



## SCOPRIO SC DC NEF LHD



**MAIN MENU** 

**INDEX** 

## **SERVICE MANUAL**

#### **CONFIDENTIAL**

ONLY FOR INTERNAL CIRCULATION WITHIN
M&M AUTHORIZED DEALERS & SERVICE
CENTRES
PASSING ON TO THIRD PARTY IS NOT
PERMITTED
ALWAYS CHECK FOR LATEST VERSION

#### **RELEASED BY:**

TECHNICAL PUBLICATION CELL MAHINDRA & MAHINDRA LTD

**VERSION 1 – AUGUST 2006** 

All copyrights reserved by Mahindra & Mahindra Ltd

# **INDEX**

# Scorpio SC DC NEF RHD

- 2.49L TURBO DI ENGINE
- AIR INTAKE SYSTEM
- COOLING SYSTEM
- EMISSION CONTROL SYSTEM
- > FUEL SYSTEM
- CLUTCH
- NGT 530 2WD
- NGT 530 4WD
- TRANSFER CASE
- PROPELLOR SHAFT
- BRAKES
- REAR AXLE
- > CHASSIS
- FRONT AXLE
- FRONT SUSPENSION
- > REAR SUSPENSION
- STEERING
- ➤ HVAC
- WHEELS & TYRES





## 2.49 L Turbo DI Engine

**Contents** 

**Description** 

**Trouble Shooting** 

**Care** of the System

In Car Repairs

Working principle, of the various subsystems of the Engine. Dismantling & overhauling of the Engine.

Working Principle, Dismantling & Overhauling of the <u>Turbocharger</u>

**Specifications & Wear Data** 

**Lubricants & Sealants** 

**Tightening Torque's** 

List of the MST

All copyrights reserved by Mahindra & Mahindra Ltd



2.49 L Engine Version 1, Aug. 06













**EXIT** 

Scorpio - SC DC





### **Description -**

The 2.6-liter Turbochargered and intercooled engine direct injected diesel engine with a bore of 94 mm and stroke of 90 mm develop 105 BHP at 3800 RPM and a torque of 257 Nm at 1800 RPM.

A waste gated turbocharger controls the boost to 2.2 bar. The compressed air is cooled by the charge intercooler which is mounted upstream of the turbocharger. The cooled air enters the inlet manifold's plenum and it enters the Cast iron cylinder head through the inlet valves having a 45-degree angle.

The piston features re-entrant type combustion chamber and having ferrous ring insert in the Top ring groove. A 3-ring pack is used. The top ring is asymmetrical barrel face and with CKS coating and keystone shape. The  $2^{nd}$  ring is taper faced. The  $3^{rd}$  is Conformable Oil Ring. The piston is having an offset of 0.5 mm

The forged connecting rod is connected to induction-hardened crankshaft. The small end of the connecting rod is trapezoidal shaped to reduce the mass as well as to ensure higher loading. The crankshaft is induction hardened with the filets hardened & ground. The flywheel has a shrunk fit ring gear and also a ball bearing to act as pilot for the gearbox input shaft. The front end is having a rubber moulded dampener pulley

The FIP and the camshaft are driven by chain. The valves are overhead valves.

## <u>Trouble Shooting</u> -

Refer to the Service diagnosis chart. Additional tests & diagnostic procedures may be necessary for specific engine complaints that can not be isolated using only the diagnostic chart.

Information concerning the additional checks is provided within the following diagnostic.

All copyrights reserved by Mahindra & Mahindra I td

Scorpio - SC DC



















## <u>Cylinder compression pressure Test</u> -

The results of the cylinder compression test can be utilized to diagnose several engine malfunctions.

Before carrying out the compression test ensure that the battery is in good working condition. Otherwise the indicated pressures may not be valid for diagnostic purpose.

- Remove all the injectors.
- Fit the dummy injector (MST no. ) and connect it with the compression gauge.
- Disconnect the FIP's solenoid.
- Crank the engine.
- Note the compression value should be 30 bars.
- Repeat the procedure for the other cylinder.
- Refer to the Specification for the value.

### **Engine cylinder Head Gasket Failure Diagnosis**

A leaking engine cylinder head gasket usually results in loss of power, loss of coolant and engine misfiring, overheating and poor fuel economy.

An engine cylinder head gasket leak can be:

A. Between adjacent cylinders

Or

B. Between a cylinder and adjacent water jacket.

Cylinder head gasket failure between cylinders is indicated by Loss of power and /or engine misfiring.

Cylinder head gasket leaking between a cylinder and coolant passage results in coolant foaming or overheating and loss of coolant indicate an engine water jackets.

## Cylinder to Cylinder Leakage Test:

Check the cylinder compression pressure as already explained. Leakage between cylinders will be result in drop of compression pressure by nearly 50 to 70% in the affected cylinders.

All copyrights reserved by Mahindra & Mahindra I td

Scorpio - SC DC



















## Cylinder to Water jacket Leakage Test -

- Remove the radiator cap.
- Warm up the engine and allow it to warm up until the engine thermostat opens.
- If large combustion /combustion pressure leak exist, bubbles will be visible in coolant.
- If bubbles are not visible, install a radiator pressure tester and pressurize the cooling circuit. If a cylinder is leaking combustion pressure into the water jackets then the tester's needle will pulsate with every combustion stroke of the cylinder.

Symptom	Causes	Remedial action
Engine will not start & emit black smoke		<ul> <li>✓ Clean the element or replace the element.</li> <li>✓ Check for free operation of Turbocharger.</li> </ul>
	<ul><li>2. Defective injectors</li><li>3. Lack of compression.</li></ul>	<ul> <li>✓ Calibrate injectors.</li> <li>✓ Check compression pressure if low check for valve seat ,rings &amp; liner wear</li> <li>✓ Replace the cyl. head</li> </ul>
	<ul><li>4. Cylinder head gasket failure</li><li>5. Engine timing-Valve and FIP injection timing.</li></ul>	gasket.  ✓ Check engine timing.
Noisy engine & black smoke.	injection timing. 2. Faulty injectors.	<ul><li>✓ Check &amp; correct the Timing.</li><li>✓ Clean or replace injectors</li></ul>
	<ul><li>3. Loose main bearings</li><li>4. Broken parts</li><li>5. Rockers loose or out of adjustment.</li></ul>	<ul> <li>✓ Tighten the main bearings.</li> <li>✓ Inspect and replace the broken parts.</li> <li>✓ Adjust tappet.</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC

















Automotive Sector			
Symptom Causes		Remedial action	
Engine speed falls off.  Figure does not give	<ul><li>2. FIP solenoid connection improper.</li><li>3. Throttle lever or accelerator cable</li></ul>	<ul> <li>✓ Rectify the FIP.</li> <li>✓ Check &amp; connect properly the 12 V supply to solenoid.</li> <li>✓ Check the accelerator cable &amp; throttle lever.</li> <li>✓ Clean filter replace if</li> </ul>	
Engine does not give full power.	<ol> <li>Air intake restricted.</li> <li>Clogged fuel filter.</li> <li>Incorrect tappet clearance</li> <li>Injection pump timing.</li> <li>Defective injectors.</li> <li>Air leaks in pressure line after</li> </ol>	required.  ✓ Replace filters.  ✓ Adjust tappets in cold	
	turbocharger( Turbo to intercooler,interc ooler & intercooler to intake manifold)	<ul> <li>✓ Replace the hose or tighten</li> <li>✓ Locate the kink/block in return pipe and rectify.</li> <li>✓ Check the pipe, washer &amp; rectify.</li> <li>✓ Check the compression, relap if required.</li> <li>✓ Get the Turbocharger repaired at authorized TEL dealer.</li> <li>✓ Replace gaskets.</li> <li>✓ Replace Turbocharger</li> <li>✓ Tighten the TC mounting</li> </ul>	
	11. Turbocharger	bolts. Replace gasket if	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC











damaged.
----------

- 12. Gas leaks between exhaust manifold cylinder head.
- 13. Restricted exhaust system.
- 14. Exhaust gas leak between turbo & manifold.
- Gas leak between EGR pipe joints
- 16. EGR pipe leak.
- **Fuels** supply line kink creating restriction.
- 18. FIP inlet Œ outlet banjos interchanged.
- 19. **EGR** valve improper functioning.
- 20. **Defective FIP**
- Compression21. leak.
- 22. Jammed piston rings
- **Viscous** 23. fan continuously engaged.

- required.
- ✓ Remove the restriction in exhaust system.
- ✓ Change the gasket or the hose.
- ✓ Replace the pipe.
- ✓ Remove the restriction.
- ✓ Fit the correct banjos
- ✓ Check the EGR using the codes. blink Proceed appropriately.
- ✓ Repair or replace the FIP.
- ✓ Check compression.
- ✓ Replace piston rings.
- ✓ Check the **VFD** as outlined in cooling. Replace if required.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC

2.49 L Engine Version 1, Aug. 06













**EXIT** 





Automotive Sector		
Symptom	Causes	Remedial action
Irregular idling	1. Leaking HP unions.	<ul><li>✓ Tighten the unions or replace the High-pressure pipes.</li><li>✓ Replace the accelerator</li></ul>
	<ol> <li>Accelerator cable sticky</li> <li>Air entering into fuel system.</li> </ol>	cable.  ✓ Replace all the banjo washers and check for the cracks in fuel line particularly from Tank to FIP
	<ul> <li>4. Vacuum connection from alternator to FICD leak.</li> <li>5. Vacuum solenoid valve of FICD.</li> <li>6. Idling stop out of</li> </ul>	<ul> <li>✓ Check all the pipes, for cracks, aging leaksreplace.</li> <li>✓ Replace the vacuum solenoid valve.</li> <li>✓ Adjust the idling stop.</li> <li>✓ Replace FICD.</li> </ul>
	adjustment 7. Defective FICD. 8. Defective FIP	✓ Repair or replace FIP.
Noisy engine & high smoke ( White/ Grey)	<ol> <li>Cylinder head gasket defective.</li> <li>Worn out or damaged valve seats.</li> </ol>	<ul><li>✓ Replace the cylinder head gasket.</li><li>✓ Lap the valve seats or regrind.</li></ul>
	<ul><li>3. FIP timing</li><li>4. Leaking injector holder</li></ul>	✓ Check the FIP timing. ✓ Tighten the injector holder.

Scorpio - SC DC



















Automotive Sector		
Symptom	Causes	Remedial action
Black smoke.	1. Air intake restricted.	✓ Check for hoses, clean or replace element.
	2. Incorrect tappet setting.	
	3. Defective injectors	<ul><li>✓ Check injectors.</li><li>✓ Correct the timing</li></ul>
	4. Improper FIP	✓ Check for leaks between
	timing 5. Air leaks.	Turbocharger to intercooler
		& intercooler to inlet manifold.
	6. EGR valve stuck open	✓ Check the EGR valve
	<ul><li>7. Defective FIP.</li><li>8. Restricted</li></ul>	<ul><li>✓ Rectify or replace FIP.</li><li>✓ Remove restriction or</li></ul>
	exhaust system.  9. Gas leak between exhaust manifold & cylinder head.	replace parts.  ✓ Replace manifold gasket or parts.
	10. Worn out rings, liners & valves.	✓ Overhaul engine.
Excessive oil consumption	1. Cracked vacuum line hoses.	✓ Check the vacuum line from the alternator to FICD and the EGR valve (check for leaks, crack. Replace cracked hoses. ✓ Clean or replace
	2. Clogged air filter element.	elements. ✓ Locate & remove
	3. Restriction in air	restriction.
	intake to compressor duct.	✓ Remove the restriction in the drainpipe.
	4. Restrictions in turbocharger oil	✓ Check the crankcase

Scorpio - SC DC

















<b>Mahindra</b> Automotive Sector		MARINDRA TECHNICAL INFORMATION SYSTEM
Automotive Sector	drain line. 5. Restriction in crankcase breather.	ventilation & rectify.
	<ul><li>6. Damaged oil separator</li><li>7. Turbocharger damaged.</li></ul>	<ul> <li>✓ Replace the oil separator</li> <li>✓ Change oil, filter, service the Turbocharger &amp; use recommended oils &amp; drain intervals. Follow the recommended procedure while shutting down.</li> </ul>
	8. Worn out rings, liners, and valves.	<ul><li>✓ Repair Turbocharger.</li><li>✓ Overhaul engine.</li></ul>
	9. External oil leaks	✓ Stop the external oil leakages.
	10. Leakages through inlet manifold mounting face allowing dust entry.	<ul><li>✓ Change the vacuum hoses.</li><li>✓ Change the manifold gasket or replace the</li></ul>
	11. Bend/kink in any of the oil return pipe's/vacuum hoses.	✓ Remove the bend or kinks.
	12. Defective vacuum pump.	✓ Replace the vacuum pump.

Scorpio - SC DC

2.49 L Engine Version 1, Aug. 06











**EXIT** 





Automotive Sector		
Symptom	Causes	Remedial action
Blue smoke.	<ol> <li>Clogged air filter element.</li> <li>Restriction in air intake to compressor duct.</li> <li>Air leak between the Turbocharger to intake manifold.</li> <li>Excess oil.</li> <li>Wear in valve seal.</li> <li>Wear in piston rings &amp; liner.</li> <li>TC oil seal leaks</li> </ol>	elements.  ✓ Locate & remove restriction.  ✓ Locate the leaks,
White smoke.	<ol> <li>Improper timing.</li> <li>Defective cylinder head gasket.</li> <li>Cold start advance not working.</li> <li>Inlet or outlet banjo not proper.</li> <li>Restriction in fuel supply</li> </ol>	attended.  ✓ Check & correct timing.  ✓ Replace the cylinder head gasket.  ✓ Check & correct KSB.  ✓ Use the correct banjo with new banjo washers.  ✓ Remove the restrictions.

Scorpio - SC DC















Automotive Sector		
Symptom	Causes	Remedial action
Starter will not work or only cranks slightly	<ol> <li>Electrical complaints.</li> <li>Check water level.</li> <li>Hydrostatic lock</li> </ol>	<ul> <li>✓ See the electrical section.</li> <li>✓ If water level reduced drastically then check for hydrostatic lock.</li> <li>✓ Remove the water in the cylinder and find the cause for water entry.</li> </ul>
Starter will not crank the engine.	<ol> <li>Weak battery.</li> <li>Corroded or loose battery connection</li> <li>Faulty starter.</li> <li>Improper earthing.</li> <li>Defective FIP's solenoid.</li> <li>Faulty FIP timing.</li> <li>Faulty FIP.</li> </ol>	<ul> <li>Cause for water entry.</li> <li>✓ Check the battery specific gravity.</li> <li>✓ Clean &amp; tighten battery connections.</li> <li>✓ Repair starter.</li> <li>✓ Rectify earthing.</li> <li>✓ Check connection or replace solenoid.</li> <li>✓ Check the FIP timing.</li> <li>✓ Replace FIP</li> </ul>
Noisy valves	<ol> <li>Tappets loose.</li> <li>Rocker arms touching the rocker cover.</li> <li>Thin or diluted oil.</li> <li>Low oil pressure.</li> <li>Bent push rods.</li> <li>Worn rocker arms.</li> <li>Worn valve guides.</li> <li>Excessive runout of valves seats</li> <li>Oil thickening</li> </ol>	<ol> <li>Install the correct rocker cover gasket. If after that also the problem persist change the rocker cover.</li> <li>Change oil.</li> <li>Check the oil level.</li> </ol>

Scorpio - SC DC









Automotive Sector		
Symptom	Causes	Remedial action
Oil pressure drop	<ol> <li>Low oil level.</li> <li>Defective oil</li> </ol>	<ul><li>✓ Check engine oil level.</li><li>✓ Install new sensor.</li></ul>
	pressures sensor. 3. Clogged oil filter. 4. Clogged oil cooler 5. Clogged oil	✓ Clean the oil cooler.
	strainer. 6. Pressure relief	✓ Clean the valve & bore
	valve in oil filter bracket stuck. 7. Oil leaks- internal	
	8. Worn parts in oil	between the block & front cover or any of the MOG plugs
	pump. 9. Excessive oil	✓ Replace the worn parts or pump.
	clearances 10. Thin or diluted oil.	<ul><li>✓ Check oil clearances.</li><li>✓ Change oil to correct</li></ul>
	11. Excessive bearing	viscosity. ✓ Remove the valve, inspect, clean & refit.
	clearance. 12. Oil pump relief valve stuck.	✓ Remove sump, inspect
	13. Oil pump suction tube	
	loose, bent or cracked.  14. Oil pump	✓ Install new pump.
Oil looks	cover warped or cracked	/ Parlaga and
Oil leaks	<ol> <li>Worn oil seals</li> <li>Misaligned or deteriorated gaskets.</li> </ol>	<ul><li>✓ Replace seals.</li><li>✓ Replace gasket.</li></ul>
	3. Loose fastener, broken or porous metal parts	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC













The performance of the engine is dependent on ensuring that the following maintenance is carried out as per the schedule without fail.

**Fan belt tension:** To be checked and adjusted if required at every 10,000 Kms.

Air cleaner: The air cleaner element to be cleaned at every 10,000 Kms. If the red band shows earlier then the element has to be cleaned. The element should be replaced at every 40,000 Kms or when the element paper is torn when inspected by a light bulb. For the detailed procedure, refer to the Air Intake System.

Oil: The oil filter and the oil should be changed every 10,000 Kms. The oil should conform to CG4 grade and with a viscosity Index of 15W40. It should be kept in mind that in the turbocharger engine the oil has to have do an additional load of lubricating and cooling the Turbocharger shaft If any oil of lower specification is used it can break down under the high thermal load at the turbine end of the shaft especially during the hot shutdown.

This oil grade also ensures that the oil consumption is within the desire limits. <u>Use Maximile Premium</u> Grade of oils. (If oil conforming to CF4 grade is used then oil change interval has to be made 7000 Kms. Oil below CG 4 are not acceptable i.e. MIL 2104 C oils are not acceptable)

**Cooling system:** Ensure that no leakages are present. For details of the coolant and ratio refer the **Cooling System**.

**Turbocharger:** The engine is having an exhaust gas driven turbocharger. The turbocharger shaft speed varies from about 40, 000 when engine is idling to about 1,70,000 when the engine is having the full rated RPM.

Thus it very critical that while shutting down, the engine is allowed to run at idle for at least one minute. Similarly the engine should be run at idle for 1 minute at starting before accelerating. Refer Turbocharger in the Intake system for further details.

















**EGR:** On vehicles fitted with EGR system the following additional points check have to done during scheduled maintenance.

- Check for any exhaust gas leakage through sealing faces, EGR pipe. Formation of any black soot indicates leakage.
- Check the vacuum hoses for any leaks, cracks.
- Retighten all nuts and bolts as per the recommend torque.
- Check blink codes every 10,000 kms.

**Tappet** setting has to be carried out every 20000. Kilometers.

While doing the tappet clearance, in case of vehicle fitted with EGR system ensure that the EGR pipe is not bend or overstress the pipes, elbow.

If the pipes are removed then it is essential that while fitting back new gaskets be used. Do not open the pipe from one end only; it will cause the pipe to twist. If the EGR pipe has to be removed, then open from both the ends.

















The in car repairs which can be carried out are: **Tappet setting** 

Accessory Belt tension adjustment.

Accessory belt removal & Refitment.

VFD Assembly with Fan Blade removal

FIP Removal & Refitment

Oil filter changing.

Turbocharger removal & Refitment.

Cylinder head gasket Replacement.

**Idling Setting** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC

















## Tappet setting -



Remove the oil filler cap and the pipe from the ladder frame to the rocker cover.



Remove the tappet cover mounting Allen screws along with the rubber washer



Remove the tappet cover.

Adjust the tappets as per the firing order.

The tappet clearance should be adjusted in cold condition and values are Inlet - 0.3 mm & Exhaust 0.45 mm



Note: The valves layout is (from the front) Ex -In-Ex-In-Ex-In-Ex-In

To rotate the engine it is suggested that the Gear be engaged and one rear wheel lifted and the wheel turned.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















## Accessory Belt tension adjustment -

Loosen the center bolt
Adjust the tension by tightening the tension bolt.
Tighten the center bolt.
Measure the belt tension using the clevis gauge.
If not found ok, repeat

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC




















## Accessory belt Remove & Refit -

Loosen the belt tension-loosen the tension bolt.
Loosen the center bolt.
Deactivate the belt tension by moving the belt tensioner away
Remove the accessory belt. If required the fan shrouds can be removed and the belt removed.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















## Fan Blade & viscous fan drive removal & assembly -

Caution: Do not remove the accessory belt before the removing the nut.
Loosen the water pump nut.
Note that the threads are anticlockwise threads. Hence to loosen then the direction of rotation has to be clockwise when viewed from front.  Do not tamper or service the center portion of the fan.
The nut should rest on pulley after tightening.
The fan blade assembly and the VFD assembly can be removed together.

## FIP Removal & Refitment

Remove tappet cover.
Bring the 1 <sup>st</sup> cylinder in compression.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC























(To confirm the first cylinder TDC position remove the 1<sup>st</sup> cylinder injector, insert the MST and the dial gauge. Check by the dial if the piston is in TDC)



To lock the FIP Loosen the timing lock bolt. Move the lock plate away & then tighten the Timing lock bolt so that it locks the camshaft.



After locking the FIP - do not rotate the engine. If rotated it can damage the FIP's camshaft





Remove the fan belt.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















Remove the FIP connections and fuel supply.



Remove the injector pipes.

Remove the FIP mounting bracket

Remove the FIP inspection cover





If the piston is not in TDC then the holes will not align with the block. As a consequence when the MST is used subsequently the MST can break.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















Automotive Sector	
	Rotate the engine to align three holes of FIP sprocket with three tapped hole provided on crank case for mounting threaded pins of FIP removal tool.
	FIT the three nosthreaded pins (Detail no. 2 of MST tool) on crankcase through FIP sprocket holes and tightened with 17-mm spanner.

Scorpio - SC DC




















All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector	Insert three slotted pins (Detail no. 5) in the other three holes of FIP sprocket and rest against crankcase face (The marking F provided on the pin should face front side)
	Now slide pins in the slot so that bottom portion of slot will butt against the back face of sprocket when FIP shaft is pushed away from sprocket.
	Remove the three nuts used for mounting the FIP flange on the crankcase
	Remove the FIP sprocket-mounting Nut
	Assemble the Flange of MST tool (Detail no. 1) with help three M8 bolts on the face of three threaded pins.  Ensure that the plate is butting properly on the three pins.
	Now assemble the M 16 threaded bolt (Detail no. 3) on the flange. Rotate the threaded bolt with 24mm spanner so that FIP is pushed out from the sprocket.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector	
	Please hold the FIP with hand while pushing out from sprocket.
	Do not remove all the pins i.e. detail no. 2 & 5 till FIP is reassembled on the sprocket.
	(If the MST is removed while the FIP is not in place then chance of sprocket getting bent and later the chain failure is high.)
	While fitting back the FIP. The plunger travel of the FIP has to be checked. Remove the center bolt at the back. Mount the dial gauge using the special tool.
CAUTION	Caution: After fitting back the FIP, loosen the timing lock bolt. Fit the plate and then retighten .So that the camshaft is free. Failure to do so will damage the FIP's camshaft when the engine is rotated.
	The plunger travel of the FIP is Euro II engine- 1.2 +/-0.05 mm

Scorpio - SC DC



















## Oil filter removal & refitting -



the right side wheel Remove apron.



Remove the oil filter using the MST 545



After removal, ensure that the central stud is fully tight.

It can work out loose while removal of the filter.

If it has worked loose then tighten it to torque of 25-30 Nm ( 18-22 Lbft)

While fitting the new oil filter. Apply oil on the "O" rings. Tighten by hand only.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC

2.49 L Engine Version 1, Aug. 06













**EXIT** 





## Turbocharger removal & Refitment -



Remove the right side wheel apron.

Remove the oil filter using the MST 545

Remove the oil cooler assembly



The above 3 steps are suggested for ease of operations & access.



Remove the air intake hose to turbocharger.





Please cover the opening to the turbocharger with cover to avoid accidentally dropping any foreign object e.g. spanner

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC























Remove the exhaust pipe from after the elbow. (Access is only after lifting it on a two post or in a pit and using a extension with UJ.)



Remove the oil feed pipe and the oil return pipe.



(It is recommended to apply rust cleaning spray (WD 40) in the nuts before attempting to remove otherwise, the stud will come off.)



Remove the turbocharger mounting 3 nuts.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















## Cylinder Head Gasket Removal & Refitment -

S. S	(Congress)	

Remove the rocker cover

Remove the Injector's high-pressure pipes.



Remove the <u>Fan blade</u> assembly along with VFD

Remove the **Accessory Belt** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC






















All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector	
CAUTION	The cylinder head gasket is of the Multi Layer Steel (MLRS) Type gasket. Though it can be assembled either way it is recommended that for optimum performance the Top, which is identified by the lettering, is facing upward. (The cylinder Head gasket cannot be reused - even if it appears to be good.)
CAUTION	Do not use any sealant/lubricant like shellac or oil on either block or head or gasket face.
CAUTION	The cylinder head bolts are to be tightened with slight trace of clean engine oil. (2-3 drops only). Do not put excess quantity of oil
	The tightening sequence is as shown.
9 3 2 6 8	The tightening torque's is 90 Nm then followed by 60-degree
7 5 1 4 10	angular torque. Again torque by 60 degree.
	The angular torque in 2 stages ensure that the tightening/clamping loads of all the bolts are very close to each other.

Scorpio - SC DC

















## Working principle, of the various subsystems of the Engine -

The various subsystems are:


**Turbocharger**: Please refer to the Air Intake System section.


**Exhaust Gas Recirulation**. (For BSII vehicles)

**Crankcase ventilation** 

Oil circulation.

All copyrights reserved by Mahindra & Mahindra Ltd

























## Working Principle of the Exhaust Gas Recirculation -



During acceleration and in higher loads the combustion chamber temperatures increase. The high combustion temperatures increase the NOx generation. The higher percentage of NOx generated in the combustion chamber come out through the tail pipe in the atmosphere.

To reduce the amount of NOx coming through the tail pipe the EGR system adds exhaust gases into the fresh air that is going into the combustion chamber. Since the exhaust gas is already burnt hence when mixed with fresh air acts an inert gas. Thus when the exhaust gas mixed with fresh air enters the combustion chamber, it performs a dual role. The first role it does is that it reduces the amount of oxygen available for combustion. The second role that it acts is as a heat absorbent/heat sink.

The net effect is that it reduces the combustion temperatures. This results in lower amount of NOx being generated.

To control the amount/percentage of exhaust gases to be circulated back to the combustion chamber an ECU is used. The ECU monitors the coolant temperature, attitude, engine speed, and accelerator pedal position. Based on the above parameters the ECU operates a switch that in turn controls the amount of vacuum going to the EGR valve. The amount of vacuum applied

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















controls the lift of the EGR valve. The lift of the EGR valve is sensed. This lift is used as feedback signal to the ECU

### EGR Valve -

Remove the EGR valve and check it valve-sticking, deposition of carbon etc. If excess carbon deposits and sticky valve noticed then it should be cleaned with a suitable solvent, so that the correct valve seat is ensured.

After cleaning the valve blow air from the bottom side of the valve and check for any leakages.

## EGR Pipe -

Remove the EGR pipe and check for gas leakage, damages etc. Clean the gasket seating area from any carbon deposits, burrs etc. Spray WD 40 rust cleaning spray on the nut.

To check the pipe for any leakages, close one end of flange and from other end blow air at 2 bars. Dip the pipe in water and observe if any leakage is observed. If any leaks are observed then the pipe has to be replaced. Do not attempt to weld/ seal the leakage joint

### **EGR Solenoid switch** -

The solenoid switch does not require any maintenance. For any damage replace the component.

## Vacuum Modulator Valve -

Does not require any maintenance. However please check and confirm that that the line from the modulator to air cleaner is clean and the hole at the air cleaner hose end is not choked.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















## Working principle of Crankcase Ventilation System -

#### Caution:

Ensure that the tying clips are not too tight & pinching/ strangulating the hoses.

The ventilation system is closed ventilation type. A hose connects the sump assembly to the rocker cover. This hose balances the gas pressure in the rocker cover and sump. The second hose goes from the rocker cover to the oil separator. This hose also has a coarse mesh, which trap the bigger particles.

The vapors with the oil particle enter the separator and due to the centrifugal action are again separated. The vacuum after the air cleaner acts on to the top of the diaphragm. The balance of the vacuum against the spring and the vapor pressure controls the amount of the oil going to the sump.

Certain amount of oil will be carried from the oil separator to the Air inlet hose, which is normal. However if it is excessive please look for all the causes mentioned in the high blow bye.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















## The Oil circulation system -

An external gear type pump sucks the oil through the strainer. The oil pump is driven by the gear, which is mounted, on the crankshaft. (Oil pump is identified by phosphating on cover plate.)

The oil pump delivers pressurized oil to the supply bore in the block. This oil is delivered to the oil cooler and after getting cooled comes on the outer side of the element. The filtered oil goes through the center of the oil filter and is connected to the main oil gallery.

The main oil gallery runs to the front of the block where it is delivered to the timing cover. From therein it takes a small loop in the timing cover and again comes to the front of the block. Goes to another oil gallery. Oil from this gallery supplies oil to the piston cooling jets

Oil from the main oil gallery goes to the crankshaft main journal and camshaft, while from the rear end it is supplied to the alternator's vacuum pump. The oil supply for the turbocharger is from the oil filter bracket.

The oil routed from the main oil gallery lubricates the timing gears and the idler gear bush. Part of this oil gets sprayed from idler shaft hole. The camshaft gear and the thrust plate are lubricated by engine oil routed from the first camshaft bushing through the camshaft hole.

The oil from the First camshaft bush goes to the top of the cylinder and enters an oil gallery, which extend upto 110 mm from the front. Oil from this gallery comes to the base of the first rocker shaft-mounting bracket. The oil then enters the rocker shaft. Oil enters the rocker bushing at through two holes facing the bottom half. At the same time it sprays from the oil hole at the side of the rocker to lubricate the valve stem and the surfaces over which the valve cap slides. The oil then returns to the sump through the push rod holes in the cylinder head.

In both the oil cooler and oil filter, bypass valves are provided which operate if the differential pressure exceeds 0.8 bar.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC




















Scorpio - SC DC

















Oil filter bracket & pressure relief valve in oil filter bracket is deleted. Crack opening pressure of relief valve in oil pump is 4.5 bar. Oil pressure sensor, which is mounted on main oil galleries rear (which is on exhaust side.)

Oil gallery is drilled from front bottom side for oil supply to hydraulic tensioner.

This oil gallery is plugged by M9 tapered plug from bottom side.

Oil supply to turbo charger is from opening in exhaust side main oil gallery.

## Dismantling & overhauling of the Engine -

Comprise of 5 steps:

Removal of the engine

Dismantling.

Inspection

**Assembly** 

**Testing** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC

2.49 L Engine Version 1, Aug. 06













**EXIT** 





## Removal of the engine from the vehicle -

- CONTRACTOR OF THE PARTY OF TH	
NOZC 1	
	Town ( 1.1)

Disconnect the battery cables & remove the battery.



Remove the bonnet.

Remove the bottom encapsulation as well as the encapsulation on top and side panels.

Remove the radiator drain cock.
Collect the coolant -if the coolant

is clean it so that it can be reused.

Remove the electrical connections of:

- Oil pressure sensor
- FIP solenoid
- Water temperature sensor.
- Starter motor
- FIP's potentiometer socket (BS II) vehicles.

Remove the hose from air cleaner to turbocharger.

Remove the air cleaner assembly.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC























Remove the hose connection from the Turbocharger end TC to intercooler.



Remove the exhaust pipe at the Turbocharger outlet elbow.



Remove the oil filter using the MST 545



Remove the Turbocharger mounting bolts and remove the Turbocharger.

It is recommended to remove the Turbocharger before the removal in order to avoid any accidental damage to it while removing.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector		
	Remove the oil evaporator system  Remove the starter motor.	
	Remove the pipe connecting the inlet pipe to FIP's LDA unit.	
	Remove the accelerator cable.	
	Remove the fuel lines from filter to FIP & return to tank	

Scorpio - SC DC





















Remove hoses connecting the water pump to radiator.



Remove the hose connected from the water pump to heater and also the heater return line.



Remove the fan shroud.



Remove the radiator.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















Automotive Sector	Remove the power steering connection hoses from the power steering pump.
	Remove the pipes connecting from AC compressor suction and discharge lines.
	Remove the vacuum hose from the vacuum pump in alternator to booster
	Drain the oil from the sump.
	Attach lifting device.
	Remove the front insulators mounting bolts,
	Remove the gearbox mounting Allen screws.
	Pull out and lift the engine from the engine compartment.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC

2.49 L Engine Version 1, Aug. 06
















**EXIT** 








After removing the engine from the vehicle mount it on the engine stand.



Remove the rocker cover



Remove the High-pressure pipes.



Remove the leak off pipe.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















Loosen the Viscous Fan Drives nut. Loosen the water pump nut.

Note that the threads are anticlockwise threads. Hence to loosen then the direction of rotation has to be clockwise when viewed from front



Loosen the tensioner bolt first. Loosen the belt tension with the bolt on bracket.

Remove the accessory belt.



Remove the pipe from the oil cooler to the water pump.



Remove the water pump.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















Remove the pipe oil cooler to the block.



Remove the oil cooler.



Remove the accessory like power steering pump. AC pump and the alternator.



Remove the injectors.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC






















Bring the first cylinder into compression. Confirm using the MST



Remove the front cover on the timing cover.

Ensure that the "O" rings on the front cover is kept securely so that it can be reused if not damaged while





Loosen the timing lock bolt (FBB). Remove the triangular plate and then tighten so that the FIP's camshaft is locked.

Remove the FIP's locking bolt.

Remove the FIP inspection cover

Rotate the engine to align three holes of FIP sprocket with three tapped hole provided on crank case for mounting threaded pins of FIP removal tool.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC





















FIT the three nos.-threaded pins (Detail no. 2 of MST tool) on crankcase through FIP sprocket holes and tightened with 17-mm spanner.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC




















All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector			
	Insert three slotted pins (Detail no. 5) in the other three holes of FIP sprocket and rest against crankcase face (The marking F provided on the pin should face front side)		
	Now slide pins in the slot so that bottom portion of slot will butt against the back face of sprocket when FIP shaft is pushed away from sprocket.		
	Remove the three nuts used for mounting the FIP flange on the crankcase		
	Remove the FIP sprocket-mounting Nut		
	Assemble the Flange of MST tool (Detail no. 1) with help three M8 bolts on the face of three threaded pins.		
	Now assemble the M 16 threaded bolt (Detail no. 3) on the flange. Rotate the threaded bolt with 24mm spanner so that FIP is pushed out from the sprocket.		
	Please hold the FIP with hand while pushing out from sprocket.		
	Do not remove all the pins i.e. detail no. 2 & 5 till FIP is reassembled on the sprocket.		
	(If the MST is removed while the FIP is not in place then chance of sprocket getting bent and later the chain failure is high.)		

Scorpio - SC DC

















Automotive Sector		
	While fitting back the FIP. The plunger travel of the FIP has to be checked. Remove the center bolt at the back. Mount the dial gauge using the special tool.	
CAUTION	Caution: After fitting back the FIP, loosen the timing lock bolt. Fit the plate and then retighten .So that the camshaft is free. Failure to do so will damage the FIP's camshaft when the engine is rotated.	
	The plunger travel of the FIP is	
	1.2 =/- 0.05 mm	
	Remove rocker cover	
	Remove the rocker shaft assembly	
	Remove the cylinder head mounting bolts.	
	Remove the cylinder head along with the inlet and exhaust manifold.	

Scorpio - SC DC






















Rotate the engine.



Remove the oil sump.



Remove the oil pump along with the suction.

Rotate the engine by 90 degree.

Remove the oil jets along with the gasket.



Remove the connecting rod caps and take out the pistons.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC
























All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC






















Remove the rear end oil seal with the retainer.



Remove the main bearing bolts.

Remove	the	bearing	caps	along	with
bearing s	hell	halves.			
Remove	the c	rankshaf	t.		
Remove	the	bearing	shells	& t	hrust
washers.					
Rotate th	ne en	gine.			
Remove MST	the	cylinder	liners	using	the
Remove	the	tappets	by rev	ersing	the

engine.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















All the components should be inspected for wear. Any components, which are beyond the wear limits, have to be replaced.

Over & above the wear limits: The following points also need to be ensured.

<u>Piston</u>: Check for scuffing/scoring on the skirt. A hard thick layer of carbon lacquer on top land is acceptable. (If the thick layer is present on the piston check that the liner does not have scuffing)

However scuffing of the top land and skirt giving indication of overheating which is not acceptable.

**Cylinder Liner**: Any scoring on the liner is not acceptable.

<u>Crankshaft</u>: Check for scoring on the main as well as connecting rod journal. If scoring is nominal and will not the increase the oil clearance then the crankshaft can be used in, as it is condition.

However if it is unacceptable then the journal has to be ground up to service limits only.

Any deep groove in the rear end oil seal seating area is unacceptable. It will result in oil leaks.

Valve: If valve tip is worn out/ ridged then not acceptable

<u>Main bearing and connecting rod bearing</u> - If the scoring is nominal and oil clearance is not affected, then it can be reused. However if flaking /peeling of the bimetal in any particular zone only is present then use new shell. Look for foreign particle embedded, deep scratches.

<u>Dampener pulley</u> rubber bonding- inspect for any gap between the rubber ring and the outer/inner ring. Cracks on ring. Any deep groove in the front oil seal seating area is unacceptable. It will lead to leakage's.

If any deterioration of rubber or gap noticed between the ring and the rubber replace the dampener pulley.

It is suggested that the dampener pulley be replaced at every 3,00,000 Kms.

All copyrights reserved by Mahindra & Mahindra I td

Scorpio - SC DC



















#### Caution:

While measuring the inner diameter of the connecting rod big end and main journal please take the measurements after torque tightening only. For measurement purpose the torque should be 85±8 Nm. Do not reuse this bolt

If line boring of the crankshaft's journal in the block is done to rectify any ovality. Then please ensure that the material from block half is not removed. In absence of taking this precaution the piston will move up. It will change the compression, influencing the performance. In the worst case the valves can hit the piston.

## Assembly -

The assembly sequence is the reverse of the dismantling procedure. To obtain a good life of the rebuilt unit absolute cleanliness of the parts is taken as a prerequisite and also the fact that all the parts have been inspected.

The additional points which are mentioned are necessary to give you the engine life same as the original engine.

<u>Bolts</u> - The following bolts are recommend to be replace every time they are opened-if the Maximum length exceeds the specification. However the connecting rod bolt has to be changed every time without exception.

The bolts have to be tightened by base torque then 2 stage angular torque. The angular torque's ensures that the bolts are torqued up to yield point. And the 2 stage ensures that the clamping load for each bolt is within a very close tolerance.

Cylinder head bolts- 10 no Maximum length 136.6/135.4 mm
Main Bearing Bolts- 10 no Maximum length 90.6/89.4mm Connecting rod
bolts- 8 noReplace everytime
Flywheel bolts- 6no Maximum length 29.58/30.42 mm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















<u>Cylinder block - Top face</u> - Ensure that the tapping for the cylinder head bolt as well as the crankshaft's main journal is fine. Ensure that no water or oil after cleaning is in the bolt holes (esp. the cylinder heads.). If found please remove them, if necessary using cotton cloth (not cotton waste).

If the oil /water is not removed then it is possible that while tightening the bolt. It may not allow complete tightening of the bolts and one will get a false reading.

## Cylinder head gasket -

It is a multi layer steel gasket type. Do not use any oil or shellac on the cylinder head gasket or on the block face or the cylinder head face. The gasket has to be fitted dry.

The gasket can be assembled any face up or down. However it is suggested that the face with the numbers should be facing up.

## Piston & Rings-

While fitting the piston rings ensure that the rings end gap are staggered in 120°.

The first ring end gap should not be on the thrust axis but the minor axis i.e. on the gudgeon pin axis. Please note that the first ring is keystone shaped hence the top mark has to face up. The 2<sup>nd</sup> ring is taper faced. The face, which should be on the top, has to be facing up. The 3<sup>rd</sup> ring is the conformable type oil ring. It can be assembled either way.

While assembling the piston on to the liner- apply clean oil liberally on the liner surface.

# Bearing shells -

Before fitting the bearing shell ensure that the parent bore of the block/connecting rod are clean.

Wipe with a clean cloth the back end of shells before assembling on to the block or connecting rod.

Ensure that the bearing shells are located properly in the notches.

Oil seals -

Ensure that

✓ All the oil seals are fitted using the dolly MST.

All copyrights reserved by Mahindra & Mahindra I td

Scorpio - SC DC



















- ✓ Always ensure that the lip is coated with grease before fitment.
- ✓ Apply engine oil on the outside diameter of seal. The receiving bore should be free of burrs, dent.

## Oil pump -

The oil pump for chain drives engine is identified by phosphating on cover plate. <u>CAUTION</u>. Oil pump of chain drive engine & gear drive engine are dimensionally similar but are not interchangeable due to difference in crack opening pressure of pressure relief valve.

## **Testing** -

After the engine is reassembled in the engine stand. It is recommended that:

The engine is assembled back to the vehicle. All the connections are made.

- ✓ Start the engine
- ✓ Run at idle for 5 minute. Observe for leaks.
- ✓ Drive the vehicle at 50% of the maximum speed in each gear for about 10 to 30 Km each (Aprox.)
- ✓ Hand over the vehicle to customer to drive with speed limitation for 2000 Kms.
- ✓ After 5000 Kms. Readjust the fan belt and tappet clearance. Change the engine oil.

DO NOT RUN THE ENGINE WITHOUT LOAD FOR HOURS FOR BEDDING IN. THIS PROCESS ONLY HARMS THE ENGINE.

RUNNING THE ENGINE WITHOUT LOAD CAUSE RING FLUTTERING AND DAMAGE TO RINGS AS WELL AS LINERS.

RUNNING THE ENGINE AT IDLE FOR PROLONGED TIME HAS SERIOUS CONSEQUENCES ON MAJOR ENGINE COMPONENTS

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















# Automotive Sector Specifications & Wear Data -

Figure	Description	Value
	Bore	94 mm
1	Stroke	90 mm
	Power- Max	105 BHP @ 3800
	Torque-Max	257 Nm@1800
	Firing Order	1-3-4-2
	Direction of rotation	Clockwise from fan side
	Emission limits	I. Euro II
	Compression Pressure	Standard 30 bar
	Compression ratio	17.8
	Permissible variation of compression pressure between cylinders.	
	Piston	Reentrant Bowl

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector		
Figure	Description	Value
	Piston Pin	Full floating. Surface
		hardened & ground.
	Oil grade & Quantity	API grade CG4
		Viscosity Index 15W40 6 liters
Σ		Mahindra Maximile 10 K
	Cylinder liner	Replaceable wet type Cast
		Iron
1	Tappet clearance	
	Inlet	
	Exhaust	0.45 mm
	Inlet valve	
	OPENS	14°BTDC
	CLOSES	30°ABDC
	Exhaust Valve	
	OPENS	46°BBDC
	CLOSES	14°ATDC
	Oil pump shaft	Standard Service Limit
		13.984/13.966 13.956
	Oil pump shaft Bush	Standard Service Limit
		14.000/14.018 14.038
	Oil filter bypass opening pressure	0.8 bar
	Relief valve opening	2.5/3.5 bar
	pressure ( for gear	
	drive engines only)	
	Oil pressure at	
	Idle ( 60~80°C)	2.5 bar
	Max speed( 60~80°C)	

Scorpio - SC DC



















Automotive Sector			
Figure	Figure Description Value		llue
	Piston ring to groove clearance	Standard	Service Limit
		0.11/0.15	0.25
	2 <sup>nd</sup> ring	0.05/0.09	0.15
	3 <sup>rd</sup> ring	0.04/0.072	0.15
	Piston ring end gaps	Standard	Service Limit
	1 <sup>st</sup> ring	0.33/0.55	0.9
	2 <sup>nd</sup> ring	0.8/1.05	1.5
	3 <sup>rd</sup> ring	0.25/0.55	0.9
<b>+</b>	Gudgeon pin O.D φ	32/31.994	
	Connecting rod -	Standard	
	Small end bush I.D $\phi$ in assembled condition	32.041/32.02	
	Gudgeon pin to	Standard	Service Limit
	connecting rod small end bush clearance.	0.047/0.025	0.05
	Gudgeon pin to piston pin hole clearance	Standard 0.017/0.004	Service Limit 0.03
	Piston weights grading		
	A	836-840 gm	
h	В	841-845 gm	
	С	846-850 gm	
	D	851-855 gm	
	Е	856-860 gm	

Scorpio - SC DC















Automotive Sector		
Figure	Description	Value
	Connecting rod	
	grading as per	
	weights	≥ 1260
	F	≥1265
	G	
	H	≥1275
	!	≥1280
	J	≥1285
	K L	≥1290
	M	≥1295
	N N	≥1300
	0	≥1305
	P	≥1310
	R.	≥1315
	S	≥1320
	T	≥1325 to 1330
	Ü	
	Recommended for	M i.e. 1295 to 1300 gms
	service replacement	
	Connecting rod bend	0.05 in 50mm length.
	or twist	
	Connecting rod	160 mm
	centre to centre	
	distance (Big end to	
	small end)	
	Connecting rod end	Standard Service Limit
	play	0.1/0.3 0.5
4	Crankshaft end play	Standard Service Limit
	Crankshart end play	0.10/0.37 0.5
		0.10/0.3/
/		
	Camshaft end play	Standard Service Limit
		01/0.3 0.4
,		

Scorpio - SC DC



















	Automotive Sector			
	Figure	Description	Value	
		Liner projection from	0.02/0.09	
		crankcase top		
		surface		
		X Axis- Along C/s	Standard Limit	
		Y Axis- Perpendicular		
		to cranks shaft	φ ID 94.022/94.04	
/	X axis	A- 25 mm		
		B86.6 mm	Roundness ≤ 0.05	
	<b>₹</b> ***	C- 113 mm		
		D- 163 mm	Cylindricty ≤ 0.05	
		Roundness/Ovality-		
		Difference in X & Y		
		plane at any pt.		
		Cylindricity/Taper -		
		Difference in same		
		plane x/y at any		
		point Crankcase top	Standard Service	
		surface distortion	Limit	
		surface distortion	0.07 0.1	
		Cylinder head	Standard Service Limit	
		bottom face	0.05 0.1	
		distortion	0.03	
		Height of cylinder	Standard Service Limit	
		head from top to	97.7/98.3 97.4	
	<b></b>	bottom face		
		Rocker lever bush I.D	22.0	
		( in pressed	22.0	
		condition)		
		condicion		
		Rocker shaft O.D	21.98/21.980	
		Rocker to shaft	Standard Service Limit	
		clearance	0.02/0.06 0.2	
		Push rod bent	Standard Service Limit	
			≤ 0.25 0.4	

Scorpio - SC DC



















Automotive Sector		
Figure	Description	Value
	Valve spring	Standard Service Limit
	Free Length	53.6 50.6
	Squareness	0.15 0.2
	Installed	381.5N/43 mm 347 N
	Load/Installed length	
	Valve seat angle	44°45′ to 45°
П	Valve stem O.D	
<b>→</b>	Inlet	6.95/7.10
	Exhaust	6.95/7.10
п	Valve to Valve guide	
	clearance	
	Cicui dilee	
	Inlet	0.03/0.07
	Exhaust	
	Thickness of the	Standard Service Limit
	valve head	Standard Service Limit
	valve nead	2.0 1.5
		2.0
<u> </u>		
Chain Drive	Chain	Pitch - 3/8" (9.52 mm )
Engine		, ,
		Duplex bush type
		102 Links, Endless &
		Riveted.
+ 0.0		
	Crank Sprocket	19 Teeth
	Cam & FIP Sprocket	38 Teeth
	Difference between	Standard Service Limit
	Cam height & base	
	circle diameter	
<b>├</b>		
<b>—</b>	Inlet	6.0796 5.5796
	Exhaust	6.9076 6.4076
	=/:::005€	

Scorpio - SC DC



















Automotive Sector			
Figure	Description	Valu	ie
	Camshaft Bush I.Dφ	49.025/49.0	
	Camshaft Journal O.D	48.98/48.95	
	Camshaft bush to	Standard	Service
	cam journal		Limit
		0.02/0.075	0.1
	Camshaft bend	≤ 0.01	
	I.D of tappet hole in crankcase	24.48	
	Tappet to tappet	Standard	Service
	hole clearance	Limit	
		0.02/0.075	0.15
<b>├</b>	Crankshaft pin ∅ OD Roundness/Ovality	Standard Limit 53.0/52.981	Service
	Cylindricity/Taper	≤ 0.01	0.03
	Cytillaricity/raper	≤ 0.012	0.03
<b>₹</b>	-· Throw	45 mm	
	Main Bearing oil clearance	Standard Limit 0.016/0.074	Service 0.1
	Undersize of the c/s	Dimensions	of the
	crank pin $\varnothing$ OD	crankpin.	
	0.25mm US	•	
	0.50 mm US	52.75/52.731	
	0.75 mm US	52.50/52.481	
		52.25/52.231	

Scorpio - SC DC

2.49 L Engine Version 1, Aug. 06











**EXIT** 





Automotive Sector			
Figure	Description	Value	
	Crankshaft journal  Ø OD Roundness/ Ovality Cylindricity/ Taper		
	Undersize of the c/s journal pin Ø OD 0.25mm US 0.50 mm US 0.75 mm US	Dimensions of the journal 58.75/58.371 58.50/58.481 58.25/58.231	
	Crankshaft bend CAUTION	Standard Service Limit ≤ 0.025 0.06  FILLETS ARE HARDENED. DO NOT ATTEMPT TO STRAIGTEN	
1	Crankshaft fillet radius	Standard Service Limits 3.0/3.5	
	Crankshaft Hardness Minimum	50 HRC	
	Connecting rod Bearing oil clearance	Standard Service Limit 0.016/0.040 0.070	
	The Maximum length of bolts after which they have to can not be used  Cylinder head bolts Main Bearing Bolts Connecting rod Flywheel bolts length	Replace everytime	

Scorpio - SC DC



















Figure	Description	Val	ue
	Thermostat		
	Starts opening at	84~88°C	
	Fully opens at	96°C	
	Lift	mm	
	Water pump pulley ratio	1.25	
	Flywheel Width from Mounting face to clutch face	35±0.13	
	Flywheel	Standard	Service
	Flatness	Limit	
	Runout	≤ 0.05	0.1
		≤ 0.05	0.1

## **Lubricants & Sealants**

Mahindra Maximile Premium Or any other engine oil conforming to API grade CG4 or above and a viscosity Index of 15W 40.

If any oil conforming to CG4 grade is used then the oil change interval is 7000 Kilometers. Oils of MIL 2104 C or below are not acceptable

RTV silicone sealant- RHODOSEAL. Part number 0024532 to be used:

- Between Rear oil seal retainer & Block
- Between ladder frame & block

All other places Loctite 547. Part number 0084337 are used.

Hard gaskets are used only at: -

- ✓ Cylinder head Gasket.
- ✓ Turbocharger to Exhaust manifold mounting.
- ✓ Exhaust manifold to cylinder head.
- ✓ Exhaust manifold to EGR pipe
- ✓ EGR pipe to elbow.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















Automotive Sector Rust cleaning solution (For the Turbocharger mounting nuts):

Brand Name: WD-40
Manufacturer- WD-40 COMPANY
MARKETEDBY—Hardcastle & Waud Manufacturing Co. Ltd.
Brabourne Stadium,
87, Veer Nariman Road
MUMBAI-20.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















# Automotive Sector <u>Tightening Torque's</u> -

Bolt location	Torque in Nm ( Lbft)	
Cylinder head	90 Nm + 60° + 60° ( 66.4 Lbft +	
	60°+ 60°)	
Connecting rod	45 Nm + 90° ( 33 Lbft +90°)	
Main Bearing cap	168 ± 17 Nm ( 123 ± 12.5 Lbft)	
Flywheel	,	
	90 Nm + 60° ( 66 Lbft+ 60°)	
Main Drive Pulley	Step 1:- 67 Nm (49.4 Lbft)	
	Step 2: -167 Nm ( 123 Lbft)	
Cranks shaft pulley	90 Nm + 90°+ 90°	
(apply oil on bolt before		
tightening)		
Cam gear mounting bolts	110 $\pm$ 10 Nm (81 $\pm$ 7.4 Lbft)	
FIP gear lock nut	92.5 $\pm$ 3 Nm ( 68 $\pm$ 2.2 Lbft)	
Camshaft thrust mounting	25 $\pm$ 3 Nm ( 18.4 $\pm$ 2.2 Lbft)	
plate		
Crank gear mounting bolts	105 ± 10 ( 77.4 ± 7.4 Lbft)	
Idler shaft mounting bolts	25 ± 3 Nm ( 18.4 ± 2.2 Lbft)	
Viscous Fan clutch nut	40-50 Nm ( 29.5 to 37 Lbft)	
Water drain plate mounting	$25 \pm 3 \; \text{Nm} \; (\; 18.4 \pm 2.2 \; \text{Lbft})$	
bolts in crankcase		
Injector holding clamping stud	25 ± 3 Nm ( 18.4 ± 2.2 Lbft)	
Front cover on crankcase	$25 \pm 3$ Nm ( $18.4 \pm 2.2$ Lbft)	
Oil jet Assembly bolt		
M14	35± 3 Nm ( 26±2 Lbft)	
M6	11± 1 Nm ( 8± 0.73 Lbft)	
FIP Lock screw	12.5 ± 2.5 Nm	
All M5 nuts/ Bolts on FIP	2~3 Nm	
High Pressure Pipe Nut	$25 \pm 3 \text{ Nm} (18.4 \pm 2.2 \text{ Lbft})$	
Injector holding clamping	$25\pm3$ Nm ( $18.4\pm2.2$ Lbft)	
stud.	F 7 Nm	
Injector Overflow pipe Banjo nut	5-7 Nm	
LDA hose on FIP	10-15 Nm	
LDA hose banjo on manifold	10-15 Nm	
Fast idle screw on FIP	10-15 Nm	
FIP Inlet & Outlet Banjo	15~20 Nm	
in met a oatiet banjo	IJ ZU IVIII	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC



















# List of the MST

MST Number	Description
MST - 542	Special Spanner for Nut -
	Engine Mounting
MST - 543	Extractor Flywheel Bearing
MST - 544	Drift Flywheel Bearing
MST - 545	Wrench Oil Filter Remover



















Air Intake System-2.49 L

**Contents** 

**Description** 

**Trouble Shooting** 

**Care** of the System

**In Car Repairs** 

Working Principle, Inspection & Fitment procedures of the Turbocharger

**Specification** 

**Tightening** Torque's




















The air is sucked through a foam air cleaner. The air enters the air cleaner housing at the bottom and leaves at the top.

The air cleaner is made up of 5 different layers of foam. Each layer is having different cleaning efficiency.



After filtration the air goes to the turbocharger.

Before turbocharger there is mechanical or electrical service indicator. In case of electrical service indicator, signal of choked air cleaner goes to the instrument cluster. In case of mechanical one, red band appears in choked condition.

The waste gated turbocharger controls the boost to 1.8. The compressed air is cooled by the charge intercooler, which is mounted just below the radiator. The cooled air enters the inlet manifolds. It enters the Cast iron cylinder head through the inlet valves having a 45-degree angle.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















# Automotive Sector <u>Trouble Shooting</u> -

Symptom	Causes	Remedial action
Engine will not start & emit black smoke  Engine does not give full power.	Air intake obstructed  1. Air intake restricted. 2. Air leaks in system after turbocharger 3. Air leak in pipe - manifold to FIP 4. Boost pressure control valve stuck in pen condition. 5. Boost pressure pipe/hose assembly damaged 6. Turbocharger damaged.	<ul> <li>✓ Check whether service indicator light glows or red band appears and replace element if light is on /red band appears.</li> <li>✓ Refer to the <u>care of the system</u> also</li> <li>✓ Check for free operation of Turbocharger</li> <li>✓ Replace element.</li> <li>✓ Plug the leaks, replace hose or clip if required.</li> <li>✓ Replace the hose or tighten</li> <li>✓ Correct the control valve &amp; find the cause</li> <li>✓ Check the pipe, washer &amp; rectify.</li> <li>✓ Get the Turbocharger repaired at authorized</li> </ul>
Black smoke.	<ol> <li>Air intake restricted.</li> <li>Air leaks.</li> </ol>	<ul> <li>✓ Check for hoses, replace element.</li> <li>✓ Check for leaks between Turbocharger &amp; inlet manifold</li> <li>✓ Remove restriction or replace parts.</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC















Automotive Sector			
Causes	Remedial action		
element.  2. Restriction in air intake to compressor duct.  3. Air leak between the Turbocharger to intake manifold.  4. Restrictions in turbocharger drain line.  5. Restriction in crankcase breather.  6. Thick oil/sludge or coke in the turbocharger's central housing  7. Turbocharger damaged.  1. Indication of	<ul> <li>✓ Locate &amp; remove restriction.</li> <li>✓ Locate the leaks, change hose or clamp if required.</li> <li>✓ Remove the restriction in the drainpipe.</li> <li>✓ Check the crankcase ventilation &amp; rectify.</li> <li>✓ Change oil, filter, service the Turbocharger &amp; use recommended oils &amp; drain intervals. Follow the recommended procedure while shutting down.</li> <li>✓ Repair Turbocharger.</li> </ul>		
air leak esp. in between: Turbocharger to inlet manifold.	the intercooler inlet and outlet.  ✓ Tighten the clamps at the Turbocharger inlet & outlet.  ✓ Check the hoses for leak  ✓ Check & replace the pipe to and from intercooler.		
	<ol> <li>Clogged air filter element.</li> <li>Restriction in air intake to compressor duct.</li> <li>Air leak between the Turbocharger to intake manifold.</li> <li>Restrictions in turbocharger drain line.</li> <li>Restriction in crankcase breather.</li> <li>Thick oil/sludge or coke in the turbocharger's central housing</li> <li>Turbocharger damaged.</li> <li>Indication of air leak esp. in between: Turbocharger to inlet</li> </ol>		

















The air cleaner element should be replaced every 40,000 km or If service indicator light glows under normal driving conditions.

Under extremely dusty conditions replace earlier than above.

It should be noted that if the engine is run with clogged air cleaner, then it will lead to seepage of oil from turbocharger into the air intake system. Ensure that the recommended engine oil only is used and the specified drain intervals are maintained.

To achieve an optimum cooling of the compressed air it is vital that the vehicle's number plate position is not changed and/ or an oversize number plate does not block the aperture for the air draft for the intercooler.

The Turbocharger & boost control valve does not require any special maintenance. However check the boost pressure pipe for proper fitment (connection from compressor to boost valve). Damage, cracks, chips at ends, etc.

Check the operation of the waste gate valve by blowing compressed air with 2.0 bar in the valve hose. The valve should open, pressing the turbocharger stem and opening the exhaust valve (flap valve)

Check the oil separator system, in particular for any leak in vacuum leak. As any vacuum leak will lead to a high-pressure build up and then it will go through the intake system and give a signal of high blow by or be confused with compressor oil leak.

Do not attempt to disturb length of the waste gate controlling actuator rod.

If the Turbocharger is removed, please do not lift the turbocharger using the actuator rod as a lifting handle.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC














Air cleaner Removal

Cleaning the element.

Turbocharger removal & Refitment.

# Air cleaner Servicing -



# To replace the filter element -

- 1) Remove filter housing completely from engine compartment. Remove Mass Flow Sensor
- 2) Ensure that filter housing is completely clean by blowing compressed air (<30psi) inside filter housing

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















- 3) Ensure that the bottom grate is in position and not loose or shaking before putting the element.
- 4) Install foam filter pack into housing taking care to ensure that all layers sit correctly and no layers are folded over and foam fingers projecting out
- 5) Ensure that all edges of the foam filter pack are sitting properly
- 6) Ensure that Top Grate is in position and seated properly
- 7) Assemble top cover and tighten all screws.



The cleaning of the element is not recommended under any circumstance.

Do not wring the foam.

Do not use if foam is cut, torn or foam layers are separated."

# Turbocharger removal & Refitment -



Remove the air cleaner assembly

Remove the exhaust pipe from after the elbow. (Access is only after lifting it on a two post or in a pit.)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















Remove the air intake hose to turbocharger.



Remove the oil feed pipe and the oil return pipe.



It is suggested that the all the opening in the Turbine housing, compressor housing and the center housing be covered with plugs or masking tape.

This is recommended as even a small particle/ washer if trapped between the blades & housing can destroy the turbocharger.

(It is recommended to apply rust cleaning spray in the nuts before attempting to remove otherwise the stud will come off.)

Remove the turbocharger mounting 3 nuts.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC






















# Working Principle, Inspection & Fitment procedures of the Turbocharger

The Turbocharger is basically an axial inflow air compressor, which is driven by an exhaust gas driven turbine.

The exhausts gases coming out of exhaust manifold impinge on the turbine blade give the drive to turbine shaft. At the other end of the turbine shaft the compressor is assembled. The whole assembly is supported on a floating bush. The bush gets an oil supply directly from the engine and has oil film between the shaft and bearing as well as the bush and the central housing.

The exhaust gases from the Turbine impinge on the turbine blade & rotate the shaft. The compressor blades at the other end suck the air from the air filter. After compression the temperature of the compressed air increases thus reducing the air density. Hence if the air is cooled and then the air density increases thus helping in getting more power as well as improve emissions. The compressed air is sent to the intercooler, which is mounted just below the radiator. Hence the incoming ram air also cools the compressed air and gives it to the intake manifold.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















The turbocharger is matched to give an optimum boost for the desired engine speed band. A waste gate controls the boost. The waste gate is used to bypass the excess exhaust gas away from the turbine and thus maintain the boost as well as control the backpressure. A spring-loaded diaphragm controls the waste gate.

A flap valve is installed in the turbine housing just before the turbine blade. Opening the valve allows the excess gases to bypass the turbine. The flap movement is controlled by a push rod, which is controlled by a spring-loaded diaphragm. At the other end of the diaphragm the compressed air is sensed through a hose which is connected at a tapping in the compressor housing.

The length of the pushrod, functioning of the diaphragm and the hose connection are essential for the precise operation of the push rod. Any air leak from the hose connecting the compressor housing to the waste gate-controlling diaphragm will also affect the performance of the turbocharger/engine.

## Inspection

- ✓ Inspect the suction side (i.e. up to the air cleaner) for oil traces. In a close crank case ventilation system it is normal to have oil in this area. These oil particles are carried from blow bye of the engine, which gets condensed from gas to oil. Look for any undue gumming of oil, hard carbon particles in this area. If such an observation is present then all the causes for excess blow symptoms have to be checked and eliminated.
- ✓ Inspect the compressor and turbine blades for any damage caused by foreign object. The inspection can be done through the compressor housing inlet and turbine housings outlet.
- ✓ Inspect the blades outer edge and observe if any rubbing marks are noticed on the housing.
- ✓ Rotate the shaft wheel assembly by hand and check for freeness, and any binding.
- ✓ Push the shaft to side and rotate to check for wheel rub. It should turn smoothly.


















- ✓ Lift both end of shaft up and down at the same time and feel for excessive journal bearing clearance. If clearance is normal then very little shaft movement will be detected.
- If all the above checks are satisfactory then the turbocharger can be reused.
- ♦ If the turbocharger parts are damaged, wheel rubbing marks present, shaft not rotating freely or binding or excessive journal clearance then the Turbocharger should be serviced.
- ✓ Do not attempt to service or overhaul the Turbocharger. It should be done only at the authorized Turbo Energy Ltd service center. Any attempts to attend without the use of special tools or procedure can damage to turbocharger or personnel!

#### **Turbocharger Installation**



Do not mishandle, tumbled, dropped or keep any ports open.

Do not use the actuator control rod for lifting or carrying.

Do not disturb the setting of the actuator.

## Check

The inlet connection & outlet exhaust connection to turbocharger for foreign material, cracks, blockages, sand particles, loose nuts etc. This check should be done more thoroughly if any damage has been noticed in compressor or turbine blades. As under normal operating conditions the blades can damaged only if a foreign object hits them.

Check all the hoses and pipes from turbocharger outlet to inercooler and intercooler to inlet manifold for crack, aging, leaks. Check the hose clips for proper functioning. If in doubt - replace.

The oil supply pipe should be checked carbon deposits, crack, distortions etc. Clean the supply pipe before fitting.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















Do not attempt to change the orientation of turbocharger and ensure the correct gaskets are used.

Do not re use any of metallic gaskets even if they appear to be good. It will lead to leakage & drop in the performance of the engine.

#### Installation -

Once a new turbocharger is being installed.

- i. Fill fresh clean oil from the oil supplies port and after that gives the shaft few rotations.
- ii. Fit the supply pipe.
- iii. Without fitting the drain oil pipe, disconnect the FIP solenoid.
- iv. Crank the engine till a steady stream of oil comes out through the drainpipe. (<u>CAUTION</u>: Do not crank the engine for too long. Excessive cranking will result in emptying of the pump cavity causing the plunger to run dry.)

This will ensure that the oil supply line to Turbocharger is purged of any air pocket.

After this fit the return line from turbocharger to sump, taking care to avoid any kinks.

With engine running condition, check the air, exhaust and oil connections for leaks.

# **Specifications** -

Turbocharger Model	K 03
Turbocharger specifications	K0 3-2070 ECD5.82
Turbocharger supplier	Turbo Energy Ltd.
Oil pressure at upstream	f 2.5 bar @ idle
turbocharger	

All copyrights reserved by Mahindra & Mahindra Ltd

Main Menu

Scorpio -SC DC

















# <u>Tightening Torque's</u> -

Bolt location	Torque in Nm ( Lbft)
Turbocharger Mounting stud/	25±3 ( 18.4±2 )
nut	·
Inlet manifold	25±3 ( 18.4±2 )
LDA hose on FIP	10 to 15 (7.37 to 11)
LDA hose banjo on FIP	10 to 15 (7.37 to 11)

















Cooling System- 2.49 L

**Description** 

**Trouble Shooting** 

**Care** of the system

In Car repairs

**Dismantling & Assembly of the Cooling System.** 

Fan Belt-Routing & Analysis

**Specifications & Coolant** 

**Tightening Torque's** 




















# **Description** -

The cooling system is designed to cater to the following functions:

- Remove & dissipate excess heat from the combustion process.
- To maintain the optimum temperature for complete and uniform combustion.
- To provide heating for the heater system.( In the models where the Heater is provided)

The cooling system include the following components/ sub system:

- ✓ Radiator
- ✓ Radiator Pressure cap
- ✓ Coolant
- ✓ Cooling fan ( Mechanical or Electrical)
- √ Fan drive



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC


















- √ Fan shroudThermostat
- √ Water pump
- ✓ Thermostat housing, cover thermostat.
- ✓ Recovery tank
- ✓ Hoses & their clamp.

The layout of the cooling system is shown in the sketch, above. The functional system is shown in the block diagram.




















Broadly speaking the water flows from the water pump to the Front cover from the cover it goes to cylinder block and from the block to the cylinder head and then to the bottom of thermostat. In case the thermostat is closed, water goes through the bypass tube to water pump. Once the thermostat opens the water goes to the radiator and after getting cooled the water is again fed to the water pump. One pipe goes from the thermostat housing to the heater core of HVAC unit and then returns

#### Water pump & cover -

The coolant from the outlet elbow of the cross flow type radiator enters the inlet of the water pump. The centrifugal water pump delivers the water to the front cover from there to the cylinder block.

The Pump housing is aluminum. Water pump & thermostat housing by pass is connected by out side hose.



# Cylinder block & cylinder head -

In the block the water enters a main cooling passage which runs along the length of the block in one sides (inlet manifold side). The top passage ensures that the maximum cooling is provided to the hottest zone of the cylinder liners i.e. the top portion.

At the same time a passage at the front end connect the inlet to another gallery at the bottom of the liner. In between the top and lower passage in the block the coolant flows between the block & liners due to the thermos

All copyrights reserved by Mahindra & Mahindra I td

Scorpio -SC DC

















siphon effect. The water then goes to the cylinder head and from there to bottom of the thermostat. One external pipe from the back end of the block goes to the oil cooler. The return pipe form the oil cooler is connected to the inlet of the water pump.

#### Radiator & No loss tank -

The radiator cap controls the system pressure to 0.9 bar. Once the pressure exceeds 0.9 bar the cap lifts off the seat and the coolant is allowed to escape into a no loss tank.

As the engine cools down the system pressure falls and vacuum is formed . The vacuum valve in the radiator cap opens and allows the water from the no loss tank to go back into the radiator. Thus the system does not have any coolant loss during normal operation.

#### Water for HVAC -

The hot water at the thermostat housing is diverted to the heater unit, which is located in the passenger compartment for the HVAC function. The return from the heater is connected to the inlet of the water pump. It should be noted that a water valve near the heater/climate box controls the amount of the water, which enters the heater unit. The occupants determine the amount of the opening of the water valve. It will be full quantity when it is set is maximum heater mode and vary till the coldest mode where it will become nil as the valve will be fully closed















#### **Trouble Shooting -**

Before going into the specifics of the cooling system it is worthwhile to find out under which driving conditions the complaints is present.

Some of the causes are:

Prolonged /excess idling.
Very high ambient temperature
Slow traffic
Traffic jams
High speed
Steep Gradients.

To avoid overheating under such conditions it will be worthwhile to: Idle with the AC off .In case the temperature indicator needle is close to the red band.

Increase the engine idling speed.

Symptom	Causes	Remedial action
Noise	Fan shroud  1. Fan contacting the shroud	✓ Reposition the shroud and inspect the engine insulators.
	Water pump 1. Loose water pump impeller. 2. Water pump bearing worn/failure. 3. Loose mounting of pump	✓ Replace water pump.
	<ul><li>Belts</li><li>1. Belt loose</li><li>2. Glazed/stretched fan belt.</li><li>3. Rough surface on drive pulley.</li><li>4. Belt alignment</li></ul>	<ul> <li>✓ Tighten belt</li> <li>✓ Replace serpentine belt,</li> <li>✓ Replace pulley.</li> <li>✓ Check the belt alignment &amp; rectify.</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















	Alternator/Water pump  1. Alternator bearing failure  Belt tension mechanism 1. Idler pulley bearing failure 2. Idler mounting bracket failure. 3. Tension bolt failure.	<ul><li>✓ Replace idler bearing.</li><li>✓ Replace the idler bracket.</li></ul>
Coolant loss- over	boil Coolant  1. Overfilled recovery tank.  2. Insufficient coolant additive causing lower boiling points.  3. Additive deteriorated due to aging/ contamination.  4. Low coolant level. Hot shut down  1. Quick shut downs after a long and hot run.  Leakage's  1. Leaks due to loose hose	<ul> <li>✓ Replace the coolant</li> <li>✓ Add coolant</li> <li>✓ Allow the engine to run at idle for some time before stopping.</li> <li>✓ Find the area of leaks , replace hose or if necessary the clamp also</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC


















Coolant loss- boil over	filling of the cooling system. 4. Air trapped in system.	the core plugs. Repair or replace.  ✓ Flush radiator.  ✓ Purge the system.  ✓ Replace the cap/ pipe.  ✓ Replace the cap/ pipe.  ✓ Replace the cap.  ✓ Check the engine timing, FIP timing, injector pressure and also the
	Belt 1. Slipping belts	tappet clearance.  ✓ Adjust belt tension.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















	2. Belt failure	✓ Replace belt
	Water pump	
	Water pump shaft broken or damaged	✓ Replace water pump
	impeller. Thermostat	✓ Replace Thermostat.
	1. Faulty Thermostat.	✓ Replace hoses.
	Hoses. 1. Radiator hoses collapsed Fan	✓ Check the functioning of the VFD replace if required.
	1. Cooling fan not engaging.	<ul><li>✓ Clean the radiator fins.</li><li>✓ Remove the obstruction.</li><li>✓ Check the brake system.</li></ul>
	Air flow	
	1. Air flow reduced	
	to choked fins	
	2. Airflow reduced	
	due to	
	obstruction.	
	Vehicle	
	Brakes dragging.	
High Temperature	Improper indication	
Indication	1. Faulty sensor	✓ Replace the sensor.
	2. Faulty gauge	✓ Replace the gauge
Coolant entry into Crankcase or cylinder	1. Low cylinder head torque.	✓ Replace the cylinder head gasket, torque as per procedure.
	2. Faulty head	✓ Replace the cylinder
	gasket.	head gasket
		✓ Replace the affected part.
	3. Blow hole in	F 5 5.
	crankcase, head,	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















	liner	
Low Temperature	1. Thermostat stuck	✓ Replace thermostat.
Gauge Indication-	open	
Undercooling	2. Faulty sensor.	✓ Replace sensor.
	3. Faulty gauge.	✓ Replace gauge.
Coolant reserve system inoperative	1. Coolant level low	✓ Replenish coolant to FULL level.
	2. Leak in system	✓ Pressure test to isolate & repair.
	3. Overflow tube	✓ Remove clogging
	clogged or leaking.	
	4. Recovery bottle	
	vent blocked.	✓ Clean vent.
	5. Radiator cap	
	defective.	✓ Change the cap.
No coolant flow	1. Restricted return	✓ Remove restriction.
trough Heater Core	inlet in water	
	pump.	✓ Remove restriction or

hoses

valve

not

valve

or

# Care of the System -

Unless there is loss of coolant the coolant additive added is adequate for 80,000 of the vehicle.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Cooling system- 2.49 L Version 1, Aug 06





2. Heater

core.

housing.
5. Heater

controls

6. Heater

stuck.

functioning.

collapsed

restricted.

3. Restricted heater

4. Restricted outlet

in the thermostat







replace hose.

restriction.

✓ Repair controls.

✓ Repair or replace

✓ Remove restriction.

flash

or

✓ Remove







The recommended coolant additive is given in the <u>Recommended</u> Coolant section.

The fan belt tension should not fall below 550 N.

### In Car repairs -

Fan belt tension adjustment,
Fan belt replacement.
Fan Blade & the viscous fan drive removal & fitment.
Water pump removal.
Radiator removal

### Fan belt tension adjustment -



Loosen the center bolt



Adjust the tension by tightening the tensioner bolt.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC





















Tighten the center bolt.

Measure the belt tension using the clavis gauge.

If not found ok, repeat

# Fan belt Remove & Refit -



Loosen the belt tension-loosen the tensioner bolt.



Loosen the center bolt.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















Deactivate the belt tension by moving the belt tensioner away
Remove the fan belt. If required the fan shrouds can be removed and the belt removed.

# Fan Blade & viscous fan drive assembly removal -

Caution: Do not remove the fan belt before removing the nut.
Loosen the water pump nut.  Note that the threads are anticlockwise threads. Hence to loosen then the direction of rotation
has to be clockwise when viewed from front
The fan blade assembly and the VFD assembly can be removed together.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















# Water Pump removal -

Do not remove the cylinder block drain plate or the radiator drain cock with the system hot and pressurized. Serious burns from the splashing of hot coolant can occur.  Before draining the system. The system pressure has to be relieved. Holding the radiator cap with a rag slowly open the radiator cap. The water may splash upward causing injury  Remove the fan blade  Remove the fan belt
with the thermostat after removing the mounting bolts.  Remove the inlet and outlet hoses.
Remove the HVAC return line from the water pump inlet.  Remove the hose connecting the oil
cooler to the water pump.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC





















Remove the water pump assembly after removing the mounting bolts.



While assembly, ensure that the "O" ring is seated securely and does not fall down.

#### Radiator Removal & Refitment -



Do not remove the cylinder block drain plate or the radiator drain cock with the system hot and pressurized. Serious burns from the splashing coolant can occur.

Before draining the system. The system pressure has to be relieved. Holding the radiator cap with a rag slowly open the radiator cap. The water may splash upward causing



Remove the radiator inlet and outlet hose

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Cooling system- 2.49 L Version 1, Aug 06









injury













Remove the inlet and outlet hose for the intercooler.



Remove the fan shroud.



Remove the condenser mounting bolts.



Remove the radiator mounting bolts and remove the radiator along with the pipe connecting it to the no loss tank.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC





















#### <u>Dismantling & Assembly of the Cooling System</u> -

- Water Pump
- Viscous Fan Drive

#### CAUTION

Do not remove the radiator draincock or the Engine coolant plate drain with the engine in hot condition.

Always remove the pressure on the system by removing the radiator cap before undertaking any work on the cooling system.

If the coolant is not contaminated then collect the coolant in a clean container so that it can be reused. Replace coolant as per recommendation

# Water pump -

A centrifugal water pump is used to circulate the coolant through the water jackets, cylinder head, hoses and radiator. The water pump is belt driven by the engine main drive pulley. It ratio of pulley diameter ensures that the water pump rotates 1.25 times the engine speed.

The water pump impeller is pressed onto the shaft. The shaft is supported on two bearings that are integral to the shaft.

The water pump seal is located between the impeller and the housing. The housing has a small hole to allow the seepage to escape. That also acts as an indication point if the water pump seal fails.

Water pump removal & Refitment.

The water pump is not serviceable and has to be changed as an assembly.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















#### **Viscous Fan Drive Operation -**

The viscous drive unit for the engine-cooling fan provides a means for controlling the speed of the fan relative to the temperature of the engine. The viscous fan unit is a type of fluid coupling, which drives the fan blade by means of silicone fluid



There are two main components of the viscous fan drive: input (drive member), which consist of a threaded shaft passing through a bearing into the clutch plate and secured to the water pump. The output (driven) member comprises of the main body to which the fan is attached, with the temperature sensing mechanism (bi- metal coil) and pump plates.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















The fan drive has to be engaged only periodically, between 5 to 10% of the normal operating conditions because the rest of the time the vehicle cools itself by ram air-cooling.

To engage and disengage the fan drive the bi metal coil senses the air temperature behind the radiator. When a pre determined temperature is reached, the coil opens a valve, which allows the fluid to enter the drive area and due to centrifugal forces circulate to the annular drive area



There are two sets of annular grooves. , One in the drive clutch and the other in the drive body, a specific clearance being provided between two sets of grooves. When this clearance is filled with viscous fluid a shearing

All copyrights reserved by Mahindra & Mahindra I td

Scorpio -SC DC

















action caused by the speed differential between the two drive components, transmit the torque to the fan. The fluid is thrown to the outside of the unit by the centrifugal force from where it is recirculated to the reservoir via the pump plate adjacent to the drive member.

If the engine sped is increased the amount of slip will also increase to limit the maximum fan speed.

When the air temperature from the radiator drops sufficiently, the bi metal coil closes the valve and prevents fluid entering the drive area. The fluid that is in the drive area will gradually pump out into the reservoir and the fan will return to an idle condition

#### Checking the VFD -

This procedure will only give an indication that the fan is cutting in and out, but will not be able to check the accuracy of the cut in temperature.

Depending on the level of the test equipment there are several ways to check the if the fan is working correctly.

# Using a non-contact tachometer

- 1. Run the engine at idle without any load for approximately 3 minutes, for example at 2000 rpm, observer the fan drive speed. In the disengaged mode the fan speed will be approximately 800 rpm. By running for 3 minutes it will ensure that the fan drive has pumped out the silicone fluid into the reservoir and that the fan drive will be in the cut out (idle)
- 2. Either
  - (a) Blank the radiator by using a sheet of cardboard, which has a 15-cm hole, cut out of in line with the center of the fan drive. This will allow a flow of air on the bimetal coil and the cardboard will allow the radiator to heat up quickly.

Keep a check on the vehicle temperature gauge and let the water temperature rise to about  $105^{\circ}$ C. this will ensure that the fan drive will engage

**(b)** Using a commercial hot air blower, which will provide a hot air flow of at least 75°C, direct the air on to the centers of the fan drive through

All copyrights reserved by Mahindra & Mahindra I td.

Scorpio -SC DC




















the radiator. Keep the hot air on for several minutes. This will cut the fan drive in, and the fan speed will increase. It is important that only a powerful blower is used so that the hot air should reach the fan drive after going the radiator at the correct temperature.

3. Once the fan drive has become engaged by either method (a) or (b). Check the fan speed with the non-contact tachometer. At 2000 rpm input speed the fan speed should be 1800 rpm.


#### Testing without a non-contact tachometer

4. Use the same method explained in step 2, but this time listen to the noise level generated by the fan. With the fan in the idle condition the noise level should be very low, however when the fan speed increases in the engaged mode there will be a significant roar from the fan. This will clearly indicate if the fan drive is working.

If the fan drive fails to engage during these tests, there is something wrong with the VFD (Viscous Fan Drive). The unit should be replaced.

While returning the failed unit (to Plant for vehicles under warranty) take care to see that the unit is packed with the sensing coil facing down and sent in the same way. If this is not observed then the silicone fluid will flow down to bearing, damaging the bearing and also making it impossible to do any investigation.

# <u>Viscous Fan Drive removal</u> -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















Remove the shroud.



Loosen the clutch fan nut.

Note that the threads are anticlockwise threads. Hence to loosen then the direction of rotation has to be clockwise when viewed from front



Note: The VFD assembly should be kept in 2 positions only.



As far as possible - in vertical plane. If in horizontal then the bimetallic strip should be facing down.

If stored in horizontal position resting on the nut face then the silicone fluid will flow down to the bearing assembly and result in contamination of the bearing's lubricant.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















### Serpentine Poly V Belt -

The 2.49 L engine is having Poly V belt drive. The layout of the belt and the pulley for the gear drive engine is given above.

The fan belt tension has to be measured between the A/C Compressor pulley and the alternator pulley.

The accessory belt layout for the Chain drive engines is given below.



The belt must be routed correctly.



The main drive pulley can be assembled in either direction, however the front end is identified by holes drilled for balancing (this are not thorough holes). If assembled wrongly it will cause misalignment by 5to 6 mm

Belt Diagnosis.

When diagnosing serpentine accessory drive belt,

All copyrights reserved by Mahindra I td

Scorpio -SC DC



















Small crack that run across the ribbed surface of the belt from rib to rib are considered normal.

### Cracks running along a rib are not normal

The correct belt tension is required to ensure optimum performance of the belt.

Do not apply any external means to reduce noise. Application of oil will reduce the belt life.

A detailed drive belt analysis is given below.

Symptom & condition	Possible reasons	Correction
Rib chunking (One or more ribs has separated from belt body)- Chunking happens when several cracks in one area of rib move parallel to the cord line.		<ul> <li>✓ Remove foreign objects from pulley grooves. Replace belt</li> <li>✓ Replace belt.</li> <li>✓ Clean pulley, replace if required.</li> </ul>
Piling- happens when the material is sheared off the undercord and builds up in the groove.	pulleys 3. Worn out pulleys	<ul><li>✓ Adjust tension</li><li>✓ Correct the alignment.</li></ul>
Rib or belt wear.	<ol> <li>Pulley or pulley's mis aligned.</li> <li>Abrasive environment</li> <li>Rusted pulley's</li> <li>Sharp or jagged pulley groove tips.</li> <li>Poor surface finish.</li> </ol>	<ul> <li>✓ Correct the alignment.</li> <li>✓ Clean pulleys- replace if required.</li> <li>✓ Change pulley.</li> <li>✓ Replace belt.</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















#### **Tooth shear** 1. Low belt tension ✓ Correct the tension. 2. Seizure of driven ✓ Replace belt. part. ✓ Align pulleys 3. Misalignment. **Tooth Wear** 1. Incorrect tension ✓ Adjust tension. √ Change pulleys 2. Worn out pulleys 1. Belt ✓ Replace belt. Longitudinal Belt has mis-✓ Change pulley. from cracking (Cracks tracked between two ribs.) pulley groove. 2. Pulley groove tip has worn out the rubber to tensile member. Belt slips 1. Belts ✓ Adjust belt tension. slipping ✓ Clean pulleys. because of insufficient tension ✓ Replace failed the 2. Belt components. or pulley subjected ✓ Replace belt to substances that reduce the belt life ( oil, grease, ethylene alcohol) 3. Driven component's bearing failure. 4. Belt hardened and glazed from heat and excessive slippage. Groove jumping 1. Belt tensions ✓ Adjust belt tension. ✓ Replace pulleys. belt does either too high or not ✓ Clean pulleys. correct too low. maintain 2. Pulleys not within ✓ Correct the alignment position on pulley) design tolerances. ✓ Replace belt. 3. Foreign objects in groove. 4. Pulley

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

















	misalignment, 5. Belt cordline is broken.	
Belt broken	<ol> <li>Excessive tension.</li> <li>Tensile members damaged during installation.</li> <li>Severe misalignment.</li> <li>Bracket pulley or bearing failure.</li> </ol>	<ul> <li>✓ Adjust belt tension</li> <li>✓ Correct the alignment</li> <li>✓ Replace the failed component.</li> </ul>
Noise Objectionable squeak, squeal rumble heard or felt while drive belt is in operation	<ol> <li>Belt slippage</li> <li>Bearing noise</li> </ol>	<ul> <li>✓ Adjust belt.</li> <li>✓ Replace the defective bearing.</li> <li>✓ Adjust alignment.</li> <li>✓ Use the correct belt.</li> <li>✓ Vary belt tension within specifications.</li> <li>✓ Replace belt.</li> </ul>
Tensile failure	<ol> <li>Tension sheeting contacting stationary object.</li> <li>Excessive heat</li> </ol>	<ul> <li>✓ Correct rubbing condition.</li> <li>✓ Replace belt.</li> <li>✓ Correct the tension.</li> <li>✓ Replace pulley.</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC




















	splice has fractured.	
Oil contamination	1. Oil leaks.	✓ Correct the oil leak condition.
Cord edge failure ( Tensile member		<ul><li>✓ Adjust tension.</li><li>✓ Remove the stationary</li></ul>
exposed at edges of	_ · · · · · · · · · · · · · · · · · · ·	objects fouling.
belt or separated	, ,	✓ Replace pulleys.
from Belt body)	tolerance.	✓ Replace pulley.
	5. Insufficient	
	adhesion between	
	tensile member & rubber matrix.	

# Rib chunking -




















# Piling -

### **Tooth Shear**



Tooth wear





All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC


















## Tensile failure



Oil contamination



Cord Edge failure



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















# **Specifications** -

Radiator capacity	2.15 liters
Cooling system capacity	9.3 liters
Coolant	GLYSANTIN G45-23
Ratio	30%
Coolant to be added after	2.79 liters
draining/flushing	
Radiator pressure	0.9 bar
Viscous Fan Drive	75°C of air temperature at
- fan starts at (For reference	Sensor
only)	Input speed - 3600 rpm
Viscous Fan Drive	35°C of air temperature at
- fan stops at (For reference	Sensor
Only)	Input speed - 1300 rpm
Input speed of Fan pulley	1.30x Engine speed.
No of fan blades	11
Fan blade size	370 mm
Fan Belt tension	New installation 800 Newton
	Stabilized 580 Newton
Fan Belt tension-Minimum	550 Newton
Fan Belt tension	New installation -165 ± 2 Hz
	Stabilized -134 Hz Min
Fan Belt tension- Chain Drive-	New installation -170 ± 5 Hz
Gates make	Stabilized -140 Hz Min

# <u>Tightening Torque's</u> -

Bolt location	Torque in Nm	
Viscous Fan clutch nut	40-50	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

















Emission Control system - 2.49 L Turbo DI

**Contents** 

**Description** 

**Trouble Shooting** 

Care of the System

**Checking the System.** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















# **Description** --

The 2.49 L Turbo intercooled DI engines meet the Euro II emission norms. To control the NOx an Exhaust gas recirculation is used.

Overall, two systems are used.

Exhaust Gas re circulation.
Closed crankcase ventilation

Working Principle of the Exhaust Gas Recirculation -



During acceleration and in higher loads the engine generates high combustion temperatures. The high combustion temperatures increase the NOx generation. The higher percentage of NOx generated in the combustion chamber come out through the tail pipe in the atmosphere.

To reduce the amount of NOx coming through the tail pipe the EGR system adds exhaust gases into the fresh air that is going into the combustion chamber. Since the exhaust, gas is already burnt hence when mixed with

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















fresh air acts an inert gas. Thus when the exhaust gas mixed with fresh air enters the combustion chamber. The role it does is that it reduces the amount of oxygen available for combustion. The net effect is that it reduces the peak combustion temperatures. This results in lower amount of NOx being generated.

To control the amount/percentage of exhaust gases to be circulated back to the combustion chamber an ECU is used. The ECU monitors the coolant temperature, attitude, engine speed, and accelerator pedal position. Based on the above parameters the ECU operates a switch that in turn controls the amount of vacuum going to the EGR valve. The amount of vacuum applied controls the lift of the EGR valve.
















Main Menu | Index

















The inputs of the engine speed (from the alternator W terminal); Throttle position (from the potentiometer.) is fed in one map. Another map uses the throttle position and correlate in terms of the acceleration. The third map uses the water temperature. The inputs from the 3 maps are added together to give an input to the EGR pressure modulator. The EGR valve lift feedback is taken and the signal to the modulator suitable increased or decreased.

At the same time it has a set point that if the water temperature is less than  $25\,^{\circ}$  C or more than  $95\,^{\circ}$ C. Then the EGR will not be operated. Also if the water temperature is less than  $30\,^{\circ}$  C then the cold start advance (KSB) will be in operation.

The acceleration map ensures that if the rate of acceleration is above a certain level then the EGR will not operate. This feature allows full engine power to be available during acceleration (say during overtaking).

The EGR controller is located just below the co driver's seat.

The vacuum connections are shown below.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















#### Working principle of Crankcase Ventilation System -

The ventilation system is closed ventilation type. A hose connects the oil sump assembly to the rocker cover. This hose balances the gas pressure in the rocker cover and sump. The second hose goes from the rocker cover to the oil separator. This hose also has a coarse mesh, which trap the bigger particles.

The vapors with the oil particle enter the separator and due to the centrifugal action are again separated. The vacuum after the air cleaner acts on to the top of the diaphragm. The balance of the vacuum against the spring and the vapor pressure controls the amount of the oil going to the sump.

Certain amount of oil will be carried from the oil separator to the Air inlet hose, which is normal. However if it is excessive please look for all the causes mentioned in the high blow bye.

















# <u>Trouble Shooting</u> -

Symptom	Causes	Remedial action
Engine does not give full power.	<ol> <li>Gas leak between EGR pipe joints.</li> <li>EGR pipe leak.</li> <li>EGR valve improper functioning.</li> <li>Vacuum hose crack, loose, fallen off</li> </ol>	<ul> <li>✓ Change the gasket or the hose.</li> <li>✓ Change the pipe.</li> <li>✓ Check the EGR using the blink codes.         Proceed appropriately.     </li> <li>✓ Ensure vacuum connections at vacuum modulator, reservoir, and alternator.</li> </ul>
Noisy engine & high smoke	<ol> <li>Cylinder head gasket defective.</li> <li>Worn out or damaged valve seats.</li> <li>FIP timing.</li> <li>Leaking injector holder.</li> <li>Leakage at EGR Valve flange face,</li> </ol>	<ul> <li>✓ Replace the cylinder head gasket.</li> <li>✓ Lap the valve seats or regrind.</li> <li>✓ Check the FIP timing.</li> <li>✓ Tighten the injector holder. (Check if the injector holder of the BS 2 does not have the BS1 holder.)</li> <li>✓ Confirm &amp; check -Gasket condition - Bolt torque.</li> </ul>
Black smoke.	exhaust manifold and EGR pipe end. 1. EGR valve stuck open	Check the EGR valve- using the blink code & confirm.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Excessive oil	1. Cracked vacuum	✓ Check the vacuum line
consumption	line hoses	from the alternator to
	<ul><li>2. Restriction in crankcase breather.</li><li>3. Damaged oil</li></ul>	FICD and the EGR valve (for BSII)- check for leaks, crack. Replace cracked hoses.
	separator  4. Bend/kink in any of the oil return pipe's/vacuum hoses.	<ul> <li>✓ Locate &amp; remove restriction.</li> <li>✓ Check the crankcase ventilation &amp; rectify.</li> <li>✓ Replace the oil separator</li> <li>✓ Change the vacuum hoses.</li> <li>✓ Remove the bend or kinks.</li> </ul>

#### Care of the System -

To meet the emission norms it is essential that the Fuel system, Air intake system & cooling system be maintained as per the schedule . For details refer to the particular section

Generally it is not appreciated that if the engine is running below the optimum temperature (happens when thermostat is removed then tailpipe emissions in particular the particulate increases (up to 30%). Similarly a wrong grade or poor quality of fuel increases the emissions. A blocked air cleaner or restriction in intake system increases the emissions

## Oil separator system -

Check the hose connection at every 10,000 Kms for cracks, aging and leaks.

### EGR -

On vehicles fitted with EGR system the following additional points check have to done during scheduled maintenance.

• Check for any exhaust gas leakage through sealing faces, EGR pipe. Formation of any black soot indicates leakage.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















- Check the vacuum hoses for any leaks, cracks.
- Retighten all nuts and bolts as per the recommend torque.
- Check blink codes every 10,000 kms.

While doing the tappet clearance, in case of vehicle fitted with EGR system ensure that the EGR pipe is not bend or overstress the pipes, elbow.

If the pipes are removed then it is essential that while fitting back new gaskets is used. Do not open the pipe from one end only; it will cause the pipe to twist. If the EGR pipe has to be removed, then open from both the ends.

The ECU/controller controlling the EGR operation is an electronic device. Hence it is prone to get damaged if spikes are generated in the system.

It is advised that the following precautions be taken.

- ◆ If any welding work is being carried out on the vehicle then the battery terminals are removed.
- Similarly, the practices of shorting the battery to check the battery have to be avoided. (It can cause a spike.).
- ◆ The practice of changing battery with a running engine is also not acceptable. Again, the resultant spike can damage the controller beyond repairs.

### EGR Valve -

Remove the EGR valve and check it valve-sticking, deposition of carbon etc. If excess carbon deposits and sticky valve noticed then it should be cleaned with a suitable solvent, so that the correct valve seat is ensured.

After cleaning the valve blow air from the bottom side of the valve and check for any leakages.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















To check for the functioning of the EGR valve apply vacuum on the vacuum connection of the EGR valve. The lift of the valve at the required vacuum should be achieved.

#### EGR Pipe -

Remove the EGR pipe and check for gas leakage, damages etc. Clean the gasket seating area from any carbon deposits, burrs etc. Spray WD 40 rust cleaning spay on the nut.

To check the pipe for any leakage's, close one end of flange and from other end blow air at two bars. Dip the pipe in water and observe if any leakage is observed. If any leaks are observed then the pipe has to be replaced. Do not attempt to weld/ seal the leakage joint

#### EGR Solenoid switch -

The solenoid switch does not require any maintenance. For any damage replace the component.

#### **EGR ECU -**

Does not require any maintenance.

However, like any ECU care has to be taken that if any welding work is being carried out on the vehicle then the battery terminals are removed.

Similarly, the practices of shorting the battery to check the battery have to be avoided. (It can cause a spike.). The practice of changing battery with a running engine is also not acceptable. Again, the resultant spike can damage the controller beyond repairs

## **Checking the System -**

### **EGR System**

- Checking the system by using the blink codes:
- ✓ Procedure
- ✓ Blink code details

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















- Check the EGR Valve
- Checking the EGR pipe.

#### Procedure for checking the failure /system by blink codes is:

- ◆ Connect an external 2 W bulb to the appropriate connector.
- Switch the ignition switch to ON position.
- Wait for minimum 3 minute.
- ♦ Start the engine and run at idle.
- ◆ If the light is continuously on then the system is defect free and in good condition.
- ◆ If the lamp is blinking, observe the blink and compare it with the defect chart.



#### Caution:

Use of bulb higher than 2W can damage the ECU

Observe the bulb for a minimum of 10 second

Observe the lamp for the blink codes.

Observe the light for at least 10 seconds

#### The blink codes details are:

Sl. No.	Parameter	Error type	Blink code
1	EGR ECU	No errors	Lamp ON
			continuously
2	EGR ECU	No ECU supply /	No blink
		ECU defective	
3	Throttle sensor	No Signal	On 2s/Off 2s

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















Automotive Secto	I		
		Consor not	On 10/0ff Fc
		Sensor not connected /	On 1s/Off 5s
		Setting error	
4	Temperature sensor	Open / Short	On 5s/Off 1s
5	EGR Valve	No Signal /	(On 0.5s Off 0.5)* 2
J	sensor	Sensor not connected	cycles than Off 3s
		Valve not lifting	(On 0.5s Off 0.5)* 3 cycles then Off 3s
		Valve not closing	(On 0.5s Off 0.5)* continuously.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Emisson control 2.49 L Version 1 Aug 06

















Fuel System- 2.49 L

#### **Contents**

- Description
- Trouble Shooting
- Care of the System
- In Car Repairs
- Dismantling ,Inspection & overhaul of the Fuel Injection Equipment.
- Specification
- <u>Tightening Torque's</u>























All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















The fuel system can be divided into following subgroups.

- Fuel filling.
- Fuel supply from tank to FIP
- FIP &injectors including the High pressure pipes.
- Return line from FIP to tank

The fuel is filled from the opening provided at rear left. The fuel cap is ventilated and threaded type. The cap is locked in place when further turning action result in clicking of the ratchet.

When filling the tank, the air entrapped inside is vented by the vent tube, which is connected at the mouth of the inlet pipe. The venting is done from the highest point in the fuel tank. The fuel tank has a capacity of 58 liters.

During operation the fuel pump due to the vacuum created by the internal feed pump the fuel is sucked through the Primary fuel & Secondary filters, to the fuel pump.

The rotary pump, pressurizes, meters and distributes the correct amount of fuel to the injectors through the high-pressure pipes.

The excess amount of fuel from the FIP and the injectors is sent back to the Fuel tank.

The entire length of the fuel tank is protected at the bottom by a stoneguard.

















# **Trouble Shooting -**

Symptom	Causes	Remedial action
Engine will not start	1. Clogged fuel filter/	✓ Change fuel filter
& emit black smoke	fuel lines	✓ Check fuel supply line.
	2. Defective injectors	✓ Calibrate injectors.
	3. Engine timing.	<ul><li>✓ Check engine timing.</li><li>✓ Replace FIP,</li></ul>
	4. Defective FIP	
Noisy engine & black smoke.	1. Improper injection timing.	✓ Check & correct the Timing.
	2. Seized injectors.	✓ Replace injectors.
Engine speed falls		✓ Change fuel filter
off.	fuel lines	<ul><li>✓ Check fuel supply line.</li><li>✓ Check the supply to</li></ul>
	2. Solenoid supply	solenoid and the
	intermittent or loose	solenoid.
	3. Defective FIP	✓ Rectify the FIP.
Engine does not give	1. Clogged fuel filter/	✓ Change fuel filter
full power.	fuel lines	✓ Check fuel supply line.
	2 Inication number	✓ Check & correct timing.
	2. Injection pump	✓ Replace filters.
	timing. 3. Defective	<ul><li>✓ Calibrate injectors</li><li>✓ Plug the leaks, replace</li></ul>
	injectors.	hose or clip if required.
	4. Air leak in pipe -	✓ Replace the hose or
	manifold to FIP	tighten
	5. Return pipe	
	blocked.	the correct torque.
	6. Defective FIP	✓ Locate the kink/block
		in return pipe and rectify.
		✓ Repair or replace the

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC















Automotive Sector		
		FIP.  ✓ Check the pipe, washer & rectify.
Irregular idling	<ol> <li>Solenoid supply intermittent or loose</li> <li>Leaking HP unions.</li> </ol>	or replace solenoid ✓ Tighten the unions or replace the Highpressure pipes.
	3. Air entering fuel system.	<ul> <li>✓ Replace all the banjo washers and check for the cracks in fuel line particularly from Tank to FIP</li> <li>✓ Adjust the idling stop.</li> <li>✓ Replace FICD.</li> </ul>
	<ul><li>4. Idling stop out of adjustment</li><li>5. Defective FICD.</li><li>6. Defective FIP</li><li>7. Wrong High</li></ul>	<ul> <li>✓ Repair or replace FIP.</li> <li>✓ Replace with original pipes.</li> </ul>
Engine stalls when accelerator pedal is released	pressure pipes.  1. Improper anti stall setting.  2. Water contamination causing partial seizure of FIP	<ul> <li>✓ Rfer to idling setting procedure. Set on vehicle.</li> <li>✓ FIP overhaul.</li> <li>✓ Find the cause of water contamination &amp; take corrective action</li> </ul>
Black smoke.	<ul><li>3. Defective injectors</li><li>4. Improper FIP timing</li><li>5. Defective FIP.</li></ul>	<ul><li>✓ Check injectors.</li><li>✓ Correct the timing</li><li>✓ Rectify or replace FIP.</li></ul>
White smoke.	<ol> <li>Clogged fuel filter/ fuel lines</li> <li>Improper FIP</li> </ol>	✓ Check & correct timing. ✓ Check & correct KSB

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

















Automo	tive	Sec	tor

	timing. 3. Cold start advance not working.
Engine will not start	<ol> <li>Weak battery</li> <li>Corroded or loose battery connection</li> <li>Faulty starter.</li> <li>Defective FIP's solenoid/ no supply to solenoid.</li> <li>✓ Check the battery specific gravity.</li> <li>✓ Clean &amp; tighten battery connections.</li> <li>✓ Repair starter.</li> <li>✓ Check connection or replace solenoid</li> </ol>
	<ul><li>5. Improper earthing.</li><li>✓ Rectify earthing.</li><li>✓ Replace FIP</li></ul>

#### Care of the System -

The fuel injection system depends on supply of clean diesel fuel for the proper functioning of the fuel system.

To ensure that FIP receives clean fuel all the times it is advisable that the fuel filters are replaced at the specified intervals.

Primary should be changed at 10,000 Kms and the secondary at 20,000 Kms. If the operating conditions are poor then reduce the change interval. Both the fuel filters should be of paper and coil type.

It should be noted that replacement of both the filters at the same time has to be avoided.

It should be understood that when the filters get choked then the filtering efficiency that is the size of particle they are able to stop improves. However, if it gets fully choked then the flow of the fuel is very less and inadequate at higher speed. Hence if only one filter is changed at a time then the fuel flow is also adequate and maintains a higher filtering efficiency. The working clearance of the FIP components are in order of few microns, hence the importance of the above procedure is high.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

















The internal components of the Fuel Injection pump depend on the lubricating properties of diesel for lubricating them. Hence, if water is present in the fuel then lubrication between the component break down and there is seizure. The commonly affected components tend to be either the distributor head & the piston or the control sleeve getting jammed.

To avoid such an occurrence, it is recommended that at every 5000 kms water be drained from the bottom of the filter bowls. During monsoons, the frequency can be increase to every fortnight.

The procedure, which should be followed, is:

- Loosen the drain bolt.
- Loosen the filter mounting bolt.
- Drain the water at the bottom of the bowl.
- Close the drain bolt and then the mounting bolt.

In a Turbocharger engine, fuelling is dependent on the boost being sensed by the LDA unit hence it is essential that at **each service the hose connecting the inlet manifold to LDA unit be checked**. If in doubt, replace the hose. Any air leak in this pipe or joint will result in the FIP's delivery not matching the boost being achieved and will show as reduced power delivery.

The FICD unit is actuated by vacuum whenever the HVAC system is switched on and ensures that the idling rpm stays within the specified band. Irregular idling when AC is switched on will indicate any leak in the vacuum line. Hence checking the vacuum pipes from the alternator to the FICD unit should be done at each service.

## In Car Repairs -

The In Car repairs which can be carried out are: Removal & Replacement of the fuel filers.

Draining the water from the fuel filters.

Removal & refitting injectors.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

















Removal & refitting the FIP.

Removal & replacement of the accelerator cable.

Removal of the fuel tank.

# Removal & Replacement of the fuel filers -

Loosen the filter-mounting bolt.

Remove the filter
While fitting back, fit the filter with a
new O ring.



For bleeding the system, loosen the high-pressure pipe unions and use the hand primer.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















# **Draining the water from the fuel filters** -



Loosen the drain bolt.



Loosen the filter mounting bolt.

Drain the water.

Tighten the drain bolt and then the filter mounting bolt



For bleeding the system, loosen the high-pressure pipe unions and use the hand primer.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06


















## **Automotive Sector** Removal & refitting injectors -



Loosen the high-pressure pipes from both the FIP end & injectors.



Avoid loosening only at one end as it can cause strain in the pipes, while removing the injectors

Remove the leak off pipe from injectors to FIP overflow bolt.



Remove the injector clamps.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06























Remove the injectors.



While refitting, the injectors use a new washer between the injector & cylinder head. (Thickness of washer should be 3mm)



Avoid two-injector washer. using Normally it tends to happen if the older washer is not removed and has got stuck to cylinder head.

It will change the injector tip height to change and affect combustion.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06


















# **Idling Setting** -



All copyrights reserved by Mahindra & Mahindra Ltd


Scorpio -SC DC


















The idle setting comprises two Steps:

A. Low idle setting.



B. Fast Idle setting/ Idle setting with AC on.

## A. Low idle setting -



Observe / record idling rpm in as is condition.

Ensure LFG lever is resting on idling screw Gap between LFG lever and clamp on cable to be approx. 1.0 to 1.5 mm.

If LFG lever is resting on clamp, release the clamp and check for Idling rpm again.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















Mahindra	
Automotive Sector	


If idling rpm is n spec.


Set AC idling as defined in procedure 'B'

Go to procedure B

If idling is not in spec. adjust the idling by following method

Unscrew anti-stalling fully such a way that this has no effect on idling rpm and idling is controlled by normal idling screw.





**Unscrew Fast idle** screw to ensure it doesn't stop the movement of LFG lever.



















Set the idling to 845 - 850 rpm approx. by adjusting idling screw.


Screw in: increases rpm Screw out: reduces rpm



Re set the anti-stalling screw to get idling rpm of 855 - 860 approx.



Idling set with anti stalling should be slightly more then normal idling to ensure anti stalling screw is in proper position



Set or ensure the gap between clamp and LFG screw, lock it at that position.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















Set Fast Idling as explained in
procedure 'B'

# B. Fast idle setting./ Idle setting with AC ON -

	Ensure Idling is with in the specification
	Ensure gap is maintained between LFG lever and clamp
	Switch on the AC.
	When AC is on vacuum supply will go to PLA unit, which activates the LFG lever and pulls in lever so that it butts against fast idle screw.
	Ensure that the LGF lever is pulled.
1	

Measure engine rpm.



If rpm is out of specification adjust the fast idle screw to get required rpm.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC



















Screw in : Decrease rpm , Screw out: Increase idling rpm.
Caution: The fast idle screw movement effect on Engine RPM is the reverse of the idle screw movement/
With AC on (load on engine) fast idle rpm should be between 850 - 950
Lock the fast idle screw in that position.

## Removal & refitting the FIP -



Remove tappet cover.



Bring the 1<sup>st</sup> cylinder in compression.

(To confirm the first cylinder TDC position remove the 1<sup>st</sup> cylinder injector, insert the MST and the dial gauge. Check by the dial if the piston is in TDC)

All copyrights reserved by Mahindra & Mahindra Ltd


Scorpio -SC DC












To lock the FIP

Loosen the timing lock bolt. Move the lock plate away & then tighten the Timing lock bolt so that it locks the camshaft.





Remove the fan belt.

Remove the FIP connections and fuel supply.



Remove the injector pipes.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06













**EXIT** 





Automotive Sector	
	Remove the FIP mounting bracket
	Remove the front cover in the timing cover.
	Loosen & remove the FIP locking nut. And then the 4 mounting nuts on the flange and the bracket at the rear,
CAUTION	While fitting back the FIP. The plunger travel of the FIP has to be checked. Remove the center bolt at the back. Mount the dial gauge using the special tool.
	Caution: After fitting back the FIP, loosen the timing lock bolt. Fit the plate and then retighten .So that the camshaft is free. Failure to do so will damage the FIP's camshaft when the
The aleman to the SIR! SIR!	engine is rotated.
The plunger travel of the FIP is	5
1.2 mm	

# Removal & replacement of the accelerator cable -

Remove the accelerator cable from pedal end.
Remove the cable end from the FIP lever end.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1 , Aug 06



















Do not lubricate the accelerator cable. If the movement is found sticky. Please rectify the routing or replace.

Lubricating will not remove the root cause and will only aggravate the complaint as dust will stick and cause it to get jammed.

Further these cable are having EPDM coated and do not require any external lubrication.











**EXIT** 





# Removal of the fuel tank-

9

Disconnect the fuel tank supply hoe and the vent hose.

Disconnect the fuel supply and return hoses



Disconnect the fuel gauges, tank unit electrical connection.



Remove the skid plate.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06













**EXIT** 







### Remove the mounting 5 no bolts.

Lower transm	the	fuel	tank	on	to	the
transm	ission	jack				
The a	assem	bly	proced	ure	is	the
reverse	of th	is.				

### Dismantling, Inspection & overhaul of the Fuel Injection Equipment --

The FIP and injectors are high precision equipment.

It is recommended that they are serviced in the OEM' dealers or their authorized workshops only. Where the necessary equipment for dismantling, testing and calibration is available along with trained personnel.

The 2.49 L is fitted with MICO BOSCH's Fuel pump and injectors.

The high-pressure pipes also form an integral part of the injection system. Hence, the use of non-genuine pipes whose lengths or thickness or inner diameter may vary from the original will adversely influence the performance. Any one of the parameter changes affects the fuel being injected into cylinder in terms of the quantity and timing.

The Injector sealing washer also forms an integral part of the injection system. Hence, the use of non-genuine washers whose thickness or inner diameter may vary from the original (3 mm thick) will adversely affect the performance.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06



















# **Specifications** -

	Euro II
FIP	0460 414 240
Static timing	1.2 mm plunger lift @ TDC
Overflow valve	φ 0.75 mm
Features in FIP	
LDA (Increases the fuelling according to	Yes
boost)	
FBB( Lock timing bolt)	Yes
PLA unit( Controls the idling to the	Yes
specified band when the AC is switched	
ON)	
LFG (Avoids the fuelling to become zero	Yes
during gear changing thus improving	
driveabiility.)	
KSB ( Cold start advance)	Yes
Determinanta (In word to give the input	Vac
Potentiometer ( Is used to give the input	Yes
of the engine load to the controller for	
EGR)	F
Injector Identification	•
	Red colur ring 250+8 bar
NOP (Nozzle Opening Pressure)	
Specification (No of holes x hole dia x	7x0.203x150°
Spray angle Nozzle holder	E002 C70 EEE 1200 box
Nozzle notder Nozzle	F002 C70 555, 1200 bar
113 == 13	F002 C40 532 (DSLA 150 P 1093) 6 x 1.8 x 480
High Pressure pipe	0 X 1.0 X 40U
( OD x Thickness x length)	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio -SC DC

Fuel System 2.49 L Version 1, Aug 06

















# <u>Tightening Torque's</u> -

Location	Torque
FIP Lock screw	12.5±2.5 Nm
All M5 nuts/ Bolts on FIP	2~3 Nm
High Pressure Pipe Nut	25±3 Nm
Injector holding clamping stud.	25±3 Nm
Injector Overflow pipe Banjo nut	5-7 Nm
LDA hose on FIP	10-15 Nm
LDA hose banjo on manifold	10-15 Nm
Fast idle screw on FIP	10-15 Nm
FIP Inlet & Outlet Banjo	15~20 Nm















## Clutch

**General** 

Care of the System

**Trouble Shooting** 

**In Car Repairs** 

**Clutch Actuation Mechanism** 

**Clutch overhaul** 

**Inspection** 

**Specification & Wear Limit** 

**Tightening Torque's** 

**Lubricant** 

**List of the MST** 



















#### General

The clutch disc is a single, dry type with cushion springs in the hub. The clutch disc's friction material is riveted to the hub.

The clutch cover is a diaphragm type with one-piece construction. A 240-mm clutch disc is used.

In the engaged position (when the clutch pedal is not pressed), the diaphragm spring of the clutch cover assembly holds the clutch pressure plate against the clutch disc. This enables the engine torque to be transmitted to the input shaft of the gearbox, without any slip / loss.

The clutch is hydraulically actuated with self-adjusting features. The complete actuation system comprises of a clutch master cylinder with integral reservoir. The master cylinder is connected to the clutch actuation or the slave cylinder by hydraulic pipe. The travel of the push rod results in linear movement of the release bearing through a release fork pivoted on a ball in the clutch housing.

The clutch release bearing pushes the diaphragm spring center towards the flywheel. The diaphragm spring pivots at the fulcrum, relieving the load on the clutch plate. Steel spring straps riveted to the pressure plate cover pulls the pressure plate away from the clutch disc. When the clamping load on the clutch plate is relieved it slides on the splines of the input shaft away from the flywheel thus disengaging the engine torque from the input shaft & enabling the gears to be changed.

For vehicles with Rev 116 engine the release mechanism is different. The clutch actuation mechanism consists of a slave cylinder directly acting on a release bearing. For further details refer the clutch actuation.

# Care of the System -

While topping up use the recommended fluid conforming to DOT 3 specifications only. Avoid mixing different brands.

The clutch fluid is hygroscopic fluids hence tend to collect humidity. The humidity along with the brake fluid can cause acidic reaction & seizure of the master & slave cylinders. The clutch fluid should be replaced every

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















40,000 km or one in a year, whichever is earlier. The master & clutch cylinder seals to be replace every 50,000 Kms

### **Trouble Shooting -**

Unless the cause of a clutch problem is extremely obvious, accurate problem diagnosis will require a road test to confirm that the problem exists. To find out the actual root cause of the problem the clutch will have to be dismantled and the failed parts examined to determine the cause.

During road test, drive the vehicle in normal operating speeds. Shift the gears and observe the clutch action. If chatter, grab, slip or improper release is experienced, remove & inspect the parts. However if problem is noise or hard shift then the problem may not be in clutch only but also the transmission or the driveline.

If the clutch slip is suspected then drive the vehicle in 1<sup>st</sup> or 2<sup>nd</sup> gear at the top speed (corresponding to the gear). Keeping the accelerator fully pressed, slowly apply the brake- with your left feet. If the engine stalls then the clutch is not slipping.

### **Clutch Problem Causes -**

Fluid contamination is the most frequent cause of clutch malfunction. Oil, water on the clutch contact surface will cause faulty operation viz. Slip, grab, and judder.

During inspection check if any parts in the clutch are coated with oil or water splash from road.

Oil contamination indicates a leak at either rear main seal or transmission-input shaft. The oil leaks from either of these areas will normally coat the housing interior or clutch cover or flywheel. Heat build up due to slippage between the clutch plate and the flywheel or the pressure plate can result into the leaked oil literally getting baked. Visually this will result in a glazed residue varying from amber to black.

Roads splash contamination will mean that the dirt water is entering the clutch housing either due to loose bolt or torn rubber boot.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC




















### <u>Clutch misalignment</u> -

The clutch component i.e. the clutch plate, flywheel and the pressure plate have to be aligned with the crankshaft and the transmission input shaft. Misalignment caused by runouts/ warpage will cause clutch to grab judder as well as improper release (also manifesting as hard gearshift).

### Flywheel runout -

The flywheel runout needs to be checked whenever misalignment is suspected. Flywheel runout should not exceed 0.10 mm.



To measure the runout mount the base of the magnetic dial gauge on the block. Locate the dial gauge's needle on the outer surface of the flywheel.

Some of the common reasons for excessive runout are:

- ✓ Heat warpage.
- ✓ Improper machining.
- ✓ Incorrect bolt tightening

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















- ✓ Foreign material on crankshaft flange or flywheel.
- ✓ Improper seating on crankshaft.

#### Clutch cover & Disc runout -

A warped cover or diaphragm spring will result in clutch grab and / or incomplete release of clutch plate.

If the clutch alignment tool is not used then the misalignment of the clutch plate can cause distortion of the cover and also disc damage.

The cover can also get misaligned due to improper tightening of the cover onto the flywheel. The only way to avoid is that the bolts must be tightened alternatively (diagonal pattern) and evenly i.e. 2 to 3 thread a time only.

A noisy gearshift operation especially the 1<sup>st</sup> and 2<sup>nd</sup> gear can be due to clutch not getting disengaged completely. To check it, jack up the rear axle. Lift the axle till both the wheels are rotating freely.

Press the clutch pedal completely and start the engine, the wheels should not be spinning. Now slowly release the pedal till it has moved about 10 mm, the wheel should still not be spinning. If some spinning is noticed then it indicates improper lift of the pressure plate. First check the bleeding and the pedal travel then check for the pressure plate lift.

# **Clutch Housing Misalignment** -

The clutch housing has to be aligned with the engine so that the input shaft is aligned with the crankshaft. Absence of this alignment results in clutch noise, incomplete release of the clutch plate. It can normally be judged by uneven wear of the finger and pilot bearing. In severe case it can also damage the spline of the input shaft and clutch hub's well as the clutch splines

- Normally the clutch housing misalignment is a result of:
- Incorrect seating on the engine/transmission.
- > Missing alignment dowel holes.
- Loose or missing mounting bolt.
- > Mounting surfaces that are damaged/ not parallel.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















To check the clutch housing misalignment.



bell housing runout will also need to be checked.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















Problem: Clutch slip

Observation	Causes	Remedial action
Disc facing worn out.	<ol> <li>Normal wear.</li> <li>Clutch riding.</li> <li>Insufficient diaphragm spring clamp load.</li> </ol>	<ul> <li>✓ Replace clutch disc</li> <li>✓ Replace clutch plate</li> <li>✓ Replace clutch plate &amp; cover assembly.</li> <li>✓ Replace, and bleed/</li> </ul>
	<ul> <li>4. Faulty release mechanism.</li> <li>5. Vehicle being driven despite slipping clutch.</li> <li>6. Bad driving practice of allowing the clutch to slip far too long.</li> </ul>	
Clutch disc facing contaminated with oil, grease or clutch fluid.	<ol> <li>Crankshaft rear end oil seal</li> <li>Leak through the input shaft</li> <li>Excess amount of grease applied to the input shaft splines</li> </ol>	Clean cover assembly.  ✓ Replace seal & disc. Clean cover assembly.  ✓ Apply less grease. Replace clutch disc. Clean cover assembly.
Clutch is running partially disengaged.	Release bearing carrier sticky.	✓ Replace bearing / carrier.
Flywheel height incorrect.	<ol> <li>Improperly machined flywheel.</li> <li>Excess machining done.</li> </ol>	✓ Replace flywheel.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















Wrong disc or pressure plate used.	Use the correct parts	✓ Replace the parts after comparison.
Clutch disc/ cover or diaphragm spring warped.	Improper     tightening or     loosening     procedure.	✓ Replace the parts and tighten as per sequence.
	Rough handling of clutch plate or cover assembly	✓ Replace the parts, ensure that the rough handling is avoided
Flywheel side clutch facing surface - torn/ nicked/ worn	Flywheel surface ,scored and having light notch	<ul><li>✓ Reduce the scoring and nicks by sand paper. Reduce if scoring deeper.</li></ul>
Clutch disc facing burnt. Excessive glazing of the flywheel & pressure plate.	1. Frequent operation under high loads or hard acceleration conditions	✓ Roughen the flywheel face with sandpaper. Replace clutch plate & cover assembly.
	Frequent clutch riding by the driver.	✓ The driver has to be alerted to avoid repeat failure.
Clutch facing broken	Improper storage- clutch plate dropped prior to fitting.	✓ Replace.
Fouling marks on the torsion damper.	Improper fitment- assembled the wrong way around	✓ Rectify

# Problem: Clutch grab/chatter.

Observation	Causes	Remedial action
Clutch disc facing	Leak at:	
contaminated with	1. Crankshaft rear	✓ Replace seal & disc.
oil, grease or clutch	end oil seal	Clean cover assembly.
fluid.	2. Leak through the	✓ Replace seal & disc.
	input shaft	Clean cover assembly.
	3. Excess amount of	✓ Apply less grease.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

















	grease applied to the input shaft splines	Replace clutch disc. Clean cover assembly.
Clutch disc / pressure plate warped.	<ol> <li>Incorrect or substandard parts.</li> <li>Improper</li> </ol>	<ul> <li>✓ Replace disc and cover with the correct parts.</li> <li>✓ Replace the parts and tighten as per sequence.</li> </ul>
Disc facing show unusual wear	tightening or loosening procedure.	✓ Replace the parts, ensure that the rough handling is
	3. Rough handling of clutch plate or cover assembly	avoided.
Partial engagements of clutch disc (One side worn - opposite side glazed and	<ol> <li>Clutch pressure plate position setting incorrect or modified</li> </ol>	✓ Replace clutch cover & clutch plate.
lightly worn.)	2. Clutch cover, spring or release fingers bent or distorted due to rough handling or improper	✓ Replace clutch cover & clutch plate.
	assembly. 3. Clutch disc damaged or	✓ Replace clutch plate.
	distorted. 4. Clutch misalignment.	✓ Check alignment and runout of flywheel disc or cover.
		<ul> <li>✓ Replace the clutch plate &amp; cover assy (if required. Correct the alignment)</li> </ul>
No fault found with clutch components.	Problem related to suspension or driveline components.	✓ Further diagnosis required. Check engine & transmission mounting insulators. U Joint, tyres, body attaching parts.
Clutch master	Piston/ bore	✓ Overhaul the master &

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Clutch Version 1, Aug 06













**EXIT** 





cylinder or slave cylinder piston jammed/scuffing.	damaged or corroded	slave cylinder.
Tangential strap connecting the pressure plate to the diaphragm cover broken.	<ul> <li>1. Incorrect driving practice</li> <li>✓ Mostly due to tow starting in 1<sup>st</sup> or 2<sup>nd</sup> gear</li> <li>Or</li> <li>✓ Incorrect gear selection</li> </ul>	✓ Advise the customer of the consequences.
Withdrawal fork worn out	Wear of the fork at pivot end or the release bearing end	✓ Replace the fork

# Problem: Improper clutch release

Observation	Causes	Remedial action
Clutch disc warped.	New disc not checked before installation	✓ Check the new disc's runout & replace it.
Clutch plate is binding on the input shaft's splines.	1. Clutch disc hub splines damaged during	✓ Replace the clutch plate.
	installation.	✓ Replace input shaft is severely damaged.
	2. Input shaft splines	/ Danie a the shotel what
	rough or damaged.	<ul> <li>✓ Replace the clutch plate.</li> <li>Replace the input shaft if the scaling can not be</li> </ul>
	3. Corrosion or rust formation on	removed.
	splines of disc and input shaft.	
Clutch disc-facing sticks to flywheel.	Vacuum may form in pockets over rivet head. Occurs as clutch cools down after use.	✓ Drill 1/16 inch diameter hole through rivets and scuff sand the clutch disc facing .

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC




















Clutch will not disengage properly.	1. Low fluid in the clutch master cylinder. ✓ Top off the fluid and check for leaks.
	2. Air in the hydraulic system   ✓ Bleed & refill the system. ✓ Tighten the bolts.
	3. Clutch cover loose. ✓ Replace disc.
	4. Wrong clutch disc. ✓ Replace the cover assembly.
	5. Clutch cover diaphragm spring bent / warped during transmission installation. ✓ Fit the clutch plate correctly the hub should be facing the pressure plate side & the flywheel side mark towards the flywheel
	6. Clutch disc fitted backwards.
Pilot bearing seized.	1. Bearing cocked during for misalignments. installation. ✓ Fit new bearings & check
	2. Bearing seized.
	3. Clutch misalignment







Problem: Hard gear shift

Observation	Causes	Remedial action
Brake fluid less a or contaminated	1. Leaks 2. Reservoir strainer missing	<ul><li>✓ Replace fluid.</li><li>✓ Stop leaks and avoid contamination.</li></ul>
Excessive clut pedal free plays. Clutch pla warpage	or lock nut loosening	Replace
	2. Warpage due to misalignment.	

















In Car Repairs -

Adjustment of clutch pedal height.

Clutch bleeding.

Adjustment of clutch pedal height -



Loosen the lock nut of master cylinder's push rod fork.



Slide backs the dust cover.



Rotate the master cylinder push rod till desired height of pedal is achieved.

Tighten the lock nut of push rod fork.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC
























### Bleeding the clutch -



Clean the external areas of the clutch slave cylinder and remove the dust cap of the bleeder screw.



If the bleeding operation is done by without connecting by a tube and in the open air then the chance of air remaining trapped is high.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC























Connect bleeding tube, to bleeding screw on slave cylinder.

Ensure that the other end of the tube is fully immersed in the bottle having clean clutch /brake fluid.



Fill the Reservoir clutch master cylinder up to the top level with recommended clutch fluid.



Operate clutch pedal 3 or 4 times slowly to the full stroke.

Holding the clutch in depressed condition loosen the bleeding screw on slave cylinder by  $\frac{1}{2}$  to  $\frac{3}{4}$  turn and allow all the air escape in to the container bottle.

Repeat the exercise till no air bubbles appears in the bottle.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















During this operation ensure fluid level in reservoir.



Tighten the bleed screw properly.



Remove bleeding tube and place the dust cover.



Check the fluid level in container and need be top up to the max. level.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC




















Master cylinder overhaul
Slave cylinder overhaul.
Slave cylinder and Concentric bearing Overhaul

# Master cylinder overhaul -



Remove the outlet pipe connection.



Remove the clevis pin lock & the clevis pin.



Remove the clutch push rod fork & the clutch pedal.

Remove the master cylinder from the Firewall .

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC






















- 1. Pull back the dust cover.
- 2. Remove circlip.
- 3. Remove the push rod assembly with retainer washer.
- 4. Remove the piston assembly by gently tapping the Clutch Master cylinder body on a wooden block.



Using a screwdriver, lift the leaf retainer. spring Remove spring assembly from plunger.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















	Take care, while lifting the spring otherwise the spring and the stem will fall off.
	Compress spring to free valve stem from eccentrically positioned hole in the end face of spring retainer. This will separate spring retainer from valve stem.
	Remove spring, valve spacer and spring washer from the valve stem.
<del></del>	(While assembling hold the spacer between fingers such that the valve stems hangs down vertically. Pull down the stem downwards as far as possible. Observe if the valve stem has moved freely upwards. If movement is not free replace valve spacer.)
	Remove the valve seal from the valve stem.
	The bore and the plunger should be checked for scoring, scuffing uneven wear marks, corrosion and excessive clearance between plunger & body
	Check the condition of dust cover for cut, deterioration if damaged replace.
	The assembly procedure is the reverse of the dismantling procedure. While fitting the plunger lubricate it with brake fluid.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















# Slave cylinder overhaul -



Remove the Bundy pipe from the inlet.



Remove the slave cylinder from the mounting bracket.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















- 1. Remove dust cover
- 2. Remove circlip.
- 3. Remove plunger with gland seal and plunger spring from body by lightly tapping it on wooden block.
- 4. Remove gland seal from plunger.

The bore and the plunger should be checked for scoring, scuffing uneven wear marks, corrosion and excessive clearance between plunger & body
Check the condition of dust cover for cut, deterioration if damaged replace.
The assembly procedure is the reverse of the dismantling procedure.
While fitting the plunger lubricate it with brake fluid.
Make sure that the push rod end is firmly located at the fork.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC







Clutch overhaul -



Block the front wheels, so that the vehicle does not move forward.
Disconnect the negative cable of the battery.
Remove the electrical connections to the starter motor.
Remove the starter motor.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















0
1000

Remove the clutch slave cylinder from the gearbox mounting.

Note: Remove the slave cylinder along with the small Bundy tube. Disconnect the Bundy tube from the main tubing.

Remove the propeller shaft from the gearbox end.

Do not allow the propeller shaft to hang. Support it.



Remove the speedometer cable from the gearbox end



Remove the electrical connection for the reverse lamp switch.

Support the engine suitably at rear
Remove the gearboxes gearshift lever grommet.
Remove the gearbox lever upper half.
Support the gearbox using a suitable stand.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















	Remove the gearbox mounting insulators.
	Remove the clutch housing mounting
	screws to the engine rear face & the
	ladder frame.
	Move the gearbox away from the engine.
	Remove the clutch release bearing with sleeve.
	Remove the clutch fork.
	If the original cover will be reinstalled then mark position of cover on the flywheel for assembly reference. Use paint as a marker for this.
	If the cover assembly may be reused then loosen the cover bolts evenly and in tightening sequence to relive the spring tension equally.  The bolts should be loosened few threads at a time - so that the warping is avoided.  If the cover assembly is not going to be reused then this precaution is not essential.
	If the pilot bearing has to be removed then the flywheel has to be removed and then the bearing removed using the MST no 543.  (To install the bearing MST no 544 has to be used.)  During assembly use the MST 546 to
	align the clutch plate while the cover is being tightened.
The assembly sequence is the re	everse of the dismantling (except the
precautions mentioned.)	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

















All the components should be inspected for wear. Any components, which are beyond the wear limits, have to be replaced.

Over & above the wear limits: The following points also need to be ensured.

### Flywheel runout --

The flywheel runout needs to be checked whenever misalignment is suspected. Flywheel runout should not exceed 0.10 mm

To measure the runout mount the base of the magnetic dial gauge on the block. Locate the dial gauge's needle on the outer surface of the flywheel.

Some of the common reasons for excessive runout are:

- ✓ Heat warpage.
- ✓ Improper machining.
- ✓ Incorrect bolt tightening
- ✓ Foreign material on crankshaft flange or flywheel.
- ✓ Improper seating on crankshaft.

If the flywheel has been removed for resurfacing or replacing the pilot bearing then while fitting it back ensure that:

- No dirt and grease present on the mounting face (it can cause cocking & run out)
- The flywheel bolts have been replaced.
- > Torque tightened as per sequence and also the angular tightening as per the specification is done.

Absence of any of these requirements may result in bolt loosening causing flywheel runouts.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















#### Clutch cover & Disc runout --

Check the clutch disc runout before fitting. It should be within the specifications. If it is more than the specification- use a different clutch plate.

A warped cover or diaphragm spring will result in clutch grab and / or incomplete release of clutch plate.

If the clutch alignment tool is not used then the misalignment of the clutch plate can cause distortion of the cover and also disc damage.

The cover can also get misaligned due to improper tightening of the cover onto the flywheel. The only way to avoid is that the bolts must be tightened alternatively (diagonal pattern) and evenly i.e. 2 to 3 thread a time only.

### Clutch Housing Misalignment -

The clutch housing has to be aligned with the engine so that the input shaft is aligned with the crankshaft. Absence of this alignment results in clutch noise, incomplete release of the clutch plate. It can normally be judged by uneven wear of the finger and pilot bearing. In severe case it can also damage the spline of the input shaft and clutch hub's well as the clutch splines

- > Normally the clutch housing misalignment is a result of:
- Incorrect seating on the engine/transmission.
- Missing alignment dowel holes.
- Loose or missing mounting bolt.
- Mounting surfaces that are damaged/ not parallel.

Before fitting the clutch housing ensure that no dirt, debris or foreign parts are trapped between the mating surface of the transmission & the clutch housing.

## Flywheel --

If the flywheel is found to be having minor scoring then it can be resurfaced. However the maximum allowed cut is 0.076 mm. If scoring is deeper than 0.0076 than the flywheel has to be changed. (Excessive material removal will cause the flywheel to either crack/ warpage after installation/ drop in

All copyrights reserved by Mahindra & Mahindra I td

Scorpio SC - DC



















clamping load and will affect the proper clutch release as the travel of release bearing gets affected.)

If the flywheel has been removed for resurfacing or replacing the pilot bearing then while fitting it back ensure that:

- No dirt and grease present on the mounting face (it can cause cocking & run out)
- The flywheel bolts have been replaced.
- > Torque tightened as per sequence and also the angular tightening as per the specification is done.

Absence of any of these requirements may result in bolt loosening causing flywheel runouts.

<u>Starter ring replacement</u>: Unless the provision of properly heating & fitting is available. It is not recommended to replace the starter ring. It is worthwhile to replace the ring along with the flywheel.

Caution: If the starter ring is only going to be



replaced then :-

Do not use an gas flame to cut .It can Cause local overheating of flywheel.
The ring gear has to be heated in a oven

To get a uniform expansion. (Nearly 191°C)

Do not use flame to heat the ring - it can cause annealing of the ring teeth and premature failure.

















# Specifications & Wear Limits --

Figure	Description	Value
	Clutch control type- Pressure plate Clutch Disc Outer Dia (mm) Inner Dia ( mm)	Hydraulic- self adjusting Diaphragm  240±1 160± 1
<b>→</b>	Disc Thickness ( mm)	8.8 mm ( free)
Measure at about 6 mm from outer edge.	Clutch disc run out	0.8 mm Max
	Minimum thickness from outer face to rivet head.	0.4 mm
	Clutch pedal	Suspended Type
	Clutch pedal Ratio	7.4

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















Automotive Sector		V 1
Figure	Description	Value
	Clutch Pedal Height above carpet thickness of 10 mm. Normal Under full depression.	172 mm 165 mm.
	Clutch pedal free play ( including push rod play at pedal top)	5 to 6 mm
	Master Cylinder Bore diameter	19.05 mm
	Slave Cylinder Inner diameter	22.22 mm
	Clearance between The piston & the bore ( Both cylinders)	0.13 mm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















Figure	Description	Value
	Flywheel	Standard Service Limit
	Flatness	≤ 0.05 0.1
i	Runout	≤ 0.05 0.1
	Flywheel Width from Mounting face to clutch face	35±0.13
Clutch release point from pedal full stroke end position		25 mm from Bottom position
	Pressure plate finger height ( mm)	47.6±1.0 mm
<u></u>	Diaphragm spring tip non alignment. (Max)	0.8 mm ( finger to finger)
	Diaphragm spring finger wear	Max depth 0.5 mm Max width 5 mm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Clutch Version 1, Aug 06











**EXIT** 





# <u>Tightening Torque's</u> -

Bolt location	Torque in Nm ( Lbft)
Pressure plate bolts	30 - 35 Nm (22 to 26 Lb-ft)
Clutch pedal position Switch lock nut	25 Nm (18 Lb-ft)
Bleed Screw	8 - 10 Nm ( 6-7.3 Lb-ft)
Clutch master cylinder nut	25 Nm (18 Lb-ft)
Cylinder clutch slave cylinder bolts	45 Nm (33 Lb-ft)
Flywheel	90 Nm + 60° ( 66 Lbft+ 60°)
Clutch pedal pivot bolt and nut	25 - 30 Nm ( 18-22 Lb-ft)

















# List of the MST -

Description / Part No. / Sketch	Usage View
Master clutch plate assembly-diesel (aligner) MST 546	
Extractor Flywheel bearing MST 543	
Drift Flywheel bearing MST 544	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Clutch Version 1, Aug 06















**EXIT** 





# <u>Lubricant</u> -

**Specification:** DOT 3

Hindustan Petroleum: HP Super Duty Brake Fluid

Castrol: Girling Brake Fluid

Indian Oil: Servo Brake fluid Super HD




















All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















## NGT 530 2 WD

**Description** 

Care of the transmission

**Service Diagnosis** 

In vehicle adjustment & repair.

**Dismantling** 

**Adjustments** 

**Cleaning & Inspection** 

**Tightening Torque** 

**Special Tools** 

**Sealants** 

**Specifications** 






















### **Description --**



It is a 5-speed gearbox. All the forward speed is using baulk ring type synchronizer. The reverse gear is sliding mesh type with synchro brake.

The gear selection is by a direct shift lever operating a 3-rail system. The accidental operation of two gears is avoided by an interlocking mechanism. To avoid vibrations passing on to the shift lever. The shift lever is a two-piece with rubber isolation provided on to the top half.

The gearbox housing is aluminum 3 piece with split housing. The Gearbox is mounted directly on the flywheel through the integral clutch housing and supported at bottom below the rear housing using a bracket.




















# Care of the transmission --

The lubricant level should be checked every 10000 Kms. with the vehicle unladen and in a level ground. The lubricant level should be at the lower edge of the filler plug. Use lubricant meeting oils specification of GL 4 & viscosity 80W90. The brand names have been specified in the Operators Manual. The other optional grade is 80 W90 Synchro oil. This grade is particularly suitable for cold weather operation.

The lubricant should be changed at 5000 Kilometers, then at 20000 Kilometer's and subsequently every 20000-Kilometer's.

# Service Diagnosis -

A low transmission lubricant level is generally the result of a leak, inadequate lubricant fill, or an incorrect lubricant level check.

Leaks can occur at the mating surface of the gear case, intermediate plate and adapter or extension housing or from the front/rear seals. A suspected leak could also be result of an overfill condition.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Leaks at the rear of the extension or adapter housing will be from the housing oil seal. Leaks at component mating surface will probably be the

result of inadequate sealer, gaps in sealer, incorrect bolt tightening, or the use of a non-recommended sealer.

A leak at the front of the transmission will be from either the front bearing retainer. Lubricant may be seen dripping from the clutch housing after extended operation. If the leak is severe, it may also contaminate the clutch disc causing slip, grab and chatter.

A correct lubricant level check can be made only when the vehicle is level, use a two post or a four post hoist to ensure this. Also allow the lubricant to settle for a minute or so before checking. These recommendations will ensure that an accurate check and avoid an under fill or overfill conditions.

# **Hard Shifting**

Hard shifting is usually caused by low lubricant level, improper or contaminated lubricants, component damage, and incorrect clutch adjustment or by a damaged clutch pressure plate or disc.

Substantial lubricant leak can result in gear, shift rail, synchro and bearing damage. If a leak goes undetected for an extended period the first indications of a problem are usually hard shifting and noise.

Incorrect or contaminated lubricants can also contribute to hard shifting. The consequence of using non-recommended lubricants is noise, excessive wear, internal bind and hard shifting.

Improper clutch release is one of the most frequent causes of hard shifting. Incorrect adjustment of a worn damaged pressure plate or disc can cause incorrect release. If the clutch problem is advanced then gear clash during shifts can result. Incomplete travel of the clutch pedal due to restrictions at the end of stroke (upturned carpet, extra carpet or cover or bend clutch linkage can also cause improper clutch release and hard shift.)

Worn or damaged synchro rings can cause gear clash when shifting any forward gear. In some new or rebuilt transmissions, new synchro rings

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















may tend to stick slightly causing hard or noisy shifts. In most conditions this will decline as the rings wear in.

# **Transmission noise**

Most manual transmissions make some noise during normal operation. Rotating gears can generate slight whine that may only be audible at extreme speeds.

Severe obviously audible transmission noise is generally the result of a lubricant problem. Insufficient, improper or contaminated lubricant can promote rapid wear of gears, synchros, shift rail, forks and bearing's. The overheating caused by a lubricant problem can also lead to gear breakage.

# Summarizing the common faults and their cause:

PROBLEM	POSSIBLE CAUSES	CORRECTION
Gear Whine	Low oil level	Top up oil.
	Worn teeth gears	Replace gears
	Worn bearings	Replace bearings.
Knocking or	Chipped gear teeth	Replace gears.
ticking	Foreign matter inside	Remove the foreign
	transmission.	matter and locate how
	Defective bearings.	the foreign matter
		came inside e.g.
		missing breather and
		rectify that also to
		avoid recurrence.
		Check drain plug for
		metal particles.
		Replace the bearings.
Jumping out of		Replace the detent
gear	Worn out grooves in shift	springs.
	rail.	Replace the shift rails.
	Shaft misalignment.	
	Worn dog teeth in gear	Replace the gears
	Worn out fork pads	Replace the fork
	Worn out synchronizer	assembly
	body.	Replace the synchro
	Gear shift lever fouling with	pack

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















	vehicle vehicles cutout for lever.	Find out the reason for the fouling, correct them.
Unable to select gear	Clutch defective Worn out selector mechanism	Rectify the clutch/ clutch withdrawal mechanism Rectify the gear selector mechanism
Hard gear shifting	Clutch defective Improper or contaminated lubricants	Rectify the clutch/ clutch withdrawal mechanism Replace the lubricant with  the specified lubricant. ( 80 W 90 Synchro Oil )

# A: - IN VEHCILE ADJUSTEMENT & REPAIR -

The rectifications in transmission that can be done without removing from the vehicle are:

# 1) Replacement of output shaft seal -

Sketch / Photo	Description	Check	Note/ Tools
	Remove the propeller shaft from the companion flange		Spanne r 14 mm
	Lock the companion flange.		MST 203

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC























1. Unlock the output shaft nut

3. Remove the companion flange

Socket 29 mm

Note: Unless otherwise specified the assembly procedure / guidelines is the reverse of the disassembly procedure

## **DISMANTLING** -



- 1) Remove Clutch Release bearing & fork.
- 2) Remove biasing cover plate bolts & springs. 4 nos. (Check Point A)
- 3) Remove Lever retention bolts 3 nos.
- 4) Put the selector mechanism in neutral & remove lever assembly along with nylon bush & spring.
- 5) Loosen & Remove the rear companion flange nut & remove

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















- the Flange using MST 203.
- 6) Remove the mounting bracket.
- 7) Loosen & remove the locking bolt & remove the speed sensor.
- 8) Using the **MST 514** remove the speedometer driven gear. (Check Point B)
- 9) Remove the reverse light switch.
- 10) Place the gear box on a wooden block such as the bell housing rests on the block.
- 11) Loosen & remove rear-housing bolts. (7 Nos.)
- 12) Remove the plate cover by unscrewing three nos. bolts & fit the MST 513 on the rear housing.
- 13) Tighten the MST 513 center bolt gently to pull out the rear housing. Gently tap on the rear housing using a soft mallet to make the extraction uniformly from the gearbox. (Check Point C)
- 14) Remove 5<sup>th</sup> driven gear using **MST 523** (Check point D)
- 15) After shifting into the 5<sup>th</sup> gear install the retaining plate **MST** 503 over 5<sup>th</sup> gear selector fork shaft.
- 16) Remove rail pins from 5<sup>th</sup> Reverse fork. & remove the 5<sup>th</sup> reverse fork & synchro pack.
- 17) Loosen & remove intermediate housing (4 nos. bolts & 3 nos. nuts). By gently tapping remove intermediate housing.
- 18) Place the gearbox on GearBox mounting stand **MST 522**. (Check Point E)



All copyrights reserved by

Scorpio SC DC




















# Dismantling -- Main Shaft Assembly -



- 1. Remove circlip & remove taper roller bearing, 3rd-4<sup>th</sup> synchro unit, 3<sup>rd</sup> gear.
- 2. Remove 5<sup>th</sup> driven gear using MST 523.
- 3. Remove distance sleeve & reverse main gear.
- Place the main shaft on mechanical press with MST 511.
   Remove spacer, 1<sup>st</sup> gear, 1st 2<sup>nd</sup> synchro unit & 2<sup>nd</sup> gear.

All copyrights reserved by

Scorpio SC DC
















# **Shift Mechanism** -



# Note:

A: 1<sup>st</sup>/ 2<sup>nd</sup> fork boss is facing towards rear.

B: 3<sup>rd</sup>/4<sup>th</sup> fork boss is facing towards front.

C: The postion of the interlock pin.

Suggestion: While assmbly lightly smear the interlock pin & the detent spring & the balls with grease, so that they do not fall. (Check Point F)

Main Menu




















# **Check Points -**



A)
Springs towards 1<sup>st</sup> / 2<sup>nd</sup> gear position is softer than 5<sup>th</sup> / reverse position.



B)
Use MST 514 to pull out the speedo drive.



While tightening the centre bolt of the special tool; tighten it gently.

To make the extraction easier tap the rear cover using a soft mallet.



D)

Use MST 523 to remove the 5<sup>th</sup> Gear. All the legs should be locked properly.

Care must be taken not to damage the roller bearing.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















E)

While mounting the gear box on support stand the orientation to be ensured as shown in photograph.

Lock on only one support leg.

Lock on both the support legs.



F) Please note the fitment of the balls & the interlock pins.

It is recommended that while assembly lightly smear the pin & balls with grease.

This will avoid the ball or the pin falling down while assembly

#### Caution:

The split portion of the spilit pin should be along the axis of the rail. That is in the same direction of the rail travel.

If fitted facing the fork then during shifting, due to compression the pin can fall down.

All copyrights reserved by

Scorpio SC DC



















# **Adjustments**

The adjustments are required to achieve the following parameters:

The shimming which is done at the  $4^{th}$  gear is done so that the postion of the  $4^{th}$  gear synchro cone is correct. Wrong / improper setting will lead to  $4^{th}$  gear slip.


It is advisable to use the same shims.

The shaft reshimming is only required if either of the comonnets are changed:

- Main shaft
- 1<sup>st</sup>/2<sup>nd</sup> hub.
- 3<sup>rd</sup>/4<sup>th</sup> hub.
- Needle bearing of 1<sup>st</sup> or 2<sup>nd</sup> gear.
- Bush 1st gear.

The shimming sketch & available shims are shown in the sketch.


















**EXIT** 







All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















# Cleaning & Inspection -

Clean the transmission parts in solvent.

Dry the housing gear mechanisms & shafts with compressed air.

Do not use the compressed air to clean / dry the bearings. It can cause damage to raceways and rollers.

# Inspect the -

#### A. Bearings for:

Excessive pitting.
Brinelling
Flaking.
Overheating of raceways.

#### B. Gears for:

Teeth breakage. Teeth pitting.

# C. Synchronizer rings:

Check for excessive wear. The lubrication grooves should be present.

# D. Clutch body ring:

check for excessively worn out tooth.

# E. Sliding sleeve:

Check for excessive wear of the groove & wear of the teeth.

#### F. Forks:

Check for excessive wear causing excess play when they are located in the sleeve.

#### G. Shift rails:

Check for wear in the poppet groove.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# <u>Tightening Torque's</u> -

Description	Torque Nm (lbf-ft)
Companion Flange nut	183 ± 20 (135 ± 15 lbf-ft)
Plugs for shift rail poppet spring	12.5 ± 2.5 Nm (9 ± 2 lbf-ft)
Ft. housing bolts (split housing) M7 bolts	10 ± 2.5 Nm (7 ± 2 lbf-ft)
Ft. housing bolts (split housing) M8 bolts	15 ± 2.5 Nm ( 11 ± 2 lbf-ft)
Drain plug	$27.5 \pm 2.5 \text{ Nm} (20 \pm 2 \text{ lbf-ft})$
Filler plug	27.5 ± 2.5 Nm ( 20 ± 2 lbf-ft)
Reverse light switch	27.5 ± 5 Nm ( 20 ± 4 lbf-ft)
Clutch housing bolts M10	$30 \pm 5$ Nm ( $22 \pm 4$ lbf-ft)
Intermediate Housing bolts M8	17.5 ± 2.5 Nm ( 13 ± 2 lbf-ft)
Rear Housing bolts M8	15 ± 2.5 Nm ( 11 ± 2 lbf-ft)
Bolt - Mounting Brackets	27.5 ± 2.5 Nm ( 20 ± 2 lbf-ft)
Rear housing cover plate	8 ± 2 Nm ( 6 ± 1 lbf-ft)
Biasing bolt M6x1s	8 ± 2 Nm ( 6 ± 1 lbf-ft)



















# Special Tools --

Description/ Part No./ Sketch	Usage View
Press Plate 5th Gear Removal MST - 502	
BA10 5th Rev. Rail Ret. Plate MST - 503	
Press Block 5th Gear Removal MST - 505	
Output Shaft Roller Bearing Press MST - 507	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Description/ Part No./ Sketch	Usage View
5th/Rev Sub Shaft Bearing Installer MST - 508	
Press Plate For Input Shaft MST - 511	
Rear Housing Seal Installing Ring MST - 512	
Extractor Rear Housing.  MST - 513	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















# **Usage View** Description/ Part No./ Sketch **BA10 Circlip Plier For Speedo** MST - 514 **Dial Indicator Support** MST - 515 **BA10 Drift** MST - 517

All copyrights reserved by

Scorpio SC DC





















# Description/ Part No./ Sketch **Usage View** Socket **MST - 518** Socket Hex Hd M8 3/8 Sq Drive MST - 519 Socket Hex Hd M7 3/8 Sq Drive MST - 520









All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

NGT 530 2WD Version 1, Aug 06













**EXIT** 





Description/ Part No./ Sketch	Usage View
BA10 Fix. To Extract 5th Gear MST - 523	
BA10 Extractor For Reverse Sub Shaft Bearing MST - 524	
Extractor For Roller Bearing On 5 <sup>th</sup> Gear MST - 525	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC























# **SEALANTS:** -





Serial number	Location	Sealant / Thread Locks	Applicability
			NGT 530
1	Clutch Hsg. / Split Hsg. / Intermediate Hsg. / Rear Hsg.	Rhodorseal 5632 Option 1 - CAF 33 Option 2 - Pidiseal 3P Option 3 - Loctite 574	$\checkmark$
4	Breather	Loctite 648 Option 1 - Anabond 413 Option 2 - ANR 138	
5	Pivot locking	RTV Sealant Metlock 920 Option 1 Rhodoseal Option 2 Pidiseal 3 P	
6	Companion Flange Lock Nut (Output Shaft Thd.)	Anabond 111	
7	Speedo Sleeve Thd.	Pidilite 171	$\checkmark$
9	Clutch release bearing support sleeve	Loctite 510	$\checkmark$
10	Poppet plug M12x1.25	Loctite 542 Option 1 - Anabond 612	$\checkmark$

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# **Specifications** -

Figure	Description	Value	
	Туре	Mechanical	
	Description	NGT 530	
	Gears	5 Forward and one reverse gear	
	Gear shift	Direct shift with rubberized lever	
	Gears	Helical- tooth	
1 3 5	Gear Engagement	Block ring type synchronizer on ½, ¾; pin type on 5 <sup>th</sup>	
2 4 R			
	Gear Ratio	Scorpio SC DC (V1)	
OTUTO TO	1 <sup>st</sup>	3.78	
	2 <sup>nd</sup>	2.24	
	3 <sup>rd</sup> 4 <sup>th</sup>	1.43	
	5 <sup>th</sup>	1.00	
	Reverse	0.79 3.52	
	Oil grade/ quantity	80 W90; GL 4	
	on grader quantity	or .	
		80 W90 Synchro GL4	
		Fill Quantity: 2.0 litres.	
	Counter shaft bearing	Taper roller bearing.	
	Input Torque capacity	27 Kg - m	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Figure	Description		Value	
Kg	Weight ( With clutch housing)		42.5 Kgs W/O Oil	
	Play	1 <sup>st</sup> 2 <sup>nd</sup> 3 <sup>rd</sup> 4 <sup>th</sup>	0.175 0.175 0.175 0.175 0.175	Service limit(mm) 0.375 0.375 0.375
	Fork to clearances	5 <sup>th</sup> groove	0.18 0.1to 0.4	0.3

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















NGT 530-4 WD

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















**NGT 530 4WD** 

**Description** 

Care of the transmission

**Service Diagnosis** 

**Dismantling** 

**Adjustments** 

**Cleaning & Inspection** 

**Tightening Torque** 

**Special Tools** 

**Sealants** 

**Specifications** 






















# **Description --**



It is a 5-speed gearbox. All the forward speed is using baulk ring type synchronizer. The reverse gear is sliding mesh type with synchro brake.

The gear selection is by a direct shift lever operating a 3-rail system. The accidental operation of two gears is avoided by an interlocking mechanism. To avoid vibrations passing on to the shift lever. The shift lever is a two-piece with rubber isolation provided on to the top half.

The gearbox housing is aluminum 3 piece with split housing. The Gearbox is mounted directly on the flywheel through the integral clutch housing and supported at bottom below the rear housing using a bracket.


















### Care of the transmission --

The lubricant level should be checked every 10000 Kms. with the vehicle unladen and in a level ground. The lubricant level should be at the lower edge of the filler plug. Use lubricant meeting oils specification of GL 4 & viscosity 80W90. The brand names have been specified in the Operators Manual. The other optional grade is 80 W90 Synchro oil. This grade is particularly suitable for cold weather operation.

The lubricant should be changed at 5000 Kilometers, then at 20000 Kilometer's and subsequently every 20000-Kilometer's.

# Service Diagnosis -

A low transmission lubricant level is generally the result of a leak, inadequate lubricant fill, or an incorrect lubricant level check.

Leaks can occur at the mating surface of the gear case, intermediate plate and adapter or extension housing or from the front/rear seals. A suspected leak could also be result of an overfill condition.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Leaks at the rear of the extension or adapter housing will be from the housing oil seal. Leaks at component mating surface will probably be the

result of inadequate sealer, gaps in sealer, incorrect bolt tightening, or the use of a non-recommended sealer.

A leak at the front of the transmission will be from either the front bearing retainer. Lubricant may be seen dripping from the clutch housing after extended operation. If the leak is severe, it may also contaminate the clutch disc causing slip, grab and chatter.

A correct lubricant level check can be made only when the vehicle is level, use a two post or a four post hoist to ensure this. Also allow the lubricant to settle for a minute or so before checking. These recommendations will ensure that an accurate check and avoid an under fill or overfill conditions.

# **Hard Shifting**

Hard shifting is usually caused by low lubricant level, improper or contaminated lubricants, component damage, and incorrect clutch adjustment or by a damaged clutch pressure plate or disc.

Substantial lubricant leak can result in gear, shift rail, synchro and bearing damage. If a leak goes undetected for an extended period the first indications of a problem are usually hard shifting and noise.

Incorrect or contaminated lubricants can also contribute to hard shifting. The consequence of using non-recommended lubricants is noise, excessive wear, internal bind and hard shifting.

Improper clutch release is one of the most frequent causes of hard shifting. Incorrect adjustment of a worn damaged pressure plate or disc can cause incorrect release. If the clutch problem is advanced then gear clash during shifts can result. Incomplete travel of the clutch pedal due to restrictions at the end of stroke (upturned carpet, extra carpet or cover or bend clutch linkage can also cause improper clutch release and hard shift.)

Worn or damaged synchro rings can cause gear clash when shifting any forward gear. In some new or rebuilt transmissions, new synchro rings

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















may tend to stick slightly causing hard or noisy shifts. In most conditions this will decline as the rings wear in.

# **Transmission noise**

Most manual transmissions make some noise during normal operation. Rotating gears can generate slight whine that may only be audible at extreme speeds.

Severe obviously audible transmission noise is generally the result of a lubricant problem. Insufficient, improper or contaminated lubricant can promote rapid wear of gears, synchros, shift rail, forks and bearing's. The overheating caused by a lubricant problem can also lead to gear breakage.

# Summarizing the common faults and their cause:

PROBLEM	POSSIBLE CAUSES	CORRECTION
Gear Whine	Low oil level	Top up oil.
	Worn teeth gears	Replace gears
	Worn bearings	Replace bearings.
Knocking or	Chipped gear teeth	Replace gears.
ticking	Foreign matter inside	Remove the foreign
	transmission.	matter and locate how
	Defective bearings.	the foreign matter
		came inside e.g.
		missing breather and
		rectify that also to
		avoid recurrence.
		Check drain plug for
		metal particles.
		Replace the bearings.
Jumping out of	Defective detent springs.	Replace the detent
gear	Worn out grooves in shift	springs.
	rail.	Replace the shift rails.
	Shaft misalignment.	
	Worn dog teeth in gear	Replace the gears
	Worn out fork pads	Replace the fork
	Worn out synchronizer	assembly
	body.	Replace the synchro
	Gear shift lever fouling with	pack

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















	vehicle vehicles cutout for lever.	Find out the reason for the fouling, correct them.
Unable to select gear	Clutch defective Worn out selector mechanism	Rectify the clutch/ clutch withdrawal mechanism Rectify the gear selector mechanism
Hard gear shifting	Clutch defective Improper or contaminated lubricants	Rectify the clutch/ clutch withdrawal mechanism Replace the lubricant with the specified lubricant. (80 W 90 Synchro Oil )

Note: Unless otherwise specified the assembly procedure / guidelines is the reverse of the disassembly procedure

# **DISMANTLING**



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC


















- Remove Clutch Release bearing & fork. 1)
- Remove biasing cover plate bolts & springs. 4 nos. 2) (Check Point A)
- Remove Lever retention bolts 3 nos. 3)
- Put the selector mechanism in neutral & remove 4) lever assembly along with nylon bush & spring.
- 5) Remove the mounting bracket.
- Using the MST 514 remove the speedometer driven 6) gear. (Check Point B)
- Remove the reverse light switch. 7)
- Place the gear box on a wooden block such as the bell 8) housing rests on the block.
- Loosen & remove rear-housing bolts. (7 Nos.) 9)
- Remove 5<sup>th</sup> driven gear using **MST 523** (Check point D) 10)
- After shifting into the 5<sup>th</sup> gear install the retaining plate **MST 503** over 5<sup>th</sup> gear selector fork shaft. 11)
- 12)
- Remove rail pins from 5<sup>th</sup> Reverse fork. & remove 13) the 5<sup>th</sup> - reverse fork & synchro pack.
- Loosen & remove intermediate housing (4 nos. bolts & 14) 3 nos. nuts). By gently tapping remove intermediate housing.
- Place the gearbox on GearBox mounting stand MST 15) **522.** (Check Point E)



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















- 16) Loosen & remove clutch housing bolts (7 Nos.) & the housing.
- 17) Loosen & remove the split housing bolts (12 Nos.) & remove housing.
- 18) Remove the main shaft assembly & MD gear assembly.
- 19) Remove the counter shaft assembly.

#### Dismantling -- Main Shaft Assembly -



- 1) Remove circlip & remove taper roller bearing, 3rd-4<sup>th</sup> synchro unit, & 3<sup>rd</sup> gear.
- 2) Remove 5<sup>th</sup> driven gear using MST 523.
- 3) Loosen & Remove the nut & reverse main gear.
- 4) Place the main shaft on mechanical press with MST 511.
- 5) Remove spacer, 1<sup>st</sup> gear, 1st 2<sup>nd</sup> synchro unit & 2<sup>nd</sup> gear.


















#### **Shift Mechanism** -



#### Note:

A: 1<sup>st</sup>/ 2<sup>nd</sup> fork boss is facing towards rear.
B: 3<sup>rd</sup>/4<sup>th</sup> fork boss is facing towards front.
C: The postion of the interlock pin.

Suggestion: While assmbly lightly smear the interlock pin & the detent spring & the balls with grease, so that they do not fall. (Check Point F)





















A) Springs towards  $1^{st}$  /  $2^{nd}$  gear position is softer than  $5^{th}$  / reverse position.



#### D)

Use MST 523 to remove the 5<sup>th</sup> Gear. All the legs should be locked properly.

Care must be taken not to damage the roller bearing.



#### E)

While mounting the gear box on support stand the orientation to be ensured as shown in photograph.

Lock on only one support

Lock on both the support legs.

All copyrights reserved by Mahindra & Mahindra Ltd

Main Menu

Scorpio SC DC






















F) Please note the fitment of the balls & the interlock pins.

It is recommended that while assembly lightly smear the pin & balls with grease.

This will avoid the ball or the pin falling down while assembly

#### Caution:

The split portion of the spilit pin should be along the axis of the rail. That is in the same direction of the rail travel.

If fitted facing the fork then during shifting, due to compression the pin can fall down.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

NGT 530 4WD Version 1, Augl 06

**EXIT** 



















#### **Adjustments**

The adjustments are required to achieve the following parameters:

The shimming which is done at the  $4^{th}$  gear is done so that the postion of the  $4^{th}$  gear synchro cone is correct. Wrong / improper setting will lead to  $4^{th}$  gear slip.

It is advisable to use the same shims.

The shaft reshimming is only required if either of the comonnets are changed:

- Main shaft
- 1<sup>st</sup>/2<sup>nd</sup> hub.
- 3<sup>rd</sup>/4<sup>th</sup> hub.
- Needle bearing of 1st or 2nd gear.
- Bush 1st gear.

The shimming sketch & available shims are shown in the sketch.






















All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















#### Cleaning & Inspection -

Clean the transmission parts in solvent.

Dry the housing gear mechanisms & shafts with compressed air.

Do not use the compressed air to clean / dry the bearings. It can cause damage to raceways and rollers.

#### Inspect the -

#### A. Bearings for:

Excessive pitting.
Brinelling
Flaking.
Overheating of raceways.

#### B. Gears for:

Teeth breakage. Teeth pitting.

#### C. Synchronizer rings:

Check for excessive wear. The lubrication grooves should be present.

### D. Clutch body ring:

check for excessively worn out tooth.

#### E. Sliding sleeve:

Check for excessive wear of the groove & wear of the teeth.

#### F. Forks:

Check for excessive wear causing excess play when they are located in the sleeve.

#### G. Shift rails:

Check for wear in the poppet groove.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

NGT 530 4WD Version 1, Augl 06













**EXIT** 





# <u>Tightening Torque's</u> -

Description	Torque Nm (lbf-ft)
Plugs for shift rail poppet spring	12.5 ± 2.5 Nm (9 ± 2 lbf-ft)
Ft. housing bolts (split housing) M7 bolts	10 ± 2.5 Nm (7 ± 2 lbf-ft)
Ft. housing bolts (split housing) M8 bolts	15 ± 2.5 Nm ( 11 ± 2 lbf-ft)
Drain plug	27.5 ± 2.5 Nm ( 20 ± 2 lbf-ft)
Filler plug	27.5 ± 2.5 Nm ( 20 ± 2 lbf-ft)
Reverse light switch	$27.5 \pm 5 \text{ Nm}  (20 \pm 4 \text{ lbf-ft})$
Clutch housing bolts M10	$30 \pm 5$ Nm ( $22 \pm 4$ lbf-ft)
Intermediate Housing bolts M8	17.5 ± 2.5 Nm ( 13 ± 2 lbf-ft)
Rear Housing bolts M8	15 ± 2.5 Nm ( 11 ± 2 lbf-ft)
Bolt - Mounting Brackets	27.5 ± 2.5 Nm ( 20 ± 2 lbf-ft)
Rear housing cover plate	8 ± 2 Nm ( 6 ± 1 lbf-ft)
Biasing bolt M6x1s	8 ± 2 Nm ( 6 ± 1 lbf-ft)

















# **Usage View** Description/ Part No./ Sketch Press Plate 5th Gear Removal MST - 502 BA10 5th Rev. Rail Ret. Plate MST - 503 Press Block 5th Gear Removal MST - 505 Press Plate For Input Shaft MST - 511

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

NGT 530 4WD Version 1, Augl 06













**EXIT** 





# **Usage View** Description/ Part No./ Sketch Rear Housing Seal Installing Ring MST - 512 **Dial Indicator Support** MST - 515 **BA10 Drift** MST - 517









All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















# Description/ Part No./ Sketch Usage View

Socket MST - 518





Socket Hex Hd M8 3/8 Sq Drive MST - 519





Socket Hex Hd M7 3/8 Sq Drive MST - 520





Support Transmission MST - 522





All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















ilidililidi a	
Description/ Part No./ Sketch	Usage View
BA10 Fix. To Extract 5th Gear MST - 523	
BA10 Extractor For Reverse Sub Shaft Bearing MST - 524	
Extractor For Roller Bearing On 5 <sup>th</sup> Gear MST - 525	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















## **SEALANTS:** -





Serial number	Location	Sealant / Thread Locks	Applicability
			NGT 530
1	Clutch Hsg. / Split Hsg. / Intermediate Hsg. / Rear Hsg.	Rhodorseal 5632 Option 1 - CAF 33 Option 2 - Pidiseal 3P Option 3 - Loctite 574	
4	Breather	Loctite 648 Option 1 - Anabond 413 Option 2 - ANR 138	
5	Pivot locking	RTV Sealant Metlock 920 Option 1 Rhodoseal Option 2 Pidiseal 3 P	
6	Companion Flange Lock Nut (Output Shaft Thd.)	Anabond 111	
7	Speedo Sleeve Thd.	Pidilite 171	
9	Clutch release bearing support sleeve	Loctite 510	
10	Poppet plug M12x1.25	Loctite 542 Option 1 - Anabond 612	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















Figure	Description	Value
	Туре	Mechanical
	Description	NGT 530 - 4WD
	Gears	5 Forward and one reverse
		gear
	Gear shift	Direct shift with rubberized
		lever
	Gears	Helical- tooth
1 3 5	Gear Engagement	Block ring type synchronizer on ½, ¾; pin type on 5 <sup>th</sup>
2 4 R		
	Gear Ratio	Scorpio CRDe, (V1)
The state of the s	1 <sup>st</sup>	3.78
	2 <sup>nd</sup> 3 <sup>rd</sup>	2.24
	4 <sup>th</sup>	1.43 1.00
	5 <sup>th</sup>	0.79
	Reverse	
	Oil grade/ quantity	80 W90; GL 4
		or
		80 W90 Synchro GL4
		Fill Quantity: 2.0 litres.
	Counter shaft	Taper roller bearing.
	bearing Torque	27 Kg - m
	Input Torque capacity	Z/ Ng - III

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















Figure	Description		Va	alue
Kg	Weight ( With clutch housing)		42.5 Kgs W/O Oil	
	Play	1 <sup>st</sup> 2 <sup>nd</sup> 3 <sup>rd</sup> 4 <sup>th</sup> 5 <sup>th</sup>	0.175 0.175 0.175 0.175 0.175 0.18	Service limit(mm) 0.375 0.375 0.375 0.375
	Fork to clearances	groove	0.1to 0.4	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

NGT 530 4WD Version 1, Augl 06













**EXIT** 



**Transfer Case - Electric Shift** 

#### **Contents**

**Description** 

**Construction & Operation** 

Identification

**Trouble Shooting** 

Care of the system

Removal from the vehicle

**Dismantling** 

**Cleaning & Inspection** 

**Assembly** 

**Specifications** 

**Tightening Torques** 

**Special Tools** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio CRDe (All New)

Transfer Case - Electric Shift Jun. 07














**EXIT** 





Divgi-Warner's 4555 Transfer case is a two-speed, part-time electrical shift transfer case. The transfer case operates in a system. The system consists of:

- 1. Transfer case with Shift Motor, Speed sensor and Electric clutch.
- 2. Electronic Control Unit (ECU)
- 3. Mode selector switch and Indicator lights 4WH and 4WL on dash board
- 4. Harness to connect the above parts and power input. The power is received by input shaft, which is coupled with output shaft of transmission gearbox by matching splines. There are two outputs, one for

rear wheels and one for front wheels. Four selector positions are provided.

Position	Speed Ratio	Operation
2H - Two high position	1: 1	Only the two rear wheels are
		driven at 1: 1 speed ratio
4WH - Four high	1: 1	All four wheels are driven at 1: 1
position		speed ratio
4WL - Four low position	2.48:1	All four wheels are driven at 2.48:
		1 speed ratio

#### Construction & Operation -

Planetary gear set provides gear reduction. Power is transferred to the front wheel drive through a Morse HY-VO chain drive. Unit operates in an oil bath. An oil pump is used to provide positive lubrication to the planetary gear set and other upper output shaft components.

The different modes are obtained by rotating selector switch for selection. This in turn gives signal to Electronic Control Unit (ECU). ECU intelligently controls operations. It senses the conditions and shift transfer case in to the mode selected.

The control over the operations is obtained using Electronic Control Unit (ECU). It is housed below the driver's or co-driver's seat in .Rotary switch is provided for selection of different modes

2H - Two wheel high

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

















4H - Four wheel high

4L - Four wheel low

#### **Identification** -





All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC


















# **Trouble Shooting -**

Symptom	Causes	Remedial action
Electric shift problems	1. Faulty or damaged ECU, speed sensor, clutch or internal wiring	✓ Refer to self diagnosis
	2. Damaged or worn shift cam, hub, fork and rail shaft	<ul><li>✓ Overhaul and check for wear and damage.</li><li>✓ Replace if necessary</li></ul>
No front wheel drive when Shifted to 4WD.	1. Broken drive chain	✓ Check internal parts and replace if necessary
Noise in 4WD operation.	Oil level lower than minimum Required	Drain old oil and replace with Specified oil
Make sure noise is coming	Loosened bolts or mounting Parts	Re-tighten as specified
from Transfer case and not from clutch, transmission, drive shaft, Automatic	Noisy transfer case bearings	Disassemble bearings and parts and check for wear or damage. Replace if necessary
locking hubs or other Components.	Noisy gears	Check for wear and damage Including speedometer gear and replace if necessary
	Worn or damaged sprockets or drive chain	Disassemble and check for wear and damage. Replace if necessary
	Incorrect tire pressure.	Adjust tire pressure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC









Transfer case oil leakage	Cracked transfer case.	Replace the case.
	Leakage from other parts.	Clean case and parts and check For leakage.
	Breather barb clogging.	Remove breather barb and clean it. Replace if necessary.
	Oil level higher than required or improper brand of oil being used.	Use specified oil. Adjust oil level
	Loosened sealing bolts.	Re-tighten.
	Improper brand of sealant or improperly applied sealant	Use specified sealant and retighten.
	Worn or damaged oil seal	Replace oil seal

## Care of the System -

Oil level Check - every 10,000 Oil replacement interval - every 48,000 Kilometer's.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC












#### Removal & fitting on the vehicle -



- 1. Disconnect the wiring harness connection from the T/case
- 2. Lift up the vehicle.
- 3. Remove transfer case drain and fluid plugs. Drain all fluid and reinstall plugs
- 4. Disconnect speedometer cable connector and breather hose.
- 5. Lower the vehicle.
- 6. Support the transfer case with the jack and disconnect the front and rear propeller shafts from the transfer case
- 7. Remove the transfer case by removing the mounting nuts, attaching the transfer case to transmission

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















#### **Dismantling** -



Remove the Rear Output flange.



- Position the Transfer case on repair fixture.
- Holding the flange by flange holder, remove the nut and washer and then remove the flange and oil seal.
- Remove the two oil plugs from the cover.



Disassembly - Assembly Cover ( Motor, Speed sensor, Clutch coil and Speedo Gear.

- Remove bolts and remove Asm Motor, Speed sensor bracket and speed sensor.
- Separate clutch coil wire terminal from the connector and pull out from the sleeve.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC























Disassembly - Assembly Cover ( Motor, Speed sensor, Clutch coil and Speedo Gear.

 Remove the bolt and remove Speedo body and separate Assembly Speedo driven gear & shaft and Speedo body.



Disassembly - Assembly Cover ( Motor, Speed sensor, Clutch coil and Speedo Gear.

Remove oil seal, and speedo drive gear

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



























All copyrights reserved by Mahindra & Mahindra Ltd

Disassembly - Assembly Cover ( Motor, Speed sensor, Clutch coil and Speedo Gear.

- Remove the 9 bolts, and identification tag.
- Pry at the bosses provided on the cover and the case to break the sealant bond of the cover and the transfer case in such a way that the metal surface is not damaged.
- Remove the snap ring and pull out the ball bearing from the cover.
- Remove clutch coil from the cover.
- Pull out the needle bearing from the cover.
- Remove the magnet from the slot in the case.
- Remove the return spring. Clean and remove the sealant of


Scorpio SC - DC











the cover and case.

Be careful not to damage the metal surface.



## Disassembly - Lock-Up Shift Part

 Remove clutch housing from output shaft



#### Disassembly - Lock-Up Shift Part

Together slid 2W-4W lock up assembly and lock up fork from output shaft and separate fork assembly and Remove the two shift fork facings from the shift fork assembly, if required.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















### Disassembly - Lock-Up Shift Part

 To dismantle 2W-4W lockup assembly remove snap ring, lock up hub return spring from lock up collar.



# Disassembly - Reduction Shift Parts.

- Remove rail shaft from the case.
- Remove the reduction hub and reduction fork assembly from the case



# Disassembly - Reduction Shift Parts

 Remove the two shift fork facings from the shift fork assembly, if required.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

























#### Disassembly - Electrical Shift Cam Parts

- Remove Asm shift shaft from the case.
- Separate Cam, Spring, Spacer and shift shaft by pulling outward.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC






















#### Disassembly - Yoke and Output Shaft

- Holding the end yoke with the voke holder remove the nut, washer and then pull out the front yoke assembly.
- Remove the out put shaft.
- Press deflector from the yoke only if replacement is required.



#### Disassembly - Adapter, Input Shaft and Carrier Assembly

- Remove the breather barb.
- Remove the six bolts of adapter.
- Remove the adapter by separating the adapter sealer bond (pry front adapter, take care not to damage the adapter or the case).



#### Disassembly - Adapter, Input Shaft and Carrier Assembly

 Remove the adapter assembly, input shaft assembly and carrier gear assembly. (Expanding long ends of the snap ring, separate the carrier and input shaft assembly from the adapter.) Remove snap ring and oil seal from front adapter.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

**Transfer Case** Version 1, April 06















**EXIT** 











Disassembly - Adapter, Input Shaft and Carrier Assembly

- Remove snap ring and pull out Asm Input shaft and sun gear from Asm Carrier.
- After removing retaining ring, pull out the bearing and thrust washer from input shaft.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















1	
100	(0)
	0
	(4)
	0
1	0
1	0
	L'

Disassembly - Adapter, Input Shaft and Carrier Assembly

Remove the needle bearing and sleeve bearing from input shaft assembly, if required.



All copyrights reserved by Mahindra & Mahindra Ltd

Disassembly - Case

- Remove the oil seal.
- Remove the retaining ring and bearing.
- Remove the dowel pin from transfer case, if required.

Scorpio SC - DC

























Do not remove ring gear from the case.

#### Cleaning -

Before cleaning, check the magnet for the presence of metal Note: particles, which indicate internal chipping of the transfer case.

- ✓ Using a cleaning solvent, clean the old oil and dirt deposits
- ✓ After cleaning dry the parts with low-pressure (20 psi maximum) compressed air.
- ✓ Lubricate the ball bearings and needle bearing with ATF oil.
- ✓ Protect lubricated bearings from dust.

#### Inspection -

Always replace the hose coupling, O-ring and oil seal with new Note: parts.

✓ Visually check all the parts for damage.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

















✓ Referring to normal gear tooth face, specifically inspect the uneven wear and chips of gear tooth. Replace or repair if necessary.

#### Assembly -

Do not use hammer to drive in the oil seal and bearing. Use special tools for assembly.

Torque values are specified in the torque table.

Lubricate bearings, oil seals, O rings, bushings and matching metal parts before assembly.



**Assembly - Case** 



Insert the two new dowel pins.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















Assembly - Case



• Press the ball bearing into the case and install the retaining ring (snap ring).



Assembly - Case

• Install the new oil seal, by pressing it into the case.

Assembly - Case
Make sure that all parts are
correctly and firmly installed into
the case

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















#### Assembly - Yoke

 Position the output shaft in transfer case and install the end yoke assembly, seal, washer and nut.



## Assembly - Yoke

 Holding the end yoke by yoke holder, tighten the nut.

Turn the fixture for further assembly.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















Automotive Sector	
	Assembly - Reduction Shift Parts
	Install the two fork facing on the reduction shift fork assembly.
	<ul> <li>Assembly - Reduction Shift Parts</li> <li>Install the reduction hub in to the fork.</li> <li>Install reduction hub and fork in to the planet carrier.</li> </ul>
	Assembly - Reduction Shift Parts     Insert shift rail in reduction fork bore, to match with case bore.
	<ul> <li>Assembly - Electrical Shift Cam Parts.</li> <li>Insert spacer into torsion spring, insert the shift shaft into the spacer. Slide electric cam on to the shift shaft.</li> <li>Slide the torsion spring and spacer to the right of the shift shaft and position the end of the first spring to fix on the drive tang.</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC





















## Assembly - Electrical Shift Cam Parts

 Position the cam on the second spring and rotated anticlockwise.
 Push the end of the second spring to left with cam and fix it on the drive tang.



# Assembly - Assembly Output Shaft & Gerotor Pump

Align rotor slot of the pump and slot of the pump body in line.

- Slide the pump assembly on the output shaft over pump pin.
- Slip hose clamp over free end of hose coupling with strainer and push onto hose barb on pump and tighten.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Transfer Case Version 1 ,April 06





















# **Assembly - Assembly Output Shaft** & Gerotor Pump

Install the output shaft spline into the reduction hub and engage the output shaft end with input shaft bearing.

Couple strainer with case and insert the magnet into the transfer case slot.



# **Assembly - Chain Drive**

Position the drive sprocket to the rear output shaft end and driven sprocket to the front output shaft end.

- Install the drive chain onto the sprockets.
- Holding each sprocket with drive chain tight and parallel with transfer case, install the drive chain assembly to the output shafts.
- Rotate the driven sprocket slightly to engage splines on the

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

**Transfer Case** Version 1, April 06















**EXIT** 








Install the spacer to the front output shaft and insert snap ring into the groove over spacer.


front output shaft.



- Install two new facings to the fork.
- Engage the lockup fork in groove

2WD-4WD lock up assembly and slide this group down over drive sprocket and rail shaft.

• Install clutch housing on out put shaft.





All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

**Transfer Case** Version 1, April 06















**EXIT** 









# **Assembly - Assembly Cover**

Position the cover with the open end facing up on the table

- Position the end of needle bearing with the identification mark up and press into the cover (If removed).
- Press the ball bearing in to cover and install snap ring.



# **Assembly - Assembly Cover**

- Install the clutch coil assembly inside the cover, put wire bracket and tighten three nuts.
- Install speed sensor assembly to the cover.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Transfer Case Version 1 ,April 06


























Assembly - Assembly Cover Install the return spring over rail shaft

in the transfer case

 Apply 1.6 mm bead of Loctite RTV598 to the transfer casemounting surface.

For installation of cover, align the cover with transfer case. Do not use excessive force.

Install the cover into the transfer case

## as follows:

- Align the cover holes with the transfercase dowel pins
- Align the cover bearings with output

#### shafts

- Align shift shaft with cover boss.
- Align the cover blind hole with rail

shaft and make sure that return spring

is not cocked.

• Tighten nine bolts positioning

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Transfer Case Version 1 ,April 06
































 Install the motor to the shift shaft

and contact cover. Rotate the motor


clockwise direction to check correct Engagement.

- Install the bracket to the motor assembly and tighten three bolt.
- Tighten motor bracket bolt.





# **Assembly - Assembly Cover**





 Pass clutch coil wire through sensor

wiring sleeve, connect clutch coil terminal with the connector.

Install motor connector and sensor

connector to the motor bracket.

 Insert wiring in the respective Clip

and crimp it properly.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

**Transfer Case** Version 1, April 06





















 Install the Speedo gear over output shaft spline in the cover assembly



 Press the new oil seal into the cover assembly.



Position the flange on the upper output shaft in transfer case and install the flange, seal, washer and nut.



• Holding the flange with the help of flange holder, tighten the nut.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Transfer Case Version 1 ,April 06




















## **Specifications** -

Transfer Case 4555 (Electrical Shift)

Configuration Part time, Single Offset

Rear Output Configuration Circular flange Front Output Configuration Fixed Yoke

Input Configuration Female Spline Offset hand Right hand

Lubrication System Force lubrication by Gerotor pump

Fluid Type ATF

Castrol - TQ, IOC-A, Chemolium -A, Servo

Transfluid -A;

Housing Material Aluminum

Dry Weight in Kgs.

Fluid Capacity in liter

Shift Pattern

Shift Control

30 Kgs. Approx.

1.2 Approx.

2H - 4H - 4L

Selector Switch

4WDH Shift -on the Fly Yes

## <u>Tightening Torque's</u> -

Bolt location	Torque in Kgm ( Lbft)
Level & Drain Plug	2.8 - 4.2 (20 - 30)
Flange Nut	35 - 38 (250 - 275)
Front Yoke Nut	20 - 25 (150 - 180)
Case Bolts	2.8 - 4.2 (20 - 30)
Motor bolts, and coil nuts	0.8 - 1.1 (6 - 8)
Speedo body bolt	0.8 - 1.1 (6 - 8)
Breather Barb	0.8 - 1.9 ( 6 - 14)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Transfer Case Version 1 ,April 06





















# **Special Tools** -





Description	Borg & Warner Number
Yoke Holder 1	T-10001
Seal Driver 2	T-10003
Snap ring plier Adapter 3	T-10007
Snap ring plier 4	T-10006
Drift ball bearing 5	T-10053
Drift ball bearing Input shaft 6	T-10056
Drift NRB fitting Input shaft 7	T-10054
Drift Bush fitting Input shaft 8	T-10055
Drift NRB fitting Cover 9	T-10057
Repair Fixture 12	T-10037
Speedo body Oil seal driver 11	T-100-
Flange Holder 10	T - 10012

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Transfer Case Version 1 ,April 06













**EXIT** 





Propeller shaft

**General** 

**Trouble shooting** 

In car repairs

Care of the system.

**Repairs** 

**Specification & Wear Limits.** 

**Tightening Torque** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD




















## General -

The function of the propeller shaft is to transmit power from one point to another. The shaft is designed to transmit torque from transmission / transfer case to the axle.

The propeller shaft has to operate through constantly changing length while transmitting torque. The axle rides suspended by spring in floating motion. The propeller shaft must be able to change the transmission angle when going through the various road surfaces. This is done through Universal joints which permit the propeller shaft top operates at different angles. The slip joint or the yokes allow the countratction or expansion of the propeller shaft thus allowing the length to change.

The propeller shaft is built with the yoke lugs in line with each other, which is called phasing. This design produces the smoothest running condition. An out of phase shaft can cause a vibration.

The propeller shaft is 2 piece with a center bearing construction. The view of the split propeller shaft is shown below.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD




















The details of the center bearing are shown below.



While assembling the split propeller shaft -

- 1. Locate the center bearing assembly- keep the bolts loose in the slot of the chassis.
- 2. Locate & tighten the propeller shaft flange at the gearbox end.
- 3. Tighten the center bearings mounting bracket bolts.
- 4. Fit the rear propeller shaft.

This procedure is important; in order to avoid straining the center bearing Failure to do so will result in transmission noise and premature failure of the center bearing

# **Trouble shooting -**

Tyres that are out of round or wheels that are out of balance cause a low frequency vibration.

Brake drums that are unbalanced cause a harsh low frequency vibration. Driveline vibrations can also result from loose or damaged engine mountings.

All copyrights reserved by Mahindra & Mahindra I td

Scorpio - SC DC RHD



















Propeller shaft vibrations will keep on increasing as the vehicle speed increase. The propeller shaft does not cause a vibration that is present only in a narrow speed range.

Drive condition	Possible cause	Correction
Propeller shaft  Universal Joint	<ol> <li>Undercoating or other foreign on the shaft.</li> <li>Loose companion flange mounting bolts.</li> <li>Worn out yoke/slip joint.</li> <li>Excessive runout.</li> <li>Incorrect drive line angularity.</li> <li>Worn UJ bearings.</li> <li>Propeller shaft damaged or bent.</li> <li>Broken rear springs.</li> <li>Excessive runout or unbalanced condition.</li> <li>Excessive pinion shaft runout.</li> <li>UJ worn out</li> </ol>	Clean exterior of shaft & wash with solvent. Tighten the mounting bolts. Replace the joint/yoke. Check runout- replace shaft. Correct angularity. Replace the UJ. Replace the propeller shaft. Replace the rear springs. Reindex the propeller shaft by 180°, test and correct as required. Reindex the propeller shaft by 180°, test and correct as required. Reindex the propeller shaft by 180°, test and correct as required
Noise	33 World Out	Replace the 00

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD















<u>Unbalance</u> Runout

## **Unbalance** -

If the propellers shaft unbalance is suspected then it can be verified by the following procedure.

Removing & rendering the propeller shaft by 180° may eliminate some vibrations.

Clean all the foreign material from propeller shaft and the universal joint.
Inspect the propeller shaft for missing balance weight, broken welds and bent areas.  If the propeller shaft is bent then it must be replaced.
Ensure that the propeller shaft is not worn, are properly installed and are correctly aligned with the propeller shaft
Check the companion flange mounting bolts.
Raise the vehicle.
Remove the wheel & tyres.
Install the wheel nuts to lock the brake drum.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD





















Mark & number the shaft 6 inches from pinion end at four positions 90° apart.



Run and accelerate the engine until vibration occurs. Note the intensity & the speed at which the vibration occurs.



Install a screw clamp at position "1"



Start the engine and recheck for vibrations. If there is little or no change in vibrations then move the clamp or of the other 3 positions.

If there is no difference in vibration at the other position then the vibration is not due to the propeller shaft imbalance.



If the vibration decreases, install a second clamp and repeat the test.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD






















If the clamps cause an additional imbalance, separate the clamp (¼ inch above & below the mark.). Repeat the vibration test.



Increase the distance between the clamps until the vibration is at the lowest level.

At this position bend the slack end of the clamp so that it does not loosen. Install the wheel & tyres. Lower the vehicle.

If the amount of the vibration remains unacceptable then repeat the exercise at the Gearbox end.

## Runout -

Remove dirt, rust, paint & undercoating from the propeller shaft surface.
The dial indicator must be installed perpendicular to the shaft surface.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD






















Measure the runout at the center and at the ends - away from the weld.

Replace the propeller shaft if the runout is beyond the specified limit.

## Care of the system --

#### Caution:

Before undercoating a vehicle with any underbody protection. The propeller shaft and the UJ's should be covered. This will prevent the undercoating from causing an unbalanced condition and vibration.

Use the exact replacement hardware for attaching the propeller shafts. The specified torque's must always be applied when tightening the mounting bolts.

- ✓ The UJ to be greased at every service.
- ✓ The slip joint should be lubricated every 10,000 kilometer's

## Repairs --



### Lift the vehicle

Put aligning marks on the flange, UJ and propeller shaft before removal.

Do not use a punch to mark impression.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD





















Remove the mounting bolts at the pinion end



Remove the mounting bolts at the gearbox end.

It is important to protect the machined, external surface of the yoke from damage after propeller shaft removal. Any damage in the machined surface will lead to damage of the seal and cause a leak.



Remove the circlips holding the UJ in place.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD





















Applying the socket wrench on the outside of the propeller shaft flange, force out one end of UJ using a vise as shown. (One end 32 mm socket to receive other end 21-mm socket to push.)

While assembling- insert both ends then hold & press fit them with special tool.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD



















Description	2WD	4WD
Length (Joint to Joint) x O.D x thickness in mm		
Rear	1023.5x70x2	727.5x70x2
Front ( Diesel)		479.6x 44.45x3.25
Rear (GB -c/brg)-Split propellor	132.8x 63.5x2.1	
Rear ( center brg to axle) Split propellor	761.4x63.5x2.1	
Runout Diesel	0.5 mm TIR at center	
Runout ( Petrol)	0.4 mm TIR 75 mm from weld	

# <u>Tightening Torque</u> -

Location	Torque
Flange bolt	55-66 Nm
Center bearing mounting	72-105 Nm
bracket	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio - SC DC RHD

















## **Brakes**

Contents

**Description** 

**Trouble Shooting** 

Care of the system

In Car repairs

Working principle Assembly & dismantling of the Front Disc Brakes

Rear principle, Assembly & dismantling of the Rear Brake

Working principle Assembly & Dismantling of the master cylinder

Working principle of the brake booster.

Working principle <u>LSPV</u> Valve setting

**Parking Brake Description, Setting** 

**Specification & Wear Data** 

**Tightening** Torque's

List of the MST's.

**Recommended** Lubricants

















## **Description**

The brake system is vacuum assisted 'H'split type. The front brakes are twin pot calipers with ventilated rotor. The rear brakes are drum types with self-adjusting mechanism. The parking brakes are actuated in the rear through cable. Both the front disc pads and the rear brake liners are non-asbestos.

The braking system includes a Load sensing Proportioning Valve. It controls the brake fluid pressure going to the rear depending on the load on the vehicle. Normally when the vehicle is loaded and brakes applied; due to the weight transfer the load on the rear wheels become very less. In vehicles without the LSPV the full pressure of brake fluid going to the rear wheels tend to lock them. In vehicles with the LSPV, the LSPV reduces the brake fluid going to the rear depending on the load hence avoids the rear wheel locking. Since the rear wheel locking is avoided it results in reducing the braking distance (distance covered before the vehicle comes to a stand still)

The brake circuit is having an inbuilt bypass valve in the LSPV. In an unlikely situation of the front brake circuit failure; the LSPV valve is bypassed and the full pressure of brake fluid goes to the rear. This ensures that braking is achieved. The complete details about the LSPV valve & its functioning and setting are mentioned later.

# **Trouble Shooting -**

Preliminary checks involve inspecting fluid level, parking brake action, wheel and tyre conditions. Checking for obvious or external leaks or component damage and pedal response. A road test will confirm or deny the existence of the problem.

While road testing if the complaint involved low brake pedal, make several low speed stops and note if pedal comes back to normal height. Check the pedal response with gear in neutral and engine running. The pedal should remain firm under steady pressure. During road test make normal and firm brake stops in speeds of 40 to 60 Km/h. Note faulty brake operation such as pull, grab, drag, noise, low pedal, hard pedal, fade, pedal pulsation, etc.

All copyrights reserved by Mahindra & Mahindra Ltd

Main Menu l

Scorpio SC DC

















## Diagnosis -

## Pedal falls away

A brake pedal that falls away under steady foot pressure is generally the result of system leak. The leak point could be at a brake line, fitting hose, wheel cylinder or Master Cylinder Internal leakage's caused by worn or damaged piston, seals may also be the problem cause.

If leakage is severe fluid will be evident at or around the leaking component.

## Low pedal

If a low pedal is experienced, pump the pedal several times. If the pedal comes back up, worn lining and worn rotors or drums are the most likely cause. However, if the pedal remains low and / or the warning light illuminates then the problem is in the master cylinder, wheel cylinder, or calipers.

A decrease in master cylinder fluid may only be the result of normal lining wear. Fluid level will decrease in proportion to the lining wear. It is a result of the outward movement of caliper and wheel cylinder pistons to compensate for normal wear. Top up reservoir fluid and check brake operation to verify the complaint.

# Spongy pedal

A spongy pedal is most often caused by air in the system. However thin drums or substandard brake lining and hoses will also cause a condition similar to spongy pedal. The proper course of action is bleed the system or replace thin drums and suspect quality brake lining and hoses. In case the system has not been maintained as per recommendations and the brake hoses have not been replaced then due to swelling of the hoses during braking - it also causes spongy braking. In such a condition it is advisable to replace the hoses and replace all the seals and change the brake fluid.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















## Hard pedal or High pedal effort

A hard pedal or high pedal effort may be due to lining that is water soaked, contaminated, glazed or badly worn. Defective vacuum assistance will also cause hard operation. The vacuum booster or check valve (NRV) could also be faulty. Test the booster function. As detailed below —

- 1. Start engine & check booster hose connections as well as the EGR valve connections. Correct any vacuum leak before proceeding further.
- 2. Stop the engine and put in neutral.
- 3. Pump the brake pedal until all the vacuum in the reservoir is exhausted (normally after 6 to 8 pedal applications the brake pedal will become hard)
- 4. Press and hold brake pedal under light foot pressure
- a) If the pedal hold firm then proceed to step 5.
- b) If the pedal does not hold firm then and falls away then the master cylinder is defective.
- 5. Start the engine and note pedal action.
- a) If the pedal falls away slightly under light pedal action and then hold firm then proceed to step 6
- b) If no pedal action is discernable then vacuum pump or vacuum check valve is defective.
- 6. Rebuild the vacuum reserve as follows. Release brake pedal. Increase engine speed to 1500 rpm and then bring it to idle and shut off engine.
- 7. Wait for about 90 seconds and try brake action again. Booster should provide two or more vacuum assisted pedal applications. If vacuum assist is not performed then perform check for the check valve and booster.

Find the enclosed flow chart for reference -

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# TROUBLE SHOOTING OF VACUUM BOOSTER ASSEMBLY BASIC TEST

ENGINE OFF. Depress & release brake pedal several times to remove vacuum from Booster Assembly. After this the pedal application will feel hard to press.

Depress the brake pedal & hold with light pressure of @ 10kgs. & start the ENGINE

If the booster is functioning satisfactory, the pedal will fall slightly & then hold. Here less pressure will be needed to hold the pedal dawn.

IF THE BOOSTER IS NOT OPERATING Disconnect the vacuum hose from the NRV. Then with ENGINE RUNNING, check vacuum supply with a vacuum gauge. There should be at least 600 mm of Hg vacuum for Diesel & 500 mm of Hg for petrol vehicle.

If the BOOSTER is OPERATING pl. turn over & do the VACUUM LEAK TEST.

If VACUUM SUPPLY IS BELOW 600 mm of Hg for diesel & 500 mm of Hg for petrol veh. replace or repair vacuum hose & vacuum source.

When adequate vacuum supply is obtained, repeat basic test.

If VACUUM SUPPLY IS 600 mm of Hg for or more for diesel or 500 mm of Hg or more for petrol vehicle, then the booster is faulty & should be replaced.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















#### VACUUM LEAK TEST

Run engine to medium speed. Release accelerator & turn Engine OFF. This builds up vacuum.

Wait for 90 sec.& apply brakes. Two or more applications should be vacuum assisted.

IF APPLICATIONS ARE NOT VACUUM ASSISTED disconnect vacuum hose from vacuum source or NRV whichever is easier. If disconnected from NRV, attach short length of hose to valve.

IF APPLICATIONS ARE VACUUM ASSISTED there is no vacuum leak. DO THE HYDRAULIC LEAK TEST.

Blow into hose attached to NRV. If air passes through , valve is defective.

IF NRV or CHECK VALVE IS DEFECTIVE install new NRV & repeat VACUUM LEAK TEST.

IF NRV OR CHECK VALVE IS OK, vacuum booster is leaking & should be replaced.

#### HYDRAULIC LEAK TEST

Depress & release brake pedal several times . Then hold pedal depressed with medium pressure.

IF PEDAL FALLS AWAY hydraulic system is leaking. Check for external leakage at wheel cylinders, calipers, brake pipes, hoses & joints.

If there is no external leak, there may be an internal leak (master cylinder seals). Repair or replace parts needed to correct leak.

IF PEDAL DOES NOT FALL AWAY hydraulic system is not leaking.

CHECK VALVE OR NRV -- NON RETURN VALVE (MOUNTED ON VACUUM BOOSTER FT. FACE

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















## Brake drag

Brake drag occurs when the lining is in constant contact with the rotor or drum. Drag can occur at one wheel, all wheels, front only or rear only. It is caused by incomplete shoe release. Drag can be minor or severe enough to overheat the lining, rotor and drum.

Brake drag has a direct effect on fuel economy. Undetected minor drag can be misdiagnosed as an engine complaint. In case of severe drag it can also cause clutch slip.

Minor drag will usually cause slight surface charring of the lining. It can also generate hard spots in the rotor or the brake drum from the overheating/ cooling process. In most cases the rotors, drums, wheels, and tyres are quite warm to touch after the vehicle is stopped.

Severe drag can char the brake lining all the way through. It can also cause distort and score rotors and drums to the point of replacement. The wheels, tyre and brake components will be extremely hot. In severe cases the lining may generate smoke as it chars from overheating.

Some common causes of brake drag are:

- ◆ Loose or damaged wheel bearing
- Seized or sticky caliper or wheel cylinder piston.
- Loose caliper-mounting bracket.
- ♦ Loose mounting bolts of the rotor.
- Distorted brake drum or shoes.
- Rear brake shoes binding on worn/ damaged support plates
- Misassembled components
- ◆ Incomplete release of parking brake
- ♦ No free play
- Clogged master cylinder return port
- Broken master cylinder return spring
- ◆ Early lock of rear wheel due to change in setting distance of LSPV (Any change in rear spring camber can affect or also wrong setting.)

If the brake drag occurs at all the wheels, the problem may be related to a blocked master cylinder compensation port or faulty vacuum booster (binds does not release).

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















An improperly mounted brake light switch can also be a cause of drag. An improper mounting may prevent the brake pedal to return completely. This will cause the master cylinder feed port port to be blocked. The brakes would be partially applied causing the drag.

#### Brake Fade

Brake fade is a product of overheating caused by brake drag. However overheating and subsequent brake fade can also be caused by riding the brake pedal, making repeated high deaccelration stops in a short time span, Constant braking on steep roads also cause brake fade. If the brake lining is contaminated with oil or glazed then also the brake fading will take place.

#### **Pedal Pulsation**

Pedal pulsation is caused by components those are loose or beyond tolerance limits.

Disc brake rotors with excessive lateral runout or disc thickness variation, or out of round drums are the primary cause of pulsation. Other causes are loose wheel bearings or calipers and worn, damaged tyre

#### Pull

A front pull condition would be the result of:

- Contaminated lining in one caliper.
- Seized caliper piston
- Binding caliper.
- Loose caliper.
- Loose or corroded slide pin.
- Improper brake shoes
- Inadequate contact of pad.
- Damaged rotor
- Incorrect wheel bearing adjustment (at one wheel)
- Incorrect tyre inflation(High variations between two wheel)
- Shoe return spring weak or broken

A worn, damaged wheel bearing or suspension components are further cause. A damaged front tyre (bruised, ply separation) can also cause pull.

All copyrights reserved by Mahindra & Mahindra I td

Scorpio SC DC



















A common and frequently misdiagnosed pull condition is where the direction of pull changes after a few stops. The cause is a combination of brake drag followed by brake fade at the dragging brake unit.

As the dragging brake overheats, efficiency is so reduced as the fade occurs. If the opposite braking unit is still functioning then its braking effect is magnified. These causes pull to switch direction in favor of the brake unit that is functioning normally.

While diagnosing a pull in change in pull condition, remember that pull will return to the original direction if the dragging brake unit is allowed to cool down (and is not seriously damaged)

#### Rear Brake Grab

Contaminated lining, bent, or binding shoes and support plate usually causes rear grab (or pull). This is particularly true when one wheel is involved. However when both rear wheels are affected the master cylinder or the proptionating valve could be at fault.

## Brakes Do not Hold After Driving Through Deep Water Puddle

This condition is generally caused by water soaked lining. If the lining is only wet it can be dried by driving with the brakes lightly applied for 2 to 4 kms. However if the lining is both wet and dirty then it will be necessary to dismantle, clean and reassemble.

#### **Brake Fluid Contamination**

There are two causes of brake fluid contamination. The first involves allowing dirt, debris, or other liquid material to enter cylinder reservoir when the cover is off. The second involves adding to, or filling the cylinder with a non- - recommended fluid.

Brake fluid contaminated with only dirt, or debris usually retains a normal appearance. In some cases the foreign material will remain suspended in the fluid and be visible. The fluid and foreign material can be removed from the reservoir with a suction gun but only if the brakes have not been

All copyrights reserved by Mahindra & Mahindra I td

Scorpio SC DC



















applied. If the brakes are applied after contamination, system flushing will be required. The master cylinder may have to be disassembled, cleaned and the piston seals replaced. Foreign material lodged in the reservoir compensator/ports can cause brake drag by restricting the fluid return after application.

Brake fluid contaminated by a non recommended fluid will usually be discolored, milky, oily looking or foamy. In some cases it may even appear as if the fluid contains sludge. However remember that the brake fluid will darken in time and occasionally are cloudy in appearance. These are normal conditions and should not be mistaken for contamination.

If some type of oil has been added to the system then the fluid can separate into distinct layers. This can be verified by draining off a sample with a clean suction gun. Then pour the sample into a glass container and observe fluid action. If the fluid separates into distinct layers, it is definitely contaminated.

The only real correction for contamination by non-recommended fluids is to flush the entire hydraulic system and replace all the seals and the brake hose.

## Brake Noise -

# Squeak/Squeal

Brake squeak or squeal may be due to linings those are wet or contaminated with brake fluid, grease or oil. Glazed linings and rotor/drums with hard spots can also cause squealing. Dirt and foreign material embedded in the system will also cause squeak/squeal. Worn retaining pins can also cause disc pad to squeak/ rattle.

A very loud squeak or squeal is frequently a sign of severely worn brake lining (or the drum or the rotor). If the lining has worn to the rivets then metal to metal contact takes place. If the condition is allowed to persist then rotors/drums can become so scored that replacement is necessary.

# Thump/clunk

Thumping or clunking noise during braking are not caused by the brake components. In many cases such noises are caused by loose or damaged steering, suspension or engine components. However caliper that bind on

All copyrights reserved by Mahindra & Mahindra I td

Scorpio SC DC



















the slide surface can generate thump or clunk noise. In addition, worn out improperly adjusted, or improperly assembled rear brake shoes can also produce a thumping noise.

#### Chatter -

Loose or worn components or glazed/burnt lining usually causes brake chatter. Rotors with hard spots can also contribute to chatter. Additional causes of chatter are out of tolerance rotors, brake ling not secured properly to shoes, loose wheel bearings and contaminated brake lining.

## **Brake lining contamination -**

Brake lining contamination is usually a product of leaking calipers or wheel cylinders, driving through deep puddles, or lining that has become covered with grease and gravel during repair.

## Wheel & Tyre Problems -

Some conditions attributed to brake components may actually be caused by a wheel or tyre problem

A damage wheel can cause shudder, vibration and pull. A worn or damaged tyre can also cause pull.

Severely worn tyres with very little tread depth can produce a condition similar to grab as the tyre loses and recover traction.

Flat spotted tyres can cause vibration and wheel tramp and generate wheel shudder during brake operation.

A tyre with internal damage such as bruise or ply separation can cause pull and vibration

# **Defective Parking Brake** -

Can be caused by excessive brake lever play. Sticky parking cable, grease or oil on shoe, excess shoe clearance (normally caused by malfunction of automatic adjusting mechanism)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















## Care of the system -

The brake fluid should conform to DOT 3 specifications.

The brake fluid should be replaced once a year or every 40,000 Kms - which ever is earlier. This is because brake fluid is hygroscopic in nature hence it absorbs moisture. The normal braking operation also results in brake fluid getting heated. The process of heating and cooling also results in moisture. The brake fluid boiling point keeps coming down due to the presence of moisture hence if not changed it can cause higher corrosion of the wheel cylinders/ master cylinders/ brake tubes as well as spongy or poor braking.

Caution - Do not mix brake fluid of different brands. Do not use any brake fluid, which is kept in an open container. Always use brake fluid from a sealed container.

The brake fluid should not be contaminated with any mineral oil. Do not use reuse brake fluid that has just been bled.

The list of the recommended lubricants is enclosed at the end of the chapter.

# In Car repairs -

- a) Free Play Adjustment.
- b) Brake Bleeding.
- c) Front Pad replacement
- d) Rear brake shoe replacement.

## a) Free Play adjustment

Adjusting the pedal to booster push rod sets the free play adjustment.

## b) Brake bleeding

The sequence of the bleeding which has to be ensured is -

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















- 1. Rear left
- 2.Rear right
- 3.LSPV
- 4. Front left
- 5. Front right

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC


















#### For LHD Vehicles -



- 1. Rear left
- 2. Rear right
- 3. LSPV
- 4. Front right
- 5. Front left

The procedure at each of the bleed point is to pump 2 to 3 times; open the bleed screw1/4<sup>th</sup> turn,. Then close the bleed screw. Again pump 2/3 times then open the bleed screw keeping the pedal pressed down. Close the bleed screw and release the pedal. Repeat the operation until no bubbles are coming. The Bypass valve is inbuilt in the LSPV & it shold be bled at the time of bleeding.

It is also advisable to keep the engine running at idling so that the pedal travel is complete.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















#### Caution

Before opening the reservoir cap- clean the area of all dust and muck.

Before starting the bleeding - ensure that the parking brake is in released condition.

After bleeding each point put back the rubber cap.

Always use the brake fluid from an unopened container.

A pipe should be connected from the bleed screw to a clean container where the pipe other end is fully immersed in brake fluid. Doing the bleeding without the pipe can lead to improper bleeding as the presence of small bubbles can not be seen without the tube.

DO not reuse the bled fluid immediately. (It will have air bubbles entrapped.)

During the bleeding operation ensure that the master cylinder fluid level does not become below lower level. (It can draw air thus defeating the purpose of bleeding)

If the brake fluid has to be reused then it should be poured into a can using clean plastic pipe. The removed fluid should be kept without disturbing for at least 72 hours, so as to allow the air bubbles to get out. Later it is suggested to use chamois leather to strain the brake fluid.

## c) Front Pad replacement

Put the vehicle under hand brake in order to prevent from rolling.

## In Car Repairs -

Removal & Refitment of Brake pads --

Note: The Assembly sequence is the reverse of the dismantling sequence. Any special precautions to be taken while disssembling or assembly are indicated & shown later.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















## Replacement of the brake pads -



- 1. Loosen and remove the bolt Pin of the guide pin & swing up the caliper. (Check Point A)
- 2. Remove the old pads one by one.

### Check Points -



A)

While swinging down the caliper take care and see that the antisqueal shims are not damaged.

While fitting the guide pin ensure that the straight portion of the pin matches the with ear of the caliper body.

It is recommended to change the antirattle

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















clips at the time of pad change.

After tightening the bolt to torque.

Rotate the disc and ensure that the disc is free to rotate.



B)

Connect a transparent plastic pipe to the bleed screw on the caliper. Dip the other end of the pipe into a container filled with brake fluid.

Ensure the tip of the plastic pipe always remains dipped in the brake fluid.

Loosen the bleed screw & push both the pistons one by one into the caliper bore.

Ensure the pistons are pushed back fully into the caliper bore.

#### **Caution:**

Because the bleed screw is loosened to push the pistons of the caliper back, it is required to bleed the vehicle to retain the original brake performance of the vehicle.

#### CAUTION

If the pads are to be reused make sure they are assembled back in the same position as they were when removed i.e., inboard pad on to the piston side and outboard pad to the wheel side. This is possible only when at the time of removal these pads are marked for their positions and kept aside.

Never lubricate the pad seating areas as it may lead to jamming.

After fitting the pads, apply brake pedal 5 to 6 times in static condition in order to make the pads align properly.

The brake pads require nearly 200 Kilometer's of running for bedding in. Hence it is advisable that during the brake testing after fitting the new pads and also during the initial run, severe braking and / or continuous operation be avoided.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# Rear Brake liner replacement

Rear Brake liner replacement		
	Remove the wheel. The jacking point for rear axle is below the axle. Care must be taken to avoid any damage to the suspension links. Remove the brake drum after removing	
	the drum mounting screw.	
	Remove the parking brake cable lock.	
a a	If there is any difficuly in removing the drum; using a screw driver push the hand brake lever. A click sound will denote that the shoe setting is dropped. Now the drum can be removed using two puller bolts.	
	Detach the hand brake cable from the lever on the trailing shoe by moving the lever towards the centre of the brake. & remove the cable end from its location in the end of the lever	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Daniel de la constant
Remove the return spring (near the wheel cylinder) from trailing shoe.
Reduce the adjuster assembly to its minimum length by lifting the end of the pawl lever and rotating the serrated adjuster nut.
Remove shoe hold down springs and cup washers from the back plate by compressing the spring.
Slide both shoes off the wheel cylinder pistons. Care must be taken not to damage the rubber boots on the wheel cylinder. Detach the adjuster assembly and shoe return spring from the shoes.
<ul> <li>While riveting the new liners on to the shoe following care should be taken -</li></ul>

Main Menu

Scorpio SC DC
























Place one shoe on backplate & assemble pin shoe hold down cup. Fit one end of the shoe return spring - lower (abutment spring) in the slot provided on brake shoe.

Assemble the other end of the shoe return spring - lower (abutment spring) in the second shoe.



Hook the shoe return spring (short length coil) to the leading shoe with the adjuster assembly in its minimum length condition, assemble it in between the shoe webs.

Attach the other end of the shoe return spring to the opposite end of the trailing shoe.



Fit the pawl lever to the spring dowel inserting one leg of the pawl between male push rod end & shoe web of the leading shoe & the other end of the pawl leg resting on the adjuster nut.

Hook the short end of the spring into the hole in the pawl lever & use plier to attach the opposite end of the spring on to the shoe web.

#### Note -

Ensure proper resting of auto adjuster inside web & hand brake lever slot.

Ensure that the the auto adjuster pawl lever edge is properly located on tooth of auto adjuster wheel.

Connect the Parking brake cable in

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















reverse order of dismantling.
Centre the shoes relatively by tapping & moving upwards or downwards.
Before refitting the brake drum check that the drum thickness has not gone below 8.20 mm.
A thin brake drum will flex during braking reducing the braking efficiency and also it will cause improper functioning of the parking brakes.
Refit drum & wheels. Apply brakes few times to adjust the brake shoes.

# Working principle, Assembly & Dismantling of Twin Pot Caliper Assembly -

# **Description** -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















When the brake pedal is pressed then the hydraulic pressure pushes the two pistons to act simulatenuosly on the brake disc. The combined thrust provided by two pistons is much higher than the single piston caliper.

The sliding rail type carrier on which the twin caliper body slide easily to ensure that equal thrust is applied on both pads. A higher friction pad area improves the durability (life) of the friction material.

Disc brakes by their very nature & design are self adjusting to the wear and hence do not require brake adjustment to compensate the pad wear.

#### Servicing of Caliper -

- Apply hand brakes. Place wheel chocks on rear wheel
- Jack up the front of the vehicle and remove the front wheels by loosening / removing the wheel nuts.
- Disconnect the hose from the caliper by removing the banjo bolt



1. Loosen and remove the mounting bolts of the caliper.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















- 2. Remove the caliper assembly after removing the banjo bolt at caliper inlet port .
- 3. Loosen & remove the sliding pin bolts. Remove the pads. Separate the caliper sub assembly from the carrier sub assembly.

  Clean the caliper & carrier assembly externally with alcohol or fresh brake fluid.
- 4. Remove the caliper pistons from the bore by blowing dry compressed air through the inlet port of the caliper. Care must be taken to remove both the pistons at a time. Also to avoid the damage to the pistons, place a wooden block in front of the pistons.
- 4. Remove the boot.
- 5. Remove the seal- Pistons from the groove by using a blunt edged connector or feeler gauge. Take care druing seal removal the bore is not damaged.
- 6. Remove the bleed screw from the caliper body.

#### Cleaning & Inspection -

All the removed parts should be cleaned properly using fresh brake fluid or alcohol and kept in a clean tray.

NEVER USE ANY MINERAL OIL BASE FLUIDS LIKE KEROSENE ,DIESEL , PETROL etc,. FOR CLEANING OF REMOVED PARTS. DO NOT CLEAN THE BORE OF THE CALIPER WITH WATER OR STEAM.

#### Tips -

The Piston seals are to be lubricated with fresh brake fluid and assembled in to the seal grooves in the caliper bores. Make sure the seating of this is properly done. Then lubricate the outer surface of the pistons with fresh brake fluid.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















The piston boots are to be lubricated internally with the grease supplied in Caliper Repair Kits before it is assembled on the pistons.
Fit the boot into the groove in the caliper body. Locking of the rubber boot in the groove to be ensured. Expand the rubber boots & insert the pistons one by one into the caliper bore. The piston should be inserted into the bore in a straight position only. If it gets tilted while pushing, there is a chance that the piston will get jam half way & also can damage the seal.

# Servicing / Replacement of Sliding pin -



1. Separate the sliding pins from the carrier assembly .

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















- 2. Separate the rubber boots from the sliding pins.
- 4. Clean the sliding pins & sliding pin bores.
- 5. Check the sliding pins for bent / damage / rust. If found should be replaced with new ones.

# Discard all rubber parts.

Smear the pins and the pin bores with the special grease supplied in Kit.


Fit the pin boots on to the pins and assemble it on to the carrier bore.

Ensure proper location of the boot lip on to the carrier. Move the pins in and out 3 to 5 times in order to allow for the trapped air inside the bore to escape.

Repeat the above procedure for the other side caliper assembly.

# Inspection of the rotor -

1. Check the runout of the wheel disc in four places. Excessive lateral



runout will cause brake pedal pulsation and rapid unven wear of the brake pads.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















#### The maximum runout permissible is 0.12 mm

2. Disc Brake Rotor thickness variations: Variations in the rotor thickness will cause pedal pulsation, noise and shudder. It should be kept in mind that the disc rotor thickness variation is one of the primary causes for brake pedal pulsation.

# The maximum variation permissible is ± 0.012 mm

The rotor thickness should be measured in at least 6 different points around the rotor face. Position the micrometer approximately 15 mm from the outer edge.

#### Recondition on out of specification rotor -

The rotor/disc should be mounted in such that the lathe can take cut in both the face at the same time. <u>It is important to remember and note that a lathe which take cut only on a face will produce a tapered rotor.</u>

If the rotor requires only minor cleanup of rust, scale or minor scoring then use abrasive disc to clean up the rotor face. However when a rotor is scored or worn, machining with cutting tools will be required.

#### Caution:

Do not go below the minimum specified thickness of 21 mm.

Please ensure that whenever the disc is removed from the hub, then while fitting it back. Use the sealant METALOCK 343 or ANR124 from FEVICOL on the disc mounting bolts thread. Use new spring washers. Failure to do so may cause the mounting bolt to work loose.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















#### Working principle, Assembly & dismantling of the Rear Brake -



This brake is designed for use on rear wheels and is equally efficient in both forward and reverse direction of movement. A mechanical lever mechanism is incorporated for normal hand brake operation. The feature of this brake is that the brake shoe adjustment takes place automatically when the service brake is applied.

The leading and trailing shoes are connected at one end by a two-piston wheel cylinder and an adjuster assembly. The adjuster assembly consists of a male and female push rod with an adjuster nut operated by a pawl. Coupled on the trailing shoe is a hand brake lever, which pivots on a pin at the wheel cylinder end of the shoe.

A spring dowel fitted at the leading shoe provides a pivot for the pawl lever, which is retained in position by a spring hooked on to the web. The hand brake cable passes through a hole in the back plate, and the slotted cable end fits in the end of the hand brake lever. When the hand brake is applied, the cable pulls the lever and this movement is transferred via the adjuster assembly to the shoes, which move outwards onto the drum. When the foot brake is operated, both the shoes are pushed on to the drum by the wheel cylinder pistons. As the shoe linings wear, the outward

All copyrights reserved by Mahindra & Mahindra I td

Scorpio SC DC



















movement of the shoes exceeds a predetermined amount and the pawl pivots on the spring dowel to rotate the adjuster nut. This action lengthens the adjuster assembly sufficiently to reduce the clearance between the brake shoes and drum to the desired minimum. The adjustment is repeated, whenever necessary, according to the rate of lining wear.

Dismantling & assembly consist of:

# Shoe removal & Wheel cylinder overhaul -

	For removal and refitting the brake liner. Refer to Rear Brake Liner replacement section.
	Disconnect the brake Bundy tubes.
O COO	Remove the rubber boots at the ends of the wheel cylinder.
	Remove the pistons along with the spring.
	Check the bore of the cylinder for any pitting or scuffing- if so then the wheel cylinder will need to be replaced.
	Check the piston for any deep scoring or scuffing.
	Before assembly clean the wheel cylinder and piston with alcohol or clean brake fluid.
	Do not attempt to clean with any mineral oil. Any trace of it left will

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















contaminate the brake fluid and reduce the life of the all the rubber components of the hydraulic system.
It is advisable to fit the parking brake cable on the slot in the trailing shoe before assembling it on the back plate
Before refitting the brake drum check that the drum thickness has not come below 8.20 mm.  A thin brake drum will flex during braking reducing the braking efficiency and also it will cause improper functioning of the parking brakes.

Working principle, Assembly & Dismantling of the Master Cylinder -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















The center Flow master cylinder, Suitable for ABS system is made of aluminum body with the brake fluid reservoir coupled on to the Master cylinder.

The Tandem Master Cylinder is designed to operate dual line hydraulic systems .It consists of two independent hydraulic chambers working in series and should one chamber or circuit develop a fault, the other remains operative.

In the normal-"Brakes-off" position, the brake fluid can flow unrestricted between the dual line systems and separate chambers in the integral fluid reservoir. Fluid movement to the Independent cylinders is controlled by two valves-(center valves). Hence CF/ CF Master cylinder. When the brake is applied the push rod pushes Master Cylinder primary plunger of the bore.

This master cylinder is divided in to two chambers . The primary train is composite assembly and is resting on stop washer through a connecting pin. Connecting pin is rectangular in section and has a hole at center . One end of the valve stem passes through this hole. The connecting pin is assembled in to the circular hole on primary plunger.

The poppet valve train consists of poppet valve assembled on the valve stem. This composite assembly is ahead upon by a valve spring. The end of the valve spring is resting on the distance sleeve. The distance sleeve is held rigidly with the plunger by 6 or 8 crimps on the plunger.

A similar arrangement is provided for secondary train also. The secondary plunger has a center slot into which the stop pin reciprocates. A cover plate is assemble in-between the secondary grommet and connecting pin to prevent falling off of connecting pin from cylinder body. This plate also acts as a baffle and reduces the velocity of fluid jet that will emerge form secondary feed ports on return.

Secondary and primary plunger train moves as a composite assembly. At this juncture the poppet valve (centre valves) of both primary and secondary close the respective sealing faces of the plunger and pressure is developed.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















During further stroke of the primary plunger, the primary spring is compressed and pressure is developed. The pressurised fluid is forced though pipelines to the calipers and wheel cylinders.

When the brake is released, the master cylinder plungers move back creating partial vacuum in front of poppet valves (center vlaves) deseating by deflecting poppet spring and the port are opened and the brake fluid can again move unrestricted between separate systems and the fluid reservoir.

#### Servicing of Master Cylinder -

As the TMC is of CV/CV (Center Valve type) design; the TMC can be serviced using only Major Repair Kit. The assembly procedure is in the reverse order of disassembly.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















- 1. Remove the Reservoir Fixing Pin by tapping it carefully.
- 2. Remove the Reservoir Assembly from grommets.
- 3. Using a blunt edge screw driver; remove the reservoir grommets.
- 4. Press the Primary Piston in the bore using a hylem rod & remove the circlip.
- 5. Gently remove the Primary Piston assembly.
- 6. Hold the TMC in upside down condition & by pressing Secondary Piston gently; remove the stop pin from secondary feed port of TMC assembly. (If any problem is observed while removing the stop pin; push the Secondary Piston gently using a hylem rod & gently tap the TMC from the Secondary Feed port side on a wooden block.)
- 7. Remove the Secondary Piston assembly.

#### Caution -

Use only fresh brake fluid for cleaning.

If contamination is observed in the seals (seals would have swollen and the size would have enlarged compared to the new seals) ensure all rubber parts in the system including rear wheel cylinder seals, front caliper seals and the front and rear rubber hoses must be discarded and the entire system to be flushed with new brake fluid.

ENSURE THAT THE TMC FLANGE SURFAE IS FREE FROM DIRT, DENT & BURR BEFORE MOUNTING IT ON TO THE BOOSTER.

# NOTE -

- 1. It is essential that reservoir cap must be removed and cleaned. While assembling the reservoir cap ensure the presence of filter in the reservoir.
- 2. After fitting TMC on to the vehicle / vacuum booster, the outlet pipes are to be connected and torque tightened.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















#### Working principle of the brake booster -



Note -- The Booster is a non- serviceable Unit & it should never be tampered with.

Ensure booster out put rod is correctly aligned to the primary piston bore during the coupling of TMC to the booster.

The Scorpio vehicle is equipped with a Tandem type vacuum booster to assist driver's effort. This is achieved by using vacuum from the vacuum pump provided on alternator in case of diesel engines & from inlet manifold in case of petrol engines.

A pair of diaphragms is provided between the two shells of the booster & difference of pressure on two sides of diaphragms (one side vacuum & other side atmospheric pressure) gives mechanical advantage. This amplifies the driver's pedal effort while braking.

The booster assembly & TMC assembly are coupled with the help of two nuts & washer. The meting dimensions of booster & TMC are factory set. Hence -

Do not alter the height of the output rod of the Vacuum Booster unit at any stage and ensure Booster out put rod is correctly aligned to the primary piston bore during the coupling of TMC to the booster.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















#### Working principle of LSPV Valve -

#### **Description** -

The load on a vehicle governs the amount of braking which can be applied to the rear wheels, before locking-up and sliding occurs. As the load can vary between unladen to fully laden, it is sensible to assume the braking pressure which can be applied, should also be varied.

The LSPV senses the weight on the rear wheels and adjusts the braking pressures accordingly, even if by weight transfer, the alteration occurs during braking. The valve is fitted in the rear line and has no effect on the front brakes. At front circuit failed condition, rear circuit receives 100% of inlet pressure.

Working of Valve - Please refer the attached figure.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















#### Working of Valve -

At front circuit healthy condition, fluid pressure from the master cylinder passes through the open valve to the rear brakes. As pressure in the rear brakes increases, it loads the valve piston until the pressure is sufficient to overcome the combined load from internal spring and sensing (control) spring. The plunger then moves down allowing valve seal to close, thus preventing further pressure going to the rear brakes. The pressure increases to the rear brakes is a proportioning of the increase to the front brakes and these rapid controlling movements are repeated as long as the pressure from the master cylinder continues to rise.

At front failed condition, valve is always open. 100% fluid pressure from the master cylinder passes through the open valve to rear brakes completely.

#### Maintenance Precautions -

LSPV is a non-serviceable unit & should be replaced if any problem arises.

During vehicle servicing control spring setting should be checked & corrected if required with the help of an 'Installation gauge 'provided for the purpose. The stretched length of the control spring should be set at 92.5 mm with the help of Installation gauge.

The correct setting of Control Spring ensures adequate oil pressure to rear circuit & thereby ensures no skidding of rear wheels.

# Do's & Don'ts -

Do's	Don'ts
Check LSPV setting whenever the	No other spring setting except
vehicle is reported to the Workshop	the control spring is to be
for servicing. Spring setting to correct	disturbed in field. Main spring
length should be done by stretching	setting should not be disturbed
the control spring to the	as it is set in factory & any
manufacturer's specification by	change in the setting of this
loosening the nut provided on rear axle	spring can lead to
bracket & retightening after correct	malfunctioning of LSPV & result

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















setting.

While doing any suspension job (when the chassis of the vehicle is lifted) or whenever the vehicle is lifted on a two post lift, remove LSPV Control spring from the hooking on rear axle. LSPV is a non-serviceable unit & should not be opened in field. If any problem arises this unit is to be replaced.

in brake locking on rear.

If the leaf springs are removed from vehicle putting Axle stands below the chassis the whole rear axle will float downwards & result into overstretching of LSPV control spring. This also can lead to malfunctioning of LSPV.

The LSPV setting needs to be carried out if:

- -The axle has been removed.
- -LSPV Valve replaced.
- -Any change in rear suspension carried.

# Procedure for fitting and setting the LSPV Valve -

Mount the LSPV valve on the bracket in the chassis. Fit all the hydraulic connections

Caution: Before fitting / setting the LSPV valve ensure that the

- Vehicle unladen condition. Fuel tank is assumed to be ¾ full.
- Before doing the fitment/setting run the vehicle through rough road / normal road for 5 to 10 kms. This is essential for the spring/ bushes to settle.



Remove the 'e' clip.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC























Remove the Washer.





Put the projecting pin of the tool in the eye of the spring & allow the tool to hang freely..

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

**Brakes** Version 1, Aug 06















**EXIT** 







Loosen the nut & move the bolt in such away that the bolt is alligned & enters in the slot on the tool.

Retighten the nut in such a way			
that the bolt is in the correct			
position as indicated by the tool.			
Remove the tool .			
Pull down the spring and locate the			
eye in the bolt.			
Ensure that the spring is sitting			
properly in its position.			
Fit the washer & the 'e' clip.			

# Parking Brake -- Description, Setting -

The parking brake is cable actuated and acts on the rear brakes. On applying the parking brake the parking cables are pulled and they act on the trailing shoes at the lower end. Since the shoe is pivoted on top it result in actuation of the trailing shoe. Due to the scroll plate the force also gets transmitted to the leading shoe.

Based on the slackness in the system the parking brake is manually adjusted by readjusting the adjusting stud and lock nut.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# Specifications & Wear data -

Figure	Description	Value
1 iguic	Disc pad Usable thickness	8.5 max
	Replace disc pad if worn out thickness less than	9 mm
	Disc pad Material	Rane R808 asbestos free
	Rotor thickness	24 mm
	Minimum disc thickness	21 mm
	Runout of rotor face- permissible limit	0.12 mm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Figure	Description	Value
	Disc thickness variation allowed	± 0.012 mm
	Rear Drum thickness	8.20 to 8.35 mm
	Minimum thickness of brake drum	8.20 mm
	Maximum taper/ bell mouthing of brake drum	0.05 mm
	Rear brake lining Usable thickness	3.5 mm to 4.3 mm

Scorpio SC DC



















Figure	Description	Value
0 0 0 0	Replace when lining thickness falls below Minimum Usable thickness of	0.2 mm.
	Brake shoe Lining Material	Sundaram Asbestos free 3691
	Setting length (By setting gauge)	92.5 mm
	Master cylinder I.D	26.99 mm
	Wheel Cylinder I.D Wheel Cylinder I.D	25.4 mm
	Brake disc O.D	298 mm

Scorpio SC DC

















Figure	Description	Value
	Rear Drum I.D	282.2 mm
	Boost ratio-tandem booster	7.5
	Booster size Tandem	8 + 9 inch
	Clearance Adjustment- Front Rear	Automatic Automatic
	Free Play of the Brake Pedal	3 mm

Scorpio SC DC

















# Tightening Torque's -

Description	Torque Value
Front Brake Caliper Mounting	24 Nm (18 lbf-ft)
Bolts	
Sliding Pin Bolts	$27 \pm 5 \text{ Nm} (20 \pm 4 \text{ lbf-ft})$
Banjo Bolt - Caliper	24 Nm (18 lbf-ft)
Brake pipe connectors -	18 ± 4 Nm (13 ± 3 lbf-ft)
Master Cylinder	`
Vacuum Booster - Mounting	$21 \pm 7 \text{ Nm} (15 \pm 5 \text{ lbf-ft})$
Nuts	
Brake Pipe connectors - Wheel	$21 \pm 7 \text{ Nm} (15 \pm 5 \text{ lbf-ft})$
Cylinder	
LSPV Banjo Bolt	24 ± 2 Nm (18 ± 1 lbf-ft)
LSPV Brake Pipe Connectors	18 ± 4 Nm (13 ± 3 lbf-ft)

















# Special Tools --

# Description/ Part No./ Sketch **Usage View** Tool for removal of Brake shoe hold down spring MST - 570 Tool for removal of return spring. MST - 569 Tool for LSPV setting MST - 568

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















# **Recommended Lubricants -**

Specification:

Castrol: DOT 3

TVS Girling: DOT 3

Sealant:

METALOCK 343 or ANR124 from FEVICOL

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















**Rear Axle** 

**Contents** 

**Description** 

**Trouble Shooting** 

Care of the axle

In Vehicle Adjustment & Repair

Rear axle Overhaul

**Specification** 

**Tightening Torque's** 

**Special Tools** 

**Lubricant** 

All copyrights reserved by Mahindra & Mahindra Ltd



Rear Axle Version 1, Aug 06



















**Automotive Sector** 

#### **Description** -

The rear axle is of the hypoid, semi-floating type using shim adjustment to obtain bearing pre-loads. The differential case with Crown wheel and the drive pinion are mounted in opposed taper roller bearing in one-piece rear axle carrier.

The rear axle pinion receives its power from the engine through the Transmission and driveshaft. The drive pinion rotates the differential case through the engagement with the crown wheel, which is bolted, to the differential case flange. Inside the differential cages are four differential pinions mounted on the differential pinion shaft which is splined to the housing. These gears are engaged with the side gears, to which the axle shafts are splined. Therefore as the differential housing turns, it rotates the axle shaft and the rear wheel. When it is necessary for one wheel to rotate faster than the other is, the faster turning gear causes the pinion to roll on slower turning gear to allow differential action between the two axle shafts.

The axle shafts are held in the housing by the bearings and the retainers at the housing outer end. Axle shaft endplay is pre set and not adjustable. The hub bearings are prepackaged for life.

(i) All operations other than the removal of the axle shafts and the replacement of the wheel bearing oil seal should be carried out with the axle removed from the vehicle.

# **Trouble Shooting -**

Certain rear axle and driveline trouble symptoms are also common to the engine, transmission, tyres and other parts of the Vehicle. For this reason be sure that the cause of the trouble is in the rear axle before adjusting, repairing or replacing any of the axle parts.

# Rear Axle Noise Diagnosis -

Basic characteristics in a rear axle are more difficult to diagnose and repair than mechanical failures. Slight axle noise heard only at certain speed or under particular conditions must be considered normal. Axle noise tend to

All copyrights reserved by

Scorpio SC DC

Rear Axle Version 1, Aug 06



















**Automotive Sector** 

peak or be more pronounced at particular speeds and the noise is in now way a sign of the trouble in the vehicle.

Where noise is present in objectionable form (Loud and/ or at all speeds) the first effort should be to isolate the noise.

Isolation of noise in any one unit requires care and experience and an attempt to eliminate a slight noise may baffle even the most experienced mechanic/ technician.

Axle noise fall into two basic categories: gear noise and/ or bearing noise.

Axle Noise

<u>Gear Noise</u> <u>Bearing Noise</u> Others

#### <u>Gear Noise</u> –

The most important characteristic of the gear noise is that it is usually sensitive to accelerator position. E.g. noise audible under drive condition will often disappear under coast condition (i.e. driving in neutral with the clutch released and engine running) at the same vehicle speed and vice versa.

Axle gear noise whine will always occur at the same road speed and throttle setting i.e. drive or coast (i.e. driving in neutral with the clutch released and engine running). Gear whine is usually a fairly high pitched pure tone as opposed to a low-pitched rumble caused by a spalled bearing.

Some noises, which can be confused with axle gear whine, are: -

- .... Whine from an engine component; this will always occur at the same engine speed irrespective of which transmission gear is used
- .... Whine from an indirect Transmission gear (e.g. 5th gear on some vehicles produces a whine comparable with axle whine) however this will disappear when the direct transmission ratio is selected.
- .... Whine from tyres or wind noise from a rack or aerial. These noise generally occur over a very broad speed range and do not change with

All copyrights reserved by

Scorpio SC DC

Rear Axle Version 1, Aug 06











Search







**Automotive Sector** 

driving mode i.e. drive or coast (i.e. driving in neutral with the clutch released and engine running)

#### Remember

#### Before diagnosing the whine as axle gear noise, ensure that the whine:

- (a)Occurs in direct transmission ratio (4th gear)
- (b) Changes with throttle/ accelerator variations (drive and coast) (i.e. driving in neutral with the clutch released and engine running)
- (c) Always occur at the same road speed and not engine speed,
- (d) Occurs over a limited vehicle speed. (This can vary over a wide band should the axle be in extremely bad condition.)

#### **Bearing Noise-**

Bearing noise is inclined to be less throttle sensitive than gear noise and frequently occurs over a wide speed range. Bad cases of faulty bearings can, in fact be detected from walking speed, building up in pitch as speed increases and is not directly affected by changing from drive to coast (i.e. driving in neutral with the clutch released and engine running) and visa versa

- (a)Rear wheel bearing noise tends to be low pitched grumble, which can normally be detected and confirmed when driving on a smooth road at constant speed, with the noise most audible while swerving sharply from left to right. If the noise increases or decreases as the car is swerved, it is probable that a wheel bearing is faulty. Driving close to a wall or a curb at a suitable speed can carry out a further check for wheel bearing noise.
- (b) Differential bearing noise is usually similar to in pitch to wheel bearing noise but is not affected by the swerve check referred to previously.

All copyrights reserved by

Scorpio SC DC

Rear Axle Version 1, Aug 06



















(c)Pinion bearing noise is normally at a higher pitch than wheel or differential bearings and is often slightly sensitive to throttle position, although not to the same extent as gear noise.

#### Other:

- 1. A further condition, which can exist, is due to a worn bearing that allows the gearset to move out of its correct mesh cause gear noise. This condition is usually throttle sensitive, with the noise frequently disappearing on a "drive" condition.
  - Any amount of or endplay in either the pinion bearings or differential carrier bearings are detrimental to the gears and bearings and will cause axle noise.
- 2. A high spot sometimes occur on either the ring gear or the drive pinion; this shows up as a ticking or light knocking noise over a restricted range of throttle position. The frequency of the noise will indicate whether the high spot is on the pinion (drive shaft frequency) or on the ring gear. The severity of the noise indicates the size of the defect. A light "tick " is seldom detrimental and usually occurs in new axle and will normally disappears once the axle has been run in.
- 3. Louder noise usually indicate a more serious defect and a knock occurring in an axle which was previously free from this type of noise must always be investigated.

# Care of the axle -

The lubricant level should be checked every 10000 Kms with the vehicle unladen and in a level ground. The lubricant level should be at the lower edge of the filler plug. Use lubricant meeting oils specification of GL 5 and viscosity of SAE 90 .The brand names have been specified in the <u>lubricant</u> section.

All copyrights reserved by

Scorpio SC DC

Rear Axle Version 1, Aug 06



















Note: Unless otherwise specified the assembly procedure / guidelines is the reverse of the disassembly procedure

#### IN VEHCILE ADJUSTEMENT & REPAIR -

The works in axle that can be done without removing from the vehicle are:

Replacement of pinion seal.

**Backlash adjustment** 

# Replacement of Pinion seal -



Remove the propeller shaft from the companion flange



Using the MST 216, Lock the companion flange.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Rear Axle Version 1, Aug 06
















**EXIT** 





Unlock the pinion nut
Remove the companion flange along with the dust cover
Using screwdriver take out the old oil seal- take care not to damage the seating / contact areas/
Fit the new seal using the dolly.  Apply oil on lip and ensure that seating are has been wiped clean and free of burrs

# Backlash adjustment.

The backlash adjustment should not be done on the vehicle. This is due to the fact that the spreader usage in vehicle is difficult if the vehicle isn't being attended in a pit. Further after adjustment it may be necessary to adjust pinion height. (Any change in backlash indicates wear- hence though shim adjustment may compensate for gear teeth wear. It will not compensate the pinion wear and pinion bearing wear and loss of preload)

However it is suggested that the tooth contact be checked on the vehicle



before taking decision to overhaul. It is recommended that after draining the oil and opening the rear cover. Put paint marks in four different places. Then push the vehicle forward and backwards at least 15 feet. This will give a much better tooth contact under load. (It should be remembered that

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Rear Axle Version 1, Aug 06



















with load the tooth contact moves away from toe to heel). The tooth contact without load is given in the specification sheet.)

#### Rear axle Overhaul -

Comprises of the following major steps

- 1. Removal & Refitment of the axle from the vehicle.
- 2. Removal of the Refitment of the hub and the brake carrier and oil seal.
- 3. Removal of the differential assembly.
- 4. Pinion height adjustment and preloading of pinion bearings
- 5. Assembly of the crown wheel.

# Removal and Refitment of the axle assembly from the vehicle -

	Support the body on stand and		
	remove the tyres.		
	Remove the shock absorber.		
	Remove the brake pipe T clamp		
	from axle		
	Remove the LSPV spring from		
	axle end		
	Loosen U clamps		
	Axle to be supported & should not fall		
Remove the axle from the vehicle			

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# Removal & Refitment of the rear axle shaft & hub --



Remove the brake drum after loosening the two screws



Remove the parking brake locking



Loosen the 6 screws holding the retainer.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















Using the MST576 and the sliding hammer MST 577. Pull out the hub integral with the axle shaft, prepackaged bearing, retainer ,oil seal and carrier
For removal of the bearing the locking collar has to be cut using a drill. It should be cut up to the end and then using the chisel it should be snapped open
Remove bearing using the hydraulic press and the MST.
While assembly use the MST 578 to support the bearing & tube MST 579 for pressing

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Rear Axle Version 1, Aug 06














**EXIT** 







All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















The assembly section is shown in the sketch attached. Please note the bearing direction the circlip



DO NOT ATTEMPT TO FIT THE LOCKING COLLAR BY HEATING.

THE COLLAR IS HARDENED AND TEMPERED.HEATING & PRESSING MAY CAUSE IT TO LOOSEN IN SERVICE CAUSING MAJOR FAILURE

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC























While reassemble use the hole in axle shaft flange to tighten the retainer bolts.

Please ensure that the hydraulic press is capable of at least 10 tons load and it has a adequate stroke.

#### Removal of the Center assembly -



After draining the oil - remove the differential cover set screws.



Remove the differential side bearing bolts



Remove the side bearing caps,

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Rear Axle Version 1, Aug 06













Search







Mahindra
Automotive Sector

Additionive Sector	
H	Using MST 205, expand the differential.
	Pull out the crown along with the bearings
	Using MST 216, lock the companion flange.
	Unlock the pinion nut.
	Remove the companion flange along with the dust cover
	Tap the pinion along with bearings,

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















#### Assembly of the Center assembly -

#### Using the special tool

#### Without the special tool

Preloading of the crown wheel and backlash adjustment.

# The pinion preload setting and tooth contact setting can be done by using:

- a) **Special Tool**. The special tool and gauges are strongly recommended in either of the scenario
- new axle housing is used or
- the bearing seating surface has worn out.
- b) Without the use of special tools. This can be done only if the crown wheel & pinion is being replaced in the existing housing and the crown wheel bearing seating and the pinion inner bearing seating area is not worn.

### 4 a) Assembly Using the Special Tools -

	If the pinion bearings are having pitting, flaking or spalling of the raceway then they have to be replaced.	
	Remove the outer race using the MST	
	( For Fitting use MST 200)	
To measure the Z value (distance of pinion apex from the carrier		

All copyrights reserved by

Main Menu

center)

Scorpio SC DC






















Place the setting gauge (MST 581) in the carrier (the pinions inner bearing outer race & shim should be removed) Please note that the lifting handle should be removed after placing it in position



Place the setting gauge 2 - MST 582 (in the crown wheel bore)



Measure the gap between the setting gauge 1 and 2 using a feeler gauge.



Ensure that the gauge 582's face is parallel to the differential case. (Use a level gauge)

For example if the thickness measured X is 12 thou

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















75	The value etched in pinion is Y Then the shim value is X-Y In this example it will become 12-5= 7 thou		
	Place the 7thou shim below the bearing seating area.		
	After that cross check the gap between the gauge and the new pinion. It should be the same as the Z mark punched. In this case 5 thou (tolerance ± 1 thou)		
	In case the Z value is -ve then the gap has to be checked between the bore & MST 582.		
This will ensure that the tooth contact of the Crown wheel and pinior is accurate  However this shim also affects the distance between the two pinior bearings and thus will affect the pinion bearing preload.			
	Suppose 10 thou of shims were the thickness originally present (at the height adjusting end and the new value is 12 thou.)		
	Hence to maintain the pinion bearing preload equal amount of shims at the outer bearing end will have to be adjusted		

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

end.

Rear Axle Version 1, Aug 06













bearing has increased by 2 thou hence add 2 thou of shims from the other








If the pinion preload is not as per the specifications after assembly then add or remove shims from the outer bearing end.
Please note that if the shims are removed or added at the outer end for adjusting the preload then do not add or remove shims at the height adjusting end- that will disturb the contact.
Before inserting the companion flange at the end- apply <b>Loctite 638</b> in the splines so that the loosening can be avoided.

# 4 b) Only if the crown wheel & pinion are being replaced - no wear on seating surfaces is present -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Note the Z value etched on top of the old pinion (O) and the Z value etched on the top of the new pinion (N)
The correct shim thickness = O-N (Old-New)
If the value is + then shims have to be added and if - then shims have to be removed. These shims are between the pinion inner bearing outer race & the housing.
This will ensure that the tooth contact of the Crown wheel and pinion is accurate
However this shim also affects the distance between the two pinion bearings and thus will affect the pinion bearing preload.
Suppose 2 thou of shims are adjusted. E.g + 2 added
Then to maintain the pinion bearing preload equal amount of shims at the outer bearing end will have to be adjusted Since the shim thickness at the inner bearing has increased by 2 thou hence add 2 thou of shims at the other bearing
If the pinion preload is not as per the specifications after assembly then add or remove shims from the outer bearing end.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Please note that if the shims are removed or added at the outer end for adjusting the preload then do not add or remove shims at the height adjusting end- that will disturb the contact.

#### Adjustments of the crown preload & tooth backlash -

|--|

Install the crown, in the carrier. Instead of using the bearings use MST 583, - one on each side.

The advantage of using the MST instead of bearings while setting is that as the outer race does not keep getting tilted hence we get accurate reading further the bearings do not get damaged when they are removed after checking the values of shims required.



Push the crown assembly towards the pinion so that the backlash is zero.

In this position find the shim pack which has to be inserted on right (Back of crown) side. And also on the teeth side.

Move shims from teeth side to back of the crown side so that the backlash is achieved.

Add an additional 0.075mm (0.003")-of shim on the both the side so that

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















the crown teeth get preloaded.		
Take out the assembly, keep the selected shim packs correctly.		
Remove the MST 583.		
Insert the bearing assembly along with the selected shim pack. Use MST 205 to spread the carrier.		
While using the spreader ensure that the expansion is not more than 0.5 mm. If more it can cause permanent deformation of the carrier.		
While assembling the caps ensure that the markings match.		
Torque- 9.6 to 12.5 Mkg ( 70 to 90 Lbft)		
Check the backlash, if less or more then the shims should be moved from one side to the other.		
Note: Approximately 5 thou shim is equal to 3 thou of backlash.		
Check the backlash.		
0.13 to 0.25 mm ( 0.005"-0.010")		
Check the runout in four places it should be less than 0.15 mm (0.006")		

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















After the backlash has been achieved, check the tooth contact on both the drive and the reverse side.

Note since the crown wheel is without load hence the contact should not be exactly at center but as shown in the sketch.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# **Specifications** -

Figure	Description		Value	
	Semi floating single re	eduction wi	thout diff	. lock
		High end/Petro l	Mid range	Low range
	No of teeth on crown N1	48	_	0 opt)
Ц	No of teeth on	10	i	1
	pinion N2 Axle reduction ratio N1/N2	4.88	4.55( optional	4.09
	No of teeth on	From SI no 32 K 90710 ( All mode except Ro 116)	)	
	crown N1 No of teeth on	43		
	pinion N2 Axle reduction ratio	10		
	N1/N2	4.3		
	Pinion Pre load	23 to 45 Kg	gcm	
	Preloading of differential bearings	0.075 mm	( 0.003"	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Automotive Sector		
Figure	Description	Value
	Crown-pinion backlash	(0.005 to 0.008"
	Maximum variation of backlash in a crown	(0.003")
	Run out of the ring gear / crown wheel	
	Hub end play	Max 0.3 mm ( 0.0012")
	Hub rotational torque	Not applicable
Toe Heel 6 mm aprox	tooth contact on both the forward and reverse direction	Check on both the driving & reverse flank. This contact is for checking without load.
	Clearance between and side( sun) gears and diff case	0.20 mm (0.008")
	Rotational torque of differential case with sun & pinion gears	5 Kg cm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Figure	Description	Value
	Inner race interference Outer race clearance	0.125 mm (0.005 to 0.007")
	Oil grade/ Viscosity/ Quantity	GL 5/ SAE 90/ 1.65 liters

# <u>Tightening Torque's</u> -

Location	Torque in Nm ( Lbft)	
Brake carrier mounting bolts	33.8 to 47.45 (25 to 35 LB FT)	
Pinion nut	217 to 244 (160 to 180 LB FT )	
Crown mounting nuts	54 to 68 (40 to 50 Lb Ft)	
Differential side bearing bolts	95 to 122 (70 to 90 LB FT)	
Differential disc cover bolts	16 to 20(12 to 15 LB FT )	
Oil filling bolt / Drain bolt	47.5 ± 6.5 Nm ( 35±6 lb-f)	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC


















# Special Tools --



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















Automotive Sector	
Description / Part No. / Sketch Tube-Rear axle collar pressing MST 579	Usage View
Installer Inner Oil seal Rear axle tube MST 580	
Rear axle Pinion Height setting Gauge (1) MST 581	

All copyrights reserved by Mahindra & Mahindra Ltd



Rear Axle Version 1, Aug 06













**EXIT** 





Description / Part No. / Sketch	
Rear axle Pinion Height setting	
Gauge (2) MST 582	





**Usage View** 

Differential side bearing setting gage MST 583





All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















### **Recommended Lubricants -**

Specification: GL 5; SAE 90

#### **Brands**

Maximile : Recommended	Maximile DO
Other options	
IOC	SERVOGEAR HP 90
HP	HP GEAR OIL XP 90
BPCL -	BHARAT SPIROL HD 90
BHARAT SHELL -	SPIRAX HD 90
CHEMOLEUMS -	CHEMOLEUMS TURBO GL5 SAE 90
GULF	MP GO 90
CALTEX	THUBAN GL5-90
VEEDOL	VEEDOL MULTI GEAR 90 HD
CASTROL -	CASTROL HYPOY B 90

## <u>Sealant</u> -

Differential cover sealant: Loctite 587 / Gasket



















Chassis

**General** 

**Inspection** 

**Inspection Data** 

Frame repair

**Tightening torque** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Chassis Version 1, Aug 06





















# <u>Description</u> -

The chassis has C in C pressed and welded section. The section in the center is largest. The front & rear have smaller section. This feature ensures optimum chassis design for the loads in the given section.

The cross members connect the side members to each other.

#### Frame alignment -

Normally frame misalignment is happens only due to:

- ♦ Collision
- Excessive overloading.

An improper frame alignment will affect axles alignment thus influencing the tyre wear. It will also affect the door closure & window operation. In severely misaligned frame it will affect the vehicle handling.

Frame Inspection & Measurement

## **Inspection** -

Before proceeding with measurements, inspect all component for visible damage and other damage.

All damaged areas must be repaired or replaced.

#### Measurements -

Measure the frame for misaligned with body attached to the frame. The inspection sketch attached gives the alignment reference dimensions.

However before proceeding with any measurements, the following precautions have to be taken.

All copyrights reserved by

Scorpio SC DC

Chassis Version 1, Aug 06



















Place vehicle on level ground.

The vehicle is in unloaded conditon. With full fuel tank. If any extra fittings have been fitted. Please remove them. (E.g. winch) Measure the tyre inflation pressure. Keep it as per recommendation (Front 2.0 and rear 2.2)

#### Diagonal frame measurement's -

- ✓ Select reference points along one frame long member. It is suggested that the body mounting points be used.
- ✓ Transfer these points to the surface floor with a plumb bob. (Attaching paper sheets below on the ground will improve the measurements accuracy)
- ✓ Locate the reference point on the other long member.
- ✓ Measure the frame outer distance in front and the frame outer distance in rear.
- ✓ Move the vehicle away.
- ✓ Measure the distance between all the reference points diagonally. The measurement should not vary more than 10 mm
- ✓ Divide the distance between the front outer points and the rear frame outer points. This gives the center of the frame.
- ✓ Join the center of the frame width at front and the center of the frame width at rear. Place a chalk line between these two points. This gives the centerline of the chassis.
- ✓ Determine how close to centerline is to diagonals intersection point.
- ✓ The reference mark on the floor will provide an illustrated indication of the degree of misalignment.
- ✓ A reference point transferred from one side's long member may be 5 mm ahead or behind the reference point from the opposite long member.
- ✓ Frame bow to the side should not exceed 5 mm per 2540 mm in length.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Chassis Version 1, Aug 06




















#### Inspection points -



INSPECTION SKETCH FOR CHASSIS WITH BODY OUTRIGGERS

Measurement of Independent Front suspensions points.

Take the measurement of the IFS points as shown in the sketch. And using the same procedure of marking.





















The dimension for the LCA bracket front & rear is the same.



unassis Version 1, Aug 06













## Frame Repair -

It is not recommended to repair the chassis frame. In case of any bend. Twist due to accident collision: if the bend is beyond the specified limits then it has to be replaced.

## <u>Tightening Torque's</u> -

Chassis outrigger to Body Mounting :  $45 \pm 0.5$  Nm (33  $\pm 0.4$  lb. ft)

















#### Front Axle

**Contents** 

**Description** 

**Trouble Shooting** 

Care of the axle

In Vehicle Adjustment & Repair

Rear axle Overhaul

**Tightening Torque's** 

**Lubricant** 





















The front axle is of the hypoid, semi-floating type using shim adjustment to obtain bearing pre-loads. The differential case with Crown wheel and the drive pinion are mounted in opposed taper roller bearing in one-piece rear axle carrier.

The rear axle pinion receives its power from the engine through the Transmission and driveshaft. The drive pinion rotates the differential case through the engagement with the crown wheel, which is bolted, to the differential case flange. Inside the differential cages are four differential pinions mounted on the differential pinion shaft which is splined to the housing. These gears are engaged with the side gears, to which the axle shafts are splined. Therefore as the differential housing turns, it rotates the axle shaft and the rear wheel. When it is necessary for one wheel to rotate faster than the other is, the faster turning gear causes the pinion to roll on slower turning gear to allow differential action between the two axle shafts.

The axle shafts are held in the housing by the bearings and the retainers at the housing outer end. Axle shaft endplay is pre set and not adjustable. The hub bearings are prepackaged for life.

All operations other than the removal of the axle shafts and the replacement of the wheel bearing oil seal should be carried out with the axle removed from the vehicle.

## **Trouble Shooting -**

Certain rear axle and driveline trouble symptoms are also common to the engine, transmission, tyres and other parts of the Vehicle. For this reason be sure that the cause of the trouble is in the rear axle before adjusting, repairing or replacing any of the axle parts.

## Rear Axle Noise Diagnosis -

Basic characteristics in a rear axle are more difficult to diagnose and repair than mechanical failures. Slight axle noise heard only at certain

All copyrights reserved by

Scorpio SC DC



















speed or under particular conditions must be considered normal. Axle noise tend to peak or be more pronounced at particular speeds and the noise is in now way a sign of the trouble in the vehicle.

Where noise is present in objectionable form (Loud and/ or at all speeds) the first effort should be to isolate the noise.

Isolation of noise in any one unit requires care and experience and an attempt to eliminate a slight noise may baffle even the most experienced mechanic/ technician.

Axle noise fall into two basic categories: gear noise and/ or bearing noise.

Axle Noise

<u>Gear Noise</u> <u>Bearing Noise</u> Others

#### Gear Noise -

The most important characteristic of the gear noise is that it is usually sensitive to accelerator position. E.g. noise audible under drive condition will often disappear under coast condition (i.e. driving in neutral with the clutch released and engine running) at the same vehicle speed and vice versa.

Axle gear noise whine will always occur at the same road speed and throttle setting i.e. drive or coast (i.e. driving in neutral with the clutch released and engine running). Gear whine is usually a fairly high pitched pure tone as opposed to a low-pitched rumble caused by a spalled bearing.

Some noises, which can be confused with axle gear whine, are: -

.... Whine from an engine component; this will always occur at the same engine speed irrespective of which transmission gear is used

.... Whine from an indirect Transmission gear (e.g. 5th gear on some vehicles produces a whine comparable with axle whine) however this will disappear when the direct transmission ratio is selected.

All copyrights reserved by

Scorpio SC DC




















.... Whine from tyres or wind noise from a rack or aerial. These noise generally occur over a very broad speed range and do not change with driving mode i.e. drive or coast (i.e. driving in neutral with the clutch released and engine running)

#### Remember

Before diagnosing the whine as axle gear noise, ensure that the whine:

- (a)Occurs in direct transmission ratio (4th gear)
- (b) Changes with throttle/ accelerator variations (drive and coast) ( i.e. driving in neutral with the clutch released and engine running)
- (c) Always occur at the same road speed and not engine speed,
- (d) Occurs over a limited vehicle speed. (This can vary over a wide band should the axle be in extremely bad condition.)

#### Bearing Noise -

Bearing noise is inclined to be less throttle sensitive than gear noise and frequently occurs over a wide speed range. Bad cases of faulty bearings can, in fact be detected from walking speed, building up in pitch as speed increases and is not directly affected by changing from drive to coast (i.e. driving in neutral with the clutch released and engine running) and visa versa

(a) Rear wheel bearing noise tends to be low pitched grumble, which can normally be detected and confirmed when driving on a smooth road at constant speed, with the noise most audible while swerving sharply from left to right. If the noise increases or decreases as the car is swerved, it is probable that a wheel bearing is faulty. Driving close to a wall or a curb at a suitable speed can carry out a further check for wheel bearing noise.

All copyrights reserved by

Scorpio SC DC



















- (b) Differential bearing noise is usually similar to in pitch to wheel bearing noise but is not affected by the swerve check referred to previously.
- (c)Pinion bearing noise is normally at a higher pitch than wheel or differential bearings and is often slightly sensitive to throttle position, although not to the same extent as gear noise.

#### Other -

- 1. A further condition, which can exist, is due to a worn bearing that allows the gearset to move out of its correct mesh cause gear noise. This condition is usually throttle sensitive, with the noise frequently disappearing on a "drive" condition.
  - Any amount of or endplay in either the pinion bearings or differential carrier bearings are detrimental to the gears and bearings and will cause axle noise.
- 2. A high spot sometimes occur on either the ring gear or the drive pinion; this shows up as a ticking or light knocking noise over a restricted range of throttle position. The frequency of the noise will indicate whether the high spot is on the pinion (drive shaft frequency) or on the ring gear. The severity of the noise indicates the size of the defect. A light "tick " is seldom detrimental and usually occurs in new axle and will normally disappears once the axle has been run in.
- 3. Louder noise usually indicate a more serious defect and a knock occurring in an axle which was previously free from this type of noise must always be investigated.

## Care of the axle -

The lubricant level should be checked every 10000 Kms with the vehicle unladen and in a level ground. The lubricant level should be at the lower edge of the filler plug. Use lubricant meeting oils specification of GL 5 and viscosity of SAE 85W140 .The brand names have been specified in the lubricant section.

All copyrights reserved by

Scorpio SC DC


















Note: Unless otherwise specified the assembly procedure / guidelines is the reverse of the disassembly procedure

#### **IN VEHCILE ADJUSTEMENT & REPAIR -**

The works in axle that can be done without removing from the vehicle are:

#### CV joint servicing -

Remove the upper ball joint & tilt the corner assembly. Now remove the CV joints from the vehicle.

Mark the position of small end of boot on shaft for reassembly purpose.
Remove the boot clamps & discard.
Cut the rubber boots & discard.
Inspect the grease. If presence of water, grit or metal particles or any other contaminant found the CV joint should be replaced.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Automotive Sector	
	Wipe awayexcess grease so that the snap ring in the inner race is visible. Remove the snap ring by expanding it with a snap ring plier.
	Remove the shaft by tapping on the outer race with a brass hammer.
	Place the CV joint in vice jaws with teflon or plastic proctectors to prevent damage to the splines.
	Assemble the disassembly tool set to the joint.
	Tilt the inner race from side to side in a crisscross or star pattern.
	Remove all steel balls from the cage, one at a time using a star pattern.
	Pivot cage & remove the inner race assembly from outer race assembly.
	Pivot inner race & remove from the cage.

Inspect all parts for wear or damage. Wear or damage to any part indicates replacement of CV joint is necessary.

## While reassembly; following sequence should be followed -

- Clean CV joint components & boot area on shafts. DO NOT USE PETROL.
- Apply tape to shaft splines to protect boot during installation.
- Slide new small circlip & boot on one side of the shaft having one circlip groove.
- Lightly coat inner & outer race with lithium grease.
- The assembly sequence for CV joint is in the reverse order of disassembly.
- Install new snap ring in inner race.
- Completely pack CV joint with grease.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















- Allign CV joint splines with shaft splines. Gently rock the CV joint while pushing onto the shaft untill click sound is heard.
- Position the boot & clamp over CV joint (large end) & secure with the clamp.
- Insert blunt edged screwdriver between shaft & small end of the boot to equalise air. Allign boot marks on shaft. Install & tighten the small clamp.

#### Pinion Seal Replacement -



Pinion nut removal

Oil seal removal

#### Backlash adjustment.

The backlash adjustment should not be done on the vehicle. This is due to the fact that the spreader usage in vehicle is difficult if the vehicle isn't being attended in a pit. Further after adjustment it may be necessary to adjust pinion height. (Any change in backlash indicates

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















wear- hence though shim adjustment may compensate for gear teeth wear. It will not compensate the pinion wear and pinion bearing wear and loss of preload)

However it is suggested that the tooth contact be checked on the



vehicle before taking decision to open/ overhaul. It is recommended that after draining the oil and opening the rear cover. Put paint marks in four different places. Then vehicle forward push the and backwards at least 15 feet. This will give a much better tooth contact under load. should be (lt remembered that

with load the tooth contact moves away from toe to heel). The tooth contact without load is given in the specification sheet.)

### Front axle Overhaul -

Comprises of the following major steps

- 1. Removal & Refitment of the axle from the vehicle.
- 2. Removal of the Refitment of the hub and the brake carrier and oil seal.
- 3. Removal of the differential assembly.
- 4. Pinion height adjustment and preloading of pinion bearings
- 5. Assembly of the crown wheel.
- 1) Removal and Refitment of the axle assembly from the vehicle

Support the body on stand and
remove the tyres.
Remove the shock absorber.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















Axle to be supported & should not fall

Remove the axle from the vehicle

## 2) Removal of the Center assembly



After draining the oil - remove the differential cover set screws.



Remove the side bearing caps, note mating letters stamped on caps & carrier.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

























Using special tool expand the differential.

Do not spread carrier over 0.58 mm.



Pry differential case from carrier with pry bars. After differential case has been removed; remove the spreader.

lock the companion flange.

Unlock the pinion nut.

Remove the companion flange along with the dust cover.

### 3) Assembly of the Center assembly

Using the special tool

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















### 4 a) Assembly Using the Special Tools


The setting can be divided into three phases.

Pinion height setting . Pinion preload. Crwon preloading. Crown backlash setting.

Pinion height setting.



The tool used to do the same is



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















Automotive Sector Pinion preloading:


The pinion preloading is done by the collapsiable spacer.

Note: In case the pinion nut is opened then the spacers need to be changed.

Crown Wheel Preload & backlash



First the play of the diff cage or crown wheel with diff cage but without the pinion in place is checked. This play is A



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















Then the play B with the Diff gear & pinion in place is meausred



The right hand play is C C= A-B

To get the preload on both LH & RH side 3thou shims are added.

Now to get the backlash 6 thou shims are added on RH side & 6 thou shims are removed from LH  $\,$ 

( Recommended preload- 3 thou. Backlash- 6thou )

An example of the working is given below:

















# WORKSHEET FOR CALCULATING RING GEAR BACKLASH AND DIFFERENTIAL BEARING PRELOAD SHIMS

 Total play observed ( Without crown wheel )
 = A

 Left hand play ( With crown wheel )
 = B

 Right hand play = ( A - B )
 = C

This is just an exmple for understanding the calculation with values rounded off to nearest decimal

Case 1.

Suppose A = 0.070" (1.75 mm)
B = 0.040" (1.01 mm)

C = 0.070" - 0.040" = 0.030" ( 0.74 )

Blacklash Calculations -

A B C 0.070" ( 1.75 mm ) 0.040" (1.0160 mm ) 0.030" ( 0.762mm ) + 0.003" ( 0.0762mm ) + 0.003" ( 0.0762mm ) + 0.006" ( 0.1524mm ) + 0.006" ( 0.1524mm ) + 0.006" ( 0.1524mm ) 0.037" ( 0.9398mm )

RH Side

LH Side

Case 2.

Suppose A = 0.085" (2.159 mm)
B = 0.055" (1.397 mm)

C = 0.085" - 0.055" = 0.030" ( 0.762mm )

Blacklash Calculations -

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# Tightening Torque's -

Location	Torque in Nm ( Lbft)
Brake carrier mounting bolts	33.8 to 47.45 (25 to 35 LB FT)
Pinion nut	217 to 244 (160 to 180 LB FT )
Crown mounting nuts	54 to 68 (40 to 50 Lb Ft)
Differential side bearing bolts	95 to 122 (70 to 90 LB FT)
Differential disc cover bolts	16 to 20(12 to 15 LB FT )

### **Recommended Lubricants -**

Specification: GL 5; SAE 85 W 140

<u>Sealant</u> -

Differential cover sealant: Loctite 587 / Gasket

















### **Front Suspension**

**Description** 

**Trouble Shooting** 

**Care** of the system

In Car repairs

Working principle, Dismantling & Assembly of the Front Suspension 4WD

**Specification & Wear Data** 

**Lubricants** 

**Tightening Torque's** 

List of the MST's

Main Menu




















In the 4WD vehicles, the suspension is torsion bar type with hydraulic dampener.



# **Trouble Shooting -**

A squeak noise from the shock absorber can be produced if movement between the rubber bushing and metal occurs. Tightening the attaching parts can usually stop this noise. If the squeak noise persist then inspect for worn or damaged bushings and attaching components. Repair as necessary if any thing found amiss.

Squeak also happen due to relative movement from suspension arm's bush inner sleeve (serration end) and chassis bracket. This situation happens, if

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















torque is not as per specs. Torque tightening the LCA & UCA bolts normally resolves the issue.

The shock absorber bushings do not require any kind of lubrication. Do not lubricate the bushings to reduce bushing noise. Grease or mineral oil base lubricants will deteriorate the bushing.

The shock absorbers are not refillable or adjustable. If a malfunction occurs, the shock absorber must be replaced. To test a shock absorber hold it upright in fully extended position for 10 minutes. Then force the piston in and out of the cylinder four or five times. The action throughout each stroke should be smooth and even.

Symptom	Causes	Remedial action
		<ul> <li>✓ Check and adjust:</li> <li>✓ Hub end play</li> <li>✓ Camber to be checked and adjusted.</li> </ul>
One Edge Wear	Excessive camber	
		<ul> <li>✓ Check &amp; correct Toe In</li> <li>✓ Check the chassis bend</li> <li>✓ If tyre rotation not carried out as per schedule. Do the tyre rotation.</li> </ul>
Feathered Edge Wear	Incorrect Toe In	
Excessive Vehicle rolling	<ol> <li>Body Mounts loose.</li> <li>Suspension mounting loose.</li> <li>Broken or</li> </ol>	mounts. ✓ Tighten the suspension mounts.

All copyrights reserved by

Scorpio SC DC

Front Suspension Version 1, Aug.06













**EXIT** 





	deteriorated stabilizer 4. Worn stabilizer	replace ✓ Replace the bushes & tighten to the specified
	bush 5. Malfunctioning shock absorber	torque, ✓ Replace the shock absorber.
Vehicle inclined	Broken or deteriorated coil spring	✓ Replace the coil spring
Noise	1. Parts worn or loose	✓ Tighten the parts or replace
	2. Broken coil spring	<ul><li>✓ Replace the coil spring</li><li>✓ Replace the shock</li></ul>
	3. Malfunctioning shock absorber	absorber

Caution: Do not lubricate the suspension bushes/joints.

### Care of the system -

- ✓ The first wheel alignment should be carried out at 5000 kms then at every 10,000 Kilometer's.
- ✓ Torque tighten the LCA & UCA bolts to the required torque. (Upper arm 110-130 Nm, LCA front 150-180 Nm; LCA rear 110-130 Nm)
- ✓ First at 5000 Kilometer then subsequently every 10,000 Kilometer's.
- $\checkmark$  Check the shock absorber for leaks every 10,000 Kms.
- ✓ Check the rubber bushes for the mounting of the shock absorber, stabilizer bar and links every 20,000 Kilometer's or once in a year

# In Car repairs -

- a) Wheel alignment
- b) Wheel hub greasing
- a) Wheel alignment

The sequence of the wheel alignment, which should be followed, is:

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC









Carry out the runout compensation when using the computerized equipment

- 1. Steering Wheel Centralize- cross check & adjust.
- 2. Castor checking & adjustment ( Computerized / Manual)
- 3. Camber checking & adjustment( Computerized / Manual)
- 4. Toe in checking & adjustment. ( Computerized / Manual)
- 5. Wheel Turning Angle, checking and adjustment. (Computerized / Manual)
- 6. *Check* the centralization of the Steering wheel as the final operation

Caution: In order to obtain the correct values and avoid complaints. Please note that that the following parameters have to be adhered to without fail:

- ◆ The tyre pressures in all the four wheels are as per the specifications.
- Vehicle should be unladen and parked on level surface
- Ensure that the wheel hub play is correct.
- ♦ Check that the chassis and the underbody are not coated with mud. If in doubt get the vehicle cleaned before doing the checking.
- ◆ Check the ride height variation as per the specification.
- Replace the parts of suspension if found badly damaged
- Before starting the measurement, ensure that the parking brakes are applied and the rear wheels are blocked
- Before doing the wheel alignment ensure that the linkages i.e. the ball joint are not worn or loose. Check the free play in the steering.
- All the tyres and the wheel disc should be of the same type.

Caution: This procedure for centralizing the Steering wheel is valid only if the misalignment of the spokes is less than 10 degrees. In other words this procedure is only for fine-tuning the steering wheel position not for glaring error. If it is more 10 degrees then remove the steering wheel and initially realign to less than 10 degrees.

# **Steering Wheel Centralization -**

To d	check for the centralization
of the	ne steering wheel. Drive the
vehi	cle on a level road surface;
note	the angular position
(mis	alignment of the steering
	el spokes.

All copyrights reserved by

Scorpio SC DC



















Automotive Sector	
	Raise the vehicle. Keep the wheels in Straight Ahead Position.
	Mark the position of the track rods and the track rod ends
	Slacken the track rod end lock nuts and also remove the gaiter outer retaining clips.
	Rotate both track rods in the same direction approximately 30 degrees for every 1-degree of steering misalignment error.
Clock wise error Clock	If the steering wheel has an anti clockwise angular error then both track rods must be rotated clockwise- when viewed from the left - hand side of the vehicle.
Clock wise error Wise err	

With the computerized wheel alignment gauges; the checking procedure may vary slightly. However the sequence of checking and the adjustment procedure remains the same. The most common error made while doing the wheel alignment using the computerized equipment is that the wheel run out

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















compensation procedure is not carried. That is one of the reasons of poor repeatability

The computerized wheel alignment machines, which have been approved by M&M, are of Precision or Manatec make. It is mandatory that the wheel alignment machine be calibrated at regular interval specified by the individual Manufacturer.


Wheel alignment using computerised gauge (Photos are with Manatec )



Start the computerised alignment machine. Move the cursor to the alignment name and press enter.



Enter the details of the details as displayed on the screen, the vehicle code can be selected from the list by pressing the F3 button on the key board. For moving to the other details press "enter" or "tab". Press "F5" when all the details are entered.



State the tyre and the bearing condition. The condition can be selected by moving the up or down arrow keys. For selecting particular condition press enter. For going to the next tyre condition press "tab" key. When the conditions are selected press "F5" key

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















From the alignment menu select two wheel Alignment, since our vehicle have fixed alignment at the rear.



Fix the sensors on the rear as well as front wheels.

#### Caution:

While fitting the sensors ensure that the clamps are properly tightened.


The right sensors are in place, sensors are marked with right and left side.



Ensure that the bubble in the spirit level of the rear sensor is set in the center of the marking made on it.

Jack up the front wheels.

Loosen the knob on the sensor.



For the runout press the runout key on the sensor as shown in the figure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















Move the tyre in the direction as shown on the screen by holding the sensor, after completing half rotation press the run out key on the sensor complete the remaining rotation.



**Caution:** Move the tyre slowly and smoothly.



The front wheel run out will be displayed, press "enter" key to continue.



Remove the lock-pins of the turning table

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















For achieving the straight ahead position move the steering wheel slowly to the directions as displayed on the screen first to the right and the to the left. Hold for some time at the end, for the computer to acquire data. Hold for some time at the centre position. Fix the steering lock at that Press "enter" position. kev continue.



Press "enter" key to continue. The values of Castor, camber, and toe will appear.



The castor & the camber are adjusted by addition or removal of

The Toe is changing the track rod end distance. When done press "enter" key.

	The sequence of adjustment which have to be carried is Castor Camber
	Toe in adjustment
For adju	sting the Castor
	The values should be within 2.75
	°±1.00 (2°45'± 1.0°)
	The difference between the two
	wheels should be within ±45'
	The adjusting shims are available in

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Automotive Sector	
	1.6, 0.4-mm thickness.
	Addition of shims in front between
	the fulcrum lever and the chassis
	bracket will reduce the castor
	Dracket with reduce the easter
	Addition of shims in rear between
	the fulcrum lever and the chassis
	bracket will increase the castor
	$0.4 \text{ mm} = 9'(0.15^{\circ})$
	1.6 mm = 37'(0.62°)
	Loosen the lower arm mounting bolts
	,and the upper arm side nuts so that
	the lower arm movement is free.
	Remove the front apron cover.
	Compress the spring by moving the
	lower arm, using a jack
	Loosen the fulcrum mounting bolts
	Add or remove shims as required
	Tighten the fulcrum mounting bolts to
	12.0 to 14.0 Mkg (87 lb. ft- 101 lb. ft).
	Also refer to the Torque chart.
	After that decompress the spring.
	Tighten the lower arm mounting bolts.
	And the upper arm side nuts. As per
	the Torque chart
	Before tightening shake the vehicle
	by compressing the front and rear of
	the vehicle alternatively by hand.
For adius	sting the Camber
	The value for any given wheel should
	be $0^{\circ}14' \pm 0^{\circ}30'$ and the maximum
	difference between the two wheels
	should be ± 30'
	The shims are available in thickness
	of 3.2, 1.6, 0.8 mm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Front Suspension Version 1 , Aug.06









**EXIT** 





Automotive Sector		
	Addition of shim between the fulcrum and the chassis bracket will decrease the camber.	
	0.8mm =0.15 °( 9')	
	1.6 mm = 0.32 °(19')	
	3.2 mm = $0.62^{\circ}(37')$	
	To increase the camber - remove the	
	shims	
	Loosen the lower arm mounting bolts, and the upper arm side nuts. so that the lower arm movement is free	
	Take out the apron cover behind the wheel by carefully removing the plastic fasteners	
	Compress the spring by moving the lower arm, using a jack.	
	Loosen the fulcrum mounting bolts	
Camber adjusting shim	Add or remove shims as required	
	Tighten the fulcrum mounting bolts to 12.0 to 14.0 Mkg (87 lb. ft- 101 lb. ft). Refer to the torque chart	
	After that decompress the spring.	
	Tighten the lower arm mounting bolts.	
	And the upper arm side nuts.	
	Before tightening shake the vehicle	
	by compressing the front and rear of	
	the vehicle alternatively by hand.	
Cross-confirm the camber value.  For adjusting the Toe In		
ror daju		
	Adjust by moving the tie rod. The tie	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















Automotive Sector	
	rods should be adjusted equally on both sides. The variation between left and right side of the tie rods should be maximum one turn. (If it is more than the centralization of the steering wheel will also be affected.)
Adjusting the Wheel tuning angle	
	Bring the Wheels in Straight Ahead Position (SAP). At this position confirm that the turntables Zero are also showing Zero
	Turn the steering wheel to Right Hand Side so that the wheel turns through $36\pm0.5^{\circ}$ (Please refer the specifications)
	Check the condition of the stopper bolt of LH side It should touch the bracket on the lower arm assy.
	If it is not touching or the wheel is not able to turn through 36±0.5° then loosen the lock nut adjust the bolt and then lock the bolt with locknut.
	Turn the steering now towards the Left-hand side and then adjust the stopper on the right hand side.
FINAL  COMPLETED  F10->Print, CTRL+HOME->Save & Re-start	For print out press "F10" key to save press "ctrl" and the "home" key together.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















Even if the manual gauge is used please ensure that it is having high accuracy and also repeatability.

### Castor checking (With the bubble type gauge) -

Confirm that the bubble is set at Zero and also that the turntable is also set to zero.
Remove the turn tables locking pin
Rotate the steering so that the wheel turns inwards by 20 degrees.
Set the castor scale to zero
Turn the steering wheel in opposite
direction so that it turns outwards by
20 degrees
The value in the castor scale gives the castor value.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Automotive Sector	
	The values should be within 2.75 $^{\circ}\pm1.00$ (2°45' $\pm1.0^{\circ}$ )
	Repeat on the other side
	The difference between the two
	wheels should be within ±45'
	The adjusting shims are available in
	1.6, 0.4-mm thickness.
	Addition of shims in front between
	the fulcrum lever and the chassis
	bracket will reduce the castor
	Addition of shims in rear between
	the fulcrum lever and the chassis
	bracket will increase the castor
	$0.4 \text{ mm} = 9'(0.15^{\circ})$
	1.6 mm = 37'(0.62°)
	Loosen the lower arm mounting bolts
	,and the upper arm side nuts so that
	the lower arm movement is free
	Remove the front apron cover.
	Compress the spring by moving the
	lower arm, using a jack Loosen the fulcrum mounting bolts
	Add or remove shims as required
	Tighten the fulcrum mounting bolts to
	12.0 to 14.0 Mkg (87 lb. ft- 101 lb. ft).
	Also refer to the Torque chart.
	After that decompress the spring.
	Tighten the lower arm mounting bolts.
	And the upper arm side nuts. As per
	the Torque chart
	Before tightening shake the vehicle
	by compressing the front and rear of
	the vehicle alternatively by hand.
	Cross-confirm the castor value.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC











# Camber checking (With the bubble type gauge) -

Keep the front wheel in straight-ahead condition. (SAP)  Clean the hub assembly for any dirt or mud. Remove the front wheel hubcap.
Install the magnetic base of the gauge in such a way that the center pin of the gauge aligns with stub axle center drill and gauge is sitting squarely on the hub.  By turning the gauge bring the spirit
level to read " ZERO ".  The value in the camber scale at this point is the Camber reading. Note the reading  Repeat the same procedure on the
other wheel.  The value for any given wheel should be 0°14′ ± 0°30′ and the maximum difference between the two wheels should be ± 30′  The shims are available in thickness of 3.2, 1.6, 0.8 mm
Addition of shim between the fulcrum and the chassis bracket will decrease the camber.
0.8mm = 0.15 ° (9') 1.6 mm = 0.32 ° (19') 3.2 mm = 0.62° (37') To increase the camber - remove the shims

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















Loosen the lower arm mounting bolts ,and the upper arm side nuts. so that the lower arm movement is free



Take out the apron cover behind the wheel by carefully removing the plastic fasteners

Compress the spring by moving the lower arm, using a jack

Loosen the fulcrum mounting bolts



Add or remove shims as required

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Tighten the fulcrum mounting bolts to 12.0 to 14.0 Mkg (87 lb. ft- 101 lb. ft). Refer to the torque chart

0.00	
	After that decompress the spring.
	Tighten the lower arm mounting bolts.
	And the upper arm side nuts.
	Before tightening shake the vehicle
	by compressing the front and rear of
	the vehicle alternatively by hand.
	Cross-confirm the camber value.
	Replace the apron and the hub cover.

#### Caution:

Ensure that while the hubcap is being fitted back the Anabond RTV sealant 673 has been applied. The sealant should be applied in the mounting face as well as the inner dia.

Do not fill grease in cavity.

Failure to do so will result in premature wheel bearing failure and tyre wear.

# Toe in checking (With manual gauge) -

Mark the center of the tyre treads. Do it for both the tyres
Adjust the height of the pointer so that
it touches the marked line in line with
the center of the axle spindle/ hubcap.
Place the gauge in front of the vehicle

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# Wheel Turning Angle (With manual gauge) -

Bring the Wheels in Straight Ahead
Position (SAP). At this position confirm
that the turntables Zero are also
showing Zero
Turn the steering wheel to Right Hand
Side so that the wheel turns through -(
Please refer the specifications

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Check the condition of the stopper bolt of LH side It should touch the bracket on the lower arm assy.
If it is not touching or the wheel is not able to turn through 36±0.5° then loosen the lock nut adjust the bolt and then lock the bolt with locknut.
Turn the steering now towards the Left-hand side and then adjust the stopper on the right hand side.

# **Check the Steering Wheel Centralization** -

One of the most common complaints / perceptions is that after the Wheel Alignment the Steering wheel is not centralized. Though strictly speaking it does not constitute wheel alignment but if the steering wheel is centralized then a lot of customer dissatisfaction will be avoided.

Caution: This procedure for centralizing the Steering wheel is valid only if the misalignment of the spokes is less than 10 degrees. In other words this procedure is only for fine-tuning the steering wheel position not for glaring error. If it is more 10 degrees then remove the steering wheel and initially realign to less than 10 degrees.

Adjust the **Steering wheel centralization** 

Cross check the Wheel <u>Toe</u> In after
this operation, before releasing the
vehicle.

# Wheel hub greasing --

Remove the caliper assembly without disconnecting the brake hose.
Caution: Ensure that the brake hoses

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Front Suspension Version 1 , Aug.06













**EXIT** 





Automotive Sector	
	are not stretched/ damaged. Put the caliper without straining the brake tube.  Loosen & remove allen bolts & the automatic hub lock.
	Using the MST 571, remove the outer locknut
	Remove the lock washer and the inner nut.
	Pull out the hub along with the bearings.
	Inspect the rollers and the inner races of the bearings for pitting/ brinelling or spalling.
	If any damage is noticed - inspect the outer races also.
	To remove and refit the outer races, use MST.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Front Suspension Version 1 , Aug.06













**EXIT** 





Automotive Sector	
	Caution: Never clean the bearings in water.
	Never rotate the bearings with compressed air.
	Never tap the bearing's to clean out the trapped dust.
	DO: Clean with kerosene and a hard brush. Wrap up the cleaned bearings with polythene to avoid water, humidity affecting the bearings.
	Do remember that the dust and water are the 2 main reasons for bearing failures
	If the outer race / cup is found to be loose in the housing then it is advisable to replace the hub. Trying to recondition the hub bore is not recommended.
	If the bearing seating area or the oil seal seating area in the spindle is worn then replace the spindle.
	Caution: Ensure that the hub assembly is being rotated while the inner nut is being tightened This is essential to ensure that the roller centralize themselves and also so that they abut properly.
	Failure to do so causes two complaint- excessive loading on few rollers and also increase/ variation in hub endplay after running.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















7 1000000000000000000000000000000000000	
	Fill the grease in the bearing.
	Locate the inner bearing cone & press
	the oil seal using the MST 574.
	Note: The lip of the oil seal should be
	coated with grease. Also fill grease in
	the cavity where the oil seal spring is
	present.
	Press the hub assembly on the spindle,
	Locate the inner cone of the outer
	bearing.
	Tighten the inner nut. and back off by
	90 degrees .The hub play should be
	within 0.010 to 0.030 mm
	Put the locking washer.
	Tighten the outer nut.
	Press the hub cover after applying
	Anabond RTV 673 sealant Use the MST
	575 to fit the hub cover,
	Fit the automatic hub lock.



Caution: Do not lubricate the suspension bushes/joints. For fitting & removing bush use soap solution only.



Jack up the vehicle-locate the jack

Behind the lower arm just below the first outrigger.

Care must be taken not to damage the torsion bar.

Remove the tyre .

Remove the calliper assembly without

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















utomotive Sector	
	disconnecting the brake hose .
	Caution: Ensure that the brake hoses are not stretched/ damaged. Put the calliper without straining the brake tube.
	Remove the Shock Absorber.
	In case only the Upper arm bushes have to be replaced- remove the arm.
	Remove the lower Ball joint using the Special tool after removing the split pin and the castle nut.
	Remove the pin fulcrum bolt on chassis & remove the upper arm.
	Remove the Lower control arms front and rear nut and remove the LCA.
	For removing the upper and lower arm bushes use the Special tool MST 564 & 565
æ.	Note: While fitting new bushes use soap solution so that the bush can pressed easily.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Front Suspension Version 1 , Aug.06













**EXIT** 







Caution: Use of any lubricant will result in degradation of the rubber bush and lower life. Pressing without soap solution will damage the bush



During refitting use the dolly.



### **Caution:**

In the lower arm while pressing the rib in the arm has to match groove in the tool

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















### Working principle, Dismantling, Assembly of the Front Suspension -

The front Wheel suspension in the 4 WD vehicles is wishbone type with torsion bar springs and telescopically acting hydraulic dampener. Both the lower and upper arm employ two point mounting.

The torsion bar is connected to the Lower control Arms rear end through a Torque control Arm. The rear end of the torsion bar is connected to a ride control arm. A ride control height-adjusting nut links the control arm to chassis.

An anti roll bar is used to transfer the loads to the outer wheel during turns. The telescopic shock absorbers are used to dampen the wheel oscillations and ensure proper wheel contact irrespective of the road condition.

#### Caution:

The Torsion bars are pretwisted. LH marking identifies the Left Hand side and RH marking identifies the Right Hand torsion bar. The arrow should be facing front.

While jacking up the vehicle (for doing ride height adjustment) ensure that the jack or the two post lift points are not touching the torsion bar.

The dismantling sequence is reverse of the assembly procedure explained below -



Jack the wheels, ensure that the anti roll bar link has been disconnected.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC











Insert Lower Control Arm on frame

Insert The torsion bar rear end in Height Control Arm serration



Put the height control arm assembly on chassis bracket.



It is advisable to keep all the bolts of the LCA & UCA loose while doing assembly, as it will ease the assembly operations.

Also if the bolts are tightened in this position then the bushes will get preloaded. Further while trying to adjust the ride height the effort required to turn the ride height bolt will be high and cause damage to the face.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















Insert the bolt of height control Arm and flush the thread end to Height control nut.

Give a slight twist to the torsion bar by hand so that the rocker maintains a horizontal position/ touching the bottom of the bracket.

Holding the torsion bar by hand and insert/slide in the Torsion bar into the Lower Control arm's Torque Arm.



Tighten the Torque Arms 3 bolts (2 bolts onto the weld nuts and 1 free bolt +flanged nut)



It is essential to tighten the torque arms bolts first.

In case it is not done so and the ride height is adjusted. Then the adjustment will not be achieved, and also the twist of the torsion bar by tightening will not result in proportionate lift/height of the LCA.

Also the 3 bolts will not seat properly on the torque arm and may damage the threads of the 3 bolts. In other words the torque arm bolts ensure that the torsion bar becomes integral to the LCA through the Torque arm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Tighten the height control bolts by 24 to 26 Turns
Lower the Jack so that the wheels are touching the ground
Gently shake the Vehicle 5/6 times
Tighten the Lower control Arms and the Upper Control Arm's both the front and rear bolts to the specified Torque.
Measure the ride height. (Lower control Arms front bolt head center to ground.)
Note: Ensure that the measurement is done on level ground with specified tyre pressure on all four wheels. (Front 2.0 bar and Rear 2.2 bar).
If variation is more than +/- 7.0 mm then tighten or reduce the height by turning the height adjusting bolt.
It is suggested that for turning the nut it is advisable to jack the vehicle.
Take the measurement again after a ride.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC





















If the ride height varies from the specifications then readjust after loosening the UCA & LCA bolts and jacking both the wheels only

1 turn of the bolt affects the ride height by 6 to 7 mm.

Hence if the ride height is less by say 3 mm then turn the ride height bolt by half a turn

The assembly procedure for fitting the bushes onto the LCA & UCA is same as mentioned in the 2WD. There is no change in setting the Wheel alignment procedure also.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Description	Specification
Туре	Independent, torsion bar with
Front Shock absorbers- 2WD	telescopic shock absorbers
Trone shock absorbers 200	Maximum length: 335±3. Minimum length: 222+3.
Front Shock absorbers- 4WD	
	Maximum length: 378±3. Minimum length: 244+3.
Camber	
	0.23 °±0.5 (0°14' ± 0°30')
Difference between LH & RH Camber	±0.5° (±30')

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















omotive Sector	
Castor	2.75 °± 1.0 (2°45'± 1.0°)
Difference between LH & RH castor	±0.75° (±45')
Total Toe in	1 to 3 mm.
Total Toe in ( in degrees)	0.15 to 0.45° (9' to 27')
Individual Toe in	0 to 20 minute
King pin Inclination	10.75° ± 1° (10°45'± 1°)
Wheel Turning Angle	36° - 2WD 4WD 35° - Inner Wheel angle 32° - Outer Wheel angle
Ride hight to be set on vehicle	282 mm

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















**Automotive Sector** 

Ride height Variation Between	15 mm
LH & RH. ( Up to LCA front pivot	
bolt)	

#### Lubricants -



No lubricants are used in the suspension bush. Only soap solution to be used during assembly

### <u>Tightening Torque's</u> –

Location	Torque	
Upper Arm side bushes	110-130 Nm (81-96 Lbft)	
Upper Arm Ball joint	23-29 Nm (17- 21 Lbft)	
mounting nut		
Upper Arm pin fulcrum	120-140 Nm (88.5 -103 Lbft)	
mounting nut		
Lower Control Arm Front	150-180 Nm (111-133 Lbft)	
Mounting		
Lower control Arm Rear	110-130 Nm (81-96 Lbft)	
mounting		
Torque Arm M12x1.25 with	60-80 Nm (44-59 Lbft)	
spring washer & weld nut		
Torque Arm	40-60 Nm ( 29.5-44 Lbft)	
M10x1.25		
LCA ball joint mounting nut	60-80 Nm (44-59 Lbft)	
LCA bump stop mounting	40-60 Nm ( 29.5-44 Lbft)	
Stabilizer bar on Frame	30-45 Nm (22- 33 Lbft)	
Stabilizer bar +Link	60-80 Nm (44-59 Lbft)	
Link on Lower Arm	16-22 Nm ( 12- 16 Lbft)	
Shock absorber Top- on	16- 22 Nm ( 12- 16 Lbft)	
frame		
Shock absorber Bottom on	16-22 Nm ( 12- 16 Lbft)	
LCA		
Shock absorber Bottom on	60-80 Nm (44-59 Lbft)	
LCA ( 4WD)		
Steering stopper on knuckle	50-75 Nm (37-55 Lbft)	
Castle Nut UCA	120-160 Nm (88.5-118 Lbft)	
Castle Nut LCA	120-160 Nm (88.5-118 Lbft)	
Frame- Rebound stopper	40-60 Nm ( 29.5-44 Lbft)	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















MST Number	Description
MST-561	Upper Arm Ball Joint Puller
MST-562	Lower Arm Ball Joint Puller
MST-563	Fulcrum Mounting Bolt Spanner
MST-564	Fixture Upper/ Lower Arm Bush
MST-565	Extractor / Installer Arm
	Suspension Bush
MST-566	Extractor/ Installer Chassis
	Suspension Bush
MST-571	Special Socket for hub nut.
MST-572	Installer Front Wheel Bearing
	Cone-Outer
MST-573	Installer Front Wheel Bearing
	Cone-Inner
MST-574	Installer Front wheel Hub oil
	seal
MST-575	Installer Front Hub Grease Cup

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















### **Rear Suspension**

**Description** 

**Trouble Shooting** 

**Shock Absorbers** 

**Spring Leaves** 

**Specifications** 

**Tightening Torques** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

Rear Suspension Version 1, Aug 06



















The rear suspension is a progressively rated multi leaf spring with double acting shock absorber. The front end of the springs is mounted at the pivot end through rubber bushings. The bushings isolate the road noise and road harshness as the springs move. The rear end of the spring is connected to the springs through shackle

Again the spring and shackles use the rubber bushes to isolate the noise and road harshness. The shackles allow the variation of the spring length when the vehicle moves over the different terrain causing the wheel to move up and down.

The travel of the spring is controlled by bumper, which is mounted on the axle. The springs are connected to the axle with U-bolts and spring plate. All suspension components that use rubber bushings should be tightened with the vehicle at normal height. If the springs were not at normal ride height condition the ride quality would be affected and also the life of rubber will also be affected. Rubber bushings must never be lubricated.

The ride control is achieved by the use of double acting shock absorbers and leaf springs. The shock absorbers dampen the jolt and the rebound as the vehicle travels over the various road conditions. The top end of the shock absorber is connected to the chassis while the bottom end is connected to axle.

The anti roll bars are used to transfer the loads to the outer wheel during

A sketch of the antiroll bars in rear with spring, shock absorber & axle is shown below.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Rear Suspension Version 1, Aug 06




















### **Trouble Shooting -**

A squeak noise from the shock absorber can be produced if movement between the rubber bushing and metal occurs. Tightening the attaching parts can usually stop this noise. If the squeak noise persist then inspect for worn or damaged bushings and attaching components. Repair as necessary if any thing found amiss.

The shock absorber bushings do not require any kind of lubrication. Do not lubricate the bushings to reduce bushing noise. Grease or mineral oil base lubricants will deteriorate the bushing.

The shock absorbers are not refillable or adjustable. If a malfunction occurs, the shock absorber must be replaced. To test a shock absorber hold it upright in fully extended position for 10 minutes. Then force the piston in and out of the cylinder four or five times. Also check for any hydraulic oil leakage. The action throughout each stroke should be smooth and even.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

Rear Suspension Version 1, Aug 06















**Automotive Sector** 

Symptom	Causes	Remedial action
Suspension Noise	1. Check if mud is between the leaf springs.	✓ Clean with pressurized water.
	2. Check tip insert if broken/ worn out.	<ul><li>✓ Replace the tip between the leaves.</li><li>✓ Replace the bushes.</li></ul>
	<ul><li>3. Check bushes.</li><li>4. Check shock</li></ul>	✓ Tighten the shock absorber mounting bolt
	absorber bush- worn out/ loose.	or replace the bushes.  ✓ Replace the spring assembly.
	5. Check leaf breakage.	_
Vehicle ride Jumpy/ Jerky	1. Improper tyre pressure.	✓ Keep tyre pressure as recommended.
	2. Shock absorber bushes worn out.	✓ Replace the shock absorber.
	3. Spring leaf bushes worn out.	✓ Replace the bushes.
	4. Shock absorbers leaking/weak.	✓ Check the shock absorber and replace if
		required.
	5. Leaf spring sagging / broken.	<ul> <li>✓ Check the bump clearance as per the specified procedure. Replace springs.</li> </ul>

### **Shock Absorber** -

Remove the upper attaching nut and washer.

Remove the lower attaching nuts, washer and bolts from the axle. Remove the shock absorber.

While fitting ensure that they are tightened to a torque of 45 to 55 Nm (33 to 40 Lb ft)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

Rear Suspension Version 1, Aug 06















Automotive Sector **Leaf Spring** -

**Bush Replacement** 

Leaf replacement

**Bush replacement -**


Pivot end bush replacement.

Shackle end bush replacement.

### Pivot end bush replacement -

Support the vehicle in chassis

- 1. Loosen the shackle mounting bolts.
- 2. Remove the pivot mounting bolts by rotating and pulling.
- 3. Pull out inner bush by pulling it out
- 4. Lower the axle and bring the spring out of pivot.
- 5. Remove the bush by pulling it out.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC

Rear Suspension Version 1, Aug 06




















**Automotive Sector** 

### Shackle end bush replacement -

Support the vehicle in chassis

- 1. Loosen the shackle mounting bolts.
- 2. Remove the shackle / pivot mounting bolts.
- 3. Pull out the one bush at a time. Each eye is having two collared bushes. They can be pulled out



### While assembling ensure that:

- The rubber bushes are liberally coated with soap water.
- The hole in the center of the pivot and the hanger bracket are clean and not blocked by mud. (The hole is provided so that while assembling the air should not get trapped between the two bushes- preventing proper assembly.)
- The eyes in spring and pivot/ shackle are properly aligned before the bushes are inserted.

After the bushes are inserted, remove the support from the chassis & axle (if used) and then tighten the pivot and shackle bolts to 50 to 70 Nm (37 to 52 Lb ft).

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

Rear Suspension Version 1, Aug 06



















## Automotive Sector Leaf Replacement -

The leaf springs need to be replaced only if the springs are broken or are sagging.

To check for the spring sagging it is recommended that bump clearance in unladen conditions is measured.

The bump clearance has to measured after ensuring that

- The vehicle is in level ground.
- It is unladen.
- The tyre pressure is as per the recommendations and also no variation between left and right tyres.
- The bump stop is not in deteriorated or damaged condition.

The bump clearance is  $85\pm$  10 mm and the variation between Left and right is allowed to be 7 mm

<u>Recambering of the spring is not recommended</u>. (Please note that the spring is of progressive type - any recambering will result in the ride becoming linear as well as stiff.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

Rear Suspension Version 1, Aug 06

















Free Camber	165 mm- reference only
Specified camber	64 to 70 mm under load of 3355N (Only for reference in field)
 Bump clearance - Unladen vehicle	85± 10 mm
Difference between LHS & RHS bump clearance	7 mm

### <u>Tightening Torque's</u> -

Description	Value
Bolt - Leaf spring pivot	50 to 70 Nm (37 to 52 Lb ft)
Shackle at chassis	50 to 70 Nm (37 to 52 Lb ft)
Shackle at Spring	50 to 70 Nm (37 to 52 Lb ft)
U Bolt	80 to 100 Nm (59. to 74 Lb ft)
Shock absorber top	45 to 55 Nm (33 to 40 Lb ft)
Shock absorber bottom	45 to 55 Nm (33 to 40 Lb ft)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

Rear Suspension Version 1, Aug 06

















### **Steering System**

**Description** 

**Trouble Shooting** 

Care of the system

**In Car repairs** 

Dismantling & Assembly of the Steering Gear

**Working principle of the Steering Pump** 

**Specifications** 

**Tightening Torque's** 

List of the MST's.

**Recommended Lubricants** 



















### **Description** -

The power steering system is a rack and pinion system. The engine driven hydraulic -pump supplies oil to a control valve situated in housing that supports the pinion shaft. Movement, imparted to the control valve from the shaft in the steering column is via a torsion bar. This sensing bar moves the control valve, which in turn directs the oil to one side or the other side of the ram piston inside the steering rack.

The control valve is a rotary type spool valve controlled by the torsion bar interposed

between the steering shaft and pinion of the steering box. The spool valve is a shaft with six flutes and a sleeve, which has six internal axial grooves, encases this. Radial ports in the sleeve and shaft pass the oil from the supply to the lines connected to the ram chamber.

A series of the splines between the shaft and the sleeve limit the twist of the torsion bar to about 7 degrees in each direction; below this angle the torque applied by the driver to the steering box is transmitted by the torsion bar. This fail-safe feature provides a mechanical drive from the steering shaft to the pinion in the event of any power system failure.

The amount of the twist of the torsion bar and the movement of the spool valve is proportional to the effort applied by the driver. Initial power steering assistance is obtained at about 0.5 degrees deflection of the bar and this power rises progressively as the bar moves to about 4 degrees; the point o maximum assistance.

When the wheel is in straight-ahead position, all the ports are open so oil is allowed to flow through the valve and return to the reservoir.

As soon as the wheel is turned, the torsion bar is deflected; this allows the spool valve to rotate relative to the sleeve, cutting off the oil flow both to the reservoir and one side of the ram. At the same time the other side of the ram is subjected to oil pressure, which builds up sufficiently to move the road wheel and return the torsion bar to no - torque position. During this stage the oil displaced from the uncompressed side of the ram is returned to the reservoir.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















**Automotive Sector** 

On occasion when the resistance to road wheel movement is excessive, the oil pressures build up to its maximum. At this pressure a relief valve fitted inside the pump opens and allows the oil to return to pump inlet.

### **Trouble Shooting -**

The rack and pinion design is a simple design. However it is still susceptible to various problems in particular to leaks. If the bellows are ripped or are unable to keep the contaminant's away then it can cause damage to oil seal and subsequent leaks.

One complaint, which can be present, is that the steering may be stiff and jerky when the unit is cold and as the vehicle is driven/ warmed the power assist gradually comes back. It normally indicates that grooves worn into the bore of the pinion aluminum housing by hard control valve seals.

Wear in the centre housing causes the fluid to leak around the rack piston. Causing either steering wander or lack of straight-ahead stability. Another cause of steering wander and erratic control often accompanied by clumping, thunking noise is the deterioration of rack mounting bushings.

Fluid levels can be hard to locate. Sometimes you will see a low level in the pump reservoir but no evidence of escaping liquid. Squeeze the bellows and you will probably find that they are full of liquid. To confirm if that side of the rack is the culprit, then remove the both the bellows, clean the rack housing and then operate the system to observe the seepage directly.

It should be mentioned that a rusty input shaft U joint or deteriorated flexible textile/rubber coupling could imitate rack problems.

Caution: After attending to the repairs it critical that the system be completely flushed completely. Disconnect the return line from the pump and put in a container, then disable the injection (remove the wire from the shut off solenoid) and crank the engine. Add fresh fluid until you get a clear flow from the line. Take care that the reservoir does not run dry during the flushing. Failure to do so will result in premature failure of the repaired unit.)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















The possible causes for the power steering complaints are tabulated below:

PROBLEM	POSSIBLE CAUSES	CORRECTION
Objectionable Hiss	Noisy relief valve in hydraulic pump. Steering gear noise valve noise is transmitted trough the steering column or open-air passages in the area where the column or controls pass through the floor into the engine compartment.	There is some noise in all the power steering system. One of the most common is a hissing sound most evident at stand still parking. Hiss is a high frequency noise that is present in every valve and results from high velocity fluid passing valve orifice edges. There is no relationship between this noise and the steering gear performance. DO not replace the intermediate shaft or the steering gear unless the noise is too objectionable. Check the dashboard seals between the drivers area and under hood to eliminate open space/ gaps
Rattle or chuckle noise in Steering Gear	<ol> <li>Gear loose on frame.</li> <li>Steering linkage looseness.</li> <li>Pressure hose touching other parts of the vehicle.</li> </ol>	<ol> <li>Check the gear mounting bolts.         Torque the bolts to specifications.</li> <li>Check the IBJ and OBH for wear.</li> <li>Adjust the hose position. Do not bend the tubing by hand.</li> <li>Replace.</li> <li>Adjust to specification</li> </ol>
	4. Loose IBJ or OBJ 5. Improper over centre-	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Steering Version 1, Aug 06

















#### clearance. A slight rattle may occur on turns because of increased clearance off the high point. This is normal and clearance must not be reduced below specified limits to eliminate this slight rattle. 1. Air in the steering. Excessive 1. Add oil to the pump wheel Kick reservoir and bleed. Back or Loose Steering Gear Mounting 2. Tighten attaching loose. bolts to the specified Steering torque. Replace loose parts. 3. Front wheel Bearings 3. Adjust the wheel Incorrectly adjusted or bearings or replace as required. worn. 4. Adjust to specifications 4. Steering Gear Improperly 5. Dismantle and adjusted. assemble the steering 5. Damaged or worn steering Gear. gear as specified. 6. Worn or damaged rubber 6. Replace the rubber bushing for mounting bushings steering gear Vehicle leads 1. Adjust to 1. Front end misaligned. specifications. to one side or the Other Unbalanced steering gear 2. Replace the gear (keep in mind valve. If this is the cause Valve. the road steering effort will vary condition and light in direction of lead and heavy in opposite wind direction. conditions.) 3. Align the column. 3. Steering shaft rubbing Test the with the ID of the shaft vehicle, Going 4. Adjust as required. in Both tube 4. Steering linkage not directions, On level. a Flat road

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















**Automotive Sector** 

		1
Momentary Increase in steering Effort When Turning the Wheel Quickly To the Right or Left Poor return of Steering	<ol> <li>Low oil level in Reservoir.</li> <li>Pump Belt slipping.</li> <li>High Internal leakage's (Steering Gear or Pump)</li> <li>Tyres under inflated.</li> <li>Lower coupling flange against the steering gear adjuster</li> <li>Steering wheel rubbing against directional signal housing.</li> <li>Tight or seized steering shaft bushing/bearings</li> <li>Steering joint or linkage binding.</li> <li>Steering column misalighned.</li> <li>Lack of lubrication in the suspension ball.</li> <li>Improper front end alignment.</li> <li>Steering gear adjusted too tight.</li> <li>Kink in return hose.</li> </ol>	<ol> <li>Add steering fluid as required.</li> <li>Tighten or replace belt.</li> <li>Refer to pump test.</li> <li>Inflate to specified pressure.</li> <li>Loosen the pinch bolt and assemble.</li> <li>Adjust the steering column.</li> <li>Replace the bearings.</li> <li>Relubricate/ replace the joints.</li> <li>Align the steering column.</li> <li>Relubricate/ replace the ball joints.</li> <li>Check &amp; adjust to specifications.</li> <li>Adjust the preload.</li> <li>Replace the hose.</li> </ol>
Steering wheel Surges or Jerks when Turning with engine running, especially during Parking.	<ol> <li>Low oil level in Pump.</li> <li>Loose pump belt.</li> <li>Sticky flow control valve.</li> <li>Insufficient pump pressure</li> </ol>	<ol> <li>Add fluid as required.</li> <li>Adjust tension as per specification.</li> <li>Clean the control valve or replace the pump.</li> <li>Refer to the power steering System Test.</li> </ol>
Hard steering effort in both the directions	<ol> <li>Low tyre pressures</li> <li>Lack of lubrication is</li> </ol>	<ol> <li>Adjust the tyre pressure.</li> <li>Lubricate &amp;</li> </ol>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC







All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

Steering Version 1, Aug 06











**Automotive Sector** 

Full wheel Travel & Standstill Parking)		
Growl noise in Steering Pump	<ol> <li>Scored pressure plate, thrust plate or rotor</li> <li>Extreme Wear of cam ring</li> </ol>	<ol> <li>Replace Pump.</li> <li>Replace Pump.</li> </ol>
Growl noise in Steering Pump	<ol> <li>Low oil level</li> <li>Air in the oil. Poor pressure hose connection.</li> </ol>	<ol> <li>Add the power steering fluid.</li> <li>Bleed the system.</li> </ol>
Rattle or knock noise in steering Pump	Pump Vanes sticking in rotor slot Pressure hose touching other parts of the Vehicle.	Replace pump, flush system. Adjust hose position.
Swish Noise in steering Pump	Faulty flow control valve	Replace pump.
Whine Noise In Steering Pump	Pump shaft bearing scored	Replace pump.
Low oil Pressure Due to Steering pump	<ol> <li>Flow control valve stuck or inoperative</li> <li>Pressure plate not flat against the cam ring.</li> <li>Extreme wear of the cam ring.</li> <li>Air in oil.</li> <li>Low oil level</li> <li>Pump belt slipping</li> <li>Damaged hoses or steering gear</li> </ol>	<ol> <li>Replace pump.</li> <li>Replace pump.</li> <li>Replace pump, flush system.</li> <li>Locate source of leak &amp; correct. Bleed the system.</li> <li>Add power steering fluid as required.</li> <li>Tighten or replace belt as required</li> <li>Replace as necessary.</li> </ol>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC









### Care of the system -

The lubricant level should be checked every 10000 Kms with the vehicle unladen and in a level ground. The lubricant level should be between the maximum and minimum mark. The fluid level should be checked with the engine in off condition. If the oil level is excess it will tend to come out from the filler cap in use lubricant meeting oils specification of ATF (Automatic Transmission Fluid. The brand names have been specified in the Operators Manual and also in the end of the Section.

### In Car repairs -

The following repairs can be carried out without removing the assemblies.

- a) **Removal** and refitment of out board Joints (OBJ)
- b) **Greasing** of the OBJ (In case the rubber gaiter is torn.)
- c) Removal & Refitment of the Steering Wheel.
- d) Checking for Steering Play.
- e) Steering Wheel Centralize
- f) Bleeding the system.

### a) Removal and refitment of Track rod ends/ Outer Ball Joint



Slacken the wheel nuts. Raise the wheel and remove the front wheels.



Slacken the track rod end lock nut.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC









Remove the castelled nut split pin
and remove the castelled nut.
Remove the track rod end using
the special tool.
Remove the track rod end. While
removing the track rod end, make
a note of the number of tuns
required to remove the end.
While fitting back the end or
fitting a new end turn it back the
same number of threads

# b) <u>Greasing of the track rod end/Outer Ball Joint (Only if the rubber gaiter is torn.)</u>

After removal of the track rod end
Remove the circlip
Fill the joint with about 10 grams of grease
Fit a new gaiter and put the lock

### c) Removal & Refitment of the Steering Wheel

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















	Remove the horn cover, using
	the screw driver
Remove the lock nut, using the	
	22 mm socket

### d) Checking and adjusting the Steering Play

straight road, check the wheel spokes for angular play.  If more than 25 to 30 degrees then check -Tie-rod end ball joint or steering gear inner ball joint or Lower arm ball joint or universal joint
Replace the defective part/parts  Caution- While checking ensure that the engine is in off condition and wheels are in Straight Ahead Position (SAP

### e) Steering Wheel - Centralize

Caution: This procedure for centralizing the Steering wheel is valid only if the misalignment of the spokes is less than 30 degrees. In other words this procedure is only for fine-tuning the steering wheel position not for gross error. If it is more 30 degrees then remove the steering wheel and initially realign to less than 30 degrees.

To check for the centralization of the
To check for the centralization of the steering wheel. Drive the vehicle on a
level road surface; note the angular
level road surface; note the angular position (misalignment of the steering

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Automotive decision		
	wheel spokes.	
	Raise the vehicle	
	Mark the position of the track rods and the track rod ends	
	Slacken the track rod end lock nuts and also remove the gaiter outer retaining clips.	
	Rotate both track rods in the same direction approximately 30 degrees for every 1-degree of steering misalignment error.	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC


Steering Version 1, Aug 06

















wise	nti ock	If the steering wheel has an anticlockwise angular error then both track rods must be rotated clockwisewhen viewed from the left - hand side of the vehicle
Wise	nti	If the steering wheel has an clockwise angular error then both track rods must be rotated anticlockwise- when viewed from the left - hand side of the vehicle
		Check the front wheel alignment (Toe In) after the steering wheel has been centralized

### f) Bleeding the system

Before starting the Bleeding operation, ensure that the Vehicle is in level ground, and the reservoir is filled to the maximum specified. As with any hydraulic system ensure that the recommended <u>fluid</u> only are used. Ensure that no dirt enters the system while topping up. Before opening the reservoir cap, wipe the area with a cloth.



Caution: Ensure that the front wheels are jacked up and wheels are lightly touching the ground.

If this is not done then the steering linkage and components

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















will be under undue stress.
Even with the wheels partly jacked up, do not hold the steering in fully locked position for more than 10 second. Failure to do so may damage the pump beyond repairs.
Start the engine.
Rotate the steering wheel from lock to lock 3 to 4 times.
Check if the oil in the reservoir has dropped down drastically- if so check for any leaks.
Check if any foaming/ frothing is taking place.
Repeat the rotation from lock to lock till the foaming subsides
If the foaming is not subsiding after ¾ of the above cycle, check for the tightness of the hoses in particular the reservoir to the steering pump and later the steering gear to reservoir. The
loose connection in these pipes will allow air to sucked into the

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















system.
After completing the bleeding operation, ensure that with the engine running the oil level is between the maximum and minimum mark
Close the cap.

Servicing of the steering gear assembly is not recommended. If the rubber bellows found damaged can be replaced. The procedure is as follows -



Remove the bellows along with the clips.



If the bellow is having any crack, or swelling then discard them. It is also advisable to use new clips along with the bellows.

Note that the RHS and LHS bellows are not equal.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















CAUTION	Fit the bellows. Caution: ensure that the outer clips are fitted on top of the groove. (The rubber boot also has a beading, which sits on the groove.)
CAUTION	Caution: The tube side boot is smaller than the control housing side.

### Working principle of the Steering Pump -

The steering pump is non-serviceable. Hence it cannot be repaired.

The pump is a constant flow, vane type incorporating a flow control valve (with an integrated relief valve) and it is gear driven by engine. The power steering pump consist of housing, drive shaft, cartridge assembly & bearing(s) apart from the valve.

As the pump rotates a vacuum is created at the inlet, which causes atmospheric pressure to force the fluid in to pump from the reservoir. As the rotor rotates, the inlet port closes and the fluid is trapped between the vans. Further movement forces the fluid to be pressurized as the profile of the cam ring constantly reduces the available volume. At the minimum point of the profile the chamber opens into the outlet port.

The rotor is having 10 vanes, thus each rotation is equal to 5 pumping action. The discharge rate of the power steering pump increases in proportion to the pump speed increases.. The flow control valve is provided to maintain the optimum flow of the supplied oil for power steering operation, at all engine speeds. The relief pressure will open when the system pressure exceeds the set value. This normally happens when the steering wheel is turned and held in the lock position.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















### **Specifications** -

Steering Gear Type	Rack & Pinion, End Take Off, Integral Power Assisted
Steering Gear Make	Sona
Rack Travel (Steering Gear)	LH - 75 mm & RH - 75 mm, maximum
Overall Steering Ratio	20:1
Total Turns Available on Input Shaft of the Steering Gear	3.75
No. Of Steering Wheel Rotations (Lock to Lock)	3.6
Torque required on input shaft to move the Rack (preload)	1.5 Nm
Normal Operating Pressure	85 bar
Steering Wheel Diameter	395 mm / 365 mm
Power Steering Pump	Sliding Vane Type - Positive displacement
Pump Make	Коуо
Pump Make	Delphi - from Serial no 42D 67038
Direction of pump rotation	Clockwise when viewed from shaft end
Pump Flow	8.5 LPM @ 1000 rpm
Pump - Pressure Relief	75 kg/cm2 0r 75 bar
Pump - Drive	Gear driven
Wide Operating Speed - Pump	600 rpm - 6500 rpm
Wide Operating Temp. Pump & Gear	- 40 ° C to + 120 ° C
Flow Control cum Pressure Relief Valve in Pump	In-built System 7.5 +0.5 / - 0 Mpa. 8.5 ± 0.7 lit / min @ 1500 RPM

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC















**Automotive Sector** 

Oil capacity - Reservoir	
Oil capacity - System	0.8 aprox.

### List of the MST's -

MST Number	Description
MST - 547	Steering wheel puller
MST - 548	Steering stand
MST - 549	Tie rod end remover
MST - 550	Socket steering pump Nut
MST - 551	Unit wrench -12 mm
MST - 552	Spanner power Steerin
	g Lock nut
MST - 553	Drift pinion assembly
MST - 554	Rack stopper wrench
MST - 555	Installer power Steering Oil End
	Cap
MST - 556	Driver needle bearing
MST - 557	Driver bearing rack Housing
MST - 558	Installer oil seal-Steering
MST - 559	Installer pinion Housing Upper
	Pinion Oil seal
MST - 560	Installer oil seal Power
	steering.
MST - 567	Unit wrench - 10 mm

### **Recommended Lubricants -**

The recommended brand names are

### **DEXTRON TEXMATIC 1278 / 1888 from CALTEX ATF**

Capacity is 0.8 liters

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















### **HVAC**

### **Contents**

**Description** 

**Trouble Shooting** 

Care of the system

In Car repairs

**Control panel** 

**Specification** 

**Recommended Lubricants** 

















### **Description --**

The Heater, Ventilation and Air conditioning combines air conditioning, heating and ventilating functions.

The system comprises of:


- ✓ Blower & Air Inlet system
- ✓ Heater core, and Air distribution assembly.
- ✓ Air Conditioning system.

### Heater system

The heater system is controlled water flow system. A water valve controls the quantity of water entering the heater core.

### Air conditioning System

The system uses non-CFC refrigerant R134A.



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

**HVAC** Version 1, Aug. 06


















The refrigerant at low pressure and temperature enters the compressor where it is compressed and its pressure and temperature increase. The refrigerant after leaving compressor enters condenser and here it is condensed into highpressure liquid and is collected in receiver drier. From the receiver drier it passes through expansion valve where it is throttled down to a low temperature and pressure. After finding its way through expansion valve it finally passes into evaporator coil where it extracts heat from surrounding. The refrigerant, which was in low-pressure liquid state, converts to lowpressure vapour. The low-pressure vapour then again enters the compressor.



The incoming air (in fresh mode or recycle mode) passes through a particle filter & then gets cooled and dehumidified by the evaporator. The evaporator is in operation all the times unless the AC switch is kept in off condition. To maintain minimum evaporator temperature a fixed thermostat-setting switch controls the compressor clutch. This switch which is called Anti freeze switch has a probe so that it touches the coldest part of the evaporator is used to avoid formation of ice. (If ice formation is allowed then the ice formed prevents exchange of heat thus reducing the cooling and forcing the compressor to work continuously/ longer period. Leading to low cooling as well as system failure.)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

**HVAC** Version 1, Aug. 06











Search







The evaporator always cools the incoming air (recirculated or fresh) to an amount set by the fixed thermostat value. The cooled air later goes through the heater coil. Thus the final air temperature is dependent on the amount of hot water passing through the heater.

For example when the control panel thermostat is set to the coldest value then no quantity of hot water goes through the heater and the final outcome is only the cold air. As the control panel's knob is moved towards the hotter the mixing start i.e. the quantity of hot water going through the heater starts increasing proportionately.

It should be borne in mind that when the engine is cold the temperature of incoming water is low, hence to get a desired temperature the knob will have to be set any given position. However as the engine warms up the water coming to the heater also gets warmer, thus the final outcoming air temperature will raise. As a result after the engine warms up the knob in the panel will have to be readjusted to get the same outcoming air temperature.

**Trinary Pressure switch:** It is mounted on Receiver drier.

**High-Low Pressure operation:** If the system pressure becomes low then it switches off the compressor. Thus in the case of refrigerant loss due to any system leak the compressor failure is avoided. Once the pressure increases above 32 bar then the compressor is shut off to avoid any system failure. If the system pressure falls due to any leaks then the compressor is switched off.

**Medium pressure operation:** When the pressure in the system goes above 17 bars then it switches on the condenser fan. As the pressure reduces below 14 bar the condenser fan is switched off.


















# **Trouble Shooting -**

AC Performance Test --

This test has to done in shade and at an ambient temperature of 30 to 40 degrees maximum. If the ambient temperature is more than that, then please take the vehicle to the coolest area available in shade and then carry out the test.

- A. Start the engine, switch on the AC and keep the Engine RPM at 1500.
- B. Set the Blower to 3<sup>rd</sup> speed, the ventilation mode to be set to chest and recalculation mode. The temperature control should be set to the coolest.

#### Now we have two tests

- 1. In the 10-minute open door test, the drop in average grill temperature with respect to the ambient temperature should be 15 degree. Hence if the ambient is 30, then the grill temperature should be 15 degrees.
- 2. In the 10-minute closed-door test, the average grill temperature should be less than 12 degrees.
- 3. The probe should not go more than 1" inside the grill. Take average value of the 4 grilles.

#### Note:

In normal conditions:

The low side pressure should be 1.5 to 2.5 bars. High-pressure side the pressure should be 15 to 17 bar.

This is with reference ambient temperature of 30 to 35 ° C If the ambient temperature is different from the range refer to the <u>chart</u> for getting the range of suction and discharge pressures.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















Symptom	Causes	Remedial action
Low pressure side pressure high Ps>2.5to 2.9 And High pressure side pressure gauge high. Pd>19.5 to 25 bar Discharge air warm	Evaporator flooding due to Block valve stuck open.  1. Dirt in Block valve. 2. Moisture in the refrigerant circuit	
Low side -High High Side- High Ps>2.5-3.0 bar Pd> 19.5-25 bar Suction side piping is hot to touch.	Non condensable (excessive air)  1. Large amount of air caused by insufficient evacuation after repair or servicing of system  2. Leak in system allowing air and moisture to enter.	performance.  ✓ Remove refrigerant ✓ Evacuate/dehydr ate ✓ Change filter/drier. ✓ Charge correct amount of oil & refrigerant. ✓ Check performance
Low side -High High Side- High Ps>2.5-3.0 bar Pd> 19.5-25 bar Frosting on suction side piping	1. Expansion valve stuck open.	✓ Change the expansion valve.
Low side -High High Side- High Ps>2.5-3.0 bar	<ol> <li>Excessive refrigerant</li> <li>Poor condenser cooling</li> <li>Engine or condenser</li> </ol>	<ul><li>✓ Check refrigerant condition</li><li>✓ Check &amp; repair</li></ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC















Automotive Sector		
Pd> 19.5-25 bar  Discharge air- Warm High side tubes-Very hot Compressor clutch- Could continuously cycle on the high pressure switch  Pressure does not come to normal when condenser cooled by water	fan not working 4. Fan direction reverse. 5. Condenser fan clogged with debris/ sand. 6. Radiator overheating.	condenser fan.  ✓ Check condenser.  ✓ Check pressure cap, clearance between fan and radiator.  ✓ Check coolant and any other radiator problem.
Low side- Low or vacuum High side- High Ps> 1.5 bar to vacuum Pd> 19 to 22 bar  Discharge air- slightly cool	<ol> <li>Expansion valve-Stuck closed and or insufficient refrigerant flow to suction side of the compressor.</li> <li>Foreign material or moisture entry causing rust formation.</li> </ol>	<ul> <li>✓ Remove         refrigerant</li> <li>✓ Evacuate/dehydr         ate</li> <li>✓ Change         filter/drier.</li> <li>✓ Charge correct         amount of oil &amp;         refrigerant.</li> <li>✓ Check         performance.</li> </ul>
Low side _ low or vacuum High side- High Ps> 1.5 bar to vacuum Pd> 5 to 7 bar  Discharge air-slightly cool	Clogging on high side:  1. Clogging between compressor outlet and evaporator inlet ( High side)  2. Very little or no	<ul> <li>✓ Remove refrigerant.</li> <li>✓ Clean &amp; flush system.</li> <li>✓ Change filter drier.</li> <li>✓ Charge correct amount of oil &amp;</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

**HVAC** Version 1, Aug. 06















**Automotive Sector** 

High side tubes- Cool and showing signs of sweating or moisture build up at the position after the point of restriction.  Temperature difference found on both the sides of the clogged component.	refrigerant flow to suction ( low) side of the compressor	
Low side Gauge-Normal to Vacuum (Gradual reduction) High side- Normal Ps> 1.5 to vacuum Pd> 14 to 16 bar  Discharge air becomes warmer as low side cycles to vacuum.	<ol> <li>Excessive moisture in system</li> <li>Moisture can freeze within the expansion valve and cause blockage through rust formation.</li> </ol>	valve 9 check)
Low side- High High side- Low Ps> 4 to 6 bar Pd> 7 to 10 bar  Compressor -Noisy. Discharge air- Warm Discharge hose- Cool.	<ol> <li>Compressor malfunction.</li> <li>Compressor faulty, internal blockage in suction Hose after low side filing port.</li> </ol>	<ul> <li>✓ Replace compressor.</li> <li>✓ Remove refrigerant</li> <li>✓ Evacuate/Dehydra te.</li> <li>✓ Change filter drier.</li> <li>✓ Charge correct amount of oil &amp; refrigerant</li> </ul>

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC







		√ Check performance.					
Abnormal noise	<ol> <li>Belt slippage/damage.</li> <li>Idler pulley misalignments</li> <li>Compressor clutch pulley faulty.</li> <li>Loose compressor mounting bolts</li> <li>Loose A/C plumbing touching firewall/ front panel/ fenders.</li> <li>Compressor internal damage.</li> </ol>	in the pulley.  ✓ Check the compressor					
High /Low pressure equalize soon after compressor stops. Compressor is not hot to touch.	<ol> <li>Faulty compressor discharge or inlet valve.</li> <li>Faulty compressor seal.</li> </ol>	✓ Replace compressor.					
Compressor pressure drops rapidly after switching off and does not stabilize to	1. Non condensable in system	✓ Recover refrigerant/ check for leaks and repair					

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

**HVAC** Version 1, Aug. 06

















saturation pressure as per ambient temperature. Line to condenser is excessively hot.	Restricted flow of refrigerant in system	restriction Evacuate ✓ Replace receiver drier. ✓ Charge through the charging unit.
Insufficient/ no air flow	<ol> <li>Blower rotation direction wrong.</li> <li>Sealing disconnected. Insulation piece blocking air passage.</li> <li>Mode cable not adjusted properly.</li> <li>Voltage insufficient &lt; 12 Volts</li> <li>Improper earthing.</li> <li>Open circuit, wiring harness.</li> <li>Fuse blown</li> <li>Filter clogged</li> </ol>	blower fitment.  ✓ Renew sealing. Remove blockage.  ✓ Adjust cable.  ✓ Recharge battery. Check the charging system.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC











Compressor clutch engagement not satisfactory	<ol> <li>Weak battery.</li> <li>Faulty clutch relay.</li> <li>No refrigerant.</li> <li>Shorted clutch coil.</li> </ol>	<ul> <li>✓ Replace fuse.</li> <li>✓ Charge battery.</li> <li>✓ Change relay.</li> <li>✓ Check for leaks, charge refrigerant &amp; oil &amp; check.</li> <li>✓ Replace coil.</li> <li>✓ Change clutch plates</li> </ul>
Check condenser/ radiator Fan- direction of rotation	<ol> <li>Condenser fan pusher type Radiator fan puller.</li> <li>If fan not operating:         <ul> <li>Loose connection</li> <li>Loose wiring harness.</li> <li>Motor burnout.</li> </ul> </li> </ol>	
















# Air circulation in the climate box -



	Knob Position				
Flaps↓	Face	Face-foot	Foot	Foot- defrost	Defrost
Face LH	Open	Open			
Face RH	Open	Open			
Face MiddleRH	Open	Open			
Face Middle LH	Open	Open			
Center Console	Open	Open	Open	Open	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















Foot LH	Open	Open	Open	
Foot RH	Open	Open	Open	
Defrost			Open	Open

The Airflow can be either fresh air or recirculation mode.

The air box with the electrically controlled flaps & recirculation mode is slightly different. Sketch given below.



# Care of the system --

The system should be flushed and charged every 50,000 or 1 year of operation. The quantity of the gas which has to be filled is 830  $\pm$  20 grams.

The refrigerant used is R134A.

Do not use mix R12 & R134 A. the oils used for compressor is unique for R134. DO NOT MIX. IT WILL CAUSE DAMAGE TO O RINGS as well as the R/D.

Though R134A is non-CFC, it is recommended that it should not be discharged to atmosphere.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















**Automotive Sector** 

We recommend the use of ROBINAIR equipment for evacuation, charging of the system.

The particle filter should be changed once in 15,000 Kms. Also it is recommended that the vehicle should not be driven with AC or blower on without the particle filter as it will seriously damage the AC system components.

It is recommended that the evaporator fins be cleaned of dirt/ fungus every 40,000 Kilometer or once in 9 months for normal operation. If the vehicle is not clocking long mileage then also it should be cleaned every 9 months (normal areas) and 4 months in dusty conditions.

This will ensure that the heat transfer is effective hence better cooling and also increase the airflow. The recommended cleaning agent is mentioned in the recommended lubricant section.

# In Car repairs --



#### Caution

- ✓ Extreme care has to be taken to prevent any liquid. refrigerant in coming in contact with skin. Always wear safety goggles.
- ✓ Do not allow liquid refrigerant to touch bright metal. Refrigerant will tarnish bright metal and chrome surface. Refrigerant in combination with moisture is very corrosive and can damage to all metal surfaces.
- ✓ When charging, always keep the tank in upright position. If the tank is on its side or upside down, liquid refrigerant will enter and affect the compressor.
- ✓ Always double check that the gas being used is a R134A. The refrigerant cylinder is color-coded to avoid confusion. R134A is Blue.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC













- ✓ The compressor oil for R134A gas is different from R12A compressor oil.

  Do not mix. If the R12A compatible compressor oil is used then it will damage the O rings as well as the receiver Drier.
- ✓ The Robinair equipment AC 350 should be used with R134A gas only.
- ✓ Never discharge a system or do brazing/welding operation when the engine is ON.
- ✓ PAG oil is highly hygroscope. Open containers only when ready to use. Cap containers immediately after use.
- ✓ Use only the specified oil for the AC system
- ✓ Do not allow PAG oil to contact bare skin.
- ✓ Do not allow PAG oil to contact paint work- wash immediately

The charging procedure comprises of the following distinct steps.

Discharging the system.

Evacuation of the system and checking for low vacuum leak

Purging - if required.

Preliminary charging & High Pressure leak test.

Charging the system.

**Evaporator cleaning** 

Performance test.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















# Discharging the system --

The following procedure is recommended for evacuation.

- 1. Connect the hose of Recovery unit to the vehicle circuit Red hose to the high pressure charging port Blue hose the low pressure charging port
- 2. Open the quick coupler valves on the hose after they are connected to the system
- 3. Check the manifold gauges the units control pane. They should register above zero. If it is indicating zero then either the hose is not connected properly/or/quick coupler valves are not opened or the system is empty.
- 4. Make sure that the drain valve at the bottom is closed.
- 5. Open both the manifold valves on the control panel
- 6. Open the Gas (vapor valve and liquid valve on the tank.
- 7. Switch on the power
- 8. Choose Recover option from the panel
- 9. To assure that the complete recovery of the refrigerant. Wait for 5 minutes and watch the manifold gauges for a rise above zero.
- 10. If a rise occurs, press HOLD/CONT. repeat until the system pressure hold for at least 2 minutes
- 11. The system displays the weight of the refrigerant recovered.
- Confirm that the oil catch bottle is empty. Then slowly open the drain 12. valve and allow the oil to be drained into the bottle. When all the oil has been recovered, close the valve immediately. New clean oil must be added to system before recharging with the refrigerant

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















The automatic recovery unit will operate until the air conditioning system has been emptied of refrigerant down to atmospheric pressure. The cylinder can now be closed.

#### Evacuation of the system -

The evacuation and leak test ensues that the system does not leak under low-pressure conditions.

Ensure that the hoses are connected to the charging ports and valves on the hoses. Tank & manifold are open.

Choose vacuuming program (Shift/Reset option) from the control panel.

Set up the vacuuming time in minutes. Approximately 15 minutes of vacuuming time is recommended.

The unit displays the complete message after the vacuuming is over.

Check the moisture indicator. If it is green, it means that the system is ready for recharging. If it is not green then manual recycling has to be done for one hour. In case the moisture indicator still does not turn green, the reason could be saturated receiver drier. It should be replaced.

The charging station is equipped with recycling facility. During evacuation the refrigerant is automatically recycled to assure recharging with the cleanest possible refrigerant. Recycling begins automatically after 5 second of the vacuum pump starting. Non condensable gases (mostly air) are automatically vented from the tank.

The system must hold the vacuum of -100 Kpa for a minimum of 15 minutes. If vacuum is held then the system has no ands and should be evacuated for further 15 minutes

This completes the evacuation process.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















## Purging - if required --

Where the system has been ruptured, contaminated, or a compressor has to be removed, reinstalled or replaced, the system should be checked for contamination, and if so then the entire system must be flushed.

The system can be flushed with Nitrogen.

#### Preliminary charging & High Pressure leak test --

This ensures that the system does not leak under high pressure conditions.

Confirm that the hoses are connected to the charging ports and valves on the hose, Tank & manifold are open

Enter the refrigerant quantity by weight and press ENTER. (At least 200 grams of charge are required to do the high-pressure leakage test)

Press CHG to start charging. The unit displays the completed message after the charging is completed.

Use the electronic leak detector to probe the leakage's. Leakage checking to be done at the following points.

Expansion valve joints

All pipe joints.

Suction & discharge ports.

Both the charging ports

Note: Inspect for leaks by slowly moving the probe of the detector around all the hose connections and points of possible leakage's. The R134A is heavier than air; hence, any leakage will be more apparent at the bottom of fitting.

# **Charging the system** -

If no leaks are found then do an additional charging of  $650\pm20$  grams. The total system requirement is  $830\pm20$  grams.

All copyrights reserved by Mahindra & Mahindra Ltd

Main Menu I

Scorpio SC DC



















However in case of leakage, the system should be <u>discharged</u>. After that repeat, the steps from evacuation onwards till the above steps. Then proceed.

In case the system was checked for High pressure leaks by using Nitrogen, Evacuation should done first and then system should be directly charge with  $850\pm20$  grams.

Close both the manifold valves and then start the vehicle.


Start the vehicle's AC system and set it to maximum cooling. Check the pressure gauges and temperatures in the vehicle.

Turn off the engine.

Disconnect the high side hose and start the vehicle. Open both the manifold valves to pull the refrigerant from both the hoses into the system.

At the lowest operating pressure close the low side valve and switch off the vehicle. Disconnect the low side hose and remove adapters if used.

Close the high side manifold valve. Both the valves should now be in closed position.



engine.

✓ Never run the compressor without the refrigerant in the system as the lubricant relies on the refrigerant flow

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















Accurate system refrigerant charge can only be determined by charging the correct amount of R134a

If in doubt as to gas charge, e.g.
Suction pressure low
Or
Discharge pressure low
Or
Air outlet temperature at the face high.

Then: Evacuate the system and Charge with the 830±20 grams of R134 A

Carry out cooling system pressure test and suction (low side) pressure reading *comparison*.

#### **Evaporator Cleaning Procedure -**

- 1. Remove Blower connection & remove Blower Assembly.
- 2. Insert "Coil Rinse Nozzle" inside the Climate Box Assembly.
- 3. Spray "Coil Rinse" at least 2 times.



4. After Spraying, the Liquid becomes Foam & enters in the Evaporator coil.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC






















- 5. Assemble the removed Blower Assembly again.
- 6. Wait for 10 minutes.
- 7. Close all the Vents. Start AC with Blower on 1st speed.
- 8. Run the Engine at 1500 RPM for 5 minutes.
- 9. Put AC Off & put Blower on 4<sup>th</sup> Speed for 5 minutes, Keep all the Vents closed.
- 10. All the Evaporator Containment's & Water (Liquid) will drain out through the Drain Hose & Evaporator becomes clean.

















# <u>Special Instructions for Vehicle Users to avoid Wet Smell on the Evaporator:</u>

Put OFF the AC & put Blower on  $4^{th}$  speed 5 minutes before stopping the Vehicle, this will keep Evaporator DRY & NO WET SMELL will come from Evaporator.

#### Performance test -

Pressure gauge readings together with the face air outlet temperatures are the only method of checking and diagnosing the cooling system.

## Checking system oil charge -

The compressor is charged at the factory with 150 cc of FD46XG(PAG) refrigerant oil, which circulates within the entire AC system. Only this type of oil, which is pale yellow in color, must be used when adding or changing oil. This oil is not compatible with any other PAG oil. It is not necessary to regularly check the oil level in the system. It should be remembered that the oil gets circulated within the whole system. Therefore, whenever an AC system component is replaced a quantity of new refrigerant oil must be added to the system, where a major loss of system oil has occurred. The loss normally takes place when:

Hose failure or leak is present.

Refrigerant system component is damaged due to collision. If oil is suspected to be in the system

The procedure to be followed is

Recover refrigerant from the system by <u>evacuation</u>.

Drain out the refrigerant oil.

Flush the remaining oil using R134a refrigerant.

Add 150 cc of new refrigerant oil to the compressor.

Install the compressor after replacing the Suction and discharge "O" rings.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















Note: Ensure that the 'O" rings are not twisted and that both the seals and 'O' rings are clean and then oil.

. Follow the steps of **charging procedure**.

#### Compressor Replacement -

- 1. Discharge the refrigerant
- 2. Remove the suction and discharge pipes from the compressor, ensuring no foreign items get clogged to the ports. (In order to have better accessibility it is suggested that the following parts be removed first-right wheel, right aprons; oil cooler)
- 3. Loosen the tensioner pulley.
- 4. Remove the fan belt
- 5. Loosen the compressor mounting bolts.
- 6. Remove the compressor.
- 7. Drain and measure the refrigerant oil from the original compressor by removing the drain plug.
- 8. For example, the oil quantity drained from the original compressor is 80 cc.

The replacement compressor comes with 150 cc of compressor oil. The implication is that out of the total 150 cc of the original compressor. 70 cc of oil is in the system. Hence if the replacement compressor is fitted as it is, it will cause this 70 cc extra to get into the whole system and

affect the performance.

9. Hence it should always be -Oil to be drained from new compressor =Total oil capacity of compressor-Drained oil

The refitting procedure is the reverse of assembly procedure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















## **10.** Follow the steps of **charging procedure.**

## **Control Panel** ---

The control panel has 3 knobs- the right knob is for degree of cooling to heating- depending on the knob setting. For maximum cooling set the knob on blue color dot and for maximum heating set the knob on red color dot.



The left knob sets the flap position to direct the airflow to face only or face & feet or feet only or feet & defrosting or only defrosting.

The middle knob controls the blower speed. The bottom row indicates AC low , AC high & fresh air / recirculation mode.

The control panel is PCB based & has only one cable for water valve opening operation.

All copyrights reserved by Mahindra & Mahindra Ltd

Main Menu

Scorpio SC DC


















# View of the Base plate assembly with actuators (Electrical Operation of Flaps & circulation modes -



All copyrights reserved by Mahindra & Mahindra Ltd

Main Menu

Scorpio SC DC


















# View of the electrical actuator base plate Assembly -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

















# Setting of the control panel Cable --

The procedure, which is, outlined below are the setting procedure for assembly. However, please note that the removal of the cables should also be done in the same positions.


Caution: Failure to follow the procedure may cause breakages.

Note: The procedure for setting of the links with Electric actuation is given after the manual control panels

#### Water valve setting Procedure

# Water valve setting Procedure -

# Hold the control panel in front of the housing.



Keep the cooling & heating knob at the highest cooling point position.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

HVAC Version 1, Aug. 06























Water lever at closed position,

Clamp the cable of the control panel water valve to closed position of water lever in the housing side.
















# View of linkages for different actuation -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC




















# Fitting the rod by snapping it on the Hook -



















# Photo showing the levers in the face mode -



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC

**HVAC** Version 1, Aug. 06


















# Fitting the Fresh /re circulating flap ( with the flap in the fresh air mode) -



Connecting Rod



Motor for Fresh / Recirculating mode

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















## Replacing the Antifreeze switch -

The function of the anti freeze switch is to protect the refrigerant system from damage. It switches off the compressor when the condenser water dries ices up on the evaporator fins. Otherwise, the evaporator becomes extra cool, resulting in the air passage between the fins getting blocked. Suction pipe becomes extra cool and sometimes iced up, the refrigerant remains liquid even after the expansion valve due to insufficient heat transfer across the evaporator surface and eventually the compressor will get damaged due to liquid refrigerant inflow.

### Replacement procedure:

Remove the wiring harness from the connector.
Pull out the probe carefully.
While fitting back, ensure that the washer & the O ring is present.

## Recommended Lubricants -

Refrigerant: R134A

Compressor oil: FD46XG. PAG stands for (Poly Alkaline Glycol oil)

## Oil quantity to be filled while replacing components -

- Condenser/evaporator: In addition to the drained quantity- 20 cc
- Receiver Drier: Add 20 cc of new oil
- If any one pipe is replaced then 10cc. (If 2 pipes replaced then it should be 20 cc.)

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



















## **Evaporator cleaning Agent --**

"Coil Rinse" Packaged by Chemguard Laboratories; Kuala Lumpar.


In India Marketed by Astro Trading Company Contact person Mr. Rakesh Bhai; Mobile no 9820141308

# **Specifications** -

Blower Motor: 3700±300; 12 V; 300 W Condenser Motor: 2500± 200; 12V; 200 W

Expansion Valve- 2T

Chart showing the Effect of ambient temperature on Low Pressure side pressure & High side pressure with R134 A



All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC DC



































































Main Menu Index

**Print** 














































Index












Main Menu Index


Search





Main Menu Index


Search

**Print** 












































Main Menu Index

**Print** 




















**Print** 

















Painting / Refinishing.

**Trouble shooting** 

**Paint application** 

**Technical Terms** 

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC




















# **Trouble Shooting**

Symptom	Causas	Domodial action
Stains under the paint  Stain appearing in the film under the finishing paint.	Application on to a stained undercoat (Fall out, faulty preparation). Gun cleaning problems.	Preparation.  ✓ .Remove the affected coats with abrasive paper  ✓ Finish sand Painting.  ✓ Mask and apply the final coats according to recommended procedure

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC



















Automotive Sector		
Symptom	Causes	Remedial action
Micro Blistering/ Pinholing  Concentration of very small bubbles of solvent or	<ol> <li>Paint too thick.</li> <li>Flash off time too short.</li> <li>Oven temperature rises too rapid.</li> <li>Viscosity too high, high paint output</li> <li>PINHOLE</li> <li>Metal</li> <li>Topcoat</li> <li>Undercoat</li> <li>Undercoat</li> </ol>	Preparation.  ✓ Remove the affected coats with abrasive paper.  ✓ Finish sand.  Painting.  ✓ Mask and apply the final coats according to recommended procedure.
air included in the paint film. A pierced bubble is called a pinhole.  Blistering  Blister or bubbles caused by absorption or presence of water.	1. Absorbed salts incompletely removed, pollution of the undercoat (finger marks under the paint), faulty products.	Preparation.  ✓ Remove the affected coats with abrasive paper  ✓ Finish sand  Painting.  ✓ Mask and apply the final coats according to recommended procedure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC




















## **Symptom Craters**



Cavities in the finish coat, possibly allowing the previous coat to show.

## Causes

1. Contamination of the prepared surface causing a wetting fault (silicone, grease, wax, soap, atmospheric agents cause which can cause a similar activity)



#### Remedial action

- ✓ Remove the affected coats with abrasive paper.
- ✓ Finish sand.
- ✓ Mask and apply the final coats according to recommended procedure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC

Paint Version 1, Aug 06

















Automotive Sector		
Symptom	Causes	Remedial action
Stains or Deposits on the Paint  (Entroperson 200)	Stain or residue of product deposited during manufacture, preparation or use of the vehicle e.g. adhesives, fuel, hydraulic fluid, lubricant	For Deposits  ✓ Treatment with a body work cleaning product. If the fault persist  Polishing: Elimination of the fault using the polishing paste. The thickness of the paint film removed must not exceed 8 microns.  ✓ Return the gloss with a finishing polish.  Sanding + Polishing. Elimination of the fault using a suitable abrasive paper.  The thickness of the film removed must not exceed 8 microns. Next polish with a polishing paste and a finishing polish.  If the fault is still persisting. Preparation. Remove the affected areas with abrasive paper. Finish sand.  Stain: Preparation Remove the affected coats with abrasive paper Finish sand Paint. Mask and apply the final coats as per recommended procedure.

Scorpio SCDC

Paint Version 1,Aug06



















Automotive Sector  Symptom	Causes	Remedial action
Atmospheric fall out	Stains or deposits	Remove the affected coats
<b>F</b>	mainly affecting the	with abrasive paper.
	horizontal surfaces	
	of the body work.	If bare metal is showing -
		apply an anti corrosion
N	This fall out can	primer.
A STATE OF THE STA	cause an attack in	·
	depth, which can	Finish sand
	extend to flaking of	
	the paint if it is not	Mask and apply the final
	dealt with without	coats according to
	delay.	recommended procedure.
	Atmospheric fall out	
	can be of industrial	
	origin( foundry,	
	cement works,	
	furnace),	
	vegetable ( tree	
	resin) or animal (	
	bird or insect	
	droppings	

Scorpio SCDC

















Automotive Sector	Causes	Remedial action
Symptom	Causes	
Runs  Layers of paint or varnish in the shape of a curtain starting, generally, on vertical parts or from a panel joint	Viscosity of the product:-  1. Thickness too great.  2. Paint flow too great.  3. Air pressure too low.  4. Gun too near.	Depending on the severity of the fault, carry out one or the other of the following solutions:  Sanding +Polishing. Elimination of the fault using a suitable abrasive paper. The thickness of the paint film removed must not exceed 8 microns. Next polish with a polishing paste and a finishing polish  Or  Remove the affected coats with abrasive paper. Finish sand  Mask and apply the final coats according to recommended procedure.

Scorpio SCDC



















### **Automotive Sector** Causes **Symptom** Remedial action Scaling/Flaking Preparation. ✓ Remove the affected SCALING DOWN TO BARE METAL coats with abrasive Topcoat paper. ✓ If bare metal is showing apply an anti corrosion primer. Colur Coat Flaking from the Undercoat ✓ Finish sand. Painting. ✓ Mask and apply the final coats according to Flaking is related to recommended poor adhesion of one procedure. coat on the previous coat or to the base Mechanical and can affect one destruction of one or several or more of the coats components of the of the paint film vehicle. which can extend to bare metal and give It can be caused by rise to corrosion of either metal parts. Stone chips, damage. High-pressure washing used inappropriately Preparation or paint procedures not followed correctly.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC



















# Symptom



Small solid particles embedded in the paint producing a rough paint surface

# Causes

Foreign bodies present in the air or the product during painting.



# Remedial action

**Preparation.**Depending on the severity

of the fault, carry out one or the other of the following solutions:

Sanding +Polishing.

Elimination of the fault using a suitable abrasive paper. The thickness of the paint film removed must not exceed 8 microns. Next polish with a polishing paste and a finishing polish

Or

Remove the affected coats with abrasive paper.

Finish sand

Painting.

Mask and apply the final coats according to recommended procedure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC



















Symptom	Causes	Remedial action
Thin paint / Lack of	1. Paint flow	Preparation.
cover	insufficient.	Flat with fine paper to
	2. Unsuitable gun	obtain adhesion to the
	nozzle.	underneath coat
	3. Gun too far away.	Painting.
		Mask and apply the final
		coats according to
		recommended procedure
Partial or total		
insufficiency of		
color or varnish. It		
can cause		
differences in color		
and relief of the		
paint surface or a		
lack of gloss		
Orange Peel	Application	Preparation.
D. A. S.	parameters, solvent	Remove the affected coats
So PAS	balance, paint	with abrasive paper.
8	viscosity, surface	. If bare metal is showing
	condition of the	apply an anti corrosion
	previous coat, paint	primer .Finish sand
	film thickness.	Painting.
NAME OF THE PARTY		Mask and apply the final
		coats according to
		recommended procedure.
Drangunged		
Pronounced		
undulations of the		

Scorpio SCDC



















Automotive Sector		
paint film giving a	GOOD BAD	
granular	MINERAL PROPERTY OF THE PROPER	
appearance		
resembling orange		
peel		
Peer		
Symptom	Causes	Remedial action
Insufficient gloss	Insufficient	Polishing.
msurrene gross	thickens, sinking,	Elimination of the fault
Poor reflection of	excessive baking,	using polishing paste.
	<u> </u>	using potisiting paste.
light or image	under baking of the	The thickness of the point
which can appear	preceding coat,	The thickness of the paint
Matt	faulty products	film removed must not
		exceed 8 microns.
		Return the gloss with a
		finishing polish.
		If the fault still persist.
		Preparation.
		_
		Flat with fine paper to
		obtain adhesion to the
		underneath coat then paint
		Painting.
		Mask and apply the final
		coats according to
		recommended procedure
Marbling	1. Temperature of	Preparation.
	the application	
	too low	Flat with fine paper to
	2. Faulty dilution	obtain adhesion to the
	3. Poor spraying	underneath coat.
	technique	
	4. Faulty gun	Painting.
	adjustment	Mask and apply the final
		coats according to
		recommended procedure.
		recommended procedure.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC



















Automotive Sector		,
Dark or light stains		
in the shape of		
irregularly		
distributed veins		
giving a non		
uniform color to		
the panel Color difference.		Preparation.
Color difference.		Flat with fine paper to
		obtain adhesion to the
Difference in color		underneath coat
visible between		
two panel		Painting.  Mask and apply the final coats according to
		recommended procedure
Sanding/Polishing	Sanding/ polishing	Preparation.
marks	procedure poorly executed	Flat with fine paper to obtain adhesion to the underneath coat Painting.  Mask and apply the final coats according to recommended procedure

Scorpio SCDC



















Sanding marks: scratches visible through the paint film.

Polishing marks: lighter paint halo

### Deterioration

The micro scratches can be caused by an over aggressive roller brush car wash (badly maintained, incorrectly adjusted, etc) In this case they are circular or lengthwise and

Preparation. *Polishing*. Elimination of the fault with cutting paste.

The thickness of paint removed should not exceed 8 microns.

Restore the gloss with finish paste. If the fault persist Fine rubbing down +

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC





















Superficial deterioration of the paint finish

cover the whole of the body. In other case they will be multi directional (a dirty or abrasive sponge, rubbing by an object etc.) polishing.
Rub down with suitable abrasive paper and then polish. *Scratches*Preparation. Remove the affected coats with abrasive paper.
Finish with fine paper Painting.
Mask and apply the final coats according to recommended procedure

## Paint application

# **Surface preparation**

Proper surface preparation is the key to top quality body panel refinishing. Even if it is sometimes long, sanding with the adequate abrasives of suitable material and properly trained personnel will ensure a quality result. The importance of selecting the right grit is a must. If unsuitable grit is used then will cause damage impossible to hide. For example a 40 grit causes very deep scratched - do not ever use this grit.

Always clean the panel surface with a wax and grease removal solution and then wipe the surface with a lint free rag before applying primer or paint. Cleaning will also remove any residual silicone from the painted surface.

Body putty that is procured from any major supplier is recommended. If synthetic body filler is to be used then it should be a quality product.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC



















The type of primer to be used is dependent on the condition of the panel surface. Bare metal should be primed with epoxy - base. A sealant is recommended when applying a second color coat over an existing color coat. With certain colors sealants are also important in preventing bleed through.

#### Base/ Color coat

Base color coat paint finishes must be applied in a clean envoirement. Top loader guns are recommended for applying the base / color cat paint.

Base / color coat paint should be reduced/ thinned and applied to the manufacturers suggestion. Please refer to the manufacturer suggestion.

#### Basecoat/ Clearcoat

Basecoat / Clearcoat application is a two stage process. The Basecoat is applied over the final primer coat. The Clearcoat is then applied over the Basecoat. The Clearcoat provides the paint finish with a high gloss and increased durability

The work areas should be well ventilated for application of Basecoat and Clearcoat paint. More particularly when applying the Clearcoat paint.

# Buffing & polishing

Minor paint defects in Basecoat/ Clearcoat can frequently be removed by light sanding, buffing & polishing. Wet sand the defect with 600 grit soaked in mineral spirits.

Buff the surface area with fine grade buffing compound. Finish the repair with quality polishing compound to blend and restore the gloss.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC

Paint Version 1, Aug 06

















## Single Coat

A single coat spray pattern is applied from left to right. After that the returning right to left spray pattern is applied so that it overlaps the lower one half of the initial spray pattern

#### **Double Coat**

A double coat spray pattern is applied from left to right. Then the returning spray of right to left is applied.

### **Drying**

Drying and hardening of the film involves 3 stage of evaporation.

1st stage- Dust free stage.

2<sup>nd</sup> stage- tack free stage.

3<sup>rd</sup> stage-hard dry stage.

It is recommended that to obtain a high quality of gloss the painting operation and drying be done in a paint booth where the heating can be achieved.

# Degrease/ De wax

Degreasing or dewaxing involves cleaning a panel surface either with 3M Allpurpose cleaner or any other equivalent. This removes the surface grease or wax

#### Flash Time

is the time required for the solvent to evaporate from the applied primer / paint coat.

#### Mist Coat

A mist coat is frequently used as the final color coat. Mist coats are overthinned paint that is sprayed wet.

#### **Surface Primer Coat**

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC

Paint Version 1, Aug 06

















A surface primer must be applied over the repaired metal substrate. The body parts taken from the Spare parts have the OE treatment of CED priming.

The primer provides a bond between the metal and the colors base coat. Various types of primers for use in exposed parts are available. Surface primers are available in either sandable or non-sandable form.

Spot putty can be applied on top of the primer to cover up small imperfections which will not get covered / concealed by the standard primer

#### Reducer/ Thinners

Is mixture of volatile liquids and are used to reduce the surface primers and color coat paints. Use only the type that is specified.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SCDC

Paint Version 1, Aug 06

















Wheels & Tyres

**Description** 

**Trouble Shooting** 

Care of the system

**In Car repairs** 

Removal & Refitment of the tyre

**Specification & Wear Data** 

















The tyres fitted in Scorpio are radial tyres and with a suitable wheel disc. The tyre size can be is 235. Additionally the Scorpio All New is shod with tubeless tyres.

In the tyre the P 235/75 R 15. The 215 is the width of the tyre in mm at the designated air pressure and load. The / 75 is the aspect ratio of the tyre. (Ratio between the height and width here the height is 0.75 times the width

The tyres play a very important and vital role in the vehicle handling and ride characteristic. Hence it is advised that any change not as per the specification have to be done with caution.

The air pressure maintained has a direct influence on the fuel average obtained, braking and also on ride characteristic. Hence it is imperative that the tyre pressure be maintained as per specification. The tyre specified with the specified air pressure gives these tyres a safe speed of 180 Km/hr

# Trouble Shooting -

Symptom	Causes	Remedial action
		<ul><li>✓ Maintain the correct tyre pressure.</li><li>✓ Do the tyre rotation.</li></ul>
Rapid wear at Shoulder	Under Inflation Lack of rotation Excessive cornering.	

















Automotive Sector		✓ Maintain the correct <u>tyre</u> <u>pressure.</u>
Rapid wear at centre	Over inflation	
		✓ Maintain the correct <u>tyre</u> <u>pressure</u> .
Cracked Treads	Under Inflation	
		Check and adjust:  ✓ Hub end play  ✓ Camber to be checked and adjusted.
One Edge Wear	Excessive camber Excessive cornering	
one Lage Wear	- Comerning	<ul> <li>✓ Check &amp; correct Toe In</li> <li>✓ Check the chassis bend</li> <li>✓ If tyre rotation not carried out as per schedule. Do the tyre rotation.</li> </ul>
Feathered Edge Wear	Incorrect Toe In No tyre rotation.	

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC

















Automotive Sector		
		<ul> <li>✓ Balance the tyres.</li> <li>✓ Check the brake drum roundness.</li> <li>✓ Check jammed wheel cylinder/ calipers.</li> <li>✓ Check the wheel</li> </ul>
Bald Spots	Unbalanced tyre Out of round brake drums in rear. Faulty wheel bearings. Sudden braking.	bearings. ✓ Avoid driving with sudden brake locking.
Wavy / Scalloped wear	Lack of rotation or Worn or Out of Alignment Suspension	
Side Wall crack- radial/ diagonal	Kerb damage Stone hit	
Side wall crack circumferential / tyre bulging	Run Flat ( It is more obvious from inside )	


















The tyre is one of the most abused components hence maintaining the tyre is of utmost importance.

The recommended tyre pressures are given below:

Tyre size P245/75 R16		
Front	Rear	
2.1 bar / 30 psi	2.4 bar / 34 psi	

The tyre pressure should be checked once in a fortnight. (Once a week during summers). The tyre pressures should always be checked & corrected in cold condition. The valve should be always covered with the valve cover. An opened valve can have the valve needle stuck in a partial position causing the tyre to bleed during operation..

The tyre pressure specified can cater to continuous high-speed performance. Hence it is not advisable to increase the tyre pressure before going on a high speed run.

The practice of keeping the tyre pressure lower in summer is actually detrimental to the tyre. To understand that let us examine what happens - if lower pressure is kept. Then the sidewall flexing is going to be more hence the heat generation will also be higher. Which will result in a faster increase in tyre pressure. So the wear rate is going to be higher.

Similarly the practice of bleeding the tyre pressure to reduce the pressure after a long run can cause the sidewall to crack and in a worst scenario sidewall bulging.

Before going on a long drive it is a good practice to remove the stones/pebbles trapped in the treads. The probability of a puncture due to stone trapped and digging through the crown once it gets heated up is reduced.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC



















It should also be kept in mind that a radial tyre with higher pressure is more prone to burst under impact from stone at high speed or kerb impact. Lower air pressure results in higher sidewall flexing and drastically increases the chance of sidewall damage / cut in bad roads.

Wheel balancing should be done at least every 20,000 Kms. It is compulsory to do a balancing of the wheel after any puncture.

The tyre rotation should be carried out every 10,000 Kilometer's

An improper wheel alignment will have an adverse affect on the life of the tyre. Hence it is suggested that the wheel alignment be checked initially at 10,000 kms then every 20,000 Kms. (In case the vehicle has traversed through extremely bad terrain at high speed then it should be done earlier. If the wheel disc is having any deformation particularly in the bead seating area then do not wait until the mileage has coveredget it balanced.) In case of abnormal tyre wear refer to the Trouble shooting section and take the corrective action suggested.

The grooves in the tyre are used to pump out the water between the road and the tyre. In case the water is not pumped out the tyre will ride on water. Since the coefficient of friction of water is very low that will result a sliding action. Obviously the amount of water which the tyre can pump out between the ground and the tyre will depend on the depth of the groove which is acting as a channel. The tyre manufacturers recommend that a minimum tread depth of 1.6 mm should be present.

Once the tread depth is less than 1.6 mm it is recommended to replace the tyres. It is not advisable to retread the tyre.

Any kind of lubricant on the tyre is detrimental as it promotes degradation of rubber and also increases the chance of hardening. Normally this happens when a mechanics rubs the spare oil or grease on to the sidewall of the tyre.


















Automotive Sector

The tyre rotation pattern is -



## In Car repairs -

The tyres should be removed and then only attended for puncture or damage. In situ repairs are not recommended.

For removal of the tyre from the vehicle the jacking points are:

For 2WD Front- to be supported on the chassis, behind the lower arm just below the first outrigger.

For 4WD Front -Behind the lower arm just below the first outrigger. While locating the jack or the locating for the 2-post lift please ensure that it does not touch the torsion bar. (It can cause the torsion bar to bend.)

For the rear wheels: below the spring.

### Caution

Never go under the vehicle when it is jacked up. This jack is meant for only raising the wheel. For any under body work/inspection support the vehicle on vehicle stands.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC



















If the vehicle is run with severely under inflated tyres - the vehicle stability may be affected. A run flat wheel can also damage the wheel disc- besides literally shredding the tyre.

## Removal & Refitment of the tyre -

It is recommended that the tyre removal and refitment on the wheel disc be done in a tyre specialist shop where the tyre fitting machines are available. The advantage of the machine over the conventional method is that the damage to the beading area is totally avoided.

In absence of the machine. Ensure that:

No sharp tools are inserted while removing the tyre.

No sharp tools/ screwdriver is used while fitting the tyre.

While refitting the tyre the use of powder between the tube & the tyre is recommended

It is recommended that the tyre be inflated to a pressure of 40 PSI. This will ensure that the bead is locked in properly and also in centralizing. Then later reduce the pressure to the recommended pressure.

# Removal & Refitment of the spare wheel from the vehicle -

Remove the covering on the
rear and using the wheel
spanner lower the spare wheel
Lower the wheel on to the
ground and take off the
locating tang from the disc.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC – DC



















Automotive Sector	
	The fitment of the old tyre to the spare wheel carrier is the reverse of the above procedure  While fitting the tyre on to the axle ensure that:  The boltholes in disc are not oblong.  The threads of the bolt are not having dirt - neither is there dirt/ mud in the nut. (Generally while removing a wheel the nuts are left in the ground collecting dirt/mud. It is a better practice to keep the removed nuts on vehicle.



While tightening the wheel nut tighten as per the sequence shown.

Caution: Failure to do so can cause vibration of the steering wheel at high speed.

All copyrights reserved by Mahindra & Mahindra Ltd

Scorpio SC - DC



















# <u>Tightening Torque's</u> -

Description	Torque Nm (lbf-ft)
Wheel Nut	97.5± 5 Nm (72 ±4 lbf-ft)

# Specification & Wear Data -

Run out of the tyre- radial	1.5 mm
Run out of the tyre- lateral	1.5 mm
Unbalanced allowed- tyre	Maximum 1.8 Kgf
Minimum tread depth	1.6 mm











