




CHAPTER 7. ELECTRICAL

DT175D CIRCUIT DIAGRAM	H-3
COLOR CODE.....	H-3
ELECTRICAL COMPONENTS	H-4
CHECKING OF CONNECTIONS.....	H-5
CHECKING OF SWITCHES	H-5
SWITCH CONNECTION AS SHOWN IN MANUAL	H-5
CHECKING SWITCH FOR TERMINAL CONNECTION	H-5
CHECKING OF BULBS (FOR HEADLIGHT, TAIL/BRAKE, LIGHT, FLASHER LIGHT, METER LIGHT, ETC.)	H-7
KINDS OF BULBS	H-7
CHECKING BULB CONDITION	H-7
IGNITION SYSTEM	H-8
CIRCUIT DIAGRAM	H-8
TROUBLESHOOTING	H-8
CHARGING SYSTEM	H-12
CIRCUIT DIAGRAM	H-12
TROUBLESHOOTING	H-12
LIGHTING SYSTEM.....	H-13
CIRCUIT DIAGRAM	H-13
TROUBLESHOOTING	H-14
LIGHTING SYSTEM CHECK	H-15
SIGNAL SYSTEM.....	I-1
CIRCUIT DIAGRAM	I-1
TROUBLESHOOTING	I-1
SIGNAL SYSTEM CHECK	I-2



ELECTRICAL

DT175D CIRCUIT DIAGRAM





- ① CDI magneto
- ② CDI unit
- ③ Ignition coil
- ④ Rectifier/Regulator
- ⑤ Control unit
- ⑥ Main switch
- ⑦ "ENGINE STOP" switch
- ⑧ Oil level gauge
- ⑨ "OIL" warning light
- ⑩ Neutral switch
- ⑪ "NEUTRAL" indicator light
- ⑫ Sidestand switch
- ⑬ "LIGHTS" (Dimmer) switch
- ⑭ Headlight
- ⑮ Auxiliary light
- ⑯ Meter light
- ⑰ Tail/brake light
- ⑱ Flasher light
- ⑲ "HIGH BEAM" indicator light
- ⑳ Horn
- ㉑ Brake switch
- ㉒ Flasher relay
- ㉓ "TURN" switch
- ㉔ "HORN" switch
- ㉕ Battery
- ㉖ Spark plug
- ㉗ Fuse

COLOR CODE

B	Black	G	Green	L/Y	Blue/Yellow
R	Red	W	White	B/W	Black/White
O	Orange	Ch	Chocolate	W/R	White/Red
L	Blue	Dg	Dark green	W/L	White/Blue
P	Pink	Sb	Sky blue	Y/R	Yellow/Red
Y	Yellow	Br	Brown	Br/W	Brown/White



ELECTRICAL COMPONENTS (1)

- ① Rectifier/Regulator
- ② Control unit
- ③ Sidestand switch
- ④ Horn
- ⑤ Flasher relay
- ⑥ CDI unit


IGNITION COIL:

PRIMARY COIL RESISTANCE:

0.8 ~ 1.2Ω at 20°C (68°F)

SECONDARY COIL RESISTANCE:

4.72 ~ 7.08kΩ at 20°C (68°F)





ELECTRICAL COMPONENTS (2)

- ① Wireharness
- ② Fuse
- ③ Battery
- ④ Brake switch
- ⑤ Neutral switch
- ⑥ Ignition coil
- ⑦ Oil level gauge
- ⑧ Main switch


BATTERY:

CAPACITY:

12V 3AH

SPECIFIC GRAVITY:

1.280 at 20°C (68°F)








CHECKING OF CONNECTIONS

Dealing with stains, rust, moisture, etc. on the connector.

1. Disconnect:
 - Connector
2. Dry each terminal by an air blower.




3. Connect and disconnect the connector two or three times.
4. Pull the lead to check that it will not come off.
5. If the terminal comes off, bend up the pin ① and reinsert the terminal into connector.



6. Connect:
 - Connector
7. Check for continuity by a tester.

NOTE:

- If there is no continuity, clean the terminals.
- Be sure to perform the above steps 1 to 7 when checking the wireharness.
- When replacing the CDI unit, be sure to check its connector.
- For a field remedy, use a contact revitalizer available on the market.
- Use the tester on the connector as shown.





CHECKING OF SWITCHES

SWITCH CONNECTION AS SHOWN IN MANUAL

The manual contains a connection chart as shown left showing the terminal connections of the switches (e.g., main switch, handlebar switch, bracket switch, lighting switch etc.).

The extreme left column indicates the switch positions and the top line indicates the colors of leads connected with the terminals in the switch component.

"○—○" indicates the terminals between which there is a continuity of electricity; i.e., a closed circuit at the respective switch positions.

In this chart:

"R and Br" and "L/W and L/R" are continuous with the "ON" switch position.

"B and B/W" is continuous with the "OFF" switch position.

"B and B/W" is continuous with the "LOCK" switch position.


"B and B/W" and "R and L/R" are continuous with the "P" switch position.

	B	B/W	R	Br
ON			○—○	
OFF	○—○			
LOCK	○—○			

CHECKING SWITCH FOR TERMINAL CONNECTION

Before checking the switch, refer to the connection chart as shown above and check for the correct terminal connection (closed circuit) by the color combination.

To explain how to check the switch, the main switch taken for example in the following.



1. Disconnect the main switch coupler from the wireharness.

CAUTION:

Never disconnect the main switch coupler by pulling the leads. Otherwise, leads may be pulled off the terminals inside the coupler.

2. Inspect whether any lead is off the terminal inside the coupler. If it is, repair it.

NOTE:

If the coupler is clogged with mud or dust, blow it off by compressed air.

	B	B/W	R	Br
ON			○	○
OFF	○	○		
LOCK	○	○		

3. Use the connection chart to check the color combination for continuity (a closed circuit). In this example, the continuity is as follows.



"R and Br" and "L/W and L/R" are continuous with the "ON" switch position.

"B and B/W" is continuous with the "OFF" switch position.

"B and B/W" is continuous with the "LOCK" switch position.

"B and B/W" and "R and L/R" are continuous with the "P" switch position.

Please note that there is no continuity (an open circuit) at all for the color combinations other than the above.



4. Check the switch component for the continuity between "R and Br".

Checking steps:

- Turn the switch key to the "ON", "OFF", "LOCK" and "P" several times.
- Set the pocket tester selector to the " $\Omega \times 1$ ".
- Connect the tester (+) lead to the "R" lead terminal in the coupler and the (-) lead to the "Br" lead terminal.

NOTE:

Use thin probes for checking the continuity. Otherwise, the probes may contact other-terminals inside the coupler.

- Check the continuity between "R" and "Br" at the respective switch position of "ON" ①, "OFF" ②, "LOCK" ③, and "P" ④.

There must be continuity (the tester indicating "0") at the "ON" switch position, and there must be no continuity (the tester indicating " ∞ ") at "OFF", "LOCK" or "P".

There is something wrong between "R" and "Br" if there is no continuity at the "ON" position or if there is some continuity either at the "OFF" or "LOCK" or "P".

NOTE:

Check the switch for continuity several times.

5. Next go on to checking of the continuity between "B" and "B/W", "L/W and L/R", and "R and L/R" at the respective switch positions, as in the same manner mentioned above.

6. If there is something wrong with any one of the combinations, replace the switch component.




CHECKING OF BULBS (FOR HEADLIGHT, TAIL/BRAKE LIGHT, FLASHER LIGHT, METER LIGHT, ETC.)

Check the bulb terminal continuity for the condition of the bulb.

KINDS OF BULBS

The bulbs used in the motorcycle are classified as shown left by the shape of the bulb socket.



Ⓐ and Ⓑ are mainly used for the headlight.

Ⓒ is mainly used for the flasher light and tail/brake light.

Ⓓ and Ⓔ are mainly used for the meter light and other indicator lights.

CHECKING BULB CONDITION

1. Remove the bulb.

NOTE:

- Bulbs of the Ⓐ and Ⓑ type uses a bulb holder. Remove the bulb holder before removing the bulb itself. Most of the bulb holder for this type can be removed by turning them counterclockwise.
- Most of the bulbs of Ⓒ and Ⓓ type can be removed from the bulb sockets by pushing and turning them counterclockwise.
- Bulbs of the Ⓔ type can be removed from the bulb sockets by simply pulling them out.

CAUTION:

Be sure to hold the socket firmly when removing the bulb. Never pull the lead. Otherwise, the lead may be pulled off the terminal in the coupler.

⚠ WARNING

Keep flammable products or your hands away from the headlight bulb while it is on. It will be hot. Do not touch the bulb until it cools down.




2. Check the bulb terminals for continuity.


Checking steps:

- Set the pocket tester selector to the " $\Omega \times 1$ ".
- Connect the tester lead to the respective bulb terminals. Take for example a 3-terminal bulb as shown left. First check the continuity between the ① and ② terminal by connecting the tester (+) lead to the ① terminal and the tester (-) lead to the ② terminal. Then check the continuity between the ① and ③ terminals by connecting the tester (+) lead still to the ① terminal and the tester (-) lead to the ③ terminal. If the tester shown " ∞ " in either case, replace the bulb.

3. Check the bulb socket by installing a proven bulb to it. As in the checking of bulbs, connect the pocket tester leads to the respective leads of the socket and check for continuity in the same manner as mentioned above.



IGNITION SYSTEM CIRCUIT DIAGRAM



- ① CDI magneto
- ② CDI unit
- ③ Ignition coil
- ④ Control unit
- ⑤ Main switch
- ⑥ "ENGINE STOP" switch

- ⑩ Neutral switch
- ⑫ Sidestand switch
- ⑮ Spark plug



TROUBLESHOOTING

**IF IGNITION SYSTEM SHOULD BECOME INOPERATIVE
(NO SPARK OR INTERMITTENT SPARK)**

Procedure

Check;

- | | |
|------------------------------|--|
| 1. Spark plug | 7. Neutral switch |
| 2. Ignition spark gap | 8. Sidestand switch |
| 3. Spark plug cap resistance | 9. Pickup coil resistance |
| 4. Ignition coil resistance | 10. Source coil resistance |
| 5. Main switch | 11. Wiring connection (entire ignition system) |
| 6. "ENGINE STOP" switch | 12. CDI unit |

NOTE:

• Remove the following parts before troubleshooting.

- 1) Front cover
- 2) Side cover (left)
- 3) Seat
- 4) Fuel tank



Ignition checker:
P/N. 90890-06754
Pocket tester:
P/N. 90890-03112

1. Spark plug

- Check the spark plug condition.
 - Check the spark plug type.
 - Check the spark plug gap.
- Refer to the "SPARK PLUG INSPECTION" section in the CHAPTER 3.

Standard spark plug:
BR8ES (N.G.K.)



Spark plug gap:
0.7 ~ 0.8 mm (0.028 ~ 0.032 in)

INCORRECT

Repair or replace spark plug.

CORRECT

*



2. Ignition spark gap

- Disconnect the spark plug gap from spark plug.
- Connect the ignition checker ① as shown.
- ② Spark plug


- Start the engine, and increase the spark gap until misfire occurs.



Minimum spark gap:
6 mm (0.24 in)



Ignition checker:
90890-06754



MEETS SPECIFICATION

Ignition system is good.


OUT OF SPECIFICATION
OR NO SPARK

3. Spark plug cap resistance

- Remove the spark plug cap.
- Connect the pocket tester ($\Omega \times 1k$) to the spark plug cap.
- Check the spark plug cap for specified resistance.



Spark plug cap resistance:
5.46 ~ 7.34k Ω at 20°C (68°F)



OUT OF SPECIFICATION

MEETS
SPECIFICATION

*

Spark plug cap is faulty, replace it.



4. Ignition coil resistance

- Disconnect the ignition coil lead (Orange) from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil.

Tester (+) lead → Orange ① lead
Tester (-) lead → Ignition coil base

- Check the primary coil for specified resistance.



Primary coil resistance:
 $0.8 \sim 1.2 \Omega$ at 20°C (68°F)
 (Orange—coil base)

- Connect the pocket tester ($\Omega \times 1\text{k}$) to the ignition coil.

Tester (+) lead → Spark plug lead ①
Tester (-) lead → Ignition coil base



- Check the secondary coil for specified resistance.



Secondary coil resistance:
 $4.72 \sim 7.08 \text{k}\Omega$ at 20°C (68°F)
 (Spark plug lead—coil base)

BOTH MEET SPECIFICATIONS

*



OUT OF SPECIFICATION

Ignition coil is faulty, replace it.



5. Main switch


- Disconnect the main switch coupler from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the main switch.

Tester (+) lead → Black/White ① lead
Tester (-) lead → Black ② lead

- Turn the main switch to "ON" and "OFF".
- Check the main switch for continuity.

Switch position	Good condition	Bad condition		
OFF	○	×	○	×
ON	×	○	○	×

○: Continuity ×: Nocontinuity



BAD CONDITION

Main switch is faulty, replace it.

GOOD CONDITION

6. "ENGINE STOP" switch


- Disconnect the "ENGINE STOP" switch leads ① from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the "ENGINE STOP" switch.

Tester (+) lead → Black/White ② lead
Tester (-) lead → Black ③ lead

- Turn the "ENGINE STOP" switch to "OFF" and "RUN".
- Check the "ENGINE STOP" switch for continuity.

Switch position	Good condition	Bad condition		
RUN	×	○	×	○
OFF	○	×	×	○

○: Continuity ×: Nocontinuity



BAD CONDITION

Replace handlebar switch.

GOOD
CONDITION

*



7. Neutral switch

- Disconnect the CDI magneto coupler ① from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the neutral switch lead.

Tester (+) lead → Sky blue ② lead
Tester (-) lead → Frame ground

- Shift the transmission in neutral and gear.
- Check the neutral switch for continuity.

Transmission position	Good condition	Bad condition		
Neutral	○	×	×	○
Gear	×	○	×	○

○: Continuity ×: Nocontinuity



GOOD
CONDITION

8. Sidestand switch


- Disconnect the sidestand switch leads from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the sidestand switch.

Tester (+) lead → Blue/Yellow ① lead
Tester (-) lead → Black ② lead

- Check the sidestand switch for continuity.




CONTINUITY



BAD CONDITION

Replace neutral switch.



NO CONTINUITY

Replace the sidestand switch.



9. Pickup coil resistance

- Disconnect the CDI magneto leads (White/Red and Black) ① from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the pickup coil.


Tester (+) lead → White/Red ② terminal
Tester (-) lead → Black ③ terminal

- Check the pickup coil for specified resistance.



Pickup coil resistance:
 $8 \sim 12\Omega$ at 20°C (68°F)

MEET
SPECIFICATION



OUT OF SPECIFICATION

Replace pickup coil.

10. Source coil resistance

- Disconnect the CDI magneto coupler ① from the wireharness.
- Connect the pocket tester ($\Omega \times 100$) to the source coil.


Tester (+) lead → Black ② terminal
Tester (-) lead → Brown ③ terminal

- Measure the source coil resistance.



Source coil resistance:
 $270 \sim 330\Omega$ at 20°C (68°F)

MEETS
SPECIFICATION



OUT OF SPECIFICATION

Replace source coil.

11. Wiring connection


- Check the entire ignition system for connections.
Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.

CORRECT

*





TROUBLESHOOTING

THE BATTERY IS NOT CHARGED.

Procedure

Check;

1. Fuse
2. Battery
3. Charging voltage
4. Charging coil resistance
5. Wiring connection (charging system)

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Side cover
 - 2) Fuel tank
 - 3) Seat
- Use the following special tool(s) in this troubleshooting.




Inductive tachometer:

P/N. 90890-03113

Pocket tester:

P/N. 90890-03112





3. Charging voltage


- Connect the engine tachometer to spark plug lead.
- Connect the pocket tester (DC20V) to the battery.

Tester (+) lead → Battery (+) terminal
Tester (-) lead → Battery (-) terminal

- Start the engine and accelerate to about 3,000 r/min.
- Measure the charging voltage.



Charging voltage:
13.3 ~ 15.3V at 3,000 r/min



MEETS SPECIFICATION

Replace battery.

OUT OF SPECIFICATION

4. Charging coil resistance


- Disconnect the CDI magneto coupler and lead (Black) ① from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the charging coil.

Tester (+) lead → Green/White ② lead
Tester (-) lead → Black ③ lead

- Measure the charging coil resistance.



Charging coil resistance:
0.24 ~ 0.36 Ω at 20°C (68°F)



OUT OF SPECIFICATION

Replace stator assembly.

MEETS SPECIFICATION

5. Wiring connection

- Check the entire ignition system for connections. Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.

CORRECT

Replace rectifier/regulator.



TROUBLESHOOTING

HEADLIGHT "HIGH BEAM" INDICATOR LIGHT, TAILLIGHT, AND/OR METER LIGHT DO NOT COME ON.

Procedure

Check;

1. "LIGHTS" (Dimmer) switch
2. Lighting coil resistance
3. Wiring connection

NOTE:

- Remove the following parts before troubleshooting.
 - 1) Side covers
 - 2) Seat
 - 3) Fuel tank
- Use the following special tool(s) in this troubleshooting.




Pocket tester:

P/N. 90890-03112

1. "LIGHTS" (Dimmer) switch

- Disconnect the handlebar switch (left) and headlight coupler ① from the wireharness.
- Check the switch component for the continuity between "Green ② and Yellow/Red ③" and "Yellow/Red ③ and Yellow ④". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

Replace handlebar switch (left).

CORRECT

*



2. Lighting coil resistance

- Disconnect the CDI magneto coupler and lead (Black) ① from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the lighting coil coupler.

Tester (+) lead → Yellow ② terminal
Tester (-) lead → Black ③ terminal

- Measure the lighting coil resistance.



Lighting coil resistance:
 $0.14 \sim 0.22 \Omega$ at 20°C (68°F)


MEETS
SPECIFICATION

3. Wiring connection

- Check the entire lighting system for connections.
Refer to the "WIRING DIAGRAM" section.

CORRECT

Check condition of each circuit for lighting system.
Refer to "LIGHTING SYSTEM CHECK" section.



OUT OF SPECIFICATION

Replace stator assembly.

POOR CONNECTION

Correct.



LIGHTING SYSTEM CHECK

1. Headlight and "HIGH BEAM" indicator light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.

CONTINUITY

2. Voltage

- Connect the pocket tester (DC20V) to the headlight and "HIGH BEAM" indicator light couplers.

- A** When "LIGHTS" (Dimmer) switch is "LO" position.
B When "LIGHTS" (Dimmer) switch is "HI" position.

Headlight:

Tester (+) lead → Yellow ① or Green ② lead

Tester (-) lead → Black ③ lead

"HIGH BEAM" indicator light:

Tester (+) lead → Yellow ④ lead

Tester (-) lead → Black ⑤ lead


- Start the engine.
- Turn the "LIGHTS" (Dimmer) switch to "LO" or "HI" position.
- Check for voltage (12V) on the "Green" and "Yellow" lead at bulb socket connectors.

MEETS SPECIFICATION

This circuit is good.

NO CONTINUITY

Replace bulb and/or bulb socket.



OUT OF SPECIFICATION

Wiring circuit from main switch to bulb socket connector is faulty, repair.



2. Meter light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.

NO CONTINUITY

Replace bulb and/or bulb socket.


CONTINUITY

2. Voltage

- Connect the pocket tester (DC20V) to the bulb socket coupler ①.

Tester (+) lead → Blue ② terminal
Tester (-) lead → Black ③ terminal

- Start the engine.
- Check for voltage (12V) on the "Blue" lead at the bulb socket connector.



OUT OF SPECIFICATION

Wiring circuit from main switch to bulb socket connector is faulty, repair.

MEETS
SPECIFICATION

This circuit is good.

3. Taillight does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.

NO CONTINUITY

Replace bulb and/or bulb socket.

CONTINUITY

2. Voltage

- Connect the pocket tester (DC20V) to the bulb socket connector ①.

Tester (+) lead → Blue ② terminal
Tester (-) lead → Black ③ terminal


- Start the engine.
- Check for voltage (12V) on the "Blue" lead at the bulb socket connector.

OUT OF SPECIFICATION

Wiring circuit from main switch to bulb socket connection is faulty, repair.

MEETS SPECIFICATION

This circuit is good.





4. Auxiliary light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.

NO CONTINUITY

Bulb and/or bulb socket are faulty, replace.


CONTINUITY

2. Voltage

- Connect the pocket tester (DC20V) to the bulb socket connector ①.

Tester (+) lead → Blue/Red ② lead
Tester (–) lead → Black ③ lead

- Start the engine.
- Check for voltage (12V) on the "Blue/Red" lead at the bulb socket connector.



OUT OF SPECIFICATION

Wiring circuit from main switch to bulb socket connector is faulty, repair.


MEETS
SPECIFICATION

This circuit is good.



SIGNAL SYSTEM

CIRCUIT DIAGRAM



- | | |
|-----------------------------|------------------|
| ⑥ Main switch | ②① Brake switch |
| ⑧ Oil level gauge | ②② Flasher relay |
| ⑨ "OIL" warning light | ②③ "TURN" switch |
| ⑪ "NEUTRAL" indicator light | ②④ "HORN" switch |
| ⑪⑦ Tail/Brake light | ②⑤ Battery |
| ⑪⑧ Flasher light | ②⑦ Fuse |
| ⑪⑨ Horn | |



TROUBLESHOOTING

- FLASHER LIGHT, BRAKE LIGHT AND/OR INDICATOR LIGHT DO NOT COME ON.
- HORN DOES NOT SOUND.

Procedure

Check;

1. Fuse (main)
2. Battery
3. Main switch
4. Wiring connection (entire signal system)


NOTE:

- Remove the following parts before troubleshooting.
 - 1) Seat
 - 2) Side cover (left)
 - 3) Side cover (right)
- Use the following special tool in this troubleshooting.



Pocket tester:

P/N. 90890-03112





3. Main switch

- Disconnect the main switch coupler from the wireharness.
- Check the switch component for the continuity between "Red ① and Brown ②". Refer to the "CHECKING OF SWITCHES" section.

- Turn the main switch to "ON" and "OFF".
- Check the main switch for continuity.

Switch position	Good condition	Bad condition		
ON	○	×	×	○
OFF	×	○	×	○

○: Continuity ×: Nocontinuity



CORRECT


4. Wiring connection

- Check the entire signal system for connections. Refer to the "WIRING DIAGRAM" section.



CORRECT

Check condition of each circuit for signal system. Refer to "SIGNAL SYSTEM CHECK" section.



INCORRECT

Replace main switch.

POOR CONNECTION

Correct.




SIGNAL SYSTEM CHECK

1. Horn does not sound.

1. "HORN" switch.

- Disconnect the handlebar switch (left) coupler ① from wireharness.
- Check the switch component for the continuity between "Pink ② and Black ③". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT

Replace handlebar switch (left).


CORRECT

2. Voltage

- Connect the pocket tester (DC20V) to the horn lead.

Tester (+) lead → Brown ① lead
Tester (-) lead → Frame ground

- Turn the main switch to "ON".
- Check for voltage (12V) on the "Brown" lead at the horn terminal.



OUT OF SPECIFICATION

Wiring circuit from main switch to horn terminal is faulty, repair.


MEETS SPECIFICATION (12V)

*



3. Horn

- Disconnect the "Pink" lead from the horn terminal.
- Connect a jumper lead ① to the horn terminal and ground the jumper lead.
- Turn the main switch to "ON".



HORN IS SOUNDED

Horn is good.


HORN IS NOT
SOUNDED

4. Voltage

- Connect the pocket tester (DC20V) to the horn at the "Pink" terminal.

Tester (+) lead → Pink ① lead
Tester (-) lead → Frame ground

- Turn the main switch to "ON".
- Check for voltage (12V) on the "Pink" lead at the horn terminal.



OUT OF SPECIFICATION

Horn is faulty, replace it.

MEETS
SPECIFICATION (12V)

Adjust or replace horn.



2. Brake light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.



NO CONTINUITY

Replace bulb and/or bulb socket.



CONTINUITY

2. Brake switch

- Disconnect the brake switch leads from the wireharness.
- Check the switch component for the continuity between "Black ① and Black ②". Refer to the "CHECKING OF SWITCHES" section.



A Front brake switch
B Rear brake switch



INCORRECT


Replace brake switch.

CORRECT

3. Voltage

- Connect the pocket tester (DC20V) to the bulb socket connector.

Tester (+) lead → Green/Yellow ① lead
Tester (-) lead → Brown ② lead





- Turn the main switch to "ON".
- The brake lever is pulled in or brake pedal is stepped down.
- Check for voltage (12V) on the "Green/Yellow" lead at the bulb socket connector.

MEETS
SPECIFICATION (12V)

This circuit is good.

OUT OF SPECIFICATION

Wiring circuit from main switch to bulb socket connector is faulty, repair.

3. Flasher light and/or "TURN" indicator light does not blink.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.



NOCONTINUITY

Replace bulb and/or bulb socket.

CONTINUITY

2. "TURN" switch

- Disconnect the handlebar switch (left) coupler ① from the wireharness.
- Check the switch component for the continuity between "Brown/White ② and Chocolate ③" and "Brown/White ② and Dark green ④". Refer to the "CHECKING OF SWITCHES" section.



NOCONTINUITY

"TURN" switch is faulty, replace handlebar switch (left).

CORRECT

*




3. Voltage

- Connect the pocket tester (DC20V) to the flasher relay.

Tester (+) lead → Brown ① lead
Tester (-) lead → Frame ground

- Turn the main switch to "ON".
- Check for voltage (12V) on the "Brown" lead at the flasher relay terminal.



OUT OF SPECIFICATION

Wiring circuit from main switch to flasher relay connector is faulty, repair.


MEETS SPECIFICATION (12V)

4. Voltage

- Connect the pocket tester (DC20V) to the flasher relay.

Tester (+) lead → Brown/White ① lead
Tester (-) lead → Frame ground

- Turn the main switch to "ON".
- Check for voltage (12V) on the "Brown/White" lead at the flasher relay terminal.



OUT OF SPECIFICATION

Flasher relay is faulty, replace it.


MEETS SPECIFICATION (12V)

5. Voltage

- Connect the pocket tester (DC20V) to the bulb socket connector.

At flasher light (left):
Tester (+) lead → Chocolate ① lead
Tester (-) lead → Frame ground

At flasher light (right):
Tester (+) lead → Dark green ② lead
Tester (-) lead → Frame ground





- Turn the main switch to "ON".
- Turn the "TURN" switch to "L" or "R".
- Check for voltage (12V) on the "Chocolate" lead or "Dark green" lead at the bulb socket connector.

OUT OF SPECIFICATION

MEETS
SPECIFICATION (12V)

This circuit is good.

Wiring circuit from "TURN" switch to bulb socket connector is faulty, repair.

4. "NEUTRAL" indicator light does not come on.

1. Bulb and bulb socket

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.


NO CONTINUITY

CONTINUITY

Replace bulb and/or bulb socket.

2. Neutral switch

- Disconnect the neutral switch coupler ① from the wireharness.
- Check the switch component for the continuity between "Sky blue ② and Ground". Refer to the "CHECKING OF SWITCHES" section.



INCORRECT


CORRECT

Replace neutral switch.

3. Voltage

- Connect the pocket tester (DC20V) to the bulb socket connector.

Tester (+) lead → Sky blue ① terminal
Tester (-) lead → Brown ② terminal





- Turn the main switch to "ON".
- Check for voltage (12V) on the "Sky blue and Brown" lead at bulb socket connector.

OUT OF SPECIFICATION

MEETS
SPECIFICATION

Wiring circuit from main switch to bulb socket connector is faulty, repair.

This circuit is good.

5. "OIL" indicator light does not come on.

1. Bulb and bulb socket

NOCONTINUITY

- Check the bulb and bulb socket for continuity. Refer to the "CHECKING OF BULBS" section.

Replace bulb and/or bulb socket.

CONTINUITY

2. Oil level gauge

- Remove the oil level gauge from the oil tank.
- Disconnect the oil level gauge coupler from the wireharness.
- Connect the pocket tester ($\Omega \times 1$) to the oil level gauge.

Check 1:

Tester (+) lead → Black/Red ① lead

Tester (-) lead → Sky blue ② lead


- Check the oil level gauge for continuity.

NOCONTINUITY

CONTINUITY

Replace oil level gauge.

*





3. Oil level gauge

- Connect the pocket tester ($\Omega \times 1$) to the oil level gauge.

Check 2:


Tester (+) lead → Black/Red ① lead

Tester (-) lead → Black ② lead

- Check the oil level gauge for continuity.

Switch position	Good condition	Bad condition		
Upright position	○	×	×	○
Up-side down position	×	○	×	○

○: Continuity ×: Nocontinuity



BAD CONDITION

Replace oil level gauge.

GOOD CONDITION

4. Voltage

- Disconnect the indicator light box coupler from the wireharness.
- Connect the pocket tester (DC20V) to the "OIL" indicator light coupler.

Tester (+) lead → Black/Red ① lead

Tester (-) lead → Brown ② lead


- Check the "OIL" indicator light voltage.



"OIL" indicator light voltage:
12.0V

MEETS
SPECIFICATION

This circuit is good.



OUT OF SPECIFICATION

5. Wiring connection

Check the entire signal system for connections.
Refer to the "WIRING DIAGRAM" section.

CHAPTER 8. TROUBLESHOOTING

STARTING FAILURE/HARD STARTING	I-10
FUEL SYSTEM	I-10
ELECTRICAL SYSTEM	I-10
COMPRESSION SYSTEM	I-10
POOR IDLE SPEED PERFORMANCE	I-11
POOR IDLE SPEED PERFORMANCE	I-11
POOR MEDIUM AND HIGH SPEED PERFORMANCE	I-11
FUEL SYSTEM	I-11
ELECTRICAL SYSTEM	I-11
COMPRESSION SYSTEM	I-11
FAULTY GEAR SHIFTING	I-11
HARD SHIFTING	I-11
SHIFT PEDAL DOES NOT MOVE	I-12
JUMP-OUT GEAR	I-12
CLUTCH SLIPPING/Dragging	I-12
CLUTCH SLIPPING	I-12
CLUTCH DRAGGING	I-12
IMPROPER KICKING	I-12
SLIPPING	I-12
HARD KICKING	I-12
KICK CRANK NOT RETURNING	I-12
FAULTY BRAKE	I-12
POOR BRAKING EFFECT	I-12
FRONT FORK OIL LEAKAGE AND FRONT FORK MALFUNCTION ...	I-13
OIL LEAKAGE	I-13
MALFUNCTION	I-13
INSTABLE HANDLING	I-13
INSTABLE HANDLING	I-13
FAULTY SIGNAL AND LIGHTING SYSTEM	I-14
HEADLIGHT DARK	I-14
BULB BURNT OUT	I-14
FLASHER DOES NOT LIGHT	I-14
FLASHER KEEPS ON	I-14
FLASHER WINKS SLOWER	I-14
FLASHER WINKS QUICKER	I-14
HORN IS INOPERATIVE	I-14
OVERHEATING	I-14
OVERHEATING	I-14

TROUBLESHOOTING

NOTE: The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for inspection, adjustment and replacement of parts.

STARTING FAILURE/HARD STARTING

FUEL SYSTEM

PROBABLE CAUSE

Fuel tank	<ul style="list-style-type: none"> • Empty • Clogged fuel filter • Clogged fuel tank cap • Deteriorated fuel or fuel containing water or foreign material
Fuel cock	<ul style="list-style-type: none"> • Clogged fuel hose
Carburetor	<ul style="list-style-type: none"> • Deteriorated fuel, fuel containing water or foreign material • Clogged pilot jet • Clogged pilot air passage • Sucked-in air • Deformed float • Groove-worn needle valve • Improperly sealed valve seat • Improperly adjusted fuel level • Improperly set pilot jet • Clogged starter jet • Starter plunger malfunction • Improperly adjusted starter cable
Air cleaner	<ul style="list-style-type: none"> • Clogged air filter

ELECTRICAL SYSTEM

PROBABLE CAUSE

Spark plug	<ul style="list-style-type: none"> • Improper plug gap • Worn electrodes • Wire between terminals broken • Improper heat range • Faulty spark plug cap
Ignition coil	<ul style="list-style-type: none"> • Broken or shorted primary/secondary • Faulty spark plug lead • Broken body
CDI unit system	<ul style="list-style-type: none"> • Faulty CDI unit • Faulty source coil • Faulty pick-up coil • Broken woodruff key
Switches and wiring	<ul style="list-style-type: none"> • Faulty main switch • Faulty engine stop switch • Broken or shorted wiring • Faulty neutral switch • Faulty sidestand switch • Faulty ignition control unit

COMPRESSION SYSTEM

PROBABLE CAUSE

Cylinder and cylinder head	<ul style="list-style-type: none"> • Loose spark plug • Loose cylinder head or cylinder • Broken cylinder head gasket • Broken cylinder gasket • Worn, damaged or seized cylinder
Piston and piston rings	<ul style="list-style-type: none"> • Improperly installed piston ring • Worn, fatigued or broken piston ring • Seized piston ring • Seized or damaged piston
Crankcase and crankshaft	<ul style="list-style-type: none"> • Improperly seated crankcase • Improperly sealed crankcase (Damaged oil seal) • Seized crankshaft
Reed valve	<ul style="list-style-type: none"> • Deformed reed valve stopper • Improperly seated reed valve • Loose intake manifold • Broken gasket • Broken reed valve

**POOR IDLE SPEED PERFORMANCE/
POOR MEDIUM AND HIGH SPEED PERFORMANCE**

**TRBL
SHTG**

?

I.

POOR IDLE SPEED PERFORMANCE

POOR IDLE SPEED PERFORMANCE

PROBABLE CAUSE

— Carburetor —

- Improperly returned starter plunger
- Clogged or loose pilot jet
- Clogged pilot air passage
- Improperly adjusted idle speed (Throttle stop screw)
- Improper throttle cable play
- Faulty pick up coil

POOR MEDIUM AND HIGH SPEED PERFORMANCE

FUEL SYSTEM

PROBABLE CAUSE

— Fuel tank —

- Clogged fuel filter
- Deteriorated fuel or fuel containing water or foreign material
- Clogged fuel breather hose

— Fuel cock —

- Clogged fuel hose

— Carburetor —

- Deteriorated fuel, fuel containing water or foreign material
- Sucked-in air
- Deformed float
- Groove-worn needle valve
- Improperly sealed valve seat
- Improperly set clip position of jet needle
- Improperly adjusted fuel level
- Clogged or loose main jet
- Clogged or loose needle jet

— Air cleaner —

- Clogged air filter

ELECTRICAL SYSTEM**PROBABLE CAUSE**

- Spark plug —
 - Improper plug gap
 - Worn electrodes
 - Wire between terminals broken
 - Improper heat range
 - Faulty spark plug cap
- CDI unit system —
 - Faulty CDI unit
 - Faulty source coil
 - Faulty pickup coil

COMPRESSION SYSTEM**PROBABLE CAUSE**

- Cylinder and cylinder head —
 - Loose spark plug
 - Broken cylinder head gasket
 - Broken cylinder gasket
 - Loose cylinder head or cylinder
 - Worn, damaged or seized cylinder
- Piston and piston ring —
 - Improperly installed piston ring
 - Worn, fatigued or broken piston ring
 - Seized piston ring
 - Seized or damaged piston
- Crankcase and crankshaft —
 - Improperly seated crankcase
 - Improperly sealed crankcase (Damaged oil seal)
 - Seized crankshaft
- Reed valve —
 - Deformed reed valve stopper
 - Improperly adjusted reed valve stopper height
 - Improperly seated reed valve
 - Loose intake manifold
 - Broken gasket
 - Broken reed valve

FAULTY GEAR SHIFTING**HARD SHIFTING****PROBABLE CAUSE**

- Clutch —
 - Improperly adjusted clutch cable
 - Improperly adjusted push lever position
 - Improper engagement of push lever and push rod
 - Warped clutch plate
 - Swollen friction plate
 - Broken clutch plate
- Transmission oil —
 - High oil level
 - Improper quality (High viscosity)
 - Deterioration

CLUTCH SLIPPING/Dragging

TRBL
SHTG

?

L-

SHIFT PEDAL DOES NOT MOVE

PROBABLE CAUSE

- Shift shaft —
 - Bent shift shaft
- Shift cam and shift fork —
 - Groove jammed with impurities
 - Seized shift fork
 - Bent shift fork guide bar
- Transmission —
 - Seized transmission gear
 - Jammed impurities
 - Incorrectly assembled transmission

JUMP-OUT GEAR

PROBABLE CAUSE

- Shift shaft —
 - Improperly adjusted shift lever position
 - Improperly returned stopper lever
- Shift fork —
 - Worn shift fork
- Shift cam —
 - Improper thrust play
 - Worn shift cam groove
- Transmission —
 - Worn gear dog

CLUTCH SLIPPING/DRAGGING

CLUTCH SLIPPING





PROBABLE CAUSE

- Clutch —
 - Improperly adjusted clutch cable
 - Loose clutch spring
 - Fatigued clutch spring
 - Worn friction plate
 - Worn clutch plate
- Transmission oil —
 - Low oil level
 - Improper quality (Low viscosity)
 - Deterioration

CLUTCH DRAGGING

PROBABLE CAUSE

- Clutch —
 - Improperly adjusted clutch cable
 - Improperly adjusted push lever position
 - Improper engagement of push lever and push rod
 - Warped clutch plate
 - Swollen friction plate
 - Broken clutch boss
- Transmission oil —
 - High oil level
 - Improper quality (High viscosity)
 - Deterioration

IMPROPER KICKING**SLIPPING****HARD KICKING****KICK CRANK NOT RETURNING****FAULTY BRAKE****POOR BRAKING EFFECT**

FRONT FORK OIL LEAKAGE AND FRONT FORK MALFUNCTION

TRBL
SHTG

?



FRONT FORK OIL LEAKAGE AND FRONT FORK MALFUNCTION

OIL LEAKAGE

PROBABLE CAUSE

- Bent, damaged or rusty inner tube
- Damaged or cracked outer tube
- Damaged oil seal lip
- Improperly installed oil seal
- Improper oil level (too much)
- Loose damper rod holding bolt
- Broken cap bolt O-ring
- Loose drain bolt
- Damaged drain bolt gasket

MALFUNCTION

PROBABLE CAUSE

- Bent, deformed or damaged inner tube
- Bent or deformed outer tube
- Damaged fork spring
- Worn or damaged slide metal
- Bent or damaged damper rod
- Improper oil viscosity
- Improper oil level

INSTABLE HANDLING

INSTABLE HANDLING

PROBABLE CAUSE

Handlebars	<ul style="list-style-type: none"> • Improperly installed or bent
Steering	<ul style="list-style-type: none"> • Improperly installed handlebar crown • Bent steering shaft • Improperly installed steering shaft (Improperly tightened ringnut) • Damaged ball bearing, roller bearing or bearing race
Front forks	<ul style="list-style-type: none"> • Uneven oil levels on both sides • Uneven spring tension (Uneven damping adjuster position) • Broken spring • Twisted front forks
Tires	<ul style="list-style-type: none"> • Uneven tire pressures on both sides • Incorrect tire pressure • Unevenly worn tires
Wheels	<ul style="list-style-type: none"> • Incorrect wheel balance • Deformed cast wheel • Loose bearing • Bent or loose wheel axle • Excessive wheel run-out
Frame	<ul style="list-style-type: none"> • Twisted • Damaged head pipe • Improperly installed bearing race
Swingarm	<ul style="list-style-type: none"> • Worn bearing or bush • Bent or damaged
Rear shock absorber	<ul style="list-style-type: none"> • Fatigued spring • Improperly adjusted spring preload • Oil leakage
Drive chain	<ul style="list-style-type: none"> • Improperly adjusted chain slack

FAULTY SIGNAL AND LIGHTING SYSTEM

HEADLIGHT DARK

PROBABLE CAUSE

- Improper bulb
- Too many electric accessories
- Hard charging (Broken charging coil and/or faulty rectifier/regulator)
- Incorrect connection
- Improperly grounded
- Bulb life expired

BULB BURNT OUT

PROBABLE CAUSE

- Improper bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded
- Faulty main and/or light switch
- Bulb life expired

FLASHER DOES NOT LIGHT

PROBABLE CAUSE

- Improperly grounded
- Discharged battery
- Faulty "TURN" switch
- Faulty flasher relay
- Broken wireharness
- Loosely connected coupler
- Bulb burnt out

FLASHER KEEPS ON

PROBABLE CAUSE

- Faulty flasher relay
- Insufficient battery capacity (nearly discharged)
- Bulb burnt out

FLASHER WINKS SLOWER

PROBABLE CAUSE

- Faulty flasher relay
- Insufficient battery capacity (nearly discharged)
- Improper bulb
- Faulty main and/or "TURN" switch

FLASHER WINKS QUICKER

PROBABLE CAUSE

- Improper bulb
- Faulty flasher relay

HORN IS INOPERATIVE

PROBABLE CAUSE

- Faulty battery
- Faulty main and/or horn switch
- Improperly adjusted horn
- Faulty horn
- Broken wireharness

OVERHEATING

OVERHEATING

PROBABLE CAUSE

- Ignition system
 - Improper spark plug gap
 - Improper spark plug heat range
 - Faulty CDI unit
- Fuel system
 - Improper carburetor main jet (Improper setting)
 - Improperly adjusted fuel height
 - Clogged air cleaner element
- Compression system
 - Heavy carbon build-up
- Engine oil
 - Incorrect oil level
 - Improper oil viscosity
 - Inferior oil quality
- Brake
 - Dragging brake