

# SECTION **EM**

## ENGINE MECHANICAL

### CONTENTS

<b>MR16DDT</b>		
<b>PRECAUTION</b> .....	<b>3</b>	
<b>PRECAUTIONS</b> .....	<b>3</b>	
Precaution for Procedure without Cowl Top Cover.....	3	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	
Special Cautions to Ensure the Safe Disposal of Sodium-filled Exhaust Valves .....	4	
Draining Engine Coolant .....	5	
Disconnecting Fuel Piping .....	5	
Precaution for Handling High Pressure Fuel System .....	5	
Removal and Disassembly .....	5	
Inspection, Repair and Replacement .....	5	
Assembly and Installation .....	6	
Parts Requiring Angle Tightening .....	6	
Liquid Gasket .....	6	
<b>PREPARATION</b> .....	<b>8</b>	
<b>PREPARATION</b> .....	<b>8</b>	
Special Service Tools .....	8	
Commercial Service Tools .....	10	
<b>BASIC INSPECTION</b> .....	<b>12</b>	
<b>CAMSHAFT VALVE CLEARANCE</b> .....	<b>12</b>	
Inspection and Adjustment .....	12	
<b>COMPRESSION PRESSURE</b> .....	<b>15</b>	
Inspection .....	15	
<b>SYMPTOM DIAGNOSIS</b> .....	<b>16</b>	
<b>NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING</b> .....	<b>16</b>	
NVH troubleshooting Chart .....	16	
<b>PERIODIC MAINTENANCE</b> .....	<b>18</b>	
<b>DRIVE BELT</b> .....	<b>18</b>	
Exploded View .....	18	
Removal and Installation .....	18	
Inspection .....	19	
Adjustment .....	19	
<b>AIR CLEANER FILTER</b> .....	<b>20</b>	
Exploded View .....	20	
Removal and Installation .....	20	
Inspection .....	21	
<b>SPARK PLUG</b> .....	<b>22</b>	
Exploded View .....	22	
Removal and Installation .....	22	
Inspection .....	23	
<b>REMOVAL AND INSTALLATION</b> .....	<b>24</b>	
<b>ENGINE COVER</b> .....	<b>24</b>	
Exploded View .....	24	
Removal and Installation .....	24	
<b>AIR CLEANER AND AIR DUCT</b> .....	<b>25</b>	
Exploded View .....	25	
Removal and Installation .....	25	
Inspection .....	26	
<b>INTAKE MANIFOLD</b> .....	<b>27</b>	
Exploded View .....	27	
Removal and Installation .....	28	
Inspection .....	29	
<b>CHARGE AIR COOLER</b> .....	<b>30</b>	
Exploded View .....	30	
Removal and Installation .....	30	
Inspection .....	31	
<b>CATALYST</b> .....	<b>32</b>	
<b>2WD</b> .....	<b>32</b>	
2WD : Exploded View .....	32	
2WD : Removal and Installation .....	32	

<b>AWD</b> .....	<b>33</b>	Removal and Installation .....	71
AWD : Exploded View .....	34		
AWD : Removal and Installation .....	34		
<b>TURBOCHARGER</b> .....	<b>37</b>	<b>TIMING CHAIN</b> .....	<b>72</b>
Exploded View .....	37	Exploded View .....	72
Removal and Installation .....	37	Removal and Installation .....	73
Inspection .....	38	Inspection .....	82
<b>EXHAUST MANIFOLD</b> .....	<b>41</b>	<b>CAMSHAFT</b> .....	<b>84</b>
Exploded View .....	41	Exploded View .....	84
Removal and Installation .....	41	Removal and Installation .....	85
Inspection .....	42	Inspection .....	88
<b>OIL PAN (LOWER)</b> .....	<b>43</b>	<b>OIL SEAL</b> .....	<b>93</b>
Exploded View .....	43	<b>VALVE OIL SEAL</b> .....	<b>93</b>
Removal and Installation .....	44	VALVE OIL SEAL : Removal and Installation .....	93
Inspection .....	45	<b>FRONT OIL SEAL</b> .....	<b>94</b>
<b>HIGH PRESSURE FUEL PUMP AND FUEL HOSE</b> .....	<b>46</b>	FRONT OIL SEAL : Removal and Installation .....	94
Exploded View .....	46	<b>REAR OIL SEAL</b> .....	<b>94</b>
Removal and Installation .....	46	REAR OIL SEAL : Removal and Installation .....	94
Inspection .....	50	<b>CYLINDER HEAD</b> .....	<b>96</b>
<b>FUEL INJECTOR AND FUEL TUBE</b> .....	<b>51</b>	Exploded View .....	96
Exploded View .....	51	Removal and Installation .....	97
Removal and Installation .....	51	Disassembly and Assembly .....	98
Inspection .....	56	Inspection .....	103
<b>IGNITION COIL, SPARK PLUG AND ROCKER COVER</b> .....	<b>57</b>	<b>OIL PAN (UPPER)</b> .....	<b>106</b>
Exploded View .....	57	Exploded View .....	106
Removal and Installation .....	57	Removal and Installation .....	107
<b>UNIT REMOVAL AND INSTALLATION</b> ....	<b>59</b>	Inspection .....	109
<b>ENGINE ASSEMBLY</b> .....	<b>59</b>	<b>CYLINDER BLOCK</b> .....	<b>110</b>
<b>2WD</b> .....	<b>59</b>	Exploded View .....	110
2WD : Exploded View .....	59	Disassembly and Assembly .....	111
2WD : Removal and Installation .....	60	Inspection .....	119
2WD : Inspection .....	63	<b>HOW TO SELECT PISTON AND BEARING</b> ..	<b>129</b>
<b>4WD (AWD)</b> .....	<b>64</b>	Description .....	129
4WD (AWD) : Exploded View .....	64	Piston .....	129
4WD (AWD) : Removal and Installation .....	64	Connecting Rod Bearing .....	130
4WD (AWD) : Inspection .....	67	Main Bearing .....	132
<b>UNIT DISASSEMBLY AND ASSEMBLY</b> ...	<b>68</b>	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	<b>135</b>
<b>ENGINE STAND SETTING</b> .....	<b>68</b>	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	<b>135</b>
Setting .....	68	General Specification .....	135
<b>ENGINE UNIT</b> .....	<b>70</b>	Drive Belt .....	135
Disassembly .....	70	Spark Plug .....	135
Assembly .....	70	Exhaust Manifold .....	136
<b>DRIVE BELT AUTO TENSIONER AND IDLER PULLEY</b> .....	<b>71</b>	Turbocharger .....	136
Exploded View .....	71	Camshaft .....	136
		Cylinder Head .....	138
		Cylinder Block .....	140
		Connecting Rod Bearing .....	144
		Main Bearing .....	144


## PRECAUTION

### PRECAUTIONS

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000007577402

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007577403

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

**Always observe the following items for preventing accidental activation.**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

**Always observe the following items for preventing accidental activation.**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

# PRECAUTIONS

< PRECAUTION >


[MR16DDT ]

## Special Cautions to Ensure the Safe Disposal of Sodium-filled Exhaust Valves

INFOID:000000007577404

Handling and disposal of sodium-filled exhaust valves requires special care and consideration. Under conditions such as breakage with subsequent contact with water, metal sodium which lines the inner portion of exhaust valve will react violently, forming sodium hydroxide and hydrogen which may result in an explosion. Sodium-filled exhaust valve is identified on the top of its stem as shown in illustration.

A : Identification mark of sodium-filled exhaust valve




## DEALER DISPOSAL INSTRUCTIONS

### CAUTION:

- Use approved shatter-resistant eye protection when performing this procedure.
- Perform this and all subsequent disposal work procedures in an open room, away from flammable liquids. Keep a fire extinguisher, rated at least 10 ABC, in close proximity to the work area.
- Be sure to wear rubber gloves when performing the following operations.
- Make sure the resultant (high alkalinity) waste water does not contact your skin. If the waste water does contact you, wash the contacted area immediately with large quantities of water.
- Dealers should check their respective state and local regulations concerning any chemical treatment or waste water discharge permits which may be required to dispose of the resultant (high alkalinity) waste water.


1. Clamp valve stem in a vice.
2. The valve has a specially-hardened surface. To cut through it, first remove a half-round section, approximately 30 mm (1.18 in) long using air-powered grinder until black color is removed and silver color appears.

- A : Black color  
B : Silver color  
c : 47 mm (1.85 in)  
d : 17 mm (0.67 in)



3. Use hacksaw to cut through approximately half the diameter of valve stem. Make the serration at a point 40 mm (1.57 in) from the end of valve stem.

- a : 32 mm (1.26 in)





## PRECAUTIONS

[MR16DDT ]

### < PRECAUTION >

4. Cover the serrated end of the valve with a large shop towel (A). Strike the valve face end with a hammer, separating it into two pieces.
5. Fill a bucket (such as a 20 ℓ oil can) with at least 10 ℓ (2-5/8 US gal, 2-1/4 Imp gal) of water. Carefully place the already cut (serrated) valves into the water one-at-a-time using a set of large tweezers and quickly move away at least 2.7 m (9 ft).
6. The valves should be placed in a standing position as shown in the illustration to allow complete reaction. After the bubbling action has subsided, additional valves can be placed into the bucket allowing each subsequent chemical reaction to subside. However, no more than 8 valves should be placed in the same 10 ℓ (2-5/8 US gal, 2-1/4 Imp gal) amount of water. The complete chemical reaction may take as long as 4 to 5 hours. Remove the valves using a set of large tweezers after the chemical reaction has stopped. Afterwards, valves can be disposed as ordinary scrap.

A : Bucket (Such as 20 ℓ oil can)



## Draining Engine Coolant

INFOID:000000007577405

Drain engine coolant and engine oil when the engine is cooled.

## Disconnecting Fuel Piping

INFOID:000000007577406

- Before starting work, check no fire or spark producing items are in the work area.
- Release fuel pressure before disconnecting and disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

## Precaution for Handling High Pressure Fuel System

INFOID:000000007577407

- High pressure fuel system components are between high pressure fuel pump and fuel injector.
- Always release fuel pressure and never start the engine when performing removal and installation.
- When removing or installing parts without releasing fuel pressure, fuel may be splashed and, if fuel contacts skin or eyes, it may cause inflammation.

## Removal and Disassembly

INFOID:000000007577408

- When instructed to use SST, use specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Dowel pins are used for several parts alignment. When replacing and reassembling parts with dowel pins, check that dowel pins are installed in the original position.
- Cover openings of engine system with a tape or equivalent, if necessary, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and reassembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used in the step.

## Inspection, Repair and Replacement

INFOID:000000007577409

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

# PRECAUTIONS

< PRECAUTION >

[MR16DDT ]

## Assembly and Installation

INFOID:000000007577410

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check engine oil or engine coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- Release air within route when refilling after draining engine coolant.
- After repairing, start the engine and increase engine speed to check engine coolant, fuel, engine oil, and exhaust gases for leakage.

## Parts Requiring Angle Tightening

INFOID:000000007577411

- Use the angle wrench [SST: KV10112100 (BT8653-A)] for the final tightening of the following engine parts:
  - Camshaft sprocket (INT) bolt
  - Cylinder head bolts
  - Main bearing cap bolts
  - Connecting rod cap bolts
  - Crankshaft pulley bolt (No the angle wrench is required as bolt flange is provided with notches for angle tightening)
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

## Liquid Gasket

INFOID:000000007577412

### REMOVAL OF LIQUID GASKET SEALING

- After removing mounting nuts and bolts, separate the mating surface using the seal cutter [SST: KV10111100 (J-37228)] (A) and remove old liquid gasket sealing.


#### CAUTION:

**Be careful not to damage the mating surfaces.**

- Tap the seal cutter [SST: KV10111100 (J-37228)] to insert it (B), and then slide it (C) by tapping on the side as shown in the figure.
- In areas where the seal cutter [SST: KV10111100 (J-37228)] is difficult to use, lightly tap the parts using a plastic hammer to remove it.


#### CAUTION:

**If for some unavoidable reason tool such as a screwdriver is used, be careful not to damage the mating surfaces.**



### LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper (A), remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
  - Remove liquid gasket completely from the groove of the liquid gasket application surface, mounting bolts, and bolt holes.
2. Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.



# PRECAUTIONS


[MR16DDT ]

## < PRECAUTION >

3. Attach liquid gasket tube to the tube presser (commercial service tool).

**Use Genuine RTV Silicon Sealant or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).**

4. Apply liquid gasket without gaps to the specified location according to the specified dimensions.
  - If there is a groove for liquid gasket application, apply liquid gasket to the groove.




- As for bolt holes (B), normally apply liquid gasket inside the holes. Occasionally, it should be applied outside the holes. Check to read the text of this manual.

A : Groove

⇐ : Inside

- Within five minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten mounting bolts or nuts after the installation.
- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.



### CAUTION:

**If there are specific instructions in this manual, observe them.**







## PREPARATION

### PREPARATION

#### Special Service Tools

INFOID:000000007577413

The actual shapes oh Kent-Moore tools may differ from those of special service tools illustrated here.








Tool number (Kent-Moore No.) Tool name	Description
KV10111100 (J-37228) Seal cutter	Removing oil pan (upper and lower) etc.  S-NT046
KV10114400 (J-38365) Heated oxygen sensor wrench	Loosening or tightening heated oxygen sensor 2 (AWD models) <b>a: For 22 mm (0.87 in) width hexagon nut</b>  S-NT636
KV10116200 (J-26336-A) Valve spring compressor 1. KV10115900 (J-26336-20) Attachment 2. KV10109220 ( — ) Adapter	Disassembling and assembling valve mechanism Part (1) is a component of KV10116200 (J-26336-A), but Part (2) is not so.  PBIC1650E
KV10112100 (BT8653-A) Angle wrench	Tightening bolts for main bearing cap, cylinder head, etc.  S-NT014
KV10117100 (J-3647-A) Heated oxygen sensor wrench	Loosening or tightening air fuel ratio sensor 1 <b>For 22 mm (0.87 in) width hexagon nut</b>  NT379
KV10107902 (J-38959) Valve oil seal puller	Removing valve oil seal  NT011



# PREPARATION

< PREPARATION >

[MR16DDT ]

Tool number (Kent-Moore No.) Tool name	Description	A
KV10115600 (J-38958) Valve oil seal drift	 <p>Installing valve oil seal <b>Use side A (G).</b> a: 20 (0.79) dia. d: 8 (0.31) dia. b: 13 (0.51) dia. e: 10.7 (0.421) c: 10.3 (0.406) dia. f: 5 (0.20) H: Side B</p> <p>Unit: mm (in)</p>	EM
EM03470000 (J-8037) Piston ring compressor	 <p>Installing piston assembly into cylinder bore</p>	D
ST16610001 (J-23907) Pilot bushing puller	 <p>Removing pilot converter</p>	F
KV11103000 ( — ) Pulley puller	 <p>Removing crankshaft pulley</p>	G
KV11105210 (J-44716) Stopper plate	 <p>Fixing drive plate</p>	H
KV10119600 ( — ) Injector remover	 <p>Removing fuel injector</p>	I
KV101197S0 ( — ) Injector seal drift set	 <p>Installing fuel injector seal ring</p>	J







# PREPARATION

< PREPARATION >

[MR16DDT ]

## Commercial Service Tools





INFOID:000000007577414

(Kent-Moore No.) Tool name	Description
( — ) Spark plug wrench	Removing and installing spark plug a: 14 mm (0.55 in)
 JPBIA0399ZZ	
( — ) Pulley holder	Crankshaft pulley removing and installing
 ZZA1010D	
( — ) Valve seat cutter set	Finishing valve seat dimensions
 S-NT048	
( — ) Piston ring expander	Removing and installing piston ring
 S-NT030	
( — ) Valve guide drift	Removing and installing valve guide
 PBIC4012E	
( — ) Valve guide reamer	1: Reaming valve guide inner hole 2: Reaming hole for oversize valve guide
 PBIC4013E	

# PREPARATION

< PREPARATION >

[MR16DDT ]

(Kent-Moore No.) Tool name		Description	
(J-43897-18) (J-43897-12) Oxygen sensor thread cleaner		Reconditioning the exhaust system threads before installing a new air fuel ratio sensor (Use with anti-seize lubricant shown below.) <b>A: J-43897-18 [18 mm (0.71 in) dia.] for zirconia heated oxygen sensor</b> <b>B: J-43897-12 [12 mm (0.47 in) dia.] for titania heated oxygen sensor</b> C: Mating surface shave cylinder D: Flutes	A EM
( — ) Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)		Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads	D E F
( — ) Manual lift table caddy		Removing and installing engine	G H
( — ) Tube presser		Pressing the tube of liquid gasket	I J K L M N O P

## BASIC INSPECTION

## CAMSHAFT VALVE CLEARANCE

## Inspection and Adjustment


INFOID:000000007577415

## INSPECTION

Perform inspection as follows after removal, installation or replacement of camshaft or valve-related parts, or if there is unusual engine conditions regarding valve clearance.

1. Remove rocker cover. Refer to [EM-57, "Exploded View"](#).
2. Measure the valve clearance with the following procedure:
  - a. Set No. 1 cylinder at TDC of its compression stroke.
    - Rotate crankshaft pulley (1) clockwise and align TDC mark (no paint) (B) to timing indicator (A) on front cover.


C : White paint mark (Not use for service)



- At the same time, check that both intake and exhaust cam noses of No. 1 cylinder face inside (←) as shown in the figure.


- 1 : Camshaft (INT)  
 2 : Camshaft (EXH)  
 ← : Engine front

- If they do not face inside, rotate crankshaft pulley once more (360 degrees) and align as shown in the figure.



- b. Use a feeler gauge, measure the clearance between valve lifter and camshaft.

**Valve clearance** : Refer to [EM-136, "Camshaft"](#).




# CAMSHAFT VALVE CLEARANCE

[MR16DDT ]

## < BASIC INSPECTION >

- By referring to the figure, measure the valve clearances at locations marked "x" as shown in the table below [locations indicated with black arrow (↖) in the figure] with a feeler gauge.


- A : Exhaust side  
 B : No. 1 cylinder  
 C : No. 2 cylinder  
 D : No. 3 cylinder  
 E : No. 4 cylinder  
 F : Intake side  
 ↖ : Engine front



Measuring position		No. 1 CYL.	No. 2 CYL.	No. 3 CYL.	No. 4 CYL.
No. 1 cylinder at compression TDC	EXH	x		x	
	INT	x	x		


- c. Set No. 4 cylinder at TDC of its compression stroke.
- Rotate crankshaft pulley (1) one revolution (360 degrees) and align TDC mark (no paint) (B) to timing indicator (A) on front cover.

- C : White paint mark (Not use for service)



- By referring to the figure, measure the valve clearance at locations marked "x" as shown in the table below [locations indicated with black arrow (↖) in the figure] with a feeler gauge.

- A : Exhaust side  
 B : No. 1 cylinder  
 C : No. 2 cylinder  
 D : No. 3 cylinder  
 E : No. 4 cylinder  
 F : Intake side  
 ↖ : Engine front



Measuring position		No. 1 CYL.	No. 2 CYL.	No. 3 CYL.	No. 4 CYL.
No. 4 cylinder at compression TDC	EXH		x		x
	INT			x	x

3. If out of standard, perform adjustment. Refer to "ADJUSTMENT".

## ADJUSTMENT


- Perform adjustment depending on selected head thickness of valve lifter.
- Remove camshaft. Refer to [EM-84. "Exploded View"](#).
  - Remove valve lifters at the locations that are out of the standard.

## CAMSHAFT VALVE CLEARANCE

### < BASIC INSPECTION >

[MR16DDT ]

3. Measure the center thickness of the removed valve lifters with a micrometer (A).



4. Use the equation below to calculate valve lifter thickness for replacement.

**Valve lifter thickness calculation:**  $t = t_1 + (C_1 - C_2)$

**t** = Valve lifter thickness to be replaced

**t<sub>1</sub>** = Removed valve lifter thickness


**C<sub>1</sub>** = Measured valve clearance

**C<sub>2</sub>** = Standard valve clearance:

**Intake** : 0.28 mm (0.011 in)

**Exhaust** : 0.29 mm (0.011 in)

- Thickness of new valve lifter (B) can be identified by stamp mark (A) on the reverse side (inside the cylinder).
- Stamp mark "302" indicates 3.02 mm (0.1189 in) in thickness.



#### NOTE:

Available thickness of valve lifter: 26 sizes range 3.00 to 3.50 mm (0.1181 to 0.1378 in) in steps of 0.02 mm (0.0008 in) (when manufactured at factory). Refer to [EM-136, "Camshaft"](#).


5. Install the selected valve lifter.
6. Install camshaft. Refer to [EM-84, "Exploded View"](#).
7. Install timing chain and related parts. Refer to [EM-72, "Exploded View"](#).
8. Manually rotate crankshaft pulley a few rotations.
9. Check that the valve clearances is within the standard. Refer to "INSPECTION".
10. Install remaining parts in the reverse order of removal.
11. Warm up the engine, and check for unusual noise and vibration.

## COMPRESSION PRESSURE

### Inspection


INFOID:000000007577416

1. Warm up engine thoroughly. Then, stop it.
2. Release fuel pressure. Refer to [EC-136, "Work Procedure"](#).
3. Remove ignition coil and spark plug from each cylinder. Refer to [EM-57, "Exploded View"](#).
4. Connect engine tachometer (not required in use of CONSULT).
5. Install compression gauge (B) with an adapter (A) (commercial service tool) onto spark plug hole.



- Use the adapter whose picking up end inserted to spark plug hole is smaller than 20 mm (0.79 in) in diameter. Otherwise, it may be caught by cylinder head during removal.

a : 20 mm (0.79 in)



6. With accelerator pedal fully depressed, turn ignition switch to "START" for cranking. When the gauge pointer stabilizes, read the compression pressure and the engine rpm. Perform these steps to check each cylinder.

**Compression pressure** : Refer to [EM-135, "General Specification"](#).

#### CAUTION:

**Always use a fully charged battery to obtain the specified engine speed.**

- If the engine speed is out of the specified range, check battery liquid for proper gravity. Check the engine speed again with normal battery gravity.
- If compression pressure is below minimum value, check valve clearances, and parts associated with combustion chamber (valve, valve seat, piston, piston ring, cylinder bore, cylinder head, and cylinder head gasket). After the checking, measure compression pressure again.
- If some cylinder has low compression pressure, pour small amount of engine oil into the spark plug hole of the cylinder to recheck it for compression.
- If the added engine oil improves the compression, piston rings may be worn out or damaged. Check piston rings and replace if necessary.
- If the compression pressure remains at low level despite the addition of engine oil, valves may be malfunctioning. Check valves for damage. Replace valve or valve seat accordingly.
- If two adjacent cylinders have respectively low compression pressure and their compression remains low even after the addition of engine oil, cylinder head gaskets are leaking. In such a case, replace cylinder head gaskets.


7. After inspection is completed, install removed parts.
8. Start the engine, and check that the engine runs smoothly.
9. Perform trouble diagnosis. If DTC appears, erase it. Refer to [EC-150, "Description"](#).

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH troubleshooting Chart

INFOID:000000007577417



1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.



# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[MR16DDT ]

4. Check specified noise source.

If necessary, repair or replace these parts.

Location of noise	Type of noise	Operating condition of engine						Source of noise	Check item	Reference page
		Before warm-up	After warm-up	When starting	When idling	When racing	While driving			
Top of engine Rocker cover Cylinder head	Ticking or clicking	C	A	—	A	B	—	Tappet noise	Valve clearance	<a href="#">EM-12</a>
	Rattle	C	A	—	A	B	C	Camshaft bearing noise	Camshaft journal oil clearance Camshaft runout	<a href="#">EM-136</a>
Crank-shaft pulley Cylinder block (Side of engine) Oil pan	Slap or knock	—	A	—	B	B	—	Piston pin noise	Piston to piston pin oil clearance Connecting rod bushing oil clearance	<a href="#">EM-140</a>
	Slap or rap	A	—	—	B	B	A	Piston slap noise	Piston to cylinder bore clearance Piston ring side clearance Piston ring end gap Connecting rod bend and torsion	<a href="#">EM-140</a>
	Knock	A	B	C	B	B	B	Connecting rod bearing noise	Connecting rod bushing oil clearance Connecting rod bearing oil clearance	<a href="#">EM-140</a> <a href="#">EM-144</a>
	Knock	A	B	—	A	B	C	Main bearing noise	Main bearing oil clearance Crankshaft runout	<a href="#">EM-144</a> <a href="#">EM-140</a>
Front of engine Front cover	Tapping or ticking	A	A	—	B	B	B	Timing chain and chain tensioner noise	Timing chain cracks and wear Timing chain tensioner operation	<a href="#">EM-82</a> <a href="#">EM-72</a>
Front of engine	Squeaking or fizzing	A	B	—	B	—	C	Drive belt (Sticking or slipping)	Drive belt deflection	<a href="#">EM-18</a>
	Creaking	A	B	A	B	A	B	Drive belt (Slipping)	Idler pulley bearing operation	
	Squall Creak	A	B	—	B	A	B	Water pump noise	Water pump operation	<a href="#">CO-19</a>


A: Closely related B: Related C: Sometimes related —: Not related

## PERIODIC MAINTENANCE

### DRIVE BELT

#### Exploded View

INFOID:000000007577418




- |                       |                                           |                      |
|-----------------------|-------------------------------------------|----------------------|
| 1. Alternator         | 2. Drive belt auto-tensioner              | 3. Crankshaft pulley |
| 4. A/C compressor     | 5. Water pump                             | 6. Drive belt        |
| A. Possible use range | B. Range when new drive belt is installed | C. Indicator         |

#### Removal and Installation

INFOID:000000007577419

##### REMOVAL

- Turn the steering wheel to the right.
- Remove the front fender protector (RH) front side bolts and clips. And keep a service area. Refer to [EXT-21, "Exploded View"](#).
- Hold the hexagonal part (A) of drive belt auto-tensioner (1) with a wrench securely. Then move the wrench handle in the direction of arrow (loosening direction of tensioner).  
**CAUTION:**  
**Avoid placing hand in a location where pinching may occur if the holding tool accidentally comes off.**
- Insert a rod approximately 6 mm (0.24 in) in diameter such as short-length screwdriver into the hole (B) of the retaining boss to fix drive belt auto-tensioner.
  - Keep drive belt auto-tensioner pulley arm locked after drive belt is removed.
- Remove drive belt.



##### INSTALLATION

- Install drive belt.  
**CAUTION:**
  - Confirm drive belt is completely set to pulleys.
  - Check for engine oil, working fluid and engine coolant are not adhered to drive belt and each pulley groove.
- Release drive belt auto-tensioner, and apply tension to drive belt.
- Turn crankshaft pulley clockwise several times to equalize tension between each pulley.
- Confirm tension of drive belt at indicator (notch on fixed side) is within the possible use range. Refer to [EM-18, "Exploded View"](#).


## DRIVE BELT

< PERIODIC MAINTENANCE >

[MR16DDT ]

### Inspection

INFOID:000000007577420



- |                       |                                           |                      |
|-----------------------|-------------------------------------------|----------------------|
| 1. Alternator         | 2. Drive belt auto-tensioner              | 3. Crankshaft pulley |
| 4. A/C compressor     | 5. Water pump                             | 6. Drive belt        |
| A. Possible use range | B. Range when new drive belt is installed | C. Indicator         |

#### **WARNING:**

**Perform this step when engine is stopped.**

- Check that the indicator (C) (notch on fixed side) of drive belt auto-tensioner is within the possible use range (A) in the figure.

#### **NOTE:**

- Check the drive belt auto-tensioner indication when the engine is cold.
- When new drive belt is installed, the indicator (notch on fixed side) should be within the range (B) in the figure.
- Visually check entire drive belt for wear, damage or cracks.
- If the indicator (notch on fixed side) is out of the possible use range or belt is damaged, replace drive belt.

### Adjustment

INFOID:000000007577421

Refer to : [EM-135, "Drive Belt"](#).

# AIR CLEANER FILTER


< PERIODIC MAINTENANCE >

[MR16DDT ]

## AIR CLEANER FILTER

### Exploded View

INFOID:000000007577422



- |                            |                       |                               |
|----------------------------|-----------------------|-------------------------------|
| 1. Mass air flow sensor    | 2. Gasket             | 3. Clamp                      |
| 4. Air duct (suction side) | 5. Clamp              | 6. Air cleaner cover assembly |
| 7. Mounting rubber         | 8. Air cleaner filter | 9. Air cleaner body assembly  |
| 10. Air duct inlet (lower) | 11. Grommet           | 12. Air duct inlet (upper)    |
| 13. Grommet                | 14. Bracket           | 15. Mounting rubber           |
| A. To turbocharger         |                       |                               |

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

## Removal and Installation

INFOID:000000007577423


### REMOVAL

# AIR CLEANER FILTER


[MR16DDT ]

## < PERIODIC MAINTENANCE >

1. Remove air duct inlet (upper) (1).
2. Unhook the tabs (A) of both ends of the air cleaner cover.



3. Remove the air cleaner filter (1) and air cleaner body (2) from the air cleaner case.
4. Remove the air cleaner filter from the air cleaner body.



## INSTALLATION

Note the following, and install in the reverse order of removal.

- Fixing clips shall be fixed after inserting air cleaner body protrusion to air cleaner case notch hole.
- Make sure that whether air cleaner body has been firmly installed by shaking it.

## Inspection

INFOID:000000007577424

## INSPECTION AFTER REMOVAL

Examine with eyes that there is no stain, clogging, or damage on air cleaner element.

- Remove dusts (such as dead leaves) on air cleaner element surface and inside cleaner case.
- If clogging or damage is observed, replace the air cleaner element.

### **CAUTION:**

**Never clean the viscous paper type air cleaner element by blowing as there is a risk of deterioration of its performance.**

## MAINTENANCE INTERVAL

Refer to [MA-6, "Introduction of Periodic Maintenance"](#).

# SPARK PLUG


< PERIODIC MAINTENANCE >

[MR16DDT ]

## SPARK PLUG

### Exploded View

INFOID:000000007577425



- |                           |                                                                                       |                        |
|---------------------------|---------------------------------------------------------------------------------------|------------------------|
| 1. Rocker cover protector | 2. O-ring                                                                             | 3. PCV valve           |
| 4. PCV hose               | 5. Clamp                                                                              | 6. Rocker cover gasket |
| 7. Rocker cover           | 8. Clamp                                                                              | 9. PCV hose            |
| 10. Oil filler cap        | 11. Spark plug                                                                        | 12. Ignition coil      |
| A. To intake manifold     | B. Comply with the assembly procedure when tightening. Refer to <a href="#">EM-57</a> | C. To air duct         |

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

## Removal and Installation

INFOID:000000007577426

### REMOVAL

1. Remove engine cover. Refer to [EM-24, "Exploded View"](#).
2. Remove air inlet tube assembly. Refer to [EM-30, "Exploded View"](#).
3. Remove ignition coil.

# SPARK PLUG

## < PERIODIC MAINTENANCE >


[MR16DDT ]

4. Remove spark plug with a spark plug wrench (commercial service tool).

a : 14 mm (0.55 in)

### CAUTION:

Never drop or shock spark plug.



## INSTALLATION

Install in the reverse order of removal.

## Inspection

INFOID:000000007577427

## INSPECTION AFTER REMOVAL

Use the standard type spark plug for normal condition.


Spark plug (Standard type) : Refer to [EM-135, "Spark Plug"](#).

### CAUTION:


- Never drop or shock spark plug.
- Never use a wire brush for cleaning.
- If plug tip is covered with carbon, spark plug cleaner may be used.

Cleaner air pressure : Less than 588 kPa (6 kg/cm<sup>2</sup>, 85 psi)

Cleaning time : Less than 20 seconds



- Spark plug gap adjustment is not required between replacement intervals.
- Measure spark plug gap. when it exceeds the limit, replace spark plug even if it is with in the specified replacement mileage. Refer to [EM-135, "Spark Plug"](#).




## REMOVAL AND INSTALLATION

### ENGINE COVER

Exploded View

INFOID:000000007577428



1. Engine cover

2. Mounting rubber (Black)

3. Mounting rubber (Gray)

### Removal and Installation

INFOID:000000007577429

#### REMOVAL

Remove engine cover.

#### **CAUTION:**

**Never damage or scratch engine cover when installing or removing.**

#### INSTALLATION

Install in the reverse order of removal.



# AIR CLEANER AND AIR DUCT


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## AIR CLEANER AND AIR DUCT

### Exploded View

INFOID:000000007577430



- |                            |                       |                               |
|----------------------------|-----------------------|-------------------------------|
| 1. Mass air flow sensor    | 2. Gasket             | 3. Clamp                      |
| 4. Air duct (suction side) | 5. Clamp              | 6. Air cleaner cover assembly |
| 7. Mounting rubber         | 8. Air cleaner filter | 9. Air cleaner body assembly  |
| 10. Air duct inlet (lower) | 11. Grommet           | 12. Air duct inlet (upper)    |
| 13. Grommet                | 14. Bracket           | 15. Mounting rubber           |
- A. To turbocharger

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

### Removal and Installation

INFOID:000000007577431

#### REMOVAL

##### NOTE:

Mass air flow sensor is removable under the car-mounted condition.

1. Remove engine cover. Refer to [EM-24, "Exploded View"](#).
2. Remove air duct inlet (upper).
3. Remove the air cleaner filter from the air cleaner case.
4. Disconnect mass air flow sensor harness connector, and remove harness clamp from air cleaner body.
5. Remove air cleaner body assembly.
6. Remove the air duct (suction side).
  - Add matching marks if necessary for easier installation.

## AIR CLEANER AND AIR DUCT

[MR16DDT ]

### < REMOVAL AND INSTALLATION >

---

7. Remove air cleaner cover assembly.
8. Remove mass air flow sensor from air cleaner cover, if necessary.

**CAUTION:**

**Handle the mass air flow sensor with following cares.**

- **Never shock the mass air flow sensor.**
- **Never disassemble the mass air flow sensor.**
- **Never touch the sensor of the mass air flow sensor.**

9. Remove air duct inlet (lower) with the following procedure.
  - a. Remove fender protector (LH). Refer to [EXT-21, "Exploded View"](#).
  - b. Remove air duct inlet (lower).

### INSTALLATION

Note the following, and install in the reverse order of removal.

- Align marks. Attach each joint. Screw clamps firmly.
- Fixing clips shall be fixed after inserting air cleaner body assembly protrusion to air cleaner case botch hole.
- Make sure whether air cleaner body has been firmly installed by shaking it.

### Inspection

INFOID:000000007577432

### INSPECTION AFTER REMOVAL

Inspect air duct and resonator assembly for crack or tear.

- If anything found, replace air duct and resonator assembly.

# INTAKE MANIFOLD


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## INTAKE MANIFOLD


### Exploded View


INFOID:000000007577433




- |                                                       |                                      |                                |
|-------------------------------------------------------|--------------------------------------|--------------------------------|
| 1. Clamp                                              | 2. Water hose                        | 3. PCV hose                    |
| 4. Gasket                                             | 5. Intake manifold                   | 6. Vacuum tube                 |
| 7. Vacuum hose (with check valve)                     | 8. Vacuum hose                       | 9. Vacuum gallery assembly     |
| 10. EVAP hose                                         | 11. EVAP check valve                 | 12. EVAP hose                  |
| 13. EVAP canister purge volume control solenoid valve | 14. Bracket                          | 15. Bracket                    |
| 16. EVAP hose                                         | 17. EVAP service port                | 18. EVAP hose                  |
| 19. EVAP tube                                         | 20. EVAP hose                        | 21. Water hose                 |
| 22. Electric throttle control actuator                | 23. Gasket                           |                                |
| A. To turbocharger                                    | B. To centralized under-floor piping | C. To recirculation valve hose |
| D. To break booster hose                              |                                      |                                |

: N·m (kg-m, ft-lb)

 : N·m (kg·m, in·lb)

 : Always replace after every disassembly.


 : Indicates that the part is connected at points with same symbols in actual vehicle.

## Removal and Installation


INFOID:000000007577434

### REMOVAL

1. Remove engine cover. Refer to [EM-24, "Exploded View"](#).
2. Pull out oil level gauge.  
**CAUTION:**  
**Cover the oil level gauge guide openings to avoid entry of foreign materials.**
3. Disconnect turbocharger boost sensor (with intake air temperature sensor 2) harness connector. Refer to [EM-30, "Exploded View"](#).
4. Remove air inlet tube assembly. Refer to [EM-30, "Exploded View"](#).
5. Disconnect water hoses from electric throttle control actuator as follows:
  - Attach plug to prevent engine coolant leakage when engine coolant is not drained. Refer to [CO-8, "Draining"](#).**CAUTION:**  
**Perform this step when the engine is cold.**  
**NOTE:**  
This step is not required when removing only intake manifold.
6. Disconnect electric throttle control actuator harness connector.
7. Remove electric throttle control actuator.  
**CAUTION:**
  - Handle carefully to avoid any shock to electric throttle control actuator.
  - Never disassemble electric throttle control actuator.
8. Remove EVAP vacuum tank.
9. Disconnect EVAP canister purge volume control solenoid valve harness connector, and then remove bracket with EVAP canister purge volume control solenoid valve.
10. Remove vacuum gallery.
11. Disconnect PCV hose (intake manifold side).
12. Remove intake manifold (1) with the following procedure.
  - Loosen and remove intake manifold mounting bolt (A).



- Loosen mounting bolts in reverse order as shown in the figure.


 : Engine front

### NOTE:

Disregard the numerical order No.6 in removal.

### CAUTION:

**Cover engine openings to avoid entry of foreign materials.**



# INTAKE MANIFOLD

[MR16DDT ]

## < REMOVAL AND INSTALLATION >

### INSTALLATION

Note the following, and install in the reverse order of removal.


#### Intake Manifold

1. Check if gasket is not dropped from the installation groove of intake manifold.
2. Install intake manifold with the following procedure:
  - a. Tighten in numerical order as shown in the figure.

← : Engine front

#### NOTE:


- Tighten bolt the No.1 in two steps.
- The numerical order No.6 shows the second step.



3. Install in the reverse order of removal after this step.

#### CAUTION:

Since check valve is built-in inside vacuum hose (1), install the vacuum hose fitting the arrow (A) to intake manifold side (2).



#### Electric Throttle Control Actuator

- Tighten bolts of electric throttle control actuator equally and diagonally in several steps.
- Perform "Throttle Valve Closed Position Learning" after repair when removing harness connector of the electric throttle control actuator. Refer to [EC-131. "Work Procedure"](#).
- Perform "Throttle Valve Closed Position Learning" and "Idle Air Volume Learning" after repair when replacing electric throttle control actuator. Refer to [EC-131. "Work Procedure"](#) and [EC-132. "Work Procedure"](#).

### Inspection

INFOID:000000007577435

### INSPECTION AFTER REMOVAL

#### Vacuum hose (with check valve)

Check that the check valve. Refer to [BR-40. "Inspection"](#).

# CHARGE AIR COOLER


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## CHARGE AIR COOLER

### Exploded View

INFOID:000000007577436



- |                               |                                          |                               |
|-------------------------------|------------------------------------------|-------------------------------|
| 1. Air inlet tube 3           | 2. Mounting rubber (gray)                | 3. Air inlet tube bracket     |
| 4. Clamp                      | 5. Air inlet hose 2                      | 6. Gasket                     |
| 7. Turbocharger               | 8. Mounting rubber                       | 9. Charge air cooler          |
| 10. Air inlet tube 2          | 11. Air inlet tube bracket               | 12. Air inlet hose 1          |
| 13. Air inlet tube 1          | 14. O-ring                               | 15. Turbocharger boost sensor |
| 16. Grommet                   | 17. Mounting rubber (black)              | 18. Air inlet hose            |
| 19. Clamp                     | 20. Recirculation valve                  | 21. Clamp                     |
| 22. Vacuum hose               |                                          |                               |
| A. To vacuum gallery assembly | B. To electric throttle control actuator | C. To turbocharger            |

↩ : Vehicle front

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

: Should be lubricated with oil.

## Removal and Installation

INFOID:000000007577437

### REMOVAL

Air inlet hose 1, Air inlet tube 1 and Recirculation valve

1. Remove engine cover. Refer to [EM-24. "Exploded View"](#).

# CHARGE AIR COOLER

[MR16DDT ]

## < REMOVAL AND INSTALLATION >

2. Make matching marks on each connecting part for reference at installation.
3. Remove recirculation hose and vacuum hose to recirculation valve.
4. Loosen clamp, and then remove air inlet hose 1.
5. Remove recirculation valve and turbocharger boost sensor from air inlet tube 1, if necessary.
6. loosen clamp, and then remove air inlet hose 1.

Air inlet tube 3


1. Remove engine cover. Refer to [EM-24, "Exploded View"](#).
2. Make matching marks on each connecting part for reference at installation.
3. Loosen clamp, and then remove air inlet tube 3.

Charge air cooler, Air inlet hose 2 and Air inlet tube 2

1. Remove front bumper. Refer to [EXT-11, "Exploded View"](#).
2. Remove radiator core support upper. Refer to [DLK-123, "Exploded View"](#)(With intelligent key system) or [DLK-238, "Exploded View"](#)(Without intelligent key system).
3. Make matching marks on each connecting part for reference at installation.
4. Remove air inlet hose 2.
5. Loosen air inlet tube 2 clamp, and then remove charge air cooler (1).

### CAUTION:

- Avoid interference between the charge air cooler and radiator.
- When removing charge air cooler, close opening on turbo charger and intake manifold with shop cloth or other suitable material.



6. Remove air inlet tube 2, if necessary.

## INSTALLATION

Install in the reverse order of removal paying attention to the following points:

### CAUTION:

**Do not reuse O-rings.**

- Apply a neutral detergent (fluid) to the joint between hoses and pipes (oil is not permissible).
- Pay attention to identification mark and direction.

## Inspection

INFOID:000000007577438

## INSPECTION AFTER REMOVAL


1. Check that the charge air cooler is not full of oil. In that case, clean it with cleaning agent and then let it dry.
2. Check air passages of charge air cooler core and fins for clogging, leaks or deformation. Clean or replace charge air cooler in necessary.
  - Be careful not to deform core fins.
  - For cleaning procedure of charge air cooler core, refer to [CO-16, "Inspection"](#).

## CATALYST

2WD

2WD : Exploded View

INFOID:000000007577439



- |                       |                                               |                                               |
|-----------------------|-----------------------------------------------|-----------------------------------------------|
| 1. A/F sensor 1       | 2. Catalyst converter shroud upper            | 3. Gasket                                     |
| 4. Catalyst converter | 5. Catalyst converter support bracket (lower) | 6. Catalyst converter support bracket (upper) |

A. To exhaust system

⇐ Engine front

⊗ : N·m (kg-m, ft-lb)

⊗ : N·m (kg-m, in-lb)

⊗ : Always replace after every disassembly.

●, ▲ : Indicates that the parts is connected at points with same symbols in actual vehicle.

## 2WD : Removal and Installation

INFOID:000000007577440

### REMOVAL

- Remove engine cover. Refer to [EM-24, "Exploded View"](#).
- Remove cowl top extension. Refer to [EXT-19, "Exploded View"](#).
- Remove front tube. Refer to [EX-5, "Exploded View"](#).
- Remove catalyst converter support bracket (lower).
- Remove A/F sensor 1.
  - Using heated oxygen sensor wrench [SST: KV10117100 (J-3647-A)], remove A/F sensor 1.

### CAUTION:

- Never damage air fuel ratio sensor 1.
- Discard any sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



# CATALYST

## < REMOVAL AND INSTALLATION >


[MR16DDT ]

6. Remove catalyst converter shroud upper.
7. Remove bolts and nut of catalyst converter turbocharger side.
8. Remove catalyst converter support bracket (upper).
9. Remove heat insulator. Refer to [FAX-18, "Exploded View"](#).
10. Remove catalyst converter.
11. Remove gasket.


## INSTALLATION

1. Install gasket between turbocharger and catalyst as shown in the figure.

- 1 : Gasket  
A : Turbocharger side  
B : Catalyst converter side  
C : Claw



2. Install catalyst converter with the following procedure.
  - Tighten in numerical order as shown in the figure.
  - Install catalyst converter (base on stud position 1).
  - Temporary assemble 2 (no priority).
  - Temporary assemble 3, 4.
  - Tightening 5, 6 and 7.
  - Tightening again 8, 9 and 10.
  - Temporary assemble 11.
  - Tightening 12,13,14,and 15.



3. Note the following, and install in the reverse order of removal.

### A/F sensor 1

- Using heated oxygen sensor wrench [SST: KV10117100 (J-3647-A)], install A/F sensor 1.

### CAUTION:

- Before installing a new sensors, clean exhaust system threads using heated oxygen sensor thread cleaner tool (Commercial Service Tool: J-43897-18 or J-43897-12) and apply anti-seize lubricant.
- Never apply excessive torque to sensor 2. Doing so may cause damage to sensor 2, resulting in the "MIL" illuminating.
- Prevent rust preventives from adhering to the sensor body.

AWD


# CATALYST

< REMOVAL AND INSTALLATION >

[MR16DDT ]

AWD : Exploded View

INFOID:000000007577441



- |                                               |                                               |                       |
|-----------------------------------------------|-----------------------------------------------|-----------------------|
| 1. A/F sensor 1                               | 2. Catalyst converter shroud upper            | 3. Gasket             |
| 4. Heated oxygen sensor 2                     | 5. Catalyst converter support bracket (lower) | 6. Catalyst converter |
| 7. Catalyst converter support bracket (upper) |                                               |                       |
| A. To exhaust system                          |                                               |                       |

Engine front

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

, : Indicates that the parts is connected at points with same symbols in actual vehicle.

AWD : Removal and Installation

INFOID:000000007577442

## REMOVAL

1. Drain engine coolant. Refer to [CO-8. "Draining"](#).
2. Remove engine cover. Refer to [EM-24. "Exploded View"](#).
3. Remove cowl top extension. Refer to [EXT-19. "Exploded View"](#).
4. Remove front tube. Refer to [EX-5. "Exploded View"](#).
5. Remove catalyst converter support bracket (lower).
6. Remove A/F sensor 1 and heated oxygen sensor 2.
  - Use heated oxygen sensor wrench [SST: KV10117100 (J-3647-A)], remove A/F sensor 1 and heated oxygen sensor 2.

### CAUTION:

- Never damage air fuel ratio sensor 1 and heated oxygen sensor 2.
- Discard any sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

# CATALYST

## < REMOVAL AND INSTALLATION >

[MR16DDT ]

7. Remove catalyst converter shroud (upper).
8. Remove bolts and nut of catalyst converter turbocharger side.
9. Remove heat insulator. Refer to [DLN-95, "Exploded View"](#).
10. Remove catalyst converter support bracket (upper).
11. Remove catalyst converter. And keep a service area.

### NOTE:


Slide the catalyst converter in a lateral direction to obtain work space for removing turbocharger.

12. Remove turbocharger. Refer to [EM-37, "Exploded View"](#).
13. Pull up and remove catalyst converter.
14. Remove gasket.

## INSTALLATION


1. Install gasket between turbocharger and catalyst as shown in the figure.

- 1 : Gasket  
A : Turbocharger side  
B : Catalyst converter side  
C : Claw



2. Install catalyst converter with the following procedure.

- Tighten in numerical order as shown in the figure.
- Install catalyst converter (base on stud position 1).
- Temporary assemble 2 (no priority).
- Temporary assemble 3, 4.
- Tightening 5, 6 and 7.
- Tightening again 8, 9 and 10.
- Temporary assemble 11.
- Tightening 12,13,14,and 15.



3. Note the following, and install in the reverse order of removal.

### A/F sensor 1 and Heated oxygen sensor 2

- Using heated oxygen sensor wrench [SST: KV10117100 (J-3647-A)], install A/F sensor 1 and heated oxygen sensor 2.

### CAUTION:

- Before installing a new sensors, clean exhaust system threads using heated oxygen sensor thread cleaner tool (Commercial Service Tool: J-43897-18 or J-43897-12) and apply anti-seize lubricant.
- Never apply excessive torque to sensors. Doing so may cause damage to sensors, resulting in the "MIL" illuminating.

## CATALYST

< REMOVAL AND INSTALLATION >

[MR16DDT ]

- 
- Prevent rust preventives from adhering to the sensor body.

# TURBOCHARGER


< REMOVAL AND INSTALLATION >

[MR16DDT]

## TURBOCHARGER

### Exploded View

INFOID:000000007577443



- |                                    |                               |                          |
|------------------------------------|-------------------------------|--------------------------|
| 1. Heat insulator                  | 2. Actuator hose              | 3. Clamp                 |
| 4. Turbocharger inlet tube         | 5. Gasket                     | 6. Gasket                |
| 7. Clamp                           | 8. Oil outlet hose            | 9. Oil return pipe       |
| 10. Oil supply tube                | 11. O-ring                    | 12. Gasket               |
| 13. Turbocharger                   | 14. Eye bolt                  | 15. Gasket               |
| 16. Oil supply tube                |                               |                          |
| A. To boost control solenoid valve | B. To air inlet hose          | C. To PCV hose           |
| D. To air duct                     | E. To air inlet tube assembly | F. To catalyst converter |

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

### Removal and Installation

INFOID:000000007577444

#### REMOVAL

# TURBOCHARGER

[MR16DDT ]

## < REMOVAL AND INSTALLATION >

1. Drain engine coolant. Refer to [CO-8, "Draining"](#).
2. Remove engine cover. Refer to [EM-24, "Exploded View"](#).
3. Remove air cleaner cover assembly and air cleaner body assembly. Refer to [EM-25, "Exploded View"](#).
4. Remove air inlet tube 3. Refer to [EM-30, "Exploded View"](#).
5. Remove cowl top extension. Refer to [EXT-19, "Exploded View"](#).
6. Disconnect heated oxygen sensor 2 harness connector.
7. Remove front tube. Refer to [EX-5, "Exploded View"](#).
8. Remove catalyst converter. Refer to [EM-32, "2WD : Exploded View"](#) (2WD models) or [EM-34, "AWD : Exploded View"](#) (AWD models).
9. Remove turbocharger assembly as follows:
  - a. Remove heat insulator.
  - b. Disconnect water hose from turbocharger. Refer to [EM-27, "Exploded View"](#).
  - c. Remove oil supply tube.
  - d. Remove mounting nuts of turbocharger.

### CAUTION:

**Never deform each turbocharger piping when pulling out the assembly.**

## INSTALLATION

### CAUTION:

**Do not reuse O-rings.**

Install in the reverse order of removal.

## Inspection

INFOID:000000007577445

## INSPECTION PROCEDURE

### Trouble Diagnosis of Turbocharger

#### Check items before trouble diagnosis

1. Check that the engine oil level is between L (Low level) and H (High level) of the oil level gauge. [When the engine oil amount is more than H (High level), the engine oil flows into the inlet duct through the blow-by gas passage, and the turbocharger is misjudged failure.]
2. Ask the customer if he/she always runs the vehicle in idle engine speed to cool the engine oil down after driving.
  - Replace the exhaust manifold and turbocharger assembly when any malfunction is found after unit inspections specified in the table below.
  - If no malfunction is found after the unit inspections, judge that the turbocharger body has no non-standard conditions. Check the other parts again.

Inspection Location	Result	Symptoms likely to occur when the results shown on the left exist.			
		Oil leakage	Smoke	Noise	Poor power Poor acceleration
Turbine wheel	Wet with oil.	C	A	C	C
	Carbon deposits observed.	C	A	B	B
	"Rubs against" housing.	C	B	A	B
	Vane is bent or broken.			A	A
Compressor wheel	Inside of intake port is badly stained with oil.	B	B		
	"Rubs against" housing.	C	B	A	B
	Vane is bent or broken.			A	A

# TURBOCHARGER

< REMOVAL AND INSTALLATION >

[MR16DDT ]


Inspection Location	Result	Symptoms likely to occur when the results shown on the left exist.			
		Oil leakage	Smoke	Noise	Poor power Poor acceleration
Check both turbine and compressor rotor shaft end play.	Heavy feel or catching when turned by hand.		C	C	B
	Cannot be turned by hand.				A
	Excessively loose bearing.	C	C	B	C
Rotor shaft, oil return port (Check inside using penlight.)	Carbon or sludge deposits in oil drain port.	C	A	C	C
Boost control valve actuator operation (using a handy pump)	<ul style="list-style-type: none"> <li>Does not operate smoothly when air pressure is gradually applied.</li> <li>Stroke amount is not compliance with the air pressure.</li> </ul>				A

**A:** Highly possible. **B:** Possible. **C:** May exist.

## INSPECTION AFTER REMOVAL

Turbocharger

Turbocharger



A. Check for leakage

### CAUTION:

When the compressor wheel, turbine wheel or rotor shaft is damaged, remove all the fragments and foreign matter left in the following passages in order to prevent a secondary failure:

**Suction side** : Between turbocharger and charge air cooler

**Exhaust side** : Between turbocharger and outlet duct

Turbocharger Boost Control

## TURBOCHARGER


[MR16DDT ]

### < REMOVAL AND INSTALLATION >

- Connect the a pressurized handy pump (A) to the actuator, and check that the rod strokes smoothly in compliance with the following pressure.

Standard (value of pressure/Value of rod moving):

Refer to [EM-136, "Turbocharger"](#).



### INSPECTION AFTER INSTALLATION

Start engine and raise engine speed to check no exhaust emission leaks.



# EXHAUST MANIFOLD


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## EXHAUST MANIFOLD

### Exploded View

INFOID:000000007577446



- 1. Stud bolt
- 2. Exhaust manifold cover
- 3. Exhaust manifold
- 4. Gasket
- ↶ Engine front

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

## Removal and Installation

INFOID:000000007577447

### REMOVAL

1. Drain engine coolant. Refer to [CO-8. "Draining"](#).
2. Remove front tube. Refer to [EX-5. "Exploded View"](#).
3. Remove turbocharger. Refer to [EM-37. "Exploded View"](#).
4. Remove exhaust manifold cover.
5. Remove exhaust manifold.

# EXHAUST MANIFOLD

## < REMOVAL AND INSTALLATION >


[MR16DDT ]

- Loosen nuts in reverse order as shown in the figure.

⇐ : Engine front

### NOTE:

Disregard the numerical order No. 9 to 12 in removal.



- Remove gasket.


### CAUTION:

Cover engine openings to avoid entry of foreign materials.

## INSTALLATION

- Install gasket to cylinder head as shown in the figure.

⇐ : Engine front




- Install exhaust manifold with the following procedure:
  - Tighten nuts in numerical order as shown in the figure.

⇐ : Engine front

### NOTE:

- Tighten nuts the No.1 to No.4 in two steps.
- The numerical order No.9 to No.12 shows the second step.



- Install remaining parts in the reverse order of removal.

## Inspection

INFOID:000000007577448


## INSPECTION AFTER REMOVAL

### Surface Distortion

- Using feeler gauge (A) and straightedge (B), check the surface distortion of exhaust manifold mating surface in each exhaust port and entire part.

**Limit** : Refer to [EM-136, "Exhaust Manifold"](#).

- If it exceeds the limit, replace exhaust manifold.



# OIL PAN (LOWER)


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## OIL PAN (LOWER)

### Exploded View

INFOID:000000007577449



- |                                |                      |                             |
|--------------------------------|----------------------|-----------------------------|
| 1. O-ring                      | 2. Oil pan (upper)   | 3. Oil level gauge guide    |
| 4. O-ring                      | 5. Oil level gauge   | 6. Oil pump drive chain     |
| 7. Crankshaft sprocket         | 8. Oil pump sprocket | 9. Oil pump chain tensioner |
| 10. Oil pump                   | 11. Drain plug       | 12. Drain plug washer       |
| 13. Oil pan (lower)            | 14. Oil filter       | 15. Connector bolt          |
| 16. Clamp                      | 17. Water hose       | 18. Oil cooler              |
| 19. Crankshaft position sensor | 20. Gasket           | 21. Oil pan bolt            |
| 22. Rear oil seal              |                      |                             |
- A. Refer to [LU-10](#)
- B. To thermostat hosing
- C. To thermostat housing (M/T models)  
To CVT oil warmer (CVT models)

D. Oil pan side

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

: Sealing point

# OIL PAN (LOWER)

## < REMOVAL AND INSTALLATION >

[MR16DDT ]



: Should be lubricated with oil.



: Indicates that the parts is connected at points with same symbols in actual vehicle.

## Removal and Installation

INFOID:000000007577450

### REMOVAL


1. Drain engine oil. Refer to [LU-8, "Draining"](#).
2. Remove oil pan (lower) with the following procedure:
  - a. Loosen mounting bolts in reverse order as shown in the figure.



: Engine front

#### NOTE:

Disregard the numerical order No.7 and No.11 in removal.




- b. Insert seal cutter [SST: KV10111100 (J-37228)] (A) between oil pan (upper) and oil pan (lower).

#### CAUTION:

- Never damage the mating surface.
- Never insert a screwdriver. This damages the mating surfaces.

- c. Slide the seal cutter [SST: KV10111100 (J-37228)] by tapping on the side of tool with a hammer.
    - d. Remove oil pan (lower).



### INSTALLATION


#### CAUTION:

**Do not reuse drain plug washer.**

1. Install oil pan (lower) as follows:
  - a. Use a scraper (A) to remove old liquid gasket from mating surfaces.
    - Also remove old liquid gasket from mating surface of oil pan (upper).
    - Remove old liquid gasket from the bolt holes and threads.

#### CAUTION:

**Never scratch or damage the mating surface when cleaning off old liquid gasket.**





## OIL PAN (LOWER)

[MR16DDT ]

### < REMOVAL AND INSTALLATION >


- b. Apply a continuous bead of liquid gasket (A) with a tube presser (commercial service tool) as shown in the figure.

- 1 : Oil pan (lower)  
 b : 7.5 - 9.5 mm (0.295 - 0.374 in)  
 c :  $\phi$  4.0 - 5.0 mm (0.157 - 0.197 in)  
 : Engine outside  
 : Engine front

Use Genuine RTV Silicon Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).


#### CAUTION:

Attaching should be done within 5 minutes after liquid gasket application.




JPBIA4367ZZ

- c. Tighten bolts in numerical order as shown in the figure.

-  : Engine front

#### NOTE:

- Tighten bolts the No.1 and No.2 in two steps.
- The numerical order No.7 and No.11 shows the second steps.



JPBIA4364GB

2. Install oil pan drain plug.

#### CAUTION:

Do not reuse drain plug washer.

- Refer to the figure of components of former page for installation direction of drain plug washer. Refer to [EM-106, "Exploded View"](#).

3. Install in the reverse order of removal after this step.

### Inspection

INFOID:000000007577451

#### INSPECTION AFTER REMOVAL

Clean oil strainer if any object attached.

#### INSPECTION AFTER INSTALLATION

1. Check the engine oil level and adjust engine oil. Refer to [LU-7, "Inspection"](#).
2. Start engine, and check there is no leakage of engine oil.
3. Stop engine and wait for 10 minutes.
4. Check the engine oil level again. Refer to [LU-7, "Inspection"](#).

# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

< REMOVAL AND INSTALLATION >

[MR16DDT ]


## HIGH PRESSURE FUEL PUMP AND FUEL HOSE

Exploded View

INFOID:000000007577452

### CAUTION:

Never remove or disassemble parts unless instructed as shown in the figure.



- |                                      |                                  |                   |
|--------------------------------------|----------------------------------|-------------------|
| 1. High pressure fuel pump insulator | 2. High pressure fuel pump       | 3. O-ring         |
| 4. High pressure fuel pump lifter    | 5. Fuel rail connector           | 6. Fuel tube      |
| 7. Bracket                           | 8. Fuel pump connector protector | 9. Fuel feed hose |

A. To centralized under-floor piping

↶ : Engine front

⊙ : N·m (kg-m, ft-lb)

⊙ : N·m (kg-m, in-lb)

⊗ : Always replace after every disassembly.

⊙ : Should be lubricated with oil.

● : Indicates that the parts is connected at points with same symbols in actual vehicle.

## Removal and Installation

INFOID:000000007577453

### REMOVAL

#### WARNING:

- Be sure to read [EM-5, "Precaution for Handling High Pressure Fuel System"](#) when working on the high pressure fuel system.
- Put a "CAUTION: FLAMMABLE" sign in the workshop.
- Be sure to work in a well ventilated area and furnish workshop with a CO2 fire extinguisher.


# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

< REMOVAL AND INSTALLATION >

[MR16DDT ]

- **Never smoke while servicing fuel system. Keep open flames and sparks away from the work area.**
- **To avoid the danger of being scalded, never drain engine coolant when engine is hot.**

1. Release fuel pressure. Refer to [EC-136. "Work Procedure"](#).
2. Remove engine cover. Refer to [EM-24. "Exploded View"](#).
3. Remove fuel pump connector protector, and remove high pressure fuel pump insulator.
4. Disconnect quick connector (A) with the following procedure.
  - a. Disconnect fuel feed hose (1) from bracket hose clamp (2).



- b. Disengage (A) and pull up (B) the pawl of the fuel feed hose connector retainer (C) to disconnect the fuel feed hose from high pressure fuel pump.


**NOTE:**

If the fuel feed hose is stuck, hold the fuel pipe by hand and disconnect it by pushing and pulling.


**CAUTION:**

- **Keep parts away from heat source. Especially, be careful when welding is performed around them.**
- **Never expose parts to battery electrolyte or other acids.**
- **Never bent or twist connection between quick connector and fuel feed hose (with damper) during installation/removal.**
- **Pull quick connector holding (D).**
- **Never remove the retainer.**
- **Prepare a tray and waste beforehand as fuel leaks out.**
- **Never pull with lateral force applied. O-ring inside quick connector may be damaged.**

Retainer color : Red



- **To prevent damage to each joint and protect it from the entry of foreign matter, cover the joint with plastic bag (A) or an equivalent.**



5. Remove intake manifold. Refer to [EM-28. "Removal and Installation"](#).
6. Remove fuel tube.
7. Remove fuel rail connector.

# HIGH PRESSURE FUEL PUMP AND FUEL HOSE


## < REMOVAL AND INSTALLATION >

[MR16DDT ]

8. Remove high pressure fuel pump (1) and lifter.

**CAUTION:**

To prevent damage to high pressure fuel pump and camshaft bracket, loosen bolt (A) alternately by one turn at a time until the reaction force applied on the high pressure fuel pump disappears.




## INSTALLATION

**CAUTION:**

- Do not reuse O-rings.
- To prevent damage to parts due to generated abnormal stress and eccentric load, always observe the installation procedure.

1. Install high pressure fuel pump according to the following procedure.

- a. Check the orientation of pump cam from the mounting area (view arrow) of high pressure fuel pump.




- b. Aim pump cam at the BDC area (arrow position).

1 : Camshaft (EXH)

**NOTE:**

For BDC area, anywhere within the area indicated by arrow can be accepted.



- c. Install O-ring to high pressure fuel pump. When handling new O-ring, paying attention to the following caution items:

**CAUTION:**

- Do not reuse O-ring.
- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with new engine oil.
- Never clean O-ring with solvent.
- Check that O-ring and its mating part are free of foreign material.
- Never damage O-ring with tools and fingernails during the installation. In addition, twisting or stretching O-ring is not allowed. If O-ring is stretched during the installation to high pressure fuel pump, never install high pressure fuel pump immediately.

- d. Install high pressure fuel pump lifter.
- e. Apply oil to the fitting area of high pressure fuel pump O-ring and camshaft bracket side to install high pressure fuel pump.
- f. Install high pressure fuel pump. To prevent damage to high pressure fuel pump and camshaft bracket, the following instructions must be observed.



# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

< REMOVAL AND INSTALLATION >


[MR16DDT ]

## CAUTION:

- Temporarily tighten bolt (A) by hand. Alternately tighten bolt by one turn at a time until high pressure fuel pump reaches camshaft bracket.

1 : High pressure fuel pump

- After a pump flange sitting, tighten the bolts to the specified torque.




2. Connect fuel feed hose with the following procedure, and then install the fuel feed hose.
  - a. Check no foreign substances are deposited in and around matching pipe and quick connector, and no damage on them.
  - b. Quick connector shall be inserted gradually, aligning with the axis of the matching pipe.
  - c. Insert the retainer until it clicks and check the retainer is locked. After insertion, pull the connector and check that the connector is locked.

A : Lock position

B : Unlock position

## CAUTION:

If retainer cannot be installed smoothly, quick connector may be have not been installed correctly. Check connection again.




- d. After attaching the quick connector and fix the hose to the clamp.
3. Install new fuel rail connector (1).

2 : O-ring

## CAUTION:

- Never reuse fuel rail connector.
- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with new engine oil.
- Never clean O-ring with solvent.
- Check that O-ring and its mating part are free of foreign material.
- Never scratch O-ring with tools or fingernails when installing fuel rail connector.
- Insert new fuel rail connector straight into fuel rail. Never decenter or twist the fuel rail connector during insertion.



4. Install the fuel tube with the following procedure.

## CAUTION:

- When removing fuel tube, always replace fuel rail connector together with fuel tube.
- Never reuse fuel tube.
- Never use fuel tube if its terminal tip is damaged.
- Observe the tightening order and the tightening torque.

## HIGH PRESSURE FUEL PUMP AND FUEL HOSE

## < REMOVAL AND INSTALLATION >

[MR16DDT]

- a. Temporarily tighten flare nut (A) and (B) of fuel tube (3) until seated.

- 1 : High pressure fuel pump  
2 : Fuel rail connector

**CAUTION:**


**When temporarily tightening flare nut, place pipe in the center of the nut inner diameter.**

- b. Temporarily tighten bolt (4) until the seat of bracket is seated.
- c. Tighten flare nut (A) and (B) in alphabetical order.

**CAUTION:**

**Always fit the tool completely with the nut.**

- d. Tighten bolt (4).
5. Install in the reverse order of removal after this step.



## Inspection

INFOID:0000000007577454

## INSPECTION AFTER INSTALLATION

### Check for Fuel Leakage

1. Turn ignition switch "ON" (with the engine stopped). With fuel pressure applied to fuel piping, check that there is no fuel leakage at connection points.

**NOTE:**

Use mirrors for checking at points out of clear sight.

2. Start the engine. With engine speed increased, check again that there is no fuel leakage at connection points.

**CAUTION:**

**Never touch the engine immediately after it is stopped because the engine is extremely hot.**

# FUEL INJECTOR AND FUEL TUBE


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## FUEL INJECTOR AND FUEL TUBE

Exploded View

INFOID:000000007577455



- |                                          |                                      |                                   |
|------------------------------------------|--------------------------------------|-----------------------------------|
| 1. Holder                                | 2. Seal ring (white)                 | 3. Backup ring                    |
| 4. O-ring (blue)                         | 5. Fuel injector                     | 6. Stud bolt                      |
| 7. Fuel rail                             | 8. Fuel rail insulator (united type) | 9. Adaptor cover (separated type) |
| 10. Fuel rail insulator (separated type) | 11. Fuel rail cover                  | 12. Fuel pressure sensor          |
| 13. Gasket                               |                                      |                                   |

A. To fuel rail connector and fuel tube.  
Refer to [EM-46](#).

B. Comply with the assembly procedure  
when tightening. Refer to [EM-51](#)

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

: Should be lubricated with oil.

: Indicates that the parts is connected at points with same symbols in actual vehicle.

### CAUTION:

- Never remove or disassemble parts unless instructed as shown in the figure.
- When fuel rail insulator (separated type) and adaptor cover (separated type) are removed, be sure to replace them with fuel insulator (united type).

## Removal and Installation

INFOID:000000007577456

### WARNING:

# FUEL INJECTOR AND FUEL TUBE

[MR16DDT ]

## < REMOVAL AND INSTALLATION >

- Be sure to read [EM-5, "Precaution for Handling High Pressure Fuel System"](#) when working on the high pressure fuel system.
- Put a "CAUTION: FLAMMABLE" sign in the workshop.
- Be sure to work in a well ventilated area and furnish workshop with a CO2 fire extinguisher.
- Never smoke while servicing fuel system. Keep open flames and sparks away from the work area.
- To avoid the danger of being scalded, never drain engine coolant when engine is hot.

### REMOVAL

1. Release the fuel pressure. Refer to [EC-136, "Work Procedure"](#).
2. Remove front bumper. Refer to [EXT-11, "Exploded View"](#).
3. Remove charge air cooler. Refer to [EM-30, "Exploded View"](#).
4. Remove oil level gauge. Refer to [EM-43, "Exploded View"](#).
5. Remove intake manifold. Refer to [EM-27, "Exploded View"](#).
6. Remove alternator. Refer to [CHG-22, "Exploded View"](#).
7. Remove oil level gauge guide. Refer to [EM-43, "Exploded View"](#).
8. Remove fuel rail cover, and then remove fuel rail insulator.

#### CAUTION:


When fuel rail insulator (separated type) and adapter cover (separated type) are removed, be sure to replace them with fuel rail insulator (united type).

9. Remove fuel tube and fuel rail connector. Refer to [EM-46, "Exploded View"](#).
10. Disconnect fuel pressure sensor harness connector.
11. Disconnect fuel injector harness connector.
12. Remove fuel pressure sensor, if necessary.
13. Remove fuel rail.
  - Loosen mounting bolts in reverse order as shown in the figure.

← : Engine front

#### CAUTION:

- When removing, be careful to avoid any interference with fuel injector.
- Use a shop cloth to absorb any fuel leakage from fuel rail.




14. Remove fuel injector from cylinder head as per the following.

#### CAUTION:

- Be careful with remaining fuel that may go out from fuel rail.
- Be careful not to damage injector nozzles during removal.
- Never bump or drop fuel injector.
- Never disassemble fuel injector.

- a. Remove injector holder.
- b. Install an remover [SST: KV10119600 (—)] (A) to the injector connector side so that cutout (B) of injector remover faces the injector connector side.




## FUEL INJECTOR AND FUEL TUBE


### < REMOVAL AND INSTALLATION >

[MR16DDT ]


- Hook pawl portion (B) of injector remover [SST: KV10119600 (—)] (A) to groove portion (C) of injector




- c. Press down body portion of injector remover [SST: KV10119600 (—)] (A) until it contacts cylinder head.



- d. Tighten injector remover [SST: KV10119600 (—)] clockwise and remove injector from cylinder head.



- e. Cut seal ring (1) while pinching it. Be careful not to damage injector.



# FUEL INJECTOR AND FUEL TUBE

< REMOVAL AND INSTALLATION >

[MR16DDT ]

## INSTALLATION

### CAUTION:


Do not reuse O-rings.

1. Install seal ring to fuel injector as per the following:


### CAUTION:

- Handle seal ring with bare hands. Never wear gloves.
- Never apply engine oil to seal ring.
- Never clean seal ring with solvent.

- a. Install an injector seal drift set [SST: KV101197S0 (—)] (A) to fuel injector (1).




- b. Set seal ring (1) to injector seal drift set [SST: KV101197S0 (—)] (A).



- c. Straightly insert seal ring (1), which is set in step 2, to fuel injector as shown in the figure and install.

### CAUTION:


Be careful that seal ring does not exceed the groove portion of fuel injector.



- d. Insert injector seal drift set [SST: KV101197S0 (—)] (A) to injector and rotate clockwise and counterclockwise by 90° while pressing seal ring to fit it.

### NOTE:

Compress seal ring, because this operation is for rectifying stretch of seal ring caused by installation and for preventing sticking when inserting injector into cylinder head.



2. Install O-ring and backup ring to fuel injector. When handing new O-ring and backup ring, paying attention to the following caution items:


### CAUTION:

# FUEL INJECTOR AND FUEL TUBE

< REMOVAL AND INSTALLATION >

[MR16DDT ]

- Do not reuse O-ring.
- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with new engine oil.
- Never clean O-ring with solvent.
- Check that O-ring and its mating part are free of foreign material.
- When installing O-ring, be careful not to scratch it with tool or fingernails. Also be careful not to twist or stretch O-ring. If O-ring was stretched while it was being attached, never insert it quickly into fuel tube.
- Insert new O-ring straight into fuel rail. Never decenter or twist it.
- Always install the back up ring (1) in the right direction as instructed.



3. Install fuel injector (1) to fuel rail (2) as per the following:

3 : O-ring (blue)

4 : Backup ring

a. Install fuel injector holder (5) to fuel injector.

**CAUTION:**


- Never reuse fuel injector holder. Replace it with a new one.
- Be careful to keep fuel injector holder from interfering with O-ring. If interference occurs, replace O-ring.

b. Insert fuel injector into fuel rail with fuel injector holder attached.

- Insert it while matching it to the axial center.
- Insert so that protrusion (A) of fuel injector is aligned to cutout (B).

c. Check that installation is complete by checking that fuel injector does not rotate or come off.

- Check that protrusions of fuel injectors and fuel rail are aligned with cutouts of clips after installation.




4. Install fuel rail and fuel injector assembly to cylinder head.

- Tighten mounting bolts and nuts in two steps in numerical order as shown in the figure.

← : Engine front

**1st step** : 10.0 N·m (1.0 kg-m, 89 in-lb)

**2nd step** : 20.5 N·m (2.1 kg-m, 15 ft-lb)



5. Connect injector harness connector.

6. Install fuel pressure sensor, if removed.

# FUEL INJECTOR AND FUEL TUBE

## < REMOVAL AND INSTALLATION >

[MR16DDT ]

7. Install fuel rail insulator.

**CAUTION:**

- As covering part of fuel tube connector at the back end of common rail can easily move because of its shape, do not remove it before installation.
- Install the insulator so that it is placed under lower side of intake manifold flange.

8. Install in the reverse order of removal after this step.

## Inspection

INFOID:000000007577457

## INSPECTION AFTER INSTALLATION

### Check on Fuel Leakage

1. Turn ignition switch "ON" (with the engine stopped). With fuel pressure applied to fuel piping, check there are no fuel leakage at connection points.

**NOTE:**

Use mirrors for checking at points out of clear sight.

2. Start the engine. With engine speed increased, check again that there are no fuel leakage at connection points.

**CAUTION:**

Never touch the engine immediately after stopped, as the engine becomes extremely hot.



# IGNITION COIL, SPARK PLUG AND ROCKER COVER


< REMOVAL AND INSTALLATION >

[MR16DDT ]

## IGNITION COIL, SPARK PLUG AND ROCKER COVER

Exploded View

INFOID:000000007577458



- |                           |                                                                                         |                        |
|---------------------------|-----------------------------------------------------------------------------------------|------------------------|
| 1. Rocker cover protector | 2. O-ring                                                                               | 3. PCV control valve   |
| 4. PCV hose               | 5. Clamp                                                                                | 6. Rocker cover gasket |
| 7. Rocker cover           | 8. Clamp                                                                                | 9. PCV hose            |
| 10. Oil filler cap        | 11. Spark plug                                                                          | 12. Ignition coil      |
| A. To intake manifold     | B. Comply with the assembly procedure when tightening. Refer to <a href="#">EM-57</a> . | C. To air duct         |

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

## Removal and Installation

INFOID:000000007577459

### REMOVAL

1. Drain engine coolant. Refer to [CO-8, "Draining"](#).
2. Remove engine cover. Refer to [EM-24, "Exploded View"](#).
3. Remove air inlet tube assembly. Refer to [EM-30, "Exploded View"](#).
4. Remove PCV hose.
5. Remove rocker cover protector.
6. Disconnect ignition coil harness connector, and then remove ignition coil.

### CAUTION:

- Never drop or shock ignition coil.

# IGNITION COIL, SPARK PLUG AND ROCKER COVER


## < REMOVAL AND INSTALLATION >

[MR16DDT ]

- **Never disassemble ignition coil.**

7. Move ignition harness.
8. Remove rocker cover.
  - Loosen bolts in reverse order shown in the figure.

⇐ : Engine front



9. Remove PCV valve and PCV hose, if necessary.
10. Remove rocker cover gasket from rocker cover.

## INSTALLATION

### CAUTION:

**Do not reuse O-rings.**


1. Install the rocker cover gasket to rocker cover.  
**CAUTION:**  
**Check the gasket is not dropped.**
2. Install rocker cover.
  - Tighten bolts in two steps separately in numerical order as shown in the figure.

⇐ : Engine front

 **1st step : 1.96 N·m (0.20 kg-m, 17 in-lb)**

 **2nd step : 8.33 N·m (0.85 kg-m, 74 in-lb)**

3. Install in the reverse order of removal, for the rest of parts.



## UNIT REMOVAL AND INSTALLATION


### ENGINE ASSEMBLY

2WD

2WD : Exploded View

M/T

INFOID:000000007577460



- |                                       |                                   |                                   |
|---------------------------------------|-----------------------------------|-----------------------------------|
| 1. Washer                             | 2. Upper torque rod (RH)          | 3. Engine mounting insulator (RH) |
| 4. Rear torque rod bracket            | 5. Rear torque rod                | 6. Engine mounting bracket (LH)   |
| 7. Engine mounting frame support (LH) | 8. Engine mounting insulator (LH) |                                   |


: N·m (kg-m, ft-lb)

: Always replace after every disassembly.

#### CAUTION:

Check that the stud bolt (\*2) is tight at the specified torque before tightening the mounting nut (\*1) shown in the figure. [Stud bolt (\*2) may be loosened after loosening the mounting nut (\*1)]

CVT



- |                                 |                          |                                   |
|---------------------------------|--------------------------|-----------------------------------|
| 1. Washer                       | 2. Upper torque rod (RH) | 3. Engine mounting insulator (RH) |
| 4. Rear engine mounting bracket | 5. Rear torque rod       | 6. Engine mounting insulator (LH) |

: N·m (kg-m, ft-lb)

: Always replace after every disassembly.

## 2WD : Removal and Installation

INFOID:000000007577461

### WARNING:

- Situate the vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Attach proper slingers and bolts described in PARTS CATALOG if engine slingers are not equipped.

### CAUTION:

- Always be careful to work safely, avoid forceful or uninstructed operations.
- Never start working until exhaust system and coolant are cool enough.
- If items or work required are not covered by the engine section, refer to the applicable sections.
- Always use the support point specified for lifting.
- Use either 2-pole lift type or separate type lift as best you can. If board-on type is used for unavoidable reasons, support at the rear axle jacking point with a transmission jack or similar tool before starting work, in preparation for the backward shift of center of gravity.
- For supporting points for lifting and jacking point at rear axle, refer to [GI-34, "Garage Jack and Safety Stand and 2-Pole Lift"](#).

### NOTE:

# ENGINE ASSEMBLY

[MR16DDT ]

## < UNIT REMOVAL AND INSTALLATION >

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

### REMOVAL

#### Outline

Remove the engine and the transaxle assembly from the vehicle downward. Separate the engine and the transaxle.

#### Preparation

1. Release fuel pressure. Refer to [EC-136, "Work Procedure"](#).
2. Drain engine coolant from radiator. Refer to [CO-8, "Draining"](#).  
**CAUTION:**
  - **Perform this step when the engine is cold.**
  - **Never spill engine coolant on drive belts.**
3. Remove the following parts.
  - Engine undercover
  - Front road wheels and tires
  - Front fender protector (RH and LH): Refer to [EXT-21, "Exploded View"](#).
  - Drive belt: Refer to [EM-18, "Removal and Installation"](#).
  - Engine cover: Refer to [EM-24, "Exploded View"](#).
  - Battery and battery tray: Refer to [PG-95, "Exploded View"](#).
  - Air duct, and air cleaner case assembly and air cleaner body assembly: Refer to [EM-25, "Exploded View"](#).
  - Radiator hose (upper and lower): Refer to [CO-14, "Exploded View"](#).
  - Exhaust front tube: Refer to [EX-5, "Exploded View"](#).
  - Radiator cooling fan assembly: Refer to [CO-17, "Exploded View"](#).
  - Charger air cooler: Refer to [EM-30, "Exploded View"](#).
  - Alternator: Refer to [CHG-22, "Exploded View"](#).

#### Engine Room LH

1. Disconnect all connections of engine harness around the battery, and then temporarily secure the engine harness into the engine side.  
**CAUTION:**  
**Protect connectors using a resin bag against foreign materials during the operation.**
2. Disconnect fuel feed hose quick connector. Refer to [EM-46, "Exploded View"](#).
3. Disconnect heater hoses. Refer to [CO-23, "Exploded View"](#).
4. Remove EVAP hoses. Refer to [EM-27, "Exploded View"](#).
5. Disconnect control cable from transaxle. (CVT models) Refer to [TM-215, "Exploded View"](#).
6. Disconnect control linkage from transaxle. (M/T models) Refer to [TM-20, "Exploded View"](#).
7. Disconnect clutch tube on transaxle side from clutch damper. (M/T models) Refer to [CL-15, "Exploded View"](#).

#### Engine Room RH

1. Disconnect vacuum hose from intake manifold. Refer to [EM-27, "Exploded View"](#).
2. Remove A/C compressor. Refer to [HA-27, "Exploded View"](#).
3. Remove ground cable at engine side.

#### Vehicle Underbody

1. Remove ground cable at transaxle side.
2. Remove drive shafts (RH and LH). Refer to [FAX-18, "Exploded View"](#).
3. Remove rear torque rod.
4. Remove stabilizer connecting rod. Refer to [FSU-14, "Exploded View"](#).
5. Remove front suspension member. Refer to [FSU-16, "Exploded View"](#).
6. Preparation for the separation work of transaxle is as follows:
  - Remove transaxle joint bolts which pierce at oil pan (upper) lower rear side. Refer to [EM-106, "Exploded View"](#).

#### Removal

# ENGINE ASSEMBLY


[MR16DDT ]

## < UNIT REMOVAL AND INSTALLATION >

1. Use a manual lift table caddy (commercial service tool) (A) or equivalently rigid tool such as a transmission jack. Securely support bottom of the engine and the transaxle assembly.


**CAUTION:**

**Put a piece of wood or an equivalent as the supporting surface, secure a completely stable condition.**




2. Remove upper torque rod (RH) (1), and engine mounting insulator (RH) (2).

↶ : Vehicle front



3. Remove engine mounting insulator (LH). (CVT models)
4. Remove the through bolt-securing nut (B) of engine mounting bracket (LH). (M/T models)

- 1 : Engine mounting insulator (LH)  
2 : Engine mounting frame support (LH)  
A : Through bolt  
↶ : Vehicle front



5. Carefully lower jack, or raise lift to remove the engine and the transaxle assembly. When performing work, observe the following caution.

**CAUTION:**

- Check that no part interferes with the vehicle side.
- Before and during this lifting, always check if any harnesses are left connected.
- During the removal, always be careful to prevent the vehicle from falling off the lift due to changes in the center of gravity.
- If necessary, support the vehicle by setting jack or suitable tool at the rear.

### Separation

1. Remove catalyst convertor. Refer to [EM-32, "2WD : Exploded View"](#).
2. Remove turbocharger. Refer to [EM-37, "Exploded View"](#).
3. Remove exhaust manifold. Refer to [EM-41, "Exploded View"](#).

# ENGINE ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >

[MR16DDT ]

4. Install engine slinger to front cover front left side (A) and cylinder head rear right side (B).

↔ : Engine front


### Slinger bolts

Front cover front left side:

: 32.9 N·m (3.4 kg-m, 24 ft-lb)

Cylinder head rear right side:

: 25.0 N·m (2.6 kg-m, 18 ft-lb)



5. Remove starter motor. Refer to [STR-21, "Exploded View"](#).
6. Lift with a hoist and separate the engine from the transaxle assembly. Refer to [TM-25, "Exploded View"](#).

## INSTALLATION

Note the following, and install in the reverse order of removal.

### CAUTION:


- **Never allow engine oil to get on engine mounting insulator. Be careful not to damage engine mounting insulator.**
- **Check that each mounting insulator is seated properly, and tighten mounting nuts and bolts.**
- **When installation directions are specified, install parts according to the direction marks on them referring to the figure of components. Refer to [EM-59, "2WD : Exploded View"](#).**

Rear torque rod bracket

1. Temporarily tighten mounting bolts in the numerical order as shown in the figure.

↔ : Vehicle front

2. Tighten mounting bolts to the specified torque in the numerical order as shown in the figure.



## 2WD : Inspection

INFOID:000000007577462

## INSPECTION AFTER INSTALLATION

### Inspection for Leakage

The following are procedures for checking fluids leakage, lubricates leakage, and exhaust gases leakage.

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use procedure below to check for fuel leakage.
  - Turn ignition switch "ON" (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
  - Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to check there is no leakage of fuel, exhaust gases, or any oil/fluids including engine oil and engine coolant.
- Bleed air from lines and hoses of applicable lines, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to the specified level, if necessary.

Summary of the inspection items:

Items	Before starting engine	Engine running	After engine stopped
Engine coolant	Level	Leakage	Level
Engine oil	Level	Leakage	Level

# ENGINE ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >

[MR16DDT ]


Transmission / transaxle fluid	AT & CVT Models	Leakage	Level / Leakage	Leakage
	MT Models	Level / Leakage	Leakage	Level / Leakage
Other oils and fluids*		Level	Leakage	Level
Fuel		Leakage	Leakage	Leakage
Exhaust gases		—	Leakage	—

\*: Power steering fluid, brake fluid, etc.

### 4WD (AWD)

### 4WD (AWD) : Exploded View

INFOID:000000007577463



- |                                 |                          |                                   |
|---------------------------------|--------------------------|-----------------------------------|
| 1. Washer                       | 2. Upper torque rod (RH) | 3. Engine mounting insulator (RH) |
| 4. Rear engine mounting bracket | 5. Rear torque rod       | 6. Engine mounting insulator (LH) |

: N·m (kg-m, ft-lb)

: Always replace after every disassembly.

### 4WD (AWD) : Removal and Installation

INFOID:000000007577464

#### **WARNING:**

- Situate the vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.



# ENGINE ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >

[MR16DDT ]

- Attach proper slingers and bolts described in PARTS CATALOG if engine slingers are not equipped.

### CAUTION:

- Always be careful to work safely, avoid forceful or uninstructed operations.
- Never start working until exhaust system and coolant are cool enough.
- If items or work required are not covered by the engine section, refer to the applicable sections.
- Always use the support point specified for lifting.
- Use either 2-pole lift type or separate type lift as best you can. If board-on type is used for unavoidable reasons, support at the rear axle jacking point with a transmission jack or similar tool before starting work, in preparation for the backward shift of center of gravity.
- For supporting points for lifting and jacking point at rear axle, refer to [GI-34, "Garage Jack and Safety Stand and 2-Pole Lift"](#).

### NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

## REMOVAL

### Outline

Remove the engine and the transaxle assembly from the vehicle downward. Separate the engine and the transaxle.

### Preparation

1. Release fuel pressure. Refer to [EC-136, "Work Procedure"](#).
2. Drain engine coolant from radiator. Refer to [CO-8, "Draining"](#).  
**CAUTION:**
  - Perform this step when the engine is cold.
  - Never spill engine coolant on drive belts.
3. Remove the following parts.
  - Engine undercover
  - Front road wheels and tires
  - Front fender protector (RH and LH): Refer to [EXT-21, "Exploded View"](#).
  - Drive belt: Refer to [EM-18, "Removal and Installation"](#).
  - Engine cover: Refer to [EM-24, "Exploded View"](#).
  - Battery and battery tray: Refer to [PG-95, "Exploded View"](#).
  - Air duct, air cleaner case assembly and air cleaner body assembly: Refer to [EM-25, "Exploded View"](#).
  - Radiator hose (upper and lower): Refer to [CO-14, "Exploded View"](#).
  - Radiator cooling fan assembly: Refer to [CO-17, "Exploded View"](#).
  - Exhaust front tube: Refer to [EX-5, "Exploded View"](#).
  - Alternator: Refer to [CHG-22, "Exploded View"](#).

### Engine Room LH

1. Disconnect all connections of engine harness around the battery, and then temporarily secure the engine harness into the engine side.  
**CAUTION:**  
**Protect connectors using a resin bag against foreign materials during the operation.**
2. Disconnect fuel feed hose quick connector. Refer to [EM-46, "Exploded View"](#).
3. Disconnect heater hoses. Refer to [CO-23, "Exploded View"](#).
4. Disconnect control cable from transaxle. Refer to [TM-215, "Exploded View"](#).
5. Remove EVAP hoses. Refer to [EM-27, "Exploded View"](#).

### Engine Room RH


1. Disconnect vacuum hose from intake manifold. Refer to [EM-27, "Exploded View"](#).
2. Remove A/C compressor. Refer to [HA-27, "Exploded View"](#).
3. Remove ground cable at engine side.

### Vehicle Underbody

1. Remove ground cable at transaxle side.
2. Remove rear propeller shaft. Refer to [DLN-125, "Exploded View"](#).
3. Remove drive shafts (RH and LH). Refer to [FAX-18, "Exploded View"](#).
4. Remove rear torque rod (1). Refer to [EM-64, "4WD \(AWD\) : Exploded View"](#).

2 : Rear torque rod bracket

↔ : Vehicle front




5. Remove stabilizer connecting rod. Refer to [FSU-14, "Exploded View"](#).
6. Rear front suspension member. Refer to [FSU-16, "Exploded View"](#).
7. Preparation for the separation work of transaxle is as follows:
  - Remove transaxle joint bolts which pierce at oil pan (upper) lower rear side. Refer to [EM-43, "Exploded View"](#).

### Removal

1. Use a manual lift table caddy (commercial service tool) (A) or equivalently rigid tool such as a transmission jack. Securely support bottom of the engine and the transaxle assembly.


#### **CAUTION:**

**Put a piece of wood or an equivalent as the supporting surface, secure a completely stable condition.**



2. Remove upper torque rod (RH) (1) and engine mounting insulator (RH) (2).

↔ : Vehicle front



3. Remove engine mounting insulator (LH).
4. Carefully lower jack, or raise lift to remove the engine and the transaxle assembly. When performing work, observe the following caution.

#### **CAUTION:**

- Check that no part interferes with the vehicle side.
- Before and during this lifting, always check if any harnesses are left connected.
- During the removal, always be careful to prevent the vehicle from falling off the lift due to changes in the center of gravity.
- If necessary, support the vehicle by setting jack or suitable tool at the rear.

### Separation

1. Remove catalyst convertor. Refer to [EM-34, "AWD : Exploded View"](#).
2. Remove turbocharger. Refer to [EM-37, "Exploded View"](#).
3. Remove exhaust manifold. Refer to [EM-41, "Exploded View"](#).

# ENGINE ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >

[MR16DDT ]

- Install engine slinger to front cover front left side (A) and cylinder head rear right side (B).

↔ : Engine front


### Slinger bolts

Front cover front left side:

: 32.9 N·m (3.4 kg-m, 24 ft-lb)

Cylinder head rear right side:

: 25.0 N·m (2.6 kg-m, 18 ft-lb)



- Remove starter motor. Refer to [STR-21, "Exploded View"](#).
- Lift with a hoist and separate the engine from the transaxle assembly. Refer to [TM-242, "2WD : Exploded View"](#).

## INSTALLATION

Note the following, and install in the reverse order of removal.

### CAUTION:

- Never allow engine oil to get on engine mounting insulator. Be careful not to damage engine mounting insulator.
- Check that each mounting insulator is seated properly, and tighten mounting nuts and bolts.
- When installation directions are specified, install parts according to the direction marks on them referring to the figure of components. Refer to [EM-64, "4WD \(AWD\) : Exploded View"](#).

## 4WD (AWD) : Inspection

INFOID:000000007577465

## INSPECTION AFTER INSTALLATION

### Inspection for Leakage

The following are procedures for checking fluids leakage, lubricates leakage, and exhaust gases leakage.

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use procedure below to check for fuel leakage.
  - Turn ignition switch "ON" (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
  - Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to check there is no leakage of fuel, exhaust gases, or any oil/fluids including engine oil and engine coolant.
- Bleed air from lines and hoses of applicable lines, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to the specified level, if necessary.

Summary of the inspection items:

Items		Before starting engine	Engine running	After engine stopped
Engine coolant		Level	Leakage	Level
Engine oil		Level	Leakage	Level
Transmission / transaxle fluid	AT & CVT Models	Leakage	Level / Leakage	Leakage
	MT Models	Level / Leakage	Leakage	Level / Leakage
Other oils and fluids*		Level	Leakage	Level
Fuel		Leakage	Leakage	Leakage
Exhaust gases		—	Leakage	—

\*: Power steering fluid, brake fluid, etc.

## UNIT DISASSEMBLY AND ASSEMBLY

## ENGINE STAND SETTING

## Setting

INFOID:000000007577466


**NOTE:**

Explained here is how to disassemble with engine stand supporting transaxle surface. When using different type of engine stand, note with difference in steps and etc.

1. Remove the engine and the transaxle assembly from the vehicle, and separate the transaxle from the engine. Refer to [EM-60. "2WD : Removal and Installation"](#) (2WD models) or [EM-64. "4WD \(AWD\) : Removal and Installation"](#) (4WD models).
2. Install engine to engine stand with the following procedure:
  - a. Remove flywheel (M/T models) or drive plate (CVT models).
    - Secure flywheel (M/T models) or drive plate (CVT models) (1) with a stopper plate [SST: KV11105210 (J-44716)] (A), and remove mounting bolts.

**NOTE:**


This figure shows CVT models as an example.



- b. Remove pilot converter (1) (CVT models) or pilot bush (M/T models) using pilot bushing puller [SST: ST16610001 (J-23907)] (A) or suitable tool.

**NOTE:**

This figure shows CVT models as an example.



- c. Lift the engine with a hoist to install it onto widely use engine stand.

**CAUTION:**

- Use the engine stand that has a load capacity [approximately 135 kg (298 lb) or more] large enough for supporting the engine weight.
- If the load capacity of stand is not adequate, remove the following parts beforehand to reduce the potential risk of overturning stand.
  - Intake manifold: Refer to [EM-27. "Exploded View"](#).
  - Catalyst converter: Refer to [EM-32. "2WD : Exploded View"](#) (2WD models) or [EM-34. "AWD : Exploded View"](#) (AWD models).
  - Rocker cover: Refer to [EM-57. "Exploded View"](#).

**NOTE:**

# ENGINE STAND SETTING


[MR16DDT ]

## < UNIT DISASSEMBLY AND ASSEMBLY >

The figure shows an example of widely used engine stand (A) that can support mating surface of transaxle with flywheel (M/T models) or drive plate (CVT models) removed.

**CAUTION:**

**Before removing the hanging chains, check the engine stand is stable and there is no risk of overturning.**



3. Drain engine oil. Refer to [LU-8, "Draining"](#).

**CAUTION:**


**Be sure to clean drain plug and install with new drain plug washer.**

4. Drain engine coolant by removing water drain plug (1) from inside of the engine.

↶ : Engine front

**Tightening torque** : Refer to [EM-111, "Disassembly and Assembly"](#).

**Use Genuine RTV Silicon Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**



A

EM

C

D

E

F

G

H

I

J

K

L

M

N

O

P

---

**ENGINE UNIT****Disassembly**

INFOID:000000007577467

1. Remove intake manifold. Refer to [EM-27, "Exploded View"](#).
2. Remove oil pan (lower). Refer to [EM-106, "Exploded View"](#).
3. Remove ignition coil, spark plug, and rocker cover. Refer to [EM-22, "Exploded View"](#).
4. Remove fuel injector and fuel tube. Refer to [EM-51, "Exploded View"](#).
5. Remove timing chain. Refer to [EM-72, "Exploded View"](#).
6. Remove camshaft. Refer to [EM-84, "Exploded View"](#).
7. Remove water inlet. Refer to [CO-21, "Exploded View"](#).
8. Remove water outlet. Refer to [CO-23, "Exploded View"](#).
9. Remove cylinder head. Refer to [EM-96, "Exploded View"](#).

**Assembly**

INFOID:000000007577468

Assemble in the reverse order of disassembly.

# DRIVE BELT AUTO TENSIONER AND IDLER PULLEY


< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## DRIVE BELT AUTO TENSIONER AND IDLER PULLEY

Exploded View

INFOID:000000007577469



1. Front cover

2. Drive belt auto-tensioner

: N·m (kg-m, ft-lb)

### Removal and Installation

INFOID:000000007577470

#### Removal

1. Loosen mounting bolt and remove drive belt auto-tensioner.

#### Installation

Install in the reverse order of removal.

#### **CAUTION:**

**When installing drive belt auto-tensioner, be careful not to interfere with water pump pulley.**

# TIMING CHAIN


< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## TIMING CHAIN

### Exploded View

INFOID:000000007577471




- |                                                 |                                                |                                    |
|-------------------------------------------------|------------------------------------------------|------------------------------------|
| 1. Timing chain slack guide                     | 2. Timing chain tensioner                      | 3. Timing chain                    |
| 4. Oil pump drive chain                         | 5. Crankshaft sprocket                         | 6. Crankshaft key                  |
| 7. Oil pump sprocket                            | 8. Front cover                                 | 9. O-ring                          |
| 10. O-ring                                      | 11. Valve timing control cover                 | 12. O-ring                         |
| 13. Exhaust valve timing control solenoid valve | 14. Intake valve timing control solenoid valve | 15. Crankshaft pulley bolt         |
| 16. Crankshaft pulley                           | 17. Front oil seal                             | 18. Oil pump drive chain tensioner |
| 19. O-ring                                      | 20. Timing chain tension guide                 | 21. Camshaft sprocket (INT)        |




22. Camshaft sprocket (EXH)                      23. O-ring


Comply with the assembly procedure when tightening.


- A.
- Crankshaft pulley bolt. Refer to [EM-73](#)
  - Camshaft sprocket bolt. Refer to [EM-85](#)


 : N·m (kg-m, ft-lb)

 : N·m (kg-m, in-lb)

 : Always replace after every disassembly.

 : Should be lubricated with oil.

 : Sealing point

 : Indicates that the parts is connected at points with same symbols in actual vehicle.

## Removal and Installation

INFOID:000000007577472


### REMOVAL

#### CAUTION:

The rotating direction in the text indicates all directions seen from the engine front.

1. Drain engine oil. Refer to [LU-8, "Draining"](#).  
**CAUTION:**  
Perform this step when engine is cold.
2. Remove the following parts:
  - Intake manifold: Refer to [EM-27, "Exploded View"](#).
  - Rocker cover: Refer to [EM-22, "Exploded View"](#).
3. Set No. 1 cylinder at TDC on its compression stroke with the following procedure:
  - a. Rotate crankshaft pulley (1) clockwise and align TDC mark (no paint) (B) to timing indicator (A) on front cover.

C : White paint mark (Not use for service)




- b. At the same time, check that the cam noses of the No. 1 cylinder are located (←) as shown in the figure.

1 : Camshaft (INT)

2 : Camshaft (EXH)

← : Engine front

- If not, rotate crankshaft pulley one revolution (360 degrees) and align as shown in the figure.



4. Remove crankshaft pulley with the following procedure:

## TIMING CHAIN


### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


- a. Fix crankshaft pulley (1) with a pulley holder (commercial service tool) (A), loosen crankshaft pulley bolt, and locate bolt seating surface at 10 mm (0.39 in) from its original position.

**CAUTION:**

**Never remove the crankshaft pulley bolt as they will be used as a supporting point for the pulley puller [SST: KV11103000 ( — )].**



- b. Attach a pulley puller [SST: KV11103000 ( — )] (A) in the M6 thread hole on crankshaft pulley (1), and remove crankshaft pulley.




5. Remove oil pan (lower). Refer to [EM-106. "Exploded View"](#).

**NOTE:**

If crankshaft sprocket and oil pump drive component are not removed, this step is unnecessary.

6. Remove intake valve timing control solenoid valve and exhaust valve timing control valve.
7. Remove drive belt auto-tensioner. Refer to [EM-71. "Exploded View"](#).
8. Remove front cover with the following procedure:
  - a. Loosen mounting bolts in reverse order as shown in the figure.



## TIMING CHAIN


### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- b. Cut liquid gasket by prying the position (←) shown in the figure, and then remove the front cover.

**CAUTION:**

- Be careful not to damage the mating surface.
- A more adhesive liquid gasket is applied compared to previous types when shipped, so it should not be forced off the position not specified.



9. Remove front oil seal from front cover.

**CAUTION:**

**Be careful not to damage front cover.**


- Lift up front oil seal using a screwdriver.

10. Remove valve timing control cover, if necessary.

- Loosen mounting bolts in reverse order as shown in the figure.

**NOTE:**

Disregard the numerical order No.1 in removal.




11. Remove timing chain tensioner with the following procedure:

- a. Insert a wire (A) (e.g. clip) into the top groove with the timing chain tensioner plunger pressed.

**NOTE:**

Timing chain tensioner plunger is securely fixed by inserting a wire (e.g. clip).

- b. Remove timing chain tensioner (1).



# TIMING CHAIN

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


12. Remove slack guide (2), tension guide (3) and timing chain (1).

**CAUTION:**

Never rotate each crankshaft and camshaft individually while timing chain is removed. It causes interference between valve and piston.


**NOTE:**

If timing chain is difficult to remove, remove camshaft sprocket (EXH) first to remove timing chain.



13. Remove crankshaft sprocket and oil pump drive component with the following procedure:

- Push oil pump drive chain tensioner (1) in the direction show in the figure.
- Insert a stopper pin (A) into the body hole (B).
- Remove oil pump chain tensioner.
  - When the holes on lever and tensioner body cannot be aligned, align these holes by slightly moving the oil pump chain tensioner slack guide.




- Hold the WAF part of oil pump shaft [WAF: 10 mm (0.39 in)] (A), and then loosen the oil pump sprocket bolt and remove it.

1 : Oil pan (upper)

↔ : Engine front

**CAUTION:**

- Secure the oil pump shaft with the WAF part.
- Never loosen the oil pump sprocket bolt by tightening the oil pump drive chain.



# TIMING CHAIN

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

14. Remove tension guide (front cover side) from front cover, if necessary.

## INSTALLATION


### CAUTION:

**Do not reuse O-rings.**

### NOTE:

The figure shows the relationship between the matching mark on each timing chain and that on the corresponding sprocket, with the components installed.

- 1 : Timing chain
- 2 : Camshaft sprocket (EXH)
- 3 : Slack guide
- 4 : Timing chain tensioner
- 5 : Crankshaft sprocket
- 6 : Oil pump drive chain
- 7 : Oil pump sprocket
- 8 : Oil pump drive chain tensioner
- 9 : Tension guide
- 10 : Camshaft sprocket (INT)
- A : Matching mark (dark blue link)
- B : Matching mark (outer groove)
- C : Crankshaft key position (straight up)
- D : Matching mark (stamping)
- E : Matching mark (white link)
- F : Matching mark (yellow link)
- G : Matching mark (outer groove)



1. Check that crankshaft key points straight up.
2. If the tension guide (front cover side) is removed, install it to the front cover.

### CAUTION:

**Check the joint condition by sound or feeling.**


3. Install crankshaft sprocket (2), oil pump sprocket (3), and oil pump drive chain (1).

- A : Matching mark (stamping)
- B : Matching mark (yellow link)
- C : Matching mark (dark blue link)

- Install it by aligning matching marks on each sprockets and oil pump drive chain.
- If these matching marks are not aligned, rotate the oil pump shaft slightly to correct the position.

### CAUTION:

**Check matching mark position of each sprockets after installing the oil pump drive chain.**



## TIMING CHAIN

### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


4. Hold the WAF part of oil pump shaft [WAF: 10 mm (0.39 in)] (A), and then tighten the oil pump shaft sprocket bolt.

1 : Oil pan (upper)


↔ : Engine front

**CAUTION:**

- Secure the oil pump shaft with the WAF part.
- Never loosen the oil pump shaft sprocket bolt by tightening the oil pump drive chain.



5. Install oil pump chain tensioner (1).
- Fix the face oil pump tensioner at the most compressed position using a stopper pin (A), and then install it.
  - Securely pull out (↔) the stopper pin after installing the oil pump chain tensioner.
  - Check matching mark position of oil pump drive chain and each sprockets again.



# TIMING CHAIN

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


6. Align the matching marks of each sprockets with the matching marks of timing chain.

- 1 : Camshaft sprocket (EXH)
- 2 : Camshaft sprocket (INT)
- 3 : Timing chain
- A : Matching mark (dark blue link)
- B : Matching mark (outer groove)
- C : Matching mark (outer groove)
- D : Matching mark (white link)
- E : Matching mark (stamping)

- If these matching marks are not aligned, rotate the camshaft slightly by holding the hexagonal portion to correct the position.


### CAUTION:

**Check matching mark position of each sprocket and timing chain again after installing the timing chain.**



7. Install the slack guide (2) and the tension guide (3).

- 1 : Timing chain



8. Install timing chain tensioner.

- Fix the plunger at the most compressed position using a stopper pin, and then install it.
- Securely pull out the stopper pin after installing the timing chain tensioner.

### CAUTION:

- After installing tensioner on the cam side, pull out lock pin.
- If plunger pops out after pulling out lock pin without installing the tensioner to the engine, never use the tensioner. (If used, the plunger does not slide smoothly.)
- To reuse tensioner on the cam side:  
After installation, pick up and move ratchet clip toward the tip of the plunger and position the tensioner parallel to the groove of the plunger.

9. Check matching mark position of timing chain and each sprockets again.

10. Install front oil seal. Refer to [EM-94. "FRONT OIL SEAL : Removal and Installation"](#).



## TIMING CHAIN

### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

11. Install front cover with the following procedure:


a. Install valve timing control cover, if removed.

- Apply a continuous bead of liquid gasket (E) with a tube presser (commercial service tool) to valve timing control cover as shown in the figure.

- 1 : Front cover
- 2 : Valve timing control cover
- A : Start and end of gasket application
- B : Liquid gasket application area
- E : Gasket
- c : 4.0 - 5.6 mm (0.157 - 0.220 in)
- d :  $\phi$ 3.4 - 4.4 mm (0.134 - 0.173 in)

**NOTE:**


The start and end of gasket application must overlap 5mm or more one another.



- Tighten mounting bolts in numerical order as shown in the figure.

**NOTE:**

Tighten bolt the No.1 in two step. The numerical order No.6 shows the second step.



b. Install new O-ring to cylinder block.

**CAUTION:**

**Do not reuse O-rings.**



# TIMING CHAIN


## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- c. Apply a continuous bead of liquid gasket (D) with a tube presser (commercial service tool) to front cover as shown in the figure.

- 1 : Cylinder head  
 2 : Front cover  
 A : Liquid gasket application area  
 b : 4.0 - 5.6 mm (0.157 - 0.220 in)  
 c :  $\phi 3.4 - 4.4$  mm (0.134 - 0.173 in)  
 ⇐ : Engine outside

Use Genuine RTV Silicon Sealant or equivalent. Refer to [GL-22, "Recommended Chemical Products and Sealants"](#).



- d. Check that matching marks of timing chain and each sprockets are still aligned. Then install front cover.

**CAUTION:**

- Check O-ring on cylinder block is correctly installed.
- Be careful not to damage front oil seal by interference with front end of crankshaft.

- e. Install front cover, and tighten mounting bolts in numerical order as shown in the figure.

- Refer to the following for the installation position of bolts.

- M6 bolt : No. 1  
 M10 bolts : No. 6, 7, 10, 13, 21  
 M12 bolts : No. 2, 4, 8, 11  
 M8 bolts : Except the above


**CAUTION:**

Attaching should be done within 5 minutes after liquid gasket application.

- f. After all bolts are tightened, retighten them to specified torque in numerical order as shown in the figure.

**CAUTION:**

Be sure to wipe off any excessive liquid gasket leaking.



12. Install crankshaft pulley with the following procedure:

- a. When inserting crankshaft pulley with a plastic hammer, tap on its center portion (not circumference).

**CAUTION:**

Never damage front oil seal lip section.


## TIMING CHAIN

### < UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT]

- b. Secure crankshaft pulley (1) with a pulley holder (commercial service tool) (A).
- c. Apply new engine oil to thread and seat surfaces of crankshaft pulley bolt.
- d. Tighten crankshaft pulley bolt.

 : 29.4 N·m (3.0 kg·m, 22 ft·lb)



- e. Put a paint mark (B) on crankshaft pulley (2), matching with any one of six easy to recognize angle marks (A) on crankshaft pulley bolt (1) flange.
- f. Turn another 60 degrees clockwise (angle tightening).
  - Check the tightening angle with movement of one angle mark.
- g. Check that crankshaft rotates clockwise smoothly.



13. Install remaining parts in the reverse order of removal.


### Inspection

INFOID:000000007577473

### INSPECTION AFTER REMOVAL

#### Timing Chain

Check for cracks (A) and any excessive wear (B) at link plates and roller links of timing chain. Replace timing chain if necessary.



### INSPECTION AFTER INSTALLATION

#### Inspection for Leakage

The following are procedures for checking fluids leakage, lubricates leakage, and exhaust gases leakage.

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use procedure below to check for fuel leakage.
  - Turn ignition switch "ON" (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
  - Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.

#### NOTE:

If hydraulic pressure inside chain tensioner drops after removal/installation, slack in guide may generate a pounding noise during and just after the engine start. However, this does not indicate an unusualness. Noise will stop after hydraulic pressure rises.

- Warm up engine thoroughly to check there is no leakage of fuel, or any oil/fluids including engine oil and engine coolant.
- Bleed air from lines and hoses of applicable lines, such as in cooling system.

## TIMING CHAIN

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to the specified level, if necessary.

A

Summary of the inspection items:

Items		Before starting engine	Engine running	After engine stopped
Engine coolant		Level	Leakage	Level
Engine oil		Level	Leakage	Level
Transmission / transaxle fluid	AT & CVT Models	Leakage	Level / Leakage	Leakage
	MT Models	Level / Leakage	Leakage	Level / Leakage
Other oils and fluids*		Level	Leakage	Level
Fuel		Leakage	Leakage	Leakage
Exhaust gases		—	Leakage	—

EM

C

D

E

F

G

H

I

J

K

L

M

N

O

P

\*: Power steering fluid, brake fluid, etc.

# CAMSHAFT


< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## CAMSHAFT

### Exploded View

INFOID:000000007577474



- |                                                 |                            |                            |
|-------------------------------------------------|----------------------------|----------------------------|
| 1. Exhaust valve timing control position sensor | 2. O-ring                  | 3. Camshaft bracket        |
| 4. Camshaft (EXH)                               | 5. Camshaft sprocket (EXH) | 6. Camshaft sprocket (INT) |
| 7. Camshaft (INT)                               | 8. Valve lifter (EXH)      | 9. Valve lifter (INT)      |
| 10. Signal plate (INT)                          | 11. Signal plate (EXH)     | 12. O-ring                 |
| 13. Camshaft position sensor (PHASE)            |                            |                            |

A. Comply with the assembly procedure when tightening. Refer to [EM-85](#)

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

: Should be lubricated with oil.

: Sealing point

★ : Select with proper thickness.

## Removal and Installation

INFOID:000000007577475

### CAUTION:

The rotating direction in the text indicates all directions seen from the engine front.

### REMOVAL

1. Remove the following parts.

- Intake manifold: Refer to [EM-27, "Exploded View"](#).
- Rocker cover: Refer to [EM-22, "Exploded View"](#).
- Front cover and timing chain related parts: Refer to [EM-72, "Exploded View"](#).

#### NOTE:

Removal of oil pump drive related part is not necessary.

2. Remove camshaft position sensor (PHASE) and exhaust valve timing control position sensor from camshaft bracket.


#### CAUTION:

- Handle camshaft position sensor (PHASE) and exhaust valve timing control position sensor carefully and avoid impacts.
- Never disassemble camshaft position sensor (PHASE) and exhaust valve timing control position sensor.
- Never place sensor where it is exposed to magnetism.

3. Put the matching mark (A) on the camshaft sprocket (INT) (2), camshaft sprocket (EXH) (3) and the camshaft bracket (1) as shown in the figure.

#### NOTE:

It prevents the knock pin of the camshaft (INT) from engaging with the incorrect pin hole when installing the camshaft sprocket (INT).



4. Remove camshaft sprockets (INT and EXH).


- Secure hexagonal part (A) of camshaft with a wrench. Loosen camshaft sprocket mounting bolts and remove camshaft sprocket.

1 : Camshaft sprocket (INT)

2 : Camshaft sprocket (EXH)

#### CAUTION:


- Never rotate crankshaft or camshaft while timing chain is removed. It causes interference between valve and piston.
- Never loosen the mounting bolts with securing anything other than the camshaft hexagonal part or with tensioning the timing chain.



5. Remove camshaft bracket with the following procedure:

- a. Loosen mounting bolts in reverse order as shown in the figure.

← : Engine front



# CAMSHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT ]

- b. Cut liquid gasket by prying the position (↖) shown in the figure, and then remove the camshaft bracket.

↖ : Engine front

### CAUTION:

- Never damage the mating surface.
- A more adhesive liquid gasket is applied compared to previous types when shipped, so it should not be forced off the position not specified.



- Remove camshafts.
- Remove valve lifters.
  - Identify installation positions, and store them without mixing them up.
- Remove signal plate from camshaft, if necessary.

## INSTALLATION


### CAUTION:

**Do not reuse O-rings.**

- Install valve lifters.
  - Install them in the original positions.
- Install camshafts.
  - Clean camshaft journal to remove any foreign material.
  - Distinguish between the intake and the exhaust by looking at the different shapes of the front and rear ends of the camshaft or using the identification colors (A) and (B).

- 1 : Camshaft (EXH)  
2 : Camshaft (INT)

Identification color	A	B
Camshaft (EXH)	—	Light blue
Camshaft (INT)	Light blue	—




- Install camshafts so that camshaft dowel pins (A) on the front side are positioned as shown in the figure.

- 1 : Camshaft (EXH)  
2 : Camshaft (INT)

### NOTE:

Though camshaft does not stop at the positions as shown in the figure, for the placement of cam nose, it is generally accepted camshaft is placed for the same direction of the figure.





- Install camshaft bracket with the following procedure:
  - Remove foreign material completely from camshaft bracket backside and from cylinder head installation face.

# CAMSHAFT


## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


- b. Apply liquid gasket (A) to camshaft bracket as shown in the figure.

- b : 4.0 - 5.6 mm (0.157 - 0.220 in)  
 c :  $\phi$  3.4 - 4.4mm (0.134 - 0.173 in)  
 : Engine front  
 : Engine outside

Use Genuine RTV silicon sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).




- c. Tighten mounting bolts of camshaft brackets in the following steps, in numerical order as shown in the figure.

 : Engine front

- There are two types of mounting bolts. Refer to the following for locating bolts.

**M6 bolts [thread length: 57.5 mm (2.264 in)]**  
 : 13, 14, and 15 in the figure

**M6 bolts [thread length: 35.0 mm (1.378 in)]**  
 : Except the above



- i. Tighten mounting bolts in numerical order.

: **1.96 N·m (0.20 kg-m, 17 in-lb)**

- ii. Tighten mounting bolts in numerical order.

: **5.88 N·m (0.60 kg-m, 52 in-lb)**

- iii. Tighten mounting bolts in numerical order.

: **9.5 N·m (0.97 kg-m, 84 in-lb)**

### CAUTION:

After tightening mounting bolts of camshaft brackets, be sure to wipe off excessive liquid gasket from the mating surface of cylinder head.

4. Install the camshaft sprocket to the camshaft with the following procedure.


# CAMSHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- a. When the camshaft sprocket (INT) (2) and camshaft sprocket (EXH) (3) is removed, refer to the paint mark (A) put according to step "3". Securely align the knock pin and the pin hole, and then install them.

1 : Camshaft bracket



- b. Tighten bolts in the following steps.
- Secure the hexagonal part of camshaft using wrench to tighten mounting bolt.
- i. Tighten camshaft mounting bolt.

: 35.0 N·m (3.6 kg-m, 26 ft-lb)


- ii. Turn 30 degrees clockwise (angle tightening).

**CAUTION:**

**Check the tightening angle by using an angle wrench [SST: KV10112100 (BT8653-A)] (B) or protractor. Never judge by visual inspection without an angle wrench.**

1 : Camshaft sprocket

A : Camshaft hexagonal part



5. Install timing chain and related parts. Refer to [EM-72, "Exploded View"](#).
6. Inspect and adjust valve clearance. Refer to [EM-12, "Inspection and Adjustment"](#).
7. Install remaining parts in the reverse order of removal.

## Inspection

INFOID:000000007577476

### INSPECTION AFTER REMOVAL

#### Camshaft Runout

1. Put V-block on a precise flat table, and support No. 2 and 5 journal of camshaft.


**CAUTION:**

**Never support No. 1 journal (on the side of camshaft sprocket) because it has a different diameter from the other four locations.**

2. Set dial indicator (A) vertically to No. 3 journal.
3. Turn camshaft to one direction with hands, and measure the camshaft runout on dial indicator. (Total indicator reading)

**Standard and Limit : Refer to [EM-136, "Camshaft"](#).**

4. If it exceeds the limit, replace camshaft.



#### Camshaft Cam Height




# CAMSHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

1. Measure the camshaft cam height with a micrometer (A).

**Standard and Limit** : Refer to [EM-136, "Camshaft"](#).




2. If it exceeds the limit, replace camshaft.

Camshaft Journal Oil Clearance

### CAMSHAFT JOURNAL OUTER DIAMETER

Measure the outer diameter of camshaft journal with a micrometer (A).

**Standard** : Refer to [EM-136, "Camshaft"](#).




### CAMSHAFT BRACKET INNER DIAMETER

- Tighten camshaft bracket bolts with specified torque. Refer to [EM-85, "Removal and Installation"](#).
- Measure the inner diameter of camshaft bracket with a bore gauge (A).

B : Measuring direction of inner diameter

**Standard** : Refer to [EM-136, "Camshaft"](#).



### CAMSHAFT JOURNAL OIL CLEARANCE

- (Oil clearance) = (Camshaft bracket inner diameter) – (Camshaft journal diameter)

**Standard and Limit** : Refer to [EM-136, "Camshaft"](#).

- If it exceeds the limit, replace camshaft or cylinder head, or both.

#### NOTE:

Camshaft bracket cannot be replaced as a single part, because it is machined together with cylinder head. Replace whole cylinder head assembly.

Camshaft End Play

1. Install camshaft in cylinder head. Refer to [EM-85, "Removal and Installation"](#).


# CAMSHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

2. Install dial indicator in thrust direction on front end of camshaft. Read the end play of dial indicator (A) when camshaft is moved forward/backward (in direction to axis).

**Standard and Limit** : Refer to [EM-136, "Camshaft"](#).




- Measure the following parts if out of the standard.
- Dimension (A) for groove of cylinder head No. 1 journal

**Standard** : 4.000 - 4.030 mm (0.1575 - 0.1587 in)

- Dimension (B) for camshaft flange

**Standard** : 3.877 - 3.925 mm (0.1526 - 0.1545 in)

- Refer to the standards above, and then replace camshaft and/or cylinder head.



### Camshaft Sprocket Runout

1. Put V-block on precise flat table, and support No. 2 and 5 journals of camshaft.


#### **CAUTION:**

**Never support No. 1 journal (on the side of camshaft sprocket) because it has a different diameter from the other four locations.**

2. Measure the camshaft sprocket runout with a dial indicator (A). (Total indicator reading)

**Limit** : Refer to [EM-136, "Camshaft"](#).


- If it exceeds the limit, replace camshaft sprocket.



### Valve Lifter

Check if surface of valve lifter has any wear or cracks.

- If anything above is found, replace valve lifter. Refer to [EM-136, "Camshaft"](#).



### Valve Lifter Clearance

#### VALVE LIFTER OUTER DIAMETER


# CAMSHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Measure the outer diameter of valve lifter with a micrometer (A).

**Standard** : Refer to [EM-136, "Camshaft"](#).



### VALVE LIFTER HOLE DIAMETER

Measure the inner diameter of valve lifter hole of cylinder head with an inside micrometer (A).


**Standard** : Refer to [EM-136, "Camshaft"](#).

### VALVE LIFTER CLEARANCE

- (Valve lifter clearance) = (Valve lifter hole diameter) – (Valve lifter outer diameter)

**Standard** : Refer to [EM-136, "Camshaft"](#).

- If out of the standard, referring to the each standard of valve lifter outer diameter and valve lifter hole diameter, replace either or both valve lifter and cylinder head.



### INSPECTION AFTER INSTALLATION

Inspection of Camshaft Sprocket (INT), (EXH) Oil Groove

#### CAUTION:

- **Perform this inspection only when DTC P0011 or P0014 is detected in self-diagnostic results of CONSULT and it is directed according to inspection procedure of EC section. Refer to [EC-165, "Diagnosis Procedure"](#) (P0011) or [EC-168, "Diagnosis Procedure"](#) (P0014).**

- **Check when engine is cold so as to prevent burns by the splashing engine oil.**

1. Check engine oil level. Refer to [LU-7, "Inspection"](#).
2. Perform the following procedure so as to prevent the engine from being unintentionally started while checking.
  - a. Release the fuel pressure. Refer to [EC-136, "Work Procedure"](#).
  - b. Remove intake manifold. Refer to [EM-27, "Exploded View"](#).
  - c. Disconnect ignition coil and injector harness connectors.
  - d. Support the bottom surface of engine using a transmission jack, and then remove the engine mounting bracket (RH) and engine mounting insulator (RH). Refer to [EM-59, "2WD : Exploded View"](#) (M/T models) or [EM-64, "4WD \(AWD\) : Exploded View"](#) (CVT models).
3. Remove intake or exhaust valve timing control solenoid valve. Refer to [EM-72, "Exploded View"](#).
  - Lift the front side of the engine with a jack base to remove intake or exhaust valve timing control solenoid valve.
4. Clean the mounting area of intake or exhaust valve timing control solenoid valve, and then insert a clean waste with no oil adhesion into the oil hole of the cylinder head.
5. Install engine mounting insulator (RH) and engine mounting bracket (RH). (After the removal of intake or exhaust valve timing control solenoid valve and insertion of a waste into the oil hole.)
6. Perform cranking to check that engine oil comes out from the oil hole (mounting hole of intake or exhaust valve timing control solenoid valve) of cylinder head.
  - Regarding the engine oil check, judge it by the amount of oil adhered to the waste inserted into the oil hole.

#### WARNING:

- **Never insert fingers into the oil hole.**
- **Be careful not to touch rotating parts (drive belt, idler pulleys and crankshaft pulley, etc.).**

**CAUTION:**

- Never perform cranking without installing the engine mounting insulator (RH) and engine mounting bracket (RH).
  - Prevent splashing by using a shop cloth so as to prevent the worker from injury from engine oil and so as to prevent engine oil contamination.
  - Prevent splashing by using a shop cloth so as to prevent engine oil from being splashed to engine and vehicle. Especially, be careful not to apply engine oil to rubber parts of drive belt, engine mounting insulator, etc. Wipe engine oil off immediately if it is splashed.
7. Perform the following inspection if engine oil does not come out from intake or exhaust valve timing control solenoid valve oil hole of the cylinder head.
    - Clean oil groove between oil strainer and intake or exhaust valve timing control solenoid valve. Refer to [LU-6, "Engine Lubrication System"](#) and [LU-6, "Engine Lubrication System Schematic"](#).
  8. Remove components between intake valve timing control solenoid valve and camshaft sprocket (INT) or exhaust valve control solenoid valve and camshaft sprocket (EXH), and then check each oil groove for clogging.
    - Clean oil groove if necessary. Refer to [LU-6, "Engine Lubrication System"](#) and [LU-6, "Engine Lubrication System Schematic"](#).
  9. After inspection, install removed parts in the reverse order.

## OIL SEAL

## VALVE OIL SEAL

## VALVE OIL SEAL : Removal and Installation

INFOID:000000007577477

EM


## REMOVAL

1. Remove camshafts. Refer to [EM-84. "Exploded View"](#).
2. Remove valve lifters. Refer to [EM-84. "Exploded View"](#).
3. Rotate crankshaft, and set piston whose valve oil seal is to be removed to TDC. This will prevent valve from dropping into cylinder.

**CAUTION:**

**When rotating crankshaft, be careful to avoid scarring front cover with timing chain.**


4. Remove valve collet.
  - Compress valve spring with the valve spring compressor [SST: KV10116200 (J-26336-A)] (A), the attachment [SST: KV10115900 (J-26336-20)] (C), and the adapter [SST: KV10109220 ( — )] (B). Remove valve collet with magnet hand.

**CAUTION:**

- Be careful not to damage valve lifter holes.
- Fit the attachment [SST: KV10115900 (J-26336-20)] in the center of valve spring retainer to press it.

1 : Valve spring retainer

A : Attachment




5. Remove valve spring retainer and valve spring (with valve spring seat).

**CAUTION:**

**Never remove valve spring seat from valve spring.**

6. Remove valve oil seal with the valve oil seal puller [SST: KV10107902 (J-38959)] (A).



## INSTALLATION

1. Apply new engine oil to valve oil seal joint surface and seal lip.


## OIL SEAL

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Press in valve oil seal to the height (H) shown in the figure with the valve oil seal drift [SST: KV10115600 (J-38958)] (A).

**Height (H) : 15.1 - 15.7 mm (0.594 - 0.618 in)**



- Install in the reverse order of removal, for the rest of parts.

## FRONT OIL SEAL

### FRONT OIL SEAL : Removal and Installation

INFOID:000000007577478

#### REMOVAL

- Remove the following parts.
  - Front fender protector (RH): Refer to [EXT-21, "Exploded View"](#).
  - Drive belt: Refer to [EM-18, "Exploded View"](#).
  - Crankshaft pulley: Refer to [EM-72, "Exploded View"](#).
- Remove front oil seal with a suitable tool.


#### **CAUTION:**

**Be careful not to damage front cover and crankshaft.**

#### INSTALLATION

- Apply new engine oil to new front oil seal joint surface and seal lip.
- Install front oil seal so that each seal lip is oriented as shown in the figure.

- A : Dust seal lip  
B : Oil seal lip  
⇐ : Engine outside  
➡ : Engine inside



- Press-fit front oil seal using a suitable drift with outer diameter 57 mm (2.24 in) and inner diameter 45 mm (1.77 in).

**Within 0.3 mm (0.012 in) toward engine front (crankshaft pulley side)**

**Within 0.5 mm (0.020 in) toward engine rear (crankshaft sprocket side)**

#### **CAUTION:**

- Be careful not to damage front cover and crankshaft.**
- Press-fit oil seal straight to avoid causing burrs or tilting.**

- Install in the reverse order of removal, for the rest of parts.

## REAR OIL SEAL

### REAR OIL SEAL : Removal and Installation

INFOID:000000007577479

#### REMOVAL

# OIL SEAL

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

1. Remove transaxle assembly. Refer to [TM-242, "2WD : Exploded View"](#) (CVT / 2WD models) or [TM-246, "AWD : Exploded View"](#) (CVT / AWD models) or [TM-25, "Exploded View"](#) (M/T models).
2. Remove clutch cover and clutch disk (M/T models). Refer to [EM-110, "Exploded View"](#).
3. Remove drive plate (CVT models) or flywheel (M/T models). Refer to [EM-110, "Exploded View"](#).
4. Remove rear oil seal with a suitable tool.


### CAUTION:

**Be careful not to damage crankshaft and cylinder block.**

## INSTALLATION

1. Apply the liquid gasket lightly to entire outside area of new rear oil seal.  
**Use Genuine RTV silicon sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**
2. Install rear oil seal so that each seal lip is oriented as shown in the figure.


- A : Dust seal lip  
B : Oil seal lip  
⇐ : Engine outside  
➡ : Engine inside



- Press-fit rear oil seal with a suitable drift (A) outer diameter 115 mm (4.53 in) and inner diameter 90 mm (3.54 in).


### CAUTION:

- **Be careful not to damage crankshaft and cylinder block.**
- **Press-fit oil seal straight to avoid causing burrs or tilting.**
- **Never touch grease applied onto oil seal lip.**



- Press in rear oil seal (1) to the position as shown in the figure.

- A : Rear end surface of cylinder block



3. Install in the reverse order of removal, for the rest of parts.

# CYLINDER HEAD

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## CYLINDER HEAD

### Exploded View


INFOID:000000007577480

#### CAUTION:

Read PRECAUTION carefully.

The exhaust valve contains metallic sodium. Therefore, extreme caution must be taken when handling and disposing of the exhaust valve. Refer to [EM-4, "Special Cautions to Ensure the Safe Disposal of Sodium-filled Exhaust Valves"](#).

#### REMOVAL



1. Cylinder head assembly
2. Cylinder head bolt
3. Cylinder head gasket

A. Comply with the assembly procedure when tightening. Refer to [EM-97](#).



: N·m (kg-m, ft-lb)



: Always replace after every disassembly.



: Should be lubricated with oil.


#### DISASSEMBLY



# CYLINDER HEAD

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]



- |                      |                          |                       |
|----------------------|--------------------------|-----------------------|
| 1. Valve collet      | 2. Valve spring retainer | 3. Valve spring (EXH) |
| 4. valve spring seat | 5. Valve oil seal        | 6. Valve guide (EXH)  |
| 7. Valve seat (EXH)  | 8. Valve (EXH)           | 9. Valve (INT)        |
| 10. Valve seat (INT) | 11. Cylinder head        | 12. Valve guide (INT) |
| 13. Spark plug       | 14. Valve spring (INT)   |                       |

Replacement must be following the  
A. disassembly and assembly procedure. Refer to [EM-98](#)

: N·m (kg-m, ft-lb)

: Always replace after every disassembly.

: Should be lubricated with oil.

## Removal and Installation

INFOID:000000007577481

### REMOVAL

#### CAUTION:

Read PRECAUTION carefully.

The exhaust valve contains metallic sodium. Therefore, extreme caution must be taken when handling and disposing of the exhaust valve. Refer to [EM-4, "Special Cautions to Ensure the Safe Disposal of Sodium-filled Exhaust Valves"](#).


- Remove the following components and related parts.
  - Exhaust manifold: Refer to [EM-41, "Exploded View"](#).
  - Intake manifold: Refer to [EM-27, "Exploded View"](#).
  - Fuel injector and fuel tube assembly: Refer to [EM-51, "Exploded View"](#).
  - Water outlet: Refer to [CO-23, "Exploded View"](#).
  - Rocker cover: Refer to [EM-22, "Exploded View"](#).
  - Front cover, timing chain: Refer to [EM-72, "Exploded View"](#).

# CYLINDER HEAD

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Camshaft: Refer to [EM-84, "Exploded View"](#).
2. Remove cylinder head.
    - Loosen cylinder head bolts in reverse order as shown in the figure.
- ⇐ : Engine front
- Using TORX socket, loosen cylinder head bolts.



3. Remove cylinder head gasket.

## INSTALLATION


1. Install cylinder head gasket.
2. Install cylinder head, and tighten cylinder head bolts in numerical order as shown in the figure with the following procedure.

⇐ : Engine front

### CAUTION:

If cylinder head bolts are reused, check their outer diameters before installation. Refer to [EM-103, "Inspection"](#).

- a. Apply new engine oil to threads and seating surface of mounting bolts.
- b. Tighten all cylinder head bolts.



: 40.0 N·m (4.1 kg-m, 30 ft-lb)

- c. Turn all cylinder head bolts 100 degrees clockwise (angle tightening).

### CAUTION:

Check and confirm the tightening angle by using an angle wrench [SST: KV10112100 (BT8653-A)] (A) or protractor. Never judge by visual inspection without the tool.

- d. Completely loosen.

: 0 N·m (0 kg-m, 0 ft-lb)


### CAUTION:

In this step, loosen cylinder head bolts in reverse order that indicated in the figure.

- e. Tighten all cylinder head bolts.

: 40.0 N·m (4.1 kg-m, 30 ft-lb)

- f. Turn all cylinder head bolts 95 degrees clockwise (angle tightening).
  - g. Turn all cylinder head bolts 95 degrees clockwise again (angle tightening).
3. Install in the reverse order of removal, for the rest of parts.



## Disassembly and Assembly

INFOID:000000007577482

## DISASSEMBLY


1. Remove spark plug with spark plug wrench (commercial service tool).
2. Remove valve lifter.
  - Identify installation positions, and store them without mixing them up.

## CYLINDER HEAD

### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


3. Remove valve collet.
  - Compress valve spring with the valve spring compressor [SST: KV10116200 (J-26336-A)] (A), the attachment [SST: KV10115900 (J-26336-20)] (C), and the adapter [SST: KV10109220 ( — )] (B). Remove valve collet with a magnet hand.



#### CAUTION:

- Be careful not to damage valve lifter holes.
- Fit the attachment [SST: KV10115900 (J-26336-20)] in the center of valve spring retainer to press it.

- 1 : Valve spring retainer  
A : Attachment




4. Remove valve spring retainer and valve spring (with valve spring seat).

#### CAUTION:

**Never remove valve spring seat from valve spring.**

5. Push valve stem to combustion chamber side, and remove valve.
  - Identify installation positions, and store them without mixing them up.
6. Remove valve oil seal with a valve oil seal puller [SST: KV10107902 (J-38959)] (A).



7. When valve seat must be replaced.
  - Bore out old seat until it collapses. Boring should not continue beyond the bottom face of the seat recess in cylinder head. Set the machine depth stop to ensure this. Refer to [EM-138, "Cylinder Head"](#).
8. When valve guide must be replaced.

#### CAUTION:


**Never bore excessively to prevent cylinder head from scratching.**

## CYLINDER HEAD

### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


- a. To remove valve guide, heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil (A).



- b. Drive out valve guide with a hammer and valve guide drift (commercial service tool).

**CAUTION:**

**Cylinder head contains heat, wear protective equipment to avoid getting burned.**



### ASSEMBLY

1. When valve guide is removed, install it.


**CAUTION:**

**Replace with oversize [0.2 mm (0.008 in)] valve guide.**


- a. Ream cylinder head valve guide hole with a valve guide reamer (commercial service tool) (A).

**For service parts: Oversize [0.2 mm (0.008 in)]**

**Refer to [EM-138, "Cylinder Head"](#).**



- b. Heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil (A).



# CYLINDER HEAD

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


- c. Press valve guide (1) from camshaft side to dimensions as shown in the figure.

2 : Cylinder head

**Projection (H)** : Refer to [EM-138, "Cylinder Head"](#).


**CAUTION:**

Cylinder head contains heat, wear protective equipment to avoid getting burned.



- d. Apply reamer finish to valve guide with a valve guide reamer (commercial service tool) (A).

**Standard** : Refer to [EM-138, "Cylinder Head"](#).



2. When valve seat is removed, install it.

**CAUTION:**


**Replace with oversize [0.5 mm (0.020 in)] valve seat.**

- a. Ream cylinder head (1) recess diameter for service valve seat (2).


**For service parts: Oversize [0.5 mm (0.020 in)]**

**Refer to [EM-138, "Cylinder Head"](#).**

- Be sure to ream in circles concentric to the valve guide center. This will enable valve seat to fit correctly.



- b. Heat cylinder head to 110 to 130°C (230 to 266°F) by soaking in heated oil (A).



- c. Provide valve seats cooled well with dry ice. Press-fit valve seat into cylinder head.

**CAUTION:**

- **Never touch cold valve seats directly.**
- **Cylinder head contains heat, wear protective equipment to avoid getting burned.**

# CYLINDER HEAD


## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- d. Using valve seat cutter set (commercial service tool) or valve seat grinder, finish valve seat to the specified dimensions. For dimensions, refer to [EM-138, "Cylinder Head"](#).

### CAUTION:

When using valve seat cutter, firmly grip the cutter handle with both hands. Then, press on the contacting surface all around the circumference to cut in a single drive. Improper pressure on with the cutter or cutting many different times may result in stage valve seat.




- e. Using compound, grind to adjust valve fitting.
- f. Check again for normal contact. Refer to [EM-103, "Inspection"](#).
3. Install valve oil seal.
  - Install with a valve oil seal drift [SST: KV10115600 (J-38958)] (A) to match dimension in the figure.

### NOTE:

Dimension is height that measured before installing valve spring (with valve spring seat).

**Height (H) : 15.1 - 15.7 mm (0.594 - 0.618 in)**




4. Install valve.
  - Install larger diameter to intake side.
5. Install valve spring (with valve spring seat).
  - Install smaller pitch (valve spring seat side) to cylinder head side (B).

1 : Valve spring seat (Do not remove from valve spring.)

- Confirm identification color (A) of valve spring.

**Intake : White**

**Exhaust : Yellow green**



6. Install valve spring retainer.


7. Install valve collet.

- Compress valve spring with the valve spring compressor [SST: KV10116200 (J-26336-A)] (A), the attachment [SST: KV10115900 (J-26336-20)] (C), and the adapter [SST: KV10109220 ( — )] (B). Install valve collet with a magnet hand.

### CAUTION:

When working care not to damage valve lifter holes.

- Tap valve stem edge lightly with a plastic hammer after installation to check its installed condition.



8. Install valve lifter.

- Install it in the original position.

9. Install spark plug with spark plug wrench (commercial service tool).

# CYLINDER HEAD

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## Inspection

INFOID:000000007577483


### INSPECTION AFTER REMOVAL

#### Cylinder Head Bolts Outer Diameter

- Cylinder head bolts are tightened by plastic zone tightening method. Whenever the size difference between (d1) and (d2) exceeds the limit, replace them with a new one.

**Limit [(d1) – (d2)]: 0.15 mm (0.0059 in)**

- If reduction of outer diameter appears in a position other than (d2), use it as (d2) point.



#### Cylinder Head Distortion

##### NOTE:

When performing this inspection, cylinder block distortion should be also checked. Refer to [EM-119. "Inspection"](#).

1. Wipe off engine oil and remove water scale (like deposit), gasket, sealant, carbon, etc. with a scraper.


##### CAUTION:

**Never allow gasket debris to enter passages for engine oil or water.**

2. At each of several locations on bottom surface of cylinder head, measure the distortion in six directions using straightedge (A) and feeler gauge (B).

**Limit: Refer to [EM-138. "Cylinder Head"](#).**

- If it exceeds the limit, replace cylinder head.



### INSPECTION AFTER DISASSEMBLY

#### VALVE DIMENSIONS

- Check the dimensions of each valve. For the dimensions, refer to [EM-138. "Cylinder Head"](#).
- If dimensions are out of the standard, replace valve and check valve seat contact. Refer to "VALVE SEAT CONTACT".

#### VALVE GUIDE CLEARANCE

##### Valve Stem Diameter

- Measure the diameter of valve stem with micrometer (A).

**Standard: Refer to [EM-138. "Cylinder Head"](#).**

##### Valve Guide Inner Diameter


- Measure the inner diameter of valve guide with bore gauge.

**Standard: Refer to [EM-138. "Cylinder Head"](#).**

##### Valve Guide Clearance

- (Valve guide clearance) = (Valve guide inner diameter) – (Valve stem diameter)

**Standard and Limit: Refer to [EM-138. "Cylinder Head"](#).**





# CYLINDER HEAD

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


- If the calculated value exceeds the limit, replace valve and/or valve guide. When valve guide must be replaced. Refer to [EM-98, "Disassembly and Assembly"](#).

### VALVE SEAT CONTACT

- After confirming that the dimensions of valve guides and valves are within the specifications, perform this procedure.
- Apply prussian blue (or white lead) onto contacting surface of valve seat to check the condition of the valve contact on the surface.
- Check if the contact area band is continuous all around the circumference.

A : OK

- If not, grind to adjust valve fitting and check again. If the contacting surface still has "NG" conditions (B) even after the recheck, replace valve seat. Refer to [EM-98, "Disassembly and Assembly"](#).



JPBIA0187ZZ


### VALVE SPRING SQUARENESS

- Set a try square (A) along the side of valve spring and rotate spring. Measure the maximum clearance between the top of spring and try square.

B : Contact

**Limit** : Refer to [EM-138, "Cylinder Head"](#).

- If it exceeds the limit, replace valve spring.



JPBIA4391ZZ

### VALVE SPRING DIMENSIONS AND VALVE SPRING PRESSURE LOAD


- Check valve spring pressure with valve spring seat installed at the specified spring height.

#### **CAUTION:**

**Never remove valve spring seat from valve spring.**

**Standard** : Refer to [EM-138, "Cylinder Head"](#).

- If the installation load or load with valve open is out of the standard, replace valve spring (with valve spring seat).



SEM113

## INSPECTION AFTER INSTALLATION

### Inspection for Leakage

The following are procedures for checking fluids leakage, lubricates leakage, and exhaust gases leakage.

- Before starting engine, check oil/fluid levels including engine coolant and engine oil. If less than required quantity, fill to the specified level. Refer to [MA-10, "Fluids and Lubricants"](#).
- Use procedure below to check for fuel leakage.
  - Turn ignition switch "ON" (with engine stopped). With fuel pressure applied to fuel piping, check for fuel leakage at connection points.
  - Start engine. With engine speed increased, check again for fuel leakage at connection points.
- Run engine to check for unusual noise and vibration.
- Warm up engine thoroughly to check there is no leakage of fuel, exhaust gases, or any oil/fluids including engine oil and engine coolant.
- Bleed air from lines and hoses of applicable lines, such as in cooling system.
- After cooling down engine, again check oil/fluid levels including engine oil and engine coolant. Refill to the specified level, if necessary.



# CYLINDER HEAD

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

Summary of the inspection items:				
Items		Before starting engine	Engine running	After engine stopped
Engine coolant		Level	Leakage	Level
Engine oil		Level	Leakage	Level
Transmission / transaxle fluid	AT & CVT Models	Leakage	Level / Leakage	Leakage
	MT Models	Level / Leakage	Leakage	Level / Leakage
Other oils and fluids*		Level	Leakage	Level
Fuel		Leakage	Leakage	Leakage
Exhaust gases		—	Leakage	—


\*: Power steering fluid, brake fluid, etc.

A  
EM  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

[MR16DDT]

## Exploded View

INFOID:0000000007577484




- |                                |                      |                             |
|--------------------------------|----------------------|-----------------------------|
| 1. O-ring                      | 2. Oil pan (upper)   | 3. Oil level gauge guide    |
| 4. O-ring                      | 5. Oil level gauge   | 6. Oil pump drive chain     |
| 7. Crankshaft sprocket         | 8. Oil pump sprocket | 9. Oil pump chain tensioner |
| 10. Oil pump                   | 11. Drain plug       | 12. Drain plug washer       |
| 13. Oil pan (lower)            | 14. Oil filter       | 15. Connector bolt          |
| 16. Clamp                      | 17. Water hose       | 18. Oil cooler              |
| 19. Crankshaft position sensor | 20. Gasket           | 21. Oil pan bolt            |
| 22. Rear oil seal              |                      |                             |


- A. Refer to [LU-10](#) B. To thermostat housing C. To thermostat housing (M/T models)  
To CVT fluid cooler (CVT models)

D. Oil pan side

 : N·m (kg-m, ft-lb)

 : N·m (kg-m, in-lb)

 : Always replace after every disassembly.

 : Should be lubricated with oil.

# OIL PAN (UPPER)

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]



: Sealing point



: Indicates that the parts is connected at points with same symbols in actual vehicle.

## Removal and Installation

INFOID:000000007577485

EM

### REMOVAL

1. Remove oil pan (lower). Refer to [EM-106, "Exploded View"](#).
2. Remove oil filter. Refer to [LU-10, "Removal and Installation"](#).
3. Remove front cover, timing chain, oil pump drive chain, and other related parts. Refer to [EM-72, "Exploded View"](#).
4. Remove oil level gauge and oil level gauge guide.
5. Remove oil pump. Refer to [LU-14, "Exploded View"](#).


#### NOTE:

The oil pan (upper) can be removed and installed without removing the oil pump.

6. Remove oil pan (upper) with the following procedure:
  - a. Loosen bolts in reverse order as shown in the figure.



: Engine front




- b. Insert a screwdriver shown by the arrow (↔) in the figure and open up a crack between oil pan (upper) and cylinder block.



: Engine front

#### CAUTION:

A more adhesive liquid gasket is applied compared to previous types when shipped, so it should not be forced off the position not specified.



- c. Insert seal cutter [SST: KV10111100 (J-37228)] between oil pan (upper) and cylinder block, and slide it by tapping on the side of the tool with a hammer.

#### CAUTION:

Never damage the mating surface.

7. Remove O-ring between cylinder block and oil pan (upper).

### INSTALLATION

#### CAUTION:

Do not reuse O-rings.

1. Install oil pan (upper) with the following procedure:

## OIL PAN (UPPER)


[MR16DDT ]

### < UNIT DISASSEMBLY AND ASSEMBLY >

- a. Use a scraper (A) to remove old liquid gasket from mating surfaces.
  - Remove the old liquid gasket from mating surface of cylinder block.
  - Remove old liquid gasket from the bolt holes and threads.

**CAUTION:**

**Never scratch or damage the mating surfaces when cleaning off old liquid gasket.**




- b. Apply a continuous bead of liquid gasket (D) with a tube presser (commercial service tool) as shown in the figure.

- 1 : Oil pan (upper)
- A : 2 mm (0.08 in) protruded to outside
- B : 2 mm (0.08 in) protruded to rear oil seal mounting side
- c : 5.5 - 7.5 mm (0.217 - 0.295 in)
- e :  $\phi$  4.0 - 5.0 mm (0.157 - 0.197 in)
- ← : Engine front
- ➡ : Engine outside

**Use Genuine RTV silicon sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**


**CAUTION:**

- Apply liquid gasket to outside of bolt hole for the positions shown by ▲ marks.
- Attaching should be done within 5 minutes after liquid gasket application.



- c. Install new O-ring at cylinder block side.
- d. Tighten bolts in numerical order as shown in the figure.

- ← : Engine front



2. Install rear oil seal with the following procedure.

**CAUTION:**

- The installation of rear oil seal should be completed within 5 minutes after installing oil pan (upper).
- Always replace rear oil seal with new one.
- Never touch oil seal lip.


- a. Wipe off liquid gasket protruding to the rear oil seal mounting part of oil pan (upper) and cylinder block using a scraper.

## OIL PAN (UPPER)

### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- b. Apply engine oil to entire outside area of rear oil seal.
- c. Press-fit the rear oil seal using a suitable drift (A) with outer diameter 115 mm (4.53 in) and inner diameter 90 mm (3.54 in).



- Press-fit to the specified dimensions as shown in the figure.

1 : Rear oil seal


A : Cylinder block rear end surface

#### CAUTION:

- Never touch the grease applied to the oil seal lip.
- Be careful not to damage the rear oil seal mounting part of oil pan (upper) and cylinder block or the crankshaft.
- Press-fit straight, checking that rear oil seal does not curl or tilt.

#### NOTE:

The standard surface of the dimension is the rear end surface of cylinder block.



3. Install in the reverse order of removal, for the rest of parts.

### Inspection

INFOID:000000007577486

### INSPECTION AFTER REMOVAL

Clean oil strainer portion (part of the oil pump) if any object attached.

# CYLINDER BLOCK


< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## CYLINDER BLOCK

Exploded View

INFOID:000000007577487



- |                   |                   |                                   |
|-------------------|-------------------|-----------------------------------|
| 1. Cylinder block | 2. Top ring       | 3. Second ring                    |
| 4. Oil ring       | 5. Piston         | 6. Piston pin                     |
| 7. Snap ring      | 8. Connecting rod | 9. Connecting rod bearing (upper) |

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- |                                                                                    |                                      |                                        |
|------------------------------------------------------------------------------------|--------------------------------------|----------------------------------------|
| 10. Connecting rod bearing (lower)                                                 | 11. Crankshaft key                   | 12. Connecting rod cap                 |
| 13. Connecting rod cap bolt                                                        | 14. Main bearing cap bolt            | 15. Main bearing beam                  |
| 16. Main bearing cap                                                               | 17. Main bearing (lower)             | 18. Crankshaft                         |
| 19. Pilot converter (CVT models)                                                   | 20. Signal plate                     | 21. Rear oil seal                      |
| 22. Drive plate (CVT models)                                                       | 23. Reinforcement plate (CVT models) | 24. Main bearing (upper)               |
| 25. Thrust bearing                                                                 | 26. Oil temperature sensor           | 27. Oil pressure sensor                |
| 28. Knock sensor                                                                   | 29. Flywheel (M/T models)            | 30. Cylinder block heater (For Canada) |
| A. Comply with assembly procedure when tightening. Refer to <a href="#">EM-111</a> | B. Chamfered                         |                                        |

↩ : Crankshaft side

⚙ : N·m (kg·m, ft·lb)

✕ : Always replace after every disassembly.

🛢 : Should be lubricated with oil.

🔧 : Sealing point


★ : Select with proper thickness.

## Disassembly and Assembly

INFOID:000000007577488

### DISASSEMBLY

- Remove oil pan (upper). Refer to [EM-106, "Exploded View"](#).
- Remove thermostat housing. Refer to [CO-21, "Exploded View"](#).
- Remove knock sensor.  
**CAUTION:**  
**Carefully handle sensor avoiding shocks.**
- Remove piston and connecting rod assembly with the following procedure:
  - Before removing piston and connecting rod assembly, check the connecting rod side clearance. Refer to [EM-119, "Inspection"](#).
- Position crankshaft pin corresponding to connecting rod to be removed onto the bottom dead center.
- Remove connecting rod cap.
- Using a hammer handle or similar tool, push piston and connecting rod assembly out to the cylinder head side.  
**CAUTION:**
  - Never damage matching surface with connecting rod cap.
  - Never damage the cylinder wall and crankshaft pin, resulting from an interference of the connecting rod big end.



- Remove connecting rod bearings.

**CAUTION:**

**When removing them, note the installation position. Keep them in the correct.**

- Remove piston rings from piston.
  - Before removing piston rings, check the piston ring side clearance. Refer to [EM-119, "Inspection"](#).

## CYLINDER BLOCK


### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Use a piston ring expander (commercial service tool) (A).


**CAUTION:**

- When removing piston rings, be careful not to damage the piston.
- Never damage piston rings by expanding them excessively.




7. Remove piston from connecting rod with the following procedure:


- a. Using snap ring pliers (A), remove snap rings.



- b. Heat piston to 60 to 70°C (140 to 158°F) with an industrial use drier (A) or equivalent.



- c. Push out piston pin with stick of outer diameter approximately 18 mm (0.71 in).



8. Remove main bearing cap bolts.

- Measure crankshaft end play before loosening main bearing cap bolts. Refer to [EM-119. "Inspection"](#).



# CYLINDER BLOCK


## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Loosen and remove main bearing cap bolts in reverse order as shown in the figure.

↩ : Engine front

- Use TORX socket.



- Remove main bearing caps.
  - Tap main bearing caps lightly with a plastic hammer for removal.

### CAUTION:

**Be careful not to damage the mounting surface.**


- Remove crankshaft.

### CAUTION:

- Be careful not to damage or deform signal plate (1) mounted on rear end of crankshaft (A).
- When setting crankshaft on a flat floor surface, use a block of wood to avoid interference between signal plate and the floor surface.
- Never remove signal plate unless it is necessary to do so.

### NOTE:

When removing or installing signal plate, use TORX socket.



- Pull rear oil seal out from rear end of crankshaft.
- Remove main bearings and thrust bearings from cylinder block and main bearing caps.

### CAUTION:

**Identify installation positions, and store them without mixing them up.**

## ASSEMBLY

### CAUTION:

**Do not reuse washers.**

- Fully air-blow engine coolant and engine oil passages in cylinder block, cylinder bore and crankcase to remove any foreign material.

### CAUTION:

**Use a goggles to protect your eye.**

- Install each plug to cylinder block as shown in the figure.


2 : Washer

↩ : Engine front

- Apply liquid gasket to the thread of water drain plug (4).  
**Use Genuine RTV silicon sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**
- Apply sealant to the thread of plug (1).  
**Use genuine high strength thread locking sealant or equivalent.**

### NOTE:

Do not apply liquid gasket or high strength thread locking sealant to the plug (3).



- Tighten each plug as specified below.

# CYLINDER BLOCK

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


Part	Washer	Tightening torque
1	Yes	54.0 N·m (5.5 kg-m, 40 ft-lb)
3	No	19.6 N·m (2.0 kg-m, 14 ft-lb)
4	No	9.8 N·m (1.0 kg-m, 87 in-lb)

3. Install main bearings and thrust bearings with the following procedure:

- Remove dust, dirt, and engine oil on the bearing mating surfaces of cylinder block and main bearing cap.
- Install thrust bearings to the both sides of the No. 3 journal housing (B) on cylinder block.

⇐ : Engine front

- Install thrust bearings with the oil groove (A) facing crankshaft arm (outside).




c. Install the main bearings paying attention to the direction.


- Before installing main bearings, apply new engine oil to the bearing surface (inside). Do not apply new engine oil to the back surface, but thoroughly clean it.
- When installing, align main bearing to the center position of cylinder block and main bearing cap.
- The difference (A) between main bearing (upper) (1) and main bearing (lower) (3) should be 0.85 mm (0.0335 in) or less when installing.

2 : Cylinder block

4 : Main bearing cap



- Ensure the oil holes on cylinder block and oil holes (A) on the main bearings (1) are aligned.



4. Install signal plate to crankshaft if removed.

- Set the signal plate with the flange facing toward the counter weight side (engine front side) to the crankshaft rear surface.
- Apply new engine oil to threads and seat surfaces of mounting bolts.

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- c. Position crankshaft (2) and signal plate (1) using a dowel pin (service part), and tighten mounting bolts in numerical order as shown in the figure using TORX socket.

A : Dowel pin hole

### NOTE:

Dowel pin of crankshaft and signal plate is provided as a set for each.

- d. Tighten mounting bolts in numerical order as shown in the figure again.
- e. Remove dowel pin. (service parts)

### CAUTION:



**Be sure to remove dowel pin.**

5. Install crankshaft to cylinder block.
  - While turning crankshaft by hand, check that it turns smoothly.
6. Install main bearing caps with the following procedure:
  - a. Install main bearing caps referring to the journal No. stamp (A) and front mark (B) as shown in the figure.

← : Engine front

### NOTE:

Main bearing cap cannot be replaced as a single part, because it is machined together with cylinder block.




- b. Tighten main bearing cap bolts in numerical order as shown in the figure with the following procedure:

← : Engine front

- i. Apply new engine oil to threads and seat surfaces of mounting bolts.
- ii. Tighten main bearing cap bolts.


**34.3 N·m (3.5 kg-m, 25 ft-lb)**



- iii. Turn main bearing cap bolts 70 degrees clockwise (angle tightening) in order from No. 1 to 10 in the figure.

### CAUTION:

**Confirm the tightening angle by using an angle wrench [SST: KV10112100 (BT8653-A)] (A) or protractor. Never judge by visual inspection without the tool.**



- After installing mounting bolts, check that crankshaft can be rotated smoothly by hand.
  - Check crankshaft end play. Refer to [EM-119, "Inspection"](#).
7. Install piston to connecting rod with the following procedure:

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- a. Using snap ring pliers, install new snap ring to the groove of the piston rear side.
  - Insert it fully into groove to install.
- b. Assemble piston to connecting rod.
  - Using an industrial use drier or similar tool, heat the piston until the piston pin can be pushed in by hand without excess force [approximately 60 to 70°C (140 to 158°F)]. From the front to the rear, insert piston pin into piston and connecting rod.
  - Assemble so that the front mark (A) on the piston head and the oil hole (B) and the cylinder number (D) on connecting rod are positioned as shown in the figure.

C : Engine type  
 E : Large end hole diameter grade  
 F : Front mark (connecting rod)

- c. Install new snap ring to the groove of the piston front side.
  - Insert it fully into groove to install.
  - After installing, check that connecting rod moves smoothly.
8. Using a piston ring expander (commercial service tool), install piston rings.

### CAUTION:



- **Never damage piston.**
- **Never damage piston rings by expanding them excessively.**
- Position each ring with the gap as shown in the figure referring to the piston front mark.

A : Oil ring upper or lower rail gap  
 B : Front mark  
 C : Second ring and oil ring spacer gap  
 D : Top ring gap  
 E : Stamped mark

### CAUTION:

**Never contact the rail end gap under the oil ring with the oil drain cast groove of piston.**

- Install second ring with the stamped surface facing upward.




9. Install connecting rod bearing upper (2) and lower (3) to connecting rod (1) and connecting rod cap (4).

C : Oil hole (connecting rod)  
 D : View D  
 E : OK  
 F : NG  
 g : 2.55 - 2.95 mm (0.1004 - 0.1161 in)  
 ⇐ : Engine front

- Install the connecting rod in the dimension shown in the figure.
- Check that connecting rod bearing oil hole (A) is completely in the inside of connecting rod oil hole chamfered area (B).
- When installing connecting rod bearings, apply new engine oil to the bearing surface (inside). Do not apply new engine oil to the back surface, but thoroughly clean it.

### NOTE:

- There is no positioning tab.
- Install the connecting rod bearings in the center of connecting rod and connecting rod cap as shown in the figure. For service operation, the center position can be checked, visually.



# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT ]

### 10. Install piston and connecting rod assembly to crankshaft.

- Position crankshaft pin corresponding to connecting rod to be installed onto the bottom dead center.
- Apply new engine oil sufficiently to the cylinder bore, piston and crankshaft pin.
- Match the cylinder position with the cylinder number (D) on connecting rod to install.

- A : Front mark (piston)  
 B : Oil hole  
 C : Engine type  
 E : Large end hole diameter grade  
 F : Front mark (connecting rod)


- Install so that front mark (A) on the piston head faces the front of engine.



- Using a piston ring compressor [SST: EM03470000 (J-8037)] (A) or suitable tool, install piston with the front mark on the piston head facing the front of the engine.

### CAUTION:


**Be careful not to damage the cylinder wall and crankshaft pin, resulting from an interference of the connecting rod big end.**



### 11. Install connecting rod cap.

- Match the stamped cylinder number marks (D) on connecting rod with those on connecting rod cap to install.

- A : Front mark (piston)  
 B : Oil hole  
 C : Engine type  
 E : Large end hole diameter grade  
 F : Front mark (connecting rod)



### 12. Tighten connecting rod cap bolt with the following procedure:

### CAUTION:

- Check that there is no gap in the thrust surface (A) of the joint between connecting rod (1) and connecting rod cap (2) and that these parts are in the correct position. And then, tighten the connecting rod cap bolts.
- If the connecting rod cap bolts are reused, measure the outer diameter. Refer to [EM-119, "Inspection"](#).


- Apply new engine oil to the threads and seats of connecting rod cap bolts.
- Tighten connecting rod cap bolts.

: 27.4 N·m (2.8 kg-m, 20 ft-lb)

- Completely loosen connecting rod cap bolts.

: 0 N·m (0 kg-m, 0 ft-lb)

- Tighten connecting rod cap bolts.



# CYLINDER BLOCK

< UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT ]

: 19.6 N·m (2.0 kg-m, 14 ft-lb)

- e. Then turn all connecting rod cap bolts 60 degrees clockwise (angle tightening).

**CAUTION:**

Check and confirm the tightening angle by using an angle wrench [SST: KV10112100 (BT8653-A)] (A) or protractor. Never judge by visual inspection without the tool.



- After tightening connecting rod cap bolt, check that crankshaft rotates smoothly.
- Check the connecting rod side clearance. Refer to [EM-119, "Inspection"](#).

13. Install oil pan (upper). Refer to [EM-106, "Exploded View"](#).

**NOTE:**

Install the rear oil seal after installing the oil pan (upper).


14. Install rear oil seal. Refer to [EM-94, "REAR OIL SEAL : Removal and Installation"](#).

15. Install flywheel (M/T models) or drive plate (CVT models).

Drive plate (CVT models)

- Secure crankshaft with a stopper plate [SST: KV11105210 (J-44716)], (A) and tighten mounting bolts crosswise over several times.

1 : Drive plate




- Install pilot converter (1), drive plate (2), and reinforcement plate (3) as shown in the figure.

A : Crankshaft rear end

B : R

- Using a drift of 33 mm (1.30 in) in dia meter, press-fit pilot converter into the end of crankshaft until it stops.



Fly wheel (M/T models)

- Secure crankshaft with a stopper plate [SST: KV11105210 (J-44716)] and tighten mounting bolts crosswise over several times.

**NOTE:**

M/T models have no pilot bushing and reinforcement plate.

16. Install knock sensor.

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Install knock sensor (1) with harness connector facing toward the rear of engine.

A : Cylinder block left side

↔ : Engine front

### CAUTION:

- **Never tighten mounting bolts while holding the harness connector.**
- **If any impact by dropping is applied to knock sensor, replace it with a new one.**

### NOTE:

- Check that there is no foreign material on the cylinder block mating surface and the back surface of knock sensor.
- Check that knock sensor does not interfere with other parts.

17. Assemble in the reverse order of disassembly.

## Inspection


INFOID:000000007577489

### CRANKSHAFT END PLAY

- Measure the clearance between thrust bearings and crankshaft arm when crankshaft is moved fully forward or backward with a dial indicator (A).

**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If the measured value exceeds the limit, replace thrust bearings, and measure again. If it still exceeds the limit, replace crankshaft also.




### CONNECTING ROD SIDE CLEARANCE

- Measure the side clearance between connecting rod and crankshaft arm with a feeler gauge (A).

**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If the measured value exceeds the limit, replace connecting rod, and measure again. If it still exceeds the limit, replace crankshaft also.




### PISTON TO PISTON PIN OIL CLEARANCE

Piston Pin Hole Diameter

Measure the inner diameter of piston pin hole with an inside micrometer (A).

**Standard** : Refer to [EM-140, "Cylinder Block"](#).



Piston Pin Outer Diameter




# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

Measure the outer diameter of piston pin with a micrometer (A).

**Standard** : Refer to [EM-140, "Cylinder Block"](#).



Piston to Piston Pin Oil Clearance

(Piston to piston pin oil clearance) = (Piston pin hole diameter) – (Piston pin outer diameter)

**Standard** : Refer to [EM-140, "Cylinder Block"](#).

- If oil clearance is out of the standard, replace piston and piston pin assembly.
- When replacing piston and piston pin assembly. Refer to [EM-129, "Description"](#).

### NOTE:


- Piston is available together with piston pin as assembly.
- Piston pin (piston pin hole) grade is provided only for the parts installed at the plant. For service parts, no grades can be selected. (Only grade "0" is available.)

## PISTON RING SIDE CLEARANCE

- Measure the side clearance of piston ring and piston ring groove with a feeler gauge (A).

**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If the measured value exceeds the limit, replace piston ring, and measure again. If it still exceeds the limit, replace piston also.




## PISTON RING END GAP

- Check that cylinder bore inner diameter is within specification. Refer to "PISTON TO CYLINDER BORE CLEARANCE".
- Lubricate with new engine oil to piston (1) and piston ring (2), and then insert (A) piston ring until middle of cylinder (B) with piston, and measure piston ring end gap with a feeler gauge (C).

**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If the measured value exceeds the limit, replace piston ring, and measure again. If it still exceeds the limit, rebore cylinder and use oversized piston and piston rings.



## CONNECTING ROD BEND AND TORSION



# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT ]

- Check with a connecting rod aligner.

A : Bend  
B : Torsion  
C : Feeler gauge

**Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If it exceeds the limit, replace connecting rod assembly.



### CONNECTING ROD BIG END DIAMETER


- Install connecting rod cap (1) without connecting rod bearing installed, and tightening connecting rod cap bolts to the specified torque. Refer to [EM-111, "Disassembly and Assembly"](#).

2 : Connecting rod  
A : Example  
B : Measuring direction of inner diameter

- Measure the inner diameter of connecting rod big end with an inside micrometer.

**Standard** : Refer to [EM-140, "Cylinder Block"](#).

- If out of the standard, replace connecting rod assembly.




### CONNECTING ROD BUSHING OIL CLEARANCE

#### Connecting Rod Bushing Inner Diameter

Measure the inner diameter of connecting rod bushing with an inside micrometer (A).

**Standard** : Refer to [EM-140, "Cylinder Block"](#).



#### Piston Pin Outer Diameter


# CYLINDER BLOCK

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

Measure the outer diameter of piston pin with a micrometer (A).

**Standard** : Refer to [EM-140, "Cylinder Block"](#).



Connecting Rod Bushing Oil Clearance

(Connecting rod bushing oil clearance) = (Connecting rod bushing inner diameter) – (Piston pin outer diameter)

**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If the measured value is out of the standard, replace connecting rod assembly and/or piston and piston pin assembly.
- If replacing piston and piston pin assembly. Refer to [EM-129, "Piston"](#).
- If replacing connecting rod assembly. Refer to [EM-130, "Connecting Rod Bearing"](#).

## CYLINDER BLOCK TOP SURFACE DISTORTION

- Using a scraper, remove gasket on the cylinder block surface, and also remove engine oil, scale, carbon, or other contamination.


### CAUTION:

**Be careful not to allow gasket flakes to enter engine oil or engine coolant passages.**

- Measure the distortion on the cylinder block upper face at some different points in six directions with a straight edge (A) and feeler gauge (B).

**Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If it exceeds the limit, replace cylinder block.



## MAIN BEARING HOUSING INNER DIAMETER

- Install main bearing cap without main bearings installed, and tighten main bearing cap mounting bolts to the specified torque. Refer to [EM-111, "Disassembly and Assembly"](#).
- Measure the inner diameter of main bearing housing with a bore gauge.
- Measure the position shown in the figure [5 mm (0.20 in)] backward from main bearing housing front side in the 2 directions as shown in the figure. The smaller one is the measured value.


- 1 : Cylinder block
- 2 : Main bearing cap
- ⇐ : Engine front

**Standard** : Refer to [EM-140, "Cylinder Block"](#).

- If out of the standard, replace cylinder block and main bearing caps assembly.

### NOTE:

Main bearing caps cannot be replaced as a single, because it is machined together with cylinder block.



## PISTON TO CYLINDER BORE CLEARANCE

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]


### Cylinder Bore Inner Diameter

- Using a bore gauge, measure the cylinder bore for wear, out-of-round and taper at six different points on each cylinder. [(A) and (B) directions at (C), (D), and (E)] [(A) is in longitudinal direction of engine]

f : 10 mm (0.39 in)  
g : 60 mm (2.36 in)  
h : 130 mm (5.12 in)

#### NOTE:

When determining cylinder bore grade, measure the cylinder bore (B) direction at (D) position.



#### Standard:

##### Cylinder bore inner diameter

: Refer to [EM-140, "Cylinder Block"](#).

#### Limit:

##### Out-of-round [Difference between (A) and (B)]

##### Taper [Difference between (C) and (D)]

: Refer to [EM-140, "Cylinder Block"](#).

- If the measured value exceeds the limit, or if there are scratches and/or seizure on the cylinder inner wall, replace cylinder block.


#### NOTE:

Oversize piston is not provided.

### Piston Skirt Diameter

Measure the outer diameter of piston skirt with a micrometer (A).

**Standard** : Refer to [EM-140, "Cylinder Block"](#).




### Piston to Cylinder Bore Clearance

Calculate by piston skirt diameter and cylinder bore inner diameter [direction (B), position (D)].

A : Direction A  
C : Position C  
E : Position E  
f : 10 mm (0.39 in)  
g : 60 mm (2.36 in)  
h : 130 mm (5.12 in)

(Clearance) = (Cylinder bore inner diameter) – (Piston skirt diameter)



**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If it exceeds the limit, replace piston and piston pin assembly and/or cylinder block. Refer to [EM-129, "Piston"](#).

# CYLINDER BLOCK

< UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT]

## CRANKSHAFT MAIN JOURNAL DIAMETER

- Measure the outer diameter of crankshaft main journals with a micrometer (A).

**Standard** : Refer to [EM-140, "Cylinder Block"](#).

- If out of the standard, measure the main bearing oil clearance. Then use undersize bearing. Refer to [EM-144, "Main Bearing"](#).



## CRANKSHAFT PIN JOURNAL DIAMETER

- Measure the outer diameter of crankshaft pin journal with a micrometer.

**Standard** : Refer to [EM-140, "Cylinder Block"](#).

- If out of the standard, measure the connecting rod bearing oil clearance. Then use undersize bearing. Refer to [EM-144, "Connecting Rod Bearing"](#).

## OUT-OF-ROUND AND TAPER OF CRANKSHAFT


- Measure the dimensions at four different points as shown in the figure on each main journal and pin journal with a micrometer.
- Out-of-round is indicated by the difference in dimensions between (X) and (Y) at (A) and (B).
- Taper is indicated by the difference in dimension between (A) and (B) at (X) and (Y).

**Limit:**

**Out-of-round [Difference between (X) and (Y)]**

**Taper [Difference between (A) and (B)]**

**: Refer to [EM-140, "Cylinder Block"](#).**




- If the measured value exceeds the limit, correct or replace crankshaft.
- If corrected, measure the bearing oil clearance of the corrected main journal and/or pin journal. Then select main bearing and/or connecting rod bearing. Refer to [EM-130, "Connecting Rod Bearing"](#) and/or [EM-132, "Main Bearing"](#).

## CRANKSHAFT RUNOUT

- Place a V-block on a precise flat table to support the journals on the both end of the crankshaft.
- Place a dial indicator (A) straight up on the No. 3 journal.
- While rotating crankshaft, read the movement of the pointer on the dial indicator. (Total indicator reading)

**Standard and Limit** : Refer to [EM-140, "Cylinder Block"](#).

- If it exceeds the limit, replace crankshaft.



## CONNECTING ROD BEARING OIL CLEARANCE

Method by Calculation

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >


[MR16DDT ]

- Install connecting rod bearings (2) to connecting rod (3) and connecting rod bearing cap (1), and tighten connecting rod cap bolts to the specified torque. Refer to [EM-111, "Disassembly and Assembly"](#).

A : Example

B : Inner diameter measuring direction

- Measure the inner diameter of connecting rod bearing with an inside micrometer.  
(Bearing oil clearance) = (Connecting rod bearing inner diameter) – (Crankshaft pin journal diameter)



**Standard and Limit** : Refer to [EM-144, "Connecting Rod Bearing"](#).

- If clearance exceeds the limit, select proper connecting rod bearing according to connecting rod big end diameter and crankshaft pin journal diameter to obtain specified bearing oil clearance. Refer to [EM-130, "Connecting Rod Bearing"](#).

### Method of Using Plastigage

- Remove engine oil and dust on crankshaft pin and the surfaces of each bearing completely.
- Cut a plastigage slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Install connecting rod bearings to connecting rod and cap, and tighten connecting rod cap bolts to the specified torque. Refer to [EM-111, "Disassembly and Assembly"](#).


### CAUTION:

**Never rotate crankshaft.**

- Remove connecting rod cap and bearing, and using the scale (A) on the plastigage bag, measure the plastigage width.

### NOTE:

The procedure when the measured value exceeds the limit is same as that described in the "Method by Calculation".



## MAIN BEARING OIL CLEARANCE


### Method by Calculation

- Install main bearings (3) to cylinder block (1) and main bearing cap (2), and tighten main bearing cap mounting bolts to the specified torque. Refer to [EM-111, "Disassembly and Assembly"](#).

A : Example

B : Inner diameter measuring direction

- Measure the inner diameter of main bearing with a bore gauge.  
(Bearing oil clearance) = (Main bearing inner diameter) – (Crankshaft main journal diameter)



**Standard and Limit** : Refer to [EM-144, "Main Bearing"](#).

- If clearance exceeds the limit, select proper main bearing according to main bearing inner diameter and crankshaft main journal diameter to obtain specified bearing oil clearance. Refer to [EM-132, "Main Bearing"](#).

### Method of Using Plastigage

- Remove engine oil and dust on crankshaft main journal and the surfaces of each bearing completely.
- Cut a plastigage slightly shorter than the bearing width, and place it in crankshaft axial direction, avoiding oil holes.
- Install main bearings to cylinder block and main bearing cap, and tighten main bearing cap mounting bolts to the specified torque. Refer to [EM-111, "Disassembly and Assembly"](#).

# CYLINDER BLOCK

## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT]


### CAUTION:

**Never rotate crankshaft.**

- Remove main bearing cap and bearings, and using the scale (A) on the plastigage bag, measure the plastigage width.

### NOTE:

The procedure when the measured value exceeds the limit is same as that described in the "Method by Calculation".




## MAIN BEARING CRUSH HEIGHT

- When main bearing cap is removed after being tightened to the specified torque with main bearings (1) installed, the tip end of bearing must protrude (B). Refer to [EM-111, "Disassembly and Assembly"](#).

A : Example

**Standard : There must be crush height.**

- If the standard is not met, replace main bearings.




## CONNECTING ROD BEARING CRUSH HEIGHT

- When connecting rod cap is removed after being tightened to the specified torque with connecting rod bearings (1) installed, the tip end of bearing must protrude (B). Refer to [EM-111, "Disassembly and Assembly"](#).

A : Example

**Standard : There must be crush height.**

- If the standard is not met, replace connecting rod bearings.



## MAIN BEARING CAP BOLT OUTER DIAMETER

- Measure the outer diameters (d1) and (d2) at two positions as shown in the figure.


A : (d1) measuring position

B : (d2) measuring position

- If reduction appears in places other than (B) range, regard it as (d2).

**Limit [(d1) – (d2)]: 0.15 mm (0.0059 in)**

- If it exceeds the limit (a large difference in dimensions), replace main bearing cap mounting bolt with a new one.



## CONNECTING ROD CAP BOLT OUTER DIAMETER

# CYLINDER BLOCK


## < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Measure the outer diameter (d) at position as shown in the figure.
- If reduction appears in a position other than (d), regard it as (d).

**Limit: 7.75 mm (0.3051 in)**

- When (d) exceeds the limit (when it becomes thinner), replace connecting rod cap bolt with a new one.



## FLYWHEEL DEFLECTION (M/T MODELS)


- Measure the deflection of flywheel contact surface to torque with a dial indicator (A).
- Measure the deflection at 210 mm (8.27 in) diameter.

**Limit : 0.45 mm (0.0177 in) or less.**

- If measured value is out of the standard, replace flywheel.
- If a trace of burn or discoloration is found on the surface, repair it with sandpaper.

### CAUTION:

**When measuring, keep magnetic fields (such as dial indicator stand) away from signal plate of the rear end of crankshaft.**



## MOVEMENT AMOUNT OF FLYWHEEL (M/T MODELS)

### CAUTION:

**Never disassemble double mass flywheel.**

### Movement Amount of Thrust (Fore-and-Aft) Direction

- Measure the movement amount of thrust (fore-and-aft) direction when 100 N (10.2 kg, 22 lb) force is added at the portion of 125 mm (4.92 in) radius from the center of flywheel.


**Standard : 1.8 mm (0.071 in) or less**

- If measured value is out of the standard, replace flywheel.

### Movement Amount in Radial (Rotation) Direction

Check the movement amount of radial (rotation) direction with the following procedure:

1. Install clutch cover mounting bolt (1) to clutch cover mounting hole, and place a torque wrench (A) on the extended line of the flywheel (2) center line.
  - Tighten bolt at a force of 9.8 N·m (1.0 kg-m, 87 in-lb) to keep it from loosening.
2. Put a mating mark on circumferences of the two flywheel masses without applying any load (Measurement standard points).
3. Apply a force of 9.8 N·m (1.0 kg-m, 87 in-lb) in each direction, and mark the movement amount on the mass on the transaxle side.
4. Measure the dimensions of movement amounts "A" and "B" on circumference of the flywheel on the transaxle side.



**Limit : 33.2 mm (1.307 in) or less.**

- If measured value is out of the standard, replace flywheel.

## DRIVE PLATE DEFLECTION (CVT MODELS)



## CYLINDER BLOCK


### < UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

- Measure the deflection of drive plate contact surface to torque converter with a dial indicator (A).
- Measure the deflection at the area limited between 12.4 mm (0.488 in) dia and 20.0 mm (0.787 in) dia around hole (B).

**Limit : 0.35 mm (0.0138 in) or less.**

- If measured value is out of the standard, replace drive plate.





# HOW TO SELECT PISTON AND BEARING

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## HOW TO SELECT PISTON AND BEARING

### Description

INFOID:000000007577490

Selection points	Selection parts	Selection items	Selection methods
Between cylinder block and crankshaft	Main bearing	Main bearing grade (bearing thickness)	Determined by match of cylinder block bearing housing grade (inner diameter of housing) and crankshaft journal grade (outer diameter of journal)
Between crankshaft and connecting rod	Connecting rod bearing	Connecting rod bearing grade (bearing thickness)	Combining service grades for connecting rod big end diameter and crankshaft pin outer diameter determine connecting rod bearing selection.
Between cylinder block and piston	Piston and piston pin assembly (piston is available together with piston pin as an assembly.)	Piston grade (piston outer diameter)	Piston grade = cylinder bore grade (inner diameter of bore)

- The identification grade stamped on each part is the grade for the dimension measured in new condition. This grade cannot apply to reused parts.
- For reused or repaired parts, measure the dimension accurately. Determine the grade by comparing the measurement with the values of each selection table.
- For details of the measurement method of each part, the reuse standards and the selection method of the selective fitting parts, refer to the text.

### Piston


INFOID:000000007577491

#### WHEN NEW CYLINDER BLOCK IS USED

- Check the cylinder bore grade on rear left side of cylinder block (L), and select piston of the same grade.

- A : Correction stamp  
 B : Standard stamp  
 C : Cylinder No. 1 bore grade  
 D : Cylinder No. 2 bore grade  
 E : Cylinder No. 3 bore grade  
 F : Cylinder No. 4 bore grade  
 G : No. 1 main bearing housing grade  
 H : No. 2 main bearing housing grade  
 I : No. 3 main bearing housing grade  
 J : No. 4 main bearing housing grade  
 K : No. 5 main bearing housing grade  
 ⇐ : Engine front

- If there is a correction stamp mark on the cylinder block, use it as a correct reference.



#### WHEN CYLINDER BLOCK IS REUSED

1. Measure the cylinder bore inner diameter. Refer to [EM-140. "Cylinder Block"](#).
2. Determine the bore grade by comparing the measurement with the values under the cylinder bore inner diameter of the "Piston Selection Table".


# HOW TO SELECT PISTON AND BEARING

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

## 3. Select piston of the same grade.

- A : Identification code
- B : Piston grade number
- C : Front mark
- D : Sub grade number



JPBIA4439ZZ

## PISTON SELECTION TABLE

Unit: mm (in)

Grade number (Mark)	1	2 [or no mark (piston only)]
Cylinder bore Inner diameter	79.700 - 79.710 (3.1378 - 3.1382)	79.710 - 79.720 (3.1382 - 3.1386)
Piston skirt diameter	79.670 - 79.680 (3.1366 - 3.1370)	79.680 - 79.690 (3.1370 - 3.1374)

### NOTE:

Piston is available together with piston pin as an assembly.


## Connecting Rod Bearing

INFOID:000000007577492

### WHEN NEW CONNECTING ROD AND CRANKSHAFT ARE USED

1. Apply connecting rod big end diameter grade stamped on connecting rod side face to the row in the "Connecting Rod Bearing Selection Table".


- A : Oil hole
- B : Management code
- C : Cylinder number
- D : Big end diameter grade
- E : Front mark



JPBIA4442ZZ

2. Apply crankshaft pin journal diameter grade stamped on crankshaft front side to the column in the "Connecting Rod Bearing Selection Table".

- A : No. 1 pin journal diameter grade
- B : No. 2 pin journal diameter grade
- C : No. 3 pin journal diameter grade
- D : No. 4 pin journal diameter grade
- E : No. 1 main journal diameter grade
- F : No. 2 main journal diameter grade
- G : No. 3 main journal diameter grade
- H : No. 4 main journal diameter grade
- I : No. 5 main journal diameter grade



PBIC3261J

3. Read the symbol at the cross point of selected row and column in the "Connecting Rod Bearing Selection Table".
4. Apply the symbol obtained to the "Connecting Rod Bearing Grade Table" to select connecting rod bearing.

### WHEN CONNECTING ROD AND CRANKSHAFT ARE REUSED

1. Measure the dimensions of the connecting rod big end diameter and crankshaft pin journal diameter individually. Refer to [EM-119, "Inspection"](#).

# HOW TO SELECT PISTON AND BEARING

[MR16DDT ]

< UNIT DISASSEMBLY AND ASSEMBLY >

- Apply the measured dimension to the "Connecting Rod Bearing Selection Table".
- Read the symbol at the cross point of selected row and column in the "Connecting Rod Bearing Selection Table".
- Apply the symbol obtained to the "Connecting Rod Bearing Grade Table" to select connecting rod bearing.

## CONNECTING ROD BEARING SELECTION TABLE

Connecting rod big end diameter Unit: mm (in)		Mark	Hole diameter															
			A	B	C	D	E	F	G	H	J	K	L	M	N			
Mark	Axle diameter	Crankshaft pin journal diameter Unit: mm (in)																
		A	B	C	D	E	F	G	H	J	K	L	M	N				
A	43.970 - 43.971 (1.7311 - 1.7311)	0	0	0	0	0	01	01	01	1	1	1	12	12	12	12		
B	43.969 - 43.970 (1.7311 - 1.7311)	0	0	0	0	01	01	01	1	1	1	1	12	12	12	12		
C	43.968 - 43.969 (1.7310 - 1.7311)	0	0	0	01	01	01	1	1	1	1	12	12	12	12	12		
D	43.967 - 43.968 (1.7310 - 1.7310)	0	0	01	01	01	1	1	1	1	12	12	12	12	2	2		
E	43.966 - 43.967 (1.7309 - 1.7310)	0	01	01	01	1	1	1	1	12	12	12	2	2	2	2		
F	43.965 - 43.966 (1.7309 - 1.7309)	01	01	01	1	1	1	12	12	12	2	2	2	2	23	23		
G	43.964 - 43.965 (1.7309 - 1.7309)	01	01	1	1	1	1	12	12	12	2	2	2	2	23	23		
H	43.963 - 43.964 (1.7308 - 1.7309)	01	1	1	1	12	12	12	12	2	2	2	2	23	23	23		
J	43.962 - 43.963 (1.7308 - 1.7308)	1	1	1	12	12	12	12	2	2	2	2	23	23	23	3		
K	43.961 - 43.962 (1.7307 - 1.7308)	1	1	12	12	12	2	2	2	2	2	23	23	23	3	3		
L	43.960 - 43.961 (1.7307 - 1.7307)	1	12	12	12	2	2	2	2	2	23	23	23	3	3	3		
M	43.959 - 43.960 (1.7307 - 1.7307)	12	12	12	2	2	2	2	23	23	23	23	3	3	3	34		
N	43.958 - 43.959 (1.7306 - 1.7307)	12	12	2	2	2	2	23	23	23	3	3	3	3	34	34		
P	43.957 - 43.958 (1.7306 - 1.7306)	12	2	2	2	23	23	23	23	3	3	3	3	34	34	34		
R	43.956 - 43.957 (1.7305 - 1.7306)	2	2	2	23	23	23	23	3	3	3	34	34	34	4	4		
S	43.955 - 43.956 (1.7305 - 1.7305)	2	2	23	23	23	3	3	3	3	34	34	34	4	4	4		
T	43.954 - 43.955 (1.7305 - 1.7305)	2	23	23	23	3	3	3	34	34	34	34	4	4	4	4		
U	43.953 - 43.954 (1.7304 - 1.7305)	23	23	23	3	3	3	34	34	34	34	4	4	4	4	4		

PBIC4077E

## CONNECTING ROD BEARING GRADE TABLE

Connecting rod bearing grade table : Refer to [EM-144, "Connecting Rod Bearing"](#).

## UNDERSIZE BEARINGS USAGE GUIDE

- When the specified connecting rod bearing oil clearance is not obtained with standard size connecting rod bearings, use undersize (US) bearings.
- When using undersize (US) bearing, measure the connecting rod bearing inner diameter with bearing installed, and grind the crankshaft pin so that the connecting rod bearing oil clearance satisfies the standard.

**CAUTION:**

# HOW TO SELECT PISTON AND BEARING


< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

In grinding crankshaft pin to use undersize bearings, keep the fillet R [1.5 - 1.7 mm (0.059 - 0.067 in)] (A).

## Bearing undersize table

: Refer to [EM-144, "Connecting Rod Bearing"](#).



## Main Bearing


INFOID:000000007577493

### WHEN NEW CYLINDER BLOCK AND CRANKSHAFT ARE USED

1. "Main Bearing Selection Table" rows correspond to main bearing housing grade on rear left side of cylinder block (L).


- A : Correction stamp
- B : Standard stamp
- C : Cylinder No. 1 bore grade
- D : Cylinder No. 2 bore grade
- E : Cylinder No. 3 bore grade
- F : Cylinder No. 4 bore grade
- G : No. 1 main bearing housing grade
- H : No. 2 main bearing housing grade
- I : No. 3 main bearing housing grade
- J : No. 4 main bearing housing grade
- K : No. 5 main bearing housing grade
- ↔ : Engine front

- If there is a correction stamp mark on cylinder block, use it as a correct reference.



2. Apply main journal diameter grade stamped on crankshaft front side to column in the "Main Bearing Selection Table".

- A : No. 1 pin journal diameter grade
- B : No. 2 pin journal diameter grade
- C : No. 3 pin journal diameter grade
- D : No. 4 pin journal diameter grade
- E : No. 1 main journal diameter grade
- F : No. 2 main journal diameter grade
- G : No. 3 main journal diameter grade
- H : No. 4 main journal diameter grade
- I : No. 5 main journal diameter grade



3. Read the symbol at the cross point of selected row and column in the "Main Bearing Selection Table".

### CAUTION:

There are two main bearing selection tables. One is for No. 1, 4, and 5 journals and the other is for No. 2 and 3 journals. Make certain to use the appropriate table. This is due to differences in the specified clearances.

# HOW TO SELECT PISTON AND BEARING

< UNIT DISASSEMBLY AND ASSEMBLY >

[MR16DDT ]

4. Apply the symbol obtained to the "Main Bearing Grade Table" to select main bearing.

## NOTE:

Service part is available as a set of both upper and lower.

## WHEN CYLINDER BLOCK AND CRANKSHAFT ARE REUSED

1. Measure the dimensions of the cylinder block main bearing housing inner diameter and crankshaft main journal diameter individually. Refer to [EM-119, "Inspection"](#).
2. Apply the measured dimension to the "Main Bearing Selection Table".
3. Read the symbol at the cross point of selected row and column in the "Main Bearing Selection Table".

## CAUTION:

There are two main bearing selection tables. One is for No. 1, 4, and 5 journals and the other is for No. 2 and 3 journals. Make certain to use the appropriate table. This is due to differences in the specified clearances.

4. Apply the symbol obtained to the "Main Bearing Grade Table" to select main bearing.

## NOTE:

Service part is available as a set of both upper and lower.

## MAIN BEARING SELECTION TABLE (No. 1, 4, AND 5 JOURNAL)

<div> Cylinder block main bearing housing inner diameter Unit: mm (in)  </div> <div> Crankshaft main journal diameter Unit: mm (in)  </div>		Mark		A	B	C	D	E	F	G	H	J	K	L	M	N	P	R	S	T	U	V	W
		Hole diameter		55.997 - 55.998 (2.2046 - 2.2046)	55.998 - 55.999 (2.2046 - 2.2047)	55.999 - 56.000 (2.2047 - 2.2047)	56.000 - 56.001 (2.2047 - 2.2048)	56.001 - 56.002 (2.2048 - 2.2048)	56.002 - 56.003 (2.2048 - 2.2048)	56.003 - 56.004 (2.2048 - 2.2049)	56.004 - 56.005 (2.2049 - 2.2049)	56.005 - 56.006 (2.2049 - 2.2050)	56.006 - 56.007 (2.2050 - 2.2050)	56.007 - 56.008 (2.2050 - 2.2050)	56.008 - 56.009 (2.2050 - 2.2051)	56.009 - 56.010 (2.2051 - 2.2051)	56.010 - 56.011 (2.2051 - 2.2052)	56.011 - 56.012 (2.2052 - 2.2052)	56.012 - 56.013 (2.2052 - 2.2052)	56.013 - 56.014 (2.2052 - 2.2053)	56.014 - 56.015 (2.2053 - 2.2053)	56.015 - 56.016 (2.2053 - 2.2053)	56.016 - 56.017 (2.2053 - 2.2054)
Mark	Axle diameter																						
A	51.978 - 51.979 (2.0464 - 2.0464)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
B	51.977 - 51.978 (2.0463 - 2.0464)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
C	51.976 - 51.977 (2.0463 - 2.0463)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
D	51.975 - 51.976 (2.0463 - 2.0463)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
E	51.974 - 51.975 (2.0462 - 2.0463)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
F	51.973 - 51.974 (2.0462 - 2.0462)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
G	51.972 - 51.973 (2.0461 - 2.0462)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
H	51.971 - 51.972 (2.0461 - 2.0461)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
J	51.970 - 51.971 (2.0461 - 2.0461)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
K	51.969 - 51.970 (2.0460 - 2.0461)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
L	51.968 - 51.969 (2.0460 - 2.0460)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
M	51.967 - 51.968 (2.0459 - 2.0460)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
N	51.966 - 51.967 (2.0459 - 2.0459)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
P	51.965 - 51.966 (2.0459 - 2.0459)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
R	51.964 - 51.965 (2.0458 - 2.0459)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
S	51.963 - 51.964 (2.0458 - 2.0458)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
T	51.962 - 51.963 (2.0457 - 2.0458)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
U	51.961 - 51.962 (2.0457 - 2.0457)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
V	51.960 - 51.961 (2.0457 - 2.0457)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
W	51.959 - 51.960 (2.0456 - 2.0457)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0

PBIC4078E

[MR16DDT]

[illegible]

Diagram illustrating the component PBIC3263J, showing the location of the mounting holes (A and B) relative to the component body.

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specification


INFOID:000000007577494

EM

#### GENERAL SPECIFICATIONS

Engine type	MR16DDT	
Cylinder arrangement	In-line 4	
Displacement $\text{cm}^3$ (cu in)	1,618 (98.78)	
Bore and stroke mm (in)	79.7×81.1 (3.138×3.193)	
Valve arrangement	DOHC	
Firing order	1-3-4-2	
Number of piston rings	Compression	2
	Oil	1
Compression ratio	9.5	
Compression pressure $\text{kPa}$ ( $\text{kg}/\text{cm}^2$ , $\text{psi}$ )/250 rpm	Standard	1,560 (15.9, 226.2)
	Minimum	1,190 (12.1, 172.6)
	Differential limit between cylinders	100 (1.0, 14.5)

Unit: degree

Valve timing ↶ : Intake valve ↷ : Exhaust valve						
	a	b	c	d	e	f
	228	228	11 (-31) ATDC	59 (17) ABDC	4 (61) ATDC	44 (-13) BBDC

( ) : Valve timing control "ON"

#### Drive Belt

INFOID:000000007577495

#### DRIVE BELT

Tension of drive belt	Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.
-----------------------	----------------------------------------------------------------------------------------------

#### Spark Plug

INFOID:000000007577496

#### SPARK PLUG

Unit: mm (in)

Make	NTK	
Standard type	DILKAR7C9H	
Gap (Nominal)	Standard	0.9 (0.035)
	Limit	1.1 (0.043)

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

## Exhaust Manifold

INFOID:000000007577497

### EXHAUST MANIFOLD

Unit: mm (in)

Items		Limit
Surface distortion	Each exhaust port	0.1 (0.004)
	Entire part	0.3 (0.012)

## Turbocharger

INFOID:000000007577498

### TURBOCHARGER ACTUATOR

	Value of pressure	Value of rod moving
Standard	68.4 kPa (513 mmHg, 20.19 inHg)	1 mm (0.039 in)


## Camshaft

INFOID:000000007577499

### CAMSHAFT

Unit: mm (in)

Items		Standard	Limit
Camshaft journal oil clearance	No. 1	0.045 - 0.086 (0.0018 - 0.0034)	0.15 (0.0059)
	No. 2, 3, 4, 5	0.030 - 0.071 (0.0012 - 0.0028)	
Camshaft bracket inner diameter	No. 1	28.000 - 28.021 (1.1024 - 1.1032)	—
	No. 2, 3, 4, 5	25.000 - 25.021 (0.9843 - 0.9851)	—
Camshaft journal diameter	No. 1	27.935 - 27.955 (1.0998 - 1.1006)	—
	No. 2, 3, 4, 5	24.950 - 24.970 (0.9823 - 0.9831)	—
Camshaft end play		0.075 - 0.153 (0.0030 - 0.0060)	0.24 (0.0094)
Camshaft cam height "A"	Intake	44.605 - 44.795 (1.7561 - 1.7636)	44.66 (1.75827)
	Exhaust	43.175 - 43.365 (1.6998 - 1.7073)	44.20 (1.74016)
Camshaft runout [TIR*]		Less than 0.02 (0.0008)	0.05 (0.0020)
Camshaft sprocket runout [TIR*]		—	0.15 (0.0059)



SEM671

\*: Total indicator reading

### VALVE LIFTER

Unit: mm (in)

Items		Standard
Valve lifter outer diameter	Intake	33.977 - 33.987 (1.3377 - 1.3381)
	Exhaust	29.977 - 29.987 (1.1802 - 1.1806)



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Valve lifter hole diameter	Intake	34.000 - 34.021 (1.3386 - 1.3394)
	Exhaust	30.000 - 30.021 (1.1811 - 1.1819)
Valve lifter clearance		0.013 - 0.044 (0.0005 - 0.0017)

## VALVE CLEARANCE

Unit: mm (in)


Items	Cold	Hot* (reference data)
Intake	0.24 - 0.32 (0.009 - 0.013)	0.304 - 0.416 (0.012 - 0.016)
Exhaust	0.25 - 0.33 (0.01 - 0.013)	0.308 - 0.432 (0.012 - 0.017)

\*: Approximately 80°C (176°F)

## AVAILABLE VALVE LIFTER

Unit: mm (in)

Identification mark	Thickness
---------------------	-----------



KBIA0119E

300	3.00 (0.1181)
302	3.02 (0.1189)
304	3.04 (0.1197)
306	3.06 (0.1205)
308	3.08 (0.1213)
310	3.10 (0.1220)
312	3.12 (0.1228)
314	3.14 (0.1236)
316	3.16 (0.1244)
318	3.18 (0.1252)
320	3.20 (0.1260)
322	3.22 (0.1268)
324	3.24 (0.1276)
326	3.26 (0.1283)
328	3.28 (0.1291)
330	3.30 (0.1299)
332	3.32 (0.1307)
334	3.34 (0.1315)
336	3.36 (0.1323)
338	3.38 (0.1331)
340	3.40 (0.1339)
342	3.42 (0.1346)
344	3.44 (0.1354)

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Identification mark	Thickness
346	3.46 (0.1362)
348	3.48 (0.1370)
350	3.50 (0.1378)


## Cylinder Head

INFOID:000000007577500

### CYLINDER HEAD

Unit: mm (in)


Items	Standard	Limit
Head surface distortion	—	0.1 (0.004)
Normal cylinder head height "H"	130.9 (5.15)	—



PBIC0924E

### VALVE DIMENSIONS

Unit: mm (in)



Valve head diameter "D"	Intake	31.2 - 31.5 (1.228 - 1.240)
	Exhaust	25.6 - 25.9 (1.008 - 1.020)
Valve length "L"	Intake	107.08 (4.22)
	Exhaust	106.06 (4.18)
Valve stem diameter "d"	Intake	5.465 - 5.480 (0.2152 - 0.2157)
	Exhaust	5.455 - 5.470 (0.2148 - 0.2154)
Valve seat angle "α"		45°15' - 45°45'
Valve margin "T"	Intake	1.4 (0.055)
	Exhaust	1.4 (0.055)


### VALVE GUIDE

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Unit: mm (in)




PBIC2187E

Items		Standard	Oversize (service) [0.2 (0.008)]
Valve guide	Outer diameter	9.523 - 9.534 (0.3749 - 0.3754)	9.723 - 9.734 (0.3828 - 0.3832)
	Inner diameter (Finished size)	5.500 - 5.518 (0.2165 - 0.2172)	
Cylinder head valve guide hole diameter		9.475 - 9.496 (0.3730 - 0.3739)	9.675 - 9.696 (0.3809 - 0.3817)
Interference fit of valve guide		0.027 - 0.059 (0.0011 - 0.0023)	
Items		Standard	Limit
Valve guide clearance	Intake	0.020 - 0.053 (0.0008 - 0.0021)	0.1 (0.004)
	Exhaust	0.030 - 0.063 (0.0012 - 0.0025)	
Projection length “H”		13.35 - 13.65 (0.5256 - 0.5374)	

## VALVE SEAT

Unit: mm (in)



PBIC2745E

Items		Standard	Oversize (service) [0.5 (0.020)]
Cylinder head seat recess diameter "D"	Intake	31.900 - 31.927 (1.2559 - 1.2570)	35.200 - 35.227 (1.3858 - 1.3869)
	Exhaust	26.300 - 26.327 (1.0354 - 1.0365)	29.200 - 29.227 (1.1496 - 1.1507)
Valve seat outer diameter "d"	Intake	31.997 - 32.013 (1.2597 - 1.2604)	32.497 - 32.513 (1.2794 - 1.2800)
	Exhaust	26.408 - 26.424 (1.0397 - 1.0403)	
Valve seat interference fit		0.07 - 0.113 (0.0028 - 0.0044)	
Diameter "d1"*1	Intake	29.2 (1.150)	
	Exhaust	23.3 (0.917)	
Diameter "d2"*2	Intake	30.5 - 31.0 (1.201 - 1.220)	
	Exhaust	24.9 - 25.4 (0.980 - 1.0)	
Angle "alpha1"	Intake	70°	
	Exhaust	45°	
Angle "alpha2"		88°45' - 90°15'	
Angle "alpha3"		120°	

# SERVICE DATA AND SPECIFICATIONS (SDS)

## < SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Contacting width "W"*3	Intake	1.0 - 1.4 (0.039 - 0.055)	
	Exhaust	1.2 - 1.6 (0.047 - 0.063)	
Height "h"	Intake	5.9 - 6.0 (0.232 - 0.236)	5.09 - 5.10 (0.2004 - 0.2008)
	Exhaust		
Depth "H"	Intake	6.01 (0.2366)	
	Exhaust	6.07 (0.2390)	

\*1: Diameter made by intersection point of conic angles " $\alpha_1$ " and " $\alpha_2$ "

\*2: Diameter made by intersection point of conic angles " $\alpha_2$ " and " $\alpha_3$ "

\*3: Machining data

## VALVE SPRING

Items	Standard	
	Intake	Exhaust
Free height	49.4 - 49.6 mm (1.945 - 1.953 in)	54.5 - 54.7 mm (2.146 - 2.154 in)
Installation height	38.46 mm (1.514 in)	38.46 mm (1.514 in)
Installation load	151 - 175 N (15.4 - 17.9 kg, 34 - 39 lb)	257 - 289 N (26.2 - 29.5 kg, 57.8 - 65.0 lb)
Height during valve open	28.86 mm (1.1362 in)	30.03 mm (1.1823 in)
Load with valve open	344 - 392 N (35.0 - 40.0 kg, 77.3 - 88.1 lb)	450 - 502 N (45.9 - 51.2 kg, 101.2 - 112.9 lb)
Identification color	White	Yellow green

Unit: mm (in)


Items	Limit
Valve spring squareness	1.0 (0.039)

## Cylinder Block

INFOID:000000007577501

## CYLINDER BLOCK

Unit: mm (in)



PBIC4017E

Cylinder block top surface distortion	Limit		0.1 (0.004)
Cylinder bore inner diameter	Standard	Grade No. 1	79.700 - 79.710 (3.1378 - 3.1382)
		Grade No. 2	79.710 - 79.720 (3.1382 - 3.1386)
Out-of-round	Limit		0.015 (0.0006)
Taper			0.010 (0.0004)

# SERVICE DATA AND SPECIFICATIONS (SDS)


< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Main bearing housing inner diameter grade	Grade No. A	55.997 - 55.998 (2.2046 - 2.2046)	A
	Grade No. B	55.998 - 55.999 (2.2046 - 2.2047)	
	Grade No. C	55.999 - 56.000 (2.2047 - 2.2047)	
	Grade No. D	56.000 - 56.001 (2.2047 - 2.2048)	EM
	Grade No. E	56.001 - 56.002 (2.2048 - 2.2048)	
	Grade No. F	56.002 - 56.003 (2.2048 - 2.2048)	
	Grade No. G	56.003 - 56.004 (2.2048 - 2.2049)	C
	Grade No. H	56.004 - 56.005 (2.2049 - 2.2049)	
	Grade No. J	56.005 - 56.006 (2.2049 - 2.2050)	D
	Grade No. K	56.006 - 56.007 (2.2050 - 2.2050)	
	Grade No. L	56.007 - 56.008 (2.2050 - 2.2050)	
	Grade No. M	56.008 - 56.009 (2.2050 - 2.2051)	E
	Grade No. N	56.009 - 56.010 (2.2051 - 2.2051)	
	Grade No. P	56.010 - 56.011 (2.2051 - 2.2052)	F
	Grade No. R	56.011 - 56.012 (2.2052 - 2.2052)	
	Grade No. S	56.012 - 56.013 (2.2052 - 2.2052)	
	Grade No. T	56.013 - 56.014 (2.2052 - 2.2053)	G
	Grade No. U	56.014 - 56.015 (2.2053 - 2.2053)	
	Grade No. V	56.015 - 56.016 (2.2053 - 2.2053)	H
	Grade No. W	56.016 - 56.017 (2.2053 - 2.2054)	

## AVAILABLE PISTON

Unit: mm (in)



PBIC0188E

Piston skirt diameter “A”	Standard	Grade No. 1	79.670 - 79.680 (3.1366 - 3.1370)
		Grade No. 2	79.680 - 79.690 (3.1370 - 3.1374)
Measure point “H”			43.4 (1.7087)
Piston pin hole diameter			21.993 - 21.999 (0.8658 - 0.8661)
Piston to cylinder bore clearance	Standard		0.020 - 0.040 (0.0008 - 0.0016)
	Limit		0.08 (0.0031)

## PISTON RING

Unit: mm (in)

Items		Standard	Limit
Piston ring side clearance	Top	0.04 - 0.08 (0.0016 - 0.0031)	0.11 (0.0043)
	2nd	0.03 - 0.07 (0.0012 - 0.0028)	0.10 (0.0039)
	Oil ring	0.055 - 0.155 (0.0022 - 0.0061)	—

# SERVICE DATA AND SPECIFICATIONS (SDS)

## < SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Piston ring end gap	Top	0.19 - 0.29 (0.0075 - 0.0114)	0.48 (0.0189)
	2nd	0.29 - 0.44 (0.0114 - 0.0173)	0.60 (0.0236)
	Oil (rail ring)	0.15 - 0.45 (0.0059 - 0.0177)	0.76 (0.0299)

## PISTON PIN

Unit: mm (in)

Items	Standard	Limit
Piston pin outer diameter	21.989 - 21.995 (0.8657 - 0.8659)	—
Piston to piston pin oil clearance	0.002 - 0.006 (0.0001 - 0.0002)	—

## CONNECTING ROD


Unit: mm (in)

Center distance		138.97 - 139.07 (5.47 - 5.48)
Bend [per 100 (3.94)]	Limit	0.15 (0.0059)
Torsion [per 100 (3.94)]	Limit	0.30 (0.0118)
Connecting rod bushing inner diameter*	Standard	22.000 - 22.012 (0.8661 - 0.8666)
Connecting rod bushing oil clearance	Standard	0.005 - 0.023 (0.0002 - 0.0009)
	Limit	0.03 (0.0012)
Connecting rod side clearance	Standard	0.20 - 0.35 (0.0079 - 0.0138)
	Limit	0.4 (0.016)
Connecting rod big end diameter grade	Grade No. A	47.000 - 47.001 (1.8504 - 1.8504)
	Grade No. B	47.001 - 47.002 (1.8504 - 1.8505)
	Grade No. C	47.002 - 47.003 (1.8505 - 1.8505)
	Grade No. D	47.003 - 47.004 (1.8505 - 1.8505)
	Grade No. E	47.004 - 47.005 (1.8505 - 1.8506)
	Grade No. F	47.005 - 47.006 (1.8506 - 1.8506)
	Grade No. G	47.006 - 47.007 (1.8506 - 1.8507)
	Grade No. H	47.007 - 47.008 (1.8507 - 1.8507)
	Grade No. J	47.008 - 47.009 (1.8507 - 1.8507)
	Grade No. K	47.009 - 47.010 (1.8507 - 1.8508)
	Grade No. L	47.010 - 47.011 (1.8508 - 1.8508)
	Grade No. M	47.011 - 47.012 (1.8508 - 1.8509)
	Grade No. N	47.012 - 47.013 (1.8509 - 1.8509)


\*: After installing in connecting rod

## CRANKSHAFT

Unit: mm (in)



SEM645



PBIC3459J

Center distance "r"	40.41 - 40.49 (1.5909 - 1.5940)
---------------------	---------------------------------

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

Out-of-round	Limit	0.0035 (0.0001)	A
Taper	Limit		
Runout [TIR*]	Standard	0.05 (0.0020)	EM
	Limit	0.10 (0.0039)	
Crankshaft end play	Standard	0.10 - 0.26 (0.0039 - 0.0102)	
	Limit	0.30 (0.0118)	
Crankshaft pin journal diameter "Dp" grade.	Grade No. A	43.970 - 43.971 (1.7311 - 1.7311)	C
	Grade No. B	43.969 - 43.970 (1.7311 - 1.7311)	
	Grade No. C	43.968 - 43.969 (1.7310 - 1.7311)	D
	Grade No. D	43.967 - 43.968 (1.7310 - 1.7310)	
	Grade No. E	43.966 - 43.967 (1.7309 - 1.7310)	E
	Grade No. F	43.965 - 43.966 (1.7309 - 1.7309)	
	Grade No. G	43.964 - 43.965 (1.7309 - 1.7309)	
	Grade No. H	43.963 - 43.964 (1.7308 - 1.7309)	F
	Grade No. J	43.962 - 43.963 (1.7308 - 1.7308)	
	Grade No. K	43.961 - 43.962 (1.7307 - 1.7308)	
	Grade No. L	43.960 - 43.961 (1.7307 - 1.7307)	G
	Grade No. M	43.959 - 43.960 (1.7307 - 1.7307)	
	Grade No. N	43.958 - 43.959 (1.7306 - 1.7307)	
	Grade No. P	43.957 - 43.958 (1.7306 - 1.7306)	H
	Grade No. R	43.956 - 43.957 (1.7305 - 1.7306)	
	Grade No. S	43.955 - 43.956 (1.7305 - 1.7305)	I
	Grade No. T	43.954 - 43.955 (1.7305 - 1.7305)	
	Grade No. U	43.953 - 43.954 (1.7304 - 1.7305)	J
Crankshaft main journal diameter "Dm" grade.	Grade No. A	51.978 - 51.979 (2.0464 - 2.0464)	
	Grade No. B	51.977 - 51.978 (2.0463 - 2.0464)	
	Grade No. C	51.976 - 51.977 (2.0463 - 2.0463)	K
	Grade No. D	51.975 - 51.976 (2.0463 - 2.0463)	
	Grade No. E	51.974 - 51.975 (2.0462 - 2.0463)	
	Grade No. F	51.973 - 51.974 (2.0462 - 2.0462)	L
	Grade No. G	51.972 - 51.973 (2.0461 - 2.0462)	
	Grade No. H	51.971 - 51.972 (2.0461 - 2.0461)	
	Grade No. J	51.970 - 51.971 (2.0461 - 2.0461)	M
	Grade No. K	51.969 - 51.970 (2.0460 - 2.0461)	
	Grade No. L	51.968 - 51.969 (2.0460 - 2.0460)	N
	Grade No. M	51.967 - 51.968 (2.0459 - 2.0460)	
	Grade No. N	51.966 - 51.967 (2.0459 - 2.0459)	
	Grade No. P	51.965 - 51.966 (2.0459 - 2.0459)	O
	Grade No. R	51.964 - 51.965 (2.0458 - 2.0459)	
	Grade No. S	51.963 - 51.964 (2.0458 - 2.0458)	P
	Grade No. T	51.962 - 51.963 (2.0457 - 2.0458)	
	Grade No. U	51.961 - 51.962 (2.0457 - 2.0457)	
	Grade No. V	51.960 - 51.961 (2.0457 - 2.0457)	
	Grade No. W	51.959 - 51.960 (2.0456 - 2.0457)	

\*: Total indicator reading

## SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

### Connecting Rod Bearing

INFOID:000000007577502

#### CONNECTING ROD BEARING GRADE TABLE

Unit: mm (in)

Grade number		Thickness	Identification color	Remarks
0		1.494 - 1.497 (0.0588 - 0.0589)	Black	Grade and color are the same for upper and lower bearings.
1		1.497 - 1.500 (0.0589 - 0.0591)	Brown	
2		1.500 - 1.503 (0.0591 - 0.0592)	Green	
3		1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
4		1.506 - 1.509 (0.0593 - 0.0594)	Blue	
01	UPR	1.494 - 1.497 (0.0588 - 0.0589)	Black	Grade and color are different between upper and lower bearings.
	LWR	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
12	UPR	1.497 - 1.500 (0.0589 - 0.0591)	Brown	
	LWR	1.500 - 1.503 (0.0591 - 0.0592)	Green	
23	UPR	1.500 - 1.503 (0.0591 - 0.0592)	Green	
	LWR	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
34	UPR	1.503 - 1.506 (0.0592 - 0.0593)	Yellow	
	LWR	1.506 - 1.509 (0.0593 - 0.0594)	Blue	

#### UNDERSIZE TABLE

Unit: mm (in)

Items	Thickness	Crank pin journal diameter
US 0.25 (0.0098)	1.623 - 1.631 (0.0639 - 0.0642)	Grind so that bearing clearance is the specified value.

#### CONNECTING ROD BEARING OIL CLEARANCE

Unit: mm (in)

Connecting rod bearing oil clearance	Standard	0.037 - 0.047 (0.0015 - 0.0019)
	Limit	0.07 (0.0028)

### Main Bearing

INFOID:000000007577503

#### MAIN BEARING GRADE TABLE (ALL JOURNALS)

Unit: mm (in)

Grade number	Thickness	Identification color	Remarks
0	1.996 - 1.999 (0.0786 - 0.0787)	Black	Grade and color are the same for upper and lower bearings.
1	1.999 - 2.002 (0.0787 - 0.0788)	Brown	
2	2.002 - 2.005 (0.0788 - 0.0789)	Green	
3	2.005 - 2.008 (0.0789 - 0.0791)	Yellow	
4	2.008 - 2.011 (0.0791 - 0.0792)	Blue	
5	2.011 - 2.014 (0.0792 - 0.0793)	Pink	
6	2.014 - 2.017 (0.0793 - 0.0794)	Purple	
7	2.017 - 2.020 (0.0794 - 0.0795)	White	



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[MR16DDT ]

01	UPR	1.996 - 1.999 (0.0786 - 0.0787)	Black	Grade and color are different between upper and lower bearings.	A
	LWR	1.999 - 2.002 (0.0787 - 0.0788)	Brown		
12	UPR	1.999 - 2.002 (0.0787 - 0.0788)	Brown		EM
	LWR	2.002 - 2.005 (0.0788 - 0.0789)	Green		
23	UPR	2.002 - 2.005 (0.0788 - 0.0789)	Green		C
	LWR	2.005 - 2.008 (0.0789 - 0.0791)	Yellow		
34	UPR	2.005 - 2.008 (0.0789 - 0.0791)	Yellow		D
	LWR	2.008 - 2.011 (0.0791 - 0.0792)	Blue		
45	UPR	2.008 - 2.011 (0.0791 - 0.0792)	Blue		E
	LWR	2.011 - 2.014 (0.0792 - 0.0793)	Pink		
56	UPR	2.011 - 2.014 (0.0792 - 0.0793)	Pink		F
	LWR	2.014 - 2.017 (0.0793 - 0.0794)	Purple		
67	UPR	2.014 - 2.017 (0.0793 - 0.0794)	Purple		G
	LWR	2.017 - 2.020 (0.0794 - 0.0795)	White		

## UNDERSIZE TABLE

Unit: mm (in)

Items	Thickness	Main journal diameter
US 0.25 (0.0098)	2.126 - 2.134 (0.0837 - 0.0840)	Grind so that bearing clearance is the specified value.

## MAIN BEARING OIL CLEARANCE

Unit: mm (in)

Main bearing oil clearance	Standard	No. 1, 4 and 5	0.024 - 0.034 (0.0009 - 0.0013)
		No. 2 and 3	0.012 - 0.022 (0.0005 - 0.0009)
	Limit		0.065 (0.0026)