В


This manual provides information on the electrical circuits installed on vehicles by dividing them into a circuit for each system.

The actual wiring of each system circuit is shown from the point where the power source is received from the battery as far as each ground point. (All circuit diagrams are shown with the switches in the OFF position.)

When troubleshooting any problem, first understand the operation of the circuit where the problem was detected (see System Circuit section), the power source supplying power to that circuit (see Power Source section), and the ground points (see Ground Points section). See the System Outline to understand the circuit operation.

When the circuit operation is understood, begin troubleshooting of the problem circuit to isolate the cause. Use Relay Location and Electrical Wiring Routing sections to find each part, junction block and wiring harness connectors, wiring harness and wiring harness connectors, splice points, and ground points of each system circuit. Internal wiring for each junction block is also provided for better understanding of connection within a junction block.

Wiring related to each system is indicated in each system circuit by arrows (from___,to__). When overall connections are required, see the Overall Electrical Wiring Diagram at the end of this manual.




(A): System Title

B: Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B.

Example: 1 Indicates Relay Block No. 1.


C: Indicates the connector to be connected to a part (the numeral indicates the pin No.)

Explanation of pin use.



The pins shown are only for the highest grade, or only include those in the specification.

- D: Connector Color Connectors not indicated are milky white in color:
- (E): () is used to indicate different wiring and connector, etc. when the vehicle model, engine type, or specification is different.
- (F): Indicates related system.
- (G): Indicates the wiring harness and wiring harness connector. The wiring harness with male terminal is shown with arrows ().




The first letter of the code for each wiring harness and wiring harness connector(s) indicates the component's location, e.g, "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

When more than one code has the first and second letters in common, followed by numbers (e.g, IH1, IH2), this indicates the same type of wiring harness and wiring harness connector.

- (H): Represents a part (all parts are shown in sky blue). The code is the same as the code used in parts position.
- Junction Block (The number in the circle is the J/B No. and the connector code is shown beside it). Junction Blocks are shaded to clearly separate them from other parts.

Example:



Indicates the wiring color.
 Wire colors are indicated by an alphabetical code.

The first letter indicates the basic wire color and the second letter indicates the color of the stripe.

Example: L-Y (blue) (yellow)

K: Indicates a wiring Splice Point (Codes are "E" for the Engine Room, "I" for the Instrument Panel, and "B" for the Body).





The Location of Splice Point I 5 is indicated by the shaded section.

- L): Page No.
- (M): Indicates a shielded cable.




(N): Indicates a ground point.

The first letter of the code for each ground point(s) indicates the component's location, e.g. "E" for the Engine Compartment, "I" for the Instrument Panel and Surrounding area, and "B" for the Body and Surrounding area.

O: Indicates the pin number of the connector.

The numbering system is different for female and male connectors.



P: When 2 parts both use one connector in common, the parts connector name used in the wire routing section is shown in square brackets [].

B HOW TO USE THIS MANUAL

(Q)

SYSTEM OUTLINE

WITH THE IGNITION SW TURNED ON, THE CURRENT FLOWS TO TERMINAL 3 OF THE POWER WINDOW MASTER SW, TERMINAL 2 OF THE POWER WINDOW CONTROL RELAY AND TERMINAL 8 OF THE POWER WINDOW SW THROUGH THE DOOR FUSE.

1. DRIVER'S WINDOW "MANUAL UP" OPERATION BY MASTER SW

HOLDING MANUAL SW (DRIVER'S) ON "UP" POSITION LOCATED IN POWER WINDOW MASTER SW, THE CURRENT FLOWS TO **TERMINAL 5** OF THE POWER WINDOW CONTROL RELAY. THUS THE CURRENT INSIDE THE RELAY FLOWS FROM **TERMINAL 2** OF THE RELAY \rightarrow **TERMINAL 1** \rightarrow **TERMINAL 1** \rightarrow **TERMINAL 2** OF THE POWER WINDOW MOTOR \rightarrow **TERMINAL 1** \rightarrow **TERMINAL 4** OF THE RELAY \rightarrow **TERMINAL 3** \rightarrow TO **GROUND**. THE MOTOR TURNS TO ASCENT THE WINDOW. RELEASING THIS SW, THE ROTATION OF MOTOR IS STOPPED AND THE WINDOWS CAN STOP AT WILL POINT.

(FOR THE "MANUAL DOWN" OPERATION, CURRENT FLOWS IN THE REVERSE DIRECTION BECAUSE THE TERMINALS WHERE IT FLOW ARE CHANGED).

2. DRIVER'S WINDOW "AUTO DOWN" OPERATION BY MASTER SW

ONCE THE "AUTO DOWN" BUTTON OF THE MASTER SW IS PUSHED, THE CURRENT FLOW **TERMINAL 9** OF THE POWER WINDOW CONTROL RELAY THROUGH **TERMINAL 3** OF THE MASTER SW **TERMINALS 8** AND **9** TO OPERATE THE RELAY. THUS THE CURRENT INSIDE THE POWER WINDOW CONTROL RELAY FLOWS FROM **TERMINAL 2** OF THE RELAY \rightarrow **TERMINAL 1** OF THE POWER WINDOW MOTOR \rightarrow **TERMINAL 2** \rightarrow **TERMINAL 3** \rightarrow TO **GROUND**. THE MOTOR CONTINUES THE ROTATION ENABLING TO DESCENT THE WINDOW.

THE WINDOW DESCENDS TO THE END POSITION. THE CURRENT WILL BE CUT OFF TO RELEASE THE AUTO DOWN FUNCTION BASED ON THE INCREASING CURRENT BETWEEN TERMINAL 2 OF THE RELAY AND TERMINAL 1 IN RELAY.

3. DRIVER'S WINDOW AUTO DOWN RELEASE OPERATION BY MASTER SW

HOLDING THE MANUAL SW (DRIVER'S) ON "UP" POSITION IN OPERATING AUTO DOWN. THE CURRENT FROM **TERMINAL 3** OF THE MASTER SW PASSING **TERMINAL 2** FLOWS **TERMINAL 5** OF THE RELAY AND RELEASES THE AUTO DOWN FUNCTION IN THE POWER WINDOW CONTROL RELAY. RELEASING THE HAND FROM SW, WINDOW STOPS AND CONTINUING ON TOUCHING SW. THE FUNCTION SWITCHES TO MANUAL UP OPERATION.

4. PASSENGER'S WINDOW UP OPERATION (MASTER SW) AND WINDOW LOCK SW OPERATION

HOLDING PASSENGER'S WINDOW SW (MASTER SW) ON "UP", THE CURRENT FLOWS FROM **TERMINAL 3** OF THE MASTER SW PASSING **TERMINAL 6** TO **TERMINAL 3** OF THE POWER WINDOW SW (PASSENGER'S) \rightarrow **TERMINAL 4 TERMINAL** \rightarrow **2** OF THE MOTOR \rightarrow **TERMINAL 1** \rightarrow **TERMINAL 9** OF THE POWER WINDOW SW \rightarrow **TERMINAL 7** \rightarrow **TERMINAL 1** OF THE MASTER SW \rightarrow **TERMINAL 4** TO **GROUND**. THE MOTOR RUNS TO ASCENT THE WINDOW. RELEASING THIS SW, THE ROTATION OF MOTOR IS STOPPED AND WINDOW CAN STOP AT WILL PLACE. SWITCHING THE WINDOW LOCK SW IN "LOCK" POSITION, THE CIRCUIT IS OPENED AND STOPPED THE MOTOR ROTATION.

(R)

(FOR THE DOWN OPERATION, CURRENT FLOWS IN THE REVERSE DIRECTION BECAUSE THE TERMINALS WHERE IT FLOWS ARE CHANGED).

SERVICE HINTS

P 2 POWER WINDOW CONTROL RELAY

3-GROUND: ALWAYS CONTINUITY

2-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT **ON** POSITION

5-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE MASTER SW AT UP POSITION

8-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE MASTER SW AT AUTO DOWN POSITION

9-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION AND THE MASTER SW AT DOWN OR AUTO DOWN POSITION

P 4 POWER WINDOW MASTER SW

4-GROUND: ALWAYS CONTINUITY

3-GROUND: APPROX. 12 VOLTS WITH THE IGNITION SW AT ON POSITION

WINDOW LOCK SW

(S)	

OPEN WITH THE WINDOW LOCK SW AT LOCK POSITION

	: PARTS	LOCATION					
l	CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE	
	P2	21	P4	21	P6	21	
				24			

(T)

: REL	AY BLOCKS	
CODE	SEE PAGE	RELAY BLOCK (RELAY BLOCK LOCATION)

1 16 R/B NO. 1 (INSTRUMENT PANEL LEFT)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR		NESS CONNECTOR
CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)

38 14 J/B NO. 3 AND COWL WIRE (INSTRUMENT PANEL LEFT SIDE)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS		
CODE	SEE PAGE	JOINING WIRE HARNESS AND WIRE HARNESS (CONNECTOR LOCATION)
ID1	26	FRONT DOOR RH WIRE AND COWL WIRE (RIGHT KICK PANEL)

H1 26 FRONT DOOR LH WIRE AND COWL WIRE (RIGHT NICK PANEL)

COWL LEFT

: GROUND POINTS		
CODE	SEE PAGE	GROUND POINT LOCATION

ソ	\cup					
	: SPLICE	POINTS				
	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS

15 24 COWL WIRE

- Q: Explains the system outline.
- R: Indicates values or explain the function for reference during troubleshooting.
- S: Indicates the reference page showing the position on the vehicle of the parts in the system circuit.

Example: Part "P 4" (Power Window Master SW) is on page 21 of the manual.

* The letter in the code is from the first letter of the part, and the number indicates its order in parts starting with the letter.

Example: P4
Part is 4th in order
Power Window Master SW

T: Indicates the reference page showing the position on the vehicle of Relay Block Connectors in the system circuit.

Example: Connector "1" is described on page 16 on this manual and is installed on the left side of the instrument panel.

(U): Indicates the reference page showing the position on the vehicle of J/B and Wire Harness in the system circuit.

Example: Connector "3B" connects the Cowl Wire and J/B No. 3. It is described on page 14 of this manual, and is installed on the instrument panel left side.

(V): Indicates the reference page describing the wiring harness and wiring harness connector (the female wiring harness is shown first, followed by the male wiring harness).

Example: Connector "ID1" connects the front door RH wire (female) and cowl wire (male). It is described on page 26 of this manual, and is installed on the right side kick panel.


W: Indicates the reference page showing the position of the ground points on the vehicle.

Example: Ground point "IC" is described on page 24 of this manual and is installed on the cowl left side.

(X): Indicates the reference page showing the position of the splice points on the vehicle.

Example: Splice point "I 5" is on the Cowl Wire Harness and is described on page 24 of this manual.

HINTS:



Junction connector (code: J1 to J19) in this manual include a short terminal which is connected to a number of wire harnesses. Always perform inspection with the short terminal installed. (When installing the wire harnesses, the harnesses can be connected to any position within the short terminal grouping. Accordingly, in other vehicles, the same position in the short terminal may be connected to a wire harness from a different part.)

Wire harness sharing the same short terminal grouping have the same color.


B HOW TO USE THIS MANUAL

The "Current Flow Chart" section, describes which parts each power source (fuses, fusible links, and circuit breakers) transmits current to. In the Power Source circuit diagram, the conditions when battery power is supplied to each system are explained. Since all System Circuit diagrams start from the power source, the power source system must be fully understood.


H POWER SOURCE (CURRENT FLOW CHART)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.

The next page and following pages shown the parts to which each electrical source outputs current.



POWER SOURCE



^{*} The system shown here is an EXAMPLE ONLY. It is different to the actual circuit shown in the SYSTEM CIRCUITS SECTION.


The ground points circuit diagram shows the connections from all major parts to the respective ground points. When troubleshooting a faulty ground point, checking the system circuits which use a common ground may help you identify the problem ground quickly. The relationship between ground points (and) con also be checked this way.

GROUND POINT HEATER CONTROL CIGARETTE LIGHTER FAN HAIN RELAT EATER SERVO D/D MAIN SW FAN HAIN RELAY CLOCK LOWER SW A/C FAN RELAY NO.2 PARKING BRAKE SW A/C FAN RELAY NO.3 RADIATOR FAN HOTOR BETRACT CONTROL COMBINATION METER HORN SW (COMB. SW) RETRACT MOTOR RH DIMMER SE RETRACT MOTOR LM FRONT TURN SIGNAL CRUISE CONTROL FRONT SIDE MARKER REMOTE CONTROL FRONT SIDE MARKER PARKING LIGHT BH BRAKE FLUID LEVEL TURN SIGNAL FLASHER REAR WINDOW DEFORGER SW PARKING LIGHT LH DOOR LOCK CONTROL DOOR KEY LOCK SW RE UNLOCK WARNING DOOR LOCK MOTOR RH CONTROL RELAY DOOR KEY LOCK SW LH BLOWER RESISTOR DOOR LOCK CONTROL ELECTRICAL MOLE-UP BOOR LOCK HOTOR LH A/C AMPLIFIER FUEL CONTROL SM WOOFER AMPLIFIER RADIO AND PLAYER CONSINATION METER HEATER RELAY COMBINATION METER AUTO ANTENNA MOTOR FUEL SEMDER

A INTRODUCTION

This manual consists of the following 11 sections:

No.	Section	Description
A	INDEX	Index of the contents of this manual.
	INTRODUCTION	Brief explanation of each section.
В	HOW TO USE THIS MANUAL	Instructions on how to use this manual.
С	TROUBLE- SHOOTING	Describes the basic inspection procedures for electrical circuits.
D	ABBREVIATIONS	Defines the abbreviations used in this manual.
E	GLOSSARY OF TERMS AND SYMBOLS	Defines the symbols and functions of major parts.
F	RELAY LOCATIONS	Shows position of the Electronic Control Unit, Relays, Relay Block, etc. This section is closely related to the system circuit.
G	ELECTRICAL WIRING ROUTING	Describes position of Parts Connectors, Splice points, Ground points, etc. This section is closely related to the system circuit.
Н	POWER SOURCE (Current Flow Chart)	Describes power distribution from the power supply to various electrical loads.
	INDEX	Index of the system circuits.
I	SYSTEM CIRCUITS	Electrical circuits of each system are shown from the power supply through ground points. Wiring connections and their positions are shown and classified by code according to the connection method. (Refer to the section, "How to sue this manual"). The "System Outline" and "Service Hints" useful for troubleshooting are also contained in this section.
J	GROUND POINTS	Shows ground positions of all the parts decribed in this manual.
К	OVERALL ELECTRICAL WIRING DIAGRAM	Provides circuit diagrams showing the circuit connections.



VOLTAGE CHECK

(a) Establish conditions in which voltage is check point.


Example:

A Ignition SW on

B- Ignition SW and SW 1 on


©- Ignition SW, SW 1 and Relay on (SW2 off)

(b) Using a voltmeter, connect the negative lead to a ground point or negative battery terminal, and a positive lead to the connector or component terminal. This check can be done with a test light instead of a voltmeter.



CONTINUITY AND RESISTANCE CHECK


- (a) Disconnect the battery terminal or wire so there is no voltage between the check points.
- (b) Contact the two leads of an ohmmeter to each of the check point.




If the circuit has diodes, reverse the two leads and check again.

When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.



(c) Use the volt/ohmmeter with high impedance (10kΩ/V minimum) for troubleshooting of the electrical circuit.



FINDING A SHORT CIRCUIT

- (a) Remove the blown fuse and disconnect all loads of the fuse.
- (b) Connect a test light in place of the fuse.
- (c) Establish conditions in which the test light comes on.

Example:

- (A) Ignition SW on
- B- Ignition SW and SW 1 on
- C Ignition SW, SW 1 and Relay on (Connect the Relay) and SW 2 off (or Disconnect SW 2)
- (d) Disconnect and reconnect the connectors while watching the test light.

The short lies between the connector where the test light stays lit and the connector where the light goes out.

(e) Find the exact location of the short by lightly shaking the problem wire along the body.


CAUTION:

- (a) Do not open the cover or the case of the ECU unless absolutely necessary. (If the IC terminals are touched, the IC may be destroyed by static electricity.)
- (b) When replacing the internal mechanism (ECU part) of the digital meter, be careful that no part of your body or clothing comes in contact with the terminals of leads from the IC, etc. of the replacement part (spare part).


DISCONNECTION OF MALE AND FEMALE CONNECTORS


To pull apart the connectors, pull on the connector itself, not the wire harness.


HINT: Check to see what kind of connector you are disconnecting before pulling apart.




C TROUBLESHOOTING









HOW TO REPLACE TERMINAL (with terminal retainer or secondary locking device)

1 PREPARE THE SPECIAL TOOL

HINT: To remove the terminal from the connector, please construct and use the special tool or like object shown on the left.

- 2. DISCONNECT CONNECTOR
- 3. DISENGAGE THE SECONDARY LOCKING DEVICE OR TERMINAL RETAINER
 - (a) Locking device must be disengaged before the terminal locking clip can be released and the terminal removed from the connector.
 - (b) Use a special tool or the terminal pick to unlock the secondary locking device or terminal retainer.

NOTICE:

Do not remove the terminal retainer from connector body.

(1) For Non–Waterproof Type Connector


HINT: The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.


"Case 1"


Raise the terminal retainer up to the temporary lock position.


"Case 2"

Open the secondary locking device.









B For Waterproof Type Connector

HINT: Terminal retainer color is different according to connector body.

Example:

<u>Terminal Retainer</u> : <u>Connector Body:</u>

Black or White :Gray
Black or White :Dark Gray
Gray or White :Black

"Case 1"

Type where terminal retainer is pulled up to the temporary lock position (Pull Type).


Insert the special tool into the terminal retainer access hole (▲Mark) and pull the terminal retainer up to the temporary lock position.

HINT: The needle insertion position varies according to the connector's shape (number of terminals etc.), so check the position before inserting it.


"Case 2"

Type which cannot be pulled as far as Power Lock insert the tool straight into the access hole of terminal retainer as shown.


C TROUBLESHOOTING



Push the terminal retainer down to the temporary lock position.



(c) Release the locking lug from terminal and pull the terminal out from rear.




4. INSTALL TERMINAL TO CONNECTOR


(a) Insert the terminal.

HINT:

- 1. Make sure the terminal is positioned correctly.
- 2. Insert the terminal until the locking lug locks firmly.
- 3. Insert the terminal with terminal retainer in the temporary lock position.



5. CONNECT CONNECTOR



ABBREVIATIONS

The following abbreviations are used in this manual.

ABS = Anti–Lock Brake System

A/C = Air Conditioning

A/T = Automatic Transaxle

COMB. = Combination

ECU = Electronic Control Unit

ESA = Electronic Spark Advance

FL = Fusible Link

IAC = Idle Air Control

IC = Integrated Circuit

J/B = Junction Block

LH = Left-Hand

M/T = Manual Transaxle

O/D = Overdrive

ORVR = On-Board Refueling Vapor Recovery

R/B = Relay Block

RH = Right-Hand

SFI = Sequential Multiport Fuel Injection

SRS = Supplemental Restraint System

SW = Switch


TEMP. = Temperature

VSV = Vacuum Switching Valve


w/ = With

w/o = Without

^{*} The titles given inside the components are the names of the terminals (terminal codes) and are not treated as being abbreviations.



section surface area of the wires.



RELAY

1. **NORMALLY CLOSED**

Basically, an electrically operated switch which flow through a small



SPEAKER

An electromechanical device which creates sound waves from current flow.



may be normally closed (1) or open (2). Current coil creates a magnetic field which either opens or closes an attached switch.



SWITCH, MANUAL

NORMALLY OPEN

Open and closes circuits, thereby stopping (1) or allowing (2) current flow.



RELAY, DOUBLE THROW

A relay which passes current through one set of contacts or the other.



NORMALLY CLOSED

RESISTOR

An electrical component with a fixed resistance, placed in a circuit to reduce voltage to a specific value.



SWITCH. DOUBLE THROW

A switch which continuously passes cureent through one set of contacts or the other.




RESISTOR, TAPPED

RHEOSTAT

RESISTOR, VARIABLE or

A resistor which supplies two or more different non adjustable resistance values.



SWITCH. **IGNITION**

A key operated switch with several positions which allows various circuits, particularly the primary ignition circuit, to become operational.



A controllable resistor with a variable rate of resistance. Also called a potentiometer or rheostat.



SENSOR (Thermistor)

A resistor which varies its resistance with temperature.



SWITCH, WIPER PARK


Automatically returns wipers to the stop position when the wiper switch is turned off.



(Reed Switch Type)

SENSOR, SPEED

Uses magnetic impulses to open and close a switch to create a signal for activation of other components.



TRANSISTOR

A solid state device typically used as an electronic relay; stops or passes current depending on the voltage applied at "base."

Wires are always



SHORT PIN

Used to provide an unbroken connection within a juction block.



WIRES

(1) NOT **CONNECTED**

drawn as straight lines on wiring diagrams. Crossed wires (1) without a black dot at the junction are not ioined: crossed wires (2) and a black dot or



SOLENOID

An electromagnetic coil which forms a magnetic field when current flows, to move a plunger, etc.




(2) SPLICED

octagonal (O) mark at the juction as spliced (joined) connections.


F RELAY LOCATIONS

[Engine Compartment]




[Body]

18




[Instrument Panel]




1 : Driver Side R/B

Left Kick Panel (See Page 19)




5 : Engine Room R/B No. 5


Engine Compartment Left (See Page 18)




6 : Engine Room R/B No. 6

Radiator Support RH (See Page 18)






(Inner Circuit: See Page 30)




: Driver Side J/B

Left Kick Panel (See Page 19)




(Inner Circuit: See Page 31)




: Engine Room J/B

Engine Compartment Left (See Page 18)

- *1: HEAD (RH) or HEAD (RH-UPR)
- *2: HEAD (LH) or HEAD (LH-UPR)
- *3: EFI or F-HTR




(Inner Circuit: See Page 32)



: Center J/B


Behind the Combination Meter (See Page 19)

(Inner Circuit: See Page 33)




[Instrument Panel J/B Inner Circuit]

*1: DEF I-UP/M-HTR




[Driver Side J/B Inner Circuit]




[Engine Room J/B Inner Circuit]


- *1: HEAD (RH) or HEAD (RH-UPR)
- *2: HEAD (LH) or HEAD (LH-UPR)
- *3: EFI or F-HTR



[Center J/B Inner Circuit]




Position of Parts in Engine Compartment



- A1 A/C Condenser Fan Motor
- A2 A/C Magnetic Clutch and Lock Sensor
- A3 A/C Triple Pressure SW
 (A/C Dual and Single Pressure SW)
- A4 ABS Actuator and ECU
- A5 ABS Speed Sensor Front LH
- A6 ABS Speed Sensor Front RH
- A7 Airbag Sensor Front LH
- A8 Airbag Sensor Front RH
- A9 Ambient Temp. Sensor
- B1 Back-Up Light SW
- B2 Brake Fluid Level Warning SW
- C1 Camshaft Position Sensor
- C2 Carnakshaft Position Sensor
- C3 Cruise Control Actuator

- D1 Data Link Connector 1
- E1 Electronically Controlled Transmission Solenoid
- E2 Engine Coolant Temp.
 Sensor and Water Temp. Sender
- E3 Engine Hood Courtesy SW
- F1 Front Turn Signal and Parking Light LH
- F2 Front Turn Signal and Parking Light RH
- F3 Front Wiper Motor
- F4 Fusible Link Block
- G1 Generator
- G2 Generator


Position of Parts in Engine Compartment



- H1 Headlight LH
- H2 Headlight RH
- H3 Heated Oxygen Sensor (Bank 1 Sensor 1)
- H4 Horn
- 11 Idle Air Control Valve
- 12 Ignition Coil and Igniter No. 1
- 13 Ignition Coil and Igniter No. 2
- 14 Injector No. 1
- I5 Injector No. 2
- I6 Injector No. 3
- I7 Injector No. 4
- 18 Intake Air Temp. Sensor
- K1 Knock Sensor
- M1 Manifold Absolute Pressure Sensor
- O1 Oil Pressure SW

- P1 Park/Neutral Position SW
- P2 Power Steering Oil Pressure SW
- R1 Radiator Fan Motor
- S1 Starter
- S2 Starter
- T1 Theft Deterrent Horn
- T2 Throttle Position Sensor
- V1 Vehicle Speed Sensor
- V2 VSV (ORVR)
- W1 Washer Level Warning SW
- W2 Washer Motor
- W3 Water Temp. SW (Radiator Fan)

Position of Parts in Instrument Panel



A10 A/C Amplifier

A11 A/C Evaporator Temp. Sensor

A12 A/C SW

A13 Airbag Squib (Front Passenger Airbag Assembly)

A14 Airbag Squib (Steering Wheel Pad)

A15 Ashtray Illumination

A16 Automatic Light Control Sensor

B3 Blower Motor

B4 Blower Resistor

B5 Blower SW

C4 Center Airbag Sensor Assembly

C5 Center Airbag Sensor Assembly

C6 Center Airbag Sensor Assembly

C7 Cigarette Lighter

C8 Cigarette Lighter Illumination

C9 Clock

C10 Clutch Start SW

C11 Combination Meter

C12 Combination Meter

C13 Combination Meter

C14 Combination Meter

C15 Combination SW

C16 Combination SW

C17 Combination SW

C18 Cruise Control Clutch SW

C19 Cruise Control ECU

D2 Data Link Connector 3

D3 Daytime Running Light Relay (Main)

D4 Diode (Daytime Running Light)

D5 Diode (Door Courtesy)

E4 Engine Control Module


E5 Engine Control Module

E6 Engine Control Module

H5 Hazard SW

H6 Heated Oxygen Sensor (Bank 1 Sensor 2)


Position of Parts in Instrument Panel



- 19 Ignition Key Cylinder Light
- I10 Ignition SW
- **I11 Intergration Relay**
- **I12 Intergration Relay**
- J1 Junction Connector
- J2 Junction Connector
- J3 Junction Connector
- J4 Junction Connector
- J5 Junction Connector
- J6 Junction Connector
- J7 Junction Connector
- J8 Junction Connector
- J9 Junction Connector
- J10 Junction Connector
- J11 Junction Connector
- J12 Junction Connector
- J13 Junction Connector
- J14 Junction Connector
- N1 Noise Filter (Ignition)

- P3 Parking Brake SW
- R2 Radio and Player
- R3 Radio and Player
- R4 Rear Window Defogger SW
- R5 Remote Control Mirror SW
- R6 Rheostat
- S3 Shift Lock ECU
- S4 Side Airbag Squib LH
- S5 Side Airbag Squib RH
- S6 Stop Light SW
- T3 Theft Deterrent ECU
- T4 Theft Deterrent ECU
- U1 Unlock Warning SW and Key Interlock Solenoid

Position of Parts in Body




A17 ABS Speed Sensor Rear LH A18 ABS Speed Sensor Rear RH

- B6 Back-Up Light LH
- B7 Back-Up Light RH
- D6 Door Courtesy SW Front LH
- D7 Door Courtesy SW Front RH
- D8 Door Courtesy SW Rear LH
- D9 Door Courtesy SW Rear RH
- D10 Door Key Lock and Unlock SW LH
- D11 Door Key Lock and Unlock SW RH
- D12 Door Lock Control SW LH
- D13 Door Lock COntrol SW RH
- D14 Door Lock Motor and Ulock Detection SW Front LH
- D15 Door Lock Motor or Unlock Detection Sw Front RH
- D16 Door Lock Motor or Unlock Detection SW Front LH
- D17 Door Lock Motor or Unlock Detection SW Rear RH
- D18 Door Lock Motor Rear LH
- D19 Door Lock Motor Rear RH
- D20 Door Lock Motor, Unlock Detection SW and Door Key Lock and Unlock SW Front LH


- D21 Door Lock Motor and Door Key Lock and Unlock SW Front RH
- F5 Front Door Speaker LH
- F6 Front Door Speaker RH
- F7 Fuel Pump and Sender
- H7 High Mounted Stop Light
- 113 Interior Light
- J15 Junction Connector
- J16 Junction Connector
- J17 Junction Connector
- J18 Junction Connector
- J19 Junction Connector


Position of Parts in Body



- L1 License Plate Light
- L2 Luggage Compartment Key Unlock SW
- L3 Luggage Compartment Light
- L4 Luggage Compartment Light SW
- M2 Moon Roof Control Relay
- M3 Moon Roof Control SW
- M4 Moon Roof Motor and Limit SW
- P4 Power Window Control SW Front RH
- P5 Power Window Control SW Rear LH
- P6 Power Window Control SW Rear RH
- P7 Power Window Master SW
- P8 Power Window Motor Front LH
- P9 Power Window Motor Front RH
- P10 Power Window Motor Rear LH
- P11 Power Window Motor Rear RH
- P12 Pretensioner LH
- P13 Pretensioner RH

- R7 Rear Combination Light LH
- R8 Rear Combination Light RH
- R9 Rear Speaker LH
- R10 Rear Speaker RH
- R11 Rear Window Defogger (+)
- R12 Rear Window Defogger (-)
- R13 Remote Control Mirror LH
- R14 Remote Control Mirror RH
- S7 Seat Belt Retractor SW
- S8 Side Airbag Sensor LH
- S9 Side Airbag Sensor RH
- V3 Vapor Pressure Sensor
- V4 VSV (Vapor Pressure Sensor)





SYSTEM OUTLINE

ABS is a brake system designed to improve the operating ability and securing the stability of the vehicle by preventing the lock—up of the vehicle by controlling the wheel cylinder pressure of all the four wheels at the time of sudden braking.

1. INPUT SIGNALS

(1) Speed sensor signal

The speed of the wheels is detected and input to TERMINALS FL+, FR+, RL+, and RR+ of the ABS actuator and ECU.

(2) Stop light SW signal

A signal is input to TERMINAL STP of the ABS actuator and ECU when brake pedal is depressed.

2. SYSTEM OPERATION

When the wheels are locked—up, the solenoid inside the actuator is controlled by the signal from the ABS actuator and ECU, and the brake fluid in the wheel cylinder will flow through the reservoir and reduce the hydraulic pressure.

While the ABS is in operation, as the ABS actuator and ECU always outputs the operation signal to the pump inside the actuator, and the brake fluid stored inside the reservoir will be sucked up by the pump inside the actuator and returned to the master cylinder.

When the hydraulic pressure of the wheel cylinder is decompressed or increased until the necessary hydraulic pressure, the solenoid inside the actuator is controlled by the control signal from the ABS actuator and ECU and as a result, hydraulic pressure of the wheel cylinder will be closed at both the master cylinder and reservoir sides routes, and the hydraulic pressure of the wheel cylinder will be in the hold condition.

If increase of the hydraulic pressure volume of the wheel cylinder becomes necessary, the control signals from the ABS actuator and ECU control the solenoid inside the actuator, to resume to the mormal condition. Thus the brake fluid of the master cylinder will be sent to the wheel cylinder and will increase the hydraulic pressure of the wheel cylinder. At this time, in the case that the brake fluid is left in the reservoir, it will be sucked up by the pump inside the actuator and will be sent to the wheel cylinder.

SERVICE HINTS

A5, A6 ABS SPEED SENSOR FRONT LH, RH

2-1 : **1.4** -**1.8** k Ω (**25** °C, **77** °F)

A17, A18 ABS SPEED SENSOR REAR LH, RH

1–2 : **1.05** –**1.45** $k\Omega$ (**25**°C, **77**°F)

A4 ABS ACTUATOR AND ECU

(Connect the ABS actuator and ECU connectors)

23-GROUND: Approx. 12 volts with the ignition SW at ON position and the data link connector 1,

TC-E1 TS-E1 not connected

10-GROUND: Approx. 12 volts with the ignition SW at ON position and the data link connector 1,

TC-E1 TS-E1 not connected

16, 17-GROUND: Always continuity

8, 24–GROUND : Approx. 12 volts with the ignition SW at ON position

11-GROUND: Approx. 12 volts with the brake pedal depressed

1, 2-GROUND : Always approx. 12 volts

O : PARTS LOCATION

Code	See Page	Co	de	See Page	Code	See Page
A4	34	C13	С	36	J1	37
A5	34	C14	D	36	J13	37
A6	34	D	1	34	S6	37
A17	38	F	4	34		
A18	38	l11	Α	37		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IA	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)
IC	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1B	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
3B		
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3D		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB1	42	Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)
IC1	42	Floor Wire and Cowl Wire (Near the Driver Side J/B)
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)
IL1	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)


: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
EC	40	Cylinder Head

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	40	Engine Room Main Wire			





_ SERVICE HINTS _

P1 (A), (B) BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T)

(A) 2, (B) 6–(A) 8, (B) 5 : Closed with the shift lever at **R** position

B1 BACK-UP LIGHT SW (M/T)

2-1 : Closed with the shift lever at R position

: PARTS LOCATION

Code	See Page	Code		See Page	Code		See Page
B1	34	J9	Α	37	J1	9	38
В6	38	J10	В	37	P1	Α	35
B7	38	J1	11	37	PI	В	35
I11 A	37	J1	18	38			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F	24	Floor Wire and Driver Side J/B (Left Kick Panel)
3C	20	Instrument Denel Wire and Center I/D (Dehind the Combination Mater)
3D	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ1	44	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)


: GROUND POINTS


Code	See Page	Ground Points Location
BI	46	Under the Left Quarter Pillar












(Hint : See Page 7)

J10 (B) BLACK



J11

J18 DARK GRAY

(Hint : See Page 7)


(Hint : See Page 7)

(Hint : See Page 7)





(Hint : See Page 7)


(4A/T) P1 (A) GRAY



(3A/T) P1 (B) GRAY







CRUISE CONTROL

SYSTEM OUTLINE

The current is applied at all times through the STOP fuse to TERMINAL 2 of the stop light SW.

With the ignition SW turned to on, the current flows through the **GAUGE** fuse to **TERMINAL 9** of the integration relay to **TERMINAL (A) 9** to **TERMINAL (D) 2** of the combination meter and the current through the **ECU-IG** fuse flows to **TERMINAL 9** of the cruise control ECU.

When the ignition SW is on and the CRUISE SW is turned on, a signal is input from **TERMINAL 5** of the cruise control SW to **TERMINAL 11** of the cruise control ECU. As a result, the cruise control ECU functions and the current flows from the **ECU–IG** fuse to **TERMINAL 9** of the cruise control ECU to **TERMINAL 16** of the cruise control ECU to **GROUND**, and the cruise control system is in a condition ready for operation.

At the same time, the current through the GAUGE fuse flows to TERMINAL 9 of the integration relay to TERMINAL (A) 9 to TERMINAL (D) 2 of the cruise control indicator light to TERMINAL (A) 7 to TERMINAL 4 of the cruise control ECU to TERMINAL 16 to GROUND, causing the cruise control indicator light to light up, indicating that cruise control is ready for operation.

1. SET OPERATION

When the CRUISE SW is turned on and the SET SW is pushed with the vehicle speed within the set limit (Approx. 40 km/h, 25 mph to 200 km/h, 124 mph), a signal is input to **TERMINAL 10** of the cruise control ECU, and the vehicle speed at the time the SET SW is released is memorized in the ECU as the set speed.

2. SET SPEED CONTROL

During cruise control driving, the ECU compares the set speed memorized in the ECU with the actual vehicle speed input into **TERMINAL 12** of the cruise control ECU from the vehicle speed sensor via combination meter, and controls the cruise control actuator to maintain the set speed.

When the actual speed is lower than the set speed, the ECU causes the current to the cruise control actuator to flow from **TERMINAL 15** of the cruise control ECU to **TERMINAL 1** of the cruise control actuator to **TERMINAL 2** to **TERMINAL 7** of the cruise control ECU. As a result, the motor in the cruise control actuator is rotated to open the throttle valve and the throttle cable is pulled to increase the vehicle speed. When the actual driving speed is higher than the set speed, the current to the cruise control actuator flows from **TERMINAL 7** of the ECU to **TERMINAL 2** of the cruise control actuator to **TERMINAL 1** to **TERMINAL 15** of the cruise control ECU.

This causes the motor in the cruise control actuator to rotate to close the throttle valve and return the throttle cable to decrease the vehicle speed.

3. COAST CONTROL

During cruise control driving, while the COAST SW is on, the cruise control actuator returns the throttle cable to close the throttle valve and decrease the driving speed. The vehicle speed when the COAST SW is turned off is memorized, and the vehicle continues at the new set speed.

4. ACCEL CONTROL

During cruise control driving, while the ACCEL SW is turned on, the cruise control actuator pulls the throttle cable to open the throttle valve and increase the driving speed.

The vehicle speed when the ACCEL SW is turned off is memorized and the vehicle continues at the new set speed.

5. RESUME CONTROL

Unless the vehicle speed falls below the minimum speed limit (Approx. **40**km/h, **25**mph) after canceling the set speed by the CANCEL SW, pushing the RESUME SW will cause the vehicle to resume the speed set before cancellation.

6. MANUAL CANCEL MECHANISM

If any of the following operations occurs during cruise control operation, the magnetic clutch of the actuator turns off and the motor rotates to close the throttle valve and the cruise control is released.

- * Placing the shift lever to positions except "D" position (Park/Neutral position SW except "D" position)(A/T), depressing the clutch pedal (Cruise control clutch SW off)(M/T). "Signal is not input to **TERMINAL 3** of the ECU"
- * Depressing the brake pedal (Stop light SW on). "Signal input to **TERMINAL 2** of the ECU"
- * Pushing the CANCEL SW (CANCEL SW on). "Signal input to TERMINAL 10 of the ECU"
- * Pushing the CRUISE SW off "signal input to TERMINAL 11 of the ECU".

7. TAP-UP CONTROL FUNCTION

When the difference between the actual vehicle speed and the set speed is less than **5** km/h (**3** mph), the set speed can be increased **1.6** km/h (**1** mph) each time by operating the RESUME/ACCEL SW quickly within **0.6** seconds.

8. TAP-DOWN CONTROL FUNCTION

When the difference between the actual vehicle speed and the set speed is less than 5 km/h (3 mph), the set speed can be lowered 1.6 km/h (1 mph) each time by operating the SET/COAST SW quickly within 0.6 seconds.

9. AUTO CANCEL FUNCTION

A) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, current flow to the magnetic clutch is stopped and the cruise control is released, (CRUISE SW turns off).

When this occurs, the ignition SW must be turned off once before the CRUISE SW will turn on.

- * When current continues to flow to the motor inside the actuator in the throttle valve "OPEN" direction.
- * The motor does not operate despite the motor drive signal being output.
- B) If any of the following operating conditions occurs during cruise control operation, the set speed is erased, current flow to the magnetic clutch is stopped and the cruise control is released. (CRUISE SW turn off).

When this occurs, the cancel state is cleared as the CRUISE SW will turn on again.

- * Over current to transistor driving the motor or the magnetic clutch.
- * Open circuit in the magnetic clutch.
- * Momentary interruption of vehicle speed signal.
- * Short circuit in the cruise control SW.
- C) If any of the following conditions occurs during cruise control operation, the set speed is erased and the cruise control is released. (The power to the magnetic clutch is cut off until the SET SW is "ON" again.)
- * When the vehicle speed falls below the minimum speed limit, approx. 40 km/h (25 mph)
- * When power to the cruise control system is momentarily cut off.

10. AUTOMATIC TRANSAXLE CONTROL FUNCTION

- * In overdrive. If the vehicle speed becomes lower than the overdrive cut speed (Set speed minus approx. 4 km/h, 2.5 mph) during cruise control operation, such as driving up a hill, the overdrive is released and the power is increased to prevent a reduction in vehicle speed.
- * After releasing the overdrive, if the vehicle speed becomes higher than the overdrive return speed (Set speed minus approx. 2 km/h, 1.2 mph) and the ECU judges by the signals from the actuator's potentiometer that the upward slope has finished, the overdrive is resumed after approximately 2 seconds.
- * During cruise control driving, the cruise control operation signal is output from the cruise control ECU to the engine control module. Upon receiving this signal, the engine control module changes the shift pattern to normal.

To maintain smooth cruise control operation (on a downward slope etc.), the lock-up release of the transaxle when the idling point of the throttle position is "ON" is forbidden.

SERVICE HINTS

C3 CRUISE CONTROL ACTUATOR

3–4 : Approx. **38.5** Ω

C16 CRUISE CONTROL SW [COMB. SW]

5-3: Continuity with the CRUISE SW on

4–3 : Approx. 418 Ω with the CANCEL SW on

Approx. 68 Ω with the RESUME/ACCEL SW on

Approx. 198 Ω with the SET/COAST SW on

C19 CRUISE CONTROL ECU

9-GROUND: 10-16 volts with the ignition SW at ON position

12-GROUND: 4 pulses with 1 rotation of the rotor shaft

10–GROUND : Approx. 418 Ω with the CANCEL SW on in the control SW

Approx. 198 Ω with the SET/COAST SW on in the control SW

Approx. 68 Ω with the RESUME/ACCEL SW on in the control SW

16-GROUND : Always continuity

CRUISE CONTROL

: PARTS LOCATION

Co	de	See Page Code See Page		Co	de	See Page		
С	3	34	D	1	34	J13		37
C11	Α	36	E4	Α	36	J1	14	37
C12	В	36	E5	В	36	P1	Α	35
C13	С	36	E6	С	36	PI	В	35
C14	D	36	I11	Α	37	S	6	37
C′	16	36	J9	Α	37	V	1	35
C,	18	36	J10	В	37			
C19		36	J1	2	37			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IC	00	Could Wine and Instrument Densit VD (Louise Finish Densit)
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1B	0.5	Could Wine and Driver Cide 1/D /I of 1/Cel. Denail
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
3A		
3B	00	Instrument Dariel Wire and Content I/D (Dakind the Content in Mater)
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3D		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IJ2	44	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)
IL1	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)

: GROUND POINTS


-		
Code	See Page	Ground Points Location
EC	40	Cylinder Head
ID	42	Left Kick Panel
IG	42	Instrument Panel Brace RH
IH	42	Right Kick Panel


C3 BLACK

C11 (A) BROWN


(w/ Theft Deterrent System) C12 (B)










(w/o Theft Deterrent System) C12 (B)









SERVICE HINTS

C7 CIGARETTE LIGHTER

2-GROUND : Approx. 12 volts with the ignition SW at ACC or ON position

1-GROUND : Always continuity

C9 CLOCK

4–GROUND : Approx. 12 volts with the ignition SW at \boldsymbol{ACC} or \boldsymbol{ON} position

1-GROUND : Always approx. 12 volts

3-GROUND : Approx. 12 volts with the light control SW at TAIL or HEAD position

2-GROUND: Always continuity

: PARTS LOCATION

Code	See Page	Co	de	See Page	Code	See Page
C7	36	I11	Α	37	J8	37
C9	36	J	7	37		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3A		
3B	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3C		


: GROUND POINTS


Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH

C7













(Hint: See Page 7)



(Hint: See Page 7)







SERVICE HINTS

B2 BRAKE FLUID LEVEL WARNING SW

1-2: Closed with the float down

C11 (A), C12 (B), C13 (C), C14 (D) COMBINATION METER

(A)10, (D) 2-GROUND : Approx. 12 volts with the ignition SW at ON position

(A) 2, (B) 15, (C) 12–GROUND : Always continuity (A) 5, (B) 13–GROUND : Always approx. **12** volts

F7 FUEL SENDER

2–3 : Approx. 4 Ω at fuel full Approx. 107 Ω at fuel empty

O1 OIL PRESSURE SW

1-GROUND: Opened with the oil pressure above approx. 19.61 kpa (2.84 psi, 0.2 kgf/cm²)

P3 PARKING BRAKE SW

1-GROUND: Closed with the parking brake lever pulled up

E2 WATER TEMP. SENDER [ENGINE COOLANT TEMP. SENSOR]

3–GROUND : Approx. 160–240 Ω (50 $^{\circ}$ C, 122 $^{\circ}$ F) Approx. 17.1–21.2 Ω (120 $^{\circ}$ C, 288 $^{\circ}$ F)

: PARTS LOCATION

Co	de	See Page	Co	de	See Page	Co	de	See Page
А	9	34 D3 B 36 O1		1	35			
В	2	34	E	2	34	P1	Α	35
C.	10	36	F	7	38	FI	В	35
C11	Α	36	l11	Α	37	P	3	37
C12	В	36	J	1	37	R	6	37
C13	С	36	J	8	37	V	1	35
C14	D	36	J9	Α	37	W	1	35
D3	Α	36	J10	В	37			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IJ	22	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)				
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)				
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
2C	27	Engine Wire and Engine Room J/B (Engine Compartment Left)				
2D	21					
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
3A						
3B	20	Instrument Benel Wire and Center I/B (Behind the Combination Meter)				
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				
3D						

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)					
IG2	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)					
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)					
IJ1	44	Familia Wire and last was at Danel Wire (last was at Danel Dross LLI)					
IJ2	44	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)					
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)					
IL2	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)					

COMBINATION METER

∇

: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
EC	40	Cylinder Head
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IG	42	Instrument Panel Brace RH

A9 BLACK

(w/ ABS) B2 GRAY

(w/o ABS) B2 GRAY


C11 (A) BROWN














(w/ Theft Deterrent System) C12 (B)



(w/o Theft Deterrent System) C12 (B)




C13 (C) BLUE




(USA, Puerto Rico) C14 (D) GRAY

| X23XX6X8910

(Canada) C14 (D) GRAY



(USA, Puerto Rico) D3 (A)








E2 DARK GRAY



F7 DARK GRAY




I11 (A)




J1



(Hint: See Page 7)




(Hint: See Page 7)



(Hint : See Page 7)

J10 (B) BLACK



(Hint : See Page 7)


O1 GRAY



X 5 6 • X •

(4A/T) P1 (A) GRAY

(3A/T) P1 (B) GRAY



P3 BLACK



R6




V1 BLACK



W1 BLACK





SERVICE HINTS

G2 (B) GENERATOR

(B) 3-GROUND: 13.9-15.1 volts with the engine running at 2000 rpm and 25°C (77°F)

13.5–14.3 volts with the engine running at 5000 rpm and 115 °C (239 °F)

(B) 1-GROUND: 0-4 volts with the ignition SW at ON position and the engine not running

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
С	11	36	F4		34	I11	Α	37
D3	Α	36	G1	Α	34	J9	Α	37
D3	В	36	G2	В	34	J10	В	37

) : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
6	21	Engine Room R/B No.6 (Radiator Support RH)


: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IJ	22	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
2B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2C	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
3C	20	Instrument Denel Wire and Center I/D (Dehind the Combination Mater)
3D	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)


: SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	40	Engine Room Main Wire			

CHARGING



DOOR LOCK CONTROL (NUMMI MADE)





DOOR LOCK CONTROL (NUMMI MADE)

SERVICE HINTS

I11 (A), I12 (B) INTEGRATION RELAY

7-GROUND: Always continuity

8-GROUND: Continuity with the driver's door open

(B)14-GROUND: Always approx. 12 volts

(B) 7-GROUND : Approx. 12 volts 0.2 seconds with following operation

* Door lock control SW locked

* Locking the driver's, front passenger's door cylinder with the key

(B) 1-GROUND: Continuity with the door lock control SW locked

(B) 9-GROUND: Continuity with the front passenger's door open

(B)10-GROUND: Continuity with the driver's door lock knob unlocked

(B) 2-GROUND: Continuity with the door lock control SW unlocked

(B) 6-GROUND: Continuity with the front passenger's door lock cylinder unlock with the key

(B) 5-GROUND: Continuity with the driver's door lock cylinder unlocked with the key

(B) 3-GROUND: Continuity with the driver's, front passenger's door lock cylinder locked with the key

(B) 8 or (B) 12-GROUND : Approx. 12 volts 0.2 seconds with following operation

* Door lock control SW unlocked

* Door lock control SW locked with the ignition key in cylinder and the driver's door open (Ignition key reminder function)

* Door lock knob locked with the ignition key in cylinder and the driver's door open (Ignition key reminder function)

* Unlocking the driver's, front passenger's door cylinder with the key

D6, D7 DOOR COURTESY SW FRONT LH,RH

1-GROUND: Closed with each of the doors open

U1 UNLOCK WARNING SW

1-2: Closed with the ignition key in cylinder

: PARTS LOCATION

Co	Code See Page Code D6 38 D20 3		See Page Code		See Page			
D			D20		38	J8	37	
D	7	38	D21		38	J14	37	
D12	В	38	l11	Α	37	J15	37	
D13	Α	38	l12	В	37	J16	37	
DIS	В	38	J	3	37	J17	38	
D'	18	38	J4	Α	37	P7 A	39	
D19		38	J5	В	37	U1	37	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3D		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	42	Front Door LH Wire and Cowl Wire (Near the Driver Side J/B)
IM2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BA1 46 Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)		Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)
BB1 46 Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)		Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)


(Hint: See Page 7)

: GROUND POINTS


Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IH	42	Right Kick Panel











TAILLIGHT AND ILLUMINATION

SERVICE HINTS

C15 COMBINATION SW

14-16: Closed with the light control SW at TAIL or HEAD position

TAII RFI AY

5-3: Closed with the light control SW at **TAIL** or **HEAD** position

: PARTS LOCATION

Code	See Page	Code	See Page	Code		See Page
A12	36	F4	34	O2		37
A15	36	H5	36	R2 A		37
B5	36	I11 A	37	R3	В	37
C8	36	J1	37	R4		37
C12	36	J8	37	R	6	37
C15	36	J14	37	R7		39
D3	36	J18	38	R	8	39
F1	34	J19	38			
F2	34	L1	39		•	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
IB	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)		
IC	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)		
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1B	0.5	Cowl Wire and Driver Side J/B (Left Kick Panel)		
1C	25			
1D	0.4	Instrument Denel Wire and Drives Cide 1/D /I of 1/Cide Denell)		
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
1F	24	Floor Wire and Driver Side J/B (Left Kick Panel)		
3A				
3B	20	Leadman and David Million and October UD (Dala's addless Octobe's addless Mades)		
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)		
3D				

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)		
Ī	IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)		

: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IH	42	Right Kick Panel
BI	46	Under the Left Quarter Pillar
BJ	46	Lower Back Panel Center

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	ss with Splice Points Code See F		Wire Harness with Splice Points
E1	40	Engine Room Main Wire	I1	44	Engine Room Main Wire



SYSTEM OUTLINE

The current always flows to TERMINAL (B) 14 of the integration relay through the D/L fuse.

1. MANUAL LOCK OPERATION

When the door lock control SW or door key lock and unlock SW are operated to LOCK position, a lock signal is input to TERMINAL (B) 1 or (B) 3 of the integration relay and causes the relay to function. The current flows from TERMINAL (B) 14 of the relay to TERMINAL (B) 7 to the door lock motors to TERMINALS (B) 8 and (B) 12 of the relay to TERMINAL 7 to GROUND and the door lock motors locks the door.

2. MANUAL UNLOCK OPERATION

When the door lock control SW or door key lock and unlock SW are operated to **UNLOCK** position, an unlock signal is input to **TERMINAL (B) 2**, **(B) 5** or **(B) 6** of the integration relay and causes the relay to function. The current flows from **TERMINAL (B) 14** of the relay to **TERMINAL (B) 8** and **(B) 12** to the door lock motors to **TERMINAL (B) 7** of the relay to **TERMINAL 7** to **GROUND** and the door lock motors unlocks the door.


3. DOUBLE OPERATION UNLOCK OPERATION


When the door key lock and unlock SW LH is turned to the unlock side, only the driver's door is unlocked. By turning the door key lock and unlock SW LH to the unlock side, a signal is input to **TERMINAL (B) 5** of the relay, and if the signal is input again within **3** seconds by turning the SW to the unlock side again, current flows from **TERMINAL (B) 8** of the integration relay to the door lock motors (Front RH, rear LH, RH) to **TERMINAL (B) 7** of the relay to **TERMINAL 7** to **GROUND**, causing the door lock motors to operate and unlock the doors.

4. IGNITION KEY REMINDER OPERATION

- * Operating door lock knob (Operation of door lock motors)
 With the ignition key in the cylinder (Unlock warning SW on), when the door is opened and locked using door lock knob (Door lock motor), the door is locked once but each door is unlocked soon by the function of the relay. As a result, the current flows from TERMINAL (B) 14 of the integration relay to TERMINALS (B) 8 and (B) 12 to the door lock motors to TERMINAL (B) 7 of the relay to TERMINAL 7 to GROUND and unlocks all the doors.
- * Operating door lock control SW or door key lock and unlock SW
 With the ignition key in the cylinder (Unlock warning SW on), when the door is opened and locked using door lock control
 SW or key SW, the door is locked once but each door is unlocked by the function of SW contained in motors, and the
 signal is input to TERMINAL (B) 10 of the relay. According to this input signal, the current flows from TERMINAL (B) 14 of
 the relay to TERMINALS (B) 8 and (B) 12 to the door lock motors to TERMINAL (B) 7 of the relay to TERMINAL 7 to
 GROUND and unlocks all the doors.
- * In case of key less lock
 With the ignition the key in the cylinder (Unlock warning SW on), when the unlock function is disturbed more than 0.2
 seconds, for example pushing the door lock knob etc., the door holds on lock condition. Closing the door after, door
 courtesy SW inputs the signal into TERMINAL 8 or (B) 9 of the integration relay. By this input signal, the relay works and
 current flows from TERMINAL (B) 14 of the relay to TERMINALS (B) 8 and (B) 12 to the door lock motors to TERMINAL
 (B) 7 of the relay to TERMINAL 7 to GROUND and unlocks all the doors.

DOOR LOCK CONTROL (TMMC MADE)





DOOR LOCK CONTROL (TMMC MADE)

SERVICE HINTS

I11 (A), I12 (B) INTEGRATION RELAY

7-GROUND: Always continuity

8-GROUND: Continuity with the driver's door open

(B)14-GROUND: Always approx. 12 volts

(B) 7-GROUND : Approx. 12 volts 0.2 seconds with following operation

* Door lock control SW locked

* Locking the driver's, front passenger's door cylinder with the key

(B) 1-GROUND: Continuity with the door lock control SW locked

(B) 9-GROUND: Continuity with the front passenger's door open

(B)10-GROUND: Continuity with the driver's door lock knob unlocked

(B) 2-GROUND: Continuity with the door lock control SW unlocked

(B) 6-GROUND: Continuity with the front passenger's door lock cylinder unlock with the key

(B) 5-GROUND: Continuity with the driver's door lock cylinder unlocked with the key

(B) 3-GROUND: Continuity with the driver's, front passenger's door lock cylinder locked with the key

(B) 8 or (B) 12-GROUND : Approx. 12 volts 0.2 seconds with following operation

* Door lock control SW unlocked

* Door lock control SW locked with the ignition key in cylinder and the driver's door open (Ignition key reminder function)

* Door lock knob locked with the ignition key in cylinder and the driver's door open (Ignition key reminder function)

* Unlocking the driver's, front passenger's door cylinder with the key

D6, D7 DOOR COURTESY SW FRONT LH,RH

1-GROUND: Closed with each of the doors open

U1 UNLOCK WARNING SW

1-2: Closed with the ignition key in cylinder

) : PARTS LOCATION

Co	ode	See Page	Co	de	See Page	Co	de	See Page
D	6	38	D	15	38	J8		37
D	7	38	D	16	38 J14		37	
D'	10	38	D	17	38	J1	5	38
D.	11	38	l11	Α	37	J1	6	38
D12	В	38	l12	В	37	J17		38
D13	Α	38	J	3	37	P7	Α	39
013	В	38	J4	Α	37	U	1	37
D'	14	38	J5	В	37		•	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)				
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)				
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
3C	00	Instrument Denel Wire and Contar I/D (Dehind the Combination Mater)				
3D	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	42	Front Door LH Wire and Cowl Wire (Near the Driver Side J/B)
IM2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)
BB1	46	Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)

: GROUND POINTS

Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IH	42	Right Kick Panel

D6, D7

D10 GRAY

D11 GRAY

(w/o Power Window) D12 (B) BLACK









(w/ Power Window) D13 (A)

(w/o Power Window) D13 (B) BLACK

D14 BLACK








D15 BLACK

D16 BLACK


D17 BLACK


I11 (A)






I12 (B)







(Hint : See Page 7)

(Hint : See Page 7)

(Hint : See Page 7)



J14



(Hint: See Page 7)

J16


J17 BLACK (Hint: See Page 7)


(Hint : See Page 7)


(Hint : See Page 7)


(Hint: See Page 7)


(w/ Power Window) P7 (A)

















SYSTEM OUTLINE

The engine control system utilizes a microcomputer and maintains overall control of the engine, etc. An outline of engine control is given here.

1. INPUT SIGNALS

(1) Engine coolant temp. signal system

The engine coolant temp. sensor detects the engine coolant temp. and has a built–in thermistor with a resistance which varies according to the engine coolant temp. Thus the engine coolant temp. is input as a control signal to **TERMINAL THW** of the engine control module.

(2) Intake air temp. signal system

The intake air temp. sensor is detects the intake air temp., which is input as a control signal to **TERMINAL THA** of the engine control module.

(3) Power steering oil pressure signal system

Power steering oil pressure is detected by the power steering oil pressure SW and is input as a control signal to **TERMINAL PSSW** of the engine control module.

(4) RPM signal system

Camshaft position and crankshaft position are detected by the camshaft position sensor and crankshaft position sensor. Camshaft position is input as a control signal to **TERMINAL G2** of the engine control module, and engine RPM is input into **TERMINAL NE**.

(5) Throttle signal system

The throttle position sensor detects the throttle valve opening angle, which is input as a control signal to **TERMINAL VTA** of the engine control module.

(6) Vehicle speed signal system

The vehicle speed is detected by the vehicle speed sensor installed in the transaxle and the signal is input to **TERMINAL SPD** of the engine control module via the comb. meter.

(7) NSW signal system (A/T)

The Park/Neutral position SW detects whether the shift position is in neutral or not, and inputs a control signal to **TERMINAL NSW** of the engine control module.

(8) A/C SW signal system

The operating voltage of the A/C amplifier is detected and is input as a control signal to **TERMINAL AC1** of the engine control module.

(9) Battery signal system

Voltage is constantly applied to **TERMINAL BATT** of the engine control module. When the ignition SW is turned to on, voltage for engine control module operation is applied via the EFI or F–HTR relay to **TERMINAL +B** of the engine control module.

(10) Intake air volume signal system

Intake air volume is detected by the manifold absolute pressure sensor and is input as a control signal to **TERMINAL PIM** of the engine control module.

(11) STA signal system

To confirm that the engine is cranking, the voltage applied to the starter motor during cranking is detected and is input as a control signal to **TERMINAL STA** of the engine control module.

(12) Oxygen sensor signal system

The oxygen density in the exhaust gases is detected and is input as a control signal into **TERMINALS OX1** and **OX2** of the engine control module. To maintain stable detection performance by the oxygen sensor, a heater is used for warming the sensor. The heater is also controlled by the engine control module (**HT1** and **HT2**).

(13) Engine knock signal system

Engine knocking is detected by the knock sensor and input as a control signal to **TERMINAL KNK** of the engine control module.

(14) Electrical load signal system

When systems which cause a high electrical load such as the rear window defogger, taillight are turned on, a signal is input to **TERMINALS ELS1** and **ELS2** as a control signal.

(15) Vapor pressure signal system

Vapor pressure is detected by the vapor pressure sensor and is input as a control signal to **TERMINAL PTNK** of the engine control module.

ENGINE CONTROL

2. CONTROL SYSTEM

* SFI system

The SFI system monitors the engine conditions through the signals each sensor (Input signals 1, 4, 5, 10, 12)) input to the engine control module. Based on this data and the program memorized in the engine control module, the most appropriate fuel injection timing is decided and current is output to **TERMINALS #10, #20, #30** and **#40** of the engine control module, operating the injectors (to inject fuel). This is the system which finely controls the fuel injection in response to the driving conditions, through the engine control module.

* ESA system

The ESA system monitors the engine conditions using the signals (Input signals (1, 4, 5, 10, 13)) input to the engine control module from each sensor. Based on this data and the program memorized in the engine control module, the most appropriate ignition timing is decided and current is output to **TERMINALS IGT1** and **IGT2** of the engine control module. This output controls the ignition coil and igniter No. 1 and No. 2 to produce the most appropriate ignition timing for the driving conditions.

* IAC system

The IAC system (Rotary solenoid type) increases the RPM and provides idle stability for fast idle—up when the engine is cold, and when the idle speed has dropped due to electrical load and so on. The engine control module evaluates the signals from each sensor, and outputs current to **TERMINAL RSO** to control the idle air control valve.

* A/C cut control system

When the vehicle suddenly accelerates from low engine speed, this system cuts off the air conditioner operation for a fixed period of time in response to the vehicle speed, throttle valve opening angle and intake manifold pressure in order to maintain acceleration performance.

The engine control module receives (each signal), and outputs signals to TERMINAL ACT.

* Knock control system

Knock control system controls the gate based on the engine rotation speed and detects knocking by the peak value of the knock sensor output during the gate open period, and then controls it to the most suitable ignition timing in proportion to the driving condition.

* Evapoparge control system

This system leads the vapor stuck to the canister to the serge tank in order not to agitate the air fuel by adjusting the fuel injection volume.

The signal at this time will be output from **TERMINAL EVP** of the engine control module to VSV (ORVR).

3. DIAGNOSIS SYSTEM

With the diagnosis system, when there is a malfunctioning in the engine control module signal system, the malfunction system is recorded in the memory. The malfunctioning system can be found by reading the display (Code) of the check engine warning light.

4. FAIL-SAFE SYSTEM

When a malfunction occurs in any system, if there is a possibility of engine trouble being caused by continued control based on the signals from that system, the fail–safe system either controls the system by using the data (Standard values) recorded in the engine control module memory or else stops the engine.

```
SERVICE HINTS
C/OPN RELAY
   5-3: Closed with the starter running and the engine running
EFI or F-HTR RELAY
   5-3: Closed with the ignition SW at ON or ST position
E2 ENGINE COOLANT TEMP. SENSOR
   1–2 : Approx. 14.96 kΩ (–20^{\circ}C, –4^{\circ}F)
         Approx. 5.65 k\Omega ( 0^{\circ}C, 32^{\circ}F)
         Approx. 2.44 kΩ (20°C, 68°F)
         Approx. 0.3143 k\Omega (80°C, 176°F)
E4 (A), E5 (B), E6 (C) ENGINE CONTROL MODULE
Voltage at engine control module wiring connectors
  BATT-E1: Always 9-14 volts
     +B-E1: 9-14 volts (Ignition SW at ON position)
     VC-E1: 4.5-5.5 volts (Ignition SW at ON position)
    VTA-E1: 0.3-0.8 volts (Ignition SW on and throttle valve fully closed)
             : 3.2-4.9 volts (Ignition SW on and throttle valve fully open)
    PIM-E1: 3.3-3.9 volts (Ignition SW at ON position)
   THA-E1: 0.5-3.4 volts (Engine idling and intake air temp. 0-80°C, 32-176°F)
   THW-E1: 0.2-1.0 volts (Engine idling and engine coolant temp. 60-120°C, 140-248°F)
    STA-E1: 6-14 volts (Engine cranking)
 IGT1, IGT2-E1: Pulse generation (Engine idling)
    IGF-E1: Pulse generation (Engine idling)
     FC-E1: 9-14 volts (Ignition SW on and engine stopping)
              0-3 volts (Engine idling)
      W-E1: 9-14 volts (Engine idling and warning light off)
    AC1-E1: 9-14 volts (Ignition SW on and A/C SW off)
   ACT-E1: 4.5-5.5 volts (Ignition SW on and A/C SW on)
   SPD-E1: Pulse generation (Driving approx. 20 km/h)
   ELS2-E1: 7.5-14 volts (Ignition SW on and taillight on)
  ELS1-E1: 7.5-14 volts (Ignition SW on and rear window defogger on)
   NSW-E1: 0-3 volts (Engine cranking)
 #10, #20, #30, #40-E1: Pulse generation (Engine idling)
   NE-NE-: Pulse generation (Engine idling)
   RSO-E1: Pulse generation (Engine idling)
   G2-NE- : Pulse generation (Engine idling)
   TPC-E1: 9.0-14.0 volts (Ignition SW on and disconnect the quick connector from the vapor pressure sensor)
  PTNK-E1: 3.0-3.6 volts (Ignition SW at ON position)
             : 1.3-2.1 volts (Ignition SW on and apply vacuum 2.0 kpa (15.0 mm hg, 0.6 in. hg)
OX1, OX2-E1: Pulse generation (Maintain engine speed at 2500 rpm for two minutes after warming up.)
HT1, HT2-E1: 9.0-14.0 volts (Ignition SW at ON position)
                0-3.0 volts (Engine idling)
     KNK-E1: Pulse generation (Engine idling)
     EVP-E1: 9.0-14.0 volts (Ignition SW at ON position)
    TACH-E1: Pulse generation (Engine idling)
```

ENGINE CONTROL

: PARTS LOCATION

Co	de	See Page Code		See Page	Code		See Page
A.	A10 36 H3		H3	35	J9	Α	37
С	:1	34	H6	36	J10	В	37
C	2	34	I1	35	J1	11	37
С	10	36	12	35	J1	12	37
C12	В	36	13	35	K	1	35
C13	С	36	14	35	M1		35
C14	D	36	15	35	N1		37
C	19	36	16	35	P1	Α	35
D	1	34	17	35	PI	В	35
D	2	36	18	35	P2		35
Е	2	34	I10	37	Т	2	35
E4	Α	36	I11 A	37	V	1	35
E5	В	36	J1	37	V2		35
E6	С	36	J6	37	V	3	39
F	7	38	J8	37	V	4	39

: RELAY BLOCKS

Code	See Page	elay Blocks (Relay Block Location)				
1	20	Driver Side R/B (Left Kick Panel)				

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IA	00	Facine Dear Main Wire and least report Dead I/D (Laurer Finish Dead)				
IB	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IC	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)				
IE	23					
IG	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
IJ	22					
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)				
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
1F	24	Floor Wire and Driver Side J/B (Left Kick Panel)				
2B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
2C						
2D	27	Engine Wire and Engine Room J/B (Engine Compartment Left)				
2E						
2F						
2G	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
21						
3B						
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				
3D						

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
EA1	40	Engine No.4 Wire and Engine Wire (Inside of the Intake Manifold RH)				
IC1	42	Floor Wire and Cowl Wire (Near the Driver Side J/B)				
IG1	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)				
IJ1	44	Engine Wire and Instrument Denal Wire (Instrument Denal Drace LLI)				
IJ2	44	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)				
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)				
IL1	44	Farsing Wire and Coud Wire (Joseph Page) Proce DLIV				
IL2	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)				
BC1	46	Fuel Control Wire and Floor Wire (Rear Wheel House LH)				


: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
EC	40	Cylinder Head
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IG	42	Instrument Panel Brace RH
BI	46	Under the Left Quarter Pillar

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	40	Engine Room Main Wire	19	44	Engine Wire
18	44	Engine Wire			












(w/ Theft Deterrent System) C12 (B)




(w/o Theft Deterrent System) C12 (B)




C13 (C) BLUE




(USA, Puerto Rico) C14 (D) GRAY





(Canada) C14 (D) GRAY




C19
















E6 (C) DARK GRAY









































J12



(Hint: See Page 7) (Hint: See Page 7)

M1 BLACK




N1 GRAY



(4 A/T) P1 (A) GRAY



(3 A/T) P1 (B) GRAY



P2 BLACK



T2 BLACK



V1 BLACK



V2 BLACK




V3 BLACK




V4 BLACK



ELECTRONICALLY CONTROLLED TRANSMISSION





ELECTRONICALLY CONTROLLED TRANSMISSION

SYSTEM OUTLINE

Previous automatic transaxle have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock—up hydraulic pressure. The electronically controlled transmission, however, controls the line pressure and lock—up pressure etc.electrically, through the solenoid valve. The engine control module controls each solenoid valve based on the input signals from each sensor, which makes smooth driving possible by shift selection for each gear that is most appropriate to the driving conditions at that time.

1. GEAR SHIFT OPERATION

During driving, the engine control module selects the shift for each gear which is most appropriate to the driving conditions, based on input signals from the engine coolant temp. sensor to **TERMINAL THW** of the engine control module, and also the input signals to **TERMINAL SPD** of the engine control module from the vehicle speed sensor devoted to the electronically controlled transmission. Current is then output to the electronically controlled transmission solenoid. When shifting to 1st speed, the current flows from **TERMINAL S1** of the engine control module to **TERMINAL 3** of the solenoid to **GROUND**, and continuity to the No. 1 solenoid causes the shift.

For 2nd speed, the current flows from **TERMINAL S1** of the engine control module to **TERMINAL 3** of the solenoid to **GROUND**, and from **TERMINAL S2** of the engine control module to **TERMINAL 1** of the solenoid to **GROUND**, and continuity to solenoids No. 1 and No. 2 causes the shift.

For 3rd speed, there is no continuity to No. 1 solenoid, only to No. 2, causing the shift.

Shifting into 4th speed (Overdrive) takes place when there is no continuity to both No. 1 and No. 2 solenoid.

2. LOCK-UP OPERATION

When the engine control module judges from each signal that lock—up operation conditions have been met, the current flows from **TERMINAL SL** of the engine control module to **TERMINAL 2** of the electronically controlled transmission solenoid to **GROUND**, causing continuity to the lock—up solenoid, thus causing lock—up operation.

3. STOP LIGHT SW CIRCUIT

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to **TERMINAL STP** of the engine control module, the engine control module operates and continuity to the lock-up solenoid is cut.

4. OVERDRIVE CIRCUIT

* O/D SW on

When the O/D SW is turned on (O/D off indicator light turns off), a signal is input into **TERMINAL OD2** of the engine control module and engine control module operation causes gear shift when the conditions for overdrive are met.

* O/D SW off

When the O/D SW is turned off, the current through the O/D off indicator light flows through the O/D SW to ground, causing the indicator light to light up. At the same time, a signal is input into **TERMINAL OD2** of the engine control module and engine control module operation prevents shift into overdrive.

SERVICE HINTS

E4 (A), E5 (B), E6 (C) ENGINE CONTROL MODULE

S1,S2-E1: 9.0-14.0 volts with the ignition SW on and the solenoid on

0-1.5 volts with the ignition SW on and the solenoid off

L-E1: **7.5-14.0** volts with the ignition SW on and the shift lever at **L** position

2–E1: **7.5–14.0** volts with the ignition SW on and the shift lever at **2** position

R-E1: 7.5-14.0 volts with the ignition SW on and the shift lever at R position

STP-E1: 9.0-14.0 volts with the brake pedal depressed

THW-E2: 0.2-1.0 volts with the engine coolant temp. 60°C (140°F) -120°C (248°F) and engine idling

VTA-E2: 0.3-0.8 volts with the ignition SW on and the throttle valve fully closed

3.2-4.9 volts with the ignition SW on and the throttle valve fully open

VC-E2: 4.5-5.5 volts with the ignition SW on

OD2-E1: 9.0-14.0 volts with the ignition SW on and the O/D SW turned on

0-3.0 volts with the ignition SW on and the O/D SW turned off

+B-E1: 9.0-14.0 volts with the ignition SW on

E1 ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID

1, 2, 3-GROUND : Each 11-15 Ω

O2 O/D SW

2-4: Closed with the O/D SW off, open with the O/D SW on

O : PARTS LOCATION

Co	de	See Page	Code		See Page	Code	See Page
C12	В	36	E6	С	36	J12	37
C13	С	36	18	8	35	M1	35
C14	D	36	l11	Α	37	O2	37
C.	19	36	J1		37	P1	35
D	D1 34 J7		7	37	S6	37	
E	1	34	J8		37	T2	35
E	2	34	J9	Α	37	V1	35
E4	Α	36	J10	В	37		
E5 B		36	J1	11	37		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IA	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IC	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)				
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
1B	25	Could Mire and Driver Cide I/D (Left Kiels Done)				
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)				
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
2C						
2D	27	Engine Wire and Engine Room J/B (Engine Compartment Left)				
2E						
2F	- 27	Facing Deem Main Wise and Engine Deem I/D /Engine Comportment Left)				
21	21	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
3B						
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				
3D	1					

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	Sode See Page Joining Wire Harness and Wire Harness (Connector Location)					
IJ1	- 44	Facing Wire and Instrument Panel Wire (Instrument Panel Proce LLI)				
IJ2		Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)				
IL1	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)				


: GROUND POINTS


Code	See Page	Ground Points Location	
EB	40	Front Side of the Left Fender	
EC	40	Cylinder Head	
ID	42	ft Kick Panel	
IE	42	Instrument Panel Brace LH	
IG	42	Instrument Panel Brace RH	


: SPLICE POINTS

Code See Page Wire Harness with Splice Points		Code	See Page	Wire Harness with Splice Points		
ſ	18	44	Engine Wire			

ELECTRONICALLY CONTROLLED TRANSMISSION







SYSTEM OUTLINE

With the ignition SW turned on, the current flows to **TERMINAL 17** of the front wiper and washer SW, **TERMINAL 2** of the washer motor and **TERMINAL 6** of the front wiper motor through the **WIP** fuse.

1. LOW SPEED POSITION

With wiper SW turned to **LOW** position, the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 7** to **TERMINAL 3** of the front wiper motor to **TERMINAL 1** to **GROUND** and causes to the wiper motor to run at low speed.

2. HIGH SPEED POSITION

With wiper SW turned to **HIGH** position, the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 8** to **TERMINAL 2** of the front wiper motor to **TERMINAL 1** to **GROUND** and causes to the wiper motor to run at high speed.

3. INT POSITION (w/INTERMITTENT OPERATION)

With wiper SW turned to INT position, the relay operates and the current which is connected by relay function flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 2 to GROUND. This flow of current operates the intermittent circuit and the current flows from TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 3 of the front wiper motor to TERMINAL 1 to GROUND and the functions.

The intermittent operation is controlled by the charge/discharge function of the condenser installed in the relay, and the intermittent time is controlled by a time control SW (w/ intermittent volume SW) to change the charging time of the condenser.

4. MIST POSITION (w/ MIST SW)

With wiper SW turned to **MIST** position, the current flows from **TERMINAL 17** of the front wiper and washer SW to **TERMINAL 7** to **TERMINAL 3** of the front wiper motor to **TERMINAL 1** to **GROUND** and causes to the front wiper motor to run at low speed.

5. WASHER CONTINUOUS OPERATION

With the washer SW turned to on, the current flows from TERMINAL 2 of the washer motor to TERMINAL 1 to TERMINAL 1 of the front wiper and washer SW to TERMINAL 2 to GROUND and causes to the washer motor to run, and the window washer jet operates. This causes the current to flow to washer continuous operation circuit in TERMINAL 17 of the front wiper and washer SW to TERMINAL 7 to TERMINAL 3 of the front wiper motor to TERMINAL 1 to GROUND and the washer operates continuously.

6. WASHER OPERATION (w/o WASHER CONTINUOUS CONTROL)

With the washer SW turned to on, the current flows from **TERMINAL 2** of the washer motor to **TERMINAL 1** to **TERMINAL 1** of the front wiper and washer SW to **TERMINAL 2** to **GROUND** and causes the washer motor to run and the window washer jet operates only while the washer SW is pressed.

SERVICE HINTS

C17 FRONT WIPER AND WASHER SW [COMB. SW]

2-GROUND: Always continuity

17-GROUND: Approx. 12 volts with ignition SW at ON position

7-GROUND : Approx. 12 volts with wiper and washer SW at LOW position

: Approx. 12 volts with wiper and washer SW at MIST position (w/ mist SW)

: Approx. 12 volts every approx. 1 to 10 seconds intermittently with wiper and washer SW at INT position

(w/ intermittent operation)

16–GROUND : Approx. **12** volts with ignition SW on unless wiper motor at **STOP** position

8-GROUND: Approx. 12 volts with ignition SW on and wiper and washer SW at HIGH position

F3 FRONT WIPER MOTOR

6-5: Closed unless wiper motor at STOP position

) : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C17	36	J13	37	W2	35
F3	34	J14	37		

FRONT WIPER AND WASHER

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	unction Block and Wire Harness (Connector Location)		
IC	IC 22 Cowl Wire and Instrument Panel J/B (Lower Finish Panel)			
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1B	25	Cowl Wire and Driver Side J/B (Left Kick Panel)		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	42	Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)



: GROUND POINTS

Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IH	42	Right Kick Panel






F3 GRAY



J13


(Hint : See Page 7)




(Hint : See Page 7)

W2 BLACK







HEADLIGHT (CANADA)

SYSTEM OUTLINE

The current from the **FL MAIN** is always flowing from the **MAIN** fuse to HEAD relay (Coil side) to **TERMINAL 8** of the daytime running light relay (Main), and from **DOME** fuse to **TERMINAL 3** of the daytime running light relay (Main).

When the ignition SW is turned on, the current flowing through the **GAUGE** fuse flows to **TERMINAL 9** of the integration relay to **TERMINAL (A) 9** to **TERMINAL 2** of the daytime running light relay (Main).

1. DAYTIME RUNNING LIGHT OPERATION

When the engine is started, voltage generated at **TERMINAL L** of the generator is applied to **TERMINAL 14** of the daytime running light relay (Main). If the parking brake lever is pulled up (Parking brake SW on) at this time, the relay is not activated so the daytime running light system does not operate. If the parking brake lever is then released (Parking brake SW off), a signal is input to **TERMINAL 5** of the relay.

This activates the daytime running light relay (Main) and the HEAD relay is turned to on, so the current flows from the MAIN fuse to the HEAD relay (Point side) to TERMINAL 4 of the DIMMER relay to TERMINAL 1 to HEAD (LH-LWR), HEAD (RH-LWR) fuses to TERMINAL 1 of the headlights to TERMINALS 1 and 7 of the daytime running light relay (Main) to TERMINALS 11 and 12 to GROUND, causing the headlights to light up (Headlights light up dimmer than normal brightness.). Once the daytime running light system operates and the headlights light up, the headlights remain on even if the parking brake lever is pulled up (Parking brake SW on).

If the engine stalls and the ignition SW remains on, the headlights remain light up even through current is no longer output from **TERMINAL** L of the generator. If the ignition SW is then turned off, the headlights go off.

If the engine is started with the parking brake lever released (Parking brake SW off), the daytime running light system operates and headlights light up when the engine starts.

2. HEADLIGHT OPERATION

When the light control SW is switched to **HEAD** position and the dimmer SW is set to **LOW** position, causing the daytime running light relay (Main) and the HEAD relay to turn on, so the current flows from the **MAIN** fuse to HEAD relay (Point side) to **DRL** fuse to **TERMINAL 4** of the DRL relay to **TERMINAL 3** to **TERMINAL 1** of the diode (Daytime running light) to **TERMINAL 2** to **TERMINAL 13** of the light control SW to **TERMINAL 16** to **GROUND**, activating the DRL relay. The current to HEAD relay (Point side) then flows to **TERMINAL 4** of the DIMMER relay to **TERMINAL 1** to **HEAD** (**LH-LWR**), **HEAD** (**RH-LWR**) fuses to **TERMINAL 1** of the headlights to **TERMINAL 3** to **TERMINAL 1** of the DRL relay to **TERMINAL 2** to **GROUND**, causing the headlights to light up at normal intensity.

When the light control SW is switched to **HEAD** position and the dimmer SW is set to **HIGH** position, the signal from the dimmer SW is input to the daytime running light relay (Main). This activates the daytime running light relay (Main) and the HEAD relay is turned on, so the current flows from the **MAIN** fuse to HEAD relay (Point side) to **TERMINAL 4** of the DIMMER relay to **TERMINAL 2** to **TERMINAL 9** of the daytime running light relay (Main), activating the DIMMER relay. This causes current to flow from **TERMINAL 4** of the DIMMER relay to **TERMINAL 3** to **HEAD (LH)** or **HEAD (LH–UPR)**, **HEAD (RH)** or **HEAD (RH–UPR)** fuses to **TERMINAL 2** of the headlights to **TERMINAL 3** to **TERMINAL 1** of the DRL relay to **TERMINAL 2** to **GROUND**, causing the headlights to light up at high beam and the high beam indicator light to light up.

When the dimmer SW is switched to **FLASH** position, the signal from the dimmer SW is input to the daytime running light relay (Main). This activates the daytime running light relay (Main) and the HEAD relay is turned on, so the current flows from the **MAIN** fuse to HEAD relay (Point side) to **DRL** fuse to **TERMINAL 4** of the DRL relay to **TERMINAL 3** to **TERMINAL 1** of the diode (Daytime running light) to **TERMINAL 2** to **TERMINAL 8** of the dimmer SW to **TERMINAL 16** to **GROUND**, activating the DRL relay. At the same time, the current flows from the **TERMINAL 4** of the DIMMER relay to **TERMINAL 2** to **TERMINAL 9** of the daytime running light relay (Main), activating the DIMMER relay, and also flows from the **HEAD (LH)** or **HEAD (LH-UPR)**, **HEAD (RH)** or **HEAD (RH-UPR)** fuses to **TERMINAL 2** of the headlights to **TERMINAL 3** to **TERMINAL 1** of the DRL relay to **TERMINAL 2** to **GROUND**, causing the headlights to light up at high beam and the high beam indicator light to light up.

SERVICE HINTS

HEAD RELAY

1–2 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position Closed with the engine running and the parking brake lever is released (Parking brake SW off)

D3 DAYTIME RUNNING LIGHT RELAY (MAIN)

2-GROUND : Approx. 12 volts with the ignition SW at ON position

13-GROUND: Approx. 12 volts with the light control SW at HEAD position or the dimmer SW at FLASH position

3, 8-GROUND: Always approx. 12 volts

5-GROUND: Continuity with the parking brake lever pulled up

14-GROUND: 13.9-15.1 volts with the engine running at 2000 rpm 25°C (77°F)

11, 12-GROUND: Always continuity

6-GROUND: Continuity with the dimmer SW at HIGH or FLASH position

4-GROUND: Continuity with the brake fluid level not enough or the parking brake lever pulled up

: PARTS LOCATION

Co	de	See Page	Code		See Page	Code		See Page
В	2	34	G2		34	J8		37
C13	С	36	Н	l1	35	J9	Α	37
C14	D	36	Н	12	35	J10	В	37
C	15	36	I11	Α	37	J1	4	37
D3		36	J1		37	Р	3	37
D)4	36	J	2	37			

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)			
5	20	Engine Room R/B No.5 (Engine Compartment Left)			
6	21	Engine Room R/B No.6 (Radiator Support RH)			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1B	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
1C	25	
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
2B		
2G	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
21		
3A		Instrument Denel Wire and Contex I/D (Dehind the Combination Mater)
3B	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3C 28 Instrument Panel Wire and Center J/B (Behind the Combination Meter)		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	42	Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)

: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IH	42	Right Kick Panel

HEADLIGHT (CANADA)

\bigcirc

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	40	Engine Room Main Wire	14	44	Cowl Wire

(w/ ABS) B2 GRAY


(w/o ABS) B2 GRAY





C14 (D) GRAY
















D4 BLACK
























(Hint: See Page 7)




(Hint : See Page 7)









SYSTEM OUTLINE

The current from the **FL MAIN** is always flowing from the **MAIN** fuse to HEAD relay (Coil side) to **TERMINAL 19** of the daytime running light relay (Main), from **DOME** fuse to **TERMINAL 22** of the daytime running light relay (Main) and from the **ALT** fuse to TAIL relay (Coil side) to **TERMINAL 16** of the daytime running light relay (Main).

When the ignition SW is turned on, the current flowing through the **GAUGE** fuse flows to **TERMINAL 9** of the integration relay to **TERMINAL (A) 9** to **TERMINAL 23** of the daytime running light relay (Main).

1. DAYTIME RUNNING LIGHT OPERATION

When the engine is started, voltage generated at **TERMINAL L** of the generator is applied to **TERMINAL 13** of the daytime running light relay (Main). If the parking brake lever is pulled up (Parking brake SW on) at this time, the relay is not activated so the daytime running light system does not operate. If the parking brake lever is then released (Parking brake SW off), a signal is input to **TERMINAL 14** of the relay.

This activates the daytime running light relay (Main) and the HEAD relay is turned to on, so the current flows from the MAIN fuse to the HEAD relay (Point side) to TERMINAL 4 of the DIMMER relay to TERMINAL 1 to HEAD (LH-LWR), HEAD (RH-LWR) fuses to TERMINAL 1 of the headlights to TERMINALS 11 and 25 of the daytime running light relay (Main) to TERMINALS 1 and 12 to GROUND, causing the headlights to light up (Headlights light up dimmer than normal brightness.). Once the daytime running light system operates and the headlights light up, the headlights remain on even if the parking brake lever is pulled up (Parking brake SW on).

If the engine stalls and the ignition SW remains on, the headlights remain light up even through current is no longer output from **TERMINAL L** of the generator. If the ignition SW is then turned off, the headlights go off.

If the engine is started with the parking brake lever released (Parking brake SW off), the daytime running light system operates and headlights light up when the engine starts.

2. HEADLIGHT OPERATION

When the light control SW is switched to **HEAD** position and the dimmer SW is set to **LOW** position, causing the daytime running light relay (Main) and the HEAD relay to turn on, so the current flows from the **MAIN** fuse to HEAD relay (Point side) to **DRL** fuse to **TERMINAL 4** of the DRL relay to **TERMINAL 3** to **TERMINAL 18** of the daytime running light relay (Main) to **TERMINAL 2** to **TERMINAL 13** of the light control SW to **TERMINAL 16** to **GROUND**, activating the DRL relay. The current to HEAD relay (Point side) then flows to **TERMINAL 4** of the DIMMER relay to **TERMINAL 1** to **HEAD** (**LH-LWR**), **HEAD** (**RH-LWR**) fuses to **TERMINAL 1** of the headlights to **TERMINAL 3** to **TERMINAL 1** of the DRL relay to **TERMINAL 2** to **GROUND**, causing the headlights to light up at normal intensity.

When the light control SW is switched to **HEAD** position and the dimmer SW is set to **HIGH** position, the signal from the dimmer SW is input to the daytime running light relay (Main). This activates the daytime running light relay (Main) and the HEAD relay is turned on, so the current flows from the **MAIN** fuse to HEAD relay (Point side) to **TERMINAL 4** of the DIMMER relay to **TERMINAL 2** to **TERMINAL 20** of the daytime running light relay (Main), activating the DIMMER relay. This causes current to flow from **TERMINAL 4** of the DIMMER relay to **TERMINAL 3** to **HEAD (LH)** or **HEAD (LH–UPR)**, **HEAD (RH)** or **HEAD (RH–UPR)** fuses to **TERMINAL 2** of the headlights to **TERMINAL 3** to **TERMINAL 1** of the DRL relay to **TERMINAL 2** to **GROUND**, causing the headlights to light up at high beam and the high beam indicator light to light up.

When the dimmer SW is switched to **FLASH** position, the signal from the dimmer SW is input to the daytime running light relay (Main). This activates the daytime running light relay (Main) and the HEAD relay is turned on, so the current flows from the **MAIN** fuse to HEAD relay (Point side) to **DRL** fuse to **TERMINAL 4** of the DRL relay to **TERMINAL 3** to **TERMINAL 18**, of the daytime running light relay (Main) to **TERMINAL 2** to **TERMINAL 8** of the dimmer SW to **TERMINAL 16** to **GROUND**, activating the DRL relay. At the same time, the current flows from the **TERMINAL 4** of the DIMMER relay to **TERMINAL 2** to **TERMINAL 2** to of the daytime running light relay (Main), activating the DIMMER relay, and also flows from the **HEAD (LH)** or **HEAD (LH-UPR)**, **HEAD (RH)** or **HEAD (RH-UPR)** fuses to **TERMINAL 2** of the headlights to **TERMINAL 3** to **TERMINAL 1** of the DRL relay to **TERMINAL 2** to **GROUND**, causing the headlights to light up at high beam and the high beam indicator light to light up.

3. AUTOMATIC LIGHT CONTROL OPERATION

When the daytime running light is operating and the Automatic control sensor detects a decrease in the ambient light (It continues less than approx. **2500** lux over about **20** seconds, and it is less than **1000** lux.), the automatic light control operation starts. At the same time, daytime running light relay (Main) is activated, so current flows from the **ALT** fuse to the TAIL relay (Coil side) to **TERMINAL 16** of the daytime running light relay (Main), and the **DRL** fuse to the DRL relay (Coil side) to **TERMINAL 18** of the daytime running light relay (Main), activating both the TAIL relay and the DRL relay, so that the taillights and headlights light up.

When the automatic light control sensor detects an increase in the ambient light (It continues more than approx. **1000** lux over about **20** seconds, and it is more than approx. **2500** lux), the ignition SW is turned to off, the light control SW is turned to **HEAD** position, and the automatic light control operation stops.

HEADLIGHT (USA, PUERTO RICO)

SERVICE HINTS

HEAD RELAY

1–2 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position Closed with the engine running and the parking brake lever is released (Parking brake SW off)

D3 DAYTIME RUNNING LIGHT RELAY (MAIN)

23-GROUND : Approx. 12 volts with the ignition SW at ON position

2-GROUND : Approx. 12 volts with the light control SW at HEAD position or the dimmer SW at FLASH position

16, 19, 22-GROUND: Always approx. 12 volts

14-GROUND: Continuity with the parking brake lever pulled up

13–GROUND: 13.9–15.1 volts with the engine running at 2000 rpm 25 °C (77 °F)

1, 12-GROUND: Always continuity

3-GROUND : Continuity with the dimmer SW at HIGH or FLASH position

4-GROUND: Continuity with the brake fluid level not enough or the parking brake lever pulled up

: PARTS LOCATION

Code		See Page	Code		See Page	Code		See Page
A16		36	F4		34	J	2	37
B2		34	G2		34	J	8	37
C13	С	36	Н	11	35	J9	Α	37
C14	D	36	Н	12	35	J10	В	37
C15		36	I11 A		37	J14		37
D	3	36	J	1	37	P3		37

: RELAY BLOCKS

Code	See Page	elay Blocks (Relay Block Location)			
5	20	Engine Room R/B No.5 (Engine Compartment Left)			
6	21	Engine Room R/B No.6 (Radiator Support RH)			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)						
IB	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)						
IC	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)						
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)						
1B	0.5							
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)						
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)						
2B								
2G	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)						
21	1							
3A								
3B	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)						
3C								

CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	loining Wire Harness and Wire Harness (Connector Location)					
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)					
IK1	44	Instrument Denel Wire and Could Wire (Instrument Denel Brees DLI)					
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)					




: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IH	42	Right Kick Panel





Code	See Page	age Wire Harness with Splice Points		See Page	Wire Harness with Splice Points
E1	E1 40 Engine Room Main Wire				


















F4 (See Page 26)







(TMMC Made) J1 BLACK



(Hint : See Page 7)

(NUMMI Made) J1



(Hint: See Page 7)


J2 GRAY

AAXICO


(Hint : See Page 7)




(Hint : See Page 7)



(Hint : See Page 7)




(Hint : See Page 7)



(Hint : See Page 7)





___ SERVICE HINTS ____

HORN RELAY

5-3: Closed with the horn SW on.

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C16	36	H4	35		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)						
2F	07	Facing Doom Main Wire and Engine Doom I/D (Facing Compartment Left)						
21	21	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)						

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	oining Wire Harness and Wire Harness (Connector Location)				
IB2	42	Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)				
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)				

C16 BLACK

H4 BLACK







SERVICE HINTS _

D6, D7, D8, D9 DOOR COURTESY SW FRONT LH, RH, REAR LH, RH

1–GROUND : Closed with the door open **L4 LUGGAGE COMPARTMENT LIGHT SW**

1-GROUND: Closed with the luggage compartment door open

: PARTS LOCATION

Code	See Page	Co	de	See Page	Code	See Page
C11	36	19	9	37	J7	37
D5	36	I11	Α	37	J18	38
D6	38	l12	В	37	L3	39
D7	38	I1	3	38	L4	39
D8	38	J4	Α	37	M3	39
D9	38	J5	В	37		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1F	24	Floor Wire and Driver Side J/B (Left Kick Panel)
1G	24	Roof Wire and Driver Side J/B (Left Kick Panel)
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3B	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3C	20	institution ratio vite and center 3/5 (benind the combination Meter)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	pining Wire Harness and Wire Harness (Connector Location)				
IA1	42	Roof Wire and Cowl Wire (Near the Driver Side R/B)				
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)				


: GROUND POINTS

Code	See Page	Ground Points Location
ID	42	Left Kick Panel

Ī	Code	See Page	ee Page Wire Harness with Splice Points		See Page	Wire Harness with Splice Points
	B1					

INTERIOR LIGHT





_ SERVICE HINTS .

I10 IGNITION SW

7-6 : Closed with the ignition SW at **ON** or **ST** position

: PARTS LOCATION

Code	See Page	Code	Code See Page		See Page
E4	36	13	35	J11	37
12	35	I10	37	N1	37

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
IB	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
IC	22 Cowl Wire and Instrument Panel J/B (Lower Finish Panel)				
IG	IG 23 Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
2B	27	Engine Ream Main Wire and Engine Ream I/P (Engine Compartment Left)			
2G 27		Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)			

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IL2	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)

7 : GROUND POINTS

Code	See Page	Ground Points Location
EC	40	Cylinder Head

Γ	Code	Code See Page Wire Harness with Splice Points		Code	See Page	Wire Harness with Splice Points
	E1 40 Engine Room Main Wire					

E4 DARK GRAY





I2 GRAY



I3 BLACK








(Hint : See Page 7)

N1 GRAY





SYSTEM OUTLINE

The current is applied at all times to TERMINAL (A) 3 of the integration relay through the DOME fuse.

1. SEAT BELT WARNING SYSTEM

When the ignition SW is turned on and the driver's seat belt is not used, the current flows from the GAUGE fuse to the integration relay at the same time, the current flows to TERMINAL 9 of the relay from the GAUGE fuse through TERMINAL (A) 9 of the integration relay to TERMINAL (D) 2 of the seat belt warning light. This current activates the integration relay and, at intervals of approx. 0.6 seconds, current flowing through the warning light flows from TERMINAL (A) 2 of the relay to TERMINAL 7 to GROUND, causing the warning light to blink. At the same time as the warning light blinks, a seat belt retractor SW off signal is input to TERMINAL (A) 5 of the relay, the current flowing to TERMINAL (A) 3 of the relay flows from TERMINAL 7 to GROUND and the seat belt warning buzzer gose on for approx. 6 seconds. However, if the seat belt is put on during this period (while the buzzer is sounding and warning light blinking), signal input to TERMINAL (A) 5 of the relay stops, and the current flow from TERMINAL (A) 3 of the relay to TERMINAL 7 to GROUND is cut, stopping the buzzer and warning light blinking.

2. KEY REMINDER SYSTEM

With the ignition key inserted in the key cylinder (Unlock warning SW on), the ignition SW still off and the driver's door open (Door courtesy SW on), when a signal is input to **TERMINALS (A) 4** and **8** of the relay, the integration relay operates, the current flows from **TERMINAL (A) 3** of the relay to **TERMINAL 7** to **GROUND** and the key reminder buzzer gose on.

SERVICE HINTS

U1 UNLOCK WARNING SW

1-2: Closed with the ignition key in cylinder

S7 SEAT BELT RETRACTOR SW

1-2: Open with the driver's seat belt in use

I11 (A) INTEGRATION RELAY

9-GROUND : Approx. 12 volts with the ignition SW at ON position

7-GROUND: Always continuity

(A) 5-GROUND: Continuity with the driver's seat belt not use

(A) 4-GROUND : Continuity with the ignition key in cylinder

(A) 3-GROUND: Always approx. 12 volts

8-GROUND : Continuity with the front LH door open

: PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page	
C13	С	36	I11	Α	37	S7	39	
C14	D	36	J	8	37	U1	37	
D6		38	J1	9	38			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)		
IE	IE 23 Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)		
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)		
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)		
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)		
3B				
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)		
3D				

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


C	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
I	G2	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)


KEY REMINDER AND SEAT BELT WARNING


∇

: GROUND POINTS


Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
BI	46	Under the Left Quarter Pillar

























SYSTEM OUTLINE

The current is applied at all times to TERMINAL (A) 3 of the integration relay through the DOME fuse.

With the ignition SW in ACC position, the current flows to **TERMINAL 1** of the integration relay through the **CIG** fuse. When the ignition SW is turned to **ON** position, the current flows to **TERMINAL 9** of the integration relay through the **GAUGE** fuse. When the light control SW is turned to **TAIL** or **HEAD** position, current is applied to **TERMINAL 11** of the integration relay through the **TAIL** fuse.

LIGHT REMINDER SYSTEM

When the light control SW is in **TAIL** or **HEAD** position, the ignition SW turned to **OFF** from **ON** position, and the driver's door opened (Door courtesy SW on), the current flows to **TERMINAL 1** and **9** of the integration relay stops. As a result, the relay is activated and current flows from **TERMINAL (A) 3** of the relay to **TERMINAL 7** to **GROUND**, sounding the light reminder buzzer.

SERVICE HINTS

I11 (A) INTEGRATION RELAY

9-GROUND : Approx. 12 volts with the ignition SW at ON position

1–GROUND : Approx. 12 volts with the ignition SW at ACC or ON position

11-GROUND: Approx. 12 volts with the light control SW at TAIL or HEAD position

7-GROUND : Always continuity

8-GROUND: Continuity with the driver's door open

(A) 3-GROUND : Always approx. 12 volts

: PARTS LOCATION

Code	See Page	Code		See Page	Code	See Page
D6	38	I11	Α	37	J8	37

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)			
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)			
IE	23	nstrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)			
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)			
1E	24	nstrument Panel Wire and Driver Side J/B (Left Kick Panel)			
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)			
3B	20	Instrument Denel Wire and Contar I/D (Dehind the Combination Mater)			
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)			

: GROUND POINTS


Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH







(Hint: See Page 7)



SYSTEM OUTLINE

The current always flows to **TERMINAL 5** of the P/W relay through the **POWER** fuse, with the ignition SW turned on, the current flows through the **GAUGE** fuse to **TERMINAL 1** of the P/W relay. This activates the relay and the current flowing to **TERMINAL 5** of the P/W relay flows to **TERMINAL 3** to **TERMINAL 5** of the moon roof control relay.

1. SLIDE OPEN OPERATION

With the ignition SW turned on, and the moon roof closed completely, when the moon roof control SW is pushed to **OPEN** position, a signal is input from **TERMINAL 3** of the moon roof control SW to **TERMINAL 1** of the moon roof control relay. The moon roof limit SW LS1 is on and the moon roof limit SW LS2 is off at this time.

When this occurs, the relay is activated and the current to **TERMINAL 12** of the moon roof control relay flows from **TERMINAL 5** to **TERMINAL 2** of the moon roof motor to **TERMINAL 1** to **TERMINAL 4** of the moon roof control relay to **TERMINAL 11** to **GROUND** and rotates the motor to open the moon roof while the SW is being pushed to **OPEN** position. The moon roof limit SW LS1 and LS2 are both on.

2. SLIDE CLOSE OPERATION

With the ignition SW turned on, and the moon roof opend completely, and the moon roof limit SW LS1 and LS2 both on, when the moon roof control SW is pushed to **CLOSE** position, a signal is input from **TERMINAL 6** of the moon roof control SW to **TERMINAL 2** of the moon roof control relay.

When this occurs, the relay is activated and the current to **TERMINAL 12** of the moon roof control relay flows from **TERMINAL 4** of the relay to **TERMINAL 1** of the moon roof motor to **TERMINAL 2** to **TERMINAL 5** of the moon roof control relay to **TERMINAL 11** to **GROUND** and rotates the motor to close the moon roof while the SW is being pushed to **CLOSE** position. The moon roof limit SW LS1 turns off (Limit SW LS2 is on), a signal is input from **TERMINAL 5** of the moon roof limit SW LS1 to **TERMINAL 8** of the moon roof control relay. This signal activates the relay and stops continuous from **TERMINAL 12** of the

to **TERMINAL 8** of the moon roof control relay. This signal activates the relay and stops continuous from **TERMINAL 12** of the moon roof control relay to **TERMINAL 11**. As a result, the moon roof stops at this position. To close the moon roof completely, pushing the moon roof control SW again to the **CLOSE** position causes a signal to be input again to **TERMINAL 2** of the moon roof control relay. This activates the relay and the moon roof will close as long as the moon roof control SW is being pushed, allowing the moon roof to fully close.

3. TILT UP OPERATION

When the moon roof control SW is pushed to **TILT UP** position, with the ignition SW turned on and the moon roof completely closed (Moon roof limit SW LS2 is off), a signal is input from **TERMINAL 5** of the moon roof control SW to **TERMINAL 3** of the moon roof control relay. As a result, the relay is activated and the current to **TERMINAL 12** of the moon roof control relay flows from **TERMINAL 4** of the relay to **TERMINAL 1** of the moon roof motor to **TERMINAL 2** to **TERMINAL 5** of the moon roof control relay to **TERMINAL 11** to **GROUND** and rotates the motor so that tilt up operation occurs as long as the moon roof control SW is pushed on the **TILT UP** position.

4. TILT DOWN OPERATION

When the moon roof control SW is pushed to **TILT DOWN** position, with the ignition SW turned on and the moon roof tilted up (Moon roof limit SW LS1 and LS2 are both off), a signal is input from **TERMINAL 2** of the moon roof control SW to **TERMINAL 7** of the moon roof control relay.

As a result, the relay is activated and the current to **TERMINAL 12** of the moon roof control relay flows from **TERMINAL 5** of the relay to **TERMINAL 2** of the moon roof motor to **TERMINAL 1** to **TERMINAL 4** of the moon roof control relay to **TERMINAL 11** to **GROUND** and rotates the motor so that tilt down operation occurs as long as the moon roof control SW is pushed on the **TILT DOWN** position. (During tilt down, moon roof limit SW LS1 is changed from off to on.)

SERVICE HINTS

M2 MOON ROOF CONTROL RELAY

11-GROUND : Always continuity

6, 12-GROUND: Approx. 12 volts with the ignition SW at ON position

4–GROUND : Approx. **12** volts with the ignition SW on and the moon roof control SW at **CLOSE** or **UP** position 5–GROUND : Approx. **12** volts with the ignition SW on and the moon roof control SW at **OPEN** or **DOWN** position

M3 MOON ROOF CONTROL SW

5-4: Close with the moon roof control SW at **TILT UP** position

6-4 : Close with the moon roof control SW at **CLOSE** position

2-4: Close with the moon roof control SW at TILT DOWN position

3-4 : Close with the moon roof control SW at **OPEN** position

4-GROUND: Always continuity

MOON ROOF

: PARTS LOCATION

Co	ode	See Page	Code	See Page	Code	See Page
J4	Α	37	M2	39	M4	39
J5	В	37	M3	39		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	20	Driver Side R/B (Left Kick Panel)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)		
1B	0.5	Could Mine and Driver Cide 1/D /Lett (Cide Decell)		
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)		
1G	24	Roof Wire and Driver Side J/B (Left Kick Panel)		


7 : GROUND POINTS

Code	See Page	Ground Points Location
ID	42	Left Kick Panel

: SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
B1	46	Roof Wire			

J4 (A) BLACK



(Hint : See Page 7)

J5 (B) BLACK



(Hint: See Page 7)


M2




МЗ



M4





POWER SOURCE

SERVICE HINTS

HEAD RELAY

1–2 : Closed with the light control SW at **HEAD** position or the dimmer SW at **FLASH** position

: Closed with the engine running and the parking brake lever is released (Paking brake SW off)

TAIL RELAY

5-3: Closed with the light control SW at TAIL or HEAD position

I10 IGNITION SW

2–3 : Closed with the ignition SW at \boldsymbol{ACC} or \boldsymbol{ON} position

2-4: Closed with the ignition SW at ON or ST position

7-6: Closed with the ignition SW at ON or ST position

7-8 : Closed with the ignition SW at ST position

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
F4	34	I10	37		
G1	34	J1	37		

) : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)		
5	20	Engine Room R/B No.5 (Engine Compartment Left)		
6	21	Engine Room R/B No.6 (Radiator Support RH)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)		
IA	22	Facing Doom Main Wire and Instrument Donal I/D /I quar Finish Donal)		
IB	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)		
IG	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)		
2A	- 27			
2B				
2F		Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)		
2G				
2H				
21				

: GROUND POINTS

Code	See Page	Ground Points Location
EA	40	Front Side of the Right Fender
EB	40	Front Side of the Left Fender


: SPLICE POINTS


Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	40	Engine Room Main Wire			

(See Page 26)


F4








(Hint: See Page 7)





POWER WINDOW

SYSTEM OUTLINE

When the ignition SW is turned on, the current flows through the **GAUGE** fuse to **TERMINAL 1** of the P/W relay to **TERMINAL 2** to **GROUND**. This activates the relay and the current flows through the **POWER** fuse to **TERMINAL 5** of the relay to **TERMINAL 3** to **TERMINAL BW** of the power window master SW, **TERMINAL 4** of the power window control SW.

1. MANUAL OPERATION (DRIVER'S WINDOW)

With the ignition SW turned on and with the power window master SW (Front LH) in **UP** position, the current flowing to **TERMINAL BW** of the power window master SW flows to **TERMINAL DU** of the master SW to **TERMINAL 1** of the power window motor to **TERMINAL 2** to **TERMINAL DD** of the master SW to **TERMINAL E** to **GROUND** and rotates the power window motor in the up direction. The window ascends only while the SW is being pushed. In down operation, the flows of current from to **TERMINAL BW** of the power window master SW to **TERMINAL DD** of the master SW causes the flows of current from **TERMINAL 2** of the motor to **TERMINAL 1** to **TERMINAL DU** of the master SW to **TERMINAL E** to **GROUND**, flowing in the opposite direction to manual up operation and rotating the motor in reverse, thus opening the window.

2. AUTO DOWN OPERATION (DRIVER'S WINDOW)

When the front LH window control SW in the power window master SW is pushed strongly on the down side, current flows from **TERMINAL BW** of the master SW to **TERMINAL DD** to **TERMINAL 2** of the power window motor to **TERMINAL 1** to **TERMINAL DU** of the master SW to **TERMINAL E** to **GROUND**. Because the hold circuit inside the master SW keeps the relay on the down side activated, the power window motor continues operating even if the power window master SW is released. When the driver's window is fully opened, the hold circuit turns off and the relay on the down side turns off, and auto down operation is completed.

3. STOPPING OF AUTO DOWN OPERATION (DRIVER'S WINDOW)

When the master SW (Front LH) is pulled to the up side during auto down operation, a ground circuit opens in the master SW and current does not flow from **TERMINAL DU** of the master SW to **TERMINAL E**, so the motor stops, causing auto down operation to stop. If the master SW is pulled continuously, the motor rotates in the up direction in manual up operation.

4. MANUAL OPERATION (FRONT RH, REAR RH WINDOW)

With the power window control SW (Front RH, rear RH) pulled to the up side, current flowing from **TERMINAL 4** of the power window control SW flows to **TERMINAL 3** to **TERMINAL 2** of the power window motor to **TERMINAL 1** to **TERMINAL 1** of the power window control SW to **TERMINAL 2** to **TERMINALS PD**, **RRD** of the master SW to **TERMINAL E** to **GROUND** and rotates the power window motor (Front RH, rear RH) in the up direction. Up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from **TERMINAL 1** to **TERMINAL 2**, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the passenger's window becomes open. As a result, even if Open/Close operation of the passenger's window is attempted, the current from **TERMINAL E** of the power window master SW is not grounded and the motor does not rotate, so the passenger's window can not be operated and window lock occurs.

5. MANUAL OPERATION (REAR LH WINDOW)

With the power window control SW (Rear LH) pulled to the up side, current flowing from **TERMINAL 4** of the power window control SW flows to **TERMINAL 3** to **TERMINAL 1** of the power window motor to **TERMINAL 2** to **TERMINAL 2** to **TERMINAL RLD** of the master SW to **TERMINAL E** to **GROUND** and rotates the power window motor (Rear LH) in the up direction. Up operation continues only while the power window control SW is pulled to the up side. When the window descends, the current flowing to the motor flows in the opposite direction, from **TERMINAL 2** to **TERMINAL 1**, and the motor rotates in reverse. When the window lock SW is pushed to the lock side, the ground circuit to the passenger's window becomes open. As a result, even if Open/Close operation of the passenger's window is attempted, the current from **TERMINAL E** of the power window master SW is not grounded and the motor does not rotate, so the passenger's window can not be operated and window lock occurs.

SERVICE HINTS

P7 POWER WINDOW MASTER SW

 $\mbox{BW-GROUND}$: Approx. 12 volts with the ignition SW at \mbox{ON} position

DU-GROUND: Approx. 12 volts with the ignition SW on and master SW (Front LH window) at UP posotion

DD-GROUND: Approx. 12 volts with the ignition SW on and master SW (Front LH window)

at **DOWN** or **AUTO DOWN** position

E-GROUND: Always continuity

WINDOW LOCK SW

Open with window lock SW at LOCK position

: PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
J4	Α	37	P5	39	P9	39
J5	В	37	P6	39	P10	39
J.	16	38	P7	39	P11	39
F	94	39	P8	39		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	20	Driver Side R/B (Left Kick Panel)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	lunction Block and Wire Harness (Connector Location)			
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)			
1B	25	Could Wire and Driver Cide I/D (Left Kiels Banel)			
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)			

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
ID1	40	Front Door LH Wire and Cowl Wire (Near the Driver Side J/B)	
ID2	42		
IM2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)	
BA1	46 Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)		
BB1	46	Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)	

: GROUND POINTS


Code	See Page	Ground Points Location
ID	42	Left Kick Panel



(Hint : See Page 7)



(Hint : See Page 7)






P8, P9, P10, P11 BLUE

J16

(Hint : See Page 7)



SERVICE HINTS

R3 (B) RADIO AND PLAYER

(B) 4-GROUND : Always approx. 12 volts

(B) 3-GROUND : Approx. 12 votls with the ignition SW at ACC or ON position

(B) 7-GROUND : Always continuity

: PARTS LOCATION

Co	de	See Page	Code		See Page	Code	See Page
F5		38	R2	Α	37	R10	39
F	6	38	R3	В	37		
I11	Α	37	R	9	39		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)	
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)	
1E	24	strument Panel Wire and Driver Side J/B (Left Kick Panel)	
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)	
3A			
3B	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)	
3C			


: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	oining Wire Harness and Wire Harness (Connector Location)	
IF1	42	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)	
IG2	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)	
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)	
IM1	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)	


7 : GROUND POINTS

Code	See Page	Ground Points Location
IG	42	Instrument Panel Brace RH














SERVICE HINTS

FLASHER RELAY

2-GROUND : Approx. 12 volts with the ignition SW on or the hazard SW on

1-GROUND : Changes from 12 to 0 volts with the ignition SW on and the turn signal SW at LH or RH position,

or with the hazard SW on

3-GROUND : Always continuity

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C13	36	F2	34	J8	37
C15	36	H5	36	R7	39
F1	34	J1	37	R8	39

) : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)	
1	20	Driver Side R/B (Left Kick Panel)	

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
IJ	22	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
1A	24	Ingine Room Main Wire and Driver Side J/B (Left Kick Panel)			
1B	0.5	Count Military and Delivery Citles I/D (Laft Miles Dane)			
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)			
1D	0.4	Joséph Joseph Million and Driven Cida 1/D // off (Cida Dana)			
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
1F	24	Floor Wire and Driver Side J/B (Left Kick Panel)			
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)			

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)	
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)	


: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
BJ	46	Lower Back Panel Center

Ī	Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
	I 1	44	Engine Room Main Wire			


TURN SIGNAL AND HAZARD WARNING LIGHT




















SERVICE HINTS _

R5 REMOTE CONTROL MIRROR SW

9--6 : Continuity with the operation SW at **DOWN** or **RIGHT** position 6–10 : Continuity with the operation SW at **UP** or **LEFT** position

9--GROUND : Approx. 12 votls with the ignition SW at \boldsymbol{ACC} or \boldsymbol{ON} position

10-GROUND : Always continuity

: PARTS LOCATION

С	ode	See Page	Code	See Page	Code	See Page
l11	Α	37	J8	37	R13	39
	J7	37	R5	37	R14	39

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)			
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)			
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			
3B					
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)			
3D					


: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	42	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)
IM1	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)


: GROUND POINTS

Code	See Page	Ground Points Location
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH













R13, R14











RADIATOR FAN AND AIR CONDITIONING

SYSTEM OUTLINE

1. HEATER BLOWER MOTOR OPERATION

The current is applied at all times through the **ALT** fuse to the **HTR** fuse to **TERMINAL 1** of the HTR relay. When the ignition SW is turned on, the current flows through the **GAUGE** fuse to **TERMINAL 5** of the HTR relay to coil to **TERMINAL 3** to **TERMINAL 3** of the blower SW.

* Low speed operation

When the blower SW is moved to **LO** position, the current flows to **TERMINAL 3** of the blower SW to **TERMINAL 1** to **GROUND**, turning the HTR relay on. This causes the current to flow from the **HTR** fuse to **TERMINAL 1** of the HTR relay to **TERMINAL 2** to **TERMINAL 2** to **TERMINAL 4** of the blower resistor to **TERMINAL 1** to **GROUND**, rotating the blower motor at low speed.

* Medium speed operation (Operation at M1, M2)

When the blower SW is moved to M1 position, the current flows to TERMINAL 3 of the blower SW to TERMINAL 1 to GROUND, turning the HTR relay on. This causes the current to flow from the HTR fuse to TERMINAL 1 of the HTR relay to TERMINAL 2 to TERMINAL 1 of the blower motor to TERMINAL 2 to TERMINAL 4 of the blower resistor to TERMINAL 3 to TERMINAL 4 of the blower SW to TERMINAL 1 to GROUND. At this time, the blower resistance of the blower resistor is less than at low speed, so the blower motor rotates at medium low speed.

When the blower SW is moved to M2 position, the current through the motor flows from TERMINAL 4 of the blower resistor to TERMINAL 2 to TERMINAL 8 of the blower SW to TERMINAL 1 to GROUND. At this time, resistance of the blower resistor is less than at M1 position, so the blower motor rotates at medium high speed.

* High speed operation

When the blower SW is moved to HI position, the current flows to TERMINAL 3 of the blower SW to TERMINAL 1 to GROUND, turning the HTR relay on.

This causes the current to flow from the HTR fuse to TERMINAL 1 of the HTR relay to TERMINAL 2 to TERMINAL 1 of the blower motor to TERMINAL 2 to TERMINAL 5 of the blower SW to TERMINAL 1 to GROUND, rotating the blower motor at high speed.

2. FAN MOTOR OPERATION

When the ignition SW is turned on, the current from the **ECU–IG** fuse flows to the FAN NO.1 relay (Coil side) and the A.C FAN NO.2 relay (Coil side) to **TERMINAL 3** of the A/C single pressure SW to **TERMINAL 2** to **TERMINAL 1** of the water temp. SW (Radiator fan) to **GROUND**, and the FAN NO.1 relay is turned off and the A.C FAN NO.2 relay is turned on.

At the same time as this current flow, the current from the **ECU-IG** fuse flows to the ENGINE MAIN relay (Coil side) to **GROUND**, turning the ENGINE MAIN relay on. As a result, current from the **ALT** fuse flows to the **CDS** fuse and **RDI** fuse.

* Low speed operation

When the ignition SW is turned on and the A/C is activated, the current flows from the ALT fuse to the HTR fuse to the HTR relay (Point side) to the A.C fuse to the A.C MG relay (Point side) to the A.C FAN NO.3 relay (Coil side) to GROUND, turning the A.C FAN NO.3 relay on. As a result, the current from the CDS fuse flows to TERMINAL 2 of the A/C condenser fan motor to TERMINAL 1 to the A.C FAN NO.2 relay (Point side) to the A.C FAN NO.3 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND. As a result, the fans are activated at low speed.

If the engine coolant temperature is approx. **90**°C (**194**°F) or less, and the refrigerant pressure is approx. **15.5** kgf/cm² (**220** psi, **1520** kpa) or less, both the water temp. SW (Radiator fan) and the A/C single pressure SW are closed, so the FAN NO.1 relay is turned off and the A.C FAN NO.2 relay is turned on. As a result, each fan motor operates at low speed.

* High speed operation

During A/C operation, if the refrigerant pressure becomes higher than ordinary level (Approx. 15.5 kgf/cm² (220 psi, 1520 kpa)), the A/C single pressure SW is turned off. As a result, the FAN NO.1 relay is turned on and the A.C FAN NO.2 relay is turned off, and the current flows from the RDI fuse to FAN NO.1 relay (Point side) to TERMINAL 2 of the radiator fan motor to TERMINAL 1 to GROUND, and the current from the CDS fuse flows to TERMINAL 2 of the A/C condenser fan motor to TERMINAL 1 to A.C FAN NO.2 relay (Point side) to GROUND, reaching each fan motor in parallel, thus causing the fan motors to operate at high speed.

Note that, because the current flows in the same manner even if the engine coolant temperature is approx. **90**°C (**194**°F) or higher, the fan motors still operate at high speed.

3. AIR CONDITIONING OPERATION

When the blower SW is set on, the current from the **ALT** fuse flows to the **HTR** fuse to the HTR relay (Point side) to the **A.C** fuse to **TERMINAL 1** of the A/C dual pressure SW to **TERMINAL 4** to **TERMINAL 2** of the A/C amplifier. The engine RPM signal from the engine control module, the evaporator temp. signal from the A/C evaporator temp. sensor and the lock signal from the lock sensor are all supplied to the A/C amplifier.

When the A/C SW is turned on, the A/C SW on signal is sent to the **TERMINAL 7** of the A/C amplifier. At the same time, the current flows from the **A.C** fuse to **TERMINAL 1** of the A.C MG relay to coil to **TERMINAL 2** to **TERMINAL 11** of the A/C amplifier to **TERMINAL 5** to **GROUND**, turning the A.C MG relay on.

This causes the current from the **A.C** fuse to flow to the A/C magnetic clutch, turning the A/C magnetic clutch on.

When any of the following signals are input to the A/C amplifier, the amplifier operates to turn off the air conditioning.

- * Engine low RPM signal.
- * A signal that the temperature at evaporator is low.
- * A signal that the refrigerant pressure is abnormally high or low.
- * A signal that the A/C compressor is locked.

4. DEF SYNCHRONIZED CONTROL FUNCTION

When the air vent mode control lever is turned to DEF mode, the A/C SW is automatically turned on.

SERVICE HINTS

FAN NO. 1 RELAY

4-3: Open with the ignition SW on, the A/C single pressure SW on and the water temp. SW (Radiator fan) on

A.C FAN NO. 2 RELAY

- 3-4: Closed with the ignition SW off, the A/C single pressure SW off or the water temp. SW (Radiator fan) off
- 3-5: Closed with the ignition SW on, the A/C single pressure SW on and the water temp. SW (Radiator fan) on

A.C FAN NO. 3 RELAY

3-5: Closed with the ignition SW on and the A.C MG relay on

HTR RELAY

1-2: Closed with the ignition SW on and the blower SW on

A3 A/C TRIPLE PRESSURE SW (A/C DUAL AND SIGNAL PRESSURE SW)

- 1–4 : Open with the refrigerant pressure at less than approx. **196.1** kpa (**2.0** kgf/cm², **28.4** psi) or more than approx. **3138.1** kpa (**32.0** kgf/cm², **458** psi)
- 2-3: Open with the refrigerant pressure more than 1520 kpa (15.5 kgf/cm², 220 psi)

W3 WATER TEMP. SW (RADIATOR FAN)

1–GROUND : Open above approx. 90°C (194°F) Closed below approx. 83°C (181°F)

A10 A/C AMPLIFIER

2–GROUND : Approx. 12 volts with the ignition SW at **ON** position, the blower SW at **LO**, **M1**, **M2** or **HI** position and the A/C dual pressure SW on

and the AVC dual pre

5-GROUND: Always continuity

7–GROUND : Approx. 12 volts with the ignition SW at **ON** position, the blower SW at **LO**, **M1**, **M2** or **HI** position and the A/C SW at **ON** position or the air vent mode control lever at **DEF** mode

9–GROUND: Below 4 volts with the ignition SW at **ON** position, the blower SW at **LO**, **M1**, **M2** or **HI** position and the A/C SW at **ON** position or the air vent mode control lever at **DEF** mode

: PARTS LOCATION

Code	See Page	Code		See Page	Code	See Page
A1	34	B4		36	J10	37
A2	34	В	5	36	J13	37
A3	34	E	:6	36	J14	37
A10	36	F4		34	R1	35
A11	36	l11	Α	37	W3	35
A12	36	J	1	37		
В3	36	J	8	37		

RADIATOR FAN AND AIR CONDITIONING

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)		
5	20	Engine Room R/B No.5 (Engine Compartment Left)		
6	21	Engine Room R/B No.6 (Radiator Support RH)		

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)				
IA	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)				
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)				
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
2B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
2C	27	Engine Wire and Engine Room J/B (Engine Compartment Left)				
2E	21					
2F						
2G	07	Engine Deem Main Wire and Engine Deem I/D (Feeing Compartment Left)				
2H	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)				
21						
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)				


: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	loining Wire Harness and Wire Harness (Connector Location)			
IB2	42	ngine Room Main Wire and Cowl Wire (Near the Driver Side R/B)			
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)			
IK1	44	Jacks words Danel Wire and Could Wire (Jacks words Danel Danes DU)			
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)			
IL1	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)			

: GROUND POINTS

Code	See Page	Ground Points Location
EA	40	Front Side of the Right Fender
EB	40	Front Side of the Left Fender
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IH	42	Right Kick Panel

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	44	Engine Room Main Wire	17	44	Cowl Wire
16	44	Cowl Wire			





__ SERVICE HINTS

DEF RELAY

5-3: Closed with the ignition SW at \mathbf{ON} position and the rear window defogger SW on

: PARTS LOCATION

Code		See Page	Code	See Page	Code		See Page
C	13	36	J8	37	R11	Α	39
l11	Α	37	R4	37	R12	В	39

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)	
IE	22	Instrument Denel Wire and Instrument Denel I/D (Leuver Finish Denel)	
IH	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)	
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)	
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)	
3A	20	Instrument Denel Wire and Contar I/D (Dehind the Combination Mater)	
3C ²⁸		Instrument Panel Wire and Center J/B (Behind the Combination Meter)	


: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS


Code	See Page	loining Wire Harness and Wire Harness (Connector Location)	
IG2	42 Floor Wire and Instrument Panel Wire (Left Kick Panel)		

7 : GROUND POINTS

Code	See Page	ound Points Location		
ID	42	Left Kick Panel		
IE	42	trument Panel Brace LH		
BK	46	Under the Right Quarter Pillar		








(w/ Timer) R4 BLACK (w/o Timer) R4 BLACK R11 (A) BLACK R12 (B) BLACK











SERVICE HINTS

S6 STOP LIGHT SW

2-1: Closed with the brake pedal depressed

: PARTS LOCATION


Code	See Page	Code	See Page	Code	See Page
H7	38	J19	38	R8	39
J18	38	R7	39	S6	37

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
IC	IC 22 Cowl Wire and Instrument Panel J/B (Lower Finish Panel)				
1B	1B 25 Cowl Wire and Driver Side J/B (Left Kick Panel)				
1F	24 Floor Wire and Driver Side J/B (Left Kick Panel)				

: GROUND POINTS

Ī	Code	See Page	round Points Location			
Ī	BI	46	nder the Left Quarter Pillar			
Ī	BJ	46	Lower Back Panel Center			



J18 DARK GRAY

(Hint : See Page 7)

J19 BLUE



(Hint: See Page 7)

R7, R8




(w/ Cruise Control) S6 BLUE

(w/o Cruise Control) S6 BLUE







SYSTEM OUTLINE

When the ignition SW is turned to ACC position the current from the CIG fuse flows to TERMINAL 1 of the integration relay to TERMINAL (A) 1 to TERMINAL 1 of the shift lock ECU, if it is in ON position, the current from the ECU-IG fuse flows to TERMINAL 5 of the ECU.

1. SHIFT LOCK MECHANISM

With the ignition SW at **ON** position, when a signal that the brake pedal is depressed (Stop light SW on) and a signal that the shift lever is put in "**P**" position (Continuity between P1 and P of the shift lock control SW) is input to the ECU, the ECU operates and the current flows from **TERMINAL 5** of the ECU to **TERMINAL** "**SLS+**" of the shift lock solenoid to **TERMINAL** "**SLS-**" to **TERMINAL 3** of the ECU to **GROUND**. This causes the shift lock solenoid to turn on (Plate stopper disengages) and the shift lever can shift into position other than "**P**".

2. KEY INTERLOCK MECHANISM

With the ignition SW at **ON** or **ACC** position, when the shift lever is put in "P" position (No continuity between P2 and P of the shift lock control SW), the current flowing from **TERMINAL 4** of the ECU to the key interlock solenoid is cut off. This causes the key interlock solenoid to turn off (Lock lever disengages from **LOCK** position) and the ignition key can be turned from **ACC** to **LOCK** position.

SERVICE HINTS

S3 SHIFT LOCK ECU

1-GROUND: Approx. 12 volts with the ignition SW at ACC or ON position

5-GROUND : Approx. 12 volts with the ignition SW at ON position

3-GROUND: Always continuity

2-GROUND: Approx. 12 volts with the brake pedal depressed

S6 STOP LIGHT SW

2-1: Closed with the brake pedal depressed

: PARTS LOCATION

Co	ode	See Page	Code	See Page	Code	See Page
l11	Α	37	S3	37	U1	37
J8		37	S6	37		


: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR


Code	See Page	Junction Block and Wire Harness (Connector Location)				
IC	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)				
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)				
1B	25	Cowl Wire and Driver Side J/B (Left Kick Panel)				
1C	25					
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)				
3B		Instrument Panel Wire and Center J/B (Behind the Combination Meter)				
3C	28					
3D						

7 : GROUND POINTS


Γ	Code	See Page	Ground Points Location	
Γ	ID	42	Left Kick Panel	
Γ	IE	42	Instrument Panel Brace LH	

SHIFT LOCK











(w/o Cruise Control) S6 BLUE






NOTICE: When inspecting or repairing the SRS, perform the operation in accordance with the following precautionary instructions and the procedure and precautions in the Repair Manual for the applicable model year.

- Malfunction symptoms of the SRS are difficult to confirm, so the DTCs become the most important source of information
 when troubleshooting. When troubleshooting the SRS, always inspect the DTCs before disconnecting the battery.
- Work must be started after 90 seconds from when the ignition switch is turned to the "LOCK" position and the
 negative (–) terminal cable is disconnected from the battery.
 (The SRS is equipped with a back–up power source so that if work is started within 90 seconds from disconnecting
 the negative (–) terminal cable of the battery, the SRS may be deployed.)
- When the negative (-) terminal cable is disconnected from the battery, the memory of the clock and audio system will be
 canceled. So before starting work, make a record of the contents memorized in the audio memory system. When work is
 finished, reset the audio systems as they were before and adjust the clock. To avoid erasing the memory in each memory
 system, never use a back-up power supply from outside the vehicle.
- Before repairs, remove the airbag sensor if shocks are likely to be applied to the sensor during repairs.
- Do not expose the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor or side airbag sensor assembly directly to hot air or flames.
- Even in cases of a minor collision where the SRS does not deploy, the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor assembly, front airbag sensor and side airbag sensor assembly should be inspected.
- Never use SRS parts from another vehicle. When replacing parts, replace them with new parts.
- Never disassemble and repair the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt
 pretensioner or airbag sensor assembly in order to reuse it.
- If the steering wheel pad, front passenger airbag assembly, side airbag assembly, seat belt pretensioner, airbag sensor
 assembly, front airbag sensor or side airbag sensor assembly has been dropped, or if there are cracks, dents or other
 defects in the case, bracket or connector, replace them with new ones.
- Use a volt/ohmmeter with high impedance (10 kΩ/V minimum) for troubleshooting the system's electrical circuits.
- Information labels are attached to the periphery of the SRS components. Follow the instructions on the notices.
- After work on the SRS is completed, pertorm the SRS warning light check or SRS side airbag warning light check.
- If the vehicle is equipped with a mobile communication system, refer to the precaution in the IN section of the Repair Manual.



* 1 : SHIELDED * 2 : W/ SIDE AIRBAG



SYSTEM OUTLINE

The SRS is a driver and front passenger protection device which has a supplemental role to the seat belts.

When the ignition SW is turned to ACC or ON, current from the CIG fuse flows to TERMINAL (B) 4 of the center airbag sensor assembly. Only when the ignition SW is on does the current flow from the IGN fuse to TERMINAL (B) 3 of the center airbag sensor assembly.

If an accident occurs while driving, when the frontal impact exceeds a set level, the current from the CIG or IGN fuse flows to TERMINALS (B) 10, (B) 7, (A) 2 and (C) 5 of the center airbag sensor assembly to TERMINAL 1 of the airbag squibs and the pretensioners to TERMINAL 2 to TERMINALS (B) 9, (B) 8, (A) 1 and (C) 6 of the center airbag sensor assembly to TERMINAL (B) 16, (B) 17 or BODY GROUND to GROUND, so that the current flows to the front airbag squibs and the pretensioners, and causes them to operate.

When the side impact also exceeds a set level, the current from the CIG or IGN fuse flows to TERMINALS (A) 5 and (C) 2 of the center airbag sensor assembly to TERMINAL 1 of the side airbag squibs to TERMINAL 2 to TERMINALS (A) 6 and (C) 1 of the center airbag sensor assembly to TERMINAL (B) 16, (B) 17 or BODY GROUND to GROUND, causing side airbag squibs to operate.

The airbag stored inside the steering wheel pad is instantaneously expanded to soften the shock to the driver.

The airbag stored inside the passenger's instrument panel is instantaneously expanded to soften the shock to the front passenger.

Side airbags are instantaneously expanded to soften the shock of side to the driver and front passenger.

The pretensioners make sure of the seat belt restrainability.

: PARTS LOCATION

Co	de	See Page	Code		See Page	Code	See Page
Α	.7	34	C12	В	36	J13	37
A8		34		D	36	P12	39
A ²	13	36	D	1	34	P13	39
A ²	14	36	D	2	36	S4	37
C4	Α	36	J	6	37	S5	37
C5	В	36	J	8	37	S8	39
C6	С	36	J1	11	37	S9	39

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)			
IE		Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
IF	23				
IJ	22	nstrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)			
1C	25	owl Wire and Driver Side J/B (Left Kick Panel)			
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)			

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
IE1	42	ngine Room Main Wire and Instrument Panel Wire (Near the Driver Side J/B)				
II1	42	owl Wire and Instrument Panel Wire (Lower Finish Panel)				
IJ1	44	Francisco Mine and Instrument Decal Mine (Instrument Decal Decay III)				
IJ2	44	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)				
IK1	44	nstrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)				
IL1	44	ngine Wire and Cowl Wire (Instrument Panel Brace RH)				

: GROUND POINTS

Code	See Page	round Points Location			
EC	40	/linder Head			
ID	42	Left Kick Panel			
IE	42	Instrument Panel Brace LH			
IF	42				



Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
18	44	Engine Wire			

A7, A8 YELLOW

A13 YELLOW

A14 YELLOW


C4 (A) YELLOW


C5 (B) YELLOW













C6 (C) YELLOW


(w/ Theft Deterrent System) C12 (B)





(w/o Theft Deterrent System) C12 (B)




(USA, Puerto Rico) C14 (D) GRAY












J6 BLACK



(Hint : See Page 7)



(Hint : See Page 7)

(Hint : See Page 7)

J13

(Hint : See Page 7)

1 2


P12, P13 YELLOW

S4, S5 YELLOW



S8, S9 YELLOW





_ SERVICE HINTS _

S1 (A), S2 (B) STARTER

Points closed with the shift lever at $\bf P$ or $\bf N$ position on and the ignition SW at $\bf ST$ position (A/T) Points closed with the clutch padel depressed and the ignition SW at $\bf ST$ position (M/T)

: PARTS LOCATION

Co	de	See Page	Co	de	See Page	Co	de	See Page
C.	10	36	J9	Α	37	S1	Α	35
E4	Α	36	J10	В	37	S2	В	35
E6	С	36	D1	Α	35	Т	3	37
J	1	37] [7]	В	35			

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
2B	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2D	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2E	21	Engine whe and Engine Room 3/B (Engine Compartment Leit)
21	27	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

	Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)	
Ī	IB2 42 Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)			
	IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)	
Γ	IL2	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)	

: GROUND POINTS


Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E1	1 40 Engine Room Main Wire				


STARTING



E4 (A) DARK GRAY




E6 (C) DARK GRAY




J1


(Hint:See Page 7)




(Hint : See Page 7)



(Hint : See Page 7)





(3A/T) P1 (B) GRAY














THEFT DETERRENT

SERVICE HINTS

D10, D11 DOOR KEY LOCK AND UNLOCK SW LH, RH

1-3: Closed with the door key cylinder unlocked with the key

2-3: Closed with the door key cylinder locked with the key

E3 ENGINE HOOD COURTESY SW

1-2: Closed with the engine hood open

U1 UNLOCK WARNING SW

2-1: Closed with the key in the ignition key cylinder

L2 LUGGAGE COMPARTMENT KEY UNLOCK SW

2-1: Closed with the luggage compartment key cylinder unlock with the key

L4 LUGGAGE COMPARTMENT LIGHT SW

1-GROUND: Closed with the luggage compartment door open

T3 (A), T4 (B) THEFT DETERRENT ECU

(A) 5–GROUND : Continuity with the shift lever in **N** or **P** position and the ignition SW at **ST** position (A/T) Continuity with the clutch pedal depressed and the ignition SW at **ST** position (M/T)

(B) 6-GROUND: Continuity with the key in the ignition key cylinder

(B)14-GROUND: Continuity with the front LH door to UNLOCK position

(B)15-GROUND: Continuity with the front RH door to UNLOCK position

(B) 4-GROUND: Continuity with the front LH door open

(B) 5-GROUND: Continuity with the front RH door open

(B) 8-GROUND: Continuity with the door key lock and unlock SW LH, RH to LOCK position

(A) 7-GROUND: Always continuity

(B) 9-GROUND: Continuity with the door key lock and unlock SW LH to UNLOCK position

(A) 1, (A) 9, (A)11, (B)11-GROUND: Always approx. 12 volts

(B) 7-GROUND: Continuity with the luggage compartment key unlock SW to UNLOCK position

(B) 3-GROUND: Continuity with the engine hood open

(B)12-GROUND: Approx. 12 volts with the ignition SW at ACC or ON position

(B)16-GROUND: Continuity with the rear LH or RH door to UNLOCK position

(B) 1-GROUND: Continuity with the front RH, rear LH or RH door open

(B) 2-GROUND: Continuity with the ruggage compartment door open

(B)10-GROUND: Continuity with the door key lock and unlock SW RH to UNLOCK position

(B)13-GROUND: Approx. 12 volts with the ignition SW at ON position

: PARTS LOCATION

Code	See Page	Co	Code See Page		Code		See Page
C10	36	D1	16	38	J15		38
C12	36	D1	17	38	J1	7	38
D3	36	E3		34	J1	8	38
D5	36	F	4	34	J19		38
D6	38	Н	4	35	L2		39
D7	38	l11	Α	37	L4		39
D8	38	J4	Α	37	P1	Α	35
D9	38	J5	В	37	FI	В	35
D10	38	J	8	37	T1		35
D11	38	J9	Α	37	T3	Α	37
D14	38	J10	В	37	T4	В	37
D15	38	J1	4	37	U	1	37

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)					
IB	22	Engine Room Main Wire and Instrument Panel J/B (Lower Finish Panel)					
IC	22	Could Mire and Instrument Decel I/D / Javer Finish Decel					
ID	22	Cowl Wire and Instrument Panel J/B (Lower Finish Panel)					
IE	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)					
1A	24	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)					
1B	0.5	Could Military and Deliver Cide 1/D (Left Viels Depol)					
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)					
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)					
1F	24	Floor Wire and Driver Side J/B (Left Kick Panel)					
2D	27	Engine Wire and Engine Room J/B (Engine Compartment Left)					
2F	27	Engine Deem Main Wire and Engine Deem I/D /Engine Compartment Left)					
21	21	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)					
3A							
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)					
3D							

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)				
IB2	42	Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)				
IC1	42	Floor Wire and Cowl Wire (Near the Driver Side J/B)				
ID1	42	Front Door LH Wire and Cowl Wire (Near the Driver Side J/B)				
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)				
IK1	44	Instrument Penal Wire and Coul Wire (Instrument Penal Press PLI)				
IK2	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)				
IL2	44	Engine Wire and Cowl Wire (Instrument Panel Brace RH)				
IM2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)				
BA1	46	Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)				
BB1	46	Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)				


: GROUND POINTS

Code	See Page	Ground Points Location
EB	40	Front Side of the Left Fender
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IG	42	Instrument Panel Brace RH
IH	42	Right Kick Panel
BI	46	Under the Left Quarter Pillar




Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
l1	44	Engine Room Main Wire	14	44	Cowl Wire
12	44	Carril Mina		44	Cowi wile
13	44	Cowl Wire			


THEFT DETERRENT



(4A/T) P1 (A) GRAY



(3A/T) P1 (B) GRAY




T1 BLACK




T3 (A)





T4 (B)

















J GROUND POINT

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J1	37	J14	37	J17	38
J2	37	J15	38	J19	38
J8	37	J16	38		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	20	Driver Side R/B (Left Kick Panel)
5	20	Engine Room R/B No.5 (Engine Compartment Left)
6	21	Engine Room R/B No.6 (Radiator Support RH)

: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
IE	22	Instrument Denel Wire and Instrument Denel I/D (Lower Finish Denel)
IF	23	Instrument Panel Wire and Instrument Panel J/B (Lower Finish Panel)
1B	- 25	Coul Wire and Driver Side I/P (Left Kick Panel)
1C	25	Cowl Wire and Driver Side J/B (Left Kick Panel)
1E	24	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
1G	24	Roof Wire and Driver Side J/B (Left Kick Panel)
2E	27	Engine Wire and Engine Room J/B (Engine Compartment Left)
2F	27	Facing Doom Main Wire and Facing Doom I/D /Facing Compartment Laft
21	21	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
3A		
3B	20	Instrument Denel Wire and Center I/D /Dehind the Combination Mater)
3C	28	Instrument Panel Wire and Center J/B (Behind the Combination Meter)
3D		

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
ID1	42	Front Door LH Wire and Cowl Wire (Near the Driver Side J/B)
IG2	42	Floor Wire and Instrument Panel Wire (Left Kick Panel)
IH1	42	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)
IJ1	44	Familia Wire and last report Densi Wire (last report Densi Drass LLI)
IJ2	44	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)
IK1	44	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)
IM2	44	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BA1	46	Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)
BB1	46	Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)

∇

: GROUND POINTS

Code	See Page	Ground Points Location
EA	40	Front Side of the Right Fender
EB	40	Front Side of the Left Fender
EC	40	Cylinder Head
ID	42	Left Kick Panel
IE	42	Instrument Panel Brace LH
IF	42	Instrument Panel Brace LH
IG	42	Instrument Panel Brace RH
IH	42	Right Kick Panel
BI	46	Under the Left Quarter Pillar
BJ	46	Lower Back Panel Center
BK	46	Under the Right Quarter Pillar

\bigcirc

: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	44	Engine Room Main Wire	18	44	Engine Wire
12	44	Cowl Wire	B1	46	Roof Wire

(TMMC Made) J1 BLACK



(Hint: See Page 7)

(NUMMI Made) J1



(Hint : See Page 7)

J2 GRAY




(Hint : See Page 7)

J8

(Hint: See Page 7)

J14



(Hint : See Page 7)

J15 BLACK



(Hint : See Page 7)

J16

(Hint : See Page 7)

J17 BLACK




(Hint : See Page 7)

(Hint : See Page 7)

The chart below shows the route by which current flows from the battery to each electrical source (Fusible Link, Circuit Breaker, Fuse, etc.) and other parts.


The next page and following pages show the parts to which each electrical source outputs current.



These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system. not necessarily on the page indicated here.

[LOCATION] 48

(1): Instrument Panel J/B (See page 22) (2): Engine Room J/B (See page 26)



③ : Engine Room R/B No. 5 (See page 20)(4) : Engine Room R/B No. 6 (See page 21)

		*Page Nos. of Related Systems	190	190	190	158	190	104 190	104	110	84 90 184	104 190	110	110	163	118	104	118	62 72 136 184	68	184	100	184
Location		Parts Code or Location	A/C Condenser Fan Motor	A/C Magnetic Clutch and Lock Sensor	A/C Triple Pressure SW (A/C Dual and Single Pressure SW)	ABS Actuator and ECU	A/C Amplifier	A/C SW	Ashtray Illumination	Back-Up Light SW	Brake Fluid Level Warning SW	Blower SW	Back-Up Light LH	Back-Up Light RH	Center Airbag Sensor Assembly	Cigarette Lighter	Cigarette Lighter Illumination	Clock	Clutch Start SW	Charge Warning Light [Comb. Meter]	Combination Meter	Open Door Warning Light [Comb. Meter]	Combination Meter
100		CB or Fuse	A1	A2	А3	A4	A10	A12	A15	В1	В2	В5	В6	В7	C5	С7	C8	С9	C10		C11		C12
1	5A 7.5A 7.5A 7.5A 7.5A 10A 10A 15A 15A 15A 20A 30A	ST ECU-B IGN OBD TURN DEF I-UP / M-HTR ECU-IG GAUGE CIG STOP TAIL WIP D/L POWER			•	•		•	•	•	•	•	•	•	•	•	•	•		•	•		•
2	5A 10A 10A 10A 10A 15A 15A 30A	ALT-S HAZARD *1 *2 HORN DOME EFI or F-HTR RDI																•			•	•	
3	7.5A 10A 10A 30A 7.5A	DRL HEAD (LH-LWR) HEAD (RH-LWR) CDS A.C	•	•	•		•	•															

^{*}These are the page numbers of the first page on which the related system is shown.

The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①: Instrument Panel J/B (See page 22)② : Engine Room J/B (See page 26)

4: Engine Room R/B No. 6 (See page 21) : Driver Side R/B (See page 20)

C12 C13 C14 C15 C16 C17 C18 C19 D1 D2 D3 D4 E2 E4 E6 F1 F2 F3 F7 G2 H	104	163	72 146 152 184	180	96	158	72,84 90,146 152,184	90	96	116	112	152	152	72 163	72	68 84 90 184	90	184	62 72 146	62 72 146	96 104	96 104	112	72 184	68	84 90
	Combination Meter [Comb. Meter]	SRS Warning Light [Comb. Meter]	Combination Meter	Rear Window Defogger Indicator Light [Comb. Meter]	Turn Signal Indicator Light [Comb.Meter]	ABS Warning Light [Comb. Meter]	Combination Meter	Combination SW	Turn Signal SW [Comb. SW]	Horn SW [Comb. SW]	Front Wiper and Washer SW [Comb. SW]	Cruise Control Clutch SW	Cruise Control ECU		Data Link Connector 3	Daytime Running Light Relay (Main)	Diode (Daytime Running Light)	Engine Coolant Temp. Sensor and Water Temp. Sender	Engine Control Module	Engine Control Module	Front Turn Signal and Parking Light LH	Front Turn Signal and Parking Light RH	Front Wiper Motor	Fuel Pump and Sender	Generator	Headlight LH
	C1	12		C13			C14	C.	15	C16	C17	C18	C19	D1	D2	D3	D4	E2	E4	E6	F1	F2	F3	F7	G2	Н1
																			•	•						
																•									•	
															•											
			•	•					•											•	•					
													•													
			•			•	•					•	•			•		•		•				•	•	
													•							•						
	•																			•	•	•				
											•												•			
																									•	
					•													-			•	•				
										•																
																•										
														•					•	•				•		
								•									•									\dashv
																•										•
																•										
											\dashv															

		*Page Nos. of Related Systems	84 90	72	116 136	96 104	72	108	72	100	68,72,84,90,100 104,110,118,120,136 146,152,158,170,174 176,180,182,184,190	128 132	100	104	100	100	142	100 142	142	186
Location		Parts Code or Location	Headlight RH	Heated Oxygen Sensor (Bank 1 Sensor 1)	Horn	Hazard SW	Heated Oxygen Sensor (Bank 1 Sensor 2)	High Mounted Stop Light	Idle Air Control Valve	Ignition Key Cylinder Light	Integration Relay	Integration Relay	Interior Light	License Plate Light	Luggage Compartment Light	Luggage Compartment Light SW	Moon Roof Control Relay	Moon Roof Control SW	Moon Roof Motor and Limit SW	Oil Pressure SW
Loc		CB or Fuse	Н2	НЗ	Н4	Н5	Н6	Н7	11	19	l11	112	113	L1	L3	L4	M2	МЗ	М4	01
	5A	ST																		
	7.5A	ECU-B																		
	7.5A	IGN																		
	7.5A	OBD																		
	7.5A	TURN				•														
	10A	DEF I-UP / M-HTR																		
1	10A	ECU-IG																		
	10A	GAUGE																		•
	15A	CIG									•	ļ <u>.</u>								
	15A	STOP						•												
	15A	TAIL				•					•			•						
	20A	WIP																		
	30A	D/L										•								
	30A	POWER															•	•	•	
	5A	ALT-S										ļ								
	10A	HAZARD			ļ	•	ļ					-	ļ							
	10A	*1										ļ								
2	10A	*2	•		ļ							<u> </u>	<u> </u>							
	10A	HORN			•			ļ				1								
	15A	DOME								•	•	1	•	ļ	•	•		•		
	15A	EFI or F-HTR		•			•		•							ļ	<u> </u>			
\bot	30A	RDI			ļ						- War -								L	
	7.5A	DRL																	L	
3	10A	HEAD (LH-LWR)							<u> </u>			1		ļ			ļ			
	10A	HEAD (RH-LWR)	•									<u> </u>					<u> </u>			
	30A	CDS										<u> </u>							<u> </u>	
4	7.5A	A.C												L						

^{*}These are the page numbers of the first page on which the related system is shown.

The part indicated is located somewhere in the system, not necessarily on the page indicated here.

(LOCATION) (1): Instrument Panel J/B (See page 22) 2 : Engine Room J/B (See page 26)

4 : Engine Room R/B No. 6 (See page 21) : Driver Side R/B (See page 20)

104 146	62,72 110,136 146,152 184	84 90 184	122	122	122	122	122	122	122	122	190	104 182	104 180	120	104 184	96	108	104	96	108	104	120	120	170	108,146 152,158 170	62 136
WS Q/O	Park/Neutral Position SW	Parking Brake SW	Power Window Control SW Front RH	Power Window Control SW Rear LH	Power Window Control SW Rear RH	Power Window Master SW	Power Window Motor Front LH	Power Window Motor Front RH	Power Window Motor Rear LH	Power Window Motor Rear RH	Radiator Fan Motor	Radio and Player	Rear Window Defogger SW	Remote Control Mirror SW	Rheostat	Rear Turn Signal Light LH [Rear Comb. Light LH]	Stop Light LH [Rear Comb. Light LH]	Taillight LH [Rear Comb. Light LH]	Rear Turn Signal Light RH [Rear Comb. Light RH]	Stop Light RH [Rear Comb. Light RH]	Taillight RH [Rear Comb. Light RH]	Remote Control Mirror LH	Remote Control Mirror RH	Shift Lock ECU	Stop Light SW	Theft Deterrent ECU
02	P1	Р3	P4	P5	Р6	P7	Р8	P9	P10	P11	R1	R3	R4	R5	R6		R7			R8		R13	R14	S3	S6	тз
	•																									•
																•			•							
•	-	•											•											•		
												•		•								•	•	•		
•												•	•		•		•	•		•	•			•	•	
			•				•	•	•	•																•
																•			•							
												•														•
_											•															
+			-			\dashv					•										<u> </u>			-		

③ : Engine Room R/B No. 5 (See page 20)

		*Page Nos. of Related Systems	136	72 146 152 184	72	72	184	112	190	180	72 146	72 146	58 190	190	190	116 136	62 136	190	190	190	190	190	84 90	84 90
Location		Parts Code or Location	Theft Deterrent ECU	Vehicle Speed Sensor	VSV (ORVR)	VSV (Vapor Pressure Sensor)	Washer Level Warning SW	Washer Motor	Water Temp. SW (Radiator Fan)	DEF Relay (Coil Side)	EFI or F-HTR Relay (Coil Side)	EFI or F-HTR Relay (Point Side)	ENGINE MAIN Relay (Coil Side)	FAN NO.1 Relay (Coil Side)	FAN NO.1 Relay (Point Side)	HORN Relay	ST Relay (Coil Side)	A.C FAN NO.2 Relay (Coil Side)	A.C FAN NO.2 Relay (Point Side)	A.C FAN NO.3 Relay (Coil Side)	A.C FAN NO.3 Relay (Point Side)	A.C MG Relay	DRL Relay (Coil Side)	DRL Relay (Point Side)
٤		CB or Fuse	T4	V1	V2	V4	W1	W2	W3	1				2						3			4	Ð
	5A	ST															•							
	7.5A	ECU-B																						
	7.5A	IGN									•													
	7.5A	OBD											L											
	7.5A	TURN																						
	10A	DEF I-UP / M-HTR							_															
1	10A	ECU-IG	•						•				•	•				•						
	10A	GAUGE	_	•			•			•								ļ						
	15A	CIG	•																					\Box
	15A	STOP																						
	15A	TAIL																				_		\square
	20A	WIP						•																
	30A	D/L																						
\vdash	30A	POWER																						
	5A 10A	ALT-S HAZARD									•													$\vdash \vdash \vdash$
	10A	*1												<u> </u>				<u> </u>		ļ				•
	10A	*2																						
2	10A	HORN				-		-					<u> </u>			•							$\mid - \mid \mid$	
	15A	DOME	•								-												$\vdash \vdash \vdash$	
	15A	EFI or F-HTR			•	•						•						-						
	30A	RDI													•									
	7.5A	DRL										-	 					<u> </u>					•	
	10A	HEAD (LH-LWR)																 -		 				•
3	10A	HEAD (RH-LWR)																	-					
	30A	CDS														-		-	•		•			
. '																								

^{*}These are the page numbers of the first page on which the related system is shown. The part indicated is located somewhere in the system, not necessarily on the page indicated here.

[LOCATION] ①: Instrument Panel J/B (See page 22) ②: Engine Room J/B (See page 26) 54

4: Engine Room R/B No. 6 (See page 21) 5: Driver Side R/B (See page 20)


190	72	96	122 142	122 142
(A) HTR Relay (Coil Side)	C/OPN Relay	FLASHER Relay	P/W Relay (Coil Side)	P/W Relay (Point Side)
4		Œ.		
		•		
				•
	-			
	•			
ļ				

③ : Engine Room R/B No. 5 (See page 20)


MEMO


: Location of Connector Joining Wire Harness and Wire Harness

: Location of Ground Points




: Location of Splice Points






Code	Joining Wire Harness and Wire Harness (Connector Location)
EA1	Engine No. 4 Wire and Engine Wire (Inside of the Intake Manifold RH)


: Location of Connector Joining Wire Harness and Wire Harness





: Location of Ground Points



- *1: w/ Theft Deterrent System
- *2: w/o Theft Deterrent System









Code	Joining Wire Harness a Wire Harness (Connector Location)					
IA1	Roof Wire and Cowl Wire (Near the Driver Side R/B)					
IB1	Francis - Decare Main Wise and Occad Wise (New the Driver Cide D/D)					
IB2	Engine Room Main Wire and Cowl Wire (Near the Driver Side R/B)					
IC1	Floor Wire and Cowl Wire (Near the Driver Side J/B)					
ID1	Front Door LH Wire and Cowl Wire (Near the Driver Side J/B)					
ID2	Tion boot Lit wife and cowi wife (Near the Driver Side 3/b)					
IE1	Engine Room Main Wire and Instrument Panel Wire (Near the Driver Side J/B)					
IF1	Front Door LH Wire and Instrument Panel Wire (Left Kick Panel)					
IG1						
IG2	Floor Wire and Instrument Panel Wire (Left Kick Panel)					
IH1	Engine Room Main Wire and Instrument Panel Wire (Lower Finish Panel)					
II1	Cowl Wire and Instrument Panel Wire (Lower Finish Panel)					


: Location of Connector Joining Wire Harness and Wire Harness





: Location of Splice Points



*1: w/ Theft Deterrent System*2: w/o Theft Deterrent System









Code	Joining Wire Harness a Wire Harness (Connector Location)					
IJ1	Engine Wire and Instrument Panel Wire (Instrument Panel Brace LH)					
IJ2	Engine Wile and mediament raner wile (mediament raner Brase Eng					
IK1	Instrument Panel Wire and Cowl Wire (Instrument Panel Brace RH)					
IK2						
IL1	Engine Wire and Cowl Wire (Instrument Banel Bross BH)					
IL2	Engine Wire and Cowl Wire (Instrument Panel Brace RH)					
IM1	Front Door RH Wire and Cowl Wire (Right Kick Panel)					
IM2	Florit Door KH Wile and Cowr Wile (Right Rick Faher)					

: Location of Connector Joining Wire Harness and Wire Harness


: Location of Ground Points




: Location of Splice Points



- *1: w/ Theft Deterrent System
- *2: w/o Theft Deterrent System




Code	Joining Wire Harnesss a Wire Harness (Connector Location)
BA1	Rear Door LH Wire and Cowl Wire (Under the Left Center Pillar)
BB1	Rear Door RH Wire and Cowl Wire (Under the Right Center Pillar)
BC1	Fuel Control Sub Wire and Floor Wire (Rear Wheel House LH)



- A: System Title
- B. Indicates the wiring color.

Wire colors are indicated by an alphabetical code.


The first letter indicates the basic wire color and the second letter indicates the color of the stripe.



- (a): Indicates the connector to be connected to a part (the numeral indicates the pin No.)
- The position of the parts is the same as shown in the wiring diagram and wire routing.
- The numbering system is different for female Indicates the pin number of the connector. and male connectors.

from upper right to Numbered in order lower left Example: Numbered in order from upper left to lower right





The numbering system for the overall wiring diagram is the same as above.

Indicates a Relay Block. No shading is used and only the Relay Block No. is shown to distinguish it from the J/B. <u>...</u>


Example: Indicates Relay Block No. 1.

G: Junction Block (The number in the circle is the J/B No. and the connector code is shown beside clearly it). Junction Blocks are shaded to separate them from other parts.

Example:

that it is inside Junction Block No. 3. 3B indicates

- E Indicates related system.
- connector. The wiring harness with male . Indicates the wiring harness and wiring harness terminal is shown with arrows (♥). Outside numerals are pin numbers.



- connector, etc. when the vehicle model, engine J: () is used to indicate different wiring and type, or specification is different.
- (K): Indicates a shielded cable.




- Indicates and located on ground point.
- (M): The same code occuring on the next page indicates that the wire harness is continuous.

SYSTEM INDEX

1998 Model (Location No. 1 to 20)

SYSTEMS	LOCATION	SYSTEMS	LOCATION	SYSTEMS	LOCATION
ABS	16–2	Headlight	4–2	Radio and Player	18–3
Back-up Light	5–4	Horn	14–1	Rear Window Defogger	14–3
Charging	1–4	Ignition	1–3	Remote Control Mirror	9–2
Cigarette Lighter and Clock	14–2	Interior Light	6–2	Shift Lock	18–2
Combination Meter	19–2	Key Reminder and Seat Belt Warning	8–4	SRS	17–2
Cruise Control	15–2	Light Reminder Buzzer	8–3	Starting	1–2
Door Lock Control	12-1 (NUMMI Made) 11-14 (TMMC Made)	Moon Roof	9–3	Stop Ligjht	6–3
Electronically Controlled Transmission	3–2	Power Source	1~20–1	Taillight and Illumination	7–2
Engine Control	2–2	Power Window	10–2	Theft Deterrent	13–2
Front Wiper and Washer	8–2	Radiator Fan and Air Conditioning	20–2	Turn Signal and Hazard Warning Light	5–2



19 COROLLA(Cont' d)