

# Ford Escape & Mazda Tribute

2001 thru 2007

Includes Mercury Mariner

36022



## Haynes Repair Manual

*Based on a complete teardown and rebuild*



*Includes essential information for today's more complex vehicles*

# Contents

## Introductory pages

About this manual	0-5
Introduction	0-5
Vehicle identification numbers	0-6
Buying parts	0-6
Maintenance techniques, tools and working facilities	0-7
Jacking and towing	0-13
Booster battery (jump) starting	0-14
Fraction/decimal/millimeter equivalents	0-15
Conversion factors	0-16
Safety first!	0-17
Automotive chemicals and lubricants	0-18
Troubleshooting	0-19

## Chapter 1

Tune-up and routine maintenance	1-1
---------------------------------	-----

## Chapter 2 Part A

Four-cylinder engines	2A-1
-----------------------	------

## Chapter 2 Part B

V6 engine	2B-1
-----------	------

## Chapter 2 Part C

General engine overhaul procedures	2C-1
------------------------------------	------

## Chapter 3

Cooling, heating and air conditioning systems	3-1
---	-----

## Chapter 4

Fuel and exhaust systems	4-1
--------------------------	-----

## Chapter 5

Engine electrical systems	5-1
---------------------------	-----

## Chapter 6

Emissions and engine control systems	6-1
--------------------------------------	-----

## Chapter 7 Part A

Manual transaxle	7A-1
------------------	------

## Chapter 7 Part B

Automatic transaxle	7B-1
---------------------	------

## Chapter 7 Part C

Transfer case	7C-1
---------------	------

## Chapter 8

Clutch and driveline	8-1
----------------------	-----

## Chapter 9

Brakes	9-1
--------	-----

## Chapter 10

Suspension and steering systems	10-1
---------------------------------	------

## Chapter 11

Body	11-1
------	------

## Chapter 12

Chassis electrical system	12-1
---------------------------	------

## Wiring diagrams

12-25

## Index

IND-1



# Contents

0-6	Introduction
0-6	About this manual
0-6	Vehicle identification numbers
0-6	Vehicle parts
0-7	Electrical system
0-7	Engine and cooling system
0-7	Drivetrain
0-7	Brakes
0-7	Steering and suspension
0-7	Body and paint
0-7	Wiring diagrams
0-7	Index



Haynes mechanic, author and photographer with a 2002 Ford Escape

# About this manual

## Its purpose

The purpose of this manual is to help you get the best value from your vehicle. It can do so in several ways. It can help you decide what work must be done, even if you choose to have it done by a dealer service department or a repair shop; it provides information and procedures for routine maintenance and servicing; and it offers diagnostic and repair procedures to follow when trouble occurs.

We hope you use the manual to tackle the work yourself. For many simpler jobs, doing it yourself may be quicker than arranging an appointment to get the vehicle into a shop and making the trips to leave it and pick it up. More importantly, a lot of money can be saved by avoiding the expense the shop must pass on to you to cover its labor and overhead

costs. An added benefit is the sense of satisfaction and accomplishment that you feel after doing the job yourself.

## Using the manual

The manual is divided into Chapters. Each Chapter is divided into numbered Sections, which are headed in bold type between horizontal lines. Each Section consists of consecutively numbered paragraphs.

At the beginning of each numbered Section you will be referred to any illustrations which apply to the procedures in that Section. The reference numbers used in illustration captions pinpoint the pertinent Section and the Step within that Section. That is, illustration 3.2 means the illustration refers to Section 3 and Step (or paragraph) 2 within that Section.

Procedures, once described in the text, are not normally repeated. When it's necessary to refer to another Chapter, the reference will be given as Chapter and Section number. Cross references given without use of the word "Chapter" apply to Sections and/or paragraphs in the same Chapter. For example, "see Section 8" means in the same Chapter.

References to the left or right side of the vehicle assume you are sitting in the driver's seat, facing forward.

Even though we have prepared this manual with extreme care, neither the publisher nor the author can accept responsibility for any errors in, or omissions from, the information given.

## NOTE

A **Note** provides information necessary to properly complete a procedure or information which will make the procedure easier to understand.

## CAUTION

A **Caution** provides a special procedure or special steps which must be taken while completing the procedure where the Caution is found. Not heeding a Caution can result in damage to the assembly being worked on.

## WARNING

A **Warning** provides a special procedure or special steps which must be taken while completing the procedure where the Warning is found. Not heeding a Warning can result in personal injury.

# Introduction

This manual covers the Ford Escape, Mazda Tribute and Mercury Mariner. The available engines are:

The 2.0L Zetec in-line four-cylinder engine, 2.3L in-line four-cylinder engine and the 3.0L Duratec V6 engine.

The engine drives the front wheels through either a five-speed manual or a four-

speed automatic transaxle via independent driveaxles. On 4WD models the rear wheels are also propelled, via a driveshaft, rear differential, and two rear driveaxles.

Suspension is independent at all four wheels, MacPherson struts being used at the front end and trailing arms, control arms, coil springs and telescopic shock absorbers at the

rear. The rack-and-pinion steering unit is mounted on the suspension crossmember.

The brakes are disc at the front and drums at the rear, with power assist standard. Some models are equipped with an optional Anti-lock Brake System (ABS).



# Vehicle identification numbers

Modifications are a continuing and unpublicized process in vehicle manufacturing. Since spare parts manuals and lists are compiled on a numerical basis, the individual vehicle numbers are essential to correctly identify the component required.

## Vehicle Identification Number (VIN)

This very important identification number is stamped on a plate attached to the dashboard inside the windshield on the driver's side of the vehicle (see illustration). The VIN also appears on the Vehicle Certificate of Title and Registration. It contains information such as where and when the vehicle was manufactured, the model year and the body style.

## Manufacturer's Certification Regulation label

The Manufacturer's Certification Regulation label is attached to the driver's side door end or post (see illustration). The label contains the name of the manufacturer, the month

and year of production, the Gross Vehicle Weight Rating (GVWR), the Gross Axle Weight Rating (GAWR) and the certification statement.


## VIN model year code

Counting from the left, the model year code letter designation is the 10th character. On all models covered by this manual the model year codes are:

1 .....	2001
2 .....	2002
3 .....	2003
4 .....	2004
5 .....	2005
6 .....	2006
7 .....	2007

## Engine number

On four-cylinder models, the engine identification number is stamped into a machined pad on the front-side of the engine under the exhaust manifold.




The Vehicle Identification Number (VIN) is visible through the driver's side of the windshield

On V6 models, the engine identification number is stamped into a machined pad on the right end (driver's side) of the engine block (see illustration).



Location of the Manufacturer's Certification Regulation label



Location of the engine identification number - V6 engine

# Buying parts

Replacement parts are available from many sources, which generally fall into one of two categories - authorized dealer parts departments and independent retail auto parts stores. Our advice concerning these parts is as follows:

**Retail auto parts stores:** Good auto parts stores will stock frequently needed components which wear out relatively fast, such as clutch components, exhaust systems, brake parts, tune-up parts, etc. These stores often supply new or reconditioned parts on an

exchange basis, which can save a considerable amount of money. Discount auto parts stores are often very good places to buy materials and parts needed for general vehicle maintenance such as oil, grease, filters, spark plugs, belts, touch-up paint, bulbs, etc. They also usually sell tools and general accessories, have convenient hours, charge lower prices and can often be found not far from home.

**Authorized dealer parts department:** This is the best source for parts which are

unique to the vehicle and not generally available elsewhere (such as major engine parts, transmission parts, trim pieces, etc.).

**Warranty information:** If the vehicle is still covered under warranty, be sure that any replacement parts purchased - regardless of the source - do not invalidate the warranty!

To be sure of obtaining the correct parts, have engine and chassis numbers available and, if possible, take the old parts along for positive identification.

# Maintenance techniques, tools and working facilities

## Maintenance techniques

There are a number of techniques involved in maintenance and repair that will be referred to throughout this manual. Application of these techniques will enable the home mechanic to be more efficient, better organized and capable of performing the various tasks properly, which will ensure that the repair job is thorough and complete.

## Fasteners

Fasteners are nuts, bolts, studs and screws used to hold two or more parts together. There are a few things to keep in mind when working with fasteners. Almost all of them use a locking device of some type, either a lockwasher, locknut, locking tab or thread adhesive. All threaded fasteners should be clean and straight, with undamaged threads and undamaged corners on the hex head where the wrench fits. Develop the habit of replacing all damaged nuts and bolts with new ones. Special locknuts with nylon or fiber inserts can only be used once. If they are removed, they lose their locking ability and must be replaced with new ones.


Rusted nuts and bolts should be treated with a penetrating fluid to ease removal and prevent breakage. Some mechanics use turpentine in a spout-type oil can, which works quite well. After applying the rust penetrant, let it work for a few minutes before trying to loosen the nut or bolt. Badly rusted fasteners may have to be chiseled or sawed off or removed with a special nut breaker, available at tool stores.



If a bolt or stud breaks off in an assembly, it can be drilled and removed with a special tool commonly available for this purpose.


Most automotive machine shops can perform this task, as well as other repair procedures, such as the repair of threaded holes that have been stripped out.


Flat washers and lockwashers, when

removed from an assembly, should always be replaced exactly as removed. Replace any damaged washers with new ones. Never use a lockwasher on any soft metal surface (such as aluminum), thin sheet metal or plastic.



Grade	Identification
Hex Nut Grade 5	 3 Dots
Hex Nut Grade 8	 6 Dots
Standard hex nut strength markings	

Grade	Identification
Hex Nut Property Class 9	 Arabic 9
Hex Nut Property Class 10	 Arabic 10
Metric hex nut strength markings	





### Fastener sizes

For a number of reasons, automobile manufacturers are making wider and wider use of metric fasteners. Therefore, it is important to be able to tell the difference between standard (sometimes called U.S. or SAE) and metric hardware, since they cannot be interchanged.

All bolts, whether standard or metric, are sized according to diameter, thread pitch and length. For example, a standard 1/2 - 13 x 1 bolt is 1/2 inch in diameter, has 13 threads per inch and is 1 inch long. An M12 - 1.75 x 25 metric bolt is 12 mm in diameter, has a thread pitch of 1.75 mm (the distance between threads) and is 25 mm long. The two bolts are nearly identical, and easily confused, but they are not interchangeable.

In addition to the differences in diameter, thread pitch and length, metric and standard bolts can also be distinguished by examining the bolt heads. To begin with, the distance across the flats on a standard bolt head is measured in inches, while the same dimension on a metric bolt is sized in millimeters (the same is true for nuts). As a result, a standard wrench should not be used on a metric bolt and a metric wrench should not be used on a standard bolt. Also, most standard bolts have slashes radiating out from the center of the head to denote the grade or strength of the bolt, which is an indication of the amount of torque that can be applied to it. The greater the number of slashes, the greater the strength of the bolt. Grades 0 through 5 are commonly used on automobiles. Metric bolts have a property class (grade) number, rather than a slash, molded into their heads to indicate bolt strength. In this case, the higher the number, the stronger the bolt. Property class numbers 8.8, 9.8 and 10.9 are commonly used on automobiles.

Strength markings can also be used to distinguish standard hex nuts from metric hex nuts. Many standard nuts have dots stamped into one side, while metric nuts are marked with a number. The greater the number of dots, or the higher the number, the greater the strength of the nut.

Metric studs are also marked on their ends according to property class (grade). Larger studs are numbered (the same as metric bolts), while smaller studs carry a geometric code to denote grade.

It should be noted that many fasteners, especially Grades 0 through 2, have no distinguishing marks on them. When such is the case, the only way to determine whether it is standard or metric is to measure the thread pitch or compare it to a known fastener of the same size.

Standard fasteners are often referred to as SAE, as opposed to metric. However, it should be noted that SAE technically refers to a non-metric fine thread fastener only. Coarse thread non-metric fasteners are referred to as USS sizes.

Since fasteners of the same size (both standard and metric) may have different strength ratings, be sure to reinstall any bolts,

### Metric thread sizes


Metric thread sizes	Ft-lbs	Nm
M-6 .....	6 to 9	9 to 12
M-8 .....	14 to 21	19 to 28
M-10 .....	28 to 40	38 to 54
M-12 .....	50 to 71	68 to 96
M-14 .....	80 to 140	109 to 154

### Pipe thread sizes

Pipe thread sizes	Ft-lbs	Nm
1/8 .....	5 to 8	7 to 10
1/4 .....	12 to 18	17 to 24
3/8 .....	22 to 33	30 to 44
1/2 .....	25 to 35	34 to 47

### U.S. thread sizes

U.S. thread sizes	Ft-lbs	Nm
1/4 - 20 .....	6 to 9	9 to 12
5/16 - 18 .....	12 to 18	17 to 24
5/16 - 24 .....	14 to 20	19 to 27
3/8 - 16 .....	22 to 32	30 to 43
3/8 - 24 .....	27 to 38	37 to 51
7/16 - 14 .....	40 to 55	55 to 74
7/16 - 20 .....	40 to 60	55 to 81
1/2 - 13 .....	55 to 80	75 to 108



### Standard (SAE and USS) bolt dimensions/grade marks

G	Grade marks (bolt strength)
L	Length (in inches)
T	Thread pitch (number of threads per inch)
D	Nominal diameter (in inches)

### Metric bolt dimensions/grade marks

P	Property class (bolt strength)
L	Length (in millimeters)
T	Thread pitch (distance between threads in millimeters)
D	Diameter


studs or nuts removed from your vehicle in their original locations. Also, when replacing a fastener with a new one, make sure that the new one has a strength rating equal to or greater than the original.

### Tightening sequences and procedures


Most threaded fasteners should be tightened to a specific torque value (torque is the twisting force applied to a threaded component such as a nut or bolt). Overtightening the fastener can weaken it and cause it to break, while undertightening can cause it to eventually come loose. Bolts, screws and studs, depending on the material they are made of and their thread diameters, have specific

torque values, many of which are noted in the Specifications at the beginning of each Chapter. Be sure to follow the torque recommendations closely. For fasteners not assigned a specific torque, a general torque value chart is presented here as a guide. These torque values are for dry (unlubricated) fasteners threaded into steel or cast iron (not aluminum). As was previously mentioned, the size and grade of a fastener determine the amount of torque that can safely be applied to it. The figures listed here are approximate for Grade 2 and Grade 3 fasteners. Higher grades can tolerate higher torque values.

Fasteners laid out in a pattern, such as cylinder head bolts, oil pan bolts, differential cover bolts, etc., must be loosened or tightened in sequence to avoid warping the com-



Micrometer set



Dial indicator set

ponent. This sequence will normally be shown in the appropriate Chapter. If a specific pattern is not given, the following procedures can be used to prevent warping.

Initially, the bolts or nuts should be assembled finger-tight only. Next, they should be tightened one full turn each, in a criss-cross or diagonal pattern. After each one has been tightened one full turn, return to the first one and tighten them all one-half turn, following the same pattern. Finally, tighten each of them one-quarter turn at a time until each fastener has been tightened to the proper torque. To loosen and remove the fasteners, the procedure would be reversed.

### Component disassembly

Component disassembly should be done with care and purpose to help ensure that the parts go back together properly. Always keep track of the sequence in which parts are removed. Make note of special characteristics or marks on parts that can be installed more than one way, such as a grooved thrust washer on a shaft. It is a good idea to lay the disassembled parts out on a clean surface in the order that they were removed. It may also be helpful to make sketches or take instant photos of components before removal.

When removing fasteners from a component, keep track of their locations. Sometimes threading a bolt back in a part, or putting the washers and nut back on a stud, can prevent mix-ups later. If nuts and bolts cannot be returned to their original locations, they should be kept in a compartmented box or a series of small boxes. A cupcake or muffin tin is ideal for this purpose, since each cavity can hold the bolts and nuts from a particular area (i.e. oil pan bolts, valve cover bolts, engine mount bolts, etc.). A pan of this type is especially helpful when working on assemblies with very small parts, such as the carburetor, alternator, valve train or interior dash and trim pieces. The cavities can be marked with paint or tape to identify the contents.

Whenever wiring looms, harnesses or connectors are separated, it is a good idea to identify the two halves with numbered pieces of masking tape so they can be easily reconnected.

### Gasket sealing surfaces

Throughout any vehicle, gaskets are used to seal the mating surfaces between two parts and keep lubricants, fluids, vacuum or pressure contained in an assembly.

Many times these gaskets are coated with a liquid or paste-type gasket sealing compound before assembly. Age, heat and pressure can sometimes cause the two parts to stick together so tightly that they are very difficult to separate. Often, the assembly can be loosened by striking it with a soft-face hammer near the mating surfaces. A regular hammer can be used if a block of wood is placed between the hammer and the part. Do not hammer on cast parts or parts that could be easily damaged. With any particularly stubborn part, always recheck to make sure that every fastener has been removed.

Avoid using a screwdriver or bar to pry apart an assembly, as they can easily mar the gasket sealing surfaces of the parts, which must remain smooth. If prying is absolutely necessary, use an old broom handle, but keep in mind that extra clean up will be necessary if the wood splinters.

After the parts are separated, the old gasket must be carefully removed and the gasket surfaces cleaned. If you're working on cast iron or aluminum parts, stubborn gasket material can be soaked with rust penetrant or treated with a special chemical to soften it so it can be easily scraped off. **Caution:** Never use gasket removal solutions or caustic chemicals on plastic or other composite components. A scraper can be fashioned from a piece of copper tubing by flattening and sharpening one end. Copper is recommended because it is usually softer than the surfaces to be scraped, which reduces the chance of gouging the part. Some gaskets can be removed with a wire brush, but regardless of the method used, the mating surfaces must be left clean and smooth. If for some reason the gasket surface is gouged, then a gasket sealer thick enough to fill scratches will have to be used during reassembly of the components. For most applications, a non-drying (or semi-drying) gasket sealer should be used.

### Hose removal tips

**Warning:** If the vehicle is equipped with air conditioning, do not disconnect any of the A/C hoses without first having the system depressurized by a dealer service department or a service station.

Hose removal precautions closely parallel gasket removal precautions. Avoid scratching or gouging the surface that the hose mates against or the connection may leak. This is especially true for radiator hoses. Because of various chemical reactions, the rubber in hoses can bond itself to the metal spigot that the hose fits over. To remove a hose, first loosen the hose clamps that secure it to the spigot. Then, with slip-joint pliers, grab the hose at the clamp and rotate it around the spigot. Work it back and forth until it is completely free, then pull it off. Silicone or other lubricants will ease removal if they can be applied between the hose and the outside of the spigot. Apply the same lubricant to the inside of the hose and the outside of the spigot to simplify installation.

As a last resort (and if the hose is to be replaced with a new one anyway), the rubber can be slit with a knife and the hose peeled from the spigot. If this must be done, be careful that the metal connection is not damaged.

If a hose clamp is broken or damaged, do not reuse it. Wire-type clamps usually weaken with age, so it is a good idea to replace them with screw-type clamps whenever a hose is removed.


### Tools

A selection of good tools is a basic requirement for anyone who plans to maintain and repair his or her own vehicle. For the owner who has few tools, the initial investment might seem high, but when compared to the spiraling costs of professional auto maintenance and repair, it is a wise one.


To help the owner decide which tools are needed to perform the tasks detailed in this manual, the following tool lists are offered: *Maintenance and minor repair*, *Repair/overhaul* and *Special*.

The newcomer to practical mechanics should start off with the *maintenance and minor repair* tool kit, which is adequate for the








Dial caliper




Hand-operated vacuum pump



Timing light

Compression gauge with spark plug  
hole adapter


Damper/steering wheel puller




General purpose puller




Hydraulic lifter removal tool




Valve spring compressor




Valve spring compressor




Ridge reamer




Piston ring groove cleaning tool




Ring removal/installation tool




Ring compressor




Cylinder hone




Brake hold-down spring tool



Torque angle gauge



Clutch plate alignment tool



Tap and die set

simpler jobs performed on a vehicle. Then, as confidence and experience grow, the owner can tackle more difficult tasks, buying additional tools as they are needed. Eventually the basic kit will be expanded into the repair and overhaul tool set. Over a period of time, the experienced do-it-yourselfer will assemble a tool set complete enough for most repair and overhaul procedures and will add tools from the special category when it is felt that the expense is justified by the frequency of use.

### Maintenance and minor repair tool kit

The tools in this list should be considered the minimum required for performance of routine maintenance, servicing and minor repair work. We recommend the purchase of combination wrenches (box-end and open-end combined in one wrench). While more expensive than open end wrenches, they offer the advantages of both types of wrench.

- Combination wrench set (1/4-inch to 1 inch or 6 mm to 19 mm)
- Adjustable wrench, 8 inch
- Spark plug wrench with rubber insert
- Spark plug gap adjusting tool
- Feeler gauge set
- Brake bleeder wrench
- Standard screwdriver (5/16-inch x 6 inch)
- Phillips screwdriver (No. 2 x 6 inch)
- Combination pliers - 6 inch

- Hacksaw and assortment of blades
- Tire pressure gauge
- Grease gun
- Oil can
- Fine emery cloth
- Wire brush
- Battery post and cable cleaning tool
- Oil filter wrench
- Funnel (medium size)
- Safety goggles
- Jackstands (2)
- Drain pan

**Note:** If basic tune-ups are going to be part of routine maintenance, it will be necessary to purchase a good quality stroboscopic timing light and combination tachometer/dwell meter. Although they are included in the list of special tools, it is mentioned here because they are absolutely necessary for tuning most vehicles properly.

### Repair and overhaul tool set

These tools are essential for anyone who plans to perform major repairs and are in addition to those in the maintenance and minor repair tool kit. Included is a comprehensive set of sockets which, though expensive, are invaluable because of their versatility, especially when various extensions and drives are available. We recommend the 1/2-inch drive over the 3/8-inch drive. Although the larger drive is bulky and more expensive, it has the capacity of accepting a very wide

range of large sockets. Ideally, however, the mechanic should have a 3/8-inch drive set and a 1/2-inch drive set.

- Socket set(s)
- Reversible ratchet
- Extension - 10 inch
- Universal joint
- Torque wrench (same size drive as sockets)
- Ball peen hammer - 8 ounce
- Soft-face hammer (plastic/rubber)
- Standard screwdriver (1/4-inch x 6 inch)
- Standard screwdriver (stubby - 5/16-inch)
- Phillips screwdriver (No. 3 x 8 inch)
- Phillips screwdriver (stubby - No. 2)
- Pliers - vise grip
- Pliers - lineman's
- Pliers - needle nose
- Pliers - snap-ring (internal and external)
- Cold chisel - 1/2-inch
- Scribe
- Scraper (made from flattened copper tubing)
- Centerpunch
- Pin punches (1/16, 1/8, 3/16-inch)
- Steel rule/straightedge - 12 inch
- Allen wrench set (1/8 to 3/8-inch or 4 mm to 10 mm)
- A selection of files
- Wire brush (large)
- Jackstands (second set)
- Jack (scissor or hydraulic type)



**Note:** Another tool which is often useful is an electric drill with a chuck capacity of 3/8-inch and a set of good quality drill bits.

### Special tools

The tools in this list include those which are not used regularly, are expensive to buy, or which need to be used in accordance with their manufacturer's instructions. Unless these tools will be used frequently, it is not very economical to purchase many of them. A consideration would be to split the cost and use between yourself and a friend or friends. In addition, most of these tools can be obtained from a tool rental shop on a temporary basis.

This list primarily contains only those tools and instruments widely available to the public, and not those special tools produced by the vehicle manufacturer for distribution to dealer service departments. Occasionally, references to the manufacturer's special tools are included in the text of this manual. Generally, an alternative method of doing the job without the special tool is offered. However, sometimes there is no alternative to their use. Where this is the case, and the tool cannot be purchased or borrowed, the work should be turned over to the dealer service department or an automotive repair shop.

Valve spring compressor  
Piston ring groove cleaning tool  
Piston ring compressor  
Piston ring installation tool  
Cylinder compression gauge  
Cylinder ridge reamer  
Cylinder surfacing hone  
Cylinder bore gauge  
Micrometers and/or dial calipers  
Hydraulic lifter removal tool  
Balljoint separator  
Universal-type puller  
Impact screwdriver  
Dial indicator set  
Stroboscopic timing light (inductive pick-up)  
Hand operated vacuum/pressure pump  
Tachometer/dwell meter  
Universal electrical multimeter  
Cable hoist  
Brake spring removal and installation tools  
Floor jack

### Buying tools

For the do-it-yourselfer who is just starting to get involved in vehicle maintenance and repair, there are a number of options available when purchasing tools. If maintenance and minor repair is the extent of the work to be done, the purchase of individual tools is satisfactory. If, on the other hand, extensive work is planned, it would be a good idea to purchase a modest tool set from one of the large retail chain stores. A set can usually be bought at a substantial savings over the individual tool prices, and they often come with a tool

box. As additional tools are needed, add-on sets, individual tools and a larger tool box can be purchased to expand the tool selection. Building a tool set gradually allows the cost of the tools to be spread over a longer period of time and gives the mechanic the freedom to choose only those tools that will actually be used.

Tool stores will often be the only source of some of the special tools that are needed, but regardless of where tools are bought, try to avoid cheap ones, especially when buying screwdrivers and sockets, because they won't last very long. The expense involved in replacing cheap tools will eventually be greater than the initial cost of quality tools.

### Care and maintenance of tools

Good tools are expensive, so it makes sense to treat them with respect. Keep them clean and in usable condition and store them properly when not in use. Always wipe off any dirt, grease or metal chips before putting them away. Never leave tools lying around in the work area. Upon completion of a job, always check closely under the hood for tools that may have been left there so they won't get lost during a test drive.

Some tools, such as screwdrivers, pliers, wrenches and sockets, can be hung on a panel mounted on the garage or workshop wall, while others should be kept in a tool box or tray. Measuring instruments, gauges, meters, etc. must be carefully stored where they cannot be damaged by weather or impact from other tools.

When tools are used with care and stored properly, they will last a very long time. Even with the best of care, though, tools will wear out if used frequently. When a tool is damaged or worn out, replace it. Subsequent jobs will be safer and more enjoyable if you do.

### How to repair damaged threads

Sometimes, the internal threads of a nut or bolt hole can become stripped, usually from overtightening. Stripping threads is an all-too-common occurrence, especially when working with aluminum parts, because aluminum is so soft that it easily strips out.

Usually, external or internal threads are only partially stripped. After they've been cleaned up with a tap or die, they'll still work. Sometimes, however, threads are badly damaged. When this happens, you've got three choices:

- 1) Drill and tap the hole to the next suitable oversize and install a larger diameter bolt, screw or stud.
- 2) Drill and tap the hole to accept a threaded plug, then drill and tap the plug to the original screw size. You can also buy a plug already threaded to the original size. Then you simply drill a hole to the specified size, then run the threaded

plug into the hole with a bolt and jam nut. Once the plug is fully seated, remove the jam nut and bolt.

- 3) The third method uses a patented thread repair kit like Heli-Coil or Slimsert. These easy-to-use kits are designed to repair damaged threads in straight-through holes and blind holes. Both are available as kits which can handle a variety of sizes and thread patterns. Drill the hole, then tap it with the special included tap. Install the Heli-Coil and the hole is back to its original diameter and thread pitch.

Regardless of which method you use, be sure to proceed calmly and carefully. A little impatience or carelessness during one of these relatively simple procedures can ruin your whole day's work and cost you a bundle if you wreck an expensive part.

### Working facilities

Not to be overlooked when discussing tools is the workshop. If anything more than routine maintenance is to be carried out, some sort of suitable work area is essential.

It is understood, and appreciated, that many home mechanics do not have a good workshop or garage available, and end up removing an engine or doing major repairs outside. It is recommended, however, that the overhaul or repair be completed under the cover of a roof.

A clean, flat workbench or table of comfortable working height is an absolute necessity. The workbench should be equipped with a vise that has a jaw opening of at least four inches.

As mentioned previously, some clean, dry storage space is also required for tools, as well as the lubricants, fluids, cleaning solvents, etc. which soon become necessary.

Sometimes waste oil and fluids, drained from the engine or cooling system during normal maintenance or repairs, present a disposal problem. To avoid pouring them on the ground or into a sewage system, pour the used fluids into large containers, seal them with caps and take them to an authorized disposal site or recycling center. Plastic jugs, such as old antifreeze containers, are ideal for this purpose.

Always keep a supply of old newspapers and clean rags available. Old towels are excellent for mopping up spills. Many mechanics use rolls of paper towels for most work because they are readily available and disposable. To help keep the area under the vehicle clean, a large cardboard box can be cut open and flattened to protect the garage or shop floor.

Whenever working over a painted surface, such as when leaning over a fender to service something under the hood, always cover it with an old blanket or bedspread to protect the finish. Vinyl covered pads, made especially for this purpose, are available at auto parts stores.

# Jacking and towing

## Jacking

**Warning:** The jack supplied with the vehicle should only be used for changing a tire or placing jackstands under the frame. Never work under the vehicle or start the engine while this jack is being used as the only means of support.

The vehicle should be on level ground. Place the shift lever in Park, if you have an automatic, or Reverse if you have a manual transaxle. Block the wheel diagonally opposite the wheel being changed. Set the parking brake.

Remove the spare tire and jack from stowage. Remove the wheel cover and trim ring (if so equipped) with the tapered end of the lug nut wrench by inserting and twisting the handle and then prying against the back of the wheel cover. Loosen, but do not remove, the lug nuts (one-half turn is sufficient).

Place the scissors-type jack under the vehicle and adjust the jack height until it engages with the proper jacking point. There is a front and rear jacking point on each side of the vehicle (see illustrations).

Turn the jack handle clockwise until the tire clears the ground. Remove the lug nuts and pull the wheel off. Replace it with the spare.

Install the lug nuts with the beveled edges facing in. Tighten them snugly. Don't attempt to tighten them completely until the vehicle is lowered or it could slip off the jack. Turn the jack handle counterclockwise to lower the vehicle. Remove the jack and tighten the lug nuts in a diagonal pattern.


Install the cover (and trim ring, if used) and be sure it's snapped into place all the way around.

Stow the tire, jack and wrench. Unblock the wheels.


## Towing

Two-wheel drive models can be towed from the front with the front wheels off the ground, using a wheel lift type tow truck. If towed from the rear, the front wheels must be placed on a dolly. Four-wheel drive models must be towed with all four wheels off the ground. A sling-type tow truck cannot be used, as body damage will result. The best way to tow the vehicle is with a flat-bed car carrier.

In an emergency the vehicle can be towed a short distance with a cable or chain attached to one of the towing eyelets located under the front or rear bumpers. The driver must remain in the vehicle to operate the steering and brakes (remember that power steering and power brakes will not work with the engine off).



Front jacking location (place the jack head under the control arm rear mounting bolt)



Rear jacking location (place the jack head under the protrusion on the trailing arm)



## Booster battery (jump) starting

Observe these precautions when using a booster battery to start a vehicle:


- Before connecting the booster battery, make sure the ignition switch is in the Off position.
- Turn off the lights, heater and other electrical loads.
- Your eyes should be shielded. Safety goggles are a good idea.
- Make sure the booster battery is the same voltage as the dead one in the vehicle.
- The two vehicles **MUST NOT TOUCH** each other!
- Make sure the transaxle is in Neutral (manual) or Park (automatic).
- If the booster battery is not a maintenance-free type, remove the vent caps and lay a cloth over the vent holes.

Connect the red jumper cable to the positive (+) terminals of each battery (see illustration).

Connect one end of the black jumper cable to the negative (-) terminal of the booster battery. The other end of this cable should be connected to a good ground on the vehicle to be started, such as a bolt or bracket on the body.

Start the engine using the booster battery, then, with the engine running at idle speed, disconnect the jumper cables in the reverse order of connection.

**Note:** On vehicles equipped with an automatic transaxle, if the battery has been run down or disconnected, the Powertrain Control Module (PCM) must relearn its idle and fuel mixture trim strategy for optimum drivability and performance (see Chapter 5, Section 1 for this procedure).



**Make the booster battery cable connections in the numerical order shown (note that the negative cable of the booster battery NOT attached to the negative terminal of the dead battery)**

00-3 HAYNES

## DECIMALS to MILLIMETERS

Decimal	mm	Decimal	mm
0.001	0.0254	0.500	12.7000
0.002	0.0508	0.510	12.9540
0.003	0.0762	0.520	13.2080
0.004	0.1016	0.530	13.4620
0.005	0.1270	0.540	13.7160
0.006	0.1524	0.550	13.9700
0.007	0.1778	0.560	14.2240
0.008	0.2032	0.570	14.4780
0.009	0.2286	0.580	14.7320
0.010	0.2540	0.590	14.9860
0.020	0.5080		
0.030	0.7620		
0.040	1.0160	0.600	15.2400
0.050	1.2700	0.610	15.4940
0.060	1.5240	0.620	15.7480
0.070	1.7780	0.630	16.0020
0.080	2.0320	0.640	16.2560
0.090	2.2860	0.650	16.5100
		0.660	16.7640
0.100	2.5400	0.670	17.0180
0.110	2.7940	0.680	17.2720
0.120	3.0480	0.690	17.5260
0.130	3.3020		
0.140	3.5560		
0.150	3.8100		
0.160	4.0640	0.700	17.7800
0.170	4.3180	0.710	18.0340
0.180	4.5720	0.720	18.2880
0.190	4.8260	0.730	18.5420
		0.740	18.7960
0.200	5.0800	0.750	19.0500
0.210	5.3340	0.760	19.3040
0.220	5.5880	0.770	19.5580
0.230	5.8420	0.780	19.8120
0.240	6.0960	0.790	20.0660
0.250	6.3500		
0.260	6.6040		
0.270	6.8580	0.800	20.3200
0.280	7.1120	0.810	20.5740
0.290	7.3660	0.820	21.8280
		0.830	21.0820
0.300	7.6200	0.840	21.3360
0.310	7.8740	0.850	21.5900
0.320	8.1280	0.860	21.8440
0.330	8.3820	0.870	22.0980
0.340	8.6360	0.880	22.3520
0.350	8.8900	0.890	22.6060
0.360	9.1440		
0.370	9.3980		
0.380	9.6520		
0.390	9.9060		
		0.900	22.8600
0.400	10.1600	0.910	23.1140
0.410	10.4140	0.920	23.3680
0.420	10.6680	0.930	23.6220
0.430	10.9220	0.940	23.8760
0.440	11.1760	0.950	24.1300
0.450	11.4300	0.960	24.3840
0.460	11.6840	0.970	24.6380
0.470	11.9380	0.980	24.8920
0.480	12.1920	0.990	25.1460
0.490	12.4460	1.000	25.4000

## FRACTIONS to DECIMALS to MILLIMETERS

Fraction	Decimal	mm	Fraction	Decimal	mm
1/64	0.0156	0.3969	33/64	0.5156	13.0969
1/32	0.0312	0.7938	17/32	0.5312	13.4938
3/64	0.0469	1.1906	35/64	0.5469	13.8906
1/16	0.0625	1.5875	9/16	0.5625	14.2875
5/64	0.0781	1.9844	37/64	0.5781	14.6844
3/32	0.0938	2.3812	19/32	0.5938	15.0812
7/64	0.1094	2.7781	39/64	0.6094	15.4781
1/8	0.1250	3.1750	5/8	0.6250	15.8750
9/64	0.1406	3.5719	41/64	0.6406	16.2719
5/32	0.1562	3.9688	21/32	0.6562	16.6688
11/64	0.1719	4.3656	43/64	0.6719	17.0656
3/16	0.1875	4.7625	11/16	0.6875	17.4625
13/64	0.2031	5.1594	45/64	0.7031	17.8594
7/32	0.2188	5.5562	23/32	0.7188	18.2562
15/64	0.2344	5.9531	47/64	0.7344	18.6531
1/4	0.2500	6.3500	3/4	0.7500	19.0500
17/64	0.2656	6.7469	49/64	0.7656	19.4469
9/32	0.2812	7.1438	25/32	0.7812	19.8438
19/64	0.2969	7.5406	51/64	0.7969	20.2406
5/16	0.3125	7.9375	13/16	0.8125	20.6375
21/64	0.3281	8.3344	53/64	0.8281	21.0344
11/32	0.3438	8.7312	27/32	0.8438	21.4312
23/64	0.3594	9.1281	55/64	0.8594	21.8281
3/8	0.3750	9.5250	7/8	0.8750	22.2250
25/64	0.3906	9.9219	57/64	0.8906	22.6219
13/32	0.4062	10.3188	29/32	0.9062	23.0188
27/64	0.4219	10.7156	59/64	0.9219	23.4156
7/16	0.4375	11.1125	15/16	0.9375	23.8125
29/64	0.4531	11.5094	61/64	0.9531	24.2094
15/32	0.4688	11.9062	31/32	0.9688	24.6062
31/64	0.4844	12.3031	63/64	0.9844	25.0031
1/2	0.5000	12.7000	1	1.0000	25.4000



# Conversion factors

## Length (distance)

Inches (in)	X 25.4 = Millimeters (mm)	X 0.0394 = Inches (in)
Feet (ft)	X 0.305 = Meters (m)	X 3.281 = Feet (ft)
Miles	X 1.609 = Kilometers (km)	X 0.621 = Miles

## Volume (capacity)

Cubic inches (cu in; in <sup>3</sup> )	X 16.387 = Cubic centimeters (cc; cm <sup>3</sup> )	X 0.061 = Cubic inches (cu in; in <sup>3</sup> )
Imperial pints (Imp pt)	X 0.568 = Liters (l)	X 1.76 = Imperial pints (Imp pt)
Imperial quarts (Imp qt)	X 1.137 = Liters (l)	X 0.88 = Imperial quarts (Imp qt)
Imperial quarts (Imp qt)	X 1.201 = US quarts (US qt)	X 0.833 = Imperial quarts (Imp qt)
US quarts (US qt)	X 0.946 = Liters (l)	X 1.057 = US quarts (US qt)
Imperial gallons (Imp gal)	X 4.546 = Liters (l)	X 0.22 = Imperial gallons (Imp gal)
Imperial gallons (Imp gal)	X 1.201 = US gallons (US gal)	X 0.833 = Imperial gallons (Imp gal)
US gallons (US gal)	X 3.785 = Liters (l)	X 0.264 = US gallons (US gal)

## Mass (weight)

Ounces (oz)	X 28.35 = Grams (g)	X 0.035 = Ounces (oz)
Pounds (lb)	X 0.454 = Kilograms (kg)	X 2.205 = Pounds (lb)

## Force

Ounces-force (ozf; oz)	X 0.278 = Newtons (N)	X 3.6 = Ounces-force (ozf; oz)
Pounds-force (lbf; lb)	X 4.448 = Newtons (N)	X 0.225 = Pounds-force (lbf; lb)
Newtons (N)	X 0.1 = Kilograms-force (kgf; kg)	X 9.81 = Newtons (N)

## Pressure

Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	X 0.070 = Kilograms-force per square centimeter (kgf/cm <sup>2</sup> ; kg/cm <sup>2</sup> )	X 14.223 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	X 0.068 = Atmospheres (atm)	X 14.696 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	X 0.069 = Bars	X 14.5 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )	X 6.895 = Kilopascals (kPa)	X 0.145 = Pounds-force per square inch (psi; lbf/in <sup>2</sup> ; lb/in <sup>2</sup> )
Kilopascals (kPa)	X 0.01 = Kilograms-force per square centimeter (kgf/cm <sup>2</sup> ; kg/cm <sup>2</sup> )	X 98.1 = Kilopascals (kPa)

## Torque (moment of force)

Pounds-force inches (lbf in; lb in)	X 1.152 = Kilograms-force centimeter (kgf cm; kg cm)	X 0.868 = Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	X 0.113 = Newton meters (Nm)	X 8.85 = Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	X 0.083 = Pounds-force feet (lbf ft; lb ft)	X 12 = Pounds-force inches (lbf in; lb in)
Pounds-force feet (lbf ft; lb ft)	X 0.138 = Kilograms-force meters (kgf m; kg m)	X 7.233 = Pounds-force feet (lbf ft; lb ft)
Pounds-force feet (lbf ft; lb ft)	X 1.356 = Newton meters (Nm)	X 0.738 = Pounds-force feet (lbf ft; lb ft)
Newton meters (Nm)	X 0.102 = Kilograms-force meters (kgf m; kg m)	X 9.804 = Newton meters (Nm)

## Vacuum

Inches mercury (in. Hg)	X 3.377 = Kilopascals (kPa)	X 0.2961 = Inches mercury
Inches mercury (in. Hg)	X 25.4 = Millimeters mercury (mm Hg)	X 0.0394 = Inches mercury

## Power

Horsepower (hp)	X 745.7 = Watts (W)	X 0.0013 = Horsepower (hp)
-----------------	---------------------	----------------------------

## Velocity (speed)

Miles per hour (miles/hr; mph)	X 1.609 = Kilometers per hour (km/hr; kph)	X 0.621 = Miles per hour (miles/hr; mph)
--------------------------------	--	--

## Fuel consumption\*

Miles per gallon, Imperial (mpg)	X 0.354 = Kilometers per liter (km/l)	X 2.825 = Miles per gallon, Imperial (mpg)
Miles per gallon, US (mpg)	X 0.425 = Kilometers per liter (km/l)	X 2.352 = Miles per gallon, US (mpg)

## Temperature

Degrees Fahrenheit = (°C x 1.8) + 32

Degrees Celsius (Degrees Centigrade; °C) = (°F - 32) x 0.56

\*It is common practice to convert from miles per gallon (mpg) to liters/100 kilometers (l/100km), where mpg (Imperial) x l/100 km = 282 and mpg (US) x l/100 km = 235

# Safety first!

Regardless of how enthusiastic you may be about getting on with the job at hand, take the time to ensure that your safety is not jeopardized. A moment's lack of attention can result in an accident, as can failure to observe certain simple safety precautions. The possibility of an accident will always exist, and the following points should not be considered a comprehensive list of all dangers. Rather, they are intended to make you aware of the risks and to encourage a safety conscious approach to all work you carry out on your vehicle.

## Essential DOs and DON'Ts

**DON'T** rely on a jack when working under the vehicle. Always use approved jackstands to support the weight of the vehicle and place them under the recommended lift or support points.

**DON'T** attempt to loosen extremely tight fasteners (i.e. wheel lug nuts) while the vehicle is on a jack - it may fall.

**DON'T** start the engine without first making sure that the transmission is in Neutral (or Park where applicable) and the parking brake is set.

**DON'T** remove the radiator cap from a hot cooling system - let it cool or cover it with a cloth and release the pressure gradually.

**DON'T** attempt to drain the engine oil until you are sure it has cooled to the point that it will not burn you.

**DON'T** touch any part of the engine or exhaust system until it has cooled sufficiently to avoid burns.

**DON'T** siphon toxic liquids such as gasoline, antifreeze and brake fluid by mouth, or allow them to remain on your skin.

**DON'T** inhale brake lining dust - it is potentially hazardous (see *Asbestos* below).

**DON'T** allow spilled oil or grease to remain on the floor - wipe it up before someone slips on it.

**DON'T** use loose fitting wrenches or other tools which may slip and cause injury.

**DON'T** push on wrenches when loosening or tightening nuts or bolts. Always try to pull the wrench toward you. If the situation calls for pushing the wrench away, push with an open hand to avoid scraped knuckles if the wrench should slip.

**DON'T** attempt to lift a heavy component alone - get someone to help you.

**DON'T** rush or take unsafe shortcuts to finish a job.

**DON'T** allow children or animals in or around the vehicle while you are working on it.

**DO** wear eye protection when using power

tools such as a drill, sander, bench grinder, etc. and when working under a vehicle.

**DO** keep loose clothing and long hair well out of the way of moving parts.

**DO** make sure that any hoist used has a safe working load rating adequate for the job.

**DO** get someone to check on you periodically when working alone on a vehicle.

**DO** carry out work in a logical sequence and make sure that everything is correctly assembled and tightened.

**DO** keep chemicals and fluids tightly capped and out of the reach of children and pets.

**DO** remember that your vehicle's safety affects that of yourself and others. If in doubt on any point, get professional advice.

## Asbestos

Certain friction, insulating, sealing, and other products - such as brake linings, brake bands, clutch linings, torque converters, gaskets, etc. - may contain asbestos. Extreme care must be taken to avoid inhalation of dust from such products, since it is hazardous to health. If in doubt, assume that they do contain asbestos.

## Fire

Remember at all times that gasoline is highly flammable. Never smoke or have any kind of open flame around when working on a vehicle. But the risk does not end there. A spark caused by an electrical short circuit, by two metal surfaces contacting each other, or even by static electricity built up in your body under certain conditions, can ignite gasoline vapors, which in a confined space are highly explosive. Do not, under any circumstances, use gasoline for cleaning parts. Use an approved safety solvent.

Always disconnect the battery ground (-) cable at the battery before working on any part of the fuel system or electrical system. Never risk spilling fuel on a hot engine or exhaust component. It is strongly recommended that a fire extinguisher suitable for use on fuel and electrical fires be kept handy in the garage or workshop at all times. Never try to extinguish a fuel or electrical fire with water.

## Fumes

Certain fumes are highly toxic and can quickly cause unconsciousness and even death if inhaled to any extent. Gasoline vapor falls into this category, as do the vapors from some cleaning solvents. Any draining or pouring of such volatile fluids should be done in a well ventilated area.

When using cleaning fluids and solvents,

read the instructions on the container carefully. Never use materials from unmarked containers.

Never run the engine in an enclosed space, such as a garage. Exhaust fumes contain carbon monoxide, which is extremely poisonous. If you need to run the engine, always do so in the open air, or at least have the rear of the vehicle outside the work area.

If you are fortunate enough to have the use of an inspection pit, never drain or pour gasoline and never run the engine while the vehicle is over the pit. The fumes, being heavier than air, will concentrate in the pit with possibly lethal results.

## The battery

Never create a spark or allow a bare light bulb near a battery. They normally give off a certain amount of hydrogen gas, which is highly explosive.

Always disconnect the battery ground (-) cable at the battery before working on the fuel or electrical systems.

If possible, loosen the filler caps or cover when charging the battery from an external source (this does not apply to sealed or maintenance-free batteries). Do not charge at an excessive rate or the battery may burst.

Take care when adding water to a non maintenance-free battery and when carrying a battery. The electrolyte, even when diluted, is very corrosive and should not be allowed to contact clothing or skin.

Always wear eye protection when cleaning the battery to prevent the caustic deposits from entering your eyes.

## Household current

When using an electric power tool, inspection light, etc., which operates on household current, always make sure that the tool is correctly connected to its plug and that, where necessary, it is properly grounded. Do not use such items in damp conditions and, again, do not create a spark or apply excessive heat in the vicinity of fuel or fuel vapor.

## Secondary ignition system voltage

A severe electric shock can result from touching certain parts of the ignition system (such as the spark plug wires) when the engine is running or being cranked, particularly if components are damp or the insulation is defective. In the case of an electronic ignition system, the secondary system voltage is much higher and could prove fatal.



# Automotive chemicals and lubricants

A number of automotive chemicals and lubricants are available for use during vehicle maintenance and repair. They include a wide variety of products ranging from cleaning solvents and degreasers to lubricants and protective sprays for rubber, plastic and vinyl.

## Cleaners

**Carburetor cleaner and choke cleaner** is a strong solvent for gum, varnish and carbon. Most carburetor cleaners leave a dry-type lubricant film which will not harden or gum up. Because of this film it is not recommended for use on electrical components.

**Brake system cleaner** is used to remove brake dust, grease and brake fluid from the brake system, where clean surfaces are absolutely necessary. It leaves no residue and often eliminates brake squeal caused by contaminants.

**Electrical cleaner** removes oxidation, corrosion and carbon deposits from electrical contacts, restoring full current flow. It can also be used to clean spark plugs, carburetor jets, voltage regulators and other parts where an oil-free surface is desired.

**Demoisturants** remove water and moisture from electrical components such as alternators, voltage regulators, electrical connectors and fuse blocks. They are non-conductive and non-corrosive.

**Degreasers** are heavy-duty solvents used to remove grease from the outside of the engine and from chassis components. They can be sprayed or brushed on and, depending on the type, are rinsed off either with water or solvent.

## Lubricants

**Motor oil** is the lubricant formulated for use in engines. It normally contains a wide variety of additives to prevent corrosion and reduce foaming and wear. Motor oil comes in various weights (viscosity ratings) from 0 to 50. The recommended weight of the oil depends on the season, temperature and the demands on the engine. Light oil is used in cold climates and under light load conditions. Heavy oil is used in hot climates and where high loads are encountered. Multi-viscosity oils are designed to have characteristics of both light and heavy oils and are available in a number of weights from 5W-20 to 20W-50.

**Gear oil** is designed to be used in differentials, manual transmissions and other areas where high-temperature lubrication is required.

**Chassis and wheel bearing grease** is a heavy grease used where increased loads and friction are encountered, such as for wheel bearings, balljoints, tie-rod ends and universal joints.

**High-temperature wheel bearing grease** is designed to withstand the extreme

temperatures encountered by wheel bearings in disc brake equipped vehicles. It usually contains molybdenum disulfide (moly), which is a dry-type lubricant.

**White grease** is a heavy grease for metal-to-metal applications where water is a problem. White grease stays soft under both low and high temperatures (usually from -100 to +190-degrees F), and will not wash off or dilute in the presence of water.

**Assembly lube** is a special extreme pressure lubricant, usually containing moly, used to lubricate high-load parts (such as main and rod bearings and cam lobes) for initial start-up of a new engine. The assembly lube lubricates the parts without being squeezed out or washed away until the engine oiling system begins to function.

**Silicone lubricants** are used to protect rubber, plastic, vinyl and nylon parts.

**Graphite lubricants** are used where oils cannot be used due to contamination problems, such as in locks. The dry graphite will lubricate metal parts while remaining uncontaminated by dirt, water, oil or acids. It is electrically conductive and will not foul electrical contacts in locks such as the ignition switch.

**Moly penetrants** loosen and lubricate frozen, rusted and corroded fasteners and prevent future rusting or freezing.

**Heat-sink grease** is a special electrically non-conductive grease that is used for mounting electronic ignition modules where it is essential that heat is transferred away from the module.

## Sealants

**RTV sealant** is one of the most widely used gasket compounds. Made from silicone, RTV is air curing, it seals, bonds, waterproofs, fills surface irregularities, remains flexible, doesn't shrink, is relatively easy to remove, and is used as a supplementary sealer with almost all low and medium temperature gaskets.

**Anaerobic sealant** is much like RTV in that it can be used either to seal gaskets or to form gaskets by itself. It remains flexible, is solvent resistant and fills surface imperfections. The difference between an anaerobic sealant and an RTV-type sealant is in the curing. RTV cures when exposed to air, while an anaerobic sealant cures only in the absence of air. This means that an anaerobic sealant cures only after the assembly of parts, sealing them together.

**Thread and pipe sealant** is used for sealing hydraulic and pneumatic fittings and vacuum lines. It is usually made from a Teflon compound, and comes in a spray, a paint-on liquid and as a wrap-around tape.

## Chemicals

**Anti-seize compound** prevents seizing,

galling, cold welding, rust and corrosion in fasteners. High-temperature anti-seize, usually made with copper and graphite lubricants, is used for exhaust system and exhaust manifold bolts.

**Anaerobic locking compounds** are used to keep fasteners from vibrating or working loose and cure only after installation, in the absence of air. Medium strength locking compound is used for small nuts, bolts and screws that may be removed later. High-strength locking compound is for large nuts, bolts and studs which aren't removed on a regular basis.

**Oil additives** range from viscosity index improvers to chemical treatments that claim to reduce internal engine friction. It should be noted that most oil manufacturers caution against using additives with their oils.

**Gas additives** perform several functions, depending on their chemical makeup. They usually contain solvents that help dissolve gum and varnish that build up on carburetor, fuel injection and intake parts. They also serve to break down carbon deposits that form on the inside surfaces of the combustion chambers. Some additives contain upper cylinder lubricants for valves and piston rings, and others contain chemicals to remove condensation from the gas tank.

## Miscellaneous

**Brake fluid** is specially formulated hydraulic fluid that can withstand the heat and pressure encountered in brake systems. Care must be taken so this fluid does not come in contact with painted surfaces or plastics. An opened container should always be resealed to prevent contamination by water or dirt.

**Weatherstrip adhesive** is used to bond weatherstripping around doors, windows and trunk lids. It is sometimes used to attach trim pieces.

**Undercoating** is a petroleum-based, tar-like substance that is designed to protect metal surfaces on the underside of the vehicle from corrosion. It also acts as a sound-deadening agent by insulating the bottom of the vehicle.

**Waxes and polishes** are used to help protect painted and plated surfaces from the weather. Different types of paint may require the use of different types of wax and polish. Some polishes utilize a chemical or abrasive cleaner to help remove the top layer of oxidized (dull) paint on older vehicles. In recent years many non-wax polishes that contain a wide variety of chemicals such as polymers and silicones have been introduced. These non-wax polishes are usually easier to apply and last longer than conventional waxes and polishes.

# Troubleshooting

## Contents

Symptom	Section	Symptom	Section
<b>Engine</b>		Noise most pronounced when turning.....	42
Engine will not rotate when attempting to start.....	1	Clunk on acceleration or deceleration.....	43
Engine rotates but will not start.....	2	Clicking noise in turns.....	44
Engine hard to start when cold.....	3	Vibration.....	45
Engine hard to start when hot.....	4	Noisy in neutral with engine running.....	46
Starter motor noisy or excessively rough in engagement.....	5	Noisy in one particular gear.....	47
Engine starts but stops immediately.....	6	Noisy in all gears.....	48
Oil puddle under engine.....	7	Slips out of gear.....	49
Engine lopes while idling or idles erratically.....	8	Leaks lubricant.....	50
Engine misses at idle speed.....	9	Locked in gear.....	51
Engine misses throughout driving speed range.....	10	<b>Automatic transaxle</b>	
Engine stumbles on acceleration.....	11	Fluid leakage.....	52
Engine surges while holding accelerator steady.....	12	Transaxle fluid brown or has burned smell.....	53
Engine stalls.....	13	General shift mechanism problems.....	54
Engine lacks power.....	14	Transaxle slips, shifts roughly, is noisy or has no drive in forward or reverse gears.....	55
Engine backfires.....	15	<b>Driveaxles</b>	
Pinging or knocking engine sounds during acceleration or uphill.....	16	Clicking noise in turns.....	56
Engine runs with oil pressure light on.....	17	Shudder or vibration during acceleration.....	57
Engine diesels (continues to run) after switching off.....	18	Vibration at highway speeds.....	58
<b>Engine electrical systems</b>		<b>Brakes</b>	
Battery will not hold a charge.....	19	Vehicle pulls to one side during braking.....	59
Alternator light fails to go out.....	20	Noise (high-pitched squeal when the brakes are applied).....	60
Alternator light fails to come on when key is turned on.....	21	Brake roughness or chatter (pedal pulsates).....	61
<b>Fuel system</b>		Excessive pedal effort required to stop vehicle.....	62
Excessive fuel consumption.....	22	Excessive brake pedal travel.....	63
Fuel leakage and/or fuel odor.....	23	Dragging brakes.....	64
<b>Cooling system</b>		Grabbing or uneven braking action.....	65
Overheating.....	24	Brake pedal feels spongy when depressed.....	66
Overcooling.....	25	Brake pedal travels to the floor with little resistance.....	67
External coolant leakage.....	26	Parking brake does not hold.....	68
Internal coolant leakage.....	27	<b>Suspension and steering systems</b>	
Coolant loss.....	28	Vehicle pulls to one side.....	69
Poor coolant circulation.....	29	Abnormal or excessive tire wear.....	70
<b>Clutch</b>		Wheel makes a thumping noise.....	71
Pedal travels to floor - no pressure or very little resistance.....	30	Shimmy, shake or vibration.....	72
Fluid in area of master cylinder dust cover and on pedal.....	31	Hard steering.....	73
Fluid on release cylinder.....	32	Poor returnability of steering to center.....	74
Pedal feels spongy when depressed.....	33	Abnormal noise at the front end.....	75
Unable to select gears.....	34	Wander or poor steering stability.....	76
Clutch slips (engine speed increases with no increase in vehicle speed).....	35	Erratic steering when braking.....	77
Grabbing (chattering) as clutch is engaged.....	36	Excessive pitching and/or rolling around corners or during braking.....	78
Transaxle rattling (clicking).....	37	Suspension bottoms.....	79
Noise in clutch area.....	38	Cupped tires.....	80
Clutch pedal stays on floor.....	39	Excessive tire wear on outside edge.....	81
High pedal effort.....	40	Excessive tire wear on inside edge.....	82
<b>Manual transaxle</b>		Tire tread worn in one place.....	83
Knocking noise at low speeds.....	41	Excessive play or looseness in steering system.....	84
		Rattling or clicking noise in rack and pinion.....	85



This section provides an easy reference guide to the more common problems which may occur during the operation of your vehicle. These problems and their possible causes are grouped under headings denoting various components or systems, such as Engine, Cooling system, etc. They also refer you to the chapter and/or section which deals with the problem.

Remember that successful troubleshooting is not a mysterious black art practiced only by professional mechanics. It is simply the result of the right knowledge combined with an intelligent, systematic approach to the problem. Always work by a process of elimination, starting with the simplest solution and working through to the most complex - and never overlook the obvious. Anyone can run the gas tank dry or leave the lights on overnight, so don't assume that you are exempt from such oversights.

Finally, always establish a clear idea of why a problem has occurred and take steps to ensure that it doesn't happen again. If the electrical system fails because of a poor connection, check the other connections in the system to make sure that they don't fail as well. If a particular fuse continues to blow, find out why - don't just replace one fuse after another. Remember, failure of a small component can often be indicative of potential failure or incorrect functioning of a more important component or system.

## Engine

### 1 Engine will not rotate when attempting to start

- 1 Battery terminal connections loose or corroded (Chapter 1).
- 2 Battery discharged or faulty (Chapters 1 and 5).
- 3 Automatic transaxle not completely engaged in Park (Chapter 7) or clutch pedal not completely depressed (Chapter 6).
- 4 Broken, loose or disconnected wiring in the starting circuit (Chapters 5 and 12).
- 5 Starter motor pinion jammed in flywheel ring gear (Chapter 5).
- 6 Starter solenoid faulty (Chapter 5).
- 7 Starter motor faulty (Chapter 5).
- 8 Ignition switch faulty (Chapter 12).
- 9 Starter pinion or flywheel teeth worn or broken (Chapter 5).

### 2 Engine rotates but will not start

- 1 Fuel tank empty.
- 2 Battery discharged (engine rotates slowly) (Chapter 5).
- 3 Battery terminal connections loose or corroded (Chapter 1).

- 4 Leaking fuel injector(s), faulty fuel pump, pressure regulator, etc. (Chapter 4).
- 5 Broken or stripped timing belt (Chapter 2A) or broken timing chain (Chapter 2B).
- 6 Ignition components damp or damaged (Chapter 5).
- 7 Worn, faulty or incorrectly gapped spark plugs (Chapter 1).
- 8 Broken, loose or disconnected wiring in the starting circuit (Chapter 5).
- 9 Broken, loose or disconnected wires at the ignition coil or faulty coil (Chapter 5).
- 10 Defective crankshaft or camshaft sensor (Chapter 6).

### 3 Engine hard to start when cold

- 1 Battery discharged or low (Chapter 1).
- 2 Malfunctioning fuel system (Chapter 4).
- 3 Faulty coolant temperature sensor or intake air temperature sensor (Chapter 6).
- 4 Faulty ignition system (Chapter 5).

### 4 Engine hard to start when hot

- 1 Air filter clogged (Chapter 1).
- 2 Fuel not reaching the fuel injection system (Chapter 4).
- 3 Corroded battery connections, especially ground (Chapter 1).
- 4 Faulty coolant temperature sensor or intake air temperature sensor (Chapter 6).

### 5 Starter motor noisy or excessively rough in engagement

- 1 Pinion or flywheel gear teeth worn or broken (Chapter 5).
- 2 Starter motor mounting bolts loose or missing (Chapter 5).

### 6 Engine starts but stops immediately

- 1 Loose or faulty electrical connections at ignition coil or alternator (Chapter 5).
- 2 Insufficient fuel reaching the fuel injector(s) (Chapters 1 and 4).
- 3 Vacuum leak at the gasket between the intake manifold/plenum and throttle body (Chapter 4).

### 7 Oil puddle under engine

- 1 Oil pan gasket and/or oil pan drain bolt washer leaking (Chapter 2).
- 2 Oil pressure sending unit leaking (Chapter 2).
- 3 Valve cover leaking (Chapter 2).
- 4 Engine oil seals leaking (Chapter 2).
- 5 Oil pump housing leaking (Chapter 2).

### 8 Engine lopes while idling or idles erratically

- 1 Vacuum leakage (Chapters 2 and 4).
- 2 Leaking EGR valve (Chapter 6).
- 3 Air filter clogged (Chapter 1).
- 4 Malfunction in the fuel injection or engine control system (Chapters 4 and 6).
- 5 Leaking head gasket (Chapter 2).
- 6 Timing belt or chain and/or sprockets worn (Chapter 2).
- 7 Camshaft lobes worn (Chapter 2).

### 9 Engine misses at idle speed

- 1 Spark plugs worn or not gapped properly (Chapter 1).
- 2 Faulty spark plug wires (Chapter 1).
- 3 Vacuum leaks (Chapter 1).
- 4 Incorrect ignition timing (Chapter 1).
- 5 Uneven or low compression (Chapter 2).
- 6 Problem with the fuel injection system (Chapter 4).

### 10 Engine misses throughout driving speed range

- 1 Fuel filter clogged and/or impurities in the fuel system (Chapters 1 and 4).
- 2 Low fuel pressure (Chapter 4).
- 3 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 4 Leaking spark plug wires (Chapters 1 or 5).
- 5 Faulty emission system components (Chapter 6).
- 6 Low or uneven cylinder compression pressures (Chapter 2).
- 7 Weak or faulty ignition system (Chapter 5).
- 8 Vacuum leak in fuel injection system, intake manifold, air control valve or vacuum hoses (Chapters 4 and 6).

### 11 Engine stumbles on acceleration

- 1 Spark plugs fouled (Chapter 1).
- 2 Problem with fuel injection or engine control system (Chapters 4 and 6).
- 3 Fuel filter clogged (Chapters 1 and 4).
- 4 Intake manifold air leak (Chapters 2 and 4).
- 5 Problem with the emissions control system (Chapter 6).

### 12 Engine surges while holding accelerator steady

- 1 Intake air leak (Chapter 4).
- 2 Fuel pump or fuel pressure regulator faulty (Chapter 4).

- 3 Problem with the fuel injection system (Chapter 4).
- 4 Problem with the emissions control system (Chapter 6).

### 13 Engine stalls

- 1 Idle speed incorrect (Chapter 1).
- 2 Fuel filter clogged and/or water and impurities in the fuel system (Chapters 1 and 4).
- 3 Distributor components damp or damaged (Chapter 5).
- 4 Faulty emissions system components (Chapter 6).
- 5 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 6 Faulty spark plug wires (Chapter 1).
- 7 Vacuum leak in the fuel injection system, intake manifold or vacuum hoses (Chapters 2 and 4).

### 14 Engine lacks power

- 1 Obstructed exhaust system (Chapter 4).
- 2 Defective spark plug wires or faulty coil (Chapters 1 and 5).
- 3 Faulty or incorrectly gapped spark plugs (Chapter 1).
- 4 Problem with the fuel injection system (Chapter 4).
- 5 Plugged air filter (Chapter 1).
- 6 Brakes binding (Chapter 9).
- 7 Automatic transaxle fluid level incorrect (Chapter 1).
- 8 Clutch slipping (Chapter 8).
- 9 Fuel filter clogged and/or impurities in the fuel system (Chapters 1 and 4).
- 10 Emission control system not functioning properly (Chapter 6).
- 11 Low or uneven cylinder compression pressures (Chapter 2).

### 15 Engine backfires

- 1 Emission control system not functioning properly (Chapter 6).
- 2 Problem with the fuel injection system (Chapter 4).
- 3 Vacuum leak at fuel injector(s), intake manifold, air control valve or vacuum hoses (Chapters 2 and 4).
- 4 Valve clearances incorrectly set and/or valves sticking (Chapter 2).

### 16 Pinging or knocking engine sounds during acceleration or uphill

- 1 Incorrect grade of fuel.
- 2 Fuel injection system faulty (Chapter 4).
- 3 Improper or damaged spark plugs or

- wires (Chapter 1).
- 4 Knock sensor defective (Chapter 6).
- 5 EGR valve not functioning (Chapter 6).
- 6 Vacuum leak (Chapters 2 and 4).

### 17 Engine runs with oil pressure light on

- 1 Low oil level (Chapter 1).
- 2 Idle rpm below specification (Chapter 1).
- 3 Short in wiring circuit (Chapter 12).
- 4 Faulty oil pressure sender (Chapter 2).
- 5 Worn engine bearings and/or oil pump (Chapter 2).

### 18 Engine diesels (continues to run) after switching off

- 1 Idle speed too high (Chapter 1).
- 2 Excessive engine operating temperature (Chapter 3).

## Engine electrical systems

### 19 Battery will not hold a charge

- 1 Alternator drivebelt defective or not adjusted properly (Chapter 1).
- 2 Battery electrolyte level low (Chapter 1).
- 3 Battery terminals loose or corroded (Chapter 1).
- 4 Alternator not charging properly (Chapter 5).
- 5 Loose, broken or faulty wiring in the charging circuit (Chapter 5).
- 6 Short in vehicle wiring (Chapter 12).
- 7 Internally defective battery (Chapters 1 and 5).

### 20 Alternator light fails to go out

- 1 Faulty alternator or charging circuit (Chapter 5).
- 2 Alternator drivebelt defective or out of adjustment (Chapter 1).
- 3 Alternator voltage regulator inoperative (Chapter 5).

### 21 Alternator light fails to come on when key is turned on

- 1 Warning light bulb defective (Chapter 12).
- 2 Fault in the printed circuit, dash wiring or bulb holder (Chapter 12).

## Fuel system

### 22 Excessive fuel consumption

- 1 Dirty or clogged air filter element (Chapter 1).
- 2 Emissions system not functioning properly (Chapter 6).
- 3 Fuel injection system not functioning properly (Chapter 4).
- 4 Low tire pressure or incorrect tire size (Chapter 1).

### 23 Fuel leakage and/or fuel odor

- 1 Leaking fuel feed or return line (Chapters 1 and 4).
- 2 Tank overfilled.
- 3 Evaporative canister filter clogged (Chapters 1 and 6).
- 4 Problem with the fuel injection system (Chapter 4).

## Cooling system

### 24 Overheating

- 1 Insufficient coolant in system (Chapter 1).
- 2 Water pump drivebelt defective or out of adjustment (Chapter 1).
- 3 Radiator core blocked or grille restricted (Chapter 3).
- 4 Thermostat faulty (Chapter 3).
- 5 Electric coolant fan inoperative or blades broken (Chapter 3).
- 6 Expansion tank cap not maintaining proper pressure (Chapter 3).

### 25 Overcooling

- 1 Faulty thermostat (Chapter 3).
- 2 Inaccurate temperature gauge sending unit (Chapter 3).

### 26 External coolant leakage

- 1 Deteriorated/damaged hoses; loose clamps (Chapters 1 and 3).
- 2 Water pump defective (Chapter 3).
- 3 Leakage from radiator core or coolant reservoir (Chapter 3).
- 4 Engine drain or water jacket core plugs leaking (Chapter 2).

### 27 Internal coolant leakage

- 1 Leaking cylinder head gasket (Chapter 2).



- 2 Cracked cylinder bore or cylinder head (Chapter 2).

## 28 Coolant loss

- 1 Too much coolant in reservoir (Chapter 1).
- 2 Coolant boiling away because of overheating (Chapter 3).
- 3 Internal or external leakage (Chapter 3).
- 4 Faulty radiator cap (Chapter 3).

## 29 Poor coolant circulation

- 1 Inoperative water pump (Chapter 3).
- 2 Restriction in cooling system (Chapters 1 and 3).
- 3 Water pump drivebelt defective/out of adjustment (Chapter 1).
- 4 Thermostat sticking (Chapter 3).

## Clutch

### 30 Pedal travels to floor - no pressure or very little resistance

- 1 Master or release cylinder faulty (Chapter 8).
- 2 Hose/pipe burst or leaking (Chapter 8).
- 3 Connections leaking (Chapter 8).
- 4 No fluid in reservoir (Chapter 8).
- 5 If fluid level in reservoir rises as pedal is depressed, master cylinder center valve seal is faulty (Chapter 8).
- 6 If there is fluid on dust seal at master cylinder, piston primary seal is leaking (Chapter 8).
- 7 Broken release bearing or fork (Chapter 8).
- 8 Faulty pressure plate diaphragm spring (Chapter 8).

### 31 Fluid in area of master cylinder dust cover and on pedal

Rear seal failure in master cylinder (Chapter 8).

### 32 Fluid on release cylinder

Release cylinder plunger seal faulty (Chapter 8).

### 33 Pedal feels spongy when depressed

Air in system (Chapter 8).

## 34 Unable to select gears

- 1 Faulty transaxle (Chapter 7).
- 2 Faulty clutch disc or pressure plate (Chapter 8).
- 3 Faulty release lever or release bearing (Chapter 8).
- 4 Faulty shift lever assembly or control cables (Chapter 8).

### 35 Clutch slips (engine speed increases with no increase in vehicle speed)

- 1 Clutch plate worn (Chapter 8).
- 2 Clutch plate is oil soaked by leaking rear main seal (Chapters 2 and 8).
- 3 Clutch plate not seated (Chapter 8).
- 4 Warped pressure plate or flywheel (Chapter 8).
- 5 Weak diaphragm springs (Chapter 8).
- 6 Clutch plate overheated. Allow to cool.

### 36 Grabbing (chattering) as clutch is engaged

- 1 Oil on clutch plate lining, burned or glazed facings (Chapter 8).
- 2 Worn or loose engine or transaxle mounts (Chapter 2).
- 3 Worn splines on clutch plate hub (Chapter 8).
- 4 Warped pressure plate or flywheel (Chapter 8).
- 5 Burned or smeared resin on flywheel or pressure plate (Chapter 8).

### 37 Transaxle rattling (clicking)

- 1 Release lever loose (Chapter 8).
- 2 Clutch plate damper spring failure (Chapter 8).

### 38 Noise in clutch area

- 1 Fork shaft improperly installed (Chapter 8).
- 2 Faulty bearing (Chapter 8).

### 39 Clutch pedal stays on floor

- 1 Clutch master cylinder piston binding in bore (Chapter 8).
- 2 Broken release bearing or fork (Chapter 8).

### 40 High pedal effort

- 1 Piston binding in bore (Chapter 8).

- 2 Pressure plate faulty (Chapter 8).
- 3 Incorrect size master or release cylinder (Chapter 8).

## Manual transaxle

### 41 Knocking noise at low speeds

- 1 Worn driveaxle constant velocity (CV) joints (Chapter 8).
- 2 Worn side gear shaft counterbore in differential case (Chapter 7A).\*

### 42 Noise most pronounced when turning

Differential gear noise (Chapter 7A).\*

### 43 Clunk on acceleration or deceleration

- 1 Loose engine or transaxle mounts (Chapter 2).
- 2 Worn differential pinion shaft in case.\*
- 3 Worn side gear shaft counterbore in differential case (Chapter 7A).\*
- 4 Worn or damaged driveaxle inboard CV joints (Chapter 8).

### 44 Clicking noise in turns

Worn or damaged outboard CV joints (Chapter 8).

### 45 Vibration

- 1 Rough wheel bearing (Chapter 10).
- 2 Damaged driveaxle (Chapter 8).
- 3 Out-of-round tires (Chapter 1).
- 4 Tire out of balance (Chapters 1 and 10).
- 5 Worn CV joint (Chapter 8).

### 46 Noisy in neutral with engine running

- 1 Damaged input gear bearing (Chapter 7A).\*
- 2 Damaged clutch release bearing (Chapter 8).

### 47 Noisy in one particular gear

- 1 Damaged or worn constant mesh gear (Chapter 7A).\*
- 2 Damaged or worn synchronizers (Chapter 7A).\*

- 3 Bent reverse fork (Chapter 7A).\*
- 4 Damaged fourth speed gear or output gear (Chapter 7A).\*
- 5 Worn or damaged reverse idler gear or idler bushing (Chapter 7A).\*

#### 48 Noisy in all gears

- 1 Insufficient lubricant (Chapter 7A).
- 2 Damaged or worn bearings (Chapter 7A).\*
- 3 Worn or damaged input gear shaft and/or output gear shaft (Chapter 7A).\*

#### 49 Slips out of gear

- 1 Worn or improperly adjusted linkage (Chapter 7A).
- 2 Transaxle loose on engine (Chapter 7A).
- 3 Shift linkage does not work freely, binds (Chapter 7A).
- 4 Input gear bearing retainer broken or loose (Chapter 7A).\*
- 5 Dirt between clutch cover and engine housing (Chapter 7A).
- 6 Worn shift fork (Chapter 7A).\*

#### 50 Leaks lubricant

- 1 Side gear shaft seals worn (Chapter 7).
- 2 Excessive amount of lubricant in transaxle (Chapters 1 and 7A).
- 3 Loose or broken input gear shaft bearing retainer (Chapter 7A).\*
- 4 Input gear bearing retainer O-ring and/or lip seal damaged (Chapter 7A).\*

#### 51 Locked in gear

Lock pin or interlock pin missing (Chapter 7A).\*

\* Although the corrective action necessary to remedy the symptoms described is beyond the scope of this manual, the above information should be helpful in isolating the cause of the condition so that the owner can communicate clearly with a professional mechanic.

#### Automatic transaxle

**Note:** Due to the complexity of the automatic transaxle, it is difficult for the home mechanic to properly diagnose and service this component. For problems other than the following, the vehicle should be taken to a dealer or transmission shop.

#### 52 Fluid leakage

- 1 Automatic transaxle fluid is a deep red

color. Fluid leaks should not be confused with engine oil, which can easily be blown onto the transaxle by air flow.

2 To pinpoint a leak, first remove all built-up dirt and grime from the transaxle housing with degreasing agents and/or steam cleaning. Then drive the vehicle at low speeds so air flow will not blow the leak far from its source. Raise the vehicle and determine where the leak is coming from. Common areas of leakage are:

- a) Dipstick tube (Chapters 1 and 7)
- b) Transaxle oil lines (Chapter 7)
- c) Speed sensor (Chapter 6)
- d) Driveaxle oil seals (Chapter 7).

#### 53 Transaxle fluid brown or has a burned smell

Transaxle fluid overheated (Chapter 1).

#### 54 General shift mechanism problems

1 Chapter 7, Part B, deals with checking and adjusting the shift linkage on automatic transaxles. Common problems which may be attributed to poorly adjusted linkage are:

- a) Engine starting in gears other than Park or Neutral.
- b) Indicator on shifter pointing to a gear other than the one actually being used.
- c) Vehicle moves when in Park.

2 Refer to Chapter 7B for the shift linkage adjustment procedure.

#### 55 Transaxle slips, shifts roughly, is noisy or has no drive in forward or reverse gears

There are many probable causes for the above problems, but the home mechanic should be concerned with only one possibility - fluid level. Before taking the vehicle to a repair shop, check the level and condition of the fluid as described in Chapter 1. Correct the fluid level as necessary or change the fluid and filter if needed. If the problem persists, have a professional diagnose the cause.

#### Driveaxles

#### 56 Clicking noise in turns

Worn or damaged outboard CV joint (Chapter 8).

#### 57 Shudder or vibration during acceleration

- 1 Excessive toe-in (Chapter 10).
- 2 Worn or damaged inboard or outboard CV joints (Chapter 8).
- 3 Sticking inboard CV joint assembly (Chapter 8).

#### 58 Vibration at highway speeds

- 1 Out-of-balance front wheels and/or tires (Chapters 1 and 10).
- 2 Out-of-round front tires (Chapters 1 and 10).
- 3 Worn CV joint(s) (Chapter 8).

#### Brakes

**Note:** Before assuming that a brake problem exists, make sure that:

- a) The tires are in good condition and properly inflated (Chapter 1).
- b) The front end alignment is correct.
- c) The vehicle is not loaded with weight in an unequal manner.

#### 59 Vehicle pulls to one side during braking

- 1 Incorrect tire pressures (Chapter 1).
- 2 Front end out of alignment (have the front end aligned).
- 3 Front, or rear, tire sizes not matched to one another.
- 4 Restricted brake lines or hoses (Chapter 9).
- 5 Malfunctioning drum brake or caliper assembly (Chapter 9).
- 6 Loose suspension parts (Chapter 10).
- 7 Excessive wear of brake shoe or pad material or disc/drum on one side (Chapter 9).
- 8 Contamination (grease or brake fluid) of brake shoe or pad material or disc/drum on one side (Chapter 9).

#### 60 Noise (high-pitched squeal when the brakes are applied)

Front brake pads worn out. Replace pads with new ones immediately (Chapter 9).

#### 61 Brake roughness or chatter (pedal pulsates)

- 1 Excessive lateral runout (Chapter 9).
- 2 Uneven pad wear (Chapter 9).
- 3 Defective disc (Chapter 9).



### 62 Excessive brake pedal effort required to stop vehicle

- 1 Malfunctioning power brake booster (Chapter 9).
- 2 Partial system failure (Chapter 9).
- 3 Excessively worn pads or shoes (Chapter 9).
- 4 Piston in caliper or wheel cylinder stuck or sluggish (Chapter 9).
- 5 Brake pads or shoes contaminated with oil or grease (Chapter 9).
- 6 Brake disc grooved and/or glazed (Chapter 9).
- 7 New pads or shoes installed and not yet seated. It will take a while for the new material to seat against the disc or drum.

### 63 Excessive brake pedal travel

- 1 Partial brake system failure (Chapter 9).
- 2 Insufficient fluid in master cylinder (Chapters 1 and 9).
- 3 Air trapped in system (Chapter 9).

### 64 Dragging brakes

- 1 Incorrect adjustment of brake light switch (Chapter 9).
- 2 Master cylinder pistons not returning correctly (Chapter 9).
- 3 Restricted brake lines or hoses (Chapter 9).
- 4 Incorrect parking brake adjustment (Chapter 9).

### 65 Grabbing or uneven braking action

- 1 Malfunction of proportioning valve (Chapter 9).
- 2 Binding brake pedal mechanism (Chapter 9).
- 3 Contaminated brake linings (Chapter 9).

### 66 Brake pedal feels spongy when depressed

- 1 Air in hydraulic lines (Chapter 9).
- 2 Master cylinder mounting bolts loose (Chapter 9).
- 3 Master cylinder defective (Chapter 9).

### 67 Brake pedal travels to the floor with little resistance

- 1 Little or no fluid in the master cylinder reservoir caused by leaking caliper or wheel cylinder piston(s) (Chapter 9).
- 2 Loose, damaged or disconnected brake lines (Chapter 9).

### 68 Parking brake does not hold

Parking brake linkage improperly adjusted (Chapter 9).

### Suspension and steering systems

**Note:** Before attempting to diagnose the suspension and steering systems, perform the following preliminary checks:

- a) Tires for wrong pressure and uneven wear.
- b) Steering universal joints from the column to the rack and pinion for loose connectors or wear.
- c) Front and rear suspension and the rack and pinion assembly for loose or damaged parts.
- d) Out-of-round or out-of-balance tires, bent rims and loose and/or rough wheel bearings.

### 69 Vehicle pulls to one side

- 1 Mismatched or uneven tires (Chapter 10).
- 2 Broken or sagging springs (Chapter 10).
- 3 Wheel alignment incorrect. Have the wheels professionally aligned.
- 4 Front brake dragging (Chapter 9).

### 70 Abnormal or excessive tire wear

- 1 Wheel alignment out-of-specification. Have the wheels aligned.
- 2 Sagging or broken springs (Chapter 10).
- 3 Tire out-of-balance (Chapter 10).
- 4 Worn strut damper (Chapter 10).
- 5 Overloaded vehicle.
- 6 Tires not rotated regularly.

### 71 Wheel makes a thumping noise

- 1 Blister or bump on tire (Chapter 10).
- 2 Improper strut damper action (Chapter 10).

### 72 Shimmy, shake or vibration

- 1 Tire or wheel out-of-balance or out-of-round (Chapter 10).
- 2 Loose or worn wheel bearings (Chapter 10).
- 3 Worn tie-rod ends (Chapter 10).
- 4 Worn balljoints (Chapters 1 and 10).
- 5 Excessive wheel runout (Chapter 10).
- 6 Blister or bump on tire (Chapter 10).

### 73 Hard steering

- 1 Lack of lubrication at balljoints and/or tie-rod ends (Chapter 10).

- 2 Wheel alignment out-of-specifications. Have the wheels professionally aligned.
- 3 Low tire pressure(s) (Chapter 1).
- 4 Worn steering gear (Chapter 10).

### 74 Poor returnability of steering to center

- 1 Lack of lubrication at balljoints and tie-rod ends (Chapter 10).
- 2 Binding in balljoints (Chapter 10).
- 3 Binding in steering column (Chapter 10).
- 4 Lack of lubricant in steering gear assembly (Chapter 10).
- 5 Wheel alignment out-of-specifications. Have the wheels professionally aligned.

### 75 Abnormal noise at the front end

- 1 Lack of lubrication at balljoints and tie-rod ends (Chapters 1 and 10).
- 2 Damaged strut mounting (Chapter 10).
- 3 Worn control arm bushings or tie-rod ends (Chapter 10).
- 4 Loose stabilizer bar (Chapter 10).
- 5 Loose wheel nuts (Chapter 1).
- 6 Loose suspension bolts (Chapter 10).

### 76 Wander or poor steering stability

- 1 Mismatched or uneven tires (Chapter 10).
- 2 Lack of lubrication at balljoints and tie-rod ends (Chapters 1 and 10).
- 3 Worn strut assemblies (Chapter 10).
- 4 Loose stabilizer bar (Chapter 10).
- 5 Broken or sagging springs (Chapter 10).
- 6 Wheels out of alignment. Have the wheels professionally aligned.

### 77 Erratic steering when braking

- 1 Wheel bearings worn (Chapter 10).
- 2 Broken or sagging springs (Chapter 10).
- 3 Leaking wheel cylinder or caliper (Chapter 10).
- 4 Warped rotors or drums (Chapter 10).

### 78 Excessive pitching and/or rolling around corners or during braking

- 1 Loose stabilizer bar (Chapter 10).
- 2 Worn strut dampers or mountings (Chapter 10).
- 3 Broken or sagging springs (Chapter 10).
- 4 Overloaded vehicle.

### 79 Suspension bottoms

- 1 Overloaded vehicle.
- 2 Sagging springs (Chapter 10).

## 80 Cupped tires

- 1 Front wheel or rear wheel alignment out-of-specifications. Have the wheels professionally aligned.
- 2 Worn strut dampers or shock absorbers (Chapter 10).
- 3 Wheel bearings worn (Chapter 10).
- 4 Excessive tire or wheel runout (Chapter 10).
- 5 Worn balljoints (Chapter 10).

## 81 Excessive tire wear on outside edge

- 1 Inflation pressures incorrect (Chapter 1).
- 2 Excessive speed in turns.
- 3 Wheel alignment incorrect (excessive

toe-in). Have professionally aligned.  
4 Suspension arm bent or twisted (Chapter 10).

## 82 Excessive tire wear on inside edge

- 1 Inflation pressures incorrect (Chapter 1).
- 2 Wheel alignment incorrect (toe-out). Have professionally aligned.
- 3 Loose or damaged steering components (Chapter 10).

## 83 Tire tread worn in one place

- 1 Tires out-of-balance.
- 2 Damaged or buckled wheel. Inspect and

replace if necessary.  
3 Defective tire (Chapter 1).

## 84 Excessive play or looseness in steering system

- 1 Wheel bearing(s) worn (Chapter 10).
- 2 Tie-rod end loose (Chapter 10).
- 3 Steering gear loose (Chapter 10).
- 4 Worn or loose steering intermediate shaft U-joint (Chapter 10).

## 85 Rattling or clicking noise in steering gear

- 1 Steering gear loose (Chapter 10).
- 2 Steering gear defective.



# Chapter 1

## Tune-up and routine maintenance

### Contents

	Section		Section
Air filter check and replacement .....	18	Maintenance schedule .....	1
Automatic transaxle fluid change .....	25	Manual transaxle lubricant change .....	26
Battery check, maintenance and charging .....	8	Manual transaxle lubricant level check .....	16
Brake check .....	13	Positive Crankcase Ventilation (PCV) valve replacement (2004 and earlier four-cylinder models) .....	29
Brake fluid change .....	23	Seat belt check .....	11
Cooling system check .....	9	Spark plug check and replacement .....	30
Cooling system servicing (draining, flushing and refilling) .....	22	Spark plug wire check and replacement (2004 and earlier four-cylinder engines) .....	32
Differential lubricant change (4WD models) .....	27	Steering and suspension check .....	14
Driveaxle boot check .....	19	Tire and tire pressure checks .....	5
Drivebelt check and replacement .....	24	Tire rotation .....	10
Engine oil and filter change .....	6	Transfer case lubricant change (4WD models) .....	28
Exhaust system check .....	20	Transfer case lubricant level check .....	17
Fluid level checks .....	4	Tune-up general information .....	3
Fuel filter replacement .....	21	Underhood hose check and replacement .....	12
Fuel system check .....	15	Windshield wiper blade inspection and replacement .....	7
Ignition coil check (V6 engines and 2005 and later four-cylinder engines) .....	31		
Introduction .....	2		

### Specifications

#### Recommended lubricants and fluids

**Note:** Listed here are manufacturer recommendations at the time this manual was written. Manufacturers occasionally upgrade their fluid and lubricant specifications, so check with your local auto parts store for current recommendations.

Engine oil	API "certified for gasoline engines"
Type .....	SAE 5W-20
Viscosity .....	Unleaded gasoline, 87 octane
Fuel .....	MERCON® automatic transmission fluid. <b>Caution:</b> Do not use Mercon® V or dual usage Mercon®/Mercon® V automatic transmission fluid.
Automatic transaxle fluid .....	SAE 75W-90 gear oil
Manual transaxle lubricant .....	SAE 75W-140
Transfer case (4WD models)	SAE 80W-90 Premium Rear Axle Lubricant
With automatic transaxle .....	SAE 80W-90 Premium Rear Axle Lubricant
With manual transaxle .....	DOT 3 brake fluid
Rear differential lubricant (4WD models) .....	DOT 3 brake fluid
Brake fluid .....	50/50 mixture of Motorcraft Premium Engine Coolant (green colored) or Motorcraft Premium Gold Engine Coolant (yellow colored) and distilled water
Clutch fluid .....	MERCON® automatic transmission fluid
Engine coolant* .....	
Power steering system .....	

**\*Caution:** Do not mix coolants of different colors. Doing so might damage the cooling system and/or the engine. The manufacturer specifies either a green colored coolant or a yellow colored coolant to be used in these systems, depending on what was originally installed in the vehicle.

**Capacities\***

## Engine oil (including filter)

Four-cylinder engine .....	4.5 qts (4.25 liters)
V6 engine	
2004 and earlier models .....	5.5 qts (5.2 liters)
2005 and later models .....	6.0 qts (5.7 liters)

## Coolant

Four-cylinder engine .....	Up to 7.0 qts (6.6 liters)
V6 engine .....	Up to 10.5 qts (10.0 liters)

## Automatic transaxle (dry fill) .....

Up to 10.0 qts (9.5 liters)

**Note:** Since this is a dry-fill specification, the amount required during a routine fluid change will be substantially less. The best way to determine the amount of fluid to add during a routine fluid change is to measure the amount drained. Begin the refill procedure by initially adding 1/3rd of the amount drained. Then, with the engine running, add 1/2-pint at a time (cycling the shifter through each gear position between additions) until the level is correct on the dipstick. It is important to not overfill the transaxle. You will, however, need to purchase a few extra quarts, since the fluid replacement procedure involves flushing the torque converter (see Section 25).

## Manual transaxle

2WD models .....	Up to 2.85 qts (2.7 liters)
4WD models .....	Up to 2.32 qts (2.2 liters)

## Transfer case (4WD models)

With automatic transaxle .....	Up to 12 ounces (0.35 liters)
With manual transaxle .....	Up to 12 ounces (0.35 liters)

## Rear differential (4WD models) .....

Up to 1.47 qts (1.4 liters)

\*All capacities approximate. Add as necessary to bring up to appropriate level.

**Ignition system**

## Spark plug type and gap

## Type

## Four-cylinder engine

## Cylinders 1 and 3 .....

Motorcraft AZFS-32F or equivalent

## Cylinders 2 and 4 .....

Motorcraft AZFS-32FE or equivalent

## V6 engine .....

Motorcraft AWSF-32F or equivalent

## Gap

## 2.0L four-cylinder engine .....

0.048 to 0.052 inch (1.22 to 1.32 mm)

## 2.3L four-cylinder engine .....

0.054 inch (1.37 mm)

## V6 engine .....

0.052 to 0.056 inch (1.3 to 1.4 mm)


## Engine firing order

## Four-cylinder engine .....

1-3-4-2

## V6 engine .....

1-4-2-5-3-6

FRONT OF  
VEHICLE

Cylinder location (and 2.0L engine coil terminal arrangement) (four-cylinder engines)



1-4-2-5-3-6

FRONT OF  
VEHICLECylinder location  
(V6 engine)

36075-B-SPECS HAYNES

**Valve clearances (engine cold)**

## Four-cylinder engine

2.0L intake valve .....	0.004 to 0.007 inch (0.11 to 0.18 mm)
2.3L intake valve .....	0.008 to 0.011 inch (0.22 to 0.28 mm)
2.0L exhaust valve .....	0.010 to 0.013 inch (0.27 to 0.34 mm)
2.3L exhaust valve .....	0.010 to 0.013 inch (0.27 to 0.33 mm)

## V6 engine .....

No adjustment required

**Clutch pedal**

## Freeplay .....

0.22 to 0.59 inch (5.58 to 15 mm)

## Height .....

8.35 to 8.54 inches (212 to 217 mm)



**Brakes**

Disc brake pad lining thickness (minimum) .....	1/8 inch (3 mm)
Drum brake shoe lining thickness (minimum) .....	1/16 inch (1.5 mm)
Parking brake adjustment .....	3 to 5 clicks


**Torque specifications**

	Ft-lbs (unless otherwise indicated)	Nm
Engine oil drain plug		
Four-cylinder engine .....	18	25
V6 engine .....	19	26
Automatic transaxle drain plug .....	20	27
Manual transaxle drain plug .....	35	47
Rear differential cover bolts (4WD) .....	17	23
Rear differential check/fill plug (4WD) .....	20	27
Spark plugs .....	132 in-lbs	15
Drivebelt tensioner bolts		
Four-cylinder engine .....	18	25
V6 engine .....	18	25
Water pump drivebelt tensioner mounting bolt (V6 engine) .....	89 in-lbs	10
Wheel lug nuts .....	98	133



Typical engine compartment components (V6 engine)

- |                         |                                      |                                      |
|-------------------------|--------------------------------------|--------------------------------------|
| 1 Brake fluid reservoir | 5 Automatic transaxle fluid dipstick | 9 Power steering fluid reservoir     |
| 2 Fuse/relay block      | 6 Engine oil dipstick                | 10 Battery                           |
| 3 Air filter housing    | 7 Radiator hose                      | 11 Windshield washer fluid reservoir |
| 4 Coolant reservoir     | 8 Engine oil filler cap              |                                      |




Typical engine compartment components (four-cylinder engine)

- 1 Brake/clutch fluid reservoir
- 2 Air filter housing
- 3 Coolant reservoir

- 4 Engine oil filler cap
- 5 Battery
- 6 Power steering fluid reservoir

- 7 Engine oil dipstick (not visible in this photo)
- 8 Automatic transmission dipstick location



Typical engine underside components (V6 engine)

- 1 Engine oil filter
- 2 Engine oil drain plug


- 3 Automatic transaxle drain plug
- 4 Front disc brake caliper

- 5 Driveaxle boot
- 6 Exhaust pipe




**Typical rear underside components (2WD)**

- 1 Exhaust system hanger
- 2 Muffler
- 3 Fuel tank
- 4 Rear drum brake assembly
- 5 Brake hose
- 6 Parking brake cable
- 7 Shock absorber



**Typical rear underside components (4WD)**

- 1 Driveshaft
- 2 Driveaxle boot
- 3 Differential
- 4 Differential filler plug



# 1 Maintenance schedule

The maintenance intervals in this manual are provided with the assumption that you, not the dealer, will be doing the work. These are the minimum maintenance intervals recommended by the factory for vehicles that are driven daily. If you wish to keep your vehicle in peak condition at all times, you may wish to perform some of these procedures even more often. Because frequent maintenance enhances the efficiency, performance and resale value of your car, we encourage you to do so. If you drive in dusty areas, tow a trailer, idle or drive at low speeds for extended periods or drive for short distances (less than four miles) in below freezing temperatures, shorter intervals are also recommended.

When your vehicle is new, it should be serviced by a factory authorized dealer service department to protect the factory warranty. In many cases, the initial maintenance check is done at no cost to the owner.

## Every 250 miles or weekly, whichever comes first

- Check the engine oil level (Section 4)
- Check the engine coolant level (Section 4)
- Check the brake and clutch fluid level (Section 4)
- Check the windshield washer fluid level (Section 4)
- Check the power steering fluid level (Section 4)
- Check the automatic transaxle fluid level (Section 4)
- Check the tires and tire pressures (Section 5)

## Every 3000 miles or 3 months, whichever comes first

*All items listed above plus:*

- Change the engine oil and oil filter (Section 6)

## Every 7500 miles or 6 months, whichever comes first

*All items listed above plus:*

- Inspect (and replace, if necessary) the windshield wiper blades (Section 7)
- Check and service the battery (Section 8)
- Check the cooling system (Section 9)
- Rotate the tires (Section 10)
- Check the seat belts (Section 11)

## Every 15,000 miles or 12 months, whichever comes first

*All items listed above plus:*

- Check all underhood hoses (Section 12)
- Inspect the brake system (Section 13)\*
- Inspect the suspension and steering components (Section 14)\*
- Check the fuel system (Section 15)
- Check the manual transaxle lubricant level (Section 16)
- Check the transfer case lubricant level (4WD models) (Section 17)
- Check (and replace, if necessary) the air filter (Section 18)\*
- Check the driveaxle boots (Section 19)

## Every 30,000 miles or 24 months, whichever comes first

*All items listed above plus:*

- Check the exhaust system (Section 20)
- Replace the fuel filter (Section 21)
- Service the cooling system (drain, flush and refill) (Section 22)
- Change the brake fluid (Section 23)
- Check/adjust the engine drivebelts (Section 24)
- Replace the automatic transaxle fluid (Section 25)\*\*
- Replace the manual transaxle lubricant (Section 26)
- Replace the rear differential lubricant (4WD) (Section 27)
- Replace the transfer case lubricant (4WD) (Section 28)

## Every 60,000 miles or 48 months, whichever comes first

- Replace the Positive Crankcase Ventilation (PCV) valve (four-cylinder engines) (Section 29)
- Check (and replace, if necessary) the spark plugs (conventional, non-platinum or iridium type) (Section 30)
- Check the ignition coils (V6 engines and 2005 and later four-cylinder engines) (Section 31)
- Inspect (and replace, if necessary) the spark plug wires (2004 and earlier four-cylinder engines) (Section 32)
- Check and adjust the valve clearances (four-cylinder engines) (see Chapter 2A)
- Inspect (and replace, if necessary) the engine timing belt (four-cylinder engines) (see Chapter 2A)

## Every 90,000 miles

- Replace the engine timing belt (four-cylinder engines) (See Chapter 2A)

## Every 100,000 miles

- Replace the spark plugs (platinum-tipped type) (Section 30)
- Positive crankcase ventilation (PCV) replacement (V6 engines) (see Chapter 6)

*\*This item is affected by "severe" operating conditions as described below. If your vehicle is operated under "severe" conditions, perform all maintenance indicated with an asterisk (\*) at 3000 mile/3 month intervals. Severe conditions are indicated if you mainly operate your vehicle under one or more of the following conditions:*

- Operating in dusty areas
- Towing a trailer
- Idling for extended periods and/or low speed operation
- Operating when outside temperatures remain below freezing and when most trips are less than 4 miles

*\*\* If operated under one or more of the following conditions, change the manual or automatic transaxle fluid and differential lubricant every 15,000 miles:*

- In heavy city traffic where the outside temperature regularly reaches 90-degrees F (32-degrees C) or higher
- In hilly or mountainous terrain



## 2 Introduction

This Chapter is designed to help the home mechanic maintain the Ford Escape, Mazda Tribute or Mercury Mariner with the goals of maximum performance, economy, safety and reliability in mind.

Included is a master maintenance schedule, followed by procedures dealing specifically with each item on the schedule. Visual checks, adjustments, component replacement and other helpful items are included. Refer to the **accompanying illustrations** of the engine compartment and the underside of the vehicle for the locations of various components.

Servicing the vehicle, in accordance with the mileage/time maintenance schedule and the step-by-step procedures will result in a planned maintenance program that should produce a long and reliable service life. Keep in mind that it is a comprehensive plan, so maintaining some items but not others at the specified intervals will not produce the same results.

As you service the vehicle, you will discover that many of the procedures can - and should - be grouped together because of the nature of the particular procedure you're performing or because of the close proximity of two otherwise unrelated components to one another.

For example, if the vehicle is raised for chassis lubrication, you should inspect the exhaust, suspension, steering and fuel systems while you're under the vehicle. When you're rotating the tires, it makes good sense to check the brakes since the wheels are already removed. Finally, let's suppose you have to borrow or rent a torque wrench. Even if you only need it to tighten the spark plugs, you might as well check the torque of as many critical fasteners as time allows.

The first step in this maintenance program is to prepare yourself before the actual work begins. Read through all the procedures you're planning to do, then gather up all the parts and tools needed. If it looks like you might run into problems during a particular job, seek advice from a mechanic or an experienced do-it-yourselfer.

### Owner's Manual and VECI label information

Your vehicle owner's manual was written for your year and model and contains very specific information on component locations, specifications, fuse ratings, part numbers, etc. The Owner's Manual is an important resource for the do-it-yourselfer to have; if one was not supplied with your vehicle, it can generally be ordered from a dealer parts department.

Among other important information, the Vehicle Emissions Control Information (VECI) label contains specifications and procedures for applicable tune-up adjustments and, in some instances, spark plugs (see Chapter 6 for more information on the VECI label). The

information on this label is the exact maintenance data recommended by the manufacturer. This data often varies by intended operating altitude, local emissions regulations, month of manufacture, etc.

This Chapter contains procedural details, safety information and more ambitious maintenance intervals than you might find in manufacturer's literature. However, you may also find procedures or specifications in your Owner's Manual or VECI label that differ with what's printed here. In these cases, the Owner's Manual or VECI label can be considered correct, since it is specific to your particular vehicle.

## 3 Tune-up general information

The term tune-up is used in this manual to represent a combination of individual operations rather than one specific procedure.

If, from the time the vehicle is new, the routine maintenance schedule is followed closely and frequent checks are made of fluid levels and high wear items, as suggested throughout this manual, the engine will be kept in relatively good running condition and the need for additional work will be minimized.

More likely than not, however, there will be times when the engine is running poorly due to lack of regular maintenance. This is even more likely if a used vehicle, which has not received regular and frequent maintenance checks, is purchased. In such cases, an engine tune-up will be needed outside of the regular routine maintenance intervals.

The first step in any tune-up or diagnostic procedure to help correct a poor running engine is a cylinder compression check. A compression check (see Chapter 2C) will help determine the condition of internal engine components and should be used as a guide for tune-up and repair procedures. If, for instance, a compression check indicates serious internal engine wear, a conventional tune-up will not improve the performance of the engine and would be a waste of time and

money. Because of its importance, the compression check should be done by someone with the right equipment and the knowledge to use it properly.

The following procedures are those most often needed to bring a generally poor running engine back into a proper state of tune.

### Minor tune-up

- Check all engine related fluids (Section 4)
- Clean, inspect and test the battery (Section 8)
- Check the cooling system (Section 9)
- Check all underhood hoses (Section 12)
- Check the fuel system (Section 15)
- Check the air filter (Section 18)

### Major tune-up

All items listed under Minor tune-up, plus . . .

- Replace the air filter (Section 18)
- Replace the fuel filter (Section 21)
- Check the drivebelt (Section 24)
- Replace the PCV valve (Section 29)
- Replace the spark plugs (Section 30)


## 4 Fluid level checks (every 250 miles or weekly)

1 Fluids are an essential part of the lubrication, cooling, brake and windshield washer systems. Because the fluids gradually become depleted and/or contaminated during normal operation of the vehicle, they must be periodically replenished. See *Recommended lubricants and fluids* at the beginning of this Chapter before adding fluid to any of the following components. **Note:** The vehicle must be on level ground when fluid levels are checked.


### Engine oil

Refer to illustrations 4.2a, 4.2b, 4.4 and 4.6

2 The oil level is checked with a dipstick, which is attached to the engine block (see illustrations). The dipstick extends through a metal tube down into the oil pan.




4.2a The oil dipstick is located on the forward side of the engine on V6 engines



4.2b On four-cylinder engines the oil dipstick is located on the forward side of the engine next to the exhaust manifold





4.4 The oil level should be in the safe range - if it's below the MIN of ADD mark, add enough oil to bring it up to or near the MAX or FULL mark

3 The oil level should be checked before the vehicle has been driven, or about 5 minutes after the engine has been shut off. If the oil is checked immediately after driving the vehicle, some of the oil will remain in the upper part of the engine, resulting in an inaccurate reading on the dipstick.

4 Pull the dipstick out of the tube and wipe all the oil from the end with a clean rag or paper towel. Insert the clean dipstick all the way back into the tube and pull it out again. Note the oil at the end of the dipstick. At its highest point, the level should be between the MIN and MAX marks on the dipstick (see illustration).

5 It takes one quart of oil to raise the level from the MIN mark to the MAX mark on the dipstick. Do not allow the level to drop below the MIN mark or oil starvation may cause engine damage. Conversely, overfilling the engine (adding oil above the MAX mark) may cause oil fouled spark plugs, oil leaks or oil seal failures. Maintaining the oil level above the MAX mark can cause excessive oil consumption.

6 To add oil, remove the filler cap from the valve cover (see illustration). After adding oil, wait a few minutes to allow the level to stabilize, then pull out the dipstick and check the level again. Add more oil if required. Install the filler cap and tighten it by hand only.

7 Checking the oil level is an important preventive maintenance step. A consistently low oil level indicates oil leakage through damaged seals, defective gaskets or past worn rings or valve guides. If the oil looks milky in color or has water droplets in it, the cylinder head gasket(s) may be blown or the head(s) or block may be cracked. The engine should be checked immediately. The condition of the oil should also be checked. Whenever you check the oil level, slide your thumb and index finger up the dipstick before wiping off the oil. If you see small dirt or metal particles clinging to the dipstick, the oil should be changed (see Section 6).

### Engine coolant

Refer to illustrations 4.8 and 4.9

**Warning:** Do not allow antifreeze to come in contact with your skin or painted surfaces of the vehicle. Flush contaminated areas immediately with plenty of water. Don't store new coolant or leave old coolant lying around where it's accessible to children or pets - they're attracted by its sweet smell. Ingestion of even a small amount of coolant can be


*fatal!* Wipe up garage floor and drip pan spills immediately. Keep antifreeze containers covered and repair cooling system leaks as soon as they're noticed.

8 All vehicles covered by this manual are equipped with a pressurized coolant recovery system. A plastic expansion tank located at the front of the engine compartment is connected by a hose to the radiator (see illustration). As the engine heats up during operation, the expanding coolant fills the tank.


9 The coolant level in the tank should be checked regularly. **Warning:** Do not remove the expansion tank cap to check the coolant level when the engine is warm! The level in the tank varies with the temperature of the engine. When the engine is cold, the coolant level should be at the COLD FULL mark on the reservoir. If it isn't then remove the cap from the tank and add a 50/50 mixture of ethylene glycol based antifreeze and water (see illustration).

10 Drive the vehicle, let the engine cool completely then recheck the coolant level. Don't use rust inhibitors or additives. If only a small amount of coolant is required to bring the system up to the proper level, water can be used. However, repeated additions of water will dilute the antifreeze and water solution. In order to maintain the proper ratio of antifreeze and water, always top up the coolant level with the correct mixture. An empty plastic milk jug or bleach bottle makes an excellent container for mixing coolant.

11 If the coolant level drops consistently, there may be a leak in the system. Inspect the



4.8 The cooling system expansion tank is located at the right side of the engine compartment



4.6 The oil filler cap is located on the valve cover - always make sure the area around the opening is clean before unscrewing the cap to prevent dirt from contaminating the engine (V6 engine shown)

radiator, hoses, filler cap, drain plugs and water pump (see Section 9). If no leaks are noted, have the expansion tank cap pressure tested by a service station.


12 If you have to remove the expansion tank cap wait until the engine has cooled completely, then wrap a thick cloth around the cap and unscrew it slowly, stopping if you hear a hissing noise. If coolant or steam escapes, let the engine cool down longer, then remove the cap.

13 Check the condition of the coolant as well. It should be relatively clear. If it's brown or rust colored, the system should be drained, flushed and refilled. Even if the coolant appears to be normal, the corrosion inhibitors wear out, so it must be replaced at the specified intervals.


### Brake and clutch fluid

Refer to illustrations 4.14 and 4.15

14 The brake master cylinder is mounted on the front of the power booster unit in the



4.9 When the engine is cold, the engine coolant level should be at the COLD FULL mark



4.14 The clutch master cylinder is located next to the brake master cylinder and the two share a common reservoir

engine compartment. The hydraulic clutch master cylinder used on manual transaxle vehicles is located next to the brake master cylinder (see illustration).

15 The brake master cylinder and the clutch master cylinder share a common reservoir. To check the fluid level of either system, simply look at the MAX and MIN marks on the brake fluid reservoir (see illustration).


16 If the level is low, wipe the top of the reservoir cover with a clean rag to prevent contamination of the brake system before lifting the cover.

17 Add only the specified brake fluid to the reservoir (refer to *Recommended lubricants and fluids* at the front of this Chapter or to your owner's manual). Mixing different types of brake fluid can damage the system. Fill the brake master cylinder reservoir only to the MAX line. **Warning:** Use caution when filling the reservoir - brake fluid can harm your eyes and damage painted surfaces. Do not use brake fluid that is more than one year old or has been left open. Brake fluid absorbs moisture from the air. Excess moisture can cause a dangerous loss of braking.

18 While the reservoir cap is removed, inspect the master cylinder reservoir for contamination. If deposits, dirt particles or water droplets are present, the system should be drained and refilled.

19 After filling the reservoir to the proper level, make sure the lid is properly seated to prevent fluid leakage.

20 The fluid in the brake master cylinder will drop slightly as the brake pads at each wheel wear down during normal operation. If the master cylinder requires repeated replenishing to keep it at the proper level, this is an indication of leakage in the brake or clutch system, which should be corrected immediately. If the brake system shows an indication of leakage check all brake lines and connections, along with the calipers, wheel cylinders and booster (see Section 13 for more information). If the hydraulic clutch system shows an indication of leakage check all clutch lines and connections, along with the clutch release cyl-



4.15 The brake fluid level should be kept between the MIN and MAX marks on the translucent plastic reservoir; the same reservoir contains the clutch fluid and is connected to the clutch master cylinder by a hose

inder (see Chapter 8 for more information).


21 If, upon checking the brake or clutch master cylinder fluid level, you discover the reservoir empty or nearly empty, the systems should be bled (see Chapters 8 and 9).

### Windshield washer fluid


Refer to illustration 4.22

22 Fluid for the windshield washer system is stored in a plastic reservoir located at the right front of the engine compartment (see illustration).

23 In milder climates, plain water can be used in the reservoir, but it should be kept no more than 2/3 full to allow for expansion if the water freezes. In colder climates, use windshield washer system antifreeze, available at any auto parts store, to lower the freezing point of the fluid. Mix the antifreeze with water in accordance with the manufacturer's directions on the container. **Caution:** Do not use cooling system antifreeze - it will damage the vehicle's paint.



4.25 The power steering fluid reservoir is located at the right side of the engine compartment next to the windshield washer fluid reservoir



4.22 The windshield/rear window washer fluid reservoir is located in the right front corner of the engine compartment

### Power steering fluid

Refer to illustrations 4.25 and 4.28

24 Check the power steering fluid level periodically to avoid steering system problems, such as damage to the pump. **Caution:** DO NOT hold the steering wheel against either stop (extreme left or right turn) for more than five seconds. If you do, the power steering pump could be damaged.


25 The power steering reservoir, located at the right side of the engine compartment (see illustration), has MIN and MAX fluid level marks on the side. The fluid level can be seen without removing the reservoir cap.

26 Park the vehicle on level ground and apply the parking brake.

27 Run the engine until it has reached normal operating temperature. With the engine at idle, turn the steering wheel back and forth about 10 times to get any air out of the steering system. Shut the engine off with the wheels in the straight-ahead position.


28 Note the fluid level on the side of the reservoir. It should be between the two marks (see illustration).

29 Add small amounts of fluid until the level is correct. **Caution:** Do not overfill the reser-



4.28 At normal operating temperature, the power steering fluid level should be between the MAX and MIN marks





**4.34a** The automatic transaxle dipstick is located at the rear of the engine compartment.

voir. If too much fluid is added, remove the excess with a clean syringe or suction pump.

30 Check the power steering hoses and connections for leaks and wear.

### Automatic transaxle fluid

Refer to illustrations 4.34a and 4.34b

31 The level of the automatic transaxle fluid should be carefully maintained. Low fluid level can lead to slipping or loss of drive, while overfilling can cause foaming, loss of fluid and transaxle damage.

32 The transaxle fluid level should only be checked when the transaxle is hot (at its normal operating temperature). If the vehicle has just been driven over 10 miles (15 miles in a frigid climate), and the fluid temperature is 160 to 175-degrees F, the transaxle is hot.

**Caution:** If the vehicle has just been driven for a long time at high speed or in city traffic in hot weather, or if it has been pulling a trailer, an accurate fluid level reading cannot be obtained. Allow the fluid to cool down for about 30 minutes.


33 If the vehicle has not just been driven, park the vehicle on level ground, set the parking brake and start the engine. While the engine is idling, depress the brake pedal and move the selector lever through all the gear ranges, beginning and ending in Park.

34 With the engine still idling, remove the dipstick from its tube (see illustration). Check the level of the fluid on the dipstick (see illustration) and note its condition.

35 Wipe the fluid from the dipstick with a clean rag and reinsert it back into the filler tube until the cap seats.

36 Pull the dipstick out again and note the fluid level. The fluid level should be in the operating temperature range (the cross-hatched area). If the level is at the low side of either range, add the specified automatic transmission fluid through the dipstick tube with a funnel.

37 Add just enough of the recommended fluid to fill the transaxle to the proper level. It takes about one pint to raise the level from the low mark to the high mark when the fluid is hot, so add the fluid a little at a time and



**4.34b** At operating temperature, the automatic transaxle fluid level should be kept in the cross-hatched area of the dipstick

keep checking the level until it is correct.


38 The condition of the fluid should also be checked along with the level. If the fluid at the end of the dipstick is black or a dark reddish brown color, or if it emits a burned smell, the fluid should be changed (see Section 25). If you are in doubt about the condition of the fluid, purchase some new fluid and compare the two for color and smell.

## 5 Tire and tire pressure checks (every 250 miles or weekly)

Refer to illustrations 5.2, 5.3, 5.4a, 5.4b and 5.8

1 Periodic inspection of the tires may spare you the inconvenience of being stranded with a flat tire. It can also provide you with vital information regarding possible problems in the steering and suspension systems before major damage occurs.


2 The original tires on this vehicle are equipped with 1/2-inch wide bands that will appear when tread depth reaches 1/16-inch, at which point they can be considered worn



**5.2** A tire tread depth indicator should be used to monitor tire wear - they are available at auto parts stores and service stations and cost very little

out. Tread wear can be monitored with a simple, inexpensive device known as a tread depth indicator (see illustration).

3 Note any abnormal tread wear (see illustration). Tread pattern irregularities such



**UNDERINFLATION**




**CUPPING**

Cupping may be caused by:


- Underinflation and/or mechanical irregularities such as out-of-balance condition of wheel and/or tire, and bent or damaged wheel.
- Loose or worn steering tie-rod or steering idler arm.
- Loose, damaged or worn front suspension parts.



**INCORRECT TOE-IN OR EXTREME CAMBER**




**OVERINFLATION**




**FEATHERING DUE TO MISALIGNMENT**

**5.3** This chart will help you determine the condition of your tires, the probable cause(s) of abnormal wear and the corrective action necessary






**5.4a** If a tire loses air on a steady basis, check the valve core first to make sure it's snug (special inexpensive wrenches are commonly available at auto parts stores)



**5.4b** If the valve core is tight, raise the corner of the vehicle with the low tire and spray a soapy water solution onto the tread as the tire is turned slowly - slow leaks will cause small bubbles to appear



**5.8** To extend the life of your tires, check the air pressure at least once a week with an accurate gauge (don't forget the spare!)

as cupping, flat spots and more wear on one side than the other are indications of front end alignment and/or balance problems. If any of these conditions are noted, take the vehicle to a tire shop or service station to correct the problem.

4 Look closely for cuts, punctures and embedded nails or tacks. Sometimes a tire will hold air pressure for a short time or leak down very slowly after a nail has embedded itself in the tread. If a slow leak persists, check the valve stem core to make sure it is tight (see illustration). Examine the tread for an object that may have embedded itself in the tire or for a "plug" that may have begun to leak (radial tire punctures are repaired with a plug that is installed in a puncture). If a puncture is suspected, it can be easily verified by spraying a solution of soapy water onto the puncture area (see illustration). The soapy solution will bubble if there is a leak. Unless the puncture is unusually large, a tire shop or service station can usually repair the tire.

5 Carefully inspect the inner sidewall of each tire for evidence of brake fluid leakage. If you see any, inspect the brakes immediately.

6 Correct air pressure adds miles to the life span of the tires, improves mileage and enhances overall ride quality. Tire pressure cannot be accurately estimated by looking at a tire, especially if it's a radial. A tire pressure gauge is essential. Keep an accurate gauge in the glove compartment. The pressure gauges attached to the nozzles of air hoses at gas stations are often inaccurate.

7 Always check tire pressure when the tires are cold. Cold, in this case, means the vehicle has not been driven over a mile in the three hours preceding a tire pressure check. A pressure rise of four to eight pounds is not uncommon once the tires are warm.

8 Unscrew the valve cap protruding from the wheel or hubcap and push the gauge firmly onto the valve stem (see illustration). Note the reading on the gauge and compare the figure to the recommended tire pressure shown on the tire placard on the driver's side

door. Be sure to reinstall the valve cap to keep dirt and moisture out of the valve stem mechanism. Check all four tires and, if necessary, add enough air to bring them up to the recommended pressure.

9 Don't forget to keep the spare tire inflated to the specified pressure (refer to the pressure molded into the tire sidewall).

## 6 Engine oil and filter change (every 3000 miles or 3 months)

Refer to illustrations 6.2, 6.7, 6.12 and 6.15


1 Frequent oil changes are the most important preventive maintenance procedures that can be done by the home mechanic. As engine oil ages, it becomes diluted and contaminated, which leads to premature engine wear.

2 Make sure that you have all the necessary tools before you begin this procedure (see illustration). You should also have plenty of rags or newspapers handy for mopping up oil spills.

3 Access to the oil drain plug and filter will be improved if the vehicle can be lifted on a hoist, driven onto ramps or supported by jackstands. **Warning:** Do not work under a vehicle supported only by a jack - always use jackstands!


4 If you haven't changed the oil on this vehicle before, get under it and locate the oil drain plug and the oil filter. The exhaust components will be warm as you work, so note how they are routed to avoid touching them when you are under the vehicle.

5 Start the engine and allow it to reach normal operating temperature - oil and sludge will flow out more easily when warm. If new oil, a filter or tools are needed, use the vehicle to go get them and warm up the engine/oil at the same time. Park on a level surface and shut off the engine when it's warmed up. Remove the oil filler cap from the valve cover.




**6.2** These tools are required when changing the engine oil and filter

- 1 **Drain pan** - It should be fairly shallow in depth, but wide in order to prevent spills
- 2 **Rubber gloves** - When removing the drain plug and filter, it is inevitable that you will get oil on your hands (the gloves will prevent burns)
- 3 **Breaker bar** - Sometimes the oil drain plug is pretty tight and a long breaker bar is needed to loosen it
- 4 **Socket** - To be used with the breaker bar or a ratchet (must be the correct size to fit the drain plug)
- 5 **Filter wrench** - This is a metal band-type wrench, which requires clearance around the filter to be effective
- 6 **Filter wrench** - This type fits on the bottom of the filter and can be turned with a ratchet or breaker bar (different size wrenches are available for different types of filters)



**6.7** Use a proper size box-end wrench or socket to remove the oil drain plug and avoid rounding it off



**6.12** Use an oil filter wrench to remove the filter (V6 engine shown)



**6.15** Lubricate the oil filter gasket with clean engine oil before installing the filter on the engine

6 Raise the vehicle and support it on jackstands. Make sure it is safely supported!

7 Being careful not to touch the hot exhaust components, position a drain pan under the plug in the bottom of the engine, then remove the plug (see illustration). It's a good idea to wear a rubber glove while unscrewing the plug the final few turns to avoid being scalded by hot oil.

8 It may be necessary to move the drain pan slightly as oil flow slows to a trickle. Inspect the old oil for the presence of metal particles.

9 After all the oil has drained, wipe off the drain plug with a clean rag. Any small metal particles clinging to the plug would immediately contaminate the new oil.

10 Clean the area around the drain plug opening, reinstall the plug and tighten it securely, but don't strip the threads.

11 Move the drain pan into position under the oil filter.

12 Loosen the oil filter by turning it counter-clockwise with a filter wrench (see illustration). Any standard filter wrench will work.

13 Once the filter is loose, use your hands to unscrew it from the block. Just as the filter is detached from the block, immediately tilt the open end up to prevent the oil inside the filter from spilling out.

14 Using a clean rag, wipe off the mounting surface on the block. Also, make sure that none of the old gasket remains stuck to the mounting surface. It can be removed with a scraper if necessary.

15 Compare the old filter with the new one to make sure they are the same type. Smear some engine oil on the rubber gasket of the new filter and screw it into place (see illustration). Overtightening the filter will damage the gasket, so don't use a filter wrench. Most filter manufacturers recommend tightening the filter by hand only. Normally they should be tightened 3/4-turn after the gasket contacts the block, but be sure to follow the directions on the filter or container.

16 Remove all tools and materials from under the vehicle, being careful not to spill the

oil in the drain pan, then lower the vehicle.

17 Add new oil to the engine through the oil filler cap. Use a funnel to prevent oil from spilling onto the top of the engine. Pour four quarts of fresh oil into the engine. Wait a few minutes to allow the oil to drain into the pan, then check the level on the dipstick (see Section 4 if necessary). If the oil level is in the OK range, install the filler cap.

18 Start the engine and run it for about a minute. While the engine is running, look under the vehicle and check for leaks at the oil pan drain plug and around the oil filter. If either one is leaking, stop the engine and tighten the plug or filter slightly.

19 Wait a few minutes, then recheck the level on the dipstick. Add oil as necessary to bring the level into the OK range.

20 During the first few trips after an oil change, make it a point to check frequently for leaks and proper oil level.

21 The old oil drained from the engine cannot be reused in its present state and should be disposed of. Check with your local auto parts store, disposal facility or environmental agency to see if they will accept the oil for recycling. After the oil has cooled it can be drained into a container (capped plastic jugs, topped bottles, milk cartons, etc.) for transport to one of these disposal sites. Don't dispose

of the oil by pouring it on the ground or down a drain!

## 7 Windshield wiper blade inspection and replacement (every 7500 miles or 6 months)

Refer to illustrations 7.4a and 7.4b


1 The windshield wiper and blade assembly should be inspected periodically for damage, loose components and cracked or worn blade elements.

2 Road film can build up on the wiper blades and affect their efficiency, so they should be washed regularly with a mild detergent solution.


3 If the wiper blade elements are cracked, worn or warped, or no longer clean adequately, they should be replaced with new ones.

4 Lift the arm assembly away from the glass for clearance, press on the release lever, then slide the wiper blade assembly out of the hook in the end of the arm (see illustrations).

5 Attach the new wiper to the arm. Connection can be confirmed by an audible click.




**7.4a** To release the blade holder, push the release pin ...



**7.4b** ... and pull the wiper blade in the direction of the arrow to separate it from the arm






**8.1 Tools and materials required for battery maintenance**

- 1 **Face shield/safety goggles** - When removing corrosion with a brush, the acidic particles can easily fly up into your eyes
- 2 **Baking soda** - A solution of baking soda and water can be used to neutralize corrosion
- 3 **Petroleum jelly** - A layer of this on the battery posts will help prevent corrosion
- 4 **Battery post/cable cleaner** - This wire brush cleaning tool will remove all traces of corrosion from the battery posts and cable clamps
- 5 **Treated felt washers** - Placing one of these on each post, directly under the cable clamps, will help prevent corrosion
- 6 **Puller** - Sometimes the cable clamps are very difficult to pull off the posts, even after the nut/bolt has been completely loosened. This tool pulls the clamp straight up and off the post without damage
- 7 **Battery post/cable cleaner** - Here is another cleaning tool which is a slightly different version of number 4 above, but it does the same thing
- 8 **Rubber gloves** - Another safety item to consider when servicing the battery; remember that's acid inside the battery


## 8 Battery check, maintenance and charging (every 7500 miles or 6 months)

Refer to illustrations 8.1, 8.6a, 8.6b, 8.7a, 8.7b and 8.8

**Warning:** Certain precautions must be followed when checking and servicing the battery. Hydrogen gas, which is highly flammable, is always present in the battery cells, so keep lighted tobacco and all other open flames and sparks away from the battery. The electrolyte inside the battery is actually diluted



**8.6a Battery terminal corrosion usually appears as light, fluffy powder**



**8.7a When cleaning the cable clamps, all corrosion must be removed (the inside of the clamp is tapered to match the taper on the post, so don't remove too much material)**


sulfuric acid, which will cause injury if splashed on your skin or in your eyes. It will also ruin clothes and painted surfaces. When removing the battery cables, always detach the negative cable first and hook it up last!

1 A routine preventive maintenance program for the battery in your vehicle is the only way to ensure quick and reliable starts. But before performing any battery maintenance, make sure that you have the proper equipment necessary to work safely around the battery (see illustration).


2 There are also several precautions that should be taken whenever battery maintenance is performed. Before servicing the battery, always turn the engine and all accessories off and disconnect the cables from the negative terminal of the battery (see Chapter 5).

3 The battery produces hydrogen gas, which is both flammable and explosive. Never create a spark, smoke or light a match around the battery. Always charge the battery in a ventilated area.

4 Electrolyte contains poisonous and corrosive sulfuric acid. Do not allow it to get in your eyes, on your skin or on your clothes. Never



**8.6b Removing a cable from the battery post with a wrench - sometimes a pair of special battery pliers are required for this procedure if corrosion has caused deterioration of the nut hex (always remove the ground (-) cable first and hook it up last!)**



**8.7b Regardless of the type of tool used to clean the battery posts, a clean, shiny surface should be the result**


ingest it. Wear protective safety glasses when working near the battery. Keep children away from the battery.

5 Note the external condition of the battery. If the positive terminal and cable clamp on your vehicle's battery is equipped with a rubber protector, make sure that it's not torn or damaged. It should completely cover the terminal. Look for any corroded or loose connections, cracks in the case or cover or loose hold-down clamps. Also check the entire length of each cable for cracks and frayed conductors.

6 If corrosion, which looks like white, fluffy deposits (see illustration) is evident, particularly around the terminals, the battery should be removed for cleaning. Loosen the cable clamp bolts with a wrench, being careful to remove the ground cable first, and slide them off the terminals (see illustration). Then disconnect the hold-down clamp bolt and nut, remove the clamp and lift the battery from the engine compartment.

7 Clean the cable clamps thoroughly with a battery brush or a terminal cleaner and a





**8.8 Make sure the battery hold-down fasteners are tight**

solution of warm water and baking soda (see illustration). Wash the terminals and the top of the battery case with the same solution but make sure that the solution doesn't get into the battery. When cleaning the cables, terminals and battery top, wear safety goggles and rubber gloves to prevent any solution from coming in contact with your eyes or hands. Wear old clothes too - even diluted, sulfuric acid splashed onto clothes will burn holes in them. If the terminals have been extensively corroded, clean them up with a terminal cleaner (see illustration). Thoroughly wash all cleaned areas with plain water.

8 Make sure that the battery tray is in good condition and the hold-down clamp fasteners are tight (see illustration). If the battery is removed from the tray, make sure no parts remain in the bottom of the tray when the battery is reinstalled. When reinstalling the hold-down clamp bolts, do not overtighten them.

9 Information on removing and installing the battery can be found in Chapter 5. If you disconnected the cable(s) from the negative and/or positive battery terminals, the powertrain control module (PCM) must relearn its idle and fuel trim strategy for optimum driveability and performance (see Chapter 5, Section 1 for this procedure). Information on jump starting can be found at the front of this manual. For more detailed battery checking procedures, refer to the *Haynes Automotive Electrical Manual*.

## Cleaning

10 Corrosion on the hold-down components, battery case and surrounding areas can be removed with a solution of water and baking soda. Thoroughly rinse all cleaned areas with plain water.

11 Any metal parts of the vehicle damaged by corrosion should be covered with a zinc-based primer, then painted.

## Charging

**Warning:** When batteries are being charged, hydrogen gas, which is very explosive and flammable, is produced. Do not smoke or allow open flames near a charging or a


**Check for a chafed area that could fail prematurely.**



**Check for a soft area indicating the hose has deteriorated inside.**



**Overtightening the clamp on a hardened hose will damage the hose and cause a leak.**



**Check each hose for swelling and oil-soaked ends. Cracks and breaks can be located by squeezing the hose**



**9.4 Hoses, like drivebelts, have a habit of failing at the worst possible time - to prevent the inconvenience of a blown radiator or heater hose, inspect them carefully as shown here**

recently charged battery. Wear eye protection when near the battery during charging. Also, make sure the charger is unplugged before connecting or disconnecting the battery from the charger.

12 Slow-rate charging is the best way to restore a battery that's discharged to the point where it will not start the engine. It's also a good way to maintain the battery charge in a vehicle that's only driven a few miles between starts. Maintaining the battery charge is particularly important in the winter when the battery must work harder to start the engine and electrical accessories that drain the battery are in greater use.

13 It's best to use a one or two-amp battery charger (sometimes called a "trickle" charger). They are the safest and put the least strain on the battery. They are also the least expensive. For a faster charge, you can use a higher amperage charger, but don't use one rated more than 1/10th the amp/hour rating of the battery. Rapid boost charges that claim to restore the power of the battery in one to two hours are hardest on the battery and can damage batteries not in good condition. This type of charging should only be used in emergency situations.

14 The average time necessary to charge a battery should be listed in the instructions that come with the charger. As a general rule, a trickle charger will charge a battery in 12 to 16 hours.

## 9 Cooling system check (every 7,500 miles or 6 months)

Refer to illustration 9.4

1 Many major engine failures can be caused by a faulty cooling system.

2 The engine must be cold for the cooling system check, so perform the following procedure before the vehicle is driven for the day or after it has been shut off for at least three hours.


3 Remove the pressure-relief cap from the expansion tank at the right side of the engine compartment. Clean the cap thoroughly, inside and out, with clean water. The presence of rust or corrosion in the expansion tank means the coolant should be changed (see Section 22). The coolant inside the expansion tank should be relatively clean and transparent. If it's rust colored, drain the system and refill it with new coolant.

4 Carefully check the radiator hoses and the smaller diameter heater hoses (see illustrations in Chapter 3). Inspect each coolant hose along its entire length, replacing any hose which is cracked, swollen or deteriorated (see illustration). Cracks will show up better if the hose is squeezed. Pay close attention to hose clamps that secure the hoses to cooling system components. Hose clamps can pinch and puncture hoses, resulting in coolant leaks.

5 Make sure that all hose connections are tight. A leak in the cooling system will usually show up as white or rust colored deposits on the area adjoining the leak. If wire-type clamps are used on the hoses, it may be a good idea to replace them with screw-type clamps.

6 Clean the front of the radiator and air conditioning condenser with compressed air, if available, or a soft brush. Remove all bugs, leaves, etc. embedded in the radiator fins. Be extremely careful not to damage the cooling fins or cut your fingers on them.

7 If the coolant level has been dropping consistently and no leaks are detectable, have the expansion tank cap and cooling system pressure checked at a service station.



10.2a Four-tire rotation pattern

### 10 Tire rotation (every 7,500 miles or 6 months)

Refer to illustrations 10.2a and 10.2b

1 The tires should be rotated at the specified intervals and whenever uneven wear is noticed. Since the vehicle will be raised and the tires removed anyway, check the brakes also (see Section 13).

2 Radial tires must be rotated in a specific pattern (see illustrations). If your vehicle has a compact spare tire, don't include it in the rotation pattern.

3 Refer to the information in *Jacking and towing* at the front of this manual for the proper procedure to follow when raising the vehicle and changing a tire. If the brakes must be checked, don't apply the parking brake as stated.

4 The vehicle must be raised on a hoist or supported on jackstands to get all four wheels off the ground. Make sure the vehicle is safely supported!

5 After the rotation procedure is finished, check and adjust the tire pressures as necessary and be sure to check the lug nut tightness.


### 11 Seat belt check (every 7,500 miles or 6 months)

1 Check seat belts, buckles, latch plates and guide loops for obvious damage and signs of wear.

2 See if the seat belt reminder light comes on when the key is turned to the Run or Start position. A chime should also sound.

3 The seat belts are designed to lock up during a sudden stop or impact, yet allow free movement during normal driving. Make sure the retractors return the belt against your chest while driving and rewind the belt fully when the buckle is unlatched.

4 If any of the above checks reveal problems with the seat belt system, replace parts as necessary.



10.2b Five tire rotation pattern

### 12 Underhood hose check and replacement (every 15,000 miles or 12 months)

**Warning:** Replacement of air conditioning hoses must be left to a dealer service department or air conditioning shop that has the equipment to depressurize the system safely. Never remove air conditioning components or hoses until the system has been depressurized.

#### General

1 High temperatures under the hood can cause deterioration of the rubber and plastic hoses used for engine, accessory and emission systems operation. Periodic inspection should be made for cracks, loose clamps, material hardening and leaks.

2 Information specific to the cooling system hoses can be found in Section 9.

3 Most (but not all) hoses are secured to the fittings with clamps. Where clamps are used, check to be sure they haven't lost their tension, allowing the hose to leak. If clamps aren't used, make sure the hose has not expanded and/or hardened where it slips over the fitting, allowing it to leak.

#### PCV system hose

4 To reduce hydrocarbon emissions, crankcase blow-by gas is vented through the PCV valve in the rocker arm cover to the intake manifold via a rubber hose on most models. The blow-by gases mix with incoming air in the intake manifold before being burned in the combustion chambers.

5 Check the PCV hose for cracks, leaks and other damage. Disconnect it from the valve cover and the intake manifold and check the inside for obstructions. If it's clogged, clean it out with solvent.

#### Vacuum hoses

6 It's quite common for vacuum hoses, especially those in the emissions system, to be color coded or identified by colored stripes molded into them. Various systems require hoses with different wall thickness, collapse resistance and temperature resistance. When replacing hoses, be sure the new ones are made of the same material.

7 Often the only effective way to check a hose is to remove it completely from the vehicle. If more than one hose is removed, be sure to label the hoses and fittings to ensure correct installation.

8 When checking vacuum hoses, be sure to include any plastic T-fittings in the check. Inspect the fittings for cracks and the hose where it fits over each fitting for distortion, which could cause leakage.

9 A small piece of vacuum hose (1/4-inch inside diameter) can be used as a stethoscope to detect vacuum leaks. Hold one end of the hose to your ear and probe around vacuum hoses and fittings, listening for the "hissing" sound characteristic of a vacuum leak.

**Warning:** When probing with the vacuum hose stethoscope, be careful not to come into contact with moving engine components such as drivebelts, the cooling fan, etc.

#### Fuel hose

**Warning:** Gasoline is flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where a gas-type appliance (such as a water heater or clothes dryer) is present. Since fuel is carcinogenic, wear latex gloves when there's a possibility of being exposed to fuel, and, if you spill any fuel on your skin, rinse it off immediately with soap and water. Mop up any spills immediately and do not store fuel-soaked rags where they could ignite. The fuel system is under constant pressure, so, if any fuel lines are to be disconnected, the fuel pressure in the system must be relieved first (see Chapter 4 for more information). When you perform any kind of work on the fuel system, wear safety glasses and have a Class B type fire extinguisher on hand.


10 The fuel lines are usually under pressure, so if any fuel lines are to be disconnected be prepared to catch spilled fuel.

**Warning:** Your vehicle is equipped with fuel injection and you must relieve the fuel system pressure before servicing the fuel lines. Refer to Chapter 4 for the fuel system pressure relief procedure.

11 Check all flexible fuel lines for deterioration and chafing. Check especially for cracks in areas where the hose bends and just before fittings, such as where a hose attaches to the fuel pump, fuel filter and fuel injection unit.

12 When replacing a hose, use only hose that is specifically designed for your fuel injection system.





**13.5** You will find an inspection hole like this in each caliper through which you can view the thickness of remaining friction material for the inner pad

13 Spring-type clamps are sometimes used on fuel return or vapor lines. These clamps often lose their tension over a period of time, and can be "sprung" during removal. Replace all spring-type clamps with screw clamps whenever a hose is replaced. Some fuel lines use spring-lock type couplings, which require a special tool to disconnect. See Chapter 4 for more information on this type of coupling.

### Metal lines

14 Sections of metal line are often used for fuel line between the fuel pump and the fuel injection unit. Check carefully to make sure the line isn't bent, crimped or cracked.


15 If a section of metal fuel line must be replaced, use seamless steel tubing only, since copper and aluminum tubing do not have the strength necessary to withstand vibration caused by the engine.

16 Check the metal brake lines where they enter the master cylinder and brake proportioning unit (if used) for cracks in the lines and loose fittings. Any sign of brake fluid leakage calls for an immediate thorough inspection of the brake system.

### 13 Brake check (every 15,000 miles or 12 months)

**Warning:** Dust created by the brake system is harmful to your health. Never blow it out with compressed air and don't inhale any of it. An approved filtering mask should be worn when working on brakes. Do not, under any circumstances, use petroleum-based solvents to clean brake parts. Use brake system cleaner only!

1 The brakes should be inspected every time the wheels are removed or whenever a defect is suspected. Indications of a potential brake system problem include the vehicle pulling to one side when the brake pedal is depressed, noises coming from the brakes when they are applied, excessive brake pedal travel, a pulsating pedal and leakage of fluid,



**13.14** If the lining is bonded to the brake shoe, measure the lining thickness from the outer surface to the metal shoe, as shown here; if the lining is riveted to the shoe, measure from the lining outer surface to the rivet head

usually seen on the inside of the tire or wheel.

**Note:** It is normal for a vehicle equipped with an Anti-lock Brake System (ABS) to exhibit brake pedal pulsations during severe braking conditions.

### Disc brakes

Refer to illustration 13.5

2 Disc brakes can be visually checked without removing any parts except the wheels. Remove the hub caps (if applicable) and loosen the wheel lug nuts a quarter turn each.

3 Raise the vehicle and place it securely on jackstands. **Warning:** Never work under a vehicle that is supported only by a jack!

4 Remove the wheels. Now visible is the disc brake caliper which contains the pads. There is an outer brake pad and an inner pad. Both must be checked for wear. **Note:** Usually the inner pad wears faster than the outer pad.

5 Measure the thickness of the outer pad at each end of the caliper and the inner pad through the inspection hole in the caliper body (see illustration). Compare the measurement with the limit given in this Chapter's Specifications; if any brake pad thickness is less than specified, then all brake pads must be replaced (see Chapter 9).

6 If you're in doubt as to the exact pad thickness or quality, remove them for measurement and further inspection (see Chapter 9).

7 Check the disc for score marks, wear and burned spots. If any of these conditions exist, the disc should be removed for servicing or replacement (see Chapter 9).

8 Before installing the wheels, check all the brake lines and hoses for damage, wear, deformation, cracks, corrosion, leakage, bends and twists, particularly in the vicinity of the rubber hoses and calipers.

9 Install the wheels, lower the vehicle and tighten the wheel lug nuts to the torque given in this Chapter's Specifications.

### Drum brakes

Refer to illustrations 13.14 and 13.17

10 Remove the hub caps (if applicable) and loosen the wheel lug nuts a quarter turn each.



**13.17** Carefully peel back the wheel cylinder boot and check for leaking fluid indicating that the cylinder must be replaced or rebuilt

11 Raise the rear of the vehicle and support it securely on jackstands. **Warning:** Never work under a vehicle that is supported only by a jack! Block the front wheels to prevent the vehicle from rolling, however, do not apply the parking brake or it will lock the drums in place. Remove the rear wheels.

12 Remove the brake drum as described in Chapter 9.


13 With the drum removed, carefully clean off any accumulations of dirt and dust using brake system cleaner. **Warning:** DO NOT blow the dust out with compressed air and don't inhale any of it.

14 Measure the thickness of the lining material on both leading and trailing brake shoes (see illustration). Compare the measurement with the limit given in this Chapter's Specifications; if any brake shoe thickness is less than specified, then all brake shoes must be replaced (see Chapter 9).


15 Inspect the brake shoes for uneven wear patterns, cracks, glazing and delamination and replace if necessary. If the shoes have been saturated with brake fluid, oil or grease, this also necessitates replacement (see Chapter 9).

16 Make sure all the brake assembly springs






**14.4** Check the shocks for leakage at the indicated area



**14.10** To check a balljoint for wear, try to pry the control arm up and down to make sure there is no play in the balljoint (if there is, replace it)



**14.11** Check the balljoint boot for damage also

are connected and in good condition.

17 Check the brake wheel cylinder for signs of fluid leakage. Carefully pry back the rubber dust boots on the wheel cylinder (**see illustration**). Any leakage here is an indication that the wheel cylinders must be overhauled immediately (see Chapter 9). Also, check all hoses and connections for signs of leakage.

18 Clean the inside of the drum with brake system cleaner. Again, be careful not to breathe the dust.

19 Inspect the inside of the drum for cracks, score marks, deep scratches and "hard spots" which will appear as small discolored areas. If imperfections cannot be removed with fine emery cloth, the drum must be taken to an automotive machine shop for resurfacing.

20 Repeat the procedure for the remaining wheel.

21 Install the wheels, lower the vehicle and tighten the wheel lug nuts to the torque given in this Chapter's Specifications.

### Parking brake

22 Slowly pull up on the parking brake and count the number of clicks you hear until the handle is up as far as it will go. The adjustment is correct if you hear the specified number of clicks (see this Chapter's Specifications). If you hear more or fewer clicks, it's time to adjust the parking brake (see Chapter 9).

23 An alternative method of checking the parking brake is to park the vehicle on a steep hill with the engine running (so you can apply the brakes if necessary) with the parking brake set and the transaxle in Neutral. If the parking brake cannot prevent the vehicle from rolling, it needs adjustment (see Chapter 9).

## 14 Steering and suspension check (every 15,000 miles or 12 months)

Refer to illustrations 14.4, 14.10 and 14.11

**Note:** For detailed illustrations of the steering and suspension components, refer to Chapter 10.

### With the wheels on the ground

1 With the vehicle stopped and the front wheels pointed straight ahead, rock the steering wheel gently back and forth. If freeplay is excessive, a front wheel bearing, steering shaft universal joint or lower arm balljoint is worn or the steering gear is out of adjustment or broken. Refer to Chapter 10 for the appropriate repair procedure.

2 Other symptoms, such as excessive vehicle body movement over rough roads, swaying (leaning) around corners and binding as the steering wheel is turned, may indicate faulty steering and/or suspension components.

3 Check the shock absorbers by pushing down and releasing the vehicle several times at each corner. If the vehicle does not come back to a level position within one or two bounces, the shocks/struts are worn and must be replaced. When bouncing the vehicle up and down, listen for squeaks and noises from the suspension components.

4 Check the shock absorbers for evidence of fluid leakage (**see illustration**). A light film of fluid is no cause for concern. Make sure that any fluid noted is from the shocks and not from some other source. If leakage is noted, replace the shocks as a set.

5 Check the shocks to be sure they are securely mounted and undamaged. Check the upper mounts for damage and wear. If damage or wear is noted, replace the shocks as a set (front and rear).

6 If the shocks must be replaced, refer to Chapter 10 for the procedure.

### Under the vehicle

7 Raise the vehicle with a floor jack and support it securely on jackstands. See *Jacking and towing* at the front of this book for the proper jacking points.

8 Check the tires for irregular wear patterns and proper inflation. See Section 5 in this Chapter for information regarding tire wear and Chapter 10 for information on wheel

bearing replacement.

9 Inspect the universal joint between the steering shaft and the steering gear housing. Check the steering gear housing for lubricant leakage. Make sure that the dust seals and boots are not damaged and that the boot clamps are not loose. Check the steering linkage for looseness or damage. Check the tie-rod ends for excessive play. Look for loose bolts, broken or disconnected parts and deteriorated rubber bushings on all suspension and steering components. While an assistant turns the steering wheel from side to side, check the steering components for free movement, chafing and binding. If the steering components do not seem to be reacting with the movement of the steering wheel, try to determine where the slack is located.


10 Check the balljoints for wear by trying to move each control arm up and down with a pry bar (**see illustration**) to ensure that its balljoint has no play. If any balljoint does have play, replace it. See Chapter 10 for the ball-joint replacement procedure.

11 Inspect the balljoint boots for damage and leaking grease (**see illustration**). Replace the balljoints with new ones if they are damaged (see Chapter 10).


12 At the rear of the vehicle, inspect the suspension arm bushings for deterioration. Additional information on suspension components can be found in Chapter 10.

## 15 Fuel system check (every 15,000 miles or 12 months)

**Warning:** Gasoline is flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where a gas-type appliance (such as a water heater or clothes dryer) is present. Since fuel is carcinogenic, wear latex gloves when there's a possibility of being exposed to fuel, and, if you spill any fuel on your skin, rinse it off immediately with soap and water. Mop up any spills immediately and



**17.2** Remove the check/fill plug and use your finger as a dipstick to check the transfer case lubricant level.



**18.1a** Loosen the intake hose clamp (A), then unlatch these clips (B) . . .

do not store fuel-soaked rags where they could ignite. When you perform any kind of work on the fuel system, wear safety glasses and have a Class B type fire extinguisher on hand. The fuel system is under constant pressure, so, before any lines are disconnected, the fuel system pressure must be relieved (see Chapter 4).

1 If you smell gasoline while driving or after the vehicle has been sitting in the sun, inspect the fuel system immediately.

2 Remove the fuel filler cap and inspect it for damage and corrosion. The gasket should have an unbroken sealing imprint. If the gasket is damaged or corroded, install a new cap.

3 Inspect the fuel feed line for cracks. Make sure that the connections between the fuel lines and the fuel injection system and between the fuel lines and the in-line fuel filter are tight. **Warning:** Your vehicle is fuel injected, so you must relieve the fuel system pressure before servicing fuel system components. The fuel system pressure relief procedure is outlined in Chapter 4.

4 Since some components of the fuel system - the fuel tank and part of the fuel feed line, for example - are underneath the vehicle, they can be inspected more easily with the vehicle raised on a hoist. If that's not possible, raise the vehicle and support it on jackstands.

5 With the vehicle raised and safely supported, inspect the gas tank and filler neck for punctures, cracks and other damage. The connection between the filler neck and the tank is particularly critical. Sometimes a rubber filler neck will leak because of loose clamps or deteriorated rubber. Inspect all fuel tank mounting brackets and straps to be sure that the tank is securely attached to the vehicle. **Warning:** Do not, under any circumstances, try to repair a fuel tank (except rubber components). A welding torch or any open flame can easily cause fuel vapors inside the tank to explode.

6 Carefully check all rubber hoses and metal lines leading away from the fuel tank. Check for loose connections, deteriorated hoses, crimped lines and other damage. Repair or replace damaged sections as necessary (see Chapter 4).

#### 16 Manual transaxle lubricant level check (every 15,000 miles or 12 months)

1 The manual transaxle does not have a dipstick. To check the fluid level, raise the vehicle and support it securely on jackstands. On the front side of the transaxle housing you will see a plug. Remove it. If the lubricant level is correct, it should be up to the lower edge of the hole.

2 If the transaxle needs more lubricant (if the level is not up to the hole), use a syringe or a gear oil pump to add more. Stop filling the transaxle when the lubricant begins to run out the hole.

3 Install the plug and tighten it securely. Drive the vehicle a short distance, then check for leaks.

#### 17 Transfer case lubricant level check (every 15,000 miles or 12 months)

Refer to illustration 17.2

1 Raise the vehicle and support it securely on jackstands.

2 Using a ratchet or breaker bar, unscrew the check/fill plug from the transfer case (see illustration).

3 Use your little finger to reach inside the housing to feel the lubricant level. The level should be at or near the bottom of the plug hole. If it isn't, add the recommended lubricant through the plug hole with a syringe or squeeze bottle.

4 Install and tighten the plug. Check for leaks after the first few miles of driving.

#### 18 Air filter check and replacement (every 15,000 miles or 12 months)

Refer to illustrations 18.1a and 18.1b

1 The air filter is located inside a housing



**18.1b** . . . pull the cover out of the way and lift the element out

at the left (driver's) side of the engine compartment. To remove the air filter, loosen the clamp securing the inlet tube to the air filter cover, release the clamps that secure the two halves of the air cleaner housing together, then separate the cover halves and remove the air filter element (see illustrations).


2 Inspect the outer surface of the filter element. If it is dirty, replace it. If it is only moderately dusty, it can be reused by blowing it clean from the back to the front surface with compressed air. Because it is a pleated paper type filter, it cannot be washed or oiled. If it cannot be cleaned satisfactorily with compressed air, discard and replace it. While the cover is off, be careful not to drop anything down into the housing. **Caution:** Never drive the vehicle with the air cleaner removed. Excessive engine wear could result and back-firing could even cause a fire under the hood.

3 Wipe out the inside of the air cleaner housing.

4 Place the new filter into the air cleaner housing, making sure it seats properly.

5 Installation of the housing is the reverse of removal.





**19.2** Flex the driveaxle boots by hand to check for cracks and/or leaking grease

### 19 Driveaxle boot check (every 15,000 miles or 12 months)

Refer to illustration 19.2


1 The driveaxle boots are very important because they prevent dirt, water and foreign material from entering and damaging the constant velocity (CV) joints. Oil and grease can cause the boot material to deteriorate prematurely, so it's a good idea to wash the boots with soap and water. Because it constantly pivots back and forth following the steering action of the front hub, the outer CV boot wears out sooner and should be inspected regularly.

2 Inspect the boots for tears and cracks as well as loose clamps (see illustration). If there is any evidence of cracks or leaking lubricant, they must be replaced as described in Chapter 8.

### 20 Exhaust system check (every 30,000 miles or 24 months)

Refer to illustration 20.2

1 With the engine cold (at least three hours



**20.2** Be sure to check each exhaust system rubber hanger for damage

after the vehicle has been driven), check the complete exhaust system from the engine to the end of the tailpipe. Ideally, the inspection should be done with the vehicle on a hoist to permit unrestricted access. If a hoist isn't available, raise the vehicle and support it securely on jackstands.

2 Check the exhaust pipes and connections for evidence of leaks, severe corrosion and damage. Make sure that all brackets and hangers are in good condition and tight (see illustration).

3 At the same time, inspect the underside of the body for holes, corrosion, open seams, etc. which may allow exhaust gases to enter the passenger compartment. Seal all body openings with silicone or body putty.

4 Rattles and other noises can often be traced to the exhaust system, especially the mounts and hangers. Try to move the pipes, muffler and catalytic converter. If the components can come in contact with the body or suspension parts, secure the exhaust system with new mounts.

5 Check the running condition of the engine by inspecting inside the end of the tailpipe. The exhaust deposits here are an indication of engine state-of-tune. If the pipe is

black and sooty or coated with white deposits, the engine may need a tune-up, including a thorough fuel system inspection and adjustment.

### 21 Fuel filter replacement (every 30,000 miles or 24 months)

Refer to illustrations 21.1 and 21.4

**Warning:** Gasoline is extremely flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where a gas-type appliance (such as a water heater or clothes dryer) is present. Since fuel is carcinogenic, wear latex gloves when there's a possibility of being exposed to fuel, and, if you spill any fuel on your skin, rinse it off immediately with soap and water. Mop up any spills immediately and do not store fuel-soaked rags where they could ignite. When you perform any kind of work on the fuel system, wear safety glasses and have a Class B type fire extinguisher on hand.

1 The fuel filter is mounted under the vehicle on the right side, in front of the gas tank (see illustration).


2 Relieve the fuel system pressure (see Chapter 4).

3 If necessary, raise the vehicle and support it securely on jackstands. Inspect the fittings at both ends of the filter to see if they're clean. If more than a light coating of dust is present, clean the fittings before proceeding.


4 Release the clips holding the fuel lines to the filter (see illustration).

5 Detach the fuel hoses, one at a time, from the filter. Be prepared for fuel spillage.

6 After the lines are detached, check the fittings for damage and distortion. If they were damaged in any way during removal, new ones must be used when the lines are reattached to the new filter (if new clips are packaged with the filter, be sure to use them in place of the originals).



**21.1** The fuel filter is located in front of the fuel tank



**21.4** Use a small screwdriver to pry off the fuel line fitting retaining clips at both ends of the filter

7 Remove the fuel filter from the mounting clamp, while noting the direction the fuel filter is installed.

8 Install the new filter in the same direction. Carefully push each hose onto the filter until it's seated against the collar on the fitting, then install the clips. Make sure the clips are securely attached to the hose fittings - if they come off, the hoses could back off the filter and a fire could result!

9 Start the engine and check for fuel leaks.

## 22 Cooling system servicing (draining, flushing and refilling) (every 30,000 miles or 24 months)

Refer to illustrations 22.4, 22.5 and 22.10

**Warning:** Do not allow antifreeze to come in contact with your skin or painted surfaces of the vehicle. Rinse off spills immediately with plenty of water. Antifreeze is highly toxic if ingested. Never leave antifreeze lying around in an open container or in puddles on the floor; children and pets are attracted by its sweet smell and may drink it. Check with local authorities about disposing of used antifreeze. Many communities have collection centers which will see that antifreeze is disposed of safely. Never dump used antifreeze on the ground or pour it into drains.

**Caution:** Do not mix coolants of different colors. Doing so might damage the cooling system and/or the engine. The manufacturer specifies either a green colored coolant or a yellow colored coolant to be used in these systems. Read the warning label in the engine compartment for additional information.

**Note:** Non-toxic antifreeze is now manufactured and available at local auto parts stores, but even this type must be disposed of properly.

1 Periodically, the cooling system should be drained, flushed and refilled to replenish the antifreeze mixture and prevent formation of rust and corrosion, which can impair the performance of the cooling system and cause engine damage. When the cooling system is serviced, all hoses and the expansion tank cap should be checked and replaced if necessary.

### Draining

2 Apply the parking brake and block the wheels. If the vehicle has just been driven, wait several hours to allow the engine to cool down before beginning this procedure.


3 Once the engine is completely cool, remove the expansion tank cap.

4 Move a large container under the radiator drain to catch the coolant. Attach a length of hose to the drain fitting to direct the coolant into the container, then open the drain fitting (a pair of pliers may be required to turn it) (see illustration).

5 After the coolant stops flowing out of the radiator, move the container under the engine block drain plug(s) and allow the coolant in the




22.4 The radiator drain fitting is located at the bottom of the radiator - before opening the valve, push a short length of rubber hose onto the plastic fitting to prevent the coolant from splashing



22.5 On the V6 engine, remove the engine block drain plugs from both sides of the engine

22.10 With the thermostat removed, disconnect the upper radiator hose and flush the radiator and engine block with a garden hose



block to drain (see illustration).

6 While the coolant is draining, check the condition of the radiator hoses, heater hoses and clamps (refer to Section 9 if necessary). Replace any damaged clamps or hoses.

7 Reinstall the block drain plugs and tighten them securely.

### Flushing

8 Once the system has completely drained, remove the thermostat housing from the engine (see Chapter 3), then reinstall the housing without the thermostat. This will allow the system to be thoroughly flushed.

9 Disconnect the upper hose from the radiator.

10 Place a garden hose in the upper radiator inlet and flush the system until the water runs clear at the upper radiator hose (see illustration).

11 Severe cases of radiator contamination or clogging will require removing the radiator (see Chapter 3) and reverse flushing it. This

involves inserting the hose in the bottom radiator outlet to allow the clean water to run against the normal flow, draining out through the top. A radiator repair shop should be consulted if further cleaning or repair is necessary.

12 When the coolant is regularly drained and the system refilled with the correct coolant mixture there should be no need to employ chemical cleaners or descalers.

### Refilling


13 Close and tighten the radiator drain.

14 Place the heater temperature control in the maximum heat position.


15 Slowly add new coolant (a 50/50 mixture of water and antifreeze) to the expansion tank until the level is at the COLD FULL mark on the expansion tank.

16 Leave the expansion tank cap off and run the engine in a well-ventilated area until the thermostat opens (coolant will begin flowing through the radiator and the upper radi-





24.2 Remove the lower splash shield to gain access to the drivebelt



24.4 Small cracks in the underside of a V-ribbed belt are acceptable - lengthwise cracks, or missing pieces that cause the belt to make noise, are cause for replacement

tor hose will become hot).

17 Turn the engine off and let it cool. Add more coolant mixture to bring the level to the COLD FULL mark on the expansion tank.

18 Squeeze the upper radiator hose to expel air, then add more coolant mixture if necessary. Replace the expansion tank cap.

19 Start the engine, allow it to reach normal operating temperature and check for leaks. Also, set the heater and blower controls to the maximum setting and check to see that the heater output from the air ducts is warm. This is a good indication that all air has been purged from the cooling system.

## 23 Brake fluid change (every 30,000 miles or 24 months)

**Warning:** Brake fluid can harm your eyes and damage painted surfaces, so use extreme caution when handling or pouring it. Do not use brake fluid that has been standing open or is more than one year old. Brake fluid absorbs moisture from the air. Excess moisture can cause a dangerous loss of braking effectiveness.

1 At the specified intervals, the brake fluid should be drained and replaced. Since the brake fluid may drip or splash when pouring it, place plenty of rags around the master cylinder to protect any surrounding painted surfaces.

2 Before beginning work, purchase the specified brake fluid (see *Recommended lubricants and fluids* at the beginning of this Chapter).

3 Remove the cap from the master cylinder reservoir.

4 Using a hand suction pump or similar device, withdraw the fluid from the master cylinder reservoir.

5 Add new fluid to the master cylinder until it rises to the base of the filler neck.

6 Bleed the brake system as described in

Chapter 9 at all four brakes until new and uncontaminated fluid is expelled from the bleeder screw. Be sure to maintain the fluid level in the master cylinder as you perform the bleeding process. If you allow the master cylinder to run dry, air will enter the system.

7 Refill the master cylinder with fluid and check the operation of the brakes. The pedal should feel solid when depressed, with no sponginess. **Warning:** Do not operate the vehicle if you are in doubt about the effectiveness of the brake system.

## 24 Drivebelt check and replacement (every 30,000 miles or 24 months)

### Accessory drivebelt

1 A single serpentine drivebelt is located at the front of the engine and plays an important role in the overall operation of the engine and its components. Due to its function and material make up, the belt is prone to wear and should be periodically inspected. The serpentine belt drives the alternator, power steering pump, water pump (four-cylinder models) and air conditioning compressor. Although the belt should be inspected at the recommended intervals, replacement may not be necessary for more than 100,000 miles.

### Check

Refer to illustrations 24.2 and 24.4

2 Since the drivebelt is located very close to the right-hand side of the engine compartment, it is possible to gain better access by raising the front of the vehicle and removing the right-hand wheel, then unbolting the lower splash shield from the underbody (see illustration). Be sure to support the front of the vehicle securely on jackstands.

3 With the engine stopped, inspect the full length of the drivebelt for cracks and separation of the belt plies. It will be necessary to turn the engine (using a wrench or socket and

bar on the crankshaft pulley bolt) in order to move the belt from the pulleys so that the belt can be inspected thoroughly. Twist the belt between the pulleys so that both sides can be viewed. Also check for fraying, and glazing which gives the belt a shiny appearance. Check the pulleys for nicks, cracks, distortion and corrosion.


4 Note that it is not unusual for a ribbed belt to exhibit small cracks in the edges of the belt ribs, and unless these are extensive or very deep, belt replacement is not essential (see illustration).

### Replacement


Refer to illustration 24.6

5 To remove the drivebelt, loosen the right front wheel lug nuts, then raise the front of the vehicle and support it on jackstands. Remove the right front wheel and remove the lower splash shield from the underbody.

6 Note how the drivebelt is routed, then remove the belt from the pulleys. If you're working on a four-cylinder engine, use a wrench on the tensioner center bolt and turn the tensioner clockwise to release the drive-



24.6 Rotate the tensioner arm to relieve belt tension



**24.10 Rotate the tensioner and remove the belt**

belt tension. If you're working on a V6 engine, insert a 3/8-inch drive ratchet or breaker bar into the tensioner hole and pull the handle clockwise to release the drivebelt tension (see illustration).

7 Fit the new drivebelt onto the crankshaft, alternator, power steering pump, and air conditioning compressor pulleys, as applicable, then turn the tensioner counterclockwise and locate the drivebelt on the pulley. Make sure that the drivebelt is correctly seated in all of the pulley grooves, then release the tensioner.

8 Install the lower splash shield and wheel, then lower the car to the ground. Tighten the lug nuts to the torque listed in this Chapter's Specifications.

## Water pump drivebelt (V6 engine)

### Replacement

Refer to illustration 24.10

9 The water pump drivebelt is located at the left end of the engine and is driven by a pulley attached to the end of the front cylinder bank intake camshaft. The belt and pulley are protected by a cover.

10 To replace the belt, remove the cover (see illustration 4.1 in Chapter 2, Part B), rotate the tensioner clockwise and remove the belt (see illustration). Slowly release the tensioner.

11 Route the new belt over the pulleys, again rotating the tensioner to allow the belt to be installed, then release the belt tensioner. Make sure the belt is positioned properly on the pulleys. Reinstall the cover and tighten the fasteners securely.


### Tensioner replacement

12 Remove the drivebelt as described previously.

### Accessory drivebelt tensioner

Refer to illustration 24.13

13 On four-cylinder models, remove the two bolts securing the tensioner to the engine



**24.13 On V6 models, remove the bolt securing the tensioner to the block**

block. On V6 models, remove the bolt in the center of the tensioner, then detach the tensioner from the engine (see illustration).


14 Installation is the reverse of removal. Be sure to tighten the tensioners bolt(s) to the torque listed in this Chapter's Specifications.

## Water pump drivebelt tensioner (V6 engine)

Refer to illustration 24.15

15 Unscrew the bolt securing the tensioner, then remove the tensioner (see illustration).

16 Installation is the reverse of removal. Be sure to tighten the tensioner bolts to the torque listed in this Chapter's Specifications.



**24.15 Remove the bolt securing the water pump drivebelt tensioner**

position, wrenches, drain pan capable of holding at least four quarts, newspapers and clean rags.

4 The fluid should be drained immediately after the vehicle has been driven. Hot fluid is more effective than cold fluid at removing built-up sediment. **Warning:** Fluid temperature can exceed 350-degrees F in a hot transaxle. Wear protective gloves.

5 After the vehicle has been driven, warm up the fluid, raise the front of the vehicle and support it securely on jackstands. **Warning:** Never work under a vehicle that is supported only by a jack! Remove the transaxle splash shield for access to the transaxle drain plug.

6 Place the drain pan under the drain plug in the transaxle pan and remove the drain plug (see illustration). Be sure the drain pan is in position, as fluid will come out with some force. Once the fluid is drained, reinstall the drain plug securely. Measure the amount of fluid drained and write down this figure for reference when refilling.

7 Lower the vehicle

8 With the engine off, add new fluid to the transaxle through the dipstick tube (see Recommended lubricants and fluids for the recommended fluid type). Begin the refill procedure by initially adding 1/3 of the amount


## 25 Automatic transaxle fluid change (every 30,000 miles or 24 months)

Refer to illustration 25.6

1 The automatic transaxle fluid should be changed at the recommended intervals.


2 Before beginning work, purchase the specified transmission fluid (see Recommended lubricants and fluids at the front of this chapter).

3 Other tools necessary for this job include jackstands to support the vehicle in a raised



**25.6 Remove the transaxle drain plug**





27.4 Rear differential check/fill plug

drained. Then, with the engine running, add 1/2-pint at a time (cycling the shifter through each gear position between additions) until the level is correct on the dipstick.

9 Repeat Steps 5 through 8 once to flush any contaminated fluid from the torque converter.

10 Before final installation of the transaxle drain plug, apply Teflon tape to the threads.


## 26 Manual transaxle lubricant change (every 30,000 miles or 24 months)

- 1 Raise the vehicle and support it securely on jackstands.
- 2 Move a drain pan, rags, newspapers and wrenches under the transaxle.
- 3 Remove the transaxle fill plug on the front of the case and the drain plug at the bottom of the case, then allow the lubricant to drain into the pan.
- 4 After the lubricant has drained completely, reinstall the drain plug and tighten it securely.
- 5 Using a hand pump, syringe or funnel, fill the transaxle with the specified lubricant until it is level with the lower edge of the filler hole. Reinstall the fill plug and tighten it securely.
- 6 Lower the vehicle.
- 7 Drive the vehicle for a short distance, then check the drain and fill plugs for leakage.

## 27 Differential lubricant change (4WD models) (every 30,000 miles or 24 months)

### Drain

- 1 This procedure should be performed after the vehicle has been driven so the lubricant will be warm and therefore flow out of the differential more easily.
- 2 Raise the vehicle and support it securely on jackstands.



27.11 Apply a continuous thin bead of RTV sealant to the cover

- 3 The easiest way to drain the differential(s) is to remove the lubricant through the filler plug hole with a suction pump. If the differential cover gasket is leaking, it will be necessary to remove the cover to drain the lubricant (which will also allow you to inspect the differential).

### Changing the lubricant with a suction pump

Refer to illustration 27.4

- 4 Remove the filler plug from the differential (see illustration).
- 5 Insert the flexible hose.
- 6 Work the hose down to the bottom of the differential housing and pump the lubricant out.

### Changing the lubricant by removing the cover

Refer to illustration 27.11

- 7 Move a drain pan, rags, newspapers and wrenches under the vehicle.
- 8 Remove the bolts on the lower half of the cover. Loosen the bolts on the upper half and use them to loosely retain the cover. Allow the oil to drain into the pan, then completely

remove the cover.

9 Using a lint-free rag, clean the inside of the cover and the accessible areas of the differential housing. As this is done, check for chipped gears and metal particles in the lubricant, indicating that the differential should be more thoroughly inspected and/or repaired.

10 Thoroughly clean the gasket mating surfaces of the differential housing and the cover plate. Use a gasket scraper or putty knife to remove all traces of the old gasket.

11 Apply a thin bead of RTV sealant to the cover flange (see illustration). Make sure the bolt holes align properly then install the cover and tighten the fasteners to the torque listed in this Chapter's Specifications.

### Refill


12 Use a hand pump, syringe or funnel to fill the differential housing with the specified lubricant until it's level with the bottom of the filler plug hole.

13 Install the fill plug and tighten it securely.


## 28 Transfer case lubricant change (4WD models) (every 30,000 miles or 24 months)

Refer to illustrations 28.3a and 28.3b


- 1 Drive the vehicle for at least 15 minutes to warm the lubricant in the case. Perform this warm-up procedure with 4WD engaged, if possible.
- 2 Raise the vehicle and support it securely on jackstands.
- 3 Remove the check/fill plug, then the drain plug and allow the old lubricant to drain completely (see illustrations).
- 4 After the lubricant has drained completely, reinstall the plug and tighten it securely.
- 5 Fill the case with the specified lubricant until it is level with the lower edge of the filler hole.
- 6 Install the check/fill plug and tighten it securely.



28.3a First remove the transfer case check/fill plug ...



28.3b ... then remove the transfer case drain plug



### 30.2 Tools required for changing spark plugs

- 1 **Spark plug socket** - This will have special padding inside to protect the spark plug porcelain insulator
- 2 **Torque wrench** - Although not mandatory, use of this tool is the best way to ensure that the plugs are tightened properly
- 3 **Ratchet** - Standard hand tool to fit the plug socket
- 4 **Extension** - Depending on model and accessories, you may need special extensions and universal joints to reach one or more of the plugs
- 5 **Spark plug gap gauge** - This gauge for checking the gap comes in a variety of styles. Make sure the gap for your engine is included


7 Drive the vehicle for a short distance, then check the drain and fill plugs for leakage.

## 29 Positive Crankcase Ventilation (PCV) valve replacement (four-cylinder models) (every 60,000 miles or 48 months)

**Note 1:** For additional information on the PCV system, the PCV valve on V6 models and the oil separators on both engines, refer to Chapter 6.

**Note 2:** This Section applies to models with four-cylinder engines only.

- 1 The PCV valve is located in the valve cover.
- 2 Start the engine and allow it to idle, then disconnect the PCV valve from the valve cover and feel for vacuum at the end of the valve. If vacuum is felt, the PCV valve/system is working properly (see Chapter 6 for additional PCV system information).
- 3 If no vacuum is felt, remove the valve and check for vacuum at the hose. If vacuum is present at the hose but not at the valve, replace the valve. If no vacuum is felt at the hose, check for a plugged or cracked hose between the PCV valve and the intake plenum.
- 4 Check the rubber grommet in the valve cover for cracks and distortion. If it's damaged, replace it.
- 5 If the valve is clogged, the hose might



**30.5a** Spark plug manufacturers recommend using a tapered thickness gauge when checking the gap - slide the thin side into the gap and turn it until the gauge just fills the gap, then read the thickness on the gauge - do not force the tool into the gap or use the tapered portion to widen a gap

also be plugged. Remove the hose between the valve and the intake manifold and clean it with solvent.


6 After cleaning the hose, inspect it for damage, wear and deterioration. Make sure it fits snugly on the fittings.

7 If necessary, install a new PCV valve.


## 30 Spark plug check and replacement (see Maintenance schedule for service intervals)

Refer to illustrations 30.2, 30.5a, 30.5b, 30.7a, 30.7b, 30.7c, 30.7d, 30.9, 30.11a and 30.11b

- 1 On these vehicles the spark plugs are located at the top of the engine.
- 2 In most cases, the tools necessary for spark plug replacement include a spark plug socket which fits onto a ratchet (spark plug sockets are padded inside to prevent damage to the porcelain insulators on the new plugs), various extensions and a gap gauge to check and adjust the gaps on the new plugs (see illustration). A torque wrench should be used to tighten the new plugs.



**30.7a** V6 models are equipped with individual coils which must be removed to access the spark plugs




**30.5b** To change the gap, bend the side electrode only, using the adjuster hole in the tool, and be very careful not to crack or chip the porcelain insulator surrounding the center electrode

3 The best approach when replacing the spark plugs is to purchase the new ones in advance, adjust them to the proper gap and replace the plugs one at a time. When buying the new spark plugs, be sure to obtain the correct plug type for your particular engine. This information can be found in the Specifications Section at the beginning of this Chapter or in the factory owner's manual.

4 Allow the engine to cool completely before attempting to remove any of the plugs. These engines are equipped with aluminum cylinder heads, which can be damaged if the spark plugs are removed when the engine is hot. While you are waiting for the engine to cool, check the new plugs for defects and adjust the gaps.

5 The gap is checked by inserting the proper-thickness gauge between the electrodes at the tip of the plug (see illustration). The gap between the electrodes should be the same as the one specified on the Emissions Control Information label or in this Chapter's Specifications. The gauge should just slide between the electrodes with a slight amount of drag. If the gap is incorrect, use the adjuster on the gauge body to bend the curved side electrode slightly until the proper gap is obtained (see illustration). If the side electrode is not exactly over the center electrode, bend it with the adjuster until it is. Check for cracks in the porcelain






**30.7b** To remove the coils, disconnect the electrical connector . . .



**30.7c** . . . and remove the coil retaining screw . . .



**30.7d** . . . then pull straight up and out to remove the coil

insulator (if any are found, the plug should not be used). **Note:** We recommend using a tapered thickness gauge when checking platinum- or iridium-type spark plugs. Other types of gauges may scrape the thin coating from the electrodes, thus dramatically shortening the life of the plugs. However, if dual-electrode spark plugs are used, a wire-type gauge will have to be used.

6 On V6 engines, remove the engine cover and intake manifold (see Chapter 2 Part B).

7 Some engines are equipped with individual ignition coils which must be removed first to access the spark plugs (see illustrations). On other engines, remove the spark plug wire from one spark plug. Pull only on the boot at the end of the wire - do not pull on the wire. A plug wire removal tool should be used if available.


8 If compressed air is available, use it to blow any dirt or foreign material away from the spark plug hole. The idea here is to eliminate the possibility of debris falling into the cylinder as the spark plug is removed.

9 Place the spark plug socket over the plug and remove it from the engine by turning it in a counterclockwise direction (see illustration).


10 Compare the spark plug to those shown in the photos located on the inside back cover to get an indication of the general running condition of the engine.

11 Apply a small amount of anti-seize compound to the spark plug threads (see illustration). Install one of the new plugs into the hole until you can no longer turn it with your fingers, then tighten it with a torque wrench (if available) or the ratchet. It is a good idea to slip a short length of rubber hose over the end of the plug to use as a tool to thread it into place (see illustration). The hose will grip the plug well enough to turn it, but will start to slip if the plug begins to cross-thread in the hole - this will prevent damaged threads and the accompanying repair costs.


12 On V6 engines, before pushing the ignition coil onto the end of the plug, inspect the ignition coil following the procedures outlined in Section 31. On four-cylinder engines, inspect the plug wire following the procedures



**30.9** Use a ratchet and extension to remove the spark plugs



**30.11a** Apply a thin coat of anti-seize compound to the spark plug threads



**30.11b** A length of snug-fitting rubber hose will save time and prevent damaged threads when installing the spark plugs

outlined in Section 32.

13 Repeat the procedure for the remaining spark plugs.

### **31 Ignition coil check (V6 engines and 2005 and later four-cylinder engines) (every 60,000 miles or 48 months)**

1 Remove the ignition coils (see illustrations 30.7b and 30.7c). Clean the coil(s) with a dampened cloth and dry them thoroughly.

2 Inspect each coil, for cracks, damage and carbon tracking. If damage exists, replace the coil.

### **32 Spark plug wire check and replacement (2004 and earlier four-cylinder engines) (every 60,000 miles or 48 months)**

1 The spark plug wires should be checked at the recommended intervals or whenever new spark plugs are installed.

2 Begin this procedure by making a visual check of the spark plug wires while the engine is running. In a darkened garage (make sure there is adequate ventilation) or at night while using a flashlight, start the engine and observe each plug wire. Be careful not to come into

contact with any moving engine parts. If possible, use an insulated or non-conductive object to wiggle each wire. If there is a break in the wire, you will see arcing or a small blue spark coming from the damaged area. Secondary ignition voltage increases with engine speed and sometimes a damaged wire will not produce an arc at idle speed. Have an assistant press the accelerator pedal to raise the engine speed to approximately 2000 rpm. Check the spark plug wires for arcing as stated previously. If arcing is noticed, replace all spark plug wires.

3 Perform the following checks with the engine OFF. The wires should be inspected one at a time to prevent mixing up the order that is essential for proper engine operation. **Note:** Due to the short length of the spark plug wire, always disconnect the spark plug wire from the ignition coil pack first.

4 With the engine cool, disconnect the spark plug wire from the ignition coil pack. Pull only on the boot at the end of the wire; don't

pull on the wire itself. Use a twisting motion to free the boot/wire from the coil. Disconnect the same spark plug wire from the spark plug, using the same twisting method while pulling on the boot. Disconnect the spark plug wire from any retaining clips as necessary and remove it from the engine.

5 Check inside the boot for corrosion, which will look like a white, crusty powder (don't mistake the white dielectric grease used on some plug wire boots for corrosion protection).

6 Now push the wire and boot back onto the end of the spark plug. It should be a tight fit on the plug end. If not, remove the wire and use a pair of pliers to carefully crimp the metal connector inside the wire boot until the fit is snug.

7 Now push the wire and boot back into the end of the ignition coil terminal. It should be a tight fit in the terminal. If not, remove the wire and use a pair of pliers to carefully crimp the metal connector inside the wire boot until

the fit is snug.

8 Now, using a cloth, clean each wire along its entire length. Remove all built-up dirt and grease. As this is done, inspect for burned areas, cracks and any other form of damage. Bend the wires in several places to ensure that the conductive material inside hasn't hardened. Repeat the procedure for the remaining wires.

9 If new spark plug wires are required, purchase a complete set for your particular engine. The terminals and rubber boots should already be installed on the wires. Replace the wires one at a time to avoid mixing up the firing order and make sure the terminals are securely seated on the coil pack and the spark plugs.

10 Attach the plug wire to the new spark plug and to the ignition coil pack using a twisting motion on the boot until it is firmly seated. Attach the spark plug wire to any retaining clips to keep the wires in their proper location on the valve cover.