# **Brake System**

| GENERAL                      | . BR -2 |
|------------------------------|---------|
| BRAKE SYSTEM                 | . BR -8 |
| PARKING BRAKE SYSTEM         | BR -37  |
| ABS (ANTI-LOCK BRAKE SYSTEM) | BR -39  |

**BRAKE SYSTEM** 

# **GENERAL**

### SPECIFICATIONS EJMB0010

| ITEMS   | SPECIFICATIONS  |  |
|---|---|--|
| Master cylinder Type I.D. Fluid level sensor  | Tandem type<br>25.4 mm (1.0 in.)<br>Provided  |  |
| Brake booster Type Effective dia. Boosting ratio  | Vacuum type with tandem booster 7 + 8 in.(Diesel), 8 + 9 in.(Gasoline) 7.0 : 1  |  |
| Front brake Type Disc O.D. Disc thickness Pad thickness Cylinder type Cylinder I.D.           | Floating with ventilated disc 280 mm (11.02 in.) 27 mm (1.06 in.) 10 mm (0.39 in.) Double piston 42.9 mm (1.689 in.) (x2) |  |
| Rear disk brake (ABS) Type Disc O.D. Disc thickness Pad thickness Cylinder type Cylinder I.D. | Floating with ventilated disc 315 mm (12.4 in.) 20 mm (0.787 in.) 10 mm (0.39 in.) Single piston 42.9 mm (1.69 in.)       |  |
| Rear drum brake (CBS) Type Drum I.D. Cylinder I.D. Clearance adjustment Lining thickness      | Leading & Trailing type 270 mm (10.63 in.) 23.81 mm (0.94 in.) Automatic 4.7 mm (0.19 in.)                                |  |
| Parking brake Type Brake type   | Drum type (CBS), Disc type (ABS)<br>Hand brake lever type   |  |

O.D. = Outer diameter

I.D. = Inner diameter

ABS = Anti-lock Brake System
CBS = Conventional Brake System

## SERVICE STANDARD EJMB0020

| ITEMS   | SPECIFICATIONS                                      |  |
|---|---|--|
| Standard value  |   |  |
| Brake pedal height  | M/T : 188 mm (7.40 in.), A/T : 189 mm (7.44 in.)    |  |
| Clearance between stop lamp switch outer case and pedal arm | 0.5 - 1.0 mm (0.020 - 0.040 in.)                    |  |
| Brake pedal free play                                       | 3-8 mm (0.117 - 0.312 in.)                          |  |
| Clearance between brake pedal and floor board               | M/T : 54 mm, A/T : 55 mm                            |  |
| Parking brake lever stroke                                  | 8 clicks (When lever assembly is pulled with 20kgf) |  |
| Service limit   |   |  |
| Front disc brake pad thickness                              | 2.0 mm (0.079 in.)                                  |  |
| Front disc thickness (minimum)                              | 25.4 mm (1 in.)                                     |  |
| Front disc runout   | 0.03 mm ( 0.0012 in.)                               |  |
| Front disc thickness variation                              | 0.005 mm (0.0002 in.)                               |  |
| Rear disc brake pad thickness                               | 2.0 mm (0.079 in.)                                  |  |
| Rear disc thickness   | 18.4 mm (0.724 in.)                                 |  |
| Rear drum I.D.  | 272 mm (10.71 in.)                                  |  |
| Rear brake lining thickness                                 | 1.5 mm (0.059 in.)                                  |  |

## TIGHTENING TORQUE EJMB0030

| ITEMS  | Nm    | Kg⋅cm   | lb-ft   |
|--|-------|---------|---------|
| Brake support member mounting                  | 18-25 | 180-250 | 13-18   |
| Brake pedal stop lamp lock nut/Ignition switch | 10-15 | 100-150 | 0.73-11 |
| Brake booster mounting nut                     | 8-12  | 80-120  | 6-9     |
| Brake booster vacuum warning switch            | 20-25 | 200-250 | 15-18   |
| Bleeder screw                                  | 7-9   | 70-90   | 5-7     |
| Brake tube flare nut, brake hose               | 13-17 | 130-170 | 9.5-13  |
| Caliper guide rod bolt                         | 22-32 | 220-320 | 16-23   |
| Caliper assembly to knuckle                    | 65-75 | 650-750 | 48-55   |
| Brake hose to front caliper                    | 25-30 | 250-300 | 18-22   |
| Wheel cylinder mounting bolt                   | 12-18 | 120-180 | 9-13    |
| Parking brake mounting bolt                    | 17-26 | 170-260 | 13-19   |

## LUBRICANTS EJHA0150

| Items   | Recommended lubricant                    | Quantity    |
|---|--|-------------|
| Brake fluid   | DOT 3 or equivalent                      | As required |
| Brake pedal bushing and brake pedal bolt              | Chassis grease SAE J310, NLGI No.0       | As required |
| Clevis pin  | Wheel bearing grease SAE J310, NLGI No.2 | As required |
| Parking brake shoe and backing plate contact surfaces | Bearing grease, NLGI No.0-1              | As required |

# SPECIAL TOOLS EJHA0200

| Illustration | Usage   |
|--------------|---|
|              | Pushing back of the front disc and rear disc brake piston |
|              |   |

## TROUBLESHOOTING EJMB0040

| Trouble symptom                | Possible cause                                       | Remedy             |
|--------------------------------|--|--------------------|
| Noise or vibration when        | Caliper improperly mounted                           | Correct            |
| brakes are applied             | Loose caliper mounting bolts                         | Retighten          |
| • •                            | Unevenly worn or cracked brake drum or brake disc    | Replace            |
|                                | Foreign material in brake drum                       | Clean              |
|                                | Seized pad or lining contact surface                 | Replace            |
|                                | Excessive clearance between pad assembly and caliper | Correct            |
|                                | Uneven pad contact                                   | Correct            |
|                                | Lack of lubrication in sliding parts                 | Lubricate          |
| ·                              | Loose suspension parts                               | Retighten          |
|                                | Excessive of disc runout                             | Correct the runout |
|                                | Excessive variation of disc thickness                | Replace disc       |
| Vehicle pulls to one side when | Difference in left and right tire inflation pressure | Adjust             |
| brakes are applied             | Inadequate contact of pad                            | Correct            |
| • •                            | Grease or oil on pad or lining surface               | Replace            |
|                                | Drum warped or uneven wear                           | Replace            |
|                                | Incorrect wheel cylinder installation                | Correct            |
|                                | Auto adjuster malfunction                            | Reair              |
| Insufficient braking power     | Low or deteriorated brake fluid                      | Refill or change   |
|                                | Air in the brake system                              | Bleed the system   |
| •                              | Brake booster malfunction                            | Correct            |
|                                | Inadequate contact of pad                            | Correct            |
|                                | Grease or oil on pad surface                         | Replace            |
|                                | Auto adjuster malfunction                            | Correct            |
|                                | Overheated brake rotor due to dragging of pad        | Correct            |
|                                | Clogged brake line                                   | Replace            |
|                                | LCR valve malfunction                                | Replace            |


# SERVICE ADJUSTMENT PROCERDURES EJMB0050

#### INSPECTION AND ADJUSTMENT

 Measure the brake pedal height. If the brake pedal height is not within the standard value, adjust as follows.


#### Standard value

M/T : 188 mm (7.40 in.) A/T : 189 mm (7.44 in.)




FJMB065A

- Disconnect the stop lamp switch connector, loosen the lock nut, and move the stop lamp switch to a position where it does not contact the brake pedal arm.
- Adjust the brake pedal height by turning the operating rod with pliers (with the operating rod lock nut loosened), until the correct brake pedal height is obtained.



H7BR202A

- 3) After turning the stop lamp switch until it contacts the brake pedal stopper (just before the brake pedal is caused to move), return the stop lamp switch 1/2 to 1 turn and secure by tightening the lock nut.
- 4) Connect the connector of the stop lamp switch.
- 5) Check that the stop lamp is not illuminated with the brake pedal unpressed.



EHPBR01A


With the engine stopped, depress the brake pedal two or three times. After eliminating the vacuum in the power brake booster, press the pedal down by hand, and confirm that the amount of movement before resistance is met (the free play) is within the standard value.

#### Standard value

3 - 8 mm (0.118 - 0.315 in.)

If free play does not reach the standard value, check that clearance between the outer case of stop light switch and brake pedal is within the standard value. If free play exceeds the standard value, it is probably due to excessive clearance between the clevis pin and brake pedal arm.

Check for excessive clearance and replace faulty parts as required.




H7BR204A

 Start the engine, depress the break pedal with approximately 120kgf of force, and check for oil leakage in the master cylinder, brake line and each connecting part.

Repair the faulty parts as required.

### STOP LAMP SWITCH INSPECTION

Connect a circuit tester to the connector of stop lamp switch, and check whether or not there is continuity when the plunger of the stop lamp switch is pushed in and when it is released. The stop lamp switch is in good condition if there is no continuity when the plunger is pushed.




H788206A

### **BRAKE BOOSTER OPERATING TEST**

For simple checking of the brake booster operation, carry out the following tests:

 Run the engine for one or two minutes, and then stop it

If the pedal depresses fully the first time but gradually becomes higher when depressed succeeding times, the booster is operating properly, if the pedal height remains unchanged, the booster is defective.




EJA9002A


With the engine stopped, step on the brake pedal several times.

Then step on the brake pedal and start the engine. If the pedal moves downward slightly, the booster is in good condition. If there is no change, the booster is defective.

#### When engine is stopped



When engine is started




EJA9002B

3. With the engine running, step on the brake pedal and then stop the engine.

Hold the pedal depressed for 30 seconds. If the pedal height does not change, the booster is in good condition, if the pedal rises, the booster is defective.

If the above three tests are okay, the booster performance can be determined as good.

Even if one of the above three tests is not okay, check the check valve, vacuum hose and booster for defect.




### BLEEDING THE BRAKE SYSTEM FIMEN

 Remove the reservoir cap and fill the brake reservoir with brake fluid.




- Do not allow brake fluid to remain on a painted surface. Wash it off immediately.
- Use the specified brake fluid. Avoid using a mixture of the specified brake fluid and other fluid.
- Connect a vinyl tube to the wheel cylinder bleeder screw and insert the other end of the tube in a container of brake fluid which is half full.



KJMB070A

- 3. Start the engine.
- 4. Slowly depress the brake pedal several times.
- 5. While depressing the brake pedal fully, loosen the bleeder screw until fluid runs out. Then close the bleeder screw and release the brake pedal.




EAHA014B

- 6. Repeat steps 4 and 5 until there are no more bubbles in the fluid.
- 7. Tighten the bleeder screw.

**Tightening torque** 

Bleeder screw: 7 - 9 Nm (70-90kg·cm, 5-6.6 lb·ft)

8. Repeat the above procedure for each wheel in the sequence shown in the illustration.



EHP1341A

# **BRAKE SYSTEM**

# L.C.R(LOAD CONSCIOUS REDUCING) VALVE

# L.C.R (LOAD CONSCIOUS REDUCING)

VALVE EJMB0070

L.C.R valve is designed to provide maximum brake ability while controlling the brake according to the vehicle weight.


The brake fluid pressure of rear wheel may reduce as the vehicle weight is increased by heavy load or the number of passenger.

The changes of rear wheel suspension by the load of vehicle would affect to the valve body of L.C.R valve causing reducing or increasing the brake fluid into the rear brake system.

It is pre-setting type which does not need the difficult setting procedures.

EJMB0080

### **COMPONENTS**



### THE L.C.R VALVE CONSISTS OF EJMB0090

- 1. Load sensing part : sensing spring, Lever
- 2. Linkage part : Connecting link, Operating lever, Bell crank
- Pressure control part : Machine body, Piston, Valve seal
- 4. By-pass part: By-pass piston, O-ring

### INSTALLATION EJMB0100

When the L.C.R valve is set, the adjustment procedure is unnecessary.

- When the fuel tank is full, position the vehicle on a level surface. Don't load things or people in the vehicle.
- 2. Set the valve body to the vehicle with the hole of the mounting bracket.

### **Tightening torque**

11 - 14 Nm (110 - 140 kg·cm, 8.14 - 10.36 lb·ft)

3. Tighten the bolt of the connecting rod end in the valve mounting bracket.


### **Tightening torque**

11 - 14 Nm (110 - 140 kg·cm, 8.14 - 10.36 lb·ft)

4. When the machine body and the bolt of the connecting rod are fixed, tighten the flange bolt in the bell crank so that the connecting rod and operating lever can't move.

#### Tightening torque

19 - 23 Nm (190 - 230 kg·cm, 14.06 - 17.02 lb·ft)




Tightening torque : 11-14 Nm (110-140 kg-cm, 8.14-10.36 lb-ft)

EHPBR02A

### **BRAKE BOOSTER**

### COMPONENTS EJMB0110



EJMB011A

### **REMOVAL**


EJMB0120

Remove the master cylinder.




### ( CAUTION

Do not allow brake fluid to remain on a painted surface. Wash it off immediately.



KHPBR07A

- 2. Separate the vacuum tube from the booster.
- Remove the operating rod from the brake pedal.
- Remove the booster installation nut.
- 5. Remove the booster assembly.



EJDA025B

### **INSTALLATION**

EJMB0130


- When installing the booster assembly, replace the packing of each end of booster installation holder.
- Install the brake booster and tighten the mounting nut.

### **Tightening torque**

Booster installation nut:

8 - 12 Nm (80 - 120 kg·cm, 6 - 9 in.)

Connect the booster push rod and brake pedal with a clevis pin and install a split pin to the clevis pin.



EJA9005B


- Install the master cylinder. 4.
- 5. Connect the vacuum hose to the brake booster.
- After filling the brake reservoir with brake fluid, bleed 6. the system.
- Check for fluid leakage. 7.
- Check and adjust the brake pedal for proper opera-8. tion.
- After installing, apply grease to the contact parts of the clevis and brake pedal.

CAUTION

While installing the split pin to the clevis pin connecting the booster push rod and brake pedal, the split pin must be bent to approx. 180°.

# **BRAKE LINE**

### COMPONENTS EJMB0140



- Front brake assembly
   Rear brake assembly
- 3. Front brake disc
- 4. Rear dum brake
- 5. Booster & master cylinder assembly
- 6. Brake tube

- 7. L.C.R valve
- 8. Front brake hose
- 9. Rear brake hose
- 10. Brake pedal assembly
- 11. Parking brake lever assembly
- 12. Parking brake cable assembly

### REMOVAL EJMB0150

Holding the nut at the brake hose side, loosen the flare nut of the brake tube.

### INSPECTION EJMB0160

- Check the brake tubes for cracks, crimps and corrosion.
- Check the brake hoses for cracks, damaged and oil leakage.
- Check the brake tube flare nuts for damage and oil leakage.

### INSTALLATIONS EJMB0170

1. Install the brake hoses without twisting them.




When installing, be sure the brake hose does not contact edges, welding or moving parts.

2. Tighten to the specified torque as follows.

| Items                          | Torque Nm (kg·cm, lb·f) |  |
|--------------------------------|-------------------------|--|
| Brake flare nut and brake hose | 13-17 (130-170, 9.5-12) |  |
| Brake hose and caliper         | 25-30 (250-300, 18-22)  |  |
| Air bleed screw                | 7-9 (70-90, 5-7)        |  |
| Brake tube and connector       | 20 (200, 15) or less    |  |

## **BRAKE PEDAL**


#### COMPONENTS EJMB0180




EHPBR05A

### REMOVAL EJMB0190

- Remove the lower crash pad assembly.
- Remove the stop lamp switch connector. 2.
- 3. Remove the return spring.



- Remove the split pin and clevis pin.
- Remove the brake pedal assembly mounting nut. 5.



EJKB010A

#### **INSPECTION** EJJB0095

- 1. Check the bushing for wear.
- 2. Check the brake pedal for bending or twisting.
- 3. Check the brake pedal return spring for damage.
- 4. Check all parts for crack and wear.

#### **INSTALLATION** EJMB0210

Installation is the reverse of removal.




### / CAUTION

Coat the inner surface of the bushings with the specified grease.

Specified grease: Chassis grease LiG - 2


Before inserting the clevis pin, apply the specified grease to the clevis pin and washer.



EJA9005B

### FRONT DISC BRAKE

### COMPONENTS EJMB0220




EHPBR10A

## INSPECTION AND REPLACEMENT OF FRONT DISC BRAKE PAD EJMB0230

1. Check the brake pad thickness through the caliper body inspection hole.

### Pad lining thickness

Standard value: 10mm (0.394 in.) Service limit: 2.0mm (0.079 in.)



H7BR215A




If the pad lining thickness is out of specification, left and right pads must be replaced as

a complete set.

- When the thickness difference between the left pad and right pad is large, check the sliding condition of the piston, the lock pin and the guide pin.
- 2. Remove the guide pin, lift the caliper assembly up and suspend it with a wire.




Be careful not to contaminate the lock pin and guide pin with grease.




H7BR216A

- 3. Remove the following parts from the caliper support.
  - 1. Pad and wear sensor assembly
  - 2. Pad assembly
  - 3. Clip
  - 4. Outer shim



KJMB230A



### INSPECTION EJMB0240

#### FRONT BRAKE THICKNESS CHECK


Remove all rust and contamination from the disc surface, and then measure the disc thickness at 4 positions at least.

### Front brake disc thickness

Standard value: 27mm (1.06 in.)

Limit: 25.4mm (1 in.)


- 2. Thickness variation should not exceed 0.005mm (circumference) and 0.05mm (radisu) at any directions.
- 3. If wear exceeds the limit, replace the discs and pad assembly for left and right of the vehicle.



KGX8031A

### FRONT BRAKE DISC RUNOUT CHECK

 Remove the caliper support, then raise the caliper assembly upward and suspend with a wire.



H7BR216A


 Place a dial gauge about 5mm (0.2 in.) from the outer circumference of the brake disc, and measure the runout of the disc.

Brake disc runout

Limit: 0.03mm (0.0012 in.) or less




Fix the disc to the hub by tightening the nut.



H7BR221A

### FRONT BRAKE DISC RUN OUT CORRECTION

- If the runout of the brake disc is equivalent to or exceeds the limit specification, replace the disc and hub, and then measure the runout again.
  - Before removing the brake disc, chalk both sides of the wheel stud on the side at which the runout is greatest.



EJMB240A

- 2) If it is exceeds the limit, disassemble the hub knuckle and check each part.
- 3) If the runout does not exceed the limit specification, install the brake disc after turning it 180° from the chalk mark, and then check the runout of the brake disc again.
- If the runout cannot be corrected by changing the position of the brake disc, replace the brake disc.


### INSTALLATION EJMB0250

- 1. Install the pad clips.
- 2. Install the pads on each pad clip.

## <u>^</u>

### CAUTION

- 1. All four pads must be replaced as a complete set.
- 2. When replacing the brake pads, check for deformation. When replacing the guide spring, use a new one or thoroughly clean the used one.
- 3. Press-fit the piston with a hammer handle or the special tool (09581-11000).



KGX8029A

- 4. Lower and insert the brake cylinder carefully so as not to damage the boot.
- 5. Tighten the two guide rod bolts to the specified torque.


### Tightening torque

Guide rod bolt:


22 - 32 Nm (220 - 320 kg·cm, 16 - 24 lb·ft)

### DISASSEMBLY AND REASSEMBLY EJJB0230

TORQUE: Nm (kg.cm, lb.ft)



### LUBRICATION POINTS EJJB0240



#### DISASSEMBLY EJMB0260


Front disc brakes should be disassembled separately into the left and right as a set.

 Remove the piston boot/piston.
 Blow compressed air into the brake hose seating hole so as to remove the piston and the piston boot.

## **NOTE**

When removing the piston, blow air slowly, adjusting the heights of the two pistons to push them out equally.

The secondary piston should not be removed before the primary piston is removed completely. Otherwise the secondary piston can't be removed.



KGX8039A


- 2. Remove the piston seal.
  - 1) Remove the piston seal with your finger.



Do not use a screwdriver or another tool because it may damage the cylinder.

2) Clean the piston surface and inner cylinder using alcohol or the specified brake fluid.

Brake fluid: DOT 3 or DOT 4




KGX8040A

### INSPECTION EJJB0260

- 1. Check the cylinder for wear, damage and rust.
- 2. Check the piston surface for wear, damage and rust.
- 3. Check the caliper body and sleeve for wear.
- 4. Check that grease is applied, and the pad and backing metal are not damaged.
- 5. Check the pad wear. Measure the pad thickness and replace it if it is less than the specified value.

### Pad thickness


Specification: 10.0 mm (0.39 in.) Service limit: 2.0 mm (0.08 in.)



KGX8041A


### REASSEMBLY EJJB0270

- 1. Clean all components with isopropyl alcohol except for the pad and shim.
- 2. Install the piston seal.
- 3. After applying the specified brake fluid to the piston outer surface, install the piston into the cylinder.
- 4. Install the piston boot and boot ring.



EJHA008A

5. Install the guide pin boots and guide pin.



EJA9015J


### INSTALLATION EJMB0280

- 1. Install the pads and brake cylinder.
- 2. Install the brake hose to the caliper.

### **Tightening torque**

Bleeder screw: 7-9 Nm (70-90 kg·cm, 5-6.6 lb·ft)

- 3. Fill the brake reservoir with brake fluid.
- 4. Bleed the system.




EAHA014B

### **MASTER CYLINDER**

### COMPONENTS

EJMB0290



EHPBR06A

### **REMOVAL**

EJMB0291


Detach the brake tubes from the master cylinder, and then install the plug.



### **CAUTION**

Do not allow brake fluid to remain on a painted surface. Wash it off immediately.


2. Remove the master cylinder mounting nuts and then remove the master cylinder.



KHPBR07A


#### DISASSEMBLY EJMB0300

- Remove the reservoir cap and drain the brake fluid into a suitable container.
- 2. Remove the reservoir from the master cylinder.



KHPBR08A

Using a snap ring pliers, remove the retainer ring.




FJDA027B

- Remove the cylinder pin with the primary piston pushed completely using a screwdriver. Remove the primary piston assembly.
- Remove the cylinder pin with the secondary piston pushed completely using a screwdriver. Remove the secondary piston assembly.



Do not disassemble the primary and secondary piston assembly. ·



#### INSPECTION FJMB0310

- Check the master cylinder bore for rust or scratch.
- Check the master cylinder for wear or damage. If necessary, clean or replace the cylinder.



### /!\ CAUTION

- If the cylinder bore is damaged, replace the master cylinder assembly.
- Wash the contaminated parts in alchohol.


#### REASSEMBLY EJMB0320

Apply genuine brake fluid to the rubber parts of the cylinder kit and grommets.




KFW8016A

- Carefully insert the springs and pistons in the proper direction.
- 3. Press the piston with a screwdriver and install the retainer ring.



EJDA027B

- With the piston pushed completely by a screwdriver, install the piston pin.
- 5. Mount two grommets.
- Install the reservoir on the cylinder. 6.



EJMB170A


### INSTALLATION EJMB0330

1. Install the master cylinder the on brake booster with 2 nuts.

### **Tightening torque**

Master cylinder installation nut:

8-12 Nm (80-120 kg·cm, 6-9 lb·ft)



KHPBR07A


Connect 2 brake tubes and the brake fluid level warning connector.

### **Tightening torque**

Brake tube flare nut: 13-17 (130-170 kg·cm, 9.5-12 in.)

## **REAR DISC BRAKE**


### COMPONENTS EJMB0340



- 1. Guide bolt
- 2. Lock pin
- 3. Bushing
- 4. Caliper support
- 5. Boot
- 6. Boot ring
- 7. Piston boot

- 8. Piston
- 9. Piston seal
- 10. Caliper body
- 11. Pad and wear indicator assembly
- 12. Pad
- 13. Outer shim
- 14. Clip


## LUBRICATION POINTS EJJB0300



### DISC BRAKE PAD EJMB0350

#### **REMOVAL**

- Remove the wheel.
- 2. Remove the guide bolt, lift up the caliper assembly, and remove the pad assembly.




EJJA030B

#### DISASSEMBLY SERVICE POINT

Rear disc brakes should be disassembled seperately as a set of left and right as a set.

Remove the piston boot/piston.
 Wrap the caliper body with a rag. Blow compressed air into the brake hose, and remove the piston and the piston boot.





KGX8057A

- 2. Remove the piston seal.
  - 1) Remove the piston seal with your finger.




### **CAUTION**

Do not use a screwdriver or another tool in order to avoid damage the inside of the cylinder.

 Clean the piston surface and the inside of the cylinder using trichloro-ethylene, alcohol or the specified brake fluid.

Brake fluid: DOT 3 or DOT 4



EJMB0360


#### INSPECTION

- 1. Check the cylinder for wear, damage and rust.
- 2. Check the piston surface for wear, damage and rust.
- 3. Check the caliper body and sleeve for wear.
- Check that grease is adhesive, and the pad and backing metal are damaged.
- 5. Check the pads for wear or oil contamination and replace if necessary.



The pads for the right and left wheels should be replaced at the same time.

Pad thickness wear limit: 2.0mm (0.08 in.)




EJA9015E

 Check for worn or damaged dust boots. If dust or mud had entered the caliper assembly through the seal, the caliper assembly must be replaced or repaired. EJMB0370

### **INSTALLATION**

- Before replacing the brake pads, drain brake fluid from the master cylinder reservoir until it remains half full.
- Remove the brake pad by turning the piston in the housing assembly. Using the special tool (09581-11000), remove the piston.



- EJJA035B
- 3. Install two caliper guide rods and tighten to a torque of 22-32 Nm (220-320 kg·cm, 16-23 lb·ft)
- After filling the master cylinder reservoir with the fluid, bleed the brake line.

Recommended brake fluid: DOT 3 or DOT 4

### CALIPER

EJMB0380

### **REMOVAL**

- Remove the rear wheel.
- 2. Remove the caliper assembly.
- 3. Remove the brake hose from the caliper.


EJMB0390

### DISASSEMBLY

- 1. Remove the pad.
- 2. Remove the piston boot from the housing, and then remove the piston.



Using a wire hanger or equivalent, remove the caliper so as not to damage the brake hose.




EJJA035D

3. Remove the piston by applying compressed air through the brake hose fitting.



Do not place your fingers in front of the piston when using compressed air.




- 4. Remove the piston seal carefully so as not to damage the cylinder wall.
- 5. Clean all removed parts with the specified fluid.

| Item                               | Specified fluid                                  |  |
|------------------------------------|--|--|
| Metal section                      | Trichloroethylene, alcohol or brake fluid        |  |
| Piston seal                        | If the oil level is low, add fluid (about 70cc). |  |
| Piston boot and other rubber parts | Alcohol  |  |

# **CAUTION**

Rubber parts should be replaced with new ones but if you want to reuse them, don't put them in alcohol for more than thirty minutes.




EJJA035F

EJJB0370

### INSPECTION

- Check the piston and its inside for wear, damage and rust.
  - Replace the damaged parts if necessary.
- 2. Check the piston seal, boot, and pin insulators for wear and damage.




F.IMB0400

#### REASSEMBLY

- 1. When disassembling the caliper assembly, use a new piston seal and boot.
- Apply the recommended fluid to the bearing part of the piston seal and piston. Insert the piston seal into grooves inside the caliper, being careful not to twist the seal.

| Item                      | Recommended fluid           | Quantity    |
|---------------------------|-----------------------------|-------------|
| Piston seal               | Brake fluid (DOT3,<br>DOT4) | As required |
| Inside of piston cylinder | Brake fluid (DOT3, DOT4)    | As required |
| Piston boot               | Brake fluid (DOT3,<br>DOT4) | As required |
| Locating pin insulator    | White silicone grease       | As required |

 Install the piston boot to the piston.
 Confirm that the concave part of the piston is placed outward and the boot is seated in grooves of the piston completely.



EJJA035G

- 4. Install the piston and boot in the caliper housing. Insert the boot flange in the caliper housing and check that the boot fits in grooves around the piston.
- 5. Apply the recommended oil to the inside of the locating pin insulator.

EJMB0410

### **INSTALLATION**

- Refer to "Brake pad installation" for detail.
- 2. Install the brake hose connector
- 3. Install the caliper installation bolt.
- Bleed the system. 4.



### /!\ CAUTION

When replacing the piston seal, check the pedal


If the pedal stroke is too excessive, the piston may not retain the piston seal.

### Adjust as follows :

- 1. After removing the pad from the piston, push the piston into the cylinder 3-5mm. Put a lever or steel plate (1m x 0.3m) between the piston and disc, being careful not to damage the contact surface of the disc or the piston end.
- 2. Install the pad. To restore the brake pedal to the original position, step on it 2-3 times.
- 3. Repeat the above procedure more than 5 times and move the piston outward and inward to assure that the piston seal is properly installed.
- 4. Before driving a vehicle, step on the brake pedal and release it several times.
- 5. Perform the road test.

## **REAR DRUM BRAKE**

### COMPONENTS EJMB0420



### Removal steps

- 1. Wheel and tire
- 2. Brake drum
- 3. Shoe hold-down spring
- 4. Adjuster assembly
- 5. Shoe return spring
- 6. Shoe and lining assembly

### INSPECTION


Measure the brake drum inside diameter. Check the runout of the brake drum using a dial indicator.

Standard value: 270mm (10.63 in.) Service limit: 272mm (10.71 in.)




### /!\ CAUTION

If the brake drum inner diameter is greater than the service limit, replace the brake drum.




EJA9018E



EJA9018C

Measure the brake lining thickness.

Standard value: 4.7mm (0.185 in.) Service limit: 1.5mm (0.059 in.)



EJA9018D




# **CAUTION**

If the brake lining thickness is less than the service limit, replace the brake lining.

- 3. Inspect the brake lining and drum for proper contact.
- Inspect the outside of the wheel cylinder for excessive corrosion and damage.

### REMOVAL AND INSTALLATION EJMB0440



### Removal steps

- 1. Brake drum
- 2. Bleeder screw
- 3. Brake tube
- 4. Wheel cylinder assembly


### Procedures after installation


- Applying brake fluid
- Air bleeding


TORQUE: Nm (kg-cm, lb-ft)

### DISASSEMBLY AND REASSEMBLY EJMB0450









## Disassembly steps

- 1. Wheel cylinder boot
- 2. Piston assembly
- 3. Piston cup
- 4. Body machining

### REASSEMBLY

EJMB0460

### **PISTON CUP**


- Clean the inside of the wheel cylinder and the outside of the piston with alcohol or brake fluid.
- Apply the specified brake fluid on piston cup.

Specified brake fluid: DOT 3 or DOT 4

Until the piston cup is seated completely, push the special tool with fingers as shown in the illustration.



When pushing down the piston cup, push slowly with both hands without stopping so that deformation or turn-over will not result.





AHBR0840


# PARKING BRAKE SYSTEM

# PARKING BRAKE

## REMOVAL AND INSTALLATION EJMB0470







# Removal steps for the lever

- 1. Remove the console
- 2. Loosen the lever adjusting nut
- 3. Detach the cable from the lever
- 4. Remove the lever mounting bolts
- 5. Disconnect the parking brake switch connector

## Removal steps for cable

- 1. Remove the console
- 2. Loosen the lever adjusting nut
- 3. Detach the cable from the lever
- 4. Connect the cable to the body and install the axle housing
- 5. Remove the cable clip
- 6. Remove the parking cable from the operating lever

## **ADJUSTMENT PROCEDURE**

#### PARKING BRAKE STROKE ADJUSTMENT


Pull the brake lever with force of 200N (20kg, 44lbs) and count the number of notches.

# /!\ CAUTION

After operating the parking brake at full stroke more than 3 times, operate it in the position of 40mm of lever so as to seat the cable completely.


# Parking brake stroke

Standard value: 8 clicks




KHPBR13A

- If the parking brake stroke is out of the standard value, adjust it as follows:
  - Loosen the adjusting nut to release the parking brake cable.



EHPB320A

- Remove the adjusting hole plug, and then turn the adjuster the direction of the arrow. To prevent the disc from rotating, use a screwdriver (flat tip
- Turn the adjuster 5 notches in the opposite direction of arrow.



EJJA040B

Turn the adjuster nut to adjust the parking brake stroke to the specification.

# /!\ CAUTION

If the number of parking brake notches is less than the specification, loosen the adjusting nut and readjust.

- After adjusting, check that there is no gap between the adjusting nut and pin and that the adjusting nut is fixed in the nut holder precisely.
- 6) After adjusting the parking brake stroke, raise the rear of vehicle with a jack.
- Check that the rear brakes do not drag by turning the rear wheel when the parking brake lever is released.


#### PARKING BRAKE BED-IN (DIH)

- When the parking brake lever is pulled with force of 20-25 kg(f), drive the vehicle 400m at 60 kph.
- 2. Repeat step 1 more than 2 times.
- Parking should be possible on a hill of 30%. 3.

# **ABS (ANTI-LOCK BRAKE** SYSTEM)

#### SYSTEM COMPONENT

EJMB2100



EJMB210A

The Anti-Lock Brake System (ABS) controls the hydraulic brake pressure of all four wheels during sudden braking and braking on hazardous road surfaces, preventing the wheels from locking up. ABS provides the following benefits:

- Enables steering around obstacles with a greater degree of certainty, even during emergency braking.
- 2. Enables stopping during emergency braking while keeping stability and steerability even on curves.

If a malfunction occurs, a diagnosis function and fail-safe system are included for serviceability.

The traction control is a variable system designed to enhance traction during acceleration and cornering. It does so by determining the optimum amount of wheel spin for any given driving situation, and then suppressing surplus engine power accordingly.

The hydraulic electronic control unit (HECU) receives signals concerning the vehicle's speed, direction and road conditions from sensors at the wheels. Based on these signals, the control unit will determine the optimum amount of wheel spin. Because the system is variable, the control unit may determine, depending on the driving conditions, that some wheel spin is beneficial (thus enhancing straight-line acceleration), or that no wheel spin is beneficial (thus enhancing cornering). For any given driving situation, the control unit will determine the amount of wheel spin best suited to the driver's needs. The system is automatically read whenever the engine is started, but can be manually canceled with the TCS switch.

However, once actuated, the system cannot be canceled until it is once again in the ready state.

# EBD (ELECTRONIC BRAKE-FORCE DISTRIBUTION) EJMB2150


EBD is additionally applied, instead of the proportioning valve, to deliver ideal distribution of fluid pressure to the

front and rear brakes. This prevents the brakes from skidding in the event of rear wheel lock up and provides higher brake efficiency within the range of brake application.

## **ADVANTAGES**

- Functional improvement of base-brake system
- Compensation of different friction coefficients
- Elimination of proportioning valve
- Failure recognition by warning lamp


#### COMPARISON BETWEEN PROPORTIONING VALVE AND EBD



CUMUUUSEM

# INSPECTION AT HECU TERMINALS EJMB2200

# **TERMINAL VOLTAGE CHART**



EJHA025A

| Terminal<br>No.    | Description   | Condition            | Output   |
|--------------------|---|----------------------|--|
| 9                  | Battery power source 1     Solenoid valve power source  | Always               | System voltage   |
| 8                  | Ground  | G12                  |  |
| 7                  | Diagnosis interface (K-Line)  | Data to the Hi-Scan  |  |
| 5<br>1<br>19<br>23 | Wheel speed sensor (Left rear) Wheel speed sensor (Left front) Wheel speed sensor (Right front) Wheel speed sensor (Right rear) |                      | Resistance $R=1.1k\Omega \pm 50\%$ Min. detectable voltage 130mV peak to peak voltage at 50Hz  |
| 6<br>2<br>20<br>22 | Wheel speed sensor (Left rear) Wheel speed sensor (Left front) Wheel speed sensor (Right front) Wheel speed sensor (Right rear) |                      |  |
| 4                  | Start/ON input  | Ignition 2 condition | Over voltage detection: between $16.5V \pm 0.5V$ and $20V$ Suspend voltage detection: between $7.0V \pm 0.5$ and $9.5V \pm 0.5$ System off: below $5.5V \pm 0.5$ |
| 25                 | Battery power source 2     Motor power source   | Always               | <ul> <li>System voltage</li> <li>Max. current</li> <li>below 100A (before 100msec.)</li> <li>Rated current</li> <li>below 30A (after 100msec.)</li> </ul>        |
| 24                 | Ground  | G12                  |  |
| 16                 | ABS & EBD warning lamp  | Energized ABS relay  | Max. current : below 200mA Max. voltage 40V  |
| 18                 | Stop lamp switch input  |                      | Input voltage threshold<br>1.00V - 2.75V<br>5.00V - 16.00V   |
| 14                 | ECU Check pin   |                      |  |
| 3                  | Front right speed sensor output   |                      |  |
| 12                 | Rear left speed sensor output   |                      |  |
| 17                 | Front right speed sensor output   |                      |  |
| 21                 | Rear right speed sensor output  |                      |  |


# Input-output specification

| No.                                      | Mark   | Terminal Name  | Specification   | Note   |
|--|--|--|---|--|
| 9  | BATT1  | Battery power source<br>1 terminal (Valve<br>power source)           | Max. current : I < 20A Rated current : I < 20mA Dark current: I < 1mA   | When all valves<br>activated<br>When non ABS control   |
| 25                                       | BATT2  | Battery power source<br>2 terminal (Motor<br>power source)           | Max. current : I < 100A<br>Rated current : I < 40A  | Rush current   |
| 4  | IGN  | Power source via IG2<br>SW terminal                                  | Rated voltage: 12V Over voltage detection: 16.5V < V < 20.2V Suspend voltage detection: 8.5V < V < 9.5V System off: 4.5V < V < 7.5V Rated current: I < 300mA  |  |
| 8<br>24                                  | GND1<br>GND2   | Ground terminal  | Max. current : (Total of 2 terminals) Continuous valve Activated time : 14s Rated current : I < 300mA   | In ABS control When non ABS control  |
| 18                                       | STP  | Brake Lamp Switch input terminal                                     | Voltage range : $-5V \le V_{in} \le 16V$<br>Input voltage threshold : $V_{IL} < 1.2V$ , $V_{IH} > 4.0V$   |  |
| 1<br>19<br>5<br>23<br>2<br>20<br>6<br>22 | FL1<br>FR1<br>RL1<br>RR1<br>FL0<br>FR0<br>RL0<br>RR0 | Wheel sensor input terminal  | Detectable frequency range : F = 15 - 2000Hz Resistance : 1.1k $\Omega$ ± 50% Inductance : L=0.7H ± 50%   | Should be use the twist pair cable for connect between sensor and ECU  |
| 16<br>3                                  | WLAS<br>WLE  | ABS Warning Lamp output terminal  Brake warning lamp output terminal | Max. curent: I < 200mA Max. voltage: 40V Low level output voltage: V < 2.0V(at 200mA) Leakage current: I < 1mA  |  |
| 7  | К  | Diagnosis interface<br>terminal                                      | Input voltage threshold : $V_{IL} < 0.3 \text{VB V} \\ V_{IH} < 0.7 \text{VB V} \\ \text{Output votlage threshold :} \\ V_{OL} < 0.2 \text{VB V} \\ V_{OH} > 0.8 \text{VB V} \\ \text{Receiving, sending signal "1" : R > 50 k}\Omega \\ \text{Sending signal "0" : R < 110 k}\Omega$ | VB : Ignition voltage  Should be no use the unsettled  unsettled voltage area 0.3*IGN voltage-0.7*GN voltage |
| 17                                       | IDL  | Idle-up Solenoid output  | Coil current : I $\leq$ 400mA<br>Output voltage threshold : $V_{OL}$ 1.5V(ON), $V_{OH} > V_{IGN}$ - 1.0V(OFF)<br>Max. voltage : 40V<br>Low level output voltage   |  |
| 11                                       | DMY<br>IDL   | Dummy idle-up ouput  | Input voltage: -0.5V ≤ V ≤ 16V Output current: I ≤ 1mA  |  |
| 13                                       | GS   | G-sensor input   | Input voltage range: -0.5V ≤ V ≤ 5.0V   | No connection to the chassis GND out of ECU.   |

| No. | Mark | Terminal Name                      | Specification   | Note  |
|-----|------|------------------------------------|---|---|
| 15  | GSG  | G-sensor input                     | Input voltage range : -0.5V ≤ V ≤ 5.0V  | No connection to the chassis GND out of ECU.                |
| 10  | TOD  | TOD ECU<br>Communication<br>output | Output voltage threshold : V <sub>OL</sub> < 0.5V<br>Output current : I < 2mA | NO ABS CONTROL<br>> 4.0V (High)<br>ABS IN CONTROL<br>< 0.5V |
| 12  | NC   | No connection                      |   |   |
| 14  | NC   | No connection                      |   |   |
| 21  | NC   | No connection                      |   |   |

# DIAGRAM OF INPUT/OUTPUT FOR


HECU EJHA2250



# SYSTEM DIAGRAM

EJHA2300

# [ABS]




MCS : Master Cylinder Secondary MCP : Master Cylinder Primary

NO : Normal Open NC : Normal Close M : Motor & Pump


LPA: Low Pressure Accumulator

# INPUT/OUTPUT CIRCUIT DIAGRAM EJMB5050

#### ABS E.C.U



# STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING EJHA2400



<sup>\*</sup> Using the customer problem analysis check sheet for reference, ask the customer as much detail as possible about the problem.

EJDA015A

# NOTES WITH REGARD TO DIAGNOSIS EJHA2450

The phenomena listed in the following table are not abnormal

| Phenomenon                            | Explanation  |
|---------------------------------------|--|
| System check sound                    | When starting the engine, a thudding sound can sometimes be heard coming from inside the engine compartment. This is because the system operation check is being performed.  |
| ABS operation sound                   | <ol> <li>Sound of the motor inside the ABS hydraulic unit operation (whine).</li> <li>Sound is generated along with vibration of the brake pedal (scraping).</li> <li>When ABS operates, sound is generated from the vehicle chassis due to repeated brake application and release.         (Thump: suspension; squeak: tires)     </li> </ol> |
| ABS operation (Long braking distance) | For road surfaces such as snow-covered and gravel roads, the braking distance for vehicles with ABS can sometimes be longer than that for other vehicles. Accordingly, advise the customer to drive safely on such roads by lowering the vehicle speed.  |
| Pedal kickback                        | It's normal operation.   |

after the diagnosis code has been erased, ensure that the requirements listed in "Comment" are met.


# ABS CHECK SHEET EJHA2500

|   | АВ               |      | Check Sheet      |      | Name                   |             |
|---|------------------|------|------------------|------|------------------------|-------------|
|   |                  |      |                  |      |                        |             |
| *************************************** |                  |      | Registration     | No.  |                        |             |
| Customer's Name                         |                  |      | Registration     | Year | / /                    |             |
|   |                  |      | VIN.             |      |                        |             |
| Date Vehicle<br>Brought In              | /                | /    | Odometer         |      |                        | Km<br>Miles |
|   |                  |      |                  |      |                        |             |
| Date the Problem Fi                     | rst Occurred     |      | /                |      | /                      |             |
| Frequency of Occur                      | ence of Problem  |      | Continuous       |      | Intermittent ( times a | a day)      |
|   |                  |      |                  |      |                        |             |
|   | ☐ ABS does not d | pera | ite.             |      |                        |             |
| Symptoms                                | ☐ ABS does not d | pera | ate efficiently. |      | Intermittent ( times a | a day)      |
| ABS Warning<br>Light Abnormal           |                  |      | Remains ON       |      | Does not light up      |             |
|   |                  |      |                  |      |                        |             |
| Diagnostic<br>Trouble Code              | 1st Time         |      | Normal Code      |      | Malfunction Code (Code | )           |
| Check                                   | 2nd Time         |      | Normal Code      |      | Malfunction Code (Code | )           |


EJDA017A

# HI-SCAN (PRO) CHECK EJHA2550

- 1. Turn the ignition "OFF".
- 2. Connect the Hi-scan to the data link connector located underneath low crash pad panel.
- 3. Turn the ignition "ON".
- 4. Use the Hi-scan to check the self-diagnosis codes.
- 5. After completion of the repair or correction of the problems, turn the ignition switch; then erase the stored faults codes using the clear key.
- 6. Disconnect the Hi-scan.



ERHA006A



**DATA LINK CONNECTOR** 

EJHA100A

# INSPECTION CHART FOR DIAGNOSTIC TROUBLE CODES EJMB2600

Inspect according to the inspection chart that is appropriate for the malfunction code.

| DTC on Hi-Scan | Description  |
|----------------|--|
| C1101          | Too high battery voltage (over 18V)                  |
| C1102          | Too low battery voltage (below 9V)                   |
| C1200          | FL wheel sensor : open or short to GND               |
| C1201          | -Range / Performance : exciter or speed jump error   |
| C1202          | - No signal : air-gap error                          |
| C1203          | FR wheel sensor : open or short to GND               |
| C1204          | - Range / Performace : exciter or speed jump error   |
| C1205          | - No signal : air-gap error                          |
| C1206          | RL wheel sensor : open or short to GND               |
| C1207          | - Range / Performanace : exciter or speed jump error |
| C1208          | Battery voltage over volt (over 18V)                 |
| C1209          | RR whel sensor : open or short to GND                |
| C1210          | - Range / Performance : exciter or speed jump error  |
| C1211          | Battery voltage over volt (over 18V)                 |
| C1274          | G-sensor signal is fail                              |
| C1275          | G-sensor open or short to GND                        |
| C1506          | Idle-up failure                                      |
| C1604          | Harware (including valve failures)                   |
| C1615          | TOD line failure                                     |
| C2112          | Valve relay (including fuse failure)                 |
| C2201          | Without setting vehicle selection code               |
| C2402          | Electrical (Pump-Motor)                              |

# **ACTUATOR DRIVING**

| No. | Description             | Condition          | Recognition   | Time      |
|-----|-------------------------|--------------------|---|-----------|
| 01  | Motor                   | KEY ON<br>ENG. OFF | Motor pump relay operation (Click sounds)           | 2 seconds |
| 02  | Front left valve (In)   |                    | Front left solenoid valve operation (Click sounds)  |           |
| 03  | Front right valve (In)  |                    | Front right solenoid valve operation (Click sounds) |           |
| 04  | Rear left valve (In)    |                    | Rear left solenoid valve operation (Click sounds)   |           |
| 05  | Rear right valve (In)   |                    | Rear right solenoid valve operation (Click sounds)  |           |
| 06  | Front left valve (Out)  |                    | Front left solenoid valve operation (Click sounds)  |           |
| 07  | Front right valve (Out) |                    | Front right solenoid valve operation (Click sounds) |           |
| 80  | Rear left valve (Out)   |                    | Rear left solenoid valve operation (Click sounds)   |           |
| 09  | Rear right valve (Out)  |                    | Rear right solenoid valve operation (Click sounds)  |           |

# **CURRENT DATA**

| No. | Description         | Recognition                    | Unit    |
|-----|---------------------|--------------------------------|---------|
| 1   | Battery             | Battery                        | Voltage |
| 2   | FL wheel speed SNSR | Front left wheel speed sensor  | km/h    |
| 3   | FR wheel speed SNSR | Front right wheel speed sensor |         |
| 4   | RL wheel speed SNSR | Rear left wheel speed sensor   |         |
| 5   | RR wheel speed SNSR | Rear right wheel speed sensor  |         |
| 6   | ABS SRI status      | Warning lamp                   | ON/OFF  |
| 7   | Brake SW            | Brake switch                   |         |
| 8   | Motor pump relay    | Motor relay                    |         |
| 9   | Valve relay         | Valve relay                    |         |
| 10  | Motor pump status   | Motor                          |         |
| 11  | FL valve (In)       | Front left valve (In)          |         |
| 12  | FR valve (In)       | Front right valve (In)         |         |
| 13  | RL valve (In)       | Rear left valve (In)           |         |
| 14  | RR valve (In)       | Rear right valve (In)          |         |
| 15  | FL valve (Out)      | Front left valve (Out)         |         |
| 16  | FR valve (Out)      | Front right valve (Out)        |         |
| 17  | RL valve (Out)      | Rear left valve (Out)          |         |
| 18  | RR valve (Out)      | Rear right valve (Out)         |         |

| E : Diagnostic mode                           | Detect timing              | D E                          | 0  | 0   |   | 0  | 0  |
|---|----------------------------|------------------------------|--|---|---|--|--|
| 盲   | t tin                      | 5                            | 0  | 0   |   | 0  | 0  |
| SS  | tec                        | В                            | 0  | 0   |   | 0  | 0  |
| jag   | ۵                          | ٧                            | 0  | 0   |   | 0.   | οF   |
| <u> </u>                                      | ָ<br>נ                     | W/L                          | 0  | 1   | 0   | 0  |  |
| ъ   | V O V                      | WL                           | 0  | 0   | 0   | 0  |  |
| C : ABS control mode D : EBD control mode     | Conditions for Restoration |                              | Vign < 17V   | VigN>10V and VREF>10V continue 224ms. But in case of ABS control mode, all wheels inhibit until end of ABS control. | Vign>9V and VREF>9V continue 70ms   | Restart  |  |
| C: ABS co                                     |                            | ABS control<br>mode          | All wheel<br>inhibit                                   | ABS inhibit   | All wheel<br>inhibit  | System   |  |
| B : Out of control                            | Management                 | EBD control ABS control mode | All wheel<br>inhibit                                   | Continue<br>EBD<br>control  | All wheel<br>inhibit  | System<br>down   |  |
|   |                            | Out of<br>control            | All wheel<br>inhibit                                   | ABS inhibit<br>(permit<br>EBD<br>control)   | All wheel<br>inhibit  | System<br>down   | `  |
| <b>ON</b> Detect timing A: Initial check mode |                            | Condition for Detection      | When Vign>18V continue 224ms, ECU detects the failure. | Voltage drop When Vign<9V or VREF<9V continues of Vign 224ms, ECU detects the failure.                              | Voltage drop When Vign<7.5V or VREF<7.5V continues of Vign 70ms, ECU detects the failure. (EBD inhibit) | Master CPU always sends a test pulse (about 200s) to valves, and feedback signal returns into master and slave CPU. When feedback signal is not equal to test signal, CPU recognizes the actuator failure. Monitoring time is 56ms. If the CPU detects a voltage drop or overvoltage, failure of the actuator is not detected. |  |
| FAILSAFE SPECIFICATION                        |                            | Detect mode                  | Over voltage of Vign                                   | Voltage drop<br>of Vign   | Voltage drop<br>of Vign<br>(EBD inhibit)  | Interruption<br>or short<br>circuit of<br>actuator   | Interruption<br>or short<br>circuit of<br>main relay |
| FE SP   | (i)                        | Locations                    | Power<br>supply  |   |   | C1604 Actuator   | Main<br>relay  |
| ILSA  |                            | No. DTC                      | C1101  | C1102   |   | C1604  | C2112<br>VREF<<br>6V                                 |
| ΕĀ  |                            | ģ                            | -  |   |   | 2  |  |
|   |                            |                              |  |   |   |  |  |

|                            |   | -:   | <del></del>   |  | · · · · · · · · · · · · · · · · · · ·   | 1  |   |
|----------------------------|---|--|---|--|---|--|---|
| Detect timing              | ш   |  |   |  |   | 0  | 0   |
| ţ                          | 3   |  |   |  |   | 0  | 0   |
| ect                        | 8   |  |   |  |   | 0  | 0   |
| Del                        |   | 0  | 0   |  |   | 0.5  | 0   |
|                            |   | 0  | 0   |  | <del></del>   | 0  | o.<br>*a  |
| 900                        | WL  | 0  | 0   |  |   | 0  | 0   |
| Conditions for Restoration |   | Restart  | Restart   | 11111  |   | Restart  | Restart   |
|                            | ABS control<br>mode   |  | 1   |  |   | System   | Manage-<br>ment C   |
| Management                 | EBD control ABS control mode  | -  | 1   |  |   | System   | Manage-<br>ment B   |
|                            | Out of<br>control   | System<br>down   | System<br>down  |  |   | System   | Manage-<br>ment A   |
|                            | Condition for Detection   | With the initial check, the main CPU checks the functions of sub CPU inhibit signal and custom IC inhibit circuit. | 1) IG-SW<br>ECU checks VREF just after IGN-SW<br>ON, and detects the failure. | OFF voltage is below 2.5V, 105ms over 4.2V (short or leak) | voltage is If the ECU detects unvelow 6V 105ms usual Vign, failure isn't detected | When voltage is below for 224ms, ECU detects the failure. But if the ECU detects a voltage drop or overvoltage, the failure is not detected. | The CPU detects the failure by checking voltage of the wheel speed sensor with a velocity of 0km/h. Sensor voltage is below 0.4V or over 2.7V Monitoring time=196ms |
|                            | Detect mode Interruption or short circuit of inhibit signal Interruption or short circuit of main relay |  |   |  |   |  | Interruption<br>or short<br>circuit of<br>wheel speed<br>sensor   |
|                            | Failure<br>Locations  | Main<br>relay  |   |  |   |  | Wheel speed sensor  |
|                            | o DTC   | C1604  |   |  |   | C112   | FL:<br>C1200<br>FR:<br>C1203<br>RL:<br>C1206<br>RR:<br>C1209  |
|                            | Š.  | ო  |   |  |   |  | 4   |

| 6   | П                            | 0   |   |   | :                 |   |  |
|---|------------------------------|---|---|---|-------------------|---|--|
| Detect timing   | ٥                            | 0   | 0   |   |                   |   | 0  |
| #<br>  #  | ၁                            | 0   | 0   |   |                   | 0   | 0  |
| ¥   | В                            | 0   | 0   | 0   | 0                 |   | 0  |
|   | ∢                            |   |   |   |                   |   | 0  |
|   | EBD<br>W/L                   | O.*   | O.ª   | · · · · · · · · · · · · · · · · · · ·   | O *a              | 0   |  |
|   | ABS<br>W/L                   | 0   | o   |   |                   | 0   | 0  |
|   | Conditions for Restoration   | To meet EC regulations, all wheel sensing inhibits and ABS warning lamp tums on until vehicle velocity > 20km/h after restart.  | To meet EC regulations, all wheel sensing inhibits and ABS warning lamp turns on until vehicle velocity > 20km/h after restart. |   |                   | To meet EC regulations, all wheel sensing inhibits and ABS warning lamp turns on until vehicle velocity > 20km/h after restart. | Restart  |
|   | EBD control ABS control mode | Manage-<br>ment C   | Manage-<br>ment C   | •   | •                 | Manage-<br>ment C   | System<br>down   |
| Management  | EBD control<br>mode          | Manage-<br>ment B   | Manage-<br>ment B   | 1   |                   | •   | System<br>down   |
|   | Out of<br>control            | Manage-<br>ment B   | Manage-<br>ment B   | Manage-<br>ment B   | Manage-<br>ment B |   | System<br>down   |
|   | Condition for Detection      | After wheel velocity changes over 30km/h per 7ms (over 120G), if there is the difference between calibrated wheel velocity and monitoring velocity continuously beyond the constant, ECU detects the failure. | When starting the vehicle, ECU detects the following conditions.  1. VMax ≥ 40km/h and Vret ≤ 0.6 x VMaX Monitoring time 120s.  | When starting the vehicle, ECU detects the following conditions.  1. VMax≥ 40km/h and Vret ≤ 0.6 x VMax Monitoring time 120s.  2. Within the range of 7 to 20km/h, if the wheel speed sensor reports 6 km/h continuously, the ECU will report a failure for that wheel.  3. If the vehicle speed is over 20km/h for 120 seconds but the wheel speed sensor reports 6km/h continuously for the sensor reports 6km/h continuously for the cont |                   | In ABS control, if the pressure decrease mode and hold mode continue, for 14sec., ECU detects the failure.                      | When there are over 32 pulses from the wheel sensor within 7ms, ECU detects the failure. |
| Detect mode Intermittent interruptions or short circuit of sensor. Defect of air gap, or sen- sor wheels, or clearance of bearing Missing |                              |   | Missing<br>sensor signal<br>Too large air<br>gap  | wheel<br>is not<br>installed  |                   | oo large air<br>gap Long<br>term EMI  | Defect of clearance of bearing EMI/IGN noise   |
| Failure<br>Locations<br>Wheel<br>speed<br>sensor  |                              |   |   |   |                   |   |  |
|   | ртс                          | FL:<br>C1201<br>FR:<br>C1204<br>RL:<br>C1207<br>RR:<br>C1210  | FL:<br>C1202<br>FR:<br>C1205  | C1208<br>RR:<br>C1211   |                   |   | C1604  |
| <b> </b>  | ģ                            | 4   |   |   |                   |   | , ,  |
|   |                              | ***************************************   |   |   |                   |   |  |

|               | ш                            |  |  |  |
|---------------|------------------------------|--|--|--|
| Detect timing |                              | 0  | O.t.   | 0  |
| 🖺             | ठ                            | 0  | 0  | 0  |
| §             | 8                            | 0 %  | O ?  | 0  |
| ا گا          | <                            | 050  | 0 ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° °  | 0  |
| - E           |                              |  |  |  |
| ARS           | W/L                          | 0  |  |  |
|               | Conditions for Restoration   | If ECU detects the failure of motor relay output ON or motor lock(see 7-(2)), after checking main relay failure at initial check, ECU unconditionally checks motor and motor relay with motor ON for | 560ms. If ECU detects motor lock, ECU repeats the same check. After that, in case of an unusual condition, ECU recognizes the failure. This step meets the EC regulation.  | Restart  |
|               | ABS control<br>mode          | ABS inhibit  |  |  |
| Management    | EBD control ABS control mode | Continue<br>EBD<br>control   |  |  |
|               | Out of control               | ABS inhibit<br>(permit EBD<br>control  |  |  |
|               | Condition for Detection      | Monitoring VMS, ECU detects the failure.  over 6.5V 1785ms below 6.5V 196ms  When Vign is unusual, ECU does not detect the failure.  | 1. Monitoring decrease of Vws, ECU detects the failure.  Monitoring Vws every 7ms after the, motor relay output changes from ON to OFF.  It is recognized as normal condition in case that ECU detects Vws>5V over 6 times. If it is abnormal, ECU does the same check again with motor ON for 560ms. If it is abnormal again, ECU repeats the same process with motor ON for 553ms. After that, if the state is abnormal again, ECU recognizes the failure.  After initial check, in case that more than predetermined acceleration continues for a fixed period, ECU checks in the same way as the above, with motor ON for 560ms. If that is abnormal, motor ON for 553ms and ECU repeats the same process. After that, in case of abnormal condition, ECU recognizes the failure.  If Vign is abnormal, ECU does not detect the failure. | By comparing the voltage of the motor relay monitor and DIAG signal output from the custom IC, ECU detects the failure. But ECU does not check the failure for 1000ms from the time the motor is turned off. |
|               | Detect mode                  | Interruption<br>or short<br>circuit of<br>motor/motor<br>relay   | Interruption of motor Motor lock   | Failure of<br>motor relay<br>circuit / motor<br>relay over<br>current  |
| :             | Failure<br>Locations         | Motor<br>Motor<br>relay  |  |  |
|               | DTC                          | C2402  |  |  |
|               | ģ                            | 2  |  |  |

| ] § [                                 | D<br>D       | 0   | 0   | 0   |   |  |  |  |
|---------------------------------------|--------------|---|---|---|---|--|--|--|
| etect timi                            |              |   |   | <del></del>   |   |  |  |  |
| etect                                 |              |   |   | 0   |   |  |  |  |
| 1 # L                                 | ပ            |   |   | 0   |   |  |  |  |
| . ~ _                                 | В            |   |   | 0   |   |  |  |  |
|                                       | ٧            | 0   | 0   | 0   |   |  |  |  |
| ABS EBD                               | W/L W/L      | 0   | 0   | 0 0 0   |   |  |  |  |
| ABS                                   | W/L          | 0   | 0   | 0   |   |  |  |  |
| Conditions for Restoration            |              | Restart   | Restart   | Restart   |   |  |  |  |
| Management<br>EBD control ABS control | epom<br>wode | System<br>down  | System  | System<br>down  |   |  |  |  |
| Management<br>EBD control             | mode         | System<br>down  | System<br>down  | System<br>down  |   |  |  |  |
| Out of                                | control      | System<br>down  | System<br>down  | System<br>down  |   |  |  |  |
| Condition for Detection               |              | 1.When ECU starts, main and sub CPU execute the following checks:     a) ECU checks the value of the result of fixed multiplications, whether it becomes the value decided in advance or not.     b) ECU executes read/write for RAM.     c) ECU executes sum check of ROM. | 2. IGN After IGN ON, main and sub CPU communicate each other for syn- chronization. When one or the other CPU can't synchronize within 1sec., the main CPU shuts system down and sub CPU stops running. | 3.Main and sub CPU always execute the following checks. | ECU checks whether the program is finished or not |  |  |  |
| Detect mode                           |              | CPU   |   |   | :   |  |  |  |
| No. DTC Failure Locations 6 C1604 ECU |              |   |   |   |   |  |  |  |
| DTC Failu                             |              |   |   |   |   |  |  |  |
|                                       |              |   |   | _   | o v   |  |  |  |

| <u>ه</u> [                  | Ш                            | 0  |  |
|-----------------------------|------------------------------|--|--|
| Detect timing               | D                            | 0  | 0  |
| ŧ.                          | ပ                            | 0  | 0  |
| e [                         | 8                            | 0  | 0  |
|                             | ٧                            | 0  | 0  |
| EBD<br>W/L                  |                              | 0  | 0  |
| ABS                         | W/L                          | 0  | 0  |
| Conditions for Restoration  |                              | Restart  | Restart  |
|                             | ABS control<br>mode          | System<br>down   | System   |
| Management                  | EBD control ABS control mode | System<br>down   | System   |
|                             | Out of<br>control            | System   | System   |
| Condition for Detection     |                              | <ol> <li>In every program cycle, the main CPU<br/>and sub CPU communicate with each<br/>other for synchronization. When one or<br/>the other can't synchronize within 300μ<br/>sec, main CPU shuts the system down<br/>and sub CPU stops running.</li> </ol> | <ul> <li>5. Sub CPU checks the following:</li> <li>a) Sub CPU always compares the result of analog sent by main CPU with the result of data calculated by sub CPU, in case that there is a difference above 7 bits for 112ms, ECU recognizes the failure.</li> <li>b) In case that wheel velocity of FL calculated by main CPU is different from that calculated by sub CPU above 10km/h for 504ms, ECU recognizes the failure.</li> <li>c) Sub CPU calculates the slip from Vref calculated by main CPU and wheel velocity of FL calculated by sub CPU.</li> <li>ECU recognizes a failure when the main CPU judges ABS phase as pressure decrease phase for 1sec. with no slip calculated by sub CPU does not judge ABS phase as pressure decrease phase, in that case the main CPU sets the valves as pressure decrease state for 1 sec., ECU recognizes the failure.</li> <li>e)When main CPU judges ABS phase as out of ABS control, in which case the valve driven information from main CPU is in a pressure hold state for 1 sec., ECU recognizes the failure.</li> </ul> |
| Detect mode                 |                              | CPU<br>failure   |  |
| Failure<br>Locations<br>ECU |                              |  |  |
|                             | ртс                          | C1604  |  |
|                             | <u> </u>                     | 9  |  |

\*1 In case of main relay ON only
\*2 In case of motor initial check only, ECU detects the failure of motor relay output ON.
\*3 In case of motor initial check only
\*4 In case of over two wheels failure

**BR** -58

## Management A

| Conditions   | Management   |
|--|--------------|
| Vmax > 5km/h   | Management B |
| Vmax < 5km/h One front wheel failure detected causes ABS inhibit       |              |
| One rear wheel or more than two wheels failure causes all wheels to in |              |

#### Management B

| Conditions                 | Management                       |
|----------------------------|----------------------------------|
| Failure of one wheel       | ABS inhibit (permit EBD control) |
| Failure of over two wheels | System down                      |

#### Management C

| Conditions Management        | Management   |
|------------------------------|--|
| Failure of one front wheel   | ECU discontinues ABS control of defective wheel and continues ABS control of     |
|                              | normal wheels. ABS inhibit after end of ABS control.                             |
| Failure of two front wheels  | ECU discontinues ABS control of defective wheel and continues ABS control of     |
|                              | normal wheels. System down after end of ABS control.                             |
| Failure of one rear wheel    | ECU continues ABS control of rear wheels using information of normal rear        |
|                              | wheel and front wheels. System down after end of ABS control.                    |
| Failure of two rear wheels   | System down  |
| Failure of one front wheel   | ECU discontinues ABS control of defective front wheel, and continues rear wheels |
| and one rear wheel           | using information of normal rear wheel. System down after end of ABS control.    |
| Failure of over three wheels | System down  |

# **ADDITIONAL EXPLANATION OF FAILSAFE**

- 1. Warning lamp initial lighting time
  - 1) Immediately after IG-SW ON, warning lamp is lit for 3 sec. This term is called 'warning lamp initial lighting time'.
  - 2) Within this term, in case that the ECM detects the failure, warning lamp is lighted continuously.

#### NOTE

## 1. System down

The system changes to normal braking with warning lamp ON after detecting the failure by its software. ECM restart is caused by IG-SW OFF  $\rightarrow$  ON once.

After the failure is corrected, the ECM returns a to normal mode with warning lamp OFF.

#### 2. All wheel inhibit


ECM discontinues ABS control of all wheels. (Equivalent to normal brake) When the failure is corrected, it returns to normal mode with warning lamp OFF. (But during ABS control, it does not return to a normal mode.)

#### **TERM COMMENTARY**

VIGN : Terminal voltage of IGN, VREF : Terminal voltage of REF VMAX : Maximum wheel velocity, Vref : estimated vehicle velocity


# SCHEMATIC DIAGRAM EJBB265

# **ABS CIRCUIT (1)**




**BRAKE SYSTEM** 

# **ABS CIRCUIT (2)**




# **ABS CIRCUIT (3)**



EJBB265C


# INSPECTION PROCEDURE FOR DIAGNOSTIC TROUBLE CODES EJBB2700

| DTC No. C1200, C1203, C1206, C1209<br>Wheel speed sensor open or short to GND circuit                          | Probable cause   |
|--|--|
| The HECU determines that an open or short circuit has occured in more than one wire of the wheel speed sensors | <ul> <li>Malfunction of wheel speed sensor</li> <li>Malfunction of wiring harness or connector</li> <li>Malfunction of HECU</li> </ul> |




EJBB270A

| DTC No. C1201, C1204, C1207, C1210 (Speed jump or wrong exciter)                    | Probable cause  |
|---|---|
| A wheel speed sensor outputs an abnormal signal (other than an open short-circuit). | <ul> <li>Improper installation of wheel speed sensor</li> <li>Malfunction of wheel speed sensor</li> <li>Malfunction of rotor</li> <li>Malfunction of wheel bearing</li> <li>Malfunction of wiring harness or connector</li> <li>Malfunction of HECU</li> </ul> |



EJBB275A

| DTC No. C1202, C1205, C1208, C1211 (Large air gap) | Probable cause  |
|--|---|
| A wheel speed sensor outputs no signal             | <ul> <li>Malfunction of wheel speed sensor</li> <li>Improper installation of wheel speed sensor</li> <li>Malfunction of rotor (excitor)</li> <li>Malfunction of wiring harness or connector</li> <li>Malfunction of HECU</li> </ul> |




EJBB280A

| DTC No. C1101, C1102 Voltage out of range (Low and over voltage)  | Probable cause   |
|---|--|
| The voltage of the HECU power supply drops lower than or rises higher than the specified value. If the voltage returns to the specified value, this code is no longer output. | <ul> <li>Malfunction of wiring harness or connector</li> <li>Malfunction of HECU.</li> </ul> |



# / CAUTION

If battery voltage drops or rises during inspection, this code will be output as well. If the voltage returns to the standard value, the code is no longer output. Before carrying out the following inspection, check the battery level and refill if necessary.




EJBB285A

**EJHA2900** 

| DTC No. C1604 ECU Hardware (EEPROM and ECU failure)  | Probable cause  |
|--|---|
| The HECU always monitors the solenoid valve drive circuit. It determines that there is an open or short-circuit in the solenoid coil or in a harness even if no current flows in the solenoid or through the HECU. | <ul> <li>Malfunction of wiring harness</li> <li>Malfunction of hydraulic unit</li> <li>Malfunction of HECU</li> </ul> |

EJHA2950

| DTC No. C2112 Valve relay (Including fuse failure)  | Probable cause  |
|---|---|
| When the ignition switch is turned ON, the HECU switches the valve relay off and on during the initial check. In that way, the HECU compares the signals sent to the valve relay with the voltage in the valve power monitor line. That is how to check if the valve relay is operating normally. The HECU always checks if current flows in the valve power monitor line. It determines that there is an open circuit when no current flows. If no current flows in the valve power monitor line, this diagnosis code is output. | <ul> <li>Malfunction of wiring harness or connector</li> <li>Malfunction of HECU</li> </ul> |




EJFA029B

| DTC No. C2402 Electrical (Motor relay, motor)   | Probable cause  |
|---|---|
| When the motor power line is normal but no signal is input to the motor monitor line, it is abnormal. | <ul><li>Malfunction of hydraulic unit</li><li>Malfunction of HECU</li></ul> |



Because powering of the motor with the Hi-Scan or Hi-Scan Pro 3will discharge the battery, the engine should be run for a while after testing is completed.




EJBB300A

# ABS WARNING LAMP INSPECTION EJHASOR

Check that the ABS warning lamp illuminates as follows.

When the ignition key is turned "ON", the ABS warning lamp comes on for approximately 2 seconds and then goes out.



ERHA003A

# INSPECTION CHART FOR TROUBLE SYMPTOMS EJHA3100

Find out the symptoms and check according to the inspection procedure chart.

| Trouble system   |   | Inspection procedure No. |  |
|--|---|--------------------------|--|
| Communication with Hi-Scan is not possible                   | Communication with any system is not possible.                    | 1                        |  |
|  | Communication with ABS only is not possible.                      | 2                        |  |
| When the ignition key is turne warning lamp does not illumin | d "ON" (engine stopped), the ABS ate.                             | 3                        |  |
| After the engine starts, the lan                             | np remains illuminated.   | 4                        |  |
| Faulty ABS operation   | Unequal braking power on both sides                               | 5                        |  |
|  | Insufficient braking power  |                          |  |
|  | ABS operates under normal braking conditions                      |                          |  |
|  | ABS operates before vehicle stops under normal braking conditions |                          |  |
|  | Large brake pedal vibration (Caution 2.)                          | -                        |  |



During ABS operation, the brake pedal may vibrate or may not be able to be depressed. Such phenomena are due to intermittent changes in hydraulic pressure inside the brake line to prevent the wheels from locking and is not an abnormality.


# INSPECTION PROCEDURE FOR TROUBLE SYMPTOMS EJBB3150

# **INSPECTION PROCEDURE 1**

| Communication with Hi-Scan is not possible. (Communication with all systems is not possible.)         | Probable cause   |  |
|---|--|--|
| The reason is probably a defect in the power supply system (including ground) for the diagnosis line. | <ul><li>Malfunction of connector</li><li>Malfunction of wiring harness</li></ul> |  |

# **INSPECTION PROCEDURE 2**


| Communication with Hi-Scan is not possible. (Communication with ABS only is not possible.)   | Probable cause  |  |
|--|---|--|
| When communication with Hi-Scan is not possible, the cause is probably an open circuit in the HECU power circuit or an open circuit in the diagnosis output circuit. | <ul><li>Blown fuse</li><li>Malfunction of wiring harness or connector</li><li>Malfunction of HECU</li></ul> |  |



EJBB315A

#### **INSPECTION PROCEDURE 3**

| When the ignition key is turned "ON" (engine stopped), ABS warning lamp does not illuminate   | Probable cause  |  |
|---|---|--|
| When current flows through the HECU, the ABS relay turns from on to off as the initial check. The ABS warning lamp will illuminate when the ABS relay is "Off" even if there is a problem with the circuit between the ABS warning lamp and the HECU.                             | <ul> <li>Blown fuse</li> <li>Burnt out ABS warning lamp bulb</li> <li>Malfunction of wiring harness or connector</li> </ul> |  |
| Therefore, if the lamp does not illuminate, the cause may be an open circuit in the lamp power supply circuit, a blown bulb, or an open circuit in both the circuits between the ABS warning lamp and the HECU and in the circuit between the ABS warning lamp and the ABS relay. |   |  |




EJBB315B

#### **INSPECTION PROCEDURE 4**

| Even after the engine is started, the ABS warning lamp remains illuminated         | Probable cause   |  |
|--|--|--|
| The cause is probably a short-circuit in the ABS warning lamp illumination circuit | <ul><li>Malfunction of combination meter</li><li>Malfunction of HECU</li><li>Malfunction of wiring harness</li></ul> |  |


This trouble symptom is limited to cases where communication with the Hi-Scan is possible (HECU power supply is normal) and the diagnosis code is normal.



EJBB315C

#### **INSPECTION PROCEDURE 5**

| Brake operation is abnormal  | Probable cause   |   |  |
|--|--|---|--|
| This varies depending on driving conditions and road surface conditions, so problem diagnosis is difficult.  However, if a normal diagnosis code is displayed, carry out the following inspection. | <ul> <li>Improper installation of wheel<br/>speed sensor</li> <li>Incorrect sensor harness<br/>contact</li> <li>Foreign material adhering to<br/>wheel speed sensor</li> </ul> | <ul> <li>Malfunction of wheel speed sensor</li> <li>Malfunction of rotor</li> <li>Malfunction of wheel bearing</li> <li>Malfunction of hydraulic unit</li> <li>Malfunction of HECU</li> </ul> |  |



EJBB315D

#### BLEEDING OF BRAKE SYSTEM EJBB35

This procedure should be used to insure adequate bleeding and filling of ABS unit, brake lines, master cylinder.

 Remove the reservoir cap and fill the brake reservoir with brake fluid.


# / CAUTION

Do not allow brake fluid remain on a painted surface. Wash it off immediately.

# **NOTE**


When bleeding by pressured fluid, do not depress the brake pedal.

Recommended fluid......DOT3 or equivalent




EJA9003A

Connect the clear plastic tube to the wheel cylinder bleeder plug and insert the other end of tube in a half filled clear plastic bottle.



EJBB356A

Connect Hi-Scan to Data Link Connector located underneath the dash panel.



EJBB356B

 Select and operate according to the instruction on the Hi-Scan screen.

# A CAUTION

You have to obey maximum operating time (60sec) of ABS motor with Hi-Scan to prevent motor pump burnt.

1) Select hyundai vehicle diagnosis.

0. INITIAL SCREEN

61. HYGNBAL VEHTCHE DIAGLOSIS

02. TOOL BOX

03. CARB OBD-II DIAGNOSIS

04. FLIGHT RECORD REVIEW

05. SYSTEM SETUP

EJBB356C

Select Anti-Lock brake system.

1. HYUNDAI VEHICLE DIAGNOSIS

MODEL: XG ALL
SYSTEM: ANTI-LOCK BRAKE SYSTEM

01. ENGINE V6-DOHC

02. AUTOMATIC TRANSAXLE

03. ANTI LOCK BRAKE SYSTEM

04. SRS-AIRBAG

EJBB356D

3) Select air bleeding mode.


# 1. HYUNDAI VEHICLE DIAGNOSIS MODEL : XG ALL SYSTEM : ANTI-LOCK BRAKE SYSTEM

01. DIAGNOSTIC TROUBLE CODES

- 02. CURRENT DATA
- \_\_\_\_\_
- 03. FLIGHT RECORD
- 04. ACTUATION TEST
- 05. SIMU-SCAN

EJBB356E

Press 'YES' to operate motor pump and solenoid valve.



EJBB356F

ON' and 'OFF' controls are automatically perfomed to prevent the motor pump from being burnt. (If not, you may damage the motor)


# 1.6 AIR BLEEDING MODE ABS AIR BLEEDING STATUS 0.1 SOLENOID VALVE STATUS OPEN 02. MOTOR PUMP STATUS ON TIME : 2SEC

EJBB356G

- Pump the brake pedal several times, and then loosen the bleeder screw until fluid starts to run out without bubbles. Then close the bleeder screw.
- Repeat the step 5. until there are no more bubbles in the fluid for each wheel in the sequence shown in the illustration.
- 7. Tighten the bleeder screw.

# Bleeder screw tightening torque


7-9 Nm (70-90 kg·cm, 5-6.6 lb·ft)



EJA9004A

# **ANTI-LOCK BRAKING SYSTEM CONTROL MODULE**


# COMPONENTS EJHA3200



#### EJHA040A

# REMOVAL EJHA3250

Disconnect the HECU (Hydraulic and electronic Control Unit) and motor connector.



EJHA022A

EJHA045A

3. Remove the HECU bracket mounting bolt and the HECU.




# /!\ CAUTION

1. Never attempt to disassemble the HECU.

Disconnect the brake lines from the HECU.

2. The HECU must be transported and stored in the upright position and with sealed ports. The HECU must not be drained.



EJHA045A

# INSTALLATION EJHA3300

- 1. Follow the reverse order for removal.
- 2. Tighten the modulator mounting bolts and brake tube nuts to the specified torque.

# **Tightening toque**

**HECU** mounting bolt:

8-10 Nm (80-100 kg·cm, 5.6-6.9 lb·ft)

Brake tube nut:

13-17 Nm (130-170 kg·cm, 9-12 lb·ft)

# ANTI-LOCK BRAKING SYSTEM **MODULATOR**

# HYDRAULIC MODULE INSPECTION EJHA3600



## /!\ CAUTION

Turn the ignition switch off before connecting or disconnecting the Hi-Scan.

Jack the vehicle up and support the vehicle with rigid racks at the specified jack-up points or replace the wheels which are checked on the rollers of the braking force tester.




# /!\ CAUTION

- The roller of the braking force tester and the tire should be dry during testing.
- 2. When testing the front brakes, apply the parking brake, and when testing the rear brakes, stop the front wheels by chocking them.
- Release the parking brake and feel the drag force (drag torque) on each road wheel. When using the braking force tester, take a reading of the brake drag force.
- Turn the ignition key "OFF" and set the Hi-Scan or Hi-Scan Pro as shown in the diagram.
- 4. After checking that the shift lever <M/T> or the selector lever <A/T> is in neutral, start the engine.



If the ABS is in fail-safe mode, the Hi-Scan actuator test cannot be used.


Use the Hi-Scan to force-drive the ABS actuator.



ERHA006A

# **ANTI-LOCK BRAKING SYSTEM** WHEEL SPEED SENSOR

# COMPONENTS EJHA3350




EJHA055A


## REMOVAL EJHA3400

## **FRONT WHEEL SPEED SENSOR**

1. Remove the front wheel speed sensor mounting bolt.




Remove the front wheel speed sensor after disconnecting the wheel speed sensor connector.



EJHA023B

#### **REAR WHEEL SPEED SENSOR**

Remove the rear wheel speed sensor after disconnecting the wheel speed sensor connector.




KFW8060A

# INSPECTION EJBB3450

 Connect an ohmmeter between the wheel speed sensor terminals and measure the resistance.

#### Service standard

Front :  $1385 \pm 110\Omega$ Rear :  $1385 \pm 110\Omega$ 




EJA9031E

Connect a voltmeter between the wheel speed sensor terminals and measure the voltage by turning the wheel.



Set the voltmeter to measure AC voltage. Service standard : AC voltage detected.



EJA9031F

## ABS OPERATION CHECK EJHA3550

# WHEEL SPEED SENSOR OUTPUT VOLTAGE CHECK

- 1. Lift the vehicle up and release the parking brake.
- 2. Disconnect the HECU harness connector and measure from the harness side connector.



Be sure to remove the connector double lock and insert the probe into the harness side. Inserting it into the terminal side will result in a bad connection.

3. Rotate the wheel to be measured at approximately 1/2–1 rotation per second, and check the output voltage using a circuit tester or an oscilloscope.

| Wheel<br>speed<br>sensor | Front left | Front right | Rear left | Rear<br>right |
|--------------------------|------------|-------------|-----------|---------------|
| Terminal                 | 1          | 19          | 5         | 22            |
| No.                      | 2          | 20          | 6         | 23            |

#### **Output voltage**

When measuring with an oscilloscope: 130 mV peak-to-peak or more