




Service Manual

ELECTRICAL



ECLIPSE

Service Manual

ECLIPSE

1992-1993-1994

Volume 2 Electrical

FOREWORD

This Service Manual has been prepared with the latest service information available at the time of publication. It is subdivided into various group categories and each section contains diagnosis, disassembly, repair, and installation procedures along with complete specifications and tightening references. Use of this manual will aid in properly performing any servicing necessary to maintain or restore the high levels of performance and reliability designed into these outstanding vehicles.



Mitsubishi Motors Corporation reserves the right to make changes in design or to make additions to or improvements in its products without imposing any obligations upon itself to install them on its products previously manufactured.

GROUP/SECTION INDEX

General

Fusible Link, Fuse and IOD or
Storage Connector Location

Inspection Terminal Location

Grounding Location

Relay Location

Sensor Location

Control Unit Location

Solenoid, Solenoid Valve Location

Diode Location

Junction Block

Centralized Junction

Harness Connector Inspection

Troubleshooting

Configuration Diagrams

Circuit Diagrams

Engine Electrical

Chassis Electrical

Alphabetical Index


16

54

NOTE: For Engine, Chassis & Body,
refer to Volume-1
"Engine, Chassis & Body".

FUSIBLE LINK, FUSE AND IOD OR STORAGE CONNECTOR LOCATION





<Engine compartment>





Name	Symbol
Dedicated fuses	B*, D
IOD or storage connector	C
Main fusible links	A
Multi-purpose fuse block	E
Sub fusible links	C

NOTE

- (1) *: Air conditioning equipped models.
- (2) For details of fusible link and fuse, refer to P.18, 19, 20.
- (3) The "Name" column is arranged in alphabetical order.



<Interior>







INSPECTION TERMINAL LOCATION

Name	Symbol	Name	Symbol
Data link connector	E	Oxygen sensor check connector <2.0L DOHC Engine>	D
Fuel pump check connector	A	Terminal for detecting the engine revolution speed <2.0L DOHC Engine>	C
Ignition timing adjustment connector	B		




NOTE

The "Name" column is arranged in alphabetical order.

<Engine compartment>









<Interior>







GROUNDING LOCATION




<Engine compartment>






<Interior—Front section>



<Interior—Rear section and luggage compartment>



NOTE
The ground point indicated by the * symbol is applicable to models equipped with ABS.




RELAY LOCATION

Name	Symbol	Name	Symbol
ABS motor relay	B	Generator relay	A
ABS power relay	H	Headlight relay	A
ABS valve relay	B	Heater relay	E
Automatic seat belt motor relay	I	Intermittent wiper relay (rear wiper)	I
Blower motor High relay	G	Intermittent wiper relay (windshield wiper)	F
Condenser fan motor High-Low select relay	C	Magnet clutch relay	C
Condenser fan motor relay	C	Power window relay	A
Dome light relay	I	Radiator fan motor relay	A
Door lock relay	D	Starter relay	D
Fog light relay	A	Taillight relay	A






NOTE







The "Name" column is arranged in alphabetical order.

Engine compartment



Interior





SENSOR LOCATION


Name	Symbol	Name	Symbol
Air inlet sensor	I	ISC motor position sensor	C
Air thermo sensor	I	Intake air temperature sensor	A
Barometric pressure sensor	A	Knock sensor	G
Camshaft position sensor	D	Oxygen sensor	E
Crankshaft position sensor	D	Rear speed sensor	L
Engine coolant temperature sensor	F	Throttle position sensor	B
Front speed sensor	J	Vehicle-speed sensor (Reed switch)	H
G-sensor	K	Volume air flow sensor	A

NOTE


The "Name" column is arranged in alphabetical order.

Engine compartment




1.8L Engine














2.0L DOHC Engine <Non-Turbo>




2.0L DOHC Engine <Turbo>













Interior



16A0734














CONTROL UNIT LOCATION

Name	Symbol
4-speed automatic transaxle control module	D
Air conditioning control unit	B
Anti-lock brake control unit	G
Automatic seat belt control unit	F
Door lock control unit	C
Engine control module	E
Auto-cruise control unit	A

NOTE
The "Name" column is arranged in alphabetical order.

Interior





SOLENOID, SOLENOID VALVE LOCATION


Name	Symbol
4-speed automatic transaxle control solenoid valve	A
EGR solenoid	B
Evaporative emission purge solenoid	B, C
Fuel pressure solenoid	C
Turbocharger waste gate solenoid	C

NOTE


The "Name" column is arranged in alphabetical order.

Engine compartment




1.8L Engine





2.0L DOHC Engine <Non-Turbo>



2.0L DOHC Engine <Turbo>








DIODE LOCATION

<Interior-Rear section>

Name	Symbol
Diode (for ABS circuit)	A
Diode (for door ajar-warning circuit)	B


NOTE

The "Name" column is arranged in alphabetical order.



JUNCTION BLOCK


M168C-




16A1331-AD-UTTOR-II

Front side

Reverse side



16A1331



16A1385

Remarks

- (1) Same alphabets in the diagram indicate the counterparts of connectors.
- (2) Terminals of the harness side connector are indicated in parentheses ().


CENTRALIZED JUNCTION

M1685-

MAIN FUSIBLE LINK (direct connection to battery's positive ⊕ terminal)


No.	Circuit	Housing color	Rated capacity (A)
1	MFI circuit	Blue	20
2	Radiator fan motor circuit	Pink	30
3	Ignition switch circuit	Pink	30
4	ABS circuit	Yellow	60

<Vehicles without ABS>



16A0893


<Vehicles with ABS>



16A1197

SUB FUSIBLE LINK (relay box inside engine compartment)


No.	Circuit	Housing color	Rated capacity (A)
1	Generator circuit, sub fusible link ②, ③, ④, ⑤, ⑥	Black	80
2	Defogger circuit	Green	40
3	Automatic seatbelt circuit, dedicated fuse ⑤ circuit	Pink	30
4	Generator circuit	Pink	30
5	Power window circuit	Pink	30
6	Multi-purpose fuse ①, ⑥, ⑬, ⑭, ⑮, ⑯, ⑰, ⑱, dedicated fuse ④ circuit	Green	40
7	Headlight circuit, dedicated fuse ①, ③, ⑥ circuit	Green	40



16A1330

MULTI-PURPOSE FUSE (inside junction block)

Power supply circuit		No.	Rated capacity (A)	Load circuit
Battery		1	10	Automatic seat belt control unit, buzzer assembly, fog light relay, key reminder switch
Ignition switch	IG ₂	2	—	—
		3	10	Air conditioning control unit, air conditioning switch, blower switch, defogger timer, heater relay, power window relay, ABS relay
	ACC	4	10	Radio, motor antenna
		5	15	Cigarette lighter, remote controlled mirror
Battery		6	15	Door lock relay, door lock control unit
Ignition switch	IG ₂	7	10	A/T fluid temperature warning light, 4-speed automatic trans-axle control module, auto-cruise control unit <A/T>
		8	—	—
	ACC	9	15	Intermittent wiper relay, wiper motor, washer motor
		10	10	Headlight relay, horn
	IG ₁	11	10	Auto-cruise control unit, auto-cruise control actuator, automatic seat belt control unit, buzzer assembly, combination meter, motor antenna, seat belt warning light
		12	10	Turn-signal and hazard flasher unit
Battery		13	—	—
		14	—	—
		15	—	—
		16	30	Blower motor
		17	15	ABS power relay, stop light
Ignition switch	IG ₁	18	10	Back-up light, dome light relay
Battery		19	10	4-speed automatic transaxle control module, dome light, door-ajar warning light, foot light, ignition key illumination light, luggage compartment light, MFI control unit, radio, ABS relay, motor antenna, automatic seat belt control unit, ABS control unit, door lock control unit




16A0805

TSB Revision

DEDICATED FUSE


Power supply circuit	No.	Rated capacity (A)	Housing color	Circuit
Sub fusible link ⑦	1	10	Red	Taillight circuit
Battery	2	10	Red	Hazard warning light circuit
Headlight relay	3	10	Red	Upper beam circuit
Sub fusible link ⑥	4	10	Red	Air conditioning magnetic clutch circuit
Sub fusible link ③	5	20	Yellow	Condenser fan motor circuit
Sub fusible link ⑦	6	15	Blue	Fog light circuit

<Engine compartment R.H. side relay box>



16A1330

<Engine compartment L.H. side relay box (air conditioning equipped models)>



Dedicated fuse

16A0896


CENTRALIZED RELAY

Classification		Name	Classification		Name
Engine compartment R.H. side relay box	A-01X	IOD or storage connector	Engine compartment L.H. side relay box	A-17X	Condenser fan motor high-low changeover relay
	A-02X	Taillight relay		A-18X	Condenser fan motor relay
	A-03X	Headlight relay		A-19X	Magnetic clutch relay
	A-04X	Power window relay	Interior relay box	C-31X	Door lock relay
	A-05X	Fog light relay		C-32X	Starter relay <M/T>
	A-06X	Radiator fan motor relay		C-33X	Defogger timer
	A-07X	Generator relay			


NOTE

IOD: Ignition Off Draw


<Engine compartment R.H. side relay box>



<Engine compartment L.H. side relay box (air conditioning equipped models)>



<Interior relay box>



CONFIGURATION DIAGRAMS

CONTENTS

M16VA--


Dash Panel	44	Engine Compartment <2.0L DOHC Engine (Turbo)>	40
Engine and Transaxle <1.8L Engine>	42	How to Read Configuration Diagrams	35
Engine and Transaxle <2.0L DOHC Engine>	43	Instrument Panel and Floor Console	47
Engine Compartment <1.8L Engine>	36	Interior	48
Engine Compartment <2.0L DOHC Engine (Non-Turbo)>	38	Overall Configuration Diagram	34



CONFIGURATION DIAGRAMS

OVERALL CONFIGURATION DIAGRAM

M16VB--



16A1333

NOTE

- (1) This illustration shows only the major wiring harness.
- (2) *¹ indicates also equipped at the right side.
- (3) *² indicates vehicles with ABS.

HOW TO READ CONFIGURATION DIAGRAMS

The wiring diagrams are prepared in such a way that the arrangement of connectors for each vehicle, and the routing of each harness, can be easily understood for each individual wiring section.

Indicates the connector number.

The connector number used is the same number as that used for circuit diagrams; these numbers facilitate the location of the connector positions.

The alphabet letter used as the prefix represents the wiring section in which that connector is used; subsequent numerals make up the number that indicates particular characteristics of that individual connector. As a general rule, numbers are assigned clockwise around the wiring diagram.

Note that, if there is a concentration of connectors with the same form (same number of pins), the connectors' colors are noted in order to facilitate identification.

Example: A-12 (Black)

Connector color

Number indicating the connector's characteristics (series number)

Symbol indicating wiring section location of the connector


A: Engine compartment

B: Engine and transaxle

C: Dash panel

D: Instrument panel and floor console

E: Interior




Indicates ground point.

The ground number used is the same number as that used for circuit diagrams; these numbers facilitate the location of the ground points. For detailed information concerning ground points, refer to P.4.

Represents the part concealed by corrugated tubing.

ENGINE COMPARTMENT <1.8L Engine>

Connector
symbol**A**

A-01X IOD or storage connector

A-02X Taillight relay

A-03X Headlight relay

A-04X Power window relay

A-05X Fog light relay

A-06X Radiator fan motor relay

A-07X Generator relay

A-08 Dual pressure switch
(for air conditioning circuit)

A-09 Wiper motor

A-10 Control wiring harness and battery cable
assembly combination

A-11 Auto-cruise control vacuum pump

A-12 Brake fluid level sensor

A-13 —

A-14 Evaporative emission purge solenoid

A-15 —

A-16 EGR solenoid
(Vehicles for California)Refer to
CENTRALIZED
JUNCTION

A-17X Condenser fan motor

A-18X high-low changeover relay

A-19X Condenser fan motor relay

A-20X Magnetic clutch relay

A-21X Condenser

A-22 Air conditioning relay box

A-23 —

A-24 Washer motor

A-25 Front side marker light (Left side)

A-26 Headlight (Left side)

A-27 Horn (Left side)

A-28 —



A-29 —

A-30 Fog light (Left side)

A-31 Condenser fan motor
(for air conditioning circuit)

A-32 Front combination light (Left side)

Refer to
CENTRALIZED
JUNCTION
(for air
conditioning
circuit)




- A-33 —
- A-34 —
- A-35 Volume air flow sensor
- A-36 Automatic transaxle fluid temperature sensor*1
- A-37 Kickdown servo switch <A/T>*1
- A-38 Pulse generator <A/T>
- A-39 Radiator fan assembly
- A-40 Front combination light (Right side)
- A-41 Radiator water level switch
- A-42 Fog light (Right side)
- A-43 —
- A-44 } Horn (Right side)
- A-45 }
- A-46 Headlight (Right side)
- A-47 Front side marker light (Right side)
- A-48 —

- A-49 } Control wiring harness and engine
- A-50 } compartment wiring harness combination
- A-51 —
- A-52 Fuel pump check connector
- A-53 Noise condenser
- A-54 Defogger relay
- A-55 —
- A-56 —
- A-57 Ignition timing adjustment connector

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: 1), refer to P. 4.
- (3) "—" means that the connector with code-number is not used.
- (4) IOD : Ignition Off Draw
- (5) *1: 1992 models

ENGINE COMPARTMENT <2.0L DOHC Engine (Non-Turbo)>





A-01X IOD or storage connector
 A-02X Taillight relay
 A-03X Headlight relay
 A-04X Power window relay
 A-05X Fog light relay
 A-06X Radiator fan motor relay
 A-07X Generator relay
 A-08 Dual pressure switch
 (for air conditioning circuit)
 A-09 Wiper motor
 A-10 Control wiring harness and battery cable
 assembly combination
 A-11 Auto-cruise control vacuum pump
 A-12 Brake fluid level sensor
 A-13 —
 A-14 Evaporative emission purge solenoid
 A-15 —
 A-16 EGR solenoid
 (Vehicles for California)

Refer to
CENTRALIZED
JUNCTION

A-17X Condenser fan motor
 high-low changeover relay
 A-18X Condenser fan motor relay
 A-19X Magnetic clutch relay
 A-20X Condenser
 A-21 } Air conditioning relay box
 A-22 }
 A-23 ABS front speed sensor (Left side)
 A-24 Washer motor
 A-25 Front side marker light (Left side)
 A-26 Headlight (Left side)
 A-27 } Horn (Left side)
 A-28 }
 A-29 —
 A-30 Fog light (Left side)
 A-31 Condenser fan motor
 (for air conditioning circuit)
 A-32 Front combination light (Left side)

Refer to
CENTRALIZED
JUNCTION
(for air
conditioning
circuit)



36A0271



- A-33 } Hydraulic unit
- A-34 } Volume air flow sensor
- A-35 } Automatic transaxle fluid temperature sensor*1
- A-36 } Kickdown servo switch <A/T>*1
- A-37 } Pulse generator <A/T>
- A-38 } Radiator fan assembly
- A-39 } Front combination light (Right side)
- A-40 } Radiator water level switch
- A-41 } Fog light (Right side)
- A-42 } —
- A-43 } —
- A-44 } Horn (Right side)
- A-45 } Headlight (Right side)
- A-46 } Front side marker light (Right side)
- A-47 } —
- A-48 } —

- A-49 } Control wiring harness and engine
- A-50 } compartment wiring harness combination
- A-51 } ABS front speed sensor (Right side)
- A-52 } Fuel pump check connector
- A-53 } Noise condenser
- A-54 } Defogger relay
- A-55 } —
- A-56 } Engine speed adjustment connector
- A-57 } Ignition timing adjustment connector

Remarks



- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: 1), refer to P. 4.
- (3) "—" means that the connector with code-number is not used.
- (4) The wiring indicated by the *1 symbol is applicable to vehicles with ABS and the wiring indicated by the *2 symbol is applicable to vehicles without ABS.
- (5) IOD : Ignition Off Draw
- (6) *1: 1992 models

ENGINE COMPARTMENT <2.0L DOHC Engine (Turbo)>



A-01X	IOD or storage connector	Refer to CENTRALIZED JUNCTION
A-02X	Taillight relay	
A-03X	Headlight relay	
A-04X	Power window relay	
A-05X	Fog light relay	
A-06X	Radiator fan motor relay	
A-07X	Generator relay	
A-08	Dual pressure switch (for air conditioning circuit)	
A-09	Wiper motor	
A-10	Control wiring harness and battery cable assembly combination	
A-11	Auto-cruise control vacuum pump	
A-12	Brake fluid level sensor	
A-13	Control wiring harness and solenoid valve harness assembly combination	
A-14	Evaporative emission purge solenoid	
A-15	Fuel pressure solenoid valve	
A-16	EGR solenoid (Vehicles for California)	

A-17X	Condenser fan motor high-low changeover relay	} Refer to CENTRALIZED JUNCTION (for air conditioning circuit)
A-18X	Condenser fan motor relay	
A-19X	Magnetic clutch relay	
A-20X	Condenser	
A-21	} Air conditioning relay box	
A-22		
A-23	ABS front speed sensor (Left side)	
A-24	Washer motor	
A-25	Front side marker light (Left side)	
A-26	Headlight (Left side)	
A-27	} Horn (Left side)	
A-28		
A-29	—	
A-30	Fog light (Left side)	
A-31	Condenser fan motor (for air conditioning circuit)	
A-32	Front combination light (Left side)	




- A-33 Hydraulic unit
- A-34 Volume air flow sensor
- A-35 Automatic transaxle fluid temperature sensor
- A-36 Kickdown servo switch <A/T>*1
- A-37 Pulse generator <A/T>
- A-38 Radiator fan assembly
- A-39 Front combination light (Right side)
- A-40 Radiator water level switch
- A-41 Fog light (Right side)
- A-42 —
- A-43 Horn (Right side)
- A-44 Headlight (Right side)
- A-45 Front side marker light (Right side)
- A-46 Turbocharger waste gate solenoid
- A-47 Control wiring harness and engine compartment wiring harness combination
- A-48
- A-49
- A-50

- A-51 ABS front speed sensor (Right side)
- A-52 Fuel pump check connector
- A-53 Noise condenser
- A-54 Defogger relay
- A-55 Resistor
- A-56 Engine speed adjustment connector
- A-57 Ignition timing adjustment connector

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: [1]), refer to P. 4.
- (3) The wiring indicated by the *1 symbol is applicable to vehicles with ABS and the wiring indicated by the *2 symbol is applicable to vehicles without ABS.
- (4) IOD : Ignition Off Draw
- (5) *1: 1992 models

ENGINE AND TRANSAXLE <1.8L Engine>

Connector
symbol**B**


B-01	Injector No. 4
B-02	Throttle position sensor
B-03	ISC motor position sensor
B-04	Idle speed control actuator
B-05	—
B-06	Injector No. 3
B-07	—
B-08	EGR temperature sensor (Vehicles for California)
B-09	Injector No. 2
B-10	Injector No. 1
B-11	CRC filter
B-12	Distributor assembly
B-13	
B-14	—
B-15	—
B-16	Magnetic clutch (for air conditioning circuit)
B-17	Power steering pressure switch
B-18	Generator
B-19	
B-20	—
B-21	Oil pressure switch

B-22	Oil pressure gauge unit
B-23	Back-up light switch <M/T>
B-24	4-speed automatic transaxle control solenoid valve
B-25	Park/Neutral position switch
B-26	Oxygen sensor
B-27	Starter motor
B-28	
B-29	Engine coolant temperature gauge unit
B-30	Engine coolant temperature sensor
B-31	—
B-32	—
B-33	Kickdown servo switch*1
B-34	Automatic transaxle fluid temperature sensor*1

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: 4), refer to P.4.
- (3) "—" means that the connector with code-number is not used.
- (4) *1: From 1993 models

ENGINE AND TRANSAXLE <2.0L DOHC Engine>

Connector
symbol**B**


- B-01 Injector No. 4
 B-02 Throttle position sensor
 B-03 —
 B-04 Idle speed control actuator
 B-05 Closed throttle position switch
 B-06 Injector No. 3
 B-07 Knock sensor <2.0L DOHC turbo>
 B-08 EGR temperature sensor
 (Vehicles for California)
 B-09 Injector No. 2
 B-10 Injector No. 1
 B-11 }
 B-12 } —
 B-13 }
 B-14 Ignition coil
 B-15 Ignition power transistor
 B-16 Magnetic clutch (for air conditioning circuit)
 B-17 Power steering pressure switch
 B-18 } Generator
 B-19 }
 B-20 Engine compartment wiring harness and
 engine wiring harness combination
 B-21 Oil pressure switch

- B-22 Oil pressure gauge unit
 B-23 Back-up light switch <M/T>
 B-24 4-speed automatic transaxle control solenoid
 valve
 B-25 Park/Neutral position switch
 B-26 Heated oxygen sensor
 B-27 } Starter motor
 B-28 }
 B-29 Engine coolant temperature gauge unit
 B-30 Engine coolant temperature sensor
 B-31 Air conditioning engine coolant
 temperature switch
 B-32 Crankshaft position and camshaft position sensor
 B-33 Kickdown servo switch*¹
 B-34 Automatic transaxle fluid temperature sensor*¹

Remarks

- (1) The mark ★ shows the standard mounting position of
 wiring harness.
 (2) For details concerning the ground point (example: 4),
 refer to P.4.
 (3) "—" means that the connector with code-number is not
 used.
 (4) *¹: From 1993 models


DASH PANEL



C-01 Auto-cruise control unit or jumper connector
 C-02 } Stop light switch
 C-03 }
 C-04 Ignition switch
 C-05 Key reminder switch
 C-06 } Column switch
 C-07 }
 C-08 Accelerator pedal switch <A/T>
 C-09 Blower switch
 C-10 Air conditioning switch
 C-11 Blower resistor
 C-12 Air conditioning wiring harness and body wiring harness combination
 C-13 —
 C-14 Foot light (Right side)
 C-15 } Body wiring harness and ABS wiring harness
 C-16 } combination
 C-17 Door lock control unit
 C-18 Blower motor high relay (vehicles with an air conditioning) or jumper connector
 C-19 Blower motor
 C-20 } Radio
 C-21 }
 C-22 Turn-signal and hazard flasher unit

C-23 Buzzer assembly
 C-24 —
 C-25 Floor console wiring harness and body wiring harness combination
 C-26 Clutch pedal position switch (for starter circuit) <M/T>
 C-27 Clutch pedal position switch (for auto-cruise circuit) <M/T>
 C-28 Data link connector
 C-29 Foot light (Left side)
 C-30 —
 C-31X Door lock relay
 C-32X Starter relay <M/T>
 C-33X Defogger timer
 C-34X —
 C-35X —
 C-36 Air conditioning control unit
 C-37 Air inlet sensor
 C-38 Air thermo sensor
 C-39 Heater relay
 C-40 Instrument panel wiring harness and junction block combination

Refer to
CENTRALIZED
JUNCTION




- C-41 } Engine compartment wiring harness and
- C-42 } junction block combination
- C-43 }
- C-44 }
- C-45 }
- C-46 }
- C-47 } Body wiring harness and junction block
- C-48 } combination
- C-49 }
- C-50 }

Remarks


- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: 6), refer to P.4.
- (3) "—" means that the connector with code-number is not used.

[Vehicles with an air conditioning]




[Junction block]

To instrument panel (connector symbol [D])




(Front side) 16A1328



(Rear side) 16A1329

DASH PANEL

Connector
symbol**C** -51
to
-68

- C-51 Oxygen sensor check connector
<2.0L DOHC engine>
- C-52 } Control wiring harness and body wiring
C-53 } harness combination
C-54 }
- C-55 } 4-speed automatic transaxle control module
C-56 }
C-57 } 4-speed automatic transaxle control module*¹
- C-58 MFI control relay
- C-59 }
C-60 } MFI control unit
C-61 }
- C-62 Control wiring harness and body wiring
harness combination
- C-63 instrument panel wiring harness and engine
compartment wiring harness combination

- C-64 } Instrument panel wiring harness and body
C-65 } wiring harness combination
- C-66 } Engine compartment wiring harness and
C-67 } body wiring harness combination
C-68 }


Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: **6**), refer to P.4.
- (3) *1: 1992 models

INSTRUMENT PANEL AND FLOOR CONSOLE

Connector
symbol

D





36A0269

- D-01 Rheostat
- D-02 Fog light switch
- D-03 Front speaker (Left side)
- D-04 } Combination meter
- D-05 }
- D-06 Heater control panel illumination light
- D-07 Rear wiper and washer switch
- D-08 Defogger switch
- D-09 Hazard switch
- D-10 Front speaker (Right side)
- D-11 Glove compartment light
- D-12 Glove compartment light switch
- D-13 Ashtray illumination light


- D-14 Cigarette lighter illumination light
- D-15 Cigarette lighter (+)
- D-16 Cigarette lighter (-)
- D-17 Overdrive switch and automatic transaxle selector lever position illumination light <A/T>
- D-18 Power/Economy changeover switch <A/T>

Remark
The mark ★ shows the standard mounting position of wiring harness.

INTERIOR



- | | | | |
|------|--|------|--|
| E-01 | Dome light | E-22 | Back-up light (Right side) |
| E-02 | Door speaker (Right side) | E-23 | License plate lights |
| E-03 | Door mirror (Right side) | E-24 | |
| E-04 | Power window motor (Right side) | E-25 | Back-up light (Left side) |
| E-05 | Power window sub-switch | E-26 | License plate light wiring harness and body wiring harness combination |
| E-06 | Outer switch (for automatic seat belt) | E-27 | Rear combination light (Left side) |
| E-07 | Door latch switch (Right side) (for automatic seat belt) | E-28 | Rear washer motor |
| E-08 | Door lock actuator (Right side) | E-29 | Rear combination light (Left side) |
| E-09 | Door switch (Right side) | E-30 | Fuel pump and gauge assembly <AWD> |
| E-10 | ABS power relay | E-31 | Rear side marker light (Left side) |
| E-11 | ABS control unit | E-32 | Motor antenna |
| E-12 | Diode (for ABS circuit) | E-33 | G sensor (for ABS circuit) |
| E-13 | Resistor (for ABS circuit) | E-34 | ABS rear speed sensor (Right side) |
| E-14 | Rear speaker (Right side) | E-35 | Luggage compartment light |
| E-15 | Defogger (-) | E-36 | ABS rear speed sensor (Left side) |
| E-16 | Rear wiper motor | E-37 | Rear speaker (Left side) |
| E-17 | High-mounted stop light | E-38 | Automatic seat belt control unit |
| E-18 | Rear combination light (Right side) | E-39 | Intermittent wiper relay (Rear wiper) |
| E-19 | Rear side marker light (Right side) | E-40 | Diode (for door-ajar warning light) |
| E-20 | Rear combination light (Right side) | E-41 | Noise condenser |
| E-21 | Liftgate latch switch | E-42 | Dome light relay |



- E-43 } Automatic seat belt motor relay (Left side)
- E-44 } Automatic seat belt motor relay (Left side)
- E-45 } Fuel wiring harness and body wiring harness combination <FWD>
- E-46 } Door switch (Left side)
- E-47 } Door lock actuator (Left side)
- E-48 } Door latch switch (Left side) (for automatic seat belt)
- E-49 } Power window main switch
- E-50 } Power window motor (Left side)
- E-51 } Door speaker (Left side)
- E-52 } Door wiring harness and body wiring harness combination (Left side)
- E-53 } Door mirror (Left side)
- E-54 } Remote controlled mirror switch
- E-55 } Seat belt buckle switch
- E-56 } Parking brake switch
- E-57 } Door wiring harness and body wiring harness combination (Right side)
- E-58 } Automatic seat belt motor relay (Right side)
- E-59 } Automatic seat belt motor relay (Right side)
- E-60 } Defogger (+)
- E-61 } Defogger (+)
- E-62 } Defogger (+)

- E-63 } Fuel gauge unit <FWD>
- E-64 } Fuel pump <FWD>
- E-65 } Liftgate wiring harness and body wiring harness combination
- E-66 } Liftgate wiring harness and body wiring harness combination
- E-67 } ABS wiring harness and ABS sensor wiring harness combination

Remarks

- (1) The mark ★ shows the standard mounting position of wiring harness.
- (2) For details concerning the ground point (example: ■), refer to P.4.
- (3) The wiring indicated by the *1 symbol is applicable to vehicles with ABS and the wiring indicated by the *2 symbol is applicable to vehicles without ABS.
- (4) The wiring indicated by the *3 symbol is applicable to FWD vehicles and the wiring indicated by the *4 symbol is applicable to AWD vehicles.

CIRCUIT DIAGRAMS


CONTENTS

M18VE--

Air Conditioning Circuit	142	Headlight Circuit	54-24
Anti-Lock Braking System Circuit	158	Heater Circuit	141
Audio Circuit	54-54	Horn Circuit	54-49
Auto-Cruise Control Circuit	170	How to Read Circuit Diagrams	52
Automatic Seatbelt Circuit	152	Ignition Circuit	16-28
Back-Up Light Circuit	54-31	Meter and Gauges Circuit	54-10
Brake Warning Light, Oil Pressure Warning Light, Seat Belt Warning Light and Fuel Warning Light Circuit	54-13	MFI Circuit	65
Buzzer Circuit	156	Power Distribution Circuit	57
Central Door Locking Circuit	139	Power Window Circuit	124
Charging Circuit	16-3	Rear Window Defogger Circuit	54-87
Cigarette Lighter Circuit	54-52	Rear Wiper and Washer Circuit	149
Cooling Circuit	121	Remote Controlled Mirror Circuit	151
Dome Light, Ignition Key Illumination Light, Foot Light, Glove Compartment Light, Door-Ajar Warning Light and Luggage Compartment Light Circuit	54-28	Starting Circuit	16-14
ELC 4-Speed Automatic Transaxle Circuit	127	Taillight, Position Light, Side Marker Light and License Plate Light Circuit	54-27
Fog Light Circuit	54-26	Turn Signal Light, Hazard Light and Stop Light Circuit	54-32
		Windshield Wiper and Washer Circuit	147

POWER DISTRIBUTION CIRCUIT

<1992 MODELS>




KX35-AC-U0111-NM

TSB Revision


POWER DISTRIBUTION CIRCUIT (CONTINUED)

<1992 MODELS>




REMARKS


- (1) THE ABOVE CIRCUIT DIAGRAM SHOWS THE CURRENT FLOW AT THE IGNITION KEY POSITIONS "ACC", "ON" AND "ST" COMBINED.
- (2) BE SURE TRACE THE APPROPRIATE CIRCUIT DEPENDING ON THE IGNITION KEY POSITION.



POWER DISTRIBUTION CIRCUIT

<FROM 1993 MODELS>






REMARKS

- (1) THE ABOVE CIRCUIT DIAGRAM SHOWS THE CURRENT FLOW AT THE IGNITION KEY POSITIONS "ACC", "ON" AND "ST" COMBINED.
- (2) BE SURE TRACE THE APPROPRIATE CIRCUIT DEPENDING ON THE IGNITION KEY POSITION.

POWER DISTRIBUTION CIRCUIT (CONTINUED)

<FROM 1993 MODELS>









COMPONENT LOCATION

Name	Symbol	Name	Symbol
Dedicated fuses	A, C*	Multi-purpose fuse block	D
Headlight relay	A	Sub fusible links	A
IOD or storage connector	A	Taillight relay	A
Main fusible links	B	—	—


NOTE

- (1) *: Air conditioning equipped models.
 (2) The "Name" column is arranged in alphabetical order.


<Engine compartment>



<Interior>




16A0734



16A0742


MFI CIRCUIT (CONTINUED)

1.8L Engine <M/T>




MFI CIRCUIT (CONTINUED)

1.8L Engine <M/T>




MFI CIRCUIT <1992 MODELS>


1.8L Engine <A/T>



MFI CIRCUIT <1992 MODELS>


1.8L Engine <A/T> (CONTINUED)






MFI CIRCUIT <1992 MODELS>


1.8L Engine <A/T> (CONTINUED)





MFI CIRCUIT <FROM 1993 MODELS>

1.8L Engine <A/T>





KX35-AC-U0534-NM

TSB Revision

MFI CIRCUIT <FROM 1993 MODELS>


1.8L Engine <A/T> (CONTINUED)






MFI CIRCUIT <FROM 1993 MODELS>


1.8L Engine <A/T> (CONTINUED)






MFI CIRCUIT


2.0L DOHC Engine (Non-Turbo) <M/T>






MFI CIRCUIT (CONTINUED)


2.0L DOHC Engine (Non-Turbo) <M/T>






2.0L DOHC Engine (Non-Turbo) <M/T>





MFI CIRCUIT <1992 MODELS>**2.0L DOHC Engine (Non-Turbo) <A/T>**

2.0L DOHC Engine (Non-Turbo) <A/T> (CONTINUED)




MFI CIRCUIT <1992 MODELS>


2.0L DOHC Engine (Non-Turbo) <A/T> (CONTINUED)




MFI CIRCUIT <FROM 1993 MODELS>


2.0L DOHC Engine (Non-Turbo) <A/T>






MFI CIRCUIT <FROM 1993 MODELS>
2.0L DOHC Engine (Non-Turbo) <A/T> (CONTINUED)









MFI CIRCUIT <1992 MODELS>

2.0L DOHC Engine (Turbo-M/T)
(CONTINUED)




MFI CIRCUIT <1992 MODELS>

2.0L DOHC Engine (Turbo-M/T) (CONTINUED)




MFI CIRCUIT <FROM 1993 MODELS>


2.0L DOHC Engine (Turbo-M/T)



MFI CIRCUIT <FROM 1993 MODELS>

2.0L DOHC Engine (Turbo-M/T)
(CONTINUED)





MFI CIRCUIT <FROM 1993 MODELS>

2.0L DOHC Engine (Turbo-M/T)
(CONTINUED)

C-45


1	2	3	4	5	6	7
8	9	10	11	12	13	14


C-60

51	52	53	54	55	56	57	58	59
60	61	62	63	64	65	66	67	68

C-61


1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24






MFI CIRCUIT <1992 MODELS>

2.0L DOHC Engine (Turbo-A/T)







MFI CIRCUIT <1992 MODELS>

2.0L DOHC Engine (Turbo-A/T)


(CONTINUED)





MFI CIRCUIT <1992 MODELS>


2.0L DOHC Engine (Turbo-A/T) (CONTINUED)



TSB Revision


MFI CIRCUIT <FROM 1993 MODELS>


2.0L DOHC Engine (Turbo-A/T)



MFI CIRCUIT <FROM 1993 MODELS>


2.0L DOHC Engine (Turbo-A/T) (CONTINUED)






MFI CIRCUIT <FROM 1993 MODELS>

2.0L DOHC Engine (Turbo-A/T)
(CONTINUED)





COMPONENT LOCATION


Name	Symbol	Name	Symbol
Air conditioning control unit	Q	Idle air control motor	F
Air conditioning engine coolant temperature switch	L	Idle speed control motor	F
Barometric pressure sensor	A	Ignition coil	I
Camshaft position sensor	I	Ignition power transistor	I
Closed throttle position switch	F	Ignition timing adjustment terminal	D
Crankshaft position sensor	I	Intake air temperature sensor	A
Data link connector	O	ISC motor position sensor	F
Dual pressure switch	B	Knock sensor	N
EGR solenoid (Calif. only)	E	Magnet clutch relay	G
EGR temperature sensor	H	Multiport fuel injection relay	S
Engine control module	R	Oxygen sensor	K
Engine coolant temperature sensor	L	Power steering pressure switch	J
Evaporative emission purge solenoid	E	Throttle position sensor	C
Fuel pressure solenoid	E	Turbocharger waste gate valve	M
Fuel pump check terminal	D	Vehicle speed sensor (Reed switch)	P
		Volume air flow sensor	A

NOTE


The "Name" column is arranged in alphabetical order.

Engine compartment


1.8L Engine




2.0L DOHC Turbo






2.0L DOHC Non-Turbo




1.8L Engine, 2.0L DOHC Non-Turbo Engine





2.0L DOHC Turbo Engine




1.8L Engine




2.0L DOHC Engine




1.8L Engine




2.0L DOHC Non-Turbo Engine






2.0L DOHC Turbo Engine




1.8L Engine




2.0L DOHC Engine




1.8L Engine




2.0L DOHC Engine




2.0L DOHC Engine




1.8L Engine




2.0L DOHC Engine




1.8L Engine





2.0L DOHC Engine




1.8L Engine




2.0L DOHC Engine









2.0L DOHC Turbo Engine



2.0L DOHC Turbo Engine




Interior



MAIN FUSIBLE LINK ②

IGNITION
SWITCH(IG2)

SUB FUSIBLE LINK ③












COMPONENT LOCATION

Name	Symbol	Name	Symbol
Air conditioning control unit	D	Radiator fan motor relay	A
Condenser fan motor High-Low select relay	B	Resistor	C
Condenser fan motor relay	B	—	—

NOTE
The "Name" column is arranged in alphabetical order.





[illegible]




COMPONENT LOCATION


Name	Symbol
Power window relay	A




ELC 4-SPEED AUTOMATIC TRANSAXLE CIRCUIT <1992 MODELS>




ELC 4-SPEED AUTOMATIC TRANSAXLE CIRCUIT <1992 MODELS> (CONTINUED)



Remark
*Mark indicates the optional wiring harness for auto-cruise control system.




ELC 4-SPEED AUTOMATIC TRANSAXLE CIRCUIT <1992 MODELS> (CONTINUED)





ELC 4-SPEED AUTOMATIC TRANSAXLE CIRCUIT


<FROM 1993 MODELS>



ELC 4-SPEED AUTOMATIC TRANSAXLE CIRCUIT <FROM 1993 MODELS>
(CONTINUED)





SUB FUSIBLE
LINK ⑥

COMPONENT LOCATION


Name	Symbol	Name	Symbol
Auto-cruise control unit	F	Pulse generator A	A
Data link connector	H	Pulse generator B	A
Dual pressure switch	C	Solenoid valves	D
Engine control module	K	Throttle position sensor	B
Oil temperature sensor	E	Vehicle-speed sensor	G
Power (PWR)/Economy (ECO) select switch	I	4-speed automatic transaxle control module	J

NOTE


1. The "Name" column is arranged in alphabetical order.
2. Refer to GROUP 13A—On vehicle inspection of MFI components for installation position of **B** throttle position sensor.

Engine compartment


1.8L Engine



















2.0L DOHC Engine




Interior












CENTRAL DOOR LOCKING CIRCUIT




COMPONENT LOCATION

Name	Symbol
Door lock actuator	C
Door lock control unit	B
Door lock relay	A

NOTE
The "Name" column is arranged in alphabetical order.




HEATER CIRCUIT



KX35-AC-U1209-NM


TSB Revision

AIR CONDITIONING CIRCUIT





AIR CONDITIONING CIRCUIT (CONTINUED)















COMPONENT LOCATION

Name	Symbol	Name	Symbol
Air conditioning control unit	F	Condenser fan motor relay	D
Air conditioning engine coolant temperature switch <2.0L DOHC Engine>	A	Dual pressure switch	C
Air inlet sensor	H	Heater relay	I
Air thermo sensor	H	Magnet clutch relay	D
Blower motor High relay	G	Radiator fan motor relay	B
Condenser fan motor High-Low selecting relay	D	Resistor	E


NOTE

The "Name" column is arranged in alphabetical order.






WINDSHIELD WIPER AND WASHER CIRCUIT




The diagram illustrates the electrical system for the rear wiper and washer. Key components and their connections include:


- Ignition Switch (ACC):** Provides power to the system via terminal 3-L.
- Taillight Relay:** Connected to the system via terminal 6.
- Connectors:** C-43, C-48, C-40, C-49, C-64, C-65, and C-44 are used to route the wiring between components.
- Switches:** The Rear Wiper and Washer Switch (D-07) controls both the wiper and washer. The Rear Washer Switch is also shown.
- Relays:** The Rear Intermittent Wiper Relay (E-39) and the Rheostat (D-01) are part of the wiper control circuit.
- Motors:** The Rear Wiper Motor (E-16) and Rear Washer Motor (E-28) are the final actuators in the system.
- Wiring Details:** The diagram specifies wire colors (e.g., L, LW, BR, BY, LR, F-L, F-LW, F-LR, B, GW, ILL) and terminal numbers (e.g., 1, 2, 3, 4, 5, 6, 7, 8, 15, 16) for each connection point.

REMOTE CONTROLLED MIRROR CIRCUIT




AUTOMATIC SEAT BELT CIRCUIT







BUZZER CIRCUIT



ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT


<FWD>






ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT (CONTINUED)

<FWD>



ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT

<AWD> <1992 MODELS>




RX35-AC-V1532-ND

TSB Revision


<AWD> <1992 MODELS> (CONTINUED)






ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT


<AWD> <FROM 1993 MODELS>







ANTI-LOCK BRAKING SYSTEM (ABS) CIRCUIT

<AWD> <FROM 1993 MODELS> (CONTINUED)







16A0734




16A1323




16A0741




16A0100



16A1225





16A1223



16A0101

<M/T>






AUTO-CRUISE CONTROL CIRCUIT

<M/T> (CONTINUED)

AUTO-CRUISE
CONTROL-UNIT C-01

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26




MFI
CONTROL
UNIT

C-61

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24


<A/T>




TSB Revision

AUTO-CRUISE CONTROL CIRCUIT

<A/T> (CONTINUED)






AUTO-CRUISE CONTROL CIRCUIT

<A/T> (CONTINUED)

AUTO-CRUISE
CONTROL-UNIT C-01

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

MFI
CONTROL
UNIT

C-61

1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24

ENGINE ELECTRICAL


CONTENTS

M16AA--

CHARGING SYSTEM	2	Spark Plug Test	34
GENERATOR	8	Camshaft Position Sensor Refer to GROUP 13A (ON-VEHICLE INSPECTION OF MFI COMPONENTS)	
SERVICE ADJUSTMENT PROCEDURES	4	Crankshaft Position Sensor Refer to GROUP 13A (ON-VEHICLE INSPECTION OF MFI COMPONENTS)	
Charging System Inspection	4		
SPECIFICATIONS	2	SPECIFICATIONS	26
General Specifications	2	General Specifications	26
Service Specifications	2	Service Specifications	27
Torque Specifications	2	Torque Specifications	27
TROUBLESHOOTING	3	TROUBLESHOOTING	28
IGNITION SYSTEM	26	STARTING SYSTEM	13
DISTRIBUTOR	41	SPECIFICATIONS	13
IGNITION SYSTEM	35	General Specifications	13
SERVICE ADJUSTMENT PROCEDURES .	31	Service Specifications	13
Ignition Timing Adjustment <1.8L Engine>	31	Torque Specifications	14
<2.0L DOHC Engine>	32	STARTER MOTOR	15
Spark Plug Cable Test	33	TROUBLESHOOTING	14

TROUBLESHOOTING

CIRCUIT DIAGRAM



XJ35-AC-V0495-100

OPERATION

When engine is stopped

When the ignition switch is switched to the "ON" position, electricity flows from the "L" terminal of the generator to the field coil, and at the same time the charging warning light illuminates.

When engine is being started/has started

When the engine is started, charging voltage is applied to the "L" terminal of the generator, with the result that the charging warning light is extinguished. In addition, because battery voltage is applied to the "S" terminal of the generator, this battery voltage is monitored at the IC voltage regulator, thus switching ON and OFF the current to the field coil and thereby controlling the amount of generation by the generator.

Power is supplied to each load from the "B" terminal of the generator.

NOTE


The generator relay functions as a back-up for the flow of electricity to the field coil if there is a disconnection or damaged wiring of the charging warning light.

TROUBLESHOOTING HINTS


1. Charging indicator light does not go on when the ignition switch is turned to "ON", before the engine starts.
 - Check the bulb
2. Charging indicator light fails to go off once the engine starts.
 - Check the IC voltage regulator (located within the generator).
3. Discharged or overcharged battery.
 - Check the IC voltage regulator (located within the generator).
4. The charging warning light illuminates dimly.
 - Check the diode (within the combination meter) for a short-circuit.

COMPONENT LOCATION

Name	Symbol
Generator relay	A



16A1336



16A1337



TORQUE SPECIFICATIONS

M16FD--

Items	Nm	ft.lbs.
Starter motor mounting bolts	27–34	20–25
Starter wiring harness connector mounting nut	10–16	7–11
Battery holder mounting bolts	2–3	1.5–2
Battery tray mounting bolts	9–14	6–10
Intake manifold stay mounting bolts	18–25	13–18

TROUBLESHOOTING
CIRCUIT DIAGRAM


M16HAF6



Remarks
*A: 1992 models
*B: Vehicles built from 1993 models
*1: NON-TURBO
*2: TURBO

CIRCUIT DIAGRAM

< 1.8L Engine >



NY 95 - AC - 110.348 - NY

< 1.8L Engine >

- When the ignition switch is turned to "ON", battery voltage is applied to the ignition coil primary winding.
- As the distributor shaft rotates, ignition signals are transmitted from the multiport injection control unit to the ignition power transistor.
- These signals activate the ignition power transistor to cause ignition coil primary winding current to flow from the ignition coil negative terminal through the ignition power transistor to ground or be interrupted, repeatedly.
- This action induces high voltage in the secondary winding of the ignition coil. From the ignition coil, the secondary winding current produced flows through the distributor and spark plug to ground, thus causing ignition in each cylinder.

<2.0L DOHC Engine>

- When the ignition switch is turned to "ON", battery voltage is applied to the ignition coil primary winding.
- As the crankshaft position sensor shaft rotates, ignition signals are transmitted from the multi-port injection control unit to the ignition power transistor.
- These signals activate the ignition power transistor to cause ignition coil primary winding current to flow from the ignition coil negative terminal through the ignition power transistor to ground or be interrupted, repeatedly.
- This action induces high voltage in the secondary winding of the ignition coil. From the ignition coil, the secondary winding current produced flows through the spark plug to ground, thus causing ignition in each cylinder.





1. *Chlorophyll a*

1. *Chlorophyll a* and *Chlorophyll b* contents were determined by spectrophotometry using the method of Lichtenthaler and Whistler (1987).

100


TROUBLESHOOTING
METER AND GAUGES CIRCUIT
CIRCUIT DIAGRAM



**TSB Revision**

BRAKE WARNING LIGHT, OIL PRESSURE WARNING LIGHT, SEAT BELT WARNING LIGHT AND FUEL WARNING LIGHT CIRCUIT


CIRCUIT DIAGRAM





TROUBLESHOOTING

HEADLIGHT

CIRCUIT DIAGRAM



FOG LIGHT CIRCUIT DIAGRAM



EX35-AC-U0622-NM

OPERATION

- Set the lighting switch to the "HEAD" position.
- If the fog light switch is set at the "ON" position when the dimmer switch is at the "low" position, current flows through the multi-purpose fuse, lighting switch, fog light switch, fog light relay, dimmer switch, and ground, causing the fog light relay contacts to close.
- Once the fog light relay contacts have closed, current flows through the dedicated fuse, fog light relay (contacts), fog lights, and ground, causing the fog lights to go on.

MT6IHIA

TROUBLESHOOTING HINTS

1. The right or left fog lights only go on
 - Check the bulb.
2. Fog lights do not go on when the fog light switch is set at "ON".
 - Check the dedicated fuse ⑥.

NOTE


For information concerning the fog light relay, refer to P.54-43.

TSB Revision

TAIL LIGHT, POSITION LIGHT, SIDE MARKER LIGHT AND LICENSE PLATE LIGHT

MB41HC1

CIRCUIT DIAGRAM



KX35-AC-U0824-NM

OPERATION

- The tail light relay is switched ON when the lighting switch is set to the "TAIL" or "HEAD" position.
- As a result, electricity flows via dedicated fuse No.① to each light, and each light illuminates.

TROUBLESHOOTING HINTS


1. All lights do not illuminate.
 - (1) The headlights also do not illuminate.
 - Check sub-fusible link No.⑦.
 - (2) The headlights illuminate.
 - Check the tail light relay.
 - Check dedicated fuse No.①.


TSB Revision

DOME LIGHT, IGNITION KEY ILLUMINATION LIGHT, FOOT LIGHT, GLOVE COMPARTMENT LIGHT, DOOR-AJAR WARNING LIGHT AND LUGGAGE COMPARTMENT LIGHT CIRCUIT

M54IHEN


CIRCUIT DIAGRAM





BACK-UP LIGHT CIRCUIT

CIRCUIT DIAGRAM



KX35-AC-U0920-NM


OPERATION


- When, with the ignition switch at the "ON" position, the shift lever (or the selector lever) is moved to the "R" position, the back-up light switch (M/T) is switched ON [or the park/neutral position switch (A/T) is switched to the "R" position], and the back-up light illuminates.

TSB Revision


TURN-SIGNAL LIGHT, HAZARD LIGHT AND STOP LIGHT CIRCUIT CIRCUIT DIAGRAM

M54HGL





TURN-SIGNAL LIGHT, HAZARD LIGHT AND STOP LIGHT CIRCUIT (CONTINUED)



Remark

*Indicates vehicles with rear spoiler

HORN

SPECIFICATIONS

GENERAL SPECIFICATIONS


M54LB-

Items	Specifications
Type	Flat type
Effective sounding voltage V	11.5-15
Power consumption A	3.0
Sound level dB	
"low" sound	100-112
"high" sound	100-112
Fundamental frequency Hz	
"low" sound	370
"high" sound	415

TROUBLESHOOTING

M54LHAE

CIRCUIT DIAGRAM



CIGARETTE LIGHTER

SPECIFICATIONS

GENERAL SPECIFICATIONS


M54MB-

Items	Specifications
Max. input	W 120
Reset time	second Within 18
Thermal fuse fusion temperature	°C (°F) 180-250 (356-482)

TROUBLESHOOTING


M54MHCA

CIRCUIT DIAGRAM



TROUBLESHOOTING

AUDIO CIRCUIT DIAGRAM




KX35-AC-U1413-M

OPERATION

- When the radio power switch is turned on with the ignition switch at "ACC" or "ON", current flows through fuse No.4, radio, and ground, causing the radio to operate.
- Battery voltage is always supplied for use of the memory and other functions in the radio.

TSB Revision



Remark
 *The connector indicated by the * symbol is applicable to vehicles with ABS.

CIRCUIT DIAGRAM

The diagram illustrates the electrical circuit for a vehicle's defogger system. Key components and their connections are as follows:

- Power Sources:**
 - SUB FUSIBLE LINK (5-B):** Provides power to the DEFROGGER RELAY and the DEFROGGER.
 - IGNITION SWITCH (1G2):** Provides power to the DEFROGGER SWITCH and the DEFROGGER TIMER.
 - GENERATOR (L TERMINAL):** Provides power to the DEFROGGER SWITCH and the DEFROGGER.
- Defogger Control Circuit:**
 - The **DEFROGGER SWITCH (D-08)** is controlled by the ignition switch and the generator. It has two positions: OFF and ON.
 - The **DEFROGGER TIMER (C-33X)** is connected to the ignition switch and the defogger switch. It controls the defogger relay.
 - The **DEFROGGER RELAY (A-54)** is controlled by the defogger timer and the defogger switch. It has two positions: OFF and ON.
- Defogger Heating Element:**
 - The **DEFROGGER (E-62)** is connected to the defogger relay and the defogger switch. It is controlled by the defogger relay and the defogger switch.
 - The **DEFROGGER (E-62)** is connected to the defogger relay and the defogger switch. It is controlled by the defogger relay and the defogger switch.
- Other Components:**
 - RHEOSTAT (D-01):** Controls the defogger switch and the defogger relay.
 - TAILLIGHT RELAY:** Controls the defogger switch and the defogger relay.
 - DEFROGGER RELAY (A-54):** Controls the defogger switch and the defogger relay.

The diagram is a technical drawing with clear lines and labels, typical of a service manual.

TROUBLESHOOTING HINTS

1. Defogger is inoperative.
 - (1) Indicator does not come on, either.
 - Check multi-purpose fuse No. ③.
 - Check defogger relay.
 - (2) Indicator comes on.
 - Check defogger.
2. Defogger timer is inoperative.
 - Check defogger timer.

For information concerning the defogger relay and defogger timer, refer to P.54-89.