




1995

**BMW 318i/s/c,
320i, 325i/s/c,
M3 (E36)**

Electrical Troubleshooting Manual

Vehicles Produced 9/94 to Present



ELECTRICAL TROUBLESHOOTING MANUAL

**SERIES 3 – E36 (318i, 318is, 320i, 325i, 325is, M3,
INCL. CONVERTIBLE)**

SCHEMATICS

MODEL YEAR 1995

0100.0	INDEX	3234.0	SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG)
0110.0	INTRODUCTION	3450.0	SLIP CONTROL (ABS)
0140.0	SYMBOLS	3450.1	SLIP CONTROL (ABS/ASC)
0670.0	POWER DISTRIBUTION CHART	5116.0	POWER MIRRORS
0670.1	FUSE CHART	5126.0	ZKE CENTRAL LOCKING (ZV)
0670.2	POWER DISTRIBUTION	5133.1	POWER WINDOWS (FH)
0670.3	FUSE DETAILS	5200.0	POWER SEATS
0670.4	GROUND DISTRIBUTION	5203.0	HEATED SEATS
0670.5	DATA LINK	5410.1	POWER SUN ROOF (SHD)
1210.9	ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)	5430.0	ELECTRO-MECHANICAL CONVERTIBLE TOP
1210.10	ENGINE CONTROL SYSTEM MS40 (6-CYLINDER M50)	6100.0	CENTRAL BODY ELECTRONICS (ZKE IV)
1210.13	ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)	6133.0	HORN
1210.14	ENGINE CONTROL SYSTEM (DME M3.3, 6-CYLINDER S50 B30)	6135.0	DRIVE-AWAY PROTECTION (EWS II)
1230.0	CHARGING SYSTEM	6160.1	WIPER/WASHER MODULE (WWM)
1240.0	START	6167.1	HEADLIGHT WASHER (SRA)
2460.2	ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)	6211.0	INSTRUMENT CLUSTER
2460.4	ELECTRONIC TRANSMISSION CONTROL (EGS A5S 310Z)	6213.2	MULTI-FUNCTION CLOCK
		6214.0	ON-BOARD DISPLAY

SCHEMATICS

6300.0	LIGHT SWITCH DETAILS	6424.0	REAR WINDOW DEFOGGER
6312.0	HEADLIGHTS/FOG LIGHTS	6450.4	INTEGRATED CLIMATE REGULATION (IHKR E36)
6313.0	TURN/HAZARD LIGHTS	6510.0	RADIO/CD PLAYER (PROVISIONS)
6314.0	PARK/TAIL/UNDERHOOD LIGHTS	6510.1	RADIO/HIFI
6320.0	LICENSE PLATE/LUGGAGE COMPARTMENT LIGHTS	6561.0	CELLULAR TELEPHONE (PROVISIONS)
6322.0	BACK UP LIGHTS	6571.0	CRUISE CONTROL (TEMPOMAT)
6325.0	BRAKE LIGHTS	6575.2	ANTI-THEFT SYSTEM (ALPINE)
6330.3	INTERIOR LIGHTS	6581.2	ON-BOARD COMPUTER (BC V)
6332.1	GLOVE BOX LIGHT/CASSETTE BOX/ ASHTRAY LIGHT/CHARGING SOCKET/ CIGAR LIGHTER	7000.0	COMPONENT LOCATION CHART
6350.0	CRASH CONTROL MODULE	7100.0	COMPONENT LOCATION VIEWS
6412.5	PARK VENTILATION WITH IHKR	8000.0	SPLICE LOCATION VIEWS
		8500.0	CONNECTOR VIEWS



0100.0

ABS HYDRAULIC UNIT, Y1	3450.0-01
ABS HYDRAULIC UNIT, Y1w	3450.1-01
ABS PEDAL TRAVEL SENSOR, S123	3450.
ABS PUMP MOTOR RELAY, K75	3450.
ABS RELAY, K10	3450.
AIR BAG GAS GENERATOR, DRIVER'S, G5	3234.0-00
AIR BAG GAS GENERATOR, PASSENGER'S, G6	3234.0-00
AIR CONDITIONING COMPRESSOR, Y2	6450.4-05
AIR FLOW SENSOR, B6233	1210.9-05
AIR PUMP, M6133	1210.14-06
ANTENNA AMPLIFIER AM/FM, N8	6424.0-00
ANTI-THEFT CONTROL MODULE (ALPINE), N12w	6575.2-00
ANTI-THEFT HORN (ALPINE), H1w	6575.2-02
ANTI-THEFT SYSTEM (ALPINE)	6575.2-00
ASC DIODE, V7	3450.1-00
ASC SWITCH, S6	3450.1-02
ASHTRAY LIGHT, FRONT, E25	6332.1-00
ASHTRAY LIGHT, REAR, E28y	6300.0-03
AUTOMATIC TRANSMISSION RANGE SWITCH, S3	2460.
AUXILIARY FAN MOTOR, M9	6450.4-06
AUXILIARY FUSE BOX, P95	0670.2-04
AUXILIARY THROTTLE POSITION MOTOR (ADS), M93 .	3450.1-02
AUXILIARY THROTTLE POSITION SENSOR, R31	3450.1-04
AUXILIARY TURN LIGHT, LEFT FRONT, H9	6313.0-02
AUXILIARY TURN LIGHT, RIGHT FRONT, H8	6313.0-02
B+ JUMP START JUNCTION POINT, G6430	0670.2-00
BACK UP LIGHT, LEFT, H27	6322.0-00
BACK UP LIGHT, RIGHT, H28	6322.0-00
BACK UP LIGHTS	6322.0-00
BATTERY, G1	0670.2-00
BLOWER MOTOR, M30	6450.4-01
BLOWER RELAY, K4	6450.4-00

BLOWER RESISTORS, R11	6450.4-01
BLOWER SWITCH, S75	6450.4-01
BODY ELECTRONICS CONTROL MODULE (ZKE IV), A104	6100.0-00
BRAKE FLUID LEVEL SWITCH, B18	6211.0-00
BRAKE LIGHT SWITCH, S29	6325.0-00
BRAKE LIGHT SWITCH, S30	6325.0-01
BRAKE LIGHT, LEFT, H24	6325.0-00
BRAKE LIGHT, RIGHT, H31	6325.0-00
BRAKE LIGHTS	6325.0-00
BRAKE PAD SENSOR, LEFT FRONT, B16	6211.0-01
BRAKE PAD SENSOR, RIGHT REAR, B17	6211.0-01
CAMSHAFT ACTUATOR, B6208	1210.
CAMSHAFT ACTUATOR, Y6208	1210.10-05
CAMSHAFT POSITION SENSOR (CYLINDER IDENTIFICATION), B6204	1210.
CASSETTE BOX LIGHT, E45y	6300.0-00
CD CHANGER, N22	6510.1-00
CELLULAR TELEPHONE (PROVISIONS)	6561.0-00
CENTRAL BODY ELECTRONICS (ZKE IV)	6100.0-00
CENTRAL POWER WINDOW SWITCH, S40y	5133.1-03
CHANGE-OVER VALVE, Y5013	1210.14-06
CHARGING SYSTEM	1230.0-00
CHECK CONTROL MODULE, A4	6581.2-03
CHILD PROTECTION CONTROL (CONSOLE), S130	5133.1-02
CHIME MODULE, H10	6581.2-01
CIGAR LIGHTER LIGHT, FRONT, E29	6300.0-03
CIGAR LIGHTER, FRONT, E28	6332.1-00
CLUTCH SWITCH, S32	6525.0-00
COMBINATION SWITCH, S7	6312.0-00
COMFORT RELAY, K114	0670.2-08
COMPONENT LOCATION CHART	7000.0-00



INDEX

COMPONENT LOCATION VIEWS 7100.0-00
COMPRESSOR CONTROL RELAY, K19 6450.4-05
CONNECTOR VIEWS 8500.0-00
CONTACT RING, C101 3234.0-00
CONVERTIBLE TOP ACTUATING SWITCH, S143 5430.0-01
CONVERTIBLE TOP CONTROL MODULE, A96 5430.0-00
CONVERTIBLE TOP END-POSITION MICRO SWITCH,
S164 5430.0-01
CONVERTIBLE TOP MOTOR, M101 5430.0-02
CONVERTIBLE TOP POSITION MICRO SWITCH,
S165 5430.0-01
CONVERTIBLE TOP STORAGE LID LOCK MOTOR,
M43 5430.0-02
CONVERTIBLE TOP STORAGE LID MICRO SWITCH,
S214 5430.0-02
CONVERTIBLE TOP STORAGE LID MOTOR, M100 5430.0-02
CRANKSHAFT POSITION/RPM SENSOR, B6203 1210.
CRASH CONTROL MODULE 6350.0-00
CRASH CONTROL MODULE, N17 6350.0-01
CRUISE CONTROL (TEMPOMAT) 6571.0-00
CRUISE CONTROL ACTUATOR (TEMPOMAT), M25 6571.0-01
CRUISE CONTROL MODULE (TEMPOMAT), A8 6571.0-00
CRUISE CONTROL SWITCH, S28 6571.0-00
DASH VENT MIXING FLAP MOTOR, M34 6450.4-04
DATA LINK 0670.5-00
DATA LINK CONNECTOR, D100 0670.5-00
DAYTIME RUNNING LIGHTS CODING DIODE, V4 6314.0-02
DEFOGGER RELAY, REAR, K13 6424.0-00
DEFOGGER/ANTENNA, REAR, E10 6424.0-02
DELAY RELAY, K6314 1210.13-01
DIMMER, N3 6300.0-00
DIVERSITY, N404 6424.0-03

DOME LIGHT/MAP READING ASSEMBLY,
FRONT, E34 6330.3-00
DOOR CONTACT, LEFT REAR, S125 6330.3-01
DOOR CONTACT, RIGHT REAR, S124 6330.3-01
DOOR JAMB SWITCH, DRIVER'S, S14 6330.3-01
DOOR JAMB SWITCH, PASSENGER'S, S13 6330.3-01
DOOR LOCK MOTOR, DRIVER'S, M12 5126.0-00
DOOR LOCK MOTOR, LEFT REAR, M15 5126.0-01
DOOR LOCK MOTOR, PASSENGER'S, M13 5126.0-00
DOOR LOCK MOTOR, RIGHT REAR, M14 5126.0-01
DOUBLE RELAY, K5029 1210.14-00
DRIVE-AWAY PROTECTION (EWS II) 6135.0-00
ELECTRO-MECHANICAL CONVERTIBLE TOP 5430.0-00
ELECTRONIC IMMOBILIZER CONTROL MODULE
(EWS II), A836 6135.0
ELECTRONIC TRANSMISSION CONTROL
(EGS A4S 310R) 2460.2-00
ELECTRONIC TRANSMISSION CONTROL
(EGS A5S 310Z) 2460.4-00
ENGINE CONTROL MODULE (DME), A6000 1210.
ENGINE CONTROL MODULE RELAY, K6300 1210.
ENGINE CONTROL SYSTEM
(DME M1.7, 4-CYLINDER M42) 1210.9-00
ENGINE CONTROL SYSTEM
(DME M3.3.1, 6-CYLINDER M50) 1210.13-00
ENGINE CONTROL SYSTEM
(DME M3.3, 6-CYLINDER S50 B30) 1210.14-00
ENGINE CONTROL SYSTEM MS40
(6-CYLINDER M50) 1210.10-00
ENGINE COOLANT LEVEL SWITCH, S63 6581.2-03
ENGINE COOLANT TEMPERATURE SENSOR, B6232 .. 6211.0-02
ENGINE COOLANT TEMPERATURE SENSOR, B6236 1210.



ENGINE HOOD SWITCH, S21w 6575.2-02
EVAPORATIVE EMISSION VALVE, Y6120 1210.
EVAPORATOR TEMPERATURE SENSOR, B14 6450.4-03
FM AMPLIFIER HLO, N444 6424.0-03
FOG LIGHT RELAY, FRONT, K47 6312.0-00
FOG LIGHT SWITCH, REAR, S82 6312.0-02
FOG LIGHT SWITCH, S10 6312.0-00
FOG LIGHT, LEFT REAR, H26 6312.0-02
FOG LIGHT, LEFT, E26 6312.0-00
FOG LIGHT, RIGHT, E27 6312.0-00
FRESH AIR FLAP MOTOR, M36 6450.4-04
FUEL INJECTION VALVE, CYL. 1, Y6101 1210.
FUEL INJECTION VALVE, CYL. 2, Y6102 1210.
FUEL INJECTION VALVE, CYL. 3, Y6103 1210.
FUEL INJECTION VALVE, CYL. 4, Y6104 1210.
FUEL INJECTION VALVE, CYL. 5, Y6105 1210.
FUEL INJECTION VALVE, CYL. 6, Y6106 1210.
FUEL LEVEL SENSOR, B6 6211.0-04
FUEL PUMP RELAY, CYL. 1-6, K6301 1210.
FUEL PUMP RELAY, K6301w 1210.9-03
FUEL PUMP, M2 1210.
FUEL PUMP/START IDENTIFICATION RELAY, K6307 .. 1210.14-02
FUEL TANK SENSOR II, B25y 6211.0-04
FUSE CHART 0670.1-00
FUSE DETAILS 0670.3-00
GAS FILLER LOCK MOTOR, M16 5126.0-01
GENERATOR, G6509 1230.0-00
GLOVE BOX LIGHT, E42 6332.1-00
GLOVE BOX LIGHT/CASSETTE BOX/ASHTRAY LIGHT/
CHARGING SOCKET/CIGAR LIGHTER 6332.1-00
GLOVE BOX LOCK MOTOR, M107 5126.0-01
GROUND DISTRIBUTION 0670.4-00

HALL EFFECT CAMSHAFT SENSOR, B6209 1210.13-01
HARD TOP CONNECTOR 1, E99 5430.0-00
HARD TOP CONNECTOR 2, E100y 6330.3-03
HAZARD FLASHER RELAY, K16 6313.0-00
HAZARD SWITCH, S18 6313.0-01
HEADLIGHT WASHER (SRA) 6167.1-00
HEADLIGHT, LEFT, E7 6313.0-02
HEADLIGHT, RIGHT, E8 6313.0-02
HEADLIGHT/FOG LIGHT WASHER PUMP, M7 6167.1-00
HEADLIGHT/FOGLIGHT CLEANING MODULE (SRA),
N6 6167.1-00
HEADLIGHTS/FOG LIGHTS 6312.0-00
HEAT EXCHANGER TEMPERATURE SENSOR, LH, B11 6450.4-03
HEAT EXCHANGER TEMPERATURE SENSOR, RH, B12 6450.4-03
HEATED OXYGEN SENSOR 2, B5028 1210.14-06
HEATED OXYGEN SENSOR, B6200 1210.
HEATED SEATS 5203.0-00
HIFI AMPLIFIER, A18 6510.1-00
HIGH BEAM LIGHT RELAY, K46 6312.0-01
HIGH BEAM LIGHT, LEFT, E11 6312.0-01
HIGH BEAM LIGHT, RIGHT, E12 6312.0-01
HIGH LEVEL STOP LIGHT, H34 6325.0-00
HIGH RANGE SPEAKER, LEFT FRONT, H59 6510.1-01
HIGH RANGE SPEAKER, LEFT REAR, H56 6510.1-01
HIGH RANGE SPEAKER, RIGHT FRONT, H50 6510.0-00
HIGH RANGE SPEAKER, RIGHT FRONT, H50 6510.1-02
HIGH RANGE SPEAKER, RIGHT REAR, H53 6510.1-02
HIGH SPEED RELAY, K22 6450.4-06
HORN 6133.0-00
HORN RELAY (ALPINE), K108 6575.2-02
HORN RELAY, K2 6133.0-00
HORN SWITCH, S4 6133.0-00



INDEX

HORN, LEFT, H2 6133.0-00
HORN, RIGHT, H3 6133.0-00
HOT FILM AIR MASS METER, B6217 1210.13-05
IDLE SPEED CONTROL VALVE, Y6130 1210.
IGNITION COIL, CYL. 1, T6151 1210.
IGNITION COIL, CYL. 2, T6152 1210.
IGNITION COIL, CYL. 3, T6153 1210.
IGNITION COIL, CYL. 4, T6154 1210.
IGNITION COIL, CYL. 5, T6155 1210.
IGNITION COIL, CYL. 6, T6156 1210.
IGNITION SWITCH, S2 0670.2-05
IHKR CONTROL PANEL, S134y 6450.4-02
INDEX 0100.0-00
INERTIA SWITCH, S27 5126.0-02
INSTRUMENT CLUSTER 6211.0-00
INSTRUMENT CLUSTER, A2 6211.0-00
INTAKE AIR RESONANCE CHANGEOVER VALVE,
Y6131 1210.9-01
INTAKE AIR TEMPERATURE SENSOR, B6205 1210.
INTEGRATED CLIMATE REGULATION
CONTROL MODULE, A87y 6450.4-00
INTEGRATED CLIMATE REGULATION (IHKR E36) 6450.4-00
INTENSIVE WASH PUMP, M5 6160.1-01
INTERIOR LIGHT, LEFT REAR, E39 6330.3-00
INTERIOR LIGHT, RIGHT REAR, E40 6330.3-00
INTERIOR LIGHTS 6330.3-00
INTRODUCTION 0110.0-00
KICK-DOWN SWITCH, S8507 2460.2-04
KNOCK SENSOR, CYL. 1-2, B6241 1210.9-05
KNOCK SENSOR, CYL. 1-3, B6241w 1210.
KNOCK SENSOR, CYL. 3-4, B6242 1210.9-05
KNOCK SENSOR, CYL. 4-6, B6242w 1210.

KNOCK SENSOR, CYL. 5-6, B6243 1210.14-05
LICENSE PLATE LIGHT, LEFT, E43 6320.0-00
LICENSE PLATE LIGHT, RIGHT, E44 6320.0-00
LICENSE PLATE/LUGGAGE COMPARTMENT LIGHTS .. 6320.0-00
LIGHT SWITCH DETAILS 6300.0-00
LIGHT SWITCH, S8 6300.0-00
LOW BEAM LIGHT RELAY, K48 6312.0-01
LOW BEAM LIGHT, LEFT, E13 6312.0-01
LOW BEAM LIGHT, RIGHT, E14 6312.0-01
LOW RANGE SPEAKER, LEFT FRONT, H58 6510.0-00
LOW RANGE SPEAKER, LEFT FRONT, H58 6510.1-01
LOW RANGE SPEAKER, LEFT REAR, H57 6510.1-01
LOW RANGE SPEAKER, RIGHT FRONT, H51 6510.0-00
LOW RANGE SPEAKER, RIGHT FRONT, H51 6510.1-02
LOW RANGE SPEAKER, RIGHT REAR, H52 6510.1-02
MAKE-UP MIRROR LIGHT, DRIVER'S, E35 6330.3-00
MAKE-UP MIRROR LIGHT, PASSENGER'S, E36 6330.3-00
MAKE-UP MIRROR SWITCH, DRIVER'S, S77 6330.3-00
MAKE-UP MIRROR SWITCH, PASSENGER'S, S78 6330.3-00
MICROPHONE, B400 6561.0-00
MID-HIGH RANGE SPEAKER, LEFT, H42 6510.1-01
MID-HIGH RANGE SPEAKER, RIGHT, H43 6510.1-02
MIDRANGE SPEAKER, LEFT FRONT, H55 6510.1-01
MIDRANGE SPEAKER, RIGHT FRONT, H54 6510.1-02
MIRROR CONTROL SWITCH, S17 5116.0-00
MIRROR, DRIVER'S, SIDE Y5 5116.0-01
MIRROR, PASSENGER'S SIDE, Y6 5116.0-01
MULTI-FUNCTION CLOCK 6213.2-00
MULTI-FUNCTION CLOCK, N10 6213.2-00
NORMAL SPEED RELAY, K21 6450.4-06
OIL PRESSURE SWITCH, B6231 6211.0-00
OIL TEMPERATURE SENSOR, B6238 6211.0-04

ON-BOARD COMPUTER (BC V)	6581.2-00
ON-BOARD COMPUTER TEMPERATURE SENSOR, B21	6581.2-00
ON-BOARD COMPUTER, N4	6581.2-00
ON-BOARD DISPLAY	6214.0-00
ON-BOARD DISPLAY, A35	6214.0-00
OUTSIDE TEMPERATURE SENSOR, B13	6450.4-03
OXYGEN SENSOR RELAY, K6303	1210.
PARK BRAKE SWITCH, S31	6211.0-00
PARK LIGHT, LEFT, E15	6314.0-01
PARK LIGHT, RIGHT, E19	6314.0-01
PARK VENTILATION RELAY, K450	6412.5-00
PARK VENTILATION WITH IHKR	6412.5-00
PARK/TAIL/UNDERHOOD LIGHTS	6314.0-00
POWER DISTRIBUTION	0670.2-00
POWER DISTRIBUTION BOX, FRONT, P90	0670.2-00
POWER DISTRIBUTION CHART	0670.0-00
POWER MIRRORS	5116.0-00
POWER SEATS	5200.0-00
POWER SUN ROOF (SHD)	5410.0-00
POWER WINDOW SWITCH, DRIVER'S, S126y	5133.1-01
POWER WINDOW SWITCH, PASSENGER'S, S127y	5133.1-01
POWER WINDOWS (FH)	5133.1-00
PRESSURE SWITCH, B9508	6450.4-06
PROGRAM SWITCH, S8503	2460.
RADIO MICROSWITCH, S20y	6575.2-02
RADIO, N9	6510.0-00
RADIO/CD PLAYER (PROVISIONS)	6510.0-00
RADIO/HIFI	6510.1-00
REAR DOOR (CONSOLE) POWER WINDOW SWITCH, RH, S129y	5133.1-02
REAR DOOR (CONSOLE)	

POWER WINDOW SWITCH, LH, S128y	5133.1-02
REAR POWER WINDOW SWITCH, LH, S128z	5133.1-03
REAR POWER WINDOW SWITCH, RH, S129z	5133.1-03
RECIRCULATION FLAP MOTOR, M40	6450.4-04
RESISTOR, R8554	1210.13-04
REVERSING LIGHT SWITCH, S8511	6322.0-00
ROLLOVER PROTECTION ACTUATOR, LH, Y85	5430.0-03
ROLLOVER PROTECTION ACTUATOR, RH, Y86	5430.0-03
ROLLOVER SENSOR, N24	5430.0-03
SEAT BELT SWITCH, DRIVER'S, S58	3234.0-00
SEAT BELT SWITCH, PASSENGER'S, S59	3234.0-00
SEAT CONTROL SWITCH, DRIVER'S SEAT, S51	5200.0-00
SEAT CONTROL SWITCH, PASSENGER'S SEAT, S56 ..	5200.0-01
SEAT CUSHION TILT MOTOR, DRIVER'S, M50	5200.0-00
SEAT CUSHION TILT MOTOR, PASSENGER'S, M61	5200.0-01
SEAT HEATER SWITCH, DRIVER'S SEAT, S53	5203.0-00
SEAT HEATER SWITCH, PASSENGER'S SEAT, S54	5203.0-00
SEAT HEATER, DRIVER'S, E57	5203.0-00
SEAT HEATER, PASSENGER'S, E58	5203.0-00
SEAT HEIGHT MOTOR, DRIVER'S, M52	5200.0-00
SEAT HEIGHT MOTOR, PASSENGER'S, M59	5200.0-01
SEAT MOVEMENT MOTOR, DRIVER'S, M51	5200.0-00
SEAT MOVEMENT MOTOR, PASSENGER'S, M60	5200.0-01
SEAT OCCUPANCY DETECTOR, A113	3234.0-00
SEATBACK HEATER, DRIVER'S, E56	5203.0-00
SEATBACK HEATER, PASSENGER'S, E59	5203.0-00
SEATBACK RECLINER MOTOR, DRIVER'S, M53	5200.0-00
SEATBACK RECLINER MOTOR, PASSENGER'S, M58 ..	5200.0-01
SHIFT-LOCK, Y19	2460.2-04
SLIP CONTROL (ABS)	3450.0-00
SLIP CONTROL (ABS/ASC)	3450.1-00

SLIP CONTROL MODULE (ABS), A7 3450.0-00
 SLIP CONTROL MODULE (ABS/ASC), A52 3450.1-01
 SOLENOID VALVE ("RUNNING LOSSES"), Y6550 1210.13-01
 SPEAKER, LEFT REAR, H46 6510.1-01
 SPEAKER, RIGHT REAR, H45 6510.0-00
 SPEAKER, RIGHT REAR, H45 6510.1-02
 SPEED SENSOR - ABS, LEFT FRONT, B2 3450.
 SPEED SENSOR - ABS, LEFT REAR, B4 3450.
 SPEED SENSOR - ABS, RIGHT FRONT, B1 3450.
 SPEED SENSOR - ABS, RIGHT REAR, B3 3450.
 SPLICE LOCATION VIEWS 8000.0-00
 START 1240.0-00
 STARTER IMMOBILIZATION RELAY, K1w 5126.0-03
 STARTER, M6510 1240.0-01
 SUNROOF CONTROL ASSEMBLY, A56 5410.1-01
 SUNROOF MOTOR, M24 5410.1-01
 SUNROOF SWITCH, S38 5410.1-01
 SUPPLEMENTAL RESTRAINT SYSTEM
 CONTROL MODULE, A12 3234.0-00
 SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG) 3234.0-00
 SUPPRESSION FILTER, C900 6424.0-01
 SYMBOLS 0140.0-00
 TAIL LIGHT, LEFT, H25 6314.0-01
 TAIL LIGHT, LEFT, H37 6314.0-01
 TAIL LIGHT, RIGHT, H30 6314.0-01
 TAIL LIGHT, RIGHT, H39 6314.0-01
 TELEPHONE HANDSET, U4 6561.0-00
 TELEPHONE TRANSCEIVER, H38 6561.0-00
 TEMPERATURE SWITCH, S36 6450.4-06
 THROTTLE FLAP HEATER, E104 3450.1-02
 THROTTLE POSITION SENSOR, R6252 1210.9-05
 TRANSMISSION CONTROL MODULE (EGS), A7000 ... 2460.4-00

TRANSMISSION CONTROL MODULE (EGS), A8500 ... 2460.2-00
 TRANSMISSION POSITION INDICATOR LIGHT, E82 2460.2-03
 TRANSMISSION VALVE UNIT, Y8505 2460.2-01
 TRANSMISSION VALVE UNIT, Y8505y 2460.4-01
 TRANSMITTER MODULE (EWS II), A835 6135.0
 TRUNK COMPARTMENT LIGHT, E32 6320.0-00
 TRUNK COMPARTMENT LIGHT, LEFT, E101 6320.0-00
 TRUNK COMPARTMENT LIGHT, RIGHT, E102 6320.0-00
 TRUNK LID MICRO SWITCH, S213 5430.0-02
 TRUNK LID RELAY, K117 5126.0-01
 TRUNK LIGHT ASSEMBLY, LEFT, E46 6312.0-04
 TRUNK LIGHT ASSEMBLY, LEFT, E46 6313.0-02
 TRUNK LIGHT ASSEMBLY, LEFT, E46 6314.0-01
 TRUNK LIGHT ASSEMBLY, LEFT, E46 6322.0-00
 TRUNK LIGHT ASSEMBLY, LEFT, E46 6325.0-01
 TRUNK LIGHT ASSEMBLY, LEFT, E46 6581.2-04
 TRUNK LIGHT ASSEMBLY, RIGHT, E47 6312.0-04
 TRUNK LIGHT ASSEMBLY, RIGHT, E47 6313.0-02
 TRUNK LIGHT ASSEMBLY, RIGHT, E47 6314.0-01
 TRUNK LIGHT ASSEMBLY, RIGHT, E47 6322.0-00
 TRUNK LIGHT ASSEMBLY, RIGHT, E47 6325.0-01
 TRUNK LIGHT ASSEMBLY, RIGHT, E47 6581.2-04
 TRUNK LIGHT SWITCH, S61y 6320.0-00
 TRUNK LOCK MOTOR, M17 5126.2-01
 TURN LIGHT, LEFT FRONT, H7 6313.0-02
 TURN LIGHT, LEFT REAR, H6 6313.0-02
 TURN LIGHT, RIGHT FRONT, H4 6313.0-02
 TURN LIGHT, RIGHT REAR, H5 6313.0-02
 TURN/HAZARD LIGHTS 6313.0-00
 TWIN RELAY MODULE, N21 6160.1-01
 UNCOUPLING DIODE (KL61), V9501 1210.14
 UNDERHOOD LIGHT SWITCH, S19 6300.0-00

UNDERHOOD LIGHT, E20	6300.0-00
UNLOADER RELAY, TERMINAL 15, K9	5203.0-00
VARIABLE CAMSHAFT CONTROL MODULE (VANOS), A5024	1210.14-04
VARIABLE CAMSHAFT CONTROL SENSOR 1, B5022 ..	1210.14-04
VARIABLE CAMSHAFT CONTROL SENSOR 2, B5023 ..	1210.14-04
VARIABLE CAMSHAFT CONTROL VALVE 1, Y5020	1210.14-04
VARIABLE CAMSHAFT CONTROL VALVE 2, Y5021	1210.14-04
VEHICLE SPEED SENSOR, B10	6211.0-04
WASHER FLUID LEVEL SWITCH, S64	6581.2-03
WASHER PUMP, M4	6160.1-01
WATER VALVE ASSEMBLY, Y4	6450.4-02
WINDOW BLOWER MICRO SWITCH, REAR, S196	5430.0-01
WINDOW BLOWER RELAY, REAR, K99	6424.0-01
WINDOW BLOWER, REAR, M105	6424.0-01
WINDOW DEFOGGER/ANTENNA, REAR	6424.0-00
WINDOW MOTOR, DRIVER'S, M21	5133.1-04
WINDOW MOTOR, LEFT REAR, M20	5133.1-05
WINDOW MOTOR, LEFT REAR, M98	5133.1-05
WINDOW MOTOR, PASSENGER'S, M23	5133.1-04
WINDOW MOTOR, RIGHT REAR, M22	5133.1-05
WINDOW MOTOR, RIGHT REAR, M99	5133.1-05
WINDOW SWITCH, LEFT REAR, S41	5133.1-02
WINDOW SWITCH, RIGHT REAR, S42	5133.1-02
WIPER MOTOR RELAY, K53	6160.1-00
WIPER MOTOR, M3	6160.1-00
WIPER RELAY, K11	6160.1-00
WIPER/WASHER MODULE (WWM)	6160.1-00
WIPER/WASHER MODULE, A51	6160.1-01
WIPER/WASHER SWITCH, S5	6160.1-01
ZKE CENTRAL LOCKING (ZV)	5126.0-00



0110.0

Schematics

The schematics divide the entire vehicle electrical system into individual circuits. Interacting electrical components are shown on one common schematic.

Switches and other components are represented in such a way that their general layout and function are self-explicit. They are arranged on the sheet such that the current path can be followed from positive (top) to negative (bottom).

Important: The components and wires are not drawn to scale. For instance, a lead with a length of over 1m can be shown as a lead that is only a few cm long. To ensure clear arrangement, all connectors, line branches and connected components from the fuses to the component and from the component to ground connection are not shown within the individual cells. If required, reference can be made to cells **0670.3 Fuse Details** and **0670.4 Ground Distribution** where all lines are illustrated with all plug connections, line branches and connected components.

All circuit symbols used are listed and explained in cell **0140.0 Symbols**.


In cell **7000.0 Component Location Chart** all important connectors, ground points and components are listed in tabular form. It provides a precise description of the component locations in the vehicle.

In cell **7100.0 Component Location Views** the location of connectors and components which are difficult to locate are shown in line arts or illustrations. In cell **8000.0 Splice Location Views** all splices are listed in numerical order and illustrations are provided to assist in locating splices on larger harnesses. In cell **8500.0 Connector Views** diagrams of connectors with more than 2 pins are illustrated.

Included in this ETM are foldout block diagrams. These are overviews of the entire system (EGS, ABS, AC, etc.) which helps understand the relationships between various components and control unit of the system being diagnosed.

Example

General conventions can be explained based on the following schematic example.





INTRODUCTION

General Conventions

1. Switches and relays are always shown in rest position (e.g. K11).
2. A component shown in a dashed frame signifies that the component is illustrated only in part (e.g. P90 and P91).
3. A component shown in a completely drawn frame signifies that the component is illustrated in full (e.g. K11).
4. The dashed line between pin 8 and pin 6 of connector X293 indicates that both pins belong to connector X293.
5. The dashed line from fuse F1 to pin 8 of connector X293 shows the positive supply of relay K11. If required, refer to cell **0670.3 Fuse Details** at fuse F1 for the complete line progressing with plug connections, line branches, wire colors and cross sections.
6. The dashed line with an arrow at splice X452 indicates that several wires lead to splice X452. All lines leading to the connection are illustrated in cell **6100.0 Central Body Electronics (ZKE)**. An interrupted line with an arrow indicates that only this one wire leads to another circuit.
7. The dashed line from pin 4 of connector X293 to ground X493 shows the ground supply for relay K11. If required, refer to cell **0670.4 Ground Distribution** at ground X493 for the complete line progression with all plug connections, line branches, wire colors, and cross sections.
8. The interrupted line from splice X452 with an A in the open arrow is continued on page 6160.0-02. Termination of wire 4 VI/SW from splice X452 with a wavy line indicates that the wire is continued on the opposite page.



BATTERY



FUSE DETAILS



FUSIBLE LINK



THERMO SWITCH



SOLENOID



SOLENOID CONTROLLED VALVE
OR CLUTCH SOLENOID



HEATING ELEMENT



LOUDSPEAKER OR HORN



LIGHT



PERMANENT MAGNET MOTOR
ONE SPEED



PERMANENT MAGNET MOTOR
TWO SPEEDS



KNOCK SENSOR



VARIABLE RESISTANCE
SENSOR
VARIABLE CONTACT IS
MOVED BY AN EXTERNAL
FORCE



VARIABLE RESISTOR
RESISTANCE IS CHANGED
BY TEMPERATURE OR
PRESSURE



DIODE
CURRENT CAN FLOW ONLY
IN DIRECTION OF ARROW




ZENER DIODE
TO REGULATE VOLTAGE



LIGHT EMITTING DIODE



OXYGEN SENSOR



IGNITION COIL



CONTROL/POWER ELECTRONICS



HALL EFFECT SENSOR



RADIO



TRANSISTORIZED SWITCH








INDUCTIVE SENSOR






VEHICLE SPEED SENSOR




SYMBOLS




WIRE COLOR	
BL	BLUE
BR	BROWN
GE	YELLOW
GN	GREEN
GR	GRAY
OR	ORANGE
RS	PINK
RT	RED
SW	BLACK
VI	VIOLET
WS	WHITE
TR	TRANSPARENT







CONTACT RELAY



RELAY WITH RESISTOR
ACROSS WINDING



CONTACT RELAY WITH TWO
OUTPUTS



CHANGEOVER RELAY WITH
TWO OUTPUTS

TERMINAL NUMBER DESCRIPTION


30 RELAY INPUT

85 RELAY OUTPUT (WINDING)

86 RELAY INPUT (WINDING)

87 RELAY OUTPUT (ENERGIZED)

87a RELAY OUTPUT (AT REST)



TERMINAL NUMBER	DESCRIPTION	TERMINAL NUMBER	DESCRIPTION
50	VOLTAGE: IGNITION SWITCH IN START	15I	VOLTAGE: IGNITION SWITCH IN RUN
30	VOLTAGE: SUPPLIED AT ALL TIMES	R	VOLTAGE: IGNITION SWITCH IN ACCESSORY, RUN OR START
15	VOLTAGE: IGNITION SWITCH IN RUN OR START	31	GROUND

HOT AT ALL TIMES



INDICATES THAT FUSE 9 IS
SUPPLIED WITH POWER AT
ALL TIMES

POWER STATUS

HOT AT ALL TIMES

HOT IN RUN AND START

HOT IN ACCY, RUN AND START

DESCRIPTION


VOLTAGE: SUPPLIED
AT ALL TIMES

VOLTAGE: IGNITION
SWITCH IN RUN OR START


VOLTAGE: IGNITION
SWITCH IN ACCESSORY,
RUN OR START

SYMBOLS


HOT IN ACCY, RUN AND START




THE COMPLETE WIRE
PROGRESSION AND FURTHER
CIRCUITS CONNECTED TO
FUSE 18 ARE SHOWN IN CELL
"0870.3 FUSE DETAILS" AT
FUSE 18



CIRCUIT REFERENCE-
A WIRE WHICH CONNECTS
TO ANOTHER CIRCUIT



THE COMPLETE WIRE
PROGRESSION AND FURTHER
CIRCUITS CONNECTED TO
GROUND X497 ARE SHOWN IN
CELL "0870.4 GROUND
DISTRIBUTION" AT
GROUND X497



CURRENT PATH IS CONTINUED
AS LABELED




ARROW SHOWS
DIRECTION OF CURRENT
FLOW AND IS REPEATED
WHERE CURRENT
PATH CONTINUES



SYMBOLS

BLOCK DIAGRAM






0670.0



POWER DISTRIBUTION CHART


FRONT POWER DISTRIBUTION BOX





POWER DISTRIBUTION CHART


RELAY PANEL UNDER LH SIDE OF DASHBOARD





POWER DISTRIBUTION CHART


SPLICE PANEL UNDER LH SIDE OF DASHBOARD





POWER DISTRIBUTION CHART

SPLICE PANEL UNDER RH SIDE OF DASHBOARD





FUSE CHART

FUSES 1 TO 29

	FUSE NUMBER																												
	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
	30A	15A	30A	15A	30A	20A	5A	15A	20A	30A	7.5A	7.5A	5A	30A	15A	5A	10A	15A	30A	30A	5A	5A	5A	10A	5A	10A	5A	5A	7.5A
1210.9 ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)																●		●										●	
1210.10 ENGINE CONTROL SYSTEM MS40 (6-CYLINDER M50)																●		●										●	
1210.13 ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)																●		●										●	
1210.14 ENGINE CONTROL SYSTEM (DME M3.3, 6-CYLINDER S50 B30)																●		●											
1230.0 CHARGING SYSTEM																													
1240.0 START																									●		●		
2460.2 ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)																									●		●		
2460.4 ELECTRONIC TRANSMISSION CONTROL (EGS A5S 310Z)																									●		●		
3234.0 SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG)																													
3450.0 SLIP CONTROL (ABS)										●										●		●				●			
3450.1 SLIP CONTROL (ABS/ASC)										●										●					●	●			
5116.0 POWER MIRRORS																								●					
5126.0 ZKE CENTRAL LOCKING (ZV)							●																		●		●		
5133.1 POWER WINDOWS (FH)														●					●										
5200.0 POWER SEATS					●																								
5203.0 HEATED SEATS			●																				●						
5410.1 POWER SUN ROOF (SHD)	●												●																
5430.0 ELECTRO- MECHANICAL CONVERTIBLE TOP							●																				●		
6100.0 CENTRAL BODY ELECTRONICS (ZKE IV)							●							●															
6133.0 HORN								●																					



FUSE CHART

FUSES 1 TO 29

		FUSE NUMBER																												
		1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29
		30A	15A	30A	15A	30A	20A	5A	15A	20A	30A	7.5A	7.5A	5A	30A	15A	5A	10A	15A	30A	30A	5A	5A	5A	10A	5A	10A	5A	5A	7.5A
6160.1	WIPER/WASHER MODULE (WWM)																													
6167.1	HEADLIGHT WASHER (SRA)			●																										
6211.0	INSTRUMENT CLUSTER																							●				●		
6213.2	MULTI-FUNCTION CLOCK																							●			●	●		
6214.0	ON-BOARD DISPLAY																							●				●		
6300.0	LIGHT SWITCH DETAILS																							●			●			
6312.0	HEADLIGHTS/ FOG LIGHTS											●	●			●		●						●		●				●
6313.0	TURN/HAZARD LIGHTS																							●						
6314.0	PARK/TAIL/ UNDERHOOD LIGHTS																													
6320.0	LICENSE PLATE/ LUGGAGE COMPARTMENT LIGHTS																													
6322.0	BACK UP LIGHTS																										●			
6325.0	BRAKE LIGHTS																													
6330.3	INTERIOR LIGHTS							●																						
6332.1	GLOVE BOX LIGHT/CASSETTE BOX/ASHTRAY LIGHT/ CHARGING																													
6350.0	CRASH CONTROL MODULE																													
6412.5	PARK VENTILATION WITH IHKR																				●									
6424.0	REAR WINDOW DEFOGGER						●																	●						
6450.4	INTEGRATED CLIMATE REGULATION (IHKR E36)																●			●				●						
6510.0	RADIO/ CD PLAYER (PROVISIONS)									●																				
6510.1	RADIO/HIFI			●						●																				



FUSES 1 TO 29

[illegible]





FUSE CHART


FUSES 30 TO 47

	FUSE NUMBER																		
	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48
	7.5A	5A	30A	10A	15A	25A	30A	10A	30A	7.5A	30A	30A	7.5A	5A	15A	7.5A	15A	15A	40A
1210.9 ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)																			
1210.10 ENGINE CONTROL SYSTEM MS40 (6-CYLINDER M50)										●									
1210.13 ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)																			
1210.14 ENGINE CONTROL SYSTEM (DME M3.3, 6-CYLINDER S50 B30)										●									
1230.0 CHARGING SYSTEM																			
1240.0 START																			
2460.2 ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)																	●		
2460.4 ELECTRONIC TRANSMISSION CONTROL (EGS A5S 310Z)																			
3234.0 SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG)													●	●					
3450.0 SLIP CONTROL (ABS)									●								●	●	
3450.1 SLIP CONTROL (ABS/ASC)									●								●		
5116.0 POWER MIRRORS																			
5126.0 ZKE CENTRAL LOCKING (ZV)						●													
5133.1 POWER WINDOWS (FH)																			
5200.0 POWER SEATS											●								
5203.0 HEATED SEATS																			
5410.1 POWER SUN ROOF (SHD)																			
5430.0 ELECTRO- MECHANICAL CONVERTIBLE TOP						●							●	●					
6100.0 CENTRAL BODY ELECTRONICS (ZKE IV)			●		●									●					
6133.0 HORN																			

[illegible]












POWER DISTRIBUTION









POWER DISTRIBUTION








POWER DISTRIBUTION





POWER DISTRIBUTION




BMW
3

0670.3



FUSE DETAILS


FUSES 1, 2, 3, 4, AND 5





FUSE DETAILS


FUSES 8 AND 9






FUSE DETAILS

FUSES 10, 11, 12, AND 13



FUSE DETAILS


FUSES 14 AND 15






FUSE DETAILS

FUSES 16, 17, 18, AND 19




FUSE DETAILS

FUSES 20, 21, AND 22




BMW
3 **FUSE DETAILS**
FUSE 23





FUSE DETAILS


FUSES 24 AND 25






FUSE DETAILS


FUSES 26, 27, 28, 29, AND 30






FUSE DETAILS

FUSES 32 AND 33



FUSE DETAILS


FUSES 34, 35, 36, 37, 38, AND 39






FUSE DETAILS

FUSES 40, 41, 42, AND 43








FUSE DETAILS


FUSE 45





FUSE DETAILS


FUSE 46





FUSE DETAILS


FUSE 47 AND 48





GROUND DISTRIBUTION


GROUND X165





GROUND DISTRIBUTION


GROUND X165






GROUND DISTRIBUTION

GROUND X173



GROUND DISTRIBUTION


GROUND X173





GROUND DISTRIBUTION



GROUND X173





GROUND DISTRIBUTION


GROUNDS X494 AND X498





GROUND DISTRIBUTION


GROUND X495





GROUND DISTRIBUTION

GROUND X495




0670.4-06



GROUND DISTRIBUTION


GROUND X498







GROUND DISTRIBUTION

GROUNDS X1165, X1166, AND X1441




GROUND X6454





GROUND X6454






GROUND DISTRIBUTION

GROUND X6454

325i, M3 (USA)






GROUND DISTRIBUTION

GROUND X6454


M3



GROUND DISTRIBUTION

GROUND X6454

M3 (CDN)






GROUND DISTRIBUTION

GROUND X6456

320i, 325i



09/94


0670.4-16

1995



GROUND DISTRIBUTION


GROUND X10010





GROUND DISTRIBUTION


GROUND X10012





GROUND DISTRIBUTION

GROUND X10012






GROUND DISTRIBUTION

GROUND X13004

FOUR-DOOR



09/94


0670.4-20

1995



GROUND DISTRIBUTION

GROUND X13006






GROUND DISTRIBUTION

GROUND X13006

CONVERTIBLE



09/94


0670.4-22

1995



GROUND DISTRIBUTION

GROUNDS X13009, X13016, AND X18723






GROUND DISTRIBUTION

CONVERTIBLE

GROUND X13230



09/94

0670.4-24


1995



0670.5




DATA LINK BLOCK DIAGRAM





DATA LINK


TXD, PIN 20





DATA LINK

RXD, PIN 15








DATA LINK

DATA LINK CONNECTOR, PIN 1

318i, 320i, 325i









DATA LINK

DATA LINK CONNECTOR PINS 7, 16, AND 18



DATA LINK CONNECTOR PIN 19






DATA LINK

320i **CDN**

DATA LINK CONNECTOR PIN 19






DATA LINK

DATA LINK CONNECTOR PIN 19

325i



09/94


0670.5-08

1995

DATA LINK

M3 **CDN**


DATA LINK CONNECTOR PIN 19







DATA LINK

DATA LINK CONNECTOR (X6002)



PIN NUMBER	TERMINAL NUMBER	TERMINAL DESCRIPTION	WIRE COLOR
1	-	MOTOR	SW
2	-	NOT OCCUPIED	
3	-	NOT OCCUPIED	
4	-	NOT OCCUPIED	
5	-	NOT OCCUPIED	
6	-	NOT OCCUPIED	
7	SI	SERVICE INTERVAL RESET	WS/GN
8	-	NOT OCCUPIED	
9	-	NOT OCCUPIED	
10	-	NOT OCCUPIED	
11	-	NOT OCCUPIED	
12	61(D+)	GENERATOR CHARGE INDICATOR	BL
13	-	NOT OCCUPIED	
14	30	VOLTAGE: HOT AT ALL TIMES	RT
15	RXD	DIAGNOSTIC DATA LINK	WS/GE
16	15S	VOLTAGE: IGNITION SWITCH IN RUN AND START	GN/WS
17	-	NOT OCCUPIED	
18	PGSP	PROGRAM SELECT FOR ENGINE CONTROL MODULE (DME)	GN/BL
19	31	GROUND	BR
20	TXD	DIAGNOSTIC DATA LINK	WS/VI






Pin Assignments

X6000

Pin	Type	Description/Function	Connection
1	A	Fuel pump relay control	Fuel pump relay, terminal 85
2		Not used	
3	A	Cyl. 2 and cyl. 4 fuel injection valve control	Cyl. 2 and cyl. 4 fuel injection valves
4		Not used	
5		Not used	
6	M	Ground, fuel injection valve output stages	Ground point
7		Not used	
8	A	"Check engine" indicator control	Instrument cluster
9		Not used	
10		Not used	
11	A	DKV potentiometer signal	Transmission control module (EGS)
12	E	Throttle position	Throttle position sensor
13		Not used	
14	E	Volume air flow sensor	Volume air flow sensor
15	E	Cyl. 1-2 knock sensor	Cyl. 1-2 knock sensor
16	E	Camshaft position sensor (cylinder identification)	Camshaft position sensor (cylinder identification)
17	A	Ti - measurement signal (fuel consumption)	Instrument cluster
18	A	Intake air resonance changeover valve control	Intake air resonance changeover valve
19		Not used	
20		Not used	
21		Not used	
22		Not used	
23		Not used	
24	A	Cyl. 3 ignition coil control	Cyl. 3 ignition coil
25	A	Cyl. 1 ignition coil control	Cyl. 1 ignition coil
26	E	Battery voltage	B + junction point
27	A	Engine control module relay control	Engine control module relay, terminal 85
28	M	Ground for electronics and shielding of sensors	Ground point


E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
29	A	Idle speed control valve control	Idle speed control valve
30		Not used	
31		Not used	
32	A	Cyl. 1 and cyl. 3 fuel injection valve control	Cyl. 1 and cyl. 3 fuel injection valves
33		Not used	
34	M	Ground, remaining output stages (except for ignition and fuel injection valves)	Ground point
35		Not used	
36	A	Evaporative emission valve control	Evaporative emission valve
37	A	Oxygen sensor heater control	Oxygen sensor relay, terminal 85
38		Not used	
39		Not used	
40		Not used	
41	E	Volume air flow sensor	Volume air flow sensor
42	E	Cyl. 3-4 knock sensor	Cyl. 3-4 knock sensor
43	M	Ground for sensors	Engine coolant temperature sensor, cyl. 1-2 knock sensor, cyl. 3-4 knock sensor, and throttle position sensor
44	E	Camshaft position sensor (cylinder identification)	Camshaft position sensor (cylinder identification)
45		Not used	
46		Not used	
47		Not used	
48	A	A/C compressor cut-out	Compressor control relay, terminal 85
49		Not used	
50		Not used	
51	A	Cyl. 4 ignition coil control	Cyl. 4 ignition coil
52	A	Cyl. 2 ignition coil control	Cyl. 2 ignition coil
53		Not used	
54	E	Battery voltage from engine control module relay	Engine control module relay, terminal 87a
55	M	Ground, ignition	Ground point
56	E	Ignition switch, terminal 15	Ignition switch, terminal 15
57		Not used	


E = Input, A = Output, M = Ground





Pin Assignments

Pin	Type	Description/Function	Connection
58		Not used	
59	A	5V component supply	Throttle position sensor and volume air flow sensor
60	E	Programming voltage	Data link connector
61		Not used	
62		Not used	
63		Not used	
64	E	Ignition timing intervention	Transmission control module (EGS)
65	E	Drive range P/N	Automatic transmission range switch
66		Not used	
67	E	Crankshaft position/RPM sensor	Crankshaft position/RPM sensor
68	E	Crankshaft position/RPM sensor	Crankshaft position/RPM sensor
69		Not used	
70	E	Oxygen sensor signal	Heated oxygen sensor
71	M	Oxygen sensor signal ground	Heated oxygen sensor
72		Not used	
73	E	Vehicle speed signal	Instrument cluster
74	A	Crankshaft RPM speed signal TD	Instrument cluster
75		Not used	
76	E	Volume air flow sensor	Volume air flow sensor
77	E	Volume air flow sensor	Volume air flow sensor
78	E	Engine coolant temperature	Engine coolant temperature sensor
79		Not used	
80		Not used	
81	E	Drive-away protection signal (code)	Starter interlock module
82		Not used	
83		Not used	
84		Not used	
85	E	A/C pressure	Pressure switch
86	E	A/C switch	Integrated climate regulation control module
87	A	RxD diagnosis data line	Data link connector
88	E/A	TxD diagnosis data line	Data link connector

E = Input, A = Output, M = Ground










ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)


FUEL PUMP

HOT IN RUN AND START




HOT IN RUN AND START






ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)







ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)


DATA LINK




ENGINE CONTROL SYSTEM (DME M1.7, 4-CYLINDER M42)










Pin Assignments

X6000

Pin	Type	Description/Function	Connection
1	A	Cyl. 1 ignition coil control	Cyl. 1 ignition coil
2	A	Cyl. 3 ignition coil control	Cyl. 3 ignition coil
3	A	Cyl. 5 ignition coil control	Cyl. 5 ignition coil
4	M	Ground	Ground
5	A	Cyl. 6 fuel injection valve control	Cyl. 6 fuel injection valve
6	A	Cyl. 4 fuel injection valve control	Cyl. 4 fuel injection valve
7		Not used	
8	E	Drive range P/N	Automatic transmission range switch
9	A	A/C signal	Pressure switch
10	A	Auxiliary ventilation signal	Integrated climate regulation control module
11		Not used	
12	E	Vehicle speed signal	Instrument cluster
13		Not used	
14	A	Throttle valve position	Transmission control module (EGS)
15	E	Drive-away protection signal	Starter interlock module
16		Not used	
17	A	TI - measurement signal (fuel consumption)	Instrument cluster
18	A	Crankshaft RPM speed signal TD	Instrument cluster
19		Not used	
20	E	Ignition timing intervention	Transmission control module (EGS)
21		Not used	
22	A	Cyl. 3 fuel injection valve control	Cyl. 3 fuel injection valve
23	A	Cyl. 1 fuel injection valve control	Cyl. 1 fuel injection valve
24	A	A/C compressor control	Compressor control relay
25	A	Camshaft control signal	Camshaft control
26	E	Battery voltage	Jump start junction point
27	A	Idle speed signal	Idle speed control valve
28	M	Ground	Ground
29	A	Cyl. 2 ignition coil control	Cyl. 2 ignition coil
30	A	Cyl. 4 ignition coil control	Cyl. 4 ignition coil


E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
31	A	Cyl. 6 ignition coil control	Cyl. 6 ignition coil
32	M	Ground	Ground
33	A	Cyl. 5 fuel injection valve control	Cyl.5 fuel injection valve
34	M	Ground	Ground
35	M	Shield, crankshaft position/RPM sensor	Shield
36	M	Shield, camshaft sensor	Shield
37		Not used	
38		Not used	
39	M	Shield, knock sensor (Cyl. 1-3)	Knock sensor (Cyl. 1-3)
40	M	Shield, knock sensor (Cyl. 4-6)	Knock sensor(Cyl. 4-6)
41		Not used	
42	M	Shield, oxygen sensor	Shield
43		Not used	
44		Not used	
45		Not used	
46		Not used	
47		Not used	
48	E	Voltage supply	Engine control module relay
49	E	Ignition signal	Ignition switch
50	A	Cyl. 2 fuel injection valve control	Cyl. 2 fuel injection valve
51	A	Evaporative emission valve control	Evaporative emission valve
52	A	Fuel pump signal	Fuel pump relay
53	M	Ground, oxygen sensor	Oxygen sensor
54	E	Voltage supply	Engine control module relay
55	A	DME-relay signal	Engine control module relay
56		Not used	
57		Not used	
58		Not used	
59		Not used	
60	E	Programming voltage	Data link connector
61		Not used	
62	M	Ground	Ground


E = Input, A = Output, M = Ground





Pin Assignments


Pin	Type	Description/Function	Connection
63	E	Knock sensor signal (-)	Knock sensor (Cyl. 4-6)
64	E	Knock sensor signal (-)	Knock sensor (Cyl. 1-3)
65	A	Knock sensor signal (+)	Knock sensor (Cyl. 1-3)
66	A	Knock sensor signal (+)	Knock sensor (Cyl. 4-6)
67		Not used	
68	M	Ground, air mass meter	Hot film air mass meter
69	E	Air mass meter signal	Hot film air mass meter
70		Not used	
71		Not used	
72	A	Voltage supply	Throttle position sensor
73	E	Oxygen sensor signal	Oxygen sensor
74	M	Ground, hall effect camshaft sensor	Hall effect camshaft sensor
75	M	Ground, oxygen sensor	Oxygen sensor
76	M	Ground, throttle position sensor	Throttle position sensor
77	E	Throttle position signal	Throttle position sensor
78	E	Crankshaft position/RPM signal (-)	Crankshaft position/RPM sensor
79	A	Crankshaft position/RPM signal (+)	Crankshaft position/RPM sensor
80	E	Engine coolant temperature	Engine coolant temperature sensor
81	A	Engine coolant temperature	Engine coolant temperature sensor
82	M	Ground, crankshaft position/RPM sensor	Crankshaft position/RPM sensor
83	E	Camshaft signal (-)	Hall effect camshaft sensor
84	A	Camshaft signal (+)	Hall effect camshaft sensor
85	E	Engine intake air temperature	Engine intake air temperature sensor
86	M	Ground, engine intake air temperature sensor	Engine intake air temperature sensor
87	A	RxD diagnostic data link	Data link connector
88	E/A	TxD diagnostic data link	Data link connector


E = Input, A = Output, M = Ground






















ENGINE CONTROL SYSTEM MS40 (6-CYLINDER M50)


CDN





	L1	L2	L3	L4
P	1	1	0	1
R	1	0	0	0
N	1	1	1	0
O	0	0	0	1
3	0	0	1	1
2	1	0	1	1
1	0	0	1	0












Pin Assignments

X6000

Pin	Type	Description/Function	Connection
1	A	Fuel pump relay control	Fuel pump relay, terminal 85
2	A	Idle speed control valve - close winding control	Idle speed control valve
3	A	Cyl. 5 fuel injection valve control	Cyl. 5 fuel injection valve
4	A	Cyl. 6 fuel injection valve control	Cyl. 6 fuel injection valve
5	A	Cyl. 4 fuel injection valve control	Cyl. 4 fuel injection valve
6	M	Ground, fuel injection valve output stages	Ground point
7	A	Camshaft actuator control	Camshaft actuator
8	A	"Check engine" indicator control	Instrument cluster
9		Not used	
10		Not used	
11	A	Throttle valve position	Transmission control module (EGS)
12		Not used	
13	E	Oxygen sensor signal	Heated oxygen sensor
14	A	Hot wire air mass meter	Hot wire air mass meter
15	M	Ground	Ground point
16	E	Crankshaft position/RPM sensor signal (+)	Crankshaft position/RPM sensor
17	E	Camshaft position sensor	Hall effect camshaft sensor
18		Not used	
19		Not used	
20		Not used	
21		Not used	
22		Not used	
23	A	Cyl. 4 ignition coil control	Cyl. 4 ignition coil
24	A	Cyl. 6 ignition coil control	Cyl. 6 ignition coil
25	A	Cyl. 5 ignition coil control	Cyl. 5 ignition coil
26	E	Battery voltage	B+ junction point
27	A	Engine control module relay control	Engine control module relay, terminal 85
28	M	Ground for electronics and shielding of sensors	Ground point


E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
29	A	Idle speed control valve - opening winding control	Idle speed control valve
30		Not used	
31	A	Cyl. 3 fuel injection valve control	Cyl. 3 fuel injection valve
32	A	Cyl. 2 fuel injection valve control	Cyl. 2 fuel injection valve
33	A	Cyl. 1 fuel injection valve control	Cyl. 1 fuel injection valve
34	M	Ground remaining output stages (except for ignition and fuel injection valves)	Ground point
35		Not used	
36	A	Evaporative emission valve control	Evaporative emission valve
37		Not used	
38	A	Oxygen sensor heater control	Oxygen sensor relay, terminal 85
39		Not used	
40	M	Oxygen sensor signal ground	Heated oxygen sensor
41	E	Hot wire air mass meter	Hot wire air mass meter
42	E	Vehicle speed signal	Instrument cluster
43	E	Crankshaft position/RPM sensor signal (-)	Crankshaft position/RPM sensor
44	M	Ground for sensors	Engine intake air temperature sensor, engine coolant temperature sensor, and throttle position sensor
45	M	Ground for shield	Shield
46	A	Ti measurement signal (fuel consumption)	Instrument cluster
47	A	Crankshaft RPM speed signal TD	Instrument cluster
48	A	A/C compressor control	Compressor control relay, terminal 85
49		Not used	
50	A	Cyl. 1 Ignition coil control	Cyl. 1 Ignition coil
51	A	Cyl. 2 Ignition coil control	Cyl. 2 Ignition coil
52	A	Cyl. 3 Ignition coil control	Cyl. 3 Ignition coil
53		Not used	
54	E	Battery voltage from engine control module relay	Engine control module relay, terminal 87a
55	M	Ground, ignition	Ground point
56	E	Ignition switch, terminal 15	Ignition switch
57	E	Ignition timing intervention	Transmission control module (EGS)

E = Input, A = Output, M = Ground




Pin Assignments

Pin	Type	Description/Function	Connection
58		Not used	
59	A	5V component supply	Throttle position sensor
60	E	Programming voltage	Data link connector
61		Not used	
62		Not used	
63		Not used	
64	E	A/C switch	Integrated climate regulation control module
65	E	A/C pressure signal	Pressure switch
66	E	Drive-away protection signal (code)	Starter interlock module
67		Not used	
68		Not used	
69	E	Cyl. 4-6 knock sensor	Cyl. 4-6 knock sensor
70	E	Cyl. 1-3 knock sensor	Cyl. 1-3 knock sensor
71	M	Ground for knock sensors and shields	Cyl. 1-3 knock sensor, cyl. 4-6 knock sensor, and shields
72		Not used	
73	E	Throttle position	Throttle position sensor
74		Not used	
75		Not used	
76		Not used	
77	E	Engine intake air temperature	Engine intake air temperature sensor
78	E	Engine coolant temperature	Engine coolant temperature sensor
79		Not used	
80		Not used	
81	E	Drive range P/N	Automatic transmission range switch
82		Not used	
83		Not used	
84		Not used	
85		Not used	
86		Not used	
87	E	RxD diagnosis data line	Data link connector
88	E/A	TxD diagnosis data line	Data link connector

E = Input, A = Output, M = Ground

POWER, FUEL INJECTION VALVES





BMW 3 ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)

FUEL PUMP, IGNITION COILS

HOT IN RUN AND START

P80
FRONT POWER
DISTRIBUTION BOX

15 F28
5A

16 X10017

FUSE DETAILS
0670.3

5 X511

S3
AUTOMATIC
TRANSMISSION
RANGE SWITCH
0) OFF (LOW)
1) ON (HIGH)

7 X511

.5 BR/SW

X191

.5 BR/SW

ELECTRONIC
TRANSMISSION
CONTROL (EGS
A4S 310R)
2460.2

.5 BR/SW

ELECTRONIC
TRANSMISSION
CONTROL (EGS
A5S 310Z)
2460.4

X8042

.5 BR/SW

WITH EGS

WITHOUT EGS

81

31

56

31

.5 GN

X6000

A6000
ENGINE CONTROL
MODULE (DME)


EGS A4S 310R

	L1	L2	L3	L4
P	1	1	0	1
R	1	0	0	0
N	1	1	1	0
D	0	0	0	1
3	0	0	1	1
2	1	0	1	1
1	0	0	1	0

EGS A5S 310Z

	L1	L2	L3	L4
P	1	1	0	1
R	1	0	0	0
N	1	1	1	0
D	0	0	0	1
4	0	0	1	1
3	1	0	1	1
2	0	0	1	0

HOT AT ALL TIMES



S2
IGNITION SWITCH
0) OFF
1) ACCESSORY
2) RUN
3) START

1 X209

2.5 GN

7 X33

2.5 GN

X203

2.5 GN

21 X20

2.5 GN

X8832

4 GN

HOT IN RUN AND START

4 GN

.5 GN

X6830

4 GN

POWER
DISTRIBUTION
0670.2

1210.13-01

POWER
DISTRIBUTION
0670.2

1.5 RT

30

87

2

1.5 GN/VI

1.5 GN/VI

13 X20

1.5 GN/VI

15 X10016

16 X10016

11 X13

1.5 GN/VI

2 X638

M2
FUEL PUMP

1 X638

GROUND
DISTRIBUTION
0670.4

X13006

1210.13-00

.5 RT/WS

8 X6301

86

85

4 X6301

.5 BR/GN


1 X6000


31

31


K6301
CYL. 1-6 FUEL
PUMP RELAY

A6000
ENGINE CONTROL
MODULE (DME)






ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)








ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)



ENGINE CONTROL SYSTEM (DME M3.3.1, 6-CYLINDER M50)







Pin Assignments


X5024

Pin	Type	Description/Function	Connection
1	A	Valve 1 (delayed setting)	Variable camshaft control valve 1
2	M	Ground	Ground
3	A	RxD diagnostic data link	Data link connector
4	E/A	CAN-High signal	Engine control module (DME)
5	M	Ground	Ground
6	E	Sensor 1 (output NW)	Variable camshaft control sensor 1
7		Not used	
8	E	Battery voltage	DME-relay
9	A	Valve 2 (advanced setting)	Variable camshaft control valve 2
10	E	Fan signal	High speed relay (auxiliary fan)
11	E/A	TxD diagnostic data link	Data link connector
12	E/A	CAN-Low signal	Engine control module (DME)
13	E	Battery voltage	DME-relay
14	E	Sensor 2 (input NW)	Variable camshaft control sensor 2
15		Not used	

X6000

Pin	Type	Description/Function	Connection
1	A	Fuel pump relay control	Fuel pump relay
2	A	Close winding control	Idle speed control valve
3	A	Cyl. 1 fuel injection valve control	Cyl. 1 fuel injection valve
4	A	Cyl. 3 fuel injection valve control	Cyl. 3 fuel injection valve
5	A	Cyl. 2 fuel injection valve control	Cyl. 2 fuel injection valve
6	M	Ground, full injection output stages	Ground
7		Not used	
8	A	"Check engine" indicator control	Instrument cluster
9		Not used	
10		Not used	
11		Not used	


E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
12	E	Oxygen sensor II signal	Heated oxygen sensor
13	E	Oxygen sensor I signal	Heated oxygen sensor
14	M	Ground, hot film air mass meter	Hot film air mass meter
15	E	Ignition control signal	Ground
16	E	Crankshaft position/RPM sensor signal	Crankshaft position/RPM sensor
17	E	Camshaft position sensor signal	Hall effect camshaft sensor
18		Not used	
19	A	Secondary air pump	Double relay
20		Not used	
21		Not used	
22		Not used	
23	A	Cyl. 2 ignition coil control	Cyl. 2 ignition coil
24	A	Cyl. 3 ignition coil control	Cyl. 3 ignition coil
25	A	Cyl. 1 ignition coil control	Cyl. 1 ignition coil
26	E	Battery voltage	Jump start junction point
27	A	DME relay signal	Engine control module relay
28	M	Ground	Ground
29	A	Opening winding control	Idle speed control valve
30		Not used	
31	A	Cyl. 5 fuel injection valve control	Cyl. 5 fuel injection valve
32	A	Cyl. 6 fuel injection valve control	Cyl. 6 fuel injection valve
33	A	Cyl. 4 fuel injection valve control	Cyl. 4 fuel injection valve
34	M	Ground, output stages	Ground
35		Not used	
36	A	Evaporative emission valve control	Evaporative emission valve
37	A	Oxygen sensor heater control	Double relay
38		Not used	
39	M	Ground, oxygen sensor II	Heated oxygen sensor
40	M	Ground, oxygen sensor I	Heated oxygen sensor
41	E	Air mass meter signal	Hot film air mass meter
42	E	Vehicle speed signal	Instrument cluster
43	M	Ground, crankshaft sensor	Crankshaft position/RPM sensor


E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
44	M	Ground, camshaft sensor	Hall effect camshaft sensor
45		Not used	
46	A	Ti - measurement signal (fuel consumption)	Instrument cluster/On Board Computer
47	A	Crankshaft RPM speed signal TD	Instrument cluster
48	E	A/C compressor signal	Compressor control relay
49		Not used	
50	A	Cyl. 4 ignition coil control	Cyl. 4 ignition coil
51	A	Cyl. 6 ignition coil control	Cyl. 6 ignition coil
52	A	Cyl. 5 ignition coil control	Cyl. 5 ignition coil
53		Not used	
54	E	Battery voltage	Engine control module (DME)
55	M	Ground, ignition	Ground
56	E	Voltage, terminal 15	Ignition switch
57		Not used	
58		Not used	
59	A	5V voltage supply	Throttle position sensor
60	E	Programming voltage	Data link connector
61		Not used	
62		Not used	
63		Not used	
64	E	A/C signal	Integrated climate regulation control module
65	E	A/C pressure signal	Pressure switch/Auxiliary VENT I
66	E	Drive away protection signal	Starter interlock module
67		Not used	
68	E	Knock sensor signal	Cyl. 5-6 knock sensor
69	E	Knock sensor signal	Cyl. 3-4 knock sensor
70	E	Knock sensor signal	Cyl. 1-2 knock sensor
71	M	Ground, knock sensors and shields	Knock sensors and shields
72		Not used	
73	E	Throttle position	Throttle position sensor
74		Not used	
75		Not used	

E = Input, A = Output, M = Ground





Pin Assignments

Pin	Type	Description/Function	Connection
76		Not used	
77	E	Engine intake air temperature	Engine intake air temperature sensor
78	E	Engine coolant temperature	Engine coolant temperature sensor
79		Not used	
80		Not used	
81		Not used	
82	E	Start revolution signal	Ignition switch
83		Not used	
84	M	Shield	Ground
85	E/A	CAN-Low signal	Variable camshaft control module
86	E/A	CAN-High signal	Variable camshaft control module
87	A	RxD diagnostic data link	Data link connector
88	E/A	TxD diagnostic data link	Data link connector

E = Input, A = Output, M = Ground












ENGINE CONTROL SYSTEM (DME M3.3, 6-CYLINDER S50 B30)


CDN


POWER
















ENGINE CONTROL SYSTEM (DME M3.3, 6-CYLINDER S50 B30)

CDN







1230.0






1240.0



	L1	L2	L3	L4
P	1	1	0	1
R	1	0	0	0
N	1	1	1	0
D	0	0	0	1
3	0	0	1	1
2	1	0	1	1
1	0	0	1	0



09/94

2460 2

1995

09/94


2460 2


1995

09/94

2460 2

1995






Pin Assignments

X8500

Pin	Type	Description/Function	Connection
1	A	Shift lock solenoid control	Shift lock
2	E	Automatic mode signal	Program switch
3		Not used	
4	A	Ignition timing intervention	Engine control module (DME)
5		Not used	
6	E	ASC signal	ABS/ASC control module
7	A	S-program indication	Not used
8	E	Gear range signal L3	Automatic transmission range switch
9	E	Ti measurement signal (fuel consumption)	Engine control module (DME)
10	A	A-program indication	Program switch
11	E	Cyl. 1-6 fuel pump relay control	Engine control module (DME)
12	A	M-program indication	Program switch
13	E/A	TxD diagnostic data link	Data link connector
14	E	Output speed (-)	Transmission valve unit
15	E	Brake switch test signal	Brake light switch
16		Not used	
17	E	Oil temperature signal (analog ground)	Transmission valve unit
18	A	Shield for speed sensor	Transmission valve unit shield
19	M	Ground, power	Ground point
20	E	Output speed (+)	Transmission valve unit
21	E	A/C compressor ON-signal	Engine control module (DME)
22	E	Oil temperature signal (+)	Transmission valve unit
23	E	Gear range signal L1	Automatic transmission range switch
24		Not used	
25	A	RxD diagnostic data link	Data link connector
26	E	Gear range signal L2	Automatic transmission range switch
27		Not used	
28	E	Battery voltage	B+ junction point
29	A	Fault indicator signal	Instrument cluster
30	E	Kick-down signal	Kick-down switch

E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
31	E	Manual mode signal	Program switch
32		Not used	
33	E	Gear range signal L4	Automatic transmission range switch
34	E	S-program button	Not used
35	A	Ground, shift lock solenoid	Shift lock
36	M	Ground, electronic	Ground point
37	E	Voltage supply	Engine control module relay, terminal 87a
38	A	Torque converter clutch solenoid valve control	Transmission valve unit
39	E	Brake pedal position	Brake light switch
40	A	Hydraulic pressure regulator control (+)	Transmission valve unit
41	A	Hydraulic pressure regulator control (-)	Transmission valve unit
42		Not used	
43	A	Solenoid valve 2 control (+)	Transmission valve unit
44		Not used	
45	A	Band solenoid control (+)	Transmission valve unit
46		Not used	
47		Not used	
48	A	Solenoid valve 1 control (+)	Transmission valve unit
49		Not used	
50		Not used	
51		Not used	
52		Not used	
53		Not used	
54	A	Solenoid valves ground control	Transmission valve unit
55	E	Throttle position signal	Engine control module (DME)

E = Input, A = Output, M = Ground

(


)



2460.2

ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)


POWER, PROGRAM SWITCH






ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)

GEAR VALVE UNIT




ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)






ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)


GEAR SELECTOR SWITCH




ELECTRONIC TRANSMISSION CONTROL (EGS A4S 310R)

SHIFT LOCK, DATA LINK, KICK-DOWN SWITCH








Pin Assignments

X7000

Pin	Type	Description/Function	Connection
1		Not used	
2		Not used	
3	A	Solenoid valve 5	Transmission valve unit
4	A	Torque converter clutch solenoid valve	Transmission valve unit
5	A	Hydraulic pressure regulator	Transmission valve unit
6		Not used	
7		Not used	
8		Gear range signal L2	Automatic transmission range switch
9		Gear range signal L4	Automatic transmission range switch
10		Not used	
11		Not used	
12	E	S-program indication	Program switch
13	E	*-program indication	Program switch
14	E	Speed sensor	Transmission valve unit
15	M	Shield speed sensor	Shield
16	A	Speed sensor n-turbine	Transmission valve unit
17		Not used	
18	E	Kick-down-signal	Kick-down-switch
19	E	ABS signal	ABS/ASC control module
20		Not used	
21	M	Ground oil temperature sensor	Transmission valve unit
22	E	Oil temperature sensor	Transmission valve unit
23		Not used	
24		Not used	
25	A	Fault indicator signal	Instrument cluster
26	E	Battery voltage	Jump start junction point
27		Not used	
28	M	Ground, electronics	Ground
29		Not used	
30	A	Solenoid valve 1	Transmission valve unit


E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
31	A	Solenoid valve 4	Transmission valve unit
32	A	Solenoid valve 3	Transmission valve unit
33	A	Solenoid valve 2	Transmission valve unit
34	M	Ground	Ground
35	E	DKT-interface	Engine control module (DME)
36	E	Gear range signal L1	Automatic transmission range switch
37	E	Gear range signal L3	Automatic transmission range switch
38		Not used	
39		Not used	
40	A	Ignition timing intervention	Engine control module (DME)
41	E	Ti - measurement signal (fuel consumption)	Engine control module (DME)
42	A	Speed sensor n - ab (+)	Transmission valve unit
43	E	Crankshaft RPM speed signal TD	Engine control module (DME)
44	E	Speed sensor n-turbine	Transmission valve unit
45	E	E-program indication	Program switch
46		Not used	
47		Not used	
48		Not used	
49		Not used	
50		Not used	
51		Not used	
52		Not used	
53	A	Voltage supply for solenoid valves	Transmission valve unit
54	E	Voltage supply	DME-relay
55		Not used	
56		Not used	
57		Not used	
58		Not used	
59		Not used	
60		Not used	
61		Not used	
62		Not used	

E = Input, A = Output, M = Ground





Pin Assignments

Pin	Type	Description/Function	Connection
63		Not used	
64		Not used	
65		Not used	
66		Not used	
67		Not used	
68		Not used	
69		Not used	
70		Not used	
71		Not used	
72		Not used	
73		Not used	
74		Not used	
75		Not used	
76		Not used	
77		Not used	
78		Not used	
79		Not used	
80		Not used	
81		Not used	
82		Not used	
83		Not used	
84		Not used	
85		Not used	
86		Not used	
87	A	RxD diagnostic data link	Data link connector
88	E/A	TxD diagnostic data link	Data link connector


E = Input, A = Output, M = Ground

ELECTRONIC TRANSMISSION CONTROL (EGS A5S 310Z)







ELECTRONIC TRANSMISSION CONTROL (EGS A5S 310Z)





ELECTRONIC TRANSMISSION CONTROL (EGS A5S 310Z)










3234.0

SUPPLEMENTAL RESTRAINT SYSTEM (AIR BAG)








Pin Assignments

X11

Pin	Type	Description/Function	Connection
1	M	Ground, control module	Chassis ground
2	M	Ground, control module	ABS hydraulic unit solenoid valve, FL
3	E	Voltage monitoring	ABS hydraulic unit
4		Not used	
5		Not used	
6		Not used	
7		Not used	
8		Not used	
9		Not used	
10		Not used	
11		Not used	
12		Not used	
13		Not used	
14		Not used	
15	A	ABS pump motor relay control	ABS pump motor relay
16	E	ABS pedal travel sensor	ABS pedal travel sensor
17		Not used	
18		Not used	
19	M	Ground, control module	Chassis ground
20	A	Left front inlet valve control	ABS hydraulic unit
21	A	Right front outlet valve control	ABS hydraulic unit
22		Not used	
23	A	RxD diagnostic data link	Data link connector
24		Not used	
25		Not used	
26		Not used	
27	A	Speed sensor ground, RR	Right rear speed sensor - ABS
28	A	Speed sensor ground, RL	Left rear speed sensor - ABS
29	A	Speed sensor ground, FR	Right front speed sensor - ABS
30	A	Speed sensor ground, FL	Left front speed sensor - ABS

E = Input, A = Output, M = Ground




Pin Assignments


Pin	Type	Description/Function	Connection
31	E	Pump motor sensor shield	ABS hydraulic unit
32	E	Brake light signal	Brake light switch
33	E	Operating voltage	ABS relay
34	A	ABS relay control	ABS relay
35		Not used	
36	A	Rear axle outlet valve control	ABS hydraulic unit
37		Not used	
38	A	Right front inlet valve control	ABS hydraulic unit
39		Not used	
40		Not used	
41	E	ABS pedal travel sensor	ABS pedal travel sensor
42	E/A	TxD diagnostic data link	Data link connector
43		Not used	
44		Not used	
45	E	Speed sensor signal RR	Right rear speed sensor - ABS
46	E	Speed sensor signal RL	Left rear speed sensor - ABS
47	E	Speed sensor signal FR	Right front speed sensor - ABS
48	E	Speed sensor signal FL	Left front speed sensor - ABS
49	E	Pump motor sensor signal	ABS hydraulic unit
50		Not used	
51		Not used	
52	A	ABS warning lamp control	Instrument cluster
53	E	Voltage supply, terminal 15	Front power distribution box, fuse 21
54	A	Rear axle inlet valve control	ABS hydraulic unit
55		Not used	


E = Input, A = Output, M = Ground





3450.0












Pin Assignments

X1170

Pin	Type	Description/Function	Connection
1	A	ABS relay control	ABS relay
2	A	Right front inlet valve control	ABS hydraulic unit
3		Not used	
4		Not used	
5		Not used	
6		Not used	
7		Not used	
8	E	Voltage supply, terminal 15	Front power distribution box, fuse 23
9	E	Operating voltage	ABS relay
10	A	Right front outlet valve control	ABS hydraulic unit
11		Not used	
12	A	ABS warning lamp control	Instrument cluster
13	A	Speed sensor ground, RL	Left rear speed sensor - ABS
14	A	Speed sensor ground, RR	Right rear speed sensor - ABS
15	A	Speed sensor ground, FR	Right front speed sensor - ABS
16	A	Speed sensor ground, FL	Left front speed sensor - ABS
17	M	Ground, control module	Chassis ground
18		Not used	
19	E	Voltage supply, terminal 15	Front power distribution box, fuse 21
20		Not used	
21		Not used	
22	A	Left front inlet valve control	ABS hydraulic unit
23	A	ABS pump motor relay control	ABS pump motor relay
24	A	Rear axle inlet valve control	ABS hydraulic unit
25	A	Left front outlet valve control	ABS hydraulic unit
26	M	Ground, control module	Chassis ground
27	E	Voltage monitoring, hydraulics	ABS hydraulic unit
28	E/A	TxD diagnostic data link	Data link connector
29	E	Brake light signal	Brake light switch
30		Not used	

E = Input, A = Output, M = Ground




Pin Assignments


Pin	Type	Description/Function	Connection
31		Not used	
32		Not used	
33		Not used	
34	E	Speed sensor signal RL	Left rear speed sensor - ABS
35	E	Speed sensor signal RR	Right rear speed sensor - ABS
36	E	Speed sensor signal FR	Right front speed sensor - ABS
37	E	Speed sensor signal FL	Left front speed sensor - ABS
38		Not used	
39	A	Rear axle outlet valve control	ABS hydraulic unit
40		Not used	
41	M	Ground, control module	Chassis ground
42		Not used	
43		Not used	
44		Not used	
45		Not used	
46		Not used	
47		Not used	
48		Not used	
49		Not used	
50		Not used	
51		Not used	
52		Not used	
53		Not used	
54		Not used	
55		Not used	


E = Input, A = Output, M = Ground





3450.0












Pin Assignments

X1171

Pin	Type	Description/Function	Connection
1	M	Ground	Ground
2	E	Battery voltage	ABS relay
3	M	Ground, module	Ground
4	E	Signal	DME-module
5	A	EML-signal	DME-module
6	A	Transmission influence	EGS-module
7	E/A	TxD-signal	Diagnostic link
8	A	RxD-signal	Diagnostic link
9		Not used	
10	A	Sensor ground	ABS-speed sensor rear right
11	A	Sensor ground	ABS-speed sensor front right
12		Not used	
13	A	ABS-power protection relay	ABS-power protection relay
14	E	Signal ABS-travel sensor	ABS-travel sensor
15		Not used	
16	E	Current	ABS-relay
17	A	Solenoid valve signal left rear	ABS-hydraulic unit
18	A	Solenoid valve signal left rear	ABS-hydraulic unit
19	M	Ground	Ground
20	A	ADS-step Motor	ADS-step motor
21	A	ADS-step Motor	ADS-step motor
22	A	Solenoid valve signal right front	ABS-hydraulic unit
23	E	ASC-throttle flap potentiometer	ASC-throttle flap motor
24		Not used	
25	E	Signal idle speed	DME-module
26	A	Throttle flap position	DME-module
27	E	ASC-switch signal	ASC-switch
28		Not used	
29	A	Sensor ground	ABS-speed sensor rear left
30	A	Sensor ground	ABS-speed sensor front left

E = Input, A = Output, M = Ground




Pin Assignments


Pin	Type	Description/Function	Connection
31	A	Signal ABS-travel sensor	ABS-travel sensor
32	E	Brake signal	Brake light switch
33	E	Plus supply	ABS-protection relay
34	A	ABS-lamp control	Instrument cluster
35	E	Ignition signal	Ignition switch
36	A	Solenoid valve	ABS-hydraulic unit
37	A	Solenoid valve signal right front	ABS-hydraulic unit
38		Not used	
39	A	Solenoid valve signal left rear	ABS-hydraulic unit
40	A	Solenoid valve signal left front	ABS-hydraulic unit
41	E	Speed signal	DME-module
42	E	ASC-throttle flap potentiometer	ASC-throttle flap potentiometer
43	E	ASC-throttle flap potentiometer	ASC-throttle flap potentiometer
44	A	ASC-lamp control	Instrument cluster
45	E	Speed sensor signal rear right	Speed sensor rear right
46	E	Speed sensor signal rear left	Speed sensor rear left
47	E	Speed sensor signal front right	Speed sensor front right
48	E	Speed sensor signal front left	Speed sensor front left
49	E	Pump motor sensor signal	ABS-hydraulic unit
50	E	Shield pump motor sensor	ABS-hydraulic unit
51	E	Plus supply	Front power distribution box
52	A	ABS-pump motor relay	ABS-pump motor relay
53		Not used	
54	A	Solenoid valve signal left front	ABS-hydraulic unit
55	A	Solenoid valve signal left rear	ABS-hydraulic unit


E = Input, A = Output, M = Ground





3450.1



















POWER MIRRORS

OUTSIDE MIRROR












ZKE CENTRAL LOCKING (ZV) DRIVE-AWAY PROTECTION

EARLY PRODUCTION






ZKE CENTRAL LOCKING (ZV)

DRIVE-AWAY PROTECTION

LATE PRODUCTION



11/94

5126.0-04


1995





POWER WINDOWS (FH)


INPUT DETAILS






POWER WINDOWS (FH)

INPUT DETAILS



INPUT DETAILS






POWER WINDOWS (FH)

TWO-DOOR

INPUT DETAILS



09/94


5133.1-03

1995



POWER WINDOWS (FH)


OUTPUT DETAILS






POWER WINDOWS (FH)

OUTPUT DETAILS










POWER SEATS

PASSENGER'S SEAT











EARLY PRODUCTION







POWER SUN ROOF (SHD)

LATE PRODUCTION







Pin Assignments

A = X13156

B = X13157

C = X13159


X13156

Pin	Type	Description/Function	Connection
1		Not used	
2		Not used	
3		Not used	
4	E/A	Control signal	Convertible top motor
5	E/A	Control signal	Convertible top storage lid motor
6	M	Ground	Ground
7		Not used	
8	E/A	Control signal	Convertible top motor
9	E/A	Control signal	Convertible top storage lid motor
10	E	Plus supply 12V	Front power distribution box

X13157

Pin	Type	Description/Function	Connection
1	A	Plus supply	Position sensor (convertible top storage lid motor)
2	E	Position signal	Convertible top position micro switch
3	E	Position signal	Convertible top end position micro switch
4	E	Component ground	Position sensor (convertible top storage lid motor)
5	E	Position signal	Convertible top position micro switch
6	E	Control signal	Position sensor (convertible top storage lid motor)

E = Input, A = Output, M = Ground



Pin Assignments

X13159

Pin	Type	Description/Function	Connection
1	E	Top open signal	Convertible top actuating switch
2		Not used	
3		Not used	
4	E/A	TxD data signal	Data link connector
5	M	Ground	Hard top connector 1
6	E	Power supply	Front power distribution box
7		Not used	
8	E	Rear window blower signal	Rear window blower micro switch
9		Not used	
10	A	Data signal	Body electronics control module
11		Not used	
12	A	Data signal	Roll over sensor
13	A	Speed signal	Instrument cluster
14	E	Top closed signal	Convertible top actuating switch
15		Not used	
16	A	RxD data signal	Data link connector
17		Not used	
18		Not used	
19	A	Data signal	Roll over sensor
20	E	Trunk lid signal	Trunk lid micro switch
21		Not used	
22	A	Data signal	Body electronics control module
23	A	Roll over signal	Instrument cluster
24	A	Data signal	Roll over sensor
25	M	Ground	Ground
26	E	Power supply	Front power distribution box

E = Input, A = Output, M = Ground




5430.0

ELECTRO- MECHANICAL CONVERTIBLE TOP


HOT AT ALL TIMES


HOT AT ALL TIMES

HOT IN ACCY, RUN AND START




ELECTRO- MECHANICAL CONVERTIBLE TOP







ELECTRO- MECHANICAL CONVERTIBLE TOP






5430.0-04







Pin Assignments

A = X10182

B = X13252

C = X13253

D = X13254


E = X13255

F = X13258

X10182

Pin	Type	Description/Function	Connection
1	E	Crash signal	Crash control unit
2	E	Light signal	Light switch
3	E	Power supply	Front power distribution box
4	E	Power supply	Front power distribution box
5	M	Ground	Ground
6		Not used	
7	A	Anti-theft signal	Alpine alarm horn relay
8	E	Glove box signal	Glove box light
9	A	Diagnosis RxD - signal	Data Link connector
10		Not used	
11	E/A	Diagnosis TxD - signal	Data link connector
12	E	KL30h	Starter
13		Not used	
14		Not used	
15	A	Drive away protection	Starter Immobilization Relay
16		Not used	
17	E	Hood signal	Hood micro switches
18	E	Power supply	Front power distribution box

E = Input, A = Output, M = Ground



Pin Assignments


X13252

Pin	Type	Description/Function	Connection
1	E	Power lock signal	Door lock motors
2	A	Voltage supply	All lock motors
3		Not used	
4	E	Automatic interior light signal	Interior light
5		Not used	
6	A	Voltage supply	Power window motor driver's door
7	A	Voltage supply	Power window motor passenger's door
8	E	Power supply	Front power distribution box
9	E	Lock signal	Lock motor & trunk lid relay
10	E	Power supply	Front power distribution box
11	A	Voltage supply	Interior lights, engine comp light glove box light
12	E	Power supply	Front power distribution box
13	E	Motor signal	Power window motor driver's door
14	E	Motor signal	Power window motor passenger's door
15	M	Ground	Ground

X13253

Pin	Type	Description/Function	Connection
1	E	Position signal	Door lock motor driver's door
2	E	Position signal	Door lock motor passenger's door
3	E	Lock signal trunk lid	Trunk lid lock motor, trunk lid relay
4	E	Data signal	Anti-theft system control module (Alpine)
5		Not used	
6		Not used	
7	E	Crash signal	Inertia switch
8	E	Revolution signal	Power window motor driver's door
9	E	Revolution signal	Power window motor passenger's door
10		Not used	

E = Input A = Output, M = Ground




Pin Assignments

Pin	Type	Description/Function	Connection
11		Not used	
12		Not used	
13	E	Central arrest signal	Door lock switches
14	E	Lock signal driver's door	Door lock motor driver's door
15	E	Lock signal passenger's door	Door lock motor passenger's door
16	E	Lock signal trunk lid	Trunk lid lock motor
17	E	Data signal	Anti-theft system control module (Alpine)
18		Not used	
19		Not used	
20	E/A	Data signal	Relay module
21		Not used	
22		Not used	
23	A	Plus supply (revolution)	Power window's motor driver's side
24	A	Voltage supply (revolution)	Power window's motor passenger's side
25		Not used	
26	A	Voltage supply	Luggage compartment lights

X13254

Pin	Type	Description/Function	Connection
1		Not used	
2	E	Door - signal	Door jamb switch driver's door
3	E	Door - signal	Door jamb switch passenger's door
4	E	Convertible trunk lid signal Four-door door-signal	Trunk lid switch/trunk lid relay Door jump switch left rear
5	E	Door signal	Door jump switch right rear
6	E	OPEN - signal	Power window switch driver's door
7	E	CLOSE - signal	Power window switch driver's door
8	E	OPEN - signal	Power window switch passenger's door
9	E	CLOSE - signal	Power window switch passenger's door
10	E	Four-door child protection signal	child protection switch
11		Not used	

E = Input, A = Output M = Ground




Pin Assignments

Pin	Type	Description/Function	Connection
12		Not used	
13		Not used	
14	E	Trunk lid signal	Trunk lid switch
15	A	DATA - signal	Relay module
16	A	DATA - signal	Relay module
17	A	DATA - signal	Relay module
18	A	Convertible DATA - signal	Convertible top control module
19	A	Four-door CORRECT - signal	Comfort relay
20		Not used	
21	A	Convertible DATA - signal	Convertible top control module
22		Not used	
23		Not used	
24		Not used	
25		Not used	
26		Not used	

X13255

Pin	Type	Description/Function	Connection
1	A	DATA - signal	Relay module
2	E	OPEN - signal	Power window switch left rear
3	E	OPEN - signal	Power window switch right rear
4	E	Convertible OPEN - signal Four-door OPEN - signal	Main power window switch Driver's rear window switch
5	E	Convertible DATA - signal Four-door CLOSE - signal	Convertible top control module Passenger's rear window switch
6		Not used	
7	A	DATA - signal	Relay module
8	E	CLOSE - signal	Power window switch left rear
9	E	CLOSE - signal	Power window switch right rear
10	E	Convertible CLOSE - signal Four-door CLOSE - signal	Main power window switch Driver's window switch

E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
11	E	Convertible DATA - signal Four-door OPEN - signal	Convertible top control module Passenger's window switch
12		Not used	
13		Not used	
14		Not used	
15		Not used	
16		Not used	
17		Not used	
18		Not used	
19		Not used	
20		Not used	
21		Not used	
22		Not used	
23		Not used	
24		Not used	
25		Not used	
26		Not used	

X13258

Pin	Type	Description/Function	Connection
1	E	DATA - signal	Central body electronic module
2	A	Voltage supply (motor)	Power window motor right rear
3	E	Signal	Power window motor right rear
4	E	Signal	Power window motor left rear
5	A	Voltage supply (motor)	Power window motor left rear
6		Not used	
7		Not used	
8	M	Ground	Ground
9	E	DATA - signal	Central body electronic module
10	E/A	DATA - signal	Central body electronic module
11	E/A	DATA - signal	Central body electronic module


E = Input, A = Output, M = Ground



09/94

6100.0-f

1995




Pin Assignments

Pin	Type	Description/Function	Connection
12	E	DATA - signal	Central body electronic module
13	E/A	DATA - signal	Central body electronic module
14		Not used	
15	E	Power supply	Front power distribution box


E = Input, A = Output, M = Ground




6100.0





CENTRAL BODY ELECTRONICS (ZKE IV)






CENTRAL BODY ELECTRONICS (ZKE IV)








6135.0





DRIVE-AWAY PROTECTION (EWS II)







DRIVE-AWAY PROTECTION (EWS II)

COMPONENT


A835	TRANSMITTER MODULE (EWS II)		RH side of steering column
A836	CONTROL MODULE (EWS II)		Under glove box
X1659	CONNECTOR (15-PINS, YELLOW)		Under glove box
X1660	CONNECTOR (3-PINS, WHITE)		RH side of steering column
X90260	CONNECTOR (3-PINS, BLACK)		RH side of steering column









HOT IN ACCY, RUN AND START






HEADLIGHT WASHER (SRA)








Pin Assignments

X16

Pin	Type	Description/Function	Connection
1	E	High beam indicator control	Combination switch
2	E	Terminal 58g, instrument illumination power	Dimmer
3	E	Right turn signal indicator control	Hazard flasher relay
4	E	Left turn signal indicator control	Hazard flasher relay
5	E	Warning lamp for EGS fault (information signal transmission oil temperature)	Transmission control module (EGS)
6		Not used	
7		Not used	
8		Not used	
9		Not used	
10	E	Convertible Roll over signal	Convertible top control module
11	A	RxD diagnostic data link	Data link connector
12	E/A	TxD diagnostic data link	Data link connector
13	E	M3 oil temperature	Engine oil temperature sensor
14	E	Airbag warning lamp (SRS) control	Supplemental restraint system control module
15	E	Voltage supply, terminal R for airbag warning lamp (SRS)	Ignition switch, terminal R
16	E	"Check engine" indicator control	Engine control module (DME)
17	E	Park brake warning lamp control	Park brake switch
18	E	Brake fluid warning lamp control	Brake fluid level switch
19	E	Brake pad wear warning lamp control	Brake pad sensors
20	E	Crankshaft RPM speed signal TD	Engine control module (DME)
21	E	Fuel consumption signal + KVA	Engine control module (DME)
22	E	Voltage supply, terminal 30	Front power distribution box, fuse 31
23	E	Voltage supply, terminal 15 for indicator and warning lamps	Front power distribution box, fuse 27
24	M	Ground supply, terminal 31 for instrument cluster electronics	Ground point
25		Not used	
26		Not used	

E = Input, A = Output, M = Ground




Pin Assignments

X17

Pin	Type	Description/Function	Connection
1	E	Trailer turn signal indicator control	Hazard flasher relay
2	A	Vehicle speed signal	Various control modules
3	M	Ground supply, terminal 31 for indicator and warning lamps	Ground point
4	E	Voltage supply terminal 15 for instrument cluster electronics	Front power distribution box, fuse 23
5	E	Voltage supply, terminal 15 for battery charge indicator	Ignition switch, terminal 15
6	E	Ground supply terminal 61 for battery charge indicator	Generator
7		Not used	
8	E	Fog light indicator control	Front power distribution box fuse 15
9	A	Sound tone signal	Chime module
10	A	Information signal, fuel tank content	On-board computer
11	E	Slip control system warning lamp (ABS) control	Slip control module (ABS)
12	E	ASC signal	ASC control module
13		Not used	
14	E	Seat belt warning lamp control	Driver's seat belt switch
15	E	SIA reset/service interval indicator reset	Data link connector
16	E	Voltage supply, terminal R	Front power distribution box, fuse 46
17	A	Coolant temperature sensor	Coolant temperature sensor
18	E	Coolant temperature sensor	Coolant temperature sensor
19	E	Oil pressure warning lamp control	Oil pressure switch
20		Not used	
21		Not used	
22	E	Ignition key warning/audible ignition key warning	Ignition switch
23	E	Driver's door open	Driver's door jamb switch
24	A	Dimmer signal/brightness information signal for connected control modules	On-board computer or multi-function clock

E = Input, A = Output, M = Ground



Pin Assignments


Pin	Type	Description/Function	Connection
25		Not used	
26	E	Central indicator lamp/check-control	On-board computer or multi-function clock

X271


Pin	Type	Description/Function	Connection
1	A	Fuel level sensor	Fuel tank sensors
2		Not used	
3	A	Ground supply for fuel tank sensors and vehicle speed sensor	Fuel tank sensors and vehicle speed sensor
4	E	Position signal tw	Vehicle speed sensor
5		Not used	
6		Not used	
7		Not used	
8	E	Rear fog lights indicator control	Rear fog light switch
9		Not used	
10		Not used	
11		Not used	
12		Not used	


E = Input, A = Output, M = Ground

INSTRUMENT CLUSTER INDICATORS



INSTRUMENT CLUSTER INDICATORS










INSTRUMENT CLUSTER

SIGNAL-OUTPUT SPEEDOMETER



INSTRUMENT CLUSTER INDICATORS






MULTI-FUNCTION CLOCK

HOT AT ALL TIMES


HOT IN RUN AND START

HOT IN ACCY, RUN AND START



MULTI-FUNCTION CLOCK

CHIME, BRAKE LIGHT SWITCH



ON-BOARD DISPLAY

HOT IN ACCY, RUN AND START


HOT IN RUN AND START

HOT AT ALL TIMES

HOT IN RUN AND START


HOT IN ACCY, RUN AND START

HOT IN ACCY, RUN AND START







6300.0






LIGHT SWITCH DETAILS










6312.0




USA














6313.0






TURN/HAZARD LIGHTS







6314.0

PARK/TAIL LIGHTS







LICENSE PLATE/ LUGGAGE COMPARTMENT LIGHTS



LICENSE PLATE/ LUGGAGE COMPARTMENT LIGHTS









6325.0



BRAKE LIGHTS WITHOUT CCM



BMW 3 BRAKE LIGHTS WITH CCM






INTERIOR LIGHTS

TWO DOOR/FOUR DOOR


09/94


6330.3-00


1995




INTERIOR LIGHTS









GLOVE BOX LIGHT/CASSETTE BOX/ASHTRAY LIGHT/CHARGING SOCKET/CIGAR LIGHTER








6350.0












HOT IN RUN AND START


HOT AT ALL TIMES





REAR WINDOW DEFOGGER


REAR WINDOW ANTENNA






REAR WINDOW DEFOGGER


3-ANTENNA-DIVERSITY





6424.0-04





Pin Assignments

A = X18155 26 Pins, white

B = X18156 26 Pins, black

C = X18157 26 Pins, blue

X18155

Pin	Type	Description/Function	Connection
1	A	Function light, air recirculation	IHKR control panel
2		Not used	
3	A	Function light, rear window defogger	IHKR control panel
4	A	Function light, air conditioning	IHKR control panel
5	E	Rear window defogger switch	IHKR control panel
6	E	Air circulation switch	IHKR control panel
7	E	Air conditioning switch	IHKR control panel
8		Not used	
9	A	Ground for rear window defogger switch, air recirculation switch, air conditioning switch, electric flaps switch, and function lights	IHKR control panel
10		Not used	
11	A	Ground for temperature sensors	Various temperature sensors
12	A	Ground for rotary switches and interior temperature sensor	IHKR control panel
13		Not used	
14	E	Voltage supply for function lights	IHKR control panel
15 (USA)	E	Terminal 58K	Light switch
16		Not used	
17		Not used	
18	E	Crankshaft position/RPM signal TD	Engine control module (DME)
19	A	Vehicle speed	Instrument cluster
20	E	Independent ventilation	Park heating/ventilation relay
21		Not used	
22	A/E	Evaporator temperature	Evaporator temperature sensor
23	A/E	Outside temperature	Outside temperature sensor

E = Input, A = Output, M = Ground




Pin Assignments

Pin	Type	Description/Function	Connection
24	A/E	Heater temperature, left	Left heat exchanger temperature sensor
25	A/E	Heater temperature, right	Right heat exchanger temperature sensor
26		Not used	

X18156

Pin	Type	Description/Function	Connection
1	E	Terminal 30h	Starter, terminal 30h
2	E	Terminal 61	Generator
3		Not used	
4	E	Voltage supply, terminal 15	Front power distribution box, fuse 23
5	A	Left water valve activation	Water valve assembly
6		Not used	
7		Not used	
8		Not used	
9		Terminal 15 (independent ventilation only)	Park heating/ventilation relay
10		Not used	
11		Not used	
12	A	Right water valve activation	Water valve assembly
13		Not used	
14	E	Voltage supply, terminal 30	Front power distribution box, fuse 31
15	E	Voltage supply, terminal 30	Front power distribution box, fuse 31
16	M	Ground for load circuit	Ground point
17	M	Ground for load circuit	Ground point
18	A	Engine control module (DME) activation (anti-stall)	Engine control module (DME)
19		Not used	
20		Not used	
21	E	Nominal temperature valve, right	IHKR control panel
22	E	Nominal temperature valve, left	IHKR control panel
23	E	Nominal air flow valve	IHKR control panel
24	A/E	Interior temperature sensor	IHKR control panel

E = Input, A = Output, M = Ground



Pin Assignments

Pin	Type	Description/Function	Connection
25		Not used	
26	M	Ground for electronics	Ground point

X18157

Pin	Type	Description/Function	Connection
1	A	Voltage supply for recirculation flap motor	Recirculation flap motor
2	A	Voltage supply for dash vent mixing flap motor	Dash vent mixing flap motor
3	A	Voltage supply for fresh air flap motor	Fresh air flap motor
4		Not used	
5		Not used	
6	A	Recirculation flap motor activation	Recirculation flap motor
7	A	Recirculation flap motor activation	Recirculation flap motor
8	A	Recirculation flap motor activation	Recirculation flap motor
9	A	Recirculation flap motor activation	Recirculation flap motor
10	A	Fresh air flap motor activation	Fresh air flap motor
11	A	Fresh air flap motor activation	Fresh air flap motor
12	A	Fresh air flap motor activation	Fresh air flap motor
13	A	Fresh air flap motor activation	Fresh air flap motor
14	A	Voltage supply for rotary switches	IHKR control panel
15	A	RxD diagnostic data line	Data link connector
16	E/A	TxD diagnostic data line	Data link connector
17	E	Ventilation flap switch	IHKR control panel
18	A	Interior sensor blower activation	IHKR control panel
19		Not used	
20	A	Rear window defogger activation	Rear defogger relay, terminal 86b
21		Not used	
22	A	Activate A/C compressor	Pressure switch
23	A	Dash vent mixing flap motor activation	Dash vent mixing flap motor
24	A	Dash vent mixing flap motor activation	Dash vent mixing flap motor


E = Input, A = Output, M = Ground



09/94

6450.4-d

1995



Pin Assignments

Pin	Type	Description/Function	Connection
25	A	Dash vent mixing flap motor activation	Dash vent mixing flap motor
26	A	Dash vent mixing flap motor activation	Dash vent mixing flap motor


E = Input, A = Output, M = Ground




6450.4

INTEGRATED CLIMATE REGULATION (IHKR E36)


POWER, BLOWER CONTROLS





INTEGRATED CLIMATE REGULATION (IHKR E36)


CONTROL MODULE, WATER VALVES






INTEGRATED CLIMATE REGULATION (IHKR E36)


TEMPERATURE CONTROL




AIR DELIVERY




INTEGRATED CLIMATE REGULATION (IHKR E36) COMPRESSOR CONTROLS








STEREO, 6-SPEAKER SYSTEM










RADIO/HIFI


HIFI, 10-SPEAKER SYSTEM





RADIO/HIFI


HIFI, 10-SPEAKER SYSTEM





RADIO/HIFI


HIFI, 10-SPEAKER SYSTEM





CELLULAR TELEPHONE (PROVISIONS)


AMPS SYSTEM






6571.0

CRUISE CONTROL (TEMPOMAT)




BMW 3 CRUISE CONTROL (TEMPOMAT)





ANTI-THEFT SYSTEM (ALPINE)






ANTI-THEFT SYSTEM (ALPINE)

FRONT AND REAR DOOR JAMB SWITCHES

HOT IN ACCY, RUN AND START



30 F47 15A P85
AUXILIARY
FUSE BOX

X10250
FUSE DETAILS
0670.3

N12w
ANTI-THEFT
CONTROL MODULE
(ALPINE)

[illegible]

 A104
BODY ELEC-
TRONICS CONTROL
MODULE (ZKE IV)



N4
ON-BOARD
COMPUTER

2 X1171

.5 VI/GN/GE

.5 VI/GN/GE

.5 VI/GN/GE

2 X539

NOT USED

1 X539

.5 BR

2 X371

1 X371

S21w
ENGINE HOOD
SWITCH
1) HOOD OPEN
2) HOOD CLOSED


.5 BR

GROUND
DISTRIBUTION
0670.4
X10012





6581.2

ON-BOARD COMPUTER (BC V) POWER




BMW 3 **ON-BOARD COMPUTER (BC V)**
CHIME, BRAKE LIGHT SWITCH









ON-BOARD COMPUTER (BC V) CHECK CONTROL







ON-BOARD COMPUTER (BC V) CHECK CONTROL





COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

A2	INSTRUMENT CLUSTER	LH side of dash	28-3
A4	CHECK CONTROL MODULE	Below LH side of dash	00-3
A5	RELAY MODULE	Behind glove box	
A7	SLIP CONTROL MODULE (ABS)	RH side of dash behind glove box	01-2
A8	CRUISE CONTROL MODULE (TEMPOMAT)	RH side of dash behind glove box	01-2
A12	SUPPLEMENTAL RESTRAINT SYSTEM CONTROL MODULE	Below rear seat	00-2
A18	HIFI AMPLIFIER	Below RH side of rear seat Convertible	02-3
A18	HIFI AMPLIFIER	In LH side of luggage compartment	04-1
A35	ON-BOARD DISPLAY	Center of dash center console	
A51	WIPER/WASHER MODULE	Behind glove box (glove box removed)	01-1
A52	SLIP CONTROL MODULE (ABS/ASC)	Behind glove box (glove box removed)	01-3
A56	SUNROOF CONTROL ASSEMBLY	Under roof center panel	04-2
A64	WIPER/WASHER MODULE (LOW II)	Behind glove box (glove box removed)	
A87y	INTEGRATED CLIMATE REGULATION CONTROL MODULE	Center console	03-2
A96	CONVERTIBLE TOP CONTROL MODULE	In lower LH C-pillar behind side panel	02-1
A104	BODY ELECTRONICS CONTROL MODULE (ZKE IV)	Behind glove box (glove box removed)	01-1
A113	SEAT OCCUPANCY DETECTOR	Under RH front seat	
A117	TELEPHONE EJECT BOX	Center console	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

A5024	VARIABLE CAMSHAFT CONTROL MODULE (VANOS)	Rear RH side of engine compartment	04-3
A6000	ENGINE CONTROL MODULE (DME)	Rear RH side of engine compartment	00-1
A7000	TRANSMISSION CONTROL MODULE (EGS)	Rear RH side of engine compartment	00-1
A8500	TRANSMISSION CONTROL MODULE (EGS)	Rear RH side of engine compartment	00-1
B1	RIGHT FRONT SPEED SENSOR - ABS	On RH front wheel, above brake caliper	08-3
B2	LEFT FRONT SPEED SENSOR - ABS	On LH front wheel, above brake caliper	08-3
B3	RIGHT REAR SPEED SENSOR - ABS	On RH rear wheel, above brake caliper	
B4	LEFT REAR SPEED SENSOR - ABS	On LH rear wheel, above brake caliper	
B6	FUEL LEVEL SENSOR	Below LH side of rear seat	21-2
B10	VEHICLE SPEED SENSOR	Under rear of car	08-1
B11	LH HEAT EXCHANGER TEMPERATURE SENSOR	Center console	
B12	RH HEAT EXCHANGER TEMPERATURE SENSOR	Center console	
B13	OUTSIDE TEMPERATURE SENSOR	Rear of engine compartment behind RH fresh air cowl	15-2
B14	EVAPORATOR TEMPERATURE SENSOR	RH side of LH footwell LH side of IHKR Plenum	28-1
B16	LEFT FRONT BRAKE PAD SENSOR	On LH front wheel, above brake caliper	08-3
B17	RIGHT REAR BRAKE PAD SENSOR	Behind RH rear wheel	
B18	BRAKE FLUID LEVEL SWITCH	Rear LH side of engine compartment near brake master cylinder top of brake fluid reservoir (325i)	18-3
B21	ON-BOARD COMPUTER TEMPERATURE SENSOR	Front RH side of engine compartment	20-1
B25y	FUEL TANK SENSOR II	Top of fuel tank	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

B400	MICROPHONE	Center of dash	
B5022	VARIABLE CAMSHAFT CONTROL SENSOR 1	Front of engine compartment (M3)	12-2
B5023	VARIABLE CAMSHAFT CONTROL SENSOR 2	RH front of engine (M3)	12-1
B5028	HEATED OXYGEN SENSOR 2	Front of engine compartment	
B6200	HEATED OXYGEN SENSOR	Under center of car	15-3
B6203	CRANKSHAFT POSITION/RPM SENSOR	Under RH front of car rear of radiator	10-3
B6204	CAMSHAFT POSITION SENSOR (CYLINDER IDENTIFICATION)	RH front of engine below intake manifold rear of radiator (325i)	11-1
B6204	CAMSHAFT POSITION SENSOR (CYLINDER IDENTIFICATION)	RH front of engine (M3)	11-2
B6204	CAMSHAFT POSITION SENSOR (CYLINDER IDENTIFICATION)	RH front of engine (M3)	
B6205	INTAKE AIR TEMPERATURE SENSOR	LH side of engine (near oil level stick)	13-3
B6208	CAMSHAFT ACTUATOR	Front of engine	
B6209	HALL EFFECT CAMSHAFT SENSOR	Front of engine	
B6217	HOT FILM AIR MASS METER	Top front of engine	
B6231	OIL PRESSURE SWITCH	RH front of engine below intake manifold (325i)	11-1
B6231	OIL PRESSURE SWITCH	LH side of engine (near oil level stick) (M3)	14-2
B6231	OIL PRESSURE SWITCH	RH front of engine below intake manifold (318i)	17-1
B6232	ENGINE COOLANT TEMPERATURE SENSOR	RH front of engine below intake manifold (325i)	11-3



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

B6232	ENGINE COOLANT TEMPERATURE SENSOR	RH front of engine (M3)	12-1
B6232	ENGINE COOLANT TEMPERATURE SENSOR	RH front of engine below intake manifold (318i)	17-2
B6233	VOLUME AIR FLOW SENSOR	LH side of engine compartment right of LH side shock tower	
B6236	ENGINE COOLANT TEMPERATURE SENSOR	RH front of engine below intake manifold (325i)	11-1
B6236	ENGINE COOLANT TEMPERATURE SENSOR	RH front of engine (M3)	12-1
B6236	ENGINE COOLANT TEMPERATURE SENSOR	RH front of engine below intake manifold (318i)	17-2
B6238	OIL TEMPERATURE SENSOR	LH side of engine (M3)	14-2
B6241	CYL. 1-2 KNOCK SENSOR	Top front of engine	
B6241w	CYL. 1-3 KNOCK SENSOR	Top front of engine	
B6242	CYL. 3-4 KNOCK SENSOR	Top front of engine	14-3
B6242w	CYL. 4-6 KNOCK SENSOR	Top front of engine	
B6243	CYL. 5-6 KNOCK SENSOR	Top front of engine (M3)	
B9508	PRESSURE SWITCH	Front RH side of engine compartment near RH headlight assembly	09-3
C101	CONTACT RING	Top of steering column	24-2
C900	SUPPRESSION FILTER	In upper RH C-pillar	33-2
D100	DATA LINK CONNECTOR	Rear RH side of engine compartment	05-1
E9	REAR DEFOGGER I	In upper RH C-pillar	33-2
E10	REAR DEFOGGER/ANTENNA	In rear window	
E11	LEFT HIGH BEAM LIGHT	Near LH headlight assembly	
E12	RIGHT HIGH BEAM LIGHT	Near RH headlight assembly	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

E13 ...	LEFT LOW BEAM LIGHT	Near LH headlight assembly	
E14 ...	RIGHT LOW BEAM LIGHT	Near RH headlight assembly	
E15 ...	LEFT PARK LIGHT	Front of vehicle	
E19 ...	RIGHT PARK LIGHT	Front of vehicle	
E20 ...	UNDERHOOD LIGHT	On underside of engine hood	
E25 ...	FRONT ASHTRAY LIGHT	Center console	31-2
E26 ...	LEFT FOG LIGHT	Under LH front bumper	08-2
E27 ...	RIGHT FOG LIGHT	Under RH front bumper	08-2
E28 ...	FRONT CIGAR LIGHTER	Near gearshift lever	
E28y ..	REAR ASHTRAY LIGHT	Below center console	31-2
E28y ..	REAR ASHTRAY LIGHT	Behind center console	
E29 ...	FRONT CIGAR LIGHTER LIGHT	Center console	
E32 ...	TRUNK COMPARTMENT LIGHT	In luggage compartment	
E34 ...	FRONT DOME LIGHT/MAP READING ASSEMBLY	Under roof center panel	04-2
E35 ...	DRIVER'S MAKEUP MIRROR LIGHT	Center of windshield header	
E36 ...	PASSENGER'S MAKEUP MIRROR LIGHT	Center of windshield header	23-1
E39 ...	LEFT REAR INTERIOR LIGHT	In upper LH C-pillar	33-1
E40 ...	RIGHT REAR INTERIOR LIGHT	In upper RH C-pillar	33-2
E42 ...	GLOVE BOX LIGHT	LH side of glove box	25-1
E43 ...	LEFT LICENSE PLATE LIGHT	Underside of trunk lid, near license plate	09-1



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

E44 ...	RIGHT LICENSE PLATE LIGHT	Underside of trunk lid, near license plate	09-1
E45y ...	CASSETTE BOX LIGHT	Center of dash	
E46 ...	LEFT TRUNK LIGHT ASSEMBLY	In LH rear side of luggage compartment	
E47 ...	RIGHT TRUNK LIGHT ASSEMBLY	In RH rear side of luggage compartment	03-3
E56 ...	DRIVER'S SEATBACK HEATER	In upper LH front seatback	23-3
E57 ...	DRIVER'S SEAT HEATER	Under LH front seat	23-3
E58 ...	PASSENGER'S SEAT HEATER	Underside of RH front seat	
E59 ...	PASSENGER'S SEATBACK HEATER	In upper RH front seatback	
E82 ...	TRANSMISSION POSITION INDICATOR LIGHT	Center console	
E99 ...	HARD TOP CONNECTOR 1	In convertible top compartment	
E100y ...	HARD TOP CONNECTOR 2	In convertible top compartment	
E101 ...	LEFT TRUNK COMPARTMENT LIGHT	In LH rear side of luggage compartment Convertible	
E102 ...	RIGHT TRUNK COMPARTMENT LIGHT	In RH rear side of luggage compartment Convertible	
E104 ...	THROTTLE FLAP HEATER	LH side of engine compartment	
G1	BATTERY	Rear RH side of engine compartment	
G5	DRIVER'S AIR BAG GAS GENERATOR	Behind steering wheel	24-2
G6	PASSENGER'S AIR BAG GAS GENERATOR I	RH side of dash	27-2
G6430 ...	B+ JUMP START JUNCTION POINT	Rear RH side of engine compartment back of RH side shock tower	05-1
G6509 ...	GENERATOR	Front LH side of engine compartment	05-2
H1w ...	ANTI-THEFT HORN (ALPINE)	Front RH side of engine compartment	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

H2	LEFT HORN	Front of engine compartment
H3	RIGHT HORN	Front of engine compartment
H4	RIGHT FRONT TURN LIGHT	Front of vehicle
H5	RIGHT REAR TURN LIGHT	RH side of body rear end
H6	LEFT REAR TURN LIGHT	LH side of body rear end
H7	LEFT FRONT TURN LIGHT	Front of vehicle
H8	RIGHT FRONT AUXILIARY TURN LIGHT	Front of vehicle
H9	LEFT FRONT AUXILIARY TURN LIGHT	Front of vehicle
H10	CHIME MODULE	Below LH side of dash
H24	LEFT BRAKE LIGHT	LH side of body rear end
H25	LEFT TAIL LIGHT	LH side of body rear end
H26	LEFT REAR FOG LIGHT	LEFT TRUNK LIGHT ASSEMBLY, E46
H27	LEFT BACK UP LIGHT	LEFT TRUNK LIGHT ASSEMBLY, E46
H28	RIGHT BACK UP LIGHT	LEFT TRUNK LIGHT ASSEMBLY, E46
H30	RIGHT TAIL LIGHT	RIGHT TRUNK LIGHT ASSEMBLY, E47
H31	RIGHT BRAKE LIGHT	RIGHT TRUNK LIGHT ASSEMBLY, E47
H34	HIGH LEVEL STOP LIGHT	At back of rear window shelf
H37	LEFT TAIL LIGHT	RIGHT TRUNK LIGHT ASSEMBLY, E47
H38	TELEPHONE TRANSCEIVER	Rear side of luggage compartment
H41	LEFT FRONT SPEAKER	In lower LH A-pillar



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

H42 ...	LEFT MID-HIGH RANGE SPEAKER	In upper LH front door	
H43 ...	RIGHT MID-HIGH RANGE SPEAKER	In upper RH front door	
H45 ...	RIGHT REAR SPEAKER	Under rear window shelf	
H46 ...	LEFT REAR SPEAKER	Under rear window shelf	
H50 ...	RIGHT FRONT HIGH RANGE SPEAKER	In upper RH front door	
H51 ...	RIGHT FRONT LOW RANGE SPEAKER	In lower RH A-pillar	
H52 ...	RIGHT REAR LOW RANGE SPEAKER	Under rear window shelf	
H53 ...	RIGHT REAR HIGH RANGE SPEAKER	Under rear window shelf	
H54 ...	RIGHT FRONT MIDRANGE SPEAKER	In upper RH front door	
H55 ...	LEFT FRONT MIDRANGE SPEAKER	In upper LH front door	
H56 ...	LEFT REAR HIGH RANGE SPEAKER	Under rear window shelf	
H57 ...	LEFT REAR LOW RANGE SPEAKER	Under rear window shelf	
H58 ...	LEFT FRONT LOW RANGE SPEAKER	In lower LH A-pillar	
H59 ...	LEFT FRONT HIGH RANGE SPEAKER	In upper LH front door	
K1	STARTER RELAY	Behind LH footwell speaker grille	25-3
K2	HORN RELAY	Rear LH side of engine compartment In Power Distribution Box	19-2
K4	BLOWER RELAY	Rear LH side of engine compartment In Power Distribution Box	19-2
K9	UNLOADER RELAY, TERMINAL 15	Behind LH footwell speaker grille	25-3
K10 ...	ABS RELAY	Rear LH side of engine compartment In Power Distribution Box	19-1
K11 ...	WIPER RELAY	Behind LH footwell speaker grille	25-3



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

K13 ...	REAR DEFOGGER RELAY	Rear LH side of engine compartment in Power Distribution Box	19-1
K16 ...	HAZARD FLASHER RELAY	Rear LH side of engine compartment in Power Distribution Box	19-2
K19 ...	COMPRESSOR CONTROL RELAY	Rear LH side of engine compartment in Power Distribution Box	19-1
K21 ...	NORMAL SPEED RELAY	Rear LH side of engine compartment in Power Distribution Box	19-3
K22 ...	HIGH SPEED RELAY	Rear LH side of engine compartment in Power Distribution Box	19-3
K46 ...	HIGH BEAM LIGHT RELAY	Rear LH side of engine compartment in Power Distribution Box	19-2
K47 ...	FRONT FOG LIGHT RELAY	Rear LH side of engine compartment in Power Distribution Box	19-2
K48 ...	LOW BEAM LIGHT RELAY	Rear LH side of engine compartment in Power Distribution Box	19-2
K53 ...	WIPER MOTOR RELAY	Behind LH footwell speaker grille	25-3
K75 ...	ABS PUMP MOTOR RELAY	Rear LH side of engine compartment in Power Distribution Box	19-1
K99 ...	REAR WINDOW BLOWER RELAY	Behind glove box left	25-2
K108 ..	HORN RELAY (ALPINE)	Behind glove box left	01-2
K114 ..	COMFORT RELAY	Footwell, driver's side	27-1
K117 ..	TRUNK LID RELAY	Behind glove box right	
K450 ..	PARK VENTILATION RELAY	Footwell, driver's side	02-2
K5029 .	DOUBLE RELAY	Rear LH side of engine compartment in Power Distribution Box (M3)	19-3
K6300 .	ENGINE CONTROL MODULE RELAY	Rear LH side of engine compartment in Power Distribution Box	19-1
K6300 .	ENGINE CONTROL MODULE RELAY	Rear LH side of engine compartment in Power Distribution Box (M3)	19-3
K6301 .	CYL. 1-6 FUEL PUMP RELAY	Rear LH side of engine compartment in Power Distribution Box	19-1
K6301w	FUEL PUMP RELAY	Rear LH side of engine compartment in Front Power Distribution Box	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

K6303	OXYGEN SENSOR RELAY	Power Distribution Box rear LH side of engine compartment	
K6307	FUEL PUMP/START IDENTIFICATION RELAY	Rear LH side of engine compartment in Power Distribution Box (M3)	19-3
M2	FUEL PUMP	Below RH side of rear seat	20-2
M3	WIPER MOTOR	Rear of engine compartment below center of cowl	16-1
M4	WASHER PUMP	Front RH side of engine compartment on washer fluid reservoir	10-1
M5	INTENSIVE WASH PUMP	Front RH side of engine compartment	
M7	HEADLIGHT/FOG LIGHT WASHER PUMP	Front RH side of engine compartment on washer fluid reservoir	10-2
M9	AUXILIARY FAN MOTOR	Behind front grille behind trim panel	18-1
M12	DRIVER'S DOOR LOCK MOTOR	In lower LH front door behind trim panel	
M13	PASSENGER'S DOOR LOCK MOTOR	In lower RH side of front door behind trim panel	
M14	RIGHT REAR DOOR LOCK MOTOR	In lower RH rear door behind trim panel	
M15	LEFT REAR DOOR LOCK MOTOR	In lower LH rear door behind trim panel	
M16	GAS FILLER LOCK MOTOR	In RH rear side of luggage compartment	03-3
M17	TRUNK LOCK MOTOR	Rear side of luggage compartment	
M20	LEFT REAR WINDOW MOTOR	In lower LH rear door behind trim panel	
M21	DRIVER'S WINDOW MOTOR	LH front door behind door panel	31-3
M22	RIGHT REAR WINDOW MOTOR	In lower RH rear door behind door panel	
M23	PASSENGER'S WINDOW MOTOR	RH front door behind door panel	32-1
M24	SUNROOF MOTOR	Center of windshield header	
M25	CRUISE CONTROL ACTUATOR (TEMPOMAT)	Front LH side of engine compartment	18-2



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

M30 ...	BLOWER MOTOR	Rear of engine compartment behind RH fresh air cowl	15-2
M34 ...	DASH VENT MIXING FLAP MOTOR	Below LH side of dash RH side of steering column	29-2
M36 ...	FRESH AIR FLAP MOTOR	Below RH side of dash center console right	29-3
M40 ...	RECIRCULATION FLAP MOTOR	Below LH side of dash RH side of steering column	29-2
M43 ...	CONVERTIBLE TOP STORAGE LID LOCK MOTOR	In convertible top compartment left	22-1
M50 ...	DRIVER'S SEAT CUSHION TILT MOTOR	Under LH front seat	23-3
M51 ...	DRIVER'S SEAT MOVEMENT MOTOR	Under LH front seat	23-3
M52 ...	DRIVER'S SEAT HEIGHT MOTOR	Under LH front seat	23-3
M53 ...	DRIVER'S SEATBACK RECLINER MOTOR	Under LH front seat	23-3
M58 ...	PASSENGER'S SEATBACK RECLINER MOTOR	Under RH front seat	
M59 ...	PASSENGER'S SEAT HEIGHT MOTOR	Under RH front seat	
M60 ...	PASSENGER'S SEAT MOVEMENT MOTOR	Under RH front seat	
M61 ...	PASSENGER'S SEAT CUSHION TILT MOTOR	Under RH front seat	
M93 ...	AUXILIARY THROTTLE POSITION MOTOR (ADS)	Front of engine compartment	
M98 ...	LEFT REAR WINDOW MOTOR	Left from LH rear seat behind trim panel	22-2
M99 ...	RIGHT REAR WINDOW MOTOR	RH side of RH rear seat behind trim panel	22-2
M100 ..	CONVERTIBLE TOP STORAGE LID MOTOR	In LH side of luggage compartment	34-1
M101 ..	CONVERTIBLE TOP MOTOR	In LH side of luggage compartment	34-3
M105 ..	REAR WINDOW BLOWER	Behind rear seats	21-3
M107 ..	GLOVE BOX LOCK MOTOR	RH side of dash behind glove box	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

M6133 .	AIR PUMP	Front of engine compartment	
M6510 .	STARTER	Rear LH side of engine compartment	
N3 . . .	DIMMER	LH side of dash	26-1
N4 . . .	ON-BOARD COMPUTER	Center console	03-1
N6 . . .	HEADLIGHT/FOGLIGHT CLEANING MODULE (SRA)	Footwell, driver's side	02-2
N8 . . .	ANTENNA AMPLIFIER AM/FM	In upper LH C-pillar	33-1
N10 . . .	MULTI-FUNCTION CLOCK	Center console	
N12w . .	ANTI-THEFT CONTROL MODULE (ALPINE)	Behind glove box (glove box removed)	01-3
N17 . . .	CRASH CONTROL MODULE	Footwell, driver's side	02-2
N21 . . .	TWIN RELAY MODULE	Footwell, driver's side	02-2
N22 . . .	CD CHANGER	In LH forward side of luggage compartment	03-3
N24 . . .	ROLLOVER SENSOR	In lower LH C-pillar behind side panel	02-1
N404 . .	DIVERSITY	In upper LH C-pillar	
N444 . .	FM AMPLIFIER HLO	In upper RH C-pillar	
P90 . . .	FRONT POWER DISTRIBUTION BOX	Rear LH side of engine compartment	05-3
P95 . . .	AUXILIARY FUSE BOX	Footwell, driver's side	
R11 . . .	BLOWER RESISTORS	Behind center of dashboard left	29-1
R13 . . .	HEADLIGHT WIDENING POTENTIOMETER	Front of engine compartment	
R6240 .	RESISTOR	Front of engine compartment	
R6252 .	THROTTLE POSITION SENSOR	RH front of engine (M3)	11-2



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100 0 8500 0

R6252	THROTTLE POSITION SENSOR	LH side of engine (near oil level stick) (320l-325l)	13-3
R6252	THROTTLE POSITION SENSOR	LH side of engine compartment (318l)	17-3
R8554	RESISTOR	Front of engine compartment	
S2	IGNITION SWITCH	LH side of dash	24-3
S3	AUTOMATIC TRANSMISSION RANGE SWITCH	Center console near gearshift lever	30-3
S4	HORN SWITCH	Top of steering column	24-2
S5	WIPER/WASHER SWITCH	LH side of dash RH side of steering column above	
S6	ASC SWITCH	Center console	30-2
S7	COMBINATION SWITCH	LH side of steering column	24-3
S8	LIGHT SWITCH	LH side of dash	26-1
S10	FOG LIGHT SWITCH	LH side of dash	
S13	PASSENGER'S DOOR JAMB SWITCH	Rear RH door pillar	33-3
S14	DRIVER'S DOOR JAMB SWITCH	LH rear door jamb	33-3
S15	REAR RIGHT DOOR JAMB SWITCH	In lower RH C-pillar	33-3
S16	LEFT REAR DOOR JAMB SWITCH	In lower LH C-pillar	33-3
S17	MIRROR CONTROL SWITCH	In upper LH front door	
S18	HAZARD SWITCH	Center console near gearshift lever	30-3
S19	UNDERHOOD LIGHT SWITCH	Near RH headlight assembly	
S20y	RADIO MICROSWITCH	Center of dash	
S21	ENGINE HOOD SWITCH (DWA)	Front RH side of engine compartment on washer fluid reservoir	10-2



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

S27 ...	INERTIA SWITCH	In lower RH A-pillar	
S28 ...	CRUISE CONTROL SWITCH	LH side of dash RH side of steering column above	24-3
S29 ...	BRAKE LIGHT SWITCH	LH footwell on brake pedal support bracket behind LH footwell trim	26-3
S30 ...	BRAKE LIGHT SWITCH	LH footwell on brake pedal support bracket behind LH footwell trim	26-2
S31 ...	PARK BRAKE SWITCH	Center console on rear of park brake lever	31-2
S32 ...	CLUTCH SWITCH	LH footwell on clutch pedal support bracket behind LH footwell trim	26-3
S36 ...	TEMPERATURE SWITCH	Front RH side of engine compartment near RH headlight assembly	09-3
S38 ...	SUNROOF SWITCH	Roof	
S40y ..	CENTRAL POWER WINDOW SWITCH	Center console	
S41 ...	LEFT REAR WINDOW SWITCH	In lower LH rear door behind trim panel	
S42 ...	RIGHT REAR WINDOW SWITCH	In lower RH rear door behind trim panel	
S51 ...	DRIVER'S SEAT, SEAT CONTROL SWITCH	LH side of driver's seat	
S53 ...	DRIVER'S SEAT, SEAT HEATER SWITCH	Center console near gearshift lever	30-2
S54 ...	PASSENGER'S SEAT, SEAT HEATER SWITCH	Center console near gearshift lever	30-1
S56 ...	PASSENGER'S SEAT, SEAT CONTROL SWITCH	RH front seat	
S58 ...	DRIVER'S SEAT BELT SWITCH	In LH front seat belt buckle	
S59 ...	PASSENGER'S SEAT BELT SWITCH	In RH front seat belt buckle	
S61y ..	TRUNK LIGHT SWITCH	Underside of trunk lid left	34-2
S63 ...	ENGINE COOLANT LEVEL SWITCH	Front RH side of engine compartment	18-1
S64 ...	WASHER FLUID LEVEL SWITCH	Front RH side of engine compartment on washer fluid reservoir	10-1



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

S71	... LEFT FRONT IMPACT SENSOR	LH side of engine compartment	
S75	... BLOWER SWITCH	Center of dash	
S77	... DRIVER'S MAKEUP MIRROR SWITCH	Above LH sun visor	
S78	... PASSENGER'S MAKEUP MIRROR SWITCH	Above RH sun visor	23-1
S82	... REAR FOG LIGHT SWITCH	LH side of dash	
S123	.. ABS PEDAL TRAVEL SENSOR	Near brake master cylinder	18-3
S124	.. RIGHT REAR DOOR CONTACT	LH C-Pillar	
S125	.. LEFT REAR DOOR CONTACT	RH C-Pillar	
S126y	.. DRIVER'S POWER WINDOW SWITCH	Center console near gearshift lever	31-1
S127y	.. PASSENGER'S POWER WINDOW SWITCH	Center console near gearshift lever	31-1
S128y	.. LH REAR DOOR (CONSOLE) POWER WINDOW SWITCH	Center console	
S128z	.. LH REAR POWER WINDOW SWITCH	Center console	
S129y	.. RH REAR DOOR (CONSOLE) POWER WINDOW SWITCH	Center console	
S129z	.. RH REAR POWER WINDOW SWITCH	Center console	
S130	.. CHILD PROTECTION CONTROL (CONSOLE)	Center console	
S134y	.. IHKR CONTROL PANEL	Center of dash	
S143	.. CONVERTIBLE TOP ACTUATING SWITCH	Center console	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

S164	..	CONVERTIBLE TOP END-POSITION MICRO SWITCH	At convertible top linkage	
S165	..	CONVERTIBLE TOP POSITION MICRO SWITCH	At convertible top motor	
S196	..	REAR WINDOW BLOWER MICRO SWITCH ...	Behind rear seats	
S213	..	TRUNK LID MICRO SWITCH	Underside of trunk lid	
S214	..	CONVERTIBLE TOP STORAGE LID MICRO SWITCH	At convertible top linkage	
S8503	.	PROGRAM SWITCH	Center console	
S8507	.	KICK-DOWN SWITCH	LH footwell	
S8511	.	REVERSING LIGHT SWITCH	Under front of car LH side of transmission	
T6151	.	CYL. 1 IGNITION COIL	Top RH side of engine	13-1
T6151	.	CYL. 1 IGNITION COIL	RH side of engine compartment (318i)	17-3
T6152	.	CYL. 2 IGNITION COIL	Top RH side of engine	13-1
T6152	.	CYL. 2 IGNITION COIL	RH side of engine compartment (318i)	17-3
T6153	.	CYL. 3 IGNITION COIL	Top RH side of engine	13-1
T6153	.	CYL. 3 IGNITION COIL	RH side of engine compartment (318i)	17-3
T6154	.	CYL. 4 IGNITION COIL	Top RH side of engine	13-1
T6154	.	CYL. 4 IGNITION COIL	RH side of engine compartment (318i)	17-3
T6155	.	CYL. 5 IGNITION COIL	Top RH side of engine	13-1
T6156	.	CYL. 6 IGNITION COIL	Top RH side of engine	13-1
U4		TELEPHONE HANDSET	Below front of console	
V4		DAYTIME RUNNING LIGHTS CODING DIODE	LH side of dash	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

V7	ASC DIODE	Top LH side of engine compartment in Front Power Distribution Box		
V9501	UNCOUPLING DIODE (KL61)	Front of engine compartment		
X1	B+ JUNCTION POINT	Rear LH side of engine compartment	05-3	
X2	BATTERY B+ START POINT	Rear LH side of engine compartment	05-3	
X9	B+ JUNCTION POINT	Rear LH side of engine compartment	05-3	
X11	CONNECTOR (55-PINS, BLACK)	EARLY PRODUCTIONbehind glove box (glove box removed)	01-2	00-1
X13	CONNECTOR (30-PINS, BLACK)	Behind LH footwell kickpanel		00-4
X14	CONNECTOR (30-PINS, WHITE)	Behind LH footwell kickpanel		00-4
X16	CONNECTOR (26-PINS, WHITE)	LH side of dash rear of A2 instrument cluster	28-3	00-2
X17	CONNECTOR (26-PINS, BLUE)	LH side of dash rear of A2 instrument cluster	28-3	00-2
X20	CONNECTOR (25-PINS, BLACK)	Rear LH side of engine compartment	18-3	05-2
X22	CONNECTOR (26-PINS, BLUE)	RH side of dash behind glove box	01-2	00-2
X31	CONNECTOR (12-PINS, BLACK)	Rear LH side of engine compartment back of LH side shock tower	16-2	01-4
X32	CONNECTOR (12-PINS, WHITE)	LH footwell underside of steering column	27-3	02-6
X33	CONNECTOR (12-PINS, BLACK)	LH footwell underside of steering column behind LH footwell trim	27-3	02-6
X35	CONNECTOR (12-PINS, NATURAL)	Below LH side of dash RH side of steering column	27-3	02-6
X43	CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment		03-6
X44	CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment		03-6
X45	CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment		03-6
X51	CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment		03-6



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X52 ... CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment	03-6
X53 ... CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment	03-6
X54 ... CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment	03-6
X55 ... CONNECTOR (9-PINS, BLACK)	Behind LH footwell speaker grille	03-6
X56 ... CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment	03-6
X58 ... CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment	03-6
X61 ... CONNECTOR (9-PINS, BLACK)	Below LH side of dash	03-6
X63 ... CONNECTOR (9-PINS, BLACK)	Behind LH footwell speaker grille	03-6
X64 ... CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment	03-6
X65 ... CONNECTOR (9-PINS, BLACK)	Below LH side of dash	03-6
X69 ... CONNECTOR (25-PINS, GRAY)	Rear LH side of engine compartment (325i)	18-3 05-2
X70 ... CONNECTOR (8-PINS, BLACK)	Front LH side of engine compartment	18-2 02-2
X72 ... CONNECTOR (8-PINS, NATURAL)	EARLY PRODUCTIONLH footwell underside of steering column	27-3 03-5
X72 ... CONNECTOR (6-PINS, BLACK)	LATE PRODUCTIONfootwell, driver's side	04-2
X74 ... CONNECTOR (30-PINS, ORANGE)	Below rear seat	00-2 12-2
X78 ... CONNECTOR (4-PINS, BLACK)	LH footwell on brake pedal support bracket behind LH footwell trim	26-2 03-3
X82 ... CONNECTOR (3-PINS, BLACK)	Front of engine compartment on auxiliary fan	18-1 08-1
X85 ... CONNECTOR (3-PINS, BLACK)	Rear LH side of engine compartment	16-2 06-3
X87 ... CONNECTOR (3-PINS, BLACK)	Front RH side of engine compartment RH top of radiator	09-3 06-3
X99 ... CONNECTOR (9-PINS, BLACK)	Behind LH footwell speaker grille	03-6



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X107 ..	CONNECTOR (2-PINS, GRAY)	Front RH side of engine compartment on washer fluid reservoir	10-1
X109 ..	CONNECTOR (2-PINS, BLACK)	Front RH side of engine compartment on washer fluid reservoir	10-1
X110 ..	CONNECTOR (2-PINS, GRAY)	Rear RH side of engine compartment back of RH side shock tower	
X111 ..	CONNECTOR (2-PINS, BLACK)	Rear LH side of engine compartment near brake master cylinder top of brake fluid reservoir	18-3
X112 ..	CONNECTOR (2-PINS, BLACK)	Front RH side of engine compartment	18-1
X113 ..	CONNECTOR (2-PINS, GRAY)	Above RH front wheel well behind RH front wheel	09-2
X114 ..	CONNECTOR (2-PINS, GRAY)	Above LH front wheel well behind LH front wheel	09-2
X116 ..	CONNECTOR (2-PINS, BLACK)	LH footwell near brake pedal	26-3
X118 ..	CONNECTOR (2-PINS, BLACK)	Above LH front wheel well behind LH front wheel	09-2
X121 ..	CONNECTOR (2-PINS, WHITE)	LH footwell on clutch pedal	26-3
X123 ..	CONNECTOR (2-PINS, GRAY)	Front RH side of engine compartment on washer fluid reservoir	10-2
X126 ..	CONNECTOR (2-PINS, BLACK)	Front RH side of engine compartment near RH headlight assembly	09-3
X127 ..	CONNECTOR (2-PINS, NATURAL)	Front RH side of engine compartment near RH headlight assembly	09-3
X128 ..	CONNECTOR (2-PINS, BLACK)	Front RH side of engine compartment	
X132 ..	CONNECTOR (2-PINS, BLACK)	Front of engine compartment	
X133 ..	CONNECTOR (2-PINS, BLACK)	Front of engine compartment	
X137 ..	CONNECTOR (2-PINS, BLACK)	Front LH side of engine compartment	
X142 ..	CONNECTOR (3-PINS, GRAY)	Under rear of car LH side of on differential	02-1
X143 ..	CONNECTOR (3-PINS, GRAY)	Under rear of car LH side of on differential	08-1 02-1



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X161 .. CONNECTOR (1-PINS, WHITE)	Near RH headlight assembly		
X163 .. CONNECTOR (3-PINS, BLACK)	Front RH side of engine compartment on washer fluid reservoir near RH headlight assembly	10-1	06-3
X165 .. GROUND	Front LH side of engine compartment	06-3	
X173 .. GROUND	Below LH side of dash	07-1	
X209 .. CONNECTOR (12-PINS, BLACK)	LH footwell underside of steering column		
X256 .. CONNECTOR (26-PINS, BLACK)	Ahead of RH front door in lower RH A-pillar	32-1	04-1
X257 .. CONNECTOR (26-PINS, BLACK)	Ahead of LH front door in lower LH A-pillar		04-1
X271 .. CONNECTOR (12-PINS, BLACK)	LH side of dash rear of A2 instrument cluster	28-3	01-3
X272 .. CONNECTOR (2-PINS, BLACK)	Under roof center panel		
X273 .. CONNECTOR (12-PINS, BLACK)	In lower LH B-pillar	21-1	01-2
X274 .. CONNECTOR (12-PINS, BLACK)	In lower RH B-pillar	21-1	01-2
X275 .. CONNECTOR (4-PINS, WHITE)	Under LH front seat under carpet	23-2	03-3
X279 .. CONNECTOR (4-PINS, WHITE)	Under RH front seat	32-3	03-3
X285 .. CONNECTOR (15-PINS, BLUE)	Behind glove box	25-2	00-3
X292 .. CONNECTOR (9-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment		03-6
X295 .. CONNECTOR (8-PINS, BLACK)	LH footwell underside of steering column behind LH footwell trim	27-3	03-5
X311 .. CONNECTOR (3-PINS, BLACK)	Underside of trunk lid left	34-2	01-1
X312 .. CONNECTOR (2-PINS, BLACK)	In RH rear side of luggage compartment behind RH rear light assembly	03-3	01-6
X315 .. CONNECTOR (2-PINS, BLACK)	Underside of trunk lid left	34-2	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X316 .. CONNECTOR (6-PINS, WHITE)	Center console near gearshift lever	31-1	05-3
X317 .. CONNECTOR (6-PINS, WHITE)	Center console near gearshift lever	30-3	05-3
X318 .. CONNECTOR (8-PINS, BLACK)	In RH rear side of luggage compartment behind RH rear light assembly	03-3	01-4
X319 .. CONNECTOR (8-PINS, BLACK)	In LH rear side of luggage compartment behind LH rear light assembly		01-4
X320 .. CONNECTOR (6-PINS, WHITE)	Center console near gearshift lever	30-3	04-2
X322 .. CONNECTOR (6-PINS, BLACK)	LH footwell	28-2	04-2
X324 .. CONNECTOR (6-PINS, WHITE)	Center console near gearshift lever	31-1	05-3
X333 .. CONNECTOR (4-PINS, BLACK)	Rear of engine compartment below center of cowl	16-1	07-2
X336 .. CONNECTOR (6-PINS, WHITE)	Under roof center panel	04-2	09-3
X351 .. CONNECTOR (2-PINS, BLACK)	In upper RH B-pillar		
X352 .. CONNECTOR (3-PINS, BLACK)	In upper LH B-pillar		01-1
X355 .. CONNECTOR (2-PINS, BLACK)	In upper RH C-pillar	33-2	
X356 .. CONNECTOR (2-PINS, BLACK)	In upper LH C-pillar	33-1	
X371 .. CONNECTOR (2-PINS, BLACK)	Front RH side of engine compartment on washer fluid reservoir	10-2	
X372 .. CONNECTOR (2-PINS, GRAY)	Rear RH side of engine compartment back of RH side shock tower		
X379 .. CONNECTOR (1-PINS, NATURAL)	In upper LH C-pillar	33-1	
X380 .. CONNECTOR (1-PINS, NATURAL)	In upper RH C-pillar	33-2	
X381 .. CONNECTOR (3-PINS, BLACK)	Under roof center panel		01-1
X382 .. CONNECTOR (3-PINS, BLACK)	Above RH sun visor	23-1	01-1
X383 .. CONNECTOR (2-PINS, BLACK)	Under rear of car LH side of on differential	08-1	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X386	..	CONNECTOR (2-PINS, BLACK)	..	REAR ASHTRAY LIGHT, E28y	
X388	..	CONNECTOR (2-PINS, BLACK)	..	In lower RH A-pillar	
X389	..	CONNECTOR (2-PINS, GRAY)	..	Rear LH side of engine compartment	
X390	..	CONNECTOR (2-PINS, BLACK)	..	RH side of dash behind glove box	
X400	..	CONNECTOR (8-PINS, BLACK)	..	In LH rear side of luggage compartment	03-5
X401	..	CONNECTOR (1-PINS, BLACK)	..	Above LH sun visor	
X402	..	CONNECTOR (1-PINS, BLACK)	..	Above RH sun visor	23-1
X413	..	CONNECTOR (2-PINS, BLACK)	..	At back of rear window shelf	
X423	..	CONNECTOR (1-PINS, NATURAL)	..	Below center console on rear of park brake lever	
X424	..	CONNECTOR (1-PINS, BROWN)	..	In upper LH C-pillar	33-1
X494	..	GROUND	..	Center console near gearshift lever	07-2
X495	..	GROUND	..	Behind RH footwell trim above	07-3
X498	..	GROUND	..	Center console near gearshift lever	07-2
X503	..	CONNECTOR (12-PINS, WHITE)	..	Below LH side of dash	26-1 01-6
X504	..	CONNECTOR (4-PINS, WHITE)	..	Center console	26-1 03-3
X509	..	CONNECTOR (9-PINS, BLACK)	..	Behind glove box (glove box removed)	03-6
X510	..	CONNECTOR (9-PINS, BLACK)	..	Behind glove box (glove box removed)	03-6
X511	..	CONNECTOR (8-PINS, BLACK)	..	Center console near gearshift lever	30-3 01-4
X516	..	CONNECTOR (5-PINS, BLACK)	..	Center console	30-3 03-2
X517	..	CONNECTOR (4-PINS, BLACK)	..	Below LH side of dash	26-1 03-3



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X518	.. CONNECTOR (4-PINS, BLACK)	LH footwell	28-2	03-3
X521	.. CONNECTOR (6-PINS, BLUE)	Center console		04-5
X522	.. CONNECTOR (3-PINS, WHITE)	LH footwell	28-2	03-6
X523	.. CONNECTOR (3-PINS, NATURAL)	LH side of dash		03-6
X531	.. CONNECTOR (1-PINS, NATURAL)	Center console near gearshift lever	30-2	
X532	.. CONNECTOR (2-PINS, BLACK)	Center console near gearshift lever	30-2	
X537	.. CONNECTOR (2-PINS, BLACK)	In upper LH front door behind door panel	31-3	01-1
X538	.. CONNECTOR (2-PINS, BLACK)	RH front door behind door panel	32-1	
X539	.. CONNECTOR (2-PINS, BLACK)	Center console		
X540	.. CONNECTOR (2-PINS, BLACK)	LH side of glove box	25-1	
X541	.. CONNECTOR (1-PINS, NATURAL)	LH side of glove box	25-1	
X542	.. CONNECTOR (2-PINS, BLACK)	LH side of glove box	25-1	
X603	.. CONNECTOR (6-PINS, (---))	Center console		05-1
X604	.. CONNECTOR (6-PINS, (---))	RH front seat		05-1
X605	.. CONNECTOR (12-PINS, BLACK)	Below RH side of rear seat Convertible	02-3	11-3
X605	.. CONNECTOR (12-PINS, BLACK)	In LH side of luggage compartment	04-1	11-3
X606	.. CONNECTOR (26-PINS, BLACK)	Below RH side of rear seat Convertible	02-3	00-2
X606	.. CONNECTOR (26-PINS, BLACK)	In LH side of luggage compartment	04-1	00-2
X607	.. CONNECTOR (9-PINS, BLACK)	Below LH side of dash		03-6
X623	.. CONNECTOR (4-PINS, BLACK)	In upper LH front door behind door panel		10-1



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X624	.. CONNECTOR (4-PINS, BLACK)	 In upper RH front door behind door panel	32-1	10-1
X625	.. CONNECTOR (6-PINS, WHITE)	 LH front door	31-3	05-1
X638	.. CONNECTOR (2-PINS, BLACK)	 Below RH side of rear seat	20-2	
X641	.. CONNECTOR (6-PINS, BLACK)	 RH front door behind door panel		08-2
X644	.. CONNECTOR (6-PINS, BLACK)	 In lower LH rear door		05-3
X645	.. CONNECTOR (6-PINS, BLUE)	 In lower LH rear door		06-2
X646	.. CONNECTOR (6-PINS, BLACK)	 In lower RH rear door behind trim panel		06-2
X647	.. CONNECTOR (6-PINS, BLUE)	 In lower RH rear door behind trim panel		08-4
X651	.. CONNECTOR (6-PINS, YELLOW)	 Center console	30-2	05-3
X658	.. CONNECTOR (6-PINS, YELLOW)	 Center console	30-1	05-3
X660	.. CONNECTOR (4-PINS, BLACK)	 LH front door in door at key lock assembly		05-4
X662	.. CONNECTOR (6-PINS, GRAY)	 Below LH side of dash RH side of steering column	29-2	04-5
X663	.. CONNECTOR (6-PINS, GRAY)	 Below LH side of dash RH side of steering column	29-3	04-5
X669	.. CONNECTOR (6-PINS, GRAY)	 Below RH side of dash center console right	29-2	04-5
X679	.. CONNECTOR (2-PINS, WHITE)	 Below RH side of rear seat	20-2	
X692	.. CONNECTOR (3-PINS, BLACK)	 Center console		02-1
X695	.. CONNECTOR (10-PINS, BLACK)	 Below center console		02-4
X700	.. CONNECTOR (1-PINS, NATURAL)	 Behind RH footwell speaker grille		
X701	.. CONNECTOR (1-PINS, NATURAL)	 Behind LH footwell kickpanel		
X706	.. CONNECTOR (2-PINS, BLACK)	 Center console	31-2	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X709	CONNECTOR (2-PINS, BLACK)	Underside of trunk lid, near license plate	09-1	
X710	CONNECTOR (2-PINS, BLACK)	Underside of trunk lid, near license plate	09-1	
X711	CONNECTOR (1-PINS, NATURAL)	Underside of trunk lid left	34-2	
X712	CONNECTOR (1-PINS, NATURAL)	Underside of trunk lid left		
X713	CONNECTOR (2-PINS, BLACK)	Under rear of car LH side of on differential	08-1	
X714	CONNECTOR (2-PINS, GRAY)	In lower LH rear door behind trim panel		
X720	CONNECTOR (2-PINS, GRAY)	In lower RH rear door behind trim panel		
X726	CONNECTOR (2-PINS, (---))	Under LH front seat	23-2	
X727	CONNECTOR (2-PINS, (---))	Under LH front seat	23-2	
X728	CONNECTOR (2-PINS, (---))	Under LH front seat	23-2	
X729	CONNECTOR (2-PINS, (---))	Under LH front seat	23-2	
X732	CONNECTOR (4-PINS, BLACK)	Under LH front seat under carpet		03-3
X733	CONNECTOR (4-PINS, BLACK)	Under LH front seat under carpet		03-3
X734	CONNECTOR (2-PINS, (---))	Under RH front seat		
X735	CONNECTOR (2-PINS, (---))	Under RH front seat		
X736	CONNECTOR (2-PINS, (---))	Under RH front seat		
X737	CONNECTOR (2-PINS, (---))	Under RH front seat		
X740	CONNECTOR (4-PINS, BLACK)	Under RH front seat	24-1	03-3
X741	CONNECTOR (4-PINS, BLACK)	Under RH front seat	24-1	03-3
X742	CONNECTOR (2-PINS, YELLOW)	RH front door in door at key lock assembly		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X744	.. CONNECTOR (2-PINS, GRAY)	 RH front door behind door panel	 32-1	
X746	.. CONNECTOR (3-PINS, BLACK)	 RH front door behind door panel	 32-1	01-1
X747	.. CONNECTOR (2-PINS, YELLOW)	 LH front door in door at key lock assembly	 32-2	
X749	.. CONNECTOR (4-PINS, BLACK)	 In upper LH front door	 31-3	12-3
X751	.. CONNECTOR (2-PINS, WHITE)	 LH front door in door at key lock assembly	 32-2	
X752	.. CONNECTOR (2-PINS, GRAY)	 LH front door in door at key lock assembly	 32-2	
X757	.. CONNECTOR (2-PINS, BLACK)	 LH front door	 31-3	
X768	.. CONNECTOR (2-PINS, WHITE)	 In the engine compartment near LH headlight assembly	 08-2	
X768	.. CONNECTOR (2-PINS, WHITE)	 In the engine compartment near LH headlight assembly		
X769	.. CONNECTOR (2-PINS, WHITE)	 In the engine compartment near RH headlight assembly	 08-2	
X770	.. CONNECTOR (2-PINS, YELLOW)	 Front RH side of engine compartment	 20-1	
X771	.. CONNECTOR (2-PINS, BLACK)	 RH side of LH footwell LH side of IHKR Plenum	 28-1	
X772	.. CONNECTOR (2-PINS, WHITE)	 Center console		
X773	.. CONNECTOR (2-PINS, WHITE)	 Center console		
X774	.. CONNECTOR (1-PINS, GRAY)	 Rear of engine compartment behind RH fresh air cowl		
X778	.. CONNECTOR (3-PINS, BLACK)	 In LH front seat belt buckle	 23-2	01-1
X779	.. CONNECTOR (2-PINS, BLACK)	 LH side of glove box	 25-1	
X782	.. CONNECTOR (3-PINS, ORANGE)	 Front LH side of engine compartment	 27-2	13-1
X783	.. CONNECTOR (3-PINS, BLACK)	 Underside of steering column		13-1
X786	.. CONNECTOR (2-PINS, BLACK)	 UNDERHOOD LIGHT, E20		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X816	CONNECTOR (2-PINS, BLACK)	Rear of engine compartment behind RH fresh air cowl		
X817	CONNECTOR (1-PINS, BLACK)	Rear of engine compartment behind RH fresh air cowl		
X904	CONNECTOR (4-PINS, GRAY)	LH side of IHKR Plenum	29-1	03-3
X905	CONNECTOR (5-PINS, BLACK)	Behind center of dashboard		
X998	CONNECTOR (4-PINS, BLACK)	Below center console		03-1
X999	CONNECTOR (4-PINS, BLACK)	Behind center of dashboard LH side of IHKR Plenum		03-3
X1001	CONNECTOR (4-PINS, BLACK)	RIGHT REAR SPEAKER, H45		03-3
X1002	CONNECTOR (4-PINS, (---))	LEFT REAR SPEAKER, H46		03-3
X1014	CONNECTOR (1-PINS, BLACK)	Center console near gearshift lever	30-2	
X1034	CONNECTOR (3-PINS, BLACK)	Near LH headlight assembly	13-2	11-2
X1070	CONNECTOR (18-PINS, BLACK)	Center console	03-1	01-5
X1071	CONNECTOR (18-PINS, NATURAL)	Center console	03-1	01-5
X1074	CONNECTOR (15-PINS, WHITE)	Below LH side of dash	00-3	00-3
X1075	CONNECTOR (15-PINS, BLACK)	Below LH side of dash	00-3	00-3
X1082	CONNECTOR (9-PINS, BLACK)	Behind LH footwell speaker grille		03-6
X1161	CONNECTOR (9-PINS, BLACK)	Rear LH side of engine compartment		03-6
X1162	CONNECTOR (2-PINS, BLACK)	Near brake master cylinder	18-3	
X1165	GROUND	Below LH side of dash	07-1	
X1166	GROUND	Behind RH footwell trim above	07-3	
X1170	CONNECTOR (42-PINS, BLACK)	LATE PRODUCTIONbehind glove box (glove box removed)	01-2	12-4



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X1171	CONNECTOR (55-PINS, BLACK)	Behind glove box (glove box removed)	01-3	00-1
X1176	CONNECTOR (25-PINS, BLACK)	LH side of engine compartment		05-3
X1178	CONNECTOR (2-PINS, WHITE)	Below center console LH side of gearshift selector		
X1193	CONNECTOR (3-PINS, BLACK)	Center console RH side of gearshift selector		01-1
X1213	CONNECTOR (2-PINS, BLACK)	Center console	31-2	
X1239	CONNECTOR (2-PINS, BLACK)	RH C-Pillar		
X1240	CONNECTOR (2-PINS, BLACK)	LH C-Pillar		
X1241	CONNECTOR (2-PINS, NATURAL)	Below LH side of rear seat	21-2	
X1242	CONNECTOR (26-PINS, BLACK)	Behind glove box	01-1	00-2
X1243	CONNECTOR (6-PINS, BLACK)	Center console near gearshift lever	31-1	04-2
X1245	CONNECTOR (1-PINS, BLACK)	Above LH sun visor		
X1246	CONNECTOR (1-PINS, BLACK)	Above RH sun visor		
X1380	CONNECTOR (1-PINS, NATURAL)	Behind RH footwell speaker grille		
X1381	CONNECTOR (1-PINS, NATURAL)	Behind LH footwell kickpanel		
X1426	CONNECTOR (1-PINS, BROWN)	Rear RH side of engine compartment in E-Box		
X5013	CONNECTOR (2-PINS, BLACK)	LH side of engine (M3)	14-2	
X5013	CONNECTOR (2-PINS, BLACK)	Front of engine compartment		
X5020	CONNECTOR (2-PINS, BLACK)	Front of engine compartment (M3)		
X5021	CONNECTOR (2-PINS, BLACK)	Front of engine compartment		
X5022	CONNECTOR (3-PINS, BLACK)	Front of engine compartment (M3)	12-2	07-3



COMPONENT LOCATION CHART

COMPONENT

			PAGE - FIGURE	
			7100 0	8500 0
X5023	CONNECTOR (3-PINS, BLACK)	RH front of engine (M3)	12-1	07-3
X5023	CONNECTOR (3-PINS, BLACK)	Front of engine compartment		07-3
X5024	CONNECTOR (15-PINS, WHITE)	Rear RH side of engine compartment	04-3	00-3
X5028	CONNECTOR (4-PINS, BLACK)	Lower LH side of engine (M3)		03-4
X5029	CONNECTOR (10-PINS, BLACK)	Front LH side of engine compartment in Front Power Distribution Box		09-1
X5032	CONNECTOR (15-PINS, BLACK)	Front of engine compartment		00-3
X6000	CONNECTOR (88-PINS, BLACK)	Rear RH side of engine compartment	00-1	06-1
X6002	CONNECTOR (20-PINS, BLACK)	Rear RH side of engine compartment	05-1	04-4
X6101	CONNECTOR (2-PINS, BLACK)	On throttle body (M3)	11-2	
X6101	CONNECTOR (2-PINS, BLACK)	Top center of engine		
X6102	CONNECTOR (2-PINS, BLACK)	Top center of engine		
X6103	CONNECTOR (2-PINS, BLACK)	Top center of engine		
X6104	CONNECTOR (2-PINS, BLACK)	Top center of engine		
X6105	CONNECTOR (2-PINS, BLACK)	Top center of engine		
X6106	CONNECTOR (2-PINS, BLACK)	Top center of engine		
X6120	CONNECTOR (2-PINS, BLACK)	LH side of engine compartment right of LH side shock tower	15-1	
X6120	CONNECTOR (2-PINS, BLACK)	LH side of engine compartment right of LH side shock tower	20-3	
X6130	CONNECTOR (3-PINS, GRAY)	RH front of engine below intake manifold (325i)	11-3	13-2
X6130	CONNECTOR (2-PINS, BLACK)	Rear LH side of engine compartment (M3)	14-3	
X6133	CONNECTOR (2-PINS, BLACK)	Front of engine compartment		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X6151 . CONNECTOR (3-PINS, GRAY)	Top RH side of engine		07-4
X6152 . CONNECTOR (3-PINS, GRAY)	Top RH side of engine		07-4
X6153 . CONNECTOR (3-PINS, GRAY)	Top RH side of engine		07-4
X6154 . CONNECTOR (3-PINS, GRAY)	Top RH side of engine		07-4
X6155 . CONNECTOR (3-PINS, GRAY)	Top RH side of engine		07-4
X6156 . CONNECTOR (3-PINS, GRAY)	Top RH side of engine		07-4
X6200 . CONNECTOR (4-PINS, BLACK)	Under center of car	15-3	03-4
X6203 . CONNECTOR (3-PINS, BLACK)	Front of engine below intake manifold (M3)	12-2	13-2
X6204 . CONNECTOR (3-PINS, BLACK)	Front of engine below intake manifold (M3)	12-2	07-3
X6205 . CONNECTOR (2-PINS, BLACK)	LH side of engine (near oil level stick)	13-3	
X6208 . CONNECTOR (2-PINS, BLACK)	Front of engine CAMSHAFT ACTUATOR, B6208		
X6209 . CONNECTOR (3-PINS, BLACK)	Front of engine HALL EFFECT CAMSHAFT SENSOR, B6209		07-5
X6217 . CONNECTOR (4-PINS, GRAY)	Top front of engine		07-2
X6231 . CONNECTOR (2-PINS, BROWN)	RH front of engine below intake manifold (near oil level stick) (325i)	11-1	
X6231 . CONNECTOR (2-PINS, BLACK)	LH side of engine compartment (near oil level stick) (M3)	14-2	
X6231 . CONNECTOR (2-PINS, BROWN)	RH front of engine below intake manifold (near oil level stick) (318i)	17-1	
X6232 . CONNECTOR (2-PINS, BLACK)	RH front of engine below intake manifold (325i)	11-3	
X6232 . CONNECTOR (2-PINS, BLACK)	RH front of engine (M3)	12-1	
X6232 . CONNECTOR (2-PINS, BLACK)	RH front of engine below intake manifold (318i)	17-2	
X6233 . CONNECTOR (7-PINS, BLACK)	LH side of engine compartment right of LH side shock tower		04-3



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X6236 . CONNECTOR (2-PINS, BLUE)	RH front of engine below intake manifold (325i)	11-1	
X6236 . CONNECTOR (2-PINS, BLUE)	RH front of engine (M3)	12-1	
X6236 . CONNECTOR (2-PINS, BLUE)	RH front of engine below intake manifold (318i)	17-2	
X6238 . CONNECTOR (2-PINS, BLACK)	LH side of engine (M3)	14-2	
X6241 . CONNECTOR (3-PINS, BLACK)	LH side of engine (M3)	14-1	07-5
X6241 . CONNECTOR (3-PINS, BLACK)	LH side of engine (318i)	16-3	07-5
X6242 . CONNECTOR (2-PINS, BLACK)	LH side of engine (M3)	14-1	07-3
X6242 . CONNECTOR (3-PINS, BLACK)	LH side of engine (318i)	16-3	07-5
X6243 . CONNECTOR (3-PINS, BLACK)	LH side of engine (M3)	14-1	07-5
X6252 . CONNECTOR (3-PINS, BLACK)	LH side of engine (M3)	11-2	07-3
X6252 . CONNECTOR (3-PINS, BLACK)	LH side of engine (near oil level stick) (320i-325i)	13-3	13-2
X6300 . CONNECTOR (9-PINS, BLACK)	Rear LH side of engine compartment		03-6
X6301 . CONNECTOR (9-PINS, BLACK)	Rear LH side of engine compartment		03-6
X6303 . CONNECTOR (9-PINS, BLACK)	Rear LH side of engine compartment		03-6
X6307 . CONNECTOR (10-PINS, BLACK)	Front of engine compartment		09-1
X6454 . GROUND	Rear RH side of engine compartment back of RH side shock tower	06-2	
X6456 . GROUND	RH front of engine (325i)	11-3	
X6509 . CABLE SOCKET ALTERNATOR B+	Front LH side of engine compartment	05-2	
X6509 . CABLE SOCKET ALTERNATOR B+	Front LH side of engine compartment		
X6510 . CABLE SOCKET STARTER TERMINAL 50	Rear LH side of engine compartment below intake manifold		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X6511	CABLE SOCKET ALTERNATOR TERMINAL 30h	Rear LH side of engine compartment below intake manifold		
X6512	CABLE SOCKET STARTER TERMINAL 30h	Rear LH side of engine compartment below intake manifold		
X7000	CONNECTOR (88-PINS, BLACK)	Rear RH side of engine compartment	00-1	06-1
X7509	CABLE SOCKET ALTERNATOR TERMINAL D+	Front LH side of engine compartment below		
X8500	CONNECTOR (55-PINS, BLACK)	Rear RH side of engine compartment	00-1	00-1
X8503	CONNECTOR (10-PINS, WHITE)	Center console RH side of gearshift selector	31-1	02-4
X8507	CONNECTOR (1-PINS, BLACK)	Below LH side of dash		
X8511	CONNECTOR (2-PINS, BLACK)	Under front of car LH side of transmission		
X8516	CONNECTOR (3-PINS, BLACK)	Under center of car above		13-2
X8521	CONNECTOR (9-PINS, BLACK)	Under center of car above		13-3
X9997	CONNECTOR (2-PINS, ORANGE)	Behind steering wheel	24-2	
X10012	GROUND	Behind RH footwell trim above	07-3	
X10013	CONNECTOR (1-PINS, (---))	Top of steering column		
X10015	CONNECTOR (20-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10016	CONNECTOR (20-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10017	CONNECTOR (20-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X10018	CONNECTOR (32-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10026	CONNECTOR (6-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10030	CONNECTOR (5-PINS, BLACK)	Power Distribution Box rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10031	CONNECTOR (9-PINS, BLACK)	Below LH side of dash		03-6
X10034	CONNECTOR (2-PINS, (---))	Rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10035	CONNECTOR (2-PINS, (---))	Rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10036	CONNECTOR (2-PINS, BLACK)	Rear LH side of engine compartment FRONT POWER DISTRIBUTION BOX, P90		
X10054	CONNECTOR (12-PINS, BLACK)	Below LH side of dash RH side of steering column	28-1	02-6
X10065	CONNECTOR (2-PINS, WHITE)	LH side of LH footwell under footrest		
X10070	CONNECTOR (2-PINS, GRAY)	Near LH headlight assembly	13-2	
X10071	CONNECTOR (2-PINS, BLACK)	Near LH headlight assembly	13-2	
X10074	CONNECTOR (2-PINS, BLACK)	Near LH headlight assembly		
X10075	CONNECTOR (2-PINS, GRAY)	Near RH headlight assembly		
X10092	CONNECTOR (9-PINS, BLACK)	Behind glove box left	25-2	03-6
X10094	CONNECTOR (2-PINS, BLACK)	LH side of engine compartment		
X10098	CONNECTOR (1-PINS, (---))	Front RH side of engine compartment		
X10099	CONNECTOR (1-PINS, (---))	Front RH side of engine compartment		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X10182	CONNECTOR (18-PINS, BLACK)	Behind glove box (glove box removed)	01-1	01-5
X10193	CONNECTOR (9-PINS, BLACK)	Behind glove box (glove box removed)		03-6
X10218	CONNECTOR (3-PINS, NATURAL)	Under RH front seat	24-1	01-1
X10223	CONNECTOR (3-PINS, BLACK)	In convertible top compartment left	22-1	03-6
X10224	CONNECTOR (2-PINS, BLACK)	In convertible top compartment left	22-1	
X10225	CONNECTOR (3-PINS, BLACK)	Underside of trunk lid		01-1
X10226	CONNECTOR (9-PINS, BLACK)	Behind glove box	25-2	03-6
X10238	CONNECTOR (2-PINS, BLACK)	LH side of engine compartment		
X10239	CONNECTOR (3-PINS, BLACK)	LH side of engine compartment		07-3
X10240	CONNECTOR (9-PINS, BLACK)	Below LH side of dash		03-6
X10244	CONNECTOR (1-PINS, BLACK)	Below LH side of dash		
X10250	CONNECTOR (2-PINS, (---))	Behind LH footwell speaker grille		
X11205	CONNECTOR (2-PINS, BLACK)	In convertible top compartment behind rear seats		
X11209	CONNECTOR (2-PINS, BLACK)	Behind rear seats left		
X11211	CONNECTOR (2-PINS, (---))	In convertible top compartment		
X13004	GROUND	In upper RH rear seatback	06-1	
X13006	GROUND	In upper LH rear seatback		
X13009	GROUND	Behind RH footwell trim above	07-3	
X13016	GROUND	Below LH side of dash	07-1	
X13025	CONNECTOR (12-PINS, BLACK)	Behind glove box (glove box removed)	01-3	02-6



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X13026	CONNECTOR (1-PINS, BLACK)	LH side of dash		
X13044	CONNECTOR (12-PINS, BLACK)	In lower LH C-pillar behind side panel	02-1	01-3
X13045	CONNECTOR (6-PINS, GREEN)	Center console		05-3
X13079	CONNECTOR (3-PINS, YELLOW)	Behind rear seats		01-1
X13142	CONNECTOR (2-PINS, WHITE)	Behind rear seats	21-3	
X13143	CONNECTOR (3-PINS, BLACK)	Behind rear seats		01-1
X13145	CONNECTOR (6-PINS, BLACK)	In LH side of luggage compartment	34-3	04-2
X13146	CONNECTOR (2-PINS, BLACK)	In LH side of luggage compartment	34-1	
X13152	CONNECTOR (4-PINS, BLACK)	In LH side of luggage compartment	34-1	07-6
X13156	CONNECTOR (10-PINS, BLACK)	In lower LH C-pillar behind side panel	02-1	09-4
X13157	CONNECTOR (6-PINS, BLACK)	In lower LH C-pillar behind side panel	02-1	05-3
X13159	CONNECTOR (26-PINS, BLACK)	In lower LH C-pillar behind side panel	02-1	00-2
X13226	CONNECTOR (2-PINS, BLACK)	Behind rear seats		
X13227	CONNECTOR (2-PINS, BLACK)	Behind rear seats		
X13230	GROUND	Behind RH footwell trim above Convertible		
X13252	CONNECTOR (15-PINS, YELLOW)	Behind glove box (glove box removed)	01-1	00-3
X13253	CONNECTOR (26-PINS, YELLOW)	Behind glove box (glove box removed)	01-1	00-2
X13254	CONNECTOR (26-PINS, GREEN)	Behind glove box (glove box removed)	01-1	00-2
X13255	CONNECTOR (12-PINS, NATURAL)	Behind glove box (glove box removed)		01-3
X13256	CONNECTOR (2-PINS, GRAY)	Left from LH rear seat behind trim panel	22-2	



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X13257	CONNECTOR (2-PINS, GRAY)	RH side of RH rear seat behind trim panel	22-2	
X13258	CONNECTOR (15-PINS, WHITE)	Behind glove box (glove box removed)	25-2	00-3
X13262	CONNECTOR (6-PINS, BLUE)	Center console		05-3
X13263	CONNECTOR (2-PINS, BLACK)	Behind glove box		
X18080	CONNECTOR (1-PINS, NATURAL)	In luggage compartment		
X18126	CONNECTOR (17-PINS, BLACK)	Center console behind radio		02-3
X18154	CONNECTOR (26-PINS, BLUE)	Center console		00-2
X18155	CONNECTOR (26-PINS, WHITE)	Center console	03-2	00-2
X18156	CONNECTOR (26-PINS, BLACK)	Center console	03-2	00-2
X18157	CONNECTOR (26-PINS, BLUE)	Center console	03-2	00-2
X18180	CONNECTOR (3-PINS, WHITE)	In RH rear side of luggage compartment	03-3	02-1
X18196	CONNECTOR (10-PINS, BLACK)	Driver's door LEFT FRONT HIGH RANGE SPEAKER, H59		02-4
X18198	CONNECTOR (10-PINS, BLACK)	Passenger's door RIGHT FRONT HIGH RANGE SPEAKER, H50		02-4
X18277	CONNECTOR (2-PINS, BLACK)	LH front door	32-2	
X18295	CONNECTOR (2-PINS, YELLOW)	In lower RH B-pillar behind trim panel		
X18296	CONNECTOR (2-PINS, YELLOW)	In lower LH B-pillar behind trim panel	32-2	
X18336	CONNECTOR (3-PINS, BLACK)	LH side of glove box (glove box removed)		01-1
X18500	CONNECTOR (25-PINS, (---))	Center console		
X18507	CONNECTOR (2-PINS, (---))	Center console		
X18509	CONNECTOR (8-PINS, (---))	Center console		



COMPONENT LOCATION CHART

COMPONENT

PAGE - FIGURE
7100.0 8500.0

X18515	CONNECTOR (2-PINS, (---))	LH side of LH footwell behind trim panel	
X18518	CONNECTOR (3-PINS, BLACK)	Under RH front seat	01-1
X18520	CONNECTOR (10-PINS, (---))	Center console RADIO, N9	
X18521	CONNECTOR (10-PINS, (---))	RH side of luggage compartment CD CHANGER, N22	
X18723	GROUND	Below LH side of dash	
X18741	CONNECTOR (4-PINS, (---))	Center of dash MICROPHONE, B400	
X18797	CONNECTOR (1-PINS, NATURAL)	In RH rear side of luggage compartment	
X18798	CONNECTOR (1-PINS, NATURAL)	In RH rear side of luggage compartment	
Y1	ABS HYDRAULIC UNIT	Rear LH side of engine compartment back of LH side shock tower	16-2
Y1w	ABS HYDRAULIC UNIT	LH side of engine compartment	
Y2	AIR CONDITIONING COMPRESSOR	Front of engine	
Y4	WATER VALVE ASSEMBLY	Rear LH side of engine compartment	16-2
Y5	DRIVER'S SIDE MIRROR	In upper LH front door	
Y6	PASSENGER'S SIDE MIRROR	In upper RH front door	
Y19	SHIFT-LOCK	Center console RH side of gearshift selector	
Y85	LH ROLLOVER PROTECTION ACTUATOR	Behind rear seats Convertible	02-3
Y86	RH ROLLOVER PROTECTION ACTUATOR	Behind rear seats Convertible	02-3
Y5013	CHANGE-OVER VALVE	LH side of engine (M3)	14-2
Y5020	VARIABLE CAMSHAFT CONTROL VALVE 1	RH front of engine (M3)	11-2
Y5021	VARIABLE CAMSHAFT CONTROL VALVE 2	Front of engine compartment (M3)	



COMPONENT LOCATION CHART

COMPONENT





PAGE - FIGURE
7100.0 8500.0

Y6101	. CYL. 1 FUEL INJECTION VALVE	 RH front of engine (M3)	 11-2
Y6101	. CYL. 1 FUEL INJECTION VALVE	 Top center of engine	 12-3
Y6102	. CYL. 2 FUEL INJECTION VALVE	 Top center of engine	 12-3
Y6103	. CYL. 3 FUEL INJECTION VALVE	 Top center of engine	 12-3
Y6104	. CYL. 4 FUEL INJECTION VALVE	 Top center of engine	 12-3
Y6105	. CYL. 5 FUEL INJECTION VALVE	 Top center of engine	 12-3
Y6106	. CYL. 6 FUEL INJECTION VALVE	 Top center of engine	 12-3
Y6120	. EVAPORATIVE EMISSION VALVE	 Front LH side of engine compartment right of LH side shock tower	 15-1
Y6120	. EVAPORATIVE EMISSION VALVE	 LH side of engine compartment right of LH side shock tower	 20-3
Y6130	. IDLE SPEED CONTROL VALVE	 RH front of engine below intake manifold (325i)	 11-3
Y6130	. IDLE SPEED CONTROL VALVE	 Rear LH side of engine compartment (M3)	 14-3
Y6208	. CAMSHAFT ACTUATOR	 Front of engine compartment	
Y8505y	. TRANSMISSION VALVE UNIT	 On LH side of transmission	



COMPONENT LOCATION VIEWS





ELECTRICAL CONTROL MODULE LOCATIONS





COMPONENT LOCATION VIEWS





ELECTRICAL CONTROL MODULE LOCATIONS





COMPONENT LOCATION VIEWS





ELECTRICAL CONTROL MODULE LOCATIONS





COMPONENT LOCATION VIEWS





ELECTRICAL CONTROL MODULE LOCATIONS





COMPONENT LOCATION VIEWS






ELECTRICAL CONTROL MODULE LOCATIONS



M3 **CDN**








COMPONENT LOCATION VIEWS











COMPONENT LOCATION VIEWS





BMW
3 **COMPONENT LOCATION VIEWS**

B(-)









*RH similar







*RH similar





COMPONENT LOCATION VIEWS









COMPONENT LOCATION VIEWS






M3



325i



325i




B5023
VARIABLE CAM-
SHAFT CONTROL
SENSOR 2

X5023
X6232
X6236

B6232
ENGINE COOLANT
TEMPERATURE
SENSOR

B6236
ENGINE COOLANT
TEMPERATURE
SENSOR



Y6101
CYL. 1 FUEL
INJECTION VALVE

Y6102
CYL. 2 FUEL
INJECTION VALVE

Y6103
CYL. 3 FUEL
INJECTION VALVE





Y6104
CYL. 4 FUEL
INJECTION VALVE



Y6105
CYL. 5 FUEL
INJECTION VALVE

Y6106
CYL. 6 FUEL
INJECTION VALVE




COMPONENT LOCATION VIEWS






M3 **CDN**







M3 **CDN**







M3 **CDN**



COMPONENT LOCATION VIEWS







316I




COMPONENT LOCATION VIEWS



B6231
OIL PRESSURE
SWITCH

X6231


318l



B6236
ENGINE COOLANT
TEMPERATURE
SENSOR

X6236

318l



R6252
THROTTLE
POSITION
SENSOR





T6151
CYL. 1 IGNITION
COIL

T6152
CYL. 2 IGNITION
COIL

T6153
CYL. 3 IGNITION
COIL





T6154
CYL. 4 IGNITION
COIL

318l







COMPONENT LOCATION VIEWS




M3




B21
ON-BOARD
COMPUTER
TEMPERATURE
SENSOR

X770



M2
FUEL PUMP

X638
X679







Y6120
EVAPORATIVE
EMISSION VALVE

X6120

3181






COMPONENT LOCATION VIEWS













COMPONENT LOCATION VIEWS







COMPONENT LOCATION VIEWS






COMPONENT LOCATION VIEWS




COMPONENT LOCATION VIEWS







AUTOMATIC




MANUAL



COMPONENT LOCATION VIEWS




K114
COMFORT RELAY







G6
PASSENGER'S
AIR BAG GAS
GENERATOR I

X782











X32
X33
X35
X72
X295













COMPONENT LOCATION VIEWS









COMPONENT LOCATION VIEWS









COMPONENT LOCATION VIEWS





COMPONENT LOCATION VIEWS



BMW
3

8000.0



SPLICE LOCATION VIEWS

SPLICE	HARNESS	PAGE NUMBER	SPLICE	HARNESS	PAGE NUMBER
X181-X276	FRONT	8000.0-02	X5018-X5035	S50 ENGINE	8000.0-06
X313-X314	REAR	8000.0-03	X6410	M42/M43 ENGINE	8000.0-05
X313-X314	REAR, CONVERTIBLE	8000.0-04	X6410-X6492	S50 ENGINE	8000.0-06
X428-X481	REAR	8000.0-03	X6410	M50 ENGINE	8000.0-07
X428	REAR, CONVERTIBLE	8000.0-04	X6411	M50 ENGINE	8000.0-07
X441-X456	REAR, CONVERTIBLE	8000.0-04	X6458-X6492	M42/M43 ENGINE	8000.0-05
X460-X462	REAR, CONVERTIBLE	8000.0-04	X6458-X6461	M50 ENGINE	8000.0-07
X465-X481	REAR, CONVERTIBLE	8000.0-04	X6475	M50 ENGINE	8000.0-07
X530-X595	FRONT	8000.0-02	X6491	M50 ENGINE	8000.0-07
X805	REAR	8000.0-03	X6492	M50 ENGINE	8000.0-07
X805	REAR, CONVERTIBLE	8000.0-04	X6810-X6866	M42/M43 ENGINE	8000.0-05
X824-X830	RADIO	NOT SHOWN	X6810-X6866	S50 ENGINE	8000.0-06
X849-X851	DRIVER'S DOOR	NOT SHOWN	X6810	M50 ENGINE	8000.0-07
X876-X878	RADIO	NOT SHOWN	X6820-6823	M50 ENGINE	8000.0-07
X906	IHKR	NOT SHOWN	X6830-X6831	M50 ENGINE	8000.0-07
X942	PASSENGER'S DOOR	NOT SHOWN	X6835-X6836	M50 ENGINE	8000.0-07
X1015-X1164	FRONT	8000.0-02	X6863-X6866	M50 ENGINE	8000.0-07
X1167	REAR	8000.0-03	X6900-X6906	M50 ENGINE	8000.0-07
X1168-X1192	FRONT	8000.0-02	X6900-X6906	S50 ENGINE	8000.0-06
X1212-X1218	REAR	8000.0-03	X8004	M50 ENGINE	8000.0-07
X1212-X1238	REAR, CONVERTIBLE	8000.0-04	X8004	S50 ENGINE	8000.0-06
X1225-X1233	FRONT	8000.0-02	X8004-X8576	M42/M43 ENGINE	8000.0-05
X1226-X1235	REAR	8000.0-03	X8007	M50 ENGINE	8000.0-07
X1258	FRONT	8000.0-02	X8010	M50 ENGINE	8000.0-07
X1299	REAR	8000.0-03	X8015	M50 ENGINE	8000.0-07
X1382-X1383	RADIO	NOT SHOWN	X8022	M50 ENGINE	8000.0-07
X1387-X1396	REAR	8000.0-03	X8025	M50 ENGINE	8000.0-07
X1387-X1396	REAR, CONVERTIBLE	8000.0-04	X8042	M50 ENGINE	8000.0-07




SPLICE LOCATION VIEWS

SPLICE	HARNESS	PAGE NUMBER
X8051	M50 ENGINE	8000.0-07
X8056	M50 ENGINE	8000.0-07
X8065	M50 ENGINE	8000.0-07
X8071-8074	M50 ENGINE	8000.0-07
X8084	M50 ENGINE	8000.0-07
X10007-X10100	FRONT	8000.0-02
X10118	REAR, CONVERTIBLE	8000.0-04
X10251-10252	FRONT	8000.0-02
X10120-X10192	FRONT	8000.0-02
X10189-X10229	REAR, CONVERTIBLE	8000.0-04
X13002-X13011	REAR	8000.0-03
X13002-X13011	REAR, CONVERTIBLE	8000.0-04
X13021-X13115	FRONT	8000.0-02
X13007-X13273	REAR, CONVERTIBLE	8000.0-04
X18160-X18161	IHKR	NOT SHOWN
X18165	FRONT	8000.0-02
X18251	DRIVER'S DOOR	NOT SHOWN
X18252	PASSENGER'S DOOR	NOT SHOWN
X18253	DRIVER'S DOOR	NOT SHOWN
X18254-X18284	PASSENGER'S DOOR	NOT SHOWN
X18783-X18784	FRONT	8000.0-02
X18785-X18799	REAR, CONVERTIBLE	8000.0-04
X19513-X19514	RADIO	NOT SHOWN
X69008-X69009	S50 ENGINE	8000.0-06

SPLICE LOCATION VIEWS


FRONT HARNESS





SPLICE LOCATION VIEWS

REAR HARNESS




SPLICE PANEL

X441	●	X462	●	X1396	●
X442	●	X475	●	X13002	●
X443	●	X481	●	X13003	●
X444	●	X1212	●	X13010	●
X445	●	X1235	●	X13011	●
X449	●	X1299	●		
X450	●	X1387	●		



SPLICE LOCATION VIEWS


REAR WIRING HARNESS - CONVERTIBLE





SPLICE LOCATION VIEWS

ENGINE HARNESS M42/M43






SPLICE LOCATION VIEWS

ENGINE HARNESS S50

CDN



09/94

8000.0-06

1995



SPLICE LOCATION VIEWS

M50 ENGINE HARNESS




FIG. 1

B550001.03




FIG. 2

B260005.00




FIG. 3

B150003.00





FIG. 4

B300001.00





CONNECTOR VIEWS

FIG. 1

B030024




FIG. 2

B120003.00




FIG. 3

B120001.00




FIG. 4

B080002.00




FIG. 5

B180000.00




FIG. 6

B120015




FIG. 1

B030001.00




FIG. 2

B070007.00




FIG. 3

B170001.00




FIG. 4

B100008.00




FIG. 5

B030005.00





FIG. 6

B120004.01





CONNECTOR VIEWS

FIG. 1

B040002.00




FIG. 2

B050003.00



FIG. 3

B040004.00



FIG. 4

B040018




FIG. 5

B080001.00




FIG. 6

B090002.00




FIG. 1

B210002.00




FIG. 2

B060001.02



FIG. 3

B070005.00




FIG. 4

B200003.00




FIG. 5

B060010.01




FIG. 6

B030003.02





CONNECTOR VIEWS

FIG. 1

B060008.00




FIG. 2

B250001.01




FIG. 3

B060019.02




FIG. 4

B060037.00




FIG. 1

B880001.00




FIG. 2

B080038.00





FIG. 3

B030008.00





CONNECTOR VIEWS

FIG. 1

B080012.00




FIG. 2

B040023.01




FIG. 3

B030018.00




FIG. 4

B030015.08




FIG. 5

B030023.00




FIG. 6

B040020.00




FIG. 1

B030025.00




FIG. 2

B060037.01




FIG. 3

B030001.00




FIG. 4

B060001.00



FIG. 5

B120004.05




FIG. 6

B060009.00




FIG. 1

B100004.01




FIG. 2

B180002.00




FIG. 3

B090042




FIG. 4

B100007.00




FIG. 1

B040021




FIG. 2

B260002.04




FIG. 3

B040003.00




FIG. 4

B130002.00





FIG. 5

B040013





CONNECTOR VIEWS

FIG. 1

B040022.00




FIG. 2

B030009.00




FIG. 3

B120002.02




FIG. 4

B180001.00




FIG. 5

B100011.01




FIG. 6

B480000.00




FIG. 1

B050006.00




FIG. 2

B300003.00




FIG. 3

B040027.00





FIG. 4

B420000.00





CONNECTOR VIEWS

FIG. 1

B030042.01




FIG. 2

B030018.01




FIG. 3

B090008.00

