

AUTOMATIC TRANSMISSION

CONTENTS

E23AA--

| | | | |
|--|--------------|--|----|
| GENERAL INFORMATION | 2 | 2WD/4WD Detection Switch Check | 40 |
| SPECIFICATIONS | 26 | Centre Differential Lock | |
| Transmission Model Table | 26 | Operation Detection Switch Check | 40 |
| Gear Ratio Table | 26 | 4WD Operation Detection Switch Check | 40 |
| General Specifications | 26-1 | HI/LO Detection Switch Check | 40 |
| Service Specifications | 27 | Inhibitor Switch Check | 41 |
| Lubricants | 28 | Selector Lever Operation Check | 43 |
| Sealants and Adhesives | 28 | Adjustment of Inhibitor Switch and | |
| SPECIAL TOOLS | 28-1 | Control Cable | 43 |
| TROUBLESHOOTING <V4AW2> | 29 | | |
| TROUBLESHOOTING <V4AW3> | 35-1 | | |
| SERVICE ADJUSTMENT | | | |
| PROCEDURES | 35-37 | | |
| Automatic Transmission Fluid | | | |
| Inspection | 35-37 | | |
| Automatic Transmission Fluid Change | 35-38 | | |
| Transfer Oil Inspection and Change | 35-38 | | |
| Throttle Cable Check and Adjustment | 35-38 | | |
| ELC-4A/T Control Component Location | | | |
| <V4AW3> | 35-40 | | |
| V4AW3 Control Component Inspection ... | 35-43 | | |
| Converter Stall Test | 36 | | |
| Hydraulic Pressure Test | 37 | | |
| Governor Pressure Test | 37 | | |
| Line Pressure Test | 38 | | |
| Centre Differential Lock Detection | | | |
| Switch Check | 40 | | |

23-1-1

| | |
|--|-----------|
| 4WD Indicator Control Unit Check | 44 |
| Speedometer Cable Replacement | 44 |
| Transfer Oil Seals Replacement | 44 |
| Automatic Transmission Fluid Temperature Switch Check | 44-1 |
| TRANSMISSION CONTROL | 45 |
| SELECTOR LEVER ASSEMBLY | 48 |
| TRANSMISSION OIL COOLER, HOSES, PIPES | 50 |
| TRANSMISSION AND TRANSFER ASSEMBLY | 52 |

NOTES

cardiagn.com


GENERAL INFORMATION

E23BAAL

TRA0238


HYDRAULIC CIRCUIT
<V4AW2-3-L>

N (NEUTRAL)




P (PARKING)

TRA0239




D-1 (DRIVE 1ST)




TRA0240

D-2 (DRIVE 2ND)

TRA0241



D-3 (DRIVE 3RD)




TRA0242

D-4 (DRIVE 4TH)


LOCK-UP CLUTCH : OFF

TRA0243



D-4 (DRIVE 4TH)

LOCK-UP CLUTCH : ON




TRA0244

D-K/D (DRIVE KICK DOWN)


4TH ➡ 3RD

TRA0245



D-3 (DRIVE 3RD)


OVERDRIVE SWITCH : OFF



TRA0246


2-2 (SECOND 2ND)

TRA0247



L (LOCK UP)


TRA0248



R (REVERSE)

TRA0249

cardiagn.com




HYDRAULIC CIRCUIT


<V4AW2-3-Q>

N (NEUTRAL)

TRA0250




P (PARKING)




TRA0251

D-1 (DRIVE 1ST)



TRA0252


D-2 (DRIVE 2ND)



TRA0253

cardiagn.com


D-3 (DRIVE 3RD)



TRA0254

D-4 (DRIVE 4TH)


LOCK-UP CLUTCH : OFF



TRA0255

LOCK-UP CLUTCH : ON


TRA0256



D-K/D (DRIVE KICK DOWN)


4TH ➔ 3RD

TRA0257



D-3 (DRIVE 3RD)


OVERDRIVE SWITCH : OFF




TRA0258

2-2 (SECOND 2ND)

TRA0259




L (LOCK UP)



TRA0260

R (REVERSE)




TRA0261

cardiagn.com

HYDRAULIC CIRCUIT


<V4AW3>

(1) R (REVERSE)



TRA0735


(2) D-1 (DRIVE 1ST)



TRA0736


cardiagn.com

(3) D-2 (DRIVE 2ND)




TRA0737

(4) D-3 (DRIVE 3RD)




TRA0738

(5) D-4 (DRIVE 4TH) LOCK UP



TRA0739

(6) 2-1 (SECOND 1ST)




TRA0740


cardiagn.com

(7) 2-2 (SECOND 2ND)

TRA0741



(8) L (1ST)



TRA0742

cardiagn.com

cardiagn.com

NOTES

cardiagn.com

SPECIFICATIONS

TRANSMISSION MODEL TABLE

E23CF--

| Transmission model | Gear ratio | Speedometer gear ratio | Vehicle model | Engine model (Engine displacement) |
|--------------------|------------|------------------------|------------------|---------------------------------------|
| V4AW2-3-LFP | B | 26/8 | V23W, V43W | 6G72-12 valve (3000-12V) |
| V4AW2-3-LFPL | B | 26/8 | V23C, V23W, V43W | 6G72-12 valve (3000-12V) |
| V4AW2-3-QGP | A | 27/8 | V44W | 4D56 (2500D) |
| V4AW2-3-QGPL | A | 27/8 | V44W | 4D56 (2500D) |
| V4AW2-3-QHP | A | 28/8 | V44W | 4D56 (2500D) |
| V4AW2-3-QHPL | A | 28/8 | V44W | 4D56 (2500D) |
| V4AW2-7-LFP | B | 26/8 | V23W, V43W | 6G72-12 valve (3000-12V) |
| V4AW2-7-LFPL | B | 26/8 | V23C, V23W, V43W | 6G72-12 valve (3000-12V) |
| V4AW3-7-LI | C | 29/8 | V23W, V43W | 6G72-24 valve (3000-24V) |
| V4AW3-7-LIL | C | 29/8 | V23C, V23W, V43W | 6G72-24 valve (3000-24V) |
| V4AW3-7-MH | C | 28/9 | V25W, V45W | 6G74 (3500) |
| V4AW3-7-MHL | C | 28/9 | V25W, V45W | 6G74 (3500) |
| V4AW3-7-UI | D | 29/9 | V46W | 4M40 (2800D) |
| V4AW3-7-UIL | D | 29/9 | V46W | 4M40 (2800D) |
| V4AW3-7-UJ | D | 30/9 | V46W | 4M40 (2800D) |
| V4AW3-7-UJL | D | 30/9 | V46W | 4M40 (2800D) |

GEAR RATIO TABLE

E23CG--

| | A | B | C | D |
|---------|-------|-------|-------|-------|
| 1st | 2.826 | 2.826 | 2.804 | 2.804 |
| 2nd | 1.493 | 1.493 | 1.531 | 1.531 |
| 3rd | 1.000 | 1.000 | 1.000 | 1.000 |
| 4th | 0.688 | 0.730 | 0.754 | 0.705 |
| Reverse | 2.703 | 2.703 | 2.393 | 2.393 |

GENERAL SPECIFICATIONS

E23CA--

| Items | V4AW2-3 | V4AW3-7 |
|--------------------------|---|---|
| Torque converter | | |
| Type | 3 elements, 1-step 2-phase system with lock-up clutch | 3 elements, 1-step 2-phase system with lock-up clutch |
| One-way clutch | Sprag type | Sprag type |
| Transmission | | |
| Type | 4 speed full automatic | Electronically controlled 4 speed full automatic |
| Control elements | | |
| Clutch | Multiple disc type 3 pairs | Multiple disc type 3 pairs |
| Brake | Multiple disc type 4 pairs | Multiple disc type 3 pairs |
| One-way clutch | Sprag type 3 pairs | Sprag type 3 pairs |
| Shift control method | Floor shift type | Floor shift type |
| Select pattern | P-R-N-D-2-L and overdrive switch | P-R-N-D-2-L and overdrive switch |
| Oil pump | | |
| Type | Gear type | Gear type |
| Drive system | Directly coupled to engine via torque converter | Directly coupled to engine via torque converter |
| Hydraulic control system | Throttle opening and vehicle speed detection | Electronically controlled |
| Oil-cooling system | Air-cooled and water-cooled type | Air-cooled and water-cooled type |
| Transfer | | |
| Type | 2 speed | 2 speed |
| Shift control method | Floor-shift type | Floor-shift type |
| Gear ratios | | |
| LOW | 1.925 | 1.925 |
| HIGH | 1.000 | 1.000 |

SERVICE SPECIFICATIONS

E23CB--

| Items | 3000-12V | 2500D |
|--|------------------------------|--------------------------------------|
| Stall speed (r/min) | 2,100-2,400 | 2,100-2,400 |
| Governor pressure kPa (kg/cm ² , psi) | | |
| 1000 r/min | 140-170 (1.4-1.7, 19.9-24.2) | 110-140 (1.1-1.4, 15.6-19.9) |
| 2000 r/min | 250-290 (2.5-2.9, 35.6-41.2) | 220-240 (2.2-2.4, 31.3-34.1) |
| 3200 r/min | 410-470 (4.1-4.7, 58.3-66.8) | 410-470 (4.1-4.7, 58.3-66.8) |
| Line pressure kPa (kg/cm ² , psi) | | |
| "D" range | | |
| When idling | 520-600 (5.2-6.0, 74-85) | 450-510 (4.5-5.1, 64-72.5) |
| During stall | 1100-1300 (11-13, 156-185) | 1,120-1,320 (11.2-13.2, 159.3-187.7) |
| "R" range | | |
| When idling | 790-910 (7.9-9.1, 112-129) | 620-700 (6.2-7.0, 88.2-99.5) |
| During stall | 1600-2000 (16-20, 228-284) | 1,500-1,900 (15-19, 213.3-270.2) |
| Dimensions of inner cable stopper and dust cover end mm (in.) | 0-1 (0-0.04) | — |
| Dimensions of inner cable stopper and outer cable end mm (in.) | — | 34-35 (1.34-1.38) |
| Clearance between sleeve and selector lever end mm (in.) | 18.2-18.9 (0.717-0.744) | 18.2-18.9 (0.717-0.744) |

| Items | 3000-24V, 3500 | 2800D |
|--|----------------------------------|----------------------------------|
| Stall speed (r/min) | 2,100-2,600 | 2,100-2,600 |
| Governor pressure kPa (kg/cm ² , psi) | | |
| 1000 r/min | — | — |
| 2000 r/min | — | — |
| 3200 r/min | — | — |
| Line pressure kPa (kg/cm ² , psi) | | |
| "D" range | | |
| When idling | 430-490 (4.3-4.9, 61-70) | 430-490 (4.3-4.9, 61-70) |
| During stall | 1,140-1,390 (11.4-13.9, 162-198) | 1,350-1,600 (13.5-16.0, 192-228) |
| "R" range | | |
| When idling | 520-620 (5.2-6.2, 74-88) | 530-630 (5.3-6.3, 75-90) |
| During stall | 1,400-1,750 (14.0-17.5, 199-249) | 1,670-2,020 (16.7-20.2, 238-287) |
| Dimensions of inner cable stopper and dust cover end mm (in.) | 0-1 (0-0.0394) | — |
| Dimensions of inner cable stopper and outer cable end mm (in.) | — | 34-35 (1.3386-1.3780) |
| Clearance between sleeve and selector lever end mm (in.) | — | — |

LUBRICANTS

E23CD--

| Items | Specified lubricants | Quantity dm ³ (U.S.qts., Imp.qts.) |
|------------------------------|---|--|
| Automatic transmission fluid | Dia Queen ATF SP, ATF DEXRON II or equivalent | Approx. 7.2 (7.6, 6.3): V4AW2 Approx. 8.5 (9.0, 7.5): V4AW3 |
| Transfer oil | Hypoid gear oil API GL-4, SAE 75W-90 or 75W-85W | Approx. 2.3 (2.4, 2.0): V4AW2 Approx. 2.5 (2.6, 2.2): V4AW3 |
| Transfer oil seal lip | Hypoid gear oil API GL-4, SAE 75W-90 or 75W-85W | As required |
| O-ring for oil filler pipe | Dia Queen ATF SP, ATF DEXRON II or equivalent | As required |








SEALANTS AND ADHESIVES

E23CE--

| Items | Specified sealant and adhesive | Remarks |
|---|---|---|
| TRANSMISSION CONTROL Transfer control lever assembly gasket Stopper plate gasket Transfer control lever assembly mounting bolt | 3M ATD Part No. 8661 or equivalent 3M ATD Part No. 8661 or equivalent 3M Stud Locking No. 4170 or equivalent | Semi-drying sealant Semi-drying sealant Anaerobic sealant |
| TRANSMISSION AND TRANSFER ASSEMBLY Control housing gasket Control housing mounting bolt | 3M ATD Part No. 8661 or equivalent 3M Stud Locking No. 4170 or equivalent | Semi-drying sealant Anaerobic sealant |

SPECIAL TOOLS

E23DA--

| Tool | Number | Name | Use |
|--|------------------------------------|---|---|
|  | MD998330 (includes MD998331) | Oil pressure gauge (3,000 kPa, 30 kg/cm ² , 427 psi) | Measurement of oil pressure |
|  | MD999563 (includes MD998331) | Oil pressure gauge (1,000 kPa, 10 kg/cm ² , 142 psi) | |
|  | MD998920 | Adapter | Connection of oil pressure gauge |
|  | MB990925 | Bearing and oil seal installer set | Installation of oil seal MB990938, MB990928 (Refer to GROUP 22–Special Tools.) |
|  | MB991529 | Diagnostic trouble code check terminal | Reading diagnostic trouble code |
|  | MB991502 | MUT-II | <ul style="list-style-type: none"> ● Reading diagnostic trouble code ● ELC-4A/T system inspection |
|  16X0607 | | ROM pack | |

NOTES

cardiagn.com

TROUBLESHOOTING <V4AW2>

E23EAAK


Automatic transmission malfunctions may be caused by the following conditions:




- (1) Improper maintenance and adjustment
- (2) Mechanical malfunctions
- (3) Hydraulic malfunctions
- (4) Poor engine performance


Troubleshooting in the event of any such malfunctions should begin by checking fluid level, ATF condition, manual linkage adjustment, throttle control cable adjustment and other conditions whose deviation from standards can be readily known. Then, road test shall be performed to determine whether or not the problem has been corrected or more diagnosis is necessary. If the problem still persists after these tests and corrections, hydraulic tests should be performed for further troubleshooting.

ROAD TEST


Prior to performing road test, be sure to make basic checks including check and adjustment of fluid level and condition and adjustment of the throttle cable. For road test, the transfer must be placed in the 2H (2WD-high) position. In road test, various changes such as slips in transmission and shifting conditions are checked and hence the transmission operation at each shift position must have been checked.

D RANGE TEST



**NOTE**


Abnormal noises and vibrations are often caused by an unbalanced propeller shaft, differential, tyre, torque converter, engine etc. Extremely thorough inspection is therefore required.






NOTE

- (1) Determine the moment when lock up turns ON by decreased engine r/min or by a slight shock back and forth.
 - (2) Determine the moment when lock up turns OFF by increased engine r/min.
 - (3) Check lock up condition by pumping the accelerator slightly. If engine r/min rises in accordance with throttle valve opening size, determine that the lock up is OFF, if not, determine it ON.
- (When lock up is OFF, drive power is transferred through the fluid in the torque converter and therefore, when the accelerator pedal is depressed, slipping occurs inside the torque converter with a resulting large increase in engine r/min.)


2 RANGE TEST



L RANGE TEST**R RANGE TEST****P RANGE TEST**


SHIFT PATTERN

3000-12V <V4AW2-3-LFP, LFPL>





TRA0343

2500D <V4AW2-3-QGP, QGPL>



TRA0345


2500D <V4AW2-3-QHP, QHPL>**3000-12V <V4AW2-7-LFP, LFPL>**

TROUBLESHOOTING <V4AW3>

STANDARD FLOW OF DIAGNOSTIC TROUBLESHOOTING

Malfunctions of the 4 A/T system can be caused by malfunctions or incorrect adjustments of the electronic control system, hydraulic control system or A/T system or a combination of these.

Carry out troubleshooting by the following procedure in order to make effective diagnoses.



- ① Gain a full understanding of the conditions under which the trouble symptoms that the customer is complaining about occur, including frequency of occurrence.
- ② Use the MUT-II to read and make a note of the diagnostic trouble codes (including fail-safe codes). (Refer to P.23-35-9.)
- ③ Erase the diagnostic trouble codes in order to carry out a road test. (Refer to P.23-35-9.)
- ④ Carry out adjustment of the basic inspection items (ATF, TPS, inhibitor switch, manual control cable, etc.) (Refer to P.23-35-37.)
- ⑤ Carry out a road test. (Refer to P.23-35-2.)
Be sure to check that the basic inspection items and all diagnostic trouble codes and conditions of reoccurrence are covered during this test.
- ⑥ Check that the diagnostic trouble codes which were read before the road test (in step (2) above) are present.
- ⑦ Determine the probable cause from the Inspection Procedures For Each Diagnostic Trouble Code. (Refer to P.23-35-10.)
- ⑧ Determine the probable cause from the Inspection Procedures For Each Trouble Symptom. (Refer to P.23-35-16.)

- ⑨ Carry out a intermittent malfunction simulation test.
 ⑩ After repairs are completed, carry out a road test to check that the malfunction has been repaired.

ROAD TEST

(Transfer Lever position: 4H Range)

★ : MUT-II used

| Proce- dure | Conditions | Operation | Judgement value | Inspection item | Inspection procedure page |
|----------------|--|--|--|---|---|
| 1 | Ignition switch: ON Engine: Stopped | Overdrive switch (1) ON (2) OFF | ★ Data List No. 35 (1) OD (2) OD-OFF | Overdrive switch | Overdrive switch system (P.23-35-29) |
| | | Pattern select switch (1) Power (2) Hold | ★ Data List No. 36 (1) Power (2) Hold | Pattern select switch | Pattern select switch system (P.23-35-28) |
| | | Selector lever position (1) P (2) R (3) N (4) D (5) 2 (6) L | ★ Data List No. 37 (1) P, R, D (2) P, R, D (3) N (4) P, R, D (5) 2 (6) L | Inhibitor switch | Inhibitor switch system (P.23-35-27) |
| | | Brake pedal (1) Depressed (2) Released | ★ Data List No. 28 (1) OD (2) OFF | Stop lamp switch | Stop lamp switch system (P.23-35-29) |
| 2 | Ignition switch: ST Engine: Stopped | Engine starting test in P and N positions | Starting should be possible | Starting | Does not move (P.23-35-18.) |
| | | | | | Lockup malfunction (P.23-35-26) |
| 3 | Warming up | (1) When engine is cold | ★ Data List No. 29 (1) OFF (2) ON | Engine coolant temperature switch | Engine coolant temperature switch system (P.23-35-30) |
| | | (2) Drive for 15 minutes or more so that the ATF temperature becomes 70–90°C (158–194°F) | ★ Data List No. 15 (2) 70–90°C (158–149°F) | Oil tempera- ture sensor | Oil temperature sensor system (P. 23-35-31) |

23-35-3 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

| Procedure | Conditions | Operation | Judgement value | Inspection item | Inspection procedure page |
|-----------|--|---|--|---|---|
| 4 | Engine: Idle Selector lever position: N | Accelerator pedal (1) Fully closed (2) Depressed (3) Fully open (up to 2 seconds) | ★ Data List No. 11 (1) 0–5% <Petrol engine> 0–20% <Diesel engine> (2) Gradually rises (1) (3) 85–100% <Petrol engine> 90–100% <Diesel engine> | TPS <Petrol engine> | Code No. 11 – TPS system (P.23-35-11) |
| | | | | LPS <Diesel engine> | Code No. 11 – LPS system (P.23-35-11) |
| | | | ★ Data List No. 21 (1) OFF (3) ON | Wide open throttle switch (W.O.T. switch) | Code No. 22 – W.O.T. switch system (P.23-35-12) |
| | | Selector lever operation (1) N → D shift (2) N → R shift | Should be no abnormal shifting shocks Time lag should be within 2 seconds | Does not move | Does not move forward or reverse (P.23-35-18) |
| | | | | | Does not move forward only (P.23-35-19) |
| | | | | | Does not reverse only (P.23-35-19) |
| | | | | Shock | Large shocks (P.23-35-24) |
| 5 | Engine: Idle (Vehicle stopped) Selector lever position: D Mode selection: Normal | Accelerator pedal (1) Fully closed | ★ Data List No. 27 (1) 1st | Shift solenoid No. 1 | Code Nos. 41, 42 – Shift control solenoid valve No. 1 system (P.23-35-14) |
| | | | | Shift solenoid No. 2 | Code Nos. 43, 44 – Shift control solenoid valve No. 2 system (P.23-35-15) |

| Procedure | Conditions | Operation | Judgement value | Inspection item | Inspection procedure page |
|-----------|--|--|--|---------------------------|---|
| 6 | Selector lever position: D Mode selection: Normal Overdrive: OFF | Engine (1) Idle (Vehicle stopped) (2) Driving at 10 km/h (3) Driving at constant speed of 50 km/h (20 seconds or more) (4) Driving at constant speed of 40 km/h with selector lever in 2 range | ★ Data List No. 27 (1) 1st (2) 1st (3) 3rd (4) 2nd | Shift solenoid No. 1 | Code Nos. 41, 42 – Shift solenoid No. 1 system (P.23-35-14) |
| | | | | Shift solenoid No. 2 | Code Nos. 43, 44 – Shift solenoid No. 2 system (P.23-35-15) |
| | | | ★ Data List No. 32 (1) 0 km/h (2) 7 – 13 km/h (3) 42 – 58 km/h (4) 33 – 47 km/h | A/T speed sensor | A/T speed sensor system (P.23-35-13) |
| | | | ★ Data List No. 41 (2) OFF (3) OFF (4) ON | Shift solenoid No. 1 | Code Nos. 41, 42 – Shift control solenoid valve No. 1 system (P.23-35-14) |
| | | | ★ Data List No. 43 (2) OFF (3) ON (4) ON | Shift solenoid No. 2 | Code Nos. 43, 44 – Shift control solenoid valve No. 2 system (P.23-35-15) |
| | | | ★ Data List No. 47 (2) OFF (3) ON (3) Acceleration should be smooth with no abnormal vibration. | Lock-up solenoid | Code Nos. 47, 48 – Lock-up solenoid (P.23-35-15) Shifting point abnormality (P.23-35-22) |
| | | | | Malfunction when shifting | Slippage (vibration) (P.23-35-25) |


23-35-5 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

| Procedure | Conditions | Operation | Judgement value | Inspection item | Inspection procedure page |
|-----------|--|--|--|------------------------------------|---|
| 7 | Selector lever position: D Mode selection: Normal Overdrive: ON | Engine (1) Driving at constant speed of 50 km/h (20 seconds or more) | ★ Data List No. 27 (1) 4 | Shift control solenoid valve No. 1 | Code Nos. 41, 42 – Shift control solenoid valve No. 1 system (P.23-35-14) |
| | | | | Shift control solenoid valve No. 2 | Code Nos. 43, 44 – Shift control solenoid valve No. 2 system (P.23-35-15) |
| | | | ★ Data List No. 41 (1) OFF | Shift control solenoid valve No. 1 | Code Nos. 41, 42 – Shift control solenoid valve No. 1 system (P.23-35-14) |
| | | | ★ Data List No. 43 (1) OFF | Shift control solenoid valve No. 2 | Code Nos. 43, 44 – Shift control solenoid valve No. 2 system (P.23-35-15) |
| 8 | Selector lever position: D Mode selection: Normal Overdrive: ON ● Carry out the same test with the mode selection at POWER and HOLD also. | Monitor MUT-II data list Nos. 11, 27 and 32. (1) TPS Accelerate to 4 range at opening angle of 30%. (2) Slowly decelerate to a standstill. (3) TPS Accelerate to 4 range at opening angle of 50%. (4) At 50 km/h in 4 range, turn overdrive OFF. (5) At 50 km/h in 3 range, move selector lever to 2 range. (6) At 20 km/h in 2 range, move selector lever to L range. | (1), (2) and (3) should match the specified output shaft speed (vehicle speed), and there should be no abnormal shocks. For (4), (5) and (6), downshifting should occur immediately after moving the lever. | Malfunction when shifting | Upshifting does not occur (P.23-35-20) |
| | | | | | Downshifting does not occur (P.23-35-21) |
| | | | | | Shifting point abnormality (P.23-35-22) |
| | | | | | Upshifting occurs spontaneously (P.23-35-22) |
| | | | | | Incorrect drive gear position (P.23-35-23) |
| | | | | Malfunction while driving | Large shocks (P.23-35-24) |
| | | | | | Slippage (vibration) (P.23-35-25) |
| | | | | | Lockup malfunction (P.23-35-26) |
| | | | | | Poor engine braking (P.23-35-26) |

SHIFT PATTERN


<3500>

Normal pattern



TRA0729


Power pattern



TRA0730

23-35-7 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>


Hold Pattern



TRA0731

<2800D>


Normal pattern



TRA0732


<3000-24V>

Power pattern



Hold pattern

TRA0733




TRA0734

23-35-8a AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>


<3000–24 V>

Normal pattern




TRA0880

Power pattern



TRA0881

Hold pattern



TRA0882




DIAGNOSTIC FUNCTIONS**PRECAUTIONS BEFORE SERVICE**

- (1) If battery voltage is low, diagnostic trouble codes will not be output. Accordingly, check the battery before carrying out inspection.
- (2) If the battery is disconnected or if the engine control unit connector is disconnected, the diagnostic trouble code memory will be erased. Accordingly, the battery should not be disconnected until reading of the diagnostic trouble codes has been completed.

READING THE DIAGNOSTIC TROUBLE CODES**<When using the MUT-II>****Caution**


Connection and disconnection of the MUT-II should always be carried out with the ignition switch in the OFF position.

- (1) Connect the MUT-II to the diagnosis connector.
- (2) Turn the ignition switch to ON.
- (3) Take a reading of the diagnostic code output.
- (4) Repair the malfunction location while referring to the Inspection Procedures For Each Diagnostic Trouble Code.
- (5) Turn the ignition switch to OFF and then back to ON again.
- (6) Erase the diagnostic trouble codes.
- (7) Check that the diagnostic code output is normal.

**<When using the oil temperature warning lamp>**

- (1) Use the special tool (diagnostic trouble code check harness) to earth terminal ① of the self-diagnosis connector.
- (2) Take a reading of the diagnostic trouble codes from the flashing of the oil temperature warning lamp.
- (3) Repair the malfunction location while referring to the Chart Classified by Diagnostic Trouble Codes.
- (4) Erase the diagnostic trouble codes by the following procedure.
 - ① Turn the ignition switch to OFF.
 - ② After disconnecting the battery cable from the negative battery terminal for 10 seconds or more, re-connect the cable.
 - ③ Turn the ignition switch to ON, take a reading of the diagnostic code output and check that a normal code is output.
 - ④ After the engine has warmed up, run it at idle for about 10 minutes.

UNDERSTANDING DIAGNOSIS RESULT BY THE OIL TEMPERATURE WARNING LAMP FLASHING



NOTE


Other diagnostic trouble codes also are output by the flashing of the check warning lamp corresponding to the same code numbers as when using the MUT-II.

INSPECTION CHART CLASSIFIED BY DIAGNOSTIC TROUBLE CODES


| Code | Diagnostic item | | Reference page |
|------|---|--|----------------|
| 11 | Throttle position sensor system <Petrol engine> Lever position sensor system <Diesel engine> | Malfunction of sensor Open circuit, short circuit | P.23-35-11 |
| 22 | Wide open throttle switch system | Short circuit | P.23-35-12 |
| 32 | A/T speed sensor system | Open circuit | P.23-35-13 |
| 38 | Vehicle speed sensor system | Open circuit | P.23-35-14 |
| 41 | Shift control solenoid valve No. 1 system | Open circuit | P.23-35-14 |
| 42 | Shift control solenoid valve No. 1 system | Short circuit | P.23-35-14 |
| 43 | Shift control solenoid valve No. 2 system | Open circuit | P.23-35-15 |
| 44 | Shift control solenoid valve No. 2 system | Short circuit | P.23-35-15 |
| 47 | Lock-up solenoid system | Open circuit | P.23-35-15 |
| 48 | Lock-up solenoid system | Short circuit | P.23-35-15 |

INSPECTION PROCEDURES FOR EACH DIAGNOSTIC TROUBLE CODE


| Code No. 11 | Throttle position sensor system | Probable cause |
|---|---------------------------------|---|
| [Comment] If the TPS output becomes 4.95 V or more, TPS output is excessive, and if the TPS output becomes 0.09 V or less, TPS output is insufficient. In both cases, diagnostic trouble code No. 11 is output. | | <ul style="list-style-type: none"> ● Malfunction of throttle position sensor ● Malfunction of connector ● Malfunction of A/T-ECU |



| Code No. 11 | Lever position sensor system | Probable cause |
|---|------------------------------|--|
| [Comment] If the LPS output becomes 4.95 V or more, LPS output is excessive, and if the LPS output becomes 0.09 V or less, LPS output is insufficient. In both cases, diagnostic trouble code No. 11 is output. | | <ul style="list-style-type: none"> ● Malfunction of lever position sensor ● Malfunction of connector ● Malfunction of A/T-ECU |




| Code No. 22 | Wide open throttle switch system | Probable cause |
|--|----------------------------------|--|
| [Comment] When the wide open throttle switch is ON despite less than 85% opening of the throttle, Code No. 22 is output. | | <ul style="list-style-type: none">● Malfunction of wide open throttle switch● Malfunction of connector● Malfunction of A/T-ECU |




23-35-13 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

| Code No. 32 | A/T speed sensor system | Probable cause |
|---|-------------------------|---|
| [Comment] If the vehicle moves 800 m or more while there is no output from the A/T speed sensor during the time that four pulses are input from the vehicle speed sensor, then there is judged to be an open circuit in the A/T speed sensor, and diagnostic trouble code No. 32 is output. | | <ul style="list-style-type: none">● Malfunction of A/T speed sensor● Malfunction of connector● Malfunction of sensor rotor● Malfunction of A/T-ECU● Noise generated |


★ : Refer to the Transmission Workshop Manual.



| Code No. 38 | Vehicle speed sensor system | Probable cause |
|--|-----------------------------|---|
| [Comment] If the vehicle moves 800 m or more while there is no output from the vehicle speed sensor during the time that 13 pulses (when the transfer control lever is at HIGH) or 25 pulses (when the transfer control lever is at LOW) are input from the A/T speed sensor, then there is judged to be an open circuit in the vehicle speed sensor, and diagnostic trouble code No. 38 is output. | | <ul style="list-style-type: none"> ● Malfunction of vehicle speed sensor ● Malfunction of connector ● Malfunction of A/T-ECU |




| Code No. 41, 42 | Shift control solenoid valve No. 1 system | Probable cause |
|--|---|---|
| [Comment] If the resistance value of shift control solenoid valve No. 1 is large, there is an open circuit in shift control solenoid valve No. 1 and diagnostic trouble code No. 41 is output. If the resistance value is small, there is a short circuit in shift control solenoid valve No. 1 and diagnostic trouble code No. 42 is output. | | <ul style="list-style-type: none"> ● Malfunction of shift solenoid No. 1 ● Malfunction of connector ● Malfunction of A/T-ECU |




23-35-15 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

| Code No. 43, 44 | Shift control solenoid valve No. 2 system | Probable cause |
|---|---|---|
| [Comment] If the resistance value of shift control solenoid valve No. 2 is large, there is an open circuit in shift solenoid No. 2 and diagnostic trouble code No. 43 is output. If the resistance value is small, there is a short circuit in shift control solenoid valve No. 2 and diagnostic trouble code No. 44 is output. | | <ul style="list-style-type: none"> ● Malfunction of shift control solenoid valve No. 2 ● Malfunction of connector ● Malfunction of A/T-ECU |



| Code No. 47, 48 | Lock-up solenoid system | Probable cause |
|---|-------------------------|---|
| [Comment] If the resistance value of the lock-up solenoid is large, there is an open circuit in the lock-up solenoid and diagnostic trouble code No. 47 is output. If the resistance value is small, there is a short circuit in the lock-up solenoid and diagnostic trouble code No. 48 is output. | | <ul style="list-style-type: none"> ● Malfunction of lock-up solenoid ● Malfunction of connector ● Malfunction of A/T-ECU |




INSPECTION CHART CLASSIFIED BY TROUBLE SYMPTOMS

| Trouble symptom | | Inspection procedure No. | Reference page |
|---|--|--------------------------|----------------|
| Communication with the MUT-II is not possible | | 1 | P.23-35-17 |
| Does not move | Does not move forward or reverse | 2 | P.23-35-18 |
| | Does not move forward only | 3 | P.23-35-19 |
| | Does not reverse only | 4 | P.23-35-19 |
| Malfunction when shifting | Upshifting does not occur | 5 | P.23-35-20 |
| | Downshifting does not occur | 6 | P.23-35-21 |
| | Shifting point abnormality | 7 | P.23-35-22 |
| | Upshifting occurs spontaneously | 8 | P.23-35-22 |
| | Incorrect drive gear position | 9 | P.23-35-23 |
| Large shocks | | 10 | P.23-35-24 |
| Slippage (vibration) | | 11 | P.23-35-25 |
| Lockup malfunction | | 12 | P.23-35-26 |
| Abnormal engine braking | | 13 | P.23-35-26 |
| Electronic circuit systems | Inhibitor switch system | 14 | P.23-35-27 |
| | Pattern select switch system | 15 | P.23-35-28 |
| | Overdrive switch system | 16 | P.23-35-29 |
| | Stop lamp switch system | 17 | P.23-35-29 |
| | Engine coolant temperature switch system | 18 | P.23-35-30 |
| | Oil temperature sensor system | 19 | P.23-35-31 |

INSPECTION PROCEDURES FOR EACH TROUBLE SYMPTOM

INSPECTION PROCEDURE 1


| | |
|---|--|
| <ul style="list-style-type: none"> Communication with the MUT-II is not possible | Probable cause |
| [Comment] If communication with the MUT-II is not possible, the cause is probably a malfunction in the self-diagnosis system or the A/T-ECU is not functioning. | <ul style="list-style-type: none"> Malfunction of self-diagnosis system Malfunction of A/T-ECU power circuit Malfunction of A/T-ECU earth circuit Malfunction of A/T-ECU |



INSPECTION PROCEDURE 2

| ● Does not move forward or reverse | Probable cause |
|--|---|
| <p>[Comment] When the engine is idling, the vehicle does not move forward or back even if the selector lever is shifted from N to D, 2, L or R range. In such cases, the cause is probably abnormal line pressure, or a malfunction of the torque converter, oil pump, parking mechanism or the power train.</p> | <ul style="list-style-type: none"> ● Abnormal line pressure ● Malfunction of power train ● Malfunction of oil pump ● Malfunction of valve body ● Malfunction of parking mechanism ● Malfunction of torque converter |

★ : Refer to the Transmission Workshop Manual.




23-35-19 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

INSPECTION PROCEDURE 3

| ● Does not move forward only | Probable cause |
|---|--|
| <p>[Comment] When the engine is idling, the vehicle does not move forward even if the selector lever is shifted from N to D, 2 or L range. In such cases, the cause is probably a malfunction of the clutch or brake.</p> | <ul style="list-style-type: none"> ● Malfunction of forward clutch ● Malfunction of direct clutch ● Malfunction of one-way clutch No. 2 ● Malfunction of 2nd-coast brake ● Malfunction of 2nd brake ● Malfunction of 1st & reverse brake |


★ : Refer to the Transmission Workshop Manual.



INSPECTION PROCEDURE 4

| ● Does not reverse only | Probable cause |
|--|--|
| <p>[Comment] When the engine is idling, the vehicle does not reverse even if the selector lever is shifted from N to R range. In such cases, the cause is probably a malfunction of a clutch, brake or the valve body.</p> | <ul style="list-style-type: none"> ● Malfunction of 2nd-coast brake ● Malfunction of direct clutch ● Malfunction of 1st & reverse brake ● Malfunction of valve body ● Malfunction of planetary gear |


★ : Refer to the Transmission Workshop Manual.



INSPECTION PROCEDURE 5

| | |
|--|---|
| <ul style="list-style-type: none"> Upshifting does not occur | Probable cause |
| <p>[Comment] Upshifting does not occur under conditions when upshifting should occur. Check shifting from 1 → 2, 2 → 3 and 3 → 4 respectively.</p> | <ul style="list-style-type: none"> Shift solenoid A/T-ECU Power train internal parts |


★ : Refer to the Transmission Workshop Manual.



INSPECTION PROCEDURE 6


| | |
|--|---|
| ● Downshifting does not occur | Probable cause |
| [Comment] Downshifting does not occur under conditions when downshifting should occur. Check shifting from 2 → 1, 3 → 2 and 4 → 3 respectively. | ● Shift solenoid ● A/T-ECU ● Power train internal parts |

★ : Refer to the Transmission Workshop Manual.




INSPECTION PROCEDURE 7

| ● Shifting point abnormality | Probable cause |
|---|---|
| <p>[Comment] Shifting occurs at points which are different from the shift pattern. Note that the shift pattern will vary in different modes and at high oil temperatures.</p> | <ul style="list-style-type: none"> ● Throttle (lever) position sensor ● A/T speed sensor ● Oil temperature sensor ● Pattern selector switch ● Engine coolant temperature switch ● A/T-ECU |



INSPECTION PROCEDURE 8

| ● Upshifting occurs spontaneously | Probable cause |
|---|---|
| <p>[Comment] Upshifting occurs in ranges where upshifting should not occur when in 2nd gear in L range, 3rd gear in 2 range or 4th gear in D range when OD switch is OFF.</p> | <ul style="list-style-type: none"> ● Inhibitor switch ● Overdrive switch ● A/T-ECU |




23-35-23 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

INSPECTION PROCEDURE 9

| | |
|--|--|
| <ul style="list-style-type: none">Incorrect drive gear position | Probable cause |
| [Comment] Vehicle starts off in 2nd, 3rd or 4th gear when in D range. Often occurs when starting off is not smooth. | <ul style="list-style-type: none">Inhibitor switchPattern select switchDirect clutchPlanetary gearValve body |


★ : Refer to the Transmission Workshop Manual.



INSPECTION PROCEDURE 10

| ● Large shocks | Probable cause |
|--|--|
| [Comment] Shocks accompany shifting from N → D, N → R and during each upshift and downshift. | <ul style="list-style-type: none"> ● Direct clutch ● 1st & Rev brake ● Stop lamp switch ● Inhibitor switch ● Forward clutch ● Valve body |

★ : Refer to the Transmission Workshop Manual.




23-35-25 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

INSPECTION PROCEDURE 11

| | |
|--|---|
| <ul style="list-style-type: none">Slippage (vibration) <p>[Comment] Occurs when a clutch or brake does not fully engage due to low hydraulic pressure or a worn facing. Appears as vibration when the problem is slight.</p> | <p>Probable cause</p> <ul style="list-style-type: none">Torque converterDirect clutchForward clutch2nd-coast brake2nd brakeOverdrive brake |
|--|---|


★ : Refer to the Transmission Workshop Manual.



INSPECTION PROCEDURE 12

| ● Lockup abnormality | Probable cause |
|--|---|
| [Comment] When lock-up does not operate even though in the lock-up range, and also when lock-up is operating and the engine is idling but then stalls. | <ul style="list-style-type: none"> ● Torque converter ● Valve body ● Oil temperature sensor ● Engine coolant temperature switch |


★ : Refer to the Transmission Workshop Manual.



INSPECTION PROCEDURE 13


| ● Abnormal engine braking | Probable cause |
|---|--|
| [Comment] Engine braking effectiveness is poor after downshifting has occurred. | <ul style="list-style-type: none"> ● Overdrive clutch ● 1st & Rev brake ● 2nd-coast brake ● Valve body |

★ : Refer to the Transmission Workshop Manual.




INSPECTION PROCEDURE 14

| Inhibitor switch system | Probable cause |
|---|---|
| [Comment] If the engine does not start in P or N range, the cause is probably a problem in the inhibitor switch system. | <ul style="list-style-type: none">● Malfunction of inhibitor switch● Malfunction of connector● Malfunction of A/T-ECU |



INSPECTION PROCEDURE 15


| | |
|---|--|
| <ul style="list-style-type: none"> Pattern select switch system | Probable cause |
| <p>[Comment] If the shift pattern does not change when the pattern select switch is operated, the cause is probably a malfunction of the pattern select switch.</p> | <ul style="list-style-type: none"> Malfunction of pattern select switch Malfunction of connector Malfunction of A/T-ECU |



23-35-29 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>


INSPECTION PROCEDURE 16

| ● Overdrive switch system | Probable cause |
|--|---|
| [Comment] If downshifting does not occur when overdrive is turned off while driving in 4th gear, or if shifting to 4th gear is not possible, the cause is probably a problem in the overdrive switch system. | <ul style="list-style-type: none"> ● Malfunction of overdrive switch ● Malfunction of connector ● Malfunction of A/T-ECU |




INSPECTION PROCEDURE 17

| ● Stop lamp switch system | Probable cause |
|--|---|
| [Comment] If large shocks occur during squat control, the cause is probably a problem with the stop lamp switch. | <ul style="list-style-type: none"> ● Malfunction of stop lamp switch ● Malfunction of connector ● Malfunction of A/T-ECU |




INSPECTION PROCEDURE 18

| ● Engine coolant temperature switch system | Probable cause |
|--|--|
| <p>[Comment] The cause is probably a malfunction of the engine coolant teaperture switch:</p> <ul style="list-style-type: none"> ● When upshifting to the 4th gear does not occur in D range. (OD switch: ON) ● When lock-up does not operate even though in the lock-up range. ● When there is insufficient output while the engine is cold. | <ul style="list-style-type: none"> ● Malfunction of engine coolant temperature switch ● Malfunction of connector ● Malfunction of A/T-ECU |



INSPECTION PROCEDURE 19

| ● Oil temperature sensor system | Probable cause |
|---|---|
| [Comment] If the oil temperature warning lamp remains illuminated, the cause is probably a problem with the oil temperature sensor. | <ul style="list-style-type: none">● Malfunction of oil temperature sensor● Malfunction of connector● Malfunction of A/T-ECU |



SERVICE DATA REFERENCE TABLE

| Item No. | Inspection item | Inspection conditions | | Normal value |
|----------|--|---|--|--|
| 11 | Throttle position sensor <Petrol powered vehicles> | Accelerator pedal position Engine: Idle Selector lever position: N | Fully closed | 0–5% |
| | | | Depressed | Gradually rises from the above value |
| | | | Fully open (up to 2 seconds) | 85–100% |
| | Lever position sensor <Diesel powered vehicles> | Accelerator pedal position Engine: Idle Selector lever position: N | Fully closed | 0–20% |
| | | | Depressed | Gradually rises from the above value |
| | | | Fully open (up to 2 seconds) | 90–100% |
| 15 | Oil temperature sensor | Warming up | Drive for 15 minutes or more so that the ATF temperature becomes 70–90°C (158–194°F) | Gradually rises to 70–90°C (158–194°F) |
| 21 | Wide open throttle switch | Accelerator pedal position Ignition switch: ON Engine: Stopped | Fully closed | OFF |
| | | | Fully open | ON |
| 27 | Shift position signal | Accelerator pedal position Engine: Idle (Vehicle stopped) Selector lever position: D Mode selection: Normal | Fully closed | 1st |
| | | | N → D shift | 1st → 3rd → 1st |
| | | Selector lever position: L Mode selection: Normal | Idle (Vehicle stopped) | 1st |
| | | Selector lever position: 2 Mode selection: Normal | Idle (Vehicle stopped) | 1st |
| | | | Driving at 40 km/h (20 seconds or more) | 2 |
| | | Selector lever position: D Mode selection: Normal Overdrive: OFF | Driving at constant speed of 50 km/h (20 seconds or more) | 3rd |
| | | Selector lever position: D Mode selection: Normal Overdrive: ON | Driving at constant speed of 50 km/h (20 seconds or more) | 4th |
| 28 | Stop lamp switch | Brake pedal position Ignition switch: ON Engine: Stopped | Depressed | ON |
| | | | Released | OFF |

23-35-33 AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3>

| Item No. | Inspection item | Inspection conditions | | Normal value |
|----------|-----------------------------------|--|--|--|
| 29 | Engine coolant temperature switch | When engine changes from cold to warm | While engine is cold | OFF |
| | | | After engine has warmed up | ON |
| 32 | A/T speed sensor* | Selector lever position: D Mode selection: Normal Overdrive: ON | Driving at 30 km/h | 25 – 35 km/h |
| | | | Driving at 50 km/h | 42 – 58 km/h |
| 35 | Overdrive switch | Ignition switch: ON Engine: Stopped | Overdrive switch: ON | OD |
| | | | Overdrive: OFF | OD – OFF |
| 36 | Pattern select switch | Ignition switch: ON Engine: Stopped | Pattern select switch Power mode | Power |
| | | | Pattern select switch Hold mode | Hold |
| | | | Pattern select switch Normal mode | Normal |
| 37 | Inhibitor switch | Ignition switch: ON Engine: Stopped | Selector lever position: P Selector lever position: R Selector lever position: N Selector lever position: D Selector lever position: 2 Selector lever position: L | P, R, D P, R, D N P, R, D 2 L |
| 39 | Cruise control-ECU | Selector lever position: D Mode selection: Normal | Auto-cruise control OFF | OFF |
| | | | Auto-cruise control ON (climbing at 50 km/h) | ON |
| 41 | Shift solenoid No. 1 | Selector lever position: D Mode selection: Normal | Driving at 10 km/h (Drive 1st) | ON |
| | | | Driving at 50 km/h (Drive 4th) | OFF |
| 43 | Shift solenoid No. 2 | Selector lever position: D Mode selection: Normal Overdrive: OFF | Driving at 10 km/h (Drive 1st) | OFF |
| | | | Driving at 50 km/h (Drive 3rd) | ON |
| 47 | Lock-up solenoid | Selector lever position: D Mode selection: Normal Overdrive: ON | Driving at 10 km/h (Drive 1st) | OFF |
| | | | Driving at 50 km/h (Drive 4th) | ON |

NOTE

*: Transfer lever position: 4H Range

REFERENCE FOR FAIL-SAFE/BACKUP FUNCTIONS

When malfunctions of the main sensors or actuators are detected by the self-diagnosis system, the vehicle is controlled by means of the pre-set control logic to maintain safe conditions for driving.

| Malfunctioning item | Control contents during malfunction | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|-------------------------|--------|-----------------------------------|-----|-----------------------------------|-----------------------------------|-----|-----------------------------------|--|----|--|--|--|------|----|----|------|----|----|------|----|----|------|----|----|---|---|---|---|---|--|-----|---|---|--|-----|--|--|---|---|---|--|---|--|-----|--|--|--|---|---|---|--|---|-----|---|--|--|--|-----|---|---|-----|---|--|---|--|--|--|---|---|---|---|---|--|-----|---|---|--|---|--|--|---|---|---|--|---|---|-----|--|--|--|---|---|---|--|---|---|---|--|--|--|---|---|---|---|---|--|---|---|---|--|---|--|--|---|---|---|---|--|---|--|---|--|--|--|--|
| A/T speed sensor | When there is an open circuit in the A/T speed sensor, vehicle speed detection is switched to the output from the vehicle speed sensor in the speedometer to maintain vehicle control. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Inhibitor switch | If there is an open circuit in the N, 2 or L signal line, driving is possible in the case of 2 and L (same as D range) so that control can be performed as if the range is D range, and driving is not possible in N range. If more than one of the 2, L or N signals are input, the order of priority for control is L → 2 → N. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Throttle position sensor | If the output is 0.09 V or less or 4.95 V or more, the throttle is fully closed and gear shifting control is carried out. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Lock-up solenoid | If a problem is detected, lock-up is stopped over the whole range and the solenoid is turned OFF to prevent the engine from stalling during idling. | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Shift control solenoid valve No. 1, No. 2 | <div>If a problem is detected, each solenoid stops operating and is turned OFF. The gear shifting logic when a problem is detected is given in the table below.</div> <table><tr><th rowspan="2">Selector lever position</th><th colspan="3">Normal</th><th colspan="3">When the solenoid No.1 has broken</th><th colspan="3">When the solenoid No.2 has broken</th><th colspan="3">When the solenoids No.1 and No.2 have broken</th></tr><tr><th>Gear</th><th>S1</th><th>S2</th><th>Gear</th><th>S1</th><th>S2</th><th>Gear</th><th>S1</th><th>S2</th><th>Gear</th><th>S1</th><th>S2</th></tr><tr><td rowspan="4">D</td><td>1</td><td>O</td><td>X</td><td rowspan="4">3</td><td></td><td>X→O</td><td>1</td><td>O</td><td></td><td rowspan="4">O/D</td><td></td><td></td></tr><tr><td>2</td><td>O</td><td>O</td><td></td><td>O</td><td></td><td>O→X</td><td></td><td></td><td></td></tr><tr><td>3</td><td>X</td><td>O</td><td></td><td>O</td><td>O/D</td><td>X</td><td></td><td></td><td></td></tr><tr><td>O/D</td><td>X</td><td>X</td><td>O/D</td><td>X</td><td></td><td>X</td><td></td><td></td><td></td></tr><tr><td rowspan="3">2</td><td>1</td><td>O</td><td>X</td><td rowspan="3">3</td><td></td><td>X→O</td><td>1</td><td>O</td><td></td><td rowspan="3">3</td><td></td><td></td></tr><tr><td>2</td><td>O</td><td>O</td><td></td><td>O</td><td>3</td><td>O→X</td><td></td><td></td><td></td></tr><tr><td>3</td><td>X</td><td>O</td><td></td><td>O</td><td>3</td><td>X</td><td></td><td></td><td></td></tr><tr><td rowspan="2">L</td><td>1</td><td>O</td><td>X</td><td>1</td><td></td><td>X</td><td>1</td><td>O</td><td></td><td>1</td><td></td><td></td></tr><tr><td>2</td><td>O</td><td>O</td><td>2</td><td></td><td>O</td><td></td><td>O</td><td></td><td></td><td></td><td></td></tr></table> <div>O : Energized (ON) X : Not energized (OFF) S1 : Solenoid valve No. 1 S2 : Solenoid valve No. 2</div> | Selector lever position | Normal | | | When the solenoid No.1 has broken | | | When the solenoid No.2 has broken | | | When the solenoids No.1 and No.2 have broken | | | Gear | S1 | S2 | Gear | S1 | S2 | Gear | S1 | S2 | Gear | S1 | S2 | D | 1 | O | X | 3 | | X→O | 1 | O | | O/D | | | 2 | O | O | | O | | O→X | | | | 3 | X | O | | O | O/D | X | | | | O/D | X | X | O/D | X | | X | | | | 2 | 1 | O | X | 3 | | X→O | 1 | O | | 3 | | | 2 | O | O | | O | 3 | O→X | | | | 3 | X | O | | O | 3 | X | | | | L | 1 | O | X | 1 | | X | 1 | O | | 1 | | | 2 | O | O | 2 | | O | | O | | | | |
| Selector lever position | Normal | | | When the solenoid No.1 has broken | | | When the solenoid No.2 has broken | | | When the solenoids No.1 and No.2 have broken | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | Gear | S1 | S2 | Gear | S1 | S2 | Gear | S1 | S2 | Gear | S1 | S2 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| D | 1 | O | X | 3 | | X→O | 1 | O | | O/D | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | O | O | | | O | | O→X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | X | O | | | O | O/D | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | O/D | X | X | | O/D | X | | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 2 | 1 | O | X | 3 | | X→O | 1 | O | | 3 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | O | O | | | O | 3 | O→X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 3 | X | O | | | O | 3 | X | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| L | 1 | O | X | 1 | | X | 1 | O | | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| | 2 | O | O | 2 | | O | | O | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

A/T-ECU TERMINAL VOLTAGE REFERENCE CHART

| Terminal No. | Inspection item | Inspection conditions | Standard value |
|--------------|------------------------------------|--|------------------------------------|
| 1 | Shift control solenoid valve No. 1 | When in 1st or 2nd gear | System voltage |
| | | When in 3rd or 4th gear | 0 V |
| 2 | Shift control solenoid valve No. 2 | When in 2nd or 3rd gear | System voltage |
| | | When in 1st or 4th gear | 0 V |
| 3 | Lock-up solenoid | When lock-up clutch is operating | System voltage |
| | | When lock-up clutch is not operating | 0 V |
| 4 | A/T speed sensor Earth side | Ignition switch: OFF | 0V |
| | | Ignition switch: ON | 2.5 V |
| 5 | Inhibitor switch (N) | Selector lever position: N | System voltage |
| | | Selector lever position: Other than N | 0 V |
| 6 | Diagnostic output terminal | When MUT-II is not connected | System voltage |
| 7 | HOLD mode signal | When HOLD mode is selected | System voltage |
| | | When mode other than HOLD mode is selected | 0 V |
| 8 | Overdrive switch | Overdrive switch: ON (OD) | 0 V |
| | | Overdrive switch: OFF (OD-OFF) | System voltage |
| 9 | Vehicle speed sensor | Vehicle: Slowly moving forward | Alternates between 0 → approx. 5 V |
| 10 | A/T speed sensor output side | Vehicle: Stopped | Approx. 2.5 V |
| | | Vehicle: Driving | Other than 2.5 V |
| 11 | Cruise control signal | When cruise control is requested | 0 V |
| | | When cruise control is not requested | System voltage |
| 12 | Oil temperature sensor | ATF temperature: 120°C (248°F) | Approx. 1.9 V |
| | | ATF temperature: 150°C (302°F) | Approx. 1.1 V |
| 13 | Self-diagnosis control terminal | — | — |
| 14 | Power supply | Ignition switch: ON | System voltage |
| | | Ignition switch: OFF | 0 V |
| 15 | Backup power supply | Ignition switch: OFF | System voltage |
| 16 | Earth | Engine: Idling | 0 V |
| 17 | Stop lamp switch | When brake pedal is depressed | 0 V |
| | | When brake pedal is released | System voltage |
| 18 | Inhibitor switch (2) | Selector lever position: 2 | System voltage |
| | | Selector lever position: Other than 2 | 0 V |

AUTOMATIC TRANSMISSION – Troubleshooting <V4AW3> 23-35-36

| Terminal No. | Inspection item | Inspection conditions | Standard value |
|--------------|---|---|----------------|
| 19 | Inhibitor switch (L) | Selector lever position: L | System voltage |
| | | Selector lever position: Other than L | 0 V |
| 20 | Oil temperature warning lamp | When normal | 0 V |
| | | Ignition switch: For 5 seconds after turning ON | System voltage |
| 21 | Power mode signal | When POWER mode is selected | System voltage |
| | | When mode other than POWER mode is selected | 0 V |
| 22 | — | — | — |
| 23 | — | — | — |
| 24 | Engine coolant temperature signal | When engine coolant temperature is 30°C (86°F) | System voltage |
| | | When engine coolant temperature is 80°C (176°F) | 0 V |
| 25 | Wide open throttle switch | Accelerator pedal: Fully closed | System voltage |
| | | Accelerator pedal: Fully open | 0 V |
| 26 | Throttle position sensor <Petrol powered vehicles> | Accelerator pedal: Fully closed | 0.3–1.0 V |
| | | Accelerator pedal: Fully open | 4.4–5.0 V |
| | Lever position sensor <Diesel powered vehicles> | Accelerator pedal: Fully closed | 0.6–1.3 V |
| | | Accelerator pedal: Fully open | 4.3–5.0 V |

SERVICE ADJUSTMENT PROCEDURES

AUTOMATIC TRANSMISSION FLUID INSPECTION

- (1) Place the vehicle on a level surface.
- (2) Before removing the dipstick, wipe all dirt from area around the dipstick.
- (3) With the selector lever in the "P" position and the parking brake applied, start the engine.
- (4) The engine should be running at idle and the transmission should be warmed up sufficiently. [fluid temperature 70–80°C (158–176°F)]
- (5) Move the selector lever through all positions to fill the torque converter and hydraulic circuit with fluid. Then place the lever in the "N" position.
- (6) Check that fluid level is at oil level gauge "HOT". If fluid level is low, add fluid to "HOT" level.

Transmission fluid: DIA QUEEN ATF-SP or equivalent

NOTE



Low fluid level can allow the oil pump to take in air together with fluid, leading to various troubles. Air trapped in hydraulic circuit forms bubbles which make the fluid spongy. This lowers pressure and slows down pressure buildup. If the transmission has too much fluid, gears churn up foam and cause same conditions as when the fluid level is low, resulting in premature deterioration of ATF. In either case, air bubbles can cause overheating and fluid oxidation and varnishing, which can interfere with normal valve, clutch and servo operation. Foaming can also result in fluid escaping from the transmission vent where it may be mistaken for a fluid leak.

- (7) Check fluid condition.

NOTE

When fluid smells burned, it is contaminated with metal bushing or friction material particles and hence a complete overhaul of the transmission is needed. Be sure to examine fluid on the dipstick closely.

- (8) After fluid has been checked, insert the dipstick until it is seated fully to seal out water and dirt.





AUTOMATIC TRANSMISSION FLUID CHANGE

Caution


If ATF change is required due to damage to the transmission, be sure to clean the cooler system.

- (1) Raise the vehicle on hoist. Place a drain container with large opening under the drain plug (located in bottom of the oil pan).
- (2) Remove the drain plug to let ATF drain.
- (3) Install the drain plug and new gasket and tighten to 21 Nm (2.1 kgm, 15 ft.lbs.).
- (4) Refill ATF through the oil level gauge hole until its level reached at COLD lower limit of the level gauge.
- (5) Start the engine and allow to idle for at least two minutes. Then, with the parking brake and service brake applied, move the selector lever through all positions and finally place in the "N" or "P" position.
- (6) After the transmission is warmed up to the normal operating temperature, recheck the fluid level, which must be between the HOT upper limit and HOT lower limit marks.
- (7) Insert the dipstick fully to prevent dirt from entering the transmission.



TRANSFER OIL INSPECTION AND CHANGE

Refer to GROUP 22 – Service Adjustment Procedures.



THROTTLE CABLE CHECK AND ADJUSTMENT


<3000, 3500>

- (1) Check for defective or bent throttle lever or throttle cable bracket.
- (2) With the accelerator depressed, check to be sure that the distance between the inner cable stopper and dust cover surface is within the standard value.

Standard value: 0 – 1 mm (0 – 0.0394 in.)

- (3) If outside the standard value, adjust with adjusting nut.

23-35-39 AUTOMATIC TRANSMISSION – Service Adjustment Procedures



<2500D, 2800D>


- (1) Check for defective or bent throttle lever or throttle cable bracket.
- (2) Remove outer cable side of boot to expose inner cable stopper.
- (3) Pull throttle lever to fully open throttle valve and check that the distance between the inner cable stopper and outer cable ends is within the standard value.

Standard value: 34-35 mm (1.3386-1.3780 in.)


- (4) If outside the standard value, adjust with adjusting nut.

ELC-4A/T CONTROL COMPONENT LOCATION <V4AW3>

| Name | Symbol | Name | Symbol |
|---|--------|-----------------------------------|--------|
| Throttle position sensor <3000–24V, 3500> | A | Stop lamp switch | H |
| Lever position sensor <2800D> | B | Engine coolant temperature switch | I |
| Inhibitor switch | C | Oil temperature sensor | J |
| A/T-speed sensor | D | Solenoid valves | K |
| Vehicle-speed sensor | E | A/T-ECU | L |
| Overdrive switch | F | Diagnosis connector | M |
| Pattern select switch | G | Wide open throttle switch | N |





















7FU1480



7FU1534

23-35-41 AUTOMATIC TRANSMISSION – Service Adjustment Procedures






V4AW3 CONTROL COMPONENT INSPECTION
THROTTLE POSITION SENSOR <3000–24V, 3500>

Refer to GROUP 13 – Service Adjustment Procedures.

LEVER POSITION SENSOR <2800D>

Refer to GROUP 13 – Service Adjustment Procedures.



A/T-SPEED SENSOR

- (1) Disconnect the sensor connector.
- (2) Measure resistance value between terminal ③ and ④.

Standard value: $620 \pm 60 \Omega$ [at 20°C (68°F)]


- (3) If outside the standard value, replace the sensor.

VEHICLE-SPEED SENSOR

Refer to GROUP 54 – Service Adjustment Procedures.

STOP LAMP SWITCH

Refer to GROUP 35 – Service Adjustment Procedures.




ENGINE COOLANT TEMPERATURE SWITCH

- (1) Disconnect the switch connector.
- (2) Check continuity between the terminal and the thread part.

Standard value:

| | |
|-----------------|---------------|
| Oil temperature | Continuity |
| 30°C (86°F) | No continuity |
| 60°C (140°F) | Continuity |

- (3) If outside the standard value, replace the switch.



OIL TEMPERATURE SENSOR

- (1) Disconnect the sensor connector.
- (2) Measure resistance value between terminal ① and ②.

Standard value:

| Oil temperature | Resistance value |
|-----------------|------------------|
| 25°C (77°F) | 10 kΩ |
| 120°C (248°F) | 615 Ω |


- (3) If outside the standard value, replace the sensor.

SHIFT CONTROL SOLENOID VALVE NO. 1

- (1) Disconnect the solenoid connector.
- (2) Measure resistance value between the terminal ⑤ and earth.

Standard value: $13 \pm 2 \Omega$ [at 25°C (77°F)]

- (3) If outside the standard value, replace the solenoid assembly.




SHIFT CONTROL SOLENOID VALVE NO. 2

- (1) Disconnect the solenoid connector.
- (2) Measure resistance value between the terminal ⑥ and earth.

Standard value: $13 \pm 2 \Omega$ [at 25°C (77°F)]

- (3) If outside the standard value, replace the solenoid assembly.




LOCK-UP SOLENOID

- (1) Disconnect the solenoid connector.
- (2) Measure resistance value between the terminal ⑦ and earth.

Standard value: $13 \pm 2 \Omega$ [at 25°C (77°F)]

- (3) If outside the standard value, replace the solenoid assembly.



CONVERTER STALL TEST

In this test, the engine maximum speed when the torque converter stalls with the shift lever in the "D" or "R" range is measured to check operation of the torque converter, starter and one-way clutch and check hiding performance of the transmission clutch (including brake).

Caution

Do not stand in front or at rear of the vehicle during this test.

- (1) Check the transmission fluid level. The fluid temperature should be at the level after normal operation [70–80°C (158–176°F)]. The engine coolant temperature should also be at the level after normal operation [80–90°C (176–194°F)].
- (2) Apply chocks to the rear wheels (right and left).

- (3) Mount an engine tachometer.
- (4) Apply fully the parking and service brakes.
- (5) Start the engine.
- (6) With the selector lever in the "D" range, fully depress the accelerator pedal and read off the engine maximum speed.

Standard value: 2,100–2,400 r/min. <V4AW2>
2,100–2,600 r/min. <V4AW3>

NOTE

When doing so, do not keep the engine running with throttle full open for more than necessary duration (5 seconds or more). If two or more stall tests are needed, place the selector lever in the "N" position and run the engine at about 1,000 r/min to allow the transmission fluid to cool before another stall test.

- (7) Place the selector lever in the "R" range and perform the test as above.




JUDGEMENT OF STALL TEST RESULTS

<V4AW2>

| | |
|---|---|
| Stall speed in "D" and "R" range is equal to each other but lower than the nominal value. | (1) Engine output is low (2) Starter one-way clutch is faulty. (Faulty torque converter is suspected if it is lower than nominal by more than 600 r/min.) |
| Stall speed in "D" range is higher than nominal. | (1) O.D. clutch slipping. (2) O.D. one-way clutch faulty (3) Forward clutch slipping (4) One-way clutch No. 2 faulty (5) Low line pressure |
| Stall speed in "R" range is higher than nominal. | (1) O.D. clutch slipping. (2) O.D. one-way clutch faulty (3) Direct clutch slipping (4) Brake No. 3 slipping (5) Low line pressure |

<V4AW3>

| | |
|--|---|
| Stall speeds in each range are equal to each other but are lower than the standard value. | (1) Throttle valve is not fully open (2) Insufficient engine output (3) Malfunction of stator one-way clutch (Malfunction of torque converter could be the problem if the stall speed is lower than the standard value by 600 r/min or more) |
| Stall speeds in each range are equal to each other but are higher than the standard value. | (1) Low line pressure (2) Fluid level is not at standard level (insufficient fluid) (3) Malfunction of O.D. one-way clutch |
| Stall speed in D range is higher than the standard value | (1) Forward clutch slippage (2) Malfunction of O.D. one-way clutch (3) Malfunction of one-way clutch No. 2 (4) Low line pressure |
| Stall speed in R range is higher than the standard value | (1) Direct clutch slippage (2) 1st & reverse brake slippage (3) Low line pressure (4) Malfunction of O.D. one-way clutch |



HYDRAULIC PRESSURE TEST

The hydraulic pressure tests (governor pressure and line pressure tests) are important in determining the causes of transmission failures. Before conducting these tests, fluid level and condition and throttle cable adjustment, etc. must be checked for defects or abnormalities. When conducting the tests, the engine and transmission should be at correct operating temperatures, [engine coolant 80–90°C (176–194°F), transmission fluid 70–80°C (158–176°F)].

GOVERNOR PRESSURE TEST <V4AW2 only>

- (1) Place vehicle on a chassis dynamometer.
- (2) Remove plug from governor pressure take off port.
- (3) Install special tool as shown in figure and place the meter inside vehicles.
- (4) Apply parking brake.
- (5) Start engine.
- (6) Release parking brakes.
- (7) Shift to D and measure governor pressure at each output shaft r/min.

Standard value:

<V4AW2-3-Q>

| Output shaft speed (r/min) | Governor pressure kPa (kg/cm ² , psi) |
|----------------------------|--|
| 1,000 | 110–140 (1.1–1.4, 15.6–19.9) |
| 2,000 | 220–240 (2.2–2.4, 31.3–34.1) |
| 3,200 | 410–470 (4.1–4.7, 58.3–66.8) |



<V4AW2-3-L>

| Output shaft speed (r/min) | Governor pressure kPa (kg/cm ² , psi) |
|----------------------------|--|
| 1,000 | 140–170 (1.4–1.7, 19.9–24.2) |
| 2,000 | 250–290 (2.5–2.9, 35.6–41.2) |
| 3,200 | 410–470 (4.1–4.7, 58.3–66.8) |

JUDGEMENT BY GOVERNOR PRESSURE

Governor pressure is not within the standard value

- Line pressure malfunction
- Oil leak in governor circuit
- Governor malfunction



LINE PRESSURE TEST

- (1) Place the vehicle on a chassis dynamometer.
- (2) Remove the plug from the line pressure take off port.
- (3) Install special tool as shown in the figure and place the meter inside vehicle.
- (4) Apply the parking brake.
- (5) Start the engine.
- (6) Place the selector lever in the "D" range.
- (7) Depress the brake pedal firmly by the left foot and operates the accelerator pedal by the right foot to measure the line pressure at each engine rpm. If the measured pressure is not nominal, check adjustment of the throttle cable and readjust if necessary before conducting the test again.
- (8) Place the selector lever in the "R" range and test as above. When measuring the hydraulic pressure for reverse, change the oil-pressure gauge to 3,000 kPa (30 kg/cm², 427 psi).

Standard value:

<V4AW2-2500D>

| Items | Line pressure kPa (kg/cm ² , psi) | |
|----------|--|-------------------------------------|
| | "D" range | "R" range |
| At idle | 450-510 (4.5-5.1, 64-72.5) | 620-700 (6.2-7.0, 88.2-99.5) |
| At stall | 1,120-1,320 (1.12-13.2, 159.3-187.7) | 1,500-1,900 (15-19, 213.3-270.2) |

<V4AW2-3000-12V>

| Items | Line pressure kPa (kg/cm ² , psi) | |
|----------|--|---------------------------------|
| | "D" range | "R" range |
| At idle | 520-600 (5.2-6.0, 74-85) | 790-910 (7.9-9.1, 112-129) |
| At stall | 1,100-1,300 (11-13, 156-185) | 1,600-2,000 (16-20, 228-284) |

<V4AW3-3000-24V, 3500>

| Items | Line pressure kPa (kg/cm ² , psi) | |
|----------|--|-------------------------------------|
| | "D" range | "R" range |
| At idle | 430-490 (4.3-4.9, 61-70) | 520-620 (5.2-6.2, 74-88) |
| At stall | 1,140-1,390 (11.4-13.9, 162-198) | 1,400-1,750 (14.0-17.5, 199-249) |

<V4AW3-2800D>


| Items | Line pressure kPa (kg/cm ² , psi) | |
|----------|--|-------------------------------------|
| | "D" range | "R" range |
| At idle | 430-490 (4.3-4.9, 61-70) | 530-630 (5.3-6.3, 75-90) |
| At stall | 1,350-1,600 (13.5-16.0, 192-228) | 1,670-2,020 (16.7-20.2, 238-287) |

JUDGEMENT BY LINE PRESSURE**<V4AW2>**

| | |
|--|---|
| Hydraulic pressure higher than nominal in all ranges | (1) Regulator valve faulty (2) Throttle valve faulty (3) Throttle control cable incorrectly adjusted |
| Hydraulic pressure lower than nominal in all ranges | (1) Oil pump faulty (2) Regulator valve faulty (3) Throttle valve faulty (4) Throttle control cable incorrectly adjusted (5) O.D. clutch faulty |
| Hydraulic pressure lower than nominal in "D" range | (1) Large fluid leaks in "D" range hydraulic circuit (2) Forward clutch faulty (3) O.D. clutch faulty |
| Hydraulic pressure lower than nominal in "R" range | (1) Large fluid leaks in "R" range hydraulic circuit (2) Brake No. 3 faulty (3) Direct clutch faulty (4) O.D. clutch faulty |

<V4AW3>

| | |
|--|--|
| Hydraulic pressure in all ranges is higher than the standard value | (1) Malfunction of regulator valve (2) Malfunction of throttle valve (3) Incorrect throttle cable adjustment |
| Hydraulic pressure in all ranges is lower than the standard value | (1) Malfunction of oil pump (2) Malfunction of regulator valve (3) Malfunction of throttle valve (4) Incorrect throttle cable adjustment (5) Malfunction of O.D. direct clutch |
| Hydraulic pressure in D range is lower than the standard value | (1) Large fluid leaks in D range hydraulic circuit (2) Malfunction of forward clutch (3) Malfunction of O.D. direct clutch |
| Hydraulic pressure in R range is lower than the standard value | (1) Large fluid leaks in R range hydraulic circuit (2) Malfunction of 1st & reverse brake (3) Malfunction of direct clutch (4) Malfunction of O.D. direct clutch |




CENTRE DIFFERENTIAL LOCK DETECTION SWITCH CHECK

E22FFAA

Check the continuity between the brown connector terminal on the side of the transfer case and the transfer case.

| Transfer control lever position | Continuity |
|---------------------------------|---------------|
| 4H | No continuity |
| 4HLc | Continuity |




2WD/4WD DETECTION SWITCH CHECK

E22FGAA

Check the continuity between the black connector terminal on the side of the transfer case and the transfer case.

| Transfer control lever position | Continuity |
|---------------------------------|---------------|
| 2H | Continuity |
| 4H | No continuity |




CENTRE DIFFERENTIAL LOCK OPERATION DETECTION SWITCH CHECK

E22FHAA

Check the continuity between the brown connector terminal on the top of the transfer case and the transfer case.

| Transfer control lever position | Continuity |
|---------------------------------|---------------|
| 4H | No continuity |
| 4HLc | Continuity |




4WD OPERATION DETECTION SWITCH CHECK

E22FIAA

Check the continuity between the black connector terminal on the top of the transfer case and the transfer case.

| Transfer control lever position | Continuity |
|---------------------------------|---------------|
| 2H | No continuity |
| 4H | Continuity |




HI/LO DETECTION SWITCH CHECK

E22FJAA

Check the continuity between the white connector terminal on the side of the transfer case and the transfer case.

| Transfer control lever position | Continuity |
|---------------------------------|---------------|
| 4HLc | Continuity |
| N (between 4HLc and 4LLc) | No continuity |
| 4LLc | Continuity |




INHIBITOR SWITCH CHECK

E23FYAA

<V4AW2>

| Item | Terminal No. | | | | | | | | |
|------|--------------|---|---|---|---|---|---|---|----|
| | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 9 | 12 |
| P | | | | | | ○ | ○ | ○ | ○ |
| R | | | | | ○ | ○ | ○ | ○ | |
| N | | | | ○ | ○ | ○ | ○ | ○ | ○ |
| D | | | ○ | ○ | ○ | ○ | ○ | ○ | |
| 2 | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| L | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |




<V4AW3>

| Item | Terminal No. | | | | | | | | | |
|------|--------------|---|---|---|---|---|---|---|----|--|
| | 1 | 2 | 3 | 5 | 6 | 7 | 8 | 9 | 10 | |
| P | ○ | | | ○ | ○ | | | | ○ | |
| R | ○ | | | | | | | ○ | | |
| N | ○ | | | ○ | ○ | ○ | | | | |
| D | ○ | | | | | | ○ | | | |
| 2 | ○ | | ○ | | | | | | | |
| L | ○ | ○ | | | | | | | | |

NOTE


○—○ indicate that there is a continuity between the terminals.



SELECTOR LEVER OPERATION CHECK

E23FOAB

1. Shift selector lever to each range and check that lever moves smoothly and is controlled. Check that position indicator is correct.
2. Check to be sure the selector lever can be shifted to each position (by button operation as shown in the illustration).
3. Start the engine and check if the vehicle moves forward when the selector lever is shifted from N to D, and moves backward when shifted to R.
4. When the shift lever malfunctions, adjust control cable and selector lever sleeve. Check for worn shift lever assembly sliding parts.




ADJUSTMENT OF INHIBITOR SWITCH AND CONTROL CABLE


E23FOAH

INHIBITOR SWITCH

- (1) Move the selector lever to the "N" position.
- (2) Loosen the adjusting nut of the control cable.



- (3) Loosen the inhibitor switch mounting bolt.
- (4) Adjust by turning the inhibitor switch so that the bosses for aligning the "N" position on the inhibitor switch are aligned with the "N" position adjustment lever.
- (5) Tighten the inhibitor switch mounting bolt to the specified torque.



- (6) Gently pull the end of the transmission control cable in the direction of the arrow and tighten the adjusting nut to the specified torque.
- (7) Check that the selector lever is in the "N" position.
- (8) Check that each range on the transmission side operates and functions correctly for each position of the selector lever.

CONTROL CABLE

Whether control cable is properly adjusted can be confirmed by checking whether inhibitor switch is performing well.

1. Apply parking brakes and service brakes securely.
2. Place selector lever to "R" range.
3. Set ignition key to "ST" position.
4. Slowly move the selector lever upward until it clicks as it fits in notch of "P" range. If starter motor operates when lever makes a click, "P" position is correct.
5. Then slowly move selector lever to "N" range by the same procedure as in foregoing paragraph. If starter motor operates when selector lever fits in "N", "N" position is correct.
6. Also check to be sure the vehicle doesn't begin to move and the lever doesn't stop between P-R-N-D.
7. The control cable is properly adjusted if, as described above, the starter motor starts at both the "P" range and the "N" range.

4WD INDICATOR CONTROL UNIT CHECK


E23FKAA

Refer to GROUP 22–Service Adjustment Procedures.

SPEEDOMETER CABLE REPLACEMENT

E23FPAD

Refer to GROUP 22–Service Adjustment Procedures.



**TRANSFER OIL SEALS REPLACEMENT**

E22FAAF

1. Disconnect the propeller shaft from the transfer. (Refer to GROUP 25–Propeller Shaft.)
2. Using a flat-tip (–) screwdriver, remove the oil seal.
3. Using the special tool, tap the transfer oil seal into the transfer. Note in illustration the direction of installation of transfer oil seal.
4. Apply a coating of the transmission oil to the lip of the oil seal.

Transmission oil:

Hypoid gear oil API GL-4, SAE 75W-90 or 75W-85W



AUTOMATIC TRANSMISSION FLUID TEMPERATURE SWITCH CHECK


1. Remove the automatic transmission fluid temperature switch from the automatic transmission.

Caution

Use care to prevent foreign subject from entering the automatic transmission fluid temperature switch mounting hole.

2. Immerse the automatic transmission fluid temperature switch in fluid up to the threaded portion as shown in the illustration.
3. Use a circuit tester or the like to check continuity when oil temperature changes. The switch is judged good if the conditions are in the following ranges.

| Item | Temperature °C (°F) |
|---|---------------------|
| Continuity is present (temperature at point A) | 143–151 (289–304) |
| No continuity is present (temperature at point B) | 125 (257) or less |



4. Apply recommended sealant sparingly to the thread of automatic transmission fluid temperature switch. (Models not equipped with O-ring in the sensor mounting hole)

Specified sealant: 3M ATD Part No. 8660 or equivalent

5. Install the automatic transmission fluid temperature switch. **Tightening torque: 30 Nm (3.0 kgm, 22 ft.lbs.)**
6. Check automatic transmission fluid for quantity.

NOTES

cardiagn.com

TRANSMISSION CONTROL


E231A--

REMOVAL AND INSTALLATION

<L.H. drive vehicles>

Pre-removal and Post-installation Operation

- Removal and Installation of Front Console Assembly (Refer to GROUP 52–Floor Console.)



Selector lever assembly removal steps

1. Connection for transmission control cable assembly (selector lever assembly side)
2. Selector lever assembly

Transmission control removal steps

1. Connection for transmission control cable assembly (selector lever assembly side)
3. Transfer case protector
4. Connection for transmission control cable assembly (transmission side)

5. Upper lever

6. Transmission control cable assembly

7. Cable bracket

8. Cable end bracket



Transfer control lever assembly removal steps

9. Retainer
10. Control lever boot
11. Transfer control lever assembly
12. Gasket
13. Stopper plate
14. Gasket
15. Transfer control lever

<R.H. drive vehicles>

Pre-removal and Post-installation Operation

- Removal and Installation of Front Console Assembly (Refer to GROUP 52–Floor Consoles.)



09E0065

Selector lever assembly removal steps

- ◆◆ 1. Connection for transmission control cable assembly (selector lever assembly side)
2. Selector lever assembly

Transmission control removal steps

- ◆◆ 1. Connection for transmission control cable assembly (selector lever assembly side)
3. Transfer case protector
4. Connection for transmission control cable assembly (transmission side)

5. Upper lever
6. Transmission control cable assembly
7. Cable bracket
8. Cable end bracket

Transfer control lever assembly removal steps

9. Retainer
10. Control lever boot
11. Transfer control lever assembly
12. Gasket
13. Stopper plate
14. Gasket
15. Transfer control lever

SERVICE POINTS OF REMOVAL

E23IBAE


11. REMOVAL OF TRANSFER CONTROL LEVER ASSEMBLY

When removing the transfer control lever assembly, move the transfer control lever to the 2H (2 wheel drive-high range) position.

INSPECTION

E23ICAJ

- Check the transmission control cable assembly for function and for damage.


**SERVICE POINTS OF INSTALLATION**

E23IDAK

11. INSTALLATION OF TRANSFER CONTROL LEVER ASSEMBLY

- (1) Remove the adhesive sticking to the transfer control lever assembly mounting bolts.
- (2) Use a tap (M8 × 1.25) to remove the adhesive sticking to the transfer control lever assembly installation holes.
- (3) Check to be sure that the return spring is set to the spring stopper of the 2-4WD shift lug, and then install the control lever in the position shown by the arrow (←).
- (4) Apply specified adhesive to the threads of the lever assembly mounting bolts, and then tighten the transfer control lever.

Specified adhesive: 3M Stud Locking No. 4710 or equivalent

**1. INSTALLATION OF TRANSMISSION CONTROL CABLE ASSEMBLY (SELECTOR LEVER ASSEMBLY SIDE)**




After installing the transmission control cable, adjust it by the following procedure.

- (1) Move the selector lever to the "N" position.
- (2) Loosen the adjusting nut, gently pull the end of the transmission control cable in the direction of the arrow and then tighten the adjusting nut.


SELECTOR LEVER ASSEMBLY DISASSEMBLY AND REASSEMBLY

E23NA--

<L.H. drive vehicles>



<R.H. drive vehicles>





Removal steps

- 1. Overdrive switch/position lamp switch connector case
- 2. Selector knob
- 3. Push button
- 4. Spring
- 5. Overdrive switch
- 6. Knob cover
- 7. Guide
- 8. Upper panel
- 9. Slider
- 10. Lower panel
- 11. Position indicator lamp assembly
- 12. Sleeve
- 13. Bolt
- 14. Selector lever assembly
- 15. Bushing
- 16. Pipe
- 17. Pin
- 18. Spring
- 19. Support
- 20. Steel ball
- 21. Bracket assembly
- 22. Pattern select switch
- 23. Wide open throttle switch } <V4AW3>

<L.H. drive vehicles>

<R.H. drive vehicles>






SERVICE POINTS OF DISASSEMBLY

E23NBAB


1. REMOVAL OF OVERDRIVE SWITCH/POSITION LAMP CONNECTOR CASE

Use a minus screwdriver or similar to remove the overdrive switch/position lamp connector case from the terminal.



2. REMOVAL OF SELECTOR KNOB

- (1) Press the knob cover downwards.
- (2) Remove the front and back mounting screws and remove the selector knob from the selector lever.



5. REMOVAL OF OVERDRIVE SWITCH

Use a minus screwdriver or similar to remove the overdrive switch.

INSPECTION

E23NCAB

- Check the detent plate for wear.
- Check the bushing for wear or damage.
- Check the spring for damage or deterioration.



OVERDRIVE SWITCH

Check for continuity between terminals when the switch is OFF and when ON.

| Terminal | 3 | 4 | 5 |
|-----------------|---|---|---|
| Switch position | | | |
| OD ON | ○ | | ○ |
| OD OFF | ○ | ○ | |

NOTE

○—○ Indicate that there is continuity between the terminals.




PATTERN SELECT SWITCH <V4AW3>

| Terminal | 1 | 2 | 6 | 4 | 7 |
|-----------------|---|---|---|---|---|
| Switch position | | | | | |
| HOLD | ○ | ○ | | | |
| POWER | ○ | | ○ | ○ | ○ |

NOTE

○—○ indicates that there is continuity between the terminals.




WIDE OPEN THROTTLE SWITCH

Check for continuity between terminals when the switch is off and when ON.

| | 1 | 2 |
|-----|---|---|
| ON | | |
| OFF | | |

NOTE
○—○ indicates that there is continuity between the terminals.



SERVICE POINTS OF REASSEMBLY

E23NDAB

12. INSTALLATION OF SLEEVE

Move the selector lever to the "N" position and adjust the sleeve by turning it so that the distance A between the sleeve and the tip of the lever is at the standard value.

Standard value (A): 18.2–18.9 mm (0.717–0.744 in.)

NOTES

cardiagn.com

TRANSMISSION OIL COOLER, HOSES, PIPES


E23KA--

REMOVAL AND INSTALLATION

<3000, 3500, 2500D>

Pre-removal and Post-installation Operation

- Removal and Installation of Under Cover and Under Skid Plate
- Bleeding and Supplying of the Automatic Transmission Fluid.
(Refer to P. 23-40.)



- ◆◆ 1. Hose A
- ◆◆ 2. Hose B
- ◆◆ 3. Hose C

Feed pipe A, Return pipe A removal steps

- ◆◆ 4. Clamp
- ◆◆ 5. Feed pipe A
- ◆◆ 6. Return pipe A
- 7. Pipe bracket

Oil cooler assembly removal steps

- 8. Radiator grill
- 9. Oil cooler assembly
- 10. Oil cooler bracket (L.H.)
- 11. Oil cooler bracket (R.H.)

Feed pipe B, Return pipe B removal steps

- 8. Radiator grill
- 12. Clamp
- ◆◆ 13. Feed pipe B
- ◆◆ 14. Return pipe B


Hose D, Hose E removal steps

- 8. Radiator grill
- ◆◆ 15. Hose D
- ◆◆ 16. Hose E

INSPECTION

E23KCAD

- Check the hose and pipe for crack, damage and clog.
- Check for rusted or clogged radiator oil cooler.
- Check oil cooler fins for bend, damage, and clogged foreign matter.



SERVICE POINTS OF INSTALLATION

E23KDAC

16. INSTALLATION OF HOSE E/15. HOSE D/14. RETURN PIPE B/13. FEED PIPE B

When connecting hoses to pipes with a stepped part, insert securely as far as the stepped part.

6. INSTALLATION OF RETURN PIPE A/5. FEED PIPE A/4. CLAMP

- (1) Provisionally tighten the return pipe A and feed pipe A flare nuts to the transmission and transfer, and after clamping the pipes with each clamp, fully tighten the flare nuts.

Also, tighten all of the clamps, starting with those that are the closest to the transmission and transfer assembly.

- (2) When connecting the pipes to the hoses, insert securely as far as the stepped part.

3. INSTALLATION OF HOSE C/2. HOSE B/1. HOSE A

When connecting hoses to pipes with a stepped part, insert securely as far as the stepped part.

TRANSMISSION AND TRANSFER ASSEMBLY



E23LA--

REMOVAL AND INSTALLATION

<2500D>


Pre-removal and Post-installation Operation

- Removal and Installation of Transfer Control Lever Assembly. (Refer to P. 23-45, 46.)
- Removal and Installation of Transfer Case Protector
- Removal and Installation of Front Exhaust Pipe
- Draining and Supplying of Automatic Transmission Fluid and Transfer Oil (Refer to P. 23-40 and GROUP 22–Service Adjustment Procedures.)
- Removal and Installation of Front and Rear Propeller Shaft (Refer to GROUP 25–Propeller Shaft.)




Removal steps

1. Intercooler
2. Oil filler pipe
3. O-ring
- ◆◆ 4. Connection for throttle control cable
5. Dust seal guard
- ◆◆ 6. Connection for transmission control cable
7. Connection for speedometer cable
<Vehicles built up to October, 1993>
8. Speed sensor connector
<Vehicles built from November, 1993>
9. HI/LO detection switch connector
10. 4WD operation detection switch connector
11. Center differential lock operation detection switch connector
12. Center differential lock detection switch connector
13. 2WD/4WD detection switch connector
14. Inhibitor switch connector
16. Connection for oil cooler pipe



09E0115

- 17. Starter motor
- 22. Bell housing cover
- 23. Transfer roll stopper
- 24. Transfer mounting bracket
- 25. No. 2 crossmember
- 26. Engine mount rear insulator
- 28. Transfer case protector bracket
- 29. Mass damper
- 30. Torque converter connecting bolt
- 31. Transmission and transfer assembly
- 32. Control housing
- 33. Gasket





| | Nm | kgm | ft.lbs. | O.D. × Length mm (in.) | Bolt identification |
|---|----|-----|---------|------------------------|----------------------------|
| A | 50 | 5.0 | 36 | 10 × 40 (0.4 × 1.6) | <p>D × L</p> <p>09Y512</p> |
| B | 24 | 2.4 | 17 | 8 × 25 (0.3 × 1.0) | |
| C | 50 | 5.0 | 36 | 10 × 65 (0.4 × 2.6) | |
| D | 31 | 3.1 | 22 | 10 × 60 (0.4 × 2.4) | |

<3000-12 VALVE>


Pre-removal and Post-installation Operation

- Removal and Installation of Transfer Control Lever Assembly. (Refer to P. 23-45, 46.)
- Removal and Installation of Transfer Case Protector
- Removal and Installation of Front Exhaust Pipe
- Draining and Supplying of Automatic Transmission Fluid and Transfer Oil (Refer to P. 23-40 and GROUP 22-Service Adjustment Procedures.)
- Removal and Installation of Front and Rear Propeller Shaft (Refer to GROUP 25-Propeller Shaft.)




Removal steps

- Oil filler pipe
- O-ring
- Connection for throttle control cable
- Dust seat guard
- Connection for transmission control cable
- Connection for speedometer cable
<Vehicles built up to October, 1993>
- Speed sensor connector
<Vehicles built from November, 1993>
- HI/LO detection switch connector
- 4WD operation detection switch connector
- Center differential lock operation detection switch connector
- Center differential lock detection switch connector
- 2WD/4WD detection switch connector
- Inhibitor switch connector
- Connection for oil cooler pipe



09E0116

- 17. Starter motor
- 18. Starter cover
- 19. Heat protector
- 20. Transmission stay (L.H.)
- 21. Transmission stay (R.H.)
- 22. Bell housing cover
- 23. Transmission roll stopper
- 24. Transfer mounting bracket
- 25. No. 2 crossmember
- 26. Engine mount rear insulator
- 28. Transfer case protector bracket
- 29. Mass damper
- 30. Torque converter connecting bolt
- 31. Transmission and transfer assembly
- 32. Control housing
- 33. Gasket




| | Nm | kgm | ft.lbs. | O.D. × Length mm (in.) | Bolt identification |
|---|----|-----|---------|------------------------|---------------------|
| A | 75 | 7.5 | 54 | 12 × 40 (0.5 × 1.6) | <p>09Y512</p> |
| B | 90 | 9.0 | 65 | 12 × 55 (0.5 × 2.2) | |
| C | 31 | 3.1 | 22 | 10 × 55 (0.4 × 2.2) | |
| D | 36 | 3.6 | 26 | 10 × 40 (0.4 × 1.6) | |
| E | 75 | 7.5 | 54 | 12 × 35 (0.5 × 1.4) | |
| F | 42 | 4.2 | 31 | 10 × 30 (0.4 × 1.2) | |
| G | 75 | 7.5 | 54 | 12 × 50 (0.5 × 2.0) | |


<3000-24 VALVE, 3500>

Pre-removal and Post-installation Operation

- Removal and Installation of Transfer Control Lever Assembly. (Refer to P. 23-45, 46.)
- Removal and Installation of Transfer Case Protector
- Removal and Installation of Front Exhaust Pipe
- Draining and Supplying of Automatic Transmission Fluid and Transfer Oil (Refer to P. 23-40 and GROUP 22-Service Adjustment Procedures.)
- Removal and Installation of Front and Rear Propeller Shaft (Refer to GROUP 25-Propeller Shaft.)




Fluid: Dia Queen ATF SP, ATF DEXRON II or equivalent




Removal steps

2. Oil filler pipe
3. O-ring
4. Connection for throttle control cable
5. Dust seal guard
6. Connection for transmission control cable
8. Speed sensor connector
9. HI/LO detection switch connector
10. 4WD operation detection switch connector
11. Center differential lock operation detection switch connector
12. Center differential lock detection switch connector
13. 2WD/4WD detection switch connector
14. Inhibitor switch connector
15. Solenoid valve connector
16. Connection for oil cooler pipe



09E0102





- 17. Starter motor
- 18. Starter cover
- 19. Heat protector
- 25. No. 2 crossmember
- 27. Engine rear mount bracket
- 29. Mass damper
- 30. Torque converter connecting bolt
- 31. Transmission and transfer assembly
- 32. Control housing
- 33. Gasket

| | Nm | kgm | ft.lbs. | O.D. × Length mm (in.) | Bolt identification |
|---|----|-----|---------|------------------------|---------------------|
| A | 75 | 7.5 | 54 | 12 × 40 (0.5 × 1.6) | 09Y512 |
| B | 90 | 9.0 | 65 | 12 × 55 (0.5 × 2.2) | |
| C | 31 | 3.1 | 22 | 10 × 55 (0.4 × 2.2) | |
| D | 36 | 3.6 | 26 | 10 × 40 (0.4 × 1.6) | |

<2800D>


Pre-removal and Post-installation Operation

- Removal and Installation of Transfer Control Lever Assembly. (Refer to P. 23-45, 46.)
- Removal and Installation of Transfer Case Protector
- Removal and Installation of Front Exhaust Pipe
- Draining and Supplying of Automatic Transmission Fluid and Transfer Oil (Refer to P. 23-40 and GROUP 22–Service Adjustment Procedures.)
- Removal and Installation of Front and Rear Propeller Shaft (Refer to GROUP 25–Propeller Shaft.)
- Removal and Installation of Inter-cooler (Refer to GROUP 15–Inter-cooler.)





Removal steps

2. Oil filler pipe
3. O-ring
4. Connection for throttle control cable
5. Dust seat guard
6. Connection for transmission control cable
8. Speed sensor connector
9. Hi/LO detection switch connector
10. 4WD operation detection switch connector
11. Center differential lock operation detection switch connector
12. Center differential lock detection switch connector
13. 2WD/4WD detection switch connector
14. Inhibitor switch connector
15. Solenoid valve connector
16. Connection for oil cooler pipe



- 17. Starter motor
- 22. Bell housing cover
- 25. No. 2 crossmember
- 27. Engine rear mount bracket
- 30. Torque converter connecting bolt
- 31. Transmission and transfer assembly
- 32. Control housing
- 33. Gasket





SERVICE POINTS OF REMOVAL

E23LBAK

23. REMOVAL OF TRANSFER ROLL STOPPER

Before removing the transfer roll stopper, support the transmission and transfer assembly with a transmission jack.


30. REMOVAL OF TORQUE CONVERTER CONNECTING BOLT 31. TRANSMISSION AND TRANSFER ASSEMBLY

- (1) Remove the cover from the oil pan upper. <3500>
- (2) Remove the connecting bolts (6 places) while turning the crank shaft.
- (3) Gently lower the rear section of the transmission and transfer assembly to remove the assembly from the engine.

Caution

When removing the transmission and transfer assembly, push the torque converter over to the transmission and transfer assembly side so it does not remain on the engine side.

- (4) Next, tilt the front section of the transmission and transfer assembly downwards and gently lower it, being careful that the rear section of the transfer does not touch the No.4 crossmember.



SERVICE POINTS OF INSTALLATION

E23LDAK

32. INSTALLATION OF CONTROL HOUSING

- (1) Remove the adhesive sticking to the bolts attached to portion (A).
- (2) Use a tap (M8 x 1.25) to remove the adhesive sticking to the screw holes (portion (A)).
- (3) Apply specified adhesive to the threads of the mounting bolts (portion (A)).


Specified adhesive:

3M Stud Locking No. 4710 or equivalent

- (4) The dimensions of the mounting bolts vary according to their mounting locations, so do not confuse them when installing.


| Bolt to be used | O.D. × Length mm (in.) | Bolt identification |
|-----------------|----------------------------------|---------------------|
| A | 8 × 25 (0.3 × 1.0) | |
| B | 8 × 27 (0.3 × 1.1) Reame bolt | |

09Y512



31. INSTALLATION OF TRANSMISSION AND TRANSFER ASSEMBLY


- (1) Align the engine transmission mounting bolt holes with the transmission and transfer assembly as shown in the illustration, and connect the transmission and transfer assembly to the engine.



6. INSTALLATION OF TRANSMISSION CONTROL CABLE ASSEMBLY

After installing the transmission control cable, adjust it by the following procedure.

- (1) Move the selector lever to the "N" position.
- (2) Loosen the adjusting nut, gently pull the end of the transmission control cable in the direction of the arrow and then tighten the adjusting nut to the specified torque.



4. INSTALLATION OF THROTTLE CONTROL CABLE

After installing the throttle control cable, adjust it by the following procedure.

<Diesel powered vehicles>

- (1) Remove the cable from the boot outer cable side until the inner cable stopper can be seen.
- (2) Open the throttle lever completely and adjust the cable with the adjusting nut so that the distance between the inner cable stopper and the outer cable end is at the standard value.

Standard value (A): 34–35 mm (1.34–1.38 in.)

<Petrol powered vehicles>

Open the throttle lever completely and adjust the cable with the adjusting nut so that the distance between the inner cable stopper and the dust cover end is at the standard value.

Standard value (B): 0–1 mm (0–0.04 in.)

