

POWER SUPPLY, GROUND & CIRCUIT ELEMENTS


CONTENTS

POWER SUPPLY ROUTING CIRCUIT	3	GROUND	30	
Schematic	3	Ground Distribution	30	
Wiring Diagram - POWER -	4	MAIN HARNESS	30	
BATTERY POWER SUPPLY - IGNITION SW. IN		ENGINE ROOM HARNESS	33	
ANY POSITION	4	ENGINE CONTROL HARNESS	35	
ACCESSORY POWER SUPPLY - IGNITION SW.		BODY HARNESS	36	
IN "ACC" OR "ON"	9	BODY NO.2 HARNESS	38	
IGNITION POWER SUPPLY - IGNITION SW. IN		HARNESS	39	
"ON" AND/OR "START"	10	Harness Layout	39	
Fuse	16	HOW TO READ HARNESS LAYOUT	39	
Fusible Link	16	OUTLINE	40	
Circuit Breaker	16	MAIN HARNESS	41	
IPDM E/R (INTELLIGENT POWER DISTRIBUTION		ENGINE ROOM HARNESS	43	
MODULE ENGINE ROOM)	17	ENGINE CONTROL HARNESS	46	
System Description	17	BODY HARNESS	48	
SYSTEMS CONTROLLED BY IPDM E/R	17	BODY NO.2 HARNESS	50	
CAN COMMUNICATION LINE CONTROL	17	ROOM LAMP HARNESS	51	
IPDM E/R STATUS CONTROL	18	FRONT DOOR HARNESS	52	
CAN Communication System Description	18	REAR DOOR HARNESS	53	
CAN Communication Unit	18	BACK DOOR HARNESS	54	
Function of Detecting Ignition Relay Malfunction ...	18	Wiring Diagram Codes (Cell Codes)	55	
CONSULT-II	19	ELECTRICAL UNITS LOCATION	58	
CONSULT-II INSPECTION PROCEDURE	19	Electrical Units Location	58	
SELF-DIAG RESULTS	20	ENGINE COMPARTMENT	58	
DATA MONITOR	21	PASSENGER COMPARTMENT	59	
ACTIVE TEST	22	LUGGAGE COMPARTMENT	61	
Auto Active Test	23	HARNESS CONNECTOR	62	
DESCRIPTION	23	Description	62	
OPERATION PROCEDURE	23	HARNESS CONNECTOR (TAB-LOCKING		
INSPECTION IN AUTO ACTIVE TEST MODE...	23	TYPE)	62	
Schematic	25	HARNESS CONNECTOR (SLIDE-LOCKING		
IPDM E/R Terminal Arrangement	26	TYPE)	63	
IPDM E/R Power/Ground Circuit Inspection	27	ELECTRICAL UNITS	64	
Inspection With CONSULT-II (Self-Diagnosis)	28	Terminal Arrangement	64	
Removal and Installation of IPDM E/R	29	SMJ (SUPER MULTIPLE JUNCTION)	66	
REMOVAL	29	Terminal Arrangement	66	
INSTALLATION	29	STANDARDIZED RELAY	67	
		Description	67	
		NORMAL OPEN, NORMAL CLOSED AND		

MIXED TYPE RELAYS	67	FUSE, FUSIBLE LINK AND RELAY BOX	70
TYPE OF STANDARDIZED RELAYS	67	Terminal Arrangement	70
FUSE BLOCK - JUNCTION BOX (J/B)	69		
Terminal Arrangement	69		

PFP-24110

AKS007HF






*: This relay is built into the IPDM E/R (Intelligent power distribution module engine room).

POWER SUPPLY ROUTING CIRCUIT




Wiring Diagram - POWER - BATTERY POWER SUPPLY - IGNITION SW. IN ANY POSITION

AKS007HF







TKWA1742E

POWER SUPPLY ROUTING CIRCUIT





TKWA1743E





POWER SUPPLY ROUTING CIRCUIT

PG-POWER-05





TKWA1746E

POWER SUPPLY ROUTING CIRCUIT

ACCESSORY POWER SUPPLY - IGNITION SW. IN "ACC" OR "ON"

PG-POWER-06



REFER TO THE FOLLOWING.

M1	M2	E101	E103
----	----	------	------

-FUSE BLOCK-JUNCTION BOX (J/B)


1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWA1747E

POWER SUPPLY ROUTING CIRCUIT

IGNITION POWER SUPPLY - IGNITION SW. IN "ON" AND/OR "START"

PG-POWER-07



3	5	1
4	2	6

E117
W


REFER TO THE FOLLOWING.

(M1), (E101), (E104)

-FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22

TKWA1748E



REFER TO THE FOLLOWING.




M1 -FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22



PG-POWER-09

POWER SUPPLY ROUTING CIRCUIT

PG-POWER-10





TKWA1751E



POWER SUPPLY ROUTING CIRCUIT

PG-POWER-12



REFER TO THE FOLLOWING.

M2	E101	E103
----	------	------

- FUSE BLOCK-JUNCTION BOX (J/B)

1	2	3	4	5	6	7	8	9	10	11
12	13	14	15	16	17	18	19	20	21	22


TKWA1753E

POWER SUPPLY ROUTING CIRCUIT

Fuse

AKS007HG

- If fuse is blown, be sure to eliminate cause of incident before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.




Fusible Link

AKS007HH

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:


- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of incident.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker

AKS007HI

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

PFP:284B7

System Description

AKS00A49

- IPDM E/R (Intelligent Power Distribution Module Engine Room) integrates the relay box and fuse block which were originally placed in engine room. It controls integrated relay via IPDM E/R control circuit.
- IPDM E/R-integrated control circuit performs ON-OFF operation of relay, CAN communication control, oil pressure switch signal, hood switch signal reception, etc.
- It controls operation of each electrical part via ECM, BCM and CAN communication lines.

CAUTION:

None of the IPDM E/R-integrated relays can be removed.

SYSTEMS CONTROLLED BY IPDM E/R

1. Lamp control
Using CAN communication line, it receives signal from BCM and controls the following lamps:
 - Headlamps (Hi, Lo)
 - Parking lamps
 - Tail lamps
 - Front fog lamps
2. Wiper control
Using CAN communication line, it receives signals from BCM and controls the front wipers.
3. Rear window defogger relay control
Using CAN communication line, it receives signals from BCM and controls the rear window defogger relay.
4. A/C compressor control
Using CAN communication line, it receives signals from ECM and controls the A/C relay.
5. Cooling fan control
Using CAN communication line, it receives signals from ECM and controls cooling fan relay.
6. Horn control
Using CAN communication line, it receives signals from BCM and controls horn relay.

CAN COMMUNICATION LINE CONTROL

With CAN communication, by connecting each control unit using two communication lines (CAN L line, CAN H line), it is possible to transmit maximum amount of information with minimum wiring. Each control unit can transmit and receive data, and reads necessary information only.

1. Fail-safe control
 - When CAN communication with other control units is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.
 - Operation of control parts by IPDM E/R during fail-safe mode is as follows:

Controlled system	Fail-safe mode
Headlamp	● With the ignition switch ON, the headlamp (low) is ON. ● With the ignition switch OFF, the headlamp (low) is OFF.
Tail and parking lamps	● With the ignition switch ON, the tail and parking lamps is ON. ● With the ignition switch OFF, the tail and parking lamps is OFF.
Cooling fan	● With the ignition switch ON, the cooling fan HI operates. ● With the ignition switch OFF, the cooling fan stops.
Front wiper	Until the ignition switch is turned off, the front wiper LO and HI remains in the same status it was in just before fail-safe control was initiated.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C compressor OFF
Front fog lamps	Front fog lamp relay OFF

IPDM E/R STATUS CONTROL

In order to save power, IPDM E/R switches status by itself based on each operating condition.

1. CAN communication status
 - CAN communication is normally performed with other control units.
 - Individual unit control by IPDM E/R is normally performed.
 - When sleep request signal is received from BCM, mode is switched to sleep waiting status.
2. Sleep waiting status
 - Process to stop CAN communication is activated.
 - All systems controlled by IPDM E/R are stopped. When 1 seconds have elapsed after CAN communication with other control units is stopped, mode switches to sleep status.
3. Sleep status
 - IPDM E/R operates in low current-consumption mode.
 - CAN communication is stopped.
 - When a change in CAN communication line is detected, mode switches to CAN communication status.
 - When a change hood switch or ignition switch signal is detected, mode switches to CAN communication status.

CAN Communication System Description

AKS00A4A

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicles are equipped with many electronic control units and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Unit

AKS00A0H

Refer to [LAN-8, "CAN Communication Unit"](#) .

Function of Detecting Ignition Relay Malfunction

AKS00A4C

- When contact point of integrated ignition relay is stuck and cannot be turned OFF, IPDM E/R turns ON tail and parking lamps for 10 minutes to indicate IPDM E/R malfunction.
- When a state of ignition relay having built-in does not agree with a state of Ignition switch signal input by a CAN communication from BCM, IPDM E/R lets tail lamp relay operate.

Ignition switch signal	Ignition relay status	Tail lamp relay
ON	ON	—
OFF	OFF	—
ON	OFF	—
OFF	ON	ON (10 minutes)

NOTE:

When the ignition switch is turned ON, the tail lamp is OFF.

CONSULT-II

AKS00A4D

CONSULT-II performs the following functions with combination of data receiving, command and transmission using the CAN communication line from the IPDM E/R.


Inspection Item, Diagnosis Mode	Description
SELF-DIAG RESULTS	The IPDM E/R performs diagnosis of the CAN communication and self-diagnosis.
DATA MONITOR	The input/output data of the IPDM E/R is displayed in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.
ACTIVE TEST	The IPDM E/R sends a drive signal to electronic components to check their operation.

CONSULT-II INSPECTION PROCEDURE


CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


1. With the ignition switch OFF, connect CONSULT-II and CONSULT-II CONVERTER to the data link connector, then turn the ignition switch ON.



2. Touch "START (NISSAN BASED VHCL)".




3. Touch "IPDM E/R" on "SELECT SYSTEM" screen.
 - If "IPDM E/R" is not displayed, print "SELECT SYSTEM" screen, then refer to [GI-39, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

4. Select the desired part to be diagnosed on the “SELECT DIAG MODE” screen.



SELF-DIAG RESULTS

Operation Procedure

1. Touch “SELF-DIAG RESULTS” on “SELECT DIAG MODE” screen.
2. Check display content in self-diagnostic results.

Display Item List

Display Items	CONSULT-II display code	Malfunction detecting condition	TIME		Possible causes
			CRNT	PAST	
NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.	-	-	-	-	-
CAN COMM CIRC	U1000	● If CAN communication reception/transmission data has a malfunction, or if any of the control units malfunction, data reception/transmission cannot be confirmed. ● When the data in CAN communication is not received before the specified time	×	×	Any of or several items below have errors. ● TRANSMIT DIAG ● ECM ● BCM/SEC

NOTE:

The details for display of the period are as follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

DATA MONITOR

Operation Procedure

1. Touch "DATA MONITOR" on "SELECT MONITOR ITEM" screen.
2. Touch "ALL SIGNALS", "MAIN SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.

ALL SIGNALS	All items will be monitored.
MAIN SIGNALS	Monitor the predetermined item.
SELECTION FROM MENU	Select any item for monitoring.

3. Touch "START".
4. Touch the required monitoring item on "SELECTION FROM MENU". In "ALL SIGNALS", all items are monitored. In "MAIN SIGNALS", predetermined items are monitored.
5. Touch "RECORD" while monitoring to record the status of the item being monitored. To stop recording, touch "STOP".

All Signals, Main Signals, Selection From Menu

Item name	CONSULT-II screen display	Display or unit	Monitor item selection			Description
			ALL SIGNALS	MAIN SIGNALS	SELECTION FROM MENU	
Motor fan request	MOTOR FAN REQ	1/2/3/4	×	×	×	Signal status input from ECM
Compressor request	AC COMP REQ	ON/OFF	×	×	×	Signal status input from ECM
Tail & clear request	TAIL&CLR REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L LO request	HL LO REQ	ON/OFF	×	×	×	Signal status input from BCM
H/L HI request	HL HI REQ	ON/OFF	×	×	×	Signal status input from BCM
Front fog request	FR FOG REQ	ON/OFF	×	×	×	Signal status input from BCM
Head lamp washer request ^{NOTE}	HL WASHER REQ	ON/OFF	×		×	Signal status input from BCM
Front wiper request	FR WIP REQ	STOP/1LOW/LOW/HI	×	×	×	Signal status input from BCM
Wiper auto stop	WIP AUTO STOP	ACT P/STOP P	×	×	×	Output status of IPDM E/R
Wiper protection	WIP PROT	OFF/Block	×	×	×	Control status of IPDM E/R
Starter request	ST RLY REQ	ON/OFF	×		×	Status of input signal ^{NOTE}
Ignition relay status	IGN RLY	ON/OFF	×	×	×	Ignition relay status monitored with IPDM E/R
Rear window defogger request	RR DEF REQ	ON/OFF	×	×	×	Signal status input from BCM
Oil pressure switch	OIL P SW	OPEN/CLOSE	×		×	Signal status input in IPDM E/R
Day time light request ^{NOTE}	DTRL REQ	ON/OFF	×		×	Signal status input from BCM
Hood switch	HOOD SW	ON/OFF	×		×	Signal status input in IPDM E/R
Theft warning horn request	THFT HRN REQ	ON/OFF	×		×	Signal status input from BCM
Horn chirp	HORN CHIRP	ON/OFF	×		×	Output status of IPDM E/R

NOTE:

- Perform monitoring of IPDM E/R data with the ignition switch ON. When the ignition switch is at ACC, the display may not be correct.
- The head lamp washer request items are displayed, but they cannot be monitored.
- The Day time light request items are displayed, but they cannot be monitored.

ACTIVE TEST

Operation Procedure

1. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
2. Touch item to be tested, and check operation.
3. Touch "START".
4. Touch "STOP" while testing to stop the operation.

Test item	CONSULT-II screen display	Description
Tail lamp output	TAIL LAMP	With a certain ON-OFF operation, the tail lamp relay can be operated.
Rear window defogger output	REAR DEFOGGER	With a certain ON-OFF operation, the rear window defogger relay can be operated.
Front wiper (HI, LO) output	FRONT WIPER	With a certain operation (OFF, HI ON, LO ON), the front wiper relay (Lo, Hi) can be operated.
Cooling fan output	MOTOR FAN	With a certain operation (1,2,3,4), the cooling fan can be operated.
Headlamp washer	HEAD LAMP WASHER	—
Lamp (HI, LO, FOG ^{NOTE}) output	LAMPS	With a certain operation (OFF, HI ON, LO ON, FOG ON ^{NOTE}), the lamp relay (Lo, Hi, Fog ^{NOTE}) can be operated.
Horn output	HORN	Push "ON" button, horn relay operates 20ms.

NOTE:

The headlamp washer items are displayed, but they cannot be tested.

Auto Active Test

AKS00A4E

DESCRIPTION

- In auto active test mode, operation inspection can be performed when IPDM E/R sends a drive signal to the following systems:
 - Rear window defogger
 - Front wipers
 - Tail and parking lamps
 - Front fog lamps
 - Headlamps (Hi, Lo)
 - A/C compressor (magnetic clutch)
 - Cooling fan

OPERATION PROCEDURE

1. Close hood front door RH and lift wiper arms away from windshield (to prevent glass damage by wiper operation).

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield beforehand.

2. Turn ignition switch OFF.
3. Turn ignition switch ON and, within 20 seconds, open and close 10 times of front door LH. Then turn ignition switch OFF.
4. Turn ignition switch ON within 10 seconds after ignition switch OFF.
5. When auto active test mode is actuated, horn chirps once.
6. After a series of operations is repeated three times, auto active test is completed.

NOTE:


When auto active test mode has to be cancelled halfway, turn ignition switch OFF.

CAUTION:

Be sure to inspect **BL-37. "Check Door Switch"** when the auto active test cannot be performed.

INSPECTION IN AUTO ACTIVE TEST MODE

- When auto active test mode is actuated, the following eight steps are repeated three times.



NOTE:

Turns ON-OFF the solenoid to switch Hi/Lo. In this case, the bulb does not illuminate.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Concept of Auto Active Test

- IPDM E/R actuates auto active test mode when it receives door switch signal from BCM via CAN communication line. Therefore, when auto active test mode is activated successfully, CAN communication between IPDM E/R and BCM is normal.
- If any of systems controlled by IPDM E/R cannot be operated, possible cause can be easily diagnosed using auto active test.


Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause	
Any of front wipers, tail and parking lamps, front fog lamps, and head lamps (Hi, Lo) do not operate.	Perform auto active test. Does system in question operate?	YES	● BCM signal input system
		NO	● Lamp/wiper motor malfunction ● Lamp/wiper motor ground circuit malfunction ● Harness/connector malfunction between IPDM E/R and system in question ● IPDM E/R (integrated relay) malfunction
Rear window defogger does not operate.	Perform auto active test. Does rear window defogger operate?	YES	● BCM signal input circuit
		NO	● Rear window defogger relay circuit ● Open circuit of rear window defogger ● IPDM E/R malfunction
A/C compressor does not operate.	Perform auto active test. Does magnetic clutch operate?	YES	● BCM signal input circuit ● CAN communication signal between BCM and ECM. ● CAN communication signal between ECM and IPDM E/R
		NO	● Magnetic clutch malfunction ● Harness/connector malfunction between IPDM E/R and magnetic clutch ● IPDM E/R (integrated relay) malfunction
Cooling fan does not operate.	Perform auto active test. Does cooling fan operate?	YES	● ECM signal input circuit ● CAN communication signal between ECM and IPDM E/R
		NO	● Cooling fan motor malfunction ● Harness/connector malfunction between IPDM E/R and cooling fan motor ● IPDM E/R (integrated relay) malfunction
Oil pressure warning lamp does not operate.	Perform auto active test. Does oil pressure warning lamp blink?	YES	● Harness/connector malfunction between IPDM E/R and oil pressure switch ● Oil pressure switch malfunction ● IPDM E/R malfunction
		NO	● CAN communication signal between BCM and Unified Meter and A/C Amp ● Combination meter

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Schematic


AKS00A4F



TKWA1754E

IPDM E/R Terminal Arrangement

AKS00A4G



CKIA0346E

IPDM E/R Power/Ground Circuit Inspection

AKS00A4H

1. CHECK FUSE AND FUSIBLE LINK

- Make sure the following fusible links or IPDM E/R fuses are not blown.

Terminal No.	Signal name	Fuse, fusible link No.
1, 2, 16	Battery power	F/L-C, F/L-E, F/L-L, Fuse No. 71, 78

OK or NG

- OK >> GO TO 2.
NG >> Replace fuse or fusible link.


2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect IPDM E/R harness connector E3.
- Check voltage between IPDM E/R harness connector E3 terminals 1 (R), 2 (W/L) and ground.

Battery voltage should exist

OK or NG

- OK >> GO TO 3.
NG >> Replace IPDM E/R power supply circuit harness.




3. CHECK GROUND CIRCUIT

- Disconnect IPDM E/R harness connectors E8 and E9.
- Check continuity between IPDM E/R harness connectors E8 terminal 38 (B), E9 terminal 50 (B), 60 (B) and ground.

Continuity should exist

OK or NG

- OK >> INSPECTION END
NG >> Replace ground circuit harness of IPDM E/R.



Inspection With CONSULT-II (Self-Diagnosis)

AKS00A4I

CAUTION:

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.

1. CHECK SELF DIAGNOSTIC RESULT

1. Connect CONSULT-II and select "IPDM E/R" on the Diagnosis System Selection screen.
2. Select "SELF-DIAG RESULTS" on the "SELECT DIAG MODE" screen.
3. Check display content in self diagnostic results.

CONSULT-II display	CONSULT-II display code	TIME		Details of diagnosis result
		CRNT	PAST	
NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	-	-	-	No malfunction
CAN COMM CIRC	U1000	×	×	Any of or several items below have errors. ● TRANSMIT DIAG ● ECM ● BCM/SEC

NOTE:

The Details for Display of the Period Are as Follows:

- CRNT: Error currently detected with IPDM E/R.
- PAST: Error detected in the past and memorized with IPDM E/R.

Contents displayed


NO DTC IS DETECTED.FURTHER TESTING MAY BE REQUIRED.>>INSPECTION END

CAN COMM CIRC>>After print-out of the monitor items, refer to [LAN-6. "Precautions When Using CONSULT-II"](#).

Removal and Installation of IPDM E/R

REMOVAL


1. Remove IPDM E/R cover A and IPDM E/R cover.
2. While spreading pawls on both side of IPDM E/R cover B, remove IPDM E/R from IPDM E/R cover B.
3. Remove harness connector from IPDM E/R.



INSTALLATION

Install in the revers order of removal.

GROUND

Ground Distribution
MAIN HARNESS

CON- NECTOR NUMBER	CONNECT TO
M2	Fuse block (J/B) (Terminal No.7B) • Accessory relay • Blower relay
M17	VDC off switch
M18	Headlamp aiming switch
M20	Automatic drive positioner control unit (Terminal No. 40)
M20	Automatic drive positioner control unit (Terminal No. 48)
M22	Power socket relay
M24	Data link connector (Terminal No. 4)
M24	Data link connector (Terminal No. 5)
M27	Shift lock control unit
M29	Combination switch
M33	Steering angle sensor
M38	Display (With navigation system)
M39	Display unit (Without navigation system)
M42	Display control unit (With navigation system)
M48	A/C and AV switch
M50	Unified meter and A/C amp. (Terminal No. 29)
M50	Unified meter and A/C amp. (Terminal No. 30)
M60	Front power socket (Center console)
M62	NAVI control unit (Terminal No. 1)
M62	NAVI control unit (Terminal No. 4)
M64	Air bag diagnosis sensor unit
M73	Front power socket (Center cluster)
M88	Pedal adjusting control unit
M90	Cigarette lighter socket
M93	Condenser
M96	Option connector for DVD

Next page

GROUND

Preceding page

A B

M12 R1

Room lamp harness

M3 D1

Front door harness
(Driver side)

CON- NECTOR NUMBER	CONNECT TO
R2	Vanity mirror lamp (Driver side)
R3	Map lamp
R4	Auto anti-dazzling inside mirror
R5	Sunroof switch
R6	Sunroof motor assembly
R7	Vanity mirror lamp (Passenger side)
R8	Personal lamp LH
R9	Room lamp
R10	Personal lamp RH
D2	Door mirror (Driver side) (With door mirror defogger)
D3	Seat memory switch
D7	Power window main switch • CPU • Door lock and unlock switch • Power window lock switch • Illumination
D10	Front door lock assembly (Driver side) • Door key cylinder switch • Door switch

CON- NECTOR NUMBER	CONNECT TO
M25	Combination meter (Terminal No.22)
M25	Combination meter (Terminal No.23)
M25	Combination meter (Terminal No.24)
M35	BCM (Body control module) (Terminal No.49)
M35	BCM (Body control module) (Terminal No.52)
M53	Heated seat switch (Passenger side)
M54	Heated seat switch (Driver side)
M55	AWD lock switch
M56	Door mirror remote control switch (Without memory mirror)
M57	CVT device (Terminal No.2) (Without manual mode switch)
M57	CVT device (Terminal No.11) (With manual mode switch)
M58	Coin box illumination
M66	Door mirror remote control switch (With memory mirror)

c D

Next page


A
B
C
D
E
F
G
H
I
J
PG
L
M

CKIA0348E

GROUND

Preceding page

C D



CON- NECTOR NUMBER	CONNECT TO
(M70)	Blower motor
(M75)	Glove box lamp
(M80)	ECM (Terminal No. 115)
(M80)	ECM (Terminal No. 116)
(M81)	Low tire pressure warning control unit
(M91)	Condenser
(M92)	Condenser
(M252)	Mode door motor
(M253)	Air mix door motor (Driver side)
(M254)	Air mix door motor (Passenger side)
(M255)	Intake door motor
(F8)	Camshaft position sensor (PHASE) (Bank 2)
(F20)	Crankshaft position sensor (POS)
(F33)	Shield wire [Electric throttle control actuator (Throttle position sensor)] (For circuit from terminal No. 1)
(F33)	Shield wire [Electric throttle control actuator (Throttle position sensor)] (For circuit from terminal No. 2,4,5)
(F33)	Shield wire [Electric throttle control actuator (Throttle control motor)] (For circuit from terminal No. 3,6)
(F34)	Camshaft position sensor (PHASE) (Bank 1)
(F101)	ECM (Terminal No. 1)
(F104)	TCM (Transmission control module) (Terminal No. 25)
(F104)	TCM (Transmission control module) (Terminal No. 48)
(F242)	Shield wire (Knock sensor)
(D32)	Door mirror (Passenger side) (With door mirror defogger)
(D35)	Front power window switch (Passenger side) • CPU • Doorlock and unlock switch • Illumination
(D38)	Front door lock assembly (Passenger side) • Door switch


* : This sub-harness is not shown in "HARNES LAYOUT".

CKIA0349E

GROUND

ENGINE ROOM HARNESS

○
= Body ground



- (E16) (E91) Engine room sub-harness-1
- (E33) (E93) Engine room sub-harness-2

CON-
NECTOR
NUMBER

CONNECT TO


- (E6) IPDM E/R
(Intelligent power distribution module engine room) (Terminal No. 14)
Cooling fan relay-2
- (E17) Front combination lamp LH (Terminal No. 5)
 - Headlamp
 - Headlamp aiming motor
 - Parking
 - Side marker
- (E17) Front combination lamp LH (Terminal No. 8)
 - Turn signal
- (E21) Brake fluid level switch
- (E22) Front wiper motor
- (E92) Front fog lamp LH
- (E94) Front fog lamp RH

CON-
NECTOR
NUMBER

CONNECT TO

- (E9) IPDM E/R
(Intelligent power distribution module engine room) (Terminal No. 38)
 - CPU
 - Ignitionrelay
 - Front wiper relay
- (E9) IPDM E/R
(Intelligent power distribution module engine room) (Terminal No. 50)
 - CPU
- (E9) IPDM E/R
(Intelligent power distribution module engine room) (Terminal No. 60)
 - CPU
- (E30) Front combination lamp RH (Terminal No. 5)
 - Headlamp
 - Headlamp aiming motor
 - Parking
 - Side marker
- (E30) Front combination lamp RH (Terminal No. 8)
 - Turn signal
- (E32) Washer level sensor
- (E38) Cooling fan motor-1
- (E39) Cooling fan motor-2

○
= Body ground




A
Next
page


CKIA0350E

GROUND

Preceding
Page



CON- NECTOR NUMBER	CONNECTTO
M64	Shield wire (Air bag diagnosis sensor unit)
E24	ABS actuator and electric unit (Control unit) (Terminal No. 16)
E24	ABS actuator and electric unit (Control unit) (Terminal No. 47)




CON- NECTOR NUMBER	CONNECTTO
E35	Alternator (E)

CK1A0280E

GROUND


ENGINE CONTROL HARNESS



A
B
C
D
E
F
G
H
I
J
PG
L
M

GROUND


BODY HARNESS




CKIA0352E

GROUND

Preceding page



CON- NECTOR NUMBER	CONNECTTO
D55	Rear power window switch LH
D56	Rear door lock assembly LH • Door switch
D96	High-mounted stop lamp
D99	Back-up lamp LH
D100	Back door switch
D102	License plate lamp LH
D103	Rear wiper motor
D104	License plate lamp RH
D105	Back-up lamp RH
D107	Rear window defogger (-)




CON- NECTOR NUMBER	CONNECTTO
B11	Shield wire (Air bag diagnosis sensor unit)

CK1A0283E

GROUND

BODY NO.2 HARNESS



*:This sub-harness is not shown in "HARNESS LAYOUT".

CKIA0284E

HARNESS

PFP:00011

Harness Layout

AKS007HK


HOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Engine Control Harness
- Body Harness

To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.



CONNECTOR SYMBOL


Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
• Cavity: Less than 4 • Relay connector				
• Cavity: From 5 to 8				
• Cavity: More than 9				
• Ground terminal etc.	—			


CKIT0108E

HARNESS

OUTLINE




MAIN HARNESS



B4★	(M1)	W/16	: Fuse block (J/B)	E2	(M42)	W/24	: Display control unit (With NAVI)	E2	(M70)	W/6	: Blower motor
B4	(M2)	W/8	: Fuse block (J/B)	E2	(M43)	W/32	: Display control unit (With NAVI)	F2	(M73)	B/2	: Front power socket (Center cluster)
A2	(M3)	SMJ	: To (D1)	G2	(M44)	W/10	: Audio unit	F1	(M74)	Y/4	: Front passenger air bag module
A2	(M4)	Y/4	: To (E107)	E3	(M45)	W/6	: Audio unit	F2	(M75)	W/2	: Glove box lamp
A1★	(M5)	W/2	: To (E108)	E3	(M46)	W/16	: Audio unit	E1	(M77)	BR/2	: Tweeter RH
B4	(M6)	W/24	: To (E109)	G2	(M47)	BR/2	: Antenna amp.	F1★	(M78)	—	: Body ground
A4★	(M7)	GR/16	: To (E110)	G3	(M48)	W/16	: A/C and AV switch	E1	(M79)	B/2	: Sunload sensor
A4	(M8)	BR/12	: To (B1)	F3★	(M49)	GR/20	: Unified meter and A/C amp.	F1★	(M80)	SMJ	: ECM
A3★	(M9)	W/20	: To (B2)	G3★	(M50)	GR/16	: Unified meter and A/C amp.	G2	(M81)	W/24	: Low tire pressure warning
A3★	(M10)	BR/16	: To (B3)	F3	(M51)	W/24	: Unified meter and A/C amp.				
C2	(M11)	W/2	: Tire pressure warning check connector	D2	(M52)	W/2	: In-vehicle sensor				
A1	(M12)	W/8	: To (R1)	F3	(M53)	BR/6	: Heated seat switch (Passenger side)				
A1★	(M14)	—	: Body ground	F3	(M54)	W/6	: Heated seat switch (Driver side)	G2★	(M82)	W/18	: To (F102)
B1	(M15)	BR/2	: Tweeter LH	E3	(M55)	W/6	: AWD lock switch	F1	(M84)	W/6	: To (B101)
A1	(M16)	W/3	: Optical sensor	E3	(M56)	W/10	: Door mirror remote control switch (Without memory mirror)	F1	(M85)	W/18	: To (B102)
B3	(M17)	GR/6	: VDC off switch	E3	(M57)	W/16	: CVT device	G1	(M86)	BR/16	: To (B103)
B3	(M18)	W/4	: Headlamp aiming switch	F4★	(M58)	W/2	: Coin box illumination	G1	(M87)	SMJ	: To (D31)
B1	(M19)	W/32	: Automatic drive positioner control unit	F4	(M59)	BR/2	: CVT illumination	B1	(M88)	W/16	: Pedal adjusting control unit
B1	(M20)	W/16	: Automatic drive positioner control unit	G4	(M60)	B/2	: Front power socket (Center console)	C3	(M89)	W/2	: Circuit breaker
C3	(M21)	L/4	: Back-up lamp relay	D4	(M61)	B/6	: Yaw rate / side / decel G sensor	F4	(M90)	B/2	: Cigarette lighter socket
C2	(M22)	L/4	: Power socket relay	E4	(M62)	W/24	: NAVI control unit	D1★	(M91)	GR/2	: Condenser
B3	(M24)	W/16	: Data link connector	F4	(M63)	GR/24	: NAVI control unit	E1★	(M92)	GR/2	: Condenser
C1★	(M25)	W/24	: Combination meter	G5	(M64)	Y/28	: Air bag diagnosis sensor unit	E1	(M93)	W/2	: Condenser
C3	(M27)	GR/10	: Shift lock control unit	D1	(M65)	W/6	: Heater & cooling unit assembly	G2	(M94)	W/12	: To (B120)
D2	(M28)	W/4	: Key switch and key lock solenoid	E3	(M66)	W/12	: Door mirror remote control switch (With memory mirror)	E3	(M95)	W/12	: Option connector for audio unit
D3	(M29)	W/16	: Combination switch	C3★	(M67)	B/8	: Accelerator pedal position sensor	G4	(M96)	W/3	: Option connector for DVD
D3	(M30)	W/8	: NATS antenna amp.								
D3★	(M31)	GR/8	: Combination switch (Spiral cable)								
D3	(M32)	Y/6	: Combination switch (Spiral cable)								
C3	(M33)	W/8	: Steering angle sensor								
D2	(M34)	W/40	: BCM (Body control module)								
D2	(M35)	B/15	: BCM (Body control module)								
C1	(M36)	W/15	: BCM (Body control module)								
E1	(M38)	W/24	: Display (With NAVI)								
E2	(M39)	W/24	: Display unit (Without NAVI)								
D1	(M40)	W/2	: Ignition keyhole illumination								

★ : Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and CVT sections.

ENGINE ROOM HARNESS
Engine Compartment



TKIA0113E

Engine room sub-harness-1

E4 E91 B/2 : To E16

D4 E92 BR/2 : Front fog lamp LH

Engine room sub-harness-2


A2 E93 B/2 : To E33

A2 E94 BR/2 : Front fog lamp RH

★ : Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the ECM to have diagnostic trouble codes. **Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and CVT sections.**

Engine room	D2	(E1)	BR/2	: Fusible link holder	Engine room
	D2	(E2)	GR/2	: Fusible link holder	
	B1	(E3)	B/2	: IPDM E/R (Intelligent power distribution module)	
	B1	★(E4)	W/4	: IPDM E/R (Intelligent power distribution module)	
	C2	★(E5)	B/4	: IPDM E/R (Intelligent power distribution module)	
	B2	★(E6)	W/6	: IPDM E/R (Intelligent power distribution module)	
	C2	★(E7)	GR/16	: IPDM E/R (Intelligent power distribution module)	
	C2	★(E8)	W/12	: IPDM E/R (Intelligent power distribution module)	
	C2	★(E9)	W/16	: IPDM E/R (Intelligent power distribution module)	
	D2	(E10)	—	: Fuse and fusible link block	
	D2	(E11)	-/3	: Horn relay	
	D3	★(E13)	—	: Body ground	
	D3	(E14)	B/1	: Horn (Low)	
	C3	(E15)	B/2	: Ambient sensor	
	E4	(E16)	B/2	: To (E91)	
	LH	E3	(E17)	GR/8	
F2		★(E18)	GR/9	: To (F2)	
F2		★(E19)	B/8	: To (F3)	
F2		(E20)	L/2	: Front wheel sensor	
E2		(E21)	GR/2	: Brake fluid level switch	
E1		(E22)	GR/6	: Front wiper motor	
E2		(E23)	B/3	: Pressure sensor	
C1		(E24)	B/47	: ABS actuator and electric unit	
C2		(E26)	—	: Body ground	
C2		(E27)	GR/2	: Front wheel sensor	
A1		★(E28)	—	: Body ground	
A1		(E29)	—	: Body ground	
A1		(E30)	GR/8	: Front combination lamp	
A3		(E31)	GR/2	: Front and rear washer motor	
A3		(E32)	BR/2	: Washer level sensor	
Engine room		A3	(E33)	B/2	: To (E93)
	A3	(E34)	B/1	: Horn (High)	
	B2	(E35)	—	: Alternator (E)	
	B4	(E36)	B/3	: Refrigerant pressure sensor	
	B3	(E37)	Y/2	: Crash zone sensor	
	B3	★(E38)	GR/4	: Cooling fan motor-1	
	C3	★(E39)	GR/4	: Cooling fan motor-2	

Passenger Compartment



- | | | | | | |
|--------|-------|------------------|--------|------|-----------------------|
| ★ E101 | W/8 | Fuse block (J/B) | E111 | W16 | AWD control unit |
| E103 | B/1 | Fuse block (J/B) | E112 | W/1 | Parking brake switch |
| E104 | B/2 | Fuse block (J/B) | E113 | GR/2 | Pedal adjusting motor |
| E105 | W/12 | To B4 | E114 | W/3 | Pedal adjusting motor |
| E106 | W/4 | To B5 | ★ E115 | BR/2 | ASCD brake switch |
| E107 | Y/4 | To M4 | ★ E116 | B/2 | Stop lamp switch |
| ★ E108 | W/2 | To M5 | E117 | W/6 | Ignition switch |
| E109 | W/24 | To M6 | | | |
| ★ E110 | GR/16 | To M7 | | | |

★: Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and CVT sections.

TKIA0115E

ENGINE CONTROL HARNESS



Engine control harness

E3	(F1)	—	Fusible link holder
G3★	(F2)	GR/9	To (E18)
G3★	(F3)	B/8	To (E19)
G2★	(F4)	B/6	Mass air flow sensor
E3	(F5)	GR/1	Starter motor
E4★	(F6)	-/22	CVT unit
E3★	(F7)	GR/2	Engine coolant temperature sensor
E3★	(F8)	B/3	Camshaft position sensor (PHASE) (Bank 2)
E2★	(F9)	GR/2	To (F241)
D3	(F10)	GR/2	Condenser
B2★	(F11)	GR/2	Injector No.2
C3★	(F12)	GR/2	Injector No.4
D3★	(F13)	GR/2	Injector No.6
B2	(F14)	GR/3	Ignition coil No.2 (With power transistor)
C3	(F15)	GR/3	Ignition coil No.4 (With power transistor)
D3	(F16)	GR/3	Ignition coil No.6 (With power transistor)
C3	(F18)	BR/3	Front electronic controlled engine mount
C3★	(F19)	G/4	Heated oxygen sensor 2 (Bank 1)
C4★	(F20)	B/3	Crankshaft position sensor (POS)
C4★	(F21)	G/4	Heated oxygen sensor 2 (Bank 2)
B2★	(F22)	B/2	VIAS control solenoid valve
B1	(F23)	—	Engine ground
B2★	(F25)	LGR/2	Intake valve timing control solenoid valve (Bank 2)
B3	(F26)	—	Alternator (B)
B3	(F27)	GR/4	Alternator (S, L)
B3	(F28)	B/1	Compressor
C1★	(F29)	GR/8	To (F201)
A1★	(F31)	B/3	Power steering pressure sensor
D1	(F32)	DGR/6	To (F221)
F2★	(F33)	DGR/6	Electric throttle control actuator
E2★	(F34)	G/3	Camshaft position sensor (PHASE) (Bank 1)
F2★	(F35)	B/3	Secondary speed sensor
F2	(F36)	BR/3	Rear electronic controlled engine mount (AWD models)
F3	(F37)	—	Fusible link holder
D3	(F38)	—	Starter motor
D1★	(F41)	-/6	Air fuel ratio (A/F) sensor 1 (Bank 1)
C3★	(F42)	-/6	Air fuel ratio (A/F) sensor 1 (Bank 2)

F4★	(F101)	SMJ	ECM
G4★	(F102)	W/18	To (M82)
G5★	(F103)	W/24	TCM (Transmission control module)
G4★	(F104)	GR/24	TCM (Transmission control module)
Engine control sub-harness-1			
B1★	(F201)	G/8	To (F29)
B1★	(F202)	G/2	Intake valve timing control solenoid valve (Bank 1)
B2	(F203)	GR/1	Oil pressure switch
B1★	(F204)	GR/2	Injector No.1
D1★	(F205)	GR/2	Injector No.3
D2★	(F206)	GR/2	Injector No.5
E1★	(F207)	L/2	EVAP canister purge volume control solenoid valve

Engine control sub-harness-2

D1	(F221)	G/6	To (F32)
C1	(F222)	GR/3	Ignition coil No.1 (With power transistor)
D1	(F223)	GR/3	Ignition coil No.3 (With power transistor)
D1	(F224)	GR/3	Ignition coil No.5 (With power transistor)


Engine control sub-harness-3

D3★	(F241)	GR/2	To (F9)
D3★	(F242)	L/2	Knock sensor

★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and CVT sections.

HARNESS

BODY HARNESS




B1	(B1)	BR/12	:	To (M8)
B1	★ (B2)	W/20	:	To (M9)
A2	★ (B3)	BR/16	:	To (M10)
A2	(B4)	W/12	:	To (E105)
B2	(B5)	W/4	:	To (E106)
A2	(B7)	—	:	Body ground
A2	(B8)	BR/6	:	Rear window defogger relay
B2	(B9)	W/16	:	Front power seat (Driver side)
C2	(B10)	Y/2	:	Front LH side air bag module
C2	(B11)	Y/12	:	Air bag diagnosis sensor unit
B3	(B12)	W/2	:	Condenser
B2	(B13)	Y/2	:	LH side air bag (satellite) sensor
C3	(B14)	Y/2	:	Front LH seat belt pre-tensioner
C3	(B15)	—	:	Body ground
B2	(B16)	W/18	:	To (D51)
C2	★ (B17)	GR/5	:	Fuel level sensor unit and fuel pump
D2	(B18)	Y/2	:	To (B118)
D2	(B19)	W/12	:	To (B117)
D2	(B20)	—	:	Body ground
D4	★ (B21)	B/2	:	EVAP canister vent control valve
D4	★ (B22)	GR/3	:	EVAP control system pressure sensor
D4	(B23)	W/4	:	Fuel lid lock actuator
E2	(B24)	W/4	:	Rear combination lamp LH

E1	(B25)	W/12	:	To (D91)
E1	(B26)	Y/4	:	To (D92)
E1	(B27)	W/2	:	To (D93)
F3	(B28)	GR/6	:	Woofer
G2	(B29)	W/4	:	Rear combination lamp RH
G2	(B30)	B/2	:	Rear power socket
A2	(B31)	B/5	:	Fuel lid lock actuator relay
C2	(B32)	W/2	:	Front power seat (Driver side)
E4	(B33)	W/1	:	Option connector for trailer
E2	(B34)	W/2	:	Diode


★ : Be sure to connect and lock the connectors securely after repair work.
Failure to do so may cause the ECM to have diagnostic trouble codes.
Do not disconnect these connectors except in the case of working according to WORK FLOW of TROUBLE DIAGNOSES in EC and CVT sections.

Diode (B34)



HARNESS


BODY NO.2 HARNESS



TKIB0002E

ROOM LAMP HARNESS

(R1)	W/8	: To (M12)
(R2)	W/2	: Vanity mirror lamp (Driver side)
(R3)	W/2	: Map lamp
(R4)	B/10	: Auto anti-dazzling inside mirror
(R5)	GR/6	: Sunroof switch
(R6)	W/10	: Sunroof motor assembly
(R7)	W/2	: Vanity mirror lamp (Passenger side)
(R8)	W/3	: Personal lamp LH
(R9)	-/3	: Room lamp
(R10)	W/3	: Personal lamp RH



A
B
C
D
E
F
G
H
I
J
PG
L
M


TKIA0035E

HARNESS

FRONT DOOR HARNESS


LH Side

- (D1) SMJ : To (M3)
- (D2) W/10 : Door mirror (Driver side)
- (D3) W/8 : Seat memory switch
- (D4) BR/2 : Front door speaker LH
(With BOSE system)
- (D5) W/2 : Front door speaker LH
(Without BOSE system)
- (D6) W/16 : Power window main switch
- (D7) W/3 : Power window main switch
- (D8) W/6 : Front power window motor
(Driver side)
- (D9) W/2 : Step lamp (Driver side)
- (D10) B/6 : Front door lock assembly
(Driver side)



TKIA0121E

RH Side




- (D31) SMJ : To (M87)
- (D32) W/10 : Door mirror (Passenger side)
- (D33) BR/2 : Front door speaker RH
(With BOSE system)
- (D34) W/2 : Front door speaker RH
(Without BOSE system)
- (D35) W/16 : Front power window switch
(Passenger side)
- (D36) W/6 : Front power window motor
(Passenger side)
- (D37) W/2 : Step lamp (Passenger side)
- (D38) B/6 : Front door lock assembly
(Passenger side)

TKIA0122E


HARNESS

REAR DOOR HARNESS

LH Side




RH Side



HARNESS

BACK DOOR HARNESS



D91	W/12	:	To	B25
D92	Y/4	:	To	B26
D93	W/2	:	To	B27
D94	O/2	:	LH side curtain air bag module	
D95	Y/2	:	RH side curtain air bag module	
D96	W/2	:	High-mounted stop lamp	
D97	B/1	:	Rear window defogger (+)	
D98	W/4	:	Luggage room lamp LH	
D99	W/2	:	Back-up lamp LH	
D100	W/3	:	Back door switch	
D101	W/4	:	Back door lock actuator	
D102	BR/2	:	License plate lamp LH	
D103	W/4	:	Rear wiper motor	
D104	BR/2	:	License plate lamp RH	
D105	W/2	:	Back-up lamp RH	
D106	W/4	:	Luggage room lamp RH	
D107	B/1	:	Rear window defogger (-)	

TKIA0087E

HARNESS

Wiring Diagram Codes (Cell Codes)

AKS007HU

Use the chart below to find out what each wiring diagram code stands for.

Refer to the wiring diagram code in the alphabetical index to find the location (page number) of each wiring diagram.

Code	Section	Wiring Diagram Name
A/C	ATC	Air Conditioner
ABS	BRC	Anti-lock Brake System
AF1B1	EC	Air Fuel Ratio Sensor 1 Bank 1
AF1B2	EC	Air Fuel Ratio Sensor 1 Bank 2
AF1HB1	EC	Air Fuel Ratio Sensor 1 Heater Bank 1
AF1HB2	EC	Air Fuel Ratio Sensor 1 Heater Bank 2
APPS1	EC	Accelerator Pedal Position Sensor
APPS2	EC	Accelerator Pedal Position Sensor
APPS3	EC	Accelerator Pedal Position Sensor
ASC/BS	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASC/SW	EC	Automatic Speed Control Device (ASCD) Steering Switch
ASCBOW	EC	Automatic Speed Control Device (ASCD) Brake Switch
ASCIND	EC	Automatic Speed Control Device (ASCD) Indicator
AUDIO	AV	Audio
AUT/DP	SE	Automatic Drive Positioner
AUTO/L	LT	Automatic Light System
AWD	TF	AWD System
BACK/L	LT	Back-Up Lamp
BRK/SW	EC	Brake Switch
CAN	CVT	CAN Communication Line
CAN	EC	CAN Communication Line
CAN	LAN	CAN System
CHARGE	SC	Charging System
CHIME	DI	Warning Chime
CIGAR	WW	Cigarette Lighter
COMBSW	LT	Combination Switch
COMM	AV	Audio Visual Communication Line
COMPAS	DI	Compass
COOL/F	EC	Cooling Fan Control
CVTIND	DI	CVT Indicator Lamp
D/LOCK	BL	Power Door Lock
DEF	GW	Rear Window Defogger
DTRL	LT	Daytime Light System
ECM/PW	EC	ECM Power Supply For Back-Up
ECTS	EC	Engine Coolant Temperature Sensor
EMNT	EC	Engine Mount
ETC1	EC	Electrical Throttle Control Function
ETC2	EC	Electrical Throttle Control Motor Relay
ETC3	EC	Electrical Throttle Control Motor
F/FOG	LT	Front Fog Lamp
F/PUMP	EC	Fuel Pump

HARNESS

Code	Section	Wiring Diagram Name
FTS	CVT	CVT Fluid Temperature Sensor Circuit
FTTS	EC	Fuel Tank Temperature Sensor
FUELB1	EC	Fuel Injection System Function (Bank 1)
FUELB2	EC	Fuel Injection System Function (Bank 2)
H/AIM	LT	Headlamp Aiming Control System
H/LAMP	LT	Headlamp
HORN	WW	Horn
HSEAT	SE	Heated Seat
I/MIRR	GW	Inside Mirror (Auto Anti-Dazzling Mirror)
IATS	EC	Intake Air Temperature Sensor
IGNSYS	EC	Ignition System
ILL	LT	Illumination
INF/D	AV	Vehicle Information And Integrated Switch System
INJECT	EC	Injector
IVCB1	EC	Intake Valve Timing Control Solenoid Valve Bank 1
IVCB2	EC	Intake Valve Timing Control Solenoid Valve Bank 2
KEYLES	BL	Remote Keyless Entry System
KS	EC	Knock Sensor
L/USSV	CVT	Lock-Up Select Solenoid Valve
LPSV	CVT	Line Pressure Solenoid Valve
MAFS	EC	Mass Air Flow Sensor
MAIN	EC	Main Power Supply And Ground Circuit
METER	DI	Speedometer, Tachometer, Temp., And Fuel Gauges
MIL/DL	EC	Mil & Data Link Connectors
MIRROR	GW	Power Door Mirror
MMSW	CVT	Manual Mode Switch
NATS	BL	Nissan Anti - Theft System
NAVI	AV	Navigation System
NONDTC	CVT	Non-Detective Items
O2H2B1	EC	Rear Heated Oxygen Sensor 2 Heater Bank 1
O2H2B2	EC	Rear Heated Oxygen Sensor 2 Heater Bank 2
O2S2B1	EC	Rear Heated Oxygen Sensor 2 Bank 1
O2S2B2	EC	Rear Heated Oxygen Sensor 2 Bank 2
P/SCKT	WW	Power Socket
PEDAL	AP	Adjustable Pedal System
PGC/V	EC	EVAP Canister Purge Volume Control Solenoid Valve
PHSB1	EC	Camshaft Position Sensor (PHASE) (Bank1)
PHSB2	EC	Camshaft Position Sensor (PHASE) (Bank2)
PNP/SW	CVT	Park / Neutral Position Switch
PNP/SW	EC	Park / Neutral Position Switch
POS	EC	Crankshaft Position Sensor (CKPS) (POS)
POWER	CVT	Transmission Control Module (Power Supply)
POWER	PG	Power Supply Routing
PRE/SE	EC	EVAP Control System Pressure Sensor

HARNESS

Code	Section	Wiring Diagram Name	
PRIPS	CVT	Primary Pressure Sensor	A
PRSCVT	CVT	Primary Speed Sensor CVT (Revolution Sensor)	
PS/SEN	EC	Power Steering Pressure Sensor	B
ROOM/L	LT	Interior Room Lamp	
RP/SEN	EC	Refrigerant Pressure Sensor	
SEAT	SE	Power Seat	C
SECPS	CVT	Secondary Pressure Sensor	
SECPSV	CVT	Secondary Pressure Solenoid Valve	D
SEN/PW	EC	Sensor Power Supply	
SESCVT	CVT	Secondary Speed Sensor CVT (Revolution Sensor)	
SHIFT	CVT	CVT Shift Lock System	E
SPSW	CVT	Second position Switch	
SROOF	RF	Sunroof	F
SRS	SRS	Supplemental Restraint System	
START	SC	Starting System	
STM	CVT	Step Motor	G
STOP/L	LT	Stop Lamp	
STSIG	CVT	Start Signal Circuit	H
T/WARN	WT	Low Tire Pressure Warning System	
TAIL/L	LT	Parking, License and Tail Lamps	
TCV	CVT	Torque Converter Clutch Solenoid Valve	I
TPS1	EC	Throttle Position Sensor (Sensor 1)	
TPS2	EC	Throttle Position Sensor (Sensor 2)	J
TPS3	EC	Throttle Position Sensor	
TRANSCV	BL	Homelink Universal Transceiver	
TURN	LT	Turn Signal and Hazard Warning Lamp	PG
VDC	BRC	Vehicle Dynamics Control System	
VEHSEC	BL	Vehicle Security System	
VENT/V	EC	EVAP Canister Vent Control Valve	L
VIAS	EC	Variable Induction Air Control System	
VIAS/V	EC	VIAS Control Solenoid Valve	M
WARN	DI	Warning Lamps	
WINDOW	GW	Power Window	
WIP/R	WW	Rear Wiper and Washer	
WIPER	WW	Front Wiper and Washer	



ELECTRICAL UNITS LOCATION

ELECTRICAL UNITS LOCATION

PFP:25230

Electrical Units Location ENGINE COMPARTMENT


AKS007HM




CKIA0319E

ELECTRICAL UNITS LOCATION


PASSENGER COMPARTMENT



A Driver side view with lower instrument panel removed




Fuse block (J/B) rear view



CKIA0320E


ELECTRICAL UNITS LOCATION

B Dash side LH




AWD control unit (E111)


C Driver side view with lower instrument panel removed



D Driver side view with lower instrument panel removed




E Under driver seat




Driver seat control unit
(With automatic drive positioner)
(B303, B304)

F Driver side view with cluster lid A removed




NATS antenna amp. (M30)

G View with instrument panel center removed




Display control unit (M42, M43)
Unified meter and A/C amp.
(M49, M50, M51)

H




NAVI control unit (M62, M63)

J Behind lower instrument panel on passenger side



ECM (M80, F101)
TCM (Transmission control module)
(F103, F104)
Low tire pressure warning control unit (M81)

K View with floor console box removed





Air bag diagnosis sensor unit (M64)

CKIA0321E

ELECTRICAL UNITS LOCATION

LUGGAGE COMPARTMENT



A

B

C

D

E

F

G

H

I

J

PG

L

M

CKIA0288E

HARNESS CONNECTOR

PFP:00011

Description

HARNESS CONNECTOR (TAB-LOCKING TYPE)

AKS007HN


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the illustration below.

Refer to the next page for description of the slide-locking type connector.

CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

HARNESS CONNECTOR


HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the illustration below.

CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



A
B
C
D
E
F
G
H
I
J
PG
L
M

ELECTRICAL UNITS


ELECTRICAL UNITS

PFP:00011


Terminal Arrangement

AKS007HP


ECM




TCM (TRANSMISSION CONTROL MODULE)



ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)



UNIFIED METER AND A/C AMP.



ELECTRICAL UNITS

BCM (BODY CONTROL MODULE)

M34

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40



(White)

M35

41	42	43	44	45	46	47	48	49
50	51	52	53	54	55			

(Black)

M36

56	57	58	59	60	61	62	63	64
65	66	67	68	69	70			



(White)

A
B
C
D
E
F
G
H
I
J
PG
L
M


SMJ (SUPER MULTIPLE JUNCTION)

SMJ (SUPER MULTIPLE JUNCTION)

PFP:B4341

Terminal Arrangement

AKS007HQ



STANDARDIZED RELAY

STANDARDIZED RELAY


PFP:00011

Description

AKS007HR

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H













TYPE OF STANDARDIZED RELAYS

1M 1 Make 2M 2 Make
 1T 1 Transfer 1M·1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W


FUSE BLOCK - JUNCTION BOX (J/B)

FUSE BLOCK - JUNCTION BOX (J/B)

PFP:24350

Terminal Arrangement

AKS007HS



CKIA0357E



FUSE, FUSIBLE LINK AND RELAY BOX

FUSE, FUSIBLE LINK AND RELAY BOX

PFP:24382

Terminal Arrangement

AKS007HT



CKIA0358E