


BX. 45-25e



## PARTS LIST

47 : A.B.S. hydraulic control block  
 54 : A.B.S. electronic control unit  
 146 : Front LH wheel sensor  
 147 : Front RH wheel sensor  
 148 : Rear LH wheel sensor  
 149 : Rear RH wheel sensor  
 185 : Stoplamp switch  
 229 : Antitheft/ignition switch  
 312 : Anti-blocage system diode  
 457 : LH stoplamp  
 458 : RH stoplamp  
 470 : Fuse  
 756 : A.B.S. electrovalve relay  
 963 : A.B.S. warning lamp.

## WARNES IDENTIFICATION

A : Front  
 E : Screen wiper  
 F : Connection for rear lamps  
 MF : Rear lamp earth  
 R : Rear  
 (No identification) : Anti-blocage system.

\* : Connection to stoplamp 1/9/87 →

NOTE : For the parts and connectors location, see the wiring diagram of (12) Op. XB19E.510.00C.

## A.B.S. SYSTEM AUTO-CHECKING DEVICE :

The anti-locking braking system has a self check device built into the electronic control unit.

## • AIM :

- Check of the internal circuits of the ECU
- Check of the A.B.S. units.

Remark : the road wheel sensor signals will be checked with the engine running.

## • PRINCIPLE OF OPERATION :

- The A.B.S. warning lamp (963) circuit is completed, being connected to earth by connection **27** of the electronic control unit (54). The lamp **is on**.
- Connection **2** of the ECU is electrically supplied.
- Connection **8** supplies the control relay (**756**) via the ECU.
- Connections **8** and **20** of the ECU are supplied by the control relay (**756**) power circuit.
- If no fault is found, the ECU will cut off the earth circuit at connection **27** : **the warning lamp will go out**.
- **The system is ready to operate.**

## A.B.S. FAULT FINDING :

When a fault is detected :

- Connection **8** of the ECU is no longer supplied electrically.
- Control relay (**756**) does not operate.
- **The warning lamp circuit is completed to earth via the relay.**
- **The A.B.S. is out of operation.**

## DIAGNOSTIC AND ELECTRICAL CHECKS

NORMAL CYCLE	FAULT DETECTED	POINTS TO CHECK	Chapter
<p>ANTITHEFT/IGNITION SWITCH IN « HOME » POSITION</p> <p>↓ <b>E</b></p> <p>ANTITHEFT/IGNITION SWITCH IN THE « ACCESSORY » POSITION</p> <p>↓ <b>E</b></p> <p>ANTITHEFT/IGNITION SWITCH IN THE « IGNITION ON » POSITION</p> <p>↓ <b>A</b></p> <p>SELF CHECK</p> <p>↓ <b>E</b></p> <p>ANTITHEFT/IGNITION SWITCH IN THE « STARTER » POSITION</p> <p>↓ <b>A</b></p> <p>ANTITHEFT/IGNITION SWITCH IN THE « IGNITION/ON, ENGINE RUNNING » POSITION</p> <p>↓ <b>A</b></p> <p>SELF CHECK</p> <p>↓ <b>E</b></p> <p>VEHICLE MOVING</p> <p>↓ <b>E</b></p>			
	<b>A</b>	<ul style="list-style-type: none"> <li>– Electrical supply to the ECU</li> <li>– Wheel sensor resistances</li> <li>– Resistance of controlling electrovalves (inlet and exhaust)</li> <li>– Resistance of the main electrovalve</li> <li>– Earth screening of the wheel sensor leads</li> </ul>	<p><b>1</b> (page 5)</p> <p><b>2</b> (page 5)</p> <p><b>4</b> (page 6)</p> <p><b>5</b> (page 6)</p> <p><b>6</b> (page 6)</p>
	<b>A</b>	Current output from the wheel sensors	<b>3</b> (page 5)

**A** = ABS warning lamp stays on**E** = warning lamp does not light

## CHECKING THE A.B.S. ELECTRONIC UNITS AND ELECTRICAL CIRCUITS :

The ECU connector checks are carried out with the ECU disconnected.

So as not to deteriorate the sockets of the harness connector, it is advised to remove the protection cover « a » and to take readings on the wire entry as shown on drawing, page 2.

With the protector cover removed, the multipin connector has the sockets numbered 1 to 35.

**IMPORTANT : Always switch off the electrical supply to the ECU before disconnecting it.**

**CHAPTER 1 – Electrical supply to the ECU :**

CHECKING EQUIPMENT VOLTMETER or OHM-METER	CORRECT VALUE	IF READING IS INCORRECT
<ul style="list-style-type: none"> <li>Switch the ignition on (accessory or ignition position)</li> <li>– Voltmeter between connections 1 and 2.</li> </ul>	above <b>12 V</b>	Check the electrical circuit for continuity.
<ul style="list-style-type: none"> <li>Switch the ignition off :</li> <li>– Ohm-meter between connections 1 and 3</li> </ul>	less than <b>1Ω</b>	Check : – control relay (756) – the continuity of the circuit
<ul style="list-style-type: none"> <li>– Ohm-meter between connections 1 and 20</li> </ul>	less than <b>1Ω</b>	Check, for continuity, the electrical circuit
<ul style="list-style-type: none"> <li>– Ohm-meter between connections 1 and 8</li> </ul>	between <b>50</b> and <b>100Ω</b>	Check : – control relay (756) – the continuity of the circuit
<ul style="list-style-type: none"> <li>Link up connections 2 and 8 then switch the ignition on :</li> <li>– Volt-meter between connections 1 and 3.</li> </ul>	above <b>12 V</b>	Check : – control relay (756) – the continuity of the circuit

**CHAPTER 2 – Wheel sensor resistances :**

CHECKING EQUIPMENTS : OHM-METER	CORRECT VALUE	IF READING IS INCORRECT
<b>R.H. rear sensor (149) :</b> Ohm-meter between connections 4 and 22. <b>L.H. rear sensor (148) :</b> Ohm-meter between connections 6 and 24. <b>R.H. front sensor (147) :</b> Ohm-meter between connections 7 and 25. <b>L.H. front sensor (146) :</b> Ohm-meter between connections 5 and 23.	between <b>800 and 1400Ω</b>	Connect an ohm-meter on the connections of the corresponding sensor. – if the reading is correct, check the circuit for continuity between the sensor and the ECU plug. – if the reading is incorrect, change the sensor.

**CHAPTER 3 – Current output from the sensors :**

CHECKING EQUIPMENT : VOLTMETER « AC » (or « ≈ ») range	CORRECT VALUE	IF READING IS INCORRECT
The check is carried out by rotating the road wheel of the sensor concerned at approximately 1 turn per second : <b>R.H. rear sensor (149) :</b> Voltmeter between connections 4 and 22. <b>L.H. rear sensor (148) :</b> Voltmeter between connections 6 and 24. <b>R.H. front sensor (147) :</b> Voltmeter between connections 7 and 25. <b>L.H. front sensor (146) :</b> Voltmeter between connections 5 and 23.	between <b>100 and 570mV</b>          between <b>100 and 350mV</b>	Check : – the reading of the sensor, – the air gap (not adjustable) – the rotor wheel (fitting and condition of the teeth)

**CHAPTER 4 – Resistance of the controlling electrovalves (located inside the hydraulic control block) :**



CHECKING EQUIPMENT : OHM-METER	CORRECT VALUE	IF READING IS INCORRECT
Ohm-meter between connections <b>11</b> and <b>1</b>	less than <b>1 <math>\Omega</math></b>	Check : – on the 7-way connector of the hydraulic control block, if lead <b>11</b> is to earth. – for continuity, the circuit on lead <b>11</b> between the ECU and the hydraulic control block.
<b>R.H. front electrovalve (inlet) :</b> ohm-meter between connections <b>11</b> and <b>15</b>  <b>R.H. front electrovalve (exhaust) :</b> ohm-meter between connections <b>11</b> and <b>34</b>  <b>L.H. front electrovalve (inlet) :</b> ohm-meter between connections <b>11</b> and <b>35</b>  <b>L.H. front electrovalve (exhaust) :</b> ohm-meter between connections <b>11</b> and <b>16</b>  <b>Rear electrovalve (inlet) :</b> ohm-meter between connections <b>11</b> and <b>17</b>  <b>Rear electrovalve (exhaust) :</b> ohm-meter between connections <b>11</b> and <b>33</b>	between <b>3 and 7 <math>\Omega</math></b>	Check : – on the 7-way connector of the hydraulic control block, the resistance of the electrovalves : ohm-meter between leads : – 11 and 15 – 11 and 34 – 11 and 35 – 11 and 16 – 11 and 17 – 11 and 33 – If one of the readings is incorrect, change the hydraulic block. – If all the readings are correct, check the continuity of the electrical circuit between the 7-way connector of the hydraulic control block and the ECU plug.

**CHAPTER 5 – Resistance of the main electrovalve (attached to the hydraulic control block)**


CHECKING EQUIPMENT : OHM-METER	CORRECT VALUE	IF READING IS INCORRECT
Ohm-meter between connections <b>11</b> and <b>18</b>	between <b>2 and 5 <math>\Omega</math></b>	Connect an ohm-meter on the 2-way connector of the hydraulic control block (not disconnected) : – if the reading is correct, check the continuity of the circuit between the electrovalve connector and the ECU plug, – if the reading is incorrect, change the hydraulic block.

**CHAPTER 6 – Screening of the sensor leads :**

CHECKING EQUIPMENT : OHM-METER	CORRECT VALUE	IF READING IS INCORRECT
<b>R.H. rear sensor (149) :</b> ohm-meter between connections <b>4</b> and <b>1</b>  <b>L.H. rear sensor (148) :</b> ohm-meter between connections <b>6</b> and <b>1</b>  <b>R.H. front sensor (147) :</b> ohm-meter between connections <b>7</b> and <b>1</b>  <b>L.H. front sensor (146) :</b> ohm-meter between connections <b>5</b> and <b>1</b>	$\infty$	Check the insulation of the electrical circuit screening against the earth of the vehicle.



II



III

## ANTI-LOCKING BRAKING SYSTEM

## Hydraulic circuit, Fig. I

- 1 : Source of pressure.
- 2 : High pressure supply to the brake control valve (front brakes).
- 3 : Rear suspension pressure ; feed to control valve (rear brakes).
- 4 : Rear suspension height corrector.
- 5 : Front braking pressure to hydraulic control block.
- 6 : Rear braking pressure to hydraulic control block.
- 7 : Compensator bleed screw.
- 8 : A.B.S. hydraulic control block.
- 9 : Front LH wheel braking pressure.
- 10 : Rear wheels braking pressure.
- 11 : Front RH wheel braking pressure.
- 12 : Brake tube carrier on bulkhead.
- 13 : Hydraulic block return to reservoir.
- 14 : Brake control valve return to reservoir.

Note : Front brake hoses have a blue identification mark ; hose connection is M. 9 x 125 instead of M. 8 x 125.

## Road wheel sensors

## Front wheel sensors, Fig. II.

Air gap : 0.30 mm to 1 mm (not adjustable)

Fitting a new sensor :

- slacken screw (16),
- offer up the sensor with its adjusting paper shim « a »,
- tighten screw (15) previously coated with LOCTITE FRENETANCH compound, to 1 mdaN,
- push the sensor until its paper shim is into contact with the toothed wheel,
- tighten screw (16) until it shears.

## Rear wheel sensors, Fig. III.

Air gap : 0,50 to 1,10 mm (not adjustable)

Screw (17) tightening : 1 mdaN (previously coated with LOCTITE FRENETANCH)

## Hydraulic block (8), Fig. I (identification : purple disc 09/87 →)

Situated on the front LH wheel arch.

It is composed of 6 electro-valves (2 per braking circuit : LH front, RH front and rear).

The hydraulic pipe connections are marked as shown on the drawing of Fig. I.

## Electronic control unit (identification : purple disc 09/87 →)

Located under the front LH seat.

REPAIR : On the vehicles produced until 09/87, the electronic control unit or the hydraulic block with the purple identification replaces the former ones.

It is compulsory to fit a part with a purple identification to the vehicles manufactured since 09/87 or having components with purple ident. marks.

CHECKING the A.B.S. : See Op (11) XB 453-Oa.