NISSAN TRUCK MODEL D21 SERIES

QUICK REFERENCE INDEX	
GENERAL INFORMATION —	GI
MAINTENANCE —	MA
ENGINE MECHANICAL ————————————————————————————————————	EM
ENGINE LUBRICATION & COOLING SYSTEMS	LC
ENGINE CONTROL SYSTEM —————	EC
ACCELERATOR CONTROL, FUEL &EXHAUST SYSTEMS	FE
CLUTCH	CL
MANUAL TRANSMISSION ——————	MT
AUTOMATIC TRANSMISSION —	AT
TRANSFER ————————————————————————————————————	TF
PROPELLER SHAFT & DIFFERENTIAL CARRIER	PD
FRONT AXLE & FRONT SUSPENSION ————	FA
REAR AXLE & REAR SUSPENSION ————	RA
BRAKE SYSTEM —	BR
STEERING SYSTEM —	ST
RESTRAINT SYSTEM	RS
BODY & TRIM	ВТ
HEATER & AIR CONDITIONER —————	нА
ELECTRICAL SYSTEM —————	EL
ALPHABETICAL INDEX	IDX

© 1996 NISSAN NORTH AMERICA, INC. Printed in U.S.A. All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan North America, Inc., Torrance, California.

FOREWORD

This manual contains maintenance and repair procedures for the 1997 Nissan TRUCK.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.





NISSAN PLEASE HELP MAKE THIS SERVICE MANUAL BETTER!

Your comments are important to NISSAN and will help us to improve our Service Manuals. Use this form to report any issues or comments you may have regarding our Service Manuals. Please photocopy this form and type or print your comments below. Mail or fax to:

Nissan North America, Inc. Technical Service Information 39001 Sunrise Drive, P.O. Box 9200 Farmington Hills, MI USA 48331

FAX: (810) 488-3910

SERVICE MANUA	AL: Model:	Yea	r:		·
PUBLICATION N	O. (Please photocopy b	ack cover):			
VEHICLE INFOR	MATION VIN:		Production Da	te:	
Please describe a	ny issues or problems in	detail:			
Page number(s)_	Note	e: Please include	a copy of each p	age, marked with you	r comments.
Are the trouble d	liagnosis procedures lo	gical and easy to	use? (circle yo	our answer) Y	ES NO
If no, what page no	ımber(s)? <i>N</i>	ote: Please include	e a copy of each p	nage, marked with you	comments.
Please describe th	ne issue or problem in de	etail:			
_	on of the manual clear a	-		•	NO
- Tamber					
What information repairing custom	should be included in er vehicles?	NISSAN Service	Manuals to bet	ter support you in s	ervicing or
The Address of the Control of the Co					
DATE:	YOUR NAME:			POSITION:	
DEALER:	DEALEF	R NO.:	ADDRESS:		
CITY:	STATE/P	ROV./COUNTRY:_	2	ZIP/POSTAL CODE:_	·

QUICK REFERENCE CHART: TRUCK

]1997

ENGINE TUNE-UP DATA

Engine model	Engine model KA24E				
Firing arder		1-3-4-2			
idle speed					
M /T			800 + 50		
A/T (in "N" position)			800 ± 50		
Ignition timing (degree B.T.D.C. at idle speed)		10 ' ± 2'		
CO% at idle		ldle mixtur	e screw is preset at factory	and sealed	
Spark plug					
	Standard		ZFR5E-11		
Туре	Cold		ZFR6E-11		
	Hot		ZFR4E-11		
Gap	mm (in)	1.0	0 - 1.1 (0.039 - 0.0	43)	
Drive belt deflection (Cold)	mm (in)	Used	i belt		
		Limit	Deflection after adjustment	Deflection of new belt	
Generator		17 (0.67)	10 - 12 (0.39 - 0.47)	8 - 10 (0.31 - 0.39)	
Air conditioner compres	sor	16 (0.63)	10 - 12 (0.39 - 0.47)	8 - 10 (0.31 - 0.39)	
Power steering oil pump) 	15 (0.59)	9 - 11 (0.35 - 0.43)	7 - 9 (0.28 - 0.35)	
Applied pressed force	N (kg, lb)		98 (10, 22)		
Radiator cap relief pressure	kPa (kg/cm ² , psi)	78 -	98 (0.8 - 1.0, 11 -	14)	
Cooling system leakage testin	g pressure kPa (kg/cm ² , psi)		157 (1.6, 23)		
Compression pressure	Standard	1,324 (13.5, 192)/300			
kPa (kg/cm2, psi)/rpm	Minimum		981 (10, 142)/300		
Fightening torque		N·m	kg-m	ft-lb	
Spark plug		20 - 29	2.0 - 3.0	14 - 22	
Oil pan drain plug	**	29 - 39	3.0 - 4.0	22 - 29	

FRONT WHEEL ALIGNMENT (Unladen*1)

	ALLOW	ABLE LIMIT	ADJUST	NG RANGE
Applied model	2WD	4WD	2WD	4WD
Camber degree (Decimal degree)	-0°20' - 1°10' (-0.33° - 1.17°)	-0:05' - 1°25' (-0.08" - 1.42°)	-0°05' - 0°55' (-0.08° - 0.92°)	0°10' - 1°10' (0.17° - 1.17°)
Caster degree (Decimal degree)	-0°23' - 1°07' (-0.38" - 1.12")	0°33' - 2°03' (0.55° - 2.05°)	-0°08' - 0°52' (-0.13' - 0.87')	0°48' - 1°48' (0.80' - 1.80'')
Kingpin inclination degree (Decimal degree)	8°20' ~ 9°50' (8.33° - 9.83°)	7°21' - 8°51' (7.35° - 8.85°)	8°35' - 9°35' (8.58° - 9.58°)	7"36" - 8"36" (7.60" - 8.60")
Toe-in Radial fire A - B mm (in) Total angle 2i; degree (Decimal degree)	1 - 5 (0.04 - 0.20) 5' - 25' (0.08° - 0.42°)	2 - 6 (0.08 - 0.24) 9' - 29' (0.15' - 0.48")	2 - 4 (0.08 - 0.16) 10' - 20' (0.17° - 0.33°)	3 - 5 (0.12 - 0.20) 14' - 24' (0.23° - 0.40°)
Wheel turning angle Inside Degree minute (Decimal degree)	34"00" - 38"00" (34.00" - 38.00")	31°00' - 35°00' (31.00° - 35.00°)	36°00" - 38°00" (36.00° - 38.00°)	33°00′ - 35°00 (33.00° - 35.00°
Outside Degree minute (Decimal degree)	31°00° - 35°00° (31.00° - 35.00°)	29°00' - 33°00' (29.00° - 33.00')	33°00° - 35°00° (33.00° - 35.00°)	

^{*1:} Fuel, radiator coolant and engine oil full.

CLUTCH PEDAL

	Unit: mm (in)
Pedal height	236 - 246 (9.29 - 9.69)
Pedal free play	9 - 16 (0.35 - 0.63)

BRAKE

	Unit: mm (
Disc brake	
Pad minimum thickness	2.0 (0.079)
Rotor repair limit	
Runout	0.07 (0.0028) or less
Minimum thickness	20.0 (0.787), CL28VA 24.0 (0.945), CL28VD
Drum brake	
Lining minimum thickness	1.5 (0.059)
Drum repair fimit Maximum inner diameter	261.5 (10.30), LT26B 296.5. (11.67), LT30B
Parking brake	
Number of notches*1	10 - 12

^{*1:} At pulling farce: 196 N (20 kg, 44 lb)

FRONT WHEEL BEARING

		Model				
Item		2WD	4WD			
Tightening torque N·m (kg·m, ft·lb)	34 - 39 (3.5 - 4.0, 25 - 29)		-			
Return angle degree]	45° - 60°	-			
			Wheel bearing look nut Tightening torque N-m (kg-m, ft-lb)	78 - 98 (8 - 10, 58 - 72)		
Preload (At hub bolt) N (kg, lb)	New seal	9.8 - 28.4 (1.0 - 2.9, 2.2 - 6.4)	Retightening torque after loosening wheel bearing lock nut N·m (kg·m, ft-lb) Axial end play mm (in)	0.5 - 1.5 (0.05 - 0.15, 0.4 - 1.1) 0 (0)		
			Start force at wheel hub boit N (kg, lb)	A		
	Used scal	Used scal	9.8 - 23.5 (1.0 - 2.4, 2.2 - 5.3)	Turning angle degree Starling force at wheel hub bolt N (kg, lb)	15° - 30° B	
			Wheel bearing preload at wheel hub bolt B - A N (kg, lb)	7.06 - 20.99 (0.72 - 2.14, 1.59 - 4.72)		

REFILL CAPACITIES

	Unit		Liter	US measure
Fuel tank			60	15.9 gal
0-1-1 (with a		2WD	8.1	8-5/8 qt
Coolant (with reservoir)		4WD	9.0	9-1/2 qt
	2WD	With oil filter	3.9	4-1/8 qt
Engine	2WD	Without oil filter	3.5	3-3/4 qt
	4WD	With oil filter	4.1	4-3/8 qt
	4WD	Without oil filter	3.8	4 qt
Transaxle	мт	2WD	2.0	4-1/4 pt
	M/T	4WD	4.9	10-3/8 pt
	A/T	-	7.9	8-3/8 qt
Transfer		4WD	2.2	2-3/8 qt
	OH (D	H190A	1.5	3-1/8 pt
	2WD	C200	1.3	2-3/4 pt
Final drive		R180A	1.3	2-3/4 pt
	4WD	H233B	2.8	5-7/8 pt
Manual steering system			0.62	1-3/8 pt
D		PB48S	0.9	1 qt
Power steering system		PB59K	1.0	1-1/8 qt
		Lubricant	0.2	6.8 fl oz
Air conditioner system		Refrigerant*	0.75 - 0.85	1.65 - 1.87 lb

^{*}R-134a

TEST VALUE AND TEST LIMIT (GST ONLY — NOT APPLICABLE TO CONSULT-II)

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items.

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the GST screen.

: Applicable ·: Not applicable

						: Applicable •	: Not applicable
			Test	value			
SRT item	Self-diagnostic test item	DTC	(GST	display)	Te s t limit	Application	Unit
	_		TID	CID			
CATALYST	Three way catalyst function	P0420	01H	01H	Max.	Χ	-
UNINCIST	Tillee way catalyst fullction	P0420*1	02H	81H	Min.	Χ	-
EVAP SYSTEM	EVAP control system (Small leak)	P0440	05H	03H	Max.	Χ	-
LVAI GIGILIII	EVAP control system purge flow monitoring	P1447	06H	83H	Min.	Χ	mV
		P0130	09H	04H	Max.	Χ	ms
		P0130	OAH	84H	Min.	Χ	mV
	Heated oxygen sensor 1	P0130	0BH	04H	Max.	Χ	mV
		P0130	0CH	04H	Max.	Χ	mV
H02S		P0130	ODH	04H	Max.	Χ	S
	Heated oxygen sensor 2	P0136	19H	86H	Min.	Χ	mV/500ms
		P0136	1AH	86H	Min.	Χ	mV
		P0136	1BH	06H	Max.	Χ	mV
		P0136	1CH	06H	Max.	Χ	mV
	Heated oxygen sensor 1 heater	P0135	29H	08H	Max.	Χ	mV
HO2S HTR	neated oxygen sensor i heater	P0135	2AH	88H	Min.	Χ	mV
11023 1111	Heated oxygen sensor 2 heater	P0141	2DH	OAH	Max.	Χ	mV
		P0141	2EH	8AH	Min.	Χ	mV
		P0400	31H	8CH	Min.	Χ	°C
		P0400	32H	8CH	Min.	Χ	°C
	EGR function	P0400	33H	8CH	Min.	Χ	Ω
EGR SYSTEM		P0400	34H	8CH	Min.	Χ	ပ္
		P0400	35H	0CH	Max.	Χ	°C
	EGRC-BPT valve function	P0402	36H	0CH	Max.	Χ	-
	Edito Bili valve idilotion	P0402	37H	8CH	Min.	Χ	-

^{*1:} Models B15 GA16DE engine 1997MY only.

MAINTENANCE

SECTION MA

EM:

LC

FE

CIL

Mil

AT

TE

90

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

ŖS

Bī

 $\mathbb{H}\mathbb{A}$

IDX

CONTENTS

PRECAUTIONS AND PREPARATION	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
Special Service Tool	
GENERAL MAINTENANCE	3
PERIODIC MAINTENANCE	5
Schedule 1	6
Schedule 2	
RECOMMENDED FLUIDS AND LUBRICANTS	8
Fluids and Lubricants	8
SAE Viscosity Number	9
Antifreeze Coolant Mixture Ratio	9
ENGINE MAINTENANCE	10
Checking Drive Belts	10
Changing Engine Coolant	11
Checking Fuel Lines	12
Changing Fuel Filter	12
Changing Air Cleaner Filter	12
Changing Engine Oil	13
Changing Oil Filter	
Changing Spark Plugs	14
Checking EVAP Vapor Purge Lines	15
Changing Positive Crankcase Ventilation (PCV)	
Filter	
CHASSIS AND BODY MAINTENANCE	16
Checking Exhaust System	16

Checking Clutch Fluid Level and Leaks	16
Checking M/T Oil	16
Changing M/T Oil	16
Checking Water Entry For 4WD models	16
Checking A/T Fluid	16
Changing A/T Fluid	17
Checking Transfer Fluid	
Changing Transfer Fluid	18
Checking Propeller Shaft	
Checking Differential Gear Oil	18
Changing Differential Gear Oil	19
Balancing Wheels	19
Tire Rotation	19
Checking Brake Fluid Level and Leaks	20
Checking Brake System	
Checking Disc Brake	
Checking Drum Brake	20
Checking Steering Gear and Linkage	21
Checking Power Steering Fluid and Lines	21
Checking Steering Gear Oil Level and Leaks	
Lubricating Hood Latches, Locks and Hinges	22
Checking Seat Belts, Buckles, Retractors,	
Anchors and Adjusters	23
SERVICE DATA AND SPECIFICATIONS (SDS).	24
Engine Maintenance	24
Chassis and Body Maintenance	24

PRECAUTIONS AND PREPARATION

Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death
 in the event of a collision which would result in air bag inflation, all maintenance must be performed
 by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Special Service Tool

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description		
KV10105900 (J34274) Oil filter cap wrench	NT005	Removing oil filter	

GENERAL MAINTENANCE

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform checks and inspections themselves or they can have their NISSAN dealers do them.

MA

Item	Reference page	MA
OUTSIDE THE VEHICLE The maintenance items listed here should be performed from time to time, unless otherwise specified.		
Tires Check the pressure, including the spare, with a gauge periodically when at a service station, and adjust to the specified pressure if necessary. Check carefully for damage, cuts and excessive wear.	_	L©
Wheel nuts When checking the tires, make sure no nuts are missing, and check for any loose nuts. Tighten if necessary.	_	EC
Tire rotation Tires should be rotated every 12,000 km (7,500 miles) for 2WD models and every 6,000 km (3,750 miles) for 4WD models.	MA-19	[]
Wheel alignment and balance If the vehicle pulls to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.	MA-19, FA-8	GL.
Windshield wiper blades Check for cracks and wear if they do not wipe properly.	_	 MT
Doors and engine hood Check that all doors, engine hood and tailgate operate smoothly. Also make sure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-22	AT
Lamps Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also check headlamp aim.	_	 T!F
INSIDE THE VEHICLE The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.		 PD
Warning lamps and buzzers/chimes Make sure that all warning lamps and buzzers/chimes are operating properly.	_	FA
Windshield wiper and washer Check that the wipers and washer operate properly and that the wipers do not streak.	<u> </u>	
Windshield defroster Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioner.		RA
Steering wheel Check that it has the specified play. Be sure to check for changes in the steering condition, such as excessive play, hard steering or strange noises. Free play: Less than 35 mm (1.38 in)	ST-7	BR
Seats Check seat position controls such as seat adjusters, seatback recliner, etc. to make sure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if equipped) hold securely in all latched positions. Check jump seats for smooth operation.	_	
Seat belts Check that all parts of the seat belt system (e.g., buckles, anchors, adjusters and retractors) operate properly and smoothly and are installed securely. Check the belt webbing for cuts, fraying, wear and damage.	MA-23	 87
Clutch pedal Make sure the pedal operates smoothly and check that it has the proper free play.	CL-5	
Brakes Check that the brakes do not pull the vehicle to one side when applied.		I.A
Brake pedal and booster Check the pedal for smooth operation and make sure that it has the proper distance under it when depressed fully. Check the brake booster function. Be sure to keep floor mats away from the pedal.	BR-11, 16	
Parking brake Check that the lever has the proper travel and make sure that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	BR-27]D))

MA-3 55

GENERAL MAINTENANCE

Item	Reference page
Automatic transmission "Park" mechanism Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that the vehicle is held securely with the selector lever in the "P" position without applying any brakes.	_
UNDER THE HOOD AND VEHICLE The maintenance items listed here should be checked periodically (e.g., each time you check the engine oil or refuel).	
Windshield washer fluid Check that there is adequate fluid in the tank.	
Engine coolant level Check the coolant level when the engine is cold.	MA-11
Radiator and hoses Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure that the hoses have no cracks, deformation, deterioration or loose connections.	_
Brake and clutch fluid levels Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoirs.	MA-16, 20
Battery Check the fluid level in each cell. It should be between the "MAX" and "MIN" lines.	<u>—</u>
Engine drive belts Make sure that no belt is frayed, worn, cracked or oily.	MA-10
Engine oil level Check the level on the dipstick after parking the vehicle on a level spot and turning off the engine.	MA-13
Power steering fluid level and lines Check the level on the dipstick with the engine off. Check the lines for improper attachment, leaks, cracks, etc.	MA-21
Automatic transmission fluid level Check the level on the dipstick after putting the selector lever in "P" with the engine idling.	MA-16
Exhaust system Make sure that there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-16
Underbody The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	_
Fluid leaks Check under the vehicle for fuel, oil, water and other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If any leaks or gasoline fumes are evident, check for the cause and correct it immediately.	_

MA-4

PERIODIC MAINTENANCE

Two different maintenance schedules are provided, and should be used, depending upon the conditions under which the vehicle is mainly operated. After 60,000 miles (96,000 km) or 48 months, continue the periodic maintenance at the same mileage/time intervals.

MA

SCHEDULE 1

Follow Periodic Maintenance Schedule 1 if your driving habits frequently include one or more of the following driving conditions:

- Repeated short trips of less than 5 miles (8 km).
- Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing.
- Operating in hot weather in stop-and-go "rush hour" traffic.
- Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery
- Driving in dusty conditions.
- Driving on rough, muddy, or salt spread roads.
- Towing a trailer, using a camper or a car-top carrier.

EG

LC

SCHEDULE 2

Follow Periodic Maintenance Schedule 2 if none of the driving conditions shown in Schedule 1 apply to your driving habits.



CIL

MT

AT

Maintenance for off-road driving (Ax only)

Whenever you drive off-road through sand, mud or water, more frequent maintenance may be required of the following items:

- Brake pads and discs
- Brake lining and drums
- Brake lines and hoses
- Wheel bearing grease and free-running hub grease
- Differential gear oil, transmission and transfer fluid
- Steering linkage
- ▲ Propeller shaft and drive shafts
- ▲ Air cleaner filter
- Clutch housing (Check water entry. Refer to MA-16.)

PD

TF

- - FA

RA

- 88
- ST
- RS
- 87
- HA
- EL

Schedule 1

Abbreviations: H ≈ Heplace = Inspect. Correct or replace if necessary.	replace if necessary.				ı				·					_]: At	the n]: At the mileage intervals only
MAINTENANCE OPERATION							MA	MAINTENANCE INTERVAL	ANCE	INTER	IVAL						
	Miles x 1,000	3.75	7.5	11.25	15	18.75	11.25 15 18.75 22.5 26.25	3.25	30 33	.75 37	30 33.75 37.5 41.25	5 45	48.75	45 48.75 52.5 56.25	6.25	09	
Perform at number of miles, kilometers or months, whichever comes first.	$(km \times 1,000)$	(9)	(12)	(18)	(24)	(30)) (9E)	(42) (48)		(54) (6	(99) (09)	(72)	(78)	(84)	(06)	(96)	Reference page
	Months	ო	9	6	12	15	9 12 15 18 21 24	21 ,		27	30 33	98	39	42 45		48	
Emission control system maintenance	a																

Drive belts					ļ			*_		•						I* MA-10
Air cleaner filter	See NOTE (1)							[8]								[R] MA-12
Positive crankcase ventilation (PCV) filter	See NOTE (2)			İ				E.								
Vapor lines								*_							'	
Fuel lines								*_								* MA-12
Fuel filter	See NOTE (2)*															MA-12
Engine coolant	See NOTE (3)														-	R* MA-11
Engine oil		œ	œ	~	н	E E	~	œ	<u>«</u>	Œ	æ	ш	m	<u>~</u>	_ 	R MA-13
Engine oil filter		ш	Œ	æ	- H	8	~	œ	Œ	Œ	æ	Œ	æ	<u>_</u>		R MA-13
Spark plugs								E							=	[R] MA-14
Chassis and body maintenance	and the second s															; , , ,
Brake lines & cables					_							_				I MA-20
Brake pads, rotors, drums & linings			_		_				i	-				_		I MA-20
Automatic transmission, transfer fluid & manual transmission, differential gear oil (exc. LSD)	See NOTE (4)				_			-				_			i	I MA-16, 17, 18, 19
Limited-slip differential (LSD) gear oil	See NOTE (4)				_			Œ			İ	_			-	R MA-19
Steering gear (box) & linkage, (steering damper ट्राइट्र), axle & suspension parts	axle & suspension parts		_		_	_		-		-		-		_		I MA-21, FA-5, RA-4
Drive shaft boots & propeller shaft (Exer)			_			_		-		-		-		-		I MA-18, FA-14. PD-9
Steering linkage ball joints & front suspension ball joints			_		_	_		-		_				_		I MA-21, FA-5
Front wheel bearing grease (4x2)								-								I FA-6
Front wheel bearing grease & free-running hub grease (EXC)	See NOTE (5)							Œ				_				R FA-7, 17, 18
Exhaust system			_		_	_		-				_		_		I MA-16
Air bag system	See NOTE (6)															

NOTE: (1) if operating mainly in dusty conditions, more frequent maintenance may be required.
(2) if vehicle is operated under extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high, the

filters might become clogged. In such an event, replace them immediately.

(3) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.

(4) If towing a trailer, using a camper or a car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil at every 30,000 miles (48,000 km) or 24 months except for LSD. Change LSD gear oil every 15,000 miles (24,000 km) or 12 months.

(5) If operating frequently in water, replace grease every 3,750 miles (6,000 km) or 3 months.

(5) If operating frequently in water, replace grease every specification of the FMVSS certification label.
(6) Inspect the air bag system 10 years after the date of manufacture noted on the FMVSS certification. The owner need not perform such maintenance in ★ Maintenance items and intervals with "*" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance items and intervals are required.
order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

Abbreviations: R ≈ Replace 1 = Inspect. Correct or replace if necessary.

Schedule 2

]: At the mileage intervals only

Correct or replace if necessary.

Abbreviations: B = Replace | = Inspect.

MAINTENANCE OPERATION				MAIN	MAINTENANCE INTERVAI	AHTM H	17/4			
	Miles x 1,000	7.5	15	22.5	90	37.5	45	52 5	Ĝ	
Perform at number of miles, kilometers or months, whichever comes first	(km × 1,000)	(12)	(24)	(36)	(48)	(99)	(72)	(84)	(96)	Reference page
	Months	့် မှ	12	18	24	98	36	42	48	
Emission control system maintenance									ŀ	:
Drive belts					*-				-	MA-10
Air cleaner filter					[R]				Œ	MA-12
Positive crankcase ventilation (PCV) filter	See NOTE (1)				[R]				Œ	MA-15
Vapor lines					-				<u>*</u>	MA-15
Fuel lines					-				<u>*</u>	MA-12
Fuel filter	See NOTE (1)*							:		MA-12
Engine coolant	See NOTE (2)								ř.	MA-11
Engine oil		Œ	æ	۳.	α	æ	æ	Œ	æ	MA-13
Engine oil filter		œ		æ	œ	ж	Œ	Œ	щ	MA-13
Spark plugs					[H]				 E	MA-†4
Chassis and body maintenance								i		
Brake lines & cables			_		_		_		-	MA-20
Brake pads, rotors, drums & linings			_		_		_		-	MA-20
Automatic transmission, transfer fluid & manual transmission, differential g	on, differential gear oil (exc. LSD)		_		_		_		_	MA-16, 17, 18, 19
Limited-slip differential (LSD) gear oil			-		ш		_		۳	MA-19
Steering gear (box) & linkage, (steering damper EXG), axle & suspension parts	xle & suspension parts				_				-	MA-21, FA-5, RA-4
Drive shaft boots & propeller shaft (EXET)			_		_		_		_	MA-18, FA-14, PD-9
Steering linkage ball joints & front suspension ball joints									_	MA-21, FA-5
Front wheel bearing grease (4x2)					_				-	FA-6
Front wheel bearing grease & free-running hub grease (232)	(🖼		_		œ		_		<u>~</u>	FA-7, 17, 18
Exhaust system					_				_	MA-16
Air bag system	See NOTE (3)									

MA-7

filters might become clogged. In such an event, replace them immediately.

(2) After 60,000 miles (96,000 km) or 48 months, replace every 30,000 miles (48,000 km) or 24 months.

(3) Inspect the air bag system 10 years after the date of manufacture noted on the FMVSS certification label.

★ Maintenance items and intervals with "**" are recommended by NISSAN for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

GI

MA

LС

EC

FE

GL

MT

AT

TF

PD

FA

BR

ST

R\$

BT

HA

EL

IDX

RECOMMENDED FLUIDS AND LUBRICANTS

Fluids and Lubricants

			С	apacity (Approximate	e)	
			US measure	lmp measure	Liter	Recommended Fluids and Lubricants
Engine oil (Refill)						-
2WD	With oil filte	r	4-1/8 qt	3-3/8 qt	3.9	· ·
2000	Without oil	filter	3-3/4 qt	3-1/8 qt	3.5	API SG or SH and Energy Con-
4WD	With oil filte	r	4-3/8 qt	3-5/8 qt	4.1	 serving II*1 API Certification Mark*1
4000	Without oil	filter	4 qt	3-3/8 qt	3.8	
Cooling system (With reservo	ir)					
		2WD	8-5/8 qt	7-1/8 qt	8.1	Antifreeze coolant
		4WD	9-1/2 qt	7-7/8 qt	9.0	(Ethylene glycol base) 50/50 mixture
Manual transmission and all	ECEWA710	2WD	4-1/4 pt	3-1/2 pt	2.0	A.D.I. C.I. 444
Manual transmission gear oil	FS5W71C	4WD	10-3/8 pt	8-5/8 pt	4.9	API GL-4*1
Transfer fluid			2-3/8 qt	2 qt	2.2	Type DEXRON TM
Manual steering fluid			1-3/8 pt	1-1/8 pt	0.62	API GL-4*1
Differential carrier gear oil						
	H190A		3-1/8 pt	2-5/8 pt	1.5	Standard differential gear:
Rear:	C200		2-3/4 pt	2-1/4 pt	1.3	API GL-5*1 Limited-slip differential (LSD) gear:
	H233B		5-7/8 pt	4-7/8 pt	2.8	Use only LSD gear oil API GL-5 or
Front (4WD):	R180A		2-3/4 pt	2-1/4 pt	1.3	— SAE 80W-90*4 approved for Nissan LSD*5.
Automatic transmission fluid			8-3/8 qt	7 qt	7.9	Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Auto- matic Transmission Fluid (Canada)*2
D	PB48S		30.4-33.8 fl oz	31.7-35.2 fl oz	0.9-1.0	Type DEXRON™ IIE, DEXRON™ III
Power steering fluid	PB59K		33.8-37.2 fl oz	35.2-38.7 fl oz	1.0-1.1	or equivalent
Brake and clutch fluid		-		_		Genuine Nissan Brake Fluid*3 or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease	***************************************		_	_	_	NLG! No. 2 (Lithium soap base)
Free-running hub grease (Auto	o-lock)			_	_	Genuine Nissan grease or equivalent

^{*1:} For further details, see "SAE Viscosity Number".

^{*2:} Dexron® Ill/Mercon® or equivalent may also be used. Outside the continental United States and Alaska contact a NISSAN dealership for more information regarding suitable fluids, including recommended brand(s) of Dexron® Ill/Mercon® or Dexron® Ille/Mercon® Automatic Transmission Fluid.

*3: Available in mainland U.S.A. through your Nissan dealer.

^{*4:} SAE 90 is acceptable in ambient temperatures above -18°C (0°F).

^{*5:} Contact a Nissan dealer for a list of approved oils.



EM

LC

EC

FE

GL

MT

TI0003


TF

(PD)

FA

RA

BR



SAE 5W-30 viscosity oil is preferred for all temperatures. SAE 10W-30 viscosity oil may be used if the ambient temperature is above -18° C (0°F).

5W-30

10W-30

Outside Temperature Range

GASOLINE ENGINE OIL

Anticipated Before Next Oil Change

75W-90 for transmission, and 80W-90 for differential are preferable if the ambient temperature is below 40°C (104°F).

Antifreeze Coolant Mixture Ratio

The engine cooling system is filled at the factory with a high-quality, year-round, antifreeze coolant solution. The antifreeze solution contains rust and corrosion inhibitors. Additional cooling system additives are not necessary.

CAUTION:

SMA796CB

When adding or replacing coolant, be sure to use only an ethylene glycol antifreeze with the proper mixture ratio of 50% antifreeze 50% soft water.

	mperature in to	Anti- freeze	Soft water
°C	°F	neeze	water
-35	-30	50%	50%

Other types of coolant solutions may damage the cooling system.


RS

87

HA

EL

Checking Drive Belts




- Inspect for cracks, fraying, wear and oil. If necessary, replace with a new one.
- 2. Inspect drive belt deflections by pushing midway between pulleys.


Inspect drive belt deflections when engine is cold.


Adjust if belt deflections exceed the limit. Belt deflection:


Unit: mm (in)


	Used be	It deflection	Deflection of new
	Limit	Deflection after adjustment	belt
Generator	17 (0.67)	10 - 12 (0.39 - 0.47)	8 - 10 (0.31 - 0.39)
Air conditioner compressor	16 (0.63)	10 - 12 (0.39 - 0.47)	8 - 10 (0.31 - 0.39)
Power steering oil pump	15 (0.59)	9 - 11 (0.35 - 0.43)	7 - 9 (0.28 - 0.35)
Applied pushing force		98 N (10 kg, 22 lb)	











Changing Engine Coolant

WARNING:

To avoid being scalded, never change the coolant when the engine is hot.

- Move heater temperature control lever all the way to "HOT" position or the highest temperature position.
- Open drain cock at the bottom of radiator, and remove radiator cap.

Be careful not to allow coolant to contact drive belts.

- Remove cylinder block drain plug.
- Close drain cock and tighten drain plug securely.
- Apply sealant to the thread of drain plug. (1): 34 - 44 N·m (3.5 - 4.5 kg·m, 25 - 33 ft-lb)
- 5. Open air relief plug.
- Fill radiator with water and close air relief plug and radiator
- Run engine and warm it up sufficiently. 7.
- Rev engine 2 or 3 times under no-load.
- Stop engine and wait until it cools down.
- 10. Repeat step 2 through step 9 until clear water begins to drain from radiator.
- 11. Drain water.

- 12. Open radiator cap and air relief plug.
- 13. Fill radiator with coolant up to specified level.

For coolant mixture ratio, refer to MA-9.

|--|

	Coolant	capacity
	2WD	4WD
Without reservoir tank	7.3 (7-3/4, 6-3/8)	8.2 (8-5/8, 7-1/4)
Reservoir tank	0.8 (7/	/8, 3/4)

Pour coolant through coolant filler neck slowly to allow air in system to escape.

- 14. Close air relief pluq.
- 15. Remove reservoir tank, drain coolant, then clean reservoir tank.
- 16. Install reservoir tank and fill it with coolant up to "MAX" level and then install radiator cap.
- 17. Run engine and warm it up sufficiently.
- 18. Rev engine 2 or 3 times under no-load.
- 19. Stop engine and cool it down, then add coolant as necessary.
- Clean excess coolant from engine.

(G)

MA

1,6

圓例

屋の

털

@1.

MT

AT

TE

210

FA

BA

BR


ST

RS

BT

EL


[D)X



Checking Fuel Lines

Inspect fuel lines and tank for improper attachment, leaks, cracks, damage, chafing and deterioration.

If necessary, repair or replace.




CAUTION:

Tighten high-pressure rubber hose clamp so that clamp end is 3 mm (0.12 in) from hose end.

Tightening torque specifications are the same for all rubber hose clamps.

Ensure that the screw does not contact adjacent parts.




Changing Fuel Filter

WARNING:

Before removing fuel filter, release fuel pressure from fuel line.


- 1. Remove fuse for fuel pump.
- 2. Start engine.
- After engine stalls, crank engine two or three times to make sure that fuel pressure is released.
- 4. Turn ignition switch OFF and install fuse for fuel pump.



WARNING:

Use rubber gloves to prevent fuel from contacting skin when removing fuel hoses and filter.


- 5. Loosen fuel hose clamps.
- 6. Replace fuel filter.
- Be careful not to spill fuel over engine compartment. Place a shop towel to absorb fuel.
- Use a high-pressure fuel filter. Do not use a synthetic resinous fuel filter.
- When tightening fuel hose clamps, refer to "Checking Fuel Lines", MA-12.



Changing Air Cleaner Filter

The viscous paper filter does not need cleaning between replacement intervals.

64 MA-12



Changing Engine Oil

WARNING:

- Be careful not to burn yourself, as the engine oil is hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer; try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.
- Warm up engine, and check for oil leakage from engine components.
- 2. Remove drain plug and oil filler cap.
- 3. Drain oil and refill with new engine oil.

Oil specification and viscosity:


- API SG or SH and Energy Conserving II
- API Certification Mark
- Refer to "RECOMMENDED FLUIDS AND LUBRICANTS", MA-8.

Refill oil capacity (Approximately):

		Unit: & (US qt, Imp qt)
	2WD	4WD
With oil filter change	3.9 (4-1/8, 3-3/8)	4.1 (4-3/8, 3-5/8)
Without oil filter change	3.5 (3-3/4, 3-1/8)	3.8 (4, 3-3/8)

CAUTION:

- Be sure to clean drain plug and install with new washer.
 Drain plug:
 - (3.0 4.0 kg-m, 22 29 ft-lb)
- The refill capacity changes depending on the oil temperature and drain time. Use these values as a reference and be certain to check with the dipstick when changing the oil.



-KV10105900 (J34274)

- Check oil level.
- Start engine and check area around drain plug and oil filter for oil leakage.
- 6. Run engine for a few minutes, then turn it off. After several minutes, check oil level.

Changing Oil Filter

1. Remove oil filter with Tool.

WARNING:

Be careful not to burn yourself. Engine and engine oil are hot.

MA



LC

EC:

50

re

AT

MT

76

일()

FA

RA

BR

ST

RS

87


MA

ייטט ט


凮

ENGINE MAINTENANCE

Changing Oil Filter (Cont'd)




Clean oil filter mounting surface on cylinder block. Coat rubber seal of new oil filter with engine oil.



- 3. Screw in the oil filter until a slight resistance is felt, then tighten additionally more than 2/3 of a turn.
- 4. Add engine oil.


Refer to "Changing Engine Oil", MA-13.

Clean excess oil from engine.



Changing Spark Plugs

Disconnect ignition wires from spark plugs at boot.
 Do not pull on the wire.



2. Remove spark plugs with spark plug wrench.

Spark plug:

Make	NGK
Standard type	ZFR5E-11
Hot type	ZFR4E-11
Cold type	ZFR6E-11

Use standard type spark plug under normal conditions. The hot type spark plug is suitable when fouling occurs with the standard spark plug under conditions such as:

- frequent engine starts
- low ambient temperature

The cold type spark plug is suitable when spark knock occurs with the standard spark plug under conditions such as:


- extended highway driving
- frequent high engine revolution
- 3. Check plug gap of each new spark plug.

Gap: 1.0 - 1.1 mm (0.039 - 0.043 in)


 Install spark plugs. Reconnect ignition wires according to numbers indicated on them.

Spark plug:

(2.0 - 29 N·m (2.0 - 3.0 kg-m, 14 - 22 ft-lb)



ENGINE MAINTENANCE



Checking EVAP Vapor Purge Lines

 Visually inspect EVAP vapor purge lines for improper attachment and for cracks, damage, loose connections, chafing and deterioration.

Inspect fuel tank filler cap vacuum relief valve for clogging, sticking, etc.

Refer to EC section ("EVAPORATIVE EMISSION SYSTEM").

MA

GI

· ____

LG

图例

ĘC

CL

MT

AT

TF

Changing Positive Crankcase Ventilation (PCV) Filter

Remove air cleaner cover and take out PCV filter located inside air cleaner cover. Then install new PCV filter.

PD

RA

BR

ST


RS

137

HA


EL

 $\mathbb{P}\mathbb{X}$




Checking Exhaust System

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.



Checking Clutch Fluid Level and Leaks

If fluid level is extremely low, check clutch system for leaks.




Checking M/T Oil

Check for oil leakage and oil level.

Never start engine while checking oil level.

Filler plug:

(2.5 - 34 N·m (2.5 - 3.5 kg-m, 18 - 25 ft-lb)



1. Drain oil from drain plug and refill with new gear oil.

Oil grade and viscosity:

API GL-4. Refer to "RECOMMENDED FLUIDS AND

LUBRICANTS", MA-8.

Oil capacity:


FS5W71C

2WD 2.0 ℓ (4-1/4 US pt, 3-1/2 lmp pt)

4WD 4.0 ℓ (8-1/2 US pt, 7 lmp pt)

Drain plug:

(2.5 - 34 N·m (2.5 - 3.5 kg-m, 18 - 25 ft-lb)



Checking Water Entry — For 4WD models

Check water entry in the clutch housing by removing the sealing grommet whenever driving in deep water or mud.



SMA514CA

HOT Reverse side Cold: 30 - 50°C (86 - 122°F)

Checking A/T Fluid

- Warm up engine.
- Check for fluid leakage.
- 3. Before driving, fluid level can be checked at fluid temperatures of 30 to 50°C (86 to 122°F) using "COLD" range on dipstick.
- a. Park vehicle on level surface and set parking brake.
- b. Start engine and move selector lever through each gear position. Leave selector lever in "P" position.
- c. Check fluid level with engine idling.
- d. Remove dipstick and note reading. If level is at low side of either range, add fluid to the charging pipe.


Checking A/T Fluid (Cont'd)


- Reinsert dipstick into charging pipe as far as it will go.
- Remove dipstick and note reading. If reading is at low side of range, add fluid to the charging pipe.

Do not overfill.

- Drive vehicle for approximately 5 minutes in urban areas.
- Recheck fluid level at fluid temperatures of 50° to 80°C (122° to 176°F) using "HOT" range on dipstick.
- Check fluid condition.
- If fluid is very dark or smells burned, refer to AT section for checking operation of A/T. Flush cooling system after repair of A/T.
- If A/T fluid contains frictional material (clutches, bands, etc.), replace radiator and flush cooler line using cleaning solvent and compressed air after repair of A/T. Refer to LC section ("Radiator", "ENGINE COOLING SYSTEM").







Changing A/T Fluid

- Warm up A/T fluid.
- 2. Stop engine.
- Drain A/T fluid from drain plug and refill with new A/T fluid. Measure amount of fluid drained and refill with equal amount of new fluid.

Fluid grade and viscosity:

Nissan Matic "D" (Continental U.S. and Alaska) or **Genuine Nissan Automatic Transmission Fluid** (Canada). Refer to "RECOMMENDED FLUIDS AND LUBRICANTS", MA-8.

Fluid capacity (With torque converter): 7.9 (8-3/8 US qt, 7 Imp qt)

Drain plug:

💟: 29 - 39 N·m (3.0 - 4.0 kg-m, 22 - 29 ft-lb)

- Run engine at idle speed for five minutes.
- Check fluid level and condition. Refer to "Checking A/T Fluid". If fluid is still dirty, repeat steps 2 through 5, MA-16.

Checking Transfer Fluid

Check for fluid leakage and fluid level.

Automatic Transmission Fluid is used for the transfer in the factory.

Never start engine while checking fluid level.

Filler plua:

[□]: 25 - 34 N·m (2.5 - 3.5 kg-m, 18 - 25 ft-lb)

MA-17

MA

(Gli

ΞC

FE

GL.

MIT

AT

PD)

75

FA

RA

固兒

ST

RS

RT

HA

EL,


(ID)X


69

















Changing Transfer Fluid

When changing transfer fluid completely, use the following fluid.

Fluid grade:

Type DEXRON™. Refer to "RECOMMENDED

FLUIDS AND LUBRICANTS", MA-8.

Fluid capacity:

2.2 ℓ (2-3/8 US qt, 2 Imp qt)

Drain plug:

□: 25 - 34 N·m (2.5 - 3.5 kg-m, 18 - 25 ft-lb)

Checking Propeller Shaft

Check propeller shaft for damage, looseness and grease leakage.

Tightening torque: Refer to PD section.

Checking Differential Gear Oil

Check for oil leakage and oil level.


Filler plug:
Front


[**]: 39 - 59 N·m (4 - 6 kg-m, 29 - 43 ft-lb)
Rear

H190A, H233B

[**]: 59 - 98 N·m (6 - 10 kg-m, 43 - 72 ft-lb)
C200

[**]: 39 - 59 N·m (4 - 6 kg-m, 29 - 43 ft-lb)





Changing Differential Gear Oil

Drain oil from drain plug and refill with new gear oil.

Check oil level. 2.

Oil grade and viscosity: See "RECOMMENDED FLUIDS AND LUBRICANTS", MA-8.

Oil capacity:

Front

1.3 ℓ (2-3/4 US pt, 2-1/4 Imp pt)

Rear

H190A

1.5 (3-1/8 US pt, 2-5/8 lmp pt)

1.3 ℓ (2-3/4 US pt, 2-1/4 Imp pt)

H233B

2.8 £ (5-7/8 US pt, 4-7/8 Imp pt)

Drain plug:

Front

☑: 39 - 59 N·m (4 - 6 kg-m, 29 - 43 ft-lb)

Rear

(C): 59 - 98 N·m (6 - 10 kg-m, 43 - 72 ft-lb)

Limited-slip differential gear

Use only approved limited-slip differential gear oil.

Limited-slip differential identification.

(1) Lift both rear wheels off the ground.

Turn one rear wheel by hand.

(3) If both rear wheels turn in the same direction simultaneously, vehicle is equipped with limited-slip differential.

Balancing Wheels

Adjust wheel balance using the road wheel center.

Wheel balance (Maximum allowable unbalance): Refer to SDS, MA-24.

Tire Rotation



After rotating the tires, adjust the tire pressure.


Retighten the wheel nuts after the aluminum wheel has been run for the first 1,000 km (600 miles) or if a flat tire

Do not include the T-type spare tire and small size spare tire when rotating the tires.

Wheel nuts:

🔽: 118 - 147 N·m (12 - 15 kg-m, 87 - 108 ft-lb)

MA-19 71





Gi.

EM.

LC

EC

1515

CL

MIT

AT.

TF

PD)

FA RA


图图


ST

RS

TI

HA






Checking Brake Fluid Level and Leaks

If fluid level is extremely low, check brake system for leaks.

Checking Brake System

Check brake fluid lines and parking brake cables for improper attachment, leaks, chafing, abrasion, deterioration, etc.




Checking Disc Brake ROTOR

Check condition and thickness.


Minimum thickness:

CL28VA 20 mm (0.79 in) CL28VD 24 mm (0.94 in)



CALIPER


Check for leakage.



PAD

Measure wear and check for damage.

Minimum thickness: 2 mm (0.08 in)



Checking Drum Brake

WHEEL CYLINDER

Check for leakage.


DRUM

Check condition and inner surface.

Drum repair limit (Maximum inner diameter):

LT26B 261.5 mm (10.30 in)

LT30A 296.5 mm (11.67 in)



Checking Drum Brake (Cont'd) LINING

Measure wear and check for damage.

Lining wear limit (Minimum thickness):

1.5 mm (0.059 in)

G|

MA

LC

EC

FE

Checking Steering Gear and Linkage STEERING GEAR

 Check gear housing and boots for looseness, damage and grease leakage.

Check connection with steering column for looseness.



 Check ball joint, dust cover and other component parts for looseness, wear, damage and grease leakage.

GL



MT

AT

Checking Power Steering Fluid and Lines

Check fluid level with engine off.

Check fluid level with dipstick on reservoir cap. Use "HOT" range at fluid temperatures of 50 to 80°C (122 to 176°F). Use "COLD" range at fluid temperatures of 0 to 30°C (32 to 86°F).

PD

CAUTION:

SMA442B

SST280B

Do not overfill.

 Recommended fluid is Automatic Transmission Fluid type "DEXRONTM IIE", "DEXRONTM III" or equivalent.



FA

RA

Check lines for improper attachment, leaks, cracks, damage,

loose connections, chafing and deterioration.

Shi

RS

D5:


BŢ

. . . .

HA

ĒL

1DX



(On vehicle)

80°C - 176ºF

ŏ

HOT: 50 -

• Che

SMA660B

Checking Steering Gear Oil Level and Leaks

Check steering gear for oil level and leakage.

Check oil level.


Oil level:

Distance "A"


20 mm (0.79 in) or less

Be careful not to overflow gear oil when filling up.

Lubricating Hood Latches, Locks and Hinges



Checking Seat Belts, Buckles, Retractors, Anchors and Adjusters



AMA088

HA

[D)X

Gi

MA-23 75

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Maintenance

INSPECTION AND ADJUSTMENT

Drive belt deflection

Unit: mm (in)

			01110
	Used belt deflection		Deflection of
	Limit	Deflection after adjustment	Deflection of new belt
Generator	17 (0.67)	10 - 12 (0.39 - 0.47)	8 - 10 (0.31 - 0.39)
Air conditioner compressor	16 (0.63)	10 - 12 (0.39 - 0.47)	8 - 10 (0.31 - 0.39)
Power steering oil pump	15 (0.59)	9 - 11 (0.35 - 0.43)	7 - 9 (0.28 - 0.35)
Applied pushing force		98 N (10 kg, 22 lb)	

Spark plug		
Standard type	ZFR5E-11	
Hot type	ZFR4E-11	
Cold type	ZFR6E-11	
Plug gap	1.0 - 1.1 mm (0.039 - 0.043 in)	

Chassis and Body Maintenance

INSPECTION AND ADJUSTMENT

Wheel balance

Maximum allowable unbalance	Dynamic (At rim flange)	g (oz)	10 (0.35) (one side)
	Static	g (oz)	20 (0.71)

ENGINE MECHANICAL (6)

SECTION EM

MA

EM

LC

EC

CONTENTS

PRECAUTIONS	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
Parts Requiring Angular Tightening	
Liquid Gasket Application Procedure	2
PREPARATION	3
Special Service Tools	3
Commercial Service Tools	5
OUTER COMPONENT PARTS	6
COMPRESSION PRESSURE	7
Measurement of Compression Pressure	7
OIL PAN	8
Removal	8
Installation	8
TIMING CHAIN	10
Removal	10
Inspection	11
Installation	12

	FE
OIL SEAL REPLACEMENT14	u _,
Valve Oil Seal14	
Front Oil Seal14	C[_
Rear Oil Seal15	
CYLINDER HEAD 16	
Removal17	MIT
Disassembly19	
Inspection19	n
Assembly25	AT
Installation26	
ENGINE REMOVAL29	TF
Removal30	16
Installation31	
CYLINDER BLOCK32	PD)
Disassembly33	l E
Inspection	
Assembly39	FA
SERVICE DATA AND SPECIFICATIONS (SDS)42	
General Specifications42	
Inspection and Adjustment42	RA

77

BR

ST

RS

BT

 $\mathbb{H}\mathbb{A}$

BDX

Supplemental Restraint System (SRS) "AIR BAG"


The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.


WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Parts Requiring Angular Tightening

- Use an angle wrench for the final tightening of the following engine parts:
 - (1) Cylinder head bolts
 - (2) Connecting rod cap nuts
- Do not use a torque value for final tightening.
- The torque values for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.





Liquid Gasket Application Procedure

- a. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- b. Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
- c. Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- d. Assembly should be done within 5 minutes after coating.
- e. Wait at least 30 minutes before refilling engine oil and engine coolant.

PREPARATION

Ĝ[**Special Service Tools** The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here. MA Tool number (Kent-Moore No.) Description Tool name EM ST0501S000 Disassembling and assembling (-)Engine stand assembly (1) ST05011000 (-)Engine stand EC (2) ST05012000 (--)NT042 Base Œ KV10105001 (-)CL, Engine attachment MT NT031 KV10109250 Disassembling and assembling valve compo-AT (J26336-B) nents Valve spring compressor ① KV10109210 TE (-)Compressor ② KV10109220 (-)Adapter NT021 FA KV109B0010 Installing valve oil seal (-)Valve oil seal drift NT027 KV10110300 Disassembling and assembling piston with $\mathbb{B}\mathbb{R}$ connecting rod (--) Piston pin press stand assembly ST (1) KV10110310 (-)Cap RS (2) KV10110330 (-)Spacer BT (3) ST13030020 (-)Press stand HA (4) ST13030030 (-)Spring (5) KV10110340 (-)Drift **6** KV10110320 (-)Center shaft NT036

PREPARATION

	Special Service Tools (Cont'd)		
Tool number (Kent-Moore No.) Tool name	Description		
EM03470000 (J8037) Piston ring compressor	NT044	Installing piston assembly into cylinder bore	
(J36467) Valve oil seal remover	NT034	Displacement valve oil seal	
ST16610001 (J23907) Pilot bushing puller	NT045	Removing crankshaft pilot bushing	
KV10111100 (J37228) Seal cutter	NT046	Removing oil pan	
WS39930000 (—) Tube presser	NT052	Pressing the tube of liquid gasket	
(V10105800 (J25660-C) Chain stopper	NT010	Holding the timing chain	
KV10112100 (BT8653-A) Angle wrench	NT014	Tightening bolts for bearing cap, cylinder head, etc.	

PREPARATION

Commercial Service Tools			Gi
Tool name	Description		. 200
Spark plug wrench	P	Removing and installing spark plug	· MA
	16 mm		EM
	(0.63 in) NT047		LG
Pulley holder		Holding camshaft pulley while tightening or loosening camshaft bolt	EC
	NT035		FE
Valve seat cutter set		Finishing valve seat dimensions	- CL
	NT048		MT
Piston ring expander		Removing and installing piston ring	
	NT030		77
Valve guide drift		Removing and installing valve guide	- PD
		Diameter mm (in)	
	ав	Intake Exhaust	FA
	#	a 10.5 (0.413) 11.5 (0.453)	
	NT015	b 6.6 (0.260) 7.6 (0.299)	RA -
Valve guide reamer		Reaming valve guide ① or hole for oversize valve guide ②	BR
	d ₁ to	Intake: $d_1 = 7.0 \text{ mm } (0.276 \text{ in}) \text{ dia.}$ $d_2 = 11.2 \text{ mm } (0.441 \text{ in}) \text{ dia.}$ Exhaust:	ST
	NT016	$d_1 = 8.0 \text{ mm } (0.315 \text{ in}) \text{ dia.}$ $d_2 = 12.2 \text{ mm } (0.480 \text{ in}) \text{ dia.}$	RS

EM-5 81


æ

BT

MA


(DX

OUTER COMPONENT PARTS



Measurement of Compression Pressure

- Warm up engine.
- Turn ignition switch OFF.
- Release fuel pressure.
 Refer to EC section ("Fuel Pressure Release", "BASIC SER-VICE PROCEDURE").
- Remove all spark plugs.
- Disconnect distributor center cable.



6. Attach a compression tester to No. 1 cylinder.

- Depress accelerator pedal fully to keep throttle valve wide open.
- 8. Crank engine and record highest gauge indication.
- 9. Repeat the measurement on each cylinder.
- Always use a fully-charged battery to obtain specified engine speed.

Compression pressure:
kPa (kg/cm², psi)/rpm
Standard
1,324 (13.5, 192)/300
Minimum
981 (10, 142)/300
Difference limit between cylinders
98 (1.0, 14)/300

- 10. If compression in one or more cylinders is low:
- a. Pour a small amount of engine oil into cylinders through spark plug holes.
- B. Retest compression.
- If adding oil helps compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.
- If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. (Refer to SDS.) If valve or valve seat is damaged excessively, replace them.
- If compression stays low in two cylinders that are next to each other:
- The cylinder head gasket may be leaking, or
- Both cylinders may have valve component damage.
 Inspect and repair as necessary.

G[

MA

EM

LG

FE

GL.

3.015T

MT

AT

TE

PD)

FA

(a)


BR


RS


BT


HA


IDX











Removal

- 1. Raise vehicle and support it with safety stands.
- 2. Drain engine oil.
- Remove front stabilizer bar securing bolts and nuts from side member.
- 4. Lift engine.
- 5. Remove oil pan bolts.
- 6. Remove oil pan.
- a. Insert Tool between cylinder block and oil pan.
- Be careful not to damage aluminum mating surface.
- Do not insert screwdriver, or oil pan flange will be damaged.
- b. Slide Tool by tapping on the side of the Tool with a hammer.
- 7. Pull out oil pan from front side.


Installation

- 1. Use a scraper to remove old liquid gasket from mating surface of oil pan.
- Also remove traces of liquid gasket from mating surface of cylinder block.
- Apply a continuous bead of liquid gasket to mating surface of oil pan.
- Use Genuine Liquid Gasket or equivalent.
- Apply to groove on mating surface.
- Allow 7 mm (0.28 in) clearance around bolt hole.

OIL PAN

Install oil pan.

AEM301



Front

AEM259

Installation (Cont'd)

Be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).

Attaching should be done within 5 minutes after coating.

😭: 6.3 - 8.3 N·m (0.64 - 0.85 kg-m, 55.6 - 73.8 in-lb)

Wait at least 30 minutes before refilling engine oil.

Tighten oil pan bolts in numerical order.

Install parts in reverse order of removal.



MA

LC

EG

院

GL.

MIT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST

RS

BT

MA

IDX



CAUTION:


- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing rocker arms, camshafts, chain tensioner, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to bolt threads and seat surfaces when installing cylinder head, camshaft sprockets, crankshaft pulley, and camshaft brackets.

Removal

- Disconnect battery terminal.
- 2. Drain coolant from radiator.
- 3. Remove radiator shroud and cooling fan.
- 4. Remove the following belts.
- Power steering drive belt
- Compressor drive belt
- Generator drive belt

TIMING CHAIN

Removal (Cont'd)



5. Remove all spark plugs.





 $\mathbb{M}\mathbb{A}$

ΕM

[LC

Remove the following parts.
Power steering pump, idler pulley and power steering pump

Compressor idler pulley

Crankshaft pulley with a suitable puller

Oil pump with pump drive spindle

Rocker cover

SEM200C

brackets

티

ĒC,

C[_

MT

ATi'

Remove oil pan. (Refer to OIL PAN, EM-9.)

9. Remove front cover.

 Inspect for oil leakage at front oil seal. Replace seal if oil leak is present.

TF

FA

RA

For retiming during cylinder head removal/installation, apply paint mark to timing chain at mating mark of cam-

Chain tensioner

shaft sprocket.

Chain guides

Timing chain and camshaft sprocket

10. Remove the following parts.

Oil thrower, oil pump drive gear and crankshaft sprocket


\$T


RS

Inspection


Check for cracks and excessive wear at roller links. Replace chain if necessary.


BT





Paint mark on chain Camshaft sprocket Paint mark on chain Paint mark on chain Paint mark on chain Paint mark





Installation

- 1. Install crankshaft sprocket, oil pump drive gear and oil thrower.
- Make sure that mating marks on crankshaft sprocket face front of engine.


- 2. Install camshaft sprocket.
- Confirm that No. 1 piston is set at TDC on its compression stroke.
- 4. Install timing chain.
- Set timing chain by aligning paint marks with mating marks of crankshaft sprocket and camshaft sprocket.

- 5. Tighten camshaft sprocket bolt.
- 6. Install chain guide and chain tensioner.


- Use a scraper to remove old liquid gasket from mating surface of front cover.
- Also remove traces of liquid gasket from mating surface of cylinder block.

③

TIMING CHAIN



Installation (Cont'd)



Use Genuine Liquid Gasket or equivalent.

Be sure to install new front oil seal in the right direction. Refer to EM-14.

Apply lithium grease to sealing lip of crankshaft oil seal.



(H

EM

LC

EG

10. Install front cover.

Be careful not to damage cylinder head gasket. Be careful not to damage front oil seal when installing

front cover.

11. Install new rubber plug. (Refer to "Installation", CYLINDER HEAD, EM-27.)



FE

12. Install oil pan. (Refer to OIL PAN, EM-9.)



13. Install oil pump and distributor driving spindle with new gasket in front cover.

a. Assemble oil pump and driving spindle, aligning punchmark on driving spindle with oil hole.





FA

RA



ST




RS

BT

HA

EL




Front (

SEM453C


SEM136C


Make sure that driving spindle is set as shown in figure.




14. Install distributor.

15. Make sure that No. 1 piston is set at TDC and that distributor rotor is set at No. 1 cylinder spark position.





- Valve oil seal 15.6 - 16.2 (0.614 - 0.638) Valve spring seat 1.0 (0.039) Unit: mm (in) SEM397E
- ÅEM258



Valve Oil Seal

- Remove rocker cover.
- Remove rocker shaft assembly. (Refer to "Disassembly", CYLINDER HEAD, EM-19.)
- Remove valve spring and valve oil seal with Tool or suitable
- Piston concerned should be set at TDC to prevent valve from falling.
- Apply engine oil to new valve oil seal and install it with Tool.
- Before installing valve oil seal, install valve spring seat.


Front Oil Seal

- Remove radiator shroud and crankshaft pulley.
- Remove front oil seal.
- Be careful not to scratch front cover.

- Apply engine oil to new oil seal and install it using suitable tool.
- Install new oil seal in the direction shown.

EM-14

OIL SEAL REPLACEMENT



Rear Oil Seal

Remove flywheel or drive plate.

Remove rear oil seal retainer.

Remove rear oil seal from retainer.

Be careful not to scratch rear oil seal retainer.



GP

 EM

LC

Apply engine oil to new oil seal and install it using suitable tool.

Install new oil seal in the direction shown.



CL

MT

AT

TF

 $\mathbb{P}\mathbb{D}$

FA

RA

Before installing rear oil seal retainer, remove all traces of liquid gasket from mating surface using a scraper.

88

Also remove traces of liquid gasket from mating surface of cylinder block.



RS





Apply a continuous bead of liquid gasket to mating surface of rear oil seal retainer.


HA


Use Genuine Liquid Gasket or equivalent.

10X












Install rear oil seal retainer.

SEC. 111-130







CAUTION:

0

When installing rocker arms, camshaft and oil seal, lubricate contacting surfaces with new engine oil.

When tightening cylinder head bolts and rocker shaft bolts, lubricate bolt threads and seat surfaces with new engine oil.

 Hydraulic valve lifters are installed in each rocker arm. If hydraulic valve lifter is kept on its side, even when installed in rocker arm, there is a risk of air entering it. When rocker arms are removed, stand them straight up or soak them in new engine oil.

Do not disassemble hydraulic valve lifter.

Attach tags to valve lifters so as not to mix them up.

G

EM

....

LC

EC

FE

CL

MT

AT

TIF

PD

FA

RA

BR

Removal

- Release fuel pressure. Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").
- Drain coolant from radiator and drain plug of block.
- 3. Remove the following parts.
- Power steering drive belt
- Power steering pump, idler pulley and power steering brackets
- Vacuum hoses of swirl control valve and pressure control solenoid valve
- Accelerator wire bracket
- Disconnect EGR tube from exhaust manifold.
- Remove bolts which hold intake manifold collector to intake manifold.
- Remove bolts which hold intake manifold to cylinder head while raising collector upwards.
- 7. Remove rocker cover.
- When removing rocker cover, do not hit rocker cover against rocker arm.

RS

ST


Set No. 1 piston at TDC on its compression stroke.

HA

BT


EL

[DX




EM-17

Removal (Cont'd)




Make sure No. 1 cylinder is at TDC by looking at the distributor rotor position.




9. Loosen camshaft sprocket bolt.

Support timing chain by using Tool as shown in figure.




10. Remove camshaft sprocket.


 For retiming during installation, apply paint marks to timing chain at mating marks of crankshaft sprocket and camshaft sprocket.





11. Remove front timing cover to cylinder head bolts.



- 12. Remove cylinder head.
- Loosen in numerical order.
- A warped or cracked cylinder head could result from removing in incorrect order.
- Loosen cylinder head bolts in two or three steps.







Disassembly

Remove rocker shaft assembly.

a. When loosening bolts, evenly loosen as shown in figure at left.

b. Bolts should be loosened in two or three steps.

2. Remove camshaft.

 Before removing camshaft, measure camshaft end play. (Refer to "Inspection".)

EM ⁄.

LC

(G1

B. Remove valve components with Tool.

 Remove valve oil seals. (Refer to OIL SEAL REPLACEMENT, EM-14.)

FE

GL.

MT

AT.

TF

EC.

Inspection

CYLINDER HEAD DISTORTION

Clean surface of cylinder head.

Use a reliable straightedge and feeler gauge to check the flat-

ness of cylinder head surface.

Check along six positions shown in figure.

PD

EA

Head surface flatness:

Standard

Less than 0.03 mm (0.0012 in)

Limit

0.1 mm (0.004 in)

If beyond the specified limit, replace or resurface.

RR

BR

ST

RS

Resurfacing limit:

The limit for cylinder head resurfacing is determined by the cylinder block resurfacing.

Amount of cylinder head resurfacing is "A"

Amount of cylinder block resurfacing is "B"

The maximum limit is as follows:

A + B = 0.2 mm (0.008 in)

After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.

Nominal cylinder head height:

98.8 - 99.0 mm (3.890 - 3.898 in)


BT

CAMSHAFT VISUAL CHECK


Check camshaft for scratches, seizure and wear.

EL

Inspection (Cont'd) CAMSHAFT RUNOUT



- Measure camshaft runout at the center journal.
 - Runout (Total indicator reading): 0 - 0.02 mm (0 - 0.0008 in)
- 2. If it exceeds the limit, replace camshaft.



CAMSHAFT CAM HEIGHT


- 1. Measure camshaft cam height.
 - Standard cam height:

44.43 - 44.58 mm (1.7492 - 1.7551 in)

Cam height wear limit:

0.2 mm (0.008 in)

2. If wear is beyond the limit, replace camshaft.




CAMSHAFT JOURNAL CLEARANCE

- 1. Install camshaft bracket and rocker shaft and tighten bolts to the specified torque.
- 2. Measure inner diameter of camshaft bearing.

Standard inner diameter:

33.000 - 33.025 mm (1.2992 - 1.3002 in)



3. Measure outer diameter of camshaft journal.

Standard outer diameter:

32.935 - 32.955 mm (1.2967 - 1.2974 in)

 If clearance exceeds the limit, replace camshaft and/or cylinder head.


Camshaft journal clearance:

Standard

0.045 - 0.090 mm (0.0018 - 0.0035 in)

Limit

0.12 mm (0.0047 in)



CAMSHAFT END PLAY

- Install camshaft in cylinder head.
- Measure camshaft end play.

Camshaft end play:


Standard

0.07 - 0.15 mm (0.0028 - 0.0059 in)

Limit

0.2 mm (0.008 in)

- 3. If end play exceeds the limit, replace camshaft and remeasure camshaft end play.
- If end play still exceeds the limit after replacing camshaft, replace cylinder head.





Install sprocket on camshaft.

2. Measure camshaft sprocket runout.

Runout (Total indicator reading): Limit 0.12 mm (0.0047 in)

. If it exceeds the limit, replace camshaft sprocket.




MA

EM

LC

EC



VALVE GUIDE CLEARANCE

 Measure valve deflection as shown in illustration. (Valve and valve guide wear the most in this direction.)

Valve deflection limit (Dial gauge reading): 0.15 mm (0.0059 in)

CL.

Mt.


AT

TF

PD

FA

RA



2. If it exceeds the limit, check valve to valve guide clearance.

a. Measure valve stem diameter and valve guide inner diameter.

b. Check that clearance is within specification.

Valve to valve guide clearance = valve guide inner diameter - valve stem diameter:

Standard

Intake

0.020 - 0.053 mm (0.0008 - 0.0021 in)

Exhaust

0.040 - 0.070 mm (0.0016 - 0.0028 in)

Limit 0.1 mm (0.004 in)

c. If it exceeds the limit, replace valve and remeasure clearance.

 If clearance still exceeds the limit after replacing valve, replace the valve guide.

ST

RS

BT


 $\mathbb{H}\mathbb{A}$

EL

IDX


EM-21

97




Inspection (Cont'd) VALVE GUIDE REPLACEMENT

 To remove valve guide, heat cylinder head to 150 to 160°C (302 to 320°F).




2. Drive out valve guide using a hammer and suitable tool or a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 lmp ton) pressure].



3. Ream cylinder head valve guide hole.

Valve guide hole diameter (for service parts): Intake 11.175 - 11.196 mm (0.4400 - 0.4408 in) Exhaust 12.175 - 12.196 mm (0.4793 - 0.4802 in)



4. Heat cylinder head to 150 to 160°C (302 to 320°F) and press service valve guide onto cylinder head.

Projection "L":

14.9 - 15.1 mm (0.587 - 0.594 in)

5. Ream valve guide.


Finished size:

Intake

7.000 - 7.018 mm (0.2756 - 0.2763 in)

Exhaust


8.000 - 8.018 mm (0.3150 - 0.3157 in)





VALVE SEATS


Check valve seats for pitting at contact surface. Resurface or replace if excessively worn.


- Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.
- Use both hands to cut uniformly.











Inspection (Cont'd) REPLACING VALVE SEAT FOR SERVICE PARTS

Bore out old seat until it collapses. Set machine depth stop so that boring cannot contact bottom face of seat recess in cylinder head.

Ream cylinder head recess.

Reaming bore for service valve seat Oversize [0.5 mm (0.020 in)]: Intake 36.500 - 36.516 mm (1.4370 - 1.4376 in) Exhaust 42.500 - 42.516 mm (1.6732 - 1.6739 in)

Use the valve guide center for reaming to ensure valve seat will have the correct fit.

3. Heat cylinder head to 150 to 160°C (302 to 320°F).

Press fit valve seat until it seats on the bottom.

Cut or grind valve seat using suitable tool of the specified dimensions. Refer to SDS, EM-43.

After cutting, lap valve seat with abrasive compound.

Check valve seating condition.

Seat face angle " α ":

45 deg.

Contacting width "W": Intake

1.6 - 1.7 mm (0.063 - 0.067 in)

1.7 - 2.1 mm (0.067 - 0.083 in)

VALVE DIMENSIONS

Check dimensions of each valve. Refer to SDS, EM-44.

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

less.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or

ΞV

MA

@[

ĒC,

CL.

MIT

TF

PD

FA

BA


ST


BR

RS.

BT

HA





Inspection (Cont'd) **VALVE SPRING**

Squareness

Measure dimension "S".

Out-of-square "S":

Outer

Intake Less than 2.5 mm (0.098 in) Exhaust Less than 2.3 mm (0.091 in)

Inner

Intake Less than 2.3 mm (0.091 in) Exhaust Less than 2.1 mm (0.083 in)

2. If it exceeds the limit, replace spring.

Pressure

Check valve spring pressure at specified spring height.

Pressure: N (kg, lb) at height mm (in)

Standard

Outer

Intake 604.1 (61.6, 135.8) at 37.6 (1.480)

Exhaust 640.4 (65.3, 144.0) at 34.1 (1.343)

Intake 284.4 (29.0, 63.9) at 32.6 (1.283)

Exhaust 328.5 (33.5, 73.9) at 29.1 (1.146)

Limit


Intake 567.8 (57.9, 127.7) at 37.6 (1.480)

Exhaust 620.8 (63.3, 139.6) at 34.1 (1.343)

Intake 266.8 (27.2, 60.0) at 32.6 (1.283)

Exhaust 318.7 (32.5, 71.7) at 29.1 (1.146)

If it exceeds the limit, replace spring.




ROCKER SHAFT AND ROCKER ARM

- Check rocker shafts for scratches, seizure and wear.
- Check outer diameter of rocker shaft.

Diameter:

21.979 - 22.000 mm (0.8653 - 0.8661 in)




Diameter:


22.012 - 22.029 mm (0.8666 - 0.8673 in)


Rocker arm to shaft clearance:


0.012 - 0.050 mm (0.0005 - 0.0020 in)

Keep rocker arm with hydraulic valve lifter standing to prevent air from entering hydraulic valve lifter when checking.












install valve component parts.

Always use new valve oil seal. Refer to OIL SEAL REPLACEMENT.

Before installing valve oil seal, install inner valve spring


Install outer valve spring (uneven pitch type) with its narrow pitch side toward cylinder head side.

After installing valve component parts, use plastic hammer to lightly tap valve stem tip to assure a proper fit.





Apply engine oil to camshaft when mounting onto cylinder

Install camshaft brackets. Front mark is punched on the camshaft brackets.











G1

GL

MT

AT

TF

PD

FA

RA

BR


ST

RS

BT


HA.


IDX




Assembly (Cont'd)


5. Tighten bolts as shown in figure at left.






SEM216C








Installation

- 1. Set No. 1 piston at TDC on its compression stroke as follows:
- Align mark on crankshaft pulley with "0°" position and confirm that distributor rotor head is set as shown in figure.

b. Confirm that knock pin on camshaft is set at the top.

- Install cylinder head with new gasket and tighten cylinder head bolts in numerical order.
- Do not rotate crankshaft and camshaft separately, or valves will hit piston heads.
- Tightening procedure
- a. Tighten all bolts to 29 N·m (3.0 kg-m, 22 ft-lb).
- b. Tighten all bolts to 78 N·m (8.0 kg-m, 58 ft-lb).
- c. Loosen all bolts completely.
- d. Tighten all bolts to 29 N·m (3.0 kg-m, 22 ft-lb).
- e. Turn all bolts 80^{+5}_{-0} degrees clockwise with an angle wrench. If an angle wrench is not available, tighten all bolts to 74 to 83 N·m (7.5 to 8.5 kg-m, 54 to 61 ft-lb).

Installation (Cont'd)



Set chain on camshaft sprocket by aligning each mating mark. Then install camshaft sprocket to camshaft.

MA

Œ[

LC

Tighten camshaft sprocket bolt.

EC

FE

GL

MI

Mi.

Rubber plugs should be replaced with new ones.

applying liquid gasket.

PD

FA

RA


RS

BT.

HA

EL

JDX




SEM207C

SEM931B

Install rubber plugs as follows: Apply liquid gasket to rubber plugs.

Rubber plugs should be installed within 5 minutes of



Liquid gasket

3 mm (0.12 in) diameter (liquid gasket)


> Install rubber plugs, then move them with your fingers to uniformly spread the gasket on cylinder head surface.

Rubber plugs should be installed flush with the surface.


Do not start the engine for 30 minutes after installing rocker cover.

Wipe away excessive liquid gasket from cylinder head top surface.


SEM932B



Installation (Cont'd)




- 6. Check hydraulic valve lifter.
- a. Push hydraulic valve lifter forcefully with your finger.
- Be sure to check it with rocker arm in its free position.
- b. If valve lifter moves more than 1 mm (0.04 in), air may be inside of it.
- Bleed air off by running engine at 1,000 rpm under no load for about 20 minutes.
- d. If hydraulic valve lifters are still noisy, replace them and bleed air off again in the same manner as in step c.




7. Install rocker cover.

SEM275C

- Be sure to avoid interference between rocker cover and rocker arm.
- 8. Tighten bolts as follows:
- Tighten two bolts to 3 N·m (0.3 kg-m, 26 in-lb) temporarily in order shown in figure.



- b. Then tighten bolts to 7 to 11 N·m (0.7 to 1.1 kg-m, 61 to 95 in-lb) in order shown in figure.
- 9. Install any parts removed.



MEM195A

WARNING:

- Position vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled off.
 Otherwise, you may burn yourself and/or fire may break

out in fuel line.

- Before disconnecting fuel hose, release fuel pressure.
 Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").
- Be sure to hoist engine and transmission in a safe manner.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

CAUTION:


- When lifting engine, be sure to clear surrounding parts.
 Take special care near accelerator wire casing, brake lines and brake master cylinder.
- In hoisting the engine, always use engine slingers in a safe manner.
- Before separating engine and transmission, remove the crankshaft position sensor (OBD) from the assembly.
- Always take extra care not to damage edge of crankshaft position sensor (OBD) or ring gear teeth.


Removal

- Drain coolant from engine block and radiator. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTE-NANCE").
- 2. Release fuel pressure. Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").
- Remove negative battery cable.
- 4. Remove hood. Refer to BT section.
- Remove power steering drive belt, generator drive belt and A/C compressor drive belt
- 6. Remove radiator. Refer to LC section ("Radiator", "ENGINE COOLING SYSTEM").
- 7. Remove exhaust manifold heat shield.
- 8. Disconnect exhaust system from exhaust manifold.
- 9. Discharge refrigerant. Refer to HA section ("R-134a Service Procedure", "SERVICE PROCEDURES").
- 10. Disconnect refrigerant lines. Refer to HA section ("Refrigerant Lines", "SERVICE PROCEDURES").
- 11. Disconnect accelerator wire, vacuum hoses, electrical connectors, heater hoses and vacuum booster hose.

ENGINE REMOVAL

Removal (Cont'd)





- 12. Remove four power steering pump bolts.
- 13. Disconnect A/T dipstick tube and A/T throttle wire. (A/T models only)
- 14. Remove transmission Refer to MT or AT section ("Removal", "REMOVAL AND INSTALLATION").
- 15. Remove LH and RH engine mounts.



MA

(H)

LC

EC

뜐딭

CL.

MT

ÆΠ

TE

PD)

凮

RA


BR

ST

R\$

BT

16. Remove engine.




Installation

Install in reverse order of removal.

MA

ľDX

SEC. 110-120-135-150-210




CAUTION:

- When installing sliding parts (bearings, pistons, etc.), lubricate contacting surfaces with new engine oil.
- Place removed parts such as bearings and bearing caps in their proper order and direction.
- When installing connecting rod nuts and main bearing cap bolts, apply new engine oil to threads and seating surfaces.
- Do not allow any magnetic materials to contact the ring gear teeth of flywheel or drive plate.




PISTON AND CRANKSHAFT

- I. Place engine on a work stand.
- 2. Drain coolant and oil.
- 3. Remove oil pan.
- 4. Remove timing chain.
- 5. Remove water pump.
- 6. Remove cylinder head.
- 7. Remove pistons with connecting rod.



- Before removing bearing caps, measure crankshaft end play. Refer to EM-40.
- Bolts should be loosened in two or three steps.



9

ST0501S000

(5)

1

KV10105001

7

SEM744

Inspection

PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".

Standard diameter "dp":

21.002 - 21.008 mm (0.8268 - 0.8271 in)

. Measure outer diameter of piston pin "Dp".


Standard diameter "Dp":


20.994 - 20.996 mm (0.8265 - 0.8266 in)

Calculate piston pin clearance.
 dp - Dp = 0.008 - 0.012 mm (0.0003 - 0.0005 in)

If it exceeds the above value, replace piston assembly with pin.









GI

ΕM

LC

ĒC

FE

@I

CL

MT

AT

TF

PD

FA

RA

3R

ST


RS


87

HA

מריעש ט

IDX





Inspection (Cont'd)

PISTON RING SIDE CLEARANCE

Side clearance:

Top ring 0.04 - 0.08 mm (0.0016 - 0.0031 in) 2nd ring 0.03 - 0.07 mm (0.0012 - 0.0028 in) Oil ring 0.065 - 0.135 mm (0.0026 - 0.0053 in)

Max. limit of side clearance:

0.1 mm (0.004 in)

If out of specification, replace piston ring.

If clearance exceeds maximum limit with new ring, replace piston.

PISTON RING END GAP

End gap:

Top ring

0.28 - 0.52 mm (0.0110 - 0.0205 in)

2nd rina

0.45 - 0.69 mm (0.0177 - 0.0272 in)

(R or T is punched on the ring.)

0.55 - 0.70 mm (0.0217 - 0.0276 in)

(N is punched on the ring.)


Oil ring


0.20 - 0.69 mm (0.0079 - 0.0272 in)

Max. limit of ring gap: 0.5 mm (0.020 in)

If out of specification, replace piston ring. If gap exceeds maximum limit with a new ring, rebore cylinder and use oversized piston and piston rings. Refer to SDS, EM-46.

When replacing the piston, check cylinder block surface for scratches or seizure. If scratches or seizure are found, hone or replace the cylinder block.





CONNECTING ROD BEND AND TORSION

Bend:

Limit 0.15 mm (0.0059 in)


per 100 mm (3.94 in) length

Torsion:

Limit 0.3 mm (0.012 in)

per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.



Inspection (Cont'd)

CYLINDER BLOCK DISTORTION AND WEAR

Clean upper face of cylinder block. Use a reliable straightedge and feeler gauge to check the flatness of cylinder block surface. Check along six positions shown in figure.

Limit:

0.1 mm (0.004 in)


If out of specification, resurface it. The limit for cylinder block resurfacing is determined by cylinder head resurfacing.


Amount of cylinder head resurfacing is "A" Amount of cylinder block resurfacing is "B" The maximum limit is as follows:

> A + B = 0.2 mm (0.008 in)Nominal cylinder block height from crankshaft center:


246.95 - 247.05 mm (9.7224 - 9.7264 in)

3. If necessary, replace cylinder block.





SEM257C



PISTON-TO-BORE CLEARANCE

Using a bore gauge, measure cylinder bore for wear, out-ofround and taper.

Standard inner diameter:

Refer to SDS. EM-42. Wear limit: 0.2 mm (0.008 in)

Out-of-round (X - Y) standard: 0.015 mm (0.0006 in)

Taper (A – B) standard: 0.015 mm (0.0006 in)

If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.

Check for scratches and seizure. If seizure is found, hone it.

If cylinder block and piston are replaced, match piston grade with grade number on cylinder block upper surface.

Measure piston skirt diameter.

Piston diameter "A":

Refer to SDS, EM-46.

Measuring point "a" (Distance from the top):

Approximately 52 mm (2.05 in)

Check that piston-to-bore clearance is within specification.

Piston-to-bore clearance "B":

0.020 - 0.040 mm (0.0008 - 0.0016 in)

Determine piston oversize according to amount of cylinder

Oversize pistons are available for service. Refer to SDS, EM-46.

MA

 $\mathsf{E} \mathsf{M}$

[LC

EC

33

CL.

腳了

Δī

TF

1919

FA

RA

88

ST

RS

Bĩ

MA

凮

[ID]X

111

Inspection (Cont'd)

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation:

D = A + B - C

where.


D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)

- 7. Install main bearing caps and tighten bolts to the specified torque. This will prevent distortion of cylinder bores.
- Cut cylinder bores.
- When any cylinder needs boring, all other cylinders must also be bored.
- Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so at a time.
- 9. Hone cylinders to obtain specified piston-to-bore clearance.
- 10. Measure finished cylinder bore for out-of-round and taper.
- Measurement should be done after cylinder bore cools down.



CRANKSHAFT

- Check crankshaft main and pin journals for score, wear or cracks.
- With a micrometer, measure journals for taper and out-ofround.

Out-of-round (X - Y):

Main journal Less than 0.01 mm (0.0004 in)


Crank pin Less than 0.005 mm (0.0002 in)


Taper (A - B):

Main journal Less than 0.01 mm (0.0004 in) Crank pin Less than 0.005 mm (0.0002 in)



Runout (Total indicator reading): Less than 0.10 mm (0.0039 in)





BEARING CLEARANCE


 Use Method A or Method B. Method A is preferred because it is more accurate.


Method A (Using bore gauge and micrometer)

Main bearing

1. Set main bearings in their proper positions on cylinder block and main bearing cap.

Inspection (Cont'd)





Measure inner diameter "A" of each main bearing.




LC

PE

C[L

MA

G



Measure outer diameter "Dm" of each crankshaft main journal.

Calculate main bearing clearance. Main bearing clearance = A - Dm

Standard:

0.020 - 0.047 mm (0.0008 - 0.0019 in)

Limit:


EEM119

0.1 mm (0.004 in) If it exceeds the limit, replace bearing.

If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.

AT

TF



When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.


"L": 0.1 mm (0.004 in)

b. Refer to SDS for grinding crankshaft and available service parts.

PD

客

RA



If crankshaft is reused, measure main bearing clearance and select thickness of main bearing.


If crankshaft or cylinder block is replaced, select thickness of main bearings as follows:

a. Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Roman numerals.

RS

HA

NDX




SEM2720

= 3 (Yellow)

Inspection (Cont'd)


Main bearing grade number and identification color:

-		Main journal grade number		
		0	1	2
Crankshaft journal grade number	0	0 (Black)	1 (Brown)	2 (Green)
	1 or l	1 (Brown)	2 (Green)	3 (Yellow)
	2 or II	2 (Green)	3 (Yellow)	4 (Blue)



Connecting rod bearing (Big end)

- 1. Install connecting rod bearing to connecting rod and cap.
- 2. Install connecting rod cap to connecting rod.
- Tighten bolts to the specified torque.
- 3. Measure inner diameter "C" of each bearing.




- 4. Measure outer diameter "Dp" of each crankshaft pin journal.
- 5. Calculate connecting rod bearing clearance.

Connecting rod bearing clearance = C - Dp: Standard

0.010 - 0.035 mm (0.0004 - 0.0014 in) Limit

0.09 mm (0.0035 in)

- 6. If it exceeds the limit, replace bearing.
- If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing. Refer to step 7 of "BEARING CLEARANCE — Main bearing".




If crankshaft is replaced, select connecting rod bearing according to the following table.

Connecting rod bearing grade number:

These numbers are punched in either Arabic or Roman numerals.


Crank pin grade number	Connecting rod bearing grade number		
0	0		
1 or l	1		
2 or II	2		





Method B (Using plastigage)


CAUTION:


- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- When bearing clearance exceeds the specified limit, ensure that the proper bearing has been installed. Then if excessive bearing clearance exists, use a thicker main bearing or undersized bearing so that the specified bearing clearance is obtained.











Inspection (Cont'd)

CONNECTING ROD BUSHING CLEARANCE (Small end)

1. Measure inner diameter "C" of bushing.

2. Measure outer diameter "Dp" of piston pin.

3. Calculate connecting rod bushing clearance.

C - Dp = -0.015 to -0.033 mm (-0.0006 to -0.0013 in) (Standard)

If out of specification, replace connecting rod assembly and/or piston set with pin.

EM

LC

EC

ME

CL

MT

(9)

FLYWHEEL/DRIVE PLATE RUNOUT

Runout (Total indicator reading):
Flywheel (M/T model)
Less than 0.1 mm (0.004 in)
Drive plate (A/T model)
Less than 0.1 mm (0.004 in)

CAUTION:

• Be careful not to damage the ring gear teeth.

Check the drive plate for deformation and cracks.

Do not allow any magnetic materials to contact the ring gear teeth.

Do not resurface the flywheel. Replace as necessary.

Assembly

PISTON

1. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin and connecting rod.

Align the direction of piston and connecting rod.

 Numbers stamped on connecting rod and cap correspond to each cylinder.

 After assembly, make sure connecting rod swings smoothly.

Set piston rings as shown.

CAUTION:

 When piston rings are not replaced, make sure that piston rings are mounted in their original positions.

 When piston rings are being replaced and no punchmark is present, piston rings can be mounted with either side up.

AT

TE

PD

FA

BR


RA

ST


138

BT

Assembly (Cont'd)




3. Align piston rings so that end gaps are positioned as shown.




CRANKSHAFT

- 1. Set main bearings in their proper positions on cylinder block and main bearing beam.
- Confirm that correct main bearings are used. Refer to EM-36
- Apply new engine oil to bearing surfaces.



- 2. Install crankshaft and main bearing beam and tighten bolts to the specified torque.
- Apply new engine oil to the bolt threads and seat surface.
- Prior to tightening bearing cap bolts, place bearing cap in its proper position by shifting crankshaft in the axial direction.
- Tighten bearing cap bolts gradually in two or three stages.
 Start with center bearing and move outward as shown in figure.
- After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.



Crankshaft end play:


Standard

0.05 - 0.18 mm (0.0020 - 0.0071 in)


Limit


0.3 mm (0.012 in)

If beyond the limit, replace bearing with a new one.



- Install connecting rod bearings in connecting rods and connecting rod caps.
 - Confirm that correct bearings are used. Refer to EM-38.
 - Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.
 - Apply new engine oil to bearing surfaces, bolt threads and seating surfaces.





Assembly (Cont'd)

Install pistons with connecting rods.

Install them into corresponding cylinders with Tool.

Arrange so that front mark on piston head faces toward front of engine.

Make sure connecting rod does not scratch cylinder wall.

Make sure connecting rod bolts do not scratch crankshaft

Apply new engine oil to piston rings and sliding surface of piston.

EM

(G)

Install connecting rod bearing caps.

LC.

EC

Tighten connecting rod bearing cap nuts using the following procedure.

尾岩



(1) Tighten to 14 to 16 N·m (1.4 to 1.6 kg-m, 10 to 12 ft-lb).

CL


(2) Tighten bolts 60⁺⁵ degrees clockwise with an angle wrench. If an angle wrench is not available, tighten them to 38 to 44 N·m (3.9 to 4.5 kg-m, 28 to 33 ft-lb).

MIT

Δìſ

TF.

PD



Connecting rod side clearance:

Standard

0.2 - 0.4 mm (0.008 - 0.016 in)

Limit

EEM123

EEM124

0.6 mm (0.024 in)

If beyond the limit, replace connecting rod and/or crankshaft.

FA

BA

REPLACING PILOT BUSHING



R

ST


RS


BT

HA

EL

MOX





2. Install pilot bushing (M/T) or pilot convertor (A/T).

SERVICE DATA AND SPECIFICATIONS (SDS)


General Specifications

Cylinder arrangement		4, in-line
Displacement	cm³ (cu in)	2,389 (145.78)
Bore x stroke	mm (in)	89 x 96 (3.50 x 3.78)
Valve arrangement		ОНС
Firing order		1-3-4-2
Number of piston rings		
Compression		2
Oil		. 1
Number of main bearing	ıs	5
Compression ratio		8.6

	Unit: kPa (kg/cm², psi)/rpm
Compression pressure	
Standard	1,324 (13.5, 192)/300
Minimum	981 (10, 142)/300
Differential limit between cylinders	98 (1.0, 14)/300

Inspection and Adjustment

CYLINDER BLOCK



SEM400E

Unit: mm (in)

			Standard	Limit	
Distortion		_	0.1 (0.004)		
Cylinder bore		Grade 1	89.000 - 89.010 (3.5039 - 3.5043)	0.2 (0.008)*	
	Inner diameter	Grade 2	89.010 - 89.020 (3.5043 - 3.5047)		
	į	Grade 3	89.020 - 89.030 (3.5047 - 3.5051)	1	
	Out-of-round (X – Y)	Less than 0.015 (0.0006)		
	Taper (A - B)		Less than 0.015 (0.0006)		
Difference in inner	diameter between cylinder	s	Less than 0.05 (0.0020)	0.2 (0.008)	
Piston-to-cylinder c	learance	· · · · · · · · · · · · · · · · · · ·	0.020 - 0.040 (0.0008 - 0.0016)	_	
Cylinder block heig (From crankshaft c			246.95 - 247.05 (9.7224 - 9.7264)	0.2 (0.008)**	

^{*} Wear limit

CYLINDER HEAD

Unit: mm (in)

	Standard	Limit
Height (H)	98.8 - 99.0 (3.890 - 3.898)	0.2 (0.008)*
Surface distortion	0.03 (0.0012)	0.1 (0.004)

^{*} Total amount of cylinder head resurfacing and cylinder block resurfacing


118 EM-42


^{**} Total amount of cylinder head resurfacing and cylinder block resurfacing

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

VALVE GUIDE





EM

 $\mathbb{M}\mathbb{A}$

GI

LĈ

EC

罪

CL.

MT

AT

TF

PD

FA

RA

ST

RS


BT


MA

SEM401E Unit: mm (in)

	Star	ndard	Service		Limit	
	Intake	Exhaust	Intake	Exhaust		
Length (L)	52.6 (2.071)	56.0 (2.205)	52.6 (2.071)	56.0 (2.205)	_	
Outer diameter (D)	11.023 - 11.034 (0.4340 - 0.4344)	12.023 - 12.034 (0.4733 - 0.4738)	11.223 - 11.234 (0.4418 - 0.4423)	12.223 - 12.234 (0.4812 - 0.4817)	-	
Inner diameter (d) (Finished size)	7.000 - 7.018 (0.2756 - 0.2763)	8.000 - 8.018 (0.3150 - 0.3157)	7.000 - 7.018 (0.2756 - 0.2763)	8.000 - 8.018 (0.3150 - 0.3157)	_	
Cylinder head hole diameter	10.975 - 10.996 (0.4321 - 0.4329)	11.975 - 11.996 (0.4715 - 0.4723)	11.175 - 11.196 (0.4400 - 0.4408)	12.175 - 12.196 (0.4793 - 0.4802)	_	
Interference fit	0.027 - 0.059 (0.0011 - 0.0023)				-	
Stem to guide clearance	0.020 - 0.053 (0.0008 - 0.0021)	0.040 - 0.070 (0.0016 - 0.0028)	0.020 - 0.053 (0.0008 - 0.0021)	0.040 - 0.070 (0.0016 - 0.0028)	0.1 (0.004)	
Tapping length (f)	14.9 - 15.1 (0.587 - 0.594)					

VALVE SEAT





BR


SEM402E Unit: mm (in)

	Standard		Service		
	Intake	Exhaust	Intake	Exhaust	
Cylinder head seat recess diameter	36.000 - 36.016 (1.4173 - 1.4179)	42.000 - 42.016 (1.6535 - 1.6542)	36.500 - 36.516 (1.4370 - 1.4376)	42.500 - 42.516 (1.6732 - 1.6739)	
Valve seat outer diameter (D ₁)	36.080 - 36.096 (1.4205 - 1.4211)	42.080 - 42.096 (1.6567 - 1.6573)	36.580 - 36.596 (1.4402 - 1.4408)	42.580 - 42.596 (1.6764 - 1.6770)	
Face angle (α)	45°	45°	45°	45°	
Contacting width (W)	1.6 - 1.7 (0.063 - 0.067)	1.7 - 2.1 (0.067 - 0.083)	1.6 - 1.7 (0.063 - 0.067)	1.7 - 2.1 (0.067 - 0.083)	

IDX

Inspection and Adjustment (Cont'd)

VALVE



SEM188A

Unit: mm (in)

			Office training (min)
		Standard	Limit
Valve head diameter (D)	In.	33.95 - 34.25 (1.3366 - 1.3484)	_
valve nead diameter (b)	Ex.	40.0 - 40.2 (1.575 - 1.583)	_
Valve length (L)	ln.	119.9 - 120.2 (4.720 - 4.732)	_
valve length (L)	Ex.	120.67 - 120.97 (4.7508 - 4.7626)	
	ln.	6.965 - 6.980 (0.2742 - 0.2748)	_
Valve stem diameter (d)	Ex.	7.948 - 7.960 (0.3129 - 0.3134)	_
Valve face angle (α)	ln.	45°30′	
valve lace aligie (α)	Ex.	45°30′	
Valve head margin (T)	ln.	1.15 - 1.45 (0.0453 - 0.0571)	0.5 (0.020)
valve fread filalight (1)	Ex.	1.35 - 1.65 (0.0531 - 0.0650)	0.5 (0.020)
Valve clearance		0 (0)	

VALVE SPRING


Unit: mm (in)


		Star	Standard		Limit	
		Intake	Exhaust	Intake	Exhaust	
F	Outer	57.44 (2.2614)	53.21 (2.0949)	_		
Free height (H) Inner	53.34 (2.1000)	47.95 (1.8878)				
Pressure N (kg, lb) at height Inner	Outer	604.1 (61.6, 135.8) at 37.6 (1.480)	640.4 (65.3, 144.0) at 34.1 (1.343)	567.8 (57.9, 127.7) at 37.6 (1.480)	620.8 (63.3, 139.6) at 34.1 (1.343)	
		284.4 (29.0, 63.9) at 32.6 (1.283)	328.5 (33.5, 73.9) at 29.1 (1.146)	266.8 (27.2, 60.0) at 32.6 (1.283)	318.7 (32.5, 71.7) at 29.1 (1.146)	
Out-of-square Outer	Outer	_	-	2.5 (0.098)	2.3 (0.091)	
	Inner	_	_	2.3 (0.091)	2.1 (0.083)	

120 EM-44

Inspection and Adjustment (Cont'd)

CAMSHAFT AND CAMSHAFT BEARING





SEM568A

EM120

Unit: mm (in)

			Unit: mm (in)
		Standard	Limit
Cam height (A)	and the same of th	44.43 - 44.58 (1.7492 - 1.7551)	_
Valve lift (h)		9.7 (0.382)	_
Wear limit of carn height		_	0.2 (0.008)
Camshaft journal to bearing clearance		0.045 - 0.090 (0.0018 - 0.0035)	0.12 (0.0047)
Inner diameter of camshaft bearing		33.000 - 33.025 (1.2992 - 1.3002)	-
Outer diameter of camshaft journal (D)		32.935 - 32.955 (1.2967 - 1.2974)	-
Camshaft runout		0 - 0.02 (0 - 0.0008)	_
Camshaft end play		0.07 - 0.15 (0.0028 - 0.0059)	0.2 (0.008)
	a	232	
	b	232	
Value timing (Degree on eventobati)	С	-5	
Valve timing (Degree on crankshaft)	d	57	
	е	11	
	f	41	

ROCKER ARM AND ROCKER SHAFT

Unit: mm (in)

Rocker arm to shaft clearance	0.012 - 0.050 (0.0005 - 0.0020)
Rocker shaft diameter	21.979 - 22.000 (0.8653 - 0.8661)
Rocker arm rocker shaft hole diameter	22.012 - 22.029 (0.8666 - 0.8673)

MA

GI

ΕM

LC

EC

Æ

 $\mathbb{C}[$

MT

AT

PD

TF

FA

RA

BR

ST

RS


BT

HA

Inspection and Adjustment (Cont'd)

PISTON, PISTON RING AND PISTON PIN

Piston



SEM444C

Unit: mm (in)

			Orne: min (in)
Piston skirt diarneter (A)	Standard	Grade No. 1	88.970 - 88.980 (3.5027 - 3.5031)
		Grade No. 2	88.980 - 88.990 (3.5031 - 3.5035)
		Grade No. 3	88.990 - 89.000 (3.5035 - 3.5039)
	Service (Oversize)	0.5 (0.020)	89.470 - 89.500 (3.5224 - 3.5236)
		1.0 (0.039)	89.970 - 90.000 (3.5421 - 3.5433)
Dimension (a)		Approximately 52 (2.05)	
Piston pin hole diameter (d)		21.002 - 21.008 (0.8268 - 0.8271)	
Piston-to-cylinder bore clearance		0.020 - 0.040 (0.0008 - 0.0016)	

Piston pin

Unit: mm (in)


	Standard
Piston pin outer diameter	20.994 - 20.996 (0.8265 - 0.8266)
Pin to piston pin hole clearance	0.008 - 0.012 (0.0003 - 0.0005)
Piston pin to connecting rod clearance	-0.015 to -0.033 (-0.0006 to -0.0013)

Piston ring

			Unit: mm (in)
		Standard	Limit
	Тор	0.040 - 0.080 (0.0016 - 0.0031)	0.1 (0.004)
Side clear- ance	2nd	0.030 - 0.070 (0.0012 - 0.0028)	0.1 (0.004)
	Oil	0.065 - 0.135 (0.0026 - 0.0053)*	0.1 (0.004)
	Тор	0.28 - 0.52 (0.0110 - 0.0205)	0.5 (0.020)
Ring gap	2nd	0.45 - 0.69 (0.0177 - 0.0272)	0.5 (0.020)
	Oil (rail ring)	0.20 - 0.69 (0.0079 - 0.0272)	0.5 (0.020)

^{*:} Riken-make

CONNECTING ROD



SEM216E

Unit: mm (in)

		Onn. man (m)
	Standard	Limit
Center distance (S)	164.95 - 165.05 (6.4941 - 6.4980)	
Bend [per 100 mm (3.94 in)]		0.15 (0.0059)
Torsion [per 100 mm (3.94 in)]	_	0.3 (0.012)
Small end inner diameter (d)	20.948 - 20.978 (0.8247 - 0.8259)	_
Connecting rod big end inner diameter (D)	53.000 - 53.013 (2.0866 - 2.0871)	_
Side clearance	0.2 - 0.4 (0.008 - 0.016)	0.6 (0.024)

122 EM-46

Inspection and Adjustment (Cont'd)

Out-of-round (X) - (Y)

CRANKSHAFT

Main journal diameter (Dm)

Pin journal diameter (Dp)

Center distance (r)

 $[(\hat{\mathbf{X}}) - (\hat{\mathbf{Y}})]$

Runout [TIR]*

Free end play

* Total indicator reading

Fillet roil



MA

LC

EC

EM715

FE

Unit: mm (in)

CL	

 MT

AT

TF

PD

FA

RA

BR

ST

More than 0.1 (0.004)

59.967 - 59.975 (2.3609 - 2.3612)

59.959 - 59.967 (2.3606 - 2.3609)

59.951 - 59.959 (2.3603 - 2.3606)

49.968 - 49.974 (1.9672 - 1.9675)

49.962 - 49.968 (1.9670 - 1.9672)

49.956 - 49.962 (1.9668 - 1.9670)

47.95 - 48.05 (1.8878 - 1.8917)

Standard

0.05 - 0.18 (0.0020 - 0.0071)

Limit

0.01 (0.0004)

0.005 (0.0002)

0.01 (0.0004)

0.005 (0.0002)

0.10 (0.0039)

0.3 (0.012)

BEARING CLEARANCE

Taper of journal and pin $[\mathbf{A} - \mathbf{B}]$

Out-of-round of journal and pin

ŧ	Jnit	: mm	(in)

SEM394

No. 0

No. 2

No. 0

No. 2

Grade No. 1

Grade No. 1

Journal

Journal

Pin

Pin

	Standard	Limit	
Main bearing clearance	0.020 - 0.047 (0.0008 - 0.0019)	0.1 (0.004)	
Connecting rod bearing clearance	0.010 - 0.035 (0.0004 - 0.0014)	0.09 (0.0035)	

RS

BT

HA

IDX

Inspection and Adjustment (Cont'd)

AVAILABLE CONNECTING ROD BEARING

AVAILABLE MAIN BEARING

Standard

Grade number	Thickness mm (in)	Identification color
0	1.821 - 1.825 (0.0717 - 0.0719)	Black
1	1.825 - 1.829 (0.0719 - 0.0720)	Brown
2	1.829 - 1.833 (0.0720 - 0.0722)	Green
3	1.833 - 1.837 (0.0722 - 0.0723)	Yellow
4	1.837 - 1.841 (0.0723 - 0.0725)	Blue

Undersize (service)

		Unit: mm (in)
	Thickness	Main journal diameter "Dm"
0.25 (0.0098)	1.952 - 1.960 (0.0769 - 0.0772)	Grind so that bearing clearance is the specified value.

Standard

Grade number	Thickness mm (in)	ldentification color	
0	1.505 - 1.508 (0.0593 - 0.0594)	_	
1	1.508 - 1.511 (0.0594 - 0.0595)	Brown	
2	1.511 - 1.514 (0.0595 - 0.0596)	Green	

Undersize (service)

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
0.08 (0.0031)	1.540 - 1.548 (0.0606 - 0.0609)	
0.12 (0.0047)	1.560 - 1.568 (0.0614 - 0.0617)	Grind so that bearing clearance is the specified value.
0.25 (0.0098)	1.625 - 1.633 (0.0640 - 0.0643)	

MISCELLANEOUS COMPONENTS

Unit: mm (in)

Camshaft sprocket runout		
Cambrian oproduct randa.	[TIR]*	Less than 0.12 (0.0047)
Flywheel runout	[TIR]*	Less than 0.1 (0.004)
Drive plate runout	[TIR]*	Less than 0.1 (0.004)

^{*} Total indicator reading

GENERAL INFORMATION

SECTION GI

MA

GI

L© EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

ST

CONTENTS

PRECAUTIONS	2
Precautions for Supplemental Restraint System	
(SRS) "AIR BAG"	2
General Precautions	3
Precautions for Engine Oils	5
Precautions for Multiport Fuel Injection System	
or ECCS Engine	6
Precautions for Three Way Catalyst	6
Precautions for Fuel	6
Precautions for Air Conditioning	6
HOW TO USE THIS MANUAL	7
HOW TO READ WIRING DIAGRAMS	9
Sample/Wiring Diagram — EXAMPL —	9
Description	11
Connector Symbols	13
Switch Positions	14
Detectable Lines And Non-Detectable Lines	15
Multiple Switch	15
Foldout Page	16
Wiring Diagram Codes (Cell Codes)	17

	_
HOW TO PERFORM EFFICIENT DIAGNOSIS FOR	
AN ELECTRICAL INCIDENT	
Work Flow	
Incident Simulation Tests	
Circuit Inspection	
Introduction	
Testing For "Opens" In The Circuit	
Testing For "Shorts" In The Circuit	25
Ground Inspection	26
Voltage Drop Tests	27
HOW TO FOLLOW FLOW CHART IN TROUBLE	
DIAGNOSES	30
CONSULT CHECKING SYSTEM	33
IDENTIFICATION INFORMATION	34
Model Variation	34
Identification Number	36
Dimensions	38
Wheels & Tires	38
LIFTING POINTS AND TOW TRUCK TOWING	39
Pantograph Jack	39
Screw Jack	39
Garage Jack and Safety Stand	40
2-pole Lift	
Tow Truck Towing	
Towing Point	
TIGHTENING TORQUE OF STANDARD BOLTS	
SAE J1930 TERMINOLOGY LIST	
	_







Observe the following precautions to ensure safe and proper servicing.




Precautions for Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.



General Precautions

Do not operate the engine for an extended period of time without proper exhaust ventilation. Keep the work area well ventilated and free of any inflammable materials. Special care should be taken when handling any inflammable or poisonous materials, such as gasoline, refrigerant gas, etc. When working in a pit or other enclosed area, be sure to properly ventilate the area before working with hazardous materials.


Do not smoke while working on the vehicle.



Before jacking up the vehicle, apply wheel chocks or other tire blocks to the wheels to prevent the vehicle from moving. After jacking up the vehicle, support the vehicle weight with safety stands at the points designated for proper lifting before working on the vehicle.

These operations should be done on a level surface.

When removing a heavy component such as the engine or transaxle/transmission, be careful not to lose your balance and drop them. Also, do not allow them to strike adjacent parts, especially the brake tubes and master cylinder.




Before starting repairs which do not require battery power: Turn off ignition switch.

Disconnect the negative battery terminal.



To prevent serious burns: Avoid contact with hot metal parts. Do not remove the radiator cap when the engine is hot.



Before servicing the vehicle: Protect fenders, upholstery and carpeting with appropriate cov-

Take caution that keys, buckles or buttons do not scratch paint.

GI

MA

国M

LC

EC

CL

MT

TF

ΑŦ

PD)

EA

BA

BR

ST

RS

37

配

MDX

PRECAUTIONS

General Precautions (Cont'd)

- Clean all disassembled parts in the designated liquid or solvent prior to inspection or assembly.
- Replace oil seals, gaskets, packings, O-rings, locking washers, cotter pins, self-locking nuts, etc. with new ones.
- Replace inner and outer races of tapered roller bearings and needle bearings as a set.
- Arrange the disassembled parts in accordance with their assembled locations and sequence.
- Do not touch the terminals of electrical components which use microcomputers (such as ECMs).
 - Static electricity may damage internal electronic components.

 After disconnecting vacuum or air hoses, attach a tag to indi-
- cate the proper connection.
- Use only the fluids and lubricants specified in this manual.
- Use approved bonding agent, sealants or their equivalents when required.
- Use tools and recommended special tools where specified for safe and efficient service repairs.
- When repairing the fuel, oil, water, vacuum or exhaust systems, check all affected lines for leaks.
- Dispose of drained oil or the solvent used for cleaning parts in an appropriate manner.

WARNING:

To prevent ECM from storing the diagnostic trouble codes, do not carelessly disconnect the harness connectors which are related to the ECCS and A/T control system. The connectors should be disconnected only when working according to the WORK FLOW of TROUBLE DIAGNOSES in EC and AT sections.

Precautions for Engine Oils

Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

MA

HEALTH PROTECTION PRECAUTIONS

 Avoid prolonged and repeated contact with oils, particularly used engine oils.

LC

 Wear protective clothing, including impervious gloves where practicable. 56

Do not put oily rags in pockets.

Ē¢

Avoid contaminating clothes, particularly underclothing, with oil.
Heavily soiled clothing and oil-impregnated footwear should

rere

not be worn. Overalls must be cleaned regularly.

• First Aid treatment should be obtained immediately for open

CL

cuts and wounds.
Use barrier creams, applying them before each work period, to help the removal of oil from the skin.

MT

 Wash with soap and water to ensure all oil is removed (skin cleansers and nail brushes will help). Preparations containing lanolin replace the natural skin oils which have been removed.

 Do not use gasoline, kerosene, diesel fuel, gas oil, thinners or solvents for cleaning skin.

AT

If skin disorders develop, obtain medical advice without delay.

TF

Where practicable, degrease components prior to handling.
 Where there is a risk of eye contact, eye protection should be worn, for example, chemical goggles or face shields; in addition, an eye wash facility should be provided.

PD

ENVIRONMENTAL PROTECTION PRECAUTIONS

Burning used engine oil in small space heaters or boilers can be recommended only for units of approved design. The heating system must meet the requirements of HM Inspectorate of Pollution for small burners of less than 0.4 MW. If in doubt, check with the appropriate local authority and/or manufacturer of the approved

UF*IA*X

RA

appliance. Dispose of used oil and used oil filters through authorized waste disposal contractors to licensed waste disposal sites, or to the waste oil reclamation trade. If in doubt, contact the local authority for advice on disposal facilities.

8R


It is illegal to pour used oil on the ground, down sewers or drains, or into water courses.

ŝŢ

The regulations concerning the pollution of the environment will vary between regions.

87

HA



Precautions for Multiport Fuel Injection System or ECCS Engine

 Before connecting or disconnecting any harness connector for the multiport fuel injection system or ECM (ECCS control module):

Turn ignition switch to OFF position.

Disconnect negative battery terminal.

Otherwise, there may be damage to ECM.

- Before disconnecting pressurized fuel line from fuel pump to injectors, be sure to release fuel pressure.
- Be careful not to jar components such as ECM and mass air flow sensor.

Precautions for Three Way Catalyst

If a large amount of unburned fuel flows into the catalyst, the catalyst temperature will be excessively high. To prevent this, follow the instructions below:

- Use unleaded gasoline only. Leaded gasoline will seriously damage the three way catalyst.
- When checking for ignition spark or measuring engine compression, make tests quickly and only when necessary.
- Do not run engine when the fuel tank level is low, otherwise the engine may misfire, causing damage to the catalyst.

Do not place the vehicle on inflammable material. Keep inflammable material off the exhaust pipe and the three way catalyst.

Precautions for Fuel

Use unleaded gasoline with an octane rating of at least 87 AKI (Anti-Knock Index) number (research octane number 91).

CAUTION:

Do not use leaded gasoline. Using leaded gasoline will damage the three way catalyst.

Using a fuel other than that specified could adversely affect the emission control devices and systems, and could also affect warranty coverage.

Precautions for Air Conditioning

Use an approved refrigerant recovery unit any time the air conditioning system must be discharged. Refer to HA section ("R-134a Service Procedure", "SERVICE PROCEDURES") for specific instructions.

MA

EM

EC

FE

CL

MT

AT

77

PD

FA

RA

BR

RS


BT

HA

配

- AN ALPHABETICAL INDEX is provided at the end of this manual so that you can rapidly find the item and page you are searching for.
- A QUICK REFERENCE INDEX, a black tab (e.g., ET) is provided on the first page. You can quickly find the first page of each section by mating it to the section's black tab.
- THE CONTENTS are listed on the first page of each section.
- THE TITLE is indicated on the upper portion of each page and shows the part or system.
- THE PAGE NUMBER of each section consists of two letters which designate the particular section and a number (e.g., "BR-5").
- THE LARGE ILLUSTRATIONS are exploded views (see below) and contain tightening torques, lubrication points, section number of the PARTS CATALOG (e.g., SEC.440) and other information necessary to perform repairs.

The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate PARTS CATALOG.



THE SMALL ILLUSTRATIONS show the important steps such as inspection, use of special tools, knacks
of work and hidden or tricky steps which are not shown in the previous large illustrations.
Assembly, inspection and adjustment procedures for the complicated units such as the automatic transaxle
or transmission, etc. are presented in a step-by-step format where necessary.

GI-7

11

HOW TO USE THIS MANUAL

• The following SYMBOLS AND ABBREVIATIONS are used:

O, 😉	:	Tightening torque	4 × 4		
	:	Should be lubricated with grease.	4WD	:	4-Wheel Drive
		Unless otherwise indicated, use rec-	2WD	:	2-Wheel Drive
		ommended multi-purpose grease.	A/C	:	Air Conditioner
	:	Should be lubricated with oil.	P/S	:	Power Steering
	:	Sealing point	Tool	:	Special Service Tools
<u> </u>	;	Checking point	SAE	:	Society of Automotive Engineers,
Š	:	Always replace after every disas-			Inc.
•		sembly.	ATF	:	Automatic Transmission Fluid
6 P	:	Apply petroleum jelly.	D_{τ}	:	Drive range 1st gear
ATF)	:	Apply ATF.	D_2	:	Drive range 2nd gear
*	:	Select with proper thickness.	D_{3}^{-}	:	Drive range 3rd gear
☆	:	Adjustment is required.	D_4	:	Drive range 4th gear
SDS	:	Service Data and Specifications	OD	:	Overdrive
LH, RH	:	Left-Hand, Right-Hand	22	:	2nd range 2nd gear
FR, RR	:	Front, Rear	21	:	2nd range 1st gear
M/T	:	Manual Transaxle/Transmission	12	:	1st range 2nd gear
A/T	:	Automatic Transaxle/Transmission	1,	:	1st range 1st gear

• The **UNITS** given in this manual are primarily expressed as the SI UNIT (International System of Unit), and alternatively expressed in the metric system and in the yard/pound system.

"Example"

Tightening torque:

59 - 78 N·m (6.0 - 8.0 kg-m, 43 - 58 ft-lb)

- TROUBLE DIAGNOSES are included in sections dealing with complicated components.
- SERVICE DATA AND SPECIFICATIONS are contained at the end of each section for quick reference of data.
- The captions WARNING and CAUTION warn you of steps that must be followed to prevent personal injury and/or damage to some part of the vehicle.


WARNING indicates the possibility of personal injury if instructions are not followed.

CAUTION indicates the possibility of component damage if instructions are not followed.

BOLD TYPED STATEMENTS except WARNING and CAUTION give you helpful information.


Sample/Wiring Diagram — EXAMPL —

For Description, refer to GI-11.



Sample/Wiring Diagram — EXAMPL — (Cont'd)

OPTIONAL SPLICE



	<u> </u>	Description		
Number	Item	Description		
1	Power condition	 This shows the condition when the system receives battery positive voltage (can be operated). 		
2	Fusible link	 The double line shows that this is a fusible link. The open circle shows current flow in, and the shaded circle shows current flow out. 		
3	Fusible link/fuse location	 This shows the location of the fusible link or fuse in the fusible link or fuse box. For arrangement, refer to EL section ("POWER SUPPLY ROUTING"). 		
4	Fuse	 The single line shows that this is a fuse. The open circle shows current flow in, and the shaded circle shows current flow out. 		
5	Current rating	This shows the current rating of the fusible link or fuse.		
6	Connectors	 This shows that connector (£3) is female and connector (M1) is male. The G/R wire is located in the A1 terminal of both connectors. Alphabetic letters with terminal numbers (A1, B5, etc.) indicate that the connector is SMJ connector. Refer to GI-16. 		
7	Optional splice	The open circle shows that the splice is optional depending on vehicle application.		
8	Splice	The shaded circle shows that the splice is always on the vehicle.		
9	Page crossing	 This arrow shows that the circuit continues to an adjacent page. The A will match with the A on the preceding or next page. 		
10	Common connector	 The dotted lines between terminals show that these terminals are part of the same connector. 	_	
(1)	Option abbreviation	This shows that the circuit is optional depending on vehicle application.	-	
12	Relay	 This shows an internal representation of the relay. For details, refer to EL section ("STANDARDIZED RELAY"). 	_	
13)	Connectors	 This shows that the connector is connected to the body or a terminal with bolt or nut. 	_	
1	Wire color	 This shows a code for the color of the wire. B = Black BR = Brown W = White OR = Orange R = Red P = Pink G = Green PU = Purple L = Blue GY = Gray Y = Yellow SB = Sky Blue LG = Light Green CH = Dark Brown DG = Dark Green 		

color as shown below:

the B position.

gram page number.

15)

(16)

17)

(18)

Option description

Assembly parts

Cell code

Switch

Example: L/W = Blue with White Stripe

• This shows a description of the option abbreviation used on the page.

• This shows that continuity exists between terminals 1 and 2 when the switch is in

• Connector terminal in component shows that it is a harness incorporated assem-

• This identifies each page of the wiring diagram by section, system and wiring dia-

the A position. Continuity exists between terminals 1 and 3 when the switch is in

RS

MK

GI-11 15

Description (Cont'd)			
Number	Item	Description	
19	Current flow arrow	 Arrow indicates electric current flow, especially where the direction of standard flow (vertically downward or horizontally from left to right) is difficult to follow. A double arrow " " shows that current can flow in either direction depending on circuit operation. 	
20	System branch	 This shows that the system branches to another system identified by cell code (section and system). 	
21)	Page crossing	 This arrow shows that the circuit continues to another page identified by cell code. The C will match with C on any other page within the system except the next or preceding page. 	
22	Shielded line	The line enclosed by broken line circle shows shield wire.	
23	Component box in wave line	This shows that another part of the component is also shown on another page (indicated by wave line) within the system.	
24	Component name	This shows the name of a component.	
2 5	Connector number	 This shows the connector number. The letter shows which harness the connector is located in. Example: M: main harness. For detail and to locate the connector, refer to EL section ("Main Harness", "HARNESS LAYOUT"). A coordinate grid is included for complex harnesses to aid in locating connectors. 	
26	Ground (GND)	 The line spliced and grounded under wire color shows that ground line is spliced at the grounded connector. 	
27	Ground (GND)	This shows the ground connection.	
28	Connector views	 This area shows the connector faces of the components in the wiring diagram on the page. 	
29	Common component	 Connectors enclosed in broken lines show that these connectors belong to the same component. 	
30	Connector color	 This shows a code for the color of the connector. For code meaning, refer to wire color codes, Number (4) of this chart. 	
31)	Fusible link and fuse box	 This shows the arrangement of fusible link(s) and fuse(s), used for connector views of "POWER SUPPLY ROUTING" in EL section. The open square shows current flow in, and the shaded square shows current flow out. 	
32	Reference area	 This shows that more information on the Super Multiple Junction (SMJ) and Joint Connectors (J/C) exists on the foldout page. Refer to GI-16 for details. 	

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA


BR

ST

RS

BT

HA



Description (Cont'd) CONNECTOR SYMBOLS


Most of connector symbols in wiring diagrams are shown from the terminal side.

Connector symbols shown from the terminal side are enclosed by a single line and followed by the direction mark

Connector symbols shown from the harness side are enclosed by a double line and followed by the direction mark

T.S.

- Connector guides for male terminals are shown in black.
- Connector guides for female terminals are shown in white.




17

Example Harness indication BCM connector (M33) Single line C/UNIT O CONNECTOR 109 SB V AC mode switch connector (M33) Double line 113 AGI067

Description (Cont'd)

- Connector numbers that indicate harness are enclosed by a single line.
- Connector numbers that indicate components are enclosed by a double line.



SWITCH POSITIONS

Switches are shown in wiring diagrams as if the vehicle is in the "normal" condition.

A vehicle is in the "normal" condition when:

- ignition switch is "OFF",
- doors, hood and trunk lid/back door are closed,
- · pedals are not depressed, and
- parking brake is released.

Description (Cont'd)

DETECTABLE LINES AND NON-DETECTABLE LINES


In some wiring diagrams, two kinds of lines with different thicknesses are used to represent wires.

- A line with regular thickness (wider line) represents a "detectable line for DTC (Diagnostic Trouble Code)". A "detectable line for DTC" is a circuit in which ECM (ECCS control module) can detect malfunctions with the on-board diagnostic system.
- A line with less thickness (thinner line) represents a "non-detectable line for DTC". A "non-detectable line for DTC" is a circuit in which ECM cannot detect malfunctions with the onboard diagnostic system.

MULTIPLE SWITCH

The continuity of multiple switch is described in two ways as shown below.

- The switch chart is used in schematic diagrams.
- The switch diagram is used in wiring diagrams.



MA

EM

LC

ĒC

(C)L

FE

MT

AT

TE

PD)

FA

RA

BR

ST

RS

PT

HA

1DX

Description (Cont'd)

FOLDOUT PAGE

The foldout page should be opened when reading wiring diagram.


Super multiple junction (SMJ)

In wiring diagram, SMJ connectors include a letter of the alphabet with the terminal number for each terminal. SMJ connector numbers are shown in the Reference Area. Terminal arrangement can be found on the foldout page.

If connector numbers are shown in Reference Area, these connector symbols are not shown in Connector Area. For terminal arrangement of these connectors, refer to the foldout page at the end of this manual.

Joint connector

Joint connector symbols are shown in Connector Area of the wiring diagram. Inside wiring layout and joint connector terminal arrangement can be found on the foldout page.



GI

MA

Wiring Diagram Codes (Cell Codes)

- Use the chart below to find out what each wiring diagram code stands for. Refer to the wiring diagram code in the Alphabetical Index to find the location (page number) of each wiring diagram.


		
Code	Section	Wiring Diagram Name
AAC/V	EC	IACV-AAC Valve
ABS	BR	Anti-lock Brake System
A/C HA		Air Conditioner
AP/SEN	EC	Absolute Pressure Sensor
ASCD	EL	Automatic Speed Control Device (ASCD)
A/T	AT	Automatic Transmission
AUDIO	EL	Audio
BACK/L	EL	Back-up Lamp
BYPS/V	EC	Vacuum Cut Valve Bypass Valve
CANI/V	EC	EVAP Canister Purge Control Valve/ Solenoid Valve
CHARGE	EL	Charging System
CHIME	EL	Warning Chime
CKPS	EC	Crankshaft Position Sensor (OBD)
CMPS	EC	Camshaft Position Sensor
D/LOCK	EL	Power Door Lock
DTRL	ĒL	Headlamp - With Daytime Light System
ECTS	EC	Engine Coolant Temperature Sensor
EGRC/V	EC	EGRC-Solenoid Valve
EGRC1	EC	EGR System Function
EGR/TS	EC	EGR Temperature Sensor
FICD	EC	IACV-FICD Solenoid Valve
F/PUMP	EC	Fuel Pump Control
FRO2	EC	Front Heated Oxygen Sensor
FRO2/H	EC	Front Heated Oxygen Sensor Heater
FUEL	EC	Fuel Injection System Function
HEATER	HA	Heater System
H/LAMP	EL	Headlamp - Without Daytime Light System
HORN	EL	Horn, Lighter and Clock
IATS	EC	Intake Air Temperature Sensor
IGN/SG	EC	Ignition Signal
ILL	EL	Illumination
INJECT	EC	Injector
INT/L	EL	Interior and Map Lamps

Code	Section	Wiring Diagram Name	
MAFS	EC	Mass Air Flow Sensor	
MAIN	EC	Main Power Supply and Ground Circuit	
METER	EL	Speedometer, Tachometer, Temp. and Fuel Gauges	
MIL/DL	EC	MIL & Data Link Connectors	
MIRROR	EL	Door Mirror	
PGC/V	EC	EVAP Canister Purge Control Sole- noid Valve	
PNP/SW	EC	Park/Neutral Position Switch	
POWER	EL	Power Supply Routing	
PRE/SE	EC	EVAP Control System Pressure Sensor	
PST/SW	EC	Power Steering Oil Pressure Switch	
RRO2	EC	Rear Heated Oxygen Sensor	
RRO2/H	EC	Rear Heated Oxygen Sensor Heater	
SHIFT	AT	A/T Shift Lock System	
SRS	RS	Supplemental Restraint System	
S/SIG	EC	Start Signal	
START	EL	Starting System	
S/VCSW	EC	Swirl Control Valve Control Vacuum Check Switch	
SWL/V	EC	Swirl Control Valve Control Solenoid Valve	
SW/V	EC	MAP/BARO Switch Solenoid Valve	
TAIL/L	EL	Clearance, License, Tail and Stop Lamps	
TFTS	EC	Tank Fuel Temperature Sensor	
TPS	EC	Throttle Position Sensor	
TP/SW	EC	Throttle Position Switch	
TURN	EL	Turn Signal and Hazard Warning Lamps	
VENT/V	EC	EVAP Canister Vent Control Valve	
vss	EC	Vehicle Speed Sensor	
WARN	EL	Warning Lamps	
WINDOW	EL	Power Window	
WIPER	EL	Front Wiper and Washer	

GI-17 21

IDX

Work Flow



STEP		DESCRIPTION			
STEP 1	Get detailed information about the conditions and the environment when the incident occurred. The following are key pieces of information required to make a good analysis:				
	WHAT	Vehicle Model, Engine, Transmission and the System (i.e., Radio).			
	WHEN	Date, Time of Day, Weather Conditions, Frequency.			
	WHERE	Road Conditions, Altitude and Traffic Situation.			
	HOW	System Symptoms, Operating Conditions (Other Components Interaction). Service History and if any After Market Accessories have been installed.			
STEP 2	Operate the system, road test if necessary. Verify the parameter of the incident. If the problem can not be duplicated, refer to "Incident Simulation Tests" next page.				
STEP 3	Get the proper diagnosis materials together, including:				
		POWER SUPPLY ROUTING System Operation Descriptions Applicable Service Manual Sections Check for Any Service Bulletins			
	Identify wh	ere to begin diagnosis based upon your knowledge of the system operation and the customer comments.			
STEP 4	Inspect the system for mechanical binding, loose connectors or wiring damage. Determine which circuits and components are involved and diagnose using the Power Supply Routing and Harness Layouts.				
STEP 5	Repair or r	replace the incident circuit or component.			
STEP 6	Operate the system in all modes. Verify that the system works properly under all conditions. Make sure you have not inadvertently created a new incident during your diagnosis or repair steps.				

Incident Simulation Tests

INTRODUCTION

Sometimes the symptom is not present when the vehicle is brought in for service. If possible, recreate the conditions present at the time of the incident. Doing so may help avoid a No Trouble Found Diagnosis. The following section illustrates ways to simulate the conditions/environment under which the owner experiences an electrical incident.

The section is broken into the six following topics:

- Vehicle vibration
- Heat sensitive
- Freezing
- Water intrusion
- Electrical load
- Cold or hot start up

Get a thorough description of the incident from the customer. It is important for simulating the conditions of the problem.

VEHICLE VIBRATION

The problem may occur or become worse while driving on a rough road or when engine is vibrating (idle with A/C on). In such a case, you will want to check for a vibration related condition. Refer to the illustration below.

Connectors & harness


Determine which connectors and wiring harnesses would affect the electrical system you are inspecting. **Gently** shake each connector and harness while monitoring the system for the incident you are trying to duplicate. This test may indicate a loose or poor electrical connection.

Hint

Connectors can be exposed to moisture. It is possible for a thin film of corrosion to build up on the connector terminals. A visual inspection may not reveal this without disconnecting the connector. If the problem occurs intermittently, perhaps the problem is caused by corrosion. It is a good idea to disconnect, inspect and clean the terminals on related connectors in the system.

Sensors & relays

Gently apply a slight vibration to sensors and relays in the system you are inspecting. This test may indicate a loose or poorly mounted sensor or relay.



GI

L©

EG

FE

©L

MT

AT

TF

.P(3)

FA

RA

BR

ST


RS


1817

KA.

Ð.

Incident Simulation Tests (Cont'd)





Tester probe

When probing a connector it is possible to enlarge the contact spring opening. If this occurs it may create an intermittent signal in the circuit. When probing a connector, use care not to enlarge the opening. The probe of the Digital Multimeter (DMM) may not fit into the connector cavity. In such cases make an extension of a "T" pin and probe it from the harness side of the connector. Most DMMs have accessory alligator clips. Slide these over the probe to allow clipping the "T" pin for a better contact. If you have any difficulty probing a terminal, inspect the terminal. Ensure that you have not accidentally opened the contact spring or pulled a wire loose.

Incident Simulation Tests (Cont'd)

Engine compartment

There are several reasons why a vehicle or engine vibration could cause an electrical complaint. Some of the things to check for are:

- Connectors not fully seated.
- Wiring harness not long enough and stressed due to engine vibrations or rocking.
- Wires laying across brackets or moving components.
- Loose, dirty or corroded ground wires.
- Wires routed too close to hot components.


To inspect components under the hood, start by verifying the integrity of ground connections. (Refer to GROUND INSPECTION described later.) First check that the system is properly grounded. Then check for loose connection by gently shaking the wiring or components as previously explained. Using the wiring diagrams inspect the wiring for continuity.

Behind the instrument panel

An improperly routed or improperly clamped harness can become pinched during accessory installation. Vehicle vibration can aggravate a harness which is routed along a bracket or near a screw.

Under seating areas

An unclamped or loose harness can cause wiring to be pinched by seat components (such as slide guides) during vehicle vibration. If the wiring runs under seating areas, inspect wire routing for possible damage or pinching.



HEAT SENSITIVE

The owner's problem may occur during hot weather or after car has sat for a short time. In such cases you will want to check for a heat sensitive condition.

To determine if an electrical component is heat sensitive, heat the component with a heat gun or equivalent.

Do not heat components above 60°C (140°F). If incident occurs while heating the unit, either replace or properly insulate the component.

GI

MA

EM

ILC.

GL

MT

AT

TF

(āle)

FA

RA

38


128

BT

出風

EL

M




Incident Simulation Tests (Cont'd) FREEZING

The customer may indicate that the incident goes away after the car warms up (winter time). The cause could be related to water freezing somewhere in the wiring/electrical system.

There are two methods to check for this. The first is to arrange for the owner to leave his car overnight. Make sure it will get cold enough to demonstrate his complaint. Leave the car parked outside overnight. In the morning, do a quick and thorough diagnosis of those electrical components which could be affected.


The second method is to put the suspect component into a freezer long enough for any water to freeze. Reinstall the part into the car and check for reoccurrence of the incident. If it occurs, repair or replace the component.



WATER INTRUSION

The incident may occur only during high humidity or in rainy/snowy weather. In such cases the incident could be caused by water intrusion on an electrical part. This can be simulated by soaking the car or running it through a car wash.

Do not spray water directly on any electrical components.



ELECTRICAL LOAD

The incident may be electrical load sensitive. Perform diagnosis with all accessories (including A/C, rear window defogger, radio, fog lamps) turned on.

COLD OR HOT START UP

On some occasions an electrical incident may occur only when the car is started cold. Or it may occur when the car is restarted hot shortly after being turned off. In these cases you may have to keep the car overnight to make a proper diagnosis.

The connector and terminal pin kit contains some of the most commonly used NISSAN connectors and terminals.

Tool number (Kent-Moore No.) Tool name	Description
— (J38751-95NI) Connector and terminal pin kit	AGI063

INTRODUCTION

In general, testing electrical circuits is an easy task if approached logically. Before beginning, it is important to have all available information on the system to be tested. Also, get a thorough understanding of system operation. Then you will be able to use the appropriate equipment and follow the correct test procedure. You may have to simulate vehicle vibrations while testing electrical components. Gently shake the wiring harness or electrical component to do this.

OPEN

A circuit is open when there is no continuity through a section of the circuit.

SHORT

There are two types of shorts.

SHORT CIRCUIT

When a circuit contacts another circuit and causes the

normal resistance to change.

SHORT TO GROUND

When a circuit contacts a ground source and grounds the

circuit.

GI

-MIA

LC

EC

滘

CL

MT

AT

TF

PD

FA

RA

周周

ST

RS

TS

HA

EL


IDX

27

Circuit Inspection (Cont'd)

TESTING FOR "OPENS" IN THE CIRCUIT

Before you begin to diagnose and test the system, you should rough sketch a schematic of the system. This will help you to logically walk through the diagnosis process. Drawing the sketch will also reinforce your working knowledge of the system.



Continuity check method

The continuity check is used to find an open in the circuit. The Digital Multimeter (DMM) set on the resistance function will indicate an open circuit as over limit (OL, no beep tone or no ohms symbol). Make sure no power is supplied to the checked component. Always start with the DMM at the highest resistance level. To help in understanding the diagnosis of open circuits please refer to the schematic above.

- 1. Disconnect the battery negative cable.
- 2. Start at one end of the circuit and work your way to the other end (At the fuse block in this example).
- 3. Connect one probe of the DMM to the fuse block terminal on the load side.
- 4. Connect the other probe to the fuse block (power) side of SW1. Little or no resistance will indicate that portion of the circuit has good continuity. If there were an open in the circuit, the DMM would indicate an over limit or infinite resistance condition (point A).
- 5. Connect the probes between SW1 and the relay. Little or no resistance will indicate that portion of the circuit has good continuity. If there were an open in the circuit, the DMM would indicate an over limit or infinite resistance condition (point B).
- 6. Connect the probes between the relay and the solenoid. Little or no resistance will indicate that portion of the circuit has good continuity. If there were an open in the circuit, the DMM would indicate an over limit or infinite resistance condition (point C).

Any circuit can be diagnosed using the approach in the above example.

Voltage check method

To help in understanding the diagnosis of open circuits please refer to the previous schematic.

In any powered circuit, an open can be found by methodically checking the system for voltage. This is done by switching the DMM to the voltage function.

- 1. Connect one probe of the DMM to a known good ground.
- 2. Begin probing at one end of the circuit and work your way to the other end.
- 3. With SW1 open, probe at SW1 to check for voltage.

Voltage: Open is further down the circuit than SW1.

No voltage: Open is between fuse block and SW1 (point A).

4. Close SW1 and probe at relay.

Voltage: Open is further down the circuit than the relay. No voltage: Open is between SW1 and relay (point B).

No voltage: Open is between SW1 and r

Close the relay and probe at the solenoid.

Voltage: Open is further down the circuit than the solenoid.

No voltage: Open is between relay and solenoid (point C).

Any powered circuit can be diagnosed using the approach in the above example.


MA

HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT

Circuit Inspection (Cont'd)

TESTING FOR "SHORTS" IN THE CIRCUIT

To simplify the discussion of shorts in the system please refer to the schematic below.



Resistance check method

1. Disconnect the battery negative cable and remove the blown fuse.

2. Disconnect all loads (SW1 open, relay disconnected and solenoid disconnected) powered through the

Connect one probe of the ohmmeter to the load side of the fuse terminal. Connect the other probe to a known good ground.

4. With SW1 open, check for continuity.

Continuity: Short is between fuse terminal and SW1 (point A).

No continuity: Short is further down the circuit than SW1.

5. Close SW1 and disconnect the relay. Put probes at the load side of fuse terminal and a known good ground. Then, check for continuity.

Continuity: Short is between SW1 and the relay (point B).

No continuity: Short is further down the circuit than the relay.

6. Close SW1 and jump the relay contacts with jumper wire. Put probes at the load side of fuse terminal and a known good ground. Then, check for continuity.

Continuity: Short is between relay and solenoid (point C).

No continuity: Check solenoid, retrace steps.

Voltage check method

1. Remove the blown fuse and disconnect all loads (i.e., SW1 open, relay disconnected and solenoid disconnected) powered through the fuse.

Turn the ignition key to the ON or START position. Verify battery voltage at the B+ side of the fuse terminal (one lead on the B+ terminal side of the fuse block and one lead on a known good ground).

With SW1 open and the DMM leads across both fuse terminals, check for voltage.

Voltage: Short is between fuse block and SW1 (point A).

No voltage: Short is further down the circuit than SW1.

With SW1 closed, relay and solenoid disconnected and the DMM leads across both fuse terminals, check for voltage.

Voltage: Short is between SW1 and the relay (point B).

No voltage: Short is further down the circuit than the relay.

With SW1 closed, relay contacts jumped with fused jumper wire check for voltage.

Short is down the circuit of the relay or between the relay and the disconnected sole-Voltage:

noid (point C).

Retrace steps and check power to fuse block. No voltage:

剛

LC

EC

FF

CL

MT

TF

PD)

FA

RA

BR

RS

BT

HA

11D)X

Circuit Inspection (Cont'd)


GROUND INSPECTION

Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works.

Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface.

When inspecting a ground connection follow these rules:

- 1. Remove the ground bolt screw or clip.
- 2. Inspect all mating surfaces for tarnish, dirt, rust, etc.
- 3. Clean as required to assure good contact.
- 4. Reinstall bolt or screw securely.
- 5. Inspect for "add-on" accessories which may be interfering with the ground circuit.
- 6. If several wires are crimped into one ground eyelet terminal, check for proper crimps. Make sure all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet make sure no ground wires have excess wire insulation.



Circuit Inspection (Cont'd)

VOLTAGE DROP TESTS

Voltage drop tests are often used to find components or circuits which have excessive resistance. A voltage drop in a circuit is caused by a resistance when the circuit is in operation.

Check the wire in the illustration. When measuring resistance with ohmmeter, contact by a single strand of wire will give reading of 0 ohms. This would indicate a good circuit. When the circuit operates, this single strand of wire is not able to carry the current. The single strand will have a high resistance to the current. This will be picked up as a slight voltage drop.

Unwanted resistance can be caused by many situations:

Undersized wiring (single strand example)

Corrosion on switch contacts


Loose wire connections or splices.

If repairs are needed, always use wire that is of the same or larger gauge.

Measuring voltage drop — Accumulated method

- 1. Connect the voltmeter across the connector or part of the circuit you want to check. The positive lead of the voltmeter should be closer to power and negative lead closer to ground.
- 2. Operate the circuit.
- 3. The voltmeter will indicate how many volts are being used to "push" current through that part of the circuit.

Note in the illustration that there is an excessive 4.1 volt drop between the battery and the bulb.



GI-27

31

[₩I/A

GI

EWI

[©

EC

. . .

GL

MT

ÆÜ

TF

PD

FA

P.A

BR

ઝા

89

27

HA

Circuit Inspection (Cont'd)


Measuring voltage drop — Step by step

The step by step method is most useful for isolating excessive drops in low voltage systems (such as computer controlled systems).

Circuits in the computer controlled system operate on very low amperage.

Computer controlled operations can be adversely affected by any variation in resistance in the system. Such resistance variation may be caused by poor connection, improper installation, improper wire gauge or corrosion.

The step by step voltage drop test can identify a component or wire with too much resistance.



- Connect the voltmeter as shown, starting at the battery and working your way around the circuit.
- An unusually large voltage drop will indicate a component or wire that needs to be repaired. In the illustration, the poor connection causes a 4 volt drop.

The chart that follows illustrates some maximum allowable voltage drops. These values are given as a guideline, the exact value for each component may vary.

COMPONENT

Wire

Ground Connections Switch Contacts VOLTAGE DROP negligible <.001 volts

Approx. 0.1 volts Approx. 0.3 volts

AGI055

MA

圖M

LC

EC

BE

CL.

WT

AT

TIE

PD)

FA

IRA.

20

R\$

BT

HA

剧。


MOL

HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT

Circuit Inspection (Cont'd)

CONTROL UNIT CIRCUIT TEST

System Description: When the switch is ON, the ECM lights up the lamp.




Input-output voltage chart

Pin No.	ítem	Condition	Voltage value [V]	In case of high resistance such as single strand [V] *
1	Switch	Switch ON	Battery voltage	Lower than battery voltage Approx. 8 (Example)
		OFF	Approx. 0	Approx. 0
2	Lamp	Switch ON	Battery voltage	Approx. 0 (Inoperative lamp)
		OFF	Approx. 0	Approx. 0

The voltage value is based on the body ground.

^{* :} If high resistance exists in the switch side circuit (caused by a single strand), terminal 1 does not detect battery voltage. ECM does not detect the switch is ON even if the switch does turn ON. Therefore, the ECM does not supply power to light up the lamp.



Input-output voltage chart

Pin No.	Item	Condition	Voltage value [V]	In case of high resistance such as single strand [V] *
1	Lamp	Switch ON	Approx. 0	Battery voltage (Inoperative lamp)
		OFF	Battery voltage	Battery voltage
2	Switch	Switch ON	Approx. 0	Higher than 0 Approx. 4 (Example)
		OFF	Approx. 5	Approx. 5


The voltage value is based on the body ground.

[:] If high resistance exists in the switch side circuit (caused by a single strand), terminal 2 does not detect approx. 0V. ECM does not detect the switch is ON even if the switch does turn ON. Therefore, the ECM does not control ground to light up the lamp.

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

The flow chart indicates work procedures required to diagnose problems effectively. Observe the following instructions before diagnosing.

- 1) Use the flow chart after locating probable causes of a problem following the "Preliminary Check", the "Symptom Chart" or the "Work Flow".
- 2) After repairs, recheck that the problem has been completely eliminated.
- 3) Refer to Component Parts and Harness Connector Location for the systems described in each section for identification/location of components and harness connectors.
- 4) Refer to the Circuit Diagram for Quick Pinpoint Check.
 If you must check circuit continuity between harness connectors in more detail, such as when a sub-harness is used, refer to Wiring Diagram in each individual section and Harness Layout in EL section for identification of harness connectors.
- 5) When checking circuit continuity, ignition switch should be OFF.
- 6) Before checking voltage at connectors, check battery voltage.
- 7) After accomplishing the Diagnostic Procedures and Electrical Components Inspection, make sure that all harness connectors are reconnected properly.



110X

HOW TO FOLLOW THIS FLOWCHART

Work and diagnostic procedure

Start to diagnose a problem using procedures indicated in enclosed blocks, as shown in the following example.

CHECK POWER SUPPLY.

1. Stop engine.
2. Disconnect IACV-FICD solenoid valve harness connector.
3. Start engine, then turn air conditioner switch and blower fan "ON".
4. Check voltage between terminal (1) and ground with CONSULT or tester.

Voltage: Battery voltage

Check item being performed.

Procedure, steps or measurement results

2 Measurement results

Required results are indicated in bold type in the corresponding block, as shown below.

These have the following meanings:

Battery voltage \to 11 - 14V or approximately 12V Voltage: Approximately 0V \to Less than 1V Resistance: Continuity should exist \to Approximately 0 Ω

3 Cross reference of work symbols in the text and illustrations

Illustrations are provided as visual aids for work procedures. For example, symbol A indicated in the left upper portion of each illustration corresponds with the symbol in the flowchart for easy identification. More precisely, the procedure under the "CHECK POWER SUPPLY" outlined previously is indicated by an illustration A.

4 Symbols used in illustrations

Symbols included in illustrations refer to measurements or procedures. Before diagnosing a problem, familiarize yourself with each symbol.

For connector symbols, refer to "HOW TO READ WIRING DIAGRAMS" on GI-13.

Direction mark

Refer to "CONNECTOR SYMBOLS" on GI-13.

GI-31 35

HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES

Key to symbols signifying measurements or procedures

Symbol	Symbol explanation	Symbol	Symbol explanation
DISCONNECT	Check after disconnecting the connector to be measured.		Procedure with CONSULT
CONNECT	Check after connecting the connector to be measured.		Procedure without CONSULT
	Insert key into ignition switch.		Procedure with Generic Scan Tool (GST, OBD-II scan tool)
	Remove key from ignition switch.	TOOLS	Procedure without CONSULT or GST
COFF	Turn ignition switch to "OFF" position.		A/C switch is "OFF".
Can	Turn ignition switch to "ON" position.	AC	A/C switch is "ON".
(CST)	Turn ignition switch to "START" position.	\$ OFF 1 2 3 4	Fan switch is "ON". (At any position except for "OFF" position)
(GFFF) OC	Turn ignition switch from "OFF" to "ACC" position.	\$ OFF 1 2 3 4	Fan switch is "OFF".
(ACC) OFF	Turn ignition switch from "ACC" to "OFF" position.	FUSE	Apply positive voltage from battery with fuse directly to components.
(GFF*)ON	Turn ignition switch from "OFF" to "ON" position.		Drive vehicle.
(CN+OFF	Turn ignition switch from "ON" to "OFF" position.	BAT	Disconnect battery negative cable.
	Do not start engine, or check with engine stopped.		Depress brake pedal.
	Start engine, or check with engine run- ning.	W.	Release brake pedal.
and the	Apply parking brake.		Depress accelerator pedal.
guidin.	Release parking brake.	J.	Release accelerator pedal.
с-ОДн	Check after engine is warmed up sufficiently.	CUNIT O CONNECTOR	Pin terminal check for SMJ type ECM and A/T control unit connectors.
V	Voltage should be measured with a voltmeter.	OF CONNECTOR	For details regarding the terminal arrangement, refer to the foldout page.
	Circuit resistance should be measured with an ohmmeter.	D.SCONNECT	1 2 3 0 4 5 8 7 9 0 0 1041112 HS
A	Current should be measured with an ammeter.	4	<u>_</u>

GI-32

Function and System Application

Diagnostic test mode	Function	ECCS	Air bag
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT.	х	_
Self-diagnostic results	Self-diagnostic results can be read and erased quickly.	x	х
Trouble diagnostic record	Current self-diagnostic results and all trouble diagnostic records previously stored can be read.	_	×
ECU discriminated No.	Classification number of a replacement ECU can be read to prevent an incorrect ECU from being installed.	_	x
Data monitor	Input/Output data in the ECM can be read.	х	
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.	x	_
ECM part number	ECM part number can be read.	х	
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".	х	

x: Applicable

Lithium Battery Replacement

CONSULT contains a lithium battery. When replacing the battery obey the following:

WARNING:

Replace the lithium battery with SANYO Electric Co., Ltd., CR2032 only. Use of another battery may present a risk of fire or explosion. The battery may present a fire or chemical burn hazard if mistreated. Do not recharge, disassemble of dispose of in fire.

Keep the battery out of reach of children and discard used battery conforming to the local regulations.

Checking Equipment

When ordering the equipment below, contact your NISSAN distributor.

Tool name	Description	R
NISSAN CONSULT ① CONSULT unit		
and accessories 2 Program card UE950		\$
		(2)
	NT004	

GI-33

37

MA

LC

EM

EC

FE

CL

MT

AT

TF

FA

HA

EL

IDENTIFICATION INFORMATION

Model Variation

2-WHEEL DRIVE

			Engine		KA24E	
Destination		Transmission	FS5W71C	F\$5W71C	RL4R01A (Floor shift)	
	Body		Differential carrier	H190A	C200	H190A
	Doguđer Cab	STD		ABFALCFD21EUN	_	_
Non-California,	Regular Cab	XE	Standard wheelbase	ABFALEFD21EUN	_	ABFALEAD21EUN
U.S.A.	Vina Cab	XE	Lang wheelbeer	BBFGLEFD21EUN	BBFGLEFD21EUN*	BBFGLEAD21EUN
	King Cab	SE	Long wheelbase	-	BBFGLFFD21EUN	BBFGLFAD21EUN
	Regular Cab	STD	Standard wheelbase	ABFALCFD21EVN	_	_
California,	neguiai Cab	XE	Standard wheelbase	ABFALEFD21EVN		ABFALEAD21EVN
U.S.A.	King Cab	XE	Long wheelbase	BBFGLEFD21EVN	BBFGLEFD21EVN*	BBFGLEAD21EVN
	King Cao	SE	Long wheelbase	_	BBFGLFFD21EVN	BBFGLFAD21EVN
	Dogwior Coh	STD	Ctandard wheelbase	ABFALCFD21ENN	_	_
Canada	Regular Cab	ΧE	Standard wheelbase	ABFALEFD21ENN	-	ABFALEAD21ENN
Canada	King Coh	XE	1 and wheelbase	BBFGLEFD21ENN	BBFGLEFD21ENN*	BBFGLEAD21ENN
	King Cab	SE	Long wheelbase	_	BBFGLFFD21ENN	BBFGLFAD21ENN


^{*:} Option

4-WHEEL DRIVE

			Engine KA24E			
			Transmission	FS5W71C		
Destination			Transfer	TX1	0	
Body		Differential carrier	Front R180A	Rear H233B		
	Regular Cab	XE	Standard wheelbase	ABFNLEFD21EUN		
Non-California, U.S.A.	King Coh	XE	Lang whallbook	BBFULEFD21EUN		
	King Cab	SE	Long wheelbase —	BBFULFFD21EUN		
	Regular Cab	XE	Standard wheelbase	ABFNLEFD21EVN		
California, U.S.A.	Kin o Onla	XE		BBFULEFD21EVN		
	King Cab	SE	Long wheelbase	BBFULFFD21EVN		
<u></u>	Regular Cab	XE	Standard wheelbase	ABFNLEFE	D21ENN	
Canada	XE			BBFULEFD21ENN		
	King Cab	SE	Long wheelbase	BBFULFFD21ENN		

38 GI-34

Prefix and suffix designations:



A: Regular Cab B: King Cab

GI

MiA

EM

LC

EC

FE

CL.

MT

AT

TF

1910)

 $\mathbb{R}\mathbb{A}$

FA

®R

ST


RS

BT


MA

IDX

Identification Number



VEHICLE IDENTIFICATION NUMBER ARRANGEMENT




1N6: U.S.A. produced truck

GI-36


IDENTIFICATION INFORMATION

Identification Number (Cont'd)


ENGINE SERIAL NUMBER




TRANSMISSION SERIAL NUMBER



TRANSMISSION SERIAL NUMBER



TRANSFER SERIAL NUMBER



GI

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

ST

RS

BT

AR

IDX

IDENTIFICATION INFORMATION

Dimensions

Unit: mm (in)

		2-whee	2-wheel drive		l drive	
		Regular Cab	Regular Cab King Cab		King Cab	
		Standard wheelbase	Long wheelbase	Standard wheelbase	Long wheelbase	
Overall length*1		4,435 (174.6)	4,825 (190.0)	4,435 (174.6)	4,825 (190.0)	
Overall width		1,650 (65.0)	1,650 (65.0)	1,690 (66.5)	1,690 (66.5)	
Overall height		1,575 (62.0)	1,575 (62.0)	1,705 (67.1)	1,705 (67.1)	
Front tread*2		1,395 (54.9)	1,395 (54.9)	1,455 (57.3)	1,455 (57.3)	
Rear tread*2		1,385 (54.5)	1,385 (54.5)	1,440 (56.7)	1,440 (56.7)	
Wheelbase		2,650 (104.3)	2,950 (116.1)	2,650 (104.3)	2,950 (116.1)	
Cargo space	Length	1,875 (73.8)	1,895 (74.6)	1,875 (73.8)	1,895 (74.6)	
	Width	1,520 (59.8)	1,520 (59.8)	1,520 (59.8)	1,520 (59.8)	
	Height	435 (17.1)	435 (17.1)	435 (17.1)	435 (17.1)	
Minimum ground c	learance	211 (8.3)	211 (8.3)	236 (9.3)	236 (9.3)	

^{*1:} On step bumper equipped models, the bumper adds 140 mm (5.5 in) to the overall length. *2: On 14x6JJ road wheel equipped models, adds 20 mm (0.79 in) to the tread.

Wheels & Tires

				· · · · · · · · · · · · · · · · · · ·	
	Cab type	Grade	Road wheel/offset mm (in)	Tire	Spare tire size
	Regular	STD	14x5J/40 (1.57)	P195/75R14	T135/70D16 P195/75R14*
4x2	Regular & King	XE	14x5J/40 (1.57) 14x6JJ Aluminum/30 (1.18)*	P195/75R14 P215/70R14*	T135/70D16 P195/75R14* P215/70R14*
King	SE	14x6JJ Aluminum/30 (1.18)	P215/70R14	T135/70D16	
	Regular	XE	15x6JJ/25 (0.98) 15x7JJ Aluminum/25 (0.98)	P235/75R15	P215/75R15* P235/75R15
4x4	King	XE	15x6JJ/25 (0.98) 15x7JJ Aluminum/25 (0.98)	P235/75R15	P235/75R15
,	King	SE	15x7JJ Aluminum/25 (0.98)	P235/75R15	P235/75R15

^{*:} Option


LIFTING POINTS AND TOW TRUCK TOWING

WARNING:


a. Never get under the vehicle while it is supported only by the jack. Always use safety stands to support the frame when you have to get under the vehicle.

b. Place wheel chocks at both front and back of the wheels on the ground.

Pantograph Jack



Screw Jack



GI

MA

LC.

EC

FE

ŒL.

MI

AT

TF

PD)

FA

RA

1318

ST

RS

BT

HA

۵L,


1DX

LIFTING POINTS AND TOW TRUCK TOWING

Garage Jack and Safety Stand

CAUTION:

Place a wooden or rubber block between safety stand and vehicle body when the supporting body is flat.



GI


LIFTING POINTS AND TOW TRUCK TOWING

2-pole Lift

WARNING:

When lifting the vehicle, open the lift arms as wide as possible and ensure that the front and rear of the vehicle are well balanced.

When setting the lift arm, do not allow the arm to contact the brake tubes, brake cable or fuel lines.



MA

LC

EC

FE

CL.

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Tow Truck Towing

CAUTION:

- All applicable state or provincial (in Canada) laws and local laws regarding the towing operation must be obeyed.
- It is necessary to use proper towing equipment to avoid possible damage to the vehicle during towing operation.

Towing is in accordance with Towing Procedure Manual at dealer.

Attach safety chains for all towing.


- When towing, make sure that the transmission, steering system and powertrain are in good order.
 If any unit is damaged, a dolly must be used.
- When towing with the front wheels on the ground: Turn the ignition key to the "OFF" position and secure the steering wheel in a straight ahead position with a rope or similar device. Never place the ignition key in the "LOCK" position. This will result in damage to the steering lock mechanism.

When towing manual transmission models with the rear wheels on the ground, release the parking brake and move the gearshift lever to neutral position ("N" position).

 Never tow vehicle from the rear (i.e., backward) with four wheels on the ground as this may cause serious and expensive damage to the transmission.

For 4-wheel drive model:

Set the free-running hubs to the free position. Move the transfer case shift lever into the "2H" position and the transmission shift lever into the neutral ("N") position.



2-WHEEL DRIVE MODELS

NISSAN recommends that vehicle be towed with the driving (rear) wheels off the ground as illustrated.

Towing with four wheels on ground or towing with front wheels raised (With rear wheels on ground)

Observe the following restricted towing speeds and distances.

Automatic transmission model:


Speed: Below 50 km/h (30 MPH) Distance: Less than 65 km (40 miles)

Manual transmission model:

Speed: Below 95 km/h (60 MPH)

Distance: Less than 800 km (500 miles)

If the speed or distance must necessarily be greater, remove the propeller shaft beforehand to prevent damage to the transmission.



Tow Truck Towing (Cont'd) 4-WHEEL DRIVE MODELS

NISSAN recommends that a dolly be used as illustrated when towing 4-speed drive models.

MA

ĿC

EC

35

CL.

MT

AT

T

PD)

RA

RA

BR

ST

KS

Towing with four wheels on ground or towing with front or rear wheels raised

Observe the following restricted towing speeds and distances.

Automatic transmission model:

Speed: Below 50 km/h (30 MPH) Distance: Less than 65 km (40 miles)

Manual transmission model:

Speed: Below 95 km/h (60 MPH)


Distance: Less than 800 km (500 miles)


If the speed or distance must necessarily be greater, remove the front and rear propeller shafts beforehand to prevent damage to the transmission.

Towing Point

 Never tow the vehicle using only the towing hooks. To avoid damaging the vehicle body, use proper towing equipment when towing.

Always pull the cable straight out from the vehicle. Never pull on the hook at a sideways angle.





VEHICLE RECOVERY (Freeing a stuck vehicle)

- Tow chains or cables must be attached only to the main structural members of the vehicle.
- Pulling devices should be routed so they do not touch any part of the suspension, steering, brake or cooling systems.
- Always pull the cable straight out from the front or rear of the vehicle. Never pull the vehicle at a sideways angle.
- Pulling devices such as ropes or canvas straps are not recommended for use for vehicle towing or recovery.

EL

TIGHTENING TORQUE OF STANDARD BOLTS

		Bolt diameter*				Tight	ening torque	(Without lub	ricant)		
Grade	Bolt size		Pitch mm		Hexagon head bolt			Hexagon flange bolt			
<u> </u>		mm		N·m	kg-m	ft-fb	in-lb	N∙m	kg-m	ft-lb	in-lb
	M6	6.0	1.0	5.1	0.52	3.8	45.1	6.1	0.62	4.5	53.8
	Mo	8.0	1.25	13	1.3	9	_	15	1.5	11	_
	M8	0.0	1.0	13	1.3	9		16	1.6	12	
4T	M10	10.0	1.5	25	2.5	18	_	29	3.0	22	_
41	INITO	10.0	1.25	25	2.6	19		30	3.1	22	_
	M12	10.0	1.75	42	4.3	31	_	51	5.2	38	_
	MIZ	12.0	1.25	46	4.7	34		56	5.7	41	_
	M14	14.0	1.5	74	7.5	54	_	88	9.0	65	
	M6	6.0	1.0	8.4	0.86	6.2	74.6	10	1.0	7	87
		8.0	1.25	21	2.1	15	_	25	2.5	18	_
	M8		1.0	22	2.2	16	_	26	2.7	20	
7 T	M10	10 10.0	1.5	41	4.2	30	_	48	4.9	35	
/ 1	IVITO	10.0	1.25	43	4.4	32	_	51	5.2	38	
	M12	12.0	1.75	71	7.2	52	_	84	8.6	62	
	19112	12.0	1.25	77	7.9	57		92	9.4	68	
	M14	14.0	1.5	127	13.0	94		147	15.0	108	
	М6	6.0	1.0	12	1.2	9	_	15	1.5	11	<u> </u>
	M8	8.0	1.25	29	3.0	22	_	35	3.6	26	_
	IVIO	0.0	1.0	31	3.2	23	_	37	3.8	27	_
OT	9T M10	10.0	1.5	59	6.0	43	_	70	7.1	51	_
अ।		10.0	1.25	62	6.3	46	_	74	7.5	54	
	M12	12.0	1.75	98	10.0	72	_	118	12.0	87	_
	19112	12.0	1.25	108	11.0	80	_	137	14.0	101	_
	M14	14.0	1.5	177	18.0	130	_	206	21.0	152	

Special parts are excluded.
 This standard is applicable to bolts having the following marks embossed on the bolt head.

*: Nominal diameter

Grade	Mark	
4 T	 4	<u>M</u> <u>6</u>
7 T	 7	Nominal diameter of bolt threads (Unit: mm)
9T	 9	Metric screw threads

MA

SAE J1930 Terminology List

All emission related terms used in this publication in accordance with SAE J1930 are listed. Accordingly, new terms, new acronyms/abbreviations and old terms are listed in the following chart.

***: Not applicable

NEW TERM	NEW ACRONYM / ABBREVIATION	OLD TERM	EiM	
Air cleaner	ACL	Air cleaner		
Barometric pressure	BARO	***	LC	
Barometric pressure sensor-BCDD	BAROS-BCDD	BCDD	-, <u></u> -	
Camshaft position	СМР	***	 EC	
Camshaft position sensor	CMPS	Crank angle sensor		
Carburetor	CARB	Carburetor		
Charge air cooler	CAC	Intercooler	FE	
Closed loop	CL	Closed loop		
Closed throttle position switch	CTP switch	Idle switch	Cl	
Clutch pedal position switch	CPP switch	Clutch switch		
Continuous fuel injection system	CFI system	***	 MT	
Continuous trap oxidizer system	CTOX system	***		
Crankshaft position	СКР	***	 AT	
Crankshaft position sensor	CKPS	***	,, <u>,,,</u> ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
Data link connector	DLC	***	- 7712	
Data link connector for CONSULT	DLC for CONSULT	Diagnostic connector for CONSULT	—— TE	
Diagnostic test mode	DTM	Diagnostic mode		
Diagnostic test mode selector	DTM selector	Diagnostic mode selector	PD	
Diagnostic test mode I	DTM I	Mode I		
Diagnostic test mode II	DTM II	Mode II	FA	
Diagnostic trouble code	DTC	Malfunction code		
Direct fuel injection system	DFI system	***	ra	
Distributor ignition system	DI system	Ignition timing control		
Early fuel evaporation-mixture heater	EFE-mixture heater	Mixture heater		
Early fuel evaporation system	EFE system	Mixture heater control	ن ارک	
Electrically erasable programmable read only memory	EEPROM	***	 ST	
Electronic ignition system	EI system	Ignition timing control		
Engine control	EC	***	 R\$	
Engine control module	ECM	ECCS control unit		
Engine coolant temperature	ECT	Engine temperature		
Engine coolant temperature sensor	ECTS	Engine temperature sensor		
Engine modification	EM	***		
Engine speed	RPM	Engine speed	—— KA	
Erasable programmable read only memory	EPROM	***		
Evaporative emission canister	EVAP canister or Canister	Canister	<u>E</u> L	

GI-45 49

SAE J1930 TERMINOLOGY LIST SAE J1930 Terminology List (Cont'd) ***: Not applicable

NEW TERM	NEW ACRONYM / ABBREVIATION	OLD TERM
Evaporative emission system	EVAP system	Evaporative emission control system
Exhaust gas recirculation valve	EGR valve	EGR valve
Exhaust gas recirculation control-BPT valve	EGRC-BPT valve	BPT valve
Exhaust gas recirculation control-solenoid valve	EGRC-solenoid valve	EGR control solenoid valve
Exhaust gas recirculation temperature sensor	SORT	
EGR temperature sensor	EGRT sensor	Exhaust gas temperature sensor
Flash electrically erasable programmable read only memory	FEEPROM	***
Flash erasable programmable read only memory	FEPROM	***
Flexible fuel sensor	FFS	***
Flexible fuel system	FF system	***
Fuel pressure regulator	***	Pressure regulator
Fuel pressure regulator control solenoid valve	***	PRVR control solenoid valve
Fuel trim	FT	***
Heated oxygen sensor	HO2S	Exhaust gas sensor
Idle air control system	IAC system	Idle speed control
Idle air control valve-air regulator	IACV-air regulator	Air regulator
Idle air control valve-auxiliary air control valve	IACV-AAC valve	Auxiliary air control (AAC) valve
Idle air control valve-FICD solenoid valve	IACV-FICD solenoid valve	FICD solenoid valve
Idle air control valve-idle up control solenoid valve	IACV-idle up control solenoid valve	Idle up control solenoid valve
Idle speed control-FI pot	ISC-FI pot	FI pot
Idle speed control system	ISC system	***
Ignition control	IC	***
Ignition control module	ICM	***
Indirect fuel injection system	IFI system	***
Intake air	IA	Air
Intake air temperature sensor	IAT sensor	Air temperature sensor
Knock	***	Detonation
Knock sensor	KS	Detonation sensor
Malfunction indicator lamp	MIL	Check engine light
Manifold absolute pressure	MAP	***
Manifold absolute pressure sensor	MAPS	***
Manifold differential pressure	MDP	***
Manifold differential pressure sensor	MDPS	***

GI-46

SAE J1930 TERMINOLOGY LIST SAE J1930 Terminology List (Cont'd)

NEW TERM	NEW ACRONYM / ABBREVIATION	OLD TERM
Manifold surface temperature	MST	***
Manifold surface temperature sensor	MSTS	#**
Manifold vacuum zone	MVZ	***
Manifold vacuum zone sensor	MVZS	***
Mass air flow sensor	MAFS	Air flow meter
Mixture control solenoid valve	MC solenoid valve	Air-fuel ratio control solenoid valve
Multiport fuel injection System	MFI system	Fuel injection control
Neutral position switch	***	Neutral switch
Nonvolatile random access memory	NVRAM	***
On board diagnostic system	OBD system	Self-diagnosis
Open loop	OL.	Open loop
Oxidation catalyst	ОС	Catalyst
Oxidation catalytic converter system	OC system	***
Oxygen sensor	O2S	Exhaust gas sensor
Park position switch	***	Park switch
Park/neutral position switch	PNP switch	Park/neutral switch
Periodic trap oxidizer system	PTOX system	宇治
Positive crankcase ventilation	PCV	Positive crankcase ventilation
Positive crankcase ventilation valve	PCV valve	PCV valve
Powertrain control module	PCM	***
Programmable read only memory	PROM	***
Pulsed secondary air injection control solenoid valve	PAIRC solenoid valve	AIV control solenoid valve
Pulsed secondary air injection system	PAIR system	Air induction valve (AIV) control
Pulsed secondary air injection valve	PAIR valve	Air induction valve
Random access memory	RAM	***
Read only memory	ROM	***
Scan tool	ST	***
Secondary air injection pump	AIR pump	***
Secondary air injection system	AiR system	***
Sequential multiport fuel injection system	SFI system	Sequential fuel injection
Service reminder indicator	SRI	***
Simultaneous multiport fuel injection system	***	Simultaneous fuel injection
Smoke puff limiter system	SPL system	***
Supercharger	SC	***
Gupercharger bypass	SCB	***
System readiness test	SRT	***
Thermal vacuum valve	TVV	Thermal vacuum valve
Fhree way catalyst	TWC	Catalyst
hree way catalytic converter system	TWC system	***
Three way+oxidation catalyst	TWC+OC	Catalyst

GI-47 51

1DX

SAE J1930 TERMINOLOGY LIST SAE J1930 Terminology List (Cont'd)

***: Not applicable

NEW TERM	NEW ACRONYM / ABBREVIATION	OLD TERM
Three way+oxidation catalytic converter system	TWC+OC system	***
Throttle body	ТВ	Throttle chamber
		SPI body
Throttle body fuel injection system	TBI system	Fuel injection control
Throttle position	TP	Throttle position
Throttle position sensor	TPS	Throttle sensor
Throttle position switch	TP switch	Throttle switch
Torque converter clutch solenoid valve	TCC solenoid valve	Lock-up cancel solenoid
		Lock-up solenoid
Turbocharger	TC	Turbocharger
Vehicle speed sensor	VSS	Vehicle speed sensor
Volume air flow sensor	VAFS	Air flow meter
Warm up oxidation catalyst	WU-OC	Catalyst
Warm up oxidation catalytic converter system	WU-OC system	***
Warm up three way catalyst	WU-TWC	Catalyst
Warm up three way catalytic converter system	WU-TWC system	***
Wide open throttle position switch	WOTP switch	Full switch

GI-48

ENGINE LUBRICATION & COOLING SYSTEMS

SECTION LC

MA

ĒM

LC

ĒC

FE

CL

MT

AT

CONTENTS

PRECAUTIONS AND PREPARATION	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
Liquid Gasket Application Procedure	2
Special Service Tools	3
ENGINE LUBRICATION SYSTEM	
Lubrication Circuit	4
Oil Pressure Check	5
Oil Pump	5

ENGINE COOLING SYSTEM	7
Cooling Circuit	7
System Check	7
Water Pump	8
Thermostat	9
Radiator	11
Cooling Fan	12
Overheating Cause Analysis	13
SERVICE DATA AND SPECIFICATIONS (SDS)	14
Engine Lubrication System	14
Engine Cooling System	14

TF

PD

FA RA

BR

ST

RS

BT

HA


EL


Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.





Liquid Gasket Application Procedure

- a. Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - For oil pan, be sure liquid gasket diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
 - For areas except oil pan, be sure liquid gasket diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
- Apply liquid gasket around the inner side of bolt holes (unless otherwise specified).
- d. Assembly should be done within 5 minutes after coating.
- Wait at least 30 minutes before refilling engine oil and engine coolant.

LC-2

PRECAUTIONS AND PREPARATION

Tool number (Kent-Moore No.) Tool пате	Description			[
(J34301-C) Oil pressure gauge set			Measuring oil pressure	- [
(J34301-1) Oil pressure gauge				
(J34301-2)Hoses(J34298)Adapter	1998			
(J34282-1) Adapter (5) (790-301-1230-A)	2			
60° adapter 6 (J34301-15)			Maximum measuring range:	!
Square socket	AAT546		1,379 kPa (14 kg/cm², 200 psi)	
EG17650301 J33984-A)		c + Final b	Adapting radiator cap tester to radiator filler neck	
Radiator cap tester adapte		▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗ ▗		i
	NT564		a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)	1
VS39930000 —)			Pressing the tube of liquid gasket	
Tube presser		De la		
	NT052			

LC-3 127

BR

ST


RS

BŢ


KA

ľDX

Lubrication Circuit



ENGINE LUBRICATION SYSTEM



Oil Pressure Check


WARNING:

- Be careful not to burn yourself, as the engine and oil may be hot.
- For M/T models, put gearshift lever in Neutral "N" position.
 For A/T models, put selector lever in Park "P" position.
- 1. Check oil level.
- 2. Remove oil pressure switch.
- 3. Install pressure gauge.
- 4. Start engine and warm it up to normal operating temperature.
- 5. Check oil pressure with engine running under no-load.

Engine speed rpm	Approximate discharge pressure kPa (kg/cm², psi)
Idle speed	More than 78 (0.8, 11)
3,000	412 - 481 (4.2 - 4.9, 60 - 70)

- If difference is extreme, check oil passage and oil pump for oil leaks.
- Install oil pressure switch with sealant.

Oil Pump



Œ[

MA

LC

EC

PE

CL

MT

At

77

PD

FA

RA

BR

ST

RS


FT

HΑ

EL


1DX

ENGINE LUBRICATION SYSTEM




Oil Pump (Cont'd)

- Always replace with new oil seal and gasket.
- When removing oil pump, turn crankshaft so that No. 1 piston is at TDC on its compression stroke.
- When installing oil pump, apply engine oil to gears, then align punchmark on drive spindle and oil hole on oil pump.



REGULATOR VALVE INSPECTION


- Visually inspect components for wear and damage.
- Check oil pressure regulator valve sliding surface and valve spring.
- Coat regulator valve with engine oil. Check that it falls smoothly into the valve hole by its own weight.
- Replace regulator valve set or oil pump assembly if damaged.



OIL PRESSURE RELIEF VALVE INSPECTION

Inspect oil pressure relief valve for movement, cracks and breaks by pushing the ball. If replacement is necessary, remove valve by prying it out with a suitable tool.

Install a new valve by tapping it in place.




OIL PUMP INSPECTION

Use a feeler gauge to check the following clearances.


Standard clearance:

	Unit: mm (in)
Rotor tip clearance ①	Less than 0.12 (0.0047)
Outer rotor to body clearance 2	0.15 - 0.21 (0.0059 - 0.0083)
Side clearance (with gasket) 3	0.04 - 0.08 (0.0016 - 0.0031)

- If the tip clearance (1) exceeds the limit, replace gear set.
- If body to gear clearances (2), 3) exceed the limit, replace oil pump assembly.



LC-6



System Check

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could occur from high pressure coolant escaping from the radiator.

Wrap a thick cloth around the radiator cap. Slowly turn it a quarter turn to allow built up pressure to escape. Carefully remove the radiator cap by turning it all the way.

CHECKING COOLING SYSTEM HOSES

Check hoses for the following:

- Improper attachment
- Leaks
- Cracks
- Damage
- Chafing
- Deterioration

LC-7

131

MA

GI

1000 G

LC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

78

HA

0.02-3

]DX



System Check (Cont'd)

CHECKING COOLING SYSTEM FOR LEAKS


To check for leakage, apply pressure to the cooling system with a radiator cap tester.

Testing pressure:

157 kPa (1.6 kg/cm², 23 psi)

CAUTION:

Higher pressure than specified may cause radiator damage.



CHECKING RADIATOR CAP

To check radiator cap, apply pressure to radiator cap with a radiator cap tester.


Radiator cap relief pressure:

Standard


78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi)

Limit

59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi)



Pull the negative pressure valve to open it. Check that it closes completely when released.



Water Pump


CAUTION:

- When removing water pump assembly, be careful not to get coolant on drive belts.
- Water pump cannot be disassembled and should be replaced as a unit.
- After installing water pump, connect hose and clamp securely, then check for leaks using radiator cap tester.

REMOVAL

- Drain coolant from engine.
 Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
- 2. Remove fan coupling with fan.
- 3. Remove power steering pump drive belt, generator drive belt and A/C compressor drive belt.
- 4. Remove water pump.

LC-8



Water Pump (Cont'd) **INSPECTION**

Check body assembly for rust or corrosion.

Check for rough operation due to excessive end play.




MA

LC

EC

티트



2.0 - 3.0 mm (0.079 - 0.118 in)

Thermostat

Liquid 🏠

6.3 - 8.3 N·m (0.64 - 0.85 kg·m.

55.6 - 73.8 in - lb)

gasket

Liquid gasket:

SEC. 210A

Water inlet

INSTALLATION


Use a scraper to remove liquid gasket from water pump.

Also remove traces of liquid gasket from mating surface of cylinder block.



CL

MT'



TF

When filling radiator with coolant, refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). When installing drive belts, refer to MA section ("Checking Drive Belts").

PD

FA

RA

BR

Be careful not to spill coolant over engine compartment. Use a rag to absorb coolant.

REMOVAL

Thermostat

SLC391AA

ALC061

Drain coolant from engine. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").

Remove air cleaner and air duct assembly.

Remove water hose from water inlet housing. 3.

Remove water inlet housing, then take out thermostat.


BT

RS

MA

킲






Thermostat (Cont'd) INSPECTION

 Check valve seating condition at normal room temperature. It should seat tightly.

2. Check valve opening temperature and valve lift.


Valve opening temperat	ure °C (°F)	76.5 (170)
Valve lift	mm/°C (in/°F)	More than 8/90 (0.31/194)

3. Then check if valve closes at 5°C (9°F) below valve opening temperature.



INSTALLATION

- 1. Use a scraper to remove old liquid gasket from water inlet.
- Also remove traces of liquid gasket from mating surface of front cover.
- 2. Apply a continuous bead of liquid gasket to mating surface of water inlet.
- Use Genuine Liquid Gasket or equivalent.




- 3. Install thermostat with jiggle valve or air bleeder at upper side.
- 4. Install water inlet housing.
- 5. Install water hose to water inlet housing.
- 6. Install air cleaner and air duct assembly.
- 7. Refill engine coolant. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
- After installation, run engine for a few minutes, and check for leaks.

134 LC-10

Radiator

REMOVAL AND INSTALLATION

- Drain coolant from radiator. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
- Disconnect upper and lower radiator hoses.
- 3. Remove air cleaner and air duct assembly.
- Remove fan coupling with fan.
- 5. Remove lower radiator shroud.
- 6. Remove radiator shroud.
- 7. Remove A/T oil cooler hoses (A/T models only).
- Disconnect coolant reservoir hose.
- 9. Remove radiator.
- After replacing radiator, install all parts in reverse order of removal.
- 11. Refill engine coolant. Refer to MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE").
- After installation, run engine for a few minutes, and check for leaks.



Œſ

MA

EM

LC

FE

CL

MT^{*}

TF

AT

PD

FA


<u>B</u>R

RA


©T

RS

El.



Cooling Fan DISASSEMBLY AND ASSEMBLY



INSPECTION

Check fan coupling for rough operation, oil leakage and bent bimetal.

Overheating Cause Analysis

	Sy	mptom	Chec	k items	ь
		Water pump malfunction	Worn or loose drive belt		R
		Thermostat stuck closed	_		
	Poor heat transfer	Damaged fins	Dust contamination or paper clogging	_	
			Mechanical damage		
		Clogged radiator cooling tube	Excess foreign material (rust, dirt, sand, etc.)		
		Cooling fan does not operate			7
	Reduced air flow	Fan coupling does not operate			i
	neduced all llow	High resistance to fan rotation	_	_	
		Damaged fan blades]		
	Damaged radiator shroud			_	
ooling	Improper coolant mixture ratio		-	_	
stem parts	Poor coolant quality			_	
alfunction			_	Loose clamp	
			Cooling hose	Cracked hose	
			Water pump	Poor sealing	
Ins				Loose	
	Coolant leaks Insufficient coolant	Coolant leaks	Radiator cap	Poor sealing	
			Radiator	O-ring for damage, deteriora- tion or improper fitting	
				Cracked radiator tank	
			Cracked radiator core		
			Reservoir tank	Cracked reservoir tank	
		-		Cylinder head deterioration	
		Overflowing reservoir tank	Exhaust gas leaks into cooling system	Cylinder head gasket deteriora- tion	
				High engine rpm under no load	
			Abusive driving	Driving in low gear for extended time	
		Overload on engine		Driving at extremely high speed	
			Powertrain system malfunction		
			Installed improper size wheels and tires	-	
cept oling			Dragging brakes		
stem parts			Improper ignition timing		
malfunction		Blocked bumper	_		
			Installed truck brassiere		
	Blocked or restricted air flow	Blocked radiator grille	Mud contamination or paper clogging	_	
		Blocked radiator	_	1	
		Blocked condenser			
		Installed large fog lamp	_		

G

LC-13 ₁₃₇

SERVICE DATA AND SPECIFICATIONS (SDS)

Engine Lubrication System

Oil pressure check

Engine speed rpm	Approximate discharge pressure kPa (kg/cm², psi)
Idle speed	More than 78 (0.8, 11)
3,000	412 - 481 (4.2 - 4.9, 60 - 70)

Oil pump

	Unit: mm (in)
Rotor tip clearance	Less than 0.12 (0.0047)
Outer rotor to body clearance	0.15 - 0.21 (0.0059 - 0.0083)
Side clearance (with gasket)	0.04 - 0.08 (0.0016 - 0.0031)

Engine Cooling System

Thermostat

Valve opening temperature	°C (°F)	76.5 (170)
Valve lift	mm/°C (in/°F)	More than 8/90 (0.31/194)

Radiator

- 1.0, 11 - 14)
- 1.0, 9 - 14)
1.6, 23)

138 LC-14

SECTION EC

CONTENTS

DIAGNOSTIC TROUBLE CODE INDEX	2
Alphabetical & P No. Index for DTC	2
PRECAUTIONS AND PREPARATION	
ENGINE AND EMISSION CONTROL OVERALL	
SYSTEM	9
Circuit Diagram	9
System Diagram	10
ECCS Component Parts Location	, 11
Vacuum Hose Drawing	13
System Chart	14
ENGINE AND EMISSION BASIC CONTROL	
SYSTEM DESCRIPTION	
Multiport Fuel Injection (MFI) System	15
Distributor Ignition (DI) System	
Air Conditioning Cut Control	18
Fuel Cut Control (at no load & high engine	
speed)	
EVAPORATIVE EMISSION SYSTEM	20
Description	20
Inspection	20
Evaporative Emission Line Drawing	
POSITIVE CRANKCASE VENTILATION	
Description	
Inspection	
BASIC SERVICE PROCEDURE	
Fuel Pressure Release	
Fuel Pressure Check	
Injector Removal and Installation	
Fast Idle Cam (FIC) Inspection and Adjustment	27
Idle Speed/Ignition Timing/Idle Mixture Ratio	
Adjustment	28
ON BOARD DIAGNOSTIC SYSTEM	
DESCRIPTION	
Introduction	
Two Trip Detection Logic	
Emission-related Diagnostic Information	
Malfunction Indicator Lamp (MIL)	
OBD System Operation Chart	
CONSULT	
Generic Scan Tool (GST)	66

TROUBLE DIAGNOSIS — Introduction	68
Introduction	68
Diagnostic Worksheet	
TROUBLE DIAGNOSIS — Work Flow	70
Work Flow	70
Description for Work Flow	71
TROUBLE DIAGNOSIS — Basic Inspection	72
Basic Inspection	72
TROUBLE DIAGNOSIS — General Description	75
Diagnostic Trouble Code (DTC) Inspection	
Priority Chart	75
Fail-Safe Chart	76
Symptom Matrix Chart	77
CONSULT Reference Value in Data Monitor	
Mode	79
Major Sensor Reference Graph in Data Monitor	
Mode	81
ECM Terminals and Reference Value	83
TROUBLE DIAGNOSIS FOR POWER SUPPLY	89
Main Power Supply and Ground Circuit	
TROUBLE DIAGNOSIS FOR DTC P0100	
Mass Air Flow Sensor (MAFS)	
TROUBLE DIAGNOSIS FOR DTC P0105	
Absolute Pressure Sensor	100
TROUBLE DIAGNOSIS FOR DTC P0110	
Intake Air Temperature Sensor	
TROUBLE DIAGNOSIS FOR DTC P0115	
Engine Coolant Temperature Sensor (ECTS)	113
TROUBLE DIAGNOSIS FOR DTC P0120	
Throttle Position Sensor	
TROUBLE DIAGNOSIS FOR DTC P0125	
Engine Coolant Temperature (ECT) Sensor	
TROUBLE DIAGNOSIS FOR DTC P0130	
Front Heated Oxygen Sensor (Front HO2S)	129
TROUBLE DIAGNOSIS FOR DTC P0130	
Closed Loop Control	
TROUBLE DIAGNOSIS FOR DTC P0135	
Front Heated Oxygen Sensor Heater	
TROUBLE DIAGNOSIS FOR DTC P0136	
Rear Heated Oxygen Sensor (Rear HO2S)	139

CONTENTS (Cont'd.)

TROUBLE DIAGNOSIS FOR DTC P0141143	TROUBLE DIAGNOSIS FOR DTC P0705232	
Rear Heated Oxygen Sensor Heater143	Park/Neutral Position Switch	$\mathbb{M}\mathbb{A}$
TROUBLE DIAGNOSIS FOR DTC P0171148	TROUBLE DIAGNOSIS FOR DTC P1105237	
Fuel Injection System Function (Lean side)148	Manifold Absolute Pressure (MAP)/Barometric	
TROUBLE DIAGNOSIS FOR DTC P0172153	Pressure (BARO) Switch Solenoid Valve237	
Fuel Injection System Function (Rich side)153	TROUBLE DIAGNOSIS FOR DTC P1130243	
TROUBLE DIAGNOSIS FOR DTC P0180158	Swirl Control Valve Control Solenoid Valve243	r 🙈
Tank Fuel Temperature Sensor158	TROUBLE DIAGNOSIS FOR DTC P1165251	
TROUBLE DIAGNOSIS FOR DTC P0300 - P0304162	Swirl Control Valve Control Vacuum Check	
No. 4 - 1 Cylinder Misfire, Multiple Cylinder		EC
Misfire162	TROUBLE DIAGNOSIS FOR DTC P1320256	1.0
TROUBLE DIAGNOSIS FOR DTC P0335166	Ignition Signal256	
Crankshaft Position Sensor (CKPS) (OBD)166	TROUBLE DIAGNOSIS FOR DTC P1336262	Æ
TROUBLE DIAGNOSIS FOR DTC P0340171	Crankshaft Position Sensor (CKPS) (OBD)	
Camshaft Position Sensor (CMPS)171	(COG)262	
TROUBLE DIAGNOSIS FOR DTC P0400176	TROUBLE DIAGNOSIS FOR DTC P1400267	Cl.
EGR Function176	EGRC-Solenoid Valve267	
TROUBLE DIAGNOSIS FOR DTC P0402184	TROUBLE DIAGNOSIS FOR DTC P1401271	5.70
EGRC-BPT Valve Function184	EGR Temperature Sensor271	MT
TROUBLE DIAGNOSIS FOR DTC P0420186	TROUBLE DIAGNOSIS FOR DTC P1441276	
Three Way Catalyst Function186	Vacuum Cut Valve Bypass Valve276	AT
TROUBLE DIAGNOSIS FOR DTC P0440189	TROUBLE DIAGNOSIS FOR DTC P1445281	ZA\15
Evaporative Emission (EVAP) Control System	Evaporative Emission (EVAP) Canister Purge	
(Small Leak)189	Volume Control Valve281	TE
TROUBLE DIAGNOSIS FOR DTC P0443199	TROUBLE DIAGNOSIS FOR DTC P1447288	u D
Evaporative Emission (EVAP) Canister Purge	Evaporative Emission (EVAP) Control System	
Control Valve/Solenoid Valve	Purge Flow Monitoring288	
TROUBLE DIAGNOSIS FOR DTC P0446207	TROUBLE DIAGNOSIS FOR DTC P1550295	
Evaporative Emission (EVAP) Canister Vent	Torque Converter Clutch Solenoid Valve295	
Control Valve207	TROUBLE DIAGNOSIS FOR DTC P1900300	FA
TROUBLE DIAGNOSIS FOR DTC P0450212	Overheat300	
Evaporative Emission (EVAP) Control System	TROUBLE DIAGNOSIS FOR NON-DETECTABLE	DED 1/3
Pressure Sensor212	ITEMS303	RA
TROUBLE DIAGNOSIS FOR DTC P0500217	Injector303	
Vehicle Speed Sensor (VSS)217	Start Signal306	BR
TROUBLE DIAGNOSIS FOR DTC P0505221	Fuel Pump309	(E)(1)
Idle Air Control Valve (IACV) — Auxiliary Air	Power Steering Oil Pressure Switch313	
Control (AAC) Valve221	IACV-FICD Solenoid Valve317	ST
TROUBLE DIAGNOSIS FOR DTC P0510226	MIL & Data Link Connectors321	-
Closed Throttle Position Switch226	SERVICE DATA AND SPECIFICATIONS (SDS)323	
TROUBLE DIAGNOSIS FOR DTC P0605230	General Specifications323	RS
Engine Control Module (ECM)-ECCS Control	Inspection and Adjustment323	
Module230		
		BT

When you read wiring diagrams:

• Read GI section, "HOW TO READ WIRING DIAGRAMS".

• See EL section, "POWER SUPPLY ROUTING" for power distribution circuit. When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

 $\mathbb{H}\mathbb{A}$

EL

 $\mathbb{I}\mathbb{D}\mathbb{X}$

(Gi

DIAGNOSTIC TROUBLE CODE INDEX

Alphabetical & P No. Index for DTC

ALPHABETICAL INDEX FOR DTC

	DTC*3		
Items (CONSULT screen terms)	ECM*1	CONSULT GST*2	Reference page
Unable to access ECCS	_	_	EC-76
*COOLANT TEMP SEN	0908	P0125	EC-124
ABSOL PRESS SEN- SOR	0803	P0105	EC-100
CAMSHAFT POSI SEN	0101	P0340	EC-171
CLOSED LOOP	0307	P0130	EC-134
CLOSED THRL POS SW	0203	P0510	EC-226
COOLANT TEMP SEN*4	0103	P0115	EC-113
CRANK P/S (OBD) COG	0905	P1336	EC-262
CRANK POS SEN (OBD)	0802	P0335	EC-166
CYL 1 MISFIRE	0608	P0301	EC-162
CYL 2 MISFIRE	0607	P0302	EC-162
CYL 3 MISFIRE	0606	P0303	EC-162
CYL 4 MISFIRE	0605	P0304	EC-162
ECM	0301	P0605	EC-230
EGR SYSTEM	0302	P0400	EC-176
EGR TEMP SENSOR	0305	P1401	EC-271
EGRC SOLENOID/V	1005	P1400	EC-267
EGRC-BPT VALVE	0306	P0402	EC-184
EVAP PURG FLOW/ MON	0111	P1447	EC-288
EVAP SYS PRES SEN	0704	P0450	EC-212
EVAP (SMALL LEAK)	0705	P0440	EC-189
FRONT O2 SENSOR	0303	P0130	EC-129
FR O2 SEN HEATER	0901	P0135	EC-135
FUEL SYS DIAG-LEAN	0115	P0171	EC-148

	DTC*3		Bitimo
Items (CONSULT screen terms)	ECM*1	CONSULT GST*2	Reference page
FUEL SYS DIAG-RICH	0114	P0172	EC-153
IACV-AAC VALVE	0205	P0505	EC-221
IGN SIGNAL-PRIMARY	0201	P1320	EC-256
INT AIR TEMP SEN	0401	P0110	EC-107
MAP/BARO SW SOL/V	1302	P1105	EC-237
MASS AIR FLOW SEN*4	0102	P0100	EC-93
MULTI CYL MISFIRE	0701	P0300	EC-162
NO SELF DIAGNOSTIC FAILURE INDICATED	Flashing*5	No DTC	EC-45
NO SELF DIAGNOSTIC FAILURE INDICATED	0505	P0000	
OVER HEAT	0208	P1900*6	EC-300
PARK/NEUT POSI SW	1003	P0705	EC-232
PURG CONT/V & S/V	0807	P0443	EC-199
PURG VOLUME CONT/V	1008	P1445	EC-281
REAR O2 SENSOR	0707	P0136	EC-139
RR O2 SEN HEATER	0902	P0141	EC-143
SWIRL/V CONT VC SW	0112	P1165	EC-251
SWIRL CONT S/V	1004	P1130	EC-243
TANK FUEL TEMP SEN	0402	P0180	EC-158
THROTTLE POSI SEN*4	0403	P0120	EC-118
TOR CONV CLUTCH S/V	0904	P1550	EC-295
TW CATALYST SYSTEM	0702	P0420	EC-186
VC/V BYPASS/V	0801	P1441	EC-276
VEHICLE SPEED SEN	0104	P0500	EC-217
VENT CONTROL VALVE	0903	P0446	EC-207

^{*1:} In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

EC-2

^{*2:} These numbers are prescribed by SAE J2012. *3: 1st trip DTC No. is the same as DTC No.

^{*4:} When the fail-safe operation occurs, the MIL illuminates.

^{*5:} While engine is running.

^{*6:} Since this diagnosis does not meet P1900 of SAE J2012, it is indicated only by CONSULT.

DIAGNOSTIC TROUBLE CODE INDEX

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

DTC*3			
CONSULT GST*2	ECM*1	ltems (CONSULT screen terms)	Reference page
_	_	Unable to access ECCS	EC-76
No DTC	Flashing*5	NO SELF DIAGNOSTIC FAILURE INDICATED	EC-45
P0000	0505	NO SELF DIAGNOSTIC FAILURE INDICATED	
P0100	0102	MASS AIR FLOW SEN*4	EC-93
P0105	0803	ABSOL PRESS SEN- SOR	EC-100
P0110	0401	INT AIR TEMP SEN	EC-107
P0115	0103	COOLANT TEMP SEN*4	EC-113
P0120	0403	THROTTLE POSI SEN*4	EC-118
P0125	0908	*COOLANT TEMP SEN	EC-124
P0130	0307	CLOSED LOOP	EC-134
P0130	0303	FRONT O2 SENSOR	EC-129
P0135	0901	FR O2 SEN HEATER	EC-135
P0136	0707	REAR O2 SENSOR	EC-139
P0141	0902	RR 02 SEN HEATER	EC-143
P0171	0115	FUEL SYS DIAG-LEAN	EC-148
P0172	0114	FUEL SYS DIAG-RICH	EC-153
P0180	0402	TANK FUEL TEMP SEN	EC-158
P0300	0701	MULTI CYL MISFIRE	EC-162
P0301	0608	CYL 1 MISFIRE	EC-162
P0302	0607	CYL 2 MISFIRE	EC-162
P0303	0606	CYL 3 MISFIRE	EC-162
P0304	0605	CYL 4 MISFIRE	EC-162
P0335	0802	CRANK POS SEN (OBD)	€C-166
P0340	0101	CAMSHAFT POSI SEN	EC-171
P0400	0302	EGR SYSTEM	EC-176
P0402	0306	EGRC-BPT VALVE	EC-184
P0420	0702	TW CATALYST SYSTEM	EC-186
P0440	0705	EVAP (SMALL LEAK)	EC-189
P0443	0807	PURG CONT/V & S/V	EC-199
P0446	0903	VENT CONTROL VALVE	EC-207
P0450	0704	EVAP SYS PRES SEN	EC-212

DTC*3		Itome	Reference	MA
CONSULT GST*2	ECM*1	(CONSULT screen terms)	page	1.Ude-e
P0500	0104	VEHICLE SPEED SEN	EC-217	EM
P0505	0205	IACV-AAC VALVE	EC-221	
P0510	0203	CLOSED THRL POS SW	EC-226	[@
P0605	0301	ECM	EC-230	LC
P0705	1003	PARK/NEUT POSI SW	EC-232	
P1105	1302	MAP/BARO SW SOL/V	EC-237	EC
P1130	1004	SWIRL CONT S/V	EC-243	
P1165	0112	SWIRL/V CONT VC SW	EC-251	浸湿
P1320	0201	IGN SIGNAL-PRIMARY	EC-256	
P1336	0905	CRANK P/S (OBD) COG	EC-262	@1
P1400	1005	EGRC SOLENOID/V	EC-267	GL
P1401	0305	EGR TEMP SENSOR	EC-271	
P1441	0801	VC/V BYPASS/V	EC-276	Mili
P1445	1008	PURG VOLUME CONT/V	EC-281	WES
P1447	0111	EVAP PURG FLOW/ MON	EC-288	AT
P1550	0904	TOR CONV CLUTCH	EC-295	76
P1900*6	0208	OVER HEAT	EC-300	
	CONSULT GST*2 P0500 P0505 P0510 P0605 P0705 P1105 P1130 P1165 P1320 P1336 P1400 P1401 P1441 P1445 P1447	CONSULT GST*2 ECM*1 P0500 0104 P0505 0205 P0510 0203 P0605 0301 P0705 1003 P1105 1302 P1130 1004 P1165 0112 P1320 0201 P1336 0905 P1401 0305 P1441 0801 P1445 1008 P1447 0111 P1550 0904	Items	Items

^{*1:} In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.

EC-3 143

RA

88

FA

Œ

Sii

RS

TS

ĒL

^{*2:} These numbers are prescribed by SAE J2012.

^{*3: 1}st trip DTC No. is the same as DTC No.

^{*4:} When the fail-safe operation occurs, the MIL illuminates.

^{*5:} While engine is running.

^{*6:} Since this diagnosis does not meet P1900 of SAE J2012, it is indicated only by CONSULT.

PRECAUTIONS AND PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	1		
(J36471-A) Heated oxygen sensor wrench				Loosening or tightening front and rear heated oxygen sensors
EG17650301 (J33984-A)	NT379			Adapting radiator cap tester to radiator filler neck
Radiator cap tester adapter	NT564	80	a ‡ [] ‡ a	a: 28 (1.10) dia. b: 31.4 (1.236) dia. c: 41.3 (1.626) dia. Unit: mm (in)

Commercial Service Tool

Tool name	Description	
Fuel filler cap adapter		Checking fuel tank vacuum relief valve open- ing pressure
	NT653	

Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

144 EC-4

PRECAUTIONS AND PREPARATION

Precautions for On Board Diagnostic (OBD) System of Engine

The ECM (ECCS control module) has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc., will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to the open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. The interference of the harness with a bracket, etc., may cause the MIL to light up due to the short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to the malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the ECM before returning the vehicle to the customer.

GI

MA

EC

CL,

MT

AT

TF

PD

FA

RA

BR

ST

RS

87


HA

胍

Engine Fuel & Emission Control System

FUEL PUMP

- Do not operate fuel pump when there is no fuel in lines.
- Tighten fuel hose clamps to the specified torque. (Refer to MA section.)



ECM

- Do not disassemble ECCS control module (ECM).
- Do not turn diagnosis mode selector forcibly.
- If a battery terminal is disconnected, the memory will return to the ECM value.

The ECCS will now start to self-control at its initial value. Engine operation can vary slightly when the terminal is disconnected. However, this is not an indication of a problem. Do not replace parts because of a slight variation.

WHEN STARTING

- Do not depress accelerator pedal when starting.
- Immediately after starting, do not rev up engine unnecessarily.
- Do not rev up engine just prior to shutdown.

WIRELESS EQUIPMENT

- When installing CB ham radio or a mobile phone, be sure to observe the following as it may adversely affect electronic control systems depending on its installation location.
- Keep the antenna as far away as possible from the electronic control units.
- Keep the antenna feeder line more than 20 cm (7.9 in) away from the harness of electronic controls.
 Do not let them run parallel for a long distance.
- Adjust the antenna and feeder line so that the standing-wave ratio can be kept smaller.
- Be sure to ground the radio to vehicle body.



ECCS PARTS HANDLING


- Handle mass air flow sensor carefully to avoid damage.
- Do not disassemble mass air flow sensor.
- Do not clean mass air flow sensor with any type of detergent.
- Do not disassemble IACV-AAC valve.
- Even a slight leak in the air intake system can cause serious problems.
- Do not shock or jar the camshaft position sensor.

ECCS HARNESS HANDLING

- Securely connect ECCS harness connectors.
 - A poor connection can cause an extremely high (surge) voltage to develop in coil and condenser, thus resulting in damage to ICs.
- Keep ECCS harness at least 10 cm (3.9 in) away from adjacent harnesses, to prevent an ECCS system malfunction due to receiving external noise,
- Keep ECM parts and harnesses dry.
- Before removing parts, turn of ignition switch and then disconnect battery ground cable.

SEF903MC

PRECAUTIONS AND PREPARATION




Precautions

Before connecting or disconnecting the ECM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the ECM because battery voltage is applied to ECM even if ignition switch is turned off.



MA

LC



When connecting ECM harness connector, tighten securing bolt until the gap between orange indicators disappears.


3 - 5 N·m (0.3 - 0.5 kg-m, 26 - 43 in-lb)



FE

CL

MT



SEF291H

Bend

When connecting or disconnecting pin connectors into or from ECM, take care not to damage pin terminals (bend or break).

Make sure that there are not any bends or breaks on ECM pin terminal when connecting pin connectors.



TF

PD)

FA


RA

Before replacing ECM, perform ECM Terminals and Reference Value inspection and make sure ECM functions properly. Refer to EC-83.






1D)X




After performing each TROUBLE DIAGNOSIS, perform "OVERALL FUNCTION CHECK" or "DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE" The DTC should not be displayed in the "DTC CONFIRMA-

TION PROCEDURE" if the repair is completed. The "OVERALL FUNCTION CHECK" should be a good result if the repair is completed.




PRECAUTIONS AND PREPARATION




Precautions (Cont'd)

 When measuring ECM signals with a circuit tester, never allow the two tester probes to contact.
 Accidental contact of probes will cause a short circuit and damage the ECM power transistor.



System Diagram



SEF821T

*4: EVAP control system pressure sensor *5: EVAP canister purge volume control valve

*3: Vacuum cut valve bypass valve

*2: EVAP shut valve

*6: EVAP canister purge control valve


*1: Ignition coil, power transistor and camshaft position sensor built into distributor


*7: Crankshaft position sensor (OBD)

Fuel filter

ò

ECCS Component Parts Location






SEF725T


EC-11


(Gi)


ENGINE AND EMISSION CONTROL OVERALL SYSTEM

ECCS Component Parts Location (Cont'd)










Gi Vacuum Hose Drawing MA EGRC-BPT valve Swirl control valve actuator EGR valve Fuel pressure regulator LC To air cleaner-EC EGRC-solenoid Vacuum valve EVAP canister purge gallery Swirl control valve volume control valve control solenoid valve CL Throttle body EVAP canister purge control valve MT One-way valve AT TF EVAP canister purge PD control solenoid valve One-way valve FA MAP/BARO solenoid switch RA Vacuum gallery To EGRC-solenoid valve Swirl control valve control BR To EGRC-solenoid vacuum check switch valve To fuel pressure regulator ST To air RS To throttle cleaner To swirl control BT valve and solenoid valve To throttle body HA To EVAP canister To vacuum tank purge control solenoid valve To swirl control valve To 3 way control vacuum connector check switch IDX To MAP/BARO solenoid switch Refer to "System Diagram", EC-10 for vacuum control system.


EC-13

153

AEC146A



- *1: These sensors are not used to control the engine system. They are used only for the on board diagnosis.
- *2: This sensor is not used to control the engine system under normal conditions.
- *3: This switch will operate in place of the throttle position sensor to control EVAP parts if the sensor malfunctions.



BASIC MULTIPORT FUEL INJECTION SYSTEM

The amount of fuel injected from the fuel injector is determined by the ECM. The ECM controls the length of time the valve remains open (injection pulse duration). The amount of fuel injected is a program value in the ECM memory. The program value is preset by engine operating conditions. These conditions are determined by input signals (for engine speed and air intake) from both the camshaft position sensor and the mass air flow sensor.

VARIOUS FUEL INJECTION INCREASE/DECREASE COMPENSATION

In addition, the amount of fuel injection is compensated for to improve engine performance under various operating conditions as listed below. (Fuel increase)

RA

BR

ST

RS

BT

HA

퇸.

- During warm-up
- When starting the engine
- During acceleration
- Hot-engine operation
- High-load, high-speed operation


(Fuel decrease)

- During deceleration
- During high engine speed operation

JDX

EC-15 155

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION



Multiport Fuel Injection (MFI) System (Cont'd) MIXTURE RATIO FEEDBACK CONTROL

The mixture ratio feedback system provides the best air-fuel mixture ratio for driveability and emission control. The three way catalyst can then better reduce CO, HC and NOx emissions. This system uses a front heated oxygen sensor in the exhaust manifold to monitor if the engine is rich or lean. The ECM adjusts the injection pulse width according to the sensor voltage signal. For more information about front heated oxygen sensor, refer to page EC-129. This maintains the mixture ratio within the range of stoichiometric (ideal air-fuel mixture).

This stage is referred to as the closed loop control condition.

The rear heated oxygen sensor is located downstream of the three way catalyst. Even if the switching characteristics of the front heated oxygen sensor shift, the air-fuel ratio is controlled to stoichiometric by the signal from the rear heated oxygen sensor.

OPEN LOOP CONTROL

The open loop system condition refers to when the ECM detects any of the following conditions. Feedback control stops in order to maintain stabilized fuel combustion.

- Deceleration and acceleration
- High-load, high-speed operation
- Engine idling
- Malfunction of front heated oxygen sensor or its circuit
- Insufficient activation of front heated oxygen sensor at low engine coolant temperature
- High-engine coolant temperature
- During warm-up
- After shifting from "N" to "D"
- When starting the engine

MIXTURE RATIO SELF-LEARNING CONTROL

The mixture ratio feedback control system monitors the mixture ratio signal transmitted from the front heated oxygen sensor. This feedback signal is then sent to the ECM. The ECM controls the basic mixture ratio as close to the theoretical mixture ratio as possible. However, the basic mixture ratio is not necessarily controlled as originally designed. Both manufacturing differences (i.e. mass air flow sensor hot wire) and characteristic changes during operation (i.e., injector clogging) directly affect mixture ratio.


Accordingly, the difference between the basic and theoretical mixture ratios is monitored in this system. This is then computed in terms of "injection pulse duration" to automatically compensate for the difference between the two ratios.

"Fuel trim" refers to the feedback compensation value compared against the basic injection duration. Fuel trim includes short-term fuel trim and long-term fuel trim.

"Short-term fuel trim" is the short-term fuel compensation used to maintain the mixture ratio at its theoretical value. The signal from the front heated oxygen sensor indicates whether the mixture ratio is RICH or LEAN compared to the theoretical value. The signal then triggers a reduction in fuel volume if the mixture ratio is rich, and an increase in fuel volume if it is lean.

"Long-term fuel trim" is overall fuel compensation carried out longterm to compensate for continual deviation of the short-term fuel trim from the central value. Such deviation will occur due to individual engine differences, wear over time and changes in the usage environment.

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION



No. 1 cylinder JL...

No. 2 cylinder J

No. 3 cylinder JL

No. 4 cylinder J.

MEF523D

Multiport Fuel Injection (MFI) System (Cont'd) **FUEL INJECTION TIMING**

Two types of systems are used.

Sequential multiport fuel injection system

Fuel is injected into each cylinder during each engine cycle according to the firing order. This system is used when the engine is runnina.

EM

LC

(G)

MA

Simultaneous multiport fuel injection system

Fuel is injected simultaneously into all four cylinders twice each engine cycle. In other words, pulse signals of the same width are simultaneously transmitted from the ECM.

The four injectors will then receive the signals two times for each engine cycle.

This system is used when the engine is being started and/or if the fail-safe system (CPU) is operating.

FUEL SHUT-OFF

Fuel to each cylinder is cut off during deceleration or operation of the engine at excessively high speeds.


MT

Distributor Ignition (DI) System

INPUT/OUTPUT SIGNAL LINE

- 1 engine cycle

Simultaneous multiport fuel injection system



EC-17 157

EC

脬

C[_

AT

TF

FA


RA

RS

BT

HA

ENGINE AND EMISSION BASIC CONTROL SYSTEM DESCRIPTION



Distributor Ignition (DI) System (Cont'd) SYSTEM DESCRIPTION

The ignition timing is controlled by the ECM to maintain the best air-fuel ratio for every running condition of the engine.

The ignition timing data is stored in the ECM. This data forms the map shown.


The ECM detects information such as the injection pulse width and camshaft position sensor signal. Responding to this information, ignition signals are transmitted to the power transistor.

During the following conditions, the ignition timing is revised by the ECM according to the other data stored in the ECM.

- At starting
- During warm-up
- At idle
- When swirl control valve operates
- Hot engine operation
- During acceleration

Air Conditioning Cut Control

INPUT/OUTPUT SIGNAL LINE



SYSTEM DESCRIPTION

This system improves engine operation when the air conditioner is used.

Under the following conditions, the air conditioner is turned off.


- When the accelerator pedal is fully depressed.
- When cranking the engine.
- When the engine coolant temperature becomes excessively high.

Fuel Cut Control (at no load & high engine speed)

٩

MA

INPUT/OUTPUT SIGNAL LINE



If the engine speed is above 3,500 rpm with no load (for example, in neutral and engine speed over 3,500 rpm) fuel will be cut off after some time. The exact time when the fuel is cut off varies based on engine speed.

Fuel cut will operate until the engine speed reaches 1,500 rpm, then fuel cut is cancelled.

NOTE:

This function is different than deceleration control listed under multiport fuel injection on EC-15.

@L

MT

AT

TF

PD

iR∖A

SŢ

ŔS

BT


HiA

EL

10)X

EC-19 159

Description



The evaporative emission system is used to reduce hydrocarbons emitted into the atmosphere from the fuel system. This reduction of hydrocarbons is accomplished by activated charcoals in the EVAP canister.


The fuel vapor in the sealed fuel tank is led into the EVAP canister which contains activated carbon and the vapor is stored there when the engine is not operating.

The vapor in the EVAP canister is purged by the air through the purge line to the intake manifold when the engine is operating.

EVAP canister purge volume control valve is controlled by engine control module. When the engine operates, the flow rate of vapor controlled by EVAP canister purge volume control valve is proportionally regulated as the air flow increases.

EVAP canister purge control valve shuts off the vapor purge line during decelerating and idling, and under normal operating conditions the valve is usually open.

EVAP shut valve shuts off the vapor charge line when fuel is being supplied to the fuel tank.




Inspection

EVAP CANISTER

Check EVAP canister as follows:

- Pinch the fresh air vent hose.
- 2. Blow air in port (A) and check that it flows freely out of port (B).

EVAPORATIVE EMISSION SYSTEM



Inspection (Cont'd) TIGHTENING TORQUE

Tighten EVAP canister as shown in the figure.


Make sure new O-ring is installed properly between EVAP canister and EVAP canister vent control valve.

G[

MA

1.C

EC



FUEL TANK VACUUM RELIEF VALVE (Built into fuel filler cap)

Wipe clean valve housing.

2. Check valve opening pressure and vacuum.

Pressure:

15.3 - 20.0 kPa (0.156 - 0.204 kg/cm², 2.22 - 2.90 psi)


Vacuum:


-6.0 to -3.3 kPa (-0.061 to -0.034 kg/cm², -0.87 to -0.48 psi)

If out of specification, replace fuel filler cap as an assembly.

CAUTION:

Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.






When releasing the shutter, the valve is open.
 Plant air from and side of the EVAP shut valve.

2. Insert suitable steel tube as shown in the figure.

 Blow air from one side of the EVAP shut valve tube (a) or (b) and check that there is no air flow.



(a)

EVAP CANISTER PURGE CONTROL VALVE

Refer to EC-199.

SEF319QA

VACUUM CUT VALVE

Refer to EC-280.

EVAPORATIVE EMISSION (EVAP) CANISTER PURGE VOLUME CONTROL VALVE

Refer to EC-281.

EVAPORATIVE EMISSION (EVAP) CANISTER PURGE CONTROL SOLENOID VALVE

Refer to EC-199.

TANK FUEL TEMPERATURE SENSOR

Refer to EC-158.





FE

MT

Ati'

TF

PD

FA

BA

88

ST

RS

BT

[D] [·


טישב נו

EL

IDX


J*E211*J

Evaporative Emission Line Drawing



EVAPORATIVE EMISSION SYSTEM


Evaporative Emission Line Drawing (Cont'd)



SEF234S

(DX

POSITIVE CRANKCASE VENTILATION



Description

This system returns blow-by gas to the intake manifold collector. The positive crankcase ventilation (PCV) valve is provided to conduct crankcase blow-by gas to the intake manifold.


During partial throttle operation of the engine, the intake manifold sucks the blow-by gas through the PCV valve.

Normally, the capacity of the valve is sufficient to handle any blow-by and a small amount of ventilating air.

The ventilating air is then drawn from the air duct into the crankcase. In this process the air passes through the hose connecting air inlet tubes to the rocker cover.

Under full-throttle condition, the manifold vacuum is insufficient to draw the blow-by flow through the valve. The flow goes through the hose connection in the reverse direction.


On vehicles with an excessively high blow-by, the valve does not meet the requirement. This is because some of the flow will go through the hose connection to the intake collector under all conditions.



Inspection


PCV (Positive Crankcase Ventilation) VALVE


With engine running at idle, remove PCV valve from breather separator. A properly working valve makes a hissing noise as air passes through it. A strong vacuum should be felt immediately when a finger is placed over the valve inlet.





PCV HOSE


- Check hoses and hose connections for leaks.
- 2. Disconnect all hoses and clean with compressed air. If any hose cannot be freed of obstructions, replace.











Fuel Pressure Release

Before disconnecting fuel line, release fuel pressure from fuel line to eliminate danger.



- Start engine.
- Perform "FUEL PRESSURE RELEASE" in "WORK SUPPORT" mode with CONSULT. (Touch "START", and after engine stalls, crank it two or three times to release all fuel pressure.)

Turn ignition switch OFF.



1. Remove fuse for fuel pump.

Start engine.

After engine stalls, crank it two or three times to release all fuel pressure.

4. Turn ignition switch OFF and reinstall fuel pump fuse.

Fuel Pressure Check

- a. When reconnecting fuel line, always use new clamps.
- b. Make sure that clamp screw does not contact adjacent parts.
- c. Use a torque driver to tighten clamps.
- Use Pressure Gauge to check fuel pressure.
- 1. Release fuel pressure to zero.
- 2. Disconnect fuel hose between fuel filter and fuel tube (engine side).
- 3. Install pressure gauge between fuel filter and fuel tube.
- 4. Start engine and check for fuel leakage.
- 5. Read the indication of fuel pressure gauge.

At idling:

Approximately 235 kPa (2.4 kg/cm², 34 psi)
A few seconds after ignition switch is turned OFF to ON:

Approximately 294 kPa (3.0 kg/cm², 43 psi)

- 6. Stop engine and disconnect fuel pressure regulator vacuum hose from intake manifold.
- 7. Plug intake manifold with a rubber cap.
- 8. Connect variable vacuum source to fuel pressure regulator.

L©

GI

MA

EC

.FE

CL

MT

ÆT

PD

RA

BR

ST

RS


BT

KA.

EL

1DX


BASIC SERVICE PROCEDURE



Fuel Pressure Check (Cont'd)


9. Start engine and read indication of fuel pressure gauge as vacuum is changed.

Fuel pressure should decrease as vacuum increases. If results are unsatisfactory, replace fuel pressure regulator.




Injector Removal and Installation

- Release fuel pressure to zero.
- Remove injector tube assembly with injectors from intake manifold.
- Remove injectors from injector tube assembly.
- Push injector tail piece.
- Do not pull on the connector.
- 4. Install injector to fuel tube assembly.
- a. Clean exterior of injector tail piece.
- b. Use new O-rings.



Always replace O-rings with new ones. Lubricate O-rings with a smear of engine oil.



5. Install injectors with fuel tube assembly to intake manifold.


Tighten in numerical order shown in the figure.

- a. First, tighten all bolts to 9.3 to 10.8 N·m (0.95 to 1.1 kg-m, 6.9 to 8.0 ft-lb).
- b. Then, tighten all bolts to 21 to 26 N·m (2.1 to 2.7 kg-m, 15 to 20 ft-lb).
- Install fuel hoses to fuel tube assembly.
- 7. Reinstall any parts removed in reverse order of removal.

CAUTION:


After properly connecting injectors to fuel tube assembly, check connections for fuel leakage.

BASIC SERVICE PROCEDURE



Fast Idle Cam (FIC) Inspection and Adjustment


Remove air cleaner assembly.



 An alignment mark is stamped on the FIC so that the top of the cam will face in the correct direction.

LC

MA




 If necessary, adjust the FIC screw (A) until the alignment mark is centered on the lever roller. EC

FE

©,L

MT

AT



3. Start engine and warm up to operating temperature.

4. Measure clearance (a) between the lever roller and the top of the FIC using a feeler gauge as shown in the figure.

Clearance G:

M/T model 2.0 - 2.6 mm (0.079 - 0.102 in)

A/T model

1.8 - 2.4 mm (0.071 - 0.094 in)


(PIC)

TF

= c

FA

 $\mathbb{R}\!\!/\!\!\mathbb{A}$



If clearance G is out of specification, adjust clearance G using adjusting screw B to 2.3 mm (0.091 in) (M/T) or 2.1 mm (0.083 in) (A/T).

ST

RS

BT

[<u>F</u>]/A

EL

IDX


Idle Speed/Ignition Timing/Idle Mixture Ratio Adjustment

PREPARATION


- Make sure that the following parts are in good order.
- (1) Battery
- (2) Ignition system
- (3) Engine oil and coolant levels
- (4) Fuses
- (5) ECM harness connector
- (6) Vacuum hoses
- (7) Air intake system (Oil filler cap, oil level gauge, etc.)
- (8) Fuel pressure
- (9) Engine compression
- (10) EGR valve operation
- (11) Throttle valve
- (12) Evaporative emission (EVAP) canister purge control valve


- On air conditioner equipped models, checks should be carried out while the air conditioner is "OFF".
- When checking idle speed, ignition timing and mixture ratio of A/T models, shift lever to "N" position.
- When measuring "CO" percentage, insert probe more than 40 cm (15.7 in) into tail pipe.
- Turn off headlamps, heater blower, rear window defogger.
- Keep front wheels pointed straight ahead.
- Make the check after the cooling fan has stopped.

Overall inspection sequence




BASIC SERVICE PROCEDURE






SEF602K

BASIC SERVICE PROCEDURE




EC-31 ₁₇₁

BASIC SERVICE PROCEDURE



(Go to next page.)



EC-33 173

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Introduction

The ECM (ECCS control module) has an on board diagnostic system, which detects malfunctions related to engine sensors or actuators. The ECM also records various emission-related diagnostic information. Including:

• `	Diagnostic Trouble Code (DTC)	Mode 3 of SAE J1979
	Freeze Frame data	
•	System Readiness Test (SRT) code	Mode 1 of SAE J1979
	1st Trip Diagnostic Trouble Code (1st Trip DTC)	
	. ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	

1st Trip Freeze Frame data

The above information can be checked using procedures listed in the table below.

	DTC	1st trip DTC	Freeze Frame data	1st trip Freeze Frame data	SRT code	Test value
Diagnostic test mode II (Self- diagnostic results)	0	○ *1				
CONSULT	0	0	0	0	0	0
GST	0	⊜*2	0		0	0

^{*1:} When DTC and 1st trip DTC simultaneously appear on the display, they cannot be clearly distinguished from each other.

The malfunction indicator lamp (MIL) on the instrument panel lights up when the same malfunction is detected in two consecutive trips (Two trip detection logic), or when the ECM enters fail-safe mode (Refer to EC-76.).

Two Trip Detection Logic

When a malfunction is detected for the first time, 1st trip DTC and 1st trip Freeze Frame data are stored in the ECM memory. The MIL will not light up at this stage. (1st trip)

If the same malfunction is detected again during the next drive, the DTC and Freeze Frame data are stored in the ECM memory, and the MIL lights up. The MIL lights up at the same time when the DTC is stored. (2nd trip) The "trip" in the "Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation. Specific on board diagnostic items will cause the ECM to light up or blink the MIL and store DTC and Freeze Frame data, even in the 1st trip, as shown below.

	MIL			DTC		1st trip DTC	
Items	1st trip		2nd trip	1st trip	2nd trip	1st trip	2nd trip
	Blinking	Lighting up	lighting up	displaying	displaying	displaying	displaying
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 (0701, 0605 - 0608) is being detected	X			×		×	
Misfire (Possible three way catalyst damage) — DTC: P0300 - P0304 (0701, 0605 - 0608) has been detected		х		х		х	
Closed loop control — DTC: P0130 (0307)		х		х		х	
Fail-safe items (Refer to EC-76.)		Х		X*1		X*1	
Except above			x		Х	Х	Х

^{*1:} Except "ECM".

^{*2: 1}st trip DTCs for self-diagnoses concerning SRT items cannot be shown on the GST display.

Emission-related Diagnostic Information

DTC AND 1ST TRIP DTC

The 1st trip DTC (whose number is the same as the DTC number) is displayed for the latest self-diagnostic result obtained. If the ECM memory was cleared previously, and the 1st trip DTC did not reoccur, the 1st trip DTC will not be displayed. If a malfunction is detected during the 1st trip, the 1st trip DTC is stored in the ECM memory. The MIL will not light up (two trip detection logic). If the same malfunction is not detected in the 2nd trip (meeting the required driving pattern), the 1st trip DTC is cleared from the ECM memory. If the same malfunction is detected in the 2nd trip, both the 1st trip DTC and DTC are stored in the ECM memory and the MIL lights up. In other words, the DTC is stored in the ECM memory and the MIL lights up when the same malfunction occurs in two consecutive trips. If a 1st trip DTC is stored and a non-diagnostic operation is performed (for example, driving pattern A, refer to EC-52) between the 1st and 2nd trips, only the 1st trip DTC will continue to be stored. For malfunctions that blink or light up the MIL during the 1st trip, the DTC and 1st trip DTC are stored in the ECM memory.

Procedures for clearing the DTC and the 1st trip DTC from the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION". Refer to EC-43.

For malfunctions in which 1st trip DTCs are displayed, refer to EC-41. These items are required by legal regulation to continuously monitor the system/component. In addition, the items monitored non-continuously are also displayed on CONSULT.

1st trip DTC is specified in Mode 7 of SAE J1979. 1st trip DTC detection occurs without lighting up the MIL and therefore does not warn the driver of a problem. However, 1st trip DTC detection will not prevent the vehicle from being tested, for example during Inspection/Maintenance (I/M) tests.

When a 1st trip DTC is detected, check, print out or write down and erase (1st trip) DTC and Freeze Frame data as specified in "Work Flow" procedure Step II, refer to page EC-70. Then perform "DTC confirmation procedure" or "Overall function check" to try to duplicate the problem. If the malfunction is duplicated, the item requires repair.


How to read DTC and 1st trip DTC

DTC and 1st trip DTC can be read by the following methods.

- 1. The number of blinks of the malfunction indicator lamp in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 0101, 0201, 1003, 1104, etc.

 These DTCs are controlled by NISSAN.
- 2. CONSULT or GST (Generic Scan Tool) Examples: P0340, P1320, P0705, P0750, etc. These DTCs are prescribed by SAE J2012.

 (CONSULT also displays the malfunctioning component or system.)
- (CONSOLT also displays the manufactioning component of system.)
- 1st trip DTC No. is the same as DTC No.
- Output of a DTC indicates a malfunction. However, Mode II and GST do not indicate whether the
 malfunction is still occurring or has occurred in the past and has returned to normal.
 CONSULT can identify malfunction status as shown below. Therefore, using CONSULT (if available)
 is recommended.



A sample of CONSULT display for DTC is shown at left. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode of CONSULT. Time data indicates how many times the vehicle was driven after the last detection of a DTC. If the DTC is being detected currently, the time data will be "0".

EC-35 175

©i

MA

EM

1.0

EC

_

<u> 635</u>

MT

ÆT.

-0 U

PD)

TH

, ...

FA

(A)(2)


E (8)

S1.

37

HA

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION



Emission-related Diagnostic Information (Cont'd)

If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".

FREEZE FRAME DATA AND 1ST TRIP FREEZE FRAME DATA

The ECM records the driving conditions such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment a malfunction is detected.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data. The data, stored together with the DTC data, are called freeze frame data and are displayed on CONSULT or GST. The 1st trip freeze frame data can only be displayed on the CONSULT screen, not on the GST. For details, see EC-56.

Only one set of freeze frame data (either 1st trip freeze frame data or freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

Priority		Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0304 (0701, 0605 - 0608) Fuel Injection System Function — DTC: P0171 (0115), P0172 (0114)	
2		Except the above items (Includes A/T related items)	***
3	1st trip freeze frame	st trip freeze frame data	

For example, the EGR malfunction (Priority: 2) was detected and the freeze frame data was stored in the 2nd trip. After that when the misfire (Priority: 1) is detected in another trip, the freeze frame data will be updated from the EGR malfunction to the misfire. The 1st trip freeze frame data is updated each time a different malfunction is detected. There is no priority for 1st trip freeze frame data. However, once freeze frame data is stored in the ECM memory, 1st trip freeze frame data is no longer stored (because only one freeze frame data or 1st trip freeze frame data can be stored in the ECM). If freeze frame data is stored in the ECM memory and freeze frame data with the same priority occurs later, the first (original) freeze frame data remains unchanged in the ECM memory.

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased. Procedures for clearing the ECM memory are described in "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION". Refer to EC-43.

SYSTEM READINESS TEST (SRT) CODE

System Readiness Test (SRT) code is specified in Mode 1 of SAE J1979. It indicates whether the self-diagnostic tests for non-continuously monitored items have been completed or not.

Inspection/Maintenance (I/M) tests of the on board diagnostic (OBD) II system may become the legal requirement in some states/areas. All SRT codes must be set in this case. Unless all SRT codes are set, conducting the I/M test may not be allowed.

SRT codes are set after self-diagnosis has been performed two or more times. This occurs regardless of whether the diagnosis is in "OK" or "NG", and whether or not the diagnosis is performed in consecutive trips. The following table lists the 5 SRT items (9 test items) for the ECCS used in D21 models.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emissio	n-related	Diagnostic	Information
(Cont'd)		_	

(G)

MA

EM

LC

EC

FE

CL

MT

TF

PD

FA

RA

BR

ST

RS

BT


HA

Mall

SRT items	Self-diagnostic test items	
Catalyst monitoring	● Three way catalyst function P0420 (0702)	
EVAP system monitoring	 EVAP control system (Small Leak) P0440 (0705) EVAP control system purge flow monitoring P1447 (0111) 	
Oxygen sensor monitoring	 Front heated oxygen sensor P0130 (0503) Rear heated oxygen sensor P0136 (0707) 	
Oxygen sensor heater monitoring	 Front heated oxygen sensor heater P0135 (0901) Rear heated oxygen sensor heater P0141 (0902) 	
EGR system monitoring	● EGR function P0400 (0302) ● EGRC-BPT valve function P0402 (0306)	


Together with the DTC, the SRT code is cleared from the ECM memory using the method described later (Refer to EC-43). In addition, after ECCS components/systems are repaired or if the battery terminals remain disconnected for more than 24 hours, all SRT codes may be cleared from the ECM memory.

How to display SRT code



1. Selecting "SRT" in "SRT-OBD TEST VALUE" mode with CONSULT For items whose SRT codes are set, a "CMPLT" is displayed on the CONSULT screen; for items whose SRT codes are not set, "INCMP" is displayed.

2. Selecting Mode 1 with GST (Generic Scan Tool)



A sample of CONSULT display for SRT code is shown at left. "INCMP" means the self-diagnosis is incomplete and SRT is not set. "CMPLT" means the self-diagnosis is complete and SRT is set.


How to set SRT code

To set all SRT codes, self-diagnosis for the items indicated above must be performed two or more times. Each diagnosis may require a long period of actual driving under various conditions. The most efficient driving pattern in which SRT codes can be properly set is explained on the next page. The driving pattern should be performed two times or more to set all SRT codes.

EC-37 177

Emission-related Diagnostic Information (Cont'd)

Driving pattern



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

The time required for each diagnosis varies with road surface conditions, weather, altitude, individual driving habits, etc.

Zone A refers to the range where the time required, for the diagnosis under normal conditions*, is the shortest. Zone B refers to the range where the diagnosis can still be performed if the diagnosis is not completed within zone A.

- *: Normal conditions refer to the following:
- Sea level
- Fiat road
- Ambient air temperature: 20 30°C (68 86°F)
- Diagnosis is performed as quickly as possible under normal conditions.

Under different conditions [For example: amblent air temperature other than 20 - 30°C (68 - 86°F)], diagnosis may also be performed.

Pattern 1: • The engine is started at the engine coolant temperature of -10 to 35°C (14 to 95°F) (where the voltage between the ECM terminals (51) and (43) is 3.0 - 4.3V).

 The engine must be operated at idle speed until the engine coolant temperature is greater than 70°C (158°F) (where the voltage between the ECM terminals (51) and (43) is lower than 1.4V).

Pattern 2: When steady-state driving is performed again even after it is interrupted, each diagnosis can be conducted. In this case, the time required for diagnosis may be extended.

Pattern 3: • The driving pattern outlined in *2 must be repeated at least 3 times.

On M/T models, shift gears following "suggested upshift speeds" schedule at right.

Pattern 4: • Tests are performed after the engine has been operated for at least 12 minutes.


 The accelerator pedal must be held very steady during steady-state driving.

 If the accelerator pedal is moved, the test must be conducted all over again.

*1: Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH), then release the accelerator pedal and keep it released for more than 10 seconds. Depress the accelerator pedal until vehicle speed is 90 km/h (56 MPH) again.

*2: Operate the vehicle in the following driving pattern.

- 1) Decelerate vehicle to 0 km/h and let engine idle.
- 2) Repeat driving pattern shown below at least 10 times.
 - During acceleration, hold the accelerator pedal as steady as possible. (The THRTL POS SEN value of CONSULT should be between 0.8 to 1.2V.)
- 3) Repeat steps 1 and 2 until the EGR system SRT is set.



SEF414S

- *3: The driving pattern may be omitted when EVAP (SMALL LEAK) checks are performed using the FUNCTION TEST mode of CONSULT.
- *4: Checking the vehicle speed with CONSULT or GST is advised.

Suggested transmission gear position for A/T models

Set the selector lever in the "D" position with the overdrive switch turned ON.

Suggested upshift speeds for M/T models

Shown below are suggested vehicle speeds for shifting into a higher gear. These suggestions relate to fuel economy and vehicle performance. Actual upshift speeds will vary according to road conditions, weather and individual driving habits.

For normal acceleration in low altitude areas [less than 1,219 m (4,000 ft)]:

Gear change	ACCEL shift point km/h (MPH)	CRUISE shift point km/h (MPH)
1st to 2nd	24 (15)	23 (14)
2nd to 3rd	40 (25)	28 (17)
3rd to 4th	65 (40)	44 (27)
4th to 5th	75 (45)	61 (38)

For high altitude areas [over 1,219 m (4,000 ft)] and quick acceleration in low altitude areas:

Gear change	km/h (MPH)
1st to 2nd	24 (15)
2nd to 3rd	40 (25)
3rd to 4th	64 (40)
4th to 5th	72 (45)

Suggested maximum speed in each gear

Downshift to a lower gear if the engine is not running smoothly, or if you need to accelerate.

Do not exceed the maximum suggested speed (shown below) in any gear. For level road driving, use the highest gear suggested for that speed. Always observe posted speed limits and drive according to the road conditions to ensure safe operation. Do not over-rev the engine when shifting to a lower gear as it may cause engine damage or loss of vehicle control.

o or vornor oc	7116101.	
Gear	km/h (MPH)	
	2WD models	4WD models (2H position)
1st	50 (30)	40 (25)
2nd	90 (55)	70 (43)
3rd	130 (80)	110 (68)
4th	_	
5th	_	

(H

MA

r 🙉

EC

C

FE

ŒL.

Mī

£=∆1;

PD

TF

D) (A

BR

ST

RS

Bir

HA

EL

10X

EC-39 ₁₇₉

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Emission-related Diagnostic Information (Cont'd)

TEST VALUE AND TEST LIMIT

The following is the information specified in Mode 6 of SAE J1979.

The test value is a parameter used to determine whether a system/circuit diagnostic test is "OK" or "NG" while being monitored by the ECM during self-diagnosis. The test limit is a reference value which is specified as the maximum or minimum value and is compared with the test value being monitored.

Items for which these data (test value and test limit) are displayed are the same as SRT code items (9 test items).

These data (test value and test limit) are specified by Test ID (TID) and Component ID (CID) and can be displayed on the CONSULT screen or GST.

X: Applicable
—: Not applicable

SRT item		Test value				
(CONSULT	Self-diagnostic test item	GST	display	CONSULT	Test limit	Application
display)		TID	CID	display		
CATALYST	Warm-up three way catalyst function	01H	01H	Parameter 1	Max.	х
EVAD SVSTEM	EVAP control system (Small leak)	05H	03H	Parameter 1	Max.	Х
EVAP SYSTEM	EVAP control system purge flow monitoring	06H	83H	Parameter 2	Min.	Х
		09H	04H	Parameter 1	Max.	X
	Front heated oxygen sensor	0AH	84H	Parameter 2	Min.	Х
		0BH	04H	Parameter 3	Max.	Х
		0CH	04H	Parameter 4	Max.	Х
O2 SENSOR		0DH	04H	Parameter 5	Max.	Х
		19H	86H	Parameter 6	Min.	X
	Rear heated oxygen sensor	1AH	86H	Parameter 7	Min.	X
		1BH	06H	Parameter 8	Max.	Х
		1CH	06H	Parameter 9	Max.	Х
	Front heated	29H	08H	Parameter 1	Max.	X
O2 SENSOR	oxygen sensor heater	2AH	88H	Parameter 1	Min.	Х
HEATER	Rear heated	2DH	0AH	Parameter 1	Max.	Х
	oxygen sensor - heater	2EH	8AH	Parameter 1	Min.	Х
		31H	8CH	Parameter 1	Min.	Х
		32H	8CH	Parameter 2	Min.	X
	EGR function	33H	8CH	Parameter 3	Min.	Х
EGR SYSTEM		34H	8CH	Parameter 4	Min.	X
		35H	0CH	Parameter 5	Max.	X
	EGRC-BPT valve	36H	0CH	Parameter 6	Max.	Х
	function	37H	8CH	Parameter 7	Min.	X

Emission-related Diagnostic Information (Cont'd)

EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS

X: Applicable —: Not applicable

	та	C*3		—			
Items (CONSULT screen terms)	CONSULT GST*2	ECM*1	SRT code	Test value/ Test limit	1st trip DTC	Reference page	EM
NO SELF DIAGNOSTIC FAIL- URE INDICATED	P0000	0505	-	_	_	_	L©
MASS AIR FLOW SEN	P0100	0102	_	_	X	EC-93	
ABSOL PRESS SENSOR	P0105	0803	_	_	x	EC-100	EC
INT AIR TEMP SEN	P0110	0401		_	x	EC-107	-
COOLANT TEMP SEN	P0115	0103			х	EC-113	
THROTTLE POSI SEN	P0120	0403	_	_	х	EC-118	FE
*COOLANT TEMP SEN	P0125	0908	_	_	×	EC-124	•
CLOSED LOOP	P0130	0307		_	×	EC-134	GL
FRONT O2 SENSOR	P0130	0503	X	Х	X*4	EC-129	-
FR O2 SEN HEATER	P0135	0901	Х	Х	X*4	EC-135	- - MT
REAR O2 SENSOR	P0136	0707	Х	Х	X*4	EC-139	- 600.0
RR O2 SEN HEATER	P0141	0902	Х	X	X*4	EC-143	-
FUEL SYS DIAG LEAN	P0171	0115			Х	EC-148	AT
FUEL SYS DIAG RICH	P0172	0114	_	_	х	EC-153	-
TANK FUEL TEMP SEN	P0180	0402	_	_	х	EC-158	- 7F
MULTI CYL MISFIRE	P0300	0701	_	_	Х	EC-162	-
CYL 1 MISFIRE	P0301	0608		_	х	EC-162	- - PD
CYL 2 MISFIRE	P0302	0607		_	х	EC-162	- ITL9
CYL 3 MISFIRE	P0303	0606			X	EC-162	_
CYL 4 MISFIRE	P0304	0605	-	_	Х	EC-162	FA
CRANK POS SEN (OBD)	P0335	0802	_		X	EC-166	-
CAMSHAFT POSI SEN	P0340	0101		_	х	EC-171	- IRA
EGR SYSTEM	P0400	0302	X	X	X*4	EC-176	_
EGRC-BPT VALVE	P0402	0306	Х	X	X*4	EC-184	- - BR
TW CATALYST SYS	P0420	0702	X	х	X*4	EC-186	- DW
EVAP (SMALL LEAK)	P0440	0705	х	х	X*4	EC-189	_
PURG CONT/V & S/V	P0443	0807	_	 -	X	EC-199	ST
VENT CONTROL VALVE	P0446	0903	_	_	X	EC-207	_
EVAP SYS PRES SEN	P0450	0704		_	X	EC-212	– RS

^{*1:} In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.
*2: These numbers are prescribed by SAE J2012.
*3: 1st trip DTC No. is the same as DTC No.
*4: These are not displayed with GST.

EC-41

G[-

MIA

BT

ΗA

EL

181

Emission-related Diagnostic Information (Cont'd)

X: Applicable
—: Not applicable

	DT	°C*3		Test value/		
Items (CONSULT screen terms)	CONSULT GST*2	ECM*1	SRT code	Test limit	1st trip DTC	Reference page
VEHICLE SPEED SEN	P0500	0104		_	х	EC-217
IACV-AAC VALVE	P0505	0205	_		×	EC-221
CLOSED THRL POS SW	P0510	0203	_	_	×	EC-226
ECM	P0605	0301	_	_	×	EC-230
PARK/NEUT POSI SW	P0705	1003	_	_	×	EC-232
MAP/BARO SW SOL/V	P1105	1302	_	_	×	EC-237
SWIRL CONT S/V	P1130	1004	_	_	×	EC-243
SWIRL/V CONT VC SW	P1165	0112		_	×	EC-251
IGN SIGNAL-PRIMARY	P1320	0201	_		×	EC-256
CRANK P/S (OBD) COG	P1336	0905			×	EC-262
EGRC SOLENOID/V	P1400	1005			Х	EC-267
EGR TEMP SENSOR	P1401	0305	_	_	х	EC-271
VC/V BYPASS/V	P1441	0801	_	_	Х	EC-276
PURGE VOLUME CONT/V	P1445	1008	_	_	×	EC-281
EVAP PURGE FLOW/MON	P1447	0111	х	х	X*4	EC-288
TOR CONV CLUTCH S/V	P1550	0904	_	_	X	EC-295


^{*1:} In Diagnostic Test Mode II (Self-diagnostic results). These numbers are controlled by NISSAN.
*2: These numbers are prescribed by SAE J2012.
*3: 1st trip DTC No. is the same as DTC No.
*4: These are not displayed with GST.

Emission-related Diagnostic Information GI (Cont'd) HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION The emission-related diagnostic information can be erased by the following methods. MA Selecting "ERASE" in the "SELF-DIAG RESULTS" mode with CONSULT Selecting Mode 4 with GST (Generic Scan Tool) EM (No Changing the diagnostic test mode from Diagnostic Test Mode II to Mode I by turning the mode selector on the ECM (Refer to EC-46.) LC If the battery is disconnected, the emission-related diagnostic information will be lost after approx. 24 hours. EC Erasing the emission-related diagnostic information using CONSULT or GST is easier and quicker than switching the mode selector on the ECM. The following data are cleared when the ECM memory is erased. 冒記 1. Diagnostic trouble codes 2. 1st trip diagnostic trouble codes 3. Freeze frame data CL 4. 1st trip freeze frame data 5. System readiness test (SRT) codes 6. Test values MD? 7. Others Actual work procedures are explained using a DTC as an example. Be careful so that not only the DTC, but all of the data listed above, are cleared from the ECM memory during work procedures. AT How to erase DTC (With CONSULT) Note: If the diagnostic trouble code is not for A/T related items (see EC-2), skip steps 2 through 4. ΥĒ 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 7 seconds and then turn it "ON" (engine stopped) again. PD 2. Turn CONSULT "ON" and touch "A/T". 3. Touch "SELF-DIAG RESULTS". 4. Touch "ERASE". (The DTC in the A/T control unit will be erased.) Then touch "BACK" twice. 5. Touch "ENGINE" FA 6. Touch "SELF-DIAG RESULTS". 7. Touch "ERASE". (The DTC in the ECM will be erased.) If DTCs are displayed for both ECM and A/T control unit, they need to be erased individually from the ECM and A/T control unit. BR ST. RS B1: HA Ш

EC-43 183

IDX

Emission-related Diagnostic Information (Cont'd)



How to erase DTC (With GST)


Note: If the diagnostic trouble code is not for A/T related items (see EC-2), skip step 2.

- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 7 seconds and then turn it "ON" (engine stopped) again.
- 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
- 3. Select Mode 4 with GST (Generic Scan Tool).

(NO Tools) How to erase DTC (No Tools)

Note: If the diagnostic trouble code is not for A/T related items (see EC-2), skip step 2.

- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 7 seconds and then turn it "ON" again.
- 2. Perform "SELF-DIAGNOSTIC PROCEDURE (Without CONSULT)" in AT section titled "TROUBLE DIAGNOSIS", "Self-diagnosis". (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
- Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. (See EC-46.)



Malfunction Indicator Lamp (MIL)

The malfunction indicator lamp will light up when the ignition switch is turned ON without the engine running. This is a bulb check.

If the malfunction indicator lamp does not light up, refer to EL section ("WARNING LAMPS") or see EC-321.

When the engine is started, the malfunction indicator lamp should go off.

If the lamp remains on, the on board diagnostic system has detected an engine system malfunction.

EC

@[

MA

圓쎄

[_0

ON BOARD DIAGNOSTIC SYSTEM FUNCTION

The on board diagnostic system has the following four functions.

Diagnostic Test Mode I

1. BULB CHECK

: This function checks the MIL bulb for damage (blown, open circuit,

If the MIL does not come on, check MIL circuit and ECM test mode

selector. (See next page.)

2. MALFUNCTION WARNING

: This is a usual driving condition. When a malfunction is detected twice in two consecutive driving cycles (two trip detection logic), the MIL will light up to inform the driver that a malfunction has been detected. The following malfunctions will light up or blink the MIL in the 1st trip.

"Misfire (Possible three way catalyst damage)"

"Closed loop control"

Fail-safe mode

Diagnostic Test Mode II

3. SELF-DIAGNOSTIC RESULTS

: This function allows DTCs and 1st trip DTCs to be read.

4. FRONT HEATED OXY-GEN SENSOR MONI-TOR

This function allows the fuel mixture condition (lean or rich), monitored by front heated oxygen sensor, to be read.

MIL flashing without DTC

If the ECM is in Diagnostic Test Mode II, MIL may flash when engine is running. In this case, check ECM test mode selector following "HOW TO SWITCH DIAGNOSTIC TEST MODES" on next page. Refer to "HOW TO SWITCH DIAGNOSTIC TEST MODES" on next page.

Со	ndition	Diagnostic Test Mode I	Diagnostic Test Mode II	S)
Ignition switch	Engine stopped	BULB CHECK	SELF-DIAGNOSTIC RESULTS	<u>R</u> (
tion (Con)	Engine running	MALFUNCTION WARNING	FRONT HEATED OXYGEN SENSOR MONITOR	

EC-45 185

CL

MT

AT

TF

PD

FA

BR

RA


T

lA.

EL

Malfunction Indicator Lamp (MIL) (Cont'd)

HOW TO SWITCH DIAGNOSTIC TEST MODES



Malfunction Indicator Lamp (MIL) (Cont'd)

DIAGNOSTIC TEST MODE I—BULB CHECK

In this mode, the MALFUNCTION INDICATOR LAMP on the instrument panel should stay ON. If it remains OFF, check the bulb. Refer to EL section ("WARNING LAMPS") or see EC-321.

DIAGNOSTIC TEST MODE I—MALFUNCTION WARNING


MALFUNCTION INDICATOR LAMP	Condition
ON	When the malfunction is detected or the ECM's CPU is malfunctioning.
OFF	No malfunction.


These Diagnostic Trouble Code Numbers are clarified in Diagnostic Test Mode II (SELF-DIAGNOSTIC RESULTS).

DIAGNOSTIC TEST MODE II—SELF-DIAGNOSTIC RESULTS

In this mode, the DTC and 1st trip DTC are indicated by the number of blinks of the MALFUNCTION INDI-CATOR LAMP.

The DTC and 1st trip DTC are displayed at the same time. If the MIL does not illuminate in diagnostic test mode 1 (Malfunction warning), all displayed items are 1st trip DTCs. If only one code is displayed when the MIL illuminates in diagnostic test mode if (SELF-DIAGNOSTIC RESULTS), it is a DTC; if two or more codes are displayed, they may be either DTCs or 1st trip DTCs. DTC No. is same as that of 1st trip DTC. These unidentified codes can be identified by using the CONSULT or GST. A DTC will be used as an example for how to read a code.





Long (0.6 second) blinking indicates the number of ten digits, and short (0.3 second) blinking indicates the number of single digits. For example, the malfunction indicator lamp blinks 10 times for 6 seconds (0.6 sec x 10 times) and then it blinks three times for about 1 second (0.3 sec x 3 times). This indicates the DTC "1003" and refers to the malfunction of the park/neutral position switch.

In this way, all the detected malfunctions are classified by their diagnostic trouble code numbers. The DTC "0505" refers to no malfunction. (See DIAGNOSTIC TROUBLE CODE INDEX, EC-2.)

HOW TO ERASE DIAGNOSTIC TEST MODE II (Self-diagnostic results)

The diagnostic trouble code can be erased from the backup memory in the ECM when the diagnostic test mode is changed from Diagnostic Test Mode II to Diagnostic Test Mode I. (Refer to "HOW TO SWITCH DIAGNOS-TIC TEST MODES" on previous page.)

- If the battery is disconnected, the diagnostic trouble code will be lost from the backup memory after approx. 24 hours.
- Be careful not to erase the stored memory before starting trouble diagnoses.

EC

(Gi)

MA

EM

LC

CL

MIT

AT

TF

PD

BA

RA

88

ST

RS

BT

MA

MDX

Malfunction Indicator Lamp (MIL) (Cont'd)

DIAGNOSTIC TEST MODE II—FRONT HEATED OXYGEN SENSOR MONITOR

In this mode, the MALFUNCTION INDICATOR LAMP displays the condition of the fuel mixture (lean or rich) which is monitored by the front heated oxygen sensor.

MALFUNCTION INDICATOR LAMP	Fuel mixture condition in the exhaust gas	Air fuel ratio feedback control condition
ON	Lean	Closed loop system
OFF	Rich	Closed loop system
*Remains ON or OFF	Any condition	Open loop system

^{*:} Maintains conditions just before switching to open loop.

To check the front heated oxygen sensor function, start engine in Diagnostic Test Mode II. Then warm it up until engine coolant temperature indicator points to middle of gauge.

Next run engine at about 2,000 rpm for about 2 minutes under no-load conditions. Make sure that the MAL-FUNCTION INDICATOR LAMP comes ON more than 5 times within 10 seconds with engine running at 2,000 rpm under no-load.

OBD System Operation Chart

RELATIONSHIP BETWEEN MIL, 1ST TRIP DTC, DTC, AND DETECTABLE ITEMS

- When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data are stored in the ECM memory.
- When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data are stored in the ECM memory, and the MIL will come on. For details, refer to "Two Trip Detection Logic" on EC-34.
- The MIL will go off after the vehicle is driven 3 times with no malfunction. The drive is counted only when
 the recorded driving pattern is met (as stored in the ECM). If another malfunction occurs while counting,
 the counter will reset.
- The DTC and the freeze frame data will be stored until the vehicle is driven 40 times (driving pattern A) without the same malfunction recurring (except for Misfire and Fuel Injection System). For Misfire and Fuel Injection System, the DTC and freeze frame data will be stored until the vehicle is driven 80 times (driving pattern C) without the same malfunction recurring. The "TIME" in "SELF-DIAGNOSTIC RESULTS" mode of CONSULT will count the number of times the vehicle is driven.
- The 1st trip DTC is not displayed when the self-diagnosis results in "OK" for the 2nd trip.

SUMMARY CHART

ltems	Fuel Injection System	Misfire	Except the lefts
MIL (goes off)	3 (pattern B)	3 (pattern B)	3 (pattern B)
DTC, Freeze Frame Data (no display)	80 (pattern C)	80 (pattern C)	40 (pattern A)
1st Trip DTC (clear)	1 (pattern C), *1	1 (pattern C), *1	1 (pattern B)
1st Trip Freeze Frame Data (clear)	*1, *2	*1, *2	1 (pattern B)


Details about patterns "A", "B", and "C" are on EC-50, 52.

^{*1:} Clear timing is at the moment OK is detected.

^{*2:} Clear timing is when the same malfunction is detected in the 2nd trip.

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS FOR "MISFIRE" <EXHAUST QUALITY DETERIORATION>, "FUEL INJECTION SYSTEM"



- *1: When the same malfunction is detected in two consecutive trips, MIL will light up
- *2: MIL will go off after vehicle is driven three times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in **ECM**
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 80 times (pattern C) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: The 1st trip DTC and the 1st trip freeze frame data will be cleared at the moment OK is detected.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.
- *8: 1st trip DTC will be cleared when vehicle is driven once (pattern C) without the same malfunction after DTC is stored in ECM.

G

EM

10

EC

55

MIT

AT

TF

PD

RA

88

ST

RS

Ta

FIA

EL

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

(Driving pattern B)

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will reset when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without the malfunction.
- The MIL will go off when the B counter reaches 3. (*2 in "OBD SYSTEM OPERATION CHART")

⟨Driving pattern C⟩

Driving pattern C means the vehicle operation as follows:

- (1) The following conditions should be satisfied at the same time:
 Engine speed: (Engine speed in the freeze frame data) ±375 rpm
 Calculated load value: (Calculated load value in the freeze frame data) x (1±0.1) [%]
 Engine coolant temperature (T) condition:
- When the freeze frame data shows lower than 70°C (158°F), "T" should be lower than 70°C (158°F).
- When the freeze frame data shows higher than or equal to 70°C (158°F), "T" should be higher than or equal to 70°C (158°F).

Example:

If the stored freeze frame data is as follows:

Engine speed: 850 rpm, Calculated load value: 30%, Engine coolant temperature: 80°C (176°F)


To be satisfied with driving pattern C, the vehicle should run under the following conditions:

Engine speed: 475 - 1,225 rpm, Calculated load value: 27 - 33%, Engine coolant temperature: more than ≥ 70°C (158°F)

- The C counter will be cleared when the malfunction is detected regardless of (1).
- The C counter will be counted up when (1) is satisfied without the same malfunction.
- The DTC will not be displayed after C counter reaches 80.
- The 1st trip DTC will be cleared when C counter is counted once without the same malfunction after DTC is stored in ECM.

OBD System Operation Chart (Cont'd)

RELATIONSHIP BETWEEN MIL, DTC, 1ST TRIP DTC AND DRIVING PATTERNS <u>EXCEPT</u> FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"



EC-51

- *1: When the same malfunction is detected in two consecutive trips, MIL will light up.
- *2: MIL will go off after vehicle is driven three times (pattern B) without any malfunctions.
- *3: When the same malfunction is detected in two consecutive trips, the DTC and the freeze frame data will be stored in ECM.
- *4: The DTC and the freeze frame data will not be displayed any longer after vehicle is driven 40 times (pattern A) without the same malfunction. (The DTC and the freeze frame data still remain in ECM.)
- *5: When a malfunction is detected for the first time, the 1st trip DTC and the 1st trip freeze frame data will be stored in ECM.
- *6: 1st trip DTC will be cleared after vehicle is driven once (pattern B) without the same malfunction.
- *7: When the same malfunction is detected in the 2nd trip, the 1st trip freeze frame data will be cleared.

191

MA

Œ[

LC

EC

Æ

CIL.

MT

AT

715

PD

FA

RA

PR

ST

RS

BŢ

HA


2 35 4

10X

OBD System Operation Chart (Cont'd)

EXPLANATION FOR DRIVING PATTERNS <u>EXCEPT</u> FOR "MISFIRE <EXHAUST QUALITY DETERIORATION>", "FUEL INJECTION SYSTEM"

(Driving pattern A)




- The A counter will be cleared when the malfunction is detected regardless of (1) (4).
- The A counter will be counted up when (1) (4) are satisfied without the same malfunction.
- The DTC will not be displayed after the A counter reaches 40.

(Driving pattern B)

Driving pattern B means the vehicle operation as follows:

All components and systems should be monitored at least once by the OBD system.

- The B counter will be cleared when the malfunction is detected once regardless of the driving pattern.
- The B counter will be counted up when driving pattern B is satisfied without any malfunctions.
- The MIL will go off when the B counter reaches 3 (*2 in "OBD SYSTEM OPERATION CHART").



CONSULT **CONSULT INSPECTION PROCEDURE** Turn ignition switch OFF.

MA

(Gl

Connect "CONSULT" to data link connector for CONSULT. (Data link connector for CONSULT is located behind the fuse

box cover.)

LC

EC

NISSAN CONSULT **START** SUB MODE

> SELECT SYSTEM **ENGINE**

Turn ignition switch ON. Touch "START".

FE

MI

C:L

5. Touch "ENGINE".

Δľ

TF

PD

[=/A

RA

| Մայ SELECT DIAG MODE lacksquareprocedure. For further information, see the CONSULT Operation Manual. WORK SUPPORT **SELF-DIAG RESULTS** DATA MONITOR **ACTIVE TEST**

SBR455D

SEF895K

6. Perform each diagnostic test mode according to each service

ST


BR

BT

RS

HA

EJ.



SRT- OBD TEST VALUE

FUNCTION TEST

CONSULT (Cont'd)

ECCS COMPONENT PARTS/CONTROL SYSTEMS APPLICATION

					DIAGN	OSTIC TEST	MODE		
ĺ				SELF-DIA	GNOSTIC				
ĺ		_	WORK	RESU	LTS*1			FUNC-	SRT-OBD
ĺ		ltem	SUP-		FREEZE	DATA	ACTIVE	TION	TEST
ĺ			PORT		FRAME	MONITOR	TEST	TEST	VALUE
			PORT		1			IESI	VALUE
	1	T			DATA*2				ļ
		Camshaft position sensor		X	X	Х			ļ
		Mass air flow sensor		X		Х			-
		Engine coolant temperature sen-		X	Х	x	Х		
		sor							<u> </u>
i	i	Front heated oxygen sensor		X		X		X	X
		Rear heated oxygen sensor		Х		Х			X
		Vehicle speed sensor		X	Х	X		X	<u> </u>
		Throttle position sensor	Χ	X		Х		Х	ļ
		Tank fuel temperature sensor		Х		Х			
		EVAP control system pressure		X		x			
		sensor							
		Absolute pressure sensor		X	·	X			
		EGR temperature sensor		Х		X			
	INPUT	Intake air temperature sensor		X		Х			
		Crankshaft position sensor		х					
		(OBD)		_ ^					<u> </u>
	1	Ignition switch (start signal)				X		Х	
		Closed throttle position switch		X					
		Closed throttle position switch		1					
		(throttle position sensor signal)				X		Х	ļ
		Air conditioner switch				X			
	i	Park/Neutral position switch		Х		X		X	
		Power steering oil pressure				1			
10		switch				X [Х	
Ë		Swirl control valve control							
ΑF		vacuum check switch		X		X			
-		Battery voltage				X			-
z		Injectors		 		X	X	X	
Ž		Injectors		X (Igni-				<u> </u>	
ECCS COMPONENT PARTS		Power transistor (Ignition timing)	Х	tion sig-		x	X	×	
₹		Power transistor (ignition timing)	^			^	^	^	
ರ		14074440		nal)		- V	X	X	
တ္လ		IACV-AAC valve	Х	X		X	X		
ပ္ထ		EVAP canister purge volume		X		x	X		
ш		control valve				<u> </u>			
		Air conditioner relay				X			-
		Fuel pump relay	X			X	X	X	
		EGRC-solenoid valve		X		Х	Х	Х	
	i	Swirl control valve control sole-		Х		x	Х	Х	
		noid valve							
	OUTPUT	Front heated oxygen sensor		X		x			X
		heater		^					
į		Rear heated oxygen sensor		X		x			X
		heater							
		Torque converter clutch solenoid		X		x		i	
		valve							<u> </u>
		EVAP canister purge control				·x	Χ		
		solenoid valve		X		^	^		
		EVAP canister vent control valve		Х		Х			
		Vacuum cut valve bypass valve	•	Х		Х			
		MAP/BARO switch solenoid							
1		valve		X		X	Х		
		Calculated load value			Х	X			

X: Applicable

^{*1:} This item includes 1st trip DTCs.

^{*2:} This mode includes 1st trip freeze frame data or freeze frame data. The items appear on CONSULT screen in freeze frame data mode only if a 1st trip DTC or DTC is detected. For details, refer to EC-36.

CONSULT (Cont'd)

FUNCTION

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on the CONSULT unit.
Self-diagnostic results	Self-diagnostic results such as 1st trip DTC, DTCs and 1st trip freeze frame data or freeze frame data can be read and erased quickly.*1
Data monitor	Input/Output data in the ECM can be read.
Active test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ECMs and also shifts some parameters in a specified range.
SRT-OBD test value	The status of system monitoring tests and the test values/test limits can be read.
Function test	Conducted by CONSULT instead of a technician to determine whether each system is "OK" or "NG".
ECM part numbers	ECM part numbers can be read.

- *1: The following emission-related diagnostic information is cleared when the ECM memory is erased.
 - 1. Diagnostic trouble codes
 - 2. 1st trip diagnostic trouble codes
 - 3. Freeze frame data
 - 4. 1st trip freeze frame data
 - 5. System readiness test (SRT) codes
 - 6. Test values
 - 7. Others

WORK SUPPORT MODE

WORK ITEM	CONDITION	USAGE
THRTL POS SEN ADJ	CHECK THE THROTTLE POSITION SENSOR SIGNAL. ADJUST IT TO THE SPECIFIED VALUE BY ROTATING THE SENSOR BODY UNDER THE FOLLOWING CONDITIONS. IGN SW "ON" ENG NOT RUNNING ACC PEDAL NOT PRESSED	When adjusting throttle position sensor initial position
IGNITION TIMING ADJ	 IGNITION TIMING FEEDBACK CONTROL WILL BE HELD BY TOUCHING "START". AFTER DOING SO, ADJUST IGNITION TIMING WITH A TIMING LIGHT BY TURNING THE CRANKSHAFT POSITION SENSOR. 	When adjusting initial ignition timing
IACV-AAC VALVE ADJ	SET ENGINE SPEED AT THE SPECIFIED VALUE UNDER THE FOLLOWING CONDITIONS. • ENGINE WARMED UP • NO-LOAD	
FUEL PRESSURE RELEASE	FUEL PUMP WILL STOP BY TOUCHING "START" DURING IDLING. CRANK A FEW TIMES AFTER ENGINE STALLS.	When releasing fuel pressure from fuel line

EC-55 195

@[

MA

LC

EC

FE

CL

WY

AT

717

PD)

FA

RAS

38

T

38

3T

CONSULT (Cont'd)

SELF-DIAGNOSTIC MODE

DTC and 1st trip DTC

Regarding items of "DTC and 1st trip DTC", refer to "EMISSION-RELATED DIAGNOSTIC INFORMATION ITEMS" (See EC-41.)

Freeze frame data and 1st trip freeze frame data

Freeze frame data item*	Description
DIAG TROUBLE CODE [PXXXX]	 ECCS component part/control system has a trouble code, it is displayed as "PXXXX". [Refer to "Alphabetical & P No. Index for DTC (EC-2).]
FUEL SYS DATA	 "Fuel injection system status" at the moment a malfunction is detected is displayed. One mode in the following is displayed. "MODE 2": Open loop due to detected system malfunction "MODE 3": Open loop due to driving conditions (power enrichment, deceleration enrichment) "MODE 4": Closed loop - using oxygen sensor(s) as feedback for fuel control "MODE 5": Open loop - has not yet satisfied condition to go to closed loop
CAL/LD VALUE [%]	The calculated load value at the moment a malfunction is detected is displayed.
COOLANT TEMP [°C] or [°F]	The engine coolant temperature at the moment a malfunction is detected is displayed.
S-FUEL TRIM [%]	 "Short-term fuel trim" at the moment a malfunction is detected is displayed. The short-term fuel trim indicates dynamic or instantaneous feedback compensation to the base fuel schedule.
L-FUEL TRIM [%]	 "Long-term fuel trim" at the moment a malfunction is detected is displayed. The long-term fuel trim indicates much more gradual feedback compensation to the base fuel schedule than short-term fuel trim.
ENGINE SPEED [rpm]	The engine speed at the moment a malfunction is detected is displayed.
VHCL SPEED [km/h] or [mph]	The vehicle speed at the moment a malfunction is detected is displayed.
ABSOL PRES [kPa] or [kg/cm²] or [psi]	The intake manifold absolute pressure at the moment a malfunction is detected is displayed.

^{*:} The items are same as those of 1st trip freeze frame data.

[Unit]	ECM input signals	Main signals	Description	Remarks
CMPS·RPM (POS) [rpm]	0	0	 Indicates the engine speed computed from the POS signal (1° signal) of the camshaft position sensor. 	
CMPS·RPM (REF) [rpm]	0		 Indicates the engine speed computed from the REF signal (180° signal) of the camshaft position sensor. 	 The accuracy of detection becomes poor if engine speed drops below the idle rpm. If the signal is interrupted while the engine is running, an abnormal value may be indicated.
MAS AIR/FL SE [V]	0	0	The signal voltage of the mass air flow sensor is displayed.	When the engine is stopped, a certain value is indicated.
COOLAN TEMP/S [°C] or [°F]	0	0	 The engine coolant temperature (determined by the signal voltage of the engine coolant temperature sensor) is displayed. 	 When the engine coolant temperature sensor is open or short-circuited, ECM enters fail-safe mode. The engine cool- ant temperature determined by the ECM is displayed.
FR O2 SENSOR [V]	\bigcirc	0	 The signal voltage of the front heated oxygen sensor is displayed. 	
RR O2 SENSOR [V]		\circ	 The signal voltage of the rear heated oxygen sensor is displayed. 	
FR O2 MNTR [RICH/LEAN]	0	0	 Display of front oxygen sensor signal during air-fuel ratio feedback control: RICH means the mixture became "rich", and control is being affected toward a leaner mixture. LEAN means the mixture became "lean", and control is being affected toward a rich mixture. 	 After turning ON the ignition switch, "RICH" is displayed until air-fuel mixture ratio feedback control begins. When the air-fuel ratio feedback is clamped, the value just before the clamp- ing is displayed continuously.
RR O2 MNTR RICH/LEAN]	0		 Display of rear heated oxygen sensor signal: RICH means the amount of oxygen downstream three way catalyst is rela- tively small. LEAN means the amount of oxygen downstream three way catalyst is rela- tively large. 	When the engine is stopped, a certain value is indicated.
/HCL SPEED SE km/h] or [mph]	0	0	The vehicle speed computed from the vehicle speed sensor signal is displayed.	
			gatch the vehicle being diagnosed is o	leleted from the display automatically
IOTE: .ny monitored item	that doe	es not n	later the vernote being diagnosed is e	,
	tnat doe	as not n	later the vernote being diagnosed is e	,
	tnat doe	TOIT R	later the vernote being diagnosed is e	

CONSULT (Cont'd) Monitored item **ECM** Main Remarks [Unit] input Description signals signals BATTERY VOLT [V] The power supply voltage of ECM is dis-• The throttle position sensor signal volt-THRTL POS SEN [V] age is displayed. TANK F/TMP SE [°C] • The fuel temperature judged from the or [°F] tank fuel temperature sensor signal voltage is displayed. EGR TEMP SEN [V] The signal voltage of the EGR temperature sensor is displayed. INT/A TEMP SE [°C] • The intake air temperature determined by or [°F] the signal voltage of the intake air temperature sensor is indicated. · After starting the engine, [OFF] is dis-START SIGNAL Indicates [ON/OFF] condition from the played regardless of the starter signal. [ON/OFF] starter signal. CLSD THL/P SW Indicates [ON/OFF] condition from the closed throttle position switch signal. [ON/OFF] AIR COND SIG • Indicates [ON/OFF] condition of the air conditioner switch as determined by the [ON/OFF] air conditioner signal. P/N POSI SW Indicates [ON/OFF] condition from the [ON/OFF] park/neutral position switch signal. PW/ST SIGNAL [ON/OFF] condition of the power steering oil pressure switch determined by the [ON/OFF] power steering oil pressure signal is indi-**IGNITION SW** Indicates [ON/OFF] condition from igni-[ON/OFF] tion switch. SWL CON VC SW Indicates [ON/OFF] condition of swirl [ON/OFF] control valve control vacuum check switch determined by ECM according to the input signal. ON ... Atmospheric pressure OFF ... Vacuum pressure INJ PULSE [msec] Indicates the actual fuel injection pulse When the engine is stopped, a certain width compensated by ECM according to computed value is indicated. the input signals. **B/FUEL SCHDL** · "Base fuel schedule" indicates the fuel [msec] injection pulse width programmed into ECM, prior to any learned on-board cor-IGN TIMING [BTDC] Indicates the ignition timing computed by ECM according to the input signals.

	 ::		CONSULT (Cont'd)	
Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
IACV-AAC/V [%]		0	 Indicates the idle air control valve (AAC valve) control value computed by ECM according to the input signals. 	
PURG VOL C/V [step]			 Indicates the EVAP canister purge volume control valve computed by the engine control module according to the input signals. The opening becomes larger as the value increases. 	
A/F ALPHA [%]			 The mean value of the air-fuel ratio feed- back correction factor per cycle is indi- cated. 	 When the engine is stopped, a certain value is indicated. This data also includes the data for the air-fuel ratio learning control.
EVAP SYS PRES [V]		0	 The signal voltage of EVAP control sys- tem pressure sensor is displayed. 	
AIR COND RLY [ON/OFF]			 The air conditioner relay control condition (determined by ECM according to the input signal) is indicated. 	
FUEL PUMP RLY [ON/OFF]			 Indicates the fuel pump relay control con- dition determined by ECM according to the input signals. 	
SWRL CONT S/V			 The control condition of the swirl control valve control solenoid valve (computed by the ECM according to the input sig- nal) is indicated. ON Swirl control valve is closed OFF Swirl control valve is open 	
EGRC SOL/V [ON/OFF]			 The control condition of the EGRC-sole- noid valve (determined by ECM accord- ing to the input signal) is indicated. ON EGR operation is cut-off OFF EGR is operational 	
TCC SOL/V			 The control condition of the torque con- verter clutch solenoid valve (determined by ECM according to the input signal) is 	
			indicated. ON Lock-up is cancelled OFF Lock-up is operational	
VENT CONT/V (ON/OFF]			 The control condition of the EVAP canister vent control valve (determined by ECM according to the input signal) is 	
			indicated. ON Closed OFF Open	
FR O2 HEATER	1	-	 Indicates [ON/OFF] condition of front heated oxygen sensor heater determined by ECM according to the input signals. 	
VC/V BYPASS/V ON/OFF]			 The control condition of the vacuum cut valve bypass valve (determined by ECM according to the input signal) is indicated. ON Open 	

EC-59 199

CONSULT (Cont'd)

OGNOCET (Cont a)				
Monitored item [Unit]	ECM input signals	Main signals	Description	Remarks
PURG CONT S/V [ON/OFF]			 The control condition of the EVAP canister purge control solenoid valve (computed by the engine control module according to the input signals) is indicated. ON Canister purge is operational OFF Canister purge operation is cutoff 	
RR O2 HEATER			 Indicates [ON/OFF] condition of front heated oxygen sensor heater determined by ECM according to the input signals. 	
CAL/LD VALUE [%]			 "Calculated load value" indicates the value of the current airflow divided by peak airflow. 	
ABSOL TH·P/S [%]			 "Absolute throttle position sensor" indi- cates the throttle opening computed by ECM according to the signal voltage of the throttle position sensor. 	
MASS AIRFLOW [g·m/s]			 Indicates the mass airflow computed by ECM according to the signal voltage of the mass airflow sensor. 	
MAP/BARO SW/V [MAP/BARO]			 The control condition of the MAP/BARO switch solenoid valve (determined by ECM according to the input signal) is indicated. MAP Intake manifold absolute pressure BARO Barometric pressure 	
ABSOL PRES/SE [V]			 The signal voltage of the absolute pres- sure sensor is displayed. 	
VOLTAGE [V]			Voltage measured by the voltage probe.	
PULSE [msec] or [Hz] or [%]			 Pulse width, frequency or duty cycle measured by the pulse probe. 	 Only "#" is displayed if item is unable to be measured. Figures with "#"s are temporary ones. They are the same figures as an actual piece of data which was just previously measured.

CONSULT (Cont'd)

TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
FUEL INJECTION	Engine: Return to the original trouble condition Change the amount of fuel injection using CONSULT.	If trouble symptom disappears, see CHECK ITEM.	Harness and connector Fuel injectors Front heated oxygen sensor
IACV-AAC/V OPEN- ING	 Engine: After warming up, idle the engine. Change the IACV-AAC valve opening percent using CONSULT. 	Engine speed changes according to the opening percent.	Harness and connector IACV-AAC valve
ENG COOLANT TEMP	 Engine: Return to the original trouble condition Change the engine coolant tempera- ture using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	 Harness and connector Engine coolant temperature sensor Fuel injectors
IGNITION TIMING	 Engine: Return to the original trouble condition Timing light: Set Retard the ignition timing using CONSULT. 	If trouble symptom disappears, see CHECK ITEM.	 Adjust initial ignition timing
POWER BALANCE	 Engine: After warming up, idle the engine. Air conditioner switch "OFF" Shift lever "N" Cut off each injector signal one at a time using CONSULT. 	Engine runs rough or dies.	 Harness and connector Compression Injectors Power transistor Spark plugs Ignition coils
FUEL PUMP RELAY	 Ignition switch: ON (Engine stopped) Turn the fuel pump relay "ON" and "OFF" using CONSULT and listen to operating sound. 	Fuel pump relay makes the operating sound.	Harness and connector Fuel pump relay
EGRC SOLENOID VALVE	 Ignition switch: ON Turn solenoid valve "ON" and "OFF" with CONSULT and listen to operating sound. 	Solenoid valve makes an operating sound.	Harness and connector Solenoid valve
SWIRL CONT SOL VALVE	 Ignition switch: ON (Engine stopped) Turn solenoid valve "ON" and "OFF" with CONSULT and listen to operating sound. 	Solenoid valve makes an operating sound.	Harness and connector Solenoid valve Swirl control valve Vacuum hose
SELF-LEARNING CONT	 In this test, the coefficient of self-learning the screen. 	ng control mixture ratio returns to the origin	nal coefficient by touching "CLEAR" on
PURG VOL CONT/V	 Engine: After warming up, run engine at 1,500 rpm. Change the EVAP canister purge vol- ume control valve opening step using CONSULT. 	Engine speed changes according to the opening step.	Harness and connector EVAP canister purge volume control valve
PURG CONT S/V	Start engine. Turn the EVAP canister purge control solenoid valve "ON" and "OFF" using CONSULT and listen for operating sound.	EVAP canister purge control solenoid valve makes an operating sound. Check vacuum signal for EVAP canister purge control valve. VC ON Vacuum exists. VC OFF Vacuum does not exist.	Harness and connector EVAP canister purge control solenoid valve Vacuum hose
MAP/BARO SW/V	Ignition switch: ON (Engine stopped) Turn the MAP/BARO switch solenoid valve between "MAP" and "BARO" using CONSULT and listen for operating sound.	MAP/BARO switch solenoid valve makes an operating sound.	Harness and connector MAP/BARO switch solenoid valve
ANK F/TEMP SEN	Change the tank fuel temperature using	g CONSULT.	

IDX

EC-61 201

CONSULT (Cont'd)

FUNCTION TEST MODE

FUNCTION TEST ITEM	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
SELF-DIAG RESULTS	 Ignition switch: ON (Engine stopped) Displays the results of on board diagnostic system. 			Objective system	
CLOSED THROTTLE POSI (CLOSED	 Ignition switch: ON (Engine stopped) Closed throttle position switch circuit is tested when throttle is opened and 	Throttle valve: opened	OFF	 Harness and connector Throttle position sensor (Closed throttle position switch) Throttle position sensor 	
THROTTLE POSITION SWITCH CIRCUIT)	closed fully. ("IDLE POSI- TION" is the test item name for the vehicles in which idle is selected by throttle posi- tion sensor.)	Throttle valve: closed	ON	(Closed throttle position switch) adjustment ■ Throttle linkage ■ Verify operation in DATA MONITOR mode.	
THROTTLE POSI SEN CKT	 Ignition switch: ON (Engine stopped) Throttle position sensor circuit is tested when throttle is opened and closed fully. 	Range (Throttle valve fully opened — Throttle valve fully closed)	More than 3.0V	 Harness and connector Throttle position sensor Throttle position sensor adjustment Throttle linkage Verify operation in DATA MONITOR mode. 	
PARK/NEUT POSI	 Ignition switch: ON (Fngine stopped) Inhibitor/Neutral position 	OUT OF N/P-RANGE	OFF	Harness and connector Neutral position switch/	
SW CKT	switch circuit is tested when shift lever is manipulated.	IN N/P-RANGE	ON	Inhibitor switch Linkage + Inhibitor switch adjustment	
FUEL PUMP CIRCUIT	 Ignition switch: ON (Engine stopped) Fuel pump circuit is tested by checking the pulsation in fuel pressure when fuel tube is pinched. 	There is pressure pulsation on the fuel feed hose.		 Harness and connector Fuel pump Fuel pump relay Fuel filter clogging Fuel level 	
EGRC SOL/V CIR- CUIT	I ■ EGRC-solenoid valve circuit I		The solenoid valve makes an operating sound every 3 seconds.		
noid valve operating noise. ● Ignition switch: ON → START ● Start signal circuit is tested when engine is started by operating the starter. Battery START SIGNAL		Start signal: OFF → ON		Harness and connectorIgnition switch	

FUNCTION TEST	CONDITION	JUDGEMENT		CHECK ITEM (REMEDY)	
ITEM PW/ST SIGNAL	 Ignition switch: ON (Engine running) Power steering circuit is tested when steering wheel 	Locked position	ON	Harness and connectorPower steering oil pressure	
CIRCUIT	is rotated fully and then set to a straight line running position.	Neutral position	OFF	switch Power steering oil pump	
SWRL CONT S/V CIRCUIT	Ignition switch: ON (Engine stopped) Swirl control valve control solenoid valve circuit is tested by checking solenoid valve operating sound. Ignition switch: ON (Engine stopped) The solenoid valve makes an operating sound every 3 seconds.		 Harness and connector Solenoid valve Swirl control valve Vacuum hose 		
VEHICLE SPEED SEN CKT	 Vehicle speed sensor circuit is tested when vehicle is running at a speed of 10 km/h (6 MPH) or higher. 	Vehicle speed sensor input sigr greater than 4 km/h (2 MPH)	nal is	Harness and connectorVehicle speed sensorSpeedometer	
GN TIMING ADJ	 After warming up, idle the engine. Ignition timing adjustment is checked by reading ignition timing with a timing light and checking whether it agrees with specifications. 	The timing light indicates the same value		 Adjust ignition timing (by moving camshaft position sensor or distributor) Camshaft position sensor drive mechanism 	
MIXTURE RATIO	 Air-fuel ratio feedback circuit (injection system, ignition system, vacuum system, etc.) is tested by examining 	Front heated oxygen sensor CO		 INJECTION SYS (Injector, fuel pressure regulator, harness or connector) IGNITION SYS (Spark plug, power transistor, ignition coil, harness or connector) VACUUM SYS (Intake air 	
FEST	the front heated oxygen sensor output at 2,000 rpm under non-loaded state.	circuit Front heated oxyger operation Fuel pressure high o		Front heated oxygen sensor circuitFront heated oxygen sensor	
POWER BALANCE	bustion of each cylinder. (This is only displayed for	Difference in engine speed is greater than 25 rpm before and after cutting off the injector of each cylinder.		 Injector circuit (Injector, harness or connector) Ignition circuit (Spark plug, power transistor, ignition coil, harness or connector) Compression Valve timing 	
	models where a sequential multiport fuel injection system is used.)			_	

EC-63 203

CONSULT (Cont'd)

FUNCTION TEST ITEM	CONDITION	JUDGEMENT	CHECK ITEM (REMEDY)
IACV-AAC/V SYSTEM	 After warming up, idle the engine. IACV-AAC valve system is tested by detecting change in engine speed when IACV-AAC valve opening is changed to 0%, 20% and 80%. 	Difference in engine speed is greater than 150 rpm between when valve opening is at 80% and at 20%.	 Harness and connector IACV-AAC valve Air passage restriction between air inlet and IACV-AAC valve IAS (Idle adjusting screw) adjustment
★EVAP (SMALL LEAK)	 After warming up, idle the engine etc. EVAP system is tested by using the evaporative gas pressure in the fuel tank or engine intake manifold pressure. 	 EVAP control system has no leak. EVAP control system operates properly. 	 Incorrect fuel tank vacuum relief valve Incorrect fuel filler cap used Fuel filler cap remains open or fails to close. Foreign matter caught in fuel filler cap. Leak is in line between intake manifold and EVAP canister purge control valve. Foreign matter caught in EVAP canister vent control valve. EVAP canister or fuel tank leaks EVAP purge line tube leaks EVAP purge line rubber tube bent. Biocked or bent rubber tube to EVAP control system pressure sensor EVAP canister purge control valve EVAP canister purge volume control valve EVAP canister purge control solenoid valve Absolute pressure sensor Tank fuel temperature sensor Tank fuel temperature sensor MAP/BARO switch solenoid valve Blocked or bent rubber tube to MAP/BARO switch solenoid valve Loose or disconnected rubber tube O-ring of EVAP canister vent control valve is missing or damaged

^{★:} Always select "SINGLE TEST" with CONSULT when performing the "FUNCTION TEST".

CONSULT (Cont'd)

REAL TIME DIAGNOSIS IN DATA MONITOR MODE

CONSULT has two kinds of triggers and they can be selected by touching "SETTING" in "DATA MONITOR" mode.

- 1. "AUTO TRIG" (Automatic trigger):
 - The malfunction will be identified on the CONSULT screen in real time.

In other words, DTC/1st trip DTC and malfunction item will be displayed at the moment the malfunction is detected by ECM.

DATA MONITOR can be performed continuously until a malfunction is detected. However, DATA MONI-TOR cannot continue any longer after the malfunction detection.


- 2. "MANU TRIG" (Manual trigger):
 - DTC/1st trip DTC and malfunction item will not be displayed automatically on CONSULT screen even though a malfunction is detected by ECM.
 - DATA MONITOR can be performed continuously even though a malfunction is detected.

Use these triggers as follows:

- 1. "AUTO TRIG"
 - While trying to detect the DTC/1st trip DTC by performing the "DTC CONFIRMATION PROCEDURE", be sure to select to "DATA MONITOR (AUTO TRIG)" mode. You can confirm the malfunction at the moment it is detected.
 - While narrowing down the possible causes, CONSULT should be set in "DATA MONITOR (AUTO) TRIG)" mode, especially in case the incident is intermittent. When you are inspecting the circuit by gently shaking (or twisting) the suspicious connectors, compo-

nents and harness in the "DTC CONFIRMATION PROCEDURE", the moment a malfunction is found the DTC will be displayed. (Refer to GI section, "Incident Simulation Tests" in "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".)

- 2. "MANU TRIG"
 - If the malfunction is displayed as soon as "DATA MONITOR" is selected, reset CONSULT to "MANU TRIG". By selecting "MANU TRIG" you can monitor and store the data. The data can be utilized for further diagnosis, such as a comparison with the value for the normal operating condition.



EC-65 205

MA

G1

EM

LC

EC

MT

ÆT

TE

PD)

FA

RA

郎

ST


RS

BT

HA.

EL

M




Generic Scan Tool (GST)

DESCRIPTION

Generic Scan Tool (OBDII scan tool) complying with SAE J1978 has 7 different functions explained on the next page.


ISO9141 is used as the protocol.

The name "GST" or "Generic Scan Tool" is used in this service manual.



GST INSPECTION PROCEDURE

- Turn off ignition switch.
- Connect "GST" to data link connector for GST. (Data link connector for GST is located under LH dash panel near the fuse box cover.)



- 3. Turn ON ignition switch.
- Enter the program according to instruction on the screen or in the operation manual.
- (*: Regarding GST screens in this section, sample screens are shown.)

OBD II FUNCTIONS

F0: DATA LIST
F1: FREEZE DATA
F2: DTCS
F3: SNAPSHOT
F4: CLEAR DIAG INFO
F5: O2 TEST RESULTS
F6: READINESS TESTS
F7: ON BOARD TESTS
F8: EXPAND DIAG PROT
F9: UNIT CONVERSION

Sample screen*

SEF416S

Perform each diagnostic mode according to each service procedure.

For further information, see the GST Operation Manual of the tool maker.

Generic Scan Tool (GST) (Cont'd)

G

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

\$1)

RS

BT

RA.


SI.

IDX


FILE	NC	TI	\cap	N
	IIV	1 1	u	N

Diagnostic test mode		Function
MODE 1	READINESS TESTS	This mode gains access to current emission-related data values, including analog inputs and outputs, digital inputs and outputs, and system status information.
MODE 2	(FREEZE DATA)	This mode gains access to emission-related data value which were stored by ECM during the freeze frame. [For details, refer to "Freeze frame data and 1st trip freeze frame data" (EC-56).]
MODE 3	DTCs	This mode gains access to emission-related power train trouble codes which were stored by ECM.
		This mode can clear all emission-related diagnostic information. This includes: Clear number of diagnostic trouble codes (MODE 1) Clear diagnostic trouble codes (MODE 3)
MODE 4	CLEAR DIAG INFO	 Clear trouble code for freeze frame data (MODE 1) Clear freeze frame data (MODE 2) Clear heated oxygen sensor test data (MODE 5) Reset status of system monitoring test (MODE 1) Clear on board monitoring test results (MODE 6 and 7)
MODE 5	(O2 TEST RESULTS)	This mode gains access to the on board heated oxygen sensor monitoring test results.
MODE 6	(ON BOARD TESTS)	This mode accesses the results of on board diagnostic monitoring tests of specific components/systems that are not continuously monitored.
MODE 7	(ON BOARD TESTS)	This mode enables the off board test drive to obtain test results for emission-related powertrain components/systems that are continuously monitored during normal driving conditions.

EC-67 207







Introduction

The engine has an ECM to control major systems such as fuel control, ignition control, idle air control system, etc. The ECM accepts input signals from sensors and instantly drives actuators. It is essential that both input and output signals are proper and stable. At the same time, it is important that there are no problems such as vacuum leaks, fouled spark plugs, or other problems with the engine.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT (or GST) or a circuit tester connected should be performed. Follow the "Work Flow" on EC-70.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example on the next page should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

KEY POINTS

WHAT Vehicle & engine model
WHEN Date, Frequencies
WHERE..... Road conditions
HOW Operating conditions,
Weather conditions,

Symptoms

SEF907L

Diagnostic Worksheet

There are many operating conditions that lead to the malfunction of engine components. A good grasp of such conditions can make troubleshooting faster and more accurate.

In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Utilize a diagnostic worksheet like the one on next page in order to organize all the information for troubleshooting.

Some conditions may cause the malfunction indicator lamp to come on steady or blink and DTC to be detected. Examples:

- Vehicle ran out of fuel, which caused the engine to misfire.
- Fuel filler cap was left off or incorrectly screwed on, allowing fuel to evaporate into the atmosphere [for models with EVAP (SMALL LEAK) diagnosis].

TROUBLE DIAGNOSIS — Introduction

Diagnostic Worksheet (Cont'd)

G

RS

BT

ĦA

[DX

WORKSHEET SAMPLE

Customer name MR/MS		Model & Year	VIN			
Engine #		Trans.	Mileage Mi			
Incident Date		Manuf. Date	In Service Date			
Fuel and fuel	filler cap	☐ Vehicle ran out of fuel causing misfire ☐ Fuel filler cap was left off or incorrectly scr	ewed on.			
☐ Startability		☐ Impossible to start ☐ No combustion ☐ Partial combustion affected by throttle ☐ Partial combustion NOT affected by th ☐ Possible but hard to start ☐ Others [position rottle position]			
Sumotomo	[.] Idling	☐ No fast idle ☐ Unstable ☐ High ☐ Others [idle Low idle]			
Symptoms	☐ Driveability	☐ Stumble ☐ Surge ☐ Knock☐ Intake backfire ☐ Exhaust backfire☐ Others [☐ Intake backfire ☐ Exhaust backfire			
	□ Engine stall	☐ At the time of start ☐ While idling ☐ While accelerating ☐ While decelerating ☐ Just after stopping ☐ While loading				
Incident occur	rence	☐ Just after delivery ☐ Recently ☐ In the morning ☐ At night ☐ In the daytime				
Frequency		□ All the time □ Under certain conditions □ Sometimes				
Weather cond	ditions	□ Not affected				
	Weather	☐ Fine ☐ Raining ☐ Snowing	□ Others []			
	Temperature	□ Hot □ Warm □ Cool □ Co	old □ Humid °F			
Engine conditions		☐ Cold ☐ During warm-up ☐ After Engine speed ☐	warm-up 4,000 6,000 8,000 rpm			
Road condition	ns	☐ In town ☐ In suburbs ☐ Highwa	y ☐ Off road (up/down)			
Driving conditions		□ Not affected □ At starting □ While idling □ At r. □ While accelerating □ While cruising □ While decelerating □ While turning (F	. F₩			
Malfunction inc	dicator lamp	☐ Turned on ☐ Not turned on				

EC-69 209

Work Flow CHECK IN CHECK INCIDENT CONDITIONS ----- STEP I Listen to customer complaints. (Get symptoms.) CHECK DTC AND FREEZE FRAME DATA Check and print out (write down) (1st trip) Diagnostic Trouble Code (DTC) and Freeze Frame Data (Pre-check). Then clear. If DTC is not available even if MIL lights up, check ECM fail-safe. (Refer to EC-76.) Also check related service bulletins for information. Symptoms No symptoms, except MIL collected. lights up, or (1st trip) DTC exists at STEP II. Verify the symptom by driving in the condition the customer described. Normal Code Malfunction Code (at STEP II) (at STEP II) INCIDENT CONFIRMATION Verify the (1st trip) DTC by performing the "DTC CONFIRMATION PROCEDURE". STEP V Choose the appropriate action. Malfunction Code (at STEP II or IV) Normal Code (at both STEP II and IV) BASIC INSPECTION SYMPTOM BASIS (at STEP I or III) Perform inspections according to Symptom Matrix Chart. STEP VI TROUBLE DIAGNOSIS FOR DTC PXXXX. REPAIR/REPLACE NG **FINAL CHECK** Confirm that the incident is completely fixed by performing BASIC INSPECTION and DTC CONFIRMATION PROCEDURE (or OVERALL FUNCTION CHECK). Then, erase the unnecessary (already fixed) 1st trip DTCs in ECM and A/T control unit. OK CHECK OUT If completion of SRT is needed, drive the vehicle under the specific pattern. Refer to EC-37.

^{*1:} If the incident cannot be duplicated, see "Incident Simulation Tests" of "HOW TO PERFORM EFFICIENT DIAGNO-SIS FOR AN ELECTRICAL INCIDENT" in GI section.

^{*2:} If the on board diagnostic system cannot be performed, check main power supply and ground circuit (See TROUBLE DIAGNOSIS FOR POWER SUPPLY EC-89).


TROUBLE DIAGNOSIS — Work Flow


Description for Work Flow


STEP	DESCRIPTION
STEP I	Get detailed information about the conditions and the environment when the incident/symptom occurred using the "DIAGNOSTIC WORK SHEET", EC-68.
STEP II	Before confirming the concern, check and write down (print out using CONSULT or Generic Scan Tool) the (1st trip) Diagnostic Trouble Code (DTC) and the (1st trip) freeze frame data, then erase the code and the data. (Refer to EC-43.) The (1st trip) DTC and the (1st trip) freeze frame data can be used when duplicating the incident at STEP III & IV. Study the relationship between the cause, specified by (1st trip) DTC, and the symptom described by the customer. (The "Symptom Matrix Chart" will be useful. See EC-77.) Also check related service bulletins for information.
TEP III	Try to confirm the symptom and under what conditions the incident occurs. The "DIAGNOSTIC WORK SHEET" and the freeze frame data are useful to verify the incident. Connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.) If the malfunction code is detected, skip STEP IV and perform STEP V.
	Try to detect the (1st trip) Diagnostic Trouble Code by driving in (or performing) the "DTC CONFIRMATION PRO- CEDURE". Check and read the (1st trip) DTC and (1st trip) freeze frame data by using CONSULT or Generic Scan Tool.
STEP IV	During the (1st trip) DTC verification, be sure to connect CONSULT to the vehicle in DATA MONITOR (AUTO TRIG) mode and check real time diagnosis results. If the incident cannot be verified, perform INCIDENT SIMULATION TESTS. (Refer to GI section.) In case the "DTC CONFIRMATION PROCEDURE" is not available, perform the "OVERALL FUNCTION CHECK" instead. The (1st trip) DTC cannot be displayed by this check, however, this simplified "check" is an effective alter-
	native. The "NG" result of the "OVERALL FUNCTION CHECK" is the same as the (1st trip) DTC detection.
TEP V	Take the appropriate action based on the results of STEP I through IV. If the malfunction code is indicated, proceed to TROUBLE DIAGNOSIS FOR DTC PXXXX. If the normal code is indicated, proceed to the BASIC INSPECTION on next page. Then perform inspections according to the Symptom Matrix Chart. (Refer to EC-77.)
	Identify where to begin diagnosis based on the relationship study between symptom and possible causes. Inspect the system for mechanical binding, loose connectors or wiring damage using (tracing) "Harness Layouts". Gently shake the related connectors, components or wiring harness with CONSULT set in "DATA MONITOR".
STEP VI	(AUTO TRIG)" mode. Check the voltage of the related ECM terminals or monitor the output data from the related sensors with CON- SULT. Refer to EC-79, 83.
	The "DIAGNOSTIC PROCEDURE" in EC section contains a description based on open circuit inspection. A short circuit inspection is also required for the circuit check in the DIAGNOSTIC PROCEDURE. For details, refer to GI section ("HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT", "Circuit Inspection"). Repair or replace the malfunctioning parts.
	Once you have repaired the circuit or replaced a component, you need to run the engine in the same conditions and circumstances which resulted in the customer's initial complaint. Perform the "DTC CONFIRMATION PROCEDURE" and confirm the normal code [Diagnostic trouble code No.
TEP VII	P0000 or 0505] is detected. If the incident is still detected in the final check, perform STEP VI by using a different method from the previous one.
	Before returning the vehicle to the customer, be sure to erase the unnecessary (already fixed) (1st trip) DTC in


IDX


211











Basic Inspection

Precaution:

Perform Basic Inspection without electrical or mechanical loads applied:

Go to 🖪 .

sensor.

Adjust ignition timing by

turning camshaft position

NG

- Headlamp switch is OFF,
- Air conditioner switch is OFF,
- Rear window defogger switch is OFF,
- Steering wheel is in the straight-ahead position, etc.

Α

BEFORE STARTING

- Check service records for any recent repairs that may indicate a related problem, or the current need for scheduled maintenance.
- Open engine hood and check the following:
- Harness connectors for improper connections
- Vacuum hoses for splits, kinks, or improper connections
- Wiring for improper connections, pinches, or cuts

В

CONNECT CONSULT TO THE VEHICLE.

Connect "CONSULT" to the data link connector for CONSULT and select "ENGINE" from the menu. Refer to EC-53.

DOES ENGINE START?

CHECK IGNITION TIMING.



C

- 1. Warm up engine sufficiently.
- 2. Select "IGN TIMING ADJ" in "WORK SUPPORT" mode.
- 3. Touch "START"
- Check ignition timing at idle using timing light.

Ignition timing:

M/T 10°±2° BTDC A/T 10°±2° BTDC (in "N" position)



- Warm up engine sufficiently.
- Stop engine and disconnect throttle position sensor harness connector.
- Start engine.
- Check ignition timing at idle using timing light.


Ignition timing:

M/T 10°±2° BTDC A/T 10°±2° BTDC (in "N" position)

OK (A)

(Go to next page.)


TROUBLE DIAGNOSIS — Basic Inspection



SEF403T

TROUBLE DIAGNOSIS — Basic Inspection

Basic Inspection (Cont'd)



Diagnostic Trouble Code (DTC) Inspection Priority Chart

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority		Detected items (DTC)	
1	● ECM (P0605, 0301)	 Camshaft position sensor circuit (P0340, 0101) 	 Engine coolant temperature sensor circuit (P0115, 0103) (P0125, 0908)
	 Mass air flow sensor circuit (P0100, 0102) 	 Vehicle speed sensor circuit (P0500, 0104) 	● Ignition signal circuit (P1320, 0201)
	 Throttle position sensor circuit (P0120, 0403) 	 Intake air temperature sensor cir- cuit (P0110, 0401) 	 Park/Neutral position switch circuit (P0705, 1003)
	● EGRC-solenoid valve circuit (P1400, 1005)	 Tank fuel temperature sensor (P0180, 0402) 	
2	• EGR temperature sensor circuit (P1401, 0305)	 Crankshaft position sensor circuit (P0335, 0802), (P1336, 0905) 	 Front heated oxygen sensor circuit (P0130, 0303)
	 Absolute pressure sensor circuit (P0105, 0803) 	 Front heated oxygen sensor heater circuit (P0135, 0901) 	 Rear heated oxygen sensor circuit (P0136, 0707)
	MAP/BARO switch solenoid valve circuit (P1105, 1302)	 EVAP control system pressure sensor circuit (P0450, 0704) 	 EVAP canister purge volume con- trol valve circuit (P1445, 1008)
	 EVAP canister purge control valve/ solenoid valve circuit (P0443, 0807) 	 EVAP canister vent control valve circuit (P0446, 0903) 	 EVAP control system purge flow monitoring (P1447, 0111)
	 Vacuum cut valve bypass valve (P1441, 0801) 	● T/C clutch solenoid valve (P1550, 0904)	 Closed throttle position switch cir- cuit (P0510, 0203)
	Rear heated oxygen sensor heater circuit (P0141, 0902)	 Swirl control valve control vacuum check switch (P1165, 0112) 	
3	● EGR function (P0400, 0302)	• Misfire (P0300 - P0304, 0701 - 0605)	• Fuel injection system function (P0172, 0114), (P0171, 0115)
	• EGRC-BPT valve function (P0402, 0306)	◆ Closed loop control (P0130, 0307)	 Three way catalyst function (P0420, 0702)
	• IACV-AAC valve circuit (P0505, 0205)		EVAP control system (small leak) (P0440, 0705)
	Swirl control valve control solenoid valve (P1130, 1004)		

215



MA

RS

BT

HA

EL

[DX

TROUBLE DIAGNOSIS — General Description

Fail-Safe Chart

The ECM enters fail-safe mode, if any of the following DTCs is recorded due to the open or short circuit. When the ECM enters the fail-safe mode, the MIL illuminates.

DT¢ I	No.					
CONSULT GST	ECM*	Detected items	En	Engine operating condition in fail-safe mode		
P0100	0102	Mass air flow sensor cir- cuit	Engine speed will not rise more than 2,400 rpm due to the fuel cut.		2,400 rpm due to the fuel cut.	
P0110	0401	Intake air temperature sensor circuit	The ECM controls 20°C (68°F).	on the assumption	that the intake air temperature is	
P0115	0103	Engine coolant tempera- ture sensor circuit	after turning ignitio	n switch "ON" or "S	otermined by ECM based on the time START". It temperature decided by ECM.	
			Cor	ndition	Engine coolant temperature decided (CONSULT display)	
			Just as ignition swi	itch is turned ON or	20°C (68°F)	
			More than approx. tion ON or START	6 minutes after igni-	80°C (176°F)	
			Except as shown a	bove	20 - 80°C (68 - 176°F) (Depends on the time)	
P0120	0403	Throttle position sensor circuit	sensor Throttle position will be determined based on the injected fithe engine speed. Therefore, acceleration will be poor.		sed on the injected fuel amount and	
			Con	dition	Driving condition	
			When engine is idli	ng	Normal	
			When accelerating		Poor acceleration	
Unable to access ECCS	Unable to access Diagnostic Test Mode !I	ЕСМ	ECM fail-safe activating condition The computing function of the ECM was judged to be When the fail-safe system activates (i.e., if the ECM condition in the CPU of ECM), the MALFUNCTION II the instrument panel lights to warn the driver. However it is not possible to access ECCS and DTC Engine control with ECM fail-safe When ECM fail-safe is operating, fuel injection, ignitic operation and IACV-AAC valve operation are controll tions.		e.e., if the ECM detects a malfunction ALFUNCTION INDICATOR LAMP on e driver. ECCS and DTC cannot be confirmed. injection, ignition timing, fuel pump	
				E	CM fail-safe operation	
			Engine speed	Engine speed	will not rise more than 3,000 rpm	
			Fuel injection	Simultaneou	us multiport fuel injection system	
			Ignition timing	Ignition tim	ning is fixed at the preset valve	
	i		Fuel pump	Fuel pump relay is "	ON" when engine is running and "OFF" when engine stalls	
	l	ı				

^{*:} In Diagnostic Test Mode II (Self-diagnostic results)

Symptom Matrix Chart

_			_				•		ev	MPT	OM								
			-	Τ	T	T	Т	Ι –	S	T T	OIM	Ţ	1	T				•	MA
			HA)				ATION					RE HIG							1.0(10)
			(EXCP. HA)		T SPOT	N C	CCELEF				 ш	ERATU	APTION	TION	HARGE				EM
			START/RESTART		GING/FLA	ETONATIC	/POOR A	DLE	TING	lz	IN TO IDL	ER TEMP	CONSU	CONSUME	(UNDER CHARGE)			Reference page	LC
			IO START	STALL	HESITATION/SURGING/FLAT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (STOO	OVERCHARGING		EC
			HARD/NO	ENGINE STALL							_					OVERCOOLS			FZ
Wa	rranty Sympt		AA	AB	AC		ΑE	AF	AG	AH	AJ	AK		ΑM	НА	1P	1X		
	Fuel	Fuel pump circuit	•	•	•	0	•		•	0		L	0		0	<u> </u>		EC-309	CL
		Fuel pressure regulator system	•	•	•	0	•	0	•	•	0		•		_	↓		EC-25	⊗ □
		Injector circuit	•	•	•	0	•		•	•			•			<u> </u>		EC-303	
em		Evaporative emission system	0	0	Q	0	•	0	0	0	0	L	0			<u> </u>		EC-20	MT
syst	Air	Positive crankcase ventilation system	0	0	0	0	•	0	0	0	0		0	0		<u> </u>		EC-24	UWE L -
<u>0</u>		Incorrect idle speed adjustment	0	Ö				0	0	0	0		0			ļ.,		EC-28	
'n		Swirl control valve circuit		0	0					•								EC-243	
engine control system		IACV-AAC valve circuit	•	•	•	0	•	•	•	•	•	L	0		0	<u> </u>		EC-221	AT
ğ		IACV-FICD solenoid valve circuit	0		0	0	0	0	0	0			0			<u> </u>		EC-317	-
üe	Ignition	Incorrect ignition timing adjustment	$\overline{\circ}$	0	•	•	•		•	•			•				<u> </u>	EC-28	
Basic		Ignition circuit	•	•	•	•	•		•	•			•			L		EC-256	TF
Ва	EGR	EGRC-solenoid valve circuit		0	•	0	0]	0		Ì			EC-267	_
		EGR system	•	•	•	•	•	•	•	•	0		•					EC-176	
	Main power	supply and ground circuit	•	•	•	0	0		0	0		0	0		0			EC-89	. PD
	Air condition	ner circuit	0	0	0	0	0	0	0	0	0		0		0			HA section	. 🗈
	ECCS	Camshaft position sensor circuit	•	•	•	•	•		0	0			0					EC-171	
		Mass air flow sensor circuit	•	•	•	•	•		•	0			0					EC-93	· FA
		Front heated oxygen sensor circuit		•	•	0	•		•	0			•			Γ		EC-129	tr#N
_		Engine coolant temperature sensor circuit	•	•	•	0	•	•	•	0	0		•				Γ	EC-113, 124	
terr		Throttle position sensor circuit		•	•		•	•	•	•	•		•		<u> </u>			EC-118	
ECCS system		Incorrect throttle position sensor adjust- ment		•	0		0	•	0	0	•		0					EC-72	
ដ្ឋ		Vehicle speed sensor circuit		0	0								0					EC-217	_
		ECM	Ó	0	Õ	0	0	0	Q	0	0	0	0					EC-76, 230	BR
		Start signal circuit	0				\Box											EC-306	_
		Park/Neutral position switch circuit			0		0		0	0			0				Γ	EC-232	,
		Power steering oil pressure switch circuit		0					0	0								EC-313	ST

• ; High Possibility Item

; Low Possibility Item

(continued on next page)

EC-77 217

RS

GI

BT

HA

JDX

Symptom Matrix Chart (Cont'd)

		T	<u> </u>	-				SY	MPT			•					
SYSTEM — Engine mechanical & other		HARD/NO START/RESTART (EXCP. HA)	ENGINE STALL	HESITATION/SURGING/FLAT SPOT	SPARK KNOCK/DETONATION	LACK OF POWER/POOR ACCELERATION	HIGH IDLE/LOW IDLE	ROUGH IDLE/HUNTING	IDLING VIBRATION	SLOW/NO RETURN TO IDLE	OVERHEATS/WATER TEMPERATURE HIGH	EXCESSIVE FUEL CONSUMPTION	EXCESSIVE OIL CONSUMPTION	BATTERY DEAD (UNDER CHARGE)	OVERCOOLS	OVERCHARGING	Reference page
Warranty Sy	rmptom Code	AA	AB	AC	AD	L	AF	AG		AJ	AK	AL	AM		1P	1X	
Fuei	Fuel tank	•	•	İ			†		 	·			i			ļ · · · ·	
	Fuel piping	•	•	0	0	•		0	0			0				Τ	
	Vapor lock	\top	0	Ť	Ť			Ť	Ť			Ť				<u> </u>	
	Valve deposit	0	0	0	0	0		0	0			0					
	Poor fuel (Heavy weight gasoline, Low					i				\vdash					-		
	octane)		0	0	0	0		0	0	İ		0					<u> </u>
Air	Air duct		0	0		0		0	0		ļ	0					
	Air cleaner		0	•		•		•	0			0					
	Air leakage from air duct																
	(Mass air flow sensor — throttle body)	0	0	0	0	0	0	0	0	0		0					
	Throttle body, Throttle wire	0	•	•		0	•	•	0	0		0					FE section
	Air leakage from intake manifold/				0							•					
	Collector/Gasket			0	0	0	0	•	0	0		_					
Cranking	Battery	0	0	0		0		0	0			0		0		0	
	Alternator circuit	0	0	0		0		0	0			0		0		0	EL section
	Starter circuit	•															
	Flywheel/Drive plate	•															
	Clutch interlock switch	•						†									CL section
	Inhibitor switch	1					_									 	AT section
Engine	Cylinder head	•	0	•	0	0		•	0		-	0		<u> </u>		 	
go	Cylinder head gasket	0	ŏ	0	0	Ö		•	ŏ		•	ŏ	0		_	· · · · -	1
	Cylinder block	lŏ	ŏ	Ö	0	$\overline{\bullet}$		0	ŏ			Ö	ŏ			-	-
	Piston	10	0	0	0	0		Ö	•	-		0	•			┿	
	Piston ring	16	Ö	0	0	$\overline{}$		$\overline{\bullet}$		-		ŏ	•			 	
	Connecting rod	 	0	0	0			0	0			0	-		\vdash	+	
	Bearing	+	-		$\overline{\bullet}$				$\frac{\circ}{\bullet}$	ļ					-	-	-
				0		0		Ŏ		 		0	ļ				-
\ f=4	Crankshaft	0	0	<u> </u>	0	<u>_</u>		0	0	├		0		<u> </u>		∔	
Valve mechanism	Timing chain		0	•	0	•		0	0			0				 	
mechanisti	Camshaft	•	$\overline{}$	0	0	0		0	0	ļ	ļ	Ö			├ —	┼	1
	Intake valve	ļ	•	•	0	0		•	0			0	<u> </u>		ļ <u>.</u>	₩	4
	Exhaust valve	•	<u> </u>	•	0	•		•	0			0	•		<u> </u>	ļ	1 -
Exhaust	Exhaust manifold/Tube/Muffler/Gasket	0	•	•	•	•		•	0			•	<u> </u>		<u> </u>	↓	
	Three way catalyst	0	•	0	0	•		0	0			0			<u> </u>	ļ	4
Lubrication	Oil pan/Oil strainer/Oil pump/Oil filter/Oil gallery	•	0	0	•	•		0	0			0	•		ļ	_	
	Oil level (Low)/Filthy oil	0	0	0	0	0		0	0			0	0		<u> </u>	<u> </u>]
Cooling	Radiator/Hose/Radiator filler cap	0	0	0	0	0		0	0		•	0				<u> </u>	1
	Thermostat	0	0	0	0	0	0	•	0	0	•	0			0]
	Water pump	•	0	0	0	0		0	0		•	0]
	Water gallery	0	0	Ō	Ō	0		0	Ō		0	Ō				ļ]
	Cooling fan	Ŏ	Ŏ	Ŏ	Ŏ	•	0	•	Ŏ	0	•	Ŏ			0		1
-																	

^{• ;} High Possibility Item

; Low Possibility Item

CONSULT Reference Value in Data Monitor Mode

Remarks:

- Specification data are reference values.
- Specification data are output/input values which are detected or supplied by the ECM at the connector.
 - * Specification data may not be directly related to their components signals/values/operations.
 - i.e. Adjust ignition timing with a timing light before monitoring IGN TIMING, because the monitor may show the specification data in spite of the ignition timing not being adjusted to the specification data. This IGN TIMING monitors the data calculated by the ECM according to the signals input from the camshaft position sensor and other ignition timing related sensors.
- If the real-time diagnosis results are NG and the on board diagnostic system results are OK when diagnosing the mass air flow sensor, first check to see if the fuel pump control circuit is normal.

MONITOR ITEM	COI	NDITION	SPECIFICATION	_
CMPS-RPM (POS)	Tachometer: Connect		Almost the same speed as the CON-	
CMPS·RPM (REF)	Run engine and compare tachomete	r indication with the CONSULT value.	SULT value.	
MAS AIR/FL SE	Engine: After warming up Air conditioner switch OFF	idle	1.3 - 1.7V	
	Shift lever "N"No-load	2,500 rpm	1.7 - 2.1V	
COOLAN TEMP/S	Engine: After warming up		More than 70°C (158°F)	_
FR O2 SENSOR			0 - 0.3V ↔ Approx. 0.6 - 1.0V	
FR O2 MNTR	Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.	
RR O2 SENSOR		Majarajaja anajarana ana ana ana ana ana	0 - 0.3V ↔ Approx. 0.6 - 1.0V	
RR O2 MNTR	■ Engine: After warming up	Maintaining engine speed at 2,000 rpm	$LEAN \leftrightarrow RICH$	
VHCL SPEED SE	Turn drive wheels and compare spee value	Almost the same speed as the CONSULT value		
BATTERY VOLT	Ignition switch: ON (Engine stopped)	11 - 14V		
TUDTI DOC OEN	Ignition switch: ON	ition switch: ON Throttle valve fully closed		
THRTL POS SEN	(Engine stopped)	Throttle valve fully opened	Approx. 4.0V	
EGR TEMP SEN	Engine: After warming up	Less than 4.5V		
START SIGNAL	Ignition switch: $ON \to START \to ON$		$OFF \to ON \to OFF$	
CLSD THL/P SW	Ignition switch: ON	Throttle valve: Idle position	ON	
CLSD THE/F SW	(Engine stopped)	Throttle valve: Slightly open	OFF	
	Engine: After warming up, idle the	Air conditioner switch OFF	OFF	
AIR COND SIG	engine	Air conditioner switch ON (Compressor operates.)	ON	
P/N POSI SW	● lanition switch: ON	Shift lever "P" or "N"	ON	_
F/N FUSI 5W	- ignition switch. ON	Except above	OFF	_
PW/ST SIGNAL	Engine: After warming up, idle the	Steering wheel in neutral position (forward direction)	OFF	_
	engine	The steering wheel is turned	ON	
IGNITION SW	• Ignition switch ON \rightarrow OFF \rightarrow ON		$ON \rightarrow OFF \rightarrow ON$	
EMI CON VO OW	• Engine is running at a speed of less	than 3,600 rpm.	OFF	
SWL CON VC SW	Except above		ON	
INJ PULSE	Engine: After warming up Air conditioner switch OFF	Idle	2.4 - 3.2 msec.	
, QLOL	Shift lever "N"No-load	2,000 rpm	1.9 - 3.2 msec.	

EC-79 219

61

MA

10

37

311

IDX

CONSULT Reference Value in Data Monitor Mode (Cont'd)

MONITOR ITEM	COI	NDITION	SPECIFICATION
DELICI COLIDI		Idle	1.0 - 1.6 msec
B/FUEL SCHDL		2,000 rpm	0.7 - 1.3 msec
	1	ſdłe	10° BTDC
IGN TIMING	 Engine: After warming up Air conditioner switch: OFF 	2,000 rpm	More than 25° BTDC
	Shift lever "N"	Idle	20 - 40%
IACV-AAC/V	No-load	2,000 rpm	_
-		Vehicle stopped	0 step
PURG VOL C/V		Vehicle running	_
A/F ALPHA	Engine: After warming up	Maintaining engine speed at 2,000 rpm	52 - 159%
EVAP SYS PRES	Ignition switch: ON		Approx. 3.4V
AIR COND RLY	Air conditioner switch: OFF → ON	OFF → ON	
FUEL PUMP RLY	 Ignition switch is turned to ON (Oper Engine running and cranking When engine is stopped (Stops in 1. 	ON	
Except as shown above			OFF
01/01/00/07/07	Engine is running at a speed of less	than 3,600 rpm.	ON
SWRL CONT S/V	Except above		OFF
EGRC SOL/V	Engine: After warming up Air conditioner switch: OFF	Idle	ON
Lanc 30DV	Shift lever: "N" No-load	Revving up to 1,500 - 2,000 rpm	OFF
VENT CONT/V	Ignition switch: ON		OFF
	Engine speed: Idle Engine coolant temperature below 40	°C (104°F)	ON
TCC SOL/V	 Engine: After warming up Engine coolant temperature above 40°C (104°F) 	2,000 rpm	OFF
	Engine speed: Idle		ON
FR O2 HEATER	Engine speed: Above 3,000 rpm		OFF
VC/V BYPASS/V	Ignition switch: ON		OFF
OUDO CONT CAL	A firm and a firm and a firm a	Idle	OFF
PURG CONT S/V	Engine: After warming up	2,000 rpm	ON
00.00.1/54750	Engine speed: Below 6,000 rpm		ON
RR O2 HEATER	Ignition switch: ON (Engine stopped)		OFF
	Engine: After warming up Air conditioner switch: OFF	Idle	16.8 - 34.7% (2WD models) 15.9 - 33.2% (4WD models)
CAL/LD VALUE	● Shift lever "N" ● No-load	2,500 rpm	14.1 - 27.6 % (2WD models) 13.3 - 26.1 % (4WD models)
ABSOL TH·P/S	● Ignition switch: ON	Throttle valve fully closed	0.0%
	(Engine stopped)	Throttle valve fully opened	Approx. 84%
ASS AIRFLOW	Engine: After warming upAir conditioner switch: OFF	Idle	1.8 - 6.5 g·m/s (2WD models) 2.1 - 6.0 g·m/s (4WD models)
MINGO AIRELUW	Shift lever "N"No-load	2,500 rpm	7.7- 15.0 g·m/s (2WD models) 6.8 - 13.3 g·m/s (4WD models)
AAD/DADO SWA	Ignition switch: ON		BARO
MAP/BARO SW/V	Engine speed: Idle (More than 5 seconds)	onds after starting engine)	MAP
		Engine is not running	Approx. 4.4V
ABSOL PRES/SE	Engine: After warming up	Idle (More than 5 seconds after starting engine)	Approx. 1.2V

Major Sensor Reference Graph in Data Monitor Mode

G[

MA

EM.

EC

FE

CL

MIT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL


1DX

The following are the major sensor reference graphs in "DATA MONITOR" mode. (Select "HI SPEED" in "DATA MONITOR" with CONSULT.)

THRTL POS SEN, ABSOL TH-P/S, CLSD THL/P SW


Below is the data for "THRTL POS SEN", "ABSOL TH·P/S" and "CLSD THL/P SW" when depressing the accelerator pedal with the ignition switch "ON".

The signal of "THRTL POS SEN" and "ABSOL TH·P/S" should rise gradually without any intermittent drop or rise after "CLSD THL/P SW" is changed from "ON" to "OFF".




CMPS·RPM (REF), MAS AIR/FL SE, THRTL POS SEN, RR O2 SENSOR, FR O2 SENSOR, INJ PULSE


Below is the data for "CMPS·RPM (REF)", "MAS AIR/FL SE", "THRTL POS SEN", "RR O2 SENSOR", "FR O2 SENSOR" and "INJ PULSE" when revving quickly up to 4,800 rpm under no load after warming up engine sufficiently.



EC-81 221

Major Sensor Reference Graph in Data Monitor Mode (Cont'd)





ECM Terminals and Reference Value PREPARATION

1. ECM is located behind the front passenger seat side dash. For this inspection, remove the front passenger side dash.

MA

GI

LC

EM

Remove ECM harness protector.

EC

FE

C[

MT

Perform all voltage measurements with the connectors con-

TF

PD)

FA

RA

BR


ST

RS

BT.

HA


SEF064P



ECM harness protector

nected. Extend tester probe as shown to perform tests easily.

ECM HARNESS CONNECTOR TERMINAL LAYOUT



ECM Terminals and Reference Value (Cont'd)

ECM INSPECTION TABLE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
1	w	Ignition signal	Engine is running. Idle speed	0.3 - 0.6V*
1	ignition signal		Engine is running. Engine speed is 2,000 rpm	Approximately 0.8V*
2	W/G	Ignition check	Engine is running. Idle speed	Approximately 12V*
3	w	Tachometer	Engine is running. Idle speed	Approximately 0.9V*
4	L/R	ECCS relay (Self-shutoff)	Engine is running. Ignition switch "OFF" Less than 7 seconds after turning ignition switch "OFF". Ignition switch "OFF" 7 seconds passed after turning ignition switch "OFF"	0 - 1V BATTERY VOLTAGE (11 - 14V)
5	R L/G	EVAP canister purge vol- ume control valve	Engine is running. Idle speed	0 - 0.4V or BATTERY VOLTAGE (11 - 14V)
8	W/R	Fuel pump relay	Ignition switch "ON" For 5 seconds after turning ignition switch "ON" Engine is running.	Approximately 1V
·			Ignition switch "ON" 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
10	B/P	ECCS ground	Engine is running. Idle speed	Engine ground
15	G/R	Air conditioner relay	Engine is running. Both air conditioner switch and blower switch are "ON".	Approximately 1V
			Engine is running. Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
16	G Y	EVAP canister purge vol- ume control valve	Engine is running. Idle speed	0 - 0.4V or BATTERY VOLTAGE
17	1		Ignition switch "ON"	(11 - 14V) 0 - 1V
18	R/W	Malfunction indicator lamp	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ECM Terminals and Reference Value (Cont'd) a TER-**WIRE** DATA MINAL ITEM CONDITION COLOR (DC voltage) NO. MA Engine is running. B/P 19 ECCS ground Engine ground Idle speed 国图 Ignition switch "ON" Approximately 0V 20 OR Start signal LC. BATTERY VOLTAGE Ignition switch "START" (11 - 14V)Engine is running. EC Approximately 0V Both air conditioner switch and blower switch are "ON". (Compressor operates) 21 G/R Air conditioner switch Engine is running. **BATTERY VOLTAGE** (11 - 14V)Air conditioner switch is "OFF". CL Ignition switch "ON" Gear position is "Neutral position" (M/T mod-Neutral position switch Approximately 0V MIT (M/T models) 22 L/B Gear position is "N" or "P" (A/T models) Inhibitor switch (A/T mod-Ignition switch "ON" Æï Approximately 5V Except the above gear position Ignition switch "ON" TF 0.3 - 0.7VAccelerator pedal released 23 W Throttle position sensor Ignition switch "ON" PD) Approximately 4V Accelerator pedal fully depressed Engine is running. ÉÂ 0V Steering wheel is being turned. Power steering oil pres-25 G sure switch Engine is running. RA Approximately 5V Steering wheel is not being turned. Engine is running. BR Approximately 1.8 - 2.4V* 26 W/L Vehicle speed sensor (AC voltage) Slowly rotating front wheels Ignition switch "ON" (Warm-up condition) **BATTERY VOLTAGE** (11 - 14V)Accelerator pedal released Throttle position switch 27 Υ (Closed position) RS Ignition switch "ON" Approximately 0V Accelerator pedal depressed BT Approximately 0 - 4.8V Intake air temperature Y/L 28 Engine is running. Output voltage varies with sensor intake air temperature. HA Engine is running. 0٧ Engine speed is above 3,600 rpm. Swirl control valve control 32 R/Y 周5 vacuum check switch Engine is running. Approximately 4.8V Engine speed is less than 3,600 rpm. [DX

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ECM Terminals and Reference Value (Cont'd)

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
			Ignition switch "OFF"	ov
38	B/W	Ignition switch	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
39	В	ECCS ground	Engine is running. Idle speed	Engine ground
40 44	GY R	Camshaft position sensor (Reference signal)	Engine is running.	Approximately 0.3V*
41	G	Camshaft position sensor (Position signal)	Engine is running.	Approximately 2.5V*
42	w	Front heated oxygen sen-	Engine is running. Engine speed is below 3,000 rpm.	Approximately 0V
		sor heater	Engine is running. Engine speed is above 3,000 rpm.	BATTERY VOLTAGE (11 - 14V)
43	В	ECCS ground	Engine is running. Lidle speed	Engine ground (Probe this terminal with ⊝ tester probe when measuring.)
46	W	Front heated oxygen sensor	Engine is running. After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V (periodically changes)
47	В	Mass air flow sensor	Engine is running. (Warm-up condition) Idle speed	1.3 - 1.7V
47	Б	wass all now sensor	Engine is running. (Warm-up condition) Engine speed is 2,500 rpm.	1.7 - 2.1V
48	w	Mass air flow sensor ground	Engine is running. (Warm-up condition) Idle speed	0.005 - 0.02V
49	Р	Sensors' power supply	Ignition switch "ON"	Approximately 5V
50	B/G	Sensors' ground	Engine is running. (Warm-up condition) Idle speed	0.001 - 0.02V
51	LG/R	Engine coolant tempera- ture sensor	Engine is running.	Approximately 0 - 4.8V Output voltage varies with engine coolant tempera- ture.
52	w	Rear heated oxygen sensor	Engine is running. After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V
53	R	Crankshaft position sensor (OBD)	Engine is running. (A/T: N range, M/T: Neutral) Idle speed (Air conditioner switch "OFF".)	More than 0.2V* (AC range)
56 61	G/R G/R	Power supply for ECM	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ECM Terminals and Reference Value (Cont'd)

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
			[Ignition switch "ON"] Engine is not running	Approximately 4.4V
57	*	Absolute pressure sensor	Engine is running. Idle speed (More than 5 seconds after starting engine)	Approximately 1.2V
58	R	Data link connector for GST	Engine is running. Idle speed (GST is disconnected.)	Approximately 9V
	0/05	FOR	Engine is running. (Warm-up condition) Idle speed	Less than 4.5V
62	G/OR	EGR temperature sensor	Engine is running. (Warm-up condition) EGR system is operating.	0 - 3.0V
63	L	Tank fuel temperature sensor	Engine is running.	Approximately 0 - 4.8V Output voltage varies with fuel temperature.
64	Υ		Engine is running.	Approximately 0.1V
65	R	Data link connector for CONSULT	Idle speed (Connect CONSULT and select	Approximately 4 - 9V
68	G	00110021	DATA MONITOR mode.)	Approximately 3.5V*
67	L	EVAP control system pressure sensor	[Ignition switch "ON"]	Approximately 3.4V
70	R/G	Power supply (Back-up)	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
101	W/G	IACV AAC valva	Ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)
101	i w/G	IACV-AAC valve	Engine is running. (Warm-up condition) Engine speed is 2,000 rpm	0 - 7V
102	W/B	Injector No. 1		
104	W/R	Injector No. 3	Engine is rupping	BATTERY VOLTAGE
107	W/L	Injector No. 2	Engine is running.	(11 - 14V)
109	W/G	Injector No. 4		
102	VAT/I	ECPC coloneid value	Engine is running. (Warm-up condition) Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
103	W/L	EGRC-solenoid valve	Engine is running. (Warm-up condition) Idle speed	0 - 1V
105	W/R	EVAP canister purge control solenoid valve	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)
106	B/P	ECCS ground	Engine is running. Idle speed	Engine ground

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ECM Terminals and Reference Value (Cont'd)

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
108	R	EVAP canister vent control valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
110	В	ECCS case ground	Engine is running. Idle speed	Approximately 0V
111	GY	Swirl control valve control	Engine is running. Idle speed	0 - 1V
111	GY	solenoid valve	Engine is running. Engine speed is above 3,600 rpm.	BATTERY VOLTAGE (11 - 14V)
112	B/P	ECCS ground	Engine is running. Idle speed	Engine ground
113	G/R	Current return	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)
		Torque converter clutch solenoid valve	Engine is running. Idle speed Engine coolant temperature is below 40°C (104°F)	Approximately 0V
114	L/Y		Engine is running. After warming up Engine coolant temperature is above 40°C (104°F) Engine speed is 2,000 rpm	BATTERY VOLTAGE (11 - 14V)
115	п	Rear heated oxygen sen-	Engine is running. Engine speed is below 6,000 rpm.	Approximately 0V
115	R	sor heater	Ignition switch "ON" Engine is stopped.	BATTERY VOLTAGE (11 - 14V)
			Ignition switch "ON"	0 - 1V
116	W/R	MAP/BARO switch sole- noid valve	Engine is running. Idle speed (More than 5 seconds after starting engine)	BATTERY VOLTAGE (11 - 14V)
117	Υ	Vacuum cut valve bypass valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)
118	B/P	ECCS ground	Engine is running. Idle speed	Engine ground

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

Gl Main Power Supply and Ground Circuit EC-MAIN-01 MiA BATTERY : Detectable line for DTC EM : Non-detectable line for DTC Refer to "EL-POWER". L© (M146)**FUSIBLE** FUSIBLE LINK LINK (M143) BR (M47) (M48), (E22) (E21) EC 10A 2 20 W/B 湄 CL 2 3 IGNITION SWITCH ECCS RELAY MT (M32) (M130) ON **3** AT' ΒĀW TF JOINT CONNECTOR-1 PD (M110) 20 $\mathbb{F}\mathbb{A}$ B/P B/P R/G G/R G/R G/R B/W В₿ B/P B/P≬ B/P 4 38 10 118 106 56 61 39 112 19 RA ECM (ECCS CONTROL MODULE) IGSW GND-C GND-C GND-I GND-E GND-E GND-E SSOFE CRTN GND-CASE (M112) BR ST (M111 RS Refer to last page (Foldout page). M110 1 M146 W (M48) BT **(M**112) MA 104 105 106 6 7 8 9 44 45 46 57 58 59 60 10 42 61 109 110 111 112 107 108 47 48 62 63 64 65 49 116 117 66 67 68 69 [DX

AEC038A

TROUBLE DIAGNOSIS FOR POWER SUPPLY


Main Power Supply and Ground Circuit (Cont'd)

ECM TERMINALS AND REFERENCE VALUE


Specification data are reference values and are measured between each terminal and 43 (ECCS ground).


TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
4	L/R	ECCS relay (Self-shutoff)	Engine is running. Ignition switch "OFF" Less than 7 seconds after turning ignition switch "OFF". Ignition switch "OFF"	0 - 1V BATTERY VOLTAGE
			7 seconds passed after turning ignition switch "OFF"	(11 - 14V)
10	B/P	ECCS ground	Idle speed	Engine ground
19	В/Р	ECCS ground	Engine is running. Idle speed	Engine ground
			Ignition switch "OFF"	ov
38	B/W	Ignition switch	[gnition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
39	В	ECCS ground	Engine is running. Idle speed	Engine ground
43	В	ECCS ground	Engine is running. Idle speed	Engine ground (Probe this terminal with tester probe when measuring.)
56 61	G/R G/R	Power supply for ECM	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)
70	R/G	Power supply (Back-up)	Ignition switch "OFF"	BATTERY VOLTAGE (11 - 14V)
106	В/Р	ECCS ground	Engine is running. Idle speed	Engine ground
110	В	ECCS case ground	Engine is running. Idle speed	Approximately 0V
112	В/Р	ECCS ground	Engine is running. — Idle speed	Engine ground
113	G/R	Current return	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)
118	B/P	ECCS ground	Engine is running. Idle speed	Engine ground

TROUBLE DIAGNOSIS FOR POWER SUPPLY



TROUBLE DIAGNOSIS FOR POWER SUPPLY





Mass Air Flow Sensor (MAFS)

COMPONENT DESCRIPTION

The mass air flow sensor is placed in the stream of intake air. It measures the intake flow rate by measuring a part of the entire intake flow. It consists of a hot wire that is supplied with electric current from the ECM. The temperature of the hot wire is controlled by the ECM a certain amount. The heat generated by the hot wire is reduced as the intake air flows around it. The more air, the greater the heat loss.

Therefore, the ECM must supply more electric current to the hot wire as air flow increases. This maintains the temperature of the hot wire. The ECM detects the air flow by means of this current change.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (a) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
4-7		Mana six flavo annon	Engine is running. (Warm-up condition) Idle speed	1.3 - 1.7V
47	В	Mass air flow sensor	Engine is running. (Warm-up condition) Engine speed is 2,500 rpm.	1.7 - 2.1V
48	w	Mass air flow sensor ground	Engine is running. (Warm-up condition) Idle speed	0.005 - 0.02V

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	co	ONDITION	SPECIFICATION	
MAS AIR/FL SE	Engine: After warming upAir conditioner switch OFF	Idle	1.3 - 1.7V	
MIAS AITH E SE	Shift lever "N"No-load	2,500 rpm	1.7 - 2.1V	
CAL/LD VALUE	Engine: After warming up Air conditioner switch: OFF	Idle	16.8 - 34.7% (2WD models) 15.9 - 33.2% (4WD models)	
CAL/LD VALUE	Shift lever "N"No-load	2,500 rpm	14.1 - 27.6 % (2WD models) 13.3 - 26.1 % (4WD models)	
MACC AIDELOW	Engine: After warming up Air conditioner switch: OFF	Idle	1.8 - 6.5 g·m/s (2WD models) 2.1 - 6.0 g·m/s (4WD models)	_
MASS AIRFLOW	Shift lever "N"No-load	2,500 rpm	7.7- 15.0 g·m/s (2WD models) 6.8 - 13.3 g·m/s (4WD models)	

EC-93 233

(G)

EM

EC

FE

(CL

Mï

ÆT

TF

PD)

HA

1DX


Mass Air Flow Sensor (MAFS) (Cont'd)


ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
P0100 0102	A) An excessively high or low voltage from the sensor is sent to ECM.* B)C) Rationally incorrect voltage is sent to ECM, compared with the calculated value by camshaft position sensor signal and throttle position sensor signal.	 Harness or connectors (The sensor circuit is open or shorted.) Mass air flow sensor

^{*:} When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up. (Refer to EC-76.)

	-
Engine operating condition in fail-safe mode	
Engine speed will not rise more than 2,400 rpm due to the fuel cut.	_





Mass Air Flow Sensor (MAFS) (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B". If there is no problem on "Procedure for malfunction B", perform "Procedure for malfunction C", "OVERALL FUNCTION CHECK".

Procedure for malfunction A



- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and wait at least 3 seconds.


GST

TOOLS

- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- Start engine and wait at least 3 seconds.
- 3) Select "MODE 7" with GST.

– OR –

- 1) Turn ignition switch "ON" and wait at least 6 seconds.
- 2) Start engine and wait at least 3 seconds.
- Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.





- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up sufficiently.
 4) Run engine for at least 10 seconds at idle spee
- 4) Run engine for at least 10 seconds at idle speed.

 OR

- 1) Turn ignition switch "ON".
- Start engine and warm it up sufficiently.
- 3) Run engine for at least 10 seconds at idle speed.
- 4) Select "MODE 7" with GST.

.___

G[

MA

LC

EC

FE

CL.

MT

AT

TF

PD

FA

RA

19(8)

ST

RS


BT


HA



- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- Run engine for at least 10 seconds at idle speed.
- 4) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Mass air flow Engine speed sensor voltage 48 32 16 X100rpm 38 26 X0.1V 13 0 CMPS+RPM(REF MAS AIR/FL SE 충 48 32 16 X100rpm 38 26 X0.1V 13 0 CMPS•RPM(REF) MAS AIR/FL SEF945S





Mass Air Flow Sensor (MAFS) (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of mass air flow sensor. During this check a 1st trip DTC might not be confirmed.

Procedure for malfunction C




- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Select "DATA MONITOR" mode with CONSULT.
- Check the voltage of mass air flow sensor with "DATA MONITOR".
- Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.



NO TOOLS

- 1) Turn ignition switch "ON".
- 2) Start engine and warm it up sufficiently.
- 3) Select "MODE 1" with GST.
- 4) Check the mass air flow with "MODE 1".
- 5) Check for linear mass air flow rise in response to increases to about 4,000 rpm in engine speed.

OR -



- 2) Start engine and warm it up sufficiently.
 3) Check the voltage between FCM term
- 3) Check the voltage between ECM terminal 47 and ground.
- 4) Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

TROUBLE DIAGNOSIS FOR DTC P0100 Mass Air Flow Sensor (MAFS) (Cont'd) G[EC-MAFS-01 MA BATTERY : Detectable line for DTC : Non-detectable line for DTC Refer to **FUSIBLE** "EL-POWER". BR LINK M48, E22 10 EC FE CL RELAY MASS AIR FLOW SENSOR (M32) (M20) MT AT YF 13 JOINT CONNECTOR-1 PD (M110) FA G/R RA G/R G/R ĽR 4 113 61 56 48 47 ECM (ECCS CONTROL MODULE) BR (M112) ST Refer to last page (Foldout page). RS (M110) 1234 (M48) BT G (M112) HA 44 45 46 57 58 59 60 47 48 62 63 64 65 5 6 7 8 9 10 24 25 26 27 28 42 43 61 112 107 108 109 110 111


AEC039A


49 50


70

EL

10%







Mass Air Flow Sensor (MAFS) (Cont'd) COMPONENT INSPECTION

Mass air flow sensor

Turn ignition switch "ON".

2. Start engine and warm it up sufficiently.

3. Check voltage between terminal 1 and ground.

Conditions	Voltage V
Ignition switch "ON" (Engine stopped.)	Less than 1.0
Idle (Engine is warmed-up sufficiently.)	1.3 - 1.7
2,500 rpm	1.7 - 2.3
Idle to about 4,000 rpm*	1.3 - 1.7 to Approx. 4.0

*: Check for linear voltage rise in response to increases to about 4,000 rpm in engine speed.

 If NG, remove mass air flow sensor from air duct. Check hot wire for damage or dust.



_...

MiA

国M·

į.C

EC

...

©L.

MT

AT

TE

PD

FA

RA

82


ST

RS

ST

HA

IDX



SEF428Q 5 4.5 2 4 93.5 5 4.5 2 1 0 0.5 0 13.3 106.6

Pressure kPa (mmHg, inHg) (Absolute pressure)

(100, 3.94)

Absolute Pressure Sensor COMPONENT DESCRIPTION

The absolute pressure sensor is connected to the MAP/BARO switch solenoid valve by a hose. The sensor detects ambient barometric pressure and intake manifold pressure and sends the voltage signal to the ECM. As the pressure increases, the voltage rises. The absolute pressure sensor is not used to control the engine system. It is used only for on board diagnosis.

ECM TERMINALS AND REFERENCE VALUE

(800, 31.50)

SEF946S

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
49	Р	Sensors' power supply	Ignition switch "ON"	Approximately 5V
50	B/G	Sensors' ground	Engine is running. (Warm-up condition)	0.001 - 0.02V
			Ignition switch "ON" Engine is not running	Approximately 4.4V
57	L	Absolute pressure sensor	Engine is running. Idle speed (More than 5 seconds after starting engine)	Approximately 1.2V

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
		Engine is not running	Approx. 4.4V
ABSOL PRES/SE	Engine: After warming up	Idle (More than 5 seconds after starting engine)	Approx. 1.2V

Absolute Pressure Sensor (Cont'd)

G

CL

MT

ÆΤ

PD)

FA

RA

BR

87


MA

킲

EDX

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	Ma
P0105 0803	A) An excessively low or high voltage from the sensor is sent to ECM.	 Harness or connectors (Absolute pressure sensor circuit is open or shorted.) Absolute pressure sensor 	EM
	B) A low voltage from the sensor is sent to ECM under heavy load driving conditions.	Absolute pressure sensor	LC
	A high voltage from the sensor is sent to ECM under light load driving conditions.	Hoses (Hoses between the intake manifold and absolute pressure sensor are disconnected or clogged.)	EC
		Intake air leaks Absolute pressure sensor	



DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE**


Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B", "OVERALL FUNCTION CHECK". If there is no problem on "Procedure for malfunction B", perform "Procedure for malfunction C".

Procedure for malfunction A



TOOLS


- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT.
- Wait at least 6 seconds.



Turn ignition switch "ON" and wait at least 6 seconds.








- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B", "OVERALL FUNCTION CHECK" on next page.



Absolute Pressure Sensor (Cont'd)

Procedure for malfunction C



- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- Start engine and let it idle.
- Wait at least 20 seconds.



- Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Start engine.
- 4) Let engine idle and wait at least 20 seconds.

- OR -


- OR


5) Select "MODE 7" with GST.






- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Start engine. 3)
- Let engine idle and wait at least 20 seconds.
- Turn ignition switch "OFF".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.







OVERALL FUNCTION CHECK

Use this procedure to check the overall function of absolute pressure sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Procedure for malfunction B



- 1) Turn ignition switch "ON".
- 2) Select "ABSOL PRES/SE" in "DATA MONITOR" mode with CONSULT.
- Make sure that the voltage of "ABSOL PRES/SE" is more than 1.74 [V].



- Turn ignition switch "ON". 1)
- Select "MAP" in "MODE 1" with GST.
- Make sure that the pressure of "MAP" is more than 46 kPa (0.47 kg/cm², 6.7 psi). - OR -

NO TOOLS

- Turn ignition switch "ON".
- Make sure that the voltage between ECM terminal (57) and ground is more than 1.74 [V].

If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction C" above.

Absolute Pressure Sensor (Cont'd)

EC-AP/SEN-01

(H

MA

EM

EC

GL.

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

38

ST


RS


87

HA


EL


[DX







AEC040A






EC-105 245







Absolute Pressure Sensor (Cont'd) COMPONENT INSPECTION

Absolute pressure sensor

- 1. Start engine and warm it up sufficiently.
- 2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
- 3. Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
- 4. If NG, check MAP/BARO switch solenoid valve.
 - (1) Turn ignition switch "OFF".
 - (2) Remove MAP/BARO switch solenoid valve.
 - (3) Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

(4) If NG, replace MAP/BARO switch solenoid valve; if OK, go to step 5.

- 5. Remove absolute pressure sensor with its harness connector connected.
- 6. Remove hose from absolute pressure sensor.
- 7. Turn ignition switch "ON" and check output voltage between terminal ② and engine ground.

The voltage should be 3.2 to 4.8 V.


8. Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg, -3.87 psi) to absolute pressure sensor as shown in figure and check the output voltage.


The voltage should be 1.0 to 1.4 V lower than the value measured in step 3.

CAUTION:

Always calibrate the vacuum pump gauge when using it.

If NG, replace absolute pressure sensor.





Intake Air Temperature Sensor

COMPONENT DESCRIPTION

The intake air temperature sensor is mounted to the air duct. The sensor detects intake air temperature and transmits a signal to the ECM.

The temperature sensing unit uses a thermistor, which is sensitive to the change in temperature. Electrical resistance of the thermistor decreases in response to the temperature rise.

This sensor is not used to control the engine system. It is used only LC for the on board diagnosis.

(Reference data)

,	Intake air temperature °C (°F)	Voltage* (V)	Resistance kΩ
	20 (68)	3.5	2.1 - 2.9
	80 (176)	1.23	0.27 - 0.38

*: These data are reference values and are measured between ECM terminal 28 (Intake air temperature sensor) and ECM terminal (43) (ECCS ground).

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0110 0401	A) An excessively low or high voltage from the sensor is sent to ECM.*	 Harness or connectors (The sensor circuit is open or shorted.) Intake air temperature sensor
	B) Rationally incorrect voltage from the sensor is sent to ECM, compared with the voltage signal from engine coolant temperature sensor.	

^{*:} When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up. (Refer to EC-76.)

Engine operating condition in fail-safe mode	
M controls on the assumption that the intake air temperature is 20°C	

The ECN (68°F).

EÇ

GI

C[_

MT

AT

T.F

PD)

FA

RA

ST


BR

R\$

BT

HA

[D]X



Intake Air Temperature Sensor (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.

- OR

– OR ·

3) Wait at least 5 seconds.





- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select MODE 7 with GST.

) Turn ignition switch



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.





Procedure for malfunction B




- 1) Lift up vehicle and open engine hood.
- 2) Wait until engine coolant temperature is less than 90°C (194°F).
 - (a) Turn ignition switch "ON".
 - (b) Select "DATA MONITOR" mode with CONSULT.
 - (c) Check the engine coolant temperature.
 - (d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 3) Turn ignition switch "ON".
- 4) Select "DATA MONITOR" mode with CONSULT.
- 5) Start engine.
- 6) Shift selector lever to "D" position.
- 7) Hold vehicle speed at 70 to 80 km/h (43 to 50 MPH) for 2 minutes.

(SF)

- 1) Lift up vehicle and open engine hood.
- Wait until engine coolant temperature is less than 90°C (194°F).
 - (a) Turn ignition switch "ON".
 - (b) Select MODE 1 with GST.
 - (c) Check the engine coolant temperature.
 - (d) If the engine coolant temperature is not less than 90°C (194°F), turn ignition switch "OFF" and cool down engine.
- Perform the following steps before engine coolant temperature is above 90°C (194°F).
- 3) Start engine.
- 4) Shift selector lever to "D" position.
- 5) Hold vehicle speed at 70 to 80 km/h (43 to 50 MPH) for 2 minutes.
- 6) Select MODE 7 with GST.

\sim	_	
 11	_	

Intake Air Temperature Sensor (Cont'd)



1) Lift up vehicle and open engine hood.

2) Wait until engine coolant temperature is less than 90°C (194°F).

(a) Turn ignition switch "ON".

(b) Check voltage between ECM terminal (f) and ground.

Voltage: More than 1.0 (V)

(c) If the voltage is not more than 1.0 (V), turn ignition switch "OFF" and cool down engine.

 Perform the following steps before the voltage is below 1.0V.

3) Start engine.

4) Shift selector lever to "D" position.

5) Hold vehicle speed at 70 to 80 km/h (43 to 50 MPH) for 2 minutes.

6) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".

7) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

g

MA

EM

LC

EC

FE

C[

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA


EL,


IDX


Intake Air Temperature Sensor (Cont'd)

EC-IATS-01










EC-111


1DX



Intake Air Temperature Sensor (Cont'd) COMPONENT INSPECTION

Intake air temperature sensor


Check resistance as shown in the figure.



(Reference data)

Intake air temperature °C (°F)	Resistance k Ω
20 (68)	2.1 - 2.9
80 (176)	0.27 - 0.38

If NG, replace intake air temperature sensor.



Gasket — SEF594K 20 - 10 - 86 - 86 - 97 - Acceptable 20 - Acceptable 20 - Acceptable 20 - Acceptable 30 - Acceptable 30 - Acceptable 30 - Acceptable

Engine Coolant Temperature Sensor (ECTS) COMPONENT DESCRIPTION

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.

(Reference data)

Engine coolant tempera- ture °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260

^{*:} These data are reference values and measured between ECM terminal (51) (Engine coolant temperature sensor) and ECM terminal (42) (ECCS ground).

ON BOARD DIAGNOSIS LOGIC

) 20 40 60 80 100 (2) (68) (104) (140) (176) (212) Temperature °C (°F)

0.2

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0115 0103	 An excessively high or low voltage from the sensor is sent to ECM.* 	Harness or connectors (The sensor circuit is open or shorted.) Engine coolant temperature sensor

^{*:} When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up. (Refer to EC-76.)

SEF012P

Engine coolant temperature will be determined by ECM based on the time after turning ignition switch "ON" or "START".

CONSULT displays the engine coolant temperature decided by ECM.

Condition	Engine coolant temperature decided (CONSULT display)
Just as ignition switch is turned ON or START	20°C (68°F)
More than approx. 6 minutes after ignition ON or START	80°C (176°F)
Except as shown above	20 - 80°C (68 - 176°F) (Depends on the time)

EC-113 253

G]

 $\mathbb{M}\mathbb{A}$

LC.

EC

FE

GL.

MT

AT

FA

PD)

TE


RA

RE

ST

RS

Ta HA



Engine Coolant Temperature Sensor (ECTS) (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.

_____OR -

- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

B/G

B/G 50

GND-A

1 2 3 4 5 6 7 8 9 10

19

M18 1 2 GY

101 102 103

108 109

104 105 106

110 111 112

Engine Coolant Temperature Sensor (ECTS) (Cont'd)

ENGINE COOLANT TEMPERATURE SENSOR

(M18)

LG/R

LG/R 51

ECM (ECCS CONTROL MODULE)

(M112)

(M112)

EC-ECTS-01

MA

EM

@I

: Detectable line for DTC : Non-detectable line for DTC

LC

EC



35

CL

Mir

AT

TF

PD

RA

BR

ST

RS


BT


HA


AEC042A

38 39 42 43

20 21 22 23 24 25 26 27 28







Engine Coolant Temperature Sensor (ECTS)	
(Cont'd)	

COMPONENT INSPECTION

Engine coolant temperature sensor

Check resistance as shown in the figure.

(Reference data)

Temperature °C (°F)	Resistance k Ω
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.00
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.

G]

MA

LC

EC

FE

GL

MT

AT

P(j)

FA

 $\mathbb{R}\mathbb{A}$

BR


ST

RS

BT

MA


EL



Throttle Position Sensor COMPONENT DESCRIPTION

The throttle position sensor responds to the accelerator pedal movement. This sensor is a kind of potentiometer which transforms the throttle position into output voltage, and emits the voltage signal to the ECM. In addition, the sensor detects the opening and closing speed of the throttle valve and feeds the voltage signal to the ECM.

Idle position of the throttle valve is determined by the ECM receiving the signal from the throttle position sensor. This controls engine operation such as fuel cut. The throttle position sensor unit contains a built-in "Wide open and closed throttle position switch".



ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and @ (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
22	347	Throttle position conser	Ignition switch "ON" Accelerator pedal released	0.3 - 0.7V
23	23 W Throttle position sensor	Ignition switch "ON" Accelerator pedal fully depressed	Approximately 4V	
49	Р	Sensors' power supply	Ignition switch "ON"	Approximately 5V
50	B/G	Sensors' ground	Engine is running. (Warm-up condition) Idle speed	0.001 - 0.02V

Throttle Position Sensor (Cont'd)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	
THRTL POS SEN Ignition switch: ON (Engine stopped)	Ignition switch: ON	Throttle valve fully closed	0.3 - 0.7V	
	Throttle valve fully opened	Approx. 4.0V		
ABSOL TH:P/S	Ignition switch: ON	Throttle valve fully closed	0.0%	
(Engine stopped)	Throttle valve fully opened	Approx. 84%		

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	
P0120 0403	 An excessively low or high voltage from the sensor is sent to ECM.* Voltage sent to ECM is not practical when compared with mass air flow sensor and camshaft position sensor signals. 	(The sensor circuit is open or shorted.) ■ Throttle position sensor	

*: When this malfunction is detected, the ECM enters fail-safe mode and the MIL lights up. (Refer to EC-76.)

Engine operating condition in fail-safe mode

Throttle position will be determined based on the injected fuel amount and the engine speed.

Therefore, acceleration will be poor.

Condition	Driving condition
When engine is idling	Normal
When accelerating	Poor acceleration
	· · · · · · · · · · · · · · · · · · ·

EC

GI

MA

LC

FE

CL

MT

TF

PD

FA

RA

BR

ST

RS


BT


HA


EL

IDX

EC-119 259







Throttle Position Sensor (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the throttle position sensor circuit. During this check, a 1st trip DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Turn ignition switch "ON".
- 4) Select "MANU TRIG" and "HI SPEED" in "DATA MONITOR" mode with CONSULT.
- 5) Select "THRTL POS SEN" and "ABSOL TH-P/S" in "DATA MONITOR" mode with CONSULT.
- Press RECORD on CONSULT SCREEN at the same time accelerator pedal is depressed.
- 7) Print out the recorded data and check the following:
 - The voltage when accelerator pedal fully released is 0.3 - 0.7V.
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal fully depressed is approximately 4V.



Start engine and warm it up sufficiently.

- OR

- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Turn ignition switch "ON".
- 4) Check the voltage between ECM terminal (2) and (4) (ground) and check the following:
 - The voltage when accelerator pedal fully released is 0.3 - 0.7V.
 - The voltage rise is linear in response to accelerator pedal depression.
 - The voltage when accelerator pedal fully depressed is approximately 4V.

Throttle Position Sensor (Cont'd)

EC-TPS-01

Œ[

 $\mathbb{W}\mathbb{A}$

EM

LC

EC

FE

Cl.

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST


RS

BT


HA

 $\mathbb{D}\mathbb{X}$






AEC043A



Throttle Position Sensor (Cont'd)





GI

LC.

EC

FE

CL,

MT

AT


TF

PD

FA

 $\mathbb{R}\mathbb{A}$

Re



COMPONENT INSPECTION

Throttle position sensor

1. Start engine and warm it up sufficiently.

2. Turn ignition switch "OFF".

3. Disconnect throttle position sensor harness connector.

 Check resistance between terminals ② and ③ while opening throttle valve manually.

Throttle valve conditions	Resistance at 25°C (77°F)
Completely closed	Approximately 0.5 k()
Partially open	0.5 - 4.0 kΩ
Completely open	Approximately 4.0 kΩ

If NG, replace throttle position sensor.

To adjust throttle position sensor, perform "BASIC INSPECTION", EC-72.


ST

RS

HA


]DX

EC-123 263



Engine Coolant Temperature (ECT) Sensor COMPONENT DESCRIPTION

The engine coolant temperature sensor is used to detect the engine coolant temperature. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the engine coolant temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




(Reference data)


Engine coolant temperature °C (°F)	Voltage* (V)	Resistance (kΩ)
-10 (14)	4.4	7.0 - 11.4
20 (68)	3.5	2.1 - 2.9
50 (122)	2.2	0.68 - 1.00
90 (194)	0.9	0.236 - 0.260


^{*:} These data are reference values and measured between ECM terminal (5) (Engine coolant temperature sensor) and ECM terminal (43) (ECCS ground).

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0125 0908	 Rationally incorrect voltage from the sensor is sent to ECM, even when some time has passed after starting the engine. Engine coolant temperature is insufficient for closed loop fuel control. 	 Harness or connectors (High resistance in the circuit) Engine coolant temperature sensor Thermostat







Engine Coolant Temperature (ECT) Sensor (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the engine coolant temperature sensor circuit. During this check, a 1st trip DTC might not be confirmed.

Note: If both DTC P0115 (0103) and P0125 (0908) are displayed, first perform TROUBLE DIAGNOSIS FOR DTC P0115. (See EC-113.)



TOOLS

- 1) Turn ignition switch "ON".
- Select "COOLAN TEMP/S" in "DATA MONITOR" mode with CONSULT.
- Start engine and run it at idle speed.
- Check that the engine coolant temperature rises to 20°C (68°F) or more within 13 minutes. (Be careful not to overheat engine.)

OR

- Turn ignition switch "ON". 1) 2) Select "MODE 1" with GST.
- Start engine and run it at idle speed.
- Check that the engine coolant temperature rises to 20°C (68°F) or more within 13 minutes. (Be careful not to overheat engine.)

OR

- Turn ignition switch "ON". Probe voltage meter between ECM terminal (51) and ground.
- 3) Start engine and run it at idle speed.
- Check that voltage of engine coolant temperature changes to less than 3.5 (V) within 13 minutes. (Be careful not to overheat engine.)

Gil

MA

LC

EC

CL

AT

75

PD

FA

RA

윘옙

ST.

RS

BT


HA

IDX


Engine Coolant Temperature (ECT) Sensor (Cont'd)


EC-ECTS-01

: Detectable line for DTC
: Non-detectable line for DTC











EC-127 267





Engine Coolant Temperature (ECT) Sensor (Cont'd)

COMPONENT INSPECTION


Engine coolant temperature sensor


Check resistance as shown in the figure.

(Reference data)

Temperature °C (°F)	Resistance kΩ
20 (68)	2.1 - 2.9
50 (122)	0.68 - 1.0
90 (194)	0.236 - 0.260

If NG, replace engine coolant temperature sensor.





Front Heated Oxygen Sensor (Front HO2S) COMPONENT DESCRIPTION

The front HO2S is placed into the exhaust manifold. It detects the amount of oxygen in the exhaust gas compared to the outside air. The sensor has a closed-end tube made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions. The sensor signal is sent to the ECM. The ECM adjusts the injection pulse duration to achieve the ideal air-fuel ratio. The ideal air-fuel ratio occurs near the radical change from 1V to 0V.



CL

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (4) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
46	w	Front heated oxygen sen- sor	Engine is running. After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V (periodically change)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	- _
FR O2 SENSOR			0 - 0.3V ↔ Approx. 0.6 - 1.0V	<u> </u>
FR O2 MNTR	Engine: After warming up	Maintaining engine speed at 2,000 rpm	LEAN ↔ RICH Changes more than 5 times during 10 seconds.	- (2)

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	BŢ
P0130	An excessively high voltage from the sensor is sent to ECM.	Harness or connectors	
0303	 The voltage from the sensor is constantly approx. 0.3V. 	(The sensor circuit is open or shorted.)	HA.
	• The maximum and minimum voltages from the sensor do not	 ◆ Front heated oxygen sensor 	0.00.0
	reach the specified voltages.	Fuel pressure	
	The sensor does not respond between rich and lean within	● Injectors	
	the specified time.	Intake air leaks	رعد

IDX

EC-129 269

MA

G

EC

MT

AT

PD)

TF


BA

ST

RS

37

₽A.



Front Heated Oxygen Sensor (Front HO2S) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the front heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.




- 1) Start engine and warm it up sufficiently.
- Select "MANU TRIG" and "HI SPEED" in "DATA MONI-TOR" mode with CONSULT, and select "FR O2 SEN-SOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- Check the following.
- "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.


5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 | FR O2 MNTR R-L-R-L-R-L-R-L-R

R = "FR O2 MNTR", "RICH" L = "FR O2 MNTR", "LEAN"

- "FR O2 SENSOR" voltage goes above 0.6V at least once.
- "FR O2 SENSOR" voltage goes below 0.3V at least once.







Start engine and warm it up sufficiently.

- OR -

- 2) Set voltmeter probes between ECM terminal (6) (sensor signal) and (3) (engine ground).
- Check the following with engine speed held at 2,000 rpm constant under no load.
- Malfunction indicator lamp goes on more than 5 times within 10 seconds in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).
- The maximum voltage is over 0.6V at least one time.
- The minimum voltage is below 0.3V at least one time.

Front Heated Oxygen Sensor (Front HO2S) (Cont'd)

EC-FRO2-01

@l

MA

圖鄉

LG

EC

FE

(CL

MET

AT

75

PD

凮


 $\mathbb{R}\mathbb{A}$

BR

ST

RS

Bir



IGNITION SWITCH ON or START Refer to "EL-POWER".

B/W 3 FRONT HEATED OXYGEN SENSOR (M62) 13 JOINT CONNECTOR-1 M110

ECM (ECCS

M15

CONTROL MODULE) (M112)

9

46

42


O2HF

43

GND-C

ВW

Refer to last page (Foldout page). (M110)




MA

亂

IDX


AEC304A



(Go to next page.)

EC-132 272

SEF377R



EC-133 273


EL

1DX

Closed Loop Control

The closed loop control has one trip detection logic.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0130 0307		 The front heated oxygen sensor circuit is open or shorted. Front heated oxygen sensor Front heated oxygen sensor heater



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the closed loop control. During this check, a 1st trip DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- Select "MANU TRIG" and "HI SPEED" in "DATA MONI-TOR" mode with CONSULT, and select "FR O2 SEN-SOR" and "FR O2 MNTR".
- 3) Hold engine speed at 2,000 rpm under no load during the following steps.
- 4) Touch "RECORD" on CONSULT screen.
- 5) Check the following.
- "FR O2 MNTR" in "DATA MONITOR" mode changes from "RICH" to "LEAN" to "RICH" 5 times in 10 seconds.

5 times (cycles) are counted as shown below:

cycle | 1 | 2 | 3 | 4 | 5 | FR O2 MNTR R-L-R-L-R-L-R




- 1) Start engine and warm it up sufficiently.
- Check that malfunction indicator lamp goes on more than 5 times in 10 seconds while keeping at 2,000 rpm in Diagnostic Test Mode II (FRONT HEATED OXYGEN SENSOR MONITOR).

DIAGNOSTIC PROCEDURE

Refer to TROUBLE DIAGNOSIS FOR DTC P0130, EC-129. Refer to TROUBLE DIAGNOSIS FOR DTC P0135, EC-135.

Front Heated Oxygen Sensor Heater

SYSTEM DESCRIPTION



The ECM performs ON/OFF control of the front heated oxygen sensor heater corresponding to the engine conditions.

Engine speed (rpm)	Engine condition	Front heated oxygen sensor heater
Above 3,000	_	OFF
Below 3,000	Heavy load after warm-up	OFF
	Except above	ON

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	AT
42	Front heated oxygen sen-	Engine is running. Engine speed is below 3,000 rpm.	Approximately 0V	TF	
42	W	sor heater	Engine is running. Engine speed is above 3,000 rpm.	BATTERY VOLTAGE (11 - 14V)	PD

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	RA
FR O2 HEATER	Engine speed: Idle	ON	
FN 02 HEATER	Engine speed: Above 3,000 rpm	OFF	BR

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	- §1
P0135 0901	 The current amperage in the front heated oxygen sensor heater circuit is out of the normal range. (An improper voltage drop signal is sent to ECM 	 Harness or connectors (The front heated oxygen sensor heater circuit is open or shorted.) 	- R
	through the front heated oxygen sensor heater.)	Front heated oxygen sensor heater	_ Bi

EC-135 275

HA

Gi]

FE


CL.

MT

FA

El

[DX



Front Heated Oxygen Sensor Heater (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- Start engine and run it for at least 6 seconds at idle speed.

GST

- 1) Start engine and run it for at least 6 seconds at idle speed.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Start engine and run it for at least 6 seconds at idle speed.
- 4) Select "MODE 3" with GST.

– OR -

---- OR -





- Start engine and run it for at least 6 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II" (Self-diagnostic results) with ECM.
- When using GST, "DIAGNOSTIC TROUBLE CODE CON-FIRMATION PROCEDURE" should be performed twice as much as when using CONSULT or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CON-SULT or ECM (Diagnostic Test Mode II) is recommended.

Front Heated Oxygen Sensor Heater (Cont'd)

EC-FRO2/H-01

G





AEC305A


RS


BT

HA

EL.

IDX





COMPONENT INSPECTION

Front heated oxygen sensor heater

Check resistance between terminals (3) and (1).

Resistance: 2.3 - 4.3 Ω at 25°C (77°F)


Check continuity between terminals (2) and (1), (3) and (2).

Continuity should not exist.

If NG, replace the front heated oxygen sensor.

CAUTION:

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



Rear Heated Oxygen Sensor (Rear HO2S)

COMPONENT DESCRIPTION

The rear heated oxygen sensor (Rear HO2S), after three way catalyst, monitors the oxygen level in the exhaust gas.

Even if switching characteristics of the front heated oxygen sensor are shifted, the air fuel ratio is controlled to stoichiometric, by the signal from the rear heated oxygen sensor.

This sensor is made of ceramic zirconia. The zirconia generates voltage from approximately 1V in richer conditions to 0V in leaner conditions.

Under normal conditions the rear heated oxygen sensor is not used for engine control operation.

EC

CL

ΔT

77

PD)

|**5**/A

RA

Gl

MA

追∭

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
52	w	Rear heated oxygen sen- sor	Engine is running. After warming up sufficiently and engine speed is 2,000 rpm.	0 - Approximately 1.0V

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
RR 02 SENSOR	• Facing After warming up	Maintaining engine speed at 2,000	0 - 0.3V ↔ Approx. 0.6 - 1.0V
RR O2 MNTR	Engine: After warming up	rpm	LEAN ↔ RICH

ON BOARD DIAGNOSIS LOGIC


The rear heated oxygen sensor has a much longer switching time between rich and lean than the front heated oxygen sensor. The oxygen storage capacity of the three way catalyst causes the longer switching time. To judge the malfunctions of rear heated oxygen sensor, ECM monitors the sensor's voltage value and the switching response during the various driving condition such as fuel-cut.


Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	BF
P0136 0707	 An excessively high voltage from the sensor is sent to ECM. The maximum and minimum voltages from the sensor are not reached to the specified voltages. 	 Harness or connectors (The sensor circuit is open or shorted.) Rear heated oxygen sensor 	SŢ
	It takes more time for the sensor to respond between rich and lean than the specified time.	Fuel pressureInjectorsIntake air leaks	IRS

EC-139 279

BT,

HA





Rear Heated Oxygen Sensor (Rear HO2S) (Cont'd)

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the rear heated oxygen sensor circuit. During this check, a 1st trip DTC might not be confirmed.



- 1) Start engine and warm it up sufficiently.
- Select "FUEL INJECTION" in "ACTIVE TEST" mode, and select "RR O2 SENSOR" as the monitor item with CONSULT.
- 3) Check "RR O2 SENSOR" at idle speed when adjusting "FUEL INJECTION" to ±25%.

"RR O2 SENSOR" should be above 0.48V at least once when the "FUEL INJECTION" is +25%. "RR O2 SENSOR" should be below 0.43V at least once when the "FUEL INJECTION" is -25%.



1) Start engine and warm it up sufficiently.

- OR

- Set voltmeter probes between ECM terminals (see sor signal) and (see (engine ground).
- Check the voltage when racing up to 4,000 rpm under no load at least 10 times.


(depress and release accelerator pedal as soon as possible)

The voltage should be above 0.48V and below 0.43V at least once during this procedure.

If the voltage can be confirmed in step 3, step 4 is not necessary.


4) Keep vehicle at idling for 10 minutes, then check the voltage. Or check the voltage when coasting from 80 km/h (50 MPH) in 3rd gear position.

The voltage should be above 0.48V and below 0.43V at least once during this procedure.



Rear Heated Oxygen Sensor (Rear HO2S) **G**[(Cont'd) **ER-RRO2-01** IGNITION SWITCH MA ON or START Refer to "EL-POWER". : Detectable line for DTC 9 国M : Non-detectable line for DTC LC (M401)REAR HEATED OXYGEN SENSOR EC (M402) FE [3] G/R ĞΥ CL MT G/R AT TF PD FA 4 JOINT CONNECTOR-1 RA (M110) BR 115 52 ECM (ECCS CONTROL MODULE) B O2HR O2SR \$1 (M112) (M15) RS Refer to last page (Foldout page). (M110) BT HA (M112 104 105 106 EL 44 45 46 57 58 59 60 24 25 26 27 28 10 109 29 30 31 32 33 47 48 62 63 64 65 19 49 50 70 66 67 68 69 1DX

AEC306A



TROUBLE DIAGNOSIS FOR DTC P0141 (G) Rear Heated Oxygen Sensor Heater SYSTEM DESCRIPTION MA ECM Rear (ECCS heated oxy-EM Engine speed Camshaft position sensor control gen sensor module) heater 1LC The ECM performs ON/OFF control of the rear **OPERATION** EC heated oxygen sensor heater corresponding to the Rear heated oxygen sensor engine speed. Engine speed rpm heater FE **OFF** Above 6,000 Below 6,000 ON CL **ECM TERMINALS AND REFERENCE VALUE** Specification data are reference values and are measured between each terminal and la (ECCS ground). MIT TER-WIRE DATA **MINAL** ITEM CONDITION COLOR (DC voltage) AT NO. Engine is running. Approximately 0V TF Engine speed is below 6,000 rpm. Rear heated oxygen sen-R 115 sor heater Ignition switch "ON" **BATTERY VOLTAGE** (11 - 14V)PD) Engine is stopped. **CONSULT REFERENCE VALUE IN DATA MONITOR MODE** FA Specification data are reference values. MONITOR ITEM CONDITION **SPECIFICATION** RA • Engine speed: Below 6,000 rpm ON RR 02 HEATER Ignition switch: ON (Engine stopped) OFF BR ON BOARD DIAGNOSIS LOGIC Diagnostic Trouble Check Items ST Malfunction is detected when Code No. (Possible Cause) P0141 The current amperage in the rear heated oxygen Harness or connectors 0902 RS sensor heater circuit is out of the normal range. (The rear heated oxygen sensor heater circuit is

(An improper voltage drop signal is sent to ECM

through the rear heated oxygen sensor heater.)

EC-143 283

open or shorted.)


Rear heated oxygen sensor heater

BT

ΉA

EL

ID)X



Rear Heated Oxygen Sensor Heater (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- Start engine and run it for at least 6 seconds at idle speed.

(S)

- 1) Start engine and run it for at least 6 seconds at idle speed.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Start engine and run it for at least 6 seconds at idle speed.
- 4) Select "MODE 3" with GST.

- OR -


OR -




- 1) Start engine and run it for at least 6 seconds at idle speed.
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.
- When using GST, "DIAGNOSTIC TROUBLE CODE CON-FIRMATION PROCEDURE" should be performed twice as much as when using CONSULT or ECM (Diagnostic Test Mode II) because GST cannot display MODE 7 (1st trip DTC) concerning this diagnosis. Therefore, using CON-SULT or ECM (Diagnostic Test Mode II) is recommended.

Rear Heated Oxygen Sensor Heater (Cont'd) G1 EC-RRO2/H-01 MA IGNITION SWITCH ON or START Refer to : Detectable line for DTC "EL-POWER". : Non-detectable line for DTC LC EC REAR HEATED OXYGEN SENSOR FE 2 G/R В GΥ CL MT 2 AT TF [PD) FA 4 JOINT CONNECTOR-1 M110 $\mathbb{R}\mathbb{A}$ 115 52 ECM (ECCS O2HR O2SR CONTROL 88 MODULE) (M112) ST M15(M16 Refer to last page (Foldout page). RS (M110) BŢ HA 20 21 22 23 56 10 19 42 43 49 50 44 45 46 57 58 59 60 5 6 7 8 9 24 25 26 27 28 61 108 110 111 29 30 31 32 33 47 48 62 63 64 65 70 51 52 66 67 68 69 34 35 36 37 1DX

AEC307A





Rear Heated Oxygen Sensor Heater (Cont'd) COMPONENT INSPECTION

Rear heated oxygen sensor heater

Check the following.

1. Check resistance between terminals ④ and ①. Resistance: 11.4 - 17.4Ω at 25°C (77°F)

2. Check continuity.

Terminal No.	Continuity	
② and ①, ③, ④	No	
3 and 1, 2, 4	No	

If NG, replace the rear heated oxygen sensor.

CAUTION

Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.

GI

MA

EM

LC

EC

FE

C[_

MT

AT

TF

PD

FA

RA

BR

Sī

RS

BŢ

HA


EL

EC-147 287


Fuel Injection System Function (Lean side)

ON BOARD DIAGNOSIS LOGIC

With Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (the actual mixture ratio is too lean), the ECM judges the condition as a fuel system malfunction and lights up the MIL (2 trip detection logic).



Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0171	Fuel injection system does not operate properly.	• Intake air leak
0115	The amount of mixture ratio compensation is too large.	 Front heated oxygen sensor
	(The mixture ratio is too lean.)	Injectors
		Exhaust gas leak
		 Incorrect fuel pressure
		● Lack of fuel
		 Mass air flow sensor



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)




- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.
- 4) Clear the self-learning control coefficient by touching "CLEAR".
- 5) Select "DATA MONITOR" mode with CONSULT.
- Start engine again and run it for at least 10 minutes at idle speed.
 - The 1st trip DTC should be detected at this stage, if a malfunction exists.
- 7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too.

 Crank engine while depressing accelerator pedal. If

engine starts, go to "DIAGNOSTIC PROCEDURE", EC-151. If engine does not start, check exhaust and intake air leak visually.

- OR



Fuel Injection System Function (Lean side) (Cont'd)



- 1) Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.
- Stop engine and reconnect mass air flow sensor harness connector.
- Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- Select "MODE 4" with GST and erase the 1st trip DTC P0100.
- Start engine again and run it for at least 10 minutes at idle speed.
- Select "MODE 7" with GST. The 1st trip DTC P0171 should be detected at this stage, if a malfunction exists.
- If it is difficult to start engine at step 8, the fuel injection system has a malfunction. Crank engine while depressing accelerator pedal. If engine starts, go to "DIAGNOSTIC PROCEDURE", EC-151. If engine does not start, check exhaust and intake air leak visually.

OR -



- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- Disconnect mass air flow sensor harness connector.
- 4) Start engine and run it for at least 3 seconds at idle speed.
- 5) Stop engine and reconnect mass air flow sensor harness connector.
- 6) Turn ignition switch "ON".
- 7) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure 1st trip DTC 0102 is detected.
- 8) Erase the 1st trip DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 9) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 10) Start engine again and run it for at least 10 minutes at idle speed.
 - The 1st trip DTC 0115 should be detected at this stage, if a malfunction exists.
- 11) If it is difficult to start engine at step 10, the fuel injection system also has a malfunction.
 - Crank engine while depressing accelerator pedal. If engine starts, go to "DIAGNOSTIC PROCEDURE", EC-151. If engine does not start, check exhaust and intake air leak visually.

(H

LC

EC

MT

(C|9

BA

BR

RS

BT


HA


EL,

IDX


Fuel Injection System Function (Lean side) (Cont'd)

EC-FUEL-01





EC-151 291




Fuel Injection System Function (Rich side)


ON BOARD DIAGNOSIS LOGIC

With Mixture Ratio Self-Learning Control, the actual mixture ratio can be brought closely to the theoretical mixture ratio based on the mixture ratio feedback signal from the front heated oxygen sensor. The ECM calculates the necessary compensation to correct the offset between the actual and the theoretical ratios. In case the amount of the compensation value is extremely large (the actual mixture ratio is too rich), the ECM judges the condition as a fuel system malfunction and lights up the MIL (2 trip detection logic).

Front heated oxygen sensor	Density of oxygen in exhaust gas (Mixture ratio feedback signal)	ECM (ECCS control	 Injectors	LC
		module)		EC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	FE
P0172 0114	 Fuel injection system does not operate properly. The amount of mixture ratio compensation is too large. (The mixture ratio is too rich.) 	Front heated oxygen sensorInjectorsExhaust gas leak	CL.
		Incorrect fuel pressureMass air flow sensor	MT





DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)



1) Start engine and warm it up sufficiently.

Turn ignition switch "OFF" and wait at least 7 seconds.

Turn ignition switch "ON" and select "SELF-LEARN CONTROL" in "ACTIVE TEST" mode with CONSULT.

Clear the self-learning control coefficient by touching "CLEAR".

Select "DATA MONITOR" mode with CONSULT.

Start engine again and run it for at least 10 minutes at idle speed.

The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists.

7) If it is difficult to start engine at step 6, the fuel injection system has a malfunction, too. Crank engine while depressing accelerator pedal. If engine starts, go to "DIAGNOSTIC PROCEDURE", EC-156. If engine does not start, remove ignition plugs and check for fouling, etc.

OR -

(SF)

Start engine and warm it up sufficiently. 1)

Turn ignition switch "OFF" and wait at least 7 seconds.

Disconnect mass air flow sensor harness connector. Then restart and run engine for at least 3 seconds at idle speed.

Stop engine and reconnect mass air flow sensor harness connector.

- 5) Select "MODE 7" with GST. Make sure 1st trip DTC P0100 is detected.
- 6) Select "MODE 4" with GST and erase the 1st trip DTC P0100.
- 7) Start engine again and run it for at least 10 minutes at idle speed.

Select "MODE 7" with GST. The 1st trip DTC P0172 should be detected at this stage, if a malfunction exists. (6)

MA

EM

/NT/

AT

TF

PD

BR

RS

KA

IDX

293

Fuel Injection System Function (Rich side) (Cont'd)

9) If it is difficult to start engine at step 8, the fuel injection system has a malfunction. Crank engine while depressing accelerator pedal. If engine starts, go to "DIAGNOSTIC PROCEDURE", EC-156. If engine does not start, remove ignition plugs and check for fouling, etc.



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Disconnect mass air flow sensor harness connector.

- OR

- Start engine and run it for at least 3 seconds at idle speed.
- 5) Stop engine and reconnect mass air flow sensor harness connector.
- 6) Turn ignition switch "ON".
- Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure 1st trip DTC 0102 is detected.
- Erase the 1st trip DTC 0102 by changing from Diagnostic Test Mode II to Diagnostic Test Mode I.
- 9) Perform Diagnostic Test Mode II (Self-diagnostic results) with ECM. Make sure DTC 0505 is detected.
- 10) Start engine again and run it for at least 10 minutes at idle speed.
 - The 1st trip DTC 0114 should be detected at this stage, if a malfunction exists.
- 11) If it is difficult to start engine at step 10, the fuel injection system also has a malfunction.
 Crank engine while depressing accelerator pedal. If


engine starts, go to "DIAGNOSTIC PROCEDURE", EC-156. If engine does not start, remove ignition plugs and check for fouling, etc.


294 EC-154

Fuel Injection System Function (Rich side)


GF. (Cont'd) **EC-FUEL-01** MAIGNITION SWITCH BATTERY ON or START Refer to "EL-POWER". : Detectable line for DTC 9 ĹC **FUSIBLE** : Non-detectable line for DTC LINK R/W (M47), (E21) EC B/W W/B 3 FE FRONT HEATED **OXYGEN** SENSOR (M62) GL. IGNITION 2 SWITCH (M130) ACC • MIT 3 RΛV AT 2 15 TAIOL TF CONNECTOR-1 (M110) PD) B/W BW BW BW 2 2 INJECTOR INJECTOR INJECTOR INJECTOR NO. 1 NO. 2 NO. 3 NO. 4 (M11) (M5) (M10) M6RA W/B W/R W/L W/G W/R W/G BR 43 42 102 107 109 46 104 **ECM** INJ#1 INJ#4 GND-C IN.I#3 O2HF (ECCS CONTROL MODULE) ST (M112)M15 M16 RS Refer to last page (Foldout page). (M6) , M10 (M11) **M110** (M5) BT **■ E**21 B 1 (M47) (M62) (123) $[\exists]A$ (M112 40 41 104 105 106 20 21 22 23 53 54 55 56 5 6 7 8 9 11 12 13 14 10 24 25 26 27 28 42 43 44 45 46 57 58 59 60 61 108 109 29 30 31 32 33 47 48 62 63 64 65 19 70 1DX

AEC308A






EC-157 297



Tank Fuel Temperature Sensor COMPONENT DESCRIPTION

The tank fuel temperature sensor is used to detect the fuel temperature inside the fuel tank. The sensor modifies a voltage signal from the ECM. The modified signal returns to the ECM as the fuel temperature input. The sensor uses a thermistor which is sensitive to the change in temperature. The electrical resistance of the thermistor decreases as temperature increases.




(Reference data)

Fluid temperature °C (°F)	Voltage* (V)	Resistance $(k\Omega)$
20 (68)	3.5	2.3 - 2.7
50 (122)	2.2	0.79 - 0.90

^{*:} These data are reference values and measured between ECM terminal 63 (Tank fuel temperature sensor) and ECM terminal 43 (ECCS ground).

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Causes)
P0180	 An excessively high or low voltage is sent to ECM. 	Harness or connectors
0402	 Rationally incorrect voltage is sent to ECM, compared with the voltage signals from engine coolant tempera- ture sensor and intake air temperature sensor. 	(The sensor circuit is open or shorted.) ■ Tank fuel temperature sensor



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 12 seconds.





- 1) Turn ignition switch "ON" and wait at least 12 seconds.
- 2) Select "MODE 7" with GST.





- 1) Turn ignition switch "ON" and wait at least 12 seconds.
- Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

EC-158

FUEL TANK GAUGE UNIT (TANK FUEL TEMPERATURE

SENSOR)

C4

B/G B/G

B/G 50

GND-A

ECM (ECCS CONTROL MODULE)

56 61

(M112)

44 45 46 57 58 59 60

(M112)

38 39

42 43

(C2)

M108

2

8

63

TFUEL

4

10

56789

11 12 13 14 19 15 16 17 18

101 102 103

107 108 109

104 105 106

110 111 112

Tank Fuel Temperature Sensor (Cont'd)

EC-TFTS-01

MA

@||

■ : Detectable line for DTC : Non-detectable line for DTC 1C

EC

FE

CL

MT

AT

TF

FA

RA

BR

ST

RS

BT

HA

DX


AEC049A


EC-159


24 25 26 27 28

29 30 31 32 33

299







Tank Fuel Temperature Sensor (Cont'd) COMPONENT INSPECTION

Tank fuel temperature sensor

Check resistance by heating with hot water or heat gun as shown in the figure.

(Reference data)

Temperature °C (°F)	Resistance kΩ
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90

If NG, replace tank fuel temperature sensor.

GÍ

MA

LC

__

EC

FE

@L

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

BT

HA

EL

HDX

EC-161 301

No. 4 - 1 Cylinder Misfire, Multiple Cylinder **Misfire**

ON BOARD DIAGNOSIS LOGIC

If a misfire occurs, the engine speed will fluctuate. If the fluctuation is detected by the crankshaft position sensor (OBD), the misfire is diagnosed.

The misfire detection logic consists of the following two conditions.

Crankshaft position sensor (OBD)	Engine speed	ECM

1. One Trip Detection Logic (Three Way Catalyst Damage)

When a misfire is detected which will overheat and damage the three way catalyst, the malfunction indicator lamp (MIL) will start blinking; even during the first trip. In this condition, ECM monitors the misfire every 200 revolutions.

If the misfire frequency decreases to a level that will not damage the three way catalyst, the MIL will change from blinking to lighting up.

(After the first trip detection, the MIL will light up from engine starting. If a misfire is detected that will cause three way catalyst damage, the MIL will start blinking.)

2. Two Trip Detection Logic (Exhaust quality deterioration)

When a misfire that will not damage the three way catalyst (but will affect exhaust emission) occurs, the malfunction indicator lamp will light up based on the second consecutive trip detection logic. In this condition, ECM monitors the misfire for every 1,000 revolutions of the engine.

Diagnostic Trouble Code Nos.	Malfunction is detected when	Check Items (Possible Cause)
P0300 (0701)	Multiple cylinders misfire.	Improper spark plugInsufficient compression
P0301 (0608)	No. 1 cylinder misfires.	Incorrect fuel pressure EGR valve
P0302 (0607)	No. 2 cylinder misfires.	The injector circuit is open or shorted Injectors Intake air leak
P0303 (0606)	No. 3 cylinder misfires.	The ignition secondary circuit is open or shorted
P0304 (0605)	No. 4 cylinder misfires.	Lack of fuelMagnetized flywheel (drive plate)

- OR -


– OR -

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE (Overall)



- 1) Turn ignition switch "ON", and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and warm it up sufficiently.
- 3) Turn ignition switch "OFF" and wait at least 3 seconds.
- 4) Start engine again and drive at 1,500 3,000 rpm for at least 3 minutes. Hold the accelerator pedal as steady as possible during driving.

Note: Refer to the freeze frame data for the test driving condition.



- 2) Turn ignition switch "OFF" and wait at least 3 seconds.
- 3) Start engine again and drive at 1,500 3,000 rpm for at least 3 minutes. Hold the accelerator pedal as steady as possible during driving.
- 4) Select "MODE 7" with GST.


Note: Refer to the freeze frame data for the test driving condition.




- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 3 seconds.
- 3) Start engine again and drive at 1,500 3,000 rpm for at least 3 minutes. Hold the accelerator pedal as steady as possible during driving.
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.


EC-162 302


TROUBLE DIAGNOSIS FOR DTC P0300 - P0304



TROUBLE DIAGNOSIS FOR DTC P0300 - P0304







COMPONENT INSPECTION

Ignition wires

- Inspect wires for cracks, damage, burned terminals and for improper fit.
- Measure the resistance of wires to their distributor cap terminal. Move each wire while testing to check for intermittent breaks.

Resistance:

13.6 - 18.4 k Ω /m (4.15 - 5.61 k Ω /ft) at 25°C (77°F)

If the resistance exceeds the above specification, inspect ignition wire to distributor cap connection. Clean connection or replace the ignition wire with a new one.

IDX

TF

PD


FA


RA

RS

BŤ

HA





Crankshaft Position Sensor (CKPS) (OBD) COMPONENT DESCRIPTION

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system. It is used only for the on board diagnosis of misfire.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).


TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
50	B/G	Sensors' ground	Engine is running. (Warm-up condition)	0.001 - 0.02V
53	R	Crankshaft position sensor (OBD)	Engine is running. (A/T: N range, M/T: Neutral) Idle speed (Air conditioner switch "OFF".)	More than 0.2V* (AC range)

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0335 0802	 The proper pulse signal from the crankshaft position sensor (OBD) is not sent to ECM while the engine is running at the specified engine speed. 	Harness or connectors (The crankshaft position sensor (OBD) circuit is open.) Crankshaft position sensor (OBD)

306 EC-166



Crankshaft Position Sensor (CKPS) (OBD) (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for at least 10 seconds at idle speed.



G1

MA



- 1) Start engine and run it for at least 10 seconds at idle speed.
- 2) Select "MODE 7" with GST.

EC

LC



 Start engine and run it for at least 10 seconds at idle speed.

- OR --

- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

FE

CL

MT

AT

TF

PD)

FA

RA

BR

ST

RS

BT


MA


EL

IDX


Crankshaft Position Sensor (CKPS) (OBD) (Cont'd)


EC-CKPS-01





EC-169 309







Crankshaft Position Sensor (CKPS) (OBD) (Cont'd)

COMPONENT INSPECTION

Crankshaft position sensor (OBD)

- Disconnect crankshaft position sensor (OBD) harness connector.
- 2. Loosen the fixing bolt of the sensor.
- 3. Remove the sensor.
- 4. Visually check the sensor for chipping.
- Check resistance as shown in the figure.
 Resistance: Approximately 166.5 203.5Ω at 20°C (68°F)





Camshaft Position Sensor (CMPS)

COMPONENT DESCRIPTION

The camshaft position sensor is a basic component of the ECCS. It monitors engine speed and piston position. These input signals to the ECM are used to control fuel injection, ignition timing and other functions.

The camshaft position sensor has a rotor plate and a wave-forming circuit. The rotor plate has 360 slits for a 1° signal and 4 slits for a 180° signal. The wave-forming circuit consists of Light Emitting Diodes (LED) and photo diodes.

The rotor plate is positioned between the LED and the photo diode. The LED transmits light to the photo diode. As the rotor plate turns, the slits cut the light to generate rough-shaped pulses. These pulses are converted into on-off signals by the wave-forming circuit and sent to the ECM.

The distributor is not repairable and must be replaced as an assembly, except distributor cap.

EC

G

MA

EM

LC

FE

CL

MT

AT

TF

PD

FA

RA

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
40 44	GY R	Camshaft position sensor (Reference signal)	Engine is running.	Approximately 0.3V*
41	G	Camshaft position sensor (Position signal)	Engine is running.	Approximately 2.5V*


^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check items (Possible cause)	BR
P0340 0101	Either 1° or 180° signal is not sent to ECM for the first few seconds during engine cranking.	Harness or connectors (The camshaft position sensor circuit is open or shorted.)	 \$T
	 Either 1° or 180° signal is not sent to ECM often enough while the engine speed is higher than the specified engine speed. 	 Camshaft position sensor Starter motor (Refer to EL section.) Starting system circuit (Refer to EL section.) Dead (Weak) battery 	RS
	The relation between 1° and 180° signal is not in the normal range during the specified engine speed.		2T _

EC-171 311

[=]<u>/</u>A\



Camshaft Position Sensor (CMPS) (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: Before performing the following procedure, confirm that battery voltage is more than 10.5V.

— OR -

– OR -



- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 2) Start engine and run it for 2 seconds. (If engine does not run, crank engine for at least 2 seconds.)


1)

- 1) Start engine and run it for 2 seconds. (If engine does not run, crank engine for at least 2 seconds.)
- 2) Select "MODE 7" with GST.


NO


- 1) Start engine and run it for 2 seconds. (If engine does not run, crank engine for at least 2 seconds.)
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Camshaft Position Sensor (CMPS) (Cont'd)




AEC050A





Camshaft Position Sensor (CMPS) (Cont'd) DIAGNOSTIC PROCEDURE (NON-DETECTABLE CIRCUIT)



Disconnect and reconnect harness connectors in the circuit. Then retest.

Trouble is not fixed.

Check ECM pin terminals for damage and check the connection of ECM harness con-

check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

Refer to "COMPONENT INSPECTION"

below.

INSPECTION END

(G)

MA

LC

EC

CL.

MIT

AT

TF

PD

FA







BR

ST

RS

BT





COMPONENT INSPECTION

Camshaft position sensor

Start engine.

SEF750R

Check voltage between terminals 3, 4 and ground with DC range.

Condition	Terminals	Voltage
Engine winning at idla	3 and ground	Approximately 0.3V*
Engine running at idle	4 and ground	Approximately 2.5V*

 Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

If NG, replace distributor assembly with camshaft position sensor.

Visually check signal plate for damage or dust.


HA

IDX

EC-175 315


EGR Function

SYSTEM DESCRIPTION



This system cuts and controls vacuum applied to the EGR valve to suit engine operating conditions. This cut-and-control operation is accomplished through the ECM and the EGRC-solenoid valve. When the ECM detects any of the following conditions, current flows through the solenoid valve. This causes the port vacuum to be discharged into the atmosphere and the EGR valve remains closed.

- Low engine coolant temperature
- Engine starting
- Engine stopped
- Engine idling
- Excessively high engine coolant temperature
- Mass air flow sensor malfunction




ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
50	B/G	Sensors' ground	Engine is running. (Warm-up condition) Idle speed	0.001 - 0.02V
62	G/OR	EGR temperature sensor	Engine is running. (Warm-up condition) Idle speed	Less than 4.5V
			Engine is running. (Warm-up condition) EGR system is operating.	0 - 3.0V
103	W/L	EGRC-solenoid valve	Engine is running. (Warm-up condition) Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
			Engine is running. (Warm-up condition) Idle speed	0 - 1V

316 EC-176




EGR Function (Cont'd) COMPONENT DESCRIPTION

Exhaust gas recirculation (EGR) valve

The EGR valve controls the amount of exhaust gas routed to the intake manifold. Vacuum is applied to the EGR valve in response to throttle valve opening. The vacuum controls the movement of a taper valve connected to the vacuum diaphragm in the EGR valve.



MA



EGR temperature

ECM

EGR

temperature

SEF073P

sensor

EGRC-solenoid valve

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve).

When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve.



. .

31

MT

ON BOARD DIAGNOSIS LOGIC

If the absence of EGR flow is detected by EGR temperature sensor under the condition that calls for EGR, a low-flow malfunction is diagnosed.

If EGR temperature sensor detects EGR flow under the condition that does not call for EGR, a high-flow malfunction is diagnosed.

TF

AT

PD

FA

回瓜

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	
P0400	A) The exhaust gas recirculation (EGR) flow is exces-	● EGR vaive stuck closed	
0302	sively low during the specified driving condition.	EGRC-BPT valve leaking	
		Passage blocked	
		EGRC-solenoid valve	
		Tube leaking for EGR valve	
		EGR temperature sensor	
	B) The exhaust gas recirculation (EGR) flow is exces-	EGRC-solenoid valve	
	sively high during the specified driving condition.	● EGR valve leaking or stuck open	
		● EGR temperature sensor	

OVERALL FUNCTION CHECK


Use this procedure to check the overall EGR function. During this check, a 1st trip DTC might not be confirmed.


Before starting with the following procedure, check the engine coolant temperature of the freeze frame data with CONSULT or Generic Scan Tool.


If the engine coolant temperature is higher than or equal to 55°C (131°F), perform only "Procedure for malfunction A".


If the engine coolant temperature is lower than 55°C (131°F), perform both "Procedure for malfunction A" and "Procedure for malfunction B". In this case, check DTCs in the ECM and perform inspections one by one based on "INSPECTION PRIORITY", refer to EC-75.

IDX









EGR Function (Cont'd)

Procedure for malfunction A

- 1) Start engine and warm it up sufficiently.
- 2) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.

EGR valve should lift up and down without sticking.

If EGR valve does not lift up and down, try again with either of the following methods:




 Select "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and turn the solenoid valve "OFF".





- Disconnect EGRC-solenoid valve harness connector.
 (The 1st trip DTC for EGRC-solenoid valve will be displayed, however, ignore it.)
- 3) Check voltage between EGR temperature sensor harness connector terminal ① and ground at idle speed.

Less than 4.5V should exist.

- Turn ignition switch "OFF".
 Check harness continuity between EGR temperature sensor harness connector terminal ② and ECM terminal ⑤.
 Continuity should exist.
- 5) Perform "COMPONENT INSPECTION", "EGR temperature sensor", EC-183.







EGR Function (Cont'd)

Procedure for malfunction B



- Start engine.
- 2) Turn EGRC-solenoid valve "ON" in "ACTIVE TEST" mode with CONSULT.
- 3) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.

EGR valve should be closed and should not lift up.



 Confirm the engine coolant temperature is lower than 55°C (131°F) in "Mode 1" with generic scan tool. Perform the following steps before its temperature becomes higher than 55°C (131°F).

2) Start engine.

3) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.


EGR valve should be closed and should not lift up.



Confirm the voltage between ECM terminals (3) and (4) is higher than 2.08V.
 Perform the following steps before the voltage becomes lower than 2.08V.

2) Start engine.

3) Check for the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load.



GI

MA

LC

EC

CL.

MIT

TF

PD

FA

RA

BR

ST

RS

BT


HA


EL


10X


EGR Function (Cont'd)

EC-EGRC1-01











EC-181 321

EGR Function (Cont'd)





COMPONENT INSPECTION

EGR valve

Apply vacuum to EGR valve vacuum port with a hand vacuum pump.

EGR valve spring should lift.


If NG, replace EGR valve.



- Plug one of two ports of EGRC-BPT valve.
- Vacuum from the other port and check for leakage while applying a pressure above 0.981 kPa (100 mmH₂O, 3.94 inH₂O) from under EGRC-BPT valve.
- 3. If a leakage is noted, replace the valve.

FUSE (2) BA BATTERY MEC488B

SEF643Q



EGR Function (Cont'd)

EGRC-solenoid valve

Check solenoid valve, following the table as shown below:

Conditions	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

If NG, replace the solenoid valve.

EGR temperature sensor

Check resistance change and resistance value.

(Reference data)

EGR temperature °C (°F)	Voltage (V)	Resistance (M Ω)
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

if NG, replace EGR temperature sensor.

G]

 $\mathbb{M}\mathbb{A}$ 늴쎖

[_C

EC

FE

GL

MT

AT

TF

PD)

FA

 $\mathbb{R}\mathbb{A}$

37

SŢ

RS


BT

HA

EL

[DX]

EGRC-BPT Valve Function



SYSTEM DESCRIPTION

The EGRC-BPT valve monitors exhaust pressure to activate the diaphragm, controlling throttle body vacuum applied to the EGR valve. In other words, recirculated exhaust gas is controlled in response to positioning of the EGR valve or to engine operation.

ON BOARD DIAGNOSIS LOGIC

If too much EGR flow exists due to an EGRC-BPT valve malfunction, off idle engine roughness will increase. If the roughness is large, then the vacuum to the EGR valve is interrupted through the EGRC-solenoid valve. If the engine roughness is reduced at that time, the EGRC-BPT valve malfunction is indicated.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0402 0306	◆ The EGRC-BPT valve does not operate properly.	EGRC-BPT valve Misconnected rubber tube Blocked rubber tube Intake manifold EGR passage

324 EC-184

EGRC-BPT Valve Function (Cont'd)

OVERALL FUNCTION CHECK


Use this procedure to check the overall function of the EGRC-BPT valve. During this check, a 1st trip DTC might not be confirmed.


1. Disconnect the rubber tube to the EGRC-solenoid valve at the intake manifold.

Disconnect the rubber tube to the EGRC-solenoid valve at the EGRC-BPT valve. Connect the intake manifold and the EGRC-BPT valve. (The intake manifold vacuum will be directly applied to the EGRC-BPT valve.)

3. Start engine.

- 4. Check for the EGR valve lifting with engine at less than 1,500 rpm under no load. EGR valve should remain closed.
- 5. Check the EGR valve lifting when revving from 2,000 rpm up to 4,000 rpm under no load. EGR valve should lift up, and go down without sticking when the engine is returned to idle.
- 6. Check rubber tube between EGRC-solenoid valve and throttle body for misconnection, cracks or blockages.





COMPONENT INSPECTION

EGRC-BPT valve

- Plug one of two ports of EGRC-BPT valve.
- Vacuum from the other port and check leakage without applying any pressure from under EGR-BPT valve. Leakage should exist.

EC

(G1

MIA

1C

EE

GL

MT

Air

TF

PD

FA

RA

BR

RS

ST


BT

HA

EL

Three Way Catalyst Function

ON BOARD DIAGNOSIS LOGIC



The ECM monitors the switching frequency ratio of front heated oxygen sensor and rear heated oxygen sensor.


A three way catalyst with high oxygen storage capacity will indicate a low switching frequency of rear heated oxygen sensor. As oxygen storage capacity decreases, the rear heated oxygen sensor switching frequency will increase.

When the frequency ratio of front heated oxygen sensor and rear heated oxygen sensor approaches a specified limit value, the three way catalyst malfunction is diagnosed.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0420 0702	 Three way catalyst does not operate properly. Three way catalyst does not have enough oxygen storage capacity. 	 Three way catalyst Exhaust tube Intake air leak Injectors Injector leak

OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the three way catalyst. During this check, a 1st trip DTC might not be confirmed.





- 1) Start engine and warm it up sufficiently.
- 2) Set "MANU TRIG" and "HI SPEED", then select "FR O2 SENSOR", "RR O2 SENSOR", "FR O2 MNTR", "RR O2 MNTR" in "DATA MONITOR" mode with CONSULT.
- 3) Touch "RECORD" on CONSULT screen with engine speed held at 2,000 rpm constant under no load.
- 4) Make sure that the switching frequency between "RICH" and "LEAN" of "RR O2 MNTR" is much less than that of "FR O2 MNTR".

Switching frequency ratio =

Rear heated oxygen sensor switching frequency


Front heated oxygen sensor switching frequency

This ratio should be less than 0.6 (2WD models) and 0.8 (4WD models).

If the ratio is greater than above, the three way catalyst is not operating properly.

OR ----

Three Way Catalyst Function (Cont'd)





1) Start engine and warm it up sufficiently.

2) Set voltmeter probes between ECM terminals (46) (front heated oxygen sensor signal) and (43) (engine ground), and ECM terminals (52) (rear heated oxygen sensor signal) and (43) (engine ground).

Keep engine speed at 2,000 rpm constant under no load.

4) Make sure that the voltage switching frequency (high & low) between ECM terminals ② and ③ is much less than that of ECM terminals ④ and ③.

Switching frequency ratio =

ire- EC

(G)

MA

LC

Rear heated oxygen sensor voltage switching frequency

Front heated oxygen sensor voltage switching frequency

CL

This ratio should be less than 0.6 (2WD models) and 0.8 (4WD models). If the ratio is greater than above, it means three way

MT

Note: If the voltage at terminal 46 does not switch periodically more than 5 times within 10 seconds at step 3, perform TROUBLE DIAGNOSIS FOR DTC P0130 (Front heated oxygen sensor) first. (See page EC-129.)

catalyst does not operate properly.

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL

||D)X

EC-187 327



Evaporative Emission (EVAP) Control System (Small Leak)

Note: If both DTC P0440 and P0446 are displayed, perform TROUBLE DIAGNOSIS FOR P0446 first. (See EC-207.)

MA

ON BOARD DIAGNOSIS LOGIC

This diagnosis uses two methods to detect leaks in the EVAP purge line.

The first method, the pressure test, makes use of vapor pressure in the fuel tank. The second method, the vacuum test, makes use of engine intake manifold vacuum.



Pressure test

The EVAP canister vent control valve is closed to shut the EVAP purge line. The vacuum cut valve bypass valve will then be opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP control system pressure sensor can now monitor the pressure inside the fuel tank.

If pressure increases, the ECM will check for leaks in the line between the vacuum cut valve and EVAP canister purge control valve. If no pressure does not increase, the ECM will perform the "Vacuum test".




CL

LC

Vacuum test

If pressure does not increase in the "Pressure test", the ECM will check for leaks in the line between the fuel tank and EVAP canister purge control valve, under the following "Vacuum test" conditions.

The vacuum cut valve bypass valve is opened to clear the line between the fuel tank and the EVAP canister purge control valve. The EVAP canister vent control valve will then be closed to shut the EVAP purge line off. The EVAP canister purge volume control valve and EVAP canister purge control valve are opened to depressurize the EVAP purge line using intake manifold vacuum. After this occurs, the EVAP canister purge control valve and EVAP canister purge volume control valve will be closed.



TF

PD

FA

BA

ST

RS

BT

EL,


EC-189 329

Evaporative Emission (EVAP) Control System (Small Leak) (Cont'd)

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0440 0705	EVAP control system has a leak. EVAP control system does not operate properly.	 Incorrect fuel tank vacuum relief valve Incorrect fuel filler cap used Fuel filler cap remains open or fails to close Foreign matter caught in fuel filler cap Leak is in line between intake manifold and EVAP canister purge control valve. Foreign matter caught in EVAP canister vent control valve. EVAP canister or fuel tank leaks EVAP purge line (pipe and rubber tube) leaks EVAP purge line rubber tube bent Biocked or bent rubber tube to EVAP control system pressure sensor Loose or disconnected rubber tube EVAP canister purge control valve EVAP canister purge control valve EVAP canister purge control solenoid valve Absolute pressure sensor Tank fuel temperature sensor MAP/BARO switch solenoid valve Blocked or bent rubber tube to MAP/BARO switch solenoid valve O-ring of EVAP canister vent control valve is missing or damaged

CAUTION:

- Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may come on.
- If the fuel filler cap is not tightened properly, the MIL may come on.
- Use only a genuine rubber tube as a replacement.





DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE





CAUTION:

- Always select "SINGLE TEST" with CONSULT when performing the "FUNCTION TEST".
- Perform "FUNCTION TEST" when the fuel level is less than 3/4 full. If not, inspect fuel filler cap and fuel tank separately. Refer to EC-193.
- Select "EVAP (SMALL LEAK)" in "FUNCTION TEST" mode with CONSULT.
- Make sure that "OK" is displayed with "EVAP (SMALL LEAK)". (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".)
- Check fuel filler cap and fuel tank when the fuel tank is more than 3/4 full.
 Refer to "DIAGNOSTIC PROCEDURE", EC-193.









Evaporative Emission (EVAP) Control System (GI) (Small Leak) (Cont'd) Start engine and warm it up sufficiently. Check voltage between ECM terminal 63 and ground MA Voltage: 1.9 - 4.2V Check voltage between ECM terminal (51) and ground. Voltage: 0.8 - 1.5V Perform the following procedure before the voltage drops below 0.8V. If the voltage drops below 0.8V, cool down the engine and perform the entire procedure over again. Check voltage between ECM terminal (28) and ground. EC Voltage: 1.9 - 4.1V Turn ignition switch "OFF" and wait at least 7 seconds. Turn ignition switch "ON" and wait at least 12 seconds. Restart engine and let it idle for at least 70 seconds. Maintain the following conditions for at least 40 seconds consecutively. GL Gear position: Suitable gear position Vehicle speed: 50 - 70 km/h (31 - 43 MPH) Engine speed: 1,500 - 2,500 rpm MT Decelerate the vehicle to 0 km/h and let engine idle. 10) Maintain the following conditions for at least 5 seconds consecutively. AT Gear position: "1" or "2" position Vehicle speed: 40 - 60 km/h (25 - 37 MPH) Engine speed: 1,500 - 2,500 rpm TE 11) Perform steps 9, 10 more than 10 times. 12) Decelerate the vehicle to 0 km/h and let engine idle. 13) Maintain the following condition for at least continuous PD 10 seconds. Gear position: Suitable gear position Vehicle speed: 40 - 80 km/h (25 - 50 MPH) Engine speed: 1,000 - 3,000 rpm 14) Decelerate the vehicle to 0 km/h and let engine idle, then wait at least 11 minutes. RA 15) Check voltage between ECM terminal 63 and ground (Voltage 2). Voltage: 1.9 - 4.2V BR 16) Check voltage decrease between voltage 1 and 2. Voltage 1 - Voltage 2 ≥ 0.1V 17) Check voltage between ECM terminal @ and ground ST (Voltage 3). Voltage: 0.3 - 0.7V 18) Maintain the following conditions for 9 minutes measuring voltage between ECM terminal 23 and ground (Volt-13\$ age 4) after 12 minutes have passed from restarting engine in step 7. BT Gear position: Suitable gear position Vehicle speed: 20 - 80 km/h (12 - 50 MPH) Engine speed: 800 - 2,200 rpm (A/T models)

Voltage 4 - Voltage 3 ≤ 0.5V (2WD M/T)

19) Stop the vehicle, turn ignition switch "OFF", wait at least

20) Perform "Diagnostic Test Mode II (Self-diagnostic

7 seconds, and then turn "ON".

results)" with ECM.

800 - 3,000 rpm (M/T models)

0.7V (2WD A/T) 0.8V (4WD) HA


[]

[DX

Evaporative Emission (EVAP) Control System (Small Leak) (Cont'd)


NOTE:


- Hold the accelerator pedal as steady as possible during driving in steps 8, 10, 13 and 18.
- If the driving conditions do not conform to those specified in steps 8, 10, 13 and 18, the procedure must be performed again under the specified conditions.
- It is better that the fuel level is low.
- While warming up the engine or idling it for more than 30 seconds, keep the engine hood open. Close the engine hood before driving the vehicle.



EC-193 333


MOIL








EC-195 335

IDX









Evaporative Emission (EVAP) Control System (Small Leak) (Cont'd) COMPONENT INSPECTION

EVAP canister purge volume control valve



- Disconnect EVAP canister purge volume control valve harness connector.
- 2. Check resistance between the following terminals. terminal ② and terminals ①, ③ terminal ⑤ and terminals ④, ⑥

Resistance:

Approximately 30Ω [At 25°C (77°F)]

- Reconnect EVAP canister purge volume control valve harness connector.
- 4. Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
 - (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5. Turn ignition switch "ON".
- Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.
 If NG, replace the EVAP canister purge volume control




- Disconnect EVAP canister purge volume control valve harness connector.
- 2. Check resistance between the following terminals. terminal ② and terminals ①, ③ terminal ⑤ and terminals ④, ⑥

- OR -

Resistance:

Approximately 30Ω [At 25°C (77°F)]

- Reconnect EVAP canister purge volume control valve harness connector.
- 4. Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
 - (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
 - If NG, replace the EVAP canister purge volume control valve




Evaporative Emission (EVAP) Control System (Small Leak) (Cont'd)


EVAP canister purge control solenoid valve


Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.







EVAP canister purge control valve

Check EVAP canister purge control valve as follows:

Plug the port B.

 Apply pressure [80.0 kPa (600 mmHg, 23.62 inHg, 11.60 psi)] to port (A). Then keep it for 15 seconds, and check there is no leakage.

Repeat step 2 for port ©.

EVAP canister vent control valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If NG, clean valve using air blower or replace as necessary. Make sure new O-ring is installed properly.

Absolute pressure sensor

- Remove absolute pressure sensor from bracket with its harness connector connected.
- 2. Remove hose from absolute pressure sensor.
- Turn ignition switch "ON" and check output voltage between terminal ② and engine ground.

The voltage should be 3.2 to 4.8 V.

Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg, -3.87 psi) to absolute pressure sensor as shown in figure and check the output voltage.

The voltage should be 1.0 to 1.4 V lower than the value measured in step 3.

GI

(Sile

MA

EM

LC

EC

312

CL

MT

TF

AT

(a)(a)

PD

FA

RA

BR

ST

RS

BT

...

HA

-1

EL


IDX


Evaporative Emission (EVAP) Control System (Small Leak) (Cont'd)


CAUTION:


Always calibrate the vacuum pump gauge when using it.

5. If NG, replace absolute pressure sensor.









MAP/BARO switch solenoid valve



- 1. Start engine and warm it up sufficiently.
- Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
- 3. Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
- 4. If NG, replace solenoid valve.



- 1. Remove MAP/BARO switch solenoid valve.
- 2. Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

3. If NG, replace solenoid valve.

Tank fuel temperature sensor

Check resistance by heating with hot water or heat gun as shown in the figure.

(Reference data)

Temperature °C (°F)	Resistance k Ω
20 (68)	2.3 - 2.7
50 (122)	0.79 - 0.90


If NG, replace tank fuel temperature sensor.

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve

MA

(H

SYSTEM DESCRIPTION



This system controls the vacuum signal applied to the EVAP canister purge control valve.

When the ECM detects any of the following conditions, current does not flow through the EVAP canister purge control solenoid valve.

The solenoid valve cuts the vacuum signal so that the EVAP canister purge control valve remains closed.

- Ignition switch "START"
- Closed throttle position
- Low or high engine coolant temperature
- During deceleration
- Engine stopped
- Low vehicle speed (M/T models)

AT

TF

PD

FA

BA

MT

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).


TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	
105	W/R	EVAP canister purge control solenoid valve	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)	

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.


MONITOR ITEM	CON	DITION	SPECIFICATION	
PURG CONT S/V ● Engine: After warming up	- Engine After warming up	Idle	OFF	ST
PORG CONT 5/V	Engine: After warming up	2,000 rpm	ON	
				RS

BR ST



EC-199

BT



COMPONENT DESCRIPTION

EVAP canister purge control solenoid valve


The EVAP canister purge control solenoid valve responds to signals from the ECM. When the ECM sends an OFF signal, the vacuum signal (from the intake manifold to the EVAP canister purge control valve) is cut.

When the ECM sends an ON (ground) signal, the vacuum signal passes through the EVAP canister purge control solenoid valve. The signal then opens the EVAP canister purge control valve.

副

339

[D]X




Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (Cont'd)

EVAP canister purge control valve

When the vacuum signal is cut by EVAP canister purge control solenoid valve, EVAP canister purge control valve closes.


EVAPORATIVE EMISSION SYSTEM DIAGRAM



Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	
P0443 0807	A) An improper voltage signal is sent to ECM through EVAP canister purge control solenoid valve.	 Harness or connectors (The EVAP canister purge control solenoid valve circuit is open or shorted.) EVAP canister purge control solenoid valve 	
	B) EVAP canister purge control valve does not operate properly (stuck open).	 EVAP canister purge control valve EVAP canister purge control solenoid valve Vacuum hoses for clogging or disconnection EVAP control system pressure sensor 	

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B" on next page.



Procedure for malfunction A



- 1) Turn ignition switch "ON"
- 2) Select "DATA MONITOR" mode with CONSULT.

OR

OR


Wait at least 5 seconds.



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.



- 1) Turn ignition switch "ON" and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.



Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (Cont'd)

Procedure for malfunction B



- 1) Lift up vehicle.
- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up sufficiently.
- 4) Check that tank fuel temperature is above 0°C (32°F).
- 5) Turn ignition switch "OFF" and wait at least 7 seconds.
- 6) Turn ignition switch "ON" and wait at least 12 seconds.
- 7) Start engine and let it idle for at least 70 seconds.
- Maintain the following conditions for at least 10 seconds.

Gear position:

"2" or "D" range (A/T)
"3rd" or "4th" gear (M/T)

Vehicle speed:


50 - 80 km/h (31 - 50 MPH)


Engine speed:

1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)





---- OR -

- 1) Lift up vehicle.
- 2) Turn ignition switch "ON" and select "MODE 1" with GST.
- Start engine and warm it up sufficiently.
- 5) Turn ignition switch "OFF" and wait at least 7 seconds.
- 6) Turn ignition switch "ON" and wait at least 12 seconds.
- 7) Start engine and let it idle for at least 70 seconds.
- Maintain the following conditions for at least 10 seconds.

Gear position:

"2" or "D" range (A/T)

"3rd" or "4th" gear (M/T)

Vehicle speed:

50 - 80 km/h (31 - 50 MPH)

Engine speed:

1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)

Select "MODE 7" with GST.

@1

MA

EM

EC

FE

CL

WIT

Ŕŝ


 $\mathbb{R}\mathbb{A}$

BR

BT

KA

EC-201 341



Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (Cont'd)

TOOLS

- 1) Lift up vehicle.
- 2) Start engine and warm it up sufficiently.
- 3) Check that voltage between ECM terminal 63 and ground is less than 4.2V.

 4) Turn ignition switch "OFF" and wait at least 7 seconds.

 5) Turn ignition switch "ON" and wait at least 12 seconds.

- 6) Start engine and let it idle for at least 70 seconds.
- 7) Maintain the following conditions for at least 10 seconds.

Gear position:

"2" or "D" range (A/T)

"3rd" or "4th" gear (M/T)

Vehicle speed:

50 - 80 km/h (31 - 50 MPH)

Engine speed:

1,500 - 2,500 rpm

Voltage between ECM terminal (51) and ground: More than 0.8V

- 8) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 9) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

W/B

W/B

B/W

W/R

CPC

1 2 3

56789

11 12 13 14

10

19

104 105 106

108

■ W/B 🔷 To EL-METER

EVAP CANISTER PURGE

CONTROL SOLENOID VALVE

(M₁₉)

Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (Cont'd)

EC-CANI/V-01

.



LC

GI.

MA

EC

FE

<u>GL</u>

MT

AT

ŢF

PD

FA

RA

BR

ST

RS

BT

HA

IDX

AEC310A

EC-203

42 43

24 25 26 27 28 29 30 31 32 33 44 45 46 57 58 59 60 47 48 62 63 64 65

61


70


(M112)

ECM (ECCS CONTROL MODULE)


M112

343





EC-205 345




Evaporative Emission (EVAP) Canister Purge Control Valve/Solenoid Valve (Cont'd) COMPONENT INSPECTION

EVAP canister purge control solenoid valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals	Yes	No
No supply	No	Yes


If NG, replace solenoid valve.




EVAP canister purge control valve

Check EVAP canister purge control valve as follows.

- 1. Plug the port B.
- 2. Apply pressure [80.0 kPa (600 mmHg, 23.62 inHg, 11.60 psi)] to port (a). Then keep it for 15 seconds, and check there is no leakage.
- 3. Repeat step 2 for port ©.





Evaporative Emission (EVAP) Canister Vent Control Valve

Note: If both DTC P0440 and P0446 are displayed, perform TROUBLE DIAGNOSIS FOR P0446 first.

COMPONENT DESCRIPTION

The EVAP canister vent control valve is located on the EVAP canister and is used to seal the canister vent.

This solenoid (the EVAP canister vent control valve) responds to signals from the ECM.

When the ECM sends an ON signal, the coil in the solenoid valve is energized.

A plunger will then move to seal the canister vent. The ability to seal the vent is necessary for the on board diagnosis of other evaporative loss system components.

This solenoid valve is used only for diagnosis, and usually remains opened.

When the vent is closed, under normal purge conditions, the evaporative loss system is depressurized and allows "EVAP Control System (Small Leak)" diagnosis.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (4) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
108	R	EVAP canister vent control valve	Ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values

MONITOR ITEM	CONDITION	SPECIFICATION
VENT CONT/V	Ignition switch: ON	OFF

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	ST
P0446 0903	An improper voltage signal is sent to ECM through EVAP canister vent control valve.	 Harness or connectors (EVAP canister vent control valve circuit is open or shorted.) 	RS
	B) EVAP canister vent control valve does not operate properly.	EVAP canister vent control valve EVAP control system pressure sensor Blocked rubber tube to EVAP canister vent control	T
		valve	HA

EC-207 347

(GI

MiA

EM

LC

EC

FE

MT

AT

TF

PD

FA

RA

BR

鳳

Evaporative Emission (EVAP) Canister Vent Control Valve (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A". If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B" on next page.

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.

- OR -

3) Start engine and wait at least 5 seconds.




- 1) Start engine and wait at least 5 seconds.
- 2) Select "MODE 7" with GST.

- OR -



- 1) Start engine and wait at least 5 seconds.
- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EVAP canister vent control valve circuit. During this check, a 1st trip DTC might not be confirmed.

Procedure for malfunction B

- Remove EVAP canister vent control valve from EVAP canister and disconnect hoses from the valve.
- 2) Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals (1) and (2)	No
No supply	Yes

Make sure new O-ring is installed properly.

9

B/W

108

CDCV

EVAP CANISTER VENT CONTROL VALVE

®

Evaporative Emission (EVAP) Canister Vent Control Valve (Cont'd)

EC-VENT/V-01



EC

GI

MA

ME

LC

FE

C:L

MT

AT

PD)

TE

FA

RA

BR

. ST

RS

BT

HA

IDX


3 4 5 6 7 8 M109 9 10 11 12 13 14 W 20 21 22 23 24 25 26 27 28 29 30 31 32 33 1 2 3 4 102 103 104 105 106 5 6 7 8 9 11112 13 14 15 16 17 18 10 44 45 46 57 58 59 60 61 42 43 (M112) 107 108 109 110 111 112 49 50 19 70 116 117 118 51 52 66 67 68 69


(112) (B)

AEC311A

ECM (ECCS CONTROL MODULE)

(M112)





Evaporative Emission (EVAP) Canister Vent Control Valve (Cont'd) COMPONENT INSPECTION

G[

MA

EM

LC

EC

FE

Œ[_

MT

AT

TF

FA

 $\mathbb{R}\mathbb{A}$

88

RS

BT

 $\mathbb{H}\mathbb{A}$


EL.

EVAP canister vent control valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals 1 and 2	No
No supply	Yes

If NG, clean valve using air blower or replace as necessary. Make sure new O-ring is installed properly.



EVAP control system pressure sensor

- Remove EVAP control system pressure sensor with its harness connector connected.
- 2. Remove hose from EVAP control system pressure sensor.
- Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
- Check output voltage between terminal ② and engine ground.


Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg, 0 psi)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg, -1.35 psi)	0.4 - 0.6

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace EVAP control system pressure sensor.

EC-211 351



4.5 A 4 eb 3.5 pt 3.5 pt 3.5 0 0.5 0 -9.3 (-70, -2.76, -1.35) (+30, +1.18, +0.58) Pressure kPa (mmHg, inHg, psi) (Relative to atmospheric pressure) SEF954S

Evaporative Emission (EVAP) Control System Pressure Sensor

COMPONENT DESCRIPTION

The EVAP control system pressure sensor detects pressure in the purge line. The sensor output voltage to the ECM increases as pressure increases. The EVAP control system pressure sensor is not used to control the engine system. It is used only for on board diagnosis.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
49	Р	Sensors' power supply	[Ignition switch "ON"]	Approximately 5V
50	B/G	Sensors' ground	Engine is running. (Warm-up condition) Idle speed	0.001 - 0.02V
67	L	EVAP control system pressure sensor	Ignition switch "ON"	Approximately 3.4V


CONSULT REFERENCE VALUE IN DATA MONITOR MODE


Specification data are reference values

MONITOR ITEM	CONDITION	SPECIFICATION
EVAP SYS PRES	Ignition switch: ON	Approx. 3.4V

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0450 0704	 An improper voltage signal from EVAP control system pressure sensor is sent to ECM. 	 Harness or connectors (The EVAP control system pressure sensor circuit is open or shorted.) EVAP control system pressure sensor EVAP canister vent control valve (The valve is stuck open.)





Evaporative Emission (EVAP) Control System G Pressure Sensor (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE** MA 1) Start engine and warm it up sufficiently. Check that tank fuel temperature is above 0°C (32°F). EM

Turn ignition switch "OFF" and wait at least 7 seconds. Turn ignition switch "ON". 4)

Select "DATA MONITOR" mode with CONSULT.

Wait at least 5 seconds.

· OR · Start engine and warm it up sufficiently. Check that voltage between ECM terminal 63 and

ground is less than 4.2V. Turn ignition switch "OFF" and wait at least 7 seconds.

Turn ignition switch "ON" and wait at least 5 seconds.

Select "MODE 7" with GST.

Start engine and warm it up sufficiently. 1) Check that voltage between ECM terminal @ and ground is less than 4.2V.

Turn ignition switch "OFF" and wait at least 7 seconds.

4) Turn ignition switch "ON" and wait at least 5 seconds. 5) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".

6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

LC

EC

FE

CL

MT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS


BT


HA


킲

IIDX(


Evaporative Emission (EVAP) Control System Pressure Sensor (Cont'd)








Evaporative Emission (EVAP) Control System Pressure Sensor (Cont'd)





COMPONENT INSPECTION

EVAP control system pressure sensor


- Remove EVAP control system pressure sensor with its harness connector connected.
- 2. Remove hose from EVAP control system pressure sensor.
- Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
- Check output voltage between terminal (2) and engine ground.

Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg, 0 psi)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg, -1.35 psi)	0.4 - 0.6

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace EVAP control system pressure sensor.



Vehicle Speed Sensor (VSS)

COMPONENT DESCRIPTION

The vehicle speed sensor is installed in the transmission. It contains a pulse generator which provides a vehicle speed signal to the speedometer. The speedometer then sends a signal to the ECM.

MA

(G1)

LC

EC

FE

CL

MT

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (a) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
26	W/L	Vehicle speed sensor	Engine is running. Slowly rotating front wheels	Approximately 1.8 - 2.4V* (AC voltage)

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ON BOARD DIAGNOSIS LOGIC

OIT DOAILE	DIAGNOOIO EGGIO	<u> </u>	AT
Diagnostic Trouble Code No.	Malfunction is detected when	Check items (Possible cause)	ŢŢ
P0500 0104	 The almost 0 km/h (0 MPH) signal from the vehicle speed sensor is sent to ECM even when the vehicle is driving. 	 Harness or connector (The vehicle speed sensor circuit is open or shorted.) Vehicle speed sensor 	PD

PD

FA

RA

BR


ST


RS


BT

HA

IDX







Vehicle Speed Sensor (VSS) (Cont'd) **OVERALL FUNCTION CHECK**

Use this procedure to check the overall function of vehicle speed sensor circuit. During this check, a 1st trip DTC might not be con-

1) Jack up drive wheels.



- 2) Start engine.
- Perform "VEHICLE SPEED SEN CKT" in "FUNCTION TEST" mode with CONSULT.

— OR -



- Start engine.
- Read vehicle speed sensor signal in "DATA MONITOR" mode with CONSULT.

The vehicle speed on CONSULT should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

OR -



- Jack up drive wheels.
- Start engine.
- 3) Read vehicle speed sensor signal in "MODE 1" with

The vehicle speed on GST should be able to exceed 10 km/h (6 MPH) when rotating wheels with suitable gear position.

– OR –

DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE**



- 1) Start engine and warm it up sufficiently.
- Perform test drive for at least 10 seconds continuously in the following recommended condition.

Engine speed

: 1,400 - 2,500 rpm (A/T models) 1,700 - 2,600 rpm (2WD M/T

models)

1,850 - 2,850 rpm (4WD M/T

models)

Intake

manifold vacuum: (A/T models) -53.3 to -33.3

kPa

(-400 to -250 mmHg, -15.75 to -9.84 inHg, -7.73 to -4.83

(M/T models) -46.7 to -32.0

(-350 to -240 mmHg, -13.78

to -9.45 inHg, -6.77 to -4.64

psi)

Gear position


: Suitable position (except "N" or

"P" position)

- 3) Stop the vehicle, turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Even though 1st trip DTC is not detected, perform the above test drive at least one more time.

Vehicle Speed Sensor (VSS) (Cont'd) Œ[EC-VSS-01 IGNITION SWITCH ON or START MA Refer to "EL-POWER". 11 : Detectable line for DTC : Non-detectable line for DTC LC JOINT CONNECTOR-2 (M142) EC W/B - 20 19 - W/B W/B Æ (N_1) W/B GL COMBINATION METER (SPEEDOMETER) (M155) (N1) B **=** 21 MT N4, N5, N7 **SPEEDOMETER** AT W/L TE JOINT CONNECTOR-2 酌 (M142) w.L C16 W/L FA RA W/L 26 2 ECM (ECCS CONTROL MODULE) VEHICLE VSF BR SPEED SENSOR (E16) ST Refer to last page (Foldout page). RS M155 , N1 BT HA 44 45 46 57 58 59 60 5 6 7 8 9 10 42 61 108 109 110 1**1**2 19 47 48 62 63 64 65 49 50 70 34 35 36 37 IDX



EC-220

360

(GII Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve MA SYSTEM DESCRIPTION Engine speed Camshaft position sensor Amount of intake air Mass air flow sensor LC Engine coolant temperature Engine coolant temperature sensor EC Start signal Ignition switch FE Throttle position **ECM** Throttle position sensor (ECCS CL control IACV-AAC valve module) Park/Neutral position Inhibitor switch (A/T models)/ Neutral position switch (M/T models) Mï Air conditioner operation Air conditioner switch AT Power steering load signal Power steering oil pressure switch TF Battery voltage Battery (D) Vehicle speed Vehicle speed sensor

This system automatically controls engine idle speed to a specified level. Idle speed is controlled through fine adjustment of the amount of air which by-passes the throttle valve via IACV-AAC valve. The IACV-AAC valve repeats ON/OFF operation according to the signal sent from the ECM. The camshaft position sensor detects the actual engine speed and sends a signal to the ECM. The ECM then controls the ON/OFF time of the IACV-AAC valve so that engine speed coincides with the target value memorized in ECM. The target engine speed is the lowest speed at which the engine can operate steadily. The optimum value stored in the ECM is determined by taking into consideration various engine conditions, such as during warm up, deceleration, and engine load (air conditioner and power steering operation).

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
101 W/	W/G IACV-AAC valve		Ignition switch "ON".	BATTERY VOLTAGE (11 - 14V)
		Engine is running. (Warm-up condition) Engine speed is 2,000 rpm	0 - 7V	

EC-221 361

FA

32

RS

BT

HA

EL


 $\mathbb{D}X$

Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (Cont'd)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONE	NOITION	SPECIFICATION
	Engine: After warming upAir conditioner switch: OFF	Idle	20 - 40%
IACV-AAC/V	● Shift lever "N" ● No-load	2,000 rpm	




COMPONENT DESCRIPTION

IACV-ACC valve

The IACV-AAC valve is moved by ON/OFF pulses from the ECM. The longer the ON pulse, the greater the amount of air that will flow through the valve. The more air that flows through the valve, the higher the idle speed.

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
P0505 0205	A) The IACV-AAC valve does not operate properly.	Harness or connectors (The IACV-AAC valve circuit is open.) IACV-AAC valve
	B) The IACV-AAC valve does not operate properly.	Harness or connectors (The IACV-AAC valve circuit is shorted.) IACV-AAC valve



DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE**

Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B".

Procedure for malfunction A



- Turn ignition switch "ON".
- Select "DATA MONITOR" mode with CONSULT.

- OR -


– OR -

Start engine and run it for at least 2 seconds at idle speed.



- 1) Start engine and run it for at least 2 seconds at idle speed.
- 2) Select "MODE 7" with GST.

- 1) Start engine and run it for at least 2 seconds at idle
- 2) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.



Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (Cont'd)

Procedure for malfunction B



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
- 4) Start engine and run it for at least 1 minute at idle speed.

– OR –

LC

G

MA

- GST
- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Start engine again and run it for at least 1 minute at idle speed.

4) Select "MODE 7" with GST.

FĒ

Cl

EC



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Start engine again and run it for at least 1 minute at idle speed.
- Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

EC-223 363

AT

PD

RA

凮

BR

ST

RS


BT


HA

El,


Idle Air Control Valve (IACV) — Auxiliary Air Control (AAC) Valve (Cont'd)


EC-AAC/V-01












EC-225

SEF339S



Closed Throttle Position Switch

COMPONENT DESCRIPTION

A closed throttle position switch and wide open throttle position switch are built into the throttle position sensor unit. The wide open throttle position switch is used only for A/T control.

When the throttle valve is in the closed position, the closed throttle position switch sends a voltage signal to the ECM. The ECM only uses this signal to open or close the EVAP canister purge control valve when the throttle position sensor is malfunctioning.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
27 Y	.	, Throttle position switch	Ignition switch "ON" (Warm-up condition) Accelerator pedal released	BATTERY VOLTAGE (11 - 14V)
<i>2.1</i>		(Closed position)	Ignition switch "ON" Accelerator pedal depressed	Approximately 0V


CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
CLSD THL/P SW	Ignition switch: ON	Throttle valve: Idle position	ON
CLSD INL/P SW	(Engine stopped)	Throttle valve: Slightly open	OFF

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P0510 0203	 Battery voltage from the closed throttle position switch is sent to ECM with the throttle valve opened. 	 Harness or connectors. (The closed throttle position switch circuit is shorted.) Closed throttle position switch.



OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the closed throttle position switch circuit. During this check, a 1st trip DTC might not be confirmed.

1) Start engine and warm it up sufficiently.


2) Check the voltage between ECM terminal ② and ground under the following conditions.

At idle: Battery voltage


At 2,000 rpm: Approximately 0V

Closed Throttle Position Switch (Cont'd)

EC-TP/SW-01



4 5 6 GY



27

IDLE

ECM (ECCS CONTROL

MODULE)

AEC057A

@[

MA

LC

EC

FE

ĈL.

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST


RS

BT

HA

IDX





Closed Throttle Position Switch (Cont'd) COMPONENT INSPECTION

Closed throttle position switch

Start engine and warm it up sufficiently.

Turn ignition switch "OFF". 2.

Disconnect throttle position switch harness connector. 3.

Check continuity between terminals 5 and 6 while opening throttle valve manually.

Throttle valve conditions	Continuity
Completely closed	Yes
Partially open or completely open	No

If NG, replace throttle position switch.

(H)

MA

LC

EC

Æ

CL

MT

AT

TF

PD

FA

RA

BR


ST

RS

BŢ

HA

IDX



Engine Control Module (ECM)-ECCS Control Module

COMPONENT DESCRIPTION

The ECM consists of a microcomputer, diagnostic test mode selector, and connectors for signal input and output and for power supply. The unit controls the engine.

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
P0605 0301	● ECM calculation function is malfunctioning.	● ECM (ECCS control module)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine.
- 4) Run engine for at least 2 seconds at idle speed.

- OR -




- 1) Turn ignition switch "ON".
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.
- 4) Select "Mode 7" with GST.


– OR -




- 1) Turn ignition switch "ON".
- 2) Start engine and wait at least 2 seconds.
- 3) Turn ignition switch "OFF" and wait at least 7 seconds.
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

DIAGNOSTIC PROCEDURE





EC-231 371



Park/Neutral Position Switch

COMPONENT DESCRIPTION

When the gear position is "P" (A/T models only) or "N", park/ neutral position is "ON".

ECM detects the position because the continuity of the line (the "ON" signal) exists.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
22	L/B	Neutral position switch (M/T models) Inhibitor switch (A/T mod-	Ignition switch "ON" Gear position is "Neutral position" (M/T models) Gear position is "N" or "P" (A/T models)	Approximately 0V
		els)	Ignition switch "ON" Except the above gear position	Approximately 5V


CONSULT REFERENCE VALUE IN DATA MONITOR MODE


Specification data are reference values


MONITOR ITEM	CONDITION		SPECIFICATION
DAL DOCLOW	■ Ignition switch: ON	Shift lever "P" or "N"	ON
P/N POSI SW		Except above	OFF

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)
P0705 1003	 The signal of the park/neutral position switch is not changed in the process of engine starting and driving. 	 Harness or connectors (The neutral position switch or inhibitor switch circuit is open or shorted.) Neutral position switch (M/T models) Inhibitor switch (A/T models)







Park/Neutral Position Switch (Cont'd) **OVERALL FUNCTION CHECK**

Use this procedure to check the overall function of the park/neutral position switch circuit. During this check, a 1st trip DTC might not be confirmed.



1) Turn ignition switch "ON".

2) Perform "PARK/NEUT POSI SW CKT" in "FUNCTION TEST" mode with CONSULT.

Select "P/N POSI SW" in "DATA MONITOR" mode with CONSULT.

Check the "P/N POSI SW" signal under the following conditions.

Condition (Gear position)	Known good signal
"N" and "P" (A/T only) position	ON
Except the above position	OFF

- OR -

Turn ignition switch "ON".

Check voltage between ECM terminal (2) and body ground under the following conditions.

Condition (Gear position)	Voltage (V) (Known good data)
"N" and "P" (A/T only) position	Approx. 0
Except the above position	Approx. 5

G[

 $\mathbb{M}\mathbb{A}$

EC

FE

CL

MT

AT

TF

PD)

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

BT


MA


EL


1DX


Park/Neutral Position Switch (Cont'd)

EC-PNP/SW-01










EC-235 375


EL

IDX



Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve

SYSTEM DESCRIPTION



This system allows the absolute pressure sensor to monitor either ambient barometric pressure or intake manifold pressure. The MAP/BARO switch solenoid valve switches between two passages by ON-OFF pulse signals from the ECM. (One passage is from the intake air duct, the other is from the intake manifold.) Either ambient barometric pressure or intake manifold pressure is applied to the absolute pressure sensor.

 Ignition switch is "ON". (Engine is not running.) For 5 seconds after starting engine or More than 5 minutes after the solenoid valve shuts OFF. and Throttle valve is shut or almost fully shut for more than 5 seconds and Vehicle speed is less than 100 km/h (62 	Solenoid	Conditions			
 For 5 seconds after starting engine or More than 5 minutes after the solenoid valve shuts OFF. and Throttle valve is shut or almost fully shut for more than 5 seconds and 					
More than 5 minutes after the solenoid valve shuts OFF. and Throttle valve is shut or almost fully shut for more than 5 seconds and		1 3,			
shuts OFF. and Throttle valve is shut or almost fully shut for more than 5 seconds and		or			
and ● Throttle valve is shut or almost fully shut for more than 5 seconds and	.				
more than 5 seconds and	'IN	and			
and		Throttle valve is shut or almost fully shut for			
		more than 5 seconds			
 Vehicle speed is less than 100 km/h (62 		and			
MPH).		1			

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (3) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
116	W/R	MAP/BARO switch sole- noid valve	Ignition switch "ON" Engine is running. Idle speed (More than 5 seconds after starting engine)	0 - 1V BATTERY VOLTAGE (11 - 14V)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION	Œ
MAP/BARO SW/V	● Ignition switch: ON	BARO	u u
	Engine speed: Idle (More than 5 seconds after starting engine)	MAP	闾

EC-237 377

GI

EM

MA

LC

EC

FE

GL,

RA

ST

BR


RS

BT

AIF

餌.

1DX




Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (Cont'd)

COMPONENT DESCRIPTION

The MAP/BARO switch solenoid valve switches its air flow passage according to the voltage signal sent from the ECM. When voltage is supplied from the ECM, the MAP/BARO switch solenoid turns "ON". Then, the absolute pressure sensor can monitor the ambient barometric pressure. When voltage is not supplied from the ECM, the MAP/BARO switch solenoid valve turns "OFF". Then, the sensor monitors intake manifold pressure.

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1105 1302	 MAP/BARO switch solenoid valve receives the voltage supplied though ECM does not supply the voltage to the valve. There is little difference between MAP/BARO switch solenoid valve input voltage at ambient barometric pressure and voltage at intake manifold pressure. 	 Harness or connectors (MAP/BARO switch solenoid valve circuit is open or shorted.) Hoses (Hoses are clogged or disconnected.) Absolute pressure sensor MAP/BARO switch solenoid valve



378

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- 4) Start engine and let it idle.
- 5) Wait at least 15 seconds.

OR ·



- Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Start engine and let it idle.
- 4) Wait at least 15 seconds.
- 5) Select "MODE 7" with GST.

- OR -



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Start engine and let it idle.
- 4) Wait at least 15 seconds.
- 5) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (Cont'd)

GI

MA

EM

LC

EC

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


MA

EL


IDX




12 M25 B





AEC314A






EC-241 381







Manifold Absolute Pressure (MAP)/Barometric Pressure (BARO) Switch Solenoid Valve (Cont'd)

COMPONENT INSPECTION

MAP/BARO switch solenoid valve



- 1. Start engine and warm it up sufficiently.
- 2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
- 3. Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
- 4. If NG, replace solenoid valve.



1. Remove MAP/BARO switch solenoid valve.

- OR -


2. Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)		
12V direct current supply between terminals ① and ②	Yes	No		
No supply	No	Yes		

3. If NG, replace solenoid valve.

Swirl Control Valve Control Solenoid Valve

SYSTEM DESCRIPTION



This system has a swirl control valve in the intake passage of each cylinder.

While idling and during low engine speed operation, the swirl control valve closes. Thus the velocity of the air in the intake passage increases, promoting the vaporization of the fuel and producing a swirl in the combustion chamber.

Because of this operation, this system tends to increase the burning speed of the gas mixture. improve fuel consumption, and increase the stability in running conditions.

Also, except when idling and during low engine speed operation, this system opens the swirl control valve. In this condition, this system tends to increase power by improving intake efficiency via reduction of intake flow resistance, intake flow,

The solenoid valve controls swirl control valve's shut/open condition. This solenoid valve is operated by the ECM.

Throttle position switch	Engine speed	Swirl control valve control solenoid valve	Swirl control valve
ON	Below 3,600 rpm	ON	Closed
OFF	Less than 3,200 rpm	ON	Closed
UFF	More than 4,000 rpm	OFF	Open

When engine coolant temperature is below 0°C (32°F) swirl control valve is kept open.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (3) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	BR
111	GY	Swirl control valve control	Engine is running. Idle speed	0 - 1V	ST
111	Gi	solenoid valve	Engine is running. Engine speed is above 3,600 rpm.	BATTERY VOLTAGE (11 - 14V)	R\$

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values

оростоанот ча	a dio loronos valdos.		
MONITOR ITEM	CONDITION	SPECIFICATION	[#]/
SWRL CONT S/V	• Engine is running at a speed of less than 3,600 rpm.	ON	
SYNL CONT 5/V	Except above	OFF	<u> </u>

EC-243 383

9

FE

MT

ÆΤ

TF


PD)

KA.

RA

BT

[D)X



Swirl Control Valve Control Solenoid Valve (Cont'd)

COMPONENT DESCRIPTION


Swirl control valve control solenoid valve

The swirl control valve control solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the solenoid valve is bypassed to apply intake manifold vacuum to the swirl control valve actuator. This operation closes the swirl control valve. When the ECM sends an OFF signal, the vacuum signal is cut and the swirl control valve opens.

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1130 1004	A) An improper voltage signal is sent to ECM through swirl control valve control solenoid valve.	Harness or connectors (The swirl control valve control solenoid valve circuit is open or shorted.)
	B) The vacuum signal is not sent to swirl control valve under specified driving conditions, even though swirl control valve control solenoid valve is ON.	 Harness or connector (The swirl control valve control solenoid valve circuit is open.) Swirl control valve control solenoid valve Intake system (Intake air leaks) Hoses Swirl control valve Swirl control valve control vacuum check switch One-way valve Vacuum tank
	C) The vacuum signal is sent to swirl control valve even though swirl control valve control solenoid valve is OFF.	 Harness or connector (The swirl control valve control solenoid valve circuit is shorted.) Blocked vacuum pipe or hose Swirl control valve control solenoid valve

Note: If DTC P1130 (1004) and P1165 (0112) are displayed, first perform TROUBLE DIAGNOSIS FOR DTC P1165 (0112). (See EC-251.)



DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B and C".

Procedure for malfunction A



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Wait at least 5 seconds.

•	v	v	v		•	• •	•	•	
				1	٦	г	5		

Swirl Control Valve Control Solenoid Valve (Cont'd)



1) Turn ignition switch "ON" and wait at least 5 seconds.

- OR -

Select "MODE 7" with GST.

MA


@[



- Turn ignition switch "ON" and wait at least 5 seconds.
- Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

LC.

国MI



Procedure for malfunction B



- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
- Start engine and run it for at least 20 seconds at idle speed.

- OR -



- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- Start engine again and run it for at least 20 seconds at idle speed.
- Select "MODE 7" with GST.

- OR *-*



- 1) Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds. 2)
- Start engine and run it for at least 20 seconds at idle speed.
- Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

☆ MONITOR ☆ NO FAIL CMPS-RPM(REF) 3800rpm COOLAN TEMP/S 85°C RECORD SEF720T

Procedure for malfunction C



- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds. Turn ignition switch "ON" again and select "DATA MONITOR" mode with CONSULT.
- Start engine and run it for at least 20 seconds at 3,800 rpm under no load.



- Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds. 2)

OR -

- Start engine and run it for at least 20 seconds at 3,800 rpm under no load.
- Select "MODE 7" with GST.

OR -



- 1) Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- Start engine and run it for at least 20 seconds at 3,800 rpm under no load.
- 4) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

EC

CL

MT

ΑT

RA

RS


BT

HA.


EL,


IDX


Swirl Control Valve Control Solenoid Valve (Cont'd)

















MEC488B

Swirl Control Valve Control Solenoid Valve (Cont'd)

COMPONENT INSPECTION

Swirl control valve

Supply vacuum to actuator and check swirl control valve operation.


Condition	Swirl control valve
Supply vacuum to actuator	Close
No supply	Open


Swirl control valve control solenoid valve

Check solenoid valve air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.





One-way valve

Check one-way valve air passage continuity.

Condition	Air passage continuity
Blow air from side B to A	Yes
Blow air from side A to B	No

If NG, replace one-way valve.

Vacuum tank

Check vacuum tank leakage.

Apply vacuum -80.0 kPa (-600 mmHg, -23.62 inHg, -11.60 psi). Then keep it for 10 seconds and check there is no leakage.

EC-249 389

EC

G!

MA

EM

LC

Æ

CL

Μť

AT.

TF

PD)

FA

 $\mathbb{R}\mathbb{A}$

BR

ST.


RS

BT

MA

El,

DX




Swirl Control Valve Control Solenoid Valve (Cont'd)

Swirl control valve control vacuum check switch

- Disconnect swirl control valve control vacuum check switch harness connector.
- 2. Use vacuum pump to apply vacuum to swirl control valve control vacuum check switch as shown in figure.
- 3. Start engine.
- Check voltage between terminal ② and engine ground with CONSULT or tester.

Pressure	Voltage (V)
More than -18.7 kPa (-140 mmHg, -5.51 inHg)	Engine ground
18.7 to22.7 kPa (-140 to170 mmHg, 5.51 to6.69 inHg)	Engine ground or Approx. 4.8
Less than -22.7 kPa (-170 mmHg, -6.69 inHg)	Approx. 4.8

^{5.} If NG, replace swirl control valve control vacuum check switch.



Swirl Control Valve Control Vacuum Check Switch

COMPONENT DESCRIPTION

The swirl control valve control vacuum check switch detects vacuum signal to the swirl control valve, and sends "ON" or "OFF" signal to the ECM.

When vacuum is supplied to the valve, the swirl control valve control vacuum check switch sends "OFF" signal to the ECM.

The swirl control valve control vacuum check switch is not used to

The swirl control valve control vacuum check switch is not used to control the engine system, it is used for on board diagnosis.

EC

FE

CL

MT

AT

TE

PD

FA

 $\mathbb{R}\mathbb{A}$

38

ST

RS

BT

HA

IL

(GII

MA

EM

lC

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
32	R/Y	Swirl control valve control	Engine is running. Engine speed is above 3,600 rpm.	ov
32	FV Y	vacuum check switch	Engine is running. Engine speed is less than 3,600 rpm.	Approximately 4.8V

ON BOARD DIAGNOSIS LOGIC


Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible cause)	
P1165 0112	The swirl control valve control vacuum check switch remains "OFF" under specified engine conditions.	Harness or connectors (Swirl control valve control vacuum check switch circuit is open.)	į
		Hoses (Hoses are connected incorrectly.) Swirl control valve control solenoid valve Swirl control valve control vacuum check switch	

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
SWL CON VC SW En	 Engine is running at a speed of less than 3,600 rpm. 	OFF
SWL CON VC SW	Except above	ON

IDX



Swirl Control Valve Control Vacuum Check Switch (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE**



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Turn ignition switch "ON".
- 4) Select "DATA MONITOR" mode with CONSULT.

- OR -

5) Start engine and run it for at least 5 seconds at 3,800 rpm under no load.



- 1) Start engine and warm it up sufficiently.
- Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Start engine and run it for at least 5 seconds at 3,800 rpm under no load.
- 4) Select "MODE 7" with GST.


- OR -



- 1) Start engine and warm it up sufficiently.
- 2) Turn ignition switch "OFF" and wait at least 7 seconds.
- 3) Turn ignition switch "ON".
- 4) Start engine and run it for at least 5 seconds at 3,800 rpm under no load.
- 5) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Swirl Control Valve Control Vacuum Check Gi Switch (Cont'd) EC-S/VCSW-01 MA ECM (ECCS CONTROL MODULE) S/VCSW (M112) 32 R/Y ■ : Detectable line for DTC : Non-detectable line for DTC [C EC FE CL SWIRL CONTROL VALVE CONTROL MT VACUUM CHECK SWITCH OFF (M39) AT Б TF PD FA RA BR SŢ RS BT HA 40 41 102 5 6 7 8 9 11 12 13 14 15 16 17 18 44 45 46 57 58 59 60 47 48 62 63 64 65 51 52 66 67 68 69 24 25 26 27 28 10 42 43 61 (M112) 112 109 108 19 49 50 IDX

AEC061A



Swirl Control Valve Control Vacuum Check Switch (Cont'd) Check ECM pin terminals for damage and check the connection of ECM harness connector. Reconnect ECM harness connector and retest.

ĒM

(G)

MA

INSPECTION END

Swirl control valve control vacuum check switch Vacuum pump

COMPONENT INSPECTION

Swirl control valve control vacuum check switch

1. Use vacuum pump to apply vacuum to swirl control valve control vacuum check switch as shown in figure.


2. Start engine.

SEF378S

3. Check voltage between terminal ② and engine ground with CONSULT or tester.

Pressure	Voltage (V)
More than -18.7 kPa (-140 mmHg, -5.51 inHg)	Engine ground
~18.7 to ~22.7 kPa (-140 to -170 mmHg, -5.51 to -6.69 inHg)	Engine ground or Approx. 4.8
Less than -22.7 kPa (-170 mmHg, -6.69 inHg)	Approx. 4.8

4. If NG, replace swirl control valve control vacuum check switch.



Swirl control valve control solenoid valve

Check solenoid valve air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals ① and ②	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.

EC-255 395

EC

_

CL.

MT

AT

7[5

RA

FA

28

ST


R\$ -

BT

出為

EL

ľDX



Ignition Signal

COMPONENT DESCRIPTION

Ignition coil & power transistor (Built into distributor)

The ignition signal from the ECM is sent to and amplified by the power transistor. The power transistor turns on and off the ignition coil primary circuit. This on-off operation induces the proper high voltage in the coil secondary circuit.

ECM TERMINALS AND REFERENCE VALUE


Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
1	w	Ignition signal	Engine is running. Idle speed	0.3 - 0.6V*
, 	i ginuon signai	Engine is running. Engine speed is 2,000 rpm	Approximately 0.8V*	
2	W/G	Ignition check	Engine is running. Idle speed	Approximately 12V*
3	W	Tachometer	Engine is running. Idle speed	Approximately 0.9V*

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1320 0201	The ignition signal in the primary circuit is not sent during engine cranking or running.	 Harness or connectors (The ignition primary circuit is open or shorted.) Power transistor Resistor Camshaft position sensor Camshaft position sensor circuit



Ignition Signal (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE

Note: If both DTC P0340 (0101) and P1320 (0201) are displayed, perform TROUBLE DIAGNOSIS FOR DTC P0340 first. (See EC-171.)



- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)

 OR



- 1) Turn ignition switch "ON".
- 2) Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
- 3) Select MODE 7 with GST.





-) Turn ignition switch "ON".
- Start engine. (If engine does not run, turn ignition switch to "START" for at least 5 seconds.)
- 3) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

EC-257 397

LC

MA

G[

EC

FE

CL

MT

2000

AT

TF

PD

FA

RA

BR

©T


RS


BT

MA


]DX


Ignition Signal (Cont'd)








EC-259 399











Ignition Signal (Cont'd) COMPONENT INSPECTION

Ignition coil

- 1. Disconnect ignition coil harness connector.
- 2. Remove distributor cap.
- 3. Check resistance as shown in the figure.

Terminal	Resistance [at 25°C (77°F)]
7 - 8	Less than 1Ω
⑦ - ⑨	7 - 13 kΩ

If NG, replace distributor assembly.

Power transistor

- 1. Disconnect camshaft position sensor & power transistor harness connector and ignition coil harness connector.
- Check power transistor resistance between terminals (2) and (8).

Terminals	Resistance	Result
② and ⑧	Except 0Ω	ок
2 and 0	0Ω	NG

If NG, replace distributor assembly.

Resistor

- . Disconnect resistor harness connector.
- 2. Check resistance between terminals 1 and 2. Resistance: Approximately 2.2 k Ω If NG, replace resistor.

Gi

MA

LC

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

ST


RS


BT

HA

EL

(DX





Crankshaft Position Sensor (CKPS) (OBD) (COG)

COMPONENT DESCRIPTION

The crankshaft position sensor (OBD) is located on the transmission housing facing the gear teeth (cogs) of the flywheel or drive plate. It detects the fluctuation of the engine revolution.

The sensor consists of a permanent magnet, core and coil.

When the engine is running, the high and low parts of the teeth cause the gap with the sensor to change.

The changing gap causes the magnetic field near the sensor to change.

Due to the changing magnetic field, the voltage from the sensor changes.

The ECM receives the voltage signal and detects the fluctuation of the engine revolution.

This sensor is not used to control the engine system.

It is used only for the on board diagnosis of misfire.

ECM TERMINALS AND REFERENCE VALUE


Specification data are reference values and are measured between each terminal and (3) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
50	B/G	Sensors' ground	Engine is running. (Warm-up condition) Idle speed	0.001 - 0.02V
53	R	Crankshaft position sensor (OBD)	Engine is running. (A/T: N range, M/T: Neutral) Idle speed (Air conditioner switch "OFF".)	More than 0.2V* (AC range)

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1336 0905	 A chipping of the flywheel or drive plate gear tooth (cog) is detected by the ECM. 	Harness or connectors Crankshaft position sensor (OBD) Flywheel (Drive plate)





Crankshaft Position Sensor (CKPS) (OBD) (COG) (Cont'd)

DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE**



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- Start engine and run it for at least 2 minutes at idle





LC 2) Select "MODE 7" with GST.



1) Start engine and run it for at least 2 minutes at idle speed.

– OR –

- 2) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

EC

GI

MA

CL

MT

AT

TF

(PD)

FA

RA

ST

RS


BŢ


HA

 \mathbb{M}

Crankshaft Position Sensor (CKPS) (OBD) (COG) (Cont'd)


EC-CKPS-01







EC-265 405

Crankshaft Position Sensor (CKPS) (OBD) (COG) (Cont'd)








COMPONENT INSPECTION

Crankshaft position sensor (OBD)

- Disconnect crankshaft position sensor (OBD) harness connector.
- 2. Loosen the fixing bolt of the sensor.
- 3. Remove the sensor.
- Visually check the sensor for chipping.

Check resistance as shown in the figure.
 Resistance: Approximately 166.5 - 203.5Ω at 20°C (68°F)

SEF151P



EGRC-Solenoid Valve

COMPONENT DESCRIPTION

The EGRC-solenoid valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the coil in the solenoid valve is energized. A plunger will then move to cut the vacuum signal (from the throttle body to the EGR valve).

When the ECM sends an OFF signal, the vacuum signal passes through the solenoid valve. The signal then reaches the EGR valve.

EC

FE

CL

MT

AT

TF

(PD)

FA

LC

GI

MA

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (4) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
103 W/L E	\A1/1		Engine is running. (Warm-up condition) Engine speed is 2,000 rpm.	BATTERY VOLTAGE (11 - 14V)
	EGRC-solenoid valve	Engine is running. (Warm-up condition) Idle speed	0 - 1V	

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	COND	PITION	SPECIFICATION
EGRC SOL/V	Engine: After warming upAir conditioner switch: OFF	Idle	ON
	Shift lever: "N"No-load	Racing up to 1,500 - 2,000 rpm	OFF

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	RA BR
P1400 1005	An improper voltage signal is sent to ECM through EGRC-solenoid valve.	Harness or connectors (The EGRC-solenoid valve circuit is open or shorted.) EGRC-solenoid valve	en ST

RS


BT


HA


ĒL

IDX

EC-267 407







EGRC-Solenoid Valve (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGRC-solenoid valve circuit. During this check, a 1st trip DTC might not be confirmed.



1) Turn ignition switch "ON".

2) Perform "EGRC SOL/V CIRCUIT" in "FUNCTION TEST" mode with CONSULT.

- OR -

Turn ignition switch "ON".

2) Perform "EGRC SOLENOID VALVE" in "ACTIVE TEST" mode with CONSULT and check the operating sound, according to ON/OFF switching.

Start engine and warm it up sufficiently.

TOOLS

2) Turn ignition switch "OFF" and wait at least 7 seconds.

3) Start engine again.


4) Check the voltage between ECM terminal 103 and ground at idle speed.


Voltage: 0.04 - 0.08V

5) Check that the voltage changes to battery voltage and returns to 0.04 - 0.08V when the engine speed increases to about 2,500 rpm.

EGRC-Solenoid Valve (Cont'd)

EC-EGRC/V-01





AEC317A

GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL


IDX



COMPONENT INSPECTION


EGRC-solenoid valve

Check air passage continuity.



Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals 1 and 2	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.



10,000 1,000 Acceptable range Resistance 100 10 100 200 50 150 (32)(212)(302)(392)(122)Temperature °C (°F) SEF526Q

EGR Temperature Sensor

COMPONENT DESCRIPTION

The EGR temperature sensor detects temperature changes in the EGR passage way. When the EGR valve opens, hot exhaust gases flow, and the temperature in the passageway changes. The EGR temperature sensor is a thermistor that modifies a voltage signal sent from the ECM. This modified signal then returns to the ECM as an input signal. As the temperature increases, EGR temperature sensor resistance decreases.

This sensor is not used to control the engine system. It is used only for the on board diagnosis.

(Reference data)

		The state of the s
EGR temperature °C (°F)	Voltage* (V)	Resistance $(M\Omega)$
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

These data are reference values and measured between ECM terminal (62) (EGR temperature sensor) and ECM terminal (43) (ECCS ground).

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)	8
P1401 0305	An excessively low voltage from the EGR temperature sensor is sent to ECM, even when engine coolant temperature is low.	 Harness or connectors (The EGR temperature sensor circuit is shorted.) EGR temperature sensor Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve 	- \$` !!
	B) An excessively high voltage from the EGR temperature sensor is sent to ECM, even when engine coolant temperature is high.	 Harness or connectors (The EGR temperature sensor circuit is open.) EGR temperature sensor Malfunction of EGR function, EGRC-BPT valve or EGRC-solenoid valve 	B*

EC-271 411

Gil

MA

EM

LC

EC

FE

CL

MT

AT


TF


PD


FA


RA

IDX









EGR Temperature Sensor (Cont'd) OVERALL FUNCTION CHECK

Use this procedure to check the overall function of the EGR temperature sensor circuit. During this check, a 1st trip DTC might not be confirmed.


Procedure for malfunctions A and B



- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT.
- Confirm that engine coolant temperature and intake air temperature are lower than 40°C (104°F). (If necessary, wait until the temperatures equal atmospheric tempera-
- 3) Confirm that "EGR TEMP SEN" reading is between 3.45V and 5.0V.
- Start engine and warm it up sufficiently.
- 5) Run engine at idle for at least 2 minutes.
- 6) Confirm that EGR valve is not lifting. If NG, go to TROUBLE DIAGNOSES FOR DTC P0400 and P0402. (See pages EC-176 and 184.)
- 7) Read "EGR TEMP SEN" at about 1,500 rpm with EGR valve lifted up to the full position by hand. Voltage should decrease to less than 1.0V.
- 8) If step 7 is OK, perform TROUBLE DIAGNOSES FOR DTC P0400, P0402 and P1400. (See pages EC-176, 184 and 267.)

OR ·

Turn ignition switch "ON".



3) Confirm that voltage between ECM terminal @ and ground is between 3.45V and 5.0V.

- 4) Start engine and warm it up sufficiently.
- 5) Run engine at idle for at least 2 minutes.
- 6) Confirm that EGR valve is not lifting. If NG, go to TROUBLE DIAGNOSES FOR DTC P0400 and P0402. (See pages EC-176 and 184.)
- 7) Check voltage between ECM terminal @ and ground at about 1,500 rpm with EGR valve lifted up to the full position by hand.

Voltage should decrease to less than 1.0V.

8) If step 7 is OK, perform TROUBLE DIAGNOSES FOR DTC P0400, P0402 and P1400, (See pages EC-176, 184 and 267.)

EGR Temperature Sensor (Cont'd)

EGR

B/G

B/G 50

GND-A

G/OR

G/OR 62

EGRTS

4 10

19

56789

11 12 13 14

101 102 103

107 108 109

113 114 115

104 105 106

110 111 112

116 117 118

TEMPERATURE SENSOR (MB)

ECM (ECCS CONTROL

38 39 40 41 53 54 55 42 43 44 45 46 57 58 59 60 49 50 47 48 62 63 64 65

47 48 62 63 64 65 70

56 61

MODULE) (M112)

EC-EGR/TS-01

■: Detectable line for DTC : Non-detectable line for DTC EM

LC

MA

GI

EC

FE

GL

MT

AT

TF

PD

FA

RA

BR

\$1

RS

BT

HA


AEC065A


EC-273


20 21 22 23

24 25 26 27 28 29 30 31 32 33

413







EGR Temperature Sensor (Cont'd) COMPONENT INSPECTION

EGR temperature sensor

Check resistance change and resistance value.

(Reference data)

EGR temperature °C (°F)	Voltage (V)	Resistance $(M\Omega)$
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

If NG, replace EGR temperature sensor.

Gľ

MA

EM

LC

EC

FE

CL.

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT

HA

EL

[DX



Vacuum Cut Valve Bypass Valve

COMPONENT DESCRIPTION

The vacuum cut valve and vacuum cut valve bypass valve are installed in parallel on the EVAP purge line between the fuel tank and the EVAP canister.

The vacuum cut valve prevents the intake manifold vacuum from being applied to the fuel tank.

The vacuum cut valve bypass valve is a solenoid type valve and generally remains closed. It opens only for on board diagnosis.

The vacuum cut valve bypass valve responds to signals from the ECM. When the ECM sends an ON (ground) signal, the valve is opened. The vacuum cut valve is then bypassed to apply intake manifold vacuum to the fuel tank.

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and (43) (ECCS ground).


TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
117	Y	Vacuum cut valve bypass valve	[Ignition switch "ON"]	BATTERY VOLTAGE (11 - 14V)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
VC/V BYPASS/V	Ignition switch: ON	OFF

EVAPORATIVE EMISSION SYSTEM DIAGRAM



ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1441 0801	An improper voltage signal is sent to ECM through vacuum cut valve bypass valve.	Harness or connectors (The vacuum cut valve bypass valve circuit is open or shorted.) Vacuum cut valve bypass valve
	B) Vacuum cut valve bypass valve does not operate properly.	 Vacuum cut valve bypass valve Vacuum cut valve Bypass hoses for clogging EVAP shut valve EVAP control system pressure sensor

Vacuum Cut Valve Bypass Valve (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION **PROCEDURE**

Perform "Procedure for malfunction A" first. If 1st trip DTC cannot be confirmed, perform "OVERALL FUNCTION CHECK", "Procedure for malfunction B".



MA


闰M

LC

EC

FΞ

GL



Turn ignition switch "ON".

Select "DATA MONITOR" mode with CONSULT.

Start engine and wait at least 5 seconds.

- OR -

Start engine and wait at least 5 seconds.

Select "MODE 7" with GST. - OR -

Start engine and wait at least 5 seconds.

Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".

3) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

TF

(dq.






Procedure for malfunction B

- Remove vacuum cut valve and vacuum cut valve bypass valve as an assembly.
- Apply vacuum to port (A) and check that there is no suction from port (B).
- Apply vacuum to port (B) and check that there is suction from port (A).
- Blow air in port (B) and check that there is a resistance to flow out of port (A).
- 5) Supply battery voltage to the terminal.
- Blow air in port (A) and check that air flows freely out of port 6)
- Blow air in port (B) and check that air flows freely out of port (A).

MA



☆ NO FAIL

800rpm


SEF712T


☆ MONITOR


CMPS•RPM(REF)

RECORD

Vacuum Cut Valve Bypass Valve (Cont'd)







EC-279 419


MA


ΞL


10)%

Vacuum Cut Valve Bypass Valve (Cont'd) DIAGNOSTIC PROCEDURE

Procedure for malfunction B







COMPONENT INSPECTION

Vacuum cut valve bypass valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)
12V direct current supply between terminals	Yes
No supply	No

If NG, replace vacuum cut valve bypass valve.

Vacuum cut valve

Check vacuum cut valve as follows:

- 1. Plug port © and D with fingers.
- 2. Apply vacuum to port (A) and check that there is no suction from port (B).
- 3. Apply vacuum to port (B) and check that there is suction from port (A).
- 4. Blow air in port (B) and check that there is a resistance to flow out of port (A).
- 5. Open port © and D.
- 6. Blow air in port (A) check that air flows freely out of port (C).
- 7. Blow air in port (B) check that air flows freely out of port (D).

G1 **Evaporative Emission (EVAP) Canister Purge** Volume Control Valve MA SYSTEM DESCRIPTION Engine speed Camshaft position sensor Amount of intake air LC Mass air flow sensor EC Engine coolant temperature Engine coolant temperature sensor Start signal ECM Ignition switch (ECCS **EVAP** canister GL control purge volume module) control valve Throttle position Mï Throttle position sensor AT Density of oxygen in exhaust gas Front heated oxygen sensor (Mixture ratio feedback signal) TF Fuel temperature in fuel tank Tank fuel temperature sensor

This system controls flow rate of fuel vapor from the EVAP canister. The opening of the vapor by-pass passage in the EVAP canister purge volume control valve changes to control the flow rate. A built-in step motor moves the valve in steps corresponding to the ECM output pulses. The opening of the valve varies for optimum engine control. The optimum value stored in the ECM is determined by considering various engine conditions. When the engine is operating, the flow rate of fuel vapor from the EVAP canister is regulated as the air flow changes.

ECM TERMINALS AND REFERENCE VALUE

Vehicle speed sensor

Vehicle speed

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER* MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	RS BT
5	R				ا لا
6	L/G	EVAP canister purge vol-	Engine is running.	0 - 0.4V or	HA
16	G	ume control valve	L Idle speed	BATTERY VOLTAGE (11 - 14V)	ITII/AV
17	Υ				

EC-281 421

EM

FE

(19)

FA

RA

BR


1D)X

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (Cont'd)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION
PURG VOL C/V	Engine: After warming upAir conditioner switch: OFF	Vehicle stopped	0 step
	Shift lever "N" No-load	Vehicle running	_




COMPONENT DESCRIPTION


The EVAP canister purge volume control valve uses a step motor to control the flow rate of fuel vapor from the EVAP canister. This motor has four winding phases. It operates according to the output pulse signal of the ECM. Two windings are turned ON and OFF in sequence. Each time an ON pulse is issued, the valve opens or closes, changing the flow rate. When no change in the flow rate is needed, the ECM does not issue the pulse signal. A certain voltage signal is issued so that the valve remains at that particular opening.

ON BOARD DIAGNOSIS LOGIC


Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1445 1008	An improper voltage signal is sent to ECM through the valve.	Harness or connectors (The valve circuit is open or shorted.) EVAP canister purge volume control valve
	B) The canister purge flow is detected during the specified driving conditions, even when EVAP canister purge volume control valve is completely closed.	 EVAP control system pressure sensor EVAP canister purge volume control valve (The valve is stuck open.) EVAP canister purge control valve Hoses (Hoses are connected incorrectly.)


Evaporative Emission (EVAP) Canister Purge GI. Volume Control Valve (Cont'd) DIAGNOSTIC TROUBLE CODE CONFIRMATION MA **PROCEDURE** Perform "Procedure for malfunction A" first. If the 1st trip DTC cannot be confirmed, perform "Procedure for malfunction B". Procedure for malfunction A Lift up vehicle. 2) Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT. Start engine and let it idle for at least 90 seconds. EC 4) Move selector/gearshift lever to "1" range (A/T) or "1st" gear (M/T). Rev engine from idle to 2,000 to 3,000 rpm more than 10 times. – OR — 1) Lift up vehicle. CL. 2) Start engine and let it idle for at least 90 seconds. Move selector/gearshift lever to "1" range (A/T) or "1st" gear (M/T). 4) Rev engine from idle to 2,000 to 3,000 rpm more than 10 times. Select "MODE 3" with GST. — OR -1) Lift up vehicle. 2) Start engine and let it idle for at least 90 seconds. 3) Move selector/gearshift lever to "1" range (A/T) or "1st" gear (M/T). 4) Rev engine from idle to 2,000 to 3,000 rpm more than 10 times. PD 5) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON". 6) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM. Procedure for malfunction B Lift up vehicle. Turn ignition switch "ON" and select "DATA MONITOR" mode with CONSULT. 3) Start engine and warm it up sufficiently. 4) Check that tank fuel temperature is above 0°C (32°F). 5) Turn ignition switch "OFF" and wait at least 7 seconds. Turn ignition switch "ON" and wait at least 12 seconds. Start engine and let it idle for at least 70 seconds. Maintain the following conditions for at least 25 sec-





EC-283 423





Evaporative Emission (EVAP) Canister Purge Volume Control Valve (Cont'd)



- 1) Lift up vehicle.
- 2) Turn ignition switch "ON" and select "MODE 1" mode with GST.
- 3) Start engine and warm it up sufficiently.
- 4) Check that voltage between ECM terminal 63 and ground is less than 4.2V.
- 5) Turn ignition switch "OFF" and wait at least 7 seconds.
- 6) Turn ignition switch "ON" and wait at least 12 seconds.
- 7) Start engine and let it idle for at least 70 seconds.
- 8) Maintain the following conditions for at least 25 seconds.

Gear position:

"2" or "D" range (A/T)

"3rd" or "4th" gear (M/T)

Vehicle speed:

50 - 70 km/h (31 - 43 MPH)

Engine speed:

1,500 - 2,500 rpm

Coolant temperature:

Less than 100°C (212°F)

9) Select "MODE 3" with GST.



- 1) Lift up vehicle.
- 2) Turn ignition switch "ON".
- Start engine and warm it up sufficiently.
- 4) Check that voltage between ECM terminal 63 and ground is less than 4.2V.
- 5) Turn ignition switch "OFF" and wait at least 7 seconds.
- 6) Turn ignition switch "ON" and wait at least 12 seconds.
- 7) Start engine and let it idle for at least 70 seconds.
- 8) Maintain the following conditions for at least 25 seconds.

Gear position:

"2" or "D" range (A/T)

"3rd" or "4th" gear (M/T)

Vehicle speed:

50 - 70 km/h (31 - 43 MPH)


Engine speed:

1,500 - 2,500 rpm

Voltage between ECM terminal (51) and ground: More than 0.8V

- 9) Turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 10) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.

Evaporative Emission (EVAP) Canister Purge Volume Control Valve (Cont'd)



AEC067A

38 39

20 21 22 23

24 25 26 27 28

29 30 31 32 33

34 35 36 37

4 10

123

16 17 18

56789

11 12 13 14 15 16 17 18

104 105 106

118


107 108 109 | 44|45|46|57|58|59|60| 61 | 47|48|62|63|64|65| 70 | 51|52| | 66|67|69|49|

(M112)

EL


IDX


G





EC-286

426









Evaporative Emission (EVAP) Canister Purge Volume Control Valve (Cont'd) COMPONENT INSPECTION

EVAP canister purge volume control valve

- Disconnect EVAP canister purge volume control valve harness connector.
- 2. Check resistance between the following terminals. terminal ② and terminals ①, ③ terminal ⑤ and terminals ④, ⑥

Resistance:

Approximately 30Ω [At 25°C (77°F)]

- 3. Reconnect EVAP canister purge volume control valve harness connector.
- Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
 (Plug the purge hoses. The EVAP canister purge vol-
 - (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5. Turn ignition switch "ON".
- Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening.
 - If NG, replace the EVAP canister purge volume control valve.



- 1. Disconnect EVAP canister purge volume control valve harness connector.
- 2. Check resistance between the following terminals. terminal ② and terminals ①, ③ terminal ⑤ and terminals ④, ⑥ Resistance:

- OR -

Approximately 30Ω [At 25°C (77°F)]

- Reconnect EVAP canister purge volume control valve harness connector.
- Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
 - (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.
 - If NG, replace the EVAP canister purge volume control valve.

18T

RS

(G)

MiA

LC:

EC

(GL

MT

TE

PD)


FA

TR/A

88

HA

Evaporative Emission (EVAP) Control System Purge Flow Monitoring




SYSTEM DESCRIPTION


In this evaporative emission (EVAP) control system, purge flow occurs during non-closed throttle conditions. Purge volume is related to air intake volume. Under normal purge conditions (non-closed throttle), the EVAP canister purge volume control valve and EVAP canister purge control valve are open. Purge flow exposes the EVAP control system pressure sensor to intake manifold vacuum.


ON BOARD DIAGNOSIS LOGIC

Under normal conditions (non-closed throttle), sensor output voltage indicates if pressure drop and purge flow are adequate. If not, a fault is determined.

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1447 0111	EVAP control system does not operate properly. EVAP control system has a leak between intake manifold and EVAP control system pressure sensor.	 EVAP canister purge volume control valve stuck closed EVAP canister purge control valve stuck closed EVAP control system pressure sensor Loose or disconnected rubber tube Blocked rubber tube EVAP canister purge control solenoid valve Blocked or bent rubber tube to MAP/BARO switch solenoid valve Cracked EVAP canister Absolute pressure sensor MAP/BARO switch solenoid valve









Eva	porative Emission (EVAP) Control System	
-	ge Flow Monitoring (Cont'd)	GI
OVE	RALL FUNCTION CHECK	
EVAP	nis procedure to check the overall monitoring function of the control system purge flow. During this check, a 1st trip DTC	MA
	not be confirmed. 1) Lift up vehicle.	EM
	2) Start engine.3) Select "EVAP SYS PRES" in "DATA MONITOR" mode	
	with CONSULT. 4) Check EVAP control system pressure sensor value at	LC
	idle speed. 5) Select "PURG VOL CONT/V" in "ACTIVE TEST" mode	EC
	with CONSULT and set "PURG VOL CONT/V" to 20 steps by touching "UP" or "Qu".	
	6) Maintain the following conditions for at least 30 seconds. Verify that EVAP control system pressure sensor value ("EVAP SYS PRES") stays 0.1V less than the	FE
	value at idle speed for at least 2 seconds. Engine speed:	GL
	Approx. 2,000 rpm Gear position (for M/T models): Any position other than "Neutral" or "Reverse"	MT
	CAUTION: Do not run vehicle at speeds greater than 80 km/h (50 MPH).	AT
		570
	 Lift up vehicle. Start engine and warm it up sufficiently. Turn ignition switch "OFF", wait at least 7 seconds. Start engine and wait at least 70 seconds. 	TF PD
	 5) Set voltmeter probes to ECM terminals (a) (EVAP control system pressure sensor signal) and (4) (ground). 6) Check EVAP control system pressure sensor value at idle speed. 	FA
	7) Establish and maintain the following conditions for at least 30 seconds.	RA
	Air conditioner switch: ON Steering wheel: Fully turned	
	Headlamp switch: ON Engine speed: Approx. 3,500 rpm	<u>B</u> P.
	Intake manifold vacuum: -73.3 to -60.0 kPa (-550 to -450 mmHg, -21.65 to -17.72 inHg, -10.63 to -8.70 psi)	ST
	Gear position: M/T models Any position other than "Neutral" or "Reverse"	R\$
	A/T models Any position other than "P", "N" or "R". Return all conditions to normal. Repeat this procedure	BT
	at least 5 times. Verify that EVAP control system pressure sensor value stays 0.1V less than the value at idle speed for at least 2 seconds.	HA
	CAUTION: Do not run vehicle at speeds greater than 80 km/h (50	EL
	MPH).	ULD/V


EC-289 429


 $\mathbb{D}\mathbb{X}$







EC-291 431









432

Evaporative Emission (EVAP) Control System Purge Flow Monitoring (Cont'd) COMPONENT INSPECTION

EVAP canister purge volume control valve



- Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals. terminal ② and terminals ①, ③ terminal ⑤ and terminals ④, ⑥

Resistance:

Approximately 30Ω [At 25°C (77°F)]

- Reconnect EVAP canister purge volume control valve harness connector.
- 4) Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
 (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain
- connected.)
 5) Turn ignition switch "ON".
- 6) Perform "PURG VOL CONT/V" in "ACTIVE TEST" mode with CONSULT. Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the valve opening. If NG, replace the EVAP canister purge volume control valve.



- Disconnect EVAP canister purge volume control valve harness connector.
- 2) Check resistance between the following terminals. terminal ② and terminals ①, ③ terminal ⑤ and terminals ④, ⑥


- OR -


Resistance:

Approximately 30 Ω [At 25°C (77°F)]

- Reconnect EVAP canister purge volume control valve harness connector.
- Remove EVAP canister purge volume control valve from intake manifold collector and disconnect hoses from the valve.
 - (Plug the purge hoses. The EVAP canister purge volume control valve harness connector should remain connected.)
- 5) Turn ignition switch "ON" and "OFF". Check that EVAP canister purge volume control valve shaft moves smoothly forward and backward according to the ignition switch position.

If NG, replace the EVAP canister purge volume control valve.





Evaporative Emission (EVAP) Control System Purge Flow Monitoring (Cont'd)

EVAP canister purge control valve

Check EVAP canister purge control valve as follows:

Plug the port (B).

Apply pressure [80.0 kPa (600 mmHg, 23.62 inHg, 11.60 psi)] to port (A). Then keep it for 15 seconds, and check there is no leakage.

Repeat step 2 for port ©.

10

Gl


MA

EVAP canister purge control solenoid valve

Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals	Yes	No
No supply	No	Yes

If NG, replace solenoid valve.



EVAP control system pressure sensor

- Remove EVAP control system pressure sensor with its harness connector connected.
- 2. Remove hose from EVAP control system pressure sensor.
- Use pump to apply vacuum and pressure to EVAP control system pressure sensor as shown in figure.
- Check output voltage between terminal (2) and engine ground.

Pressure (Relative to atmospheric pressure)	Voltage (V)
0 kPa (0 mmHg, 0 inHg, 0 psi)	3.0 - 3.6
-9.3 kPa (-70 mmHg, -2.76 inHg, -1.35 psi)	0.4 - 0.6

CAUTION:

Always calibrate the vacuum pump gauge when using it.

5. If NG, replace EVAP control system pressure sensor.

EC-293 433

EC

FE

CL.

MT

AT

TF

PD)

FA.


RA

BR

RS

BT

MA



Evaporative Emission (EVAP) Control System Purge Flow Monitoring (Cont'd)

Absolute pressure sensor

- Remove absolute pressure sensor with its harness connector connected.
- Remove hose from absolute pressure sensor.
- Turn ignition switch "ON" and check output voltage between terminal ② and engine ground.

The voltage should be 3.2 to 4.8 V.


Use pump to apply vacuum of -26.7 kPa (-200 mmHg, -7.87 inHg, -3.87 psi) to absolute pressure sensor as shown in figure and check the output voltage.


The voltage should be 1.0 to 1.4 V lower than the value measured in step 3.


CAUTION:

Always calibrate the vacuum pump gauge when using it.

If NG, replace absolute pressure sensor.







MAP/BARO switch solenoid valve



- 1. Start engine and warm it up sufficiently.
- 2. Perform "MAP/BARO SW/V" in "ACTIVE TEST" mode with CONSULT.
- Check the following.
 - When "MAP" is selected, "ABSOL PRES/SE" indicates approximately 1.3V.
 - When "BARO" is selected, "ABSOL PRES/SE" indicates approximately 4.3V.
- 4. If NG, replace solenoid valve.




- Remove MAP/BARO switch solenoid valve.
- 2. Check air passage continuity.

Condition	Air passage continuity between (A) and (B)	Air passage continuity between (A) and (C)
12V direct current supply between terminals (1) and (2)	Yes	No
No supply	No	Yes

3. If NG, replace solenoid valve.

Torque Converter Clutch Solenoid Valve

SYSTEM DESCRIPTION



The ECM controls torque converter clutch solenoid valve to cancel the lock-up condition of A/T. When the solenoid valve is turned on, lock-up is cancelled. When the solenoid valve is turned off, A/T lock-up is operational.

Conditions for lock-up cancel:

- Throttle valve is fully closed (idling or decelera-
- Engine coolant temperature is below 40°C (104°F)

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)	PD
			Engine is running. — Idle speed	Approximately 0V	FA
		Torque converter clutch	Engine coolant temperature is below 40°C (104°F)	, pproximater, or	RA
114	L/Y	solenoid valve	Engine is running. — After warming up — Engine coolant temperature is above 40°C	BATTERY VOLTAGE	BR
_			(104°F) — Engine speed is 2,000 rpm		ST

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION		SPECIFICATION	<u>[</u>
	Engine speed: Idle Engine coolant temperature be	low 40°C (104°F)	ON	
TCC SOL/V	 Engine: After warming up Engine coolant temperature above 40°C (104°F) 	2,000 rpm	OFF	

EC-295 435

G

MA

LC

EC

FF

GL.

IMIT

AT

TF

RA.

88

RS

IDX

Torque Converter Clutch Solenoid Valve (Cont'd)

ON BOARD DIAGNOSIS LOGIC

Diagnostic Trouble Code No.	Malfunction is detected when	Check Items (Possible Cause)
P1550 0904	 An excessively low voltage from the solenoid is sent to ECM. A/T torque converter slip is occurred in lock-up condition. 	(The circuit is open or shorted.)

DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE



- Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode with CONSULT.
- 3) Start engine and warm it up sufficiently.
- 4) Perform test drive in "D" position for at least 20 seconds continuously under the following conditions.

Engine speed: 2,000 - 2,700 rpm

Vehicle speed: 75 - 95 km/h (45 - 60 MPH)



- 1) Start engine and warm it up sufficiently.
- 2) Perform test drive in "D" position for at least 20 seconds continuously under the following conditions.

Engine speed: 2,000 - 2,700 rpm Vehicle speed: 75 - 95 km/h (45 - 60 MPH)

– OR -

3) Select MODE 7 with GST.



- 1) Start engine and warm it up sufficiently.
- 2) Perform test drive in "D" position for at least 20 seconds continuously under the following conditions.

Engine speed: 2,000 - 2,700 rpm Vehicle speed: 75 - 95 km/h (45 - 60 MPH)

- 3) Stop the vehicle, turn ignition switch "OFF", wait at least 7 seconds and then turn "ON".
- 4) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with ECM.


EC-296


436

Torque Converter Clutch Solenoid Valve G] (Cont'd) EC-TCV-01 MA EM IGNITION SWITCH ON or START LC Refer to "EL-POWER". 10A 11 EC w/B FE CL ₩/B SOLENOID LINK CONNECTOR FOR CONSULT MT TORQUE CONVERTER CLUTCH SOLENOID VALVE UNIT g M27VALVE AT 13 3 ĹΖΥ L/Y TF PD) FA RA L/Y 114 ECM (ECCS CONTROL MODULE) LKUP BR (M112) ST RS 3 2 1 M27 O 1 2 3 4 5 6 7 M153 GY BT **(M112)** HA 44 45 46 57 58 59 60 47 48 62 63 64 65 42 43 49 50 10 61 EL 108 109 112 11 12 13 14 29 30 31 32 33 19

AEC320A

IDX





EC-299 439

HA

EL

IDX

Overheat

Note: Since this diagnosis does not meet P1900 of SAEJ2012, it is indicated only by CONSULT.

ON BOARD DIAGNOSIS LOGIC

If the cooling fan or another component in the cooling system malfunctions, the engine coolant temperature will rise.


When the engine coolant temperature reaches an abnormally high temperature condition, a malfunction is indicated.

Diagnostic trouble code No.	Malfunction is detected when	Check Items (Possible Cause)
OVERHEAT (P1900) 0208	Engine coolant temperature reaches an abnormally high temperature.	 Cooling fan Radiator hose Radiator Radiator cap Water pump Thermostat For more information, refer to "MAIN 12 CAUSES OF OVERHEATING", (EC-302).

CAUTION:

When a malfunction is indicated, be sure to replace the coolant following the procedure in the MA section ("Changing Engine Coolant", "ENGINE MAINTENANCE"). Also, replace the engine oil.

- a. Fill radiator with coolant up to specified level with a filling speed of 2 liters per minute like pouring coolant by kettle. Be sure to use coolant with the proper mixture ratio. Refer to MA section ("Anti-freeze Coolant Mixture Ratio", "RECOMMENDED FLUIDS AND LUBRICANTS").
- b. After refilling coolant, run engine to ensure that no water-flow noise is emitted.




OVERALL FUNCTION CHECK

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator.

Wrap a thick cloth around cap. Carefully remove the cap by turning it a quarter turn to allow built-up pressure to escape. Then turn the cap all the way off.

- Check the coolant level in the reservoir tank and radiator.
 Allow engine to cool before checking coolant level.
 If the coolant level in the reservoir tank and/or radiator is below the proper range, skip the following step and go to "DIAGNOS-TIC PROCEDURE" on next page.
- Confirm whether customer filled the coolant or not. If customer filled the coolant, go to "DIAGNOSTIC PROCEDURE" on next page.



EC-301 441

Then, perform "OVERALL FUNCTION CHECK".

Overheat (Cont'd)


MAIN 12 CAUSES OF OVERHEATING

Engine	Step	Inspection item	Equipment	Standard	Reference page
OFF	1	Blocked radiator Blocked condenser Blocked radiator grille Blocked bumper	● Visual	No blocking	
	2	Coolant mixture	Coolant tester	50 - 50% coolant mixture	See "RECOMMENDED FLUIDS AND LUBRI- CANTS" in MA section
	3	Coolant level	● Visual	Coolant up to MAX level in reservoir tank and radiator filler neck	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section
	4	Radiator cap	Pressure tester	78 - 98 kPa (0.8 - 1.0 kg/cm², 11 - 14 psi) 59 - 98 kPa (0.6 - 1.0 kg/cm², 9 - 14 psi) (Limit)	See "System Check" "ENGINE COOLING SYSTEM" in LC section
ON* ²	5	Coolant leaks	● Visual	No leaks	See "System Check" "ENGINE COOLING SYSTEM" in LC section
ON*2	6	Thermostat	Touch the upper and lower radiator hoses	Both hoses should be hot	See "Thermostat" and "Radiator", "ENGINE COOLING SYSTEM" in LC section
ON*1	7	Cooling fan	• Visual	Operating	See "Cooling Fan" "ENGINE COOLING SYSTEM" in LC section.
OFF	8	Combustion gas leak	Color checker chemical tester 4 gas analyzer	Negative	-
ON*3	9	Coolant temperature gauge	Visual	Gauge less than 3/4 when driving	_
		Coolant overflow to reservoir tank	● Visual	No overflow during driving and idling	See "Changing Engine Coolant", "ENGINE MAINTENANCE" in MA section
OFF*4	10	Coolant return from reservoir tank to radiator	● Visual	Should be initial level in reservoir tank	See "ENGINE MAINTE- NANCE" in MA section
OFF	11	• Cylinder head	Straight gauge feeler gauge	0.1 mm (0.004 in) Maximum distortion (warping)	See "Inspection", "CYL- INDER HEAD" in EM section
	12	Cylinder block and pistons	● Visual	No scuffing on cylinder walls or piston	See "Inspection", "CYL- INDER BLOCK" in EM section


^{*1:} Turn the ignition switch ON.
*2: Engine running at 3,000 rpm for 10 minutes.

^{*3:} Drive at 90 km/h (55 MPH) for 30 minutes and then let idle for 10 minutes. *4: After 60 minutes of cool down time.

For more information, refer to "OVERHEATING CAUSE ANALYSIS" in LC section.



AEC068A




Injector (Cont'd) COMPONENT DESCRIPTION


The fuel injector is a small, precise solenoid valve. When the ECM supplies a ground to the injector circuit, the coil in the injector is energized. The energized coil pulls the needle valve back and allows fuel to flow through the injector into the intake manifold. The amount of fuel injected depends upon the injection pulse duration. Pulse duration is the length of time the injector remains open. The ECM controls the injection pulse duration based on engine fuel needs.


ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE	ITEM	CONDITION	DATA (DC voltage)
102	W/B	Injector No. 1		
104	W/R	Injector No. 3] 	BATTERY VOLTAGE (11 - 14V)
107	W/L	Injector No. 2	Engine is running.	
109	W/G	Injector No. 4		







COMPONENT INSPECTION

Injector

- Disconnect injector harness connector.
- Check resistance between terminals as shown in the figure. Resistance: 10 - 14 Ω at 25°C (77°F) If NG, replace injector.

IDX

EL

RS


BT


HA

Start Signal

EC-S/SIG-01

: Detectable line for DTC
: Non-detectable line for DTC





Start Signal (Cont'd)

SYSTEM DESCRIPTION

If the ECM always receives a start signal, the ECM will judge the start signal "OFF" when engine speed is above 1,000 rpm. This prevents extra enrichment. After the engine speed is below 200 rpm, start-up enrichment will be allowed until the engine speed reaches 1,000 rpm.

MA

LC

G

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).

TER- MINAL NO.	WIRE	ITEM	CONDITION	DATA (DC voltage)
		Ignition switch "ON"	Approximately 0V	
20	OR	Start signal	Ignition switch "START"	BATTERY VOLTAGE (11 - 14V)



FE

CL

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values.

MONITOR ITEM	CONDITION	SPECIFICATION
START SIGNAL	 Ignition switch: ON → START → ON 	$OFF \to ON \to OFF$

AT

Mï

PD)

TF

FA

 $\mathbb{R}\mathbb{A}$

 $\mathbb{B}\mathbb{R}$

ST

RS


BŢ

HA

ĒĹ


IDX

EC-307 447



Fuel Pump

SYSTEM DESCRIPTION



The ECM activates the fuel pump for several seconds after the ignition switch is turned on to improve engine startability. If the ECM receives a 180° signal from the camshaft position sensor, it knows that the engine is rotating, and causes the pump to perform. If the 180° signal is not received when the ignition switch is on, the engine stalls. The ECM stops pump operation and prevents battery discharging, thereby improving safety. The ECM does not directly drive the fuel pump. It controls the ON/OFF fuel pump relay, which in turn controls the fuel pump.

Condition	Fuel pump operation
Ignition switch is turned to ON.	Operates for 5 seconds
Engine running and cranking	Operates
When engine is stopped	Stops in 1 second
Except as shown above	Stops

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 49 (ECCS ground).


				<u> </u>
TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
8	W/R	Fuel pump relay	Ignition switch "ON" For 5 seconds after turning ignition switch "ON" Engine is running.	Approximately 1V
			Ignition switch "ON" 5 seconds after turning ignition switch "ON"	BATTERY VOLTAGE (11 - 14V)

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Specification data are reference values

MONITOR ITEM	CONDITION	SPECIFICATION	ć
FUEL PUMP RLY	 Ignition switch is turned to ON (Operates for 5 seconds) Engine running and cranking When engine is stopped (Stops in 1.0 seconds) 	ON	Į
	Except as shown above	OFF	

EC-309



COMPONENT DESCRIPTION

The fuel pump with a fuel damper is an in-tank type (the pump and damper are located in the fuel tank).

449

87

@[

EC

FE

CL

MT

Δť

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST


RS


EL

Fuel Pump (Cont'd)


EC-F/PUMP-01











EC-311 451











COMPONENT INSPECTION

Fuel pump relay

Check continuity between terminals 3 and 5.

Conditions	Continuity
12V direct current supply between terminals ① and ②	Yes
No current supply	No

If NG, replace relay.

Fuel pump

- Disconnect fuel pump harness connector.
- Check resistance between terminals ⑤ and ⑥.
 Resistance: 0.2 5.0Ω at 25°C (77°F)
 If NG, replace fuel pump.

PWST

Power Steering Oil Pressure Switch

ECM (ECCS CONTROL MODULE)

POWER STEERING OIL PRESSURE SWITCH

(E10)

(M112)

EC-PST/SW-01

■ : Detectable line for DTC
■ : Non-detectable line for DTC

MA

GI

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

ST

R\$

BT

HA

AEC071A

24 25 26 27 28 42 43 29 30 31 32 33 40 50

40 41

51 52

44 45 46 57 58 59 60 47 48 62 63 64 65


61

(M112)

1 2 3 4 5 6 7 8 9 11 12 13 14 15 16 17 18

104 105 106

108 109



Power Steering Oil Pressure Switch (Cont'd) COMPONENT DESCRIPTION

The power steering oil pressure switch is attached to the power steering high-pressure tube and detects a power steering load. When a power steering load is detected, it signals the ECM. The ECM adjusts the IACV-AAC valve to increase the idle speed and adjust for the increased load.

ECM TERMINALS AND REFERENCE VALUE


Specification data are reference values and are measured between each terminal and (3) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
0.5		Power steering oil pres-	Engine is running. Steering wheel is being turned.	0V
25	G	sure switch	Engine is running. Steering wheel is not being turned.	Approximately 5V

CONSULT REFERENCE VALUE IN DATA MONITOR MODE


Specification data are reference values


MONITOR ITEM	CON	SPECIFICATION	
PW/ST SIGNAL	Engine: After warming up, idle	Steering wheel in neutral position (forward direction)	OFF
	the engine	The steering wheel is turned	ON



EC-315 455

Power Steering Oil Pressure Switch (Cont'd)





COMPONENT INSPECTION

Power steering oil pressure switch

 Disconnect power steering oil pressure switch harness connector then start engine.


Check continuity between terminals (1) and (2).

Conditions	Continuity
Steering wheel is being turned	Yes
Steering wheel is not being turned	No

If NG, replace power steering oil pressure switch.

GI **IACV-FICD Solenoid Valve** EC-FICD-01 IGNITION SWITCH MAACC or ON ■: Detectable line for DTC : Non-detectable line for DTC Refer to "EL-POWER". 3 6 LC G/W EC CONDITIONER SWITCH ON ON (M120) FE CL MT (M601) To HA-A/C ← G/B AT IACV-FICD SOLENOID VALVE TF (M602) G/W 3 AIR CONDITIONER RELAY (M33) (M7) FA 13 THERMAL PROTECTOR JOINT CONNECTOR-2 M14)-1 RA (M142) 別입 15 COMPRESSOR ECM (ECCS CONTROL MODULE) **ACRLY** M14)-2 ST (M112) (M49) (M160) (M105) RS Refer to last page (Foldout page). (M142) BT **(**M14)-2 1 2 M602 PU HA (M112) H.S 20 21 22 23 EL 10 44 45 46 57 58 59 60 61 108 109 107 11 12 13 14 29 30 31 32 33 47 48 62 63 64 65 19 IDX

AEC319A




IACV-FICD Solenoid Valve (Cont'd) COMPONENT DESCRIPTION

The idle air adjusting (IAA) unit is made up of the IACV-AAC valve, IACV-FICD solenoid valve and idle adjusting screw. It receives the signal from the ECM and controls the idle speed at the preset value.


ECM TERMINALS AND REFERENCE VALUE


Specification data are reference values and are measured between each terminal and (49) (ECCS ground).

TER- MINAL NO.	WIRE COLOR	ITEM	CONDITION	DATA (DC voltage)
15 G/R Air conditioner relay		Air conditioner relay	Engine is running. Both air conditioner switch and blower switch are "ON".	Approximately 1V
		-	Engine is running. Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)
21	G/R	G/R Air conditioner switch	Engine is running. Both air conditioner switch and blower switch are "ON". (Compressor operates)	Approximately 0V
			Engine is running. Air conditioner switch is "OFF".	BATTERY VOLTAGE (11 - 14V)



IACV-FICD Solenoid Valve (Cont'd)








COMPONENT INSPECTION


IACV-FICD solenoid valve

Disconnect IACV-FICD solenoid valve harness connector.

Check for clicking sound when applying 12V direct current to terminals.



- Check plunger for seizing or sticking.
- Check for broken spring.



AEC321A

MIL & Data Link Connectors (Cont'd)

ECM TERMINALS AND REFERENCE VALUE

Specification data are reference values and are measured between each terminal and 43 (ECCS ground).

TER- MINAL NO.	WIRE	ITEM	CONDITION	DATA (DC Voltage)
			Ignition switch "ON"	0 - 1V
18	R/W	Malfunction indicator lamp	Engine is running. Idle speed	BATTERY VOLTAGE (11 - 14V)
58	R	Data link connector for GST	Engine is running. Idle speed (GST is disconnected.)	Approximately 9V
64	Υ		Engine is running.	Approximately 0.1V
65	R	Data link connector for CONSULT	Idle speed (Connect CONSULT and select	Approximately 4 - 9V
68	G		DATA MONITOR mode.)	Approximately 3.5V*

^{*:} Average voltage for pulse signal (Actual pulse signal can be confirmed by oscilloscope.)

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

PRESSURE REGULATOR	
Fuel pressure at idling kPa (kg/cm², psi)	
Vacuum hose is connected	Approximately 235 (2.4, 34)
Vacuum hose is disconnected	Approximately 294 (3.0, 43)

MA

(GII

LC

Inspection and Adjustment EGR TEMPERATURE SENSOR

Idle speed*1 rpm	
No-load*2 (in "N" position)	800±50
Air conditioner: ON (in "N" position)	900 or more
Ignition timing	10°±2° BTDC
Throttle position touch speed rpm	1,000±150

Electrical load: OFF (Lights, heater fan & rear window defog-

*1: Feedback controlled and needs no adjustments

Steering wheel: Kept in straight-ahead position

EGR temperature °C (°F)	Voltage (V)	Resistance $(M\Omega)$
0 (32)	4.81	7.9 - 9.7
50 (122)	2.82	0.57 - 0.70
100 (212)	0.8	0.08 - 0.10

EC

CL

MT

0.2 - 5.0

10 - 14

AT

TF

IGNITION COIL

ger)

*2: Under the following conditions:

Air conditioner switch: OFF

Primary voltage	V	Battery voltage (11 - 14)
Primary resistance [at 25°C (77°F)]	Ω	Less than 1.0
Secondary resistance [at 25°C (77°F)]	kΩ	7 - 13

IACV-AAC VALVE

Resistance [at 25°C (77°F)]

Resistance [at 25°C (77°F)]

FUEL PUMP

Resistance [at 25°C (77°F)]	Ω	Approximately 10.0

 Ω

Ω

PD

FA

RA

MASS AIR FLOW SENSOR

Supply voltage	٧	Battery voltage (11 - 14)
Output voltage at idle	٧	1.3 - 1.7
Mass air flow (Using CONSULT or GST) g·m/s	sec	1.8 - 6.5 at idle* (2WD) 2.1 - 6.0 at idle* (4WD) 7.7 - 15.0 at 2,500 rpm* (2WD) 6.8 - 13.3 at 2,500 rpm* (4WD)

RESISTOR

INJECTOR

Resistance [at 25°C (77°F)]	kΩ	Approximately 2.2
		1 (pp. oato.) 2.2

BR

THROTTLE POSITION SENSOR

Throttle valve conditions	Resistance [at 25°C (77°F)]
Completely closed	Approximately 0.5 kΩ
Partially open	0.5 - 4.0 kΩ
Completely open	Approximately 4.0 kΩ

ST

5 kΩ	RS
0 κΩ	BT

ENGINE COOLANT TEMPERATURE SENSOR

*: Engine is warmed up sufficiently and running under no-load.

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 kΩ
50 (122)	0.68 - 1.00 kΩ
90 (194)	0.236 - 0.260 kΩ

CALCULATED LOAD VALUE

	Calculated load value % (Using CONSULT or GST)
At idle	16.8 - 34.7* (2WD) 15.9 - 33.2* (4WD)
At 2,500 rpm	14.1 - 27.6* (2WD) 13.3 - 26.1* (4WD)

^{*:} Engine is warmed up sufficiently and running under no-load.

HA

DX

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

INTAKE AIR TEMPERATURE SENSOR

Temperature °C (°F)	Resistance
20 (68)	2.1 - 2.9 kΩ
80 (176)	0.27 - 0.38 kΩ

REAR HEATED OXYGEN SENSOR HEATER

Resistance [at 25°C (77°F)]	Ω	11.4 - 17.4

CRANKSHAFT POSITION SENSOR (OBD)

Resistance [at 20°C (68°F)]	Ω	166.5 - 203.5

FRONT HEATED OXYGEN SENSOR HEATER

Resistance [at 25°C (77°F)]	0	2.3 - 4.3
Tiesistance [at 25 0 (77 1)]	35	2.0 - 4.0

ACCELERATOR CONTROL, FUEL & GI EXHAUST SYSTEMS

SECTION FE

MA

LC

EC

CONTENTS



ACCELERATOR CONTROL SYSTEM2	FUEL SYSTEM	@n
Adjusting Accelerator Wire2	Fuel Tank3	
	Fuel Pump and Gauge6	
	EXHAUST SYSTEM 7	MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

38

ST

RS


BT


HA

IDX

CAUTION:

- When removing accelerator wire, mark initial position of lock nut.
- Check that throttle valve opens fully when accelerator pedal is fully depressed. Check that throttle valve returns to idle position when accelerator pedal is released.
- Check accelerator control parts for improper contact with any adjacent parts.
- When connecting accelerator wire, do not twist or scratch the inner wire.
- For adjustment of A/T throttle wire, refer to AT section ("Throttle Wire Adjustment", "ON-VEHICLE SERVICE").





Adjusting Accelerator Wire CAUTION:

- Make sure the ASCD wire is not pulling the throttle drum.
- For ASCD wire adjustment, refer to EL section ["AUTO-MATIC SPEED CONTROL DEVICE (ASCD)"].
- Loosen lock nut, and tighten adjusting nut until throttle drum starts to move.
- 2. Loosen adjusting nut 1.5 to 2 turns and tighten lock nut.

Fuel Tank


WARNING:

When replacing fuel line parts, be sure to observe the following:

- Put a "CAUTION: FLAMMABLE" sign in workshop.
- Do not smoke while servicing fuel system. Keep open flames and sparks away from work area.
- Furnish workshop with a CO₂ fire extinguisher.

CAUTION:

- Before removing fuel line parts, carry out the following procedures:
- Put drained fuel in an explosion-proof container and put the lid on securely.
- Release fuel pressure from fuel line. Refer to EC section ("Fuel Pressure Release", "BASIC SER-VICE PROCEDURE").
- c. Disconnect battery ground cable.
- When installing fuel check valve, install it in the correct direction. Refer to EC section ("EVAPO-RATIVE EMISSION SYSTEM").
- Always replace O-ring with a new one.
- Do not kink or twist tubes and hoses during installation.
- To avoid damaging hoses, do not tighten hose clamps excessively.
- After installing tubes, run engine and check for fuel leaks at connections.
- Use only a genuine fuel filler cap as a replacement. If an incorrect fuel filler cap is used, the MIL may turn on.
- For inspection of EVAP shut valve, refer to EC section ("EVAPORATIVE EMISSION SYSTEM").



GI. MA

LC

FE

CL

MT

TF

ÆΙ

PD

FA

RA

BR

ST

RS

BT


KA

Fuel Tank (Cont'd)


REMOVAL

CAUTION:


- Do not disconnect any fuel line unless absolutely necessary.
- Plug hose and pipe openings to prevent entry of dust or dirt.



- 1. Release fuel pressure. Refer to EC section ("Fuel Pressure Release", "BASIC SERVICE PROCEDURE").
- 2. Disconnect battery ground cable.
- 3. Drain fuel from fuel tank.
- 4. Disconnect electrical connector.
- 5. Remove filler protector.
- 6. Disconnect filler tubes, fuel supply tube and fuel return tube.




7. Remove fuel tank protector.



8. Remove six fuel tank mounting bolts while supporting fuel tank.

FUEL SYSTEM

Fuel Tank (Cont'd)



9. Remove rear fuel tank mounting bracket.

GI

 $\mathbb{M}\mathbb{A}$

EM

LC

10. Remove fuel tank.

EC



AFE054

CL

MT

INSTALLATION

AT

To install, reverse the removal procedure.

CAUTION:

TF

Do not kink or twist hoses and tubes during installation.

To avoid damaging hoses, do not tighten hose clamps excessively.

PD

Tighten bolts to specified torque.

 After installation, run engine and check for leaks at connections.

FA

RA

BR

ST


R.S


BT

HA

EL

IDX





Fuel Pump and Gauge

REMOVAL

- 1. Remove fuel tank. Refer to FE-4.
- 2. Disconnect fuel supply tube, fuel return tube and electrical connector.
- 3. Remove the six screws.


4. Remove fuel pump and gauge.

INSTALLATION

To install, reverse the removal procedure.


CAUTION:

- Tighten bolts to specified torque.
 - 2.0 2.5 N·m (0.20 0.26 kg-m, 17.4 22.6 in-lb)
- Always replace O-ring with a new one.
- After installation, run engine and check for leaks at connections.



CAUTION:

- Replace exhaust gaskets with new ones when reassembling.
 - If gasket remains on flange surface, scrape off completely as shown at left.
- With engine running, check all tube connections for exhaust gas leaks, and entire system for unusual noises.
- Check to ensure that mounting brackets and mounting insulators are installed properly and are free from undue stress. Improper installation could result in excessive noise or vibration.
- Discard any heated oxygen sensor dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.



MA

GI

FΕ

Mī

AT

TF

PD)

FA

RA

BR

ST


RS

BT

HA

EL

IDX



CLUTCH

SECTION CL

MA

.....

em

LC

EC

FE

CONTENTS

PRECAUTIONS AND PREPARATION	
Precautions	
Special Service Tools	
Commercial Service Tools	
CLUTCH SYSTEM	
Clutch Pedal	
INSPECTION AND ADJUSTMENT	
Adjusting Clutch Pedal	
Bleeding Procedure	
• • • • • • • • • • • • • • • • • • • •	

HYDRAULIC CLUTCH CONTROL	7
Clutch Master Cylinder	7
Operating Cylinder	8
Clutch Damper	9
CLUTCH RELEASE MECHANISM	10
CLUTCH DISC AND CLUTCH COVER	12
Clutch Disc	12
Clutch Cover and Flywheel	13
SERVICE DATA AND SPECIFICATIONS (SDS)	14
General Specifications	14
Inspection and Adjustment	14



MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST ·

RS


BT

HA

EL

IDX

PRECAUTIONS AND PREPARATION



Precautions

- Recommended fluid is brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas.
- When removing and installing clutch piping, use a suitable tool.
- Use new brake fluid to clean or wash all parts of master cylinder, operating cylinder and clutch damper.
- Never use mineral oils such as gasoline or kerosene. They
 will ruin the rubber parts of the hydraulic system.

WARNING:

After cleaning the clutch disc, wipe it with a dust collector. Do not use compressed air.

Special Service Tools


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
ST20630000 (J26366) Clutch aligning bar	a b	Installing clutch cover and clutch disc
5 0	THE THE PROPERTY OF THE PROPER	a: 15.9 mm (0.626 in) dia.
		b: 22.8 mm (0.898 in) dia.
	NT405	c: 55 mm (2.17 in)
ST20050240 ()	a b	Adjusting unevenness of clutch cover dia- phragm spring
Diaphragm spring adjusting wrench		
		a: 150 mm (5.91 in)
	NT404	b: 25 mm (0.98 in)

Commercial Service Tools


Tool name	Description	
Flare nut crowfoot Torque wrench		Removing and installing clutch piping
	NT223	a: 10 mm (0.39 in)
Bearing puller	NT077	Removing release bearing
Bearing drift		Installing release bearing
	NT063	a: 50 mm (1.97 in) dia.

474 CL-2





ACL033


Clutch Pedal



INSPECTION AND ADJUSTMENT







Adjusting Clutch Pedal

1. Adjust pedal height with pedal stopper bolt or ASCD clutch switch.

Pedal height "H":

236 - 246 mm (9.29 - 9.69 in)

EG

LC

G1

MA

宫M

FE

CL

MT

Adjust pedal free play by turning master cylinder push rod. Then tighten lock nut.

Pedal free play "A":

9 - 16 mm (0.35 - 0.63 in)

Pedal free play, measured at pedal pad includes the following:

- Free play due to clevis pin and clevis pin hole, push rod and master cylinder.
- Make sure that clevis pin can rotate smoothly. If not, readjust pedal free play with master cylinder push rod.

TF

FA

PD)

RA

BR

ST


RS

BT

HA

EL

INSPECTION AND ADJUSTMENT





Adjusting Clutch Pedal (Cont'd)

4. Adjust clearance "C" shown in the figure while fully depressing clutch pedal.

Clearance "C":

0.3 - 1.0 mm (0.012 - 0.039 in)






Bleeding Procedure

- Carefully monitor fluid level at clutch master cylinder during bleeding operation.
- Bleed air from clutch operating cylinder according to the following procedures a through f.
- a. Fill reservoir with recommended brake fluid.
- b. Connect a transparent vinyl tube to air bleeder valve.
- c. Fully depress and release clutch pedal several times.
- d. While holding clutch pedal in the depressed position, open bleeder valve to release air.
- e. Close bleeder valve, then release clutch pedal.
- f. Repeat steps c through e above until brake fluid flows from air bleeder valve without air bubbles.
- 2. Bleed air from clutch damper by using the above procedures a through f.
- 3. Repeat the above bleeding procedures 1 and 2 several times.

Clutch Master Cylinder



DISASSEMBLY AND ASSEMBLY

- Use a screwdriver to remove stopper ring while pushing push rod into cylinder.
- When installing stopper ring, tap in lightly while pushing push rod into cylinder.

INSPECTION

CL-7

Check the following items, and replace as necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Return spring, for wear or damage
- Dust cover, for cracks, deformation or damage
- Reservoir, for deformation or damage

479

G

Mia

EMi

LC

EC

FE

CL

MT

TE

PD

RS

ST


BY

11

||D)X(

HYDRAULIC CLUTCH CONTROL

Operating Cylinder




INSPECTION

Check the following items, and replace as necessary.

- Rubbing surface of cylinder and piston, for uneven wear, rust or damage
- Piston with piston cup, for wear or damage
- Piston spring, for wear or damage
- Dust cover, for cracks, deformation or damage

HYDRAULIC CLUTCH CONTROL

Clutch Damper



INSPECTION

Check the following items, and replace as necessary.

Rubbing surface of cylinder and piston, for uneven wear, rust or damage

Piston with piston cup, for wear or damage

Damper rubber and plate for cracks, deformation or damage

Piston spring, for wear or damage

G]

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST


RS

BŢ

HA

EL

1DX



CLUTCH RELEASE MECHANISM


INSPECTION


Check the following items, and replace as necessary.

- Release bearing, to see that it rolls freely and is free from noise, cracks, pitting or wear
- Release sleeve and withdrawal lever rubbing surface, for wear, rust or damage

LUBRICATION

- Apply recommended grease to contact surface and rubbing surface.
- Too much lubricant might damage clutch disc facing.





WATERPROOF — for 4WD model

 Apply recommended sealant to contact surface of transmission case dust cover and withdrawal lever, then install dust cover clip.

Recommended sealant: Nissan genuine part (KP115-00100) or equivalent.

CL

G[

MA

EM

LC

EC

FE

MT

AT

TF

PD

RA

择為

BR

ST


R\$


Bit"


HA


EL

CLUTCH DISC AND CLUTCH COVER









Clutch Disc INSPECTION

Check the following items, and replace as necessary.

- Clutch disc, for burns, discoloration, oil or grease leakage
- Clutch disc, for wear of facing


Wear limit of facing surface to rivet head: 0.3 mm (0.012 in)


Clutch disc, for backlash of spline and runout of facing Maximum backlash of spline (at outer edge of disc): 1.0 mm (0.039 in) **Runout limit:** 1.0 mm (0.039 in) Distance of runout check point (from hub center): 115 mm (4.53 in)


INSTALLATION

- Apply recommended grease to contact surface of splines.
- Too much lubricant may damage clutch disc facing.

CLUTCH DISC AND CLUTCH COVER







Clutch Cover and Flywheel

INSPECTION AND ADJUSTMENT

 Check clutch cover, installed on vehicle, for uneven diaphragm spring toe height.

Uneven limit:

0.7 mm (0.028 in)

If out of limit, adjust the height using Tool.

FLYWHEEL INSPECTION

CAUTION:

Do not allow any magnetic materials to contact the ring gear teeth.

 Inspect contact surface of flywheel for slight burns or discoloration. Clean flywheel using emery paper.

Check flywheel runout.

Maximum allowable runout:

Refer to EM section ("Inspection", "CYLINDER BLOCK").

INSTALLATION

 Insert Tool into clutch disc hub while installing clutch cover and disc.

Be careful not to allow grease to contaminate clutch facing.

Tighten bolts in numerical order, in two steps.

First step:

(1.0 - 20 N·m (1.0 - 2.0 kg-m, 7 - 14 ft-lb)

Final step:

(2.2 - 29 N·m (2.2 - 3.0 kg-m, 16 - 22 ft-lb)

(III)

GI

MA

LUBD E

EM

LC

EC

CL

MT

AT

TE

[PID)

FA

RA

BR

ST

RS

BT

EL

MDX

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

CLUTCH MASTER CYLINDER

mm (in)	15.87 (5/8)	
ERATING CY	LINDER	
mm (in)	17.46 (11/16)	
//PER		
mm (in)	19.05 (3/4)	
	mm (in) MPER	

CLUTCH DISC

Model	240
Engine	KA24E
Facing size (Outer dia. x inner dia. x thickness) mm (in)	240 x 150 x 3.5 (9.45 x 5.91 x 0.138)
Thickness of disc assembly With load mm (in)	7.8 - 8.2 (0.307 - 0.323) with 4,413 N (450 kg, 992 lb)

CLUTCH COVER

Model		240
Engine		KA24E
Set-load	N (kg, lb)	4,413 (450, 992)

Inspection and Adjustment

CLUTCH PEDAL

	Unit: mm (in)
Pedal height "H"*	236 - 246 (9.29 - 9.69)
Pedal free play "A" (at pedal pad)	9 - 16 (0.35 - 0.63)
Clearance "C" between pedal stopper bracket and clutch pedal position switch (with clutch pedal fully depressed)	0.3 - 1.0 (0.012 - 0.039)

^{*:} Measured from surface of dash lower panel to pedal pad.

CLUTCH DISC

	Onic min (in)
Model	240
Wear limit of facing surface to rivet head	0.3 (0.012)
Runout limit of facing	1.0 (0.039)
Distance of runout check point (from hub center)	115 (4.53)
Maximum backlash of spline (at outer edge of disc)	1.0 (0.039)

CLUTCH COVER

ļ	J٢	m:	m	n	1	(11)

Model	240
Diaphragm spring height	37.5 - 39.5 (1.476 - 1.555)
Uneven limit of diaphragm spring toe height	0.7 (0.028)

486 CL-14

MANUAL TRANSMISSION

SECTION MT

D/ALAN

MA

LC

CONTENTS

PREPARATION	2
Special Service Tools	
Commercial Service Tools	
ON-VEHICLE SERVICE	
Replacing Rear Oil Seal - 2WD Model	
Position Switch Check	
REMOVAL AND INSTALLATION	5
MAJOR OVERHAUL	
Case Components	7
Gear Components — 2WD Model	
Gear Components — 4WD Model	9
Shift Control Components	
DISASSEMBLY	
Case Components	11
Shift Control Components	11
Gear Components	

INSPECTION	15
Shift Control Components	15
Gear Components	15
Gears And Shafts	15
Synchronizers	15
Bearings	
ASSEMBLY	17
Gear Components	<mark>1</mark> 7
Shift Control Components	23
Case Components	24
SERVICE DATA AND SPECIFICATIONS (SDS)	27
General Specifications	27
Inspection and Adjustment	28



CL

MT

T

ŢF

PD

FA

 $\mathbb{R}\mathbb{A}$

ST

RS

BT

HA

IDX

Special Service Tools


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
ST23810001		Fixing adapter plate with gear assembly
(—) Adapter setting plate		
	NT407	a: 166 mm (6.54 in) b: 270 mm (10.63 in)
KV32101330 (See J26349-A) Puller	a and a second s	Removing overdrive mainshaft bearing
	NT408	a: 447 mm (17.60 in) b: 100 mm (3.94 in)
KV31100401 (—) Transmission press stand		Pressing counter gear and mainshaft
\$T22520000	NT068	Tightening mainshaft lock nut
(J26348) Wrench		
	NT409	a: 100 mm (3.94 in) b: 41 mm (1.61 in)
ST23540000 (J25689-A) Pin punch	b	Removing and installing fork rod retaining pin
i iii puncii	NT442	a: 2.3 mm (0.091 in) dia. b: 4 mm (0.16 in) dia.
ST30031000 (J22912-01) Puller	a b	Removing and installing 1st gear bushing Removing main drive gear bearing
	NT411	a: 90 mm (3.54 in) dia. b: 50 mm (1.97 in) dia.
ST23860000		Installing counter drive gear
Drift	1610	a. 20 mm /1 50 in) dia
	NT065	a: 38 mm (1.50 in) dia. b: 33 mm (1.30 in) dia.
ST22360002 (J25679-01) Drift		Installing counter gear front and rear end bearings
Dint	NT065	a: 29 mm (1.14 in) dia. b: 23 mm (0.91 in) dia.
ST22350000 (J25678-01)		Installing OD gear bushing
Drift	NT065	a: 34 mm (1.34 in) dia. b: 28 mm (1.10 in) dia.

PREPARATION


Special Service Tools (Cont'd)				
Tool number (Kent-Moore No.) Tool name	Description		G1 M	
ST23800000 (J25691-01) Drift		Installing front cover oil seal		
	NTO65	a: 44 mm (1.73 in) dia. b: 31 mm (1.22 in) dia.		
ST33400001 (J26082) Drift		Installing rear oil seal	L(E(
	итове	a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.		
ST33290001 (J34286) Puller	a	Removing rear oil seal	FE CI	
	NT414	a: 250 mm (9.84 in) b: 160 mm (6.30 in)	M	
ST30720000 (J25405) Drift		Installing mainshaft ball bearing	AT	
	NT115	a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.	TF	
ST30613000 (J25742-3) Drift	b	Installing main drive gear bearing	<u> </u>	
	NT073	a: 71.5 mm (2.815 in) dia. b: 47.5 mm (1.870 in) dia.	FA	
ST33200000 (J26082) Drift		Installing counter rear bearing	R	
	NT091	a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.	18	
	Comme	ercial Service Tools	Sī	
Tool name	Description		RS	
Puller		Removing counter bearings, counter drive and OD gears	B7	
	NT077		HA	
Orift		Installing countershaft rear end bearing (FS5W71C-4WD model)	EL	
	NT074	a: 40 mm (1.57 in) dia. b: 30 mm (1.18 in) dia.]D)	

MT-3 489




Replacing Rear Oil Seal — 2WD Model REMOVAL

- 1. Remove the propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- 2. Remove rear oil seal using Tool.
- Always replace with a new seal once it has been removed.



INSTALLATION

- 1. Install new oil seal until it stops.
- Apply multi-purpose grease to seal lip of oil seal before installing.
- Install any part removed.



Position Switch Check

· Check continuity.

Switch	Gear position	Continuity
Pook up tomo quitab	Reverse	Yes
Back-up lamp switch	Except reverse	No
Noutral position switch	Neutral	Yes
Neutral position switch	Except neutral	No

490 MT-4

Removal

CAUTION:

Before separating the transmission from the engine, remove the crankshaft position sensor (OBD) from the transmission. Be careful not to damage sensor edge or ring gear teeth.

MA


EM

(G)

2WD MODEL

- 1. Remove battery negative terminal.
- Remove crankshaft position sensor (OBD) from transmission upper side.
- Remove clutch operating cylinder from transmission.
- 4. Remove back-up switch and neutral position switch harness connectors.
- Remove starter motor from transmission.
- 6. Remove propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- Insert plug into rear oil seal after removing propeller shaft.
- Be careful not to damage spline, sleeve yoke and rear oil seal when removing propeller shaft.





- 7. Remove control lever.
- 8. Support engine by placing a jack under oil pan.
- Do not place jack under oil pan drain plug.
- 9. Separate transmission from engine.

WARNING:

Support manual transmission while removing it.


PD

FA

TE

4WD MODEL

SMT478A



- Remove crankshaft position sensor (OBD) from transmission upper side.
- Remove clutch operating cylinder from transmission.
- Remove back-up switch and neutral position switch harness connector.
- Remove starter motor from transmission.
- 6. Remove front and rear propeller shafts. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- Insert plug into front and rear oil seals of transfer after removing propeller shafts.
- Be careful not to damage splines, sleeve yokes and front and rear oil seals of transfer when removing propeller shafts.
- Remove torsion bar springs. Refer to FA section ("Torsion Bar Spring", "FRONT SUSPENSION"). Then remove second crossmember.



ST

BŢ

AL.


EL

IDX



491

REMOVAL AND INSTALLATION



Removal (Cont'd)


- 8. Remove transmission and transfer control levers.
- 9. Support engine by placing a jack under oil pan.
- Do not place jack under oil pan drain plug.
- 10. Separate transmission with transfer from engine.


WARNING:

Support manual transmission with transfer while removing it.

Installation

1. Apply sealant to areas shown below: — 4WD model






2. Tighten bolts securing transmission.

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	ℓ mm (in)
1	39 - 49 (4.0 - 5.0, 29 - 36)	65 (2.56)
2	39 - 49 (4.0 - 5.0, 29 - 36)	58 (2.28)
③∗	16 - 22 (1.6 - 2.2, 12 - 16)	25 (0.98)
4	16 - 22 (1.6 - 2.2, 12 - 16)	16 (0.63)

^{*:} With nut


Tighten clutch operating cylinder to the specified torque. Refer to CL section ("CLUTCH SYSTEM").



AMT108

Gear Components — 2WD Model

SEC. 322




(G) Gear Components — 4WD Model SEC. 322 MA 3rd main gear -Needle bearing Coupling sleeve Baulk ring EM Mainshaft ball bearing-Snap ring 🛨 🔀 Thrust washer-Spread spring Pilot bearing LC 1st main gear Snap ring 🔀 1st gear bushing Main drive gear EC ball bearing 3rd & 4th synchronizer hub☆ Snap ring 🛨 🔀 - Shifting insert FE 1st and 2nd synchronizer hub 🏠 Insert spring Main drive gea CL Needle bearing 2nd outer baulk ring Baulk ring Synchronizer cone Coupling sleeve 2nd main gear Mainshaft lock nut Needle bearing 🗘 137 - 167 2nd inner baulk ring (14.0 - 17.0, 101 - 123) Mainshaft -Without Tool TF Mainshaft rear Thrust washer needle bearing Steel roller Fin Overdrive gear bushing PD) Steel ball Needle bearing Countershaft lock nut **[**] 98 - 127 (10.0 - 13.0, 72 - 94) Overdrive main gear -FA Roller bearing Baulk ring 🗸 Washer 🏡 Coupling sleeve Overdrive counter RA Shifting insert Reverse counter gear Overdrive & reverse Countershaft rear Reverse counter synchronizer hub end bearing BR gear spacer Shifting insert Counter rear bearing Snap ring 🔀 Baulk ring Spread spring Reverse idler ST thrust washer Counter gear Needle bearing Reverse idler Spread spring gear bearing Woodruff key RS Reverse idler gear Counter drive gear ☆ Reverse idler Sub-gear thrust washer BT Sub-gear spring 🏠 Snap ring 🔀 Reverse main Reverse idler shaft gear HA Reverse gear bushing Apply gear oil to gears, shafts, synchronizers Sub-gear bracket and bearings when assembling. Snap ring 🛨 🔀 Shim 🛊 * : Select proper thickness 킲 Countershaft front bearing x: Pay attention to its direction : N·m (kg-m, ft-lb) : Should be lubricated with grease IDX


AMT106


Shift Control Components

CAUTION:

To avoid damage when replacing shift knob, remove control lever with knob, as assembled.









Remove rear extension.

Remove control housing, check ball, return spring plugs, select check plungers and return springs. Also remove reverse check plug, check spring and check ball.

MA

Be careful not to lose check balls.

LC

Drive out striking lever retaining pin.


EC

Remove striking lever from striking rod.

FE

Remove rear extension by lightly tapping on it.

GL



2. Remove front cover, gasket, countershaft front bearing shim and main drive gear ball bearing snap ring.

Separate transmission case from adapter plate by lightly tapping on it.

TF

P(0)

FA

RA

Remove oil seal from front cover.

BR

Be careful not to damage mating surface of front cover.

RS

BT



Set up Tool on adapter plate.

Remove striking rod from adapter plate.

MA

Remove check ball plugs, check springs, and check balls.

EL



SMT035


SMT545A

ST23810001

IDX

Shift Control Components (Cont'd)

4. Drive out retaining pins. Then drive out fork rods and remove interlock balls.



-⊩-End play

Mainshaft or

bushing

Gear Components


1. Before disassembly, measure the end play of each gear.

 If end play is not within the specified limit, disassemble and inspect the parts.

Replace any part which is worn or damaged.


Gear end play:

Refer to SDS, MT-28.




SMT025

- Mesh 2nd and reverse gear, then remove countershaft front bearing using a suitable puller.
- 3. Remove snap ring, then remove sub-gear bracket, sub-gear spring and sub-gear.




- Remove counter drive gear together with main drive gear assembly using a suitable puller.
- When removing main drive gear assembly, be careful not to drop pilot bearing or baulk ring.
- 5. Remove snap ring, then remove 3rd & 4th synchronizer assembly and 3rd main gear.



- 6. Disassemble parts at rear of adapter plate as follows:
- a. Release staking on both countershaft and mainshaft nuts, then loosen both nuts.

Mainshaft nut: Left-hand thread

Gear Components (Cont'd)




Remove overdrive counter gear together with countershaft rear end bearing using a suitable puller.


Remove reverse counter gear and spacer.

Remove snap rings from reverse idler shaft, then remove reverse idler gear, thrust washers and reverse idler gear bear-

MA



Suitable puller





Remove 2nd gear needle bearing.


MA

EL

IDX








500

SMT420A

Gear Components (Cont'd)

- 9. Remove main drive gear ball bearing.
- a. Remove snap ring.b. Remove main drive gear ball bearing.

MT-14



Shift Control Components

Check contact and sliding surfaces of fork rods for wear, scratches, projections and other damage.

(G)

MA

LC

EC

FE

CL

MT

AT

TF



Check shafts for cracks, wear and bending. Check gears for excessive wear, chips and cracks.

PD)

FA

RA

BR

ST

RS

BT

MA


Check spline portion of coupling sleeves, synchronizer hubs and gears for wear, chips and cracks.


Check baulk rings for cracks and deformation.


Check shifting inserts for wear and deformation.

Check insert spread springs for deformation.

IDX








SYNCHRONIZERS

INSPECTION


Gear Components (Cont'd)




Measure clearance between baulk ring and gear.

Clearance between baulk ring and gear: Refer to SDS, MT-28.

If the clearance is less than the wear limit, replace baulk ring.






- Measure 2nd baulk ring wear-4WD model.
- Place baulk rings in position on synchronizer cone.
- While holding baulk rings against synchronizer cone as far as possible, measure dimensions "A" and "B".

Standard:

Inner "A": 0.7 - 0.9 mm (0.028 - 0.035 in) Outer "B": 0.6 - 1.1 mm (0.024 - 0.043 in)


Wear fimit:

0.2 mm (0.008 in) If dimension "A" or "B" is less than the wear limit, replace ${\bf B}$ baulk ring.





BEARINGS

Make sure all bearings roll freely and are free from noise, cracks, pitting or wear.




Gear Components





- Install bearings into case components. 1.
- 2. Assemble adapter plate parts.
- Install oil gutter on adapter plate and expand on rear side.
- Install bearing retainer.
- Insert reverse idler shaft, then install bearing retainer.



Tighten each screw, then stake each one at two points.

SMT674C Install main drive gear ball bearing. 3. Press main drive gear ball bearing.

SMT425A

ST30613000 (J25742-3)

- MA

IDX

MT-17

MA

G

LC

EC

FE

GL

MT

AT

TF


PD)

FA

RA BR

ST


RS




Gear Components (Cont'd)

b. Select and install proper main drive gear snap ring to achieve proper clearance of groove.


Allowable clearance of groove: 0 - 0.13 mm (0 - 0.0051 in) Main drive gear snap ring: Refer to SDS, MT-28.




- 4. Assemble synchronizers.
- 1st and 2nd (2WD model) synchronizer





Check coupling sleeve and synchronizer hub orientation.




2nd double baulk ring type synchronizer (4WD model)









Gear Components (Cont'd)

3rd & 4th synchronizer

Overdrive & reverse synchronizer

The three synchronizer gutters should be at the rear.

G

MA

LC

EC

厚层

ĈL

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA


EL

 $\mathbb{D}\mathbb{X}$


MT-19

505


Gear Components (Cont'd)




- 5. Assemble front side components to mainshaft.
- a. Install 2nd main gear, needle bearing and 1st & 2nd synchronizer assembly, then press 1st gear bushing on mainshaft.
- b. Install 1st main gear.




- c. Install steel ball and 1st gear washer.
- Before installation, apply multi-purpose grease to steel ball and to both sides of the 1st gear washer.



- 6. Install mainshaft and counter gear on adapter plate and main drive gear on mainshaft as follows:
- a. Press mainshaft assembly into adapter plate using Tool.




- b. Press counter gear into adapter plate using Tool.
- Install 3rd main gear and needle bearing, then press 3rd & 4th synchronizer assembly onto mainshaft.
- Pay attention to the direction of 3rd & 4th synchronizer.



d. Install front mainshaft snap ring.
Select proper front mainshaft snap ring to achieve proper clearance of groove.

Allowable clearance of groove: 0 - 0.18 mm (0 - 0.0071 in) Mainshaft front snap ring: Refer to SDS, MT-28.

 Apply gear oil to mainshaft pilot bearing and install it on mainshaft.



Sub-gear

SMT528A

TM366

TM443

Sub-gear spring

Sub-gear bracket

ST22360002 (J25679-01)

KV31100401

Gear Components (Cont'd)

Press counter drive gear together with main drive gear using Tool.

Pay attention to the direction of counter drive gear.

MA

EM

LC.

Install sub-gear components.

EC

Install sub-gear and sub-gear bracket on counter drive gear, then select proper snap ring to achieve proper clearance of groove.

FE

Allowable clearance of groove: 0 - 0.18 mm (0 - 0.0071 in)

CL

Counter drive gear snap ring: Refer to SDS, MT-28.

MT

(2) Remove snap ring, sub-gear bracket and sub-gear from counter gear.

(3) Reinstall sub-gear, sub-gear spring and sub-gear bracket.

AT

Install selected counter drive gear snap ring.

TF

(D)

FA

RA

Press countershaft front bearing onto counter gear using Tool.


BR

ST

RS

HA


1DX




- Install rear side components on mainshaft and counter gear as follows:
- Install reverse idler gear to reverse idler shaft along with spacers, snap rings and reverse idler gear bearing.

Gear Components (Cont'd)

- Install bushing, reverse main gear and overdrive & reverse synchronizer to mainshaft.
- Pay attention to the direction of synchronizer hub.




- c. Install overdrive gear bushing to mainshaft using Tool.
 d. Install overdrive main gear and needle bearing to mainshaft.
 e. Install spacer, reverse counter gear and overdrive counter gear to countershaft.
 - OD main gear and OD counter gear should be handled as a matched set.
 - f. Install washer, roller bearing, steel roller and thrust washer.
 - g. Tighten mainshaft lock nut temporarily.
 - Always use new lock nut.



ST22350000


(J25678-01)

h. Install countershaft rear end bearing using Tool.



- Mesh 2nd and reverse gears, then tighten mainshaft lock nut using Tool.
- Always use new lock nut.
 Mainshaft lock nut:

(14.0 - 17.0 kg-m, 101 - 123 ft-lb)



Gear Components (Cont'd)

 Use the chart shown at left to determine the proper reading torque.

(Length of torque wrench vs. setting or reading torque)

Tighten countershaft lock nut.

Always use new lock nut.
 Countershaft lock nut:

(10.0 - 13.0 kg-m, 72 - 94 ft-lb)

MA

G


EM

LC

EC

CL

MT



 Stake mainshaft lock nut and countershaft lock nut using a punch.

11. Measure gear end play. Refer to "Gear Components", "DISASSEMBLY", MT-12.

TF

PD

 $\mathbb{F}\mathbb{A}$

RA



 Install fork rods, interlock plunger, interlock balls and check balls.

BR

ST


RS


BT

HA

EL

IDX







2. Install 1st & 2nd shift fork, then drive in retaining pin.

MT-23


Shift Control Components (Cont'd)



3. Install 3rd & 4th shift fork, then drive in retaining pin.




4. Install overdrive & reverse shift fork, then drive in retaining pin.




Case Components

- 1. Install front cover oil seal using Tool.
- Apply multi-purpose grease to seal lip.



- 2. Apply sealant to mating surface of transmission case as shown at left.
- Use anaerobic liquid gasket Loctite P/N 51813 or equivalent.




3. Slide gear assembly onto adapter plate by lightly tapping it using a soft hammer.

0 0 SMT672A

Case Components (Cont'd)

4. Install main drive gear ball bearing snap ring.




LC

Apply sealant to mating surface of adapter plate as shown at

Use anaerobic liquid gasket Loctite P/N 51813 or equivalent.

FE

CL.



Sealant

6. Place shift forks in neutral position.

Install striking lever and rod onto adapter plate and align striking lever with shift brackets.

PD

FA

TF

Install rear extension.

 $\mathbb{R}\mathbb{A}$

Fit main drive bearing snap ring.

BR


ST

RS

BT

HA

I




10. Install striking rod lock pin.



SMT800B

MT-25

Case Components (Cont'd)




AMT092

- 11. Select countershaft front bearing shim.

 Countershaft front bearing shim:

 Refer to SDS, MT-29.
- 12. Install gasket and front cover.



Transmission case

Countershaft front bearing

3 Counter gear

- 13. Install return spring plugs, check ball, return springs and select check plungers.
- 14. Install control housing and gasket.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Applied model	2WD	4WD
Transmission	FS5W71C	
Number of speed		5
Shift pattern	1 3 5 N N N N N N N N N N N N N N N N N N N	
Synchromesh type	Wa	arner
Gear ratio		
1st	3.321	3.985
2nd	1.902	2.246
3rd	1.308	1.415
4th	1.000	1.000
OD	0.838	0.821
Reverse	3.382	3.657
Number of teeth		}
Mainshaft		
Drive	22	21
1st	33	34
2nd	27	28
3rd	26	26
OD	22	21
Reverse	36	36
Countershaft		
Drive	31	32
1st	14	13
2nd	20	19
3rd	28	28
OD	37	39
Reverse	15	15
Reverse idler gear	21	21
Oil capacity ℓ (US pt, Imp pt)	2.0 (4-1/4, 3-1/2)	4.9 (10-3/8, 8-5/8)
	Reverse sy	nchronizer
Remarks	_	2nd double baulk ring type synchro- nizer

GI

MA

EM

LC

ĒC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

BT

HA

EL

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

GEAR END PLAY

Unit: mm (in) 1st gear 0.31 - 0.41 (0.0122 - 0.0161) 2nd gear 0.11 - 0.21 (0.0043 - 0.0083) 3rd gear 0.11 - 0.21 (0.0043 - 0.0083) Overdrive gear 0.24 - 0.41 (0.0094 - 0.0161)


CLEARANCE BETWEEN BAULK RING AND GEAR

Unit: mm (in)

	Onit: mm (in)
Standard	
1st & 2nd (2WD)	1.20 - 1.60 (0.0472 - 0.0630)
3rd & main drive	1.20 - 1.60 (0.0472 - 0.0630)
Overdrive	1.20 - 1.60 (0.0472 - 0.0630)
Reverse	1.10 - 1.55 (0.0433 - 0.0610)
Wear limit	
1st & 2nd (2WD)	0.80 (0.0315)
3rd & main drive	0.80 (0.0315)
Overdrive	0.80 (0.0315)
Reverse	0.70 (0.0276)
	

2nd baulk ring (4WD model)

Unit: mm (in)



SMT733C

Dimension	Standard	Wear limit
Α	0.7 - 0.9 (0.028 - 0.035)	0.0 (0.000)
В	0.6 - 1.1 (0.024 - 0.043)	0.2 (0.008)

AVAILABLE SNAP RINGS

Main drive gear bearing

Allowable clearance	0 - 0.13 mm (0 - 0.0051 in)
Thickness mm (in)	Part number
1.87 (0.0736)	32204-78001
1.94 (0.0764)	32204-78002
2.01 (0.0791)	32204-78003

Mainshaft front

Allowable clearance	0 - 0.18 mm (0 - 0.0071 in)
Thickness mm (in)	Part number
2.4 (0.094)	32263-V5200
2.5 (0.098)	32263-V5201

Mainshaft rear end bearing (2WD model)

Allowable clearance	0 - 0.14 mm (0 - 0.0055 in)
Thickness mm (in)	Part number
1.1 (0.043)	32228-20100
1.2 (0.047)	32228-20101
1.3 (0.051)	32228-20102
1.4 (0.055)	32228-20103

Counter drive gear

Allowable clearance	0 - 0.18 mm (0 - 0.0071 in)
Thickness mm (in)	Part number
1.4 (0.055)	32215-E9000
1.5 (0.059)	32215-E9001
1.6 (0.063)	32215-E9002


SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

AVAILABLE SHIMS

Countershaft front bearing

Unit: mm (in)



AMT092

"A"	Thickness of shim	Part number
4.52 - 4.71 (0.1780 - 0.1854)	Not ned	cessary
4.42 - 4.51 (0.1740 - 0.1776)	0.1 (0.004)	32218-V5000
4.32 - 4.41 (0.1701 - 0.1736)	0.2 (0.008)	32218-V5001
4.22 - 4.31 (0.1661 - 0.1697)	0.3 (0.012)	32218-V5002
4.12 - 4.21 (0.1622 - 0.1657)	0.4 (0.016)	32218-V5003
4.02 - 4.11 (0.1583 - 0.1618)	0.5 (0.020)	32218-V5004
3.92 - 4.01 (0.1543 - 0.1579)	0.6 (0.024)	32218-V5005

GI

MA

EM

LC

EC

FE

CL

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

IDX

AUTOMATIC TRANSMISSION

SECTION AT

CONTENTS

PREPARATION AND PRECAUTIONS	2	REMOVAL AND INSTALLATION	40
Special Service Tools	2	Removal	40
Precautions For Supplemental Restraint System		Installation	41
(SRS) "AIR BAG"	4	MAJOR OVERHAUL	42
Precautions	4	Oil Channel	44
OVERALL SYSTEM	5	Locations of Needle Bearings, Thrust Washers	
Circuit Diagram	5	and Snap Rings	45
Wiring Diagram		DISASSEMBLY	
Cross-Sectional View	8	Disassembly	46
Hydraulic Control Circuits	9	REPAIR FOR COMPONENT PARTS	
Shift Mechanism		Oil Pump	57
TROUBLE DIAGNOSIS — Basic Inspection	12	Control Valve Assembly	
Remarks		Control Valve Upper Body	66
A/T Fluid Check	12	Control Valve Lower Body	
Road Test	12	Governor Valve Assembly	
Shift Schedule	14	Parking Gear	
TROUBLE DIAGNOSIS — General Description	16	Reverse Clutch	
Symptom Chart		High Clutch	
TROUBLE DIAGNOSIS FOR DTC P1550		Forward and Overrun Clutches	79
Torque Converter Clutch Solenoid Valve	20	Low & Reverse Brake	
TROUBLE DIAGNOSES	22	Forward Clutch Drum Assembly	86
Component Inspection		Rear Internal Gear and Forward Clutch Hub	88
Final Check		Band Servo Piston Assembly	90
TROUBLE DIAGNOSES — A/T Shift Lock		Parking Pawl Components	
System	30	ASSEMBLY	96
Description		Assembly (1)	96
Shift Lock System Electrical Parts Location	30	Adjustment	
Wiring Diagram		Assembly (2)	
Diagnostic Procedure	32	SERVICE DATA AND SPECIFICATIONS (SDS)	
Key Interlock Cable		General Specifications	
Component Check		Specifications and Adjustment	
ON-VEHICLE SERVICE		Vehicle Speed When Shifting Gears	
Control Valve Assembly and Accumulators		Vehicle Speed When Performing And	
Inspection	37	Releasing Lock-Up	113
Rear Oil Seal Replacement	37	Stall Revolution	
Parking Components Inspection		Line Pressure	
Governor Valve		Return Springs	
Throttle Wire Adjustment		Accumulator O-Ring	
Inhibitor Switch Adjustment		Clutches And Brakes	
Manual Control Linkage Adjustment		Oil Pump And Low One-Way Clutch	

CONTENTS (Cont'd.)

GI Reverse Clutch Drum End Play......116 Total End Play116 $\mathbb{M}\mathbb{A}$ Parking Gear.....116 Removal And Installation116 When you read wiring diagrams: • Read GI section, "HOW TO READ WIRING DIAGRAMS". • See EL section, "POWER SUPPLY ROUTING" for power distribution circuit. When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW ILC **CHART IN TROUBLE DIAGNOSES".** EC Æ CL MIT AT TF

PD

RA

BR

ST

RS

BT

[=]A

EL

IDX

PREPARATION AND PRECAUTIONS

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
(J34301-C) Oil pressure gauge set ① (J34301-1) Oil pressure gauge ② (J34301-2) Hose ③ (J34298) Joint pipe ④ (J34282-2) Adapter ⑤ (790-301-1230-A) 60° Adapter ⑥ (J34301-15) Square socket	AAT546	Measuring line pressure and governor pressure
ST07870000 (J37068) Transmission case stand	NT421	Disassembling and assembling A/T a: 182 mm (7.17 in) b: 282 mm (11.10 in) c: 230 mm (9.06 in) d: 100 mm (3.94 in)
KV31102100 (J37065) Torque converter one-way clutch check tool	NT098	Checking one-way clutch in torque converter
ST25850000 (J25721-A) Sliding hammer	a d	Removing oil pump assembly
	NT422	a: 179 mm (7.05 in) b: 70 mm (2.76 in) c: 40 mm (1.57 in) dia. d: M12 x 1.75P
KV31102400 (J34285 and J34285-87) Clutch spring compressor	a a a a a a a a a a a a a a a a a a a	Removing and installing clutch return springs
	NT423	a: 320 mm (12.60 in) b: 174 mm (6.85 in)

PREPARATION AND PRECAUTIONS

	Specia	I Service Tools (Cont'd)	an an
Tool number (Kent-Moore No.) Tool name	Description		GI MA
ST33200000 (J26082) Drift		Installing oil pump housing oil seal Installing rear oil seal	EM
	NT091	a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.	LC
ST30720000 (J34331) Drift	1,100	Installing rear oil seal	EC
	NT115	a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.	FE
(J34291) Shim setting gauge set		Selecting oil pump cover bearing race and oil pump thrust washer	CL
	NT101		MT

AT

TF

PD

FA

RA

1918

ST

RS

BT

HA



Precautions For Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Precautions

- Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transmission.
- Place disassembled parts in order for easier and proper assembly.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced anytime the transmission is disassembled.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place removed parts in order, on a parts rack, so they can be put back in the valve body in the same positions and sequences. Care will also prevent springs and small parts from becoming scattered or lost.

- Properly installed valves, sleeves, plugs, etc. will slide along their bores in the valve body under their own weight.
- Before assembly, apply a coat of recommended ATF to all parts. Apply petroleum jelly to protect O-rings and seals, or hold small bearings and washers in place during assembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer.
- After overhaul, refill the transmission with new ATF
- When the A/T drain plug is removed, only some of the fluid is drained. Old A/T fluid will remain in torque converter and ATF cooling system. Always follow the procedures under "Changing A/T Fluid" in the MA section when changing A/T fluid.

Circuit Diagram



BR

G[

ST

RS


BT

HA

 $\mathbb{D}\mathbb{X}$


Wiring Diagram AT-A/T-01 IGNITION SWITCH ON or START Refer to "EL-POWER". (AS): With ASCD 10A 11 W/B JOINT CONNECTOR-2 (M142) Next 20 ■ W/B page W/B 19 1 w/B SOLENOID DATA W/B N1 LINK CONNECTOR VALVE UNIT OVERDRIVE CANCEL SOLENOID VALVE TORQUE CONVERTER CLUTCH SOLENOID VALVE FOR (M27)CONSULT 17 M153 COMBINATION 2 13 3 METER (O/D OFF INDICATOR 6 W/G ŪΥ LAMP) AS To EL-ASCD (N4) 14 9 DIODE (M156) (N1)(M155) GY ■E15 ■ GΥ L/Y 而 114 ECM (ECCS CONTROL MODULE) DEVICE (OVERDRIVE CONTROL SWITCH) (M174) (M112) В (M177)Refer to last page (Foldout page). (M142) M155, N1 1 2 3 4 5 M156 6 7 8 9 10 L 1 2 3 4 5 6 7 M153 0 8 9 10 11 12 13 14 N4) **FIR** (M112) H.S W 40 41 53 54 55 44 45 46 57 58 59 60 47 48 62 63 64 65 51 52 66 67 68 69 56 61 1 2 3 20 21 22 23 38 39 5 6 7 8 9 11 12 13 14 15 16 17 18 24 25 26 27 28 29 30 31 32 33 42 43 49 50 10 107 108 109 110 112 19 70 113 114 115 116 117 118

Wiring Diagram (Cont'd)




AAT790-B

Cross-Sectional View



Hydraulic Control Circuits



AAT033A

G


Shift Mechanism

The RL4R01A automatic transmission uses compact, dual planetary gear systems to improve power-transmission efficiency, simplify construction and reduce weight.

It also employs an optimum shift control and superwide gear ratios to improve starting performance and acceleration during medium and high-speed operation.

Two one-way clutches are also employed: one is used for the forward clutch and the other for the low clutch. These one-way clutches, combined with four accumulators, reduce shifting shock to a minimum.

CONSTRUCTION



OVERALL SYSTEM

Shift Mechanism (Cont'd)

FUNCTION OF CLUTCH AND BRAKE

Clutch and brake components	Abbr.	Function
6 Reverse clutch	R/C	To transmit input power to front sun gear 9.
7 High clutch	H/C	To transmit input power to front planetary carrier (1).
16 Forward clutch	F/C	To connect front planetary carrier (1) with forward one-way clutch (17).
(18) Overrun clutch	O/C	To connect front planetary carrier (1) with rear internal gear (14).
5 Brake band	B/B	To lock front sun gear 9.
7 Forward one-way clutch	F/O.C	When forward clutch (16) is engaged, to stop rear internal gear (14) from rotating in opposite direction.
19 Low one-way clutch	L/0.C	At D ₁ position, to prevent rear internal gear (14) from rotating in opposite direction.
20 Low & reverse brake	L & R/B	To lock rear internal gear (4) (2, 1 ₂ and 1 ₁), to lock front planetary carrier (1) (R position).

OPERATION OF CLUTCH AND BRAKE

							Da-d		Forward	Low	Low &			
	hift sition	Reverse clutch	High clutch	Forward clutch	Overrun clutch 18	2nd apply	3rd release	4th apply	one-way clutch	one-way clutch	reverse brake	Lock-up	Remarks	[
	Р												PARK POSITION	
	R	0									0		REVERSE POSITION	
	N												NEUTRAL POSITION	c
	1st			0	⊗				•					
D	2nd			0	*1 🔘	0							Automatic shift	
*4	3rd		\circ	0		+2⊗	\otimes		•			*5	$1 \leftrightarrow 2 \leftrightarrow 3 \leftrightarrow 4$	Г
	4th		\circ	\otimes		*3	\otimes	0				0		
2	1st			0	8								Automatic shift	ſ
	2nd			0	0	0	:						1 ↔ 2	
1	1st			0	\circ				•		0		Locks (held stationary) in 1st	[
'	2nd			0	0	0			•				speed 1 ← 2	

[:] Operates when overdrive control switch is set in OFF position.

AT-11 527

CL.

@]

MA

LC

EC

MT

PD)

TE

FA

RA

BR

R\$

BT

HA

EL

[:] Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

^{*4} : A/T will not shift to 4th when overdrive control switch is set to OFF position.

[:] Operates when overdrive control switch is set to OFF position.

^{):} Operates.

^{():} Operates when throttle opening is less than 1/16, activating engine brake.

[:] Operates during "progressive" acceleration.

⁽X): Operates but does not affect power-transmission.


^{(3):} Operates when throttle opening is less than 1/16 but does not affect engine brake.

Remarks

ATF COOLER SERVICE

If the oil pan contains large quantities of foreign matter or the strainer is excessively clogged, replace the ATF cooler.

 ATF cooler is not serviceable separately from the radiator. If service is required, replace radiator assembly.



A/T Fluid Check

FLUID LEAKAGE CHECK

- Clean area suspected of leaking, for example, mating surface of converter housing and transmission case.
- Start engine, apply foot brake, place selector lever in "D" position and wait a few minutes.
- 3. Stop engine.
- 4. Check for fresh leakage.



FLUID CONDITION CHECK

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling — Overheating

FLUID LEVEL CHECK

Refer to MA section ("Checking A/T Fluid", "CHASSIS AND BODY MAINTENANCE").

Road Test

Perform road tests using "Symptom" chart. Refer to AT-16.

"P" POSITION

- 1. Place selector lever in "P" position and start the engine. Stop the engine and repeat the procedure in all positions, including "N" position.
- Stop vehicle on a slight upgrade and place selector lever in "P" position. Release parking brake to make sure vehicle remains locked.

"R" POSITION

- Manually move selector lever from "P" or "R", and note shift quality.
- 2. Drive vehicle in reverse long enough to detect slippage or other abnormalities.

TROUBLE DIAGNOSIS — Basic Inspection

Road Test (Cont'd)

"N" POSITION

- Manually move selector lever from "R" and "D" to "N" and note shift quality.
- Release parking brake with selector lever in "N" position. Lightly depress accelerator pedal to make sure vehicle does not move. (When vehicle is new or soon after clutches have been replaced, vehicle may move slightly. This is not a problem.)



MA


I.C


EG

FE

CL.


MT





"D" POSITION

- Manually shift selector lever from "N" to "D" position, and note shift quality.
- 2. Using the shift schedule as a reference, drive vehicle in "D" position. Record, on symptom chart, respective vehicle speeds at which up-shifting and down-shifting occur. These speeds are to be read at three different throttle positions (light, half and full), respectively. Also determine the timing at which shocks are encountered during shifting and which clutches are engaged.



- 4. Check to determine if shifting to overdrive gear cannot be made while overdrive control switch is OFF.
- 5. Drive vehicle at 65 to 80 km/h (40 to 50 MPH) with half to light throttle position (D₃ position). Fully depress accelerator pedal to make sure transmission downshifts from 3rd to 2nd gear.
- Drive vehicle at 35 to 45 km/h (22 to 28 MPH) with half to light throttle position (D₂ position). Fully depress accelerator pedal to make sure transmission downshifts from 2nd to 1st gear.

AT

PD

FA

RA

BR

ST

RS

HA

IDX

"2" POSITION

- 1. Shift to "2" position and make sure vehicle starts in 1st gear.
- 2. Increase vehicle speed to make sure transmission upshifts from 1st to 2nd gear.
- 3. Further increase vehicle speed. Make sure transmission does not upshift to 3rd gear.
- 4. Drive vehicle at 35 to 45 km/h (22 to 28 MPH) with throttle at half to light position (2₂ position). Fully depress accelerator pedal to make sure transmission downshifts from 2nd to 1st gear.
- 5. Drive vehicle at idle in "2" position to make sure that transmission downshifts to 1st gear.
- 6. Move selector lever to "D" position and drive vehicle at 40 to 50 km/h (25 to 31 MPH). Then, move selector lever to "2" position to make sure transmission downshifts to 2nd gear.

"1" POSITION

- 1. Place selector lever in "1" position and accelerate. Make sure transmission does not shift from 1st to 2nd gear although vehicle speed increases.
- 2. While driving vehicle in "1" position, release accelerator pedal to make sure that engine compression acts as a brake.
- 3. Place selector lever in "D" or "2" position and drive vehicle at 20 to 30 km/h (12 to 19 MPH). Then move selector lever to "1" position to make sure transmission downshifts to 1st gear.

AT-13 529

TROUBLE DIAGNOSIS — Basic Inspection

Shift Schedule

VEHICLE SPEED WITH SHIFTING GEARS

This check should be carried out when ATF temperature is between 50 and 80°C (122 and 176°F) after the vehicle has been driven approx. 10 minutes.

Vehicle speed when shifting gears

Throttle			Veh	nicle speed km/h (M	IPH)		
position	$D_1 \rightarrow D_2$	$D_2 \rightarrow D_3$	$D_3 \rightarrow D_4$	$D_4 \rightarrow D_3$	$D_3 \rightarrow D_2$	$D_2 \rightarrow D_1$	1 ₂ → 1 ₁
Full throttle	53 - 57 (33 - 35)	100 - 108 (62 - 67)	_	147 - 157 (91 - 98)	91 - 99 (57 - 62)	47 - 51 (29 - 32)	41 - 45 (25 - 28)
Half throttle	32 - 36 (20 - 22)	57 - 65 (35 - 40)	114 - 124 (71 - 77)	65 - 75 (40 - 47)	28 - 36 (17 - 22)	12 - 16 (7 - 1 0)	41 - 45 (25 - 28)

Vehicle speed when performing and releasing lock-up

	·)4
Throttle position	Vehicle spee	d km/h (MPH)
	Lock-up ON	Lock-up OFF
Full throttle	_	_
Half throttle	71 - 79 (44 - 49)	71 - 79 (44 - 49)

TROUBLE DIAGNOSIS — Basic Inspection

NOTES

Gi

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BŢ

HA

AT-15

531

TROUBLE DIAGNOSIS — General Description

Symptom Chart

	Cympion.							OI	N VE	HIC	LE						→
Numbers are arranged in order Perform inspections starting wit Numbers in the OFF VEHICLE must be removed from the vehi	h number one and work up. columns indicate that the transmission cle to perform the inspection.	Oil level and oil quality	Control linkage	Inhibitor switch and wiring	Throttle wire	Engine idling speed	Line pressure	Control valve	4th speed cut valve	Pressure regulator valve	Pressure modifier valve	1-2 shift valve	2-3 shift valve	3-4 shift valve	Accumulator control vaive	3-2 downshift valve	2-3 throttle modifier valve
Sharp shocks in shifting from "N"	to "D" position	1	2		5	3	4	8		2 St W	\$ 18. 1 \$1. 8;				K 186 1		
	When shifting from 1st to 2nd or 2nd to 3rd	1	2		4		3	7									
	When shifting from 3rd to 4th	1	2		4		3	6	2 45 E	\$1 18 19 \$1 18 19	***				·		
Shift shocks	When shifting from "D" to "2" and "1" position. When overdrive control switch is set from ON to OFF	1	2		4		3	5									
	When shifting from 2nd to 1st in "1" position	1	2		4		3	5		新·新·特 3. 深·请	* * * * * * * * * * * * * * * * * * * *						
	When shifting from 1st to 2nd	1	2		4		3	6		# # # #	10 10 14 17 18						
Shift slippage when upshifting	When shifting from 2nd to 3rd	1	2		4		3	6		1:4: 1	(ei of (filig						
	When shifting from 3rd to 4th	1	2		4		3	6			# 0 # 2						
	When shifting from 4th to 2nd	1	2		5	•	3	7		* # 4	# - 64 . G: 353					\Box	
Shift slippage with accelerator pedal depressed	When shifting from 4th to 3rd	1	2		4	•	3	6		+ 14 H + 14 J	141 187 1 181 182					\dashv	
	When shifting from 4th to 1st and shifting from 3rd to 1st	1	2		5		3	7		計 別 12 別 額 2 等 費	# ## ## # ## ## : #! ##						
Poor power/acceleration	When vehicle starts	1	2		5		\dashv	10		湯漬	ii ii i						
		1	2		4		3	8		å & € €	23 23				.	\Box	
	position	1	2		4		3	6		€ - 61-4 € 24-4	· (8) (8)						
No engine braking	When shifting from 4th to 1st and shifting from 3rd to 1st When vehicle starts When upshifting When upshifting When upshifting When shifting from "D" to "2" and "1" position When overdrive control switch is set from ON to OFF When shifting from 2nd to 1st in "1" position Too low a gear change point from 2nd to 3rd and from 3rd to 2nd.																
		1	2		4		3	6	•	6 to 1	· (4:						
		1		-	4		2	5								í	
Shift quality	Too high a gear change point from 2nd to 3rd and from 3rd to 2nd.	1			4		2	5									
Shift quality	Too low a gear change point from 2nd to 1st in "1" position.	1			4		2	5	*		* * *		4				
	Too high a gear change point from 2nd to 1st in "1" position.	1			4		2	5									

TROUBLE DIAGNOSIS — General Description

Symptom Chart (Cont'd)

-										ON	VEH	IICLI	Ε									-	 			(ÖFF	VEF	HCLE	Ē			→	 M/
4-2 relay vaive	Torque converter clutch control valve	Throttle valve & detent valve	Manual valve	Kickdown modifier valve	1st reducing valve	Overrun clutch reducing valve	3-2 timing valve	Torque converter relief valve	4-2 sequence valve	Governor pressure	Governor valve	Primary governor valve	Secondary governor valve (1)	Secondary governor valve (2)	Overdrive cancel solenoid valve	Torque converter clutch solenoid valve	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter motor	overdrive control switch and wiring	Torque converter	Oit pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse clutch	Brake band	Parking components	EM LC EC
-) 11 W		13.5					<u> </u>		ļ .		 	<u> </u>			6	•		7					9			-				•		
										-								5	6					-										GL
1											-		\vdash							5				-					8			7		1
																										7		,			-	6		IMT
					****					-																				6				ΙA
		193 196 . At 164		\$ 18 ; 18 41 1						·					-			5														7		TF
		N 4		12. 13; :						Ŀ								٠	5	٠		٠		·		8						7		
		1 18 181 1 18 18 18 18 18 18 18 18 18 18 18 18 18		\$ 45 \$ 46 48 48					Ø1 - 80 - 10			((0) 1	h i da liir	D: 00 01	<u>.</u>					5			٠			8	,			-	-	7	•	
_		i de del Liè de Liè de Brierde		42 Mg					\$1 :3% .3 \$1 !\$1 :0	4	11	400 4	建造建	9:0 A	·	·	6	8	9	7			12		14	15	17	18	19	20	21	26	٠	ໍັ
				# # # # # #			(4) (4) (4) (4)			4	8			11年の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の日本の			<u></u>	5	6 6	7	•			9		10 9		11		<u> </u>	13	10	•	F/
				700 MB			107 - 100					1:1枚	章 举 對	\$1 167 18	-				5							7	8							t
1					-		- 14 - 14 - 14			4	8	8 8	43 Ry II 43 Ry II	* *					6								9					-		R
															-	-		-	5	-		-		-	-			-	7	-	-			- B
				•	(0: 44) (0: 44)					-					7				5	-		6					•	•	9	•		•	•	
	n unga /25/				191 : 48 191 : 48							31 · M		量 許は												٠		-	7		8	•		\$ 1
										3	6	± . ₩	提: 36 日															•		•			٠	R
		., % . 41								3		2002:00	2 .000 .000 13								-		•		•					-		•	,	
		: #:# : #:# : #:#								3	6							•	•		-				•			•	-			•	-	
										3	6		· 🕯 🗑		٠	•		•		•									•				-	

AT-17 533

GI

EL

TROUBLE DIAGNOSIS — General Description Symptom Chart (Cont'd)

`		-						0	N VE	HIC	LE		-		 	-
Numbers are arranged in orde Perform inspections starting w Numbers in OFF VEHICLE co removed from the vehicle to positive in the vehicle to be with the vehicle	ith number one and work up. lumns indicate that the transmission must be erform the inspection.	Oil level and oil quality	Control linkage	Inhibitor switch and wiring	Throttle wire	Engine idling speed	Line pressure	Control valve	4th speed cut valve	Pressure regulator valve	# Pressure modifier valve Pressure modi	2-3 throttle modifier valve				
	Failure to change gear from 4th to 2nd with accelerator pedal depressed.	1			4		2	5								
	Failure to change gear from 3rd to 2nd with accelerator pedal depressed.	1			4		2	5								
	Failure to change gear from 1st to 2nd in "D" and "2" position.	1			4		2	5				H . S. S				
Shift quality	Vehicle does not start from 1st in "D" and "2" position.	1	-		4		2	5				: \$ i.k				
	Failure to change gear to 3rd to 4th in "D" position.	1			4		2	7					18 si :	10: 20 ₩ 14:		
	Changes gear to 1st directly when selector lever is set from "D" to "1" position.	1			4		2	5								
	Changes gear to 2nd in "1" position.	1			4		2	5		;; H :						
	Too high or low a change point when lock-up operates.	1		. 1	4		2	5		3. 10	# 13					
	Lock-up point is extremely high or low.	1			4		2	5	48 -34 -0:10	(i - : 4: : 3: · - €;						
Lock-up quality	Torque converter does not lock-up.	1			4		2	5	: 35 3							
Look up quality	Lock-up is not released when accelerator pedal is released.	1														
Engine does not start in "P" ar engine starts in positions other			2	3												
Vehicle moves with selector lev	ver in "P" position.		1	,												

TROUBLE DIAGNOSIS — General Description Symptom Chart (Cont'd)

←										ON	VEH 	ICLI		_			m (-				,	OFF	VEH	HCL	E			-	
	/alve															valve						lng												
	h control v	valve		g g		g valve		valve					alve	alve ②	oid valve	n solenoid					rter motor	th and wir						Ę			:		:	
<u>×</u> e	erter clutcl	/e & detent	ø	odifier valv	yvalve	tch reducin	alve	rerter relief	se valve	essure	alve	ernor valve	governor va	governor va	ancel soler	rerter cluto	N-D	r 1-2	r 2-3	r 3-4 (N-R)	ch and sta	ontrof switc	erter		ᇋ		tch	e-way cluto	덮	y clutch	se clutch		ponents	
4-2 relay valve	Torque converter clutch control valve	Throttle valve & detent valve	Manual valve	Kickdown modifier valve	1st reducing valve	Overrun clutch reducing valve	3-2 timing valve	Torque converter relief valve	4-2 sequence valve	Governor pressure	Governor valve	Primary governor valve	Secondary governor valve	Secondary governor valve	Overdrive cancel solenoid valve	Torque converter clutch solenoid valve	Accumulator N-D	Accumulator 1-2	Accumulator 2-3	Accumulator 3-4 (N-R)	Ignition switch and starter motor	Overdrive control switch and wiring	Torque converter	Oil pump	Reverse clutch	High clutch	Forward clutch	Forward one-way clutch	Overrun clutch	Low one-way clutch	Low & reverse clutch	Brake band	Parking components	
										3	6				-											•							·	
										3	6																							
										3	6																							
										3	6	1	H							-														
										3	8				6							5	•											
										3	6	推 被 使 使		Ħ																				
										3	6	0.1		10 (d) 10 (d)																,				
										3	6	6. 14. 18 8. 16. 13 16. 19. 13	第一张	40 (14 (B) A) A) A) A) A) A) A) A) A) A) A) A) A)	٠																			
	11									3	6																							
]			3	6	# S		報酬							·		7			·		·					·	l
											-					2								,										l I
										-											1													[
╗																											,				,		2	

AT-19 535


ST

RS


BT

HA

EL



TROUBLE DIAGNOSIS FOR DTC P1550



AT-21 537


EL

IID)X


seconds. Then turn ignition switch ON.

ECM.

5) Perform "Diagnostic Test Mode II (Self-diagnostic results)" with




TROUBLE DIAGNOSES





AAT841

AT-23 539

TROUBLE DIAGNOSES







Final Check STALL TESTING Stall test procedure

MA

GI

Check A/T and engine fluid levels. If necessary, add fluid.

Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.

ATF operating temperature: 50 - 80°C (122 - 176°F)

LC

Set parking brake and block wheels.

EC

Install a tachometer where it can be seen by driver during test.


It is good practice to put a mark on point of specified

Æ

engine speed on indicator.

CL.


MT



5. Start engine, apply foot brake, and place selector lever in "D" position.

TE

FA



Accelerate to wide open throttle gradually while applying foot brake.

BR

During test, never hold throttle wide-open for more than 5 seconds.

Quickly note the engine stall revolution and immediately release throttle.

ST

Stall revolution standard: 2,100 - 2,300 rpm

RS

BT


- Shift selector lever to "N" position. 8. Cool off ATF.
- Run engine at idle for at least one minute.

HA

10. Repeat steps 5 through 9 with selector lever in "2", "1" and "R" positions.

EL


[D)X




AT-25

Final Check (Cont'd)

JUDGEMENT OF STALL TEST



TROUBLE DIAGNOSES



Final Check (Cont'd) PRESSURE TESTING



Line pressure plugs are hexagon-headed bolts.

 Always replace line pressure plugs as they are selfsealing bolts.

MA

(G)

LC

EG

Line pressure test procedure


1. Check A/T and engine fluid levels. If necessary, add.

Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.

ATF operating temperature: 50 - 80°C (122 - 176°F)

CL

MT



SAT647B

SAT513G

3. Install pressure gauge to line pressure port.

- D, 2 and 1 positions -

R position —

T||=

AT

[PID]

FA

RA

열

ST

RS


BT

HA

g

ĪĹ

IDX



4. Set parking brake and block wheels.

 Continue to depress brake pedal fully while performing line pressure test at stall speed.

TROUBLE DIAGNOSES



Final Check (Cont'd)

- 5. Start engine and measure line pressure at idle and stall speed.
- When measuring line pressure at stall speed, follow the stall test procedure.

Line pressure:


Engine speed	Line pressure kPa (kg/cm², psi)		
rpm	D, 2 and 1 positions	R position	
ldle	422 - 461 (4.3 - 4.7, 61 - 67)	667 - 706 (6.8 - 7.2, 97 - 102)	
Stall	883 - 961 (9.0 - 9.8, 128 - 139)	1,393 - 1,471 (14.2 - 15.0, 202 - 213)	

JUDGEMENT OF LINE PRESSURE TEST

Judgement		Suspected parts		
At idle	Line pressure is low in all positions.	 Oil pump wear Control piston damage Pressure regulator valve or plug sticking Spring for pressure regulator valve damaged Fluid pressure leakage between oil strainer and pressure regulator valve Clogged strainer 		
	Line pressure is low in particular position.	 Fluid pressure leakage between manual valve and particular clutch. For example, line pressure is: Low in "R" and "1" positions, but Normal in "D" and "2" positions. Therefore, fluid leakage exists at or around low & reverse brake circuit. Refer to OPERATION OF CLUTCH AND BRAKE, AT-11. 		
	Line pressure is high.	 Maladjustment of throttle position sensor Fluid temperature sensor damaged Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure modifier valve sticking Pressure regulator valve or plug sticking 		
At stall speed	Line pressure is low.	 Maladjustment of throttle position sensor Control piston damaged Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure regulator valve or plug sticking Pressure modifier valve sticking Pilot valve sticking 		

544 AT-28

TROUBLE DIAGNOSES



Final Check (Cont'd)

Governor pressure testing

Check A/T and engine fluid levels. If necessary, add fluid.

Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.

ATF operating temperature: 50 - 80°C (122 - 176°F)

Install pressure gauge to governor pressure port.

1,0

G]

MA

Jack up front and rear wheels.

Set selector lever in "D" position and gradually depress accelerator pedal.


Be careful of rotating wheels.

酮

EC

CL.

MT



Governor pressure:

Governor pressure is not generated when vehicle is

Governor pressure rises gradually in response to vehicle

	· · · · · · · · · · · · · · · · · · ·
Vehicle speed	Governor pressure kPa (kg/cm² psi)
0 km/h (0 MPH)	0 (0, 0)
29 km/h (18 MPH)	102.4 - 141.6 (1.22 - 1.26, 17 - 18)
57 km/h (35 MPH)	233.5 - 284.5 (2.40 - 2.90, 34 - 41)
86 km/h (53 MPH)	350.6 - 409.4 (3.58 - 4.18, 51 - 60)

If not, check governor valve assembly. Refer to AT-72.

ΑT

PD ·

TF

FA

 $\mathbb{R}\mathbb{A}$

38

ST

RS

BT

HA


EL,


]DX

Description

- The mechanical key interlock mechanism also operates as a shift lock:
 With the key switch turned to ON, the selector lever cannot be shifted from "P" (park) to any other position unless the brake pedal is depressed.
 - With the key removed, the selector lever cannot be shifted from "P" to any other position.
- The key cannot be removed unless the selector lever is placed in "P".
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder, respectively.

Shift Lock System Electrical Parts Location





AAT037A


Diagnostic Procedure

SYMPTOM 1:


- Selector lever cannot be moved from "P" position with key in ON position and brake pedal applied.
- Selector lever can be moved from "P" position with key in ON position and brake pedal released.
- Selector lever can be moved from "P" position when key is removed from key cylinder.

SYMPTOM 2:


Ignition key cannot be removed when selector lever is set to "P" position. It can be removed when selector lever is set to any position except "P".



TROUBLE DIAGNOSES — A/T Shift Lock System




Key Interlock Cable



CAUTION:


- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions. If casing cap can be removed with an external load of less than 39.2 N (4.0 kg, 8.8 lb), replace key interlock cable with new one.



REMOVAL

Unlock slider from adjuster holder and remove rod from cable.

TROUBLE DIAGNOSES — A/T Shift Lock System



Key Interlock rod

Key Interlock Cable (Cont'd) **INSTALLATION**

Set key interlock cable to steering lock assembly and install lock plate.

Clamp cable to steering column and fix to control cable with

Set control lever to "P" position.

MA

GI

Insert interlock rod into adjuster holder.


EC

LC

FE

CL.

MT



Install casing cap to bracket.

Move slider in order to fix adjuster holder to interlock rod.

TF

ΑT

PD

FA

RA

BR


ST

RS

BT

HA

IDX



Install snap pin.


A/T device Shift lock solenoid harness connector (M174) harness connector (S1) FUSE AAT802


Snap pin


Component Check SHIFT LOCK SOLENOID

Check operation by applying battery voltage to A/T device and shift lock solenoid harness terminal.

TROUBLE DIAGNOSES — A/T Shift Lock System







Component Check (Cont'd) PARK POSITION SWITCH

Check continuity between A/T device harness connector terminal 6 and park position switch harness connector terminal 2

Condition	Continuity		
When selector lever is set in "P" position and selector lever button is released	Yes		
Except above	No		


ASCD BRAKE SWITCH


Check continuity between terminals (1) and (2)

Condition	Continuity		
When brake pedal is depressed	No		
When brake pedal is released	Yes		

Check ASCD brake switch after adjusting brake pedal. Refer to BR section ("Adjustment", BRAKÉ PEDAL AND BRACKET").

AT-36





Front

B

(A)

SAT714C

SAT074BA

3.

(B)

Control Valve Assembly and Accumulators Inspection

Drain ATF from drain plug.

Remove oil pan and gasket.

Remove oil strainer.

Disconnect harness connector.

G

MA

Remove control valve assembly by removing fixing bolts.

EC

Bolt length and location

Bolt symbol	ք mm (in)
(A)	33 (1.30)
B	45 (1.77)

MT

CL

Be careful not to drop manual valve out of valve body.

Remove solenoids and valves from valve body if necessary. Remove terminal cord assembly if necessary.

ΑT

TF

FA

 $\mathbb{R}\mathbb{A}$

8. Remove accumulators (A), (B), (C) and (D) by applying compressed air if necessary.

Hold each piston with rag.

9. Reinstall any part removed.

Always use new sealing parts.

ST

RS

BT

Rear Oil Seal Replacement

Remove propeller shaft from vehicle. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").

HA


Remove rear oil seal. 2. Install rear oil seal.

Apply ATF before installing.

EL

Reinstall any part removed.

DX





(B)

B (B)


AT-37

553





P. (Full throttle position) Throttle drum Direction U P2 (Idling position) Direction T (at P1) Engine side Adjusting tube bracket Return spring



Parking Components Inspection

- 1. Remove propeller shaft from vehicle. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- 2. Support A/T assembly with a jack.
- 3. Remove rear engine mounting member.
- 4. Remove rear extension from transmission case.
- 5. Replace parking components if necessary.
- Reinstall any part removed.
- Always use new sealing parts.

Governor Valve

- 1. Remove propeller shaft from vehicle. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- Support A/T assembly with a jack.
- Remove rear engine mounting member from A/T assembly.
- Remove rear extension from transmission case.
- Remove governor valve assembly.
- Inspect and repair governor valve assembly. Refer to REPAIR FOR COMPONENT PARTS, AT-72.

Throttle Wire Adjustment

- 1. Turn ignition switch OFF.
- 2. While pressing lock plate, move adjusting tube in Direction T.
- 3. Release lock plate. (Adjusting tube is locked at this time.)
- Move throttle drum from P₂ (Idling position) to P₁ (Full throttle position) quickly and release.
- 5. Ensure that throttle wire stroke "L" is within the specified range, between full throttle and idle.

Throttle wire stroke "L":


38 - 42 mm (1.50 - 1.65 in)

- Adjust throttle wire stroke after accelerator wire is installed and adjusted.
- When connecting throttle wire to throttle drum, do not use tools. Manually hook wire.
- Put mark on throttle wire for measuring wire stroke.

If throttle wire stroke is improperly adjusted, the following problems may arise.

- When the throttle drum fully-open position "P₁" is too far toward Direction T, the shift schedule will be as shown by ② in the figure, and the kickdown range will greatly increase.
- When the throttle drum fully-open position "P₁" is too far toward Direction U, the shift schedule will be as shown by ① in the figure, and kickdown will not occur.

ON-VEHICLE SERVICE



Inhibitor Switch Adjustment

- Remove manual control linkage from manual shaft of A/T assembly.
- 2. Set manual shaft of A/T assembly in "N" position.
- 3. Loosen inhibitor switch fixing bolts.
- Use a 4 mm (0.157 in) pin for this adjustment.
- Insert the pin straight into the manual shaft adjustment hole.
- b. Rotate inhibitor switch until the pin can also be inserted straight into hole in inhibitor switch.
- 5. Tighten inhibitor switch fixing bolts.
- Remove pin from adjustment hole after adjusting inhibitor switch.
- 7. Reinstall any part removed.
- Adjust control linkage. Refer to "Manual Control Linkage Adjustment".
- Check operation of inhibitor switch. Refer to AT-23.



AT

TE

PD

FA

RA

BR

ST

G]

MA

EM

LC

EC

扂

CL.


Manual Control Linkage Adjustment

Move the selector lever from the "P" position to "1" position. You should be able to feel the detents in each position.

If the detents cannot be felt or the pointer indicating the position is improperly aligned, the linkage needs adjustment.

- 1. Place selector lever in "P" position.
- 2. Loosen lock nuts.





(☑: 11 - 15 N·m (1.1 - 1.5 kg-m, 8 - 11 ft-lb)

Move selector lever from "P" position to "1" position. Make sure that selector lever can move smoothly.




BT

HA

魟

[D)X




AT-39 555

Removal


CAUTION:

Before separating the A/T assembly from engine, remove the crankshaft position sensor (OBD) from the A/T assembly. Be careful not to damage sensor.


- 1. Disconnect battery negative terminal.
- 2. Remove fluid charging pipe from A/T assembly and plug opening.
- Remove oil cooler pipe from A/T assembly and plug opening.
- Remove propeller shaft.
 Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- Insert plug into rear oil seal after removing rear propeller shaft.
- Be careful not to damage spline, sleeve yoke and rear oil seal.
- 5. Remove A/T control linkage from selector lever.
- Disconnect A/T harness connectors.



- 7. Remove starter motor.
- 8. Remove bolts securing torque converter to drive plate.
- Rotate crankshaft to gain access to securing bolts.





- 9. Support A/T assembly with a jack.
- 10. Remove rear mounting bracket from body and A/T assembly. Refer to EM section ("ENGINE REMOVAL").
- 11. Remove bolts securing A/T assembly to engine.
- 12. Pull A/T assembly backwards.
- Secure torque converter to prevent it from dropping.
- Secure A/T assembly to a jack.





13. Slant and lower A/T assembly.

REMOVAL AND INSTALLATION











Installation

Check drive plate runout.

CAUTION:

Do not allow any magnetic materials to contact the ring gear teeth.

Maximum allowable runout:

Refer to EM section ("Inspection", "CYLINDER BLOCK").

If this runout is out of specification, replace drive plate with ring gear.

When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled. Distance "A":

26.0 mm (1.024 in) or more

Install converter to drive plate.

With converter installed, rotate crankshaft several turns to check that transmission rotates freely without binding.

Tighten bolts securing transmission.

Tightening torque N⋅m (kg-m, ft-lb)	Bolt length "ℓ" mm (in)
1 39 - 49 (4.0 - 5.0, 29 - 36)	43 (1.69)
2 3 - 4 (0.3 - 0.4, 2.2 - 2.9)	16 (0.63)
3 16 - 22 (1.6 - 2.2, 12 - 16)	16 (0.63)

Reinstall any part removed. 5.

Adjust manual control linkage. Refer to AT-39. 6.

- Adjust throttle wire. Refer to AT-38. 7.
- Adjust inhibitor switch. Refer to AT-39. 8.
- Refill transmission with ATF and check fluid level.
- 10. Move selector lever through all positions to be sure that transmission operates correctly. With parking brake applied, allow engine to idle. Move selector lever through "N" to "D", to "2", to "1" and to "R". A slight shock should be felt through the hand gripping the selector each time the transmission is shifted.
- 11. Perform road test. Refer to "ROAD TEST", AT-12.

(GII

MA

区M

Ł¢.

EC

FE

C[_

MT

AT

TF

PD)

FA

 $\mathbb{R}\mathbb{A}$


BR


RS

BT

HA

AT-41






AAT041A

AT-43

Oil Channel




Locations of Needle Bearings, Thrust Washers and Snap Rings

MA Outer diameter of needle bearings Inner diameter of bearing races Outer diameter of snap rings 58 (2.28) 58.8 (2.315) Outer diameter Inner diameter Outer diameter 142.0 (5.59) Outer diameter 156.4 (6.16) 159.2 (6.27) 140.1 (5.52) 52.8 (2.08) 84.5 (3.33) 161.0 (6.34) Inner diameter of thrust washers mm (in) mm (in) 64 (2.52) 53 (2.09) mm (in) 53 (2.09) 78 (3.07) 53 (2.09) mm (in) 47 (1.85) 53 (2.09) 78 (3.07) 57 (2.24) 78 (3.07) LC number number Color Black Item White Item number Item EC Installation of one-piece bearings Item number Bearing race (black) location FE side Rear side Rear side Front Rear CL, number MT **(AT** (2) TF **©** PD FA RA ✐ BR ST **©** RS **③** BT HA IDX


SAT375I

G




Disassembly


1. Removing torque converter by holding it firmly and turning while pulling straight out.




- 2. Check torque converter one-way clutch.
- a. Insert Tool into spline of one-way clutch inner race.
- b. Hook bearing support unitized with one-way clutch outer race with suitable wire.
- c. Check that one-way clutch inner race rotates only clockwise with Tool while holding bearing support with wire.




3. Remove inhibitor switch from transmission case.




- 4. Remove oil pan.
- a. Drain ATF from drain plug.
- b. Raise oil pan by placing wooden blocks under converter housing and adapter case.
- c. Separate the oil pan and transmission case.
- Always place oil pan straight down so that foreign particles inside will not move.



5. Place transmission into Tool with the control valve facing up.



Disassembly (Cont'd)




MA

If frictional material is detected, replace radiator after repair of A/T. Refer to LC section ("Radiator", "ENGINE **COOLING SYSTEM").**

Remove torque converter clutch solenoid valve and overdrive

10




cancel solenoid valve connectors.

FE

CL

MT



Remove oil strainer.

Remove oil strainer from control valve assembly. Then remove O-ring from oil strainer.

Check oil strainer screen for damage.

PD

FA

RA

BR


ST

RS

BT

HA

1DX



Remove control valve assembly.

Straighten terminal clips to free terminal cords then remove terminal clips.

킯


AT-47

SAT307


Disassembly (Cont'd)

b. Remove bolts (A) and (B), and remove control valve assembly from transmission.


Bolt	ℓ mm (in)	
(A)	33 (1.30)	
B	45 (1.77)	




c. Remove manual valve from control valve assembly.




- 10. Remove terminal cord assembly from transmission case while pushing on stopper.
- Be careful not to damage cord.
- Do not remove terminal cord assembly unless it is damaged.



- 11. Remove converter housing.
- a. Remove converter housing from transmission case.
- b. Remove traces of sealant.
- Be careful not to scratch converter housing.



Disassembly (Cont'd)




12. Remove O-ring from input shaft.



G

MA

LĈ



ST25850000 (J25721-A)

SAT027B

13. Remove oil pump assembly.


EC

Attach Tool to oil pump assembly and extract it evenly from transmission case.

Æ

CL

MT



Remove O-ring from oil pump assembly.

Remove traces of sealant from oil pump housing.

TF

Be careful not to scratch pump housing.

PD)

FA

RA

Remove needle bearing and thrust washer from oil pump assembly.


BR

ST

RS

BT

HA




14. Remove input shaft and oil pump gasket.

[DX]




SAT988A

Disassembly (Cont'd)




SAT029B


- 15. Remove brake band and band strut.
- Loosen lock nut and remove band servo anchor end pin from transmission case.




b. Remove brake band and band strut from transmission case.



c. Hold brake band in a circular shape with clip. Check brake band facing for damage, cracks, wear or burns.




- 16. Remove front side clutch and gear components.
- Remove clutch pack (reverse clutch, high clutch and front sun gear) from transmission case.



- b. Remove front bearing race from clutch pack.
- c. Remove rear bearing race from clutch pack.

Disassembly (Cont'd)



d. Remove front planetary carrier from transmission case.




MA

LC





EC



Remove rear bearing from front planetary carrier.



MT

Remove rear sun gear from transmission case.



TF

PD)

FA


RA

 $\mathbb{B}\mathbb{R}$

RS

BT


HA



17. Remove rear extension case.


Remove rear extension case from transmission case.

Remove rear extension gasket from transmission case.




Remove oil seal from rear extension case.


Do not remove oil seal unless it is to be replaced.




Disassembly (Cont'd)




- 18. Remove output shaft and parking gear.
- a. Remove governor valve assembly.




b. Remove rear snap ring from output shaft.



- c. Slowly push output shaft all the way forward.
- Do not use excessive force.
- d. Remove snap ring from output shaft.




- e. Remove output shaft and parking gear as a unit from transmission case.
- f. Remove parking gear from output shaft.



g. Remove needle bearing from transmission case.

Disassembly (Cont'd)




19. Remove rear side clutch and gear components.

a. Remove front internal gear.



MA

LC



SAT110B


SAT682H

b. Remove bearing race from front internal gear.

FE

CL





c. Remove needle bearing from rear internal gear.

TF

PD

FA



Remove rear internal gear, forward clutch hub and overrun clutch hub as a set from transmission case.

BR

ST


RS

BT

MA

EL


IDX




Remove needle bearing from overrun clutch hub.

Remove overrun clutch hub from rear internal gear and forward clutch hub.


Disassembly (Cont'd)




g. Remove thrust washer from overrun clutch hub.




h. Remove forward clutch assembly from transmission case.



- 20. Remove band servo and accumulator components.
- a. Remove band servo retainer from transmission case.




- b. Apply compressed air to oil hole until band servo piston comes out of transmission case.
- Hold piston with a rag and gradually direct air to oil hole.
- c. Remove return springs.



- d. Remove springs from accumulator pistons (B), (C) and (D).
- e. Apply compressed air to each oil hole until piston comes out.
- Hold piston with a rag and gradually direct air to oil hole.

Identification of accumulator pistons	A	B	©	(D)
Identification of oil holes	a	Ь	©	d

Disassembly (Cont'd)



Remove O-ring from each piston.



G


MA

EM

E¢

LC

- 21. Remove throttle wire components if necessary.
- a. Remove throttle wire from A/T assembly.



Screwdriver

CL

FE

MT

- Remove throttle lever shaft E-ring. Remove return spring.
- Remove throttle lever.

1/18

PD

FA

RA

- Remove throttle lever shaft retaining pin and throttle lever shaft.
- BR

ST


RS

BT

HA


EL

1DX




22. Remove manual shaft components, if necessary.

Hold width across flats of manual shaft (outside the transmission case) and remove lock nut from shaft.




Disassembly (Cont'd)


b. Remove retaining pin from transmission case.




 While pushing detent spring down, remove manual plate and parking rod from transmission case.




d. Remove manual shaft from transmission case.




e. Remove spacer and detent spring from transmission case.




f. Remove oil seal from transmission case.




Oil Pump






DISASSEMBLY

1. Loosen bolts in numerical order and remove oil pump cover.



- Remove rotor, vane rings and vanes.
- Inscribe a mark on back of rotor for identification of foreaft direction when reassembling rotor. Then remove rotor.



- While pushing on cam ring remove pivot pin.
- Be careful not to scratch oil pump housing.

AT-57

@[

MA

LC

EC

FE

ŒL.

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

REPAIR FOR COMPONENT PARTS


Oil Pump (Cont'd)




- 4. While holding cam ring and cam ring return spring, lift out cam ring return spring.
- Be careful not to damage oil pump housing.
- Hold cam ring return spring to prevent it from jumping.



5. Remove cam ring and cam ring return spring from oil pump housing.




Remove pivot pin from control piston and remove control piston assembly.



- 7. Remove oil seal from oil pump housing.
- Be careful not to scratch oil pump housing.








Oil pump cover, rotor, vanes, control piston, side seals, camring and friction ring


Check for wear or damage.


REPAIR FOR COMPONENT PARTS











Oil Pump (Cont'd)

Side clearances

 Measure side clearances between end of oil pump housing and cam ring, rotor, vanes and control piston in at least four places along their circumferences. Maximum measured values should be within specified ranges.

 Before measuring side clearance, check that friction rings, O-ring, control piston side seals and cam ring return spring are removed.

Standard clearance (Cam ring, rotor, vanes and control piston):

Refer to SDS, AT-116.

 If not within standard clearance, replace oil pump assembly except oil pump cover assembly.

Seal ring clearance

Measure clearance between seal ring and ring groove.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Wear limit:

0.25 mm (0.0098 in)

If not within wear limit, replace oil pump cover assembly.

ASSEMBLY

- 1. Drive oil seal into oil pump housing.
- Apply ATF to outer periphery and lip surface.

- 2. Install cam ring in oil pump housing by the following steps.
- a. Install side seal on control piston.
- Pay attention to its direction Black surface goes toward control piston.
- Apply petroleum jelly to side seal.
- b. Install control piston on oil pump.
- c. Install O-ring and friction ring on cam ring.
- Apply petroleum jelly to O-ring.

HA

冒.

BT

G

MA

LC

EC

FE

CL

MT

ΑT

TF

PD)

EA


RA

图图


ST

REPAIR FOR COMPONENT PARTS


Oil Pump (Cont'd)




d. Assemble cam ring, cam ring return spring and spring seat. Install spring by pushing it against pump housing.




e. While pushing on cam ring install pivot pin.



- Install rotor, vanes and vane rings.
- Pay attention to direction of rotor.



- 4. Install oil pump housing and oil pump cover.
- Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly in oil pump housing assembly, then remove masking tape.
- b. Tighten bolts in a criss-cross pattern.



- 5. Install seal rings carefully after packing ring grooves with petroleum jelly. Press rings down into jelly to a close fit.
- Seal rings come in two different diameters. Check fit carefully in each groove.

Small dia. seal ring:

No mark

Large dia. seal ring:

Yellow mark in area shown by arrow


Do not spread gap of seal ring excessively while installing. It may deform ring.

Control Valve Assembly

SEC. 317 10 - 13 (1.0 - 1.3, 87 - 113) -MAOverdrive cancel solenoid valve EM 7 - 9 (0.7 - 0.9, 61 - 78) LC Harness clips EC FE Lower body CL MT Orifice check spring Orifice check valve TF PD) Separator plate FA Support plates RA Side plate Steel ball BR ST -Upper body RS BT Reamer bolt HA O-ring ∠ Reamer bolt Torque converter clutch solenoid valve : N•m (kg-m, in-lb) 10 - 13 (1.0 - 1.3, 87 - 113) ATF: Apply ATF. 1DX


AAT813

Gľ.




Control Valve Assembly (Cont'd) DISASSEMBLY


- Remove solenoids.
- a. Remove overdrive cancel solenoid valve and side plate from lower body.
- b. Remove Ó-ring from solenoid.




- Remove torque converter clutch solenoid valve from upper body.
- d. Remove O-ring from solenoid valve.




- 2. Disassemble upper and lower bodies.
- Place upper body facedown, and remove bolts, reamer bolts and support plates.
- Remove lower body, separator plate and separate gasket as a unit from upper body.
- Be careful not to drop orifice check valve, spring and steel balls.



- c. Place lower body facedown, and remove separator plate.
- d. Remove orifice check valve and orifice check spring.



e. Check to see that steel balls are properly positioned in upper body and then remove them from upper body.



Tube connecto

Control Valve Assembly (Cont'd) INSPECTION

@[

Lower and upper bodies


Check to see that there are pins and retainer plates in lower body.



MA

Check to see that there are pins and retainer plates in upper

LC






CL

FE





Separator plates

SAT140C

SAT141C

SAT151G

Tube bracket

TF



FA

RA

Check to make sure that separator plate is free of damage and not deformed and oil holes are clean.

BR

Overdrive cancel solenoid valve and torque converter clutch solenoid valve

Check that filter is not clogged or damaged.

ST

Measure resistance. Refer to "Component Inspection", AT-22.








Install upper and lower bodies.


Place oil circuit of upper body face up. Install steel balls in their

IDX




proper positions.

Control Valve Assembly (Cont'd)




b. Install reamer bolts from bottom of upper body and install separate gaskets.




 Place oil circuit of lower body face up. Install orifice check spring, orifice check valve.

> D: mm (in) 2.0 (0.079)



- d. Install separator plate on lower body.
- e. Install and temporarily tighten support plates and tube brackets.



- f. Temporarily assemble lower and upper bodies, using reamer bolt as a guide.
- Be careful not to dislocate or drop steel balls, orifice check spring and orifice check valve.

Control Valve Assembly (Cont'd)

 Install and temporarily tighten bolts and tube brackets in their proper locations.


Bolt length and location:

		Bolt symbol	
		а	b
Bolt length	mm (in)	45 (1.77)	33 (1.30)

MA

LC

EC




Install solenoids.

 Attach O-ring and install overdrive cancel solenoid valve and side plate onto lower body.

FE

CL

MT



b. Attach O-ring and install torque converter clutch solenoid valve onto upper body.

3. Tighten bolt.

TF

PD

 $\mathbb{R}\mathbb{A}$

BR

ST

RS


BT

HA

EL

IDX

Control Valve Upper Body




Apply ATF to all components before their installation.

AAT040A

Numbers preceding valve springs correspond with those shown in Return Springs Chart on SDS. AT-114.

AT-66

jumping out.



Control Valve Upper Body (Cont'd) **DISASSEMBLY**

Remove valves at parallel pins.

Do not use a magnetic hand.



MA


LC

Use a wire paper clip to push out parallel pins.

肥

CL.

MT




Remove parallel pins while pressing their corresponding plugs and sleeves.

Remove plug slowly to prevent internal parts from TF

PD

FA

 $\mathbb{R}\mathbb{A}$



Parallel pin

- Place mating surface of valve facedown, and remove internal parts.
- If a valve is hard to remove, place valve body facedown and lightly tap it with a soft hammer.
- Be careful not to drop or damage valves and sleeves.

ST


88

RS

BT

HA

EL




Remove valves at retainer plates.


Pry out retainer plate with wire paper clip.

Control Valve Upper Body (Cont'd)

b. Remove retainer plates while holding spring.



- Soft hammer
- Place mating surface of valve facedown, and remove internal parts.
- If a valve is hard to remove, lightly tap valve body with a soft hammer.
- Be careful not to drop or damage valves, sleeves, etc.



INSPECTION

SAT827A

Valve springs

Measure free length and outer diameter of each valve spring.
 Also check for damage or deformation.


Inspection standard:

Refer to SDS, AT-114.

Replace valve springs if deformed or fatigued.


Control valves

Check sliding surfaces of valves, sleeves and plugs.




ASSEMBLY

- Lubricate the control valve body and all valves with ATF Install control valves by sliding them carefully into their bores.
- Be careful not to scratch or damage valve body.



 Wrap a small screwdriver with vinyl tape and use it to insert the valves into proper position.



Control Valve Upper Body (Cont'd) Accumulator control plug

 Align protrusion of accumulator control sleeve with notch in plug.

Align parallel pin groove in plug with parallel pin, and install accumulator control valve.

MA

EM

LC


. Install parallel pins and retainer plates.

EC

FE

CL

MT



• While pushing plug, install parallel pin.

Insert retainer plate while pushing spring.

AT

ŢF

PD

FA

RA


ST

RS

BT

HA


IDX



AT-69 585

Control Valve Lower Body


SEC. 317




Apply ATF to all components before their installation.

SAT752GA

Numbers preceding valve springs correspond with those shown in Return Springs Chart on SDS. AT-114.





Remove valves at parallel pins.

2. Remove valves at retainer plates. For removal procedures, refer to "DISASSEMBLY", "Control Valve Upper Body," AT-67.

g

MA

ĔM


LC

EC

FΕ

CL

MT



INSPECTION

Valve springs

• Check each valve spring for damage or deformation. Also measure free length and outer diameter.

Inspection standard: Refer to SDS, AT-114.

Replace valve springs if deformed or fatigued.

Control valves

 Check sliding surfaces of control valves, sleeves and plugs for damage.

r

ASSEMBLY

 Install control valves.
 For installation procedures, refer to "ASSEMBLY", "Control Valve Upper Body," AT-68.



PD

FA

RA

BR


ST

RS


BT


HA


IDX



Governor Valve Assembly







INSPECTION

Valve springs

Measure free length and outer diameter of each valve spring.
 Also check for damage or deformation.

Inspection standard: Refer to SDS, AT-114.

Governor valves and valve body

 Check governor valves and valve body for indication of burning or scratches.

Parking Gear

INSPECTION

- Check contacting surface of parking gear and ring groove areas for wear.
- Measure clearance between seal ring and ring groove.


Standard clearance:


0.15 - 0.40 mm (0.0059 - 0.0157 in)


Wear limit:

0.40 mm (0.0157 in)

Reverse Clutch







DISASSEMBLY

- Check operation of reverse clutch.
- Install seal ring onto oil pump cover and install reverse clutch.
 Apply compressed air to oil hole.
- b. Check to see that retaining plate moves to snap ring.
- c. If retaining plate does not contact snap ring,
- D-ring might be damaged.
- Oil seal might be damaged.
- Fluid might be leaking past piston check ball.

2. Remove drive plates, driven plates, retaining plate, dish plate and snap ring.

HA

GI

MA

LC

EC

門

CL

MT

TF

PD

FA

RA


ST

RS


BT

AT-73

Reverse Clutch (Cont'd)



- 3. Remove snap ring from clutch drum while compressing clutch springs.
- Do not expand snap ring excessively.
- 4. Remove spring retainer and return spring.




- Install seal ring onto oil pump cover and install reverse clutch drum. While holding piston, gradually apply compressed air to oil hole until piston is removed.
- Do not apply compressed air abruptly.
- 6. Remove D-ring and oil seal from piston.

INSPECTION

Reverse clutch snap ring and spring retainer


· Check for deformation, fatigue or damage.



Reverse clutch return springs

 Check for deformation or damage. Also measure free length and outside diameter.

> Inspection standard: Refer to SDS, AT-114.



Reverse clutch drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.


Thickness of drive plate:

Standard value 1.90 - 2.05 mm (0.0748 - 0.0807 in) Wear limit 1.80 mm (0.0709 in)

• If not within wear limit, replace.

Reverse clutch dish plate

Check for deformation or damage.



Oil seal ATF

D-ring ATF

SAT847A

(ATF)

Reverse Clutch (Cont'd)

Reverse clutch piston

Shake piston to assure that balls are not seized.

Apply compressed air to check ball oil hole opposite the return spring to assure that there is no air leakage.

Also apply compressed air to oil hole on return spring side to assure that air leaks past ball.

LC

MA

Œ1

ASSEMBLY

Install D-ring and oil seal on piston.

Apply ATF to both parts.

FE

CL

MT

Install piston assembly by turning it slowly and evenly.

ΑT TF

Apply ATF to inner surface of drum.

PD

FA

RA

Install return springs and spring retainer.

BR


ST

RS


BT

HA

EL




Install snap ring while compressing clutch springs.




KV31102400 (J34285 and


Reverse Clutch (Cont'd)



Do not align snap ring gap with spring retainer stopper.



- 5. Install drive plates, driven plates, retaining plate and dish plate.
- 6. Install snap ring.



7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit

1.2 mm (0.047 in)


Retaining plate:


Refer to SDS, AT-115.




8. Check operation of reverse clutch. Refer to "DISASSEMBLY", "Reverse Clutch", AT-73.

High Clutch







DISASSEMBLY AND ASSEMBLY

Service procedures for high clutch are essentially the same as those for reverse clutch, with the following exception:

Check of high clutch operation

Removal and installation of return spring

AT-77 593

GI

MA

EM

[_C

EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


ST

RS

BT


HA

EL




High Clutch (Cont'd)

Inspection of high clutch return springs
 Inspection standard:
 Refer to SDS, AT-114.



Inspection of high clutch drive plate
Thickness of drive plate:
Standard
1.52 - 1.67 mm (0.0598 - 0.0657 in)
Wear limit
1.40 mm (0.0551 in)



 Measurement of clearance between retaining plate and snap ring

Specified clearance:
Standard
1.8 - 2.2 mm (0.071 - 0.087 in)
Allowable limit
2.8 mm (0.110 in)
Retaining plate:
Refer to SDS, AT-115.

Forward and Overrun Clutches

Overrun clutch plate

_ Oil seal 🏖 ATF

D-ring ATF

Return spring -

Drive plate 1

Overrun clutch piston -

Driven plate

G

MA

SEC. 315

For the number of clutch sheets (drive plate and driven plate), refer to the below cross-section.

Forward clutch plate


Snap ring Spring retainer

Driven plate

Drive plate

Oil seal 🚷 ATF













Forward clutch drum (ATF)

Forward clutch piston

Direction of oil seal

D-ring (ATF)

Direction of oil seal

(ATF): Apply ATF.

: Select with proper thickness.
























IDX


SAT3141




Forward and Overrun Clutches (Cont'd) DISASSEMBLY AND ASSEMBLY

Service procedures for forward and overrun clutches are essentially the same as those for reverse clutch, with the following exception:


Check of forward clutch operation.




Check of overrun clutch operation.




 Removal of forward clutch drum
 Remove forward clutch drum from transmission case by holding snap ring.



Removal of forward clutch and overrun clutch pistons
 While holding overrun clutch piston, gradually apply compressed air to oil hole.



2. Remove overrun clutch from forward clutch.



Forward and Overrun Clutches (Cont'd)

Removal and installation of return springs

Inspection of forward clutch and overrun clutch return springs Inspection standard: Refer to SDS, AT-114.

FE

(G)

MA


LC

diameter Outer Q: Free length SAT829A

CL MT

AT

TE



Inspection of forward clutch drive plates Thickness of drive plate: Standard 1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit

1.40 mm (0.0551 in)

PD

FA

RA

Thickness Core plate

SAT845A

Inspection of overrun clutch drive plates Thickness of drive plate:

Standard

1.90 - 2.05 mm (0.0748 - 0.0807 in)

Wear limit

1.80 mm (0.0709 in)

BR

RS

ST

Installation of forward clutch piston and overrun clutch piston

Install forward clutch piston by turning it slowly and evenly.


Apply ATF to inner surface of clutch drum.


HA

BT

]DX


EL





Forward and Overrun Clutches (Cont'd)

- Align notch in forward clutch piston with groove in forward clutch drum.
- 2. Install overrun clutch by turning it slowly and evenly.
- Apply ATF to inner surface of forward clutch piston.



 Measurement of clearance between retaining plate and snapring of overrun clutch

Specified clearance:

Standard


1.0 - 1.4 mm (0.039 - 0.055 in)

Allowable limit

2.0 mm (0.079 in)

Retaining plate:

Refer to SDS, AT-115.



 Measurement of clearance between retaining plate and snap ring of forward clutch

Specified clearance:

Standard

0.35 - 0.75 mm (0.0138 - 0.0295 in)

Allowable limit


1.85 mm (0.728 in)


Retaining plate:


Refer to SDS, AT-115.

598 AT-82

Low & Reverse Brake







DISASSEMBLY

- 1. Check operation of low and reverse brake.
- Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.
- b. Check to see that retaining plate moves to snap ring.
- If retaining plate does not contact snap ring, C.
- D-ring might be damaged.
- Oil seal might be damaged.
- Fluid might be leaking past piston check ball.

Remove snap ring, low & reverse brake drive plates, driven

plates and dish plate.

G

MA

LC.

EC

FE

CL

MT

AT

TF

PD

FA

RA

RS

BT

HA


EL

IDX

SAT154G

Low & Reverse Brake (Cont'd)

- 3. Remove low one-way clutch inner race, spring retainer and return spring from transmission case.
- 4. Remove seal rings from low one-way clutch inner race.
- 5. Remove needle bearing from low one-way clutch inner race.




- 6. Remove low & reverse brake piston using compressed air.
- 7. Remove oil seal and D-ring from piston.

INSPECTION

Low & reverse brake snap ring and spring retainer


· Check for deformation, or damage.



Low & reverse brake return springs

 Check for deformation or damage. Also measure free length and outside diameter.

> Inspection standard: Refer to SDS, AT-114.



Low & reverse brake drive plates

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:


Standard value

1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit

1.8 mm (0.071 in)

If not within wear limit, replace.



Low & Reverse Brake (Cont'd)


Low one-way clutch inner race

- Check frictional surface of inner race for wear or damage.
- Install new seal rings onto low one-way clutch inner race.
- Be careful not to expand seal ring gap excessively.
- Measure seal ring-to-groove clearance.

Inspection standard:


Standard value 0.10 - 0.25 mm (0.0039 - 0.0098 in) Allowable limit 0.25 mm (0.0098 in)

If not within allowable limit, replace low one-way clutch inner race.




ASSEMBLY

- Install needle bearing onto one-way clutch inner race.
- Pay attention to its direction Black surface goes to rear side.
- Apply petroleum jelly to thrust washers.



- Install oil seal and D-ring onto piston.
- Apply ATF to oil seal and D-ring.



- Install piston by rotating it slowly and evenly.
- Apply ATF to inner surface of transmission case.



SAT881A

- Install return springs, spring retainer and low one-way clutch inner race onto transmission case.
 - Install dish plate, low & reverse brake drive plates, driven plates and retaining plate.
 - Install snap ring on transmission case.

IDX

@1

MA

國

LC

EC

CL

MT

TF

PD)

FA

RA


BR

ST


RS

MA

Low & Reverse Brake (Cont'd)



7. Check operation of low & reverse brake clutch piston. Refer to "DISASSEMBLY", AT-83.



8. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


0.8 - 1.1 mm (0.031 - 0.043 in)

Allowable limit

2.3 mm (0.091 in)


Retaining plate:


Refer to SDS, AT-115.



- 9. Install low one-way clutch inner race seal ring.
- Apply petroleum jelly to seal ring.
- Make sure seal rings are pressed firmly into place and held by petroleum jelly.

Forward Clutch Drum Assembly





Forward Clutch Drum Assembly (Cont'd) DISASSEMBLY

- 1. Remove snap ring from forward clutch drum.
- 2. Remove side plate from forward clutch drum.
- 3. Remove low one-way clutch from forward clutch drum.
- 4. Remove snap ring from forward clutch drum.
- 5. Remove needle bearing from forward clutch drum.



LC

G

MA



EC


Forward clutch drum

- Check spline portion for wear or damage.
- Check frictional surfaces of low one-way clutch and needle bearing for wear or damage.

CL

FE

MT



SAT892A

SAT893A

Needle bearing and low one-way clutch

Check frictional surface for wear or damage.

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

ASSEMBLY

- . Install needle bearing in forward clutch drum.
- 2. Install snap ring onto forward clutch drum.

26

ST


RS


 Install low one-way clutch onto forward clutch drum by pushing the roller in evenly.


HA

BT

EL









Forward Clutch Drum Assembly (Cont'd)

- Install low one-way clutch with flange facing rearward.
- I. Install side plate onto forward clutch drum.
- 5. Install snap ring onto forward clutch drum.


Rear Internal Gear and Forward Clutch Hub






DISASSEMBLY

- Remove rear internal gear by pushing forward clutch hub forward.
- 2. Remove thrust washer from rear internal gear.
- Remove snap ring from forward clutch hub.
- 4. Remove end bearing.



- 5. Remove forward one-way clutch and end bearing as a unit from forward clutch hub.
- 6. Remove snap ring from forward clutch hub.



Rear Internal Gear and Forward Clutch Hub (Cont'd)

INSPECTION

Rear internal gear and forward clutch hub

Check gear for excessive wear, chips or cracks.

Check frictional surfaces of forward one-way clutch and thrust washer for wear or damage.

Check spline for wear or damage.

EM

GI

MA

LC

Snap ring and end bearing


Check for deformation or damage.

EC

FE

CL.

MT



ASSEMBLY

- Install snap ring onto forward clutch hub.
- Install end bearing.

TF

PD)

FA

RA

Install forward one-way clutch with flange facing rearward. BR

4. Install end bearing.


Install snap ring onto forward clutch hub.

Install forward one-way clutch onto clutch hub.

ST

RS

BT





Apply petroleum jelly to thrust washer.


Securely insert pawls of thrust washer into holes in rear internal gear.

EL

HA









Rear Internal Gear and Forward Clutch Hub (Cont'd)


7. Position forward clutch hub in rear internal gear.



8. After installing, check to assure that forward clutch hub rotates clockwise.


Band Servo Piston Assembly





DISASSEMBLY

- 1. Block one oil hole in OD servo piston retainer and the center hole in OD band servo piston.
- Apply compressed air to the other oil hole in piston retainer to remove OD band servo piston from retainer.
- 3. Remove D-ring from OD band servo piston.



Band Servo Piston Assembly (Cont'd)

Remove band servo piston assembly from servo piston retainer by pushing it forward.

MA

EM


LC

Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.

Æ

CL

MT



E-ring

SAT912A

6. Remove servo piston spring retainer, return spring © and piston stem from band servo piston.

TF

PD)

RA

- Remove servo cushion spring retainer from band servo piston.
- Remove D-rings from band servo piston.
- 10. Remove O-rings from servo piston retainer.


Remove E-ring from band servo piston.

ST

BR

RS

BT




INSPECTION

Pistons, retainers and piston stem

Check frictional surfaces for abnormal wear or damage.

HA


EL.



Band Servo Piston Assembly (Cont'd) Return springs


 Check for deformation or damage. Measure free length and outer diameter.

> Inspection standard: Refer to SDS, AT-114.




ASSEMBLY


- 1. Install O-rings onto servo piston retainer
- Apply ATF to O-rings.
- Pay attention to position of each O-ring.



2. Install servo cushion spring retainer onto band servo piston.




- 3. Install E-ring onto servo cushion spring retainer.
- 4. Install D-rings onto band servo piston.
- Apply ATF to D-rings.



5. Install servo piston spring retainer, return spring © and piston stem onto band servo piston.

Band Servo Piston Assembly (Cont'd)



6. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.

MA

GI

EM


LC

 Install band servo piston assembly onto servo piston retainer by pushing it inward.

FE

CL

MT



ATF

8. Install D-ring on OD band servo piston.

Apply ATF to D-ring.

TF

AT

(1919)

٦.

FA

RA

Install OD band servo piston onto OD servo piston retainer by pushing it inward.


ST

RS

BT


HA


IDX



SAT923A


Parking Pawl Components






DISASSEMBLY

1. Slide return spring to the front of rear extension flange.




- Remove return spring, pawl spacer and parking pawl from rear extension.
- 3. Remove parking pawl shaft from rear extension.



4. Remove parking actuator support from rear extension.

AT-94



Parking Pawl Components (Cont'd) INSPECTION


G]

Parking pawl and parking actuator support

 Check contact surface of parking rod and parking gear for wear.



LC



ASSEMBLY

EC


1. Install parking actuator support onto rear extension.

FE

2. Insert parking pawl shaft into rear extension.

CL

MT



3. Install return spring, pawl spacer and parking pawl onto parking pawl shaft.

TF

PD

FA

RA

4. Bend return spring upward and install it onto rear extension.

BR


ST


RS

BŢ

HA


IDX






Assembly (1)


- 1. Install manual shaft components.
- a. Install oil seal onto manual shaft.
- Apply ATF to oil seal.
- Wrap threads of manual shaft with masking tape.
- b. Insert manual shaft and oil seal as a unit into transmission case.
- c. Remove masking tape.




d. Push oil seal evenly and install it onto transmission case.



e. Align groove in shaft with drive pin hole, then drive pin into position as shown in figure at left.




f. Install detent spring and spacer.



 While pushing detent spring down, install manual plate onto manual shaft.

Assembly (1) (Cont'd)



5 mm (0.20 in)

SAT148C

SAT135C

Retaining pin

h. Install lock nuts onto manual shaft.

MA

G[

EM

LC

Install throttle lever components.

EC

Install throttle lever shaft.

Align groove in shaft with drive pin hole, then drive pin into position as shown in figure at left.

Æ

ŒL

MT

Install throttle lever, return spring, spring retainer and E-ring.

TF

PD

FA

RA


BR

ST

RS

HA

IDX




Throttle lever shaft?


Install throttle wire.

BT






Assembly (1) (Cont'd)




- 3. Install accumulator piston.
- a. Install O-rings onto accumulator piston.
- Apply ATF to O-rings.
 Accumulator piston O-rings:
 Refer to SDS, AT-114.




b. Install return spring for accumulator (A) onto transmission case.


Free length of return spring: Refer to SDS, AT-114.




- c. Install accumulator pistons (A), (B), (C) and (D).
- Apply ATF to transmission case.



- 4. Install band servo piston.
- a. Install return springs onto band servo piston.



- b. Install band servo piston onto transmission case.
- Apply ATF to O-ring of band servo piston and transmission case.
- c. Install gasket for band servo onto transmission case.




d. Install OD servo piston retainer onto transmission case.



(GI


EM

LC





FE




Place transmission case in vertical position.



CL.

MT



Slightly lift forward clutch drum assembly and slowly rotate it clockwise until its hub passes fully over the clutch inner race inside transmission case.



PD)

TF

FA




Check to be sure that rotation direction of forward clutch

BR

ST

R\$

BT



SAT945A

Install thrust washer onto front of overrun clutch hub.

Apply petroleum jelly to the thrust washer.


Insert pawls of thrust washer securely into holes in overrun clutch hub.

HA


EL

IDX


assembly is correct.




e. Install overrun clutch hub onto rear internal gear assembly.




- f. Install needle bearing onto rear of overrun clutch hub.
- Apply petroleum jelly to needle bearing.




g. Check that overrun clutch hub rotates as shown while holding forward clutch hub.



- h. Place transmission case into horizontal position.
- Install rear internal gear, forward clutch hub and overrun clutch hub as a unit onto transmission case.



- j. Install needle bearing onto rear internal gear.
- Apply petroleum jelly to needle bearing.
- k. Install bearing race onto rear of front internal gear.
- Apply petroleum jelly to bearing race.
- Securely engage pawls of bearing race with holes in front internal gear.



I. Install front internal gear on transmission case.




G

MA

LC

EC



3. Install output shaft and parking gear.


 Insert output shaft from rear of transmission case while slightly lifting front internal gear.

Do not force output shaft against front of transmission case.



CL

MT



b. Carefully push output shaft against front of transmission case. Install snap ring on front of output shaft.

Check to be sure output shaft cannot be removed in rear direction.



PD

FA

0 10-0

RA

Pay attention to its direction — Black side goes to rear.

Apply petroleum jelly to needle bearing.

Install needle bearing on transmission case.



ST


R\$

BT

HA

EL

111111111



d. Install parking gear on transmission case.











Assembly (1) (Cont'd)




SAT3101


- e. Install snap ring on rear of output shaft.
 Check to be sure output shaft cannot be remove
- Check to be sure output shaft cannot be removed in forward direction.




f. Install governor valve assembly on oil distributor.




- 7. Install rear extension case.
- a. Install oil seal on rear extension case.
- Apply ATF to oil seal.



b. Install rear extension gasket on transmission case.



c. Install parking rod on transmission case.



Install rear extension case on transmission case. Tighten bolts to specified torque.

(2.0 - 2.5 kg-m, 14 - 18 ft-lb)



G

国网


LC


EC

匠


CL

MT









Black side goes to front

SAT967A

SAT969A

Install needle bearing on front of front planetary carrier. b.

Apply petroleum jelly to needle bearing.

Install needle bearing on rear of front planetary carrier.

Apply petroleum jelly to needle bearing.

Pay attention to its direction — Black side goes to front.



TF

FA

While rotating forward clutch drum clockwise, install front



RA

planetary carrier on forward clutch drum.



RS




Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.




EL










Assembly (1) (Cont'd)

- e. Install bearing races on front and rear of clutch pack.
- Apply petroleum jelly to bearing races.
- Securely engage pawls of bearing races with holes in clutch pack.
- Place transmission case in vertical position.




Adjustment


SAT973A

When any parts listed in the following table are replaced, total end play or reverse clutch end play must be adjusted.

Item		
Total end play	Reverse clutch end play	
•	•	
•	•	
•	•	
•	•	
•	•	
•	•	
•	•	
•	•	
•	•	
•	•	
•	•	
	•	
	Total end play	



Adjust total end play.
 Total end play "T₁":
 0.25 - 0.55 mm (0.0098 - 0.0217 in)



Adjustment (Cont'd)


a. With needle bearing installed, place J34291-1 (bridge), J34291-2 (legs) and the J34291-5 (gauging cylinder) onto oil pump. The long ends of legs should be placed firmly on machined surface of oil pump assembly and gauging cylinder should rest on top of the needle bearing. Lock gauging cylinder in place with set screw.



MA

LC

EC



SAT978A

Feeler gauge

SAT979A

Install J34291-23 (gauging plunger) into gauging cylinder.



CL



With original bearing race installed inside reverse clutch drum, place shim selecting gauge with its legs on machined surface of transmission case (no gasket) and allow gauging plunger to rest on bearing race. Lock gauging plunger in place with set screw.



PD)

FA

RA

Remove Tool and use feeler gauge to measure gap between gauging cylinder and gauging plunger. This measurement should give exact total end play.



Total end play "T1":

0.25 - 0.55 mm (0.0098 - 0.0217 in)


ST

If end play is out of specification, decrease or increase thickness of oil pump cover bearing race as necessary.

RS


Available oil pump cover bearing race: Refer to SDS, AT-116.


BT



HA


IDX






Adjustment (Cont'd)


a. Place J34291-1 (bridge), J34291-2 (legs) and J34291-5 (gauging cylinder) on machined surface of transmission case (no gasket) and allow gauging cylinder to rest on front thrust surface of reverse clutch drum. Lock cylinder in place with set screw.



b. Install J34291-23 (gauging plunger) into gauging cylinder.



c. With original thrust washer installed on oil pump, place shim setting gauge legs onto machined surface of oil pump assembly and allow gauging plunger to rest on thrust washer. Lock plunger in place with set screw.




d. Use feeler gauge to measure gap between gauging plunger and gauging cylinder. This measurement should give you exact reverse clutch drum and play.

Reverse clutch drum end play "T₂": 0.55 - 0.90 mm (0.0217 - 0.0354 in)


If end play is out of specification, decrease or increase thickness of oil pump thrust washer as necessary.

Available oil pump thrust washer: Refer to SDS, AT-116.




Assembly (2)

- 1. Place transmission case into horizontal position.
- 2. Install brake band and band strut.
- a. Install band strut on brake band.
- Apply petroleum jelly to band strut.



Place brake band around reverse clutch drum, and insert band strut into end of band servo piston stem.






Install anchor end bolt on transmission case. Then, tighten anchor end bolt just enough so that reverse clutch drum (clutch pack) will not tilt forward.



CL.

MT



Install input shaft on transmission case.

Pay attention to its direction — O-ring groove side is front.

Install gasket on transmission case.

Install oil pump assembly.

5.




AT

1P(D)

RA

BR



Install selected thrust washer on oil pump assembly.

Apply petroleum jelly to thrust washer.

ST


RS

Te


HA

EL

IDX





Carefully install seal rings into grooves and press them into the petroleum jelly so that they are a tight fit.




AT-107


Assembly (2) (Cont'd)









e. Apply petroleum jelly to mating surface of transmission case and oil pump assembly.




- f. Install oil pump assembly.
- Install two converter housing securing bolts in bolt holes in oil pump assembly as guides.




 Insert oil pump assembly to the specified position in transmission, as shown at left.



- 6. Install O-ring on input shaft.
- Apply ATF to O-rings.





Assembly (2) (Cont'd)

Install converter housing.

Apply anaerobic liquid gasket Loctite P/N 51813 or equivalent around bolt holes in converter housing.

Do not apply too much sealant.


MA

(GII

EM

LC

EC




Apply anaerobic liquid gasket Locite P/N 51813 or equivalent to seating surfaces of bolts that secure front of converter housing.

Install converter housing on transmission case.

FE

CL

MT



Adjust brake band.

SAT158G

SAT002B

9.

Tighten anchor end bolt to specified torque.

Anchor end bolt:

(0.4 - 0.6 kg-m, 35 - 52 in-lb)

Back off anchor end bolt two and a half turns.

PD)

TF

FA

RA

While holding anchor end pin, tighten lock nut.

BR

ST

RS

BT

HA


Apply petroleum jelly to O-ring.

Install terminal cord assembly.

Install O-ring on terminal cord assembly.


Compress terminal cord assembly stopper and install terminal

ID)X




cord assembly on transmission case.


Assembly (2) (Cont'd)



- 10. Install control valve assembly.




- b. Install manual valve on control valve.
- Apply ATF to manual valve.




- c. Install control valve assembly on transmission case.
- d. Install connector tube brackets and tighten bolts (A) and (B).
- Check that terminal assembly harness does not catch.


Bolt	ا mm (in)
(A)	33 (1.30)
B	45 (1.77)



- e. Install O-ring on oil strainer.
- Apply petroleum jelly to O-ring.
- f. Install oil strainer on control valve.



g. Securely fasten terminal harness with clips.



Drain plug

Assembly (2) (Cont'd)

11. Install oil pan.

Attach a magnet to oil pan.



MA

ĒM

LC

EC

Install new oil pan gasket on transmission case. Install oil pan and bracket on transmission case.

Always replace oil pan bolts; they are self-sealing bolts.

Before installing bolts, remove traces of sealant and oil from mating surface and thread holes.

Tighten four bolts in a criss-cross pattern to prevent dislocation of gasket.


d.



CL

Tighten drain plug.

MT



SAT099H

SAT2991

1)

TF

PD)

FA

RA

Insert the pin straight into the manual shaft adjustment hole.

Rotate inhibitor switch until the pin can also be inserted straight 2) into hole in inhibitor switch.

Use a 4 mm (0.157 in) pin for this adjustment.

Tighten inhibitor switch fixing bolts. e.

Remove pin from adjustment hole after adjusting inhibitor

ST

BR

RS

BT


HA


Pour ATF into torque converter. Approximately 2 liters (2-1/8 US qt, 1-3/4 lmp qt) of fluid

are required for a new torque converter.

When reusing old torque converter, add the same amount

ĒĻ IDX







Install torque converter.

switch.

Assembly (2) (Cont'd)



b. Install torque converter while aligning notches and oil pump.



 Measure distance A to check that torque converter is in proper position.

Distance "A": 26.0 mm (1.024 in) or more

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Automatic transmission model	RL4R01A		
Transmission model code number	49X10		
Stall torque ratio	2.0 : 1		
Transmission gear ratio			
1st	2.785		
2nd	1.545		
Тор	1.000		
OD	0.694		
Reverse	2.272		
Recommended fluid	Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Automatic Transmission Fluid (Canada)*1		
Fluid capacity & (US qt, Imp qt)	7.9 (8-3/8, 7)		

^{*1:} Refer to MA section ("Fluids and Lubricants", "RECOMMENDED FLUIDS AND LUBRICANTS").

Specifications and Adjustment

VEHICLE SPEED WHEN SHIFTING GEARS

TI			Vehi	cle speed km/h (I	MPH)		
Throttle position	$D_1 \rightarrow D_2$	$D_2 \rightarrow D_3$	$D_3 \rightarrow D_4$	$D_4 \rightarrow D_3$	$D_3 \rightarrow D_2$	$D_2 \rightarrow D_1$	1 ₂ → 1 ₁
Full throttle	53 - 57 (33 - 35)	100 - 108 (62 - 67)	_	147 - 157 (91 - 98)	91 - 99 (57 - 62)	47 - 51 (29 - 32)	41 - 45 (25 - 28)
Half throttle	32 - 36 (20 - 22)	57 - 65 (35 - 40)	114 - 124 (71 - 77)	65 - 75 (40 - 4 7)	28 - 36 (17 - 22)	12 - 16 (7 - 10)	41 - 45 (25 - 28)

VEHICLE SPEED WHEN PERFORMING AND RELEASING LOCK-UP

	D ₄		
Throttle position	Vehicle speed km/h (MPH)		
	Lock-up ON	Lock-up OFF	
Full throttle	_		
Half throttle	71 - 79 (44 - 49)	71 - 79 (44 - 49)	

STALL REVOLUTION

Stall revolution	rpm	2,100 - 2,300

LINE PRESSURE

Engine speed	Line pressure kPa (kg/cm², psi)		
rpm	D, 2 and 1 positions	R position	
Idle	422 - 461 (4.3 - 4.7, 61 - 67)	667 - 706 (6.8 - 7.2, 97 - 102)	
Stall	883 - 961 (9.0 - 9.8, 128 - 139)	1,393 - 1,471 (14.2 - 15.0, 202 - 213)	

@[

MA

LC

EC

FE

CL

MT

PD

FA

RA

ST

RS

BT

 $\mathbb{H}\mathbb{A}$

AT-113 629

SERVICE DATA AND SPECIFICATIONS (SDS) Specifications and Adjustment (Cont'd)

RETURN SPRINGS

Unit: mm (in)

Parts		Item				
		Г	aits	Part No.	Free length	Outer diameter
		1	4th speed cut valve spring	31756-48X09	23.5 (0.925)	7.0 (0.276)
		2	Pressure regulator valve spring	31742-48X16	48.5 (1.909)	12.1 (0.476)
		3	Pressure modifier valve spring	31742-48X13	40.83 (1.6075)	8.0 (0.315)
		4	1-2 shift valve spring	31762-48X00	43.4 (1.709)	6.0 (0.236)
		(5)	2-3 shift valve spring	31762-48X01	42.7 (1.681)	9.0 (0.354)
	Upper body	6	3-4 shift valve spring	31762-48X06	44.03 (1.7335)	8.0 (0.315)
	Орроговау	7	Accumulator control valve spring	31742-48X02	29.3 (1.154)	8.0 (0.315)
			3-2 downshift valve spring		_	
		8	2-3 throttle modifier valve spring	31742-41X21	33.0 (1.299)	6.5 (0.256)
Control valve		9	4-2 relay valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)
JOILIO VAIVE		10	Torque converter clutch control valve spring	31742-48X07	20.0 (0.787)	5.45 (0.2146)
		1	Throttle valve & detent valve spring	31802-48X02	34.23 (1.3476)	11.0 (0.433)
		2	Kickdown modifier valve spring	31756-48X01	45.3 (1.783)	7.0 (0.276)
	3	1st reducing valve spring	31756-48X08	29.7 (1.169)	7.2 (0.283)	
	l	4	→ Overrun clutch reducing valve enring 🕒	31742-48X21	33.2 (1.307)	7.7 (0.303)
Lower	Lower body	Lower body S		31742-48X05	31.0 (1.220)	5.2 (0.205)
			3-2 timing valve spring	31742-48X15	23.0 (0.906)	7.0 (0.276)
		7	Torque converter relief valve spring	.31742-41X23	38.0 (1.496)	9.0 (0.354)
	8	4-2 sequence valve spring	31756-41X00	29.1 (1.146)	6.95 (0.2736)	
	1	1	Primary valve spring	31742-48X11	19.1 (0.752)	9.05 (0.3563)
iovernor valve)	2	Secondary governor valve I spring	31742-48X09	30.58 (1.2039)	9.2 (0.362)
		3	Secondary governor valve II spring	31742-48X10	16.79 (0.6610)	9.0 (0.354)
everse clutch			16 pcs	31505-41X02	19.69 (0.7752)	11.6 (0.457)
igh clutch			16 pcs	31505-21X03	22.06 (0.8685)	11.6 (0.457)
orward clutch Overrun clutch			20 pcs	31521-41X00 (Assembly)	35.77 (1.4083)	9.7 (0.382)
ow & reverse	brake		18 pcs	31505-41X05	22.3 (0.878)	11.6 (0.457)
		****	Spring (A)	31605-41X05	45.6 (1.795)	34.3 (1.350)
and servo			Spring B	31605-41X00	53.8 (2.118)	40.3 (1.587)
			Spring ©	31605-41X01	29.0 (1.169)	27.6 (1.087)
	***		Accumulator (A)	31605-41X02	43.0 (1.693)	18.0 (0.709)
			Accumulator (B)	31605-41X15	66.0 (2.598)	20.8 (0.819)
ccumulator			Accumulator ©	31605-41X09	45.0 (1.772)	29.3 (1.154)
			Accumulator (D)	31605-41X06	58.4 (2.299)	17.3 (0.681)

ACCUMULATOR O-RING

A		Diamete	r mm (in)	
Accumulator	A	B	©	(D)
Small diameter end	28.6 (1.13)	31.5 (1.24)	44 (1.73)	28.6 (1.13)
Large diameter end	44 (1.73)	48.8 (1.92)	48.8 (1.92)	44 (1.73)

AT-114 630

SERVICE DATA AND SPECIFICATIONS (SDS)

Specifications and Adjustment (Cont'd)

ode number		49X10			
Reverse clutch]				
Number of drive p	l plates	İ	2		
Number of driven		2			
1	piates		- 2.05		
Thickness of drive plate	Standard		- 0.0807)		
mm (in)	Wear limit	1.80 (0.0709)		
Clearance	Standard	0.5 - 0.8 (0.	.020 - 0.031)		
mm (in)	Allowable limit	1.2 (0.047)			
		Thickness mm (in)	Part number		
Thickness of retai	ning plate	4.8 (0.189) 5.0 (0.197) 5.2 (0.205) 5.4 (0.213) 5.6 (0.220)	31537-42X 31537-42X 31537-42X 31537-42X 31537-42X		
2. High clutch					
Number of drive p	lates		5		
Number of driven	plates		5		
Thickness of drive plate	Standard	1.52 - 1.67 (0.0598 - 0.0657)			
mm (in)	Wear limit	1.40 (0	1.40 (0.0551)		
Clearance	Standard	1.8 - 2.2 (0.071 - 0.087			
mm (in)	Allowable limit	2.8 (0.110)			
		Thickness mm (in)	Part numbe		
Thickness of retai	ning plate	3.4 (0.134) 3.6 (0.142) 3.8 (0.150) 4.0 (0.157) 4.2 (0.165) 4.4 (0.173) 4.6 (0.181) 4.8 (0.189)	31537-41X 31537-41X 31537-41X 31537-41X 31537-41X 31537-41X 31537-41X 31537-41X		
3. Forward clutch					
Number of drive p	lates	:	5		
Number of driven	plates	5			
Thickness of drive plate	Standard	1.52 - 1. 67 (0.0598 - 0.0657)			
mm (in)	Wear limit	1.40 (0	0.0551)		
Clearance mm (in)	Standard		- 0.75 - 0.0295)		
	Allowable limit	1.85 (0).0728)		
		Thickness mm (in)	Part numbe		
Thickness of retain	ning plate	8.0 (0.315) 8.2 (0.323) 8.4 (0.331) 8.6 (0.339) 8.8 (0.346) 9.0 (0.354) 9.2 (0.362)	31537-41X0 31537-41X0 31537-41X0 31537-41X0 31537-41X0 31537-41X0 31537-41X0		

Overrun clutch			÷
Number of drive p	olates		3
Number of driven	plates	-	5
Thickness of drive plate	Standard	l	- 2.05 - 0.0807)
mm (in)	Wear limit	1.80 (0.0709)	
Clearance	Standard	1.0 - 1.4 (0.	039 - 0.055)
mm (in)	Allowable limit	2.0 (0	0.079)
		Thickness mm (in)	Part number
Thickness of retai	ning plate	4.2 (0.165) 4.4 (0.173) 4.6 (0.181) 4.8 (0.189) 5.0 (0.197)	31537-41X80 31537-41X81 31537-41X82 31537-41X83 31537-41X84
. Low & reverse b	rake		
Number of drive p	olates	6	
Number of driven	plates	6	
Thickness of drive plate mm (in)	Standard	1.52 - 1.67 (0.0598 - 0.0657)	
	Wear limit	1.80 (0.0709)	
Clearance	Standard	0.8 - 1.1 (0.031 - 0.043)	
mm (in)	Allowable limit	2.3 (0	0.091)
		Thickness mm (in)	Part number
Thickness of retai	ning plate	7.0 (0.276) 7.2 (0.283) 7.4 (0.291) 7.6 (0.299) 7.8 (0.307) 8.0 (0.315)	31667-41X12 31667-41X13 31667-41X14 31667-41X07 31667-41X08 31667-41X00
		8.2 (0.323) 8.4 (0.331) 8.6 (0.339) 8.8 (0.346) 9.0 (0.354) 9.2 (0.362)	31667-41X01 31667-41X02 31667-41X03 31667-41X04 31667-41X05 31667-41X06
			1
. Brake band		•	
. Brake band Anchor end bolt ti	ghtening torque N·m (kg-m, in-lb)	4 - 6 (0.4 -	0.6, 35 - 52)
	N·m (kg-m, in-lb)		0.6, 35 - 52) .5

AT-115



























DX

631

SERVICE DATA AND SPECIFICATIONS (SDS) Specifications and Adjustment (Cont'd)

OIL PUMP AND LOW ONE-WAY CLUTCH

Oil pump clearance mm (in)	
Cam ring — oil pump housing	
Standard	0.01 - 0.024 (0.0004 - 0.0009)
Rotor, vanes and control piston — oil pump housing	
Standard	0.03 - 0.044 (0.0012 - 0.0017)
Seal ring clearance mm (in)	
Standard	0.10 - 0.25 (0.0039 - 0.0098)
Allowable limit	0.25 (0.0098)

TOTAL END PLAY

Total end play "T ₁ "	0.25 - 0.55 mm (0.0098 - 0.0217 in)		
	Thickness mm (in)	Part number	
Thickness of oil pump cover bearing race	0.8 (0.031) 1.0 (0.039) 1.2 (0.047) 1.4 (0.055) 1.6 (0.063) 1.8 (0.071) 2.0 (0.079)	31435-41X01 31435-41X02 31435-41X03 31435-41X04 31435-41X05 31435-41X06 31435-41X07	

PARKING GEAR

Seal ring — ring groove	mm (in)	
Standard		0.15 - 0.40 (0.0059 - 0.0157)
Allowable limit		0.40 (0.0157)

Reverse clutch drum end play "T ₂ "	0.55 - 0.90 mm (0.0217 - 0.0354 in)		
	Thickness mm (in)	Part number	
Thickness of oil pump thrust washer	0.9 (0.035) 1.1 (0.043) 1.3 (0.051) 1.5 (0.059) 1.7 (0.067) 1.9 (0.075)	31528-21X01 31528-21X02 31528-21X03 31528-21X04 31528-21X05 31528-21X06	

REMOVAL AND INSTALLATION

Manual control linkage		
Number of returning revolutions for lock nut	2	
Lock nut tightening torque N·m (kg-m, ft-lb)	11 - 15 (1.1 - 1.5, 8 - 11)	
Distance between end of clutch housing and torque converter mm (in)	26.0 (1.024) or more	

AT-116 632

TRANSFER

SECTION TF

LC

CONTENTS

PREPARATION	2
Special Service Tools	2
Commercial Service Tools	
Replacing Oil Seal	4
Center Case Oil Seal	4
Shift Shaft Oil Seal	4
Rear Oil Seal	5
REMOVAL AND INSTALLATION	6
TRANSFER GEAR CONTROL	
MAJOR OVERHAUL	8
Case Components	8
Gear Components	9
Shift Control Components	10
DISASSEMBLY	11

REPAIR FOR COMPONENT PARTS	15
Mainshaft	15
Front Drive Shaft	17
Counter Gear	18
Main Gear	18
Front Case	20
Shift Shaft Oil Seal	20
Front Case Cover	20
Cover Oil Seal	20
Bearing Retainer	21
Oil Catcher	21
Rear Case	21
Rear Oil Seal	21
Air Breather	21
Shift Control Components	22
ASSEMBLY	23
SERVICE DATA AND SPECIFICATIONS (SDS).	30
General Specifications	30
Inspection and Adjustment	30

FE

CL

MT

AT

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

BT

HA

EL

Special Service Tools


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description			
ST38060002 (J34311) Flange wrench	a	Removing companion flange nut Installing companion flange nut		
	NT428	a: 480 mm (18.90 ln) b: Pitch dia.: 75 mm (2.95 in) Pin dia.: 10 mm (0.39 in)		
ST30021000 (J22912-01) Puller	a b	Removing counter gear front bearing (Use with ST36710010) Removing L & H hub		
	NT411	a: 110 mm (4.33 in) dia. b: 68 mm (2.68 in) dia.		
ST30031000 (J22912-01) Puller	a b	Removing counter gear rear bearing (Use with ST36710010)		
	NT411	a: 90 mm (3.54 in) dia. b: 50 mm (1.97 in) dia.		
ST33290001 (J34286) Puller	a	Removing center case oil seal Removing rear oil seal		
	NT414	a: 250 mm (9.84 in) b: 160 mm (6.30 in)		
ST33051001 J22888) Puller		Removing companion flange		
	NT429	a: 135 mm (5.31 in) b: 100 mm (3.94 in) c: 130 mm (5.12 in)		
6T30720000 1) (J25273) 2) (J25405)		Installing center case oil seal Installing rear oil seal		
Orift	NT115	a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.		
ST36710010) Orift		Removing counter gear front bearing (Use with ST30021000) Removing counter gear rear bearing (Use with ST30031000)		
	NT063	a: 34.5 mm (1.358 in) dia.		

TF-2


PREPARATION

		Special Serv	ice Tools (Cont'd)	•
Tool number (Kent-Moore No.) Tool name	Description			- (_ (
ST33061000 (J8107-2) Drift		a. Control of the con	Removing main gear bearing	_
	NT116	b	a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.	_ [
ST30613000 ① (J25742-3) ② (J34339) Drift		b	Installing main gear bearing Installing cover oil seal	
	NT073	a	a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.	
(J35864) Drift			Installing shift shaft oil seal	-
	NT117	a bi	a: 26 mm (1.02 in) dia. b: 20 mm (0.79 in) dia. c: 150 mm (5.91 in)	() []
(J26092) Drift			Seating counter gear assembly	-
	NT065	161	a: 44.5 mm (1.752 in) dia. b: 38.5 mm (1.516 in) dia.	<i> </i> -
(J34291) Shim setting gauge set	NT101		Selecting counter gear rear bearing shim	
(J34291-20) Plunger-shim setting gauge	NT118		Selecting counter gear rear bearing shim	
	NITIO	Commercial S	Service Tools	-
Tool name	Description	· · · · · · · · · · · · · · · · · · ·		•
Puller	NT077		Removing front drive shaft front bearing Removing front drive shaft rear bearing Removing main gear bearing	
Drift			① Installing mainshaft rear bearing ② Installing L & H hub ① a: 50 mm (1.97 in) dia. b: 42 mm (1.65 in) dia. c: 180 mm (7.09 in)	
	NT117	a 01	② a: 60 mm (2.36 in) dia. b: 50 mm (1.97 in) dia. c: 60 mm (2.36 in)	




Replacing Oil Seal CENTER CASE OIL SEAL


- Remove front propeller shaft. Refer to PD sa
- 1. Remove front propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- 2. Remove companion flange nut.




Remove companion flange.



- 4. Remove center case oil seal.
- 5. Install center case oil seal.
- Before installing, apply multi-purpose grease to seal lip.
- Install companion flange.



- 7. Tighten companion flange nut.
 [O]: 226 324 N·m (23 33 kg-m, 166 239 ft-lb)
- 8. Install front propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").



SHIFT SHAFT OIL SEAL

- 1. Remove front propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").
- Remove companion flange. Refer to "CENTER CASE OIL SEAL", TF-4.
- 3. Remove transfer control lever from transfer outer shift lever. Then remove outer shift lever.

PREPARATION

Screwdriver SMT491A

Replacing Oil Seal (Cont'd)

4. Remove shift shaft oil seal.

Be careful not to damage cross shaft.




MA

EΜ

LC

EC



ST33290001

AMT087

(J34286)

- Install shift shaft oil seal.
- Before installing, apply multi-purpose grease to seal lip.
- Install transfer control linkage.
- Install companion flange. Refer to "CENTER CASE OIL SEAL", TF-4.
- 8. Install front propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").



al and

MT

REAR OIL SEAL





2. Remove rear oil seal.



PD


FA

n A

RA

88

- Install rear oil seal.
- Before installing apply multi-purpose grease to seal lip.
- 4. Install rear propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT").



\$T

RS


Te


 $\mathbb{H}\mathbb{A}$

EL

TF-5

637








Removal

- 1. Drain oil from transfer and transmission.
- Remove front and rear propeller shaft. Refer to PD section ("Removal and Installation", "PROPELLER SHAFT"). Insert plug into rear oil seal after removing propeller shaft.
- Be careful not to damage spline, sleeve yoke and rear oil seal, when removing propeller shaft.
- Remove torsion bar spring. Refer to FA section ("Torsion Bar Spring", "FRONT SUSPENSION"). Then remove second crossmember.
- 4. Remove transfer control lever from transfer outer shift lever.
- 5. Separate transfer from transmission.

Support transfer while removing it.




Installation

Apply recommended sealant to mating surface of transfer case to transmission.

Recommended sealant:

Nissan genuine part (KP610-00250) or equivalent




Tighten bolts securing transfer.

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	f mm (in)	
1	31 - 41 (3.2 - 4.2, 23 - 30)	45 (1.77)	
2	31 - 41 (3.2 - 4.2, 23 - 30)	60 (2.36)	


TF-6 638


TRANSFER GEAR CONTROL



SMT809C


Case Components






AMT089

Shift Control Components






- Remove companion flange nut.
- Remove companion flange.



- MA
- LC
- EC



Oil cover

Oil gutter

Snap ring

- Remove 4WD switch.
- Remove rear case.
- Be careful not to damage the mating surface.



CL

MT

Remove oil cover and oil gutter.

Remove bolts securing bearing retainer.

Remove snap ring from 2-4 shift rod.

AT

PD)

FA

RA

- This step is necessary to remove mainshaft from center case.

BR

ST

RS


BT


Remove bolts securing center case to front case, then separate

HA

EL


IDX





center case from front case.

TF-11




9. Measure low gear end play.


Standard:

0.2 - 0.35 mm (0.0079 - 0.0138 in)


 If end play is not within specification, check low gear and L & H hub for wear.




- 10. Disassemble center case assembly.
- a. Remove snap ring from mainshaft.




b. Remove low gear with L & H hub.



c. Remove needle bearing from main shaft.



d. Pay attention to the direction of the drive chain before removing it. (It must be reinstalled in the same direction.)



Remove mainshaft, front drive and drive chain as a set by tapping front end of mainshaft and front drive shaft alternately.


Be careful not to bend drive chain.



١

MA

LC



11. Disassemble front case assembly.

Remove switch, plugs, check springs and balls.




EC

FE

CL

MT




Remove lock pin from outer shift lever, then remove outer shift lever.



PD

FA

RA



SMT797A

Remove lock pin from inner shift lever, then drive out cross shaft and plug together.



ST


RS

BT




HA

EL




Remove 2-4 shift rod.


TF-13




e. Remove L & H shift rod and fork assembly with coupling sleeve.




f. Remove needle bearing from main gear.



g. Remove bolts securing front case cover, then remove case cover.





h. Remove counter gear by tapping lightly.





i. Remove main gear by tapping lightly.


REPAIR FOR COMPONENT PARTS











Mainshaft

DISASSEMBLY

1. Check front drive sprocket end play. Standard:

0.2 - 0.35 mm (0.0079 - 0.0138 in)

If end play is not within specification, check front drive sprocket and clutch gear for wear.

Remove retainer ring, speedometer drive gear and steel ball.

Be careful not to lose the steel ball.

Remove snap ring and spacer.

Use a press to remove front drive sprocket with mainshaft rear bearing and clutch gear together.

Remove needle bearing.

6. Remove bearing retainer, then remove snap ring and spacer.

GI

MA

LC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA


EL


IDX

REPAIR FOR COMPONENT PARTS

Mainshaft (Cont'd)








INSPECTION


Gear and shaft

- Check gears for excessive wear, chips or cracks.
- Check shaft for cracks, wear or bending.
- Check coupling sleeve for wear or damage.




Baulk ring

Check baulk ring for cracks or deformation.




Measure clearance between baulk ring and clutch gear.
 Baulk ring to clutch gear clearance:
 Refer to SDS, TF-30.



Bearing

 Make sure bearings roll freely and are free from noise, cracks, pitting or wear.



Mainshaft (Cont'd) **ASSEMBLY**

(3)

1. Press mainshaft front bearing onto mainshaft.

Pay attention to its direction.

MA

EM

Install spacer.

EC

尾

LC

Select and install snap ring with proper thickness.

Allowable clearance between snap ring and groove:


0 - 0.15 mm (0 - 0.0059 in) Available snap ring for mainshaft front bearing:

CL

Refer to SDS, TF-30. For further procedures, refer to "ASSEMBLY", TF-23.

MT

AT




Front Drive Shaft

DISASSEMBLY

Using a gear puller, remove front drive shaft front and rear bearings.

TF PD



INSPECTION

RA

FA

Sprocket and shaft

BR

Check sprocket for excessive wear, chips or cracks.

Check shaft for cracks or wear.

ST

Bearing

Make sure bearings roll freely and are free from noise, cracks, pitting or wear.


RS BT





Press front drive shaft front and rear bearings onto front drive shaft.

HA

EL









Counter Gear

DISASSEMBLY

 Use a press to remove counter gear front bearing, then remove front sub-gear, spacer and dish plate.



Use a press to remove counter gear rear bearing, then remove rear sub-gear, spacer and dish plate.




INSPECTION

Gear and shaft

- Check gears for excessive wear, chips or cracks.
- · Check shaft for cracks or wear.


Bearing

 Make sure bearings roll freely and are free from noise, cracks, pitting or wear.



ASSEMBLY


- 1. Install front sub-gear, dish plate and spacer, then press on counter gear front bearing.
- 2. Install rear sub-gear, dish plate and spacer, then press on counter gear rear bearing.



Main Gear DISASSEMBLY

Main gear bearing

1. Remove snap ring.




Main Gear (Cont'd)

2. Pull out main gear bearing.



MA

LC



Plug


 Always replace with a new one whenever it has been removed.



EC

CL

MT



ST30613000

SMT307A

(J25742-3)

INSPECTION

Gear and shaft

• Check gears for excessive wear, chips or cracks.

Check shaft for cracks or wear.



AT

Bearing

 Make sure bearings roll freely and are free from noise, cracks, pitting or wear.



(PD)



Main gear bearing

1. Press on main gear bearing.




명

ST

R\$

BT




Allowable clearance between snap ring and groove: 0 - 0.15 mm (0 - 0.0059 in)

Available snap ring for main gear bearing: Refer to SDS, TF-30.




EL

IDX



TF-19


651



Main Gear (Cont'd)

Plug

Apply sealant to plug, then install.




Front Case

SHIFT SHAFT OIL SEAL


Removal

- Use a screwdriver to pry out old seal.
- Be careful not to damage case.
- Always replace with a new one whenever it has been removed.



Installation


- Install new shift shaft oil seal until flush with case.
- Before installing, apply multi-purpose grease to seal lip.



Front Case Cover COVER OIL SEAL


Removal

- Drive out old seal from inside of front case cover.
- Be careful not to damage front case cover.



Installation

- Install new front case cover oil seal until it stops.
- Before installing, apply multi-purpose grease to seal lip.



Drift

SMT315A

Bearing Retainer

OIL CATCHER

Removal



Be careful not to damage bearing retainer.




Install oil catcher until it stops.

Be careful not to damage or distort oil catcher or bearing retainer.

Before installing, apply multi-purpose grease to seal lip.

MT

AT



Rear Case

REAR OIL SEAL

Removal

Pull out rear oil seal.

Installation


Install new rear oil seal until it stops.

Before installing, apply multi-purpose grease to seal lip.

BR

AIR BREATHER

Install as shown in illustration.



ST30720000 (J25405)

TF-21

653

G1

MA

LC

EC

FE

CL

PD)

FA

RA

ST


RS

BŢ

MA


EL

IDX



Shift Control Components INSPECTION


 Check contact surface and sliding surface for wear, scratches, projections or other faulty conditions.



L & H SHIFT ROD & FORK

Assemble as shown in illustration.


* Retaining pin is the same size as the one for 2-4 shift rod.




2-4 SHIFT ROD & FORK

Assemble as shown in illustration.

- * Retaining pins are the same size.
- Pay attention to the direction of fork guide collar.





- 1. Assemble front case.
- a. Install main gear assembly by tapping lightly.



- MA
- EM
- LC

- B SMT325A
- b. Apply sealant to the mating surface and bolts of front case cover, then attach it to the front case.
- These ten bolts should be coated with sealant.
 Bolts A:

ৃ : 16 - 21 N·m (1.6 - 2.1 kg-m, 12 - 15 ft-lb) Bolts B:

(1.9 - 24 N·m (1.9 - 2.4 kg-m, 14 - 17 ft-lb)

0.5


FE

- (4 17 ff-lb)
 - MT
- c. Apply gear oil to needle bearing and install it into main gear.



AT


- PD
- FA
- RA
- - RB
 - ST
 - R\$
 - 37
 - 0 ستا
- When replacing cross shaft, outer shift lever or outer shift lever lock pin, replace them as a set.
- HA




SMT326A


SMT327A

Ħ




Install cross shaft and inner shift lever.







f. Apply sealant to plug, then install it into front case.




g. Insert interlock plunger into front case.




h. Install L & H shift rod and fork assembly with coupling sleeve.




i. Install 2-4 shift rod.



- j. Install switches, check balls, check springs and plugs.
- Apply sealant to switches and plugs.





Seat counter gear assembly.




G]

MA

LC

EC



SMT591A

Place J34291-1 (bridge), J34291-2 (legs) and J34291-5 (gauging cylinder) on machined surface of center case, allowing gauging cylinder to rest on top outer portion of counter gear rear bearing. Lock gauging cylinder in place.

FE

GL

MT

Insert J34291-20 (gauging plunger) into J34291-5 (gauging cylinder).

PD

FA

RA

BR


ST


RS

BT


MA

IDX






Place bridge, legs, gauging cylinder and gauging plunger onto machined surface of front case assembly, allowing gauging plunger to drop until it contacts counter gear rear bearing mating surface.




- Lock gauging plunger in place and use feeler gauge to measure clearance between gauging cylinder and gauging plunger.
- Use measured distance to select correct counter gear rear bearing shim.


Allowable counter gear clearance: 0 - 0.2 mm (0 - 0.008 in) Available counter gear rear bearing shim: Refer to SDS, TF-30.




- 3. Place suitable shim with grease on counter gear rear bearing.
- 4. Apply gear oil to each part in front case.




- 5. Assemble center case assembly.
- a. Install mainshaft on center case by tapping lightly.
- Apply gear oil to mainshaft front bearing.





- b. Install bearing retainer.
 - : 16 21 N·m (1.6 21 kg-m, 12 15 ft-lb)




- Put drive chain onto the front drive sprocket and front drive shaft, and then put them in center case.
- Be sure to install drive chain in same direction as removed.








Make sure shafts are aligned in the case.



SMT411A


e. Apply gear oil to needle bearings and install them into front drive sprocket.

• These needle bearings will be installed more easily if front drive sprocket is rotated while installing them.



f. Install 2-4 coupling sleeve with 2-4 shift fork.

Pay attention to the direction of the coupling sleeve.



g. Install shifting inserts and spread spring.

Pay attention to the direction of shifting inserts.

IDX





LO

EC

FE

OL.

MT

TF

PD

RA


BR

\$T


RS

BT

HA




- h. Install baulk ring, then install clutch gear and mainshaft rear bearing.
- Place wooden block under mainshaft in order to protect mainshaft front bearing.




- i. Install spacer.
- j. Select and install snap ring with proper thickness.

Allowable clearance between snap ring and groove: 0 - 0.15 mm (0 - 0.0059 in)


Available snap ring for mainshaft rear bearing: Refer to SDS, TF-30.




- k. Install steel ball, speedometer drive gear and retainer ring.
- Steel ball is the smallest check ball for this unit.



- Install low gear and bearing onto mainshaft.
- Apply gear oil to needle bearing.



- m. Install L & H hub and snap ring onto mainshaft.
- Pay attention to the direction of L & H hub.



Measure low gear end play. Standard: 0.2 - 0.35 mm (0.0079 - 0.0138 in)

MA

G

EM

LC

Apply sealant to mating surface of center case, then attach to front case and tighten bolts.

EC

FE

CL.

MT

AT

(PD)

FA

RA


BR

ST

RS

MA

1DX





7. Install snap ring to 2-4 shift rod.



SMT343A


Apply gear oil to each part in center case.





11. Install 4WD switch.

Apply sealant to switch threads.



SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Transfer model		·	TX10A	
Gear ratio	High		1.000	
Gearrano	Low		2.020	
Number of teeth	Main gear		29	
	Low gear		37	
	Counter	High	38	
	gear	Low	24	
	Front drive sprocket		41	
	Front drive shaft		41	
Oil capacity	ť	(US qt, Imp qt)	2.2 (2-3/8, 2)	

Inspection and Adjustment

GEAR END PLAY

Unit: mm (in) Front drive sprocket 0.2 - 0.35 (0.0079 - 0.0138) Low gear 0.2 - 0.35 (0.0079 - 0.0138) Counter gear 0 - 0.2 (0 - 0.008)

CLEARANCE BETWEEN BAULK RING AND CLUTCH GEAR

	Unit: mm (in)
Standard	Wear limit
1.0 - 1.5 (0.039 - 0.059)	0.5 (0.020)

AVAILABLE SHIM

Counter gear rear bearing

Mowable clearance	0 - 0.2 mm (0 - 0.008 in)
Thickness mm (in)	Part number
0.1 (0.004)	33112-C6900
0.2 (0.008)	33112-C6901
0.3 (0.012)	33112-C6902
0.4 (0.016)	33112-C6903
0.5 (0.020)	33112-33G00
0.6 (0.024)	33112-33G01

AVAILABLE SNAP RING

Mainshaft front bearing

Allowable clearance	0 - 0.15 mm (0 - 0.0059 in)
Thickness mm (in)	Part number
3.1 (0.122)	33138-73P10
3.19 (0.126)	33138-73P11
3.28 (0.129)	33138-73P12

Mainshaft rear bearing

0 - 0.15 mm (0 - 0.0059 in)
Part number
33138-73P20
33138-73P21
33138-73P22
33138-73P23
33138-73P24

Main gear bearing

Allowable clearance	0 - 0.15 mm (0 - 0.0059 in)
Thickness mm (in)	Part number
2.60 (0.102)	33114-73P00
2.69 (0.106)	33114-73P01
2.78 (0.109)	33114-73P02

662 TF-30

PROPELLER SHAFT & DIFFERENTIAL CARRIER

SECTION PD

CONTENTS

PREPARATION2
Special Service Tools2
Propeller shaft
PROPELLER SHAFT7
On-vehicle Service9
Removal and Installation9
Inspection9
Disassembly 10
Assembly11
Assembly11
Float dubin
Final drive
ON-VEHICLE SERVICE
Front Oil Seal Replacement (Front final drive)13
Front Oil Seal Replacement
(Rear final drive: Model H233B)13
Rear Cover Gasket Replacement
(Rear final drive: Model C200)14
REMOVAL AND INSTALLATION (Front final
drive)15
REMOVAL AND INSTALLATION (Rear final drive)16
R180A
FRONT FINAL DRIVE17
DISASSEMBLY 18
Pre-inspection18
Final Drive Housing18
Differential Case
Extension Tube and Differential Side Shaft21
INSPECTION23
Ring Gear and Drive Pinion23
Differential Case Assembly23
Bearing23

ADJUSTMENT	24
Side Bearing Preload	24
Pinion Gear Height and Pinion Bearing Preload	
Tooth Contact	
ASSEMBLY	
Extension Tube and Differential Side Shaft	30
Differential Case	30
Final Drive Housing	
•	
H190A	
REAR FINAL DRIVE	35
DISASSEMBLY	
Pre-inspection	
Differential Carrier	
Differential Case	
INSPECTION	
Ring Gear and Drive Pinion	
Differential Case Assembly	
Bearing	
LIMITED SLIP DIFFERENTIAL	
Preparation for Disassembly	
Disassembly	
Inspection	
Assembly	
ADJUSTMENT	
Side Bearing Preload	
Pinion Gear Height	
Tooth Contact	
ASSEMBLY	
Differential Case	
Differential Carrier	

CONTENTS (Cont'd.)

REAR FINAL DRIVE	57
DISASSEMBLY	58
Pre-inspection	58
Differential Carrier	
Differential Case	60
INSPECTION	
Ring Gear and Drive Pinion	
Differential Case Assembly	
Bearing	
LIMITED SLIP DIFFERENTIAL	
Preparation for Disassembly	
Disassembly	
Inspection	
Adjustment	
Assembly	
ADJUSTMENT	
Side Bearing Preload	
Pinion Gear Height	
Tooth Contact	
ASSEMBLY	
Differential Case	
Differential Carrier	_

C200

H233B	MA
REAR FINAL DRIVE80	avuvo
DISASSEMBLY81	r=r.o
Pre-inspection81	
Differential Carrier81	
Differential Case83	LC
INSPECTION85	50
Ring Gear and Drive Pinion85	
Differential Case Assembly85	EC
Bearing85	
LIMITED SLIP DIFFERENTIAL86	
Preparation for Disassembly86	FE
Disassembly86	
Inspection87	@I
Adjustment88	CL
Assembly89	
ADJUSTMENT92	MT
Pinion Gear Height92	נו טעים
Tooth Contact95	
ASSEMBLY96	AT
Differential Case96	
Differential Carrier97	
SERVICE DATA AND SPECIFICATIONS (SDS)100	TF
Propeller Shaft100	
Final Drive102	
General Specifications102	PD
Inspection And Adjustment (R180A)103	
Inspection And Adjustment (H190A)104	FA
Inspection And Adjustment (C200)105	IT/AL
Inspection And Adjustment (H233B)106	
	RA

BR

ST

RS

BT

HA

EL

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number	Description			Unit app	olication	
(Kent-Moore No.) Tool name	Description		R180A	H190A	C200	H233B
ST3127S000 (See J25765-A) Preload gauge ① GG91030000 (J25765) Torque wrench ② HT62940000 (—) Socket adapter ③ HT62900000 (—) Socket adapter	1—————————————————————————————————————	Measuring pinion bearing preload and total preload	x	X	X	х
KV38100800 (J25604-01), (J34310) Differential attachment		Mounting final drive (To use, make a new hole.)	x		_`	
	NT119	a: 152 mm (5.98 in)				
ST06310000 (J25602-01) Differential attachment	NT140	Mounting final drive	_	х	_	_
ST06340000 (J24310) Differential attachment	NT140	Mounting final drive	_		_	×
ST32580000 (J34312) Differential side bearing adjusting nut wrench	NT141	Adjusting side bearing pre- load and backlash (ring gear- drive pinion)		_		X
ST33290001 (J25810-A) Side bearing outer race puller	NT076	Removing side bearing outer race and side oil seal	х			
ST38060002 (J34311) Drive pinion flange wrench	NT113	Removing and installing propeller shaft lock nut and drive pinion lock nut	х	x	х	

R180A	Unit ap	C200	H233B
- Anno		_	X
X	×	x	
X	x	x	X
Х	X	x	X
	:		
х	x	×	
_	_	_	x
_	_	x	x
	x	x x	

PD-3 667

Restalling pinion rear bearing outer race		Sp	ecial Service Tools	(Cont	d)				
NT073 NT07				Unit application					
ST30611000 (J25742-1) Drift ST30613000 (J25742-2) Drift ST30613000 (J25742-3) Drift ST30720000 (J25742-3) Drift Drif		Description		R180A	H190A	C200	H233B		
ST30621000	(J25267)	b	a: 8 mm (0.31 in)			х			
A	(J25742-1)	NT090		x	х	х	х		
Drift Drif	(J25742-5)	a	outer race a: 79 mm (3.11 in) dia.	х	х	Х	X		
Drift	(J25742-2)	NT073	outer race a: 61.5 mm (2.421 in) dia.	Х					
Oil seal fitting tool ST30720000 (J25405) Drift bar KV38102510 ((J25742-3)	a a	outer race a: 72 mm (2.83 in) dia.		х	X	х		
(J25273) Gear carrier front oil seal drift — X	(—) Oil seal fitting tool ① ST30720000 (J25405) Drift bar ② KV38102510 (—)	a b 1 c d	a: 77 mm (3.03 in) dia. b: 55 mm (2.17 in) dia. c: 71 mm (2.80 in) dia.	X	X		X		
a: 85 mm (3.35 in) dia. NT115 b: 60 mm (2.36 in) dia.	(J25273) Gear carrier front oil seal	a b	a: 85 mm (3.35 in) dia.	_	_	x	x		

. <u> </u>	Sp	ecial Service Tools	(Cont	d)		
Tool number	Description		Unit application			
(Kent-Moore No.) Tool name	Description	_	R180A	H190A	C200	H233B
ST33720000 (J25817) Differential side retainer guide	NT138	Installing side retainer	x	_	_	_
ST33270000 J25809) Side oil seal drift	NT526	Installing side oil seal a: 62 mm (2.44 in) dia. b: 28 mm (1.10 in) dia.	×	_	_	
(J34309) Differential shim selector	NT134	Adjusting bearing pre-load and gear height	x	x	x	X
(J25269-4) Side bearing discs (2 Req'd)	NT136	Selecting pinion height adjusting washer	x	_	x	
(J25269-18) Side bearing discs (2 Req'd)	NT135	Selecting pinion height adjusting washer		х	<u> </u>	х
(J8129) Spring gauge	NT127	Measuring carrier turning torque	x	х	x	х
J35764) Gear carrier side oil seal drift		Installing side oil seal	×		_	_

EĹ

PD-5 669


	Special Service Tools (Cont'd)						
Tool number			Unit application				
(Kent-Moore No.) Tool name	Description		R180A	H190A	C200	H233B	
KV381051S0 (—) Rear axle shaft durmmy ① KV38105110 (—) Torque wrench side ② KV38105120 (—) Vice side	NT142	Checking differential torque on limited slip differential	_	x	x	_	
KV381052S0 (—) Rear axle shaft dummy ① KV38105210 (—) Torque wrench side ② KV38105220		Checking differential torque on limited slip differential	_	_	-	x	

PD-6


(--) Vice side

NT142

Front propeller shaft (Model 2F71H)



Rear propeller shaft (Model 2S80B)



MA

LC

ËC

FE

CL

MT

AT

TF

PD

RA

BR

ST


RS

BT


HA


IDX


Rear propeller shaft (Model 3S80B)





Rear propeller shaft (Model 3S71A)














On-vehicle Service

PROPELLER SHAFT VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

- 1. Raise rear end of vehicle until wheels are clear of the ground.
- 2. Measure propeller shaft runout at several points along propeller shaft by rotating final drive companion flange using hands.
- 3. If runout exceeds specifications, disconnect propeller shaft at final drive companion flange. Rotate companion flange 180 degrees, then reconnect propeller shaft.

Runout limit: 0.6 mm (0.024 in)

- 4. Check runout again. If runout still exceeds the limit, replace propeller shaft assembly.
- 5. Perform road test.

APPEARANCE CHECKING

- Inspect propeller shaft tube surface for dents or cracks and replace as necessary.
- Check center bearing for noise or damage and replace as necessary.

Removal and Installation

1. Place matching marks on flanges, then separate propeller shaft from final drive.

- 2. Remove propeller shaft.
- Insert plug into rear oil seal after removing rear propeller shaft.

Inspection

 Inspect propeller shaft runout. If runout exceeds the limit, replace propeller shaft assembly.

Runout limit: 0.6 mm (0.024 in)



MA

LC

EC

FE

GL

-

MT

AT

TE

....

PD

FA

RA

BR

ST

RS

BT

HA

EL

10X

PROPELLER SHAFT

SPD874


Inspection (Cont'd)

Inspect journal axial play.

If play exceeds the limit, replace propeller shaft assembly.

Journal axial play:


0.02 mm (0.0008 in) or less




Disassembly

CENTER BEARING

 Place matching marks on flanges, then separate 2nd tube from 1st tube.




2. Place matching marks on the flange and shaft.



- 3. Remove locking nut using Tool.
 - Tool numbers: R180A, H190A, C200 ST38060002 (J34311) H233B


KV38104700 (J34311)

4. Remove companion flange using puller.



5. Remove center bearing using Tool and press. Tool number: ST30031000 (J22912-01)

PROPELLER SHAFT



Disassembly (Cont'd) **JOURNAL**

NOTE:

1. Place matching marks on propeller shaft and flange or yoke.



ĒM

MA

LC

Remove snap ring.

EC

FE

CL.

MT

Remove pushed out journal bearing by lightly tapping yoke with a hammer, taking care not to damage journal and yoke hole.

TF

RA

4. Remove bearing at opposite side in above operation. Put marks on disassembled parts so that they can be reinstalled in their original positions.

BR


ST

RS

BT

HA

EL



Assembly

SPD732

SPD131


CENTER BEARING

When installing center bearing, position the "F" mark on center bearing toward front of vehicle.


Apply a coat of multi-purpose lithium grease containing molybdenum disulfide to the end face of the center bearing and both sides of the washer.

PROPELLER SHAFT

Assembly (Cont'd)




- Stake the nut. Always use new one.
- Align match marks when assembling tubes.



JOURNAL


1. Assemble journal bearing. Apply recommended multi-purpose grease on bearing inner surface.

When assembling, be careful that needle bearing does not fall down.




 Select snap ring that will provide specified play in axial direction of journal, and install them. Refer to SDS, PD-101.

Select snap rings with a difference in thickness at both sides within 0.06 mm (0.0024 in).




3. Adjust thrust clearance between bearing and snap ring to zero by tapping yoke.



 Check to see that journal moves smoothly and check for axial play.

Axial play: 0.02 mm (0.0008 in) or less



SPD735

SPD736

Front Oil Seal Replacement (Front final drive)

Remove front propeller shaft.

Loosen drive pinion nut.

Tool number: ST38060002 (J34311)




MA

EM

L©





Remove companion flange using puller.



CL





AT








FA

RA



For final drive models using collapsible spacer (H190A, C200), bearing preload must be adjusted whenever companion flange



Tool number:

Remove front oil seal.

ST30720000 (J25405)

Install companion flange and drive pinion nut.

Install propeller shaft. 7.



RS

BT

MA

IDX

EL


Remove propeller shaft.

Front Oil Seal Replacement (Rear final drive: Model H233B)

Loosen drive pinion nut.

Tool number: KV38104700 (J34311)


is removed. Therefore, final drive overhaul is required.



Tool


CAUTION:

1.




Front Oil Seal Replacement (Rear final drive: Model H233B) (Cont'd)


3. Remove companion flange.



Remove front oil seal.





- Apply multi-purpose grease to cavity at sealing lips of oil seal. Press front oil seal into carrier.
- Tool number: KV38100500 (J25273)
 6. Install companion flange and drive pinion nut.
- 7. Install rear propeller shaft.




Rear Cover Gasket Replacement (Rear final drive: Model C200)

- Drain gear oil.
- 2. Remove rear cover and rear cover gasket.
- 3. Install new rear cover gasket and rear cover.
- 4. Fill final drive with recommended gear oil.







Removal

Remove front propeller shaft.

Remove drive shaft. Refer to FA section ["Drive Shaft", "FRONT AXLE (4WD)"].

Remove engine mounting bolts and raise up engine.

Remove front final drive together with differential mounting member.

EM LC

Gl

MA

Installation

1. Install front final drive assembly together with differential mounting member.

EC

FE

CL

MT

Tighten front final drive securing bolts and nuts by following the procedure to prevent drive train vibration.

Temporarily tighten nut (A). a.

Temporarily tighten nut (B). b.

TF

PD

FA

Tighten bolt © to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).

d. Tighten bolt (D) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).

Tighten nut (A) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m,

50 to 64 ft-lb).

Tighten nut (B) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m, 50 to 64 ft-lb).

Tighten nut (E) to the torque of 68 to 87 N·m (6.9 to 8.9 kg-m,

50 to 64 ft-lb). Install drive shaft. Refer to FA section ["Drive Shaft", "FRONT

AXLE (4WD)"].

f.

Install front propeller shaft.

BR

ST

RS

BT

HA

EL

Removal


Remove propeller shaft.

Plug front end of transfer.

Remove axle shaft.
 Refer to RA section ("REAR AXLE").


CAUTION:

- Be careful not to damage spline, sleeve yoke and front oil seal when removing propeller shaft.
- Before removing the final drive assembly or rear axle assembly, disconnect the ABS sensor harness connector from the assembly and move it away from the final drive/ rear axle assembly area. Failure to do so may result in the sensor wires being damaged and the sensor becoming inoperative.




Installation


Fill final drive with recommended gear oil.





Pay attention to the direction of gasket (H233B only).





SPD284AA











Pre-inspection

Before disassembling final drive, perform the following inspection.

- Total preload
- Turn drive pinion in both directions several times to set bearing rollers.
- b. Check total preload with Tool.

Tool number: ST3127S000 (J25765-A) Total preload:

1.2 - 2.3 N·m

(12 - 23 kg-cm, 10 - 20 in-lb)

Ring gear-to-drive pinion backlash
 Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash: 0.13 - 0.18 mm (0.0051 - 0.0071 in)

Ring gear runout

Check runout of ring gear with a dial indicator.

Runout limit:

0.05 mm (0.0020 in)

Tooth contact

Check tooth contact. Refer to "ADJUSTMENT", PD-29.

Final Drive Housing


1. Using three spacers [20 mm (0.79 in)], mount final drive assembly on Tool.

Tool number:

KV38100800 (J34310), (J25604-01)

Remove extension tube and differential side shaft assembly.

Final Drive Housing (Cont'd)




3. Remove differential side flange.

G[MA

LC

ĒC




4. Mark side retainers for identification. Remove side retainers. Be careful not to confuse right and left side retainers and shims.

FE

CL

MT



Tool

5. Extract differential case from final drive housing.

TF

AT

PD

FA

RA

Tool number: ST33290001 (J25810-A) Keep the side bearing outer races together with their respective inner cones — do not mix them up.

Remove side oil seal.

Remove side outer races.

ST


RS

BT

HA

EL

IDX




PD243

Loosen drive pinion nut.


Tool number: ST38060002 (J34311)

Remove companion flange with puller.




Final Drive Housing (Cont'd)

- Take out drive pinion together with pinion rear bearing inner cone, drive pinion bearing spacer and pinion bearing adjusting washer.
- 11. Remove front oil seal and pinion front bearing inner cone.




Remove pinion front and rear bearing outer races with brass drift.



13. Remove pinion rear bearing inner cone and drive pinion adjusting washer.

Tool number: ST30031000 (J22912-01)




Differential Case

1. Remove side bearing inner cones.

To prevent damage to bearing, engage puller jaws in grooves.

Tool numbers:

- (A) ST33051001 (J22888-20)
- ® ST33061000 (J8107-2)



Differential Case (Cont'd)

Be careful not to confuse the right and left hand parts.

GI

MA

LC

EC

- 2. Loosen ring gear bolts in a criss-cross fashion.
- 3. Tap ring gear off differential case with a soft hammer.

Tap evenly all around to keep ring gear from binding.



CL

MT

AT

 Separate differential case LH and RH.
 Put match marks on both differential case LH and RH sides prior to separating them.

TF

PD

FA

RA

Extension Tube and Differential Side Shaft

1. Remove differential side shaft assembly from extension tube.

BR

ST


RS

BT


 Cut rear axle bearing collar with cold chisel. Be careful not to damage differential side shaft.


MA


IDX



SPD024








Extension Tube and Differential Side Shaft (Cont'd)

3. Reinstall differential side shaft into extension tube and secure with bolts. Remove rear axle bearing by drawing out differential side shaft from rear axle bearing with puller.



4. Remove grease seal.

Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping. If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).

G[

MA

LC

EC

Differential Case Assembly Check mating surfaces of differential of

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft and thrust washers.

FE

C[

MT

AT

TF

PD

FA

RA

u uz u

 $\mathbb{B}\mathbb{R}$

. Thoroughly clean bearing.

Bearing

Check bearing for wear, scratches, pitting or flaking.
 Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.

ST

RS


BT


HA

 $\mathbb{D}\mathbb{X}$










For quiet and reliable final drive operation, the following five adjustments must be made correctly:


- 1. Side bearing preload
- Pinion gear height
- 3. Pinion bearing preload
- 4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-33.
- Ring and pinion gear tooth contact pattern.




Side Bearing Preload

A selection of carrier side retainer adjusting shims is required for successful completion of this procedure.

- Make sure all parts are clean. Also make sure the bearings are well lubricated with light oil or type "DEXRONTM" automatic transmission fluid.
- 2. Install differential carrier and side bearing assembly into the final drive housing.




Place all of the original side retainer adjusting shims onto the side bearing retainer that goes at the ring gear end of the carrier.



4. Install both bearing retainers onto the final drive housing and torque the retainer bolts.

Bolt torque specification:

9: 9 - 12 N·m (0.9 - 1.2 kg-m, 78 - 104 in-lb)



- Turn the carrier several times to seat the bearings.
- Measure the carrier turning torque with a spring gauge, J8129, at the ring gear retainer bolt.

Turning torque specification: 34.3 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb) of pulling force at the ring gear bolt


Side Bearing Preload (Cont'd)

- If the turning torque measured is incorrect, establish the correct bearing preload by adding to or subtracting from the total amount of shim thickness.
- Increase shim thickness to decrease turning torque on the
- Decrease shim thickness to increase turning torque on the carrier.



MA






Record the correct, selected total thickness of the side retainer adjusting shims, and remove the carrier and bearings from the final drive housing. Save all shims for later re-use.









SPD769

Pinion Gear Height and Pinion Bearing Preload



Make sure all parts are clean and that the bearings are well lubricated.



Assemble the pinion gear bearings into the pinion pre-load shim selector tool, J34309.

PD

Front Pinion Bearing — make sure the J34309-3 front pinion bearing seat is secured tightly against the J34309-2 gauge secure the bearing in its proper position.



anvil. Then turn the front pinion bearing pilot, J34309-7, to



BR

Rear Pinion Bearing — the rear pinion bearing pilot, J34309-8, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4, is used to lock the bearing to the assembly.










BT

HA






689 PD-25




Pinion Gear Height and Pinion Bearing Preload (Cont'd)


3. Place the pinion preload shim selector tool gauge screw, J34309-1, with the pinion rear bearing inner cone installed, into the final drive housing.



4. Install the J34309-2 gauge anvil with the front pinion bearing into the final drive housing and assemble it to the J34309-1 gauge screw. Make sure that the J34309-16 gauge plate will turn a full 360 degrees, and tighten the two sections by hand.



5. Turn the assembly several times to seat the bearings.



Measure the turning torque at the end of the J34309-2 shaft using Tool.


Tool number: ST3127S000 (J25765-A)
Turning torque specification:

0.6 - 1.0 N·m (6 - 10 kg-cm, 5.2 - 8.7 in-lb)

7. Place the J34309-10 "R180A" pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:


Make sure all machined surfaces are clean.



PINION BEARING PRELOAD WASHER SELECTION

 Place the solid pinion bearing adjusting spacer squarely into the recessed portion of the J34309-2 gauge anvil.

ADJUSTMENT



Pinion height

adapter

Pinion Gear Height and Pinion Bearing Preload (Cont'd)

Select the correct thickness of pinion bearing preload adjusting washer using a standard gauge of 6 mm (0.24 in) and J34309-101 feeler gauge. The exact total measure you get with the gauges is the thickness of the adjusting washer required. Select the correct washer.

Drive pinion bearing adjusting washer: Refer to SDS, PD-103.

10. Set the selected pinion bearing preload adjusting washer aside for use when assembling the pinion and bearings into the final drive housing.

PINION HEIGHT ADJUSTING WASHER SELECTION

11. Place the J34309-10 pinion height adapter onto the gauge plate and tighten by hand.

CAUTION:

SPD208A


SPD203A


Make sure all machined surfaces are clean.

12. Position firmly the side bearing discs, J25269-4, and arbor into the side bearing bores.

13. Select the correct standard pinion height adjusting washer thickness using a standard gauge of 3 mm (0.12 in) and J34309-101 feeler gauge. Measure the distance between the J34309-10 "R180A" pinion height adapter and the arbor.

14. Write down your exact total measurement.







MA

EC

FE

Mit

TF

PD

BR


ST

RS

BT

HA

!DX



Pinion Gear Height and Pinion Bearing Preload (Cont'd)


15. Correct the pinion height washer size by referring to the "pinion head number".

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set and should be the same as the number on the ring gear. The second number is the "pinion head height number", and it refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.

Pinion Head Height Number	Add or Remove from the Standard Pinion Height Washer Thickness Measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

16. Select the correct pinion height washer.

Drive pinion height adjusting washer: Refer to SDS, PD-103.



 Remove the J34309 pinion preload shim selector tool from the final drive housing and disassemble to retrieve the pinion bearings.

Tooth Contact


Gear tooth contact pattern check is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear sets which are not positioned properly may be noisy, or have short life, or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.



MA

LC



Thoroughly clean ring gear and drive pinion teeth.

Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.

EC

FE

CL

MT

Hold companion flange steady and rotate the ring gear in both directions.

TF

RA


BR

ST


RS

81

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.



To correct, reduce thickness of pinion height adjusting washer in order to make drive pinion go away from ring gear.




MA

EL

SPD007

When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent.



Extension Tube and Differential Side Shaft


Measure rear axle bearing end play.
 Rear axle bearing end play (A - B):

0.1 mm (0.0039 in) or less

The end play can be adjusted with bearing adjusting shim.


Available bearing adjusting shims:

Refer to SDS, PD-103.




2. Install grease seal.

Tool number: (J35764)



- 3. Install extension tube retainer, rear axle bearing and rear axle shaft bearing collar on differential side shaft.
- 4. Install differential side shaft assembly into extension tube.



Differential Case

 Measure clearance between side gear thrust washer and differential case.

Clearance between side gear thrust washer and differential case (A - B):


Less than 0.15 mm (0.0059 in)

The clearance can be adjusted with side gear thrust washer.

Available side gear thrust washers:

Refer to SDS, PD-103.

Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.



Tool (A)

Tool (B)

Differential Case (Cont'd)

3. Install differential case LH and RH.

G

MA

L¢

Place differential case on ring gear.

EC

Apply locking agent [Locktite (stud lock) or equivalent] to ring gear bolts, and install them.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head

CL

MT

Press-fit side bearing inner cones on differential case with



with a hammer.

(A) ST33230000 (J25805-01)

TF


B ST33061000 (J8107-2)

PD

FA

RA

Final Drive Housing



Tool numbers:

BR

A ST30611000 (J25742-1)

(B) ST30621000 (J25742-5) © ST30701000 (J25742-2)

ST

RS


BT

HA

EL


DX





SPD746


PD353



Final Drive Housing (Cont'd)


- 2. Select pinion bearing adjusting washer and drive pinion bearing spacer. Refer to "ADJUSTMENT", PD-25.
- Install drive pinion height adjusting washer in drive pinion, and press-fit pinion rear bearing inner cone in it, using press and Tool.

Tool number: ST30901000 (J26010-01)




- 4. Place pinion front bearing inner cone in final drive housing.
- Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.


Tool number: ST30720000 (J25405)



Place drive pinion bearing spacer, pinion bearing adjusting washer and drive pinion in final drive housing.



Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.



8. Tighten pinion nut to the specified torque.

The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number: ST38060002 (J34311)

MA

LC

EC

SE

CL

MT

AT

PD


FA

RA

BR

ST

RS



Final Drive Housing (Cont'd)

Turn drive pinion in both directions several revolutions and measure pinion bearing preload.

Tool number: ST3127S000 (J25765-A)

Pinion bearing preload:

1.1 - 1.7 N·m (11 - 17 kg-cm, 9.5 - 14.8 in-lb)

When pinion bearing preload is outside the specifications, replace pinion bearing adjusting washer and spacer with a different thickness.


Select side retainer adjusting shim. Refer to "ADJUSTMENT", PD-24.

11. Press-fit side bearing outer race into side retainer.

Tool numbers:

A ST30611000 (J25742-1)

B ST30621000 (J25742-5)




12. Install side oil seal to side retainer.

Tool number: ST33270000 (J25809)


13. Install differential case assembly.

14. Place side retainer adjusting shims (refer to "ADJUSTMENT", PD-24), and O-ring on side retainer, and install them in final drive housing.

Tool number: ST33720000 (J25817)



Align arrows stamped on side retainer and final drive housing.




15. Measure ring gear-to-drive pinion backlash with a dial indicator. Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)

If backlash is too small, decrease thickness of right shim and increase thickness of left shim by the same amount. If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.




PD-33





HA

697




Final Drive Housing (Cont'd)

16. Check total preload with Tool.

When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number: ST3127S000 (J25765-A)
Total preload:
1.2 - 2.3 N·m


(12 - 23 kg-cm, 10 - 20 in-lb)



- If preload is too great, add the same amount of shim to each side.
- If preload is too small, remove the same amount of shim from each side.

Never add or remove a different number of shims for each side as it will change ring gear-to-drive pinion backlash.

17. Recheck ring gear-to-drive pinion backlash because increase or decrease in thickness of shims will cause change of ring gear to pinion backlash.





18. Check runout of ring gear with a dial indicator.


Runout limit:

0.05 mm (0.0020 in)

- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
- If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.
- 19. Check tooth contact. Refer to "ADJUSTMENT", PD-29.
- 20. Install rear cover and gasket.











GI


SEC. 380











Pre-inspection

Before disassembling final drive, perform the following inspection.

- Total preload
- Turn drive pinion in both directions several revolutions to seat bearing rollers correctly.
- b. Check total preload with Tool.

Tool number: ST3127S000 (J25765-A) Total preload:

1.2 - 2.2 N·m

(12 - 22 kg-cm, 10 - 19 in-lb)

Ring gear-to-drive pinion backlash
 Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash: 0.13 - 0.18 mm (0.0051 - 0.0071 in)

Ring gear runout

Check runout of ring gear with a dial indicator.

Runout limit:

0.08 mm (0.0031 in)

- Tooth contact
 - Check tooth contact. Refer to "ADJUSTMENT", PD-51.
- Side gear-to-pinion mate gear backlash

Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:


Less than 0.15 mm (0.0059 in)

Differential Carrier

1. Mount differential carrier on Tools.

Tool numbers:

- ♠ ST0501S000 ()
- ® ST06310000 (J25602-01)



Differential Carrier (Cont'd)

2. Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.


Bearing caps are line-bored during manufacture and should be put back in their original places.



LC

EC Remove side bearing caps.







CL

Remove differential case assembly with a pry bar.



TF



FA

 $\mathbb{R}\mathbb{A}$

Keep the side bearing outer races together with their respective inner cones - do not mix them up.

BR


ST

RS

BT

HA

EL



SPD011


SPD213A

Tool


Remove drive pinion nut with Tool. Tool number: ST38060002 (J34311)

Remove companion flange with puller.


Differential Carrier (Cont'd)




- 7. Remove drive pinion with soft hammer.
- 8. Remove oil seal.



9. Remove pinion bearing outer races with a brass drift.



10. Pull out rear bearing inner cone with a press and Tool. Tool number: ST30031000 (J22912-01)




Differential Case

1. Remove side bearing inner cones.

To prevent damage to bearing, engage puller jaws in groove. Tool numbers:

- A ST33051001 (J22888-20)
- **B** ST33061000 (J8107-2)





Be careful not to confuse the left and right hand parts.

DISASSEMBLY

PD-39

H190A





SPD025

Differential Case (Cont'd)

Spread out lock straps and loosen ring gear bolts in a criss-cross fashion.

3. Tap ring gear off differential case with a soft hammer.

Tap evenly all around to keep ring gear from binding.

MA

EM

LC

 Drive out pinion mate shaft lock pin, with Tool from ring gear side.

들

ĒC

Lock pin is calked at pin hole mouth on differential case.

CL

MT

AT.

TF

PD

FA

RA

BR

ST

RS


BŢ

HA

ZL


Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping. If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).



Differential Case Assembly


Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, and thrust washers.



Bearing


1. Thoroughly clean bearing.

Check bearings for wear, scratches, pitting or flaking.
 Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



CAUTION:

Do not run engine when only one wheel (rear) is off the ground.



Preparation for Disassembly

CHECKING DIFFERENTIAL TORQUE

Measure differential torque with Tools.

If it is not within the specifications, inspect components of limited slip differential.

Differential torque:

New parts

69 - 118 N·m (7 - 12 kg-m, 51 - 87 ft-lb)

Used parts

39 - 74 N·m (4 - 7.5 kg-m, 29 - 54 ft-lb)

Tool number:

♠ KV38105110 (—)

® KV38105120 (—)

G[

MA

ĒM

LC

EC

FE

C.L

MT

AT

5212

PD

FA

RA

BR


ST

RS

BŢ


HA

PD-41 705



Disassembly


- Remove couple screws.
- Separate differential cases A and B. Draw out component parts (disc and plates etc.).



Inspection

CONTACT SURFACES

- Clean the disassembled parts in suitable solvent and blow dry with compressed air.
- If the following surfaces are found with burrs or scratches, smooth with oil stone.
 - 1 Differential case A
 - 2 Differential case B
 - Side gear
 - 4 Pinion mate gear
 - ⑤ Pinion mate shaft
 - 6 Thrust block
 - (7) Pressure ring



DISC AND PLATE

- Clean the discs and plates in suitable solvent and blow dry with compressed air.
- Inspect discs and plates for wear, nicks and burrs.
- Check friction discs or plates for warpage.

Maximum allowable warpage:

0.08 mm (0.0031 in)

If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.

Friction plate

Friction disc

Inspection (Cont'd)

4. Measure frictional surfaces and projected portions of friction discs, plates, spring disc and plate. If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

MΆ

Wear limit:

0.1 mm (0.004 in) or less

EM

LC

EC

FE

CL

MT

Assembly

Prior to assembling discs and plates, properly lubricate them with limited slip differential oil.

TF

AT

 Alternately position specified number of friction plates and friction discs on rear of side gear.

PD

FA

2. Install spring disc.

 $\mathbb{R}\mathbb{A}$

BR

ST


RS


BT

HA

EL


IDX






3. Install spring plate.


Assembly (Cont'd)




4. Install side gear thrust washer to differential case A.



5. Install differential case A over side gear, discs and plates assembly.




6. Install pinion mate gears, pinion shaft and thrust block to differential case A.



- 7. Install side gear to pinion mate gears.
- 8. Install pressure ring to side gear.
- 9. Install each disc and plate.


Use same procedures as outlined in steps 1. through 3.



10. Install side gear thrust washer to differential case B.

LIMITED SLIP DIFFERENTIAL

Assembly (Cont'd)



G1

Position differential cases B and A by correctly aligning marks stamped on cases.

MA

ĒM

LĈ

EC Tighten differential case couple screws.

FE

CL

MT

13. Check if there is a clearance between differential cases B and

TF

If there is a clearance, use a thinner side gear thrust washer on both sides.

Available side gear thrust washers: Refer to SDS, PD-104.

PD

FA

RA

BR 69 - 118 N·m (7 - 12 kg-m, 51 - 87 ft-lb)

Used parts 39 - 74 N·m (4 - 7.5 kg-m, 29 - 54 ft-lb)

Tool numbers:

14. Check differential torque: Differential torque: **New parts**

ST

(A) KV38105110 (**®** KV38105120 (

If greater than specification, use a thinner friction disc. If less than specification, use a thicker friction disc.

RS


Available friction discs: Refer to SDS, PD-104.


BT


HA


1DX

709










Feeler gauge




For quiet and reliable final drive operation, the following five adjustments must be made correctly:

- Side bearing preload
- 2. Pinion gear height
- 3. Pinion bearing preload. Refer to "ASSEMBLY", PD-55.
- 4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-55.
- 5. Ring and pinion gear tooth contact pattern

Side Bearing Preload

A selection of carrier side bearing preload shims is required for successful completion of this procedure.




- Make sure all parts are clean and that the bearings are well lubricated with light oil or type "DEXRONTM" automatic transmission fluid.
- 2. Remove side bearing inner cones.


To prevent damage to bearing, engage puller jaws in grooves.

Tool numbers:


- A ST33051001 (J22888-20)
- **B** ST33061000 (J8107-2)



 Reinstall all of the original side bearing adjusting shims on the carrier side, away from the ring gear.



 Reinstall the carrier side bearing using Tools J25805-01 and J8107-2. Press on the bearings.



SPD192A

SPD776

SPD196A

Pinion Gear Height

Side Bearing Preload (Cont'd)


Install carrier and bearings into the final drive housing. Install side bearing caps. Torque the bolts and tap on the caps with a soft hammer to seat the bearings.

Side bearing cap bolt torque specification: 49 - 59 N·m (5 - 6 kg-m, 36 - 43 ft-lb)



EM

LC




34.3 - 39.2 N (3.5 - 4.0 kg, 7.7 - 8.8 lb) of pulling force at the ring gear bolt



EC

CL









FA

RA

BR

Make sure all parts are clean and that the bearings are well lubricated.



Assemble the pinion gear bearings into the pinion pre-load shim selector Tool, J34309.






BT

HA


EL





Front Pinion Bearing — make sure the J34309-3 front pinion bearing is secured tightly against the J34309 gauge anvil. Then turn the front pinion bearing pilot J34309-5 to secure the bearing in its proper position.


Rear Pinion Bearing — the rear pinion bearing pilot, J34309-15, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4 is used to lock the bearing to the assembly.




SPD216A

Pinion Gear Height (Cont'd)


 Place the pinion pre-load shim selector Tool J34309-1 gauge screw assembly with the pinion rear bearing inner cone installed into the final drive housing.



4. Assemble the front pinion bearing inner cone and the J34309-2 gauge anvil together with the J34309-1 gauge screw in the final drive housing. Make sure that the pinion height gauge plate, J34309-16, will turn a full 360 degrees, and tighten the two sections together by hand.




5. Turn the assembly several times to seat the bearings.



Measure the turning torque at the end of the J34309-2 gauge anvil using Tool.


Tool number: ST3127S000 (J25765-A)
Turning torque specification:
1.0 - 1.3 N·m
(10 - 13 kg-cm, 8.7 - 11.3 in-lb)



Place the J34309-14 pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:

Make sure all machined surfaces are clean.




Pinion Gear Height (Cont'd) PINION HEIGHT ADJUSTING WASHER SELECTION

Now, position the side bearing discs, J25269-18, and arbor firmly into the side bearing bores.

MA

EM

[LC



SPD219A


SPD778

EC

FE

CL.

MT



10. Select the correct standard pinion height adjusting washer thickness by using J34309-101 feeler gauge. Measure the gap between the J34309-14 pinion height adapter and the arbor.

11. Write down your exact total measurement.

TF

PD

FA

RA

BR


ST

RS

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set and

HA

1DX



12. Correct the pinion height washer size by referring to the "pinion head number".

should be the same as the number on the ring gear. The second number is the "pinion head height number," and it refers to the ideal pinion height from standard for quietest operation.

ADJUSTMENT

Pinion Gear Height (Cont'd)


Use the following chart to determine the correct pinion height washer.

Pinion Head Height Number	Add or Remove from the Standard Pinion Height Washer Thickness Measurement
	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

13. Select the correct pinion height washer.

Drive pinion height adjusting washer:

Refer to SDS, PD-104.



14. Remove the J34309 pinion preload shim selector Tool from the final drive housing and disassemble to retrieve the pinion bearings.

Tooth Contact


Checking of gear tooth contact pattern is necessary to verify correct relationship between ring gear and drive pinion. Hypoid gear sets which are not positioned properly may be noisy, or have short life, or both. With a pattern check, the most desirable

GI

MA

EM

LC



1. Thoroughly clean ring gear and drive pinion teeth.

contact for low noise level and long life can be assured.

Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.

FE

EG

915

MT

Hold companion flange steady and rotate the ring gear in both directions.

TF

PN

ĒA.

BR


ST

RS

BT


FIA

IDX




Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up. Face contact Flank contact Toe contact Heel contact To correct, increase thickness of pinion To correct, reduce thickness of pinion height adjusting washer in order to bring height adjusting washer in order to make drive pinion close to ring gear. drive pinion go away from ring gear. Correct tooth contact When adjustment is completed, be sure to wipe off completely the ferric oxide and oil or their equivalent. SPD007

PD-51



Differential Case


1. Install side gears, pinion mate gears and thrust washers into differential case.



- 2. Fit pinion mate shaft to differential case so that it meets lock pin holes.
- 3. Adjust backlash between side gear and pinion mate gear by selecting side gear thrust washer. Refer to SDS, PD-104.


Backlash between side gear and pinion mate gear (Clearance between side gear thrust washer and differential case):

Less than 0.15 mm (0.0059 in)




4. Install pinion mate shaft lock pin with a punch.


Make sure lock pin is flush with case.





5. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




Apply locking agent [Locktite (stud lock) or equivalent] to contacting surfaces of ring gear and differential case, then place differential case on ring gear.









Differential Case (Cont'd)

Apply a small amount of locking agent (described on previous page) to ring gear bolts.

Install new lock straps and ring gear bolts.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

Then bend up lock straps to lock the bolts in place.

Select side bearing adjusting shims. Refer to "ADJUSTMENT", PD-46.

10. Install the shims behind each bearing and press on side bearing inner cones with Tools.

Tool numbers:

(A) ST33230000 (J25805-01)

B ST33061000 (J8107-2)

Differential Carrier

Press-fit front and rear bearing outer races with Tools.

Tool numbers:

A ST30611000 (J25742-1)

(B) ST30621000 (J25742-5)

© ST30613000 (J25742-3)

Select pinion height adjusting washer. Refer "ADJUSTMENT", PD-47.

Install pinion height adjusting washer in drive pinion, and press-fit rear bearing inner cone with press and Tool.

Tool number: ST30901000 (J26010-01)

HA

il

717 PD-53

EC

MA

LC

FE

CL.

MT

AT

TF

FA


RA

BR


ST

RS

Differential Carrier (Cont'd)




4. Place pinion front bearing inner cone in gear carrier.




5. Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.

Tool numbers:


- (A) ST30720000 (J25405)
- ® KV38102510 ()



Install drive pinion washer, collapsible spacer and drive pinion in gear carrier.




Install companion flange and hold it firmly.
 Insert pinion into companion flange by tapping its head with a soft hammer.





8. Temporarily tighten pinion nut until there is no axial play.


The threaded portion of drive pinion and pinion nut should be free from oil or grease.


Tool number: ST38060002 (J34311)











Differential Carrier (Cont'd)

Tighten pinion nut by degrees to the specified preload while checking the preload with Tools.

When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.

Pinion bearing preload:

1.1 - 1.6 N·m (11 - 16 kg-cm, 9.5 - 13.9 in-lb)

Tool number: ST3127S000 (J25765-A)

CAUTION:

The preload is achieved by the permanent setting of the collapsible spacer. So, if an overpreload results from turning of the pinion nut excessively, the spacer should be replaced by new one.

10. Install differential case assembly with side bearing outer races into gear carrier.

11. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.

12. Measure ring gear-to-drive pinion backlash with a dial indica-

Ring gear-to-drive pinion backlash: 0.13 - 0.18 mm (0.0051 - 0.0071 in)

If backlash is too small, decrease thickness of left shim and increase thickness of right shim by the same amount.

If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the bearing preload.

Check total preload with Tool.

When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number: ST3127S000 (J25765-A) Total preload:

1.2 - 2.2 N·m (12 - 22 kg-cm, 10 - 19 in-lb)

MA

EM

ĒC

FE

C[

Mit

TF

PD

FA

BR

ST

RS


BT


HA

EL

IDX

ASSEMBLY





Differential Carrier (Cont'd)


- If preload is too great, remove the same amount of shims from each side.
- If preload is too small, add the same amount of shims to each side.

Never add or remove a different number of shims for each side as it will change ring gear-to-drive pinion backlash.

- 14. Recheck ring gear-to-drive pinion backlash because an increase or decrease in thickness of shims will cause change of ring gear-to-pinion backlash.
- 15. Check runout of ring gear with a dial indicator.

Runout limit: 0.08 mm (0.0031 in)

- If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.
- If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.
- Check tooth contact. Refer to "ADJUSTMENT", PD-51.



G!


MA


PD


IDX


SPD784-A


SEC. 380











Pre-inspection

Before disassembling final drive, perform the following inspection.

- Total preload
- Turn drive pinion in both directions several times to set bearing rollers.
- b. Check total preload with Tool.

Tool number: ST3127S000 (J25765-A)

Total preload:

1.2 - 2.3 N·m

(12 - 23 kg-cm, 10 - 20 in-lb)

• Ring gear-to-drive pinion backlash.

Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:

0.13 - 0.18 mm (0.0051 - 0.0071 in)

Ring gear runout

Check runout of ring gear with a dial indicator.

Runout limit: 0.05 mm (0.0020 in)

Tooth contact

Check tooth contact. Refer to "ADJUSTMENT", PD-74.

Side gear-to-pinion mate gear backlash

Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:

Less than 0.15 mm (0.0059 in)

Differential Carrier

Remove rear cover and rear cover gasket.

Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.

Bearing caps are line-bored during manufacture and should be put back in their original places.

SPD202

SPD193

Differential Carrier (Cont'd)

3. Remove side bearing caps.



MA

LC

Remove differential case assembly with pry bar.




FE

Cl

MT





Keep the side bearing outer races together with their respective inner cones — do not mix them up.



PD

FA

RA

BR

ST


RS


BT

HA

EL

IDX






Remove pinion nut with Tool. Tool number: ST38060002 (J34311)


6. Remove companion flange with puller.

PD-59




Differential Carrier (Cont'd)

- 7. Remove drive pinion with soft hammer.
- 8. Remove front oil seal and pinion front bearing inner cone.




9. Remove pinion bearing outer races with a brass drift.



10. Remove pinion rear bearing inner cone and pinion height adjusting washer.

Tool number: ST30031000 (J22912-01)



Differential Case

1. Remove side bearing inner cones.

To prevent damage to bearing, engage puller jaws in grooves.

Tool numbers:

- A ST33051001 (J22888-20)
- ® ST33061000 (J8107-2)

SPD022

Differential Case (Cont'd)

Be careful not to confuse the right and left hand parts.



MA

LC

EC

Loosen ring gear bolts in a criss-cross fashion. Tap ring gear off the differential case with a soft hammer.

Tap evenly all around to keep ring gear from binding.

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST


RS

BT


HA

EL

725




4. Punch off pinion mate shaft lock pin from ring gear side. Lock pin is calked at pin hole mouth on differential case.




Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping. If any damaged part is evident, replace ring gear and drive pinion as a set (hypoid gear set).




Differential Case Assembly

Check mating surfaces of differential case, side gears, pinion mate gears, pinion mate shaft, thrust block and thrust washers.





Bearing

- 1. Thoroughly clean bearing.
- 2. Check bearings for wear, scratches, pitting or flaking. Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.



ground.





Preparation for Disassembly	jīú.
CHECKING DIFFERENTIAL TORQUE	En:
Measure differential torque with Tools.	
If it is not within the specifications, inspect components of limited	
slip differential.	S
Differential torque:	9
88 - 108 N⋅m	
(9.0 - 11.0 kg-m, 65 - 80 ft-lb)	R
Tool numbers:	ינרון
® KV38105120 (←)	(m)

Do not run engine when only one wheel (rear) is off the

Spread out lock straps. Remove couple bolts using a press. Tool number: \$T33081000 (

Separate differential cases A and B. Draw out component parts (discs and plates, etc.).

Put marks on gears and pressure rings so that they can be reinstalled in their original positions.

PD

FA

RA

BT


HA

EL

NOX

Disassembly

1.



Inspection


CONTACT SURFACES

- Clean the disassembled parts in suitable solvent and blow dry with compressed air.
- If the following sufaces are found with burrs or scratches, smooth with oil stone.
 - 1 Differential case B
 - ② Differential case A

 - Side gearPinion mate gear
 - ⑤ Pinion mate shaft
 - (6) Thrust block
 - 7 Friction plate guide

DISC AND PLATE

- Clean the discs and plates in suitable solvent and blow dry with compressed air.
- 2. Inspect discs and plates for wear, nicks and burrs.



3. Check friction discs or plates for warpage.

Maximum allowable warpage: 0.08 mm (0.0031 in)

If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.

Measuring points Projected portion Frictional surface

A - B = Wear limit mm (in) SPD403



4. Measure frictional surfaces and projected portions of friction discs, plates and spring plate. If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:

0.1 mm (0.004 in) or less



MA

LC

EC

FE

CL

MT

AT




SPD761

FRICTION DISC AND FRICTION PLATE END PLAY

End play of friction disc and friction plate can be calculated by using the following equation and should be adjusted within the following range.

Adjustment can be made by selecting friction disc having two different thicknesses.



$$\mathsf{E} = \mathsf{A} - (\mathsf{B} + \mathsf{C})$$

A: Length of differential case contact surface to differential case inner bottom.

B: Total thickness of friction discs, friction plates and spring plate in differential case on one side.

C: Length of differential case contact surface to back side of side gear.



RA

FA

8R

SK

ST

RS

BT


Measure values of "A".

Standard length A:


49.50 - 49.55 mm (1.9488 - 1.9508 in)

HA

EL



PD-65 729



Adjustment (Cont'd)

2. Measure thickness of each disc and plate.

Total thickness "B":


19.24 - 20.26 mm (0.7575 - 0.7976 in)

No. of discs and plates (One side):

Friction disc 6

Friction plate 6

Spring plate 1




3. Measure values of "C".

a. Attach a dial indicator to the base plate.

b. Place differential case B on the base plate, and install a master gauge on case B.

Then adjust the dial indicator scale to zero with its tip on the master gauge.



c. Install pinion mate gears, side gears and pinion mate shaft in differential case B.

d. Set dial indicator's tip on the side gear, and read the indication.

Example:

$$E = A - D$$

$$= A - (B + C)$$

= 0.05 to 0.15 mm

A = 49.52 mm

B = 19.45 mm

C = 29.7 mm

D = B + C


B ... 19.45


+ C ... 29.7 49.15


$$E = A - D$$


From the above equation, end play of 0.37 mm exceeds the specified range of 0.05 to 0.15 mm.


Select suitable discs and plates to adjust correctly.











Assembly

Prior to assembling discs and plates, properly lubricate them by dipping them in limited slip differential oil.

Alternately position specified number of friction plates and friction discs on rear of side gear.

Always position a friction plate first on rear of side gear.

Install spring plate.

3. Install friction plate guides.

Correctly align the raised portions of friction plates, and apply grease to inner surfaces of friction plate guides to prevent them from falling.

Install differential case B over side gear, discs, plates and friction plate guide assembly.

Install differential case B while supporting friction plate guides with your middle finger by inserting through oil hole in differential case.

Be careful not to detach spring plate from the hexagonal part of the side gear.

Install pinion mate gears and pinion shaft to differential

case B.

MA

EM

LC

EC

FE

CL.

MT

AT

PD

FA

BR


RS

HA


EL

IDX

Assembly (Cont'd)




6. Install thrust block.



7. Install side gear to pinion mate gears.


8. Install each disc and plate.

Use same procedures as outlined in steps 1. through 3.



9. Install differential case A.

Position differential cases A and B by correctly aligning marks stamped on cases.



- 10. Tighten differential case bolts.
- 11. Place ring gear on differential case and install new lock straps and bolts.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

Then bend up lock straps to lock the bolts in place.

- 12. Install side bearing inner cone.
- 13. Check differential torque.


For quiet and reliable final drive operation, the following five adjustments must be made correctly.

- Side bearing preload
- Pinion gear height 2.
- Pinion bearing preload. Refer to "ASSEMBLY", PD-77.
- Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-78.

Side Bearing Preload

A selection of carrier side bearing preload shims is required for successful completion of this procedure.

CL



Place the differential carrier, with side bearings and bearing races installed, into the final drive housing.

PD

3. Put the side bearing spacer in place.

CAUTION:

PD-69


Side bearing spacer is placed on either the right or left depending upon final drive gear ratio. Be sure to replace it on the correct side.


ST


Use Tool to place original carrier side bearing preload shims on

Tool number: KV38100600 (J25267)

the carrier end, opposite the ring gear.









MA



Ring and pinion gear tooth contact pattern

[LC

EC

FE

MIT

RA


BR

RS

HA

EL

733



Side Bearing Preload (Cont'd)


5. Install the side bearing caps in their correct locations and torque the bearing cap retaining bolts.

Specification:

88 - 98 N·m

(9.0 - 10.0 kg-m, 65 - 72 ft-lb)

Turn the carrier several times to seat the bearings.




7. Measure the turning torque of the carrier at the ring gear retaining bolts with a spring gauge, J8129.

Specification:


34.3 - 39.2 N

(3.5 - 4.0 kg, 7.7 - 8.8 lb)


of pulling force at the ring gear bolt



- 8. If the turning torque is not within the specifications, correct the torque as follows:
- If the turning torque is less than the specified range, install washers of greater thickness.
- If the turning torque is greater than the specification, install thinner washers.
- See the SDS section for washer dimensions and part numbers.
- 9. Record the total amount of washer thickness required for the correct carrier side bearing preload.




 Remove the carrier from the final drive housing. Save the selected preload washers for later use during the assembly of the final drive unit.



Pinion Gear Height

- Make sure all parts are clean and that the bearings are well lubricated.
- 2. Assemble the pinion gear bearings into the pinion preload shim selector Tool, J34309.

Pinion Gear Height (Cont'd)




Front pinion bearing — make sure the J34309-3 front pinion bearing seat is secured tightly against the J34309-2 gauge anvil. Then turn the front pinion bearing pilot, J34309-5, to secure the bearing in its proper position.



Rear pinion bearing — the rear pinion bearing pilot, J34309-8, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4, is used to lock the bearing to the assembly.



LC




Install the pinion rear bearing inner cone into the final drive housing. Then place the pinion preload shim selector Tool, J34309-1, gauge screw assembly.



CL

MT

AT



Assemble the front pinion bearing inner cone and the J34309-2 gauge anvil. Assemble them together with the J34309-1 gauge screw in the final drive housing. Make sure that the pinion height gauge plate, J34309-16, will turn a full 360 degrees. Tighten the two sections together by hand.

Turn the assembly several times to seat the bearings.



PD





BR




ST

RS










Turning torque specification:






SPD770

1.0 - 1.3 N·m (10 - 13 kg-cm, 8.7 - 11.3 in-lb)






Pinion Gear Height (Cont'd)

7. Place the J34309-11 pinion height adapter onto the gauge plate and tighten it by hand.


CAUTION:

Make sure all machined surfaces are clean.




PINION HEIGHT ADJUSTING WASHER SELECTION


 Now, position the side bearing discs, J25269-4, and arbor firmly into the side bearing bores.
 Install the side bearing caps and tighten the cap bolts to proper torque.



 Select the correct standard pinion height adjusting washer thickness. Select by using a standard gauge of 3 mm (0.12 in) and J34309-101 feeler gauge. Measure the distance between the J34309-11 pinion height adapter including the standard gauge and the arbor.



10. Write down your exact measurement (the value of feeler gauge).



Pinion Gear Height (Cont'd)

11. Correct the pinion height washer size by referring to the "pinion head number".

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set. This number should be the same as the number on the ring gear. The second number is the "pinion head height number". It refers to the ideal pinion height from standard for quietest operation. Use the following chart to determine the correct pinion height washer.

MA

EM

LC

Use the following chart to determine the correct pinion height washer:

Pinion head height number	Add or remove from the standard pinion height washer thickness measurement
-6	Add 0.06 mm (0.0024 in)
-5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
-1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

FE

Œ[

MT

AT

PD

FA

 $\mathbb{R}\mathbb{A}$

12. Select the correct pinion height washer.

Drive pinion height adjusting washer: Refer to SDS, PD-105.



ST


RS

BT

HA

EL

]D)X




13. Remove the J34309 pinion preload shim selector Tool from the final drive housing. Then disassemble to retrieve the pinion bearings.

> 737 PD-73


Tooth Contact

Checking gear tooth contact pattern is necessary to verify correct relationship between ring gear and drive pinion.


Hypoid gear set which is not positioned properly may be noisy, or have short life or both. With the checking or gear tooth contact pattern, the most desirable contact for low noise level and long life can be assured.




- 1. Thoroughly clean ring gear and drive pinion teeth.
- Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.



Hold companion flange steady and rotate the ring gear in both directions.





Differential Case

Measure clearance between side gear thrust washer and differential case.

> Clearance between side gear thrust washer and differential case (A - B):

Less than 0.15 mm (0.0059 in)

The clearance can be adjusted with side gear thrust washer. Refer to SDS, PD-105.

Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.

EC

G

MA

EM

FE

CL

Mii

Install differential case LH and RH.

AT

TF

FA

RA

BR

Place differential case on ring gear.

Apply locking agent [Locktite (stud lock) or equivalent] to ring gear bolts, and install them.

ST

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

RS

Press-fit side bearing inner cones on differential case with Tool. Tool numbers:


(A) ST33230000 (J25805-01)

B ST33061000 (J8107-2)

HA

BT


IDX



SPD643

SPD746

739 PD-75




Differential Carrier

1. Press-fit front and rear bearing outer races with Tools.


Tool numbers:

- A ST30611000 (J25742-1)
- (B) ST30621000 (J25742-5)
- © ST30613000 (J25742-3)




- Select pinion height adjusting washer. Refer to "ADJUSTMENT", PD-70.
- 3. Install pinion height adjusting washer in drive pinion, and press-fit rear bearing inner cone in it, with press and Tool.

Tool number: ST30901000 (J26010-01)




4. Place pinion front bearing inner cone in gear carrier.



Apply multi-purpose grease to cavity at sealing lips of oil seal.
 Install front oil seal.

Tool number: KV38100500 (J25273)



Soft hammer

SPD708

SPD204

Differential Carrier (Cont'd)

6. Place drive pinion bearing spacer, drive pinion bearing adjusting washer and drive pinion in gear carrier.

MA

EM

LC

 Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.

FE

CL.

MT

ח מער

8. Tighten pinion nut to 127 N·m (13 kg-m, 94 ft-lb).

AT

The threaded portion of drive pinion and pinion nut should be free from oil or grease.


Tool number: ST38060002 (J34311)

TF

.

PD

FA



BR

RA

Tool number: ST3127S000 (J25765-A) Pinion bearing preload:

1.1 - 1.7 N·m

(11 - 17 kg-cm, 9.5 - 14.8 in-lb)

ST

This procedure will have to be repeated if:

Maximum preload is achieved before the minimum pinion

nut torque is reached.

Minimum preload is not achieved before maximum pinion

...

 Minimum preload is not achieved before maximum pinion nut torque is reached.


BT

 Select side bearing adjusting washer. Refer to Adjustment.

HA

11. Install differential case assembly with side bearing outer races into gear carrier.


EL




∠ Tool

PD-77


Differential Carrier (Cont'd)




12. Insert left and right side bearing adjusting washers in place between side bearing and carrier.



13. Drive in side bearing spacer with Tool. Tool number: KV38100600 (J25267)



14. Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.




15. Measure ring gear-to-drive pinion backlash with a dial indicator. Ring gear-to-drive pinion backlash:

> 0.13 - 0.18 mm (0.0051 - 0.0071 in)

If backlash is too small, decrease thickness of right shim and increase thickness of left shim by the same amount. If backlash is too great, reverse the above procedure.

Never change the total amount of shims as it will change the

bearing preload.



16. Check total preload with Tool.

When checking preload, turn drive pinion in both directions several times to seat bearing rollers correctly.


Total preload:


1.2 - 2.3 N·m

(12 - 23 kg-cm, 10 - 20 in-lb)

Tool number: ST3127S000 (J25765-A)

ASSEMBLY





Differential Carrier (Cont'd)

 If preload is too great, remove the same amount of shim from each side.

• If preload is too small, add the same amount of shim to each side.

Never add or remove a different number of shims for each side as it will change ring gear-to-drive pinion backlash.

17. Recheck ring gear-to-drive pinion backlash because increase or decrease in thickness of shims will cause change of ring gear-to-pinion backlash.

18. Check runout of ring gear with a dial indicator.

Runout limit:

0.05 mm (0.0020 in)

 If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.

 If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.

Check tooth contact.
 Refer to "ADJUSTMENT", PD-74.

20. Install rear cover and gasket.



MA

LC

EC

FE

©L

MT

AT

TF

PD

FA

RA

BR

ST


RS

BT


HA


EL


IDX





DISASSEMBLY











Pre-inspection

Before disassembling final drive, perform the following inspection.

- Total preload
- Turn drive pinion in both directions several times to seat bearing rollers correctly.
- Check total preload with Tool.

Total preload:

1.7 - 2.5 N·m

(17 - 25 kg-cm, 15 - 22 in-lb)

Tool number: ST3127S000 (J25765-A)

Ring gear-to-drive pinion backlash Check backlash of ring gear with a dial indicator at several points.

Ring gear-to-drive pinion backlash:

0.15 - 0.20 mm (0.0059 - 0.0079 in)

Ring gear runout

Check runout of ring gear with a dial indicator.

Runout limit:

0.08 mm (0.0031 in)

Tooth contact

Check tooth contact, referring to "ADJUSTMENT", PD-95.

Side gear-to-pinion mate gear backlash

Measure clearance between side gear thrust washer and differential case with a feeler gauge.

Clearance between side gear thrust washer and differential case:

Less than 0.15 mm (0.0059 in)

Differential Carrier

1. Mount final drive assembly on Tool.

Tool numbers: (A) ST0501S000 (

(B) ST06340000 (J24310)

MA

G

LC

EC

FE

CL.

MT

AT

75

PD

FA

RA

RE

ST


RS

BT

HA

ÊL


IDX




Differential Carrier (Cont'd)

Put match marks on one side of side bearing cap with paint or punch to ensure that it is replaced in proper position during reassembly.


Bearing caps are line-bored during manufacture and should be put back in their original places.




3. Remove side lock fingers and side bearing caps.



 Remove side bearing adjuster with Tool. Tool number: ST32580000 (J34312)



5. Remove differential case assembly with a pry bar.



Keep the side bearing outer races together with their respective inner cones — do not mix them up.

DISASSEMBLY

Differential Carrier (Cont'd)

Remove drive pinion nut with Tool. Tool number: KV38104700 (J34311)

- Remove companion flange with puller.
- Remove ABS sensor.




G

MA

EM

LC







MT

AT

10. Remove front oil seal and pinion front bearing inner cone.

11. Remove pinion bearing outer races with a brass drift.

TF

PD

FA

12. Remove pinion rear bearing inner cone and drive pinion adjusting washer. Tool number: ST30031000 (J22912-01)

ST

BR

RS

BT

KA


1. Remove side bearing inner cones. To prevent damage to bearing, engage puller jaws in groove.


> Tool numbers: A ST33051001 (J22888-20)


® ST33061000 (J8107-2)


Differential Case


DX














Differential Case (Cont'd)




Be careful not to confuse the left and right hand parts.



2. Spread out lock straps and loosen ring gear bolts in a criss-cross fashion.



3. Tap ring gear off differential case with a soft hammer. Tap evenly all around to keep ring gear from binding.



4. Separate differential case LH and RH.

Put match marks on both differential case LH and RH sides prior to separating them.

Ring Gear and Drive Pinion

Check gear teeth for scoring, cracking or chipping. If any damaged part is evident, replace ring gear and drive pinion **G**I

MA

LC

EC

Check mating surfaces of differential case, side gears, pinion mate

FE



MT

AT

TF





RA



 \mathbb{BR}

ST

RS

BŢ

HA


訌


IDX

749



as a set (hypoid gear set).






Differential Case Assembly


gears, pinion mate shaft, and thrust washers.

Bearing

Thoroughly clean bearing.

Check bearings for wear, scratches, pitting or flaking. Check tapered roller bearing for smooth rotation. If damaged, replace outer race and inner cone as a set.





CAUTION:

Do not run engine when only one wheel (rear) is off the ground.

Preparation for Disassembly


CHECKING DIFFERENTIAL TORQUE

Measure differential torque with Tools.

If it is not within the specifications, inspect components of limited slip differential.

Differential torque:
201 - 240 N·m
(20.5 - 24.5 kg-m, 148 - 177 ft-lb)
Tool numbers:


(A) KV38105210 (—)
(B) KV38105220 (—)




Disassembly

- 1. Remove side bearing inner cone with Tool.
- 2. Remove ring gear by spreading out lock straps.
- 3. Loosen ring gear bolts in a criss-cross fashion.
- 4. Tap ring gear off gear case with a soft hammer.

Tap evenly all around to keep ring gear from binding.





Disassembly (Cont'd)

5. Remove differential case by spreading out lock straps.

6. Remove couple bolts on differential cases A and B with a press.

Tool number: ST33081000 (—

7. Separate differential cases A and B. Draw out component parts (discs and plates, etc.).

Put marks on gears and pressure rings so that they can be reinstalled in their original positions.

MA

EM

LC

EC

Inspection

CONTACT SURFACES

 Clean the disassembled parts in suitable solvent and blow dry with compressed air.

If the following surfaces are found with burrs or scratches, smooth with oil stone.

1 Differential case B

② Differential case A

3 Side gear

(4) Pinion mate gear

(5) Pinion mate shaft

(6) Thrust block

Friction plate guide

MT

CL

AT

TF

PD

FA

RA

DISC AND PLATE

 Clean the discs and plates in suitable solvent and blow dry with compressed air.

2. Inspect discs and plates for wear, nicks and burrs.

BR ST

RS

BT

Check friction discs or plates for warpage.

Allowable warpage:


0.08 mm (0.0031 in)

If it exceeds limits, replace with a new plate to eliminate possibility of clutch slippage or sticking.

HA








Inspection (Cont'd)

4. Measure frictional surfaces and projected portions of friction discs, plates, spring disc and plate.

If any part has worn beyond the wear limit, replace it with a new one that is the same thickness as the projected portion.

Wear limit:

0.1 mm (0.004 in) or less



Adjustment

FRICTION DISC AND FRICTION PLATE END PLAY

End play of friction disc and friction plate can be calculated by using the following equation and should be adjusted within the following range.


Adjustment can be made by selecting friction disc having two different thicknesses.

End play E:

0.05 - 0.15 mm (0.0020 - 0.0059 in)

E = A - (B + C)


- A: Length of differential case contact surface to differential case inner bottom.
- B: Total thickness of friction discs, friction plates, spring disc and spring plate in differential case on one side.
- C: Length of differential case contact surface to back side of side gear.



1. Measure values of "A".

Standard length A:

49.50 - 49.55 mm (1.9488 - 1.9508 in)



Suitable block


Suitable block [master gauge 30 mm

(1.18 in)]

[master gauge 30 mm

(1.18 in)]

Adjustment (Cont'd)



Total thickness "B":

19.24 - 20.26 mm (0.7575 - 0.7976 in)

No. of discs and plates (One side):

Friction disc 5

Friction plate 6

Spring disc 1

Spring plate 1




LC

EC

FE

MA

GI




Attach a dial indicator to the base plate.

Place differential case B on the base plate, and install a master gauge on case B.

Then adjust the dial indicator scale to zero with its tip on the




MIT



SPD418

SPD419



Set dial indicator's tip on the side gear, and read the indication. Example:



A = 49.52 mm

B = 19.45 mm

C = 29.7 mm

From the above equation, end play of 0.37 mm exceeds the specified range of 0.05 to 0.15 mm.

Select suitable discs and plates to adjust correctly.



TF

RA

BR


ST

RS

BT

HA





Assembly


Prior to assembling discs and plates, properly lubricate them by dipping them in limited slip differential oil.

Alternately position specified number of friction plates and friction discs on rear of side gear.

Always position a friction plate first on rear of side gear.

EL


IDX




Assembly (Cont'd)

2. Install spring disc.

Align the twelve angular holes in spring disc with the hexagonal area of the side gear.




3. Install spring plate.




4. Install friction plate guides.

Correctly align the raised portions of friction plates, and apply grease to inner surfaces of friction plate guides to prevent them from falling.




- 5. Install differential case B over side gear, discs, plates and friction plate guide assembly.
- Install differential case B while supporting friction plate guides with your middle finger by inserting through oil hole in differential case.
- Be careful not to detach spring disc from the hexagonal part of the side gear.



Install pinion mate gears and pinion shaft to differential case B.

Assembly (Cont'd)



SPD429

SPD430

Match mark

7. Install thrust block.

@]

MA

LC

Install side gear to pinion mate gears.

EC

Install each disc and plate.

stamped on cases.

and bolts.

11. Tighten differential case bolts.

FE

Cl

MT

AT.

10. Install differential case A. Position differential cases A and B by correctly aligning marks

Use same procedures as outlined in steps 1. through 4.

TF

PD

FA

RA

12. Place ring gear on differential case and install new lock straps

BR

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.

ST


Then bend up lock straps to lock the bolts in place.

RS

BT


HA

IDX




For quiet and reliable final drive operation, the following five adjustments must be made correctly:

- 1. Side bearing preload
- 2. Pinion gear height
- 3. Pinion bearing preload. Refer to "ASSEMBLY", PD-98.
- 4. Ring gear-to-pinion backlash. Refer to "ASSEMBLY", PD-99.
- 5. Ring and pinion gear tooth contact pattern




Pinion Gear Height


- Make sure all parts are clean and that the bearings are well lubricated.
- 2. Assemble the pinion gear bearings into the pinion pre-load shim selector Tool, J34309.



- Rear Pinion Bearing the rear pinion bearing pilot, J34309-8, is used to center the rear pinion bearing only. The rear pinion bearing locking seat, J34309-4, is used to lock the bearing to the assembly.
- Front Pinion Bearing make sure the J34309-3, front pinion bearing seat is secured tightly against the J34309-2 gauge anvil. Then turn the front pinion bearing pilot, J34309-5, to secure the bearing in its proper position.




Place the pinion preload shim selector Tool gauge screw assembly, J34309-1, with the pinion rear bearing inner cone installed, into the final drive housing.



- 4. Install the J34309-2 gauge anvil with the front pinion bearing into the final drive housing and assemble it to the J34309-1 gauge screw. Make sure that the J34309-16 gauge plate will turn a full 360 degrees, and tighten the two sections by hand to set bearing pre-load.
- Turn the assembly several times to seat the bearings.

ADJUSTMENT



Pinion Gear Height (Cont'd)

Measure the turning torque at the end of the J34309-2 gauge anvil using Tool.

Tool number: ST3127S000 (J25765-A) Turning torque specification:

0.4 - 0.9 N·m (4 - 9 kg-cm, 3.5 - 7.8 in-lb)

 $\mathbb{M}\mathbb{A}$

LC

7. Place the J34309-12 "H233B" pinion height adapter onto the gauge plate and tighten it by hand.

CAUTION:

Make sure all machined surfaces are clean.

FE

CL

MT

PINION HEIGHT ADJUSTING WASHER SELECTION

Position the J25269-18 side bearing discs and the arbor into

TF

PD

RA

9. Install the bearing caps and torque the bolts.

Specification:

the side bearing bores.

(9.5 - 10.5 kg-m, 69 - 76 ft-lb)

ST

BR

RS

BŢ


10. Select the correct standard pinion height adjusting washer thickness using a standard gauge of 2.5, 3.0, or 3.5 mm (0.098, 0.118, or 0.138 in) and J34309-101 feeler gauge. Measure the distance between the J34309-12 "H233B" pinion height adapter and the arbor.

堲

HA

[D)X









SPD208A

SPD286A




AT






Pinion Gear Height (Cont'd)

11. Write down your exact total measurement.






12. Correct the pinion height washer size by referring to the "pinion head height number".

There are two numbers painted on the pinion gear. The first one refers to the pinion and ring gear as a matched set and should be the same as the number on the ring gear. The second number is the "pinion head height number," and it refers to the ideal pinion height from standard for the quietest operation. Use the following chart to determine the correct pinion height washer.

Pinion Head Height Number	Add or Remove from the Selected Standard Pinion Height Washer Thickness Measurement
_6	Add 0.06 mm (0.0024 in)
- 5	Add 0.05 mm (0.0020 in)
-4	Add 0.04 mm (0.0016 in)
-3	Add 0.03 mm (0.0012 in)
-2	Add 0.02 mm (0.0008 in)
_1	Add 0.01 mm (0.0004 in)
0	Use the selected washer thickness
+1	Subtract 0.01 mm (0.0004 in)
+2	Subtract 0.02 mm (0.0008 in)
+3	Subtract 0.03 mm (0.0012 in)
+4	Subtract 0.04 mm (0.0016 in)
+5	Subtract 0.05 mm (0.0020 in)
+6	Subtract 0.06 mm (0.0024 in)

13. Select the correct pinion height washer.

Drive pinion height adjusting washer: Refer to SDS, PD-106.



 Remove the J34309 pinion preload shim selector tool from the final drive housing and disassemble to retrieve the pinion bearings.

Tooth Contact


Gear tooth contact pattern check is necessary to verify correct relationship between ring gear and drive pinion.

Hypoid gear sets which are not positioned properly may be noisy, or have short life or both. With a pattern check, the most desirable contact for low noise level and long life can be assured.



MA

EM



Thoroughly clean ring gear and drive pinion teeth.

Sparingly apply a mixture of powdered ferric oxide and oil or equivalent to 3 or 4 teeth of ring gear drive side.

FE

CL

MIT

Hold companion flange steady and rotate the ring gear in both directions.

RA

BR

Usually the pattern will be correct if you have calculated the shims correctly and the backlash is correct. However, in rare cases you may have to use trial-and-error processes until you get a good tooth contact pattern. The tooth pattern is the best indication of how well a differential has been set up.

SPD695





ŜT

MA

IDX

SPD007






Differential Case

1. Measure clearance between side gear thrust washer and differential case.


Clearance between side gear thrust washer and differential case (A — B):
Less than 0.15 mm (0.0059 in)

The clearance can be adjusted with side gear thrust washer. Refer to SDS, PD-106.

2. Apply gear oil to gear tooth surfaces and thrust surfaces and check to see they turn properly.




- 3. Install differential case LH and RH.
- Install differential case on ring gear.



- 5. Place differential case on ring gear.
- Apply locking agent [Locktite (stud lock) or equivalent] to ring gear bolts, and install them.

Tighten bolts in a criss-cross fashion, lightly tapping bolt head with a hammer.




- 7. Press-fit side bearing inner cones on differential case with Tool. **Tool numbers:**
 - (A) ST33190000 (J25523)
 - ® ST33081000 (−)

Select

drive

"ADJUSTMENT", PD-92.



Differential Carrier

1. Press-fit front and rear bearing outer races with Tools.

Tool numbers:

(A) ST30611000 (J25742-1)

(B) \$T30621000 (J25742-5)

© ST30613000 (J25742-3)

MA

G

LC

FE

washer. Refer

Install drive pinion adjusting washer in drive pinion, and pressfit pinion rear bearing inner cone in it, with press and Tool.

adjusting

Tool number: ST30901000 (J26010-01)

pinion

PD

Place pinion front bearing inner cone in gear carrier.

BR

ST

RS

BŢ

Apply multi-purpose grease to cavity at sealing lips of oil seal. Install front oil seal.

Tool numbers:


(A) ST30720000 (J25405)


® KV38102510 (—)




HA

761




















Differential Carrier (Cont'd)



6. Install drive pinion bearing spacer, pinion bearing adjusting shim and drive pinion in gear carrier.




7. Insert companion flange into drive pinion by tapping the companion flange with a soft hammer.



8. Tighten pinion nut to the specified torque.

The threaded portion of drive pinion and pinion nut should be free from oil or grease.

Tool number: KV38104700 (J34311)




9. Turn drive pinion in both directions several times, and measure pinion bearing preload.

Tool number: ST3127S000 (J25765-A)
Pinion bearing preload (Without front oil seal):
1.2 - 1.5 N·m (12 - 15 kg-cm, 10 - 13 in-lb)

If preload is out of specification, adjust the thickness of spacer and shim combination by replacing shim and spacer with thinner one.


- Start from the combination of thickest spacer and shim.
- Combine each spacer and shim thickness one by one until the correct specification is achieved.



- Install differential case assembly with side bearing outer races into gear carrier.
- Position side bearing adjusters on gear carrier with threads properly engaged; screw in adjusters lightly at this stage of assembly.

Tool number: ST32580000 (J34312)

ASSEMBLY




Differential Carrier (Cont'd)

Align mark on bearing cap with that on gear carrier and install bearing cap on gear carrier.

 Do not tighten at this point to allow further tightening of side bearing adjusters.



LC




13. Tighten both right and left side bearing adjusters alternately and measure ring gear backlash and total preload at the same time. Adjust right and left side bearing adjusters by tightening them alternately so that proper ring gear backlash and total preload can be obtained.

Ring gear-to-drive pinion backlash: 0.15 - 0.20 mm (0.0059 - 0.0079 in)

CL

MT



Side lock

SPD698

 When checking preload, turn drive pinion in both directions several times to set bearing rollers.

Tool number: ST3127S000 (J25765-A) Total preload:

1.7 - 2.5 N·m (17 - 25 kg-cm, 15 - 22 in-lb)

PD

TF

FA

RA

14. Tighten side bearing cap bolts.

15. Install side lock finger in place to prevent rotation during operation.


BR

ST

RS

U.S

BT




 If backlash varies excessively in different places, the variance may have resulted from foreign matter caught between the ring gear and the differential case.

 If the backlash varies greatly when the runout of the ring gear is within a specified range, the hypoid gear set or differential case should be replaced.

17. Check tooth contact. Refer to "ADJUSTMENT", PD-95.

HA



PD-99

763

Propeller Shaft

GENERAL SPECIFICATIONS

2WD models

Wheelbase			Standard Long				
Transmission			M/T A/T M/T				
Propeller shaft model	" " " " " " " " " " " " " " " " " " " "			387	71A		
Number of joints				3	3		
Coupling method with transmission			Sleeve type				
Type of journal bearing	s		Solid type (disassembly type)				
Distance between yoke	S	mm (in)	88.1 (3.47)				
Shaft length (Spider to spider)		mm (in)					
	1st		651.5 (25.65)	549.9 (21.65)	651.5 (25.65)	549.9 (21.65)	
	2nd		675.2 (26.58)	975.2 ((38.39)	
Shaft outer diameter		mm (in)					
	1st		63.5 (2.50)				
	2nd		63.5 (2.50)				

4WD models

Location			Front	Rear		
Wheelbase				Standard	Long	
Propeller shaft model			2F71H	2S80B	3\$80B	
Number of joints				2	3	
Coupling method with tra	nsmission		Flange type	Sleev	e type	
Type of journal bearings			Solid type (disassembly type)			
Distance between yokes		mm (in)	88.1 (3.47)			
Shaft length (Spider to spider)		mm (in)				
	1st		514.1 (20.24)	938.1 (36.93)	398.0 (15.67)	
2nd			_	<u> </u>	840.3 (33.08)	
Shaft outer diameter		mm (in)				
	1st		63.5 (2.50)	63.5 (2.50)	63.5 (2.50)	
	2nd		_	_	63.5 (2.50)	

Unit: mm (in)

Part number

37146-C9400

37147-C9400

37148-C9400 37149-C9400

37150-C9400 37151-C9400

37152-C9400

37153-C9400

Propeller Shaft (Cont'd)

SERVICE DATA

Snap ring

Thickness

1.99 (0.0783) 2.02 (0.0795)

2.05 (0.0807)

2.08 (0.0819)

2.11 (0.0831)

2.14 (0.0843)

2.17 (0.0854)

2.20 (0.0866)

	Unit: mm (in)
Propeller shaft runout limit	0.6 (0.024)
Journal axial play	0.02 (0.0008) or less

Color

White

Yellow

Red

Green

Blue

Light brown

Black

No paint

MA

Œ[

0000

EM

n 🙈

Ь	S

re 🙉	·
	,



CL





TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

Final Drive

GENERAL SPECIFICATIONS

2WD models

Transmission		M/T A/T					<u></u>	
Body type	Regular/	King cab	King cab King cab			Regular/King cab		
Vehicle type	Except SE				XE*		SE/XE	
	Standard	Optional	Standard	Optional	Standard	Optional	Standard	Optiona
Final drive model	H190A		C200			H190A		
	2-pinion	L\$D	2-pinion	LSD	2-pinion	L\$D	2-pinion	LSD
Gear ratio	3.545		3.900			4.111		
Number of teeth (Ring gear/drive pinion)	39/11		39/10			37/9		
Oil capacity (Approx.) ℓ (US pt, Imp pt)	1.5 (3-1/8, 2-5/8)		1.3 (2-3/4, 2-1/4)			(3-1/8,	.5 2-5/8)	

^{*:} Option

4WD models

R180A		
4- pi	nion	
4.625 1.3 (2-3/4, 2-1/4)		
		Standard
H20	33B	
4-pinion	LSD	
4.625		
37/8		
Oil capacity (Approx.) ℓ (US pt, Imp pt) 2.8 (5-7/8,		
	4-pi 4.6 1.3 (2-3/ Standard H23 4-pinion 4.6	

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (R180A)

Ring gear runout

Ring gear runout limit	mm (in)	 0.05 (0.0020)	

Axle bearing adjustment

Axle bearing end play	mm (in)	0 - 0.1 (0 - 0.004)
Available axle bea	shims	
Thickness m	ım (in)	Part number
0.10 (0.0039)		38233-01G11
0.20 (0.00	79)	38233-01G12
0.30 (0.0118)		38233-01G13
0.40 (0.0157)		38233-01G14
0.50 (0.01	97)	38233-01G10

Side gear adjustment

Side gear backlash		
(Clearance between side gea	rand	Less than 0.15 (0.0059)
differential case)	mm (in)	

Available side gear thrust washers

Thickness mm (in)	Part number
0.75 - 0.78 (0.0295 - 0.0307) 0.78 - 0.81 (0.0307 - 0.0319) 0.81 - 0.84 (0.0319 - 0.0331) 0.84 - 0.87 (0.0331 - 0.0343) 0.87 - 0.90 (0.0343 - 0.0354) 0.90 - 0.93 (0.0354 - 0.0366) 0.93 - 0.96 (0.0366 - 0.0378)	38424-W2010 38424-W2011 38424-W2012 38424-W2013 38424-W2014 38424-W2015 38424-W2016
0.96 - 0.99 (0.0378 - 0.0390)	38424-W2017

Side bearing adjustment

Differential carrier assembly turning resistance N (kg, lb)	34.3 - 39.2 (3.5 - 4.0, 7.7 - 8.8)	
Side bearing adjusting method	Adjusting shim	
Available side retainer shims		
Thickness mm (in)	Part number	
0.20 (0.0079) 0.25 (0.0098) 0.30 (0.0118) 0.40 (0.0157) 0.50 (0.0197)	38453-01G00 38453-01G01 38453-01G02 38453-01G03 38453-01G04	

Total preload adjustment

Total preload	1.2 - 2.3
N·m (kg-cm, in-tb	(12 - 23, 10 - 20)
Ring gear backlash mm (in	0.13 - 0.18 (0.0051 - 0.0071)

Drive pinion height adjustment

Available pinion height adjusting washers

38154-P6017 38154-P6018	_ MA
38154-P6019	
38154-P6020	ISIMI
38154-P6021	
38154-P6022	
38154-P6023	[_C
38154-P6024	
38154-P6025	
38154-P6026	
38154-P6027	EC
38154-P6028	
38154-P6029	
38154-P6030	PP
38154-P6031	33
38154-P6032	
38154-P6033	
38154-P6034	©L
38154-P6035	96
38154-P6036	
	38154-P6021 38154-P6022 38154-P6023 38154-P6024 38154-P6025 38154-P6026 38154-P6027 38154-P6028 38154-P6030 38154-P6031 38154-P6031 38154-P6032 38154-P6033 38154-P6034 38154-P6035

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Adjusting washer and spacer	• AT
Drive pinion preload N·m (kg-cm, in-lb)		
With front oil seal	1.1 - 1.7 (11 - 17, 9.5 - 14.8)	TF

PN	eload adjusting washers	Available drive pinion bearing pr
	Part number	Thickness mm (in)
	38127-01G00	6.59 (0.2594)
FA	38127-01G01	6.57 (0.2587)
U L G	38127-01G02	6.55 (0.2579)
	38127-01G03	6.53 (0.2571)
	38127-01G04	6.51 (0.2563)
$\mathbb{R}\mathbb{A}$	38127-01G05	6.49 (0.2555)
	38127-01G06	6.47 (0.2547)
	38127-01G07	6.45 (0.2539)
frédra)	38127-01G08	6.43 (0.2531)
BR	38127-01G09	6.41 (0.2524)
	38127-01G10	6.39 (0.2516)
	38127-01G11	6.37 (0.2508)
ST	38127-01G12	6.35 (0.2500)
© 0	38127-01G13	6.33 (0.2492)
	38127-01G14	6.31 (0.2484)
 P@	eload adjusting spacers	Available drive pinion bearing pr

art number 130-78500	
. +	
131-78500	BT
132-78500	
133-78500	
134-78500	HA
135-78500	L¬J <i>L</i> "
	3132-78500 3133-78500 3134-78500 3135-78500

G[

MT

PD-103 767

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (H190A)

Ring gear runout

Ring gear runout limit	mm (in)	0.08 (0.0031)

Side gear adjustment

Side gear backlash	
(Clearance between side gear to	Less than 0.15 (0.0059)
differential case) mm	(in)

Available side gear thrust washers Conventional models

Thickness mm (in)	Part number
0.75 (0.0295)	38424-E3000
0.80 (0.0315)	38424-E3001
0.85 (0.0335)	38424-E3002
0.90 (0.0354)	38424-E3003

LSD models

Thickness mm (in)	ID color	Part number
1.50 (0.0591)	None	38424-41W00
1.60 (0.0630)	White	38424-41W01
1.70 (0.0669)	Yellow	38424-41W02

Additional service for LSD model — Differential torque adjustment

69 - 118 (7 - 12, 51 - 87)
39 - 74 (4 - 7.5, 29 - 54)
4
4
2
2
0.1 (0.004)
0.08 (0.0031)

Available discs and plates

Part name	Thickness mm (in)	Part number	
Friction disc	1.75 (0.0689) 1.85 (0.0728)	38433-41W00 38433-41W01	
Friction plate	1.75 (0.0689)	38432-41W00	
Spring disc	1.75 (0.0689)	38436-N3210	
Spring plate	1.75 (0.0689)	38435-N3210	

Drive pinion height adjustment

Available drive pinion height adjusting washers

Thickness mm (in)	Part number
2.58 (0.1016)	38154-P6000
2.61 (0.1028)	38154-P6001
2.64 (0.1039)	38154-P6002
2.67 (0.1051)	38154-P6003
2.70 (0.1063)	38154-P6004
2.73 (0.1075)	38154-P6005
2.76 (0.1087)	38154-P6006
2.79 (0.1098)	38154-P6007
2.82 (0.1110)	38154-P6008
2.85 (0.1122)	38154-P6009
2.88 (0.1134)	38154-P6010
2.91 (0.1146)	38154-P6011
2.94 (0.1157)	38154-P6012
2.97 (0.1169)	38154-P6013
3.00 (0.1181)	38154-P6014
3.03 (0.1193)	38154-P6015
3.06 (0.1205)	38154-P6016
3.09 (0.1217)	38154-P6017
3.12 (0.1228)	38154-P6018
3.15 (0.1240)	38154-P6019
3.18 (0.1252)	38154-P6020

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Collapsible spacer
Drive pinion preload N-m (kg-cm, in-lb)	
With front oil seal	1.1 - 1.6 (11 - 16, 9.5 - 13.9)

Side bearing adjustment

Differential carrier assembly turning resistance N (kg,	×
Side bearing adjusting method	Adjusting shim
Available side bearing adjusting	ng shims
Thickness mm (in)	Part number
0.10 (0.0039)	38455-61200
0.12 (0.0047) 0.15 (0.0059)	38453-61201 38453-61202
0.17 (0.0067)	38453-61203
0.20 (0.0079)	38456-61200
0.25 (0.0098)	38453-61204
0.30 (0.0118)	38453-61205
0.40 (0.0157) 0.50 (0.0197)	38453-61206 38457-61200

Total preload adjustment

Total preload N·m (kg-cm, in-lb)	1.2 - 2.2 (12 - 22, 10 - 19)
Ring gear backlash mm (in)	0.13 - 0.18 (0.0051 - 0.0071)

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (C200)

Ring gear runout

Ring gear runout limit	mm (in)	0.05 (0.0020)
The second secon		

Side gear adjustment

Side gear backlash		
(Clearance between side	e gear and	Less than 0.15 (0.0059)
differential case)	mm (in)	

Available side gear thrust washers

Thickness mm (in)	Part number
0.75 (0.0295)	38424-N3110
0.78 (0.0307)	38424-N3111
0.81 (0.0319)	38424-N3112
0.84 (0.0331)	38424-N3113
0.87 (0.0343)	38424-N3114
0.90 (0.0354)	38424-N3115
0.93 (0.0366)	38424-N3116

Side bearing adjustment

Differential carrier	assembly turning	34.3 - 39.2
resistance	N (kg, lb)	(3.5 - 4.0, 7.7 - 8.8)

Available side bearing adjusting washers

Thickness mm (in)	Part number
2.00 (0.0787)	38453-N3100
2.05 (0.0807)	38453-N3101
2.10 (0.0827)	38453-N3102
2.15 (0.0846)	38453-N3103
2.20 (0.0866)	38453-N3104
2.25 (0.0886)	38453-N3105
2.30 (0.0906)	38453-N3106
2.35 (0.0925)	38453-N3107
2.40 (0.0945)	38453-N3108
2.45 (0.0965)	38453-N3109
2.50 (0.0984)	38453-N3110
2.55 (0.1004)	38453-N3111
2.60 (0.1024)	38453-N3112

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number	MA
3.09 (0.1217)	38154-P6017	3552 3
3.12 (0.1228)	38154-P6018	
3.15 (0.1240)	38154-P6019	r≡n.ai
3.18 (0.1252)	38154-P6020	EM
3.21 (0.1264)	38154-P6021	
3.24 (0.1276)	38154-P6022	
3.27 (0.1287)	38154-P6023	LC
3.30 (0.1299)	38154-P6024	
3.33 (0.1311)	38154-P6025	
3.36 (0.1323)	38154-P6026	
3.39 (0.1335)	38154-P6027	EC
3.42 (0.1346)	38154-P6028	
3.45 (0.1358)	38154-P6029	
3.48 (0.1370)	38154-P6030	序置
3.51 (0.1382)	38154-P6031	
3.54 (0.1394)	38154-P6032	
3.57 (0.1406)	38154-P6033	
3.60 (0.1417)	38154-P6034	GL
3.63 (0.1429)	38154-P6035	<u>, П</u>
3.66 (0.1441)	38154-P6036	

Total preload adjustment

Total preload N·m (kg-cm, in-lb)		g-cm, in-lb)	1.2 - 2.3 (12 - 23, 10 - 20)
Ring gear back	klash	mm (in)	0.13 - 0.18 (0.0051 - 0.0071)

Additional service for LSD model — (C200)

Differential torque adjustment

Differential torque N·m (kg-m, ft-lb)	88 - 108 (9.0 - 11.0, 65 - 80)
Number of discs and plates	
Friction disc	12
Friction plate	12
Spring plate	2
Wear limit of plate and disc mm (in)	0.1 (0.004)
Allowable warpage of friction disc and plate mm (in)	0.08 (0.0031)

Available discs and plates

Part name	Thickness mm (in)	Part number
Fristian dian	1.5 (0.059)	38433-C6002 (Standard type)
Friction disc	1.6 (0.063)	38433-C6003 (Adjusting type)
Friction plate	1.5 (0.059)	38432-C6001
Spring plate	1.5 (0.059)	38435-C6011

EL

PD-105 769

PD

Mï

AT

TF

GI



88

ST

RS

- BT -

HA

Final Drive (Cont'd)

INSPECTION AND ADJUSTMENT (H233B)

Ring gear runout

Ring gear runout limit	mm (in)	0.08 (0.0031)	
Side gear adius	stment		

Less than 0.15 (0.0059)
s
Part number
38424-T5000
38424- T 5001
38424-T5002

- Additional service for LSD model -Differential torque adjustment

Differential torque N·m (kg-m, ft-lb)	201 - 240 (20.5 - 24.5, 148 - 177)	
Number of discs and plates		
Friction disc Friction plate Spring disc Spring plate	10 12 2 2	
Wear limit of plate and disc mm (in)	0.1 (0.004)	
Allowable warpage of friction disc and plate mm (in)	0.08 (0.0031)	

Available discs and plates

Part name	Thickness mm (in)	Part number
Friation diag	1.48 - 1.52 (0.0583 - 0.0598)	38433-C6000 (Standard type)
Friction disc	1.58 - 1.62 (0.0622 - 0.0638)	38433-C6001 (Adjusting type)
Friction plate	1.48 - 1.52 (0.0583 - 0.0598)	38432-C6000
Spring disc	1.48 - 1.52 (0.0583 - 0.0598)	38436-C6000
Spring plate	1.48 - 1.52 (0.0583 - 0.0598)	38435-C6010

Drive pinion height adjustment

Available pinion height adjusting washers

Thickness mm (in)	Part number
2.58 (0.1016)	38151-01J00
2.61 (0.1028)	38151-01J01
2.64 (0.1039)	38151-01J02
2.67 (0.1051)	38151-01J03
2.70 (0.1063)	38151-01J04
2.73 (0.1075)	38151-01J05
2.76 (0.1087)	38151-01J06
2.79 (0.1098)	38151-01J07
2.82 (0.1110)	38151-01J08
2.85 (0.1122)	38151-01J09
2.88 (0.1134)	38151-01J10
2.91 (0.1146)	38151-01J11
2.94 (0.1157)	38151-01J12
2.97 (0.1169)	38151-01J13
3.00 (0.1181)	38151-01J14
3.03 (0.1193)	38151-01J15
3.06 (0.1205)	38151-01J16
3.09 (0.1217)	38151-01J17
3.12 (0.1228)	38151-01J18
3.15 (0.1240)	38151-01J19
3.18 (0.1252)	38151-01J60
3.21 (0.1264)	38151-01 J 61
3.24 (0.1276)	38151-01J62
3.27 (0.1287)	38151-01J63
3.30 (0.1299)	38151-01J64
3.33 (0.1311)	38151-01J65
3.36 (0.1323)	38151-01J66
3.39 (0.1335)	38151-01J67
3.42 (0.1346)	38151-01J68
3.45 (0.1358)	38151-01J69
3.48 (0.1370)	38151-01J70
3.51 (0.1382)	38151-01J71
3.54 (0.1394)	38151-01J72
3.57 (0.1406)	38151-01J73
3.60 (0.1417)	38151-01J74
3.63 (0.1429)	38151-01J75
3.66 (0.1441)	38151-01J76

Final Drive (Cont'd)

Drive pinion preload adjustment

Drive pinion bearing preload adjusting method	Adjusting shim and spacer
Drive pinion preload N·m (kg-cm, in-lb)	
Without front oil seal	1.2 - 1.5 (12 - 15, 10 - 13)

Part number

38125-82100 38126-82100

38127-82100

38128-82100

38129-82100

38130-82100

38131-82100

38132-82100

38133-82100

38134-82100

38135-82100

38136-82100

38137-82100

38138-82100

38139-82100

Part number

38165-76000

38166-76000

38167-76000 38166-01J00

38166-01J10

Available drive pinion preload adjusting shims

Thickness mm (in)

2.31 (0.0909)

2.33 (0.0917)

2.35 (0.0925)

2.37 (0.0933)

2.39 (0.0941)

2.41 (0.0949)

2.43 (0.0957)

2.45 (0.0965)

2.47 (0.0972)

2.49 (0.0980)

2.51 (0.0988)

2.53 (0.0996)

2.55 (0.1004)

2.57 (0.1012)

2.59 (0.1020)

Length mm (in)

4.50 (0.1772)

4.75 (0.1870)

5.00 (0.1969)

5.25 (0.2067) 5.50 (0.2165)

Available drive pinion preload adjusting spacers

Total preload adjustment

Total preload N·m (kg-cm, in-lb)	1.7 - 2.5 (17 - 25, 15 - 22)	MA
Ring gear backlash mm (in)	0.15 - 0.20 (0.0059 - 0.0079)	DOIL C
Side bearing adjusting method	Side adjuster	

GI

C

EC	











PD







ST



BT

HA

FRONT AXLE & (3) FRONT SUSPENSION

SECTION FA

MA

EM

LC

EC

FE

C[L

MT

AT

TF

PD

CONTENTS

PRECAUTIONS AND PREPARATION	2
Precautions	
Special Service Tools	
Commercial Service Tools	
FRONT AXLE AND FRONT SUSPENSION	
ON-VEHICLE SERVICE	5
Front Axle and Front Suspension Parts	5
Front Wheel Bearing	
Preload Adjustment (2WD)	
Preload Adjustment (4WD)	
Front Wheel Alignment	8
Preliminary Inspection	8
Camber, Caster And Kingpin Inclination	g
Adjustment	
Toe-In	12
Front Wheel Turning Angle	13
Drive Cheft	4.4

FRONT AXLE	15
FRONT AXLE (4WD)	17
Manual-lock Free-running Hub	
Auto-lock Free-running Hub	18
FRONT AXLE	24
Wheel Hub and Rotor Disc	24
Knuckle Spindle	25
FRONT AXLE (4WD)	28
Drive Shaft	
FRONT SUSPENSION	
Shock Absorber	36
Torsion Bar Spring	36
Stabilizer Bar	39
Upper Link	40
Tension Rod or Compression Rod	42
Lower Link	43
Upper Ball Joint and Lower Ball Joint	44
SERVICE DATA AND SPECIFICATIONS (SDS).	45
General Specifications	45
Inspection and Adjustment	46



RA

BR

ST

RS


BT

HA

EL

IDX

PRECAUTIONS AND PREPARATION



Precautions

- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
 - * Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Use flare nut wrench when removing or installing brake tubes.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Always torque brake lines when installing.

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Danadatian			Unit application	
	Description		2WD	4WD	
ST29020001 (J24319-01) Gear arm puller	NT143	Removing ball joint for knuckle spindle	х	X	
HT72520000 (J25730-B) Ball joint remover	NT146	Removing tie-rod outer end	x	х	
KV401021S0 (—) Bearing race drift	NT153	Installing wheel bearing outer race	x	х	
KV40105400 (J36001) Wheef bearing lock nut wrench	NT154	Removing or installing wheel bearing lock nut	_	х	

Commercial Service Tools


Tool name	Description	
Flare nut crowfoot Torque wrench		Removing and installing each brake piping
	NT360	a: 10 mm (0.39 in)

2WD

SEC. 400-401-406

When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.

 Fuel, radiator coolant and engine oil full.
 Spare tire, jack, hand tools and mats in designated positions.



AFA101

HA

IDX

G


MA

4WD


SEC. 390-400-401-406


When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.


Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.




: N-m (kg-m, ft-lb)









Front Axle and Front Suspension Parts

Check front axle and front suspension parts for excessive play, cracks, wear or other damage.

Shake each front wheel to check for excessive play.

If looseness is noted, adjust wheel bearing end play, then check ball joint end play.

Make sure that the cotter pin is inserted. b.

Retighten all nuts and bolts to the specified torque. C.

: Refer to FRONT SUSPENSION, FA-34.

Check front axle and front suspension parts for wear, cracks d. or other damage.

Check shock absorber for oil leakage and other damage.

Check suspension ball joint for grease leakage and ball joint dust cover for cracks and other damage.

Check ball joint for vertical end play.

Upper ball joint:

0.1 - 1.4 mm (0.004 - 0.055 in) at side frame.

Jack up front of vehicle and set the stands. a.

Remove road wheel. b.

Clamp dial indicator onto upper link and place indicator tip on knuckle near upper ball joint.

Jack up lower link [Approx. 20 mm (0.79 in).] d.

Place a pry bar between upper link and upper link spindle.

While pushing and releasing pry bar, observe maximum dial indicator value.

If upper ball joint movement is beyond specifications, remove and recheck it. Refer to "Upper Ball Joint and Lower Ball Joint", "FRONT SUSPENSION", FA-44.

Lower ball joint:

0.1 - 1.3 mm (0.004 - 0.051 in) 4WD

0.7 mm (0.028 in) or less

Jack up front of vehicle and set the stands at side frame.

Clamp dial indicator onto transverse link and place indicator tip on lower edge of brake caliper.

Make sure front wheels are straight and brake pedal is depressed.

Place a pry bar between transverse link and inner rim of road

While pushing and releasing pry bar, observe maximum dial indicator value.

If lower ball joint movement is beyond specifications, remove and recheck it. Refer to "Upper Ball Joint and Lower Ball Joint", "FRONT SUSPENSION", FA-44.

> FA-5 777

MA

G1

EC

FE

CL

MIT

AT

TF

PD)

RA


88

ST

RS

BT

HA




Front Wheel Bearing

- Check that wheel bearings operate smoothly.
- Check axial end play.

Axial end play: 0 mm (0 in)


Adjust wheel bearing preload if there is any axial end play or wheel bearing does not turn smoothly.



PRELOAD ADJUSTMENT (2WD)

Adjust wheel bearing preload after wheel bearing has been replaced or front axle has been reassembled.

- 1. Before adjustment, thoroughly clean all parts to prevent dirt
- 2. Apply multi-purpose grease sparingly to the following parts:
- Rubbing surface of spindle
- Contact surface between lock washer and outer wheel bearing
- Hub cap (as shown at left)
- Grease seal lip




Tighten wheel bearing lock nut to the specified torque.


□: 34 - 39 N·m (3.5 - 4.0 kg-m, 25 - 29 ft-lb)

- Turn wheel hub several times in both directions to seat wheel bearing correctly.
- 5. Again tighten wheel bearing lock nut to the specified torque.

(3.5 - 4.0 kg-m, 25 - 29 ft-lb)



- Turn wheel bearing lock nut back 45 degrees.
- Fit adjusting cap and new cotter pin. Align cotter pin slot by loosening nut 15 degrees or less.



Measure wheel bearing preload and axial end play.

Axial end play: 0 mm (0 in)

Wheel bearing preload

(As measured at wheel hub bolt):


[New grease seal]

9.8 - 28.4 N (1.0 - 2.9 kg, 2.2 - 6.4 lb)

[Used grease seal]

9.8 - 23.5 N (1.0 - 2.4 kg, 2.2 - 5.3 lb)

Repeat above procedures until correct bearing preload is obtained.



Front Wheel Bearing (Cont'd)

Spread cotter pin.

10. Install hub cap.

PRELOAD ADJUSTMENT (4WD)

Adjust wheel bearing preload after wheel bearing has been replaced or front axle has been reassembled.

Adjust wheel bearing preload as follows:

Before adjustment, thoroughly clean all parts to prevent dirt


Apply multi-purpose grease sparingly to the following parts:

Threaded portion of spindle

Contact surface between wheel bearing washer and outer wheel bearing

Grease seal lip

Wheel hub (as shown at left)




3. Tighten wheel bearing lock nut with Tool.

☑: 78 - 98 N·m (8 - 10 kg-m, 58 - 72 ft-lb) Turn wheel hub several times in both directions.

Loosen wheel bearing lock nut so that torque becomes 0 N·m (0 kg-m, 0 ft-lb).

Retighten wheel bearing lock nut with Tool.

(0.05 - 1.5 N·m (0.05 - 0.15 kg-m, 4.3 - 13.0 in-lb)




Turn wheel hub several times in both directions.

Retighten wheel bearing lock nut with Tool.

⊕: 0.5 - 1.5 N·m (0.05 - 0.15 kg-m, 4.3 - 13.0 in-lb)

Measure wheel bearing axial end play.

Axial end play: 0 mm (0 in)



Starting force: "A"

SMA580A

10. Measure starting force "A" at wheel hub bolt.

FA-7

779

G

MA

LC

EC

FE

CL

MT

AT

TF

PD

RA

88


ST

RS

BT

HA

EL



Front Wheel Bearing (Cont'd)

- 11. Install lock washer by tightening the lock nut within 15 to 30 degrees.
- 12. Turn wheel hub several times in both directions to seat wheel bearing correctly.
- 13. Measure starting force "B" at wheel hub bolt. Refer to step 10.
- 14. Wheel bearing preload "C" can be calculated as shown below.

$$C = B - A$$

Wheel bearing preload "C":


7.06 - 20.99 N (0.72 - 2.14 kg, 1.59 - 4.72 lb)

- 15. Repeat steps 3 through 14 until correct axial end play and wheel bearing preload are obtained.
- 16. Install free-running hub.

Front Wheel Alignment

Before checking front wheel alignment, make a preliminary inspection (Unladen*).

*: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.




PRELIMINARY INSPECTION

- 1. Check tires for wear and proper inflation.
- 2. Check outside and inside wheel runout.

Wheel runout average

[(Outside runout value + Inside runout value) x 0.5]: Refer to SDS, FA-48.

- Check front wheel bearings for looseness.
- Check front suspension for looseness.
- 5. Check steering linkage for looseness.
- Check that front shock absorbers work properly by using the standard bounce test.



- 7. Measure vehicle height (Unladen): H = A B mm (in) Refer to SDS, FA-46.
- a. Exercise the front suspension by bouncing the front of the vehicle 4 or 5 times to ensure that the vehicle is in a neutral height attitude.
- b. Measure wheel alignment.


Refer to ALLOWABLE LIMIT in SDS, FA-46.


c. If wheel alignment is not as specified, adjust vehicle posture.

Refer to ADJUSTING RANGE in SDS, FA-46.

d. Adjust wheel alignment.

Refer to ADJUSTING RANGE in SDS, FA-46.





Front Wheel Alignment (Cont'd) **CAMBER, CASTER AND KINGPIN INCLINATION**


(1)

Before checking camber, caster or kingpin inclination, move vehicle up and down on turning radius gauge to minimize friction. Ensure that the vehicle is in correct posture.

MA

Measure camber, caster and kingpin inclination of both right and left wheels with a suitable alignment gauge and adjust in accordance with the following procedures.

LC




Camber (Unladen): Refer to SDS, FA-46. Kingpin inclination (Unladen): Refer to SDS, FA-46.

EC FE

CL

MT




Caster (Unladen): Refer to SDS, FA-46.

TF

AT

PD)

RA



ADJUSTMENT

Both camber and caster angles are adjusted by increasing or decreasing the number of adjusting shims inserted between upper link spindle and frame.

ST

BR

RS

BT

MA

EL,

IDX

Adjusting shim B Frame bracket Adjusting shim A Upper link spindle Adjusting shim B (For fine adjustment) Adjusting shim A Shim thickness Shim thickness 1.0 (0.039) 1.0 (0.039) 2.0 (0.079) 2.0 (0.079) 2.6 (0.102) Unit: mm (in) 2.9 (0.114) [2WD only] 4.0 (0.157) [4WD only] SFA970-A

Front Wheel Alignment (Cont'd)

Before removing or installing adjusting shim(s), be sure to place a jack under lower link.

Adjusting shim standard thickness:

2WD

2.9 mm (0.114 in)

4WD

4.0 mm (0.157 in)

- Do not use four or more shims at one place.
- When installing shim B, always face the pawl towards spindle and insert it from bracket side. Use only one shim B in a place.
- Total thickness of shims must be within 8.0 mm (0.315 in).
- Difference of total thickness of the front and rear must be within 3.0 mm (0.118 in).
- Determine thickness and number of shims necessary for adjusting camber and caster, in accordance with the following graph.

[Example]

a. When service data value minus measured value is equal to:

Caster angle: -30' Camber angle: +30'

b. Obtain the intersecting point of lines in accordance with the

- c. Choose shims which are nearest to the intersecting point.
- d. For the above example:


2WD:

Add 2.0 mm (0.079 in) shim on front side.

Add 3.0 mm (0.118 in) shim on rear side.


4WD:

Add 1.0 mm (0.039 in) shim on front side. Add 3.0 mm (0.118 in) shim on rear side.





FA-11 783

SFA478BA



Lines parallel to center line of body Total toe-in = A - B Front SFA234AC





Front Wheel Alignment (Cont'd)

TOE-IN

Measure toe-in using the following procedure.

WARNING:

- Always perform the following procedure on a flat surface.
- Make sure that no one is in front of the vehicle before pushing it.
- 1. Bounce front of vehicle up and down to stabilize the posture.
- 2. Push the vehicle straight ahead about 5 m (16 ft).
- Put a mark on base line of the tread (rear side) of both tires at the same height of hub center. This mark is a measuring point.
- Measure distance "A" (rear side).
- 5. Push the vehicle slowly ahead to rotate the wheels 180 degrees (1/2 turn).
- If the wheels have rotated more than 180 degrees (1/2 turn), try the above procedure again from the beginning. Never push vehicle backward.
- 6. Measure distance "B" (front side).

Total toe-in:

Refer to SDS, FA-46.

- 7. Adjust toe-in by varying the length of both steering tie-rods.
- a. Loosen clamp bolts or lock nuts.
- b. Adjust toe-in by turning both the left and right tie-rod tubes equal amounts.

Make sure that the tie-rod bars are screwed into the tie-rod tube more than 35 mm (1.38 in).

Make sure that the tie-rods are the same length.

Standard length (A = B):


2WD

344 mm (13.54 in)

4WD

281 mm (11.06 in)

:. Tighten clamp bolts or lock nuts, then torque them.



Front Wheel Alignment (Cont'd) FRONT WHEEL TURNING ANGLE

Set wheels in straight-ahead position. Then move vehicle forward until front wheels rest properly on turning radius gauge.

Rotate steering wheel all the way right and left; measure turning angle.

On power steering models, turn steering wheel to full lock and apply force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine at idle.

Do not hold the steering wheel at full lock for more than 15 seconds.

> Wheel turning angle (Full turn): Refer to SDS, FA-46.

EC

LC

GI

MA

EM

FE

CL

Mil

AT

TF

PD

2WD

3. Adjust stopper bolt if necessary. [2WD]

Standard length "L,": 20 mm (0.79 in)

FA

[4WD]

Standard length "L2": 26.5 mm (1.043 in)

RA 8R


ST


RS

BT


HA

EL





FA-13 785




Drive Shaft

Check for grease leakage and damage.

2WD

SEC. 400



SFA559BA

RA

G

BR

ST


RS

BT

HA

4WD

SEC. 391-400



Manual-lock Free-running Hub

@|

MA

LC

ĒC

FE

GL

MT

AT

TF

PD

RA

BR

ST


RS


BT


HA

EL

IDX







REMOVAL AND INSTALLATION

- Set knob of manual-lock free-running hub in the FREE position.
- Remove manual-lock free-running hub with brake pedal depressed.

Remove snap ring and then draw out drive clutch.

 When installing manual-lock free-running hub, make sure the hub is in the FREE position.

Apply multi-purpose grease to the parts shown in the above illustration.


 Check operation of manual-lock free-running hub after installation.


INSPECTION

- Check that the knob moves smoothly and freely.
- Check that the clutch moves smoothly in the body.

FA-17 789


Auto-lock Free-running Hub






REMOVAL AND INSTALLATION

- Set auto-lock free-running hub in the FREE position.
- Remove auto-lock free-running hub with brake pedal depressed.



- Remove snap ring.
- Remove washer B, washer A and brake B.
- After installing auto-lock free-running hub, check operation.

When installing it, apply recommended grease to the parts shown in the above illustration.



INSPECTION

Thoroughly clean parts with cleaning solvent and dry with compressed air.

Brake "A" and "B"

Measure the thickness "L" of brake "A" and "B". If thickness is less than the specified limit, replace brake "A" and "B" as a set.

Noise

Was the transfer lever shifted from the

km/h (25 MPH)?

"2H" to the "4H" position while the vehicle

(Go to next page.)

No

Auto-lock Free-running Hub (Cont'd) TROUBLE-SHOOTING

Noise occurring in the auto-lock free-running hub under any of the conditions described below is not indicative of a problem. Noise can be eliminated by properly operating the transfer lever.



MA












































IDX








was operated at a speed greater than 40 position in high-speed operation (Fig. $A \rightarrow$ Fig. B), is sometimes difficult. At this point, a clattering occurs in the auto hub. If shifting is stopped halfway, the drive shaft no longer rotates and the cam is held in the "LOCK" position (Fig. B). In this case, the noise will continue until the vehicle is stopped. When this occurs, decrease vehicle speed to less than 40 km/h (25 MPH), return the transfer lever to the "2H" position once and then reshift to the "4H" position. Gears will then be engaged and the noise will cease (Fig. C).


Shifting the transfer lever

from the "2H" to the "4H"

Auto-lock Free-running Hub (Cont'd)



(Go to next page.)





SFA523A

Gears engaged in reverse

Auto-lock Free-running Hub (Cont'd)

Yes






(C)

Auto-hub gears will disengage with a resultant noise (clicking). If the distance the vehicle is moved in the opposite direction is short [less than 1 m (3 ft)] or if the rotation angle of the left and right wheels is not the same (as in rounding a corner), gears on one side will disengage (Fig. 1). Under this condition, a noise (crushing, etc.) might occur while driving in the "2H" position. If only gears on one side are unlocked, the locked drive shaft rotates at the same speed as wheels; however, the unlocked drive shaft is made to rotate in the reverse direction by the differential. This forces the auto hub's slide gear to lock in the reverse direction. As a result, noise occurs. If this happens, slowly move

If this happens, slowly move the vehicle straight back approximately 2 to 3 m (7 to 10 ft) with the transfer lever in the "2H" position to disengage the gears on the other side.

(Go to next page.)

FA-22



FΑ

RA

BR


ST


RS

BT

HA

10X






Wheel Hub and Rotor Disc

REMOVAL AND INSTALLATION

- Remove free-running hub assembly. 4WD Refer to FRONT AXLE (4WD) — Auto-lock Free-running Hub or Manual-lock Free-running Hub, FA-17.
- Remove brake caliper assembly without disconnecting hydraulic line.


Be careful not to depress brake pedal, or piston will pop out. Make sure brake hose is not twisted.

Remove lock washer. -- 4WD --



Remove wheel bearing lock nut. 2WD: With suitable tool

4WD: With Tool




Remove wheel hub and wheel bearing.

Be careful not to drop outer bearing.


After installing wheel hub and wheel bearing, adjust wheel bearing preload.

Refer to PRELOAD ADJUSTMENT of Front Wheel Bearing in ON-VEHICLE SERVICE, FA-6.



DISASSEMBLY

Remove bearing outer races with suitable brass bar.



Wheel Hub and Rotor Disc (Cont'd) INSPECTION

Thoroughly clean wheel bearings and wheel hub.

Wheel bearings

Make sure wheel bearings roll freely and are free from noise, cracks, pitting and wear.

MA

GI

Wheel hub

Check wheel hub for cracks by using a magnetic exploration

EM



or dyeing test.

EC

LC

ASSEMBLY

KV401021S0

4WD

🖾 : Multi-purpose grease point

2WD

SFA943

AFA122

SFA459B


Install bearing outer race with Tool until it seats in hub.

FE

CL

MT

AT



TF

PD

Apply multi-purpose grease to each bearing cone.

RA


Pack grease seal lip with multi-purpose grease, then install it into wheel hub with suitable drift.

BR

ST

RS

BT




REMOVAL

Remove free-running hub assembly. — 4WD — Refer to FRONT AXLE (4WD) — Auto-lock Free-running Hub or Manual-lock Free-running Hub, FA-17.

EL

HA




Inner side


FA-25

FRONT AXLE

Knuckle Spindle (Cont'd)




 Separate drive shaft from knuckle spindle by slightly tapping drive shaft end. — 4WD —




Separate tie-rod from knuckle spindle with Tool.

Install stud nut conversely on stud bolt so as not to damage stud bolt.




- Separate knuckle spindle from ball joints.
- (1) Loosen (do not remove) upper and lower ball joint tightening nuts.



(2) Separate knuckle spindle from upper and lower ball joint studs with Tool.

During above operation, never remove ball joint nuts which are loosened in step (1) above.

Seried in Step (1) above.
Tool:
2WD
ST29020001 (J24319-01)
4WD
HT72520000 (J25730-B)




Support lower link with jack.

(4) Remove knuckle spindle from upper and lower links.



Knuckle spindle

Check knuckle spindle for deformation, cracks and other damage by using a magnetic exploration or dyeing test.



Knuckle Spindle (Cont'd)

Bearing spacer — 2WD —

Check bearing spacer for damage.

Needle bearing — 4WD —

Apply multi-purpose grease.

Check needle bearing for wear, scratches, pitting, flaking and burn marks.


MA

GI

EM.

[LC

EC



INSTALLATION

Install bearing spacer onto knuckle spindle. — 2WD —

Make sure that bearing spacer is facing in proper direction. Apply multi-purpose grease.

FE

CL

MT

Install needle bearing into knuckle spindle. — 4WD — Make sure that needle bearing is facing in the proper direction.


TF

AT

PD)

FA

RA



Cotter pin

SFA929

Install knuckle spindle to upper and lower ball joints with lower

link jacked up.

Make sure that oil and grease do not come into contact with tapered areas of ball joint, knuckle spindle and threads of ball joint.

Connect tie-rod to knuckle spindle.

ST

BR

RS

BT


After installing knuckle spindle, adjust wheel bearing preload. Refer to PRELOAD ADJUSTMENT of Front Wheel Bearing in ON-VEHICLE SERVICE, FA-6.

After installing drive shaft, check drive shaft axial end play. Do not reuse snap ring once it has been removed.

EL


HA








Refer to FRONT AXLE (4WD) — Drive shaft, FA-28.

Drive Shaft









REMOVAL

- 1. Remove bolts fixing drive shaft to final drive.
- Remove free-running hub assembly with brake pedal depressed. Refer to FRONT AXLE (4WD) — Auto-lock Freerunning Hub or Manual-lock Free-running Hub, FA-17.
- Remove brake caliper assembly without disconnecting brake hydraulic line.

Be careful not to depress brake pedal, or piston will pop out. Make sure that the brake hose is not twisted.

- Remove tie-rod ball joint. Refer to FRONT AXLE Knuckle Spindle, FA-25.
- 5. Remove nuts fixing lower ball joint on lower link.


Support lower link with jack.

- 6. Remove upper ball joint fixing bolt.
- 7. Remove shock absorber lower bolt.

Remove drive shaft with knuckle.

Cover drive shaft boot with a suitable protector.

Drive Shaft (Cont'd)



Slide joint

housing


9. Separate drive shaft from knuckle by slightly tapping it.

G[

MA

LC

EC



SFA880

SFA392

 Remove plug seal from slide joint housing by lightly tapping around slide joint housing.

FE CL

Remove boot bands.

MT

Matching marks

SFA963

 Move boot and slide joint housing toward wheel side, and put matching marks.

TF

PD

FA

4. Remove snap ring.

BR

RA


ST

RS

BT

HA

IDX




5. Detach spider assembly with press.

FA-29

Drive Shaft (Cont'd)

6. Draw out boot.

Cover drive shaft serration with tape to prevent damaging the boot.



Wheel side (ZF100)


CAUTION:

The joint on the wheel side cannot be disassembled.

- Before separating joint assembly, put matching marks on drive shaft and joint assembly.
- Separate joint assembly with suitable tool.

Be careful not to damage threads on drive shaft.

Remove boot bands.



INSPECTION

Thoroughly clean all parts in cleaning solvent, and dry with compressed air. Check parts for evidence of deformation or other damage.

Drive shaft

Replace drive shaft if it is twisted or cracked.

Boot

Check boot for fatigue, cracks and wear. Replace boot with new boot bands.

Joint assembly (Final drive side)

- Replace any parts of double offset joint which show signs of scorching, rust, wear or excessive play.
- Check serration for deformation. Replace if necessary.
- Check slide joint housing for any damage. Replace if necessary.


Joint assembly (Wheel side)

Replace joint assembly if it is deformed or damaged.

ASSEMBLY

- After drive shaft has been assembled, ensure that it moves smoothly over its entire range without binding.
- Use NISSAN GENUINE GREASE or equivalent after every overhaul.

FA-30 802



Suitable tool

Chamfer

SFA397

SFA460BA

Suitable tool

Drive Shaft (Cont'd)

Final drive side (TS82F)

Install new small boot band, boot and side joint housing to drive shaft.


Cover drive shaft serration with tape to prevent damaging boot during installation.



@[

<u>l</u>C

国网



Press-fit with spider assembly serration chamfer facing shaft.

FE

Install new snap ring.

CL

MT

Pack with grease.


Specified amount of grease: 95 - 105 g (3.35 - 3.70 oz)

AT

5. Make sure that the boot is properly installed on the drive shaft groove. Set the boot so that it does not swell or deform when its length is "L₁". Length "L₁": 95 - 97 mm (3.74 - 3.82 in)

PD

FA



BR

Apply sealant to mating surface of plug seal.

ST

RS

BT

Wheel side (ZF100)


Install new small boot band and boot on drive shaft.

Cover drive shaft serration with tape to prevent damaging boot during installation.

EL


HA

IDX




Boot band

Drive Shaft (Cont'd)



Set joint assembly onto drive shaft by lightly tapping it. Install joint assembly securely, ensuring that marks which were made during disassembly are properly aligned.




Pack drive shaft with specified amount of grease.

Specified amount of grease: 135 - 145 g (4.76 - 5.11 oz)


Make sure that the boot is properly installed on the drive shaft groove. Set the boot so that it does not swell or deform when its length is "L2".

- Length " L_2 ": 96 98 mm (3.78 3.86 in) Lock new large boot band securely with a suitable tool.
- Lock new small boot band.



INSTALLATION


Apply multi-purpose grease.




Install bearing spacer onto drive shaft.

Make sure that the bearing spacer is facing in the proper direction.

After installing wheel hub and wheel bearing, adjust wheel bearing preload. Refer to PRELOAD ADJUSTMENT of Front Wheel Bearing in ON-VEHICLE SERVICE, FA-6.



- When installing drive shaft, adjust drive shaft axial end play by selecting a suitable snap ring.
- (1) Temporarily install new snap ring on drive shaft in the same thickness as it was installed before removal.



Drive Shaft (Cont'd)

(2) Set dial gauge on drive shaft end.

(3) Measure axial end play of drive shaft.

Axial end play:

0.45 mm (0.0177 in) or less

(4) If axial end play is not within the specified limit, select another snap ring.

1.1 mm (0.043 in)

1.3 mm (0.051 in)

1.5 mm (0.059 in)

1.7 mm (0.067 in)

1.9 mm (0.075 in)

2.1 mm (0.083 in)

2.3 mm (0.091 in)

EC

LC

G

MA

em

FΞ

CL

MT

AT

TF

PD

RA

BR

ST


RS

BT

HA

IDX


2WD





Gl 4WD Do not allow the bushings and washers to come When installing stabilizer bar, compression rod, project beyond the surface area of the washer. MA lower and upper links, final tightening must be carried out under unladen condition* with tires When removing or installing brake tubes, use In contact with grease, oil, soapy water, etc. When installing a bushing, do not allow it to When removing each suspension part, check (11.6 - 15.0, Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in Nut 💸 wheel alignment and adjust if necessary. 84 - 108) E Ķ (3) 89 - 118 (9.1 - 12.0, 66 - 87) Anchor bolt pitot Anchor arm bolt 30 - 40 (3.1 - 4.1, 22 - 30) Anchor arm LC Snap ring-Ô lare nut torque wrench. designated positions. Dust cover -Torsion bar spring 6 EC on the ground. (4.6 - 6.1, 33 - 44) Front spring torque arm Nut 🚰 16 - 22 (1.6 - 2.2, 12 - 16) FE Shock absorber (12 - 15, 87 - 108) Dust cover CL -Upper link bushing outer washer Ę (12.0 - 15.0)Nut (12.0 - 19.5, 87 - 141) (1.6 - 23 (1.6 - 2.3, 12 - 17) Nut 💸 87 - 108) MT Compression rod Bushing -Washer Washer AT Upper link bushing () 邒 @@@@ -Cotter pin -(8.0 - 15.0, 58 - 108) Bound bumper → Cotter pin 🔯 Nut 78 - 147 ġ PD Nut S Filler plug Spring washer 1 (4.8 - 6.2, Dust cover O 47 - 61 Lower link 35 - 45) FA (1.6 - 2.2, spindle 12 - 16) ball joint 16 - 22 16 - 22 **(10) S**toN RA Lower Ò Dust cover Upper ball joint Dust cover clamp B (3) BR 0 \$ CO @ 8 0 ⊃@@ Upper link **(1)** 9 (I) (I) (I Bushing ST @ Nut S 16 - 22 (1.6 - 2.2, 12 - 16) (11.1 - 15.0, 80 - 108) RS : N•m (kg-m, ft-lb) B -Bushing When adjusting wheel alignment, Clamp (11.1 - 15.0, 80 - 108) To upper link spindle Nut 💸 Clamp (7.2 - 10.5, 52 - 76) BT Upper link spindle Washer 109 - 147 To frame HA 9 O 71 - 103 Adjusting shims SEC. 401-406 select them. (5.2 - 6.2,⁻ 38 - 45) EL 51 - 61 Stabilizer **FRONT**


FA-35


AFA098











Shock Absorber

REMOVAL AND INSTALLATION

When removing and installing shock absorber, do not allow oil or grease to contact rubber parts.

INSPECTION

Except for nonmetallic parts, clean all parts with suitable solvent and dry with compressed air.

Use compressed air to blow dirt and dust off of nonmetallic parts.

- Check for oil leakage and cracks. Replace if necessary.
- Check piston rod for cracks, deformation and other damage.
 Replace if necessary.
- Check rubber parts for wear, cracks, damage and deformation.
 Replace if necessary.

Torsion Bar Spring

REMOVAL

Remove adjusting nut.

- Move dust cover, then detach snap ring from anchor arm.
- Pull out anchor arm rearward, then withdraw torsion bar spring rearward. — 2WD —
- Remove torque arm. 2WD —

 Remove torque arm fixing nuts, then withdraw torsion bar spring forward with torque arm. — 4WD —

INSPECTION

- Check torsion bar spring for wear, twist, bend and other damage.
- Check serrations of each part for cracks, wear, twist and other damage.
- Check dust cover for cracks.

Torsion Bar Spring (Cont'd) **INSTALLATION AND ADJUSTMENT**

G

Adjustment of anchor arm adjusting nut is in tightening direction only.

Do not adjust by loosening anchor arm adjusting nut.

MA

- Install torque arm to lower link. 2WD —
- Coat multi-purpose grease on the serration of torsion bar spring.

LC

Place lower link in the position where bound bumper clearance "C" is 0.

Clearance "C": 0 mm (0 in)

FE

GL

MT

AT

Install torsion bar spring. — 2WD — Install torsion bar spring with torque arm. — 4WD —

Be sure to install right and left torsion bar springs correctly.

TF

PD

FA

RA

BR

ST


RS


BT


HA


EL

IDX









Set anchor arm.

SFA854

Standard length "G": 2WD

6 - 18 mm (0.24 - 0.71 in)

4WD


50 - 60 mm (1.97 - 2.36 in)

Dust cover Snap ring SFA914-A

Torsion Bar Spring (Cont'd)


Install snap ring to anchor arm and dust cover.
 2WD

Make sure that the snap ring is properly installed on the anchor arm groove.



- 4WD -

Make sure that the snap ring and anchor arm are properly installed.




7. Tighten anchor arm adjusting nut to get L dimension. Standard length "L":

2WD


49 mm (1.93 in)


4WD


77 mm (3.03 in)




2WD Lower link spindle center: R Tension rod attaching bolt SFA709-B









Torsion Bar Spring (Cont'd)

Bounce vehicle with tires on ground (Unladen) to eliminate friction of suspension.

Measure vehicle posture "H".

(1) Exercise the front suspension by bouncing the front of the vehicle 4 or 5 times to ensure that the vehicle is in a neutral height attitude.

(2) Measure vehicle posture ... Dimension "H".

H = A - B mm (in) "Unladen" Refer to WHEEL ALIGNMENT (Unladen) in SDS, FA-46.

10. If height of the vehicle is not within allowable limit, adjust vehicle posture.

Refer to WHEEL ALIGNMENT (Unladen) in SDS, FA-46.

11. Check wheel alignment if necessary. Refer to WHEEL ALIGNMENT (Unladen) in SDS,FA-46.

Stabilizer Bar

REMOVAL

Remove stabilizer bar connecting bolts and clamp bolts.

INSPECTION

Check stabilizer bar for twist and deformation. Replace if necessary.

Check rubber bushing for cracks, wear and deterioration. Replace if necessary.

INSTALLATION

Install bushing outside of white mark painted on stabilizer.

FA-39

MA

 $\mathbb{E}\mathbb{M}$

LC

FE

CL

MT

AT

TF

PD

FA

RA


BR

ST

RS

BT


MA EL.




Upper Link

REMOVAL

Remove shock absorber upper fixing nut.




- Remove bolts fixing upper ball joint on upper link. Support lower link with jack.
- Remove upper link spindle fixing bolts.




INSTALLATION

- Tighten upper link spindle with camber adjusting shims.
- After fitting, check dimensions "A" and "B".

A: 110 mm (4.33 in) B: 32 mm (1.26 in)



- Install upper ball joint on upper link.
- Install shock absorber upper fixing nut.
- Tighten upper link spindle lock nuts under unladen condition with tires on ground.
- After installing, check wheel alignment. Adjust if necessary. Refer to FA-8.




DISASSEMBLY

Press out upper link spindle with bushings.

INSPECTION

- Check upper link spindle and rubber bushings for damage. Replace if necessary.
- Check upper link for deformation and cracks. Replace if necessary.





Apply soapsuds to rubber bushing.

Press upper link bushing.

Press bushing so that the flange of bushing securely contacts the end surface of the upper link collar.

GI

LC

EC

Inner washers 0

SFA103

Insert upper link spindle and inner washers.

Install inner washers with rounded edges facing inward.

Press another bushing.

Temporarily tighten nuts.

Press bushing so that the flange of bushing securely contacts the end surface of the upper link collar. FE

CL

MT

AT

TF

PD)

FΑ

RA

BR


ST


RS

BT

HA


IDX






Tension Rod or Compression Rod REMOVAL AND INSTALLATION


• Remove fixing nuts on lower link and frame. Support lower link with jack.





Install tension rod. — 2WD —
 Make sure that the bushings and washers are installed properly.





Install compression rod. — 4WD —
 Make sure that the bushings and washers are installed properly.














Lower Link

— 2WD —

REMOVAL AND INSTALLATION

Remove torsion bar spring. Refer to REMOVAL in Torsion Bar Spring, FA-36.

Make matching mark on anchor arm and crossmember when loosening adjusting nut until there is no tension on torsion bar spring.



Refer to FRONT AXLE — Knuckle Spindle, FA-25.

Separate lower ball joint from lower link. — 4WD —

Remove front lower link fixing nut.

Remove bushing of lower link spindle from frame with suitable

When installing, apply soapy water to bushing.

After installing lower link, adjust wheel alignment and vehicle height. Refer to FA-8.

INSPECTION

Lower link and lower link spindle

Check for deformation and cracks. Replace if necessary. Lower link bushing

Check for distortion and damage. Replace if necessary.

@[

MA

LC

EC

FE

CL

MIT

AT

TF

PD

FA

BA

BR

ST


RS

BT

HA

EL

815



Upper Ball Joint and Lower Ball Joint REMOVAL AND INSTALLATION

Separate knuckle spindle from upper and lower links.
 Refer to FRONT AXLE — Knuckle Spindle, FA-25.

INSPECTION

Check ball joint for vertical end play "A".

Upper ball joint:

0.1 - 1.4 mm (0.004 - 0.055 in)

Lower ball joint:

2WD

0.1 - 1.3 mm (0.004 - 0.051 in)

4WD

0.7 mm (0.028 in) or less

Replace ball joint if movement is beyond specifications.

Check dust cover for damage.
 Replace dust cover and dust cover clamp if necessary.

General Specifications

TORSION BAR SPRING

Applied model	2WD	4WD	_
Spring diameter x length mm (in)	22.6 x 885 (0.890 x 34.84)	26.0 x 1,205 (1.024 x 47.44)	_
Spring constant N/mm (kg/mm, lb/in)	16.5 (1.68, 94.1)	25.7 (2.62, 146.7)	_

SHOCK ABSORBER

Applied model		2WD		41	4WD	
		Except Heavy duty	Heavy duty	U.S.A.	Canada	ĒC
Shock absorber type		Non-adjustable Non-adjustable				
Damping force [at 0.3 m (1.0 ft)/sec.]	N (kg, lb)					FE
Expansion		579 - 794 (59 - 81, 130 - 179)	1,089 - 1,461 (111 - 149, 245 - 329)	1,599 - 2,128 (163 - 217, 359 - 478)	1,687 - 2,236 (172 - 228, 379 - 503)	@1
Compression		216 - 333 (22 - 34, 49 - 75)	314 - 471 (32 - 48, 71 - 106)	559 - 814 (57 - 83, 126 - 183)	432 - 647 (44 - 66, 97 - 146)	- Cl

STABILIZER BAR

Applied model		2WD	4WD
Stabilizer bar diameter	mm (in)	23.0 (0.906)	26.0 (1.024)

TENSION ROD OR COMPRESSION ROD

Applied model		2WD	4WD
Rod diameter	mm (in)	22.0 (0.866)	23.5 (0.925)

DRIVE SHAFT (4WD)

	`	,	
Drive shaft joint type			^-
Final drive side		TS82F	AT
Wheel side		ZF100	
Fixed joint axial end limit	play mm (in)	1 (0.04)	TF
Diameter	mm (in)		
Wheel side (D ₁)		29.0 (1.142)	PD
Grease			
Quality		Nissan genuine grease or equivalent	FA
Capacity	g (oz)		
Final drive side		95 - 105 (3.35 - 3.70)	RA
Wheel side		135 - 145 (4.76 - 5.11)	BR
Boot length	mm (in)		rear a
Final drive side (L ₁)		95 - 97 (3.74 - 3.82)	
Wheel side (L ₂)		96 - 98 (3.78 - 3.86)	ST
Final drive side			RS T
	L	L ₁	E) t
Wheel side			HA
∠ _D ,		L ₂	EL
		SFA877A	[DX

G

MA

EM

LC

MT

FA-45 817

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

WHEEL ALIGNMENT (Unladen*1)

2WD

				ALLOWABLE LIMIT	ADJUSTING RANGE
Camber			Minimum	-0°20′ (-0.33°)	-0°05′ (-0.08°)
			Nominal	0°25′ (0.42°)	0°25′ (0.42°)
		Degree minute	Maximum	1°10′ (1.17°)	0°55′ (0.92°)
		(Decimal degree)	Left and right difference	45' (0.75	°) or tess
Caster			Minimum	-0°23' (-0.38°)	-0°08' (-0.13°)
			Nomínal	0°22' (0.37°)	0°22′ (0.37°)
		Degree minute	Maximum	1°07′ (1.12°)	0°52′ (0.87°)
		(Decimal degree)	Left and right difference	45′ (0.75	°) or less
Kingpin inclination			Minimum	8°20′ (8.33°)	8°35' (8.58°)
		Degree minute	Nominal	9°05′ (9.08°)	9°05' (9.08°)
		(Decimal degree)	Maximum	9°50′ (9.83°)	9°35' (9.58°)
Total toe-in			Minimum	1 (0.04)	2 (0.08)
Distance (A	- R)		Nominal	3 (0.12)	3 (0.12)
Distance (A - B)		mm (in)	Maximum	5 (0.20)	4 (0.16)
<u> </u>			Minimum	5' (0.08°)	10′ (0.17°)
Angle (left plus right)		Degree minute (Decimal degree)	Nominal	15' (0.25°)	15' (0.25°)
			Maximum	25′ (0.42°)	20′ (0.33°)
Wheel turning angle			Minimum	34°00′ (34.00°)	36°00′ (36.00°)
	Inside		Nominal	38°00′ (38.00°)	38°00′ (38.00°)
F. II + + 0		Degree minute (Decimal degree)	Maximum	38°00′ (38.00°)	38°00′ (38.00°)
Full turn*2	Outside		Minimum	31°00' (31.00°)	33°00′ (33.00°)
		Degree minute	Nominal	35°00' (35.00°)	35°00′ (35.00°)
		(Decimal degree)	Maximum	35°00′ (35.00°)	35°00′ (35.00°)
Vehicle posture					-
Lower arm p	pivot height (H)		mm (in)	108 - 118 (4.25 - 4.65)	111 - 115 (4.37 - 4.53
				Lower li	nk spindle center

SFA709-A

^{*1:} Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.


^{*2:} On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

4WD

				ALLOWABLE LIMIT	ADJUSTING RANGE
Camber Degree minute			Minimum	-0°05' (-0.08°)	0°10′ (0.17°)
		•	Nominal	0°40′ (0.67°)	0°40′ (0.67°)
		(Decimal degree)	Maximum	1°25′ (1.42°)	1°10′ (1.17°)
			Left and right difference	4 5′ (0.75	°) or less
Caster			Minimum	0°33′ (0.55°)	0°48′ (0.80°)
		Degree minute	Nominal	1°18′ (1.30°)	1°18′ (1.30°)
		(Decimal degree)	Maximum	2°03′ (2.05°)	1°48′ (1.80°)
			Left and right difference	45' (0.75	°) or less
Kingpin inclination		- 11.0	Minimum	7°21′ (7.35°)	7°36′ (7.60°)
		Degree minute	Nominal	8°06′ (8.10°)	8°06′ (8.10°)
		(Decimal degree)	Maximum	8°51′ (8.85°)	8°36′ (8.60°)
Total toe-in			Minimum	2 (0.08)	3 (0.12)
Distance (A	- B)		Nominaf	4 (0.16)	4 (0.16)
		mm (in)	Maximum	6 (0.24)	5 (0.20)
Angle (left p	lus right)		Minimum	9′ (0.15°)	14′ (0.23°)
		Degree minute (Decimal degree)	Nominal	19′ (0.32°)	19′ (0.32°)
		, ,	Maximum	29′ (0.48°)	24' (0.40°)
Wheel turning angle	•		Minimum	31°00′ (31.00°)	33°00′ (33.00°)
	Inside		Nominal	35°00′ (35.00°)	35°00′ (35.00°)
Full turn*2		Degree minute (Decimal degree)	Maximum	35°00′ (35.00°)	35°00′ (35.00°)
Full fulfi 2	Outside		Minimum	29°00′ (29.00°)	31°00′ (31.00°)
	Degree minute		Nominal	31°00′ (31.00°)	33°00′ (33.00°)
		(Decimal degree)	Maximum	33°00′ (33.00°)	33°00′ (33.00°)
Vehicle posture					
Lower arm n	ivot height (H)		mm (in)	41 - 51 (1.61 - 2.01)	44 - 48 (1.73 - 1.89)



G!

MA

EM

LĈ

EC

72

CL

MIT

AT

TF

PD

RA

ST

RS

BT

HA

IDX

FA-47

819

^{*1:} Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

^{*2:} On power steering models, wheel turning force (at circumference of steering wheel) of 98 to 147 N (10 to 15 kg, 22 to 33 lb) with engine idle.

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd) DRIVE SHAFT (4WD)

WHEEL BEARING

2WD

Wheel bearing axial end pla	0 (0)	
Wheel bearing lock nut	-	
Tightening torque N·m (34 - 39 (3.5 - 4.0, 25 - 29)	
Return angle	degree	45° - 60°
Wheel bearing starting torqu	ne	
At wheel hub bolt With new grease seal	N (kg, lb)	9.8 - 28.4 (1.0 - 2.9, 2.2 - 6.4)
With used grease seal	N (kg, lb)	9.8 - 23.5 (1.0 - 2.4, 2.2 - 5.3)

4WD

Wr	neel bearing lock nu	t	
	Tightening torque	V·m (kg-m, ft-lb)	78 - 98 (8 - 10, 58 - 72)
	Retightening torquing wheel bearing		0.5 - 1.5 (0.05 - 0.15, 0.4 - 1.1)
	Axial end play	mm (in)	0 (0)
	Starting force at w	rheel hub bolt N (kg, lb)	А
	Turning angle	degree	15° - 30°
	Starting force at w	heel hub bolt N (kg, lb)	В
Wh	neel bearing preload	l at wheel hub N (kg, lb)	
	B A		7.06 - 20.99 (0.72 - 2.14, 1.59 - 4.72)

WHEEL RUNOUT AVERAGE*

		Steel			
Wheel type	Aluminum	15 inches	14 inches		
		15 Inches	Painted	Plated	
Radial runout limit mm (in)	0.3 (0.012)	0.8 (0.031)	0.5 (0.020)	0.6 (0.024)	
Lateral runout limit mm (in)	0.3 (0.012)	0.8 (0.031)	0.8 (0.031)	0.8 (0.031)	

^{*} Wheel runout average = (Outside runout value + Inside runout value) x 0.5

Drive shaft axial end play mm (in) 0.45 (0.0177) or less

Drive shaft end snap ring

Thickness mm (in)	Part No.
1.1 (0.043)	39253-88G10
1.3 (0.051)	39253-88G11
1.5 (0.059)	39253-88G12
1.7 (0.067)	39253-88G13
1.9 (0.075)	39253-88G14
2.1 (0.083)	39253-88G15
2.3 (0.091)	39253-88G16

UPPER BALL JOINT

Vertical end play limit "A" mm (in)	0.1 - 1.4 (0.004 - 0.055)
-------------------------------------	---------------------------

LOWER BALL JOINT

Applied model	2WD	4WD
Vertical end play limit "A" mm (in)	0.1 - 1.3 (0.004 - 0.051)	0.7 (0.028) or less

820 FA-48

REAR AXLE & REAR SUSPENSION

SECTION RA

MA

EM

LC

EC

CONTENTS

FE

CL

MT

PRECAUTIONS AND PREPARATION	2
Precautions	
Special Service Tools	2
Commercial Service Tools	2
REAR AXLE AND REAR SUSPENSION	3
ON-VEHICLE SERVICE	4
Rear Axle and Rear Suspension Parts	4
Rear Wheel Bearing	4

REAR AXLE	(C)L
Components5	(SIL
Removal5	
Inspection7	MIT
Installation7	DVI L
REAR SUSPENSION9	
Shock Absorber10	AT
Leaf Spring10	
SERVICE DATA AND SPECIFICATIONS (SDS)12	
General Specifications12	TF
Inspection and Adjustment12	
-	

PD

TF

FA

RA

BR


ST

RS

BT

AH

]DX



Precautions


- When installing rubber parts, final tightening must be carried out under unladen condition* with tires on ground.
 - *: Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Use flare nut wrench when removing or installing brake tubes.
- After installing removed suspension parts, check wheel alignment and adjust if necessary.
- Always torque brake lines when installing.

Special Service Tools


The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description			
KV40101000 (J25604-01) Axle stand	NT159	Removing rear axle shaft		
ST36230000 (J25840-A) Sliding hammer	NT126	Removing rear axle shaft		
ST38020000 (—) Bearing lock nut wrench	NT160	Removing wheel bearing lock nut		
HT72480000 (J25852-B) Rear axle shaft bearing puller	NT161	Removing wheel bearing		
ST37840000 (—) Rear axle shaft guide	NT162	Installing rear axle shaft		
Commercial Service Tools				
Tool name	Description			
Flare nut crowfoot Torque wrench		Removing and installing each brake piping		
	NT360	a: 10 mm (0.39 in)		
Rear axle oil seal drift	NT163	Installing oil seal a: 74 mm (2.91 in) dia. b: 68 mm (2.68 in) dia. c: 10 mm (0.39 in)		

2WD



4WD



RA-3

G

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD FA

RA

BR

ST


R\$

BT

HA

IDX


823




Rear Axle and Rear Suspension Parts

Check rear axle and rear suspension parts for excessive play, wear or damage.


Shake each rear wheel to check for excessive play.



Retighten all nuts and bolts to the specified torque.
 Refer to REAR SUSPENSION, RA-9.



- Check shock absorber for oil leakage or other damage.
- Check shock absorber bushing for excessive wear or other damage.




Rear Wheel Bearing


- Check that wheel bearings operate smoothly.
- Check axial end play.


Axial end play:

Refer to SDS, RA-12.

Components







Removal

Disconnect parking brake cable and brake tube.

Remove nuts securing wheel bearing cage with baffle plate.

Draw out axle shaft with Tool.

When drawing out axle shaft, be careful not to damage oil seal.

Remove oil seal.

Do not reuse oil seal once it is removed.

Always install new one.

RA

G||

KA

BR

ST

RS


BT

HA


ĒL

REAR AXLE


Removal (Cont'd)




• Unbend lock washer with a screwdriver.




Remove bearing lock nut with Tool.



 Remove wheel bearing together with bearing cage and baffle plate from axle shaft.



- Remove grease seal in bearing cage with suitable bar.
- Remove wheel bearing outer race with a brass drift.



Inspection

AXLE SHAFT

Check axle shaft for straightness, cracks, damage, wear or distortion. Replace if necessary.

١

WHEEL BEARING

Make sure wheel bearing rolls freely and is free from noise, cracks, pitting or wear.



AXLE CASE

Check axle case for yield, deformation or cracks. Replace if necessary.



Installation

滬


Install wheel bearing outer race with a brass drift.

Install a new grease seal in bearing cage.

CL

After installing new grease seal, coat sealing lip with multipurpose grease.






Install bearing spacer with chamfer side facing axle shaft flange.





FA



Install wheel bearing inner race with a brass drift.

Coat each bearing cone with multi-purpose grease.

Specified amount of grease:

8 - 12 g (0.28 - 0.42 oz)



RA

ST

RS

BT




- Install plain washer and a new wheel bearing lock washer.
- Tighten wheel bearing lock nut.


Fit wheel bearing lock washer lip in wheel bearing lock nut groove correctly by tightening lock nut. Be sure to bend it up.








REAR AXLE




Installation (Cont'd)

Install a new oil seal with suitable tool.

After installing new oil seal, coat sealing lip with multi-purpose grease.




- Apply recess of axle case end with multi-purpose grease.
- Apply gear oil to the spline of axle shaft. Coat seal surface of axle shaft with multi-purpose grease (as shown left).



- Adjust axial end play.
- a. Select end shims.

Standard thickness: 1.5 mm (0.059 in)
Axle case end shim: Refer to SDS, RA-12.

Do not insert end shims between case seal and bearing cage.



b. Insert axle shaft with Tool as a guide.

When inserting axle shaft, be careful not to damage oil seal.

c. Measure end play of axle shaft.

Axial end play:

Servicing one side axle

0.02 - 0.15 mm (0.0008 - 0.0059 in)

Servicing both side axles

On first axle (right or left)


0.30 - 0.90 mm (0.0118 - 0.0354 in)

On second axle


0.02 - 0.15 mm (0.0008 - 0.0059 in)

d. If axial end play is not within the specified limit, reselect axle case end shims.


While adjusting axial end play, be careful not to damage oil seal.



2WD



4WD



RA-9

(Gil

EC

FE

CL.

MT

TF

PD)

FA


RA

RS

BT

HA

1DX




Shock Absorber

REMOVAL AND INSTALLATION

Remove shock absorber by disconnecting upper and lower end.

INSPECTION


- If oil leakage, cracks or deformation occurs, replace shock absorber assembly.
- If rubber bushings are cracked or deformed, replace rubber bushings.



Leaf Spring

REMOVAL AND INSTALLATION

Disconnect shock absorber lower end, and remove U-bolts.



Disconnect spring shackle.


REAR SUSPENSION

SRA705

Leaf Spring (Cont'd)

Disconnect front pin.






EM

MA

LC



INSPECTION

Check leaf spring for cracks. Replace if necessary.

FE

EC

Check front bracket and pin, shackle, U-bolts and spring pad for wear, cracks, straightness or damaged threads. Replace if necessary.


Check all bushings for deformation or cracks. Replace if necessary.

CL.

[4WD: Rear spring front bushing]

Make sure that front bushing is properly installed.

MT



INSTALLATION

AT

Apply soapsuds to rubber bushing.

Install spring shackle and front pin, and finger tighten the nuts. Install spring pad and nuts under leaf spring or axle case.


Tighten U-bolt mounting nuts diagonally.

Tighten U-bolts so that the lengths of all U-bolts under spring pad are the same.

FA

Install shock absorber, and finger tighten the nuts.

RA



Remove stands and bounce the vehicle to stabilize suspension. (Unladen)

38


RS

Tighten spring shackle nuts, front pin nuts and shock absorber nuts. When installing rubber parts, final tightening must be carried

HA

out under unladen condition* with tires on the ground. Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

EL



SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

LEAF SPRING AND SHOCK ABSORBER

·		21	VD		
Applied model	II C A		Canada		4WD
	U.S.A.	Regular Cab	King Cab	Option	7
eaf spring					
Spring length x width mm (in)		1,2	200 × 60 (47.24 × 2.3	36)	
Spring thickness - number of leaves mm (in)	7 (0.28) - 2 13 (0.51) - 1	'	(8) - 2 47) - 2	7 (0.28) - 2 13 (0.51) - 1	7 (0.28) - 1 8 (0.31) - 1 12 (0.47) -1 13 (0.51) - 1
Free camber "S" mm (in)	171.0 (6.73)	183.0 (7.20)	164.5 (6.48)	171.0 (6.73)	106.0 (4.17)
Shock absorber					• • •
Shock absorber type			Non-adjustable		
Maximum length mm (in)		508 (2	20.00)		528 (20.79)
Compression N (kg, lb)		157 - 275 (16	- 28, 35 - 62)		265 - 422 (27 - 43, 60 - 95
S T S	Helper spring			L	
		SRA657A			SRA658

Inspection and Adjustment

WHEEL BEARING

Total end play	mm (in)	0.02 - 0.15 (0.	0008 - 0.0059)
		Thickness mm (in)	Part number
	. [0.05 (0.0020) 0.07 (0.0028)	43086-P0110 43087-P0110
Available rear axle shims	case end	0.10 (0.0028)	43087-P0110 43088-P0110
		0.15 (0.0059)	43086-B9500
		0.20 (0.0079)	43089-P0110
		0.50 (0.0197)	43090-P0110
		1.00 (0.0394)	43036-01G00

BRAKE SYSTEM

SECTION BR

MA

EM

[LC

EC

CL

MT

AT

TF

PD)

FA

RA

CONTENTS

PRECAUTIONS AND PREPARATION	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
Commercial Service Tools	3
CHECK AND ADJUSTMENT	4
Checking Brake Fluid Level	4
Checking Brake Line	4
Changing Brake Fluid	
AIR BLEEDING	
Bleeding Procedure	
BRAKE HYDRAULIC LINE	
CONTROL VALVE	8
Proportioning Valve (4WD)	8
Load Sensing Valve (2WD)	9
BRAKE PEDAL AND BRACKET	
Adjustment	12
MASTER CYLINDER	
BRAKE BOOSTER	
On-vehicle Service	16
VACUUM HOSE	
FRONT DISC BRAKE	
Pad Replacement	
REAR DRUM BRAKE	
PARKING BRAKE CONTROL	
Adjustment	

REAR WHEEL ANTI-LOCK BRAKE SYSTEM	30
Purpose	30
Operation	30
System Description	30
System Components	31
Hydraulic Circuit	31
Removal and Installation	32
TROUBLE DIAGNOSES	33
How to Perform Trouble Diagnoses for Quick	
and Accurate Repair	33
Symptom Chart	34
Preliminary Check 1	35
Self-diagnosis	36
Component Parts and Harness Connector	
Location	37
Circuit Diagram	38
Wiring Diagram -ABS	39
Diagnostic Procedures	41
Electrical Components Inspection	49
SERVICE DATA AND SPECIFICATIONS (SDS)	50
General Specifications	50
Inspection and Adjustment	51

BR

When you read wiring diagrams:

Read GI section, "HOW TO READ WIRING DIAGRAMS".
See EL section, "POWER SUPPLY ROUTING" for power distribution circuit. When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN **ELECTRICAL INCIDENT".**



RS

BT

KA


ΞL

Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.



Brake System

- Use brake fluid DOT 3.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean master cylinder parts, disc brake caliper parts or wheel cylinder parts, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of the hydraulic system.
- Use flare nut wrench when removing and installing brake tubes.
- Always torque brake lines when installing.

WARNING:

 Clean brakes with a vacuum dust collector to minimize the hazard of airborne materials.

PRECAUTIONS AND PREPARATION

	Commercial Serv	ice Tools	Gi
Tool name	Description		- - MA
Flare nut crowfoot Torque wrench		Removing and installing each brake piping	
	NT360	a: 10 mm (0.39 in)	LC
Brake fluid pressure gauge		Measuring brake fluid pressure	EC
	NT151		- CL

BR-3 835

MT

AT

TF

PD

FA

RA


BR

ST

RS


BT

KA



Checking Brake Fluid Level

- Check fluid level in reservoir tank. It should be between Max and Min lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.
- If the brake warning lamp comes on, check brake fluid level switch and parking brake switch.




Checking Brake Line

CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

- 1. Check brake lines (tubes and hoses) for cracks, deterioration and other damage. Replace any damaged parts.
- 2. Check for oil leakage by fully depressing brake pedal while engine is running.




Changing Brake Fluid

CAUTION:

- Refill with new brake fluid DOT 3.
- Always keep fluid level higher than minimum line on reservoir tank.
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- 1. Clean inside of reservoir tank, and refill with new brake fluid.
- 2. Connect a vinyl tube to each air bleeder valve.
- 3. Drain brake fluid from each air bleeder valve by depressing brake pedal.
- 4. Refill until brake fluid comes out of each air bleeder valve. Use same procedure as in bleeding hydraulic system to refill brake fluid. Refer to "Bleeding Procedure", BR-5.

AIR BLEEDING



Bleeding Procedure

CAUTION:

Carefully monitor brake fluid level at master cylinder during bleeding operation.

 If master cylinder is suspected to have air inside, bleed air from master cylinder first. Refer to "Installation", "MAS-TER CYLINDER", BR-15.

 Fill reservoir with new brake fluid DOT 3. Make sure it is full at all times while bleeding air out of system.

 Place a container under master cylinder to avoid spillage of brake fluid.

Rear Wheel Anti-Lock Brake system:
 Before bleeding air, be sure to turn ignition switch OFF and disconnect battery ground cable and actuator connector.

Bleed air in the following order.

a. LSV air bleeder (Models equipped with LSV)

b. Left rear brake

c. Right rear brake

d. Left front brake

e. Right front brake

f. ABS actuator



Fully depress brake pedal several times.

With brake pedal depressed, open air bleeder valve to release air.


4. Close air bleeder valve.

Release brake pedal slowly.

6. Repeat steps 2 through 5 until clear brake fluid comes out of air bleeder valve.

7. Tighten air bleeder to the specified torque.

P: 7 - 9 N·m (0.7 - 0.9 kg-m, 61 - 78 in-lb)



RA

FA

G

国网

EC

Æ

CL.

MT

AT

TF

BR


ψ.u


RS

BT

HA


EL





BR-6

BRAKE HYDRAULIC LINE



REMOVAL

CAUTION:

 Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

n MA

 All hoses must be free from excessive bending, twisting and pulling.

æри

GI

Connect vinyl tube to air bleeder valve.

Drain brake fluid from each air bleeder valve by depressing brake pedal.

g LC

Remove flare nut connecting brake tube and hose, then withdraw lock spring.

EC


Cover openings to prevent entrance of dirt whenever disconnecting brake line.

INSPECTION

Check brake lines (tubes and hoses) for cracks, deterioration and other damage. Replace any damaged parts.

MT

CL



INSTALLATION

CAUTION:

Refill with new brake fluid DOT 3.

TF

PD

AT

Never reuse drained brake fluid.

Flare nut:

(1.5 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

Connecting bolt:

(1.7 - 19 N·m (1.7 - 2.0 kg-m, 12 - 14 ft-lb)

2. Refill until new brake fluid comes out of each air bleeder valve.

FA

3. Bleed air. Refer to "Bleeding Procedure", BR-5.

Tighten all flare nuts and connecting bolts.

RA

BR


ST


RS


BT

HA

10X







Proportioning Valve (4WD) INSPECTION

CAUTION:

- Carefully monitor brake fluid level at master cylinder.
- Use new brake fluid DOT 3.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on paint areas, wash it away with water immediately.
- Depress pedal slowly when raising front brake pressure.
- Check rear brake pressure 2 seconds after front brake pressure reaches specified value.
- Disconnect ABS harness connectors from ABS actuator relay box before checking.
- Connect Tool to air bleeders of front and rear brakes on either LH or RH side.
- 2. Bleed air from the Tool.
- 3. Check fluid pressure by depressing brake pedal.

Unit: kPa (kg/cm², psi)

Wheelbase	Standard	Long
Applied pressure (Front brake) D ₁	5,884 (60, 853)	6,375 (65, 924)
Output pressure (Rear brake) D ₂	2,942 - 3,334 (30 - 34, 427 - 483)	3,432 - 3,825 (35 - 39, 498 - 555)


If output pressure is out of specifications, replace master cylinder assembly (built-in type).

4. Bleed air after disconnecting the Tool. Refer to "Bleeding Procedure", BR-5.

REMOVAL AND INSTALLATION (Built-in type)

- Always replace proportioning valve and master cylinder as an assembly.
- Refer to "Removal", "MASTER CYLINDER", BR-13.

Load Sensing Valve (2WD)



REMOVAL AND INSTALLATION CAUTION:

- Refill with new brake fluid DOT 3.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- 1. Replace damaged load sensing valve linkage as an assembly.
- 2. When disassembling, apply multi-purpose grease to linkage.
- 3. Tighten all flare nuts and bolts.
 - (1.5 1.8 kg-m, 11 13 ft-lb)
- 4. Bleed air. Refer to "Bleeding Procedure", BR-5.

GI

MA

EM

LC

EC

CL

....

MIT

AT

TF

PD

FA

BR

RA

ST


RS

BT

HA

EL

CONTROL VALVE




Load Sensing Valve (2WD) (Cont'd) INSPECTION

- 1. Ensure vehicle is unladen condition*.
 - * Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.
- Have a driver sit in the driver's seat and one person sit on the rear of the vehicle. Then have the person on the rear of the vehicle slowly get off. This is necessary to stabilize suspension deflection.
- 3. Adjust length "L" as follows:
- a. Loosen stopper bolt locknut.
- Pull lever against stopper bolt and adjust by turning stopper bolt.
- c. Tighten stopper bolt locknut.


Length "L":

Approx. 189 mm (7.44 in)



- 4. Install pressure gauge to front and rear brake.
- 5. Bleed air from the Tool.
- Raise front brake pressure to 5,884 kPa (60 kg/cm², 853 psi) and 9,807 kPa (100 kg/cm², 1,422 psi) and check rear brake pressure.

Rear brake pressure: Refer to table below.





 Set down weight slowly over axle center so that sensor spring length becomes the same as when in loaded condition (refer to table below). Check rear brake pressure in the same way described in step 6.

Unit: kPa (kg/cm², psi)

	U.S.A.	Canada
Without weight	2,942 - 3,727 (30 - 38, 427 - 540)	2,942 - 3,727 (30 - 38, 427 - 540)
With weight	3,432 - 4,805 (35 - 49, 498 - 697)	3,334 - 4,707 (34 - 48, 483 - 683)

Removal and Installation





Inspection

Check brake pedal for following items:

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion
- Crack or deformation of clevis pin stopper

 $\mathbb{R}\mathbb{A}$

G[

BR


ST

RS

BT

MA

BR-11 843



Adjustment

Check brake pedal free height from melt sheet.

H: Free height Refer to SDS BR-51.

D: Depressed height Refer to SDS BR-51.


Under force of 490 N (50 kg, 110 lb) with engine running

C₁: Clearance between pedal stopper and threaded end of stop lamp switch 0.3 - 1.0 mm (0.012 - 0.039 in)

C₂: Clearance between pedal stopper and threaded end of ASCD switch 0.3 - 1.0 mm (0.012 - 0.039 in)

A: Pedal free play at clevis


1 - 3 mm (0.04 - 0.12 in)



If necessary, adjust brake pedal free height.

- Loosen lock nut and adjust pedal free height by turning brake booster input rod. Then tighten lock nut.
- Make sure that the tip of input rod stays inside.

- Loosen lock nut and adjust clearance "C₁" and "C₂" with stop lamp switch and ASCD brake switch respectively. Then tighten lock nuts.
- Check pedal free play.
- Make sure that stop lamps are off when pedal is released.
- Check depressed height of brake pedal while engine is running. If lower than specification, check for leaks, air in system and damage to components (master cylinder, wheel cylinder, etc.).



Removal

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- In the case of brake fluid leakage from the master cylinder, disassemble the cylinder. Then check piston cups for deformation and scratches and replace necessary parts.
- Connect a vinyl tube to air bleeder valve.
- Drain brake fluid from each air bleeder valve, depressing brake pedal to empty fluid from master cylinder.
- 3. Remove brake pipe flare nuts.
- 4. Remove master cylinder mounting nuts.

EL,

HA


RS

BT

IDX


מאשוו

BR-13



Disassembly


1. Bend claws of stopper cap outward.



- 2. Remove piston assemblies.
- If it is difficult to remove secondary piston assembly, gradually apply compressed air through fluid outlet.
- 3. Draw out reservoir tank.


Inspection

Check master cylinder inner wall for pin holes and scratches. Replace if damaged.




Assembly

- Insert secondary piston assembly. Then insert primary piston assembly.
- Pay attention to direction of piston cups in figure at left.
 Also, insert pistons squarely to avoid scratches on cylinder bore.



- 2. Install stopper cap.
- Before installing stopper cap, ensure that claws are bent inward.
- 3. Push reservoir tank seals into cylinder body.
- 4. Push reservoir tank into cylinder body.

MASTER CYLINDER



Installation

CAUTION:

- Refill with new brake fluid DOT 3.
- Never reuse drained brake fluid.
- Place master cylinder onto brake booster and secure mounting nuts lightly.
- 2. Tighten mounting nuts.

Fill up reservoir tank with new brake fluid.

- 3. Fill up reservoir tank with new brake fluid.4. Plug all ports on master cylinder with fingers to prevent air suction while releasing brake pedal.
- 5. Have driver depress brake pedal slowly several times until no air comes out of master cylinder.
- 6. Fit brake lines to master cylinder.
- 7. Tighten flare nuts.

[V]: 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

 Bleed air from brake system. Refer to "Bleeding Procedure", BR-5

CL

FE

(G)

MA

LC

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST


R\$

BT

HA


EL

BR-15 847




On-vehicle Service OPERATING CHECK

- Depress brake pedal several times with engine off. After exhausting vacuum, make sure there is no change in pedal
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.



AIRTIGHT CHECK


- Start engine, and stop it after one or two minutes. Depress brake pedal several times slowly. Booster is airtight if pedal stroke is less each time.
- Depress brake pedal while engine is running, and stop engine with pedal depressed. The pedal position should not change after holding pedal down for 30 seconds.



Removal

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- Be careful not to deform or bend brake pipes during removal of booster.



Inspection

OUTPUT ROD LENGTH CHECK

- 1. Apply vacuum of -66.7 kPa (-500 mmHg, -19.69 inHg) to brake booster with a hand vacuum pump.
- 2. Check output rod length.

Specified length:

10.275 - 10.525 mm (0.4045 - 0.4144 in)


BR-16

BRAKE BOOSTER


Installation


CAUTION:

- Be careful not to deform or bend brake pipes during installation of booster.
- Replace clevis pin if damaged.
- Refill with new brake fluid DOT 3.
- Never reuse drained brake fluid.
- Take care not to damage brake booster mounting bolt thread when installing. Due to the narrow angle of installation, the threads can be damaged by the dash panel.



- Fit booster, then secure mounting nuts (brake pedal bracket to brake booster) lightly.
- 3. Connect brake pedal and booster input rod with clevis pin.
- 4. Secure mounting nuts. (1.3 - 16 N·m (1.3 - 1.6 kg-m, 9 - 12 ft-lb)
- Install master cylinder. Refer to "Installation", "MASTER CYLINDER", BR-15.
- 6. Adjust brake pedal height and free play. Refer to BR-12.
- Secure lock nut for clevis. 7. (1.6 - 22 N·m (1.6 - 2.2 kg-m, 12 - 16 ft-lb)
- Bleed air. Refer to "Bleeding Procedure", BR-5.





2WD: Approx. 160 mm (6.30 in)

TF

AT

(G)

MA

LC

FE

CL

MT

FA

RA


BR


RS

87

HA

||D)X(





Removal and Installation

CAUTION:

When installing vacuum hoses, pay attention to the following points.


- Do not apply any oil or lubricants to vacuum hose and check valve.
- Insert vacuum tube into vacuum hose as shown.

• Install check valve, paying attention to its direction.

Inspection

HOSES AND CONNECTORS

Check vacuum lines, connections and check valve for airtightness, improper attachment chafing and deterioration.



CHECK VALVE

Check vacuum with a vacuum pump.

Connect to booster side	Vacuum should exist.
Connect to engine side	Vacuum should not exist.

Pad Replacement

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne materials.

GI

CAUTION:

When cylinder body is open, do not depress brake pedal or caliper piston will pop out.

Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.

If shims are rusted or show peeling of the rubber coat, replace them with new shims.

It is only necessary to remove connecting bolt if disassembling or replacing caliper assembly. Otherwise, suspend cylinder body with wire so as not to stretch brake hose.




LC

FE

CL.

MIT

AT



Remove master cylinder reservoir cap.

Remove lower pin bolt.


TF

PD

FA

 $\mathbb{R}\mathbb{A}$

Open cylinder body upward. Then remove pad retainers and inner and outer shims.



CL28VA model

11 mm (0.44 in)

CL28VD model

10 mm (0.39 in)

Pad wear limit:

2.0 mm (0.079 in)

Carefully monitor brake fluid level because brake fluid will


return to reservoir when pushing back piston.


ST


BT


HA

EL,









Removal

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne materials.

MA

G

CAUTION:

Suspend caliper assembly with wire so as not to stretch brake

EM

Remove torque member fixing bolts and connecting bolt.

It is only necessary to remove connecting bolt if disassembling or replacing caliper assembly. Otherwise, suspend caliper assembly with wire so as not to stretch brake hose.

EC


厚邑

CL

MIT

AI

TF



Disassembly

WARNING:

Do not place your fingers in front of piston.

CAUTION:

- Do not scratch or score cylinder wall.
- CL28VD type front disc brake uses plastic pistons, handle them carefully.

Push out piston and dust cover with compressed air. For CL28VD (2-piston type), use a wooden block so that both pistons come out evenly.

RA

2. Remove piston seal with a suitable tool.

Inspection — Caliper

CYLINDER BODY

 BR

Check inside surface of cylinder for score, rust, wear, damage and presence of foreign objects. If any of the above conditions are observed, replace cylinder body.

Minor damage from rust or foreign objects may be eliminated by polishing the surface with a fine emery sandpaper. Replace cylinder body if necessary.

ST RS

CAUTION:

Use brake fluid to clean. Never use mineral oil.

M

PISTON


– for steel piston (CL28VA) —

Check piston for score, rust, wear, damage and presence of foreign objects. Replace if any of these conditions are observed.

Piston sliding surface is plated. Do not polish with emery sandpaper even if rust or foreign objects are stuck to sliding surface.

for plastic piston (CL28VD) —


Check pistons for uneven surface, chips and cracks. Replace if any of these conditions are observed.





BR-21


Inspection — Caliper (Cont'd) SLIDE PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks and other damage. Replace if any of these conditions are observed.









Inspection — Rotor

RUNOUT

- 1. Check runout using a dial indicator.
- Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to FA section ("Front Wheel Bearing", "ON-VEHICLE SERVICE").

Maximum runout:

0.07 mm (0.0028 in)

 If the runout is out of specification, machine rotor with on-car brake lathe ("MAD, DL-8700", "AMMCO 700 and 705" or equivalent).

THICKNESS

Thickness variation (At least 8 positions): Maximum 0.02 mm (0.0008 in)

If thickness variation exceeds the specification, machine rotor with on-car brake lathe.

Rotor repair limit:

CL28VA 20.0 mm (0.787 in)

CL28VD 24.0 mm (0.945 in)


Assembly

- 1. Insert piston seal into groove on cylinder body.
- With piston boot fitted to piston, insert piston boot into groove on cylinder body and install piston.
- 3. Properly secure piston boot.

CAUTION:

- Secure dust seal properly.
- Lubricate with new brake fluid before installing plastic pistons (CL28VD) into cylinder body.

FRONT DISC BRAKE



Installation

CAUTION:

- Refill with new brake fluid DOT 3.
- Never reuse drained brake fluid.
- 1. Install caliper assembly.
- 2. Install brake hose to caliper securely.
- Install all parts and secure all bolts.
- 4. Bleed air. Refer to "Bleeding Procedure", BR-5.

G[

MA

EM

LC

EC

FE

CL

MT

AT

ŢF

PD

FA

RA

BR

@57

RS


BT


HA

EL

IDX

BR-23 855





Removal

WARNING:

Clean brake lining with a vacuum dust collector to minimize the hazard of airborne materials.


MA

(GII

CAUTION:

Make sure parking brake lever is completely released.

LC



Release parking brake lever fully, then remove drum.

EC


If drum is hard to remove, the following procedures should be carried out.

Æ

Remove plug. Then shorten adjuster to make clearance between brake shoe and drum.

CL

MT



Adjuster strut

Retainer

Cable

Install two bolts as shown. Tighten the two bolts gradually.

TF

PD

FA

RA

After removing retainer, remove spring by rotating shoes. Be careful not to damage wheel cylinder piston boots.

Be careful not to damage parking brake cable when separating it.


BRST

3. Remove adjuster.

Disconnect parking brake cable from toggle lever.

RS


BT



Remove retainer clip with a suitable tool. Then separate toggle lever and brake shoe.


HA

IDX




Inspection — Wheel Cylinder

- Check wheel cylinder for leakage.
- Check for wear, damage and loose conditions.
 Replace if any such conditions exists.



Wheel Cylinder Overhaul


- Check all internal parts for wear, rust and damage. Replace if necessary.
- Pay attention not to scratch cylinder when installing pistons.



Inspection — Drum

Maximum inner diameter (Repair limit): LT26B 261.5 mm (10.30 in) LT30A 296.5 mm (11.67 in)

- Contact surface should be finished with No. 120 to 150 emery sandpaper.
- Using a brake lathe, machine brake drum if it shows score marks, partial wear or stepped wear.
- After brake drum has been completely reconditioned or replaced, check drum and shoes for proper contact pattern.



Inspection — Lining

Check lining thickness.

Standard lining thickness:


LT26B 5.5 mm (0.217 in)

LT30A 6.1 mm (0.240 in)

Lining wear limit (A):

LT26B 1.5 mm (0.059 in)

LT30A 1.5 mm (0.059 in)





Installation

- Always perform shoe clearance adjustment. Refer to BR-29.
- 1. Fit toggle lever to brake shoe with retainer clip.
- 2. Apply brake grease to the contact areas shown at left.

REAR DRUM BRAKE

: Should be lubricated with grease ABR396





Installation (Cont'd)

Shorten adjuster by rotating it.

Pay attention to direction of adjuster.

Wheel	Screw
Left	Left-hand thread
Right	Right-hand thread

- Connect parking brake cable to toggle lever.
- 5. Install all parts.
- Be careful not to damage wheel cylinder piston boots.
 - Check that all parts are installed properly.
- After installation is completed, adjust shoe-to-drum clearance.
- Install brake drum.
- When installing new wheel cylinder or overhauling wheel cylinder, bleed air. Refer to "Bleeding Procedure", BR-5.
- Adjust parking brake. Refer to BR-29.
- Install all the parts by referring to the figure below.

LT30A model

After installing crank lever on back plate, make sure that there is no play between crank lever and back plate. If play exists, adjust bolt (A) and lock nut (B).

LT30A LT26B LH wheel SBR100CA FE

EC

GI

MA

LC

CL

MT AT

TF

PD)

FA

RA

BR

ST

RS


BT


HA

ᇍ

IDX

2WD





PARKING BRAKE CONTROL

Removal and Installation

Be careful not to damage cable.

Make sure there is no free play after installation.

Inspection

Check control lever for wear and damage. Replace if neces-

Check wires for discontinuity and deterioration. Replace if necessary.

Check warning lamp and switch. Correct if necessary.

4. Check part at each connecting portion and, if found deformed or damaged, replace.

Adjustment

Adjust parking brake as follows:

— LT26B —

Pull parking brake lever several times until clicking sound does not occur from rear brakes.

2. Release parking brake lever.

3. Loosen lock nut (A), rotate adjusting nut (B).

4. Tighten lock nut (A).


Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.


Number of notches: Refer to SDS, BR-51

— LT30A —

- Release parking brake lever.
- Depress brake pedal fully at least 10 times.
- 3. Loosen lock nut (A), rotate adjuster (B).
- 4. Tighten lock nut (A).
- Pull control lever with specified amount of force. Check lever









stroke and ensure smooth operation.

Number of notches: Refer to SDS, BR-51.



LT30A(4WD)





RA

GI.

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD)


RS

BT

HA

[D)X

BR-29 861



Purpose

The Rear Wheel Anti-Lock Brake System (ABS) consists of electronic and hydraulic components. It controls rear braking force so locking of the rear wheels can be avoided. The ABS:


- 1) Improves proper tracking performance during severe braking.
- Eases obstacle avoidance during severe braking.
- 3) Improves vehicle stability.

Operation

- When the vehicle speed is less than 10 km/h (6 MPH) this system does not work.
- The Rear Wheel Anti-Lock Brake System (ABS) has self-test capabilities. The system turns on the ABS warning lamp for a few seconds each time the ignition switch is turned ON. After the engine is started, the ABS warning lamp turns off. The system performs a circuit check when the ignition switch is first turned ON. If a malfunction is found during this check, the ABS warning lamp will stay on.
- While driving, a mechanical noise may be heard and slight pedal pulsation may be felt during ABS operation. This is a normal condition.

CAUTION:


When driving in 4WD, the rear wheel anti-lock brake system is not effective in most cases. The rear wheels will lock if the front wheels lock because the transfer mechanically couples the front and rear axles together. If this happens, the rear wheel anti-lock brake system may not function but the ordinary brakes will operate normally. The ABS warning lamp will then turn on. The above condition is not a malfunction and the rear wheel anti-lock brake system can be re-activated by starting the engine again. The ABS warning lamp will then go off.



System Description


REAR SENSOR

The rear sensor unit consists of a gear-shaped sensor rotor and a sensor unit. The sensor unit consists of a bar magnet around which a coil is wound. The sensor rotor is installed on the companion flange and the sensor unit is installed on the rear axle housing. A sine-wave current is generated by the rear sensor unit as the rear axle pinion rotates. The frequency and voltage increase as the rotating speed increases.



ABS CONTROL UNIT


The ABS control unit computes the rear axle pinion rotating speed by reading the signal from the rear sensor unit. Then it supplies a DC current to the ABS actuator. If any electrical malfunction is detected in the system, the ABS control unit causes the ABS warning lamp to turn on. In this condition, the ABS system will be deactivated by the ABS control unit, and the vehicle's brake system reverts to normal operation.




862 BR-30

REAR WHEEL ANTI-LOCK BRAKE SYSTEM

System Components



Hydraulic Circuit



BR-31 863

MA

GI

nous-y

EM LC

EC

FĘ

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

TE

HA

El


IDX


Removal and Installation

CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth. In case the final drive assembly needs to be removed, disconnect the ABS sensor from the assembly and move it away. Failure to do so may result in damage to the sensor wires making the sensor inoperative.

REAR SENSOR AND CONTROL UNIT





ACTUATOR

Removal

- Disconnect battery cable.
- Drain brake fluid. Refer to "Changing Brake Fluid", "CHECK AND ADJUSTMENT", BD.4
- 3. Disconnect connectors, brake pipes and remove fixing nuts.


Installation

CAUTION:

After installation, refill brake fluid. Then bleed air. Refer to "Bleeding Procedure", BR-5.


- 1. Connect brake pipes temporarily.
- 2. Secure fixing bolts.
- 3. Torque brake pipe flare nuts.
- Connect connectors and battery cable.

BR-32



Symptom Chart

PROCEDURE	Preliminary Check	ıinary ∋ck			gnostic F	Diagnostic Procedure				ielect ins	Diagnostic Procedure spection with LED flas	tic Proce	Diagnostic Procedure (Select inspection with LED flashing No.)	ng No.)		Electrical Components Inspection
REFERENCE PAGE	BR-35	BR-35	BR-41	BR-41	BR-41	BR-42	BR-43	BR-44	BR-45	BR-45	BR-46	BR-47	BR-47	BR-47	BR-48	BR-49
	Preliminary Check 1	Preliminary Check 2	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Warning flashing 2 or 7	Warning flashing 4	Warning flashing 3 or 8	Warning flashing 9 or 10	Warning flashing 6	Warning flashing 13,14 or 15	Warning flashing 5	Rear sensor unit and ABS actuator
Pedal vibration or noise.			0						0	0	0	0	0	0	0	
Long stopping distance.				0					0	0	0	0	0	0	0	
Brake pedal stroke is large.					0				0	0	0	0	0	0	0	
ABS does not work.	0	0				0		0	0	0	0	0	0	0	0	0
ABS works frequently.							0								0	



TROUBLE DIAGNOSES

Self-diagnosis

CHECKING THE NUMBER OF WARNING LAMP FLASHES

When a problem occurs in the ABS, the ABS warning lamp on the instrument panel turns on. As shown in the table, the control unit performs self-diagnosis.

To obtain satisfactory self-diagnosing results, the vehicle must be driven in 2WD above 40 km/h (25 MPH) for at least one minute before the self-diagnosis is performed. After the vehicle has been stopped, the number of ABS warning lamp flashes is counted by grounding the check terminal, with the engine running, thereby identifying a malfunctioning part or unit by the number of flashes.

If more than two parts or units malfunction at the same time, the ABS warning lamp will flash to indicate one of the malfunctioning parts or units. After the part or unit has been repaired, the ABS warning lamp will then flash to indicate that the other part or unit is malfunctioning.

No. of warning lamp flashes	Detected items	Malfunctioning cause or part		Diagnostic Procedure
2			Open	Diagnostic Procedure 7
7	ABS actuator	ISO solenoid DUMP solenoid	Short circuit	Diagnostic Procedure 7
4			Bull Bull	Blocked
3				Open
8			Short circuit	Diagnostic Procedure 9
9		Op	en	Diagnostic Procedure 10
10	Rear sensor	Short circuit Erratic		Diagnostic Procedure 10
6				Diagnostic Procedure 11
13, 14 or 15	ABS control unit			Diagnostic Procedure 12
5	Other		Diagnostic Procedure 13	

CAUTION:

When driving in 4WD, the rear wheel anti-lock brake system is not effective in most cases. The rear wheels will lock if the front wheels lock because the transfer mechanically couples the front and rear axles together. If this happens, the rear wheel anti-lock brake system may not function but the ordinary brakes will operate normally. The ABS warning lamp will then turn on. The above condition is not a malfunction and the rear wheel anti-lock brake system can be re-activated by starting the engine again. The ABS warning lamp will then go off.

Component Parts and Harness Connector Location Stoplamp switch Warning lamp ABS control unit -Rear sensor -ABS actuator Under driver's seat M176 ABS control unit connector Rear sensor unit -Rear sensor unit connector (C5) ©3 ABS actuator connector ABS actuator

ABR402

Œ[

MM

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

RS


BT

KA

IDX

Second crossmember


Circuit Diagram




Œ[Wiring Diagram -ABS-**BR-ABS-01** IGNITION SWITCH BATTERY MA ON or START M143 M146 W/L (PW): With power windows EM Refer to "EL-POWER". 10A 20A 19 To EL-WINDOW ■ W ■ PW 16 LC R/B STOP 5 7 EC IGNITION-2 SWITCH RELEASED AND POWER WINDOW RELAY (M138) DEPRESSED (M148) 厖 6 2 G/Y ÇL **◆** W/G **▼**PW To EL- WINDOW G/Y ■ A Next page MT B/G G/Y AT B/G 3 12 8 ABS CONTROL UNIT IGN IGN STOP LAMP SW TF ISOLATION SOLENOID BRAKE FLUID SW DUMP (M176) DUMP ACTUATOR SOLENOID(+) (+) 17 4 6 PD GY/R LG/R W/G 10 LG/R 11 12 9 (01)FA w/G GY/R В 1 3 2 4 1 ABS ACTUATOR BRAKE $\mathbb{R}\mathbb{A}$ FLUID LEVEL SWITCH DUMP DUMP **ISOLATION** \bigcirc SWITCH SWITCH SOLENOID SOLENOID (M59) BR) ■ B ■ |-**■** B ■ ST DIODE (M156) 8 BR/Y BR/Y BNext page (M177) (M49) (M105) (M160) RS BT 1 W146 W HA 1 2 3 4 D 5 6 7 8 M176 ĒL IDX

ABR485

Wiring Diagram -ABS- (Cont'd)




TROUBLE DIAGNOSES




BR-41 873

Diagnostic Procedure 4

SYMPTOM: ABS does not work.



TROUBLE DIAGNOSES



BR

TF

PD)

FA

 $\mathbb{R}\mathbb{A}$


RS


BT


HA


 $\mathbb{D}\mathbb{X}$


BR-43 875











Diagnostic Procedure 6

MAIN POWER SUPPLY AND GROUND CIRCUIT (Not self-diagnostic item)

No

No



Yes

CHECK GROUND CIR-CUIT. Check harness continuity, between ABS control unit terminal (1) and suitable body ground. Continuity should exist. ŲNG OK

Check and replace fuse, warning lamp or relays if necessary. Repair ignition harness, relay and warning lamp connectors.

Repair har-

connectors.

ness or

CHECK ABS RELAY POWER SUPPLY.

1. Turn ignition switch ON.

2. Do approx. 12 volts exist between ABS control unit connector terminals (12), (3) and (11)?

Yes

Check and replace fuse, ABS relay, or repair harness and connectors.

D **CHECK STOP LAMP SWITCH POWER** SUPPLY.

1. Depress brake pedal.

2. Do approx. 12 volts exist between ABS control unit connector terminals (8) and (11)?

Adjust stop lamp switch if necessary. Replace stop lamp switch, if necessary or repair harness or connec-

CHECK PARKING BRAKE POWER SUP-


Yes


1. Confirm that brake fluid level is adequate.


If necessary, refill it. 2. Turn ignition switch ON.

3. Do approx. 12 volts exist between ABS control unit connector terminals (5) and (11) without parking brake applied? Do approx. 0 volts exist with parking brake applied?

Adjust parking brake switch, if necessary. Replace parking brake switch, if necessary or repair harness or connector.











Diagnostic Procedure 13


Other (Warning lamp flashing 5)














Electrical Components Inspection REAR SENSOR UNIT AND ACTUATOR

NG CHECK REAR SENSOR SIGNAL. 1. Raise vehicle. Confirm it is safe to rotate rear wheels. 2. Start engine and rotate rear wheels with transmission in D position or first gear position. Check rear sensor signal voltage between control unit terminals 10 and 9 with AC voltmeter. Voltage: 0.4V or more M/T at 700 rpm A/T at 850 rpm OK В

CHECK ABS ACTUATOR OPERATION. Go to Preliminary Check 2, BR-35. Clicking noise sounds from actuator, when the ignition switch is turned on with battery cable connected.


OK

CHECK ABS OPERATION as follows: 1. Perform ABS check in a safe place without obstacles in the vicinity.

2. Drive the vehicle for more than one minute at speeds over 40 km/h (25 MPH) in the 2WD mode, then check that the warning lamp does not light on the instrument panel. After this, check for operation.

3. Check if ordinary braking effect occurs. and also check that the rear wheels do not lock when abrupt braking causes the front wheels lock.

Į oĸ ⊥NG Replace ABS ABS is good condition. actuator.



CHECK PULSING VOLT-AGE FROM ABS CON-TROL UNIT.

Check pulsing voltage for ISO and DUMP solenoid between ABS control unit terminals (17) and (11), and terminals (1) and (11) Voltage: 0.3 - 3.5V for

approx. 13 msec. Use suitable digital voltmeter. Pulsing voltage appears when ABS warning lamp goes off after ignition is turned on.

Replace ABS control unit.

↓NG

Replace ABS actuator

Loĸ

 BR

(H

MA

LC

EC

FE

ĈL.

MT

AT

TF

PD)

FA


RA

RS

BT

HA

 $\mathbb{R}^{\mathbb{N}}$



SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Applied model		2WD	4WD		
		2440	Standard wheelbase Long wheelb		
Front brake					
Brake model		CL28VA	CL2	8VD	
Cylinder bore diameter x number of pisto	ns mm (in)	60.6 (2.386) x 1	42.8 (1.685) x 2		
Pad length x width x thickness	mm (in)	IN: 126.5 x 43 x 11 (4.98 x 1.69 x 0.43)	146.6 x 48.5 x 10 (5.77 x 1.909 x 0.39)	
		OUT: 129 x 43 x 11 (5.08 x 1.69 x 0.43)	, Y	, 	
Rotor outer diameter x thickness	mm (in)	250 x 22 (9.84 x 0.87)	277 x 26 (10.9 x 1.02)		
Rear brake					
Brake model		LT26B	LT30A		
Cylinder bore diameter	mm (in)	22.22 (7/8)	20.64 (13/16)		
Lining length x width x thickness	mm (in)	249.6 x 50 x 5.5 (9.83 x 1.97 x 0.217)	296 x 50 x 6.1 (11.65 x 1.97 x 0.240)		
Drum inner diameter	mm (in)	260.0 (10.24)	295.0	(11.61)	
Master cylinder	}				
Bore diameter	mm (in)		25.40 (1)		
Control valve					
Valve model		Linkage type load sensing valve	Proportioning valve within master cylinder		
Split point [kPa (kg/cm², psi)] x reducing i	ratio	(Variable) x 0.23	2,452 (25, 356) x 0.2	2,942 (30, 427) x 0.2	
Brake booster					
Booster model		M195T	M2 ⁻	15T	
Diaphragm diameter	mm (in)	Pri.: 205 (8.07) Sec.: 180 (7.09)	Pri.: 230 (9.06) Sec.: 205 (8.07)		
Recommended brake fluid			DOT 3		

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

GI

DISC BRAKE

		Unit: mm (in)
Brake model	CL28VA	CL28VD
Pad wear limit		
Minimum thickness	ness 2.0 (0.079)	
Rotor repair limit		
Minimum thickness	20.0 (0.787)	24.0 (0.945)

DRUM BRAKE

		Unit: mm (in)	
Brake model	LT26B	LT30A	
Lining wear limit			
Minimum thickness	1.5 (0.059)		
Drum repair limit			
Maximum inner diameter	261.5 (10.30)	296.5 (11.67)	
Out-of-round limit 0.15 (0.0059)		0.0059)	

BRAKE PEDAL

	Unit: mm (in)	M
Free height "H"*		
M/T	209 - 219 (8.23 - 8.62)	EN
A/T	212 - 222 (8.35 - 8.74)	
Depressed height "D" [under force of 490 N (50 kg, 110 lb) with engine run- ning]	120.0 (4.72)	LC
Clearance "C" between pedal stopper and threaded end of stop lamp switch or ASCD switch	0.3 - 1.0 (0.012 - 0.039)	
Pedal free play		n (
At clevis	1.0 - 3.0 (0.039 - 0.118)	
At pedal pad	4 - 12 (0.16 - 0.47)	C

^{*:} Measured from surface of melt sheet to pedal pad.

PARKING BRAKE CONTROL

Control type	Stick lever
Lever stroke [under force of 196 N (20 kg, 44 lb)]	10 - 12
Lever stroke when warning switch comes on	1

PD

TF

MT

AT

FA

 $\mathbb{R}\mathbb{A}$

\$T

R\$

BT

HA

EL

 $\mathbb{D}\mathbb{X}$

STEERING SYSTEM

SECTION ST



MA

LC

CONTENTS

PRECAUTIONS AND PREPARATION	2
Supplemental Restraint System (SRS) "AIR BAG"	,
Steering System	2
Special Service Tools	
Commercial Service Tool	
ON-VEHICLE SERVICE	
Steering System	
Checking and Adjusting Drive Belts (For power	
steering)	
Checking Fluid Level	
Checking Fluid Leakage	
Bleeding Hydraulic System	
Checking Steering Wheel Turning Force (For	
power steering)	7
Checking Steering Wheel Play	
Checking Neutral Position on Steering Wheel	
Checking Front Wheel Turning Angle	
Checking Hydraulic System	
STEERING WHEEL AND STEERING COLUMN	
Steering Wheel	
Steering Column	
Disassembly and Assembly	
Inspection	
MANUAL STEERING GEAR (Model: VB66K)	
Removal and Installation	
Disassembly	
Assembly and Adjustment	
Inercetion	1Ω

POWER STEERING SYSTEM (Model: PB59K)	20
Description	20
POWER STEERING GEAR (Model: PB59K)	
Removal and Installing	21
Power Steering Gear Component	21
Pre-disassembly Inspection and Adjustment	
Disassembly	
Assembly	24
POWER STEERING SYSTEM (Model: PB48S)	27
Description	27
POWER STEERING GEAR (Model: PB48S)	28
Removal and Installing	
Power Steering Gear Component	28
Pre-disassembly Inspection and Adjustment	29
Disassembly	
Assembly	32
POWER STEERING OIL PUMP	35
Disassembly and Assembly	35
Pre-disassembly Inspection	35
Inspection	36
Disassembly	36
Assembly	37
STEERING LINKAGE	38
Removal and Installation	38
Disassembly	39
Inspection	40
SERVICE DATA AND SPECIFICATIONS (SDS)	41
General Specifications	41
Inspection and Adjustment	41



EC

FE

CL

MH

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

98

BT

HΑ

EL



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag" used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Steering System

- . Before disassembly, thoroughly clean the outside of the unit.
- Disassembly should be done in a clean work area. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- For easier and proper assembly, place disassembled parts in order on a parts rack.
- Use nylon cloths or paper towels to clean the parts; common shop rags can leave lint that might interfere with their operation.
- Before inspection or reassembly, carefully clean all parts with a general purpose, non-flammable solvent.
- Before assembly, apply a coat of recommended ATF* to hydraulic parts. Petroleum jelly may be applied to O-rings and seals. Do not use any grease.
- Replace all gaskets, seals and O-rings. Avoid damaging O-rings, seals and gaskets during installation. Perform functional tests whenever designated.
 - *: Automatic Transmission Fluid type DEXRON™ II E, DEXRON™ III, or equivalent.

886 ST-2

PRECAUTIONS AND PREPARATION

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number			Unit ap	olication	-
(Kent-Moore No.) Tool name	Description		Manual steering	Power steering	
ST27180001 (J25726-A) Steering wheel puller	9 M10 x 1.25 pitch 29 mm (1.14 in) NT544	Removing steering wheel	Х	х	-
HT72520000 J25730-B) Ball joint remover	NT546	Removing ball joint and swivel joint a: 33 mm (1.30 in) b: 50 mm (1.97 in) r: R11.5 mm (0.453 in)	X	x	- (
ST29020001 J24319-01) Steering gear arm puller	C b	Removing pitman arm a: 34 mm (1.34 in) b: 6.5 mm (0.256 in) c: 61.5 mm (2.421 in)	х	х	
V48101500 I28802) ock nut wrench	NT534	Removing and installing lock nut a: 73.1 mm (2.878 in) b: 100 mm (3.94 in) c: 12 mm (0.47 in) d: 60 mm (2.36 in) dia.	х	_	_
V48101400 J28803) djusting plug wrench	NT539	Adjusting and tightening lock nut a: 46.7 mm (1.839 in) b: 8.5 mm (0.335 in) dia. c: 7 mm (0.28 in)	x	_	
T3127S000 See J25765-A) 1 GG91030000 (J25765-A) Torque wrench 2 HT62940000 (—) Socket adapter 3 HT62900000	1/4" Torque wrench with range of 2.9 N·m (30 kg-cm, 26 in-lb)	Measuring turning torque	x	x	
(—) Socket adapter	NT541				

ST-3 887

Ġ[

PRECAUTIONS AND PREPARATION


Special Service Tools (Cont'd)

Tool number		•	Unit ap	plication
(Kent-Moore No.) Tool name	Description		Manual steering	Power steering
KV48100301 (—) Strut & steering gearbox attachment	NT543	Steering gear is installed. a: 162 mm (6.38 in) b: 110 mm (4.33 in) c: 190 mm (7.48 in) d: 9 mm (0.35 in)	x	х
ST27091000 (J26357 and J26357-10) Pressure gauge	To oil pump outlet PF3/8" (female) PF3/8" (male) NT547	Measuring oil pressure	_	×
KV481009S0 (—) Oil seal drift set (1) KV48100910 (—) Drift (2) KV48100920 (J26367) Adapter (3) KV48100930 (J26367) Adapter	3 2 0 1	Installing oil seal	_	x
KV48100700 (J26364) Torque adapter	NT169	Adjusting worm bearing pre- load	x	x

Commercial Service Tool


		Unit application	
Tool name	Description		Power steering
Boot band attachment	Installing boot band Unit: mm (in) 8 (0.31) 25 (0.98) 52 (2.05)	X	X

Steering System



Checking and Adjusting Drive Belts (For power steering)

Refer to MA section ("Checking Drive Belts", "ENGINE MAINTE-NANCE").



Checking Fluid Level

Check fluid level referring to the scale on the dipstick. Use "HOT" range for fluid temperatures of 50 to 80°C (122 to 176°F). Use "COLD" range for fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is Automatic Transmission Fluid type "DEXRON $^{\text{TM}}$ II E, DEXRON $^{\text{TM}}$ III", or equivalent.

AT

GI

MA

例

LC

EC

FE

CL

MT

PD

TF

FA


BR

RA

BT

EL

1DX



Checking Fluid Leakage

Check lines for proper attachment, leaks, cracks, damage, chafing or deterioration.

- 1. Run engine between idle speed and 1,000 rpm.
- Make sure temperature of fluid in reservoir tank rises to 60 to 80°C (140 to 176°F).
- Turn steering wheel right-to-left several times.
- 3. Hold steering wheel at each "lock" position for five seconds and carefully check for fluid leakage.

CAUTION:

Do not hold steering wheel at lock position for more than 15 seconds.

4. If fluid leakage from any line is noticed, loosen flare nut and then retighten.

Do not overtighten connector as this can damage O-ring, washer and connector.

- 5. If fluid leakage from power steering pump is noticed, check power steering pump. Refer to ST-35.
- If fluid leakage from power steering gear is noticed, check power steering gear. Refer to ST-20 (4WD models), or ST-27 (2WD models).

Bleeding Hydraulic System


- 1. Raise front end of vehicle until wheels are clear of the ground.
- Add fluid to reservoir tank to specified level. Then quickly turn steering wheel fully to right and left and lightly touch steering stoppers.

Repeat steering wheel operation until fluid level no longer decreases.

- 3. Start engine.
 - Repeat step 2 above.
- Incomplete air bleeding will cause the following to occur:
- a. Air bubbles in reservoir tank
- b. Clicking noise in power steering pump
- c. Excessive buzzing in power steering pump When this happens, bleed air again.

Fluid noise may occur in the valve or power steering pump. This is common when the vehicle is stationary or while turning the steering wheel slowly. This does not affect the performance or durability of the system.

ST-6



Checking Steering Wheel Turning Force (For power steering)

- Park vehicle on a level, dry surface and set parking brake.
- Start engine and run at idle speed or 1.000 rpm.
- Bring power steering fluid up to adequate operating temperature. [Make sure temperature of fluid is approximately 60 to 80°C (140 to 176°F).]

Tires need to be inflated to normal pressure.

Check steering wheel turning force when steering wheel has been turned 360° from neutral position.

Steering wheel turning force:


PB48S-type

24.5 - 29.4 N (2.5 - 3.0 kg, 5.5 - 6.6 lb)

PB59K-type

39 N (4 kg, 9 lb) or less

- If steering wheel turning force is out of specification, check the following:
- Hydraulic system. Refer to "Checking Hydraulic System", ST-8.
- Steering Column. Refer to ST-11.
- Front suspension and axle. Refer to FA section ("Front Axle and Front Suspension Parts", "ON-VEHICLE SERVICE").
- Steering gear turning torque. Refer to "TURNING TORQUE MEASUREMENT", ST-22 (4WD models), or ST-29 (2WD models).



Checking Steering Wheel Play

Place wheels in a straight ahead position and check steering wheel play.

Steering wheel play:

- 35 mm (1.38 in) or less If it is not within specification, check the following for loose or worn components.
- Steering column. Refer to ST-11.
- Front suspension and axle. Refer to FA section ("Front Axle and Front Suspension Parts", "ON-VEHICLE SERVICE".)
- C. Steering gear. [Refer to ST-14 (manual steering), ST-20 (power steering 4WD), or ST-27 (power steering 2WD).]

MA

Gl

LC

EC

FE

TF

PD)

FA

RA

BR


ST

BT

HA

配

 $\mathbb{D}X$



Checking Neutral Position on Steering Wheel

Make sure that wheel alignment is correct.

Wheel alignment:


Refer to FA section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS").


 Verify that the steering gear is centered before removing the steering wheel.

Checking

- Check that the steering wheel is in the neutral position when driving straight ahead.
- 2. If it is not in the neutral position, remove the steering wheel and reinstall it correctly.
- 3. If the neutral position is still not correct:
- a. Loosen tie-rod lock nuts.
- b. Move tie-rods, in opposite direction, the same amount on both left and right sides.

This will compensate for error in the neutral position.





Checking Front Wheel Turning Angle

 Rotate steering wheel fully right, then left; measure turning angle.

Turning angle of full turns:

Refer to FA section ("Inspection and Adjustment", "SERVICE DATA AND SPECIFICATIONS".)

 If it is not within specification, check stopper bolt adjustment.
 Refer to FA section ("FRONT WHEEL TURNING ANGLE", "Front Wheel Alignment".)

Checking Hydraulic System

Before starting, check belt tension, driving pulley and tire pressure.

- 1. Set Tool. Open shut-off valve. Then bleed air. Refer to "Bleeding Hydraulic System", ST-6.
- 2. Run engine at idle speed or 1,000 rpm.
- Make sure temperature of fluid in reservoir tank rises to 60 to 80°C (140 to 176°F).

WARNING:

Warm up engine with shut-off valve fully opened. If engine is started with shut-off valve closed, fluid pressure in power steering pump increases to maximum. This will raise fluid temperature abnormally.

3. Check pressure with steering wheel fully turned to left and right positions while idling at 1,000 rpm.

CAUTION:

Do not hold the steering wheel at full lock position for more than 15 seconds.

Oil pump maximum pressure:

7,649 - 8,238 kPa

(78 - 84 kg/cm², 1,109 - 1,194 psi) at idling

4. If power steering pressure is below standard pressure, slowly close shut-off valve and check pressure.

ON-VEHICLE SERVICE

Checking Hydraulic System (Cont'd) CAUTION:

GI

Do not close shut-off valve for more than 15 seconds.

 When pressure reaches maximum pressure, gear is damaged. Check power steering gear. Refer to ST-20 (4WD models), or ST-27 (2WD models).

MA

 When pressure remains below standard pressure, pump is damaged. Check power steering pump. Refer to ST-35. EM

 If power steering pressure is higher than standard pressure, power steering pump flow control valve is damaged. Check power steering pump. Refer to ST-35.

LC

 After checking hydraulic system, remove Tool and add fluid as necessary. Then completely bleed air out of system. Refer to ST-6.

ĒC

FE

CL

MT

AT

TF

PD

FA

RA

BR


RS


BT


HA

DX

STEERING WHEEL AND STEERING COLUMN







Steering Wheel

REMOVAL AND INSTALLATION


- Remove air bag module and spiral cable. Refer to RS section ["Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].
- Disconnect horn connector and remove steering wheel nut.
- 3. Remove steering wheel mass damper.
- Remove steering wheel using Tool.
- For installation, refer to RS section ["Air Bag Module and Spiral Cable", "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

STEERING WHEEL AND STEERING COLUMN

Steering Column

REMOVAL CAUTION: The rotation of the spiral cable (SRS "Air bag" component part) is limited. If the steering gear must be removed, set the front wheels in the straight-ahead direction. Do not rotate the steering column while the steering gear is removed.

- Remove the steering wheel before removing the steering lower joint to avoid damaging the SRS spiral cable. Refer to ST-10.
- 1. Remove steering wheel, refer to ST-10.
- Remove driver lower finisher and reinforcement.
- Disconnect combination switch electrical connectors and air bag harness connector.
- 4. Remove key interlock cable (A/T models).
- 5. Pull back carpet and remove dash insulator.
- Remove bolt from lower joint.
- Remove two steering column bolts and remove steering column.



INSTALLATION

- When installing steering column, finger-tighten all lower bracket and clamp retaining bolts; then tighten them securely.
 Make sure that undue stress is not applied to steering column.
- When fitting steering lower joint, be sure tightening bolt faces cutout portion.
- Align spiral cable correctly when installing steering wheel.
 Refer to RS section ["Air Bag Module and Spiral Cable",
 "SUPPLEMENTAL RESTRAINT SYSTEM (SRS)"].

CAUTION:

After installation, turn steering wheel to make sure it moves smoothly. Ensure the number of turns from the straight forward position to left and right locks are the same. Be sure that the steering wheel is in a neutral position when driving straight ahead.

ST

G1

MA

EM

EG

C[

MT

ASP

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

RS

BT


HA


EL.

10)X

ST-11 895

Disassembly and Assembly







- When disassembling and assembling, unlock steering lock with key.
- Remove combination switch.
- Install lock nut on steering column shaft and tighten the nut to specified torque.

Lock nut:

(2.5 - 34 N·m (2.5 - 3.5 kg-m, 18 - 25 ft-lb)




- Steering lock
- Break self-shear type screws using a drill or other appropriate tool.



b. Install self-shear type screws, then tighten until heads break

STEERING WHEEL AND STEERING COLUMN



L, 2W D 4W D SST709A

Disassembly and Assembly (Cont'd)

Tilt mechanism

After installing steering column, check tilt mechanism operation.

MMA

G

LC.

EC

Inspection

When steering wheel does not turn smoothly, check the steering column as follows and replace damaged parts.

FE

Check column bearings for damage or unevenness. Lubricate with recommended multi-purpose grease or replace steering column as an assembly, if necessary.

Check jacket tube for deformation or breakage. Replace if necessary.

MT

When the vehicle is involved in a light collision, check dimension "L". If it is not within specifications, replace steering column as an assembly.

Column length "L1 & L2": $L_1 = 895.0 - 898.6 \text{ mm}$ (35.24 - 35.38 in) $L_2 = 863.1 - 866.7 \text{ mm}$ (33.98 - 34.12 in)

AT

TF

PD

FA

RA


BR


RS


BT

EL

Removal and Installation







Disassembly

1. Place steering gear in a vise using Tool.




MA

国M

LC

EC



KV48101500 (J28802)

Set worm gear in a straight-ahead position.

Loosen adjusting plug lock nut using Tool.

Remove sector shaft together with sector shaft cover.

CAUTION:

CAUTION:

SST8230

SST086

When pulling sector shaft out, be careful not to damage oil seal or associated parts.

Do not remove sector shaft needle bearings from steering gear housing. If necessary, replace gear housing as an assembly.



MT

AΤ

TF

PD)

FA

RA

BR

Ends of ball guides will be damaged if nut is rotated until

Do not separate ball nut from worm gear assembly.

If necessary, replace entire unit as an assembly.


Remove worm gear together with worm bearing.

Do not remove sector shaft needle bearings from steering gear housing.

If necessary, replace entire gear housing as an assembly.

Be careful not to rotate ball nut fully to either end of worm





Apply multi-purpose grease to sealing area of new oil seals for sector shaft and worm gear.

Before installing oil seal, coat oil seal contacting face with

HIA

BT


WORM GEAR BEARING PRELOAD

it stops at end of worm gear.

Drive oil seal into place.


gear fluid.

配




ST-15 899

Assembly and Adjustment (Cont'd)



2. Place worm gear assembly together with worm gear bearing into gear housing.




3. Adjust worm gear bearing preload using Tools.

CAUTION:

- Always adjust worm gear bearing preload by turning adjusting plug in clockwise direction.
- Before measuring preload, rotate worm gear a few turns in both directions to seat worm gear bearing.

Worm gear bearing preload: 0.69 - 0.88 N·m

(7.0 - 9.0 kg-cm, 6.1 - 7.8 in-lb)



4. Apply suitable sealant to inner surface of lock nut.

Assembly and Adjustment (Cont'd)

KV48101500

(J28802)


5. Tighten lock nut using Tools. Lock nut: (23 - 255 N·m (23 - 26 kg-m, 166 - 188 ft-lb)




GI


国网


LC











Assembly and Adjustment (Cont'd)

4. Adjust steering gear turning torque in a straight-ahead position using Tool, then lock with lock nut.

CAUTION:

- Always adjust steering gear preload by turning adjusting screw in clockwise direction.
- Rotate worm gear a few turns in both directions to seat steering gear assembly.
- Measure turning torque at 360° position from straight-ahead position using Tools.

Turning torque at 360°:

0.69 - 0.88 N·m (7.0 - 9.0 kg-cm, 6.1 - 7.8 in-lb)

Measure turning torque at straight-ahead position.

Straight-ahead position is a position where stub shaft is turned 2.14 turns (two full turns and 50°) from lock position.

Turning torque at straight-ahead position:


0.20 - 0.39 N·m (2.0 - 4.0 kg-cm, 1.7 - 3.5 in-lb)

higher than turning torque at 360°


Maximum turning torque:

1.08 N·m (11.0 kg-cm, 9.5 in-lb)

If turning torque is not within specifications, adjust by turning sector shaft adjusting screw.



- 5. Turn worm gear several times by hand to properly break in worm bearing.
- 6. Check steering gear preload. Readjust as necessary.



- Measure total preload.
- Check backlash.

Measure backlash at top end of pitman arm in straight-ahead position.

Backlash (in straight-ahead position):


0.1 mm (0.004 in) or less

Inspection

Clean all the disassembled parts in solvent, then check condition.

SECTOR SHAFT

- 1. Check gear teeth surface for pitting, burrs, cracks or any other damage, and replace as necessary.
- Check sector shaft serration for distortion and replace as necessary. Also check gear housing for deformation.



Inspection (Cont'd)

STEERING WORM ASSEMBLY

 Inspect ball nut gear teeth surface. Replace if pitting, burrs, wear or any other damage is found.

 Ball nut must rotate smoothly on worm gear. If found to be too tight, assembly should be replaced. Check rotation of ball nut as follows:

CAUTION:

Be careful not to allow ball nut to rotate fully to either end of worm gear.

a. Move ball nut to either end of worm gear. Gradually stand worm shaft and ball nut assembly on end until ball nut moves downward on worm gear under its own weight.

 If ball nut does not move freely over entire stroke, replace assembly.

Be careful not to damage ball nut guide tube while check is being made.

BEARING

Inspect worm gear bearing for wear, pitting or any other damage. Replace as necessary.

When replacing worm gear bearing, replace bearing and outer race as a set.

If sector shaft needle bearings are worn or damaged, replace gear housing as an assembly.

OIL SEALS

- Discard any oil seal which has been removed.
- Replace oil seal if sealing surface is deformed or cracked.
- Discard oil seal if spring is fatigued or dislocated.

FA

(G)

MA

EM

LC

EC

CL

AT

TF

PD)

RA

BR

SТ

R\$


BT

HA

IDX

ST-19 903

Description




CAUTION:

- Parts which can be disassembled are strictly limited. Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- Follow the procedures and cautions indicated in the Service Manual.


Removal and Installing

Before removal, clean gear housing and oil pump exteriors using a steam cleaner. Then dry with compressed air.

STEERING GEAR



Power Steering Gear Component



@|

MA

EM

LC

CL

MIT

PD

FA

RA

BR

RS

BT

KA

EL

]DX

905


Pre-disassembly Inspection and Adjustment

Before disassembling power steering gear component parts, make sure there is no oil leakage around sealing portion and check steering turning torque as follows:

Check sealing portion.


- Sector shaft cover O-ring
- Sector shaft U-packing
- Sector shaft oil seal
- Rear housing O-ring
- Gear housing O-ring

Discard any oil seal and O-ring which have been removed. Replace oil seal and O-ring if sealing surface is deformed or cracked.



TURNING TORQUE MEASUREMENT


- 1. Measure turning torque at 360° position.
- a. Install steering gear on Tool.



- b. Turn stub shaft all the way to right and left several times.
- c. Measure turning torque at 360° position from straight-ahead position with Tools.

Turning torque at 360°:

0.15 - 0.78 N·m (1.5 - 8.0 kg-cm, 1.3 - 6.9 in-lb)



d. Measure turning torque at straight-ahead position.

Straight-ahead position is a position where stub shaft is turned 2.14 turns (two full turns and 50°) from lock position.

Turning torque at straight-ahead position:


0.25 - 1.32 N·m (2.5 - 13.5 kg-cm, 2.2 - 11.7 in-lb)

higher than turning torque at 360°

Maximum turning torque:

1.03 - 1.47 N·m (10.5 - 15 kg-cm, 9.1 - 13.0 in-lb)

If turning torque is not within specifications, adjust by turning sector shaft adjusting screw.



Pre-disassembly Inspection and Adjustment (Cont'd)

2. Tighten adjusting screw lock nut with tools.




@

ЦC

EĈ

FE

CL.



Disassembly

Before disassembly, measure turning torque.

If not within specifications, replace steering gear assembly. **CAUTION:**

Oil sealing parts, dust cover, copper washer and snap ring must not be used again after removal.

Place steering gear in a vise with Tool.

Set worm gear in a straight-ahead position.

MT

- Loosen (do not remove) sector shaft cover bolt.
- Knock out end of sector shaft with a plastic hammer.
- Remove sector shaft by hand.

TF

AT

PD

FA

RA

BR

Remove U-packing.


SST3190

SST320C

When removing oil seal and U-packing, be careful not to

scratch gear housing.

Remove oil seal.





BT


RS

KA


EL

IDX

Disassembly (Cont'd)




8. Remove lock nut, then loosen adjusting screw using a screw-driver. Separate sector cover and sector shaft.



- 9. Remove O-ring.
- 10. Remove U-packing.

CAUTION:

- When removing U-packing, be careful not to scratch sector cover, needle bearing, etc.
- Needle bearing cannot be disassembled. If it is damaged, remove sector cover assembly.



- 11. Remove dust seal.
- 12. Remove rear housing bolts.
- 13. Remove rear housing together with worm gear assembly.


CAUTION:


Worm gear assembly cannot be disassembled. When it is removed, be careful not to disengage worm gear from shaft or allow it to drop.

14. Remove teflon ring and O-ring of worm gear assembly.

Assembly

- 1. Install new O-ring on worm gear assembly.
- Apply a thin coat of ATF to new O-ring.
- 2. Install new teflon ring on worm gear assembly.
- Make sure that teflon ring is seated in correct position.
- 3. Install new O-ring into rear housing.





Assembly (Cont'd)

4. Install worm gear assembly with rear housing into the gear housing.

CAUTION:

Apply a thin coat of ATF inside gear housing and piston before insertion.


Be careful not to damage teflon ring at piston end when inserting worm gear assembly into gear housing.

LC.

EC

MA

Gradually tighten rear housing bolts in a criss-cross fashion.



∠O-ring 🐼

U-packing 🔀

SST322C

SST321C

FE

CL

MT

AT

TE

- Install new O-ring into sector shaft cover.
- Before installing, apply a thin coat of ATF to O-ring.
- 7. Install new U-packing into sector shaft cover.
- Before installing, apply a thin coat of ATF to U-packing.
- Direct grooved side of U-packing to needle bearing.

PD

FA

RA

- Install sector shaft into sector shaft cover. Set adjusting screw to its outermost position.
- Before installing sector shaft, apply multi-purpose grease to adjusting screw and adjusting screw shim.



BT


Install new oil seal into gear housing with suitable tool.

Before installing oil seal, apply multi-purpose grease to oil seal lips.

EL


DX

909



Adjusting screw

ST-25




Assembly (Cont'd)

10. Set piston rack at straight-ahead position.

Turn piston rack about 10° to 15° toward yourself with your finger.

This enables smooth insertion of sector gear.



- 11. Gradually insert sector shaft into gear housing.
- 12. Tighten sector shaft cover bolts.
- 13. Set worm gear turning torque by turning sector shaft adjusting screw and locking with lock nut.

Refer to "TURNING TORQUE MEASUREMENT", "Pre-disassembly and Adjustment", ST-22.

- If set and adjusting turning torque is considerably different from the value before disassembly, replace the entire assembly.
- 14. Check sector shaft end play in neutral position.


End play:

Less than 0.1 mm (0.004 in)

If not within specification, adjust it with adjusting screw.

15. Check worm gear preload. If not within specification, readjust it.

Description



This power steering adopts spool valve control which was developed in a technical tie-up with the ZF Company.

Only the sealing parts can be replaced. The remaining parts must be replaced as an assembly.

CAUTION:

- Parts which can be disassembled are strictly limited.
 Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- Follow the procedures and cautions indicated in the Service Manual.

G

MA

LG

EC

FE

CL

MT

AT

TF

PD

PA

RA

BR

ST

RS

BT

HA


EL

ST-27 911


Removal and Installing

Before removal, clean gear housing and oil pump exteriors using a steam cleaner. Then dry with compressed air.

STEERING GEAR



Power Steering Gear Component




Pre-disassembly Inspection and Adjustment

Before disassembling power steering gear component parts, make sure there is no oil leakage around sealing portion and check steering turning torque as follows:

Check sealing portion.


- Adjusting screw nut O-ring
- Sector shaft cover O-ring
- Sector shaft oil seal
- Rear cover oil seal and O-ring
- Rear housing O-ring
- Gear housing O-ring

Discard any oil seal and O-ring which have been removed. Replace oil seal and O-ring if sealing surface is deformed or cracked.



TURNING TORQUE MEASUREMENT


- 1. Measure turning torque at 360° position.
- a. Install steering gear on Tool.



- Turn stub shaft all the way to right and left several times.
- Measure turning torque at 360° position from straight-ahead position with Tools.

Turning torque at 360°:

0.7 - 1.2 N·m (7 - 12 kg-cm, 6.1 - 10.4 in-lb)



d. Measure turning torque at straight-ahead position.

Straight-ahead position is a position where stub shaft is turned 2.14 turns (two full turns and 50°) from lock position.

Turning torque at straight-ahead position:

0.1 - 0.4 N·m (1 - 4 kg-cm, 0.9 - 3.5 in-lb) higher than turning torque at 360°

If turning torque is not within specifications, adjust by turning sector shaft adjusting screw.

ST-29 913



MA

LC

50

Cl

FE

MT

AT

TF

PD)

- -

FA

RA


BR

BT

HA

L U∂-4

[DX



Pre-disassembly Inspection and Adjustment (Cont'd)


2. Tighten adjusting screw lock nut with tools.

Disassembly

Before disassembly, measure turning torque.

If not within specifications, replace steering gear assembly. CAUTION:

Oil sealing parts, dust cover, copper washer and snap ring must not be used again after removal.




ADJUSTING SCREW LOCK NUT O-RING

Remove adjusting screw lock nut, and replace O-ring.

SECTOR SHAFT OIL SEAL


1. Set stub shaft in a straight-ahead position.

Straight-ahead position is a position where stub shaft is turned 2.14 turns (two full turns and 50°) from lock position.




2. Disconnect sector shaft cover bolt.

Do not turn lock nut unless necessary; otherwise it will damage O-ring, resulting in an oil leak.



3. Draw out sector shaft.

Knock out end of sector shaft approximately 20 mm (0.79 in).



35 mm (1.38 in) or less

Disassembly (Cont'd)

4. Connect a roll of plastic film to sector shaft.

Plastic film:

Thickness 0.1 mm (0.004 in) Length x width

200 x 200 mm (7.87 x 7.87 in)

Pull out sector shaft by hand.

Attach plastic film to needle bearings located at two places inside gear housing while simultaneously pulling out sector shaft so that bearings will not drop into housing.

LC

EM

G1.

MA

REAR HOUSING O-RING

Remove torx screw.

EG

SST149A

SST807


SST150A

FE

CL.

MT

AT



TE

When worm gear assembly is removed, piston may turn and come off under its own weight. Hold piston to prevent it from turning.

If piston-to-rear housing clearance exceeds 35 mm (1.38 in) recirculating ball will be out of groove of worm gear; do not reinstall piston but replace the entire assembly.

FA

Be careful not to damage teflon ring at piston end when removing.

RA

Remove O-rings.

RS

BT

REAR COVER O-RING AND OIL SEAL


Remove snap ring, then rear cover.


Remove O-ring and oil seal.

HA

EL

ID)X






Assembly

ADJUSTING SCREW LOCK NUT O-RING


Insert new O-ring into adjusting screw lock nut.

- Before inserting, apply a thin coat of petroleum jelly to O-ring.
- Insert O-ring to make sure it fits into groove.




SECTOR SHAFT OIL SEAL

- When installing, be sure to use new oil seal, dust seal, back-up ring and snap ring.
- Before installing, apply a thin coat of petroleum jelly to new oil seal and dust seal.




1. Press new oil seal and then install back-up ring with Tool.




2. Install a new snap ring into gear housing.

CAUTION:

- Turn snap ring to make sure it fits into groove.
- Always install snap ring with R face facing inward.



- Press a new dust seal.
- 4. Fit new O-ring into sector shaft cover.
- Before installing, apply a thin coat of petroleum jelly to O-ring.
- Make sure that O-ring is installed properly and is not damaged by sector shaft.



Assembly (Cont'd) **SECTOR SHAFT END PLAY**

Select suitable adjusting shim and adjust end play between sector shaft and adjusting screw.

Sector shaft end play:

0.01 - 0.03 mm (0.0004 - 0.0012 in) Sector shaft adjusting screw shims:

Refer to SDS, ST-42.

LC

MA

G

REAR COVER O-RING AND OIL SEAL

Install new O-ring and oil seal.

Install rear cover, then install snap ring.

肥

CAUTION:

SST155A

SST808

Turn snap ring to make sure it fits into grooves.

Always install snap ring with its rounded edge facing rear cover.

C/L



REAR HOUSING O-RING

AT

MIT

Install new O-rings.


Before installing, apply a thin coat of petroleum jelly to O-ring.

Make sure O-ring is installed correctly and is not damaged

PD)

by worm gear.


FA



Install torx screws.

BR

RA





RS


BT


HA


EL

IDX

ST-33 917







Assembly (Cont'd) SECTOR SHAFT

1. Set piston rack at straight-ahead position.

Turn piston rack about 10° to 15° toward yourself with your finger. This permits smooth insertion of sector gear.

2. Wrap vinyl tape around serration area of sector shaft.

Vinyl tape prevents oil seal lip from being damaged during insertion.

3. Gradually insert sector shaft into gear housing, being careful not to damage oil seal.

When inserting sector shaft into gear housing, remove plastic film. Be careful not to drop bearings into gear housing.


- 4. Tighten sector shaft cover bolts.
- 5. Check turning torque and steering gear preload.


Refer to "TURNING TORQUE MEASUREMENT", "Pre-disassembly Inspection and Adjustment", ST- 29.

 If turning torque is considerably different from the value before disassembly, replace the entire assembly.

ST-34

Disassembly and Assembly





Pre-disassembly Inspection

Disassemble the power steering oil pump only if the following items are found.

- Oil leak from any point shown in the figure.
- Deformed or damaged pulley.
- Poor performance.

MA

G1

LC

EC

FE

GL

MT

AT

ŢF

PD

jr/Al

 $\mathbb{R}\mathbb{A}$

BR

ST

R\$

BT

HA

EL

 $\mathbb{D}\mathbb{X}$

Inspection


PULLEY AND PULLEY SHAFT

- If pulley is cracked or deformed, replace it.
- If fluid leak is found around the pulley shaft, replace the oil seal.


Disassembly

CAUTION:


- Parts which can be disassembled are strictly limited.
 Never disassemble parts other than those specified.
- Disassemble in as clean a place as possible.
- Clean your hands before disassembly.
- Do not use rags; use nylon cloths or paper towels.
- When disassembling and reassembling, do not let foreign matter enter or contact the parts.



- Remove snap ring, then draw drive shaft out.
- Be careful not to drop drive shaft.





- Remove oil seal.
- Be careful not to damage front housing.





- Remove connector.
- Be careful not to drop control valve.

POWER STEERING OIL PUMP









Assembly

Assemble oil pump, noting the following instructions.

Make sure O-rings and oil seal are properly installed.

Always install new O-rings and oil seal.

Be careful of oil seal direction.

Cam ring, rotor and vanes must be replaced as a set if neces-

sary.

When assembling, coat each part with ATF.

Pay attention to the direction of rotor.

When assembling vanes to rotor, rounded surfaces of vanes must face cam ring side.

Insert pin 2 into pin groove 1 of front housing and front side plate. Then install cam ring 3 as shown at left.

Cam ring:

D₁ is less than D₂

LC

GI.

MA

EC

FE

CL

MT

TF

PD

FA

BR

RA


RS


BT


HA

EL

Removal and Installation








Remove pitman arm with Tool.

ST-38

STEERING LINKAGE



Removal and Installation (Cont'd)

Remove tie-rod from knuckle arm with Tool.


MΑ

G[

EM

LC

EC



Disassembly

IDLER ARM ASSEMBLY

Apply coat of multi-purpose grease to bushing.

 Press bushing into idler body, and insert shaft of idler bracket carefully until bushing protrudes.

CL

MT

FE

CROSS ROD AND TIE-ROD

1. When tie-rod ball joints and tie-rod bar are separated, adjust tie-rod length correctly.

Adjustment should be done between ball stud centers.

Lock tie-rod clamp nut so that ball joint on outer ball stud is as follows with respect to that on inner ball stud.

AT

L: Standard

344 mm (13.54 in) ... 2WD 281 mm (11.06 in) ... 4WD

TF

CAUTION:

Make sure that tie-rod bars are screwed into tie-rod tube more than 35 mm (1.38 in).

FA

PD)

RA

BR


ST


RS


BT


HA

EL









Inspection

BALL JOINT AND SWIVEL JOINT

 Check joints for play. If ball or swivel stud is worn and play in axial direction is excessive or joint is hard to swing, replace as a complete unit.

2. Check condition of dust cover. If it is cracked excessively, replace dust cover.

0.1 - 1.0 mm (0.004 - 0.039 in)

- When replacing dust cover, be careful not to damage it.
- Lubricate joint with multi-purpose grease, if necessary.
- When installing boot band with commercial service tool, be careful not to overexpand it. Refer to ST-4.

CAUTION:

Be careful not to apply grease or oil to taper of joint.

IDLER ARM ASSEMBLY

- Check rubber bushing of idler arm for breakage, wear or play, and if necessary replace.
- Lubricate idler arm assembly with multi-purpose grease, if necessary.

When lubricating, refer to "BALL JOINT AND SWIVEL JOINT".

CROSS ROD AND TIE-ROD

Check tie-rod and cross rod for breakage, bends or cracks, and replace with a new one if necessary.

STEERING DAMPER

Check for oil leaking from damper, and replace if necessary.

FIXING LOCATION

- Check fixing location (nuts and cotter pins) for looseness, play or breakage.
- When looseness or play is found, check for wear on tapered portion of joints, gear arm of idler arm.
- When reassembling each joint, use new cotter pins.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

Steering column type	Manual steering	Power steering	
(Collapsible)	2WD	2WD	4WD
Steering gear type	VB66K	PB48S	PB59K
Turns of steering wheel on the vehicle (Lock-to-lock)	5.8	3.7	3.4
Steering gear ratio	24.4 - 26.84	16.5	15

Steering wheel axial play mm (in)	0 (0)	
Steering wheel play mm (in)	35 (1.38) or less	

MA

G

LC

EC

FE


CL

MT

Inspection and Adjustment

STEERING COLUMN

Unit: mm (in) Dimension "L" 2WD model 895.0 - 898.6 (35.24 - 35.38) 4WD model 863.1 - 866.7 (33.98 - 34.12)



AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

EL

ST-41 925

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

MANUAL STEERING GEAR (Model: VB66K)

Worm bearing preload N·m (kg-cm, in-lb)	0.00	- 0.88 , 6.1 - 7.8)
Steering gear turning torque N·m (kg-cm, in-lb)		·
360° position from straight-ahead position	0.69 - 0.88 (7.0 - 9.0, 6.1 - 7.8)	
Straight-ahead position (As compared with steering wheel turned 360°)		- 0.39 , 1.7 - 3.5)
Maximum turning torque	1.08 (11.0, 9.5)	
Backlash at pitman arm top end (in a straight-ahead position) mm (in)	0 - 0.1 ((0 - 0.004)
End play (Between sector shaft and adjusting screw) mm (in)	0.1 (0.00	4) or less
	Thickness mm (in)	Part number
Adjusting shim thickness	1.95 (0.0768)	48129-84500
•	2.00 (0.0787)	48130-84500
	2.05 (0.0807)	48131-84500
Oil capacity f (US pt, Imp pt)	Approx. 0.62	(1-3/8, 1-1/8)

STEERING LINKAGE

Applied model		2WD	4WD
Relay-rod swivel joint			
Rotating torque N·m (kg-	cm, in-lb)	_	0.5 - 4.9 (5 - 50, 4.3 - 43.4)
Axial end play	mm (in)	_	0.1 - 1.0 (0.004 - 0.039)
Tie-rod & relay-rod ball joi	nt		
Swinging force at cotte hole	erpin N(kg,lb)		107.9 2.4 - 24.3)
Rotating torque N·m (kg-cm, in-lb)		0.5 (5 - 50, 4	- 4.9 .3 - 43.4)
Axial end play mm (in)		0.1 - 0.8 (0.	004 - 0.031)
Tie-rod standard engine (l	_) mm (in)	344 (13.54)	281 (11.06)

POWER STEERING SYSTEM (Model: PB48S)

Steering wheel turning force (at 360° from neutral position and circumference of steering wheel) N (kg, lb)	24.5 - 29.4 (2.5 - 3.0, 5.5 - 6.6)	
Oil pump pressure kPa (kg/cm², psi)	7,649 ~ (78 - 84, 1,109 -	•
Fluid capacity mℓ (US fl oz, Imp fl oz)	Approximately 90 33.8, 31.	
Normal operating temperature °C (°F)	60 - 80 (1	40 - 176)
Steering gear turning torque N·m (kg-cm, in-lb)		
360° position from straight-ahead position	0.7 - 1.2 (7 - 1	12, 6.1 - 10.4)
Straight-ahead position (As compared with steering wheel turned 360°)	0.1 - 0.4 (1 - 4,	0.9 - 3.5) higher
Backlash at pitman arm top end (in a straight- ahead position) mm (in)	0 - 0.1 (0 - 0.004)	
End play (Between sector shaft and adjusting screw) mm (in)	0.01 - 0.03 (0.0004 - 0.0012)	
Adjusting shim thickness	Thickness mm (in)	Part number
	1.575 - 1.600 (0.0620 - 0.0630)	48213-B0100
	1.550 - 1.575 (0.0610 - 0.0620)	48214-B0100
	1.525 - 1.550 (0.0600 - 0.0610)	48215-B0100
	1.500 - 1.525 (0.0591 - 0.0600)	48216-B0100
	1.475 - 1.500 (0.0581 - 0.0591)	48217-B0100
	1.450 - 1.475 (0.0571 - 0.0581)	48218-B0100

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

POWER STEERING SYSTEM (Model: PB59K)

39 (4, 9) or less	
7,649 - 8,238 (78 - 84, 1,109 - 1,194) at idling	
Approximately 1,000 - 1,100 (33.8 - 37.2, 35.2 - 38.7)	
60 - 80 (140 - 176)	
0.15 - 0.78 (1.5 - 8.0, 1.3 - 6.9)	
0.25 - 1.32 (2.5 - 13.5, 2.2 - 11.7) higher	
1.03 - 1.47 (10.5 - 15, 9.1 - 13.0)	
0 - 0.1 (0 - 0.004)	
0.1 (0.004) or less	

(Gi)

MA

EM

lC

EC

FE

C[_

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

EL

1DX

RESTRAINT SYSTEM

SECTION RS

MA

[LC

EG

CONTENTS

PRECAUTIONS	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
SEAT BELTS	
Front Seat Belt	
Rear Seat Belt	
SUPPLEMENTAL RESTRAINT SYSTEM (SRS)	
Precautions for SRS "Air Bag" Service	
Special Service Tools	
Description	
SRS Component Parts Location	
Maintenance Items	
Diagnosis Sensor Unit and Crash Zone Sensor	
Removal And Installation	
Air Bag Module and Spiral Cable	10
Removal	
Installation	
Disposal of Air Bag Module	

	FE
Checking Deployment Tool13	
Deployment Procedures For Air Bag Module	
(Outside of Vehicle)14	CL
Deployment of Air Bag Module While Mounted	
In Vehicle15	
Disposing of Air Bag Module15	MT
TROUBLE DIAGNOSES — Supplemental	
Restraint System (SRS)17	. —
How to Perform Trouble Diagnoses for Quick	AT
and Accurate Repair17	
Schematic19	77
Wiring Diagram -SRS20	ľΓ
Self-diagnosis22	
Diagnostic Procedures22	(1)(q)
Trouble Diagnoses for Air Bag Warning Lamp35	IT ISV
Diagnostic Procedures35	
COLLISION DIAGNOSIS37	FA
SRS inspection37	8 F G
- · · - p - · · · · p - · · · · · · · ·	

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit. When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

 $\mathbb{R}\mathbb{A}$

13(8)

ST

RS

BT

 $\mathbb{R}\mathbb{A}$

EL.



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness and spiral cable.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

RS-2

SEAT BELTS

CAUTION:

- Do not disassemble buckle or seat belt assembly.
- Replace anchor bolts if they are deformed or worn out.
- Never oil tongue and buckle.
- If any component of seat belt assembly is questionable, do not repair. Replace the seat belt assembly.
- If webbing is cut, frayed, or damaged, replace seat belt assembly.
- When replacing seat belt assembly, use a genuine NISSAN seat belt assembly.
- After any collision, inspect all seat belt assemblies, including retractors and other attached hardware.

G

MA

LC EC

尾

CL.

MT

AT

PD)

TF

FA

RA

BR

ST

RS

BY


KA


EL

1DX

Front Seat Belt

SEC. 868





ARS126

: N·m (kg-m, ft-lb)


Removal

Remove front seat. Refer to BT section ("Front Seat", "SEAT").

1 Remove buckle.

- 2 Remove floor anchor bolt.
- 3 Remove lower side finisher.

- 4 Remove pillar anchor cover and anchor bolt.
- (5) Remove guide plate.
- 6 Remove retractor bolts and remove retractor.



Removal

- 1 Remove underseat storage.
- ② Remove buckle.③ Remove seat belt anchor bolt.

Gi

 $\mathbb{M}\mathbb{A}$

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

ARS125

RS

BT

HA

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Precautions for SRS "Air Bag" Service

- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.
- Before servicing the SRS, turn ignition switch OFF, disconnect both battery cables and wait at least 3 minutes.
 - For approximately 3 minutes after the cables are removed it is still possible for the air bag to deploy. Therefore, do not work on any air bag system connectors or wires until at least 3 minutes have passed.
- Diagnosis sensor unit and crash zone sensor (4WD models) must always be installed with arrow mark "\$\phi" pointing toward the front of the vehicle for proper operation. Also check diagnosis sensor unit for cracks, deformities and rust before installation and replace if necessary.
- The spiral cable must be aligned with the neutral position since its rotations are limited. Do not attempt to turn steering wheel or column after removal of steering gear.
- Handle air bag module carefully. Always place it with the pad side facing upward.
- Do not use old special bolts after removing any SRS parts; replace with new special bolts. Conduct selfdiagnosis to check entire SRS for proper function.
- If front of vehicle is damaged in a collision, always check the crash zone sensor and the wiring harness (4WD models).

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special serivce tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
KV991072S0 (J38381-KIT) Air bag deployment kit KV99106400 (J38381) Deployment tool	NT357	Disposing of air bag module
KV99105300 (J41246) Air bag module bracket	NT354	Anchor the air bag module
HT61961000 and HT62152000 combined (J38219) *Special torx bit		Use for special bolts [TAMPER RESISTANT TORX (Size T50)]
Opecial lork bit	NT361	a: 3.5 (0.138) dia. b: 8.5 - 8.6 (0.335 - 0.339) dia. c: approx. 10 (0.39) sq. Unit: mm (in)

^{*:} Special tool or commercial equivalent

934 RS-6

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

Description


2WD models

The diagnosis sensor unit will deploy the air bag if the G-sensor activates simultaneously with the safing sensor while the ignition switch is ON.

4WD models

The diagnosis sensor unit will deploy the air bag if the G-sensor and/or the crash zone sensor activates simultaneously with the safing sensor while the ignition switch is ON.

l our it i our	Crash zone sensor	Diagnosis	s sensor unit	Air had signal
Ignition	(4WD models only)	G-sensor	Safing sensor	Air bag signal
ON		ON	ON	ON
ON	ON		ON	ON
ON	ON	ON	ON	ON



RS

BT

HIA

935

RS-7

G[

MA

LC

EC

FE

CL.

MT

AT

TE

PD)

FA


RA

BR

ST

]DX

SRS Component Parts Location



Maintenance Items

- 1. Check "AIR BAG" warning lamp operation
 - After turning ignition key to the ON position, "AIR BAG" warning lamp illuminates. The "AIR BAG" warning lamp will turn off after about 7 seconds if no malfunction is detected.
 - If any of the following "AIR BAG" warning lamp conditions occur, immediately check the air bag system. Refer to RS-22 for details.
- The warning lamp does not illuminate when the ignition switch is turned ON.
- The warning lamp does not turn off about 7 seconds after the ignition switch is turned ON.
- The warning lamp turns off about 7 seconds after the ignition switch is turned ON, but it turns on again or blinks.
- 2. Visually check SRS components
- a. Crash zone sensor (4WD models).
- Check crash zone sensor to ensure the arrow marks face the front of the vehicle.
- Check body and sensor bracket for deformities and rust.
- Check sensor case for dents, cracks, deformities and rust.
- Check sensor harness for binding, connector for damage and terminals for deformities.
- b. Diagnosis sensor unit
- Check diagnosis sensor unit and bracket for dents, cracks and deformities.
- Check connectors for damage and terminals for deformities.
- c. Air bag module and steering wheel
- Remove air bag module from steering wheel. Check harness cover and connectors for damage, terminals for deformities and harness for binding.
- Install air bag module to steering wheel to check fit and alignment with the wheel.
- Check steering wheel for excessive free play.
- d. Spiral cable
- Check spiral cable and combination switch for damage.
- Check connectors and protective tape for damage.
- Check steering wheel for noise, binding and heavy operation.
- e. Main harness and air bag harness
- Check connectors for poor connections and damage and terminals for deformities.
- Check harnesses for binding, chafing and cuts.

CAUTION:

Replace previously used special bolts with new ones.

CAUTION:

Diagnosis Sensor Unit and Crash Zone Sensor

Before servicing SRS, turn the ignition switch OFF, disconnect both battery cables and wait for at least 3 minutes.

MA

The special bolts are coated with a bonding agent while the other bolt is for ground. Do not use old bolts after removal; replace with new coated bolts.

Check diagnosis sensor unit for proper installation.

圓例

Check diagnosis sensor unit to ensure that there are no deformities, dents, cracks or rust. If there are any visible signs of damage, replace with a new one.

Check diagnosis sensor unit brackets to ensure they are free of deformities and rust.

LC

Replace diagnosis sensor unit if it has been dropped or sustained an impact. Check crash zone sensor for proper installation.

Check crash zone sensor to ensure that there are no deformities, dents, cracks or rust. If there are any visible signs of damage, replace the crash zone sensor.


EE

Check crash zone sensor bracket to ensure that it is free of deformities and rust.

G[_

MIT

AT



REMOVAL AND INSTALLATION

Before servicing SRS, turn the ignition switch OFF, disconnect both battery cables and wait at least 3 minutes.

Diagnosis sensor unit

PD

1. Disconnect driver air bag module connector.

Remove console box. Refer to BT section ("INSTRUMENT 2. PANEL").

3. Disconnect diagnosis sensor unit connector.

 $\mathbb{R}\mathbb{A}$

Using the TAMPER RESISTANT TORX (Size T50), remove the three special bolts, then remove ground bolt. The diagnosis sensor unit can then be removed.

国图

NOTE:

To install, reverse the removal procedure.

ST

RS

Crash zone sensor (4WD models)

BT

Disconnect crash zone sensor connector.

Disconnect driver air bag module connector.

HA

Using the TAMPER RESISTANT TORX (Size T50), remove the three special bolts. The crash zone sensor can then be removed.

EL

1D)X

To install, reverse the removal procedure.

Forward

mark

Crash zone : N·m (kg-m, ft-lb) ARS112 sensor

SEC. 253


Special bolt


15 - 25

(1.5 - 2.5,

11 - 18)

Air Bag Module and Spiral Cable









CAUTION:

- Before servicing SRS, turn the ignition switch OFF, disconnect both battery cables and wait for at least 3 minutes.
- Always work from the side of air bag module.
- Remove lower lid from steering wheel, and disconnect air bag module connector.




2. Remove LH and RH side lids and ASCD steering switch (if so equipped). Using the TAMPER RESISTANT TORX (Size T50), remove left and right special bolts. The air bag module can then be removed.



CAUTION:

- Always place air bag module with pad side facing upward.
- Do not attempt to disassemble air bag module.
- The special bolts are coated with a bonding agent. Do not use old bolts after removal; replace with new coated bolts.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



Air Bag Module and Spiral Cable (Cont'd)

 Do not drop or impact air bag module. Replace air bag module if it has been dropped or sustained an impact.

Do not expose the air bag module to temperatures exceeding 90°C (194°F).

 Do not allow oil, grease or water to contact the air bag module.

LC

EC

MA

G1

Set steering wheel in the neutral position.

4. Disconnect horn connector and remove steering wheel nut.

5. Remove steering wheel mass damper.

6. Using steering wheel puller, remove steering wheel. Be careful not to overtighten puller bolt on steering wheel.

eful PE



Do not tap or bump the steering wheel.

7. Remove steering column cover.

8. Disconnect air bag harness and main harness connectors.

MT

CL.

9. Remove the four spiral cable retaining screws. The spiral cable can then be removed.

CAUTION:

SBF239F

ARS152

Do not attempt to disassemble spiral cable.

Do not apply lubricant to the spiral cable.

[P]D)

TE

FA RA


INSTALLATION

1. Set the front wheels in the straight-ahead position.

Align the turn signal cancel tab with the notch of the combination switch as shown.

ST


RS



Guide pin hole

()-k);

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)



Air Bag Module and Spiral Cable (Cont'd)

- 3. Rotate the spiral cable fully clockwise until tight.
- 4. Rotate spiral cable counterclockwise as specified below. Align the white pin with the alignment mark.


Specified turns for spiral cable:

Applied model	Specified turns from neutral position
With power steering	Approx. 2.5
Without power steering	Approx. 4

CAUTION:


The spiral cable may snap during steering operation if the cable is installed improperly. Also, with the steering linkage disconnected, the cable may snap by turning the steering wheel beyond the specified number of turns. Always perform SRS self-diagnosis after installing the air bag module.

Connect spiral cable air bag harness and main harness connectors and tighten screws. Install steering column cover.



- Install mass damper on steering wheel.
- Install steering wheel, setting spiral cable pin guide, and pulling spiral cable harness through.
- 8. Connect horn connector.
- Tighten steering wheel nut.

(1): 29 - 39 N·m (3.0 - 4.0 kg-m, 22 - 29 ft-lb)



- 10. Position air bag module and tighten with new special bolts.
- 11. Connect air bag module connector.
- 12. Install ASCD switch and tighten screws.
- 13. Install all lids.
- 14. Connect both battery cables.
- 15. Conduct Self-diagnosis to ensure entire SRS operates properly (Use CONSULT or warning lamp check). Turn steering wheel to the left end and then to the right end fully to make sure that the spiral cable is set in the neutral position.
- 16. If "AIR BAG" warning lamp blinks (in User mode), it shows that the spiral cable may be snapped due to its improper position. Perform Self-diagnosis again (Use CONSULT or warning lamp check). If a malfunction is detected, replace the spiral cable with a new one.

Disposal of Air Bag Module

Make sure to deactivate air bag modules before disposing of them. Also, before disposing of a vehicle equipped with an air bag system, deactivate air bag modules. If such a system has already been deployed due to an accident, dispose of as indicated in "DISPOSING OF AIR BAG MODULE", RS-15.

Do not dispose of the air bag module undeployed.

When deploying the air bag module, always use the Special Service Tool; Deployment tool (Kent-Moore No. J38381).


When deploying the air bag module, stand to the side of the module at least 5 m (16 ft) away.

Due to heat, do not touch air bag module for at least 30 minutes after deployment.

Be sure to wear gloves when handling a deployed air bag

Never apply water to a deployed air bag module.

Wash your hands after finishing work.



Push

Lamp

SRS019

CHECKING DEPLOYMENT TOOL

Connecting to battery

Place vehicle outdoors with at least 6 m (20 ft) of open space on all sides.

Use a voltmeter to make sure the vehicle battery is fully charged.

CAUTION:

The battery must show voltage of 9.6V or more.

Remove the battery from the vehicle and place it on dry wood blocks approximately 5 m (16 ft) away from the vehicle.

Wait 3 minutes after the vehicle battery is disconnected before

Connect red clip of deployment tool to battery positive terminal and black clip to negative terminal.

CAUTION:

Make sure the polarity is correct. The right side lamp in the tool, marked "deployment tool power", should glow with a green light. If the right side lamp glows red, reverse the connections to the battery.

Deployment tool check


RS-13

Press the deployment tool switch to the ON position. The left side lamp in the tool, marked "air bag connector voltage" should illuminate. If it does not illuminate, replace the tool.

Air bag deployment tool lamp illumination chart (Battery connected)

Switch operation	Left side lamp, green* "AIR BAG CONNECTOR VOLTAGE"	Right side lamp, green* "DEPLOYMENT TOOL POWER"
OFF	OFF	ON
ON	ON	ON

^{*:} If this lamp glows red, the tool is connected to the battery incorrectly. Reverse the connections and make sure the lamp glows green.





(ii)

MA

EG

FΕ

CL

MT

AT

PD

RA

BR


BT


HA.


[D)X




SUPPLEMENTAL RESTRAINT SYSTEM (SRS)









Disposal of Air Bag Module (Cont'd) DEPLOYMENT PROCEDURES FOR AIR BAG MODULE (OUTSIDE OF VEHICLE)

Deploying air bag module while it is mounted in vehicle may damage vehicle. Deploy air bag module as a unit except when disposing of vehicle.

Anchor air bag module in a vise secured to a firm foundation during deployment.

Deployment of air bag module (outside of vehicle)

- 1. Make an 8.5 mm (0.335 in) diameter hole in air bag module bracket (SST: J41246) at the position shown in figure at left.
- 2. Using wire, secure air bag module to air bag module bracket (SST: J41246) in two places as shown.

CAUTION:

Use wire of at least 1 mm (0.04 in) diameter.

Firmly secure air bag module bracket (SST: J41246) (with air bag module attached) in the vise.

Make sure vise is firmly secured and will not pivot.


 Connect deployment tool (SST: J38381) to air bag module connector.


- Connect red clip of deployment tool to battery positive terminal and black clip to negative terminal.
- The lamp on the right side of the tool, marked "deployment tool power", should glow green, not red.
- 7. Press the button on the deployment tool. The left side lamp on the tool, marked "air bag connector voltage", will illuminate and the air bag module will deploy.


CAUTION:

When deploying the air bag module, stand to the side of the module at least 5 m (16 ft) away.

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)







Disposal of Air Bag Module (Cont'd) DEPLOYMENT OF AIR BAG MODULE WHILE MOUNTED IN VEHICLE

When disposing of a vehicle, deploy air bag module while it is mounted in vehicle.

CAUTION:

When deploying air bag module, ensure vehicle is empty.

- 1. Turn ignition switch OFF, disconnect both battery cables and wait at least 3 minutes.
- 2. Disconnect air bag module connector.
- Connect deployment tool (SST: J38381) connector to air bag module.
- 4. Connect red clip of deployment tool to battery positive terminal and black clip to negative terminal.
- 5. The lamp on the right side of the tool, marked "deployment tool power", should glow green, not red.
- 6. Press the button on the deployment tool. The left side lamp on the tool, marked "air bag connector voltage", will illuminate and the air bag module will deploy.

DISPOSING OF AIR BAG MODULE

Deployed air bag module is very hot. Before disposing of air bag modules, wait at least 30 minutes. Seal them in a plastic bag before disposal.

CAUTION:

- Never apply water to a deployed air bag module.
- Be sure to wear gloves when handling a deployed air bag module.
- No poisonous gas is produced upon air bag module deployment. However, be careful not to inhale gas since it irritates throat and can cause choking.
- Do not attempt to disassemble air bag module.
- Air bag module cannot be reused.
- Wash your hands after finishing work.

BR

RA

MA

LC.

FE

CL

MT

AT

TF

PD)

ST

RS

BT

HA

EL

[D)X

RS-15 943

SUPPLEMENTAL RESTRAINT SYSTEM (SRS)

NOTES

944 RS-16

How to Perform Trouble Diagnoses for Quick and Accurate Repair

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

MA EM

G

INFORMATION FROM CUSTOMER

WHAT	Vehicle model
WHEN	Date, Frequencies
WHERE	Road conditions

LC

HOW Operating conditions, Symptoms

EC

PRELIMINARY CHECK

Check that the following parts are in good order.

- Battery [Refer to EL section ("BATTERY").]
- Fuse [Refer to EL section ("Fuse", "POWER SUPPLY ROUTING").]
- System component-to-harness connections

FE

CL

DIAGNOSIS FUNCTION

The SRS self-diagnosis results can be read by using "AIR BAG" warning lamp and/or CONSULT. The reading of these results is accomplished using one of two modes — "User mode" and "Diagnosis mode". The User mode is exclusively prepared for the customer (driver). This mode warns the driver of a system malfunction through the operation of the "AIR BAG" warning lamp.

AT.

MT

The Diagnosis mode allows the technician to locate and inspect the malfunctioning part.

The mode applications for the "AIR BAG" warning lamp and CONSULT are as follows:

	User mode	Diagnosis mode	Display type
"AIR BAG" warning lamp	Χ	X	ON-OFF operation
CONSULT		X	Monitoring

TF

[PD)

DIAGNOSIS MODE FOR CONSULT



SELF-DIAG [CURRENT]

A current Self-diagnosis result (also indicated by the number of warning lamp flashes in the Diagnosis mode) is displayed on the CONSULT screen in real time. This refers to a malfunctioning part requiring repairs.

BR

RA

SELF-DIAG [PAST]

Diagnosis results previously stored in the memory (also indicated by the warning lamp flashes in the Diagnosis mode) are displayed on the CONSULT screen. The stored results are not erased until memory erasing is executed.


ST

TROUBLE DIAG RECORD

With TROUBLE DIAG RECORD, diagnosis results previously erased by a reset operation can be displayed on the CONSULT screen.

RS

BT



ECU DISCRIMINATED NO.

The diagnosis sensor unit for each vehicle model is assigned with its own individual classification number. This number will be displayed on the CONSULT screen, as shown at left. When replacing the diagnosis sensor unit, refer to the part number for the compatibility. After installation, replacement with a correct unit can be checked by confirming this classification number on the CONSULT screen.

闆

For NISSAN MODEL D21, the diagnosis sensor unit classification numbers assigned are as follows:

2WD models: 40 4WD models: 45

945

RS-17


SRS154


How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

CAUTION:

- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.
- Do not attempt to repair, splice or modify the SRS wiring harness. If the harness is damaged, replace it with a new one.
- Keep ground portion clean.

WORK FLOW





ST

RS


BT


HA

RS-19 947

Wiring Diagram -SRS-


RS-SRS-01






ARS106-A

Wiring Diagram -SRS- (Cont'd)



AR\$106-B



Self-diagnosis

DIAGNOSTIC PROCEDURE 1


Checking SRS operation by using "AIR BAG" warning lamp — User mode

- 1. After turning ignition switch from OFF to ON, "AIR BAG" warning lamp operates.
- 2. Compare "AIR BAG" warning lamp operation to the chart below.

"AIR BAG" warning lamp operation — User mode —	SRS condition	Reference item
OFF 7 sec. MRS095A	No malfunction is detected. No further action is necessary.	
OFF 0.5 sec. 0.5 sec.	The system has a problem and needs to be repaired as indicated.	Go to DIAGNOSTIC PRO- CEDURE 2 or 3, RS-23 or 25.
MRS096A		
IGN ON	Air bag is deployed.	Go to COLLISION DIAGNOSIS, RS-38.
OFF MRS097A	Air bag fuse, diagnosis sensor unit or harness is malfunctioning and needs to be repaired.	Go to DIAGNOSTIC PRO- CEDURE 8, RS-36.
AVEOCHIM		
IGN ON ON OFF MRS098A	One of the following has occurred and needs to be repaired: Meter fuse is open "AIR BAG" warning lamp circuit is shorted or open Diagnosis sensor unit is malfunctioning	Go to DIAGNOSTIC PRO- CEDURE 9, RS-36.

NOTE:

If "AIR BAG" warning lamp operates differently from the operations shown above, refer to "AIR BAG" warning lamp operation — Diagnosis mode —, DIAGNOSTIC PROCEDURE 3 (step 4), RS-25.



RS-23 951

SELF-DIAG [CURRENT] FAILURE DETECTED * NO SELF DIAGNOSTIC FAILURE INDICATED. FURTHER TESTING MAY BE REQUIRED. ** ERASE | PRINT SRS049

Self-diagnosis (Cont'd)

 If no self-diagnostic failure is detected on SELF-DIAG [CURRENT] even though a malfunction is detected in DIAGNOSTIC PROCEDURE 1, go to DIAGNOSTIC PROCE-DURE 6, RS-31.


- 8. Touch PRINT.
- Compare diagnostic codes to the CONSULT DIAGNOSTIC CODE CHART.
- Touch BACK key of CONSULT until SELECT SYSTEM MODE appears, then turn off CONSULT.
- 11. Turn ignition switch OFF, then disconnect CONSULT and both battery cables.
- Repair the system as outlined by the Repair order that corresponds to the problem code in CONSULT DIAGNOSTIC CODE CHART. For replacement procedure of component parts, refer to RS-9.
- 13. After repairing the system, go to DIAGNOSTIC PROCEDURE 4, RS-26.

CONSULT DIAGNOSTIC CODE CHART

Diagnostic item	Explanation/Possible causes	Repair order *Recheck SRS using CONSULT at each replacement
NO SELF DIAGNOSTIC FAILURE INDICATED	No malfunction is detected.	Go to DIAGNOSTIC PROCEDURE 6, RS-31.
AIRBAG MODULE [OPEN]	 Air bag module circuit is open (including the spiral cable). 	Visually check wiring harness connections. Replace the harness if it has visible damage.
AIRBAG MODULE [VB-SHORT]	 Air bag module circuit is shorted to some power supply circuit (including the spiral cable). 	3. Replace air bag module. (Before disposing of it, it must be deployed.) 4. Replace spiral cable.
AIRBAG MODULE [GND-SHORT]	 Air bag module circuit is shorted to ground (including the spiral cable). 	5. Replace diagnosis sensor unit.
AIRBAG MODULE [SHORT]	Air bag module circuits are shorted to each other.	
CRASH ZONE SEN-CTR [OPEN/UPR-VB-SHORT] (4WD models)	 Crash zone sensor circuit is open, or Crash zone sensor circuit is shorted to some power supply circuit. 	 Visually check wiring harness connections. Replace the harness if it has visible damage. Replace crash zone sensor.
CRASH ZONE SEN-CTR [SHORT/UPR-GND-SHORT] (4WD models)	 Both crash zone sensor circuits are shorted, or Crash zone sensor circuit is shorted to ground. 	Replace diagnosis sensor unit. Replace airbag harness for crash zone sensor.
CONTROL UNIT	Diagnosis sensor unit is out of order.	 Visually check wiring harness connections. Replace diagnosis sensor unit. Replace the harness if it has visible damage.
INDEFINITE FAILURES [AIR BAG]	Low battery voltage.	Go to DIAGNOSTIC PROCEDURE 4, RS-26, after charging battery.

^{*}Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using the "AIR BAG" warning lamp (in User mode) or CONSULT each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.

952 RS-24



Self-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 3 () without CONSULT) Inspecting SRS malfunctioning parts by using "AIR BAG" warning lamp — Diagnosis mode

SRS will not enter Diagnosis mode if no malfunction is detected in User mode.

Open driver's door.

Turn ignition switch from OFF to ON.

Press driver's door switch at least 5 times within 7 seconds after turning ignition switch ON.


SRS is now in Diagnosis mode.

"AIR BAG" warning lamp operates in Diagnosis mode as follows:

NOTE:

If SRS does not enter Diagnosis mode even though malfunction is detected in User mode, go to DIAGNOSTIC PROCE-**DURE 10, RS-37.**

CL



Malfunctioning part is indicated by the number of flashes (part (d)). Compare the number of flashes to WARNING LAMP FLASH CODE CHART and locate malfunctioning part.

6. Turn ignition switch OFF, and disconnect both battery cables.

Repair the system as outlined by the Repair order in WARN-ING LAMP FLASH CODE CHART that corresponds to the flash code. For replacement procedure of component parts, refer to RS-9.

After repairing the system, go to DIAGNOSTIC PROCEDURE 5, RS-29.

RS-25 953

MA

GI

EM

MIT

FA

RS


BT

Self-diagnosis (Cont'd)

WARNING LAMP FLASH CODE CHART

Warning lamp	Flash code d (# of flashes)	Explanation	Repair order *Recheck SRS at each replacement
	0	No malfunction is detected.	Go to DIAGNOSTIC PROCEDURE 7, RS-32.
lamp	2	Air bag module circuit is out of order.	1. Visually check wiring harness connections. 2. Replace spiral cable. 3. Replace air bag module. (Before disposing of it, it must be deployed.) 4. Replace diagnosis sensor unit. 5. Replace main harness.
"AIR BAG" warning lamp	6	Crash zone sensor is out of order.	 Visually check wiring harness connections. Replace crash zone sensor. Replace diagnosis sensor unit. Replace air bag harness for crash zone sensor. Replace main harness.
	7	Diagnosis sensor unit is out of order.	Visually check wiring harness connections. Replace diagnosis sensor unit. Replace main harness.
i	9	• Low battery or SRS system voltage. ("Flash code 9" may not show up even if the battery voltage is low.)	Check and, if necessary, charge battery, then go to DIAGNOSTIC PROCEDURE 5, RS-29. Replace diagnosis sensor unit.

^{*}Follow the procedures in numerical order when repairing malfunctioning parts. Confirm whether malfunction is eliminated using the "AIR BAG" warning lamp (in User mode) or CONSULT each time repair is finished. If malfunction is still observed, proceed to the next step. When malfunction is eliminated, further repair work is not required.



NISSAN CONSULT START SUB MODE SRS046

DIAGNOSTIC PROCEDURE 4 (with CONSULT) Final checking after repairing SRS by using CONSULT — Diagnosis mode

- After repairing SRS, connect both battery cables.
- Connect CONSULT to data link connector.
- 3. Turn ignition switch from OFF to ON.


4. Touch START.

TROUBLE DIAGNOSES — Supplemental Restraint System (SRS) Self-diagnosis (Cont'd) **G**I 5. Touch AIRBAG. SELECT SYSTEM **ENGINE** MA **AIRBAG** EΜ LC. SBF884F EC Touch SELF-DIAG [CURRENT]. SELECT DIAG MODE SELF-DIAG [CURRENT] FE SELF-DIAG [PAST] TROUBLE DIAG RECORD CL ECU DISCRIMINATED NO. MT SRS047 7. If no malfunction is detected on SELF-DIAG [CURRENT], ■ SELF-DIAG [CURRENT] ■ L repair of SRS is completed. Touch ERASE. NOTE: FAILURE DETECTED TF Touch ERASE to erase problem (Trouble code) retained in **★ NO SELF DIAGNOSTIC** memory. Otherwise, the diagnosis sensor unit will still sense FAILURE INDICATED. a problem in memory when step 13 (Air bag warning lamp PD) **FURTHER TESTING** operation check) is performed. As a result, the "AIR BAG" MAY BE REQUIRED. ** warning lamp will still indicate a malfunction in the system. FA **ERASE** PRINT SRS049



 If any problem code was displayed on SELF-DIAG [CURRENT], the malfunctioning part is not repaired completely or another malfunctioning part is detected. Go to DIAGNOSTIC PROCEDURE 2, RS-23, and repair malfunctioning part completely.

8. Touch BACK key of CONSULT.



). Touch SELF-DIAG [PAST].

#A

RA

BR

ST

RS

BT


SELF-DIAG [PAST] FAILURE DETECTED * NO SELF DIAGNOSTIC FAILURE INDICATED. FURTHER TESTING MAY BE REQUIRED. ** PRINT SRS062

Self-diagnosis (Cont'd)

10. Check that no self-diagnostic failure is detected on SELF-DIAG [PAST].

- 11. Touch BACK key of CONSULT until SELECT SYSTEM MODE appears, turn off CONSULT, then disconnect CONSULT.
- 12. Turn ignition switch OFF.
- 13. Go to DIAGNOSTIC PROCEDURE 1, RS-22 to check SRS operation by using "AIR BAG" warning lamp with User mode.

RS-28



Self-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 5 (without CONSULT)
Final checking after repairing SRS by using "AIR BAG" warning lamp — Diagnosis mode and User mode

- 1. After repairing SRS connect both battery cables.
- 2. Open driver's door.
- 3. Turn ignition switch from OFF to ON.
- "AIR BAG" warning lamp operates in Diagnosis mode as follows:

,		
	MA	

(H

EM

LC

EC

No.	"AIR BAG" warning lamp operation — Diagnosis mode —		SRS condition	
1	OFF 7 sec. 3 sec. 2 sec. MRS100A	(a) through (b) are repeated.	No malfunction is detected or repair is completed. No further action is necessary.	Fii CL MT
2	ON (a) (b) (c) (d) (a) (b) (c) (d) (d) (o) (f) (f) (f) (f) (f) (f) (f) (f) (f) (f	(a) through (d) are repeated. NOTE: (a) — Interval I (b) — Start signal (Start signal identifies display modes) (c) — Interval II (d) — Indicates malfunctioning part (0.5 sec. ON and 0.5 sec. OFF is counted as one flash.)	The system has a problem and needs to be repaired.	AT TF PD

5. If "AIR BAG" warning lamp operates as shown in No. 1 in the chart above, turn ignition switch OFF to reset from Diagnosis mode to User mode, then go to step 6.

R:(8)

RA

If "AIR BAG" warning lamp operates as in No. 2 in chart above, the malfunctioning part is not repaired completely, or another malfunctioning part is detected. Go to DIAGNOSTIC PROCEDURE 3, RS-25, and repair malfunctioning part completely.

\$T

RS

Bī

HA

EL

Self-diagnosis (Cont'd)

6. Turn ignition switch ON. "AIR BAG" warning lamp operates in User mode. Compare "AIR BAG" warning lamp operation to the chart below.

NOTE:


If switching Diagnosis mode to User mode is required while malfunction is being detected, turn ignition switch from OFF to ON. Then press driver's door switch at least 5 times within 7 seconds after turning ignition switch ON. SRS is now in User mode.

"AIR BAG" warning lamp operation — User mode —	SRS condition	Reference item
OFF 7 sec. MRS095A	No malfunction is detected. No further action is necessary.	
OFF 0.5 sec. 0.5 sec.	The system has a problem and needs to be repaired as indicated.	Go to DIAGNOSTIC PRO- CEDURE 2 or 3, RS-23 or 25.
MRS096A		
IGN ON	Air bag is deployed.	Go to COLLISION DIAGNOSIS, RS-37.
ON OFF	Air bag fuse, diagnosis sensor unit or harness is malfunctioning and needs to be repaired.	Go to DIAGNOSTIC PRO- CEDURE 8, RS-35.
IGN ON ON OFF MRS098A	One of the following has occurred and needs to be repaired: Meter fuse is open "AIR BAG" warning lamp circuit is shorted or open Diagnosis sensor unit is malfunctioning	Go to DIAGNOSTIC PRO- CEDURE 9, RS-35.

958 RS-30

Self-diagnosis (Cont'd) DIAGNOSTIC PROCEDURE 6 (Continued from DIAGNOSTIC PROCEDURE 2)

Inspecting SRS malfunctioning record



G

ΜA

EMi

LC

EC

FE

CL

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR


St

RS

BT

HA


EL.




Self-diagnosis (Cont'd)

DIAGNOSTIC PROCEDURE 7 (with CONSULT)
Inspecting SRS intermittent problem by using CONSULT —
Diagnosis mode


- 1. Turn ignition switch OFF.
- 2. Connect CONSULT to data link connector.




- 3. Turn ignition switch ON.
- 4. Touch START.



5. Touch AIRBAG.



5. Touch SELF-DIAG [PAST].



7. If diagnostic codes are displayed on SELF-DIAG [PAST], go to step 10.

■ SELF-DIAG [PAST] FAILURE DETECTED * NO SELF DIAGNOSTIC FAILURE INDICATED. **FURTHER TESTING** MAY BE REQUIRED. ★ ★ PRINT SRS062 SELECT DIAG MODE SELF-DIAG [CURRENT] SELF-DIAG [PAST]

TROUBLE DIAG RECORD ECU DISCRIMINATED NO.

■ TROUBLE DIAG RECORD ■

PRINT

FAILURE DETECTED

ASSIST A/B MODULE

[OPEN]

. SRS055

SRS056

Self-diagnosis (Cont'd) If no self-diagnostic failure is detected on SELF-DIAG [PAST],

touch BACK and go back to SELECT DIAG MODE.

MA

EM

LC

Touch TROUBLE DIAG RECORD.

EC

FE

MT

Diagnostic code is displayed on TROUBLE DIAG RECORD.

TF

PD)

FA

RA

10. Touch PRINT.

11. Compare diagnostic codes to the INTERMITTENT PROBLEM DIAGNOSTIC CODE CHART.

Touch BACK key of CONSULT until SELECT SYSTEM MODE appears, then turn off CONSULT.

ST

13. Turn ignition switch OFF, then disconnect CONSULT and both battery cables.

RS

14. Repair the system as outlined by the Repair order that corresponds to the problem code in INTERMITTENT PROBLEM DIAGNOSTIC CODE CHART. For replacement procedure of component parts, refer to RS-9.

HA

EL


 $\mathbb{D}X$

15. Go to DIAGNOSTIC PROCEDURE 4, RS-26 for final checking.


Self-diagnosis (Cont'd) INTERMITTENT PROBLEM DIAGNOSTIC CODE CHART

Diagnostic item	Explanation	Repair order Recheck SRS at each replacement.	
NO SELF DIAGNOSTIC FAILURE INDICATED.	No malfunction is detected.	_	
AIRBAG MODULE [VB-SHORT]	 Air bag module circuit is shorted to some power supply circuit (including the spiral cable). 	 Visually check wiring harness connection. Replace harness if it has visible damage. Replace spiral cable. 	
AIRBAG MODULE [OPEN]	 Air bag module circuit is open (including the spiral cable). 	 Visually check wiring harness connection. Replace harness if it has visible damage. 	
AIRBAG MODULE [GND-SHORT]	 Air bag module circuit is shorted to ground (including the spiral cable). 	3. Replace spiral cable. 4. Replace air bag module. (Before disposing of it, it must be deployed.)	
AIRBAG MODULE [SHORT]	 Air bag module circuits are shorted to each other. 	(Delote disposing of it, it must be deployed.)	
CRASH ZONE SEN-CTR [OPEN/UPR-VB-SHORT] (4WD models)	 Crash zone sensor circuit is open, or Crash zone sensor circuit is shorted to a power supply circuit. 	Visually check wiring harness connections. Replace harness if it has visible damage.	
CRASH ZONE SEN-CTR [SHORT/UPR-GND-SHORT] (4WD models)	 Both crash zone sensor circuits are shorted, or Crash zone sensor circuit is shorted to ground. 	 Visually check wiring harness connections. Replace harness if it has visible damage. Replace crash zone sensor. 	
CONTROL UNIT	Diagnosis sensor unit is out of order.	Replace diagnosis sensor unit.	

RS-34 962



RS-35 963



ARS129

COLLISION DIAGNOSIS

(G) To repair the SRS, perform the following steps. When SRS is activated in a collision: (1) Replace the diagnosis sensor unit. MA (2) Remove the air bag module. (3) Check the SRS components using the table shown below: Replace any SRS components showing visible signs of damage (dents, cracks, deformation). EM (4) Install a new air bag module. (5) Conduct self-diagnosis using CONSULT and "AIR BAG" warning lamp. Refer to "Self diagnosis", RS-22, for details. Ensure that the entire SRS operates properly. LC When SRS is not activated in a collision: (1) Check the SRS components using the table shown below: Replace any SRS components showing visible signs of damage (dents, cracks, deformation). (2) Conduct self-diagnosis using CONSULT and "AIR BAG" warning lamp. Refer to "Self-diagnosis", RS-22 for details. Ensure that the entire SRS operates properly. FE SRS inspection SRS is activated Part SRS is NOT activated Air bag module REPLACE. 1. Remove air bag module. Check harness cover and connectors for damage, ter-Install with new minals for deformities, and harness for binding. holts. 2. Install air bag module into the steering wheel to check fit and alignment with the MT wheel. 3. If no damage is found, reinstall with new bolts. 4. If damaged—REPLACE. Air bag module must be deployed before discarding. Crash zone sensor 1. Check body and sensor bracket for deformities and rust. ÆΤ (4WD models) 2. Check sensor case for dents, cracks, scratches, deformities and rust. 3. Check sensor harness, connector, and terminals for binding, damage, and deformities. 4. If no damage is found, reinstall with new bolts. TE 5. If damaged—REPLACE. REPLACE. Diagnosis sensor 1. Check case and bracket for dents, cracks and deformities. unit Install with new 2. Check connectors for damage and terminals for deformities. PD) bolts. 3. If no damage is found, reinstall with new bolts. 4. If damaged—REPLACE. Steering wheel 1. Visually check steering wheel for deformities. 2. Check harness (built into steering wheel) and connectors for damage and terminals for deformities. 3. Install air bag module to check fit and alignment with steering wheel. 4. Check steering wheel for excessive free play. If no damage is found, reinstall with new bolts. RA 6. If damaged—REPLACE. Spiral cable 1. Visually check spiral cable and combination switch for damage. 2. Check connectors, flat cable and protective tape for damage. BR 3. Check steering wheel for noise, binding and heavy operation. 4. If no damage is found, reinstall with new bolts. 5. If damaged---REPLACE. Harness and Con-1. Check connectors for poor connection and damage and terminals for deformities. nectors 2. Check harness for binding, chafing, cuts and deformities. 3. If no damage is found, reinstall. 4. Damaged—REPLACE damaged section of harness. Do not attempt to repair, splice or modify any SRS RS harness.

EL

BT

HA

(D)X

BODY & TRIM

SECTION BT

MA

LC

EC

CONTENTS

PRECAUTIONS	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
GENERAL SERVICING	3
Clip and Fastener	3
BODY END	6
Front End	6
Rear End	7
Step Bumper	8
DOOR	
Front Door	9
INSTRUMENT PANEL	10
INTERIOR TRIM	13
Side and Floor Trim — Passenger room	13
Roof Trim	15
EXTERIOR	17
SEAT	23
Front Seat	23
Jump Seat — King Cab Model	24

SUNROOF 2	FE :5
Service Procedure2	
WINDSHIELD AND WINDOWS2	
Windshield2	~ —
Back Window2	8
Rear Side Window2	9 MT
MIRROR3	0
Door Mirror3	0
Rearview Mirror3	W-L
CAB AND REAR BODY3	
Removal3	2 ==
Cab Body3	11 7
Rear Body3	
Body Mounting3	
BODY ALIGNMENT3	
Engine Compartment3	
Underbody3	
•	300

- ★ For seat belt, refer to MA and RS section.
- ★ For wiring diagrams of body electrical systems, refer to EL section.

BR

 $\mathbb{R}\mathbb{A}$

RS

HA

IDX

PRECAUTIONS

- When removing or installing various parts, place a cloth or padding on the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc., carefully during removal or installation. Be careful not to soil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example, body outer panel, members, etc.), be sure to take rust prevention measures.



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

BT-2

Clip and Fastener

- Clips and fasteners in BT section correspond to the following numbers and symbols. Replace any clips and/or fasteners which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
(E)		Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.
	SBF302H	SBF367BA
©103)	SBF303H	Removal: Remove with a clip remover. SBF423H
(203) TO (5)	SBF258G	Push center pin to catching position. (Do not remove center pin by hitting it.) Installation: SBF708E
	SBF104B	Removal:

BT-3 969

Œ[

MA

IME

EC

LC

C[

FE

MT

AT.

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

HΑ

弎...

Clip and Fastener (Cont'd)

	Clip and rasteller (Cont d)	
Symbol No.	Shapes	Removal & Installation
© (10 9)	SBF351C	Removal: Remove by bending up with flat-bladed screwdrivers. Radiator grille Body panel
Œ11 3)	SBF353C	
	Clip-A Clip-B (Grommet)	Flat-bladed screwdriver Body panel Clip-A SBF652B
(a) (b) (b)	Clip-A Seal rubber Clip-B SBF648B	Removal: Clip-A Finisher Weatherstrip Clip-B Rubber seal Flat-bladed screwdriver SBF649B
(FIIA)	SBF317C	Panel Removal: Removal: Remove using flat-bladed screwdrivers or pliers. Panel Flat-bladed Clip screwdriver

GENERAL SERVICING

Clip and Fastener (Cont'd)

Symbol No.	Shapes	Removal & Installation
(FII)		Removal: Holder portion of clip must be spread out to remove rod.
	\$8F768B	SBF770B
	SBF145B	Removal: Rotate 45° to remove. Removal: SBF085B
(E) (E)		Removal: 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver.
	SBF078B	SBF992G

G]

 $\mathbb{M}\mathbb{A}$

LC

EC

FE

CL

MT

AT

TF

(d9

FA

RA

313

ST

RS


BT

HA

Front End

- Hood adjustment: Adjust at hinge portion.
- Hood lock adjustment: After adjusting, check hood lock control operation. Apply a coat of grease to hood lock engaging mechanism.
- Hood opener: Do not attempt to bend cable forcibly. Doing so could increase effort required to unlock hood.
- Bumper finisher: It is made of plastic. Do not use excessive force and keep oil away from it.

SEC. 260+261+262+620+623+650+656



Gi Rear End SEC. 930A • 940A MAEM LC 13 - 16 (1.3 - 1.6, 9 - 12) 21 - 26 (2.1 - 2.7, 15 - 20) EC Eye bolt FE 21 - 26 (2.1 - 2.7, 15 - 20) Rear gate striker CL O 62 - 78 (6.3 - 8.0, 46 - 58) MT 21 - 26 (2.1 - 2.7, AT 15 - 20) TF Rear gate Rear body -PD CR 103 FA ∠_[O] _{13 - 16} (1.3 - 1.6, 9 - 12) $\mathbb{R}\mathbb{A}$ ∠(CR 103) Rear gate handle Rear gate stay

ВТ

ST

RS

HA


O: N-m (kg-m, ft-lb)

Rear gate lock

: Should be lubricated with grease


ABT152


Step Bumper





Front Door


- For removal of door trim, refer to "INTERIOR TRIM", BT-13.
- After adjusting door lock, check door lock operation.











: N·m (kg-m, in-lb)

: N·m (kg-m, ft-lb)

: Should be lubricated with grease

ВТ

RS

G

MA

EM

1C

EC

FE

CL

MIT

AT

TF

PD

FA

RA

BR

ST

HA


EL

IDX

CAUTION:

- Disconnect both terminals from battery in advance.
- Disconnect air bag module connector in advance.
- Be careful not to scratch finishers and other parts.
- Never tamper with or force air bag lid open, as this may adversely affect air bag performance.

REMOVAL — Instrument panel assembly



INSTALLATION


Reverse the procedures described above.

Pay attention so as not to scratch the parts (plastic). During installation, fit the ducting parts exactly.

Gl

MA

SEC. 272•280•680•685•969



LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

3**T**


HA


EL


IDX


מעשונו


ABT154











ABT155


BT-12


Side and Floor Trim — Passenger room


- Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnish.
- When handling interior or exterior parts, do not use excessive force and take care not to damage them.

Regular Cab

SEC. 678•749•769•803•805•809







G1

MA

EC

FE

CL

MIT

FA

RA

BR

ST


RS


BT


HA


1

IDX










\di



Then remove the regulator handle from the regulator shaft.



Before installing, position the regulator handle clip as shown in figure 1.

45° Front

Push the regulator handle onto the regulator shaft.


Push the regulator handle onto the regulator shaft Install the regulator handle in place as shown in the figure with the window completely closed.

ABT217


King Cab


Side and Floor Trim — Passenger room (Cont'd)


SEC. 678•749•769•799•803•805•809
























remove it.

ABT160

Roof Trim

Regular Cab



A

EM

LC

ĒC

FI

C[_

MT

AT

TF

PD

RA

BR


ST

RS

HA


Roof Trim (Cont'd)

King Cab



EXTERIOR

Apply sealing compound where necessary while installing parts. When applying sealing compound, be careful that the sealing compound does not protrude from parts.



G

MA

EM

LC

EC

FE

CL

WIT

AT

PD

TF

FA

 $\mathbb{R}\mathbb{A}$


BR

ST


RS

 $\mathbb{H}\mathbb{A}$

1 2 Cowl top sealing rubber & grille




3 Windshield upper molding



Method 2

- 1. Cut off sealant at glass end.
- 2. Clean the side on which panel was mounted.
- Set molding fastener and apply sealant & primer to body panel, and apply primer to molding.




 Install molding by aligning the molding mark located on center with vehicle center.


Be sure to install tightly so that there is no gap around the corner.

ABT168


4 5 Windshield side & lower molding




6 Drip weatherstrip




8 Door weatherstrip



7 Body side welt



9 Door corner cover



MA

Gi

EM

LC

EC

FE

GL

7.052

MT

AT

(PD)

TF

FA

RA

8R

ST

RS


ВТ

9.8.0


HA

EL


10 Door waist inner seal




11 Door waist outer seal



12) Drafter duct




13 Back window




BT-20


(14) (15) Rear side window weatherstrip and rear side window protector



⊕ ⊕ Sunroof weatherstrip and lid protector



[®] High-mounted stop lamp



RS


G[

ВТ


ΉA

DX

(9) 20 Fender protector and mudguard



② Step bumper cover




BT-22

• When removing or installing the seat trim, carefully handle it to keep dirt out and avoid damage.

Front Seat

BUCKET SEAT



ABT180

G

MA

闖例

LC

EC

FE

CL

MT

AT

77

1910)

FA

RA

있입


ST

RS


DX


BENCH SEAT

Front Seat (Cont'd)




Jump Seat — King Cab Model







ABT183

WINDSHIELD AND WINDOWS







REMOVAL

After removing moldings, remove glass using piano wire or power cutting tool and an inflatable pump bag.

CAUTION:

Be careful not to scratch glass when removing.

INSTALLATION

- Use genuine Nissan Sealant kit or equivalent. Follow instructions furnished with it.
- After installation, the vehicle should remain stationary until the sealant hardens.

WARNING:

Keep heat and open flames away as primers are flammable.

CAUTION:


Advise the user not to drive the vehicle on rough roads or surfaces for 24 hours after installation.

- Do not use sealant which is past its usable term.
- Do not leave cartridge unattended with its cap open.
- Keep primers and sealant in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Molding must be installed securely so that it is in position and leaves no gap.


BT-26

Windshield

Body side



Sealant application areas



19/4

G[

MA

EC

Æ

CL

Mï

AĪ

TF

P.D)



BT



EL

 $\mathbb{D}\mathbb{X}$

WINDSHIELD AND WINDOWS

Windshield (Cont'd)

REPAIRING WATER LEAKS FOR WINDSHIELD


Leaks can be repaired without removing and reinstalling glass.

If water is leaking between caulking material and body or glass, determine the extent of the leak. This can be done by applying water while pushing glass outward.

To stop the leak, apply primer (if necessary) and then sealant to the leak point.


Back Window

- Window glass is held in place by weatherstripping. For details regarding weatherstrip, refer to "EXTERIOR", BT-17.
- Using sealant, fill gaps between vehicle body and weatherstrip as necessary.



WINDSHIELD AND WINDOWS

Rear Side Window



G!

MA

EC

FE

CL

MT

AT

TF

PD

FA

RA

ST


R\$

HA

EL

IDX

Door Mirror





★ For Wiring Diagram, refer to "MIRROR" in EL section.

Rearview Mirror

REMOVAL

Remove rearview mirror by deflecting spring with screwdriver as shown in the figure.





INSTALLATION

- Install mounting bracket as follows:
- a. Determine mounting bracket position on windshield by measuring from top of windshield to top of mounting bracket as shown in the figure.
- Mark location on outside of windshield with wax pencil or equivalent.
- Clean attaching point on inside of windshield with an alcoholsaturated paper towel.
- d. Sand bonding surface of mounting bracket with sandpaper (No. 320 or No. 360).
- Clean bonding surface of mounting bracket with an alcoholsaturated paper towel.
- f. Apply Loctite Adhesive 11067-2 or equivalent to bonding surface of mounting bracket.
- g. Install mounting bracket at premarked position and press mounting bracket against glass for 30 to 60 seconds.
- After five minutes, wipe off excess adhesive with an alcoholmoistened paper towel.
- 2. Install rearview mirror.

G[

MA

ΞM

LC

EC

FE

CL

MŤ

נו נולאנו

AT

TF

PD

FA

RA

BR

ST

⊕u

--9G


DΤ


BT

ĽΙΛ

HA

1DX





998

Removal

CAB BODY

- Remove the following parts in engine compartment at least.
- (1) Main harness and other wiring harnesses
- Disconnect brake and clutch lines in engine compartment.
- Remove the following parts from underbody at least.
 Transmission and transfer control levers
- (2) Parking brake control lever and cables
- (3) Main harness and other wiring harnesses


REAR BODY


- Remove the following parts at least.
- (1) Rear combination lamp and license plate lamp harness
- (2) Fuel filler tube fixing screws

BT-32

Body Mounting


When installing, be sure to use new bolts and nuts (sealant applied bolts or self-lock nuts are used for all mounting).






20 - 24 (2.0 - 2.4)14 - 17)

Section (D)



Section (E)



: N·m (kg-m, ft-lb)

SBF350C

BT-33

G

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT

HA

IDX

BODY ALIGNMENT

- All dimensions indicated in figures are actual ones.
- When using a tracking gauge, adjust both pointers to equal length. Make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- All measurements and mounting hole diameters are expressed in millimeters (mm).
- An asterisk (*) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the respective dimension lines in the directions of "x", "y" and "z".

Dimension lines: "x" line — Center line of vehicle

"y" line — Center line of front axle (Any measurement point in front of the dimension line refers to a minus "—" value.)

"z" line — Datum line (Any measurement point under the dimension line refers to a minus "—" value.)

2W.SB

2W.LB

4W.SB

4W.LB

: Short wheelbase (2WD)

: Long wheelbase (2WD)

: Short wheelbase (4WD)

: Long wheelbase (4WD)

2W : 2WD

4W : 4WD


SB : Short wheelbase

LB : Long wheelbase


R : Regular Cab

K : King Cab

BT-34



DETAILED MEASUREMENT POINTS



MBF726A


BT-35

IDX

Underbody

MEASUREMENT POINTS

2WD models





Underbody (Cont'd)

MEASUREMENT POINTS

4WD models

R|: Regular cab **K**|: King cab





GI

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS

ВТ


HA


SBT185

MEASUREMENT

Underbody (Cont'd)

2WD models





Underbody (Cont'd)

Gl

MA

EM

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT


MA

EL

[DX

4WD models





BT-39 1005

BODY ALIGNMENT

Underbody (Cont'd)

DETAILED MEASUREMENT POINTS

Points	Hole dia.	Detailed noints			Coordinates mm			
Points	mm	Detailed points		"x"	"у"	"z"		
(A) (a)	24			450.0	-488.5	2W 21.2 4W: 71.2		
© ©	28		Cab body or rear body mounting insulator mounting hole	605.0	597.5	2W : -28.2 4W : 21.8		
(D) (d)	85			593.5	R: 1,637.0 K: 1,987.0	2W : ~15.0 4W : 35.0		
(F) (T)	18			570.0	SB: 2,050.0 LB: 2,350.0	2W: 171.8 4W: 221.8		
① ①	18		Cab body or rear body	565.0	SB: 3,286.0 LB: 3,586.0	2W: 171.8 4W: 221.8		
(L) (I)	22		mounting insu- lator mounting hole	505.0	SB: 3,530.0 LB: 3,830.0	220.0		
® b	2W : 15 4W : 15.3	2WD B 4WD B SBF668C	Hole for front shock absorber mounting at the bracket	2W : 434.7 4W : 439.7	2W : 5.6 4W : 1.4	2W : 203.2 4W : 142.0		
© 9	12	Front mounting bracket Inner side SBF795G	Hole for rear spring front mounting at the bracket	2W]: 469.0 4W]: 470.5	2W.SB: 2,059.0 2W.LB: 2,359.0 4W.SB: 2,080.0 4W.LB: 2,380.0	2W]: -152.0 4W]: -86.0		

BODY ALIGNMENT

		Underbody (Co	nt'd)				_ (
Points	Hole dia.	Hole dia.		Coordinates mm		ım	- (
	mm	Detailed points	Detailed points		"y"	"z"	_ [
H h	33	Front Rear mounting bracket Inner side SBF796G	Hole for rear spring rear mounting at the bracket	480.0	2W.SB: 3,209.0 2W.LB: 3,509.0 4W.SB: 3,240.0 4W.LB: 3,540.0	2W : 30.0 4W : 43.0	[]
(k) (k)	22	Side member outer	Hole for body mounting at rear of side member outer	505.0	SB: 3,530.0 LB: 3,830.0	170.0	_ Q Q T
(M) (m)	27	Front Tension rod bracket M m SBF798G	Hole for tension rod mounting at the bracket	254.6	417.1	-92.3	- GC CC CCC CCC CCC CCC CCC CCC CCC CCC
(S)	9	Bumper rubber SBF799G	Hole for locat- ing at bound bumper bracket	359.5	-3.2	-23.5	

BT-41 1007

BODY ALIGNMENT Underbody (Cont'd)

District	Hole dia. mm	Detailed points		Coordinates mm			
Points				"x"	"у"	"z"	
P P	10.5	SBF800G	Hole for rebound bumper mounting at lower link bracket	447.0	-88.0	-14.9	
@ @	27	Compression rod bracket Front a @ @ SBF801G	Hole for com- pression rod mounting at the bracket	361.1	294.5	-158.9	
® •	13	Side member outer R (r) SBF802G	Hole for wax- ing at lower side of side member outer	510.0	1,040.0	-135.0	

HEATER & AIR CONDITIONER

SECTION HA

MA

LC

CONTENTS

PRECAUTIONS AND PREPARATION2	Trouble Diagnoses for Abnormal Pressure	25
Precautions for Supplemental Restraint System	Harness Layout	28
(SRS) "AIR BAG"2	Circuit Diagram	29
Introduction3	Wiring Diagram ~HEATER	30
Precautions for Working with R-134a4	Wiring Diagram -A/C	31
General Refrigerant Precautions4	Main Power Supply and Ground Circuit Check	
Precautions for Refrigerant Connection5	Diagnostic Procedure 1	34
Precautions for Servicing Compressor6	Electrical Components Inspection	41
Special Service Tools6	Control Linkage Adjustment	42
R-134a Service Tools and Equipment7	SERVICE PROCEDURES	44
Precautions for Service Equipment9	Checking Refrigerant Leaks	44
DESCRIPTION11	Refrigerant Lines	47
Refrigeration Cycle11	R-134a Service Procedure	48
Component Layout12	Compressor Lubricant Quantity	50
Discharge Air Flow13	Compressor Mounting	52
Control Operation14	Belt Tension	
TROUBLE DIAGNOSES15	Fast Idle Control Device (FICD)	52
How to Perform Trouble Diagnoses for Quick	Condenser	
and Accurate Repair15	Compressor	53
Operational Check16	Compressor Clutch	53
Symptom Chart18	Thermal Protector	56
Preliminary Check19	SERVICE DATA AND SPECIFICATIONS (SDS)	57
Performance Test Diagnoses22	General Specifications	57
Performance Chart24	Inspection and Adjustment	57

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".
- See EL section, "POWER SUPPLY ROUTING" for power distribution circuit. When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

EC

E.E

CL

AT

TF

FA 2

 $\mathbb{R}\mathbb{A}$

88

RS

BT

HA

EL

1DX

Precautions for Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, warning lamp, wiring harness, a crash zone sensor (4WD models) and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.


Introduction

To prevent the ozone layer from being destroyed, R-134a refrigerant has replaced the previously used CFC-12 (R-12).


The new and previous service tools, refrigerant, lubricant, etc. are not interchangeable due to differences in their physical properties and characteristics.

Always service the R-134a air conditioner system using the specified tools, lubricant and refrigerant, observing the following precautions:

Identification IDENTIFICATION LABEL FOR VEHICLE



PARTS IDENTIFICATION



HA-3 1011

Gil

MA

LC

FE

3[.

MT

AT

TF

PD

FA

RA

ST

KS

НА

IDX

Precautions for Working with R-134a

WARNING:

- CFC-12 (R-12) refrigerant and R-134a refrigerant are not compatible. These refrigerants must never be mixed, even in the smallest amounts. If the refrigerants are mixed, compressor malfunction is likely.
- Use only specified lubricant for the R-134a A/C system and R-134a components. If lubricant other than that specified is used, compressor malfunction is likely.
- The specified R-134a lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - a: When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b: When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into the system.
 - c: Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - d: Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system, using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment), or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e: Do not allow lubricant to contact styrofoam parts. Damage may result.

General Refrigerant Precautions

WARNING:

- Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioner system is discharged.
- Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioner system.
- Do not store or heat refrigerant containers above 52°C (125°F).
- Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.
- Do not intentionally drop, puncture, or incinerate refrigerant containers.
- Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.
- Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.
- Do not introduce compressed air into any refrigerant container or refrigerant component.

Precautions for Refrigerant Connection

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.

CAUTION:


When replacing or cleaning refrigerant cycle components, observe the following.

- Do not leave compressor on its side or upside down for more than 10 minutes. Compressor lubricant will enter low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, immediately plug all openings to prevent entry of dirt and moisture.
- When installing an air conditioner in the vehicle, connect the pipes as the final stage of the operation. Do not remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to portions shown in illustration. Be careful not to apply lubricant to threaded portion.

Lubricant name: Nissan A/C System Oil Type R

Part number: KLH00-PAGR0

- O-ring must be closely attached to inflated portion of tube.
- After inserting tube into union until O-ring is no longer visible, tighten nut to specified torque.
- After connecting line, conduct leak test and make sure that there is no leakage. When the gas
 leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal
 seat to the specified torque.



HA

(GII

MA

[L]

CL.

MT

Precautions for Servicing Compressor

- Plug all openings to prevent moisture and foreign matter from entering.
- Do not leave compressor on its side or upside down for more than 10 minutes. Compressor lubricant will enter low pressure chamber.
- When replacing or repairing compressor, be sure to remove lubricant from the compessor and check the lubricant quantity extracted.
- When replacing or repairing compressor, follow Lubricant Checking and Adjusting Procedure exactly. Refer to "Compressor Lubricant Quantity", "SERVICE PROCEDURES", HA-50.
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated, with oil, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour.
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation.

Special Service Tools

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
KV99231260 (J-38874) Clutch disc wrench	NT204	Removing shaft nut and clutch disc
KV99232340 (J-38874) Clutch disc puller	NT206	Removing clutch disc
KV99234330 (J-39024) Pulley installer	NT207	Installing pulley
KV99233130 (J-39023) Center pulley puller	NT208	Removing pulley

R-134a Service Tools and Equipment

(G)

MA

剛

Never mix R-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant. Separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubricant.

Refrigerant container fittings, service hose fittings and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and R-134a. This is to avoid mixed use of the refrigerants/lubricant.

Adapters to convert from one size fitting to the other must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.

Tool number (Kent-Moore No.) Tool name	Description	Note
R-134a refrigerant		Container color: Light blue Container marking: R-134a Fitting size: Thread size Iarge container 1/2"-16 ACME
KLH00-PAGR0	NT196	Type: Polyalkyline glycol oil (PAG), type R
(—) Nissan A/C System Oil Type R	MSZAN	Application: R-134a vane rotary compressors (Nissan only) Lubricity: 40 ml (1.4 US fl oz, 1.4 Imp fl oz)
	NT197	
J-39500-NI) Recovery/Recycling equipment (ACR4)		Function: Refrigerant Recovery and Recycling
	NT195	3411
J-39400) Electrical leak detector		Power supply: ● DC 12 V (Cigarette lighter)
	0000	
	NT198	Libert Control
J-39183) Manifold gauge set (with noses and couplers)		Identification: The gauge face indicates R-134a. Fitting size: Thread size 1/2"-16 ACME
	NT199	

HA-7 1015

R-134a Service Tools and Equipment (Cont'd)

		Tools and Equipment (Cont d)
Tool number (Kent-Moore No.) Tool name	Description	Note
Service hoses High side hose (J-39501-72) Low side hose (J-39502-72) Utility hose (J-39476-72)		Hose color: Low hose: Blue with black stripe High hose: Red with black stripe Utility hose: Yellow with black stripe or green with black stripe Hose fitting to gauge: 1/2"-16 ACME
Service couplers High side coupler (J-39500-20) Low side coupler (J-39500-24)	NT201	Hose fitting to service hose: ■ M14 x 1.5 fitting (optional) or permanently attached.
(J-39650) Refrigerant weight scale	NT200	For measuring of refrigerant Fitting size: Thread size ■ 1/2"-16 ACME
(J-39649) Vacuum pump (Including the isolator valve)		Capacity: • Air displacement: 4 CFM • Micron rating: 20 microns • Oil capacity: 482 g (17 oz) Fitting size: Thread size • 1/2"-16 ACME
	NT203	

Precautions for Service Equipment

RECOVERY/RECYCLING EQUIPMENT

Follow the manufacturer's instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

MA

(GII

ELECTRONIC LEAK DETECTOR

Follow the manufacturer's instructions for tester operation and tester maintenance.



LC,

EC



The lubricating oil contained inside the vacuum pump is not compatible with the specified lubricant for R-134a A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. Therefore, if the pump is switched off after evacuation, the lubricating oil may migrate into the hose. To prevent this, isolate the pump from the hose after evacuation (vacuuming).



This migration is avoided by placing a manual shut-off valve near the hose-to-pump connection, as follows:

MT

 Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.

For pumps without an isolator valve, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to

TF

isolate the hose from the pump.
If the hose has an automatic shut-off valve, disconnect the hose from the pump: as long as the hose is connected, the valve is open and lubricating oil may migrate.

PD

Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.

FA

MANIFOLD GAUGE SET

RA

Be certain the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant R-134a along with specified lubricant.

98




RS


BT


Be certain that the service hoses display the markings described (colored hose with black stripe). Be certain that all hoses include a positive shut-off device (either manual or automatic) near the end of the hoses opposite the manifold gauge.




[DX








SERVICE HOSES





Precautions for Service Equipment (Cont'd) SERVICE COUPLERS

Never attempt to connect R-134a service couplers to an CFC-12 (R-12) A/C system. The R-134a couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur

Shut-off valve rotation	A/C service valve		
Clockwise	Ореп		
Counterclockwise	Close		

REFRIGERANT WEIGHT SCALE

When using a scale which controls refrigerant flow electronically, assure the following:

- Hose fitting size is 1/2"-16 ACME
- No refrigerant other than R-134a (along with specified lubricant) has been used with the scale.

CHARGING CYLINDER

Using a charging cylinder is not recommended. Refrigerant may be vented into the air through the cylinder's top valve when filling the cylinder.

Refrigeration Cycle

REFRIGERANT FLOW

The refrigerant flows in the standard pattern. It flows from compressor through condenser, liquid tank, evaporator and back to compressor.

The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.

FREEZE PROTECTION

The compressor cycles on and off to maintain the evaporator temperature within a specified range. When the evaporator coil temperature falls below a specified point, the thermo control amplifier interrupts the compressor operation. When the evaporator coil temperature rises above the specification, the thermo control amplifier allows compressor operation.


REFRIGERANT SYSTEM PROTECTION

Dual-pressure switch

The refrigerant system is protected against excessively high or low pressure. The protection is effected by the dual-pressure switch located on the liquid tank. If the pressure rises or falls out of specifications, the switch opens to interrupt the compressor operation.

Pressure relief valve

The refrigerant system is also protected by a pressure relief valve. The valve is located on the end of high flexible hose near compressor. When refrigerant pressure in the system increases abnormally [over 3,727 kPa (38 kg/cm², 540 psi)], the relief valve's release port opens automatically. The valve then releases refrigerant into the atmosphere.



HA-11 ₁₀₁₉

GII

MA

LĈ

FE

EG

. . .

CL

MT

Al

TF

FA

 $\mathbb{R}\mathbb{A}$

BR

ST


RS

BT

на

EL


Component Layout





^{*:} For removal, it is necessary to remove instrument assembly.

Discharge Air Flow


Air outlets

















EL

AHA819

DX

Gl

MA

LC

EĈ

FE

CL

MT

AT

TF

PD)

FA

RA

BR


ST

RS

BT

HA

Control Operation



FAN CONTROL LEVER

This lever controls fan speed and turns the fan ON and OFF.

MODE CONTROL LEVER

This lever controls the outlet air flow.

TEMPERATURE CONTROL LEVER

This lever allows adjustment of the temperature of the outlet air.

RECIRCULATION CONTROL LEVER

FRESH Sposition:

Outside air is drawn into the passenger compartment.

Recirculation REC position:

Interior air is recirculated inside the vehicle.

AIR CONDITIONER SWITCH

The air conditioner switch controls the A/C system. When the switch is depressed with the fan ON, the compressor will turn ON. The indicator lamp will also light.

The air conditioner cooling function operates only when the engine is running.

@! How to Perform Trouble Diagnoses for Quick and Accurate Repair **WORK FLOW** MA CHECK IN Reference item EW LISTEN TO CUSTOMER COMPLAINT AND CON-Operational Check LC FIRM BY PERFORMING OPERATIONAL CHECK. Refer to HA-16. EC INVESTIGATE ITEMS YOU SHOULD CARRY OUT Symptom Chart RELATED TO EACH SYMPTOM. Refer to HA-18. FE CL CHECK FOR ANY SERVICE BULLETINS. MT ELIMINATE GOOD SYSTEM(S)/PART(S). Preliminary Check Refer to HA-19. AT CHECK MAIN POWER SUPPLY AND GROUND CIR-Main Power Supply and CUITS. Ground Circuit Check TF Refer to HA-33. PD Diagnostic Proce-ELIMINATE GOOD PART(S)/HARNESS(ES)/ Harness Layout dure(s) CONNECTOR(S) ELECTRICALLY. Refer to HA-28. Refer to HA-34. FA Malfunctioning Circuit Diagram Refer to HA-29. part(s) RA Malfunctioning **Electrical Components INSPECT EACH** harness(es)/ COMPONENT. Inspection connector(s) Refer to HA-41. BR REPAIR/REPLACE. REPAIR. ST RS FINAL CHECK NG OK 87 CHECK OUT EL

HA-15 1023


1D)X

Operational Check

The purpose of the operational check is to confirm that the system operates properly.


CONDITIONS:

Engine running at normal operating temperature.




PROCEDURE:

- 1. Check blower
- Slide fan control lever to 1-speed. Blower should operate on 1-speed.
- Slide fan control lever to 2-speed and continue checking blower speed until all speeds are checked.
- Leave blower on 4-speed.




Check discharge air

- Slide mode control lever to 🐩 position.
- Confirm that all discharge air comes out of face vents.
- Slide mode control lever to 👣 position.
- d. Confirm that discharge air comes out of face vents and foot
- e. Slide mode control lever to J position.
- Confirm that discharge air comes out of foot vents, with some air from defrost vents.
- g. Slide mode control lever to position.h. Confirm that discharge air comes out of foot vents with some air from defrost vents.
- Slide mode control lever to position. İ.
- Confirm that all discharge air comes out of defrost vents.



3. Check recirculation

- Slide recirculation control lever to the REC position.
- Listen for intake door position change (you should hear blower sound change slightly).



0

食るでき

Operational Check (Cont'd)

- 4. Check temperature decrease
- a. Slide temperature control lever to full cold.
- o. Check for cold air at discharge air outlets.



MA

G[

LG



EC

- a. Slide temperature control lever to full hot.
- b. Check for hot air at discharge air outlets.

CL

MT

6. Check A/C switch

AT

TF

Move fan control lever to the desired position (1 to 4) and press air conditioner switch to turn air conditioner ON. Indicator light will come on when air conditioner is ON.

PD)

ir1E9

FA

RA

BR


ST

RS

BT

HA

IDX




Symptom Chart

DIAGNOSTIC TABLE

PROCEDURE		elimin Checl	-	no Pro	ag- stic oce- ire	Su Gro	in Po ipply a und C Checl	and ircuit			Elect	rical (Compo	onents	Insp	ection		
REFERENCE PAGE	HA-19	HA-20	HA-21	HA-34	HA-37		HA-33		HA-41	HA-41	HA-41	HA-41	HA-42	HA-42	HA-41	HA-53	HA-42	
		2	3	re 1	re 2	4 and 5)									ts.		Complessor	
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Diagnostic procedure	Diagnostic procedure	15A Fuses (Nos. Z	10A Fuse (No. [6]	15A Fuse (No. 3	Blower motor	Resistor	A/C switch	Fan switch	Blower motor relay	A/C relay	Dual-pressure switch	Magnet clutch	Thermal protector	Harness
A/C does not blow cold air.	0			0		0	0	0	0	0	0	0	0	0	0	0	0	0
Blower motor does not rotate.	0			0		0			0	0		0	0					0
Magnet clutch does not engage when A/C switch and fan switch are ON.	0				0		0	0			0	0	0	0	0	0	0	0
Noise.		0																
Insufficient heating.			0	0														0

^{1, 2:} The number means checking order.

[:] Checking order depends on malfunction in flow chart.



HA-19

1027

Preliminary Check (Cont'd)

PRELIMINARY CHECK 2 Noise. CHECK WHERE NOISE COMES FROM. Refrigerant line Belt Blower motor Compressor Expansion valve CHECK FOR Inspect the com-Replace expan-NOISE IN ALL pressor clutch and sion valve. MODES AND pulley and idler **TEMPERATURE** pulley. SETTINGS. NG OK Noise is constant CHECK Line is fixed Line is not fixed. Replace com-**BLOWER** pressor clutch directly to body. and pulley. MOTOR AND FAN FOR Refer to WEAR. HA-53. OK NG Replace CHECK DISC-TO-Fix line with Fix line tightly. **PULLEY CLEAR**rubber or vibrablower motor or ANCE. tion absorbing Refer to HA-55. material. fan. OK CHECK CHECK AND **BLOWER** ADJUST COM-MOTOR FOR **PRESSOR** FOREIGN PAR-LUBRICANT. TICLES. Refer to HA-50. NG OK Side of belt is Belt vibration is Remove foreign Replace compresparticles from sor and liquid intense. worn out. intake unit. tank. Noise is Pulley center Readjust belt intermittent tension. does not match. CHECK AIR DIS-Refer to MA Readjust pulley CHARGE DUCTS center. section FOR OBSTRUC-("Checking Refer to HA-54. Drive Belts", TIONS, FOREIGN MATERIALS OR "ENGINE MAINTE-AIR LEAKAGE. NANCE").

NG

Remove obstructions or repair air leakage.

TROUBLE DIAGNOSES **Preliminary Check (Cont'd)** GI MA DOES AIR FLOW FROM FOOT AREA? Condition: CHECK BLOWER MOTOR Vehicle at operating temperature. No OPERATION. EW Ignition switch and fan switch are ON. Go to Diagnostic Procedure Mode control lever is in FOOT position and tem-1, HA-34. perature control lever is in full hot position. LC Yes EC Check the following: Engine coolant level. Refer to MA section. NG Hoses for leaks or kinks. Repair/replace as necessary. Radiator cap. Refer to LC section ("ENGINE FE COOLING SYSTEM"). Air in cooling system. GL OK CHECK WATER COCK OPERATION. MT NG Warm up engine before checking. Adjust or replace water cock. Refer to "Control Linkage Adjustment", HA-43. AT OK CHECK TEMPERATURE CONTROL CABLE. NG Adjust temperature control TF Refer to "Control Linkage Adjustment", HA-43. cable. OK PD) VISUALLY INSPECT AIR MIX DOOR. Replace air mix door. Access by removing instrument panel. EA OK RA CHECK BY FEEL HEATER INLET AND OUTLET Both hoses Both hoses 問問 warm ST **CHECK THERMOSTAT** CHECK HEATER HOSES FOR PROPER INSTALLATION. RS OK OK Back flush heater core, drain and refill coolant. Replace thermostat. Refer

PRELIMINARY CHECK 3 Insufficient heating.

HOSES.

cold

to LC section ("Thermostat". "ENGINE COOLING SYS-

INSTALLATION.

TEM").

HA-21

Both hoses

warm

Replace heater

core.

Retest.

Hot inlet

System OK

Warm outlet


RT


IIDX

1029

Performance Test Diagnoses

INSUFFICIENT COOLING





EL

Performance Chart

TEST CONDITION

Testing must be performed as follows:

Vehicle location: Indoors or in the shade (in a well-ventilated place)

Doors: Closed
Door window: Open
Hood: Open
TEMP setting: Max CO

TEMP. setting: Max. COLD Discharge air: FACE VENT

INTAKE lever position: (Recirculation)

FAN speed: 4-speed Engine speed: 1,500 rpm

Operate the air conditioner system for 10 minutes before taking measurements.

TEST READING

Recirculating-to-discharge air temperature table

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator			
Relative humidity %	Air temperature °C (°F)	°C (°F)			
	20 (68)	6.6 - 8.3 (44 - 47)			
	25 (77)	10.4 - 12.4 (51 - 54)			
50 - 60	30 (86)	14.2 - 16.7 (58 - 62)			
	35 (95)	18.2 - 21.0 (65 - 70)			
	40 (104)	22.0 - 25.2 (72 - 77)			
	20 (68)	8.3 - 9.8 (47 - 50)			
	25 (77)	12.4 - 14.4 (54 - 58)			
60 - 70	30 (86)	16.7 - 18.9 (62 - 66)			
	35 (95)	21.0 - 23.6 (70 - 74)			
	40 (104)	25.2 - 28.1 (77 - 83)			

Ambient air temperature-to-operating pressure table

Ambie	ent air	High property (Discharge side)	Law pressure (Susting side)		
Relative humidity %	Air temperature °C (°F)	High-pressure (Discharge side) kPa (kg/cm², psi)	Low-pressure (Suction side) kPa (kg/cm², psi)		
	20 (68)	961 - 1,187 (9.8 - 12.1, 139 - 172)	108 - 157 (1.1 - 1.6, 16 - 23)		
	25 (77)	1,295 - 1,599 (13.2 - 16.3, 188 - 232)	161.8 - 215.8 (1.65 - 2.2, 23.5 - 31.3)		
50 - 70	30 (86)	1,285 - 1,569 (13.1 - 16, 186 - 228)	167 - 216 (1.7 - 2.2, 24 - 31)		
	35 (95)	1,520 - 1,863 (15.5 - 19, 220 - 270)	235 - 284 (2.4 - 2.9, 34 - 41)		
	40 (104)	1,765 - 2,158 (18 - 22, 256 - 313)	289.3 - 353.1 (2.95 - 3.6, 41.9 - 51.2)		

Trouble Diagnoses for Abnormal Pressure

GI

MA

Whenever system's high or low-pressure side is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following table indicates the standard (normal) pressure range. Since the standard (normal) pressure differs from vehicle to vehicle, refer to HA-24 ("Ambient air temperature-to-operating pressure table").

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
oth high and low-pressure des are too high.	 Pressure is reduced soon after water is splashed on condenser. 	Excessive refrigerant charge in refrigeration cycle.	Reduce refrigerant until speci- fied pressure is obtained.
	Air suction by cooling fan is insufficient.	Insufficient condenser cooling performance. 1 Condenser fins are clogged. 2 Improper fan rotation of cooling fan.	 Clean condenser. Check and repair cooling fan as necessary.
AC359A	 Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter. 	Poor heat exchange in condenser. (After compressor operation stops, high pressure decreases too slowly.) Air in refrigeration cycle.	Evacuate repeatedly and recharge system.
	Engine tends to overheat.	Engine cooling systems mal- function.	Check and repair each engine cooling system.
	An area of the low-pressure pipe is colder than areas near the evaporator outlet.	Excessive liquid refrigerant on low-pressure side. Excessive refrigerant dis-	Replace expansion valve.
	Plates are sometimes covered with frost.	charge flow. Expansion valve is open a little compared with the specification.	
		Improper thermal valve installation. Improper expansion valve	
gh-pressure side is too high d low-pressure side is too //	Upper side of condenser and high-pressure side are hot, however, liquid tank is not so	adjustment. High-pressure tube or parts located between compressor and condenser are clogged or	 Check and repair or replace malfunctioning parts. Check lubricant for contami-
	hot.	crushed.	nation.
B B B			
AC360A			

HA-25 1033

Trouble Diagnoses for Abnormal Pressure (Cont'd)

	(33.11.4)		
Gauge indication	Refrigerant cycle	Probable cause	Corrective action
High-pressure side is too low and low-pressure side is too high.	High and low-pressure sides become equal soon after compressor operation stops.	Compressor pressure operation is improper. Damaged inside compressor packings.	Replace compressor.
LO HI)	No temperature difference between high and low-pressure sides.	Compressor pressure operation is improper. Damaged inside compressor packings.	Replace compressor.
Both high and low-pressure sides are too low.	 There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. Liquid tank inlet and expansion valve are frosted. 	Liquid tank inside is clogged a little.	Replace liquid tank. Check lubricant for contamination.
(LO HI)	 Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. Expansion valve inlet may be frosted. Temperature difference occurs somewhere in high-pressure side. 	High-pressure pipe located between liquid tank and expansion valve is clogged.	 Check and repair malfunctioning parts. Check lubricant for contamination.
AC353A	 Expansion valve and liquid tank are warm or only cool when touched. 	Low refrigerant charge. Leaking fittings or components.	Check refrigerant for leaks. Refer to "Checking Refrigerant Leaks", HA-44.
Both high and low-pressure sides are too low.	There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.	Expansion valve closes a little compared with the specification. 1 Improper expansion valve adjustment. 2 Malfunctioning thermal valve. 3 Outlet and inlet may be clogged.	 Remove foreign particles by using compressed air. Check lubricant for contami- nation.
(O) HI	An area of the low-pressure pipe is colder than areas near the evaporator outlet.	Low-pressure pipe is clogged or crushed.	 Check and repair malfunctioning parts. Check lubricant for contamination.
AC353A	Air flow volume is not enough or is too low.	Compressor pressure operation is improper.	Replace compressor.

Trouble Diagnoses for Abnormal Pressure (Cont'd)

Gauge indication	Refrigerant cycle	Probable cause	Corrective action	
Low-pressure side sometimes becomes negative.	 Air conditioner system does not function and does not cyclically cool the compart- ment air. The system constantly func- tions for a certain period of time after compressor is stopped and restarted. 	Refrigerant does not discharge cyclically. Moisture is frozen at expansion valve outlet and inlet. Water is mixed with refrigerant.	 Drain water from refrigerant or replace refrigerant. Replace liquid tank. 	•
(O HI)				
AC354A Low-pressure side becomes	Liquid tank or front/rear side of	High-pressure side is closed	Leave the system at rest. Start	
negative.	expansion valve's pipe is frosted or dewed.	and refrigerant does not flow. Expansion valve or liquid tank	it again to check whether or not the problem is caused by water or foreign particles.	
		is frosted.	 If water is the cause, initially cooling is okay. Then the water freezes, causing a blockage. Drain water from 	
			refrigerant or replace refrigerant.	
			 If due to foreign particles, remove expansion valve and remove the particles with dry and compressed air. 	
AC362A			 If either of the above meth- ods cannot correct the problem, replace expansion 	
			valve.Replace liquid tank.Check lubricant for contamination.	

BT

ST

RS


G


HA

EL


1DX


Harness Layout






Wiring Diagram -HEATER-





Wiring Diagram -A/C-






HA

G[

EL

AHA692-A


Wiring Diagram -A/C- (Cont'd)




Main Power Supply and Ground Circuit Check POWER SUPPLY CIRCUIT CHECK FOR A/C SYSTEM

Check power supply circuit for air conditioner system.

Refer to "POWER SUPPLY ROUTING" in EL section and "Wiring Diagram".





THERMO CONTROL AMP. CHECK

Check power supply circuit for thermo control amp. with ignition switch ON and air conditioner switch ON.

- 1. Disconnect thermo control amp. harness connector.
- 2. Connect voltmeter from harness side.
- 3. Measure voltage across terminal No. ① and body ground.

Voltmeter	Voltago			
\oplus	Θ	Voltage		
1	Body ground	Approx. 12V		

Check body ground circuit for thermo control amp. with ignition switch ON and fan switch ON.

- 1. Disconnect thermo control amp. harness connector.
- 2. Connect ohmmeter from harness side.
- Check for continuity between terminal No. 2 and body ground.

Ohmmete	Continuity			
+	\ominus	Continuity		
2	Body ground	Yes		

G

MA

LC

EC

FE

CL

MT

TF

PD

FA

RA

BR


ST

RS

BT


HA

IDX



If the result is NG after checking circuit continuity, repair harness or connec-


Note:



HA-35


JDX

BT





Note:

If the result is NG after checking circuit continuity, repair harness or connector.





AHA864





Diagnostic Procedure 2 (Cont'd)





Blower motor

3 2 1 6 5 4

Continuity check

A/C switch

Electrical Components Inspection FAN SWITCH

MA

Gi

Check continuity between terminals at each lever position.

LEVER POSITION TERMINAL	OFF	1	2	3	4	ļ
3					C	5
5		0			П	_
2			Q		П	_
6		П	П	Ø.	П	_
4		Ō	Q	Q	Ç)
1		Δ	\wedge	\rightarrow	$\overline{}$	₹

EM

BLOWER MOTOR

EC

LC

Confirm smooth rotation of the blower motor.

Check that there are no foreign particles inside the intake unit.

GL

FE

BLOWER RESISTOR

RHA400A

AHA852

AHA850

AT

MT

Check continuity between terminals.

PD

TF

FA

 $\mathbb{R}\mathbb{A}$

A/C SWITCH



Check continuity between terminals at each switch position.



A/C indicator

ST

BR


RS

BT


DUAL-PRESSURE SWITCH

High-pressure side line pressure kPa (kg/cm², psi)	Operation	Continuity	
Decreasing to 157 - 216 (1.6 - 2.2, 23 - 31) Increasing to 2,648 - 2,844 (27 - 29, 384 - 412)	Turn OFF	Does not exist	
Increasing to 157 - 235 (1.6 - 2.4, 23 - 34) Decreasing to 392 - 785 (4 - 8, 57 - 114)	Turn ON	Exists	

EL




TROUBLE DIAGNOSES




Electrical Components Inspection (Cont'd) THERMO CONTROL AMP.

Evaporator outlet air temperature °C (°F)	Thermo amp. operation	Tester
Decreasing to 0.1 - 0.9 (32 - 34)	Turn OFF	Approx. 12V
Increasing to 2.5 - 3.5 (37 - 38)	Turn ON	Approx. 0V



THERMAL PROTECTOR


Temperature of compressor °C (°F)	Operation
Increasing to approx. 145 - 155 (293 - 311)	Turn OFF
Decreasing to approx. 130 - 140 (266 - 284)	Turn ON




A/C RELAY AND BLOWER MOTOR RELAY

Check circuit continuity between terminals by supplying 12 volts to coil side terminals of relay.

Blower motor relay




A/C relay



Control Linkage Adjustment VENTILATOR DOOR CONTROL ROD

- 1. Move side link in direction of arrow.
- 2. With upper and lower ventilator door levers held in the direction of the arrow, connect rods ① and ② to their corresponding ventilator door levers in that order.

TROUBLE DIAGNOSES



Control Linkage Adjustment (Cont'd) **DEFROST DOOR CONTROL ROD**

- Move side link in direction of arrow.
- Connect rod to side link while pushing defrost door lever in direction of arrow.






EM

LC.

EG

FE



MODE CONTROL CABLE

- Move mode control lever to position. Set side link in DEF mode. Pull on outer cable in direction of arrow and then clamp it.
- After positioning mode control cable, check that it operates properly.




AT

PD)

FA


RA

MT



WATER COCK CONTROL ROD

- When adjusting water cock control rod, first disconnect temperature control cable from air mix door lever and then adjust control rod. Reconnect temperature control cable and readjust it. (Refer to next item.)
- Push air mix door lever in direction of arrow.
- Pull control rod of water cock in direction of arrow so as to make clearance of about 2 mm (0.08 in) between ends of rod and link lever and connect the rod to door lever.
- After connecting water cock control rod, check that it operates properly.



TEMPERATURE CONTROL CABLE

- When adjusting ventilator door rod and defrost door rod. first disconnect mode control cable from side link. Reconnect and readjust mode control cable.
- Move temperature control lever to max. COLD position. Set air mix door lever in full hot mode. Pull on outer cable in direction of arrow and then clamp it.
- operates properly.



BR

After positioning temperature control cable, check that it

RS


TE



- Move recirculation lever to position. Set recirculation lever in REC mode. Pull on outer cable in direction of arrow and then clamp it.
- After positioning recirculation control cable, check that it operates properly.



1DX



HA-43

Checking Refrigerant Leaks

PRELIMINARY CHECK

Perform a visual inspection of all refrigeration parts, fittings, hoses, and components for signs of A/C lubricant leakage, damage and corrosion.




When performing a refrigerant leak check, use a J39400 A/C leak detector or equivalent. Ensure that the instrument is calibrated and set properly per the operating instructions.

The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.


Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and cleaners, may falsely trigger the leak detector. Make sure the surfaces to be checked are clean. Do not allow the sensor tip of the detector to come into contact with any substance. This can also cause false readings and may damage the detector.

1. Position probe approximately 5 mm (3/16 in) away from point to be checked.




(J-39400)

2. When testing, circle each fitting completely with probe.



3. Move probe along component approximately 25 - 50 mm (1-2 in)/sec.



Checking Refrigerant Leaks (Cont'd) GI CHECKING PROCEDURE To prevent inaccurate or false readings, make sure there is no refrigerant vapor or tobacco smoke in the vicinity of the vehicle. MM Perform the leak test in calm area (low air/wind movement) so that the leaking refrigerant is not dispersed. Turn engine off. EM 2. Connect a suitable A/C manifold gauge set to the A/C service Check if the A/C refrigerant pressure is at least 345 kPa (50 psi) above 16°C (60°F). If less than specification, evacuate and recharge the system with the specified amount of refrigerant. NOTE: At temperatures below 16°C (60°F), leaks may not EC be detected since the system may not reach 345 kPa (50 psi). 4. Conduct the leak test from the high side to the low side at points (a) through (i). Refer to HA-47. Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detector CL probe completely around the connection/component. Compressor Check the fittings of high and low pressure hoses, relief valve, and shaft seal. Liquid tank Check the pressure switch, tube fitting, weld seams and the ΔT fusible plug mounts. Service valves Check all around the service valves. Ensure service valve caps TF are secured on the service valves (to prevent leaks). NOTE: After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any PD) false readings by leak detector. Cooling unit (Evaporator) Turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Insert the leak detector probe into the drain hose immediately after stopping engine. (Keep the probe inserted for at least ten seconds.) If a leak detector detects a leak, verify at least once by blowing compressed air into area of suspected leak, then repeat 6. Do not stop when one leak is found. Continue to check for additional leaks at all system components.

BR

81

ST


RS

EL

[DX


Checking Refrigerant Leaks (Cont'd)

- 7. Start engine.
- 8. Set the heater A/C control as follows:
 - a. A/C switch ON
 - b. Face mode
 - c. Recirculation switch ON
 - d. Max cold temperature
 - e. Fan speed high
- 9. Run engine at 1500 rpm for at least 2 minutes.
- 10. Turn engine off and perform leak check again following steps 4 through 6 on the previous page.



Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector on the high pressure line. The pressure in the high pressure line will gradually drop after refrigerant circulation stops and pressure in the low pressure line will gradually rise, as shown in the graph. Leaks are more easily detected when pressure is high.

- 11. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component as necessary.
- 12. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
- 13. Conduct A/C performance test to ensure system works properly.




R-134a Service Procedure


DISCHARGING REFRIGERANT

WARNING:


Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from A/C system, using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment), or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.



EVACUATING SYSTEM AND CHARGING REFRIGERANT



1056 HA-48



Note: *1 Before charging refrigerant, ensure engine is OFF.

1057

[:D)X(

^{*2} Before checking for leaks, start engine to activate air conditioner system then turn engine OFF. Service valve caps must be installed to prevent leakage.

Compressor Lubricant Quantity

The lubricant used to lubricate the compressor circulates through the system with the refrigerant. Whenever any A/C component is replaced or gas leakage occurs, lubricant must be added. If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)


LUBRICANT

Name: Nissan A/C System Lubricant Type R

Part No.: KLH00-PAGR0

CHECKING AND ADJUSTING

Adjust the lubricant quantity according to the flowchart shown below.




Compressor Lubricant Quantity (Cont'd)



- 1. Discharge refrigerant into refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
- 2. Drain the lubricant from the old (removed) compressor into a graduated container and record the amount of lubricant drained.
- 3. Drain the lubricant from the new compressor into a separate, clean container.
- 4. Measure an amount of new lubricant equal to amount drained from old compressor. Add this lubricant to new compressor through the suction port opening.
- 5. Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to new compressor through the suction port opening.
- 6. If the liquid tank also needs to be replaced, add an additional 5 mf (0.2 US fl oz, 0.2 lmp fl oz) of lubricant at this time. Do not add this 5 mf (0.2 US fl oz, 0.2 lmp fl oz) of lubricant if only replacing the compressor.

Lubricant adjusting procedure for compressor replacement



HA

BT

GI

MA

国施


LC.

EG

FE

EL

Compressor Mounting





Belt Tension

 Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").

Fast Idle Control Device (FICD)

 Refer to EC section ("IACV-FICD Solenoid Valve", TROUBLE DIAGNOSIS FOR NON-DETECTABLE ITEMS").





Condenser


REMOVAL


- Discharge refrigerant using the recovery/recycling equipment (ACR4).
- 2. Remove coolant reservoir tank (3 screws).
- 3. Remove side marker lamps.
- Remove front grille (5 fasteners).
- Remove harness clip from hood lock stay, if equipped (gently press out).
- 6. Remove hood lock stay plate (4 bolts) and hood lock stay brace (2 bolts).
- Remove hose (high-pressure) clamp bracket from radiator core support.
- 8. Disconnect high-pressure hose at condenser.
- 9. Disconnect dual-pressure switch harness connector.
- 10. Disconnect high-pressure tube (liquid tank to cooling unit) at liquid tank.
- 11. Remove condenser mounting bolts (2 bolts).
- 12. Remove condenser assembly.

CAUTION:

Carefully lift condenser without damaging radiator (fin and tube).


Compressor








When removing center bolt, hold clutch disc with clutch disc wrench.



Remove the drive plate using Tool KV99232340. Insert holder's three pins into the drive plate. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the drive plate.

When tightening the center bolt, insert a round bar (screwdriver, etc.) between two of the pins (as shown in the left-hand figure) to prevent drive plate rotation. After removing the drive plate, remove the shims from either the drive shaft or the drive plate.

Remove the snap ring using external snap ring pliers.



HA

IDX

HA-53

EM

MA

GI

LC

EC

FE

CL

MT

AT

PD)


BR

RA

ST

RS

BT



Compressor Clutch (Cont'd)

Pulley removal

Use any commercially available pulley puller. Position the center of it on the end of the drive shaft, and remove the pulley assembly.


For pressed pulleys:

To prevent deformation of the pulley groove, the puller claws should be hooked under (not into) the pulley groove.


For machine latched pulleys:

Align the pulley puller groove with the pulley groove, and then remove the pulley assembly.

Remove the field coil harness clip using a screwdriver.



 Remove the three field coil fixing screws and remove the field coil.




INSPECTION

Clutch disc: If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

Pulley: Check the appearance of the pulley assembly. Check the contact surface of the pulley for any sign of excessive grooving due to slippage. If any sign is found, replace both the pulley and clutch disc. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

Coil: Check coil for loose connection or cracked insulation.



INSTALLATION

- Install the field coil.
- Be sure to align the coil's pin with the hole in the compressor's front head.
- Install the field coil harness clip using a screwdriver.

HA-54

Pulley assembly

AHA845

Compressor Clutch (Cont'd)


Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



G

EM

LC



KV99231260

Ratchet wrench

(J-38874)

KV99234330

(J-39024)

Snap ring

Drive plate holder

Install the drive plate on the drive shaft, together with the original shim(s). Press the drive plate down by hand.



CL

MT

Using the holder to prevent drive plate rotation, tighten the bolt to 12 - 15 N·m (1.2 - 1.5 kg-m, 9 - 11 ft-lb) torque. After tightening the bolt, check that the pulley rotates



TF



FA

RA

Check clearance around the entire periphery of clutch disc. Disc-to-pulley clearance:

0.3 - 0.6 mm (0.012 - 0.024 in)

If the specified clearance is not obtained, replace adjusting spacer and readjust.



ST

BREAK-IN OPERATION

transmitted torque.

smoothly.


When replacing compressor clutch assembly, always conduct the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of


RS

BT

킲

IDX





Thermal Protector INSPECTION

- When servicing, do not allow foreign matter to get into compressor.
- Check continuity between two terminals.

1064 HA-56

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

COMPRESSOR

Model	DKV-14C
Туре	Vane rotary
Displacement cm3 (cu in)/Rev	140 (8.54)
Direction of rotation	Clockwise (Viewed from drive end)
Drive belt	A type

LUBRICANT

Model	ZEXEL make DKV-14C
Name	Nissan A/C System Oil Type R
Part number	KLH00-PAGR0
Capacity mf (US fl oz, Imp fl oz)	
Total in system	200 (6.8, 7.0)
Compressor (Service parts) charging amount	200 (6.8, 7.0)

REFRIGERANT

Туре		R134a
Capacity	kg (lb)	0.75 - 0.85 (1.65 - 1.87)

Inspection and Adjustment COMPRESSOR

ENGINE IDLING SPEED

When A/C is ON Refer to EC section.

BELT TENSION

Refer to MA section ("Checking Drive Belts", "ENGINE MAINTENANCE").

Model	DKV-14C
Clutch disc-to-pulley clearance	0.3 - 0.6
mm (in)	(0.012 - 0.024)

TF

Gl

MA

FE

CL

Mĩ

AT

FA

RA

BR

ST RS

87

HA

Ī.

IDX

SECTION EL

CONTENTS

PRECAUTIONS	2
Supplemental Restraint System (SRS) "AIR	
BAG"	2
HARNESS CONNECTOR	3
STANDARDIZED RELAY	4
POWER SUPPLY ROUTING	6
Schematic	6
Wiring Diagram -POWER	7
Fuse	11
Fusible Link	11
Circuit Breaker Inspection	11
GROUND DISTRIBUTION	12
BATTERY	
How to Handle Battery	
Service Data and Specifications (SDS)	
STARTING SYSTEM	
System Description	
Wiring Diagram -START	
Starter	
Pinion/Clutch Check	
Service Data and Specifications (SDS)	
CHARGING SYSTEM	
System Description	
Wiring Diagram – CHARGE–	
Trouble Diagnoses	
Generator	
Diode Check	
Disassembly and Assembly	
Service Data and Specifications (SDS)	31
COMBINATION SWITCH	
Combination Switch/Check	
Combination Switch/Replacement	
Steering Switch/Check HEADLAMP	
System Description (For USA)	
Wiring Diagram (For USA) – H/LAMP–	
Trouble Diagnoses (For USA) – H/LAMP	
System Description (For Canada)	
Operation (Daytime light system for Canada)	
Schematic (For Canada)	
	,, ,4 U

	Wiring Diagram (For Canada) -DTRL	42
	Trouble Diagnoses (For Canada)	
	Bulb Specifications	
	Aiming Adjustment	
E	XTERIOR LAMP	
	Back-up Lamp/Wiring Diagram -BACK/L	49
	Parking, License, Tail and Stop Lamps/Wiring	
	Diagram -TAIL/L	50
	Turn Signal and Hazard Warning Lamps/System	
	Description	52
	Turn Signal and Hazard Warning Lamps/Wiring	
	Diagram -TURN	54
	Turn Signal and Hazard Warning Lamps/Trouble	
	Diagnoses	56
	Combination Flasher Unit Check	56
	Bulb Specifications	57
I۱	ITERIOR LAMP	58
	Illumination/System Description	58
	Illumination/Schematic	59
	Illumination/Wiring Diagram -ILL	60
	Interior and MAP Lamps/	
	Wiring Diagram -INT/L	63
	Bulb Specifications	
M	ETERS AND GAUGES	
	System Description	
	Combination Meter	66
	Speedometer, Tachometer, Temp. and Fuel	
	Gauges/Wiring Diagram -METER	
	Inspection/Water Temperature Gauge	
	Inspection/Fuel Gauge	
	Inspection/Tachometer	71
	Inspection/Speedometer and Vehicle Speed	
	Sensor	
	Inspection/Speedometer and Fuse	
	Fuel Tank Gauge Unit Check	
	Fuel Warning Lamp Sensor Check	
	Thermal Transmitter Check	
	Oil Pressure Switch Check	
	Vehicle Speed Sensor Signal Check	78
W	ARNING LAMPS	76

CONTENTS (Cont'd.)

Schematic 7 Wiring Diagram –WARN– 7 Diode Check 8 IRNING CHIME 8 System Description 8 Wiring Diagram –CHIME— 8 Frouble Diagnoses 8 PER AND WASHER 9 System Description 9 Wiring Diagram –WIPER— 9 Frouble Diagnoses 9 Wiper Amplifier Check 9 Installation 9 Washer Nozzle Adjustment 10 RN, LIGHTER, CLOCK 10 Wiring Diagram –HORN— 10 System Description 10 System Description 10 Frouble Diagnoses 10 Viring Diagram –AUDIO— 10 Fronda 10 Viring Diagram –MIRROR— 11 Viring Diagram –MIRROR— 11 Component Parts and Harness Connector 10 Component Parts and Harness Connector 11 Cocation 11 System Description 11 Schematic 11	Component Layout System Description Wiring Diagram –WINDOW– Trouble Diagnoses POWER DOOR LOCK System Description Chematic Wiring Diagram –D/LOCK– Trouble Diagnoses LOCATION OF ELECTRICAL UNITS Passenger Compartment Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
Diode Check	System Description Wiring Diagram -WINDOW- Trouble Diagnoses. POWER DOOR LOCK System Description Schematic Wiring Diagram -D/LOCK- Trouble Diagnoses. LOCATION OF ELECTRICAL UNITS Passenger Compartment Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline. Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement.	
RNING CHIME System Description Wiring Diagram –CHIME— System Description System Description Wiring Diagram –WIPER— System Description Wiring Diagram –WIPER— System Amplifier Check System Nozzle Adjustment Stallation System Description System Description System Description System Description System Description System Description System Description System Description Sochematic System Diagram –AUDIO— System Diagram –AUDIO— System Diagram –AUDIO— System Diagram –Buren System Diagram –MIRROR— System Diagram –MIRROR— System Diagram –MIRROR— System Description System Description System Diagram –MIRROR— System Description System Description System Description System Description System Description System Description System Description System Description System Description System Description Schematic System Description Schematic System Description Schematic	Wiring Diagram –WINDOW– Trouble Diagnoses POWER DOOR LOCK System Description Compartment Diagnoses Compartment Diagnoses Diagnoses DOCATION OF ELECTRICAL UNITS Diagnore Compartment Diagnoses Diagnoses DOCATION OF ELECTRICAL UNITS Diagnore Compartment Diagnoses Diagn	
System Description 8 Wiring Diagram –CHIME— 8 Frouble Diagnoses 9 System Description 9 Wiring Diagram –WIPER— 9 Frouble Diagnoses 9 Wiper Amplifier Check 9 Installation 9 Washer Nozzle Adjustment 10 INTERNA 11 INTERNA 11	Trouble Diagnoses	
Wiring Diagram –CHIME– 8. Frouble Diagnoses 8. Frouble Diagnoses 8. Frouble Diagnoses 9. Frouble Diagram –WIPER– 9. Frouble Diagnoses 9. Wiper Amplifier Check 9. Installation 9. Washer Nozzle Adjustment 10. RN, LIGHTER, CLOCK 10. Wiring Diagram –HORN– 10. System Description 10. System Description 10. Frouble Diagnoses 10. Froubl	POWER DOOR LOCK System Description Schematic Wiring Diagram –D/LOCK– Trouble Diagnoses LOCATION OF ELECTRICAL UNITS Passenger Compartment Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
Frouble Diagnoses	System Description Schematic Wiring Diagram –D/LOCK– Trouble Diagnoses LOCATION OF ELECTRICAL UNITS Passenger Compartment Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
PER AND WASHER System Description	Schematic Wiring Diagram –D/LOCK– Trouble Diagnoses LOCATION OF ELECTRICAL UNITS Passenger Compartment Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
System Description 95 Wiring Diagram –WIPER 96 Frouble Diagnoses 96 Wiper Amplifier Check 97 Installation 98 Washer Nozzle Adjustment 106 RN, LIGHTER, CLOCK 107 Wiring Diagram –HORN 107 System Description 107 System Description 107 System Diagram –AUDIO 108 Frouble Diagnoses 107 TENNA 108 Location of Antenna 108 Viring Diagram –MIRROR 116 Viring Diagram –MIRROR 112 Component Parts and Harness Connector 114 Component Parts and Harness Connector 114 System Description 115 Schematic 115 Schematic 117	Wiring Diagram -D/LOCK- Trouble Diagnoses LOCATION OF ELECTRICAL UNITS Passenger Compartment Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
Wiring Diagram -WIPER	Trouble Diagnoses	
Frouble Diagnoses 99 Wiper Amplifier Check 99 Installation 99 Washer Nozzle Adjustment 100 RN, LIGHTER, CLOCK 10 Wiring Diagram —HORN— 10 DIO 10 System Description 10 Schematic 10 Wiring Diagram —AUDIO— 10 Frouble Diagnoses 10 TENNA 10 Location of Antenna 10 Wiring Diagram —MIRROR— 11 RROR 11 Wiring Diagram —MIRROR— 11 Component Parts and Harness Connector 11 Cocation 11 System Description 11 Schematic 11	Passenger Compartment Passenger Compartment	
Frouble Diagnoses 99 Wiper Amplifier Check 99 Installation 99 Washer Nozzle Adjustment 100 RN, LIGHTER, CLOCK 10 Wiring Diagram —HORN— 10 DIO 10 System Description 10 Schematic 10 Wiring Diagram —AUDIO— 10 Frouble Diagnoses 10 TENNA 10 Location of Antenna 10 Wiring Diagram —MIRROR— 11 RROR 11 Wiring Diagram —MIRROR— 11 Component Parts and Harness Connector 11 Cocation 11 System Description 11 Schematic 11	Passenger Compartment Passenger Compartment	
Nasher Nozzle Adjustment 100 RN, LIGHTER, CLOCK 10 Wiring Diagram –HORN– 10 DIO 10 System Description 10 Schematic 10 Wiring Diagram –AUDIO– 10 Trouble Diagnoses 10 TENNA 10 Location of Antenna 10 Window Antenna Repair 11 Viring Diagram –MIRROR– 11 Component Parts and Harness Connector 11 Component Parts and Harness Connector 11 System Description 11 Schematic 11	Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
Nasher Nozzle Adjustment 100 RN, LIGHTER, CLOCK 10 Wiring Diagram –HORN– 10 DIO 10 System Description 10 Schematic 10 Wiring Diagram –AUDIO– 10 Trouble Diagnoses 10 TENNA 10 Location of Antenna 10 Window Antenna Repair 11 Viring Diagram –MIRROR– 11 Component Parts and Harness Connector 11 Component Parts and Harness Connector 11 System Description 11 Schematic 11	Engine Compartment HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
RN, LIGHTER, CLOCK 10 Wiring Diagram -HORN- 10 System Description 10 Schematic 10 Wiring Diagram -AUDIO- 10 Frouble Diagnoses 10 TENNA 10 Location of Antenna 10 Window Antenna Repair 11 RROR 11 Wiring Diagram -MIRROR- 11 Component Parts and Harness Connector 11 Cocation 11 System Description 11 Schematic 11	HARNESS LAYOUT How To Read Harness Layout Outline Main Harness and Air Bag Harness Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
RN, LIGHTER, CLOCK 10 Wiring Diagram -HORN- 10 System Description 10 Schematic 10 Wiring Diagram -AUDIO- 10 Frouble Diagnoses 10 TENNA 10 Location of Antenna 10 Window Antenna Repair 11 RROR 11 Wiring Diagram -MIRROR- 11 Component Parts and Harness Connector 11 Cocation 11 System Description 11 Schematic 11	How To Read Harness Layout	
Wiring Diagram –HORN– 10° DIO 10° System Description 10° Schematic 10° Wiring Diagram –AUDIO– 10° Trouble Diagnoses 10° TENNA 10° Location of Antenna 10° Window Antenna Repair 11° RROR 11° Wiring Diagram –MIRROR– 11° Component Parts and Harness Connector 11° Location 11° System Description 11° Schematic 11°	Outline	
DIO 100 System Description 100 Schematic 100 Wiring Diagram –AUDIO- 104 Frouble Diagnoses 105 TENNA 105 Location of Antenna 105 Window Antenna Repair 110 RROR 112 Wiring Diagram –MIRROR- 112 Component Parts and Harness Connector 114 Cocation 114 System Description 115 Schematic 117	Main Harness and Air Bag Harness Instrument Harness	
System Description	Instrument Harness Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	
Schematic	Engine Harness Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	159160161162Foldout pageFoldout pageFoldout page
Trouble Diagnoses	Chassis and Tail Harness Front Door Harness Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation Terminal Arrangement	160161162 Foldout page Foldout page Foldout page
Trouble Diagnoses	Front Door Harness	161162 Foldout page Foldout page Foldout page
TENNA	Room Lamp Harness SUPER MULTIPLE JUNCTION (SMJ) Installation	162 Foldout page Foldout page Foldout page
Location of Antenna	SUPER MULTIPLE JUNCTION (SMJ) Installation	Foldout page Foldout page Foldout page
Window Antenna Repair	Installation Terminal Arrangement	Foldout page Foldout page
Niring Diagram -MIRROR- 112 TOMATIC SPEED CONTROL DEVICE (ASCD) 114 Component Parts and Harness Connector Location 114 System Description 118 Schematic 117	2 Terminal Arrangement	Foldout page
Viring Diagram -MIRROR	•	
TOMATIC SPEED CONTROL DEVICE (ASCD)114 Component Parts and Harness Connector Location		Foldout page
Component Parts and Harness Connector Location 114 System Description 118 Schematic 117	• • •	· ·
ocation 114 System Description 115 Schematic 117	Terminal Arrangement	, ,
System Description118 Schematic	· ·	
Schematic117		• -
Viring Diagram -ASCD118		i oldodi page
hen you read wiring diagrams: Read GI section, "HOW TO READ WIRING D hen you perform trouble diagnoses, read		CHART IN
ROUBLE DIAGNOSES" and "HOW TO PERFO	ORM EFFICIENT DIAGNOSIS FOR AN E	LECTRICAL
WIRING DIAGRA	M REFERENCE CHART	
CS (Ignition system)		EC SECTION
TOMATIC TRÁNSMIŚSION CONTROL SYSTEM,		
TI-LOCK BRAKE SYSTEM		
S "AIR BAG" ATER AND AIR CONDITIONER		

[DX

Œ]



Supplemental Restraint System (SRS) "AIR BAG"

The Supplemental Restraint System "Air Bag", used along with a seat belt, helps to reduce the risk or severity of injury to the driver in a frontal collision. The Supplemental Restraint System consists of an air bag module (located in the center of the steering wheel), a diagnosis sensor unit, a crash zone sensor (4WD models), warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



SEL769D

EL-3

GI

MA

LC

EC

FE

CL.

MT

AT

TF

PD

FA RA

BR

ST

RS

BT


HA

UE97

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can be divided into three main types: normal open, normal closed and mixed type relays.



AEL669A

TYPE OF STANDARDIZED RELAYS

1M 1 Make 1 Break 2M 2 Make




AEL309A

EL-4

STANDARDIZED RELAY

		Description (Cont	'd)	
Туре	Outer view	Circuit	Connector symbol and connection	Case color
1M	2 1	2 2 3 3 0 1 3	2 3 1	GRAY
1M	5 3	1 3 9 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	00 1 2 5 3	BLUE
1M	3	(1) (3) (2) (3)	00 5 2 1	BLUE
2M	2 1 7 5 6 3	3 6 0 7 5 5	00 00 2 1 7 5 6 3	BROWN
1M-1B	2 1 6 3 7 4	274	00 2 1 6 7 3 4	GRAY

AEL308A





EL-6

Œ[Wiring Diagram -POWER-**EL-POWER-01** MA 1 EM BATTERY FUSIBLE LINK FUSIBLE LINK E5), E23 BR (M47), (E21) M48, E22 LC 3 W/B W/R w EC MAIN, MAFS, CMPS, PGC/V W/R BLOCK FE (M143) FUSIBLE LINK ВR (M38) CL. 12 13 MT R/W CIRCUIT BREAKER H/LAMP, DTRL (M106) AT A Next page TF ■W■B>To EL-POWER-03 W/G ₽ D/LOCK PD) >To EL-POWER-03 W/G **[7**] IGNITION-2 AND POWER WINDOW RELAY $\mathbb{R}\mathbb{A}$ **റി** 5 (M148) ■ B/G ➡ ABS W NDOW ST В В В (E24) (E25) $\overline{(M49)}$ (M105) (M160) RS BT (M38 M47(E21) M48 HA 2 1 3 5 3 5 3 5 ĒL M143 9 10 11 (0 12 13 14 15 16 17 18 19 20 21 22 1DX


AEL299A-A

Wiring Diagram -POWER- (Cont'd)





Wiring Diagram -POWER- (Cont'd)





AEL867A

@[


Wiring Diagram -POWER- (Cont'd)


EL-POWER-04








POWER SUPPLY ROUTING











Fuse

If fuse is blown, be sure to eliminate cause of problem before installing new fuse.

Use fuse of specified rating. Never use fuse of more than specified rating.

Do not partially install fuse; always insert it into fuse holder properly.

Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.

Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with fingertip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

If fusible link should melt, it is possible that a critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check these circuits and eliminate cause of problem.

Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.

Circuit Breaker Inspection

For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems:

- Power door lock
- Power window

G

MA

副

[_C

EC

MT

Air

TE

PD

RA

BR

ST

RS

87

HA

(ID)X

GROUND DISTRIBUTION

GROUND	CONNECT TO	CONN. NO.	CELL CODE
M15/M16	ABS CHECK CONNECTOR	M154	BR-ABS
	DATA LINK CONNECTOR FOR CONSULT	M153	EC-MIL/DL
	DATA LINK CONNECTOR FOR GST	M152	EC-MIL/DL
	DISTRIBUTOR (CAMSHAFT POSITION SENSOR)	M12	EC-CMPS
	DISTRIBUTOR (POWER TRANSISTOR)	M12	EC-IGN/SG
	ECM (ECCS CONTROL MODULE)	M112	EC-MAIN EC-AP/SEN EC-FR02 EC-FR02/H EC-FUEL
	REAR HEATED OXYGEN SENSOR	M402	EC-RR02 EC-RR02/H
	SHIELD WIRE (ABSOLUTE PRESSURE SENSOR)	M24	EC-AP/SEN
	SHIELD WIRE (CAMSHAFT POSITION SENSOR)	M12	EC-CMPS
	SHIELD WIRE (CRANKSHAFT POSITION SENSOR)	E15	EC-CKPS
	SHIELD WIRE (EVAP CONTROL SYSTEM PRESSURE SENSOR)	C6	EC-PRE/SE
	SHIELD WIRE (FRONT HEATED OXYGEN SENSOR)	M62	EC-FR02 EC-FRO2/H EC-FUEL
	SHIELD WIRE (MASS AIR FLOW SENSOR)	M20	EC-MAFS
	SHIELD WIRE (REAR HEATED OXYGEN SENSOR)	M402	EC-RR02 EC-RR02/H
	SHIELD WIRE (THROTTLE POSITION SENSOR)	M23	EC-TPS AT-A/T
//49/M105/M160	ACCESSORY RELAY	M149	EL-POWER
	AIR BAG DIAGNOSIS SENSOR UNIT	M175	RS-SRS
	ASCD CONTROL UNIT	M126	EL-ASCD
	ASCD MAIN SWITCH	N2	EL-ASCD
	ASCD HOLD RELAY (With A/T)	M65	EL-ASCD
	ASCD HOLD RELAY (With M/T)	M64	EL-ASCD
	BLOWER MOTOR RELAY	M150	HA-A/C HA-HEATER EL-POWER
	BRAKE FLUID LEVEL SWITCH	M59	EL-WARN BR-ABS
	BULB CHECK RELAY	M63	EL-WARN
	CIGARETTE LIGHTER SOCKET	M119	EL-HORN
	CLUTCH INTERLOCK SWITCH (With M/T)	M136	EL-START
	COMBINATION FLASHER UNIT	M139	EL-TURN
	COMBINATION METER (AIR BAG WARNING LAMP)	N6	RS-SRS EL-WARN
	COMBINATION METER (CLOCK)	N6	EL-HORN
	COMBINATION METER [CLOCK (Without tachometer)]	N4	EL-HORN
	COMBINATION METER [CRUISE INDICATOR (With ASCD)]	N6	EL-ASCD
	COMBINATION METER (GAUGES)	N4	EL-METER
	COMBINATION METER (HIGH BEAM INDICATOR)	N5	EL-DTRL EL-H/LAMP
	COMBINATION METER (SPEEDOMETER)	N4	EC-VSS EL-ASCD
	COMBINATION METER [TACHOMETER (With tachometer)]	N6	EL-METER
	COMBINATION METER (TURN SIGNAL LAMP)	N6	EL-TURN
	COMBINATION METER [4WD INDICATOR (With 4WD)]	N6	EL-WARN
	DATA LINK CONNECTOR FOR GST	M152	EC-MIL/DL
Ì	DAYTIME LIGHT CONTROL UNIT (With DTRL)	M41	EL-DTRL
ļ	DOOR MIRROR SWITCH	N3	EL-MIRROR
ļ	FRONT TURN SIGNAL LAMP LH	M70	EL-TURN
ļ	FRONT TURN SIGNAL LAMP RH	M54	EL-TURN
	GLOVE BOX LAMP SWITCH	M203	EL-ILL

1078 EL-12

GROUND DISTRIBUTION

GROUND	CONNECT TO	CONN. NO.	CELL CODE	
M49/M105/M160	HEADLAMP LH	M66	EL-H/LAMP	
	HEADLAMP RH	M51	EL-H/LAMP EL-DTRL	
	HIGH-MOUNTED STOP LAMP	R4	EL-TAIL/L	
	IACV-FICD SOLENOID VALVE	M602	EC-FICD HA-A/C	
	IGNITION RELAY-1	M151	EL-POWER	
	IGNITION-2 AND POWER WINDOW RELAY	M148	BR-ABS EL-POWER EL-WINDOW	
	ILLUMINATION CONTROL SWITCH	M123	EL-ILL	
	CLUTCH INTERLOCK SWITCH (With M/T)	M36	EL-START	
	INHIBITOR RELAY (With ASCD)	M35	EL-START EL-ASCD	
	INHIBITOR RELAY (Without ASCD)	M34	EL-START	
	LOCK/UNLOCK KNOB SWITCH	D9	EL-D/LOCK	
	MAP LAMP	R2	EL-INT/L	
	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	D8	EL-DLOCK EL-WINDOW	
	PARK AND NEUTRAL POSITION RELAY (with A/T)	M42	EC-PNP/SW AT-A/T	
	POWER WINDOW AMPLIFIER	M102	EL-WINDOW	
	ROOM LAMP	R5	EL-INT/L	
	SWIRL CONTROL VALVE CONTROL VACUUM CHECK SWITCH	M39	EC-S/VCSW	
	WARNING CHIME UNIT	M170	EL-CHIME	
	WASHER FLUID LEVEL SWITCH (Canada only)	M58	EL-WARN	
	WIPER AMPLIFIER	M4	EL-WIPER	
•	WIPER MOTOR	М3	EL-WIPER	
	WIPER SWITCH	M132	EL-WIPER	
M111	ECM (ECCS CONTROL MODULE)	M112	EC-MAIN EC-IGN/SG	
	SHIELD WIRE (ABS CONTROL UNIT)	M176	BR-ABS	

RA

BR

ST

R\$

BT

KA

EL

1DX

GROUND DISTRIBUTION

BROUND	CONNECT TO	CONN. NO.	CELL CODE
M177	ABS ACTUATOR	C3	BR-ABS
	ABS CONTROL UNIT	M176	BR-ABS
	A/T DEVICE	M174	AT-SHIFT
	A/T DEVICE (OVERDRIVE SWITCH)	M174	AT-A/T
	DOOR LOCK CONTROL UNIT	M178	EL-D/LOCK
	DOOR SWITCH LH	M171	RS-SRS EL-CHIME
	FRONT PARKING LAMP LH	M55	EL-TAIL/L
	FRONT PARKING LAMP RH	M50	EL-TAIL/L
	FUEL TANK GAUGE UNIT (FUEL PUMP)	C4	EC-F/PUMP
	FUEL TANK GAUGE UNIT (LOW FUEL WARNING)	C4	EL-WARN
	LICENSE LAMP LH	T5	EL-TAIL/L
	LICENSE LAMP RH	T4	EL-TAIL/L
	LICENSE LAMP LH (With step bumper)	Т6	EL-TAIL/L
	LICENSE LAMP RH (With step bumper)	T2	EL-TAIL/L
	REAR COMBINATION LAMP LH (BACK-UP)	T7	EL-BACK/L
	REAR COMBINATION LAMP RH (BACK-UP)	тз	EL-BACK/L
	REAR COMBINATION LAMP LH (TAIL)	Т7	EL-TAIL/L
	REAR COMBINATION LAMP RH (TAIL)	ТЗ	EL-TAIL/L
	REAR COMBINATION LAMP LH (TURN)	Т7	EL-TURN
	REAR COMBINATION LAMP RH (TURN)	тз	EL-TURN
	REAR SPEAKER AMPLIFIER	M179	EL-AUDIO
	SEAT BELT BUCKLE SWITCH	M173	EL-CHIME EL-WARN
E6	GENERATOR	E8	EL-CHARGE
	NEUTRAL POSITION SWITCH	E18	EC-PNP/SW
	POWER STEERING OIL PRESSURE SWITCH	E10	EC-PST/SW
E24/E25	BATTERY	E23	EL-POWER

1080 EL-14

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.



GI



LC.

EC

FE

(GL



How to Handle Battery


METHODS OF PREVENTING DISCHARGE

The following precautions must be taken to prevent overdischarging a battery.

- The battery surface (particularly its top) should always be kept clean and drv.
- The terminal connections should be clean and tight.
- During every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".

When the vehicle is not going to be used over a long period of





PD

FA

RA

Check the condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

1818

ST

RS

187




Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.


Normally the battery does not require additional water. However, when the battery is used under severe conditions, adding distilled water may be necessary during the battery life.


HA

EL

EL-15 1081







Hydrometer Read top level with scale Thermometer SEL195P



- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.


SULPHATION

A battery (with specific gravity less than 1.100) will completely discharge when left unattended for a long period of time. This will result in sulphation on the cell plates.

A sulphated battery may sometimes be brought back into service by means of a slow charge, 12 hours or more. A capacity test should be run after the battery is charged to ensure the battery is not damaged.

SPECIFIC GRAVITY CHECK

Check hydrometer and thermometer readings at eye level.



When electrolyte level is too low, tilt battery case for easy measurement.

Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading	Battery electrolyte temperature °C (°F)	Add to specific gravity reading
71 (160)	0.032	21 (70)	-0.004
66 (150)	0.028	16 (60)	-0.008
60 (140)	0.024	10 (50)	-0.012
54 (129)	0.020	4 (39)	-0.016
49 (120)	0.016	-1 (30)	-0.020
43 (110)	0.012	-7 (20)	-0.024
38 (100)	0.008	-12 (10)	-0.028
32 (90)	0.004	-18 (0)	-0.032
27 (80)	0		***************************************

Corrected specific gravity	Approximate charge condition	Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged	1.170 - 1.190	1/4 charged
1.230 - 1.250	3/4 charged	1.140 - 1.160	Almost discharged
1.200 - 1.220	1/2 charged	1.110 - 1.130	Completely discharged

BATTERY

How to Handle Battery (Cont'd) G CHARGING THE BATTERY **CAUTION:** Do not "quick charge" a fully discharged battery. MA Keep the battery away from open flame while it is being When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark. If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F). EC Charging rates: Amps Time FE 50 1 hour 25 2 hours 10 5 hours CL 5 10 hours Do not charge at more than 50 ampere rate. Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above are referred to as the initial charge rate. If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced. After the battery is charged, always perform a "capacity test" as follows, to assure that the battery is serviceable. PD) MEMORY RESET If the battery is disconnected or goes dead, the following items must Radio AM and FM preset Clock RA 88 ST RS BT HA

۲L


IDX

How to Handle Battery (Cont'd)


 Check battery type and determine the specified current using the following table.

Fig. 1 DISCHARGING CURRENT (Load tester)

Group size	Current (A)
21R (USA)	245
24R (Canada)	275



SEL008Z



Voltage chart

battery.

Estimated electrolyte temperature °C (°F)	Minimum voltage under 15 second load
21 (70)	9.6
16 (60)	9.5
10 (50)	9.4
4 (40)	9.3
-1 (30)	9.1
-7 (20)	8.9
-12 (10)	8.7
-18 (0)	8.5

Service Data and Specifications (SDS)

Applied area		USA	Canada
Group size		21R	24R
Capacity	V-AH	12-60	12-65
Cold cranking current	А	490	550
Reserve capacity	minutes	88	113

1084 EL-18

STARTING SYSTEM


System Description	Gi
M/T models Power is supplied at all times:	MA
 to ignition switch terminal ① through green fusible link (located at the battery positive terminal). With the ignition switch in the START position, power is supplied: through terminal ④ of the ignition switch 	EM
• to clutch interlock relay terminals ① and ③. Ground is supplied to clutch interlock relay terminal ② when the clutch pedal is depressed through the clutch interlock switch and body grounds (M49), (M105) and (M160).	[_C
 The clutch interlock relay is energized and power is supplied: from terminal (5) of the clutch interlock relay to terminal (1) of the starter motor windings. 	EC
The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.	FE
A/T models	CL
 Power is supplied at all times: to ignition switch terminal 1 through green fusible link (located at the battery positive terminal). With the ignition switch in the ON or START position, power is supplied: 	MT
 to inhibitor switch terminal ① through 10A fuse (No. ① , located in the fuse block). With the ignition switch in the START position, power is supplied: 	
 from ignition switch terminal (4) to inhibitor relay terminal (3) (without ASCD) or to inhibitor relay terminal (7) (with ASCD). Power is supplied:	75
 from inhibitor switch terminal ② (with selector lever in the P or N position) to inhibitor relay terminal ①. 	PD
Ground is supplied: to inhibitor relay terminal ② through body grounds (M49), (M105), and (M160).	FA
With power and ground supplied, the inhibitor relay is energized and power is supplied: from inhibitor relay terminal (5) (without ASCD) or from inhibitor relay terminal (6) (with ASCD)	
• to terminal ① of the starter motor windings. The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine	BR
starts.	ST
	RS
	BT
	HA


EL

 $\mathbb{D}\mathbb{X}$

Wiring Diagram -START-

M/T MODELS







AEL869A

Wiring Diagram -START- (Cont'd)

A/T MODELS





EL

JDX


BT

 $\mathbb{G}[$

AEL275A-B

Starter

CALIFORNIA, USA




- 1 Sleeve bearing
- (2) Gear case
- 3 Pinion stopper set
- 4 Pinion assembly5 Shift lever
- 6 Plate

- 7 Packing
- 8 Adjusting plate
- Magnetic switch assembly
- Yoke
- Brush (+)
- Armature

- (13) Washer
- (14) Brush (--)
- (15) Brush holder
- (16) Sleeve bearing
- 17 Rear cover

Starter (Cont'd)

NON-CALIFORNIA, USA AND CANADA



- Gear case

- 2 Shift lever
 3 Plate
 4 Packing
 5 Adjusting plate
- 6 Magnetic switch assembly
- Pinion assembly
- (9) Internal gear
- (10) Pinion shaft
- 11) Planetary gear

- 12 Packing
- Yoke
- Armature
- (15) Brush holder assembly
- (16) Rear cover

ËL

G1

Pinion/Clutch Check

- 1. Inspect pinion teeth.
- Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
- 2. Inspect reduction gear teeth.
- Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
- 3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
- If it locks or rotates in both directions, or unusual resistance is evident, replace.

Service Data and Specifications (SDS) STARTER

	, 	·, ···
	M003T70381	M000T60081ZC
Туре	MITS	UBISHI
	Non-reduction	Reduction
Applied model	California, USA	Non-California, USA and Canada
System voltage \	1	12
No-load		
Terminal voltage	11.5	11.0
Current /	60 Max.	90 Max.
Motor revolution rpm	6,500 Min.	2,500 Min.
Minimum diameter of commutator mm (in	31.4 (1.236)	28.8 (1.134)
Minimum length of brush mm (in	11.5 (0.453)	7.0 (0.276)
Brush spring tension N (kg, lb	13.7 - 25.5 (1.4 - 2.6, 3.1 - 5.7)	11.8 - 23.5 (1.20 - 2.40, 2.65 - 5.28)
Clearance of bearing metal and armature shaft mm (in	0.2 (0.008)	0.2 (0.008)
Clearance between pinion front edge and pinion stopper mm (in)	0.5 - 2.0 (0.020 - 0.079)	0.5 - 2.0 (0.020 - 0.079)


CHARGING SYSTEM


G System Description The generator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator. MA Power is supplied at all times to generator terminal (4) through: Black fusible link (located at the battery positive terminal). 国M Voltage output through generator terminal (1), to charge the battery and operate the vehicle's electrical system, is controlled by the amount of voltage detected by the IC regulator at terminal (4). ЦC Terminal (2) of the generator supplies ground through body ground (E6). EC With the ignition switch in the ON or START position, power is supplied: through 10A fuse (No. III , located in the fuse block) to combination meter terminal (7) for the charge warning lamp. Ground is supplied to terminal 3 of the combination meter through terminal 3 of the generator. With power and ground supplied, the charge warning lamp will illuminate. When the generator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off. CL If the charge warning lamp illuminates with the engine running, a fault is indicated. Refer to "Trouble Diagnoses", "CHARGING SYSTEM", EL-27. Mi AT TF PD FA RA BR ST RS BT

ĒĹ

Wiring Diagram - CHARGE-

EL-CHARGE-01






Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

WITH IC REGULATOR



Warning lamp: "CHARGE" warning lamp in combination meter

*: When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.

MALFUNCTION INDICATOR

The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while alternator is operating:

- B terminal is disconnected.
- S terminal is disconnected or related circuit is open.
- Field circuit is open.
- Excessive voltage is produced.

1877

HA

GI


MA

EM

|||D)X(

EL-27

Generator



EL-28


CHARGING SYSTEM

Diode Check

MAIN DIODES

- In order to check diodes, they must be unsoldered from the stator.
- Use an ohmmeter to check condition of diodes as indicated in chart below.
- If any of the test results are not satisfactory, replace diode assembly.

	Ohmmet	Judgement		
	Positive ⊕			
Diados chook (Positivo sido)	Positive diode plate	Diode terminals	Diode conducts in only one	
Diodes check (Positive side)	Diode terminals	Positive diode plate	direction.	
Diodes check (Negative side)	Negative diode plate	Diode terminals	Diode conducts in only one	
Diodes check (Negative side)	Diode terminals	Negative diode plate	direction.	



GI

MA

EM LC

EC

FE

CL

MT

AT:

TF

PD

FA

RA

BR

ST


RS

BT

HA


EL

 $\mathbb{D}\mathbb{X}$



Disassembly and Assembly

- Remove rear cover.
- Heat rear cover, using heat gun, to 50°C (90°F) above room temperature to prevent bearing damage.




- Disconnect stator/diode.
- Cut diode terminals.
- Unsolder stator coil leads.


CAUTION:

Unsolder stator coil leads as fast as possible to avoid damaging diodes.

- 3. Remove stator and rotor.
- 4. Remove bearing retainer and bearing.
- 5. Assemble in reverse of disassembly.



- Insert stator coil lead into lower portion of diode terminal.
- Using pliers, crimp diode terminal around stator coil lead.
- Be sure stator coil leads do not protrude more than 3 mm (0.118 in) past diode terminal.





Solder stator coil lead and diode terminals.


CAUTION:

Solder stator coil leads and diode terminals as fast as possible to avoid damaging diodes. Use 9/1 Pb/Sn solder in assembly.

CHARGING SYSTEM







Disassembly and Assembly (Cont'd) REAR COVER INSTALLATION

1. Before installing front cover with pulley and rotor with rear cover, push brush up with fingers and retain brush by inserting brush lift wire into brush lift hole from outside.

After installing front and rear sides of generator, pull out brush lift wire.

ĒM

MA

G

LC

EC

FE

CL

MT

AT.

TF

PD

FA

RA

 \mathbb{BR}

ST

RS

BT

HA

Service Data and Specifications (SDS)


GENERATOR


Туре		LR160-727
Nominal rating	V-A	12-60
Ground polarity		Negative
Minimum revolution under no-loa (When 13.5 volts is applied)	d rpm	Less than 1,000
Hot output current (When 13.5 volts is applied)	A/rpm	More than 17/1,300 More than 48/2,500 More than 57/5,000
Regulated output voltage	٧	14.1 - 14.7
Minimum length of brush	mm (in)	6.0 (0.24)
Slip ring minimum outer diameter	mm (in)	More than 26.0 (1.024)
Rotor (Field coil) resistance	Ω	2.58


EL


]DX


Combination Switch/Check














COMBINATION SWITCH



CTT(4)

Combination Switch/Replacement

Each switch can be replaced without removing combination switch base.

MA

 $\mathbb{G}[$

LC

To remove combination switch base, remove base attaching screws.

FE

C[

MT

Before installing the steering wheel, align the turn signal cancel tab with the notch of combination switch. Refer to RS sec-

TF

PD)

FA

RA

BR


ST

RS

BT


MA


IDX



tion ("INSTALLATION", Air Bag Module and Spiral Cable").

Steering Switch/Check





AEL896A


HEADLAMP

The headlamps are controlled by the lighting switch which is built into the combination switch. Power is supplied at all times: • through 15A fuse (No. 12 , located in the fuse block) • to lighting switch terminal ③ and • through 15A fuse (No. 13 , located in the fuse block) • to lighting switch terminal ③. **Combination of the Lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied: • from lighting switch terminal ④ • to terminal ① of the Light headlamp, and • from lighting switch terminal ④ • to terminal ① of the AH headlamp. **Terminal ② of each headlamp supplies ground through body grounds ③ • Terminal ② of each headlamp supplies, the headlamp(s) will illuminate. **High beam operation/flash-to-pass operation When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or the lighting switch is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ④ • to terminal ② of the LH headlamp, and • from lighting switch terminal ③ • to terminal ② of the H headlamp, and • from lighting switch terminal ④ • to terminal ② of the RH headlamp, and • from lighting switch terminal ④ • to terminal ② of the RH headlamp, and • from lighting switch terminal ④ • to terminal ② of the RH headlamp, and • to combination meter reminal ④ of the combination meter and terminal ④ of each headlamp through body grounds (Setting) (MBS), and (MBS). **With power and ground supplied, the high beams and the hi beam indicator illuminate. **Power and ground supplied, the high beams and the hi beam indicator illuminate.	System Description (For USA)	GI
• to lighting switch terminal ②. Low beam operation When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied: • from lighting switch terminal ③ • to terminal ① of the LH headlamp, and • from lighting switch terminal ④ • to terminal ① of the RH headlamp, and • from lighting switch the headlamp supplies ground through body grounds ���, ���� and ����. **Terminal ③ of each headlamp supplies ground through body grounds ���, ���� and ����. **High beam operation/flash-to-pass operation When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or the lighting switch is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ① • to terminal ② of the LH headlamp, and • from lighting switch terminal ③ • to terminal ② of the RH headlamp, and • to combination meter terminal ④ for the hib beam indicator. Ground is supplied to terminal ④ of the combination meter and terminal ③ of each headlamp through body grounds ���, ���, ����, ����, ����, ����, ����, ����, ����, ���, ���, ����, ���, ���, ����, ���, ����, ��, ���, ���, ���, ���, ��, ���, ���, ���, ���, ��, ���, ��, ��, ��, ��, ��, ��, ���, ���, ���, ��	Power is supplied at all times: • through 15A fuse (No. 12 , located in the fuse block)	MA
When the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied: • from lighting switch terminal ③ • to terminal ① of the LH headlamp, and • from lighting switch terminal ④ • to terminal ① of each headlamp supplies ground through body grounds (MS), (MIS) and (MIS). With power and ground supplied, the headlamp(s) will illuminate. High beam operation/flash-to-pass operation When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or the lighting switch is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ② • to terminal ② of the LH headlamp, and • to combination meter terminal ④ for the hi beam indicator. Ground is supplied to terminal ① of the combination meter and terminal ③ of each headlamp through body grounds (MS), (MIS), and (MIS). With power and ground supplied, the high beams and the hi beam indicator illuminate.		EM
• from lighting switch terminal ③ • to terminal ① of the LH headlamp, and • from lighting switch terminal ② • to terminal ① of the RH headlamp. Terminal ③ of each headlamp supplies ground through body grounds ⑥ With power and ground supplied, the headlamp(s) will illuminate. High beam operation/flash-to-pass operation When the lighting switch is turned to the 2ND position and placed in HiGH ("A") position or the lighting switch is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ② • to terminal ② of the LH headlamp, and • from lighting switch terminal ③ • to terminal ② of the RH headlamp, and • to combination meter terminal ⑥ of the hi beam indicator. Ground is supplied to terminal ④ of the combination meter and terminal ③ of each headlamp through body grounds ⑥ ③ With power and ground supplied, the high beams and the hi beam indicator illuminate.	·	LC
Terminal ③ of each headlamp supplies ground through body grounds (MB), (MB) and (MB). With power and ground supplied, the headlamp(s) will illuminate. When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or the lighting switch is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ② • to terminal ② of the LH headlamp, and • to combination meter terminal ③ for the hi beam indicator. Ground is supplied to terminal ④ of the combination meter and terminal ③ of each headlamp through body grounds (MB), (MB), and (MB). With power and ground supplied, the high beams and the hi beam indicator illuminate.	 from lighting switch terminal (8) to terminal (1) of the LH headlamp, and from lighting switch terminal (4) 	ĒC
When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position or the lighting switch is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ③ • to terminal ② of the LH headlamp, and • from lighting switch terminal ③ • to terminal ② of the RH headlamp, and • to combination meter terminal ④ for the hi beam indicator. Ground is supplied to terminal ① of the combination meter and terminal ③ of each headlamp through body grounds (M®), (M®), and (M®), and (M®), the high beams and the hi beam indicator illuminate.	Terminal 3 of each headlamp supplies ground through body grounds (M49), (M105) and (M160).	FE
is placed in the PASS ("C") position, power is supplied: from lighting switch terminal (") to terminal (*) of the LH headlamp, and from lighting switch terminal (*) to terminal (*) of the RH headlamp, and to combination meter terminal (*) of the hi beam indicator. Ground is supplied to terminal (*) of the combination meter and terminal (*) of each headlamp through body grounds (**), (**), and (**), and (**). With power and ground supplied, the high beams and the hi beam indicator illuminate. PO RA RA RA RB RB RB RB RB RB RB	·	GL
• to terminal ② of the RH headlamp, and • to combination meter terminal ⑥ for the hi beam indicator. Ground is supplied to terminal ⑪ of the combination meter and terminal ③ of each headlamp through body grounds , and . With power and ground supplied, the high beams and the hi beam indicator illuminate.	is placed in the PASS ("C") position, power is supplied: • from lighting switch terminal ⑦ • to terminal ② of the LH headlamp, and	MT
grounds (M8), (M18), and (M18). With power and ground supplied, the high beams and the hi beam indicator illuminate. PO RA BR ST RS	 to terminal ② of the RH headlamp, and to combination meter terminal ⑩ for the hi beam indicator. 	AT
FA RA BR ST RS	grounds (M49), (M105), and (M160).	TF
RA BR ST BS		PD
BR ST RS LT ET		FA
ST RS BT		RA
		BR
BT		ST
		R\$
HA		BT
		HA

EL-35 1101

 $\mathbb{I}\mathbb{D}\mathbb{X}$

Wiring Diagram (For USA) - H/LAMP-



HEADLAMP

Trouble Diagnoses (For USA)

Symptom	Possible cause	Repair order	
LH headlamps do not operate.	1. Bulb 2. Grounds (M49), (M105) and	Check bulb. Check grounds	M
	(M160) 3. 15A fuse	3. Check 15A fuse (No. 12 , located in fuse block). Verify battery positive voltage is present at terminal 6 of lighting switch.	
	4. Lighting switch	4. Check lighting switch.	
RH headlamps do not operate.	1. Bulb 2. Grounds (M49), (M105) and (M160)	Check bulb. Check grounds (M49), (M105) and (M160).	E (
	3. 15A fuse	3. Check 15A fuse (No. 13 , located in fuse block). Verify battery positive voltage is present at terminal 2 of lighting switch.	Fl
LH high beam does not operate, but	4. Lighting switch	Check lighting switch. Check bulb.	@I
LH low beam operates.	Open in LH high beam circuit	Check Build. Check R/L wire between lighting switch and LH head-lamp for an open circuit.	Ĉ
	Lighting switch	3. Check lighting switch.	M
LH low beam does not operate, but LH high beam operates.	Bulb Open in LH low beam circuit	Check bulb. Check R/G wire between lighting switch and LH head-lamp for an open circuit.	
	Lighting switch	3. Check lighting switch.	
RH high beam does not operate, but RH low beam operates.	Bulb Open in RH high beam circuit	Check bulb. Check R/Y wire between lighting switch and RH head-lamp for an open circuit.	T
	3. Lighting switch	3. Check lighting switch.	Pi
RH low beam does not operate, but RH high beam operates.	Bulb Open in RH low beam circuit	Check bulb. Check R/B wire between lighting switch and RH head-lamp for an open circuit.	F
	3. Lighting switch	3. Check lighting switch.	im#
High beam indicator does not work.	1. Bulb 2. Grounds (M49), (M105) and (M160)	Check bulb in combination meter. Check grounds	R
_	3. Open in high beam circuit	Check R/Y wire between lighting switch and combination meter for an open circuit.	B[

ST

GI

RS

BT

EL

EL-37

System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate even when the parking brake is applied.

Power is supplied at all times:

- through 15A fuse (No. 12 , located in the fuse block)
- to daytime light control unit terminal (3) and
- to lighting switch terminal 6.

Power is also supplied at all times:

- through 15A fuse (No. 13 , located in the fuse block)
- to daytime light control unit terminal ② and
- to lighting switch terminal ②.

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. III), located in the fuse block)
- to daytime light control unit terminal ②.

With the ignition switch in the START position, power is supplied:

- through ignition switch terminal 4
- to daytime light control unit terminal (1).

Ground is supplied to daytime light control unit terminal (9) through body grounds (M49), (M105) and (M160).

HEADLAMP OPERATION

Low beam operation

When the lighting switch is moved to the 2ND position and placed in LOW ("B") position, power is supplied:

- from lighting switch terminal 4
- to RH headlamp terminal ①.

Ground is supplied to RH headlamp terminal ③ through body grounds (M49), (M105) and (M160). Also, when the lighting switch is turned to the 2ND position and placed in LOW ("B") position, power is supplied:

- from lighting switch terminal (8)
- to LH headlamp terminal (1).

Ground is supplied:

- to LH headlamp terminal (3)
- from daytime light control unit terminal (7)
- through daytime light control unit terminal (9)
- through body grounds (M49), (M105) and (M160).

With power and ground supplied, the low beam headlamps illuminate.

High beam operation

When the lighting switch is turned to the 2ND position and placed in HIGH ("A") position, or the lighting switch is placed in the PASS ("C") position, power is supplied:

- from lighting switch terminal 3
- to RH headlamp terminal ②.

Also, when the lighting switch is moved to the 2ND position and placed in HIGH ("A") position, or the lighting switch is placed in the PASS ("C") position, power is supplied:

- from lighting switch terminal (7)
- to daytime light control unit terminal (5)
- through daytime light control unit terminal (6)
- to LH headlamp terminal ②.

Ground is supplied in the same manner as low beam operation.

With power and ground supplied, the high beam headlamps illuminate.

HEADLAMP

System Description (For Canada) (Cont'd)

DAYTIME LIGHT OPERATION

With the engine running and the lighting switch in the OFF or 1st position, power is supplied:

- to daytime light control unit terminal 3
- through daytime light control unit terminal 6
- to LH headlamp terminal ②
- through LH headlamp terminal 3
- to daytime light control unit terminal (7)
- through daytime light control unit terminal (8)
- to RH headlamp terminal ②.

Ground is supplied to RH headlamp terminal ③ through body grounds (M49), (M105) and (M160). Because the high beam headlamps are now wired in series, they operate at half illumination.

Operation (Daytime light system for Canada)

The headlamps' high beams automatically turn on after starting the engine with the lighting switch in OFF or 1st position. Lighting switch operations other than the above are the same as conventional light systems.

Engine				Wit	h en	gine	stop	ped			With engine running								
			OFF	:		1S T			2ND)		OFF			1ST			2ND	+
Lighting switch		Α	В	С	Α	В	С	Α	В	С	Α	В	С	Α	В	С	Α	В	С
1 la calla man	High beam	Х	х	0	х	Х	0	0	Х	0	Δ*	Δ*	0	Δ*	Λ*	0	0	Х	0
Headlamp Low beam		Х	Х	Х	Х	Х	Х	х	0	Х	Х	х	Х	х	Х	Х	Х	0	Х
Parking and tail la	mp	Х	X	Х	0	0	0	0	0	0	Х	х	х	0	0	0	0	0	0
License and instrument illumination lamp		Х	Х	Х	0	0	0	0	0	0	Х	Х	Х	0	0	0	0	0	0

O: Lamp ON

FE

EC

G

MA

LC

CL

MT

AT

TF

PD

RA

BR

ST

RS

ST

HA

EL

IDX


X: Lamp OFF

 $[\]triangle$: Lamp dims

^{□:} Added functions

^{*:} When starting the engine with the parking brake released, the daytime light will come ON. When starting the engine with the parking brake applied, the daytime light won't come ON.

Schematic (For Canada)



EL-40

HEADLAMP Œ[NOTES LC EC FE CL AT TF PD BR ST

MA

MT

RA

RS


BŢ

HA


EL

IDX

Wiring Diagram (For Canada) -DTRL-



Wiring Diagram (For Canada) -DTRL- (Cont'd)





AEL872A

G

Wiring Diagram (For Canada) -DTRL- (Cont'd)

EL-DTRL-03







Trouble Diagnoses (For Canada)

DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

(Data are reference values.)

				(Data are reference values
Ter- minal No.	Item		Condition	Judgement standard
1	Start signal	(55)	When turning ignition switch to ST	Battery positive voltage
		Can	When turning ignition switch to ON from ST	1V or less
		Coff	When turning ignition switch to OFF	1V or less
2	Power source	(Con)	When turning ignition switch to ON	Battery positive voltage
		Coff	When turning ignition switch to OFF	Battery positive voltage
3	Power source	(Con)	When turning ignition switch to ON	Battery positive voltage
		(COFF)	When turning ignition switch to OFF	Battery positive voltage
4	Lighting switch (Low beam)		When turning lighting switch to HEAD (2nd position)	Battery positive voltage
5	Lighting switch (High beam)		When turning lighting switch to HIGH BEAM	Battery positive voltage
			When turning lighting switch to FLASH TO PASS	Battery positive voltage
6	LH high beam		When turning lighting switch to HIGH BEAM	Battery positive voltage
į			When releasing parking brake with engine running and turning lighting switch to OFF (daytime light operation) CAUTION: Block wheels and ensure selector lever is in "N" or "P" position.	Battery positive voltage
7	LH headlamp control (ground)		When lighting switch is turned to HEAD	1V or less
			When releasing parking brake with engine running and turning lighting switch to OFF (daytime light operation) CAUTION: Block wheels and ensure selector lever is in "N" or "P" position.	Approx. half battery voltage
8	RH high beam		When turning lighting switch to HIGH BEAM	Battery positive voltage
			When releasing parking brake with engine running and turning lighting switch to OFF (daytime light operation) CAUTION: Block wheels and ensure selector lever is in "N" or "P" position.	Approx. half battery voltage

EL-45 1111

MA

HEADLAMP

Trouble Diagnoses (For Canada) (Cont'd)

Ter- minal No.	item		Condition	Judgement standard				
9	Ground			_				
10	Parking brake switch	(2)	When parking brake is released	Battery positive voltage				
			When parking brake is applied	1.5V or less				
11	Generator	CON	When turning ignition switch to ON	1V or less				
	6-3		When engine is running	Battery positive voltage				
	3	Cort	When turning ignition switch to OFF	1V or less				
12	Power source	(Con)	When turning ignition switch to ON	Battery positive voltage				
			When turning ignition switch to ST	Battery positive voltage				
			When turning ignition switch to OFF	1V or less				

EL-46

Bulb Specifications

Item	Wattage (W)	Bulb No.				
Conventional bulb	65/55	6052				
Halogen bulb	65/35	H6059				

MA

EM

GI

Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated according to their operation

Before performing aiming adjustment, make sure of the following: **CAUTION:**

EC


- Keep all tires inflated to correct pressures.
- Place vehicle on level ground.

FE

See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

CL

MT



LOW BEAM

AT

TF

- 1. Turn headlamp low beam ON.
- Use adjusting screws to perform aiming adjustment.
- First tighten the adjusting screw all the way and then

PD)

make adjustment by loosening the screw.

FA

Adjust headlamps so that upper edge and left edge of high intensity zone are within the acceptable range as shown

BR

 $\mathbb{R}\mathbb{A}$

Dotted lines in illustration shown center of headlamp.

"H": Horizontal center line of headlamps.


"WL": Distance between each headlamp center.

ST

RS

BT

MA




high intensity zone Height of lamp centers 100 (4) 100 (4) 100 100 (4) 100 100 100 100 (4) (4) Left edge of high intensity zone = ACCEPTABLE RANGE

Unit: mm (in)

SEL914D

HEADLAMP



Aiming Adjustment (Cont'd) AIMER ADJUSTMENT MARK

When using a mechanical aimer, adjust adapter legs to the data marked on the headlamps.

Example:


4H 2V
Vertical side: 2
Horizontal side 4

GI Back-up Lamp/Wiring Diagram -BACK/L-EL-BACK/L-01 MA IGNITION SWITCH ON or START A : A/T models Refer to "EL-POWER". 10A 11 M>: M/T models W/B W/B W/B 20 LC EC W/B JOINT CONNECTOR-2 INHIBITOR SWITCH II R/B FE R/B (M142) M265 23 W/B REAR COMBINATION LAMP RH (BACK-UP) REAR COMBINATION LAMP LH (BACK-UP) CL. 6 MT W/B R/B W/B AT POSITION SWITCH **E**17 TF OTHERS PD 14 FA RA BR ST ₩177 R\$ Refer to last page (Foldout page). (M142) BT 3 4 5 6 7 8 M109 1 M26 5 GY HA IDX

AEL908A

Parking, License, Tail and Stop Lamps/Wiring Diagram -TAIL/L-EL-TAIL/L-01 BATTERY Refer to "EL-POWER". 10A LIGHTING SWITCH STOP 2ND (M134) LAMP SWITCH OFF RELEASED (M138) DEPRESSED ■ P/L ■ A Next page (R1)(M141) 5 G/ (C1)<u>©</u> HIGH-MOUNTED STOP LAMP ■P/L ■B Next page (R4) G/Y G/Y 4 4 REAR COMBINATION LAMP RH REAR COMBINATION LAMP LH 5 SIDE MARKER SIDE MARKER STOP STOP (T3) JOINT CONNECTOR-2 (77)(M142)6 (M109) <u>©</u> (C1)M49 M105 M160 Refer to last page (Foldout page). (M142) (M109 123 T3, T7 456 W W

Parking, License, Tail and Stop Lamps/Wiring \mathbb{G} Diagram -TAIL/L- (Cont'd) EL-TAIL/L-02 MA Preceding 国M SB : With step bumper XB : Without step bumper FRONT PARKING LAMP RH FRONT LC PARKING LAMP LH EC FE Preceding B P/L P ŒĽ MT LICENSE LAMP LH LICENSE LAMP RH LICENSE LAMP LH LICENSE LAMP RH AT \bigcirc (T4) **T**6) **T2**) TF PD FA $\mathbb{R}\mathbb{A}$ BR ST RS BT 3 4 5 6 7 8 M109 9 10 11 12 13 14 W HA



EL

IDX

Turn Signal and Hazard Warning Lamps/System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. 10 , located in the fuse block)
- to hazard switch terminal (8)
- through terminal (7) of the hazard switch
- to combination flasher unit terminal (1)
- through terminal 3 of the combination flasher unit
- to turn signal switch terminal (5).

Ground is supplied to combination flasher unit terminal 2 through body grounds (M49), (M105) and (M160).

LH turn

With the turn signal switch in the LH position, power is supplied from turn signal switch terminal 3 to:

- front turn signal lamp LH terminal ②
- rear combination lamp LH terminal 2, and
- combination meter terminal 9.

Ground is supplied:

- to front turn signal lamp LH terminal ①, and
- to combination meter terminal 42
- through body grounds (M49), (M105) and (M160).

Ground is supplied to rear combination lamp LH terminal 6 through body ground (M177). With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

With the turn signal switch in the RH position, power is supplied from turn signal switch terminal 6 to:

- front turn signal lamp RH terminal ②
- rear combination lamp RH terminal ②, and
- combination meter terminal 35.

Ground is supplied:

- to front turn signal lamp RH terminal (1), and
- to combination meter terminal 42
- through body grounds (M49), (M105) and (M160).

Ground is supplied to rear combination lamp LH terminal (6) through body ground (M177). With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal 2 through:

• 10A fuse (No. |18 , located in the fuse block).

With the hazard switch in the ON position, power is supplied:

- through terminal (7) of the hazard switch
- to combination flasher unit terminal (1)
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds (M49), (M105) and (M160). Power is supplied through terminal ③ of the hazard switch to

- front turn signal lamp LH terminal ②
- rear combination lamp LH terminal ②, and
- combination meter terminal (9).

Power is supplied through terminal (4) of the hazard switch to

- front turn signal lamp RH terminal ②
- rear combination lamp RH terminal ②, and
- combination meter terminal 35.

Ground is supplied:

- to terminal (1) of the front turn signal lamps, and
- to combination meter terminal 42
- through body grounds (M49), (M105) and (M160).

Ground is supplied to rear combination lamps terminal (6) through body ground (1177). With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

EL-52

EXTERIOR LAMP

NOTES

G]

MA

EW

LC

ĒC

CL

MT

TF

PD

FA

RA

BR

ST


RS

BT


HA

EL

Turn Signal and Hazard Warning Lamps/Wiring Diagram –TURN–



Turn Signal and Hazard Warning Lamps/Wiring Diagram -TURN- (Cont'd)




AEL910A

G[

Turn Signal and Hazard Warning Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	Hazard switch Combination flasher unit Open in combination flasher unit circuit	Check hazard switch. Refer to combination flasher unit check. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	1. 10A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit	 Check 10A fuse (No. 10 , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 8 of hazard switch. Check hazard switch. Check turn signal switch. Check G wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit	 Check 10A fuse (No. 18 , located in fuse block). Verify battery positive voltage is present at terminal 2 of hazard switch. Check hazard switch. Check G wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	1. Bulb 2. Grounds (M49), (M105) and (M160)	1. Check bulb. 2. Check grounds (M49), (M105) and (M160).
Rear turn signal lamp LH or RH does not operate.	1. Bulb 2. Ground (M177)	1. Check bulb. 2. Check grounds (M177).
LH and RH turn indicators do not operate.	1. Grounds (M49), (M105) and (M160)	1. Check grounds (M49), (M105) and (M160).
LH or RH turn indicator does not operate.	1. Bułb	Check bulb in combination meter.



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

EL-56

EXTERIOR LAMP

Bulb Specifications

HEADLAMPS

Item	Wattage (W)	Bulb No.
Conventional bulb	65/55	6052
Halogen bulb	65/35	H6059

OTHER LAMPS

OTHER LAMPS			. LC
Item	Wattage (W)	Bulb No.	
Front turn signal lamp	27	1156	EC
Front parking lamp	3.8	194	<u> </u>
Rear combination lamp			cc
Turn signal	27	1156	FE
Stop/Tail	27/8	1157	
Back-up	27	1156	CL
Rear side marker	3.4	194	
License plate lamp	3.8 or 5	168 (For 3.8W lamp)	MT
High-mounted stop lamp	2.3	2723	

AT

G[

 $\mathbb{M}\mathbb{A}$

EM

PD

TF

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

28

BT

HA

EL

INTERIOR LAMP

Illumination/System Description

Power is supplied at all times:

• through 10A fuse (No. 22), located in the fuse block)

• to lighting switch terminal (1).

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch is a thumbwheel that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.

The glove box lamp is not controlled by the illumination control switch. The intensity of this lamp does not change.

The clock display (if equipped) will dim when the lighting switch is turned to the 1ST or 2ND position.

The following chart shows the power and ground connector terminals for the components included in the illumination system.


Component	Power terminal	Ground terminal
Illumination control switch	(5)	2
Glove box lamp	1	2
Clock*	30)	(5)
Combination meter	40	5
ASCD main switch*	4	(5)
Hazard switch	6	(5)
A/T device indicator*	3	4
Heater	2	· ①
Radio	8	⑦

^{*} If equipped.

With the exception of the glove box lamp, the ground for all of the components is controlled through terminals 3 and 6 of the illumination control switch and body grounds (M49), (M105) and (M106). When the glove box is open, glove box lamp terminal (2) is grounded through glove box lamp switch and body

grounds (M49), (M105) and (M160).

RADIO (ILLUHINATION) RADIO (ILLUHINATION) RADIO (ILLUHINATION)



RS

ST

G[

MA

LC

EC

FE

C[

MT

AT

TF

PD

FA

RA


BR

87


HA

EL

Illumination/Wiring Diagram -ILL-



Illumination/Wiring Diagram -ILL- (Cont'd)





AEL298A-B

[DX


Illumination/Wiring Diagram -ILL- (Cont'd)

EL-ILL-03









AEL875A

INTERIOR LAMP

Bulb Specifications

Item	Wattage (W)	Bulb No.
Interior lamp	10	_
Map lamp	8	

EL-64

METERS AND GAUGES

System Description	GI
With the ignition switch in the ON or START position, power is supplied: • through 10A fuse (No. 11, located in the fuse block) • to combination meter terminal 17 for the water temperature gauge, fuel gauge, speedometer and	IM2
tachometer (if equipped). Ground is supplied: to combination meter terminal ② [and terminal ④ (with tachometer)] through body grounds (M49), (M105) and (M160).	
WATER TEMPERATURE GAUGE	LO
The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter. As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal (a) (without tachometer) or (3) (with tachometer) of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".	
TACHOMETER	
The tachometer indicates engine speed in revolutions per minute (rpm). The tachometer is regulated by a signal: from terminal ③ of the ECM (ECCS control module) to combination meter terminal ③ for the tachometer.	CL
FUEL GAUGE	MI
The fuel gauge indicates the approximate fuel level in the fuel tank. The fuel gauge is regulated by a variable ground signal supplied: • to combination meter terminal (8) for the fuel gauge	AT
 from terminal ① of the fuel tank gauge unit through terminal ② of the fuel tank gauge unit and through ECM (ECCS control module) terminal ⑤. 	TF
SPEEDOMETER	P(D
The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.	0 🗷
 The voltage is supplied: to combination meter terminals 2 and 3 for the speedometer from terminals 1 and 2 of the vehicle speed sensor. The speedometer converts the voltage into the vehicle speed displayed. 	FA
	RA
	ST
	RS
	BT
	HA

EL-65 1131

IDX

Combination Meter WITH TACHOMETER 50 60 AIR T 1∞ .70 000000 120 80 x 1000 r/min 18:88 PUSH M (O **6** HEHRER 🐐 🖘 🗊 "AB\$" or (@s) "BRAKE" or (1) 0 0 0 \bigcirc 000 000 0 0 0 o 0/ 0 0 0 0 • 0 0 23 29 24 30 25 31 (N7) 1 7 2 8 3 9 (N5) 13 18 N4 14 19 35 39 36 40 • 37 41 38 42 15 20 16 21 17 22 4 10 5 11 6 12 SEAT BELT OTIL OTIL OTIL CHARGE CHARGE FUEL PUEL ABS ABS ABS WASHER 10 9 12 34 17 CLOCK (DISPLAY) HIGH BEAN CLH © LH © RHTURN LLUMINATION GAUGE

EL-66

CLOCK

ا 33

GAUGE

TEMP (

AEL897A

TACHONETER


ا 42

Combination Meter (Cont'd) G! WITHOUT TACHOMETER MA CRUISE 100 .70 МРН 000000 120 80 LC TEMP FUEL 100 E¢ HEHREČÍ: 🍂 🖘 🗂 FE "ABS" or ((48)) "BRAKE" or ((!)) 0 0 CL. 0 MT 0 000 0 0 0 0 0 0 AT 0 0 TF PD RA 1 7 2 8 3 9 • 4 10 5 11 6 12 (N7) (N5) 23 29 24 30 25 31 • 26 32 27 33 28 34 13 18 14 19 • 15 20 16 21 17 22 (N4) (N6) 35 39 36 40 • BR ST RS 12 36 40 30 10 9 BT CHARGE CHARGE FUEL ON INDICATOR ABS WASHER CLOCK (DISPLAY) GAUGE HIGH BEAM BRAKE © 0/0 0FF MA GAUGE MALFUNCTION FUEL WATER EL IDX 42 39 ا 16 13

AEL898A

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram -METER-**EL-METER-01** IGNITION SWITCH W/B ON or START 19 W/B F1 WT>: With tachometer (M155) JOINT Refer to "EL-POWER". CONNECTOR-2 OT : Without tachometer W/B $\overline{N1}$ (M142) 11 W/B 17 COMBINATION METER N4 N5 **TACHOMETER FUEL** WATER GAUGE TEMPERATURE (N6), (N7) **SPEEDOMETER** GAUGE 22 28 W/L Y/G Y/R Y/G E13 C14 B14 E3 B12 D15 C16 Y/G W/L W В Y/R Y/G W/L W 26 3 1 ECM (ECCS CONTROL MODULE) JOINT FUEL TANK GAUGE UNIT THERMAL TRANSMITTER VSP TACH CONNECTOR-2 (M142) (M17) (C4) M112GND-A 50 2 3 B/G (M10B) B/G 2 1 VEHIC: E SPEED SENSOR (E16) M49 M105 M160 Refer to last page (Foldout page). (M112) (M142) (M155) , (N1) 9 8 7 3 2 1 B (N6)

METERS AND GAUGES




L


IDX

EL-69 1135

Inspection/Fuel Gauge




METERS AND GAUGES




EL.

HA


 $\mathbb{D}\mathbb{X}$





METERS AND GAUGES




EL-73









Fuel Tank Gauge Unit Check

• For removal, refer to FE section ("Fuel Pump and Gauge", "FUEL SYSTEM").

Check the resistance between terminals 1 and 4.

Ohm	meter		Float po	Resistance value	
(+)	(-)		mm	(Ω)	
		*3	Full	241 (9.49)	Approx. 4.5 - 5.5
1	4	*2	1/2	115 (4.53)	Approx. 31.5 - 33.5
		*1	Empty	8 (0.31)	Approx. 80 - 83

Fuel Warning Lamp Sensor Check

• It will take a short time for the bulb to light.

Thermal Transmitter Check

Check the resistance between the terminals of thermal transmitter and body ground.


Water temperature	Resistance
60°C (140°F)	Approx. 70 - 90Ω
100°C (212°F)	Approx. 21 - 24Ω

Oil Pressure Switch Check

	Oil pressure kPa (kg/cm², psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	No
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1.4 - 2.8)	Yes

Check the continuity between the terminals of oil pressure switch and body ground.

METERS AND GAUGES



Vehicle Speed Sensor Signal Check

1. Remove vehicle speed sensor from transmission.

 Turn vehicle speed sensor pinion quickly and measure voltage across 1 and 2.

GI

MA

LC

EC

Æ

ĈL.

MT

AT

TF

PD

FA

RA

ST

RS

BT

HA

EL

IDX

System Description

With the ignition switch in the ON or START position, power is supplied:

- through 10A fuse (No. 111, located in the fuse block)
- to combination meter terminal (17), and
- to 4WD switch terminal ①.

With the ignition switch in the ON or START position, power is supplied:

- through 15A fuse (No. 9, located in the fuse block)
- to bulb check relay terminal ②.

Ground is supplied:

- to combination meter terminal (2),
- bulb check relay terminal (5),
- brake fluid level switch terminal (2), and
- washer fluid level switch terminal ② (For Canada models only)
- through body grounds (M49), (M105) and (M160).

Ground is supplied:

- to seat belt buckle terminal (2), and
- fuel tank gauge unit terminal (6)
- through body ground (M177).

AIR BAG WARNING LAMP

During prove out or when an air bag malfunction occurs, the ground path is interrupted:

- from the air bag diagnosis sensor unit terminal (5)
- to combination meter terminal 39.

Ground is then supplied:

• through combination meter terminal ②.

With power and ground supplied, the air bag warning lamp (LEDs) illuminate.

For further information, refer to RS section ("TROUBLE DIAGNOSES").

LOW FUEL LEVEL WARNING LAMP

The amount of fuel in the fuel tank is determined by the fuel level sensor in the fuel tank. A signal is sent from fuel tank gauge unit terminal ③ to combination meter terminal ⑥. The fuel level sensor will illuminate the low fuel level warning lamp when the fuel level is low.

With power and ground supplied, the low fuel level warning lamp illuminates.

LOW OIL PRESSURE WARNING LAMP

Low oil pressure causes oil pressure switch terminal ① to provide ground to combination meter terminal ②. With power and ground supplied, the low oil pressure warning lamp illuminates.

LOW WASHER FLUID LEVEL WARNING LAMP (For Canada models only)

When the washer fluid level is low, ground is supplied:

- to combination meter terminal (27)
- from washer fluid level switch terminal ①.

With power and ground supplied, the low washer fluid level warning lamp illuminates.

SEAT BELT WARNING LAMP

When the driver's seat belt is unfastened, ground is supplied:

- to combination meter terminal 25
- from seat belt buckle switch terminal ①.

With power and ground supplied, the seat belt warning lamp illuminates.

MALFUNCTION INDICATOR LAMP

During prove out or when an engine control malfunction occurs, ground is supplied:

- to combination meter terminal (15)
- from ECM terminal (18).

1142

With power and ground supplied, the malfunction indicator lamp illuminates.

For further information, refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

EL-76


WARNING LAMPS

WARNING LAWPS	
System Description (Cont'd)	ക്വ
ABS WARNING LAMP	GI
During prove out or when an ABS malfunction occurs, ground is supplied: ■ to combination meter terminal ③ ■ from ABS control unit terminal ②. With power and ground supplied, the ABS warning lamp illuminates.	MA
For further information, refer to BR section ("Self-diagnosis", "TROUBLE DIAGNOSES").	EM
BRAKE WARNING LAMP	
When the parking brake is applied, or the brake fluid level is low, ground is supplied: to combination meter terminal ②6 from parking brake switch terminal ①, or brake fluid level switch terminal ①. With power and ground supplied, the brake warning lamp illuminates.	LC EC
BULB CHECK RELAY (brake warning lamp prove out)	
When the ignition switch is in the ON or START position, and the generator grounds terminal ③, ground is supplied to the bulb check relay terminal ①.	FE
With power and ground supplied, the bulb check relay is energized, providing a ground path for the brake warning lamp:	©L
 through combination meter terminal to bulb check relay terminal to bulb check relay terminal With power and ground supplied, the brake warning lamp illuminates. 	MT
CHARGE WARNING LAMP	
During prove out or when a generator malfunction occurs, ground is supplied: to combination meter terminal ② from generator terminal ③.	AT
With power and ground supplied, the charge warning lamp illuminates.	TF
4WD INDICATOR LAMP (with 4-wheel drive)	
When the 4WD switch is activated, power is supplied: from 4WD switch terminal ① to combination meter terminal ፡	PD
With power and ground supplied, the 4WD indicator lamp illuminates.	FA
	RA
	3R
	ST
	RS
	BT
	HA

EL-77 1143

ΕL


Schematic




GI Wiring Diagram –WARN– **EL-WARN-01** MA (FD): With 4-wheel drive EM **IGNITION SWITCH** w/B ON or START 20 JOINT Refer to "EL-POWER". LC CONNECTOR-2 10A M14211 EC W/B W/B ■W/B■ANext page $\overline{(N1)}$ FE w/B COMBINATION METER CL I AIR BAG WARNING AIR BAG LED (N4), (N6) Next page LAMP MALFUNCTION INDICATOR LAMP MT AT 15 TF R/W C15 N1 M155 RW PD) 18 1 JOINT CONNECTOR-2 LED-R (ECCS FA (M142) CONTROL MODULE) 15 G/Y M112 LED (Refer to "EC-MIL/DL"). RA В AIR BAG DIAGNOSIS SENSOR UNIT BR (M175) (Refer to "RS-SRS"). ST RS Refer to last page (Foldout page). M142O 3 4 (M129) 1 11 23 5 24 13 🔲 4 10 17 19 20 M175 5 6 7 8 9 10 9 8 3 7 18 14 2 22 6 12 15 16 21 (M155), (N1) BT (N4)HA (M112) 1 2 3 40 41 53 54 55 20 21 22 23 56 104 105 106 EL 10 24 25 26 27 28 44 45 46 57 58 59 60 61 112 108 109 29 30 31 32 33 47 48 62 63 64 65 11 12 13 14 70 15 16 17 18 34 35 36 37 51 52 66 67 68 69

AEL877A

Wiring Diagram -WARN- (Cont'd)




Wiring Diagram -WARN- (Cont'd)




AEL879A

IDX

WARNING LAMPS





Diode Check

• Check continuity using an ohmmeter.

• Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.

 Diodes for warning lamps are built into the combination meter printed circuit.

Refer to EL-66.


System Description	Ĝ
The warning chime is combined with the warning chime unit. Power is supplied at all times: through 10A fuse (No. 21, located in the fuse block)	MA
 to key switch terminal ①. Power is supplied at all times: through 10A fuse (No. 22), located in the fuse block) 	EM
 to lighting switch terminal ①. With the ignition switch in the ON or START position, power is supplied: through 10A fuse (No. ① located in the fuse block) to warning chime unit terminal ③. 	L©
Ground is supplied to warning chime unit terminal (4) through body grounds (M49), (M105) and (M160).	EC
Ignition key warning chime With the key inserted in the ignition switch in the OFF or ACC position, and the driver's door open, the warn-	
ing chime will sound. A battery positive voltage signal is sent: • from key switch terminal ②	FE
 to warning chime unit terminal ⑦. Ground is supplied: 	CL
 from door switch LH terminal ③ to warning chime unit terminal ⑤. 	
Door switch LH terminal ① is grounded through body ground 1777.	MT
Light warning chime	
With the ignition switch in the OFF or ACC position, the driver's door open, and the lighting switch in the 1ST or 2ND position, the warning chime will sound. A battery positive voltage signal is sent: • from lighting switch terminal [5]	AT
 to warning chime unit terminal ®. Ground is supplied: 	TF
• from door switch LH terminal ③	
• to warning chime unit terminal (5). Door switch LH terminal (1) is grounded through body ground (M177).	PD
Seat belt warning chime	
With the ignition switch turned from the OFF or ACC position to the ON position, and the seat belt unfastened (seat belt buckle switch ON), the warning chime will sound for approximately 7 seconds.	FA
Ground is supplied: • from seat belt buckle switch terminal ①	RA
• to warning chime unit terminal ②. Seat belt buckle switch terminal ② is grounded through body ground (M177).	
Seat beit buckle switch terminal (2) is grounded through body ground (1177).	BR
	ST
	RS
	BT
	HA


EL

IDX

1149

Wiring Diagram -CHIME-





Trouble Diagnoses

SYMPTOM CHART

PROCEDURE		Preliminary Check		Main Power Supply and Ground Circuit Check	Diagnostic Procedure		re ·		
REFERENCE PAGE	EL-86	EL-86	EL-86	EL-87	EL-88	EL-89	EL-89 EL-90		
SYMPTOM	Preliminary check 1	Preliminary check 2	Preliminary check 3	Main power sup- ply and Ground circuit check	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	- L©	
Light warning chime does not activate.	0			0	0			- EC	
Ignition key warning chime does not acti- vate.		0		0		0		- FE - GL	
Seat belt warn- ing chime does not activate.			0	0			0	- VI	

AT

G[

TF PD

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

87


HA

ΞL

Trouble Diagnoses (Cont'd) PRELIMINARY CHECK


Preliminary check 1

• Light warning chime does not activate.



Preliminary check 2


Ignition key warning chime does not activate.




Preliminary check 3

Seat belt warning chime does not activate.

Go to "DIAGNOSTIC PROCEDURE 3", EL-90.





Trouble Diagnoses (Cont'd) MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Main power supply

	Battery pos	itive voltage existenc	e condition	
Terminals	Ignition switch posit	gnition switch position	ion	
	OFF	ACC	ON	
3 - 4	No	No	Yes	

Ground circuit

AEL335A

Terminals	Continuity
4 - Ground	Yes

GI

MA

EM

LC

EC

FE

CL

MT

TF

AT*

PD

FA

RA

BR

ST


RS

BT

HA


ΕL

[DX




^{*:} Specifications may vary depending on the type of tester.

Before performing this inspection, refer to the instruction manual of the tester.



EL-89 1155



Door switch LH LH connector (M171)

Trouble Diagnoses (Cont'd) **ELECTRICAL COMPONENTS INSPECTION**

Door switch

Check continuity between terminals (1) and (3) when door switch is pushed and released.

Terminal No.	Condition	Continuity
1 - 3	Door switch is pushed.	No
	Door switch is released.	Yes



G[




LC











Seat belt buckle

switch connector (M173)

Key switch

AEL402A

AEL404A

AEL405A

Check continuity between terminals (1) and (2) when ignition key is drawn and inserted.

Terminal No.	Condition	Continuity
① · ②	Ignition key is drawn. No Ignition key is inserted. Yes	No
()·(2)		Yes

AT



FA

Seat belt buckle switch

Check continuity between terminals (1) and (2) when seat belt LH is fastened and unfastened.

Terminal No.	Condition	Continuity
	Seat belt LH is fastened.	No
① - ②	Seat belt LH is unfastened.	Yes

$\mathbb{B}\mathbb{R}$


 $\mathbb{R}\mathbb{A}$

ty	_
	-






HA



Check continuity between terminals 1 and 5 when lighting switch is turned to OFF and 1st or 2nd position.

Terminal No.	Condition	Continuity
Lighting switch is turned to OFF position. Lighting switch is turned to 1st or 2nd position.	Lighting switch is turned to OFF position.	No
	Yes	



System Description

WIPER OPERATION

The wiper switch is controlled by a lever built into the combination switch.

There are three wiper switch positions:

- LO speed
- HI speed
- INT (Intermittent) (if equipped).

With the ignition switch in the ACC or ON position, power is supplied:

- through 20A fuse (No. 2), located in the fuse block)
- to wiper motor terminal (4).

Low and high speed wiper operation

Ground is supplied to wiper switch terminal 6 through body grounds M49, M105 and M160.

When the wiper switch is placed in the LO position, ground is supplied:

- through terminal 4 of the wiper switch
- to wiper motor terminal (2).

With power and ground supplied, the wiper motor operates at low speed.

When the wiper switch is placed in the HI position, ground is supplied:

- through terminal 3 of the wiper switch
- to wiper motor terminal 3.

With power and ground supplied, the wiper motor operates at high speed.

Auto stop operation

When the wiper switch is placed in the OFF position, the wiper motor will continue to operate until the wiper arms reach the base of the windshield.

When the wiper switch is placed in the OFF position, ground is supplied:

- from terminal (4) of the wiper switch
- to wiper motor terminal (2), in order to continue wiper motor operation at low speed.

The ground path to terminal 4 of the wiper switch is supplied:

- through terminal (8) of the wiper switch
- to wiper amplifier shorting connector terminal (3) (without intermittent wipers), or
- to wiper amplifier terminal (3) (with intermittent wipers)
- through wiper amplifier shorting connector terminal 6 (without intermittent wipers), or
- through wiper amplifier terminal 6 (with intermittent wipers)
- to wiper motor terminal (5)
- through terminal (6) of the wiper motor, and
- through body grounds (M49), (M105) and (M160).

The ground path is interrupted and the wiper motor stops when the wiper arms reach the base of the wind-shield.

Intermittent operation

The wiper motor operates the wiper arms one time at low speed at a set interval of approximately 4 to 12 seconds. This feature is controlled by the wiper amplifier.

When the wiper switch is placed in the INT position, ground is supplied:

- to wiper amplifier terminal (4)
- from wiper switch terminal ⑦
- through wiper switch terminal (6), and
- through body grounds (M49), (M105) and (M160).

The desired interval time is input:

- to wiper amplifier terminal (5)
- from wiper switch terminal (1).

Based on these two inputs, an intermittent ground is supplied:

- to wiper motor terminal (2)
- through the wiper switch terminal (4)
- to wiper switch terminal (8)
- from wiper amplifier terminal (3).

With power and ground supplied, the wiper motor is activated.


The wiper motor operates at low speed at the desired time interval.


WIPER AND WASHER System Description (Cont'd) G **WASHER OPERATION** With the ignition switch in the ACC or ON position, power is supplied: MA through 20A fuse (No. 7 , located in the fuse block) to washer motor terminal (1). When the lever is pulled to the WASH position, ground is supplied: to washer motor terminal ②, and to wiper amplifier terminal ⑦ (with intermittent wipers) from terminal (5) of the wiper switch LC through terminal 6 of the wiper switch, and through body grounds (M49), (M105) and (M160). With power and ground supplied, the washer motor operates. The wiper motor operates twice at low speed for approximately 3 seconds to clean the windshield. This feature is controlled by the wiper amplifier in the same manner as the intermittent operation. FE CL MT ΑĪ TF PD) FA RA BR ST RS BT HA

[:D)X(

Wiring Diagram -WIPER-

MODELS WITH INTERMITTENT WIPERS







WIPER AND WASHER Wiring Diagram -WIPER- (Cont'd) G **MODELS WITHOUT INTERMITTENT WIPERS** MA**EL-WIPER-02** IGNITION SWITCH ACC or ON Refer to "EL-POWER". 7 LC EC FE WIPER MOTOR Œ[AMPLIFIER SHORTING CONNECTOR (M3) M (M4)WASHER MOTOR HIGH STOP MT (M57) 2 L/R 3 LW AT TF PD L/B 5 LW 3 B/L WIPER SWITCH FA (M132) LO $\mathbb{R}\mathbb{A}$ WASH OFF WASH 88 JOINT CONNECTOR-2 (M142) ST **B** ■ 6 2 **■** B RS Refer to last page (Foldout page). M142 BT HA EL

AEL881A

IDX



WIPER AND WASHER



(GI

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR


ST

RS

BT


HA

IDX




Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 3

(Models with intermittent wipers)
SYMPTOM: Wiper and washer activate individually but not in combination.



WIPER AND WASHER



Wiper Amplifier Check

1. Connect as shown in the figure at left.

If test lamp comes on when connected to terminal ② and battery ground, wiper amplifier is normal. GI

MA

图M

LC

EC

Mit

AT

TF

PD)

RA

BR

ST

Installation

Turn ignition ON.

 Prior to wiper arm installation, turn on wiper switch and then turn it "OFF". Allow wiper to operate until its Auto Stop position is reached before turning ignition off.

3. Lift the blade up and then set it down onto glass surface. Set the blade center to clearance "C" just before tightening nut.


4. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".

5. Ensure that wiper blades stop within clearance "C".

Clearance "C": 20 - 30 mm (0.79 - 1.18 in)

Tighten windshield wiper arm nuts to specified torque.
 Windshield wiper:

(1.3 - 1.8 kg-m, 9 - 13 ft-lb)



Ħ

1DX

EL-99

8

R\$


200


PT


WIPER AND WASHER

Installation (Cont'd) • Before reinstalling wip

Before reinstalling wiper arm, clean the pivot area as illustrated. This will reduce possibility of wiper arm looseness.








Washer Nozzle Adjustment

 Adjust washer nozzle with suitable tool as shown in the figure at left

Adjustable range: ±10°



AEL882A

System Description

Refer to Owner's Manual for audio system operating instructions.

WITH PREMIUM AUDIO SYSTEM

Power is supplied at all times:

- through 10A fuse (No. 20 , located in the fuse block)
- to radio and cassette player terminal (6).

Power is supplied at all times:

- through 15A fuse (No. 11), located in the fuse block)
- to rear speaker amplifier terminal 2.

With the ignition switch in the ACC or ON position, power is supplied:

- through 10A fuse (No. 6, located in the fuse block)
- to radio and cassette player terminal (10).

Ground is supplied through the case of the radio and cassette player.

Ground is also supplied:

- to rear speaker amplifier terminal (7)
- through body ground (M177).

When the system is on, remote on signal is supplied:

- from the radio and cassette player terminal 12
- to the rear speaker amplifier terminal (1).

And audio signals are supplied:

- through radio and cassette player terminals (1), (2), (3), (4), (13), (14), (15) and (16)
- to terminals (5), (2), (4) and (1) of the rear speaker amplifier and the door speakers, and
- through rear speaker amplifier terminals 3, 10, 8 and 9
- to the rear speakers.

WITH BASE AUDIO SYSTEM

Power is supplied at all times:

- through 10A fuse (No. 20), located in the fuse block)
- to radio and cassette player terminal 6.

With the ignition switch in the ACC or ON position, power is supplied:

- through 10A fuse (No. 6, located in the fuse block)
- to radio and cassette player terminal ①.

Ground is supplied through the case of the radio and cassette player.

When the system is on, audio signals are supplied:


- through radio and cassette player terminals (1), (2), (3), and (4)
- to the door speakers, and
- through radio and cassette player terminals (3), (4), (5) and (6) (with rear speakers)
- to the rear speakers (with rear speakers).


Œ[**Schematic PREMIUM AUDIO SYSTEM** MATo !!!umination 10 EC ROD FE CL RADIO AND CASSETTE PLAYER MT AT TF IGNITION SWITCH ACC or DN T FUSE PD 16 REAR SPEAKER AMPLIFIER 1 FA 13 10 Ż rus∉ BATTERY $\mathbb{R}\mathbb{A}$ BR Fuse BATTERY ST RS BT HA EL

AEL294A

Wiring Diagram -AUDIO-

PREMIUM AUDIO SYSTEM





To EL-ILL

RADIO AND CASSETTE PLAYER

(M502)

DOOR SPEAKER RH

(0103)

FR RH+

FR RH-

3

FR LH+

2 |

PU

1 2

10 8 4 2 M116 9 7 6 5 3 1 W

10 8 6 4 2 M502 9 7 5 3 1 W

DOOR SPEAKER LH__

(M172)

1 O 2 3 4 5 6 W, D102 W

(D4)

FR LH-

Wiring Diagram -AUDIO- (Cont'd)

RR LH+

3

RR LH-

10

G/B G
G/B G
G/B G
G/B G

RR RH+

8

GY/R

GY/R

REAR SPEAKER LH

(M303)

 $\stackrel{\hbox{\scriptsize (M302)}}{\hbox{\scriptsize B}}$, $\stackrel{\hbox{\scriptsize (M303)}}{\hbox{\scriptsize B}}$, $\stackrel{\hbox{\scriptsize (D4)}}{\hbox{\scriptsize B}}$, $\stackrel{\hbox{\scriptsize (D103)}}{\hbox{\scriptsize B}}$

GY/R GY GY/R GY

9

GΥ

REAR SPEAKER RH

(M302)

GI

EL-AUDIO-02

REAR SPEAKER AMPLIFIER (M179)

MA

EC

鼆

CL

MT

TF

AT

[9[0]

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

BT

MA

EL

1DX


AEL293A-B


EL-105

1171

Wiring Diagram -AUDIO- (Cont'd)

BASE AUDIO SYSTEM





AUDIO

Trouble Diagnoses

Symptom	Possible causes	Repair order				
Radio inoperative (no digital display and no sound from speakers).	1. 10A fuse 2. Poor radio case ground 3. Radio	Check 10A fuse (No. 6 , located in fuse block). Turn ignition switch ON and verify battery positive voltage is present at terminal 10 of radio. Check radio case ground. Remove radio for repair.				
Radio controls are operational, but no sound is heard from any speaker.	Radio output Radio	Check radio output voltages. Remove radio for repair.				
Radio presets are lost when ignition switch is turned OFF.	1. 10A fuse 2. Radio	Check 10A fuse (No. 20 , located in fuse block) and verify battery positive voltage is present at terminal 6 of radio. Remove radio for repair.				
Rear speakers are inoperative.	WITH REAR SPEAKER AMPLIFIER 1. Rear speaker amplifier 15A fuse 2. Poor rear amplifier ground 3. Rear speaker amplifier 4. Rear speaker amplifier circuit 5. Radio WITHOUT REAR SPEAKER AMPLIFIER 1. Radio output 2. Radio	WITH REAR SPEAKER AMPLIFIER 1. Check 15A fuse (No. 1 , located in the fuse block) and verify battery positive voltage is present at terminal 2 of rear speaker amplifier. 2. Check rear amplifier ground (177). 3. Check rear speaker amplifier voltages. 4. Check wires for open or short between radio, rear speaker amplifier and rear speakers. 5. Remove radio for repair. WITHOUT REAR SPEAKER AMPLIFIER 1. Check radio output voltages. 2. Remove radio for repair.				
Front speakers are inoperative.	Radio output Radio	Check radio ouput voltages. Remove radio for repair.				
Individual speaker is noisy or inoperative.	Speaker Radio/amplifier output Speaker circuit	Check speaker. Check radio/amplifier output voltages. Check wires for open or short between radio/amplifier and speaker. Remove radio for repair.				
AM stations are weak or noisy (FM stations OK).	Antenna Poor radio ground Radio	Check antenna. Check radio ground. Remove radio for repair.				
FM stations are weak or noisy (AM stations OK).	Window antenna Radio	Check window antenna. Remove radio for repair.				
Radio generates noise in AM and FM modes with engine running.	Poor radio ground Loose or missing ground bonding straps Ignition condenser Generator Ignition coil or secondary wiring Radio	Check radio ground. Check ground bonding straps. Replace ignition condenser. Check generator. Check ignition coil and secondary wiring. Remove radio for repair.				
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	Poor radio ground Antenna Accessory ground Faulty accessory	Check radio ground. Check antenna. Check accessory ground. Replace accessory.				

HA

IDX

EL-107 1173



MA

EC

FE

CL

MT

AT

Ţ[F

PD

FA

RA

3R

\$T

RS

BT

AUDIO

Trouble Diagnoses (Cont'd)

SPEAKER INSPECTION

- Disconnect speaker harness connector.
- 2. Measure the resistance between speaker terminals (1) and (2).
- The resistance should be 2-4 Ω
- 3. Using jumper wires, momentarily connect a 9V battery between speaker terminals ① and ②.
- A momentary hum or pop should be heard

ANTENNA INSPECTION

Using a jumper wire, clip an auxiliary ground between antenna and body.

- If reception improves, check antenna ground (at body surface)
- If reception does not improve, check main feeder cable for short circuit or open circuit.

RADIO AND AMPLIFIER INSPECTION

All voltage inspections are made with:

- Ignition switch ON or ACC
- Radio ON
- Radio and amplifier connected (If either is removed for inspection, supply a ground to the case using a jumper wire.)

RADIO VOLTAGES


Voltage (V) Terminal Base Audio Premium Audio System System 1 5 - 7.5 2.5 - 6.5 2 5 - 7.5 2.5 - 6.5 3 5 - 7.5 2.5 - 6.5 4 5 - 7.5 2.5 - 6.5 5 10.8 - 15.6 6 10.8 - 15.6 7 8 9 10 10.8 - 15.6 10.8 - 15.6 11 0 12 10.8 - 15.6 13 5 - 7.5 2.5 - 6.5 5 - 7.5 14 2.5 - 6.5 15 5 - 7.5 2.5 - 6.5 16 5 - 7.5 2.5 - 6.5

AMPLIFIER VOLTAGES

Terminal	Voltage (V)
1	10.8 - 15.6
2	10.8 - 15.6
3	4.5 - 8.5
4	2.5 - 6.5
5	2.5 - 6.5
6	_
7	0
8	4.5 - 8.5
9	4.5 - 8.5
10	4.5 - 8.5
11	2.5 - 6.5
12	2.5 - 6.5

Œ[**Location of Antenna** MA Fender antenna replacement Removal Window antenna 1. Remove one screw securing (if equipped) fender antenna assembly. 2. Disconnect fender antenna cable connector. 3. Remove the fender antenna assembly. LC Fender antenna EC FE GL MT AT TF Fender antenna PD Window antenna (if equipped) FA $\mathbb{R}\mathbb{A}$ BR ST RS Window antenna ∠Fender antenna cable connector BT cable connector (if equipped) HA


AEL378A




Window Antenna Repair

ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to each side of antenna terminal.



2. If an element is broken, no continuity will exist.



To locate a burned out point, move probe along filament. Tester needle swings abruptly at the burned point.

ANTENNA

Window Antenna Repair (Cont'd) **ELEMENT REPAIR**

G

Repair equipment

- Conductive silver composition (Dupont No. 4817 or equivalent)
 - Ruler 30 cm (11.8 in) long
- 3. Drawing pen
- 4. Heat gun
- 5. Alcohol
- Cloth 6.




LC

EC

MA





Repairing procedure

Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.

FE

Apply a small amount of conductive silver composition to tip of drawing pen.

Shake silver composition container before use.

Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of

MIT

CĹ

After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

Do not touch repaired area while test is being conducted.



AT

PD

FA

RA BR


ST


RS

BT

MA


 $\mathbb{D}X$







Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.


Wiring Diagram -MIRROR-





Wiring Diagram -MIRROR- (Cont'd)





EL

RS


BT

HA

G

IDX

Component Parts and Harness Connector Location ASCD main switch ASCD steering switch Indicator lamp ASCD actuator ASCD brake switch Stop lamp switch ASCD clutch switch



System Description	GI
Refer to Owner's Manual for ASCD operating instructions. When the ignition switch is in the ON or START position, power is supplied: • through 10A fuse (No. 11), located in the fuse block) • to ASCD brake switch terminal ② (A/T models)	MA
 to ASCD main switch terminal (a) (AT models) to ASCD main switch terminal (b) and to ASCD hold relay terminal (c) (M/T models) or to ASCD hold relay terminal (d) (A/T models). 	ZM
With brake pedal released, power remains supplied: through ASCD brake switch terminal ① (A/T models) and to ASCD hold relay terminal ⑥ (A/T models).	LG
When ASCD main switch is in the ON position, power is supplied: from terminal ② of the ASCD main switch to ASCD control unit terminal ④ and	EC
 from terminal ① of the ASCD main switch to ASCD hold relay terminal ② (M/T models) or to ASCD hold relay terminal ① (A/T models). 	
Ground is supplied: to ASCD hold relay terminal ① (M/T models) or to ASCD hold relay terminal ② (A/T models)	GL
 through body grounds (M49), (M105) and (M160). With power and ground supplied, the ASCD hold relay is activated, and power is supplied: from terminal (3) of the ASCD hold relay (M/T models) or 	MT
 from terminal ⑤ of the ASCD hold relay (A/T models) to ASCD main switch terminal ②, to ASCD control unit terminal ④ and 	AT
 to ASCD clutch switch terminal ① (M/T models) or from terminal ⑦ of the ASCD hold relay (A/T models) to inhibitor relay terminal ③ (A/T models). 	TF
 When the ASCD main switch is released to the N (neutral) position, power remains supplied: to ASCD hold relay terminal ② (M/T models) or to ASCD hold relay terminal ① (A/T models) 	PD
 from ASCD main switch terminal ①. Ground is supplied: to ASCD control unit terminal ③ 	FA
• through body grounds (M49), (M105) and (M160).	RA
Inputs At this point, the system is ready to activate or deactivate, based on inputs from the following: speedometer in the combination meter	BR
 stop lamp switch ASCD steering switch 	
 inhibitor relay (A/T models) ASCD clutch switch (M/T models) and ASCD brake switch. 	ST
A vehicle speed input is supplied: ◆ to ASCD control unit terminal ⑦	R\$
 from terminal ⑦ of the combination meter. Power is supplied at all times: to stop lamp switch terminal ① 	87
 through 10A fuse (No. 19 , located in the fuse block). When the brake pedal is depressed, power is supplied: from terminal ② of the stop lamp switch 	HA
• to ASCD control unit terminal ①. Power is supplied at all times:	EL
 through 10A fuse (No. 17), located in the fuse block) to horn relay terminal (2) 	
 through terminal ① of the horn relay to ASCD steering switch terminal ②. 	IDX

System Description (Cont'd)

When the SET/COAST button is depressed, power is supplied:

- from terminal 22 of the ASCD steering switch
- to ASCD control unit terminal (2).

When the RESUME/ACCEL button is depressed, power is supplied:

- from terminal ② of the ASCD steering switch
- to ASCD control unit terminal (1).

When the CANCEL button is depressed, power is supplied:

• to ASCD control unit terminals (1) and (2).

When the system is activated, power is supplied:

to ASCD control unit terminal (5).

Power is interrupted when:

- the shift lever is placed in P or N (A/T models)
- the clutch pedal is depressed (M/T models) or
- the brake pedal is depressed.

Outputs

The ASCD pump controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD pump consists of a vacuum motor, an air valve, and a release valve. Power is supplied:

- from terminal (8) of the ASCD control unit
- to ASCD pump terminal (2).

Ground is supplied to the vacuum motor:

- from terminal (9) of the ASCD control unit
- to ASCD pump terminal (3).

Ground is supplied to the air valve:

- from terminal (10) of the ASCD control unit
- to ASCD pump terminal ①.

Ground is supplied to the release valve:

- from terminal (4) of the ASCD control unit
- to ASCD pump terminal (4).

When the system is activated, power is supplied:

- from terminal (3) of the ASCD control unit
- to combination meter terminal (12).

Ground is supplied:

- to combination meter terminal 42
- through body grounds (M49), (M105) and (M160).


With power and ground supplied, the CRUISE indicator illuminates.

When vehicle speed is approximately 8 km/h (5 MPH) below set speed on A/T models, ground is supplied:

- to terminal 2 of the solenoid valve unit
- from ASCD control unit terminal (12).


When this occurs, the overdrive is canceled.

When vehicle speed reaches approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.





AEL885A

Wiring Diagram -ASCD-



Wiring Diagram -ASCD- (Cont'd)







EL

Tel


HA

Wiring Diagram -ASCD- (Cont'd)







Wiring Diagram -ASCD- (Cont'd)




AEL291A-D

Wiring Diagram -ASCD- (Cont'd)







Trouble Diagnoses FAIL-SAFE SYSTEM

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.

MA

G[

ĒM

LC

EC

Malfunction detection conditions

Detection conditions	ASCD operation during malfunction detection	[3[
 ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck. Vacuum motor ground circuit or power circuit is open or shorted. Air valve ground circuit or power circuit is open or shorted. Release valve ground circuit or power circuit is open or shorted. 	ASCD is deactivated. Vehicle speed memory is canceled.	C
 Vehicle speed sensor is faulty. ASCD control unit internal circuit is malfunctioning. 		ĪΜ
● ASCD brake switch or stop lamp switch is faulty.	 ASCD is deactivated. Vehicle speed memory is not canceled. 	Æ

TF

(PD)

FA

 $\mathbb{R}\mathbb{A}$

BR

ST


RS

BT

HA

 $\mathbb{D}\mathbb{X}$

Trouble Diagnoses (Cont'd) Fail-safe system check



Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	-				Diagnostic	procedure	;			
REFERENCE PAGE	EL-124	EL-126	EL-126	EL-127	EL-128	EL-129	EL-130	EL-131	EL-132	_
SYMPTOM	Fail-safe system check	DIAGNOSTIC PROCEDURE 1 (POWER SUPPLY AND GROUND CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK)	DIAGNOSTIC PROCEDURE 3 (ASCD HOLD RELAY CHECK)	DIAGNOSTIC PROCEDURE 4 (ASCD CLUTCH AND BRAKE SWITCH CHECK)	DIAGNOSTIC PROCEDURE 5 (ASCD STEERING SWITCH CHECK)	DIAGNOSTIC PROCEDURE 6 (VEHICLE SPEED SENSOR CHECK)	DIAGNOSTIC PROCEDURE 7 (ASCD PUMP CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 8 (ASCD ACTUATOR/PUMP CHECK)	
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)		x	х	Х		Х	Х			
ASCD cannot be set. ("CRUISE" indicator lamp blinks. *1)	х				x	x	×	×		
Vehicle speed does not decrease after SET/COAST switch has been pressed.						X	_		×	- ^ - [
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed. *2						x			×	
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.						x			×	L
System is not released after CAN- CEL switch (steering) has been pressed.						х			x	[
Large difference between set speed and actual vehicle speed.									X	- (
Deceleration is greatest immediately after ASCD has been set.									х	• [

^{*1:} It indicates that system is in fail-safe.


HA


PT


G[

(DX

^{*2:} If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to OFF vehicle speed will not return to the set speed since the memory is canceled.









EL-127 1193

IDX




Stop lamp switch is OK.





EL-129 1195

IDX



Trouble Diagnoses (Cont'd)
DIAGNOSTIC PROCEDURE 6
(VEHICLE SPEED SENSOR CHECK)





EL-131 1197

AT

TF

PD

FA


RA


ST


RS

BT

IDX







Trouble Diagnoses (Cont'd) DIAGNOSTIC PROCEDURE 8 (ASCD ACTUATOR/PUMP CHECK)

Α

CHECK VACUUM HOSE.

Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.

Loĸ

OK

age,

NG

NG

NG

CHECK ASCD WIRE.

Check wire for improper installation, rust formation or breaks.

Repair or replace wire. Refer to "ASCD WIRE ADJUSTMENT", (EL-133).

Replace ASCD actuator.

Repair or replace hose.

В

CHECK ASCD ACTUATOR.

- Disconnect vacuum hose from ASCD actuator.
- Apply -40 kPa (-0.400 bar, -0.41 kg/cm², -5.8 psi) vacuum to ASCD actuator with hand vacuum pump.

ASCD wire should move to pull throttle drum.

Wait 10 seconds and check for decrease in vacuum pressure.

Vacuum pressure decrease: Less than 2.7 kPa (0.0270 bar, 0.028 kg/cm², 0.39 psi)

OK

CHECK ASCD PUMP.


- Disconnect vacuum hose from ASCD pump and ASCD pump connector.
- 2. If necessary remove ASCD pump.
- 3. Connect vacuum gauge to ASCD pump.
- Apply 12V direct current to ASCD pump and check operation.

	12V direct current sup- ply terminals		Operation	
	\oplus	⊖	•	
Air valve		1	Close	
Release valve	2	4	Close	
Vacuum motor		3	Operate	

A vacuum pressure of at least -35 kPa (-0.350 bar, -0.36 kg/cm², -5.1 psi) should be generated.

↓OK INSPECTION END Replace ASCD pump.

Trouble Diagnoses (Cont'd) ASCD WIRE ADJUSTMENT



CAUTION:

Be careful not to twist ASCD wire when removing it.

Do not overly tighten ASCD wire during adjustment.

Confirm that accelerator wire is properly adjusted.

 For accelerator cable adjustment, refer to FE section ("Adjusting Accelerator Wire", "ACCELERATOR CONTROL SYSTEM").

Adjust the ASCD wire as follows:

- 1. Loosen lock nut and tighten adjusting nut until portion A of upper throttle lever comes into contact with lower throttle lever.
- 2. From that position turn back adjusting nut 0.5 to 1 turn, and secure lock nut.

(This prevents a delay in the operation of the ASCD.)

- For ASCD brake switch adjustment, refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").
- For ASCD clutch switch, refer to CL section ("Adjusting Clutch Pedal," "INSPECTION AND ADJUSTMENT").

EL

BT

MA

GII

MA

国M.

ILC

EC

Æ

CL.

MT

AT

777

PD)

凮

RA


BR


]DX


EL-133 1199

ASCD main switch connector N2 OISCONNECT ASCD Main switch connector N2 ASCD Main switch connector N2 ASCD Main switch connector N2 ASCD Main switch connector N2 ASCD Main switch connector N2 ASCD Main switch connector N2 ASCD Main switch connector N2 ASCD Main switch connector N2

ASCD steering switch connector (Z100) DISCONNECT | 23|22|21







Trouble Diagnoses (Cont'd) ELECTRICAL COMPONENTS INSPECTION

ASCD main switch

Check continuity between terminals by pushing switch to each position.

Switch position		Terminals				
- Switch position	6	1	2	3	4	5
ON	0_	0	O(ÐO		
N				3 0	IL	L.
					\bigcirc	<u> </u>
OFF						

ASCD steering switch

Check continuity between terminals by pushing each button.

Button	Terminal		
Bullon	21	22	23
SET/COAST	0		
RESUME/ACCEL	0		
CANCEL	0	→ ○	
CANOLL	0		-0

ASCD brake switch and stop lamp switch

	Continuity		
Condition	ASCD brake switch	Stop lamp switch	
When brake pedal is depressed	No	Yes	
When brake pedal is released	Yes	No	

Check each switch after adjusting brake pedal — refer to BR section ("Adjustment", "BRAKE PEDAL AND BRACKET").


ASCD clutch switch (For M/T models)


Condition	Continuity
When clutch pedal is depressed	No
When clutch pedal is released	Yes

Check switch after adjusting clutch pedal — refer to CL section ("Adjusting Clutch Pedal", "INSPECTION AND ADJUST-MENT").

Inhibitor switch (For A/T models)

Condition	Continuity
When shift lever position is "N" or "P"	Yes
When shift lever position is not "N" or "P"	No





EL

(DX

R\$

BT

HA

AEL377A

EL-135

System Description

Power is supplied at all times:

- from brown fusible link (located under relay box)
- to circuit breaker terminal (1)
- through circuit breaker terminal ②
- to ignition-2 and power window relay terminal 3.

With the ignition switch in the ON or START position, power is supplied:

• to ignition-2 and power window relay terminal (2).

Ground is supplied to ignition-2 and power window relay terminal 1 through body grounds (M49), (M105) and (M100).

The ignition-2 and power window relay is energized and power is supplied:

- through ignition-2 and power window relay terminal (5)
- to main power window and door lock/unlock switch terminal (5),
- to power window switch RH terminal (5), and
- to power window amplifier terminals (2) and (6).

Ground is supplied:

- to main power window and door lock/unlock switch terminal (4), and
- to power window amplifier terminal (1)
- through body grounds (M49), (M105) and (M160).

MANUAL OPERATION

Door LH

WINDOW UP

When the main power window and door lock/unlock switch is pressed in the UP position, ground signal is supplied:

- to power window amplifier terminal 3
- through main power window and door lock/unlock switch terminal 3.

Then power is supplied:

- through power window amplifier terminal 4
- to power window motor LH terminal (2).

Ground is supplied:

- to power window motor LH terminal (1)
- from power window amplifier terminal (8).

With power and ground supplied, the motor raises the window until the switch is released.

WINDOW DOWN

When the main power window and door lock/unlock switch is pressed in the DOWN position, ground signal is supplied:

- to power window amplifier terminal ?
- through main power window and door lock/unlock switch terminal ②.

Then power is supplied:

- through power window amplifier terminal ®
- to power window motor LH terminal 1.

Ground is supplied:

- to power window motor LH terminal ②
- from power window amplifier terminal 4.

With power and ground supplied, the motor lowers the window until the switch is released.


System Description (Cont'd)	
Door RH	G[
NOTE: Figures in parentheses () refer to terminal Nos. arranged in order when the DOWN or UP section of power window switch RH is pressed.	IM/
Operation by main switch Power is supplied: through main power window and door lock/unlock switch terminal (7, 6)	EW
• to power window switch RH terminal (⑥, ①). The subsequent operations are the same as those outlined under "Operation by sub-switches". Operation by sub-switches Power is supplied:	. LG
 through power window switch RH terminal (③, ④) to power window motor RH terminal (①, ②). When the power window switch RH is pressed in the DOWN or UP position, ground is supplied: 	E¢
 to power window motor RH terminal (②, ①) through power window switch RH terminal (④, ③) to power window switch RH terminal (①, ⑥) 	FE
 through main power window and door lock/unlock switch terminal (6), (7) to main power window and door lock/unlock switch terminal (4) through body grounds (M49), (M105), and (M160). 	CL
Then, the motor raises or lowers the window until the switch is released. AUTO FEATURE	MT
The power window AUTO feature enables the driver to lower the driver's window without holding the window switch in the down position. The AUTO feature only operates on the driver's window downward movement.	AT
When the main power window and door lock/unlock switch is pressed and released in the AUTO position, ground signal is supplied: • to power window amplifier terminal (5)	ŢF
 through main power window and door lock/unlock switch terminal ①. Power is supplied: to power window motor LH terminal ① 	PD
 through power window amplifier terminal (8) Ground is supplied: to power window motor LH terminal (2) 	FA
 through power window amplifier terminal 4 Then, the door LH window will travel to the fully open position. 	RA
LOCK FEATURE The power window lock is designed to lock-out passenger window operation. When the lock switch is pressed to the LOCK position, ground of the main power window and door lock/unlock	BR
switch is disconnected. This prevents the passenger power window motor from operating.	ST
	RS
	BT


EL

FIA


IDX


Wiring Diagram -WINDOW-





Wiring Diagram -WINDOW- (Cont'd)





EL

BT

HA

IDX

Trouble Diagnoses

Symptom	Possible causes	Repair order
None of the power windows can be operated from any switch.	Brown fusible link and circuit breaker.	Check brown fusible link (located under the relay box) and the circuit breaker. Turn ignition switch ON and verify battery positive voltage is present at terminal of both power window switches.
	Grounds to ignition-2 and power window relay.	2. Check grounds (M49), (M105) and (M160).
	3. Ignition-2 and power window relay	3. Check ignition-2 and power window relay.
	Grounds to main power window and door lock/unlock switch.	4. Check grounds (M49), (M105), and (M160).
Driver side power window cannot be operated but passenger window can be operated.	Driver side power window motor LH circuit.	Check driver side power window motor LH circuit.
	2. Driver side power window motor LH.	Check driver side power window motor LH.
	3. Power to power window amplifier.	3. Turn ignition switch ON and verify battery positive voltage is present at terminals (2) and (6) of power window amplifier.
	4. Ground to power window amplifier.	4. Check grounds (M49), (M105), and (M160).
	5. Dríver side power window switch.	Check main power window and door lock/unlock switch.
	6. Power window switch circuit.	Check wires between main power window and door lock/unlock switch and power window amplifier for open/short circuits.
	7. Power window amplifier.	7. Replace power window amplifier.
Passenger power window cannot be operated.	Power window switch RH.	Check power window switch RH.
	2. Power window motor RH.	2. Check power window motor RH.
	Main power window and door lock/ unlock switch.	Check main power window and door lock/unlock switch.
	4. Power window circuit.	Check wires between main power window and door lock/unlock switch and passenger power window switch and motor for open/short circuits.
Passenger power window cannot be oper- ated by main switch but can be operated by passenger's switch.	Main power window and door lock/ unlock switch.	Check main power window and door lock/unlock switch (lock must be in unlock position).
	Power to main power window and door lock/unlock switch.	Turn ignition switch ON and verify battery positive voltage is present at terminal (5) of main power window and door lock/unlock switch.
Passenger power window cannot be oper- ated by passenger switch but can be oper- ated by main switch.	Power window switch RH.	Check power window switch RH.
	2. Power to power window switch RH.	Turn ignition switch ON and verify battery positive voltage is present at terminal (5) of power window switch RH.

1206 EL-140


POWER DOOR LOCK

System Description	Gi
Power is supplied at all times: through brown fusible link (located under the relay box) to circuit breaker terminal 1 through circuit breaker terminal 2	MA
 to door lock control unit terminal ②. Ground is supplied: to door lock control unit terminal ⑥ 	ĒM
 through body ground (M177). INPUT 	LG
When the lock/unlock knob switch is moved to the UNLOCK or LOCK position, ground is supplied: to door lock control unit terminal ① or ⑤ from lock/unlock knob switch terminal ③ or ①	EC
 through lock/unlock knob switch terminal ② through body grounds (M49), (M105) and (M100). When the main power window and door lock/unlock switch is moved to the UNLOCK or LOCK position, ground 	FE
 is supplied: to door lock control unit terminal ① or ⑤ from main power window and door lock/unlock switch terminal ② or ② through main power window and door lock/unlock switch terminal ② or ④ 	CL
• through body grounds (M49), (M105) and (M160).	MT
OUTPUT Unlock	AT
Power is supplied:	
 from door lock control unit terminal 4 to door lock actuator LH terminal 3, and 	TF
• to door lock actuator RH terminal ①. Ground is supplied:	PD
 from door lock control unit terminal ③ to door lock actuator LH terminal ①, and 	
 to door lock actuator RH terminal ③. With power and ground supplied, the door actuators move to the unlocked position. 	FA
Lock	RA
Power is supplied: • from door lock control unit terminal ③	
 to door lock actuator LH terminal ①, and to door lock actuator RH terminal ③. 	BR
Ground is supplied: • from door lock control unit terminal 4	\$T
 to door lock actuator LH terminal ③, and to door lock actuator RH terminal ①. 	ଥା ।
With power and ground supplied, the door actuators move to the locked position.	RS
	BT
	000
	HA

EL

1DX

Schematic



EL-142

POWER DOOR LOCK

NOTES

GI

MA

EM

LC

EC

76

©L

MT

AT

TF

PD

FA

RA

BR

ST

RS

BT


HA


EL

IDX


Wiring Diagram -D/LOCK-


EL-D/LOCK-01





Wiring Diagram -D/LOCK- (Cont'd)






EL


BT

HA



Trouble Diagnoses MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK Main power supply for door lock control unit


Terminals	Battery voltage existence
2 - Ground (GND)	Yes




Ground circuit for door lock control unit

Terminals	Continuity
6 - Ground	Yes

POWER DOOR LOCK



POWER DOOR LOCK



POWER DOOR LOCK G[**NOTES** MA EM LC EC FE ŒL. MT AT TF PD RA BR ST


HA

RS

BT

EL

Passenger Compartment




LOCATION OF ELECTRICAL UNITS

Gľ **Engine Compartment** MA Daytime light control unit -LC (For Canada) EC FE CL MT AT TE PD Fuel pump relay-Bulb check relay ECCS relay-ASCD hold relay FA Air conditioner relay- $\mathbb{R}\mathbb{A}$ BR ST RS BT Inhibitor relay (without ASCD) Inhibitor relay (with ASCD) HA Clutch interlock relay (with M/T) Hom relay EL Park and neutral position relay (with A/T)

AEL314A

How To Read Harness Layout

Example:



Grid reference

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

Main Harness and Air Bag Harness

To use the grid reference


- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connectors (In Harness Layout) are indicated below.

Connector type	Waterproof type		Standard type	
Connector type	Male	Female	Male	Female
Cavity: Less than 4Relay connector	O	Ø		
Cavity: From 5 to 8			*	
Cavity: More than 9		\Diamond	\rightarrow	\Diamond
Ground: terminal etc.	_		C	g

Outline



G

 $\mathbb{M}\mathbb{A}$

LC

EC

FE

CL

MT

TF

PD

FA

RA

BR


ST

RS


BT

ЖA

1DX




														Ma	in	Н	ar	ne	ess	a	nc	P	۱ir	В	a	g Harnes	(Con	t'd)	G1
							anada)																			el drive)			MA
			¥				th (for C		<u></u>		insor		Ę	Ę		5		Į			Ve Ve			(IVe)	h 4-whe			
tmp RH		switch	al lamp F	mp LH			el switc	switch	ith ASCI		cygen se	≥	y (with N	y (with /		with DT		allamp l			noid val			4	MILEGIC	isor (wit			EM
arking la	mp RH	essure s	urn signa	arking la	<u> </u>	r motor	r fluid lev	luid leve	m) dunc		eated ox	eck rela	nold rela	nold rela	m H	mp LH (urn signa	_		ICD sole			Asimply A	- (WICH 4-	zone ser			LC
: Front p	: Headlamp RH	: Dual-pr	: Front t	: Front p	: Resisto	: Washer motor	: Washer fluid level switch (for Canada)	: Brake f	: ASCD	. To	GY/3: Front heated oxygen sensor	: Bulb check relay	: ASCD hold relay (with M/T)	BR/6: ASCD hold relay (with A/T)	: Headlamp LH	: Headlamp LH (with DTRL)	: Horn	: Front turn signal lamp LH	. To (Mei	(ક્રું ક્રુ	: IACV-F		larness	(E)	2 2	: Crash :			EC
(M50) GY/2: Front parking lamp RH	MSI) B/3	(NSZ) GY/2: Dual-pressure switch	ക്ര GY/2 : Front turn signal lamp RH	(Mes) GY/2: Front parking lamp LH	*(MS) GY/2: Resistor	(M57) W/2	M58) B/2	MS GY/2: Brake fluid level switch	(we) GY/4 : ASCD pump (with ASCD)	*(ME) GY/4 : To (Ma)	*(MEZ) GY/3	(MEG) L/4		Mes BR/6	(Mec) B/3	(MG7) B/3	Meg B/1	GY/2	*(Mo) GY/4 : To (Me)	*(M80) GY/4: To (M7)	*(www.) PU/2: IACV-FICD solenoid valve)	Air Baq Harness	(1) (2) (2) (3) (4) (4) (4) (4) (4) (4) (4) (4) (4) (4	1 1 1 1	(2) GY/2 : Crash zone sensor (with 4-wheel drive)			FE
B2	B3	B3 (8)	B3 ⊗	S	E3 *€	F3	£ ⊗	7. S	. E	E2 *	₹ •	F3 ©	-	₽ §	2 S	છ	. S	2 2	E3 .▼.	E2 *	, × 20	,	•	5		2			GL.
							Dolon how	relay DUX					: Swirl control valve control vacuum check switch F4																MT
								_		E	_		cuum ct	ih DTRL	th DTRL	æ													AT
			drive)					: Inhibitor relay (without ASCD)	(CDS)	: Clutch interlock relay (with M/T)			ontrol va	GY/6: Daytime light control unit (with DTRL)	(Mar) GY/8: Daytime light control unit (with DTRL)	: Park and neutral position relay													775
g	ve unit	년 -	4-wheel		alay		er relay	y (witho	y (with A	ock relay			valve co	t control	t control	utral pos							_						
oitor swit	noid val	oitor swii	z) (with	: Relay box	: Fuel pump relay	: ECCS relay	: Air conditioner relay	itor rela	: Inhibitor relay (with ASCD)	ch interf	relay	ble link	l control	ime ligh	ime ligh	and ne	(F) (F	(R)	(8)	: Fusible link	: Fusible link	: Body ground)					(PD)
(M28) GY/8: Inhibitor switch	(MZ) GY/3 : Solenoid valve unit	*(ws) GY/2: Inhibitor switch	(M2) GY/4: To (Z1) (with 4-wheel drive)	- : Rela					/6: Inhit	: Clut	(Mor) GY/3: Horn relay	MS BR/2: Fusible link		/6 : Day	/8 : Day		* (M2) GY/8: TO (E4)	. 한 편	71 : To 🔞	: To (E2)								vork. rt up	FA
M® GY	(MZZ) GY	*(M28) GY	® Gγ	(M30)	M31 L/4	* (M32) L/4	MCB L/4	Mag L4	MRS GY/6:	M36 L/4	Mg Gγ	® BH	*(M39) B/2	MAG GY	Md Gγ	* (MAZ) L/4	· (MR) GY	* (M44) B/8	M46 GY/1	M46 B/2	* (M47) B/2	(M48) W/	* (M49))				r repair v m to ligh .)	RA
D2	22	5	ប	ច	A 2	A 2	A3	A3	A3	A3	A3	5	ភ	<u>8</u>	B 5	ຽ	ខ	20	ខ	ឌ	184	84	8					rely afteric syste Section	BR
valve										J.							d valve											*: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC Section.)	ST
GY/6 : EVAP canister purge volume control valve					GY/4: IACV-AAC solenoid valve and to (450)					(M2) GY/6 : Distributor (camshaft position sensor)						sensor	: EVAP canister purge control solenoid valve		<u> </u>				valve			:		connecte n-board ion. (Ref	RS
volume					valve an	nsor	ø			ft positic	coil)					: Engine coolant temperature sensor	control	L	(kg) GY/2 : Intake air temperature sensor	itch	Sor	ensor	: MAP/BARO switch solenoid valve					ock the ose the or	BT
er purge		fier	4	က	olenoid	GY/2 : EGR temperature sensor	: EGRC-solenoid valve	8	_	camshaf	: Distributor (ignition coil)	ssor	ng.	рц	smitter	ant temp	er purge	BR/4: Mass air flow sensor	mperatu	(MZ) GY/3: Throttle position switch	(wz) BR/3 : Throttle position sensor	(M24) GY/3: Absolute pressure sensor	switch s					ct and k nay cau en circu	
P canist	: Wiper motor	: Wiper amplifier	: Injector No. 4	: Injector No. 3	/-AACs	temper	C-solen	: Injector No. 2	: Injector No. 1	ributor (ributor (i	: A/C compressor	: Engine ground	: Engine ground	: Thermal transmitter	ine cook	P canist	s air flo	ke air te	ottle pos	ottle pos	olute pre	YBARO					o conne o do so r as an op	HA
/6 : EVA					/4:IAC	/2 : EGF				/6 : Dist	/2 : Dist	71 : A/C	- : Eng	- : Eng		/2 : Eng		/4 : Mas	/2 : Inta	/3 : Thr	//3: Thr	/3 : Abs						Se sure trailure to	EL
, Œ GΥ	9/M (M3)	(MA) W/8	*(M5) B/2	* (M6) B/2	, (M7) GY	, (M8) GΥ	* (MB) B/2	* Mile B/2	* (MT) B/2	[⋆] (Mt2) GY	* (MT3) GY/2	(MI4) GY/1	 SES	 } 	M17 B/1	* (M18) GY/2	* (M19) G/2	Mag BR	[€] (MZ) Gγ	* (<u>M</u> 2) GY	* (MZB) BR	* (MZK) GY	* (MZS) B/2					** **	IDX
*	5	Ш	Z	*	т Ш	E2	F2 *	±	£2	* E	* ⊞	8	٠ 23	* 23	ឌ	π	* 23	20	, 20	, D	2	<u>"</u>	<u>υ</u>					AEL912A	




EL-156

Main Harness and Air Bag Harness (Cont'd)



AEL914A

Instrument Harness



Be sure to connect and lock the connectors securely after repair work.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

* (N5) B/12 : Combination meter


(NB) W/8 : Combination meter * (NT) W/12: Combination meter

N3 W/10: Door mirror switch

N2) W/6 : ASCD main switch

(SMJ) SMJ : To (MS)

* (N4) B/10 : Combination meter



EL-159

AEL321A

Chassis and Tail Harness

(®) GV/3: EVAP control system pressure sensor Chassis Harness '(অ) GY/6 : Fuel tank gauge unit (ಡ) GY/4 : ABS actuator ര GY/2 : Rear sensor (C) W/14: To (MI®) (CZ) W/10: To (MIS) <u></u> ଞ ์ ঠ ଞ 8 ঠ පි ප F (B) GY/2 : License lamp LH (Without step bumper) (B) GY/2 : License lamp LH (With step bumper) 2 T) W/6 : Rear combination lamp LH 4 E.

AEL322A

*(3) B/2 : EVAP canister vent control valve * (cr) G/2 : Vacuum cut valve bypass valve

*: Be sure to connect and lock the connectors securely after repair work. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

1

9

(Without step bumper)

T) GY/2 : License lamp RH (With step bumper)


Tail Harness

π் दिҮ /8: To @


Ta) W/6 : Rear combination lamp RH

Door harness LH

Front Door Harness



Door harness RH



EL-161

GI.

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

RA

BR

ST

RS


BT

HA

EL


IDX


Room Lamp Harness



EL-162

SUPER MULTIPLE JUNCTION (SMJ)





INSTALLATION


To install SMJ, tighten bolts until orange "fulltight" mark appears and then retighten to specified torque as required.


∰: 3 - 5 N·m


(0.3 - 0.5 kg-m, 26 - 43 in-lb) CAUTION:

Do not overtighten bolt, otherwise, it may be damaged.


Terminal Arrangement









Location



Terminal Arrangement




26	25	24	\times	23	22	21	20	19
18	17	16	15	14	13	12	11	10
9	8	7	6	5	4	3	2	1




			<u></u>			Ĺ		
26	25	24	\times	23	22	21	20	19
18	17	16	15	14	13	12	11	10
9	8	7	6	5	4	3	2	1

AEL343A

Fuse Arrangement



AIRBAG DIAGNOSIS SENSOR UNIT




View from harness side

ABS CONTROL UNIT



View from harness side

ECM (ECCS CONTROL MODULE)



View from harness side

SECTION IDX

MA

LC

EC

FE

CL

MT

AT

TF

PD

FA

 $\mathbb{R}\mathbb{A}$

BR

ST

RS

BŢ

HA

IDX

A		ASCD (automatic speed control device)	
		A/T - Wiring diagram	
4.4.0.0.4. NAGodin - di	EC 001	A/T mode switch	
AAC/V - Wiring diagram		A/T removal and installation	
ABS - Wiring diagram		A/T shift lock system	
ABS (anti-lock brake system)		A/T shift lock system - Wiring diagram	
Absolute pressure sensor		A/T trouble diagnoses	
A/C - Wiring diagram		Audio	
A/C air flow		AUDIO - Wiring diagram	
A/C component layout		Audio and A/C control removal and installation	
A/C compressor clutch removal and installatio		See Instrument panel	
A/C compressor mounting		Auto lock free running hub	
A/C compressor precaution		Automatic speed control system - See ASCD	
A/C compressor special service tool		Automatic transmission fluid replacement	
A/C control linkage adjustment (manual A/C)		Automatic transmission number	
A/C control operation (manual A/C)	HA-14	Auxiliary air control (AAC)	
A/C diagnostic work flow (manual A/C)	HA-15	Axle housing (rear)	RA-5
4/C harness layout (manual A/C)	HA-28		
A/C HFC134a (R134a) system identification	HA-3	B	
A/C HFC134a (R134a) system introduction	HA-3	В	
VC HFC134a (R134a) system precaution	HA-4		
VC HFC134a (R134a) system service		Back window	BT-28
procedure	HA-48	BACK/L - Wiring diagram	
A/C HFC134a (R134a) system service tools		Back-up lamp	
A/C HFC134a system service equipment		Back-up lamp switch (M/T)	
precaution	H A- 9	Ball joint front axle	
VC lubricant (R134a)		Battery	
A/C operational check		Baulk ring (M/T)	
A/C performance chart		Blower motor	
VC performance test diagnoses		Blower relay	
A/C relay		Blower resistor	
A/C service data specification		Body alignment	
VC switch		Body mounting	
A/C symptom chart (manual A/C)		Boring/honing cylinder block	
A/C trouble diagnoses (manual A/C)		BPT valve	
Accelerator control system		Brake booster	
Accelerator wire adjustment		Brake control valve (Proportioning valve)	
Air bag		Brake fluid change	
Air bag disposal		Brake fluid level	
Air bag precautions		Brake fluid level and line check	
Air bleeding for brake system		Brake hydraulic line	
Air bleeding (hydraulic clutch)		Brake inspection	
Air cleaner filter replacement		Brake lines and cables inspection	
Air conditioner - wiring diagram		Brake master cylinder	
Air conditioner cut control		Brake pedal	
Air conditioning - See A/C		Bumper, front	
Air control cable adjustment		Bumper, rear	
Air flow meter - See Mass air flow sensor		BYPS/V - Wiring diagram	EC-276
Air mix door control linkage adjustment	HA-43		
Alternator	EL-28		
Angular tightening application	EM-2	С	
Antenna			
Anti-lock brake system - See ABS		Cab body	BT-32
Anti-lock brake system - Wiring diagram		Camshaft inspection	
AP/SEN - Wiring diagram		Camshaft position sensor (CMPS)	
ASCD - Wiring diagram		Canister - See EVAP canister	

IDX-2

1230

CANI/V - Wiring diagram	EC-199	Coupling sleeve (M/T)	. MT-8	GI
Cargo space		Crank angle sensor built into distributor - See		
Center bearing assembly (propeller shaft)	PD-11	Camshaft position sensorE	C-171	
Center bearing disassembly (propeller shaft)		Crankcase ventilation system - See positive		MA
CHARGE - Wiring diagram		crankcase ventilationl	EC-24	
Charging system		Crankshaft	EM-36	EM
Chassis and body maintenance		Crankshaft position sensor (OBD) E	C-166	
CHIME - Wiring diagram		Crankshaft position sensor (OBD) cog chipping E		
Cigarette lighter		Crash zone sensor	_	LC
Circuit breaker		Cruise control - See ASCD E	L-114	150
CKPS - Wiring diagramEC-16	6, EC-262	Cylinder block	EM-32	
Clearance lamp		Cylinder block boring		EC
Clock		Cylinder head		
Closed loop control		Cylinder head bolt tightening		
Closed throttle position switch		, , , , , , , , , , , , , , , , , , , ,		
Clutch cover				
Clutch damper		D	1	
Clutch disc				CL
Clutch fluid level		Data link connector for Consult	EC-53	
Clutch master cylinder		Daytime light system		10.71==
Clutch operating cylinder		Daytime running light - See Daytime light		Mt
Clutch pedal		system	EL-38	
Clutch release bearing		Defroster door control rod adjustmenth		AT
Clutch withdrawal lever		Diagnosis sensor unit		ÆM
CMPS - Wiring diagram		Diagnostic trouble code (DTC) chart E		
Collision diagnosis		Diagnostic trouble code (DTC) for ECCS OBD		TF
Combination lamp, front, removal and		system	FC-2	0.1
installation	BT-6	Differential carrier		
Combination lamp, rear, removal and		assemblyPD-30, PD-52, PD-75, F	PD-96	PD
installation	BT-7	Differential carrier disassemblyPD-36, PD-58, F		
Combination meter		Differential gear oil replacement		
Combination meter (needle type)		Dimensions		FA
Combination meter removal and installation -	22 00	Distributor ignition (DI) system		
See Instrument panel	BT-10	D/LOCK - Wiring diagram		Б.
Combination switch		Dome light - See Interior lamp		RA
Compression pressure		Door, front		
Compressor clutch removal and installation		Door glass		(a)(a)
Compressor mounting		Door lock		BR
Compressor precaution		Door mirror		
Compressor special service tool		Door trim		ST
Connecting rod		Drive belt inspection		91
Connecting rod bearing clearance		Drive pinion diff. inspectionPD-40, PD-62, F		
Connecting rod bushing clearance		Drive pinion heightPD-47, PD-70, F		RS
Console box - See Instrument panel		Drive plate runout E		
CONSULT for ECCS		Drive shaft (front)		
CONSULT general information		DTRL - Wiring diagram		BT
Control lever (M/T)		Dual pressure switch		
Control lever transfer		Duai pressure switchmining	,, , , ,	
Control valve (A/T)		Pre		HA
Converter housing installation		E		
Coolant mixture ratio				egga a
Coolant replacement		ECCS basic inspection E	C-72	EL
Cooling circuit (engine)		ECCS dasic inspection		
Cooling fan		· · · · · · · · · · · · · · · · · · ·		IDX
-		ECCS component parts locationE		
Counter gear transfer		· ·		
Counter gear transfer	₁ ୮ - ઝ	ECCS on board diagnostic system E	_U-34	

IDX-3 1231

ECCS relay	EC-89	Fluids	MA-8
ECCS symptom matrix chart	EC-77	Flywheel (clutch)	CL-13
ECCS system diagram and chart	EC-10	Flywheel runout	EM-39
ECM input/output signal	EC-83	Fork rod (M/T)	MT-10
ECTS - Wiring diagram EC-	113, EC-124	Forward clutch	AT-79
EGR control (EGRC) - BPT valve		F/PUMP - Wiring diagram	EC-309
EGR control (EGRC) - solenoid valve	EC-267	Freeze frame data	EC-36
EGR control valve	EC-182	FRO2 - Wiring diagram	EC-129
EGR temperature sensor	EC-271	FRO2/H - Wiring diagram	EC-135
EGRC1 - Wiring diagram	EC-176	Front axle	
EGRC/V - Wiring diagram	EC-267	Front bumper	BT-6
EGR/TS - Wiring diagram	EC-271	Front combination lamp removal and	
Electrical diagnoses	Gl-18	installation	BT-6
Electrical unit	EL-150	Front disc brake	BR-19
Electrical units location	EL-150	Front door	BT-9
Engine compartment	BT-35	Front drive shaft transfer	TF-9
Engine control module (ECM)	EC-6	Front final drive disassembly (4WD)	PD-18
Engine coolant temperature sensor		Front final drive pre-inspection (4WD)	
(ECTS)EC-	113, EC-124	Front final drive removal and installation (4WI	
Engine oil filter replacement	MA-13	Front heated oxygen sensor (HO2S) heater	
Engine oil precautions		Front oxygen sensor (O2S)	
Engine oil replacement		Front seat	
Engine outer component parts		Front seat belt	R\$-3
Engine removal		Front suspension	
Engine room - See Engine compartment		Front washer	
Engine serial number		Front wiper	
EVAP canister		FUEL - Wiring diagram EC-1	
EVAP canister purge control valve		Fuel cut control (at no load & high engine	,
EVAP canister purge volume control valve		speed)	EC-19
EVAP canister vent control valve		Fuel filter replacement	
EVAP control system pressure sensor		Fuel gauge	
EVAP control system purge flow monitoring		Fuel injection systemEC-1	
diagnosis	EC-288	Fuel injector	
EVAP control system (small leak) diagnosis		Fuel line inspection	
EVAP shut valve		Fuel precautions	
EVAP vapor lines inspection	MA-15	Fuel pressure check	
Evaporative emission (EVAP) system		Fuel pressure regulator	
Exhaust gas recirculation (EGR) valve		Fuel pressure release	
Exhaust system		Fuel pump	
Exhaust system inspection	MA-16	Fuel pump and gauge	
Extension tube diff		Fuel pump relay	
Exterior	BT-17	Fuel system	
Exterior lamp		Fuel tank vacuum relief valve	
•		Fuel temperature sensor	
		Fuse	
F		Fuse block For	
		Fusible link	. •
Fan switch	HA-41	-	,
Fast idle cam (FIC) inspection and adjustmen			
FICD - Wiring diagram		G	
Final drive disassemblyPD-36, PE			
Final drive pre-inspectionPD-36, PE		Garage jack and safety stand	Gl-40
Final drive removal and installation		Gauges	
Finisher, rear panel		Gears (M/T)	
Floor trim		Generator	
Flow charts		Generic scan tool (GST)	

IDX-4

Glass	BT-9	Intake door control linkage adjustment HA-43	3 ⊈l
Governer valve assembly	AT-72	Intake manifoldEM-6	3
Grease	MA-8	InteriorBT-13	3
Ground clearance	GI-38	Interior lamp EL-58	в 🎮
Ground distribution	EL-12	INT/L - Wiring diagramEL-63	
Н		J] EA
]
Harness connector	EL-3	Jacking pointsGI-39	10 9
Harness layout	EL-152	Joint connector (J/C)Foldout page	€
Hazard warning lamp		Journal bearing assembly (propeller shaft) PD-12	2 🔯
Headlamp		Journal bearing disassembly (propeller shaft)PD-11	1
Headlamp aiming control		Jump seatBT-24	
Headlining - See Roof trim	BT-15		
Heated oxygen sensor (HO2S)	. EC-129	V	1
Heated oxygen sensor (HO2S) (front)		K]
Heated oxygen sensor (rear)			' GL
HEATER - Wiring diagram		Knuckle spindleFA-25	5
Heater system - Wiring diagram		·	
Height (Dimensions)		•	n Mî
HFC134a (R134a) system identification		L	
HFC134a (R134a) system introduction			- At
HFC134a (R134a) system precaution		Leaf spring (rear)RA-10	
HFC134a (R134a) system service procedure		Length (Dimensions)GI-38	
HFC134a (R134a) system service tools		License lampEL-50	
HFC134a system service equipment precaution.		Lifting pointsGI-39	
High clutch		Limited slip diff. adjustmentPD-65, PD-88	
H/LAMP - Wiring diagram		Limited slip diff. assemblyPD-43, PD-67, PD-89	
Hood		Limited slip diff. disassemblyPD-42, PD-63, PD-86	
Horn		Limited slip diff. inspectionPD-42, PD-64, PD-87	7
HORN - Wiring diagram		Line pressure test (A/T) AT-27	· 140
How to erase DTC for ECCS OBD system		Liquid gasket applicationEM-2	
Hydraulic lash adjuster inspection		Location of electrical unitsEL-150	`
, yaraana kan aajaata mapaata minin		Lock, doorBT-9	150/4
_		Low and reverse brake AT-83	
		LSV (Load sensing valve)BR-9	
		Lubricant (R134a) A/CHA-50	ارت
IACV-AAC valve inspection	FC-225	Lubricants	
IACV-FICD solenoid valve		Lubrication circuit (engine)LC-4	
IATS - Wiring diagram		Lubrication-locks, hinges and hood latchesMA-22	
Idle air control valve (IACV)		Eublication locks, minges and flood laterios	•
Idle mixture ratio			1 RS
Idle speed		M	
Ignition coil			J
Ignition timing		MAFS - Wiring diagram EC-93	, BT
		Magnet clutch	
Ignition wire inspection			3
IGN/SG - Wiring diagram		MAIN - Wiring diagram EC-89	1 1/2
ILL - Wiring diagram		Main drive gear (M/T)	
Illumination AT 22		Main gear transfer	_
Inhibitor switch AT-23		Mainshaft (M/T)	
INJECT - Wiring diagram		Mainshaft transferTF-9	
Injector		Maintenance	
Injector removal and installation		Maintenance (engine)MA-10	
Instrument panel		Manual lock free running hubFA-17	
Intake air temperature sensor	. EC-107	Manual steering gearST-14	ŀ

IDX-5 1233

Manual transmission number	Gl-37	Parking lamp	EL-50
Manual transmission oil replacement	MA-16	Park/Neutral position switch	
Map lamp	EL-63	PCV filter replacement	MA-15
MAP/BARO switch solenoid valve	EC-237	PCV (positive crankcase ventilation)	
Mass air flow sensor (MAFS)	EC-93	PGC/V - Wiring diagram	
Master cylinder (brake)	BR-13	Pilot bushing replacement	
Master cylinder (clutch)		Pinion bearing preload diff	
Meter		Pinion gear height diff PD-25, PD-47, F	
METER - Wiring diagram	EL-68	Piston assembly	
MIL & Data link connectors circuit	EC-321	Piston pin inspection	
MIL/DL - Wiring diagram	EC-321	Piston ring inspection	EM-34
MIRROR - Wiring diagram		Piston to bore clearance	
Mirror, door		POWER - Wiring diagram	
Mirror, out side		Power door lock	
Misfire		Power door mirror	
Mode door control linkage adjustment		Power steering fluid level	
Model variation		Power steering gear	
Molding - See Exterior		Power steering hydraulic pressure	
M/T overhaul		Power steering oil pressure switch	
M/T removal and installation		Power steering oil pump	
Mud guard - See Exterior		Power steering system bleeding	
Multiport fuel injection (MFI) system		Power supply routing	
Multiport fuel injection precautions		Power transistor	
		Power transistor & ignition coil	
		Power window	
N		Precautions (General)	
<u></u>		PRE/SE - Wiring diagram	
Neutral position switch	FC-232	Pressure plate - See Clutch cover	
Neutral position switch (M/T)		Pressure test (A/T)	
(17.7)		Propeller shaft	
		Propeller shaft inspection	
0		Propeller shaft on vehicle service	
		Propeller shaft vibration	
Oil change (capacity)	MA-8	PST/SW - Wiring diagram	
Oil change (interval)		,	
Oil pan (engine)		_	
Oil pressure (engine)		R	
Oil pressure relief valve (engine)			
Oil pump (A/T)		R134a - See HFC134a	HA-3
Oil pump (engine)		Radiator	
Oil pump regulator valve (engine)		Radiator fan - See Cooling fan	
Oil seal replacement (engine)		Radio - See Audio	
Oil seal replacement (front final drive 4WD)		Rear axle	
Oil seal replacement (front of final drive)		Rear axle (drum brake type)	
Operating cylinder (clutch)		Rear body	
Out side mirror		Rear bumper	
Overdrive control switch		Rear combination lamp removal and installat	
Overrun clutch		Rear cover packing replacement diff	
Oversize piston		Rear drum brake	
Oxygen sensor (O2S) (front)		Rear heated oxygen sensor (HO2S)	
Chygon dondor (Ozo) (nont)		Rear heated oxygen sensor (HO2S) heater	
		Rear panel finisher	
P	[Rear seat belt	
		Rear side window	
Rantograph ipok	GL 20	Rear suspension	
Pantograph jack	GI-39 BB-28	Rear wheel anti-lock brake system (R-ARS)	

IDX-6

Rear window	BT-28	Stabilizer bar (front)	FA-39	GI
Refrigerant connection precaution	HA-5	Stall test (A/T)	AT-25	
Refrigerant discharging evacuating charging	g HA-48	Standardized relay	EL-4	
Refrigerant general precaution	HA-4	START - Wiring diagram	EL-20	MA
Refrigerant lines	HA-47	Start signal	EC-306	
Refrigeration cycle	HA-11	Starter	EL-22	r=n.c
Release bearing (clutch)		Starting system	EL-19	
Resistor		Steering gear and linkage inspection		
Reverse clutch		Steering gear oil level		LC
Reverse gear (M/T)	MT-8	Steering knuckle		Ľ.
Reverse idler shaft (M/T)		Steering linkage	ST-38	-
Reverse lamp switch (M/T) - See Back-up la		Steering switch		EC
switch (M/T)	-	Steering wheel and column		
Ring gear diff. inspectionPD-40, I		Steering wheel play		
Road wheel size		Steering wheel turning force		FE
Roof trim		Stop lamp		
Room lamp		Striking rod (M/T)		
Room lamp - See Interior lamp		Sunroof		CL
Rotor disc (front)		Supplement restraint system - Wiring diagram		
RRO2 - Wiring diagram		Supplemental Restraint System		
RRO2/H - Wiring diagram		S/VCSW - Wiring diagram		MIT
Throw the stage of		Swirl control valve control solenoid valve		
_	1	Swirl control valve control vacuum check	20 2.0	052
S		switch	EC-251	AT
		SWL/V - Wiring diagram		
SAE J1930 terminology list	GL45	SW/V - Wiring diagram		TF
Screw jack		Symbols and abbreviations		111
Seal - See Exterior		Synchronizer (M/T)		
Seal - See Exterior	D1-17	· · · · · · · · · · · · · · · · · · ·	171 1-0	
Cost halt fromt	DC 3	System readinger test (SDT) code	EC 26	(תופו
Seat belt inspection		System readiness test (SRT) code	EC-36	PD
Seat belt inspection	MA-23	System readiness test (SRT) code	EC-36	PD
Seat belt inspectionSeat belt, rear	MA-23 RS-3	System readiness test (SRT) code	EC-36	
Seat belt inspection	MA-23 RS-3 BT-23		EC-36	PD FA
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results	MA-23 RS-3 BT-23 EC-47	Т		
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram	MA-23 RS-3 BT-23 EC-47 AT-31	T Tachometer	EL-71	
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T)	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10	Tachometer	EL-71	FA
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift control (TF)	MA-23RS-3BT-23EC-47AT-31MT-10TF-10	Tachometer Tail lamp TAIL/L - Wiring diagram	EL-71 EL-50 EL-50	FA Ra
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift control (TF) Shift fork (M/T)	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 MT-10	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor	EL-71 EL-50 EL-50 EC-158	FA
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift fork (M/T) Shift lock system	MA-23RS-3BT-23AT-31MT-10TF-10MT-10MT-30	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram	EL-71 EL-50 EL-50 EC-158	FA Ra
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 MT-10 AT-30 AT-14	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage	EL-71 EL-50 EL-50 EC-158 EC-295	FA RA BR
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front)	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 MT-10 AT-30 AT-14 FA-36	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment	EL-71 EL-50 EC-158 EC-295	FA Ra
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front) Shock absorber (rear)	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 MT-10 AT-30 AT-14 FA-36 RA-10	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front)	EL-71 EL-50 EL-50 EC-158 EC-295 HA-43	FA RA BR
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69	Tachometer	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158	FA RA BR
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload (front final drive 4WD)	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69 PD-24	Tachometer	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158 HA-42	FA RA BR
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Fide bearing preload (front final drive 4WD) Side shaft diff	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69 PD-24 PD-21	Tachometer	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158 HA-42	FA RA BR
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Side bearing preload (front final drive 4WD) Side shaft diff Side trim	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69 PD-24 PD-21 BT-13	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermostat	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158 HA-42 HA-42	FA RA BR ST
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift fork (M/T) Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Side bearing preload (front final drive 4WD). Side shaft diff Side trim Side window - See Rear side window	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69 PD-24 PD-21 BT-13 BT-29	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermostat Three way catalyst	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158 HA-42 LC-9 EC-186	FA RA BR
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift lock system Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Side bearing preload (front final drive 4WD) Side shaft diff Side trim	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69 PD-24 PD-21 BT-13 BT-29	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermostat	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158 HA-42 LC-9 EC-186	FA RA BR ST
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift schedule Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Side bearing preload (front final drive 4WD). Side shaft diff Side trim Side window - See Rear side window SMJ (super multiple junction) Spare tire size	MA-23RS-3RS-3RS-3RT-23MT-10MT-10MT-10MT-10AT-30AT-31RA-10RA-10RA-10RD-46, PD-69PD-21BT-13BT-29 Foldout pageGI-38	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermostat Three way catalyst	EL-71EL-50EC-158EC-295HA-43FA-42EC-158HA-42LC-9EC-186LC-6	FA RA BR ST RS BT
Seat belt, rear	MA-23RS-3BT-23MT-23MT-10MT-10MT-10AT-30AT-34AT-36RA-10 PD-46, PD-69PD-21PD-21BT-13BT-29 Foldout pageGI-38	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermo control amp Thermostat Three way catalyst Three way catalyst precautions Throttle bodies Throttle chambers	EL-71EL-50EL-50EC-158EC-295HA-43FA-42EC-158HA-42HA-42HA-46LC-9EC-186EG-6EM-6	FA RA BR ST
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift schedule Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Side bearing preload (front final drive 4WD). Side shaft diff Side trim Side window - See Rear side window SMJ (super multiple junction) Spare tire size	MA-23RS-3BT-23MT-23MT-10MT-10MT-10AT-30AT-34AT-36RA-10 PD-46, PD-69PD-21PD-21BT-13BT-29 Foldout pageGI-38	Tachometer	EL-71EL-50EL-50EC-158EC-295HA-43FA-42EC-158HA-42HA-42HA-46LC-9EC-186EG-6EM-6	FA RA BR ST RS BT
Seat belt, rear	MA-23 RS-3 BT-23 EC-47 AT-31 MT-10 TF-10 AT-30 AT-14 FA-36 RA-10 PD-46, PD-69 PD-24 PD-21 BT-13 BT-29 Foldout page GI-38 MA-14 EL-72	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermo control amp Thermostat Three way catalyst Three way catalyst precautions Throttle bodies Throttle chambers	EL-71EL-50EL-50EC-158EC-295HA-43FA-42EC-158HA-42EC-158HA-6EC-186EC-186EC-186EC-186	FA RA BR ST RS BT
Seat belt, rear	MA-23	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermo control amp Thermostat Three way catalyst Three way catalyst precautions Throttle bodies Throttle chambers Throttle drum adjustment	EL-71EL-50EL-50EC-158EC-295HA-43FA-42EC-158LC-9EC-186GI-6GI-6EM-6EM-6	FA RA BR ST RS BT HA
Seat belt, rear	MA-23	Tachometer Tail lamp TAIL/L - Wiring diagram Tank fuel temperature sensor TCV - Wiring diagram Temperature control cable and linkage adjustment Tension rod (front) TFTS - Wiring diagram Thermal protector Thermo control amp Thermo control amp Thermostat Three way catalyst Three way catalyst precautions Throttle bodies Throttle chambers Throttle drum adjustment Throttle position sensor adjustment	EL-71EL-50EC-158EC-295FA-42FA-42EC-158HA-46EC-186EC-186EC-186EC-186EC-186	FA RA BR ST RS BT HA
Seat belt, rear	MA-23	Tachometer	EL-71EL-50EC-158EC-295FA-42FA-42EC-158HA-42EC-186GI-6EM-6EM-6EC-72EC-72	FA RA BR ST RS BT HA
Seat belt inspection Seat belt, rear Seat, front Self-diagnostic results SHIFT - Wiring diagram Shift control (M/T) Shift fork (M/T) Shift schedule Shock absorber (front) Shock absorber (rear) Side bearing preload diff Side bearing preload (front final drive 4WD). Side shaft diff Side window - See Rear side window SMJ (super multiple junction) Spare tire size Spark plug replacement Speedometer Spiral cable Spot lamp SRS - See Supplemental Restraint System.	MA-23	Tachometer	EL-71 EL-50 EC-158 EC-295 HA-43 FA-42 EC-158 HA-42 LC-9 EC-186 EM-6 EM-6 EM-6 EM-6 EM-6 EM-6 EC-72 EC-718 EC-118	FA RA BR ST RS BT HA EIL

IDX-7 1235

Timing chain	FM-10	Vehicle recovery (freeing a stuck vehicle)	GI-43
Tire rotation		Vehicle speed sensor (VSS)	
Tire size		Ventilator door control rod adjustment	
Tooth contact diffPD-51, i		VENT/V - Wiring diagram	
Tooth contact (front final drive 4WD)	·	Viscosity number (SAE)	
Torque converter clutch solenoid valve		VSS - Wiring diagram	
Torque converter installation			
Torque convertor clutch solenoid valve			
Torsion bar spring		W	
Tow truck towing			
Towing point		WARN - Wiring diagram	EL-79
TPS - Wiring diagram		Warning chime	
TP/SW - Wiring diagram		Warning lamps	
Transfer case		Washer, front	
Transfer fluid replacement		Water cock control rod adjustment	
Transfer oil replacement		Water pump	
Transfer overhaul		Water temperature gauge	
Transfer removal and installation		Weatherstrip - See Exterior	
Transfer serial number	GI-37	Wheel alignment (front)	
Transmission case (M/T)		Wheel balance	
Transmission serial number	Gl-37	Wheel bearing (front axle)	
Tread-FR&RR (Dimensions)		Wheel bearing (rear)	
Trim		Wheel hub (front)	
TURN - Wiring diagram		Wheel sensors (ABS)	
Turn signal lamp		Wheel size	
Two trip detection logic		Wheelbase (Dimensions)	
Two-pole lift		Wide open & closed throttle position (CTP)	
·		switch	EC-226
E 9		Width (Dimensions)	GI-38
U		WINDOW - Wiring diagram	
		Window antenna	
Under body	BT-36	Window, back	
Upper link (front susp.)	FA-40	Window, door	
, , ,		Window, rear	
37		Window, rear side	
V		Window, side - See Rear side window	
		Windshield	
Vacuum cut valve	EC-280	Windshield washer - See Front washer	EL-93
Vacuum cut valve bypass valve	EC-276	Windshield wiper - See Front wiper	EL-92
Vacuum hose (brake system)	BR-18	WIPER - Wiring diagram	
Vacuum hose drawing (ECCS)		Wiper and washer	
Valve clearance		Wiper, front	
Valve guide	EM-21	Wiring diagrams	
Valve seat		Withdrawal lever (clutch)	
Valve spring		Wrist pin - See Piston pin inspection	
Vehicle identification number		· ·	

1236 IDX-8