RENAULT

6 Air conditioning

- 61A HEATING
- 62A AIR CONDITIONING

X38, and B32 or L38

OCTOBER 2009

EDITION ANGLAISE

"The repair procedures given by the manufacturer in this document are based on the technical specifications current when it was prepared.

The procedures may be modified as a result of changes introduced by the manufacturer in the production of the various component units and accessories from which the vehicles are constructed".

All rights reserved by Renault.

Copying or translating, in part or in full, of this document or use of the service part reference numbering system is forbidden without the prior written authority of Renault.

© Renault s.a.s 2007

FLUENCE - MEGANE GENERATION -Section 6

61A-40

61A-41

61A-42

61A-45

61A-46

61A-47

62A-1

62A-3

62A-4

62A-9

62A-13

62A-15

Contents

Pages

61A	HEATING		61A	HEATING
	Heating: List and location of components	61A-1		Front footwell air distribution duct: Removal - Refitting
	Cabin filter: Removal - Refitting	61A-8		Recirculation motor: Removal - Refitting
	C-pillar intermediate air distribution duct: Removal - Refitting	61A-10		Mixing motor: Removal - Refitting
	Rear air distribution duct:	017710		Distribution motor: Removal - Refitting
	Removal - Refitting	61A-11		Passenger compartment
	Air distribution cable: Removal - Refitting	61A-12		temperature sensor: Removal - Refitting
	Air mixing cable: Removal - Refitting	61A-13		Exterior temperature sensor: Removal - Refitting
	Distribution unit: Removal - Refitting	61A-14		1
	Heater matrix: Removal - Refitting	61A-19	62A	
	Fan assembly: Removal - Refitting	61A-22		Air conditioning: List and location of components
	Heating resistor relays: Removal - Refitting	61A-27		Air conditioning: Parts and consumables for the repair
	Passenger compartment fan assembly control unit:			Condenser: Removal - Refitting
	Removal - Refitting	61A-29		Compressor: Removal - Refitting
	Control panel: Removal - Refitting	61A-30		Expansion valve: Removal -
	Front side air distribution duct: Removal - Refitting	61A-34		Refitting Evaporator: Cleaning
	Front centre air distribution duct: Removal - Refitting	61A-39		

Contents

62A AIR CONDITIONING

Condenser - expansion valve connecting pipe: Removal - Refitting	62A-17
Expansion valve - intermediate pipe connecting pipe at the expansion valve outlet: Removal - Refitting	62A-22
Pressure sensor: Removal - Refitting	62A-25
Evaporator sensor: Removal - Refitting	62A-27
Compressor - condenser connecting pipe: Removal - Refitting	62A-28
Compressor - intermediate pipe connecting pipe: Removal - Refitting	62A-31

Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL

I - LIST OF COMPONENTS

The air conditioning system consists of:

- a control panel (see 61A, Heating, Control panel: Removal - Refitting, page 61A-30),
- a cabin filter (see 61A, Heating, Cabin filter: Removal - Refitting, page 61A-8),
- an expansion valve (see 62A, Air conditioning, Expansion valve: Removal Refitting, page 62A-13),
- a recirculation motor (see 61A, Heating, Recirculation motor: Removal - Refitting, page 61A-41),
- a recirculation control cable (see **Recirculation control cable: Removal - Refitting**),
- a cooling fan assembly (see 61A, Heating, Fan assembly: Removal - Refitting, page 61A-22),
- an evaporator sensor (see 62A, Air conditioning, Evaporator sensor: Removal - Refitting, page 62A-27).
- a fan assembly control unit (see Rear passenger compartment fan assembly control unit: Removal
 Refitting) ,
- a heater matrix (see 61A, Heating, Heater matrix: Removal Refitting, page 61A-19),
- heating resistors (see Heating resistors: Removal -Refitting) ,
- heater resistor relay (see 61A, Heating, Heating resistor relays: Removal - Refitting, page 61A-27),

AIR CONDITIONING

- an air distribution cable (see 61A, Heating, Air distribution cable: Removal Refitting, page 61A-12).
- an air mixing cable (see 61A, Heating, Air mixing cable: Removal Refitting, page 61A-13),

CLIMATE CONTROL

- air mixing motors (see 61A, Heating, Mixing motor: Removal Refitting, page 61A-42) ,
- a distribution motor (see 61A, Heating, Distribution motor: Removal Refitting, page 61A-45),
- a front centre air distribution duct (see 61A, Heating, Front centre air distribution duct: Removal - Refitting, page 61A-39),
- a front intermediate side air distribution duct,

- front side air distribution ducts (see 61A, Heating, Front side air distribution duct: Removal - Refitting, page 61A-34),
- A-pillar air distribution ducts (see 61A, Heating, Front footwell air distribution duct: Removal - Refitting, page 61A-40),
- C-pillar air distribution ducts (see C-pillar air distribution duct: Removal Refitting),

EQUIPMENT LEVEL EA3 or EQUIPMENT LEVEL EA4

- a rear intermediate air distribution duct (see 61A, Heating, C-pillar intermediate air distribution duct: Removal - Refitting, page 61A-10),
- a rear air distribution duct (see 61A, Heating, Rear air distribution duct: Removal Refitting, page 61A-11).


Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL

II - LOCATION OF COMPONENTS

AIR CONDITIONING




144483

- (1) Control panel
- (2) Passenger compartment filter
- (3) Expansion valve
- (4) Recirculation motor
- (5) Recirculation control cable
- (6) Fan assembly
- (7) Evaporator sensor
- (8) Air distribution cable

Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL




- (9) Air mixing cable
- (10) Fan assembly control unit
- (11) Heater matrix
- (12) Heating resistors
- (13) Heating resistor relay

HEATING Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL

CLIMATE CONTROL




- (14) Instrument panel
- (15) Passenger compartment filter
- (16) Expansion valve
- (17) Recirculation motor
- (18) Recirculation control cable
- (19) Fan assembly
- (20) Evaporator sensor
- (21) Right-hand air mixing motor
- (22) Distribution motor

Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL




- (23) Fan assembly control unit
- (24) Heater matrix
- (25) Heating resistors
- (26) Heating resistor relay
- (27) Left-hand air mixing motor

HEATING Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL



- (28) Front central air distribution duct
- (29) Front intermediate side air distribution duct
- (30) Front left-hand side air distribution duct
- (31) Front right-hand side air distribution duct
- (32) Front left-hand footwell air distribution duct
- (33) Front right-hand footwell air distribution duct
- (34) Rear left-hand footwell air distribution duct
- (35) Rear right-hand footwell air distribution duct


133406

HEATING Heating: List and location of components



EXPORT EQUIPMENT LEVEL ADDITIONAL

EQUIPMENT LEVEL EA3 or EQUIPMENT LEVEL EA4



(36)	Rear intermediate air distribution duct
(a)	

(37) Rear air distribution duct

HEATING Cabin filter: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

Note:

Foreign bodies (leaves, insects, etc.) are likely to accumulate in the cabin filter. Remove the filter with care so as to prevent foreign bodies getting into the evaporator.

REMOVAL

I - REMOVAL PREPARATION OPERATION

Note:


Fold the filter slightly it in its housing in order to remove it.

Remove:


- the glovebox (see **Glovebox: Removal Refit-ting**) (57A, Interior equipment),
- the front right-hand A-pillar air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).

II - REMOVAL OPERATION

AIR CONDITIONING




□ Remove the cabin filter access flap (1).



□ Remove the cabin filter (2).

CLIMATE CONTROL




- Separate the electrical wiring (3) from the cabin filter access flap.
- □ Unclip the cabin filter access flap (4).

HEATING Cabin filter: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL




□ Remove the cabin filter.

REFITTING

REFITTING PREPARATION OPERATION

□ Check for foreign bodies in the cabin filter housing, and clean thoroughly if necessary.



Refit the cabin filter, observing the position of the arrows (5).

Note:

- Fold the filter slightly it in its housing to make fitting easier.
- Be sure not to damage the filtering section.
- □ Proceed in the reverse order to removal.

C-pillar intermediate air distribution duct: Removal - Refitting



Special tooling required

Car. 1363


Set of trim removal levers.

REMOVAL

I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).
- Remove the dashboard (see Dashboard: Removal - Refitting) (57A, Interior equipment).

II - OPERATION FOR REMOVAL OF PART CONCERNED



- □ Remove:
 - the clip (1) from the C-pillar intermediate air distribution duct using the tool (Car. 1363),
 - the C-pillar intermediate air distribution duct.

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

- Refit:
 - the C-pillar intermediate air distribution duct,
 - the clip of the C-pillar intermediate air distribution duct.

II - FINAL OPERATION

- Refit the dashboard (see Dashboard: Removal -Refitting) (57A, Interior equipment).
- Connect the battery (see Battery: Removal Refitting) (80A, Battery).




REMOVAL

I - REMOVAL PREPARATION OPERATION

Remove the centre console (see Centre console: Removal - Refitting) (57A, Interior equipment).

II - OPERATION FOR REMOVAL OF PART CONCERNED



- □ Unclip the rear air distribution duct from the centre console at (3).
- Remove the rear air distribution duct from the centre console.
- □ Separate the rear section of the rear air distribution duct from the rear air distribution duct (4).

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

- Refit:
 - the rear section of the air distribution duct onto the rear air distribution duct,
 - the rear air distribution duct on the centre console.
- Clip the rear air distribution duct onto the centre console.

II - FINAL OPERATION

Refit the centre console (see Centre console: Removal - Refitting) (57A, Interior equipment).

Air distribution cable: Removal - Refitting

61A

AIR CONDITIONING, and EXPORT EQUIPMENT LEVEL ADDITIONAL

Note:

The air distribution cable cannot be separated from the control panel.

- When replacing the air distribution cable, always replace the control panel and recover the air mixing cable (see 61A, Heating, Control panel: Removal Refitting, page 61A-30).
- □ If removing the air distribution cable, remove the control panel, air mixing cable and air distribution cable assembly (see 61A, Heating, Control panel: Removal Refitting, page 61A-30).

61A

AIR CONDITIONING, and EXPORT EQUIPMENT LEVEL ADDITIONAL

Note:

The air mixing cable cannot be separated from the control panel.

- When replacing the air mixing cable, always replace the control panel and recover the air distribution cable (see 61A, Heating, Control panel: Removal -Refitting, page 61A-30).
- □ If removing the air mixing cable, remove the control panel, air mixing cable and air distribution cable assembly (see 61A, Heating, Control panel: Removal Refitting, page 61A-30).



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

compressed air nozzle

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**)

Note:

Use fuel blanking plugs with part no. **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. Do not use any which have already been used to plug a fuel circuit


REMOVAL

I - REMOVAL PREPARATION OPERATION

WARNING

Consult the device's operating manual to avoid incorrect use.

- □ Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining Filling).
- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).



□ Remove the bulkhead heat shield clips (1)

WARNING


To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

□ Move the bulkhead heat shield to one side.



EXPORT EQUIPMENT LEVEL ADDITIONAL




Remove the bolts (2) from the expansion valve connecting pipe brackets.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Uncouple the connecting pipes from the expansion valve.
- □ Move the connecting pipes away from the expansion valve.
- □ Insert the blanking plugs.




141542

- □ Fit the tool (3) on the heater matrix hoses.
- Disconnect the heater matrix hoses.
- □ Remove:
 - the dashboard (see **Dashboard: Removal Refit-ting**) (57A, Interior equipment),
 - the front side air distribution duct (see 61A, Heating, Front side air distribution duct: Removal -Refitting, page 61A-34),
 - the dashboard cross member (see **Dashboard cross member: Removal Refitting**) (42A, Upper front structure).



EXPORT EQUIPMENT LEVEL ADDITIONAL

II - REMOVAL OPERATION



- Disconnect the supply connector (4) from the distribution unit.
- □ Unclip the electrical wiring from the distribution unit.
- Separate the electrical wiring from the distribution unit.
- Remove the distribution unit.

Note:

To find the location of components (see 61A, Heating, Heating: List and location of components, page 61A-1).

AIR CONDITIONING

- Remove the following components from the distribution unit:
 - the air distribution cable,
 - the cabin filter,
 - the expansion valve,
 - the recirculation motor,
 - the air recirculation control cable,
 - the fan assembly,
 - the fan assembly control unit,
 - the evaporator sensor,
 - the heater matrix,
 - the heater resistor relays,

- the heating resistor,
- the air mixing cable.

CLIMATE CONTROL


- Remove the following components from the distribution unit:
 - the left-hand mixer motor,
 - the right-hand mixer motor,
 - the distribution motor,
 - the cabin filter,
 - the expansion valve,
 - the recirculation motor,
 - the air recirculation control cable,
 - the fan assembly,
 - the evaporator sensor,
 - the heater matrix,
 - the heater resistor relays,
 - the heating resistor.



EXPORT EQUIPMENT LEVEL ADDITIONAL


REFITTING

I - REFITTING PREPARATION OPERATION



143880

Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).



- □ Use a **compressed air nozzle** to blow on the surface and the seal of the connecting pipe.
- □ Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

WARNING

Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.

□ Remove the blanking plugs.



EXPORT EQUIPMENT LEVEL ADDITIONAL

II - REFITTING OPERATION

- □ Proceed in reverse order to removal.
- Connect the battery (see Battery: Removal Refitting) (80A, Battery).
- □ Fill up and bleed the cooling system (see **Cooling** system: Draining Refilling) (19A, Cooling).

Note:

A summary table gives the quantities of refrigerant in the system according to the engine type (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

□ Perform the following operations:

- fill the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).

- check for leaks (see Refrigerant circuit: Check) .
- □ Check that the air conditioning system is operating correctly (see **Air conditioning: Check**).

HEATING Heater matrix: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required


compressed air nozzle

Tightening torques	$\overline{\mathcal{D}}$
upper nuts on the dash- board cross member reinforcement	21 N.m
lower bolts on the dash- board cross member reinforcement	21 N.m
air filter unit air outlet pipe clips	6 N.m

REMOVAL


I - REMOVAL PREPARATION OPERATION

□ Switch off the ignition.




- $\hfill\square$ Fit the toolson the heater matrix hoses (1) .
- □ Unclip the left-hand centre console trim.
- Remove:
 - the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment),

- the front left-hand footwell air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).
- Disconnect the connector from the parking distance control buzzer.



- Unclip the wiring from the dashboard cross member reinforcement at (2).
- □ Remove the lower bolts (3) from the dashboard cross member reinforcement.



Remove:

- the upper bolts (4) from the dashboard cross member reinforcement,


HEATING Heater matrix: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

- the dashboard cross member reinforcement.

II - REMOVAL OPERATION




□ Remove the clips (5) from the heater matrix rigid pipes.

WARNING


Prepare for the flow of fluid, and protect the surrounding components.

- □ Put a protective cover on the floor carpet.
- Position a container to collect the coolant under the rigid pipes.
- □ Move the heater matrix rigid pipes aside.
- □ Remove the seals from the heater matrix rigid pipes.



Remove:

- the heater matrix trim bolts (6),
- the heater matrix trim.



- □ Take the heater matrix out of its housing.
- D Remove the heater matrix.

HEATING Heater matrix: Removal - Refitting




REFITTING

I - REFITTING PREPARATION OPERATION

WARNING


Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.



143880

□ Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).



143882

- Use a compressed air nozzle to blow on the surface and the seal of the connecting pipe.
- Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- Remove the blanking plugs.

II - REFITTING OPERATION

- Proceed in the reverse order to removal.
- □ Torque tighten:
 - the upper nuts on the dashboard cross member reinforcement (21 N.m),
 - the lower bolts on the dashboard cross member reinforcement (21 N.m),
 - Torque tighten the air filter unit air outlet pipe clips (6 N.m),

III - FINAL OPERATION

□ Fill and bleed the cooling system (see **Cooling sys**tem: Draining - Refilling) (19A, Cooling).




EXPORT EQUIPMENT LEVEL ADDITIONAL


REMOVAL

I - REMOVAL PREPARATION OPERATION

- □ Move the seat as far back as possible.
- □ Switch off the ignition.
- Remove:
 - the glovebox (see **Glovebox: Removal Refitting**) (57A, Interior equipment),
 - the front footwell air distribution duct (see 61A, Heating, Front side air distribution duct: Removal - Refitting, page 61A-34),
 - the front right-hand side air distribution duct (see 61A, Heating, Front side air distribution duct: Removal Refitting, page 61A-34).



- Disconnect the connector (2) from the recirculation motor.
- $\hfill\square$ Unclip the recirculation control cable (1) .
- $\hfill\square$ Mark the routing of the recirculation motor wiring (3)
- □ Separate the wiring from the recirculation motor.




- □ Remove the bolts (4) from the air recirculation duct.
- $\hfill\square$ Unclip the air recirculation duct at (5) .
- □ Remove the air recirculation duct.



EXPORT EQUIPMENT LEVEL ADDITIONAL


II - REMOVAL OPERATION



Note:


The tool for removing the fan assembly is supplied in the spare parts kit for the new fan assembly.

□ Fit the fan assembly removal tool in a vertical position on the turbine so that the openings (6) of the tool line up with the turbine upper bolts.



Remove:


- the two turbine bolts (7) of the fan assembly,
- the roller unit bolt (8) from the fan assembly.
- □ Remove the fan assembly removal tool.




Remove the turbine roller unit from the fan assembly at (9)



EXPORT EQUIPMENT LEVEL ADDITIONAL



- □ Fit the fan assembly removal tool on the fan assembly in a vertical position.
- Push and turn the fan assembly removal tool clockwise to unlock (10) the passenger compartment fan assembly.



Remove the fan assembly from its housing while taking care not to damage the turbine.

Note:

To avoid making the fan assembly motor unstable, position the assembly horizontally while protecting it from any impact.


- Disconnect the fan assembly connector (11)
- □ Remove the fan assembly.

61A


EXPORT EQUIPMENT LEVEL ADDITIONAL


REFITTING

I - REFITTING OPERATION



□ Fit the fan assembly removal tool (12) on the fan assembly (13).






- □ Turn the tool slightly clockwise (14) to bring the boss (15) to the end of the housing (16).
- Ensure that the fan assembly removal tool is positioned correctly in relation to the passenger compartment fan assembly turbine.
- □ Connect the fan assembly connector.



EXPORT EQUIPMENT LEVEL ADDITIONAL



- Refit the fan assembly in its housing by turning the tool 30° in relation to the vertical axis.
- Push the fan assembly until it is fully inserted in its housing.
- Turn the fan assembly removal tool anticlockwise (17) to lock the passenger compartment fan assembly.
- □ Remove the fan assembly removal tool.
- □ Refit the fan assembly roller unit.
- □ Fit the fan assembly removal tool so that the openings of the tool line up with the turbine bolts.
- □ Refit the bolts (7) and (8).
- □ Remove the fan assembly removal tool.

II - FINAL OPERATION

□ Proceed in the reverse order to removal.

HEATING Heating resistor relays: Removal - Refitting



REMOVAL


Note:

There are 2 possible fittings for the heating resistor relays:

- **1000 Watt resistor** : 1 relay unit located on the left of the centre console (see **61A**, **Heating**, **Heating: List and location of components**, page **61A-1**),


- **1800 Watt resistor** : 2 relay units located on the right and left of the centre console (see **61A**, **Heating**, **Heating: List and location of components**, page **61A-1**).

I - REMOVAL PREPARATION OPERATION




□ Unclip the left-hand or right-hand panel (1) of the centre console.

II - OPERATION FOR REMOVAL OF PART CONCERNED



- Unclip the heating resistor relay unit from the distribution unit.
- Separate the heating resistor relay unit from the distribution unit.




Unclip the cover (2) from the heating resistor relay unit.

HEATING Heating resistor relays: Removal - Refitting

6

А



□ Remove the heating resistor relays (3).

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit the heating resistor relays.
- Clip:
 - the cover of the heating resistor relay unit,
 - the heating resistor relay unit onto the distribution unit.

II - FINAL OPERATION


□ Clip on the left-hand or right-hand panel of the centre console.



EXPORT EQUIPMENT LEVEL ADDITIONAL


REMOVAL

I - REMOVAL PREPARATION OPERATION



- □ Unclip the left-hand centre console trim (1).
- □ Remove:
 - the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment),
 - the brake pedal (see **Brake pedal: Removal Re-fitting**) (37A, Mechanical component controls).

II - REMOVAL OPERATION



- Remove the bolts (2) for the passenger compartment fan assembly control unit.
- □ Disconnect the connector (3) from the passenger compartment fan assembly control unit.
- Remove the passenger compartment fan assembly control unit.

REFITTING

□ Proceed in the reverse order to removal.

HEATING Control panel: Removal - Refitting

EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

Diagnostic tool

Tightening torques 灾	
dashboard cross mem- ber reinforcement upper bolts	21 N.m
dashboard cross mem- ber reinforcement lower bolts	21 N.m

REMOVAL

I - REMOVAL PREPARATION OPERATION


- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).
- Remove the centre front panel (see Centre front panel: Removal - Refitting) (57A, Interior equipment).

RADIO 01A or RADIO 02A or RADIO 03A or RADIO 04A or RADIO 05A or RADIO 10B

Remove the radio (see Radio: Removal - Refitting) (86A, Radio).

□ Remove:


- the glovebox (see **Glovebox: Removal Refit-ting**) (57A, Interior equipment),
- the front right-hand A-pillar air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).



□ Unclip the left-hand centre console trim.

Remove:

- the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment),
- the front left-hand footwell air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).
- Unclip the wiring from the dashboard cross member reinforcement.




Remove the lower bolts (1) from the dashboard cross member reinforcement.

HEATING Control panel: Removal - Refitting




EXPORT EQUIPMENT LEVEL ADDITIONAL




□ Remove:

- the upper bolts (2) from the dashboard cross member reinforcement,
- the dashboard cross member reinforcement.


II - OPERATION FOR REMOVAL OF PART CONCERNED



- □ Unclip the air mixing cable (3) from the distribution unit.
- □ Mark the routing of the air mixing cable.



- □ Unclip the air distribution cable from the distribution unit at (4).
- □ Mark the routing of the air distribution cable.



- □ Remove the bolts (5) from the control panel.
- □ Squeeze the centring pins (6) while pushing the control panel.


AIR CONDITIONING

Tilt the control panel.

HEATING Control panel: Removal - Refitting




EXPORT EQUIPMENT LEVEL ADDITIONAL




- Disconnect the connectors (7) from the control panel.
- Remove the control panel, air mixing cable and air distribution cable assembly.

CLIMATE CONTROL



- □ Tilt the control panel.
- Disconnect the control panel connector (8) .



- □ Move aside the control panel.
- Disconnect the control panel connector (9).
- □ Remove the control panel.

REFITTING

I - REFITTING PREPARATION OPERATION

AIR CONDITIONING

1 - When replacing the control panel:

- Recover the air mixing cable and the air distribution cable by breaking the mountings of the cables on the control panel.
- □ Remove the air mixing cable and the air distribution cable.
- □ Reposition the air mixing cable and the air distribution cable on the new control panel.

2 - When replacing the air mixing cable or the air distribution cable:

Always replace the control panel, air mixing cable and air distribution cable assembly.



EXPORT EQUIPMENT LEVEL ADDITIONAL

II - REFITTING OPERATION FOR PART CONCERNED

AIR CONDITIONING

- □ Fit the control panel, air mixing cable and air distribution cable assembly in its housing.
- □ Connect the control panel connectors (7).


CLIMATE CONTROL

- □ Connect the control panel connector (9).
- □ Refit the control panel in its housing.
- □ Connect the control panel connector (8).
- □ Clip on the centring pins.
- □ Refit the control panel bolts.
- □ Clip the air distribution cable onto the distribution unit.
- Check that the air mixing control can move along its whole stroke.
- □ Clip the air mixing cable onto the distribution unit.
- □ Check that the air distribution control can move along its whole stroke.
- □ Check the correct operation of the control panel.

III - FINAL OPERATION

- □ Proceed in the reverse order to removal.
- □ Torque tighten:
 - the dashboard cross member reinforcement upper bolts (21 N.m),
 - the dashboard cross member reinforcement lower bolts (21 N.m).
- Apply the after repair procedure using the Diagnostic tool :
 - connect the Diagnostic tool,
 - select "Climate control computer",
 - go to repair mode,
 - display the "Before/after repair procedure" for the computer selected,
 - carry out the operations described in the "After repair procedure" section.

HEATING Front side air distribution duct: Removal - Refitting



REMOVAL

I - REMOVAL PREPARATION OPERATION

1 - Front right-hand side air distribution duct

Remove the airbag inhibitor switch (see Inhibitor switch: Removal - Refitting) (88C, Airbag and pretensioners).

LEFT-HAND DRIVE

Remove the glovebox (see Glovebox: Removal -Refitting) (57A, Interior equipment).


LEFT-HAND DRIVE, and RADIO 04A or RADIO 05A

- Remove:
 - the offset multimedia socket computer (see Offset multimedia socket computer: Removal Refitting) (86A, Radio),
 - the offset multimedia socket computer mounting bolts,
 - the offset multimedia socket computer mounting.

RIGHT-HAND DRIVE


Remove:

- the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment),
- the cowlings under the steering wheel.




Disconnect:

- the steering column connectors (1),
- the electric steering column lock,
- the steering column control connectors.
- □ Move the seat as far back as possible.
- □ Fit a block of approximately **440 mm** between the steering column and the floor.



- □ Remove the nuts (2) from the steering column.
- Remove the block between the steering column and the floor.

HEATING Front side air distribution duct: Removal - Refitting




Lower the steering column in the footwell.

Note:


Vertically lower the steering column and do not apply pressure to the universal joints.

□ Check that the cross piece (3) does not leave the bearing.




LEFT-HAND DRIVE

Remove the dashboard lower trim (see Dashboard lower trim: Removal - Refitting) (57A, Interior equipment).




□ Remove:

- the bolts (4) of the cowlings under the steering wheel,
- the cowlings under the steering wheel.




- Disconnect:
 - the steering column connectors (5),
 - the electric steering column lock,
 - the steering column control connectors.
- □ Move the seat as far back as possible.

□ Fit a block of approximately **440 mm** between the steering column and the floor.



- $\hfill\square$ Remove the nuts (6) from the steering column.
- Remove the block between the steering column and the floor.



138654

Lower the steering column in the footwell.

Note:

Vertically lower the steering column and do not apply pressure to the universal joints.

□ Check that the cross piece (7) does not leave the bearing.

RIGHT-HAND DRIVE


Remove the glovebox (see Glovebox: Removal -Refitting) (57A, Interior equipment).

RIGHT-HAND DRIVE, and RADIO 04A or RADIO 05A

Remove:

- the offset multimedia socket computer (see Offset multimedia socket computer: Removal - Refitting) (86A, Radio),
- the offset multimedia socket computer mounting bolts,
- the offset multimedia socket computer mounting.

II - OPERATION FOR REMOVAL OF PART CONCERNED



Disconnect:

- the front side air distribution duct from the air distribution unit at $({\bf 8})$,
- the front side air distribution duct from the air vent at $({\bf 9})$.
- □ Remove the front side air distribution duct.

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

□ Refit the front side air distribution duct.

II - FINAL OPERATION

1 - Front right-hand side air distribution duct:

RIGHT-HAND DRIVE

- □ Refit the steering column.
- □ Fit a block of approximately **440 mm** between the steering column and the floor.
- □ Torque tighten the steering column nuts (21 N.m).
- Remove the block between the steering column and the floor.
- Connect:
 - the steering column connectors,

- the electric steering column lock,
- the steering column control connectors.

Refit:

- the cowlings under the steering wheel,
- the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment).

LEFT-HAND DRIVE, and RADIO 04A or RADIO 05A

Refit:

- the offset multimedia socket computer mounting,
- the offset multimedia socket computer mounting bolts,
- the offset multimedia socket computer (see Offset multimedia socket computer: Removal Refitting) (86A, Radio).

LEFT-HAND DRIVE

Refit:

- the glovebox (see **Glovebox: Removal Refitting**) (57A, Interior equipment),
- the airbag inhibitor switch (see **Inhibitor switch: Removal Refitting**) (88C, Airbag and pretensioners).
- 2 Front left-hand side air distribution duct:

RIGHT-HAND DRIVE, and RADIO 04A or RADIO 05A

Refit:

- the offset multimedia socket computer mounting,
- the offset multimedia socket computer (see Offset multimedia socket computer: Removal Refitting) (86A, Radio).

Front side air distribution duct: Removal - Refitting

RIGHT-HAND DRIVE

Refit the glovebox (see Glovebox: Removal - Refitting) (57A, Interior equipment).

LEFT-HAND DRIVE

- □ Refit the steering column.
- □ Fit a block of approximately **440 mm** between the steering column and the floor.
- □ Torque tighten the steering column nuts (21 N.m).
- Remove the block between the steering column and the floor.
- □ Connect:
 - the steering column connectors,
 - the electric steering column lock,
 - the steering column control connectors.
- Refit:
 - the cowlings under the steering wheel,
 - the bolts of the cowlings under the steering wheel,
 - the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment).

Front centre air distribution duct: Removal - Refitting


61

REMOVAL

I - REMOVAL PREPARATION OPERATION

- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).
- Remove the dashboard (see Dashboard: Removal - Refitting) (57A, Interior equipment).

II - OPERATION FOR REMOVAL OF PART CONCERNED



137638

Remove the front centre air distribution duct bolts (1)

- □ Unclip the front centre air distribution duct at (2).
- □ Remove the front centre air duct.

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

- Refit the front centre air duct.
- □ Clip on the front centre air duct.
- □ Refit the front centre air duct bolts.

II - FINAL OPERATION

- Refit the dashboard (see Dashboard: Removal -Refitting) (57A, Interior equipment).
- Connect the battery (see Battery: Removal Refitting) (80A, Battery).

Front footwell air distribution duct: Removal - Refitting

61A

Special tooling required

Car. 1363

Set of trim removal levers.

REMOVAL

I - REMOVAL PREPARATION OPERATION

1 - Driver's side


Remove the instrument panel lower trim (see Dashboard lower trim: Removal - Refitting) (57A, Interior equipment).

2 - Passenger side

Remove the glovebox (see Glovebox: Removal -Refitting) (57A, Interior equipment).

II - OPERATION FOR REMOVAL OF PART CONCERNED

1 - Driver's side




Remove:

- the clip (1) from the A-pillar air duct, using the tool (Car. 1363),

- the A-pillar air duct (2) .

2 - Passenger side



Remove:

- the clip (3) from the A-pillar air duct,
- the A-pillar air duct (4) .

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

Refit:

- the A-pillar air duct,
- the A-pillar air duct clip.

II - FINAL OPERATION

1 - Driver's side

Refit the instrument panel lower trim (see Dashboard lower trim: Removal - Refitting) (57A, Interior equipment).

2 - Passenger side

Refit the glovebox (see Glovebox: Removal - Refitting) (57A, Interior equipment).

Recirculation motor: Removal - Refitting

EXPORT EQUIPMENT LEVEL ADDITIONAL


Equipment required

Diagnostic tool

REMOVAL


I - REMOVAL PREPARATION OPERATION

- □ Remove:
 - the glovebox (see **Glovebox: Removal Refitting**) (57A, Interior equipment),
 - the front right-hand A-pillar air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).
- Remove the offset multimedia socket computer (see Offset multimedia socket computer: Removal -Refitting).
- Remove the front side air distribution duct (see 61A, Heating, Front side air distribution duct: Removal - Refitting, page 61A-34).



- $\hfill\square$ Unclip the recirculation control cable (1) .
- Disconnect the connector (2) from the recirculation motor.

II - REMOVAL OPERATION



Remove:

- the bolts (3) from the air recirculation duct,
- the air recirculation duct,
- the bolts (4) from the air recirculation motor,
- the air recirculation motor.

REFITTING

- Proceed in the reverse order to removal.
- Apply the after repair procedure using the Diagnostic tool
 - connect the Diagnostic tool,
 - select "Climate control computer",
 - go to repair mode,
 - display the "Before/after repair procedure" for the computer selected,
 - select "air recirculation flap motor" in the "List of components stored by this computer" section,
 - carry out the operations described in the "After repair procedure" section.

Mixing motor: Removal - Refitting



CLIMATE CONTROL, and EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

Diagnostic tool

REMOVAL

I - REMOVAL PREPARATION OPERATION

1 - Right-hand mixing motor

- Remove:
 - the glovebox (see **Glovebox: Removal Refit-ting**) (57A, Interior equipment),
 - the front right-hand footwell air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal - Refitting, page 61A-40).


2 - Left-hand mixing motor

Remove:

- the dashboard lower trim (see **Dashboard lower trim: Removal Refitting**) (57A, Interior equipment),
- the front left-hand footwell air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).
- the « brake pedal accelerator » assembly (see **Brake pedal: Removal Refitting**) (37A, Mechanical component control).

II - REMOVAL OPERATION

1 - Right-hand mixing motor



Disconnect the connector (1) from the air mixing motor.

Remove:


- the bolts (2) from the air mixing motor,
- the air mixing motor.

HEATING Mixing motor: Removal - Refitting



CLIMATE CONTROL, and EXPORT EQUIPMENT LEVEL ADDITIONAL

2 - Left-hand mixing motor




- Disconnect the connector (3) from the air mixing motor.
- Remove:
 - the bolts (4) from the air mixing motor,
 - the air mixing motor.

REFITTING

I - REFITTING PREPARATION OPERATION

1 - Right-hand mixing motor




□ Move the tie rod so that the flat surface (5) of the right-hand mixing motor recess is positioned at 90° in relation to the distribution unit reference axis (6).

HEATING Mixing motor: Removal - Refitting

Д

CLIMATE CONTROL, and EXPORT EQUIPMENT LEVEL ADDITIONAL

2 - Left-hand mixing motor



❑ Move the tie rod so that the flat surface (7) of the lefthand mixing motor recess is positioned at 90° in relation to the edge of the distribution unit reference axis (8).

II - REFITTING OPERATION

□ Proceed in the reverse order to removal.

III - FINAL OPERATION

- □ Apply the after repair procedure using the **Diagnos**tic tool :
 - connect the **Diagnostic tool**,
 - select "Climate control computer",
 - go to repair mode,
 - display the "Before/after repair procedure" for the computer selected,
 - select "Left-hand air mixing flap motor or Righthand air mixing flap motor" in the "List of components stored by this computer" section,
 - carry out the operations described in the "After repair procedure" section.

Distribution motor: Removal - Refitting



CLIMATE CONTROL, and EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required


Diagnostic tool

REMOVAL

I - REMOVAL PREPARATION OPERATION

- Remove:
 - the glovebox (see **Glovebox: Removal Refit-ting**) (57A, Interior equipment),
 - the front right-hand A-pillar air distribution duct (see 61A, Heating, Front footwell air distribution duct: Removal Refitting, page 61A-40).


II - REMOVAL OPERATION



- □ Mark the routing of the distribution motor wiring.
- Disconnect the connector (1) from the distribution motor.
- Remove:
 - the bolts (2) from the distribution motor,
 - the distribution motor.

REFITTING

I - REFITTING PREPARATION OPERATION



❑ Move the tie rod so that the flat surface (3) of the distribution motor recess is positioned at 90° in relation to the distribution unit reference axis (4).

II - REFITTING OPERATION

- □ Refit the distribution motor.
- Reconnect the distribution motor connector.
- □ Fit the electrical wiring of the distribution motor.


III - FINAL OPERATION

- □ Proceed in the reverse order to removal.
- □ Apply the after repair procedure using the **Diagnos**tic tool :
 - connect the Diagnostic tool,
 - select "Climate control computer",
 - go to repair mode,
 - display the "Before/after repair procedure" for the computer selected,
 - select "Footwell air distribution flap motor" in the "List of components controlled by this computer" section,
 - carry out the operations described in the "After repair procedure" section.


Passenger compartment temperature sensor: Removal - Refitting




OPERATION FOR REMOVAL OF PART CONCERNED



□ Remove the interior rear view mirror trim (1).



□ Disconnect the passenger compartment temperature sensor connector (2).



□ Unclip the passenger compartment temperature sensor (3) from the interior rear view mirror trim.

REFITTING

REFITTING OPERATION FOR PART CONCERNED

- □ Clip the passenger compartment temperature sensor onto the interior rear view mirror trim.
- □ Connect the passenger compartment temperature sensor connector.
- □ Refit the interior rear view mirror trim.

Exterior temperature sensor: Removal - Refitting



Note:


The exterior temperature sensor is located in the door mirror on the right-hand side.

REMOVAL


I - REMOVAL PREPARATION OPERATION

- Remove:
 - the right-hand door mirror glass (see **Door mirror** glass: Removal Refitting) (56A, Exterior equipment),
 - the right-hand door mirror casing (see **Door mirror** casing: Removal Refitting) (56A, Exterior equipment).


II - OPERATION FOR REMOVAL OF PART CONCERNED



Unclip the right-hand door mirror mounting to remove the sensor by pressing on the clips (1).



Remove the exterior temperature sensor (2) from its mounting.



Cut the wires (3) of the exterior temperature sensor (see Wiring: Repair) (Technical Note 6015A, 88A, Wiring).

Exterior temperature sensor: Removal - Refitting



REFITTING


I - REFITTING OPERATION FOR PART CONCERNED

- Solder the wires of the exterior temperature sensor (see Wiring: Repair) (Technical Note 6015A, 88A, Wiring).
- Refit the exterior temperature sensor onto its mounting.
- □ Clip on the right-hand door mirror mounting.

II - FINAL OPERATION

- Refit:
 - the right-hand door mirror casing (see **Door mirror** casing: Removal Refitting) (56A, Exterior equipment),
 - the right-hand door mirror glass (see **Door mirror** glass: Removal Refitting) (56A, Exterior equipment).

AIR CONDITIONING Air conditioning: List and location of components



139042

62A

No.	Description		
(1)	Compressor (see 62A, Air conditioning, Compressor: Removal - Refit- ting, page 62A-9)		
(2)	« Compressor - condenser » connecting pipe (see 62A, Air conditioning, Compressor - condenser connecting pipe: Removal - Refitting, page 62A-28)		
(3)	Condenser (see 62A, Air conditioning, Condenser: Removal - Refitting, page 62A-4)		
(4)	Dehydrator reservoir filter		
(5)	« Condenser - expansion valve » connecting pipe (see 62A, Air condition- ing, Condenser - expansion valve connecting pipe: Removal - Refitting, page 62A-17)		
(6)	« Expansion valve - intermediate pipe » connecting pipe (see 62A, Air con ditioning, Expansion valve - intermediate pipe connecting pipe at the expansion valve outlet: Removal - Refitting, page 62A-22)		

I

Air conditioning: List and location of components



No.	Description		
(7)	« Intermediate pipe - compressor » connecting pipe (see 62A, Air condi- tioning, Compressor - intermediate pipe connecting pipe: Removal - Refitting, page 62A-31)		
(8)	Pressure sensor (see 62A, Air conditioning, Pressure sensor: Removal - Refitting, page 62A-25)		

Air conditioning: Parts and consumables for the repair



EXPORT EQUIPMENT LEVEL ADDITIONAL

For the oil part number (see **Vehicle: Parts and consumables for the repair**) (04B, Consumables - Products).

Table of vehicle refrigerant capacities according to their engines and various specifications

Engine	Refrigerant capacity (g)	Type of compres- sor	Type of origi- nal oil	Type of After- Sales oil	Quantity of oil (ml)
K4M	• 433 ± 35	CR12Sc Calsonic	DH-PR	PAG 448	150 ± 10
К9К					

Table of quantities of oil to add when replacing components:

Operation on the air conditioning circuit	Quantity of oil (ml or cm ³)	
Circuit oil change	Measure the volume recovered and add the same quantity of new oil	
Split pipe or other rapid leak	100	
Replacement of a pipe	Quantity recovered +10	
Replacement of a condenser	Quantity recovered +30	
Replacement of an evaporator or distribution unit	Quantity recovered +30	
Replacement of the filter or dehydrator reservoir	Quantity recovered +15	
Removing - Refitting a compressor	Quantity recovered	
Replacement of a compressor	None added	
Standard replacement of a compressor	Top up as necessary	
Replacement of a compressor and one or more refrigerant circuit component(s)	None added	
Standard replacement of a compressor and replacement of one or more refrigerant circuit component(s)	Top up as necessary	



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

Note:

Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

REMOVAL

I - REMOVAL PREPARATION OPERATION

 Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (02A, Lifting equipment).

WARNING

Consult the device's operating manual to avoid incorrect use.

Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).

DISCHARGE LAMPS


- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).
- Remove:


- the front wheels (see **Wheel: Removal - Refitting**) (35A, Wheels and tyres),


- the front sections of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
- the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).



EXPORT EQUIPMENT LEVEL ADDITIONAL








Unclip:

- the central deflector (1),
- the left-hand side deflector (2),
- the right-hand side deflector ${\bf (3)}$.
- Remove:
 - the audible warning (see Audible warning: Removal - Refitting) (82A, Horn),
 - the left-hand headlight (see **Headlight: Removal - Refitting**) (80B, Headlights),
 - the side support of the left-hand front panel (see **Front end panel side support: Removal Refitting**) (42A, Upper front structure).




EXPORT EQUIPMENT LEVEL ADDITIONAL

II - OPERATION FOR REMOVAL OF PART CONCERNED



Disconnect the pressure sensor connector (4).



□ Remove the bolt (5) securing the bracket for the « condenser - expansion valve » connecting pipe to the condenser.


WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- □ Disconnect the « condenser expansion valve » connecting pipe from the condenser.
- □ Insert the blanking plugs.



EXPORT EQUIPMENT LEVEL ADDITIONAL




Remove the bolt (6) securing the bracket for the « compressor - condenser » connecting pipe from the condenser.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- □ Disconnect the «compressor condenser» connecting pipe from the condenser.
- □ Insert the blanking plugs.



Remove the condenser in accordance with the direction of the arrow.

REFITTING

I - REFITTING PREPARATION OPERATION

WARNING

Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.

WARNING

To avoid any leaks, check that the seal and the pipe surface are in good condition. The seal and the surface must be clean and scratch free.

Remove the blanking plugs.

II - REFITTING OPERATION FOR PART CONCERNED

- Refit:
 - the condenser,
 - the connecting pipes to the condenser.
- Connect the pressure sensor connector.



EXPORT EQUIPMENT LEVEL ADDITIONAL

III - FINAL OPERATION

Refit

- the side support of the left-hand front panel (see **Front end panel side support: Removal Refit-ting**) (42A, Upper front structure),
- the left-hand headlight (see **Headlight: Removal - Refitting**) (80B, Headlights),
- the audible warning (see Audible warning: Removal - Refitting) (82A, Horn).

Clip:

- the right-hand side deflector,
- the left-hand side deflector,
- the central deflector.

Refit:

- the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection),
- the front sections of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
- the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres).

DISCHARGE LAMPS

Connect the battery (see Battery: Removal - Refitting) (80A, Battery).

Note:

A summary table gives the quantities of refrigerant in the system according to the engine types (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- □ Fill up the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining Filling).
- □ Check for leaks (see Refrigerant circuit: Check) .
- □ Check the air conditioning system is operating correctly (see Air conditioning: Check).
- Adjust the headlights (see Headlight: Adjustment) (80B, Headlights).



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

compressed air nozzle

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:

- (see Air conditioning: Precautions for the repair) ,
- (see Vehicle: Precautions for the repair) (01D, Mechanical introduction).

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

Note:

Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.

REMOVAL

I - REMOVAL PREPARATION OPERATION

 Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (02A, Lifting equipment).

WARNING

Consult the device's operating manual to avoid incorrect use.

- Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).
- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).

- Remove:
 - the engine undertray bolts,
 - the engine undertray.
 - the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
 - the front section of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
 - the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection),
 - the headlights (see **Headlight: Removal Refit-ting**) (80B, Headlights),
 - the front bumper supports (see **Front bumper mounting: Removal - Refitting**) (42A, Front upper structure),
 - the audible warning (see Audible warning: Removal Refitting) (82B, Horn),
 - the front impact cross member (see Front impact cross member: Removal Refitting) (41A, Front lower structure),
 - the cooling radiator air deflectors.
- Remove the bonnet lock (see Bonnet lock: Removal Refitting) (52A, Non-side opening element mechanisms).


WARNING

In order to prevent the accessories belt from being prematurely ruptured, do not damage (hit, force with a tool, etc.) the plastic pulley of the compressor.

Remove the accessories belt (see Accessories belt: Removal - Refitting) (11A, Top and front of engine).




EXPORT EQUIPMENT LEVEL ADDITIONAL




Remove the bolts (1) from the engine wiring channel.

K9K




- 135883
- □ Unclip the expansion bottle top hose (2) from the front end panel.
- Remove the intercooler air outlet pipe (see Intercooler air outlet pipe: Removal - Refitting) (12B, Turbocharging).



Remove:


- the upper bolts (3) from the front end panel,
- the front end panel clips (4) .



- □ Remove the lower bolts (6) from the front end panel.
- Tilt the front end panel slightly towards the front of the vehicle.



EXPORT EQUIPMENT LEVEL ADDITIONAL




□ Remove the connecting pipe bracket bolts (7) on the compressor.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Uncouple the connecting pipes from the compressor.
- □ Move aside the compressor connecting pipes.
- □ Fit blanking plugs on the openings of the connecting pipes and the compressor.

II - REMOVAL OPERATION



- $\hfill\square$ Disconnect the compressor connector $(\mathbf{8})$.
- □ Remove the bolts (9) from the compressor.
- □ Move aside the wiring.
- □ Remove the compressor.

REFITTING

I - REFITTING PREPARATION OPERATION


WARNING

Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.



EXPORT EQUIPMENT LEVEL ADDITIONAL



143880

□ Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).



- □ Use a **compressed air nozzle** to blow on the surface and the seal of the connecting pipe.
- □ Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- □ Remove the blanking plugs.

II - REFITTING OPERATION

Proceed in the reverse order to removal.

Note:

A summary table gives the quantities of refrigerant in the system according to the engine types (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- □ Fill up the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining Filling).
- In the event of replacement, apply the after repair procedure:
 - Switch on the ignition,
 - Check that the air conditioning is off,
 - Switch the ventilation to speed 2,
 - Put the temperature setting at minimum,
 - Select the air recirculation position,
 - Start the engine.
 - Run the air conditioning in manual mode (in the case of climate control do not press auto),
 - Run the engine at idle speed for **3 minutes** with air conditioning,
 - Switch off the engine.
- Check for leaks (see Refrigerant circuit: Check) .
- □ Check that the air conditioning system is operating correctly (see **Air conditioning: Check**).
- Adjust the headlights (see Headlight: Adjustment) (80B, Headlights).

AIR CONDITIONING Expansion valve: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

compressed air nozzle

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

Note:

Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.

REMOVAL

I - REMOVAL PREPARATION OPERATION

WARNING

Consult the device's operating manual to avoid incorrect use.

- Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).
- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).


WARNING

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

□ Remove the upper clips of the bulkhead heat shield.

Move the bulkhead heat shield to one side.




Remove the bolts (1) from the expansion valve connecting pipe bracket.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Uncouple the connecting pipes from the expansion valve.
- □ Fit the blanking plugs on the openings of the connecting pipes and on the expansion valve.

II - REMOVAL OPERATION



Remove:

- the bolts (2) from the expansion valve,

AIR CONDITIONING Expansion valve: Removal - Refitting

EXPORT EQUIPMENT LEVEL ADDITIONAL

- the expansion valve.


REFITTING

I - REFITTING PREPARATION OPERATION

WARNING


Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.





□ Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).



143882

- Use a compressed air nozzle to blow on the surface and the seal of the connecting pipe.
- Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- Remove the blanking plugs.

II - REFITTING OPERATION

Proceed in the reverse order to removal.

Note:

A summary table gives the quantities of refrigerant in the system according to the engine types (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- Perform the following operations:
 - refill the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling),
 - check for leaks (see Refrigerant circuit: Check) .
- Check that the air conditioning system is operating correctly (see Air conditioning: Check).

LEFT-HAND DRIVE

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

CLEANING

- □ Remove the cabin filter (see 61A, Heating, Cabin filter: Removal Refitting, page 61A-8).
- Apply the AIR CONDITIONING CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables - Products).
- Leave the product to work for **15 minutes**.
- □ Refit the cabin filter (see 61A, Heating, Cabin filter: Removal - Refitting, page 61A-8).
- □ Activate the low speed motor-driven fan assembly for **5 min**.



62A

RIGHT-HAND DRIVE

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

CLEANING

- Remove the evaporator sensor (see 62A, Air conditioning, Evaporator sensor: Removal - Refitting, page 62A-27).
- Apply the AIR CONDITIONING CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables - Products).
- Leave the product to work for **15 minutes**.
- Refit the evaporator sensor (see 62A, Air conditioning, Evaporator sensor: Removal - Refitting, page 62A-27).
- □ Activate the low speed motor-driven fan assembly for **5 min**.

Condenser - expansion valve connecting pipe: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

compressed air nozzle

Tightening torques \heartsuit

front right-hand side member tie rod bolts

105 N.m

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

Note:

Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.

REMOVAL

I - REMOVAL PREPARATION OPERATION

 Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (02A, Lifting equipment).

WARNING

Consult the device's operating manual to avoid incorrect use.

- □ Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining Filling).
- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).

Remove:

- the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
- the front section of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
- the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection),
- the right-hand headlight (see **Headlight: Removal** - **Refitting**) (80B, Headlights),
- the front panel support,
- the windscreen washer bottle (see **Windscreen washer reservoir: Removal - Refitting**) (85A, Wiping - Washing),
- the clips from the bulkhead heat shield.

WARNING


To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

□ Move the bulkhead heat shield to one side.

Condenser - expansion valve connecting pipe: Removal - Refitting


EXPORT EQUIPMENT LEVEL ADDITIONAL



Remove:


- the upper bolt (1) of the front right-hand side member tie rod,
- partially the lower bolt (2) of the front right-hand side member tie rod.
- □ Move the front right-hand side member tie rod towards the wheel arch.

II - REMOVAL OPERATION



62A


Remove the bolt (3) from the support of the "condenser - expansion valve" connecting pipe on the front right-hand panel.




Remove the plastic nut (4) from the support of the "condenser - expansion valve" connecting pipe on the front right-hand side member.

Condenser - expansion valve connecting pipe: Removal - Refitting


EXPORT EQUIPMENT LEVEL ADDITIONAL



□ Remove the bolt (5) from the "condenser - expansion valve" connecting pipe on the front panel.




Remove the bolt (6) from the support of the "condenser - expansion valve" connecting pipe on the front right-hand side member reinforcement.



140172

62A





□ Unclip the "condenser - expansion valve" connecting pipe at (7).

Condenser - expansion valve connecting pipe: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL





Remove:

- the bolt (8) from the bracket of the "condenser expansion valve" connecting pipe on the expansion valve,
- the bolt (9) from the bracket of the "condenser expansion valve" connecting pipe on the condenser.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

Disconnect:

- the "condenser expansion valve" connecting pipe on the expansion valve,
- the "condenser expansion valve" connecting pipe on the condenser.
- □ Fit blanking plugs on:
 - the condenser,
 - the expansion valve,
 - the "condenser expansion valve" connecting pipe.
- Remove the "condenser expansion valve" connecting pipe.

REFITTING

I - REFITTING PREPARATION OPERATION

WARNING

Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.



□ Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).

Condenser - expansion valve connecting pipe: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL



143882

- □ Use a **compressed air nozzle** to blow on the surface and the seal of the connecting pipe.
- □ Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- Remove the blanking plugs.

II - REFITTING OPERATION

- □ Proceed in the reverse order to removal.
- □ Tighten to torque the front right-hand side member tie rod bolts (105 N.m).

Note:

A summary table gives the quantities of refrigerant in the system according to the engine type (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- □ Perform the following operations:
 - refill the refrigerant circuit using the **refrigerant** charging station (see Refrigerant circuit: Draining Filling),
 - check for leaks (see Refrigerant circuit: Check) .
- □ Check that the air conditioning system is operating correctly (see **Air conditioning: Check**).
- Adjust the headlight beams (see Headlight: Adjustment) (80B, Headlights).

Expansion valve - intermediate pipe connecting pipe at the expansion valve outlet: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

compressed air nozzle

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

Note:


Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.

I - REMOVAL PREPARATION OPERATION

WARNING

Consult the device's operating manual to avoid incorrect use.

Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).



Remove the clips (1) from the bulkhead heat shield.


WARNING

To prevent the surrounding components from overheating, do not damage (tear, pierce, bend, etc.) a heat shield.

Any damaged heat shields must be replaced.

□ Move the bulkhead heat shieldto one side.

II - REMOVAL OPERATION




Remove the nut (2) from the retaining bracket (3) of the "expansion valve - intermediate pipe" connecting pipe.


Expansion valve - intermediate pipe connecting pipe at the expansion valve outlet: Removal - Refitting




EXPORT EQUIPMENT LEVEL ADDITIONAL



Remove the bolt (4) from the retaining bracket of the "expansion valve - intermediate pipe" connecting pipe.



Remove the bolt (5) from the bracket of the "expansion valve - intermediate pipe" connecting pipe on the expansion valve.



□ Remove the bolt (6) from the bracket of the "expansion valve - intermediate pipe" connecting pipe on the intermediate connecting pipe.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Disconnect:
 - the "expansion valve- intermediate pipe" connecting pipe from the expansion valve,
 - the "expansion valve intermediate pipe" connecting pipe from the intermediate connecting pipe.
- Remove the "expansion valve- intermediate pipe" connecting pipe.
- □ Fit the blanking plugs on the openings of the connecting pipes and on the expansion valve.

REFITTING

- I REFITTING PREPARATION OPERATION

WARNING


Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.

Expansion valve - intermediate pipe connecting pipe at the expansion valve outlet: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL



- 143880
- Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).



- □ Use a **compressed air nozzle** to blow on the surface and the seal of the connecting pipe.
- □ Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- □ Remove the blanking plugs.

II - REFITTING OPERATION

- Proceed in the reverse order to removal.

Note:

A summary table gives the quantities of refrigerant in the system according to the engine type (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- □ Fill up the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining Filling).
- □ Check for leaks (see Refrigerant circuit: Check).
- □ Check that the air conditioning system is operating correctly (see **Air conditioning: Check**).

AIR CONDITIONING Pressure sensor: Removal - Refitting



Tightening torques

pressure sensor

9 N.m

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).


Note:


An automatic shut-off valve isolates the circuit from the outside during removal; do not drain the refrigerant from the circuit.

REMOVAL

I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (02A, Lifting equipment).
- □ Remove:
 - the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
 - the front section of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
 - the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).






Unclip:

- the central deflector $\left(1\right)$,
- the right-hand side deflector $\left(2\right)$.



II - OPERATION FOR REMOVAL OF PART CONCERNED



- $\hfill\square$ Disconnect the pressure sensor connector (3) .
- $\hfill\square$ Remove the pressure sensor from the condenser.

REFITTING

I - REFITTING OPERATION FOR PART CONCERNED

- □ Refit the pressure sensor.
- □ Torque tighten the **pressure sensor (9 N.m)**.
- $\hfill\square$ Connect the pressure sensor connector.

II - FINAL OPERATION

- Clip:
 - the right-hand side deflector,
 - the central deflector.
- Refit:
 - the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection),
 - the front section of the front wheel arch liners (see **Front wheel arch liner: Removal Refitting**) (55A, Exterior protection),
 - the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres).

AIR CONDITIONING Evaporator sensor: Removal - Refitting




EXPORT EQUIPMENT LEVEL ADDITIONAL

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).


REMOVAL

I - REMOVAL PREPARATION OPERATION




□ Unclip the centre console side trim (1).

II - REMOVAL OPERATION



Unclip the evaporator sensor (2) by turning it a quarter of a turn anti-clockwise.



- □ Take the evaporator sensor out of its housing.
- Disconnect the evaporator sensor connector. (3)

REFITTING

Proceed in the reverse order to removal.

Compressor - condenser connecting pipe: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair:

- (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3),
- (see Basic rules of structural repair: Precautions for the repair) .

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

Note:

Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.

REMOVAL

I - REMOVAL PREPARATION OPERATION

- Position the vehicle on a two-post lift (see Vehicle: Towing and lifting) (02A, Lifting equipment).
- □ Remove the front engine cover.


WARNING

Consult the device's operating manual to avoid incorrect use.

- Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).
- Disconnect the battery (see Battery: Removal Refitting) (80A, Battery).

- Remove:
 - the front wheels (see **Wheel: Removal Refitting**) (35A, Wheels and tyres),
 - the front section of the front wheel arch liners (see **Front bumper: Removal Refitting**) (55A, Exterior protection),
 - the front bumper (see **Front bumper: Removal - Refitting**) (55A, Exterior protection).

II - REMOVAL OPERATION




 Remove the bolt (1) from the support of "compressor - condenser" connecting pipe on the front panel.


Compressor - condenser connecting pipe: Removal - Refitting



EXPORT EQUIPMENT LEVEL ADDITIONAL



Remove the bolt (2) from the bracket of the "compressor - condenser" connecting pipe on the compressor.



Remove the bolt (3) from the bracket of the "compressor - condenser" connecting pipe on the condenser.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

- Disconnect:
 - the "compressor condenser" connecting pipe on the compressor,
 - the "compressor condenser" connecting pipe on the condenser.
- Remove the "compressor condenser" connecting pipe.
- □ Fit blanking plugs on the openings:
 - of the condenser,
 - of the compressor,
 - of the "compressor condenser" connecting pipe.

Compressor - condenser connecting pipe: Removal - Refitting

EXPORT EQUIPMENT LEVEL ADDITIONAL


REFITTING

I - REFITTING PREPARATION OPERATION

WARNING


Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.



143880

Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) .



143882

- Use a compressed air gun to blow the surface and the seal of the connecting pipe.
- Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- Remove the blanking plugs.

II - REFITTING OPERATION

- □ Proceed in the reverse order to removal.

Note:

A summary table gives the quantities of refrigerant in the system according to the engine types (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- □ Perform the following operations:
 - fill the refrigerant circuit with refrigerant (see Refrigerant circuit: Draining - Filling),
 - a leak test (see Refrigerant circuit: Check) .
- Check that the air conditioning system is operating correctly (see Air conditioning: Check) .

Compressor - intermediate pipe connecting pipe: Removal - Refitting

EXPORT EQUIPMENT LEVEL ADDITIONAL

Equipment required

refrigerant charging station

compressed air nozzle

IMPORTANT

To avoid all risk of damage to the systems, apply the safety and cleanliness instructions and operation recommendations before carrying out any repair (see **Air conditioning: Precautions for the repair**).

WARNING

To prevent moisture from entering the system, place plugs on the cold loop components which are open to the air.

Note:

Use blanking plugs for the fuel circuits with part numbers **77 01 208 229** or **77 01 476 857** to plug any openings exposed to the open air. They must be clean. Do not use any which have already been used to plug a fuel circuit.


I - REMOVAL PREPARATION OPERATION

WARNING


Consult the device's operating manual to avoid incorrect use.

- Drain the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).
- Disconnect the battery (see Battery: Removal Refitting).

II - REMOVAL OPERATION



Remove the bolt (1) from the "intermediate pipe compressor" connecting pipe bracket on the compressor.



Remove the bolt (2) from the "intermediate pipe compressor" connecting pipe bracket on the intermediate pipe.

WARNING

In order to avoid any refrigerant leaks, do not damage (deform, twist, etc.) the pipe.

Compressor - intermediate pipe connecting pipe: Removal - Refitting



Disconnect:

- the "intermediate pipe compressor" connecting pipe from the compressor,
- the "intermediate pipe compressor" connecting pipe from the intermediate pipe.
- □ Remove the "intermediate pipe compressor" connecting pipe.
- □ Fit blanking plugs on the connecting pipe and on the compressor.


REFITTING

I - REFITTING PREPARATION OPERATION


WARNING

Do not remove the blanking plugs from each component until the last moment.

Also, do not remove the components from their packaging until they are to be fitted to the vehicle.



□ Clean the surface and seal of the pipe using EN-GINE CLEANER (see Vehicle: Parts and consumables for the repair) (04B, Consumables -Products).



143882

- Use a compressed air nozzle to blow on the surface and the seal of the connecting pipe.
- Lubricate the surface of the connecting pipe and the seal with air conditioning oil (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).
- Remove the blanking plugs.

II - REFITTING OPERATION

- □ Proceed in the reverse order to removal.

Note:

A summary table gives the quantities of refrigerant in the system according to the engine type (see 62A, Air conditioning, Air conditioning: Parts and consumables for the repair, page 62A-3).

- Connect the battery (see Battery: Removal Refitting).
- □ Fill up the refrigerant circuit using the refrigerant charging station (see Refrigerant circuit: Draining - Filling).
- Check for leaks (see **Refrigerant circuit: Check**).
- □ Check that the air conditioning system is operating correctly (see Air conditioning: Check) .