

Edition: May 2010

Publication No. SM1E-1Z62U0



All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, recording or otherwise, without the prior written permission of NISSAN MOTOR CO., LTD.

## QUICK REFERENCE INDEX

|  |   |
|--|---|
| <b>A GENERAL INFORMATION</b>                               | <b>GI General Information</b>                           |
| <b>B ENGINE</b>  | <b>EM Engine Mechanical</b>                             |
|  | <b>LU Engine Lubrication System</b>                     |
|  | <b>CO Engine Cooling System</b>                         |
|  | <b>EC Engine Control System</b>                         |
|  | <b>FL Fuel System</b>                                   |
|  | <b>EX Exhaust System</b>                                |
|  | <b>STR Starting System</b>                              |
|  | <b>ACC Accelerator Control System</b>                   |
| <b>C HYBRID</b>  |   |
|  |   |
|  |   |
| <b>D TRANSMISSION &amp; DRIVE-LINE</b>                     | <b>TM Transaxle &amp; Transmission</b>                  |
|  | <b>DLN Driveline</b>                                    |
|  | <b>FAX Front Axle</b>                                   |
|  | <b>RAX Rear Axle</b>                                    |
| <b>E SUSPENSION</b>  | <b>FSU Front Suspension</b>                             |
|  | <b>RSU Rear Suspension</b>                              |
|  | <b>SCS Suspension Control System</b>                    |
|  | <b>WT Road Wheels &amp; Tires</b>                       |
| <b>F BRAKES</b>  | <b>BR Brake System</b>                                  |
|  | <b>PB Parking Brake System</b>                          |
|  | <b>BRC Brake Control System</b>                         |
| <b>G STEERING</b>  | <b>ST Steering System</b>                               |
|  | <b>STC Steering Control System</b>                      |
| <b>H RESTRAINTS</b>  | <b>SB Seat Belt</b>                                     |
|  | <b>SBC Seat Belt Control System</b>                     |
|  | <b>SR SRS Airbag</b>                                    |
|  | <b>SRC SRS Airbag Control System</b>                    |
| <b>I VENTILATION, HEATER &amp; AIR CONDITIONER</b>         | <b>VTL Ventilation System</b>                           |
|  | <b>HA Heater &amp; Air Conditioning System</b>          |
|  | <b>HAC Heater &amp; Air Conditioning Control System</b> |
| <b>J BODY INTERIOR</b>                                     | <b>INT Interior</b>                                     |
|  | <b>IP Instrument Panel</b>                              |
|  | <b>SE Seat</b>  |
|  | <b>ADP Automatic Drive Positioner</b>                   |
| <b>K BODY EXTERIOR, DOORS, ROOF &amp; VEHICLE SECURITY</b> | <b>DLK Door &amp; Lock</b>                              |
|  | <b>SEC Security Control System</b>                      |
|  | <b>GW Glass &amp; Window System</b>                     |
|  | <b>PWC Power Window Control System</b>                  |
|  | <b>RF Roof</b>  |
|  |   |
|  | <b>EXT Exterior</b>                                     |
|  | <b>BRM Body Repair</b>                                  |
| <b>L DRIVER CONTROLS</b>                                   | <b>MIR Mirrors</b>                                      |
|  | <b>EXL Exterior Lighting System</b>                     |
|  | <b>INL Interior Lighting System</b>                     |
|  | <b>WW Wiper &amp; Washer</b>                            |
|  | <b>DEF Defogger</b>                                     |
|  | <b>HRN Horn</b>   |
| <b>M ELECTRICAL &amp; POWER CONTROL</b>                    | <b>PWO Power Outlet</b>                                 |
|  | <b>BCS Body Control System</b>                          |
|  | <b>LAN LAN System</b>                                   |
|  | <b>PCS Power Control System</b>                         |
|  | <b>CHG Charging System</b>                              |
|  | <b>PG Power Supply, Ground &amp; Circuit Elements</b>   |
| <b>N DRIVER INFORMATION &amp; MULTIMEDIA</b>               | <b>MWI Meter, Warning Lamp &amp; Indicator</b>          |
|  | <b>WCS Warning Chime System</b>                         |
|  |   |
|  | <b>AV Audio, Visual &amp; Navigation System</b>         |
| <b>O CRUISE CONTROL &amp; DRIVER ASSISTANCE</b>            | <b>CCS Cruise Control System</b>                        |
|  | <b>DAS Driver Assistance System</b>                     |
|  |   |
| <b>P MAINTENANCE</b>                                       | <b>MA Maintenance</b>                                   |

**A**

**B**

**D**

**E**

**F**

**G**

**H**

**I**

**J**

**K**

**L**

**M**

**N**

**O**

**P**

# FOREWORD

---

This manual contains maintenance and repair procedure for the 2011 INFINITI QX56.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

## IMPORTANT SAFETY NOTICE

---

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



INFINITI®

## QUICK REFERENCE CHART QX56

PFP:00000

## ENGINE TUNE-UP DATA (VK56VD)

ELS0003W

|  |                                    |  |
|--|------------------------------------|--|
| Engine model                             |                                    | VK56VD                                 |
| Firing order                             |                                    | 1-8-7-3-6-5-4-2                        |
| Idle speed<br>A/T (In "P or N" position) | rpm                                | 600 ± 50                               |
| Ignition timing<br>(BTDC at idle speed)  |                                    | 12° ± 2°                               |
| CO% at idle                              |                                    | 0.7 - 9.9 % and engine runs smoothly   |
| Tensions of drive belt                   |                                    | Auto adjustment by auto tensioner      |
| Radiator cap relief pressure             | kPa (kg/cm <sup>2</sup> , psi)     |  |
| Standard                                 |                                    | 108.2 - 127.8 (1.1 - 1.3, 15.7 - 18.5) |
| Limit                                    |                                    | 98 (1.0, 14)                           |
| Cooling system leakage testing pressure  | kPa (kg/cm <sup>2</sup> , psi)     | 186 (1.9, 27)                          |
| Compression pressure                     | kPa (kg/cm <sup>2</sup> , psi)/rpm |  |
| Standard                                 |                                    | 1,667 (17, 242)/200                    |
| Minimum                                  |                                    | 1,226 (12.5, 178)/200                  |
| Differential limit between cylinders     |                                    | 98 (1.0, 14)/200                       |
| Spark plug<br>(Iridium-tipped type)      | Make                               | NGK                                    |
|  | Standard type                      | DILKAR7B11                             |
|  | Gap (Standard)                     | 1.1 (0.043)                            |

## FRONT WHEEL ALIGNMENT

ELS0003X

| Item  |   | Standard                       |                                |
|---|---|--------------------------------|--------------------------------|
| Measurement wheel                                     |   | Left side                      | Right side                     |
| Camber<br>Degree minute (Decimal degree)              | Minimum   | −0°45' (−0.75°)                | −0°55' (−0.91°)                |
|   | Nominal   | 0° 00' (0.00°)                 | −0°10' (−0.17°)                |
|   | Maximum   | 0° 45' (0.75°)                 | 0° 35' (0.58°)                 |
|   | Left and right difference   | 0° 33' (0.55°) or less         |                                |
| Caster<br>Degree minute (Decimal degree)              | Minimum   | 2° 20' (2.34°)                 | 2° 40' (2.67°)                 |
|   | Nominal   | 3° 05' (3.08°)                 | 3° 25' (3.42°)                 |
|   | Maximum   | 3° 50' (3.83°)                 | 4° 10' (4.16°)                 |
|   | Left and right difference   | 0° 45' (0.75°) or less         |                                |
| Kingpin inclination<br>Degree minute (Decimal degree) | Minimum   | —                              | —                              |
|   | Nominal   | 13° 20' (13.33°)* <sup>1</sup> | 13° 25' (13.42°)* <sup>1</sup> |
|   | Maximum   | —                              | —                              |
| Toe-in  | Total toe-in<br>Distance  | Minimum                        | In 1.4 mm (0.055 in)           |
|   |   | Nominal                        | In 2.4 mm (0.094 in)           |
|   |   | Maximum                        | In 3.4 mm (0.134 in)           |
|   | Toe angle (left wheel or right wheel)<br>Degree minute (Decimal degree) | Minimum                        | In 0° 03' (0.05°)              |
|   |   | Nominal                        | In 0° 05' (0.08°)              |
|   |   | Maximum                        | In 0° 07' (0.11°)              |

\*1: The minimum value and maximum value is the same as the nominal value.

Measure value under unladen\*<sup>2</sup> conditions.

\*2: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

## REAR WHEEL ALIGNMENT

ELS0003Y

| Item                                     |   | Standard               |                      |
|--|---|------------------------|----------------------|
| Camber<br>Degree minute (Decimal degree) | Minimum   | −1° 00′ (−1.00°)       |                      |
|  | Nominal   | −0° 30′ (−0.50°)       |                      |
|  | Maximum   | 0° 00′ (0.00°)         |                      |
|  | Left and right difference   | 0° 45′ (0.75°) or less |                      |
| Toe-in                                   | Total toe-in<br>Distance  | Minimum                | 0 mm (0 in)          |
|  |   | Nominal                | In 3.4 mm (0.134 in) |
|  |   | Maximum                | In 6.8 mm (0.268 in) |
|  | Toe angle (left wheel or right wheel)<br>Degree minute (Decimal degree) | Minimum                | 0° 00′ (0.00°)       |
|  |   | Nominal                | In 0° 07′ (0.12°)    |
|  |   | Maximum                | In 0° 14′ (0.23°)    |

Measure value under unladen\* conditions.

\*: Fuel, engine coolant and lubricant are full. Spare tire, jack, hand tools and mats are in designated positions.

**BRAKE PEDAL**

Unit : mm (in)

| Item   | Standard                    |
|--|-----------------------------|
| Brake pedal height   | 168.5 (6.63) – 178.5 (7.03) |
| Depressed brake pedal height<br>[Depressing 490 N (50 kg, 110 lb) while turning the engine ON] | 100 (3.94) or more          |

**FRONT DISK BRAKE**

Unit : mm (in)

| Item       |   | Limit          |
|------------|---|----------------|
| Brake pad  | Wear thickness                                | 1.5 (0.059)    |
|            | Wear thickness                                | 28.5 (1.122)   |
| Disc rotor | Thickness variation (measured at 8 positions) | 0.015 (0.0006) |
|            | Runout (with it attached to the vehicle)      | 0.053 (0.0021) |

**REAR DISK BRAKE**

Unit : mm (in)

| Item       |   | Limit          |
|------------|---|----------------|
| Brake pad  | Wear thickness                                | 2.0 (0.079)    |
|            | Wear thickness                                | 18.0 (0.709)   |
| Disc rotor | Thickness variation (measured at 8 positions) | 0.015 (0.0006) |
|            | Runout (with it attached to the vehicle)      | 0.05 (0.0020)  |

**REFILL CAPACITIES**

ELS00040

| UNIT  |                           | Liter   | US measure |
|---|---------------------------|---------|------------|
| Fuel tank   |                           | 98.4    | 26 gal     |
| Engine Coolant ( With reservoir tank ) at MAX level |                           | 14.9    | 15-6/8 qt  |
| Engine oil  | Drain and refill          |         |            |
|   | With oil filter change    | 6.5     | 6-7/8 qt   |
|   | Without oil filter change | 6.2     | 6-4/8 qt   |
|   | Dry engine (Overhaul)     | 7.6     | 8 qt       |
| Transmission  |                           | 10.0    | 10-5/8 qt  |
| Transfer  |                           | 1.5     | 3-1/8 pt   |
| Final drive   | Front                     | 0.75    | 1-5/8 pt   |
|   | Rear                      | 1.75    | 3-3/4 pt   |
| Power steering system                               |                           | 1.0     | 7/8 qt     |
| Air conditioning system                             | Compressor oil            | 0.21    | 7.1 fl oz  |
|   | Refrigerant               | 1.05 kg | 2.32 lb    |

## SECTION

# GI

## GENERAL INFORMATION

### CONTENTS

|  |           |  |           |
|--|-----------|--|-----------|
| <b>HOW TO USE THIS MANUAL .....</b>                        | <b>3</b>  | <b>PRECAUTION .....</b>  | <b>26</b> |
| <b>HOW TO USE THIS MANUAL .....</b>                        | <b>3</b>  | <b>PRECAUTIONS .....</b>   | <b>26</b> |
| Description .....  | 3         | Description .....  | 26        |
| Terms .....  | 3         | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 26        |
| Units .....  | 3         | Precautions For Xenon Headlamp Service .....   | 26        |
| Contents .....   | 3         | Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....                  | 27        |
| Relation between Illustrations and Descriptions .....      | 4         | Precaution for Procedure without Cowl Top Cover .....  | 27        |
| Components .....   | 4         | General Precautions .....  | 27        |
| <b>HOW TO FOLLOW TROUBLE DIAGNOSES.....</b>                | <b>6</b>  | Three Way Catalyst .....   | 29        |
| Description .....  | 6         | Multiport Fuel Injection System or Engine Control System .....                                   | 29        |
| How to Follow Test Groups in Trouble Diagnosis.....        | 6         | Hoses .....  | 29        |
| Key to Symbols Signifying Measurements or Procedures ..... | 7         | Engine Oils .....  | 30        |
| <b>HOW TO READ WIRING DIAGRAMS .....</b>                   | <b>9</b>  | Air Conditioning .....   | 31        |
| Connector Symbols .....                                    | 9         | Fuel .....   | 31        |
| Sample/Wiring Diagram -Example- .....                      | 10        | <b>LIFTING POINT .....</b>   | <b>32</b> |
| Connector Information .....                                | 12        | Pantograph Jack .....  | 32        |
| <b>ABBREVIATIONS .....</b>                                 | <b>14</b> | Garage Jack and Safety Stand .....   | 32        |
| Abbreviation List .....                                    | 14        | 2-Pole Lift .....  | 33        |
| <b>TIGHTENING TORQUE OF STANDARD BOLTS .....</b>           | <b>19</b> | <b>TOW TRUCK TOWING .....</b>  | <b>34</b> |
| Description .....  | 19        | Tow Truck Towing .....   | 34        |
| Tightening Torque Table (New Standard Included) .....      | 19        | Vehicle Recovery (Freeing a Stuck Vehicle) .....   | 34        |
| <b>RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS .....</b>    | <b>22</b> | <b>BASIC INSPECTION .....</b>  | <b>36</b> |
| Recommended Chemical Products and Sealants...22            |           | <b>SERVICE INFORMATION FOR ELECTRICAL INCIDENT .....</b>   | <b>36</b> |
| <b>VEHICLE INFORMATION .....</b>                           | <b>23</b> | Work Flow .....  | 36        |
| <b>IDENTIFICATION INFORMATION .....</b>                    | <b>23</b> | Control Units and Electrical Parts .....   | 36        |
| Model Variation .....                                      | 23        | How to Check Terminal .....  | 37        |
| Information About Identification or Model Code .....       | 23        | Intermittent Incident .....  | 40        |
| Dimensions .....   | 25        | Circuit Inspection .....   | 43        |
| Wheels & Tires .....                                       | 25        | <b>CONSULT-III/GST CHECKING SYSTEM .....</b>   | <b>48</b> |
|  |           | Description .....  | 48        |
|  |           | CONSULT-III Function and System Application*1....48  |           |

---

|   |           |
|---|-----------|
| CONSULT-III/GST Data Link Connector (DLC) |           |
| Circuit .....                             | 50        |
| Wiring Diagram - CONSULT-III/GST CHECKING |           |
| SYSTEM - .....                            | 51        |
| <b>INSPECTION AND ADJUSTMENT .....</b>    | <b>65</b> |

---

|   |           |
|---|-----------|
| <b>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL .....</b> | <b>65</b> |
| ADDITIONAL SERVICE WHEN REMOVING  |           |
| BATTERY NEGATIVE TERMINAL : Required                                    |           |
| Procedure After Battery Disconnection .....                             | 65        |

# HOW TO USE THIS MANUAL

< HOW TO USE THIS MANUAL >

## HOW TO USE THIS MANUAL

### HOW TO USE THIS MANUAL

#### Description

INFOID:000000006280835

This volume explains “Removal, Disassembly, Installation, Inspection and Adjustment” and “Trouble Diagnoses”.

#### Terms

INFOID:000000006280836

- The captions **WARNING** and **CAUTION** warn you of steps that must be followed to prevent personal injury and/or damage to some part of the vehicle.

**WARNING** indicates the possibility of personal injury if instructions are not followed.

**CAUTION** indicates the possibility of component damage if instructions are not followed.

**BOLD TYPED STATEMENTS** except **WARNING** and **CAUTION** give you helpful information.

Standard value: Tolerance at inspection and adjustment.

Limit value: The maximum or minimum limit value that should not be exceeded at inspection and adjustment.

#### Units

INFOID:000000006280837

- The **UNITS** given in this manual are primarily expressed as the SI UNIT (International System of Unit), and alternatively expressed in the metric system and in the yard/pound system.  
Also with regard to tightening torque of bolts and nuts, there are descriptions both about range and about the standard tightening torque.

##### “Example”

##### Range

**Outer Socket Lock Nut : 59 - 78 N-m (6.0 - 8.0 kg-m, 43 - 58 ft-lb)**

##### Standard

**Drive Shaft Installation Bolt : 44.3 N-m (4.5 kg-m, 33 ft-lb)**

#### Contents

INFOID:000000006280838

- A **QUICK REFERENCE INDEX**, a black tab (e.g. **BR**) is provided on the first page. You can quickly find the first page of each section by matching it to the section's black tab.
- THE CONTENTS** are listed on the first page of each section.
- THE TITLE** is indicated on the upper portion of each page and shows the part or system.
- THE PAGE NUMBER** of each section consists of two or three letters which designate the particular section and a number (e.g. “BR-5”).
- THE SMALL ILLUSTRATIONS** show the important steps such as inspection, use of special tools, knacks of work and hidden or tricky steps which are not shown in the previous large illustrations.  
Assembly, inspection and adjustment procedures for the complicated units such as the automatic transaxle or transmission, etc. are presented in a step-by-step format where necessary.




# HOW TO USE THIS MANUAL

## < HOW TO USE THIS MANUAL >

### Relation between Illustrations and Descriptions

INFOID:000000006280839

The following sample explains the relationship between the part description in an illustration, the part name in the text and the service procedures.



## Components

INFOID:000000006280840


- **THE LARGE ILLUSTRATIONS** are exploded views (see the following) and contain tightening torques, lubrication points, section number of the **PARTS CATALOG** (e.g. SEC. 440) and other information necessary to perform repairs.

The illustrations should be used in reference to service matters only. When ordering parts, refer to the appropriate **PARTS CATALOG**.

Components shown in an illustration may be identified by a circled number. When this style of illustration is used, the text description of the components will follow the illustration.

# HOW TO USE THIS MANUAL

< HOW TO USE THIS MANUAL >



- |                   |                      |                                 |
|-------------------|----------------------|---------------------------------|
| 1. Union bolt     | 2. Copper washer     | 3. Brake hose                   |
| 4. Cap            | 5. Bleed valve       | 6. Sliding pin bolt             |
| 7. Piston seal    | 8. Piston            | 9. Piston boot                  |
| 10. Cylinder body | 11. Sliding pin      | 12. Torque member mounting bolt |
| 13. Washer        | 14. Sliding pin boot | 15. Bushing                     |
| 16. Torque member | 17. Inner shim cover | 18. Inner shim                  |
| 19. Inner pad     | 20. Pad retainer     | 21. Pad wear sensor             |
| 22. Outer pad     | 23. Outer shim       | 24. Outer shim cover            |
- 1: PBC (Poly Butyl Cuprysil) grease or silicone-based grease
 2: Rubber grease
 : Brake fluid

Refer to GI section for additional symbol definitions.

## SYMBOLS

| SYMBOL | DESCRIPTION   |                     | SYMBOL | DESCRIPTION                             |
|--------|---|---------------------|--------|---|
|        | Tightening torque<br>The tightening torque specifications of bolts and nuts may be presented as either a range or a standard tightening torque. | : N•m (kg-m, ft-lb) |        | Always replace after every disassembly. |
|        |   | : N•m (kg-m, in-lb) |        | Apply petroleum jelly.                  |
|        | Should be lubricated with grease. Unless otherwise indicated, use recommended multi-purpose grease.   |                     |        | Apply molybdenum added petroleum jelly. |
|        | Should be lubricated with oil.  |                     |        | Apply ATF.                              |
|        | Sealing point   |                     |        | Select with proper thickness.           |
|        | Sealing point with locking sealant.   |                     |        | Adjustment is required.                 |
|        | Checking point  |                     |        |   |

SAIA0749E

# HOW TO FOLLOW TROUBLE DIAGNOSES

< HOW TO USE THIS MANUAL >

## HOW TO FOLLOW TROUBLE DIAGNOSES

### Description

INFOID:000000006280841

#### NOTICE:

Trouble diagnoses indicate work procedures required to diagnose problems effectively. Observe the following instructions before diagnosing.


- Before performing trouble diagnoses, read the “Work Flow” in each section.
- After repairs, re-check that the problem has been completely eliminated.
- Refer to Component Parts and Harness Connector Location for the Systems described in each section for identification/location of components and harness connectors.
- When checking circuit continuity, ignition switch should be OFF.
- Refer to the Circuit Diagram for quick pinpoint check.

If you need to check circuit continuity between harness connectors in more detail, such as when a sub-harness is used, refer to Wiring Diagram in each individual section and Harness Layout in PG section for identification of harness connectors.

- Before checking voltage at connectors, check battery voltage.
- After accomplishing the Diagnosis Procedures and Electrical Components Inspection, check that all harness connectors are reconnected as they were.

### How to Follow Test Groups in Trouble Diagnosis

INFOID:000000006280842



JPAIA0021GB

1. Test group number and test group title
  - Test group number and test group title are shown in the upper portion of each test group.
2. Work and diagnosis procedure
  - Start to diagnose a problem using procedures indicated in enclosed test groups.
3. Questions and results
  - Questions and required results are indicated in test group.
4. Action
  - Next action for each test group is indicated based on result of each question.

# HOW TO FOLLOW TROUBLE DIAGNOSES

< HOW TO USE THIS MANUAL >

## Key to Symbols Signifying Measurements or Procedures

INFOID:000000006280843

| SYMBOL | DESCRIPTION   | SYMBOL | DESCRIPTION   |
|--------|---|--------|---|
|        | Check after disconnecting the connector to be measured. |        | Procedure with Generic Scan Tool. (GST, OBD-II scan tool)             |
|        | Check after connecting the connector to be measured.    |        | Procedure without CONSULT-II, CONSULT-III or GST                      |
|        | Insert key into ignition switch.                        |        | A/C switch is "OFF".  |
|        | Remove key from ignition switch.                        |        | A/C switch is "ON".   |
|        | Insert and remove key repeatedly.                       |        | REC switch is "ON".   |
|        | Turn ignition switch to "OFF" position.                 |        | REC switch is "OFF".  |
|        | Turn ignition switch to "ACC" position.                 |        | Fan switch is "ON".<br>(At any position except for "OFF" position)    |
|        | Turn ignition switch to "ON" position.                  |        | Fan switch is "OFF".  |
|        | Turn ignition switch to "START" position.               |        | Apply fuse.   |
|        | Turn ignition switch from "OFF" to "ACC" position.      |        | Apply positive voltage from battery with fuse directly to components. |
|        | Turn ignition switch from "ACC" to "ON" position.       |        |   |
|        | Turn ignition switch from "ACC" to "OFF" position.      |        |   |

JPAIA0397GB

GI

B

C

D

E

F

G

H

I

J

K

L

M






























N

O

P

# HOW TO FOLLOW TROUBLE DIAGNOSES

## < HOW TO USE THIS MANUAL >

| SYMBOL  | DESCRIPTION   | SYMBOL  | DESCRIPTION  |
|---|---|---|--|
|    | Turn ignition switch from "OFF" to "ON" position.       |    | Drive vehicle.   |
|    | Turn ignition switch from "ON" to "OFF" position.       |   |  |
|    | Do not start engine, or check with engine stopped.      |    | Disconnect battery negative cable.   |
|    | Start engine, or check with engine running.             |    | Depress brake pedal.   |
|    | Apply parking brake.                                    |    | Release brake pedal.   |
|    | Release parking brake.                                  |    | Depress accelerator pedal.   |
|    | Release accelerator pedal.                              |    | Release accelerator pedal.   |
|    | Check after engine is warmed up sufficiently.           | <br> | Pin terminal check for SMJ type ECM or TCM connectors.<br><b>For details regarding the terminal arrangement, refer to the "ELECTRICAL UNITS" electrical reference page at the end of the manual.</b> |
|    | Voltage should be measured with a voltmeter.            |   |  |
|    | Circuit resistance should be measured with an ohmmeter. |   |  |
|    | Current should be measured with an ammeter.             |   |  |
|  | Pulse signal should be checked with an oscilloscope.    |   |  |
|  | Procedure with CONSULT-III                              |   |  |
|  | Procedure without CONSULT-III                           |   |  |
|  | Place selector lever in "P" position.                   |   |  |
|  | Place selector lever in "N" position.                   |   |  |
|  | Jack up front portion.                                  |   |  |
|  | Jack up rear portion.                                   |   |  |
|  | Inspect under engine room.                              |   |  |
|  | Inspect under floor.                                    |   |  |
|  | Inspect rear under floor.                               |   |  |

JPAIA0398GB

# HOW TO READ WIRING DIAGRAMS

< HOW TO USE THIS MANUAL >


## HOW TO READ WIRING DIAGRAMS

### Connector Symbols


INFOID:000000006282193

Most of connector symbols in wiring diagrams are shown from the terminal side.

- Connector symbols shown from the terminal side are enclosed by a single line and followed by the direction mark.
- Connector symbols shown from the harness side are enclosed by a double line and followed by the direction mark.
- Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector. For description and how to disconnect, refer to PG section, "Description", "HARNESS CONNECTOR".



- Male and female terminals  
Connector guides for male terminals are shown in black and female terminals in white in wiring diagrams.




# HOW TO READ WIRING DIAGRAMS

< HOW TO USE THIS MANUAL >

## Sample/Wiring Diagram -Example-

INFOID:000000006282194

Each section includes wiring diagrams.



Description

| Number | Item                                | Description   |
|--------|-------------------------------------|---|
| 1      | Power supply                        | • This means the power supply of fusible link or fuse.  |
| 2      | Fuse                                | • "f" means the fuse.   |
| 3      | Current rating of fusible link/fuse | • This means the current rating of the fusible link or fuse.  |
| 4      | Number of fusible link/fuse         | • This means the number of fusible link or fuse location.   |
| 5      | Fusible link                        | • "X" means the fusible link.   |
| 6      | Connector number                    | • Alphabetic characters show to which harness the connector is placed.<br>• Numeric characters show the identification number of connectors.  |
| 7      | Switch                              | • This shows that continuity exists between terminals 1 and 2 when the switch is in the A position. Continuity exists between terminals 1 and 3 when the switch is in the B position. |
| 8      | Circuit (Wiring)                    | • This means the wiring.  |

# HOW TO READ WIRING DIAGRAMS

## < HOW TO USE THIS MANUAL >


| Number | Item                            | Description   |
|--------|---------------------------------|---|
| 9      | Shielded line                   | • The line enclosed by broken line circle shows shield wire.                          |
| 10     | Connectors                      | • This means that a transmission line bypasses two connectors or more.                |
| 11     | Option abbreviation             | • This means the vehicle specifications which layouts the circuit between "O".        |
| 12     | Relay                           | • This shows an internal representation of the relay.                                 |
| 13     | Optional splice                 | • The open circle shows that the splice is optional depending on vehicle application. |
| 14     | Splice                          | • The shaded circle "●" means the splice.   |
| 15     | System branch                   | • This shows that the circuit is branched to other systems.                           |
| 16     | Page crossing                   | • This circuit continues to an adjacent page.   |
| 17     | Component name                  | • This shows the name of a component.   |
| 18     | Terminal number                 | • This means the terminal number of a connector.                                      |
| 19     | Ground (GND)                    | • This shows the ground connection.   |
| 20     | Explation of option description | • This shows a explanation of the option abbreviation used on the same page.          |

## SWITCH POSITIONS

Switches are shown in wiring diagrams as if the vehicle is in the "normal" condition.

A vehicle is in the "normal" condition when:

- ignition switch is "OFF",
- doors, hood and trunk lid/back door are closed,
- pedals are not depressed, and
- parking brake is released.



## MULTIPLE SWITCH

The continuity of multiple switch is described in two ways as shown below.

- The switch chart is used in schematic diagrams.



# HOW TO READ WIRING DIAGRAMS

## < HOW TO USE THIS MANUAL >

- The switch diagram is used in wiring diagrams.

**Example**

(SWITCH CHART)

|   | OFF | INT | LO | HI | WASH |
|---|-----|-----|----|----|------|
| 1 |     |     |    |    | ○    |
| 2 |     |     |    | ○  |      |
| 3 | ○   | ○   | ○  |    |      |
| 4 | ○   | ○   |    |    |      |
| 5 |     | ○   |    |    |      |
| 6 |     | ○   | ○  | ○  | ○    |

(SWITCH DIAGRAM)

Both switches are turned in combination.

Continuity circuit of wiper switch

| SWITCH POSITION | CONTINUITY CIRCUIT |
|-----------------|--------------------|
| OFF             | 3 - 4              |
| INT             | 3 - 4, 5 - 6       |
| LO              | 3 - 6              |
| HI              | 2 - 6              |
| WASH            | 1 - 6              |

JSAIA0017GB

## Connector Information

INFOID:000000006282195

① Connector No. M3

② Connector Name UNIT

③ Connector Type NS06FW-M2

H.S.

④

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | W             | BAT                         |
| 2            | G             | SWITCH B                    |
| 4            | V             | SWITCH A                    |
| 5            | L             | CAN-H                       |
| 6            | P             | CAN-L                       |

⑤

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 9            | B             | GND                         |
| 10           | B             | GND                         |

JCAWA0152GB

## Description

| Number | Item             | Description  |
|--------|------------------|--|
| 1      | Connector number | <ul style="list-style-type: none"> <li>Alphabetic characters show to which harness the connector is placed.</li> <li>Numeric characters show the identification number of connectors.</li> </ul> |
| 2      | Connector type   | <ul style="list-style-type: none"> <li>This means the connector number. Refer to <a href="#">PG-144, "How To Read Harness Layout"</a>.</li> </ul>  |
| 3      | Terminal number  | <ul style="list-style-type: none"> <li>This means the terminal number of a connector.</li> </ul>   |

# HOW TO READ WIRING DIAGRAMS

## < HOW TO USE THIS MANUAL >

| Number  | Item                      | Description  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
|---|---------------------------|--|------------|------------|-----------|------------------|---------|----------|-----------|---------------------------|----------|-----------------|------------|---------------|------------------|-----------------|------------|-----------------|
| 4   | Wire color                | <ul style="list-style-type: none"><li>This shows a code for the color of the wire.</li></ul>   |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
|   |                           | <table><tr><td>B = Black</td><td>BR = Brown</td></tr><tr><td>W = White</td><td>OR or O = Orange</td></tr><tr><td>R = Red</td><td>P = Pink</td></tr><tr><td>G = Green</td><td>PU or V (Violet) = Purple</td></tr><tr><td>L = Blue</td><td>GY or GR = Gray</td></tr><tr><td>Y = Yellow</td><td>SB = Sky Blue</td></tr><tr><td>LG = Light Green</td><td>CH = Dark Brown</td></tr><tr><td>BG = Beige</td><td>DG = Dark Green</td></tr></table> | B = Black  | BR = Brown | W = White | OR or O = Orange | R = Red | P = Pink | G = Green | PU or V (Violet) = Purple | L = Blue | GY or GR = Gray | Y = Yellow | SB = Sky Blue | LG = Light Green | CH = Dark Brown | BG = Beige | DG = Dark Green |
|   |                           | B = Black  | BR = Brown |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| W = White   | OR or O = Orange          |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| R = Red   | P = Pink                  |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| G = Green   | PU or V (Violet) = Purple |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| L = Blue  | GY or GR = Gray           |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| Y = Yellow  | SB = Sky Blue             |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| LG = Light Green  | CH = Dark Brown           |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| BG = Beige  | DG = Dark Green           |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| <ul style="list-style-type: none"><li>When the wire color is striped, the base color is given first, followed by the stripe color as shown below:<br/>Example: L/W = Blue with White Stripe</li></ul> |                           |  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |
| 5   | Connector                 | <ul style="list-style-type: none"><li>This means the connector information.</li><li>This unit-side is described by the connector symbols.</li></ul>  |            |            |           |                  |         |          |           |                           |          |                 |            |               |                  |                 |            |                 |

GI

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# ABBREVIATIONS

< HOW TO USE THIS MANUAL >

## ABBREVIATIONS

### Abbreviation List

INFOID:000000006280882

The following **ABBREVIATIONS** are used:

| A            |                                  |
|--------------|----------------------------------|
| ABBREVIATION | DESCRIPTION                      |
| A/C          | Air conditioner                  |
| A/C          | Air conditioning                 |
| A/F sensor   | Air fuel ratio sensor            |
| A/T          | Automatic transaxle/transmission |
| ABS          | Anti-lock braking system         |
| ACCS         | Advance climate control system   |
| ACL          | Air cleaner                      |
| AP           | Accelerator pedal                |
| APP          | Accelerator pedal position       |
| ATF          | Automatic transmission fluid     |
| AV           | Audio visual                     |
| AWD          | All wheel drive                  |

| B            |                                 |
|--------------|---------------------------------|
| ABBREVIATION | DESCRIPTION                     |
| BARO         | Barometric pressure             |
| BCM          | Body control module             |
| BLSD         | Brake limited slip differential |
| BPP          | Brake pedal position            |
| BSI          | Blind spot intervention         |
| BSW          | Blind spot warning              |

| C            |  |
|--------------|--|
| ABBREVIATION | DESCRIPTION                                  |
| CKP          | Crankshaft position                          |
| CL           | Closed loop                                  |
| CMP          | Camshaft position                            |
| CPP          | Clutch pedal position                        |
| CTP          | Closed throttle position                     |
| CVT          | Continuously Variable transaxle/transmission |

| D            |                              |
|--------------|------------------------------|
| ABBREVIATION | DESCRIPTION                  |
| D1           | Drive range first gear       |
| D2           | Drive range second gear      |
| D3           | Drive range third gear       |
| D4           | Drive range fourth gear      |
| DCA          | Distance control assist      |
| DFI          | Direct fuel injection system |
| DLC          | Data link connector          |
| DTC          | Diagnostic trouble code      |

# ABBREVIATIONS

## < HOW TO USE THIS MANUAL >

| E             |   | GI |
|---------------|---|----|
| ABBREVIATION  | DESCRIPTION   |    |
| E/T           | Exhaust temperature                                 |    |
| EBD           | Electric brake force distribution                   |    |
| EC            | Engine control                                      |    |
| ECL           | Engine coolant level                                |    |
| ECM           | Engine control module                               |    |
| ECT           | Engine coolant temperature                          |    |
| ECV           | Electrical control valve                            |    |
| EEPROM        | Electrically erasable programmable read only memory |    |
| EFT           | Engine fuel temperature                             |    |
| EGR           | Exhaust gas recirculation                           |    |
| EGRT          | Exhaust gas recirculation temperature               |    |
| EGT           | Exhaust gas temperature                             |    |
| EOP           | Engine oil pressure                                 |    |
| EP            | Exhaust pressure                                    |    |
| EPR           | Exhaust pressure regulator                          | B  |
| EPS           | Electronically controlled power steering            |    |
| ESP           | Electronic stability program system                 | C  |
| EVAP canister | Evaporative emission canister                       |    |
| EXC           | Exhaust control                                     | D  |

| F            |                           | E |
|--------------|---------------------------|---|
| ABBREVIATION | DESCRIPTION               |   |
| FC           | Fan control               |   |
| FCW          | Forward collision warning |   |
| FIC          | Fuel injector control     |   |
| FP           | Fuel pump                 |   |
| FR           | Front                     |   |
| FRP          | Fuel rail pressure        |   |
| FRT          | Fuel rail temperature     |   |
| FTP          | Fuel tank pressure        |   |
| FTT          | Fuel tank temperature     |   |

| G            |                           | F |
|--------------|---------------------------|---|
| ABBREVIATION | DESCRIPTION               |   |
| GND          | Ground                    |   |
| GPS          | Global positioning system |   |
| GST          | Generic scan tool         |   |

| H            |                                      | G |
|--------------|--------------------------------------|---|
| ABBREVIATION | DESCRIPTION                          |   |
| HBMC         | Hydraulic body-motion control system |   |
| HDD          | Hard disk drive                      |   |
| HO2S         | Heated oxygen sensor                 |   |
| HOC          | Heated oxidation catalyst            |   |

# ABBREVIATIONS

## < HOW TO USE THIS MANUAL >

| I            |   |
|--------------|---|
| ABBREVIATION | DESCRIPTION                                       |
| I/M          | Inspection and maintenance                        |
| IA           | Intake air  |
| IAC          | Idle air control                                  |
| IAT          | Intake air temperature                            |
| IBA          | Intelligent brake assist                          |
| IC           | Ignition control                                  |
| ICC          | Intelligent cruise control                        |
| ICM          | Ignition control module                           |
| IPDM E/R     | Intelligent power distribution module engine room |
| ISC          | Idle speed control                                |
| ISS          | Input shaft speed                                 |

| K            |              |
|--------------|--------------|
| ABBREVIATION | DESCRIPTION  |
| KS           | Knock sensor |

| L            |                            |
|--------------|----------------------------|
| ABBREVIATION | DESCRIPTION                |
| LCD          | Liquid crystal display     |
| LCU          | Local control unit         |
| LDP          | Lane departure prevention  |
| LDW          | Lane departure warning     |
| LED          | Light emitting diode       |
| LH           | Left-hand                  |
| LIN          | Local interconnect network |

| M            |                               |
|--------------|-------------------------------|
| ABBREVIATION | DESCRIPTION                   |
| M/T          | Manual transaxle/transmission |
| MAF          | Mass airflow                  |
| MAP          | Manifold absolute pressure    |
| MI           | Malfunction indicator         |
| MIL          | Malfunction indicator lamp    |

| N            |                 |
|--------------|-----------------|
| ABBREVIATION | DESCRIPTION     |
| NOX          | Nitrogen oxides |

| O            |                               |
|--------------|-------------------------------|
| ABBREVIATION | DESCRIPTION                   |
| O2           | Oxygen                        |
| O2S          | Oxygen sensor                 |
| OBD          | On board diagnostic           |
| OC           | Oxidation catalytic converter |
| OD           | Overdrive                     |
| OL           | Open loop                     |
| OSS          | Output shaft speed            |

# ABBREVIATIONS

## < HOW TO USE THIS MANUAL >

| P            |                                  | GI |
|--------------|----------------------------------|----|
| ABBREVIATION | DESCRIPTION                      |    |
| P/S          | Power steering                   |    |
| PBR          | Potential balance resistor       |    |
| PCV          | Positive crankcase ventilation   |    |
| PNP          | Park/Neutral position            |    |
| PSP          | Power steering pressure          |    |
| PTC          | Positive temperature coefficient |    |
| PTO          | Power takeoff                    |    |
| PWM          | Pulse width modulation           |    |

| R            |                      | B |
|--------------|----------------------|---|
| ABBREVIATION | DESCRIPTION          |   |
| RAM          | Random access memory |   |
| RAS          | Rear active steer    |   |
| RH           | Right-hand           |   |
| ROM          | Read only memory     |   |
| RPM          | Engine speed         |   |
| RR           | Rear                 |   |

| S            |                                       | C |
|--------------|---------------------------------------|---|
| ABBREVIATION | DESCRIPTION                           |   |
| SAE          | Society of Automotive Engineers, Inc. |   |
| SCK          | Serial clock                          |   |
| SDS          | Service Data and Specifications       |   |
| SRT          | System readiness test                 |   |
| SST          | Special Service Tools                 |   |

| T            |                                 | D |
|--------------|---------------------------------|---|
| ABBREVIATION | DESCRIPTION                     |   |
| TC           | Turbocharger                    |   |
| TCM          | Transmission control module     |   |
| TCS          | Traction control system         |   |
| TP           | Throttle position               |   |
| TPMS         | Tire pressure monitoring system |   |
| TSS          | Turbine shaft speed             |   |
| TWC          | Three way catalytic converter   |   |

| V            |                                 | D |
|--------------|---------------------------------|---|
| ABBREVIATION | DESCRIPTION                     |   |
| VDC          | Vehicle dynamics control system |   |
| VIN          | Vehicle identification number   |   |
| VSS          | Vehicle speed sensor            |   |

| W            |                    | P |
|--------------|--------------------|---|
| ABBREVIATION | DESCRIPTION        |   |
| WOT          | Wide open throttle | P |

| 1            |                      | P |
|--------------|----------------------|---|
| ABBREVIATION | DESCRIPTION          |   |
| 11           | 1st range first gear | P |

## ABBREVIATIONS

### < HOW TO USE THIS MANUAL >

| ABBREVIATION | DESCRIPTION           |
|--------------|-----------------------|
| 12           | 1st range second gear |
| 1GR          | First gear            |

| 2            |                       |
|--------------|-----------------------|
| ABBREVIATION | DESCRIPTION           |
| 21           | 2nd range first gear  |
| 22           | 2nd range second gear |
| 2GR          | Second gear           |
| 2WD          | 2-Wheel Drive         |

| 3            |             |
|--------------|-------------|
| ABBREVIATION | DESCRIPTION |
| 3GR          | Third gear  |

| 4            |                         |
|--------------|-------------------------|
| ABBREVIATION | DESCRIPTION             |
| 4GR          | Fourth gear             |
| 4WAS         | Four wheel active steer |
| 4WD          | Four wheel drive        |

| 5            |             |
|--------------|-------------|
| ABBREVIATION | DESCRIPTION |
| 5GR          | Fifth gear  |

| 6            |             |
|--------------|-------------|
| ABBREVIATION | DESCRIPTION |
| 6GR          | Sixth gear  |

| 7            |              |
|--------------|--------------|
| ABBREVIATION | DESCRIPTION  |
| 7GR          | Seventh gear |

# TIGHTENING TORQUE OF STANDARD BOLTS

< HOW TO USE THIS MANUAL >

## TIGHTENING TORQUE OF STANDARD BOLTS

GI

### Description

INFOID:000000006280848

This vehicle has both new standard based on ISO\* and previous standard bolts/nuts. There are some differences between these two types of bolts/ nuts; shape of the head, grade of strength, hexagonal width across flats and the standard tightening torque.

- For guidance in discriminating, refer to [GI-19, "Tightening Torque Table \(New Standard Included\)"](#).
- The new standard machine screws and tapping screws have a head of ISO standard torx recess.
- If the tightening torque is not described in the description or figure, refer to [GI-19, "Tightening Torque Table \(New Standard Included\)"](#).

\*ISO: International Organization for Standardization

### Tightening Torque Table (New Standard Included)

INFOID:000000006280849

#### CAUTION:

- The special parts are excluded.
- The bolts/nuts in these tables have a strength (discrimination) number/symbol assigned to the head or the like. As to the relation between the strength grade in these tables and the strength (discrimination) number/symbol, refer to "DISCRIMINATION OF BOLTS AND NUTS".

### PREVIOUS STANDARD

| Grade<br>(Strength<br>grade) | Bolt<br>size | Bolt di-<br>ameter<br>mm | Hexagonal<br>width<br>across flats<br>mm | Pitch<br>mm | Tightening torque (Without lubricant) |      |       |       |                     |      |       |       |
|------------------------------|--------------|--------------------------|--|-------------|---------------------------------------|------|-------|-------|---------------------|------|-------|-------|
|                              |              |                          |  |             | Hexagon head bolt                     |      |       |       | Hexagon flange bolt |      |       |       |
|                              |              |                          |  |             | N-m                                   | kg-m | ft-lb | in-lb | N-m                 | kg-m | ft-lb | in-lb |
| 4T                           | M6           | 6.0                      | 10                                       | 1.0         | 5.5                                   | 0.56 | 4     | 49    | 7                   | 0.71 | 5     | 62    |
|                              | M8           | 8.0                      | 12                                       | 1.25        | 13.5                                  | 1.4  | 10    | —     | 17                  | 1.7  | 13    | —     |
|                              |              |                          |  | 1.0         | 13.5                                  | 1.4  | 10    | —     | 17                  | 1.7  | 13    | —     |
|                              | M10          | 10.0                     | 14                                       | 1.5         | 28                                    | 2.9  | 21    | —     | 35                  | 3.6  | 26    | —     |
|                              |              |                          |  | 1.25        | 28                                    | 2.9  | 21    | —     | 35                  | 3.6  | 26    | —     |
|                              | M12          | 12.0                     | 17                                       | 1.75        | 45                                    | 4.6  | 33    | —     | 55                  | 5.6  | 41    | —     |
|                              |              |                          |  | 1.25        | 45                                    | 4.6  | 33    | —     | 65                  | 6.6  | 48    | —     |
| M14                          | 14.0         | 19                       | 1.5                                      | 80          | 8.2                                   | 59   | —     | 100   | 10                  | 74   | —     |       |
| 7T                           | M6           | 6.0                      | 10                                       | 1.0         | 9                                     | 0.92 | 7     | 80    | 11                  | 1.1  | 8     | 97    |
|                              | M8           | 8.0                      | 12                                       | 1.25        | 22                                    | 2.2  | 16    | —     | 28                  | 2.9  | 21    | —     |
|                              |              |                          |  | 1.0         | 22                                    | 2.2  | 16    | —     | 28                  | 2.9  | 21    | —     |
|                              | M10          | 10.0                     | 14                                       | 1.5         | 45                                    | 4.6  | 33    | —     | 55                  | 5.6  | 41    | —     |
|                              |              |                          |  | 1.25        | 45                                    | 4.6  | 33    | —     | 55                  | 5.6  | 41    | —     |
|                              | M12          | 12.0                     | 17                                       | 1.75        | 80                                    | 8.2  | 59    | —     | 100                 | 10   | 74    | —     |
|                              |              |                          |  | 1.25        | 80                                    | 8.2  | 59    | —     | 100                 | 10   | 74    | —     |
| M14                          | 14.0         | 19                       | 1.5                                      | 130         | 13                                    | 96   | —     | 170   | 17                  | 125  | —     |       |
| 9T                           | M6           | 6.0                      | 10                                       | 1.0         | 11                                    | 1.1  | 8     | —     | 13.5                | 1.4  | 10    | —     |
|                              | M8           | 8.0                      | 12                                       | 1.25        | 28                                    | 2.9  | 21    | —     | 35                  | 3.6  | 26    | —     |
|                              |              |                          |  | 1.0         | 28                                    | 2.9  | 21    | —     | 35                  | 3.6  | 26    | —     |
|                              | M10          | 10.0                     | 14                                       | 1.5         | 55                                    | 5.6  | 41    | —     | 80                  | 8.2  | 59    | —     |
|                              |              |                          |  | 1.25        | 55                                    | 5.6  | 41    | —     | 80                  | 8.2  | 59    | —     |
|                              | M12          | 12.0                     | 17                                       | 1.75        | 100                                   | 10   | 74    | —     | 130                 | 13   | 96    | —     |
|                              |              |                          |  | 1.25        | 100                                   | 10   | 74    | —     | 130                 | 13   | 96    | —     |
| M14                          | 14.0         | 19                       | 1.5                                      | 170         | 17                                    | 125  | —     | 210   | 21                  | 155  | —     |       |

#### CAUTION:



# TIGHTENING TORQUE OF STANDARD BOLTS

< HOW TO USE THIS MANUAL >

The parts with aluminum or the cast iron washer surface/thread surface are excluded.

NEW STANDARD BASED ON ISO

| Grade<br>(Strength<br>grade)  | Bolt<br>size | Bolt di-<br>ameter<br>mm | Hexagonal<br>width<br>across flats<br>mm | Pitch<br>mm | Tightening torque |      |       |       |                     |      |       |       |
|-------------------------------|--------------|--------------------------|--|-------------|-------------------|------|-------|-------|---------------------|------|-------|-------|
|                               |              |                          |  |             | Hexagon head bolt |      |       |       | Hexagon flange bolt |      |       |       |
|                               |              |                          |  |             | N-m               | kg-m | ft-lb | in-lb | N-m                 | kg-m | ft-lb | in-lb |
| 4.8<br>(Without<br>lubricant) | M6           | 6.0                      | 10                                       | 1.0         | 5.5               | 0.56 | 4     | 49    | 7                   | 0.71 | 5     | 62    |
|                               | M8           | 8.0                      | 13                                       | 1.25        | 13.5              | 1.4  | 10    | —     | 17                  | 1.7  | 13    | —     |
|                               |              |                          |  | 1.0         | 13.5              | 1.4  | 10    | —     | 17                  | 1.7  | 13    | —     |
|                               | M10          | 10.0                     | 16                                       | 1.5         | 28                | 2.9  | 21    | —     | 35                  | 3.6  | 26    | —     |
|                               |              |                          |  | 1.25        | 28                | 2.9  | 21    | —     | 35                  | 3.6  | 26    | —     |
|                               | M12          | 12.0                     | 18                                       | 1.75        | 45                | 4.6  | 33    | —     | 55                  | 5.6  | 41    | —     |
|                               |              |                          |  | 1.25        | 45                | 4.6  | 33    | —     | 65                  | 6.6  | 48    | —     |
| 4.8<br>(With lu-<br>bricant)  | M6           | 6.0                      | 10                                       | 1.0         | 4                 | 0.41 | 3     | 35    | 5.5                 | 0.56 | 4     | 49    |
|                               | M8           | 8.0                      | 13                                       | 1.25        | 11                | 1.1  | 8     | —     | 13.5                | 1.4  | 10    | —     |
|                               |              |                          |  | 1.0         | 11                | 1.1  | 8     | —     | 13.5                | 1.4  | 10    | —     |
|                               | M10          | 10.0                     | 16                                       | 1.5         | 22                | 2.2  | 16    | —     | 28                  | 2.9  | 21    | —     |
|                               |              |                          |  | 1.25        | 22                | 2.2  | 16    | —     | 28                  | 2.9  | 21    | —     |
|                               | M12          | 12.0                     | 18                                       | 1.75        | 35                | 3.6  | 26    | —     | 45                  | 4.6  | 33    | —     |
|                               |              |                          |  | 1.25        | 35                | 3.6  | 26    | —     | 45                  | 4.6  | 33    | —     |
| 8.8<br>(With lu-<br>bricant)  | M6           | 6.0                      | 10                                       | 1.0         | 8                 | 0.82 | 6     | 71    | 10                  | 1.0  | 7     | 89    |
|                               | M8           | 8.0                      | 13                                       | 1.25        | 21                | 2.1  | 15    | —     | 25                  | 2.6  | 18    | —     |
|                               |              |                          |  | 1.0         | 21                | 2.1  | 15    | —     | 25                  | 2.6  | 18    | —     |
|                               | M10          | 10.0                     | 16                                       | 1.5         | 40                | 4.1  | 30    | —     | 50                  | 5.1  | 37    | —     |
|                               |              |                          |  | 1.25        | 40                | 4.1  | 30    | —     | 50                  | 5.1  | 37    | —     |
|                               | M12          | 12.0                     | 18                                       | 1.75        | 70                | 7.1  | 52    | —     | 85                  | 8.7  | 63    | —     |
|                               |              |                          |  | 1.25        | 70                | 7.1  | 52    | —     | 85                  | 8.7  | 63    | —     |
| 10.9<br>(With lu-<br>bricant) | M6           | 6.0                      | 10                                       | 1.0         | 10                | 1.0  | 7     | 89    | 12                  | 1.2  | 9     | 106   |
|                               | M8           | 8.0                      | 13                                       | 1.25        | 27                | 2.8  | 20    | —     | 32                  | 3.3  | 24    | —     |
|                               |              |                          |  | 1.0         | 27                | 2.8  | 20    | —     | 32                  | 3.3  | 24    | —     |
|                               | M10          | 10.0                     | 16                                       | 1.5         | 55                | 5.6  | 41    | —     | 65                  | 6.6  | 48    | —     |
|                               |              |                          |  | 1.25        | 55                | 5.6  | 41    | —     | 65                  | 6.6  | 48    | —     |
|                               | M12          | 12.0                     | 18                                       | 1.75        | 95                | 9.7  | 70    | —     | 110                 | 11   | 81    | —     |
|                               |              |                          |  | 1.25        | 95                | 9.7  | 70    | —     | 110                 | 11   | 81    | —     |
| 10.9<br>(With lu-<br>bricant) | M14          | 14.0                     | 21                                       | 1.5         | 160               | 16   | 118   | —     | 180                 | 18   | 133   | —     |

## CAUTION:

1. Use tightening torque with lubricant for the new standard bolts/nuts in principle. Friction coefficient stabilizer is applied to the new standard bolts/nuts.
2. However, use tightening torque without lubricant for the following cases. Friction coefficient stabilizer is not applied to the following bolts/nuts.
  - Grade 4.8, M6 size bolt, Conical spring washer installed
  - Paint removing nut (Size M6 and M8) for fixing with weld bolt













# TIGHTENING TORQUE OF STANDARD BOLTS

< HOW TO USE THIS MANUAL >









## DISCRIMINATION OF BOLTS AND NUTS

GI

### BOLTS


|                      | Grade<br>(Strength)              | Discrimination   |   |
|----------------------|----------------------------------|--|---|
| Previous<br>standard | 4T<br>(392N/mm <sup>2</sup> )    |   | <br>(No number/<br>symbol) |
|                      | 7T<br>(686N/mm <sup>2</sup> )    |   |                            |
|                      | 9T<br>(883N/mm <sup>2</sup> )    |   |                            |
| New<br>Standard      | 4.8<br>(420N/mm <sup>2</sup> )   |   | <br>(No number/<br>symbol) |
|                      | 8.8<br>(800N/mm <sup>2</sup> )   |   |                            |
|                      | 10.9<br>(1040N/mm <sup>2</sup> ) |  |                           |

### NUTS

|                      | Grade<br>(Proof load<br>stress) | Discrimination  |   |   |
|----------------------|---------------------------------|---|---|---|
| Previous<br>standard | 7N<br>(686N/mm <sup>2</sup> )   | <br>(No number/<br>symbol) |   |   |
|                      | 9N<br>(883N/mm <sup>2</sup> )   |                            |  |   |
| New<br>Standard      | 8<br>(800N/mm <sup>2</sup> )    |                            |  | <br>(No number/<br>symbol) |
|                      | 10<br>(1040N/mm <sup>2</sup> )  |                            |  |   |

#### NOTICE:

- A number is assigned on the side of the nuts in some cases.
- A number or symbol is assigned on the upper surface of the flange for the nut with flange.



### MACHINE SCREWS AND TAPPING SCREWS

Shape of the head :

Cross recess for the previous standard  
Torx recess for the new standard

| Screw<br>size | Screw<br>diameter | Torx size |
|---------------|-------------------|-----------|
| M4            | 4.0               | T20       |
| M5            | 5.0               | T20       |
| M6            | 6.0               | T30       |

#### NOTICE:

Use torx size T20 (united with M4 screw) for M5 screw although ISO standard specifies T25.

SAIA0453E

B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS

< HOW TO USE THIS MANUAL >

## RECOMMENDED CHEMICAL PRODUCTS AND SEALANTS

### Recommended Chemical Products and Sealants

INFOID:000000006280850

Refer to the following chart for help in selecting the appropriate chemical product or sealant.

|   | Product Description  | Purpose  | Nissan North America Part No. (USA) | Nissan Canada Part No. (Canada) | Aftermarket Cross-reference Part Nos.   |
|---|--|--|-------------------------------------|---------------------------------|---|
| 1 | Rear View Mirror Adhesive                                    | Used to permanently re-mount rear view mirrors to windows.   | 999MP-AM000P                        | 99998-50505                     | Permatex 81844  |
| 2 | Anaerobic Liquid Gasket                                      | For metal-to-metal flange sealing.<br>Can fill a 0.38 mm (0.015 inch) gap and provide instant sealing for most powertrain applications.                | 999MP-AM001P                        | 99998-50503                     | Permatex 51813 and 51817  |
| 3 | High Performance Thread Sealant                              | Provides instant sealing on any threaded straight or parallel threaded fitting. (Thread sealant only, no locking ability.)<br>• Do not use on plastic. | 999MP-AM002P                        | 999MP-AM002P                    | Permatex 56521  |
| 4 | Silicone RTV   | Gasket Maker   | 999MP-AM003P (Ultra Grey)           | 99998-50506 (Ultra Grey)        | Permatex Ultra Grey 82194;<br>Three Bond 1207, 1215, 1216, 1217F, 1217G and 1217H<br>Nissan RTV Part No. 999MP-A7007      |
|   |  | Gasket Maker for Maxima/Quest 5-speed automatic transmission (RE5F22A)   | —                                   | —                               | Three Bond 1281B or exact equivalent in its quality   |
| 5 | High Temperature, High Strength Thread Locking Sealant (Red) | Threadlocker   | 999MP-AM004P                        | 999MP-AM004P                    | Permatex 27200;<br>Three Bond 1360, 1360N, 1305 N&P, 1307N, 1335, 1335B, 1363B, 1377C, 1386B, D&E and 1388<br>Loctite 648 |
| 6 | Medium Strength Thread Locking Sealant (Blue)                | Threadlocker (service tool removable)  | 999MP-AM005P                        | 999MP-AM005P                    | Permatex 24200, 24206, 24240, 24283 and 09178;<br>Three Bond 1322, 1322N, 1324 D&N, 1333D, 1361C, 1364D, 1370C and 1374   |

# IDENTIFICATION INFORMATION

< VEHICLE INFORMATION >

## VEHICLE INFORMATION


### IDENTIFICATION INFORMATION

#### Model Variation

INFOID:0000000006280861

| Destination | Body  | Transmission | Engine | Axle | Grade   | Model       |
|-------------|-------|--------------|--------|------|---------|-------------|
| USA         | Wagon | 7A/T         | VK56VD | 4WD  | LE      | JPKNLHL-EU7 |
|             |       |              |        |      |         | JPKNLHL-EU8 |
|             |       |              |        |      | Premium | JPKNLJL-EU7 |
|             |       |              |        |      |         | JPKNLJL-EU8 |
|             |       |              |        | 2WD  | LE      | JPKALHL-EU7 |
|             |       |              |        |      |         | JPKALHL-EU8 |
|             |       |              |        |      | Premium | JPKALJL-EU7 |
|             |       |              |        |      |         | JPKALJL-EU8 |
| CANADA      |       |              |        | 4WD  | LE      | JPKNLHL-EN7 |
|             |       |              |        |      |         | JPKNLHL-EN8 |

#### Model variation code (Prefix and suffix designations)




#### Information About Identification or Model Code

INFOID:0000000006280862

#### IDENTIFICATION NUMBER

# IDENTIFICATION INFORMATION


## < VEHICLE INFORMATION >



JPAIA0814ZZ

- |  |  |   |
|--|--|---|
| 1. Air conditioner specification label | 2. Vehicle identification number plate | 3. Emission control information label             |
| 4. Tire and loading information label  | 5. FMVSS certification label           | 6. Vehicle identification number (Chassis number) |


## VEHICLE IDENTIFICATION NUMBER ARRANGEMENT



JPAIA0806GB

## ENGINE SERIAL NUMBER

← : Vehicle front




JPAIA0735GB

## AUTOMATIC TRANSMISSION NUMBER

# IDENTIFICATION INFORMATION

## < VEHICLE INFORMATION >

← : Vehicle front



JPAIA0770ZZ

INFOID:000000006280863

## Dimensions

Unit: mm (in)

|                |               |
|----------------|---------------|
| Overall length | 5,290 (208.3) |
| Overall width  | 2,030 (79.9)  |
| Overall height | 1,925 (75.8)  |
| Front tread    | 1,715 (67.5)  |
| Rear tread     | 1,725 (67.9)  |
| Wheelbase      | 3,075 (121.1) |

## Wheels & Tires

INFOID:000000006280864

|              |            |                       |         |                 |
|--------------|------------|-----------------------|---------|-----------------|
| Conventional | Tire       |                       | 20 inch | P275/60R20 114H |
|              |            |                       | 22 inch | P275/50R22 111H |
|              | Road wheel | 20 inch<br>(Aluminum) | Size    | 20 × 8J         |
|              |            |                       | Offset  | 30 mm (1.18 in) |
|              |            | 22 inch<br>(Aluminum) | Size    | 22 × 8J         |
|              |            |                       | Offset  | 30 mm (1.18 in) |
| Spare        | Tire       |                       | 20 inch | P275/60R20 114H |
|              |            |                       | 22 inch | P275/50R22 111H |
|              | Road wheel | 20 inch<br>(Aluminum) | Size    | 20 × 8J         |
|              |            |                       | Offset  | 30 mm (1.18 in) |
|              |            | 22 inch<br>(Aluminum) | Size    | 22 × 8J         |
|              |            |                       | Offset  | 30 mm (1.18 in) |

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Description

INFOID:000000006280865

Observe the following precautions to ensure safe and proper servicing. These precautions are not described in each individual section.

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006280866

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precautions For Xenon Headlamp Service

INFOID:000000006280867

#### **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector. (Turning it ON outside the lamp case may cause fire or visual impairments.)
- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

#### **CAUTION:**

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

# PRECAUTIONS

## < PRECAUTION >

### Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000006280868

GI

#### NOTE:

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### NOTE:


Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

### Precaution for Procedure without Cowl Top Cover

INFOID:000000006280869


When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### General Precautions

INFOID:000000006280870

- Do not operate the engine for an extended period of time without proper exhaust ventilation.  
Keep the work area well ventilated and free of any inflammable materials. Special care should be taken when handling any inflammable or poisonous materials, such as gasoline, refrigerant gas, etc. When working in a pit or other enclosed area, be sure to properly ventilate the area before working with hazardous materials.  
Do not smoke while working on the vehicle.






## PRECAUTIONS

### < PRECAUTION >


- Before jacking up the vehicle, apply wheel chocks or other tire blocks to the wheels to prevent the vehicle from moving. After jacking up the vehicle, support the vehicle weight with safety stands at the points designated for proper lifting before working on the vehicle.

These operations should be done on a level surface.


- When removing a heavy component such as the engine or transaxle/transmission, be careful not to lose your balance and drop them. Also, do not allow them to strike adjacent parts, especially the brake tubes and master cylinder.



- Before starting repairs which do not require battery power:  
Turn off ignition switch.  
Disconnect the negative battery terminal.
- If the battery terminals are disconnected, recorded memory of radio and each control unit is erased.




- To prevent serious burns:  
Avoid contact with hot metal parts.  
Do not remove the radiator cap when the engine is hot.
- Dispose of drained oil or the solvent used for cleaning parts in an appropriate manner.
- Do not attempt to top off the fuel tank after the fuel pump nozzle shuts off automatically.  
Continued refueling may cause fuel overflow, resulting in fuel spray and possibly a fire.
- Clean all disassembled parts in the designated liquid or solvent prior to inspection or assembly.
- Replace oil seals, gaskets, packings, O-rings, locking washers, cotter pins, self-locking nuts, etc. with new ones.
- Replace inner and outer races of tapered roller bearings and needle bearings as a set.
- Arrange the disassembled parts in accordance with their assembled locations and sequence.
- Do not touch the terminals of electrical components which use microcomputers (such as ECM).  
Static electricity may damage internal electronic components.
- After disconnecting vacuum or air hoses, attach a tag to indicate the proper connection.
- Use only the fluids and lubricants specified in this manual.
- Use approved bonding agent, sealants or their equivalents when required.
- Use hand tools, power tools (disassembly only) and recommended special tools where specified for safe and efficient service repairs.
- When repairing the fuel, oil, water, vacuum or exhaust systems, check all affected lines for leakage.



## PRECAUTIONS

### < PRECAUTION >

- Before servicing the vehicle:  
Protect fenders, upholstery and carpeting with appropriate covers.  
Take caution that keys, buckles or buttons do not scratch paint.



### WARNING:

To prevent ECM from storing the diagnostic trouble codes, never carelessly disconnect the harness connectors which are related to the engine control system and TCM (transmission control module) system. The connectors should be disconnected only when working according to the WORK FLOW of TROUBLE DIAGNOSES in EC and TM sections.

### Three Way Catalyst

INFOID:000000006280871

If a large amount of unburned fuel flows into the catalyst, the catalyst temperature will be excessively high. To prevent this, follow the instructions.

- Use unleaded gasoline only. Leaded gasoline will seriously damage the three way catalyst.
- When checking for ignition spark or measuring engine compression, make tests quickly and only when necessary.
- Do not run engine when the fuel tank level is low, otherwise the engine may misfire, causing damage to the catalyst.

Do not place the vehicle on flammable material. Keep flammable material off the exhaust pipe and the three way catalyst.

### Multiport Fuel Injection System or Engine Control System

INFOID:000000006280872

- Before connecting or disconnecting any harness connector for the multiport fuel injection system or ECM:  
Turn ignition switch to "OFF" position.  
Disconnect negative battery terminal.  
Otherwise, there may be damage to ECM.
- Before disconnecting pressurized fuel line from fuel pump to injectors, be sure to release fuel pressure.
- Be careful not to jar components such as ECM and mass air flow sensor.




### Hoses

INFOID:000000006280873

### HOSE REMOVAL AND INSTALLATION


- To prevent damage to rubber hose, do not pry off rubber hose with tapered tool or screwdriver.



## PRECAUTIONS


### < PRECAUTION >

- To reinstall the rubber hose securely, check that hose insertion length and orientation is correct. (If tube is equipped with hose stopper, insert rubber hose into tube until it butts up against hose stopper.)




### HOSE CLAMPING

- If old rubber hose is re-used, install hose clamp in its original position (at the indentation where the old clamp was). If there is a trace of tube bulging left on the old rubber hose, align rubber hose at that position.
- Discard old clamps; replace with new ones.



- After installing plate clamps, apply force to them in the direction of the arrow, tightening rubber hose equally all around.



## Engine Oils

INFOID:000000006280874

Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used oil.

If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

### HEALTH PROTECTION PRECAUTIONS

- Avoid prolonged and repeated contact with oils, particularly used engine oils.
- Wear protective clothing, including impervious gloves where practicable.
- Do not put oily rags in pockets.
- Avoid contaminating clothes, particularly underpants, with oil.
- Heavily soiled clothing and oil-impregnated footwear should not be worn. Overalls must be cleaned regularly.
- First aid treatment should be obtained immediately for open cuts and wounds.
- Use barrier creams, applying them before each work period, to help the removal of oil from the skin.
- Wash with soap and water to ensure all oil is removed (skin cleansers and nail brushes will help). Preparations containing lanolin replace the natural skin oils which have been removed.
- Do not use gasoline, kerosene, diesel fuel, gas oil, thinners or solvents for cleaning skin.
- If skin disorders develop, obtain medical advice without delay.
- Where practical, degrease components prior to handling.
- Where there is a risk of eye contact, eye protection should be worn, for example, chemical goggles or face shields; in addition an eye wash facility should be provided.

### ENVIRONMENTAL PROTECTION PRECAUTIONS

# PRECAUTIONS

## < PRECAUTION >

Dispose of used oil and used oil filters through authorized waste disposal contractors to licensed waste disposal sites, or to the waste oil reclamation trade. If in doubt, contact the local authority for advice on disposal facilities.

It is illegal to pour used oil on to the ground, down sewers or drains, or into water sources. The regulations concerning pollution vary between regions.

## Air Conditioning

INFOID:000000006280875

Use an approved refrigerant recovery unit any time the air conditioning system must be discharged. Refer to HA section "REFRIGERANT" for specific instructions.

## Fuel

INFOID:000000006280876

INFINITI recommends the use of unleaded premium gasoline with an octane rating of at least 91 AKI (Anti-Knock Index) number (Research octane number 96).

If unleaded premium gasoline is not available, unleaded regular gasoline with an octane rating of at least 87 AKI number (Research octane number 91), can be used. In such case, engine performance may be decrease.

### CAUTION:

- Using a fuel other than that specified could adversely affect the emission control system, and may also affect warranty coverage.
- Under no circumstances should a leaded gasoline be used, because this will damage the three-way catalyst.
- Do not use E-85 fuel in the vehicle. The vehicle is not designed to run on E-85 fuel. Using E-85 fuel can damage the fuel system components and is not covered by the INFINITI vehicle limited warranty.

GI

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

## LIFTING POINT

< PRECAUTION >


### LIFTING POINT

#### Pantograph Jack

INFOID:000000006280877

#### WARNING:

- Never get under the vehicle while it is supported only by the jack. Always use safety stands to support the frame when you have to get under the vehicle.
- Place wheel chocks at both front and back of the wheels on the ground.



#### Garage Jack and Safety Stand


INFOID:000000006280878

#### CAUTION:

- Place a wooden or rubber block between safety stand and vehicle body when the supporting body is flat.
- Remove engine under cover before jacking up the front side of the vehicle with garage jack. Refer to [BRM-39, "Rear Fender"](#).

## LIFTING POINT

< PRECAUTION >



A : Garage jack point

B : Safety stand point


← : Vehicle front

### 2-Pole Lift

INFOID:000000006280879

#### **WARNING:**

- When lifting the vehicle, open the lift arms as wide as possible and ensure that the front and rear of the vehicle are well balanced.
- When setting the lift arm, never allow the arm to contact the brake tubes, brake cable, or fuel lines.



← : Vehicle front

## TOW TRUCK TOWING

< PRECAUTION >

### TOW TRUCK TOWING


#### Tow Truck Towing

INFOID:000000006280880

#### CAUTION:

- All applicable local laws regarding the towing operation must be obeyed.
- It is necessary to use proper towing equipment to avoid possible damage to the vehicle during towing operation. Towing is in accordance with Towing Procedure Manual at dealer.
- Always attach safety chains before towing.
- When towing, check that the transmission, steering system and powertrain are in good order. If any unit is damaged, dollies must be used.
- Never tow automatic transmission model from the rear (that is backward) with four wheels on the ground. This may cause serious and expensive damage to the transmission.

#### 4WD MODELS



NISSAN recommends that a dolly be used as illustrated when towing 4WD models.

#### CAUTION:

Never tow 4WD models with any of the wheels on the ground as this may cause serious and expensive damage to the powertrain.

#### Vehicle Recovery (Freeing a Stuck Vehicle)

INFOID:000000006280881

#### FREEING TRAPPED VEHICLE

#### WARNING:

- Stand clear of a stuck vehicle.
- Never allow anyone to stand near the towing line during the pulling operation.
- Never spin your tires at high speed. This could cause them to explode and result in serious injury. Parts of your vehicle could also overheat and be damaged.

#### CAUTION:


- Tow chains or cables must be attached only to the vehicle recovery hooks or main structural members of the vehicle. Otherwise, the vehicle body will be damaged.
- Never use the vehicle tie downs to free a vehicle stuck in sand, snow, mud, etc. Never tow the vehicle using the vehicle tie downs or recovery hooks.
- Always pull the cable straight out from the front of the vehicle. Never pull on the hook at an angle.

# TOW TRUCK TOWING


## < PRECAUTION >

- Pulling devices should be routed so they do not touch any part of the suspension, steering, brake or cooling systems.
- Pulling devices such as ropes or canvas straps are not recommended for use in vehicle towing or recovery.
- In order to not break the towing line, tension it slowly.

FRONT



REAR



## AUTOMATIC TRANSMISSION

To tow a vehicle equipped with an automatic transmission, an appropriate vehicle dolly **MUST** be placed under the towed vehicle's drive wheels. **Always** follow the dolly manufacture's recommendations when using their product.

If the vehicle is stuck in sand, snow, mud, etc., use the following procedure:

1. Turn off the Vehicle Dynamic Control System. (if equipped)
2. Check the area in front and behind the vehicle is clear of obstructions.
3. Turn the steering wheel right and left to clear an area around the front tires.
4. Slowly rock the vehicle forward and backward.  
Shift back and forth between R (reverse) and D (drive).  
Apply the accelerator as little as possible to maintain the rocking motion.  
Release the accelerator pedal before shifting between R and D.  
Do not spin the tires above 35 mph. (55 km/h).
5. If the vehicle can not be freed after a few tries, contact a professional towing service to remove the vehicle.



# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

< BASIC INSPECTION >


## BASIC INSPECTION

### SERVICE INFORMATION FOR ELECTRICAL INCIDENT

#### Work Flow

INFOID:000000006280851

#### WORK FLOW



| STEP   | DESCRIPTION   |  |
|--------|---|--|
| STEP 1 | Get detailed information about the conditions and the environment when the incident occurred. The following are key pieces of information required to make a good analysis:   |  |
|        | <b>WHAT</b>   | Vehicle Model, Engine, Transmission/Transaxle and the System (i.e. Radio).   |
|        | <b>WHEN</b>   | Date, Time of Day, Weather Conditions, Frequency.  |
|        | <b>WHERE</b>  | Road Conditions, Altitude and Traffic Situation.   |
|        | <b>HOW</b>  | System Symptoms, Operating Conditions (Other Components Interaction). Service History and if any After Market Accessories have been installed. |
| STEP 2 | Operate the system, road test if necessary. Verify the parameter of the incident. If the problem cannot be duplicated, refer to "Incident Simulation Tests".  |  |
| STEP 3 | Get the proper diagnosis materials together including: <ul style="list-style-type: none"><li>• Power Supply Routing</li><li>• System Operation Descriptions</li><li>• Applicable Service Manual Sections</li><li>• Check for any Service Bulletins</li></ul> Identify where to begin diagnosis based upon your knowledge of the system operation and the customer comments. |  |
| STEP 4 | Inspect the system for mechanical binding, loose connectors or wiring damage. Determine which circuits and components are involved and diagnose using the Power Supply Routing and Harness Lay-outs.  |  |
| STEP 5 | Repair or replace the incident circuit or component.  |  |
| STEP 6 | Operate the system in all modes. Verify the system works properly under all conditions. check you have not inadvertently created a new incident during your diagnosis or repair steps.  |  |

#### Control Units and Electrical Parts

INFOID:000000006280852

#### PRECAUTIONS

- Never reverse polarity of battery terminals.
- Install only parts specified for a vehicle.
- Before replacing the control unit, check the input and output and functions of the component parts.
- Do not apply excessive force when disconnecting a connector.


## SERVICE INFORMATION FOR ELECTRICAL INCIDENT

### < BASIC INSPECTION >

- Do not apply excessive shock to the control unit by dropping or hitting it.
- Be careful to prevent condensation in the control unit due to rapid temperature changes and do not let water or rain get on it. If water is found in the control unit, dry it fully and then install it in the vehicle.
- Be careful not to let oil get on the control unit connector.
- Avoid cleaning the control unit with volatile oil.
- Do not disassemble the control unit, and do not remove the upper and lower covers.



- When using a DMM, be careful not to let test probes get close to each other to prevent the power transistor in the control unit from damaging battery voltage because of short circuiting.
- When checking input and output signals of the control unit, use the specified check adapter.



### How to Check Terminal


INFOID:000000006280853

### CONNECTOR AND TERMINAL PIN KIT

- Use the connector and terminal pin kits listed below when replacing connectors or terminals.
- The connector and terminal pin kits contain some of the most commonly used NISSAN/INFINITI connectors and terminals. For detailed connector and terminal pin replacement procedures, refer to the latest NISSAN/INFINITI CONNECTOR AND TERMINAL PIN SERVICE MANUAL.

# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description   |
|---|---|
| -<br>(J38751-95NI)<br>Connector and terminal<br>pin kit (NISSAN)<br>-<br>(J38751-95INF)<br>Connector and terminal<br>pin kit (INFINITI)<br>-<br>(J42992-98KIT)<br>OBD and terminal repair<br>kit<br>-<br>(J42992-2000UPD)<br>OBD-II Connector Kit Up-<br>date |  <p>J38751-95NI      J38751-95INF      J42992-98KIT      J42992-2000UPD</p> <p>WAIA0004E      WAIA0005E</p> |


## HOW TO PROBE CONNECTORS

- Connector damage and an intermittent connection can result from improperly probing of the connector during circuit checks.
- The probe of a digital multimeter (DMM) may not correctly fit the connector cavity. To correctly probe the connector, follow the procedures below using a "T" pin. For the best contact grasp the "T" pin using an alligator clip.

### Probing from Harness Side

Standard type (not waterproof type) connector should be probed from harness side with "T" pin.


- If the connector has a rear cover such as a ECM connector, remove the rear cover before probing the terminal.
- Do not probe waterproof connector from harness side. Damage to the seal between wire and connector may result.



### Probing from Terminal Side

#### FEMALE TERMINAL


- There is a small notch above each female terminal. Probe each terminal with the "T" pin through the notch. Do not insert any object other than the same type male terminal into female terminal.



# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

- Some connectors do not have a notch above each terminal. To probe each terminal, remove the connector retainer to make contact space for probing.




### MALE TERMINAL

- Carefully probe the contact surface of each terminal using a "T" pin.

#### **CAUTION:**

**Never bend terminal.**



### How to Check Enlarged Contact Spring of Terminal


- An enlarged contact spring of a terminal may create intermittent signals in the circuit.
- If the intermittent open circuit occurs, follow the procedure below to inspect for open wires and enlarged contact spring of female terminal.

- Assemble a male terminal and approx. 10 cm (3.9 in) of wire.

#### **NOTE:**

**Use a male terminal which matches the female terminal.**


- Disconnect the suspected faulty connector and hold it terminal side up.



- While holding the wire of the male terminal, try to insert the male terminal into the female terminal.

#### **CAUTION:**


**Never force the male terminal into the female terminal with your hands.**




# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

4. While moving the connector, check whether the male terminal can be easily inserted or not.



- If the male terminal can be easily inserted into the female terminal, replace the female terminal.



### Waterproof Connector Inspection


If water enters the connector, it can short interior circuits. This may lead to intermittent problems. Check the following items to maintain the original waterproof characteristics.

#### RUBBER SEAL INSPECTION

- Most waterproof connectors are provided with a rubber seal between the male and female connectors. If the seal is missing, the waterproof performance may not meet specifications.
- The rubber seal may come off when connectors are disconnected. Whenever connectors are reconnected, check the rubber seal is properly installed on either side of male or female connector.


#### WIRE SEAL INSPECTION

- The wire seal must be installed on the wire insertion area of a waterproof connector. Be sure that the seal is installed properly.



### Terminal Lock Inspection

Check for unlocked terminals by pulling wire at the end of connector. An unlocked terminal may create intermittent signals in the circuit.



## Intermittent Incident

### DESCRIPTION

Sometimes the symptom is not present when the vehicle is brought in for service. If possible, re-create the conditions present at the time of the incident. Doing so may help avoid a No Trouble Found Diagnosis. The fol-

INFOID:000000006280854

# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

Following section illustrates ways to simulate the conditions/environment under which the owner experiences an electrical incident.

The section is broken into the six following topics:

- Vehicle vibration
- Heat sensitive
- Freezing
- Water intrusion
- Electrical load
- Cold or hot start up

Get a thorough description of the incident from the customer. It is important for simulating the conditions of the problem.

### VEHICLE VIBRATION

The problem may occur or become worse while driving on a rough road or when engine is vibrating (idle with A/C on). In such a case, you will want to check for a vibration related condition. Refer to the following illustration.

#### Connector & Harness


Determine which connectors and wiring harness would affect the electrical system you are inspecting. Gently shake each connector and harness while monitoring the system for the incident you are trying to duplicate. This test may indicate a loose or poor electrical connection.

#### Hint

Connectors can be exposed to moisture. It is possible to get a thin film of corrosion on the connector terminals. A visual inspection may not reveal this without disconnecting the connector. If the problem occurs intermittently, perhaps the problem is caused by corrosion. It is a good idea to disconnect, inspect and clean the terminals on related connectors in the system.

#### Sensor & Relay

Gently apply a slight vibration to sensors and relays in the system you are inspecting. This test may indicate a loose or poorly mounted sensor or relay.



#### Engine Compartment

There are several reasons a vehicle or engine vibration could cause an electrical complaint. Some of the things to check for are:

- Connectors not fully seated.
- Wiring harness not long enough and is being stressed due to engine vibrations or rocking.
- Wires laying across brackets or moving components.
- Loose, dirty or corroded ground wires.
- Wires routed too close to hot components.

To inspect components under the hood, start by verifying the integrity of ground connections. (Refer to Ground Inspection described later.) First check that the system is properly grounded. Then check for loose connection by gently shaking the wiring or components as previously explained. Using the wiring diagrams inspect the wiring for continuity.

#### Behind the Instrument Panel

An improperly routed or improperly clamped harness can become pinched during accessory installation. Vehicle vibration can aggravate a harness which is routed along a bracket or near a screw.

#### Under Seating Areas

# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

An unclamped or loose harness can cause wiring to be pinched by seat components (such as slide guides) during vehicle vibration. If the wiring runs under seating areas, inspect wire routing for possible damage or pinching.

### HEAT SENSITIVE


- The customer's concern may occur during hot weather or after car has sat for a short time. In such cases you will want to check for a heat sensitive condition.
- To determine if an electrical component is heat sensitive, heat the component with a heat gun or equivalent.

#### **CAUTION:**

**Never heat components above 60°C (140°F).**

- If incident occurs while heating the unit, either replace or properly insulate the component.

#### Heating test




Never heat above 60°C (140°F).

JPAIA0733GB

### FREEZING

- The customer may indicate the incident goes away after the car warms up (winter time). The cause could be related to water freezing somewhere in the wiring/electrical system.
- There are two methods to check for this. The first is to arrange for the owner to leave his car overnight. Check it will get cold enough to demonstrate his complaint. Leave the car parked outside overnight. In the morning, do a quick and thorough diagnosis of those electrical components which could be affected.
- The second method is to put the suspect component into a freezer long enough for any water to freeze. Reinstall the part into the car and check for the reoccurrence of the incident. If it occurs, repair or replace the component.

#### Freezing test



SGI843

### WATER INTRUSION

The incident may occur only during high humidity or in rainy/snowy weather. In such cases the incident could be caused by water intrusion on an electrical part. This can be simulated by soaking the car or running it through a car wash.

#### **CAUTION:**

**Never spray water directly on any electrical components.**

#### Water intrusion test




SGI844

### ELECTRICAL LOAD

The incident may be electrical load sensitive. Perform diagnosis with all accessories (including A/C, rear window defogger, radio, fog lamps) turned on.

#### Electrical load test



SGI845

### COLD OR HOT START UP

On some occasions an electrical incident may occur only when the car is started cold, or it may occur when the car is restarted hot shortly after being turned off. In these cases you may have to keep the car overnight to make a proper diagnosis.

# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

### Circuit Inspection

INFOID:000000006280855

GI

#### DESCRIPTION

- In general, testing electrical circuits is an easy task if it is approached in a logical and organized method. Before beginning it is important to have all available information on the system to be tested. Also, get a thorough understanding of system operation. Then you will be able to use the appropriate equipment and follow the correct test procedure.
- You may have to simulate vehicle vibrations while testing electrical components. Gently shake the wiring harness or electrical component to do this.


|       |   |   |
|-------|---|---|
| OPEN  | A circuit is open when there is no continuity through a section of the circuit. |   |
| SHORT | There are two types of shorts.  |   |
|       | • SHORT CIRCUIT   | When a circuit contacts another circuit and causes the normal resistance to change. |
|       | • SHORT TO GROUND   | When a circuit contacts a ground source and grounds the circuit.                    |

#### NOTE:

Refer to [GI-37, "How to Check Terminal"](#) to probe or check terminal.

#### TESTING FOR "OPENS" IN THE CIRCUIT

Before you begin to diagnose and test the system, you should rough sketch a schematic of the system. This will help you to logically walk through the diagnosis process. Drawing the sketch will also reinforce your working knowledge of the system.



#### Continuity Check Method

The continuity check is used to find an open in the circuit. The digital multimeter (DMM) set on the resistance function will indicate an open circuit as over limit (no beep tone or no ohms symbol). Check to always start with the DMM at the highest resistance level.

To help in understanding the diagnosis of open circuits, please refer to the previous schematic.

- Disconnect the battery negative cable.
- Start at one end of the circuit and work your way to the other end. (At the fuse block in this example)
- Connect one probe of the DMM to the fuse block terminal on the load side.
- Connect the other probe to the fuse block (power) side of SW1. Little or no resistance will indicate that portion of the circuit has good continuity. If there were an open in the circuit, the DMM would indicate an over limit or infinite resistance condition. (point A)
- Connect the probes between SW1 and the relay. Little or no resistance will indicate that portion of the circuit has good continuity. If there were an open in the circuit, the DMM would indicate an over limit or infinite resistance condition. (point B)
- Connect the probes between the relay and the solenoid. Little or no resistance will indicate that portion of the circuit has good continuity. If there were an open in the circuit, the DMM would indicate an over limit or infinite resistance condition. (point C)

Any circuit can be diagnosed using the approach in the previous example.

#### Voltage Check Method

To help in understanding the diagnosis of open circuits please refer to the previous schematic.

In any powered circuit, an open can be found by methodically checking the system for the presence of voltage. This is done by switching the DMM to the voltage function.

- Connect one probe of the DMM to a known good ground.
- Begin probing at one end of the circuit and work your way to the other end.
- With SW1 open, probe at SW1 to check for voltage.  
voltage: open is further down the circuit than SW1.




# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

- no voltage: open is between fuse block and SW1 (point A).
  - Close SW1 and probe at relay.
    - voltage: open is further down the circuit than the relay.
    - no voltage: open is between SW1 and relay (point B).
  - Close the relay and probe at the solenoid.
    - voltage: open is further down the circuit than the solenoid.
    - no voltage: open is between relay and solenoid (point C).
- Any powered circuit can be diagnosed using the approach in the previous example.

## TESTING FOR "SHORTS" IN THE CIRCUIT

To simplify the discussion of shorts in the system, please refer to the following schematic.



### Resistance Check Method

- Disconnect the battery negative cable and remove the blown fuse.
- Disconnect all loads (SW1 open, relay disconnected and solenoid disconnected) powered through the fuse.
- Connect one probe of the DMM to the load side of the fuse terminal. Connect the other probe to a known good ground.
- With SW1 open, check for continuity.
  - continuity: short is between fuse terminal and SW1 (point A).
  - no continuity: short is further down the circuit than SW1.
- Close SW1 and disconnect the relay. Put probes at the load side of fuse terminal and a known good ground. Then, check for continuity.
  - continuity: short is between SW1 and the relay (point B).
  - no continuity: short is further down the circuit than the relay.
- Close SW1 and jump the relay contacts with jumper wire. Put probes at the load side of fuse terminal and a known good ground. Then, check for continuity.
  - continuity: short is between relay and solenoid (point C).
  - no continuity: check solenoid, retrace steps.

### Voltage Check Method

- Remove the blown fuse and disconnect all loads (i.e. SW1 open, relay disconnected and solenoid disconnected) powered through the fuse.
- Turn the ignition switch to the ON or START position. Verify battery voltage at the battery + side of the fuse terminal (one lead on the battery + terminal side of the fuse block and one lead on a known good ground).
- With SW1 open and the DMM leads across both fuse terminals, check for voltage.
  - voltage: short is between fuse block and SW1 (point A).
  - no voltage: short is further down the circuit than SW1.
- With SW1 closed, relay and solenoid disconnected and the DMM leads across both fuse terminals, check for voltage.
  - voltage: short is between SW1 and the relay (point B).
  - no voltage: short is further down the circuit than the relay.
- With SW1 closed, relay contacts jumped with fused jumper wire check for voltage.
  - voltage: short is down the circuit of the relay or between the relay and the disconnected solenoid (point C).
  - no voltage: retrace steps and check power to fuse block.


## GROUND INSPECTION

- Ground connections are very important to the proper operation of electrical and electronic circuits. Ground connections are often exposed to moisture, dirt and other corrosive elements. The corrosion (rust) can become an unwanted resistance. This unwanted resistance can change the way a circuit works.
- Electronically controlled circuits are very sensitive to proper grounding. A loose or corroded ground can drastically affect an electronically controlled circuit. A poor or corroded ground can easily affect the circuit. Even when the ground connection looks clean, there can be a thin film of rust on the surface.

# SERVICE INFORMATION FOR ELECTRICAL INCIDENT

## < BASIC INSPECTION >

- When inspecting a ground connection follow these rules:
  - Remove the ground bolt or screw.
  - Inspect all mating surfaces for tarnish, dirt, rust, etc.
  - Clean as required to assure good contact.
  - Reinstall bolt or screw securely.
  - Inspect for “add-on” accessories which may be interfering with the ground circuit.
  - If several wires are crimped into one ground eyelet terminal, check for proper crimps. Check all of the wires are clean, securely fastened and providing a good ground path. If multiple wires are cased in one eyelet check no ground wires have excess wire insulation.
- For detailed ground distribution information, refer to “Ground Distribution” in PG section.



## VOLTAGE DROP TESTS

- Voltage drop tests are often used to find components or circuits which have excessive resistance. A voltage drop in a circuit is caused by a resistance when the circuit is in operation.
- Check the wire in the illustration. When measuring resistance with DMM, contact by a single strand of wire will give reading of 0 ohms. This would indicate a good circuit. When the circuit operates, this single strand of wire is not able to carry the current. The single strand will have a high resistance to the current. This will be picked up as a slight voltage drop.
- Unwanted resistance can be caused by many situations as follows:
  - Undersized wiring (single strand example)
  - Corrosion on switch contacts
  - Loose wire connections or splices.
- If repairs are needed always use wire that is of the same or larger gauge.


### Measuring Voltage Drop — Accumulated Method

- Connect the DMM across the connector or part of the circuit you want to check. The positive lead of the DMM should be closer to power and the negative lead closer to ground.
- Operate the circuit.
- The DMM will indicate how many volts are being used to “push” current through that part of the circuit.

# SERVICE INFORMATION FOR ELECTRICAL INCIDENT


## < BASIC INSPECTION >

**Note in the illustration that there is an excessive 4.1 volt drop between the battery and the bulb.**



### Measuring Voltage Drop — Step-by-Step

- The step-by-step method is most useful for isolating excessive drops in low voltage systems (such as those in “Computer Controlled Systems”).
- Circuits in the “Computer Controlled System” operate on very low amperage.
- The (Computer Controlled) system operations can be adversely affected by any variation in resistance in the system. Such resistance variation may be caused by poor connection, improper installation, improper wire gauge or corrosion.
- The step by step voltage drop test can identify a component or wire with too much resistance.




## CONTROL UNIT CIRCUIT TEST

### System Description

- When the switch is ON, the control unit lights up the lamp.

### CASE 1



# SERVICE INFORMATION FOR ELECTRICAL INCIDENT


## < BASIC INSPECTION >

### INPUT-OUTPUT VOLTAGE CHART

| Terminal No. |             | Description |              | Condition  | Value (Approx.) | In case of high resistance such as single strand (V) * |
|--------------|-------------|-------------|--------------|------------|-----------------|--|
| +            | -           | Signal name | Input/Output |            |                 |  |
| 1            | Body ground | Switch      | Input        | Switch ON  | Battery voltage | Lower than battery voltage Approx. 8 (Example)         |
|              |             |             |              | Switch OFF | 0 V             | Approx. 0  |
| 2            | Body ground | Lamp        | Output       | Switch ON  | Battery voltage | Approx. 0 (Inoperative lamp)                           |
|              |             |             |              | Switch OFF | 0 V             | Approx. 0  |

- The voltage value is based on the body ground.
- \*: If high resistance exists in the switch side circuit (caused by a single strand), terminal 1 does not detect battery voltage. Control unit does not detect the switch is ON even if the switch does not turn ON. Therefore, the control unit does not supply power to light up the lamp.

### CASE 2



### INPUT-OUTPUT VOLTAGE CHART

| Terminal No. |             | Description |              | Condition  | Value (Approx.) | In case of high resistance such as single strand (V) * |
|--------------|-------------|-------------|--------------|------------|-----------------|--|
| +            | -           | Signal name | Input/Output |            |                 |  |
| 1            | Body ground | Lamp        | Output       | Switch ON  | 0 V             | Battery voltage (Inoperative lamp)                     |
|              |             |             |              | Switch OFF | Battery voltage | Battery voltage  |
| 2            | Body ground | Switch      | Input        | Switch ON  | 0 V             | Higher than 0 Approx. 4 (Example)                      |
|              |             |             |              | Switch OFF | 5 V             | Approx. 5  |

- The voltage value is based on the body ground.
- \*: If high resistance exists in the switch side circuit (caused by a single strand), terminal 2 does not detect approx. 0 V. Control unit does not detect the switch is ON even if the switch does not turn ON. Therefore, the control unit does not control ground to light up the lamp.

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III/GST CHECKING SYSTEM


### Description

INFOID:000000006280856

- When CONSULT-III/GST is connected with a data link connector (A) equipped on the vehicle side, it will communicate with the control unit equipped in the vehicle and then enable various kinds of diagnostic tests.

1 : Instrument lower panel LH

- Refer to "CONSULT-III Software Operation Manual" for more information.



JPAIA0769ZZ

### CONSULT-III Function and System Application\*1

INFOID:000000006280857

| Diagnostic test mode          | Function  | ENGINE | TRANSMISSION | AIR BAG | METER/M&A | AUTO BACK DOOR | BCM | AUTO DRIVE POS. | ABS | IPDM E/R | ALL MODE AWD/4WD | MULTI AV | ICC/ADAS | SONAR | AIR PRESSURE MONITOR | AFS (ADAPTIVE LIGHT) | PRECRASH SEAT BELT | HVAC | LASER | LANE CAMERA | ACCELE PEDAL ACT | E-SUS | SIDE RADAR LEFT | SIDE RADAR RIGHT | CAN GATEWAY |
|-------------------------------|---|--------|--------------|---------|-----------|----------------|-----|-----------------|-----|----------|------------------|----------|----------|-------|----------------------|----------------------|--------------------|------|-------|-------------|------------------|-------|-----------------|------------------|-------------|
| Work Support                  | This mode enables a technician to adjust some devices faster and more accurately. | x      | x            | -       | -         | -              | x   | x               | x   | -        | x                | x        | x        | x     | x                    | x                    | -                  | x    | x     | x           | -                | x     | x               | x                | -           |
| Self Diagnostic Results       | Retrieve DTC from ECU and display diagnostic items.                               | x      | x            | x       | x         | x              | x   | x               | x   | x        | x                | x        | x        | x     | x                    | x                    | x                  | x    | x     | x           | x                | x     | x               | x                | x           |
| Data Monitor                  | Monitor the input/output signal of the control unit in real time.                 | x      | x            | -       | x         | x              | x   | x               | x   | x        | x                | x        | x        | x     | x                    | x                    | x                  | x    | x     | x           | x                | x     | x               | x                | -           |
| CAN Diagnosis                 | This mode displays a network diagnosis result about CAN by a diagram.             | x      | x            | x       | x         | x              | x   | x               | x   | x        | x                | x        | x        | -     | x                    | x                    | x                  | x    | x     | x           | x                | x     | x               | x                | x           |
| CAN Diagnosis Support Monitor | It monitors the status of CAN communication.                                      | x      | x            | -       | x         | x              | x   | x               | x   | x        | x                | x        | x        | -     | x                    | x                    | x                  | x    | x     | x           | x                | x     | x               | x                | x           |

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

| Diagnostic test mode   | Function  | ENGINE | TRANSMISSION | AIR BAG | METER/M&A | AUTO BACK DOOR | BCM | AUTO DRIVE POS. | ABS | IPDM E/R | ALL MODE AWD/4WD | MULTI AV | ICC/ADAS | SONAR | AIR PRESSURE MONITOR | AFS (ADAPTIVE LIGHT) | PRECRASH SEAT BELT | HVAC | LASER | LANE CAMERA | ACCELE PEDAL ACT | E-SUS | SIDE RADAR LEFT | SIDE RADAR RIGHT | CAN GATEWAY |
|------------------------|---|--------|--------------|---------|-----------|----------------|-----|-----------------|-----|----------|------------------|----------|----------|-------|----------------------|----------------------|--------------------|------|-------|-------------|------------------|-------|-----------------|------------------|-------------|
| Active Test            | Send the drive signal from CONSULT-III to the actuator. The operation check can be performed.   | x      | -            | -       | -         | -              | x   | x               | x   | x        | -                | -        | x        | x     | x                    | x                    | -                  | x    | -     | -           | x                | x     | x               | x                | -           |
| DTC & SRT confirmation | The status of system monitoring tests and the self-diagnosis status/result can be confirmed.  | x      | x            | -       | -         | -              | -   | -               | -   | -        | -                | -        | -        | -     | -                    | -                    | -                  | -    | -     | -           | -                | -     | -               | -                | -           |
| ECU Identification     | Display the ECU identification number (part number etc.) of the selected system.  | x      | x            | x       | -         | x              | x   | x               | x   | x        | x                | x        | x        | x     | x                    | x                    | x                  | x    | x     | x           | x                | x     | x               | x                | x           |
| Function Test          | This mode can show results of self-diagnosis of ECU with either "OK" or "NG". For engine, more practical tests regarding sensors/ switches and/ or actuators are available. | x      | x            | x       | -         | -              | -   | -               | x   | -        | -                | -        | -        | -     | -                    | -                    | -                  | -    | -     | -           | -                | -     | -               | -                | -           |
| Configuration          | Function to READ/ WRITE vehicle configuration.  | -      | -            | -       | -         | -              | x   | -               | -   | -        | -                | x        | -        | -     | -                    | -                    | -                  | -    | -     | -           | -                | -     | -               | -                | x           |
| Special Function       | Other results or histories, etc. that are recorded in ECU are displayed.  | -      | x            | x       | x         | -              | -   | -               | -   | -        | -                | -        | -        | -     | -                    | -                    | -                  | -    | -     | -           | -                | -     | -               | -                | -           |

x: Applicable

\*1: If GST application is equipped, functions in accordance with SAE J1979 and ISO 15031-5 can be used.

GI

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III/GST Data Link Connector (DLC) Circuit

INFOID:000000006280858

### INSPECTION PROCEDURE

If the CONSULT-III/GST cannot diagnose the system properly, check the following items.

| Symptom   | Check item   |
|---|--|
| CONSULT-III/GST cannot access any system.                                     | <ul style="list-style-type: none"><li>CONSULT-III/GST DLC power supply circuit (Terminal 8 and 16) and ground circuit (Terminal 4 and 5)</li></ul>   |
| CONSULT-III cannot access individual system. (Other systems can be accessed.) | <ul style="list-style-type: none"><li>Power supply and ground circuit for the control unit of the system (For detailed circuit, refer to wiring diagram for each system.)</li><li>Open or short circuit between the system and CONSULT-III DLC (For detailed circuit, refer to wiring diagram for each system.)</li><li>Open or short circuit CAN communication line. Refer to <a href="#">LAN-18, "Trouble Diagnosis Flow Chart"</a>.</li></ul> |

### NOTE:

The DDL1 and DDL2 circuits from DLC pins 12, 13, 14 and 15 may be connected to more than one system. A short in a DDL circuit connected to a control unit in one system may affect CONSULT-III access to other systems.

If the GST cannot operate properly, check the circuit based on the information of SAE J1962 and ISO 15031-3.

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >


## Wiring Diagram - CONSULT-III/GST CHECKING SYSTEM -

INFOID:000000006280859

WITH ICC

### CONSULT-III CHECKING SYSTEM (WITH ICC)

4W : 4WD models




2010/05/13

JCAWM0358GB



# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >



JCAWM0359GB

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

GI

B

C

D

E

F

G

H

I

J

K


L

M

N

O

P



# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITH ICC)

|                |  |
|----------------|--|
| Connector No.  | B9   |
| Connector Name | PRE-CRASH SEAT BELT CONTROL UNIT (DRIVER SIDE) |
| Connector Type | TH18FW-CSZ                                     |



|    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|
| 1  | 2  | 3  | 4  | 5  | 6  | 7  | 8  | 9  |
| 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 |
| 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | Y             | SIG BAT                     |
| 2            | G             | OUT 1                       |
| 4            | P             | CAN-L                       |
| 6            | LG/R          | BUCKLE SW LH NO             |
| 8            | G             | LOCAL COMM 2                |
| 9            | SHIELD        | SHIELD GND                  |
| 10           | R             | SENS POWER 1                |
| 12           | B             | OUT 2                       |
| 14           | L             | CAN-H                       |
| 16           | W             | LOCAL COMM 1                |
| 17           | W             | SENS GND 1                  |
| 18           | B             | SIG GND                     |
| 19           | W             | MOTOR BAT                   |
| 20           | B             | MOTOR GND                   |

|                |                                    |
|----------------|------------------------------------|
| Connector No.  | B26                                |
| Connector Name | AUTOMATIC BACK DOOR CONTROL MODULE |
| Connector Type | TH20FW-TE6                         |



|    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|
| 7  | 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |
| 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | L             | BUZZER                      |
| 2            | Y/B           | ABD SW                      |
| 4            | GR            | ABD CLOSE SW                |
| 6            | P             | CAN-L                       |
| 7            | L             | CAN-H                       |
| 8            | L/W           | HALF LATCH SW               |
| 9            | GR/L          | IGN                         |
| 10           | Y             | BAT                         |

|    |     |                     |
|----|-----|---------------------|
| 11 | R   | CLOSURE MTR (CLOSE) |
| 12 | V   | CLOSURE MTR (OPEN)  |
| 14 | G/W | TOUCH SENS LH       |
| 15 | L/R | TOUCH SENS GND      |
| 16 | LG  | TOUCH SENS RH       |
| 17 | O   | MAIN SW             |
| 19 | L/Y | CLOSE SW            |
| 20 | G/Y | OPEN SW             |
| 22 | B   | GND                 |
| 23 | B   | GND                 |
| 28 | R/W | BAT                 |
| 34 | B   | GND                 |

|                |                   |
|----------------|-------------------|
| Connector No.  | B61               |
| Connector Name | ADAS CONTROL UNIT |
| Connector Type | TH18FW-NH         |



|    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|
| 8  | 9  | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 |
| 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | V/W           | WARNING SYSTEMS SW          |
| 3            | R/Y           | IBA OFF SW                  |
| 4            | LG/B          | WARNING SYSTEMS ON IND      |
| 5            | R             | BRAKE HOLD RLY DRIVE SIGNAL |
| 6            | B             | GND                         |
| 7            | L             | ITS COMM-H                  |
| 8            | Y             | ITS COMM-L                  |
| 12           | G/R           | WARNING BUZZER              |
| 14           | L             | CAN-H                       |
| 15           | P             | CAN-L                       |
| 16           | W/G           | IGNITION                    |

|                |               |
|----------------|---------------|
| Connector No.  | B74           |
| Connector Name | SIDE RADAR LH |
| Connector Type | AA030FB-WP-5P |



|   |   |   |   |   |
|---|---|---|---|---|
| 2 | 3 | 4 | 5 | 6 |
|---|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | GND                         |
| 3            | Y             | ITS COMM-L                  |
| 4            | L             | ITS COMM-H                  |
| 5            | W/G           | IGNITION                    |
| 6            | BR            | BSW INDICATOR               |

|                |                              |
|----------------|------------------------------|
| Connector No.  | B84                          |
| Connector Name | AIR LEVELIZER CONTROL MODULE |
| Connector Type | TH18FW-NH                    |



|   |    |    |    |    |    |    |    |
|---|----|----|----|----|----|----|----|
| 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
|---|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification]        |
|--------------|---------------|------------------------------------|
| 2            | B             | GND                                |
| 3            | V             | AIR COMPRESSOR RELAY               |
| 4            | L/W           | VEHICLE HEIGHT SENSOR GND          |
| 5            | W             | VEHICLE HEIGHT SENSOR SIGNAL       |
| 7            | P             | CAN-L                              |
| 9            | P/L           | IGN                                |
| 11           | V/W           | EXHAUST SOLENOID                   |
| 13           | R             | VEHICLE HEIGHT SENSOR POWER SUPPLY |
| 16           | L             | CAN-H                              |

|                |               |
|----------------|---------------|
| Connector No.  | B243          |
| Connector Name | SIDE RADAR RH |
| Connector Type | AA030FB-WP    |



|   |   |   |   |   |   |
|---|---|---|---|---|---|
| 1 | 2 | 3 | 4 | 5 | 6 |
|---|---|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | B/Y           | RIGHT/LEFT SWITCHING SIGNAL |
| 2            | B             | GND                         |
| 3            | Y             | ITS COMM-L                  |
| 4            | L             | ITS COMM-H                  |
| 5            | W/G           | IGNITION                    |
| 6            | L/R           | BSW INDICATOR               |

|                |  |
|----------------|--|
| Connector No.  | B246                                   |
| Connector Name | OCCUPANT DETECTION SYSTEM CONTROL UNIT |
| Connector Type | TH04FW-NH                              |



|   |   |   |   |
|---|---|---|---|
| 4 | 5 | 6 | 7 |
|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | W             | -                           |
| 2            | B             | -                           |
| 3            | L/R           | -                           |
| 4            | R/L           | -                           |

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITH ICC)

|                |                          |
|----------------|--------------------------|
| Connector No.  | B451                     |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | TH22PV-NH                |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R/Y           | CAN-H                       |
| 2            | R             | UART (TX/RX)                |
| 4            | R/L           | PUL SE (RECLINER)           |
| 5            | R/B           | TELESCOPIC SENSOR           |
| 6            | R/W           | ADDRESS 2                   |
| 7            | R/G           | IND-2                       |
| 8            | SB            | SLIDE SW (BACKWARD)         |
| 9            | L             | RECLINER SW (BACKWARD)      |
| 10           | L/B           | FRONT LIFTER SW (DOWNWARD)  |
| 11           | L/W           | REAR LIFTER SW (DOWNWARD)   |
| 12           | L/R           | SENSOR POWER SUPPLY         |
| 17           | V             | CAN-L                       |
| 18           | B/W           | PULSE (SLIDE)               |
| 19           | B/R           | PULSE (FRONT LIFTER)        |
| 20           | B/L           | PULSE (REAR LIFTER)         |
| 21           | W/B           | TILT SENSOR                 |
| 22           | W/L           | ADDRESS 1                   |
| 23           | W/R           | IND-1                       |
| 24           | V/W           | SLIDE SW (FORWARD)          |
| 25           | Y/B           | RECLINER SW (FORWARD)       |
| 26           | Y/R           | FRONT LIFTER SW (UPWARD)    |
| 27           | Y/L           | REAR LIFTER SW (UPWARD)     |
| 28           | G             | SET SW                      |



|    |    |    |    |    |    |    |    |    |    |    |    |  |  |
|----|----|----|----|----|----|----|----|----|----|----|----|--|--|
| 1  | 2  |    | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 |  |  |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 |  |  |




|    |    |    |    |    |    |    |    |    |    |    |    |  |  |
|----|----|----|----|----|----|----|----|----|----|----|----|--|--|
| 1  | 2  |    | 4  | 5  | 6  | 7  | 8  | 9  | 10 | 11 | 12 |  |  |
| 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 |  |  |

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITH ICC)


|                |                 |
|----------------|-----------------|
| Connector No.  | E80             |
| Connector Name | ECM             |
| Connector Type | MA85FB-MEB10-LH |



| Terminal No. | Color of Wire | Signal Name [Specification]          |
|--------------|---------------|--------------------------------------|
| 111          | R             | FUEL INJECTOR DRIVER POWER SUPPLY    |
| 112          | SB            | FUEL INJECTOR DRIVER POWER SUPPLY    |
| 113          | G             | FUEL RETURN VALVE                    |
| 114          | B             | ECM GROUND                           |
| 115          | B             | ECM GROUND                           |
| 120          | Y             | EVAP CANISTER VENT CONTROL VALVE     |
| 122          | BR/W          | THROTTLE CONTROL MOTOR RELAY         |
| 123          | V/R           | FUEL PUMP CONTROL MODULE (PCM)       |
| 125          | GR            | ACCELERATOR PEDAL POSITION SENSOR 2  |
| 126          | O             | ICC STEERING SWITCH                  |
| 128          | Y             | SENSOR GROUND (APP SENSOR 2)         |
| 129          | P/L           | SENSOR GROUND                        |
| 130          | R             | SENSOR POWER SUPPLY                  |
| 131          | L/W           | SENSOR POWER SUPPLY                  |
| 133          | SB            | TF                                   |
| 134          | V/W           | ACCELERATOR PEDAL POSITION SENSOR 1  |
| 136          | W/R           | SENSOR POWER SUPPLY (APP SENSOR 1)   |
| 137          | W/G           | BATTERY CURRENT SENSOR               |
| 138          | V             | BATTERY TEMPERATURE SENSOR           |
| 139          | G             | SENSOR GROUND                        |
| 140          | R/Y           | IGNITION SWITCH                      |
| 141          | SB            | FUEL PUMP CONTROL MODULE (PCM) CHECK |
| 142          | R/W           | EVAP CONTROL SYSTEM PRESSURE SENSOR  |
| 143          | L/Y           | REFRIGERANT PRESSURE SENSOR          |
| 144          | O/B           | CAN COMMUNICATION LINE               |
| 146          | L             | ICC BRAKE SWITCH                     |
| 147          | G/Y           | SENSOR GROUND                        |
| 150          | R             | CAN COMMUNICATION LINE               |
| 151          | P             | POWER SUPPLY FOR ECM (BACK-UP)       |
| 156          | L             | STOP LAMP SWITCH                     |
| 158          | W/B           | ECM COMMUNICATION LINE               |
| 161          | R/W           | ECM RELAY (SELF SHUT-OFF)            |
| 163          | L/G           | ECM RELAY (SELF SHUT-OFF)            |
| 165          | GR/R          | ECM COMMUNICATION LINE               |
| 166          | W             | ENGINE SPEED SIGNAL OUTPUT           |
| 169          | G/B           | POWER SUPPLY FOR ECM                 |
| 171          | W             | POWER SUPPLY FOR ECM                 |
| 172          | W             | POWER SUPPLY FOR ECM                 |


|     |   |                                     |
|-----|---|-------------------------------------|
| 173 | O | THROTTLE CONTROL MOTOR POWER SUPPLY |
| 174 | B | ECM GROUND                          |
| 175 | B | ECM GROUND                          |

|                |              |
|----------------|--------------|
| Connector No.  | F51          |
| Connector Name | A/T ASSEMBLY |
| Connector Type | RK1DFG       |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | V             | -                           |
| 2            | P             | -                           |
| 3            | L             | -                           |
| 4            | SB            | -                           |
| 5            | B             | -                           |
| 6            | V             | -                           |
| 7            | R             | -                           |
| 8            | P             | -                           |
| 9            | BR            | -                           |
| 10           | B             | -                           |

|                |                                   |
|----------------|-----------------------------------|
| Connector No.  | F301                              |
| Connector Name | TGM (TRANSMISSION CONTROL MODULE) |
| Connector Type | SP1DFG                            |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | -             | VIGN                        |
| 2            | -             | BATT                        |
| 3            | -             | CAN-H                       |
| 4            | -             | K LINE                      |
| 5            | -             | GND                         |
| 6            | -             | VIGN                        |
| 7            | -             | REV LAMP RLY                |

|                |                     |
|----------------|---------------------|
| Connector No.  | M4                  |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW              |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | LG            | -                           |
| 4            | B             | -                           |
| 5            | B             | -                           |
| 6            | L             | -                           |
| 7            | SB            | -                           |
| 8            | GR            | -                           |
| 11           | SB            | -                           |
| 12           | R             | -                           |
| 13           | L             | -                           |
| 14           | P             | -                           |
| 16           | Y             | -                           |

|    |   |           |
|----|---|-----------|
| 8  | - | CAN-L     |
| 9  | - | START RLY |
| 10 | - | GND       |

|                |                  |
|----------------|------------------|
| Connector No.  | M1               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS06FW-M2        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A           | Y             | -                           |
| 2A           | GR            | -                           |
| 3A           | W             | -                           |
| 4A           | Y/G           | -                           |
| 5A           | V             | -                           |
| 6A           | L/W           | -                           |
| 7A           | LG            | -                           |
| 8A           | W             | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | M2               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1B           | R             | -                           |
| 3B           | R             | -                           |
| 4B           | B             | -                           |
| 5B           | BR            | -                           |
| 8B           | Y             | -                           |
| 7B           | G             | -                           |
| 8B           | L/O           | -                           |
| 10B          | W/B           | -                           |

JCAWM0363GB

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITH ICC)

|                |                   |
|----------------|-------------------|
| Connector No.  | M34               |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH         |

|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

|                |                    |
|----------------|--------------------|
| Connector No.  | M47                |
| Connector Name | SONAR CONTROL UNIT |
| Connector Type | TH24FW-NH          |

|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

| Terminal No. | Color of Wire | Signal Name [Specification]                  |
|--------------|---------------|--|
| 1            | Y             | BATTERY POWER SUPPLY                         |
| 2            | GR            | IGNITION SIGNAL                              |
| 3            | B             | GROUND                                       |
| 4            | B             | GROUND                                       |
| 5            | B             | ILL GND                                      |
| 7            | R             | TOW MODE SIGNAL                              |
| 8            | P/L           | TRIP RESET SWITCH SIGNAL                     |
| 11           | G             | ENTER SWITCH SIGNAL                          |
| 12           | O             | SELECT SWITCH SIGNAL                         |
| 13           | W/R           | ILLUMINATION CONTROL SWITCH SIGNAL (+)       |
| 14           | R             | ILLUMINATION CONTROL SWITCH SIGNAL (-)       |
| 15           | R/W           | AIR BAG SIGNAL                               |
| 16           | W/R           | AMBIENT SENSOR SIGNAL                        |
| 19           | V/W           | A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL  |
| 20           | B             | AMBIENT SENSOR GROUND                        |
| 21           | L             | CAN-H  |
| 22           | P             | CAN-L  |
| 23           | B             | GROUND                                       |
| 24           | V             | FUEL LEVEL SENSOR GROUND                     |
| 25           | O/L           | ALTERNATOR SIGNAL                            |
| 26           | W             | PARKING BRAKE SWITCH SIGNAL                  |
| 28           | GR/R          | SECURITY SIGNAL                              |
| 29           | BR            | WASHER LEVEL SWITCH SIGNAL                   |
| 30           | SB            | VEHICLE SPEED SIGNAL (2-PULSE)               |
| 31           | BR/W          | VEHICLE SPEED SIGNAL (8-PULSE)               |
| 33           | W             | SNOW MODE SIGNAL                             |
| 34           | BR/Y          | FUEL LEVEL SENSOR SIGNAL                     |
| 35           | O/B           | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 36           | G/Y           | PASSENGER SEAT BELT WARNING SIGNAL           |
| 37           | R/Y           | NON-MANUAL MODE SIGNAL                       |
| 38           | L/W           | MANUAL MODE SHIFT DOWN SIGNAL                |
| 39           | Y/B           | MANUAL MODE SHIFT UP SIGNAL                  |
| 40           | G/W           | MANUAL MODE SIGNAL                           |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | G/R           | CORNER SENSOR FRONT LH      |
| 4            | G/Y           | CORNER SENSOR FRONT RH      |
| 5            | G/R           | CORNER SENSOR REAR LH       |
| 6            | G/Y           | CORNER SENSOR REAR RH       |
| 12           | G/O           | SENSOR GND                  |
| 13           | V             | ACC                         |
| 18           | SB            | K LINE                      |
| 19           | SB            | AV COMM (H)                 |
| 20           | LG            | AV COMM (L)                 |
| 24           | B             | GND                         |

|                |               |
|----------------|---------------|
| Connector No.  | M50           |
| Connector Name | A/C AUTO AMP. |
| Connector Type | SAB40FW       |

|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

| Terminal No. | Color of Wire | Signal Name [Specification]                    |
|--------------|---------------|--|
| 1            | L             | CAN-H  |
| 2            | B             | GROUND   |
| 3            | Y/G           | BATTERY POWER SUPPLY                           |
| 4            | V             | ACC POWER SUPPLY                               |
| 5            | W             | IONIZER CONTROL SIGNAL                         |
| 6            | V/W           | A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL    |
| 7            | W/R           | AMBIENT SENSOR SIGNAL                          |
| 8            | GR/L          | RR IN-VEHICLE SENSOR SIGNAL                    |
| 9            | BR            | SUNLOAD SENSOR (DR) SIGNAL                     |
| 10           | V/W           | EXH GAS / OUTSIDE DOOR DETECTING SENSOR SIGNAL |
| 11           | W             | COMM (A/C AUTO AMP->RR A/C CONT)               |
| 14           | O/L           | RR BLOWER MOTOR CONTROL SIGNAL                 |

|    |      |                                   |
|----|------|-----------------------------------|
| 16 | R/G  | EACH DOOR MOTOR LIN SIGNAL        |
| 17 | L/Y  | EACH DOOR MOTOR POWER SUPPLY      |
| 21 | P    | CAN-L                             |
| 22 | B    | GROUND                            |
| 23 | GR/L | IGNITION POWER SUPPLY             |
| 25 | R    | —                                 |
| 26 | B    | SENSOR GROUND                     |
| 27 | GR   | FR IN-VEHICLE SENSOR SIGNAL       |
| 28 | R    | INTAKE SENSOR SIGNAL              |
| 29 | O    | SUNLOAD SENSOR (PASS) SIGNAL      |
| 31 | O/L  | COMM (RR A/C CONT->A/C AUTO AMP.) |
| 34 | L/O  | RR BLOWER MOTOR CONTROL SIGNAL    |
| 37 | B    | GROUND                            |
| 38 | G/W  | RR A/C RELAY CONTROL SIGNAL       |

|                |                               |
|----------------|-------------------------------|
| Connector No.  | M59                           |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNIT |
| Connector Type | NH28PY-EX                     |

|    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|
| 8  | 9  | 7  | 6  | 2  | 5  | 4  | 3  |
| 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 |
| 11 | 10 | 9  | 8  | 7  | 6  | 5  | 4  |
| 3  | 2  | 1  | 0  | 9  | 8  | 7  | 6  |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R/L           | IGN                         |
| 2            | B             | GND                         |
| 3            | Y             | DRI (+)                     |
| 4            | Y/R           | DRI (-) DR2 (-)             |
| 5            | Y/G           | DR 2 (+)                    |
| 8            | Y/L           | ASI (+)                     |
| 7            | Y/B           | ASI (-)                     |
| 9            | B/Y           | AS 2 (+)                    |
| 18           | O             | ECZ3 (+)                    |
| 19           | W             | ECZ3 (-)                    |
| 22           | SHIELD        | GND                         |
| 23           | R/W           | AIRBAG W/L                  |
| 24           | G/Y           | SEATBELT W/L                |
| 25           | R             | CUTOFF TELLTALE             |
| 59           | L             | CAN-H                       |
| 60           | P             | CAN-L                       |

|                |                           |
|----------------|---------------------------|
| Connector No.  | M68                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH                 |

|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | BR/Y          | COMBI SW INPUT 5            |
| 3            | GR            | COMBI SW INPUT 4            |
| 4            | L             | COMBI SW INPUT 3            |
| 5            | G             | COMBI SW INPUT 2            |
| 6            | V             | COMBI SW INPUT 1            |
| 8            | V             | POWER WINDOW SW COMM        |
| 9            | R             | STOP LAMP SW 1              |
| 11           | R             | L&R SENSOR SERIAL LINK      |
| 14           | P/B           | OPTICAL SENSOR              |
| 16           | L/O           | DIMMER SIGNAL               |
| 17           | Y/G           | SENSOR PWR SPLY             |
| 18           | B/Y           | RECEIVER/SENSOR GND         |
| 19           | BR            | RECEIVER PWR SPLY           |
| 20           | G/R           | KYLS ENT RECEIVER COMM      |
| 21           | P             | NATS ANT AMP                |
| 22           | W/B           | KYLS ENT RECEIVER RSSI      |
| 23           | GR/R          | SECURITY IND CONT           |
| 24           | SB            | DONGLE LINK                 |
| 25           | LG/R          | NATS ANT AMP                |
| 29           | W             | HAZARD SW                   |
| 30           | W/L           | BK DOOR OPNE SW             |
| 31           | W/G           | DR DOOR UNLOCK SENSOR       |
| 32           | LG            | COMBI SW OUTPUT 3           |
| 33           | Y             | COMBI SW OUTPUT 4           |
| 34           | W             | COMBI SW OUTPUT 3           |
| 35           | R/W           | COMBI SW OUTPUT 2           |
| 36           | SB            | COMBI SW OUTPUT 1           |
| 37           | G/Y           | SHIFT P                     |
| 39           | L             | CAN-H                       |
| 40           | P             | CAN-L                       |

JCAWM0364GB

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITH ICC)

|                |  |
|----------------|--|
| Connector No.  | M96                                    |
| Connector Name | LOW TIRE PRESSURE WARNING CONTROL UNIT |
| Connector Type | TH2FW-NH                               |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification]                    |
|--------------|---------------|--|
| 1            | P             | CAN-L  |
| 2            | L             | CAN-H  |
| 3            | O/L           | RR TIRE PRESSURE RECEIVER SIGNAL               |
| 4            | L             | RL TIRE PRESSURE RECEIVER SIGNAL               |
| 5            | R/L           | FR TIRE PRESSURE RECEIVER SIGNAL               |
| 6            | W/G           | FL TIRE PRESSURE RECEIVER SIGNAL               |
| 7            | SB            | RR TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 8            | GR            | RL TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 9            | R/W           | FR TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 10           | L/G           | FL TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 11           | GR            | IGN  |
| 12           | L/R           | RR TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 13           | P             | RL TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 14           | G/R           | FR TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 15           | BR/Y          | FL TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 16           | V/W           | RR TIRE PRESSURE RECEIVER GND                  |
| 17           | R/B           | RL TIRE PRESSURE RECEIVER GND                  |
| 18           | W/L           | FR TIRE PRESSURE RECEIVER GND                  |
| 19           | W/L           | FL TIRE PRESSURE RECEIVER GND                  |
| 20           | BR/W          | GND  |
| 21           | B             | GND  |

|                |             |
|----------------|-------------|
| Connector No.  | M125        |
| Connector Name | CAN GATEWAY |
| Connector Type | TH12FW-NH   |



|   |   |   |   |   |   |   |   |   |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
|---|---|---|---|---|---|---|---|---|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | L             | CAN-H                       |
| 2            | Y             | BATTERY                     |

|    |    |          |
|----|----|----------|
| 4  | L  | CAN-H    |
| 5  | B  | GND      |
| 6  | L  | CAN-H    |
| 7  | P  | CAN-L    |
| 8  | GR | IGNITION |
| 9  | R  | CAN-L    |
| 10 | B  | GND      |
| 11 | R  | CAN-L    |
| 12 | R  | CAN-L    |

|                |                  |
|----------------|------------------|
| Connector No.  | M135             |
| Connector Name | AFS CONTROL UNIT |
| Connector Type | TH40FW-NH        |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | GR            | IGN                         |
| 2            | LG/B          | PSG-R                       |
| 3            | GR/R          | SW                          |
| 4            | Y/R           | PSV-R                       |
| 5            | L/Y           | HSV-F                       |
| 6            | LG/R          | HSV-R                       |
| 7            | P             | CAN-L                       |
| 8            | B/O           | HSG-R                       |
| 9            | GR            | PS-R                        |
| 10           | B/W           | HSG-F                       |
| 11           | R             | SMR-2 (-)                   |
| 12           | B             | SMR-1 (-)                   |
| 13           | W             | SML-1 (+)                   |
| 14           | G             | SML-2 (+)                   |
| 15           | SB            | AMDS-R                      |
| 16           | V             | HS-F                        |
| 17           | L/O           | PSV-L                       |
| 18           | B             | GND                         |
| 19           | BR/Y          | PSG-L                       |
| 20           | R/G           | HS-R                        |
| 21           | BR/W          | PS-L                        |
| 22           | L             | CAN-H                       |
| 23           | G             | SMR-1 (+)                   |
| 24           | W             | SMR-2 (+)                   |
| 25           | R             | SML-2 (-)                   |
| 26           | B             | SML-1 (-)                   |
| 27           | GR/L          | AMDS-L                      |

|                |                 |
|----------------|-----------------|
| Connector No.  | M210            |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH2FW-NH        |



|    |    |    |    |    |    |    |    |    |    |    |    |    |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification]    |
|--------------|---------------|--------------------------------|
| 65           | W             | PARKING BRAKE SIGNAL           |
| 66           | R             | COMPOSITE IMAGE SIGNAL GND     |
| 67           | SHIELD        | COMPOSITE IMAGE SIGNAL         |
| 68           | Y/G           | MICROPHONE SHIELD              |
| 69           | Y/G           | MICROPHONE VCC                 |
| 70           | P             | COMM (CONT->DISP)              |
| 71           | LG            | CAN-L                          |
| 72           | LG            | AV COMM (L)                    |
| 73           | L/O           | DIMMER SIGNAL                  |
| 74           | GR/L          | IGNITION SIGNAL                |
| 75           | R/Y           | REVERSE SIGNAL                 |
| 76           | BR/W          | VEHICLE SPEED SIGNAL (3-PULSE) |
| 77           | SHIELD        | SHIELD                         |
| 78           | W/B           | COMPOSITE IMAGE SYNC SIGNAL    |
| 79           | Y/L           | MICROPHONE SIGNAL              |
| 80           | SHIELD        | SHIELD                         |
| 81           | Y/L           | COMM (DISP->CONT)              |
| 82           | L             | CAN-H                          |
| 83           | SB            | AV COMM (H)                    |
| 84           | SB            | AV COMM (H)                    |

|                |                  |
|----------------|------------------|
| Connector No.  | R8               |
| Connector Name | LANE CAMERA UNIT |
| Connector Type | TH08FW-NH        |




|   |   |   |   |   |   |    |    |    |    |    |    |
|---|---|---|---|---|---|----|----|----|----|----|----|
| 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
|---|---|---|---|---|---|----|----|----|----|----|----|

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | B             | GND                         |

## CONSULT-III CHECKING SYSTEM (WITHOUT ICC)

4W : 4WD models



★: This connector is not shown in "Harness Layout".

2010/05/13

JCAWM0366GB

GI

B

C

D

E

F

G

H

I

J

K

L

M

N


O

P



# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >




JCAWM0367GB

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >


## CONSULT-III CHECKING SYSTEM (WITHOUT ICC)

|                |                                    |
|----------------|------------------------------------|
| Connector No.  | B26                                |
| Connector Name | AUTOMATIC BACK DOOR CONTROL MODULE |
| Connector Type | TH20FW-TB8                         |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | L             | BUZZER                      |
| 2            | Y/B           | ABD SW                      |
| 4            | GR            | ABD CLOSE SW                |
| 6            | P             | CAN-H                       |
| 7            | L             | CAN-H                       |
| 8            | L/W           | HALF LATCH SW               |
| 9            | GR/L          | IGN                         |
| 10           | Y             | BAT                         |
| 11           | R             | CLOSURE MTR (CLOSE)         |
| 12           | V             | CLOSURE MTR (OPEN)          |
| 14           | G/W           | TOUCH SENS LH               |
| 15           | L/R           | TOUCH SENS GND              |
| 16           | LG            | TOUCH SENS RH               |
| 17           | O             | MAIN SW                     |
| 19           | L/Y           | CLOSE SW                    |
| 20           | G/Y           | OPEN SW                     |
| 22           | B             | GND                         |
| 23           | B             | GND                         |
| 26           | R/W           | BAT                         |
| 34           | B             | GND                         |


|                |                              |
|----------------|------------------------------|
| Connector No.  | B84                          |
| Connector Name | AIR LEVELIZER CONTROL MODULE |
| Connector Type | TH16FW-NH                    |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | B             | GND                         |
| 3            | V             | AIR COMPRESSOR RELAY        |


|    |     |                                    |
|----|-----|------------------------------------|
| 4  | L/W | VEHICLE HEIGHT SENSOR GND          |
| 5  | W   | VEHICLE HEIGHT SENSOR SIGNAL       |
| 7  | P   | CAN-H                              |
| 9  | P/L | IGN                                |
| 11 | V/L | EXHAUST SOLENOID                   |
| 13 | R   | VEHICLE HEIGHT SENSOR POWER SUPPLY |
| 16 | L   | CAN-H                              |

|                |  |
|----------------|--|
| Connector No.  | B246                                   |
| Connector Name | OCCUPANT DETECTION SYSTEM CONTROL UNIT |
| Connector Type | TH04FW-NH                              |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | W             | -                           |
| 2            | B             | -                           |
| 3            | L/R           | -                           |
| 4            | R/L           | -                           |


|                |                          |
|----------------|--------------------------|
| Connector No.  | B451                     |
| Connector Name | DRIVER SEAT CONTROL UNIT |
| Connector Type | TH43FW-NH                |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R/Y           | CAN-H                       |
| 2            | R             | UART (TX/RX)                |
| 4            | R/L           | PULSE (RECLINER)            |
| 5            | R/B           | TELESCOPIC SENSOR           |
| 6            | R/W           | ADDRESS 2                   |
| 7            | R/G           | IND-2                       |
| 8            | SB            | SLIDE SW (BACKWARD)         |
| 9            | L             | RECLINER SW (BACKWARD)      |
| 10           | L/B           | FRONT LIFTER SW (DOWNWARD)  |


|    |     |                           |
|----|-----|---------------------------|
| 11 | L/W | REAR LIFTER SW (DOWNWARD) |
| 12 | L/R | SENSOR POWER SUPPLY       |
| 17 | V   | CAN-H                     |
| 18 | B/W | PULSE (SLIDE)             |
| 19 | B/R | PULSE (FRONT LIFTER)      |
| 20 | B/L | PULSE (REAR LIFTER)       |
| 21 | W/B | TILT SENSOR               |
| 22 | W/L | ADDRESS 1                 |
| 23 | W/R | IND-1                     |
| 24 | V/W | SLIDE SW (FORWARD)        |
| 25 | Y/B | RECLINER SW (FORWARD)     |
| 26 | Y/R | FRONT LIFTER SW (UPWARD)  |
| 27 | Y/L | REAR LIFTER SW (UPWARD)   |
| 28 | G   | SET SW                    |

|                |   |
|----------------|---|
| Connector No.  | E13   |
| Connector Name | ENGINE ROOM INTELLIGENT POWER DISTRIBUTION MODULE |
| Connector Type | TH12FW-NH   |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 23           | GR/R          | -                           |
| 24           | W/G           | -                           |
| 25           | L/Y           | -                           |
| 26           | P             | -                           |
| 27           | L             | -                           |
| 30           | R/W           | -                           |
| 31           | B             | -                           |
| 32           | LG            | -                           |
| 33           | R             | -                           |
| 34           | P/B           | -                           |

|                |   |
|----------------|---|
| Connector No.  | E36   |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Type | SAZ42FB-SJ24                                  |



| Terminal No. | Color of Wire | Signal Name [Specification]                   |
|--------------|---------------|---|
| 1            | G             | BAT   |
| 2            | B             | GND   |
| 3            | B             | GND   |
| 4            | W             | MOTOR SUPPLY                                  |
| 9            | P/B           | YAW RATE / SDC / DECEL G SENSOR COMMUNICATION |
| 10           | P/B           | YAW RATE / SDC / DECEL G SENSOR COMMUNICATION |
| 13           | GR            | BRAKE FLUID LEVEL SW                          |
| 17           | L/R           | STP2  |
| 18           | W/B           | IGN   |
| 19           | O             | DS FR   |
| 20           | SB            | DP FL   |
| 21           | R/Y           | DS RR   |
| 22           | V             | DP RL   |
| 27           | P             | CAN-L   |
| 33           | LG            | DP FR   |
| 34           | G             | DS FL   |
| 35           | BR            | DP RR   |
| 36           | P             | DS RL   |
| 37           | R             | STP   |
| 39           | L/W           | VDC OFF SW                                    |
| 41           | L             | CAN-H   |
| 46           | W             | STOP LAMP SW ON                               |

GI B C D E F G H I J K L M N O P

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITHOUT ICC)


|                |                       |
|----------------|-----------------------|
| Connector No.  | E59                   |
| Connector Name | TRANSFER CONTROL UNIT |
| Connector Type | TH40FW-NH             |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |    |     |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 | 41 | 42 | 43 | 44 | 45 | 46 | 47 | 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 | 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | 81 | 82 | 83 | 84 | 85 | 86 | 87 | 88 | 89 | 90 | 91 | 92 | 93 | 94 | 95 | 96 | 97 | 98 | 99 | 100 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|-----|


| Terminal No. | Color of Wire | Signal Name [Specification]    |
|--------------|---------------|--------------------------------|
| 6            | BR            | HI-LO POSITION SEN 1           |
| 7            | Y             | TRANSFER FLUID TEMP SEN SUPPLY |
| 9            | G             | INTERNAL SPEED SEN GND         |
| 10           | Y/G           | INTERNAL SPEED SEN IMP         |
| 11           | V             | 4LO SW                         |
| 12           | L             | CAN-H                          |
| 13           | P             | CAN-L                          |
| 14           | W/R           | AUTO SW                        |
| 15           | P/B           | ROTARY POSITION SEN PWM        |
| 16           | LG            | ROTARY POSITION SEN GND        |
| 17           | W/L           | LOCK POSITION SEN SUPPLY       |
| 18           | BR/Y          | ROTARY POSITION SEN SUPPLY     |
| 20           | GR            | TRANSFER C/U SUPPLY            |
| 25           | P/L           | HI-LO POSITION SEN 3           |
| 28           | W             | MOTOR TEMP SEN SUPPLY          |
| 29           | LG/R          | HI-LO POSITION SEN 2           |
| 30           | R/B           | LOCK POSITION SEN GND          |
| 31           | L/O           | INT SPEED SEN DIR              |
| 32           | BR/R          | IGN                            |
| 35           | R             | LOCK SW                        |
| 36           | L/R           | TRANSFER FLUID TEMP SEN GND    |
| 38           | G/O           | LOCK POSITION SEN SIGNAL       |
| 39           | R/W           | INTERNAL SPEED SEN SUPPLY      |

|                |                  |
|----------------|------------------|
| Connector No.  | E60              |
| Connector Name | ECM              |
| Connector Type | MAB55FB-MEB10-LH |




| Terminal No. | Color of Wire | Signal Name [Specification]                                     |
|--------------|---------------|---|
| 111          | R             | FUEL INJECTOR DRIVER POWER SUPPLY                               |
| 112          | SB            | FUEL INJECTOR DRIVER POWER SUPPLY                               |
| 113          | G             | FUEL RETURN VALVE   |
| 114          | B             | ECM GROUND  |
| 115          | B             | ECM GROUND  |
| 120          | Y             | EVAP CANISTER VENT CONTROL VALVE                                |
| 122          | BR/W          | VALVE INJECTOR MOTOR RELAY ADJUST SIGNAL VOLTAGE CONTROL MODULE |
| 123          | V/R           | THROTTLE CONTROL MOTOR RELAY                                    |
| 125          | GR            | FUEL PUMP CONTROL MODULE (FPCM)                                 |
| 126          | O             | ACCELERATOR PEDAL POSITION SENSOR 2                             |
| 128          | Y             | ICC STEERING SWITCH   |
| 129          | P/L           | SENSOR GROUND (APP SENSOR 2)                                    |
| 130          | R             | SENSOR GROUND   |
| 131          | L/W           | SENSOR POWER SUPPLY   |
| 133          | SB            | SENSOR POWER SUPPLY   |
| 134          | V/W           | TF  |
| 136          | W/R           | ACCELERATOR PEDAL POSITION SENSOR 1                             |
| 137          | W/G           | SENSOR POWER SUPPLY (APP SENSOR 1)                              |
| 138          | V             | BATTERY CURRENT SENSOR  |
| 139          | G             | BATTERY TEMPERATURE SENSOR                                      |
| 140          | R/Y           | SENSOR GROUND   |
| 141          | SB            | IGNITION SWITCH   |
| 142          | R/W           | FUEL PUMP CONTROL MODULE (FPCM) CHECK                           |
| 143          | L/Y           | EVAP CONTROL SYSTEM PRESSURE SENSOR                             |
| 144          | O/B           | REFRIGERANT PRESSURE SENSOR                                     |
| 146          | L             | CAN COMMUNICATION LINE  |
| 147          | G/Y           | ICC BRAKE SWITCH  |
| 150          | R             | CAN COMMUNICATION LINE  |
| 151          | P             | CAN COMMUNICATION LINE  |
| 156          | L             | POWER SUPPLY FOR ECM (BACK-UP)                                  |
| 158          | W/B           | STOP LAMP SWITCH  |
| 161          | R/W           | ECM COMMUNICATION LINE  |
| 163          | L/G           | ECM RELAY (SELF SHUT-OFF)                                       |
| 165          | GR/R          | ECM RELAY (SELF SHUT-OFF)                                       |
| 166          | W             | ECM COMMUNICATION LINE  |
| 169          | G/B           | ENGINE SPEED SIGNAL OUTPUT                                      |
| 171          | W             | POWER SUPPLY FOR ECM  |
| 172          | W             | POWER SUPPLY FOR ECM  |
| 173          | O             | THROTTLE CONTROL MOTOR POWER SUPPLY                             |
| 174          | B             | ECM GROUND  |
| 175          | B             | ECM GROUND  |

|                |              |
|----------------|--------------|
| Connector No.  | F51          |
| Connector Name | A-T ASSEMBLY |
| Connector Type | RK0FG        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | V             | -                           |
| 2            | P             | -                           |
| 3            | L             | -                           |
| 4            | SB            | -                           |
| 5            | B             | -                           |
| 6            | V             | -                           |
| 7            | R             | -                           |
| 8            | P             | -                           |
| 9            | BR            | -                           |
| 10           | B             | -                           |

|                |                                   |
|----------------|-----------------------------------|
| Connector No.  | F301                              |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Type | SP10FG                            |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | -             | VGN                         |
| 2            | -             | BATT                        |
| 3            | -             | CAN-H                       |
| 4            | -             | K LINE                      |
| 5            | -             | GND                         |
| 6            | -             | VGN                         |
| 7            | -             | REV LAMP RLY                |
| 8            | -             | CAN-L                       |
| 9            | -             | START RLY                   |
| 10           | -             | GND                         |

|                |                  |
|----------------|------------------|
| Connector No.  | M1               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS30FW-M2        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A           | Y             | -                           |
| 2A           | GR            | -                           |
| 3A           | W             | -                           |
| 4A           | Y/G           | -                           |
| 5A           | V             | -                           |
| 6A           | L/W           | -                           |
| 7A           | LG            | -                           |
| 8A           | W             | -                           |

|                |                  |
|----------------|------------------|
| Connector No.  | M2               |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS        |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1B           | R             | -                           |
| 3B           | R             | -                           |
| 4B           | B             | -                           |
| 5B           | BR            | -                           |
| 6B           | Y             | -                           |
| 7B           | G             | -                           |
| 8B           | L/O           | -                           |
| 10B          | W/B           | -                           |


JCAWM0369GB

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >


## CONSULT-III CHECKING SYSTEM (WITHOUT ICC)

|                |                     |
|----------------|---------------------|
| Connector No.  | M4                  |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16FW              |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | LG            | -                           |
| 4            | B             | -                           |
| 5            | B             | -                           |
| 6            | L             | -                           |
| 7            | SB            | -                           |
| 8            | GR            | -                           |
| 11           | SB            | -                           |
| 12           | R             | -                           |
| 13           | L             | -                           |
| 14           | P             | -                           |
| 16           | Y             | -                           |


|                |                   |
|----------------|-------------------|
| Connector No.  | M34               |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH         |



| Terminal No. | Color of Wire | Signal Name [Specification]            |
|--------------|---------------|--|
| 1            | Y             | BATTERY POWER SUPPLY                   |
| 2            | GR            | IGNITION SIGNAL                        |
| 3            | B             | GROUND                                 |
| 4            | B             | GROUND                                 |
| 5            | B             | ILL GND                                |
| 7            | R             | TOW MODE SIGNAL                        |
| 8            | P/L           | TRIP RESET SWITCH SIGNAL               |
| 11           | G             | ENTER SWITCH SIGNAL                    |
| 12           | O             | SELECT SWITCH SIGNAL                   |
| 13           | W/R           | ILLUMINATION CONTROL SWITCH SIGNAL (+) |
| 14           | R             | ILLUMINATION CONTROL SWITCH SIGNAL (-) |

|    |      |  |
|----|------|--|
| 15 | R/W  | AIR BAG SIGNAL                               |
| 18 | W/R  | AMBIENT SENSOR SIGNAL                        |
| 19 | V/W  | A/C AUTO AMP CONNECTION SIGNAL               |
| 20 | B    | AMBIENT SENSOR GROUND                        |
| 21 | L    | CAN-H  |
| 22 | P    | CAN-L  |
| 23 | B    | GROUND                                       |
| 24 | V    | FUEL LEVEL SENSOR GROUND                     |
| 25 | O/L  | ALTERNATOR SIGNAL                            |
| 26 | W    | PARKING BRAKE SWITCH SIGNAL                  |
| 28 | GR/R | SECURITY SIGNAL                              |
| 29 | BR   | WASHER LEVEL SWITCH SIGNAL                   |
| 30 | SB   | VEHICLE SPEED SIGNAL (2-PULSE)               |
| 31 | BR/W | VEHICLE SPEED SIGNAL (8-PULSE)               |
| 33 | W    | SNOW MODE SIGNAL                             |
| 34 | BR/Y | FUEL LEVEL SENSOR SIGNAL                     |
| 35 | O/B  | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 36 | G/Y  | PASSENGER SEAT BELT WARNING SIGNAL           |
| 37 | R/Y  | NON-MANUAL MODE SIGNAL                       |
| 38 | L/W  | MANUAL MODE SHIFT DOWN SIGNAL                |
| 39 | Y/B  | MANUAL MODE SHIFT UP SIGNAL                  |
| 40 | G/W  | MANUAL MODE SIGNAL                           |

|                |                    |
|----------------|--------------------|
| Connector No.  | M47                |
| Connector Name | SONAR CONTROL UNIT |
| Connector Type | TH24FW-NH          |




| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3            | G/R           | CORNER SENSOR FRONT LH      |
| 4            | G/Y           | CORNER SENSOR FRONT RH      |
| 5            | G/R           | CORNER SENSOR REAR LH       |
| 6            | G/Y           | CORNER SENSOR REAR RH       |
| 12           | G/O           | SENSOR GND                  |
| 13           | V             | ACC                         |
| 18           | SB            | K LINE                      |
| 19           | SB            | AV COMM (H)                 |
| 20           | LG            | AV COMM (L)                 |
| 24           | B             | GND                         |

|                |              |
|----------------|--------------|
| Connector No.  | M50          |
| Connector Name | A/C AUTO AMP |
| Connector Type | SAB40FW      |



| Terminal No. | Color of Wire | Signal Name [Specification]                     |
|--------------|---------------|---|
| 1            | L             | CAN-H   |
| 2            | B             | GROUND  |
| 3            | Y/G           | BATTERY POWER SUPPLY                            |
| 4            | V             | ACC POWER SUPPLY                                |
| 5            | W             | IONIZER CONTROL SIGNAL                          |
| 6            | V/W           | A/C AUTO AMP CONNECTION SIGNAL                  |
| 7            | W/R           | AMBIENT SENSOR SIGNAL                           |
| 8            | GR/L          | RR IN-VEHICLE SENSOR SIGNAL                     |
| 9            | BR            | SUNLOAD SENSOR (DRY) SIGNAL                     |
| 10           | V/W           | EVAP GAS / OUTSIDE DOOR DETECTING SENSOR SIGNAL |
| 11           | W             | COMM A/C AUTO AMP->RR A/C CONT                  |
| 14           | O/L           | FR BLOWER MOTOR CONTROL SIGNAL                  |
| 16           | R/G           | EACH DOOR MOTOR POWER SUPPLY                    |
| 17           | L/Y           | EACH DOOR MOTOR POWER SUPPLY                    |
| 21           | P             | CAN-L   |
| 22           | B             | GROUND  |
| 23           | GR/L          | IGNITION POWER SUPPLY                           |
| 25           | R             | -   |
| 26           | B             | SENSOR GROUND                                   |
| 27           | GR            | FR IN-VEHICLE SENSOR SIGNAL                     |
| 28           | R             | INTAKE SENSOR SIGNAL                            |
| 29           | O             | SUNLOAD SENSOR (PASS) SIGNAL                    |
| 31           | O/L           | COMM RR A/C CONT->A/C AUTO AMP                  |
| 34           | L/O           | FR BLOWER MOTOR CONTROL SIGNAL                  |
| 37           | B             | GROUND  |
| 38           | G/W           | RR A/C RELAY CONTROL SIGNAL                     |

|                |                               |
|----------------|-------------------------------|
| Connector No.  | M59                           |
| Connector Name | AIR BAG DIAGNOSIS SENSOR UNIT |
| Connector Type | NH2FY-EX                      |



| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1            | R/L           | IGN                         |
| 2            | B             | GND                         |
| 3            | Y             | DR1 (+)                     |
| 4            | Y/R           | DR1 (-) DR2 (+)             |
| 5            | Y/G           | DR2 (-)                     |
| 6            | Y/L           | AS1 (+)                     |
| 7            | Y/B           | AS1 (-)                     |
| 8            | B/Y           | AS2 (+)                     |
| 9            | Y             | AS2 (-)                     |
| 18           | O             | ECZS (+)                    |
| 19           | W             | ECZS (-)                    |
| 22           | SHIELD        | GND                         |
| 23           | R/W           | AIRBAG W/L                  |
| 24           | G/Y           | SEATBELT W/L                |
| 25           | R             | CUTOFF TELLTALE             |
| 59           | L             | CAN-H                       |
| 60           | P             | CAN-L                       |

JCAWM0370GB

GI  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# CONSULT-III/GST CHECKING SYSTEM

< BASIC INSPECTION >

## CONSULT-III CHECKING SYSTEM (WITHOUT ICC)

|                |                           |
|----------------|---------------------------|
| Connector No.  | M68                       |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH                 |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |

|                |  |
|----------------|--|
| Connector No.  | M66                                    |
| Connector Name | LOW TIRE PRESSURE WARNING CONTROL UNIT |
| Connector Type | TH42FW-NH                              |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2            | BR/Y          | COMBI SW INPUT 5            |
| 3            | GR            | COMBI SW INPUT 4            |
| 4            | L             | COMBI SW INPUT 3            |
| 5            | G             | COMBI SW INPUT 2            |
| 6            | V             | COMBI SW INPUT 1            |
| 8            | V             | POWER WINDOW SW COMM        |
| 9            | R             | STOP LAMP SW 1              |
| 11           | R             | L&R SENSOR SERIAL LINK      |
| 14           | P/B           | OPTICAL SENSOR              |
| 16           | L/O           | DIMMER SIGNAL               |
| 17           | Y/G           | SENSOR PWR SPLY             |
| 18           | B/Y           | RECEIVER SENSOR GND         |
| 19           | BR            | RECEIVER PWR SPLY           |
| 20           | G/R           | KYLS ENT RECEIVER COMM      |
| 21           | P             | NATS ANT AMP                |
| 22           | W/B           | KYLS ENT RECEIVER RSSI      |
| 23           | GR/R          | SECURITY IND CONT           |
| 24           | SB            | DONGLE LINK                 |
| 25           | LG/R          | NATS ANT AMP                |
| 29           | W             | HAZARD SW                   |
| 30           | W/L           | BK DOOR OPNR SW             |
| 31           | W/L           | DR DOOR UNLOCK SENSOR       |
| 32           | LG            | COMBI SW OUTPUT 5           |
| 33           | Y             | COMBI SW OUTPUT 4           |
| 34           | W             | COMBI SW OUTPUT 3           |
| 35           | R/W           | COMBI SW OUTPUT 2           |
| 36           | SB            | COMBI SW OUTPUT 1           |
| 37           | G/Y           | SHIFT P                     |
| 39           | L             | CAN-H                       |
| 40           | P             | CAN-L                       |

| Terminal No. | Color of Wire | Signal Name [Specification]                    |
|--------------|---------------|--|
| 1            | P             | CAN-L  |
| 2            | L             | CAN-H  |
| 3            | O/L           | RR TIRE PRESSURE RECEIVER SIGNAL               |
| 4            | L             | RL TIRE PRESSURE RECEIVER SIGNAL               |
| 5            | R/L           | FR TIRE PRESSURE RECEIVER SIGNAL               |
| 6            | W/G           | FL TIRE PRESSURE RECEIVER SIGNAL               |
| 7            | SB            | RR TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 8            | GR            | RL TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 9            | R/W           | FR TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 10           | LG            | FL TIRE PRESSURE RECEIVER POWER SUPPLY         |
| 15           | GR            | IGN  |
| 19           | L/R           | RR TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 21           | G/R           | RL TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 22           | BR/Y          | FR TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 23           | V/W           | FL TIRE PRESSURE RECEIVER SIGNAL (SENSITIVITY) |
| 24           | R/B           | RR TIRE PRESSURE RECEIVER GND                  |
| 25           | W/L           | RL TIRE PRESSURE RECEIVER GND                  |
| 26           | BR/W          | FR TIRE PRESSURE RECEIVER GND                  |
| 32           | B             | FL TIRE PRESSURE RECEIVER GND                  |

|                |                 |
|----------------|-----------------|
| Connector No.  | M210            |
| Connector Name | AV CONTROL UNIT |
| Connector Type | TH42FW-NH       |



|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |

| Terminal No. | Color of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 65           | W             | PARKING BRAKE SIGNAL        |
| 67           | W             | COMPOSITE IMAGE SIGNAL GND  |

|    |        |                                |
|----|--------|--------------------------------|
| 68 | R      | COMPOSITE IMAGE SIGNAL         |
| 71 | SHIELD | MICROPHONE SHIELD              |
| 72 | Y/G    | MICROPHONE VCC                 |
| 73 | Y/G    | COMM (CONT->DISP)              |
| 74 | P      | CAN-L                          |
| 75 | LG     | AV COMM (L)                    |
| 76 | LG     | AV COMM (L)                    |
| 79 | L/O    | DIMMER SIGNAL                  |
| 80 | GR/L   | IGNITION SIGNAL                |
| 81 | R/Y    | REVERSE SIGNAL                 |
| 82 | BR/W   | VEHICLE SPEED SIGNAL (3-PULSE) |
| 83 | SHIELD | SHIELD                         |
| 84 | W/B    | COMPOSITE IMAGE SYNC SIGNAL    |
| 87 | Y/L    | MICROPHONE SIGNAL              |
| 88 | SHIELD | SHIELD                         |
| 89 | Y/L    | COMM (DISP->CONT)              |
| 90 | L      | CAN-H                          |
| 91 | SB     | AV COMM (H)                    |
| 92 | SB     | AV COMM (H)                    |

JCAWM0371GB

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Required Procedure After Battery Disconnection

INFOID:000000006344676

| SYSTEM                                  | ITEM  | REFERENCE  |
|---|---|--|
| Front automatic air conditioning system | Temperature setting trimmer (Front)   | <a href="#">HAC-68, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Front)"</a>  |
|   | Foot position setting trimmer   | <a href="#">HAC-68, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Foot Position Setting Trimmer"</a>  |
|   | Inlet port memory function*   | —  |
|   | Inlet port memory function (FRE)  | <a href="#">HAC-69, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (FRE)"</a>   |
|   | Inlet port memory function (REC)  | <a href="#">HAC-69, "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : Inlet Port Memory Function (REC)"</a>   |
| ACCS (Advanced Climate Control System)  | Exhaust gas / outside odor detecting sensor sensitivity adjustment function | <a href="#">HAC-70, "ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Exhaust Gas / Outside Odor Detecting Sensor Sensitivity Adjustment Function"</a> |
|   | Auto intake switch interlocking movement change function                    | <a href="#">HAC-70, "ACCS (ADVANCED CLIMATE CONTROL SYSTEM) : Auto Intake Switch Interlocking Movement Change Function"</a>                    |
|   | Clean switch interlocking movement change function*                         | —  |
| Rear automatic air conditioning system  | Temperature setting trimmer (Rear)  | <a href="#">HAC-69, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : Temperature Setting Trimmer (Rear)"</a>  |
| Automatic drive positioner              | Automatic drive positioner system   | <a href="#">ADP-51, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"</a>   |
| Power window control                    | Power window control system   | <a href="#">PWC-31, "Description"</a>  |
| Sunroof system*                         | Sunroof system  | —  |
| Sunshade system*                        | Sunshade system   | —  |
| Rear view monitor*                      | Rear view monitor predictive course line center position adjustment         | —  |
| Around view monitor                     | Predictive course line center position adjustment                           | <a href="#">AV-111, "Description"</a>  |
| Automatic back door system              | Automatic back door system  | <a href="#">DLK-80, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"</a>   |
| Engine oil level read*                  | Engine oil level read   | —  |

\*: Not equipped.

# SECTION **EM**

## ENGINE MECHANICAL

### CONTENTS

|  |    |   |    |
|--|----|---|----|
| <b>PRECAUTION</b> .....  | 3  | Use the Chart Below to Help You Find the Cause of the Symptom ..... | 19 |
| <b>PRECAUTIONS</b> .....   | 3  | <b>PERIODIC MAINTENANCE</b> .....                                   | 20 |
| Precaution for Procedure without Cowl Top Cover.....   | 3  | <b>DRIVE BELTS</b> .....  | 20 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 3  | Exploded View .....   | 20 |
| Precaution Necessary for Steering Wheel Rotation after Battery Disconnect .....                  | 3  | Checking .....  | 20 |
| Precaution for Drain Engine Coolant and Engine Oil .....   | 4  | Tension Adjustment .....  | 20 |
| Precaution for Disconnecting Fuel Piping .....   | 4  | Removal and Installation .....                                      | 20 |
| Precaution for Handling High Pressure Fuel System .....  | 4  | Inspection .....  | 21 |
| Precaution for Removal and Disassembly .....   | 4  | <b>AIR CLEANER FILTER</b> .....                                     | 22 |
| Precaution for Inspection, Repair and Replacement .....  | 4  | Exploded View .....   | 22 |
| Precaution for Assembly and Installation .....   | 4  | Removal and Installation .....                                      | 22 |
| Parts Requiring Angle Tightening .....   | 5  | <b>SPARK PLUG</b> .....   | 23 |
| Precaution for Liquid Gasket .....   | 5  | Exploded View .....   | 23 |
| Definitions of Bank Names .....  | 6  | Removal and Installation .....                                      | 23 |
| <b>PREPARATION</b> .....   | 7  | Inspection .....  | 24 |
| <b>PREPARATION</b> .....   | 7  | <b>REMOVAL AND INSTALLATION</b> .....                               | 25 |
| Special Service Tool .....   | 7  | <b>ENGINE COVER</b> .....   | 25 |
| Commercial Service Tool .....  | 9  | Exploded View .....   | 25 |
| <b>BASIC INSPECTION</b> .....  | 12 | Removal and Installation .....                                      | 25 |
| <b>CAMSHAFT VALVE CLEARANCE</b> .....  | 12 | <b>DRIVE BELT AUTO TENSIONER AND IDLER PULLEY</b> .....             | 26 |
| Inspection .....   | 12 | Exploded View .....   | 26 |
| <b>COMPRESSION PRESSURE</b> .....  | 16 | Removal and Installation .....                                      | 26 |
| Inspection .....   | 16 | <b>AIR CLEANER AND AIR DUCT</b> .....                               | 27 |
| <b>SYMPTOM DIAGNOSIS</b> .....   | 18 | Exploded View .....   | 27 |
| <b>NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING</b> .....                                | 18 | Removal and Installation .....                                      | 27 |
| NVH Troubleshooting - Engine Noise .....   | 18 | Inspection .....  | 28 |
|  |    | <b>IGNITION COIL</b> .....  | 29 |
|  |    | Exploded View .....   | 29 |
|  |    | Removal and Installation .....                                      | 29 |
|  |    | <b>INTAKE MANIFOLD</b> .....  | 30 |
|  |    | Exploded View .....   | 30 |

|   |           |   |            |
|---|-----------|---|------------|
| Removal and Installation .....                | 30        | Inspection .....                                | 92         |
| <b>ROCKER COVER .....</b>                     | <b>33</b> | <b>OIL SEAL .....</b>                           | <b>96</b>  |
| Exploded View .....                           | 33        | <b>FRONT OIL SEAL .....</b>                     | <b>96</b>  |
| Removal and Installation .....                | 33        | FRONT OIL SEAL : Removal and Installation ..... | 96         |
| <b>VVEL ACTUATOR ASSEMBLY .....</b>           | <b>36</b> | <b>REAR OIL SEAL .....</b>                      | <b>96</b>  |
| Exploded View .....                           | 36        | REAR OIL SEAL : Removal and Installation .....  | 97         |
| Removal and Installation .....                | 36        | <b>UNIT REMOVAL AND INSTALLATION ....</b>       | <b>98</b>  |
| Inspection .....                              | 39        | <b>ENGINE ASSEMBLY .....</b>                    | <b>98</b>  |
| <b>EXHAUST MANIFOLD AND THREE WAY</b>         |           | Exploded View .....                             | 98         |
| <b>CATALYST .....</b>                         | <b>40</b> | Removal and Installation .....                  | 99         |
| Exploded View .....                           | 40        | Inspection .....                                | 102        |
| Removal and Installation .....                | 40        | <b>UNIT DISASSEMBLY AND ASSEMBLY ..</b>         | <b>103</b> |
| Inspection .....                              | 42        | <b>ENGINE STAND SETTING .....</b>               | <b>103</b> |
| <b>HIGH PRESSURE FUEL PUMP AND FUEL</b>       |           | Setting .....                                   | 103        |
| <b>HOSE .....</b>                             | <b>43</b> | <b>ENGINE UNIT .....</b>                        | <b>105</b> |
| Exploded View .....                           | 43        | Disassembly .....                               | 105        |
| Removal and Installation .....                | 43        | Assembly .....                                  | 105        |
| Inspection .....                              | 46        | <b>CYLINDER BLOCK .....</b>                     | <b>106</b> |
| <b>FUEL INJECTOR AND FUEL TUBE .....</b>      | <b>48</b> | Exploded View .....                             | 106        |
| Exploded View .....                           | 48        | Disassembly and Assembly .....                  | 107        |
| Removal and Installation .....                | 49        | Inspection .....                                | 115        |
| Inspection .....                              | 53        | <b>HOW TO SELECT PISTON AND BEARING ..</b>      | <b>125</b> |
| <b>OIL PAN (LOWER) AND OIL STRAINER .....</b> | <b>54</b> | Description .....                               | 125        |
| Exploded View .....                           | 54        | Piston .....                                    | 125        |
| Removal and Installation .....                | 55        | Connecting Rod Bearing .....                    | 126        |
| Inspection .....                              | 56        | Main Bearing .....                              | 128        |
| <b>OIL PAN (UPPER) .....</b>                  | <b>57</b> | <b>SERVICE DATA AND SPECIFICATIONS</b>          |            |
| Exploded View .....                           | 57        | <b>(SDS) .....</b>                              | <b>132</b> |
| Removal and Installation .....                | 58        | <b>SERVICE DATA AND SPECIFICATIONS</b>          |            |
| Inspection .....                              | 60        | <b>(SDS) .....</b>                              | <b>132</b> |
| <b>TIMING CHAIN .....</b>                     | <b>61</b> | General Specification .....                     | 132        |
| Exploded View .....                           | 61        | Drive Belts .....                               | 132        |
| Removal and Installation .....                | 62        | Spark Plug .....                                | 132        |
| Inspection .....                              | 72        | Exhaust Manifold .....                          | 133        |
| <b>CAMSHAFT .....</b>                         | <b>74</b> | Camshaft .....                                  | 133        |
| Exploded View .....                           | 74        | Cylinder Head .....                             | 135        |
| Removal and Installation .....                | 75        | Cylinder Block .....                            | 137        |
| Inspection .....                              | 77        | Main Bearing .....                              | 141        |
| <b>CYLINDER HEAD .....</b>                    | <b>86</b> | Connecting Rod Bearing .....                    | 142        |
| Exploded View .....                           | 86        |   |            |
| Removal and Installation .....                | 87        |   |            |
| Disassembly and Assembly .....                | 89        |   |            |



## PRECAUTIONS

< PRECAUTION >


### PRECAUTION

#### PRECAUTIONS

##### Precaution for Procedure without Cowl Top Cover

INFOID:000000006289506

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



##### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006417202

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

##### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

##### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

##### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

##### Precaution Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:000000006289508

##### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

For vehicle with steering lock unit, if the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

# PRECAUTIONS

## < PRECAUTION >

If turning the steering wheel is required with the battery disconnected or discharged, follow the operation procedure below before starting the repair operation.

### OPERATION PROCEDURE

1. Connect both battery cables.

**NOTE:**

Supply power using jumper cables if battery is discharged.

2. Turn the push-button ignition switch to ACC position.  
(At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.
5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
6. Perform self-diagnosis check of all control units using CONSULT-III.

### Precaution for Drain Engine Coolant and Engine Oil

INFOID:000000006289509

Drain engine coolant and engine oil when engine is cooled.

### Precaution for Disconnecting Fuel Piping

INFOID:000000006289510

- Before starting work, check no fire or spark producing items are in the work area.
- Release fuel pressure before disconnecting and disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

### Precaution for Handling High Pressure Fuel System

INFOID:000000006289511

- High pressure fuel system components are between high pressure fuel pump and fuel injector.
- Always release fuel pressure and never start the engine when performing removal and installation.
- When removing or installing parts without releasing fuel pressure, fuel may be splashed and, if fuel contacts skin or eyes, it may cause inflammation.

### Precaution for Removal and Disassembly

INFOID:000000006289512

- When instructed to use SST, use specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Cover openings of engine system with tape or the equivalent, if necessary, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and assembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used where noted in the step.

### Precaution for Inspection, Repair and Replacement

INFOID:000000006289513

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

### Precaution for Assembly and Installation

INFOID:000000006289514

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check engine oil or engine coolant passages for any restriction and blockage.
- Dowel pins are used for several parts alignment. When replacing and reassembling parts with dowel pins, check that dowel pins are installed in the original position.

## PRECAUTIONS

### < PRECAUTION >

- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- Release air within route when refilling after draining engine coolant.
- After repairing, start engine and increase engine speed to check engine coolant, fuel, engine oil, and exhaust gases for leakage.

### Parts Requiring Angle Tightening

INFOID:000000006289515

- Use angle wrench [SST: KV10112100 (BT8653-A)] for the final tightening of the following engine parts:
  - Cylinder head bolts
  - Main bearing cap bolts
  - Main bearing cap sub bolts
  - Connecting rod cap bolts
  - Crankshaft pulley bolt (No angle wrench is required as the bolt flange is provided with notches for angle tightening)
- Ensure thread and seat surfaces are clean and coated with engine oil.

### Precaution for Liquid Gasket

INFOID:000000006289516

#### REMOVAL OF LIQUID GASKET SEALING

- After removing mounting nuts and bolts, separate the mating surface using the seal cutter [SST:KV10111100 (J-37228)] (A) and remove old liquid gasket sealing.


#### CAUTION:

**Be careful not to damage the mating surfaces.**

- Tap the seal cutter to insert it (B), and then slide it (C) by tapping on the side as shown in the figure.
- In areas where the seal cutter is difficult to use, lightly tap the parts using a plastic hammer to remove it.


#### CAUTION:

**If for some unavoidable reason a tool such as a screwdriver is used, be careful not to damage the mating surfaces.**



#### LIQUID GASKET APPLICATION PROCEDURE


1. Using a scraper (A), remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
  - Remove liquid gasket completely from the groove of the liquid gasket application surface, mounting bolts and bolt holes.
2. Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.



3. Attach liquid gasket tube to the tube presser (commercial service tool).

**Use Genuine RTV Silicone Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).**

4. Apply liquid gasket without gaps to the specified location according to the specified dimensions.
  - If there is a groove for liquid gasket application, apply liquid gasket to the groove.



# PRECAUTIONS

## < PRECAUTION >

- As for bolt holes (B), normally apply liquid gasket inside the holes. Occasionally, it should be applied outside the holes. Check to read the text of this manual.


A : Groove

⇐ : Inside

- Within 5 minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten mounting bolts or nuts after the installation.
- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.

### CAUTION:

**If there are specific instructions in this manual, observe them.**



## Definitions of Bank Names

INFOID:000000006289517

- In this manual, each bank name is defined as per the following:

A : Bank 2 (The conventional right bank)


B : Bank 1 (The conventional left bank)

⇐ : Engine front

- For cylinder numbers and bank layout, refer to the figure.

**Bank 1 : The bank side including cylinder No. 1 (odd-numbered cylinder side)**

**Bank 2 : The other bank side of the above (even-numbered cylinder side)**



# PREPARATION

< PREPARATION >

## PREPARATION







### PREPARATION

#### Special Service Tool

INFOID:000000006289518







A

EM

| Tool number<br>(Kent-Moore No.)<br>Tool name   |   | Description  |             |
|--|---|--|-------------|
| KV10116200<br>(J-26336-A)<br>Valve spring compressor<br>1. KV10115900<br>(J-26336-20)<br>Attachment<br>2. KV10109220<br>( — )<br>Adapter |    | Disassembling valve mechanism<br>Part (1) is a component of KV10116200 (J26336-A), but part (2) is not so.   | C<br>D<br>E |
| KV10107902<br>(J-38959)<br>Valve oil seal puller   |    | Removing valve oil seal  | F<br>G<br>H |
| KV10115600<br>(J-38958)<br>Valve oil seal drift  |  | Installing valve oil seal<br><b>Use side A (G)</b><br>a: 20 (0.79) dia.      d: 8 (0.31) dia.<br>b: 13 (0.51) dia.      e: 10.7 (0.421)<br>c: 10.3 (0.406) dia.      f: 5 (0.20)<br>H: Side B<br>Unit: mm (in) | I<br>J      |
| EM03470000<br>(J-8037)<br>Piston ring compressor   |  | Installing piston assembly into cylinder bore  | K<br>L<br>M |
| KV10111100<br>(J-37228)<br>Seal cutter   |  | Removing steel oil pan and front cover   | N<br>O      |
| KV10112100<br>(BT8653-A)<br>Angle wrench   |  | Tightening bolts for bearing cap, cylinder head, etc.  | P           |



# PREPARATION

## < PREPARATION >

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description   |
|---|---|
| KV10114400<br>(J-38365)<br>Heated oxygen sensor wrench<br><br><br>JPBIA0397ZZ      | Loosening or tightening heated oxygen sensor 2<br><b>a: 22 mm (0.87 in)</b>   |
| KV10117100<br>(J-44626)<br>Heated oxygen sensor wrench<br><br><br>NT379            | Loosening or tightening air fuel ratio sensor 1<br><b>a: 22 mm (0.87 in)</b>  |
| KV10120100<br>(J-47245)<br>Ring gear stopper<br><br><br>LBIA0451E                  | Removing and installing crankshaft pulley   |
| —<br>(J-45488)<br>Quick connector release<br><br><br>PBIC0198E                   | Removing fuel tube quick connectors in engine room<br>(Available in SEC. 164 of PARTS CATALOG:Part No. 16441 6N210) |
| KV10119300<br>( — )<br>Adapter and torque wrench assembly<br><br><br>JPBIA2623ZZ | Tightening rocker cover mounting bolts.<br>(specified torque)   |
| KV10119600<br>( — )<br>Injector remover<br><br><br>JPBIA3746ZZ                   | Removing fuel injector  |





# PREPARATION

## < PREPARATION >

| Tool number<br>(Kent-Moore No.)<br>Tool name   | Description                        |
|--|------------------------------------|
| KV101197S0<br>( — )<br>Injector seal drift set   | Installing fuel injector seal ring |
| <br>JPBIA3281ZZ |                                    |
| EG15050500<br>(J-45402)<br>Compression gauge adapter   | Checking compression pressure      |
| <br>ZZA1225D    |                                    |








## Commercial Service Tool

INFOID:0000000006289519

| (Kent-Moore No.)<br>Tool name  | Description   |
|--|---|
| ( — )<br>Tube presser  | Pressing the tube of liquid gasket                              |
| <br>S-NT052     |   |
| ( — )<br>Power tool  | Loosening nuts and bolts  |
| <br>PBIC0190E   |   |
| ( — )<br>Spark plug wrench   | Removing and installing spark plug<br><b>a: 14 mm (0.55 in)</b> |
| <br>JPBIA0399ZZ |   |
| ( — )<br>Manual lift table caddy   | Removing and installing engine                                  |
| <br>ZZA1210D    |   |

# PREPARATION


## < PREPARATION >

| (Kent-Moore No.)<br>Tool name   | Description  |
|---|--|
| ( — )<br>Pilot bushing puller<br><br><br>NT045   | Removing pilot converter   |
| ( — )<br>Valve seat cutter set<br><br><br>S-NT048  | Finishing valve seat (EXH) dimensions  |
| ( — )<br>Piston ring expander<br><br><br>S-NT030   | Removing and installing piston ring  |
| ( — )<br>Valve guide drift<br><br><br>JPBIA0400ZZ  | Removing and installing valve guide (EXH)<br><b>a: 9.5 mm (0.374 in) dia.</b><br><b>b: 5.5 mm (0.217 in) dia.</b>  |
| ( — )<br>Valve guide reamer<br><br><br>JPBIA0401ZZ   | (A): Reaming valve guide (EXH) inner hole<br>(B): Reaming hole for oversize valve guide (EXH)<br><b>c: 6.0 mm (0.236 in) dia.</b><br><b>d: 10.2 mm (0.402 in) dia.</b>   |
| (J-43897-18)<br>(J-43897-12)<br>Oxygen sensor thread cleaner<br><br><br>AEM488                                     | Reconditioning the exhaust system threads before installing a new heated oxygen sensor (Use with anti-seize lubricant shown below.)<br><b>a: J-43897-18 (18 mm dia.) for zirconia heated oxygen sensor and air fuel ratio sensor</b><br><b>b: J-43897-12 (12 mm dia.) for titania heated oxygen sensor and air fuel ratio sensor</b> |
| ( — )<br>Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)<br><br><br>AEM489 | Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads  |



# PREPARATION

## < PREPARATION >

| (Kent-Moore No.)<br>Tool name   | Description   | A  |
|---|---|----|
| ( — )<br>Feeler gauge  | Inspection valve clearance (use a curved-tip gauge) | EM |
| ( — )<br>Compression gauge with flexible type adapter   | Checking compression pressure                       | C  |

E

F

G

H

I

J

K

L

M

N

O

P

# CAMSHAFT VALVE CLEARANCE

< BASIC INSPECTION >

## BASIC INSPECTION

### CAMSHAFT VALVE CLEARANCE

#### Inspection

INFOID:000000006289520

#### INSPECTION

Check valve clearance if applicable to the following cases:

Intake side:

- At the removal and installation of VVEL ladder assembly or valve-related parts, or at the occurrence of malfunction (poor starting, idle malfunction, unusual noise) due to aged deterioration in valve clearance.

#### CAUTION:

**Valve clearance check on the intake side is not required after replacing the VVEL ladder assembly & cylinder head assembly with a new one. (Install new VVEL ladder assembly & cylinder head assembly in factory-shipped condition because it is factory-adjusted and inspected.)**

#### NOTE:

VVEL ladder assembly cannot be replaced as a single part, because it is machined together with cylinder head assembly.

Exhaust side:

- At the removal, installation, and replacement of exhaust camshaft or valve-related parts, or at the occurrence of malfunction (poor starting, idle malfunction, unusual noise) due to aged deterioration in valve clearance.

1. Remove VVEL actuator motor assembly. Refer to [EM-36, "Removal and Installation"](#).
2. Remove rocker covers (bank 1 and bank 2). Refer to [EM-33, "Removal and Installation"](#).
3. Remove VVEL actuator housing assembly. Refer to [EM-36, "Removal and Installation"](#).
4. Measure the valve clearance as per the following:
  - Use the feeler gauge (commercial service tool) of curved-tip. This allows the feeler gauge to access the clearance between camshaft (drive shaft) nose and valve lifter with ease.

**Valve clearance** : Refer to [EM-133, "Camshaft"](#).

#### NOTE:

Be sure to note the following points when measuring valve clearance on the intake side.

- Before measuring, check that the position of drive shaft nose is within the angle shown in the figure.

A : Bank 2

B : Feeler gauge (commercial service tool)


c : 45 degrees (drive shaft nose angle)

D : View D

↙ : Insertion direction of feeler gauge on the bank 2

↖ : Insertion direction of feeler gauge on the bank 1


- Refer to the figure for the insertion direction of the feeler gauge since the direction depends on the bank.



# CAMSHAFT VALVE CLEARANCE

## < BASIC INSPECTION >

- a. Set No. 1 cylinder at TDC of its compression stroke.
- Rotate crankshaft pulley clockwise to align timing mark (grooved line without color) (B) with timing indicator (A).




- Check that exhaust cam nose on No. 1 cylinder (engine front side of bank 1) is located as shown in the figure.

1 : Exhaust camshaft (bank 1)

↶ : Engine front

- If not, turn crankshaft one revolution (360 degrees) and align as shown in the figure.




- By referring to the figure, measure the valve clearances at locations marked "x" as shown in the table below (locations indicated in the figure).

↶ : Engine front

- No. 1 cylinder at compression TDC

| Measuring position [bank 2 (A)]   |     | No. 2 CYL. | No. 4 CYL. | No. 6 CYL. | No. 8 CYL. |
|-----------------------------------|-----|------------|------------|------------|------------|
| No. 1 cylinder at compression TDC | EXH |            |            |            | × (C)      |
|                                   | INT | × (D)      | × (E)      |            |            |
| Measuring position [bank 1 (B)]   |     | No. 1 CYL. | No. 3 CYL. | No. 5 CYL. | No. 7 CYL. |
| No. 1 cylinder at compression TDC | INT | × (F)      |            | × (G)      |            |
|                                   | EXH | × (H)      |            |            | × (I)      |




**NOTE:**

# CAMSHAFT VALVE CLEARANCE

## < BASIC INSPECTION >

To measure valve clearance of No. 1 cylinder INT valve (front side), insert feeler gauge (A) (commercial service tool) as shown in the figure.

⇐ : Engine front




- b. Rotate crankshaft 270 degrees clockwise (when viewed from engine front) to align No. 3 cylinder at TDC its compression stroke.

### NOTE:

Crankshaft pulley mounting bolt flange has an angle mark (B) every 90 degrees (c). They can be used as a guide to rotation angle.

A : Paint mark




- By referring to the figure, measure the valve clearances at locations marked "x" as shown in the table below (locations indicated in the figure).

⇐ : Engine front

- No. 3 cylinder at compression TDC

| Measuring position [bank 2 (A)]   |     | No. 2 CYL. | No. 4 CYL. | No. 6 CYL. | No. 8 CYL. |
|-----------------------------------|-----|------------|------------|------------|------------|
| No. 3 cylinder at compression TDC | EXH |            | × (C)      |            |            |
|                                   | INT |            |            |            | × (D)      |
| Measuring position [bank 1 (B)]   |     | No. 1 CYL. | No. 3 CYL. | No. 5 CYL. | No. 7 CYL. |
| No. 3 cylinder at compression TDC | INT |            | × (E)      |            | × (F)      |
|                                   | EXH |            | × (G)      | × (H)      |            |



- c. Rotate crankshaft 90 degrees clockwise (when viewed from engine front) to align No. 6 cylinder at TDC of compression stroke.


### NOTE:

# CAMSHAFT VALVE CLEARANCE

## < BASIC INSPECTION >

Crankshaft pulley mounting bolt flange has an angle mark (B) every 90 degrees (c). They can be used as a guide to rotation angle.

A : Paint mark




- By referring to the figure, measure the valve clearances at locations marked "x" as shown in the table below (locations indicated in the figure).

← : Engine front

- No. 6 cylinder at compression TDC

| Measuring position [bank 2 (A)]   |     | No. 2<br>CYL. | No. 4<br>CYL. | No. 6<br>CYL. | No. 8<br>CYL. |
|-----------------------------------|-----|---------------|---------------|---------------|---------------|
| No. 6 cylinder at compression TDC | EXH | × (B)         |               | × (C)         |               |
|                                   | INT |               |               | × (D)         |               |



- Perform adjustment or replacement if the measured value is out of the standard.
  - If a valve clearance on the exhaust side is out of specification, adjust the valve clearance. Refer to [EM-77, "Inspection"](#).
  - If a valve clearance on the intake side is out of specification, replace VVEL ladder assembly & cylinder head assembly. Refer to [EM-86, "Exploded View"](#).

### CAUTION:

**Never adjust valve clearance on the intake side.**

### NOTE:

Since the valve lifter (INT) cannot be replaced by the piece, VVEL ladder assembly & cylinder head assembly replacement are required.

# COMPRESSION PRESSURE

< BASIC INSPECTION >

## COMPRESSION PRESSURE

### Inspection

INFOID:000000006289521

1. Warm up engine thoroughly. Then, stop it.
2. Release fuel pressure. Refer to [EC-153, "Work Procedure"](#).

**CAUTION:**


If CONSULT-III is not used to release fuel pressure leave the fuel pump fuse disconnected until step 7.

3. Remove fuel pump fuse in IPDM E/R.

**NOTE:**

- For the fuse number, refer to [EC-114, "Wiring Diagram"](#).
- For the fuse arrangement, refer to [PG-143, "Fuse, Connector and Terminal Arrangement"](#).

4. Remove engine cover. Refer to [EM-25, "Exploded View"](#).
5. Remove ignition coil and spark plug from each cylinder. Refer to [EM-29, "Exploded View"](#).
6. Connect engine tachometer (not required in use of CONSULT-III).
7. Install the compression tester with Tool [SST: EG15050500 (J-45402)] into the spark plug hole.



8. Measure compression pressure using compression gauge connected with flexible type adapter (commercial service tool).
9. With accelerator pedal fully depressed, turn ignition switch to "START" for cranking. When the gauge pointer stabilizes, read the compression pressure and the engine rpm. Perform these steps to check each cylinder.

**Compression pressure** : Refer to [EM-132, "General Specification"](#).

**CAUTION:**

- Measure a six-cylinder under the same conditions since a measurement depends on measurement conditions (engine water temperature, etc.).
- Always use a fully charged battery to obtain the specified engine speed.
- If the engine speed is out of the specified range, check battery liquid for proper gravity. Check the engine speed again with normal battery gravity. Refer to [PG-159, "How to Handle Battery"](#).
- If compression pressure is below the minimum value, check valve clearances and parts associated with combustion chamber (valve, valve seat, piston, piston ring, cylinder bore, cylinder head, cylinder head gasket). After checking, measure compression pressure again.
- If a cylinder has low compression pressure, pour a small amount of engine oil into the spark plug hole of the cylinder to re-check it for compression.
  - If the added engine oil improves the compression, piston rings may be worn out or damaged. Check piston rings and replace if necessary. Refer to [EM-107, "Disassembly and Assembly"](#).
  - If the compression pressure remains at low level despite the addition of engine oil, valves may be malfunctioning. Check valves for damage. Replace valve or valve seat accordingly. Refer to [EM-107, "Disassembly and Assembly"](#).
- If two adjacent cylinders have respectively low compression pressure and their compression remains low even after the addition of engine oil, cylinder head gaskets are leaking. In such a case, replace cylinder head gaskets. Refer to [EM-87, "Removal and Installation"](#).

10. After inspection is completed, install removed parts.
11. Start the engine, and check that the engine runs smoothly.

COMPRESSION PRESSURE

< BASIC INSPECTION >

12. Perform trouble diagnosis. If DTC appears, erase it. Refer to [EC-161, "Description"](#).

A  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EM

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING


< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting - Engine Noise

INFOID:000000006289522





# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

## < SYMPTOM DIAGNOSIS >

Use the Chart Below to Help You Find the Cause of the Symptom

INFOID:000000006289523

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of the engine.
4. Check specified noise source.

If necessary, repair or replace these parts.

| Location of noise  | Type of noise        | Operating condition of engine |               |                |             |             |               | Source of noise                               | Check item  | Reference page         |
|--|----------------------|-------------------------------|---------------|----------------|-------------|-------------|---------------|---|---|------------------------|
|  |                      | Before warm-up                | After warm-up | When start-ing | When idling | When racing | While driving |   |   |                        |
| Top of engine<br>Rocker cover<br>Cylinder head                   | Ticking or clicking  | C                             | A             | —              | A           | B           | —             | Tappet noise                                  | Valve clearance   | <a href="#">EM-12</a>  |
|  | Rattle               | C                             | A             | —              | A           | B           | C             | Camshaft bearing noise                        | Camshaft runout<br>Camshaft journal oil clearance   | <a href="#">EM-77</a>  |
| Crank-shaft pulley<br>Cylinder block (Side of engine)<br>Oil pan | Slap or knock        | —                             | A             | —              | B           | B           | —             | Piston pin noise                              | Piston to piston pin oil clearance<br>Connecting rod bushing oil clearance  | <a href="#">EM-115</a> |
|  | Slap or rap          | A                             | —             | —              | B           | B           | A             | Piston slap noise                             | Piston to cylinder bore clearance<br>Piston ring side clearance<br>Piston ring end gap<br>Connecting rod bend and torsion | <a href="#">EM-115</a> |
|  | Knock                | A                             | B             | C              | B           | B           | B             | Connecting rod bearing noise                  | Connecting rod bushing oil clearance<br>Connecting rod bearing oil clearance  | <a href="#">EM-115</a> |
|  | Knock                | A                             | B             | —              | A           | B           | C             | Main bearing noise                            | Main bearing oil clearance<br>Crankshaft runout   | <a href="#">EM-115</a> |
| Front of engine<br>Timing chain case                             | Tapping or ticking   | A                             | A             | —              | B           | B           | B             | Timing chain and timing chain tensioner noise | Timing chain cracks and wears<br>Timing chain tensioner operation   | <a href="#">EM-72</a>  |
| Front of engine  | Squeaking or fizzing | A                             | B             | —              | B           | —           | C             | Drive belts (Sticking or slipping)            | Drive belts deflection  | <a href="#">EM-20</a>  |
|  | Creaking             | A                             | B             | A              | B           | A           | B             | Drive belts (Slipping)                        | Idler pulley bearing operation  |                        |
|  | Squall Creak         | A                             | B             | —              | B           | A           | B             | Water pump noise                              | Water pump operation  | <a href="#">CO-19</a>  |

A: Closely related B: Related C: Sometimes related —: Not related

# DRIVE BELTS


< PERIODIC MAINTENANCE >

## PERIODIC MAINTENANCE

### DRIVE BELTS

#### Exploded View

INFOID:000000006289524



- |                       |   |                              |
|-----------------------|---|------------------------------|
| 1. Drive belt         | 2. Power steering oil pump pulley         | 3. Alternator pulley         |
| 4. Crankshaft pulley  | 5. A/C compressor                         | 6. Idler pulley              |
| 7. Cooling fan pulley | 8. Water pump pulley                      | 9. Drive belt auto-tensioner |
| A. Possible use range | B. Range when new drive belt is installed | C. Indicator                 |

D. View D

#### Checking

INFOID:000000006289525

#### **WARNING:**

**Be sure to perform the these steps when engine is stopped.**

- Check that the indicator (C) (notch on fixed side) of each auto-tensioner is within the possible use range (A).

#### **NOTE:**

- Check the each auto-tensioners indication when the engine is cold.
- When new drive belts is installed, the indicator (notch on fixed side) should be within the range (B) in the figure.
- Visually check all drive belts for wear, damage or cracks.
- If the indicator (notch on fixed side) is out of the possible use range or drive belts are damaged, replace drive belts.

#### Tension Adjustment

INFOID:000000006289526

Refer to [EM-132. "Drive Belts"](#).

#### Removal and Installation

INFOID:000000006289527

#### REMOVAL

1. Move reservoir tank to the position without the hindrance for work. Refer to [CO-13. "Exploded View"](#).

## DRIVE BELTS


### < PERIODIC MAINTENANCE >

2. Install wrench (A) on drive belt auto tensioner pulley bolt, move in the direction of arrow (loosening direction of tensioner) as shown.

#### **CAUTION:**

- **Never place hand in a location where pinching may occur if the holding tool accidentally comes off.**
- **Never loosen the hexagonal part in center of auto tensioner pulley (1) (Never turn it clockwise). If turned clockwise, the complete auto tensioner must be replaced as a unit, including the pulley.**

3. Under the above condition, insert a metallic bar (B) of approximately 6 mm (0.24 in) in diameter (hexagonal bar wrench shown as example in the figure) through the holding boss to lock auto tensioner pulley arm.
4. Remove drive belt.



### INSTALLATION

Note the following item, and install in the reverse order of removal.

#### **CAUTION:**

- **Check drive belts are securely installed around all pulleys.**
- **Check drive belts are correctly engaged with the pulley groove.**
- **Check for engine oil and engine coolant are not adhered drive belts and pulley groove.**

### Inspection

INFOID:000000006289528

### INSPECTION AFTER INSTALLATION

- Turn crankshaft pulley clockwise several times to equalize tension between each pulley, and then confirm tension of drive belts at indicator (notch on fixed side) is within the possible use range. Refer to [EM-20, "Exploded View"](#).


# AIR CLEANER FILTER

< PERIODIC MAINTENANCE >

## AIR CLEANER FILTER

### Exploded View

INFOID:000000006289529



- |                       |                             |                             |
|-----------------------|-----------------------------|-----------------------------|
| 1. Resonator          | 2. Adapter                  | 3. Air cleaner case (lower) |
| 4. Air cleaner filter | 5. Air cleaner case (upper) | 6. Mass air flow sensor     |
| 7. Air duct           | 8. Clamp                    |                             |

⇐ Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289530

### REMOVAL

#### NOTE:

- The viscous paper type filter does not need cleaning between replacement intervals.
  - Replace the air filter as necessary for periodic maintenance. Refer to [MA-6, "Introduction of Periodic Maintenance"](#).
1. Unhook clips, and lift air cleaner case (upper).
  2. Remove air cleaner filter from air cleaner case.

### INSTALLATION

Install is the reverse order of removal.


# SPARK PLUG

< PERIODIC MAINTENANCE >

## SPARK PLUG

### Exploded View

INFOID:000000006289531



- |                             |                             |                             |
|-----------------------------|-----------------------------|-----------------------------|
| 1. Ignition coil (No. 2, 4) | 2. Ignition coil (No. 6, 8) | 3. Spark plug               |
| 4. Rocker cover (bank 2)    | 5. Rocker cover (bank 1)    | 6. Ignition coil (No. 1, 3) |
| 7. Ignition coil (No. 5, 7) |                             |                             |

Refer to [GI-4, "Components"](#) for symbols in the figure.


### Removal and Installation

INFOID:000000006289532

#### REMOVAL

1. Remove engine cover. Refer to [EM-25, "Exploded View"](#).
2. Remove ignition coil. Refer to [EM-29, "Exploded View"](#).
3. Remove spark plug with a spark plug wrench (commercial service tool).

a : 14 mm (0.55 in)



#### INSTALLATION

Note the following item, installa is the reverse order of removal.


**CAUTION:**

# SPARK PLUG

## < PERIODIC MAINTENANCE >

Install ignition coil marked with an identification mark (A) on cylinder No. 5, 6, 7 and 8.

⇐ : Engine front



INFOID:000000006289533

## Inspection

### INSPECTION AFTER REMOVAL

Use the standard type spark plug for normal condition.

Spark plug (Standard type) : Refer to [EM-132, "Spark Plug"](#).

### CAUTION:


- Never drop or impact spark plug.
- Never use a wire brush for cleaning.
- If plug tip is covered with carbon, use spark plug cleaner to clean.

Cleaner air pressure


: Less than 588 kPa (5.9 bar, 6 kg/cm<sup>2</sup>, 85 psi)

Cleaning time

: Less than 20 seconds



- Measure spark plug gap. When it exceeds the limit, replace spark plug even if it is within the specified replacement mileage. Refer to [EM-132, "Spark Plug"](#).
- Spark plug gap adjustment is not required between replacement intervals.



# ENGINE COVER

< REMOVAL AND INSTALLATION >


## REMOVAL AND INSTALLATION

### ENGINE COVER

Exploded View

INFOID:000000006289534

EM



- 1. Engine cover
- 2. Bracket (front)
- 3. Intake manifold
- 4. Bracket (rear)

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000006289535

#### REMOVAL

##### **CAUTION:**

**Never damage or scratch engine cover when installing or removing.**

1. Remove mounting bolts.
2. Pull forward and remove engine cover.
3. Remove bracket (front) and bracket (rear).

#### INSTALLATION

Installation is the reverse order of removal.


# DRIVE BELT AUTO TENSIONER AND IDLER PULLEY

< REMOVAL AND INSTALLATION >

## DRIVE BELT AUTO TENSIONER AND IDLER PULLEY

Exploded View

INFOID:000000006289536



1. Drive belt auto-tensioner

2. Idler pulley

3. Fan bracket

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289537

### Removal

#### **CAUTION:**

**The complete drive belt auto-tensioner must be replaced as a unit, including the pulley.**

1. Remove drive belts. Refer to [EM-20, "Exploded View"](#).
  - Keep auto-tensioner pulley arm locked after drive belt is removed.
2. Remove drive belt auto-tensioner.
  - Keep auto-tensioner pulley arm locked to install or remove auto-tensioner.

#### **CAUTION:**

**Never loosen the hexagonal part in center of drive belt auto tensioner pulley (Never turn it clockwise). If turned clockwise, the complete drive belt auto tensioner must be replaced as a unit, including the pulley.**

3. Remove idler pulley.

### Installation

Installation is the reverse order of removal.

#### **CAUTION:**

**Never swap the pulley between new and old drive belt auto tensioner.**




# AIR CLEANER AND AIR DUCT

< REMOVAL AND INSTALLATION >

## AIR CLEANER AND AIR DUCT

### Exploded View

INFOID:000000006289538



- |                       |                             |                             |
|-----------------------|-----------------------------|-----------------------------|
| 1. Resonator          | 2. Adapter                  | 3. Air cleaner case (lower) |
| 4. Air cleaner filter | 5. Air cleaner case (upper) | 6. Mass air flow sensor     |
| 7. Air duct           | 8. Clamp                    |                             |

← Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000006289539

#### REMOVAL

##### NOTE:

Mass air flow sensor is removable under the car-mounted condition.

1. Remove engine cover. Refer to [EM-25, "Exploded View"](#).
2. Disconnect mass air flow sensor harness connector.
3. Remove air cleaner case and mass air flow sensor assembly and air duct by disconnecting their joints.
  - Add matching marks, if necessary for easier installation.
4. Remove mass air flow sensor from air cleaner case, if necessary.

##### CAUTION:

Handle mass air flow sensor according to the following instructions.

- Never impact it.
- Never disassemble it.
- Never touch its sensor.

5. Disconnect PCV hose from air duct.
6. Remove air duct.
7. Remove air cleaner filter.
8. Remove air cleaner case (lower).
9. Remove adapter.
10. If remove resonator (location in wheel house), refer to following.
  - a. Remove LH front wheel and tire.
  - b. Remove fender protector. Refer to [EXT-23, "FENDER PROTECTOR : Exploded View"](#).
  - c. Remove resonator.

#### INSTALLATION

## AIR CLEANER AND AIR DUCT

### < REMOVAL AND INSTALLATION >

---

Note the following item, and install in the reverse order of removal.

- Align marks. Attach each joint. Screw clamps firmly.

**Clamp tightening torque** : **4.5 N·m (0.46 kg-m, 40 in-lb)**

### Inspection

INFOID:000000006289540

#### INSPECTION AFTER REMOVAL

Inspect air duct assembly for crack or tear.

- If damage is found, replace air duct assembly


# IGNITION COIL

< REMOVAL AND INSTALLATION >

## IGNITION COIL

### Exploded View

INFOID:000000006289541



- |                             |                             |                             |
|-----------------------------|-----------------------------|-----------------------------|
| 1. Ignition coil (No. 2, 4) | 2. Ignition coil (No. 6, 8) | 3. Spark plug               |
| 4. Rocker cover (bank 2)    | 5. Rocker cover (bank 1)    | 6. Ignition coil (No. 1, 3) |
| 7. Ignition coil (No. 5, 7) |                             |                             |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289542

### REMOVAL

1. Remove engine cover. Refer to [EM-25, "Exploded View"](#).
2. Remove ignition coil.

#### CAUTION:

**Never impact it.**


#### NOTE:

Installation position of ignition coil depends on cylinder position.

### INSTALLATION

1. Install ignition coil.
  - CAUTION:**
  - Install Ignition coil marked with an identification mark (A) on cylinder No. 5, 6, 7 and 8.

← : Engine front



2. Install engine cover.


# INTAKE MANIFOLD

< REMOVAL AND INSTALLATION >

## INTAKE MANIFOLD

### Exploded View

INFOID:000000006289543



- |   |                                      |   |
|---|--------------------------------------|---|
| 1. Intake manifold                            | 2. PCV hose                          | 3. Clamp                                    |
| 4. EVAP canister purge control solenoid valve | 5. Clamp                             | 6. EVAP hose                                |
| 7. Gasket                                     | 8. Gasket                            | 9. Electric throttle control actuator       |
| 10. PCV hose                                  | 11. O-ring                           | 12. Manifold absolute pressure (MAP) sensor |
| A. To rocker cover (bank 2)                   | B. To centralized under-floor piping | C. To rocker cover (bank 1)                 |

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289544

### REMOVAL

#### **WARNING:**

**To avoid the danger of being scalded, never drain the engine coolant when the engine is hot.**

1. Remove engine cover and bracket. Refer to [EM-25, "Exploded View"](#).
2. Remove air cleaner case (upper) and air duct. Refer to [EM-27, "Exploded View"](#).
3. Disconnect manifold absolute pressure (MAP) sensor harness connector.
4. Remove EVAP canister purge control solenoid valve.
5. Disconnect PCV hoses from intake manifold.
  - Add matching marks as necessary for easier installation.
6. Drain engine coolant from radiator. Refer to [CO-8, "Draining"](#).

#### **CAUTION:**

- Perform this step when the engine is cold.

# INTAKE MANIFOLD

## < REMOVAL AND INSTALLATION >

- **Never spill engine coolant on drive belts.**

### NOTE:

When removing only intake manifold, move electric throttle control actuator without disconnecting the water hoses.

7. Remove electric throttle control actuator.


- Loosen mounting bolts in reverse order as shown in the figure.

### NOTE:

The figure shows the electric throttle control actuator viewed from the air duct side.

### CAUTION:


- **Handle carefully to avoid any impact to electric throttle control actuator.**
- **Never disassemble.**



8. Remove intake manifold, using a power tool.

- Loosen mounting bolts in reverse order as shown in the figure.

← : Engine front



9. Remove intake manifold gaskets.

### CAUTION:

**Cover engine openings to avoid entry of foreign materials.**

10. Remove manifold absolute pressure (MAP) sensor, if necessary.

### CAUTION:

**Handle carefully to avoid any impact to manifold absolute pressure (MAP) sensor.**


## INSTALLATION

Note the following item, and install in the reverse order of removal.

Intake Manifold

Tighten in numerical order as shown in the figure.

← : Engine front



Electric Throttle Control Actuator

## INTAKE MANIFOLD


### < REMOVAL AND INSTALLATION >

- Tighten in numerical order as shown in the figure.

**NOTE:**

The figure shows the electric throttle control actuator viewed from the air duct side.

- Perform the "Throttle Valve Closed Position Learning" when harness connector of electric throttle control actuator is disconnected. Refer to [EC-147. "Description"](#).
- Perform the "Idle Air Volume Learning" and "Throttle Valve Closed Position Learning" when electric throttle control actuator is replaced. Refer to [EC-148. "Description"](#) and [EC-147. "Description"](#).




# ROCKER COVER

< REMOVAL AND INSTALLATION >

## ROCKER COVER

### Exploded View

INFOID:000000006289545



- |                          |                                 |                                 |
|--------------------------|---------------------------------|---------------------------------|
| 1. Oil filler cap        | 2. Clamp                        | 3. PCV hose                     |
| 4. Rocker cover (bank 2) | 5. Rocker cover gasket (bank 2) | 6. Rocker cover gasket (bank 1) |
| 7. Rocker cover (bank 1) | 8. PCV hose                     | 9. O-ring                       |
| 10. PCV valve            | 11. Clamp                       | 12. PCV hose                    |
| 13. PCV valve            | 14. O-ring                      |                                 |

A. To air duct

B. To intake manifold

C. Comply with the installation procedure when tightening. Refer to [EM-33, "Removal and Installation"](#).

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289546

### REMOVAL


1. Remove engine cover and bracket (rear). Refer to [EM-25, "Exploded View"](#).
2. Disconnect PCV hose from rocker cover.
3. Remove air cleaner case (upper) and air duct. Refer to [EM-27, "Exploded View"](#).
4. Move the following parts to the position without the hindrance for work.
  - Oil level gauge guide. Refer to [EM-57, "Exploded View"](#).
  - Power steering fluid reservoir tank bracket. Refer to [ST-54, "Exploded View"](#).
  - EVAP canister purge control solenoid valve. [EM-30, "Exploded View"](#).
  - Fuel feed hose. Refer to [EM-43, "Exploded View"](#).
5. Remove VVEL actuator motor assembly. Refer to [EM-36, "Exploded View"](#).
6. Remove ignition coil. Refer to [EM-29, "Exploded View"](#).
- CAUTION:**  
**Never impact it.**
7. Remove rocker cover.

# ROCKER COVER

## < REMOVAL AND INSTALLATION >

- Loosen bolts in reverse order shown in the figure.

A : Bank 2  
 B : Bank 1  
 ⇐ : Engine front



- Remove rocker cover gasket from rocker cover.
- Use scraper to remove all traces of liquid gasket from cylinder head & VVEL ladder assembly.  
**CAUTION:**  
**Never scratch or damage the mating surface when cleaning off old liquid gasket.**
- Remove PCV valve from rocker cover, if necessary.
- Remove oil filler cap from rocker cover, if necessary.

## INSTALLATION

- Apply liquid gasket with the tube presser (commercial service tool) to VVEL ladder assembly (1).


A : Liquid gasket application point  
 F : End surface of VVEL ladder assembly  
 b : 4.0 mm (0.16 in)  
 c : 2.5 - 3.5 mm (0.098 - 0.138 in)  
 d : 5.0 mm (0.20 in)  
 e : 10.0 mm (0.39 in)  
 ⇐ : Engine front

Use **Genuine RTV silicone sealant** or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

### NOTE:

The figure shows an example of bank 1 side.

- Apply liquid gasket on the front and rear side of engine first. [5 mm (0.20 in) + 5 mm (0.20 in) side as shown in the figure]



- Install rocker cover gasket to rocker cover.
- Install rocker cover.
  - Check that rocker cover gasket does not drop from the installation groove of rocker cover.



# ROCKER COVER

## < REMOVAL AND INSTALLATION >

- Tighten bolts in two steps separately in numerical order as shown in the figure.


A : Bank 2

B : Bank 1

⇐ : Engine front


**1st step** :  **2.0 N·m (0.2 kg-m, 18 in-lb)**

**2nd step** :  **8.3 N·m (0.85 kg-m, 73 in-lb)**



- Because of the limited working space, use adapter and torque wrench assembly [SST: KV10119300 ( — )] (A) to tighten bolts (on the No.7 and No. 8 cylinders) to the specified torque.

⇐ : Engine front




- Install ignition coil. Refer to [EM-29, "Exploded View"](#).

### CAUTION:

- Install Ignition coil marked with an identification mark (A) on cylinder No. 5, 6, 7 and 8.

⇐ : Engine front



- Install VVEL actuator motor assembly. Refer to [EM-36, "Exploded View"](#).
- Install in the reverse order of removal.


# VVEL ACTUATOR ASSEMBLY

< REMOVAL AND INSTALLATION >

## VVEL ACTUATOR ASSEMBLY

### Exploded View

INFOID:000000006289547



- |   |   |   |
|---|---|---|
| 1. VVEL actuator motor assembly (bank 2)  | 2. Gasket                                       | 3. VVEL actuator housing assembly (bank 2)      |
| 4. Washer                                 | 5. VVEL ladder assembly (bank 2)                | 6. Exhaust camshaft (bank 2)                    |
| 7. Cylinder head (bank 2)                 | 8. Cylinder head (bank 1)                       | 9. Exhaust camshaft (bank 1)                    |
| 10. VVEL ladder assembly (bank 1)         | 11. VVEL actuator housing assembly (bank 1)     | 12. Gasket                                      |
| 13. VVEL actuator motor assembly (bank 1) | 14. VVEL control shaft position sensor (bank 1) | 15. VVEL control shaft position sensor (bank 2) |

Comply with the installation procedure when tightening. Refer to [EM-75, "Removal and Installation"](#).

B. View B

C. View C

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289548

### REMOVAL

1. Remove engine cover. Refer to [EM-25, "Exploded View"](#).

# VVEL ACTUATOR ASSEMBLY


## < REMOVAL AND INSTALLATION >

2. Loosen mounting bolts (C), and then remove VVEL actuator motor assembly (1).

A : Bank 2


B : Bank 1

⇐ : Engine front




### CAUTION:

Never loosen screws (A) of VVEL actuator motor assembly.




3. Remove rocker cover. Refer to [EM-33. "Exploded View"](#).
4. Insert mounting bolt (A) removed at step 2 into VVEL actuator housing assembly.



5. Loosen mounting bolt (C) to disengage the control shaft and the actuator arm.

# VVEL ACTUATOR ASSEMBLY

## < REMOVAL AND INSTALLATION >




A. Bank 1

B. Bank 2

⇐ : Engine front

6. Loosen mounting bolts (C), and then remove VVEL actuator housing assembly.



1. VVEL actuator housing assembly  
(bank 1)

2. VVEL actuator housing assembly  
(bank 2)

A. Bank 1


B. Bank 2

⇐ : Engine front

## INSTALLATION

Note the following, and install in the reverse order of removal.

- When disengaging the control shaft (1) and the actuator arm, hold the stopper of the control shaft in the position shown in the figure.



A. Bank 1

B. Bank 2

C. View C

⇐ : Engine front

# VVEL ACTUATOR ASSEMBLY

## < REMOVAL AND INSTALLATION >


### Inspection

INFOID:000000006289549

#### INSPECTION AFTER REMOVAL

VVEL actuator housing assembly

- Move the ball nut (A) in the axial direction to check the smooth rotation.



A

EM

C

D

E

F

G

H

I

J

K

L

M

N

O

P


# EXHAUST MANIFOLD AND THREE WAY CATALYST

< REMOVAL AND INSTALLATION >

## EXHAUST MANIFOLD AND THREE WAY CATALYST

### Exploded View

INFOID:000000006289550



- |                                     |   |   |
|-------------------------------------|---|---|
| 1. Air fuel ratio sensor 1 (bank 2) | 2. Exhaust manifold cover (bank 2)                  | 3. Exhaust manifold and three way catalyst (bank 2) |
| 4. Gasket                           | 5. Exhaust manifold and three way catalyst (bank 1) | 6. Exhaust manifold cover (bank 1)                  |
| 7. Air fuel ratio sensor 1 (bank 1) |   |   |

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000006289551

#### REMOVAL

##### **WARNING:**

**Perform the work when the exhaust and cooling system have cooled sufficiently.**

1. Drain engine coolant from radiator. Refer to [CO-8, "Draining"](#).

##### **CAUTION:**

- Perform this step when the engine is cold.
- Never spill engine coolant on drive belt.

2. Remove reservoir tank. Refer to [CO-13, "Exploded View"](#).
3. Remove drive belt. Refer to [EM-20, "Removal and Installation"](#).
4. Remove power steering oil pump. Refer to [ST-48, "Exploded View"](#).
5. Remove radiator. Refer to [CO-13, "Exploded View"](#).
6. Remove front under cover. Refer to [EXT-25, "Exploded View"](#).
7. Remove front wheels and tires. Refer to [WT-64, "Exploded View"](#).
8. Remove A/C compressor. Refer to [HA-30, "Exploded View"](#).
9. Remove alternator and alternator bracket. Refer to [CHG-25, "Exploded View"](#).
10. Remove exhaust front tube (bank 1 and bank 2). Refer to [EX-5, "Exploded View"](#).

# EXHAUST MANIFOLD AND THREE WAY CATALYST

## < REMOVAL AND INSTALLATION >


11. Remove front propeller shaft. Refer to [DLN-128, "Exploded View"](#).
12. Disconnect steering lower joint. Refer to [ST-37, "Exploded View"](#).
13. Remove air fuel ratio sensor 1 as per the following:

### CAUTION:

**Air fuel ratio sensor 1 is not reusable. Never remove air fuel ratio sensor 1 unless this is required.**

- Using the heated oxygen sensor wrench [SST: KV10117100 (J-44626)] (A), remove air fuel ratio sensor 1 (1).

← : Vehicle front




14. Remove exhaust manifold cover.
15. Remove oil level gauge guide. Refer to [EM-57, "Exploded View"](#).
16. Remove exhaust manifold.
  - Loosen nuts in the reverse order of figure to remove exhaust manifold with a power tool.

A : Bank 1

B : Bank 2

← : Engine front



17. Remove exhaust manifold gaskets.

### CAUTION:

**Cover engine openings to avoid entry of foreign materials.**

## INSTALLATION

Note the following item, and install in the reverse order of removal.

### Exhaust Manifold Gasket


- Install exhaust manifold gasket in directional shown in the figure.

A : Triangle press

← : Above

### NOTE:

When install exhaust manifold gasket, coating surface (black) shall be located on the exhaust manifold side.



Exhaust Manifold

# EXHAUST MANIFOLD AND THREE WAY CATALYST


## < REMOVAL AND INSTALLATION >

- Tighten mounting nuts in numerical order as shown in the figure.

A : Bank 1  
B : Bank 2  
⇐ : Engine front

### CAUTION:


All exhaust manifold nuts are tightened at twice.



Air Fuel Ratio Sensor 1, Heated Oxygen Sensor 2

### CAUTION:

- Before installing new sensors, clean exhaust system threads using oxygen sensor thread cleaner (commercial service tool: J-43897-18 or J-43897-12), and apply anti-seize lubricant (commercial service tool).
- Sensors are not reusable. Replace them with a new one after removal. When replacing them, handle with care not to impact on them.
- When installing the new air fuel ratio sensors 1 (1), set the heated oxygen sensor wrench [SST: KV10117100(J-44626)] (A) in the hexagonal part to tighten the them.



- Never over torque sensors. Doing so may cause damage to the sensors, resulting in "MIL" coming on.

## Inspection

INFOID:000000006289552


### INSPECTION AFTER DISASSEMBLY

#### Surface Distortion

- Check the surface distortion of the exhaust manifold mating surface with a straightedge (A) and a feeler gauge (B).

**Limit** : Refer to [EM-133, "Exhaust Manifold"](#).

- If it exceeds the limit, replace exhaust manifold.





# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

< REMOVAL AND INSTALLATION >


## HIGH PRESSURE FUEL PUMP AND FUEL HOSE

Exploded View

INFOID:000000006289553

### CAUTION:

Never remove or disassemble parts unless instructed as shown in the figure.



- |                                      |                                  |                             |
|--------------------------------------|----------------------------------|-----------------------------|
| 1. High pressure fuel pump insulator | 2. High pressure fuel pump       | 3. O-ring                   |
| 4. Lifter                            | 5. Fuel pump connector protector | 6. Copper washer            |
| 7. Fuel feed hose                    | 8. Copper washer                 | 9. Low fuel pressure sensor |
| 10. Bracket                          | 11. Fuel feed tube (pump side)   |                             |

A. From fuel tank

⇐ : Engine front

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000006289554

### REMOVAL

#### WARNING:


- Be sure to read [EM-4, "Precaution for Handling High Pressure Fuel System"](#) when working on the high pressure fuel system.
- Put a "CAUTION: FLAMMABLE" sign in the workshop.
- Be sure to work in a well ventilated area and furnish workshop with a CO2 fire extinguisher.
- Never smoke while servicing fuel system. Keep open flames and sparks away from the work area.
- To avoid the danger of being scalded, never drain engine coolant when engine is hot.

1. Release fuel pressure. Refer to [EC-153, "Work Procedure"](#).
2. Remove intake manifold. Refer to [EM-30, "Removal and Installation"](#).
3. Disconnect harness connector from high pressure fuel pump.


# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

## < REMOVAL AND INSTALLATION >

4. Remove fuel feed tube (pump side) (1).
5. Disconnect fuel hose (2) from high pressure fuel pump.



6. Remove high pressure fuel pump and lifter.  
**CAUTION:**  
**After removing lifter, replace lifter with a new one.**
7. Disconnect quick connector (A) with the following procedure.



- a. Remove quick connector cap from quick connector connection.
- b. With the sleeve side of quick connector release facing quick connector, install quick connector release onto fuel tube.

- c. Insert quick connector release into quick connector until sleeve contacts and goes no further. Hold quick connector release on that position.


**CAUTION:**

**Inserting quick connector release hard will not disconnect quick connector. Hold quick connector release where it contacts and goes no further.**

- d. Draw and pull out quick connector straight from fuel tube.

**CAUTION:**


- Pull quick connector holding (A) position as shown in the figure.
- Never pull with lateral force applied. O-ring inside quick connector may be damaged.
- Prepare container and cloth beforehand because fuel will leak out.
- Avoid fire and sparks.
- Keep parts away from heat source. Especially, be careful when welding is performed around them.
- Never expose parts to battery electrolyte or other acids.
- Never bend or twist connection between quick connector and fuel feed hose (with damper) during installation/removal.



# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

## < REMOVAL AND INSTALLATION >

- To keep clean the connecting portion and to avoid damage and foreign materials, cover them completely with plastic bags, etc. or a similar item.



8. Disconnect harness connector from low fuel pressure sensor.
9. Remove fuel hose assembly.
10. Remove fuel pressure sensor.

### CAUTION:

- Never allow water and foreign materials enter into the connector.
- Never reuse the dropped sensor.
- Carefully handle sensor avoiding shocks.
- Use hex head support installation for removal and installation of sensor.
- The contact surface of gasket must not have any stain or scoring by dust etc.

## INSTALLATION


1. Install O-ring to high pressure fuel pump. When handling new O-ring, paying attention to the following caution items:

### CAUTION:

- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with new engine oil.
- Never clean O-ring with solvent.
- Check that O-ring and its mating part are free of foreign material.
- When installing O-ring, be careful not to scratch it with tool or fingernails. Also be careful not to twist or stretch O-ring. If O-ring was stretched while it was being attached, never insert it quickly into fuel tube.
- Insert new O-ring straight into fuel rail. Never decenter or twist it.

2. Install fuel pressure sensor.
3. Install fuel hose assembly.
  - Temporarily tighten mounting bolt (A) as shown in the figure.

← : Engine front



4. Install high pressure fuel pump to front cover.

### CAUTION:

**After removing lifter, replace lifter with a new one.**

5. Connect fuel feed hose to high pressure fuel pump.


### NOTE:

- Never allow the machined edge of the high pressure fuel pump to contact with gasket.
- The gasket contact area must be free of dust and scratches.

# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

## < REMOVAL AND INSTALLATION >

- Check that rotation stopper (A) of fuel feed hose contact high pressure fuel pump.



6. Tighten mounting bolts that are temporarily tightened in step 3.
7. Connect harness connector to high pressure fuel pump.
8. Install fuel pump connector protector.
9. Connect harness connector to low fuel pressure sensor.
10. Note the following, and connect quick connector to install fuel feed hose.
  - a. Check the connection for foreign material and damage.
  - b. Align center to insert quick connector straightly into fuel tube.


### NOTE:

The figure shows engine side as an example.

- Insert fuel tube into quick connector until the top spool on fuel tube is inserted completely and the second level spool is positioned slightly below quick connector bottom end.

### CAUTION:

- **Hold “A” position in the figure when inserting fuel tube into quick connector.**
- **Carefully align center to avoid inclined insertion to prevent damage to O-ring inside quick connector.**
- **Insert until you hear a “click” sound and actually feel the engagement.**
- **To avoid misidentification of engagement with a similar sound, be sure to perform the next step.**




- c. Before clamping fuel feed hose with hose clamps, pull quick connector hard by hand holding “A” position. Check it is completely engaged (connected) so that it does not come out from fuel feed tube.
- d. Install quick connector cap to quick connector connection.

### CAUTION:

- **Check that quick connector and fuel tube are securely fit into quick connector cap installation groove.**
- **If quick connector cap cannot be installed smoothly, quick connector may have not been installed correctly. Check connection again.**

11. Install in the reverse order of removal.



## Inspection

INFOID:000000006289555

## INSPECTION AFTER INSTALLATION

### Check for Fuel Leakage

1. Turn ignition switch “ON” (with the engine stopped). With fuel pressure applied to fuel piping, check that there is no fuel leakage at connection points.

### NOTE:

Use mirrors for checking at points out of clear sight.

2. Start the engine. With engine speed increased, check again that there is no fuel leakage at connection points.

# HIGH PRESSURE FUEL PUMP AND FUEL HOSE

< REMOVAL AND INSTALLATION >

---

**CAUTION:**

Never touch the engine immediately after it is stopped because the engine is extremely hot.

A

EM

C

D

E

F

G

H

I

J

K

L

M

N

O

P


# FUEL INJECTOR AND FUEL TUBE

< REMOVAL AND INSTALLATION >

## FUEL INJECTOR AND FUEL TUBE

Exploded View

INFOID:000000006289556



- |                                 |                                 |                                 |
|---------------------------------|---------------------------------|---------------------------------|
| 1. Fuel tube insulator (bank 2) | 2. Fuel tube insulator (center) | 3. Fuel tube insulator (bank 1) |
| 4. High pressure fuel pump      | 5. Fuel feed tube (pump side)   | 6. Fuel feed tube (bank side)   |
| 7. Fuel rail (bank 2)           | 8. Injector holder              | 9. O-ring (blue)                |
| 10. Backup ring                 | 11. Fuel injector               | 12. Seal ring                   |
| 13. Insulator                   | 14. Fuel rail (bank 1)          | 15. Gasket                      |
| 16. Fuel rail pressure sensor   |                                 |                                 |

Comply with the installation procedure when tightening. Refer to [EM-49, "Removal and Installation"](#).

Refer to [GI-4, "Components"](#) for symbols in the figure.

### CAUTION:

- Never remove or disassemble parts unless instructed as shown in the figure.
- Be sure to follow the tightening instruction to avoid fuel leakage.

# FUEL INJECTOR AND FUEL TUBE

## < REMOVAL AND INSTALLATION >

### Removal and Installation

INFOID:000000006289557

#### REMOVAL

##### **WARNING:**

- Be sure to read [EM-4, "Precaution for Handling High Pressure Fuel System"](#) when working on the high pressure fuel system.
- Put a "CAUTION: FLAMMABLE" sign in the workshop.
- Be sure to work in a well ventilated area and furnish workshop with a CO2 fire extinguisher.
- Never smoke while servicing fuel system. Keep open flames and sparks away from the work area.
- To avoid the danger of being scalded, never drain engine coolant when engine is hot.

1. Release fuel pressure. Refer to [EC-153, "Work Procedure"](#).
2. Remove intake manifold. Refer to [EM-30, "Removal and Installation"](#).
3. Remove fuel feed tube (pump side) and fuel feed tube (bank side).

##### **CAUTION:**


**Never reuse fuel feed tube.**

4. Remove fuel rail (bank 1) and fuel rail (bank 2).
5. Disconnect harness connector from fuel injectors.
6. Remove fuel injector from cylinder head as per the following:


##### **CAUTION:**

- Be careful with remaining fuel that may go out from fuel tube.
- Be careful not to damage injector nozzles during removal.
- Never bump or drop fuel injector.
- Never disassemble fuel injector.

- a. Remove injector holder.
- b. Install an injector remover [SST: KV10119600 (—)] (A) to the injector connector side so that cutout (B) of injector remover faces the injector connector side.




- Hook pawl portion (B) of injector remover [SST: KV10119600 (—)] (A) to groove portion (C) of injector.




## FUEL INJECTOR AND FUEL TUBE

### < REMOVAL AND INSTALLATION >


- c. Press down body portion (A) of injector remover [SST: KV10119600 (—)] until it contacts cylinder head.



- d. Tighten injector remover [SST: KV10119600 (—)] clockwise and remove injector from cylinder head.



- e. Cut Teflon seal (1) while pinching it. Be careful not to damage injector.
- f. Remove insulator from mounting hole of fuel injector of cylinder head.



### INSTALLATION

1. Install seal ring to fuel injector as per the following:

**CAUTION:**


- Handle seal ring with bare hands. Never wear gloves.
- Never apply engine oil to seal ring.
- Never clean seal ring with solvent.




## FUEL INJECTOR AND FUEL TUBE

### < REMOVAL AND INSTALLATION >

- a. Install an injector seal drift set [SST: KV101197S0 (—)] (A) to fuel injector (1).




- b. Set seal ring (1) to injector seal drift set [SST: KV101197S0 (—)] (A).



- c. Straightly insert seal ring (1), which is set in step 2, to fuel injector as shown in the figure and install.

**CAUTION:**


Be careful that seal ring does not exceed the groove portion of fuel injector.



- d. Insert injector seal drift set [SST: KV101197S0 (—)] (A) to injector and rotate clockwise and counterclockwise by 90° while pressing seal ring to fit it.

**NOTE:**

Compress seal ring, because this operation is for rectifying stretch of seal ring caused by installation and for preventing sticking when inserting injector into cylinder head.



2. Install O-ring and backup ring to fuel injector. When handing new O-ring and backup ring, paying attention to the following caution items:


**CAUTION:**

- Handle O-ring with bare hands. Never wear gloves.
- Lubricate O-ring with new engine oil.
- Never clean O-ring with solvent.
- Check that O-ring and its mating part are free of foreign material.
- When installing O-ring, be careful not to scratch it with tool or fingernails. Also be careful not to twist or stretch O-ring. If O-ring was stretched while it was being attached, never insert it quickly into fuel tube.
- Insert new O-ring straight into fuel rail. Never decenter or twist it.

# FUEL INJECTOR AND FUEL TUBE

## < REMOVAL AND INSTALLATION >

- Always install the back up ring (1) in the right direction as instructed.



3. Install fuel injector (1) to fuel rail (2) as per the following:

3 : O-ring (blue)


4 : Backup ring

- a. Install fuel injector holder (5) to fuel injector.

### CAUTION:

- Never reuse injector holder. Replace it with a new one.
- Be careful to keep fuel injector holder from interfering with O-ring. If interference occurs, replace O-ring.

- b. Insert fuel injector into fuel rail with fuel injector holder attached.
  - Insert it while matching it to the axial center.
  - Insert so that protrusion (A) of fuel injector is aligned to cutout (B).
- c. Check that installation is complete by checking that fuel injector does not rotate or come off.
  - Check that protrusions of fuel injectors and fuel rail are aligned with cutouts of clips after installation.



4. Insert insulator into mounting hole of fuel injector of cylinder head.
5. Install fuel rail and fuel injector assembly to cylinder head.
  - Tighten mounting bolts and nuts in two steps in numerical order as shown in the figure.

← : Engine front


**1st step** : 10.0 N·m (1.0 kg-m, 89 in-lb)

**2nd step** : 20.5 N·m (2.1 kg-m, 15 ft-lb)

6. Connect injector harness connector.
7. Install fuel feed tube (bank side) to fuel rail.

### CAUTION:


- When inserting fuel feed tube (bank side) to fuel rail, press the flange part to install the tube.
- Never use O-ring with any scoring.
- Never reuse fuel feed tube (bank side), O-ring and back up ring.



# FUEL INJECTOR AND FUEL TUBE


## < REMOVAL AND INSTALLATION >

- Apply engine oil to O-ring.



- Tighten mounting bolts in numerical order as shown in the figure.

← : Engine front



8. Install fuel feed tube (pump side) to fuel feed tube (bank side) as per the following:

### **CAUTION:**


**Never reuse fuel feed tube (pump side).**

- Apply engine oil to flare screw parts of high pressure pump side and fuel feed tube (bank side) side.
- Manually tighten 2 flare nuts without using a tool until they are seated to screw thread.
- Tighten mounting bolt (A).

B : To high pressure fuel pump

← : Engine front

- d. Tighten flare nuts in numerical order as shown in the figure.



9. Install in the reverse order of removal.

## Inspection

INFOID:000000006289558

## INSPECTION AFTER INSTALLATION

### Check for Fuel Leakage

- Turn ignition switch "ON" (with the engine stopped). With fuel pressure applied to fuel piping, check that there is no fuel leakage at connection points.

### **NOTE:**

Use mirrors for checking at points out of clear sight.

- Start the engine. With engine speed increased, check again that there is no fuel leakage at connection points.

### **CAUTION:**

**Never touch the engine immediately after it is stopped because the engine is extremely hot.**


# OIL PAN (LOWER) AND OIL STRAINER

< REMOVAL AND INSTALLATION >

## OIL PAN (LOWER) AND OIL STRAINER

Exploded View

INFOID:000000006289559



**Thank you very much  
for your reading.**

**Please Click Here**

**Then            Get            More  
Information.**