

KAWASAKI

EN450 & 500 Twins

1985 to 1993 □ 454cc □ 498cc

Owners Workshop Manual



2053



Phillip Cox

© HAYNES
1993

Identification numbers

The frame serial number is stamped into the right side of the steering head and the engine serial number is stamped into the right engine case. Both of these numbers should be recorded and kept in a safe place so they can be furnished to law enforcement officials in the event of theft.


The frame serial number, engine serial number and carburetor identification number should also be kept in a handy place (such as with your driver's license) so they are always available when purchasing or ordering parts for your machine.

The models covered by this manual are as follows:


- EN450-A1 (454 LTD, LTD 450) - 1985
- EN450-A2 (454 LTD, LTD 450) - 1986
- EN450-A3 (454 LTD, LTD 450) - 1987
- EN450-A4 (454 LTD, LTD 450) - 1988
- EN450-A5 (454 LTD, LTD 450) - 1989
- EN450-A6 (454 LTD, LTD 450) - 1990
- EN500-A1 (Vulcan 500) - 1990
- EN500-A2 (Vulcan 500) - 1991
- EN500-A3 (Vulcan 500) - 1992
- EN500-A4 (Vulcan 500) - 1993

The following table is a breakdown of the engine and frame numbers by model and year of production:

Year	Model Code	Frame number range	Engine number range
1985	EN450 A1	US JKAENGA1-FA000001 to 013000 UK EN450A-000001 to 013000	EN450EA-000001 to 013000 EN450AE-000001 to 012000
1986	EN450 A2	US JKAENGA1-GA013001 to 028000 UK EN450A-013001 to 028000	ENG450AE-013001 to 028000 EN450A-012001 to 026000
1987	EN450 A3	US JKAENGA1-HA028001 to 032000 UK EN450A-028001 to 032000	EN450EA-028001 to 030300 EN450A-026001 to 030300
1988	EN450 A4	US JKAENGA1-JA032001 to 035300 UK EN450A-030301-on	EN450A-032001 to 033000 EN450A-030301-on
1989	EN450 A5	US JKAENGA1-KA035301-on UK EN450A-035301-on	EN450A-033301-on EN450A-033301-on
1990	EN450 A6	US JKAENGA1-LA040001-on UK model not imported	EN450AE-033301-on
1990	EN500 A1	US JKAENVA1-LA000001 to 007000 UK EN500A-000001-on	EX500-008186 to 010200/011051 to 015050 EN500AE-018001-on
1991	EN500 A2	US JKAENVA1-MA007001 to 008185/ 010201 to 011050/015051 to 025000 UK EN500A1 continued	EX500AE-018001-on
1992	EN500 A3	JKAENVA1-NA025001 to 045000 UK EN500A-025001-on	EX500AE-018001-on EN500AE-018000-on
1993	EN500 A4	US JKAEXNA1-PA045001 UK EN500A3 continued	EN500AE-018000-on



The frame number appears on a decal on the steering head



The engine serial number is located on the right side of the engine case

Buying parts

Once you have found all the identification numbers, record them for reference when buying parts. Since the manufacturers change specifications, parts and vendors (companies that manufacture various components on the machine), providing the ID numbers is the only way to be reasonably sure that you are buying the correct parts.

Whenever possible, take the worn part to the dealer so direct comparison with the new component can be made. Along the trail from the manufacturer to the parts shelf, there are numerous places that the part can end up with the wrong number or be listed incorrectly.

The two places to purchase new parts for your motorcycle - the accessory store and the franchised dealer - differ in the type of parts

they carry. While dealers can obtain virtually every part for your motorcycle, the accessory dealer is usually limited to normal high wear items such as shock absorbers, tune-up parts, various engine gaskets, cables, chains, brake parts, etc. Rarely will an accessory outlet have major suspension components, cylinders, transmission gears, or cases.

Used parts can be obtained for roughly half the price of new ones, but you can't always be sure of what you're getting. Once again, take your worn part to the wrecking yard (breaker) for direct comparison.

Whether buying new, used or rebuilt parts, the best course is to deal directly with someone who specializes in parts for your particular make.

General specifications

Frame and suspension

Wheelbase	
EN450.....	1485 mm (58.46 inches)
EN500.....	1555 mm (61.22 inches)
Overall length	
EN450	
US.....	2205 mm (86.81 inches)
UK.....	2210 mm (87.00 inches)
EN500.....	2265 mm (89.17 inches)
Overall width	
EN450.....	820 mm (32.28 inches)
EN500.....	840 mm (33.07 inches)
Overall height	
EN450.....	1220 mm (48.03 inches)
EN500.....	1230 mm (48.42 inches)
Seat height	
EN450.....	745 mm (29.33 inches)
EN500.....	730 mm (28.74 inches)
Dry weight	
EN450	
US except California.....	180 kg (396 lbs)
California.....	180.5 kg (397.1 lbs)
UK.....	181 kg (398.2 lbs)
EN500	
Except California.....	186 kg (409.2 lbs)
California.....	186.5 kg (410.3 lbs)
Front suspension.....	Telescopic fork
Rear suspension.....	Twin shocks/coil springs
Front brake.....	Hydraulic disc
Rear brake.....	Mechanical drum
Fuel capacity.....	11.0 liters (2.9 US gallons, 2.51 Imp. gallons)

Engine

Type.....	Liquid cooled, 4-stroke, DOHC parallel twin
Displacement	
EN450.....	454 cc (27.68 cubic inches)
EN500.....	498 cc (30.36 cubic inches)
Ignition system.....	Transistorized
Fuel system.....	Two 34 mm Keihin carburetors
Clutch.....	Wet, multi-plate
Transmission.....	6-speed, constant mesh

Maintenance techniques, tools and working facilities

Basic maintenance techniques

There are a number of techniques involved in maintenance and repair that will be referred to throughout this manual. Application of these techniques will enable the amateur mechanic to be more efficient, better organized and capable of performing the various tasks properly, which will ensure that the repair job is thorough and complete.

Fastening systems

Fasteners, basically, are nuts, bolts and screws used to hold two or more parts together. There are a few things to keep in mind when working with fasteners. Almost all of them use a locking device of some type (either a lock washer, locknut, locking tab or thread adhesive). All threaded fasteners should be clean, straight, have undamaged threads and undamaged corners on the hex head where the wrench fits. Develop the habit of replacing all damaged nuts and bolts with new ones.

Rusted nuts and bolts should be treated with a penetrating oil to ease removal and prevent breakage. Some mechanics use turpentine in a spout type oil can, which works quite well. After applying the rust penetrant, let it "work" for a few minutes before trying to loosen the nut or bolt. Badly rusted fasteners may have to be chiseled off or removed with a special nut breaker, available at tool stores.

If a bolt or stud breaks off in an assembly, it can be drilled out and removed with a special tool called an E-Z out (or screw extractor). Most dealer service departments and motorcycle repair shops can perform this task, as well as others (such as the repair of threaded holes that have been stripped out).

Flat washers and lock washers, when removed from an assembly, should always be replaced exactly as removed. Replace any damaged washers with new ones. Always use a flat washer between a lock washer and any soft metal surface (such as aluminum), thin sheet metal or plastic. Special locknuts can only be used once or twice before they lose their locking ability and must be replaced.

Tightening sequences and procedures

When threaded fasteners are tightened, they are often tightened to a specific torque value (torque is basically a twisting force). Over-tightening the fastener can weaken it and cause it to break, while under-tightening can cause it to eventually come loose. Each bolt, depending on the material it's made of, the diameter of its shank and the material it is threaded into, has a specific torque value, which is noted in the Specifications. Be sure to follow the torque recommendations closely.

Fasteners laid out in a pattern (i.e. cylinder head bolts, engine case bolts, etc.) must be loosened or tightened in a sequence to avoid warping the component. Initially, the bolts/nuts should go on finger tight only. Next, they should be tightened one full turn each, in a criss-cross or diagonal pattern. After each one has been tightened one full turn, return to the first one tightened and tighten them all one half turn, following the same pattern. Finally, tighten each of them one quarter turn at a time until each fastener has been tightened to the proper torque. To loosen and remove the fasteners the procedure would be reversed.

Disassembly sequence

Component disassembly should be done with care and purpose to help ensure that the parts go back together properly during re-assembly. Always keep track of the sequence in which parts are removed. Take note of special characteristics or marks on parts that can be installed more than one way (such as a grooved thrust washer on a shaft). It's a good idea to lay the disassembled parts out on a clean

surface in the order that they were removed. It may also be helpful to make sketches or take instant photos of components before removal.

When removing fasteners from a component, keep track of their locations. Sometimes threading a bolt back in a part, or putting the washers and nut back on a stud, can prevent mixups later. If nuts and bolts can't be returned to their original locations, they should be kept in a compartmented box or a series of small boxes. A cupcake or muffin tin is ideal for this purpose, since each cavity can hold the bolts and nuts from a particular area (i.e. engine case bolts, valve cover bolts, engine mount bolts, etc.). A pan of this type is especially helpful when working on assemblies with very small parts (such as the carburetors and the valve train). The cavities can be marked with paint or tape to identify the contents.

Whenever wiring looms, harnesses or connectors are separated, it's a good idea to identify the two halves with numbered pieces of masking tape so they can be easily reconnected.

Gasket sealing surfaces

Throughout any motorcycle, gaskets are used to seal the mating surfaces between components and keep lubricants, fluids, vacuum or pressure contained in an assembly.

Many times these gaskets are coated with a liquid or paste type gasket sealing compound before assembly. Age, heat and pressure can sometimes cause the two parts to stick together so tightly that they are very difficult to separate. In most cases, the part can be loosened by striking it with a soft-faced hammer near the mating surfaces. A regular hammer can be used if a block of wood is placed between the hammer and the part. Do not hammer on cast parts or parts that could be easily damaged. With any particularly stubborn part, always recheck to make sure that every fastener has been removed.


Avoid using a screwdriver or bar to pry apart components, as they can easily mar the gasket sealing surfaces of the parts (which must remain smooth). If prying is absolutely necessary, use a piece of wood, but keep in mind that extra clean-up will be necessary if the wood splinters.

After the parts are separated, the old gasket must be carefully scraped off and the gasket surfaces cleaned. Stubborn gasket material can be soaked with a gasket remover (available in aerosol cans) to soften it so it can be easily scraped off. A scraper can be fashioned from a piece of copper tubing by flattening and sharpening one end. Copper is recommended because it is usually softer than the surfaces to be scraped, which reduces the chance of gouging the part. Some gaskets can be removed with a wire brush, but regardless of the method used, the mating surfaces must be left clean and smooth. If for some reason the gasket surface is gouged, then a gasket sealer thick enough to fill scratches will have to be used during reassembly of the components. For most applications, a non-drying (or semi-drying) gasket sealer is best.


Hose removal tips

Hose removal precautions closely parallel gasket removal precautions. Avoid scratching or gouging the surface that the hose mates against or the connection may leak. Because of various chemical reactions, the rubber in hoses can bond itself to the metal spigot that the hose fits over. To remove a hose, first loosen the hose clamps that secure it to the spigot. Then, with slip joint pliers, grab the hose at the clamp and rotate it around the spigot. Work it back and forth until it is completely free, then pull it off (silicone or other lubricants will ease removal if they can be applied between the hose and the outside of the spigot). Apply the same lubricant to the inside of the hose and the outside of the spigot to simplify installation.

If a hose clamp is broken or damaged, do not reuse it. Also, do not reuse hoses that are cracked, split or torn.




Spark plug gap adjusting tool



Feeler gauge set



Control cable pressure luber



Hand impact screwdriver and bits


Tools

A selection of good tools is a basic requirement for anyone who plans to maintain and repair a motorcycle. For the owner who has few tools, if any, the initial investment might seem high, but when compared to the spiraling costs of routine maintenance and repair, it is a wise one.

To help the owner decide which tools are needed to perform the tasks detailed in this manual, the following tool lists are offered: Maintenance and minor repair, Repair and overhaul and Special. The newcomer to practical mechanics should start off with the Maintenance and minor repair tool kit, which is adequate for the simpler jobs. Then, as confidence and experience grow, the owner can tackle more difficult tasks, buying additional tools as they are needed. Eventually the basic kit will be built into the Repair and overhaul tool set. Over a period of time, the experienced do-it-yourselfer will assemble a tool set complete enough for most repair and overhaul procedures and will add tools from the Special category when it is felt that the expense is justified by the frequency of use.

Maintenance and minor repair tool kit


The tools in this list should be considered the minimum required for performance of routine maintenance, servicing and minor repair work. We recommend the purchase of combination wrenches (box end



Torque wrenches (left - click type; right - beam type)




Snap-ring pliers (top - external; bottom - internal)




Allen wrenches (left) and Allen head sockets (right)




Valve spring compressor



Piston ring removal/installation tool




Piston pin puller




Telescoping gauges



0-to-1-inch micrometer



Cylinder surfacing hone




Cylinder compression gauge




Dial indicator set



Multimeter (volt/ohm/ammeter)



Adjustable spanner



Alternator rotor puller

and open end combined in one wrench); while more expensive than open-ended ones, they offer the advantages of both types of wrench.

Combination wrench set (6 mm to 22 mm)
Adjustable wrench - 8 in
Spark plug socket (with rubber insert)
Spark plug gap adjusting tool
Feeler gauge set
Standard screwdriver (5/16 in x 6 in)
Phillips screwdriver (No. 2 x 6 in)
Allen (hex) wrench set (4 mm to 12 mm)
Combination (slip-joint) pliers - 6 in
Hacksaw and assortment of blades
Tire pressure gauge
Control cable pressure luber
Grease gun
Oil can
Fine emery cloth
Wire brush
Hand impact screwdriver and bits
Funnel (medium size)
Safety goggles
Drain pan
Work light with extension cord

Repair and overhaul tool set

These tools are essential for anyone who plans to perform major repairs and are intended to supplement those in the Maintenance and minor repair tool kit. Included is a comprehensive set of sockets which, though expensive, are invaluable because of their versatility (especially when various extensions and drives are available). We recommend the 3/8 inch drive over the 1/2 inch drive for general motorcycle maintenance and repair (ideally, the mechanic would have a 3/8 inch drive set and a 1/2 inch drive set).

Socket set(s)
Reversible ratchet
Extension - 6 in
Universal joint
Torque wrench (same size drive as sockets)
Ball peen hammer - 8 oz
Soft-faced hammer (plastic/rubber)
Standard screwdriver (1/4 in x 6 in)
Standard screwdriver (stubby - 5/16 in)
Phillips screwdriver (No. 3 x 8 in)
Phillips screwdriver (stubby - No. 2)
Pliers - locking
Pliers - lineman's
Pliers - needle nose
Pliers - snap-ring (internal and external)
Cold chisel - 1/2 in

Scriber
Scraper (made from flattened copper tubing)
Center punch
Pin punches (1/16, 1/8, 3/16 in)
Steel rule/straightedge - 12 in
Pin-type spanner wrench
A selection of files
Wire brush (large)

Note: Another tool which is often useful is an electric drill with a chuck capacity of 3/8 inch (and a set of good quality drill bits).

Special tools

The tools in this list include those which are not used regularly, are expensive to buy, or which need to be used in accordance with their manufacturer's instructions. Unless these tools will be used frequently, it is not very economical to purchase many of them. A consideration would be to split the cost and use between yourself and a friend or friends (e.g. members of a motorcycle club).

This list primarily contains tools and instruments widely available to the public, as well as some special tools produced by the vehicle manufacturer for distribution to dealer service departments. As a result, references to the manufacturer's special tools are occasionally included in the text of this manual. Generally, an alternative method of doing the job without the special tool is offered. However, sometimes there is no alternative to their use. Where this is the case, and the tool can't be purchased or borrowed, the work should be turned over to the dealer service department or a motorcycle repair shop.

Valve spring compressor
Piston ring removal and installation tool
Piston pin puller
Telescoping gauges
Micrometer(s) and/or dial/Vernier calipers
Cylinder surfacing hone
Cylinder compression gauge
Dial indicator set
Multimeter
Adjustable spanner
Alternator rotor holder
Alternator rotor puller
Manometer or vacuum gauge set
Small air compressor with blow gun and tire chuck

Buying tools

For the do-it-yourselfer who is just starting to get involved in motorcycle maintenance and repair, there are a number of options available when purchasing tools. If maintenance and minor repair is the extent of the work to be done, the purchase of individual tools is satisfactory. If, on the other hand, extensive work is planned, it would be a good idea to purchase a modest tool set from one of the large retail chain stores. A set can usually be bought at a substantial savings over the individual tool prices (and they often come with a tool box). As additional tools are needed, add-on sets, individual tools and a larger tool box can be purchased to expand the tool selection. Building a tool set gradually allows the cost of the tools to be spread over a longer period of time and gives the mechanic the freedom to choose only those tools that will actually be used.

Tool stores and motorcycle dealers will often be the only source of some of the special tools that are needed, but regardless of where tools are bought, try to avoid cheap ones (especially when buying screwdrivers and sockets) because they won't last very long. There are plenty of tools around at reasonable prices, but always aim to purchase items which meet the relevant national safety standards. The expense involved in replacing cheap tools will eventually be greater than the initial cost of quality tools.

It is obviously not possible to cover the subject of tools fully here. For those who wish to learn more about tools and their use, there is a book entitled *Motorcycle Workshop Practice Manual* (Book no. 1454) available from the publishers of this manual. It also provides an introduction to basic workshop practice which will be of interest to a home mechanic working on any type of motorcycle.

Troubleshooting

Contents

Symptom	Section	Symptom	Section
Engine doesn't start or is difficult to start		Abnormal engine noise	
Starter motor does not rotate.....	1	Knocking or pinging.....	31
Starter motor rotates but engine does not turn over.....	2	Piston slap or rattling.....	32
Starter works but engine won't turn over (seized).....	3	Valve noise.....	33
No fuel flow.....	4	Other noise.....	34
Engine flooded.....	5		
No spark or weak spark.....	6	Abnormal driveline noise	
Compression low.....	7	Clutch noise.....	35
Stalls after starting.....	8	Transmission noise.....	36
Rough idle.....	9	Belt or final drive noise.....	37
Poor running at low speed		Abnormal frame and suspension noise	
Spark weak.....	10	Front end noise.....	38
Fuel/air mixture incorrect.....	11	Shock absorber noise.....	39
Compression low.....	12	Disc brake noise.....	40
Poor acceleration.....	13		
		Oil pressure indicator light comes on	
Poor running or no power at high speed		Engine lubrication system.....	41
Firing incorrect.....	14	Electrical system.....	42
Fuel/air mixture incorrect.....	15		
Compression low.....	16	Excessive exhaust smoke	
Knocking or pinging.....	17	White smoke.....	43
Miscellaneous causes.....	18	Black smoke.....	44
		Brown smoke.....	45
Overheating			
Cooling system not operating properly.....	19	Poor handling or stability	
Firing incorrect.....	20	Handlebar hard to turn.....	46
Fuel/air mixture incorrect.....	21	Handlebar shakes or vibrates excessively.....	47
Compression too high.....	22	Handlebar pulls to one side.....	48
Engine load excessive.....	23	Poor shock absorbing qualities.....	49
Lubrication inadequate.....	24		
Miscellaneous causes.....	25	Braking problems	
		Brakes are spongy, don't hold.....	50
Clutch problems		Brake lever pulsates.....	51
Clutch slipping.....	26	Brakes drag.....	52
Clutch not disengaging completely.....	27		
		Electrical problems	
Gear shifting problems		Battery dead or weak.....	53
Doesn't go into gear, or lever doesn't return.....	28	Battery overcharged.....	54
Jumps out of gear.....	29		
Overshifts.....	30		

Engine doesn't start or is difficult to start

1 Starter motor does not rotate

- 1 Engine stop switch Off.
- 2 Fuse blown. Check main fuse under the seat (EN450) or the starter relay (EN500) (Chapter 9).
- 3 Battery voltage low. Check and recharge battery (Chapter 9).
- 4 Starter motor defective. Make sure the wiring to the starter is secure. Make sure the starter solenoid (relay) clicks when the start button is pushed. If the solenoid clicks, then the fault is in the wiring or motor.
- 5 Starter solenoid (relay) faulty. It is located under the seat. Check it according to the procedure in Chapter 9.
- 6 Starter button not contacting. The contacts could be wet, corroded or dirty. Disassemble and clean the switch (Chapter 9).
- 7 Wiring open or shorted. Check all wiring connections and harnesses to make sure that they are dry, tight and not corroded. Also check for broken or frayed wires that can cause a short to ground/earth (see wiring diagram, Chapter 9).
- 8 Ignition switch defective. Check the switch according to the procedure in Chapter 9. Replace the switch with a new one if it is defective.
- 9 Engine stop switch defective. Check for wet, dirty or corroded contacts. Clean or replace the switch as necessary (Chapter 9).
- 10 Faulty starter lockout switch. Check the wiring to the switch and the switch itself according to the procedures in Chapter 9.

2 Starter motor rotates but engine does not turn over

- 1 Starter motor clutch defective. Inspect and repair or replace (Chapter 2).
- 2 Damaged idler or starter gears. Inspect and replace the damaged parts (Chapter 2).

3 Starter works but engine won't turn over (seized)

Seized engine caused by one or more internally damaged components. Failure due to wear, abuse or lack of lubrication. Damage can include seized valves, valve lifters, camshaft, pistons, crankshaft, connecting rod bearings, or transmission gears or bearings. Refer to Chapter 2 for engine disassembly.

4 No fuel flow

- 1 No fuel in tank.
- 2 Fuel tap vacuum hose broken or disconnected.
- 3 Tank cap air vent obstructed. Usually caused by dirt or water. Remove it and clean the cap vent hole.
- 4 Fuel tap clogged. Remove the tap and clean it and the filter (Chapter 4).
- 5 Fuel line clogged. Pull the fuel line loose and carefully blow through it.
- 6 Inlet needle valves clogged. For both the valves to be clogged, either a very bad batch of fuel with an unusual additive has been used, or some other foreign object has entered the tank. Many times after a machine has been stored for many months without running, the fuel turns to a varnish-like liquid and forms deposits on the inlet needle valves and jets. The carburetors should be removed and overhauled if draining the float bowls does not alleviate the problem.

5 Engine flooded

- 1 Float level too high. Check and adjust as described in Chapter 4.

2 Inlet needle valve worn or stuck open. A piece of dirt, rust or other debris can cause the inlet needle to seat improperly, causing excess fuel to be admitted to the float bowl. In this case, the float chamber should be cleaned and the needle and seat inspected. If the needle and seat are worn, then the leaking will persist and the parts should be replaced with new ones (Chapter 4).

3 Starting technique incorrect. Under normal circumstances (i.e., if all the carburetor functions are sound) the machine should start with little or no throttle. When the engine is cold, the choke should be operated and the engine started without opening the throttle. When the engine is at operating temperature, only a very slight amount of throttle should be necessary. If the engine is flooded, turn the fuel tap off and hold the throttle open while cranking the engine. This will allow additional air to reach the cylinders. Remember to turn the fuel back on after the engine starts.

6 No spark or weak spark

- 1 Ignition switch Off.
- 2 Engine stop switch turned to the Off position.
- 3 Battery voltage low. Check and recharge battery as necessary (Chapter 9).
- 4 Spark plug dirty, defective or worn out. Locate reason for fouled plug(s) using spark plug condition chart and follow the plug maintenance procedures in Chapter 1.
- 5 Spark plug cap or high-tension wiring faulty. Check condition. Replace either or both components if cracks or deterioration are evident.
- 6 Spark plug cap not making good contact. Make sure that the plug cap fits snugly over the plug end.
- 7 IC igniter defective. Check the unit, referring to Chapter 5 for details.
- 8 Pickup coil defective. Check the unit, referring to Chapter 5 for details.
- 9 Ignition coil(s) defective. Check the coils, referring to Chapter 5.
- 10 Ignition or stop switch shorted. This is usually caused by water, corrosion, damage or excessive wear. The switches can be disassembled and cleaned with electrical contact cleaner. If cleaning does not help, replace the switches (Chapter 9).
- 11 Wiring shorted or broken between:
 - a) Ignition switch and engine stop switch
 - b) IC igniter and engine stop switch
 - c) IC igniter and ignition coil
 - d) Ignition coil and plug
 - e) IC igniter and pickup coils

Make sure that all wiring connections are clean, dry and tight. Look for chafed and broken wires (Chapters 5 and 9).

7 Compression low

- 1 Spark plug loose. Remove the plug and inspect the threads. Reinstall and tighten to the specified torque (Chapter 1).
- 2 Cylinder head not sufficiently tightened down. If the cylinder head is suspected of being loose, then there's a chance that the gasket or head is damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).
- 3 Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- 4 Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top end overhaul is necessary (Chapter 2).
- 5 Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburetion problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top end overhaul is necessary (Chapter 2).
- 6 Piston ring-to-groove clearance excessive. This is caused by ex-

cessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).

7 Cylinder head gasket damaged. If the head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).

8 Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).

9 Valve spring broken or weak. Caused by component failure or wear; the spring(s) must be replaced (Chapter 2).

10 Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburetion) or an accumulation of carbon deposits on the seat (from carburetion, lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

8 Stalls after starting

- 1 Improper choke action. Make sure the choke rod is getting a full stroke and staying in the "out" position.
- 2 Ignition malfunction. See Chapter 5.
- 3 Carburetor malfunction. See Chapter 4.
- 4 Fuel contaminated. The fuel can be contaminated with either dirt or water, or can change chemically if the machine is allowed to sit for several months or more. Drain the tank and float bowls (Chapter 4).
- 5 Intake air leak. Check for loose carburetor-to-intake manifold connections, loose or missing vacuum gauge access port cap or hose, or loose carburetor top (Chapter 4).
- 6 Idle speed incorrect. Turn idle speed adjuster screw until the engine idles at the specified rpm (Chapters 1 and 4).

9 Rough idle

- 1 Ignition malfunction. See Chapter 5.
- 2 Idle speed incorrect. See Chapter 1.
- 3 Carburetors not synchronized. Adjust carburetors with vacuum gauge set or manometer as outlined in Chapter 1.
- 4 Carburetor malfunction. See Chapter 4.
- 5 Fuel contaminated. The fuel can be contaminated with either dirt or water, or can change chemically if the machine is allowed to sit for several months or more. Drain the tank and float bowls. If the problem is severe, a carburetor overhaul may be necessary (Chapters 1 and 4).
- 6 Intake air leak.
- 7 Air filter clogged. Service or replace air filter element (Chapter 1).

Poor running at low speed

10 Spark weak

- 1 Battery voltage low. Check and recharge battery (Chapter 9).
- 2 Spark plug fouled, defective or worn out. Refer to Chapter 1 for spark plug maintenance.
- 3 Spark plug cap or high tension wiring defective. Refer to Chapters 1 and 5 for details on the ignition system.
- 4 Spark plug cap not making contact.
- 5 Incorrect spark plug. Wrong type, heat range or cap configuration. Check and install correct plugs listed in Chapter 1. A cold plug or one with a recessed firing electrode will not operate at low speeds without fouling.
- 6 IC igniter defective. See Chapter 5.
- 7 Pickup coil defective. See Chapter 5.
- 8 Ignition coil(s) defective. See Chapter 5.

11 Fuel/air mixture incorrect

- 1 Pilot screw(s) out of adjustment (Chapters 1 and 4).
- 2 Pilot jet or air passage clogged. Remove and overhaul the carburetors (Chapter 4).
- 3 Air bleed holes clogged. Remove carburetor and blow out all passages (Chapter 4).
- 4 Air filter clogged, poorly sealed or missing.
- 5 Air filter-to-carburetor boot poorly sealed. Look for cracks, holes or loose clamps and replace or repair defective parts.
- 6 Fuel level too high or too low. Adjust the floats (Chapter 4).
- 7 Fuel tank air vent obstructed. Make sure that the air vent passage in the filler cap is open.
- 8 Carburetor intake manifolds loose. Check for cracks, breaks, tears or loose clamps or bolts. Repair or replace the rubber boots.

12 Compression low

- 1 Spark plug loose. Remove the plug and inspect the threads. Reinstall and tighten to the specified torque (Chapter 1).
- 2 Cylinder head not sufficiently tightened down. If the cylinder head is suspected of being loose, then there's a chance that the gasket and head are damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).
- 3 Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- 4 Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top end overhaul is necessary (Chapter 2).
- 5 Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburetion problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top end overhaul is necessary (Chapter 2).
- 6 Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).
- 7 Cylinder head gasket damaged. If the head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).
- 8 Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).
- 9 Valve spring broken or weak. Caused by component failure or wear; the spring(s) must be replaced (Chapter 2).
- 10 Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburetion) or an accumulation of carbon deposits on the seat (from carburetion, lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

13 Poor acceleration

- 1 Carburetors leaking or dirty. Overhaul the carburetors (Chapter 4).
- 2 Timing not advancing. The pickup coil unit or the IC igniter may be defective. If so, they must be replaced with new ones, as they cannot be repaired.
- 3 Carburetors not synchronized. Adjust them with a vacuum gauge set or manometer (Chapter 1).
- 4 Engine oil viscosity too high. Using a heavier oil than that recommended in Chapter 1 can damage the oil pump or lubrication system and cause drag on the engine.
- 5 Brakes dragging. In front, usually caused by debris which has entered the brake piston sealing boot, or from a warped disc or bent axle.

Repair as necessary (Chapter 7). In the rear, may be caused by a sticking brake cable. Clean and lubricate (see Chapter 1).

Poor running or no power at high speed

14 Firing incorrect

- 1 Air filter restricted. Clean or replace filter (Chapter 1).
- 2 Spark plug fouled, defective or worn out. See Chapter 1 for spark plug maintenance.
- 3 Spark plug cap or high tension wiring defective. See Chapters 1 and 5 for details on the ignition system.
- 4 Spark plug cap not in good contact. See Chapter 5.
- 5 Incorrect spark plug. Wrong type, heat range or cap configuration. Check and install correct plugs listed in Chapter 1. A cold plug or one with a recessed firing electrode will not operate at low speeds without fouling.
- 6 IC igniter defective. See Chapter 5.
- 7 Ignition coil(s) defective. See Chapter 5.

15 Fuel/air mixture incorrect

- 1 Main jet clogged. Dirt, water and other contaminants can clog the main jets. Clean the fuel tap filter, the float bowl area, and the jets and carburetor orifices (Chapter 4).
- 2 Main jet wrong size. The standard jetting is for sea level atmospheric pressure and oxygen content.
- 3 Throttle shaft-to-carburetor body clearance excessive. Refer to Chapter 4 for inspection and part replacement procedures.
- 4 Air bleed holes clogged. Remove and overhaul carburetors (Chapter 4).
- 5 Air filter clogged, poorly sealed or missing.
- 6 Air filter-to-carburetor boot poorly sealed. Look for cracks, holes or loose clamps, and replace or repair defective parts.
- 7 Fuel level too high or too low. Adjust the float(s) (Chapter 4).
- 8 Fuel tank air vent obstructed. Make sure the air vent passage in the filler cap is open.
- 9 Carburetor intake manifolds loose. Check for cracks, breaks, tears or loose clamps or bolts. Repair or replace the rubber boots (Chapter 2).
- 10 Fuel tap clogged. Remove the tap and clean it and the filter (Chapter 1).
- 11 Fuel line clogged. Pull off the fuel line loose and carefully blow through it.

16 Compression low

- 1 Spark plug loose. Remove the plugs and inspect threads. Reinstall and tighten to the specified torque (Chapter 1).
- 2 Cylinder head not sufficiently tightened down. If the cylinder head is suspected of being loose, then there's a chance that the gasket and head are damaged if the problem has persisted for any length of time. The head bolts should be tightened to the proper torque in the correct sequence (Chapter 2).
- 3 Improper valve clearance. This means that the valve is not closing completely and compression pressure is leaking past the valve. Check and adjust the valve clearances (Chapter 1).
- 4 Cylinder and/or piston worn. Excessive wear will cause compression pressure to leak past the rings. This is usually accompanied by worn rings as well. A top end overhaul is necessary (Chapter 2).
- 5 Piston rings worn, weak, broken, or sticking. Broken or sticking piston rings usually indicate a lubrication or carburetion problem that causes excess carbon deposits or seizures to form on the pistons and rings. Top end overhaul is necessary (Chapter 2).
- 6 Piston ring-to-groove clearance excessive. This is caused by excessive wear of the piston ring lands. Piston replacement is necessary (Chapter 2).

7 Cylinder head gasket damaged. If the head is allowed to become loose, or if excessive carbon build-up on the piston crown and combustion chamber causes extremely high compression, the head gasket may leak. Retorquing the head is not always sufficient to restore the seal, so gasket replacement is necessary (Chapter 2).

8 Cylinder head warped. This is caused by overheating or improperly tightened head bolts. Machine shop resurfacing or head replacement is necessary (Chapter 2).

9 Valve spring broken or weak. Caused by component failure or wear; the spring(s) must be replaced (Chapter 2).

10 Valve not seating properly. This is caused by a bent valve (from over-revving or improper valve adjustment), burned valve or seat (improper carburetion) or an accumulation of carbon deposits on the seat (from carburetion, lubrication problems). The valves must be cleaned and/or replaced and the seats serviced if possible (Chapter 2).

17 Knocking or pinging

- 1 Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).
- 2 Incorrect or poor quality fuel. Old or improper grades of gasoline (petrol) can cause detonation. This causes the piston to rattle, thus the knocking or pinging sound. Drain old fuel and always use the recommended fuel grade.
- 3 Spark plug heat range incorrect. Uncontrolled detonation indicates the plug heat range is too hot. The plug in effect becomes a glow plug, raising cylinder temperatures. Install the proper heat range plug (Chapter 1).
- 4 Improper air/fuel mixture. This will cause the cylinder to run hot, which leads to detonation. Clogged jets or an air leak can cause this imbalance. See Chapter 4.

18 Miscellaneous causes

- 1 Throttle valve doesn't open fully. Adjust the cable slack (Chapter 1).
- 2 Clutch slipping. Caused by a cable that is improperly adjusted or snagging or damaged, loose or worn clutch components. Refer to Chapters 1 and 2 for adjustment and overhaul procedures.
- 3 Timing not advancing.
- 4 Engine oil viscosity too high. Using a heavier oil than the one recommended in Chapter 1 can damage the oil pump or lubrication system and cause drag on the engine.
- 5 Brakes dragging. In front, usually caused by debris which has entered the brake piston sealing boot, or from a warped disc or bent axle. Repair as necessary. In the rear, may be caused by a sticking brake cable. Clean and lubricate (see Chapter 1).

Overheating

19 Cooling system not operating properly

- 1 Coolant level low. Check coolant level as described in Chapter 1. If coolant level is low, the engine will overheat.
- 2 Leak in cooling system. Check cooling system hoses and radiator for leaks and other damage. Repair or replace parts as necessary (Chapter 3).
- 3 Thermostat sticking open or closed. Check and replace as described in Chapter 3.
- 4 Faulty radiator cap. Remove the cap and have it pressure checked at a service station.
- 5 Coolant passages clogged. Have the entire system drained and

flushed, then refill with new coolant.

- 6 Water pump defective. Remove the pump and check the components.
- 7 Clogged radiator fins. Clean them by blowing compressed air through the fins from the back side.

20 Firing incorrect

- 1 Spark plug fouled, defective or worn out. See Chapter 1 for spark plug maintenance.
- 2 Incorrect spark plugs.
- 3 Faulty ignition coils (Chapter 5).

21 Fuel/air mixture incorrect

- 1 Main jet clogged. Dirt, water and other contaminants can clog the main jets. Clean the fuel tap filter, the float bowl area and the jets and carburetor orifices (Chapter 4).
- 2 Main jet wrong size. The standard jetting is for sea level atmospheric pressure and oxygen content.
- 3 Air filter poorly sealed or missing.
- 4 Air filter-to-carburetor boot poorly sealed. Look for cracks, holes or loose clamps and replace or repair.
- 5 Fuel level too low. Adjust the float(s) (Chapter 4).
- 6 Fuel tank air vent obstructed. Make sure that the air vent passage in the filler cap is open.
- 7 Carburetor intake manifolds loose. Check for cracks, breaks, tears or loose clamps or bolts. Repair or replace the rubber boots (Chapter 2).

22 Compression too high

- 1 Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).
- 2 Improperly machined head surface or installation of incorrect gasket during engine assembly. Check Specifications (Chapter 2).

23 Engine load excessive

- 1 Clutch slipping. Caused by an out of adjustment or snagging cable or damaged, loose or worn clutch components. Refer to Chapters 1 and 2 for adjustment and overhaul procedures.
- 2 Engine oil level too high. The addition of too much oil will cause pressurization of the crankcase and inefficient engine operation. Check Specifications and drain to proper level (Chapter 1).
- 3 Engine oil viscosity too high. Using a heavier oil than the one recommended in Chapter 1 can damage the oil pump or lubrication system as well as cause drag on the engine.
- 4 Brakes dragging. In front, usually caused by debris which has entered the brake piston sealing boot, or from a warped disc or bent axle. Repair as necessary (Chapter 7). In the rear, may be caused by a sticking brake cable. Clean and lubricate (Chapter 1).

24 Lubrication inadequate

- 1 Engine oil level too low. Friction caused by intermittent lack of lubrication or from oil that is overworked can cause overheating. The oil provides a definite cooling function in the engine. Check the oil level (Chapter 1).
- 2 Poor quality engine oil or incorrect viscosity or type. Oil is rated not only according to viscosity but also according to type. Some oils

are not rated high enough for use in this engine. Check the Specifications section and change to the correct oil (Chapter 1).

25 Miscellaneous causes

Modification to exhaust system. Most aftermarket exhaust systems cause the engine to run leaner, which makes it run hotter. When installing an accessory exhaust system, always check whether you need to rejet the carburetors.

Clutch problems

26 Clutch slipping

- 1 No clutch lever play. Adjust clutch lever free play according to the procedure in Chapter 1.
- 2 Friction plates worn or warped. Overhaul the clutch assembly (Chapter 2).
- 3 Steel plates worn or warped (Chapter 2).
- 4 Clutch springs broken or weak. Old or heat-damaged (from slipping clutch) springs should be replaced with new ones (Chapter 2).
- 5 Clutch release not adjusted properly. See Chapter 1.
- 6 Clutch inner cable hanging up. Caused by a frayed cable or kinked outer cable. Replace the cable. Repair of a frayed cable is not advised.
- 7 Clutch release mechanism defective. Check the release shaft, pushrod and bearings. Replace any defective parts (Chapter 2).
- 8 Clutch hub or housing unevenly worn. This causes improper engagement of the plates. Replace the damaged or worn parts (Chapter 2).

27 Clutch not disengaging completely

- 1 Clutch lever play excessive. Adjust at bars or at engine (Chapter 1).
- 2 Clutch plates warped or damaged. This will cause clutch drag, which in turn causes the machine to creep. Overhaul the clutch assembly (Chapter 2).
- 3 Clutch spring tension uneven. Usually caused by a sagged or broken spring. Check and replace the springs (Chapter 2).
- 4 Engine oil deteriorated. Old, thin, worn out oil will not provide proper lubrication for the plates, causing the clutch to drag. Replace the oil and filter (Chapter 1).
- 5 Engine oil viscosity too high. Using a heavier oil than recommended in Chapter 1 can cause the plates to stick together, putting a drag on the engine. Change to the correct weight oil (Chapter 1).
- 6 Clutch housing seized on shaft. Lack of lubrication, severe wear or damage can cause the housing to seize on the shaft. Overhaul of the clutch, and perhaps transmission, may be necessary to repair damage (Chapter 2).
- 7 Clutch release mechanism defective. Worn or damaged release mechanism parts can stick and fail to apply force to the pressure plate. Overhaul the clutch cover components (Chapter 2).
- 8 Loose clutch hub nut. Causes housing and hub misalignment putting a drag on the engine. Engagement adjustment continually varies. Overhaul the clutch assembly (Chapter 2).

Gear shifting problems

28 Doesn't go into gear or lever doesn't return

- 1 Clutch not disengaging. See Section 27.
- 2 Shift fork(s) bent or seized. Often caused by dropping the machine or from lack of lubrication. Overhaul the transmission (Chapter 2).

- 3 Gear(s) stuck on shaft. Most often caused by a lack of lubrication or excessive wear in transmission bearings and bushings. Overhaul the transmission (Chapter 2).
- 4 Shift drum binding. Caused by lubrication failure or excessive wear. Replace the drum and bearings (Chapter 2).
- 5 Shift lever return spring weak or broken (Chapter 2).
- 6 Shift lever broken. Splines stripped out of lever or shaft, caused by allowing the lever to get loose or from dropping the machine. Replace necessary parts (Chapter 2).
- 7 Shift arm pawl broken or worn. Full engagement and rotary movement of shift drum results. Replace shaft assembly (Chapter 2).
- 8 Pawl spring broken. Allows pawl to "float", causing sporadic shift operation. Replace spring (Chapter 2).

29 Jumps out of gear

- 1 Shift fork(s) worn. Overhaul the transmission (Chapter 2).
- 2 Gear groove(s) worn. Overhaul the transmission (Chapter 2).
- 3 Gear dogs or dog slots worn or damaged. The gears should be inspected and replaced. No attempt should be made to service the worn parts.

30 Overshifts

- 1 Pawl spring weak or broken (Chapter 2).
- 2 Shift drum positioning lever not functioning (Chapter 2).

Abnormal engine noise

31 Knocking or pinging

- 1 Carbon build-up in combustion chamber. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the piston crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head will have to be removed and decarbonized (Chapter 2).
- 2 Incorrect or poor quality fuel. Old or improper fuel can cause detonation. This causes the piston to rattle, thus the knocking or pinging sound. Drain the old fuel and always use the recommended grade fuel (Chapter 4).
- 3 Spark plug heat range incorrect. Uncontrolled detonation indicates that the plug heat range is too hot. The plug in effect becomes a glow plug, raising cylinder temperatures. Install the proper heat range plug (Chapter 1).
- 4 Improper air/fuel mixture. This will cause the cylinder to run hot and lead to detonation. Clogged jets or an air leak can cause this imbalance. See Chapter 4.

32 Piston slap or rattling

- 1 Cylinder-to-piston clearance excessive. Caused by improper assembly. Inspect and overhaul top end parts (Chapter 2).
- 2 Connecting rod bent. Caused by over-revving, trying to start a badly flooded engine or from ingesting a foreign object into the combustion chamber. Replace the damaged parts (Chapter 2).
- 3 Piston pin or piston pin bore worn or seized from wear or lack of lubrication. Replace damaged parts (Chapter 2).
- 4 Piston ring(s) worn, broken or sticking. Overhaul the top end (Chapter 2).
- 5 Piston seizure damage. Usually from lack of lubrication or overheating. Replace the pistons and bore the cylinders, as necessary (Chapter 2).
- 6 Connecting rod bearing and/or piston pin-end clearance excessive. Caused by excessive wear or lack of lubrication. Replace worn parts.

33 Valve noise

- 1 Incorrect valve clearances. Adjust the clearances by referring to Chapter 1.
- 2 Valve spring broken or weak. Check and replace weak valve springs (Chapter 2).
- 3 Camshaft or cylinder head worn or damaged. Lack of lubrication at high rpm is usually the cause of damage. Insufficient oil or failure to change the oil at the recommended intervals are the chief causes. Since there are no replaceable bearings in the head, the head itself will have to be replaced if there is excessive wear or damage (Chapter 2).

34 Other noise

- 1 Cylinder head gasket leaking. This will cause compression leakage into the cooling system (which may show up as air bubbles in the coolant in the radiator). Also, coolant may get into the oil (which will turn the oil gray). In either case, have the cooling system checked by a dealer service department.
- 2 Exhaust pipe leaking at cylinder head connection. Caused by improper fit of pipe(s) or loose exhaust flange. All exhaust fasteners should be tightened evenly and carefully. Failure to do this will lead to a leak.
- 3 Crankshaft runout excessive. Caused by a bent crankshaft (from over-revving) or damage from an upper cylinder component failure. Can also be attributed to dropping the machine on either of the crankshaft ends.
- 4 Engine mounting bolts loose. Tighten all engine mount bolts to the specified torque (Chapter 2).
- 5 Crankshaft bearings worn (Chapter 2).
- 6 Camshaft chain tensioner defective. Replace according to the procedure in Chapter 2.
- 7 Camshaft chain, sprockets or guides worn (Chapter 2).
- 8 Loose alternator rotor. Tighten the mounting bolt to the specified torque (Chapter 2).

Abnormal driveline noise

35 Clutch noise

- 1 Clutch housing/friction plate clearance excessive (Chapter 2).
- 2 Loose or damaged clutch pressure plate and/or bolts (Chapter 2).

36 Transmission noise

- 1 Bearings worn. Also includes the possibility that the shafts are worn. Overhaul the transmission (Chapter 2).
- 2 Gears worn or chipped (Chapter 2).
- 3 Metal chips jammed in gear teeth. Probably pieces from a broken clutch, gear or shift mechanism that were picked up by the gears. This will cause early bearing failure (Chapter 2).
- 4 Engine oil level too low. Causes a howl from transmission. Also affects engine power and clutch operation (Chapter 1).

37 Final drive noise

- 1 Belt not adjusted properly (Chapter 1).
- 2 Pulley (engine or rear wheel) loose. Tighten fasteners (Chapter 6).
- 3 Pulley(s) worn. Replace pulley(s) (Chapter 6).
- 4 Rear pulley warped. Replace (Chapter 6).
- 5 Wheel coupling worn. Replace coupling (Chapter 6).

Abnormal frame and suspension noise

38 Front end noise

- 1 Low fluid level or improper viscosity oil in forks. This can sound like "spurring" and is usually accompanied by irregular fork action (Chapter 6).
- 2 Spring weak or broken. Makes a clicking or scraping sound. Fork oil, when drained, will have a lot of metal particles in it (Chapter 6).
- 3 Steering head bearings loose or damaged. Clicks when braking. Check and adjust or replace as necessary (Chapters 1 and 6).
- 4 Fork clamps loose. Make sure all fork clamp pinch bolts are tight (Chapter 6).
- 5 Fork tube bent. Good possibility if machine has been dropped. Replace tube with a new one (Chapter 6).
- 6 Front axle or axle clamp bolt loose. Tighten them to the specified torque (Chapter 7).

39 Shock absorber noise

- 1 Fluid level incorrect. Indicates a leak caused by defective seal. Shock will be covered with oil. Replace shock (Chapter 6).
- 2 Defective shock absorber with internal damage. This is in the body of the shock and cannot be remedied. The shock must be replaced with a new one (Chapter 6).
- 3 Bent or damaged shock body. Replace the shock with a new one (Chapter 6).

40 Brake noise

- 1 Squeal caused by pad shim not installed or positioned correctly (Chapter 7).
- 2 Squeal caused by dust on brake pads. Usually found in combination with glazed pads. Clean using brake cleaning solvent (Chapter 7).
- 3 Contamination of brake pads. Oil, brake fluid or dirt causing brake to chatter or squeal. Clean or replace pads (Chapter 7).
- 4 Pads glazed. Caused by excessive heat from prolonged use or from contamination. Do not use sandpaper, emery cloth, carborundum cloth or any other abrasive to roughen the pad surfaces as abrasives will stay in the pad material and damage the disc. A very fine flat file can be used, but pad replacement is suggested as a cure (Chapter 7).
- 5 Disc warped. Can cause a chattering, clicking or intermittent squeal. Usually accompanied by a pulsating lever and uneven braking. Replace the disc (Chapter 7).
- 6 Drum brake linings worn or contaminated. Can cause scraping or squealing. Replace the linings (Chapter 7).
- 7 Drum brake linings warped or worn unevenly. Can cause chattering. Replace the linings (Chapter 7).
- 8 Brake drum out of round. Can cause chattering. Replace brake drum (Chapter 7).
- 9 Loose or worn wheel bearings. Check and replace as needed (Chapter 7).

Oil pressure indicator light comes on

41 Engine lubrication system

- 1 Engine oil pump defective (Chapter 2).
- 2 Engine oil level low. Inspect for leak or other problem causing low oil level and add recommended lubricant (Chapters 1 and 2).
- 3 Engine oil viscosity too low. Very old, thin oil or an improper weight of oil used in engine. Change to correct lubricant (Chapter 1).
- 4 Camshaft or journals worn. Excessive wear causing drop in oil pressure. Replace cam and/or head. Abnormal wear could be caused

Excessive exhaust smoke

43 White smoke

- 1 Piston oil ring worn. The ring may be broken or damaged, causing oil from the crankcase to be pulled past the piston into the combustion chamber. Replace the rings with new ones (Chapter 2).
- 2 Cylinders worn, cracked, or scored. Caused by overheating or oil starvation. The cylinders will have to be rebored and new pistons installed.
- 3 Valve oil seal damaged or worn. Replace oil seals with new ones (Chapter 2).
- 4 Valve guide worn. Perform a complete valve job (Chapter 2).
- 5 Engine oil level too high, which causes oil to be forced past the rings. Drain oil to the proper level (Chapter 1).
- 6 Head gasket broken between oil return and cylinder. Causes oil to be pulled into combustion chamber. Replace the head gasket and check the head for warpage (Chapter 2).
- 7 Abnormal crankcase pressurization, which forces oil past the rings. Clogged breather or hoses usually the cause.

44 Black smoke

- 1 Air filter clogged. Clean or replace the element (Chapter 1).
- 2 Main jet too large or loose. Compare the jet size to the Specifications (Chapter 4).
- 3 Choke stuck, causing fuel to be pulled through choke circuit (Chapter 4).
- 4 Fuel level too high. Check and adjust the float height as necessary (Chapter 4).
- 5 Inlet needle held off needle seat. Clean float bowl and fuel line and replace needle and seat if necessary (Chapter 4).

45 Brown smoke

- 1 Main jet too small or clogged. Lean condition caused by wrong size main jet or by a restricted orifice. Clean float bowl and jets and compare jet size to Specifications (Chapter 4).
- 2 Fuel flow insufficient. Fuel inlet needle valve stuck closed due to chemical reaction with old fuel. Float height incorrect. Restricted fuel line. Clean line and float bowl and adjust floats if necessary (Chapter 4).
- 3 Carburetor intake manifolds loose (Chapter 4).
- 4 Air filter poorly sealed or not installed (Chapter 1).

Poor handling or stability

46 Handlebar hard to turn

- 1 Steering stem locknut too tight (Chapter 6).
- 2 Bearings damaged. Roughness can be felt as the bars are turned

from side-to-side. Replace bearings and races (Chapter 6).

3 Races dented or worn. Denting results from wear in only one position (e.g., straight ahead) from striking an immovable object or hole or from dropping the machine. Replace races and bearings (Chapter 6).

4 Steering stem lubrication inadequate. Causes are grease getting hard from age or being washed out by high pressure car washes. Disassemble steering head and repack bearings (Chapter 6).

5 Steering stem bent. Caused by hitting a curb or hole or from dropping the machine. Replace damaged part. Do not try to straighten stem (Chapter 6).

6 Front tire air pressure too low (Chapter 1).

47 Handlebar shakes or vibrates excessively

1 Tires worn or out of balance (Chapter 7).

2 Swingarm bearings worn. Replace worn bearings by referring to Chapter 6.

3 Rim(s) warped or damaged. Inspect wheels for runout (Chapter 7).

4 Wheel bearings worn. Worn front or rear wheel bearings can cause poor tracking. Worn front bearings will cause wobble (Chapter 7).

5 Handlebar clamp bolts loose (Chapter 6).

6 Steering stem or fork clamps loose. Tighten them to the specified torque (Chapter 6).

7 Engine mount bolts loose. Will cause excessive vibration with increased engine rpm (Chapter 2).

48 Handlebar pulls to one side

1 Frame bent. Definitely suspect this if the machine has been dropped. May or may not be accompanied by cracking near the bend. Replace the frame (Chapter 6).

2 Wheel out of alignment. Caused by improper location of axle spacers or from bent steering stem or frame (Chapter 6).

3 Swingarm bent or twisted. Caused by age (metal fatigue) or impact damage. Replace the arm (Chapter 6).

4 Steering stem bent. Caused by impact damage or from dropping the motorcycle. Replace the steering stem (Chapter 6).

5 Fork leg bent. Disassemble the forks and replace the damaged parts (Chapter 6).

6 Fork oil level uneven.

49 Poor shock absorbing qualities

1 Too hard:

- a) Fork oil level excessive (Chapter 6).
- b) Fork oil viscosity too high. Use a lighter oil (see the Specifications in Chapter 6).
- c) Fork tube bent. Causes a harsh, sticking feeling (Chapter 6).
- d) Shock shaft or body bent or damaged (Chapter 6).
- e) Fork internal damage (Chapter 6).
- f) Shock internal damage.
- g) Tire pressure too high (Chapters 1 and 7).

2 Too soft:

- a) Fork or shock oil insufficient and/or leaking (Chapter 6).
- b) Fork oil level too low (Chapter 6).
- c) Fork oil viscosity too light (Chapter 6).
- d) Fork springs weak or broken (Chapter 6).

Braking problems

50 Front brakes are spongy, don't hold

1 Air in brake line. Caused by inattention to master cylinder fluid level or by leakage. Locate problem and bleed brakes (Chapter 7).

2 Pads or disc worn (Chapters 1 and 7).

3 Brake fluid leak. See paragraph 1.

4 Contaminated pads. Caused by contamination with oil, grease, brake fluid, etc. Clean or replace pads. Clean disc thoroughly with brake cleaner (Chapter 7).

5 Brake fluid deteriorated. Fluid is old or contaminated. Drain system, replenish with new fluid and bleed the system (Chapter 7).

6 Master cylinder internal parts worn or damaged causing fluid to bypass (Chapter 7).

7 Master cylinder bore scratched. From ingestion of foreign material or broken spring. Repair or replace master cylinder (Chapter 7).

8 Disc warped. Replace disc (Chapter 7).

51 Brake lever or pedal pulsates

1 Disc warped. Replace disc (Chapter 7).

2 Axle bent. Replace axle (Chapter 7).

3 Brake caliper bolts loose (Chapter 7).

4 Brake caliper shafts damaged or sticking, causing caliper to bind. Lube the shafts and/or replace them if they are corroded or bent (Chapter 7).

5 Wheel warped or otherwise damaged (Chapter 7).

6 Wheel bearings damaged or worn (Chapter 7).

7 Brake drum out of round. Replace brake drum (Chapter 7).

52 Brakes drag

1 Master cylinder piston seized. Caused by wear or damage to piston or cylinder bore (Chapter 7).

2 Lever balky or stuck. Check pivot and lubricate (Chapter 7).

3 Brake caliper binds. Caused by inadequate lubrication or damage to caliper shafts (Chapter 7).

4 Brake caliper piston seized in bore. Caused by wear or ingestion of dirt past deteriorated seal (Chapter 7).

5 Brake pad damaged. Pad material separating from backing plate. Usually caused by faulty manufacturing process or from contact with chemicals. Replace pads (Chapter 7).

6 Pads improperly installed (Chapter 7).

7 Rear brake pedal free play insufficient (Chapter 1).

8 Rear brake springs weak. Replace the springs (Chapter 7).

Electrical problems

53 Battery dead or weak

1 Battery faulty. Caused by sulfated plates which are shorted through the sedimentation or low electrolyte level. Also, broken battery terminal making only occasional contact (Chapter 9).

2 Battery cables making poor contact (Chapter 9).

3 Load excessive. Caused by addition of high wattage lights or other electrical accessories.

4 Ignition switch defective. Switch either grounds/earths internally or fails to shut off system. Replace the switch (Chapter 9).

5 Regulator/rectifier defective (Chapter 9).

6 Stator coil open or shorted (Chapter 9).

7 Wiring faulty. Wiring grounded/earthed or connections loose in ignition, charging or lighting circuits (Chapter 9).

54 Battery overcharged

1 Regulator/rectifier defective. Overcharging is noticed when battery gets excessively warm or boils over (Chapter 9).

2 Battery defective. Replace battery with a new one (Chapter 9).

3 Battery amperage too low, wrong type or size. Install manufacturer's specified amp-hour battery to handle charging load (Chapter 9).

Chapter 1 Tune-up and routine maintenance

Contents

Air filter element - servicing.....	13	Fasteners - check.....	26
Air suction valves - check.....	23	Fluid levels - check.....	3
Battery electrolyte level/specific gravity - check.....	4	Fork oil - replacement.....	29
Brake pads and linings - wear check.....	5	Fuel system - check and filter cleaning.....	27
Brake pedal position and play - check and adjustment.....	7	Idle speed - check and adjustment.....	18
Brake system - general check.....	6	Introduction to tune-up and routine maintenance.....	2
Carburetor synchronization - check and adjustment.....	19	Lubrication - general.....	16
Clutch - check and adjustment.....	10	Routine maintenance intervals.....	1
Cooling system - check.....	20	Spark plugs - replacement.....	15
Cooling system - draining, flushing and refilling.....	21	Steering head bearings - check and adjustment.....	25
Cylinder compression - check.....	14	Suspension - check.....	28
Drive belt and pulleys - check, adjustment and lubrication.....	11	Throttle and choke operation/grip freeplay - check and adjustment.....	9
Engine oil/filter - change.....	12	Tires/wheels - general check.....	8
Evaporative emission control system (California models only) - check.....	22	Valve clearances - check and adjustment.....	17
Exhaust system - check.....	24		

Specifications

Engine

Spark plugs

Type

US and Canadian models.....

UK models.....

NGK D9EA or ND X27ES-U

NGK DR8ES or ND X27ESR-U

Gap.....

0.6 to 0.7 mm (0.024 to 0.028 inch)

Engine idle speed

Except California models.....

California models.....

1200 +/- 50 rpm

1300 +/- 50 rpm

Valve clearances (COLD engine)

Intake.....

Exhaust.....

0.13 to 0.18 mm (0.005 to 0.007 inch)

0.18 to 0.23 mm (0.007 to 0.009 inch)

Cylinder compression pressure	
EN450 models.....	119 to 185 psi (8.19 to 12.74 Bars)
EN500 models.....	129 to 213 psi (8.88 to 14.67 Bars)
Carburetor synchronization (vacuum difference between cylinders)	Less than 2 cm Hg (0.391 inch)
Cylinder numbering (from left side to right side of bike).....	1-2

Chassis

Brake pad minimum thickness	1.0 mm (0.040 inch)
Brake pedal position.....	50 to 60 mm (1.97 to 2.36 inches)*
Freeplay adjustments	
Throttle grip.....	2 to 3 mm (0.08 to 0.12 inch)
Clutch lever (gap between lever and lever bracket when freeplay is taken up)	2 to 3 mm (0.08 to 0.12 inch)
Brake pedal	20 to 30 mm (0.8 to 1.2 inch)
Choke lever (EN450 only)	2 to 3 mm (0.08 to 0.12 inch)
Drive belt	
Slack (at 4.5 kg/9.9 lbs pressure)	
EN450 models	8.5 to 18.5 mm (0.33 to 0.73 inch)
EN500 models	6.0 to 12.5 mm (0.24 to 0.49 inch)
Battery electrolyte specific gravity	1.280 at 68 degrees F (20 degrees C)
Minimum tire tread depth	
Front	1.0 mm (0.04 inch)
Rear	2.0 mm (0.08 inch)
Tire pressures (cold)	
Front	28 psi (1.9 Bars)
Rear (US and Canada)	
Up to 215 lbs (97.5 kg).....	28 psi (2.2 Bars)
215 to 406 lbs (97.5 to 184 kg)	32 psi (2.5 Bars)
Rear (UK)	28 psi (2.2 Bars)

*Measured from top of footpeg to top of brake pedal

Torque specifications

Oil drain plug	29 Nm (22 ft-lbs)
Oil filter.....	17 Nm (12.5 ft-lbs)
Coolant drain bolt.....	12 Nm (104 in-lbs)
Spark plugs.....	14 Nm (120 in-lbs)
Valve cover bolts	See Chapter 2

Recommended lubricants and fluids

Engine/transmission oil	
Type	API grade SE or SF
Viscosity	
In cold climates.....	SAE 10W40 or 10W50
In warm climates.....	SAE 20W40 or 20W50
Capacity	
With filter change	3.0 liters (3.2 US qt, 5.3 Imp pt)
Oil change only	2.8 liters (3.0 US qt, 4.9 Imp pt)
Coolant	
Type	50/50 mixture of ethylene glycol based antifreeze and soft water
Capacity	1.4 liters (1.5 US qt, 2.46 Imp pt)
Brake fluid.....	DOT 3
Fork oil	
Type	SAE 10W20 - fork oil
Amount (EN450 models)	
Dry fill	355 +/- 2.5 cc (12.0 +/- 0.084 US fl oz, 12.49 +/- 0.09 Imp fl oz)
At oil change	Approximately 300 cc (10.14 US fl oz, 10.56 Imp fl oz)
Amount (EN500 models)	
Dry fill	385 +/- 2.5 cc (13.0 +/- 0.084 US fl oz, 13.55 +/- 0.09 Imp fl oz)
At oil change	Approximately 330 cc (11.15 US fl oz, 11.62 Imp fl oz)
Oil level (fully compressed)	
EN450 models	162 +/- 2 mm (6.38 +/- 0.08 inches)
EN500 models	128 +/- 2 mm (5.04 +/- 0.08 inches)
Miscellaneous	
Wheel bearings.....	Medium weight, lithium-based multi-purpose grease
Swingarm pivot bearings	Medium weight, lithium-based multi-purpose grease
Cables and lever pivots.....	Chain and cable lubricant or 10W30 motor oil
Sidestand/centerstand pivots	Medium-weight, lithium-based multi-purpose grease
Brake pedal/shift lever pivots.....	Chain and cable lubricant or 10W30 motor oil
Throttle grip	Multi-purpose grease or dry film lubricant

1 Kawasaki EN450 & 500

Routine maintenance intervals

Note: The pre-ride inspection outlined in the owner's manual covers checks and maintenance that should be carried out on a daily basis. It's condensed and included here to remind you of its importance. Always perform the pre-ride inspection at every maintenance interval (in addition to the procedures listed). The intervals listed below are the shortest intervals recommended by the manufacturer for each particular operation during the model years covered in this manual. Your owner's manual may have different intervals for your model.

Daily or before riding

- Check the engine oil level
- Check the fuel level and inspect for leaks
- Check the engine coolant level and look for leaks
- Check the operation of both brakes - also check the fluid level and look for leakage (front)
- Check the tires for damage, the presence of foreign objects and correct air pressure
- Check the throttle for smooth operation and correct freeplay
- Check the operation of the clutch - make sure the freeplay is correct
- Make sure the steering operates smoothly, without looseness and without binding
- Check for proper operation of the headlight, taillight, brake light, turn signals, indicator lights, speedometer and horn
- Make sure the sidestand and centerstand return to their fully up positions and stay there under spring pressure
- Make sure the engine STOP switch works properly

After the initial 500 miles (800 km)

Perform all of the daily checks plus:

- Check and adjust the valve clearances
- Clean the air filter element
- Check/adjust the idle speed
- Check/adjust the carburetor synchronization
- Check/adjust the drive belt slack
- Change the engine oil and oil filter
- Check the evaporative emission control system (California models)
- Check the cooling system hoses
- Check the battery electrolyte level
- Check the tightness of all fasteners
- Check the steering
- Check/adjust clutch freeplay
- Check the brake fluid level
- Check/adjust the brake pedal position
- Check the operation of the brake light

Every 3000 miles (5000 km)

- Check the drive belt and pulleys for wear
- Check/adjust the drive belt tension
- Clean and gap the spark plugs
- Check the operation of the air suction valve (if equipped)
- Check/adjust the idle speed
- Check/adjust the carburetor synchronization

Check the evaporative emission control system (California models)

- Adjust the clutch freeplay
- Check the brake fluid level
- Check the brake discs, pads, drum and shoes
- Check/adjust the brake pedal position
- Check the operation of the brake light
- Lubricate all cables
- Lubricate the clutch and brake lever pivots
- Lubricate the shift/brake lever pivots and the sidestand/centerstand pivots
- Check the steering
- Check the tires and wheels
- Check the battery electrolyte level

Every 6000 miles (10,000 km)

All of the items above plus:

- Adjust the valve clearances
- Change the engine oil and oil filter
- Clean the air filter element
- Check the cleanliness of the fuel system and the condition of the fuel and vacuum hoses
- Lubricate the swingarm needle bearings (Chapter 6)
- Replace the spark plugs
- Check the exhaust system for leaks and check the tightness of the fasteners

Every year

- Replace the coolant filter - later UK models (Chapter 3)

Every 12,000 miles (20,000 km) or two years

- Change the brake fluid
- Lubricate the steering head bearings
- Lubricate the drum brake cam (Chapter 7)
- Replace the air filter element. (Also replace after every five cleanings).

Every 18,000 miles (30,000 km) or two years

- Check the cooling system and replace the coolant

Every 18,000 miles (30,000 km)


- Change the fork oil

Every two years


- Overhaul the brake caliper and master cylinder (Chapter 7)
- Check and lubricate the wheel bearings (Chapter 7)
- Lubricate the speedometer gear

Every four years

- Replace the fuel hoses (Chapter 4)
- Replace the brake hose (Chapter 7)




2.3a Decals under the seat include a vacuum hose routing diagram ...



2.3b ... and emissions and tune-up information



2.3c A decal on the drive belt guard lists belt maintenance intervals



3.3 Check the oil level at the inspection window (lower arrow); to add oil, remove the filler cap (upper arrow)

2 Introduction to tune-up and routine maintenance

Refer to illustrations 2.3a, 2.3b and 2.3c

1 This Chapter covers in detail the checks and procedures necessary for the tune-up and routine maintenance of your motorcycle. Section 1 includes the routine maintenance schedule, which is designed to keep the machine in proper running condition and prevent possible problems. The remaining Sections contain detailed procedures for carrying out the items listed on the maintenance schedule, as well as additional maintenance information designed to increase reliability.

2 Since routine maintenance plays such an important role in the safe and efficient operation of your motorcycle, it is presented here as a comprehensive check list. For the rider who does all his/her own maintenance, these lists outline the procedures and checks that should be done on a routine basis.

3 Maintenance information is printed on decals under the seat and on the belt guard (see illustrations). If the information on the decals differs from that included here, use the information on the decal.

4 Deciding where to start or plug into the routine maintenance schedule depends on several factors. If you have a motorcycle whose warranty has recently expired, and if it has been maintained according to the warranty standards, you may want to pick up routine maintenance as it coincides with the next mileage or calendar interval. If you have owned the machine for some time but have never performed any maintenance on it, then you may want to start at the nearest interval and include some additional procedures to ensure that nothing impor-

tant is overlooked. If you have just had a major engine overhaul, then you may want to start the maintenance routine from the beginning. If you have a used machine and have no knowledge of its history or maintenance record, you may desire to combine all the checks into one large service initially and then settle into the maintenance schedule prescribed.

5 The Sections which outline the inspection and maintenance procedures are written as step-by-step comprehensive guides to the performance of the work. They explain in detail each of the routine inspections and maintenance procedures on the check list. References to additional information in applicable Chapters is also included and should not be overlooked.


6 Before beginning any maintenance or repair, the machine should be cleaned thoroughly, especially around the oil filter, spark plugs, cylinder head covers, side covers, carburetors, etc. Cleaning will help ensure that dirt does not contaminate the engine and will allow you to detect wear and damage that could otherwise easily go unnoticed.

3 Fluid levels - check


Engine oil

Refer to illustration 3.3

1 Place the motorcycle on the centerstand, then start the engine and allow it to reach normal operating temperature. **Caution:** Do not run the engine in an enclosed space such as a garage or workshop.



3.7 With the master cylinder in a level position, check the fluid level in the inspection window



3.9 To add brake fluid, remove the master cylinder cover screws (arrows) and lift off the cover and diaphragm



3.15 Check coolant level through the inspection hole in the right side cover; it should be between the Full and Low marks with the engine cold



3.16 The reservoir is located inside the right side cover; to add coolant, remove the filler cap (arrow)

2 Stop the engine and allow the machine to sit undisturbed on the centerstand for about five minutes.

3 With the engine off, check the oil level in the window located at the lower part of the right crankcase cover. The oil level should be between the Maximum and Minimum level marks next to the window (see illustration).

4 If the level is below the Minimum mark, remove the oil filler cap from the right crankcase cover (see illustration 3.3) and add enough oil of the recommended grade and type to bring the level up to the Maximum mark. Do not overfill.

Brake fluid

Refer to illustrations 3.7 and 3.9

5 In order to ensure proper operation of the hydraulic disc brake, the fluid level in the master cylinder reservoir must be properly maintained.

6 Turn the handlebars until the top of the master cylinder is as level as possible. If necessary, tilt the bike slightly to make the master cylinder level.

7 Look closely at the inspection window in the master cylinder reservoir. Make sure that the fluid level is above the Lower mark on the reservoir (see illustration).

8 If the level is low, the fluid must be replenished. Before removing the master cylinder cap, cover the fuel tank to protect it from brake fluid spills (which will damage the paint) and remove all dust and dirt from the area around the cap.

9 Remove the screws (see illustration) and lift off the cap and

rubber diaphragm. **Note:** Do not operate the brake lever with the cap removed.

10 Add new, clean brake fluid of the recommended type until the level is above the inspection window. Do not mix different brands of brake fluid in the reservoir, as they may not be compatible.

11 Replace the rubber diaphragm and the cover. Tighten the screws evenly, but do not overtighten them.

12 Wipe any spilled fluid off the reservoir body and reposition and tighten the brake lever and master cylinder assembly if it was moved.

13 If the brake fluid level was low, inspect the front brake system for leaks.


Coolant

Refer to illustrations 3.15 and 3.16


14 The engine must be cold for the results to be accurate, so always perform this check before starting the engine for the first time each day. The reservoir is located on the right side of the frame near the front of the bike.

15 Check the coolant level through the inspection window in the side cover (see illustration).


16 The coolant level is satisfactory if it is between the Low and Full marks on the reservoir. If the level is at or below the Low mark, remove the reservoir cap and add the recommended coolant mixture (see this Chapter's Specifications) until the Full level is reached (see illustration). If the coolant level seems to be consistently low, check the entire cooling system for leaks.



4.3 Remove the junction box bracket bolt (arrow) and lift the junction box to uncover the battery



4.4 The positive terminal is identified by a plus mark molded into the top of the battery and the negative terminal is identified by a minus mark (arrows); **ALWAYS** disconnect the negative cable first and connect it last to prevent sparks which could cause a battery explosion



4.7 Check the specific gravity with a hydrometer



4.11 The clear plastic vent tube supplied with the battery fits inside the motorcycle's drain tube (arrow) when the battery is installed

4 Battery electrolyte level/specific gravity - check

Refer to illustrations 4.3, 4.4, 4.7 and 4.11

Caution: Be extremely careful when handling or working around the battery. The electrolyte is very caustic and an explosive gas (hydrogen) is given off when the battery is charging. **Note:** The first Steps describe battery removal. If the electrolyte level is known to be sufficient it won't be necessary to remove the battery.

- 1 Remove the seat (see Chapter 8).
- 2 Remove the fuel tank and bracket (see Chapter 4).
- 3 On EN450 models, remove its bolts and lift off the igniter, then release the battery holder bracket. On EN500 models, unbolt the junction box bracket and lift it off together with the junction box and battery cover (see illustration). Note the position of the carburetor vent tube and battery vent tube.
- 4 Remove the bolts securing the battery cables to the battery terminals (remove the negative cable first, positive cable last) (see illustration). Pull the battery straight up to remove it. The electrolyte level will now be visible through the translucent battery case - it should be between the Upper and Lower level marks.
- 5 If it is low, remove the cell caps and fill each cell to the upper level mark with distilled water. Do not use tap water (except in an emergency), and do not overfill. The cell holes are quite small, so it may help


to use a plastic squeeze bottle with a small spout to add the water. If the level is within the marks on the case, additional water is not necessary.

6 Next, check the specific gravity of the electrolyte in each cell with a small hydrometer made especially for motorcycle batteries. These are available from most dealer parts departments or motorcycle accessory stores.

7 Remove the caps, draw some electrolyte from the first cell into the hydrometer (see illustration) and note the specific gravity. Compare the reading to the Specifications listed in this Chapter. **Note:** Add 0.004 points to the reading for every 10-degrees F above 68-degrees F (20-degrees C) - subtract 0.004 points from the reading for every 10-degrees below 68-degrees F (20-degrees C). Return the electrolyte to the appropriate cell and repeat the check for the remaining cells. When the check is complete, rinse the hydrometer thoroughly with clean water.

8 If the specific gravity of the electrolyte in each cell is as specified, the battery is in good condition and is apparently being charged by the machine's charging system.

9 If the specific gravity is low, the battery is not fully charged. This may be due to corroded battery terminals, a dirty battery case, a malfunctioning charging system, or loose or corroded wiring connections. On the other hand, it may be that the battery is worn out, especially if



5.2 Look into the front of the caliper to check the brake pads for wear (arrows)



6.6 To adjust the rear brake light switch, hold the switch body and turn the locknut (arrow)

the machine is old, or that infrequent use of the motorcycle prevents normal charging from taking place.

10 Be sure to correct any problems and charge the battery if necessary. Refer to Chapter 9 for additional battery maintenance and charging procedures.


11 Install the battery cell caps, tightening them securely. Reconnect the cables to the battery, attaching the positive cable first and the negative cable last. Make sure to install the plastic cap over the positive terminal. Install the junction box, fuel tank and bracket and the seat. Be very careful not to pinch or otherwise restrict the battery vent tube (see illustration), as the battery may build up enough internal pressure during normal charging system operation to explode.

5 Brake pads and linings - wear check

Refer to illustrations 5.2 and 5.4

1 The front brake pads and rear brake linings should be checked at the recommended intervals and replaced with new ones when worn beyond the limit listed in this Chapter's Specifications (front) or Chapter 7 (rear).

2 To check the brake pads, remove the caliper (without disconnecting the brake hose) so you can see clearly into the front of the brake caliper (see Chapter 7). The brake pads should have at least the specified minimum amount of lining material remaining on the metal backing



5.4 If the pointer (upper arrow) goes past the Usable Range indicator toward the rear of the bike, the linings are worn and must be replaced; the adjuster (lower arrow) is used to set brake pedal freeplay

plate (see illustration).

3 If the pads are worn excessively, they must be replaced with new ones (see Chapter 7).

4 To check the rear brake linings, press the brake pedal firmly and look at the indicator on the brake drum (see illustration). If the pointer is beyond the Usable Range scale, replace the brake shoes (see Chapter 7).

6 Brake system - general check

Refer to illustration 6.6

1 A routine general check of the brakes will ensure that any problems are discovered and remedied before the rider's safety is jeopardized.

2 Check the brake lever and pedal for loose connections, excessive play, bends, and other damage. Replace any damaged parts with new ones (see Chapter 7).

3 Make sure all brake fasteners are tight. Check the brake pads and linings for wear (see Section 5) and make sure the fluid level in the reservoir is correct (see Section 3). Look for leaks at the hose connections and check for cracks in the hoses. If the lever is spongy, bleed the brakes as described in Chapter 7.

4 Make sure the brake light operates when the brake lever is depressed.

5 Make sure the brake light is activated when the rear brake pedal is depressed approximately 15 mm (0.6 inch).

6 If adjustment is necessary, hold the switch and turn the adjusting nut on the switch body (see illustration) until the brake light is activated when required. Turning the switch out will cause the brake light to come on sooner, while turning it in will cause it to come on later. If the switch doesn't operate the brake lights, check it as described in Chapter 9.


7 The front brake light switch is not adjustable. If it fails to operate properly, replace it with a new one (see Chapter 9).

7 Brake pedal position and play - check and adjustment


Refer to illustration 7.2

1 Rear brake pedal position is largely a matter of personal preference. Locate the pedal so that the rear brake can be engaged quickly and easily without excessive foot movement. The recommended factory setting is listed in this Chapter's Specifications.

2 To adjust the position of the pedal, loosen the locknut on the adjusting bolt, turn the bolt to set the pedal position and tighten the



7.2 To adjust the brake pedal position, loosen the locknut (arrow) and turn the adjusting bolt



9.3 Loosen the accelerator or decelerator cable locknut and turn the adjusting nut to obtain the correct throttle freeplay

- A Accelerator cable (toward front of bike)
- B Decelerator cable (toward rear of bike)
- C Locknuts
- D Adjusting nuts


locknut (see illustration).

- 3 If necessary, adjust the brake light switch (see Section 6).
- 4 With the pedal position adjusted correctly, check freeplay. Apply the rear brake and compare the pedal travel with that listed in this Chapter's Specifications.
- 5 To adjust the freeplay, turn the adjuster at the rear end of the brake rod (see illustration 5.4).


8 Tires/wheels - general check

Refer to illustration 8.4

- 1 Routine tire and wheel checks should be made with the realization that your safety depends to a great extent on their condition.
- 2 Check the tires carefully for cuts, tears, embedded nails or other sharp objects and excessive wear. Operation of the motorcycle with excessively worn tires is extremely hazardous, as traction and handling are directly affected. Measure the tread depth at the center of the tire and replace worn tires with new ones when the tread depth is less than specified. **Note:** In the UK, tread depth must be at least 1 mm over 3/4 of the tread breadth all the way around the tire, with no bald patches.
- 3 Repair or replace punctured tires as soon as damage is noted. Do not try to patch a torn tire, as wheel balance and tire reliability may be impaired.
- 4 Check the tire pressures when the tires are cold and keep them



8.4 Use an accurate gauge to check the air pressure in the tires



9.5 If freeplay can't be set at the throttle grip, use the adjusters at the carburetors

- A Accelerator cable adjuster
- B Decelerator cable adjuster
- C Locknuts

properly inflated (see illustration). Proper air pressure will increase tire life and provide maximum stability and ride comfort. Keep in mind that low tire pressures may cause the tire to slip on the rim or come off, while high tire pressures will cause abnormal tread wear and unsafe handling.


5 The cast wheels used on this machine are virtually maintenance free, but they should be kept clean and checked periodically for cracks and other damage. Never attempt to repair damaged cast wheels; they must be replaced with new ones.

6 Check the valve stem locknuts to make sure they are tight. Also, make sure the valve stem cap is in place and tight. If it is missing, install a new one made of metal or hard plastic.

9 Throttle and choke operation/grip freeplay - check and adjustment

Throttle check


- 1 With the engine stopped, make sure the throttle grip rotates easily from fully closed to fully open with the front wheel turned at various angles. The grip should return automatically from fully open to fully closed when released. If the throttle sticks, check the throttle cables for cracks or kinks in the housings. Also, make sure the inner cables are clean and well-lubricated.
- 2 Check for a small amount of freeplay at the grip and compare the freeplay to the value listed in this Chapter's Specifications.



9.10 On EN450 models, check choke freeplay at the handlebar lever when the choke plunger touches the choke plunger

A Choke plunger lever
B Choke plunger


C Choke lever



9.11 Loosen the locknut and turn the adjusting nut to set choke freeplay on EN450 models

A Adjusting nut

B Locknut



9.12 On EN500 models, make sure the choke plunger lever moves freely and the bushing (arrow) is in good condition

Throttle adjustment

Refer to illustrations 9.3 and 9.5

Note: These motorcycles use two throttle cables - an accelerator cable and a decelerator cable.

3 Freeplay adjustments can be made at the throttle end of the cable. Loosen the locknut on the cable where it leaves the handlebar (see illustration). Turn the adjuster until the desired freeplay is obtained, then retighten the lockwheel.

4 If the cables can't be adjusted at the grip end, adjust them at the lower ends. To do this, first remove the fuel tank (see Chapter 4).

5 Loosen the locknuts on both throttle cables (see illustration), then turn both adjusting nuts in completely. This will create a large amount of freeplay at the throttle grip.

6 Make sure the throttle grip is in the fully closed position.

7 Turn out the adjusting nut of the decelerator cable until the inner cable just becomes tight, then tighten the locknut.

8 Turn the accelerator cable adjusting nut until the desired freeplay is obtained at the throttle grip, then tighten the locknut.


9 Make sure the throttle linkage lever contacts the idle adjusting screw when the throttle grip is in the closed throttle position. **Warning:** Turn the handlebars all the way through their travel with the engine idling. Idle speed should not change. If it does, the cables may be routed incorrectly. Correct this condition before riding the bike.

Choke check

EN450 models

Refer to illustrations 9.10 and 9.11

10 If you're working on an EN450 model, check the freeplay at the



10.2 Check clutch freeplay between the lever and bracket; make the initial adjustment at the lever

A Check freeplay here
B Lockwheel

C Adjuster

choke lever (see illustration). Compare with the value listed in this Chapter's Specifications.

11 If freeplay is incorrect, loosen the locknut on the cable adjuster (see illustration). Turn the adjusting nut to set freeplay, then tighten the locknut.

EN500 models

Refer to illustration 9.12


12 Inspect the choke handle and plunger (see illustration). The choke should pull out easily and stay out by itself. If it doesn't, check the plunger bushing for wear or damage and replace as necessary.

10 Clutch - check and adjustment

Refer to illustrations 10.2 and 10.4

1 Correct clutch freeplay is necessary to ensure proper clutch operation and reasonable clutch service life. Freeplay normally changes because of cable stretch and clutch wear, so it should be checked and adjusted periodically.


2 Clutch cable freeplay is checked at the lever on the handlebar. Slowly pull in on the lever until resistance is felt, then note how far the lever has moved away from its bracket at the pivot end (see illustration). Compare this distance with the value listed in this Chapter's Specifications. Too little freeplay may result in the clutch not engaging completely. If there is too much freeplay, the clutch might not release fully.



10.4 Details of the lower end of the clutch cable

A Adjusting nuts
B Bracket

C Dust cover



11.4 If the nylon-facing material is worn off at any point on the belt, replace it immediately

1 Polyurethane (black)
2 Kevlar cord (yellow)
3 Nylon fabric facing (white)

3 Freeplay adjustments can be made at the clutch lever by loosening the lockwheel and turning the adjuster until the desired freeplay is obtained. Always retighten the lockwheel once the adjustment is complete. If the lever adjuster reaches the end of its travel, try adjusting the cable at its bracket on the engine.

4 Loosen the adjusting nuts at the lower end of the cable completely (see illustration).

5 Loosen the knurled lockwheel at the clutch lever and turn the adjuster in or out to expose approximately 5 or 6 mm of threads between the adjuster and the lockwheel.

6 Pull the clutch cable tight to remove all slack, then tighten the adjusting nuts against the bracket at the lower end of the cable.

7 Turn the adjuster at the clutch lever until the correct freeplay is obtained, then tighten the lockwheel.

8 If the proper amount of freeplay still can't be obtained, the cable must be replaced (see Chapter 2).

11 Drive belt and pulleys - check, adjustment and lubrication


Check

Refer to illustrations 11.3, 11.4 and 11.5


1 A neglected drive belt won't last long and can quickly damage the sprockets. Routine belt adjustment and inspection isn't difficult and will ensure maximum belt and pulley life.

2 To check the belt, place the bike on its centerstand and shift the transmission into Neutral. Make sure the ignition switch is off.

3 Push up on the bottom run of the belt and measure the slack mid-way between the two pulleys (see illustration), then compare your



11.3 Push up on the bottom run of the belt and measure how far it deflects - if it's not within the specified limits, adjust the slack in the belt



11.5 Check the pulleys in the areas indicated to see if they are worn excessively

1 Worn tooth (engine pulley)
2 Worn tooth (rear pulley)
3 Direction of rotation

measurements to the value listed in this Chapter's Specifications. As wear occurs, the belt will actually stretch, which means adjustment by removing some slack from the belt. **Note:** Repeat the belt slack measurement along the length of the belt at several different points.

4 Remove the belt guard (it's held on by two bolts). Check the entire length of the belt for damaged or worn teeth, fraying and cracks (see illustration). Replace the belt if any of these conditions are visible.

Warning: If the belt is worn past the nylon facing material, replace it immediately or it may cause an accident. **Note:** If the belt is in need of replacement, also check the pulleys as described below - they may also be worn.

5 Remove the shift lever and engine pulley cover (see Chapter 6). Check the teeth on the engine pulley and the rear pulley for wear (see illustration). Refer to Chapter 6 for the pulley diameter and tooth height measurement procedure if the pulleys appear to be worn excessively.

Adjustment

Refer to illustrations 11.8 and 11.11


6 Rotate the rear wheel until the belt is positioned with the least amount of slack present.

7 Remove the cotter pin (if equipped) from the torque link nut on the brake panel and loosen the nut.

8 Loosen and back-off the locknuts on the adjuster bolts (see illustration).

9 Remove the cotter pin and loosen the axle nut (see illustration 11.8).


10 Turn the axle adjusting bolts on both sides of the swingarm until the proper belt tension is obtained (get the adjuster on the belt side




11.8 Loosen the torque link nut and the axle nut, then loosen the belt adjuster locknut and back-off the bolt

A Adjuster bolt
B Adjuster locknut


C Axle nut




11.11 When the adjuster bolts are set evenly, the adjuster marks (arrow) on both sides should line up with the same marks in the swingarm, but don't rely completely on this; make a visual check of pulley alignment as well



12.4 Remove the engine oil drain plug (arrow)



12.5a Remove the oil filter with a filter wrench or a special socket; the special socket is best, since it allows the filter to be tightened accurately with a torque wrench



12.5b Let the oil drain completely from the drain plug and filter openings

close, then set the adjuster on the opposite side). Be sure to turn the adjusting bolts evenly to keep the rear wheel in alignment. If the adjusting bolts reach the end of their travel, the belt is excessively worn and should be replaced with a new one (see Chapter 6).

11 When the belt has the correct amount of slack, make sure the marks on the adjusters correspond to the same relative marks on each side of the swingarm (see illustration).

12 Tighten the axle nut snugly, then apply the rear brake firmly to center the shoes. Tighten the axle nut to the torque listed in the Chap-

ter 7 Specifications, then recheck drive belt slack and readjust if necessary. Once drive belt slack is correctly set, install a new cotter pin. If necessary, turn the nut an additional amount to line up the cotter pin hole with the castellations in the nut - don't loosen the nut to do this.

13 Tighten the adjuster locknuts and the torque link nut securely.

12 Engine oil/filter - change

Refer to illustrations 12.4, 12.5a and 12.5b


1 Consistent routine oil and filter changes are the single most important maintenance procedure you can perform on a motorcycle. The oil not only lubricates the internal parts of the engine, transmission and clutch, but it also acts as a coolant, a cleaner, a sealant, and a protectant. Because of these demands, the oil takes a terrific amount of abuse and should be replaced often with new oil of the recommended grade and type. Saving a little money on the difference in cost between a good oil and a cheap oil won't pay off if the engine is damaged.

2 Before changing the oil and filter, warm up the engine so the oil will drain easily. Be careful when draining the oil, as the exhaust pipes, the engine, and the oil itself can cause severe burns.

3 Put the motorcycle on the centerstand over a clean drain pan. Remove the oil filler cap to vent the crankcase and act as a reminder that there is no oil in the engine.

4 Next, remove the drain plug from the engine (see illustration) and allow the oil to drain into the pan. Discard the sealing washer on the drain plug; it should be replaced whenever the plug is removed.

5 As the oil is draining, remove the oil filter (see illustrations). If



13.2a Release the clip and remove the cover . . .

A Clip

B Cover

additional maintenance is planned for this time period, check or service another component while the oil is allowed to drain completely.


- 6 Wipe any remaining oil off the filter sealing area of the crankcase.
- 7 Check the condition of the drain plug threads.
- 8 Coat the gasket on a new filter with clean engine oil. Install the filter and tighten it to the amount listed in this Chapter's Specifications.
- 9 Slip a new sealing washer over the drain plug, then install and tighten the plug. Tighten the drain plug to the torque listed in this Chapter's Specifications. Avoid overtightening, as damage to the engine case will result.

10 Before refilling the engine, check the old oil carefully. If the oil was drained into a clean pan, small pieces of metal or other material can be easily detected. If the oil is very metallic colored, then the engine is experiencing wear from break-in (new engine) or from insufficient lubrication. If there are flakes or chips of metal in the oil, then something is drastically wrong internally and the engine will have to be disassembled for inspection and repair.

11 If there are pieces of fiber-like material in the oil, the clutch is experiencing excessive wear and should be checked.

12 If the inspection of the oil turns up nothing unusual, refill the crankcase to the proper level with the recommended oil and install the filler cap. Start the engine and let it run for two or three minutes. Shut it off, wait a few minutes, then check the oil level. If necessary, add more oil to bring the level up to the Maximum mark. Check around the drain plug and filter housing for leaks.

13 The old oil drained from the engine cannot be reused in its present state and should be disposed of. Check with your local refuse disposal company, disposal facility or environmental agency to see whether they will accept the oil for recycling. Don't pour used oil into drains or onto the ground. After the oil has cooled, it can be drained



13.2b . . . and remove the filter element (A); there's one on each side of the bike

into a suitable container (capped plastic jugs, topped bottles, milk cartons, etc.) for transport to one of these disposal sites.

13 Air filter element - servicing

EN450 models


Refer to illustrations 13.2a and 13.2b

- 1 Remove both side covers (see Chapter 8).
- 2 Unhook the spring, remove the cap and take out the filter element on one side of the bike (**see illustrations**).
- 3 Repeat Step 2 on the other side of the bike.
- 4 Wipe out the housing with a clean rag, then stuff a rag into each opening to keep out foreign material.
- 5 Check the element and its foam gasket for tears or other damage. Replace the element if it's damaged.
- 6 Tap the element on a hard surface to remove the dirt. Finish cleaning by blowing compressed air from the inside of the element to the outside.


EN500 models

Refer to illustrations 13.8a, 13.8b and 13.8c


- 7 Remove the right side cover (see Chapter 8).
- 8 Remove three bolts, lift off the air filter cover and remove the air filter element (**see illustrations**).
- 9 Wipe out the housing with a clean rag, then place a clean rag in the air box opening to keep out dirt.
- 10 Clean the element with solvent. If compressed air is available, use it to clean the element by blowing from the inside out (from the mesh



13.8a Remove three bolts (arrows), take off the cover . . .



13.8b . . . and pull out the filter element



13.8c Filter element details (EN500 models)

side toward the foam side). If the foam is extremely dirty or torn, replace the element with a new one.

11 Soak the element in clean SAE 30 engine oil. Squeeze as much oil as possible out of the element, then squeeze the element inside a clean rag to remove more oil.

All models

12 Reinstall the filter by reversing the removal procedure. Make sure the element is seated properly in the filter housing before installing the cover.

13 Reinstall the side cover(s).

14 Cylinder compression - check

Refer to illustration 14.5

1 Among other things, poor engine performance may be caused by leaking valves, incorrect valve clearances, a leaking head gasket, or worn pistons, rings and/or cylinder walls. A cylinder compression check will help pinpoint these conditions and can also indicate the presence of excessive carbon deposits in the cylinder heads.

2 The only tools required are a compression gauge and a spark plug wrench. Depending on the outcome of the initial test, a squirt-type oil can may also be needed.

3 Run the engine until it reaches normal operating temperature. Place the motorcycle on the centerstand, remove the fuel tank, then remove the spark plugs (see Section 15, if necessary). Work carefully - don't strip the spark plug hole threads and don't burn your hands.


4 Disable the ignition by unplugging the primary wires from the coils (see Chapter 5). Be sure to mark the locations of the wires before detaching them.

5 Install the compression gauge in one of the spark plug holes (see illustration). Hold or block the throttle wide open.

6 Crank the engine over a minimum of four or five revolutions (or until the gauge reading stops increasing) and observe the initial movement of the compression gauge needle as well as the final total gauge reading. Repeat the procedure for the other cylinder and compare the results to the value listed in this Chapter's Specifications.

7 If the compression in both cylinders built up quickly and evenly to the specified amount, you can assume the engine upper end is in reasonably good mechanical condition. Worn or sticking piston rings and worn cylinders will produce very little initial movement of the gauge needle, but compression will tend to build up gradually as the engine spins over. Valve and valve seat leakage, or head gasket leakage, is indicated by low initial compression which does not tend to build up.

8 To further confirm your findings, add a small amount of engine oil to each cylinder by inserting the nozzle of a squirt-type oil can through the spark plug holes. The oil will tend to seal the piston rings if they are



14.5 A compression gauge with a threaded fitting for the spark plug hole is preferred over the type that requires hand pressure to maintain the seal

leaking. Repeat the test for the other cylinder.

9 If the compression increases significantly after the addition of the oil, the piston rings and/or cylinders are definitely worn. If the compression does not increase, the pressure is leaking past the valves or the head gasket. Leakage past the valves may be due to insufficient valve clearances, burned, warped or cracked valves or valve seats, or valves that are hanging up in the guides.

10 If compression readings are considerably higher than specified, the combustion chambers are probably coated with excessive carbon deposits. It is possible (but not very likely) for carbon deposits to raise the compression enough to compensate for the effects of leakage past rings or valves. Remove the cylinder head and carefully decarbonize the combustion chambers (see Chapter 2).


15 Spark plugs - replacement

Refer to illustrations 15.2a, 15.2b, 15.2c, 15.6a, 15.6b and 15.7


1 This motorcycle is equipped with spark plugs that have 12 mm threads and an 18 mm wrench hex. Make sure your spark plug socket is the correct size before attempting to remove the plugs.

2 Disconnect the spark plug caps from the spark plugs (see illustrations). If available, use compressed air to blow any accumulated debris from around the spark plugs. Remove the plugs (see illustration).


3 Inspect the electrodes for wear. Both the center and side elec-



15.2a Rotate the spark plug caps back and forth to loosen them . . .



15.2b ... then pull them off the plugs and check them for brittleness and cracking



15.6a Spark plug manufacturers recommend using a wire type gauge when checking the gap - if the wire doesn't slide between the electrodes with a slight drag, adjustment is required


trodes should have square edges and the side electrode should be of uniform thickness. Look for excessive deposits and evidence of a cracked or chipped insulator around the center electrode. Compare your spark plugs to the color spark plug reading chart. Check the threads, the washer and the ceramic insulator body for cracks and other damage.

4 If the electrodes are not excessively worn, and if the deposits can be easily removed with a wire brush, the plugs can be regapped and reused (if no cracks or chips are visible in the insulator). If in doubt concerning the condition of the plugs, replace them with new ones, as the expense is minimal.


5 Cleaning spark plugs by sandblasting is permitted, provided you clean the plugs with a high flash-point solvent afterwards.

6 Before installing new plugs, make sure they are the correct type and heat range. Check the gap between the electrodes, as they are not preset. For best results, use a wire-type gauge rather than a flat gauge to check the gap (see illustration). If the gap must be adjusted, bend the side electrode only and be very careful not to chip or crack the insulator nose (see illustration). Make sure the washer is in place before installing each plug.


7 Since the cylinder heads are made of aluminum, which is soft and easily damaged, thread the plugs into the heads by hand. Since the plugs are quite recessed, slip a short length of hose over the end of the plug to use as a tool to thread it into place (see illustration). The hose will grip the plug well enough to turn it, but will start to slip if the plug begins to cross-thread in the hole - this will prevent damaged threads and the accompanying repair costs.



15.2c Use an extension and a deep socket (preferably one with rubber insert to prevent damage to the plug) to remove the spark plugs; a magnet can be used to lift the plugs out of the head once they're loose




15.6b To change the gap, bend the side electrode only, as indicated by the arrows, and be very careful not to crack or chip the ceramic insulator surrounding the center electrode




15.7 A length of rubber hose will save time and prevent damaged threads when installing the spark plugs

8 Once the plugs are finger tight, the job can be finished with a socket. If a torque wrench is available, tighten the spark plugs to the torque listed in this Chapter's Specifications. If you do not have a torque wrench, tighten the plugs finger tight (until the washers bottom on the cylinder head) then use a wrench to tighten them an additional 1/4 turn. Regardless of the method used, do not over-tighten them.

9 Reconnect the spark plug caps.



Spark plug maintenance: Checking plug gap with feeler gauges



Altering the plug gap. Note use of correct tool



Spark plug conditions: A brown, tan or grey firing end is indicative of correct engine running conditions and the selection of the appropriate heat rating plug



White deposits have accumulated from excessive amounts of oil in the combustion chamber or through the use of low quality oil. Remove deposits or a hot spot may form



Black sooty deposits indicate an over-rich fuel/air mixture, or a malfunctioning ignition system. If no improvement is obtained, try one grade hotter plug




Wet, oily carbon deposits form an electrical leakage path along the insulator nose, resulting in a misfire. The cause may be a badly worn engine or a malfunctioning ignition system




A blistered white insulator or melted electrode indicates over-advanced ignition timing or a malfunctioning cooling system. If correction does not prove effective, try a colder grade plug




A worn spark plug not only wastes fuel but also overloads the whole ignition system because the increased gap requires higher voltage to initiate the spark. This condition can also affect air pollution




16.3a To disconnect the clutch cable from the lever and bracket, line up the slots in the bracket, lockwheel and adjuster, then pull the cable in the direction of the arrow and slide it through the slots



16.3c Lubricating a control cable with a makeshift funnel and motor oil



16.3b Lubricating a cable with a pressure lube adapter (make sure the tool seats around the inner cable)



17.5 Unscrew the covers from the crankshaft rotation bolt and timing window (arrow) - inspect the cover O-rings and replace them if they're worn or damaged

16 Lubrication - general

Refer to illustrations 16.3a, 16.3b and 16.3c

1 Since the controls, cables and various other components of a motorcycle are exposed to the elements, they should be lubricated periodically to ensure safe and trouble-free operation.

2 The footpegs, clutch and brake lever, brake pedal, shift lever and side and centerstand pivots should be lubricated frequently. In order for the lubricant to be applied where it will do the most good, the component should be disassembled. However, if chain and cable lubricant is being used, it can be applied to the pivot joint gaps and will usually work its way into the areas where friction occurs. If motor oil or light grease is being used, apply it sparingly as it may attract dirt (which could cause the controls to bind or wear at an accelerated rate). **Note:** One of the best lubricants for the control lever pivots is a dry-film lubricant (available from many sources by different names).

3 The clutch cable should be separated from the handlebar lever and bracket before it is lubricated (**see illustration**). This is a convenient time to inspect the Teflon bushing at the end of the cable. The cable should be treated with motor oil or a commercially available cable lubricant which is specially formulated for use on motorcycle control cables. Small adapters for pressure lubricating the cables with spray can lubricants are available and ensure that the cable is lubricated along its entire length (**see illustration**). If motor oil is being

used, tape a funnel-shaped piece of heavy paper or plastic to the end of the cable, then pour oil into the funnel and suspend the end of the cable upright (**see illustration**). Leave it until the oil runs down into the cable and out the other end. When attaching the cable to the lever, be sure to lubricate the barrel-shaped fitting at the end with high-temperature grease. **Note:** While you're lubricating, check the barrel end of the cable for fraying. Replace frayed cables.

4 To lubricate the throttle cables (and choke cable on EN450 models), disconnect the cable(s) at the lower end, then lubricate the cable with a pressure lube adapter (**see illustration 16.3b**). See Chapter 4 for the choke cable removal procedure.

5 The speedometer cable should be removed from its housing and lubricated with motor oil or cable lubricant.

6 Refer to Chapter 6 for the swingarm needle bearing lubrication procedure.

17 Valve clearances - check and adjustment

Refer to illustrations 17.5, 17.6a, 17.6b, 17.6c, 17.8, 17.9, 17.12a and 17.12b

1 The engine must be completely cool for this maintenance procedure, so let the machine sit overnight before beginning.


2 Disconnect the cable from the negative terminal of the battery.

3 Refer to Chapter 4 and remove the fuel tank.


4 Remove the valve cover (**see Chapter 2**).

5 Remove the covers from the crankshaft rotation bolt and timing window (**see illustration**).


6 Position the no. 1 piston (on the left side of the engine) at Top




17.6a Turn the crankshaft clockwise with a socket . . .



17.6b . . . until the T mark on the rotor aligns with the timing notch . . .



17.6c . . . and the no. 1 cam lobes point upward



17.8 For the most accurate measurement, use a pair of feeler gauges - because each rocker arm operates two valves, adjusting one valve affects the setting of the other one

Dead Center (TDC) on the compression stroke. Do this by turning the crankshaft, with a socket placed on the crankshaft bolt, until the T mark on the rotor is aligned with the timing mark on the crankcase (**see illustrations**). Now, check the position of the no. 1 cylinder cam lobes - they should be pointing upward (**see illustration**). Piston no. 1 is now at TDC compression. **Note:** Turn the engine in the normal direction of rotation. If you turn it backwards, the starter clutch will make a whining sound.


7 With the engine in this position, all of the valves for cylinder no. 1 can be checked.

8 Start with the no. 1 intake valve clearance. Insert a feeler gauge of the thickness listed in this Chapter's Specifications between each valve stem and adjuster screw (**see illustration**). It's best to use "go-no go" (stepped) feeler gauges, which give a positive indication of whether the clearance is correct. If you're using a standard feeler gauge, pull it out slowly - you should feel a slight drag. If there's no drag, the clearance is too loose. If there's a heavy drag, the clearance is too tight.


9 If the clearance is incorrect, loosen the adjuster screw locknut (using Kawasaki valve adjusting screw tool no. 57001 - 1217, or equivalent) (**see illustration**) and turn the adjuster screw in or out, as needed.

10 Hold the adjuster screw with the adjusting screw tool (to keep it from turning) and tighten the locknut. Recheck the clearance to make sure it hasn't changed.

11 Now adjust the no. 1 exhaust valves, following the same procedure you used for the intake valves. Make sure to use feeler gauges of the specified thickness.




17.9 A special valve adjusting tool is a good investment, since there's no way to get a box wrench on some of the locknuts without removing the oil lines - the socket (A) loosens and tightens the locknut while the screwdriver (B) turns the adjusting screw



17.12a Turn the crankshaft until the C mark on the rotor aligns with the timing notch . . .

12 Rotate the crankshaft to align the C mark on the rotor with the timing mark on the crankcase, which will position piston no. 2 at TDC compression (**see illustration**). The cam lobes for no. 2 cylinder



17.12b . . . and the no. 2 cam lobes point upward, then adjust the valves for no. 2 cylinder

should now point upward (see illustration).

13 Adjust all four valves on cylinder no. 2, using a pair of feeler gauges and the special tool.

14 Install the valve cover and all of the components that had to be removed to get it off. Install the covers over the crankshaft rotation bolt and timing window.

15 Install the fuel tank and reconnect the cable to the negative terminal of the battery.

18 Idle speed - check and adjustment

Refer to illustration 18.3

1 The idle speed should be checked and adjusted after the carburetors are synchronized and when it is obviously too high or too low. Before adjusting the idle speed, make sure the valve clearances and spark plug gaps are correct. Also, turn the handlebars back-and-forth and see if the idle speed changes as this is done. If it does, the accelerator cable may not be adjusted correctly, or it may be worn out. Be sure to correct this problem before proceeding.

2 The engine should be at normal operating temperature, which is usually reached after 10 to 15 minutes of stop and go riding. Place the motorcycle on the centerstand and make sure the transmission is in Neutral.

3 Turn the adjusting screw, located on the left side of the bike, just forward of the carburetor for cylinder no. 1 (see illustration), until the idle speed listed in this Chapter's Specifications is obtained.

4 Snap the throttle open and shut a few times, then recheck the idle speed. If necessary, repeat the adjustment procedure.


5 If a smooth, steady idle can't be achieved, the fuel/air mixture may be incorrect. Refer to Chapter 4 for additional carburetor information.

19 Carburetor synchronization - check and adjustment


Refer to illustrations 19.9 and 19.13

Warning: Gasoline (petrol) is extremely flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where a natural gas-type appliance (such as a water heater or clothes dryer) is present. If you spill any fuel on your skin, rinse it off immediately with soap and water. When you perform any kind of work on the fuel system, wear safety glasses and have a fire extinguisher suitable for a class B type fire (flammable liquids) on hand.

1 Carburetor synchronization is simply the process of adjusting the carburetors so they pass the same amount of fuel/air mixture to each cylinder. This is done by measuring the vacuum produced in each



18.3 Turn the idle speed adjusting screw (arrow) in or out until the correct idle speed is obtained (carburetors removed from engine for clarity)



19.9 Disconnect the vacuum line from each carburetor (arrow)

cylinder. Carburetors that are out of synchronization will result in decreased fuel mileage, increased engine temperature, less than ideal throttle response and higher vibration levels.

2 To properly synchronize the carburetors, you will need some sort of vacuum gauge setup, preferably with a gauge for each cylinder, or a mercury manometer, which is a calibrated tube arrangement that utilizes columns of mercury to indicate engine vacuum.

3 A manometer can be purchased from a motorcycle dealer or accessory shop and should have the necessary rubber hoses supplied with it for hooking into the vacuum hose fittings on the carburetors.

4 A vacuum gauge setup can also be purchased from a dealer or fabricated from commonly available hardware and automotive vacuum gauges.

5 The manometer is the more reliable and accurate instrument, and for that reason is preferred over the vacuum gauge setup; however, since the mercury used in the manometer is a liquid, and extremely toxic, extra precautions must be taken during use and storage of the instrument.


6 Because of the nature of the synchronization procedure and the need for special instruments, most owners leave the task to a dealer service department or a reputable motorcycle repair shop.

7 Start the engine and let it run until it reaches normal operating temperature, then shut it off.


8 Remove the fuel tank (see Chapter 4).

9 Detach the vacuum hoses from the fittings on the carburetors (see illustration), then hook up the vacuum gauge set or the manometer according to the manufacturer's instructions. Make sure there are no leaks in the setup, as false readings will result.


10 While observing the necessary fire precautions, connect the fuel line to an auxiliary fuel source. Have an assistant hold the fuel source out of the way, but in such a position that fuel can still be delivered and



19.13 Turn this screw to synchronize the carburetors (carburetors removed from engine for clarity)



20.7 The cooling system pressure cap (arrow) is located on the left side of the bike



20.8 An antifreeze hydrometer is helpful in determining the condition of the coolant

access to the carburetors is unobstructed.

- 11 Start the engine and make sure the idle speed is correct.
- 12 The vacuum readings for both of the cylinders should be the same, or at least within the tolerance listed in this Chapter's Specifications. If the vacuum readings vary, adjust as necessary.
- 13 To perform the adjustment, synchronize the carburetors by turning the butterfly valve adjusting screw, as needed, until the vacuum is identical or nearly identical for both cylinders (see illustration).
- 14 When the adjustment is complete, recheck the vacuum readings and idle speed, then stop the engine. Remove the vacuum gauge or manometer and attach the hoses to the fittings on the carburetors. Reinstall the fuel tank and seat.

20 Cooling system - check

Refer to illustrations 20.7 and 20.8

Warning: The engine must be cool before beginning this procedure.

Note: Refer to Section 3 and check the coolant level before performing this check.

- 1 The entire cooling system should be checked carefully at the recommended intervals. Look for evidence of leaks, check the condition of the coolant, check the radiator for clogged fins and damage and make sure the fan operates when required.
- 2 Remove the side covers (Chapter 8).
- 3 Examine each of the rubber coolant hoses along its entire length. Look for cracks, abrasions and other damage. Squeeze each hose at

various points. They should feel firm, yet pliable, and return to their original shape when released. If they are dried out or hard, replace them with new ones.

- 4 Check for evidence of leaks at each cooling system joint. Tighten the hose clamps carefully to prevent future leaks.

5 Check the radiator for evidence of leaks and other damage. Leaks in the radiator leave telltale scale deposits or coolant stains on the outside of the core below the leak. If leaks are noted, remove the radiator (refer to Chapter 3) and have it repaired at a radiator shop or replace it with a new one. **Caution:** Do not use a liquid leak stopping compound to try to repair leaks.

6 Check the radiator fins for mud, dirt and insects, which may impede the flow of air through the radiator. If the fins are dirty, force water or low pressure compressed air through the fins from the backside. If the fins are bent or distorted, straighten them carefully with a screwdriver.

7 Remove the pressure cap by turning it counterclockwise (anticlockwise) until it reaches a stop. If you hear a hissing sound (indicating there is still pressure in the system), wait until it stops. Now, press down on the cap with the palm of your hand and continue turning the cap counterclockwise until it can be removed (see illustration). Check the condition of the coolant in the system. If it is rust colored or if accumulations of scale are visible, drain, flush and refill the system with new coolant. Check the cap gaskets for cracks and other damage. Have the cap tested by a dealer service department or replace it with a new one. Install the cap by turning it clockwise until it reaches the first stop, then push down on the cap and continue turning until it can turn no further.


8 Check the antifreeze content of the coolant with an antifreeze hydrometer (see illustration). Sometimes coolant may look like it's in good condition, but might be too weak to offer adequate protection. If the hydrometer indicates a weak mixture, drain, flush and refill the cooling system (see Section 21).

9 Start the engine and let it reach normal operating temperature, then check for leaks again. As the coolant temperature increases, the fan should come on automatically and the temperature should begin to drop. If it does not, refer to Chapter 3 and check the fan and fan circuit carefully.

10 If the coolant level is consistently low, and no evidence of leaks can be found, have the entire system pressure checked by a Kawasaki dealer service department, motorcycle repair shop or service station.

21 Cooling system - draining, flushing and refilling

Warning: Allow the engine to cool completely before performing this maintenance operation. Also, don't allow antifreeze to come into contact with your skin or painted surfaces of the motorcycle. Rinse off spills immediately with plenty of water. Antifreeze is highly toxic if



21.2 The coolant drain bolt is located in the bottom of the water pump cover

ingested. Never leave antifreeze lying around in an open container or in puddles on the floor; children and pets are attracted by its sweet smell and may drink it. Check with local authorities (councils) about disposing of used antifreeze. Many communities have collection centers which will see that antifreeze is disposed of safely. Antifreeze is also combustible, so don't store or use it near open flames.

Draining

Refer to illustration 21.2


- 1 Loosen the pressure cap (see illustration 20.7). Place a large, clean drain pan under the right side of the engine.
- 2 Remove the drain bolt from the bottom of the water pump cover (see illustration) and allow the coolant to drain into the pan. **Note:** The coolant will rush out with considerable force, so position the drain pan accordingly. Remove the pressure cap completely to ensure that all of the coolant can drain.
- 3 Drain the coolant reservoir. Refer to Chapter 3 for the reservoir removal procedure. Wash the reservoir out with water.

Flushing

- 4 Flush the system with clean tap water by inserting a garden hose in the radiator filler neck. Allow the water to run through the system until it is clear when it exits the drain bolt hole. If the radiator is extremely corroded, remove it by referring to Chapter 3 and have it cleaned at a radiator shop.
- 5 Check the drain bolt gasket. Replace it with a new one if necessary.
- 6 Clean the hole, then install the drain bolt and tighten it to the torque listed in this Chapter's Specifications.
- 7 Fill the cooling system with clean water mixed with a flushing compound. Make sure the flushing compound is compatible with aluminum components, and follow the manufacturer's instructions carefully.
- 8 Start the engine and allow it to reach normal operating temperature. Let it run for about ten minutes.
- 9 Stop the engine. Let the machine cool for a while, then cover the pressure cap with a heavy rag and turn it counterclockwise (anti-clockwise) to the first stop, releasing any pressure that may be present in the system. Once the hissing stops, push down on the cap and remove it completely.
- 10 Drain the system once again.
- 11 Fill the system with clean water, then repeat Steps 8, 9 and 10.

Refilling

- 12 Fill the system with the proper coolant mixture (see this Chapter's Specifications). When the system is full (all the way up to the top of the radiator cap filler neck), install the cap and start the engine. Allow the engine to reach normal operating temperature, then shut it off.
- 13 Let the engine cool off for awhile, cover the radiator cap with a heavy rag and loosen it to the first stop to allow any pressure in the system to bleed off before the cap is removed completely. Recheck the coolant level in the radiator filler neck. If it's low, add more coolant until it reaches the top of the filler neck. Reinstall the cap.



22.2 Evaporative emission control system details

1 Fuel tank	7 Liquid/vapor separator
2 Clamps	8 Canister
3 Hose (red)	9 Hose (blue)
4 Hose (blue)	10 Bracket
5 Retaining band	11 Air filter air box
6 Hose (white)	12 Carburetor assembly

- 14 Allow the engine to cool, then check the coolant level in the reservoir (see Section 3). If the coolant level is low, add the specified mixture until it reaches the FULL mark in the reservoir.
- 15 Check the system for leaks.
- 16 Do not dispose of the old coolant by pouring it down a drain. Instead, pour it into a heavy plastic container, cap it tightly and take it to an authorized disposal site or a service station.

22 Evaporative emission control system (California models only) - check

Refer to illustration 22.2


- 1 This system, installed on California EN500 models to conform to stringent emission control standards, routes fuel vapors from the fuel system into the engine to be burned, instead of letting them evaporate into the atmosphere. When the engine isn't running, vapors are stored in a carbon canister.

Hoses

- 2 To begin the inspection of the system, remove the seat and fuel tank (see Chapters 4 and 8 if necessary). Inspect the hoses from the fuel tank, carburetors and liquid/vapor separator to the canister for cracking, kinks or other signs of deterioration (see illustration).

Liquid/vapor separator test

- 3 Disconnect the breather hose from the separator and inject about 20 cc of gasoline into the fitting with a syringe.
- 4 Disconnect the fuel return hose from the tank and place the end of the hose in a container level with the top of the tank.



22.6a To remove the components, disconnect the hoses (arrows) from the bottom of the separator as well as the hose from the top ...

5 Start the engine and let it idle. If the fuel comes out of the hose, the separator is good; if not, replace it.


Component inspection

Refer to illustrations 22.6a, 22.6b and 22.6c

6 Label and disconnect the hoses, then remove the separator and canister from the machine (**see illustrations**). **Note:** For system inspection, it's easiest to remove the separator, canister and bracket as a unit (**see illustration**).

7 Check the separator closely for cracks or other signs of damage. If these are found, replace it.

8 Inspect the canister for cracks or other signs of damage. Tip the canister so the nozzles point down. If fuel runs out of the canister, the liquid/vapor separator is probably bad - check it as described above. The fuel inside the canister has probably caused damage, so it would be a good idea to replace it also.



22.6b ... and remove the mounting screws (arrows) ...




22.6c ... and take the assembly off of the motorcycle

23 Air suction valves - check


Refer to illustrations 23.3a and 23.3b

1 The air suction valves, installed on US models only, are one-way check valves that allow fresh air to flow into the exhaust ports. The suction developed by the exhaust pulses pulls the air from the air filter, through a hose to the air switching valve, through a pair of hoses and a pair of reed valves, and finally into the exhaust ports. The introduction of fresh air helps ignite any fuel that may not have been burned by the normal combustion process.




23.3a Squeeze the spring clip (arrow), slide it back along the hose and detach the hose from the air suction valve


- 2 Remove the fuel tank (see Chapter 4).
- 3 Disconnect the hoses from the air suction valves (**see illustration**). Remove the bolts and lift off the covers (**see illustration**).
- 4 Check the valves for cracks, warping, burning or other damage. Check the area where the reeds contact the valve holder for scratches, separation and grooves. If any of these conditions are found, replace the valve.
- 5 Wash the valves with solvent if carbon has accumulated between the reed and the valve holder.




23.3b Unbolt the air suction valve from the valve cover to inspect it



25.6 Loosen the lower pinch bolt on each fork (arrow)



25.7 Loosen the steering stem bolt (arrow), but don't remove it or the stem will slip down



25.8 Use a spanner wrench like this one to loosen or tighten the steering stem locknuts (upper triple clamp removed for clarity)

6 Installation of the valves is the reverse of removal. Be sure to use a new gasket.

24 Exhaust system - check

- 1 Periodically check all of the exhaust system joints for leaks and loose fasteners. If tightening the clamp bolts fails to stop any leaks, replace the gaskets with new ones (a procedure which requires disassembly of the system).
- 2 The exhaust pipe flange nuts at the cylinder heads are especially prone to loosening, which could cause damage to the head. Check them frequently and keep them tight.

25 Steering head bearings - check and adjustment

- 1 This motorcycle is equipped with tapered roller steering head bearings which can become dented, rough or loose during normal use of the machine. In extreme cases, worn or loose steering head bearings can cause steering wobble that is potentially dangerous.

Check

- 2 To check the bearings, place the motorcycle on the centerstand and block the machine so the front wheel is raised off the ground.
- 3 Point the wheel straight ahead and slowly move the handlebars from side-to-side. Dents or roughness in the bearing races will be felt and the bars will not move smoothly.
- 4 Next, grasp the fork legs and try to move the wheel forward and backward. Any looseness in the steering head bearings will be felt. If play is felt in the bearings, adjust the steering head as follows:

Adjustment

Refer to illustrations 25.6, 25.7 and 25.8

- 5 Remove the fuel tank (see Chapter 4).
- 6 Loosen the fork lower pinch bolts (**see illustration**). This allows the necessary vertical movement of the steering stem in relation to the fork tubes.
- 7 Loosen (DO NOT remove) the steering stem bolt (**see illustration**).
- 8 Use a spanner wrench (C-spanner) to adjust the steering stem locknuts as a pair (**see illustration**).
- 9 If play is excessive, tighten the steering by turning the upper locknut clockwise until the steering head is tight but does not bind when the forks are turned from side-to-side. If the steering is too tight, turn the lower locknut to loosen it. In each case, keep both locknuts together.
- 10 Retighten the steering stem bolt and the fork pinch bolts, in that order, to the torque values listed in the Chapter 6 Specifications.

- 11 Recheck the steering head bearings for play as described above. If necessary, repeat the adjustment procedure. Reinstall all parts previously removed.

- 12 Refer to Chapter 6 for steering head bearing lubrication and replacement procedures.

26 Fasteners - check


- 1 Since vibration of the machine tends to loosen fasteners, all nuts, bolts, screws, etc. should be periodically checked for proper tightness.
- 2 Pay particular attention to the following:
Spark plugs
Engine oil drain plug
Oil filter cover bolt
Gearshift lever
Footpegs and sidestand
Engine mount bolts
Shock absorber mount bolts
Front axle and clamp bolt
Rear axle nut
- 3 If a torque wrench is available, use it along with the torque specifications at the beginning of this, or other, Chapters.

27 Fuel system - check and filter cleaning


Refer to illustrations 27.8 and 27.9

Warning: Gasoline (petrol) is extremely flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where a natural gas-type appliance (such as a water heater or clothes dryer) is present. If you spill any fuel on your skin, rinse it off immediately with soap and water. When you perform any kind of work on the fuel system, wear safety glasses and have a fire extinguisher suitable for a class B type fire (flammable liquids) on hand.

- 1 Check the fuel tank, the fuel tap, the lines and the carburetors for leaks and evidence of damage.
- 2 If carburetor gaskets are leaking, the carburetors should be disassembled and rebuilt by referring to Chapter 4.
- 3 If the fuel tap is leaking, tightening the screws may help. If leakage persists, the tap should be disassembled and repaired or replaced with a new one.
- 4 If the fuel lines are cracked or otherwise deteriorated, replace them with new ones.
- 5 Check the vacuum hose connected to the fuel tap. If it is cracked or otherwise damaged, replace it with a new one.
- 6 The fuel filter, which is attached to the fuel tap, may become



27.8 The fuel tap is secured to the tank by two screws



27.9 Fuel tap and filter details



28.3 Check above and below the fork seals (arrows) for signs of oil leakage

clogged and should be removed and cleaned periodically. In order to clean the filter, the fuel tank must be drained and the fuel tap removed.

7 Remove the fuel tank (see Chapter 4). Drain the fuel into an approved fuel container.

8 Once the tank is emptied, loosen and remove the screws that attach the fuel tap to the tank (see illustration). Remove the tap and filter.

9 Clean the filter (see illustration) with solvent and blow it dry with compressed air. If the filter is torn or otherwise damaged, replace the entire fuel tap with a new one. Check the mounting flange O-ring and the gaskets on the screws. If they are damaged, replace them with new ones.

10 Install the O-ring, filter and fuel tap on the tank, then install the tank. Refill the tank and check carefully for leaks around the mounting flange and screws.

28 Suspension - check

Refer to illustration 28.3

1 The suspension components must be maintained in top operating condition to ensure rider safety. Loose, worn or damaged suspension parts decrease the vehicle's stability and control.

2 While standing alongside the motorcycle, lock the front brake and push on the handlebars to compress the forks several times. See if they move up-and-down smoothly without binding. If binding is felt, the forks should be disassembled and inspected as described in Chapter 6.

3 Carefully inspect the area around the fork seals for any signs of fork oil leakage (see illustration). If leakage is evident, the seals must be replaced as described in Chapter 6.

4 Check the tightness of all suspension nuts and bolts to be sure none have worked loose.

5 Inspect the rear shock absorbers for fluid leakage and tightness of the mounting nuts. If leakage is found, the shocks should be replaced as a pair.


6 Set the bike on its centerstand. Grab the swingarm on each side, just ahead of the axle. Rock the swingarm from side to side - there should be no discernible movement at the rear. If there's a little movement or a slight clicking can be heard, make sure the pivot shaft nuts are tight. If the pivot nuts are tight but movement is still noticeable, the swingarm will have to be removed and the bearings replaced as described in Chapter 6.

29 Fork oil - replacement


Refer to illustrations 29.2a, 29.2b, 29.2c, 29.3, 29.4, 29.7 and 29.8

1 Place the motorcycle on the centerstand. Position a jack with a block of wood on the jack head under the engine to support the motorcycle when the fork caps are removed. If you're working on a 1985 through 1988 EN450 model, bleed off the air pressure through the air valve at the top of the fork.


2 Pull off the fork cap (see illustration). Push the top plug downward against spring pressure with a Phillips screwdriver or similar tool, remove the retaining ring and release the spring pressure (see illustrations).




29.2a Pull off the fork cap



29.2b Push down on the fork cap plug and remove the retaining ring (EN500 model shown; EN450 similar)



29.2c Once the retaining ring is removed, release the spring pressure




29.3 Remove the fork cap plug and lift out the spacer

- A Retaining ring
- B Fork cap plug and O-ring
- C Spacer




29.7 Use a funnel to pour oil into the fork

- 3 Lift out the cap plug with its O-ring and the spacer (see illustration). Withdraw the spring seat and fork spring.
- 4 Place a drain pan under the fork leg and remove the drain screw (see illustration). **Warning:** Do not allow the fork oil to contact the brake disc, pads or tire. If it does, clean the disc with brake system cleaner, wipe off the tire, and replace the pads with new ones before riding the motorcycle.
- 5 After most of the oil has drained, slowly compress and release the forks to pump out the remaining oil. An assistant will most likely be required to do this procedure.
- 6 Check the drain screw gasket for damage and replace it if necessary. Clean the threads of the drain screw with solvent and let it dry, then install the screw and gasket, tightening it securely.
- 7 Pour the type and amount of fork oil, listed in this Chapter's Specifications, into the fork tube through the opening at the top (see illustration). Remove the jack from under the engine and slowly pump the forks a few times to purge the air from the upper and lower chambers.
- 8 Fully compress the front forks (you may need an assistant to do this). Insert a stiff tape measure or a marked rod into the fork tube and measure the distance from the oil to the top of the fork tube (see



29.4 There's a fork drain screw at the bottom of each fork leg (arrow)



29.8 Measure oil level in the fork with a stiff tape measure or a rod marked at the specified oil level; add or drain oil to correct the level

illustration). Compare your measurement to the value listed in this Chapter's Specifications. Drain or add oil, as necessary, until the level is correct.

9 Check the O-ring on the cap plug, then coat it with a thin layer of multi-purpose grease. Install the fork spring, its seat and the spacer. **Note:** On EN450 models, fit the spring's small-diameter end downwards, and on EN500 models fit the widely spaced coils downwards. Install the cap plug, push it down against the spring pressure, install the retaining ring and release the cap plug.

10 Tighten the fork tube pinch bolts to the torque listed in the Chapter 6 Specifications.

11 Repeat the procedure to the other fork. Note that it is essential that the oil quantity and level is identical in each fork.

12 If you're working on a 1985 through 1988 EN450 model, adjust the air pressure in the front forks (see Chapter 7).

Chapter 2 Engine, clutch and transmission

Contents

Balancer shaft - removal, inspection, bearing selection and installation.....	27	Main and connecting rod bearings - general note.....	24
Camshaft chain tensioner - removal and installation.....	8	Major engine repair - general note.....	4
Camshafts, rocker arm shafts and rocker arms - removal, inspection and installation.....	9	Oil pan - removal and installation.....	16
Clutch - removal, inspection and installation.....	19	Oil pressure relief valve - removal, inspection and installation.....	18
Clutch cable - replacement.....	20	Oil pump - pressure check, removal, inspection and installation.....	17
Clutch hub, crankshaft and main bearings - removal, inspection, main bearing selection and installation.....	25	Operations possible with the engine in the frame.....	2
Connecting rods and bearings - removal, inspection, bearing selection and installation.....	26	Operations requiring engine removal.....	3
Crankcase - disassembly and reassembly.....	22	Piston rings - installation.....	15
Crankcase components - inspection and servicing.....	23	Pistons - removal, inspection and installation.....	14
Cylinder block - removal, inspection and installation.....	13	Primary chain, camshaft chain and guides - removal, inspection and installation.....	28
Cylinder compression check.....	See Chapter 1	Recommended break-in procedure.....	33
Cylinder head - removal and installation.....	10	Shift drum and forks - removal, inspection and installation.....	31
Cylinder head and valves - disassembly, inspection and reassembly.....	12	Spark plug replacement.....	See Chapter 1
Engine - removal and installation.....	5	Starter motor clutch - removal, inspection and installation.....	See Chapter 9
Engine disassembly and reassembly - general information.....	6	Transmission shafts - disassembly, inspection and reassembly.....	30
Engine oil/filter change.....	See Chapter 1	Transmission shafts - removal and installation.....	29
External shift mechanism - removal, inspection and installation.....	21	Valve cover - removal and installation.....	7
General information.....	1	Valves/valve seats/valve guides - servicing.....	11
Initial start-up after overhaul.....	32	Water pump - check, removal and installation.....	See Chapter 3

Specifications

General

Bore	
EN450 models.....	72.0 mm (2.834 inches)
EN500 models.....	74.0 mm (2.913 inches)
Stroke.....	58.0 mm (2.283 inches)
Displacement	
EN450 models.....	454 cc
EN500 models.....	498 cc
Compression ratio	
EN450 models.....	10.7 : 1
EN500 models	
Except California.....	10.8 : 1
California.....	10.7 : 1

Camshaft and rocker arms

Lobe height (intake and exhaust)	
Standard.....	35.635 to 35.761 mm (1.403 to 1.408 inch)
Minimum.....	35.55 mm (1.40 inch)
Bearing oil clearance	
Standard.....	0.030 to 0.071 mm (0.001 to 0.003 inch)
Maximum.....	0.16 mm (0.006 inch)
Journal diameter	
Standard.....	24.950 to 24.970 mm (0.982 to 0.983 inch)
Minimum.....	24.92 mm (0.981 inch)

Camshaft and rocker arms (continued)

Camshaft runout	
Standard.....	0.03 mm (0.001 inch) or less
Maximum.....	0.1 mm (0.003 inch)
Camshaft chain 20-link length (maximum)	128.9 mm (5-5/64 inches)
Rocker arm inside diameter	
Standard.....	12.50 to 12.518 mm (0.492 to 0.493 inch)
Maximum.....	12.55 mm (0.494 inch)
Rocker shaft diameter	
Standard.....	12.466 to 12.484 mm (0.490 to 0.491 inch)
Minimum.....	12.44 mm (0.489 inch)

Cylinder head, valves and valve springs

Cylinder head warpage limit.....	0.05 mm (0.002 inch)
Valve stem bend limit	0.05 mm (0.002 inch)
Valve stem diameter	
Standard	
Intake	5.475 to 5.490 mm (0.2155 to 0.216 inch)
Exhaust	5.455 to 5.470 mm (0.2147 to 0.215 inch)
Minimum	
Intake	5.46 mm (0.2149 inch)
Exhaust	5.44 mm (0.2141 inch)
Valve head thickness	
Standard	
Intake	0.5 mm (0.020 inch)
Exhaust	1.0 mm (0.039 inch)
Minimum	
Intake	0.25 mm (0.010 inch)
Exhaust	0.7 mm (0.027 inch)
Valve guide inside diameter (intake and exhaust)	
Standard.....	5.50 to 5.512 mm (0.2165 to 0.2170 inch)
Maximum.....	5.58 mm (0.2196 inch)
Valve seat width (intake and exhaust)	0.5 to 1.0 mm (0.020 to 0.040 in)
Valve spring free length	
Standard	
Inner	36.3 mm (1.429 inch)
Outer	40.4 mm (1.59 inch)
Minimum	
Inner	35 mm (1.378 inch)
Outer	39 mm (1.535 inch)

Cylinder block

Bore diameter	
Standard	
EN450 models	72.494 to 72.506 mm (2.8540 to 2.8545 inches)
EN500 models	74.0 to 74.012 mm (2.9133 to 2.9138 inches)
Maximum	
EN450 models	72.6 mm (2.858 inches)
EN500 models	74.11 mm (2.9177 inches)
Taper limit.....	0.05 mm (0.002 inch)
Out-of-round limit.....	0.05 mm (0.002 inch)

Pistons

Piston diameter	
Standard.....	73.942 to 73.957 mm (2.9111 to 2.9116 inches)
Minimum.....	73.79 mm (2.905 inches)
Piston-to-cylinder clearance	
Standard.....	0.044 to 0.070 mm (0.0017 to 0.0027 inch)
Maximum.....	0.17 mm (0.0066 inch)
Oversize pistons and rings	+ 0.5 mm (+0.020 inch) (one oversize only)
Ring side clearance	
Standard	
Top.....	0.03 to 0.07 mm (0.0017 to 0.0027 inch)
Second.....	0.02 to 0.06 mm (0.0007 to 0.0023 inch)
Maximum	
Top.....	0.17 mm (0.0066 inch)
Second.....	0.16 mm (0.0062 inch)
Ring groove width	
Standard	
Top.....	0.82 to 0.84 mm (0.032 to 0.033 inch)
Second.....	1.01 to 1.03 mm (0.039 to 0.040 inch)
Oil	2.01 to 2.03 mm (0.079 to 0.080 inch)

Maximum	
Top.....	0.92 mm (0.036 inch)
Second.....	1.12 mm (0.044 inch)
Oil	2.11 mm (0.083 inch)
Ring thickness (top and second)	
Standard.....	0.77 to 0.79 mm (0.030 to 0.031 inch)
Minimum.....	0.7 mm (0.027 inch)
Ring end gap	
Standard	
Top and second.....	0.2 to 0.35 mm (0.008 to 0.013 inch)
Oil	0.2 to 0.7 mm (0.008 to 0.027 inch)
Maximum	
Top and second.....	0.7 mm (0.027 inch)
Oil	1.0 mm (0.039 inch)

Crankshaft and bearings

Main bearing oil clearance	
Standard.....	0.020 to 0.044 mm (0.0008 to 0.0017 inch)
Maximum.....	0.08 mm (0.003 inch)
Main bearing journal diameter	
No mark on crank throw.....	35.984 to 35.992 mm (1.4166 to 1.4170 inch)
"1" mark on crank throw	35.993 to 36.000 mm (1.4170 to 1.4173 inch)
Main bearing bore diameter	
No mark on case.....	39.009 to 39.016 mm (1.5357 to 1.5360 inch)
"0" mark on case.....	39.000 to 39.008 mm (1.5354 to 1.5357 inch)
Crankshaft endplay	
Standard.....	0.05 to 0.25 mm (0.002 to 0.010 inch)
Maximum.....	0.4 mm (0.016 inch)
Crankshaft runout limit	0.05 mm (0.002 inch)
Connecting rod side clearance	
Standard.....	0.13 to 0.33 mm (0.005 to 0.013 inch)
Maximum.....	0.5 mm (0.019 inch)
Connecting rod bearing oil clearance	
Standard.....	0.036 to 0.066 mm (0.0016 to 0.0025 inch)
Maximum.....	0.1 mm (0.004 inch)
Connecting rod big-end bore diameter	
No mark on side of rod	41.00 to 41.008 mm (1.6141 to 1.6144 inch)
"0" mark on side of rod	41.009 to 41.016 mm (1.6145 to 1.6148 inch)
Connecting rod journal (crank pin) diameter	
No mark on crank throw.....	37.984 to 37.994 mm (1.4954 to 1.4958 inch)
"0" mark on crank throw	37.995 to 38.000 mm (1.4958 to 1.4960 inch)
Connecting rod bend and twist, maximum	0.2 mm (0.008 inch) per 100 mm (3.94 inches)
Primary chain 20-link length (maximum)	193.4 mm (7-39/64 inches)

Oil pump and relief valve

Oil pressure (warm).....	2.8 to 3.3 Bars (40 to 48 psi) @ 4000 rpm
Relief valve opening pressure.....	4.3 to 5.9 Bars (63 to 85 psi)
Oil pump clearances	
Outer rotor to body	
Standard	0.15 to 0.23 mm (0.006 to 0.009 inch)
Wear limit	0.3 mm (0.012 inch)
Inner rotor to outer rotor	Less than 0.2 mm (0.008 inch)

Balancer shaft

Balancer shaft bearing oil clearance	
Standard.....	0.02 to 0.05 mm (0.0008 to 0.0019 inch)
Maximum.....	0.09 mm (0.0035 inch)
Balancer shaft journal diameter	
No mark on balancer.....	27.987 to 27.993 mm (1.1018 to 1.1020 inch)
"0" mark on balancer	27.994 to 28.00 mm (1.1021 to 1.1023 inch)
Balancer shaft bearing bore diameter	
No mark on case.....	30.014 to 31.025 mm (1.2210 to 1.2214 inch)
"0" mark on case.....	31.000 to 31.013 mm (1.2204 to 1.2210 inch)

Clutch

Spring free length	
Standard.....	34.2 mm (1.346 inch)
Minimum.....	33.1 mm (1.303 inch)

Clutch (continued)

Friction plate thickness	
Standard.....	2.9 to 3.1 mm (0.114 to 0.122 inch)
Minimum.....	2.75 mm (0.108 inch)
Friction and steel plate warpage	
Standard.....	0.2 mm (0.008 inch)
Limit	0.3 mm (0.012 inch)

Transmission

Primary drive reduction ratio:	
EN450 models.....	2.952 : 1 (62/21T)
EN500 models.....	2.652 : 1 (61/23T)
Gear ratios:	
1st gear	2.571 : 1 (36/14T)
2nd gear	1.777 : 1 (32/18T)
3rd gear	1.380 : 1 (29/21T)
4th gear	1.125 : 1 (27/24T)
5th gear	0.961 : 1 (25/26T)
6th gear	0.851 : 1 (23/27T)
Final drive reduction ratio.....	2.720 : 1 (68/25T)
Gear backlash	
Standard.....	0.02 to 0.19 mm (0.0008 to 0.0074 inch)
Maximum.....	0.23 mm (0.009 inch)
Shift fork groove width	
Standard.....	5.05 to 5.15 mm (0.199 to 0.202 inch)
Maximum.....	5.3 mm (0.208 inch)
Shift fork ear thickness	
Standard.....	4.9 to 5.0 mm (0.193 to 0.197 inch)
Minimum.....	4.8 mm (0.189 inch)
Shift fork guide pin diameter	
Standard.....	7.9 to 8.0 mm (0.311 to 0.315 inch)
Minimum.....	7.8 mm (0.307 inch)
Shift drum groove width	
Standard.....	8.05 to 8.2 mm (0.317 to 0.323 inch)
Maximum.....	8.3 mm (0.326 inch)

Torque specifications

Valve cover bolts	9.8 Nm (87 in-lbs)
Camshaft bearing cap bolts	12 Nm (104 in-lbs)
Camshaft sprocket bolts	15 Nm (11 ft-lbs)*
Rocker arm shafts	51 Nm (38 ft-lbs)
Oil pipe bolts (on cylinder head top surface).....	Not specified
Camshaft chain tensioner cap.....	4.9 Nm (43 in-lbs)
Camshaft chain tensioner mounting bolts.....	8.8 Nm (78 in-lbs)
Cylinder head bolts	
6 mm bolts	9.8 Nm (87 in-lbs)
10 mm bolts	51 Nm (38 ft-lbs)
Crankcase bolts	
6 mm bolts	12 Nm (104 in-lbs)
8 mm bolts	27 Nm (20 ft-lbs)
Connecting rod nuts.....	36 Nm (27 ft-lbs)
Primary chain guide bolts	8.8 Nm (78 in-lbs)*
Clutch cover bolts	Not specified
Clutch spring bolts	9.3 Nm (82 in-lbs)
Clutch hub nut	130 Nm (98 ft-lbs)
Oil pump bolts	Not specified*
Oil pan bolts	12 Nm (104 in-lbs)
Oil pipe-to-cylinder head union bolts	12 Nm (104 in-lbs)
Oil pipe-to-crankcase union bolts	
Left front corner of case.....	20 Nm (14.5 ft-lbs)
Left side of case (upper bolt)	7.8 Nm (69 in-lbs)
Left side of case (lower bolt)	12 Nm (104 in-lbs)
Bottom of case (inside oil pan).....	12 Nm (104 in-lbs)
Right rear corner of engine	7.8 Nm (69 in-lbs)
Cylinder head "Y" line to case	20 Nm (14.5 ft-lbs)
Oil pressure relief valve-to-oil pan.....	15 Nm (11 ft-lbs)*
Oil passage plugs	
Allen head.....	Not specified*
Hex head	17 Nm (12.5 ft-lbs)
Shift drum bearing retainer bolts.....	Not specified*

*Apply non-hardening thread locking agent to the threads.

1 General information

The engine/transmission unit is a water-cooled, in-line, parallel twin. The valves are operated by double overhead camshafts which are chain driven off the crankshaft. The engine/transmission assembly is constructed from aluminum alloy. The crankcase is divided horizontally.

The crankcase incorporates a wet sump, pressure-fed lubrication system which uses a gear-driven, dual-rotor oil pump, an oil filter and bypass valve assembly, a relief valve and an oil pressure switch. Also contained in the crankcase is the balancer shaft and the starter motor clutch.

Power from the crankshaft is routed to the transmission via the clutch, which is of the wet, multi-plate type and is chain-driven off the crankshaft. The transmission is a six-speed, constant-mesh unit.

2 Operations possible with the engine in the frame

The components and assemblies listed below can be removed without having to remove the engine from the frame. If, however, a number of areas require attention at the same time, removal of the engine is recommended.

Gearshift mechanism external components
Water pump
Starter motor
Alternator
Clutch assembly (except housing)
Oil pan and pressure relief valve
Valve cover, camshafts and rocker arms
Cam chain tensioner
Cylinder head
Cylinder block and pistons

3 Operations requiring engine removal

It is necessary to remove the engine/transmission assembly from the frame and separate the crankcase halves to gain access to the following components:

Clutch housing
Crankshaft, connecting rods and bearings
Transmission shafts
Shift drum and forks
Balancer shaft
Starter motor clutch
Camshaft chain
Primary chain
Oil pump

4 Major engine repair - general note

1 It is not always easy to determine when or if an engine should be completely overhauled, as a number of factors must be considered.

2 High mileage is not necessarily an indication that an overhaul is needed, while low mileage, on the other hand, does not preclude the need for an overhaul. Frequency of servicing is probably the single most important consideration. An engine that has regular and frequent oil and filter changes, as well as other required maintenance, will most likely give many miles of reliable service. Conversely, a neglected engine, or one which has not been broken in properly, may require an overhaul very early in its life.

3 Exhaust smoke and excessive oil consumption are both indications that piston rings and/or valve guides are in need of attention. Make sure oil leaks are not responsible before deciding that the rings and guides are bad. Refer to Chapter 1 and perform a cylinder compression check to determine for certain the nature and extent of the work required.

4 If the engine is making obvious knocking or rumbling noises, the connecting rod and/or main bearings are probably at fault.

5 Loss of power, rough running, excessive valve train noise and high fuel consumption rates may also point to the need for an overhaul, especially if they are all present at the same time. If a complete tune-up does not remedy the situation, major mechanical work is the only solution.

6 An engine overhaul generally involves restoring the internal parts to the specifications of a new engine. During an overhaul the piston rings are replaced and the cylinder walls are bored and/or honed. If a rebore is done, then new pistons are also required. The main and connecting rod bearings are generally replaced with new ones and, if necessary, the crankshaft is also replaced. Generally the valves are serviced as well, since they are usually in less than perfect condition at this point. While the engine is being overhauled, other components such as the carburetors and the starter motor can be rebuilt also. The end result should be a like-new engine that will give as many trouble free miles as the original.

7 Before beginning the engine overhaul, read through all of the related procedures to familiarize yourself with the scope and requirements of the job. Overhauling an engine is not all that difficult, but it is time consuming. Plan on the motorcycle being tied up for a minimum of two weeks. Check on the availability of parts and make sure that any necessary special tools, equipment and supplies are obtained in advance.

8 Most work can be done with typical shop hand tools, although a number of precision measuring tools are required for inspecting parts to determine if they must be replaced. Often a dealer service department or motorcycle repair shop will handle the inspection of parts and offer advice concerning reconditioning and replacement. As a general rule, time is the primary cost of an overhaul so it doesn't pay to install worn or substandard parts.

9 As a final note, to ensure maximum life and minimum trouble from a rebuilt engine, everything must be assembled with care in a spotlessly clean environment.


5 Engine - removal and installation

Note: *Engine removal and installation should be done with the aid of an assistant to avoid damage or injury that could occur if the engine is dropped. A hydraulic floor jack should be used to support and lower the engine if possible (they can be rented/hired at low cost).*

Removal

Refer to illustrations 5.16a, 5.16b and 5.16c

- 1 Set the bike on its centerstand (if equipped) and disconnect the battery (negative cable first).
- 2 Remove the seat and the fuel tank (see Chapter 4).
- 3 Remove the side covers (see Chapter 8).
- 4 Drain the coolant and the engine oil (see Chapter 1).
- 5 Remove the air filter housing (see Chapter 4).
- 6 On US models remove the air suction valves and the vacuum switching valve (see Chapter 1).
- 7 Remove the carburetors (see Chapter 4) and plug the intake openings with rags.
- 8 Remove the radiator, radiator hoses and coolant tubes (see Chapter 3).
- 9 Remove the ignition coils and brackets (see Chapter 5).
- 10 Remove the exhaust system (see Chapter 4).
- 11 Remove the shift pedal (see Section 21).
- 12 Remove the engine pulley cover, unbolt the engine pulley and detach the pulley and belt from the engine (see Chapter 6).
- 13 Disconnect the lower end of the clutch cable from the lever and remove the cable bracket (see Chapter 1).
- 14 Mark and disconnect the wires from the oil pressure switch, neutral switch and the starter motor. Unplug the brake light switch, alternator, sidestand and pickup coil electrical connectors (see Chapters 5 and 9).
- 15 Support the engine with a floor jack and a wood block.
- 16 With the engine supported, remove the upper rear mounting



5.16a With the engine securely supported, remove the mounting bolts at the upper rear . . .

bolts, lower rear mounting bolts and front mounting bolts (see illustrations).

17 Make sure no wires or hoses are still attached to the engine assembly.

18 Slowly and carefully lower the engine assembly away from the bike, then guide it out the right side.

Installation


19 Installation is the reverse of removal. Note the following points:

- Don't tighten any of the engine mounting bolts until they all have been installed.
- Use new gaskets at all exhaust pipe connections.
- Tighten the engine mounting bolts and frame downtube bolts securely.
- Adjust the drive belt, rear brake, throttle cables, choke cable (if equipped) and clutch cable following the procedures in Chapter 1.


6 Engine disassembly and reassembly - general information

Refer to illustrations 6.2a, 6.2b and 6.3

1 Before disassembling the engine, clean the exterior with a de-



5.16c . . . and at the front



5.16b . . . at the lower rear . . .

greaser and rinse it with water. A clean engine will make the job easier and prevent the possibility of getting dirt into the internal areas of the engine.


2 In addition to the precision measuring tools mentioned earlier, you will need a torque wrench, a valve spring compressor, oil gallery brushes, a piston ring removal and installation tool, a piston ring compressor, a pin-type spanner wrench and a clutch holder tool (which is described in Section 19). Some new, clean engine oil of the correct grade and type, some engine assembly lube (or moly-based grease), a tube of Kawasaki Bond liquid gasket (part no. 92104-1003) or equivalent, and a tube of RTV (silicone) sealant will also be required. Although it may not be considered a tool, some Plastigage (type HPG-1) should also be obtained to use for checking bearing oil clearances (see illustrations).

3 An engine support stand made from short lengths of 2 x 4's bolted together will facilitate the disassembly and reassembly procedures (see illustration). The perimeter of the mount should be just big enough to accommodate the engine oil pan. If you have an automotive-type engine stand, an adapter plate can be made from a piece of plate, some angle iron and some nuts and bolts.


4 When disassembling the engine, keep "mated" parts together (including gears, cylinders, pistons, etc. that have been in contact with each other during engine operation). These "mated" parts must be reused or replaced as an assembly.



6.2a A selection of brushes is required for cleaning holes and passages in the engine components



6.2b Type HPG-1 Plastigage is needed to check the crankshaft, connecting rod and camshaft oil clearances



6.3 An engine stand can be made from short lengths of 2 x 4 lumber and lag bolts or nails

5 Engine/transmission disassembly should be done in the following general order with reference to the appropriate Sections.


- Remove the cylinder head
- Remove the cylinder block
- Remove the pistons
- Remove the clutch
- Remove the oil pan
- Remove the external shift mechanism
- Remove the alternator rotor/stator coils and starter clutch (see Chapter 9)
- Separate the crankcase halves
- Remove the crankshaft and connecting rods
- Remove the balancer shaft and gears
- Remove the transmission shafts/gears
- Remove the shift drum/forks

6 Reassembly is accomplished by reversing the general disassembly sequence.


7 Valve cover - removal and installation

Refer to illustrations 7.7, 7.8, 7.9, 7.11a and 7.11b


Note: The valve cover can be removed with the engine in the frame. If the engine has been removed, ignore the steps which don't apply.



7.7 Remove the valve cover bolts (arrow)



7.8 Lift the cover off the engine - if it's stuck, tap gently on the side with a soft faced hammer; don't pry the cover loose




7.9 Be careful not to lose the locating dowels (arrows) or let them fall into the engine

Removal


- 1 Set the bike on its centerstand (if equipped).
- 2 Drain the engine coolant and remove the reservoir tank (see Chapters 1 and 3).
- 3 Remove the fuel tank (see Chapter 4).
- 4 Remove the side covers (see Chapter 8). Disconnect the coolant tubes (see Chapter 3).
- 5 On US models, remove the air suction valves and the vacuum switching valve (see Chapter 1).
- 6 If necessary for removal access, remove the ignition coils and their brackets, along with the spark plug wires (see Chapter 5).
- 7 Remove the valve cover bolts (**see illustration**).
- 8 Lift the cover off the cylinder head (**see illustration**). If it's stuck, don't attempt to pry it off - tap around the sides with a plastic hammer to dislodge it. **Note:** Pay attention to the locating dowels as you remove the cover - if they fall into the engine, major disassembly may be required to get them out.

Installation

- 9 Remove the locating dowels from the valve cover (**see illustration**). Peel the rubber gasket from the cover. If it's cracked, hardened, has soft spots or shows signs of general deterioration, replace it with a new one.



7.11a Be sure the gasket seats securely in the groove (arrow)



7.11b Apply a small amount of silicone sealant to the corners of the half-circle portions of the gasket (arrows)

thin film of RTV sealant to the half-circle cutouts on each side of the head.

11 Install the gasket to the cover. Make sure it fits completely into the cover groove (see illustration). Apply a small amount of silicone sealer to the corners of the half-circle portions of the gasket (see illustration).

12 Position the cover on the cylinder head, making sure the gasket doesn't slip out of place.

13 Check the rubber seals on the valve cover bolts, replacing them if necessary. Install the bolts, tightening them evenly to the torque listed in this Chapter's Specifications.

14 The remainder of installation is the reverse of removal. Fill the cooling system with the recommended type and amount of coolant (see Chapter 1).


8 Camshaft chain tensioner - removal and installation

Refer to illustrations 8.1 and 8.9

Removal

Caution: Once you start to remove the tensioner bolts, you must remove the tensioner all the way and reset it before tightening the bolts. The tensioner extends and locks in place, so if you loosen the bolts part way and then retighten them, the tensioner or cam chain will be damaged.

- 1 Loosen the tensioner cap bolt while the tensioner is still installed (see illustration).
- 2 Remove the tensioner mounting bolts and take it off the engine.
- 3 Remove the tensioner cap bolt and O-ring.



8.1 Loosen the tensioner cap bolt (A) while the tensioner is still on the engine, then remove the mounting bolts (B)

Installation

4 Check the O-ring on the tensioner body for cracks or hardening. It's a good idea to replace this O-ring whenever the tensioner cap is removed.

Original tensioner

5 Place the tensioner mounting bolts where you can reach them with one hand while the other hand holds the tensioner in position in Step 7.


6 Press the end of the rod that contacts the chain into the tensioner body. At the same time, turn the other end of the rod clockwise with a screwdriver until the rod protrudes about 3/8-inch (10 mm) from the tensioner body. **Caution:** Don't turn the rod counterclockwise (anticlockwise) or it may separate from the tensioner. If this happens it can't be reassembled.

7 Place the tensioner in position on the engine. Push it firmly against the engine, remove the screwdriver, and install the mounting bolts finger-tight. **Caution:** If the tensioner moves away from the engine before you tighten the bolts, the rod will extend too far. If this happens (or you think it might have happened), remove the tensioner and repeat Step 6, then continue with Step 7.


8 Tighten the mounting bolts to the torque listed in this Chapter's Specifications.

New tensioner


9 New tensioners come with a keeper that fits in the tensioner rod



8.9 New tensioners come with a keeper (arrow) to hold the rod in position for installation; add the keeper to your tool collection for the next time you need to remove and install the tensioner



9.3a Position the EX mark on the exhaust camshaft even with the cylinder head surface and the sprocket punch mark up (arrows). . .



9.3b . . .the IN mark on the intake camshaft should also be even with the head surface and the sprocket punch mark should be up (arrows) . . .

slot and holds the rod in the correct position for installation (see illustration).

10 Place the tensioner on the engine. Install the mounting bolts and tighten them to the torque listed in this Chapter's Specifications.

11 Pull the keeper out with needle nosed pliers. **Note:** Save the keeper and place it in your toolbox for future use. You can use it to hold the tensioner rod in position next time you install the tensioner, leaving both hands free.

Original or new tensioner

12 Install the tensioner cap and O-ring. Tighten the cap to the torque listed in this Chapter's Specifications.

9 Camshafts, rocker arm shafts and rocker arms - removal, inspection and installation


Note: This procedure can be performed with the engine in the frame.

Camshafts

Removal

Refer to illustrations 9.3a, 9.3b, 9.3c, 9.4, 9.5, 9.6, 9.7a, 9.7b and 9.8


- 1 Remove the valve cover (see Section 7).
- 2 Remove the camshaft chain tensioner (see Section 8).
- 3 Turn the engine to position no. 2 cylinder at TDC compression (see Chapter 1 - Valve clearances - check and adjustment). When the engine is positioned correctly, the EX mark on the exhaust camshaft




9.3c . . .once the camshafts are positioned correctly, mark across the chain and sprocket with felt pen to ease reassembly

and the IN mark on the intake camshaft will align with the cylinder head top surface (see illustrations). To ease reassembly, mark the sprockets and chain with felt pen (see illustration).


- 4 Remove the upper chain guide (see illustration).
- 5 Remove the bolts and lift the oil pipes and O-rings from the cylinder head (see illustration).
- 6 Unscrew the bearing cap bolts for one of the camshafts, a little at a time, until they are all loose, then unscrew the bearing cap bolts for the other camshaft. **Caution:** If the bearing cap bolts aren't loosened evenly, the camshaft may bind. Remove the bolts and lift off the




9.4 The center four camshaft bearing cap bolts also secure the chain guide; its arrow points toward the front of the engine




9.5 Remove the oil pipe bolts (arrows) and lift the oil lines and O-rings out of the engine



9.6 The camshaft bearing caps have letter marks to indicate position; the caps must be reinstalled in the correct locations to prevent camshaft seizure



9.7a Lift the camshafts out of the head and disengage them from the chain



9.7b The camshafts are identified by punch marks

bearing caps. Note the letters on the bearing caps which correspond to those on the cylinder head (see illustration). When you reinstall the caps, be sure to install them in the correct positions.


7 Pull up on the camshaft chain and carefully guide the camshaft out (see illustration). With the chain still held taut, remove the other camshaft. Look for marks on the camshafts (see illustration). The intake camshaft should have an IN mark and the exhaust camshaft should have an EX mark. If you can't find these marks, label the camshafts to ensure they are installed in their original locations. **Note:** Don't remove the sprockets from the camshafts unless absolutely necessary.

8 While the camshafts are out, don't allow the chain to go slack - there's a protrusion inside the crankcase that's designed to keep the chain from falling off the sprocket on the crankshaft (see illustration), but if it's worn, the chain may fall off and bind between the crankshaft and case, which could damage these components. Wire the chain to another component to prevent it from dropping down. Also, cover the top of the cylinder head with a rag to prevent foreign objects from falling into the engine.

Inspection

Refer to illustrations 9.10a, 9.10b, 9.12, 9.13a, 9.13b, 9.15a, 9.15b and 9.18

Note: Before replacing camshafts or the cylinder head and bearing caps because of damage, check with local machine shops specializing in motorcycle engine work. In the case of the camshafts, it may be possible for cam lobes to be welded, reground and hardened, at a cost far lower than that of a new camshaft. If the bearing surfaces in the cylinder head are damaged, it may be possible for them to be bored



9.8 This protrusion in the bottom of the engine case is designed to prevent the cam chain from falling out of mesh with the crankshaft sprocket, but to be safe, tie the chain up so it can't drop down


out to accept bearing inserts. Due to the cost of a new cylinder head it is recommended that all options be explored before condemning it as trash!

9 Inspect the cam bearing surfaces of the head and the bearing caps. Look for score marks, deep scratches and evidence of spalling (a pitted appearance).


10 Check the camshaft lobes for heat discoloration (blue appearance), score marks, chipped areas, flat spots and spalling (see illustration). Measure the height of each lobe with a micrometer (see illustration) and compare the results to the minimum lobe height listed in this Chapter's Specifications. If damage is noted or wear is excessive, the camshaft must be replaced. Also, be sure to check the condition of the rocker arms, as described later in this Section.

11 Next, check the camshaft bearing oil clearances. Clean the camshafts, the bearing surfaces in the cylinder head and the bearing caps with a clean, lint-free cloth, then lay the cams in place in the cylinder head, with the IN and EX marks on the gears facing away from each other and level with the valve cover gasket surface of the cylinder head (see illustrations 9.3a and 9.3b). Engage the cam chain with the cam gears, so the camshafts don't turn as the bearing caps are tightened.


12 Cut eight strips of Plastigage (type HPG-1) and lay one piece on each bearing journal, parallel with the camshaft centerline (see illustration).




9.10a Check the lobes of the camshaft for wear - here's a good example of damage which will require replacement (or repair) of the camshaft




9.10b Measure the height of the camshaft lobes with a micrometer



9.12 Position a strip of Plastigage on each cam bearing journal, parallel with the centerline of the crankshaft




9.13a Make sure the bearing cap dowels are in position



9.13b Camshaft bearing cap tightening sequence (the center four bolts also secure the chain guide) - tighten the no. 1 and no. 2 bolts evenly to specifications first, then tighten the others in numerical order

13 Make sure the bearing cap dowels are installed (see illustration). Install the bearing caps in their proper positions (the arrows on the caps must face toward the front of the engine and the letters on the caps must correspond with those on the cylinder head) and install the




9.15a Compare the width of the crushed Plastigage to the scale on the Plastigage envelope to obtain the clearance


bolts. Tighten the bolts in three steps, following the recommended sequence (see illustration), to the torque listed in this Chapter's Specifications. While doing this, DO NOT let the camshafts rotate!

14 Now unscrew the bolts, a little at a time, and carefully lift off the bearing caps.

15 To determine the oil clearance, compare the crushed Plastigage (at its widest point) on each journal to the scale printed on the Plastigage container (see illustration). Compare the results to this Chap-



9.15b Measure the cam bearing journal with a micrometer



9.18 Each sprocket has two sets of bolt holes; those labeled EX are used for the exhaust camshaft, while those labeled IN are used for the intake camshaft

ter's Specifications. If the oil clearance is greater than specified, measure the diameter of the cam bearing journal with a micrometer (see illustration). If the journal diameter is less than the specified limit, replace the camshaft with a new one and recheck the clearance. If the clearance is still too great, replace the cylinder head and bearing caps with new parts (see the Note that precedes Step 9). Remove all traces of Plastigage from the components without scratching their surfaces.

16 Except in cases of oil starvation, the camshaft chain wears very little. If the chain has stretched excessively, which makes it difficult to maintain proper tension, replace it with a new one (see Section 28).

17 Check the sprockets for wear, cracks and other damage, replacing them if necessary. If the sprockets are worn, the chain is also worn, and also the sprocket on the crankshaft (which can only be remedied by replacing the crankshaft). If wear this severe is apparent, the entire engine should be disassembled for inspection.

18 If you remove the sprockets, be sure to install them correctly; they're identical, with each sprocket having bolt holes for the intake and exhaust camshafts. The intake camshaft sprocket uses the bolt holes labeled IN; the exhaust camshaft sprocket uses the bolt holes

labeled EX (see illustration).

19 Check the chain guide for wear or damage. If it is worn or damaged, the chain is worn out or improperly adjusted. Replacement of the guide requires removal of the cylinder head and cylinder block.


Installation

Refer to illustration 9.22

20 Make sure the bearing surfaces in the cylinder head and the bearing caps are clean, then apply a light coat of engine assembly lube or moly-based grease to each of them.


21 Apply a coat of moly-based grease to the camshaft lobes. Make sure the camshaft bearing journals are clean, then lay the camshafts in the cylinder head (do not mix them up), ensuring the marks on the cam sprockets are aligned properly (see illustrations 9.3a, 9.3b and 9.3c).

22 Make sure the timing marks are aligned as described in Step 11, then mesh the chain with the camshaft sprockets. Count the number of chain link pins between the punch marks (see illustration). There should be no slack in the chain between the two sprockets.




#2 Piston TDC

9.22 With no slack in the camshaft chain, there should be 24 link pins present between the punch marks on the cam sprockets



9.30a Insert an Allen wrench into the rocker shaft head (a bit like this one is necessary for tightening the plug to specifications). . .



9.30b . . . unscrew the shaft and pull it out

23 Carefully set the bearing caps in place (arrows pointing toward the front of the engine and in their proper positions) (see illustration 9.6) and install the bolts. Tighten them in the recommended sequence (see illustration 9.13b), to the torque listed in this Chapter's Specifications.


24 Insert your finger or a wood dowel into the cam chain tensioner hole and apply pressure to the cam chain. Check the timing marks to make sure they are aligned (see Step 3) and there are still the correct number of link pins between the punch marks on the cam sprockets. If necessary, change the position of the sprocket(s) on the chain to bring all of the marks into alignment. **Caution:** If the marks are not aligned exactly as described, the valve timing will be incorrect and the valves may contact the pistons, causing extensive damage to the engine.

25 Install the tensioner as described in Section 8.

26 Adjust the valve clearances (see Chapter 1).

27 Turn the engine with a socket on the crankshaft rotation bolt. If you feel a sudden increase in resistance, stop turning. The valves may be hitting the pistons due to incorrect assembly. Find the problem and fix it before turning the engine any further, or serious damage may occur.

28 The remainder of installation is the reverse of removal.



9.31 Remove the rocker arms and springs

31 Remove the rocker arms and springs (see illustration).

32 Repeat the above Steps to remove the other rocker arm shafts and rocker arms. Keep all of the parts in order so they can be reinstalled in their original locations.

2

Rocker arm shafts and rocker arms

Removal

Refer to illustrations 9.30a, 9.30b and 9.31

29 Remove the camshafts following the procedure given above. Be sure to keep tension on the camshaft chain.

30 Unscrew one rocker shaft from the cylinder head and pull it out (see illustrations).




9.33 Inspect the rocker arms, especially the faces that contact the cam lobes, for wear

Inspection


Refer to illustrations 9.33, 9.34a, 9.34b and 9.34c

33 Clean all of the components with solvent and dry them off. Blow through the oil passages in the rocker arms with compressed air, if available. Inspect the rocker arm faces for pits, spalling, score marks and rough spots (see illustration). Check the rocker arm-to-shaft contact areas and the adjusting screws, as well. Look for cracks in each rocker arm. If the faces of the rocker arms are damaged, the rocker arms and the camshafts should be replaced as a set.

34 Measure the diameter of the rocker arm shafts, in the area where the rocker arms ride, and compare the results with this Chapter's



9.34a Check the rocker shaft for wear, make sure the oil holes (lower arrows) are clear and inspect the O-ring under the head (upper arrow); it's a good idea to replace the O-ring whenever the shaft is removed



9.34b Measure the inside diameter of the rocker arm - in this case a telescoping gauge is expanded against the bore of the rocker arm, then locked. . .

Specifications. Also measure the inside diameter of the rocker arms (see illustrations) and compare the results with this Chapter's Specifications. If either the shaft or the rocker arms are worn beyond the specified limits, replace them as a set.

35 Replace the O-ring under the head of the rocker arm shaft.

Installation

Refer to illustration 9.36

36 Position a rocker arm and spring in the cylinder head, with the spring toward the center of the cylinder head (see illustration).


37 Lubricate the rocker arm shaft with engine oil and slide it into the cylinder head and through the rocker arm and spring. Tighten it to the torque listed in this Chapter's Specifications.

38 Repeat Steps 36 and 37 to install the remaining rocker arms and shafts.


39 Install the camshafts following the procedure described earlier in this Section.

10 Cylinder head - removal and installation

Caution: The engine must be completely cool before beginning this procedure, or the cylinder head may become warped.



9.36 The rocker arm springs (arrow) go between the rocker arm and the center of the head




9.34c . . . and a micrometer is used to measure the gauge

Note: This procedure can be performed with the engine in the frame. If the engine has been removed, ignore the steps which don't apply.


Removal

Refer to illustrations 10.6, 10.7a, 10.7b, 10.8a, 10.8b, 10.9 and 10.10


- 1 Set the bike on its centerstand (if equipped).
- 2 Remove the valve cover (see Section 7).
- 3 Remove the exhaust system (see Chapter 4).
- 4 Remove the cam chain tensioner (see Section 8).
- 5 Remove the camshafts (see Section 9).
- 6 Remove the oil pipe banjo bolts and washers from the rear of the cylinder head (see illustration).
- 7 Remove the small cylinder block-to-cylinder head bolts and the main oil pipe mounting bolt (see illustrations).
- 8 Loosen the cylinder head bolts, a little at a time, using the reverse order of the tightening sequence (see illustrations).
- 9 Pull the cylinder head off the cylinder block (see illustration). If the head is stuck, tap upward against the rocker shaft heads with a rubber mallet to jar it loose, or use two wooden dowels inserted into the intake or exhaust ports to lever the head off. Don't attempt to pry the head off by inserting a screwdriver between the head and the cylinder block - you'll damage the sealing surfaces.
- 10 Lift the head gasket off the cylinder block (see illustration).
- 11 Stuff a clean rag into the cam chain tunnel to prevent the entry of debris.




10.6 Remove the oil pipe banjo bolts




10.7a Remove one small head-to-block bolt (upper arrow), the oil pipe mounting bolt (lower arrow). . .




10.7b . . .and one small head-to-block bolt located inside the head




10.8a Use a deep socket to remove the head bolts




10.8b Head bolt TIGHTENING sequence - the arrow points to the front of the engine



10.9 Lift the head off the cylinder block



10.10 Remove the old gasket



10.15 The UP mark on the head gasket goes toward the right side of the engine

12 Locate the two dowel pins to make sure they haven't fallen into the engine. If they are in the head, put them in their holes in the cylinder block.

13 Check the cylinder head gasket and the mating surfaces on the cylinder head and block for signs of leakage, which could indicate warpage. Refer to Section 12 and check the flatness of the cylinder head.

14 Clean all traces of old gasket material from the cylinder head and block. Be careful not to let any of the gasket material fall into the crankcase, the cylinder bores or the water passages.

Installation

Refer to illustrations 10.15 and 10.20

15 Lay the new gasket in place on the cylinder block. Make sure the UP mark on the gasket is positioned on the right-hand side of the engine (**see illustration**). Never reuse the old gasket and don't use any type of gasket sealant.

16 Carefully lower the cylinder head over the studs. It is helpful to have an assistant support the camshaft chain with a piece of wire so it doesn't fall and become kinked or detached from the crankshaft. When the head is resting against the cylinder block, wire the cam chain to another component to keep tension on it.

17 Install the head bolts. Using the proper sequence (**see illustration 10.8b**), tighten the bolts to approximately half of the torque listed in this Chapter's Specifications.

18 Using the same sequence, tighten the bolts to the full torque listed in this Chapter's Specifications.

19 Install the small cylinder block-to-cylinder head bolts, tightening them to the torque listed in this Chapter's Specifications.

20 Install the oil line mounting and banjo bolts. Use new washers on the banjo bolts (**see illustration**).

21 Install the camshafts and the valve cover (see Sections 9 and 7) and refit all disturbed components.


22 Change the engine oil (see Chapter 1).

11 Valves/valve seats/valve guides - servicing

1 Because of the complex nature of this job and the special tools and equipment required, servicing of the valves, the valve seats and the valve guides (commonly known as a valve job) is best left to a professional.

2 The home mechanic can, however, remove and disassemble the head, do the initial cleaning and inspection, then reassemble and deliver the head to a dealer service department or properly equipped motorcycle repair shop for the actual valve servicing. Refer to Section 12 for those procedures.

3 The dealer service department will remove the valves and



10.20 There's a washer on each side of the oil line banjo bolt fittings - replace them whenever the banjo bolts are removed

springs, recondition or replace the valves and valve seats, replace the valve guides, check and replace the valve springs, spring retainers and keepers (as necessary), replace the valve seals with new ones and reassemble the valve components.

4 After the valve job has been performed, the head will be in like-new condition. When the head is returned, be sure to clean it again very thoroughly before installation on the engine to remove any metal particles or abrasive grit that may still be present from the valve service operations. Use compressed air, if available, to blow out all the holes and passages.

12 Cylinder head and valves - disassembly, inspection and reassembly

1 As mentioned in the previous Section, valve servicing and valve guide replacement should be left to a dealer service department or motorcycle repair shop. However, disassembly, cleaning and inspection of the valves and related components can be done (if the necessary special tools are available) by the home mechanic. This way no expense is incurred if the inspection reveals that service work is not required at this time.

2 To properly disassemble the valve components without the risk of damaging them, a valve spring compressor is absolutely necessary. This special tool can usually be rented/hired, but if it's not available, have a dealer service department or motorcycle repair shop handle the entire process of disassembly, inspection, service or repair (if required) and reassembly of the valves.

Disassembly


Refer to illustrations 12.7a, 12.7b, 12.7c and 12.7d

3 Remove the rocker arm shafts and rocker arms (see Section 9). Store the components in such a way that they can be returned to their original locations without getting mixed up (labeled plastic bags work well).


4 Before the valves are removed, scrape away any traces of gasket material from the head gasket sealing surface. Work slowly and do not nick or gouge the soft aluminum of the head. Gasket removing solvents, which work very well, are available at most motorcycle shops and auto parts stores.

5 Carefully scrape all carbon deposits out of the combustion chamber area. A hand held wire brush or a piece of fine emery cloth can be used once the majority of deposits have been scraped away. Do not use a wire brush mounted in a drill motor, or one with extremely stiff bristles, as the head material is soft and may be eroded away or scratched by the wire brush.

6 Before proceeding, arrange to label and store the valves along with their related components so they can be kept separate and reinstalled in the same valve guides they are removed from (again, plastic bags work well for this).



12.7a Compressing the valve springs with a valve spring compressor



12.7b Remove the valve keepers/collets with needle-nose pliers or tweezers

7 Compress the valve spring on the first valve with a spring compressor, then remove the keepers/collets (**see illustrations**) and the retainer from the valve assembly. Do not compress the springs any more than is absolutely necessary. Carefully release the valve spring compressor and remove the springs and the valve from the head (**see illustration**). If the valve binds in the guide (won't pull through), push it back into the head and deburr the area around the keeper/collet groove with a very fine file or whetstone (**see illustration**).

8 Repeat the procedure for the remaining valves. Remember to keep the parts for each valve together so they can be reinstalled in the same location.

9 Once the valves have been removed and labeled, pull off the valve stem seals with pliers and discard them (the old seals should never be reused), then remove the spring seats.

10 Next, clean the cylinder head with solvent and dry it thoroughly. Compressed air will speed the drying process and ensure that all holes and recessed areas are clean.

11 Clean all of the valve springs, keepers/collets, retainers and spring seats with solvent and dry them thoroughly. Do the parts from one valve at a time so that no mixing of parts between valves occurs.

12 Scrape off any deposits that may have formed on the valve, then use a motorized wire brush to remove deposits from the valve heads and stems. Again, make sure the valves do not get mixed up.



Inspection

Refer to illustrations 12.14, 12.15, 12.16a, 12.16b, 12.17, 12.18a, 12.18b, 12.19a and 12.19b


13 Inspect the head very carefully for cracks and other damage. If cracks are found, a new head will be required. Check the cam bearing surfaces for wear and evidence of seizure. Check the camshafts and rocker arms for wear as well (**see Section 9**).

14 Using a precision straightedge and a feeler gauge, check the head gasket mating surface for warpage. Lay the straightedge lengthwise, across the head and diagonally (corner-to-corner), intersecting the head bolt holes, and try to slip a 0.002 in (0.05 mm) feeler gauge under it, on either side of each combustion chamber (**see illustration**).


12.7c Valve components - exploded view




12.7d If the valve binds in the guide, deburr the area above the keeper/collet groove




12.14 Lay a precision straightedge across the cylinder head and try to slide a feeler gauge of the specified thickness (equal to the maximum allowable warpage) under it




12.15 Measuring the valve seat width



12.16a Insert a small hole gauge into the valve guide and expand it so there's a slight drag when it's pulled out



12.16b Measure the small hole gauge with a micrometer




12.17 Check the valve face (A), stem (B) and keeper groove (C) for signs of wear and damage

If the feeler gauge can be inserted between the head and the straightedge, the head is warped and must either be machined or, if warpage is excessive, replaced with a new one.


15 Examine the valve seats in each of the combustion chambers. If they are pitted, cracked or burned, the head will require valve service that is beyond the scope of the home mechanic. Measure the valve seat width (see illustration) and compare it to this Chapter's Specifications. If it is not within the specified range, or if it varies around its circumference, valve service work is required.

16 Clean the valve guides to remove any carbon buildup, then measure the inside diameters of the guides (at both ends and the center of the guide) with a small hole gauge and a 0-to-1-inch micrometer (see illustrations). If the guides exceed the maximum value given in the Chapter's Specifications, they must be replaced. The guides are measured at the ends and at the center to determine if they are worn in a bell-mouth pattern (more wear at the ends). If they are, guide replacement is an absolute must.

17 Carefully inspect each valve face for cracks, pits and burned spots. Check the valve stem and the keeper/collet groove area for cracks (see illustration). Rotate the valve and check for any obvious indication that it is bent. Check the end of the stem for pitting and excessive wear. The presence of any of the above conditions indicates



12.18a Measure the valve stem diameter with a micrometer



12.19a Measure the free length of the valve springs

the need for valve servicing.

18 Measure the valve stem diameter and replace if it exceeds the minimum value listed in this Chapter's Specifications (**see illustration**). Also check the valve stem for bending. Set the valve in a V-block with a dial indicator touching the middle of the stem (**see illustration**). Rotate the valve and note the reading on the gauge. If the stem runout exceeds the value listed in this Chapter's Specifications, replace the valve.

19 Check the end of each valve spring for wear and pitting. Measure the free length (**see illustration**) and compare it to this Chapter's Specifications. Any springs that are shorter than specified have sagged and should not be reused. Stand the spring on a flat surface and check it for squareness (**see illustration**).


20 Check the spring retainers and keepers/collets for obvious wear and cracks. Any questionable parts should not be reused, as extensive damage will occur in the event of failure during engine operation.

21 If the inspection indicates that no service work is required, the valve components can be reinstalled in the head.

Reassembly

Refer to illustrations 12.23, 12.24a, 12.24b, 12.24c and 12.27

22 Before installing the valves in the head, they should be lapped to ensure a positive seal between the valves and seats. This procedure requires fine valve lapping compound (available at auto parts stores) and a valve lapping tool. If a lapping tool is not available, a piece of rubber or plastic hose can be slipped over the valve stem (after the valve has been installed in the guide) and used to turn the valve.




12.18b Check the valve stem for bends with a V-block (or blocks, as shown here) and a dial indicator




12.19b Check the valve springs for squareness

23 Apply a small amount of fine lapping compound to the valve face (**see illustration**), then slip the valve into the guide. **Note:** Make sure the valve is installed in the correct guide and be careful not to get any lapping compound on the valve stem.


24 Attach the lapping tool (or hose) to the valve and rotate the tool between the palms of your hands. Use a back-and-forth motion rather




12.23 Apply the lapping compound very sparingly, in small dabs, to the valve face only




12.24a A hose, pushed over the end of the valve, can be used to turn the valve back and forth



12.24b After lapping, the valve face should exhibit a uniform, unbroken contact pattern (arrow) . .



12.24c . . . and the seat should be the specified width (arrow) with a smooth, unbroken appearance



12.27 A small dab of grease will help hold the collets in place on the valve spring while the valve is released

than a circular motion (see illustration). Lift the valve off the seat and turn it at regular intervals to distribute the lapping compound properly. Continue the lapping procedure until the valve face and seat contact area is of uniform width and unbroken around the entire circumference of the valve face and seat (see illustrations).


25 Carefully remove the valve from the guide and wipe off all traces of lapping compound. Use solvent to clean the valve and wipe the seat area thoroughly with a solvent soaked cloth. Repeat the procedure for the remaining valves.

26 Lay the spring seats in place in the cylinder head, then install new valve stem seals on each of the guides. Use an appropriate size deep socket to push the seals into place until they are properly seated. Don't twist or cock them, or they will not seal properly against the valve stems. Also, don't remove them again or they will be damaged.

27 Coat the valve stems with assembly lube or moly-based grease, then install one of them into its guide. Next, install the spring seats, springs and retainers, compress the springs and install the keepers/collets. **Note:** Install the springs with the tightly wound coils at the bottom (next to the spring seat). When compressing the springs with the valve spring compressor, depress them only as far as is absolutely necessary to slip the keepers/collets into place. Apply a small amount of grease to the keepers/collets (see illustration) to help hold them in place as the pressure is released from the springs. Make certain that the keepers/collets are securely locked in their retaining grooves.

28 Support the cylinder head on blocks so the valves can't contact the workbench top, then very gently tap each of the valve stems with a soft-faced hammer. This will help seat the keepers/collets in their grooves.

29 Once all of the valves have been installed in the head, check for proper valve sealing by pouring a small amount of solvent into each of the valve ports. If the solvent leaks past the valve(s) into the combustion chamber area, disassemble the valve(s) and repeat the lapping procedure, then reinstall the valve(s) and repeat the check. Repeat the procedure until a satisfactory seal is obtained.



13.3 If you haven't already done so for cylinder head removal, remove the oil pipe mounting bolt

13 Cylinder block - removal, inspection and installation

Removal

Refer to illustrations 13.3, 13.4, 13.5 and 13.6


- Following the procedure given in Section 10, remove the cylinder head. Make sure the crankshaft is positioned at Top Dead Center (TDC) for cylinder no. 2.
- Remove the water pump together with the water pipe (see Chapter 3).
- Remove the oil pipe mounting bolt (see illustration).
- Lift out the camshaft chain rear guide (see illustration).
- Lift the cylinder block straight up to remove it (see illustration). If it's stuck, tap around its perimeter with a soft-faced hammer. Don't attempt to pry between the block and the crankcase, as you will ruin the sealing surfaces. As you lift, note the location of the dowel pins. Be careful not to let these drop into the engine.
- Stuff clean shop towels around the pistons (see illustration) and remove the gasket and all traces of old gasket material from the surfaces of the cylinder block and the cylinder head.

Inspection


Refer to illustration 13.8

Caution: Don't attempt to separate the liners from the cylinder block.


- Check the cylinder walls carefully for scratches and score marks.
- Using the appropriate precision measuring tools, check each cylinder's diameter near the top, center and bottom of the cylinder




13.4 Lift the rear cam chain guide out of the engine (cylinder block removed for clarity)



13.5 Lift the cylinder block up and off the crankcase and pistons; don't lose the dowels (arrows)



13.6 Place rags under the pistons to protect them and keep debris out of the crankcase



13.8 Measure the cylinder bore with a telescoping gauge (then measure the gauge with a micrometer)

bore, parallel to the crankshaft axis (see illustration). Next, measure each cylinder's diameter at the same three locations across the crankshaft axis. Compare the results to this Chapter's Specifications. If the cylinder walls are tapered, out-of-round, worn beyond the specified limits, or badly scuffed or scored, have them rebored and honed by a dealer service department or a motorcycle repair shop. If a rebore is done, oversize pistons and rings will be required as well. **Note:** Kawasaki supplies pistons in one oversize only - $+0.020$ in ($+0.5$ mm).

9 As an alternative, if the precision measuring tools are not available, a dealer service department or motorcycle repair shop will make the measurements and offer advice concerning servicing of the cylinders.

10 If they are in reasonably good condition and not worn to the outside of the limits, and if the piston-to-cylinder clearances can be maintained properly (see Section 14), then the cylinders do not have to be rebored; honing is all that is necessary.

11 To perform the honing operation you will need the proper size flexible hone with fine stones, or a "bottle brush" type hone, plenty of light oil or honing oil, some shop towels and an electric drill motor. Hold the cylinder block in a vise (cushioned with soft jaws or wood blocks) when performing the honing operation. Mount the hone in the drill motor, compress the stones and slip the hone into the cylinder. Lubricate the cylinder thoroughly, turn on the drill and move the hone up and down in the cylinder at a pace which will produce a fine


crosshatch pattern on the cylinder wall with the crosshatch lines intersecting at approximately a 60-degree angle. Be sure to use plenty of lubricant and do not take off any more material than is absolutely necessary to produce the desired effect. Do not withdraw the hone from the cylinder while it is running. Instead, shut off the drill and continue moving the hone up and down in the cylinder until it comes to a complete stop, then compress the stones and withdraw the hone. Wipe the oil out of the cylinder and repeat the procedure on the remaining cylinder. Remember, do not remove too much material from the cylinder wall. If you do not have the tools, or do not desire to perform the honing operation, a dealer service department or motorcycle repair shop will generally do it for a reasonable fee.

12 Next, the cylinders must be thoroughly washed with warm soapy water to remove all traces of the abrasive grit produced during the honing operation. Be sure to run a brush through the bolt holes and flush them with running water. After rinsing, dry the cylinders thoroughly and apply a coat of light, rust-preventative oil to all machined surfaces.

Installation

Refer to illustration 13.14

13 Lubricate the cylinder bores with plenty of clean engine oil. Apply a thin film of moly-based grease to the piston skirts.



13.14 Install the base gasket with the ridge upward

14 Install the dowel pins, then place a new cylinder base gasket on the crankcase with the ridge in the gasket upward (see illustration). Some gaskets also have an arrow, which must point to the front of the engine.

15 Slowly rotate the crankshaft until all of the pistons are at the same level. Slide lengths of welding rod or pieces of a straightened-out coat hanger under the pistons, on both sides of the connecting rods. This will help keep the pistons level as the cylinder block is lowered onto them.

16 Attach two piston ring compressors to the pistons and compress the piston rings. Large hose clamps can be used instead - just make sure they don't scratch the pistons, and don't tighten them too much.

17 Install the cylinder block over the pistons and carefully lower it down until the piston crowns fit into the cylinder liners. While doing this, pull the camshaft chain up, using a hooked tool or a piece of coat hanger. Push down on the cylinder block, making sure the pistons don't get cocked sideways, until the bottoms of the cylinder liners slide down past the piston rings. A wood or plastic hammer handle can be used to gently tap the block down, but don't use too much force or the pistons will be damaged.

18 Remove the piston ring compressors or hose clamps, being careful not to scratch the pistons. Remove the rods from under the pistons.

19 Install the cam chain rear guide (see illustration 13.4).

20 The remainder of installation is the reverse of removal.

14 Pistons - removal, inspection and installation

1 The pistons are attached to the connecting rods with piston pins that are a slip fit in the pistons and rods.

2 Before removing the pistons from the rods, stuff a clean shop towel into each crankcase hole, around the connecting rods (see illustration 13.6). This will prevent the circlips from falling into the crankcase if they are inadvertently dropped.

Removal

Refer to illustration 14.3

3 Using a sharp scribe, scratch the number of each piston into its crown. Each piston should also have an arrow pointing toward the front of the engine (see illustration). If not, scribe an arrow into the piston crown before removal. Support the first piston, grasp the circlip with needle-nose pliers and remove it from the groove. If the pin won't come out, fabricate a piston pin removal tool from threaded stock (stud), nuts, washers and a piece of pipe.

4 Push the piston pin out from the opposite end to free the piston from the rod. You may have to deburr the area around the groove to enable the pin to slide out (use a triangular file for this procedure). Repeat the procedure for the other piston.

Inspection

Refer to illustrations 14.6, 14.11, 14.13, 14.14a, 14.14b and 14.15

5 Before the inspection process can be carried out, the pistons must be cleaned and the old piston rings removed.

6 Using a piston ring installation tool, carefully remove the rings from the pistons (see illustration). Do not nick or gouge the pistons in the process.

7 Scrape all traces of carbon from the tops of the pistons. A hand-held wire brush or a piece of fine emery cloth can be used once most of the deposits have been scraped away. Do not, under any circumstances, use a wire brush mounted in a drill motor to remove deposits from the pistons; the piston material is soft and will be eroded away by the wire brush.


8 Use a piston ring groove cleaning tool to remove any carbon deposits from the ring grooves. If a tool is not available, a piece broken off the old ring will do the job. Be very careful to remove only the carbon deposits. Do not remove any metal and do not nick or gouge the sides of the ring grooves.

9 Once the deposits have been removed, clean the pistons with solvent and dry them thoroughly. Make sure the oil return holes below the oil ring grooves are clear.


10 If the pistons are not damaged or worn excessively and if the cylinders are not rebored, new pistons will not be necessary. Normal piston wear appears as even, vertical wear on the thrust surfaces of




14.3 Using a sharp scribe, scratch the cylinder numbers into the piston crowns - also note the arrow, which must point to the front



14.6 Remove the piston rings with a ring removal and installation tool



14.11 Check the piston pin bore and the piston skirt for wear, and make sure the internal holes are clear (arrows)



14.13 Measure the piston ring-to-groove clearance with a feeler gauge



14.14a Measure the piston diameter with a micrometer

the piston and slight looseness of the top ring in its groove. New piston rings, on the other hand, should always be used when an engine is rebuilt.

11 Carefully inspect each piston for cracks around the skirt, at the pin bosses and at the ring lands (see illustration).

12 Look for scoring and scuffing on the thrust faces of the skirt, holes in the piston crown and burned areas at the edge of the crown. If the skirt is scored or scuffed, the engine may have been suffering from overheating and/or abnormal combustion, which caused excessively high operating temperatures. The oil pump and cooling system should be checked thoroughly. A hole in the piston crown, an extreme to be sure, is an indication that abnormal combustion (pre-ignition) was occurring. Burned areas at the edge of the piston crown are usually evidence of spark knock (detonation). If any of the above problems exist, the causes must be corrected or the damage will occur again.


13 Measure the piston ring-to-groove clearance by laying a new piston ring in the ring groove and slipping a feeler gauge in beside it (see illustration). Check the clearance at three or four locations around the groove. Be sure to use the correct ring for each groove; they are different. If the clearance is greater than specified, new pistons will have to be used when the engine is reassembled.

14 Check the piston-to-bore clearance by measuring the bore (see Section 13) and the piston diameter. Make sure that the pistons and cylinders are correctly matched. Measure the piston across the skirt on the thrust faces at a 90-degree angle to the piston pin, about 1/2-inch (13 mm) up from the bottom of the skirt (see illustration). Sub-


tract the piston diameter from the bore diameter to obtain the clearance. If it is greater than specified, the cylinders will have to be re-bored and new oversized pistons and rings installed. If the appropriate precision measuring tools are not available, the piston-to-cylinder clearances can be obtained, though not quite as accurately, using feeler gauge stock. Feeler gauge stock comes in 12-inch lengths and various thicknesses and is generally available at auto parts stores. To check the clearance, select a 0.002 in (0.07 mm) feeler gauge and slip it into the cylinder along with the appropriate piston (see illustration). The cylinder should be upside down and the piston must be positioned exactly as it normally would be. Place the feeler gauge between the piston and cylinder on one of the thrust faces (90-degrees to the piston pin bore). The piston should slip through the cylinder (with the feeler gauge in place) with moderate pressure. If it falls through, or slides through easily, the clearance is excessive and a new piston will be required. If the piston binds at the lower end of the cylinder and is loose toward the top, the cylinder is tapered, and if tight spots are encountered as the feeler gauge is placed at different points around the cylinder, the cylinder is out-of-round. Repeat the procedure for the remaining piston and cylinder. Be sure to have the cylinders and pistons checked by a dealer service department or a motorcycle repair shop to confirm your findings before purchasing new parts.

15 Apply clean engine oil to the pin, insert it into the piston and check for freeplay by rocking the pin back-and-forth (see illustration). If the pin is loose, new pistons and pins must be installed.


16 Refer to Section 15 and install the rings on the pistons.




14.14b If you don't have a micrometer, piston clearance, out-of-round and cylinder taper can be measured with a piece of feeler gauge stock




14.15 Slip the pin into the piston and try to wiggle it back-and-forth; if it's loose, replace the piston and pin




15.3a Square the ring in the bore by turning the piston upside down and tapping on the ring. . .



15.3b . . . then check the piston ring end gap with a feeler gauge



15.5 If the end gap is too small, clamp a file in a vise and file the ring ends (from the outside in only) to enlarge the gap slightly



15.9a Installing the oil ring expander - make sure the ends don't overlap

Installation

17 Install the pistons in their original locations with the arrows pointing to the front of the engine. Lubricate the pins and the rod bores with clean engine oil. Install new circlips in the grooves in the inner sides of the pistons (don't reuse the old circlips). Push the pins into position from the opposite side and install new circlips. Compress the circlips only enough for them to fit in the piston. Make sure the clips are properly seated in the grooves.

15 Piston rings - installation

Refer to illustrations 15.3a, 15.3b, 15.5, 15.9a, 15.9b, 15.11, 15.12 and 15.15

- 1 Before installing the new piston rings, the ring end gaps must be checked.
- 2 Lay out the pistons and the new ring sets so the rings will be matched with the same piston and cylinder during the end gap measurement procedure and engine assembly.
- 3 Insert the top (No. 1) ring into the bottom of the first cylinder and square it up with the cylinder walls by pushing it in with the top of the piston (**see illustration**). The ring should be about one inch above the bottom edge of the cylinder. To measure the end gap, slip a feeler gauge between the ends of the ring (**see illustration**) and compare the measurement to the Specifications.
- 4 If the gap is larger or smaller than specified, double check to make sure that you have the correct rings before proceeding.
- 5 If the gap is too small, it must be enlarged or the ring ends may come in contact with each other during engine operation, which can




15.9b Installing an oil ring side rail - don't use a ring installation tool to do this

cause serious damage. The end gap can be increased by filing the ring ends very carefully with a fine file (**see illustration**). When performing this operation, file only from the outside in.


6 Excess end gap is not critical unless it is greater than 0.040 in (1 mm). Again, double check to make sure you have the correct rings for your engine.

7 Repeat the procedure for each ring that will be installed in the first cylinder and for each ring in the remaining cylinder. Remember to keep the rings, pistons and cylinders matched up.


Cross Section of Piston Rings



15.11 Don't confuse the top ring with the second (middle) compression ring




15.12 Make sure the marks on the rings (arrow) face up when the rings are installed on the pistons



15.15 Piston and piston ring details - when installing the oil ring side rails, stagger them approximately 30 to 40-degrees on either side of the top compression ring

- | | |
|---------------------------|---------------------|
| 1 Top compression ring | 4 Oil ring expander |
| 2 Second compression ring | 5 Arrow mark |
| 3 Oil ring side rails | 6 Circlip |
| | 7 Piston pin |



16.5a Remove the oil pan bolts (arrows)

from the top ring by its cross-section shape (see illustration). Do not mix the top and middle rings.

12 To avoid breaking the ring, use a piston ring installation tool and make sure that the identification mark is facing up (see illustration). Fit the ring into the middle groove on the piston. Do not expand the ring any more than is necessary to slide it into place.

13 Finally, install the no. 1 (top) ring in the same manner. Make sure the identifying mark is facing up.

14 Repeat the procedure for the remaining piston and rings. Be very careful not to confuse the no. 1 and no. 2 rings.

15 Once the rings have been properly installed, stagger the end gaps, including those of the oil ring side rails (see illustration).

16 Oil pan - removal and installation

Refer to illustrations 16.5a and 16.5b

Note: The oil pan can be removed with the engine in the frame.

Removal


- 1 Set the bike on its centerstand (if equipped).
- 2 Drain the engine oil and remove the oil filter (see Chapter 1).
- 3 Remove the exhaust system (see Chapter 4).
- 4 Remove the small screw and disconnect the wire from the oil pressure switch (see Chapter 9).
- 5 Remove the oil pan bolts and detach the pan from the crankcase (see illustrations).

8 Once the ring end gaps have been checked/corrected, the rings can be installed on the pistons.

9 The oil control ring (lowest on the piston) is installed first. It is composed of three separate components. Slip the expander into the groove, then install the upper side rail (see illustrations). Do not use a piston ring installation tool on the oil ring side rails as they may be damaged. Instead, place one end of the side rail into the groove between the spacer expander and the ring land. Hold it firmly in place and slide a finger around the piston while pushing the rail into the groove. Next, install the lower side rail in the same manner.

10 After the three oil ring components have been installed, check to make sure that both the upper and lower side rails can be turned smoothly in the ring groove.

11 Install the no. 2 (middle) ring next. It can be readily distinguished




16.5b Place the bolts in a holder, such as a piece of cardboard with holes punched in it - the bolt that goes next to the oil pressure switch also secures a wiring harness retainer

- 6 Remove all traces of old gasket material from the mating surfaces of the oil pan and crankcase.


Installation

Refer to illustration 16.7


- 7 Check the small O-rings in the oil passages in the crankcase and the large O-ring around the oil filter hole (in the pan) for cracking and general deterioration (see illustration). Replace them if necessary.



17.2 To check the oil pressure, remove the plug (arrow) and connect an oil pressure gauge using the proper adapter



17.9 Remove the snap-ring and the pump drive gear




16.7 Make sure the O-rings are in position (arrows); the three O-rings to the left have a flat side, which goes upward (against the crankcase and away from the oil pan)


The flat side of the O-rings must face the crankcase.

- 8 Position a new gasket on the oil pan. A thin film of RTV sealant can be used to hold the gasket in place. Install the oil pan and bolts, tightening the bolts to the torque listed in this Chapter's Specifications, using a criss-cross pattern.


- 9 The remainder of installation is the reverse of removal. Install a new filter and fill the crankcase with oil (see Chapter 1), then run the engine and check for leaks.




17.8 Unbolt the pickup from the pump so you can inspect the O-ring - use non-permanent thread locking agent on the bolt threads during assembly



17.10 Remove the pump mounting bolts



17.11 Lift out the pump and its oil pipe; if necessary, unbolt the pipe from the pump and remove them separately



17.16 The recessed side of the drive gear faces away from the oil pump - the snap-ring fits into the recess

17 Oil pump - pressure check, removal, inspection and installation


Note: Oil pump removal requires that the engine be removed and the crankcase disassembled.

Pressure check

Refer to illustration 17.2

Warning: If the oil passage plug is removed when the engine is hot, hot oil will drain out - wait until the engine is cold before beginning this check (it must be cold to perform the relief valve opening pressure check, anyway).

- 1 Remove the right footpeg (see Chapter 8).
- 2 Remove the plug at the bottom of the crankcase on the right-hand side and install an oil pressure gauge (see illustration).
- 3 Start the engine and watch the gauge while varying the engine rpm. The pressure should stay within the relief valve opening pressure listed in this Chapter's Specifications. If the pressure is too high, the relief valve is stuck closed. To check it, see Section 18.
- 4 If the pressure is lower than the standard, either the relief valve is stuck open, the oil pump is faulty, or there is other engine damage. Begin diagnosis by checking the relief valve (see Section 18), then the oil pump. If those items check out okay, chances are the bearing oil clearances are excessive and the engine needs to be overhauled.
- 5 If the pressure reading is in the desired range, allow the engine to warm up to normal operating temperature and check the pressure



17.12 Oil pump - exploded view

again, at the specified engine rpm. Compare your findings with this Chapter's Specifications.

- 6 If the pressure is significantly lower than specified, check the relief valve and the oil pump.

Removal

Refer to illustrations 17.8, 17.9, 17.10 and 17.11

- 7 Remove the engine and disassemble the crankcase (see Sections 5 and 22).
- 8 Remove the oil pump pickup tube from the pump so you can inspect the O-ring (see illustration).
- 9 Remove the snap-ring and detach the oil pump gear from the shaft (see illustration).
- 10 Remove the pump mounting bolts (see illustration).
- 11 Remove the pump and its oil pipe (see illustration).

Inspection


Refer to illustration 17.12

- 12 Remove the oil pump cover screws and lift off the cover (see illustration).
- 13 Remove the oil pump shaft, pin, inner rotor and outer rotor from the pump. Mark the rotors so they can be installed in the same relative positions.
- 14 Wash all the components in solvent, then dry them off. Check the pump body, the rotors and the cover for scoring and wear. Make sure the pick-up screen isn't clogged. Measure clearance between the rotors and between the outer rotor and pump body with a feeler gauge. If it exceeds the amount listed in this Chapter's Specifications, replace the oil pump (individual parts aren't available). If you are rebuilding the engine, it's a good idea to install a new oil pump.
- 15 Reassemble the pump by reversing the disassembly steps, but before installing it, prime it by pouring oil into it while turning the shaft by hand - this will ensure that it begins to pump oil quickly.


Installation

Refer to illustration 17.16


- 16 Installation is the reverse of removal, with the following additions:
 - a) Make sure the pickup O-ring is in place.



18.2 Location of the oil pressure relief valve (arrow)



19.3 Loosen the forward clutch cable nut to create slack



19.4 Disengage the end of the cable from the release lever

- b) Use non-permanent thread locking agent on the pickup mounting screws and the oil pump mounting bolts.
- c) Install the drive gear with its recessed side away from the pump (see illustration).

18 Oil pressure relief valve - removal, inspection and installation

Refer to illustration 18.2

Removal


- 1 Remove the oil pan (see Section 16).
- 2 Unscrew the relief valve from the oil pan (see illustration).

Inspection


- 3 Clean the valve with solvent and dry it, using compressed air if available.
- 4 Using a wood or plastic tool, depress the steel ball inside the valve and see if it moves smoothly. Make sure it returns to its seat completely. If it doesn't, replace it with a new one (don't attempt to disassemble and repair it).

Installation

- 5 Apply a non-permanent thread locking compound to the threads of the valve and install it into the oil pan, tightening it to the torque listed in this Chapter's Specifications.
- 6 The remainder of installation is the reverse of removal.



19.5a Remove the clutch cover bolts (arrows). . .



19.5b . . .take the cover off (tap it gently with a soft-faced hammer if it's stuck). . .

19 Clutch - removal, inspection and installation

Note: The clutch (except the housing) can be removed with the engine in the frame. Removal of the housing requires that the engine be removed and the crankcase disassembled.


Removal

Refer to illustrations 19.3, 19.4, 19.5a, 19.5b, 19.5c, 19.6a, 19.6b, 19.7, 19.8, 19.9a and 19.9b


- 1 Set the bike on its centerstand (if equipped).
- 2 Drain the engine oil (see Chapter 1).
- 3 Completely loosen the forward adjustment nut on the clutch cable at its bracket on the clutch cover (see illustration).
- 4 Pull the cable out of the bracket, then detach the cable end from the lever (see illustration).
- 5 Remove the clutch cover bolts and take the cover off together with the release lever (see illustrations). If the cover is stuck, tap around its perimeter with a soft-face hammer.
- 6 Loosen the clutch spring bolts in a criss-cross pattern (see illustration). To prevent the assembly from turning, thread one of the cover mounting bolts into the case and wedge a screwdriver between the bolt and the clutch housing. Remove the clutch springs, spring plate and bearing (see illustration).
- 7 Note the direction of the radial grooves in the friction plate, then remove the pushrod, friction plates and steel plates from the clutch housing (see illustration).




19.5c ...and note the location of the cover dowel




19.6a Loosen the spring bolts in a criss-cross pattern...



19.6b When spring tension is released, remove the springs and the spring plate




19.7 Remove the clutch pushrod from the hub, then remove the friction plates and metal plates - note the direction of the grooves in the friction plates; they must be reinstalled the same way




19.8 You can make your own clutch holding tool out of steel strap

3 Remove the clutch hub nut, using a special holding tool (Kawasaki tool no. 57001-305 or 1243) to prevent the clutch housing from turning. An alternative to this tool can be fabricated from some steel strap, bent at the ends and bolted together in the middle (see illustration). The nut is self-locking, so discard it and replace it with a new one during installation.

3 Remove the washer, clutch hub and thrust washer (see illustrations).



19.9a Remove the nut and washer, then remove the clutch hub and thrust washer



19.9b Exploded view of the clutch assembly

Inspection

Refer to illustrations 19.10, 19.11, 19.12, 19.13, 19.15 and 19.16

10 Examine the splines on both the inside and the outside of the clutch hub (**see illustration**). If any wear is evident, replace the hub with a new one.

11 Measure the free length of the clutch springs (**see illustration**) and compare the results to this Chapter's Specifications. If the springs have sagged, or if cracks are noted, replace them with new ones as a set.

12 If the lining material of the friction plates smells burnt or if it is glazed, new parts are required. If the metal clutch plates are scored or discolored, they must be replaced with new ones. Measure the thickness of each friction plate (**see illustration**) and compare the results to this Chapter's Specifications. Replace the friction plates as a set if they are near the wear limit.


13 Lay all metal and friction plates, one at a time, on a perfectly flat surface (such as a piece of plate glass) and check for warpage by try-

ing to slip a 0.012-inch (0.3 mm) feeler gauge between the flat surface and the plate (**see illustration**). Do this at several places around the plate's circumference. If the feeler gauge can be slipped under the plate, it is warped and should be replaced with a new one.

14 Check the tabs on the friction plates for excessive wear and mushroomed edges. They can be cleaned up with a file if the deformation is not severe.

15 Check the edges of the slots in the clutch housing for indentations made by the friction plate tabs (**see illustration**). If the indentations are deep they can prevent clutch release, so the housing should be replaced with a new one. If the indentations can be removed easily with a file, the life of the housing can be prolonged to an extent.


16 Check the clutch spring plate for wear and damage and make sure the pushrod is not bent (roll it on a perfectly flat surface or use V-blocks and a dial indicator). Check the fit of the pushrod in the spring plate bearing (**see illustration**). Check the bearing for wear or damage. Replace the pushrod and bearing if they're worn.




19.10 Check the clutch hub splines (arrows) for wear and distortion




19.11 Measure the clutch spring free length




19.12 Measure the thickness of the friction plates




19.13 Check all plates for warpage



19.15 Check the slots on the clutch housing for indentations - if they're worn, the crankcase will have to be disassembled to remove the clutch housing



19.16 Check the pushrod and the bearing in the spring plate for wear and damage



21.2 Shift pedal and linkage - exploded view

17 Clean all traces of old gasket material from the clutch cover. If the release shaft seal has been leaking, it can be replaced by removing the positioning bolt on the outside of the housing (early models) and pulling out the shaft. The seal can then be pried out and a new one driven in, using a hammer and a socket with an outside diameter slightly smaller than that of the seal. Be careful when installing the release shaft not to damage the new oil seal. Note that there should be a gap to 1-to-3 mm (0.04-to-0.12 inch) between the release shaft arm and the top of the casing, and that with the cable attached an angle of 80-to-90 degrees is formed between arm and cable. On early models, secure the shaft with the positioning bolt.

Installation

18 Install the clutch housing thrust washer and the clutch hub. Install a new hub nut and tighten it to the torque listed in this Chapter's Specifications. Use the technique described in Step 8 to prevent the hub from turning.

19 Coat the clutch friction plates with engine oil. Install the clutch plates, starting with a friction plate and alternating them. There are seven friction plates and six steel plates. Be sure the radial grooves in the friction plates are pointed in the correct direction (see illustration 19.7).

20 Lubricate the pushrod and install it through the spring plate. Mount the spring plate to the clutch assembly and install the springs and bolts, tightening them to the torque listed in this Chapter's Specifications in a criss-cross pattern.

21 Make sure the clutch cover dowel is in place (see illustration 19.5c). Install the clutch cover and bolts, using a new gasket. Tighten the bolts, in a criss-cross pattern, to the torque listed in this Chapter's Specifications.

22 Connect the clutch cable to the release lever and adjust the freeplay (see Chapter 1).

23 Fill the crankcase with the recommended type and amount of engine oil (see Chapter 1).

20 Clutch cable - replacement

1 Disconnect the upper end of the clutch cable from the lever (see Chapter 1).


2 Disconnect the clutch cable from the release lever (see Section 19).


3 Before removing the cable from the bike, tape the lower end of the new cable to the upper end of the old cable. Slowly pull the lower end of the old cable out, guiding the new cable down into position. Using this method will ensure the cable is routed correctly.

4 Lubricate the cable (see Chapter 1). Reconnect the ends of the cable by reversing the removal procedure, then adjust the cable following the procedure given in Chapter 1.


21.5 Shift linkage adjustment

- | | |
|---------------|---------------------|
| 1 90-degrees | 3 Shift linkage rod |
| 2 Shift lever | 4 Locknut |





21.9 Remove the cover bolts (A) - the larger bolt (B) secures the bottom end of the drive belt guard



21.10 Compress the shift arm (A) to disengage it from the shift cam, and slide the shift shaft (B) out of the casing

21 External shift mechanism - removal, inspection and installation

Note: The external shift mechanism can be removed with the engine in the frame.

Shift lever and pedal

Refer to illustrations 21.2 and 21.5

- 1 Set the bike on its centerstand.
- 2 Remove the shift pedal bolt (see illustration). Take the shift pedal off the shaft.
- 3 Remove the shift linkage bolts.
- 4 To ease installation, make alignment marks on the shift lever shafts and the shift levers. Remove the snap-rings and pull the shift levers off the shafts.
- 5 Installation is the reverse of removal. The shift linkage rod should be at 90-degrees to the shift levers. Adjust as needed with the nuts on the linkage rod (see illustration).

Shift mechanism


Removal

Refer to illustrations 21.9, 21.10, 21.11a and 21.11b


- 6 Remove the shift pedal and linkage (Steps 1 through 4).
- 7 Remove the drive belt, engine pulley and belt guard (see Chapter 6).
- 8 Disconnect the electrical connector from the neutral switch (see Chapter 9).
- 9 Remove the shift mechanism cover bolts and remove the cover (see illustration).
- 10 Compress the shift mechanism arm against the spring tension to disengage it from the shift drum cam (see illustration). Slide the shift mechanism out of the casing.
- 11 Remove the nut from the gear positioning lever (see illustration). Remove the locating washer, lever, spring and washer (see illustration).

Inspection

- 12 Check the shift shaft for bends and damage to the splines. If the shaft is bent, you can attempt to straighten it, but if the splines are damaged it will have to be replaced.
- 13 Check the condition of the gear positioning lever and spring, pin plate and shift drum cam. Replace them if they are cracked or distorted.
- 14 Check the shift mechanism arm for cracks, distortion and wear. If any of these conditions are found, replace the shift mechanism.




21.11a Remove the nut (A) and detach the washer, gear positioning lever, spring and washer. Note return spring pin (B).




21.11b Details of the gear positioning lever

- | | |
|--|---------------------------|
| A) Nut | C) Spring |
| B) Washer (the collar fits inside the gear positioning lever hole) | D) Gear positioning lever |
| | E) Washer |



21.18 External shift mechanism - exploded view



22.6b ...and place them in order in a holder (a piece of cardboard with holes punched in it works well)

15 Make sure the return spring pin isn't loose. If it is, unscrew it, apply a non-permanent locking compound to the threads, then reinstall the pin and tighten it securely.

16 Check the condition of the seal in the cover. If it has been leaking, drive it out with a hammer and punch. Drive a new seal in with a socket.

Installation

Refer to illustration 21.17

17 Assemble the positioning lever components (see illustrations 21.11b and 21.18) and install on the casing. The shift drum should be in neutral so that the positioning lever roller locates in the neutral detent. Ensure that the leg of the return spring is correctly located against the casing web (see illustration 21.11a).

18 Slide the external shift mechanism into place, compressing the shift arm against the spring to clear the shift drum. Make sure the springs are positioned correctly (see illustration).

19 Apply high-temperature grease to the lip of the seal. Wrap the splines of the shift shaft with electrical tape, so the splines won't damage the seal as the cover is installed.

20 Install a new gasket on the casing. Carefully guide the cover into place and install the screws, tightening them securely.


21 Install the engine pulley, drive belt and engine pulley cover (see Chapter 6).

22 Install and adjust the shift pedal and linkage (see Steps 1 through 5).

23 Check the engine oil level and add some, if necessary (see Chapter 1).

22 Crankcase - disassembly and reassembly

1 To examine and repair or replace the crankshaft, connecting rods, bearings, clutch housing, transmission components, oil pump,



22.6a Loosen the small upper case bolts first, then the large bolt...

1) Large bolts (8 mm)

2) Small bolts (6 mm)

balancer and starter motor clutch, the crankcase must be split into two parts.

2 Remove the clutch cover (see Section 19) and the external shift mechanism (see Section 21).

3 Remove the water pump and coolant pipe (on the cylinder block) (see Chapter 3).

4 Remove the alternator cover (see Chapter 9).

Disassembly

Refer to illustrations 22.6a, 22.6b, 22.9a, 22.9b, 22.9c, 22.10, 22.11a, 22.11b, 22.11c and 22.12

5 If the crankcase is being separated to remove the crankshaft, remove the alternator rotor and the stator (see Chapter 9), cylinder head, cylinder block and pistons (see Sections 10, 13 and 14). Remove the clutch if you are separating the crankcase halves to disassemble the transmission main drive shaft (see Section 19).

6 Remove the small upper crankcase half bolts, then the single large bolt (see illustrations).

7 Turn the engine upside-down and remove the oil filter (see Chapter 1, if necessary).

8 Remove the oil pan (see Section 16) and retrieve the O-rings from the oil passages.


9 Remove the oil pump outer pipe and main oil pipe connecting pipe (see illustrations).

10 Remove the small lower crankcase half bolts, then the large bolts (see illustration 22.6a and the accompanying illustration).


11 Carefully pry the crankcase apart. Pry ONLY in the areas indicated (see illustrations).

12 Separate the crankcase halves (see illustration).


13 Refer to Sections 23 through 31 for information on the internal components of the crankcase.




22.9a Remove the mounting bolt and lift out the outer oil pipe




22.9b Remove the main oil pipe connecting bolt on the side of the case (arrow). . .




22.9c . . .and one in the oil pan (upper arrow), then disconnect the oil pipe from the engine (lower arrow)




22.10 The tightening sequence numbers for the large lower case bolts are cast into the case (arrows)




22.11a Pry only at the pry points; there's one on the end of the case (arrow). . .




22.11b . . .one on the clutch side (arrow). . .




22.11c . . .and one on the alternator side (arrow)




22.12 Lift the lower case half off the upper case half




22.15a Note the location of the case dowels (arrow). . .




22.15b . . .there's one in each end of the case



22.16 Spread a thin layer of gasket sealant on the mating surfaces, but don't place it too close to the bearings



22.17a When the shift drum is in neutral, the gear positioning lever fits into the slot in the shift cam (arrow)



22.17b The shift forks should be in the Neutral position. . .

Reassembly


Refer to illustrations 22.15a, 22.15b, 22.16, 22.17a, 22.17b, 22.17c and 22.18

14 Remove all traces of sealant from the crankcase mating surfaces. Be careful not to let any fall into the case as this is done.


15 Check to make sure the two dowel pins are in place in their holes in the mating surface of the upper crankcase half (see illustrations).

Pour some engine oil over the transmission gears, the crankshaft main bearings and the shift drum. Don't get any oil on the crankcase mating surface.

16 Apply a thin, even bead of Kawasaki Bond sealant (part no. 56019-120) to the crankcase mating surfaces (see illustration). **Caution:** Don't apply an excessive amount of sealant, and don't apply it next to the bearing inserts, as it will ooze out when the case halves are



22.17c . . .and so should the fork slots in the gears (arrows) - while you're checking the gears, take a good look to make sure nothing is in the case that doesn't belong there



22.18 Be sure both ends of the breather tube fit into their holes when the cases are assembled (transmission output shaft removed for clarity)

assembled and may obstruct oil passages and prevent the bearings from seating.

17 Check the position of the shift drum, shift forks and transmission shafts - make sure they're in the neutral position (see illustrations).

18 Carefully assemble the crankcase halves. While doing this, make sure the shift forks fit into their gear grooves, and guide the breather tube into its hole in the lower crankcase half (see illustration).

19 Install the lower crankcase half bolts and tighten them so they are just snug.

20 In two steps, tighten the larger bolts (8 mm), in the indicated sequence, to the torque listed in this Chapter's Specifications (see illustration 22.6a).

21 Install the smaller (6 mm) bolts in the lower crankcase half, tightening them to the torque listed in this Chapter's Specifications.

22 Install the main oil connecting pipe (see illustration 22.9b). Use new O-rings coated lightly with engine oil.

23 Apply engine oil to both ends of the oil pump outer pipe, then install the ends in their holes (see illustration 22.9a). Apply non-permanent thread locking compound to the bolt that secures the outer pipe.

24 Install the oil pan (see Section 16).

25 Turn the case over and install the upper crankcase half bolts. Tighten the large (8 mm bolt) first, then tighten the others in the indicated sequence to the torque listed in this Chapter's Specifications (see illustration 22.6a).

26 Turn the main drive shaft and the output shaft to make sure they

turn freely. Also make sure the crankshaft turns freely.

27 The remainder of installation is the reverse of removal, with the following additions:

- Once the external shift linkage is installed, shift the transmission through all the gear positions and back to Neutral. Because the positive neutral finder locks out second gear when the output shaft isn't spinning, you'll have to spin the output shaft to shift into second through sixth gears.
- Be sure to refill the engine oil and coolant.


23 Crankcase components - inspection and servicing

Refer to illustrations 23.2a, 23.2b, 23.2c, 23.3, 23.4, 23.5, 23.6a and 23.6b


1 After the crankcases have been separated and the crankshaft, shift drum and forks and transmission components removed, the crankcases should be cleaned thoroughly with new solvent and dried with compressed air.

2 Remove any oil pipes that haven't already been removed. All oil passages and pipes should be blown out with compressed air (see illustrations).


3 Remove the breather body (see illustration). Inspect its O-ring; it's a good idea to install a new one.




23.2a Remove the oil line from the left front corner of the case. . .




23.2b . . .the line farther back along the left side. . .




23.2c ...and the oil passage plug so all the lines and passages can be cleaned




23.3 The breather body is secured by the center bolt (arrow)




23.4 Small burrs can be removed from the gasket surfaces with a fine sharpening stone



23.5 Check both primary chain guides for wear (the lower one is shown here) and replace them if necessary



23.6a Remove this lock-pin if you plan to remove the cam chain guide - DO NOT forget to reinstall it, or the chain guide retaining pin could slide out and damage the crankshaft while it's spinning. . .



23.6b ...after removing the crankshaft, pull out the retaining pin and remove the cam chain guide


4 All traces of old gasket sealant should be removed from the mating surfaces. Minor damage to the surfaces can be cleaned up with a fine sharpening stone (see illustration). **Caution:** Be very careful not to nick or gouge the crankcase mating surfaces or leaks will result. Check both crankcase sections very carefully for cracks and other damage.

5 Check the primary chain guides for wear - one is in the upper


case half and the other is in the lower case half (see illustration). If they appear to be worn excessively, replace them.

6 Check the front cam chain guide for wear. If it's worn, remove the lock-pin (see illustration). The retaining pin (see illustration) and chain guide can be removed after the crankshaft has been removed (see Section 25).

7 If any damage is found that can't be repaired, replace the crankcase halves as a set.



25.2 Slip the clutch housing back-and-forth to expose the inner bearing sleeve (arrow), then pull it out



25.3a Lift the clutch housing and transmission main drive shaft. . .

24 Main and connecting rod bearings - general note

1 Even though main and connecting rod bearings are generally replaced with new ones during the engine overhaul, the old bearings should be retained for close examination as they may reveal valuable information about the condition of the engine.

2 Bearing failure occurs mainly because of lack of lubrication, the presence of dirt or other foreign particles, overloading the engine and/or corrosion. Regardless of the cause of bearing failure, it must be corrected before the engine is reassembled to prevent it from happening again.

3 When examining the bearings, remove the main bearings from the case halves and the rod bearings from the connecting rods and caps and lay them out on a clean surface in the same general position as their location on the crankshaft journals. This will enable you to match any noted bearing problems with the corresponding side of the crankshaft journal.

4 Dirt and other foreign particles get into the engine in a variety of ways. It may be left in the engine during assembly or it may pass through filters or breathers. It may get into the oil and from there into the bearings. Metal chips from machining operations and normal engine wear are often present. Abrasives are sometimes left in engine components after reconditioning operations such as cylinder honing, especially when parts are not thoroughly cleaned using the proper cleaning methods. Whatever the source, these foreign objects often end up imbedded in the soft bearing material and are easily recognized. Large particles will not imbed in the bearing and will score or gouge the bearing and journal. The best prevention for this cause of bearing failure is to clean all parts thoroughly and keep everything spotlessly clean during engine reassembly. Frequent and regular oil and filter changes are also recommended.

5 Lack of lubrication or lubrication breakdown has a number of interrelated causes. Excessive heat (which thins the oil), overloading (which squeezes the oil from the bearing face) and oil leakage or throw off (from excessive bearing clearances, worn oil pump or high engine speeds) all contribute to lubrication breakdown. Blocked oil passages will also starve a bearing and destroy it. When lack of lubrication is the cause of bearing failure, the bearing material is wiped or extruded from the steel backing of the bearing. Temperatures may increase to the point where the steel backing and the journal turn blue from overheating.

6 Riding habits can have a definite effect on bearing life. Full throttle low speed operation, or lugging (labouring) the engine, puts very high loads on bearings, which tend to squeeze out the oil film. These loads cause the bearings to flex, which produces fine cracks in the bearing face (fatigue failure). Eventually the bearing material will loosen in pieces and tear away from the steel backing. Short trip riding leads to corrosion of bearings, as insufficient engine heat is produced to drive off the condensed water and corrosive gases produced. These



25.3b . . .and disengage the housing from the primary chain

products collect in the engine oil, forming acid and sludge. As the oil is carried to the engine bearings, the acid attacks and corrodes the bearing material.

7 Incorrect bearing installation during engine assembly will lead to bearing failure as well. Tight fitting bearings which leave insufficient bearing oil clearances result in oil starvation. Dirt or foreign particles trapped behind a bearing insert result in high spots on the bearing which lead to failure.

8 To avoid bearing problems, clean all parts thoroughly before re-assembly, double check all bearing clearance measurements and lubricate the new bearings with engine assembly lube or moly-based grease during installation.

25 Clutch hub, crankshaft and main bearings - removal, inspection, main bearing selection and installation


Clutch housing removal

Refer to illustrations 25.2, 25.3a and 25.3b


1 If you haven't already done so, remove all clutch components except the housing (see Section 19).

2 Slide the clutch housing back and forth on the shaft within the limits allowed by the primary chain to expose the inner bearing (see illustration). Pull the bearing out.


3 Lift the transmission main drive shaft and clutch housing from the case (see illustration). Slip the transmission shaft out of the clutch housing and disengage the housing from the primary chain (see illustration).




25.5 Measure the endplay with a feeler gauge inserted between the no. 2 crank journal and the case web - if the endplay isn't as listed in this Chapter's Specifications, the case halves must be replaced



25.6 The crankshaft, primary chain and cam chain



25.7 To remove a main bearing insert, push it sideways and lift it out



25.8 Inspect the bearing in the center of the clutch housing - replace the clutch housing if it's worn or damaged

Crankshaft removal

Refer to illustrations 25.5, 25.6 and 25.7

4 If you haven't already done so, remove the connecting rod caps (see Section 26).

5 Before removing the crankshaft check the endplay. This can be done with a dial indicator mounted in-line with the crankshaft, or feeler gauges inserted between the crankshaft and no. 2 crankcase main journal (**see illustration**). Compare your findings with this Chapter's Specifications. If the endplay is excessive, the case halves must be replaced.

6 Lift the crankshaft out, together with the cam chain and primary chain and set them on a clean surface (**see illustration**).


7 The main bearing inserts can be removed from their saddles by pushing their centers to the side, then lifting them out (**see illustration**). Keep the bearing inserts in order. The main bearing oil clearance should be checked, however, before removing the inserts (see Step 13).

Inspection

Refer to illustrations 25.8 and 25.10


8 Check the clutch housing bearing for wear or damage (**see illustration**). Replace the clutch housing if necessary. Also inspect the slots in the housing (see Section 19).

9 If you haven't already done so, mark and remove the connecting




25.10 Inspect the crankshaft at the following points:


- | | |
|----------------------------|-----------------------|
| A) Main bearing journals | D) Primary chain gear |
| B) Connecting rod journals | E) Balancer gear |
| C) Cam chain gear | |




25.13 Lay the Plastigage strips (arrow) on the journals, parallel to the crankshaft centerline



25.15 Measuring the width of the crushed Plastigage (be sure to use the correct scale - standard and metric are included)



25.16 Bearing thicknesses are identified by color codes on the sides of the bearings



25.18 Measure the diameter of each crankshaft journal at several points to detect taper and out-of-round conditions

rods from the crankshaft (see Section 26).

10 Clean the crankshaft with solvent, using a rifle-cleaning brush to scrub out the oil passages. If available, blow the crank dry with compressed air. Check the main and connecting rod journals for uneven wear, scoring and pits (see illustration). Rub a copper coin across the journal several times - if a journal picks up copper from the coin, it's too rough. Replace the crankshaft.

11 Check the balancer gear, camshaft chain gear and primary chain gear on the crankshaft for chipped teeth and other wear. If any undesirable conditions are found, replace the crankshaft. Check the chains as described in Section 28. Check the rest of the crankshaft for cracks and other damage. It should be magnafluxed to reveal hidden cracks - a dealer service department or motorcycle machine shop will handle the procedure.

12 Set the crankshaft on V-blocks and check the runout with a dial indicator touching one of the center main journals, comparing your findings with this Chapter's Specifications. If the runout exceeds the limit, replace the crank.

Main bearing selection

Refer to illustrations 25.13, 25.15, 25.16, 25.18, 25.20, 25.21 and 25.22

13 To check the main bearing oil clearance, clean off the bearing inserts (and reinstall them, if they've been removed from the case) and lower the crankshaft into the upper half of the case. Cut four pieces of Plastigage (type HPG-1) and lay them on the crankshaft main journals, parallel with the journal axis (see illustration).


14 Very carefully, guide the lower case half down onto the upper case half. Install the large (8 mm) bolts and tighten them, using the recommended sequence, to the torque listed in this Chapter's Specifications (see Section 22). Don't rotate the crankshaft!

15 Now, remove the bolts and carefully lift the lower case half off. Compare the width of the crushed Plastigage on each journal to the scale printed on the Plastigage envelope to obtain the main bearing oil clearance (see illustration). Write down your findings, then remove all traces of Plastigage from the journals, using your fingernail or the edge of a credit card.

16 If the oil clearance falls into the specified range, no bearing replacement is required (provided they are in good shape). If the clearance is more than the standard range, but within the service limit, replace the bearing inserts with inserts that have blue paint marks (see illustration), then check the oil clearance once again (these are the thickest bearing inserts, and may be thick enough to bring bearing clearance within the specified range). Always replace all of the inserts at the same time.

17 The clearance might be slightly greater than the standard clearance, but that doesn't matter, as long as it isn't greater than the maximum clearance or less than the minimum clearance.

18 If the clearance is greater than the service limit listed in this Chapter's Specifications, measure the diameter of the crankshaft journals with a micrometer (see illustration) and compare your findings with this Chapter's Specifications. Also, by measuring the diameter at a number of points around each journal's circumference, you'll be able to determine whether or not the journal is out-of-round. Take the



25.20 Use the marks (or absence of marks) on the crankshaft (this crankshaft has no marks) . . .

- A) No. 1 main bearing journal mark
- B) No. 2 main bearing journal mark
- C) No. 3 main bearing journal mark
- D) No. 4 main bearing journal mark
- E) No. 1 connecting rod journal mark
- F) No. 2 connecting rod journal mark

Crankshaft Main Bearing Insert Selection

Crankcase Main Bearing Bore Diameter Mark	Crankshaft Main Journal Diameter Mark	Bearing Insert*		
		Size Color	Part Number	Journal Nos.
○	1	Brown	92028-1102	2, 3
			92028-1274	.1, 4
None	None	Blue	92028-1100	3
			92028-1272	1, 4
○	None	Black	92028-1101	2, 3
None	1		92028-1273	1, 4

*The bearing inserts for Nos. 2 and 3 journals have oil grooves.

25.22 . . .to determine the proper main bearing sizes

measurement at each end of the journal, near the crank throws, to determine if the journal is tapered.

19 If any crank journal has worn down past the service limit, replace the crankshaft.


20 If the diameters of the journals aren't less than the service limit but differ from the original markings on the crankshaft (**see illustration**), apply new marks with a hammer and punch.

If the journal measures within the "no mark" range listed in the Specifications, don't make any marks on the crank (there shouldn't be any marks there, anyway).

If the journal measures within the "1" mark range listed in the Specifications, make a "1" mark on the crank in the area indicated (if it's not already there).


21 Remove the main bearing inserts and assemble the case halves (**see Section 22**). Using a telescoping gauge and a micrometer, measure the diameters of the main bearing bores, then compare the measurements with the marks on the upper case half (**see illustration**). Compare the bore measurements with those listed in this Chapter's Specifications. Also compare the bore measurements to the marks on the crankcase to find out whether the marks are accurate.

22 Using the marks on the crank and the marks on the case, determine the bearing sizes required by referring to the accompanying bearing selection chart (**see illustration**).



25.21 . . . in conjunction with the marks (or absence of marks) on the case (this case has no marks)

- A) No. 1 main bearing bore mark
- B) No. 2 main bearing bore mark
- C) No. 3 main bearing bore mark
- D) No. 4 main bearing bore mark



25.23 Make sure the tabs in the bearing inserts (arrows) fit into the notches in the web; the center two main bearings have oil grooves

Installation

Refer to illustrations 25.23, 25.27, 25.30a and 25.30b

23 Separate the case halves once again. Clean the bearing saddles in the case halves, then install the bearing inserts in their webs in the case (**see illustration**). The center two bearing inserts have oil grooves. When installing the bearings, use your hands only - don't tap them into place with a hammer.


24 Lubricate the bearing inserts with engine assembly lube or moly-based grease.

25 You can install the connecting rods on the crankshaft at this point if the top end was removed from the engine (**see Section 26**).


26 Loop the camshaft chain and the primary chain over the crankshaft and lay them onto their gears.

27 Check to make sure the cam chain guide retaining pin and lock-pin are in position. If the connecting rods are in the engine, place pieces of hose over the studs to protect the crankshaft (**see illustration**).

28 Carefully lower the crankshaft into place. If the connecting rods are in the engine, guide them onto the crankshaft journals.



25.27 Before you install the crankshaft, check to be sure the cam chain guide retainer pin (lower arrow) is pushed all the way in and its lock-pin (upper arrow) is in place - if the connecting rods are installed, put pieces of hose on the studs to protect the crankshaft



25.30b . . . and the beveled side of the clutch housing thrust washer must face toward the ball bearing on the transmission main drive shaft

29 Assemble the case halves (see Section 22) and check to make sure the crankshaft and the transmission shafts turn freely.

30 Install the oil pump drive gear and clutch housing. The pin in the gear must engage the notch in the housing (see illustration). The beveled side of the clutch housing thrust washer faces the ball bearing on the transmission main drive shaft (see illustration).

26 Connecting rods and bearings - removal, inspection, bearing selection and installation

Removal


Refer to illustrations 26.1, 26.2, 26.3a and 26.3b

1 Before removing the connecting rods from the crankshaft, measure the side clearance of each rod with a feeler gauge (see illustration). If the clearance on any rod is greater than that listed in this Chapter's Specifications, that rod will have to be replaced with a new one.


2 Using a center punch, mark the position of each rod and cap, relative to its position on the crankshaft (see illustration).




25.30a The pin in the oil pump drive gear must engage the notch in the clutch housing (arrows). . .




26.1 Slip a feeler gauge blade between the connecting rod and crankshaft throw (arrow) to check connecting rod side clearance



26.2 Make number marks (arrows) on the connecting rod and cap so they can be reassembled in their original positions, and note the relationship of the connecting rod to the crankshaft - the letter mark across the rod and cap indicates the connecting rod weight grade



26.3a Remove the connecting rod nuts (arrows)...



26.3b ...and take the cap off the studs

3 Unscrew the bearing cap nuts, separate the cap from the rod, then detach the rod from the crankshaft (**see illustrations**). If the cap is stuck, tap on the ends of the rod bolts with a soft face hammer to free them.

4 Separate the bearing inserts from the rods and caps, keeping them in order so they can be reinstalled in their original locations. Wash the parts in solvent and dry them with compressed air, if available.

Inspection

Refer to illustration 26.5

5 Check the connecting rods for cracks and other obvious damage. Lubricate the piston pin for each rod, install it in the proper rod and check for play (**see illustration**). If it is loose, replace the connecting rod and/or the pin.

6 Refer to Section 24 and examine the connecting rod bearing inserts. If they are scored, badly scuffed or appear to have been seized, new bearings must be installed. Always replace the bearings in the connecting rods as a set. If they are badly damaged, check the corresponding crankshaft journal. Evidence of extreme heat, such as discoloration, indicates that lubrication failure has occurred. Be sure to thoroughly check the oil pump and pressure relief valve as well as all oil holes and passages before reassembling the engine.

7 Have the rods checked for twist and bending at a dealer service department or other motorcycle repair shop.

Bearing selection

Refer to illustrations 26.20a, 26.20b and 26.21

8 If the bearings and journals appear to be in good condition, check the oil clearances as follows:

9 Start with the rod for the number one cylinder. Wipe the bearing inserts and the connecting rod and cap clean, using a lint-free cloth.


10 Install the bearing inserts in the connecting rod and cap. Make sure the tab on the bearing engages with the notch in the rod or cap.

11 Wipe off the connecting rod journal with a lint-free cloth. Lay a strip of Plastigage (type HPG-1) across the top of the journal, parallel with the journal axis (**see illustration 25.13**).

12 Position the connecting rod on the bottom of the journal, then install the rod cap and nuts. Tighten the nuts to the torque listed in this Chapter's Specifications, but don't allow the connecting rod to rotate at all.

13 Unscrew the nuts and remove the connecting rod and cap from the journal, being very careful not to disturb the Plastigage. Compare the width of the crushed Plastigage to the scale printed in the Plastigage envelope (**see illustration 25.15**) to determine the bearing oil clearance.

14 If the clearance is within the range listed in this Chapter's Specifications and the bearings are in perfect condition, they can be reused.



26.5 Checking the piston pin and connecting rod bore for wear

If the clearance is beyond the standard range, but within the service limit, replace the bearing inserts with inserts that have blue paint marks, then check the oil clearance once again (these are the thickest bearing inserts, and may be thick enough to bring bearing clearance within the specified range). Always replace all of the inserts at the same time.

15 The clearance might be slightly greater than the standard clearance, but that doesn't matter, as long as it isn't greater than the maximum clearance or less than the minimum clearance.


16 If the clearance is greater than the service limit listed in this Chapter's Specifications, measure the diameter of the connecting rod journal with a micrometer and compare your findings with this Chapter's Specifications. Also, by measuring the diameter at a number of points around the journal's circumference, you'll be able to determine whether or not the journal is out-of-round. Take the measurement at each end of the journal to determine if the journal is tapered.

17 If any journal has worn down past the service limit, replace the crankshaft.


18 If the diameter of the journal isn't less than the service limit but differs from the original markings on the crankshaft (**see illustration 25.20**), apply new marks with a hammer and punch.

If the journal measures within the "no mark" range listed in this Chapter's Specifications, don't make any marks on the crank (there shouldn't be one there anyway).

If the journal measures within the "0" mark range listed in this Chapter's Specifications, make a "0" mark on the crank in the area indicated (if not already there).



26.20a Assemble the connecting rod and measure the diameter of the bore with a telescoping gauge - then measure the gauge with a micrometer




26.20b There's a letter that indicates weight grade on each connecting rod; a "0" or the absence of a "0" around the letter. . .

Connecting Rod Big End Bearing Insert Selection

Con-rod Big End Bore Diameter Mark	Crankpin Diameter Mark	Bearing Insert	
		Size Color	Part Number
○	○	Black	92028-1349
None	None		
○	None	Blue	92028-1348
None	○	Brown	92028-1350

26.21 . . . can be used, in conjunction with this chart, to determine the correct bearing inserts to install



27.2 Correct alignment of the marks on the balancer gear and crankshaft gear is essential to prevent severe engine vibration

19 Remove the bearing inserts from the connecting rod and cap, then assemble the cap to the rod. Tighten the nuts to the torque listed in this Chapter's Specifications.

20 Using a telescoping gauge and a micrometer, measure the inside diameter of the connecting rod (see illustration). The mark on the connecting rod (if any) should coincide with the measurement, but if it doesn't, make a new mark (see illustration).

If the inside diameter measures within the "no mark" range listed in this Chapter's Specifications, don't make any mark on the rod (there shouldn't be one there anyway).

If the inside diameter measures within the "0" mark range, make a "0" mark on the rod (it should already be there).

21 By referring to the accompanying chart (see illustration), select the correct connecting rod bearing inserts.

22 Repeat the bearing selection procedure for the remaining connecting rod.

Installation

23 Wipe off the bearing inserts, connecting rods and caps. Install the inserts into the rods and caps, using your hands only, making sure the tabs on the inserts engage with the notches in the rods and caps. When all the inserts are installed, lubricate them with engine assembly lube or moly-based grease. Don't get any lubricant on the mating surfaces of the rod or cap.

24 Assemble each connecting rod to its proper journal, making sure the previously applied matchmarks correspond to each other and the arrow casting on the piston points to the front of the engine (see illustration 14.3). Also, the letter present at the rod/cap seam on one side

of the connecting rod is a weight mark. If new rods are being installed, they should both have the same letter on them to minimize vibration.

25 When you're sure the rods are positioned correctly, tighten the nuts to the torque listed in this Chapter's Specifications.

26 Turn the rods on the crankshaft. If any of them feel tight, tap on the bottom of the connecting rod caps with a hammer - this should relieve stress and free them up. If it doesn't, recheck the bearing clearance.

27 As a final step, recheck the connecting rod side clearances (see Step 1). If the clearances aren't correct, find out why before proceeding with engine assembly.

27 Balancer shaft - removal, inspection, bearing selection and installation


Removal

Refer to illustration 27.2


1 Split the crankcase (see Section 22).

2 If you're only planning to remove the balancer (not the crankshaft), turn the crankshaft until the marks on the balancer and crankshaft gears are aligned (see illustration).

3 Lift the balancer shaft and gear out of the crankcase.



27.5a The balancer bearing inserts near the external oil line have oil grooves. . .



27.5b . . .while the inserts at the opposite end of the balancer are smooth

Inspection

Refer to illustrations 27.5a and 27.5b

4 Check the shaft and gear for wear and damage. Make sure the springs inside the gear are not broken. Replace the balancer shaft if you find any undesirable conditions.

5 Check the bearings for wear and for damage such as grooves, nicks or small bits of foreign material stuck in their surfaces (**see illustrations**). Replace them if they aren't in perfect condition.

Bearing selection

Refer to illustrations 27.13 and 27.15

6 To check the balancer bearing oil clearance, clean off the bearing inserts (and reinstall them, if they've been removed from the case) and lower the balancer shaft into the upper half of the case. Cut two pieces of Plastigage (type HPG-1) and lay them on the balancer journals, parallel with the journal axis.

7 Very carefully, guide the lower case half down onto the upper case half. Install the large (8 mm) bolts and tighten them, using the recommended sequence, to the torque listed in this Chapter's Specifications (see Section 22). Don't rotate the balancer!


8 Now, remove the bolts and carefully lift the lower case half off. Compare the width of the crushed Plastigage on each journal to the scale printed on the Plastigage envelope to obtain the balancer bearing oil clearance. Write down your findings, then remove all traces of Plastigage from the journals, using your fingernail or the edge of a credit card.

9 If the oil clearance falls into the specified range, no bearing replacement is required (provided they are in good shape). If the clearance is more than the standard range, but within the service limit, replace the bearing inserts with inserts that have blue paint marks (**see illustration 25.16**), then check the oil clearance once again (these are the thickest bearing inserts, and may be thick enough to bring bearing clearance within the specified range). Always replace all of the inserts at the same time.

10 The clearance might be slightly greater than the standard clearance, but that doesn't matter, as long as it isn't greater than the maximum clearance or less than the minimum clearance.

11 If the clearance is greater than the service limit listed in this Chapter's Specifications, measure the diameter of the balancer journals with a micrometer and compare your findings with this Chapter's Specifications. Also, by measuring the diameter at a number of points around each journal's circumference, you'll be able to determine whether or not the journal is out-of-round. Take the measurement at each end of the journal to determine if the journal is tapered.

12 If either balancer journal has worn down past the service limit, replace the balancer shaft.



27.13 There's a journal diameter mark (or no mark, as on this balancer) on each balancer weight; there's also a size mark for each bearing bore on the case. . .

- A) Left bearing bore size mark
- B) Right bearing bore size mark

13 If the diameters of the journals aren't less than the service limit but differ from the original markings on the balancer shaft (**see illustration**), apply new marks with a hammer and punch.

If the journal measures within the "no mark" range listed in the Specifications, don't make any marks on the balancer (there shouldn't be any marks there, anyway).

If the journal measures within the "0" mark range listed in the Specifications, make a "0" mark on the balancer in the area indicated (if it's not already there).

14 Remove the balancer bearing inserts and assemble the case halves (see Section 22). Using a telescoping gauge and a micrometer, measure the diameters of the balancer bearing bores, then compare the measurements with the marks on the upper case half (**see illustration 27.13**). Compare the bore measurements with those listed in this Chapter's Specifications. Also compare the bore measurements to the marks on the crankcase to find out whether the marks are accurate.

15 Using the marks on the crank and the marks on the case, determine the bearing sizes required by referring to the accompanying bearing selection chart (**see illustration**).

Installation

16 Separate the case halves once again. Clean the bearing saddles in the case halves, then install the bearing inserts in their webs in the

Bearing Insert Selection

Crankcase Bearing Inside Diameter Mark	Balancer Shaft Journal Dia- meter Mark	Bearing Insert	
		Size Color	Part Number
○	○	Brown	92028-1497
None	None	Blue	92028-1495
○	None	Black	92028-1496
None	○		

27.15 . . . use them in conjunction with this table to select the correct bearing size

case (see illustrations 27.5a and 27.5b). The bearing insert next to the oil line has an oil groove. When installing the bearings, use your hands only - don't tap them into place with a hammer.

17 Lubricate the bearing inserts with engine assembly lube or moly-based grease.

18 Carefully lay the balancer in the bearings. Be sure the " - " mark on the balancer gear aligns with the "0" mark on the crankshaft gear (see illustration 27.2). Incorrect alignment will cause severe engine vibration.

19 The remainder of installation is the reverse of the removal steps.

28 Primary chain, camshaft chain and guides - removal, inspection and installation

Removal**Primary chain and camshaft chain**

- 1 Remove the engine (see Section 5).
- 2 Separate the crankcase halves (see Section 22).
- 3 Remove the crankshaft (see Section 25).
- 4 Remove the chains from the crankshaft.

Chain guides

5 The cam chain front guide can be lifted from the cylinder block after the head has been removed (see Section 13).

6 The cam chain rear guide is fastened to the crankcase with a retaining pin and lock-pin (see illustrations 23.6a and 23.6b). Pull out the lock-pin and push the retaining pin out, then lift out the chain guide.

7 The primary chain guide in the lower case half is secured by a bolt (see illustration 23.5).

8 The primary chain guide in the upper case half is secured by two bolts.

Inspection**Primary chain and camshaft chain**

Refer to illustration 28.9


9 The primary chain and camshaft chains are checked in a similar manner. Pull the chain tight to eliminate all slack and measure the length of twenty links, pin-to-pin (see illustration). Compare your findings to this Chapter's Specifications.

10 Also check the chains for binding and obvious damage.

11 If the twenty-link length is not as specified, or there is visible damage, replace the chain.

Chain guides

12 Check the guides for deep grooves, cracking and other obvious damage, replacing them if necessary.



28.9 When checking the camshaft chain or the primary chain, measure the length of twenty links and compare to the length listed in this Chapter's Specifications

Installation

13 Installation of these components is the reverse of the removal procedure. When installing the primary chain guides, apply a non-hardening thread locking compound to the threads of the bolts. Tighten the bolts to the torque listed in this Chapter's Specifications. Apply engine oil to the faces of the guides and to the chains.

29 Transmission shafts - removal and installation


Refer to illustrations 29.3a and 29.3b

Removal


1 Remove the engine and clutch, then separate the case halves (see Sections 5, 19 and 22).

2 Before removing either shaft, check the backlash of each set of gears. To do this, mount a dial indicator with the plunger of the indicator touching a tooth on one of the gears, then move the gear back and forth within its freeplay, holding its companion gear stationary. Check each set of gears, recording the measurements, and compare the results to this Chapter's Specifications. If the backlash between any pair of gears exceeds the limit, replace both gears (see Section 30).


3 The output shaft can simply be lifted out of the upper half of the case (see illustration). The main drive shaft (see illustration) is removed together with the clutch housing (see Section 25). If they are stuck, use a soft-face hammer and gently tap on the bearings on the ends of the shafts to free them.




29.3a The output shaft (arrow) can simply be lifted out. . .




29.3b . . .the main drive shaft is removed together with the clutch housing




29.5 At each end of the shafts there's a set pin for the small bearing and a set ring for the large bearing



29.6a The hole in the small bearing (arrow). . .



29.6b . . .must fit over the set pin (lower arrow) - the groove in the large bearing must fit over the set ring (upper arrow). . .



29.6c . . .if the bearings are correctly installed, they will fit into their saddles with no gap between the bearing and case

4 Refer to Section 30 for information pertaining to transmission shaft service and Section 31 for information pertaining to the shift drum and forks.

Installation

Refer to illustration 29.5, 29.6a, 29.6b and 29.6c

5 Check to make sure the set pins and rings are present in the upper case half, where the shaft bearings seat (**see illustration**).


6 Carefully lower each shaft into place. The holes in the needle bearing outer races must engage with the set pins, and the grooves in the ball bearing outer races must engage with the set rings (**see illustrations**).

7 The remainder of installation is the reverse of removal.


30 Transmission shafts - disassembly, inspection and reassembly

Note: When disassembling the transmission shafts, place the parts on a long rod or thread a wire through them to keep them in order and facing the proper direction.


1 Remove the shafts from the case (see Section 29).




30.2 Transmission gears and shafts - exploded view



30.4a Remove the bearing plug...



30.4b ...the outer bearing, inner bearing and spacer (arrow)...



30.4c ...slide off second gear...

Main drive shaft


Disassembly

Refer to illustrations 30.2 and 30.4a through 30.4j


2 All of the main drive shaft parts slide off the shaft except first gear, which is integral with the shaft, and the ball bearing, which is a press fit (see illustration).

3 Each freewheeling gear is secured with a toothed washer and snap-ring. Use snap-ring pliers to remove the snap-rings. **Caution:** There are two sizes of snap-ring, with only a small difference between them. Be sure to keep the snap rings in their original locations and to replace them with ones of the same size.


4 To disassemble the main drive shaft, refer to the accompanying photographs (see illustrations).




30.4d ...remove the snap-ring and toothed washer, then slide off sixth gear...



30.4e ...slide off the sixth gear bushing and toothed washer...



30.4f ...then remove the snap-ring...



30.4g ...slide the third-fourth gear cluster off the shaft. . .

Inspection

Refer to illustration 30.8


5 Wash all of the components in clean solvent and dry them off. Rotate the ball bearing on the shaft, feeling for tightness, rough spots and excessive looseness and listening for noises. If any of these conditions are found, replace the bearing. This will require the use of a hydraulic press or a bearing puller setup. If you don't have access to these tools, take the shaft and bearing to a Kawasaki dealer or other motorcycle repair shop and have them press the old bearing off the shaft and install the new one.

6 Measure the shift fork groove between third and fourth gears. If the groove width exceeds the figure listed in this Chapter's Specifications, replace the third/fourth gear assembly, and also check the third/fourth gear shift fork (see Section 31).


7 Check the gear teeth for cracking and other obvious damage. Check the sixth gear bushing and the surface in the inner diameter of sixth gear (and the fifth gear bushing, if equipped) for scoring or heat discoloration. If the gear or bushing is damaged, replace it.

8 Inspect the dogs and the dog holes in the gears for excessive wear (**see illustration**). Replace the paired gears as a set if necessary.


9 Check the needle bearing and outer race for wear or heat discoloration and replace them if necessary.




30.4h ...remove the snap-ring and toothed washer. . .




30.4i ...slide off fifth gear. . .



30.4j ...and the fifth gear bushing (if equipped)



30.8 If the gear dogs and dog holes (arrows) show signs of excessive wear, replace the gears as a set



30.10 The teeth of the toothed washers should not be aligned with the gap in the snap-ring; the gap in the snap-ring should be centered within a shaft groove

- | | |
|----------------------------|---------------------|
| 1) Teeth of toothed washer | 4) Gap in snap-ring |
| 2) Toothed washer | 5) Snap-ring |
| 3) Shaft groove | 6) Shaft |

Reassembly

Refer to illustrations 30.10, 30.11a through 30.11m and 30.12

10 During reassembly, always use new snap-rings and align the opening of the ring with a spline groove (see illustration).


11 To reassemble the main drive shaft, refer to the accompanying illustrations. Lubricate the components with engine oil before assembling them (see illustrations).

12 Check the assembled main drive shaft to make sure all parts are installed correctly (see illustration).


Output shaft**Disassembly**

Refer to illustrations 30.15a through 30.15p


13 All of the output shaft parts slide off the shaft except the ball bearing, which is a press fit. Fifth gear is secured to the shaft by three steel balls, installed in channels in the gear, which must be spun outward by centrifugal force. To do this, spin the shaft with one hand, and at the same time, lift the gear with the other hand. This may take several tries.




30.11a If the main drive shaft fifth gear has a separate bushing, install it so its oil hole lines up with the hole in the shaft




30.11b Install fifth gear with its dogs facing away from first gear; install a toothed washer and secure it with a snap-ring




30.11c Install the third-fourth gear cluster with third gear (the smaller gear) toward fifth gear




30.11d Install a snap-ring in the next shaft groove. . .



30.11e . . .and place a toothed washer against it



30.11f . . .Align the oil hole in the sixth gear bushing with the oil hole in the shaft, then slide the bushing down against the toothed washer




30.11g Install sixth gear with its flat side away from fourth gear and place a toothed washer next to it. . .




30.11h ...then secure the gear and washer with a snap-ring




30.11i Install second gear...



30.11j ...its spacer...




30.11k ...the bearing...



30.11l ...the bearing outer race...



30.11m ...and the plug




30.12 Main drive shaft components - assembled view

- 14 Each freewheeling gear is secured with a toothed washer and snap-ring. Use snap-ring pliers to remove the snap-rings.
 15 To disassemble the output shaft, refer to the accompanying illustrations.

Inspection

- 16 Refer to Steps 5 through 9 for the inspection procedures. They are the same, except that when checking the shift fork groove width you'll be checking it on fifth gear and sixth gear.




30.15a Pull off the bearing outer race...


Reassembly

Refer to illustrations 30.17a through 30.17p


- 17 Reassembly is basically the reverse of the disassembly procedure (**see illustrations**), but take note of the following points:
 a) Always use new snap-rings and align the opening of the ring with




30.15b ...the bearing and spacer (arrows)




30.15c Slide first gear off the shaft




30.15d The next gear on the output shaft is fifth gear. . .




30.15e ...it contains three steel balls (arrow) that will prevent the gear from being removed unless they're flung outward by centrifugal force. . .



30.15f . . .to disengage them from these slots (arrow) - to do so, spin the shaft rapidly with one hand while trying to slide the gear off with the other; it may take several tries, but the gear will come off with light hand pressure once the balls are spun outward




30.15g Remove the snap-ring and toothed washer, then slide third gear off the shaft. . .




30.15h . . .this will expose the bushing shared by third and fourth gears. . .




30.15i . . .slide off the bushing and fourth gear




30.15j Remove the toothed washer, then the snap-ring. . .




30.15k . . .and slide sixth gear off the shaft




30.15l Remove the snap-ring. . .




30.15m . . .and the toothed washer. . .




30.15n . . .and slide second gear off the shaft




30.15o Pull the oil seal off the bearing collar




30.15p If the bearing is worn or damaged, place it in a bearing splitter, press it off the shaft and press a new one on (or have the job done by a motorcycle dealer)




30.17a Stand the shaft on its ball bearing end. . .




30.17b . . .and install second gear (flat side toward bearing), then secure it with a toothed washer and snap-ring




30.17c Install sixth gear with its fork groove away from second gear




30.17d Install a snap-ring in the groove farthest down the shaft. . .



30.17e . . .place a toothed washer next to it. . .



30.17f . . .install fourth gear. . .




30.17g . . .and its bushing (align BOTH oil holes in the bushing with those in the shaft)

a spline groove (see illustration 30.10).


- b) When installing the bushing for third and fourth gear, align the oil hole in the bushing with the hole in the shaft.
- c) When installing fifth gear, don't use grease to hold the balls in place - to do so would impair the positive neutral finder mechanism. Just set the balls in their holes (the holes that they can't

pass through), keep the gear in a vertical position and carefully set it on the shaft (engine oil will help keep them in place). The spline grooves that contain the holes with the balls must be aligned with the slots in the shaft spline grooves.


- d) Lubricate the components with engine oil before assembling them.




30.17h Install third gear, ..




30.17i ...install a toothed washer next to it. . .




30.17j ...and secure them with a snap-ring; the slots in the shaft (arrow). . .




30.17k ...must align with the balls in fifth gear (arrow) when it's installed




30.17l Install first gear and its spacer. . .



30.17m ...the bearing. . .



30.17n ...and the bearing outer race - the assembled output shaft should look like this. . .



30.17o ...don't forget the O-ring, collar and seal on the other end of the shaft

31 Shift drum and forks - removal, inspection and installation

Removal

Refer to illustrations 31.2a, 31.2b, 31.2c, 31.3, 31.4, 31.5a and 31.5b


- 1 Remove the engine and separate the crankcase halves (see Sec-

tions 5 and 22).


- 2 Support the shift forks and pull the shift rod out (see illustrations).

- 3 Remove the shift drum bearing retaining bolts (see illustration).


- 4 Remove the cotter pin (split pin) and pull out the guide pin (see illustration).




30.17p Output shaft details




31.2a Shift drum and forks - exploded view




31.2b Note the positions of the shift forks on the rod, then slide out the rod and remove the forks




31.2c It's a good idea to reassemble the forks to the rod temporarily so you don't forget how they go




31.3 Remove the shift drum bearing retainer bolts (arrows)



31.4 Remove the cotter pin (split pin) and guide pin (arrows). . .



31.5a ...and slide the shift drum out of the fork and case



31.5b Reassemble the shift fork to the drum

5 Pull the shift drum out of the case far enough to remove the third/fourth shift fork (**see illustration**), then slide the shift drum out of the case (**see illustration**).

Inspection

Refer to illustration 31.7


6 Check the edges of the grooves in the drum for signs of excessive wear. Measure the widths of the grooves and compare your findings to this Chapter's Specifications. Check the cam and bearing on the end of the shift drum for wear and damage. If undesirable conditions are found, remove the endplate screw and replace the cam and bearing.

7 Check the shift forks for distortion and wear, especially at the fork ears. Measure the thickness of the fork ears and compare your findings with this Chapter's Specifications (**see illustration**). If they are discolored or severely worn they are probably bent. If damage or wear is evident, check the shift fork groove in the corresponding gear as well. Inspect the guide pins and the shaft bore for excessive wear and distortion and replace any defective parts with new ones.

8 Check the shift fork rod for evidence of wear, galling and other damage. Make sure the shift forks move smoothly on the rod. If the shafts are worn or bent, replace them with new ones.

Installation

- 9 Installation is the reverse of removal, noting the following points:
- Install the shift drum part-way into the case and install the third/fourth shift fork (the long end goes onto the drum first).
 - Be sure to use a new cotter pin (split pin) and install it correctly (**see illustration 31.4**).
 - Lubricate all parts with engine oil before installing them.
 - Apply a non-permanent locking agent to the threads of the bearing retainer bolts and tighten them securely.



31.7 Measure the thickness of the shift fork ears

4 Start the engine and allow it to run at a moderately fast idle until it reaches operating temperature. **Warning:** If the oil pressure indicator light doesn't go off, or it comes on while the engine is running, stop the engine immediately.

5 Check carefully for oil leaks and make sure the transmission and controls, especially the brakes, function properly before road testing the machine. Refer to Section 33 for the recommended break-in procedure.

6 Upon completion of the road test, and after the engine has cooled down completely, recheck the valve clearances (**see Chapter 1**).

32 Initial start-up after overhaul

Note: Make sure the cooling system is checked carefully (especially the coolant level) before starting and running the engine.

1 Make sure the engine oil level is correct, then remove the spark plugs from the engine. Place the engine STOP switch in the Off position and unplug the primary (low tension) wires from the coil.

2 Turn on the key switch and crank the engine over with the starter until the oil pressure indicator light goes off (which indicates that oil pressure exists). Reinstall the spark plugs, connect the wires and turn the switch to On. **Note:** If the oil pressure light won't go out, remove the oil filter (**see Chapter 1**). Hold the filter with the open end upright and pour oil into the center hole until the filter is full. Let the oil settle, then top it off again (you may need to do this twice). Reinstall the filter (a small amount of oil may leak out when you install it).

3 Make sure there is fuel in the tank, then turn the fuel tap to the On position and operate the choke.

33 Recommended break-in procedure

1 Any rebuilt engine needs time to break-in, even if parts have been installed in their original locations. For this reason, treat the machine gently for the first few miles to make sure oil has circulated throughout the engine and any new parts installed have started to seat.

2 Even greater care is necessary if the engine has been rebored or a new crankshaft has been installed. In the case of a rebore, the engine will have to be broken in as if the machine were new. This means greater use of the transmission and a restraining hand on the throttle until at least 500 miles (800 km) have been covered. There's no point in keeping to any set speed limit - the main idea is to keep from lugging (labouring) the engine and to gradually increase performance until the 500 mile (800 km) mark is reached. These recommendations can be lessened to an extent when only a new crankshaft is installed. Experience is the best guide, since it's easy to tell when an engine is running freely.

MANUAL VULCAN 500 XTREM

Chapter 3 Cooling system

Contents

Coolant level check	See Chapter 1	Cooling system draining, flushing and refilling	See Chapter 1
Coolant reservoir - removal and installation	3	General information	1
Coolant temperature gauge/light and sender unit - check and replacement	5	Radiator - removal and installation	7
Coolant tubes - removal and installation	9	Radiator cap - check	2
Cooling fan and thermostatic switch - check and replacement	4	Thermostat - removal, check and installation	6
Cooling system check	See Chapter 1	Water pump - check, removal, inspection and installation	8


Specifications


General

Coolant type and mixture ratio	See Chapter 1
Coolant capacity	See Chapter 1
Radiator cap pressure rating	1.0 to 1.2 Bars (14 to 18 psi)
Thermostat rating	
Opening temperature	69.5 to 72.5-degrees C (157 to 163-degrees F)
Valve travel (when fully open)	Not less than 8 mm (5/16-inch)

Torque specifications

Thermostatic fan switch-to-radiator	
Single-wire switch	7.4 Nm (65 in-lbs)
Two-wire switch	18 Nm (13 ft-lbs)
Coolant temperature sender unit-to-thermostat housing	
EN450 models	7.8 Nm (69 in-lbs)
EN500 models	7.4 Nm (65 in-lbs)





3.3 The reservoir tank is secured by two bolts (arrows)

1 General information

Refer to illustration 1.1

1 The models covered by this manual are equipped with a liquid cooling system which utilizes a water/antifreeze mixture to carry away excess heat produced during the combustion process (see illustration). The cylinders are surrounded by water jackets, through which the coolant is circulated by the water pump. The pump is mounted to the right side of the crankcase and is driven by the balancer shaft. The coolant passes up through a flexible hose and a coolant pipe, which distributes water around the cylinders. It flows through the water passages in the cylinder head, through a pair of tubes and hoses and into the thermostat housing. The hot coolant then flows down into the radiator (which is mounted on the frame downtubes to take advantage of maximum air flow), where it is cooled by the passing air, through another hose and back to the water pump, where the cycle is repeated. UK models include a coolant filter and temperature control valve.

2 An electric fan, mounted behind the radiator and automatically controlled by a thermostatic switch, provides a flow of cooling air through the radiator when the motorcycle is not moving. Under certain conditions, the fan may come on even after the engine is stopped, and the ignition switch is off, and may run for several minutes.

3 The coolant temperature sending unit, threaded into the thermostat housing, senses the temperature of the coolant and controls the coolant temperature gauge or light on the instrument cluster.

4 The entire system is sealed and pressurized. The pressure is controlled by a valve which is part of the radiator cap. By pressurizing the coolant, the boiling point is raised, which prevents premature boiling of the coolant. An overflow hose, connected between the radiator and reservoir tank, directs coolant to the tank when the radiator cap valve is opened by excessive pressure. The coolant is automatically siphoned back to the radiator as the engine cools.

5 Many cooling system inspection and service procedures are considered part of routine maintenance and are included in Chapter 1.

Warning: Do not allow antifreeze to come in contact with your skin or painted surfaces of the motorcycle. Rinse off spills immediately with plenty of water. Antifreeze is highly toxic if ingested. Never leave antifreeze lying around in an open container or in puddles on the floor; children and pets are attracted by its sweet smell and may drink it. Check with local authorities about disposing of used antifreeze. Many communities have collection centers which will see that antifreeze is disposed of safely.

Caution: Do not remove the pressure cap from the thermostat housing when the engine and radiator are hot. Scalding hot coolant and steam may be blown out under pressure, which could cause serious injury. To open the pressure cap, remove the left side cover. When the engine has cooled, place a thick rag, like a towel, over the radiator cap; slowly rotate the cap counterclockwise (anticlockwise) to the first stop. This procedure allows any residual pressure to escape. When the steam has

stopped escaping, press down on the cap while turning counterclockwise (anticlockwise) and remove it.

2 Radiator cap - check

If problems such as overheating and loss of coolant occur, check the entire system as described in Chapter 1. The radiator cap opening pressure should be checked by a dealer service department or service station equipped with the special tester required to do the job. If the cap is defective, replace it with a new one.

3 Coolant reservoir - removal and installation

Refer to illustration 3.3


- 1 Remove the right side cover (see Chapter 8).
- 2 Disconnect the coolant hoses from the reservoir and catch any escaped coolant in a container.
- 3 Unbolt the reservoir from the bracket and take it out (see illustration).
- 4 Installation is the reverse of the removal steps.

4 Cooling fan and thermostatic switch - check and replacement

Check


Refer to illustrations 4.1a and 4.1b

1 If the engine is overheating and the cooling fan isn't coming on, first check the fuses (see Chapter 9). If the fuse is blown, check the fan circuit for a short to ground/earth (see the Wiring diagrams at the end of this book). If the fuses are all good, unplug the fan electrical connec-



4.1a Cooling fan circuit (early 450 models)

- | | | | |
|---|--------------------|---|-------------|
| 1 | Cooling fan | 5 | 30 amp fuse |
| 2 | Fan relay | 6 | Battery |
| 3 | Two-pin connector | 7 | Fan switch |
| 4 | Four-pin connector | 8 | Radiator |



4.1b Cooling fan circuit (later 450 models - 500 model similar)

- | | |
|---------------------|--------------|
| 1 Cooling fan | 4 Battery |
| 2 Two-pin connector | 5 Fan switch |
| 3 30 amp fuse | 6 Radiator |

tor (see illustrations). Using two jumper wires, apply battery voltage to the terminals in the fan motor side of the electrical connector. If the fan doesn't work, replace the motor.


2 If the fan does come on, the problem lies in the thermostatic fan switch, the junction block, or the wiring that connects the components. Remove the jumper wires and reconnect the electrical connector to the fan.

If you're working on an early model (with a single-wire fan switch harness), unplug the electrical connector to the fan switch, attach a jumper wire to the harness side of the connector and ground/earth the other end of the jumper wire. If the fan comes on, the circuit to the motor is good, and the thermostatic fan switch is defective (see Step 10).

If you're working on a later model (with a double-wire fan switch connector), unplug the connector. Connect the terminals in the harness side of the connector together with a jumper wire. If the fan comes on, the circuit to the motor is good and the switch is defective.


3 If you're working on an early model and the fan still doesn't work, trace the fan relay (located under the seat on the electrical components plate - use its wire colors for identification) and place your hand on it. Repeatedly touch the jumper wire to ground/earth as detailed in step 2 - if you feel a clicking noise inside the relay, the relay is proved good and the fault must lie in the wiring from the relay to the fan motor. If no clicking is heard in the relay, the fault lies in the wiring from the thermostatic fan switch to the relay. If all wiring checks out OK, the fan relay is likely to be the problem and should be replaced.

4 If you're working on a later model and the fan still doesn't work, check the wiring back to the main fuse (later 450 models) or junction box fuse (500 models).



4.6 Remove the fan bracket-to-radiator bolts and separate the fan from the radiator

- A Bracket-to-radiator bolts
B Fan motor-to-bracket screws



4.7 The fan blade assembly is retained to the motor shaft by a single nut (arrow)

Replacement

Fan motor

Refer to illustrations 4.6 and 4.7

Warning: The engine must be completely cool before beginning this procedure.

5 Disconnect the cable from the negative terminal of the battery and remove the radiator (see Section 7).

6 Remove the three bolts securing the fan bracket to the radiator (see illustration). On early models, note which bolt secures the fan motor ground/earth wire. Separate the fan and bracket from the radiator.

7 Remove the nut that retains the blades to the fan motor shaft (see illustration) and remove the fan blade assembly from the motor.

8 Remove the screws that attach the fan motor to the bracket (see illustration 4.6) and detach the motor from the bracket.


9 Installation is the reverse of the removal steps.

Thermostatic fan switch


Refer to illustration 4.11

Warning: The engine must be completely cool before beginning this procedure.

10 If you're working on an early model with a single-wire fan switch harness, don't place Teflon tape or silicone sealer on the switch threads. If you're working on a late model with a two-wire fan switch harness, prepare the new switch by wrapping the new threads with



4.11 Disconnect the electrical connector and unscrew the fan switch from the radiator



6.4 Loosen the clamps (arrows) and disconnect the hoses from the thermostat housing

Teflon tape or by coating the threads with RTV sealant.

11 Unscrew the switch from the bottom of the radiator (see illustration).

12 Quickly install the new switch, tightening it to the torque listed in this Chapter's Specifications.

13 Connect the electrical connector to the switch. Check, and if necessary, add coolant to the system (see Chapter 1).

5 Coolant temperature gauge/light and sender unit - check and replacement

Refer to illustration 5.4

Check


1 These motorcycles may be equipped with a coolant temperature gauge or a warning light.

2 If the engine has been overheating but the coolant temperature gauge hasn't been indicating a hotter than normal condition (or the warning light hasn't been coming on), begin with a check of the coolant level (see Chapter 1). If it's low, add the recommended type of coolant and be sure to locate the source of the leak.

3 Remove the seat and the fuel tank (see Chapter 4).

4 Locate the coolant temperature sender unit, which is screwed into the thermostat housing (see illustration). Disconnect the electrical connector from the sender unit and turn the ignition key to the Run position (don't crank the engine over).

If you're working on a model with a temperature gauge, the gauge should read Cold.



5.4 The coolant temperature sender (arrow) is located at the bottom of the thermostat housing

If you're working on a model with a warning light, the light should stay out.

5 With the ignition key still in the Run position, connect one end of a jumper wire to the sender unit wire and connect the other end of the jumper wire to ground/earth. The needle on the temperature gauge should swing over to the Hot mark or the warning light should come on. **Caution:** If the motorcycle has a gauge, don't ground/earth the wire any longer than necessary or the gauge may be damaged.

6 If the gauge or light passes both of these tests but doesn't operate correctly under normal riding conditions, the temperature sender unit is defective and must be replaced.

7 If the gauge or light didn't respond to the tests properly, either the wire to the gauge is bad, the gauge itself is defective or the bulb is burned out.

Replacement

Sender unit

Warning: The engine must be completely cool before beginning this procedure.

8 Unscrew the sender unit from the thermostat housing and quickly install the new unit, tightening to the torque listed in this Chapter's Specifications.

9 Connect the electrical connector to the sender unit. Check, and if necessary, add coolant to the system (see Chapter 1).

Coolant temperature gauge or bulb

10 Refer to Chapter 9 for the coolant temperature gauge or bulb replacement procedure.

6 Thermostat - removal, check and installation

Refer to illustrations 6.4, 6.5, 6.6 and 6.7

Warning: The engine must be completely cool before beginning this procedure.

Removal


1 If the thermostat is functioning properly, the coolant temperature gauge should rise to the normal operating temperature quickly and then stay there, only rising above the normal position occasionally when the engine gets abnormally hot. If the engine does not reach normal operating temperature quickly, or if it overheats, the thermostat should be removed and checked, or replaced with a new one.

2 Refer to Chapter 1 and drain the cooling system.


3 Remove the seat and the fuel tank (see Chapter 4).

4 Disconnect the hoses from the thermostat housing (see illustration).

5 Loosen the clamp on the filler neck hose and unbolt the



6.5 Loosen the hose clamp (lower arrow); unbolt the housing from the frame (upper arrow), then disconnect the filler neck from the hose and take the housing out



6.7 Note the position of the relief hole (right arrow); the O-ring (left arrow) should be replaced whenever the thermostat is replaced

thermostat housing from the frame (see illustration). Work the filler neck free of the hose and remove the thermostat housing.

6 Remove the thermostat housing cover (see illustration).

7 Note the position of the relief hole, then lift out the thermostat (see illustration).

8 Check the cover O-ring and replace it if its condition is in doubt. It's a good idea to replace the O-ring as a matter of course.

Check

9 Remove any coolant deposits, then visually check the thermostat for corrosion, cracks and other damage. If it was open when it was removed, the thermostat is defective.

10 To check the thermostat operation, submerge it in a container of water along with a thermometer. The thermostat should be suspended so it does not touch the sides of the container. **Warning:** Antifreeze is poisonous. Do not use a cooking pan to test the thermostat.

11 Gradually heat the water in the container with a hot plate or stove and check the temperature when the thermostat first starts to open.

12 Compare the opening temperature to the values listed in this Chapter's Specifications.


13 Continue heating the water until the valve is fully open.

14 Measure how far the thermostat valve has opened and compare to the value listed in this Chapter's Specifications.


15 If these specifications are not met, or if the thermostat doesn't open while the water is heated, replace it with a new one.

Installation

16 Install the thermostat into the housing with the relief hole



6.6 Remove the thermostat housing bolts (B); the forward bolt (A) secures the filler neck retaining bracket



7.4 Remove the radiator mounting bolts (arrow) from each side of the radiator

positioned outward, away from the bike.

17 Install a new O-ring in the groove in the thermostat cover.

18 Place the cover on the housing and install the bolts, tightening them securely.

19 The remainder of installation is the reverse of the removal steps. Fill the cooling system with the recommended coolant (see Chapter 1).

7 Radiator - removal and installation

Refer to illustration 7.4

Warning: The engine must be completely cool before beginning this procedure.

1 Set the bike on its centerstand (if equipped). Remove the fan shroud (see illustration 1.1). Drain the cooling system (see Chapter 1).

2 Disconnect the fan motor connector. Disconnect the ground/earth wire for the fan switch (if equipped).

3 Loosen the radiator hose clamps. Work the hoses free from the fittings, taking care not to damage the fittings in the process.


4 Remove the radiator mounting bolts (see illustration). Take the radiator out.

5 Inspect the mounting bushings. Replace them if they're cracked or deteriorated.


6 Installation is the reverse of the removal steps, with the following additions:

a) Don't forget to connect the fan switch ground/earth wire (if equipped).


b) On all models, fill the cooling system with the recommended coolant (see Chapter 1).




8.4a Remove the cover bolts (arrows) . . .




8.4b . . . and lift the cover from the engine



8.5 If you can wiggle the impeller or pull it in-and-out, the pump is defective



8.11 Turn the impeller clockwise to remove it from the shaft



8.14 Pry the oil seal out of the housing

8 Water pump - check, removal, inspection and installation

Warning: The engine must be completely cool before beginning this procedure.

Check

Refer to illustrations 8.4a, 8.4b and 8.5

- 1 Visually check the area around the water pump for coolant leaks.


Try to determine if the leak is simply the result of a loose hose clamp or deteriorated hose.

- 2 Set the bike on its centerstand (if equipped).
- 3 Drain the engine coolant following the procedure in Chapter 1.
- 4 Loosen the hose clamp on the water pump cover fitting and remove the water pump cover bolts (**see illustration**). Pull the cover away from the engine, separating the coolant pipe from the cylinder block as you do so (**see illustration**).
- 5 Try to wiggle the pump impeller back-and-forth and in-and-out (**see illustration**). If you can feel movement, the water pump must be replaced.
- 6 Check the impeller blades for corrosion. If they are heavily corroded, replace the water pump and flush the system thoroughly (it would also be a good idea to check the internal condition of the radiator).
- 7 If the cause of the leak was just a defective cover gasket, remove the old gasket and install a new one.


Removal

Refer to illustrations 8.11 and 8.14

- 8 Drain the coolant and remove the cover (if it hasn't already been removed).
- 9 Drain the engine oil (see Chapter 1).
- 10 Shift the transmission into first gear and, with the rear tire in firm contact with the floor, press the brake pedal to keep the engine from turning.
- 11 Unscrew the impeller in a clockwise direction and take it off the shaft (**see illustration**).
- 12 Take the water pump housing and gasket off the engine.
- 13 Turn the water pump shaft clockwise to remove it (if necessary).
- 14 Remove the gasket from the water pump housing and pry out the oil seal (**see illustration**).




8.17 Install a new oil seal and gasket



8.18 Position the housing on the engine, install a new gasket and the dowels (arrows); turn the impeller counterclockwise (anticlockwise) to install it on the shaft



8.19 The lower right cover bolt (arrow) is the only one with a washer



9.3 Pull the tubes out of the cylinder head and remove the O-rings with a pointed tool

Inspection

- 15 Check all parts for wear and damage and replace as necessary.
- 16 If the mechanical seal needs to be replaced, have it pressed out and a new one pressed in by a Kawasaki dealer.

Installation

Refer to illustrations 8.17, 8.18 and 8.19

- 17 Install a new oil seal and gasket on the back side of the pump housing (see illustration).
- 18 Install the pump housing on the engine. Install the dowels (if they were removed), the shaft (if removed), a new cover gasket and the impeller (see illustration). Turn the impeller counterclockwise (anticlockwise) to tighten it.
- 19 Install the pump cover bolts. The lower right bolt is the only one with a washer (see illustration).

9 Coolant tubes - removal and installation

Refer to illustration 9.3

Warning: The engine must be completely cool for this procedure.

- 1 Remove the seat and fuel tank (see Chapter 4).
- 2 Remove the screws that secure the tubes to the engine. **Note:** These Phillips screws may be very tight. Be sure to use the correct size screwdriver bit. It's a good idea to replace them with Allen screws that can be removed more easily in the future.
- 3 Pull the tubes out of the engine (see illustration).
- 4 Remove the O-ring from each tube with a pointed tool. Lightly coat new O-rings with high-temperature grease and install them on the tubes.
- 5 If the tubes are being removed to provide access for other work, suspend them from the handlebars with their ends up.
- 6 Installation is the reverse of the removal steps.

Chapter 4 Fuel and exhaust systems

Contents

Air filter housing (in box) - removal and installation	11	Fuel tank - cleaning and repair	3
Air switching valve (US models) - operational test	13	Fuel tank - removal and installation	2
Carburetor overhaul - general information	5	Fuel tap - removal and installation	See Chapter 1
Carburetors - disassembly, cleaning and inspection	7	General information	1
Carburetors - reassembly and fuel level adjustment	8	Idle fuel/air mixture adjustment - general information	4
Carburetors - removal and installation	6	Idle speed - check and adjustment	See Chapter 1
Choke cable - removal, installation and adjustment	10	Throttle cables - removal, installation and adjustment	9
Exhaust system - removal and installation	12	Throttle operation/grip freeplay - check and adjustment	See Chapter 1
Fuel system - check and filter cleaning	See Chapter 1		

Specifications

General

Fuel tank capacity	See General Specifications
Fuel grade	Unleaded or low-lead (subject to local regulations), minimum octane rating 91 RON
Carburetor type	Keihin CVK34 (two)
Idle speed	See Chapter 1

Jet sizes

Main jet

EN450 models	
US and Canada except US high altitude	125
US high altitude	122
UK	112

EN500 models

US and Canada	
Left carburetor	112
Right carburetor	115
UK	105
	100

Main air jet

Jet needle

EN450 models

US	N31D
UK and Canada	N31E

EN500 models

US and Canada	N60Q
UK	
Left carburetor	N60T
Right carburetor	N60S

Pilot jet

Except US high altitude	35
US high altitude	32

Pilot air jet

Pilot screw setting

EN450 models

US	Preset
Except US	1-3/4 turns out

EN500 models

	2 turns out
--	-------------

Starter jet


45

Float height 17 mm (0.669 inch)


Fuel level

EN450 models	-0.5 mm (-0.02 inch)
EN500 models	0.5 +/- 1 mm (0.02 +/- 0.04 inch)


Air switching valve closing vacuum 430 to 490 mm Hg (17 to 19 inches Hg)



6.7 Loosen the clamps on the intake manifold tubes



6.14 Be careful not to place the end of the carburetor vent tube near the air intake (arrow); this will cause fuel starvation




7.2a Carburetor mounting details

- 7 Loosen the clamp screws on the intake manifolds (the rubber tubes that connect the carburetors to the engine) (see illustration).
- 8 Pull the carburetor assembly clear of the air box tubes. Raise the assembly up far enough to disconnect the throttle cables from the throttle pulley, then remove the carburetors from the machine.
- 9 After the carburetors have been removed, stuff clean rags into the intake manifold tubes to prevent the entry of dirt or other objects.

Installation

Refer to illustration 6.14

- 10 Position the assembly over the intake manifold tubes. Lightly lubricate the ends of the throttle cables with multi-purpose grease and attach them to the throttle pulley. Make sure the accelerator and decelerator cables are in their proper positions.
- 11 Tilt the front of the assembly down and insert the fronts of the




7.2b On the back side of the carburetor assembly, remove the screws (lower arrows) that secure the lower mounting bracket and detach the upper bracket (upper arrow)

carburetors into the intake manifold tubes. Push the assembly forward and tighten the clamps.


- 12 Make sure the ducts from the air filter box are seated properly, then slide the spring bands into position.
- 13 Connect the choke cable to the assembly and adjust it (see Section 10).
- 14 The remainder of installation is the reverse of the removal steps, with the following additions:
 - a) Be sure the carburetor vent tube isn't pinched. Don't place the end of the vent tube near the air intake (see illustration) or fuel starvation will occur, resulting in poor performance above 3,500 rpm and failure to rev past 5,000 rpm.
 - b) Adjust the throttle grip freeplay (see Chapter 1).
 - c) Check for fuel leaks.
 - d) Check and, if necessary, adjust the idle speed and carburetor synchronization (see Chapter 1).

7 Carburetors - disassembly, cleaning and inspection


Warning: Gasoline (petrol) is extremely flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where an appliance fueled by natural gas is present (such as a water heater or clothes dryer). If you spill any fuel on your skin, rinse it off immediately with soap and water. When you perform



7.2c On the front side of the carburetor assembly, remove two screws (arrows) from each carburetor and detach the bracket





7.3a Each carburetor top cover is secured by four screws (arrows); one screw also secures the choke cable bracket (if equipped)



7.3b Carburetor - exploded view

- 1 Screw
- 2 Spring washer
- 3 Washer
- 4 Top cover
- 5 Piston spring
- 6 Spring seat
- 7 Jet needle
- 8 Diaphragm/vacuum piston assembly
- 9 Needle jet
- 10 Needle jet holder/air bleed pipe
- 11 Main jet
- 12 Pilot jet
- 13 Float assembly
- 14 Pivot pin
- 15 Fuel inlet valve needle
- 16 Clip
- 17 O-ring
- 18 Float bowl
- 19 Drain screw
- 20 O-ring
- 21 Screw
- 22 Spring washer
- 23 Sealing plug (US models only)
- 24 Pilot screw
- 25 Spring
- 26 Washer
- 27 O-ring
- 28 Choke plunger
- 29 Spring
- 30 Nut
- 31 Cap



7.4 Remove the diaphragm/piston assembly from the carburetor body

any kind of work on the fuel system, wear safety glasses and have a fire extinguisher suitable for a class B type fire (flammable liquids) on hand.

Disassembly


Refer to illustrations 7.2a, 7.2b, 7.2c, 7.3a, 7.3b, 7.4, 7.5a, 7.5b, 7.7, 7.8, 7.9, 7.10, 7.11, 7.12a and 7.12b

1 Remove the carburetors from the machine as described in Section 6. Set the assembly on a clean working surface. **Note:** Unless the O-rings on the fuel and vent fittings between the carburetors are leaking, don't detach the carburetors from their mounting brackets. Also, work on one carburetor at a time to avoid getting parts mixed up.


2 If the carburetors must be separated from each other (during a complete overhaul, for example) remove the idle adjusting screw assembly (see illustration), being careful not to lose the spring and washer on the end of the screw. Disconnect the fuel hoses. Remove the choke lever spring and choke lever by removing the screw and plastic washers (two washers, one on each side of the lever) then remove the screws securing the upper and lower mounting plates to the carburetors (see illustrations). Mark the position of each carburetor and gently separate them, noting how the throttle linkage is connected, and being careful not to lose any springs or fuel and vent fittings that are present between the carburetors.

3 Remove the four screws securing the top cover to the carburetor body (see illustration). Lift the cover off and remove the piston spring (see illustration).


4 Peel the diaphragm away from its groove in the carburetor body, being careful not to tear it. Lift out the diaphragm/piston assembly (see illustration).




7.5a Remove the vacuum piston spring seat from the piston




7.5b Remove the needle from the piston




7.7 Push the float pivot pin out, then remove the float and valve needle assembly




7.8 Unscrew the main jet from the needle jet holder




7.9 Unscrew the needle jet holder/air bleed pipe



7.10 Working from the top of the carburetor, push the needle jet out with a wood or plastic tool




7.11 Unscrew the pilot jet



7.12a Location of the pilot screw (arrow)

- 5 Remove the piston spring seat and separate the needle from the piston (see illustrations).
- 6 Remove the four screws retaining the float bowl to the carburetor body, then detach the bowl (see illustration 7.3b).
- 7 Push the float pivot pin out and detach the float (and fuel inlet valve needle) from the carburetor body (see illustration). Detach the valve needle from the float.
- 8 Unscrew the main jet from the needle jet holder (see illustration).
- 9 Unscrew the needle jet holder/air bleed pipe (see illustration).
- 10 Using a wood or plastic tool, push the needle jet out of the carburetor body (see illustration).

- 11 Using a small, flat-bladed screwdriver, remove the pilot jet (see illustration).
- 12 The pilot (idle mixture) screw is located in the bottom of the carburetor body (see illustration). On US models, this screw is hidden behind a plug which will have to be removed if the screw is to be taken out. The usual way to do this is to drill a hole in the plug, then pry it out. To avoid the risk of drilling into the screw, you can also drill a very small hole above the plug, then insert a hooked tool into the hole and push the plug out (see illustration). On all models, turn the pilot screw in, counting the number of turns until it bottoms lightly. Record that number for use when installing the screw. Now remove the pilot screw



7.12b One way to remove the sealing plug is to drill a very small hole above it (left arrow), then reach into the hole with a hooked tool and push out the plug (right arrow)

along with its spring, washer and O-ring.

13 The choke plunger can be removed by unscrewing the nut that retains it to the carburetor body (see illustration 7.3b), if the carburetors have been separated from each other (see Step 2).

Cleaning

Caution: Use only a carburetor cleaning solution that is safe for use with plastic parts (be sure to read the label on the container).

14 Submerge the metal components in the carburetor cleaner for approximately thirty minutes (or longer, if the directions recommend it).
15 After the carburetor has soaked long enough for the cleaner to loosen and dissolve most of the varnish and other deposits, use a brush to remove the stubborn deposits. Rinse it again, then dry it with compressed air. Blow out all of the fuel and air passages in the main and upper body. **Caution:** Never clean the jets or passages with a piece of wire or a drill bit, as they will be enlarged, causing the fuel and air metering rates to be upset.

Inspection

Refer to illustrations 7.17 and 7.22

16 Check the operation of the choke plunger. If it doesn't move smoothly, replace it, along with the return spring.

17 Check the tapered portion of the pilot screw for wear or damage (see illustration). Replace the pilot screw if necessary.

18 Check the carburetor body, float bowl and top cover for cracks, distorted sealing surfaces and other damage. If any defects are found, replace the faulty component, although replacement of the entire carburetor will probably be necessary (check with your parts supplier for the availability of separate components).

19 Check the diaphragm for splits, holes and general deterioration. Holding it up to a light will help to reveal problems of this nature.

20 Insert the vacuum piston in the carburetor body and see that it moves up-and-down smoothly. Check the surface of the piston for wear. If it's worn excessively or doesn't move smoothly in the bore, replace the carburetor.


21 Check the jet needle for straightness by rolling it on a flat surface (such as a piece of glass). Replace it if it's bent or if the tip is worn.

22 Check the tip of the fuel inlet valve needle. If it has grooves or scratches in it, it must be replaced. Push in on the rod in the other end of the needle, then release it - if it doesn't spring back, replace the valve needle (see illustration).


23 Check the O-rings on the float bowl and the drain plug (in the float bowl). Replace them if they're damaged.

24 Operate the throttle shaft to make sure the throttle butterfly valve opens and closes smoothly. If it doesn't, replace the carburetor.

25 Check the floats for damage. This will usually be apparent by the



7.17 Check the tapered portion of the pilot screw (A) for wear or damage



7.22 Check the tip of the fuel inlet valve needle for grooves or scratches - also make sure the rod in the end of the needle pops back out quickly after it's pushed in

- 1 Rod
2 Valve needle

- 3 Groove in tip

presence of fuel inside one of the floats. If the floats are damaged, they must be replaced.

8 Carburetors - reassembly and fuel level adjustment

Caution: When installing the jets, be careful not to over-tighten them - they're made of soft material and can strip or shear easily.

Note: When reassembling the carburetors, be sure to use the new O-rings, gaskets and other parts supplied in the rebuild kit.

Reassembly


Refer to illustrations 8.4, 8.8, 8.10, 8.15 and 8.16

1 If the choke plunger was removed, install it in its bore, followed by its spring and nut. Tighten the nut securely and install the cap.

2 Install the pilot screw (if removed) along with its spring, washer and O-ring, turning it in until it seats lightly. Now, turn the screw out the number of turns that was previously recorded. If you're working on a US model, install a new metal plug in the hole over the screw. Apply a little bonding agent around the circumference of the plug after it has been seated.

3 Install the pilot jet, tightening it securely.


4 Turn the carburetor body upside-down and install the needle jet



8.4 Install the needle jet, small diameter end first



8.8 Make sure the bead of the vacuum diaphragm seats in its groove, and that the diaphragm isn't distorted



8.10 Float height adjustment details

- | | |
|--------------------------|----------------|
| 1 Carburetor body | 3 Float |
| 2 Float valve needle rod | 4 Float height |

into its hole, small diameter first (**see illustration**).

5 Install the needle jet holder/air bleed pipe, tightening it securely.


6 Install the main jet into the needle jet holder/air bleed pipe, tightening it securely.

7 Drop the jet needle down into its hole in the vacuum piston and install the spring seat over the needle. Make sure the spring seat doesn't cover the hole at the bottom of the vacuum piston - reposition it if necessary.

8 Install the diaphragm/vacuum piston assembly into the carburetor body. Lower the spring into the piston. Seat the bead of the diaphragm into the groove in the top of the carburetor body, making sure the diaphragm isn't distorted or kinked (**see illustration**). This isn't always an easy task. If the diaphragm seems too large in diameter and doesn't want to seat in the groove, place the top cover over the carburetor diaphragm, insert your finger into the throat of the carburetor and push up on the vacuum piston. Push down gently on the top cover - it should drop into place, indicating the diaphragm has seated in its groove.

9 Install the top cover, tightening the screws securely. If you're working on the right-hand carburetor, don't forget to install the choke cable bracket (if equipped) on the corner.

10 Invert the carburetor. Attach the fuel inlet valve needle to the float. Set the float into position in the carburetor, making sure the valve needle seats correctly. Install the float pivot pin. To check the float height,



8.15 Make sure to install a plastic washer on each side of the choke lever when installing the screws

hold the carburetor so the float hangs down, then tilt it back until the valve needle is just seated (the rod in the end of the valve shouldn't be compressed). Measure the distance from the carburetor body to the top of the float (**see illustration**) and compare your measurement to the float height listed in this Chapter's Specifications. If it isn't as specified, carefully bend the tang that contacts the valve needle up or down until the float height is correct.


11 Install the O-ring into the groove in the float bowl. Place the float bowl on the carburetor and install the screws, tightening them securely.

12 If the carburetors were separated, install new O-rings on the fuel and vent fittings. Lubricate the O-rings on the fittings with a light film of oil and install them into their respective holes, making sure they seat completely (**see illustration 7.2a**).


13 Position the coil springs between the carburetors, gently push the carburetors together, then make sure the throttle linkages are correctly engaged. Check the fuel and vent fittings to make sure they engage properly also.

14 Install the upper and lower mounting plates and install the screws, but don't tighten them completely yet. Set the carburetors on a sheet of glass, then align them with a straightedge placed along the edges of the bores. When the centerlines of the carburetors are both in horizontal and vertical alignment, tighten the mounting plate screws securely.

15 Install the choke lever, making sure it engages correctly with both choke plungers. Position a plastic washer on each side of the choke lever (**see illustration**) and install the screws, tightening them securely.



8.16 Install the throttle linkage springs



9.2 Loosen the locknuts (arrows) on the throttle cable adjusters, then turn the adjusters to create maximum slack in the cables

Install the lever return spring, then make sure the choke mechanism operates smoothly.

16 Install the throttle linkage springs (see illustration). Visually synchronize the throttle butterfly valves, turning the adjusting screws on the throttle linkage, if necessary, to equalize the clearance between the butterfly valve and throttle bore of each carburetor. Check to ensure the throttle operates smoothly.


Fuel level adjustment

Refer to illustration 8.18

Warning: Gasoline (petrol) is extremely flammable, so take extra precautions when you work on any part of the fuel system. Don't smoke or allow open flames or bare light bulbs near the work area, and don't work in a garage where an appliance fueled by natural gas is present (such as a water heater or clothes dryer). If you spill any fuel on your skin, rinse it off immediately with soap and water. When you perform any kind of work on the fuel system, wear safety glasses and have a fire extinguisher suitable for a class B type fire (flammable liquids) on hand.

17 Lightly clamp the carburetor assembly in the jaws of a vise. Make sure the vise jaws are lined with wood. Set an auxiliary fuel tank next to the vise, but at an elevation that is higher than the carburetors (resting on a box, for example). Connect a hose from the fuel tank to the fuel inlet fitting on the carburetor assembly.

18 Attach Kawasaki service tool no. 57001-1017 to the drain fitting on the bottom of one of the carburetor float bowls (both will be checked) (see illustration). This is a clear plastic tube graduated in



8.18 Checking the fuel level in a carburetor

- | | | | |
|---|------------------------------|---|--------------------------------|
| 1 | Kawasaki tool no. 57001-1017 | 3 | Bottom edge of carburetor body |
| 2 | Fuel hose | 4 | Zero line |
| | | 5 | Fuel level |

millimeters. An alternative is to use a length of clear plastic tubing and an accurate ruler. Hold the graduated tube (or the free end of the clear plastic tube) against the carburetor body, as shown in the accompanying illustration. If the Kawasaki tool is being used, raise the zero mark to a point several millimeters above the bottom edge of the carburetor main body. If a piece of clear plastic tubing is being used, make a mark on the tubing at a point several millimeters above the bottom edge of the carburetor main body.

19 Unscrew the drain screw at the bottom of the float bowl a couple of turns, then let fuel flow into the tube. Wait for the fuel level to stabilize, then slowly lower the tube until the zero mark is level with the bottom edge of the carburetor body. **Note:** Don't lower the zero mark below the bottom edge of the carburetor then bring it back up - the reading won't be accurate.

20 Measure the distance between the mark and top of the fuel level in the tube or gauge. This distance is the fuel level - write it down on a piece of paper, screw in the drain screw, close off the fuel supply, then move on to the next carburetor and check it the same way.

21 Compare your fuel level readings to the value listed in this Chapter's Specifications. If the fuel level in either carburetor is not correct, remove the float bowl and bend the tang up or down (see Step 10), as necessary, then recheck the fuel level. **Note:** Bending the tang up increases the float height and lowers the fuel level - bending it down decreases the float height and raises the fuel level.

22 After the fuel level for each carburetor has been adjusted, install the carburetor assembly (see Section 6).


9 Throttle cables - removal, installation and adjustment

Removal


Refer to illustrations 9.2, 9.3, 9.4, 9.5a, 9.5b and 9.6

1 Remove the fuel tank (see Section 2).


2 Loosen the locknuts on the accelerator cable and decelerator cable at the handlebar and screw the cable adjusters in to create as much slack as possible (see illustration).




9.3 Remove the cable retaining plate screw (arrow)



9.4 Remove the screws (arrows) and detach the cable/switch housing from the handlebar



9.5a Lift the inner decelerator cable out of its groove, align it with the slots in the throttle pulley and slip the cable end out of the pulley . . .




9.5b . . . then do the same thing with the accelerator cable


- 3 Remove the cable retaining plate screw at the handlebar (see illustration).
- 4 Remove the cable/switch housing screws and detach the housing from the handlebar (see illustration).
- 5 Detach the cables from the cable/switch housing, then lift them out of their grooves in the throttle pulley, align the cables with the pulley slots and slip the cable ends out of the throttle pulley (see illustrations).
- 6 Detach the decelerator and accelerator cables from the throttle pulley at the carburetor assembly (see illustration).
- 7 Remove the cables, noting how they are routed.

Installation

- 8 Route the cables into place. Make sure they don't interfere with any other components and aren't kinked or bent sharply.
- 9 Lubricate the end of the accelerator cable with multi-purpose grease and connect it to the throttle pulley at the carburetor. Pass the inner cable through the slot in the bracket, then seat the cable housing in the bracket.
- 10 Repeat the previous step to connect the decelerator cable.
- 11 Connect the cables to the throttle grip pulley and position them in their slots.
- 12 Install the cable/switch housing and tighten its screws securely.




9.6 At the carburetors, loosen the adjuster on each cable (arrows), then align the cables with the slots in the throttle pulley and slip them out



11.6a Air filter housing details (EN450 models)

1 US models

2 California models



11.6b Air filter housing details (EN500 models)

- 1 Air suction system (US models)
- 2 Air suction fitting plug (UK models)
- 3 Canister hose plug (all except California models)
- 4 Canister hose fitting (California models)
- 5 Front view of air filter housing

Adjustment

- 13 Follow the procedure outlined in Chapter 1, Throttle operation/grip freeplay - check and adjustment, to adjust the cables.
- 14 Turn the handlebars back and forth to make sure the cables don't cause the steering to bind.
- 15 Operate the throttle and check the cable action. The cables should move freely and the throttle pulley at the carburetor should move back and forth in response to both acceleration and deceleration. If the cables don't operate properly, find and fix the problem before you put the fuel tank back on.
- 16 Install the fuel tank.
- 17 Start the engine. With the engine idling, turn the handlebars all the way to left and right while listening for changes in idle speed. If idle speed increases as the handlebars turn, the cables are improperly routed. This is dangerous. Find the problem and fix it before riding the bike.

10 Choke cable (EN450 models) - removal, installation and adjustment

Removal

- 1 Remove the seat and fuel tank (see Section 2).
- 2 Pull the choke cable casing away from its mounting bracket at the carburetor and pass the inner cable through the opening in the bracket. Detach the cable end from the choke lever by the right-hand carburetor.
- 3 Remove the screws securing the choke cable/switch housing halves to the left handlebar. Pull the front half of the housing off and separate the choke cable from the lever.
- 4 Remove the cable, noting how it's routed.

Installation

- 5 Route the cable into position. Connect the upper end of the cable to the choke lever. Place the housing up against the handlebar, making sure the housing halves align correctly with each other and the handlebar. Install the screws, tightening them securely.
- 6 Connect the lower end of the cable to the choke lever. Pull back on the cable casing and connect it to the bracket on the right-hand carburetor.


Adjustment

- 7 Refer to Chapter 1 for cable adjustment procedures.
- 8 Install the fuel tank and all of the other components that were previously removed.


11 Air filter housing (air box) - removal and installation

Refer to illustrations 11.6a, 11.6b, 11.7a and 11.7b


- 1 Remove the seat and fuel tank.
- 2 Remove the side covers (see Chapter 8 if necessary).
- 3 Remove the junction box bracket, where applicable (see Chapter 9).
- 4 Disconnect the cables from the battery (negative cable first), then remove the battery.
- 5 Remove the carburetors (see Section 6).
- 6 If you're working on a US model, disconnect the large air suction hose from the front of the air filter housing (see illustrations). If you're working on a California model, disconnect the small canister hose from the front of the housing.
- 7 If you're working on an EN500 model, disconnect the drain hose from the bottom of the housing and unbolt the frame tabs from the top




11.7a Squeeze the clamp (arrow) and slide it back along the hose, then disconnect the hose



11.7b Unbolt the frame tabs (arrow) from the top of the housing (left side shown)



12.4 Remove the nuts and holders from the cylinder head studs



12.5 Loosen the crossover clamp

of the housing (see illustrations). At the rear of the housing, unbolt the rear fender front section bracket from the housing.

8 If you're working on an EN450 model, remove the mounting bolts from the top of the housing (see illustration 11.6a).

9 Tilt the housing forward and rotate it to the right as needed to clear the frame, then take it out.

10 Installation is the reverse of removal.


12 Exhaust system - removal and installation

Refer to illustrations 12.4, 12.5, 12.6, 12.7, 12.9a, 12.9b and 12.10


- 1 Remove the side covers (see Chapter 8).
- 2 Drain the coolant (see Chapter 1).
- 3 Remove the radiator (see Chapter 3).
- 4 Remove the nuts that secure the exhaust pipe holders to the cylinder head, then remove the holders (see illustration).
- 5 Loosen the clamp that secures the crossover pipe (see illustration).
- 6 If you plan to separate the mufflers from the pipes, loosen the clamps (see illustration).




12.6 Loosen the muffler clamps if you plan to separate the mufflers from the pipes



12.7 Remove the muffer mounting bolts at the rear footpegs (arrow)




12.9a The gaskets at the cylinder head should be replaced whenever the pipes are removed



12.9b The crossover clamp gasket should be replaced if it's damaged or deteriorated



12.10 The holder halves are notched so they form a flush surface when assembled correctly



13.3 Air switching valve test setup


- | | | | |
|---|---|---|--|
| A | Air hose | D | Vacuum gauge set (part of Kawasaki special tool 57001-1198) or standard vacuum gauge |
| B | Vacuum line | | |
| C | Syringe (part of Kawasaki special tool) or hand vacuum pump | | |

- 7 Remove the muffer mounting bolts at the footpeg brackets (see illustration).
- 8 Pull the exhaust system forward, separate the right side pipe from the left side pipe and remove the system from the machine.
- 9 Remove the gaskets from the cylinder head and crossover pipe (see illustrations).
- 10 Installation is the reverse of removal, with the following additions:
 - a) Install new gaskets at the cylinder head. Replace the crossover clamp gasket if it's damaged.
 - b) Be sure the holders overlap correctly (see illustration).

13 Air switching valve (US models) - operational test

Refer to illustration 13.3

- 1 The air switching valve is part of the air suction system used on US models. Routine checking procedures are described in Chapter 1. If you suspect the valve has failed (for example, if the bike runs poorly at low speed or backfires during deceleration), test it as follows:
- 2 Remove the valve and its hoses from the motorcycle (see Chapter 1).
- 3 Connect a vacuum gauge to one end of the vacuum line that branches out from the T-fitting. Connect a vacuum pump to the other end (see illustration).
- 4 Try to blow air into the large air hose. It should flow easily when there's no vacuum applied to the vacuum line.
- 5 Operate the vacuum pump and raise vacuum to the value listed in this Chapter's Specifications. The valve should close, making it impossible to blow air into the hose.
- 6 If the valve doesn't perform as described, replace it.



Chapter 5 Ignition system

Contents

General information	1	Ignition (main) switch and key lock cylinder - check, removal and installation	See Chapter 9
IC igniter - removal, check and installation	5	Pickup coils - check, removal and installation	4
Ignition coils - check, removal and installation	3	Spark plug replacement	See Chapter 1
Ignition stop switch - check, removal and installation	See Chapter 9		
Ignition system - check	2		

Specifications

Ignition coil

Primary resistance	
EN450 models	2.1 to 3.2 ohms
EN500 models	2.2 to 3.5 ohms
Secondary resistance	10,000 to 16,000 ohms
Arcing distance	7 mm (1/4 in) or more

Pickup coil resistance..... 400 to 490 ohms

Ignition timing..... Not adjustable



2.3 With the wire attached, ground (earth) a spark plug to the engine and operate the starter - bright blue sparks should be visible

1 General information

This motorcycle is equipped with a battery operated, fully transistorized, breakerless ignition system. The system consists of the following components:

- Pickup coils
- IC igniter unit
- Battery and fuse
- Ignition coils
- Spark plugs
- Stop and main (key) switches
- Primary and secondary circuit wiring

The transistorized ignition system functions on the same principle as a breaker point DC ignition system with the pickup unit and igniter performing the tasks previously associated with the breaker points and mechanical advance system. As a result, adjustment and maintenance of ignition components is eliminated (with the exception of spark plug replacement).

Because of their nature, the individual ignition system components can be checked but not repaired. If ignition system troubles occur, and the faulty component can be isolated, the only cure for the problem is to replace the part with a new one. Keep in mind that most electrical parts, once purchased, can't be returned. To avoid unnecessary expense, make very sure the faulty component has been positively identified before buying a replacement part.

2 Ignition system - check

Refer to illustrations 2.3, 2.5 and 2.13

Warning: Because of the very high voltage generated by the ignition system, extreme care should be taken to avoid electrical shock when these checks are performed.

1 If the ignition system is the suspected cause of poor engine performance or failure to start, a number of checks can be made to isolate the problem.

2 Make sure the ignition stop switch is in the Run or On position.

Engine will not start

3 Disconnect one of the spark plug wires, connect the wire to a spare spark plug and lay the plug on the engine with the threads contacting the engine. If it's necessary to hold the spark plug, use an insulated tool (see illustration). Crank the engine over and make sure a well-defined, blue spark occurs between the spark plug electrodes.

Warning: DO NOT remove one of the spark plugs from the engine to perform this check - atomized fuel being pumped out of the open spark plug hole could ignite, causing severe injury!



2.5 Unscrew the spark plug caps from the plug wires and measure their resistance with an ohmmeter

4 If no spark occurs, the following checks should be made:

5 Unscrew a spark plug cap from a plug wire and check the cap resistance with an ohmmeter (see illustration). If the resistance is infinite, replace it with a new one. Repeat this check on the other plug cap.

6 Make sure all electrical connectors are clean and tight. Refer to the wiring diagrams at the end of this book and check all wires for shorts, opens and correct installation.

7 Check the battery voltage with a voltmeter and the specific gravity with a hydrometer (see Chapter 1). If the voltage is less than 12-volts or if the specific gravity is low, recharge the battery.

8 Check the ignition fuse and the fuse connections. If the fuse is blown, replace it with a new one; if the connections are loose or corroded, clean or repair them.

9 Refer to Section 3 and check the ignition coil primary and secondary resistance.

10 Refer to Section 4 and check the pickup coil resistance.

11 If the preceding checks produce positive results but there is still no spark at the plug, have the IC igniter checked by a Kawasaki dealer service department or other repair shop equipped with the special tester required.

Engine starts but misfires

12 If the engine starts but misfires, make the following checks before deciding that the ignition system is at fault.

13 The ignition system must be able to produce a spark across a seven millimeter (1/4-inch) gap (minimum). A simple test fixture (see illustration) can be constructed to make sure the minimum spark gap can be jumped. Make sure the fixture electrodes are positioned seven millimeters apart.

14 Connect one of the spark plug wires to the protruding test fixture electrode, then attach the fixture's alligator clip to a good engine ground/earth.


15 Crank the engine over (it may start and run on the remaining cylinder) and see if well-defined, blue sparks occur between the test fixture electrodes. If the minimum spark gap test is positive, the ignition coil for that cylinder is functioning properly. Repeat the check on the spark plug wire that is connected to the other coil. If the spark will not jump the gap during either test, or if it is weak (orange colored), refer to Steps 5 through 11 of this Section and perform the component checks described.

3 Ignition coils - check, removal and installation


Check

Refer to illustration 3.4

1 In order to determine conclusively that the ignition coils are defective, they should be tested by an authorized Kawasaki dealer service



2.13 A simple spark gap testing fixture can be made from a block of wood, a large alligator clip, two nails, a screw and a piece of wire



3.10 The ignition coils are mounted to the frame

department which is equipped with the special electrical tester required for this check.

2 However, the coils can be checked visually (for cracks and other damage) and the primary and secondary coil resistances can be measured with an ohmmeter. If the coils are undamaged, and if the resistances are as specified, they are probably capable of proper operation.

3 To check the coils for physical damage, they must be removed (see Step 9). To check the resistances, simply remove the fuel tank (see Chapter 4), unplug the primary circuit electrical connectors from the coil(s) and remove the spark plug wire from the plug that is connected to the coil being checked. Mark the locations of all wires before disconnecting them.


4 To check the coil primary resistance, attach one ohmmeter lead to one of the primary terminals and the other ohmmeter lead to the other primary terminal (see illustration).

5 Place the ohmmeter selector switch in the Rx1 position and compare the measured resistance to the value listed in this Chapter's Specifications.

6 If the coil primary resistance is as specified, check the coil secondary resistance by disconnecting the meter leads from the primary terminals and attaching one of them to the spark plug wire terminal and the other to either of the primary terminals (see illustration 3.4).


7 Place the ohmmeter selector switch in the Rx100 position and compare the measured resistance to the values listed in this Chapter's Specifications.

8 If the resistances are not as specified, unscrew the spark plug wire retainers from the coil, detach the wires and check the resistance



3.4 Ignition coil test

- 1 Measure primary winding resistance
- 2 Measure secondary winding resistance
- 3 Ignition coil



4.1 The pickup coil wiring harness leaves the alternator cover at this grommet (arrow); follow the harness to the connector (apply silicone sealer to the grommet whenever it's removed and reinstalled)

again. If it is now within specifications, one or both of the wires are bad. If it's still not as specified, the coil is probably defective and should be replaced with a new one.

Removal and installation

Refer to illustration 3.10

9 To remove the coils, refer to Chapter 4 and remove the fuel tank, then disconnect the spark plug wires from the plugs. After labeling them with tape to aid in reinstallation, unplug the coil primary circuit electrical connectors.

10 Support the coil with one hand and remove the coil mounting screws (see illustration), then remove the coil.


11 Installation is the reverse of removal. If a new coil is being installed, disconnect the spark plug wire terminal from the coil, disconnect the wire and transfer it to the new coil. Make sure the primary circuit electrical connectors are attached to the proper terminals.

4 Pickup coils - check, removal and installation

Refer to illustration 4.1

Check

1 Follow the pickup coil wiring harness from the point where it leaves the alternator cover to the electrical connector, then disconnect the connector for the pickup coils (see illustration).



4.6 To remove the pickup coils (upper arrows), remove the mounting screws; also remove the screws that secure the harness clip (lower arrow)

2 Probe each pair of terminals in the pickup coil connector with an ohmmeter (the black and yellow wire terminals, then the blue and black/white wire terminals) and compare the resistance reading with the value listed in this Chapter's Specifications.

3 Set the ohmmeter on the highest resistance range. Measure the resistance between a good ground/earth and each terminal in the electrical connector. The meter should read infinity.

4 If the pickup coils fail either of the above tests, they must be replaced.

Removal


Refer to illustration 4.6

5 Remove the alternator cover (see Chapter 9).

6 Unscrew the pickup coil mounting screws and remove the pickup coils (**see illustration**). Remove the wiring harness retainer, slip the grommet out of its slot and remove the pickup coils together with their wiring harness.

Installation

7 Position the pickup coils in the alternator cover and install the screws, tightening them securely. Apply a small amount of silicone sealant to the grommet on the wiring harness and seat the grommet



5.3 The IC igniter is mounted behind the battery, on the fender front portion (EN500 models)

securely in the notch in the alternator cover (**see illustration 4.1**).

8 Install the alternator cover and connect the electrical connector.

5 IC igniter - removal, check and installation

Refer to illustration 5.2

Removal

1 Remove the seat.

2 On EN450 models, disconnect its electrical connector and remove the two bolts which retain the igniter to the battery holder bracket. Lift out the igniter.


3 On EN500 models, disconnect the electrical connector and slip the igniter off its mounting tabs (**see illustration**). Take the igniter out.

Check

4 A special tester is required to accurately measure the resistance values across the various terminals of the IC igniter. Take the unit to a Kawasaki dealer service department or other repair shop equipped with this tester.

Installation

5 Installation is the reverse of the removal steps.



Chapter 6

Suspension, steering and final drive

Contents

Drive belt and pulleys - removal, inspection and installation.....	10	Rear wheel coupling/rubber damper - check and replacement	11
Drive belt and pulleys	See Chapter 1	Steering head bearings - check and replacement	See Chapter 1
Fork oil - replacement	See Chapter 1	Steering head bearings - replacement	5
Forks - disassembly, inspection and reassembly	4	Suspension - check.....	See Chapter 1
Forks - removal and installation	3	Suspension adjustments.....	12
General information.....	1	Swingarm bearings - check	7
Handlebars - removal and installation.....	2	Swingarm bearings - replacement	9
Rear shock absorbers - removal and installation.....	6	Swingarm - removal and installation.....	8

Specifications

Front suspension

Fork oil type, amount and level	See Chapter 1
Fork spring length	
EN450 models	
Standard	442 mm (17.4 inches)
Minimum	433 mm (17.04 inches)
EN500 models	
Standard	372.9 mm (14.68 inches)
Minimum	365 mm (14.37 inches)
Front fork air pressure (early EN450 models only)	
Standard.....	0 psi (0 Bars)
Maximum.....	36 psi (2.51 Bars)

Rear spring preload standard setting

EN450 models	1
EN500 models	2

Pulleys

Tooth height


EN450 engine pulley	6.60 to 6.73 mm (0.260 to 0.265 inch)
Standard	6.3 mm (0.248 inch)
Minimum	Not specified
EN450 rear pulley	
EN500 engine pulley	6.42 to 6.49 mm (0.253 to 0.255 inch)
Standard	6.1 mm (0.240 inch)
Minimum	
EN500 rear pulley	6.62 to 6.70 mm (0.260 to 0.264 inch)
Standard	6.3 mm (0.248 inch)
Minimum	
Rear pulley diameter	300.23 to 300.28 mm (11.820 to 11.822 inches)
Standard	299.63 mm (11.796 inches)
Minimum	

Torque specifications

Handlebar bracket bolts	19 Nm (13.5 ft-lbs)
EN450 models	23 Nm (16.5 ft-lbs)
EN500 models	20 Nm (14.5 ft-lbs)
Damper rod bolt	42 Nm (31 ft-lbs)
Steering stem bolt	
Steering stem adjusting nut	39 Nm (29 ft-lbs)
Initial torque	Hand tight (approximately 4.9 Nm/43 in-lbs)
Final torque	20 Nm (14.5 ft-lbs)
Fork upper triple clamp bolts	25 Nm (18 ft-lbs)
Fork lower triple clamp bolts	
Rear shock absorber mounting bolts/nuts	
EN450 models	29 Nm (22 ft-lbs)
EN500 models	25 Nm (18 ft-lbs)
Swingarm pivot shaft nut	88 Nm (65 ft-lbs)
Rear pulley-to-wheel coupling nuts	69 Nm (51 ft-lbs)
Engine pulley holding plate bolts	9.8 Nm (87 in-lbs)



2.1a Unbolt the upper bracket . . .



2.1b . . . and lift the handlebar off

1 General information

The front forks on these models are of the conventional coil spring, hydraulically-damped telescopic type. Early EN450 forks include an air pressure adjustment mechanism.


The rear suspension consists of two coil spring/shock absorbers and a square-section swingarm.

The final drive uses a cogged belt. A rubber damper is installed between the rear wheel coupling and the wheel.


2 Handlebars - removal and installation

Refer to illustrations 2.1a and 2.1b


1 These motorcycles use a one-piece handlebar, secured to the upper triple clamp by an upper and lower bracket. If the handlebars must be removed for access to other components, such as the forks or the steering head, simply remove the bolts and lift the handlebar(s) off (see illustrations). It's not necessary to disconnect the cables, wires or hoses, but it is a good idea to support the assembly with a piece of




3.7 The front forks are held in the upper triple clamp by pinch bolts (arrow)



3.9 When installed, the top of the inner fork tube should be flush with the upper triple clamp (arrow) (fork cap removed for clarity)



4.4a This is the Kawasaki tool that keeps the damper rod from turning - the corners of the tapered section bite into the round hole in the damper rod to hold it



4.4b Hold the damper rod and remove the screw with an Allen wrench

wire or rope, to avoid unnecessary strain on the cables, wires and (on the right side) the brake hose.

- 2 Check the handlebar for cracks and distortion and replace it if any undesirable conditions are found.
- 3 Installation is the reverse of the removal steps. Tighten the bolts to the torque listed in this Chapter's Specifications.

3 Forks - removal and installation

Refer to illustration 3.7

Removal

- 1 Set the bike on its centerstand (if equipped).
- 2 Remove the fuel tank (see Chapter 4).
- 3 If you're removing the left fork leg, remove the brake caliper and hang it from the bike with a piece of rope or wire (see Chapter 7).
- 4 Remove the wheel (see Chapter 7).
- 5 Remove the front fender (see Chapter 8).
- 6 Remove any wiring harness clamps or straps from the fork tubes.
- 7 Loosen the fork upper triple clamp bolts (**see illustration**). Loosen the lower triple clamp bolts, then twist the fork tubes and slide them downward and out of the triple clamps.

Installation

Refer to illustration 3.9

- 8 Slide each fork leg into the lower triple clamp.
- 9 Slide the fork legs up, installing the tops of the tubes into the

upper triple clamp. The end of each tube should be flush with the top surface of the upper triple clamp (**see illustration**).


- 10 The remainder of installation is the reverse of the removal procedure. Be sure to tighten the triple clamp bolts to the torque listed in this Chapter's Specifications. Tighten the caliper mounting bolts to the torque listed in the Chapter 7 Specifications.
- 11 Pump the front brake lever several times to bring the pads into contact with the discs.

4 Forks - disassembly, inspection and reassembly

Disassembly

Refer to illustrations 4.4a, 4.4b, 4.4c, 4.4d, 4.5a, 4.5b, 4.6, 4.7 and 4.10

- 1 Remove the forks following the procedure in Section 3. Work on one fork leg at a time to avoid mixing up the parts.
- 2 Remove the retaining ring, top plug, spacer, spring seat and fork spring (see Chapter 1).
- 3 Invert the fork assembly over a container and allow the oil to drain out.
- 4 Prevent the damper rod from turning using a holding handle (Kawasaki tool no. 57001-183) and adapter (Kawasaki tool no. 57001-1057) or equivalents (**see illustration**). Unscrew the Allen bolt at the bottom of the outer tube and retrieve the copper washer (**see illustration**). **Note:** If you don't have access to these special tools, you can fabricate your own using a bolt with a head that fits inside the damper rod, two nuts, a socket (to fit on the nuts), a long extension and



4.4c To make a damper rod holder, thread two nuts onto a bolt with a head that will wedge inside the damper tube and tighten the nuts against each other . . .



4.4d . . . then install the nut-end into a socket (connected to a long extension) and tape it into place

a ratchet. Thread the two nuts onto the bolt and tighten them against each other (see illustration). Insert the assembly into the socket and tape it into place (see illustration). Now, insert the tool into the fork tube and engage the bolt head (or the special Kawasaki tool) into the round hole in the damper rod.

5 Pull out the damper rod and its spring (see illustrations). Don't remove the Teflon ring from the damper rod; the damper rod is sold as an assembly, so if the ring is worn, you'll need a new damper rod.

6 Pry the dust seal from the outer tube (see illustration).

7 Pry the retaining ring from its groove in the outer tube (see illustration).

8 Hold the outer tube and yank the inner tube upward, repeatedly (like a slide hammer), until the seal, washer and outer tube guide bushing pop loose.


9 Slide the seal, washer and outer tube guide bushing from the inner tube (see illustrations 4.5a and 4.5b).

10 Invert the outer tube and remove the damper rod base (see illustration).

Inspection

11 Clean all parts in solvent and blow them dry with compressed air, if available. Check the inner and outer fork tubes, the guide bushings and the damper rod for score marks, scratches, flaking of the chrome and excessive or abnormal wear. Look for dents in the tubes and replace them if any are found. Check the fork seal seat for nicks, gouges and scratches. If damage is evident, leaks will occur around the seal-to-outer tube junction. Replace worn or defective parts with new ones.

12 Have the fork inner tube checked for runout at a dealer service




4.5a Front forks (EN450 models) - exploded view

1	Fork trim cap	15	Damper rod
2	Retaining ring	16	Teflon ring
3	Air valve (early models only)	17	Damper rod spring
4	Fork cap plug	18	Damper rod base
5	O-ring	19	Dust seal
6	Upper triple clamp	20	Retaining ring
7	Steering stem/lower triple clamp	21	Oil seal
8	Fork assembly	22	Washer
9	Spacer	23	Bushing
10	Spring seat	24	Outer fork tube
11	Fork spring	25	Copper washer
12	Inner fork tube	26	Damper rod bolt
13	Bushing	27	Gasket
14	Steering stem trim piece	28	Drain bolt


department or other repair shop. **Warning:** If it is bent, it should not be straightened; replace it with a new one.

13 Measure the overall length of the long spring and check it for cracks and other damage. Compare the length to the minimum length listed in this Chapter's Specifications. If it's defective or sagged, replace both fork springs with new ones. Never replace only one spring.




4.5b Front forks (EN500 models) - exploded view


- 1 Fork trim cap
- 2 Retaining ring
- 3 Fork cap plug
- 4 O-ring
- 5 Upper triple clamp
- 6 Steering stem trim
- 7 Steering stem/lower triple clamp
- 8 Inner fork tube
- 9 Bushing
- 10 Dust seal
- 11 Retaining ring
- 12 Oil seal
- 13 Washer
- 14 Bushing
- 15 Outer fork tube
- 16 Gasket
- 17 Drain bolt
- 18 Damper rod bolt
- 19 Copper washer
- 20 Damper rod base
- 21 Damper rod spring
- 22 Teflon ring
- 23 Damper rod
- 24 Fork spring
- 25 Spring seat
- 26 Spacer
- 27 Outer fork tube




4.6 Pry the dust seal out of the outer tube with a small screwdriver




4.7 Pry the retaining ring out of its groove




4.10 Dump the damper rod base (arrow) out of the fork tube and put it back on the damper rod




4.17a Install the assembled inner fork tube into the outer fork tube. . .



4.17b . . . place a new washer on the damper rod bolt . . .



4.17c . . . and thread it into the damper rod (arrow)



Reassembly

Refer to illustrations 4.17a, 4.17b, 4.17c, 4.18a, 4.18b, 4.21 and 4.25

14 If it's necessary to replace the inner guide bushing (the one that won't come off that's on the bottom of the inner tube), pry it apart at the slit and slide it off. Make sure the new one seats properly.

15 Place the rebound spring over the damper rod and slide the rod assembly into the inner fork tube until it protrudes from the lower end of the tube.

16 If you haven't already done so, install the damper rod base onto the end of the damper rod (**see illustration 4.10**).

17 Insert the inner tube/damper rod assembly into the outer tube (**see illustration**) until the Allen-head bolt (with copper washer) can be threaded into the damper rod from the lower end of the outer tube (**see illustrations**). **Note:** Apply a non-permanent thread locking compound to the threads of the bolt. Keep the two tubes fairly horizontal so the damper rod base doesn't fall off. Using the tool described in Step 4, hold the damper rod and tighten the Allen bolt to the torque listed in this Chapter's Specifications.


18 Slide the outer guide bushing down the inner tube. On EN450 models, the slit in the bushing must point to the left or right - not to the front or rear. Using a special bushing driver (Kawasaki tool no. 57001-1219) or equivalent and a used guide bushing placed on top of the guide bushing being installed, drive the bushing into place until it is fully seated (**see illustration**). If you don't have access to one of these tools, it is highly recommended that you take the assembly to a Kawasaki dealer service department or other motorcycle repair shop to




4.18b If you don't have the proper tool, a section of pipe can be used the same way the special tool would be used - as a slide hammer (be sure to tape the ends of the pipe so it doesn't scratch the fork tube)




4.21 Install the retaining ring and make sure it seats in its groove



4.25 On EN500 models, the end of the spring with widely spaced coils (arrow) goes downward



5.4 Remove the bolts (arrows) and detach the cover from the front of the lower triple clamp (EN500 model shown)



5.8a Remove the steering stem bolt . . .

have this done. It is possible, however, to drive the bushing into place using a section of tubing and an old guide bushing (see illustration). Wrap tape around the ends of the tubing to prevent it from scratching the fork tube.

19 Slide the washer down the inner tube, into position over the guide bushing.

20 Lubricate the lips and the outer diameter of the fork seal with the recommended fork oil (see Chapter 1) and slide it down the inner tube, with the lips facing down. Drive the seal into place with a special seal driver (Kawasaki tool no. 57001-1091). If you don't have access to one of these, it is recommended that you take the assembly to a Kawasaki dealer service department or other motorcycle repair shop to have the seal driven in. If you are very careful, the seal can be driven in with a hammer and a drift punch. Work around the circumference of the seal, tapping gently on the outer edge of the seal until it's seated. Be careful - if you distort the seal, you'll have to disassemble the fork again and end up taking it to a dealer anyway!

21 Install the retaining ring, making sure the ring is completely seated in its groove (see illustration).

22 Install the dust seal, making sure it seats completely.

23 Install the drain screw and a new gasket, if it was removed.

24 Compress the fork fully and add the recommended type and quantity of fork oil (see Chapter 1).

25 Install the fork spring, with the small-diameter end at the bottom (EN450 models) or the widely spaced coils at the bottom (EN500

models) (see illustration). Install the spring seat and spacer, then install the top plug and secure it with the retaining ring (see Chapter 1).

26 Install the fork by following the procedure outlined in Section 3. If you won't be installing the fork right away, store it in an upright position to prevent leakage.

5 Steering head bearings - replacement

Refer to illustrations 5.4, 5.8a, 5.8b, 5.9, 5.10, 5.13a, 5.13b, 5.15, 5.19, 5.20 and 5.22

1 If the steering head bearing check/adjustment (see Chapter 1) does not remedy excessive play or roughness in the steering head bearings, the entire front end must be disassembled and the bearings and races replaced with new ones.

2 Refer to Chapter 4 and remove the fuel tank.

3 Refer to Chapter 7 and remove the front wheel.


4 Remove the cover from the front of the lower triple clamp (see illustration).

5 Refer to Section 3 and remove the front forks.

6 Refer to Chapter 9 and remove the front turn signals, headlight assembly, instruments and ignition switch.

7 Refer to Section 2 and remove the handlebars.


8 Remove the steering stem bolt (see illustration), then lift off the




5.8b ... and remove the upper triple clamp from the steering stem



5.9 Lift off the race cover and upper bearing



5.10 Lower the steering stem out of the steering head



5.13a This special Kawasaki tool expands to grip the bearing race, then is driven out with a hammer and punch

1 Kawasaki tool 57001-1107

upper triple clamp (sometimes called the fork bridge or crown) (see illustration).

9 Remove the stem locknut. Using an adjustable spanner wrench, remove the stem adjusting nut while supporting the steering head from the bottom. Lift off the race cover and upper bearing (see illustration).

10 Remove the steering stem and lower triple clamp assembly together with the lower bearing (see illustration). If it's stuck, gently tap on the top of the steering stem with a plastic mallet or a hammer and a wood block.

11 Clean all the parts with solvent and dry them thoroughly, using compressed air, if available. If you do use compressed air, don't let the bearings spin as they're dried - it could ruin them. Wipe the old grease out of the frame steering head and bearing races.

12 Examine the races in the steering head for cracks, dents, and pits. If even the slightest amount of wear or damage is evident, the races should be replaced with new ones.

13 To remove the races, drive them out of the steering head with Kawasaki tool no. 57001-1107 or equivalent (see illustration). A slide hammer with the proper internal-jaw puller will also work. Since the races are an interference fit in the frame, installation will be easier if the new races are left overnight in a refrigerator. This will cause them to contract and slip into place in the frame with very little effort. When installing the races, use Kawasaki press shaft no. 57001-1075 and drivers no. 57001-1106 and 57001-1076, or tap them gently into place with a hammer and bearing driver or a large socket (see illustration). Do not strike the bearing surface or the race will be damaged.

14 Check the bearings for wear. Look for cracks, dents, and pits in

the races and flat spots on the bearings. Replace any defective parts with new ones. If a new bearing is required, replace both of them as a set.

15 To remove the lower bearing from the steering stem, use a bearing puller (Kawasaki tool no. 57001-135 or equivalent) (see illustration). Don't remove this bearing unless it, or the grease seal underneath, must be replaced.

16 Check the grease seal under the lower bearing and replace it with a new one if necessary.

17 Inspect the steering stem/lower triple clamp for cracks and other damage. Do not attempt to repair any steering components. Replace them with new parts if defects are found.


18 Check the bearing cover - if it's worn or deteriorated, replace it.

19 Pack the bearings with high-quality grease (preferably a moly-based grease) (see illustration). Coat the outer races with grease also.

20 Install the grease seal and lower bearing onto the steering stem. Drive the lower bearing onto the steering stem using Kawasaki stem bearing driver no. 57001-137 and adapter no. 57001-1074 (see illustration). If you don't have access to these tools, a section of pipe with a diameter the same as the inner race of the bearing can be used. Drive the bearing on until it is fully seated.


21 Insert the steering stem/lower triple clamp into the frame head. Install the upper bearing and the race cover (see illustration 5.9).

22 Install the adjusting nut with its shoulder down (against the



5.13b If you don't have the special Kawasaki tools, drive in the bearing races with a bearing driver or a socket the same diameter as the bearing race

- 1 Bearing driver handle 2 Bearing driver
3 Bearing driver



5.19 Work the grease completely into the rollers

bearing). Using the adjustable spanner, tighten the nut while moving the lower triple clamp back and forth. Continue to tighten the nut (to approximately 29 ft-lbs/39 Nm) until the steering head becomes tight, then back off until there is some play in the bearings. You can calculate the torque by applying a measured amount of force to the spanner handle at a measured distance from the center of the nut (see illustration). Once the nut is tightened to the initial torque, make sure there is no more play (don't overtighten, though, or the steering will be too tight and the bearings may be damaged). Make sure the steering head turns smoothly.


- 23 Install the locknut, then adjust the bearings (see Chapter 1).
24 The remainder of installation is the reverse of removal.

6 Rear shock absorbers - removal and installation


Removal

Refer to illustrations 6.2, 6.3a, 6.3b and 6.3c

- 1 Set the bike on its centerstand (if equipped). If the bike doesn't have a centerstand, support it in an upright position so it can't be knocked over during this procedure.
2 If you're working on an EN450 model, remove the mufflers (see




5.15 To remove the steering stem bearing, you'll need a bearing splitter like this one and a puller or hydraulic press (if you don't have the necessary tools, have it pressed off by a Kawasaki dealer or machine shop)



5.20 Drive the grease seal and bearing lower race on with a hollow driver (or an equivalent piece of pipe) - these are the Kawasaki special tools


- 1 Stem bearing driver (tool no. 57001-137)
2 Adapter (tool no. 57001-1074)



5.22 To get a precise torque setting for the bearing adjusting nut, apply a measured pulling force to the handle at a measured distance from the center of the nut


6.2 Rear suspension (EN450 models) - exploded view


- 1 Shock absorbers
- 2 Mounting bushings
- 3 Washers
- 4 Washers
- 5 Lockwashers
- 6 Nuts
- 7 Swingarm pivot shaft
- 8 Bearings caps
- 9 Grease seals
- 10 Needle bearings
- 11 Sleeve
- 12 Swingarm
- 13 Swingarm pivot shaft nut
- 14 Drive belt buffer
- 15 Drive belt adjuster
- 16 Adjuster locknut
- 17 Adjuster bolt




6.3a Rear suspension (EN500 models) - exploded view

- 1 Shock absorber
- 2 Mounting bushings
- 3 Mounting bolts
- 4 Swingarm
- 5 Shock absorber mounting nuts
- 6 Swingarm pivot shaft nut
- 7 Bearing cap
- 8 Grease seal
- 9 Needle bearing
- 10 Sleeve
- 11 Bearing cap
- 12 Swingarm pivot shaft






6.3b Once the bolt is removed, the upper end of the shock absorber can be detached from its mounting bracket



6.3c Remove the nut and bolt (arrow) from the lower end and remove the shock absorber



8.5 Remove the swingarm pivot shaft nut and withdraw the shaft

Chapter 4). Remove the shock absorber upper and lower nuts and lift the shock off the motorcycle (*see illustration*).

3 If you're working on an EN500 model, remove the rear side trim pieces, together with the rear turn signals (see Chapter 9). The forward bolt on the rear side trim also secures the top of the shock absorber. Remove the shock absorber lower bolt and lift the shock off the motorcycle (*see illustrations*).

Installation

4 Installation is the reverse of the removal procedure. Tighten the shock absorber bolts/nuts to the torque values listed in this Chapter's Specifications.

7 Swingarm bearings - check

1 Refer to Chapter 7 and remove the rear wheel, then refer to Section 6 and remove the rear shock absorbers.

2 Grasp the rear of the swingarm with one hand and place your other hand at the junction of the swingarm and the frame. Try to move the rear of the swingarm from side-to-side. Any wear (play) in the bearings should be felt as movement between the swingarm and the frame at the front. The swingarm will actually be felt to move forward and backward at the front (not from side-to-side). If any play is noted, the bearings should be replaced with new ones (see Section 9).

3 Next, move the swingarm up and down through its full travel. It should move freely, without any binding or rough spots. If it does not move freely, refer to Section 9 for servicing procedures.

8 Swingarm - removal and installation

Refer to illustrations 8.5, 8.8a, 8.8b and 8.8c

1 Raise the bike and set it on its centerstand (if equipped). If the bike doesn't have a centerstand, support it securely so it can't be knocked over during this procedure.

2 Remove the rear wheel (see Chapter 7).

3 If you're working on an EN450 model, remove the mufflers (see Chapter 4).

4 Detach the brake torque link from the swingarm (see Chapter 7).

5 Remove the swingarm pivot shaft nut (*see illustration*). Don't remove the pivot shaft yet.


6 Support the swingarm with a jack and detach the shock absorbers (see Section 6). On EN450 models, you'll need to remove the shocks completely to get them off the swingarm studs.

7 Support the swingarm and pull the pivot shaft out. Remove the swingarm. The bearing caps may fall out as this is done.


8 Remove the caps (if they didn't fall off), then pull out the sleeve and pry out the grease seals (*see illustrations*). Check the pivot




8.8a Remove the bearing caps . . .




8.8b ... slide out the sleeve ...



8.8c ... and pry out the grease seals for access to the bearings



10.2 Remove the mounting bolts (arrows) and take off the belt guard



10.3 Remove the engine pulley cover bolts (arrows) and take off the cover

bearings in the swingarm for dryness or deterioration. If they're in need of lubrication or replacement, refer to Section 9.

9 Installation is the reverse of the removal procedure, with the following additions:

- Be sure the grease seals are in position before installing the pivot shaft.
- Tighten the pivot shaft nut and the shock absorber mounting bolts/nuts to the torque values listed in this Chapter's Specifications.
- Adjust the drive belt as described in Chapter 1.

9 Swingarm bearings - replacement

1 Bearing replacement isn't complicated, but it requires a blind hole (expanding) puller, a slide hammer and a hydraulic press. The puller and slide hammer can be rented if you don't have them, and you may be able to devise a substitute for a hydraulic press, but compare the cost of having the bearings replaced by a Kawasaki dealer to that of renting the equipment before you proceed. It may be cheaper, and it will probably be easier, to have the bearings replaced by the dealer. You can save money by removing the swingarm from the bike yourself.

- Remove the swingarm (see Section 8).
- Slide the sleeve out (see illustration 8.8b).
- Pry out the seals (see illustration 8.8c).
- Remove the bearings with a blind hole (expanding) puller and

slide hammer.

- Press new bearings into the swingarm.

10 Drive belt and pulleys - removal, inspection and installation

Refer to illustrations 10.2, 10.3 and 10.5


Removal

- Remove the shift lever (see Chapter 2).
- Remove the belt guard (see illustration). Draw an arrow on the top of the belt pointing toward the front of the motorcycle to indicate the direction of belt rotation.
- Remove the bolts securing the engine pulley cover to the engine case (see illustration). Slide the pulley cover off.
- Remove the rear wheel (see Chapter 7).
- Remove two bolts that secure the engine pulley holding plate, then remove the pulley from the engine (see illustration).
- Remove the swingarm (see Section 8). Pull the swingarm back far enough to allow the belt to slip between the frame and the front of the swingarm.


Inspection

Refer to illustrations 10.9 and 10.10

- Check the belt for wear (see Chapter 1). Replace it if it's worn or damaged.



10.5 Remove the holding plate bolts (arrows), then remove the holding plate and the pulley



10.10 Measure the diameter of the rear pulley

8 Check the pulleys for damage and for worn teeth (see Chapter 1). Replace them if any undesirable conditions are found. If the pulleys must be replaced, install a new belt as well.

9 Measure the height of the pulley teeth (see illustration). Replace the pulleys and the belt if the teeth are worn to less than the value listed in this Chapter's Specifications.

10 Measure rear pulley diameter (see illustration). Replace the pulley if it is worn to less than the value listed in this Chapter's Specifications.

Installation


11 Installation is the reverse of the removal procedure, with the following additions:

- Tighten the suspension fasteners to the torque values listed in this Chapter's Specifications.
- Adjust the belt tension (see Chapter 1).
- Tighten the rear axle nut to the torque listed in the Chapter 7 Specifications.


11 Rear wheel coupling/rubber damper - check and replacement

Refer to illustration 11.2

- Remove the rear wheel (see Chapter 7).



10.9 Measure the height of the pulley teeth



11.2 Rear coupling details

- A Spacer
- B Drive belt pulley/coupling
- C Damper

2 Lift the rear pulley/rear wheel coupling from the wheel (see illustration).

3 Lift the rubber damper from the wheel (see illustration 11.2) and check it for cracks, hardening and general deterioration. Replace it with a new one if necessary.

4 Checking and replacement procedures for the coupling bearing are similar to those described for the wheel bearings. Refer to Chapter 7.

5 Installation is the reverse of the removal procedure. **Caution:** Be sure not to forget the spacer (see illustration 11.2); if the axle nut is tightened without the spacer in position, the rear wheel bearings may be damaged.

12 Suspension adjustments

Front forks (early EN450 models)

1 The front forks on early EN450 models are equipped with air pressure valves. Later EN450 models and all EN500 models have non-adjustable forks. The recommended air pressure setting is listed in this Chapter's Specifications. **Warning:** Never exceed the maximum pressure listed in this Chapter's Specifications. Never remove the fork springs and rely on air pressure alone to support the forks or unstable handling may occur. Ensure that the pressure is equal in both legs.

Rear spring preload adjustment


Refer to illustrations 12.2a and 12.2b

- The rear spring preload is adjusted by turning the adjusting sleeve



12.2a This is the spring preload adjuster on EN450 models; setting 1 is the softest and setting 5 is the hardest

at the bottom with the hook wrench included in the bike's tool kit (see illustrations). Compare preload with the values listed in this Chapter's Specifications and adjust as needed. **Warning:** Always place both springs on the same setting or unstable handling may occur.



12.2b Spring preload adjuster details (EN500 models)

- | | | | |
|---|------------------|---|---|
| 1 | Adjuster | 3 | Positioning marks |
| 2 | Adjusting sleeve | | (1 is the softest and 5 is the hardest) |

Chapter 7 Brakes, wheels and tires

Contents

Brake caliper - removal, overhaul and installation	3	Brake system bleeding	8
Brake disc - inspection, removal and installation	4	Front brake master cylinder - removal, overhaul and installation ..	5
Brake hoses and lines - inspection and replacement	7	Front wheel - removal, inspection and installation	11
Brake light switches - check and replacement	See Chapter 9	General information	1
Brake pads - replacement	2	Rear drum brake - removal, inspection and installation	6
Brake pads and linings - wear check	See Chapter 1	Rear wheel - removal, inspection and installation	12
Brake pedal and cable - removal and installation	9	Tires/wheels - general check	See Chapter 1
Brake pedal position and play - check and adjustment	See Chapter 1	Tubeless tires - general information	14
Brake system - general check	See Chapter 1	Wheel bearings - inspection and maintenance	13
		Wheels - inspection, repair and alignment	10

Specifications

Brakes

Brake fluid type	See Chapter 1
Brake pad minimum thickness	See Chapter 1
Disc thickness	
Standard	4.8 to 5.1 mm (0.189 to 0.200 inch)
Minimum*	4.5 mm (0.177 inch)
* Refer to marks stamped into the disc (they supersede information printed here)	
Disc runout (maximum)	
EN450 models	0.15 mm (0.006 inch)
EN500 models	0.2 mm (0.008 inch)
Brake pedal position and freeplay	See Chapter 1
Rear brake lining thickness	
Standard	
EN450 models	5.0 mm (0.197 inch)
EN500 models	4.8 to 5.1 mm (0.189 to 0.200 inch)
Minimum	
EN450 models	2.5 mm (0.098 inch)
EN500 models	2.0 mm (0.079 inch)
Brake drum diameter	
Standard	180.00 to 180.16 mm (7.087 to 7.093 inch)
Maximum	180.75 mm (7.116 inch)
Brake cam diameter	
Standard	16.975 to 16.984 mm (0.668 to 0.669 inch)
Minimum	16.88 mm (0.665 inch)
Cam hole diameter in brake panel	
Standard	17.00 to 17.07 mm (0.669 to 0.672 inch)
Maximum	17.15 mm (0.675 inch)

Wheels and tires

Wheel runout	
Axial (side-to-side)	0.5 mm (0.020 inch)
Radial (out-of-round)	0.8 mm (0.031 inch)
Axle runout (front and rear)	
Standard	0.05 mm (0.002 inch) per 100 mm (3.94 inch) of axle length
Limit	0.2 mm (0.007 inch) per 100 mm (3.94 inch) of axle length
Tire pressures	See Chapter 1
Tire sizes	
Front	100/90-19 57S
Rear	
EN450 models	140/90-15 70S
EN500 models	140/90-15M/C 70S

Torque specifications

Caliper mounting bolts	
EN450 models	29 Nm (22 ft-lbs)
EN500 models	39 Nm (29 ft-lbs)
Banjo fitting bolts	25 Nm (18 ft-lbs)
Brake disc-to-wheel bolts	23 Nm (16.5 ft-lbs)
Master cylinder mounting bolts	8.8 Nm (78 in-lbs)
Front brake lever pivot pin locknut	5.9 Nm (52 in-lbs)
Caliper bleed valve	7.8 Nm (69 in-lbs)
Rear brake pedal pinch bolt	25 Nm (18 ft-lbs)
Front axle nut	88 Nm (65 ft-lbs)
Front axle clamp bolt	
EN450 models	14 Nm (10 ft-lbs)
EN500 models	16 Nm (11.5 ft-lbs)
Rear axle nut	125 Nm (94 ft-lbs)

1 General information

The models covered by this manual are equipped with a hydraulic disc brake on the front and a mechanical drum brake on the rear. The front brake uses a single piston caliper.

All models are equipped with cast aluminum wheels, which require very little maintenance and allow tubeless tires to be used.


Caution: Disc brake components rarely require disassembly. Do not disassemble components unless absolutely necessary. If any hydraulic brake line connection in the system is loosened, the entire system should be disassembled, drained, cleaned and then properly filled and bled upon reassembly. Do not use solvents on internal brake components. Solvents will cause seals to swell and distort. Use only clean brake fluid or alcohol for cleaning. Use care when working with brake fluid as it can injure your eyes and it will damage painted surfaces and plastic parts.

2 Brake pads - replacement

Refer to illustrations 2.2, 2.4, 2.5, 2.6 and 2.7


Warning: The dust created by the brake system may contain asbestos, which is harmful to your health. Never blow it out with compressed air and don't inhale any of it. An approved filtering mask should be worn when working on the brakes.

- 1 Set the bike on its centerstand (if equipped).
- 2 Remove the caliper mounting bolts (**see illustration**). Slide the caliper and pads off the disc.
- 3 Support the caliper with rope or wire so it doesn't hang by the brake hose.
- 4 Push the caliper bracket in (toward the piston) until the pins on the bracket clear the holes in the pad backing plate, then remove the inner pad (**see illustration**).
- 5 Remove the outer brake pad from the caliper (**see illustration**).




2.2 Remove the caliper mounting bolts (arrows) and support the caliper so it doesn't hang by the brake hose


- 6 Remove the anti-rattle spring (**see illustration**). If it appears damaged, replace it.
- 7 Check the pad support clips on the caliper bracket (**see illustration**). If they are missing or distorted, replace them.
- 8 Check the condition of the brake disc (**see Section 4**). If it is in need of machining or replacement, follow the procedure in that Section to remove it. If it is okay, deglaze it with sandpaper or emery cloth, using a swirling motion.
- 9 Remove the cap from the master cylinder reservoir and siphon out some fluid. Push the piston into the caliper as far as possible, while checking the master cylinder reservoir to make sure it doesn't overflow. If you can't depress the piston with thumb pressure, try using a



2.4 Slide the caliper bracket toward the pistons so it clears the inner pad, then remove the pad



2.5 Disengage the clips on the outer pad from the caliper and remove the pad



2.6 Remove the anti-rattle spring

A Anti-rattle spring

B Piston insert

C-clamp (G-clamp). If the piston sticks, remove the caliper and overhaul it as described in Section 3.


10 Install the anti-rattle spring in the caliper.

11 Install both pads in the caliper and pull the caliper bracket out, so the pins on the bracket engage with the holes in the pad backing plate.

12 Install the caliper, tightening the mounting bolts to the torque listed in this Chapter's Specifications.

13 Refill the master cylinder reservoir (see Chapter 1) and install the diaphragm and cap.

14 Operate the brake lever several times to bring the pads into contact with the disc. Check the operation of the brakes carefully before riding the motorcycle.




2.7 Front brakes - exploded view

3 Brake caliper - removal, overhaul and installation

Warning: If a caliper indicates the need for an overhaul (usually due to leaking fluid or sticky operation), all old brake fluid should be flushed from the system. Also, the dust created by the brake system may contain asbestos, which is harmful to your health. Never blow it out with compressed air and don't inhale any of it. An approved filtering mask should be worn when working on the brakes. Do not, under any circumstances, use petroleum-based solvents to clean brake parts. Use clean brake fluid, brake cleaner or denatured alcohol only!

Note: If you are removing the caliper only to replace or inspect the brake pads, don't disconnect the hose from the caliper.

- | | |
|----------------------------|----------------------------|
| 1 Brake pad | 9 Brake disc mounting bolt |
| 2 Brake pad | 10 Brake disc |
| 3 Pad clips | 11 Slider pin boots |
| 4 Caliper bracket | 12 Piston seal |
| 5 Caliper mounting bolts | 13 Piston |
| 6 Bleed valve and dust cap | 14 Dust seal |
| 7 Caliper body | |
| 8 Anti-rattle spring | |



3.2 Remove the brake hose banjo fitting bolt - there's a sealing washer on each side of the fitting

Removal

Refer to illustration 3.2

- 1 Place the bike on its centerstand (if equipped). **Note:** If you're planning to overhaul the caliper and don't have a source of compressed air to blow out the piston, use the bike's hydraulic system instead. To do this, remove the pads (see Section 2) and squeeze the brake lever to force the piston out of the cylinder. **Note:** Brake fluid will run out of the caliper if you remove the piston in this manner. Try to keep it off of the bike by holding the caliper over a pan. Be sure to wipe any spilled fluid off painted or plastic surfaces immediately and clean the area with soap and water.
- 2 Remove the brake hose banjo fitting bolt and separate the hose from the caliper (see illustration). Discard the sealing washers. Plug the end of the hose or wrap a plastic bag tightly around it to prevent excessive fluid loss and contamination.
- 3 Remove the caliper (see Section 2).


Overhaul

Refer to illustrations 3.9, 3.16 and 3.17

- 4 Remove the brake pads and anti-rattle spring from the caliper (see Section 2, if necessary).
- 5 Remove the caliper piston insert (see illustration 2.6).
- 6 Clean the exterior of the caliper with denatured alcohol or brake system cleaner.
- 7 Remove the caliper bracket and the slider pin boots from the caliper (see illustration 2.7).
- 8 If you didn't force out the piston with the bike's hydraulic system in Step 1, place a few rags between the piston and the caliper frame to act as a cushion, then use compressed air, directed into the fluid inlet, to remove the piston. Use only enough air pressure to ease the piston out of the bore. If a piston is blown out, even with the cushion in place, it may be damaged. **Warning:** Never place your fingers in front of the piston in an attempt to catch or protect it when applying compressed air, as serious injury could occur.
- 9 Using a wood or plastic tool, remove the dust seal (see illustration). Metal tools may cause bore damage.
- 10 Using a wood or plastic tool, remove the piston seal from the groove in the caliper bore.
- 11 Clean the piston and the bore with denatured alcohol, clean brake fluid or brake system cleaner and blow dry them with filtered, unlubricated compressed air. Inspect the surface of the piston for nicks and burrs and loss of plating. Check the caliper bore, too. If surface defects are present, the caliper must be replaced. If the caliper is in bad shape, the master cylinder should also be checked.
- 12 Temporarily reinstall the caliper bracket. Make sure it slides smoothly in-and-out of the caliper. If it doesn't, check the slider pins for wear or excessive wear. Also check the slider pin bores in the caliper for wear and scoring. Replace the caliper bracket, the caliper,



3.9 The dust seal should be removed with a plastic or wooden tool to avoid damage to the bore and seal groove (a pencil works well) - remove the piston seal the same way




3.16 Install the slider pin boots

or both if necessary.


- 13 Lubricate the new piston seal with clean brake fluid and install it in its groove in the caliper bore. Make sure it seats completely and isn't twisted.
- 14 Lubricate the new dust seal with clean brake fluid and install it in its groove, making sure it seats correctly.
- 15 Lubricate the piston with clean brake fluid and install it in the caliper bore. Using your thumbs, push the piston all the way in, making sure it doesn't get cocked in the bore.
- 16 Install the slider pin boots (see illustration).
- 17 Apply a thin coat of PBC (poly butyl cuprysil) grease, or silicone grease designed for high-temperature brake applications, to the slider pins on the caliper bracket (see illustration). Install the caliper bracket to the caliper and seat the boots over the lips on the bracket.

Installation

- 18 Install the piston insert (see illustration 2.6).
- 19 Install the anti-rattle spring and the brake pads (see Section 2).
- 20 Install the caliper, tightening the mounting bolts to the torque listed in this Chapter's Specifications.
- 21 Connect the brake hose to the caliper, using a new sealing washers on each side of the fitting. Tighten the banjo fitting bolt to the torque listed in this Chapter's Specifications.
- 22 Fill the master cylinder with the recommended brake fluid (see Chapter 1) and bleed the system (see Section 8). Check for leaks.
- 23 Check the operation of the brakes carefully before riding the motorcycle.



3.17 Apply a thin coat of the specified grease to the slider pins on the caliper bracket




4.6 Loosen the disc retaining bolts a little at a time to prevent distortion

4 Brake disc - inspection, removal and installation

Inspection

Refer to illustration 4.4

- 1 Set the bike on its centerstand (if equipped).
- 2 Visually inspect the surface of the disc for score marks and other damage. Light scratches are normal after use and won't affect brake operation, but deep grooves and heavy score marks will reduce braking efficiency and accelerate pad wear. If the disc is badly grooved it must be machined or replaced.
- 3 To check disc runout, mount a dial indicator to a fork leg with the plunger on the indicator touching the surface of the disc about 1/2-inch from the outer edge. Slowly turn the wheel (have an assistant sit on the seat to raise the front wheel off the ground) and watch the indicator needle, comparing your reading with the limit listed in this Chapter's Specifications. If the runout is greater than allowed, check the hub bearings for play (see Chapter 1). If the bearings are worn, replace them and repeat this check. If the disc runout is still excessive, it will have to be replaced.
- 4 The disc must not be machined or allowed to wear down to a thickness less than the minimum allowable thickness listed in this Chapter's Specifications. The thickness of the disc can be checked with a micrometer. If the thickness of the disc is less than the minimum allowable, it must be replaced. The minimum thickness is also stamped into the disc (see illustration).



4.4 The minimum allowable thickness is stamped into the disc

Removal

Refer to illustration 4.6


- 5 Remove the wheel (see Section 11). **Caution:** Don't lay the wheel down and allow it to rest on the disc - the disc could become warped.
- 6 Mark the relationship of the disc to the wheel, so it can be installed in the same position. Remove the Allen bolts that retain the disc to the wheel (see illustration). Loosen the bolts a little at a time, in a criss-cross pattern, to avoid distorting the disc.
- 7 Take note of any paper shims that may be present where the disc mates to the wheel. If there are any, mark their position and be sure to include them when installing the disc.

Installation

- 8 Position the disc on the wheel, aligning the previously applied matchmarks (if you're reinstalling the original disc). Make sure the arrow (stamped on the disc) marking the direction of rotation is pointing in the proper direction.
- 9 Apply a non-hardening thread locking compound to the threads of the bolts. Install the bolts, tightening them a little at a time, in a criss-cross pattern, until the torque listed in this Chapter's Specifications is reached. Clean off all grease from the brake disc using acetone or brake system cleaner.
- 10 Install the wheel.
- 11 Operate the brake lever several times to bring the pads into contact with the disc. Check the operation of the brakes carefully before riding the motorcycle.


5 Front brake master cylinder - removal, overhaul and installation

- 1 If the master cylinder is leaking fluid, or if the lever does not produce a firm feel when the brake is applied, and bleeding the brakes does not help, master cylinder overhaul is recommended. Before disassembling the master cylinder, read through the entire procedure and make sure that you have the correct rebuild kit. Also, you will need some new, clean brake fluid of the recommended type, some clean rags and internal snap-ring pliers. **Caution:** To prevent damage to the paint from spilled brake fluid, always cover the fuel tank when working on the master cylinder.
- 2 **Caution:** Disassembly, overhaul and reassembly of the brake master cylinder must be done in a spotlessly clean work area to avoid contamination and possible failure of the brake hydraulic system components.



5.4a Master cylinder (EN450 models) - exploded view

- | | |
|------------------------------|-----------------------|
| 1 Reservoir cap screws | 10 Piston assembly |
| 2 Reservoir cap | 11 Spring |
| 3 Diaphragm | 12 Clamp bolt |
| 4 Brake lever pivot bolt | 13 Rubber boot |
| 5 Brake lever | 14 Banjo bolt |
| 6 Brake lever pivot bolt nut | 15 Sealing washers |
| 7 Insert | 16 Grommet |
| 8 Dust boot | 17 Brake line |
| 9 Washer | 18 Brake light switch |




5.6 On EN500 models, the master cylinder mounting bolts are located beneath trim covers (arrows)

Removal

Refer to illustrations 5.4a, 5.4b and 5.6

- 3 Loosen, but do not remove, the screws holding the reservoir cap in place.
- 4 Pull back the rubber boot (if equipped), loosen the banjo fitting



5.4b Master cylinder (EN500 models) - exploded view

- | | |
|------------------------|--------------------------|
| 1 Reservoir cap screws | 13 Clamp |
| 2 Reservoir cap | 14 Screw |
| 3 Diaphragm | 15 Brake light switch |
| 4 Master cylinder body | 16 Master cylinder body |
| 5 Lever pivot bolt | 17 Banjo bolt |
| 6 Brake lever | 18 Sealing washers |
| 7 Lever pivot bolt nut | 19 Brake line |
| 8 Spring | 20 Retainer cap |
| 9 Dust boot | 21 Handlebar |
| 10 Snap-ring | 22 Front fender/mudguard |
| 11 Piston assembly | 23 Brake line retainer |
| 12 Spring | |

bolt (see illustrations) and separate the brake hose from the master cylinder. Wrap the end of the hose in a clean rag and suspend the hose in an upright position or bend it down carefully and place the open end in a clean container. The objective is to prevent excess loss of brake fluid, fluid spills and system contamination.

5 Remove the locknut from the underside of the lever pivot bolt, then unscrew the bolt (see illustration 5.4a or 5.4b).

6 Remove the master cylinder mounting bolts (see illustration) and separate the master cylinder from the handlebar. **Caution:** Do not tip the master cylinder upside down or brake fluid will run out.


7 Disconnect the electrical connectors from the brake light switch.

Overhaul

8 Detach the reservoir cap and the rubber diaphragm, then drain the brake fluid into a suitable container. Wipe any remaining fluid out of the reservoir with a clean rag.

9 Carefully remove the rubber dust boot from the end of the piston (see illustration 5.4a or 5.4b).


10 On EN450 models extract the washer, piston and cup assembly



5.15 On EN450 models, the protrusion on the master cylinder clamp faces to the right

1 Upper mounting bolt

2 Protrusion



6.4 Fold the shoes off the panel to remove them


and the spring. On EN500 models, remove the snap-ring and slide out the piston, the cup seals and the spring. Lay the parts out in the proper order to prevent confusion during reassembly.

11 Clean all of the parts with brake system cleaner (available at auto parts stores), denatured alcohol or clean brake fluid. **Caution:** Do not, under any circumstances, use a petroleum-based solvent to clean brake parts. If compressed air is available, use it to dry the parts thoroughly (make sure it's filtered and unlubricated). Check the master cylinder bore for corrosion, scratches, nicks and score marks. If damage is evident, the master cylinder must be replaced with a new one. If the master cylinder is in poor condition, then the caliper should be checked as well. Make sure the ports in the bottom of the master cylinder are clear. If the small relief port is clogged, the brakes will drag.

12 Remove the old cup seals from the piston and spring and install the new ones. If a new piston is included in the rebuild kit, use it regardless of the condition of the old one. **Note:** The secondary cups on EN500 models can't be removed. If they're worn or damaged, replace the piston assembly.

13 Before reassembling the master cylinder, soak the piston and the rubber cup seals in clean brake fluid for ten to fifteen minutes. Lubricate the master cylinder bore with clean brake fluid, then carefully insert the piston and related parts in the reverse order of disassembly. Make sure the lips on the cup seals do not turn inside out when they are slipped into the bore.

14 On EN450 models, install the washer and rubber dust boot (make sure its lip locates correctly). On EN500 models, depress the piston, then install the snap-ring (make sure the snap-ring is properly seated in the groove with the sharp edge facing out). Install the rubber dust boot (make sure the lip is seated properly in the piston groove).



6.3 The brake shoes are mounted on a panel that fits into the rear wheel

Installation

Refer to illustration 5.15

15 Attach the master cylinder to the handlebar with the clamp. On EN450 models, the protrusion on the clamp must face to the right (see illustration). Tighten the bolts to the torque listed in this Chapter's Specifications. **Note:** Tighten the upper bolt first, then the lower bolt. There will be a gap at the bottom between the clamp and master cylinder body.

16 Install the brake lever and tighten the pivot bolt locknut.

17 Connect the brake hose to the master cylinder, using new sealing washers. Tighten the banjo fitting bolt to the torque listed in this Chapter's Specifications. Refer to Section 8 and bleed the air from the system.

6 Rear drum brake - removal, inspection and installation

Warning: The dust collected by the brake system may contain asbestos, which is harmful to your health. Never blow it out with compressed air and don't inhale any of it. An approved filtering mask should be worn when working on the brakes.

Removal


Refer to illustrations 6.3 and 6.4

- 1 Before you start, inspect the rear brake wear indicator (see Chapter 1).
- 2 Remove the rear wheel (see Section 12).
- 3 Lift the brake panel out of the wheel (see illustration).
- 4 Fold the shoes toward each other to release the spring tension (see illustration). Remove the shoes and springs from the brake panel.

Inspection

Refer to illustration 6.8

- 5 Check the linings for wear, damage, and signs of contamination from road dirt or water. If the linings are visibly defective, replace them.
- 6 Measure the thickness of the lining material (just the lining material, not the metal backing) and compare with the value listed in this Chapter's Specifications. Replace the shoes if the material is worn to less than the minimum.
- 7 Check the ends of the shoes where they contact the brake cam and pivot post. Replace the shoes if there's visible wear.
- 8 Check the brake cam and pivot post for wear and damage. If necessary, make match marks on the cam and cam lever, then remove the pinch bolt, lever, wear indicator pointer, seal, spring and cam (see illustration).



6.8 Exploded view of the rear brake

- | | |
|--------------------------|--------------------------|
| 1 Brake shoes | 6 Seal |
| 2 Return springs | 7 Wear indicator pointer |
| 3 Brake cam | 8 Brake cam lever |
| 4 Brake panel | 9 Pinch bolt |
| 5 Brake cam lever spring | |

9 Check the brake drum (inside the wheel) for wear or damage. Measure the diameter at several points with a brake drum micrometer (or have this done by a Kawasaki dealer). If the measurements are uneven (indicating that the drum is out-of-round) or if there are scratches deep enough to snag a fingernail, have the drum turned (skimmed) by a dealer to correct the surface. If the drum has to be turned (skimmed) beyond the wear limit to remove the defects, replace it.

10 Check the brake cam for looseness in the brake panel hole. If it feels loose, measure the diameter of the cam and hole and compare them with those listed in this Chapter's Specifications. Replace worn parts.

Installation

11 Apply high temperature brake grease to the ends of the springs, the cam and the anchor pin.

12 Hook the springs to the shoes. Position the shoes in a V on the brake panel, then fold them down into position (see illustration 6.4). Make sure the ends of the shoes fit correctly in the cam and on the pivot post.

13 The remainder of installation is the reverse of the removal steps.

14 Check the position of the brake pedal (see Chapter 1) and adjust it if necessary. Check the operation of the brakes carefully before riding the motorcycle.

7 Brake hoses and lines - inspection and replacement

Inspection

1 Once a week, or if the motorcycle is used less frequently, before every ride, check the condition of the brake hose.

2 Twist and flex the rubber hose (see illustration 5.4a or 5.4b) while looking for cracks, bulges and seeping fluid. Check extra carefully around the areas where the hose connects to the banjo fittings, as these are common areas for hose failure.

Replacement

Refer to illustration 7.3


3 The brake hose has banjo fittings on each end. Cover the surrounding area with plenty of rags and unscrew the banjo bolts on either end of the hose. Remove the bolt that secures the hose to the lower triple clamp (see illustration), detach the hose from the clips and remove the hose.

4 Position the new hose, making sure it isn't twisted or otherwise strained, between the two components. Install the banjo bolts, using new sealing washers on both sides of the fittings, and tighten them to the torque listed in this Chapter's Specifications.


5 Flush the old brake fluid from the system, refill the system with the recommended fluid (see Chapter 1) and bleed the air from the system (see Section 8). Check the operation of the brakes carefully before riding the motorcycle.



7.3 Unbolt the hose bracket from the lower triple clamp (arrow)



8.5 Remove the bleed valve cap and fit a length of tubing over it; place the other end in a clean glass jar and place a wrench on the bleed valve




9.2 Unhook the brake pedal spring (arrow)

8 Brake system bleeding


Refer to illustration 8.5

1 Bleeding the brake is simply the process of removing all the air bubbles from the brake fluid reservoir, the hose and the brake caliper. Bleeding is necessary whenever a brake system hydraulic connection is loosened, when a component or hose is replaced, or when the master cylinder or caliper is overhauled. Leaks in the system may also allow air to enter, but leaking brake fluid will reveal their presence and warn you of the need for repair.



9.3a Brake pedal and cable details (EN450 models)

- | | |
|----|-----------------------|
| 1 | Brake pedal |
| 2 | Pinch bolt |
| 3 | Pedal adjuster bolt |
| 4 | Adjuster bolt locknut |
| 5 | Pedal bracket |
| 6 | Pedal shaft |
| 7 | Pedal return spring |
| 8 | Clips |
| 9 | Torque link nuts |
| 10 | Torque link |
| 11 | Torque link bolts |
| 12 | Brake cable |



2 To bleed the brake, you will need some new, clean brake fluid of the recommended type (see Chapter 1), a length of clear vinyl or plastic tubing, a small container partially filled with clean brake fluid, some rags and a wrench to fit the brake caliper bleed valve.

3 Cover the fuel tank and other painted components to prevent damage in the event that brake fluid is spilled.

4 Remove the reservoir cap and slowly pump the brake lever a few times, until no air bubbles can be seen floating up from the holes at the bottom of the reservoir. Doing this bleeds the air from the master cylinder end of the line. Reinstall the reservoir cap.

5 Attach one end of the clear vinyl or plastic tubing to the brake caliper bleeder valve and submerge the other end in the brake fluid in the container (see illustration).

6 Remove the reservoir cap and check the fluid level. Do not allow the fluid level to drop below the lower mark during the bleeding process.

7 Carefully pump the brake lever three or four times and hold it while opening the caliper bleeder valve. When the valve is opened, brake fluid will flow out of the caliper into the clear tubing and the lever will move toward the handlebar.


8 Retighten the bleeder valve, then release the brake lever gradually. Repeat the process until no air bubbles are visible in the brake fluid leaving the caliper and the lever is firm when applied. Remember to add fluid to the reservoir as the level drops. Use only new, clean brake fluid of the recommended type. Never reuse the fluid lost during bleeding; it absorbs moisture from the air, which can lead to brake failure.

9 Replace the reservoir cap, wipe up any spilled brake fluid and check the entire system for leaks. **Note:** If bleeding is difficult, it may be necessary to let the brake fluid in the system stabilize for a few hours (it may be aerated). Repeat the bleeding procedure when the tiny bubbles in the system have settled out.

9 Brake pedal and cable - removal and installation

Refer to illustrations 9.2, 9.3a, 9.3b, 9.4 and 9.5

- 1 Place the motorcycle on its centerstand (if equipped).
- 2 Unhook the brake pedal spring (see illustration).
- 3 Fully unscrew the brake free play adjusting nut from the wheel



9.3b Brake pedal and cable details (EN500 models)

- | | | | |
|---|---------------------------------|----|-------------------|
| 1 | Brake pedal | 9 | Clevis pin |
| 2 | Pinch bolt | 10 | Washer |
| 3 | Pedal adjuster bolt and locknut | 11 | Cotter pin |
| 4 | Pedal bracket bolt | 12 | Brake cable |
| 5 | Pedal bracket | 13 | Clips |
| 6 | Footpeg pivot | 14 | Torque link nuts |
| 7 | Pedal return spring | 15 | Torque link bolts |
| 8 | Pedal shaft | 16 | Torque link |


end of the brake cable and disengage the cable's threaded rod from the brake cam lever (**see illustrations**).

4 Remove the cotter pin and clevis pin at the brake pedal (**see illustration**). Detach the cable from the brake pedal and the bracket and take it out.

5 Look for punch marks on the brake pedal and shaft that indicate their relationship with each other (**see illustration**). If you don't see marks, make your own. Remove the pedal pinch bolt and take the pedal off.

6 Installation is the reverse of the removal steps, with the following additions:

- Tighten the pedal pinch bolt to the torque listed in this Chapter's Specifications.
- Lubricate the pedal shaft with multi-purpose grease.
- Lubricate the inner brake cable with engine oil.
- Check brake pedal height and free play and adjust as necessary (**see Chapter 1**).



9.4 Remove the clevis pin (right arrow) and detach the cable from the bracket (left arrow)

10 Wheels - inspection, repair and alignment check

Inspection and repair

1 Place the motorcycle on the centerstand (if equipped), then clean the wheels thoroughly to remove mud and dirt that may interfere with the inspection procedure or mask defects. Make a general check of the wheels and tires as described in Chapter 1.

2 With the motorcycle on the centerstand and the wheel in the air, attach a dial indicator to the fork slider or the swingarm and position the pointer against the side of the rim. Spin the wheel slowly and check the side-to-side (axial) runout of the rim, then compare your readings with the value listed in this Chapter's Specifications. In order to accurately check radial runout with the dial indicator, the wheel would have to be removed from the machine and the tire removed from the wheel. With the axle clamped in a vise, the wheel can be rotated to check the runout.

3 An easier, though slightly less accurate, method is to attach a stiff wire pointer to the fork slider or the swingarm and position the end a fraction of an inch from the wheel (where the wheel and tire join). If the wheel is true, the distance from the pointer to the rim will be constant as the wheel is rotated. Repeat the procedure to check the runout of the rear wheel. **Note:** If wheel runout is excessive, refer to the appropriate Section in this Chapter and check the wheel bearings very carefully before replacing the wheel.

4 The wheels should also be visually inspected for cracks, flat spots on the rim and other damage. Since tubeless tires are involved, look very closely for dents in the area where the tire bead contacts the rim. Dents in this area may prevent complete sealing of the tire against the rim, which leads to deflation of the tire over a period of time.

5 If damage is evident, or if runout in either direction is excessive, the wheel will have to be replaced with a new one. Never attempt to repair a damaged cast aluminum wheel.

Alignment check

6 Misalignment of the wheels, which may be due to a cocked rear wheel or a bent frame or triple clamps, can cause strange and possibly serious handling problems. If the frame or triple clamps are at fault, repair by a frame specialist or replacement with new parts are the only alternatives.

7 To check the alignment you will need an assistant, a length of string or a perfectly straight piece of wood and a ruler graduated in 1/64 inch increments. A plumb bob or other suitable weight will also be required.

8 Place the motorcycle on the centerstand, then measure the width of both tires at their widest points. Subtract the smaller measurement from the larger measurement, then divide the difference by two. The result is the amount of offset that should exist between the front and rear tires on both sides.

9 If a string is used, have your assistant hold one end of it about half way between the floor and the rear axle, touching the rear sidewall of the tire.

10 Run the other end of the string forward and pull it tight so that it is

roughly parallel to the floor. Slowly bring the string into contact with the front sidewall of the rear tire, then turn the front wheel until it is parallel with the string. Measure the distance from the front tire sidewall to the string.

11 Repeat the procedure on the other side of the motorcycle. The distance from the front tire sidewall to the string should be equal on both sides.

12 As was previously pointed out, a perfectly straight length of wood may be substituted for the string. The procedure is the same.

13 If the distance between the string and tire is greater on one side, or if the rear wheel appears to be cocked, refer to Chapter 6, Swingarm bearings - check, and make sure the swingarm is tight. Also refer to the chain adjustment procedure in Chapter 1 and make sure the adjusters are set evenly.

14 If the front-to-back alignment is correct, the wheels still may be out of alignment vertically.

15 Using the plumb bob, or other suitable weight, and a length of string, check the rear wheel to make sure it is vertical. To do this, hold the string against the tire upper sidewall and allow the weight to settle just off the floor. When the string touches both the upper and lower tire sidewalls and is perfectly straight, the wheel is vertical. If it is not, place thin spacers under one leg of the centerstand.

16 Once the rear wheel is vertical, check the front wheel in the same manner. If both wheels are not perfectly vertical, the frame and/or major suspension components are bent.

11 Front wheel - removal, inspection and installation

Refer to illustrations 11.2, 11.4, 11.5a, 11.5b and 11.6

Removal

1 Place the motorcycle on the centerstand (if equipped). If the bike doesn't have a centerstand, support it securely so it can't be knocked over during this procedure. Raise the front wheel off the ground by placing a floor jack, with a wood block on the jack head, under the engine.


2 Remove the axle nut on the left side (**see illustration**).

3 Unscrew the speedometer cable from the drive unit on the right side of the axle.


4 Loosen the axle clamp bolt (**see illustration**).

5 Support the wheel, then insert a punch or similar tool into the hole in the right side of the axle and pull it out (**see illustrations**).


6 Carefully lower the wheel until the brake disc clears the caliper. It will probably be necessary to tilt the wheel to one side to allow removal. Don't lose the spacer that fits into the right side of the hub (**see illustration**). **Caution:** Don't lay the wheel down and allow it to rest on the disc - the disc could become warped. Set the wheel on wood blocks so the disc doesn't support the weight of the wheel. If the axle is




9.5 Look for punch marks on the pedal and shaft (arrows); make your own if they aren't visible




11.2 Remove the nut from the left end of the axle




11.4 Loosen the axle clamp bolt




11.5a Insert a punch or similar tool into the hole in the axle . . .




11.5b . . . and use the tool to pull the axle out



11.6 Remove the spacer from the wheel (arrow)



11.9a Line up the lugs in the speedometer gear assembly with the notches in the speedometer drive (arrows) . . .



11.9b . . . and install the speedometer gear assembly on the wheel

corroded, remove the corrosion with fine emery cloth. **Note:** Do not operate the front brake lever with the wheel removed. To prevent accidental operation of the brake, slip a piece of wood between the brake pads.

Inspection

- 7 Check the axle for straightness (Section 12, Step 8).
- 8 Check the condition of the wheel bearings (see Section 13).

Installation


Refer to illustrations 11.9a and 11.9b

- 9 Installation is the reverse of removal. Apply a thin coat of grease


to the seal lip, then slide the spacer into the right side of the hub. Position the speedometer drive unit in place in the left side of the hub (if it was removed), then slide the wheel into place. Make sure the notches in the speedometer drive assembly in the wheel line up with the lugs in the drive unit (**see illustrations**). If the disc will not slide between the brake pads, remove the wheel and carefully pry them apart with a piece of wood.

- 10 Slip the axle into place, then tighten the axle nut to the torque listed in this Chapter's Specifications. Tighten the right side axle clamp bolt to the torque listed in this Chapter's Specifications.


- 11 Apply the front brake, pump the forks up and down several times and check for binding and proper brake operation.




12.2 Remove the cotter pin (split pin) from the axle nut (arrow); use a new one during installation



12.3 Loosen the locknut on each drive belt adjuster, then loosen the adjuster bolts all the way so the adjusters are loose



12.5 Slip the drive belt off the pulley



12.6 Note the location of the spacer (left arrow) on each side of the wheel, then remove the axle nut and the washer (right arrow)

12 Rear wheel - removal, inspection and installation

Refer to illustrations 12.2, 12.3, 12.5, 12.6 and 12.7

Removal

- 1 Set the bike on its centerstand (if equipped).
- 2 Remove the cotter pin (split pin) from the axle nut and loosen the nut (see illustration).
- 3 Loosen the belt adjusting bolt locknuts and fully loosen both adjusting bolts (see illustration).
- 4 Unscrew the brake free play adjusting nut from the cable's threaded end (see illustration 9.3a and 9.3b). Slide out the pin and disconnect the brake cable from the cam lever. Remove the cotter pin (split pin) from the torque link nut, then remove the nut and disconnect the torque link from the brake panel (see Section 6 if necessary).
- 5 Push the rear wheel as far forward as possible. Lift the top of the drive belt up off the rear sprocket and pull it to the left while rotating the wheel backwards (see illustration). This will disengage the belt from the pulley. **Warning:** Don't let your fingers slip between the belt and the pulley.
- 6 Remove the axle nut and the washer (see illustration). Note the location of the spacer on each side of the wheel.
- 7 Support the wheel and slide the axle out. Lower the wheel and remove it from the swingarm, being careful not to lose the spacers on either side of the hub (see illustration). **Caution:** Don't lay the wheel down and allow it to rest on the pulley - it could become warped. Set

the wheel on wood blocks so the pulley doesn't support the weight of the wheel.


Inspection

Refer to illustration 12.8

- 8 Before installing the wheel, check the axle for straightness. If the axle is corroded, first remove the corrosion with fine emery cloth. Set the axle on V-blocks and check it for runout using a dial indicator (see illustration). If the axle exceeds the maximum allowable runout limit listed in this Chapter's Specifications, it must be replaced.
- 9 Check the condition of the wheel bearings (see Section 13).


Installation

- 10 Apply a thin coat of grease to the seal lips, then slide the spacers into their proper positions on the sides of the hub.
- 11 Place the axle, washer and drive belt adjuster in the left side of the swingarm so they're ready to go when the wheel is in position.
- 12 Slide the wheel and spacers into place.
- 13 Pull the belt up over the pulley, raise the wheel and install the axle drive belt adjuster, washer and axle nut. Don't tighten the axle nut at this time.
- 14 Adjust the belt slack (see Chapter 1) and tighten the adjuster locknuts.
- 15 Tighten the axle nut to the torque listed in this Chapter's Specifications. Install a new cotter pin (split pin), tightening the axle nut an additional amount, if necessary, to align the hole in the axle with the castellations on the nut.



12.7 Rear axle and belt adjuster details

- | | |
|-----------------|-----------------|
| 1 Belt adjuster | 5 Belt adjuster |
| 2 Spacer | 6 Washer |
| 3 Axle | 7 Axle nut |
| 4 Spacer | |




13.4 Front wheel bearing and hub details

- | | |
|---------------------------------|------------------------------------|
| 1 Axle | 8 Spacer |
| 2 Collar | 9 Bearing |
| 3 Wheel cap (EN450 models only) | 10 Speedometer drive |
| 4 Seal | 11 Snap-ring |
| 5 Snap-ring | 12 Speedometer drive gear assembly |
| 6 Bearing | 13 Axle nut |
| 7 Wheel | |


16 Tighten the torque link nut to the torque listed in this Chapter's Specifications and install a new cotter pin (split pin).

17 The remainder of installation is the reverse of the removal steps.

18 Check the operation of the brakes carefully before riding the motorcycle.



12.8 Check the axle for runout using a dial indicator and V-blocks



13.6 Once the snap-rings have been removed, drive the bearings from the hub with a brass drift and hammer

13 Wheel bearings - inspection and maintenance

1 The front wheel uses two ball bearings, which are permanently lubricated and sealed on both sides. The rear wheel hub uses two ball bearings, which are sealed on the outer side. The drive belt pulley coupling uses one unsealed ball bearing.

2 Set the bike on its centerstand (if equipped). If the bike doesn't have a centerstand, support it securely so it can't be knocked over during this procedure. Remove the wheel (see Section 11 or 12).

3 Set the wheel on blocks so as not to allow the weight of the wheel to rest on the brake disc or pulley.

Front wheel bearings

Refer to illustrations 13.4 and 13.6

4 Remove the speedometer gear housing and collar, brake disc (see Section 4), snap-ring and speedometer drive (see illustration). If you're working on an EN450 model, remove the wheel cap.

5 Pry out the grease seal from the right side. Remove the remaining snap-ring.

6 Insert a brass drift from the right side of the hub and tap evenly around the inner race of the opposite bearing to remove it (see illustration). Remove the bearing spacer, then remove the remaining bearing in the same way.


7 Thoroughly clean the inside of the hub with high-flash point solvent and blow it out with compressed air, if available.

8 Drive in the new bearings with a bearing driver or a socket the same diameter as the bearing outer race. Don't forget to install the spacer after you've installed the first bearing.


9 Install a new snap-ring on the right-hand side and make sure it seats securely in its groove.

10 Tap in a new grease seal evenly, using a bearing driver or a socket the same diameter as the seal, until it stops at the snap-ring.


11 The remainder of installation is the reverse of the removal steps. Use a new snap-ring for the speedometer drive.



13.12a Remove the coupling collar; don't forget to reinstall it during assembly



13.13 Pry the grease seal out to expose the bearing



13.14 Drive the bearing out from this side

Sprocket coupling bearing


Refer to illustrations 13.12a, 13.12b, 13.13, 13.14 and 13.17

12 Lift the coupling out of the rear wheel and remove the coupling collar (see illustrations).

13 Pry the grease seal out of the coupling to expose the bearing (see illustration).


14 Tap against the back side of the bearing with a bearing driver or a socket to drive it out of the coupling (see illustration).

15 Thoroughly clean the bearing with solvent. Blow it dry with



13.12b Rear wheel and coupling bearing details

- | | |
|-------------------|--------------------|
| 1 Snap-ring | 8 Coupling |
| 2 Wheel bearing | 9 Coupling bearing |
| 3 Wheel | 10 Grease seal |
| 4 Spacer | 11 Spacer |
| 5 Wheel bearing | 12 Bolt |
| 6 Damper | 13 Wheel stud |
| 7 Coupling collar | |



13.17 Pack grease (A) into the bearing until it's full

compressed air, if available, but don't spin the bearing with compressed air while it's dry. Hold the inner race with fingers and spin the outer race. If the bearing feels rough, loose, or makes noise (more than a slight whirring), replace it.

16 Drive the bearing into the coupling with a bearing driver or a socket the same diameter as the outer race.

17 Pack the bearing with grease (see illustration).

18 Tap in a new grease seal with a brass or plastic mallet (see illustration 13.13). Tap evenly so the seal doesn't tilt. If necessary, lay a block of wood across the seal so the hammer's force will be spread evenly.

19 Check the rubber damper in the rear wheel; if it shows signs of wear or deterioration it must be replaced.

Rear wheel bearings


Refer to illustration 13.21

20 If you haven't already done so, lift the sprocket coupling out of the hub.

- 21 Remove the snap-ring from the right-hand bearing (see illustration).
- 22 Insert a brass drift into the hub and place it against the opposite bearing (see illustration 13.6). Tap evenly around the inner race to drive the bearing from the hub. The bearing spacer will also come out.
- 23 Lay the wheel on its other side and remove the remaining bearing using the same technique.
- 24 Refer to Step 15 and inspect the bearings.
- 25 If the bearings check out okay and will be reused, wash them in solvent once again and dry them, then pack the bearings from the open side with medium weight, lithium-based multi-purpose grease.
- 26 Thoroughly clean the hub area of the wheel. Install the right-hand bearing into the recess in the hub, with the marked or shielded side facing out. Using a bearing driver or a socket large enough to contact the outer race of the bearing, drive it in until the snap-ring groove is visible. Install the snap-ring.
- 27 Turn the wheel over and install the bearing spacer and bearing, driving the bearing into place as described in Step 25.
- 28 Press a little grease into the bearing in the rear wheel coupling (if you haven't just repacked it). Install the coupling to the wheel, making sure the coupling collar is located in the inside of the inner race (between the wheel and the coupling).
- 29 The remainder of installation is the reverse of the removal steps.

14 Tubeless tires - general information

- 1 Tubeless tires are used as standard equipment on this motorcycle. They are generally safer than tube-type tires but if problems do occur they require special repair techniques.
- 2 The force required to break the seal between the rim and the bead of the tire is substantial, and is usually beyond the capabilities of



13.21 Remove the snap-ring

an individual working with normal tire irons.

3 Also, repair of the punctured tire and replacement on the wheel rim requires special tools, skills and experience that the average do-it-yourselfer lacks.

4 For these reasons, if a puncture or flat occurs with a tubeless tire, the wheel should be removed from the motorcycle and taken to a dealer service department or a motorcycle repair shop for repair or replacement of the tire.

The accompanying illustration can be used as a guide for tire replacement in an emergency.

Chapter 8 Frame and bodywork

Contents

Footpegs and brackets - removal and installation.....	3	Rear fender/mudguard (EN500 models) - removal	
Frame - inspection and repair.....	2	and installation.....	10
Front fender/mudguard - removal and installation.....	8	Rear view mirrors - removal and installation.....	5
General information.....	1	Seat - removal and installation.....	6
Rear fender/mudguard (EN450 models) - removal		Side and centerstand - maintenance.....	4
and installation.....	9	Side covers - removal and installation.....	7

1 General information


Refer to illustrations 1.1a, 1.1b, 1.1c and 1.1d

The machines covered by this manual use a backbone frame, constructed of steel tubing. This Chapter covers the procedures necessary to remove and install the side covers and other body parts (**see illustrations**). Since many service and repair operations on these motorcycles require removal of the side covers and/or other body parts, the procedures are grouped here and referred to from other Chapters.

2 Frame - inspection and repair


1 The frame should not require attention unless accident damage has occurred. In most cases, frame replacement is the only satisfactory remedy for such damage. A few frame specialists have the jigs and other equipment necessary for straightening the frame to the required standard of accuracy, but even then there is no simple way of assessing to what extent the frame may have been over stressed.

2 After the machine has accumulated a lot of miles, the frame




1.1a Frame and body details (EN450 models) - part one of two

- 1 Front side covers
- 2 Frame
- 3 Battery hold-down
- 4 Battery case
- 5 Centerstand
- 6 Sidestand
- 7 Passenger's footpeg
- 8 Rider's footpeg
- 9 Rear side cover
- 10 Front fender/mudguard




1.1b Frame and body details (EN450 models) - part two of two

- | | | |
|------------------------|---|---------------------------------------|
| 1 Seat back pad | 7 Rear fender rear section (US and Canadian models) | 10 Rear fender/mudguard front section |
| 2 Grab handle | 8 Rear mudguard rear section (UK models) | 11 Passenger's footpeg |
| 3 Grab handle brackets | 9 Rear mudguard extension (UK models) | 12 Rider's footpeg bracket |
| 4 Tool box and cover | | 13 Rear side cover |
| 5 Seat bracket | | 14 Seat |




1.1c Frame and body details (EN500 models) - part one of two

- | | | |
|------------------------------------|-------------------------|--------------------------------|
| 1 Mirrors (UK models) | 4 Frame | 8 Seat lock |
| 2 Mirrors (US and Canadian models) | 5 Front side covers | 9 Rider's footpeg |
| 3 Steering lock | 6 Front fender/mudguard | 10 Sidestand |
| | 7 Rear side cover | 11 Passenger's footpeg bracket |



1.1d Frame and body details (EN500 models) - part two of two


- | | | |
|-----------------|--------------------------------------|---|
| 1 Seat | 6 Seat back trim | 11 Rear fender/mudguard front section support bracket |
| 2 Tool kit | 7 Emblem | 12 Rear fender/mudguard front section |
| 3 Seat bracket | 8 Tailpiece | 13 Passenger's footpeg bracket |
| 4 Seat back pad | 9 Seat back frame | 14 Rider's footpeg bracket |
| 5 Seat back | 10 Rear fender/mudguard rear section | |



3.1 Remove the circlip (arrow) to detach the footpeg from the bracket




4.3 With the motorcycle securely supported, unhook the spring and remove the pivot bolt (arrow) to detach the sidestand



6.2 The seat mounting bolts on EN450 models are inside the tool kit holder

A Tool kit holder

B Seat bolts



6.4 On EN500 models, turn the seat lock to release the seat

should be examined closely for signs of cracking or splitting at the welded joints (see illustration 1.1a or 1.1c). Rust can also cause weakness at these joints. Loose engine mount bolts can cause ovaling or fracturing of the mounting tabs. Minor damage can often be repaired by welding, depending on the extent and nature of the damage.

3 Remember that a frame which is out of alignment will cause handling problems. If misalignment is suspected as the result of an accident, it will be necessary to strip the machine completely so the frame can be thoroughly checked.

3 Footpegs and brackets - removal and installation

Refer to illustration 3.1

1 If it's only necessary to detach the footpeg from the bracket, pry the C-clip off the pivot pin (see illustration), slide out the pin and detach the footpeg from the bracket. Be careful not to lose the spring. Installation is the reverse of removal, but be sure to install the spring correctly.

2 If it's necessary to remove the entire bracket from the frame, remove the bolts that secure the bracket to the frame, then detach the footpeg and bracket (see illustrations 1.1a through 1.1d).

3 Installation is the reverse of removal.

4 Side and centerstand - maintenance

Refer to illustration 4.3

1 The centerstand, used on EN450 models only, pivots on two bolts attached to the frame (see illustration 1.1a). Periodically, remove the pivot bolts and grease them thoroughly to avoid excessive wear.

2 Make sure the return spring is in good condition. A broken or

weak spring is an obvious safety hazard.

3 The sidestand is bolted to the frame (see illustration). An extension spring anchored to the bracket ensures that the stand is held in the retracted position.

4 Make sure the pivot bolt is tight and the extension spring is in good condition and not over stretched. An accident is almost certain to occur if the stand extends while the machine is in motion.

5 Rear view mirrors - removal and installation

1 To remove a mirror, loosen its locknut. Unscrew the mirror from the bracket on the handlebar.

2 Installation is the reverse of removal. Position the mirror.

6 Seat - removal and installation

EN450 models

Refer to illustration 6.2

1 Open the tool kit holder behind the seat.

2 Remove two mounting bolts and washers and lift the seat off (see illustration).

3 Installation is the reverse of removal.

EN500 models

Refer to illustration 6.4

4 Turn the seat lock clockwise to unlock it (see illustration).

5 Unhook the seat at the front, then push it forward and unhook the

center and rear. Lift the seat off.

6 To install the seat, engage the rear and center hooks securely in their brackets, then engage the front hook.

7 Side covers - removal and installation

1 Remove the side cover mounting screw(s) (see illustrations 1.1a through 1.1d).

2 On front side covers, disengage the cover tabs and lift the covers off.

3 On rear side covers, carefully pull the securing lugs out of the grommets and lift the cover off. **Caution:** Don't use force. If the cover won't come off with a light pull, make sure all fasteners have been removed.

4 Installation is the reverse of the removal procedure.

8 Front fender/mudguard - removal and installation

Refer to illustration 8.3

1 Set the bike on its centerstand.

2 Disconnect the speedometer cable from the speedometer drive.

3 Remove the bolts from inside the fender/mudguard (see illustration).

4 Installation is the reverse of removal.

9 Rear fender/mudguard (EN450 models) - removal and installation

Rear section

1 Set the bike on its centerstand.

2 Remove the seat (see Section 6).

3 Unplug the electrical connectors for the turn signal lights. Unbolt the seat back frame and take it off (see illustration 1.1b).

4 Remove the mounting bolts and remove the rear section of the rear fender/mudguard (see illustration 1.1b).

5 Installation is the reverse of the removal procedure.

Front section

6 Remove the rear section (see above).

7 Remove the front section mounting bolts and lift the front section out.

8 Installation is the reverse of removal. Be sure to engage the tongue on the front fender section with the groove in the frame.

10 Rear fender/mudguard (EN500 models) - removal and installation

Rear section

Refer to illustration 10.2

1 Remove the seat (see Section 6). Remove the seat back and side rails (see illustration 1.1d).

2 Disconnect the electrical connectors for the rear lights, then unbolt the seat bracket (see illustration).

3 Unbolt the fender/mudguard rear section and remove it together with the taillight assembly.

4 Installation is the reverse of the removal procedure.

Front section

Refer to illustration 10.10


5 Remove the seat (see Section 6).

6 Remove the seat mounting base from the fender rear section.


7 Remove the rear side covers (see Section 7).

8 Refer to Chapter 9 and remove the junction box, turn signal relay, battery, starter relay and the mounting bolts for the IC igniter. Note carefully how the wiring harnesses and battery vent tube are routed.


9 Support the frame securely with a jack so the bike can't fall over and remove the right rear shock absorber (see Chapter 6).



8.3 Remove the mounting bolts from inside the fender (arrows)



10.2 Unplug the electrical connectors, then remove the seat bracket bolts (arrows)



10.10 The bracket (arrow) is secured by four bolts, two at the bottom and one on each side

10 Remove the bracket that supports the fender front section (see illustration). Note that one of the bolts secures the battery negative cable. Remove the fender front section to the right.

11 Installation is the reverse of removal, with the following additions:

- Fit the boss on the front of the fender section into the hole in the frame.
- One left mounting bolt of the support bracket also secures the battery negative cable.
- Be sure the wiring harnesses and battery vent tube are routed correctly.

Chapter 9 Electrical system

Contents

Alternator - output test.....	30	Horn - check, replacement and adjustment.....	24
Alternator - removal and installation	33	Ignition main (key) switch - check and replacement.....	19
Alternator - stator coil replacement	34	Instrument and warning light bulbs - replacement	17
Alternator stator coils - continuity test	31	Instrument and warning light housings (EN500 models) - removal and installation.....	15
Battery - charging	4	Junction box (EN500 models) - check	6
Battery - inspection and maintenance	3	Lighting system - check	7
Battery electrolyte level/specific gravity check	See Chapter 1	Meters and gauges - check and replacement	16
Brake light switches - check and replacement	14	Neutral switch - check and replacement	22
Charging system - output test	29	Oil pressure switch - check and replacement.....	18
Charging system testing - general information and precautions ...	28	Sidestand switch - check and replacement.....	23
Coolant temperature gauge/light and sender unit - check and replacement	See Chapter 3	Starter clutch - removal and installation	35
Cooling fan and thermostatic switch - check and replacement	See Chapter 3	Starter motor - disassembly, inspection and reassembly.....	27
Electrical troubleshooting.....	2	Starter motor - removal and installation.....	26
Fuses - check and replacement.....	5	Starter relay and starter circuit relay - check and replacement.....	25
General information.....	1	Turn signal assemblies - removal and installation	12
Handlebar switches - check.....	20	Turn signal circuit - check.....	13
Handlebar switches - removal and installation	21	Turn signal, tail/brake light and license plate light bulbs - replacement.....	11
Headlight aim - check and adjustment	10	Voltage regulator/rectifier - check and replacement.....	32
Headlight assembly - removal and installation	9	Wiring diagrams	36
Headlight bulb - replacement.....	8		

Specifications

Battery

Type.....	12 volt, 14Ah (amp hours)
Specific gravity	See Chapter 1

Charging system

Charging system output	14 to 15 volts DC at 4000 rpm
Alternator output.....	60 volts AC at 4000 rpm
Stator coil resistance	0.3 to 0.6 ohms

Starter motor

Brush length	
EN450 models	
Standard	12 mm (15/32 inch)
Minimum	6.5 mm (17/64 inch)
EN500 models	
Standard	12 to 12.5 mm (15/32 to 31/64 inch)
Minimum	6 mm (15/64 inch)
Commutator diameter	
Standard.....	28 mm (1-7/64 inch)
Minimum.....	27 mm (1-1/16 inch)

Circuit fuse ratings

All except main fuse	10A
Main fuse	30A

Bulb wattage

.....	Refer to Wiring diagrams
-------	--------------------------

Torque specifications

Alternator rotor bolt	69 Nm (51 ft-lbs)
Alternator stator screws	12 Nm (104 in-lbs)
Oil pressure switch	15 Nm (11 ft-lbs)
Starter clutch bolts	34 Nm (25 ft-lbs)

1 General information

The machines covered by this manual are equipped with a 12-volt electrical system. The components include a crankshaft mounted permanent magnet alternator and a solid state voltage regulator/rectifier unit.

The regulator maintains the charging system output within the specified range to prevent overcharging. The rectifier converts the AC (alternating current) output of the alternator to DC (direct current) to power the lights and other components and to charge the battery.

The alternator consists of a multi-coil stator (bolted to the left-hand engine case) and a permanent magnet rotor.

An electric starter mounted to the engine case behind the cylinders is standard equipment. The starting system includes the motor, the battery, the solenoid, the starter circuit relay (part of the junction box) and the various wires and switches. If the engine stop switch and the main key switch are both in the On position, the circuit relay allows the starter motor to operate only if the transmission is in Neutral (Neutral switch on) or the clutch lever is pulled to the handlebar (clutch switch on) and the sidestand is up (sidestand switch on). **Note:** *Keep in mind that electrical parts, once purchased, can't be returned. To avoid unnecessary expense, make very sure the faulty component has been positively identified before buying a replacement part.*

2 Electrical troubleshooting

A typical electrical circuit consists of an electrical component, the switches, relays, etc. related to that component and the wiring and connectors that hook the component to both the battery and the frame. To aid in locating a problem in any electrical circuit, complete wiring diagrams of each model are included at the end of this Chapter.

Before tackling any troublesome electrical circuit, first study the appropriate diagrams thoroughly to get a complete picture of what makes up that individual circuit. Trouble spots, for instance, can often be narrowed down by noting if other components related to that circuit are operating properly or not. If several components or circuits fail at one time, chances are the fault lies in the fuse or ground connection, as several circuits often are routed through the same fuse and ground connections.

Electrical problems often stem from simple causes, such as loose or corroded connections or a blown fuse. Prior to any electrical troubleshooting, always visually check the condition of the fuse, wires and connections in the problem circuit.

If testing instruments are going to be utilized, use the diagrams to plan where you will make the necessary connections in order to accurately pinpoint the trouble spot.

The basic tools needed for electrical troubleshooting include a test light or voltmeter, a continuity tester (which includes a bulb, battery and set of test leads) and a jumper wire, preferably with a circuit breaker incorporated, which can be used to bypass electrical components. Specific checks described later in this Chapter may also require an ohmmeter.

Voltage checks should be performed if a circuit is not functioning properly. Connect one lead of a test light or voltmeter to either the negative battery terminal or a known good ground (earth). Connect the other lead to a connector in the circuit being tested, preferably nearest to the battery or fuse. If the bulb lights, voltage is reaching that point, which means the part of the circuit between that connector and the battery is problem-free. Continue checking the remainder of the circuit in the same manner. When you reach a point where no voltage is present, the problem lies between there and the last good test point. Most of the time the problem is due to a loose connection. Keep in mind that some circuits only receive voltage when the ignition key is in the On position.

One method of finding short circuits is to remove the fuse and connect a test light or voltmeter in its place to the fuse terminals. There should be no load in the circuit. Move the wiring harness from side-to-side while watching the test light. If the bulb lights, there is a short to ground somewhere in that area, probably where insulation has rubbed off a wire. The same test can be performed on other components in the

circuit, including the switch.

A ground/earth check should be done to see if a component is grounded (earthed) properly. Disconnect the battery and connect one lead of a self-powered test light (continuity tester) to a known good ground/earth. Connect the other lead to the wire or ground/earth connection being tested. If the bulb lights, the ground/earth is good. If the bulb does not light, the ground/earth is not good.

A continuity check is performed to see if a circuit, section of circuit or individual component is capable of passing electricity through it. Disconnect the battery and connect one lead of a self-powered test light (continuity tester) to one end of the circuit being tested and the other lead to the other end of the circuit. If the bulb lights, there is continuity, which means the circuit is passing electricity through it properly. Switches can be checked in the same way.

Remember that all electrical circuits are designed to conduct electricity from the battery, through the wires, switches, relays, etc. to the electrical component (light bulb, motor, etc.). From there it is directed to the frame (ground/earth) where it is passed back to the battery. Electrical problems are basically an interruption in the flow of electricity from the battery or back to it.

3 Battery - inspection and maintenance

1 Most battery damage is caused by heat, vibration, and/or low electrolyte levels, so keep the battery securely mounted, check the electrolyte level frequently and make sure the charging system is functioning properly.

2 Refer to Chapter 1 for electrolyte level and specific gravity checking procedures.

3 Check around the base inside of the battery for sediment, which is the result of sulfation caused by low electrolyte levels. These deposits will cause internal short circuits, which can quickly discharge the battery. Look for cracks in the case and replace the battery if either of these conditions is found.

4 Check the battery terminals and cable ends for tightness and corrosion. If corrosion is evident, remove the cables from the battery and clean the terminals and cable ends with a wire brush or knife and emery paper. Reconnect the cables and apply a thin coat of petroleum jelly to the connections to slow further corrosion.

5 The battery case should be kept clean to prevent current leakage, which can discharge the battery over a period of time (especially when it sits unused). Wash the outside of the case with a solution of baking soda and water. Do not get any baking soda solution in the battery cells. Rinse the battery thoroughly, then dry it.

6 If acid has been spilled on the frame or battery box, neutralize it with the baking soda and water solution, dry it thoroughly, then touch up any damaged paint. Make sure the battery vent tube is directed away from the frame and is not kinked or pinched.

7 If the motorcycle sits unused for long periods of time, disconnect the cables from the battery terminals. Refer to Section 4 and charge the battery approximately once every month.

4 Battery - charging

1 If the machine sits idle for extended periods or if the charging system malfunctions, the battery can be charged from an external source.


2 To properly charge the battery, you will need a charger of the correct rating, a hydrometer, a clean rag and a syringe for adding distilled water to the battery cells.

3 The maximum charging rate for any battery is 1/10 of the rated amp/hour capacity. As an example, the maximum charging rate for a 14 amp/hour battery would be 1.4 amps. If the battery is charged at a higher rate, it could be damaged.

4 Do not allow the battery to be subjected to a so-called quick charge (high rate of charge over a short period of time) unless you are prepared to buy a new battery.

5 When charging the battery, always remove it from the machine and be sure to check the electrolyte level before hooking up the charger. Add distilled water to any cells that are low.


6 Loosen the cell caps, hook up the battery charger leads (red to



5.1a Most of the EN450 fuses are mounted inside a dummy horn; the cover contains a spare fuse

A Cover


B Fuses




5.1b The EN450 main fuse and a spare are located under the seat

A Fuse holder

B Spare fuse



5.2a Most of the EN500 fuses, including the spares, are located on the junction box



5.2b The EN500 main fuse is located on the starter relay . . .

positive, black to negative), cover the top of the battery with a clean rag, then, and only then, plug in the battery charger. **Warning:** Remember, the gas escaping from a charging battery is explosive, so keep open flames and sparks well away from the area. If the gas ignites, the entire battery can explode and spray acid. Also, the electrolyte is extremely corrosive and will damage anything it comes in contact with.

7 Allow the battery to charge until the specific gravity is as specified (refer to Chapter 1 for specific gravity checking procedures). The charger must be unplugged and disconnected from the battery when making specific gravity checks. If the battery overheats or gases excessively, the charging rate is too high. Either disconnect the charger or lower the charging rate to prevent damage to the battery.

8 If one or more of the cells do not show an increase in specific gravity after a long slow charge, or if the battery as a whole does not seem to want to take a charge, it is time for a new battery.


9 When the battery is fully charged, unplug the charger first, then disconnect the leads from the battery. Install the cell caps and wipe any electrolyte off the outside of the battery case.

5 Fuses - check and replacement

Refer to illustrations 5.1a, 5.1b., 5.2a, 5.2b, 5.2c and 5.4

1 On EN450 models, most of the fuses are located in a fuse box (dummy horn) below the headlight (see illustration). The fuse box cover contains a spare fuse. The main fuse is located in a holder under the seat and its spare fuse is next to it (see illustration).


2 On EN500 models, all of the fuses except the main fuse are located under the seat, on the junction box (see illustration). The main fuse is located on the starter relay (see illustrations). The fuses on the junction box are protected by a plastic cover, which snaps into place. This box contains fuses (and spares) which protect the fan, headlight, taillight and accessory circuit wiring and components from damage caused by short circuits.



5.2c . . . remove the cover for access to the fuse

A Fuse

B Starter relay terminals



5.4 A blown "plug-in" type fuse can be identified by a broken element - be sure to replace a blown fuse with one of the same amperage rating

3 If you have a test light, the fuses can be checked without removing them. Turn the ignition to the On position, connect one end of the test light to a good ground (earth), then probe each terminal on top of the fuse. If the fuse is good, there will be voltage available at both terminals. If the fuse is blown, there will only be voltage present at one of the terminals.

4 The 'plug-in' type fuses used on the EN500 can be pulled from position. If you can't pull the fuse out with your fingertips, use a pair of needle-nose pliers. A blown fuse is easily identified by a break in the element (see illustration).

5 If a fuse blows, be sure to check the wiring harnesses very carefully for evidence of a short circuit. Look for bare wires and chafed, melted or burned insulation. If a fuse is replaced before the cause is located, the new fuse will blow immediately.


6 Never, under any circumstances, use a higher rated fuse or bridge the fuse block terminals, as damage to the electrical system - including melted wires, ruined components, and fire - could result.

7 Occasionally a fuse will blow or cause an open circuit for no obvious reason. Corrosion of the fuse ends and fuse block terminals may occur and cause poor fuse contact. If this happens, remove the corrosion with a wire brush or emery paper, then spray the fuse end and terminals with electrical contact cleaner.

6 Junction box (EN500 models) - check

Refer to illustrations 6.1, 6.2a, 6.2b and 6.2c

1 The junction box is used on EN500 models only to house the starter circuit relay (not the starter relay) and the headlight relay (US and Canada only) (see illustration). Neither of these relays is replaceable



6.1 To remove the junction box, remove the mounting bolt (arrow), slide it out of its holder and disconnect the electrical connectors

individually. If one of them fails, the junction box must be replaced.

2 In addition to the relay checks, the fuse circuits and diode circuits should be checked also, to rule out the possibility of an open circuit condition or blown diode within the junction block as the cause of an electrical problem. Schematics of the junction box and a terminal identification chart can be found in the accompanying illustrations (see illustrations).

Fuse circuit check

Refer to illustration 6.4

3 Remove the junction box mounting bolt and slide it out of its holder (see illustration 6.1). Unplug the electrical connectors from the box.


4 If the terminals are dirty or bent, clean and straighten them. Using the accompanying table as a guide, check the continuity across the indicated terminals with an ohmmeter - some should have no resistance and others should have infinite resistance (see illustration).

5 If the resistance values are not as specified, replace the junction box.


Diode circuit check

6 Remove the junction box mounting bolt and slide it out of its holder (see illustration 6.1). Unplug the electrical connectors from the box.


7 Using an ohmmeter, check the resistance across the following pairs of terminals, then write down the readings.




6.2a Junction box terminal and circuit identification (US and Canadian models)



6.2b Junction box terminal and circuit identification (UK models)



10-Pin Connector



8-Pin Connector

6.2c Junction box terminal pin numbers

Relay Circuit Inspection (with the battery disconnected)

	Meter Connection	Meter Reading(Ω)
Headlight Relay	*7 - 8	∞
	*7 - 13	∞
Starter Relay	11 - 13	∞
	12 - 13	∞

*US, Canadian models only

6.10a With the junction box unplugged, there should be infinite resistance between the indicated terminals

Here are the terminal pairs to be checked:
 13 and 8 (US and Canadian models only)
 13 and 9 (US and Canadian models only)
 12 and 14
 15 and 14
 16 and 14

8 Now, reverse the ohmmeter leads and check the resistances again, writing down the readings. The resistances should be low in one direction and at least ten times as high in the other direction. If the readings for any pair of terminals are low or high in both directions, a diode is defective and the junction box must be replaced.

Relay checks

Refer to illustrations 6.10a and 6.10b

9 Remove the junction box mounting bolt and slide it out of its holder (see illustration 6.1). Unplug the electrical connectors from the box.

10 Using an ohmmeter, check the continuity across the terminals indicated in the accompanying table (see illustration). Then, energize each relay by applying battery voltage across the indicated terminals

Fuse Circuit Inspection

Meter Connection	Meter Reading(Ω)
1 - 2	0
1 - 3 A/B	0
6 - 7	0
6 - 17	0
1 - 7	∞
3 A/B - 8	∞
8 - 17	∞

6.4 Using an ohmmeter, check the continuity across the indicated pairs of terminals

Relay Circuit Inspection (with the battery connected)

	Meter Connection	Battery Connection + -	Meter Reading (Ω)
Headlight	*7 - 8	9 - 13	0
Starter	11 - 13	11 - 12	0

*US, Canadian Models only


6.10b Use jumper wires to connect battery voltage to the indicated terminals, then check the continuity across the indicated terminals - the resistance should be zero

and check the continuity across the corresponding terminals shown on the table (see illustration).

11 If the junction box fails any of these tests, it must be replaced.


7 Lighting system - check

1 The battery provides power for operation of the headlight, tail-light, brake light, license plate light and instrument cluster lights. If none of the lights operate, always check battery voltage before proceeding. Low battery voltage indicates either a faulty battery, low battery electrolyte level or a defective charging system. Refer to Chapter 1 for battery checks and Sections 28 through 32 for charging system tests. Also, check the condition of the fuses and replace any blown fuses with new ones.



8.1 The headlight assembly is secured by one screw on either side (the upper forward screw is for headlight horizontal adjustment)

A Mounting screws



8.3 The bulb holder is held in place by this retaining clip

Headlight


2 If the headlight is out when the engine is running (US, Canadian models) or with the lighting switch On (UK models), check the fuse first with the key On (see Section 5), then unplug the electrical connector for the headlight and use jumper wires to connect the bulb directly to the battery terminals. If the light comes on, the problem lies in the wiring or one of the switches in the circuit. Refer to Sections 19 and 20 for the switch testing procedures, and also the wiring diagrams at the end of this Chapter. On US and Canadian models also check the headlight relay in the junction box (Section 6).

3 US and Canadian EN450 models use an additional relay in the system, called the reserve lighting unit. On these models, the headlight doesn't come on when the ignition switch is first turned on, but comes on when the starter button is pressed and stays on until the ignition is turned off. The light will go out whenever the starter is operated after the engine has stalled (this prevents excessive strain on the battery). This component is checked by process of elimination (if all other parts and circuits in the lighting system are good, the reserve lighting device is defective). For this reason, it's a good idea to have a Kawasaki dealer check the lighting system before replacing the reserve lighting device. Refer to the illustration on page 9-23 for a circuit diagram of the system.


Taillight/license plate light

4 If the taillight fails to work, check the bulbs and the bulb terminals first, then check for battery voltage at the red wire in the taillight. If voltage is present, check the ground (earth) circuit for an open or poor connection.

5 If no voltage is indicated, check the wiring between the taillight and the main (key) switch, then check the switch.



8.2 Pull up on the tab to lift the dust cover away from the headlight; be sure to push the dust cover all the way on after changing the bulb



8.4 Unhook the clip and move it aside, then pull the bulb holder out of the socket

Brake light

6 See Section 14 for the brake light circuit checking procedure.

Neutral indicator light

7 If the neutral light fails to operate when the transmission is in Neutral, check the fuses and the bulb (see Section 17 for bulb removal procedures). If the bulb and fuses are in good condition, check for battery voltage at the wire attached to the neutral switch on the left side of the engine. If battery voltage is present, refer to Section 22 for the neutral switch check and replacement procedures.

8 If no voltage is indicated, check the wires between the junction box and the bulb (EN500 models), the junction box and the switch (EN500 models) and between the switch and the bulb for open circuits and poor connections.

Oil pressure warning light

9 See Section 18 for the oil pressure warning light circuit check.

Coolant temperature warning light

10 See Chapter 3, Section 5 for the coolant temperature warning light circuit check.


8 Headlight bulb - replacement

Refer to illustrations 8.1, 8.2, 8.3 and 8.4


1 Remove the headlight assembly securing screw from each side of the housing, pull out the assembly and disconnect the electrical connector (see illustration).

2 Pull up the tab and remove the dust cover (see illustration).


3 Lift up the retaining clip and swing it out of the way (see illustration). **Warning:** If the headlight has just been on, let the bulb cool be-



9.3a Label the single connectors, then disconnect all of the wiring connectors inside the headlight housing



9.3b The headlight assembly on EN500 models is secured at the top by a bolt



9.5 Remove the horn bracket bolts (arrow) (left bolt shown)

fore you continue. It will be hot to enough to cause burns.

- 4 Remove the bulb holder (see illustration).
- 5 When installing the new bulb, reverse the removal procedure. Be sure not to touch the bulb with your fingers - oil from your skin will cause the bulb to overheat and fail prematurely. If you do touch the bulb, wipe it off with a clean rag dampened with rubbing alcohol.

9 Headlight assembly - removal and installation

- 1 Remove the headlight bulb holder housing (see Section 8).

EN450 models

- 2 Remove the nuts and bolts that secure the sides of the headlight assembly to the motorcycle.

EN500 models


Refer to illustrations 9.3a, 9.3b and 9.5

- 3 Disconnect the electrical connectors inside the headlight housing and remove the headlight assembly mounting bolt (see illustrations).
- 4 Remove the steering stem cover (see Chapter 6).
- 5 Disconnect the wires from the horn and remove the horn bracket bolts (see illustration). Detach the headlight assembly from the horn bracket.
- 6 Installation is the reverse of removal. Be sure the Top mark on the lens is up. Adjust the headlight aim (see Section 10).

10 Headlight aim - check and adjustment


Refer to illustrations 10.3a and 10.3b

- 1 An improperly adjusted headlight may cause problems for oncoming traffic or provide poor, unsafe illumination of the road ahead. Before adjusting the headlight, be sure to consult with local traffic



10.3a The horizontal adjusting screw on EN450 models is low on the right side of the headlight ring . . .

A Horizontal adjuster



10.3b . . . and on EN500 models it's high on the right side of the headlight ring


A Horizontal adjuster

laws and regulations.

- 2 The headlight beam can be adjusted both vertically and horizontally. Before performing the adjustment, make sure the fuel tank has at least a half tank of fuel, and have an assistant sit on the seat.
- 3 Insert a Phillips screwdriver into the horizontal adjuster screw (see illustrations), then turn the adjuster as necessary to center the beam.


EN450 models

- 4 To adjust the vertical position of the beam, remove the headlight bulb housing (see Section 9). Loosen the nuts and bolts on each side that secure the headlight bulb housing to the motorcycle, raise or



10.5 The vertical adjusting screw on EN500 models is low on the left side of the headlight ring

A Vertical adjuster



11.1b The tail/brake light lens is secured by two screws (arrows)

lower the headlight assembly as needed and reinstall the headlight bulb housing.

EN500 models

Refer to illustration 10.5

5 Insert the screwdriver into the vertical adjuster screw and turn the adjuster as necessary to raise or lower the beam (see illustration).

11 Turn signal, tail/brake light and license plate light bulbs - replacement

Refer to illustrations 11.1a, 11.1b and 11.1c

1 Remove the lens securing screw(s) and take off the lens (see illustrations).

2 Push the bulb in and turn it counterclockwise (anti-clockwise) to remove it. Check the socket terminals for corrosion and clean them if necessary. Line up the pins on the new bulb with the slots in the socket, push in and turn the bulb clockwise until it locks in place. It is a good idea to use a paper towel or dry cloth when handling the new bulb to prevent injury if the bulb should break and to increase bulb life.


3 Position the lens on the reflector and install the screws. Be careful not to overtighten them.

12 Turn signal assemblies - removal and installation


Refer to illustrations 12.3 and 12.4

1 The turn signal assemblies can be removed individually in the event of damage or failure.


2 To remove a turn signal assembly, first follow the wiring harness from the turn signal to its electrical connectors. Mark the wires with



11.1a Turn signal lenses are secured by one or two screws (arrow)



11.1c The license plate light lens is secured by two screws



12.3 Turn signal assembly details (EN450 models)

pieces of numbered tape then unplug the electrical connectors.


3 If you're working on an EN450 model, remove the mounting screw and washer (see illustration).

4 If you're working on an EN500 model, remove the upper triple clamp (see Chapter 6) or the rear seat back support bracket (see Chapter 8). Unscrew the nut that secures the turn signal to the triple clamp or bracket (see illustration).

5 Installation is the reverse of the removal procedure.


13 Turn signal circuit - check

1 The battery provides power for operation of the signal lights, so if they do not operate, always check the battery voltage and specific gravity first. Low battery voltage indicates either a faulty battery, low electrolyte level or a defective charging system. Refer to Chapter 1 for battery checks and Sections 28 through 32 for charging system tests. Also, check the fuses (see Section 5).



12.4 The turn signals on EN500 models are secured by a nut inside the triple clamp or seat back support bracket

- A Warning light harness
- B Speedometer harness
- C Speedometer cable
- D Turn signal assembly mounting nut



15.2 Instrument housing mounting bolts (EN500 models)

2 Most turn signal problems are the result of a burned out bulb or corroded socket. This is especially true when the turn signals function properly in one direction, but fail to flash in the other direction. Check the bulbs and the sockets (see Section 11).


3 If the bulbs and sockets check out okay, refer to the *wiring diagrams* at the end of this Chapter and check for power at the turn signal relay with the ignition On. On EN450 models, it's under the seat on the right side of the motorcycle; on EN500 models it's on the battery cover. If there's no power at the relay, check the junction box (EN500 models) (see Section 6) and the switch (see Section 21).

4 If the junction box and switch are okay, check the wiring between the turn signal relay and the turn signal lights (see the *wiring diagrams* at the end of this Chapter).

5 If the wiring checks out okay, replace the turn signal relay.

6 The EN450 A1 through A4 models have self cancelling turn signals. The circuit comprises the distance sensor in the speedometer and the turn signal control unit mounted on the electrical components plate under the seat (see the illustration on page 9-23). If a fault occurs in the self cancelling function, and the turn signals function normally when operated manually, check the distance sensor, control unit, and their associated wiring to the handlebar switch.

7 The distance sensor can be checked by disconnecting its wiring at the connector (which can be accessed from the headlight housing) and connecting an ohmmeter across the red and green wires on the sensor side of the connector. Disconnect the speedometer drive cable at the wheel end and have an assistant turn the inner cable slowly while you observe the meter reading. If the sensor is functioning correctly, the ohmmeter should show continuity four times per cable revolution.



14.6 The brake light switch mounted on the brake lever is retained by a screw

- 8 There is no test procedure for the turn signal control unit; if the fault cannot be traced to the distance sensor, switch or wiring, the control unit should be replaced.

14 Brake light switches - check and replacement

Circuit check

- 1 Before checking any electrical circuit, check the fuses (see Section 5).
- 2 Using a test light (or voltmeter) connected to a good ground (earth), check for voltage at the brown wire terminal in the electrical connector at the brake light switch. If there's no voltage present, check the brown wire between the switch and the main (key) switch (EN450 models) or between the switch and the junction box (EN500 models) (see the *wiring diagrams* at the end of this Chapter).
- 3 If voltage is available, touch the probe of the test light to the other terminal of the switch, then pull the brake lever or depress the brake pedal - if the test light doesn't light up, replace the switch.
- 4 If the test light does light, check the wiring between the switch and the brake lights (see the *wiring diagrams* at the end of this Chapter).

Switch replacement

Brake lever switch

Refer to illustration 14.6

- 5 Unplug the electrical connectors from the switch.
- 6 Remove the mounting screw (see illustration) and detach the switch from the brake lever bracket/front master cylinder.
- 7 Installation is the reverse of the removal procedure. The brake lever switch isn't adjustable.


Brake pedal switch

- 8 Locate the switch at the brake pedal, follow its wiring harness to the electrical connector and disconnect it.
- 9 Loosen the adjuster nut and unscrew the switch.
- 10 Install the switch by reversing the removal procedure.
- 11 Adjust the switch by following the procedure described in Chapter 1.

15 Instrument and warning light housings (EN500 models) - removal and installation

Refer to illustration 15.2

- 1 Disconnect the electrical connectors from the temperature gauge (if equipped), speedometer and warning light harnesses (see illustration 12.4).
- 2 Disconnect the speedometer cable and remove the instrument mounting bolts (see illustration), then detach the housings from the



16.4a Instrument cluster details (EN450 models)

bracket. **Caution:** Keep the gauge(s) in an upright position while it's off the motorcycle or the gauges will be ruined.

3 Installation is the reverse of the removal procedure.

16 Meters and gauges - check and replacement

Check

Temperature gauge (if equipped)

1 Refer to Chapter 3 for the temperature gauge checking procedure.

Speedometer and tachometer (if equipped)


2 Special instruments are required to properly check the operation of these meters. Take the instrument cluster to a Kawasaki dealer service department or other qualified repair shop for diagnosis.

Gauge replacement

Refer to illustrations 16.4a and 16.4b

3 If you're working on an EN500 model, remove the handlebar (see Chapter 6).

4 Remove the screws that secure the instrument housings (see illustrations). Remove the gauge mounting fasteners and remove the gauge from the housing. **Caution:** Always store the cluster with the



16.4b Instrument cluster details (EN500 models)

gauges facing up or the gauges will be ruined.

5 Installation is the reverse of the removal procedure.

Speedometer cable replacement

6 Disconnect the speedometer cable from the cluster (see illustration 12.4).

7 Disconnect the lower end of the speedometer cable from the drive at the front wheel. Note carefully how the cable is routed, then remove it.

8 Installation is the reverse of the removal steps.

17 Instrument and warning light bulbs - replacement

1 To replace a bulb, pull the appropriate rubber socket out of the back of the instrument housing, then pull the bulb out of the socket. If the socket contacts are dirty or corroded, they should be scraped clean and sprayed with electrical contact cleaner before new bulbs are installed.

2 Carefully push the new bulb into position, then push the socket into the instrument housing.


18 Oil pressure switch - check and replacement

Refer to illustration 18.2

1 If the oil pressure warning light fails to operate properly, check the oil level and make sure it is correct.

2 If the oil level is correct, disconnect the wire from the oil pressure switch, which is located on the left side of the oil pan near the front of the engine (see illustration). Turn the main switch On and ground/earth the end of the wire. If the light comes on, the oil pressure switch is defective and must be replaced with a new one (only after draining the engine oil).

3 If the light does not come on, check the oil pressure warning light bulb, the wiring between the oil pressure switch and the light, and between the light and the main (key) switch (EN450 models) or between the light and the junction box (EN500 models) (see the wiring diagrams at the end of this Chapter).



18.2 The oil pressure switch is mounted in the oil pan on the left side of the engine near the front

Ignition Switch Connections

	BR	W	Y	BL	R
OFF					
ON	○	○	○	○	○
P(Park)		○			○

19.2b ... and this is the EN500 continuity diagram

4 To replace the switch, drain the engine oil (see Chapter 1) and unscrew the switch from the oil pan. Coat the threads of the new switch with a non-permanent thread locking agent (not sealant), then screw the unit into its hole, tightening it to the torque listed in this Chapter's Specifications.

5 Fill the crankcase with the recommended type and amount of oil (see Chapter 1) and check for leaks.

19 Ignition main (key) switch - check and replacement

Check

Refer to illustrations 19.2a and 19.2b

- 1 Disconnect the ignition switch electrical connector.
- 2 Using an ohmmeter, check the continuity of the terminal pairs indicated in the accompanying table (see illustrations). Continuity should exist between the terminals connected by a solid line when the switch is in the indicated position.
- 3 If the switch fails any of the tests, replace it.

Replacement


Refer to illustration 19.6

- 4 Remove bodywork components as necessary for access to the switch mounting screws.
- 5 If you haven't already done so, unplug the switch electrical connector.
- 6 The switch is held to the upper triple clamp with two shear-head bolts. Using a hammer and a sharp punch, knock the shear-head bolts in a counterclockwise (anti-clockwise) direction to unscrew them (see illustration). If they're too tight and won't turn, carefully drill holes through the centers of the bolts and unscrew them using a screw extractor (E-Z Out). Detach the switch from the upper triple clamp.
- 7 Hold the new switch in position and install the new shear-head bolts. Tighten the bolts until the heads break off.
- 8 The remainder of installation is the reverse of the removal steps.

Ignition Switch Connections

	BR/W	W	Y	BL	R
OFF, LOCK					
ON	○	○	○	○	○
P (Park)		○			○

19.2a Check the continuity of the ignition switch in the different switch positions across the indicated terminals - this is the EN450 continuity diagram ...



19.6 The shear-head bolts (arrows) must be carefully drilled and removed with a screw extractor or knocked in a counterclockwise (anti-clockwise) direction with a hammer and punch

20 Handlebar switches - check

Refer to illustrations 20.4a and 20.4b

- 1 Generally speaking, the switches are reliable and trouble-free. Most troubles, when they do occur, are caused by dirty or corroded contacts, but wear and breakage of internal parts is a possibility that should not be overlooked. If breakage does occur, the entire switch and related wiring harness will have to be replaced with a new one, since individual parts are not usually available.
- 2 The switches can be checked for continuity with an ohmmeter or a continuity test light. Always disconnect the battery ground/earth cable, which will prevent the possibility of a short circuit, before making the checks.
- 3 Trace the wiring harness of the switch in question and unplug the electrical connectors.
- 4 Using the ohmmeter or test light, check for continuity between the terminals of the switch harness with the switch in the various positions (see illustrations). Continuity should exist between the terminals connected by a solid line when the switch is in the indicated position.

Headlight Switch Connections (Other than US, Canada)

	R/W	R/BL	BL	BL/Y
OFF				
□	○	○		
ON	○	○	○	○

Oil Pressure Switch Connections*

	SW. Terminal	///
When engine is stopped	○	○
When engine is running		

* : Engine lubrication system is in good condition.

Horn Button Connections

	BK/W	BK/Y
Free		
Push on	○	○

Engine Stop Switch Connections

	R	Y/R
OFF		
RUN	○	○

Side Stand Switch Connections

	BR/BK	G/W
When side stand is up	○	○
When side stand is down		

Rear Brake Light Switch Connections

	BR	BL
When brake pedal is pushed down	○	○
When brake pedal is released		

Starter Button Connections

	BK/R	R
Free		
Push on	○	○

Dimmer Switch Connections

	R/BK	BL/Y	R/Y
HI		○	○
LO	○	○	

Passing Button Connections

	BL	R/BK
Free		
Push on	○	○

Front Brake Light Switch Connections

	BK	BK
When brake lever is pulled in	○	○
When brake lever is released		

Neutral Switch Connections

	SW. Terminal	///
When transmission is in neutral	○	○
When transmission is not in neutral		

Turn Signal Switch Connections

	GY	O	G	W/G	W/R	BL/W	BK/Y
R	○	○			○	○	
N				○	○	○	○
L		○	○		○	○	

Starter Lockout Switch Connections

	BK/Y	BK	BK/R
When clutch lever is pulled in	○	○	
When clutch lever is released		○	○

Starter Lockout Switch Connections

	BK	BK/Y
When clutch lever is pulled in		
When clutch lever is released		

Horn Button Connections

	BK/W	BK/Y
(Free)		
ON (Push)		

Turn Signal Switch Connections

	G	O	Y
R			
N			
L			

Dimmer Switch Connections

	R/BK	BL/Y	R/Y
HI			
LO			

Front Brake Light Switch Connections

	BK	BK
When brake lever is pulled in		
When brake lever is released		

Engine Stop Switch Connections

	Y/R	R
OFF		
RUN		

Starter Button Connections

	R	BK/R
(Free)		
PUSH(Push)		

Headlight Switch Connections
(Other than US and Canada)

	R/W	R/BL	BL/Y	BL
OFF				
ON				

Oil Pressure Switch Connections*

	SW. Terminal	
When engine is stopped		
When engine is running		

* : Engine lubrication system is in good condition.

Neutral Switch Connections


	SW. Terminal	
When transmission is in neutral		
When transmission is not in neutral		

Side Stand Switch Connections

	G/W	BK/Y
When side stand is up		
When side stand is down		

Rear Brake Light Switch Connections

	BR	BL
When brake pedal is pushed down		
When brake pedal is released		



21.1 The handlebar switches are mounted inside the housings on the handlebar

5 If the continuity check indicates a problem exists, refer to Section 21, disassemble the switch and spray the switch contacts with electrical contact cleaner. If they are accessible, the contacts can be scraped clean with a knife or polished with crocus cloth. If switch components are damaged or broken, it will be obvious when the switch is disassembled.

21 Handlebar switches - removal and installation

Refer to illustrations 21.1, 21.3a and 21.3b

1 The handlebar switches are composed of two halves that clamp around the bars. They are easily removed for cleaning or inspection by taking out the clamp screws and pulling the switch halves away from the handlebars (see illustration).

2 To completely remove the switches, the mounting screws should be removed (see illustration 21.1) and the electrical connectors in the wiring harness should be unplugged.

3 When installing the switches, make sure the wiring harnesses are properly routed to avoid pinching or stretching the wires. If there's an alignment tab on the switch housing, make sure it engages with the hole in the handlebar (see illustrations).

22 Neutral switch - check and replacement


Refer to illustration 22.3

Check


- 1 Remove the shift pedal and linkage (see Chapter 2).
- 2 Remove the engine pulley cover (see Chapter 6).
- 3 Disconnect the wire from the neutral switch (see illustration). Connect one lead of an ohmmeter to a good ground (earth) and the other lead to the post on the switch.
- 4 When the transmission is in neutral, the ohmmeter should read 0 ohms - in any other gear, the meter should read infinite resistance.
- 5 If the switch doesn't check out as described, replace it. **Note:** If the neutral light works intermittently, try removing the switch and reinstalling it temporarily without its sealing washer. If the light now works consistently, the switch plunger is worn and the switch should be replaced (don't just leave the old switch in position without the washer).

Replacement


- 6 Unscrew the neutral switch from the case and remove the sealing washer.
- 7 Install the switch with a new sealing washer and tighten it securely.



21.3a There's an alignment hole for the switch housing in the handlebar (arrow) . . .



21.3b . . . be sure the tab on the switch housing (arrow) fits into the hole when the housing is installed




22.3 Location of the neutral switch (arrow)


23 Sidestand switch - check and replacement

Check


- 1 Place the bike on the centerstand.
- 2 Follow the wiring harness from the switch to the connector, then disconnect the connector.
- 3 Connect the leads of an ohmmeter to the green/white and brown/black (EN450 models) or green/white and black/yellow (EN500 models) wire terminals on the switch side of the connector.



23.7 The sidestand switch is mounted on the frame just forward of the sidestand



24.1 The horn is accessible from the front of the motorcycle - note the electrical connectors (arrow)



25.9 The mounting tabs fit into slots in the relay holder (arrows) - EN500 models

4 With the sidestand in the up position, there should be continuity through the switch (0 ohms). With the sidestand down, there should be no continuity (infinite resistance).

5 If the switch fails either of these tests, replace it.

Replacement

Refer to illustration 23.7

6 Support the bike and raise the sidestand.

7 Remove the switch mounting screws (see illustration). Follow the wiring harness to the electrical connector, unplug it and remove the switch.

8 Installation is the reverse of the removal procedure.

24 Horn - check, replacement and adjustment

Refer to illustration 24.1

Check

1 Unplug the electrical connectors from the horn (see illustration). Using two jumper wires, apply battery voltage directly to the terminals on the horn. If the horn sounds, check the switch (see Section 20) and the wiring between the switch and the horn (see the wiring diagrams at the end of this Chapter).

2 If the horn doesn't sound, replace it.

Replacement

3 Detach the electrical connectors and unbolt the horn bracket from the frame.

4 Detach the horn from the bracket and transfer the bracket to the new horn.

5 Installation is the reverse of removal.

25 Starter relay and starter circuit relay - check and replacement

Starter relay

Check


1 Remove the rear right (EN450 models) or left (EN500 models) side panel (see Chapter 8).

2 Disconnect the battery positive cable and the starter cable from the terminals on the starter relay (see illustration 5.2c). **Caution:** Don't let the battery positive cable make contact with anything, as it would be a direct short to ground/earth.

3 Connect the leads of an ohmmeter to the terminals of the starter relay.

4 Turn the ignition switch to On and the engine stop switch to Run. Place the transmission in Neutral.

5 Press the starter button - the relay should click and the ohmmeter



25.11 Starter circuit relay check (EN450 models)

should indicate 0 ohms.

6 If the meter doesn't read 0 ohms or the relay doesn't click, replace it.

Replacement

Refer to illustration 25.9

7 Disconnect the cable from the negative terminal of the battery.

8 Detach the battery positive cable, the starter cable and electrical connector from the relay.

9 Pull the relay holder off its mounting tabs (see illustration).


10 Installation is the reverse of removal. Reconnect the negative battery cable after all the other electrical connections are made.

Starter circuit relay


Refer to illustration 25.11

11 On EN450 models, the relay is a small cylindrical unit mounted in an upright position, next to the main starter relay. To check its operation, disconnect its wire connector plug and remove the relay from the motorcycle. Connect a 12V battery and ohmmeter across the relay terminals shown (see illustration). With the battery connected, the meter should indicate 0 ohms (continuity), and with the battery disconnected, high resistance (no continuity) should be indicated.


12 On EN500 models, the starter circuit relay is incorporated in the junction box; refer to the tests described in Section 6.




26.3 Pull back the covers and disconnect the starter wires (arrows)



26.4a Remove the alternator cover bolts (arrows) . . .



26.4b . . . and pull off the cover (pull firmly to overcome the pull of the rotor magnets, but don't force it)



26.5 Remove the starter chain cover bolts (arrows)

26 Starter motor - removal and installation


Refer to illustrations 26.3, 26.4a, 26.4b, 26.5, 26.6 and 26.7

Removal


- 1 Remove the fuel tank and carburetors (see Chapter 4).
- 2 Disconnect the cable from the negative terminal of the battery.
- 3 Remove the nuts retaining the starter wires to the starter (see illustration).
- 4 Remove the alternator cover bolts and pull off the cover (see illustrations). **Note:** The alternator magnets will hold the cover on. Pull firmly to remove it, but don't pry it off. If it won't come off with a firm two-hand pull, make sure you've removed all of the cover bolts.
- 5 Remove the starter chain cover (see illustration).
- 6 Remove the starter mounting bolts (see illustration).
- 7 Lift the starter up a little bit and disengage the starter sprocket from the chain (see illustration).
- 8 Check the condition of the O-ring on the end of the starter and replace it if necessary.

Installation


- 9 Apply a little engine oil to the O-ring and install the starter by reversing the removal procedure.




26.6 Remove the starter mounting bolts (arrows)



26.7 Lift the starter and disengage it from the chain




27.2a Exploded view of the starter motor (EN450 models)




27.2b Exploded view of the starter motor (EN500 models)

- | | |
|-------------------------|---------------------------|
| 1 Starter mounting bolt | 8 Housing and armature |
| 2 End cover | 9 O-ring |
| 3 Washers | 10 Reduction gear housing |
| 4 Terminal bolt and nut | 11 O-ring |
| 5 Brush plate | 12 Snap-ring |
| 6 O-ring | 13 Through-bolt |
| 7 Terminal washers | 14 Sprocket |



27.4 Remove the brush plate from the housing (EN450 model shown)



27.5 Push the terminal bolt through the housing and remove the plastic brush holder (EN450 model shown)

27 Starter motor - disassembly, inspection and reassembly

- 1 Remove the starter motor (see Section 26).

Disassembly


Refer to illustrations 27.2a, 27.2b, 27.4 and 27.5

- 2 Mark the position of the housing to each end cover. Remove the two through-bolts and detach the end and reduction covers (see illustrations).
- 3 Pull the armature out of the housing (toward the reduction gear side).
- 4 Remove the brush plate from the housing (see illustration).
- 5 Remove the nut and push the terminal bolt through the housing. Remove the two brushes with the plastic holder from the housing (see illustration).

Inspection

Refer to illustrations 27.6, 27.7, 27.8a, 27.8b, 27.9 and 27.10

- 6 The parts of the starter motor that most likely will require attention are the brushes. Measure the length of the brushes and compare the



27.6 Measure the length of the brushes and compare the length of the shortest brush with the length listed in this Chapter's Specifications



27.7 Check the commutator for cracks and discoloring, then measure the diameter and compare it with the minimum diameter listed in this Chapter's Specifications



27.8a Continuity should exist between the commutator bars



27.8b There should be no continuity between the commutator bars and the armature shaft

results to the brush length listed in this Chapter's Specifications (**see illustration**). If any of the brushes are worn beyond the specified limits, replace the brush holder assembly with a new one. If the brushes are not worn excessively, cracked, chipped, or otherwise damaged, they may be reused.

7 Inspect the commutator (**see illustration**) for scoring, scratches and discoloration. The commutator can be cleaned and polished with crocus cloth, but do not use sandpaper or emery paper. After cleaning, wipe away any residue with a cloth soaked in an electrical system cleaner or denatured alcohol. Measure the commutator diameter and compare it to the diameter listed in this Chapter's Specifications. If it is less than the service limit, the motor must be replaced with a new one.

8 Using an ohmmeter or a continuity test light, check for continuity between the commutator bars (**see illustration**). Continuity should exist between each bar and all of the others. Also, check for continuity between the commutator bars and the armature shaft (**see illustration**). There should be no continuity between the commutator and the shaft. If the checks indicate otherwise, the armature is defective.

9 Check for continuity between the brush plate and the brushes (**see illustration**). The meter should read close to 0 ohms. If it doesn't, the brush plate has an open and must be replaced.

10 Using the highest range on the ohmmeter, measure the resistance between the brush holders and the brush plate (**see illustration**). The reading should be infinite. If there is any reading at all, replace the brush plate.




27.9 There should be almost no resistance (0 ohms) between the brushes and the brush plate (EN450 model shown)


11 Check the starter reduction gears for worn, cracked, chipped and broken teeth. If the gears are damaged or worn, replace the starter motor.




27.10 There should be no continuity between the brush plate and the brush holders (the resistance should be infinite) (EN450 model shown)




27.12 Install the washers on the starter terminal as shown (EN450 model shown)



27.13 When installing the brush plate, make sure the brush leads fit into the notches in the plate (arrow) - also, make sure the tongue on the plate fits into the notch in the housing (arrows)



27.14a Install each brush spring on the post in this position (EN450 model shown) . . .



27.14b . . . then pull the end of the spring 1/2 turn clockwise and seat the end of it in the groove in the end of the brush (EN450 model shown)

Reassembly

Refer to illustrations 27.12, 27.13, 27.14a and 27.14b

12 Install the plastic brush holder into the housing. Make sure the terminal bolt and washers are assembled correctly (see illustration). Tighten the terminal nut securely.

13 Detach the brush springs from the brush plate (this will make armature installation much easier). Install the brush plate into the housing, routing the brush leads into the notches in the plate (see illustration). Make sure the tongue on the brush plate fits into the notch in the housing.

14 Install the brushes into their holders and slide the armature into place. Install the brush springs (see illustrations).

15 Install any washers that were present on the end of the armature shaft. Install the end and reduction covers, aligning the protrusions with the notches. Install the two through-bolts and tighten them securely.

28 Charging system testing - general information and precautions

1 If the performance of the charging system is suspect, the system as a whole should be checked first, followed by testing of the individual components (the alternator and the voltage regulator/rectifier). **Note:** Before beginning the checks, make sure the battery is fully charged and that all system connections are clean and tight.

2 Checking the output of the charging system and the performance of the various components within the charging system requires the use of special electrical test equipment. A voltmeter or a multimeter is the absolute minimum equipment required. In addition, an ohmmeter is generally required for checking the remainder of the system.

3 When making the checks, follow the procedures carefully to prevent incorrect connections or short circuits, as irreparable damage to electrical system components may result if short circuits occur. Because of the special tools and expertise required, it is recommended that the job of checking the charging system be left to a dealer service department or a reputable motorcycle repair shop.

29 Charging system - output test

Refer to illustration 29.3

Caution: Never disconnect the battery cables from the battery while the engine is running. If the battery is disconnected, the alternator and regulator/rectifier will be damaged.

1 To check the charging system output, you will need a voltmeter or a multimeter with a voltmeter function.

2 The battery must be fully charged (charge it from an external source if necessary) and the engine must be at normal operating temperature to obtain an accurate reading.

3 Remove the right front side cover (see Chapter 8), locate the regulator/rectifier (see illustration) and follow its wiring harness to the connector.

4 Attach the positive (red) voltmeter lead to the white/red wire terminal and the negative lead to the black/yellow wire terminal. **Caution:** The white/red wire is connected directly to the battery at all times, so don't allow the voltmeter to short this terminal to ground (earth) (don't let the voltmeter negative lead touch metal). The voltmeter selector switch (if so equipped) must be in a DC volt range greater than 15 volts.

5 Start the engine. Run it at varying speeds up to 4,000 rpm, with headlight off and with it on (for US and Canadian models, disconnect the black/yellow wire at the headlight to turn it off with the engine running).

6 The charging system output should be within the range listed in this Chapter's Specifications. It should be at the low end of the range at low engine speeds and at the high end of the range at higher engine speeds.

7 If the output is as specified, the alternator is functioning properly. If the charging system as a whole is not performing as it should, refer to Section 32 and check the voltage regulator/rectifier.

8 Low voltage output may be the result of damaged windings in the alternator stator coils, loss of magnetism in the alternator rotor or wiring problems. Make sure all electrical connections are clean and tight, then refer to Sections 30 and 31 for specific alternator tests.

30 Alternator - output test

1 Follow the wiring harness from the alternator housing to the connector, then disconnect the connector.

2 Connect a voltmeter with a 250-volt AC scale to two of the yellow wire terminals in the alternator connector (at this point, you're measuring the alternator output before it has been rectified from alternating current to direct current, so the voltmeter must be able to measure AC).

3 Run the engine at 4,000 rpm and note the voltage reading.


4 Take three different measurements between different pairs of wires. In all cases, the voltage should be as listed in this Chapter's Specifications.

a) If the voltage reading is correct, the rectifier/regulator is probably defective. Refer to Section 32 for test procedures.

b) If the voltage reading is low, the alternator may be defective. Test the stator coils as described in Section 31. If the stator coils test out OK, the rotor magnets have probably lost magnetism. This can be caused by dropping or hitting the alternator, by leaving the alternator near another source of magnetism, or by age.

31 Alternator stator coils - continuity test

1 If charging system output is low or non-existent, the alternator



29.3 The regulator/rectifier is located behind the right front side cover

stator coil windings and leads should be checked for proper continuity. The test can be made with the stator in place on the machine.

2 Using an ohmmeter (preferred) or a continuity test light, check for continuity between each of the wires coming from the alternator stator (the same connector that was disconnected in Section 30 for the output test). Continuity should exist between any one wire and each of the others (Kawasaki actually specifies a resistance of 0.3 to 0.6 ohms).

3 Check for continuity between each of the wires and the engine. No continuity should exist between any of the wires and the engine.

4 If there is no continuity between any two of the wires, or if there is continuity between the wires and an engine ground/earth, an open circuit or a short exists within the stator coils. Since repair of the stator is not feasible, it must be replaced with a new one.

32 Voltage regulator/rectifier - check and replacement

1 Remove the right front side cover (see Chapter 8).

2 Locate the regulator/rectifier, follow its harness to the connector, then detach the electrical connector (see illustration 29.3).

3 Using an ohmmeter set on R X 1000, connect the positive lead to the white/red wire and the negative lead to each yellow wire in turn and write the readings down. Switch the ohmmeter leads (negative to white/red and positive to each yellow in turn) and note the readings. The resistance should be low during one set of three measurements and at least 10 times as high during the other three measurements.

4 Repeat Step 3, using the black wire and each yellow wire (12 measurements total). Again, the readings should be low in one direction and at least 10 times as high in the other direction. If the meter readings are not as specified, replace the regulator/rectifier.

5 This check, combined with the tests outlined in Sections 29 through 31, should diagnose most charging system problems. If the voltage regulator/rectifier passes the tests described in Steps 3 and 4, and the stator coil passes the test in Section 31, take the regulator/rectifier to a dealer service department or other repair shop for further checks, or substitute a known good unit and recheck the charging system output.

33 Alternator - removal and installation


Removal

Refer to illustrations 33.3 and 33.4


1 Disconnect the cable from the negative terminal of the battery.

2 Remove the starter (see Section 26).

3 Prevent the alternator rotor from turning by holding it with Kawasaki tool no. 57001-308, a strap wrench or a pin spanner wrench.



33.3 The alternator rotor bolt has left-hand threads (turn it clockwise to loosen it)



34.2 The stator coils are secured in the housing by three Allen screws (arrows)

Alternatively, shift the transmission into gear and apply the rear brake hard with the rear tire in firm contact with the ground. Remove the rotor bolt (**see illustration**). **Note:** The bolt has left-hand threads (loosens in a clockwise direction).

4 Hold the rotor from turning again, and using tool no. 57001-254 or 57001-1099, remove the rotor from the crankshaft (**see illustration**).

5 If you're going to replace the rotor, remove the starter clutch (**see Section 35**).

Installation

6 Clean all dirt from the crankshaft and the inside of the rotor with high flash point solvent.


7 Position the rotor on the engine and install the bolt, tightening it to the torque listed in this Chapter's Specifications.

8 The remainder of installation is the reverse of the removal steps. Before you install the housing, make sure the magnets haven't picked up any pieces of metal that could damage the alternator.


34 Alternator - stator coil replacement

Refer to illustration 34.2


- 1 Remove the alternator cover (**see Section 26**).
- 2 Remove the stator screws (**see illustration**), remove the wiring harness retainer and lift the stator coils out of the alternator housing.
- 3 Installation is the reverse of the removal steps. Tighten the stator screws to the torque listed in this Chapter's Specifications.



33.4 This special tool is used to remove the alternator rotor



35.3 Remove the washer and sprocket from the end of the crankshaft



35.4a Compress the springs with a small screwdriver and remove the rollers


35 Starter clutch - removal and installation

- 1 The starter clutch is mounted on the back of the alternator rotor.

Removal

Refer to illustrations 35.3, 35.4a and 35.4b

- 2 Remove the alternator rotor (**see Section 33**).
- 3 Slide the washer and starter sprocket off the crankshaft (**see illustration**).
- 4 Pull the rollers out of the starter clutch, then remove the spring caps and springs (**see illustrations**).



35.4b Starter clutch details

Inspection

- 5 Check all parts for wear and damage. Replace any worn or damaged parts.
- 6 If you're going to replace the starter clutch housing or rotor, remove the three Allen bolts and separate the starter clutch from the rotor.


Installation

Refer to illustrations 35.8a and 35.8b


- 7 If you removed the starter clutch from the rotor, bolt it back on. Use a non-permanent thread locking agent on the threads of the Allen bolts and tighten them to the torque listed in this Chapter's Specifications.
- 8 Place the spring caps on the springs. Place the springs in their holes, compress them with a screwdriver and install the rollers (see illustrations).
- 9 Install the alternator rotor on the engine.

36 Wiring diagrams

Prior to troubleshooting a circuit, check the fuses to make sure they're in good condition. Make sure the battery is fully charged and check the cable connections.






35.8a Press the springs and caps into the holes . . .




35.8b . . . then install the rollers and release the springs

When checking a circuit, make sure all connectors are clean, with no broken or loose terminals or wires. When unplugging a connector, don't pull on the wires - pull only on the connector housings themselves.







Wiring diagram - EN500 models (US and Canada)



Wiring diagram - EN500 models (US and Canada) continued



Wiring diagram - EN500 models (UK and other markets except US and Canada)



IGNITION SWITCH CONNECTIONS					
	Ignition 1	Battery 1	Ignition 2	Tail 1	Tail 2
Color	BP	W	Y	BL	R
OFF					
ON					
P(PARK)					

RIGHT HANDLEBAR SWITCH CONNECTIONS											
Front Brake Light Switch			Engine Stop Switch			Starter Button			Headlight Switch		
Color	BK	BK	Color	Y/R	R	Color	R	BK/R	Color	R/W	R/BL
Released			OFF						OFF		
Pulled in			RUN			PUSH			ON		

(SA) : South African Model
(WG) : West German Model

Wiring diagram - EN500 models (UK and other markets except US and Canada) continued

Conversion factors

Length (distance)

Inches (in)	25.4	=	Millimetres (mm)	X 0.0394	=	Inches (in)
Feet (ft)	0.305	=	Metres (m)	X 3.281	=	Feet (ft)
Miles	1.609	=	Kilometres (km)	X 0.621	=	Miles

Volume (capacity)

Cubic inches (cu in; in ³)	X 16.387	=	Cubic centimetres (cc; cm ³)	X 0.061	=	Cubic inches (cu in; in ³)
Imperial pints (Imp pt)	X 0.568	=	Litres (l)	X 1.76	=	Imperial pints (Imp pt)
Imperial quarts (Imp qt)	X 1.137	=	Litres (l)	X 0.88	=	Imperial quarts (Imp qt)
Imperial quarts (Imp qt)	X 1.201	=	US quarts (US qt)	X 0.833	=	Imperial quarts (Imp qt)
US quarts (US qt)	X 0.946	=	Litres (l)	X 1.057	=	US quarts (US qt)
Imperial gallons (Imp gal)	X 4.546	=	Litres (l)	X 0.22	=	Imperial gallons (Imp gal)
Imperial gallons (Imp gal)	X 1.201	=	US gallons (US gal)	X 0.833	=	Imperial gallons (Imp gal)
US gallons (US gal)	X 3.785	=	Litres (l)	X 0.264	=	US gallons (US gal)

Mass (weight)

Ounces (oz)	X 28.35	=	Grams (g)	X 0.035	=	Ounces (oz)
Pounds (lb)	X 0.454	=	Kilograms (kg)	X 2.205	=	Pounds (lb)

Force

Ounces-force (ozf; oz)	X 0.278	=	Newtons (N)	X 3.6	=	Ounces-force (ozf; oz)
Pounds-force (lbf; lb)	X 4.448	=	Newtons (N)	X 0.225	=	Pounds-force (lbf; lb)
Newtons (N)	X 0.1	=	Kilograms-force (kgf; kg)	X 9.81	=	Newtons (N)

Pressure

Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X 0.070	=	Kilograms-force per square centimetre (kgf/cm ² ; kg/cm ²)	X 14.223	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X 0.068	=	Atmospheres (atm)	X 14.696	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X 0.069	=	Bars	X 14.5	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X 6.895	=	Kilopascals (kPa)	X 0.145	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)
Kilopascals (kPa)	X 0.01	=	Kilograms-force per square centimetre (kgf/cm ² ; kg/cm ²)	X 98.1	=	Kilopascals (kPa)
Millibar (mbar)	X 100	=	Pascals (Pa)	X 0.01	=	Millibar (mbar)
Millibar (mbar)	X 0.0145	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X 68.947	=	Millibar (mbar)
Millibar (mbar)	X 0.75	=	Millimetres of mercury (mmHg)	X 1.333	=	Millibar (mbar)
Millibar (mbar)	X 0.401	=	Inches of water (inH ₂ O)	X 2.491	=	Millibar (mbar)
Millimetres of mercury (mmHg)	X 0.535	=	Inches of water (inH ₂ O)	X 1.868	=	Millimetres of mercury (mmHg)
Inches of water (inH ₂ O)	X 0.036	=	Pounds-force per square inch (psi; lbf/in ² ; lb/in ²)	X 27.68	=	Inches of water (inH ₂ O)

Torque (moment of force)

Pounds-force inches (lbf in; lb in)	X 1.152	=	Kilograms-force centimetre (kgf cm; kg cm)	X 0.868	=	Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	X 0.113	=	Newton metres (Nm)	X 8.85	=	Pounds-force inches (lbf in; lb in)
Pounds-force inches (lbf in; lb in)	X 0.083	=	Pounds-force feet (lbf ft; lb ft)	X 12	=	Pounds-force inches (lbf in; lb in)
Pounds-force feet (lbf ft; lb ft)	X 0.138	=	Kilograms-force metres (kgf m; kg m)	X 7.233	=	Pounds-force feet (lbf ft; lb ft)
Pounds-force feet (lbf ft; lb ft)	X 1.356	=	Newton metres (Nm)	X 0.738	=	Pounds-force feet (lbf ft; lb ft)
Newton metres (Nm)	X 0.102	=	Kilograms-force metres (kgf m; kg m)	X 9.804	=	Newton metres (Nm)

Power

Horsepower (hp)	X 745.7	=	Watts (W)	X 0.0013	=	Horsepower (hp)
-----------------	---------	---	-----------	----------	---	-----------------

Velocity (speed)

Miles per hour (miles/hr; mph)	X 1.609	=	Kilometres per hour (km/hr; kph)	X 0.621	=	Miles per hour (miles/hr; mph)
--------------------------------	---------	---	----------------------------------	---------	---	--------------------------------

Fuel consumption*

Miles per gallon, Imperial (mpg)	X 0.354	=	Kilometres per litre (km/l)	X 2.825	=	Miles per gallon, Imperial (mpg)
Miles per gallon, US (mpg)	X 0.425	=	Kilometres per litre (km/l)	X 2.352	=	Miles per gallon, US (mpg)

Temperature

Degrees Fahrenheit = (°C x 1.8) + 32 Degrees Celsius (Degrees Centigrade; °C) = (°F - 32) x 0.56

* It is common practice to convert from miles per gallon (mpg) to litres/100 kilometres (l/100km), where mpg (Imperial) x l/100 km = 282 and mpg (US) x l/100 km = 235

Index

A

About this manual: 0-5
Acknowledgements: 0-2
Air filter, element, servicing: 1-12
Air filter housing, removal and installation: 4-11
Air suction valves, check: 1-22
Alternator
 removal and installation: 9-20
 stator coils, continuity test: 9-20
Antifreeze, draining and refilling: 1-19

B

Battery
 charging: 9-2
 check and maintenance: 1-6
 inspection and maintenance: 9-2
Balancer, removal, inspection, bearing selection and installation: 2-45
Bearings
 connecting rod, inspection and selection: 2-43
 main, inspection and selection: 2-40
 main and connecting rod, general note: 2-39
 wheel, inspection and replacement: 7-13
Belt, drive
 check and adjustment: 1-10
 removal and installation: 6-12
Block (cylinder), removal, inspection and installation: 2-20
Bodywork: 8-1 through 6
Brake
 caliper, removal, overhaul and installation: 7-3
 disc, inspection, removal and installation: 7-5
 fluid, level check: 1-5
 front master cylinder, removal, overhaul and installation: 7-5
 general information: 7-2
 hoses and lines, inspection and replacement: 7-9
 light switches, check and replacement: 9-9
 pads, replacement: 7-2
 pedal position, check and adjustment: 1-7

rear drum brakes, removal, inspection and installation: 7-7
system, check: 1-7
system bleeding: 7-8

Brakes: 7-1 through 10

Breaking-in the engine: 2-58

Bulbs

headlight, replacement: 9-6
taillight and turn signal, replacement: 9-6
warning light, replacement: 9-10

Buying parts: 0-7

C

Cable

choke, removal, installation and adjustment: 4-11
clutch, replacement: 2-32
lubrication: 1-16
throttle, removal, installation and adjustment: 4-9

Caliper (brake), removal, overhaul and installation: 7-3

Camshaft

chain, removal, inspection and installation: 2-47
chain tensioner, removal and installation: 2-8
removal, inspection and installation: 2-9

Camshaft cover (valve cover), removal and installation: 2-7

Carburetor synchronization, check and adjustment: 1-18

Carburetors

disassembly, cleaning and inspection: 4-4
fuel level adjustment: 4-9
overhaul, general information: 4-3
reassembly: 4-7
removal and installation: 4-3

Chain

camshaft, removal, inspection and installation: 2-47
guides, removal, inspection and installation: 2-47
primary, removal, inspection and installation: 2-47

Charging system

output test: 9-20
testing, general information and precautions: 9-19

Chemicals and lubricants: 0-15

Choke cable, removal, installation and adjustment: 4-11

Clutch: 2-28, 2-39

cable, replacement: 2-32

check and adjustment: 1-9

components, removal, inspection and installation: 2-28, 2-39

Coil, ignition, check, removal and installation: 5-2**Compression check: 1-13****Connecting rods and bearings**

inspection and bearing selection: 2-44

removal and installation: 2-43, 2-45

Coolant

level check: 1-5

reservoir, removal and installation: 3-3

temperature gauge, check: 3-5

temperature sending unit, check and replacement: 3-5

Coolant tubes, removal and installation: 3-8**Cooling fan, check and replacement: 3-4****Cooling system: 3-1 through 8**

check: 1-19

general information: 3-3

radiator, removal and installation: 3-6

radiator cap, check: 3-2

servicing: 1-19

thermostat, removal, check and installation: 3-5

water pump, check, removal and installation: 3-7

Crankcase

components, inspection and servicing: 2-37

disassembly and reassembly: 2-34

Crankshaft, removal, inspection and installation: 2-40**Cylinder block, removal, inspection and installation: 2-20****Cylinder head**

disassembly, inspection and reassembly: 2-16

removal and installation: 2-14

D**Diagnosis: 0-16 through 24****Disc brake**

caliper, removal, overhaul and installation: 7-3

pads, replacement: 7-2

Drive belt and pulleys

check and adjustment: 1-10

removal and installation: 6-12

E**Electrical system: 9-1 through 22**

alternator, removal and installation: 9-20

alternator stator coils, continuity test: 9-20

battery

charging: 9-2

inspection and maintenance: 9-2

charging system, output test: 9-20

charging system testing, general information and precautions: 9-19

fuses, check and replacement: 9-3

general information: 9-2

handlebar switches

check: 9-10

removal and installation: 9-12

Ignition main (key) switch, check and replacement: 9-11

instrument and warning light housings (EN500 models),

removal and installation: 9-8

junction box (EN500 models), check: 9-4

lighting system, check: 9-5

starter motor

disassembly, inspection and reassembly: 9-17

removal and installation: 9-16

troubleshooting: 9-2

starter relay and starter circuit relay, check and replacement: 9-12

voltage regulator/rectifier, check and replacement: 9-20

wiring diagrams: 9-23

Engine: 2-1 through 58

break-in procedure: 2-58

cam chain tensioner, removal and installation: 2-8

camshafts, removal, inspection and installation: 2-47

connecting rods, bearing inspection and selection: 2-44

connecting rods and bearings, removal and installation: 2-43, 2-45

coolant, level check: 1-5

cooling fan, check and replacement: 3-3

crankcase, disassembly and reassembly: 2-34

crankcase components, inspection and servicing: 2-37

crankshaft and main bearings, removal, inspection

and installation: 2-39

cylinder block, removal, inspection and installation: 2-20

cylinder head

disassembly, inspection and reassembly: 2-16

removal and installation: 2-14

disassembly and reassembly, general information: 2-6

general information: 2-5

identification number: 0-6

ignition system: 5-1 through 4

initial start-up after overhaul: 2-58

main and connecting rod bearings, general note: 2-39

main bearing selection: 2-41

major repair, general note: 2-5

oil

change: 1-11

level check: 1-4

oil pan, removal and installation: 2-25

oil pressure relief valve, removal, inspection and installation: 2-28

oil pump, check, removal, inspection and installation: 2-27

piston rings, installation: 2-24

pistons, removal, inspection and installation: 2-22

primary chain, removal, inspection and installation: 2-47

removal and installation: 2-5

rocker arms and shafts, removal, inspection and installation: 2-9

tune-up: 1-1 through 24

valve cover, removal and installation: 2-7

valves, seats and guides, servicing: 2-16

Engine fuel and exhaust systems: 4-1 through 14**EVAP system, check: 1-20****Exhaust system: 4-12**

check: 1-22

removal and installation: 4-11

External shift mechanism, removal, inspection and installation: 2-33**F****Fasteners, check: 1-23****Fault-finding: 0-16 through 24****Fender/mudguard**

front, removal and installation: 8-6

rear, removal and installation: 8-6

Filter

air, servicing: 1-12

fuel, cleaning: 1-22

oil, change: 1-11

Final drive: 6-1 through 14

belt and pulleys, removal, inspection and installation: 6-12

rear wheel coupling/rubber damper, check

and replacement: 6-13

Fluid, level checks: 1-4**Footpegs and brackets, removal and installation: 8-5****Forks**

disassembly, inspection and reassembly: 6-3

oil replacement: 1-23

removal and installation: 6-5

Frame: 8-1 through 6

- footpegs and brackets, removal and installation: 8-5
- identification number: 0-6
- inspection and repair: 8-1
- side and centerstand, maintenance: 6-3

Frame and bodywork, general information: 8-1**Front wheel, removal and installation: 7-10****Fuel**

- filter cleaning: 1-22
- system, check: 1-22

Fuel system: 4-1 through 14**Fuel tank**

- cleaning and repair: 4-2
- removal and installation: 4-2

Fuses, check and replacement: 9-3**G****Gauge, coolant temperature, check: 3-5****Gauges, check and replacement: 9-10****General information**

- brakes: 7-2
- cooling system: 3-3
- electrical system: 9-2
- engine: 2-5
- frame and bodywork: 8-1
- fuel and exhaust systems: 4-2
- ignition system: 5-2
- suspension, steering and final drive: 6-2

H**Handlebar, switches**

- check: 9-11
- removal and installation: 9-14

Handlebars, removal and installation: 6-2**Head, cylinder, removal and installation: 2-14****Headlight**

- aim, check and adjustment: 9-7
- assembly, removal and installation: 9-7
- bulb, replacement: 9-6

Horn, check, replacement and adjustment: 9-15**Hoses, brake, inspection and replacement: 7-9****I****Identification numbers: 0-6****Idle fuel/air mixture adjustment, general information: 4-2****Idle speed, check and adjustment: 1-18****Ignition**

- coil, check, removal and installation: 5-2
- IC igniter, removal, check and installation: 5-4
- main (key) switch, check and replacement: 9-11
- pickup coils, check, removal and installation: 5-4
- system
 - check: 5-2
 - general information: 5-2

Ignition system: 5-1 through 4**Instrument and warning light bulbs, replacement: 9-10****Instrument and warning light housings (EN500 models), removal and installation: 9-9****Introduction to the Kawasaki EN450/500: 0-5****J****Junction box (EN500 models), check: 9-4****L****Lash, valve, check and adjustment: 1-16****Lighting system, check: 9-5****Linings (brake), check: 1-7****Lubricants: 0-15****Lubrication, general: 1-16****M****Main and connecting rod bearings, general note: 2-39****Main bearings, removal, inspection, selection and installation: 2-40****Maintenance, introduction: 1-4****Maintenance schedule: 1-3****Maintenance techniques: 0-8****Major engine repair, general note: 2-5****Master cylinder (front), removal, overhaul and installation: 7-5****Meters, check and replacement: 9-10****Mirrors, rear view, removal and installation: 8-5****Motor, starter**

- disassembly, inspection and reassembly: 9-17
- removal and installation: 9-16

Muffler

- check: 1-22
- removal and installation: 4-12

N**Neutral switch, check and replacement: 9-14****O****Oil**

- change: 1-11
- filter, change: 1-11
- fork, replacement: 1-23
- level check: 1-4
- pan, removal and installation: 2-25
- pressure relief valve, removal, inspection and installation: 2-28
- pressure switch, check and replacement: 9-9
- pump, removal, inspection and installation: 2-27
- pressure check: 2-27

Owner maintenance: 1-1 through 24**P****Pads (brake)**

- check: 1-7
- replacement: 7-2

Pan (oil), removal and installation: 2-25**Pickup coils, check, removal and installation: 5-3****Piston rings, installation: 2-24****Pistons, removal, inspection and installation: 2-22****Pump, oil, removal, inspection and installation: 2-27****R****Radiator**

- cap, check: 3-3
- draining, flushing and refilling: 1-19
- removal and installation: 3-6

Rear shock absorbers, removal and installation: 6-8**Rear view mirrors, removal and installation: 8-5****Rear wheel, removal and installation: 7-12**

Rear wheel coupling/rubber damper, check and replacement: 6-13
 Relay, starter, check and replacement: 9-12
 Relays, junction box, check: 9-4
 Repairs possible with the engine in the frame: 2-5
 Repairs requiring engine removal: 2-5
 Reservoir (coolant), removal and installation: 3-3
 Rocker arms and shafts, removal, inspection and installation: 2-9
 Rotor (brake), inspection, removal and installation: 7-5
 Routine maintenance: 1-1 through 24

S

Safe motorcycle repair practices: 0-14
 Sender unit
 cooling system temperature, check and replacement: 3-5
 oil pressure, check and replacement: 9-10
 Shift drum and forks, removal, inspection and installation: 2-56
 Shift mechanism, removal, inspection and installation: 2-33
 Shoes, rear brake, removal and installation: 7-7
 Sidestand, maintenance: 8-5
 Sidestand switch, check and replacement: 9-14
 Spark plug, replacement: 1-13
 Specifications, general: 0-7
 Starter
 motor
 disassembly, inspection and reassembly: 9-17
 removal and installation: 9-16
 relay, check and replacement: 9-15
 Starter motor clutch, removal, inspection and installation: 9-21
 Stator (alternator), continuity test: 9-20
 Steering, head bearings, check and adjustment: 1-22
 Steering head, bearings, replacement: 6-7
 Suspension: 6-1 through 14
 check: 1-23
 forks
 disassembly, inspection and reassembly: 6-3
 removal and installation: 6-3
 rear shock absorbers, removal and installation: 6-9
 swingarm, removal and installation: 6-11
 swingarm bearings
 check: 6-11
 replacement: 6-12
 Switch
 handlebar
 check: 9-11
 removal and installation: 9-14
 ignition main (key), check and replacement: 9-11
 neutral, check and replacement: 9-14
 oil pressure, check and replacement: 9-10
 sidestand, check and replacement: 9-14

T



Tail/brake light, license plate and turn signal bulbs, replacement: 9-6
 Temperature sending unit/switch, check and replacement: 3-5
 Tensioner, cam chain, removal and installation: 2-8
 Thermostat
 removal, check and installation: 3-5
 Thermostatic fan switch, check and replacement: 3-4
 Throttle
 cables, removal installation and adjustment: 4-9
 freeplay check and adjustment: 1-8
 Tires: 7-1 through 16
 check: 1-8
 tubeless, general information: 7-16
 Tools: 0-8
 Transmission: 2-1
 external shift mechanism, removal, inspection and installation: 2-33
 shafts
 disassembly, inspection and reassembly: 2-48
 removal and installation: 2-47
 shift drum and forks, removal, inspection and installation: 2-56
 Troubleshooting: 0-16 through 23
 electrical system: 9-2
 Tune-up, introduction: 1-3
 Tune-up and routine maintenance: 1-1 through 24
 Turn signal
 assemblies, removal and installation: 9-8
 circuit check: 9-8

V

Valve, clearance check and adjustment: 1-16
 Valve cover, removal and installation: 2-7
 Valves, seats and guides, servicing: 2-16
 Voltage regulator/rectifier, check and replacement: 9-20

W

Water pump, check, removal and installation: 3-7
 Wheels: 7-1 through 16
 alignment check: 7-10
 check: 1-8
 front wheel, removal and installation: 7-10
 inspection and repair: 7-9
 rear wheel, removal and installation: 7-11
 wheel bearings, inspection and replacement: 7-12
 Wiring diagrams: 9-23 through 35
 Working facilities: 0-8



Models covered by this manual:

Kawasaki EN450 (454 LTD). 454cc. 1985 to 1990

Kawasaki EN500 (Vulcan 500). 498cc. 1990 to 1993

Haynes Manuals Explain Best:

- Step-by step procedures accompanied by hundreds of photos and line drawings
- Comprehensive routine maintenance and fault diagnosis sections
- Every manual based on a complete stripdown and rebuild
- Written from hands-on experience using common tools
- Detailed wiring diagrams

