

BOXER

BM100 ES/KS



Mobil Super™
4T Ultra

CATÁLOGO DE PARTES



IRC LLANTAS

TECNOLOGÍA JAPONESA



**Los Expertos en motos
las usan y recomiendan:**



APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO
PULSAR 200 NS	DELANTERA	100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18
		110/70-17		RX01	PISTERA	41070-1117-RX01/18
	TRASERA	130/70-17	IRC	RX01	PISTERA	41070-1317-RX01/18
PULSAR 220	DELANTERA	90/90X17	IRC	NF45	PISTERA TUBE LESS	41070-9017-NF45/18
				NF52TL	PISTERA TUBE LESS	41070-9017-NF52TL/18
				NF42	PISTERA TUBE LESS	41070-9017-NF42/18
				NF46	PISTERA TUBE LESS	41070-9017-NF46/18
		110/70-17		RX01	PISTERA TUBE LESS	41070-1117-RX01/18
	TRASERA	130/70-17	IRC	RX01	PISTERA TUBE LESS	41070-1317-RX01/18
		120/80X17		NR57TL	PISTERA TUBE LESS	41070-1217-NR57TL/18
AVENGER 220	DELANTERA	90/90X17	IRC	NF45	PISTERA	41070-9017-NF45/18
	TRASERA	130/90X15		NR67	SPORT	41070-1315-NR67/18
PULSAR 200/180 UG	DELANTERA	2.75X17	IRC	NF53	PISTERA	41070-2717-NR53/18
		90/80X17		NR73	PISTERA	41070-9017-NR73TT/18
		90/90X17		NF53	PISTERA	41070-9017-NF53/18
		100/80-17		NR73	PISTERA	41070-1017-NR73/18
		110/70-17		RX01	PISTERA	41070-1117-RX01/18
	TRASERA	130/70-17	IRC	RX01	PISTERA	41070-1317-RX01/18

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO
PULSAR 135	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18
		90/80-17		NR73TT	PISTERA	41070-9017-NR73TT/18
		70/90-17		NF63BZ	PISTERA	41070-7017-NF63BZ/18
	TRASERA	110/80-17	IRC	NR53	PISTERA	41070-1117-NR53/18
				NR64	PISTERA	41070-1117-NR64/18
		100/80X17		NR73	PISTERA	41070-1017-NR73/18
PULSAR 180 (CLASSIC, DTS-i)	DELANTERA	2.75X18	IRC	NR21	SPORT	41070-2718-NR21/18
				NF2	LINEAL	41070-2718-NF2/18
				NR53	PISTERA	41070-2718-NR53/18
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18
				NR1	SPORT	41070-3018-NR1/18
				NR53	PISTERA	41070-3018-NR53/18
DISCOVER 125 ST DISCOVER 125 DISCOVER 100 DISCOVER 135 KS/ES DISCOVER DTSI PULSAR 180 DTS-i TEC, BLACK, PULSAR II	DELANTERA	2.75X17	IRC	NR53	PISTERA	41070-2717-NR53/18
		90/80-17		NR73TT	PISTERA	41070-9017-NR73TT/18
		70/90-17		NF63BZ	PISTERA	41070-7017-NF63BZ/18
	TRASERA	3.00X17	IRC	GP1	TRIAL ROMBO	41070-3017-GP1/18
				NR1	SPORT	41070-3017-NR1/18
		100/80-17	IRC	NR73	PISTERA	41070-1017-NR73/18
		80/90-17		NR78YL	PISTERA	41070-8017-NR78Y/18
DISCOVER 100M	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	41070-9017-NR73TT/18
	TRASERA	100/80X17		NR73	PISTERA	41070-1017-NR73/18

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO
PLATINO 125 5S, PLATINO CT, 100 SPORT, 125, XCD 125	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	90/80-17-NR73-TT
		70/90-17		NF63BZ	PISTERA	70/90-17-NF63BZ-TT
		2.75X17		NR53	PISTERA	275-17-NR53-TT
	TRASERA	100/80-17	IRC	GP1	TRIAL ROMBO	275-17-GP1-TT
		3.00X17		NR73	PISTERA	100/80-17-NR73-TT
				GP1	TRIAL ROMBO	300-17-GP1-TT
BOXER CON RIN 17" BM 150, CT 100, BM 100	DELANTERA	90/80-17	IRC	NR73TT	PISTERA	41070-9017-NR73TT/18
		90/90-17		NR53	PISTERA	41070-2717-NR53/18
		2.75X17		NR53	PISTERA	41070-2717-NR53/18
	TRASERA	100/80-17	IRC	GP1	TRIAL ROMBO	41070-2717-GP1/18
		100/80-17		NR73	PISTERA	41070-1017-NR73/18
		3.00X17		GP1	TRIAL ROMBO	41070-3017-GP1/18
BOXER BM 100 CLASSIC ES	DELANTERA	2.75X17	IRC	NR1	SPORT	41070-3017-NR1/18
	TRASERA	3.00X17		NR53	PISTERA	41070-2717-NR53/18
BOXER CON RIN 18" 4T, UG, K-TEC	DELANTERA	2.50X18	IRC	NF2	LINEAL	41070-2518-NF2/18
				NR53	PISTERA	41070-2518-NR53/18
	TRASERA	3.00X18	IRC	GP1	TRIAL ROMBO	41070-3018-GP1/18
				NR1	SPORT	41070-3018-NR1/18
				NR53	PISTERA	41070-3018-NR53/18
				NR21	SPORT	41070-2718-NR21/18
BOXER CON RIN 18" (S1D) CALIBER 115 WIND 125	DELANTERA	2.75X18	IRC	NF2	LINEAL	41070-2718-NF2/18
				NR53	PISTERA	41070-2718-NR53/18
				GP1	TRIAL ROMBO	41070-3018-GP1/18
	TRASERA	3.00X18	IRC	NR1	SPORT	41070-3018-NR1/18
				NR53	PISTERA	41070-3018-NR53/18
				GP1	TRIAL ROMBO	41070-3018-GP1/18

APLICACIONES DE LAS LLANTAS IRC EN LOS MODELOS BAJAJ

MODELO	APLICACIÓN	MEDIDA	MARCA	GRABADO	TIPO DE GRABADO	CÓDIGO
AVANTI	DELANTERA	2.25X17	IRC	NF3	LINEAL	41070-2217-NF3/18
		2.50X17		NR53	PISTERA	41070-2217-NR53/18
				TR1	TRIAL ROMBO	41070-2517-TR1/18
	TRASERA	2.75X17	IRC	NR2	SPORT	41070-2717-NR2/18
				NR53	PISTERA	41070-2717-NR53/18
				GP1	TRIAL ROMBO	41070-2717-GP1/18
PLUS/CLASSIC/LEGEND	DELANTERA	3.50X10	IRC	MB-27	SPORT	41070-3510-27/18
	TRASERA					

Advierta lo que le dicen las llantas mientras conduce:

- Si su respuesta a la dirección es lenta o si en las curvas y en el frenado la respuesta es pesada, es muy probable que sus llantas estén desinfladas.
- Vibración o tambaleo durante la conducción, puede significar que la presión en las llantas es mayor a la recomendada, o que ha ocurrido un daño en la llanta y la falla es inminente.
- La llanta puede vibrar a ciertas velocidades debido al desbalanceo, en este caso su desgaste será muy acelerado.

**RECUERDE SIEMPRE REVISAR LA PRESIÓN DE AIRE EN SUS LLANTAS
ANTES DE COMENZAR A RODAR**

PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.auteco.com.co accediendo al link repuestos. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.

En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco-Kawasaki.



DIRECTORIO TELEFÓNICO - UN REPUESTOS Y ACCESORIOS

ÁREA COMERCIAL Y ASESORES DE VENTAS

NOMBRE	CARGO	ZONA	CELULAR	CORREO ELECTRÓNICO
Alejandro Posada	ASESOR COMERCIAL	Norte Area Metropolitana de Medellín	314 811 04 09	aposada@auteco.com.co
Alexánder Grajales	ASESOR COMERCIAL	Córdoba, Cauca y El Bagre	310 373 90 19	agrajales@auteco.com.co
Bernardo Muriel	ASESOR COMERCIAL	Arauca y Norte de Santander	310 436 27 42	bmuriel@auteco.com.co
Carlos Humberto Tobón	ASESOR COMERCIAL	Tolima	310 447 36 11	ctobon@auteco.com.co
Carlos Salazar	ASESOR COMERCIAL	Sucre	310 414 88 45	csalazar@auteco.com.co
Eliecer Zamora Vásquez	ASESOR COMERCIAL	Cali y Cauca	313 584 47 13	ezamora@auteco.com.co
Elkin Humberto Gallego	ASESOR COMERCIAL	Sur de Área Metropolitana de Medellín	310 436 25 98	egallego@auteco.com.co
Esmeralda Forero Acosta	ASESOR COMERCIAL	Zona Centro Bogotá	313 585 22 07	eforero@auteco.com.co
Fredy Alexander Jiménez	ASESOR COMERCIAL	Zona Norte Bogotá	313 585 98 37	fjimenez@auteco.com.co
Gonzalo Saldarriaga	ASESOR COMERCIAL	Neiva y Norte del Huila	310 406 88 74	gsaldarriaga@auteco.com.co
Gustavo Adolfo Cantillo	ASESOR COMERCIAL	Atlántico	313 584 21 93	gcantillo@auteco.com.co
Héctor Jairo López	ASESOR COMERCIAL	Caldas y Norte de Risaralda	312 257 67 91	hlopez@auteco.com.co
Hernán Pedraza	ASESOR COMERCIAL	Pueblos de Cundinamarca	314 812 64 53	hpedraza@auteco.com.co
Jaime Alfonso Villalba	ASESOR COMERCIAL	Bolívar	313 584 72 62	jvillalba@auteco.com.co
John Jairo López	ASESOR COMERCIAL	Risaralda, Quindío y Cartago	310 444 22 15	jlopez@auteco.com.co
Jorge Gil	ASESOR COMERCIAL	Casanare, Vichada, Boyacá	313 672 73 53	kgil@auteco.com.co
Jorge Mario Maya	ASESOR COMERCIAL	Cesar y Guajira	312 258 93 84	jmaya@auteco.com.co
Jovany Castro Betancur	ASESOR COMERCIAL	Sur del Huila y Caqueta	313 767 78 43	jcastro@auteco.com.co
Julio Mario Moterrosa	ASESOR COMERCIAL	Magdalena	313 585 60 28	jmonterrosa@auteco.com.co
Karen Lorena Candanoza	ASESOR COMERCIAL	Zona Sur Bogotá	313 585 35 61	kcandanoza@auteco.com.co
Mauricio Mejía	ASESOR COMERCIAL	Suroeste, Noredeste y Chocó	312 257 61 75	mmejia@auteco.com.co
Miguel Angel Guerrero	ASESOR COMERCIAL	Norte del Valle y Buenaventura	314 772 07 98	mgguerrero@auteco.com.co
Nestor Adarve	ASESOR COMERCIAL	Resto de Antioquia y Urabá	310 436 26 89	nadarve@auteco.com.co
Rubén Darío Campo Cárdena	ASESOR COMERCIAL	Nariño y Putumayo	321 799 79 06	rcampo@auteco.com.co
Uberney Ortiz Vélez	ASESOR COMERCIAL	Magdalena Medio	313 672 73 37	uortiz@auteco.com.co
William Gutiérrez	ASESOR COMERCIAL	Meta	310 407 40 72	wgutierrez@auteco.com.co
Wilson Sabogal	ASESOR COMERCIAL	Bucaramanga y Área Metropolitana	300 542 85 48	wsabogal@auteco.com.co
Daniel Becerra	ASESOR COMERCIAL BOUTIQUES	Valle	300 542 43 98	dbecerra@auteco.com.co
Hilde Alexander García	ASESOR COMERCIAL BOUTIQUES	Área Metropolitana Medellín	321 641 50 63	hgarcia@auteco.com.co
Juan Guillermo Berrio	ASESOR COMERCIAL BOUTIQUES	Atlántico	300 541 93 94	jberrio@auteco.com.co
Yesid Zamora Castañeda	ASESOR COMERCIAL BOUTIQUES	Bogotá	300 541 04 74	yzamora@auteco.com.co
Sergio Restrepo Taborda	GERENTE CCIAL. REPUESTOS Y ACCS	Nacional	321 779 13 97	srgrestrepo@auteco.com.co
Jhon Alexander Estrada	GERENTE CCIAL. REGIONAL	Zona Paisa	311 737 37 48	dangel@auteco.com.co
José Giovanni Suárez Martínez	GERENTE CCIAL. REGIONAL	Zona Centro	320 766 49 45	jestrada@auteco.com.co
Juan Guillermo Ospina	GERENTE CCIAL. REGIONAL	Zona Sur	313 767 78 36	jgospina@auteco.com.co
Mario Martínez	GERENTE CCIAL. REGIONAL	Zona Norte	300 542 24 01	mmartinez@auteco.com.co
Alejandro García P.	Coordinador CBU	Zona Norte	320 682 09 64	agarcia@auteco.com.co
Laura Ocampo	Coordinadora CBU	Zona Sur	311 358 76 27	repuestoscbu@auteco.com.co

SERVICIO AL CLIENTE

LINEA ÚNICA DE SERVICIO AL CLIENTE CANAL (4) 444 81 90

UN DE REPUESTOS y ACCESORIOS • FAX OFICINAS: 373 03 75

ATENCIÓN EN:	NOMBRE	E-MAIL	TELÉFONO	FAX
SERVICIO A CONCESIONARIO Y MAYORISTAS	WILLINTON FRANCO	servicioadistribuidoresymayoristas@auteco.com.co		
SERVICIO PAGO ANTICIPADO	DORIS CARMONA	serviciopagoanticipadorptos@auteco.com.co		(4) 373 83 94
COORDINADOR SERVICIO POSTVENTA	LUIS G. RODRIGUEZ	lrodriguez@auteco.com.co		
GARANTÍAS	ALEJANDRO FERNÁNDEZ	garantias2@auteco.com.co		
DEVOLUCIONES - RECLAMOS	LEONARDO AGUDELO	devolucionesrptos@auteco.com.co		
MOTO FUERA DE RUTA	JONI HOLGIN	motofueraderuta@auteco.com.co		(4) 306 84 86
LÍNEA DE ATENCIÓN AL CLIENTE	MARCELA ZULUAGA		(4) 444 81 90 OPCION (2)	
	SANTIAGO ARROYAVE			
POSCONSUMO BATERIAS	YUDY DUQUE	busquedainterna@auteco.com.co	3004243097	
CARTERA		cartera@auteco.com.co		(4) 277 5117
				(4) 306 81 54
VENTA MOTOS		pedidosmotos@auteco.com.co		(4) 372 62 95

AUTOTECNICA COLOMBIANA S.A.S (AUTECO S.A.S) SEDE PRINCIPAL Cra. 42 N° 45-77 Itagüí Ant. - PBX: (4)306 81 81

Atención a clientes finales: LINEA GRATUITA NACIONAL - 01 8000 52 00 90

ÍNDICE

FIG. No.	DESCRIPCIÓN	PAG. No.	FIG. No.	DESCRIPCIÓN	PAG. No.
1	CULATA	1	24	GUARDABARRO TRASERO Y DELANTERO	24
2	MÚLTIPLE DE ADMISIÓN	2	25	REPOSAPIE DELANTERO Y TRASERO	25
3	VÁLVULAS	3	26	LLANTAS / RINES / NEUMÁTICOS	26
4	EJE DE LEVAS / TENSOR CADENILLA	4	27	CAMPANA DELANTERA	27
5	CILINDRO / PISTÓN	5	28	CAMPANA TRASERA	28 - 29
6	CIGÜEÑAL	6	29	PEDAL FRENO	30
7	TRANSMISIÓN	7	30	MANUBRIO	31
8	SECTOR DE CAMBIOS	8	31	SUSPENSIÓN DELANTERA	32 - 33
9	EJE DE CAMBIOS	9	32	TANQUE DE GASOLINA	34
10	CARCARA DERECHA	10	33	ANTIVIBRANTES TANQUE Y TAPAS LATERALES	35
11	CARCARA IZQUIERDA	11	34	GRIFO DE GASOLINA	36
12	CUBIERTA CLUTCH	12	35	GUARDACADENA	37
13	CUBIERTA VOLANTE	13	36	VELOCÍMETRO	38
14	CLUTCH	14	37	FAROLA	39
15	PEDAL CRANK	15	38	CABLES	40
16	CARBURADOR	16	39	DIRECCIONALES	41
17	FILTRO DE AIRE	17	40	STOP	42
18	SILENCIADOR	18	41	EQUIPO ELÉCTRICO	43
19	BOMBA DE ACEITE	19	42	HERRAMIENTAS / ACCESORIOS	44
20	MOTOR DE ARRANQUE	20		LISTA DE KITS	45 - 46
21	MAGNETO / C.D.I. / PLATO DE BOBINAS	21		ACTUALIZACIONES	47
22	CHASIS / SOPORTE MOTOR	22		ÍNDICE DE REFERENCIAS	48 - 51
23	BRAZO OSCILANTE /AMORTIGUADOR	23			

ÍNDICE DE GRÁFICOS




FIGURA N° 1 : CULATA

PÁG. N°
1




FIGURA N° 2 : MULTIPLE DE ADMISIÓN

PÁG. N°
2




FIGURA N° 3 : VÁLVULAS

PÁG. N°
3




FIGURA N° 4 : EJE DE LEVAS /
TENSOR CADENILLA

PÁG. N°
4




FIGURA N° 5 : CILINDRO / PISTÓN

PÁG. N°
5




FIGURA N° 6 : CIGÜEÑAL

PÁG. N°
6

ÍNDICE DE GRÁFICOS







	PÁG. N° 7		PÁG. N° 8		PÁG. N° 9
	PÁG. N° 10		PÁG. N° 11		PÁG. N° 12

FIGURA N° 7 : TRANSMISIÓN

PÁG. N°
7

FIGURA N° 8 : SELECTOR DE CAMBIOS

PÁG. N°
8

FIGURA N° 9 : EJE DE CAMBIOS

PÁG. N°
9

FIGURA N° 10 : CARCASA DERECHA

PÁG. N°
10







FIGURA N° 11 : CARCASA IZQUIERDA

PÁG. N°
11







FIGURA N° 12 : CUBIERTA CLUTCH

PÁG. N°
12

ÍNDICE DE GRÁFICOS

					
FIGURA N° 13 : CUBIERTA VOLANTE	PÁG. N° 13	FIGURA N° 14 : CLUTCH	PÁG. N° 14	FIGURA N° 15 : PEDAL CRANK	PÁG. N° 15
					
FIGURA N° 16 : CARBURADOR	PÁG. N° 16	FIGURA N° 17 : FILTRO DE AIRE	PÁG. N° 17	FIGURA N° 18 : SILENCIADOR	PÁG. N° 18

ÍNDICE DE GRÁFICOS

	FIGURA N° 19 : BOMBA DE ACEITE	PÁG. N° 19		FIGURA N° 20 : MOTOR DE ARRANQUE	PÁG. N° 20		FIGURA N° 21 : MAGNETO / C.D.I. / PLATO DE BOBINAS	PÁG. N° 21
	FIGURA N° 22 : CHASIS / SOPORTE MOTOR	PÁG. N° 22		FIGURA N° 23 : BRAZO OSCILANTE / AMORTIGUADOR	PÁG. N° 23		FIGURA N° 24 : GUARDABARRO TRASERO Y DELANTERO	PÁG. N° 24

ÍNDICE DE GRÁFICOS




FIGURA N° 25 : REPOSAPIE DELANTERO Y TRASERO

PÁG. N° 25




FIGURA N° 26 : LLANTAS / RINES / NEUMÁTICOS

PÁG. N° 26




FIGURA N° 27 : CAMPANA DELANTERA

PÁG. N° 27




FIGURA N° 28 : CAMPANA TRASERA

PÁG. N° 28-29




FIGURA N° 29 : PEDAL FRENO

PÁG. N° 30




FIGURA N° 30 : MANUBRIO

PÁG. N° 31

ÍNDICE DE GRÁFICOS




FIGURA N° 31 : SUSPENSIÓN DELANTERA

PÁG. N°
32 - 33




FIGURA N° 32 : TANQUE DE GASOLINA

PÁG. N°
34




FIGURA N° 33 : ANTIVIBRANTES TANQUE Y
TAPAS LATERALES

PÁG. N°
35




FIGURA N° 34 : GRIFO DE GASOLINA

PÁG. N°
36




FIGURA N° 35 : GUARDACADENA

PÁG. N°
37




FIGURA N° 36 : VELOCÍMETRO

PÁG. N°
38

ÍNDICE DE GRÁFICOS




FIGURA N° 37 : FAROLA

PÁG. N°
39




FIGURA N° 38 : CABLES

PÁG. N°
40




FIGURA N° 39 : DIRECCIONALES

PÁG. N°
41




FIGURA N° 40 : STOP

PÁG. N°
42




FIGURA N° 41 : EQUIPO ELÉCTRICO

PÁG. N°
43




FIGURA N° 42 : HERRAMIENTAS /
ACCESORIOS

PÁG. N°
44

This exploded view diagram illustrates the assembly of a motorcycle headlight. The components are labeled as follows:

- 1**: Headlight housing with a mounting bracket.
- 2**: A screw for mounting the housing to the bracket.
- 3**: A gasket or seal ring.
- 4**: A screw for mounting the lens plate to the housing.
- 5**: A lens plate with mounting tabs.
- 6**: A curved protective tube or shield.
- 7**: A small circular cap or plug.
- 8**: A screw for mounting the lens plate to the housing.

Dashed lines indicate the assembly sequence and alignment of the parts.

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a carburetor. The components are numbered as follows:

- 1**: The main carburetor body, featuring a throttle cable bracket on top and a float bowl at the bottom.
- 2**: Two screws used to secure the top cover to the carburetor body.
- 3**: The float bowl, which is attached to the bottom of the carburetor body.
- 4**: The jet needle assembly, which is inserted into the carburetor body.
- 5**: A small screw used to secure the jet needle assembly.
- 6**: A O-ring seal that fits into the carburetor body to ensure a proper seal for the jet needle assembly.
- 7**: A gasket or spacer plate that is placed between the float bowl and the carburetor body.
- 8**: A small O-ring seal that fits into the float bowl to ensure a proper seal with the gasket.

BOXER BM100 ES/KS

This diagram illustrates the assembly of a mechanical component. The main assembly is shown with a dashed line indicating the path of a rod (4) passing through a series of components: a washer (6), a spring, a washer (3), and a cap nut (5). A detailed inset view, enclosed in a dashed box, shows the internal mechanism of the cap nut (5), which includes a threaded rod, a washer, and a lever arm with a pin. To the right of the main assembly, two separate cylindrical components are shown, each labeled with the number 1.

BOXER *BM100 ES/KS*

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The parts are numbered 1 through 17. The assembly sequence is as follows:

- Part 1** is the main housing, which contains **Part 15** (a shaft) and **Part 16** (a rotor or impeller).
- Part 2** (a washer) is placed on the shaft (**Part 15**).
- Part 3** (a gear) is mounted on the shaft.
- Part 4** (a screw) is used to secure **Part 5** (a cover plate) onto the gear.
- Part 6** is the base plate, which is secured to the main housing (**Part 1**) using **Part 10** (a screw).
- Part 7** (a pin) is used to secure the base plate (**Part 6**) to the main housing.
- Part 8** (a bracket) is mounted to the base plate (**Part 6**) using **Part 11** (a screw).
- Part 9** (a gasket) is placed between the base plate (**Part 6**) and the main housing (**Part 1**).
- Part 12** (a O-ring) is placed on the shaft (**Part 15**).
- Part 13** (a washer) is placed on the shaft (**Part 15**).
- Part 14** is a long, curved component, possibly a belt or a hose, that is attached to the main housing (**Part 1**) and the base plate (**Part 6**).
- Part 17** (a screw) is used to secure the base plate (**Part 6**) to the main housing.

BOXER BM100 ES/KS

This diagram illustrates the assembly of a carburetor. The main components are shown in an exploded view:

- 1**: A gasket or flange plate with a central circular opening and four mounting holes.
- 2**: Two small cylindrical pins or screws used for securing the gasket.
- 3**: Three O-rings or seals of different sizes, stacked vertically.
- 4**: Two small circular washers or spacers.
- 5**: A long, thin cylindrical pin or screw that passes through the top of the carburetor body.
- 6**: The main carburetor body, which is a complex casting with multiple horizontal passages and a central outlet.

Dashed lines indicate the alignment and assembly sequence of the parts. The O-rings (3) and washers (4) are positioned between the gasket (1) and the carburetor body (6). The long pin (5) is used to clamp the entire assembly together.

BOXER BM100 ES/KS

This diagram illustrates the assembly of a mechanical component, likely a pump or motor. The main assembly is shown in a dashed box, with parts numbered 1 through 10. Part 1 is a circular component with a central hole. Part 2A is a small ring or washer. Part 3 is a curved component. Part 4 is a large, multi-lobed component. Part 5 is a small ring or washer. Part 6 is a small rectangular component. Part 7 is a large, multi-lobed component. Part 8 is a small ring or washer. Part 9 is a small rectangular component. Part 10 is a small rectangular component. The diagram shows the assembly of parts 1, 2A, 3, 4, 5, 6, 7, 8, 9, and 10.

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The parts are numbered 1 through 20. The assembly consists of two main shafts, 1 and 8, which are connected by a series of gears. Shaft 1 is at the top right, and shaft 8 is at the bottom left. A dashed line indicates the assembly path for the lower shaft components. The gears are arranged in a sequence: gear 2 is on shaft 1, meshing with gear 3, which meshes with gear 4, which meshes with gear 5, which meshes with gear 6, which meshes with gear 7. Gear 8 is on shaft 8, meshing with gear 9, which meshes with gear 10, which meshes with gear 11, which meshes with gear 12, which meshes with gear 13, which meshes with gear 14, which meshes with gear 15. Gear 16 is on shaft 17, which is connected to shaft 18 by a pin 19. A small screw 20 is used to secure the pin 19.

BOXER BM100 ES/KS

This diagram illustrates the exploded view of a mechanical assembly. The components are numbered as follows:

- 1**: A large, complex housing or base component with a cylindrical protrusion on the left.
- 2**: A small, short cylindrical pin or bush.
- 3**: A circular plate with six small holes arranged in a circular pattern.
- 4**: A long screw or bolt with a hexagonal head.
- 5**: A long, hollow cylindrical tube or sleeve.
- 6**: A lever or arm component with a circular end and a curved body.
- 7**: A small, curved bracket or support piece.

BOXER BM100 ES/KS

This diagram shows an exploded view of a mechanical assembly. The components are numbered as follows:

- 1**: A long, thin rod or shaft.
- 2**: A small pin or clip.
- 3**: A small circular component, possibly a washer or bush.
- 4**: A bracket or arm.
- 5**: A spring.
- 6**: A small circular component, possibly a washer or bush.
- 7**: A small circular component, possibly a washer or bush.
- 8**: A small circular component, possibly a washer or bush.
- 9**: A bracket or arm, shown in a dashed box labeled **9A**.
- 9A**: A label for the dashed box containing parts 9, 10, and 11.
- 10**: A spring.
- 11**: A spring.
- 12**: A screw or bolt.

The diagram also includes a central dashed outline representing the main body of the assembly, with various mounting points and holes indicated.

BOXER *BM100 ES/KS*

This diagram shows an exploded view of a mechanical assembly. The main component is a cast metal housing (2) with several circular openings. Various fasteners and components are shown being installed into these openings:

- Part 10:** Two long screws for the top flange.
- Part 11:** A short screw for the top flange.
- Part 9:** A long pin or screw for the side flange.
- Part 8:** A spring-loaded pin for the side flange.
- Part 5:** A small bracket or pin for the side flange.
- Part 12:** A screw for the side flange.
- Part 14:** A screw for the side flange.
- Part 13:** A bracket or pin for the side flange.
- Part 7:** A ring for the central opening.
- Part 6:** A small pin or screw for the central opening.
- Part 4:** A threaded plug for the bottom opening.

BOXER BM100 ES/KS

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or engine component. The main housing is labeled 1. Various fasteners and components are shown with dashed lines indicating their assembly positions:

- 1**: Main housing or pump body.
- 2**: Small cylindrical component, possibly a filter or cap.
- 3**: Circular component, possibly a gasket or seal.
- 4**: Large circular gasket or seal.
- 5**: Small cylindrical component.
- 6**: Small cylindrical component.
- 7**: Small cylindrical component.
- 8**: Small cylindrical component.
- 9**: Small cylindrical component.
- 10**: Flange or mounting bracket.
- 11**: Small cylindrical component.
- 12**: Small cylindrical component.
- 13**: Long cylindrical component, possibly a shaft or piston.
- 14**: Small cylindrical component.
- 15**: Small cylindrical component.
- 16**: Small cylindrical component.
- 17**: Spring or coiled wire.
- 18**: Small cylindrical component.
- 19**: Large circular gasket or seal.

BOXER BM100 ES/KS

[illegible]

BOXER BM100 ES/KS 12

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor head, with 15 numbered parts:

- 1**: The main housing or pump head, shown at the top.
- 2**: A small rectangular plug or cap, located near the top left of the housing.
- 3**: A small circular gasket or seal, positioned below the housing.
- 4**: A series of four circular gaskets or seals, arranged in a row.
- 5**: A circular component, possibly a filter or a small impeller, located below the gaskets.
- 6**: A circular component, possibly a filter or a small impeller, located below the gaskets.
- 7**: A circular component with a central hub and a flange, located below the gaskets.
- 8**: A set of four small rectangular components, possibly O-rings or seals, located below the central hub.
- 9**: A circular component with a central hub and a flange, located below the O-rings.
- 10**: A set of four screws or bolts, located to the right of the central hub.
- 11**: A small circular gasket or seal, located below the central hub.
- 12**: A small circular gasket or seal, located below the central hub.
- 13**: A small circular gasket or seal, located below the central hub.
- 14**: A small circular gasket or seal, located below the central hub.
- 15**: The final assembled unit, shown at the bottom right, consisting of the housing (1) and the central hub (7) with the gaskets (4) and O-rings (8) installed.

BOXER BM100 ES/KS

This diagram illustrates the exploded view of a mechanical assembly, with components numbered 1 through 14. The main assembly, labeled 1, is shown in a dashed-line box. It includes a base plate (4) and a vertical support structure (3). A long, angled arm (2) is attached to the base. A large gear (10) is mounted on the arm. A spring (14) is attached to the base. A small pin (12) is also shown. Other components shown separately are a small gear (9), a spring (8), a pin (6), a long pin (7), a spring (11), and a small pin (5).

BOXER BM100 ES/KS

This diagram illustrates the exploded view of a carburetor assembly, with components labeled 1 through 19. The parts are distributed as follows:

- 1**: A long, thin metal plate or gasket.
- 2**: A small screw or pin.
- 3**: A circular component, likely a filter or cap.
- 4**: A small pin or screw.
- 5**: A set of three small screws or pins.
- 6**: A small pin or screw.
- 7**: A small pin or screw.
- 8**: A circular component with a central hole, possibly a gasket or plate.
- 9**: A small pin or screw.
- 10**: A cable or hose with a connector.
- 11**: A small pin or screw.
- 12**: A long, thin metal plate or gasket.
- 13**: A long, thin metal plate or gasket.
- 14**: A small pin or screw.
- 15**: A small pin or screw.
- 16**: A small pin or screw.
- 17**: A small pin or screw.
- 18**: A small pin or screw.
- 19**: A small pin or screw.

The diagram shows the carburetor body in the center, with various components like the filter (3), gaskets (1, 12, 13), and screws (2, 4, 5, 6, 7, 8, 9, 11, 14, 15, 16, 17, 18, 19) positioned around it to show their assembly locations. The cable (10) is connected to the side of the carburetor.

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a car air filter system, designated by the number 1. The components are numbered as follows:

- 1**: The main air filter assembly, shown in a dashed box.
- 2**: A circular gasket or seal.
- 3**: A rectangular air filter element.
- 4**: A rectangular frame or support for the filter element.
- 5**: A rectangular mesh or screen.
- 6**: A long, curved air duct or hose.
- 7**: A short, curved air duct or hose.
- 8**: A small, curved air duct or hose.
- 9**: A small, curved air duct or hose.
- 10**: A rectangular air filter element.
- 11**: A rectangular air filter element.
- 12**: A rectangular air filter element.
- 13**: A small, curved air duct or hose.
- 14**: A small, curved air duct or hose.
- 15**: A small, curved air duct or hose.

The diagram shows the relative positions and assembly points of these components, with dashed lines indicating the path of assembly.

BOXER *BM100 ES/KS*


This diagram illustrates the assembly of a bicycle seatpost. The components are labeled as follows:

- 1**: The main seatpost tube.
- 2**: A small circular cap or plug for the top of the seatpost.
- 3**: A bolt used to secure the top cap.
- 4**: A bolt used to attach the seat clamp.
- 5**: A small ring or spacer for the seat clamp.
- 6**: A rectangular plate or bracket that fits around the seatpost.
- 7**: Two screws used to secure the plate to the seatpost.

The diagram shows the seatpost with a curved section at the top, a rectangular plate (6) attached to the main tube, and a seat clamp (4) at the very top. The plate (6) is secured with two screws (7). The seat clamp (4) is secured with a bolt (4) and a ring (5). The top cap (2) is secured with a bolt (3).

BOXER BM100 ES/KS

FIGURA N° 19 : BOMBA DE ACEITE

[illegible]

This exploded view diagram illustrates the components of a mechanical assembly, numbered 1 through 19. The parts are distributed as follows:

- Top Section:** Includes a large gear (3), a shaft with two gears (6), a pin (4), a washer (5), a flange (2), and a housing (1).
- Left Section:** Features a coiled hose (13) and a curved bracket (19).
- Bottom Section:** Contains a motor assembly (17), a large cylindrical component (18), a smaller cylindrical component (11), a bracket (12), a pin (15), a cap (7), two screws (9), a gasket (10), a ring (8), and a long pin (16).

The diagram uses solid lines for most components and dashed lines for the hose and certain internal assembly details.

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of various components for a vehicle, likely a motorcycle or small car. The components are numbered as follows:

- 1:** A circular headlight or fog light assembly.
- 2:** A multi-ported engine block or manifold.
- 3:** A small cylindrical component, possibly a sensor or valve.
- 4:** A small bolt or screw.
- 5:** A cable with a connector, possibly for a sensor or actuator.
- 6:** A rectangular electronic control unit or relay.
- 7:** A spark plug.
- 8:** A small L-shaped bracket or connector.
- 9:** A small circular cap or plug.
- 10:** A small cylindrical component, possibly a sensor or valve.
- 11:** A small bolt or screw.
- 12:** A rectangular battery or power source.
- 13:** A small rectangular component, possibly a fuse or relay.

The diagram shows the spatial arrangement and assembly sequence of these parts, with dashed lines indicating the alignment and connection points between them.

BOXER BM100 ES/KS

This diagram illustrates the exploded view of a mechanical assembly, likely a hinge or bracket system. The components are numbered as follows:

- 1:** The main horizontal structural member.
- 2, 3, 4:** A vertical plate or bracket with three mounting points.
- 5:** A small bracket or pin used for attachment.
- 6:** A rectangular plate with multiple mounting holes.
- 7:** A small pin or screw used for assembly.
- 8:** A long, thin rod or pin.
- 9:** A small pin or screw.
- 10:** A small pin or screw.
- 11:** A small pin or screw.

Dashed lines indicate the alignment and assembly path for the various components, showing how they fit together to form the complete unit.

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a vehicle chassis component, likely a rear suspension or steering knuckle. The main frame (5) is the central component, with various parts numbered 1 through 18. The diagram shows the following components and their assembly points:

- Shock Absorber (4):** A vertical component with a coil spring, shown in a dashed box. It is secured by a top nut (2) and a bottom nut (3). A bolt (1) is used to secure the bottom of the shock absorber to the frame.
- Control Arm (11):** A long, curved component that connects the frame to the wheel hub. It is secured by a bolt (1) and a nut (13).
- Frame (5):** The main structural component, which is secured by a bolt (1) and a nut (13).
- Other Components:**
 - 10:** A small bracket or bushing.
 - 12:** A bolt used to secure the frame.
 - 14:** A small bracket or bushing.
 - 15:** A small bracket or bushing.
 - 16:** A small bracket or bushing.
 - 17:** A small bracket or bushing.
 - 18:** A small bracket or bushing.

The diagram uses dashed lines to indicate the assembly path and the location of each component relative to the main frame.

BOXER BM100 ES/KS

[illegible]

BOXER BM100 ES/KS

FIGURA N° 25 : REPOSAPIE DELANTERO Y TRASERO




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.		OBSERVACIÓN
			ES	KS	
1	PF113200	Gato Central	1	1	
2	DG161124	Antivibrante	1	1	
3	JA113201	Pasador Gato Central	1	1	
4	39079708	Pin Pasador Gato Central	1	1	
5	DH161121	Resorte Gato Central	1	1	
6	JA113202	Gato Lateral	1	1	
7	DF161102	Tornillo Gato Lateral	1	1	
8	39042215	Tuerca	1	1	
9	DH161066	Antivibrante y Resorte Gato	1	1	
10	PF113000	Taco Reposapie Conductor Izq.	1	1	
11	KADF0822	Tornillo	4	4	
12	PF113001	Taco Reposapie Conductor Der.	1	1	
13	DF161413	Caucho Reposapie Conductor	2	2	
14	DH161194	Antivibrante	1	1	
15	PF113002	Soporte Reposapie Izquierdo	1	1	
16	PF113003	Soporte Reposapie Derecho	1	1	
17	DP161170	Taco Reposapie	2	2	
18	JK113008	Caucho Reposapie Pasajero	2	2	
19	30171022	Pin Pasador	2	2	
20	DP161163	Arandela	2	2	
21	39078408	Pin	2	2	
22	39248104	Tornillo	4	4	
23	39265912	Arandela	4	4	

This diagram illustrates the exploded view of a wheel assembly, showing the following components:

- 1**: A small pin or bolt used for securing the rim.
- 2**: A long, thin rod or pin used for securing the rim.
- 3**: A long, thin rod or pin used for securing the rim.
- 4**: A rim component with a series of small holes around its circumference.
- 5**: A smooth tire component.
- 6**: A hub or flange component.
- 7**: A tire component with a deep, wavy tread pattern.
- 8**: A rim component with a series of small holes around its circumference.
- 9**: A hub or flange component.
- 10**: A long, thin rod or pin used for securing the rim.
- 11**: A long, thin rod or pin used for securing the rim.

BOXER BM100 ES/KS

FIGURA N° 27 : CAMPANA DELANTERA




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.		OBSERVACIÓN
			ES	KS	
1	39268020	Rodamiento Bolas Rin Delantero	1	1	
1A	39268120	Rodamiento Bolas Rin Delantero	1	1	
2	DF151003	Campana Delantero	1	1	
3	31151004	Buje Eje Delantero	1	1	
4	14151021	Retenedor 30x17x6	1	1	
5	DU151005	Buje Eje Rueda Delantero	1	1	
6	39024811	Arandela	1	1	
7	DU151031	Tuerca M10x1.25	1	1	
8	DZ151012	Eje Rueda Delantero	1	1	
9	DZ151027	Porta Bandas Delantero	1	1	
10	30151068	Bandas Freno Delantero y Trasero	2	2	Asbesto
	JN131812		2	2	No Asbesto
11	30151069	Resorte Banda Freno	2	2	
12	31151011	Leva Interna Freno Delantero	1	1	
13	30151038	Anillo Retenedor	1	1	
14	DD151009	Indicador Desgaste Bandas	1	1	
15	DD151008	Leva Freno	1	1	
16	39077504	Tornillo M6x30	1	1	
17	39079815	Tuerca M6	1	1	
18	31151014	Retenedor Campana Delantero	1	1	
19	31151064	Piñón Velocímetro (Plástico)	1	1	
20	30151041	Piñón Velocímetro (Metalico)	1	1	
21	30151042	Arandela	1	1	
22	JA131606	Buje Piñón Velocímetro	1	1	
23	39084001	Tornillo Cable Piñón Velocímetro	1	1	
24	36DU1503	Kit Piñón Velocímetro	1	1	

FIGURA N° 28 : CAMPANA TRASERA (1/2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.		OBSERVACIÓN
			ES	KS	
1	DS151068	Porta Sprocket	1	1	
2	39224020	Rodamiento Bolas Porta Sprocket	1	1	
3	DJ151033	Buje Porta Sprocket	1	1	
4	DJ151035	Buje Porta Sprocket	1	1	
5	39256711	Arandela	1	1	
6	39080115	Tuerca Buje Porta Sprocket	1	1	
7	PF141002	Cadena 428x124L	1	1	
	PF141003	Cadena 428x122L	1	1	
8	DS151067	Campana Trasera	1	1	Para Buje de 31 mm
	PF131614		1	1	Para Buje de 36 mm
9	39268620	Rodamiento Bolas Campana Tras.	1	1	
10	39268720	Rodamiento Bolas Campana Tras.	1	1	
11	30151075	Buje (31 mm)	1	1	
	PF131228	Buje (36 mm)	1	1	
12	DK151094	Antivibrante Campana	1	1	
13	DS151076	Porta Bandas Trasero	1	1	
14	30151068	Bandas Freno Delantero y Tras.	2	2	Asbesto
	JN131812		2	2	No Asbesto
15	30151069	Resorte Banda Freno	2	2	
16	30151011	Leva Interna Freno Trasero	1	1	
17	30151038	Anillo Retenedor	1	1	
18	DD151009	Indicador Desgaste Bandas	1	1	
19	JW131601	Leva Externa Freno Trasero	1	1	
20	39077504	Tornillo M6	1	1	

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The parts are numbered 1 through 29. The assembly sequence is indicated by dashed lines and arrows. Key components include a large gear (29), a central shaft (22), a housing (1), and various seals and fasteners. The diagram shows the following parts and their assembly relationships:

- Part 1:** The main housing or casing, which is secured with screws (26).
- Part 2:** A component that fits into the housing, secured by a screw (3).
- Part 3:** A small screw or pin used to secure part 2.
- Part 4:** A small ring or seal that fits onto the shaft.
- Part 5:** A small ring or seal that fits onto the shaft.
- Part 6:** A small ring or seal that fits onto the shaft.
- Part 7:** A set of O-rings or seals.
- Part 8:** A large, flange-like component that fits onto the shaft.
- Part 9:** A large, circular component that fits onto the shaft.
- Part 10:** A small ring or seal that fits onto the shaft.
- Part 11:** A small ring or seal that fits onto the shaft.
- Part 12:** A large, circular component that fits onto the shaft.
- Part 13:** A large, circular component that fits onto the shaft.
- Part 14:** A large, circular component that fits onto the shaft.
- Part 15:** A small ring or seal that fits onto the shaft.
- Part 16:** A small ring or seal that fits onto the shaft.
- Part 17:** A small ring or seal that fits onto the shaft.
- Part 18:** A small ring or seal that fits onto the shaft.
- Part 19:** A small ring or seal that fits onto the shaft.
- Part 20:** A small ring or seal that fits onto the shaft.
- Part 21:** A small ring or seal that fits onto the shaft.
- Part 22:** The central shaft.
- Part 23:** A small ring or seal that fits onto the shaft.
- Part 24:** A small ring or seal that fits onto the shaft.
- Part 25:** A small ring or seal that fits onto the shaft.
- Part 26:** Screws used to secure the housing.
- Part 27:** A small ring or seal that fits onto the shaft.
- Part 28:** A small ring or seal that fits onto the shaft.
- Part 29:** The large gear or impeller.

BOXER BM100 ES/KS

FIGURA N° 29 : PEDAL FRENO





FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.		OBSERVACIÓN
			ES	KS	
1	PF161002	Pedal Freno	1	1	
2	PF161001	Varilla Freno Trasero	1	1	
3	30191038	Pin	1	1	
4	DS191035	Empaque Varilla Freno	1	1	
5	39019811	Arandela	2	2	
6	39080808	Pin	1	1	
7	39080511	Arandela	1	1	
8	39079708	Pin	1	1	
9	JV161014	Resorte Pedal Freno	1	1	
10	39019811	Arandela	2	2	
11	30191035	Resorte Varilla Freno Trasero	1	1	
12	JB161002	Pin Varilla Freno	1	1	
13	30191036	Tuerca Varilla Freno	1	1	
14	JW122004	Varilla Torque	1	1	
	032014/00		1	1	Integración Nacional
15	DH151029	Tornillo	1	1	
16	39154011	Arandela	1	1	
17	39078912	Arandela	2	2	
18	39069415	Tuerca	1	1	
19	39080708	Pin	2	2	
20	30151095	Tornillo	1	1	
21	39070815	Tuerca	1	1	

FIGURA N° 30 : MANUBRIO



BOXER BM100 ES/KS

FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.		OBSERVACIÓN
			ES	KS	
1	032002/00	Manubrio	1	1	
2	PF401400	Comando Luces Izquierdo	1	1	
3	PF401402	Comando Luces Derecho	-	1	
	PF401401		1	-	
4	JV161001	Manillar Izquierdo	1	1	
5	JV161002	Caucho Carretel Acelerador	1	1	
6	PF161003/83	Leva Clutch	1	1	
7	PF161203	Guardapolvo Izquierdo	1	1	
8	PF161004/83	Leva Freno Delantero	1	1	
9	PF161205	Guardapolvo Derecho	1	1	
10	PF231600	Espejo Retrovisor Izquierdo	1	1	
11	PF231601	Espejo Retrovisor Derecho	1	1	
12	FD181030	Abrazadera Superior Manubrio	2	2	
13	FD181031	Abrazadera Inferior Manubrio	2	2	
14	39107404	Tornillo	4	4	
15	DF181091	Antivibrante Superior	2	2	
16	DF181092	Antivibrante Inferior	2	2	
17	39042215	Tuerca	2	2	
18	30191048	Abrazadera Cable	2	2	
19	DF181024	Swiche de Encendido (4 en 1)	1	1	
20	39194304	Tornillo	2	2	
21	JV401409	Swiche Stop	1	1	
22	36DU1901	Kit Tensor Cable	1	1	
23	DL191014	Tornillo Leva	2	2	
24	39118415	Tuerca	2	2	

BOXER BM100 ES/KS

Exploded view diagram of a mechanical assembly, likely a fuel injector or valve. The diagram shows the following components and their assembly sequence:

- 1**: Main shaft or body.
- 2**: Washer or seal.
- 2A**: Washer or seal.
- 2B**: Washer or seal.
- 3**: Small pin or screw.
- 4**: Small pin or screw.
- 5**: Long cylindrical component.
- 6**: Spring.
- 7**: Bolt or screw.
- 8**: Cap or plug.
- 9**: Washer or seal.
- 10**: Base plate or manifold.
- 11**: Valve or needle.
- 12**: Base plate or manifold.
- 13**: Bolt or screw.
- 14**: Bolt or screw.
- 15/16**: Assembly of components 2, 2A, and 2B.
- 17**: Small pin or screw.
- 17A**: Small pin or screw.
- 18**: Washer or seal.
- 19**: Washer or seal.
- 20/21**: Lever or arm.
- 22**: Small pin or screw.
- 23**: Washer or seal.
- 24**: Washer or seal.
- 25**: Washer or seal.

BOXER BM100 ES/KS

1

2

3

BM 100 — 5/8/9

BM100 — 8A/9A

BOXER Basic — 6/7

BOXER — 6A/7A

4

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a car seat headrest. The components are labeled as follows:

- 1**: A small cylindrical pin or bush.
- 1A**: A rectangular foam or plastic insert.
- 2**: A long screw.
- 3**: A circular washer or spacer.
- 4**: A square base plate.
- 5**: A circular washer or spacer.
- 6**: A small, irregularly shaped plastic piece.
- 7**: A small circular pin or bush.
- 8**: A large, rounded, cushioned headrest cover.

The diagram shows the headrest (8) being attached to the seat backrest via the base plate (4) and various fasteners (1, 2, 3, 5, 6, 7). Dashed lines indicate the assembly path and the relative positions of the parts. A label "AIRBAG" is visible on the side of the headrest cover, indicating its compatibility with airbag-equipped vehicles.

BOXER BM100 ES/KS

[illegible]

BOXER BM100 ES/KS

BOXER BM100 ES/KS

This exploded view diagram illustrates the assembly of a car stereo unit. The components are numbered as follows:

- 1**: The main car stereo unit, shown in an exploded position relative to the other components.
- 2**: A rectangular mounting plate or bracket.
- 3**: A small electronic component, likely a fuse or relay, mounted on a base.
- 4/6**: Two small cylindrical components, possibly capacitors or resistors.
- 5**: A small cylindrical component, similar to 4/6.
- 7**: A small electronic component, possibly a diode or transistor, mounted on a base.
- 8**: A small cylindrical component, possibly a capacitor or resistor.
- 9**: A rectangular component, possibly a filter or a small amplifier module.
- 10**: A rectangular component with multiple pins or connectors, possibly a connector or a small module.
- 11**: A small electronic component, possibly a diode or transistor, mounted on a base.
- 12**: A rectangular component, possibly a filter or a small amplifier module.

The diagram shows the relative positions of these components and the screws and other fasteners used to assemble them.

BOXER BM100 ES/KS


This exploded view diagram illustrates the components of a car headlight assembly. The parts are numbered as follows:

- 1**: The main headlight housing.
- 2**: The clear lens cover.
- 3**: A small screw for the lens cover.
- 4**: A mounting bracket or spacer.
- 5**: A washer or spacer ring.
- 6**: A nut for the mounting bracket.
- 7**: A large screw for the main housing.
- 8**: A small screw for the mounting bracket.
- 9**: A small screw for the lens cover.
- 10**: The bulb and socket assembly.

Dashed lines indicate the assembly sequence and the relative positions of the components.

BOXER BM100 ES/KS

FIGURA N° 38 : CABLES

[illegible]

BOXER BM100 ES/KS

This diagram illustrates the assembly of a car headlight. The components are labeled as follows:

- 1**: The main headlight housing.
- 2**: A small, clear, dome-shaped lens or cap.
- 3**: A small circular gasket or seal.
- 4**: A small circular gasket or seal.
- 5**: A small circular gasket or seal.
- 6**: A small circular gasket or seal.
- 7**: A black plastic mounting bracket with four circular holes.
- 8**: Two screws used to secure the mounting bracket to the housing.
- 9**: A rectangular metal plate with two circular holes.
- 10**: Two screws used to secure the metal plate to the housing.

The diagram shows the headlight housing (1) with a dashed line indicating the location of the lens (2). The mounting bracket (7) is shown below the housing, with screws (8) indicating its attachment points. The metal plate (9) is shown below the bracket, with screws (10) indicating its attachment points. The gaskets (3, 4, 5, 6) are shown at the top left, with dashed lines indicating their placement on the housing.

BOXER BM100 ES/KS

This diagram illustrates the assembly of a vehicle's electrical system. The components are numbered as follows:

- 1:** A circular component, likely a fuse block or relay assembly, with internal wiring.
- 2:** A bolt used to secure the circular component.
- 3:** A main wiring harness with multiple branches and terminals.
- 4:** A small electrical component, possibly a fuse or relay, shown in a dashed box.
- 5:** A small electrical component, possibly a fuse or relay, shown in a dashed box.
- 6:** A rectangular battery unit.
- 7:** A rectangular control unit or fuse block with multiple terminals.
- 8:** A long, thin component, possibly a fuse strip or a terminal block.
- 9:** A small electrical component, possibly a fuse or relay, shown in a dashed box.
- 10:** A small electrical component, possibly a fuse or relay, shown in a dashed box.

BOXER BM100 ES/KS

1

2

3

4

5

6

7

The diagram illustrates the tools and components required for the boat. At the top, a dashed box labeled '1' contains a list of tools: a carrying bag, a screwdriver, a long thin rod, a thin wire, three open-end wrenches of different sizes, and a long hex key. Below this, a side view of the boat hull is shown, labeled '2' and '7'. Underneath the hull is a detailed view of the internal frame, labeled '3'. A small component, labeled '4', is shown being inserted into a hole in the frame, with a dashed line and the number '5' indicating the insertion point. At the bottom, a dashed box labeled '6' shows a U-shaped metal bracket with a pin and a small hook, along with a small rectangular component and a small U-shaped piece.

BOXER BM100 ES/KS

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
1	36314001	Kit Cunas de Dirección	DH181025	Cuna Chasis	1
			DH181026	Cuna Dirección	1
			DH181024	Cuna Dirección	1
			DH181023	Cuna Superior Espiga	1
2	36DS1401	Kit Anivibrantes Tapas Laterales	DS141012	Antivibrante Delantaro Tapa Lateral	2
			DS161082	Antivibrante Trasero Tapa Lateral	2
3	36DU1007	Kit Moñón Crank	30101233	Moñón Crank	1
			30101234	Resorte Moñón Crank	1
			30101236	Balín Crank	1
			30101235	Pasador Moñón Crank	1
			39085517	Arandela Crank	1
4	36JA0003	Kit Resortes Válvula	28101129	Asiento Resorte Válvula	2
			39201719	Reten Válvula	2
			JA511202	Arandela Resorte Válvula	2
			JA511203	Resorte Interno Válvula	2
			DG101029	Cuña Válvula	4
5	36JW0014	Kit Reparación Clutch de Una Vía	JA621411	Pin Resorte Arranque	5
			DH101163	Pin Pasador	5
			DH101164	Resorte	5
			DJ101109	Buje Resorte Arranque	5
6	36JZ0023	Kit Corona y Piñón Primario	PF551401	Corona Clutch	1
			JZ531006	Piñón Primario	1
7	36JZ0037	Kit Discos de Clutch	JZ551416	Discos Clutch	5
8	36PA0002	Kit Guía Cadenilla	JB541004	Guía Cadenilla	1
			JB521007	Guía Cadenilla	1

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
9	36PA0004	Kit Válvulas	JB511200	Válvula Admisión	1
			JB511201	Válvula Escape	1
10	36PA0013	Kit Tornillo Aire	JB581241	Tornillo Aire	1
			JB581240	Anillo Retenedor	1
			JB581242	Resorte	1
11	36PA0015	Kit Empaques Carburador	JB581231	Empaque Flota Carburador	1
			JB581239	Empaque Tapa Carburador	1
			JB581240	Resorte Ajuste Aire	1
			JB581269	Anillo Retenedor	1
12	36PF0032	Kit Carburador	PF581301	Difusor	1
			PF581306	Aguja de la Cortina	1
			PF581302	Pulverizador	1
			PF581303	Boquerel de Alta	1
			PF581301	Boquerel de Baja	1
13	36PF0033	Kit Tornillo Ajuste Carburador	PF581307	Tornillo	1
			JB581240	Anillo Retenedor	1
			JB581244	Resorte	1
			JB581245	Arandela	1
			JB581246	Anillo Retenedor	1
14	36PF0034	Kit Cortina Carburador	PF581305	Cortina Carburador	1
			JB581235	Pin	1
			JB581206	Soporte Magnético	1
			JB581249	Resorte Cortina	1

ACTUALIZACIONES

Fig. N°	Pág.	Ítem	Descripción	Referencia Actual	Referencia Nueva	Observación	Fecha
9	9	9A	Pedal Cambios	JZ561401	030598/00	Disponible también como integración nacional	oct-12
11	11	15	Tapón Filtro Aceite	JV541206	JV541006	Referencia errada en la edicion anterior	oct-12
13	13	6	Tapón	JA541233	JA541233	Descripción errada en el catalogo	sep-13
		7	Buje	JV541207	JA541005	Referencia y descripción erradas en el catalogo	sep-13
26	26	7	Llanta 300x17 MRF	Ninguna	DS151051	La referencia no figura en la edición anterior	oct-12
28	28	8	Campana Trasera	DS151067	PF131614	La actual aplica para buje de 31 mm y la nueva para buje de 36 mm	sep-14
		11	Buje	30151075	PF131228	El buje actual tiene un diametro interno de 31 mm y el nuevo de 36 mm	
29	30	14	Barra de Torque	JW122004	032014/00	Disponible también como integración nacional	oct-12
31	32	22	Buje	30181038	PF121011	La referencia no figura en la edición anterior	oct-12
	33	24	Empaque Soporte Farola	Ninguna	DJ181043	La referencia no figura en la edición anterior	sep-13
		25	Antivibrante Soporte Farola	Ninguna	DJ181085	La referencia no figura en la edición anterior	sep-13
32	34	1	Tanque de Gasolina	56PF0123	56PF0223	Referencia errada en la edicion anterior	oct-12
		6	Calcomanía Tanque Derecha	Ninguna	4608/00	Para Boxer Basic	oct-12
		7	Calcomanía Tanque Izquierda	Ninguna	4609/00	Para Boxer Basic	oct-12
		8	Calcomanía Tapa Lateral Derecha	Ninguna	4610/00	Para Boxer Basic	oct-12
		9	Calcomanía Tapa Lateral Izquierda	Ninguna	4611/00	Para Boxer Basic	oct-12
33	35	4	Antivibrante Tanque Gasolina	JV171001	JN171000	Referencia errada en la edicion anterior	oct-12
37	39	10	Soquete Bombillo Farola	Ninguna	PF401009	La referencia no figura en la edición anterior	oct-12

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
01110609	4	24
020229/00	6	44
030598/00	9A	9
032002/00	1	31
032014/00	14	30
06201083	3	41
14151021	4	27
15161069	2	37
16151066	1	26
22150241	4	15
22150435	3	24
28101129	12	45
30101096	6	14
30101142	4	12
30101195	8	13
30101233	7	45
30101234	8	45
30101235	10	45
30101236	9	45
30141015	7	36
30141031	3A	36
30151011	16	28
30151038	13	27
30151038	17	28
30151041	20	27
30151042	21	27
30151068	10	27
30151068	14	28
30151069	11	27
30151069	15	28
30151075	11	28
30151095	20	30
30171022	19	25
30181025	4	32

PARTE No.	FIG. No.	PAG. No.
30181026	3	32
30181029	19	32
30181037	23	33
30191035	11	30
30191036	13	30
30191038	3	30
30191048	18	31
30201029	4	38
30201128	6	38
30201129	5	38
31101173	3	6
31151004	3	27
31151011	12	27
31151014	18	27
31151064	19	27
31181099	17A	32
31181108	2A	32
31181120	7	32
31191012	1	38
31191014	11	38
31191017	9	38
31191018	3	38
31191019	12	38
31191020	10	38
31191021	2	38
31201001	5	42
31201027	6	43
31201028	2	42
31201079	4	43
31201081	5	11
36314001	1	45
36314001	3	22
36314001	11	32
36DS1401	2	45

PARTE No.	FIG. No.	PAG. No.
36DS1401	1	35
36DU1007	3	15
36DU1007	3	45
36DU1503	24	27
36DU1901	22	31
36JA0003	4	45
36JA0003	5	3
36JW0014	5	45
36JW0014	16	20
36JZ0023	6	45
36JZ0023	7	6
36JZ0023	15	14
36JZ0037	4	14
36JZ0037	7	45
36-PA00-03-025/47	3	5
36-PA00-03-050/47	3	5
36-PA00-03-075/47	3	5
36-PA00-03-100/47	3	5
36-PA00-03-STD/47	3	5
36PA0002	6	4
36PA0002	8	45
36PA0004	4	3
36PA0004	9	46
36PA0013	6	16
36PA0013	10	46
36PA0015	11	46
36PA0015	15	16
36PF0007	1	13
36PF0008	1	12
36PF0011	1	37
36PF0014	5	23
36PF0015	4	34
36PF0016	4	34
36PF0017	4	34

PARTE No.	FIG. No.	PAG. No.
36PF0027	5	5
36PF0028	3	5
36PF0029	5	34
36PF0030	5	34
36PF0031	5	34
36PF0032	5	16
36PF0032	12	46
36PF0033	4	16
36PF0033	13	46
36PF0034	14	16
36PF0034	14	46
36PF0037	1	2
36PF0038	1	11
36PF0039	1	11
36PF0040	2	10
39019811	5	30
39019811	10	30
39021111	15	24
39024811	6	27
39029215	15	23
39032615	13	24
39042215	8	25
39042215	17	31
39045411	10	23
39055302	9	23
39059417	12	4
39069415	18	30
39070815	21	30
39071411	2	23
39073817	6	15
39074701	9	11
39076101	2	36
39077504	16	27
39077504	20	28

PARTE No.	FIG. No.	PAG. No.
39078111	18	23
39078408	21	25
39078912	7	23
39078912	13	32
39078912	17	30
39079415	27	29
39079708	4	25
39079708	8	30
39079815	8	38
39079815	17	27
39079815	21	29
39080115	6	28
39080511	7	30
39080708	19	30
39080808	6	30
39081715	8	9
39084001	23	27
39085517	11	45
39093915	12	23
39098004	10	14
39098308	6	35
39098717	3	7
39099206	2	8
39099311	5	15
39099906	4	19
39099906	12	11
39099906	20	12
39100006	2	5
39100006	6	10
39100006	11	11
39100120	14	14
39104119	3	12
39105411	7	35
39105711	11	14

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
39107404	14	31
39118415	24	31
39121111	5	44
39122515	4	41
39128321	6	2
39150711	17	24
39154011	16	30
39155604	4	44
39155604	16	24
39167121	17	12
39167404	3	21
39168904	2	43
39171519	4	11
39175904	17	11
39177304	13	17
39178924	5	35
39181304	14	32
39183911	12	24
39186420	5	6
39194304	11	21
39194304	14	24
39194304	20	31
39195604	8	42
39196404	14	10
39197015	8	39
39197015	10	22
39198104	20	7
39198820	15	4
39201719	6	3
39201719	13	45
39217924	3	36
39219019	7	11
39222204	8	24
39224020	2	28

PARTE No.	FIG. No.	PAG. No.
39231204	9	22
39234911	3	23
39236615	6	23
39240817	12	15
39242001	11	24
39242911	6	42
39243015	3	42
39243704	5	20
39247304	7	24
39248104	22	25
39248415	5	24
39256220	2	11
39256611	24	29
39256711	5	28
39258204	7	39
39260011	3	14
39265912	23	25
39266921	13	4
39268020	1	27
39268120	1A	27
39268320	16	4
39268620	9	28
39268720	10	28
39270411	7	9
39272204	4	18
39272315	7	22
39276501	10	42
40602E	7	44
40602U	7	44
41023-2217/18	9	26
41070-2717-NR53/18	5	26
41070-3017-NR11/18	7	26
41075-2717/18	6	26
4608/00	6	34

PARTE No.	FIG. No.	PAG. No.
4609/00	7	34
4610/00	8	34
4611/00	9	34
52JA0027	9	10
52JA0028	13	14
52JA0029	12	10
56PF0223	1	34
59040017	11	22
59110008	2B	6
59120003	2A	6
59150014	1	6
59200036	3	10
59200036	3	11
59210023	18	11
59210024	17	7
6084/00	8A	34
6085/00	9A	34
6086/00	6A	34
6087/00	7A	34
6095/00	8A	34
6096/00	9A	34
CB101114	2	18
CL201023	9	39
CS101128	9	4
DD101097	13	15
DD111011	9	21
DD111012	10	21
DD111018	7	21
DD111048	8	21
DD121181	16	12
DD151008	15	27
DD151009	14	27
DD151009	18	28
DD181031	15	32

PARTE No.	FIG. No.	PAG. No.
DD181032	2B	32
DD181034	16	32
DD201011	4	42
DE181031	6	32
DE181033	17	32
DF151003	2	27
DF161102	7	25
DF161242	1	24
DF161245	2	24
DF161252	9	42
DF161413	13	25
DF161426	15	17
DF181024	5	36
DF181024	7	38
DF181024	19	31
DF181077	10	32
DF181083	12	32
DF181085	18	32
DF181089	9	32
DF181090	2	22
DF181091	15	31
DF181092	16	31
DF191020	6	24
DF201138	1	42
DG101029	3	3
DG101029	16	45
DG101339	11	9
DG101418	7	12
DG161121	2	35
DG161124	2	25
DH101048	5	4
DH101163	9	20
DH101163	18	45
DH101164	19	45

PARTE No.	FIG. No.	PAG. No.
DH101380	4	21
DH101380	8	10
DH101387	4	4
DH101392	7	4
DH101509	10	9
DH101607	7	18
DH101781	2	20
DH101784	6	11
DH121038	14	17
DH151029	15	30
DH161066	9	25
DH161121	5	25
DH161194	14	25
DH171019	25	29
DH181023	4	45
DH181024	3	45
DH181025	1	45
DH181026	2	45
DJ101109	20	45
DJ141008	8	35
DJ151033	3	28
DJ151035	4	28
DJ151036	13	23
DJ151037	14	23
DJ151047	16	23
DJ151086	29	29
DJ181043	24	33
DJ181085	25	33
DJ181115	4	22
DJ201051	2	39
DK151094	12	28
DL181080	2	32
DL191014	23	31
DM151029	4	26

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
DM221013	1	44
DP101269	6	12
DP121025	7	1
DP121025	8	17
DP161163	20	25
DP161170	17	25
DP171006	17	23
DS101117	8	15
DS101154	6	6
DS101215	8	12
DS101276	3	4
DS121126	7	17
DS141009	1	36
DS141012	5	45
DS151009	10	26
DS151010	11	26
DS151046	8	26
DS151051	7	26
DS151067	8	28
DS151068	1	28
DS151072	29	29
DS151073	26	29
DS151074	28	29
DS151076	13	28
DS161082	6	45
DS161150	9	13
DS161224	9	43
DS191035	4	30
DS201019	4	39
DS201020	5	39
DS201021	6	39
DS201025	10	43
DS201082	6	43
DU101213	19	7

PARTE No.	FIG. No.	PAG. No.
DU151005	5	27
DU151025	2	26
DU151026	3	26
DU151031	7	27
DU161102	3	35
DU201012	2	41
DU201014	1	41
DU201016	5	41
DU201029	3	39
DX151021	29	29
DZ151012	8	27
DZ151027	9	27
DZ191014	4	40
FD101078	3	19
FD181012	8	32
FD181030	12	31
FD181031	13	31
JA113201	3	25
JA113202	6	25
JA113402	6	22
JA113403	8	22
JA121003	11	23
JA131606	22	27
JA351602	10	20
JA351603	18	20
JA351606	8	20
JA351607	17	20
JA351608	11	20
JA351609	12	20
JA351618	13	20
JA351619	15	20
JA351624	14	20
JA351626	8	20
JA351627	10	20

PARTE No.	FIG. No.	PAG. No.
JA401801	8	43
JA511011	6	1
JA511011	9	17
JA511028	2	2
JA511202	14	45
JA511203	15	45
JA511204	2	3
JA511211	1	3
JA511216	2	4
JA521018	10	4
JA521019	11	4
JA521019	19	12
JA531011	14	4
JA531012	8	6
JA531015	9	6
JA541005	7	13
JA541005	8	11
JA541010	5	10
JA541011	4	10
JA541012	13	10
JA541016	2	19
JA541028	13	21
JA541034	10	11
JA541205	3	13
JA541211	11	12
JA541212	13	12
JA541225	12	12
JA541233	6	13
JA541236	9	12
JA541237	10	12
JA551002	4	7
JA551004	7	7
JA551008	15	7
JA551009	16	7

PARTE No.	FIG. No.	PAG. No.
JA551406	2	14
JA551420	12	14
JA561002	3	8
JA561207	4	9
JA561208	5	9
JA561209	6	9
JA561211	12	9
JA581005	3	17
JA581006	4	17
JA581009	5	17
JA581011	12	17
JA581012	6	17
JA581013	11	17
JA581406	5	2
JA591040	3	18
JA621001	7	15
JA621002	9	15
JA621006	11	15
JA621201	1	15
JA621206	2	15
JA621402	4	20
JA621406	6	20
JA621410	3	20
JA621411	17	45
JA621414	1	20
JB113005	5	18
JB122003	8	23
JB122016	1	23
JB161002	12	30
JB181220	4	37
JB181221	5	37
JB181239	3	37
JB511011	4	1
JB511015	8	1

PARTE No.	FIG. No.	PAG. No.
JB511019	3	2
JB511200	1	46
JB511201	2	46
JB-5212-00-025/47	6	5
JB-5212-00-050/47	6	5
JB-5212-00-075/47	6	5
JB-5212-00-100/47	6	5
JB-5212-00-STD/47	6	5
JB521007	25	45
JB521211	4	5
JB531021	10	6
JB541004	24	45
JB551406	9	14
JB551408	5	14
JB551411	7	14
JB581001	2	17
JB581001	10	17
JB581202	10	16
JB581204	11	16
JB581206	22	46
JB581229	7	16
JB581230	8	16
JB581231	6	46
JB581232	9	16
JB581235	21	46
JB581237	2	16
JB581238	3	16
JB581239	7	46
JB581240	4	46
JB581240	8	46
JB581240	16	46
JB581241	3	46
JB581242	5	46
JB581244	17	46

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
JB581245	18	46
JB581246	19	46
JB581248	19	16
JB581249	23	46
JB581256	16	16
JB581259	13	16
JB581260	17	16
JB581269	9	46
JB581271	7	2
JB581272	8	2
JD511010	3	1
JD521002	1	5
JD541000	19	11
JD561004	6	8
JD561011	4	8
JE541008	14	15
JG571024	13	11
JK113008	18	25
JK541214	2	12
JK541214	10	13
JN131812	10	27
JN131812	14	28
JN171000	4	35
JN402000	12	21
JP541208	3	13
JV161001	4	31
JV161002	5	31
JV161014	9	30
JV181206	2	34
JV181207	3	34
JV181408	9	24
JV181410	10	24
JV191001	2	44
JV351204	5	21

PARTE No.	FIG. No.	PAG. No.
JV351600	7	20
JV401409	21	31
JV401600	1	43
JV401801	7	43
JV401802	8	43
JV402204	19	20
JV521003	8	4
JV541006	15	11
JV541007	2	1
JV541007	4	13
JV541007	11	10
JV541007	16	11
JV541205	18	12
JV541206	5	13
JV541208	5	12
JV541209	15	12
JV541212	5	13
JV541215	2	13
JV541215	14	12
JV541216	10	10
JW122004	14	30
JW131601	19	28
JW561206	2	9
JW561208	3	9
JZ511020	5	1
JZ511021	1	1
JZ531006	22	45
JZ551004	18	7
JZ551204	14	7
JZ551205	13	7
JZ551413	1	14
JZ551415	8	14
JZ551416	23	45
JZ561002	7	8

PARTE No.	FIG. No.	PAG. No.
JZ561401	9	9
JZ621000	10	15
KADF0822	11	25
LCB00005	27	29
LJA00004	14	11
PF 5910 00	1	18
PF111000	1	22
PF113000	10	25
PF113001	12	25
PF113002	15	25
PF113003	16	25
PF113200	1	25
PF113400	5	22
PF113401	5	22
PF121001	1	32
PF121002	20	32
PF121003	21	33
PF121010	5	32
PF121011	22	33
PF122004	4	23
PF131204	23	29
PF131208	22	29
PF131228	11	28
PF131614	8	28
PF141002	7	28
PF141003	7	28
PF161001	2	30
PF161002	1	30
PF161003	6	31
PF161004	8	31
PF161201	1	40
PF161202	3	40
PF161203	7	31
PF161204	2	40

PARTE No.	FIG. No.	PAG. No.
PF161205	9	31
PF171800	4	36
PF171803	6	36
PF231220	28	29
PF231401	7	42
PF231405	3	44
PF231600	10	31
PF231601	11	31
PF351004	2	21
PF351005	1	21
PF351006	2	21
PF351007	1	21
PF351200	6	21
PF401000	1	39
PF401009	10	39
PF401400	2	31
PF401401	3	31
PF401402	3	31
PF401403	5	43
PF402201	3	43
PF402204	3	43
PF501009	1	10
PF501010	1	10
PF511200	1	4
PF521200	6	5
PF531002	4	6
PF541018	7	10
PF541211	1	13
PF551002	1	7
PF551003	8	7
PF551200	6	7
PF551201	5	7
PF551202	2	7
PF551203	10	7

[illegible]

BM100 ES/KS

FICHA TÉCNICA BOXER BM 100 CLASSIC ES

CARACTERÍSTICA	UNIDAD
MOTOR	
Tipo	4 Tiempos
Refrigeración	Aire
Desplazamiento	94.4 cc
Potencia Máxima	7.6 HP @ 8000 rpm
Torque Máximo	7.5 Nm @ 6000 rpm
Encendido	C.D.I
Carburador	Keihin
Transmisión	4 Velocidades
EQUIPO ELÉCTRICO	
Sistema	12 V, AC+DC
Luz Frontal	35/35 W
Pito	12 V, DC
CHASIS	
Tipo	Tubular
SUSPENSIÓN	
Suspensión Delantera	Telescópica
Suspensión Trasera	Brazo Oscilante con Doble Resorte (Spring-In-Spring)
LLANTAS	
Llanta Delantera	2.75 x 17, 41P
Llanta Trasera	3.00 x 17, 50P
FRENOS	
Frenos Delanteros	Bandas Expandibles
Freno Trasero	Bandas Expandibles
TANQUE DE COMBUSTIBLE	
Capacidad del Tanque	14 Litros (3.69 Galones)
Reserva de Combustible	2.5 Litros (0.66 Galones)
DIMENSIONES	
Largo Total	2005 mm
Ancho Total	750 mm
Alto Total	1045 mm
Distancia Entre Ejes	1295 mm
Peso en Seco	118 kg





Línea Gratuita Nacional
01 8000 52 00 90
servicioalcliente@auteco.com.co
www.auteco.com.co



Mobil™