

WORKSHOP MANUAL

RODEO (UE)

FOREWORD

This manual includes special notes, important points, service data, precautions, etc. that are needed for the maintenance, adjustments, service, removal and installation of vehicle components.

All information, illustrations and specifications contained in this manual are based on the latest product information available at the time of publication.

All rights are reserved to make changes at any time without notice.

Arrangement of the material is shown in the table of contents on the right-hand side of this page. A black spot on the first page of each section can be seen on the edge of the book below each section title. These point to a more detailed table of contents preceding each section.

This manual applies to 1999 models.

SECTION	TABLE OF CONTENTS
0A 0B	GENERAL INFORMATION General Information Maintenance and Lubrication
1A	HEATING, VENTILATION AND AIR CONDITIONING HVAC System
2A	STEERING Power-Assisted System
3C 3D 3E	SUSPENSION Front Suspension Rear Suspension Wheel and Tire System
4A1 4A2 4B 4C 4D	DRIVELINE/AXLE Differential Differential Driveline Control System Drive Shaft System Transfer Case
5A 5B 5C 5D1 5D2	BRAKE Brake Control System Anti-Lock Brake System Power-Assisted Brake System Parking Brake System (4x4 model) Parking Brake System (4x2 model)
HEC 6A 6B 6C 6D1 6D2 6D3 6E 6F 6G 6H 6J	6VD1 6A 6B 6C 6D1 6D2 6D3 6E 6F 6G 6H 6J ENGINE Engine Mechanical Engine Cooling Engine Fuel Engine Electrical Ignition System Starting and Charging System Driveability and Emissions Engine Exhaust Engine Lubrication Engine Speed Control System Induction
7A 7A1 7B 7C	TRANSMISSION Automatic Transmission Transmission Control System Manual Transmission Clutch
8A 8B 8C 8D 8E 8F 8G 8H 8I 8J	BODY AND ACCESSORIES Lighting System Wiper/Washer System Entertainment Wiring System Meter and Gauge Body Structure Seats Security and Locks Sun Roof/Convertible Top Exterior/Interior Trim
9A 9J 9J1	RESTRAINTS Seat Belt System Supplemental Restraint System (Air Bag System) Restraint Control System
10A	CONTROL SYSTEM Cruise Control System

GENERAL INFORMATION

CONTENTS

General Information	0A
Maintenance and Lubrication	0B

General Information

CONTENTS

General Repair Instruction	0A-1	Lifting Instructions	0A-10
Illustration Arrows	0A-2	Standard Bolts Torque Specifications	0A-12
Identification	0A-3	Abbreviations Charts	0A-13
Theft Prevention Standard	0A-5	Service Parts Identification Plate	0A-14

General Repair Instruction

1. If a floor jack is used, the following precautions are recommended.
Park vehicle on level ground, "block" front or rear wheels, set jack against the recommended lifting points (see "Lifting Instructions" in this section), raise vehicle and support with chassis stands and then perform the service operations.
2. Before performing service operations, disconnect ground cable from the battery to reduce the chance of cable damage and burning due to short circuiting.
3. Use a cover on body, seats and floor to protect them against damage and contamination.
4. Brake fluid and anti-freeze solution must be handled with reasonable care, as they can cause paint damage.
5. The use of proper tools and recommended essential and available tools, where specified, is important for efficient and reliable performance of service repairs.
6. Use genuine Isuzu parts.
7. Used cotter pins, plastic clips, gaskets, O-rings, oil seals, lock washers and self-locking nuts should be discarded and new ones should be installed, as normal function of the parts cannot be maintained if these parts are reused.
8. To facilitate proper and smooth reassembly operation, keep disassembled parts neatly in groups. Keeping fixing bolts and nuts separate is very important, as they vary in hardness and design depending on position of installation.
9. Clean the parts before inspection or reassembly. Also clean oil ports, etc. using compressed air, and make certain they are free from restrictions.
10. Lubricate rotating and sliding faces of the parts with oil or grease before installation.
11. When necessary, use a sealer on gaskets to prevent leakage.
12. Carefully observe all specifications for bolt and nut torques.

13. When removing or replacing parts that require refrigerant to be discharged from the air conditioning system, be sure to use the Vehicle Refrigerant Recovery and Recycling Equipment (VRRRE) to recover and recycle Refrigerant-134a.

14. When a service operation is completed, make a final check to be sure the service has been done properly and the problem has been corrected.








15. SUPPLEMENTAL RESTRAINT SYSTEM








The vehicle is equipped with a Supplemental Restraint System (SRS) – Air Bags. This system is not to be serviced without consulting the appropriate service information. Consult Section 9J "SRS System" if work is to be done on the front of the vehicle such as bumper, sheet metal, seats, wiring, steering wheel or column. Also review SRS system information if any arc welding is to be done on the vehicle. The SRS system equipped vehicle can be identified by:

1. "AIR BAG" warning light on the instrument cluster.
2. A Code "J" for fifth digit of Vehicle Identification Number.

Illustration Arrows

Arrows are designed for specific purposes to aid your understanding of technical illustrations.


Arrow Type	Application
	Front of vehicle
	Up Side
	Task Related
	View Detail
	View Angle
	Dimension (1:2)
	Sectioning (1:3)

Arrow Type	Application
	<input type="radio"/> Ambient/Clean air flow <input type="radio"/> Cool air flow
	<input type="radio"/> Gas other than ambient air <input type="radio"/> Hot air flow
	<input type="radio"/> Ambient air mixed with another gas <input type="radio"/> Can indicate temperature change
	Motion or direction
	Lubrication point oil or fluid
	Lubrication point grease
	Lubrication point jelly

Identification

Vehicle Identification Number (VIN)

This is the legal identification of the vehicle. It is located on the left bottom of the windshield. It can be easily seen through the windshield from outside the vehicle.




4S2	C	M	5	8	D	*	W	4	300001	
										Sequential Number
										Assembly Plant
										Model Year (W = 1998)(X = 1999)
										Check Digit
										Engine Type (D = 2.2L L4 DOHC ; X22SE) (W = 3.2L V6 DOHC ; 6VD1)
										Body Type (8 = 4 Door Cab ; Long Wheel Base)
										Series
										Vehicle Line (K = 4 x 2 with SRS-Air Bag model) (M = 4 x 4 with SRS-Air Bag model)
										GVWR Range (C = 4001 ~ 5000 LBS)
										World Manufacturer Identifier

F00RX002

Engine Serial Number

○ 6VD1 Engine


The gasoline engine serial number is stamped on the left rear lower area of the cylinder block above the starter.



F06RW001

○ X22SE Engine


The gasoline engine serial number is stamped on the rear end raised area of the cylinder block left side.



03SRW022


Transmission Serial Number

Manual : Stamped on the left side of the transmission intermediate plate.




220RS025

Automatic : Stamped on the identification plate, located on the left side of the transmission above the mode switch.



240RW019







Theft Prevention Standard

The 11 major components listed below will be marked with 17 digit VIN at the stage of production. In addition its service parts will be marked with manufacturer's trade mark, "R" mark and "DOT" mark.

Reference Figure No.	COMPONENT		INDICATION	
			PRODUCTION	SERVICE PARTS
0A-10	ENGINE	1- 6VD1 - X22SE	VIN plate	"R M DOT" Mark stamping
0A-11	TRANSMISSION	2- Manual transmission - Automatic transmission	VIN plate	"R M DOT" Mark stamping
0A-11	BODY	3- Engine hood 4- Front door 5- Rear door 6- Fender 7- Rear Quarter panel 8- Front bumper 9- Back door left side 10- Back door right side 11- Rear bumper	VIN label	" R M DOT " Mark label

Anti Theft Stamping/Plate/Label

	STAMPING/PLATE	LABEL
PRODUCTION	Example 	Example 
SERVICE PARTS		


Anti Theft Stamping/Label/Plate Location

The stamping, label and plate locations are indicated by arrows in the illustration below.

NOTE:


1. VIN plate locations for production.
2. Stamping locations for service parts.

Engine (6VD1)





901RW080


Engine (X22SE)




035RW025

Manual Transmission (TREMEC T5)**Manual Transmission (MUA)**

Automatic Transmission (THM)



Side View




Rear View

901RW082-1


Body

BODY


ENGINE HOOD





FRONT DOOR




REAR DOOR




FENDER




REAR QUARTER PANEL




FRONT BUMPER



TAIL GATE



REAR BUMPER




604RW023

Body Label Instructions

Do not peel off the masking tape until completion of paint work when replacing these parts, as the tape is affixed on the label attached to service parts for body of the anti-theft component.


NOTE: Be sure to pull off the masking tape after paint work has been completed.

Do not attempt to remove this label for any reason.



Precautions in pulling off the masking tape

1. Use only your finger nail or a similar blunt instrument to peel off the masking tape. Use of a sharp object will damage the underlying anti-theft label.
2. Be careful not to damage the paint around the label.




Lifting Instructions

CAUTION:

- If a lifting device other than the original jack is used, it is most important that the device be applied only to the correct lifting points. Raising the vehicle from any other point may result in serious damage.
- When jacking or lifting a vehicle at the frame side rail or other prescribed lift points, be certain that lift pads do not contact the catalytic converter, brake pipes or cables, or fuel lines. Such contact may result in damage or unsatisfactory vehicle performance.


Lifting Points and Supportable Point Locations



C00RX002

Lifting Point: Front


- When using a floor jack, lift on the Convex portion of the skid plate.



54RS001

Supportable Point: Front


- Position the chassis stands at the bottom of the frame sidemember, behind the front wheel.



501RS003

Supportable Point: Rear


- Position the chassis stands at the bottom of the frame sidemember, just behind the trailing link bracket.



501RW002

Lifting Point: Rear

- Position the floor jack at the center of the rear axle case when lifting the vehicle.




420RS002

Legend

- (1) Trailing Link Bracket

Supportable Point: Rear









- Position the chassis stands at the bottom of the rear axle case.



420RS001

Standard Bolts Torque Specifications

The torque values given in the following table should be applied where a particular torque is not specified.

Strength Class	4.8	8.8		9.8
		Refined	Non-Refined	
Bolt Identification				
	 No mark			
Bolt Diameter × Pitch (mm)				
M 6X1.0	4 – 8 N·m (3 – 6 lb ft)	5 – 10 N·m (4 – 7 lb ft)	–	–
M 8X1.25	8 – 18 N·m (6 – 13 lb ft)	12 – 23 N·m (9 – 17 lb ft)	17 – 30 N·m (12 – 22 lb ft)	17 – 30 N·m (12 – 22 lb ft)
M 10X1.25	21 – 34 N·m (15 – 25 lb ft)	28 – 46 N·m (20 – 34 lb ft)	37 – 63 N·m (27 – 46 lb ft)	37 – 63 N·m (27 – 46 lb ft)
* M10X1.5	20 – 33 N·m (14 – 25 lb ft)	28 – 45 N·m (20 – 33 lb ft)	36 – 60 N·m (27 – 44 lb ft)	36 – 60 N·m (27 – 44 lb ft)
M12X1.25	49 – 74 N·m (36 – 54 lb ft)	61 – 91 N·m (45 – 67 lb ft)	76 – 114 N·m (56 – 84 lb ft)	76 – 114 N·m (56 – 84 lb ft)
* M12X1.75	45 – 69 N·m (33 – 51 lb ft)	57 – 84 N·m (42 – 62 lb ft)	72 – 107 N·m (53 – 79 lb ft)	72 – 107 N·m (53 – 79 lb ft)
M14X1.5	77 – 115 N·m (56 – 85 lb ft)	93 – 139 N·m (69 – 103 lb ft)	114 – 171 N·m (84 – 126 lb ft)	114 – 171 N·m (84 – 126 lb ft)
* M14X2.0	72 – 107 N·m (53 – 79 lb ft)	88 – 131 N·m (65 – 97 lb ft)	107 – 160 N·m (79 – 118 lb ft)	107 – 160 N·m (79 – 118 lb ft)
M16X1.5	104 – 157 N·m (77 – 116 lb ft)	135 – 204 N·m (100 – 150 lb ft)	160 – 240 N·m (118 – 177 lb ft)	160 – 240 N·m (118 – 177 lb ft)
* M16X2.0	100 – 149 N·m (74 – 110 lb ft)	130 – 194 N·m (95 – 143 lb ft)	153 – 230 N·m (113 – 169 lb ft)	153 – 230 N·m (113 – 169 lb ft)
M18X1.5	151 – 226 N·m (111 – 166 lb ft)	195 – 293 N·m (144 – 216 lb ft)	230 – 345 N·m (169 – 255 lb ft)	230 – 345 N·m (169 – 255 lb ft)
M20X1.5	206 – 310 N·m (152 – 229 lb ft)	270 – 405 N·m (199 – 299 lb ft)	317 – 476 N·m (234 – 351 lb ft)	317 – 476 N·m (234 – 351 lb ft)
M22X1.5	251 – 414 N·m (185 – 305 lb ft)	363 – 544 N·m (268 – 401 lb ft)	425 – 637 N·m (313 – 469 lb ft)	425 – 637 N·m (313 – 469 lb ft)
M24X2.0	359 – 539 N·m (265 – 398 lb ft)	431 – 711 N·m (318 – 524 lb ft)	554 – 831 N·m (409 – 613 lb ft)	554 – 831 N·m (409 – 613 lb ft)

The asterisk * indicates that the bolts are used for female-threaded parts that are made of soft materials such as casting, etc.

Abbreviations Charts

List of automotive abbreviations which may be used in this manual


A — Ampere(s)	Exh — Exhaust
ABS — Antilock Brake System	° F — Degrees Fahrenheit
AC — Alternating Current	Fed — Federal (All States Except Calif.)
A/C — Air Conditioning	FF — Front Drive Front Engine
ACCEL — Accelerator	FL — Fusible Link
ACC — Accessory	FLW — Fusible Link Wire
ACL — Air Cleaner	FP — Fuel Pump
Adj — Adjust	FRT — Front
A/F — Air Fuel Ratio	ft — Foot
AIR — Secondary Air Injection System	FWD — Front Wheel Drive
Alt — Altitude	4WD — Four Wheel Drive
AMP — Ampere(s)	4 x 4 — Four Wheel Drive
ANT — Antenna	4 A/T — Four Speed Automatic Transmission/Transaxle
ASM — Assembly	Gal — Gallon
A/T — Automatic Transmission/Transaxle	GEN — Generator
ATDC — After Top Dead Center	GND — Ground
ATF — Automatic Transmission Fluid	Gov — Governor
Auth — Authority	g — Gram
Auto — Automatic	Harn — Harness
BARO — Barometric Pressure	HC — Hydrocarbons
Bat — Battery	HD — Heavy Duty
B+ — Battery Positive Voltage	Hg — Hydrargyrum (Mercury)
Bbl — Barrel	HiAlt — High Altitude
BHP — Brake Horsepower	HO2S — Heated Oxygen Sensor
BPT — Backpressure Transducer	HVAC — Heater-Vent-Air-Conditioning
BTDC — Before Top Dead Center	IAC — Idle Air Control
° C — Degrees Celsius	IAT — Intake Air Temperature
CAC — Charge Air Cooler	IC — Integrated Circuit / Ignition Control
Calif — California	ID — Identification / Inside Diameter
cc — Cubic Centimeter	IGN — Ignition
CID — Cubic Inch Displacement	INJ — Injection
CKP — Crankshaft Position	IP — Instrument Panel
CL — Closed Loop	IPC — Instrument Panel Cluster
CLCC — Closed Loop Carburetor Control	Int — Intake
CMP — Camshaft Position	ISC — Idle Speed Control
CO — Carbon Monoxide	J/B — Junction Block
Coax — Coaxial	kg — Kilograms
Conn — Connector	km — Kilometers
Conv — Converter	km/h — Kilometer per Hour
Crank — Crankshaft	kPa — Kilopascals
Cu. In. — Cubic Inch	kV — Kilovolts (thousands of volts)
CV — Constant Velocity	kW — Kilowatts
Cyl — Cylinder(s)	KS — Knock Sensor
DI — Distributor Ignition	L — Liter
Diff — Differential	lb ft — Foot Pounds
Dist — Distributor	lb in — Inch Pounds
DLC — Data Link Connector	LF — Left Front
DOHC — Double Overhead Camshaft	LH — Left Hand
DTC — Diagnostic Trouble Code	LR — Left Rear
DTM — Diagnostic Test Mode	LS — Left Side
DTT — Diagnostic Test Terminal	LWB — Long Wheel Base
DVM — Digital Voltmeter (10 meg.)	L-4 — In-Line Four Cylinder Engine
DVOM — Digital Volt Ohmmeter	MAF — Mass Air Flow
EBCM — Electronic Brake Control Module	MAN — Manual
ECM — Engine Control Module	MAP — Manifold Absolute Pressure
ECT — Engine Coolant Temperature	Max — Maximum
EEPROM — Electronically Erasable Programmable Read Only Memory	MC — Mixture Control
EGR — Exhaust Gas Recirculation	MFI — Multiport Fuel Injection
EI — Electronic Ignition	MIL — Malfunction Indicator Lamp
ETR — Electronically Tuned Receiver	Min — Minimum
EVAP — Evaporation Emission	mm — Millimeter
	MPG — Miles Per Gallon
	MPH — Miles Per Hour
	M/T — Manual Transmission/Transaxle
	MV — Millivolt

N — Newtons
NA — Natural Aspirated
NC — Normally Closed
N·M — Newton Meters
NO — Normally Open
NOX — Nitrogen, Oxides of
OBD — On-Board Diagnostic
OD — Outside Diameter
O/D — Over Drive
OHC — Overhead Camshaft
OL — Open Loop
O₂ — Oxygen
O₂S — Oxygen Sensor
PAIR — Pulsed Secondary Air Injection System
P/B — Power Brakes
PCM — Powertrain Control Module
PCV — Positive Crankcase Ventilation
PRESS — Pressure
PROM — Programmable Read Only Memory
PNP — Park/Neutral Position
P/S — Power Steering
PSI — Pounds per Square Inch
PSP — Power Steering Pressure
Pt. — Pint
Pri — Primary
PWM — Pulse Width Modulate
Qt. — Quart
REF — Reference
RF — Right Front
RFI — Radio Frequency Interference
RH — Right Hand
RPM — Revolutions Per Minute
RPM Sensor — Engine Speed Sensor
RPO — Regular Production Option
RR — Right Rear
RS — Right Side
RTV — Room Temperature Vulcanizing
RWAL — Rear Wheel Antilock Brake
RWD — Rear Wheel Drive
SAE — Society of Automotive Engineers
Sec — Secondary
SFI — Sequential Multiport Fuel Injection
SI — System International
SIR — Supplemental Inflatable Restraint System
SOHC — Single Overhead Camshaft
Sol — Solenoid
SPEC — Specification
Speedo — Speedometer
SRS — Supplemental Restraint System
ST — Start / Scan Tool
Sw — Switch
SWB — Short Wheel Base
SYN — Synchronize
Tach — Tachometer
TB — Throttle Body
TBI — Throttle Body Fuel Injection
TCC — Torque Converter Clutch
TCM — Transmission Control Module
TDC — Top Dead Center
Term — Terminal
TEMP — Temperature
TOD — Torque On Demand
TP — Throttle Position
TRANS — Transmission/Transaxle
TURBO — Turbocharger

TVRS — Television & Radio Suppression
TVV — Thermal Vacuum Valve
TWC — Three Way Catalytic Converter
3 A/T — Three Speed Automatic Transmission/Transaxle
2WD — Two Wheel Drive
4 x 2 — Two Wheel Drive
U-joint — Universal Joint
V — Volt(s)
VAC — Vacuum
VIN — Vehicle Identification Number
VRRRE — Vehicle Refrigerant Recovery and Recycling Equipment
V-ref — ECM Reference Voltage
VSS — Vehicle Speed Sensor
VSV — Vacuum Switch Valve
V-6 — Six Cylinder "V" Engine
V-8 — Eight Cylinder "V" Engine
W — Watt(s)
w/ — With
w/b — Wheel Base
w/o — Without
WOT — Wide Open Throttle

Service Parts Identification Plate

The Vehicle Information Plate (Service Parts ID plate) is provided on all vehicle models. It is located on the center dash wall inside the engine compartment. The plate lists the VIN (Vehicle Identification Number), paint information and all production options and special equipment on the vehicle when it was shipped from the factory.



RODEO

GENERAL INFORMATION

Maintenance and Lubrication

CONTENTS

Maintenance Schedule List	0B-1	Lubricant Viscosity Chart	0B-9
Explanation of Complete Vehicle Maintenance Schedule	0B-5	Recommended Liquid Gasket	0B-11
Recommended Fluids and Lubricants	0B-8	Recommended Thread Locking Agents ...	0B-12
		Maintenance Service Data	0B-13

Maintenance Schedule List

Normal Vehicle Use

The maintenance instructions in this Maintenance Schedule are based on the assumption that the vehicle will be used as designed:

- ☐ to carry passengers and cargo within the limitations specified on the tire placard located on the inside of the glove compartment door;
- ☐ to be driven on reasonable road surfaces within legal operating limits;
- ☐ to be driven on a daily basis, as a general rule, for at least several miles/kilometers;
- ☐ to be driven on unleaded fuel

Unusual or severe operating conditions will require more frequent vehicle maintenance, as specified in the following sections.

Severe Driving Conditions

If the vehicle is usually operated under any of the severe driving conditions listed below, it is recommended that the applicable maintenance services be performed at the specified interval shown in the chart below.

Severe driving conditions:

- ☐ Towing a trailer, using a camper or car top carrier.
- ☐ Repeated short trips of less than 8 Km (5 miles) with outside temperature remaining below freezing.
- ☐ Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use.
- ☐ Operating on dusty, rough, muddy or salt spread roads.

ITEMS	INTERVAL
CHANGE ENGINE OIL AND OIL FILTER	Every 3,000 miles (4,800 km) or 3 months
CHANGE AUTOMATIC TRANSMISSION FLUID	Every 20,000 miles (32,000 km)
CHANGE REAR AXLE OIL	Every 15,000 miles (24,000 km)
REPLACE TIMING BELT	Every 75,000 miles (120,000 km)
REPLACE AIR CLEANER FILTER	See explanation of service, page 0B-5
CHANGE POWER STEERING FLUID	Every 30,000 miles (48,000 km)

Mileage Only Items

MILEAGE ONLY ITEMS

MILEAGE ONLY ITEMS		IN THOUSANDS OF MILES (USE ODOMETER READING)														(x 1000 miles)		
		7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	DESCRIPTION
1	* ⁽¹⁾ CHANGE FRONT AND REAR AXLE OIL																	
2	CHANGE MANUAL TRANSMISSION AND TRANSFER CASE OIL(4WD model)																	
3	CHECK AND ADJUST CLEARANCE(V6-3.2L engine)																	
4	REPLACE AIR CLEANER ELEMENT																	
5	REPLACE SPARK PLUGS																	
6	CHANGE ENGINE COOLANT																	
7	* ⁽²⁾ REPLACE TIMING BELT																	
8	ROTATE TIRES																	
9	REPACK FRONT WHEEL BEARINGS GREASE																	
10	CLEAN RADIATOR CORE AND A/C CONDENSER																	
11	CHECK SPARK PLUG WIRES (I4- 2.2L engine)																	

*⁽¹⁾ : Under severe driving conditions, additional maintenance is required.
Refer to "Severe driving conditions".

*⁽²⁾ : Replacement of the timing belt is recommended at every 100,000 miles (160,000km)

SHADED AREA INDICATES SERVICE TO BE PERFORMED.

Mileage/Months

MILEAGE/MONTHS

MILEAGE/MONTHS whichever comes first		IN THOUSANDS OF MILES (USE ODOMETER READING)																	(x 1000 miles)
		Max Miles Months	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	
1	CHECK BATTERY FLUID LEVEL	12																	
2	CHECK ENGINE COOLANT LEVEL	12																	
3	CHECK BRAKE FLUID LEVEL	12																	
4	CHECK CLUTCH FLUID LEVEL	12																	
5	CHECK FLUID LEAKS	12																	
6	* (1) CHANGE ENGINE OIL	12																	
7	* (1) REPLACE ENGINE OIL FILTER	12																	
8	CHECK COOLING AND HEATER HOSES	12																	
9	* (2) CHECK EXHAUST SYSTEM	12																	
10	* (2) CHECK FUEL LINE AND FUEL TANK/CAP	12																	
11	CHECK ENGINE DRIVE BELTS	24																	
12	CHECK TIRES AND WHEELS	12																	
13	CHECK STEERING OPERATION	12																	
14	CHECK BRAKE LINES AND HOSES	12																	
15	CHECK DRUM AND DISC BRAKES	12																	
16	CHECK PARKING BRAKE	12																	
17	* (1) CHECK AUTOMATIC TRANSMISSION FLUID	12																	

* (1) : Under severe driving conditions, additional maintenance is required.
Refer to "Severe driving conditions".

* (2) : This service is recommended for vehicles sold in California, and it is required for vehicles sold in other areas.

SHADED AREA INDICATES SERVICE TO BE PERFORMED.

MILEAGE/MONTHS

MILEAGE/MONTHS whichever comes first		IN THOUSANDS OF MILES (USE ODOMETER READING)														(x 1000 miles)			
		Max. Miles Months	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5		105	112.5	120
18	ADJUST BRAKE PEDAL PLAY	12																	
19	LUBE ACCELERATOR LINKAGE	6																	
20	LUBE BODY AND CHASSIS	6																	
21	CHECK FRONT AND REAR PROPELLER SHAFT	6																	
22	CHECK CLUTCH LINES AND HOSE	12																	
23	LUBE CLUTCH PEDAL SPRING, BUSHING AND CLEVIS PIN	6																	
24	CHECK CLUTCH PEDAL FREE PLAY	12																	
25	CHECK PROPELLER SHAFT FLANGE TORQUE	12																	
26	CHECK STARTER SAFETY SWITCH	12																	
27	CHECK THROTTLE LINKAGE	12																	
28	CHECK SUSPENSION&STEERING	12																	
29	CHECK AUTO CRUISE CONTROL LINKAGE AND HOSE	12																	
30	LUBE KEY LOCK CYLINDER	12																	
31	CHECK SHIFT ON THE FLY SYSTEM GEAR FLUID	12																	
32	CHECK POWER STEERING FLUID LEVEL	6																	

SHADED AREA INDICATES SERVICE TO BE PERFORMED.

Explanation of Complete Vehicle Maintenance Schedule

Brief explanations of the services listed in the preceding Maintenance Schedule are presented below. Replace all questionable parts and note any necessary repairs as you perform these maintenance procedures.

Front and Rear Axle Lubricant Replacement

Check the lubricant level after every 7,500 miles (12,000 km) of operation and add lubricant to level of filler hole if necessary.

Replace the front and rear axle lubricant at 15,000 miles (24,000 km) and 30,000 miles (48,000 km) and after every 30,000 miles (48,000 km) of operation thereafter.

Manual Transmission Lubricant Replacement (MUA Type)

Check the lubricant level after every 7,500 miles (12,000 km) of operation and add lubricant to level of filler hole if necessary.

Replace the transmission lubricant at 15,000 miles (24,000 km) and 30,000 miles (48,000 km) and after every 30,000 miles (48,000 km) of operation thereafter.

Transfer Case Lubricant Replacement

Check the lubricant level after every 7,500 miles (12,000 km) of operation and add lubricant to level of filler hole if necessary.

Replace the transfer case lubricant at 15,000 miles (24,000 km) and 30,000 miles (48,000 km) and after every 30,000 miles (48,000 km) of operation thereafter.

Air Cleaner Element Replacement

Replace the air cleaner under normal operating conditions every 30,000 miles (48,000 km).

Operation of the vehicle in dusty areas will necessitate more frequent replacement.

Spark Plug Replacement

Replace the plugs at 100,000 miles (160,000 km) intervals with the type specified at the end of this section.

Cooling System Service

Drain, flush and refill system with new engine coolant. Refer to "Recommended Fluids and Lubricants" in this section, or ENGINE COOLING (SEC.6B).

Timing Belt Replacement

Replacement of the timing belt is recommended at every 100,000 miles (160,000 km).

Failure to replace the timing belt may result in serious damage to the engine.

Valve Clearance Adjustment (V6, 3.2L ENG)

Incorrect valve clearance will result in increased engine noise and reduced engine output.

Retorque the camshaft bracket bolts before checking and adjusting the valve clearance.

Check and adjust the valve clearance every 60,000 miles (100,000 km).

Tire Rotation

Rotate tires every 7,500 miles (12,000 km).

Spark Plug Wire Inspection

Check the spark plug wires at 60,000 mile (96,000 km) intervals.

Front Wheel Bearings Lubricant Replacement

Clean and repack the front wheel bearings at 30,000 miles (48,000 km) intervals.

Refer to DRIVE SHAFT SYSTEM (SEC. 4C).

Radiator Core and Air Conditioning Condenser Cleaning

Clean the front of the radiator core and air conditioning condenser, at 60,000 miles (96,000 km) intervals.

Fluid Level Check

A fluid loss in any system (except windshield washer) may indicate a problem. Repair the system at once.

Engine oil level

Check level and add if necessary. The best time to check the engine oil level is when the oil is warm. After stopping the engine with the vehicle on a level surface, wait a few minutes for the oil to drain back to the oil pan. Pull out the oil level indicator (dipstick). Wipe it clean and push the oil level indicator back down all the way. Pull out the oil level indicator, keeping the tip down, and look at the oil level on it.

Add oil, if needed, to keep the oil level above the "ADD" mark and between the "ADD" and "FULL" marks in the operating range area. Avoid overfilling the engine since this may cause engine damage. Push the oil level indicator back down all the way after taking the reading. If you check the oil level when the oil is cold, do not run the engine first. The cold oil will not drain back to the pan fast enough to give a true oil level.

Engine coolant level and condition

Check engine coolant level in the coolant reservoir and add engine coolant if necessary. Inspect the engine coolant and replace it if dirty or rusty.

Windshield washer fluid level

Check washer fluid level in the reservoir and add if necessary.

Power steering system reservoir level

Check and keep at the proper level.

Brake master cylinder reservoir level

Check fluid. Keep fluid at proper level. A low fluid level can indicate worn disc brake pads which may need to be serviced.

Hydraulic clutch system

Check fluid level in the reservoir. Add fluid as required.

Battery fluid level

Check fluid level in the battery.

Fluid Leak Check

Check for fuel, water, oil or other fluid leaks by looking at the surface beneath the vehicle after it has been parked for a while. Water dripping from the air conditioning system after use is normal. If you notice gasoline fumes or fluid at any time, locate the source and correct it at once.

Engine Oil and Oil Filter Replacement

Always use API SE, SF, SG, SH or ILSAC GF-1 quality oils of the proper viscosity.

When choosing an oil, consider the range of temperatures the car will be operated in before the next oil change. Then, select the recommended oil viscosity from the chart.

Always change the oil and the oil filter as soon as possible after driving in a dust storm.

Engine Cooling System Inspection

Inspect the coolant/anti-freeze. If the coolant is dirty or rusty, drain, flush and refill with new coolant. Keep coolant at the proper mixture for proper freeze protection, corrosion inhibitor level and best engine operating temperature. Inspect hoses and replace if cracked, swollen or deteriorated. Tighten the hose clamps if equipped with screw-type clamps. Clean outside of radiator and air conditioning condenser. Wash filler cap and neck. To help ensure proper operation, a pressure test of both the cooling system and the cap is also recommended.

Exhaust System Inspection

Visually inspect the exhaust pipes, muffler, heat shields and hangers for cracks, deterioration, or damage.

Be alert to any changes in the sound of the exhaust system or any smell of fumes. These are signs the system may be leaking or overheating. Repair the system at once, if these conditions exist. (See also "Engine Exhaust Gas Safety" and "Three Way Catalytic Converter" in the Owner's manual.)

Fuel Cap, Fuel Lines, and Fuel Tank Inspection

Inspect the fuel tank, the fuel cap and the fuel lines every 60,000 miles (96,000 km) for damage which could cause leakage.

Inspect the fuel cap and the gasket for correct sealing and physical damage. Replace any damaged parts.

Drive Belt Inspection

Check the serpentine belt driving for cracks, fraying, wear, and correct tension every 30,000 miles (48,000 km). Replace as necessary.

Wheel Alignment, Balance and Tires Operation

Uneven or abnormal tire wear, or a pull right or left on a straight and level road may show the need for a wheel alignment. A vibration of the steering wheel or seat at

normal highway speeds means a wheel balancing is needed. Check tire pressure when the tires are "cold" (include the spare).

Maintain pressure as shown in the tire placard, which is located on the driver's door lock pillar.

Steering System Operation

Be alert for any changes in steering action. An inspection or service is needed when the steering wheel is harder to turn or has too much free play, or if there are unusual sounds when turning or parking.

Brake Systems Operation

Watch for the "BRAKE" light coming on. Other signs of possible brake trouble are such things as repeated pulling to one side when braking, unusual sounds when braking or between brake applications, or increased brake pedal travel. If you note one of these conditions, repair the system at once.

For convenience, the following should be done when wheels are removed for rotation: Inspect lines and hoses for proper hookup, bindings, leaks, crack, chafing etc. Inspect disc brake pads for wear and rotors for surface condition.

Inspect other brake parts, including parking brake drums, linings etc., at the same time. Check parking brake adjustment.

Inspect the brakes more often if habit or conditions result in frequent braking.

Parking Brake and Transmission Park Mechanism Operation

Park on a fairly steep hill and hold the vehicle with the parking brake only. This checks holding ability. On automatic transmission vehicles, shifting from "P" position to the other positions cannot be made unless the brake pedal is depressed when the key switch is in the "ON" position or the engine is running.

WARNING: BEFORE CHECKING THE STARTER SAFETY SWITCH OPERATION BELOW, BE SURE TO HAVE ENOUGH ROOM AROUND THE VEHICLE. THEN FIRMLY APPLY BOTH THE PARKING BRAKE AND THE REGULAR BRAKE. DO NOT USE THE ACCELERATOR PEDAL. IF THE ENGINE STARTS, BE READY TO TURN OFF THE KEY PROMPTLY. TAKE THESE PRECAUTIONS BECAUSE THE VEHICLE COULD MOVE WITHOUT WARNING AND POSSIBLY CAUSE PERSONAL INJURY OR PROPERTY DAMAGE.

Starter Safety Switch Operation (Automatic Transmission)

Check by trying to start the engine in each gear while setting the parking brake and the foot brake. The starter should crank only in "P" (Park) or "N" (Neutral).

Starter Safety Switch Operation (Manual Transmission)

To check, place the shift lever in "Neutral", push the clutch pedal halfway and try to start. The starter should not

crank. The starter should crank only when the clutch pedal is fully depressed.

Accelerator Linkage Lubrication

Lubricate the accelerator pedal fulcrum pin with chassis grease.

Steering and Suspension Inspection

Inspect the front and rear suspension and steering system for damaged, loose or missing parts or signs of wear. Inspect power steering lines and hoses for proper hookup, binding, leaks, cracks, chafing, etc.

Body and Chassis Lubrication

Lubricate the key lock cylinders, the hood latch, the hood and door hinges, the door check link, the parking cable guides, the underbody contact points, and the linkage.

Propeller Shaft Inspection and Lubrication

Check the propeller shaft flange-to-pinion bolts for proper torque to 63 N•m (46 lb ft) for front and rear propeller shaft.

Automatic Transmission Fluid Replacement

Under harsh operating conditions, such as constant driving in heavy city traffic during hot weather, or in hilly or mountainous terrain, change the transmission fluid and service the sump filter after every 20,000 miles (32,000 km) of operation.

More over, the remaining life percentage of ATF can be estimated by using TECH-II as an auxiliary tool to judge the right time for ATF replacement.

The remaining life percentage is calculated from ATF'S heat history. When it is close to 0%, ATF replacement is recommended.

Auto Cruise Control Inspection

Check to see if the clearance between cruise link and accelerator link is normal. Also check that the connected properly.

Clutch Lines and Hoses Inspection

Check lines and hoses for proper attachment, binding, leaks, cracks, chafing, deterioration, etc. Any questionable parts should be replaced or repaired at once. When abrasion or wear is evident on lines or hoses, the cause must be corrected.

Clutch Control Lubrication

Lubricate the clutch pedal bushing, the clevis pin, and pedal spring every 15,000 miles (24,000 km) or 6 months. If a squeaking noise arises from around the bushing or the clevis pin at the clutch pedal arm when the clutch pedal is depressed, lubricate them.

Clutch Pedal Free Play Inspection

Note the clutch pedal free play. It should be 5 – 15 mm (0.2 – 0.6 in). Adjust clutch control when there is little or no free play.

Accelerator Linkage Inspection

Inspect for interference, binding, and damaged or missing parts. Check accelerator pedal for smooth operation and even pedal effort. Replace parts as needed.


Recommended Fluids and Lubricants

USAGE	FLUID/LUBRICANT
Engine	API SE, SF, SG, SH or ILSAC GF-1 Engine oil (See oil chart on the following page for proper viscosity)
Engine coolant	Mixture of water and good quality ethylene glycol base type antifreeze.
Brake system	DOT-3 hydraulic brake fluid.
Power steering system	DEXRON® II-E Automatic transmission fluid.
Automatic transmission & T5 Type Manual Transmission	DEXRON® -III Automatic transmission fluid.
MUA Type Manual transmission & Transfer case	Engine oil (See oil chart on following page for proper viscosity)
Rear axle and front axle	GL-5 gear lubricant (Standard differential) GL-5 Limited slip differential gear lubricant together with limited slip differential lubricant additive (Part No. 8-01052-358-0) or equivalent (If equipped with optional limited slip differential) (See oil chart in this section for proper viscosity)
Clutch system a. Pivot points b. Clutch fork joint c. Master cylinder	Chassis grease Chassis grease DOT-3 hydraulic brake fluid
Hood latch assembly a. Pivots and spring anchor b. Release pawl	Engine oil Chassis grease
Hood and door hinges	Engine oil
Chassis lubrication	Chassis grease
Parking brake cables	Chassis grease
Front wheel bearings	Multipurpose grease
Shift on the fly system	GL-5 gear lubricant (SAE 75W-90)
Body door hinge pins and linkage, fuel door hinge, rear compartment lid hinges	Engine oil
Windshield washer solvent	Washer fluid
Key lock cylinder	Synthetic light weight engine oil (SAE 5W-30)
Accelerator linkage	Chassis grease


Lubricant Viscosity Chart

Lubricants should be carefully selected according to the lubrication chart. It is also important to select viscosity of lubricants according to the ambient temperature by referring to the following table.


Oil Viscosity Chart for Gasoline Engine




Oil Viscosity Chart for Manual Transmission and Transfer Case (Except T5 Type)



Oil Viscosity Chart for Front Axle



Oil Viscosity Chart for Rear Axle



B00RW004

Recommended Liquid Gasket

Type	Brand Name	Manufacturer	Remarks
RTV* Silicon Base	Three Bond 1207B Three Bond 1207C Three Bond 1215 Three Bond 1280 Three Bond 1281	Three Bond Three Bond Three Bond Three Bond Three Bond	For Engine Repairs For Axle Case Repairs T/M Repairs T/M
Water Base	Three Bond 1141E	Three Bond	For Engine Repairs
Solvent	Three Bond 1104 Belco Bond 4 Belco Bond 401 Belco Bond 402	Three Bond Isuzu Isuzu Isuzu	For Engine Repairs
Anaerobic	LOCTITE 515 LOCTITE 518 LOCTITE 17430	Loctite Loctite Loctite	All

* RTV: Room Temperature Vulcanizer

NOTE:

1. It is very important that the liquid gaskets listed above or their exact equivalent be used on the vehicle.
2. Be careful to use the specified amount of liquid gasket.
Follow the manufacturer's instructions at all times.

3. Be absolutely sure to remove all lubricants and moisture from the connecting surfaces before applying the liquid gasket.

The connecting surfaces must be perfectly dry.


4. Do not apply LOCTITE 17430, LOCTITE 515 and LOCTITE 518 between two metal surfaces having a clearance of greater than 0.25 mm (0.01 in). Poor adhesion will result.

Recommended Thread Locking Agents

LOCTITE Type	LOCTITE Color
LOCTITE 242	Blue
LOCTITE 262	Red
LOCTITE 271	Red

Application Steps

1. Completely remove all lubricant and moisture from the bolts and the female-threaded surfaces of the parts to be joined.
The surfaces must be perfectly dry.
2. Apply LOCTITE to the bolts.



3. Tighten the bolts to the specified torque.
After tightening, be sure to keep the bolts free from vibration and torque for at least an hour until LOCTITE hardens.

NOTE: When the application procedures are specified in this manual, follow them.

Maintenance Service Data

Service Data and Specifications

ENGINE	Valve clearance (cold): only V6-3.2L ENG	Intake 0.28±0.05 mm (0.011±0.002 in) Exhaust 0.3±0.05 mm (0.012±0.002 in)	
	Spark plug type	K16PR-P11/PK16PR11/RC10PYP4	
	Spark plug gap	1.05 mm (0.04 in)	
CLUTCH	Clutch pedal free play	5-15 mm (0.20-0.59 in)	
BRAKE	Brake pedal free play	6-10 mm (0.24-0.39 in)	
	Parking brake travel	6-7 notches	
WHEEL ALIGNMENT	Toe-in (Front)	0±2 mm (0±0.08 in)	
	Toe-in (Rear)	0±5 mm (0±0.2 in)	
	Camber (Front)	0°±30'	
	Camber (Rear)	0°±1°	
	Caster (Front)	2° 30'±45'	
	Toe-Axis (Rear)	±1°	
PROPELLER SHAFT	Flange torque	63 N·m (46 lb ft)	
WHEEL AND TIRES	Size	P215/75R15, P235/75R15	P245/70R16
	Wheel nut torque	118 N·m (87 lb ft)	
	Tire inflation pressure (Front)	200 kPa (29 psi)	180 kPa
	* Tire inflation pressure (Rear)	200 kPa (29 psi)	180 kPa

* Unless otherwise specified on tire information label on the vehicle.

Approximate Capacities

	Items	Metric Measure	U.S. Measure
Fuel tank		80 L	21.1 Gal.
* Crankcase (V6-3.2L ENGINE)	Oil Change with Filter	4.7 L	5.0 Qt
	Oil Change without Filter	4.0 L	4.2 Qt
* Crankcase (L4-2.2L ENGINE)	Oil Change with Filter	4.5 L	4.8 Qt
	Oil Change without Filter	4.2 L	4.4 Qt
Coolant	M/T (V6-3.2L ENG)	11.0 L	11.6 Qt
	M/T (L4-2.2L ENG)	6.9 L	7.3 Qt
	A/T	11.1 L	11.7 Qt
Transmission	Manual (V6-3.2L ENG)	2.95 L	3.1 Qt
	Manual (L4-2.2L ENG)	2.13 L	2.25 Qt
	Automatic	8.6 L	9.1 Qt
Transfer		1.45 L	1.5 Qt
Axle	Rear	1.77 L	1.87 Qt
	Front	1.25 L	1.33 Qt
Shift on the fly system		0.12 L	0.13 Qt
Power steering		1.0 L	1.1 Qt
Air conditioning (R-134a)		0.6 L	1.32 Qt

*Crankcase capacities shown are approximate refill capacities. After refill, recheck oil level.

RODEO

HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

HVAC SYSTEMS

CONTENTS

Service Precaution	1A-2	Control Lever Assembly and / or Control Cable	1A-23
Heating and Ventilation System	1A-2	Control Lever Assembly, Control Cable and Associated Parts	1A-23
General Description	1A-2	Removal	1A-24
Wiring Diagram	1A-6	Installation	1A-25
Diagnosis	1A-7	Control Panel Illumination Bulb	1A-26
Individual Inspection	1A-11	Control Panel Illumination Bulb and Associated Parts	1A-26
Heater Unit	1A-13	Removal	1A-26
Heater Unit and Associated Parts	1A-13	Installation	1A-26
Removal	1A-13	Resistor	1A-26
Installation	1A-14	Resistor and Associated Parts	1A-26
Heater Core and / or Mode Door	1A-14	Removal	1A-26
Disassembled View	1A-14	Installation	1A-26
Removal	1A-14	Air Conditioning System	1A-27
Inspection	1A-15	General Description	1A-27
Installation	1A-15	Diagnosis	1A-35
Heater Mode Control Link Unit	1A-16	Individual Inspection	1A-44
Disassembled View	1A-16	General Repair Procedure	1A-45
Removal	1A-16	Leak Check	1A-47
Installation	1A-17	Compressor Assembly	1A-52
Heater Temperature Control Link Unit	1A-17	Compressor Assembly and Associated Parts	1A-52
Disassembled View	1A-17	Removal	1A-52
Removal	1A-17	Installation	1A-53
Installation	1A-18	New Compressor Installation	1A-53
Blower Assembly	1A-18	Condenser Assembly	1A-54
Blower Assembly and Associated Parts ..	1A-18	Condenser Assembly and Associated Parts	1A-54
Removal	1A-18	Removal	1A-54
Installation	1A-19	Installation	1A-54
Blower Link Unit and / or Mode door	1A-19	Condenser Fan Motor	1A-55
Disassembled View	1A-19	Condenser Fan Motor and Associated Parts	1A-55
Removal	1A-19	Removal	1A-55
Installation	1A-20	Installation	1A-55
Blower Motor	1A-21	Receiver / Drier	1A-56
Blower Motor and Associated Parts	1A-21	Receiver / Drier and Associated Parts	1A-56
Removal	1A-21	Removal	1A-56
Installation	1A-21	Installation	1A-56
Rear Heater Duct, Defroster Nozzle and Ventilation Duct	1A-22	Pressure Switch	1A-57
Rear Heater Duct, Defroster Nozzle, Ventilation Duct and Associated Parts ...	1A-22	Pressure Switch and Associated Parts ...	1A-57
Removal	1A-22		
Installation	1A-23		

1A-2 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Removal	1A-57	Diagnosis	1A-66
Installation	1A-57	Magnetic Clutch Assembly (DKV-14D Type)	1A-67
Evaporator Assembly	1A-58	Parts Location View	1A-67
Evaporator Assembly and Associated Parts	1A-58	Removal	1A-67
Removal	1A-58	Inspection and Repair	1A-68
Installation	1A-59	Installation	1A-69
Electronic Thermostat, Evaporator Core and/or Expansion Valve	1A-59	Compressor Oil	1A-70
Disassembled View	1A-59	Oil Specification	1A-70
Removal	1A-60	Handling of Oil	1A-70
Installation	1A-60	Compressor Oil Check	1A-70
Refrigerant Line	1A-61	Checking and Adjusting Oil Quantity for Used Compressor	1A-70
Refrigerant Line and Associated Parts	1A-61	Checking and Adjusting for Compressor Replacement	1A-71
Removal	1A-62	Contamination of Compressor Oil	1A-71
Installation	1A-62	Oil Return Operation	1A-71
Main Data And Specifications	1A-62	Replacement of Component Parts	1A-71
Compressor	1A-65	Main Data and Specifications	1A-72
Service Precaution	1A-65	Special Tools	1A-74
General Description	1A-65		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Heating and Ventilation System

General Description

Heater


When the engine is warming up, the warmed engine coolant is sent out into the heater core. The heater system supplies warm air into the passenger compartment to warm it up.

Outside air is circulated through the heater core of the heater unit and then back into the passenger compartment. By controlling the mixture of outside air and heater core air, the most comfortable passenger compartment temperature can be selected and maintained.

The temperature of warm air sent to the passenger compartment is controlled by the temperature control knob. This knob acts to open and close the air mix door, thus controlling the amount of air passed through the heater core.

The air selector knob, with its different modes, also allows you to select and maintain the most comfortable passenger compartment temperature.

The air source select lever is used to select either "FRESH" for the introduction of the outside air, or "CIRC" for the circulation of the inside air. When the lever is set to "FRESH", the outside air is always taken into the passenger compartment. When setting the lever to "CIRC" position, the circulation of air is restricted only to the inside air with no introduction of the outside air and the air in the passenger compartment gets warm quickly. However, the lever is normally set to "FRESH" to prevent the windshield from clouding.



840RW002

Legend


- | | |
|------------------------------------|----------------------------|
| (1) Defroster Nozzle | (5) Duct (W/O A/C) |
| (2) Ventilation Duct | (6) Heater Unit |
| (3) Blower Assembly | (7) Ventilation Lower Duct |
| (4) Evaporator Assembly (With A/C) | (8) Lap Vent Duct |
| | (9) Rear Heater Duct |

1A-4 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Control Lever Assembly

The control lever assembly has some cables to control the mode and temperature of the heater unit and the mode door for the air source of the blower assembly.

The fan control is used to control the amount of air sent out by the resistor at four levels from "LOW" to "HIGH".



865RW006

Legend

- | | |
|------------------------------------|--|
| (1) Air Source Select Lever | (4) Air Conditioning (A/C) Switch (W/ A/C) |
| (2) Air Select Knob | (5) Temperature Control Knob |
| (3) Fan Control Lever (Fan Switch) | (6) Middle Position |

Ventilation

Setting the air source select lever to "FRESH" position allows the heating system to work with sending the fresh air from outside.

The blower fan also serves to deliver fresh outside air to the passenger compartment to assure adequate ventilation.

Air Select Knob

The air select knob allows you to direct heated air into the passenger compartment through different outlets.

1. **Vent** – In this position, air is discharged from the upper air outlet. Air quantity is controlled by the fan control lever.
2. **Bi-Level** – In this position, air flow is divided between the upper air outlets and the floor air outlets, with warmer air delivered to the floor outlets than the air delivered to the upper air outlets when the temp lever is in middle position.

3. **Foot** – In this position, air flow is delivered to the foot, while sending a small amount of air to the windshield.


4. **Def/Foot** – In this position, air flow is delivered to the foot, while sending approx. 40% of total amount of air to the windshield.

Selecting this mode allows air conditioning system to work while the fan switch is turned to on position, even if the A/C switch is off.

5. **Defrost** – In this position, most of the air is delivered to the windshield and a small amount is delivered to the side windows.

Selecting this mode allows air conditioning system to work while the fan switch is turned to on position, even if the A/C switch is off.

Moving the air source select lever to the "CIRC" position provides quickest heat delivery by closing the blower assembly mode door. In this position, outside air is not delivered to the passenger compartment.



C01RW001

Air Source Select Lever

The intake of outside air and the circulation of inside air are controlled by sliding this lever left or right.

Fan Control Lever

This lever controls the blower motor speed to regulate the amount of air delivered to the defrost, foot, and ventilation ducts:

1. Low
2. Medium Low
3. Medium High
4. High


Temperature Control Knob

When the temperature control knob is in the "COLD" position, the air mix door closes to block the flow air to the heater core.

When the temperature control knob is in the "HOT" position, the air mix door opens to allow air to pass through the heater core and heat the passenger compartment.

Placing the knob in a intermediate position will cause a lesser or greater amount air to reach the heater core. In this mode the passenger compartment temperature can be regulated.

Wiring Diagram



Diagnosis


Heating Cycle diagnosis

Condition	Possible cause	Correction
No heating or insufficient heating.	Blower motor does not run or runs improperly.	Refer to "FAN CONTROL LEVER (FAN SWITCH) DIAGNOSIS".
	Engine coolant temperature is low.	Check the engine coolant temperature after warming up the engine and check the thermostat. Replace as necessary.
	Insufficient engine coolant.	Add engine coolant as required.
	Circulation volume of engine coolant is insufficient.	Check if the water hose to the heater core is clogged, collapsed or twisted. Repair or replace as necessary.
	Heater core clogged or collapsed.	Clean or replace as necessary.
	The heater cores is not provided with air sent from the blower motor.	Repair the temperature control link unit or mode doors.
	Duct connections defective or unsealing.	Repair or replace as necessary.
Control lever moves but mode door does not operate.	Cable attaching clip is not correct.	Repair
	Link unit of heater or blower assembly defective.	Repair
The mode door cannot be set to the mode selected.	Link unit of heater unit or blower assembly defective.	Repair.
	Control cable is not adjusted.	Adjust.

Fan Control Lever (Fan Switch) Diagnosis

Current flows to the blower motor through the heater relay (X-6) to activate the rotation of the blower motor by turning "ON" the fan control knob (fan switch). Blower motor speed is controlled in stages by the resistor, by operating the switch from "LOW" to "HIGH".

For the inspection of the relays, switches and units in each table, refer to "INDIVIDUAL INSPECTION" in this section.



D08RW059

Condition	Possible cause	Correction
Blower motor does not run.	—	Refer to Chart A
Blower motor does not run in certain position (s).	—	Refer to Chart B, C, D and E
Blower motor does not stop at "OFF" position.	—	Refer to Chart F

Chart "A" Blower Motor Does Not Run

Step	Action	Yes	No
1	Is relay (X-6) OK?	Go to Step 2	Replace
2	Is fuse EB-4 (20A) OK?	Go to Step 3	Replace
3	Is resistor OK?	Go to Step 4	Replace
4	Is fan control lever OK?	Go to Step 5	Replace control lever assembly.
5	Is blower motor OK?	Go to Step 6	Replace
6	1. Turn the ignition switch "ON". 2. Turn fan control lever "ON". 3. Check to see if battery voltage is present at chassis side connector terminal No. B5-1 Is there a battery voltage?	Poor ground or open circuit either between chassis side connector terminal No. B5-2 and No. B3-2 or No. I23-1 and body ground (No. B-8).	Open circuit between No. EB-4 (20A) fuse and No. B5-1.

Chart "B" Blower Motor Does Not Run At Low Position

Step	Action	Yes	No
1	Is resistor OK?	Go to Step 2	Replace
2	Is fan control lever (Fan Switch) OK?	Open circuit between chassis side connector terminal No. B3-1 and No. I23-2.	Replace control lever assembly.

Chart "C" Blower Motor Does Not Run At Medium Low Position

Step	Action	Yes	No
1	Is resistor OK?	Go to Step 2	Replace
2	Is fan control lever (Fan Switch) OK?	Open circuit between the chassis side connector terminal No. B3-4 and No. I23-3.	Replace control lever assembly.

Chart "D" Blower Motor Does Not Run At Medium High Position

Step	Action	Yes	No
1	Is resistor OK?	Go to Step 2	Replace
2	Is fan control lever (Fan Switch) OK?	Open circuit between chassis side connector terminal No. B3-6 and No. I23-4.	Replace control lever assembly.

1A-10 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Chart “E” Blower Motor Does Not Run At High Position

Step	Action	Yes	No
1	Is resistor OK?	Go to Step 2	Replace
2	Is fan control lever (Fan Switch) OK?	Open circuit between Chassis side connector terminal No. B3-3 and No. I23-5.	Replace control lever assembly.


Chart “F” Blower Motor Does Not Stop In The “OFF” Position

Step	Action	Yes	No
1	Is the fan control lever (Fan Switch) OK?	Short circuit between chassis side connector terminal No. B5-2 and No. B3-2, No. B3-3 and No. I23-5, No. B3-6 and No. I23-4, No. B3-4 and No. I23-3 or No. B3-1 and No. I23-2	Replace control lever assembly.

Individual Inspection

Blower Motor


1. Disconnect the blower motor (B-5) connector from the blower motor.
2. Connect the battery positive terminal to the No. 1 terminal of the blower motor and the negative to the No. 2.
3. Be sure to check to see if the blower motor operates correctly.



873RW002

Resistor


1. Disconnect the resistor (B-3) connector.
2. Check for continuity and resistance between the terminals of the resistor.



840RS001

Fan Control Lever (Fan Switch)


1. Check for continuity between the terminals of the fan switch.



D08RW008

Heater Relay


1. Disconnect the heater relay (X-6).
 - When removing the connector for relay, unfasten the tank lock of the connector by using a screwdriver, then pull the relay (1) out.



825RS001


1A-12 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

2. Check for continuity between the heater relay (X-6) terminals.



Heater Unit

Heater Unit and Associated Parts



840RW003

Legend

- | | |
|-------------------------------|------------------------------------|
| (1) Instrument Panel Assembly | (6) Driver Lap Vent Duct |
| (2) Cross Beam Assembly | (7) Evaporator Assembly (A/C only) |
| (3) Instrument Panel Bracket | (8) Duct |
| (4) Ventilation Lower Duct | (9) Heater Unit Assembly |
| (5) Rear Heater Duct | (10) Heater Hose |
| | (11) Resistor Connector |

Removal

1. Disconnect the battery ground cable.
2. Drain the engine coolant.
3. Discharge and recover refrigerant (with air conditioning).
 - Refer to Refrigerant Recovery in this section.
4. Remove the Instrument panel assembly.
 - Refer to Instrument Panel Assembly in Body and Accessories section.
5. Remove instrument panel bracket.
 - Refer to Cross Beam Assembly in Body and Accessories section.
6. Cross Beam Assembly.
 - Refer to Cross Beam Assembly in Body and Accessories section.
7. Disconnect resistor connector.
8. Remove duct.
9. Remove evaporator assembly (A/C only).
 - Refer to Evaporator Assembly in this section.
10. Remove driver lap vent duct.
11. Remove ventilation lower duct.
12. Remove rear heater duct.
 - Remove foot rest, carpet and 3 clips.
13. Remove heater unit assembly.
 - Disconnect heater hoses at heater unit.

1A-14 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. When handling the PCM and the control unit, be careful not to make any improper connection of the connectors.


2. Adjust the control cables.

○Refer to Control Lever Assembly in this section.

3. When installing the heater unit, defroster nozzle and center vent duct, be sure that the proper seal is made, without any gap between them.

Heater Core and / or Mode Door

Disassembled View



860RW001

Legend

- (1) Heater Core
- (2) Case (Temperature Control)
- (3) Heater Unit

- (4) Mode Door
- (5) Duct
- (6) Case (Mode Control)

Removal

1. Disconnect the battery ground cable.
2. Drain the engine coolant.

3. Discharge and recover refrigerant (with air conditioning).

○Refer to Refrigerant Recovery in this section.


4. Remove heater unit.

○Refer to Heater Unit in this section.

5. Remove duct.


6. Remove case (Mode control) and do not remove link unit at this step.

7. Remove case (Temperature control) separate two halves of core case.




860RS002

8. Remove heater core (1).



860RS003

9. Pull out the mode door while raising up the catch of the door lever.



860RS004

Inspection

Check for foreign matter in the heater core, stain or the core fin defacement.


Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. Check that each mode door operates properly.

Heater Mode Control Link Unit

Disassembled View




860RW002

Legend

- | | |
|-------------------------|--------------------------------|
| (1) Case (Mode Control) | (4) Clip |
| (2) Heater Unit | (5) Door Lever |
| (3) Mode Sub-lever | (6) Rod |
| | (7) Washer and Mode Main Lever |

Removal

1. Disconnect the battery ground cable.
2. Drain engine coolant.
3. Discharge and recover refrigerant (with air conditioning)
○Refer to Refrigerant Recovery in this section.
4. Remove heater unit.
○Refer to Heater Unit in this section.
5. Remove the case (Mode control) from heater unit.
6. Remove washer and the mode main lever.
7. Remove rod.
8. Press the tab of the sub-lever inward, and take out the sub-lever.



860RS006

9. Pull out the door lever while raising up the catch of the door lever.
10. Remove clip.


Installation

To install, follow the remove steps in the reverse order, noting the following points:

1. Apply grease to the mode sub-lever and to the abrasive surface of the heater unit.
2. After installing the link unit, check to see if the link unit operates correctly.

Heater Temperature Control Link Unit

Disassembled View



860RS007

Legend

- | | |
|--------------------------------|-----------------|
| (1) Case (Temperature control) | (4) Clip |
| (2) Clip | (5) Heater Unit |
| (3) Door Lever | (6) Rod |
| | (7) Sub-lever |

Removal

1. Disconnect the battery ground cable.
2. Drain engine coolant.
3. Discharge and recover refrigerant (with air conditioning).
 - Refer to Refrigerant Recovery in this section.
4. Remove heater unit.
 - Refer to Heater Unit in this section.
5. Remove the case (Temperature control) from the heater unit.
6. Remove rod.
7. Remove sub-lever.
8. Pull out the door lever while raising up the catch of the door lever.
9. Remove clip.


Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Apply grease to the sub-lever and to the abrasive surface of the heater unit.
2. After installing the link unit, check to see if the link unit operates correctly.

Blower Assembly

Blower Assembly and Associated Parts



Legend

- (1) Instrument Panel Assembly
- (2) Blower Assembly

- (3) Evaporator Assembly (A/C only)
- (4) Duct
- (5) Heater Unit

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant (with air conditioning).
 - Refer to Refrigerant Recovery in this section.

3. Remove instrument panel assembly.
 - Refer to Instrument Panel Assembly in Body and Accessories section.
4. Disconnect resistor connector.
5. Remove duct.

6. Remove evaporator assembly (A/C only).
○Refer to Evaporator Assembly in this section.
7. Disconnect blower motor connector.
8. Remove blower assembly.


Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. Adjust the control cables.
○Refer to Control Lever Assembly in this section.

Blower Link Unit and / or Mode door

Disassembled View



873RS001

Legend

- (1) Upper Case
- (2) Mode Door
- (3) Lower Case

- (4) Sub Lever
- (5) Door Lever
- (6) Blower Assembly


Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant (with air conditioning).
○Refer to Refrigerant Recovery in this section.

3. Remove blower assembly.
○Refer to Blower Assembly in this section.
4. Remove lower case.

1A-20 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

5. Separate the upper case and slit the lining parting face with a knife.



6. Pull out the mode door while raising up the catch of door lever.
7. Remove sub-lever.
8. Remove door lever.


Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Apply grease to the door lever and to the abrasive surface of the upper case.
2. Apply an adhesive to the parting face of the lining when assembling the upper case.

Blower Motor

Blower Motor and Associated Parts



873RW001

Legend

- | | |
|----------------------------|------------------|
| (1) Attaching Screw | (4) Clip |
| (2) Blower Motor Connector | (5) Fan |
| (3) Blower Motor Assembly | (6) Blower Motor |

Removal


1. Disconnect the battery ground cable.
2. Remove blower motor connector.
3. Remove attaching screw.
4. Remove blower motor assembly.
5. Remove clip.
6. Remove fan.
7. Remove blower motor.

Installation

To install, follow the removal steps in the reverse order.

Rear Heater Duct, Defroster Nozzle and Ventilation Duct

Rear Heater Duct, Defroster Nozzle, Ventilation Duct and Associated Parts



840RW008

Legend

- | | |
|---|-------------------------------|
| (1) Defroster Nozzle | (4) Instrument Panel Bracket |
| (2) Cross Beam Assembly | (5) Instrument Panel Assembly |
| (3) Center Ventilation Duct and Side Defroster Duct | (6) Rear Heater Duct |
| | (7) Lap Ventilation Duct |
| | (8) Ventilation Lower Duct |

Removal

1. Disconnect the battery ground cable.
2. Remove instrument panel assembly.
 - Refer to Instrument Panel Assembly in Body and Accessories section.
3. Remove center ventilation duct and side defroster duct.
 - Remove 5 screws.
4. Remove lap ventilation duct.
5. Remove instrument panel brackets.
 - Refer to Cross Beam Assembly in Body and Accessories section.
6. Remove cross beam assembly.
 - Refer to Cross Beam Assembly in Body and Accessories section.
7. Remove ventilation lower duct.
8. Remove rear heater duct.
 - Remove foot rest carpet and 3 clips.
9. Remove defroster nozzle.


Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. Connect each duct and nozzle securely leaving no clearance between them and making no improper matching.

Control Lever Assembly and / or Control Cable

Control Lever Assembly, Control Cable and Associated Parts




865RW004

Legend

- | | |
|----------------------------|--|
| (1) Control Cable | (4) Glove Box |
| (2) Control Lever Assembly | (5) Instrument Panel Driver Lower Cover Assembly |
| (3) Meter Cluster Assembly | (6) Fan Switch Air Conditioning Switch Connector |


Removal

1. Disconnect the battery ground cable.
2. Remove instrument panel driver lower cover assembly.
3. Remove meter cluster assembly.
○Refer to Instrument Panel Assembly in Body and Accessories section.
4. Remove glove box.
5. Remove the control lever attaching screws.
6. Pull the control lever assembly out and disconnect the fan switch and air conditioning switch connectors.



865RW001

7. Remove control level assembly.
8. Disconnect control cables at each unit side.




865RW002

Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Adjust the control cable.



865RW005

○Air source control cable.

1. Slide the control lever to the left ("CIRC" position).
2. Connect the control cable at the "CIRC" position of the link unit of the blower assembly and secure it with the clip.

○Temperature control cable.

1. Turn the control knob to the left ("MAX COLD" position).
2. Connect the control cable at the "COLD" position of the temperature control link of the heater unit and secure it with the clip.


○Air select control cable

1. Turn the control knob to the right ("DEFROST" position).
2. Connect the control cable at the "DEFROST" position of the mode control link of the heater unit and secure it with the clip.

2. Check the control cable operation.

Control Panel Illumination Bulb

Control Panel Illumination Bulb and Associated Parts



865RW003

Legend

- (1) Control Lever Assembly
- (2) Bulb Socket
- (3) Illumination Bulb

Removal


1. Disconnect the battery ground cable.
2. Remove control lever assembly.
○Refer to Control Lever Assembly in this section.
3. Pull out the bulb socket from the panel by turning it counterclockwise.
4. Pull the illumination bulb from the socket.

Installation

To install, follow the removal steps in the reverse order.

Resistor

Resistor and Associated Parts



840RW001

Legend

- (1) Duct (Heater only)
- (2) Resistor
- (3) Resistor Connector
- (4) Glove Box

Removal

1. Disconnect the battery ground cable.
2. Remove glove box.
3. Remove resistor connector.
4. Remove duct (heater only).
5. Remove resistor.


Installation

To install, follow the removal steps in the reverse order.

Air Conditioning System

General Description

Air Conditioning Refrigerant Cycle Construction



C01RS003

Legend

- | | |
|--|--|
| (1) Electronic Thermostat | (9) Condenser |
| (2) Evaporator Core | (10) Compressor |
| (3) Evaporator Assembly | (11) Magnetic Clutch |
| (4) Temperature Sensor | (12) Mode (HEAT) Control Door |
| (5) Expansion Valve | (13) Temp. Control Door (Air Mix Door) |
| (6) Blower Motor | (14) Heater Core |
| (7) Pressure Switch or Pressure Sensor | (15) Mode (VENT) Control Door |
| (8) Receiver/Drier | (16) Heater Unit |
| | (17) Mode (DEF) Control Door |

The refrigeration cycle includes the following four processes as the refrigerant changes repeatedly from liquid to gas and back to liquid while circulating.

Evaporation

The refrigerant is changed from a liquid to a gas inside the evaporator. The refrigerant mist that enters the

1A-28 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

evaporator vaporizes readily. The liquid refrigerant removes the required quantity of heat (latent heat of vaporization) from the air around the evaporator core cooling fins and rapidly vaporizes. Removing the heat cools the air, which is then radiated from the fins and lowers the temperature of the air inside the vehicle.

The refrigerant liquid sent from the expansion valve and the vaporized refrigerant gas are both present inside the evaporator as the liquid is converted to gas.

With this change from liquid to gas, the pressure inside the evaporator must be kept low enough for vaporization to occur at a lower temperature. Because of that, the vaporized refrigerant is sucked into the compressor.

Compression

The refrigerant is compressed by the compressor until it is easily liquefied at normal temperature.

The vaporized refrigerant in the evaporator is sucked into the compressor. This action maintains the refrigerant inside the evaporator at a low pressure so that it can easily vaporize, even at low temperatures close to 0°C (32°F).

Also, the refrigerant sucked into the compressor is compressed inside the cylinder to increase the pressure and temperature to values such that the refrigerant can easily liquefy at normal ambient temperatures.

Condensation

The refrigerant inside the condenser is cooled by the outside air and changes from gas to liquid.

The high temperature, high pressure gas coming from the compressor is cooled and liquefied by the condenser with outside air and accumulated in the receiver/drier. The heat radiated to the outside air by the high temperature, high pressure gas in the compressor is called heat of condensation. This is the total quantity of heat (heat of vaporization) the refrigerant removes from the vehicle interior via the evaporator and the work (calculated as the quantity of heat) performed for compression.

Expansion

The expansion valve lowers the pressure of the refrigerant liquid so that it can easily vaporize.

The process of lowering the pressure to encourage vaporization before the liquefied refrigerant is sent to the evaporator is called expansion. In addition, the expansion valve controls the flow rate of the refrigerant liquid while decreasing the pressure.

That is, the quantity of refrigerant liquid vaporized inside the evaporator is determined by the quantity of heat which must be removed at a prescribed vaporization temperature. It is important that the quantity of refrigerant be controlled to exactly the right value.

Compressor

The compressor performs two main functions: It compresses low-pressure and low-temperature refrigerant vapor from the evaporator into high-pressure and high-temperature refrigerant vapor to the condenser. It pumps refrigerant and refrigerant oil through the air conditioning system.

This vehicle is equipped with a five-vane rotary compressor (1).

The specified amount of the compressor oil is 150cc (5.0 fl. oz.).

The oil used in the HFC-134a system compressor differs from that used in R-12 systems.


Also, compressor oil to be used varies according to the compressor model. Be sure to avoid mixing two or more different types of oil.

If the wrong oil is used, lubrication will be poor and the compressor will seize or malfunction.

The magnetic clutch connector is a waterproof type.

Magnetic Clutch

The compressor is driven by the drive belt from the crank pulley of the engine. If the compressor is activated each time the engine is started, this causes too much load to the engine. The magnetic clutch (3) transmits the power from the engine to the compressor and activates it when the air conditioning is ON. Also, it cuts off the power from the engine to the compressor when the air conditioning is OFF. Refer to Compressor in this section for magnetic clutch repair procedure.



871RX001

Condenser

The condenser assembly (6) is located in front of the radiator. It provides rapid heat transfer from the refrigerant to the cooling fins.


Also, it functions to cool and liquefy the high-pressure and high-temperature vapor sent from the compressor by the radiator fan or outside air.

A condenser may malfunction in two ways: it may leak, or it may be restricted. A condenser restriction will result in excessive compressor discharge pressure. If a partial restriction is present, the refrigerant expands after passing through the restriction.

Thus, ice or frost may form immediately after the restriction. If air flow through the condenser or radiator is blocked, high discharge pressures will result. During normal condenser operation, the refrigerant outlet line will be slightly cooler than the inlet line.

The vehicle is equipped with the parallel flow type condenser. A larger thermal transmission area on the inner surface of the tube allows the radiant heat to increase and the ventilation resistance to decrease.

The refrigerant line connection has a bolt at the block joint, for easy servicing.



852RW007

Receiver / Drier


The receiver/drier (5) performs four functions:

- As the quantity of refrigerant circulated varies depending on the refrigeration cycle conditions, sufficient refrigerant is stored for the refrigeration cycle to operate smoothly in accordance with fluctuations in the quantity circulated.
- The liquefied refrigerant from the condenser is mixed with refrigerant gas containing air bubbles. If refrigerant containing air bubbles is sent to the expansion valve, the cooling capacity will decrease considerably. Therefore, the liquid and air bubbles are separated and only the liquid is sent to the expansion valve.
- The receiver/drier utilizes a filter and drier to remove the dirt and water mixed in the cycling refrigerant.
- The sight glass, installed atop the receiver/drier, show the state of the refrigerant.

A receiver/drier may fail due to a restriction inside the body of the unit. A restriction at the inlet to the receiver/drier will cause high pressure.

Outlet restrictions will be indicated by low pressure and little or no cooling. An excessively cold receiver/drier outlet may indicate a restriction.

The receiver/drier of this vehicle is made of aluminum with a smaller tank. It has a 300cc refrigerant capacity. The refrigerant line connection has a bolt at the block joint, for easy servicing.



852RW007

Dual Pressure Switch (V6,M/T)

The pressure switch (Dual pressure switch) (2) is installed on the upper part of the receiver/drier, to detect excessively high pressure (high pressure switch) and prevent compressor seizure due to the refrigerant leaking (low pressure switch), so that the compressor is able to be turned "ON" or "OFF".

Compressor	ON (kPa/psi)	OFF (kPa/psi)
Low-pressure control	205.9±29.4 (29.9±4.3)	176.5±19.6 (25.6±2.8)
High-pressure control	2059.4±196.1 (341.3±28.4)	2942.0±196.1 (426.6±28.4)

Triple Pressure Switch (V6, A/T)


Triple pressure switch (2) is installed on the upper part of the receiver/drier. This switch is constructed with a unitized type of two switches. One of them is a low and high pressure switch (Dual pressure switch) to switch "ON" or "OFF" the magnetic clutch as a result of irregularly high-pressure or low pressure of the refrigerant. The other one is a medium pressure switch (Cycling switch) to switch "ON" or "OFF" the condenser fan sensing the condenser high side pressure.

Compressor	ON (kPa/psi)	OFF (kPa/psi)
Low-pressure control	186.3±29.4 (27.0±4.3)	176.5±24.5 (25.6±3.6)
High-pressure control	2353.6±196.1 (341.3±28.4)	2942.0±196.1 (426.6±28.4)

Condenser fan	ON (kPa/psi)	OFF (kPa/psi)
Medium-pressure control	1471.0±98.1 (213.3±14.2)	1078.7±117.7 (156.4±17.1)

Pressure Sensor

The pressure sensor (2) is installed on the upper part of the receiver/drier. This sensor converts high pressure detection of refrigerant to an electrical voltage signal and supplies it to the ECM. The ECM controls switching compressor idle speed and cooling fan operation by the electrical voltage signal.



Expansion Valve

This expansion valve (3) is an external pressure type and it is installed at the evaporator intake port. The expansion valve converts the high pressure liquid refrigerant sent from the receiver/drier to a low pressure

liquid refrigerant by forcing it through a tiny port before sending it to the evaporator (4).

This type of expansion valve consists of a temperature sensor, diaphragm, ball valve, ball seat, spring adjustment screw, etc.


The temperature sensor contacts the evaporator outlet pipe, and converts changes in temperature to pressure. It then transmits these to the top chamber of the diaphragm.

The refrigerant pressure is transmitted to the diaphragm's bottom chamber through the external equalizing pressure tube.

The ball valve is connected to the diaphragm. The opening angle of the expansion valve is determined by the force acting on the diaphragm and the spring pressure.

The expansion valve regulates the flow rate of the refrigerant. Accordingly, when a malfunction occurs to this expansion valve, both discharge and suction pressure get low, resulting in insufficient cooling capacity of the evaporator.


The calibration has been changed to match the characteristics of HFC-134a.



Evaporator

The evaporator cools and dehumidifies the air before the air enters the passenger compartment. High-pressure liquid refrigerant flows through the expansion valve (2) into the low-pressure area of the evaporator. The heat in the air passing through the evaporator core (1) is lost to the cooler surface of the core, thereby cooling the air. As heat is lost between the air and the evaporator core surface, moisture in the vehicle condenses on the outside surface of the evaporator core and is drained off as water. When the evaporator malfunctions, the trouble will show up as an inadequate supply of cool air. The cause is typically a partially plugged core due to dirt, or a malfunctioning blower motor.

The evaporator core with a laminate louver fin is a single-sided tank type where only one tank is provided under the core.




Electronic Thermostat

The thermostat consists of the thermo sensor (3) and thermostat unit (5) which functions electrically to reduce the noises being generated while the system is in operation.

The electronic thermo sensor (3) is mounted at the evaporator core (2) outlet and senses the surface temperature of the evaporator core (4). Temperature signals are input to the thermostat unit. This information is compared by the thermo unit and results in the output to operate the A/C thermostat relay and turn the magnetic clutch ON or OFF to prevent evaporator freeze-up.

A characteristic of the sensor is that the resistance decreases as the temperature increases and the resistance increases as the temperature decreases.




Refrigerant Line

Restriction in the refrigerant line will be indicated by:

1. Suction line — A restricted suction line will cause low suction pressure at the compressor, low discharge pressure and little or no cooling.
2. Discharge line — A restriction in the discharge line generally will cause the discharge line to leak.
3. Liquid line — A liquid line restriction will be evidenced by low discharge and suction pressure and insufficient cooling.

Refrigerant flexible hoses that have a low permeability to refrigerant and moisture are used. These low permeability hoses have a special nylon layer on the inside.




852RS001

Legend

- (1) Reinforcement Layer (Polyester)
 - (2) External Rubber Layer
 - (3) Internal Rubber Layer
 - (4) Resin Layer (Nylon)
-

Air Conditioning Parts



852RX002

Legend

- | | |
|---|--------------------------------------|
| (1) Liquid Line (High-Pressure Pipe) | (5) Receiver/Drier |
| (2) Clip | (6) Condenser Assembly |
| (3) Discharge Line (High-Pressure Hose) | (7) Compressor |
| (4) Pressure Switch | (8) Suction Line (Low-Pressure Hose) |
| | (9) Evaporator Assembly |

Wiring Diagram



Diagnosis

Air Conditioning Cycle Diagnosis

Condition	Possible cause	Correction
No cooling or insufficient cooling.	Magnetic clutch does not run.	Refer to "Magnetic Clutch Diagnosis" in this section.
	Compressor is not rotating properly. Drive belt is loosened or broken.	Adjust the drive belt to the specified tension or replace the drive belt.
	Compressor is not rotating properly. Magnetic clutch face is not clean and slips.	Clean the magnetic clutch face or replace.
	Compressor is not rotating properly. Incorrect clearance between magnetic drive plate and pulley.	Adjust the clearance. Refer to Compressor in this section.
	Compressor is not rotating properly. Compressor oil leaks from the shaft seal or shell.	Replace the compressor
	Compressor is not rotating properly. Compressor is seized.	Replace the compressor
	Insufficient or excessive charge of refrigerant.	Discharge and recover the refrigerant. Recharge to the specified amount.
	Leaks in the refrigerant system.	Check the refrigerant system for leaks and repair as necessary. Discharge and recover the refrigerant. Recharge to the specified amount.
	Condenser is clogged or insufficient radiation.	Clean the condenser or replace as necessary.
	Temperature control link unit of the heat unit is defective.	Repair the link unit.
	Unsteady operation due to a foreign substance in the expansion valve.	Replace the expansion valve.
	Poor operation of the electronic thermostat.	Check the electronic thermostat and replace as necessary.
Insufficient velocity of cooling air.	Evaporator clogged or frosted.	Check the evaporator core and replace or clean the core.
	Air leaking from the cooling unit or air duct.	Check the evaporator and duct connection, then repair as necessary.
	Blower motor does not rotate properly.	Refer to Fan Control Lever (Fan Switch) Diagnosis in this section.

*For the execution of the charging and discharging operation in the table above, refer to Recovery, Recycling, Evacuating and Charging in this section.

1A-36 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Checking The Refrigerant System With Manifold Gauge

Since Refrigerant-134a (HFC-134a) is used in the air conditioning system in this vehicle, be sure to use manifold gauges, charging hoses and other air conditioning service tools for HFC-134a when checking the refrigerant system.

Conditions:

- Run the engine at Idling
- Air conditioning switch is "ON"
- Run the blower motor at "HIGH" position
- Temperature control lever set to "MAX COLD"
- Air source selector lever at "CIRC"
- Open the engine hood
- Close all the doors

Normal Pressure:

- At ambient temperature: approx. 25–30°C (77–86°F).
- At low-pressure side: approx. 147.1–294.2 kPa (21.3–42.7 psi).
- At high-pressure side: approx. 1372.9–1863.3 kPa (199.1–270.2 psi).


Refer to the table on the refrigerant pressure-temperature relationship.

HFC-134a Pressure-Temperature Relationship			
Pressure		Temperature	
(kPa)	(psi)	(°C)	(°F)
36	5.3	–20	–4.4
67	9.7	–15	5
104	15	–10	14
147	21	–5	23
196	28	0	32
255	37	5	41
314	45	10	50
392	57	15	59
471	68	20	68
569	82	25	77
677	98	30	86
785	114	35	95
912	132	40	104
1059	154	45	113
1216	176	50	122

Connect The Manifold Gauge

Low-pressure hose (LOW) — Suction side

High pressure hose (HI) — Discharge side



Legend

- (1) Low Side
(2) High Side


Condition	Possible cause	Correction
Discharge (High Gauge) Pressure Abnormally High	Condenser clogged or dirty.	Clean the condenser fins
	Cooling fan does not operate properly.	Check the cooling fan operation.
Discharge (High Gauge) Pressure Abnormally High. Insufficient cooling.	Excessive refrigerant in system.	Discharge and recover refrigerant. Recharge to specified amount.
Discharge (High Gauge) Pressure Abnormally High. High pressure gauge drop. (After stopping A/C, the pressure drops approx. 196 kPa (28 psi) quickly)	Air in system.	Evacuate and charge refrigerant system.
Discharge (High Gauge) Pressure Abnormally Low. Insufficient cooling	Insufficient refrigerant in system.	Check for leaks. Discharge and recover the refrigerant. Recharge to the specified amount.
Discharge (High Gauge) Pressure Abnormally Low. Low pressure gauge indicates vacuum.	Clogged or defective expansion valve.	Replace the expansion valve.
Discharge (High Gauge) Pressure Abnormally Low. Frost or dew on refrigerant line before and after the receiver/drier or expansion valve, and low pressure gauge indicates vacuum.	Restriction caused by debris or moisture in the receiver/drier.	Check system for restriction and replace the receiver/drier.
Discharge (High Gauge) Pressure Abnormally Low. High and low pressure gauge balanced quickly. (After turned off A/C)	Compressor seal defective	Repair or replace the compressor.
	Poor compression due to a defective compressor gasket.	Repair or replace the compressor.
Suction (Low Gauge) Pressure Abnormally High. Low pressure gauge (Low pressure gauge is lowered after condenser is cooled by water.)	Excessive refrigerant in system.	Discharge and recover refrigerant Recharge to specified amount.
Suction (Low Gauge) Pressure Abnormally High. Low pressure hose temperature. (Low pressure hose temperature around the compressor refrigerant line connector is lower than around evaporator.)	Unsatisfactory valve operation due to defective temperature sensor of expansion valve.	Replace the expansion valve.
	Expansion valve opens too long.	Replace the expansion valve.
Suction (Low Gauge) Pressure Abnormally High. High and low pressure gauge balanced quickly. (After turned off A/C)	Compressor gasket is defective.	Repair or replace the compressor.
Suction (Low Gauge) Pressure Abnormally Low. Insufficient cooling.	Insufficient refrigerant in system.	Check for leaks. Discharge and recover the refrigerant. Recharge to specified amount.

1A-38 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Condition	Possible cause	Correction
Suction (Low Gauge) Pressure Abnormally Low. Frost on the expansion valve inlet line	Expansion valve clogged.	Replace the expansion valve.
Suction (Low Gauge) Pressure Abnormally Low Receiver/drier inlet and outlet refrigerant line temperature. (A distinct difference in temperature develops.)	Receiver/Drier clogged.	Replace the receiver/drier.
Suction (Low Gauge) Pressure Abnormally Low. Expansion valve outlet refrigerant line. (Not cold and low pressure gauge indicates vacuum.)	Expansion valve temperature sensor is defective.	Replace the expansion valve.
Suction (Low Gauge) Pressure Abnormally Low. When the refrigerant line is clogged or blocked, the low pressure gauge reading will decrease, or a vacuum reading may be shown.	Clogged or blocked refrigerant line.	Replace refrigerant line.
Suction (Low Gauge) Pressure Abnormally Low. Evaporator core is frozen.	Thermo switch defective.	Replace thermo switch.
Suction (Low Gauge) and Discharge (High Gauge) Pressure Abnormally High. Insufficient cooling.	Excessive refrigerant in system.	Discharge and recover the refrigerant, the Recharge to the specified amount.
	Condenser clogged or dirty.	Clean the condenser fin.
Suction (Low Gauge) and Discharge (High Gauge) Pressure Abnormally High. Suction (Low) pressure hose (Not cold).	Air in system.	Evacuate and charge refrigerant.
Suction (Low Gauge) and Discharge (High Gauge) Pressure Abnormally Low. Insufficient cooling	Insufficient refrigerant in system.	Check for leaks. Discharge and recover refrigerant. Recharge to specified amount.

A/C — Air Conditioning

Magnetic Clutch Diagnosis



1A-40 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

When the air conditioning switch and the fan control knob (fan switch) are turned on with the engine running, current flows through the thermostat and the compressor relay to activate the magnetic clutch.

The air conditioning can be stopped by turning of the air conditioning switch or the fan control knob (fan switch). However, even when the air conditioning is in operation, the electronic thermostat, the pressure switch or the

Powertrain Control Module (PCM;V6-3.2L)/ Engine Control Module (ECM;L4-2.2L) is used to stop the air conditioning temporarily by turning off the magnetic clutch in the prearranged conditions to reduce the engine load which is being caused by the rise in the engine coolant temperature, and the acceleration of the vehicle, etc. For the inspection of the relays, switches and units in the table, refer to "Individual Inspection" in this section.

Magnetic Clutch Does Not Run

Step	Action	Yes	No
1	Are No. EB-5 (10A) fuse and No. EB-4 (20A) fuse OK?	Go to Step 2	Replace
2	Are heater (X-6), thermostat (X-5), and compressor (X-4) relays OK?	Go to Step 3	Replace
3	Is pressure switch OK?	Go to Step 4	Switch defective or insufficient refrigerant.
4	Are air conditioning switch and fan control lever (Fan Switch) OK?	Go to Step 5	Replace
5	1. Turn the ignition switch "ON" (Engine is running). 2. Air conditioning switch and fan control lever (Fan Switch) "ON". 3. Check to see if battery voltage is present at chassis side connector terminal No. E3-1. Is there a battery voltage?	Go to Step 6	Go to Step 7
6	Check to see if continuity between compressor side connector terminal No. E3-1 and the magnetic clutch side connector terminal. Is there a continuity?	Magnetic clutch defective.	Compressor defective.
7	Check to see if battery voltage is present at chassis side connector terminal No. I24-2. Is there a battery voltage?	Go to Step 8	Open circuit between No. EB-5 (10A) fuse and No. I24-2.
8	Check to see if battery voltage is present at chassis side connector terminal No. C11-1 Is there a battery voltage?	Go to Step 9	Open circuit between No. I24-1 and No. C11-1.
9	1. Disconnect thermostat relay (X-5). 2. Check to see if battery voltage is present at the chassis side relay terminal NO. X5-5 Is there a battery voltage?	Go to Step 10	Open circuit between No. EB-5 and C11-2 (10A) fuse and No. X5-5.
10	Check to see if voltage (approx. 10V) is present between chassis side relay terminal No. X5-2 and No. X5-4. Is there a battery voltage?	Go to Step 11	Go to Step 17
11	1. Reconnect thermostat relay and disconnect compressor relay (X-4). 2. Check to see if battery voltage is present at the chassis side relay terminal No. X4-5. Is there a battery voltage?	Go to Step 12	Open circuit between No. EB-5 (10A) fuse and No. X4-5.
12	Check to see if continuity between chassis side relay terminal No. X4-1 and the chassis side connector terminal No. E3-1. Is there a continuity?	Go to Step 13	Open circuit.

Magnetic Clutch Does Not Run (Cont'd)


Step	Action	Yes	No
13	Check to see if battery voltage is present between chassis side relay terminal No. X4-2 and No. X4-4. Is there a battery voltage?	Go to Step 14	Go to Step 15
14	Check to see if battery voltage is present at chassis side relay terminal No. X4-2. Is there a battery voltage?	Go to Step 16	Open circuit between No. EB-5 (10A) fuse and No. X4-2.
15	Check to see if battery voltage is present at chassis side connector terminal No. C1-B14. Is there a battery voltage?	Power train control module (PCM) defective. Refer to Driveability and Emissions in Engine section.	Open circuit between No. X4-4 and No. C1-B14.
16	Check to see if continuity between chassis side relay terminal No. X5-1 and chassis side connector terminal No. C3-E15. Is there a continuity?	Power train control module (PCM) defective. Refer to Driveability and Emissions in Engine section.	Open circuit
17	Check to see if battery voltage is present at chassis side relay terminal No. X5-2. Is there a battery voltage?	Go to Step 18	Open circuit between No. X5-2 and C11-2.
18	1. Reconnect thermostat relay. 2. Check to see if battery voltage is present at chassis side connector terminal No. B4-3. Is there a battery voltage?	Go to Step 19	Open circuit between No. I24-1 and No. B4-3.
19	Check to see if battery voltage (approx 10V) is present at chassis side connector terminal No. B4-1. Is there a battery voltage?	Go to Step 20	Open circuit between No. X5-4 and No. B4-1.
20	Check to see if continuity between chassis side connector terminal No. B4-2 and No. I23-6. Is there a continuity?	Electronic thermostat defective.	Open circuit between No. B4-2 and No. I23-6 or poor ground (Fan Switch Ground Circuit).

1A-42 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Condenser Fan Diagnosis

While the air conditioning is ON, the cycling switch in the triple pressure switch senses the refrigerant pressure, and activates the condenser fan to improve the cooling capacity of the condenser when the refrigerant pressure

exceeds a set pressure value. The condenser fan stops when the air conditioning is turned "OFF" or when the pressure goes down below the set pressure value.



D08RW062

Condition	Possible cause	Correction
Condenser fan does not run.	—	Refer to "Chart A".
	—	Refer to "Chart B".

Chart "A" Condenser Fan Does Not Run

Step	Action	Yes	No
1	Are 30A fuse OK?	Go to Step 2	Replace
2	Is relay (X-9) OK?	Go to Step 3	Replace
3	Is pressure switch OK?	Go to Step 4	Switch defective or insufficient refrigerant.
4	Is air conditioning switch OK?	Go to Step 5	Replace
5	Is fan motor OK?	Go to Step 6	Replace
6	1. Disconnect condenser fan relay (X-9). 2. Check to see if battery voltage is present at the chassis side relay terminal NO. X9-5 Is there a battery voltage?	Go to Step 7	Open circuit between EB-17 fuse (30A) and No.X9-5.
7	1. Reconnect condenser fan relay (X-9). 2. Air conditioning switch "ON". 3. Check to see if battery voltage is present at chassis side connector terminal No.C11-3. Is there a battery voltage?	Go to Step 8	Open circuit between I-24-1 and C11-3.
8	1. Air conditioning switch "OFF". 2. Check to see if continuity between chassis side relay terminal No.X9-2 and the chassis side connector terminal No.C11-4. Is there a continuity?	Go to Step 9	Open circuit.
9	Check to see if continuity between chassis side connector terminal No. C24-1 and chassis side relay terminal No.X9-1. Is there a continuity?	Poor ground or open circuit between chassis side connector terminal No.X9-4 (or No.C24-2) and body ground (No.C36).	Open circuit.


Chart "B" Condenser Fan Does Not Stop

Step	Action	Yes	No
1	1. Air conditioning switch "OFF". Does condenser fan stop?	Triple pressure switch defective.	Condenser fan relay (X9) defective.

Individual Inspection


Fan Control Knob (Fan Switch) And Air Conditioning (A/C) Switch

1. Check for continuity between the fan switch and the A/C switch side connector terminals.




Heater (X-6), Thermostat (X-5), Condenser Fan (X-9) And Compressor (X-4) Relay

1. Disconnect relays and check for continuity and resistance between relay terminals.
- For handling of these relays, refer to Heater Relay in this section.




Pressure Switch

1. Disconnect pressure switch connector and check for continuity between pressure switch side connector terminals (1) and (2).




Triple Pressure Switch (V6, A/T)

1. Disconnect the connector and check for continuity between pressure switch side connector terminals (1) and (2).
2. Reconnect the connector to activate the A/C switch, and check to see if there is continuity between the chassis side connector terminals (3) and (4) and the fan operates.



Condenser Fan

1. Disconnect the condenser fan connector.
2. Connect the battery positive terminal to the condenser fan side connector terminal No.C-24-1 and negative to the No.C-24-2.
3. Check that condenser fan is rotating correctly.



General Repair Procedure

Precautions For Replacement or Repair of Air Conditioning Parts

There are certain procedures, practices and precautions that should be followed when servicing air conditioning systems:


- Keep your work area clean.
- Always wear safety goggles and protective gloves when working on refrigerant systems.
- Beware of the danger of carbon monoxide fumes caused by running the engine.
- Beware of discharged refrigerant in enclosed or improperly ventilated garages.
- Always disconnect the negative battery cable and discharge and recover the refrigerant whenever repairing the air conditioning system.
- When discharging and recovering the refrigerant, do not allow refrigerant to discharge too fast; it will draw compressor oil out of the system.

- Keep moisture and contaminants out of the system. When disconnecting or removing any lines or parts, use plugs or caps to close the fittings immediately. Never remove the caps or plugs until the lines or parts are reconnected or installed.
- When disconnecting or reconnecting the lines, use two wrenches to support the line fitting, to prevent from twisting or other damage.
- Always install new O-rings whenever a connection is disassembled.
- Before connecting any hoses or lines, apply new specified compressor oil to the O-rings.
- When removing and replacing any parts which require discharging the refrigerant circuit, the operations described in this section must be performed in the following sequence:
 1. Use the J-39500 (ACR4: HFC-134a Refrigerant Recovery / Recycling / Recharging / System) or equivalent to thoroughly discharge and recover the refrigerant.
 2. Remove and replace the defective part.
 3. After evacuation, charge the air conditioning system and check for leaks.

Repair Of Refrigerant Leaks

Refrigerant Line Connections


Install new O-rings, if required. When disconnecting or connecting lines, use two wrenches to prevent the connecting portion from twisting or becoming damaged.




1A-46 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

When connecting the refrigerant line at a block joint, securely insert the projecting portion of the joint portion into the connecting hole on the unit side and secure with a bolt. Apply the specified compressor oil to the O-rings prior to connecting.


CAUTION: Compressor (PAG) oil to be used varies according to the compressor model. Be sure to apply oil specified for the model of compressor.



O-rings (2) must be fitted in the groove (1) of refrigerant line.



Insert the nut into the union.
First, tighten the nut by hand as much as possible, then tighten the nut to the specified torque.



Leak Check

Inspection of refrigerant leak

Refrigerant leak may cause an adverse effect not only on the performance and durability of each component of the air-conditioner, but also on the global atmosphere.

Therefore, it is most important to repair refrigerant leak when there is any leak found.

Inspection flow of refrigerant leak

Step	Action	Yes	No
1	1. Evacuate the refrigerant system. 2. Charge the refrigerant. Is there any refrigerant leak?	Repair refrigerant system.	Go to Step 2.
2	1. Operate the compressor for more than 5 minutes to raise the pressure on the high pressure side. Is there any refrigerant leak at high pressure components?	Repair refrigerant system.	Compressor operation to be confirmed.

Inspection Steps

Check the components of air-conditioner to see if there occurs any refrigerant leak along the flow of refrigerant.

NOTE:

- To avoid an error in the detection of refrigerant leak, make sure of there being no refrigerant vapor or cigarette smoke around the vehicle before conducting the inspection. Also, select a location where the refrigerant vapor will not get blown off with wind.
- Inspection should be conducted chiefly on the pipe connections and sections where a marked oil contamination is found. When refrigerant is leaking, oil inside is also leaking at the same time.
- It is possible to visually check the leak from inside the cooling unit. Follow the method below when checking. Remove the drain hose or resistor of the cooling unit, and insert a leak detector to see if there occurs any leak.

High Pressure Side

1. Discharger section of compressor.
2. Inlet/outlet section of condenser.
3. Inlet/outlet section of receiver driver.
4. Inlet section of cooling unit.

Low Pressure Side

1. Outlet section of cooling unit.
2. Intake section of compressor.

Major Checking Points of Refrigerant Leak

Compressor

- Pipe connection
- Sealing section of shaft
- Mating section or cylinder

Condenser

- Pipe connection

- Welds of condenser body

Receiver driver

- Pipe connection
- Attaching section of pressure switch
- Section around the sight glass

Evaporator unit (cooling unit)

- Pipe connections
- Connections of expansion valve
- Brazed sections of evaporator

NOTE:

- The evaporator and expansion valve are contained in the case. Remove the drain hose or the resistor of the cooling unit and insert a leak detector when checking for any leak.

Flexible hose

- Pipe connection
- Caulking section of the hose
- Hose (cracks, pinholes, flaws)

Pipe

- Pipe connection
- Pipe (cracks, flaws)

Charge valve

NOTE:

- The charge valve, which is used to connect the gauge manifold, is normally provided with a resin cap. When the valve inside gets deteriorated, refrigerant will leak out.

Leak at Refrigerant Line Connections

1. Check the torque on the refrigerant line fitting and, if too loose, tighten to the specified torque.
 - Use two wrenches to prevent twisting and damage to the line.
 - Do not over tighten.

1A-48 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

2. Perform a leak test on the refrigerant line fitting.
3. If the leak is still present, discharge and recover the refrigerant from the system.
4. Replace the O-rings.
 - O-rings cannot be reused. Always replace with new ones.
 - Be sure to apply the specified compressor oil to the new O-rings.
5. Retighten the refrigerant line fitting to the specified torque.
 - Use two wrenches to prevent twisting and damage to the line.
6. Evacuate, charge and retest the system.

Leaks In The Hose

If the compressor inlet or outlet hose is leaking, the entire hose must be replaced. The refrigerant hose must not be cut or spliced for repair.

1. Locate the leak.
2. Discharge and recover the refrigerant.
3. Remove the hose assembly.
 - Cap the open connections at once.
4. Connect the new hose assembly.
 - Use two wrenches to prevent twisting or damage to the hose fitting.
 - Tighten the hose fitting to the specified torque.
5. Evacuate, charge and test the system.

Compressor Leaks

If leaks are located around the compressor shaft seal or shell, replace or repair the compressor.

Recovery, Recycling, Evacuation and Charging of HFC-134a

Air conditioning systems contain HFC-134a. This is a chemical mixture which requires special handling procedures to avoid personal injury.

- Always wear safety goggles and protective gloves.
- Always work in a well-ventilated area. Do not weld or steam clean on or near any vehicle-installed air conditioning lines or components.
- If HFC-134a should come in contact with any part of the body, flush the exposed area with cold water and immediately seek medical help.
- If it is necessary to transport or carry any container of HFC-134a in a vehicle, do not carry it in the passenger compartment.
- If it is necessary to fill a small HFC-134a container from a large one, never fill the container completely. Space should always be allowed above the liquid for expansion.
- HFC-134a and R-12 should never be mixed as their compositions are not the same.
- HFC-134a PAG oil tends to absorb moisture more quickly than R-12 mineral oil and, therefore, should be handled more carefully.
- Keep HFC-134a containers stored below 40°C (100°F).


WARNING:

- **SHOULD HFC-134A CONTACT YOUR EYE(S), CONSULT A DOCTOR IMMEDIATELY.**
- **DO NOT RUB THE AFFECTED EYE(S). INSTEAD, SPLASH QUANTITIES OF FRESH COLD WATER OVER THE AFFECTED AREA TO GRADUALLY RAISE THE TEMPERATURE OF THE REFRIGERANT ABOVE THE FREEZING POINT.**
- **OBTAIN PROPER MEDICAL TREATMENT AS SOON AS POSSIBLE. SHOULD THE HFC-134A TOUCH THE SKIN, THE INJURY MUST BE TREATED THE SAME AS SKIN WHICH HAS BEEN FROSTBITTEN OR FROZEN.**

Refrigerant Recovery

The refrigerant must be discharged and recovered by using the J-39500 (ACR⁴:HFC-134a Refrigerant Recovery/Recycling/Recharging/System) or equivalent before removing or mounting air conditioning parts.

1. Connect the high and low charging hoses of the ACR⁴(or equivalent) as shown below.



901RS181

Legend

- (1) Low Side
- (2) High Side


2. Recover the refrigerant by following the Manufacturer's Instructions.
3. When a part is removed, put a cap or a plug on the connecting portion so that dust, dirt or moisture cannot get into it.

Refrigerant Recycling

Recycle the refrigerant recovered by J-39500 (ACR⁴:HFC-134a Refrigerant Recovery / Recycling / Recharging / System) or equivalent.

For the details of the actual operation, follow the steps in the ACR⁴(or equivalent) Manufacturer's Instructions.

Evacuation of The Refrigerant System



901RS182

Legend

- (1) Low Side
- (2) High Side

NOTE: Explained below is a method using a vacuum pump. Refer to the ACR⁴(or equivalent) manufacturer's instructions when evacuating the system with a ACR⁴(or equivalent).

Air and moisture in the refrigerant will cause problems in the air conditioning system. Therefore, before charging the refrigerant, be sure to evacuate air and moisture thoroughly from the system.

1. Connect the gauge manifold.
 - High-pressure valve (HI) — Discharge-side.
 - Low-pressure valve (LOW) — Suction-side.
2. Discharge and recover the refrigerant.
3. Connect the center hose of the gauge manifold set to the vacuum pump inlet.
4. Operate the vacuum pump, open shutoff valve and then open both hand valves.
5. When the low-pressure gauge indicates approximately 750 mmHg (30 inHg), continue the evacuation for 5 minutes or more.
6. Close both hand valves and stop the vacuum pump.
7. Check to ensure that the pressure does not change after 10 minutes or more.
 - If the pressure changes, check the system for leaks.
 - If leaks occur, retighten the refrigerant line connections and repeat the evacuation steps.

8. If no leaks are found, again operate the vacuum pump for 20 minutes or more. After confirming that the gauge manifold pressure is at 750 mmHg (30 inHg), close both hand valves.

9. Close positive shutoff valve. Stop the vacuum pump and disconnect the center hose from the vacuum pump.

Charging The Refrigerant System


There are various methods of charging refrigerant into the air conditioning system.

These include using J-39500 (ACR⁴:HFC-134a Refrigerant Recovery/Recycling/Recharging/System) or equivalent and direct charging with a weight scale charging station.

Charging Procedure

○ ACR⁴(or equivalent) Method

For the charging of refrigerant recovered by ACR⁴(or equivalent), follow the manufacturer's instruction.



901RS183

Legend


- (1) Low Side
- (2) High Side

○ Direct charging with a weight scale charging station method

1. Make sure the evacuation process is correctly completed.
2. Connect the center hose of the manifold gauge to the weight scale.

1A-50 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)


3. Connect the low pressure charging hose of the manifold gauge to the low pressure side service valve of the vehicle.
4. Connect the high pressure charging hose of the manifold gauge to the high pressure side service valve of the vehicle.



Legend

- (1) Low Side
- (2) High Side
- (3) Refrigerant Container
- (4) Weight Scale

5. Place the refrigerant container(3) up right on a weight scale(4).
Note the total weight before charging the refrigerant.
 - a. Open the refrigerant container valve.
 - b. Open the low side valve on the manifold gauge set.
Refer to the manufacturer's instructions for a weight scale charging station.



6. Perform a system leak test:

- ☐ Charge the system with approximately 200 g (0.44 lbs) of HFC-134a.
- ☐ Make sure the high pressure valve of the manifold gauge is closed.
- ☐ Check to ensure that the degree of pressure does not change.
- ☐ Check for refrigerant leaks by using a HFC-134a leak detector.
- ☐ If a leak occurs, recover the refrigerant. Repair the leak and start all over again from the first step of evacuation.

7. If no leaks are found, continue charging refrigerant to the air conditioning system.

- ☐ Charge the refrigerant until the scale reading decreases by the amount of the charge specified.

Specified amount: 650 g (1.43 lbs)

- ☐ If charging the system becomes difficult:

1. Run the engine at idle and close all the vehicle doors.
2. Turn A/C switch "ON".
3. Set the fan switch to its highest position.
4. Set the air source selector lever to "CIRC".
5. Slowly open the low side valve on the manifold gauge set.

WARNING: BE ABSOLUTELY SURE NOT TO OPEN THE HIGH PRESSURE VALVE OF THE MANIFOLD GAUGE. SHOULD THE HIGH PRESSURE VALVE BE OPENED, THE HIGH PRESSURE REFRIGERANT WOULD FLOW BACKWARD, AND THIS MAY CAUSE THE REFRIGERANT CONTAINER TO BURST.


8. When finished with the refrigerant charging, close the low pressure valve of the manifold gauge and container valve.
9. Check for refrigerant leaks.

Checking The A/C System

1. Run the engine and close all the vehicle doors.
2. Turn A/C switch "ON", set the fan switch to its highest position.
3. Set the air source lever to "CIRC", set the temperature lever to the full cool position.
4. Check the high and low pressure of the manifold gauge.
 - Immediately after charging refrigerant, both high and low pressures might be slightly high, but they settle down to the pressure guidelines shown below:
 - The ambient temperature should be between 25–30°C (77–86°F).
 - The pressure guideline for the high-pressure side is approximately 1372.9–1863.3 kPa (199.1–270.2 psi).
 - The pressure guideline for the low-pressure side is approximately 147.1–294.2 kPa (21.3–42.7 psi).
 - If an abnormal pressure is found, refer to Checking The Refrigerant System With Manifold Gauge in this section.
5. Put your hand in front of the air outlet and move the temperature control lever of the control panel to different positions. Check if the outlet temperature changes as selected by the control knob.

Compressor Assembly

Compressor Assembly and Associated Parts



871RX004

Legend


- | | |
|---------------------------------------|---------------------|
| (1) Magnetic Clutch Harness Connector | (3) Compressor |
| (2) Refrigerant Line Connector | (4) Serpentine Belt |

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant
○Refer to Refrigerant Recovery in this section.
3. Disconnect magnetic clutch harness connector.

4. Remove serpentine belt.

- Move serpentine belt tensioner to loose side using wrench then remove serpentine belt.



850RW001

Legend

- (1) Crankshaft Pulley
- (2) Cooling Fan Pulley
- (3) Tensioner
- (4) Generator
- (5) Air Conditioner Compressor
- (6) Power Steering Oil Pump
- (7) Serpentine Belt

5. Disconnect refrigerant line connector.

- When removing the line connector, the connecting part should immediately be plugged or capped to prevent foreign matter from being mixed into the line.

6. Remove compressor.

Installation

1. Install compressor.

- Tighten the compressor fixing bolts to the specified torque.

Torque: 19 N•m (14 lb•ft)

2. Connect refrigerant line connector.

- Tighten the refrigerant line connector fixing bolts to the specified torque.

Torque: 15 N•m (11 lb•ft)

- O-rings cannot be reused. Always replace with new ones.
- Be sure to apply new compressor oil to the O-rings when connecting refrigerant lines.

3. Install serpentine belt.

- Move serpentine belt tensioner to loose side using wrench, then install serpentine belt to normal position.


4. Connect magnetic clutch harness connector.

New Compressor Installation

The new compressor is filled with 150cc (5.0fl.oz.) of compressor oil and nitrogen gas. When mounting the compressor on the vehicle, perform the following steps;

1. Gently release nitrogen gas from the new compressor.


- Take care not to let the compressor oil flow out.
- Inspect O-rings and replace if necessary.



871RX005

2. Turn the compressor several times by hand and release the compressor oil in the rotor.


3. When installing on a new system, the compressor should be installed as is. When installing on a used system, the compressor should be installed after adjusting the amount of compressor oil. (Refer to Compressor in this section)



871RX005

Condenser Assembly

Condenser Assembly and Associated Parts



875RW008

Legend

- | | |
|-------------------------------|--------------------------------|
| (1) Engine Hood Lock | (4) Radiator Grille |
| (2) Pressure Switch Connector | (5) Engine Hood Front End Stay |
| (3) Refrigerant Line | (6) Condenser Assembly |

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
 - Refer to Refrigerant Recovery in this section.
3. Remove radiator grille.
4. Remove engine hood front end stay.
5. Remove engine hood lock.
 - Apply setting mark to the engine hood lock fixing position before removing it.
6. Disconnect pressure switch connector.
7. Disconnect refrigerant line.
 - When removing the line connector, the connecting part should immediately be plugged or capped to prevent foreign matter from being mixed into the line.
8. Remove condenser assembly.
 - Handle with care to prevent damaging the condenser or radiator fin.

Installation

1. Install condenser assembly.
 - If installing a new condenser, be sure to add 30cc (1.0 fl. oz.) of new compressor oil to a new one.
 - Tighten the condenser fixing bolts to the specified torque.

Torque: 6 N•m (52 lb in)
2. Connect refrigerant line.
 - Tighten the inlet line connector fixing bolt to the specified torque.

Torque: 15 N•m (11 lb ft)

 - Tighten the outlet line connector fixing bolt to the specified torque.


Torque: 6 N•m (52 lb in)

 - O-rings cannot be reused. Always replace with new ones.

- Be sure to apply new compressor oil to the O-rings when connecting the refrigerant line.
- 3. Connect pressure switch connector.
- 4. Install engine hood lock.
- 5. Install engine hood front end stay.
- 6. Install radiator grille.

Condenser Fan Motor

Condenser Fan Motor and Associated Parts



875RW009

Legend

- (1) Condenser Fan Assembly
- (2) Condenser Fan Motor

- (3) Radiator Grille
- (4) Shroud
- (5) Fan

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
 - Refer to Refrigerant Recovery in this section.
3. Remove radiator grille.
4. Remove condenser fan assembly.
 - Disconnect the fan motor connector and remove the 4 fixing bolts.
5. Remove shroud.
 - Remove the 3 fixing nuts.
 - Loosen the condenser fixing nut and disconnect the fan motor connector from bracket.

6. Remove fan.
 - Remove the fan fixing C-ring and plate.

7. Remove condenser fan motor.


Installation

To install, follow the removal steps in the reverse order, noting the following point.

1. Route the fan motor harness in its previous position, and fix it securely with clip and bracket.

Receiver / Drier

Receiver / Drier and Associated Parts



Legend

- (1) Pressure Switch Connector
- (2) Refrigerant Line
- (3) Radiator Grille
- (4) Receiver / Drier
- (5) Bracket Bolt

Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. If installing a new receiver/drier, be sure to add 30cc (1.0 fl. oz.) of new compressor oil to a new one.
2. Put the receiver/drier in the bracket and connect with the refrigerant line. Check that no excessive force is imposed on the line. Fasten the bracket bolt to the receiver/drier.
3. Tighten the refrigerant line to the specified torque.

Torque: 6 N•m (52 lb in)


4. O-rings cannot be reused. Always replace with new ones.
5. Be sure to apply new compressor oil to the O-rings when connecting the refrigerant line.

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
 - Refer to Refrigerant Recovery in this section.
3. Remove radiator grille.
4. Disconnect pressure switch connector.
5. Disconnect refrigerant line.
 - When removing the line connected part, the connecting part should immediately be plugged or capped to prevent foreign matter from being mixed into the line.
6. Remove bracket bolt.
7. Remove receiver/drier.
 - Loosen the bolt, then, using care not to touch or bend the refrigerant line, carefully pull out the receiver/drier.

Pressure Switch

Pressure Switch and Associated Parts



875RW012

Legend

- (1) Pressure Switch Connector
- (2) Pressure Switch
- (3) Radiator Grille

Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. O-ring cannot be reused. Always replace with a new one.
2. Be sure to apply new compressor oil to the O-ring when connecting pressure switch.
3. Tighten the pressure switch to the specified torque.


Torque: 13 N•m (113 lb in)

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
 - Refer to "Refrigerant Recovery in this section.
3. Remove radiator grille.
4. Disconnect pressure switch connector.
5. Disconnect pressure switch.
 - When removing the switch connected part, the connecting part should immediately be plugged or capped to prevent foreign matter from being mixed into the line.

Evaporator Assembly

Evaporator Assembly and Associated Parts




874RW007

Legend

- | | |
|--|-------------------------|
| (1) Resistor and Electronic Thermostat Connector | (3) Refrigerant Line |
| (2) Drain Hose | (4) Glove Box |
| | (5) Evaporator Assembly |

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
○Refer to Refrigerant Recovery in this section.
3. Remove glove box.
4. Disconnect resistor (2) and electronic thermostat connector (1).



840RS005

5. Disconnect drain hose.

6. Disconnect refrigerant line.

- Use a back-up wrench when disconnecting and reconnecting the refrigerant lines.
- When removing the refrigerant line connected part, the connecting part should immediately be plugged or capped to prevent foreign matter from being mixed into the line.

7. Remove evaporator assembly.

Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. To install a new evaporator assembly, add 50cc (1.7 fl. oz.) of new compressor oil to the new core.
2. Tighten the refrigerant outlet line to the specified torque.

Torque: 25 N•m (18 lb ft)

3. Tighten the refrigerant inlet line to the specified torque.

Torque: 15 N•m (11 lb ft)

4. O-rings cannot be reused. Always replace with new ones.
5. Be sure to apply new compressor oil to the O-rings when connecting lines.

Electronic Thermostat, Evaporator Core and/or Expansion Valve**Disassembled View**


874RX001

Legend


- | | |
|-------------------------|---------------------------|
| (1) Lining | (6) Clip |
| (2) Expansion Valve | (7) Attaching Screw |
| (3) O-ring | (8) Evaporator Core |
| (4) Evaporator Assembly | (9) Electronic Thermostat |
| (5) Lower Case | (10) Upper Case |

Removal


1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
 - Refer to Refrigerant Recovery in this section.
3. Remove evaporator assembly.
 - Refer to Evaporator Assembly in this section.
4. Remove the electronic thermostat sensor fixing clip.
 - Pull the sensor from the evaporator assembly.
5. Remove clip.
6. Remove attaching screw.
7. Remove upper case.
8. Remove lower case.
 - Slit the case parting face with a knife since the lining is separated when removing the evaporator.



- Lift to remove the upper case.



9. Remove evaporator core.




10. Remove expansion valve.
 - Tear off the insulator carefully.
 - Remove the sensor fixing clip.
 - Use a back-up wrench when disconnecting all refrigerant pipes.

Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. The sensor is installed on the core with the clip.
2. The sensor must not interfere with the evaporator core.
3. When installing the new evaporator core, install the thermo sensor (2) to the evaporator core (1) specified position with the clip in the illustration.



4. O-rings cannot be reused. Always replace with new ones.
5. Be sure to apply new compressor oil to the O-rings when connecting lines.
6. Be sure to install the sensor and the insulator on the place where they were before.
7. To install a new evaporator core, add 50cc (1.7 fl. oz.) of new compressor oil to the new core.
8. Tighten the refrigerant lines to the specified torque. Refer to Main Data and Specifications for Torque Specifications in this section.
9. Apply an adhesive to the parting face of the lining when assembling the evaporator assembly.

Refrigerant Line

Refrigerant Line and Associated Parts



852RX001

Legend

- | | |
|--------------------------------------|---|
| (1) Clip and Clamp | (3) Discharge Line (High-Pressure Hose) |
| (2) Liquid Line (High-Pressure Pipe) | (4) Radiator Grille |
| | (5) Suction Line (Low-Pressure Pipe) |

1A-62 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

Removal

1. Disconnect the battery ground cable.
2. Discharge and recover refrigerant.
 - Refer to Refrigerant Recovery in this section.
3. Remove radiator grille.
4. Remove clip and clamp.
5. Disconnect liquid line (High-pressure pipe).
6. Disconnect suction line (Low-pressure pipe) using a back-up wrench.
7. Disconnect suction line (Low-pressure hose) using a back-up wrench.
8. Disconnect discharge line (High-pressure hose) using a back-up wrench.
 - Use a backup wrench when disconnecting and reconnecting the refrigerant lines.

- When removing the refrigerant line connecting part, the connecting part should immediately be plugged or capped to prevent foreign matter from being mixed into the line.

Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. O-rings cannot be reused. Always replace with new ones.
2. Be sure to apply new compressor oil to the O-rings when connecting lines.
3. Tighten the refrigerant line to the specified torque. Refer to Main Data and Specifications for Torque Specifications in this section.


Main Data And Specifications

General Specifications

Heater Unit	
Temperature control	Reheat air mix system
Capacity	3,700 Kcal./hr.
Air flow	280 m ³ /h
HEATER CORE	
Type	Fin and tube type
Element dimension	167 mm (6.6 in.) × 151 mm (5.9 in.) × 35 mm (1.4 in.)
Radiating area	Approx. 2.4 m ²
EVAPORATOR ASSEMBLY	
Capacity	4,100 Kcal./hr.
Air flow	430 m ³ /hr
EVAPORATOR CORE	
Type	Al-laminate louver fin type
Element dimension	235 mm (9.3 in.) × 224 mm (8.8 in.) × 60 mm (2.4 in.)
EXPANSION VALVE	
Type	External pressure equalizer type
THERMOSTAT SWITCH	
Type	Electronic thermostat OFF: Below 0.5 ± 0.5 °C (32.9 ± 0.9 °F) ON: Above 4.5 ± 0.5 °C (40.1 ± 0.9 °F)
CONDENSER	
Type	Parallel flow type
Radiation performance	9,400 Kcal./hr
RECEIVER/DRIER	
Type	Assembly includes sight glass with dual (triple) pressure switch (V6) or pressure sensor (L14)
Internal volume	300 cc (10 fl.oz.)


PRESSURE SWITCH	
Type	Dual pressure switch
	Low pressure control ON: 205.9±29.4 kPa (29.9±4.3 psi) OFF: 176.5±24.5 kPa (25.6±3.6 psi)
	High pressure control ON: 2353.6±196.1 kPa (341.3±28.4 psi) OFF: 2942.0±196.1 kPa (426.6±28.4 psi)
	Triple pressure switch (V6, A/T)
	Low pressure control ON: 196.3±29.4 kPa (27.0±4.3 psi) OFF: 176.5±19.6 kPa (25.6±2.8 psi)
	Medium pressure control ON: 1471.0±98.1 kPa (213.3±14.2 psi) OFF: 1078.7±117.7 kPa (156.4±17.7 psi)
	High pressure control ON: 2353.6±196.1 kPa (341.3±28.4 psi) OFF: 2942.0±196.1 kPa (426.6±28.4 psi)
REFRIGERANT	
Type	HFC-134a
Specified amount	650 g (1.43 lbs.)

Torque Specifications



852RX003

1A-64 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)



874RX006

Compressor

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS ON-VEHICLE SERVICE INFORMATION. FAILURE TO FOLLOW CAUTIONS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.**

General Description

When servicing the compressor, keep dirt or foreign material from getting on or into the compressor parts and system. Clean tools and a clean work area are important for proper service. The compressor connections and the outside of the compressor should be cleaned before any "On-Vehicle" repair, or before removal of the compressor. The parts must be kept clean at all times and any parts to be reassembled should be cleaned with Trichloroethane, naphtha, kerosene, or equivalent solvent, and dried with dry air. Use only lint free cloths to wipe parts.

The operations described below are based on bench overhaul with compressor removed from the vehicle, except as noted. They have been prepared in order of accessibility of the components. When the compressor is removed from the vehicle for servicing, the oil remaining in the compressor should be discarded and new compressor oil added to the compressor.

Compressor malfunction will appear in one of four ways: noise, seizure, leakage or low discharge pressure. Resonant compressor noises are not cause for alarm; however, irregular noise or rattles may indicate broken parts or excessive clearances due to wear. To check seizure, de-energize the magnetic clutch and check to

see if the drive plate can be rotated. If rotation is impossible, the compressor is seized. Low discharge pressure may be due to a faulty internal seal of the compressor, or a restriction in the compressor. Low discharge pressure may also be due to an insufficient refrigerant charge or a restriction elsewhere in the system. These possibilities should be checked prior to servicing the compressor. If the compressor is inoperative, but is not seized, check to see if current is being supplied to the magnetic clutch coil terminals.

The compressor oil used in the HFC-134a system compressor differs from that used in R-12 systems.

Also, compressor oil to be used varies according to the compressor model. Be sure to avoid mixing two or more different types of oil.

If the wrong oil is used, lubrication will be poor and the compressor will seize or malfunction.


DKV-14G Type Compressor

DKV-14G is equipped with five-vane rotary compressor. These vanes are built into a rotor which is mounted on a shaft.

When the shaft rotates, the vanes built into the cylinder block assembly are operated by centrifugal force.

This changes the volume of the space formed by the rotor and cylinder, resulting in the intake and compression of the refrigerant gas. The discharge valve and the valve stopper, which protects the discharge valve, are built into the cylinder block assembly. There is no suction valve but a shaft seal is installed between the shaft and head; a trigger valve, which applies back pressure to the vanes, is installed in the cylinder block and a refrigerant gas temperature sensor is installed in the front head.

The specified quantity of compressor oil is contained in the compressor to lubricate the various parts using the refrigerant gas discharge pressure.




871RX002

Diagnosis

Condition	Possible cause	Correction
Noise from compression	Defective rotor/piston	Replace compressor/cylinder and shaft assembly
	Defective shaft	Replace compressor/cylinder and shaft assembly
Noise from magnetic clutch	Defective bearing	Replace magnetic clutch
	Defective clutch	Replace magnetic clutch
	Clearance between drive plate and pulley not standard	Adjust the clearance or replace magnetic clutch
Insufficient cooling	Defective gasket	Replace compressor/gasket
	Defective rotor/reed valve	Replace compressor/valve plate
	Defective trigger valve/suction valve	Replace compressor/suction valve
Not rotating	Defective rotor/piston	Replace compressor/cylinder and shaft assembly
	Defective shaft	Replace compressor/cylinder and shaft assembly
	Rotating parts seized due to insufficient oil	Replace compressor
Oil and/or gas leakage	Defective seal	Replace compressor/shaft seal
	Defective O-ring	Replace

Magnetic Clutch Assembly (DKV-14D Type)

Parts Location View




871RW009

Legend

- | | |
|----------------------|---------------------|
| (1) Drive Plate bolt | (4) Pulley Assembly |
| (2) Drive Plate | (5) Field Coil |
| (3) Snap Ring | (6) Shim(s) |
| | (7) Lead Wire |


Removal

- Using drive plate holder J-33939 (1) to prevent the drive plate from rotating, then remove the drive plate bolt.



871RW014

- Remove drive plate by using drive plate puller J-33944-A (2) and forcing screw J-33944-4 (1).




871RW013


1A-68 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

3. Remove shim (s).


4. Remove snap ring (1) by using snap ring pliers.




5. Remove pulley assembly by using pulley puller pilot J-38424, pulley puller J-8433 and pulley puller leg J-24092-2.



6. Loosen screw and disconnect the coil lead wire connector.



7. Loosen three screws and remove the field coil.



Inspection and Repair

Drive Plate

If the frictional surface shows signs of damage due to excessive heat, the drive plate and pulley should be replaced.

Pulley Assembly

Check the appearance of the pulley assembly. If the frictional surface of the pulley shows signs of excessive grooving due to slippage, both the pulley and drive plate should be replaced. The frictional surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.


Coil

Check coil for loose connector or cracked insulation.

Installation

1. Install field coil.

- Align the located portion (1) of the field coil and compressor.




871RW017

- Tighten the mounting screw to the specified torque.

Torque: 5N·m (44 lb in)

2. Connect the lead wire connector with the rubber hold and tighten the screw.
3. Install pulley assembly by using pulley installer J-33940-A and drive handle J-8092.




871RS013

4. Install snap ring.


5. Install shim (s).

6. Install the drive plate to the compressor drive shaft together with the original shim(s)(1). Press the drive plate by hand.



871RW012

7. Install drive plate bolt by using drive plate holder J-33939 (1) to prevent the drive plate from rotating.



871RW014


- Tighten the drive plate bolt to the specified torque.

Torque: 13 N·m (113 lb in)

- After tightening the drive plate bolt, check to be sure the pulley rotates smoothly.

1A-70 HEATING, VENTILATION AND AIR CONDITIONING (HVAC)

- Check to be sure that the clutch clearance is between 0.3-0.6 mm (0.01-0.02 in.)



871RW011

- If necessary, install adjusting shim(s).

- Adjusting shims are available in the following thickness.

Thickness

- 0.1 mm (0.0039 in.)
- 0.3 mm (0.0118 in.)
- 0.5 mm (0.0197 in.)

Compressor Oil

Oil Specification

- The HFC-134a system requires a synthetic (PAG) compressor oil whereas the R-12 system requires a mineral compressor oil. The two oils must never be mixed.
- Compressor (PAG) oil varies according to compressor model. Be sure to use oil specified for the model of compressor.
- **Always use HFC-134a Vane Rotary Type Compressor Oil (AIPDN Part No.2-90188-301-0)**

Handling of Oil

- The oil should be free from moisture, dust, metal powder, etc.
- Do not mix with other oil.
- The water content in the oil increases when exposed to the air. After use, seal oil from air immediately. (HFC-134a Vane Rotary Compressor Oil absorbs moisture very easily.)
- The compressor oil must be stored in steel containers, not in plastic containers.

Compressor Oil Check

The oil used to lubricate the compressor is circulating with the refrigerant.

Whenever replacing any component of the system or a large amount of gas leakage occurs, add oil to maintain the original amount of oil.

Oil Capacity

Capacity total in system: 150cc (5.0 fl.oz)

**Compressor (Service parts) charging amount:
150 cc (5.0 fl.oz)**

Checking and Adjusting Oil Quantity for Used Compressor

1. Perform oil return operation. Refer to Oil Return Operation in this section.
2. Discharge and recover refrigerant and remove the compressor.
3. Drain the compressor oil and measure the extracted oil with a measuring cylinder.
4. If the amount of oil drained is much less than 90 cc (3.0 fl. oz.), some refrigerant may have leaked out. Conduct a leak tests on the connections of each system, and if necessary, repair or replace faulty parts.
5. Check the compressor oil contamination. (Refer to Contamination of Compressor Oil in this section.)
6. Adjust the oil level following the next procedure below.

(Charging Amount)	(Collected Amount)
more than 90cc (3.0 fl.oz)	same as collected amount
less than 90 cc (3.0 fl.oz)	90cc (3.0 fl.oz)

7. Install the compressor, then evacuate, charge and perform the oil return operation.
8. Check system operation.

When it is impossible to preform oil return operation, the compressor oil should be checked in the following order:

1. Discharge and recover refrigerant and remove the compressor.

2. Drain the compressor oil and measure the extracted oil with a measuring cylinder.
3. Check the oil for contamination.
4. If more than 90 cc (3.0 fl. oz.) of oil is extracted from the compressor, supply the same amount of oil to the compressor to be installed.
5. If the amount of oil extracted is less than 90 cc (3.0 fl. oz.), recheck the compressor oil in the following order.
6. Supply 90 cc (3.0 fl. oz.) of oil to the compressor and install it onto the vehicle.
7. Evacuate and recharge with the proper amount of refrigerant.
8. Perform the oil return operation.
9. Remove the compressor and recheck the amount of oil.
10. Adjust the compressor oil, if necessary.

(Collected Amount)	(Charging Amount)
more than 90 cc (3.0 fl.oz)	same as collected amount
less than 90 cc (3.0 fl.oz)	90 cc (3.0 fl.oz)

Checking and Adjusting for Compressor Replacement

150 cc (5.0 fl.oz.) of oil is charged in compressor (service parts). So it is necessary to drain the proper amount of oil from the new compressor.

1. Perform oil return operation.
2. Discharge and recover the refrigerant and remove the compressor.
3. Drain the compressor oil and measure the extracted oil.
4. Check the compressor oil for contamination.
5. Adjust the oil level as required.

(Amount of oil drained from used compressor)	(Draining amount of oil from new compressor)
less than 90 cc (3.0 fl.oz)	Same as drained amount
more than 90 cc (3.0 fl.oz)	90 cc (3.0 fl.oz)

6. Evacuate, charge and perform the oil return operation.
7. Check the system operation.

Contamination of Compressor Oil

Unlike engine oil, no cleaning agent is added to the compressor oil. Even if the compressor runs for a long period of time (approximately one season), the oil never becomes contaminated as long as there is nothing wrong with the compressor or its method of use.

Inspect the extracted oil for any of the following conditions:

- ☐ The capacity of the oil has increased.

- ☐ The oil has changed to red.

- ☐ Foreign substances, metal powder, etc., are present in the oil.

If any of these conditions exists, the compressor oil is contaminated. Whenever contaminated compressor oil is discovered, the receiver/drier must be replaced.

Oil Return Operation

There is close affinity between the oil and the refrigerant. During normal operation, part of the oil recirculates with the refrigerant in the system. When checking the amount of oil in the system, or replacing any component of the system, the compressor must be run in advance for oil return operation. The procedure is as follows:

1. Open all the doors and the engine hood.
2. Start the engine and air conditioning switch to "ON" and set the fan control knob at its highest position.
3. Run the compressor for more than 20 minutes between 800 and 1,000 rpm in order to operate the system.
4. Stop the engine.

Replacement of Component Parts


When replacing the system component parts, supply the following amount of oil to the component parts to be installed.

(Component parts to be installed)	(Amount of Oil)
Evaporator	50 cc (1.7 fl. oz.)
Condenser	30 cc (1.0 fl. oz.)
Receiver/dryer	30 cc (1.0 fl. oz.)
Refrigerant line (one piece)	10 cc (0.3 fl. oz.)

Main Data and Specifications

General Specifications

COMPRESSOR	
Model	DKV-14G
Type	Vane rotary type
Number of vanes	5
Rotor diameter	64 mm (2.52 in.)
Stroke	8.75 mm (0.34 in.)
Displacement	140 cc (47.3 fl.oz.)
Maximum speed	7,000 rpm (up to 8,400 rpm)
Direction of rotation	Clockwise (Front-side view)
Lubrication system	Pressure differential type
Lubricant	R-134a Vane Rotary Type Compressor Oil (AIPDN Part No.2-90188-301-0) 150 cc (5.0 fl.oz.)
Refrigerant	Refrigerant-134a (R-134a), 650 g (1.43 lbs.)
Shaft seal	Lip type
Weight	3.0 kg
MAGNETIC CLUTCH	
Type	Electromagnetic single-plate dry clutch
Rated voltage	12 Volts D.C.
Current consumption	3.7 A
Starting torque	49 N·m (36 lb·ft)
Direction of rotation	Clockwise (Front-side view)
Weight	2.4 kg (5.3 lbs.)

Torque Specifications

871RW010

Special Tools









ILLUSTRATION	TOOL NO. TOOL NAME
 901RS191	J-33939 Drive plate holder
 901RS192	J-33944-A Drive plate puller
 901RS193	J-33944-4 Forcing screw
 901RS194	J-38424 Pulley puller pilot
 901RS195	J-8433 Pulley puller
 901RS196	J-24092-2 Pulley puller leg

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS197	J-33940-A Pulley installer
 901RS218	J-8092 Drive handle

RODEO

STEERING

POWER-ASSISTED STEERING SYSTEM

CONTENTS

Service Precaution	2A-2	Removal	2A-27
Diagnosis	2A-2	Inspection and Repair	2A-27
General Description	2A-8	Installation	2A-27
Power Steering System Test	2A-10	Supplemental Restraint System Steering	
Maintenance	2A-11	Wheel & Column	2A-28
Fluid Level	2A-11	Service Precaution	2A-28
Bleeding The Power Steering System	2A-11	SRS Connectors	2A-28
Bleeding Procedure	2A-11	Inflator Module	2A-30
Flushing The Power Steering System	2A-11	Inflator Module and Associated Parts	2A-30
Steering Wheel Free Play Inspection	2A-12	Removal	2A-30
Front End Alignment Inspection and		Inspection and Repair	2A-31
Adjustment	2A-12	Installation	2A-31
Main Data and Specifications	2A-16	Steering Wheel	2A-32
Special Tools	2A-17	Steering Wheel and Associated Parts	2A-32
Power Steering Unit	2A-18	Removal	2A-32
Power Steering Unit and Associated Parts	2A-18	Installation	2A-34
Removal	2A-18	Combination Switch	2A-35
Installation (4x2 Model)	2A-19	Combination Switch and Associated Parts	2A-35
Installation (4x4 Model)	2A-19	Removal	2A-35
Power Steering Unit Disassembled View ..	2A-20	Installation	2A-37
Disassembly	2A-20	Lock Cylinder	2A-39
Inspection and Repair	2A-20	Lock Cylinder and Associated Parts	2A-39
Reassembly	2A-20	Removal	2A-39
Main Data and Specifications	2A-21	Installation	2A-41
Special Tools	2A-21	System Inspection	2A-42
Power Steering Pump	2A-22	Steering Column	2A-43
Power Steering Pump and Associated Parts	2A-22	Steering Column and Associated Parts	2A-43
Removal	2A-22	Removal	2A-43
Installation	2A-22	Inspection	2A-46
Power Steering Pump Disassembled View	2A-23	Installation	2A-47
Disassembly	2A-23	System Inspection	2A-48
Inspection and Repair	2A-24	Supplemental Restraint System Steering	
Reassembly	2A-24	Wheel & Column and Associated Parts	2A-49
Main Data and Specifications	2A-26	Main Data and Specifications	2A-49
Transfer Gear Assembly	2A-27	Special Tools	2A-49
Transfer Gear Assembly and Associated			
Parts	2A-27		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Diagnosis

Since the problems in steering, suspension, wheels and tires involve several systems, they must all be considered when diagnosing a complaint. To identify the symptom, always road test the vehicle first. Proceed with the following preliminary inspections and correct any defects which are found.

1. Inspect tires for proper pressure and uneven wear.
2. Raise vehicle on a hoist, then inspect front and rear suspension and steering linkage for loose or damaged parts.
3. Spin the front wheels. Inspect for out-of-round tires, out-of-balance tires, loose and/or rough wheel bearings.

General Diagnosis

Condition	Possible cause	Correction
Vehicle Pulls	Mismatched or uneven tires.	Replace tire.
	Tires not adequately inflated.	Adjust tire pressure.
	Broken or sagging springs.	Replace spring.
	Radial tire lateral force.	Replace tire.
	Improper wheel alignment.	Adjust wheel alignment.
	Brake dragging in one wheel.	Repair brake.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension part(s).
	Faulty shock absorbers.	Replace shock absorber.
	Parts in power steering valve defective.	Replace power steering unit.
Abnormal or Excessive Tire Wear	Sagging or broken spring.	Replace spring.
	Tire out of balance.	Balance or replace tire.
	Improper wheel alignment.	Check front end alignment.
	Faulty shock absorber.	Replace shock absorber.
	Hard driving.	Replace tire.
	Overloaded vehicle.	Replace tire and reduce load.
	Tires not rotated periodically.	Replace or rotate tire.
	Worn or loose road wheel bearings.	Replace wheel bearing.
	Wobbly wheel or tires.	Replace wheel or tire.
	Tires not adequately inflated.	Adjust the pressure.

Condition	Possible cause	Correction
Wheel Hop	Blister or bump on tire.	Replace tire.
	Improper shock absorber operation.	Replace shock absorber.
Shimmy, Shake or Vibration	Tire or wheel out of balance.	Balance wheels or replace tire/or wheel.
	Loose wheel bearings.	Replace wheel bearing.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
	Excessive wheel run-out.	Repair or replace wheel and/or tire.
	Blister or bump on tire.	Replace tire.
	Excessive loaded radial run-out of tire/wheel assembly.	Replace tire or wheel.
	Improper wheel alignment.	Check wheel alignment.
	Loose or worn steering linkage.	Tighten or replace steering linkage.
	Loose steering unit.	Tighten steering unit.
	Tires not adequately inflated.	Adjust tire pressure.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension parts.
	Faulty shock absorber.	Replace shock absorber.
	Hub bearing preload misadjustment.	Adjust preload.
	Parts in power steering valve defective.	Replace power steering unit.
Hard Steering	Bind in steering linkage ball studs, upper or lower end ball joint.	Replace ball joint.
	Improper wheel alignment.	Check wheel alignment.
	Tire not adequately inflated.	Inflate tires to proper pressure.
	Bind in steering column or shaft.	Repair or replace.
	Improper power steering system operation.	Repair or replace. Refer to "Power steering system diagnosis"
Too Much Play In Steering	Wheel bearings worn.	Replace wheel bearings.
	Loose steering unit or linkage.	Retighten or repair.
	Worn or loose steering shaft universal joint.	Retighten or replace steering shaft.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
Poor Steering Wheel Returnability	Bind in steering linkage ball joints.	Replace ball joints.
	Bind in upper or lower end ball joints.	Replace ball joints.
	Bind in steering column and shaft.	Repair or replace.
	Bind in steering gear.	Check and repair steering gear.
	Improper wheel alignment.	Adjust wheel alignment.
	Tires not adequately inflated.	Adjust tire pressure.
	Loose steering wheel nut.	Retighten.
	Worn wheel bearing.	Replace.

2A-4 POWER-ASSISTED STEERING SYSTEM

Condition	Possible cause	Correction
Abnormal Noise	Worn, sticky or loose upper or lower ball joint, steering linkage ball joints or drive axle joints.	Replace.
	Faulty shock absorbers.	Replace.
	Worn upper or lower control arm bushing.	Replace.
	Loose stabilizer bar.	Retighten bolts or replace bushings.
	Loose wheel nuts.	Tighten nuts. Check for elongated wheel nut holes. Replace wheel if required.
	Loose suspension bolts or nuts.	Retighten suspension bolts or nuts.
	Broken or otherwise damaged wheel bearings.	Replace wheel bearing.
	Broken suspension springs.	Replace spring.
	Loose steering unit.	Retighten mounting bolt.
	Faulty steering unit.	Replace steering unit.
Wandering or Poor Steering Stability	Mismatched or unevenly worn tires.	Replace tire or inflate tires to proper pressure.
	Loose steering linkage ball joints.	Replace ball joints.
	Faulty shock absorbers.	Replace shock absorber.
	Loose stabilizer bar.	Tighten or replace stabilizer bar or bushings.
	Broken or sagging springs.	Replace spring (pairs).
	Improper wheel alignment.	Adjust wheel alignment.
Erratic Steering When Braking	Worn wheel bearings.	Replace wheel bearings.
	Broken or sagging springs.	Replace spring (pairs).
	Leaking caliper.	Repair or replace caliper.
	Warped discs.	Replace brake disc.
	Badly worn brake pads.	Replace brake pads.
	Tires are inflated unequally.	Inflate tires to proper pressure.

Power Steering System

There is some noise in all power steering systems. One of the most common is a hissing sound when the steering wheel is fully turned and the car is not moving. This noise will be most evident when the steering wheel is operated while the brakes are applied. There is no relationship be-

tween this noise and steering performance. Do not replace the valve unless the "hissing" noise is extremely objectionable. A replacement valve will also have a slight noise, and is not always a cure for the condition.

Condition	Possible cause	Correction
Rattle or Chucking Noise	Pressure hose touching other parts of vehicle.	Adjust hose position. Do not bend tubing by hand.
	Tie rod ends loose.	Tighten or replace tie rod end.
	Loose steering unit mounting.	Tighten steering unit mounting.
Poor Return of Steering Wheel to Center	Improper front wheel alignment.	Adjust front wheel alignment.
	Wheel bearing worn.	Replace front wheel bearing.
	Tie rod end binding.	Replace tie rod end.
	Ball joint binding.	Replace ball joint.
	Tight or frozen steering shaft bearing.	Replace steering assembly.
	Sticky or plugged steering unit valve.	Flush or replace steering unit.
	Entry of air in the power steering system.	Bleed the system.
Momentary Increase In Effort When Turning Wheel Fast To Right or Left	High internal leakage.	Repair steering gear.
	Power steering fluid level low.	Replenish fluid.
Steering Wheel Surges or Jerks When Turning Especially During Parking	Insufficient pump pressure.	Repair pump assembly.
	Sticky steering unit valve.	Flush or replace steering unit.
	Power steering fluid level low.	Replenish fluid.
Excessive Wheel Kick Back or Loose Steering	Air in system.	Bleed hydraulic system.
	Tie rod end loose.	Tighten tie rod end.
	Wheel bearing worn.	Replace wheel bearing.
Hard Steering or Lack of Power Assist	Sticky steering unit valve.	Flush or replace steering unit.
	Insufficient pump pressure.	Repair pump assembly.
	Excessive internal pump leakage.	Repair pump assembly.
	Excessive internal steering gear leakage.	Repair steering gear.
	Power steering fluid level low.	Replenish fluid.
Unstable Engine Idling or Stalling When Turning	Pressure switch of the power steering pump or its harness is faulty.	Repair or replace.

2A-6 POWER-ASSISTED STEERING SYSTEM

Power Steering Pump

Foaming milky power steering fluid, low fluid level, and possible low pressure can be caused by air in the fluid, or loss of fluid due to internal pump leakage. Check for leak and correct. Bleed the system. Extremely cold temperatures will cause air bubbles in the system if the fluid level

is low. If the fluid level is correct and the pump still foams, remove the pump from the vehicle and check housing for cracks. If the housing is cracked, replace the pump housing.

Condition	Possible cause	Correction
Low Pressure Due to Steering Pump	Relief valve sticking or inoperative.	Replace relief valve.
	Side plate not flat against cam ring.	Replace side plate.
	Extreme wear of cam ring.	Replace cam ring.
	Scored side plate or rotor.	Replace side plate or rotor.
	Vanes sticking in rotor slots.	Repair or replace vanes and rotor.
	Cracked or broken side plate.	Replace side plate.
	High internal leakage.	Repair internal leakage.
Low Pressure Due to Steering Gear	Scored housing bore.	Replace housing.
Growling Noise In Steering Pump	Excessive back pressure in hoses or steering unit caused by restriction.	Repair steering unit or pump.
	Scored side plate or rotor.	Replace side plate or rotor.
	Worn cam ring.	Replace cam ring.
Groaning Noise In Steering Pump	Air in the fluid.	Bleed hydraulic system.
	Low fluid level.	Replenish fluid.
	Pump mounting loose.	Tighten mounting bolt.
Rattling Noise In Steering Pump	Vanes sticking in rotor slots.	Repair or replace vanes and rotor.
	Vane improperly installed.	Repair rotor and vane.
Swishing Noise In Steering Pump	Damaged relief valve.	Replace relief valve.
Whining Noise In Steering Pump	Scored side plate and vanes.	Replace side plate and vanes.

Steering Column Lock System

Condition	Possible cause	Correction
Will Not Unlock	Damaged lock cylinder.	Replace lock cylinder.
	Damaged park lock cable.	Replace park lock cable.
Will Not Lock	Lock spring broken or worn.	Replace lock cylinder.
	Damaged lock cylinder.	Replace lock cylinder.
	Ignition switch stuck.	Repair or replace ignition switch.
	Park lock cable damaged.	Replace park lock cable.
Key Cannot be Removed in "OFF-LOCK"	Ignition switch is not set correctly.	Correct ignition switch.
	Damaged lock cylinder.	Replace lock cylinder.
	Faulty shift lock mechanism.	Repair or replace the shift lock mechanism.

Column

Condition	Possible cause	Correction
Noise in Column	Universal joint loose.	Tighten joint.
	Shaft lock snap ring not seated.	Place snap ring in proper position.

Turn Signal Switch

This diagnosis covers mechanical problems only. Refer to Turn Signal Switch in Electrical section for electrical diagnosis.


Condition	Possible cause	Correction
Turn Signal Will Not Stay In Turn Position	Foreign material or loose parts preventing movement of yoke.	Repair or replace signal switch.
	Broken or missing detent or canceling spring.	Replace signal switch.
Turn Signal Will Not Cancel	Loose switch mounting screws.	Tighten mounting screws.
	Switch or anchor bosses broken.	Replace turn signal switch.
	Broken, missing or out of position detent, return or canceling spring.	Replace turn signal switch.
	Worn canceling cam.	Replace turn signal switch.
Turn Signal Difficult To Operate	Turn signal switch arm loose.	Tighten arm screw.
	Broken or distorted yoke.	Replace turn signal switch.
	Loose or misplaced springs.	Replace turn signal switch.
	Foreign parts and/or material.	Repair turn signal switch.
	Loose turn signal switch mounting screws.	Tighten mounting screws.
Turn Signal Will Not Indicate Lane Change	Broken lane change pressure pad or spring hanger.	Replace turn signal switch.
	Broken, missing or misplaced lane change spring.	Replace turn signal switch.
	Base of wire damaged.	Replace turn signal switch.
Hazard Switch Cannot Be Turned Off	Foreign material between hazard switch to turn signal switch body.	Repair or replace hazard switch.
No Turn Signal Lights	Electrical failure in chassis harness.	Refer to Electrical section.
	Inoperative turn signal flasher unit.	Replace flasher unit.
	Loose chassis harness connector.	Repair loose connector.
Front or Rear Turn Signal Lights Not Flashing	Burned-out or damaged turn signal bulb.	Replace bulb.
	High resistance connection to ground at bulb socket.	Repair bulb socket.
	Loose chassis harness connector.	Repair loose connector.

2A-8 POWER-ASSISTED STEERING SYSTEM

General Description

The hydraulic power steering system consists of a pump, an oil reservoir, a steering unit, a pressure hose and a return hose.


Power Steering Unit



A02RW001

The power steering unit is rack and pinion type.
The toe-in angle can be adjusted by turning the rod on each side.
The steering housing cannot be disassembled.

Hydraulic Pump



A02RX002


The hydraulic pump is vane-type design. The submerged pump has housing and internal parts that are inside the reservoir and operate submerged in oil. There are two bore openings at the rear of the pump housing. The larger opening contains the cam ring, pressure plate, thrust plate, rotor and vane assembly, and end plate. The smaller opening contains the pressure line union, flow control valve and spring.

The flow control orifice is part of the pressure line union. The pressure relief valve inside the flow control valve limits the pump pressure.

Steering Column

Pressure Switch

When hydraulic pressure reaches 3430 kPa (500 psi), the pressure switch of the power steering pump closes causing the Engine Control Module (ECM) to actuate the idle air control valve, which increases the engine rpm to prevent the overload-induced engine speed slow down. The switch opens when hydraulic pressure drops to 2940 kPa (430 psi).



A02RX001

WARNING: TO AVOID DEPLOYMENT WHEN TROUBLE-SHOOTING THE SRS SYSTEM, DO NOT USE ELECTRICAL TEST EQUIPMENT, SUCH AS BATTERY-POWERED OR A/C-POWERED VOLT-METER, OHMMETER, ETC., OR ANY TYPE OF ELECTRICAL EQUIPMENT OTHER THAN SPECIFIED IN THIS MANUAL. DO NOT USE A NON-POWERED PROBE-TYPE TESTER.

INSTRUCTION IN THIS MANUAL MUST BE FOLLOWED CAREFULLY, OTHERWISE PERSONAL INJURY MAY RESULT.

When servicing a vehicle equipped with Supplemental Restraint System, pay close attention to all WARNINGS and CAUTIONS.

For detailed explanation about SRS, refer to Restraints section.

2A-10 POWER-ASSISTED STEERING SYSTEM

The steering column has three important features in addition to the steering function:


1. The column is energy absorbing, designed to compress in a front-end collision to minimize the possibility of injury to the driver of the vehicle.
2. The ignition switch and lock are mounted conveniently on the column.
3. With the column mounted lock, the ignition and steering operation can be locked to prevent theft of the vehicle.

The column can be disassembled and reassembled. However, to insure the energy absorbing action, use only the specified screws, bolts and nuts as designated, and tighten them to the specified torque.

Handle the column with care when it is removed from the vehicle. A sharp blow on the end of steering shaft or shift lever, or dropping the assembly could shear or loosen the fasteners that maintain column rigidity.

Power Steering System Test

Test Procedure



C02RW001

Legend

(1) Fluid Reservoir

(2) Power Steering Unit

(3) Power Steering Pump

Test of fluid pressure in the power steering system is performed to determine whether or not the oil pump and power steering unit are functioning normally.

The power steering system test is used to identify and isolate hydraulic circuit difficulties. Prior to performing this test, the following inspections and corrections, if necessary, must be made.

- Inspect pump reservoir for proper fluid level.
- Inspect pump belt for proper tension.
- Inspect pump driver pulley condition.

1. Place a container under the pump to catch the fluid when disconnecting or connecting the hoses.

2. With the engine NOT running, disconnect the pressure hose at the power steering pump and install power steering tester J-29877-A. The gage must be between the shutoff valve and pump. Open the shutoff valve.

3. Check the fluid level. Fill the reservoir with power steering fluid, to the "Full" mark. Start the engine, then turn the steering wheel and momentarily hold it against a stop (right or left). Turn the engine off and check the connections at tester for leakage.

4. Bleed the system. Refer to Bleeding the Power Steering System in this section.
5. Start the engine and check the fluid level. Add power steering fluid if required. When the engine is at normal operating temperature, increase engine speed to 1500 rpm.

CAUTION: Do not leave shutoff valve fully closed for more than 5 seconds, as the pump could become damaged internally.

6. Fully close the shutoff valve. Record the highest pressures.
 - If the pressure recorded is within 9300–9800 kPa (1350–1420 psi), the pump is functioning within its specifications.
 - If the pressure recorded is higher than 9800 kPa (1420 psi), the valve in the pump is defective.
 - If the pressure recorded is lower than 9300 kPa (1350 psi), the valve or the rotating group in the pump is defective.
7. If the pump pressures are within specifications, leave the valve open and turn (or have someone else turn) the steering wheel fully in both directions. Record the highest pressures and compare with the maximum pump pressure recorded in step 6. If this pressure cannot be built in either side of the power steering unit, the power steering unit is leaking internally and must be replaced.
8. Shut the engine off, remove the testing gauge.
9. Reconnect the pressure hose, check the fluid level and make the needed repairs.
10. If the problem still exists, the steering and front suspension must be thoroughly examined.

Maintenance

The hydraulic system should be kept clean and fluid level in the reservoir should be checked at regular intervals and fluid added when required. Refer to Recommended Fluids and Lubricants in General Information section for the type of fluid to be used and the intervals for filling. If the system contains some dirt, flush it as described in this section. If it is exceptionally dirty, the pump must be completely disassembled before further usage. (The steering unit cannot be disassembled.)

All tubes, hoses, and fittings should be inspected for leakage at regular intervals. Fittings must be tight. Make sure the clips, clamps and supporting tubes and hoses are in place and properly secured.

Power steering hoses and lines must not be twisted, kinked or tightly bent. Air in the system will cause spongy action and noisy operation. When a hose is disconnected or when fluid is lost, for any reason, the system must be bled after refilling. Refer to Bleeding the Power Steering System in this section.

- Inspect belt for tightness.
- Inspect pulley for looseness or damage. The pulley should not wobble with the engine running.
- Inspect hoses so they are not touching any other parts of the vehicle.
- Inspect fluid level and fill to the proper level.

Fluid Level

1. Run the engine until the power steering fluid reaches normal operating temperature, about 55°C (130°F), then shut the engine off.
2. Check the level of fluid in the reservoir.
3. If the fluid level is low, add power steering fluid as specified in General Information to the proper level and install the receiver cap.
4. When checking the fluid level after the steering system has been serviced, air must be bled from the system. Refer to Bleeding the Power Steering System in this section.

Bleeding The Power Steering System

When a power steering pump or unit has been installed, or an oil line has been disconnected, the air that has entered the system must be bled out before the vehicle is operated. If air is allowed to remain in the power steering fluid system, noisy and unsatisfactory operation of the system may result.

Bleeding Procedure

When bleeding the system, and any time fluid is added to the power steering system, be sure to use only power steering fluid as specified in General Information.

1. Fill the pump fluid reservoir to the proper level and let the fluid settle for at least two minutes.
2. Start the engine and let it run for a few seconds. Do not turn the steering wheel. Then turn the engine off.
3. Add fluid if necessary.
4. Repeat the above procedure until the fluid level remains constant after running the engine.
5. Raise and support the front end of the vehicle so that the wheels are off the ground.
6. Start the engine. Slowly turn the steering wheel right and left, lightly contacting the wheel stops.
7. Add power steering fluid if necessary.
8. Lower the vehicle, set the steering wheel at the straight forward position after turning it to its full steer positions 2 or 3 times, and stop the engine.
9. Check the fluid level and refill as required.
10. If the fluid is extremely foamy, allow the vehicle to set a few minutes, then repeat the above procedure.

Flushing The Power Steering System


1. Raise and support the front end of the vehicle off the ground until the wheels are free to turn.
2. Remove the fluid return line at the pump inlet connector and plug the connector port on the pump. Position the line toward a large container to catch the draining fluid.
3. While running the engine at idle, fill the reservoir with new power steering fluid. Turn the steering wheel in both directions. Do not contact or hold the steering wheel to the wheel stops. This will cause the pump to go to pressure relief mode, which may cause a sudden fluid overflow at the reservoir.

2A-12 POWER-ASSISTED STEERING SYSTEM

4. Install all the lines and hoses. Fill the system with new power steering fluid and bleed the system as described in Bleeding The Power Steering System. Operate the engine for about 15 minutes.

Remove the pump return line at the pump inlet and plug the connection on the pump. While refilling the reservoir, check the draining fluid for contamination. If foreign material is still evident, replace all lines, disassemble and clean or replace the power steering system components. Do not re-use any drained power steering fluid.

Steering Wheel Free Play Inspection



1. With the tires in the straight-ahead position, check the amount of steering wheel play by turning the wheel in both directions until the tires begin to move.

NOTE: The wheel free play should be checked with the engine running.

Free play: 0 – 30 mm (0 – 1.18 in)

2. Also check the steering wheel for play and looseness in the mount by moving it back and forth and sideways. When test driving, check for hard steering, steering shimmy and tendency to pull to one side.

Front End Alignment Inspection and Adjustment

General Description


“Front End Alignment” refers to the angular relationship between the front wheels, the front suspension attaching parts and the ground.

Proper front end alignment must be maintained in order to insure efficient steering, good directional stability and to prevent abnormal tire wear.

The most important factors of front end alignment are wheel toe-in, wheel camber and axle caster.

Camber:


This illustration shows view from the front of the vehicle.



Camber is the vertical tilting inward or outward of the front wheels. When the wheels tilt outward at the top, the camber is positive (+). When the wheels tilt inward at the top, the camber is negative (-). The amount of tilt measured in degrees from the vertical is called the camber angle (1). If camber is extreme or unequal between the wheels, improper steering and excessive tire wear will result. Negative camber causes wear on the inside of the tire, while positive camber causes wear to the outside.

Caster:


This illustration shows view from the side of the vehicle.



Caster (1) is the vertical tilting of the wheel axis either forward or backward (when viewed from the side of the vehicle). A backward tilt is positive (+) and a forward tilt is negative (-). On the short and long arm type suspension you cannot see a caster angle without a special instrument, but if you look straight down from the top of the upper control arm to the ground, the ball joints do not line up (fore and aft) when a caster angle other than 0 degree is present. With a positive angle, the lower ball joint would be slightly ahead (toward the front of the vehicle) of the upper ball joint center line.

Toe-in:

This illustration shows view from the top of the vehicle.



Toe-in is the measured amount the front wheels are turn in. The actual amount of toe-in is normally a fraction of a degree. Toe-in is measured from the center of the tire treads or from the inside of the tires. The purpose of toe-in is to insure parallel rolling of the front wheels and to offset any small deflections of the wheel support system which occurs when the vehicle is rolling forward. Incorrect toe-in results in excessive toe-in and unstable steering. Toe-in is the last alignment to be set in the front end alignment procedure.

Inspection

Before making any adjustments affecting caster, camber or toe-in, the following front end inspection should be made.



1. Inspect the tires for proper inflation pressure. Refer to Main Data and Specifications in Wheel and Tire System section.
2. Make sure that the vehicle is unladen condition (With no passenger or loading).
3. Make sure that the spare tire is installed at the normal position.
4. Inspect the front wheel bearings for proper adjustment. Refer to Front Hub and Disc Overhaul in Suspension section.
5. Inspect the ball joints and tie rod ends. If excessive looseness is noted, correct before adjusting. Refer to Steering Linkage in this section.
6. Inspect the wheel and tires for run-out. Refer to Wheel Replacement in Wheel and Tire System section.
7. Inspect the trim height. If not within specifications, the correction must be made before adjusting caster.
8. Inspect the steering unit for looseness at the frame.
9. Inspect shock absorbers for leaks or any noticeable noise. Refer to Shock Absorber in Suspension section.
10. Inspect the control arms or stabilizer bar attachment for looseness. Refer to Suspension section .
11. Inspect the front end alignment using alignment equipment. Follow the manufacturer's instructions.
12. Park the vehicle must be on a level surface.

2A-14 POWER-ASSISTED STEERING SYSTEM

Trim Height Adjustment

Adjust the trim height (1) by means of the adjusting bolt on the height control arms.

CAUTION: When adjusting front end alignment, be sure to begin with trim height first, as it may change other adjusted alignments.



1. Check and adjust the tire inflation pressures.
2. Park the vehicle on a level ground and move the front of the vehicle up and down several times to settle the suspension.
3. Make necessary adjustment with the adjusting bolt on the height control arms.



Trim height: 119 ± 5 mm (4.69 ± 0.2 in)

Caster Adjustment

The caster angle can be adjusted by means of the caster shims (1) installed between the chassis frame (2) and fulcrum pins.

Caster angle: $2^{\circ}30' \pm 1^{\circ}$

CAUTION: Left and right side must be equal within $30'$.



NOTE: Difference of the caster shim front/rear thickness should be 3.6 mm (0.142 in) or less. Overall thickness of caster shim and camber shim should be 10.8 mm (0.425 in) or less.

Tighten the fulcrum pin bolt to the specified torque.

Torque: 152 N·m 112 (lb ft)



Camber Adjustment

The camber angle can be adjusted by means of the camber shims (2) installed in position between the chassis frame (1) and fulcrum pins

Camber angle: $0^{\circ} \pm 30'$

King pin inclination: $12^{\circ}30' \pm 30'$

CAUTION: Left and right side must be equal within $30'$.



NOTE: Overall thickness of caster shim and camber shim should be 10.8 mm (0.425 in) or less.

Tighten the fulcrum pin bolt to the specified torque.

Torque: 152 N·m (112 lb ft)


	Position of shims		Camber angle	Caster angle
	Front side	Rear side		
Caster shim	When added	When removed	Decreases	Decreases
	When removed	When added	Increases	Increases
	—	When removed	Unchanged	Decreases
	—	When added	Unchanged	Increases
Camber shim	When added		Decreases	Unchanged
	When removed		Increases	Unchanged

2A-16 POWER-ASSISTED STEERING SYSTEM

Toe-in Adjustment

1. To adjust the toe-in angle, loosen the lock nuts (2) on the tie rod (1) and turn the tie rod. Turn both rods the same amount, to keep the steering wheel centered .

Toe-in: 0 ± 2 mm (0 ± 0.08 in)




2. Tighten the lock nut to the specified torque.

Torque: 98 N·m (72 lb ft)

Main Data and Specifications

General Specification

Caster		2°30' ± 1°
Camber		0° ± 30'
King pin inclination		12°30' ± 30'
Toe-in		0 ± 2 mm (0 ± 0.08 in)
Max. steering angle	inside	32.6° (+0°30' to -2°30')
	outside	31.8°

Torque Specification

E02RX001

Special Tools




ILLUSTRATION	TOOL NO. TOOL NAME
	J-29877-A Tester; Power steering
901RS276	

ILLUSTRATION	TOOL NO. TOOL NAME
	J-39213 Adapter; Power steering tester
901RS276	

Power Steering Unit

Power Steering Unit and Associated Parts



431RW013


Legend

- (1) Bracket
- (2) Transfer Gear Assembly

- (3) Power Steering Unit Assembly
- (4) Crossmember

Removal


1. Remove the stone guard.
2. Remove the transfer gear assembly.
Make a setting mark across the coupling flange and steering unit to ensure reassembly of the parts in the original position.
3. Drain power steering fluid.
4. Remove the tie rod end assembly from knuckle.
Use tie rod end remover J-29107.



433RW002

5. Disconnect the feed line and return line from steering unit.
Remove the clips on the crossmember and frame.
Wire the power steering line to frame.

NOTE: Take care to prevent foreign matter from entry when disconnect the power steering line.



4×4 model:

1. Remove the torsion bar. Refer to Front Suspension in Suspension section.
2. Remove the lower control arm bolt (Frame side). Refer to Front Suspension in Suspension section.
3. Remove the crossmember fixing bolt.
4. Remove the power steering unit with the crossmember.
5. Remove the power steering unit.

4×2 model:

1. Remove the power steering unit from the crossmember.


Installation (4×2 Model)

1. Install power steering unit to crossmember.
Tighten fixing bolt to specified torque.
Torque: 116 N·m (85 lb ft)
2. Connect the feed line and return line.
Torque: 25 N·m (18 lb ft)
3. Install tie-rod end assembly to knuckle.
Torque: 118 N·m (87 lb ft)
4. Install transfer gear assembly.
Align the setting marks made at removal.
Torque: 31 N·m (23 lb ft)
5. Install the stone guard.
6. Bleed the system.
Refer to Bleeding the Power Steering System in this section.

Installation (4×4 Model)

1. Install power steering unit to crossmember.
Tighten fixing bolt to specified torque.
Torque: 116 N·m (85 lb ft)
2. Install power steering unit with crossmember to frame.
Tighten crossmember mounting bolt to specified torque.
Torque: 190 N·m (140 lb ft)
3. Install lower control arm bolt.
Refer to Front Suspension in Suspension section.
4. Install torsion bar.
Refer to Front Suspension in Suspension section.
5. Connect the feed line and return line.
Torque: 25 N·m (18 lb ft)
6. Install tie-rod end assembly to knuckle.
Torque: 118 N·m (87 lb ft)
7. Install transfer gear assembly.
Align the setting marks made at removal.
Torque: 31 N·m (23 lb ft)
8. Install the stone guard.
9. Bleed the system.
Refer to Bleeding the Power Steering System in this section.

Power Steering Unit Disassembled View



440RW003

Legend

- | | |
|-----------------|----------------------------|
| (1) Tie-rod End | (6) Tie-rod Assembly |
| (2) Lock Nut | (7) Tab Washer |
| (3) Clip | (8) Oil Line |
| (4) Bellows | (9) Valve Housing Assembly |
| (5) Band | (10) Mounting Rubber |
| | (11) Dust Cover |

Disassembly

NOTE: The valve housing is made of aluminum and care should be exercised when clamping in a vise, etc. to prevent distortion or damage.

- Loosen lock nut and remove tie-rod end.
- Remove clip and band, then remove bellows.
- Remove tie-rod assembly.
To remove, move the boot toward the tie-rod end, then remove tab washer.
- Remove oil line, mounting rubber and dust cover.

Inspection and Repair

Inspect the following parts for wear, damage or any abnormal conditions.

Tie-rod End

If looseness or play is found when checked by moving the end of ball joint at tie-rod end, replace tie-rod end.

Tie-rod Assembly

If the resistance is insufficient or play is felt when checked by moving the ball on the tie-rod, replace the tie-rod assembly.

Rubber Parts

If wear or damage is found through inspection, replace with new ones.

Reassembly

- Install mounting rubber and dust cover (If removed).
- Install oil line.

Torque: 13 N·m (113 lb in)

- Install tie-rod assembly with tab washer.

Apply grease to ball joint, install tie-rod and tab washer, then tighten to specified torque.

Torque: 83 N·m (61 lb ft)

After tightening, bend tab washer against width across flat of inner ball joint.

4. Apply a thin coat of grease to the shaft for smooth installation. Then install bellows.
5. Install band and clip.
6. Install tie-rod end and tighten lock nut.


Torque: 98 N·m (72 lb ft)

Main Data and Specifications

General Specifications


Power Steering unit	Type	Rack and pinion
	Rack stroke	152 mm (5.98 in)
	Lock to lock	3.64

Torque Specifications



E02RX002


Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
	J-29107 Tie rod end remover

901RS279

Power Steering Pump

Power Steering Pump and Associated Parts



Legend

- (1) Pump Assembly
- (2) Hose, Suction

- (3) Hose, Flexible
- (4) Bolt


Removal

1. Remove the drive belt.
2. Place a drain pan below the pump.
3. Disconnect the suction hose.
4. Disconnect the flexible hose.
5. Remove the power steering fixing bolt and remove the pump assembly.

Installation

1. Install the pump assembly to the pump bracket, tighten the fixing bolt to the specified torque.
Torque: 46 N·m (34 lb ft)
2. Install the flexible hose.
Tighten the eye bolt to specified torque.
Torque: 54 N·m (40 lb ft)
3. Install the drive belt.
4. Connect the suction hose, then fill and bleed system.
Refer to Bleeding the Power Steering System in this section.

Power Steering Pump Disassembled View



442RX001

Legend

- | | |
|---------------------|-------------------------------|
| (1) Bolt | (12) Cam |
| (2) Suction Pipe | (13) Pump Cartridge Assembly |
| (3) O-ring | (14) O-ring |
| (4) Shaft Assembly | (15) Snap Ring |
| (5) Oil Seal | (16) Rear Housing |
| (6) Front Housing | (17) Bolt |
| (7) O-ring | (18) Spring |
| (8) O-ring | (19) Relief Valve |
| (9) Side Plate | (20) O-ring |
| (10) Rotor and Vane | (21) Connector |
| (11) Pin | (22) Pressure Switch Assembly |

Disassembly

1. Clean the oil pump with solvent (plug the discharge and suction ports to prevent the entry of solvent). Be careful not to expose the oil seal of shaft assembly to solvent.
2. Remove the bolt, suction pipe and O-ring.
3. Remove the connector, O-ring, relief valve and spring.
4. Remove the pressure switch assembly.

5. Remove the bolt, rear housing and O-ring.

6. Remove the snap ring.
7. Remove the shaft assembly.
8. Remove the oil seal.


CAUTION: When removing the oil seal, be careful not to damage the housing.

9. Remove the pump cartridge assembly from the front housing.
10. Remove two O-rings.

Inspection and Repair


Make all necessary adjustments, repairs, and part replacements if wear, damage, or other problems are discovered during inspection.

Rotor



Check that the groove in the vane is free from excessive wear and that the vane slides smoothly. When part replacement becomes necessary, the pump cartridge should be replaced as a subassembly.

Vane



Sliding faces of the vane should be free from wear. (Particularly the curved face at the tip that contact with the cam should be free from wear and distortion). When part replacement becomes necessary, the pump cartridge should be replaced as a subassembly.

Cam

The inner face of the arm should have a uniform contact pattern without a sign of step wear. When part replacement becomes necessary, the pump cartridge should be replaced as a subassembly.

Side Plate

The sliding faces of parts must be free from step wear (more than 0.01 mm), which can be felt by the finger nail. The parts with minor scores may be reused after lapping the face.

Relief Valve

The sliding face of the valve must be free from burrs and damage. The parts with minor scores may be reused after smoothing with emery cloth (#800 or finer).

Shaft

Oil seal sliding faces must be free from a step wear which can be felt by the finger nail. Bushing fitting face must be free from damage and wear.

O-ring, Oil Seal, Snap Ring

Be sure to discard used parts, and always use new parts for installation. Prior to installation, lubricate all seals and rings with power steering fluid.

Pressure Switch

Check the switch operation as follows:

With engine idling and A/C on, turn the steering wheel fully to the left; compressor should interrupt and engine idle speed will increase. Shut off A/C and again turn steering fully to the left; engine idle will increase. If system fails to function properly, disconnect connector at the pressure switch and repeat system check while testing continuity across disconnected SW connector.


Reassembly

1. Install oil seal to front housing. Be sure to discard used oil seal, and always use new parts for installation.

CAUTION: When installing the oil seal, be careful not to damage the oil seal contacting surface of the housing.

2. Install shaft assembly.

3. Install the vanes to roter with curved face in contact with the inner wall of cam.



442RS005

4. Install roter and vanes to cam.
5. Install pin to front housing.
6. Install two new O-rings to front housing. Be sure to discard used O-ring.
7. Install side plate.

CAUTION: When installing side plate, be careful not to damage its inner surface. Damaged side plate may cause poor pump performance, pump seizure or oil leakage.

8. Install pump cartridge assembly to front housing.
9. Install snap ring to shaft end.
10. Install rear housing with a new O-ring. Be sure to discard used O-ring. Then install bolt and tighten it to specified torque.

Torque: 24 N·m (17 lb ft)

11. Install suction pipe with a new O-ring. Be sure to discard used O-ring. Then install bolt and tighten it to specified torque.

Torque: 10 N·m (87 lb in)

12. Install relief valve and spring.
13. Install connector with a new O-ring. Be sure to discard used O-ring. Tighten the connector to specified torque.

Torque: 59 N·m (43 lb ft)

14. Install pressure switch assembly and tighten it to specified torque.

Torque: 18 N·m (13 lb ft)


2A-26 POWER-ASSISTED STEERING SYSTEM

Main Data and Specifications

General Specifications


Oil pump	Type	Vane
	Operating fluid	ATF DEXRON®-II-E

Torque Specifications



Transfer Gear Assembly

Transfer Gear Assembly and Associated Parts



441RW001

Legend

- | | |
|---|--|
| (1) Transfer Gear Assembly | (3) Fixing Bolt Nut |
| (2) Bolt, Universal Joint (Steering Shaft Side) | (4) Shim |
| | (5) Bolt, Universal Joint (Steering Unit Side) |

Removal

1. Remove universal joint bolt (steering shaft side).
2. Remove universal joint bolt (steering unit side).
3. Loosen fixing bolt and nut and remove transfer gear assembly with shim.

Inspection and Repair

The transfer gear assembly cannot be disassembled. If damage or abnormal condition are found, replace to new ones.

Installation

1. Install transfer gear assembly with shim and tighten bolt and nut to the specified torque.

Torque: 54 N·m (40 lb ft)

2. Connect universal joint (both side) and tighten the bolt to the specified torque.

Torque: 31 N·m (23 lb ft)

Supplemental Restraint System Steering Wheel & Column

Service Precaution

This steering wheel and column repair section covers the Supplemental Restraint System (SRS) steering column. The following repair procedures are specific to SRS components. When servicing a vehicle equipped with Supplemental Restraint System, pay close attention to all WARNINGS and CAUTIONS.

For detailed explanation about SRS, refer to Restraints section.

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

SAFE HANDLING OF INFLATOR MODULES REQUIRES FOLLOWING THE PROCEDURES DESCRIBED BELOW FOR BOTH LIVE AND DEPLOYED MODULES.

SAFETY PRECAUTIONS MUST BE FOLLOWED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY (AIR BAG). AFTER DEPLOYMENT, THE AIR BAG ASSEMBLY (AIR BAG) SURFACE MAY CONTAIN A SMALL AMOUNT OF SODIUM HYDROXIDE, A BY-PRODUCT OF THE DEPLOYMENT REACTION, THAT IS IRRITATING TO THE SKIN AND EYES. MOST OF THE POWDER ON THE AIR BAG ASSEMBLY (AIR BAG) IS HARMLESS. AS A PRECAUTION, WEAR GLOVES AND SAFETY GLASSES WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY, AND WASH YOUR HANDS WITH MILD SOAP AND WATER AFTERWARDS.

WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG AND TRIM COVER ARE POINTED AWAY FROM YOU. NEVER CARRY AN AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF MODULE. IN THE CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. WHEN PLACING A LIVE AIR BAG ASSEMBLY ON A BENCH OR OTHER SURFACE, ALWAYS FACE THE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE.

NEVER REST A STEERING COLUMN ASSEMBLY ON THE STEERING WHEEL WITH THE AIR BAG ASSEMBLY FACE DOWN AND COLUMN VERTICAL. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG ASSEMBLY TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY COULD RESULT.

TO AVOID DEPLOYMENT WHEN TROUBLESHOOTING THE SRS SYSTEM, DO NOT USE ELECTRICAL TEST EQUIPMENT, SUCH AS BATTERY-POWERED OR A/C-POWERED VOLT-METER, OHMMETER, ETC., OR ANY TYPE OF ELECTRICAL EQUIPMENT OTHER THAN SPECIFIED IN THIS MANUAL. DO NOT USE A NON-POWERED PROBE-TYPE TESTER.

INSTRUCTIONS IN THIS MANUAL MUST BE FOLLOWED CAREFULLY, OTHERWISE PERSONAL INJURY MAY RESULT.

SRS Connectors


CAUTION: The special tellow color connectors are used for supplemental restraint system-air bag circuit.

When removing the cable harness, do not pull the cables. Otherwise, cable disconnection may occur.

When connect the SRS connector, insert the connector completely. Imperfect locking may cause malfunction of SRS circuit.


Removal

To remove the connector, hold the cover insulator(1) and pull it. The cover insulator slides and lock will be released. Do not hold the socket insulator(2).




Installation

To install the connector, hold the socket insulator(1) and insert it. The cover insulator slides and connector will be locked. Do not hold the cover insulator(2).



Inflator Module

Inflator Module and Associated Parts



827RW071


Legend

- (1) Horn Lead
- (2) SRS Connector

- (3) Fixing Bolt
- (4) Inflator Module


Removal

1. Turn the steering wheel so that the vehicle's wheels are pointing straight ahead.
2. Turn the ignition switch to "LOCK".
3. Disconnect the battery "-" terminal cable, and wait at least 5 minutes.
4. Disconnect the yellow 2-way SRS connector located under the steering column.
5. Loosen the inflator module fixing bolt from behind the steering wheel assembly using a TORX® driver or equivalent until the inflator module can be released from steering assembly .



827RW070

6. Disconnect the yellow 2-way SRS connector and horn lead located behind the inflator module.




827RW073

7. Remove inflator module.

Inspection and Repair

WARNING: THE INFLATOR MODULE SHOULD ALWAYS BE CARRIED WITH THE URETHANE COVER AWAY FROM YOUR BODY AND SHOULD ALWAYS BE LAID ON A FLAT SURFACE WITH THE URETHANE SIDE UP. THIS IS NECESSARY BECAUSE A FREE SPACE IS PROVIDED TO ALLOW THE AIR CUSHION TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY MAY RESULT .



827RW072

The inflator module consists of a cover, air bag, inflator, and retainer. Inspect the inflator module mainly for the following:

- Check for holes, cracks, severe blemishes and deformation on the cover.
- Check that the retainer is not deformed.

- Check for defects such as damage and breakage in the lead wire for the igniter.

If an abnormality is found as the result of the inspection, replace the inflator module with a new one.

Installation

1. Install inflator module.
2. Support the module and carefully connect the module connector and horn lead.

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of inflator to prevent lead wire from being pinched.


3. Tighten bolts to specified torque.

Torque: 9 N·m (78 lb in)

4. Connect the yellow 2-way SRS connector located under the steering column.
5. Connect the battery “-” terminal cable.
6. Set ignition to “ON” while watching warning light. Light should flash 7 times and then go off. If lamp does not operate correctly, refer to Restraints section.

Steering Wheel

Steering Wheel and Associated Parts



827RW069

Legend

- (1) Horn Lead
- (2) SRS Connector


- (3) Steering Wheel
- (4) Steering Wheel Fixing Nut
- (5) Inflator Module

CAUTION: Once the steering column is removed from the vehicle, the column is extremely susceptible to damage. Dropping the column assembly on its end could collapse the steering shaft or loosen the slide block which maintains column rigidity. Leaning on the column assembly could cause the jacket to bend or deform. Any of the above damage could impair the column's collapsible design. If it is necessary to remove the steering wheel, use only the specified steering wheel puller. Under no conditions should the end of the shaft be hammered upon, as hammering could loosen slide block which maintains column rigidity.

Removal

1. Turn the steering wheel so that the vehicle's wheels are pointing straight ahead.
2. Turn the ignition switch to "LOCK".
3. Disconnect the battery "-" terminal cable, and wait at least 5 minutes.
4. Disconnect the yellow 2-way SRS connector located under the steering column.


5. Loosen the inflator module fixing bolt from behind the steering wheel assembly using a TORX® driver or equivalent until the inflator module can be released from steering assembly.



827RW070

6. Disconnect the yellow 2-way SRS connector located behind the inflator module.


WARNING: THE INFLATOR MODULE SHOULD ALWAYS BE CARRIED WITH THE URETHANE COVER AWAY FROM YOUR BODY AND SHOULD ALWAYS BE LAID ON A FLAT SURFACE WITH THE URETHANE SIDE UP. THIS IS NECESSARY BECAUSE A FREE SPACE IS PROVIDED TO ALLOW THE AIR CUSHION TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY MAY RESULT.



827RW073

7. Disconnect horn lead.
8. Remove steering wheel fixing nut.


9. Apply a setting mark (1) across the steering wheel and shaft so parts can be reassembled in their original position, then remove steering wheel.



430RW021

10. Move the front wheels to the straight ahead position, then use steering wheel remover J-29752 to remove the steering wheel.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.



430RX005

Installation

1. Install steering wheel by aligning the setting marks made when removing.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.

2. Tighten the steering wheel fixing nut to the specified torque.

Torque: 34 N·m (25 lb ft)

3. Connect horn lead.
4. Support the module and carefully connect the SRS connector.

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of inflator to prevent lead wire from being pinches.


5. Tighten bolts to specified torque.

Torque: 9 N·m (78 lb in)

6. Connect the yellow 2-way SRS connector located under the steering column.
7. Connect the battery “-” terminal cable.
8. Turn the ignition switch to “ON” while watching warning light. Light should flash 7 times and then go off. If lamp does not operate correctly, refer to Restraints section.

Combination Switch

Combination Switch and Associated Parts



431RX006

Legend

- | | |
|---------------------------|--|
| (1) Steering Column Cover | (4) Combination Switch and SRS Coil Assembly |
| (2) Steering Wheel | (5) Instrument Panel Lower Cover |
| (3) Inflator Module | (6) Driver Knee Bolster (reinforcement) |

Removal


1. Turn the steering wheel so that the vehicle's wheels are pointing straight ahead.
2. Turn the ignition switch to "LOCK".
3. Disconnect the battery "-" terminal cable, and wait at least 5 minutes.
4. Disconnect the yellow 2-way SRS connector located under the steering column.

CAUTION: The wheels of the vehicle must be straight ahead and the steering column in the "LOCK" position before disconnecting the steering wheel. Failure to do so will cause the coil assembly to become uncentered which will cause damage to the coil assembly.


5. Remove the engine hood opening lever, then remove instrument panel lower cover.
6. Remove the driver knee bolster (reinforcement).

2A-36 POWER-ASSISTED STEERING SYSTEM

7. Loosen the inflator module fixing bolt from behind the steering wheel assembly using a TORX® driver or equivalent until the inflator module can be released from steering assembly. Disconnect the yellow 2-way SRS connector and horn lead located behind the inflator module, then remove inflator module.




827RW070




827RW073

WARNING: THE INFLATOR MODULE SHOULD ALWAYS BE CARRIED WITH THE URETHANE COVER AWAY FROM YOUR BODY AND SHOULD ALWAYS BE LAID ON A FLAT SURFACE WITH THE URETHANE SIDE UP. THIS IS NECESSARY BECAUSE A FREE SPACE IS PROVIDED TO ALLOW THE AIR CUSHION TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY MAY RESULT.




827RW072

8. Apply a setting mark (1) across the steering wheel and shaft so parts can be reassembled in their original position. Move the front wheels to the straight ahead position, then use steering wheel remover J-29752 to remove the steering wheel.



430RW021

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.




430RX005

9. Remove steering column cover.

10. Disconnect the wiring harness connectors located under the steering column then remove combination switch and SRS coil assembly.

NOTE: The SRS coil is a part of the combination switch assembly, which can not be replaced separately. Therefore, be sure not to remove the SRS coil from the combination switch assembly.




825RW288

Installation

1. Install combination switch and SRS coil assembly. After installation of combination switch assembly, connect the combination switch wiring harness connector and the SRS 2-way connector located under the steering column. Then turn the SRS coil counter clockwise to full, return about 3 turns and align the neutral mark.


CAUTION: When turning the SRS coil counter clockwise to full, stop turning if resistance is felt. Forced further turning may damage to the cable in the SRS coil.



825RW016

2A-38 POWER-ASSISTED STEERING SYSTEM

2. When installing the steering column cover, be sure to route each wire harness as illustrated so that the harnesses do not catch on any moving parts.



Legend

- (1) Steering Column Cover
- (2) Starter Switch Harness
- (3) Combination Switch Harness
- (4) Inflator Module Harness

3. Align the setting marks made when removing then install steering wheel.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.

4. Tighten the steering wheel fixing nut to the specified torque.

Torque: 34 N·m (25 lb ft)

5. Support the inflator module and carefully connect the SRS connector and horn lead.

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of inflator to prevent lead wire from being pinched.


6. Tighten bolts to specified torque.

Torque: 9 N·m (78 lb in)

7. Install driver knee bolster (reinforcement).
8. Install instrument panel lower cover then Install the engine hood opening lever.
9. Connect the SRS connector.
10. Connect the battery “-” terminal cable.
11. Turn the ignition switch to “ON” while watching warning light and check the light should flash 7 times and then go off. If lamp does not operate correctly, refer to Restraints section.

Lock Cylinder

Lock Cylinder and Associated Parts



431RX005

Legend

- | | |
|--|---|
| (1) Inflator Module | (6) Cushion Rubber |
| (2) Steering Wheel | (7) Lock Cylinder Assembly |
| (3) Steering Column Cover | (8) Instrument Panel Lower Cover |
| (4) Combination Switch and SRS Coil Assembly | (9) Driver Knee Bolster (reinforcement) |
| (5) Snap Ring | (10) Shift Lock Cable (for A/T) |

Removal


1. Turn the steering wheel so that the vehicle's wheels are pointing straight ahead.
2. Turn the ignition switch to "LOCK".
3. Disconnect the battery "-" terminal cable, and wait at least 5 minutes.
4. Disconnect the yellow 2-way SRS connector located under the steering column.

CAUTION: The wheels of the vehicle must be straight ahead and the steering column in the "LOCK" position before disconnecting the steering wheel. Failure to do so will cause the coil assembly to become uncentered which will cause damage to the coil assembly.

5. Remove the engine hood opening lever and steering lower cover.
6. Remove driver knee bolster (reinforcement).


2A-40 POWER-ASSISTED STEERING SYSTEM

7. Loosen the inflator module fixing bolt from behind the steering wheel assembly using a TORX® driver or equivalent until the inflator module can be released from steering assembly.




827RW070

8. Disconnect the yellow 2-way SRS connector and horn lead located behind the inflator module.



827RW073


9. Apply a setting mark (1) across the steering wheel and shaft so parts can be reassembled in their original position.



430RW021


10. Move the front wheels to the straight ahead position, then use steering wheel remover J-29752 to remove the steering wheel.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.



430RX005

WARNING: THE INFLATOR MODULE SHOULD ALWAYS BE CARRIED WITH THE URETHANE COVER AWAY FROM YOUR BODY AND SHOULD ALWAYS BE LAID ON A FLAT SURFACE WITH THE URETHANE SIDE UP. THIS IS NECESSARY BECAUSE A FREE SPACE IS PROVIDED TO ALLOW THE AIR CUSHION TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY MAY RESULT.




11. Remove steering column cover.

12. Disconnect the wiring harness connectors located under the steering column.

13. Remove the combination switch assembly with SRS coil.

NOTE: The SRS coil is a part of the combination switch assembly, which can not be replaced separately. Therefore, be sure not to remove the SRS coil from the combination switch assembly.



825RW288

14. Remove snap ring.

15. Remove cushion rubber.

16. Remove shift lock cable (for A/T).

17. Disconnect the starter switch harness connector located under the steering column then remove lock cylinder assembly.

Installation

1. Install lock cylinder assembly.

2. Install shift lock cable (for A/T).

3. Install cushion rubber.


4. Install snap ring.

5. Install Combination switch and SRS coil assembly. After installation of combination switch assembly, connect the combination switch wiring harness connector and the SRS 2-way connector located under the steering column.

2A-42 POWER-ASSISTED STEERING SYSTEM


6. Turn the SRS coil counter clockwise to full, return about 3 turns and align the neutral mark.

CAUTION: When turning the SRS coil counter clockwise to full, stop turning if resistance is felt. Forced further turning may damage the cable in the SRS coil.



825RW016

7. When installing the steering column cover, be sure to wire (through each harness) as illustrated so that the harnesses starter switch, combination switch and SRS coil may not catch wiring.



825RW017

Legend

- (1) Steering Column Cover
- (2) Starter Switch Harness
- (3) Combination Switch Harness
- (4) Inflator Module Harness

8. Install steering wheel by aligning the setting marks made during removal.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.

9. Tighten the steering wheel fixing nut to the specified torque.

Torque: 34 N·m (25 lb ft)

10. Support inflator module and carefully connect the SRS connector and horn lead, then install inflator module.

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of inflator to prevent lead wire from being pinched.

11. Tighten fixing bolts to specified torque.

Torque: 9 N·m (78 lb in)

12. Install driver knee bolster (reinforcement).
13. Install instrument panel lower cover, then install the engine hood opening lever.
14. Connect the yellow 2-way SRS connector located under the steering column.
15. Connect the battery “-” terminal cable.


System Inspection

Turn the ignition switch to “ON” while watching warning light.

The light should flash 7 times and then go off. If lamp does not operate correctly, refer to Restraints section.

Steering Column

Steering Column and Associated Parts



431RX004

Legend

- | | |
|--|--|
| (1) Inflator Module | (7) Lock Cylinder Assembly |
| (2) Steering Wheel | (8) Shift Lock Cable (For A/T) |
| (3) Steering Column Cover | (9) Steering Column Assembly |
| (4) Combination Switch and SRS Coil Assembly | (10) Second Steering Shaft |
| (5) Snap Ring | (11) Instrument Panel Lower Cover |
| (6) Cushion Rubber | (12) Driver Knee Bolster (reinforcement) |

Removal


1. Turn the steering wheel so that the vehicle's wheels are pointing straight ahead.
2. Turn the ignition switch to "LOCK".
3. Disconnect the battery "-" terminal cable, and wait at least 5 minutes.

4. Disconnect the yellow 2-way SRS connector located under the steering column.

CAUTION: The wheel of the vehicle must be straight ahead and the steering column in the "LOCK" position before disconnecting the steering column from the steering gear. Failure to do so will cause the SRS coil assembly to become uncentered which will cause damage to the SRS coil assembly.


2A-44 POWER-ASSISTED STEERING SYSTEM

5. Remove the engine hood opening lever, then remove instrument panel lower cover.
6. Remove driver knee bolster (reinforcement).
7. Loosen the inflator module fixing bolt from behind the steering wheel assembly using a TORX® driver or equivalent until the inflator module can be released from steering assembly.





8. Disconnect the yellow 2-way SRS connector and horn lead located behind the inflator module.
9. Remove inflator module.

WARNING: THE INFLATOR MODULE SHOULD ALWAYS BE CARRIED WITH THE URETHANE COVER AWAY FROM YOUR BODY AND SHOULD ALWAYS BE LAID ON A FLAT SURFACE WITH THE URETHANE SIDE UP. THIS IS NECESSARY BECAUSE A FREE SPACE IS PROVIDED TO ALLOW THE AIR CUSHION TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY MAY RESULT.



10. Apply a setting mark (1) across the steering wheel and shaft so parts can be reassembled in their original position. Move the front wheels to the straight ahead position, then use steering wheel remover J-29752 to remove the steering wheel.






430RX005

11. Remove steering column cover.
12. Disconnect the wiring harness connectors located under the steering column.
13. Remove the combination switch assembly with SRS coil.


NOTE: SRS coil is a part of combination switch assembly, which can not be replaced singly. Therefore, be sure not to remove the SRS coil from the combination switch assembly.

18. Apply a setting mark (1) across the universal joint and second steering shaft to reassemble the parts in their original position, then remove steering column assembly and second shaft.

NOTE: A setting mark can be easily made if the shaft is withdrawn a little by loosening the steering shaft universal joint.



431RW009



825RW288

14. Remove snap ring.
15. Remove cushion rubber.
16. Remove shift lock cable (For A/T).
17. Disconnect the starter switch harness connector located under the steering column, then remove lock cylinder assembly.


2A-46 POWER-ASSISTED STEERING SYSTEM

Inspection


If the abnormal conditions are found through inspection, replace the steering column assembly.

Column Capsule

Check capsules on steering column bracket assembly; all must be securely seated in bracket slots and checked for any loose conditions when pushed or pulled by hand.




Check clearance between capsule and bracket. It must be within 1mm (0.039 in).



Column Tube

Check for collapses by measuring the distance as shown in the figure.

Standard distance: 162.2-165.8 mm (6.386-6.528 in)




431RW032

Column Universal Joint for Tilt Mechanism

If the resistance is felt when checked by rotate the joint, replace the steering column assembly.

Sheared Injected Plastic Pin

Check the sheared injected plastic pins for any loose conditions or damage.




431RW033

Shaft Length

Check the shaft length from the upper end of the slide joint to the end of the shaft. If column length is not in specifications, steering column should be replaced.

Standard length: 291.7-295.7 mm (11.484-11.642 in)



431RW034


Shaft Universal Joint (Lower End)

If the resistance is felt when checked by rotate the joint, replace the steering column assembly.

Shaft Bellows Pipe

Check the shaft bellows pipe for bend by using straight edge. Measure the clearance between the bellows pipe and the straight edge (at center of the bellows pipe).

Standard: Less than 1mm (0.039 in)



431RW035

Tilt Mechanism

Tilt mechanism should moves smoothly.

While locked the tilt mechanism, be sure the steering column latch securely by pushing the steering wheel upward and downward.

Installation

1. Install steering column assembly and second steering shaft.
2. Align the setting marks on the universal joint and second steering shaft made during removal.
3. Tighten the steering column fixing bolt (dash panel) to the specified torque.

Torque: 20 N·m (14 lb ft)

4. Tighten the steering column fixing nuts (cross beam) to the specified torque.

Torque: 20 N·m (14 lb ft)


5. Tighten the universal joint to the specified torque.

Torque: 31 N·m (23 lb ft)


6. Install lock cylinder assembly.
7. Install shift lock cable (For A/T).
8. Install cushion rubber.
9. Install snap ring.
10. Install combination switch and SRS coil assembly.
After installation of combination switch assembly, connect the combination switch wiring harness connector and the SRS 2-way connector located under the steering column.
11. Turn the SRS coil counter clockwise to full, return about 3 turns and align the neutral mark.

2A-48 POWER-ASSISTED STEERING SYSTEM

CAUTION: When turning the SRS coil counter clockwise to full, stop turning if resistance is felt. Forced further turning may damage to the cable in the SRS coil.



12. When installing the steering column cover, be sure to route each wire harness as illustrated so that the harnesses do not catch any moving parts.



Legend

- (1) Steering Column Cover
- (2) Starter Switch Harness
- (3) Combination Switch Harness
- (4) Inflator Module Harness

13. Install steering wheel and align the setting marks made when removing.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.

14. Tighten the steering wheel fixing nut to the specified torque.

Torque: 34 N·m (25 lb ft)

15. Support the module and carefully connect the module connector and horn lead, then install inflator module.

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of inflator to prevent lead wire from being pinched.

16. Tighten bolts to specified torque.

Torque: 9 N·m (78 lb in)

17. Install driver knee bolster (reinforcement).

18. Install instrument panel lower cover.

19. Install the engine hood opening lever.

20. Connect the yellow 2-way SRS connector and horn lead located under the steering column.

21. Connect the battery “-” terminal cable.

System Inspection


Turn the ignition switch to “ON” while watching warning light.

The light should flash 7 times and then go off. If lamp does not operate correctly, refer to Restraints section.

Supplemental Restraint System Steering Wheel & Column and Associated Parts


Main Data and Specifications

Torque Specifications



E02RX003

Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
	<p data-bbox="480 1698 693 1732">J-29752 Steering wheel remover</p>

RODEO

SUSPENSION

CONTENTS

Front Suspension	3C-1
Rear Suspension	3D-1
Wheel and Tire System	3E-1

FRONT SUSPENSION

CONTENTS

Service Precaution	3C-1	Upper Control Arm	3C-13
General Description	3C-2	Upper Control Arm and Associated Parts .	3C-13
Diagnosis	3C-2	Removal	3C-13
Shock Absorber	3C-5	Inspection and Repair	3C-14
Shock Absorber and Associated Parts	3C-5	Installation	3C-14
Removal	3C-5	Lower Control Arm	3C-16
Inspection and Repair	3C-5	Lower Control Arm and Associated Parts .	3C-16
Installation	3C-5	Removal	3C-16
Stabilizer Bar	3C-6	Inspection and Repair	3C-17
Stabilizer Bar and Associated Parts	3C-6	Installation	3C-18
Removal	3C-6	Upper Ball Joint	3C-19
Inspection and Repair	3C-6	Upper Ball Joint and Associated Parts	3C-19
Installation	3C-6	Removal	3C-19
Torsion Bar	3C-7	Inspection and Repair	3C-20
Torsion Bar and Associated Parts	3C-7	Installation	3C-20
Removal	3C-7	Lower Ball Joint	3C-21
Inspection and Repair	3C-8	Lower Ball Joint and Associated Parts	3C-21
Installation	3C-8	Removal	3C-21
Knuckle	3C-10	Inspection and Repair	3C-22
Knuckle and Associated Parts	3C-10	Installation	3C-22
Removal	3C-10	Main Data and Specifications	3C-23
Inspection and Repair	3C-11	Special Tools	3C-24
Installation	3C-11		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

The front suspension is designed to allow each wheel to compensate for changes in the road surface level without greatly affecting the opposite wheel. Each wheel is independently connected to the frame by a steering knuckle, ball joint assemblies, and upper and lower control arms. The front wheels are held in proper relationship to each other by two tie-rods which are connected to steering arms on the knuckles, and to a steering unit.

All models have a front suspension system consisting of control arms, stabilizer bar, shock absorber and a torsion bar. The front end of the torsion bar is attached to the lower control arm. The rear of the torsion bar is mounted into a height control arm at the crossmember. Vehicle trim height is controlled by adjusting this arm.

Shock absorbers are mounted between the brackets on the frame and the lower control arms. The lower portion of

each shock absorber is attached to the lower control arm. The upper portion of each shock absorber extends through a frame bracket and is secured with two rubber bushings, two retainers and a nut.

Ball joint assemblies are bolted to the outer end of the upper and lower control arm and are attached to the steering knuckle.

The inner ends of the upper control arm have pressed in bushings. Bolts, passing through the bushing, attach the control arm to the frame. The inner ends of the lower control arm are attached to the frame by bolts passing through the bushings.

Side roll of the front suspension is controlled by a spring steel stabilizer bar. It is mounted in rubber bushings, which are held to the frame by brackets. The ends of the stabilizer bar are connected to the lower control arms by links.

Diagnosis

Condition	Possible cause	Correction
Vehicle Pulls	Mismatched or uneven tires.	Replace tire.
	Tires not adequately inflated.	Adjust tire pressure.
	Broken or sagging springs.	Replace spring.
	Radial tire lateral force.	Replace tire.
	Improper wheel alignment.	Adjust wheel alignment.
	Brake dragging in one wheel.	Repair brake.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension part(s).
	Faulty shock absorbers.	Replace shock absorber.
	Parts in power steering valve defective.	Replace power steering unit.
Abnormal or Excessive Tire Wear	Sagging or broken spring.	Replace spring.
	Tire out of balance.	Balance or replace tire.
	Improper wheel alignment.	Check front end alignment.
	Faulty shock absorber.	Replace shock absorber.
	Hard driving.	Replace tire.
	Overloaded vehicle.	Replace tire and reduce load.
	Tires not rotated periodically.	Replace or rotate tire.
	Worn or loose road wheel bearings.	Replace wheel bearing.
	Wobbly wheel or tires.	Replace wheel or tire.
	Tires not adequately inflated.	Adjust the pressure.
Wheel Hop	Blister or bump on tire.	Replace tire.
	Improper shock absorber operation.	Replace shock absorber.


Condition	Possible cause	Correction
Shimmy, Shake or Vibration	Tire or wheel out of balance.	Balance wheels or replace tire/or wheel.
	Loose wheel bearings.	Replace wheel bearing.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
	Excessive wheel runout.	Repair or replace wheel and/or tire.
	Blister or bump on tire.	Replace tire.
	Excessive loaded radial runout of tire/wheel assembly.	Replace tire or wheel.
	Improper wheel alignment.	Check wheel alignment.
	Loose or worn steering linkage.	Tighten or replace steering linkage.
	Loose steering unit.	Tighten steering unit.
	Tires not adequately inflated.	Adjust tire pressure.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension parts.
	Faulty shock absorber.	Replace shock absorber.
	Hub bearing preload misadjustment.	Adjust preload.
	Parts in power steering valve defective.	Replace power steering unit.
Hard Steering	Bind in steering linkage ball studs, upper or lower ball joint.	Replace ball joint.
	Improper wheel alignment.	Check wheel alignment.
	Tire not adequately inflated.	Inflate tires to proper pressure.
	Bind in steering column or shaft.	Repair or replace.
	Improper power steering system operation.	Repair or replace. Refer to Steering section.
Too Much Play In Steering	Wheel bearings worn.	Replace wheel bearings.
	Loose steering unit or linkage.	Retighten or repair.
	Worn or loose steering shaft universal joint.	Retighten or replace steering shaft.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
Poor Steering Wheel Returnability	Bind in steering linkage ball joints.	Replace ball joints.
	Bind in upper or lower ball joints.	Replace ball joints.
	Bind in steering column and shaft.	Repair or replace.
	Bind in steering gear.	Check and repair steering gear.
	Improper wheel alignment.	Adjust wheel alignment.
	Tires not adequately inflated.	Adjust pressure.
	Loose steering wheel nut.	Retighten.
	Worn wheel bearing.	Replace.

3C-4 FRONT SUSPENSION

Condition	Possible cause	Correction
Abnormal Noise	Worn, sticky or loose upper or lower ball joint, steering linkage ball joints or drive axle joints.	Replace.
	Faulty shock absorbers.	Replace.
	Worn upper or lower control arm bushing.	Replace.
	Loose stabilizer bar.	Retighten bolts or replace bushings.
	Loose wheel nuts.	Tighten nuts. Check for elongated wheel nut holes. Replace wheel if required.
	Loose suspension bolts or nuts.	Retighten suspension bolts or nuts.
	Broken or otherwise damaged wheel bearings.	Replace wheel bearing.
	Broken suspension springs.	Replace spring.
	Loose steering unit.	Retighten mounting bolt.
	Faulty steering unit.	Replace steering unit.
Wandering or Poor Steering Stability	Mismatched or unevenly worn tires.	Replace tire or inflate tires to proper pressure.
	Loose steering linkage ball joints.	Replace ball joints.
	Faulty shock absorbers.	Replace shock absorber.
	Loose stabilizer bar.	Tighten or replace stabilizer bar or bushings.
	Broken or sagging springs.	Replace spring (pairs).
	Improper wheel alignment.	Adjust wheel alignment.
Erratic Steering When Braking	Worn wheel bearings.	Replace wheel bearings.
	Broken or sagging springs.	Replace spring (pairs).
	Leaking caliper.	Repair or replace caliper.
	Warped discs.	Replace brake disc.
	Badly worn brake pads.	Replace brake pads.
	Tires are inflated unequally.	Inflate tires to proper pressure.
Low or Uneven Trim Height	Broken or sagging springs.	Replace springs (In pairs).
	Vehicle overloaded.	Reduce load.
	Incorrect springs.	Adjust or replace torsion bar.
Suspension Bottoms	Vehicle overloaded.	Reduce load.
	Faulty shock absorber.	Replace shock absorber.
	Incorrect, broken or sagging springs.	Replace springs.
Body Leans	Loose stabilizer bar.	Tighten stabilizer bar bolts or replace bushings.
	Faulty shock absorber, struts or mounting.	Replace shock absorber.
	Broken or sagging springs.	Replace springs (In pairs).
	Vehicle overloaded.	Reduce load.
Cupped Tires	Worn wheel bearings.	Replace wheel bearing.
	Excessive tire or wheel run out.	Replace tire or wheel.
	Worn ball joints.	Replace ball joints.
	Tire out of balance.	Adjust tire balance.

Shock Absorber

Shock Absorber and Associated Parts



450RW009

Legend

- | | |
|-------------------------------|-------------------------------|
| (1) Nut | (3) Bolt and Nut |
| (2) Rubber Bushing and Washer | (4) Shock Absorber |
| | (5) Rubber Bushing and Washer |

Removal

1. Raise the vehicle and support it with suitable safety stands.
2. Remove wheel and tire assembly. Refer to Wheel Replacement in this section.
3. Remove bolt and nut.
4. Remove nut.
5. Remove rubber bushing and washer.
6. Remove shock absorber.
7. Remove rubber bushing and washer.

Installation

1. Install rubber bushing and washer.
2. Install shock absorber.
3. Install rubber bushing and washer.
4. Install nut, then tighten it to the specified torque.
Torque: 20 N·m (14 lb ft)
5. Install bolt and nut, then tighten to the specified torque.

Torque: 93 N·m (69 lb ft)

Inspection and Repair


Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts :

- ☐ Shock absorber
- ☐ Rubber bushing

Stabilizer Bar

Stabilizer Bar and Associated Parts



410RW007

Legend

- (1) Rubber Bushing
- (2) Bracket

- (3) Link
- (4) Nut
- (5) Stabilizer Bar

Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove the stone guard.
3. Remove wheel and tire assembly. Refer to Wheel Replacement in this section.
4. Remove nut.

CAUTION: Be careful not to break the ball joint boot.

5. Remove link.
6. Remove bracket.
7. Remove stabilizer bar.
8. Remove rubber bushing.

- Stabilizer bar
- Rubber bushing
- Link ball joint

Installation

1. Install rubber bushing.
2. Install stabilizer bar.
3. Install bracket, then tighten it to the specified torque.

Torque: 25 N·m (18 lb ft)

4. Install link.
5. Install nut, then tighten it to the specified torque.

Torque: 50 N·m (37 lb ft)


Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts :

Torsion Bar

Torsion Bar and Associated Parts



410RS003

Legend


(1) Adjust Bolt, End Piece and Seat

(2) Height Control Arm

(3) Torsion Bar

Removal


1. Raise the vehicle and support the frame with suitable safety stands.
2. Apply the setting marks(1) to the adjust bolt and end piece, then remove adjust bolt, end piece and seat.




410RS004

3C-8 FRONT SUSPENSION

3. Apply the setting marks(2) to the height control arm and torsion bar, then remove height control arm.





4. Apply the setting marks(3) to the torsion bar and lower control arm, then remove torsion bar.



Installation

1. Apply grease to the serrated portions, then install torsion bar. Make sure the bars are on their correct respective sides and align the setting marks(3).




Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts:


- ☐ Torsion bar
- ☐ Height control arm
- ☐ Adjust bolt
- ☐ Rubber seat

2. Apply grease to the portion that fits into the bracket then install height control arm and align the setting marks(2).



410RS005


3. Apply grease to the bolt portion of the end piece(4). Apply grease to the portion of the seat(5) that fits into the bracket.



410RS008

4. Apply grease to the serrated portions.
5. Install adjust bolt and seat, then turn the adjust bolt to the setting mark(1) applied during disassembly.


NOTE: Adjust the trim height. Refer to Front End Alignment Inspection and Adjustment in Steering section.



410RS004

Knuckle

Knuckle and Associated Parts



410RW006

Legend


- | | |
|----------------------|-------------------------|
| (1) Torsion Bar | (6) Needle Bearing |
| (2) Lower Ball Joint | (7) Thrust Washer |
| (3) Back Plate | (8) Oil Seal |
| (4) Knuckle Assembly | (9) Upper Ball Joint |
| (5) Knuckle | (10) Wheel Speed Sensor |

Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove wheel and tire assembly. Refer to Wheel in this section.
3. Remove the brake caliper. Refer to Disc Brakes in Brake section.
4. Remove the hub assembly. Refer to Front Hub and Disk in this section.
5. Remove tie-rod end from the knuckle. Refer to Power Steering Unit in Steering section.
6. Remove the speed sensor from the knuckle.
7. Loosen torsion bar by height control arm adjust bolt, then remove torsion bar. Refer to Torsion Bar in this section.
8. Remove wheel speed sensor.


9. Remove back plate.
10. Remove lower ball joint by using remover J-29107.

CAUTION: Be careful not to damage the ball joint boot.




11. Remove upper ball joint by using remover J-36831.

CAUTION: Be careful not to damage the ball joint boot.



12. Remove knuckle assembly.
13. Remove oil seal (Except 2WD model).
14. Remove washer (Except 2WD model).

15. Remove needle bearing by using remover J-23907 (Except 2WD model).



Inspection and Repair


Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts:

- ☐ Knuckle
- ☐ Knuckle arm
- ☐ Needle bearing
- ☐ Thrust washer


Installation

1. Apply appropriate amount of multipurpose type grease to the new bearing (Approx. 5 g) and install needle bearing by using installer J-36838 and J-8092 (Except 2WD model).



3C-12 FRONT SUSPENSION

2. Apply multipurpose type grease to the thrust washer, and install washer with chamfered side facing knuckle (Except 2WD model).
3. Use a new oil seal, and apply multipurpose type grease to the area surrounded by the lip (approx. 2 g). Then use installer J-36837 and J-8092 to install oil seal. After fitting the oil seal to the installer, drive it to the knuckle using a hammer or bench press until the tool front face contacts with the thrust washer (Except 2WD model).




901RW167

4. Install knuckle assembly.
5. Install upper ball joint and tighten the nut to the specified torque, with just enough additional torque to align cotter pin holes. Install new cotter pin.
Torque: 98 N·m (72 lb ft)
6. Install lower ball joint and tighten the nut to the specified torque, with just enough additional torque to align cotter pin holes. Install new cotter pin.
Torque: 147 N·m (108 lb ft)
7. Install back plate.
8. Install wheel speed sensor.
9. Install torsion bar, refer to Torsion Bar in this section.

NOTE: Adjust the trim height. Refer to Front End Alignment Inspection and Adjustment in Steering.

Upper Control Arm

Upper Control Arm and Associated Parts



450RW005

Legend


- | | |
|--------------------------------|-------------------------|
| (1) Bolt and Plate | (7) Bushing |
| (2) Camber Shims | (8) Plate |
| (3) Caster Shims | (9) Nut |
| (4) Nut Assembly | (10) Speed Sensor Cable |
| (5) Upper Control Arm Assembly | (11) Nut and Cotter Pin |
| (6) Fulcrum Pin | (12) Upper Ball Joint |

Removal



1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove wheel and tire assembly. Refer to Wheel in this section.
3. Remove the brake caliper and disconnect brake pipe. Refer to Disc Brakes in Brake section.
4. Support lower control arm with a jack.
5. Remove speed sensor cable.
6. Remove nut and cotter pin then use remover J-36831.

3C-14 FRONT SUSPENSION

CAUTION: Be careful not to damage the ball joint boot.



7. Remove upper ball joint.
8. Remove bolt and plate.
9. Remove nut assembly.
10. Remove camber shims and note the positions and number of shims.
11. Remove caster shims and note the positions and number of shims.
12. Remove upper control arm assembly.
13. Remove nut.
14. Remove plate.
15. Remove bushing by using remover J-29755.



16. Remove fulcrum pin.

Inspection and Repair


Make necessary parts replacement if wear, damage, corrosion or any other abnormal conditions are found through inspection.


Check the following parts:

- ☐ Upper control arm
- ☐ Bushing
- ☐ Fulcrum pin

Installation

1. Install fulcrum pin.
2. Install bushing by using installer J-29755 and J-39376.






3. Install plate.

4. Install nut and tighten fulcrum pin nut finger-tight.


NOTE: Torque fulcrum pin nut after adjusting buffer clearance.

Buffer clearance: 22 mm (0.87 in)

Torque: 108 N·m (80 lb ft)



5. Install upper control arm assembly with the fulcrum pin projections turned inward.




Legend

- (1) Projection
- (2) Outward

6. Install the caster shims(2) between the chassis frame and fulcrum pin.

7. Install the camber shims(1) between the chassis frame and fulcrum pin.



8. Install nut assembly.

9. Install bolt and plate, then tighten the bolt to the specified torque.

Torque: 152 N·m (112 lb ft)

10. Install upper ball joint and tighten it to the specified torque.

Torque: 57 N·m (42 lb ft)


11. Install nut and cotter pin then tighten the nut to the specified torque, with just enough additional torque to align cotter pin holes. Install new cotter pin.

Torque: 98 N·m (72 lb ft)

12. Install speed sensor cable.

Lower Control Arm

Lower Control Arm and Associated Parts



450RW010



Legend

- | | |
|----------------------------|-----------------------------|
| (1) Nut, Front | (8) Bolt, Torsion Bar Arm |
| (2) Bush, Front | (9) Torsion Bar Arm Bracket |
| (3) Bolt, Front | (10) Torsion Bar |
| (4) Nut, Rear | (11) Lower Control Arm |
| (5) Bush, Rear | (12) Lower Ball Joint |
| (6) Bolt, Rear | (13) Shock Absorber |
| (7) Bolt, Lower Ball Joint | (14) Stabilizer Link |



Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove wheel and tire assembly. Refer to Wheel in this section.
3. Remove the tie-rod end from the knuckle. Refer to Power Steering Unit in Steering section.
4. Remove the retaining ring from the front axle driving shaft to release the shaft from hub (Except 2WD model). Refer to Front Hub and Disc in Driveline/Axle section.
5. Support lower control arm with a jack.

6. Remove front nut.
7. Remove rear nut.
8. Remove torsion bar, refer to Torsion Bar in this section.
9. Remove torsion bar arm bracket.
10. Disconnect the stabilizer link at the lower control arm.
11. Remove the shock absorber lower end from the lower control arm.
12. Remove the lower ball joint from the lower control arm.
13. Remove front bolt.
14. Remove rear bolt.
15. Remove lower control arm.
16. Remove torsion bar arm bolt.
17. Remove lower ball joint bolt.
18. Remove front bushing by using remover J-36833.



19. Remove rear bushing by using remover J-36834.



Inspection and Repair


Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts:

- ☐ Lower control arm
- ☐ Bushing


Installation

1. Install rear bushing by using installer J-36834.



901RW053

2. Install front bushing by using installer J-36833.



901RW156

3. Install lower ball joint bolt.
4. Install torsion bar arm bolt.
5. Install lower control arm.
6. Install rear bolt.
7. Install front bolt.
8. Install lower ball joint and tighten it to the specified torque.
Torque: 116 N·m (85 lb ft)
9. Install shock absorber and tighten it to the specified torque.
Torque: 93 N·m (69 lb ft)
10. Install stabilizer link and tighten it to the specified torque.
Torque: 50 N·m (37 lb ft)

11. Install torsion bar arm bracket and tighten it to the specified torque.


Torque: 116 N·m (85 lb ft)

12. Install Torsion bar, refer to Torsion Bar in this section.
13. Install rear nut and tighten lower link nut finger-tight.

NOTE: Torque lower control arm nut after adjusting buffer clearance.

Buffer clearance: 22 mm (0.87 in)

Torque: 235 N·m (174 lb ft)



450RS012


14. Install front nut then tighten lower link nut finger-tight.

NOTE: Torque lower control arm nut after adjusting buffer clearance .

Buffer clearance: 22 mm (0.87 in)

Torque: 190 N·m (140 lb ft)


NOTE: Adjust the trim height. Refer to Front End Alignment Inspection and Adjustment in Steering section.



450RS012

Upper Ball Joint

Upper Ball Joint and Associated Parts



450RW004

Legend

(1) Bolt and Nut

(2) Upper Ball Joint

(3) Nut and Cotter Pin


Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove the speed sensor from the knuckle.

3C-20 FRONT SUSPENSION

3. Remove upper ball joint nut and cotter pin, then use remover J-36831 to remove the upper ball joint from the knuckle.

CAUTION: Be careful not to damage the ball joint boot.




4. Remove bolt and nut.
5. Remove upper ball joint.

Inspection and Repair


Make necessary parts replacement if wear, damage, corrosion or any other abnormal conditions are found through inspection.

- Inspect the lower end boot for damage or grease leak. Move the ball joint as shown in the figure to confirm its normal movement.
- Inspect screw/taper area of ball for damage.
- If any defects are found by the above inspections, replace the ball joint assembly with new one.



- After moving the ball joint 4 or 5 times, attach nut then measure the preload.

Starting torque: 0.5 –3.2 N·m (0.4–2.4 lb ft)



If the above limits specified are exceeded, replace the ball joint assembly.

Installation

1. Install upper ball joint.
2. Install bolt and nut, then tighten them to the specified torque.


Torque: 57 N·m (42 lb ft)

3. Install nut and cotter pin, then tighten the nut to the specified torque with just enough additional torque to align cotter pin holes. Install new cotter pin.

Torque: 98 N·m (72 lb ft)

Lower Ball Joint

Lower Ball Joint and Associated Parts



450RW011

Legend


- (1) Bolt
- (2) Lower Ball Joint

- (3) Nut
- (4) Nut and Cotter Pin

Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove wheel and tire assembly. Refer to Wheel in this section.
3. Remove the tie-rod end from the knuckle. Refer to Power Steering Unit in Steering section.
4. Remove the retaining ring from the front axle driving shaft to release the shaft from hub(Except 2WD model). Refer to Front Hub and Disc in Driveline/Axle section.
5. Support lower control arm with a jack.
6. Remove lower ball joint nut and cotter pin, then use remover J-29107 to remove the lower ball joint from the knuckle.

CAUTION: Be careful not to damage the ball joint boot.




901RW163

7. Remove nut.
8. Remove bolt.
9. Remove lower ball joint.

Inspection and Repair

Make necessary parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.


- Inspect the lower end boot for damage or grease leak. Move the ball joint as shown in the figure to confirm its normal movement .
- Inspect screw/taper area of ball for damage.
- If any defects are found by the above inspections, replace the ball joint assembly with new one.



450RS026

- After moving the ball joint 4 or 5 times, attach nut the measure the preload.

Starting torque: 0.5–6.4 N·m (0.4–4.7 lb ft)



450RS024

- If the above limits specified are exceeded, replace the ball joint assembly.

Installation

1. Install lower ball joint.
2. Install bolt.
3. Install nut and tighten it to the specified torque.

Torque: 116 N·m (85 lb ft)

4. Install ball joint nut, then tighten it to the specified torque with just enough additional torque to align cotter pin holes. Install new cotter pin.


Torque: 147 N·m (108 lb ft)

Main Data and Specifications

General Specifications

Front suspension	Type	Independent wishbone arms, torsion bar spring with stabilizer bar.
Torsion bar spring	Length	1142 mm (45.0 in)
	Diameter	28.0 mm (1.10 in)
Front shock absorber	Type	Hydraulic, double acting, telescopic
	Piston diameter	30.0 mm (1.18 in)
	Stroke	125.0 mm (4.92 in)
	Compressed length	255.0 mm (10.04 in)
	Extended length	380.0 mm (14.96 in)
Stabilizer bar	Diameter	24.0 mm (0.94 in)

Torque Specifications



E03RX001

Special Tools











ILLUSTRATION	TOOL NO. TOOL NAME
 901RS283	J-23907 Remover; Needle bearing
 901RS284	J-36838 Installer; Needle bearing
 901RS285	J-8092 Grip
 901RS182	J-36837 Installer; Oil seal
 901RS286	J-39376 Installer; Upper arm bushing
 901RS287	J-29775 Remover and Installer Upper arm bushing

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS288	J-36833 Remover and Installer kit; Lower arm front bushing
 901RS289	J-36834 Remover and Installer kit; Lower arm rear bushing
 901RS290	J-36831 Ball joint remover
 901RS279	J-29107 Tie-rod end remover

RODEO

SUSPENSION

REAR SUSPENSION

CONTENTS

Service Precaution	3D-1	Upper Link	3D-10
General Description	3D-1	Upper Link and Associated Parts	3D-10
Diagnosis	3D-2	Removal	3D-10
Coil Spring	3D-5	Inspection and Repair	3D-10
Coil Spring and Associated Parts	3D-5	Installation	3D-11
Removal	3D-5	Lateral Rod	3D-12
Inspection and Repair	3D-6	Lateral Rod and Associated Parts	3D-12
Installation	3D-6	Removal	3D-12
Shock Absorber	3D-7	Inspection and Repair	3D-12
Shock Absorber and Associated Parts	3D-7	Installation	3D-13
Removal	3D-7	Stabilizer Bar	3D-14
Inspection and Repair	3D-7	Stabilizer Bar and Associated Parts	3D-14
Installation	3D-7	Removal	3D-14
Trailing Link	3D-8	Inspection and Repair	3D-14
Trailing Link and Associated Parts	3D-8	Installation	3D-15
Removal	3D-8	Main Data and Specifications	3D-16
Inspection and Repair	3D-8	Special Tools	3D-18
Installation	3D-9		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

The rear suspension is a 5-link, coil spring type suspension with a stabilizer bar, consisting of two trailing links, two upper links, lateral rod, shock absorber, and stabilizer. In this suspension, the links are specially arranged to enable the rear axle to move freely, thereby expanding suspension stroke, reducing friction, and improving lateral rigidity and roll control. All these result in improved stability, riding comfort, and rough road maneuverability.

Each link connects the axle housing with the frame through a runner bushing. The axle housing is supported by the trailing links and upper links longitudinally and by the lateral rod latitudinally.

Diagnosis

Condition	Possible cause	Correction
Vehicle Pulls	Mismatched or uneven tires.	Replace tire.
	Tires not adequately inflated.	Adjust tire pressure.
	Broken or sagging springs.	Replace spring.
	Radial tire lateral force.	Replace tire.
	Improper wheel alignment.	Adjust wheel alignment.
	Brake dragging in one wheel.	Repair brake.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension part(s).
	Faulty shock absorbers.	Replace shock absorber.
	Parts in power steering valve defective.	Replace power steering unit.
Abnormal or Excessive Tire Wear	Sagging or broken spring.	Replace spring.
	Tire out of balance.	Balance or replace tire.
	Improper wheel alignment.	Check front end alignment.
	Faulty shock absorber.	Replace shock absorber.
	Hard driving.	Replace tire.
	Overloaded vehicle.	Replace tire and reduce load.
	Tires not rotated periodically.	Replace or rotate tire.
	Worn or loose road wheel bearings.	Replace wheel bearing.
	Wobbly wheel or tires.	Replace wheel or tire.
	Tires not adequately inflated.	Adjust the pressure.
Wheel Hop	Blister or bump on tire.	Replace tire.
	Improper shock absorber operation.	Replace shock absorber.
Shimmy, Shake or Vibration	Tire or wheel out of balance.	Balance wheels or replace tire/or wheel.
	Loose wheel bearings.	Replace wheel bearing.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
	Excessive wheel runout.	Repair or replace wheel and/or tire.
	Blister or bump on tire.	Replace tire.
	Excessive loaded radial runout of tire/wheel assembly.	Replace tire or wheel.
	Improper wheel alignment.	Check wheel alignment.
	Loose or worn steering linkage.	Tighten or replace steering linkage.
	Loose steering unit.	Tighten steering unit.
	Tires not adequately inflated.	Adjust tire pressure.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension parts.
	Faulty shock absorber.	Replace shock absorber.
	Hub bearing preload misadjustment.	Adjust preload.
	Parts in power steering valve defective.	Replace power steering unit.


Condition	Possible cause	Correction
Hard Steering	Bind in steering linkage ball studs, upper or lower ball joint.	Replace ball joint.
	Improper wheel alignment.	Check wheel alignment.
	Tire not adequately inflated.	Inflate tires to proper pressure.
	Bind in steering column or shaft.	Repair or replace.
	Improper power steering system operation.	Repair or replace. Refer to Steering section.
Too Much Play In Steering	Wheel bearings worn.	Replace wheel bearings.
	Loose steering unit or linkage.	Retighten or repair.
	Worn or loose steering shaft universal joint.	Retighten or replace steering shaft.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
Poor Steering Wheel Returnability	Bind in steering linkage ball joints.	Replace ball joints.
	Bind in upper or lower ball joints.	Replace ball joints.
	Bind in steering column and shaft.	Repair or replace.
	Bind in steering gear.	Check and repair steering gear.
	Improper wheel alignment.	Adjust wheel alignment.
	Tires not adequately inflated.	Adjust pressure.
	Loose steering wheel nut.	Retighten.
	Worn wheel bearing.	Replace.
Abnormal Noise	Worn, sticky or loose upper or lower ball joint, steering linkage ball joints or drive axle joints.	Replace.
	Faulty shock absorbers.	Replace.
	Worn upper or lower control arm bushing.	Replace.
	Loose stabilizer bar.	Retighten bolts or replace bushings.
	Loose wheel nuts.	Tighten nuts. Check for elongated wheel nut holes. Replace wheel if required.
	Loose suspension bolts or nuts.	Retighten suspension bolts or nuts.
	Broken or otherwise damaged wheel bearings.	Replace wheel bearing.
	Broken suspension springs.	Replace spring.
	Loose steering unit.	Retighten mounting bolt.
	Faulty steering unit.	Replace steering unit.
Wandering or Poor Steering Stability	Mismatched or unevenly worn tires.	Replace tire or inflate tires to proper pressure.
	Loose steering linkage ball joints.	Replace ball joints.
	Faulty shock absorbers.	Replace shock absorber.
	Loose stabilizer bar.	Tighten or replace stabilizer bar or bushings.
	Broken or sagging springs.	Replace spring (pairs).
	Improper wheel alignment.	Adjust wheel alignment.

3D-4 REAR SUSPENSION

Condition	Possible cause	Correction
Erratic Steering When Braking	Worn wheel bearings.	Replace wheel bearings.
	Broken or sagging springs.	Replace spring (pairs).
	Leaking caliper.	Repair or replace caliper.
	Warped discs.	Replace brake disc.
	Badly worn brake pads.	Replace brake pads.
	Tires are inflated unequally.	Inflate tires to proper pressure.
Low or Uneven Trim Height	Broken or sagging springs.	Replace springs (In pairs).
	Vehicle overloaded.	Reduce load.
	Incorrect springs.	Adjust or replace torsion bar.
Suspension Bottoms	Vehicle overloaded.	Reduce load.
	Faulty shock absorber.	Replace shock absorber.
	Incorrect, broken or sagging springs.	Replace springs.
Body Leans	Loose stabilizer bar.	Tighten stabilizer bar bolts or replace bushings.
	Faulty shock absorber, struts or mounting.	Replace shock absorber.
	Broken or sagging springs.	Replace springs (In pairs).
	Vehicle overloaded.	Reduce load.
Cupped Tires	Worn wheel bearings.	Replace wheel bearing.
	Excessive tire or wheel run out.	Replace tire or wheel.
	Worn ball joints.	Replace ball joints.
	Tire out of balance.	Adjust tire balance.

Coil Spring

Coil Spring and Associated Parts



460RW003

Legend

- | | |
|------------------------------------|--------------------|
| (1) Stabilizer Bar | (4) Coil Spring |
| (2) Upper Link Fixing Bolt and Nut | (5) Insulator |
| (3) Rubber Plate | (6) Shock Absorbar |
| | (7) Breather Hose |

Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Support the rear axle case with a jack.
3. Disconnect brake hose at the crossmember.
4. Remove breather hose.
5. Remove upper link fixing bolt, nut and rubber plate on the rear axle case (left-side only).
6. Disconnect the stabilizer bar at the stabilizer link.
7. Remove the shock absorber from the axle case.
8. Remove spring insulator.
9. Remove the insulator and coil spring while lowering the rear axle case.

CAUTION: Be sure not to let the brake hose, parking brake cable, and breather hose extend to their full length.

Inspection and Repair


Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts:

- ☐ Coil spring
- ☐ Insulator


Installation

1. Install coil spring and make sure that the coil spring is installed in the proper position. Paint mark(1) should be downward.




460RW001

2. Fit the end of the coil spring to the coil spring seat and mount the coil spring on the rear axle case.



460RW004

3. Install the insulator on the coil spring. Jack up the axle case gently with the top of the coil spring set to the spring seat on the frame side.



460RW013

4. Install shock absorber and tighten the nut lightly, then retighten it to the specified torque after the vehicle is at curb height.

NOTE: When mounting shock absorber, be sure not to use grease on bushings or any other nearby part.

Torque: 78 N·m (58 lb ft)

5. Install stabilizer bar.

Torque: 31 N·m (23 lb ft)

6. Install upper link with rubber plate and tighten fixing bolt.


Torque: 137 N·m (101 lb ft)

7. Install breather hose.

8. Connect brake hose and bleed the brake system.
Refer to Bleeding the Brake Hydraulic System in Brake section.

Shock Absorber

Shock Absorber and Associated Parts



461RW001

Legend

(1) Nut, Bush and Washer

(2) Shock Absorber

(3) Nut and Washer

Removal

1. Remove shock absorber fixing nut, bush and washer (upper side).
2. Remove shock absorber fixing nut and washer (lower side).
3. Remove shock absorber.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts:

- ☐ Shock absorber
- ☐ Rubber bushing

NOTE: When mounting rubber bushings, be sure not to use grease on bushings or any other nearby part.

Installation

1. Install shock absorber. When mounting shock absorber, be sure not to use grease on bushings or any other nearby part.
2. Install nut and washer (lower side), then tighten the nut lightly. Retighten to the bolt and nut specified torque after the vehicle is at curb height.


Torque: 78 N-m (58 lb ft)

3. Install nut, bush and washer (upper side), then tighten the nut lightly. Retighten to the nut specified torque after the vehicle is at curb height.

Torque: 20 N-m (14 lb ft)

Trailing Link

Trailing Link and Associated Parts



460RW005

Legend

(1) Bolt and Nut (Axle side)

(2) Protector (Left side only)

(3) Bolt (Frame side)


Removal

1. Remove the parking brake cable from the trailing link.
2. Remove the trailing link fixing bolt, nut and protector.
3. Remove trailing link.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.


1. Trailing link
2. Rubber bushing
 - Remove the rubber bushing by using remover J-39214.



901RW058

- Install the rubber bushing by using installer J-39214.


NOTE: When mounting rubber bushings, be sure not to use grease on bushings or any other nearby part.



Installation

1. Install trailing link. Make sure that the trailing link is in its correct position.

NOTE: When mounting trailing link, be sure not to use grease on bushings or any other nearby part.



2. Install bolt, nut and protector. Tighten the bolts and nuts lightly, then retighten them to the specified torque after the vehicle is at curb height.


Torque: 137 N·m (101 lb ft)

3. Install parking brake cable.

CAUTION: The parking brake cable should not be overstrained or slackened.

Upper Link

Upper Link and Associated Parts



460RW006

Legend

- | | |
|------------------------------|--------------------------------|
| (1) Bolt and Nut (Axle side) | (3) Upper Link |
| (2) Rubber Plate | (4) Protector (Left side only) |
| | (5) Bolt (Frame side) |


Removal

1. Remove fuel tank. Refer to Engine Fuel in Engine section.
2. Remove the speed sensor cable from the upper link.
3. Remove bolt, nut, rubber plate and protector.
4. Remove upper link.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.


1. Upper link
2. Rubber bushing
 - Remove the rubber bushing by using remover J-xxxxx-x.



901RW158

- Install the rubber bushing by using to installer J-xxxxx.


NOTE: When mounting rubber bushings, be sure not to use grease on bushings or any other nearby part.



Installation

1. Install upper link. Make sure that the upper link is in its correct position.

NOTE: When mounting upper link, be sure not to use grease bushings or any other nearby part.




2. Install bolt, nut, rubber plate and protector. Tighten the bolts and nuts lightly, then retighten them to the specified torque after the vehicle is at curb height.

Torque: 137 N·m (101 lb ft)

3. Install speed sensor cable.
4. Install fuel tank.

Lateral Rod

Lateral Rod and Associated Parts



460RW007

Legend

(1) Bolt and Nut (Frame side)

(2) Lateral Rod

(3) Nut and Washer (Axle side)


Removal

1. Remove nut and washer.
2. Remove bolt and nut.
3. Remove lateral rod.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.


1. Lateral rod
2. Rubber bushing (Frame side)
 - Remove the rubber bushing (Frame side) by using remover J-39214.



901RW060


- Install the rubber bushing (Frame side) by using Installer J-39215.

NOTE: When mounting rubber bushings, do not use grease on bushings or any other nearby parts.




3. Rubber bushing (Axle side)

- Remove the rubber bushing (Axle side) by using remover J-39792.




- Install the rubber bushing (Axle side) by using installer J-39792.



Installation

1. Install lateral rod and make sure that the lateral rod is in its correct position.

NOTE: When mounting lateral rod, be sure not to use grease on bushings or any other nearby part.



Legend

- (1) Frame Side
- (2) Axle Side

2. Install bolt and nut. Tighten the bolt and nut lightly, then retighten them to the specified torque after the vehicle is at curb height.


Torque: 137 N·m (101 lb ft)

3. Install nut and washer. Tighten the nut lightly, then retighten the nut to the specified torque after the vehicle is at curb height.

Torque: 78 N·m (58 lb ft)

Stabilizer Bar

Stabilizer Bar and Associated Parts



460RW009

Legend

- | | |
|-------------|--------------------|
| (1) Bracket | (3) Bolt and Nut |
| (2) Link | (4) Stabilizer Bar |
| | (5) Rubber Bushing |

Removal

1. Raise the vehicle and support the frame with suitable safety stands.
2. Remove wheel and tire assembly. Refer to Wheel in this section.
3. Remove bolt and nut.
4. Remove link.

CAUTION: Be careful not to damage the ball joint boot.

5. Remove bracket.

6. Remove rubber bushing.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts:

- Stabilizer bar
- Rubber bushing
- Link


Installation

1. Install rubber bushing.
2. Install bracket to axle housing and tighten to the specified torque.

Torque: 25 N·m (19 lb ft)

3. Install link.
4. Install bolt and nut, then tighten the nut to the specified torque.


Torque: 31 N·m (27 lb ft)



Main Data and Specifications**General Specifications**





Rear suspension	Type	5-Link, coil spring type with stabilizer bar.
Coil spring	Free length	389.5mm (15.33in)
	Spring diameter	12.2mm (0.48in)
	Coil diameter (inner)	105mm (4.13in)
	Effective No. of turns	5.74
	Total No. of turns	7.24
Shock absorber	Type	Hydraulic, double acting, telescopic
	Piston diameter	30mm (1.18in)
	Stroke	175mm (6.89in)
	Extended length	473.5mm (18.64in)
	Compressed length	298.5mm (11.75in)
Stabilizer bar	Diameter	18mm (0.71in)

Torque Specifications



E03RW003

Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
	J-39214 Remover and Installer; Trailing link bushing
	J-xxxxx Remover and Installer; Upper link bushing
	J-39792 Remover and Installer; Lateral rod bushing (axle side)
	J-39215 Remover and Installer; Lateral rod bushing

RODEO

SUSPENSION

WHEEL AND TIRE SYSTEM

CONTENTS


Service Precaution	3E-1	Tire	3E-12
General Description	3E-2	Tire Replacement	3E-12
Diagnosis	3E-3	General Balance Procedure	3E-12
Wheel	3E-11	Balancing Wheel and Tire	3E-13
Wheel and Associated Parts	3E-11	Main Data and Specifications	3E-14
Removal	3E-11		
Installation	3E-11		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



480RS008

Replacement wheels or tires must be equivalent to the originals in load capacity, specified dimension and mounting configuration. Improper size or type may affect bearing life, brake performance, speedometer/odometer calibration, vehicle ground clearance and tire clearance to the body and chassis. All model are equipped with metric sized tubeless steel belted radial tires. Correct tire pressures and driving habits have an important influence on tire life. Heavy cornering, excessively rapid acceleration and unnecessary sharp braking increase premature and uneven wear.

Diagnosis


Condition	Possible cause	Correction
Vehicle Pulls	Mismatched or uneven tires.	Replace tire.
	Tires not adequately inflated.	Adjust tire pressure.
	Broken or sagging springs.	Replace spring.
	Radial tire lateral force.	Replace tire.
	Improper wheel alignment.	Adjust wheel alignment.
	Brake dragging in one wheel.	Repair brake.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension part(s).
	Faulty shock absorbers.	Replace shock absorber.
	Parts in power steering valve defective.	Replace power steering unit.
Abnormal or Excessive Tire Wear	Sagging or broken spring.	Replace spring.
	Tire out of balance.	Balance or replace tire.
	Improper wheel alignment.	Check front end alignment.
	Faulty shock absorber.	Replace shock absorber.
	Hard driving.	Replace tire.
	Overloaded vehicle.	Replace tire and reduce load.
	Tires not rotated periodically.	Replace or rotate tire.
	Worn or loose road wheel bearings.	Replace wheel bearing.
	Wobbly wheel or tires.	Replace wheel or tire.
	Tires not adequately inflated.	Adjust the pressure.
Wheel Hop	Blister or bump on tire.	Replace tire.
	Improper shock absorber operation.	Replace shock absorber.
Shimmy, Shake or Vibration	Tire or wheel out of balance.	Balance wheels or replace tire/or wheel.
	Loose wheel bearings.	Replace wheel bearing.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
	Excessive wheel runout.	Repair or replace wheel and/or tire.
	Blister or bump on tire.	Replace tire.
	Excessive loaded radial runout of tire/wheel assembly.	Replace tire or wheel.
	Improper wheel alignment.	Check wheel alignment.
	Loose or worn steering linkage.	Tighten or replace steering linkage.
	Loose steering unit.	Tighten steering unit.
	Tires not adequately inflated.	Adjust tire pressure.
	Loose, bent or broken front or rear suspension parts.	Tighten or replace the appropriate suspension parts.
	Faulty shock absorber.	Replace shock absorber.
	Hub bearing preload misadjustment.	Adjust preload.
	Parts in power steering valve defective.	Replace power steering unit.

3E-4 WHEEL AND TIRE SYSTEM

Condition	Possible cause	Correction
Hard Steering	Bind in steering linkage ball studs, upper or lower ball joint.	Replace ball joint.
	Improper wheel alignment.	Check wheel alignment.
	Tire not adequately inflated.	Inflate tires to proper pressure.
	Bind in steering column or shaft.	Repair or replace.
	Improper power steering system operation.	Repair or replace. Refer to Steering section.
Too Much Play In Steering	Wheel bearings worn.	Replace wheel bearings.
	Loose steering unit or linkage.	Retighten or repair.
	Worn or loose steering shaft universal joint.	Retighten or replace steering shaft.
	Worn steering linkage ball joints.	Replace ball joints.
	Worn upper or lower end ball joints.	Replace ball joints.
Poor Steering Wheel Returnability	Bind in steering linkage ball joints.	Replace ball joints.
	Bind in upper or lower ball joints.	Replace ball joints.
	Bind in steering column and shaft.	Repair or replace.
	Bind in steering gear.	Check and repair steering gear.
	Improper wheel alignment.	Adjust wheel alignment.
	Tires not adequately inflated.	Adjust pressure.
	Loose steering wheel nut.	Retighten.
	Worn wheel bearing.	Replace.
Abnormal Noise	Worn, sticky or loose upper or lower ball joint, steering linkage ball joints or drive axle joints.	Replace.
	Faulty shock absorbers.	Replace.
	Worn upper or lower control arm bushing.	Replace.
	Loose stabilizer bar.	Retighten bolts or replace bushings.
	Loose wheel nuts.	Tighten nuts. Check for elongated wheel nut holes. Replace wheel if required.
	Loose suspension bolts or nuts.	Retighten suspension bolts or nuts.
	Broken or otherwise damaged wheel bearings.	Replace wheel bearing.
	Broken suspension springs.	Replace spring.
	Loose steering unit.	Retighten mounting bolt.
	Faulty steering unit.	Replace steering unit.
Wandering or Poor Steering Stability	Mismatched or unevenly worn tires.	Replace tire or inflate tires to proper pressure.
	Loose steering linkage ball joints.	Replace ball joints.
	Faulty shock absorbers.	Replace shock absorber.
	Loose stabilizer bar.	Tighten or replace stabilizer bar or bushings.
	Broken or sagging springs.	Replace spring (pairs).
	Improper wheel alignment.	Adjust wheel alignment.

Condition	Possible cause	Correction
Erratic Steering When Braking	Worn wheel bearings.	Replace wheel bearings.
	Broken or sagging springs.	Replace spring (pairs).
	Leaking caliper.	Repair or replace caliper.
	Warped discs.	Replace brake disc.
	Badly worn brake pads.	Replace brake pads.
	Tires are inflated unequally.	Inflate tires to proper pressure.
Low or Uneven Trim Height	Broken or sagging springs.	Replace springs (In pairs).
	Vehicle overloaded.	Reduce load.
	Incorrect springs.	Adjust or replace torsion bar.
Suspension Bottoms	Vehicle overloaded.	Reduce load.
	Faulty shock absorber.	Replace shock absorber.
	Incorrect, broken or sagging springs.	Replace springs.
Body Leans	Loose stabilizer bar.	Tighten stabilizer bar bolts or replace bushings.
	Faulty shock absorber, struts or mounting.	Replace shock absorber.
	Broken or sagging springs.	Replace springs (In pairs).
	Vehicle overloaded.	Reduce load.
Cupped Tires	Worn wheel bearings.	Replace wheel bearing.
	Excessive tire or wheel run out.	Replace tire or wheel.
	Worn ball joints.	Replace ball joints.
	Tire out of balance.	Adjust tire balance.

Irregular and Premature Wear




480RS001

Irregular and/or premature wear has many causes. Some of them are incorrect inflation pressures, lack of tire rotation, poor driving habits or improper wheel alignment. Incorrect inflation is common cause of tire premature wear.

NOTE: Due to their design, radial tires tend to wear faster in the shoulder area, particularly on the front tires. This makes regular rotation especially necessary. After rotation, be sure to check wheel nut torque, and set tire pressures.

Tire Rotation

Tire rotation is recommended to equalize wear for longer tire life.



Legend

(1) Spare Tire


If the following conditions are noted, rotate the tires:

- ☐ Front tire wear is different from rear.
- ☐ Uneven wear exists across the tread of any tire.
- ☐ Left and right front tire wear is unequal.
- ☐ Left and right rear tire wear is unequal.

Check wheel alignment if the following conditions are noted:

- ☐ Left and right front tire wear is unequal.
- ☐ Wear is uneven across the tread of any front tire.
- ☐ Front tire treads have a scuffed appearance with "feather" edges on one side of the tread ribs or blocks.


Tread Wear Indicators



The original equipment tires have built-in tread wear indicators(1) to show when tires need replacement. These

indicators may appear as wide bands. When the indicators appear in two or more grooves at three locations, tire replacement is recommended.

Inflation of Tires



Tire pressure, in cold condition (after vehicle has set for three hours or more, and driven less than one mile), should be checked monthly or before any extended trip. Tire pressure increases approximately 15% when the tires become hot during driving. Tire pressure specification is shown on the label located on the left door lock pillar.

NOTE: Check the tire pressure whenever irregular wear is found. Tire inflation greatly affects tire wear. If the alignment check does not reveal any alignment problems, check the condition of the shock absorbers and wheel/tire balance.

Diagnosis List

If the following conditions are noted, rotation is required.

1. Front tire wear is different from rear.
2. Uneven wear exists across the tread of any tire.
3. Left and right front tire wear is unequal.
4. Left and right rear tire wear is unequal.

If the following conditions are noted, check the wheel alignment.

1. Left and right front tire wear is unequal.
2. Uneven wear exists across the tread of any tire.
3. Front tire treads have scuffed appearance with "feather" edges on one side of tread ribs or blocks.
4. There is cupping, flat spotting etc.

Higher than recommended pressure can cause:

1. Hard ride.
2. Poor steering stability.
3. Rapid and uneven wear at center of the tread.

Lower than recommended pressure can cause:


1. Tire squeal on turns.
2. Hard steering.
3. Rapid and uneven wear on the edges of the tread.
4. Tire rim bruises and rupture.

5. Tire cord breakage.
6. High tire temperatures.
7. Reduced handling.
8. Reduced fuel economy.

Unequal pressure on same axle can cause:

1. Uneven braking.
2. Steering lead.
3. Reduced handling.
4. Swerve on acceleration.

Radial Tire Waddle



Waddle is side-to-side movement at the front and/or rear of the car. It can be caused by the steel belt not being straight within the tire, or by excessive lateral runout of the tire or wheel. It is most noticeable at low speed, about 8 to 48 km/h (5 to 30 mph). It may also cause rough ride at 80 to 113 km/h (50 to 70 mph).

The car can be road tested to see which end of the car has the faulty tire. If the tire causing the waddle is on the rear, the rear end of the car will "waddle". From the driver's seat, it feels as if someone is pushing on the side of the car.

If the faulty tire is on the front, the waddle is more easily seen. The front sheet metal appears to be moving back and forth. It feels as if the driver's seat is the pivot point in the car.

Another more time-consuming method of determining the faulty tire is substituting tire and wheel assemblies that are known to be good. Follow these steps:

1. Drive the car to determine if the waddle is coming from the front or rear.
2. Install tire and wheel assemblies known to be good (from a similar car) in place of those on the end of the car which is waddling. If the waddle cannot be isolated to front or rear, start with the rear tires.
3. Road test again. If improvement is noted, install the original tire and wheel assemblies one at a time until the faulty tire is found. If no improvement is noted, install tires known to be good in place of all four. Then, install the originals one at a time until the faulty tire is found.

Radial Tire Lead/Pull

"Lead/Pull" is vehicle deviation from a straight path, on a level road with no pressure on the steering wheel.

Lead is usually caused by:

1. Poorly manufactured radial tires.
2. Uneven brake adjustment.
3. Wheel alignment.

The way in which a tire is built can produce lead in a car. An example of this is placement of the belt. Off-center belts on radial tires can cause the tire to develop a side force while rolling straight down the road and the tire will tend to roll like a cone.

The "Radial Tire Lead/Pull Correction" chart should be used to make sure that front wheel alignment is not mistaken for tire lead.

Rear tires will not cause lead/pull.

3E-8 WHEEL AND TIRE SYSTEM


Radial Tire Lead/Pull Correction Chart

Step	Action	Yes	No
1	1. Inflate tires to recommended pressure. 2. Road test vehicle on level uncrowned road. Was a problem corrected?	End.	Go to Step 2
2	Switch front tires side to side and road test again. Was a problem corrected?	If roughness results, replace tires.	Go to Step 3
3	Did the vehicle lead in same direction?	Go to Step 4	Go to Step 5
4	Put tires back in original position and check alignment. Was a problem corrected?	End.	Go to Step 5
5	Install known good tire on one front side. Was a problem corrected?	Replace tire.	Install a known good tire in place of other front tire. If lead corrected, replace tire.

Typical examples of abnormal tire ahead wear and major causes:


CAUTION: Similar wear patterns can be caused by worn suspension parts, misalignment of wheels and tires, and other suspension related problems.

Spotty wear – wear localized on shoulder sections, and in an extreme cases, the tire becomes polygonal in shape.



1. Tire or wheel out of round or distorted.
2. Hub or knuckle out of round or distorted.
3. Play in hub bearings or ball joint.
4. Rotating parts out of balance.

Tread wear one-sided.




1. Rotating parts out of balance.
2. Tire or wheel out of round.
3. Hub or knuckle out of round or distorted.

480RW003

480RW002


Localized tread wear.



480RW004

1. Once spotty wear develops in tread due to hard braking or abrupt starting, localized wear tends to be promoted.


Wear in shoulders at points opposed to each other.



480RW006

1. Tire or wheel out of round or distorted.
2. Play in bearings or ball joint.


Shoulder wear (generally wear develops in outer shoulder):



480RW005

1. Camber or toe-in incorrect.
2. Shoulder wear caused by repeated hard-cornering.

Premature wear in shoulders.




480RW007

1. Flexing of tire excessive due to under-inflation.

3E-10 WHEEL AND TIRE SYSTEM

One sided feather edging.




480RW008

1. Wear caused by repeated hard cornering.
2. Camber or toe-in incorrect.

Wheel

Wheel and Associated Parts



480RW010

Legend

- (1) Wheel Lug Nut
- (2) Wheel and Tire

Removal

1. Loosen wheel lug nut by approximately 180 g (half a rotation), then raise the vehicle and remove the nuts.
2. Remove wheel and tire.

NOTE: Never use heat to loosen a tight wheel lug nut. The application of heat to the hub can shorten the life of the wheel and may cause damage to wheel bearings.


Installation

1. Install wheel and tire.
2. Install wheel lug nut, and lower the vehicle. Tighten the wheel lug nuts to the specified torque in numerical order.

Torque: 118 N·m (87 lb ft)

CAUTION: Before installing wheels, remove any build-up of corrosion on the wheel mounting surface and brake disc mounting surface by scraping and wire brushing. Installing wheels without good metal-to-metal contact at mounting surfaces can cause wheel nuts to loosen, which can later allow a wheel to come off while the vehicle is moving.

NOTE: Valve caps should be on the valve stems to keep dust and water out.



480RS020

Tire

Tire Replacement

When replacement is necessary, the original metric the size should be used. Most metric tire sizes do not have exact corresponding alphanumeric tire sizes. It is recommended that new tires be installed in pairs on the same axle. If necessary to replace only one tire, it should be paired with tire having the most tread, to equalize braking traction.

CAUTION: Do not mix different types of tires such as radial, bias and bias-belted tires except in emergencies, because vehicle handling may be seriously affected and may result in loss of control.

Tire Dismounting

Remove valve cap on valve stem and deflate the tire. Then use a tire changing machine to mount or dismount tires. Follow the equipment manufacturer's instruction. Do not use hand tools or tire lever alone to change tires as they may damage the tire beads or wheel rim.

Tire Mounting

Rim bead seats should be cleaned with a wire brush or coarse steel wool to remove lubricants, and light rust. Before mounting a tire, the bead area should be well lubricated with an approved tire lubricant.

After mounting, inflate the tire to 196kPa (28 psi) so that beads are completely seated. Inflate the air to specified pressure and install valve cap to the stem.

WARNING: NEVER STAND OVER TIRE WHEN INFLATING. BEAD MAY BREAK WHEN BEAD SNAPS OVER RIM'S SAFETY HUMP AND CAUSE SERIOUS PERSONAL INJURY.

NEVER EXCEED 240 KPA (35 PSI) PRESSURE WHEN INFLATING. IF 240 KPA (35 PSI) PRESSURE WILL NOT SEAT BEADS, DEFLATE, RE-LUBRICATE AND RE-INFLATE. OVER INFLATION MAY CAUSE THE BEAD TO BREAK AND CAUSE SERIOUS PERSONAL INJURY.

Tire Repair

There are many different materials on the market used to repair tires.


Manufacturers have published detailed instructions on how and when to repair tires. These instructions can be obtained from the tire manufacturer if they are not included with the repair kit.

Wheel Inspection

Damaged wheels and wheels with excessive run-out must be replaced.

Wheel run out at rim (Base on hub Bore):

Steel	Aluminum
1- Vertical play: Less than 1.5 mm (0.059 in)	1- Vertical play: Less than 0.7 mm (0.028 in)
2- Horizontal play: Less than 1.5 mm (0.059 in)	2- Horizontal play: Less than 0.7 mm (0.028 in)



480RS012

General Balance Procedure


Deposits of mud, etc. must be cleaned from the inside of the rim.

The tire should be inspected for the following: match mount paint marks, bent rims, bulges, irregular tire wear, proper wheel size and inflation pressure. Then balance according to the equipment manufacturer's recommendations.

There are two types of wheel and tire balance.

Static balance is the equal distribution of weight around the wheel.

Assemblies that are statically unbalanced cause a bouncing action called tramp. This condition will eventually cause uneven tire wear.




480RS013

Legend

- (1) Heavy Spot Wheel Shimmy
- (2) Add Balance Weights Here

Dynamic balance is the equal distribution of weight on each side of the wheel center-line so that when the tire spins there is no tendency for the assembly to move from side to side. Assemblies that are dynamically unbalanced may cause shimmy.



480RS014

Legend

- (1) Heavy Spot Wheel Hop
- (2) Add Balance Weights Here


WARNING: STONES SHOULD BE REMOVED FROM THE TREAD TO AVOID OPERATOR INJURY DURING SPIN BALANCING AND TO OBTAIN A GOOD BALANCE.

Balancing Wheel and Tire**On-vehicle Balancing**

On-Vehicle balancing methods vary with equipment and tool manufacturers. Be sure to follow each manufacturer's instructions during balancing operation.

Off-vehicle Balancing

Most electronic off-vehicle balancers are more accurate than the on-vehicle spin balancers. They are easy to use and give a dynamic balance. Although they do not correct for drum or disc unbalance (as on-vehicle spin balancing does), they are very accurate.



480RS015


3E-14 WHEEL AND TIRE SYSTEM

Main Data and Specifications

General Specifications

Wheels	Size	15 x 6.5JJ	15 x 6.5JJ	16 x 7JJ
	Offset	38.0 mm (1.50 in)	38.0 mm (1.50 in)	38.0 mm (1.50 in)
	P.C.D., wheel studs	139.7 mm (5.50 in)	139.7 mm (5.50 in)	139.7 mm (5.50 in)
Standard tire	Size	P215/75R15	P235/75R15	P245/70R16
	Pressure(Front)	200 kPa (29 psi)	200 kPa (26 psi)	180 kPa (30 psi)
	Pressure(Rear)	200 kPa (29 psi)	200 kPa (26 psi)	180 kPa (35 psi)

Torque Specifications



E03RW004

RODEO

DRIVELINE/AXLE

CONTENTS

Differential (Front)	4A1-1
Differential (Rear)	4A2-1
Driveline Control System	4B-1
Drive Shaft System	4C-1
Transfer Case	4D-1

Differential (Front)

CONTENTS

Service Precaution	4A1-1	Installation	4A1-7
Front Drive Axle	4A1-2	Differential Assembly	4A1-8
Diagnosis	4A1-2	Disassembled View	4A1-8
Pinion Shaft Oil Seal	4A1-3	Disassembly	4A1-9
Pinion Shaft Oil Seal and Associated Parts	4A1-3	Reassembly	4A1-11
Removal	4A1-3	Differential Cage Assembly	4A1-19
Inspection and Repair	4A1-4	Disassembled View	4A1-19
Installation	4A1-4	Disassembly	4A1-19
Front Drive Axle Assembly	4A1-5	Inspection and Repair	4A1-20
Front Drive Axle Assembly and Associated Parts	4A1-5	Reassembly	4A1-20
Removal	4A1-6	Main Data and Specifications	4A1-22
		Special Tools	4A1-25

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM(SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE REFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specification. Following these instructions can help you avoid damage to parts and systems.


Front Drive Axle

Diagnosis

Condition	Possible cause	Correction
Oil Leak At Front Axle	Worn or defective oil seal.	Replace the oil seal.
	Front axle housing cracked.	Repair or replace.
Oil Leak At Pinion Shaft	Too much gear oil.	Correct the oil level.
	Oil seal worn or defective.	Replace the oil seal.
	Pinion flange loose or damaged.	Tighten or replace.
Noises In Front Axle Drive Shaft Joint	Broken or worn drive shaft joints and bellows (BJ and DOJ).	Replace the drive shaft joints and bellows.
“Clank” When Accelerating From “Coast”	Loose drive shaft joint to output shaft bolts.	Tighten.
	Damaged inner drive shaft joint.	Replace.
Shudder or Vibration During Acceleration	Excessive drive shaft joint angle.	Repair.
	Worn or damaged drive shaft joints.	Replace.
	Sticking spider assembly (inner drive shaft joint).	Lubricate or replace.
	Sticking joint assembly (outer drive shaft joint).	Lubricate or replace.
Vibration At Highway Speeds	Out of balance or out of round tires.	Balance or replace.
	Front end out of alignment.	Align.
Noises in Front Axle	Insufficient gear oil.	Replenish the gear oil.
	Wrong or poor grade gear oil.	Replace the gear oil.
	Drive pinion to ring gear backlash incorrect.	Adjust the backlash.
	Worn or chipped ring gear, pinion gear or side gear.	Replace the ring gear, pinion gear or side gear.
	Pinion shaft bearing worn.	Replace the pinion shaft bearing.
	Wheel bearing worn.	Replace the wheel bearing.
	Differential bearing loose or worn.	Tighten or replace.
Wanders and Pulls	Wheel bearing preload too tight.	Adjust the wheel bearing preload.
	Incorrect front alignment.	Adjust the front alignment.
	Steering unit loose or worn.	Tighten or replace.
	Tire worn or improperly inflated.	Adjust the inflation or replace.
	Front or rear suspension parts loose or broken.	Tighten or replace.
Front Wheel Shimmy	Wheel bearing worn or improperly adjusted.	Adjust or replace.
	Incorrect front alignment.	Adjust the front alignment.
	Worn ball joint or bush.	Replace the ball joint or bush.
	Steering unit loose or worn.	Tighten or replace.
	Tire worn or improperly inflated.	Replace or adjust the inflation.
	Shock absorber worn.	Replace the shock absorber.

Pinion Shaft Oil Seal

Pinion Shaft Oil Seal and Associated Parts



415RW012


Legend

- (1) Flange Nut
- (2) Flange
- (3) Oil Seal

- (4) Oil Seal Slinger
- (5) Outer Bearing
- (6) Collapsible Spacer

Removal


1. Raise the vehicle and support it at the frame.
The hoist must remain under the front axle housing.
2. Drain the front axle oil by loosening the drain plug(1).



412RS001


4A1-4 DIFFERENTIAL (FRONT)

3. Remove the front propeller shaft. Refer to Front Propeller Shaft in this section.
4. Remove flange nut by using pinion flange holder J-8614-01.



415RS018

5. Remove flange.
6. Remove oil seal.
7. Remove outer bearing by using remover J-39602.



415RS001

8. Remove collapsible spacer.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts.


1. Seal surface of the pinion.
2. Cage bore for burns.

Installation

1. Install collapsible spacer. Discard the used collapsible spacer and install a new one.
2. Install outer bearing.

NOTE: Do not drive in, but just temporarily set in the outer bearing by hand, which should be indirectly pressed in finally by tightening the flange nut.

3. Install oil seal, use oil seal installer J-24250 to install a new oil seal that has grease on seal lip.




415RS002

4. Install flange.
5. Install flange nut, refer to Differential Assembly Overhaul for flange nut reassembly in this section.

NOTE: Discard the used nut and install a new one.

Front Drive Axle Assembly

Front Drive Axle Assembly and Associated Parts



412RW056


Legend

- | | |
|---|--------------------------------------|
| (1) Propeller Shaft | (5) Mounting Bolt |
| (2) Mounting Nut | (6) Tie-rod End; Power Steering Unit |
| (3) Front Axle Case Assembly and Front Drive Shaft Assembly | (7) Knuckle and Back Plate |
| (4) Washer | (8) Hub and Disc Assembly |
| | (9) Suspension Crossmember |


4A1-6 DIFFERENTIAL (FRONT)

Removal

1. Jack up the vehicle and support it using jack stand.
2. Remove the tire and wheel.
3. Remove the stone guard.
4. Remove the brake caliper fixing bolt and hang the caliper. Refer to Disc Brakes in Brake section.
5. Remove the antilock brake system speed sensor. Refer to Front Wheel Speed Sensor in Brake section.
6. Remove the hub and disc assembly. Refer to Front Hub and Disc in this section.
7. Remove the propeller shaft, refer to Front Propeller Shaft in this section.
8. Loosen the height control arm of the torsion bar, then remove the torsion bar from lower control arm. refer to Torsion Bar in Suspension section.
9. Remove the suspension crossmember.
10. Remove the lower nut (1) of the stabilizer link.
11. Remove the lower bolt and nut (2) of the shock absorber.




12. Remove the tie-rod end from the knuckle. Refer to Power Steering Unit in Steering Section.
13. Disconnect the hose of the shift on the fly, at the hose clip portion (1).
14. Disconnect the shift switch connector (2).



15. Remove the bolts and nuts of the lower control arm (Frame side), then disconnect the lower control arm from frame.
16. Disconnect between the right side upper control arm and the knuckle, then remove the knuckle with lower control arm.

CAUTION: When removing the knuckle, be careful not to damage the oil seal inside of the knuckle.



17. Support the differential case by the jack.
18. Remove the front axle mounting bolts and nuts, lower the jack slowly. Remove the left side drive shaft end from the knuckle, then lower the axle assembly from the vehicle.

CAUTION:

1. During the work, be sure that the axle assembly is supported securely.
2. Be careful not to damage the bellows of the power steering unit by interference.
3. Be careful not to damage the hose bracket of the shift on the fly by interference.


Installation

1. Support the differential case by the jack.
2. Jack up the front drive axle assembly, install the left side drive shaft to the knuckle, then install the mount bolts and nuts.

CAUTION:

1. Be careful not to damage the bellows of the power steering unit by interference.
2. Be careful not to damage the hose bracket of the shift on the fly by interference.
3. When installing the drive shaft to the knuckle, be careful not to damage the oil seal inside of the knuckle.
3. Tighten the mounting bolts and nuts to the specified torque.

Torque: 168 N·m (124 lb ft)




4. Install the right side knuckle with lower control arm to the upper control arm.
Refer to Knuckle in Suspension section.

CAUTION: When insert the drive shaft to the knuckle, be careful not to damage the oil seal inside of the knuckle.

5. Align the bolt hole of the lower control arm, install the bolts and nuts.

NOTE: Adjust the buffer clearance before tighten the bolts and nuts of the lower control arm.

6. Install the hose of the shift on the fly (1).
7. Install the shift switch connector (2) of the shift on the fly.



8. Install the tie-rod end of the power steering unit to the knuckle, tighten the nut to the specified torque.

Torque: 118 N·m (87 lb ft)


9. Install lower bolts and nuts of the shock absorber, tighten it to the specified torque.

Torque: 93 N·m (69 lb ft)

10. Install lower nuts of the stabilizer link, tighten it to the specified torque.
11. Install the suspension crossmember.
12. Install the torsion bar.
Refer to Torsion Bar in Suspension section.
13. Install the front propeller shaft.
Refer to Front Propeller Shaft in this section.
14. Install the hub and disc assembly and adjust the bearing preload.
Refer to Front Hub and Disc in this section.
15. Install the wheel speed sensor of the antilock brake system.
16. Install the brake caliper. Tighten the bolt of the caliper bracket to the specified torque.
Torque: 50 N·m (37 lb ft)
17. Install the stone guard.
18. Install the tire and wheel.
19. Lower the vehicle, adjust the trim height.
Refer to Trim Height Adjustment in Steering section.
20. Tighten the bolts and nuts of the lower control arm to the specified torque.
Refer to Lower Control Arm in Suspension section.

Differential Assembly

Disassembled View




415RW007

Legend


- | | |
|------------------------------|-------------------------------|
| (1) Differential Assembly | (11) Collapsible Spacer |
| (2) Flange Nut | (12) Inner Bearing Outer Race |
| (3) Flange | (13) Inner Bearing |
| (4) Oil Seal | (14) Adjust Shim |
| (5) Oil Seal Slinger | (15) Pinion Gear |
| (6) Outer Bearing | (16) Diff Cage Assembly |
| (7) Outer Bearing Outer Race | (17) Side Bearing Outer Race |
| (8) Differential Carrier | (18) Side Bearing |
| (9) Bearing Cap | (19) Adjust Shim |
| (10) Bolt | (20) Bolt |
| | (21) Axle Case |

Disassembly


1. Remove differential carrier fixing bolt.
2. Remove differential assembly.
3. Using holding fixture J-37264 and holding fixture base J-3289-20, fix the differential assembly to the bench.




4. Remove bearing cap bolt.
5. Apply a setting mark to the side bearing cap and the differential carrier then remove bearing cap.



6. Remove differential cage assembly.
7. Remove side bearing outer race, after removal, keep the right and left hand side bearing assemblies separate to maintain inner and outer race combinations.
8. Remove side bearing, using remover J-42379 and adapter J-8107-2.
 - Select insert; 303173 and collet halves; 44801 in remover kit J-42379.




9. Remove adjust shim, note the thickness and position of the shims removed.
10. Remove the flange nut using holding wrench J-8614-01.




4A1-10 DIFFERENTIAL (FRONT)

11. Remove flange using an universal puller.
12. Remove the drive pinion assembly using a soft metal rod and a hammer.




425RS012

13. Remove collapsible spacer.
14. Remove the inner bearing using remover J-42379.
○Select insert; 303173 and collet halves; 44801 in remover kit J-42379.




415RW004

15. Remove adjust shim.
16. Remove oil seal.
17. Remove oil seal slinger.
18. Remove outer bearing.
19. Remove the inner bearing outer race (1) and the outer bearing outer race (2) by using a brass bar and a hammer.




425RS014




425RS015

Reassembly

1. Using installer J-7817 and grip J-8092, install outer bearing outer race.




2. Using installer J-7818 and grip J-8092, install Inner bearing outer race.



3. Install adjust shim and adjust drive pinion mounting distance:

1. Apply gear oil to the inner and outer drive pinion bearing.
Clean the pinion setting gauge set.
Then install the gauge set together with the inner and outer bearings.
2. Tighten the nut to the specified torque.

Torque: 2.3 N·m (20 lb in)




Legend

- (1) Pilot : J-21777-42
- (2) Pilot : J-42479-2
- (3) Gauge Plate : J-42479-1
- (4) Nut and Stud : J-21777-43

3. Clean the side bearing bores. Install the dial indicator with the discs and arbor. Install and tighten the bearing caps to the specified torque.

Torque: 97 N·m (72 lb ft)




Legend

- (1) Dial Indicator: J-8001
- (2) Gauge Plate: J-42479-1
- (3) Disc (2 pcs.): J-23597-8
- (4) Arbor: J-23597-1

4A1-12 DIFFERENTIAL (FRONT)

- Set the dial indicator to "0". Place it on the mounting post of the gauging arbor with the contact button touching the indicator pad. Force the dial indicator downward until the needle has made a half turn clockwise. Tighten down the dial indicator in this position.




Legend

- (1) Dial Indicator
- (2) Gauging Arbor
- (3) Plunger
- (4) Gauge Plate


- Position the plunger on the gauge plate. Move the gauging arbor slowly back and forth and locate the position at which the dial indicator shows the greatest deflection. At this point, once again set the dial indicator to "0".

Repeat the procedure to verify the "0" setting.



- After the ZERO setting is obtained, rotate the gauging arbor until the dial indicator rod does not touch the gauging plate.

Record the number the dial indicator needle points to.




Legend

- (1) Example=Dial indicator reading of 0.085

- Record the pinion depth code on the head of the drive pinion.

The number indicates a necessary change in the pinion mounting distance. A plus number indicates the need for a greater mounting distance (which can be achieved by decreasing the shim thickness). A minus number indicates the need for a smaller mounting distance (which can be achieved by increasing the shim thickness). If examination reveals pinion depth code "0", the pinion is "nominal".




8. Select the shim using chart;

Pinion marking Dial indicator reading (Inches)	+7	+6	+5	+4	+3	+2	+1	0	-1	-2	-3	-4	-5	-6	-7
0.023															0.030
0.024														0.030	0.030
0.025													0.030	0.030	0.032
0.026												0.030	0.030	0.032	0.032
0.027											0.030	0.030	0.032	0.032	0.034
0.028										0.030	0.030	0.032	0.032	0.034	0.034
0.029									0.030	0.030	0.032	0.032	0.034	0.034	0.036
0.030								0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036
0.031							0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038
0.032						0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038
0.033					0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040
0.034				0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040
0.035			0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042
0.036		0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042
0.037	0.030	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044
0.038	0.030	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044
0.039	0.032	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046
0.040	0.032	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046
0.041	0.034	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048
0.042	0.034	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048
0.043	0.036	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050
0.044	0.036	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050
0.045	0.038	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052
0.046	0.038	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052
0.047	0.040	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052	
0.048	0.040	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052		
0.049	0.042	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052			
0.050	0.042	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052				
0.051	0.044	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052					
0.052	0.044	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052						
0.053	0.046	0.046	0.048	0.048	0.050	0.050	0.052	0.052							
0.054	0.046	0.048	0.048	0.050	0.050	0.052									
0.055	0.048	0.048	0.050	0.050	0.052	0.052									
0.056	0.048	0.050	0.050	0.052	0.052										
0.057	0.050	0.050	0.052	0.052											
0.058	0.050	0.052	0.052												
0.059	0.052	0.052													
0.060	0.052														

4A1-14 DIFFERENTIAL (FRONT)

4. Place the shim on the drive pinion. Install the inner bearing onto the pinion using an installer J-6133-01 and a press.


NOTE: Do not apply pressure to the roller cage and apply pressure only to the inner race.



425RW036

5. Discard the used collapsible spacer and install a new one.
6. Install pinion gear.
7. Install outer bearing.
8. Install oil seal slinger.
9. Use oil seal installer J-24250 to install a new oil seal that has been soaked in front axle lubricant.

NOTE: Take care to use a front differential oil seal, NOT the rear differential oil seal.



415RS011


10. Install flange.

11. Install flange nut.

1. Apply lubricant to the pinion threads.
2. Tighten the nut to the specified torque using the pinion flange holder J-8614-01.

Torque: 217N·m (160 lb ft)

NOTE: Discard used flange nut and install new one and do not over tighten the flange nut.




415RW006

3. Adjust pinion bearing preload.

- a. Measure the bearing preload by using a torque meter. Note the scale reading required to rotate the flange.
- b. Continue tightening flange nut until the specified starting torque is obtained.

Starting torque: 1.2–1.9 N·m(10–17 lb in)


NOTE: Do not tighten the flange nut more than 678 N·m(500 lb ft).



425RW018

12. Install adjust shim.


1. Attach the side bearing to the differential assembly without shims. Support the opposite side using a pilot to prevent bearing damage.



Legend


- (1) Drive handle:J-8092
- (2) Installer:J-24244
- (3) Pilot:J-8107-2

2. Insert the differential cage assembly with bearing outer races into the side bearing bores of the carrier.




3. Using two sets of feeler gauges, insert a feeler stock of sufficient thickness between each bearing outer race and the carrier to remove all end play. Make certain the feeler stock is pushed to the bottom of the bearing bores.

Mount the dial indicator J-8001 on the carrier so that the indicator stem is at right angles to a tooth on the ring gear.



4. Adjust feeler gauge thickness from side to side until ring gear backlash is in the specified range.


Backlash: 0.13–0.20 mm(0.005 –0.008 in)




With zero end play and correct backlash established, remove the feeler gauge packs, determine the thickness of the shims required and add 0.025 mm (0.001 in) to each shim pack to provide side bearing preload. Always use new shims.

4A1-16 DIFFERENTIAL (FRONT)

5. Use bearing remover J-42379 and pilot J-8107-2 to remove side bearing.
○Select insert; 303173 and collet halves;44801 in remover kit J-42379.




13. Install the side bearings together with the selected shims.



Legend


- (1) Drive Handle: J-8092
- (2) Installer: J-24244
- (3) Pilot: J-8107-2

14. Install side bearing outer race.
15. Install differential cage assembly.
16. Install bearing cap then align the setting marks(1) applied at disassembly.




17. Tighten the cap bolt to the specified torque.

Torque: 97 N·m (72 lb ft)




Gear Tooth Contact Pattern Check and Adjustment

1. Apply a thin coat of prussian blue or equivalent to the faces of the 7-8 teeth of the ring gear. Check the impression of contact on the ring gear teeth and make necessary adjustment as described in illustration if the contact is abnormal.

**Legend**

- (1) Heel
- (2) Toe
- (3) Concave Side(Coast)
- (4) Convex Side(Drive)




4A1-18 DIFFERENTIAL (FRONT)

18. Install differential assembly.

1. Clean the faces of the front axle case and differential carrier.
Apply Three Bond TB1215 or equivalent to the sealing side of the axle case and the carrier.
2. Attach the differential case and the carrier assembly to the front axle case and tighten the nuts and bolts.

Torque: 25 N·m (19 lb ft)




3. Fill the axle case with hypoid gear lubricant, to just below the filler hole.

Lubricant capacity: 1.4 liter(1.48 US qt)

Differential Cage Assembly

Disassembled View



415RW010


Legend

- (1) Thrust Washer
- (2) Pinion Gear
- (3) Thrust Washer
- (4) Side Gear

- (5) Cross Pin
- (6) Ring Gear
- (7) Bolt
- (8) Differential Cage
- (9) Lock Pin

Disassembly


1. Remove bolt.
2. Remove ring gear.
3. Remove lock pin.



425RS042

4A1-20 DIFFERENTIAL (FRONT)

4. Remove the cross pin, using a soft metal rod and a hammer.



5. Remove pinion gear and thrust washer.
6. Remove side gear.
7. Remove thrust washer.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts.


1. Ring gear, pinion gear
2. Bearing
3. Side gear, pinion gear, cross pin
4. Differential cage, carrier
5. Thrust washer
6. Oil seal

Ring gear replacement:

1. The ring gear should always be replaced with the drive pinion as a set.
2. Discard used bolts and install new ones.


Torque: 108 N·m (80 lb ft)

3. Tighten the fixing bolts in a diagonal sequence as illustrated.




Reassembly

1. Install thrust washer.
2. Install side gear.
3. Install the pinion gear with thrust washer by engaging it with the side gears while turning both pinion gears simultaneously in the same direction.



4. Install cross pin.

- Be sure to install the cross pin so that it is in alignment with the lock pin hole in the differential cage.




425RS049

5. Install lock pin. After lock pin installation, stake the cage to secure the lock pin.

6. Install ring gear and tighten the bolts in diagonal sequence as illustrated.

Torque: 108 N·m (80 lb ft)

NOTE: Discard used bolts and install new ones.



415RS016


4A1-22 DIFFERENTIAL (FRONT)

Main Data and Specifications

General Specifications


Axle tube Type		It consists of the duct, a cast iron housing and the axle tube.
Gear type		Hypoid
Gear ratio	(to 1)	3.727 (6VD1 with A/T) 4.100 (6VD1 with A/T, 6VD1 with M/T) 4.300 (6VD1 with M/T) 4.555 (X22SE with M/T) 4.777 (X22SE with M/T)
Differential type		Two pinion
Oil capacity	liter (US qt)	1.25 (1.32) (Differential) 0.12 (0.13) (Actuator Housing: Shift on the fly)
Type of lubricant		GL-5 (75W-90)
Axle shaft type		Constant velocity joint (Birfield joint type and double off-set joint)
Hub locking Type		Rigid

Torque Specifications



E04RX001

4A1-24 DIFFERENTIAL (FRONT)



E04RW009

Special Tools













ILLUSTRATION	TOOL NO. TOOL NAME
 901HW0/1	J-8614-01 Holder; Pinion flange
 901RS220	J-24250 Installer; Oil seal
 901RS212	J-37264 Differential holding fixture (Use with J-3289-20 base)
 901RS212	J-3289-20 Holding fixture base
 901RW039	J-42379 Remover; Side/Pinion bearing
 901RS236	J-8107-2 Adapter; Side bearing plug

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS220	J-7817 Installer; Outer bearing outer race
 901RS220	J-7818 Installer; Inner bearing outer race
 901RS241	J-8092 Driver handle
 901RS220	J-21777-42 Pilot
 901RS221	J-21777-43 Nut and stud
 901RS223	J-42479-1 Gauge plate

4A1-26 DIFFERENTIAL (FRONT)








ILLUSTRATION	TOOL NO. TOOL NAME
 <p>901RS224</p>	<p>J-8001 Dial indicator</p>
 <p>901RS244</p>	<p>J-23597-8 Disc</p>
 <p>901RS226</p>	<p>J-23597-1 Arbor</p>
 <p>901RS227</p>	<p>J-6133-01 Installer; Pinion bearing</p>
 <p>901RS245</p>	<p>J-24244 Installer; Side bearing</p>
 <p>901RS230</p>	<p>J-39602 Remover; Outer bearing</p>

ILLUSTRATION	TOOL NO. TOOL NAME
 <p>901RS220</p>	<p>J-42479-2 Pilot</p>

DRIVELINE/AXLE

Differential (Rear)

CONTENTS

Service Precaution	4A2-1	Inspection and Repair	4A2-16
General Description	4A2-2	Reassembly	4A2-16
Diagnosis	4A2-3	Side Bearing Preload Adjustment	4A2-20
Axle Housing	4A2-5	Pinion Installation	4A2-21
Axle Housing and Associated Parts	4A2-5	Determination of Backlash & Preload Shims	4A2-22
Removal	4A2-5	Backlash Adjustment	4A2-23
Installation	4A2-7	Gear Tooth Pattern Check	4A2-23
Axle Shaft, Oil Seal and Bearing	4A2-7	Adjustments Affecting Tooth Contact	4A2-24
Axle Shaft and Associated Parts	4A2-7	Differential Case Assembly	4A2-25
Removal	4A2-8	Disassembled View	4A2-25
Inspection	4A2-8	Disassembly	4A2-26
Installation	4A2-8	Inspection and Repair	4A2-26
Pinion Oil Seal	4A2-10	Reassembly	4A2-26
Pinion Oil Seal and Associated Parts	4A2-10	Limited Slip Differential Assembly	4A2-27
Removal	4A2-10	Disassembled View	4A2-27
Inspection and Repair	4A2-11	Disassembly	4A2-27
Installation	4A2-11	Inspection and Repair	4A2-29
Differential Assembly	4A2-13	Reassembly	4A2-29
Disassembled View	4A2-13	Main Data And Specifications	4A2-31
Inspecting the Axle Before Disassembly ..	4A2-14	Special Tools	4A2-32
Disassembly	4A2-14		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM(SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE REFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specification. Following these instructions can help you avoid damage to parts and systems.

General Description

The rear axle assembly is of the semi-floating type in which the vehicle weight is carried on the axle housing. The center line of the pinion gear is below the center line of the ring gear (hypoid drive).

All parts necessary to transmit power from the propeller shaft to the rear wheels are enclosed in a Salisbury type axle housing (a carrier casting with tubes pressed and welded into the carrier). A removable aluminum cover at the rear of the axle housing permits rear axle service without removal of the entire assembly from the vehicle. The 8.9 inch ring gear rear axle uses a conventional ring and pinion gear set to transmit the driving force of the engine to the rear wheels. This gear set transfers this driving force at a 90 degree angle from the propeller shaft to the drive shafts.

The axle shafts are supported at the wheel end of the shaft by a roller bearing.

The pinion gear is supported by two tapered roller bearings. The pinion depth is set by a shim pack located between the gear end of the pinion and the roller bearing that is pressed onto the pinion. The pinion bearing preload is set by crushing a collapsible spacer between the bearings in the axle housing.

The ring gear is bolted onto the differential case with 10 bolts.

The differential case is supported in the axle housing by two tapered roller bearings. The differential and ring gear are located in relationship to the pinion by using selective shims and spacers between the bearing and the differential case. To move the ring gear, shims are deleted from one side and an equal amount are added to the other side. These shims are also used to preload the bearings which are pressed onto the differential case. Two bearing caps are used to hold the differential into the rear axle housing.

The differential is used to allow the wheels to turn at different rates of speed while the rear axle continues to transmit the driving force. This prevents tire scuffing when going around corners and prevents premature wear on internal axle parts.

The rear axle is sealed with a pinion seal, a seal at each axle shaft end, and by a liquid gasket between the rear cover and the axle housing.

Limited Slip Differential (LSD)

The axle assembly may be equipped with an limited slip differential (LSD). It is similar to the standard differential except that part of the torque from the ring gear is transmitted through clutch packs between the side gears and differential case.

The LSD construction permits differential action when required for turning corners and transmits equal torque to both wheels when driving straight ahead. However, when one wheel tries to spin due to a patch of ice, etc., the clutch packs automatically provide more torque to the wheel which is not trying to spin.

In diagnosing customer complaints, it is important to recognize two things:


1. If, both wheels slip, with unequal traction, the LSD has done all it can possibly do.
2. In extreme cases of differences in traction, the wheel with the least traction may spin after the LSD has transferred as much torque as possible to the non-slipping wheel.

Limited Slip Differentials impose additional requirements on lubricants, and require a special lubricant or lubricant additive. Use 80W90 GL-5 LSD lubricant.

Rear Axle Identification

The Bill of Material and build date information(1) is stamped on the right axle tube on the rearward side.

The axle ratio is identified by a tag(3) which is secured by a cover bolt. If the axle has limited-slip differential, it also will be identified with a tag(2) secured by a cover bolt.



425RX001

Diagnosis

Many noises that seem to come from the rear axle actually originate from other sources such as tires, road surface, wheel bearings, engine, transmission, muffler, or body drumming. Investigate to find the source of the noise before disassembling the rear axle. Rear axles, like any other mechanical device, are not absolutely quiet but should be considered quiet unless some abnormal noise is present.

To make a systematic check for axle noise, observe the following:

1. Select a level asphalt road to reduce tire noise and body drumming.
2. Check rear axle lubricant level to assure correct level, and then drive the vehicle far enough to thoroughly warm up the rear axle lubricant.
3. Note the speed at which noise occurs. Stop the vehicle and put the transmission in neutral. Run the engine speed slowly up and down to determine if the noise is caused by exhaust, muffler noise, or other engine conditions.
4. Tire noise changes with different road surfaces; axle noises do not. Temporarily inflate all tires to 344 kPa (50 psi) (for test purposes only). This will change noise caused by tires but will not affect noise caused by the rear axle.

Rear axle noise usually stops when coasting at speeds under 48 km/h (30 mph); however, tire noise continues with a lower tone. Rear axle noise usually changes when comparing pull and coast, but tire noise stays about the same.

Distinguish between tire noise and rear axle noise by noting if the noise changes with various speeds or sudden acceleration and deceleration. Exhaust and axle noise vary under these conditions, while tire noise remains constant and is more pronounced at speeds of 32 to 48 km/h (20 to 30 mph). Further check for tire noise by driving the vehicle over smooth pavements or dirt roads (not gravel) with the tires at normal pressure. If the noise is caused by tires, it will change noticeably with changes in road surface.

5. Loose or rough front wheel bearings will cause noise which may be confused with rear axle noise; however, front wheel bearing noise does not change when comparing drive and coast. Light application of the brake while holding vehicle speed steady will often cause wheel bearing noise to diminish. Front wheel bearings may be checked for noise by jacking up the wheels and spinning them or by shaking the wheels to determine if bearings are loose.
6. Rear suspension rubber bushings and spring insulators dampen out rear axle noise when correctly installed. Check to see that there is no link or rod loosened or metal-to-metal contact.

7. Make sure that there is no metal-to-metal contact between the floor and the frame.

After the noise has been determined to be in the axle, the type of axle noise should be determined, in order to make any necessary repairs.

Gear Noise

Gear noise (whine) is audible from 32 to 89 km/h (20 to 55 mph) under four driving conditions.

1. In drive under acceleration or heavy pull.
2. Driving under load or under constant speed.
3. When using enough throttle to keep the vehicle from driving the engine while the vehicle slows down gradually (engine still pulls slightly).
4. When coasting with the vehicle in gear and the throttle closed. The gear noise is usually more noticeable between 48 and 64 km/h (30 and 40 mph) and 80 and 89 km/h (50 and 55 mph).

Bearing Noise

Bad bearings generally produce a rough growl or grating sound, rather than the whine typical of gear noise. Bearing noise frequently "wow-wows" at bearing rpm, indicating a bad pinion or rear axle side bearing. This noise can be confused with rear wheel bearing noise.

Rear Wheel Bearing Noise

Rear wheel bearing noise continues to be heard while coasting at low speed with transmission in the neutral. Noise may diminish by gentle braking. Jack up the rear wheels, spin them by hand and listen for noise at the hubs. Replace any faulty wheel bearings.

Knock At Low Speeds

Low speed knock can be caused by worn universal joints or a side gear hub counter bore in the cage that is worn oversize. Inspect and replace universal joints or cage and side gears as required.

Backlash Clunk

Excessive clunk on acceleration and deceleration can be caused by a worn rear axle pinion shaft, a worn cage, excessive clearance between the axle and the side gear splines, excessive clearance between the side gear hub and the counterbore in the cage, worn pinion and side gear teeth, worn thrust washers, or excessive drive pinion and ring gear backlash. Remove worn parts and replace as required. Select close-fitting parts when possible. Adjust pinion and ring gear backlash.

4A2-4 DIFFERENTIAL (REAR)

Rear Axle Noise


Condition	Possible cause	Correction
Noise in Drive	Excessive pinion to ring gear backlash.	Adjust.
	Worn pinion and ring gear.	Replace
	Worn pinion .bearings.	Replace.
	Loose pinion bearings.	Adjust.
	Excessive pinion end play.	Adjust.
	Worn side bearings.	Replace.
	Loose side bearings.	Adjust.
	Excessive ring gear run-out.	Replace.
	Low oil level.	Replenish.
	Wrong or poor grade oil.	Replace.
	Bent axle housing.	Replace.
Noisy when coasting	Axle noise heard when driving will usually be heard also on coasting, although not as loud.	Adjust or replace.
	Pinion and ring gear too tight (audible when slowing down and disappears when driving).	Adjust.
Intermittent noise	Warped bevel ring.	Replace.
	Loose differential case bolts.	Tighten.
Constant noise	Flat spot on pinion or ring gear teeth.	Replace.
	Flat spot on bearing.	Replace.
	Worn pinion splines.	Replace.
	Worn axle shaft dowel holes.	Replace.
	Worn hub studs.	Replace.
	Bent axle shaft.	Replace.
Noisy on turns	Worn differential side gears and pinions.	Replace.
	Worn differential shaft.	Replace.
	Worn axle shaft splines.	Replace.

Limited Slip Differential

Condition	Possible cause	Correction
Does not lock	Broken clutch plates.	Replace the clutch plates.
Chatters in turns	Lubricant contaminated.	Drain lube when hot. Wipe carrier clean. Refill with lube specified in Main Data and Specifications at the end of this section.
	Clutch plates deteriorated.	Replace clutch plates.
Noise (in addition to normal clutch engagement)	Broken clutch plates.	Replace clutch plates.
	Damaged case.	Replace unit.
	Broken differential gears.	Replace gears.

Axle Housing

Axle Housing and Associated Parts




420RW030

Legend

- | | |
|--------------------------|--------------------|
| (1) Lower Link | (6) Lateral Rod |
| (2) Stabilizer | (7) Brake Hose |
| (3) Upper Link | (8) Coil Spring |
| (4) Rear Propeller shaft | (9) Parking Cable |
| (5) Shock Absorber | (10) Axle Assembly |

Removal


1. Raise the vehicle and support it with suitable safety stands.
The hoist must remain under the rear axle housing.
2. Take out brake fluid. Refer to Hydraulic Brakes in Brake section.
3. Remove rear wheels and tires. Refer to Wheel Replacement in Suspension section.
4. Remove propeller shaft. Refer to Rear Propeller Shaft in this section.
5. Drain the rear axle oil into a proper container.
6. Remove parking brake cable, release the connection between the cable fixing clip equalizer. Refer to Parking Brakes in Brake section.
7. Move the clip aside and pull out the breather hose.
8. Disconnect the ABS connectors (1) and remove the brackets attached to the frame and center link.



350RW023


4A2-6 DIFFERENTIAL (REAR)

9. Loosen the brake tube flare nut, remove the clip and take out the brake tube.




10. Remove the shock absorber.

11. Remove the stabilizer linkage mounting bolts and nuts (2) from the frame side.




12. Remove the lateral rod fixing bolt and nut from the frame.

13. Remove the upper link mounting bolt and nut (3) from the axle housing.



14. Remove the lower link fixing bolt and nut (4) from the axle housing.



15. Jack down and remove the coil spring and insulator.

16. Axle housing assembly can be separated from the vehicle on completion of steps 1 – 15.

17. Remove the brake caliper fixing bolt, loosen the flare nut, release the clip and take out the brake caliper together with the flexible hose.

18. Remove brake disc.

19. Remove antilock brake system speed sensor fixing bolt and the clip and bracket on the axle housing.

20. Remove the brake pipe clip and fixing bolt on the axle housing and take out the brake pipe.


Installation

1. Install brake pipe.
2. Connect Antilock brake system (ABS) speed sensor and harness, refer to 4-Wheel Anti-Lock Brake System (ABS) in Brake section.
3. Install brake disc.
4. Install brake caliper. Refer to Disk Brakes in Brake section.
5. Install axle housing assembly.
6. Install coil spring and insulator.
7. Install the lower link fixing bolt and nut to the axle housing. For the procedures in items 7–11, refer to Suspension section.
8. Install the upper link bolt and nut to the axle housing.
9. Install the lateral rod fixing nut and bolt to the frame side.
10. Install the stabilizer linkage mounting nut and bolt to the frame side.
11. Install the shock absorber.
12. Install brake tube flare nut, Refer to Disk Brakes in Brake section.
13. Install ABS connector and bracket.
14. Connect breather hose.
15. Install parking brake cable, Refer to Parking Brakes in Brake section.
16. Bleed brakes. Refer to Hydraulic Brakes in Brake section.

Axle Shaft, Oil Seal and Bearing

Axle Shaft and Associated Parts


Disc Brake Model



Legend

- (1) Axle Shaft
- (2) Backing Plate
- (3) Oil Seal
- (4) Bearing
- (5) Axle Housing
- (6) Lock Washer
- (7) Nut

Drum Brake Model




Legend

- (1) Axle Shaft
- (2) Backing Plate
- (3) Oil Seal
- (4) Bearing
- (5) Axle Housing
- (6) Lock Washer
- (7) Nut

420RX001


Removal

1. Raise the vehicle.
2. Remove rear wheels and brake calipers or drums.
Do not let calipers hang from the vehicle by the brake line or hose. Wire them to frame of vehicle to prevent damage.
3. Remove four nuts and lockwashers.
4. Remove shaft assembly from the axle housing.
5. Remove snap ring and bearing cup.
6. Break retainer ring with hammer and chisel.




420RS026

7. Break bearing cage with hammer and chisel.



420RS027

8. Remove oil seal, retainer, and emergency brake assembly.
9. Remove inner race from shaft with OTC-1126 bearing splitter and press.




420RS028

Inspection

- Shaft for spalling or grooves from seal wear.
- Retainer – bent or damaged.
- Replace items if required.

Installation


1. Emergency brake assembly.
2. Install retainer.
Note direction – do not install backwards.



420RS029


3. Install oil seal. Note direction.

4. Install bearing assembly, using installer and press.




420RS030

NOTE: Install bearing with cup towards inboard side.



420RS031

5. Install retainer ring, using installer and press.



420RS033

6. Install snap ring.

7. Install axle shaft assembly into housing.


8. Install bolts, lockwashers, and nuts.

Tighten the retainer nuts to the specified torque.

Torque : 75 N-m (55 lb ft)

Pinion Oil Seal

Pinion Oil Seal and Associated Parts



420RW013


Legend

- (1) Flange Nut and Washer
- (2) Flange

- (3) Oil Seal
- (4) Outer Oil Seal Slinger
- (5) Outer Pinion Bearing (Cup and Cone)


Removal

1. Remove the rear propeller shaft. Refer to Rear Propeller Shaft in this section.
2. Drain the rear axle oil.
3. Check and record preload with an inch pound torque wrench. This will give combined pinion bearing, seal, carrier bearing, axle bearing and seal preload.




425RW018


4. Remove flange nut and washer by using pinion flange holder J-8614-01 after raising up its staked parts completely.



5. Remove flange by using SST J-8614-1 ~ 3.
 ○Have a suitable container in place to catch lubricant.



6. Remove oil seal.
 7. Remove pinion oil seal slinger.
 8. Remove outer bearing by using remover J-39602.



9. Remove collapsible spacer.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts.

1. Seal surface of the flange.
2. Cage bore for burns.


Installation

1. Install collapsible spacer, discard the used collapsible spacer and install a new one.
2. Install outer bearing.

4A2-12 DIFFERENTIAL (REAR)

NOTE: Do not drive in, but just temporarily set in the outer bearing by hand, which should be indirectly pressed in finally by tightening the flange nut.


3. By using the seal installer J-37263, install a new oil seal (1) that has grease on seal lip.



4. Install flange.

5. The pinion washer and a new nut while holding the pinion flange with J-8614-01.

- Tighten the nut until the pinion end play is just taken up. Rotate the pinion while tightening the nut to seat the bearings. Once there is not end play in the pinion, the preload torque should be checked.
- Remove J-8614-01. Using an inch-pound torque wrench, check to make sure the pinion preload is equal to or slightly over the reading recorded during removal.




6. Install propeller shaft to the flange.

7. Install bolt and nut. Tighten the bolt and nut to the specified torque.

Torque: 63 N·m (46 lb ft)

Differential Assembly

Disassembled View



420RW018

Legend

- | | |
|---|---|
| (1) ABS Speed Sensor | (17) Lock Pin |
| (2) Housing | (18) Axle Vent |
| (3) Outer Pinion Bearing (Cup and Cone) | (19) Gasket |
| (4) Outer Oil Slinger | (20) Cover and Clip Assembly |
| (5) Oil Seal | (21) Fill Plug (with Magnet) |
| (6) Companion Flange Assembly | (22) Mounting Bracket |
| (7) Pinion Nut Washer | (23) Side Bearing Cap Bolt |
| (8) Pinion Nut | (24) Side Bearing Cap |
| (9) Collapsible Spacer | (25) Drive Gear Bolts |
| (10) Baffle Plate | (26) Differential Adjustment Shims (Side Bearing Preload and Ring Gear/Pinion Backlash) |
| (11) Inner Pinion Bearing (Cup and Cone) | (27) Side Bearing (Cup and Cone) |
| (12) Inner Oil Slinger | (28) Differential Shaft |
| (13) Pinion gear adj. Shim-Selective (Position) | (29) Differential Side Gears |
| (14) Ring gear and Pinion Gear Assembly | (30) Side Gear Thrust Washer |
| (15) Exciter Ring | (31) Pinion Mate Gears |
| (16) Differential Case | (32) Thrustwasher-Differential Pinion Mate Gear |


Inspecting the Axle Before Disassembly

1. Remove the axle cover from the rear axle and drain the axle lubricant into a suitable container.
2. Check ring gear backlash. Refer to "BACKLASH ADJUSTMENT" in this section. This information can be used to determine the cause of the axle problem. It will also help when setting up the shim packs for locating and preloading the differential cage.
3. Check case for metal chips and shavings. Determine where these chips and shavings come from, such as a broken gear or bearing cage.
 - If possible, determine the cause of the axle problem before disassembly.

Disassembly

1. Remove axle shafts.
 - Refer to axle shaft replacement in this section.
2. Remove ABS sensor.
3. Remove bearing caps and bolts.
 - Mark the caps and the housing as left and right.


CAUTION: Bearing caps are machined with the housing and must be assembled in the same position as removed. Note the matched letter stamped on the caps and carrier. When assembled, the letters on the caps must agree in both the horizontal and vertical position with the letters on the carrier.



420RW003

4. Remove Differential case.

- Pry the case from the axle housing at the differential "window".




420RW010

5. Remove side bearing outer races and shims.

- Mark the races and shims as left and right, and place them with the bearing cups.

6. Remove differential side bearings using remover J-42379 and plug J-39830.

- Select insert ; 303174 and collet halves ; 44801 in remover kit J-42379.




415RW003

7. Remove ring gear bolts.

- Ring gear bolts use right handed threads.


CAUTION: DO not pry the ring gear from the case. This will damage the ring and the differential case.

8. Remove ring gear from the differential.
 - Drive the ring gear off with a brass drift if necessary.
 - Check drive pinion bearing preload.



425RW018


- Check the pinion assembly for looseness by moving it back and forth. (Looseness indicates excessive bearing wear.)
9. Remove pinion flange nut and washer.
 - Use flange holder J-8614-01 to hold the pinion flange.
 10. Remove pinion flange.
 - Use flange holder J-8614-01 to remove the pinion flange.



415RS018


11. Remove pinion from the axle housing.
 - Thread the pinion nut halfway onto the pinion.
 - Drive the pinion out of the housing with a hammer and a soft drift.
 - Remove the nut and then remove the pinion.

12. Remove collapsible spacer(1).



415RW011

13. Remove outer seal, outer oil slinger and outer pinion bearing.
14. Remove inner bearing, inner oil slinger and shim from the pinion.
 - Press the bearing off the pinion using remover J-42379.




415RW004

- Select insert ; 303174 and collet halves ; 44801 in remover kit J-42379.
 - Remove the shim.
15. Remove bearing cups and baffle plate from the axle housing using a hammer and a punch.
 - Work the cups out of the housing evenly, moving the punch back and forth between one side of the cup and the other.
 - The baffle plate will be destroyed and should be replaced with a new one.
 16. Remove exciter ring.
 - Remove the exciter ring from the differential using a mallet or a brass hammer if it is required.

4A2-16 DIFFERENTIAL (REAR)

NOTE: Discard the exciter ring after removal.



Cleaning

Do not steam clean drive parts which have ground and polished surfaces such as gears, bearings, and shafts. These parts should be cleaned in a suitable solvent. All parts should be disassembled before cleaning. Parts should be thoroughly dried immediately after cleaning. Use soft, clean, lintless rags. Parts may be dried with compressed air. Do not allow the bearings to spin while drying them with compressed air.

Inspection and Repair

It is very important to carefully and thoroughly inspect all drive unit parts before reassembly. Thorough inspection of the drive parts for wear or stress and subsequent replacement of worn parts will eliminate costly drive component repair after reassembly.

Axle Housing

- The carrier bore for nicks or burrs that would prevent the outer diameter of the pinion seal from sealing. Remove any burrs that are found.
- The bearing cap bores for nicks or burrs. Remove any burrs that are found.
- The housing for cracks. Replace the housing if any cracks are found.
- The housing for foreign material such as metal chips, dirt, or rust.

Pinion and Ring Gear

- Pinion and ring gear teeth for cracking, chipping, scoring, or excessive wear.
- Pinion splines for wear.
- Pinion flange splines for wear.
- The sealing surface of the pinion flange for nicks, burrs, or rough tool marks which would cause damage to the seal's inside diameter and result in an oil leak.
- Replace all worn or broken parts.

- Ring and pinion gears are matched sets and are both replaced anytime a replacement of either is necessary.

Bearings

- Bearings visually and by feel.
- The bearings should feel smooth when oiled and rotated while applying as much hand pressure as possible.
The large end of the bearing rollers for wear.
This is where tapered roller bearing wear is most evident.
- Bearing cups for wear, cracks, brinelling and scoring.
- Bearing and cups are only replaced as sets.
- If the rear axle was operated for an extended period of time with very loose bearings, the ring gear and drive pinion will also require replacement.
- Low mileage bearings may have minute scratches and pits on the rollers and the bearing cups from the initial pre-load. Do not replace a bearing for this reason.
- Bearing cups for cracks or chips.


Shims


- Shims for cracks and chips. Damaged shims should be replaced with an equally sized service shim.

Reassembly

1. Install pinion bearing races and baffle plate using outer bearing race installer J-8611-01 / inner bearing race installer J-42836 and drive handle J-8592.

NOTE: Baffle plate must be installed, when install the inner pinion bearing race.






2. Clean all the gauge parts.
3. Lubricate the outer and inner bearings with axle lubricant.
4. Place the bearings into the pinion bearing races.
5. Place the inner oil slinger onto the inner pinion bearing.

NOTE: The inner oil slinger must be placed between gauge plate and inner pinion bearing when measuring the pinion depth.

6. Install gauge plate J-39837-2, inner J-42827 stud and nut J-21777-43 and outer pilot J-42824 to the pinion bore.




7. Hold the stud stationary at the flats of the stud (and).

Tighten the stud nut

Torque: 2.2 N·m (1.6 lb ft)

8. Rotate the gauge plate and bearings several complete revolutions to seat the bearings.
9. Tighten the stud nut until a torque of 1.6 to 2.2 N·m (1.2 to 1.6 lb ft.) is required to keep the gauge plate in rotation.
10. Assemble discs J-39837-1, arbor J-23597-1 and dial indicator J-8001 to the side bearing bores.

NOTE: The bearing bores must be clean and burr-free.



11. Install the side bearing caps and tighten the bolts to the specified torque.


Torque: 108 N·m (80 lb ft)

12. Rotate the gauge plate until the gauging area is parallel with the discs.
13. Position the arbor assembly in the carrier so that the plunger is centered on the gauge area of the gauge plate.

4A2-18 DIFFERENTIAL (REAR)

14. Set the dial indicator to "0". Place it on the mounting post of the gauging arbor with the contact button touching the indicator pad.

Force the dial indicator downward until the needle has made a half turn clockwise. Tighten down the dial indicator in this position.




Legend

- (1) Dial Indicator
- (2) Gauging Arbor
- (3) Plunger
- (4) Gaug Plate


15. Position the plunger on the gauge plate. Move the gauging arbor slowly back and forth and locate the position at which the dial indicator shows the greatest deflection. At this point, once again set the dial indicator to "0".

Repeat the procedure to verify the "0" setting.



16. After the ZERO setting is obtained, rotate the gauging arbor until the dial indicator rod does not touch the gauging plate.

Record the number the dial indicator needle points to.




Legend

- (1) Example=Dial indicator reading of 0.085

17. Record the pinion depth code on the head of the drive pinion.

The number indicates a necessary change in the pinion mounting distance. A plus number indicates the need for a greater mounting distance (which can be achieved by decreasing the shim thickness). A minus number indicates the need for a smaller mounting distance (which can be achieved by increasing the shim thickness). If examination reveals pinion depth code "0", the pinion is "nominal".



18. Select the shim using the chart;


Dial Indicator Reading (inches)	Marking (inches)						
	+3	+2	+1	0	-1	-2	-3
0.027							0.030
0.028						0.030	0.031
0.029					0.030	0.031	0.032
0.030				0.030	0.031	0.032	0.033
0.031			0.030	0.031	0.032	0.033	0.034
0.032		0.030	0.031	0.032	0.033	0.034	0.035
0.033	0.030	0.031	0.032	0.033	0.034	0.035	0.036
0.034	0.031	0.032	0.033	0.034	0.035	0.036	0.037
0.035	0.032	0.033	0.034	0.035	0.036	0.037	0.038
0.036	0.033	0.034	0.035	0.036	0.037	0.038	0.039
0.037	0.034	0.035	0.036	0.037	0.038	0.039	0.040
0.038	0.035	0.036	0.037	0.038	0.039	0.040	0.041
0.039	0.036	0.037	0.038	0.039	0.040	0.041	0.042
0.040	0.037	0.038	0.039	0.040	0.041	0.042	0.043
0.041	0.038	0.039	0.040	0.041	0.042	0.043	0.044
0.042	0.039	0.040	0.041	0.042	0.043	0.044	0.045
0.043	0.040	0.041	0.042	0.043	0.044	0.045	0.046
0.044	0.041	0.042	0.043	0.044	0.045	0.046	0.047
0.045	0.042	0.043	0.044	0.045	0.046	0.047	0.048
0.046	0.043	0.044	0.045	0.046	0.047	0.048	0.049
0.047	0.044	0.045	0.046	0.047	0.048	0.049	0.050
0.048	0.045	0.046	0.047	0.048	0.049	0.050	0.051
0.049	0.046	0.047	0.048	0.049	0.050	0.051	0.052
0.050	0.047	0.048	0.049	0.050	0.051	0.052	0.053
0.051	0.048	0.049	0.050	0.051	0.052	0.053	
0.052	0.049	0.050	0.051	0.052	0.053		
0.053	0.050	0.051	0.052	0.053			
0.054	0.051	0.052	0.053				
0.055	0.052	0.053					
0.056	0.053						

4A2-20 DIFFERENTIAL (REAR)


19. Remove bearing caps and depth gauging tools.
20. Install the correct pinion shim and inner oil slinger onto pinion.

NOTE: Do not install pinion gear into housing at this time.

21. If the exciter ring was removed, install the new exciter ring onto the differential case by pressing using the ring gear as a pilot.



22. Install ring gear(1) to the differential case(2)




23. Install new ring gear bolts.

- Tighten the ring gear bolts alternately in stages, gradually pulling the ring gear onto the differential case.

Tighten the ring gear bolts in sequence


Torque: 108 N·m (80 lb ft)

NOTE: Discard used bolts and install new ones.



Side Bearing Preload Adjustment


1. The side bearing preload adjustment must be made before installing the pinion.
2. The side bearing preload is adjusted by changing the thickness of both the left and right shims equally. This maintains the original backlash.
3. Install master side bearings J-39836 onto the case. Remove all nicks, burrs, dirt etc., from the hubs to allow the master bearings to rotate freely.



4. Assemble the differential case into the housing (less pinion). Install bearing caps and finger tight bolts. Mount a dial indicator with a magnetic base to the housing and indicate on the flange or head of screw. Force the differential assembly as far as possible in the direction towards the indicator.

With force still applied, set indicator at zero(0).


NOTE: Dial indicator set should be capable of a minimum travel of 5.08 mm (0.2 in).



5. Force the differential assembly as far as it will go in the opposite direction. Repeat these steps until the same reading is obtained.
6. RECORD THE READING OF THE INDICATOR.
This amount, in shims, will be included in the final assembly shim stack to establish side bearing preload and ring gear and pinion backlash.
7. After marking sure the readings are correct, remove the indicator and differential assembly from the housing.

Pinion Installation

- The bearing cups should have been installed in Pinion Depth Adjustment in this section.
- 1. Place the shim(1) and inner oil slinger(2) on the pinion gear, then install the pinion inner bearing(3) using installer J-42828.




- Drive the bearing until the bearing cone seats on the pinion shims.
- 2. Install a new collapsible spacer.
○ Lubricate the pinion bearings with axle lubricant.
- 3. Install pinion to the axle housing.
- 4. Install outer pinion bearing onto the pinion.
○ Hold the pinion forward from inside the case while driving the bearing onto the pinion.
- 5. Install oil seal slinger.
- 6. Install pinion oil seal using installer J-37263.
- 7. Install the pinion flange to the pinion by tapping it with a rawhide hammer until a few threads show through the pinion flange.
- 8. Install pinion washer and a new nut while holding the pinion flange with flange holder J-8614-01.
○ Tighten the nut until the pinion end play is just taken up. Rotate the pinion while tightening the nut to seat the bearings.

Torque: 217-678 N-m (160-500 lb ft)

Once there is no end play in the pinion, the preload torque should be checked.

- Remove flange holder J-8614-01. Using an inch-pound torque wrench, check the pinion preload by rotating the pinion with the wrench.

4A2-22 DIFFERENTIAL (REAR)



Preload should be at 1.0 to 1.6 N·m (8 to 14 in lbs.) on new bearings, or 0.46 to 0.69 N·m (4 to 6 in lbs.) for used bearings.


- If the preload torque is below the preloads given above, continue torquing the nut in small increments. Check the preload after each tightening. Each tightening increases the bearing preload by several pounds. If the bearing preload is exceeded, the pinion will have to be removed, and a new collapsible spacer installed.
- Once a preload of 1.0 to 1.4 N·m (8 to 12 in lbs.) has been obtained, rotate the pinion several times to assure that the bearings have seated. Recheck the preload, and adjust if necessary.

Determination of Backlash & Preload Shims

1. Install master side bearings onto the case.
2. Install differential assembly into the carrier.
3. Install the bearing cap and finger tight bolts.
4. Set up the dial indicator.
5. Force the differential assembly away from the pinion gear until it is completely seated against the cross bore face of the carrier.
6. With force still applied to the differential case, place the tip of dial indicator on a machined surface of the differential case, if available, or on the head of a ring gear screw, and set the indicator at zero(0).
7. Force the ring gear to mesh with the pinion gear. Rock the ring gear slightly to make sure the gear teeth are meshed. Repeat this procedure several times until the same reading is obtained each time. Be sure the indicator reads zero(0) each time the ring gear is forced back into contact with the cross bore face. This reading will be the necessary amount of shims to be placed between the differential case and side bearing cone on the ring gear side.


8. The remaining amount of shims, which is the difference between the overall found in step 6 of Side Bearing Pre-load Adjustment and step(7) above, should be placed on the other side of the differential case, plus additional 0.38 mm (0.015 in) for obtaining preload and backlash.

9. Place the required amount of shims on each hub as determined in the previous steps and assemble side bearing cone by using installer J-21784 and handle J-8592.



10. Total torque to rotate — Increase of pinion torque to rotate due to differential case assembly shall not exceed 3.4 N·m (30 in lbs.) divided by the gear ratio.

11. Assemble the spreader J-24385-B and indicator to the carrier as shown in figure. Spread the carrier 0.5 mm (0.02 in) for differential installation.



CAUTION: Do not spread the carrier over 0.5 mm (0.02 in).

12. Remove the indicator.


Backlash Adjustment

1. Install the differential case assembly and bearing caps.
2. Rotate the case several times to seat the bearings.
3. Remove the spreader.
4. Install the side bearing cap bolts.

Tighten side bearing cap bolts

Torque: 108 N-m (80 lb ft)

5. Install a dial indicator to the case using a magnetic base.
6. Place the indicator stem at the heel end of a tooth.
 - Set the dial indicator so that the stem is in line with the gear rotation and perpendicular to the tooth angle.



7. Check and record the backlash at three points around the ring gear.

○ The pinion must be held stationary when checking backlash.

○ The backlash should be the same at each point within 0.07 mm (0.003 in). If the backlash varies more than 0.07 mm (0.003 in), check for burrs, a distorted case flange, or uneven bolting conditions.

8. Backlash at the minimum lash point measured should be between 0.13 and 0.20 mm (0.005 and 0.008 in) for all new gear sets.

9. If the backlash is not within specifications, move the ring gear in or out from the pinion by increasing the thickness of one shim, and decreasing the thickness of the other shim by the same amount.

This will maintain the correct rear axis side bearing preload.

○ Moving 0.05 mm (0.002 in) worth of shim from one side of the differential to the other will change the backlash adjustment by 0.03 mm (0.001 in).

10. After obtaining correct tooth contact described in later, install ABS speed sensor.

11. Install the cover with sealant.


Torque: 40 N-m (30 lb ft)

12. Fill the axle lubricant.

Gear Tooth Pattern Check

Checking the ring gear to pinion tooth pattern is to be done only after setting up the axle according to the methods in this section. The pattern check is NEVER to be used as an initial check, or instead of checking pinion depth and backlash adjustments.


This check is only to be verify the correct adjustment of the gear set after set up.



Legend

- (1) Heel
- (2) Toe
- (3) Concave Side (Coast)
- (4) Convex Side (Drive)

1. Wipe all oil out of the carrier, and carefully clean each tooth of the ring gear.
2. Use gear marking compound 1052351 or equivalent and apply this mixture sparingly to all ring gear teeth, using a medium-stiff brush. When properly used, the area of pinion tooth contact will be visible when hand load is applied.
3. Tighten the bearing cap bolts to the specified torque.
4. Expand the brake shoes until a torque of 54 to 68 N-m (40 to 50 lb ft.) is required to turn the pinion. A test made without loading the gears will not give a satisfactory pattern. Turn the pinion flange with a wrench so that the ring gear rotates one full revolution, then reverse the rotation so that the ring gear rotates one revolution in the opposite direction.
5. Observe the pattern on the ring gear teeth and compare this with figure.



425RS039

Adjustments Affecting Tooth Contact

Two adjustments can be made which will affect tooth contact pattern: backlash, and the position of the drive pinion in the case. The effects of bearing preloads are not readily apparent on head loaded tooth contact pattern tests; however, these adjustments should be within specifications before proceeding with backlash and drive pinion adjustments.

The position of the drive pinion is adjusted by increasing or decreasing the distance between the pinion head and the centerline of the ring gear.

Decreasing the distance will move the pinion closer to the centerline of the ring gear. Increasing the distance will move the pinion farther away from the centerline of the ring gear.


Backlash is adjusted by means of the side bearing adjusting shims which move the entire case and ring gear assembly closer to, or farther from, the drive pinion. (The adjusting shims are also used to set side bearing preload.)

If the thickness of the right shim is increased (along with decreasing the left shim thickness), backlash will increase.

The backlash will decrease if the left shim thickness is increased (along with a decrease in right shim thickness).

Differential Case Assembly

Disassembled View



425RW014


Legend

- (1) Thrust Washer (for Pinion Gear)
- (2) Pinion Mate Gear
- (3) Thrust Washer (for Side Gear)
- (4) Side Gear

- (5) Differential Shaft
- (6) Lock Pin
- (7) Bolt
- (8) Differential Case


Disassembly

1. Remove lock pin using a small drift.



425RS096

2. Remove the differential shaft by using a soft metal rod and a hammer.



425RS043

3. Remove pinion mate gear and thrust washer.
4. Remove side gear and thrust washer.

Inspection and Repair


Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts.

- ☐ Ring gear, pinion gear
- ☐ Bearing
- ☐ Side gear, pinion mate gear, differential shaft
- ☐ Differential case, carrier
- ☐ Thrust washer
- ☐ Oil seal

Reassembly


1. Install side gear with thrust washer.
2. Install the pinion mate gear with thrust washer by engaging it with the side gears while turning both pinion mate gears simultaneously in the same direction.



425RS046

3. Install differential shaft.

1. Be sure to install the differential shaft so that it is in alignment with the lock pin hole in the differential case.




425RS049

4. Install lock pin.

After lock pin installation, stake the case to secure the lock pin.

Limited Slip Differential Assembly

Disassembled View




425RW004

Legend

- | | |
|---|---------------------------------|
| (1) Thrust Washer—Differential Pinion Mate Gear | (6) Differential Plate Retainer |
| (2) Pinion Mate Gear | (7) Lock Pin |
| (3) Dished Spacer | (8) Differential Case |
| (4) Disc | (9) Ring Gear Bolts |
| (5) Plate | (10) Differential Shaft |
| | (11) Differential Side Gear |

Disassembly

- Place the holder J-39824 into a vise.
Position the differential on the holder with the ring gear side down.
- Remove Lock pin (1) from differential shaft using a punch.
- Remove Differential shaft (2) using hammer and punch.
Place shop towel behind case to prevent differential shaft from dropping out of case.




425RW005

4A2-28 DIFFERENTIAL (REAR)


4. Assemble clutch pack unloading tool .

- Install cap J-34174-1 to the bottom differential side gear.
- Install threaded screw cap J-34174-2 to top differential side gear. Thread forcing screws J-22342-15 into threaded screw cap until it becomes centered into the bottom cap.



- Tighten forcing screw until tight enough to collapse dished spacers and allow looseness between side and pinion mate gears.

5. Both pinion mate gear thrust washers using a shim stock (1) of 0.51 mm (0.020 in.) or equivalent tool to push out washers.




6. Relieve tension of dished spacers by loosening forcing screw.

NOTE:


- You may have to adjust the forcing screw slightly to allow the case to rotate.

7. Assemble LSD service adapter J-39834 onto long drive handle J-8592. Insert it into differential shaft hole of case. Pull on handle and rotate case until pinion mate gears can be removed.



8. Remove pinion mate gears.

9. Hold side gear top clutch pack (1) with one hand and remove positraction unloading tools.



10. Remove top side gear and clutch pack.


NOTE:

- Keep the stack of plates and discs intact and in exactly the same position while they are being removed.
11. Remove case from holder. Turn case with flange or ring gear side up to allow side gear and clutch pack to be removed from case.

12. Remove differential plate retainer from both clutch packs to allow separation of the plates and discs.

NOTE:

- Keep the discs and plates in the same order as they were removed.



425RW009

Legend

- (1) Differential Plate
- (2) Differential Disc
- (3) Dished Spacer
- (4) Side Gear

Inspection and Repair

Cleaning

- All parts with solvent.

Visual Inspection

- Clean all parts with solvent.
- Plates and Discs. If any one disc or plate in either stack shows evidence of excessive wear or scoring, the complete stack is to be replaced on both sides.
- Side Gears and Pinion Mate Gears. The gear teeth of these parts should be checked for extreme wear and possible cracks. The external teeth of the side gear, which retain the concentric groove discs, should also be checked for wear or cracks.
- If replacement of one gear is required due to wear, etc., then both side gears, pinion mate gears, and thrust washers are to be replaced.
- Differential Shaft. If excessive wear is evident, the differential shaft should be replaced.
- Differential Plate Retainers. If wear is evident on any one of the differential plate retainers, all four retainers must be replaced.
- Differential Case. If scoring, wear or metal pickup is evident on the machined surfaces, replacement of the case is necessary.

Reassembly


1. Lubricate thrust face of side gears, plates and discs with the proper limited slip rear axle lubricant.
2. Assemble plates and discs in exactly in the same position as they were removed, regardless of whether they are new or original.
3. Install differential plate retainer to ears of plates.

NOTE:

- Make sure both retainers are Completely seated on ears of plates.
- 4. Install clutch pack and side gear into bottom side gear bore. Make sure clutch pack stays assembled to side gear splines, and that retainers are completely seated into pockets of case.

NOTE:

- To prevent clutch pack from falling out of case, hold clutch pack in place by hand while repositioning case on bench.
- 5. Install other side gear and clutch pack. Make sure clutch pack stays assembled to side gear splines, and retainers are completely seated into pockets of case.
- 6. Hold clutch pack in position and assemble screw cap J-34174-2, cap J-34174-1 and forcing screw J-22342-15. Tighten forcing screw into bottom cap to hold both clutch packs in position.
- 7. With tools assembled to case, position case on holder J-39824 by aligning splines of side gear with those of shaft. Tighten forcing screw to compress clutch packs in order to provide clearance for pinion mate gears.




901RW069

8. Install pinion mate gears.

- Place the pinion mate gears into the differential 180 degrees apart.


4A2-30 DIFFERENTIAL (REAR)

9. While holding gears in place, insert LSD service adapter J-39834 with long drive handle J-8592 in differential shaft hole of case. Pull on long drive handle J-8592 and rotate case, allowing gears to turn. Make sure that holes in pinion mate gears align with holes in case.




○It may be necessary to adjust tension on forcing screw to rotate case.

10. Tighten forcing screw to compress the clutch packs, to allow installation of spherical thrust washers.
11. Lubricate spherical thrust washers (2), and assemble into case (1). Use a small screw driver to push washers into place. Remove tools.



12. Position differential shaft in case and drive in with hammer. Be sure lock pin hole of differential shaft (5) is properly aligned to allow installation of lock pin (3). Be sure that thrust washers and differential pinion mate gears are aligned with the differential case (4). Install new lock pin to proper depth using a punch. Stake metal of case over pin in two places, 180 degrees apart.




Main Data And Specifications

General Specifications

Rear axle	
Type	Salisbury, Semi-floating
Rear axle Size	226 mm (8.9 in)
Gear type	Hypoid
Gear ratio (to 1)	3.727 (6VD1 with A/T) 4.100 (6VD1 with A/T, 6VD1 with M/T) 4.300 (6VD1 with M/T) 4.555 (X22SE with M/T) 4.777 (X22SE with M/T)
Differential type	Two pinion
Lubricant Grade	GL-5: (Standard differential)
	GL-5, LSD: (Limited slip differential)
Locking Differential Lubricant	80W90 GL-5 (USE Limited Slip Differential Gear Lubricant or Friction Modifier Organic Additive)
Capacity	1.77 liter (1.87 US qt)

4A2-32 DIFFERENTIAL (REAR)

Torque Specifications



E04RX002

Special Tools













ILLUSTRATION	TOOL NO. TOOL NAME
 901RW037	J-8614-01 Pinion flange holder
 901RS211	J-37263 Installer; Pinion oil seal
 901RW039	J-42379 Remover; Bearing
 901RS215	J-39830 Adapter; Side bearing plug
 901RS217	J-8611-01 Installer; Outer bearing outer race
 901RS218	J-8592 Grip

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS219	J-42836 Installer; Inner bearing outer race
 901RS220	J-42824 Pilot; Outer
 901RS221	J-21777-43 Nut & Stud
 901RS222	J-42827 Pilot; Inner
 901RS223	J-39837-2 Gauge plate
 901RS224	J-8001 Dial indicator

4A2-34 DIFFERENTIAL (REAR)











ILLUSTRATION	TOOL NO. TOOL NAME
 901RS225	J-39837-1 Disc (2 required)
 901RS226	J-23597-1 Arbor
 901RS208	J-42828 Installer; Pinion bearing
 901RS229	J-21784 Installer; Side bearing
 901RS230	J-39602 Remover; Outer bearing
 901RW170	J-24385-B Spreader

ILLUSTRATION	TOOL NO. TOOL NAME
 901RW064	J-39858 Clutch pack unloading tool kit Includes J-34174-1/J-34174-2 Screw cap and Cap J-22342-15 Forcing screw
 901RW065	J-39834 Limited-slip differential (LSD) service adapter
 901RW066	J-39824 Holder
 901RS225	J-39836 Side bearing preload master bearings

RODEO

DRIVELINE/AXLE

DRIVELINE CONTROL SYSTEM

CONTENTS

Service Precaution	4B-1	Shift On The Fly Vacuum Piping and	
Shift On The Fly System	4B-2	Electrical Equipment	4B-17
Outline of Shift on The Fly System	4B-2	Vacuum Piping Diagram	4B-17
System Diagrams	4B-2	Inspection and Repair	4B-18
Normal Operation	4B-3	Vacuum Piping	4B-18
Retrial	4B-4	Check Valve	4B-18
Functions of Indicator Lamp	4B-6	VSV Assembly	4B-19
Diagnosis	4B-7	Functional Detective Switch	4B-19
Before Judging That Troubles Occur		Motor Actuator Assembly	4B-19
(Unfaulty mode)	4B-7	Transfer Position Switch	4B-20
Parts Location	4B-8	4WD Control Unit	4B-21
Wiring Diagram	4B-9	4WD Control Unit Associated Parts	4B-21
Connector List	4B-11	Removal	4B-22
Diagnosis of The Faults Based on		Installation	4B-22
the Status of 4WD Indicator Lamp,			
4WD Switch and T/F Change Lever	4B-12		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Shift On The Fly System


Outline of Shift on The Fly System

The shift on the fly system switches between 2 wheel drive (2WD) and 4 wheel drive (4WD) electrically by driver's pressing the 4WD switch (push button type) on instrument panel.

This system controls below operations. (Shifting between "4H" and "4L" must be performed by transfer control lever on the floor.)

1. Shifting the transfer front output gear (Connecting to, and disconnecting from, front propeller shaft by motor actuator).
2. Retrial of shifting the transfer front output gear.
3. Connecting front wheels to, and disconnecting them from, the front axles by vacuum actuator.
4. Indicator on instrument panel.
5. 4WD out signal to other Electronic Hydraulic Control Unit.

System Diagrams




412RX004

Normal Operation

The motor actuator mounted on transfer rear case is driven by signal from 4WD switch on instrument panel. After complete the connecting transfer front output gear to, or disconnecting it from, front propeller shaft, condition

of the transfer position switch changes. The vacuum solenoid valve (VSV) is driven by the signal from transfer position switch and the vacuum actuator connects front wheels to, or disconnect them from, front axles.

Time Chart of Shifting Under Normal Condition



F04RW002


4B-4 DRIVELINE CONTROL SYSTEM

Retrial

The motor actuator starts transfer gear shifting after signal from 4WD switch on instrument panel has been received. But the shifting may be impossible in cold weather or under high speed condition. When 2 seconds have passed since transfer gear shifting started and the transfer position switch dose not turn on (the gear engagement is not completed), the motor reverses its rotation for 1.2 seconds and tries again to shift transfer

gear. This procedure is repeated 3 times in maximum. While this procedure, 4WD indicator lamp blinks by 2 Hz. If the transfer position switch does not turn on after aforementioned procedure has been repeated 3 times, the gear shifting is stopped and 4WD indicator lamp's blinking changes from 2Hz to 4Hz to notify driver that the gear shifting is stopped. This blinking of indicator lamp continues until 4WD switch is returned from 4WD to 2WD.

Time Chart of Shifting Under Severe Condition (retrial)




F04RX004

Warning at “4L” position : In view of the shifting mechanism of transfer, the gear shifting from 4WD to 2WD at “4L” condition is impossible. Therefore, the transfer position switch can not be turned off by 4WD

switch when vehicle is in “4L” condition. In the case this condition continues for 2 seconds, the shifting to 2WD is stopped and the indicator lamp's blinking changes from 2Hz to 4Hz to notify driver of wrong operation.

Time Chart of Shifting from 4WD to 2WD at “4L” Condition



F04RX005

4WD out signal to other Electronic Hydraulic Control

Unit : ECU of shift on the fly sends 4WD out signal to other Electronic Hydraulic Control Unit as below.

4WD out signal (Period)	Vehicle Condition	Transfer position switch	Front axle switch
120 ms	2WD	2WD (Open)	2WD (Open)
240 ms	4WD	4WD (Close)	4WD (Close)

4B-6 DRIVELINE CONTROL SYSTEM


Functions of Indicator Lamp

Indication of vehicle condition : Indicator lamp is controlled by ECU of shift on the fly and shows vehicle conditions as below.

Indicator	Vehicle condition	4WD switch	Transfer position switch	Front axle switch
Off	2WD	Off (Close)	2WD (Open)	2WD (Open)
On	4WD	On (Open)	4WD (Close)	4WD (Close)
Blink (2Hz)	Operating	On (Open)	4WD (Close)	2WD (Open)
		Off (Close)	2WD (Open)	4WD (Close)
Blink (4Hz)	Stop operating	On (Open)	2WD (Open)	2WD (Open)
		Off (Close)	4WD (Close)	4WD (Close)

Bulb check : The bulb of indicator lamp is checked for 2 seconds when ignition key is turned on.

Time Chart of Bulb Checking



F04RW004

Retrials from 2WD to 4WD : In cold weather or under high speed condition, the gear shifting (engagement) sometimes dose not complete by 3 trials. In such case, the indicator lamp inform driver of this incident as aforementioned chart (shown at Retrial in Outline of shift on the fly system.)

Diagnosis

Before Judging That Troubles Occur (Unfaulty mode)

When Switching from 2WD to 4WD

1. In case that blinking frequency of the 4WD indicator changes from 2Hz to 4Hz.

When heavy synchronization load is needed, the motor actuator tries the shifting transfer gear three times including the activation shifting. While the motor actuator tries shifting, the indicator blinks by 2Hz. If the third shifting fails, the indicator's blinking changes from 2Hz to 4Hz at the same time that the motor actuator shifted back to 2WD.

Heavy synchronization load occurs by

- extremely lower temperature.
- higher speed.rotation difference of wheels during cornering.

Solution 1: Operate again after stop the vehicle or slow down.

2. In case that the 4WD indicator continues blinking by 2Hz for more than 11.5 seconds.

When there is rotation difference of wheels or there is phase difference between front wheels and axles, it is difficult to connect front wheels to front axles. The blinking by 2Hz shows that shifting the transfer gear or connecting the front wheels is in the middle of operating. In above case, the indicator's blinking by 2Hz shows that connecting the front wheels is not completed (because the indicator's blinking changes to 4Hz when the shifting transfer gear is impossible.). And removal of rotation or phase difference make connecting the front wheels possible.

Solution 2: When vehicle is running, drive straight ahead while accelerating and decelerating. When vehicle is at a stop, move the vehicle forward and backward from 2 to 3 meters.

When Switching from 4WD to 2WD

1. In case that the 4WD indicator continues blinking by 2Hz .

The 4WD indicator continues blinking by 2Hz until both shifting the transfer gear and disconnecting the front wheels are completed when switching 4WD to 2WD. When drive line is loaded with torsional torque, the shifting transfer gear and disconnecting front wheels are impossible. In this case, removal of torsional torque on drive line make the shifting transfer gear and disconnecting front wheels possible.

Solution 3: When vehicle is running, drive straight ahead while accelerating and decelerating. When vehicle is at a stop, move the vehicle forward and backward from 2 to 3 meters.


2. In case that the 4WD indicator's blinking changes from 2Hz to 4Hz.

Check the position of transfer lever. Is it at "4L" position? In view of the shifting mechanism of transfer, the gear shifting from 4WD to 2WD at "4L" condition is impossible.

Solution 4: Push the 4WD switch to 4WD, shift the transfer lever to "High" position and re-operate the 4WD switch to 2WD.

4B-8 DRIVELINE CONTROL SYSTEM

Parts Location




D08RX116


Legend

- | | |
|----------------------|----------------------|
| (1) Battery | (10) C-32 |
| (2) Fuse & Relay Box | (11) I-19 |
| (3) C-4 | (12) B-19 |
| (4) M-11 | (13) C-16 |
| (5) B-8 | (14) H-15, H-32 |
| (6) C-31 | (15) H-18 |
| (7) I-1 | (16) C-15 |
| (8) Starter Switch | (17) M-12 |
| (9) I-2 | (18) H-9, H-10, H-11 |



















Wiring Diagram



4B-10 DRIVELINE CONTROL SYSTEM



Connector List

No.	Connector face	No.	Connector face
B-8		H-11	
B-19		H-15	
C-4		H-18	
C-15		H-32	
C-16		I-1	
C-31		I-2	
C-32		I-19	
H-9		M-11	
M-10		M-12	

4B-12 DRIVELINE CONTROL SYSTEM

Diagnosis of The Faults Based on the Status of 4WD Indicator Lamp, 4WD Switch and T/F Change Lever

Diagnosis charts are shown on below. If troubles can not be solved after every chart was traced, troubles may occur in the ECU. In this case, replace the ECU and trace every chart again.

Fault on Switching from 2WD to 4WD

1. In case that 4WD indicator's blinking changes from 2Hz to 4Hz after Solution 1 is carried out.

Faults occur in the motor actuator or the transfer case assembly. Remove the motor actuator and check function. If problem was found and it was repaired, try **Solution 1** again. After that, disassemble the transfer case assembly for check and repair or replace. If incident is not improved after above mentioned actions were taken, replace the ECU.

2. In case that 4WD indicator dose not blink nor light, when switching from 2WD to 4WD.

Step	Action	Yes	No
1	Is ignition turned on?	Go to Step 2	Turn on the ignition and trace this chart from start.
2	Dose the indicator light during two seconds initialization after ignition is turned on?	Go to Step 3	Burning out of indicator lamp or disconnection of harness wire. Trace this chart from the start after repair or replace.
3	Is the 4WD switch turned from 2WD to 4WD?	Short-circuit (body short) on harness of the 4WD switch. Fault of the 4WD switch (holding the closed condition). Trace this chart from the start after repair or replace.	Push the 4WD switch to 4WD.

3. Case that the indicator keeps blinking by 2Hz after aforementioned Solution 2 is carried out.

Step	Action	Yes	No
1	Check the air pressure and wear of all tires. Were problems found?	Try Solution 2 after adjust the air pressure and replace worn tires.	Go to Step 2
2	Can the transfer lever be operated from High to 4L or vice versa?	Go to Step 3	Disconnection of the motor actuator harness wiring. Trace this chart from the start after repair or replace. Faults on the motor actuator. Trace this chart from the start after replace. Internal faults of transfer case. Disassemble the transfer case for check. Trace this chart from the start after repair or replace.
3	Pull out the hoses from vacuum actuator and operate 4WD switch. Is there negative pressure on either of hoses?	Go to Step 4	Faults on the transfer position switch or its harness. Trace this chart from the start after repair or replace. Faults on the VSV main body, its harness or vacuuming system. Trace the diagnosis chart in Front Axle ASM section. After that, trace this chart from the start.
4	Check the axle switch. Were problems found?	Internal faults on axle switch. Trace this chart from the start after replace.	Disconnection on the axle harness. Trace this chart from the start after repair or replace. Faults on Front Axle ASM. Trace the diagnosis chart in Front Axle ASM section. After that, trace this chart from the start.

4B-14 DRIVELINE CONTROL SYSTEM

Fault on Switching from 4WD to 2WD

1. Case that indicator dose not blink nor turn out.

Step	Action	Yes	No
1	Dose the indicator turn out by ignition off?	Go to Step 2	Short circuit of the indicator harness.
2	Is the 4WD switch on 2WD position?	Disconnection on the 4WD switch harness or breakdown of the 4WD switch in open state. Trace this chart from the start after repair or replace.	Turn the 4WD switch to 2WD position. Trace this chart from the start.

2. Case that indicator keeps 2Hz blinking after aforementioned Solution 3 is carried out.

Step	Action	Yes	No
1	Check the air pressure and wear of all tires. Were problems found?	Try Solution 3 after adjust the air pressure and replace worn tires.	Go to Step 2
2	Can the transfer lever be operated from High to 4L or vice versa?	Faults on the harness wiring of motor actuator. Trace this chart from the start after repair or replace. Internal faults on transfer case. Disassemble the transfer case for check. Trace this chart from the start after repair or replace. Faults on the motor actuator. Trace this chart from the start after or replace.	Go to Step 3
3	Pull out the hoses from vacuum actuator and operate 4WD switch. Is there negative pressure on either of hoses?	Go to Step 4	Faults on the transfer position switch or its harness. Trace this chart from the start after repair or replace. Faults on the VSV main body, its harness or vacuuming system. Trace the diagnosis chart in Front Axle ASM section. After that, trace this chart from the start.
4	Check the axle switch. Were problems found?	Internal faults on axle switch. Trace this chart from the start after replace. Faults on Front Axle ASM. Trace the diagnosis chart in Front Axle ASM section. After that, trace this chart from the start.	Short circuit (body short) or disconnection of the axle harness. Trace this chart from the start after repair or replace.


4B-16 DRIVELINE CONTROL SYSTEM

3. Case that indicator's blinking changes to 4Hz after aforementioned Solution 4 is carried out.


Step	Action	Yes	No
1	Can the transfer lever be operated from High to 4L or vice versa?	Faults on the harness wiring of motor actuator. Trace this chart from the start after repair or replace. Faults on the motor actuator. Trace this chart from the start after replace. Internal faults on transfer case. Disassemble the transfer case for check. Trace this chart from the start after repair or replace.	Faults on the ECU. Trace this chart from the start after replace.

Shift On The Fly Vacuum Piping and Electrical Equipment


Vacuum Piping Diagram



Actuator Assembly




Vacuum Tank



Inspection and Repair

Vacuum Piping




C04RW004

1. Pull out the Hose A in figure and install a vacuum gauge.
2. Plug up Hose B in figure to prevent the leak of vacuum.
3. Start the engine and measure vacuum 2 or 3 minutes afterward.
4. Repeat 1) and 2) but with Hose A plugged and Hose B pulled out.
5. If vacuum measures -400mmHg , or if it shows a sudden drop immediately after engine stop, inspect the hose, tank, and pipe for damage.

NOTE: Be careful not to permit the entry of dust and water during inspection.

6. Pull out Hose D in above illustration.
7. Plug Hose E in above illustration.
8. Make sure that Hose D in above illustration is under atmospheric pressure.
9. Pull out Hose E and plug Hose D, and make sure that Hose E is under atmospheric pressure.
10. If Check 8) or 9) has revealed stoppage, check and see that there is no bend, foreign matter in the hose or in the filter. If there is trouble, repair or replace.

Check Valve



C04RS004


1. Apply vacuum from the orange colored side(1).

Vacuum: -400mmHg

2. Check leakage of vacuum.
3. Make sure that vacuum cannot be applied from the black colored side(2).
4. If vacuum is not applicable as much as -400mmHg , and if there is resistance on the intake side, replace with a new check valve.

VSV Assembly

Inspect the vehicle side harness as follows:



412RW026

Legend


- (1) Grey
- (2) Blue

1. Remove connector.
2. Shift transfer lever to 2H and start the engine.

NOTE: The vehicle should not be started, with the engine idling.

3. Make sure that there is continuity in the vehicle side of harness. If there is no continuity, check transfer shift switch and wiring.

Inspect the both VSVs as follows



F04RS004

1. With battery not connected (Usual).

A-C:There is continuity

B:Closed


2. With battery connected

A – B:There is continuity

C:Closed

3. If 1) and 2) fail, replace with a new VSV.

Functional Detective Switch



412RS046

1. With ball (1) being free

A-B:There is continuity

2. With ball forced into the switch

A-B:No continuity


3. If 1) and 2) fail, replace with a new switch.

Motor Actuator Assembly

Inspect the function of the motor actuator assembly as follows:

1. Disassemble the motor actuator from transfer rear case.

4B-20 DRIVELINE CONTROL SYSTEM




412RW037

Legend

- (3) Shift Rod
- (4) Connector

2. Connect the terminals as shown in figure.

Shift rod of the motor actuator moves and stops at 4WD position.




412RX001

Legend

- (1) 2WD
- (2) 4WD
- (3) Shift Rod
- (4) Connector

3. Connect the terminals as shown in figure.

Shift rod of the motor actuator moves and stops at 2WD position.




412RX002

Legend

- (1) 2WD
- (2) 4WD
- (3) Shift Rod
- (4) Connector

4. If 2) and 3) fail, replace with a new motor actuator.

Transfer Position Switch



412RW040

Legend

- (1) Ball

1. With ball being free.

A-B : There is continuity.


2. With ball forced into the switch.

A-B : No continuity.

3. If 1) and 2) fail, replace with a new switch.

4WD Control Unit

4WD Control Unit Associated Parts




412RW042

Legend

- (1) Center Console Assembly
- (2) 4WD Control Unit

Removal

1. Remove center console assembly.
Refer to Interior Trim in Body and Accessories section.
2. Remove two screws and harness connector (1) from 4WD control unit.



Legend

- (1) Harness Connector

Installation

1. Connect harness connector, then install 4WD control unit.
2. Install center console assembly.

RODEO

DRIVELINE/AXLE

DRIVE SHAFT SYSTEM

CONTENTS

Service Precaution	4C-1	Main Data and Specifications	4C-26
General Description	4C-2	Special Tools	4C-28
Diagnosis	4C-2	Propeller Shaft	4C-29
Front Hub and Disc (2WD Model)	4C-3	General Description	4C-29
Disassembled View	4C-3	Universal Joint	4C-30
Disassembly	4C-3	Diagnosis of Propeller Shaft and	
Inspection and Repair	4C-4	Universal Joint	4C-31
Reassembly	4C-5	Front Propeller Shaft	4C-32
Front Hub and Disc (4WD Model)	4C-8	Front Propeller Shaft and Associated Parts	4C-32
Disassembled View	4C-8	Removal	4C-32
Disassembly	4C-8	Installation	4C-32
Inspection and Repair	4C-9	Disassembly	4C-33
Reassembly	4C-10	Universal Joint Disassembly	4C-34
Front Drive Shaft Joint	4C-13	Inspection and Repair	4C-35
Front Drive Shaft Joints Replacement	4C-13	Universal Joint Reassembly	4C-36
Front Axle Drive Shaft	4C-14	Reassembly	4C-37
Front Axle Drive Shaft and Associated		Main Data and Specifications	4C-38
Parts	4C-14	Rear Propeller Shaft	4C-39
Disassembly	4C-15	Rear Propeller Shaft and Associated Parts	4C-39
Inspection And Repair	4C-16	Removal	4C-39
Bushing Replacement	4C-16	Installation	4C-39
Reassembly	4C-16	Slip Joint Disassembly	4C-40
Shift On The Fly System	4C-19	Universal Joint Disassembly	4C-41
Shift On The Fly System and Associated		Inspection	4C-43
Parts	4C-19	Universal Joint Reassembly	4C-44
Disassembly	4C-19	Slip Joint Reassembly	4C-45
Inspection And Repair	4C-21	Main Data and Specifications	4C-46
Reassembly	4C-24		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM(SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

This publication contains essential removal, installation, adjustment and maintenance procedures. The front axle utilizes a central disconnect type front axle/transfer case system.


The drive axles are completely flexible assemblies, consisting of inner and outer constant velocity (CV) drive shaft joints connected by an axle shaft. For description of front propeller shaft and universal joint, refer to Front Propeller Shaft in this section.

Diagnosis

Condition	Possible cause	Correction
Oil Leak At Front Axle	Worn or defective oil seal.	Replace the oil seal.
	Front axle housing cracked.	Repair or replace.
Oil Leak At Pinion Shaft	Too much gear oil.	Correct the oil level.
	Oil seal worn or defective.	Replace the oil seal.
	Pinion flange loose or damaged.	Tighten or replace.
Noises In Front Axle Drive Shaft Joint	Broken or worn drive shaft joints and bellows (BJ and DOJ).	Replace the drive shaft joints and bellows.
"Clank" When Accelerating From "Coast"	Loose drive shaft joint to output shaft bolts.	Tighten.
	Damaged inner drive shaft joint.	Replace.
Shudder or Vibration During Acceleration	Excessive drive shaft joint angle.	Repair.
	Worn or damaged drive shaft joints.	Replace.
	Sticking spider assembly (inner drive shaft joint).	Lubricate or replace.
	Sticking joint assembly (outer drive shaft joint).	Lubricate or replace.
Vibration At Highway Speeds	Out of balance or out of round tires.	Balance or replace.
	Front end out of alignment.	Align.
Noises in Front Axle	Insufficient gear oil.	Replenish the gear oil.
	Wrong or poor grade gear oil.	Replace the gear oil.
	Drive pinion to ring gear backlash incorrect.	Adjust the backlash.
	Worn or chipped ring gear, pinion gear or side gear.	Replace the ring gear, pinion gear or side gear.
	Pinion shaft bearing worn.	Replace the pinion shaft bearing.
	Wheel bearing worn.	Replace the wheel bearing.
	Differential bearing loose or worn.	Tighten or replace.
Wanders and Pulls	Wheel bearing preload too tight.	Adjust the wheel bearing preload.
	Incorrect front alignment.	Adjust the front alignment.
	Steering unit loose or worn.	Tighten or replace.
	Tire worn or improperly inflated.	Adjust the inflation or replace.
	Front or rear suspension parts loose or broken.	Tighten or replace.
Front Wheel Shimmy	Wheel bearing worn or improperly adjusted.	Adjust or replace.
	Incorrect front alignment.	Adjust the front alignment.
	Worn ball joint or bush.	Replace the ball joint or bush.
	Steering unit loose or worn.	Tighten or replace.
	Tire worn or improperly inflated.	Replace or adjust the inflation.
	Shock absorber worn.	Replace the shock absorber.

Front Hub and Disc (2WD Model)

Disassembled View




411RX001

Legend

- | | |
|----------------------|---------------------------|
| (1) Bolt | (6) Hub and Disc Assembly |
| (2) Cover and Gasket | (7) ABS Sensor Ring |
| (3) Lock Washer | (8) Inner Bearing |
| (4) Hub Nut | (9) Oil Seal |
| (5) Outer Bearing | (10) Bolt |
| | (11) Wheel Pin |

Disassembly


- Before disassembly, jack up the front of vehicle and support frame with jack stands.
- Remove the two bolts from the rear side of the knuckle arm, then remove the brake caliper, with the brake hose attached.
Use a wire to attach the brake caliper to the upper link. Refer to Disk Brakes in Brake section.
- Remove cover bolt.
- Remove cover and gasket.
- Remove lock washer.
- Remove hub nut, using front hub nut wrench J-36827.




901RW054

4C-4 DRIVE SHAFT SYSTEM


7. Remove outer bearing.
8. Remove oil seal.
9. Remove inner bearing.
10. Use a brass bar to remove the outer bearing outer race(1), oil seal, inner bearing and inner bearing outer race(2) from the hub.




11. Remove bolt.
12. If necessary, replace the wheel pin in the following manner.
 - Scribe mark(1) on hub to disc before disassembly to insure proper assembly.



- Clamp hub and disc assembly in vise, using protective pads. Remove six(6) disc-to-hub retaining bolts.



- Place hub on a suitable work surface and remove wheel studs, as required, using a hammer.



Inspection and Repair

Check the following parts for wear, damage or other abnormal conditions.

- Hub
- Hub bearing
- Bearing outer race
- Disc
- Oil seal


Reassembly

1. Install wheel pin.

○Place hub on a wood workbench or a block of wood approx. 6" by 6" to protect the wheel stud ends and threads.


○Install wheel stud, using a hammer.

NOTE: Be sure wheel stud is started squarely and seats completely.



411RS005

2. Align index marks(1) and install hub to disc.




411RS003

3. Install bolt.

Tighten the bolts to the specified torque.


Torque: 103 N-m (76 lb ft)



411RS021

4. Install outer bearing.

Install the outer race by driving it into the hub by using installer J-36828 and grip J-8092.




901RW056

4C-6 DRIVE SHAFT SYSTEM

5. Install inner bearing.


Install the outer race by driving it into the hub by using installer J-36829 and grip J-8092.



411RS023

6. Install oil seal by using installer J-36830 and grip J-8092.

Apply Multipurpose grease NLGI No. 2 or equivalent to the lip portion.




901RW057

7. Apply Multipurpose grease NLGI No.2 in the hub and bearing.

Hub	35 g (1.23 oz)
Outer bearing	10 g (0.35 oz)
Inner bearing	15 g (0.53 oz)

8. Install hub nut by using wrench J-36827.

Turn the place where there is a chamfer in the tapped hole to the outer side, and attach the nut.



901RW054


Preload Adjustment

1. Tighten the hub nut to 29.4 N·m (21.7 lb ft), then loosen the nut to the full.
2. Tighten the hub nut to the value given below, using a spring scale on the wheel pin.

Bearing Preload

New bearing and New oil seal	19.6 – 24.5 N (4.4 – 5.5 lb)
Used bearing and New oil seal	11.8 – 17.7 N (2.6 – 4.0 lb)

If the measured bearing preload is outside the specifications, adjust it by loosening or tightening the bearing nut.




411RS011

9. Install lock washer.

- Turn the side with larger diameter of the tapered bore to the vehicle outer side, then attach the washer.

If the bolt holes in the lock plate are not aligned with the corresponding holes in the nut, reverse the lock plate. If the bolt holes are still out of alignment, turn in the nut just enough to obtain alignment. Screw is to be fastened tightly so its head may come lower than the surface of the washer.




10. Install cover and tighten the cover bolt.

11. Install brake caliper and tighten fixing bolt.

Front Hub and Disc (4WD Model)

Disassembled View



411RW001


Legend

- | | |
|--------------------------------|---------------------------|
| (1) Bolt | (7) Outer Bearing |
| (2) Cap | (8) Bolt |
| (3) Snap Ring and Shim | (9) Hub and Disc Assembly |
| (4) Hub Flange | (10) Wheel Pin |
| (5) Lock Washer and Lock Screw | (11) ABS Sensor Ring |
| (6) Hub Nut | (12) Inner Bearing |
| | (13) Oil Seal |

Disassembly


- Before disassembly, select the 2WD position with the 4WD switch.
- Jack up the front of vehicle and support frame with jack stands.
- Remove the disc brake caliper assembly and hang it on the frame with wires. Refer to Disk Brakes in Brake section.
- Remove Bolt.
- Remove cap.
- Remove snap ring and shim.
- Remove hub flange.

8. Remove lock washer and lock screw.
9. Use wrench J-36827, remove hub nut.




901RW054

10. Remove hub and disc assembly.
11. Remove ABS sensor ring.
12. Remove outer bearing.
13. Remove oil seal.
14. Remove inner bearing.
15. Remove bolt, if necessary, replace the wheel pin in the following manner.
 - Apply a scribe mark(1) to disc to hub.
 - Clamp the hub and disc assembly in a vise, using protective pads. Remove the 6 disc-to-hub retaining bolts.



411RS003

- Place hub on a suitable work surface and remove the studs by using a hammer.



411RS004

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts.

- Hub
- Hub bearing oil seal
- Knuckle spindle
- Disc
- Caliper
- Shift on the fly system parts (Cap, Hub flange, Shim, Snap ring)
- ABS sensor ring

For inspection and servicing of disc caliper and related parts, refer to Disc Brakes in Brake section.


Reassembly

1. Install wheel pin.

○Place the hub on a wood workbench or a block of wood approx. 6" by 6" to protect the wheel stud ends and threads.

○Insert a wheel stud using a hammer.


Be sure the wheel stud is started squarely and seats completely.



411RS005


2. Align scribe marks(1) and attach the hub to the disc, then tighten the bolts to the specified torque.

Torque: 103 N·m (76 lb ft)




411RS003

3. Use installer J-36829 and grip J-8092, then install the inner bearing by driving it into the hub.




901RW055

4. Use installer J-36828 and grip J-8092 then install the outer bearing by driving it into the hub.



901RW056

5. Apply grease (NLGI No.2 or equivalent) to the lip portion, then install oil seal by using installer J-36830 and grip J-8092.



901RW057

6. Install ABS sensor ring, then tighten the bolts to the specified torque.

Torque: 18 N·m (13 lb ft)

7. Install hub and disc assembly.

○Apply grease in the hub.


○Apply wheel bearing type grease NLGI No. 2 or equivalent to the outer and inner bearing.

Grease Amount

○Hub: 35 g (1.23 oz)

○Outer bearing: 10 g (0.35 oz)

○Inner bearing: 15 g (0.53 oz)



411RS009

Legend


(1) Inner Bearing

(2) Hub

(3) Outer Bearing

8. Install hub nut.

Turn to the place where there is a chamfer in the tapped hole to the outer side, then attach the nut by using front hub nut wrench J-36827.



901RW054

Preload Adjustment

1. Tighten the hub nut to 29 N·m (22 lb ft), then fully loosen the nut.
2. Tighten the hub nut to the value given below, using a spring scale on the wheel pin.


New bearing and New oil seal

Bearing Preload: 20 N – 25 N (4.4 lb – 5.5 lb)

Used bearing and New oil seal

Bearing Preload: 12 N – 18 N (2.6 lb – 4.0 lb)

If the measured bearing preload is outside the specifications, adjust it by loosening or tightening the bearing nut.




411RS011

4C-12 DRIVE SHAFT SYSTEM

9. Install lock washer and lock screw in the following manner.

- Turn the side with larger diameter of the tapered bore to the vehicle outer side, then attach the washer.
- If the bolt holes in the lock plate are not aligned with the corresponding holes in the nut, reverse the lock plate.
- If the bolt holes are still out of alignment, turn in the nut just enough to obtain alignment.
- Screw is to be fastened tightly so its head may come lower than the surface of the washer.




10. Apply adhesive (LOCTITE 515 or equivalent) to both joining flange faces then install hub flange.

11. Install snap ring and shim.

- Adjust the clearance between the free wheeling hub body and the snap ring.

Clearance: 0 mm–0.3 mm (0 in–0.012 in)

Shims Available: 0.2 mm, 0.3 mm, 0.5 mm, 1.0 mm (0.008 in, 0.012 in, 0.020 in, 0.039 in)



12. Install hub cap.

13. Tighten the bolts to the specified torque.

Torque: 59 N·m (43 lb ft)

Front Drive Shaft Joint

Front Drive Shaft Joints Replacement

- Refer to Front Drive Axle Assembly Replacement in this section, and refer to Front Hub and Disc Overhaul in Suspension section.

Front Hub Bearing Preload Check


Check the hub bearing preload at the wheel pin.

New bearing and New oil seal:


19.6 – 24.5 N (4.4 – 5.5 lb)

Used bearing and New oil seal:

11.8– 17.7 N(2.6 – 4.0 lb)



Inspection Of Shift On The Fly System Gear Oil



1. Open filler plug and make sure that the oil up to the plug port.


If the oil is short, replenish with gear oil GL-5 grade.

2. Tighten the filler plug to specified torque.

Torque: 78 N·m (58 lb in)

Front Axle Drive Shaft

Front Axle Drive Shaft and Associated Parts



412RW033


Legend

- | | |
|---------------------------------|--------------------|
| (1) Axle Case and Differential | (12) Ball |
| (2) DOJ Case Assembly | (13) Snap Ring |
| (3) Snap Ring | (14) Ball Retainer |
| (4) Bearing | (15) Ball Guide |
| (5) Snap Ring | (16) Band |
| (6) Oil Seal | (17) Bellows |
| (7) Bracket | (18) Band |
| (8) DOJ Case | (19) Band |
| (9) Circlip | (20) Bellows |
| (10) Bolt | (21) Band |
| (11) Drive Shaft Joint Assembly | (22) BJ Shaft |
| | (23) Dust Seal |


Disassembly

NOTE: For the left side, follow the same steps as right side.


1. Raise the hooked end of the band with a screwdriver or equivalent.




2. Remove band(1).
3. Pry off circlip (1) with a screwdriver or equivalent.




4. Remove drive shaft joint assembly.
5. Remove the six balls (1) with a screwdriver or equivalent.



6. Using snap ring pliers, remove the snap ring (1) fastening the ball retainer to the center shaft.



7. Remove ball retainer, ball guide and bellows.
8. Raise the hooked end of the band with a screwdriver or equivalent.



9. Remove band(1).
10. Remove bellows.
11. Remove dust seal.
12. Remove BJ shaft assembly.
13. Remove the mounting bracket fixing bolts, and then remove DOJ case assembly from the axle case.
14. Remove snap ring and bearing.
15. Remove snap ring and oil seal.
16. Remove bracket.

Inspection And Repair


Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.

Check the following parts.


1. Drive shaft joint assembly
2. DOJ case, ball, ball guide, ball retainer
3. Bellows
4. Bearing
5. Dust seal, oil seal

Bushing Replacement

- Remove the bushings using a remover J-39378-1 and hammer.



- By using installer J-39378-2 and base J-39378-3, press fit the bushings into the bracket.




Reassembly

1. Install DOJ case to bracket.
2. Install oil seal and fix snap ring.
3. Install bearing and fix snap ring.
4. Install bracket to axle case. Tighten the bracket bolt to the specified torque.

Torque: 116 N·m (85 lb ft)


5. Apply 150g of the specified grease in BJ.
6. Install dust seal.
7. Apply a thin coat of grease to the shaft for smooth installation then install bellows.

8. Install band. Note the setting direction. After installation, check that the bellows is free from distortion.




412RS017

9. Install another bellows and fix band.
 10. Install the ball guide with the smaller diameter side ahead onto the shaft.
 11. Install ball retainer.
 12. Using snap ring pliers, install the snap ring (1) securing the ball retainer to the shaft.




412RS013

13. Align the track on the ball (1) retainer with the window in the cage, and install the six balls into position.




412RS018

14. Pack 150g of the specified grease in DOJ case, then install drive shaft joint assembly. After reassembly, move the DOJ longitudinally several times to get to fit.
 15. Install the circlip (1) so that open ends are positioned away from the ball groove.




412RS019



Legend

- (1) Outer Case
- (2) Circlip
- (3) Open Ends


16. Install bellows. Adjust the air pressure within the bellows by inserting a screwdriver or equivalent, so that it equals atmospheric pressure.



17. Install band. After installation, check that the bellows is free from distortion.

Shift On The Fly System

Shift On The Fly System and Associated Parts



412RW031

Legend


- | | |
|-------------------------|---|
| (1) Filler Plug | (8) Needle Bearing |
| (2) Bolt | (9) Clutch Gear |
| (3) Oil Seal | (10) Sleeve |
| (4) Snap Ring(External) | (11) Housing |
| (5) Inner Shaft Bearing | (12) Front Axle Drive Shaft(LH side) with Bracket |
| (6) Snap Ring(Internal) | (13) Bolt |
| (7) Inner Shaft | (14) Actuator Assembly |
| | (15) Bolt |

Disassembly

1. Remove filler plug and gasket, drain oil.
2. Loosen mounting bracket fitting bolts and remove front axle drive shaft from front axle case.
3. Remove actuator assembly and draw out actuator ASM.
4. Remove housing.
5. Remove sleeve.
6. Remove clutch gear.


4C-20 DRIVE SHAFT SYSTEM

7. Remove snap ring from front axle case by using snap ring pliers.



412RW017


8. Take out inner shaft from front axle case.
9. Remove snap ring from inner shaft by using snap ring pliers.



412RW016


10. Remove inner shaft bearing.

NOTE: Be careful not to damage the shaft.



412RW015

11. Remove needle bearing from inner shaft by using a remover J-26941 and sliding hammer J-2619-01.



412RS045

12. Remove oil seal from front axle case.


NOTE: Be careful not to damage the front axle case.

Inspection And Repair


Inspect the removed parts. If there are abnormalities such as wear and damage, take corrective action or replace.

Visual Check

1. Check and see if the inner shaft has such abnormalities as wear and damage.



2. When inspecting the inner shaft, be sure to check and see if its splined part is twisted, worn, or cracked. If so, replace with a new shaft. In case such an abnormality in its gear part (a slide with sleeve), replace the shaft.




Inner Shaft Run-Out


With both end centers supported, rotate the shaft slowly and measure deflection with a dial gauge.

Limit: 0.5 mm (0.02 in)

NOTE: Do not heat the shaft to correct its bend.



Inner Shaft Bearing



Legend

- (1) Inner Shaft Bearing
- (2) Inner Shaft
- (3) Clutch Gear


1. Inspect the state of inner shaft bearing. If any abnormality such as smoothlessness is found, replace with a new inner shaft bearing.
2. Insert a clutch gear and check the state of needle bearing.
3. If there is an abnormality such as smoothlessness, replace the needle bearing.

Sleeve Condition

Check and see that there is not wear damage, or cracking in the sleeve.

NOTE: Close inspection of the groove and inner gear are required because those are important parts.

Sleeve Function




Operate the sleeve with the inner shaft combined with the clutch gear and if smoothness is felt, replace the sleeve.

NOTE: Gear oil should be applied to the contact surface of gear.

Check the width of sleeve center groove.


Limit: 7.1 mm (1.28 in)



Clutch Gear Condition

Check and see that there is not wear, damage, crack, or any other abnormality in the clutch gear.

Clutch Gear Function




If there is an abnormality such as roughness when operated in combination with sleeve, replace the clutch gear.

NOTE: When inspecting, gear oil should be applied to the contact surface of gear.

Clutch Gear Journal Diameter

Make sure of the size illustrated.




Limit: 36.98 mm (1.456 in)



Actuator

Check and see that there is no damage, cracking, or other abnormality.

Functional Check



Disconnect the shift position switch and make sure of function with a vacuum of -400 mmHg applied to Ports A and B, in accordance with the table below.

State	Port A	Port B	Function
C	-400 mmHg	A/P	E
D	A/P	-400 mmHg	F

If there is an abnormality, replace the actuator as an assembly.

NOTE:

1. If the actuator works under -400mmHg or less, there is no functional problem.
2. Be careful not to permit the entry of water or dust into the ports of the actuator.

Dimentional Check


Measure illustrated sizes 1, 2, and 3.

Limit

1=64.1 mm (2.52 in)

2=6.7 mm (0.26 in)


3=6.7 mm (0.26 in)



412RS037


Reassembly

1. Install the new oil seal which has been immersed in differential gear oil, by using an oil seal installer J-41693 and grip J-8092.




412RW034

2. Force a new needle bearing into inner shaft by using a Installer J-41694 and grip J-8092.



412RS051

3. Place a new snap ring(internal) in inner shaft.
Force a new inner shaft bearing into the inner shaft.



412RS044

4. Install snap ring(external).


NOTE: Be careful not to damage the inner shaft.

5. Clean the housing contact surface of the front axle case and insert inner shaft assembly into the front axle case.

NOTE: Be careful not to damage seal.


6. Install snap ring internal in the groove of front axle case.

NOTE: Be sure to install the snap ring properly.



412RW017

7. Apply differential gear oil to clutch gear, then install clutch gear.
8. Apply differential gear oil to sleeve, then install sleeve.
9. Clean contact surface with the front axle and actuator mounting surface. Apply liquid gasket to the contact surface on the front axle case, then install in the housing.



412RW023


10. Tighten bolts to specified torque.

Torque: 75N-m(55 lb ft)

11. Clean the actuator contact surface with the housing then Install and tighten shift position switch to specified torque.

Torque: 39N-m (29 lb ft)

12. Apply liquid gasket to the contact surface on the actuator side.



412RW012

13. Align shift arm with the groove of sleeve and install the actuator.

14. Tighten bolts to specified torque.

Torque: 9N-m(78 lb in)

15. Install front axle drive shaft and mounting bracket. Tighten fitting bolts to specified torque.

Torque: 116N-m (85 lb ft)

16. Pour specified amount of differential gear oil to filler plug.

Front Differential

Oil Capacity: 1.4lit (1.48US qt)

Actuator Housing

Oil Capacity: 0.12lit(0.13US qt)

17. Install filler plug through gasket and tighten to specified torque.


Torque: 78N-m (58lb ft)

Main Data and Specifications


General Specifications

Front drive axle oil capacity	1.25 liter (1.32 US qt)(Differential)
	0.12 liter (0.13 US qt)(Actuator Housing:Shift on the fly)
Type of lubricant	GL-5 (75W-90) Refer to chart in General Information
Axle shaft type	Constant velocity joint(Birfield joint type and double offset joint)

Torque Specifications



E04RX003



E04RW001

Special Tools












ILLUSTRATION	TOOL NO. TOOL NAME
 901RS233	J-39378 Remover and Installer; Front Axle mount bushing
 901RS234	J- 26941 Remover; Bearing needle
 901RS235	J-2619-01 Hammer; Sliding
 901RS236	J-41693 Installer; Oil seal
 901RS177	J-41694 Installer; Bearing needle
 901RS285	J-8092 Grip

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS246	J-36827 Wrench; Hub nut
 901RS247	J-36829 Installer; Inner bearing
 901RS248	J-36828 Installer; Outer bearing
 901RS249	J-36830 Installer; Oil seal

Propeller Shaft

General Description



401RX002

Legend

- | | |
|--|---|
| (1) Front Propeller Shaft | (3) Rear Propeller Shaft;
Aluminum Tube with Flange Yoke Type |
| (2) Rear Propeller Shaft;
Aluminum Tube with Spline Yoke Type | (4) Rear Propeller Shaft;
Steel Tube Type (for 4×4, 6VD1, A/T model) |


Torque is transmitted from the transmission to the axle through propeller shaft and universal joint assemblies. All propeller shafts are the balanced tubular type. A splined slip joint is provided in some drivelines.

- Since the propeller shaft is total balanced carefully, welding or any other modification are not permitted.

- Alignment marks should be applied to each propeller shaft before removal.
- Be sure vehicle is stopped, engine is not running, brake is secured and vehicle is secured to prevent injury.
- Be careful not to grip the propeller shaft tube too tightly in the vise as this will cause deformation.

Phasing

The propeller shaft is designed and built with the yoke lugs (ears) in line with each other. This design produces the smoothest running shaft possible, called phasing. Vibration can be caused by an out-of-phase propeller shaft. The propeller shaft will absorb vibrations from speeding up and slowing down each time the universal joint goes around. This vibration would be the same as a person snapping rope and watching the "wave" reaction flow to the end. A propeller shaft working in phase would be similar to two persons snapping a rope at the same time, and watching the "waves" meet and cancel each other out. In comparison, this would be the same as the universal joints on a propeller shaft. A total cancellation of vibration produces a smooth flow of power in the driveline. It is very important to apply a reference mark to the propeller shaft before removal, to assure installation alignment.

Universal Joint**Legend**

- (1) Spider
- (2) Yoke

A universal joint consists of two Y-shaped yokes connected by a crossmember called a spider.


The spider is shaped like a cross. Universal joints are designed to handle the effects of various loadings and front or rear axle windup during acceleration. Within the designed angle variations, the universal joint will operate efficiently and safely. When the design angle is changed or exceeded the operational life of the joint may decrease. The bearings used in universal joints are of the needle roller type. The needle rollers are held in place on the trunnions by round bearing cups. The bearing cups are held in the yokes by snap rings.

Diagnosis of Propeller Shaft and Universal Joint

Condition	Possible cause	Correction
Universal Joint Noise.	Worn universal joint bearings.	Replace.
	Improper lubrication.	Lubricate as directed.
	Loose flange bolts.	Tighten to specifications.
Ping, Snap, or Click in Drive Line (Usually Heard on Initial Load after the Transmission is in Forward or Reverse Gear)	Loose bushing bolts on the rear springs or upper and lower control arms.	Tighten the bolts to specified torque.
	Loose or out-of-phase end yoke.	Remove end yoke, turn 180 degrees from its original position, lubricate the splines and reinstall. Tighten the bolts and pinion nut to specified torque.
Knocking or Clanking Noise in the Driveline when in High or Neutral Gear at 16km/h(10mph)	Worn or damaged universal joint	Replace the universal joint.
Squeak	Lack of lubricant.	Lubricate joints and splines. Also check for worn or brinelled parts.
Shudder on Acceleration (Low Speed)	Loose or missing bolts at the flanges.	Replace or tighten bolts to specified torque.
	Incorrectly set front joint angle.	Install shim under the transmission support mount to change the front joint angle.
	Worn universal joint.	Replace.
Vibration	Incorrect shaft runout.	Replace.
	Shaft out of balance.	Adjust.
	Transmission rear housing bushing, transfer case housing bushing worn.	Replace.
	Yoke spline jammed.	Replace.
Excessive Leak at the Front Spline Yoke of Rear Propeller Shaft	Rough surface on splined yoke; burred nicked or worn.	Replace the seal. Minor burrs can be Smoothed by careful use of crocus cloth or fine stone honing. Replace the yoke if badly burred.
	Defective transmission rear oil seal.	Replace the transmission rear oil seal and replenish the transmission oil.

Front Propeller Shaft

Front Propeller Shaft and Associated Parts



Legend

(1) Bolt, Nut and Washer (Front Axle Side)


(2) Front Propeller Shaft

(3) Bolt, Nut and Washer (Transfer Side)

Removal

1. Raise the vehicle on a hoist.

NOTE: Apply alignment marks on the flange at the front propeller shaft both front and rear side.



2. Remove bolt, nut and washer (Front axle side).
3. Remove bolt, nut and washer (Transfer side).
4. Remove front propeller shaft.


Installation

NOTE: Never install the shaft assembly backwards. Never insert bar between yoke lugs when tightening or removing bolts. Completely remove the black paint from the connecting surface of flange coupling on each end of propeller shaft. Clean so that no foreign matter will be caught in between.

1. Align the mark which is applied at removal. Install front propeller shaft and tighten the bolts to the specified torque.

Torque: 63 N·m (46 lb ft)

Disassembly




401RW032

Legend

- (1) Sleeve Yoke
- (2) Clamp

- (3) Boot
- (4) Clamp
- (5) Tube Assembly


1. Lay the shaft horizontally on a bench and secure.
2. Indicate the original assembled position (1) by marking the phasing of the shaft prior to disassembly.



401RW037

3. Using the flat blade of a screwdriver, pry the loose end of the boot clamp upwards and away from the propeller shaft boot. Be careful not to damage the boot.
4. When boot clamps becomes loose, remove by hand.
5. Repeat for the other boot clamp.
6. Remove the slip yoke assembly from the driveshaft, by securing the boot with one hand and pulling on the slip yoke.
7. Remove the boot from the shaft assembly.

Universal Joint Disassembly




401RW031

Legend

- (1) Flange Yoke
- (2) Snap Ring


- (3) Spider
- (4) Needle Roller Bearing

1. Using a soft drift, tap the outside of the bearing cup assembly to loosen snap ring. Tap bearing only hard enough to break assembly away from snap ring. Remove snap ring from yoke. Turn joint over, tap bearing away from snap ring, then remove opposite snap ring. Apply alignment marks (1) on the yokes of the universal joint, then remove snap ring.



401RW018

2. Set the yoke in the arbor press with a piece of tube stock beneath it.
Place a solid plug on the upper bearing assembly and press it through to release the lower bearing assembly.



401RW020

3. If the bearing assembly will not pull out by hand after pressing, tap the base of the lug near the bearing assembly to dislodge it.
4. To remove the opposite bearing, turn the yoke over and straighten the spider in the open hole. Then carefully press on the end of the spider so the remaining bearing moves straight out of the bearing spider hole. If the spider or bearing are cocked, the bearing will score the walls of the spider hole and ruin the yoke.
5. Repeat this procedure on the remaining bearing to remove the spider from the yoke.
6. Make sure of proper position for reinstallation by applying setting marks, then remove spider.

Inspection and Repair

Make necessary correction or parts replacement if wear, damage, corrosion or any other abnormal condition is found through inspection.


NOTE: When any part of the journal assembly (spider, needle roller bearing) requires replacement, be sure to replace the entire assembly.

Check the following parts for wear, damage, noise or any other abnormal conditions.

1. Spider
2. Needle roller bearing
3. Yoke
4. Flange
5. Boot

Spider pin for wear

Spider pin should be smooth and free from fretting or galling. Visible signs of needle presence is normal, but wear should not be felt.



401RW038

Propeller shaft run-out

Support the propeller shaft on V-blocks (2) and check for run-out by holding the probe of a dial indicator (1) in contact with the shaft.

Static run-out limit:

0.13 mm (0.005 in)

TIR on the neck of the slip tube shaft (with a boot).

0.25 mm (0.010 in)

TIR on the ends of the tubing 3 inch from the welds.


0.38 mm (0.015 in)

TIR at the linear center of the tube.

0.38 mm (0.015 in)

TIR for the full length of tube with 30" or less of tubing.

(TIR : Total Indicator Reading)



401RS027


Spline

The nylon-coated spline should be free from nicks and dings and the underlying steel spline should not be visible. After cleaning the nylon coating spline, the coating should exhibit only slight indicator of wear.

Grease volume is approximately 10 grams of grease in total. Grease should be evenly applied to both the female and the male slip splines using a small brush. After assembly of the slip joint, the sliding joint should be fully worked from the full collapsed to the full extended position.

Play in the universal joint


Limit: Less than 0.15 mm (0.006 in)



401RW023

Preload of the universal joint


Preload should be 0 to 49 N(0 to 11.0 lb). Joints should rotate smoothly and freely and should exhibit no rough or ratchety movement.



401RW019

Universal Joint Reassembly


1. Install spider to flange yoke. Be sure to install the spider by aligning the setting marks made during disassembly.
2. Pack the four grease cavities of the spider with a high quality, extreme pressure N.L.G.I. Grade 2 grease. Do not add additional grease to the bearing cup assembly.
3. Move one end of the spider to cause a trunnion to project through the spider hole beyond the outer machined face of the yoke lug. Place a bearing over the trunnion diameter and align it to the spider hole. Using an arbor press, hold the trunnion in alignment with the spider hole and place a solid plug on the upper bearing. Press the bearing into the spider hole enough to install a snap ring.




401RW020

4. Install a snap ring.
Be sure the snap rings are properly seated in the grooves.
5. Repeat steps 3 and 4 to install the opposite bearing. If the joint is stiff, strike the yoke ears with a soft hammer to seat needle bearings.
6. Align setting marks (1) and join the yokes.

7. Install snap ring.



Reassembly



Legend

- (1) Sleeve Yoke
- (2) Clamp

- (3) Boot
- (4) Clamp
- (5) Tube Assembly

4C-38 DRIVE SHAFT SYSTEM


1. Apply grease evenly to both the female and male splines.
2. Apply a small amount of grease by finger to the outer lips of the boot.
3. Slide the boot onto the yoke shaft being careful not to damage the spline coating or boot.
4. Insert the yoke shaft spline into the sleeve being careful to maintain proper phasing. The spider holes should be in line and as per originally marked prior to disassembly.
5. Position boot onto sleeve and yoke shaft in final position over boot grooves.
6. Attach boot clamps and secure using pliers.
7. Be sure clamp is properly seated and secure.

Main Data and Specifications

General Specifications


Transmission	M/T	A/T
Length (between two spiders center)	367.2 mm (14.81 in)	542.2 mm (21.35 in)

Torque Specifications



Rear Propeller Shaft

Rear Propeller Shaft and Associated Parts



401RX003

Legend

- | | |
|--|---|
| (1) Bolt, Nut and Washer (Transfer Side) | (2) Rear Propeller Shaft |
| | (3) Bolt, Nut and Washer (Rear Axle Side) |

Removal

1. Raise the vehicle on a hoist.

NOTE: Apply alignment marks on the flange at the rear propeller shaft both front and rear side.

2. Remove transfer side bolt, nut and washer (except spline yoke type).
3. Remove rear axle side bolt, nut and washer.
4. Remove rear propeller shaft.

NOTE: Plug the hole of the transmission rear end to prevent oil leakage (spline yoke type only).

Installation

NOTE: Never install the shaft assembly backwards.


Never insert bar between yoke lugs when tightening or removing bolts.

Completely remove the dust or foreign matter from the connecting surface of flange coupling on each end of the propeller shaft.

1. Align the mark which is applied at removal.
2. Install rear propeller shaft and tighten the bolts to the specified torque.

Torque: 63 N·m(46 lb ft)

Slip Joint Disassembly



401RX004

Legend


- (1) Spline Yoke and Universal Joint Assembly
- (2) Clamp

- (3) Boot
- (4) Clamp
- (5) Tube and Universal Joint Assembly

1. Lay the shaft horizontally on a bench and secure.
2. Indicate the original assembled position by marking the phasing of the shaft prior to disassembly.
3. Using the flat blade of a screwdriver, pry the loose end of the boot clamp upwards and away from the propeller shaft boot. Be careful not to damage the boot.

4. When boot clamps becomes loose, remove by hand.
5. Repeat for the other boot clamp.
6. Remove the slip yoke assembly from the driveshaft, by securing the boot with one hand and pulling on the slip yoke.
7. Remove the boot from the shaft assembly.

Universal Joint Disassembly



401RX005

Legend


- | | |
|------------------------------|-----------------|
| (1) Spline Yoke | (5) Flange Yoke |
| (2) Spider | (6) Bearing |
| (3) Propeller Shaft Assembly | (7) Snap Ring |
| (4) Spider | (8) Flange Yoke |

NOTE: Aluminum is softer than steel. Care must be taken not to remove excessive material or damage bearing holes.


If the vehicle has aluminum tube type propeller shaft, flange yoke, boot kit, journal kit can be replaced. If other parts are damaged, replace propeller shaft as assembly.

4C-42 DRIVE SHAFT SYSTEM


1. Apply alignment marks on the yokes of the universal joint, then remove the snap ring.




If the snap ring is stuck in position, remove paint from the hole in the yoke or tap around the edge of the bearing lightly with a soft drift.



2. Set the yoke in the arbor press with a piece of tube stock beneath it.
Place a solid plug on the upper bearing and press it through to release the lower bearing.




3. If the bearing will not pull out by hand after pressing, tap the base of the lug near the bearing to dislodge it.
4. To remove the opposite bearing, turn the yoke over and straighten the spider in the open spider hole. Then carefully press on the end of the spider so the remaining bearing moves straight out of the bearing spider hole. If the spider or bearing are cocked, the bearing will score the walls of the spider hole and ruin it.



5. Repeat this procedure on the remaining bearing to remove the spider from the yoke.


Inspection

- Propeller shaft for run-out Aluminum tube type.
Static run-out limit : 1.0 mm(0.04 in)
TIR full length of tubing maximum.
(TIR : Total Indicator Reading)
- Propeller shaft for runout (Steel tube type).
Static runout limit : 0.13 mm(0.005 in)
TIR on the neck of the slip tube shaft (with a boot).
0.25 mm(0.010 in)
TIR on the ends of the tubing 3 inch from the welds.
0.38 mm(0.015 in)
TIR at the linear center of the tube.
0.38 mm(0.015 in)
TIR for the full length of tube with 30" or less of tubing.
(TIR: Total Indicator Reading)




401RW017

- Play in universal joint.
Limit: Less than 0.15 mm(0.006 in)
- Spider pin should be smooth and free from fretting or galling.
 Visible signs of needle presence is normal, but wear should not be felt.



401RW028


- Preload of the universal joint.
 Preload should be 0 to 49 N (0 to 11.0 lb).
 Joints should rotate smoothly and freely and should exhibit no rough or ratchety movement.



401RW019

- Inspect splines of slip joint for wear.
 The nylon-coated spline should be free from nicks and dings and the underlying steel spline should not be visible.
 After cleaning the nylon coating spline, the coating should exhibit only slight indicator of wear.
 Grease volume is approximately 10 grams of grease in total. Grease should be evenly applied to both the female and the male slip splines using a small brush.
 After assembly of the slip joint, the sliding joint should be fully worked from the full collapsed to the full extended position.

- Aluminum tube type only: Inspect the aluminum tubing for surface scratches and dents. These scratches may not exceed 0.2 mm (0.008 in) in depth.




401RW022

- Aluminum tube type only: Visually inspect the circle welds and fittings for any signs of cracks or signs of deterioration. If there are any cracks that exceed 0.2 mm (0.008 in) in depth, the assembly must be replaced.
- Aluminum tube type only: Check to be sure there are no missing balance weights. If balance weights are missing and void has occurred in the aluminum tubing greater than 0.2 mm (0.008 in), the assembly must be replaced.

Universal Joint Reassembly

1. Pack the four grease cavities of the spider with a high quality, extreme pressure N.L.G.I. Grade 2 grease. Do not add additional grease to bearing cup assembly.
2. Move one end of the spider to cause a trunnion to project through the spider hole beyond the outer machined face of the yoke lug. Place a bearing over the trunnion diameter and align it to the spider hole. Using an arbor press, hold the trunnion in alignment with the spider hole and place a solid plug on the upper bearing. Press the bearing into the spider hole enough to install snap ring.




401RW026

3. Install a snap ring.

NOTE: Be sure the snap rings are properly seated in the grooves.

4. Repeat steps 2 and 3 to install the opposite bearing. If the joint is stiff, strike the yoke ears with a soft hammer to seat the bearing.
5. Align the setting marks and join the yokes.

Slip Joint Reassembly



401RX004

Legend

- | | |
|--|---------------------------------------|
| (1) Spline Yoke and Universal Joint Assembly | (3) Boot |
| (2) Clamp | (4) Clamp |
| | (5) Tube and Universal Joint Assembly |

1. Apply grease evenly to both the female and male splines.
2. Apply a small amount of grease by finger to the outer lips of the boot.
3. Slide the boot (smaller diameter side) onto the spline yoke shaft being careful not to damage the spline coating or boot.
4. Insert the spline yoke shaft spline into the tube assembly being careful to maintain proper phasing. The spider holes should be in line and as per originally marked prior to disassembly.
5. Position boot onto tube and yoke shaft in final position.
6. Attach boot clamps and secure using pliers.

7. Be sure clamp is properly seated and secure.


CAUTION: Use new clamp which is the same parts as original. Do not use other clamp to avoid bad balancing of shaft or the grease leakage.

Main Data and Specifications

General Specifications

	2WD Model			4WD Model	
	X22SE	6VD1 (M/T)	6VD1 (A/T)	6VD1 (M/T)	6VD1 (A/T)
Length (between two spiders center)	1265.1 mm (49.81 in)	1298.5 mm (51.12 in)	1343.8 mm (52.91 in)	1212.5 mm (47.73 in)	1043.0 mm (41.06 in)
Universal joint type	Cardan type				

Torque Specifications



401RX005

DRIVELINE/AXLE

TRANSFER CASE

CONTENTS

Service Precaution	4D-1	Transfer Rear Cover Assembly	4D-16
General Description	4D-2	Disassembly	4D-16
Transfer Rear Oil Seal	4D-4	Inspection and Repair	4D-17
Transfer Rear Oil Seal and		Reassembly	4D-17
Associated Parts	4D-4	Detent, Shift Arm, and Interlock Pin	
Removal	4D-4	(Transfer Case Assembly)	4D-19
Installation	4D-4	Disassembled View	4D-19
Transfer Case Assembly (A/T)	4D-6	Disassembly	4D-20
Transfer Case Assembly (A/T) and		Inspection and Repair	4D-21
Associated Parts	4D-6	Reassembly	4D-21
Removal	4D-7	Transfer Case Assembly	4D-23
Installation	4D-8	Disassembled View	4D-23
Transfer Rear Case Assembly (A/T)	4D-11	Disassembly	4D-24
Transfer Rear Case Assembly (A/T) and		Inspection and Repair	4D-27
Associated Parts	4D-11	Reassembly	4D-30
Removal	4D-11	Main Data and Specifications	4D-37
Installation	4D-13	Special Tools	4D-40


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.


CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

Transfer Case (for M/T)



A07RW002

Transfer Case (for A/T)


A07RW001

The transfer case is used to provide a means of providing power flow to the front axle. The transfer case also provides a means of disconnecting the front axle, providing better fuel economy and quieter operation when the vehicle is driven on improved roads where four wheel drive is not required. In addition, the transfer case provides an additional gear reduction when placed in low range, which is useful when difficult off-road conditions are encountered.

A floor mounted shift lever is used to select the high-low range. When four wheel drive switch has been turned on, the four wheel drive indicator light is designed to come on and the front axle has been engaged.

Transfer Rear Oil Seal

Transfer Rear Oil Seal and Associated Parts



220RS015

Legend


(1) Rear Propeller Shaft

(2) End Nut and Rear Companion Flange

(3) Oil Seal

Removal

1. Disconnect the rear propeller shaft (1) from the transfer case side.
2. Remove end nut and rear companion flange (2), using the companion flange holder J-8614-11.




266RW001

3. Use the universal puller to remove the rear companion flange and O-ring.
4. Remove the oil seal from the transfer case.

Installation

1. Install oil seal and apply engine oil to the oil seal outer surfaces.
2. Apply the recommended grease (BESCO L2) or equivalent to the oil seal lip.
3. Use the oil seal installer J-39208 to install the rear seal (3) to the transfer rear case.



220RS016

4. Install the rear companion flange (2) and O-ring (2).
5. Use the companion flange holder J-8614-11 to install a new end nut (2) and tighten to the specified torque.



Torque: 167 N·m (123 lb ft)

6. Use the punch J-39209 to stake the end nut at two spots.

NOTE: Be sure to confirm that there is no crack at the staked portion of the end nut (2) after staking.


7. Connect the rear propeller shaft to the transfer case and tighten to the specified torque.

Torque: 63 N·m 46 (lb ft)



Transfer Case Assembly (A/T)

Transfer Case Assembly (A/T) and Associated Parts



260RW008


Legend

- | | |
|---|-----------------------------|
| (1) Transfer Control Lever Knob | (6) Transfer Protector |
| (2) Lower Cluster Assembly | (7) Fairing Plate |
| (3) Rear Console | (8) Rear Propeller Shaft |
| (4) Center Console | (9) Front Propeller Shaft |
| (5) Grommet Assembly and Transfer Control Lever | (10) Transfer Case Assembly |


Removal

NOTE: Before removing transmission and transfer assembly from vehicle, change the transfer mode to 2WD using the 4WD push button switch on dash panel.


1. Disconnect battery ground cable.
2. Remove transfer control lever knob (1).
3. Remove lower cluster assembly (2).




4. Remove rear console (3).



5. Remove center console (4).




6. Remove grommet assembly and transfer control lever (5).



4D-8 TRANSFER CASE

7. Raise and support vehicle with suitable stands. Drain transfer case fluid.
8. Remove transfer protector (6) and fairing plate (7).




9. Remove rear propeller shaft (8) and front propeller shaft (9).

NOTE: Apply alignment marks on the flange at both front and rear sides.


10. Disconnect harness connectors and clip.
Connector: transfer switch, 2WD-4WD actuator, speed sensor.
11. Support transmission case with a transmission jack.
12. Remove the top position bolt from transfer control lever hole and others under the floor.
Remove transfer case (10) from the vehicle.

Installation


1. Apply a thin coat of molybdenum disulfide grease to the input shaft spline as shown in the figure.



2. Install transfer case (10) to the transmission. Tighten transfer bolts as shown in the figure.




3. Remove the transmission jack from transmission side.
4. Connect harness connectors and clip.
Connector: transfer switch, 2WD-4WD actuator, speed sensor.
5. Install rear propeller shaft (8) and front propeller shaft (9).
- Torque: 63 N·m (46 lb ft)**
6. Install transfer protector (6) and fairing plate (7).



4D-10 TRANSFER CASE

7. Fill transfer case fluid.
8. Lower the vehicle.
Install grommet assembly and transfer control lever (5).




256RW007

9. Install center console (4), rear console (3) and lower cluster assembly (2).
10. Install transfer control lever knob (1).

Transfer Rear Case Assembly (A/T)

Transfer Rear Case Assembly (A/T) and Associated Parts



220RW133

Legend

- | | |
|---|-------------------------------------|
| (1) Speedometer Sensor, Speedometer Driven Gear and Plate | (4) Control Box Assembly |
| (2) Front Companion Flange | (5) 2WD-4WD Actuator Heat Protector |
| (3) Rear Companion Flange | (6) 2WD-4WD Actuator Assembly |
| | (7) Transfer Rear Cover Assembly |
| | (8) Transfer Case Assembly |

Removal


1. Remove the speedometer sensor (1).
2. Remove the plate (1).

3. Remove the speedometer driven gear bushing and driven gear (1).

NOTE: Apply a reference mark to the driven gear bushing before removal.

4D-12 TRANSFER CASE

4. Remove front companion flange (2) and rear companion flange (3), using the flange companion holder J-8614-11 to remove the end nut..




262RW009

5. Remove the front and rear companion flange.


NOTE: Use the universal puller to remove the rear companion flange.

6. Disconnect the actuator breather hose and transfer breather hose from control box (4).
7. Remove control box assembly (4).
8. Disconnect the actuator breather hose and 2WD-4WD actuator heat protector (5) from the 2WD-4WD actuator assembly (6).



220RW002

9. Remove the 2WD-4WD actuator assembly bolts.
10. Pull the 2WD-4WD actuator assembly (6) with 2WD-4WD shift rod.




220RW065


Legend

- (6) 2WD-4WD Actuator Assembly
(7) Rear Cover Assembly
(9) Shift Rod: 2WD-4WD (Position: 2WD)
(10) Pull
(11) Position: 4WD
(12) Mode: 2WD

11. Off set the actuator assembly.



12. Remove the actuator assembly (6).




Legend

- (13) Position: 4WD
(14) Mode: 2WD

13. Remove transfer rear cover assembly (7) from transfer case assembly.

Installation


1. Apply the recommended liquid gasket (LOCTITE 17430) or its equivalent to the transfer rear cover fitting faces.



2. Install transfer rear cover assembly (7) to transfer case assembly (8).

3. Perform the following steps before fitting the transfer rear case.

1. Shift the high-low shift rod to the 4H side.
2. The cut-away portion of the select rod head (15) should align with that of the rear case hole's stopper (16).




4D-14 TRANSFER CASE

4. Tighten the transfer rear case bolts to the specified torque.

Torque: 37 N·m (27 lb ft)


5. Shift the 2WD-4WD shift rod (17) to the 4WD side.
6. Join the rod grooves of 2WD-4WD actuator assembly (6) and shift rod (17).



Legend

- (6) 2WD-4WD Actuator Assembly (Mode: 2WD)
(7) Rear Cover Assembly
(17) Shift Rod: 2WD-4WD (Position: 4WD)

7. Push the 2WD-4WD actuator assembly (6) with 2WD-4WD shift rod (17) till the shift rod (17) reaches the 2WD position.



Legend

- (18) Position: 2WD
(19) Mode: 2WD


8. Tighten the 2WD-4WD actuator bolts to the specified torque.

Torque: 19 N·m (14 lb ft)

9. Connect the actuator breather hose to actuator.
10. Install actuator heat protector (5).
11. Install control box assembly (4).

Torque: 19 N·m (14 lb ft)

12. Connect breather hoses to control box (4).
13. Install rear companion flange (3) and front companion flange (2), using the companion flange holder J-8614-11 to tighten the flange nuts to the transfer case.




14. Tighten the new transfer flange nuts to the specified torque.

Torque


Rear companion flange: 167 N·m (123 lb ft)

Front companion flange: 137 N·m (101 lb ft)

15. Use the punch J-39209 to stake the rear companion flange nut (3) at two spots.



266RS001



266RW002

16. Stake the front companion flange nut (2) at one spot.


NOTE: Be sure to confirm that there is no crack at the staked portion of the flange nut after staking.

17. Install the O-ring (23) to the speedometer driven gear bushing (22).
 18. Install the driven gear to the speedometer driven gear bushing (22).
 19. Install the speedometer driven gear assembly to the transfer rear cover.
 20. Install the plate (21) to the transfer rear case and tighten to the specified torque.

Torque: 15 N·m (11 lb ft)

21. Install the speedometer sensor and tighten to the specified torque.

Torque: 27 N·m (20 lb ft)




225RW004

Legend

- (20) Bolt
 (21) Plate
 (22) Bushing
 (23) O-ring

Transfer Rear Cover Assembly



226RW154


Legend

- (1) Rear Output Shaft Assembly
- (2) Rear Output Shaft
- (3) Bearing Snap Ring
- (4) Ball Bearing

- (5) Bearing Snap Ring
- (6) Ball
- (7) Speedometer Drive Gear
- (8) Ball Bearing
- (9) Transfer Rear Cover (with oil seal)


Disassembly

1. Remove bearing snap ring, use a pair of snap ring pliers to remove the snap ring (3).




226RS060

2. Remove the rear output shaft assembly (1) from the transfer rear cover (with oil seal) (9).
3. Remove ball bearing (8), using a bench press and the bearing remover J-22912-01.



4. Remove speedometer drive gear (7).
5. Remove ball (6).
6. Remove bearing snap ring (5), using a pair of snap ring pliers.
7. Remove rear output shaft (2) from the ball bearing (4), using a bench press and the bearing remover J-22912-01.




Inspection and Repair

Refer to "TRANSFER CASE ASSEMBLY" in this section for inspection and repair.


Reassembly

Transfer rear cover (with oil seal) (9). Oil seal replacement.

- Remove the oil seal from the transfer rear cover.
- Apply engine oil to the oil seal outer surfaces.
- Fill in recommended grease (BESCO L2) or equivalent in the oil seal lip.
- Use the oil seal installer J-39208 to install the rear oil seal to the transfer rear cover.




1. Install ball bearing (4) to the rear output shaft (2), using the ball bearing installer J-37223 and the adapter J-37486-A.




4D-18 TRANSFER CASE

2. Install bearing snap ring (5), using a pair of snap ring pliers.
3. Install ball (6).
4. Install speedometer drive gear (7).




5. Use the ball bearing installer J-37223 to install the ball bearing (8).



6. Install the rear output shaft assembly (1) to the transfer rear cover (9).
 7. Install bearing snap ring (3).
- NOTE: The snap ring must be fully inserted into the transfer rear cover snap ring groove.

Detent, Shift Arm, and Interlock Pin (Transfer Case Assembly)

Disassembled View




262RW005

Legend


- | | |
|----------------------------------|--------------------------|
| (1) Detent Ball, Spring and Plug | (9) Interlock Pin |
| (2) Spring Pin and Bridge | (10) Spring |
| (3) Spring Pin | (11) Select Rod Assembly |
| (4) Spring | (12) Spring Pin |
| (5) 2WD-4WD Shift Rod | (13) High-Low Shift Rod |
| (6) Shift Arm | (14) Shift Arm |
| (7) Shift Block | (15) Shift Block |
| (8) 4WD Indicator Switch | (16) Transfer Case |

Disassembly


1. Remove detent ball, spring and plug (1).
2. Use a spring pin remover to remove the spring pin (2) from the bridge (6).




3. Remove spring (4).
4. Engage the 2WD-4WD sleeve with front output gear. Remove the spring pin (3) from the block (7). Remove the shift rod (5).



5. Remove shift arm (6).
6. Remove shift block (7).
7. Remove 4WD indicator switch (8).
8. Use a magnetic tool to remove the interlock pin (9) and spring (10) from the transfer case (16).



9. Remove select rod assembly (11).
10. Use a spring pin remover to remove the shift arm spring pin (12) from the shift arm (14) and shift block (15). Remove the high-low shift rod (13) from transfer case (16).




11. Remove shift arm (14).
12. Remove shift block (15) from transfer case (16).

Inspection and Repair

Refer to "TRANSFER CASE ASSEMBLY" in this section for inspection and repair.


Reassembly

1. Place shift block (15) in transfer case (16).
2. Set shift arm (14) on the High-Low sleeve.
3. Push High-Low shift rod (13) through shift arm (14) and block (14).
4. Engage the High-Low sleeve with the 4H (1) side.
5. Install the spring pin (12) to the shift block (15) and shift arm (14).



262RW034

6. Install select rod assembly (11), joining its lever to shift block groove.
7. Engage the High-Low sleeve with the 4H side and install the interlock pin and spring (10) in the proper direction.
8. Place 2WD-4WD shift block in the transfer case (16).
9. Set 2WD-4WD shift arm on the 2WD-4WD sleeve.
10. Push 2WD-4WD shift rod through 2WD-4WD shift arm and 2WD-4WD shift block.
11. Install the shift rod: 2WD-4WD (5) with interlock pin pushed in.



262RW035

Legend


- (18) 2WD-4WD
- (19) 4H Side
- (20) Interlock pin
- (21) 2WD
- (22) 4WD
- (23) Rod: 2-4
- (24) Rod: H-L
- (25) 4H
- (26) 4L
- (27) 4x2
- (28) 4x4

4D-22 TRANSFER CASE

12. Install 4WD indicator switch and gasket (8).
Tighten to the specified torque.

Torque: 39 N·m (29 lb ft)

13. Install spring (4).
14. Engage the 2WD-4WD sleeve with the 4WD side and install the spring pin (3).




15. Install spring pin (2) and bridge (2).
16. Install detent ball, spring and plug and tighten the plug to the specified torque.

Torque: 25 N·m (18 lb ft)

Transfer Case Assembly

Disassembled View



226RW209

Legend


- | | |
|------------------------------------|---|
| (1) Bearing Snap Ring | (16) Bearing Snap Ring |
| (2) Ball Bearing | (17) Ball Bearing |
| (3) Lock Nut | (18) Bearing Collar |
| (4) Snap Ring (A/T) | (19) Sub-Gear Snap Ring (M/T) |
| (5) Input Shaft Assembly (A/T) | (20) Spacer (M/T) |
| (6) High-Low Clutch Hub and Sleeve | (21) Belleville Spring (M/T) |
| (7) Transfer Input Gear | (22) Sub-Gear (anti-lash plate) (M/T) |
| (8) Needle Bearing | (23) Front Output Gear |
| (9) Bearing Collar | (24) Needle Bearing |
| (10) Ball | (25) Inside Ring |
| (11) Plate | (26) Outside Ring |
| (12) Ball Bearing (A/T) | (27) Block Ring |
| (13) Input Shaft (A/T) | (28) 2WD-4WD Clutch Hub and Sleeve Assembly |
| (14) Bearing Snap Ring | (29) Stopper Plate |
| (15) Front Output Gear Assembly | (30) Ball Bearing |
| | (31) Front Output Shaft |

4D-24 TRANSFER CASE


- | | |
|----------------------------|------------------------------------|
| (32) Bearing Snap Ring | (38) Spacer |
| (33) Counter Gear Assembly | (39) Belleville Spring |
| (34) Snap Ring | (40) Sub-Gear (anti-lash plate) |
| (35) Ball Bearing | (41) Counter Gear |
| (36) Snap Ring | (42) Transfer Case (with oil seal) |
| (37) Ball Bearing | |

Disassembly


1. Use a pair of snap ring pliers to remove the snap ring (1).
2. Use a bearing remover J-37217 and puller J-37487 to remove the ball bearing (2).




3. Install the front companion flange temporarily.
4. Use the Companion flange holder J-8614-11 and lock nut wrench J-37219 to remove the lock nut (3).




5. Remove the front companion flange.
6. Remove snap ring (4). (A/T)
7. Remove the input shaft assembly (5) from the transfer case (42). (A/T)



8. Use the universal puller to remove the high-low clutch hub and sleeve (6), and transfer input gear (7).




9. Remove needle bearing (8).
10. Remove bearing collar (9).




226RS071

11. Remove ball (10).
12. Remove plate (11).
13. Use a bench press and the ball bearing remover J-22912-01 to remove the ball bearing (12) from the input shaft (13). (A/T)




265RS002

14. Use a pair of snap ring pliers to remove the bearing snap ring (14).
15. Use a plastic hammer to tap the front output gear assembly (15) free.



262RS009

16. Remove bearing snap ring (16).
17. Use a bench press and the bearing remover J-22912-01 to remove the following parts.
18. Remove ball bearing (17), and bearing collar (18). Remove sub-gear snap ring (19), spacer (20), belleville spring (21), and sub-gear (anti-lash plate) (22). (M/T)
Remove front output gear (23) and needle bearing (24).



262RS010


19. Remove inside ring (25).
20. Remove outside ring (26).
21. Remove block ring (27).
22. Use a bench press and bearing remover J-22912-01 to remove 2WD-4WD clutch hub and sleeve assembly (28) and stopper plate (29).

NOTE: Do not reuse the stopper plate.

4D-26 TRANSFER CASE


23. Disassemble the 2WD-4WD clutch hub and sleeve assembly (28).

- Springs (1)
- Inserts (2)
- Clutch Hub (3)
- Sleeve (4)



226RW133


24. Use a bench press and the ball bearing remover J-22912-01 to remove the ball bearing (30) from front output shaft (31).



262RS011


25. Remove bearing snap ring (32).
26. Remove the counter gear assembly (33) from the transfer case (42).
27. Use a pair of snap ring pliers to remove the snap ring (34).
28. Use a bench press and the bearing remover J-22912-01 to remove the ball bearing (35).
29. Use a pair of snap ring pliers to remove the snap ring (36).

30. Use a bench press and the bearing remover J-22912-01 to remove the ball bearing (37).



226RS073

31. Remove spacer (38).
32. Remove belleville spring (39).
33. Remove sub-gear (anti-lash plate) (40).
34. Remove counter gear (41).
35. Remove transfer case (with oil seal) (42), performing the following steps (M/T)
 - Cover the shaft splines with adhesive tape (43).



A07RW022

Legend

- (43) Adhesive Tape
- (44) Oil Seal Lip
- (45) Oil Seal Collar
- (46) Bearing

- Remove the transfer case together with intermediate plate with gear assembly from the transmission case (M/T).

- Remove the transfer case from the intermediate plat with gear assembly (M/T).

Inspection and Repair

1. Make the necessary repair or parts replacement if wear, damage or any other abnormal conditions are found during inspection.
2. Wash all parts thoroughly in clean solvent. Be sure all old lubricant, metallic particles, dirt, or foreign material are removed from the surfaces of every part. Apply compressed air to each oil feed port and channel in each case half to remove any obstructions or cleaning solvent residue.

Gears

1. Inspect all the gear teeth for signs of excessive wear or damage and check all the gear splines for burrs, nicks, wear or damage. Remove the minor nicks or scratches on an oil stone. Replace any part exhibiting excessive wear or damage.


Front Output Gear Inside Diameter

1. Use an inside dial indicator to measure the gear inside diameter.
2. If the measured value exceeds the specified limit, the gear must be replaced.

Gear inside diameter

Standard : 48.000–48.013 mm (1.8898–1.8903 in)

Limit : 48.10 mm (1.894 in)



226RS040

Clutch Hub Spline Play


1. Set a dial indicator to the clutch hub to be measured.
2. Move the clutch hub as far as possible to both the right and the left.
Note the dial indicator reading.

3. If the measured value exceeds the specified limit, the clutch hub must be replaced.

Clutch hub spline play

Standard : 0–0.1 mm (0–0.004 in)

Limit : 0.2 mm (0.008 in)



226RS042

Bearings

1. Inspect the condition of all the needles and ball bearings. Wash bearings thoroughly in a cleaning solvent. Apply compressed air to the bearings.


NOTE: Do not allow the bearings to spin. Turn them slowly by hand. Spinning bearings may damage the rollers.

2. Lubricate the bearings with a light oil and check them for roughness by slowly turning the race by hand.

Ball Bearing Play

1. Use a dial indicator to measure the ball bearing play.
2. If the measured value exceeds the specified limit, the ball bearing must be replaced.

Limit : 0.2 mm (0.008 in)



226RS043

Synchronizers

The synchronizer hubs and sliding sleeves are a selected assembly and should be kept together as originally assembled.

Clean synchronizer components with clean solvent and air dry.

Inspect the components for the following:

- Teeth for wear, scuffs, nicks, burrs or breaks.
- Keys and springs for wear, cracks or distortion, replace if these conditions are present.
- If scuffed, nicked or burred conditions cannot be corrected with a soft stone or crocus cloth, replace the component.


Block Ring and Insert Clearance

1. Use a vernier caliper to measure the clearance between the block ring and the insert.
2. If the measured value exceeds the specified limit, the block ring and the insert must be replaced.

Block ring and insert clearance

Standard : 2.46–2.74 mm (0.097–0.108 in)

Limit : 3.0 mm (0.118 in)



226RS037


2WD-4WD Synchronizer (3-Cone)

1. Use a thickness gauge to measure the clearance between the block ring and the dog teeth.
2. If the measured value exceeds the specified limit, the 2WD-4WD synchronizer assembly must be replaced.

Block ring and insert clearance

Standard : 1.5 mm (0.059 in)

Limit : 0.8 mm (0.031 in)



226RW142


Clutch Hub and Insert Clearance

1. Use a thickness gauge to measure the clearance between the clutch hub and the insert.
2. If the measured value exceeds the specified limit, the clutch hub and the insert must be replaced.

Clutch hub and insert clearance

Standard : 0.01–0.19 mm (0.0004–0.0075 in)

Limit : 0.3 mm (0.012 in)



226RS038

Detent Springs

1. Inspect the springs for distortion, cracks or wear.
Replace if these conditions are present.

Detent Spring Free Length

1. Use a vernier caliper to measure the detent spring free length.
2. If the measured value is less than the specified limit, the detent spring must be replaced.

Detent spring free length

Detent ball


Standard : 23.4 mm (0.921 in)

Limit : 22.8 mm (0.898 in)

Interlock pin

Standard : 15.9 mm (0.626 in)

Limit : 15.3 mm (0.602 in)



220RW035

Detent Spring Tension

1. Use a spring tester to measure the detent spring tension.
2. If the measured value is less than the specified limit, the detent spring must be replaced.

Detent ball


Compressed height : 18.7 mm (0.736 in)

Standard : 68.6–88.2 N (15.4–19.8 lb)

Interlock pin

Compressed height : 11.5 mm (0.453 in)

Standard : 9.8 N (2.2 lb)



220RS013

Shift Arm

1. Inspect the shift arms for wear, distortion or scoring.
Replace if these conditions are present.


Shift Arm Thickness

1. Use a micrometer to measure the shift arm thickness.
2. If the measured value is less than the specified limit, the shift arm must be replaced.

Shift arm thickness

Standard : 9.60–9.85 mm (0.378–0.388 in)

Limit : 9.0 mm (0.354 in)




230RS006

Reassembly

Input Shaft Oil Seal Replacement

1. Remove the oil seal from the transfer case.
2. Apply the engine oil to the oil seal outer surfaces.
3. Apply recommended grease (BESCO L2) or equivalent to the oil seal lip.
4. Use the oil seal installer J-38592 (A/T) J-37488 (M/T) and driver handle J-8092 to install the oil seal to the transfer case.


A/T



Legend

(47) Oil Seal

M/T



Legend


- (48) Transmission Side Oil Seal
- (49) Transfer Side Oil Seal

220RW052

220RX002

Front Output Shaft Oil Seal Replacement


1. Remove the oil seal from the transfer case.
2. Apply engine oil to the oil seal outer surfaces.
3. Apply recommended grease (BESCO L2) or equivalent to the oil seal lip.
4. Use the oil seal installer J-38594 to install the oil seal to the transfer case.



Legend

(50) Front Output Shaft Oil Seal

1. Install the transfer case (with oil seal) (42), performing the following steps. (M/T)
 - Cover the shaft splines with adhesive tape (43). This will prevent damage to the oil seal lip (44).



Legend


(43) Adhesive Tape

(44) Oil Seal Lip

(45) Oil Seal Collar

(46) Bearing

- Apply recommended liquid gasket (LOCTITE FMD 127) or its equivalent to the transmission, intermediate plate and transfer case fitting surfaces (M/T).




4D-32 TRANSFER CASE

Install the transfer case together with intermediate plate with gear assembly to transmission case (M/T).

Tighten the transfer case bolts to the specified torque a little at a time (M/T).

Torque : 37 N·m (27 lb ft)



2. Apply chassis grease (51) to the sub-gear (40) and the counter gear (41) thrust surfaces.



3. Install sub-gear (40) to counter gear (41).
4. Install belleville spring (39).
5. Install spacer.
6. Install ball bearing, using a bench press.
7. Select a snap ring that will allow the minimum axial play.

Clearance : 0–0.1 mm (0–0.004 in)

Snap ring availability:	
Thickness	Color-coding
1.50 mm (0.059 in)	White
1.55 mm (0.061 in)	Yellow
1.60 mm (0.063 in)	Blue




8. Use a pair of snap ring pliers to install the snap ring (36) to the counter gear (41).

Sub-Gear (anti-lash plate) Preload


1. Hook a length of piano wire (52) over one of the sub-gear (53) teeth.
2. Attach the other end of the piano wire (52) to a spring balancer.
3. Measure the sub-gear preload.

Preload : 59–98 N (13–22 lb)




226RW156

9. Install ball bearing (35), using a bench press.
 10. Install snap ring (34).
 11. Install the counter gear assembly (33) to the transfer case (42).
 12. Use a pair of snap ring pliers to install the snap ring (32) to the transfer case (42).
- NOTE: The snap ring must be fully inserted into the transfer case snap ring groove.
13. Use a bench press to install the ball bearing (30) to the front output shaft (31).




262RS012

14. Assemble the 2WD-4WD clutch hub and sleeve assembly (28).



226RW140


15. Engage the springs in the same insert with the open ends away from each other.



226RW141

4D-34 TRANSFER CASE

16. Install a new stopper plate (29) and the clutch hub and sleeve assembly (28) to the front output shaft (31).




Legend


(54) Front Output Gear

17. The clutch hub face (with the heavy boss) must be facing the front output gear side.
18. Use a bench press to slowly force the clutch hub and sleeve assembly (28) together with the stopper plate (29) into place.
19. Align the inserts with the block ring insert grooves. Install the block ring (27) to the clutch sleeve and hub assembly (28).
20. Install the outside ring (26), inside ring (25) and needle bearing (24) to the front output gear (23) and bearing collar (18).


NOTE: Coat all parts with transmission oil before installing them.



21. Apply engine oil to the thrust surfaces of the sub-gear, the belleville spring, and the spacer.




22. Install sub-gear (anti-lash plate) (22), belleville spring (21) and spacer (20). (M/T)
23. Install sub-gear snap ring (19). (M/T)
24. Use a bench press to install the needle bearing collar together with the front output gear assembly, aligning inside ring claw with block ring groove.




25. Install ball bearing (17), using a bench press.
26. Select a snap ring (16) that will allow the minimum axial play.

Clearance : 0–0.1 mm (0–0.004 in)

Snap ring availability:	
Snap ring thickness	Color coding
1.55 mm (0.061 in)	White
1.60 mm (0.063 in)	Yellow
1.65 mm (0.065 in)	Blue
1.70 mm (0.067 in)	Pink
1.75 mm (0.069 in)	Green
1.80 mm (0.071 in)	Brown
1.85 mm (0.073 in)	Red
1.90 mm (0.075 in)	Orange



262RS015




226RS021

27. Use a pair of snap ring pliers to install the snap ring (16) to the output shaft (31).

Sub-gear (anti-lash plate) preload

1. Hook a length of piano wire (52) over one of the sub-gear (53) teeth.
2. Attach the other end of the piano wire to (52) a spring balancer.
3. Measure the sub-gear preload.

Preload: 59–98 N (13–22 lb)




226RW156

28. Install front output gear assembly (15) to transfer case (42).

29. Use a pair of snap ring pliers to install the snap ring (14) to the transfer case (42).

NOTE: The snap ring must be fully inserted into the transfer case snap ring groove.


30. Use a bench press to install the ball bearing (12) to the input shaft (13). (A/T)



265RS003


4D-36 TRANSFER CASE

31. Install plate (11), ball (10) and bearing collar (9).
32. Install needle bearing (8) and input gear (7).
33. The clutch hub face (with the heavy boss) must be facing the transfer input gear side (55).




34. Install high-low clutch hub and sleeve (6), using a bench press.
 35. Install input shaft assembly (5) to transfer case (42). (A/T)
 36. Install the snap ring (4) to the transfer case (42). (A/T)
- NOTE: The snap ring must be fully inserted into the transfer case snap ring groove.
37. Install the front companion flange temporarily and use the flange holder J-8614-11 and lock nut wrench J-37219 to install the lock nut (3).

Torque: 137 N·m (101 lb ft)



38. Use the punch to stake the lock nut (3) at one spot.
39. Use a suitable drift and hammer to install the ball bearing (2).




40. Install bearing snap ring (1).

Main Data and Specifications

General Specifications


Type	Synchronized type gears shifting between the 2 and 4 wheel drive mode. Constant mesh type gears shifting between "low" and "high".
Control method	Remote (A/T) and direct (M/T) control with the gear shift lever on the floor for gears shifting between "low" and "high". Electric control with the button switch on the instrument panel for gears shifting between the 2 and 4 wheel driver mode.
Gear ratio	High; 1.000 Low; 2.050
Oil capacity	1.45 lit. (1.53 U.S. quart)
Type of lubricant	Engine oil Refer to chart in Section 0

Torque Specifications




E07RW022

4D-38 TRANSFER CASE



E07RX006



E07RX005

Special Tools













ILLUSTRATION	PART NO. PART NAME
 901RS258	J-22912-01 Bearing remover/installer
 901RS269	J-38592 Transfer case oil seal installer
 901RS255	J-37219 Mainshaft nut wrench
 901RS257	J-37223 Rear output shaft and bearing installer
 901RS263	J-39209 Punch; end nut
 901RS271	J-38594 Front output shaft oil seal installer

ILLUSTRATION	PART NO. PART NAME
 901RS272	J-39208 Rear oil seal installer
 901RS273	J-37486-A Bearing installer adapter
 901RW071	J-8614-11 Flange holder
 901RS274	J-37217 Mainshaft end bearing remover
 901RS262	J-37487 Puller
 901RS268	J-8092 Driver handle

RODEO

BRAKES

CONTENTS

Brake Control System	5A-1
Anti-lock Brake System	5B-1
Power-assisted Brake System	5C-1
Parking Brakes (4x4 Model)	5D1-1
Parking Brakes (4x2 Model)	5D2-1

Brake Control System

CONTENTS

Service Precaution	5A-2	Chart A-4 Brake Pedal Feed Is Abnormal .	5A-33
General Description	5A-3	Chart A-5, TA-5 Braking Sound (From EHCUC) Is Heard While Not Braking	5A-34
Functional Description	5A-4	Diagnostic Trouble Codes	5A-35
System Components	5A-10	Diagnosis By "ABS" Warning Light Illumination Pattern	5A-37
Electronic Hydraulic Control Unit (EHCUC) .	5A-10	Diagnostic Trouble Codes (DTCs)	5A-38
ABS Warning Light	5A-10	Chart B-1 With the key in the ON position (Before starting the engine). Warning light (W/L) is not activated.	5A-40
Wheel Speed Sensor	5A-10	Chart B-2 CPU Error (DTC 14 (Flash out) / C0271, C0272, C0273, C0284 (Serial communications))	5A-41
G-Sensor	5A-10	Chart B-3 Low or High Ignition Voltage (DTC 15 (Flash out) / C0277, 0278 (Serial communications))	5A-41
Normal and Anti-lock Braking	5A-10	Chart B-4 Excessive Dump Time (DTC 17 (Flash out) / C0269 (Serial communications))	5A-41
Brake Pedal Travel	5A-10	Chart B-5 Excessive Isolation Time (DTC 18 (Flash out) / C0274 (Serial communications))	5A-42
Acronyms and Abbreviations	5A-10	Chart B-6 G-Sensor Output Failure (DTC 21 (Flash out) / C0276 (Serial communications))	5A-42
General Diagnosis	5A-11	Chart B-7 Brake Switch Failure (DTC 22 (Flash out) / C0281 (Serial communications))	5A-42
General Information	5A-11	Chart B-8 2WD Controller in 4WD Vehicle Controller (DTC 13 (Flash out) / C0285 (Serial communications)), 4WD State Input Signal Failure (DTC 24 (Flash out) / C0282 (Serial communications))	5A-43
ABS Service Precautions	5A-11	Chart B-9 Pump Motor Failure (DTC 32 (Flash out) / C0267, C0268 (Serial communications))	5A-43
Computer System Service Precautions ...	5A-11	Chart B-10 EHCUC Valve Relay Failure (DTC 35 (Flash out) / C0265, C0266 (Serial communications))	5A-44
General Service Precautions	5A-11	Chart B-11 FL Isolation Solenoid Coil Failure (DTC 41 (Flash out) / C0245, C0247 (Serial communications))	5A-44
Note on Intermittents	5A-11	Chart B-12 FL Dump Solenoid Coil Failure (DTC 42 (Flash out) / C0246, C0248 (Serial communications))	5A-44
Test Driving ABS Complaint Vehicles	5A-12		
"ABS" Warning Light	5A-12		
Normal Operation	5A-12		
Tech 2 Scan Tool	5A-13		
DATA LIST	5A-16		
ACTUATOR TEST	5A-17		
Tech 2 Service Bleed	5A-21		
Basic Diagnostic Flow Chart	5A-22		
Basic Inspection Procedure	5A-23		
EHCUC Connector Pin-out Checks	5A-24		
Circuit Diagram	5A-25		
Connector List	5A-28		
Part Location	5A-29		
Symptom Diagnosis	5A-30		
Chart A-1 ABS Works Frequently But Vehicle Does Not Decelerate	5A-30		
Chart TA-1 ABS Works Frequently But Vehicle Does Not Decelerate (Use TECH 2)	5A-31		
Chart A-2 Uneven Braking Occurs While ABS Works	5A-31		
Chart TA-2 Uneven Braking Occurs While ABS Works (Use TECH 2)	5A-31		
Chart A-3, TA-3 The Wheels Are Locked .	5A-32		

5A-2 BRAKE CONTROL SYSTEM

Chart B-13 FR Isolation Solenoid Coil Failure (DTC 43 (Flash out) / C0241, C0243 (Serial communications))	5A-45	Chart B-21 FR Speed Sensor Missing (DTC 62 (Flash out) / C0222, C0223 (Serial communications))	5A-50
Chart B-14 FR Dump Solenoid Coil Failure (DTC 44(Flash out) / C0242, C0244 (Serial communications))	5A-45	Chart B-22 Rear Speed Sensor Missing (DTC 63 (Flash out) / C0236, C0237 (Serial communications))	5A-51
Chart B-15 Rear Isolation Solenoid Coil Failure (DTC 45 (Flash out) / C0251, C0253 (Serial communications))	5A-45	Chart B-23 Simultaneous Drop-out of Front Speed Sensor Signal (DTC 64 (Flash out) / C0229 (Serial communications)) ...	5A-52
Chart B-16 Rear Dump Solenoid Coil Failure (DTC 46 (Flash out) / C0252, C0254 (Serial communications))	5A-46	Chart B-24 Wheel Speed Input Abnormality (DTC 65 (Flash out) / C0238 (Serial communications))	5A-53
Chart B-17 FL Speed Sensor Open or Shorted (DTC 51 (Flash out) / C0225 (Serial communications))	5A-46	Unit Inspection Procedure	5A-54
Chart B-18 FR Speed Sensor Open or Shorted (DTC 52 (Flash out) / C0221 (Serial communications))	5A-47	Chart C-1-1 FL Sensor Output Inspection Procedure	5A-54
Chart B-19 Rear Speed Sensor Open or Shorted (DTC 53 (Flash out) / C0235 (Serial communications))	5A-48	Chart C-1-2 FR Sensor Output Inspection Procedure	5A-55
Chart B-20 FL Speed Sensor Missing (DTC 61 (Flash out) / C0226, C0227 (Serial communications))	5A-49	Chart C-1-3 Rear Sensor Output Inspection Procedure	5A-55
		Chart TC-1 Sensor Output Inspection Procedure	5A-56
		Special Tools	5A-57

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.


CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

The Anti-lock Brake System (ABS) works on all four wheels. A combination of wheel speed sensor and Electronic Hydraulic Control Unit (EHCU) can determine when a wheel is about to stop turning and adjust brake pressure to maintain best braking.

This system helps the driver maintain greater control of the vehicle under heavy braking conditions.

NOTE: The Electronic Hydraulic Control Unit (EHCU) comprises the Hydraulic Unit (H/U) and the coil Integrated Module.



C05RW004

Legend


- | | |
|--------------------------|--|
| (1) Electronic | (4) Coil Integrated Module |
| (2) Hydraulic | (5) Front Wheel Speed Sensor |
| (3) Hydraulic Unit (H/U) | (6) Rear Wheel Speed Sensor |
| | (7) Proportioning and Bypass (P&B) Valve |

5A-4 BRAKE CONTROL SYSTEM

Functional Description

Hydraulic Unit (H/U)

Solenoid Valve



C05RW012


Legend

- (1) Isolation Valve
- (2) Dump valve

Normal Braking

During normal (non anti-lock) braking, the solenoid valves are without current and closed due to spring force.

Brake fluid travels through the centre of the normally open isolation valve around the normally closed dump valve and on to the brake pistons.



C05RW010

Legend


- (1) Brake
- (2) Master Cylinder

5A-6 BRAKE CONTROL SYSTEM

Pressure Isolation (Pressure Maintain)

The electro-hydraulic control unit is activated when the brakes are applied which sends a signal to the coil integrated module to prepare for a possible anti-lock stop. If the information from the wheel speed sensors indicates excessive wheel deceleration (imminent lockup), the first step in the anti-lock sequence is to isolate the brake pressure being applied by the brake pedal.

The microprocessor in the coil integrated module sends a voltage to the coil to energize and close the isolation valve. This prevents any additional fluid pressure applied by the brake pedal from reaching the wheel. With the isolation valves closed, further unnecessary increase in the brake pressure is therefore prevented.



C05RW011

Legend


- (1) Brake
- (2) Master Cylinder

Pressure Reduction

Once the brake pressure is isolated, it must be reduced to allow the wheels to unlock. This is accomplished by dumping a portion of the brake fluid pressure into a low pressure accumulator.

The microprocessor activates the normally closed dump valve to open, allowing fluid from the wheels to be dumped into the accumulator. This is done with very short activation pulses opening and closing the dump valve passageway. Brake pressure is reduced at the wheel and allows the wheel to begin rotating again. The fluid from the brake piston is stored in the accumulator against spring pressure and a portion of this fluid also primes the pump.

The dump valves are operated independently to control the deceleration of the wheel. At this point, the brake pedal is isolated from the base brake system, the hydraulic control unit pumps are primed and the attenuators are ready to pump fluid.



C05RW009

Legend

- (1) Brake
- (2) Master Cylinder


5A-8 BRAKE CONTROL SYSTEM

Pressure Increase (Re-apply)

The re-apply sequence is initiated to achieve optimum braking. The isolation valve is momentarily opened to allow master cylinder and pump pressure to reach the brakes. This controlled pressure rise continues until the wheel is at optimum brake output or until the brake pressure is brought up to the master cylinder output pressure.

If more pressure is required, more fluid is drawn from the master cylinder and applied to the brakes. The driver may feel slight pedal pulsations, or pedal drop, this is normal and expected.

As fluid is re-applied to the brakes, the wheel speed will reduce. If the wheels approach imminent lockup again, the module will isolate, dump and re-apply again. This cycle occurs in millisecond intervals, allowing several cycles to occur each second. It is a much faster and more controlled way of "pumping the pedal".



C05RW014


Legend

- (1) Brake
- (2) Master Cylinder

Brake Release

At the end of the anti-lock stop, when the brake pedal is released, the pump will remain running for a short time to help drain any fluid from the accumulators. As this fluid returns into the system, the spring forces the piston back to its original position.

The isolation valve opens and fluid may return to the master cylinder. Conventional braking is then resumed.



C05RW013

Legend

- (1) Brake
- (2) Master Cylinder

System Components

Electronic Hydraulic Control Unit (EHCU), three Wheel Speed Sensors, Warning Light, and G-sensor.

Electronic Hydraulic Control Unit (EHCU)

The EHCU consists of ABS control circuits, fault detector, and a fail-safe. It drives the hydraulic unit according to the signal from each sensor, cancelling ABS to return to normal braking when a malfunction has occurred in the ABS.

The EHCU has a self-diagnosing function which can indicate faulty circuits during diagnosis.

The EHCU is mounted on the engine compartment rear right side. It consists of a Motor, Plunger Pump, Solenoid Valves.

Solenoid Valves: Reduces or holds the caliper fluid pressure for each front disc brake or both rear disc brakes according to the signal sent from the EHCU.


Reservoir: Temporarily holds the brake fluid that returns from the front and rear disc brake caliper so that pressure of front disc brake caliper can be reduced smoothly.

Plunger Pump: Feeds the brake fluid held in the reservoir to the master cylinder.

Motor: Drives the pump according to the signal from EHCU.

Check Valve: Controls the brake fluid flow.

ABS Warning Light



Vehicles equipped with the Anti-lock Brake System have an amber "ABS" warning light in the instrument panel. The "ABS" warning light will illuminate if a malfunction in the Anti-lock Brake System is detected by the Electronic Hydraulic Control Unit (EHCU). In case of an electronic malfunction, the EHCU will turn "ON" the "ABS" warning light and disable the Anti-lock braking function.

The "ABS" light will turn "ON" for approximately three seconds after the ignition switch is to the "ON" position. If the "ABS" light stays "ON" after the ignition switch is the "ON" position, or comes "ON" and stays "ON" while driving, the Anti-lock Brake System should be inspected for a malfunction according to the diagnosis procedure.

Wheel Speed Sensor

It consists of a sensor and a rotor. The sensor is attached to the knuckle on the front wheels and to the rear axle case on the rear differential.

The rotor is press-fit in the axle shaft.

The flux generated from electrodes magnetized by a magnet in the sensor varies due to rotation of the rotor, and the electromagnetic induction generates alternating voltage in the coil. This voltage draws a "sine curve" with the frequency proportional to rotor speed and it allows detection of wheel speed.

G-Sensor

The G-sensor installed inside the EHCU detects the vehicle deceleration speed and sends a signal to the EHCU. In 4WD operation, all four wheels may be decelerated in almost the same phase, since all wheels are connected mechanically.

This tendency is noticeable particularly on roads with low friction coefficient, and the ABS control is adversely affected.

The G-sensor judges whether the friction coefficient of road surface is low or high, and changes the EHCU's operating system to ensure ABS control.

Normal and Anti-lock Braking

Under normal driving conditions, the Anti-lock Brake System functions the same as a standard power assisted brake system. However, with the detection of wheel lock-up, a slight bump or kick-back will be felt in the brake pedal. This pedal "bump" will be followed by a series of short pedal pulsations which occurs in rapid succession. The brake pedal pulsation will continue until there is no longer a need for the anti-lock function or until the vehicle is stopped. A slight ticking or popping noise may be heard during brake applications when the Anti-lock features is being used.

When the Anti-lock feature is being used, the brake pedal may rise even as the brakes are being applied. This is also normal. Maintaining a constant force on the pedal will provide the shortest stopping distance.

Brake Pedal Travel

Vehicles equipped with the Anti-lock Brake System may be stopped by applying normal force to the brake pedal. Although there is no need to push the pedal beyond the point where it stops or holds the vehicle, by applying more force the pedal will continue to travel toward the floor. This extra brake pedal travel is normal.

Acronyms and Abbreviations

Several acronyms and abbreviations are commonly used throughout this section:

ABS

Anti-lock Brake System

CIM

Coil Integrated Module

CKT

Circuit

DLC

Data Link Connector

EHC

Electronic Hydraulic Control Unit

FL

Front Left

FR

Front Right

GEN

Generator

H/U

Hydraulic Unit

MV

Millivolts

RR

Rear

RPS

Revolution per Second

VDC

DC Volts

VAC

AC Volts

W/L

Warning Light

WSS

Wheel Speed Sensor

General Diagnosis

General Information

ABS troubles can be classified into two types, those which can be detected by the ABS warning light and those which can be detected as a vehicle abnormality by the driver.

In either case, locate the fault in accordance with the "BASIC DIAGNOSTIC FLOWCHART" and repair.

Please refer to Section 5C for the diagnosis of mechanical troubles such as brake noise, brake judder (brake pedal or vehicle vibration felt when braking), uneven braking, and parking brake trouble.

ABS Service Precautions

Required Tools and Items:

- Box Wrench
- Brake Fluid
- Special Tool

Some diagnosis procedures in this section require the installation of a special tool.

J-39200 High Impedance Multimeter

When circuit measurements are requested, use a circuit tester with high impedance.

Computer System Service Precautions

The Anti-lock Brake System interfaces directly with the Electronic Hydraulic Control Unit (EHC) which is a control computer that is similar in some regards to the

Powertrain Control Module. These modules are designed to withstand normal current draws associated with vehicle operation. However, care must be taken to avoid overloading any of the EHC circuits. In testing for opens or shorts, do not ground or apply voltage to any of the circuits unless instructed to do so by the appropriate diagnostic procedure. These circuits should only be tested with a high impedance multimeter (J-39200) or special tools as described in this section. Power should never be removed or applied to any control module with the ignition in the "ON" position.

Before removing or connecting battery cables, fuses or connectors, always turn the ignition switch to the "OFF" position.

General Service Precautions

The following are general precautions which should be observed when servicing and diagnosing the Anti-lock Brake System and/or other vehicle systems. Failure to observe these precautions may result in Anti-lock Brake System damage.

- If welding work is to be performed on the vehicle using an electric arc welder, the EHC and valve block connectors should be disconnected before the welding operation begins.
- The EHC and valve block connectors should never be connected or disconnected with the ignition "ON" .
- If only rear wheels are rotated using jacks or drum tester, the system will diagnose a speed sensor malfunction and the "ABS" warning light will illuminate. But actually no trouble exists. After inspection stop the engine once and re-start it, then make sure that the "ABS" warning light does not illuminate.

If the battery has been discharged

The engine may stall if the battery has been completely discharged and the engine is started via jumper cables. This is because the Anti-lock Brake System (ABS) requires a large quantity of electricity. In this case, wait until the battery is recharged, or set the ABS to a non-operative state by removing the fuse for the ABS (60A). After the battery has been recharged, stop the engine and install the ABS fuse. Start the engine again, and confirm that the ABS warning light does not light.

Note on Intermittents

As with virtually any electronic system, it is difficult to identify an intermittent failure. In such a case duplicating the system malfunction during a test drive or a good description of vehicle behavior from the customer may be helpful in locating a "most likely" failed component or circuit. The symptom diagnosis chart may also be useful in isolating the failure. Most intermittent problems are caused by faulty electrical connections or wiring. When an intermittent failure is encountered, check suspect circuits for:

- Suspected harness damage.
- Poor mating of connector halves or terminals not fully seated in the connector body (backed out).
- Improperly formed or damaged terminals.

Test Driving ABS Complaint Vehicles

In case that there has been an abnormality in the lighting pattern of "ABS" warning light, the fault can be located in accordance with the "DIAGNOSIS BY "ABS" WARNING LIGHT ILLUMINATION PATTERN" . In case of such trouble as can be detected by the driver as a vehicle symptom, however, it is necessary to give a test drive following the test procedure mentioned below, thereby reproducing the symptom for trouble diagnosis on a symptom basis:

1. Start the engine and make sure that the "ABS" W/L goes OFF. If the W/L remains ON, it means that the Diagnostic Trouble Code (DTC) is stored. Therefore, read the code and locate the fault.

NOTE: The DTC cannot be cleared if the vehicle speed does not exceed 12 km/h (8 mph) at DTC, even though the repair operation is completed.

2. Start the vehicle and accelerate to about 30 km/h (19 mph) or more.
3. Slowly brake and stop the vehicle completely.
4. Then restart the vehicle and accelerate to about 40 km/h (25 mph) or more.
5. Brake at a time so as to actuate the ABS and stop the vehicle.
6. Be cautious of abnormality during the test. If the W/L is actuated while driving, read the DTC and locate the fault.
7. If the abnormality is not reproduced by the test, make best efforts to reproduce the situation reported by the customer.
8. If the abnormality has been detected, repair in accordance with the "SYMPTOM DIAGNOSIS" .

NOTE:

- Be sure to give a test drive on a wide, even road with a small traffic.
- If an abnormality is detected, be sure to suspend the test and start trouble diagnosis at once.

"ABS" Warning Light

When ABS trouble occurs to actuate "ABS" warning light, the trouble code corresponding to the trouble is stored in the EHCUC. Only ordinary brake is available with ABS being unactuated. Even when "ABS" warning light is actuated, if the starter switch is set ON after setting it OFF once, the EHCUC checks up on the entire system and, if there is no abnormality, judges ABS to work currently and the warning light is lit normally even though the trouble code is stored.

NOTE: Illumination of the "ABS" warning light indicates that anti-lock braking is no longer available. Power assisted braking without anti-lock control is still available.


Normal Operation

"ABS" Warning Light

When the ignition is first moved from "OFF" to "RUN" , the amber "ABS" warning light will turn "ON" . The "ABS" warning light will turn "ON" during engine starting and will usually stay "ON" for approximately three seconds after the ignition switch is returned to the "ON" position. The warning light should remain "OFF" at all other times.

Tech 2 Scan Tool

From 98 MY, Isuzu dealer service departments are recommended to use Tech 2. Please refer to Tech 2 scan tool user guide.



901RW257

Legend


- (1) PCMCIA Card
- (2) SAE 16/19 Adaptor

- (3) DLC Cable
- (4) Tech-2

5A-14 BRAKE CONTROL SYSTEM

Getting Started

- Before operating the Isuzu PCMCIA card with the Tech 2, the following steps must be performed:
 1. The Isuzu 98 System PCMCIA card (1) inserts into the Tech 2 (4).
 2. Connect the SAE 16/19 adapter (2) to the DLC cable (3).
 3. Connect the DLC cable to the Tech 2 (4).
 4. Make sure the vehicle ignition is off.
 5. Connect the Tech 2 SAE 16/19 adapter to the vehicle DLC.





6. The vehicle ignition turns on.
7. Power up the Tech 2.
8. Verify the Tech 2 power up display.



Operating Procedure

The power up screen is displayed when you power up the tester with the Isuzu systems PCMCIA card. Follow the operating procedure below.





5A-16 BRAKE CONTROL SYSTEM

DATA LIST

The data displayed by DATA LIST are as follows:

Display	Content	OK/NG Criteria for Data
Front Left Wheel Speed Front Right Wheel Speed Rear Wheel Speeds	km/h (MPH)	<input type="radio"/> Start the vehicle and make sure of linear change in each wheel speed. <input type="radio"/> Turn each wheel by hand and make sure that each speed data change.
Warning Lamp	ON/OFF	<input type="radio"/> To be OFF usually
ABS State	ON/OFF	<input type="radio"/> To be OFF usually
ABS Relay	Active/Inactive	<input type="radio"/> To be Active usually
4 Wheel Drive	Active/Inactive	<input type="radio"/> 2WD: Inactive <input type="radio"/> 4WD: Active
Brake Switch	Active/Inactive	<input type="radio"/> Inactive (Released) <input type="radio"/> Active (Pressed)
Brake Fluid Level	Normal or not	<input type="radio"/> To be Normal usually
Return Pump	Active/Inactive	<input type="radio"/> To be Inactive usually
DRP (Dynamic Rear Proportioning)	Active/Inactive	<input type="radio"/> To be Inactive usually
Rear Dump Valve Commanded	Active/Inactive	<input type="radio"/> To be Inactive usually
Rear Dump Valve Feedback		
Rear Isolation Valve Commanded		
Rear Isolation Valve Feedback		
FL Dump Valve Commanded	Active/Inactive	<input type="radio"/> To be Inactive usually
FL Dump Valve Feedback		
FL Isolation Valve Commanded		
FL Isolation Valve Feedback		
FR Dump Valve Commanded	Active/Inactive	<input type="radio"/> To be Inactive usually
FR Dump Valve Feedback		
FR Isolation Valve Commanded		
FR Isolation Valve Feedback		
G-Sensor	Voltage	<input type="radio"/> 0.00V when vehicle is stopped
Battery Voltage	Voltage	<input type="radio"/> Between 10-16.9V

ACTUATOR TEST

This mode is used to exercise the ABS actuators and make sure they operate normally. Prior to the test, pay attention to the cautions below. (When checking the solenoid valve system, be sure to jack up the vehicle.)

CAUTION:

- Before testing, be sure that the brakes work normally.
- Make sure that the battery is fully charged. Conduct the test by two persons (A TECH 2 operator and a vehicle checker).

- Be sure to start ACTUATOR TEST with the engine stopped.
- Before testing, make sure that electrical trouble, if any, has been completely repaired. Conducting tests of ABS solenoid with electrical circuit problem remaining uncorrected could damage the control unit.

Application Menu
F0: Diagnostic Trouble Codes
F1: Data Display
F2: Snapshot
F3: Actuator Test
F4: Miscellaneous Tests

Select "F3: Actuator Test" by function key from Application Menu, and push enter key.

Application Menu
F0: Return Pump Relay Test
F1: Front Left Solenoid Valve Test
F2: Front Right Solenoid Valve Test
F3: Rear Left Solenoid Valve Test
F4: Rear Left Solenoid Valve Test

Return Pump Relay Test:
Select "F0: Return Pump Relay Test" and push enter key.

Return Pump Relay Test	
(X) 1999 (UE) Rodeo/Amigo	
Electronic System: ABS	
Front Left Wheel Speed	0 km/h
Front Right Wheel Speed	0 km/h
Rear Wheel Speeds	0 km/h
Warning Lamp	Off
ABS State	Off
ABS Relay	Active
4 Wheel Drive	Inactive
Return Pump	Inactive
Quit	On Off

Using soft key, check the return pump function.

F05RX001

5A-18 BRAKE CONTROL SYSTEM

Application Menu

F0: Return Pump Relay Test
F1: Front Left Solenoid Valve Test
F2: Front Right Solenoid Valve Test
F3: Rear Left Solenoid Valve Test
F4: Rear Right Solenoid Valve Test

Solenoid Valve Test:
Select required Solenoid Valve Test and
push the enter key.

Front Left Solenoid Valve Test
(X) 1999 (UE) Rodeo/Amigo
Electronic System: ABS

Before Running this Test
See Checking Procedure !

Confirm

Push the soft key under "Confirm" box.

Release brake pedal.

Front Left Solenoid Valve Test
(X) 1999 (UE) Rodeo/Amigo
Electronic System: ABS

Normal Function

Brake Switch | Inactive


Wheel Turnable ?

Yes No

Normal Function:
Rotate the wheel.
Yes: Go to next display
No: Failed, check hydraulic brake system.
Refer to Power-assisted brake system section.

Go to next page

F05RX002



F05RX003

Depress and hold brake pedal.

Front Left Solenoid Valve Test
(X) 1999 (UE) Rodeo/Amigo
Electronic System: ABS
Normal Function
Brake Switch | Active
Wheel Blocked?

Reapply Function:
Rotate the wheel.
Yes: Go to next display
No: Failed, check brake line and bleed air.
Refer to Power-assisted brake system section.

Front Left Solenoid Valve Test
(X) 1999 (UE) Rodeo/Amigo
Electronic System: ABS
Test passed successfully !

Test completed.
To return Application Menu, push the soft key
under "Confirm" box.

Tech 2 Service Bleed

Application Menu
F0: Diagnostic Trouble Codes
F1: Data Display
F2: Snapshot
F3: Actuator Test
F4: Miscellaneous Tests

Select "F4: Miscellaneous Tests" by function key
ey.

NOTE: Apply parking brake firmly while servicing.
When operate EHCU by using Tech 2,
start the engine.

Application Menu
F0: Brake Bleed

Push enter key.

Brake Bleed
(X) 1999 (UE) Rodeo/Amigo
Electronic System: ABS
1st Time
Perfome Manual Bleed Procedure Until Fluid Flows With No Air Present.
Continue


Push the soft key under "Continue" box.

Depress and hold brake pedal.

Brake Bleed
(X) 1999 (UE) Rodeo/Amigo
Electronic System: ABS
1st Time
Depress And Hold Brake Pedal !
Activate
Yes No

To start brake bleed, push the soft key
under "Yes" box.

5A-22 BRAKE CONTROL SYSTEM



Basic Diagnostic Flow Chart

Step	Action	Yes	No
1	1. Customer complaint. 2. Questioning to customer. 3. Basic inspection (Refer to "Basic inspection procedure") Using TECH 2?	Go to Step 2	Go to Step 4
2	Make sure of DTC by mode "F0: Diagnostic Trouble Codes". Is EHCUC including DTC?	Clear code and check for repeatability. Go to Step 3	Go to Step 5
3	1. Repair of faulty part. 2. Elimination of DTC. 3. Inspection of "ABS" W/L Illumination pattern with ignition SW "ON". 4. Test drive. Does trouble repeat?	Repeat the diagnosis if the symptom or DTC appears again Go to Step 1	Go to Step 5
4	Check if the DTC is stored or not. Is EHCUC including DTC?	Clear code and check for repeatability Go to Step 3	Trouble diagnosis based on symptom (Refer to "SYMPTOM DIAGNOSIS") Go to Step 3
5	1. Reconnect all components. Ensure all component are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Finished	Go to Step 5

Basic Inspection Procedure

1. Basic Inspection of Service Brake

Step	Action	Yes	No
1	Is the fluid level normal?	Go to Step 2	Replenish with fluid Go to Step 2
2	Does fluid leak?	Repair Go to Step 3	Go to Step 3
3	Is the booster function normal?	Go to Step 4	Repair Go to Step 4
4	Is the pad and rotor normal?	Go to Step 5	Repair Go to Step 5
5	Reconnect all components. Ensure all component are properly mounted. Was this step finished?	Finished	Go to Step 5

2. Ground Inspection

Step	Action	Yes	No
1	Does ABS—related ground points normally?	Go to Step 2	Repair Go to Step 2
2	Reconnect all components. Ensure all component are properly mounted. Was this step finished?	Finished	Go to Step 2


5A-24 BRAKE CONTROL SYSTEM


EHCU Connector Pin-out Checks


- Disconnect Electronic Hydraulic Control Module.
- Perform checks with high impedance digital multimeter J-39200 or equivalent.

No.	Circuit to be Tested	Ignition Switch Position	Multimeter Scale/Range	Measure between Pin Number	Nominal Value	Note
1	Power supply	OFF	20DCV	1 (C-5) 2 (C-5)	11.5V to 14.5V	
2	Ignition enable	OFF	20DCV	1 (C-4) 7 (C-4)	0V to 0.1V	
		ON	20DCV	1 (C-4) 7 (C-4)	11.5V to 14.5V	
3	Stoplight switch	OFF	20DCV	13 (C-4) 7 (C-4)	10.5V to 14.5V	Press brake pedal
4	Ground connection	OFF	200 Ω	7 (C-4) Ground	Less than 2 Ω	
		OFF	1 Ω	2 (C-5) Ground	Less than 0.2 Ω	
5	FL speed sensor	OFF	2k Ω	2 (C-4) 10 (C-4)	2.0k Ω to 2.8k Ω	Internal Resistance
		OFF	200k Ω	2 (C-4) 7 (C-4)	more than 100k Ω	Insulation Resistance
		OFF	200mACV	2 (C-4) 10 (C-4)	more than 200mV	Turn wheel at 1RPS
6	FR speed sensor	OFF	2k Ω	3 (C-4) 11 (C-4)	2.0k Ω to 2.8k Ω	Internal Resistance
		OFF	200k Ω	3 (C-4) 7 (C-4)	more than 100k Ω	Insulation Resistance
		OFF	200mACV	3 (C-4) 11 (C-4)	more than 200mV	Turn wheel at 1RPS
7	RR speed sensor	OFF	2k Ω	4 (C-4) 12 (C-4)	1.2k Ω to 2.0k Ω	Internal Resistance
		OFF	200k Ω	4 (C-4) 7 (C-4)	more than 100k Ω	Insulation Resistance
		OFF	200mACV	4 (C-4) 12 (C-4)	more than 200mV	Turn wheel at 1RPS

Circuit Diagram

























5A-28 BRAKE CONTROL SYSTEM

Connector List

No.	Connector face	No.	Connector face
B-19		H-13 H-14	 
C-4		H-26	 
C-5		I-1	
C-13 C-33		I-18	
C-16 C-36 E-28 E-30			
C-34			
F-4			
H-5	 		
H-12 H-15 H-25	 		

Part Location



D08RX107

Legend

- | | |
|----------------------|-------------------|
| (1) Battery | (11) F-4 |
| (2) Fuse & Relay Box | (12) H-26 |
| (3) C-36 | (13) H-25 |
| (4) C-5 | (14) H-15 |
| (5) C-4 | (15) C-16 |
| (6) H-12, 13, 14 | (16) C-13 |
| (7) I-18 | (17) H-5 |
| (8) Starter Switch | (18) B-19 |
| (9) I-1 | (19) E-30 (6VD1) |
| (10) C-34 | (20) E-28 (X22SE) |
| | (21) C-33 |

5A-30 BRAKE CONTROL SYSTEM

Symptom Diagnosis

The symptoms that cannot be indicated by warning light can be divided in the following five categories:

1. ABS works frequently but vehicle does not decelerate.
2. Uneven braking occurs while ABS works.
3. The wheels lock during braking.

4. Brake pedal feel is abnormal.

5. Braking sound (from EHCUC) is heard while not braking.

These are all attributable to problems which cannot be detected by EHCUC self-diagnosis. Use the customer complaint and a test to determine which symptom is present. Then follow the appropriate flow chart listed below.

No.	Symptom	Diagnostic Flow Charts	
		Without TECH 2	With TECH 2
1	ABS works frequently but vehicle does not decelerate.	Chart A-1	Chart TA-1
2	Uneven braking occurs while ABS works.	Chart A-2	Chart TA-2
3	The wheels are locked.	Chart A-3	Chart TA-3
4	Brake pedal feel is abnormal.	Chart A-4	—
5	Braking sound (from EHCUC) is heard while not braking.	Chart A-5	Chart TA-5

Chart A-1 ABS Works Frequently But Vehicle Does Not Decelerate

Step	Action	Yes	No
1	Is braking force distribution normal between front and rear of vehicle?	Go to Step 2	Repair brake parts. Go to Step 8
2	Are axle parts installed normally?	Go to Step 3	Repair axle parts. Go to Step 8
3	Is there play in each or any wheel speed sensor?	Repair wheel speed sensor. Go to Step 8	Go to Step 4
4	Is there damage, or powered iron sticking to each or any wheel speed sensor/sensor ring?	Replace sensor or sensor ring. Go to Step 8	Go to Step 5
5	Is the output of each wheel speed sensor normal? (Refer to chart C-1 or TC-1)	Go to Step 6	Replace wheel speed sensor or repair harness. Go to Step 7
6	Is the input of 4WD controller normal?	Go to Step 7	Replace controller or repair harness. Go to Step 7
7	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 7

Chart TA-1 ABS Works Frequently But Vehicle Does Not Decelerate (Use TECH 2)

Step	Action	Yes	No
1	1. Connect TECH 2. 2. Make sure of the output conditions of each sensor. Is the output of each sensor normal?	Go to Step 2	Replace wheel speed sensor. Go to Step 3
2	Return to Chart A-1. Was the Chart A-1 finished?	Go to Step 3	Go to Step 2
3	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart A-2 Uneven Braking Occurs While ABS Works

Step	Action	Yes	No
1	Is there play in each or any sensor?	Repair. Go to Step 5	Go to Step 2
2	Damage or powdered iron sticking to each or any sensor/sensor ring?	Repair. Go to Step 5	Go to Step 3
3	Is the output of each sensor normal? (Refer to chart C-1 or TC-1)	Go to Step 4	Replace sensor or repair harness. Go to Step 5
4	Is brake pipe connecting order correct?	Replace H/U. Go to Step 5	Reconnect brake pipe correctly. Go to Step 5
5	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 5

Chart TA-2 Uneven Braking Occurs While ABS Works (Use TECH 2)

Step	Action	Yes	No
1	1. Connect TECH 2. 2. Make sure of the output conditions of each sensor. Is the output of each sensor normal?	Go to Step 2	Go to Step 3
2	Check piping by TECH 2 ACTUATOR TEST Is the piping normal?	Replace EHC. U. Go to Step 4	Repair the pipe. Go to Step 4
3	Repair and check the wheel speed sensor (Refer to chart B-20 to B-23 , C-1 or TC-1). Was the each chart finished?	Go to Step 4	Go to Step 3
4	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 4

5A-32 BRAKE CONTROL SYSTEM**Chart A-3, TA-3 The Wheels Are Locked**

Step	Action	Yes	No
1	Is ABS working?	Go to Step 2	Go to Step 6
2	Is vehicle speed under 10 km/h (6mph)?	Normal.	Go to Step 3
3	Is sensor output normal? (Chart C-1 or TC-1)	Go to Step 4	Replace sensor or repair harness. Go to Step 6
4	Is front 4WD controller normal?	Go to Step 5	Replace 4WD controller or repair harness. Go to Step 6
5	Is hydraulic unit grounded properly?	Replace EHC.U. Go to Step 6	Correct. Go to Step 6
6	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

Chart A-4 Brake Pedal Feed Is Abnormal

Step	Action	Yes	No
1	Is the stop light actuated when the brake pedal is depressed?	Go to Step 2	Go to Step 3
2	1. Turn the ignition switch off. 2. Disconnect EHCUC connector. Is the check voltage EHCUC connector terminals 13 to 7 when brake pedal is depressed than battery voltage?	Go to Step 4	Harness NG between brake SW and EHCUC. Go to Step 6
3	Is stop light fuse normal?	Go to Step 5	Replace stop light fuse. Go to Step 6
4	Is the check continuity between EHCUC connector terminals, 7 to body grounded?	Go to Step 6	Repair body grounded harness. Go to Step 6
5	Is brake SW normal?	Repair stop light harness. Go to Step 6	Replace brake SW. Go to Step 6
6	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

5A-34 BRAKE CONTROL SYSTEM

Chart A-5, TA-5 Braking Sound (From EHCU) Is Heard While Not Braking

Step	Action	Yes	No
1	Is this the first vehicle start after engine start?	It is self checking sound Normal.	Go to Step 2
2	Is vehicle speed under 10 km/h (6 mph)?	It is self checking sound Normal.	Go to Step 3
3	Check for the following condition: <input type="radio"/> At the time of shift down or clutch operation. <input type="radio"/> At the time of low road friction drive (ice or snow road) or rough road drive. <input type="radio"/> At the time of high-speed turn. <input type="radio"/> At the time of passing curb. <input type="radio"/> At the time of operating electrical equipment switches. <input type="radio"/> At the time of racing the engine (over 5000 rpm). Did it occur under any one condition above?	ABS may sometime be actuated even when brake pedal is not applied.	Go to Step 4
4	Is there play in each or any sensor/wheel speed sensor rings?	Repair. Go to Step 7	Go to Step 5
5	Damage or powdered iron sticking to each or any sensor/wheel speed sensor ring?	Repair. Go to Step 7	Go to Step 6
6	Is each sensor output normal? (Refer to chart C-1 or TC-1).	Check harness/connector for suspected disconnection If no disconnection is found, replace Coil integrated module. Go to Step 7	Repair. Go to Step 7
7	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 7

Diagnostic Trouble Codes

Choose and trace an appropriate flowchart by the numbers listed below to find fault and repair.

Code		Diagnosis	Item	Chart No.
Flash out	Serial Communications			
12	—	—	—	—
13	C0285	2 WD Controller in 4WD Vehicle Controller	Wiring	B-8
14	C0271	RAM read/write error	Coil Integrated Module	B-2
	C0272	ROM checksum error		
	C0270	ALU function error		
	C0273	Inoperative isolation item		
	C0284	Loop time overrun		
15	C0277	Low ignition voltage	Wiring	B-3
	C0278	High ignition voltage		
17	C0269	Excessive dump time	Coil Integrated Module	B-4
18	C0274	Excessive isolation time		B-5
21	C0276	G-Sensor Failure		B-6
22	C0281	Brake switch Failure		B-7
24	C0282	Open or shorted 4×4 input signal (4WD only)	Wiring	B-8
32	C0267	Open motor circuit or shorted ECU output	Motor	B-9
	C0268	Stalled motor or open ECU output		
35	C0265	Open relay circuit	Relay	B-10
	C0266	Shorted relay circuit		
41	C0245	FL Open isolation solenoid or shorted ECU output	Solenoid	B-11
	C0247	FL Shorted isolation solenoid or open ECU output		
42	C0246	FL Open dump solenoid or shorted ECU output		B-12
	C0248	FL Shorted dump solenoid or open ECU output		
43	C0241	FR Open isolation solenoid or shorted ECU output		B-13
	C0243	FR Shorted isolation solenoid or open ECU output		
44	C0242	FR Open dump solenoid or shorted ECU output		B-14
	C0244	FR Shorted dump solenoid or open ECU output		
45	C0251	Rear Open isolation solenoid or shorted ECU output		B-15
	C0253	Rear Shorted isolation solenoid or open ECU output		
46	C0252	Rear Open dump solenoid or shorted ECU output		B-16
	C0254	Rear Shorted dump solenoid or open ECU output		

5A-36 BRAKE CONTROL SYSTEM

Code		Diagnosis	Item	Chart No.
Flash out	Serial Communications			
51	C0225	FL Open or shorted sensor	Sensor or Wiring	B-17
52	C0221	FR Open or shorted sensor		B-18
53	C0235	Rear Open or shorted sensor		B-19
61	C0226	FL Missing sensor signal		B-20
	C0227	FL Sensor signal dropout		
62	C0222	FR Missing sensor signal		B-21
	C0223	FR Sensor signal dropout		
63	C0236	Rear Missing sensor signal		B-22
	C0237	Rear Sensor signal dropout		
64	C0229	Simultaneous dropout of front sensor signal	Vehicle or Sensor	B-23
65	C0238	Wheel speed error		B-24
—	C0286	Shorted indicator lamp	Wiring	—

Diagnosis By “ABS” Warning Light Illumination Pattern

In the event that there is abnormality in the “ABS” warning light illumination pattern while the key is in the ON position or if the warning light is actuated during driving, trouble should be diagnosed on a illumination pattern basis as follows:

No.	Condition	“ABS” Warning Light Illumination Pattern	Diagnostic
1	Warning light is actuated normally	<p>Warning light: ON, OFF</p> <p>Starter SW: ON, OFF</p> <p>Still not lit during driving</p>	Normal
2	Warning light is not lit	<p>Warning light: ON, OFF</p> <p>Starter SW: ON, OFF</p>	Warning light lighting circuit trouble→Go to Chart B-1
3	Warning light remains ON	<p>Warning light: ON, OFF</p> <p>Starter SW: ON, OFF</p>	Diagnostic trouble codes are stored. Display diagnostic trouble codes and diagnose on a code basis according to the flow charts.
4	Warning light is actuated while driving	<p>Warning light: ON, OFF</p> <p>Starter SW: ON, OFF</p> <p>During driving</p>	Diagnostic trouble codes are stored. Display diagnostic trouble codes and diagnose on a code basis according to the flow charts.
5	Warning light goes at 12 km/h (8 mph) or higher (After repairing the faulty part)	<p>Warning light: ON, OFF</p> <p>Starter SW: ON, OFF</p> <p>Speed: 0 kph, 12 km/h (8 mph)</p>	Even after repairing the faulty part the warning light (W/L) does not go out if vehicle is at a stop. Turn the ignition switch to the ON position and drive the vehicle at 12 km/h (8 mph) or higher to make sure that the warning light goes out.

Diagnostic Trouble Codes (DTCs)


When the warning light in the meter remains ON, the EHCU stores the fault identification and disables the ABS.

How to display and erase DTCs:

NOTE:

- DTCs can be displayed also by TECH 2. Use “Diagnostic Trouble Codes” mode.

The DLC is located behind the driver side kick panel



- Keep #12 terminal connected with #4 terminal or #5 terminal (GND) during DTC display. (If #12 terminal is separated from #4 terminal or #5 terminal (GND) during display, display will stop.)

2. DTC display:


- DTC is displayed by blinking warning light.
- Double-digit display.
- First, normal DTC 12 is displayed three times and then any other DTCs are displayed three times. (If no other DTCs have been stored, the display of DTC 12 will be repeated.)

1. How to start DTC display:

- Confirm that the vehicle has come to a complete stop (with the wheels standing still) and that the brake pedal is not depressed. (Unless these two condition are satisfied, DTC display cannot be started.)
- With IGN OFF, connect #12 terminal with #4 terminal or # 5 terminal (GND) . Then turn IGN ON.

3. How to erase code:

- Conduct brake switch ON/OFF operation 6 or more times within 3 seconds of self-diagnosis startup.
- The code cannot be erased if more than 3 seconds have passed since self-diagnosis startup, or if self-diagnosis has started with brake switched on (brake pedaled).




B05RW005

4. Notes

- If the following should occur during Diagnostic Trouble Code (DTC) display the display will be discontinued. After initial check, the status that is under the control of ABS will be returned :
 - The vehicle starts (The wheels turn) or the brake pedal is depressed.
- Up to 3 different codes can be stored.
- If the ABS should turn OFF due to an intermittent defect, the system will be restored at the next key cycle, if the initial check finds no abnormality (when IGN is switched from OFF to ON).

5. An example of DTC display


Display of DTC 23




B05RW006

After displaying DTC 12 three times, one DTC after another is displayed, starting with the most recent one. (However, display is discontinued after about 5 minutes.)

5A-40 BRAKE CONTROL SYSTEM



<In case where no DTC has been stored>



B05RS005

The DTC 12 is displayed repeatedly. (display is discontinued after about 5 minutes after)

Chart B-1 With the key in the ON position (Before starting the engine). Warning light (W/L) is not activated.

Step	Action	Yes	No
1	Is W/L fuse disconnected?	Replace fuse. Go to Step 5	Go to Step 2
2	Is W/L burnt out?	Replace W/L bulb. Go to Step 5	Go to Step 3
3	1. Turn the key off. 2. Disconnect coil integrated module connector (C-4). 3. Turn the key ON. Is the check voltage between coil integrated module connector (C-4) terminals 6 and 7 than battery voltage?	Go to Step 4	Repair harness and connector. Go to Step 5
4	Is the check continuity coil integrated module connector (C-4) terminals, 1 and 7 and body ground.	Check harness for suspected disconnection No fault found: Replace EHC. Go to Step 5	Repair harness and connector. Go to Step 5
5	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 5

Chart B-2 CPU Error (DTC 14 (Flash out) / C0271, C0272, C0273, C0284 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Inspect coil integrated module ground. Is the check resistance between the coil integrated module connector terminals, 2 (C-5) and 7 (C-4) and body ground?	Go to Step 2	Repair the body ground harness. Go to Step 3
2	1. Turn the key off, connect the coil integrated module connector. 2. Erase the trouble code. 3. Turn Ignition off, then on, to perform system self-check. 4. If warning light remains on, display trouble codes once again. Is the check trouble code 14 (Flash out) / C0271, C0272, C0273, C0284 (Serial communications)?	Replace EHCU. Go to Step 3	Inspect in accordance with the DTC displayed.
3	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-3 Low or High Ignition Voltage (DTC 15 (Flash out) / C0277, 0278 (Serial communications))

Step	Action	Yes	No
1	Is the check battery voltage normal? (Battery capacity check)	Go to Step 2	Charge or replace battery. Go to Step 2
2	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Turn the key on. Is the check voltage between coil integrated module connector (C-4) terminals 1 and 7, higher than 10V?	Check harness connector for suspected disconnection Fault found: Repair, and perform system self-check No fault found: replace EHCU. Go to Step 3	Repair harness or connector. Go to Step 3
3	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-4 Excessive Dump Time (DTC 17 (Flash out) / C0269 (Serial communications))

Step	Action	Yes	No
1	Check for anything causing extended ABS activation, such as locked brakes or an erratic speed sensor signal. Was a problem found?	Repair or Replace	Go to Step 2
2	1. The key turned off. 2. Replace EHCU. 3. Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 2

5A-42 BRAKE CONTROL SYSTEM

Chart B-5 Excessive Isolation Time (DTC 18 (Flash out) / C0274 (Serial communications))

Step	Action	Yes	No
1	Check for anything causing extended ABS activation, such as locked brakes or an erratic speed sensor signal. Was a problem found?	Repair or Replace	Go to Step 2
2	1. The key turned off. 2. Replace EHCUC. 3. Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 2

Chart B-6 G-Sensor Output Failure (DTC 21 (Flash out) / C0276 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Replace EHCUC. 3. Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 1

Chart B-7 Brake Switch Failure (DTC 22 (Flash out) / C0281 (Serial communications))

Step	Action	Yes	No
1	Is the stop light actuated when the brake pedal is depressed?	Go to Step 2	Go to Step 4
2	1. Turn the key off. 2. Disconnected coil integrated module connector. Is the check voltage coil integrated module connector (C-4) terminals 13 to 7 when brake pedal is depressed than battery voltage?	Go to Step 3	Harness between brake SW and coil integrated module is faulty. Go to Step 6
3	Is the check that pins C-5 connector 2, and C-4 connector 7 have good ground?	Check harness / connector for disconnection Fault found: Repair, and perform system self-check. No fault found: replace EHCUC. Go to Step 6	Repair. Go to Step 6
4	Is stop light fuse normal?	Go to Step 5	Replace. Go to Step 6
5	Is brake SW normal?	Abnormal harness in stop light circuit. Repair the harness. Go to Step 6	Replace. Go to Step 6
6	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

Chart B-8 2WD Controller in 4WD Vehicle Controller (DTC 13 (Flash out) / C0285 (Serial communications)), 4WD State Input Signal Failure (DTC 24 (Flash out) / C0282 (Serial communications))

Step	Action	Yes	No
1	Remove coil integrated module connector. Is the coil integrated module connector (C-4) terminal 8 line normally?	Go to Step 2	Repair. Go to Step 3
2	Is the 4WD controller normally?	Replace EHCU. Go to Step 3	Replace 4WD controller. Go to Step 3
3	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-9 Pump Motor Failure (DTC 32 (Flash out) / C0267, C0268 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the voltage between terminal 1 of the coil integrated module connector (C-5) and body ground. Is the voltage equal to the battery voltage?	Go to Step 2	Repair fuse/harness between battery and coil integrated module connector (C-5) terminal 1. Go to Step 5
2	Is the harness from the hydraulic unit connected to the coil integrated module connector?	Go to Step 3	Connect to the connector. Go to Step 3
3	Is the harness from the hydraulic unit normally?	Go to Step 4	Replace EHCU. Go to Step 5
4	Is the check resistance of hydraulic unit connector terminals 1 and 2 between 0.2 and 1.0 ohms?	Replace EHCU. Go to Step 5	Replace EHCU. Go to Step 5
5	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 5

5A-44 BRAKE CONTROL SYSTEM**Chart B-10 EHCUC Valve Relay Failure (DTC 35 (Flash out) / C0265, C0266 (Serial communications))**

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the voltage between terminal 1 of the coil integrated module connector (C-5) and body ground. Is the voltage equal to the battery voltage?	Replace EHCUC. Go to Step 2	Repair fuse and harness coil integrated module connector (C-5) terminal 1 and battery. Go to Step 2
2	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 2

Chart B-11 FL Isolation Solenoid Coil Failure (DTC 41 (Flash out) / C0245, C0247 (Serial communications))

Step	Action	Yes	No
1	Was the "EHCUC Connector Pin-out Checks" performed?	Go to Step 2	Go to "EHCUC Connector Pin-out Checks."
2	1. Turn the key switch to off. 2. Disconnect the 2-way EHCUC connector (C-5) from the EHCUC. 3. Inspect the connector for damage or corrosion. Is the connector free from damage or corrosion?	Go to Step 3	Repair the connector. Repeat the "Basic Diagnostic Flow Chart."
3	1. Replace the Coil Integrated Module. 2. Reconnect all component, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-12 FL Dump Solenoid Coil Failure (DTC 42 (Flash out) / C0246, C0248 (Serial communications))

Step	Action	Yes	No
1	Was the "EHCUC Connector Pin-out Checks" performed?	Go to Step 2	Go to "EHCUC Connector Pin-out Checks."
2	1. Turn the key switch to off. 2. Disconnect the 2-way EHCUC connector (C-5) from the EHCUC. 3. Inspect the connector for damage or corrosion. Is the connector free from damage or corrosion?	Go to Step 3	Repair the connector. Repeat the "Basic Diagnostic Flow Chart."
3	1. Replace the Coil Integrated Module. 2. Reconnect all component, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-13 FR Isolation Solenoid Coil Failure (DTC 43 (Flash out) / C0241, C0243 (Serial communications))

Step	Action	Yes	No
1	Was the "EHCU Connector Pin-out Checks" performed?	Go to Step 2	Go to "EHCU Connector Pin-out Checks."
2	1. Turn the key switch to off. 2. Disconnect the 2-way EHCU connector (C-5) from the EHCU. 3. Inspect the connector for damage or corrosion. Is the connector free from damage or corrosion?	Go to Step 3	Repair the connector. Repeat the "Basic Diagnostic Flow Chart."
3	1. Replace the Coil Integrated Module. 2. Reconnect all component, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-14 FR Dump Solenoid Coil Failure (DTC 44(Flash out) / C0242, C0244 (Serial communications))

Step	Action	Yes	No
1	Was the "EHCU Connector Pin-out Checks" performed?	Go to Step 2	Go to "EHCU Connector Pin-out Checks."
2	1. Turn the key switch to off. 2. Disconnect the 2-way EHCU connector (C-5) from the EHCU. 3. Inspect the connector for damage or corrosion. Is the connector free from damage or corrosion?	Go to Step 3	Repair the connector. Repeat the "Basic Diagnostic Flow Chart."
3	1. Replace the Coil Integrated Module. 2. Reconnect all component, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-15 Rear Isolation Solenoid Coil Failure (DTC 45 (Flash out) / C0251, C0253 (Serial communications))

Step	Action	Yes	No
1	Was the "EHCU Connector Pin-out Checks" performed?	Go to Step 2	Go to "EHCU Connector Pin-out Checks."
2	1. Turn the key switch to off. 2. Disconnect the 2-way EHCU connector (C-5) from the EHCU. 3. Inspect the connector for damage or corrosion. Is the connector free from damage or corrosion?	Go to Step 3	Repair the connector. Repeat the "Basic Diagnostic Flow Chart."
3	1. Replace the Coil Integrated Module. 2. Reconnect all component, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

5A-46 BRAKE CONTROL SYSTEM**Chart B-16 Rear Dump Solenoid Coil Failure (DTC 46 (Flash out) / C0252, C0254 (Serial communications))**

Step	Action	Yes	No
1	Was the "EHCU Connector Pin-out Checks" performed?	Go to Step 2	Go to "EHCU Connector Pin-out Checks."
2	1. Turn the key switch to off. 2. Disconnect the 2-way EHCU connector (C-5) from the EHCU. 3. Inspect the connector for damage or corrosion. Is the connector free from damage or corrosion?	Go to Step 3	Repair the connector. Repeat the "Basic Diagnostic Flow Chart."
3	1. Replace the Coil Integrated Module. 2. Reconnect all component, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-17 FL Speed Sensor Open or Shorted (DTC 51 (Flash out) / C0225 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the resistance between coil integrated module connector (C-4) terminals 2 and 10. Is the resistance between 2.0k and 2.8k ohms?	Check for faults in harness between speed sensor and coil integrated module. Fault found: Repair, and perform system self-check. No fault found: Replace coil integrated module. Go to Step 3	Go to Step 2
2	Measure the FL speed sensor resistance at the sensor connector. Is the resistance between 2.0k and 2.8k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 3	Replace sensor. Go to Step 3
3	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-18 FR Speed Sensor Open or Shorted (DTC 52 (Flash out) / C0221 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the resistance between coil integrated module connector (C-4) terminals 3 and 11. Is the resistance between 2.0k and 2.8k ohms?	Check for faults in harness between speed sensor and coil integrated module. Fault found: Repair, and perform system self-check. No fault found: Replace coil integrated module. Go to Step 3	Go to Step 2
2	Measure the FR speed sensor resistance at the sensor connector. Is the resistance between 2.0k and 2.8k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 3	Replace sensor. Go to Step 3
3	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

5A-48 BRAKE CONTROL SYSTEM

Chart B-19 Rear Speed Sensor Open or Shorted (DTC 53 (Flash out) / C0235 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the resistance between coil integrated module connector (C-4) terminals 4 and 12. Is the resistance between 1.2k and 2.0k ohms?	Check for faults in harness between speed sensor and coil integrated module. Fault found: Repair, and perform system self-check. No fault found: Replace EHC. Go to Step 3	Go to Step 2
2	Measure the Rear speed sensor resistance at the sensor connector. Is the resistance between 1.2k and 2.0k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 3	Replace sensor. Go to Step 3
3	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart B-20 FL Speed Sensor Missing (DTC 61 (Flash out) / C0226, C0227 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the FL speed sensor resistance between coil integrated module connector (C-4) terminals 2 and 10. Is the resistance between 2.0k and 2.8k ohms?	Go to Step 2	Go to Step 3
2	Is there play sensor/sensor rotor?	Repair. Go to Step 6	Go to Step 4
3	Measure the FL speed sensor resistance at the sensor connector. Is the resistance between 2.0k and 2.8k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 6	Replace sensor. Go to Step 6
4	Damage and powered iron sticking to sensor/sensor ring?	Repair. Go to Step 6	Go to Step 5
5	Is sensor output normal? (Chart C-1-1 or TC-1)	Check for faults in harness between speed sensor and coil integrated module. Fault found: repair, and perform system self-check. No fault found: replace EHC. Go to Step 6	Replace sensor. Go to Step 6
6	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

NOTE: Even after repairing the faulty part the warning light (W/L) does not go out if the vehicle is at a stop. Turn the ignition switch to the ON position and drive the vehicle at 12 km/h (8 mph) or higher to make sure that the warning light goes out.

5A-50 BRAKE CONTROL SYSTEM

Chart B-21 FR Speed Sensor Missing (DTC 62 (Flash out) / C0222, C0223 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the FR speed sensor resistance between coil integrated module connector (C-4) terminals 3 and 11. Is the resistance between 2.0k and 2.8k ohms?	Go to Step 2	Go to Step 3
2	Is there play sensor/sensor rotor?	Repair. Go to Step 6	Go to Step 4
3	Measure the FR speed sensor resistance at the sensor connector. Is the resistance between 2.0k and 2.8k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 6	Replace sensor. Go to Step 6
4	Damage and powered iron sticking to sensor/sensor ring?	Repair. Go to Step 6	Go to Step 5
5	Is sensor output normal? (Chart C-1-2 or TC-1)	Check for faults in harness between speed sensor and coil integrated module. Fault found: repair, and perform system self-check. No fault found: replace EHC. Go to Step 6	Replace sensor. Go to Step 6
6	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

NOTE: Even after repairing the faulty part the warning light (W/L) does not go out if the vehicle is at a stop. Turn the ignition switch to the ON position and drive the vehicle at 12 km/h (8 mph) or higher to make sure that the warning light goes out.

Chart B-22 Rear Speed Sensor Missing (DTC 63 (Flash out) / C0236, C0237 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the Rear speed sensor resistance between coil integrated module connector (C-4) terminals 4 and 12. Is the resistance between 1.2k and 2.0k ohms?	Go to Step 2	Go to Step 3
2	Is there play sensor/sensor rotor?	Repair. Go to Step 6	Go to Step 4
3	Measure the rear speed sensor resistance at the sensor connector. Is the resistance between 1.2k and 2.0k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 6	Replace sensor. Go to Step 6
4	Damage and powered iron sticking to sensor/sensor ring?	Repair. Go to Step 6	Go to Step 5
5	Is sensor output normal? (Chart C-1-3 or TC-1)	Check for faults in harness between speed sensor and coil integrated module. Fault found: repair, and perform system self-check. No fault found: replace EHC. Go to Step 6	Replace sensor. Go to Step 6
6	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

NOTE: Even after repairing the faulty part the warning light (W/L) does not go out if the vehicle is at a stop. Turn the ignition switch to the ON position and drive the vehicle at 12 km/h (8 mph) or higher to make sure that the warning light goes out.

5A-52 BRAKE CONTROL SYSTEM

Chart B-23 Simultaneous Drop-out of Front Speed Sensor Signal (DTC 64 (Flash out) / C0229 (Serial communications))

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Measure the FL speed sensor resistance between coil integrated module connector (C-4) terminals 2 and 10. Is the resistance between 2.0k and 2.8k ohms?	Go to Step 2	Go to Step 3
2	Measure the FR speed sensor resistance between coil integrated module connector (C-4) terminals 3 and 11. Is the resistance between 2.0k and 2.8 k ohms?	Go to Step 5	Go to Step 4
3	Measure the FL speed sensor resistance at the sensor connector. Is the resistance between 2.0k and 2.8k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 2	Replace sensor. Go to Step 2
4	Measure the FR speed sensor resistance at the sensor connector. Is the resistance between 2.0k and 2.8k ohms?	Repair harness abnormality between sensors and coil integrated module. Go to Step 5	Replace sensor. Go to Step 5
5	Damage and powered iron sticking to sensor/sensor ring?	Repair. Go to Step 6	Go to Step 6
6	Is there play sensor/sensor rotor?	Repair. Go to Step 7	Go to Step 7
7	Is sensor output normal? (Chart C-1-1&C-1-2 or TC-1)	Check for faults in harness between speed sensor and coil integrated module. Fault found: repair, and perform system self-check. No fault found: replace EHC. Go to Step 8	Replace sensor. Go to Step 8
8	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat "Basic diagnostic flow chart"	Go to Step 8

NOTE: Even after repairing the faulty part the warning light (W/L) does not go out if the vehicle is at a stop. Turn the ignition switch to the ON position and drive the vehicle

at 12 km/h (8 mph) or higher to make sure that the warning light goes out.

Chart B-24 Wheel Speed Input Abnormality (DTC 65 (Flash out) / C0238 (Serial communications))

Step	Action	Yes	No
1	Using TECH 2?	Go to Step 2	Go to Step 3
2	1. Connect TECH 2. 2. Select Snap shot manual trigger. 3. With wheel speed data displayed, run the vehicle when speed has arrived at 30 km/h (18 mph). 4. Check speed data on each wheel (refer to the criterion given below). * 1 Is the abnormal sensor condition found?	Replace. Go to Step 8	Go to Step 3 All the sensors should follow the following flowchart (without using TECH 2).
3	Is there play in sensor/sensor ring?	Repair. Go to Step 8	Go to Step 4
4	Is there powdered iron sticking to sensor/sensor ring?	Repair. Go to Step 8	Go to Step 5
5	Is there a broken tooth or indentation in sensor ring?	Replace sensor ring. Go to Step 8	Go to Step 6
6	Is there play in wheel bearing?	Adjust or repair. Go to Step 8	Go to Step 7
7	Is the check wiring between sensor and coil integrated module normal?	Replace EHC.U. Go to Step 8	Repair, and perform system self-check. Go to Step 8
8	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble code. Was this step finished?	Repeat 'Basic diagnostic flow chart'	Go to Step 8

Sensor Signal Abnormality Criteria using TECH 2

1. While driving, the speed of one or two wheels is 25% or more higher or lower than that of the other wheels.
2. The speed of one or two wheels is 10 km/h (6 mph) or more higher or lower than that of the other wheels.
3. During steady driving, wheel speed changes abruptly.

*1 The vehicle must run on a level paved road.

NOTE: Even after repairing the faulty part the warning light (W/L) does not go out if the vehicle is at a stop.

Turn the ignition switch to the ON position and drive the vehicle at 12 km/h (8 mph) or higher to make sure that the warning light goes out.

It is important to verify that the correct tires are installed on vehicle.

5A-54 BRAKE CONTROL SYSTEM

Unit Inspection Procedure

This section describes the following inspection procedures referred to during "SYMPTOM DIAGNOSIS" and "DIAGNOSIS BY 'ABS' WARNING LIGHT ILLUMINATION PATTERN" :

	without TECH 2	with TECH 2
Sensor Output Inspection	Chart C-1-1 to C-1-3	Chart TC-1

Chart C-1-1 FL Sensor Output Inspection Procedure

Step	Action	Yes	No
1	<p>1. Turn the key off.</p> <p>2. Disconnect coil integrated module connector.</p> <p>3. Jack up the vehicle with all four wheels off the ground. Measure the AC voltage between coil integrated module connector terminals while turning FL wheel at a speed of 1 RPS:</p> <p>Is the check between coil integrated module connector (C-4) terminals 2 and 10 than under 200 mV?</p>	Go to Step 2	OK. Go to Step 3
2	<p>1. Disconnect the wheel speed sensor.</p> <p>2. Measure resistance between the wheel speed sensor connector terminals 1 and 2.</p> <p>Is the check between connector (C-13) terminals 1 and 2 within 2.0k - 2.8k ohms?</p>	<p>Connector is faulty, or open or short circuit of harness between wheel speed sensor connector and coil integrated module.</p> <p>Inspect and correct the connector or harness.</p> <p>Go to Step 3</p>	<p>Wheel speed sensor is faulty.</p> <p>Replace the wheel speed sensor.</p> <p>Go to Step 3</p>
3	<p>Reconnect all components, ensure all components are properly mounted.</p> <p>Was this step finished?</p>	Repeat the "Basic diagnostic flow chart"	Go to Step 3

Chart C-1-2 FR Sensor Output Inspection Procedure

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Jack up the vehicle with all four wheels off the ground. Measure the AC voltage between coil integrated module connector terminals while turning FR wheel at a speed of 1 RPS: Is the check between coil integrated module connector (C-4) terminals 3 and 11 than under 200 mV?	Go to Step 2	OK. Go to Step 3
2	1. Disconnect the wheel speed sensor. 2. Measure resistance between the wheel speed sensor connector terminals 1 and 2. Is the check between connector (C-33) terminals 1 and 2 within 2.0k - 2.8k ohms?	Connector is faulty, or open or short circuit of harness between wheel speed sensor connector and coil integrated module. Inspect and correct the connector or harness. Go to Step 3	Wheel speed sensor is faulty. Replace the wheel speed sensor. Go to Step 3
3	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3




Chart C-1-3 Rear Sensor Output Inspection Procedure

Step	Action	Yes	No
1	1. Turn the key off. 2. Disconnect coil integrated module connector. 3. Jack up the vehicle with all four wheels off the ground measure the AC voltage between coil integrated module connector terminals while turning Rear wheel at a speed of 1 RPS: Is the check between coil integrated module connector (C-4) terminals 4 and 12 than under 200 mV?	Go to Step 2	OK. Go to Step 3
2	1. Disconnect the wheel speed sensor. 2. Measure resistance between the wheel speed sensor connector terminals 1 and 2. Is the check between connector (F-4) terminals 1 and 2 within 1.2k - 2.0k ohms?	Connector is faulty, or open or short circuit of harness between wheel speed sensor connector and coil integrated module. Inspect and correct the connector or harness. Go to Step 3	Wheel speed sensor is faulty. Replace the wheel speed sensor. Go to Step 3
3	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 3

5A-56 BRAKE CONTROL SYSTEM**Chart TC-1 Sensor Output Inspection Procedure**

Step	Action	Yes	No
1	1. Connect TECH 2. 2. Check the wheel speed of each sensor by Data List. Is the vehicle speed normal?	Go to Step 6	Go to Step 2
2	Check the sensor harness for suspected disconnection (check while shaking harness/connector). Is the sensor harness connection normal?	Replace speed sensor. Go to Step 4	Repair. Go to Step 3
3	Check the wheel speed of each sensor by Data List. Is the vehicle speed normal?	Go to Step 6	Go to Step 4
4	Check the sensor rotor. Is the sensor rotor normal?	Replace speed sensor. Go to Step 5	Replace sensor rotor. Go to Step 5
5	Check the harness between coil integrated module and speed sensor. Is the harness connection normal?	Go to Step 6	Repair harness or connector between coil integrated module and speed sensor. Go to Step 6
6	Reconnect all components, ensure all components are properly mounted. Was this step finished?	Repeat the "Basic diagnostic flow chart"	Go to Step 6

Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
 901RW074	J-35616 Connector test adapter kit
 901RS153	J-39200 High impedance multimeter
	7000086-ISU Tech 2 Set (1) PCMCIA Card (2) SAE 16/19 Adapter (3) DLC Cable (4) Tech 2

RODEO

BRAKES

ANTI-LOCK BRAKE SYSTEM

CONTENTS

Service Precaution	5B-1	Rear Wheel Speed Sensor	5B-5
Electronic Hydraulic Control Unit	5B-2	Removal	5B-5
Electronic Hydraulic Control Unit and Associated Parts	5B-2	Inspection and Repair	5B-5
Removal	5B-2	Installation	5B-5
Disassembled View	5B-3		
Disassembly	5B-3		
Reassembly	5B-3		
Installation	5B-3		
Front Wheel Speed Sensor	5B-4		
Front Wheel Speed Sensor and Associated Parts	5B-4		
Removal	5B-4		
Inspection and Repair	5B-4		
Installation	5B-4		


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Electronic Hydraulic Control Unit

Electronic Hydraulic Control Unit and Associated Parts




Legend

- (1) EHC
- (2) Bolt

- (3) Bracket
- (4) Bolt and Nut


Removal

1. Remove brake pipes.
 - After disconnecting brake pipe, cap or tape the openings of the brake pipe to prevent the entry of foreign matter.
2. Remove three bracket fixing bolts.
3. Disconnect red clip from harness connector.



4. Remove harness connector.
5. Remove EHCU ASM.
6. Remove EHCU.

Disassembled View



Legend

- (1) Fixing Bolts
- (2) Coil Integrated Module
- (3) Hydraulic Unit (H/U)

Disassembly

1. Remove fixing bolts from EHCU.
2. Remove coil integrated module from hydraulic unit.

Reassembly

To reassembly, follow the disassembly steps in the reverse order, noting the following points:

Torque:

Fixing bolts: 4.4 N·m (39 lb in)

Installation

To install, follow the removal steps in the reverse order, noting the following points:

Torque:

Hydraulic unit fixing nuts : 22 N·m (16 lb ft)

Ground cable : 14 N·m (10 lb ft)


Brake pipe (joint bolts) : 16 N·m (12 lb ft)

- After installing the hydraulic unit, bleed brakes completely. See Section 5A "Hydraulic Brakes".

350RW025

Front Wheel Speed Sensor

Front Wheel Speed Sensor and Associated Parts



350RS033

Legend

- | | |
|---|--|
| (1) Speed Sensor Connector | (3) Sensor Cable Fixing Bolt (Lower side) |
| (2) Sensor Cable Fixing Bolt (Upper side) | (4) Sensor Cable Fixing Bolt (Sensor side) |
| | (5) Speed Sensor |

Removal

1. Remove speed sensor connector.
2. Remove sensor cable fixing bolt (Upper side).
3. Remove sensor cable fixing bolt (Lower side).
4. Remove the speed sensor cable fixing bolt.
5. Remove speed sensor.

Inspection and Repair

1. Check the speed sensor pole piece for presence of foreign materials; remove any dirt, etc.
2. Check the pole piece for damage; replace speed sensor if necessary.
3. Check the speed sensor cable for short or open circuit, and replace with a new one if necessary.
To check for cable short or open, bend or stretch the cable while checking for continuity.
4. Check the sensor ring for damage including tooth chipping, and if damaged, replace the sensor ring assembly. Refer to removal of the sensor ring in Section 4D "Front hub and disc".

Installation

1. Install speed sensor and take care not to hit the speed sensor pole piece during installation.
2. Install speed sensor fixing bolt and tighten the fixing bolt to the specified torque.

Torque: 11 N·m (95 lb in)

3. Install speed sensor cable fixing bolt (Lower side) and tighten the fixing bolt to the specified torque.

Torque : 24 N·m (18 lb ft)

4. Install speed sensor cable fixing bolt (Upper side) and tighten the fixing bolt to the specified torque.

Torque : 6 N·m (52 lb ft)


NOTE: Confirm that a white line marked on the cable is not twisted when connecting the speed sensor cable.

5. Install speed sensor connector.

Rear Wheel Speed Sensor

Removal

1. Disconnect harness connector (1).
2. Remove sensor fixing bolt (2) .
3. Remove speed sensor (3).




Installation

1. Install speed sensor (3).
2. Tighten the sensor fixing bolt (2) to the specified torque.

Torque : 11 N·m (95 lb in)

3. Connect harness connector (1).



Inspection and Repair

1. Check speed sensor pole piece for presence of foreign materials; remove any dirt, etc.
2. Check the pole piece for damage, and replace speed sensor if necessary.
3. Check speed sensor cable for short or open, and replace with a new one if necessary. To check for cable short or open, bend or stretch the cable while checking for continuity.
4. Check the sensor ring for damage including tooth chipping, and if damaged, replace the axle shaft assembly. Refer to removal of the sensor ring in Section 4A2 "Differential (Rear)".

RODEO

BRAKES

POWER-ASSISTED BRAKE SYSTEM

CONTENTS

Service Precaution	5C-2	Master Cylinder Assembly	5C-22
General Description	5C-2	Master Cylinder Assembly and Associated Parts	5C-22
Diagnosis	5C-6	Removal	5C-22
General Diagnosis	5C-7	Inspection and Repair	5C-22
Hydraulic Brakes	5C-10	Installation	5C-23
Filling Master Cylinder Reservoir	5C-10	Main Data and Specifications	5C-24
Deterioration of Brake Fluid	5C-10	Special Tools	5C-24
Leakage of Brake Fluid	5C-10	Vacuum Booster Assembly	5C-25
Bleeding Brake Hydraulic System	5C-10	Vacuum Booster Assembly and Associated Parts	5C-25
Flushing Brake Hydraulic System	5C-11	Removal	5C-25
Brake Pipes and Hoses	5C-11	Inspection and Repair	5C-25
Brake Hose Inspection	5C-11	Installation	5C-26
Front Caliper Brake Hose	5C-12	Exterior Components	5C-28
Front Caliper Brake Hose and Associated Parts	5C-12	Exterior Components and Associated Parts	5C-28
Removal	5C-12	Removal	5C-28
Installation	5C-12	Inspection and Repair	5C-29
Rear Axle Brake Hose	5C-13	Installation	5C-29
Rear Axle Brake Hose and Associated Parts	5C-13	Vacuum Booster Overhaul	5C-29
Removal	5C-13	Vacuum Booster	5C-29
Installation	5C-13	Main Data and Specifications	5C-30
Brake Pipe	5C-14	Special Tools	5C-31
Removal	5C-14	Front Disc Brake Pads	5C-32
Installation	5C-14	Front Disc Brake Pads Inspection	5C-32
P & B (Proportioning and Bypass) Valve	5C-15	Front Disc Brake Pads and Associated Parts	5C-32
Removal	5C-15	Removal	5C-33
Installation	5C-15	Installation	5C-33
Main Data and Specifications	5C-16	Front Disc Brake Rotor	5C-35
Brake Pedal	5C-17	Inspection	5C-35
Checking Pedal Height	5C-17	Replacing Brake Rotors	5C-35
Checking Pedal Travel	5C-17	Refinishing Brake Rotors	5C-35
Brake Pedal and Associated Parts	5C-18	Front Disc Brake Caliper Assembly	5C-36
Removal	5C-18	Front Disc Brake Caliper Assembly and Associated Parts	5C-36
Installation	5C-18	Removal	5C-37
Stoplight Switch	5C-19	Installation	5C-37
Parts Location	5C-19	Front Disc Brake Caliper	5C-39
Removal	5C-19	Front Disc Brake Caliper Disassembled View	5C-39
Installation	5C-19	Disassembly	5C-39
Main Data and Specifications	5C-20	Inspection and Repair	5C-40
Fluid Reservoir Tank	5C-21	Reassembly	5C-40
Fluid Reservoir Tank and Associated Parts	5C-21	Main Data and Specifications	5C-42
Removal	5C-21		
Installation	5C-21		

5C-2 POWER-ASSISTED BRAKE SYSTEM

Rear Disc Brake Pads (4×4 Model)	5C-43	Inspection and Repair	5C-51
Brake Pads Inspection	5C-43	Reassembly	5C-51
Brake Pads and Associated Parts	5C-43	Main Data and Specifications (4×4 Model)	5C-53
Removal	5C-44	Brake Lining	5C-54
Installation	5C-44	Brake Lining and Associated Parts	5C-54
Rear Disc Brake Rotor (4×4 Model)	5C-46	Removal	5C-54
Inspection	5C-46	Brake Lining Inspection	5C-55
Replacing Brake Rotors	5C-46	Installation	5C-55
Refinishing Brake Rotors	5C-46	Drum Brake Adjustment (4×2 Model)	5C-56
Rear Drum (In Disc) Inside Diameter Check	5C-47	Servicing The Brake Drum	5C-56
Rear Disc Brake Caliper Assembly (4×4 Model)	5C-48	Wheel Cylinder Assembly (4×2 Model)	5C-57
Rear Disc Brake Caliper Assembly and Associated Parts	5C-48	Wheel Cylinder Assembly and Associated Parts	5C-57
Removal	5C-48	Removal	5C-57
Installation	5C-49	Installation	5C-57
Rear Disc Brake Caliper (4×4 Model)	5C-50	Disassembled View	5C-58
Rear Disc Brake Caliper Disassembled View	5C-50	Disassembly	5C-58
Disassembly	5C-51	Inspection and Repair	5C-58
		Reassembly	5C-58
		Main Data and Specifications	5C-60


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

Master Cylinder Assembly




330RS001

The master cylinder contains two pistons that supply the hydraulic pressure for a dual-circuit braking system. The primary piston provides the fluid pressure to the front brakes, while the secondary piston provides the fluid pressure to the rear brakes. If the pressure is lost from either system, the remaining system will function to stop the vehicle.

CAUTION:

1. The master cylinder is not repairable. If found defective, it must be replaced as a complete assembly.
2. If any hydraulic component is removed or disconnected, it may be necessary to bleed all or part of the brake system. (Refer to "Bleeding Brake Hydraulic System" in this section.)
3. The torque values specified are for dry, unlubricated fasteners.
4. Perform service operations on a clean bench free from all mineral oil materials.

Brake Booster



331RS001

This booster is a tandem vacuum unit with a diaphragm effective diameter 205mm + 230mm. In normal operating mode, with the service brakes in the released position, the tandem vacuum booster operates with vacuum on both sides of its diaphragms. When the brakes are applied, air at atmospheric pressure is admitted to one side of each diaphragm to provide the power assist. When the service brake is released, the atmospheric air is shut off from the one side of each diaphragm. The air is then drawn from the booster through the vacuum check valve to the vacuum source.


CAUTION:

1. If any hydraulic component is removed or disconnected, it may be necessary to bleed all or part of the brake system.
2. The torque values specified are for dry, unlubricated fasteners.
3. The vacuum booster is not repairable and must be replaced as complete assembly.

5C-4 POWER-ASSISTED BRAKE SYSTEM


Disc Brake

Front Disc Brake



A05RW001

Rear Disc Brake (4×4 Model)



A05RW002


The disc brake assembly consists of a caliper, piston, rotor, pad assembly and support bracket. The caliper assembly has a single bore and is mounted to the support bracket with two mounting bolts. The support bracket allows the caliper to move laterally against the rotor. The caliper is a one-piece casting with the inboard side containing the piston bore. A square cut rubber seal is located in a groove in the piston bore which provides the hydraulic seal between the piston and the cylinder wall.

NOTE:

1. Replace all components included in repair kits used to service this caliper.
2. Lubricate rubber parts with clean brake fluid to ease assembly.
3. If any hydraulic component is removed or disconnected, it may be necessary to bleed all or part of the brake system.
4. Replace pads in axle sets only.
5. The torque values specified are for dry, unlubricated fasteners.
6. Perform the service operation on a clean bench free from all mineral oil materials.

Operation

Hydraulic pressure, created by applying the brake pedal, is converted by the caliper to a stopping force. This force acts equally against the piston and the bottom of the caliper bore to move the piston outward and to move (slide) the caliper inward resulting in a clamping action on the rotor. This clamping action forces the linings against the rotor, creating friction to stop the vehicle.

Leading/Trailing Drum Brakes (4×2 Model)

A06RS003

This drum brake assembly is a leading/trailing shoe design. Both brake shoes are held against the wheel cylinder pistons by the upper return spring and to the fixed anchor plate by the lower return spring. When the brakes are applied, the wheel cylinder pistons move both shoes out contact the drum.

With forward wheel rotation, the forward brake shoe will wrap into the drum and become self-energized.

With reverse wheel rotation, the rear brake shoe is self-energized. Force from the brake shoes is transferred to the anchor plate through the braking plate to the axle flange. Adjustment is automatic and occurs on any service brake application. Also, with leading/trailing brakes, it is normal for the front shoe to wear at a faster rate than the rear shoe.

Diagnosis

Road Testing The Brakes

Brake Test

Brakes should be tested on a dry, clean, reasonably smooth and level roadway. A true test of brake performance cannot be made if the roadway is wet, greasy or covered with loose dirt so that all tires do not grip the road equally. Testing will also be adversely affected if the roadway is crowned so as to throw the weight of the vehicle toward wheels on one side or if the roadway is so rough that wheels tend to bounce. Test the brakes at different vehicle speeds with both light and heavy pedal pressure; however, avoid locking the wheels and sliding the tires. Locked wheels and sliding tires do not indicate brake efficiency, since heavily braked but turning wheels will stop the vehicle in less distance than locked wheels. More tire-to-road friction is present with a heavily braked turning tire than with a sliding tire.

The standard brake system is designed and balanced to avoid locking the wheels except at very high deceleration levels.

It is designed this way because the shortest stopping distance and best control is achieved without brake lock-up.

Because of high deceleration capability, a firmer pedal may be felt at higher deceleration levels.

External Conditions That Affect Brake Performance

1. **Tires:** Tires having unequal contact and grip on the road will cause unequal braking. Tires must be equally inflated, identical in size, and the thread pattern of right and left tires must be approximately equal.
2. **Vehicle Loading:** A heavily loaded vehicle requires more braking effort.
3. **Wheel Alignment:** Misalignment of the wheels, particularly in regard to excessive camber and caster, will cause the brakes to pull to one side.

Brake Fluid Leaks

With engine running at idle and the transmission in "Neutral", depress the brake pedal and hold a constant foot pressure on the pedal. If pedal gradually falls away with the constant pressure, the hydraulic system may be leaking.

Check the master cylinder fluid level. While a slight drop in the reservoir level will result from normal lining wear, an abnormally low level in reservoir indicates a leak in the system. The hydraulic system may be leaking internally as well as externally. Refer to "Master Cylinder Inspection". Also, the system may appear to pass this test but still have slight leakage. If fluid level is normal, check the vacuum booster push rod length. If an incorrect length push rod is found, adjust or replace the push rod. Check the brake pedal travel and the parking brake adjustment. When checking the fluid level, the master cylinder fluid level may be low from the "MAX" mark if the front and rear linings are worn. This is not abnormal.

Warning Light Operation

When the ignition switch is in the START position, the "BRAKE" warning light should turn on and go off when the ignition switch returns to the ON position.

The following conditions will activate the "BRAKE" light:

1. **Parking brake applied.** The light should be on whenever the parking brake is applied and the ignition switch is on.
2. **Low fluid level.** A low fluid level in the master cylinder will turn the "BRAKE" light on.
3. **During engine cranking** the "BRAKE" light should remain on. This notifies the driver that the warning circuit is operating properly.

General Diagnosis

Condition	Possible cause	Correction
Brake Pull	Tire inflation pressure is unequal.	Adjust
	Front wheel alignment is incorrect.	Adjust
	Unmatched tires on same axle.	Tires with approx. the same amount of tread should be used on the same axle.
	Restricted brake pipes or hoses.	Check for soft hoses and damaged lines. Replace with new hoses and new double-walled steel brake piping.
	Water or oil on the brake pads.	Clean or replace.
	Brake pads hardened.	Replace
	Brake pads worn excessively.	Replace
	Brake rotor worn or scored.	Grind or replace.
	Disc brake caliper malfunctioning.	Clean or replace.
	Front hub bearing preload incorrect.	Adjust or replace.
	Loose suspension parts.	Check all suspension mountings.
	Loose calipers.	Check and tighten the bolts to specifications.
Brake Roughness or Chatter (Pulsates)	Excessive lateral runout.	Check per instructions. If not within specifications, replace or machine the rotor.
	Parallelism not within specifications.	Check per instructions. If not within specifications, replace or machine the rotor.
	Wheel bearings not adjusted.	Adjust wheel bearings to correct specifications
	Pad reversed (steel against iron).	Replace the brake pad and machine rotor to within specifications.
Excessive Pedal Effort	Malfunctioning vacuum booster.	Check the vacuum booster operation and repair, if necessary.
	Partial system failure.	Check the front and rear brake system for failure and repair. Also, check the brake warning light. If a failed system is found, the light should indicate failure.
	Excessively worn pad.	Check and replace pads in sets.
	Piston in caliper stuck or sluggish.	Remove caliper and rebuild.
	Fading brakes due to incorrect pad.	Remove and replace with original equipment pad or equivalent.
	Vacuum leak to vacuum booster.	Check for ruptured or loose hose.
	Check the direction of check valve within vacuum hose.	Correct vacuum hose direction.
	Grease on the brake pads.	Replace or clean.

5C-8 POWER-ASSISTED BRAKE SYSTEM

Condition	Possible cause	Correction
Excessive Brake Pedal Travel	Air in hydraulic circuit.	Bleed the hydraulic circuit.
	Level of brake fluid in the reservoir too low.	Replenish brake fluid reservoir to specified level and bleed hydraulic circuit as necessary.
	Master cylinder push rod clearance excessive.	Adjust
	Leakage in hydraulic system.	Correct or replace defective parts.
Brake Drag	Master cylinder pistons not returning correctly.	Adjust the stop light switch and vacuum booster push rod. If necessary, rebuild.
	Restricted brake pipes or hoses.	Check for soft hoses or damaged pipes, and replace with new hoses and new double-walled steel brake piping.
	Parking brake maladjusted.	Adjust
	Parking brake lining clearance insufficient.	Adjust
	Brake pedal free play insufficient.	Adjust the brake pedal height or power cylinder operating rod.
	Piston in the master cylinder sticking.	Replace
	Piston in the disc brake caliper sticking.	Replace piston seals.
	Brake pads sticking in caliper.	Clean
	Return spring weakened.	Replace
	Parking brake binding.	Overhaul the parking brakes and correct.
	Front hub bearing preload incorrect.	Adjust or replace.
	Parking brake shoes not returning.	Correct or replace the brake back plate and brake shoe as necessary.
	Obstructions in hydraulic circuit.	Clean
	Rotor warped excessively.	Grind or replace.
	Rear brake drum distorted.	Grind or replace.
	Parking cable sticking.	Grind or replace.
Grabbing or Uneven Braking Action (All conditions listed under "Pulls")	Malfunctioning vacuum booster.	Check operation and correct as necessary.
	Binding brake pedal mechanism.	Check and lubricate, if necessary.
	Corroded caliper assembly.	Clean and lubricate.
Brake Noisy	Brake pads are worn.	Replace
	Brake pads are hardened.	Replace
	Brake pads are in poor contact with rotor.	Correct
	Brake disc(s) warped, worn or damaged.	Grind or replace.
	Disc brake anti-squeak shims fatigued.	Replace
	Front hub bearings are loose or preload is incorrect.	Adjust or replace.
	Brake disc is rusted.	Grind or replace.

Condition	Possible cause	Correction
Poor Brake Action	Master cylinder faulty.	Correct or replace.
	Vacuum booster faulty.	Correct or replace.
	Level of brake fluid in reservoir too low.	Replenish and bleed.
	Air in hydraulic circuit.	Bleed
	Disc brake caliper faulty.	Clean or replace.
	Water or oil on brake pads.	Clean or replace.
	Brake pads in poor contact with the rotor.	Correct
	Brake pads worn.	Replace
	Brake disc rusted.	Grind or replace.
	Check valve in vacuum hose faulty.	Correct or replace.

Hydraulic Brakes

Filling Master Cylinder Reservoir

CAUTION: Use only specified brake fluid. Do not use any fluid which contains a petroleum base. Do not use a container which has been used for petroleum based fluids or a container which is wet with water. Petroleum based fluid will cause swelling and distortion of rubber parts in the hydraulic brake system. Water mixed with brake fluid lowers the fluid boiling point. Keep all fluid containers capped to prevent contamination.

Always fill the master cylinder reservoir when the engine is cold.

Never allow the brake fluid to come in contact with the painted surfaces.

The master cylinder reservoir must be kept properly filled to ensure adequate reserve and to prevent air and moisture from entering the hydraulic system. However, because of expansion due to heat absorbed from the brakes and the engine, the reservoir must not be overfilled. The brake fluid reservoir is on the master cylinder, which is located under the hood on the left side of the cowl. Thoroughly clean reservoir cap before removal to avoid getting dirt into reservoir. Remove the diaphragm. Add fluid as required to bring level to the "MAX" mark on the reservoir tank. Use "DOT 3" Hydraulic Brake Fluid. If the fluid cap diaphragm is stretched, return it to the original position before installing.

Deterioration of Brake Fluid

Using any other brake fluid than specified or brake fluid with mineral oil or water mixed in will drop the boiling point of brake fluid. It may, in turn, result in vapor lock or deteriorated rubber parts of the hydraulic system. Be sure to change the brake fluid at specified intervals.

If the rubber parts are deteriorated, remove all the system parts and clean them with alcohol. Prior to reassembly, dry the cleaned parts with air to remove the alcohol. Replace all the hoses and rubber parts of the system.

Leakage of Brake Fluid

With engine idling, set shift lever in the neutral position and continue to depress brake pedal at a constant pedal application force.

Should the pedal stroke become deeper gradually, leakage from the hydraulic pressure system is possible. Make sure by visual check that there is no leak.

Bleeding Brake Hydraulic System

A bleeding operation is necessary to remove air from the hydraulic brake system whenever air is introduced into the hydraulic system. It may be necessary to bleed the hydraulic system at all four brakes if air has been introduced through a low fluid level or by disconnecting brake pipes at the master cylinder. If a brake pipe is disconnected at one wheel, only that wheel cylinder/caliper needs to be bled. If the pipes are

disconnected at any fitting located between the master cylinder and brakes, then the brake system served by the disconnected pipe must be bled.

1. For 4-Wheel Antilock Brake System (ABS) equipped vehicle, be sure to remove the ABS main fuse 60A located at the relay and fuse box before bleeding air. If you attempt to bleed air without removing the main fuse, air cannot be let out thoroughly, and this may cause damage to the hydraulic unit. After bleeding air, be sure to replace the ABS main fuse back to its original position.
2. Set the parking brake completely, then start the engine.

NOTE: The vacuum booster will be damaged if the bleeding operation is performed with the engine off.

3. Remove the master cylinder reservoir cap.
4. Fill the master cylinder reservoir with brake fluid. Keep the reservoir at least half full during the air bleeding operation
5. Always use new brake fluid for replenishment.
6. In replenishing brake fluid, take care that air bubbles do not enter the brake fluid.

When the master cylinder is replaced or overhauled, first bleed the air from the master cylinder, then from each wheel cylinder and caliper following the procedures described below.


Bleeding the Master Cylinder

7. Disconnect the rear wheel brake pipe (1) from the master cylinder.
Check the fluid level and replenish as necessary. If replenished, leave the system for at least one minute.
8. Depress the brake pedal slowly once and hold it depressed.
9. Completely seal the delivery port of the master cylinder with your finger, where the pipe was disconnected then release the brake pedal slowly.
10. Release your finger from the delivery port when the brake pedal returns completely.
11. Repeat steps 8 through 10 until the brake fluid comes out of the delivery port during step 8.

NOTE: Do not allow the fluid level in the reservoir to go below the half-way mark.

12. Reconnect the brake pipe (1) to the master cylinder and tighten the pipe.
13. Depress the brake pedal slowly once and hold it depressed.
14. Loosen the rear wheel brake pipe (1) at the master cylinder.
15. Retighten the brake pipe, then release the brake pedal slowly.
16. Repeat steps 13 through 15 until no air comes out of the port when the brake pipe is loosened

NOTE: Be very careful not to allow the brake fluid to come in contact with painted surfaces.



17. Bleed the air from the front wheel brake pipe connection (2) by repeating steps 7 through 16.

Bleeding the Caliper

18. Bleed the air from each wheel in the order listed below:

- ☐ Right rear caliper or wheel cylinder
- ☐ Left rear caliper or wheel cylinder
- ☐ Right front caliper
- ☐ Left front caliper

Conduct air bleeding from the wheels in the above order. If no brake fluid comes out, it suggests that air is mixed in the master cylinder. In this case, bleed air from the master cylinder in accordance with steps 7 through 17, and then bleed air from the caliper or wheel cylinder.

19. Place the proper size box end wrench over the bleeder screw.
20. Cover the bleeder screw with a transparent tube, and submerge the free end of the transparent tube in a transparent container containing brake fluid.
21. Pump the brake pedal slowly three (3) times (once/sec), then hold it depressed.
22. Loosen the bleeder screw until fluid flows through the tube.
23. Retighten the bleeder screw.
24. Release the brake pedal slowly.
25. Repeat steps 21 through 24 until the air is completely removed.

It may be necessary to repeat the bleeding procedure 10 or more times for front wheels and 15 or more times for rear wheels.

26. Go to the next wheel in the sequence after each wheel is bled.

Be sure to monitor reservoir fluid level.

27. Depress the brake pedal to check if you feel "sponginess" after the air has been removed from all wheel cylinders and calipers.

If the pedal feels "spongy", the entire bleeding procedure must be repeated.

28. After the bleeding operation is completed on the each individual wheel, check the level of the brake fluid in the reservoir and replenish up to the "MAX" level as necessary.

29. Attach the reservoir cap.

If the diaphragm inside the cap is deformed, reform it and install.

30. Stop the engine.

Flushing Brake Hydraulic System

It is recommended that the entire hydraulic system be thoroughly flushed with clean brake fluid whenever new parts are installed in the hydraulic system. Approximately one quart of fluid is required to flush the hydraulic system. The system must be flushed if there is any doubt as to the grade of fluid in the system or if fluid has been used which contains the slightest trace of mineral oil. All rubber parts that have been subjected to a contaminated fluid must be replaced.

Brake Pipes and Hoses

The hydraulic brake system components are interconnected by special steel piping and flexible hoses. Flexible hoses are used between the frame and the front calipers, the frame and rear axle case and the rear axle and the rear calipers.

When the hydraulic pipes have been disconnected for any reason, the brake system must be bled after reconnecting the pipe. Refer to "Bleeding the Brake Hydraulic System" in this section.


Brake Hose Inspection

The brake hose should be inspected at least twice a year. The brake hose assembly should be checked for road hazard, cracks and chafing of the outer cover, and for leaks and blisters. Inspect for proper routing and mounting of the hose. A brake hose that rubs on suspension components will wear and eventually fail. A light and mirror may be needed for an adequate inspection. If any of the above conditions are observed on the brake hose, adjust or replace the hose as necessary.

CAUTION: Never allow brake components such as calipers to hang from the brake hoses, as damage to the hoses may occur.

Front Caliper Brake Hose

Front Caliper Brake Hose and Associated Parts



352RW001

Legend

- (1) Bolt and Gasket
- (2) Clip
- (3) Hose
- (4) Brake Pipe

Removal

1. Raise the vehicle and support it with suitable safety stands.
2. Remove the wheel and tire assembly.
3. Clean dirt, grease, and other foreign material off the hose fittings at both ends.
4. Disconnect brake pipe.
5. Remove clip.
6. Remove bolt and gasket.
7. Remove hose.

Installation

To install, follow the removal steps in the reverse order, noting the following points.

1. Tighten the brake pipes to the specified torque

Torque: 16 N·m (12 lb ft)

2. Tighten the bolt to the specified torque.


Torque: 35 N·m (26 lb ft)

NOTE: Always use new gaskets and be sure to put the hooked edge of the flexible hose end into the anti-rotation cavity.

After installing the brake hoses, bleed the brakes as described in this section.

Rear Axle Brake Hose

Rear Axle Brake Hose and Associated Parts



352RW002

Legend

- (1) Brake Pipe
- (2) Clip
- (3) Bolt
- (4) Brake Pipe
- (5) Hose

Removal

1. Raise the vehicle and support it with suitable safety stands.
2. Remove wheel and tire assembly.
3. Clean dirt, grease, and other foreign material off the hose fittings at both ends.
4. Disconnect brake pipe.
5. Remove clip.
6. Remove brake pipe.
7. Remove bolt.
8. Remove hose.

Installation

To install, follow the removal steps in the reverse order, noting the following points.

1. Tighten the brake pipes to the specified torque

Torque: 16 N·m (12 lb ft)

2. Tighten the bolt to the specified torque.


Torque: 15 N·m (11 lb ft)

After installing the brake hoses, bleed the brakes as described in this section.

Brake Pipe


Removal

1. Raise the vehicle and support it with suitable safety stands.
2. Remove wheel and tire assembly as necessary.
3. Clean dirt, grease, and other foreign material off the pipe fittings at both ends.
4. Remove brake pipe (1).



330RW011

5. Remove plastic clip (2).



330RW002

Installation

To install, follow the removal steps in the reverse order, noting the following points.

1. Tighten the brake pipes to the specified torque.

Master cylinder and P&B valve sides

Torque: 12 N·m (104 lb in)


Others

Torque: 16 N·m (12 lb ft)

After installing the brake pipes, bleed the brakes as described in this section.

P & B (Proportioning and Bypass) Valve

P & B (Proportioning and Bypass) Valve Sectional View



Legend

- (1) Master Cylinder (Secondary)
- (2) Master Cylinder (Primary)
- (3) Rear Brake
- (4) Front Brake


The P&B valve contains two sections, each serving a different function.

The proportioning section of the P&B valve proportions outlet pressure to the rear brakes after a predetermined rear input pressure has been reached. This is done to prevent rear wheel lock up on the vehicles with light rear wheel loads. The valve has a by-pass feature which assures full system pressure to the rear brakes in the event of front brake system malfunction. Also full front pressure is retained in the event of rear brake malfunction.

The P&B valve is not repairable and must be replaced as complete assembly.

Removal

1. The P&B valve is not repairable and must be replaced as a complete assembly. Care must be taken to prevent brake fluid from contacting any painted surface.
2. Remove hydraulic pipes (1) and plug the pipes (1) to prevent the loss of fluid or the entrance of dirt.
3. Remove bolt (3).
4. Remove P&B valve (2).



Installation

1. Install P&B valve (2).
2. Install bolt (3) and tighten the bolt to the specified torque.

Torque: 22 N·m (16 lb ft)


3. Install hydraulic pipes (1) and tighten the bolt to the specified torque.

Torque: 12 N·m (104 lb in)

4. After installing the brake pipes, bleed the brakes as refer to Bleeding Brake Hydraulic System in this section.

Main Data and Specifications

Torque Specifications




E05RW014

Brake Pedal

Checking Pedal Height

The push rod serves as the brake pedal stopper when the pedal is fully released. Brake pedal height adjustment should be performed as follows:

Adjust Brake Pedal



1. Measure the brake pedal height after making sure the pedal is fully returned by the pedal return spring. Pedal height must be measured after starting the engine and receiving it several times.

Pedal Free Play: 6-10 mm (0.23-0.39 in)

Pedal Free Play: 173-185 mm (6.81-7.28 in)


NOTE: Pedal free play must be measured after turning off the engine and stepping on the brake pedal firmly five times or more.

2. If the measured value is not within the above range, adjust the brake pedal as follows:
 - a. Disconnect the stoplight switch connector.
 - b. Loosen the stoplight switch lock nut.
 - c. Rotate the stoplight switch so that it moves away from the brake pedal.
 - d. Loosen the lock nut (1) on the push rod.
 - e. Adjust the brake pedal to the specified height by rotating the push rod in the appropriate direction.
 - f. Tighten the lock nut to the specified torque.

Torque: 20 N·m (15 lb ft)

- g. Adjust the stoplight switch (2) to the specified clearance (between the switch housing and the brake pedal) by rotating the switch housing.


Clearance: 0.5-1.0 mm (0.02-0.04 in)



NOTE: While adjusting the stoplight switch, make sure that the threaded part of the stoplight switch does not push the brake pedal.

- h. Tighten the stoplight switch lock nut.
- i. Connect the stoplight switch connector.

Checking Pedal Travel




1. Pedal height must be measured after starting the engine and revving it several times to apply vacuum to the vacuum booster fully.

NOTE: Pedal height must be 95 mm (3.7 in) or more when about 50 kg (110.25 lb) of stepping force is applied.

2. If the measured value is lower than the above range, air existing in the hydraulic system is suspected. Perform the bleeding procedure.

Brake Pedal and Associated Parts



310RW007

Legend

- | | |
|----------------------------------|--------------------------|
| (1) Brake Pedal Bracket Assembly | (6) Pedal Assembly |
| (2) Fulcrum Pin and Nut | (7) Push Rod Pin |
| (3) Connector | (8) Lower Cover |
| (4) Snap Pin | (9) Bolts and Nut |
| (5) Return Spring | (10) Driver Knee Bolster |

Removal

1. Disconnect the battery “-” terminal cable, and wait at least 5 minutes.
2. Disconnect the yellow 3 way SRS connector located under the steering column.
3. Remove the engine hood opening lever.
4. Remove lower cover (8).
5. Remove driver knee bolster (10).
6. Disconnect the stop light switch connector (3). Disconnect the anti-theft control module connector. Refer to Body and Accessories section.
7. Remove snap pin (4) and push rod pin (7).
8. Remove the steering column shaft fixing bolt and nut (9) on the steering wheel side, and lower the steering column shaft.
9. Remove the brake pedal bracket assembly (1).
10. Remove return spring (5).
11. Remove fulcrum pin and nut (2).

12. Remove pedal assembly (6).

Installation

1. Apply grease to the entire circumference of the fulcrum pin.
2. Install pedal assembly (6) and fulcrum pin and nut (2). Tighten the nut (2) to the specified torque.

Torque: 35 N-m (26 lb ft)

3. Install the brake pedal bracket assembly (1). Tighten the bolts and nuts specified torque.

Torque: 15 N-m (11 lb ft)

4. Install return spring (5).
5. Adjust pedal free travel. Refer to Brake Pedal Adjustment in this section.
6. Tighten the steering column fixing bolt (9) (dash panel) to the specified torque.

Torque: 19 N-m (14 lb ft)

7. Tighten the steering column fixing nut (9) (Cross Beam) to the specified torque.


Torque: 20 N·m (14 lb ft)

8. Apply grease to the entire circumference of the Push rod pin (7).
9. Install push rod pin (7).
10. Install snap pin (4).
11. Connect the anti-theft control module connector.
Refer to Body and Accessories section.

12. Connect the stop light switch connector (3).
13. Install driver knee bolster (10) and lower cover (8).
14. Install the engine hood opening lever.
15. Connect the yellow 3 way SRS connector located under the steering column.
16. Connect the battery “-” terminal cable.

Stoplight Switch

Parts Location



Legend

- (1) Connector
- (2) Switch
- (3) Lock Nut

Removal


1. Disconnect connector (1)
2. Remove lock nut (3).
3. Remove switch (2).

Installation

1. Adjust the stop light switch to the specified clearance (between switch housing and brake pedal) by rotating the switch housing.

Clearance : 0.5-0.1 mm (0.02-0.04 in)

NOTE: Do not attempt to force the push rod into position during the stop light switch installation and adjustment procedure.




2. Connect connector (1).
3. Install lock nut (3).

Main Data and Specifications

General Specifications

Pedal free play	6–10 mm (0.23 –0.39 in)
Pedal Height	173–185 mm (6.81–7.28 in)


Torque Specifications



E06RW013

Fluid Reservoir Tank

Fluid Reservoir Tank and Associated Parts



330RW003

Legend


- (1) Fluid Reservoir
- (2) Electrical Connector

- (3) O-ring
- (4) Retainer

Removal

NOTE: Before removing the fluid reservoir, remove the brake fluid from the fluid reservoir.

1. Disconnect electrical connector.
2. Remove retainer (1).




330RW004

3. Remove fluid reservoir and the fluid level sensor built into the fluid reservoir. The fluid level sensor cannot be removed for servicing.
4. Remove O-ring.

Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. O-ring (1) must be set onto the fluid reservoir (2), before installing fluid reservoir.



330RW005

Master Cylinder Assembly

Master Cylinder Assembly and Associated Parts



330RW010

Legend

- | | |
|--------------------------|---------------------------|
| (1) Electrical Connector | (4) P&B Valve and Bracket |
| (2) Master Cylinder | (5) Brake Pipes |
| (3) 2 attaching Nuts | (6) Spacer and 2 gaskets |

Removal

CAUTION: When removing the master cylinder from the vacuum booster, be sure to get rid of the internal negative pressure of the vacuum booster (by, for instance, disconnecting the vacuum hose) in advance.

If any negative pressure remains in the vacuum booster, the piston may possibly come out when the master cylinder is being removed, letting the brake fluid run out.

While removing the master cylinder, further, do not hold the piston as it can be easily pulled out.

Outside surface of the piston is the surface on which seals are to slide. Care should be taken to keep the surface free of cuts and dents.

1. Disconnect electrical connector.
2. Remove brake pipes and after disconnecting the brake pipe, cap or tape the openings of the brake pipe to prevent the entry of foreign matter.
3. Remove 2 attaching nuts.
4. Remove P&B valve and bracket.

5. Remove master cylinder.

6. Remove spacer and the 2 gaskets.

Inspection and Repair

Master Cylinder

The master cylinder is not repairable and must be replaced as a complete assembly if found defective.

Inspection

Excessive brake pedal travel, malfunction or dragging brake suggests that the master cylinder is defective. In such cases perform the following visual check:


Visual Check

Make parts replacement as required if wear, distortion, nicks, cuts, corrosion, or other abnormal conditions are found through the following parts inspection:

- ☐ Master cylinder body
- ☐ Fluid reservoir
- ☐ O-ring


Functional Inspection of Master Cylinder Piston

Push the primary piston (1) with your fingers to check that it travels smoothly. If the motion is questionable, replace the master cylinder as a complete assembly.




Functional Inspection of Master Cylinder

Inspect the master cylinder for function as follows. If any abnormal function is found, replace with a new one. Install the primary piston holder (3) J-39242 (including the master cylinder attachment (5) and master cylinder plug (7)) onto the master cylinder (4). Make sure the spacer (2) (2 bolts) with its adjusting bolt is screwed in up to the "0" line



Connect the master cylinder attachment (5) J-39242 with the end of the radiator cap tester (6) J-24460-01, and apply air pressure with the cap tester. Make sure there is no rise in pressure and that with the adjusting bolt further screwed in 5 mm (align the adjusting bolt to the "5" line). There should be a pressure increase of 0.5 kg/cm² or more.



NOTE: When checking the front (or primary) side, be sure to mount the master cylinder plug in the rear (or secondary) port.

	"0" Line	"5" Line
Apply air pressure to the front and rear ports	No pressure rise.	Pressure increase of 0.5 kg/cm ² or more
Remarks	Checks port into the atmospheric pressure chamber	Checks air tightness of the pressure chamber

NOTE:

1. Do not use an air compressor, as the air from the compressor is mixed with compressor oil.
2. When installing the master cylinder onto the vacuum booster, always adjust the vacuum booster push rod. (Refer to "Vacuum Booster" in this section).
3. After the master cylinder is installed onto the vehicle, check for leakage, pedal travel and pedal free play.

Installation

1. Install spacer and the 2 gaskets.
2. Install master cylinder.

When replacing the master cylinder or vacuum booster or both, always measure the vacuum booster push rod protrusion and adjust it as necessary (Refer to "Vacuum Booster" in section).

3. Install P&B valve and bracket.
4. Install 2 attaching nuts and tighten the attaching nuts to the specified torque.

Torque: 13 N·m (113 lb in)

5C-24 POWER-ASSISTED BRAKE SYSTEM

5. Install brake pipes and tighten the brake pipe to the specified torque.

Master cylinder and P&B valve sides

Torque: 12 N·m (104 lb in)

Others

Torque: 16 N·m (12 lb in)


6. Connect electrical connector.

Main Data and Specifications

General Specifications

Type	Dual-circuit
Piston bore diameter	25.4 mm (1.000 in)

Torque Specifications




Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS200	J-39242 Primary Piston Holder (including master cylinder attachment and master cylinder plug)
 901RS201	J-24460-01 Radiator Cap Tester

Vacuum Booster Assembly

Vacuum Booster Assembly and Associated Parts



331RW005

Legend

- | | |
|-------------------------------|---------------------|
| (1) Pin | (4) Master Cylinder |
| (2) Vacuum Booster Fixing Nut | (5) Vacuum Booster |
| (3) Vacuum Hose | (6) Snap Pin |

Removal

1. Before removing the vacuum booster assembly, disconnect and remove the brake pipes.
2. Remove master cylinder, refer to "Master Cylinder Removal" in this section.

CAUTION: When removing the master cylinder from the vacuum booster, be sure to get rid of the internal negative pressure of the vacuum booster (by, for instance, disconnecting the vacuum hose) in advance.

If any negative pressure remains in the vacuum booster, the piston may possibly come out when the master cylinder is being removed, letting the brake fluid run out.

While removing the master cylinder, further, do not hold the piston as it can be easily pulled out.

Outside surface of the piston is the surface on which seals are to slide. Care should be taken to keep the surface free of cuts and dents.

3. Remove vacuum hose.
4. Disconnect the yoke clevis from the brake pedal.
5. Remove vacuum booster fixing nut.
6. Remove vacuum booster.


Inspection and Repair

Vacuum Hose

1. Inspect the check valve (2), which is installed inside the vacuum hose.
2. Air should pass freely from the vacuum booster (3) to the engine (1).

5C-26 POWER-ASSISTED BRAKE SYSTEM

3. Air should not pass from the engine (1) to the vacuum booster (3). If it does, the check valve is inoperative and must be replaced.




360RW001

Installation

1. Perform vacuum booster and vacuum booster push rod adjustment.

NOTE: When replacing either the master cylinder or vacuum booster, be sure to measure push rod, and adjust if required.


2. Remove retainer from vacuum booster front shell using a small screwdriver. Then gently draw plate and seal assembly out of the shell inside.



331RS003

3. Set push rod gauge J-39216 on vacuum booster, and apply negative pressure by means of vacuum pump J-23738-A so that the pressure in the vacuum booster becomes 500 mm Hg.


NOTE: Be sure to apply NEGATIVE pressure after installing a push rod gauge on the vacuum booster.



331RS004


4. Measure dimension (4).

**Dimension (4) (Standard): -0.1-0.1 mm
(-0.0039-0.0039 in)**



331RW002


5. If dimension (4) is out of the standard range, adjust push rod using the Push Rod Support J-39241.



6. Mount plate and seal assembly in vacuum booster front shell. Then install the retainer.
7. Install vacuum booster fixing nut and tighten the specified torque.
- Torque: 15 N·m (11 lb ft)**
8. Install yoke clevis.
9. Connect vacuum hose and make sure that the arrow on the hose points in the direction of the engine.
10. Install master cylinder, refer to "Master Cylinder Installation" in this section.

Exterior Components

Exterior Components and Associated Parts




331RW006

Legend

- | | |
|----------------------|------------------------------|
| (1) Yoke Clevis | (6) Filter |
| (2) Lock Nut | (7) 2 Gaskets and Spacer |
| (3) Retaining Clip | (8) Vacuum Booster |
| (4) Valve Body Guard | (9) Retainer |
| (5) Silencer | (10) Plate and Seal Assembly |
| | (11) Master Cylinder |

Removal

1. Remove master cylinder. Refer to "Master Cylinder" in this section.
2. Remove vacuum booster. Refer to "Vacuum Booster" in this section.
3. Remove yoke clevis.
4. Remove lock nut.
5. Remove retaining clip.
6. Remove valve body guard.
7. Remove silencer.
8. Remove filter.
9. Remove 2 gaskets and spacer.
10. Remove retainer, using a small screwdriver to pry out the retainer. Gently pull out the plate and seal assembly from the shell.



331RS003

Inspection and Repair

Visual Check

Make necessary parts replacement if cuts, nicks, excessive wear, or other abnormal conditions are found through inspection. Check the following parts:

- ☐ Yoke clevis
- ☐ Valve body guard
- ☐ Silencer
- ☐ Filter plate and seal assembly

Installation

1. Install plate and seal assembly.
2. Install retainer.

3. Install 2 gaskets and spacer.

4. Install filter.

5. Install silencer.

6. Install valve body guard.

7. Install retainer.

8. Install lock nut and yoke clevis and tighten to the specified torque.

Torque: 20 N·m (15 lb ft)

9. Install vacuum booster, refer to "Vacuum Booster" in this section.

10. Install master cylinder, refer to "Master Cylinder" in this section and after installation, perform brake pedal check and adjustment. Refer to "Brake Pedal" in this section.

Vacuum Booster Overhaul

Vacuum Booster


The vacuum booster cannot be disassembled for repair. Replace a defective vacuum booster with a new one.

Main Data and Specifications




General Specifications

Vacuum booster diaphragm diameter (Front)	205 mm (8.07 in)
Vacuum booster diaphragm diameter (Rear)	230 mm (9.06 in)
Push rod stroke	More than 32.0 mm (1.26 in)
Plunger diameter	10.25 mm (0.40 in)
Push rod diameter	27.4 mm (1.08 in)

Torque Specifications



Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
 901RS202	J-39216 Push Rod Gauge
 901RS203	J-23738-A Vacuum Pump
 901RS204	J-39241 Push Rod Support


Front Disc Brake Pads

Front Disc Brake Pads Inspection

Check the outer pad by looking at each caliper from above. Check the thickness on the inner pad by looking down through the inspection hole in the top of the caliper. Whenever the pad is worn to about the thickness of the pad base, the pad should be removed for further measurements. The pad should be replaced anytime the pad thickness (1) is worn to within 1.00 mm (0.039 in) of the pad itself.


The disc pads have a wear indicator that makes a noise when the pad wears to where the replacement is required.

Minimum limit (1): 1.0 mm (0.039 in)



302RS002

Front Disc Brake Pads and Associated Parts



302RW003

Legend


- (1) Lock Bolt
- (2) Caliper Assembly

- (3) Pad Assembly
- (4) Clip
- (5) Outer Side

Removal

NOTE: If a squealing noise occurs from the front brake while driving, check the pad wear indicator plate. If the indicator plate contacts the rotor, the disc pad assembly should be replaced.


- Draw out two-thirds of the brake fluid from the reservoir.
 - Raise the vehicle and support it with suitable safety stands.
1. Remove wheel and tire assembly, refer to "Wheels and Tires System" in Section 3E.
 2. Remove lock bolt (1).




3. Rotate caliper assembly and support the caliper assembly so that the brake hose is not stretched or damaged.
4. Remove pad assembly with shim.
5. Remove Clip.

Installation

1. Install clip.




2. Apply special grease (approximately 0.2 g) to both contacting surfaces of the inner shims (2). Wipe off extruded grease after installing. Install pad assembly with shim.




Legend

- (2) Inner Shim
- (3) Wear Indicator
- (4) Inner Side

5C-34 POWER-ASSISTED BRAKE SYSTEM




3. Use adjustable pliers to bottom the piston into the caliper bore. Be careful do not damage the piston boot and do not damage the flexible hose by twisting or pulling it.
Install caliper assembly.
Set caliper assembly in place.



4. Install lock bolt (5) and tighten the bolt to the specified torque.

Torque: 74 N·m (54 lb ft)



5. Install wheel and tire assembly, refer to "Wheels and Tires System" in Section 3E.
6. Pump the brake pedal several times to make sure that the pedal is firm. Check the brake fluid level in the reservoir after pumping the brakes.

Front Disc Brake Rotor

Inspection

In the manufacturing of the brake rotor, all the tolerances regarding surface finish, parallelism and lateral runout are held very closely. Maintaining these tolerances provides the surface necessary to assure smooth brake operation.

Lateral Runout


Lateral runout is the movement of the rotor from side to side as it rotates on the spindle. This could also be referred to as "rotor wobble".

This movement causes the piston to be knocked back into its bore. This results in additional pedal travel and a vibration during braking.

Checking Lateral Runout

1. Adjust the wheel bearing correctly, refer to "Differential" in Section 4A.
2. Attach a dial indicator to some portion of the suspension so that the stem contacts the rotor face about 29 mm (1.14 in) from the rotor edge.
3. Move the rotor one complete rotation and the lateral runout should not exceed 0.13 mm (0.005 in).

Maximum runout: 0.13 mm (0.005 in)




411RS019

Parallelism

Parallelism is the measurement of thickness of the rotor at four or more points around the circumference of the rotor. All measurement must be made at 29 mm (1.14 in) from the edge of the rotor.

The rotor thickness must not vary more than 0.010 mm (0.0004 in) from point to point.

Maximum runout: 0.010 mm (0.0004 in)



411RS018

Replacing Brake Rotors

When installing new brake rotors, do not refinish the surfaces. These parts are at the correct level of surface finish.

Refinishing Brake Rotors


Accurate control of the rotor tolerances is necessary for proper performance of the disc brakes. Machining of the rotor should be done only with precision equipment. All brake rotors have a minimum thickness dimension cast into them. This dimension is the minimum wear dimension and not a refinish dimension. The minimum wear dimension is 24.60 mm (0.969 in). The minimum refinish dimension is 24.97 mm (0.983 in).

When refinishing rotors, always use sharp cutting tools or bits. Dull or worn tools leave a poor surface finish which will affect initial braking performance. Vibration dampening attachments should always be used when refinishing braking surfaces. These attachments eliminate tool chatter and will result in better surface finish.

After refinishing, replace any rotor that does not meet the minimum thickness of 24.97 mm (0.983 in). Do not use a brake rotor that will not meet the specification.

Minimum wear dimension: 24.60 mm (0.969 in)


Refinish dimension: 24.97 mm (0.983 in)



411RW003

Front Disc Brake Caliper Assembly

Front Disc Brake Caliper Assembly and Associated Parts




302RW008

Legend


- | | |
|-------------------------|---------------------------------------|
| (1) Guide Bolt | (4) Caliper Assembly |
| (2) Brake Flexible Hose | (5) Clip |
| (3) Lock Bolt | (6) Support Bracket with Pad Assembly |
| | (7) Pad Assembly |

Removal

1. Raise the vehicle and support with suitable safety stands.
2. Concerning wheel and tire assembly, refer to "Wheels and Tires System" in Section 3E.
3. Remove the bolt and gaskets, then disconnect the flexible hose from the caliper and after disconnecting the flexible hose (1), cap or tape the openings to prevent entry of foreign material.



4. Since the brake fluid flows out from the connecting coupler, place a drain pan under the vehicle.
5. Remove guide bolt (2).
6. Remove lock bolt (3).




7. Remove caliper assembly.
8. Remove support bracket with pad assembly and take care not to damage the flexible brake hose when removing the support bracket.


9. Remove pad assembly with shim and mark the lining locations if they are to be reinstalled.
10. Remove clip.

Installation

1. Install clip.



2. Apply special grease (approximately 0.2 g) to both contacting surfaces of the inner shims (4). Wipe off extruded grease after installing. Install pad assembly with shim.




Legend

- (4) Inner Shim
- (5) Wear Indicator
- (6) Inner Side

5C-38 POWER-ASSISTED BRAKE SYSTEM

3. Install support bracket and tighten the bolt (7) to the specified torque.


Torque: 155 N·m (115 lb ft)



302RW012

4. Install caliper assembly.
5. Install lock bolt (9) and guide bolt (8) and tighten the bolt to the specified torque.


Torque: 74 N·m (54 lb ft)



302RW013

6. Install brake flexible hose, always use new gaskets and be sure to put the hooked edge of the flexible hose end into the anti-rotation cavity then tighten the I-bolt (10) to the specified torque.

Torque: 35 N·m (26 lb ft)




302RW014

7. Install wheel and tire assembly, referring to "Wheels and Tires System" in Section 3E.
8. Bleed brakes. Refer to "Hydraulic Brakes" in this section.

Front Disc Brake Caliper

Front Disc Brake Caliper Disassembled View




302RW015

Legend

- | | |
|----------------------|---|
| (1) Guide Bolt | (5) Dust Boot: Guide Bolt and Lock Bolt |
| (2) Lock Bolt | (6) Piston Seal |
| (3) Bleeder with Cap | (7) Piston |
| (4) Caliper Body | (8) Dust Boot: Piston |
| | (9) Dust Boot Ring |

Disassembly

1. Remove guide bolt.
2. Remove lock bolt.
3. Remove dust boot: guide bolt and lock bolt.
4. Remove dust boot ring, using a small screwdriver.




302RS016

5C-40 POWER-ASSISTED BRAKE SYSTEM

5. Insert a block of wood into the caliper and force out the piston by blowing compressed air into the caliper at the flexible hose attachment. This procedure must be done prior to removal of the dust boot. Remove piston.

WARNING: DO NOT PLACE YOUR FINGERS IN FRONT OF THE PISTON IN AN ATTEMPT TO CATCH OR PROTECT IT WHEN APPLYING COMPRESSED AIR. THIS COULD RESULT IN PERSONAL INJURY.

CAUTION: Use just enough air to ease the piston out of the bore. If the piston is blown out, it may be damaged.



6. Remove dust boot: piston.
7. Remove piston seal.
8. Remove bleeder with cap.
9. Remove caliper body.

Inspection and Repair

Make necessary parts replacement, if wear, damage, corrosion or any other abnormal conditions are found through inspection.

Check the following parts:

- ☐ Rotor
- ☐ Cylinder body
- ☐ Cylinder bore
- ☐ Piston
- ☐ Guide bolt, lock bolt
- ☐ Support bracket


NOTE: The piston seal, boot ring and dust boot are to be replaced each time the caliper is overhauled. Discard these used rubber parts and replace them with new ones.

Reassembly


1. Install caliper body.
2. Install bleeder with cap and tighten the cap to the specified torque.

Torque: 8 N·m (69 lb in)


3. Apply special rubber grease to the piston seal and cylinder wall, then insert the piston seal into the cylinder. The special rubber grease is included in the repair kit.




4. When inserting the piston into the cylinder, use finger pressure only and do not use a mallet or other impact tool, since damage to the cylinder wall or piston seal can result. Install piston.



5. Apply special grease (approximately 1 g) to the piston and attach the dust boot to the piston and caliper. Insert the dust boot ring into the dust boot.



6. Install guide bolt and lock bolt dust boot.
7. Install the dust boot on the support bracket after applying special grease (approximately 1 g) onto the dust boot inner surface. Apply special grease onto the lock bolt and guide bolt setting hole of the support bracket.



8. Install lock bolt and guide bolt and tighten the bolt to the specified torque.


Torque: 74 N·m (54 lb ft)

Main Data and Specifications

General Specifications

Type	Floating, pin slide
Pad dimension	55 cm ² (8.52 in ²)
Adjusting method	Self-adjusting
Piston diameter	60.33 mm (2.38 in)
Disc type	Ventilated
Disc thickness	26 mm (1.02 in)
Disc effective diameter	222 mm (8.74 in)

Torque Specifications



E05RW004


Rear Disc Brake Pads (4×4 Model)

Brake Pads Inspection

Check the outer pads by looking at each caliper from above. Check the thickness on the inner pad by looking down through the inspection hole in the top of the caliper. Whenever the pad is worn to about the thickness of the pad base, the pad should be removed for further measurements. The pad should be replaced anytime the pad thickness (1) is worn to within 1.0 mm (0.039 in) of the pad itself.


The disc pads have a wear indicator that makes a noise when the pad wears to where replacement is required.

Minimum limit (1): 1.0 mm (0.039 in)



302RW016

Brake Pads and Associated Parts



306RW001

Legend


- (1) Caliper Assembly
- (2) Clip

- (3) Lock Bolt
- (4) Pad Assembly

Removal

NOTE: If a squealing noise occurs from the rear brake while driving, check the pad wear indicator plate. If the indicator plate contacts the rotor, the disc pad assembly should be replaced.


- Draw out two-thirds of the brake fluid from the reservoir.
- Raise the vehicle and support it with suitable safety stands.
- 1. Remove wheel and tire assembly, referring to "Wheels and Tires System" in Section 3E.
- 2. Remove lock bolt (1)




- 3. Rotate caliper assembly and support the caliper assembly so that the brake hose is not stretched or damaged.
- 4. Remove pad assembly with shim.
- 5. Remove clip.

Installation

- 1. Install clip (2).




- 2. Apply special grease (approximately 0.2 g) to both contacting surfaces of the inner shims. Wipe off extruded grease after installing. Install pad assembly with shim.




Legend

- (3) Inner Shim
- (4) Wear Indicator



306RW005

3. Use adjustable pliers to bottom the piston into the caliper bore. Be careful not to damage the piston dust boot and do not damage the flexible hose by twisting or pulling it. Install caliper assembly. Set caliper assembly in place.




302RS008

4. Install lock bolt (5) and tighten the bolt to the specified torque.

Torque: 44 N·m (32 lb ft)

5. Install wheel and tire assembly, referring to "Wheels and Tires System" in Section 3E.
6. Pump the brake pedal several times to make sure that the pedal is firm. Check the brake fluid level in the reservoir after pumping the brakes.



306RW006

Rear Disc Brake Rotor (4×4 Model)

Inspection

In the manufacturing of the brake rotor, all the tolerances regarding surface finish, parallelism and lateral runout are held very closely. Maintaining these tolerances provides the surface necessary to assure smooth brake operation.

Lateral Runout


Lateral runout is the movement of the rotor from side to side as it rotates on the spindle. This could also be referred to as "rotor wobble".

This movement causes the piston to be knocked back into its bore. This results in additional pedal travel and a vibration during braking.

Checking Lateral Runout

1. Adjust the wheel bearing correctly, referring to "Differential" in Section 4A.
 2. Attach a dial indicator to some portion of the suspension so that the stem contacts the rotor face about 29 mm (1.14 in) from the rotor edge.
 3. Move the rotor one complete rotation.
1. The lateral runout should not exceed 0.13 mm (0.005 in)

Maximum runout: 0.13 mm (0.005 in)




411RS019

Parallelism

Parallelism is the measurement of thickness of the rotor at four or more points around the circumference of the rotor. All measurement must be made at 22 mm (0.87 in) from the edge of the rotor.

The rotor thickness must not vary more than 0.010 mm (0.0004 in) from point to point.

Maximum parallelism: 0.010 mm (0.0004 in)



420RS013

Replacing Brake Rotors

When installing new brake rotors, do not refinish the surfaces. These parts are at the correct level of surface finish.

Refinishing Brake Rotors


Accurate control of the rotor tolerances is necessary for proper performance of the disc brakes. Machining of the rotor should be done only with precision equipment. All brake rotors have a minimum thickness dimension cast into them. This dimension is the minimum wear dimension and not a refinish dimension. The minimum wear dimension is 16.6 mm (0.654 in). The minimum refinish dimension is 16.97 mm (0.668 in).

When refinishing rotors, always use sharp cutting tools or bits. Dull or worn tools leave a poor surface finish which will affect initial braking performance. Vibration dampening attachments should always be used when refinishing braking surfaces. These attachments eliminate tool chatter and will result in better surface finish.

After refinishing, replace any rotor that does not meet the minimum thickness of 16.97 mm (0.668 in). Do not use a brake rotor that will not meet the specification.

Minimum wear dimension: 16.6 mm (0.654 in)

Refinish dimension: 16.97 mm (0.668 in)




Rear Drum (In Disc) Inside Diameter Check

Check the rear drum inside diameter by measuring at more than two portions as shown in the illustration. If the inside diameter is greater than the limit, replace the rear rotor.


Standard: 210.0 mm (8.27 in)

Limit: 211.4 mm (8.32 in)



Rear Disc Brake Caliper Assembly (4×4 Model)

Rear Disc Brake Caliper Assembly and Associated Parts





Legend

- | | |
|-------------------------|----------------------------|
| (1) Brake Flexible Hose | (4) Support Bracket |
| (2) Clip | (5) Guide Bolt |
| (3) Lock Bolt | (6) Pad Assembly with Shim |
| | (7) Caliper Assembly |

Removal

1. Raise the vehicle and support with suitable safety stands.
2. Remove wheel and tire assembly, referring to "Wheels and Tires System" in Section 3E.
3. Remove the bolt and gaskets, then disconnect the flexible hose from the caliper and after disconnecting the flexible hose (1), cap or tape the openings to prevent entry of foreign material.

4. Since the brake fluid flows out from the connecting coupler, place a drain pan under the vehicle.
5. Remove lock bolt (3).
6. Remove guide bolt (2).



7. Remove caliper assembly.
8. Remove support bracket with pad assembly and take care not to damage the flexible brake hose when removing the support bracket.
9. Remove pad assembly with shim and mark the lining locations if they are to be reinstalled.


306RW008

306RW009


10. Remove clip.

Installation

1. Install clip (4).



2. Apply special grease (approximately 0.2 g) to both contacting surfaces of the inner shims (5). Wipe off extruded grease after installing. Install pad assembly with shim.




Legend

- (5) Inner Shim
- (6) Wear indicator

3. Install support bracket and tighten the bolt (7) to the specified torque.


Torque: 103 N·m (76 lb ft)



4. Install caliper assembly.

5. Install lock bolt and guide bolt (8) and tighten the bolt to the specified torque.


Torque: 44 N·m (32 lb ft)



6. Install brake flexible hose, always use new gaskets and be sure to put the hooked edge of the flexible hose end into the anti-rotation cavity then tighten the eye-bolt (9) to the specified torque.

Torque: 35 N·m (26 lb ft)


5C-50 POWER-ASSISTED BRAKE SYSTEM



7. Install the wheel and tire assembly, referring to "Wheels and Tires System" in Section 3E.
8. Bleed brakes. Refer to "Hydraulic Brakes" in this section.

Rear Disc Brake Caliper (4×4 Model)

Rear Disc Brake Caliper Disassembled View




Legend

- | | |
|----------------------|---|
| (1) Guide Bolt | (5) Piston Seal |
| (2) Lock Bolt | (6) Piston |
| (3) Bleeder with Cap | (7) Dust Boot: Piston |
| (4) Caliper Body | (8) Dust Boot Ring |
| | (9) Dust Boot: Guide Bolt and Lock Bolt |

306RW014

Disassembly


1. Remove guide bolt.
2. Remove lock bolt.
3. Remove dust boot; guide bolt and lock bolt.
4. Remove dust boot ring, using a small screwdriver.



5. Insert a block of wood into the caliper and force out the piston by blowing compressed air into the caliper at the flexible hose attachment. This procedure must be done prior to removal of the dust boot. Remove piston.

WARNING: DO NOT PLACE YOUR FINGERS IN FRONT OF THE PISTON IN AN ATTEMPT TO CATCH OR PROTECT IT WHEN APPLYING COMPRESSED AIR. THIS COULD RESULT IN PERSONAL INJURY.

CAUTION: Use just enough air to ease the piston out of the bore. If the piston is blown out, it may be damaged.



6. Remove dust boot: piston.
7. Remove piston seal.
8. Remove bleeder with cap.
9. Remove caliper body.

Inspection and Repair

Make necessary parts replacement, if wear, damage, corrosion or any other abnormal conditions are found through inspection.

Check the following parts:

- ☐ Rotor
- ☐ Cylinder body
- ☐ Cylinder bore
- ☐ Piston
- ☐ Guide bolt, lock bolt
- ☐ Support bracket


NOTE: The piston dust seal and dust boot are to be replaced each time the caliper is overhauled. Discard these used rubber parts and replace with new ones.

Reassembly

1. Install caliper body.
2. Install bleeder with cap and tighten the cap to the specified torque.


Torque: 8 N·m (69 lb ft)

3. Install piston seal and apply special rubber grease to the piston seal and cylinder wall, then insert the piston seal into the cylinder. The special rubber grease is included in the repair kit.




4. When inserting the piston into the cylinder, use finger pressure only and do not use a mallet or other impact tool, since damage to the cylinder wall or piston seal can result. Install piston.


5C-52 POWER-ASSISTED BRAKE SYSTEM



5. Apply special grease (approximately 1g) to the piston and attach the dust boot to the piston and caliper. Insert the dust boot ring into the dust boot.



6. Install guide bolt and lock bolt dust boot.
7. Install the dust boot on the support bracket after applying special grease (Approx. 1g) onto the dust boot inner surface. Also apply special grease onto the lock bolt and guide bolt setting hole of the support bracket.




8. Install lock bolt and guide bolt and tighten the bolt to the specified torque.

Torque: 44 N·m (32 lb ft)

Main Data and Specifications (4×4 Model)**General Specifications**


Type	Floating, pin slide
Pad dimension	33 cm ² (5.11 in ²)
Adjusting method	Self-adjusting
Piston diameter	41.3 mm (1.63 in)
Disc type	Ventilated
Disc thickness	18 mm (0.71 in)
Disc effective diameter	269.2 mm (10.60 in)

Torque Specifications

E05RW005

Brake Lining

Brake Lining and Associated Parts



305RW001


Legend

- | | |
|--|---------------------------------|
| (1) Wheel and Tire Assembly | (9) Upper (inner) Return Spring |
| (2) Drum | (10) Auto Adjuster Lever |
| (3) Hold-down Spring and Cup | (11) Parking Brake Lever |
| (4) Hold-down Spring and Cups | (12) Adjuster Assembly |
| (5) Lower Return Spring | (13) Wave Washer |
| (6) Upper (other) Return Spring | (14) Retainer |
| (7) Trailing Shoe Assembly with Parking Brake Lever | (15) Hold-down Pin |
| (8) Leading Shoe Assembly with Upper (inner) Return Spring | (16) Hold-down Pin |

Removal

1. Raise the vehicle and support with suitable safety stands.
2. Remove wheel and tire assembly (1).
 - Refer to "Wheel and Tires" in Wheel and Tire System section.
3. Remove Drum (2).
 - If difficulty is encountered in removing the drum:
 - Mark the position of the drum to the axle.
 - Make sure the parking brake is released.
 - Use a rubber mallet to tap gently on the outer rim of the drum and/or around the inner drum. Be careful to avoid damaging the drum.
4. Remove upper (other) return spring (6) and auto adjuster lever.
5. Remove lower return spring (5).
6. Remove hold-down spring and cups (4) and hold-down pin (15).
7. Remove adjuster assembly (12)
8. Remove leading shoe assembly (8) with upper (inner) return spring (9).

NOTE: Do not over stretch the return spring.



305RS003

9. Remove upper (inner) return spring (9).
10. Remove hold-down spring and cup (3) and hold-down pin (16).
11. Remove Trailing shoe assembly (7) with parking brake lever (16).
12. Remove parking brake cable from parking brake lever (11).
13. Remove retainer (14), wave washer (13), and parking brake lever (11).


Brake Lining Inspection

Check the shoe assemblies for wear by removing brake drum.

Replace the shoe assemblies, if lining thickness is less than 1.0 mm (0.039 in).

The shoe assemblies have a wear indicator that makes a noise when the linings wear to a degree where replacement required.


Minimum limit: 1.0 mm (0.039 in)



305RS001

Installation

1. Apply grease lightly to back place A.




305RW002

Legend

- (1) Place A (3 portions for each side)

2. Install parking brake lever (11), wave washer (13), and retainer (14).
3. Install trailing shoe assembly (7) with parking brake lever (16).
4. Install the parking brake cable to parking brake lever (11).
5. Install hold-down pin (16) and hold-down spring and cup (3).
6. Install upper (inner) return spring (9).
7. Install leading shoe assembly (8) with upper (inner) return spring (9).

NOTE: Do not over stretch the return spring.



305RS003

8. Install adjuster assembly (12).
9. Install hold-down pin (15) and hold-down spring and cups (4).

10. Install lower return spring (5).
○Use brake spring tool.
11. Install auto adjuster lever (10).
12. Install upper (outer) return spring (6).
○Use brake spring tool.
13. Install brake drum (2).
○Adjust the brakes, refer to the "Drum Brake Adjustment" in this section.
14. Install wheel and tire assembly (1).
○Refer to "Wheels and Tires" in wheel and Tire System section.

Drum Brake Adjustment (4×2 Model)

NOTE: All brakes are self-adjusting. Brakes are adjusted by repeated stepping on the brake pedal. (After stepping on the pedal and releasing it, the rear auto adjuster, in the rear brake, produces a clicking sound.

The same operation should be repeated until the sound disappears.)

Take the following steps after overhauling the rear brake assembly.

1. Move the parking brake handle to its fully released position.
2. Parking cable must be loosened sufficiently. (Loosen the adjust nut and the lock nut.)
3. Repeat stepping on the brake pedal firmly, and releasing it until the clicking sound can no longer be heard.
If the difference between the brake drum inside diameter and diameter of the brake shoes is adjusted to be 0,5 mm, the number of times for depressing the brake pedal can be reduced.

4. Remove the drum. Measure the brake drum inside diameter and diameter of the brake shoes.

Shoe clearance: 0.25-0.4 mm (0.0098-0.0157 in)

If incorrect, check the brake auto-adjusting system.

5. Rotate the adjust nut until all slack disappears from the cable. Set the adjust nut.
6. Applying about 30 kg (66 lb) of force, pull the parking brake handle to its fully set position three or four times.
7. If the parking brake is properly adjusted, the travel between the fully disengaged position and the fully engaged position will be between 9 and 11 notches. If the traveling range is not within these limits, again repeat steps 1 through 5.

After adjusting has been done, check to see if the rear wheel rotates smoothly without drag when turned by hand.

Servicing The Brake Drum

Whenever the brake drums are removed, they should be thoroughly cleaned and inspected for cracks, scores, deep grooves and out-of-round.

Cracked, Scored or Grooved Drum

A cracked drum is unsafe for further service and must be replaced.

Do not attempt to weld a cracked drum.


Smooth any slight scores. Heavy or extensive scoring will cause excessive brake lining wear, and it will probably be necessary to machine the drum braking surface.

If the brake linings are slightly worn and the drum is grooved, the drum should be polished with fine emery cloth but should not be machined. At this stage, eliminating all the grooves in the drum and smoothing the ridges on the lining would require the removal of too much metal and lining. If left alone, the grooves and ridges match and satisfactory service can be obtained. If brake linings are to be replaced, a grooved drum should be machined. A grooved drum, if used with a new lining, will not only wear the lining, but will make it difficult, it not impossible, to obtain efficient brake performance.

Out-Of-Round Drum

An out-of-round drum makes accurate brake shoe adjustment impossible and is likely to cause excessive wear to other parts of the brake mechanism due to its eccentric action. An out-of-round drum can also cause severe and irregular tire tread wear as well as a pulsing brake pedal. When the braking surface of a brake drum exceeds the specification limit of 0.15 mm (0.006 in) in out-of-round, the drum should be machined to true up the braking surface. Out-of-round can be accurately measured with an inside micrometer fitted with proper extension rods. When measuring a drum for out-of-round and wear, take measurements at the open and closed edges of machines surfaces and at right angles to each other.

Maximum out-of-round: 0.15 mm (0.006 in)



420RS034

Machining The Drum

If a drum is to be machined, only enough metal should be removed to obtain a true, smooth braking surface. If a drum does not clean-up when machined to a maximum diameter, it must be replaced. Removal of more metal will


affect dissipation of heat and may cause distortion of the drum.

After refinishing, replace any drum that exceeds a maximum inside diameter of 296.5 mm (11.673 in). Do not use a brake drum that is not within the specification.

Maximum inside diameter: 296.5 mm (11.673 in)

Wheel Cylinder Assembly (4×2 Model)

Wheel Cylinder Assembly and Associated Parts



305RW003

Legend

- (1) Brake Linings
- (2) Wheel Cylinder

- (3) Bolts
- (4) Brake Pipe

Removal

1. Remove brake linings (1).
 - Refer to "Brake Lining and Associated Parts" in this section.
2. Remove brake pipe (4).
 - Plug the opening in the line to prevent fluid loss and contamination.
3. Remove bolts (3) and wheel cylinder (2).


Installation

1. Install wheel cylinder (2) and tighten bolts (3) to the specified torque.

Torque: 10 N·m (8 lb ft)
2. Install brake pipe (4) and tighten the nut to the specified torque.

Torque: 16 N·m (12 lb ft)
3. Install brake linings (1).
 - Refer to "Brake Lining Replacement" in this section.
 - Bleed brake system. Refer to "Hydraulic Brake" in this section.

Disassembled View



Legend

- (1) Boot
- (2) Piston Assembly
- (3) Piston Cup
- (4) Return Spring
- (5) Bleeder
- (6) Wheel Cylinder

Disassembly

1. Remove boot (1) and piston assembly (2).
2. Remove piston cup (3) from piston assembly (2).
3. Remove return spring (4) and bleeder (5) from wheel cylinder (6).


Inspection and Repair

1. Make necessary parts replacement if wear, damage, corrosion or any other abnormal condition are found through inspection.
Check the following parts;
 - ☐ Wheel cylinder body
 - ☐ Cylinder bore
 - ☐ Piston
 - ☐ Return spring
 - ☐ Bleeder

NOTE: Replace the piston cups and boots each time the wheel cylinder is overhauled. Discard these used rubber parts and replace with new ones.


Reassembly

1. Lubricate the cylinder bore with clean rubber grease.




2. Install bleeder (5) to wheel cylinder (6).

Torque: 10 N·m (8 lb ft)



3. Install new piston cups (3) on each piston so that the flared end of the cups are turned to the inboard side of the pistons.

Attach the return spring (4) and the boot (1) to the piston.




4. Apply DELCO silicone lube No. 5459912 (or equivalent) to the piston and the inner face of the boots.
5. Install piston assembly (2) to wheel cylinder (6).

Main Data and Specifications

General Specifications

Rear drum brake	
Type	Leading-trailing, non-servo
Drum inside diameter	295 mm (11.6 in)
Wheel cylinder diameter	25.4 mm (1 in)

Torque Specifications



E06RW010

BRAKES

PARKING BRAKE SYSTEM (4×4 Model)

CONTENTS

Service Precaution	5D1-1	Parking Brake Rear Cable	5D1-4
General Description	5D1-1	Parking Brake Rear Cable and	
Operation	5D1-2	Associated Parts	5D1-4
Parking Brake Lever and Front Cable	5D1-3	Removal	5D1-5
Parking Brake Lever Assembly and		Installation	5D1-5
Associated Parts	5D1-3	Inspection and Repair	5D1-6
Removal	5D1-3	Parking Brake Adjustment	5D1-6
Installation	5D1-3	Main Data and Specifications	5D1-7

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fasteners joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fasteners. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description


Pulling up the parking brake lever by hand will set the parking brake. By means of a ratchet type lock, the lever can be held in that position until it is released. The position of the lever is transmitted through cable/lever systems to the rear wheels. These parts are designed to obtain sufficient braking force even when parking on slopes. When the parking brake is set, or when the ignition SW is in the "ON" position, the brake warning light illuminates. The rear wheel parking brake is a duo-servo brake (mechanical inside expansion type) built in the rear disc brake. Parking brake adjustment is made through the adjusting hole (bored through back plate). Parking brake lever stroke should be adjusted to 6-8 notches. Refer to "Parking Brake Adjustment" in this section.

5D1-2 PARKING BRAKE SYSTEM (4x4 Model)

Operation

When pulled in the direction "A", the parking lever presses the secondary shoe against the brake drum using the lever/shoe joint "B" as a fulcrum and pushes the strut in the direction "C". The strut, in turn, presses the primary shoe against the brake drum. Counter force "D" to the

primary shoe is transmitted again to the secondary shoe through the fulcrum "B". The secondary shoe contacts the drum thereby producing braking effect. Clearance which may result from worn parking brake shoe lining can be adjusted by turning the adjusting screw. Refer to "Parking Brake Adjustment" in this Section.




A05RS002

Legend

- | | |
|---------------------------------------|--------------------------------|
| (1) Direction "A" | (8) Parking Cable Guide |
| (2) Lever/Shoe Joint "B" as a fulcrum | (9) Primary Shoe |
| (3) Direction "C" | (10) Strut |
| (4) Counter Force "D" | (11) Shoe Expanding Direction |
| (5) Parking Lever | (12) Parking Brake Cable Guide |
| (6) Secondary Shoe | (13) Adjusting Hole Plug |
| (7) Adjusting Screw Notch | (14) Adjusting Screw Notch |

Parking Brake Lever and Front Cable

Parking Brake Lever Assembly and Associated Parts



311RW008

Legend

- | | |
|-----------------------------|------------------------------|
| (1) Rear Console | (5) Trunnion Pin |
| (2) Switch Connector | (6) Equalizer |
| (3) Bolt | (7) Parking Brake Rear Cable |
| (4) Adjust Nut and Lock Nut | (8) Parking Brake Lever |

Removal

1. Remove rear console (1).
○Refer to Body and Accessories section.
2. Disconnect switch connector (2).
3. Remove bolt (3).
4. Remove adjust nut and lock nut (4).
5. Pull out equalizer (6) from trunnion pin (5).
6. Disconnect trunnion pin (5) from Parking brake lever (8).
7. Disconnect parking brake rear cable (7).

Installation

1. Apply grease (BESCO L-2 or equivalent) to the connecting portion of the rear cable (7) and equalizer (6).
2. Connect parking brake rear cable (7) to equalizer
3. Install trunnion pin (5) to parking brake lever (8).
4. Insert equalizer (6) into trunnion pin (5) and tighten adjust nut and lock nut (4).
○To adjust the parking brake lever, see "Parking Brake Adjustment" in this section.

Lock Nut Torque: 13 N·m (113 lb in)


5. Tighten the parking brake lever fixing bolt (3) to the specified torque.

Torque: 15 N·m (11 lb ft)

6. Connect switch connector (2).
7. Install rear console (1).
○Refer to Body and Accessories section.

Parking Brake Rear Cable

Parking Brake Rear Cable and Associated Parts




Legend

- | | |
|-------------------------|--|
| (1) Rear Wheels | (8) Cable Fixing Bolt |
| (2) Caliper Assembly | (9) Bolt |
| (3) Rotor (Drum) | (10) Bolt |
| (4) Holding Spring | (11) Bolt (Only Long Wheel Base Model) |
| (5) Upper Return Spring | (12) Nut |
| (6) Lower Return Spring | (13) Nut |
| (7) Shoe Assembly | (14) Retainer |
| | (15) Rear Cable |

311RW010

Removal

1. Remove rear wheels (1).
2. Remove 2 bolts to remove the caliper assembly (2) from the support bracket. Refer to "Rear Disc Brakes" in Power Assisted Brake System section. Temporarily hang the caliper with wire etc.
3. Remove rotor (drum) (3).
4. Remove holding spring (4), upper return spring (5) and lower return spring (6).
5. Previously remove the rear cable from the parking brake lever, then remove the brake shoe assembly (7).



Legend

- (1) Parking Brake Lever

6. Remove cable fixing bolt (8) and bolt (9) (10) (11).
7. Remove nut (12).
8. Remove nut (13) and retainer (14).
9. Remove rear cable (15).

Installation

1. Apply grease (BESCO L-2 or equivalent) to the connecting portion of the rear cable and equalizer. Install rear cable (15).
2. Install retainer (14).
 - Tighten nut (13) to the specified torque.


Torque: 41N·m (30lb ft)
3. Tighten nut (12) to the specified torque.
4. Tighten bolt (11) (10) (9) to the specified torque.
 - To adjust the parking brake, refer to "Parking Brake Adjustment" in this section.

Torque: 15N·m (11lb ft)
5. Tighten the cable fixing bolt (8) to the specified
 - To adjust the parking brake, refer to "Parking Brake Adjustment" in this section.

Torque: 6.5N·m (57lb in)


6. Install shoe assembly (7).

After installation of the shoe and cable assembly, apply special grease (included in the repair kit) to the following portions indicated in the figure.



7. Install lower return spring (6) and upper return spring (5).

The parking brake lever side (secondary side) return spring must be installed on the outer side of the primary side return spring.



Legend

- (1) Outer Side
(2) Parking Lever

8. Install holding spring (4).
9. Install rotor (drum) (3).
10. Install caliper assembly (2).
11. Install rear wheels (1).

5D1-6 PARKING BRAKE SYSTEM (4x4 Model)


Inspection and Repair

Parking Brake Lining Inspection

Check the shoe assemblies for wear by removing the brake drum.

Replace the shoe assemblies if the lining thickness is less than 1.0 mm (0.039 in).

Minimum limit: 1.0 mm (0.039 in)



Parking Brake Rotor (Drum) Inspection

Refer to "Rear Disc Brakes" in Power-Assisted Brake System section for inspection procedure of the rotor (drum).

Parking Brake Adjustment

1. Prior to lever stroke adjustment, adjust rear brake shoe/rotor (drum) gap. Perform this procedure with loosening the adjust nut of the hand brake lever.
2. Remove the adjusting hole plug (rubber) and turn the shoe adjusting screw downward with a small screwdriver so that shoes will expand until they get into close touch with the rotor. (Turn down the adjusting screw notch by notch until the rotor does not turn.)
3. Turn the adjusting screw in the opposite direction (upward) until the rotor can be turned lightly. Standard number of notches to turn upward: 7 or 8
Turn the rotor and make sure that there is no brake dragging.
4. After the rear brake shoe/rotor (drum) gap has been adjusted, perform parking brake cable adjustment.
5. Turn the adjusting nut so that the parking brake lever travels 6–8 notches when pulled up with a force of 30 kg (66 lb).
6. Make sure there is no brake dragging. Then tighten the cable lock nut

Torque : 13 N·m (113 lb in)

7. When poor braking effect possibly resulting from insufficient break-in is felt, or just after replacement of parking brake shoe, be sure to conduct break-in as follows:

8. Forward 50 km/h (30 mph) × 400 m (About 30 seconds) with a lever pull force of 15 kg (33 lb).
9. Backward 10 km/h (6 mph) × 50 m (About 18 seconds) with a lever pull force of 15 kg (33 lb).

NOTE: Break-in procedures must be performed under safe conditions and traffic rules.


- If braking effect still remains poor after the above break-in, wait for some time until parking brake shoe cools down and repeat the procedures 8. and 9. noted above.
- On completion of break-in, inspect parking brake lever stroke, and if the lever does not come within the specified number of notches when pulled up, readjust.
- Excessive break-in may cause premature wear of the parking brake lining.

Main Data and Specifications

General Specifications

	Model
Type	Duo-servo
Drum inside diameter	210 mm(8.27 in)
Parking brake lever stroke	6-8 notches When pulled with a force of 30 kg (66 lb)

Torque Specifications



RODEO

BRAKES

PARKING BRAKE SYSTEM (4×2 Model)

CONTENTS

Service Precaution	5D2-1	Parking Brake Rear Cable	5D2-3
General Description	5D2-1	Parking Brake Rear Cable and	
Parking Brake Lever	5D2-2	Associated Parts	5D2-3
Parking Brake Lever Assembly and		Removal	5D2-4
Associated Parts	5D2-2	Installation	5D2-4
Removal	5D2-2	Parking Brake Adjustment	5D2-4
Installation	5D2-2	Main Data and Specifications	5D2-5

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.


CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

Pulling up the parking brake lever by hand will set the parking brake. By means of a ratchet type lock, the lever can be held in that position until it is released. The position of the lever is transmitted through cable/lever systems to the rear wheels. These parts are designed to obtain sufficient braking force even when parking on slopes. When the parking brake is set, or when the ignition SW is in the "ON" position, the brake warning light illuminates. The rear wheel parking brake is a leading/trailing brake (mechanical inside expansion type). Parking brake adjustment is made through the adjusting hole (bored through back plate). Parking brake lever stroke should be adjusted to 6 notches. Refer to "Parking Brake Adjustment" in this section.

Parking Brake Lever

Parking Brake Lever Assembly and Associated Parts



Legend

- | | |
|-----------------------------|------------------------------|
| (1) Rear Console | (5) Trunnion Pin |
| (2) Switch Connector | (6) Equalizer |
| (3) Bolt | (7) Parking Brake Rear Cable |
| (4) Adjust Nut and Lock Nut | (8) Parking Brake Lever |

Removal

1. Remove rear console (1).
○Refer to Body and Accessories section.
2. Disconnect switch connector (2).
3. Remove bolt (3).
4. Remove adjust nut and lock nut (4).
5. Pull out equalizer (6) from trunnion pin (5).
6. Disconnect trunnion pin (5) from parking brake lever (8).
7. Disconnect parking brake rear cable (7).

Installation

1. Apply grease (BESCO L-2 or equivalent) to the connecting portion of the rear cable (7) and equalizer (8).
2. Connect parking brake rear cable (7) to equalizer (6).
3. Install trunnion pin (5) to parking brake lever (8).
4. Insert equalizer (6) into trunnion pin (5) and tighten adjust nut and lock nut (4).
○To adjust the parking brake lever, see "Parking Brake Adjustment" in this section.

Lock Nut Torque: 13 N·m (113 lb in)


5. Tighten parking lever fixing bolt (3) to the specified torque.

Torque: 15 N·m (11 lb ft)

6. Connect switch connector (2).
7. Install rear console (1).
○Refer to Body and Accessories section.

Parking Brake Rear Cable

Parking Brake Rear Cable and Associated Parts




311RW011

Legend

- | | |
|-------------------|--|
| (1) Rear Wheels | (5) Clip and Bolt (Only Long Wheel Base Model) |
| (2) Drums | (6) Nut |
| (3) Clip and Bolt | (7) Nut |
| (4) Clip and Bolt | (8) Retainer |
| | (9) Rear Cable |

Removal

1. Remove rear wheels (1) and drums (2).
2. Remove bolt (3) (4) (5).
3. Remove nut (6).
4. Remove nut (7) and retainer (8).
5. Remove rear brake shoe assemblies. Refer to "Brake Lining Assembly and Associated Parts" in Power Assisted Brake System section.
6. Use offset box wrench (13 mm hex.) to compress the locking lugs on the cable, then remove the rear cable (9) from the Backing plate.



Legend

- (1) Offset Box Wrench

Installation

1. Install rear cable (9).
2. Install retainer (8).
3. Tighten nut (7) to the specified torque.
Torque : 41 N·m (30 lb ft)
○To adjust the parking brake, refer to "Parking Brake Adjustment" in this section.
4. Tighten nut (6) to the specified torque.
Torque : 15 N·m (11 lb ft)
5. Tighten bolt (5) (4) (3) to the specified torque.
Torque : 6.5 N·m (57 lb in)
6. Install rear drums (2) and wheels (1).

Parking Brake Adjustment

NOTE: All brakes are self adjusting. Brakes are adjusted by repeated stepping on the brake pedal. (After stepping on the pedal and releasing it, the rear auto-adjuster, in the rear brake, produces a clicking sound. The same operation should be repeated until the sound disappears.)

Take the following steps after overhauling the rear brake assembly.

1. Move the parking brake lever to its fully released position.
2. Parking cable must be loosened sufficiently. (Loosen the adjust nut and the lock nut.)
3. Repeat stepping on the brake pedal firmly, and releasing it until the clicking sound can no longer be heard.

If the difference between the brake drum inside diameter and diameter of the brake shoes is adjusted to be 0.5 mm, the number of times for depressing the brake pedal can be reduced.

4. Remove the drum. Measure the brake drum inside diameter and diameter of the brake shoes.

Shoe clearance: 0.25 mm to 0.40 mm

(0.0098 in to 0.0157 in)

If incorrect, check the brake auto-adjusting system.

5. Rotate the adjust nut of hand brake lever until all slack disappears from the cable. Set the adjust nut.
6. Applying about 30 kg (66 lb) of force, pull the parking brake lever to its fully set position three or four times.
7. If the parking brake is properly adjusted, the travel between the fully disengaged position and the fully engaged position will be 6 notches.

If the traveling range is not within these limits, repeat steps 1 through 5 again .


After adjusting has been done, check to see if the rear wheel rotates smoothly without drag when turned by hand.

Main Data and Specifications

General Specifications

	Model
Type	Leading-Trailing
Drum inside diameter	295 mm (11.6 in)
Parking brake lever stroke	6-8 notches When pulled with a force of 30 kg (66 lb)

Torque Specifications



E05RW012

RODEO

ENGINE

CONTENTS

Engine Mechanical	6A-1	Driveability and Emissions	6E1-1
Engine Cooling	6B-1	Engine Exhaust	6F-1
Engine Fuel	6C-1	Engine Lubrication	6G-1
Engine Electrical	6D1-1	Engine Speed Control System	6H-1
Ignition System	6D2-1	Induction	6J-1
Starting and Charging System	6D3-1		

ENGINE MECHANICAL (X22SE 2.2L)

CONTENTS

Service Precaution	6A-2	Disassembly	6A-42
General Description	6A-2	Inspection and Repair	6A-43
Engine Diagnosis	6A-3	Reassembly	6A-44
Cylinder Head Cover	6A-16	Camshaft	6A-45
Removal	6A-16	Camshaft and Associated Parts	6A-45
Installation	6A-17	Disassembly	6A-45
Exhaust Manifold	6A-18	Reassembly	6A-46
Removal	6A-18	Crankshaft	6A-47
Installation	6A-18	Crankshaft and Associated Parts	6A-47
Crankshaft Pulley	6A-19	Disassembly	6A-47
Removal	6A-19	Inspection and Repair	6A-48
Installation	6A-19	Inspection and Repair	6A-49
Intake Manifold	6A-20	Reassembly	6A-50
Removal	6A-20	Piston and Connecting Rod	6A-53
Installation	6A-21	Piston, Connecting Rod and Associate Parts	6A-53
Cylinder Head Assembly	6A-22	Disassembly	6A-53
Removal	6A-22	Inspection and Repair	6A-54
Installation	6A-24	Reassembly	6A-56
Timing Belt	6A-28	Cylinder Block	6A-57
Removal	6A-28	Cylinder Block and Associated Parts	6A-57
Installation	6A-29	Disassembly	6A-58
Camshaft	6A-32	Inspection and Repair	6A-58
Removal	6A-32	Reassembly	6A-59
Installation	6A-33	Cylinder Head Cover	6A-60
Engine Assembly	6A-35	Cylinder Head Cover and Associated parts	6A-60
Removal	6A-36	Removal	6A-61
Installation	6A-37	Installation	6A-61
Cylinder Head	6A-39	Balance Unit Assembly	6A-63
Cylinder Head and Associated Parts	6A-39	Balance Unit Assembly Associated Parts	6A-63
Disassembly	6A-39	Disassembly	6A-64
Inspection and Repair	6A-40	Adjustment	6A-64
Reassembly	6A-41	Reassembly	6A-66
Valve Spring, Valve, Valve Guide	6A-42	Main Data and Specifications	6A-68
Valve Spring, Valve, Valve Guide and Associated Parts	6A-42	Special Tools	6A-73

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

Engine Cleanliness And Care

An automobile engine is a combination of many machined, honed, polished and lapped surfaces with tolerances that are measured in the thousandths of a millimeter (ten thousandths of an inch). Accordingly, when any internal engine parts are serviced, care and cleanliness are important. Throughout this section, it should be understood that proper cleaning and protection of machined surfaces and friction areas is part of the repair procedure. This is considered standard shop practice even if not specifically stated.

- A liberal coating of engine oil should be applied to all friction areas during assembly to protect and lubricate the surfaces on initial operation.
- Whenever valve train components, pistons, piston rings, connecting rods, rod bearings, and crankshaft journal bearings are removed for service, they should be retained in order.
- At the time of installation, they should be installed in the same locations and with the same mating surfaces as when removed.
- Battery cables should be disconnected before any major work is performed on the engine. Failure to disconnect cables may result in damage to wire harness or other electrical parts.
- The four cylinders of this engine are identified by numbers; cylinders 1, 2, 3 and 4, as counted from crankshaft pulley.

General Information on Engine Service

The following information on engine service should be noted carefully, as it is important in preventing damage and contributing to reliable engine performance:

- When raising or supporting the engine for any reason, do not use a jack under the oil pan. Due to the small clearance between the oil pan and the oil pump strainer, jacking against the oil pan may cause damage to the oil pick up unit.
- The 12-volt electrical system is capable of damaging circuits. When performing any work where electrical terminals could possibly be grounded, the ground cable of the battery should be disconnected at the battery.
- Any time the intake air duct or air cleaner is removed, the intake opening should be covered. This will protect against accidental entrance of foreign material into the cylinder which could cause extensive damage when the engine is started.

Cylinder Block

The cylinder block is made of cast iron. The crankshaft is supported by five bearings. The bearing cap is made of nodular cast iron.

Cylinder Head

The cylinder head is made of aluminum alloy casting with a spark plug in the center.

Valve Train

Valve system is direct-acting inverted bucket tappet. The valves clearance adjustment are hydraulic. Hydraulic valve lash adjustment, no adjustment necessary.

Intake Manifold

The intake manifold is made of aluminum alloy.

Exhaust Manifold

The exhaust manifold is made of high Si-Mo nodular iron.

Pistons and Connecting Rods

Aluminum pistons are used after selecting the grade that meets the cylinder bore diameter. Each piston has two compression rings and one oil ring. The piston pin is made of case-hardened steel. The connecting rods are made of cast iron. The connecting rod bearings are made of steel backed with babbitt metal.

Crankshaft and Bearings

The crankshaft is made of nodular cast iron. Pins and journals are graded for correct size selection for their bearing.

Balance Shaft

Type is lanchester (twin counter-rotating shafts). The balance shafts are made of cast iron and gears are hard faced. The housing is made of cast iron. Backlash adjustment method is shim-balancer housing to block (selective fit).

Engine Diagnosis

Hard Starting

1. Starting Motor Does Not Turn Over

Trouble Shooting Procedure

Turn on headlights and starter switch.

Condition	Possible cause	Correction
Headlights go out or dim considerably	Battery run down or under charged	Recharge or replace battery
	Terminals poorly connected	Clean battery posts and terminals and connect properly
	Starting motor coil circuit shorted	Overhaul or replace
	Starting motor defective	Overhaul or replace

2. Ignition Trouble — Starting Motor Turns Over But Engine Does Not Start

Spark Test

Disconnect a high tension cable from any spark plug. Connect the spark plug tester J-26792 (ST-125), crank the engine, and check if a spark is generated in the spark plug tester. Before cranking the engine, make sure that the spark plug tester is properly grounded. To avoid electrical shock, do not touch the high tension cable while the engine is running.

Condition	Possible cause	Correction
Spark jumps across gap	Spark plug defective	Clean, adjust spark gap or replace
	Ignition timing incorrect	Refer to Ignition System
	Fuel not reaching fuel injector(s) or engine	Refer to item 3 (Trouble in fuel system)
	Valve timing incorrect	Adjust
	Engine lacks compression	Refer to item 4 (Engine lacks compression)
No sparking takes place	Ignition coil disconnected or broken	Connect properly or replace
	Electronic Ignition System with module	Replace
	Poor connections in engine harness	Correct
	Powertrain Control Module cable disconnected or defective	Correct or replace

6A-4 ENGINE MECHANICAL (X22SE 2.2L)

3. Trouble In Fuel System

Condition	Possible cause	Correction
Starting motor turns over and spark occurs but engine does not start.	Fuel tank empty	Fill
	Water in fuel system	Clean
	Fuel filter clogged	Replace filter
	Fuel pipe clogged	Clean or replace
	Fuel pump defective	Replace
	Fuel pump circuit open	Correct or replace
	Evaporative Emission Control System circuit clogged	Correct or replace
	Multiport Fuel Injection System faulty	Refer to "Electronic Fuel Injection" section

4. Engine Lacks Compression

Condition	Possible cause	Correction
Engine lacks compression	Spark plug loosely fitted or spark plug gasket defective	Tighten to specified torque or replace gasket
	Valve timing incorrect	Adjust
	Cylinder head gasket defective	Replace gasket
	Valve incorrectly seated	Lap valve
	Valve stem seized	Replace valve and valve guide
	Valve spring weakened	Replace
	Cylinder or piston rings worn	Overhaul engine
	Piston ring seized	Overhaul engine.

Engine Compression Test Procedure

1. Start and run the engine until the engine reaches normal operating temperature.
2. Turn the engine off.
3. Remove all the spark plugs.
4. Remove ignition coil fuse (15A) and disable the ignition system.
5. Remove the fuel pump relay from the relay and fuse box.

6. Engage the starter and check that the cranking speed is approximately 300 rpm.
7. Install cylinder compression gauge into spark plug hole.
8. With the throttle valve opened fully, keep the starter engaged until the compression gage needle reaches the maximum level. Note the reading.
9. Repeat the test with each cylinder.
The pressure difference between the individual cylinders should not exceed 100 kPa (14.5 psi).

Rough Engine Idling or Engine Stalling

Condition	Possible cause	Correction
Trouble in fuel injection system	Idle air control valve defective	Replace
	Throttle shutting off incomplete	Correct or replace
	Throttle position sensor circuit open or shorted	Correct or replace
	Fuel injector circuits open or shorted	Correct or replace
	Fuel injectors damaged	Replace
	Fuel pump relay defective	Replace
	Manifold Absolute Pressure Sensor cable disconnected or broken	Correct or replace
	Manifold Absolute Pressure Sensor defective	Replace
	Engine Coolant Temperature Sensor cable disconnected or broken	Correct or replace
	Engine Coolant Temperature Sensor defective	Replace
	Intake Air Temperature sensor cable disconnected or broken	Correct or replace
	Intake Air Temperature sensor defective	Replace
	Knock Sensor (KS) circuits open or shorted	Correct or replace
	KS defective	Replace
	KS Module circuits open or ground	Correct or replace
	KS Module defective	Replace
	Vehicle Speed Sensor circuit open or shorted	Correct or replace
	Vehicle Speed Sensor defective	Replace
Trouble in emission control system	Powertrain Control Module defective	Replace
	Exhaust Gas Recirculation Valve faulty	Replace
	Canister purge solenoid circuit open	Correct
	Canister purge solenoid defective	Replace
	Evaporative Emission Canister Purge control valve defective	Replace
	Trouble in ignition system	Refer to Hard Start Troubleshooting Guide
Others	Engine lacks compression	Refer to Hard Start Troubleshooting Guide
	Valve incorrectly seated	Lap valve
	Air Cleaner Filter clogged	Replace filter element
	Valve timing incorrect	Readjust
	Idle air control valve broken	Replace

Rough Engine Running

Condition	Possible cause	Correction
Engine misfires regularly	Ignition coil layer shorted	Replace
	Spark plugs fouling	Clean or install hotter type plug
	Spark plug(s) insulator nose leaking	Replace
	Fuel injector(s) defective	Replace
	Engine control module faulty	Replace
Engine knocks regularly	Spark plugs running too hot	Install colder type spark plugs
	Powertrain control module faulty	Replace
Engine lacks power	Spark plugs fouled	Clean
	Fuel injectors defective	Replace
	Manifold Absolute Pressure (MAP) Sensor or Manifold Absolute Pressure Sensor circuit defective	Correct or replace
	Engine Coolant Temperature Sensor or Engine Coolant Temperature Sensor circuit defective	Correct or replace
	Engine Control Module faulty	Replace
	Intake Air Temperature Sensor or Intake Air Temperature Sensor circuit defective	Correct or replace
	Throttle Position Sensor or Throttle Position Sensor circuit defective	Correct or replace
	Knock Sensor or Knock Sensor circuits defective	Correct or replace
	Knock Sensor Module or Knock Sensor Module circuits defective	Correct or replace

Hesitation

Condition	Possible cause	Correction
Hesitation on acceleration	Throttle Position Sensor adjustment incorrect	Replace throttle valve assembly
	Throttle Position Sensor circuit open or shorted	Correct or replace
	Excessive play in accelerator linkage	Adjust or replace
	Manifold Absolute Pressure (MAP) Sensor circuit open or shorted	Correct or replace
	MAP Sensor defective	Replace
	Intake Air Temperature (IAT) Sensor circuit open or shorted	Correct or replace
	Knock Sensor (KS) Circuit open or shorted	Correct or replace
	KS defective	Replace
	KS Module circuits open or shorted	Correct or replace
	KS Module defective	Replace
	IAT Sensor defective	Replace
Hesitation at high speeds (Fuel pressure too low)	Fuel tank strainer clogged	Clean or replace
	Fuel pipe clogged	Clean or replace
	Fuel filter clogged	Replace
	Defective fuel pump system	Check and replace
	Fuel Pressure Control Valve leaking	Replace
Hesitation at high speeds (Fuel injector not working normally)	Power supply or ground circuit for Multiport Fuel Injection System shorted or open	Check and correct or replace
	Cable of Multiport Fuel Injection System disconnected or defective	Correct or replace
Hesitation at high speeds	Engine Control Module defective	Replace
	Throttle Position Sensor circuit open or shorted	Correct or replace
	Throttle Position Sensor defective	Replace
	Engine Coolant Temperature Sensor circuit open or shorted	Correct or replace
	Engine Coolant Temperature Sensor defective	Replace
	MAP Sensor cable open or shorted	Correct or replace
	MAP Sensor defective	Replace
	IAT Sensor circuit open or shorted	Correct or replace
	IAT Sensor defective	Replace
	KS Circuit open or shorted	Correct or replace
	KS defective	Replace
	KS Module circuit open or shorted	Correct or replace
	KS Module defective	Replace
	Throttle valve not wide opened	Check and correct or replace
	Air Cleaner Filter clogged	Replace filter element
	Power supply voltage too low	Check and correct or replace

Engine Lacks Power

Condition	Possible cause	Correction
Trouble in fuel system	Fuel Pressure Control Valve not working normally	Replace
	Fuel injector clogged	Clean or replace
	Fuel pipe clogged	Clean
	Fuel filter clogged or fouled	Replace
	Fuel pump drive circuit not working normally	Correct or replace
	Fuel tank not sufficiently breathing due to clogged Evaporative Emission Control System circuit	Clean or replace
	Water in fuel system	Clean
	Inferior quality fuel in fuel system	Use fuel of specified octane rating
	Engine Control Module supplied poor voltage	Correct circuit
	Throttle Position Sensor cable disconnected or broken	Correct or replace
	Throttle Position Sensor defective	Replace
	Manifold Absolute Pressure Sensor not working normally	Replace
	Intake Air Temperature Sensor not working normally	Replace
	Engine Coolant Temperature Sensor circuit open or shorted	Correct or replace
	Engine Coolant Temperature Sensor defective	Replace
	Engine Control Module defective	Replace
Trouble in intake or exhaust system	Air Cleaner Filter clogged	Replace filter element
	Air duct kinked or flattened	Correct or replace
Ignition failure	—————	Refer to Hard Start Troubleshooting Guide
	Heat range of spark plug inadequate	Install spark plugs of adequate heat range
	Electronic Ignition System with module	Replace

Condition	Possible cause	Correction
Engine overheating	Level of Engine Coolant too low	Replenish
	Thermo switch or fan motor defective	Replace
	Thermostat defective	Replace
	Engine Coolant pump defective	Correct or replace
	Radiator clogged	Clean or replace
	Radiator filler cap defective	Replace
	Level of oil in engine crankcase too low or wrong oil in engine	Change or replenish
	Resistance in exhaust system increased	Clean exhaust system or replace defective parts
	Throttle Position Sensor adjustment incorrect	Adjust Wide Open Throttle switch setting
	Throttle Position Sensor circuit open or shorted	Correct or replace
	Cylinder head gasket damaged	Replace
Engine overcooling	Thermostat defective	Replace (Use a thermostat set to open at 92°C (197.6°F))
Engine lacks compression	—————	Refer to Hard Start
Others	Tire inflation pressure abnormal	Adjust to recommend pressures
	Brake drag	Adjust
	Clutch slipping	Adjust or replace
	Level of oil in engine crankcase too high	Correct level of engine oil
	Exhaust Gas Recirculation Valve defective	Replace

Engine Noisy

Abnormal engine noise often consists of various noises originating in rotating parts, sliding parts and other moving parts of the engine. It is, therefore, advisable to locate the source of noise systematically.

Condition	Possible cause	Correction
Noise from crank journals or from crank bearings (Faulty crank journals and crank bearings usually make dull noise that becomes more evident when accelerating)	Oil clearance increased due to worn crank journals or crank bearings	Replace crank bearings and crankshaft or regrind crankshaft and install the over size bearing
	Crankshaft out of round	Replace crank bearings and crankshaft or regrind crankshaft and install the over size bearing
	Crank bearing seized	Crank bearing seized Replace crank bearings and crankshaft or regrind crankshaft and install the over size bearing

6A-10 ENGINE MECHANICAL (X22SE 2.2L)

Troubleshooting Procedure

Short out each spark plug in sequence using insulated spark plug wire removers. Locate cylinder with defective bearing by listening for abnormal noise that stops when spark plug is shorted out.

Condition	Possible cause	Correction
Noise from connecting rods or from connecting rod bearings (Faulty connecting rods or connecting rod bearings usually make an abnormal noise slightly higher than the crank bearing noise, which becomes more evident when engine is accelerated)	Bearing or crankshaft pin worn	Replace connecting rod bearings and crankshaft or regrind crankshaft and install the under size bearing
	Crankpin out of round	Replace connecting rod bearings and crankshaft or regrind crankshaft and install the under size bearing
	Connecting rod bent	Correct or replace
	Connecting rod bearing seized	Replace connecting rod bearings and crankshaft or regrind crankshaft and install the under size bearing

Troubleshooting Procedure

Abnormal noise stops when the spark plug on the cylinder with defective part is shorted out.

Condition	Possible cause	Correction
Piston and cylinder (Faulty piston or cylinder usually makes a combined mechanical thumping noise which increases when engine is suddenly accelerated but diminishes gradually as the engine warms up)	Piston clearance increased due to cylinder wear	Replace piston and cylinder body
	Piston seized	Replace piston and cylinder body
	Piston ring broken	Replace piston and cylinder body
	Piston defective	Replace pistons and others

Troubleshooting Procedure

Short out each spark plug and listen for change in engine noise.

Condition	Possible cause	Correction
Piston pin noise (Piston makes noise each time it goes up and down)	Piston pin or piston pin hole worn	Replace piston, piston pin and connecting rod assy

Troubleshooting Procedure

The slapping sound stops when spark plug on bad cylinder is shorted out.

Condition	Possible cause	Correction
Timing belt noise	Timing belt tension is incorrect	Replace pusher or adjust the tension pulley or replace timing belt
	Tensioner bearing defective	Replace
	Timing belt defective	Replace
	Timing wheels defective	Replace
	Timing belt comes in contact with timing cover	Replace timing belt and timing cover
Valve noise	Valve and valve guide seized	Replace valve and valve guide
	Valve spring broken	Replace
	Valve seat off-positioned	Correct
Crankshaft noise	Crankshaft end play excessive (noise occurs when clutch is engaged)	Replace thrust bearing
Engine knocking	Preignition due to use of spark plugs of inadequate heat range	Install Spark Plugs of adequate heat range
	Fuel too low in octane rating	Replace fuel
	Wide Open Throttle enrichment system failure	Refer to Section 6E
	Selection of transmission gear incorrect	Caution operator of incorrect gear selection
	Engine overheating	Refer to "Engine Lacks Power"
Others	Water pump defective	Replace
	Drive belt slipping	Adjust tension of drive belt or replace drive belt

Abnormal Combustion

Condition	Possible cause	Correction
Trouble in fuel injection system	Fuel pressure control valve defective	Replace
	Fuel filter clogged	Replace
	Fuel pump clogged	Clean or replace
	Fuel tank or fuel pipe clogged	Clean or replace
	Fuel injector clogged	Clean or replace
	Fuel pump relay defective	Replace
	Power supply cable for fuel pump loosely connected or defective	Reconnect, correct or replace
	Manifold Absolute Pressure Sensor circuit open or shorted	Correct or replace
	Manifold Absolute Pressure Sensor defective	Replace
	Engine Coolant Temperature (ECT) Sensor circuit open or shorted	Correct or replace
	ECT Sensor defective	Replace
	Throttle Position Sensor adjustment incorrect	Reconnect
	Throttle Position Sensor defective	Replace
	Throttle Position Sensor connector loosely connected	Reconnect
	Vehicle Speed Sensor cable loosely connected or defective	Correct or replace
	Vehicle Speed Sensor loosely fixed	Fix tightly
	Vehicle Speed Sensor in wrong contact or defective	Replace
	Engine Control Module cable loosely connected or defective	Correct or replace
Trouble in emission control system	Heated Oxygen Sensor circuit open	Correct or replace
	Heated Oxygen Sensor defective	Replace
	Signal vacuum hose loosely fitted or defective	Correct or replace
	Exhaust Gas Recirculation Valve defective	Replace
	ECT Sensor circuit open or shorted	Correct or replace
	ECT Sensor defective	Replace
	Evaporator system	Refer to Section 6E
Trouble in ignition system	—————	Refer to "Engine Lacks Power"
Trouble in cylinder head parts	Carbon deposits in combustion chamber	Remove carbon
	Carbon deposit on valve, valve seat and valve guide	Remove carbon

Engine Oil Consumption Excessive

Condition	Possible cause	Correction
Oil leaking	Oil pan drain plug loose	Retighten or replace gasket
	Oil pan setting bolts loosened	Retighten
	Oil pan gasket broken	Replace gasket
	Front cover retaining bolts loose or gasket broken	Retighten or replace gasket
	Head cover retaining bolts loose or gasket broken	Retighten or replace gasket
	Oil filter adapter cracked	Replace
	Oil filter attachings bolt loose or rubber gasket broken	Retighten or replace oil filter
	Crankshaft front or rear oil seal defective	Replace oil seal
	Oil pressure unit loose or broken	Retighten or replace
	Blow-by gas hose broken	Replace hose
	Engine/Transmission coupling area	Replace oil seal
Oil leaking into combustion chambers due to poor seal in valve system	Valve stem oil seal defective	Replace
	Valve stem or valve guide worn	Replace valve and valve guide
Oil leaking into combustion chambers due to poor seal in cylinder parts	Cylinders and pistons worn excessively	Rebore cylinder and replace pistons and others
	Piston ring gaps incorrectly positioned	Correct
	Piston rings set with wrong side up	Correct
	Piston ring sticking	Rebore cylinder and replace pistons and others
	Piston ring and ring groove worn	Replace pistons and others
	Return ports in oil rings clogged	Clean piston and replace rings
Crank case ventilation, Positive Crankcase Ventilation System malfunctioning	Positive Crankcase Ventilation Hose clogged	Clean
Others	Improper oil viscosity	Use oil of recommended S.A.E. viscosity
	Continuous high speed driving and/or severe usage such as trailer towing	Continuous high speed operation and/or severe usage will normally cause increased oil consumption

Fuel Consumption Excessive

Condition	Possible cause	Correction
Trouble in fuel system	Mixture too rich or too lean due to trouble in fuel injection system	Refer to "Abnormal Combustion"
	Fuel cut function does not act	Refer to "Abnormal Combustion"
Trouble in ignition system	Misfiring or abnormal combustion due to trouble in ignition system	Refer to Hard Start or Abnormal Combustion Troubleshooting Guide
Others	Engine idle speed too high	Reset Idle Air Control Valve
	Returning of accelerator control sluggish	Correct
	Fuel system leakage	Correct or replace
	Clutch slipping	Correct
	Brake drag	Correct
	Selection of transmission gear incorrect	Caution operator of incorrect gear selection
	Excessive Exhaust Gas Recirculation flow due to trouble in Exhaust Gas Recirculation system	Refer to Abnormal Combustion

Oil Problems

Condition	Possible cause	Correction
Oil pressure too low	Wrong oil in use	Replace with correct engine oil
	Relief valve sticking	Replace
	Oil pump not operating properly	Correct or replace
	Oil pump strainer clogged	Clean or replace strainer
	Oil pump worn	Replace
	Oil pressure gauge defective	Correct or replace
	Crankshaft bearing or connecting rod bearing worn	Replace
Oil contamination	Wrong oil in use	Replace with new engine oil
	Oil filter clogged	Replace oil filter
	Cylinder head gasket damage	Replace gasket
	Burned gases leaking	Replace piston and piston rings or rebore cylinders
Oil not reaching valve system	Oil passage in cylinder head or cylinder body clogged	Clean or correct

Engine Oil Pressure Check

- Check for dirt, gasoline or water in the engine oil.
 - Check the viscosity of the oil.
 - Change the oil if the viscosity is outside the specified standard.
 - Refer to the "Maintenance and Lubrication" section of this manual.
- Check the engine oil level.
The level should fall somewhere between the "ADD" and the "FULL" marks on the oil level dipstick.
If the oil level does not reach the "ADD" mark on the oil level dipstick, engine oil must be added.

- Remove the oil pressure unit.
- Install an oil pressure gauge.
- Start the engine and allow the engine to reach normal operating temperature (About 80°C).
- Measure the oil pressure.
Oil pressure should be:
150 kPa (21.8 psi) at idle speed.
- Stop the engine.
- Remove the oil pressure gauge.
- Install the oil pressure unit.
- Start the engine and check for leaks.

Malfunction Indicator Lamp


The instrument panel "CHECK ENGINE" Malfunction Indicator Lamp (MIL) illuminates by self diagnostic system when the system checks the starting of engine, or senses malfunctions.

Condition	Possible cause	Correction
"CHECK ENGINE" MIL does not illuminate at the starting of engine	Bulb defective	Replace
	MIL circuit open	Correct or replace
	Command signal circuit to operate self diagnostic system shorted	Correct or replace
	Powertrain Control Module (PCM) cable loosely connected, disconnected or defective	Correct or replace
	PCM defective	Replace
"CHECK ENGINE" MIL illuminates, and stays on	Deterioration heated oxygen sensor of internal element	Replace
	Heated oxygen sensor connector terminal improper contact	Reconnect properly
	Heated oxygen sensor lead wire shorted	Correct
	Heated oxygen sensor circuit open	Correct or replace
	Deterioration engine coolant temperature sensor of internal element	Replace
	Engine coolant temperature sensor connector terminal improper contact	Reconnect properly
	Engine coolant temperature sensor lead wire shorted	Correct
	Engine coolant temperature sensor circuit open	Correct or replace
	Throttle position sensor open or shorted circuits	Correct or replace
	Deterioration of crankshaft position sensor	Replace
	Crankshaft position sensor circuit open or shorted	Correct or replace
	Vehicle speed sensor circuit open	Correct or replace
	Manifold absolute pressure sensor circuit open or shorted	Correct or replace
	Intake air temperature sensor circuit open or shorted	Correct or replace
	Fuel injector circuit open or shorted	Correct or replace
	PCM driver transistor defective	Replace PCM
	Malfunctioning of PCM RAM (Random Access Memory) or ROM (Read Only Memory)	Replace PCM

Cylinder Head Cover

Removal

1. Disconnect battery ground cable.
2. Disconnect PCV hose from cylinder head cover.
3. Remove intake duct.
4. Remove left side ground cable from cylinder head cover and disconnect ground cable connector on the left side wheel arch. Remove right side ground cable from generator stay and disconnect ground cable connector on the right side wheel arch.
5. Disconnect three(black, green and blue colors) engine wire harness connectors from chassis harness of left rear side of compartment.
6. Disconnect cooling fan wire harness connector from cooling fan on left side top of fan shroud.
7. Move drive belt tensioner to loose side using wrench then remove drive belt.



033RW001


8. Remove PCV hose from cylinder block.
9. Remove intake duct stay from cylinder head.
10. Remove two bolts for remove ignition cable cover from cylinder head cover.
11. Disconnect ignition cable from ignition plug.
12. Disconnect camshaft position sensor harness and crankshaft angle sensor harness from behind generator.

13. Remove four bolts and remove the crankshaft pulley



020RW014

14. Remove timing belt front cover.
15. Loose fixing bolt of timing belt rear cover then remove the camshaft angle sensor.




020RW012

16. Remove ten cylinder head cover fixing bolts and remove the cylinder head cover.

Installation

1. Install the camshaft position sensor and tighten timing rear cover bolt.

Torque: 8 N-m (5.9 lb ft)



2. Install the cylinder head cover and tighten bolts to the specified torque.


Torque: 8 N-m (5.9 lb ft)

3. Install the timing belt front cover then tighten fixing bolts to the specified torque.


Torque: 6 N-m (4.4 lb ft)

4. Install the crankshaft pulley, tighten fixing bolts to the specified torque.

Torque: 20 N-m (14 lb ft)



5. Move drive belt tensioner to loose side using wrench then install the drive belt to normal position.



6. Connect ignition cable to ignition plug.


7. Install ignition cable cover to cylinder head cover and tighten two bolt to the specified torque.

Torque: 3 N-m (2 lb ft)

8. Install intake duct bracket to cylinder block.

9. Install PCV hose flange to cylinder block to the specified torque.

Torque: 25 N-m (18 lb ft)



6A-18 ENGINE MECHANICAL (X22SE 2.2L)


10. Connect cooling fan wire harness connector to cooling fan on left side top of fan shroud.
11. Connect left side ground cable to cylinder head cover and connect other side connector to left side wheel arch terminal.
Connect right side ground cable to generator stay and connect other side connector to right side wheel arch terminal.

12. Connect three(black, green and blue colors) engine wire harness connector to chassis harness of left rear side of engine compartment.
13. Install intake duct.
14. Connect PCV hose to cylinder head cover.
15. Connect battery ground cable.

Exhaust Manifold

Removal

1. Disconnect battery ground cable.
2. Disconnect PCV hose from air intake duct.
3. Remove a nut from air intake duct bracket and loosen hose clamp on throttle body. Remove air intake duct assembly with air cleaner cover.
4. Remove air intake duct bracket with ground cable.
5. Remove four fixing bolts on exhaust manifold heat protector.
6. Remove fixing four nuts from flange of front exhaust pipe and remove fixing bolts from silencer side.




027RW005

7. Remove ten exhaust manifold fixing nuts then remove exhaust manifold.

Installation


1. Install exhaust manifold and tighten fixing nuts to be tightened in three steps.
 - **Tightening sequence:**
 - Step1: J G H B D C J G B D
 - Step2: A B C D E F G H J K
 - Step3: A B C D E F G H J K
 - **Tightening torque:**
 - Step1: 14 N·m (10 lb ft)
 - Step2: 20 N·m (14 lb ft)
 - Step3: 20 N·m (14 lb ft)



011RW029

2. Install front exhaust pipe to exhaust manifold and tighten fixing nut to the specified torque.

Torque: 25 N·m (18 lb ft)



027RW005

3. Tighten silencer side bolt to the specified torque.

Torque: 68 N·m (50 lb ft)

4. Install exhaust manifold heat protector and tighten bolt.

Torque: 8 N·m (5.9 lb ft)


5. Install intake duct bracket with ground cable.
6. Install intake duct assembly to throttle body and air cleaner then tighten nut to the intake duct bracket and clamp on the throttle body side, also clamp air cleaner cover.

7. Connect PCV hose to air intake duct.
8. Connect battery ground cable.

Crankshaft Pulley


Removal

1. Disconnect battery ground cable.
2. Move drive belt tensioner to loose side by using wrench then remove drive belt.



033RW001

3. Remove four crankshaft pulley fixing bolts, remove crankshaft pulley.




020RW014

Installation


1. Install the crankshaft pulley to crankshaft flange.
2. Tighten four bolt to the specified torque.

Torque: 20 N·m (14 lb ft)



020RW014

3. Move drive belt tensioner to loose side by using wrench, then install drive belt to normal position.




033RW001

4. Connect battery ground cable.


Intake Manifold

Removal


1. Disconnect battery ground cable.
2. Remove PCV hose from air intake duct.
3. Remove a nut from air intake duct bracket and loosen hose clamp on throttle body. Remove air intake duct assembly with air cleaner cover.
4. Drain engine coolant.
5. Remove water hoses from throttle body.
6. Disconnect the connector for throttle position sensor, idle air control valve sensor from throttle body.
7. Remove fuel pipe joint eye bolts from fuel rail and disconnect wire harness from fuel injector.




8. Disconnect hose from fuel pressure regulator then remove fuel rail assembly.
9. Remove throttle valve control cable from throttle body.
10. Remove fixing bolts for generator bracket.



11. Remove water pipe fixing bolt then remove water pipe.
12. Remove fixing bolt from bracket (Between cylinder block and intake manifold) of intake manifold side.




13. Remove ignition coil bracket fixing bolt.
14. Remove bolt and seven nuts, and remove intake manifold.



Installation

1. Install intake manifold with gasket to cylinder head, tighten bolt and nuts to the specified torque.


Torque: 22 N·m (16 lb ft)



027RW002

2. Install ignition coil bracket fixing bolt.
3. Install intake manifold bracket, tighten bolt.

Torque: 22 N·m (16 lb ft)




025RW002

4. Install water pipe to intake manifold.
5. Install generator bracket and tighten generator bracket bolts.

Torque

Long bolts: 35 N·m (25 lb ft)


Short bolts: 20 N·m (14 lb ft)



065RW025

6. Install fuel rail assembly to intake manifold and connect hose between fuel pressure regulator and throttle body.
7. Install fuel pipe and tighten joint eye bolt and connect fuel injector harness.

Torque: 25 N·m (18 lb ft)



042RW001

8. Connect the connector for throttle position sensor and idle air control valve sensor to throttle body.
9. Install water hoses to throttle body.
10. Install intake duct assembly to throttle body and air cleaner then tighten nut to the intake duct bracket and clamp on the throttle body side and air cleaner side.

Torque: 7 N·m (5.1 lb ft)

11. Install PCV hose to air intake duct.
12. Install throttle valve control cable to throttle body.
13. Confirm the free play of throttle valve control cable.


Free play: 5.7 to 6.3 mm

14. Fill engine coolant to full level from radiator filler neck.
15. Connect battery ground cable.

Cylinder Head Assembly


Removal

1. Disconnect battery ground cable.
2. Disconnect connector of intake air temperature sensor from intake air duct.
3. Remove PCV hose from air intake duct.
4. Remove nut from air intake duct bracket and loosen hose clamp on throttle body. Remove air intake duct assembly with air cleaner cover.
5. Remove intake air duct bracket from cylinder head.
6. Drain engine coolant.
7. Move drive belt tensioner to loose side using wrench then remove drive belt.



033RW001


8. Remove radiator upper hose from engine side.
9. Remove four nuts of exhaust front pipe.
10. Remove three bolts from generator bracket then remove the generator with brackets.



065RW025


11. Disconnect crankshaft angle sensor connector.
12. Disconnect knock sensor connector.

13. Remove heater hose from adapter side.
14. Remove heater hose from water pipe side.
15. Remove water hose between water pipe and throttle body.
16. Remove fuel pipe joint eye bolts from fuel rail assembly and remove fuel pipe bracket with electric ground cable.



042RW001

17. Disconnect connector for evaporation valve.
18. Remove canister hose.
19. Remove fixing nut of intake manifold stay from cylinder block side.




025RW002

20. Remove two bolts from intake manifold for water pipe support and remove cylinder head assembly.
21. Remove engine harness cover and disconnect three connectors from chassis harness on left rear side engine compartment.
22. Disconnect connector for power steering pump pressure switch.
23. Remove four bolts and remove crankshaft pulley.



020RW014

24. Remove two bolts and nut then remove timing belt front cover.
25. Remove ventilation hose from cylinder block side and from cylinder head side.
26. Remove two bolts, ignition cable cover and remove ignition cables from spark plug.
27. Disconnect camshaft angle sensor connector.
28. Remove ten bolts and remove cylinder head cover.
29. Remove fixing bolt of timing belt tensioner then remove timing belt tensioner.




020RW010

30. Remove timing belt.

CAUTION:


- Do not bend or twist belt, otherwise its core could be damaged. The belt should not be bent at a radius less than 30 mm.
- Timing belt drive gear counterhold with J-42620.

- Do not allow oil or other chemical substances to come in contact with the belt. They will shorten the life.
 - Do not attempt to pry or stretch the belt with a screw driver or any other tool during installation.
 - Store timing belt in cool and dark place. Never expose the belt direct sunlight or heat.
31. Remove two idle pulleys, the left side with idle pulley bracket.
 32. Remove two bolts and stud bolt and remove timing belt rear cover.
 33. Remove camshaft angle sensor
 34. Disconnect engine oil pressure switch connector.



050RW005


35. Remove camshaft assembly exhaust side.
36. Use J-42623 to remove ten cylinder head fixing bolts



012RW007


Installation

1. Put cylinder head gasket on the cylinder block.




2. Install the cylinder head assembly, tighten cylinder head bolts by four steps tightening method in the following sequence to the specified torque.(use J-42623)

Torque: 25 N·m (18 lb ft) + 90° + 90° + 90°



3. Install camshaft assembly exhaust side and tighten camshaft bracket bolts in the sequence to the specified torque.

Torque: 8 N·m (5.9 lb ft)




4. Connect engine oil pressure switch connector.
5. Install camshaft angle sensor.
6. Install the timing belt rear cover and tighten three bolts to the specified torque.

Torque


M6 bolt: 6 N·m (4.4 lb ft)

M8 bolt: 8 N·m (5.8 lb ft)



7. Install left side idle pulley with idle pulley bracket, tighten to the specified torque and install right side idle pulley and tighten to the specified torque.

Torque: 25 N·m (18 lb ft)



020RW016


8. Install timing belt tensioner then tighten it temporarily until make alignment timing belt.
9. Install the cylinder head cover and tighten fixing bolt temporarily.
10. Install the timing belt and perform timing belt setting procedure as follows.

1. Bring the engine top dead center No.1 cylinder compression stroke by rotating the engine in the direction of normal operation.


The engine is in this position when the notches on the camshaft pulleys align with the marks on the cylinder head cover(1), Check the crankshaft pulley timing mark is aligned (2) also check for water pump positioning ensure tabs are aligned (3).

- Rotate the engine two full turns in the direction of normal operation until the engine is again at top dead centre, No.1 cylinder firing being careful that all movement is in a clockwise direction.

- If the engine is turned too far, do not turn backwards, but continue to turn in the same direction until the marks are again in line.




014RW066




014RW063

2. Place J-43037 to between intake and exhaust of camshaft drive gear to prevent camshaft drive gear movement during timing belt setting.




014RW067




014RW065


3. Set the timing belt shown in the illustration, ensure that tension side of the timing belt is taut and move the timing belt tension adjustment lever clockwise, until the pointer of the tensioner is flowing.



For used timing belt (over 60 minutes from new): the pointer will be approx. 4 mm (0.16 in) to the left of the center of the "V" notch when viewed from the front of the engine.




For new timing belt: The pointer must be at the center of "V" notch when viewed from the front of the engine.



4. Tighten fixing bolt of timing belt tensioner to the specified torque.

Torque: 25 N·m (18 lb ft)



11. Tighten cylinder head cover to the specified torque.

Torque: 8 N·m (5.9 lb ft)

12. Connect camshaft angle sensor connector.

13. Install the ignition cable to spark plug.

14. Install ignition cable cover and tighten two bolts.

Torque: 3 N·m (2 lb ft)


15. Install ventilation hoses to cylinder block side and cylinder head side.

16. Install timing belt front cover and tighten two bolts to the specified torque.

Torque: 6 N·m (4.4 lb ft)

17. Install crankshaft pulley and tighten four bolts.

Torque: 20 N·m (14 lb ft)




020RW014

18. Connect connector for power steering pump pressure switch.

19. Connect engine harness connector to chassis harness of the left rear of engine compartment and install engine harness cover.

20. Install two bolts to intake manifold for water pipe support.

21. Install fixing nut of intake manifold stay to cylinder block.




025RW002

22. Install canister hose.

23. Connect connector for evaporation valve.

24. Install fuel pipe joint eye bolts to fuel rail assembly and install fuel pipe bracket with electric ground cable.

Torque: 25 N·m (18 lb ft)



042RW001

25. Install water hose between water pipe and throttle body.

26. Install heater hose to water pipe side.

27. Install heater hose to adapter side.

28. Connect knock sensor connector.


29. Connect crankshaft angle sensor connector.

30. Install generator with bracket and tighten three bolts.

Torque

35 N·m (25 lb ft) for Long bolt

20 N·m (14 lb ft) for Short bolt




065RW025

6A-28 ENGINE MECHANICAL (X22SE 2.2L)


31. Install exhaust front pipe to exhaust manifold and tighten four nuts to the specified torque.

Torque: 25 N·m (18 lb ft)



32. Install radiator upper hose to engine.

33. Move drive belt tensioner to loose side using wrench then install the drive belt to normal position.



34. Install intake air duct bracket to cylinder head.

35. Install air intake duct assembly with air cleaner cover to throttle body and tighten nut to the air intake duct bracket then tighten hose clamp.

Torque

7 N·m (5.1 lb ft) for nut


3 N·m (2.2 lb ft) for hose clamp bolt

36. Install PCV hose to air intake duct.
37. Connect connector of intake air temperature sensor on intake air duct.
38. Connect battery ground cable.
39. Fill engine coolant to full level in the engine coolant reservoir tank.


Timing Belt

Removal


1. Disconnect battery ground cable.
2. Move drive belt tensioner to loose side using wrench then remove drive belt.



3. Remove engine harness cover and disconnect three connectors from left rear side of engine compartment.
4. Remove four bolts and remove crankshaft pulley.



5. Disconnect three connectors of engine harness from chassis harness of left rear side of engine compartment.
6. Remove nut and remove engine harness cover from front of engine.
7. Remove two bolts then remove timing belt front cover.
8. Remove fixing bolt of timing belt tensioner then remove timing belt tensioner (1).




9. Remove timing belt.

CAUTION:

- Do not bend or twist belt, otherwise its core could be damaged. The belt should not be bent at a radius less than 30 mm.
- Timing belt drive gear counterhold with J-42620.
- Do not allow oil or other chemical substances to come in contact with the belt. They will shorten the life.
- Do not attempt to pry or stretch the belt with a screw driver or any other tool during installation.
- Store timing belt in cool and dark place. Never expose the belt direct sunlight or heat.

Installation


1. Install timing belt tensioner then tighten it temporarily until make alignment timing belt.




2. Install the timing belt and perform timing belt setting procedure as follows:


1. Bring the engine top dead center No.1 cylinder compression stroke by rotating the engine in the direction of normal operation.

The engine is in this position when the notches on the camshaft pulleys align with the marks on the cylinder head cover(1), Check the crankshaft pulley timing mark is aligned (2) also check for water pump positioning ensure tabs are aligned (3).






014RW066




014RW065

3. Set the timing belt shown in the illustration, ensure that tension side of the timing belt is taut and move the timing belt tensioner adjustment lever clockwise, until the pointer of the tensioner is flowing.




014RW063


2. Place J-43037 between intake and exhaust of camshaft drive gear for prevent to camshaft drive gear movement during timing belt setting.




014RW064



For used timing belt(over 60 minutes from new):
The pointer will be approx. 4 mm(0.16 in) to the left of the center of the "V" notch when viewed from the front of the engine.




For new timing belt: The pointer must be at the center of "V" notch when viewed from the front of the engine.



3. Tighten fixing bolt (1) of timing belt tensioner to the specified torque.

Torque: 25 N·m (18 lb ft)



4. Install timing belt front cover and tighten two bolts to the specified torque.

Torque: 6 N·m (4.4 lb ft)


5. Install engine harness cover to front top of engine and tighten nut to the specified torque.

Torque: 6 N·m (4.4 lb ft)


6A-32 ENGINE MECHANICAL (X22SE 2.2L)

6. Install crankshaft pulley and tighten four bolts.

Torque: 20 N·m (14 lb ft)



7. Move drive belt tensioner to loose side using wrench then install drive belt to normal position.




8. Connect engine harness three connector to chassis harness of left rear side of engine compartment.

9. Connect battery ground cable.


Camshaft

Removal

1. Disconnect battery ground cable.
2. Remove cylinder head cover.
Refer to removal procedure for Cylinder Head Cover in this manual.
3. Remove timing belt tensioner and remove timing belt.




4. Use adjustable wrench to hexagonal portion of camshaft, and remove fixing bolt from front end of camshaft.



5. Remove camshaft drive gear from intake and exhaust camshaft.

6. Remove twenty fixing bolts from intake and exhaust camshaft bracket on the cylinder head, then remove camshafts.



CAUTION:



- Do not damage camshaft lobe and journal.
 - Do not damage hydraulic lash adjuster(HLA) and do not allow into foreign materials into cylinder head.
7. Remove oil seal from camshaft.

Installation

1. Clean surface of camshaft bracket and HLA.
2. Apply engine oil to journal surface of camshaft bracket and HLA.
3. Install camshaft to cylinder head.
4. Install camshaft bracket according to numerical as shown in the illustration.


The bracket number is:

- Exhaust: 1 to 5 from front
- Intake: 6 to 10 from front.



6A-34 ENGINE MECHANICAL (X22SE 2.2L)



Camshaft oil seal installation area on the cylinder body of No.1, No.6 and camshaft bracket rear side plug portion must be applied HN1023 or equivalent as in the illustration.




5. Tighten camshaft bracket bolts to the specified torque by sequence in the illustration.

Torque: 8 N·m (5.9 lb ft)


6. Use J-42609 for installation camshaft oil seal.



7. Install the camshaft drive gear. Align the timing mark between notch on the camshaft drive gear(1) and lug on the camshaft bracket(2).




Also align a guide hole on the camshaft drive gear marked "IN" for intake and "EX" for exhaust to guide pin on the camshaft when installing the camshaft drive gear.



8. Tighten camshaft bracket fixing bolt to the specified torque.

Torque: 50 N·m (36 lb ft)



9. Install timing belt.


Refer to installation procedure for Timing Belt in this manual.

10. Install cylinder head cover.

Refer to installation procedure for Cylinder Head Cover in this manual.


11. Connect battery ground cable.

Engine Assembly




Removal

1. Disconnect battery ground and positive cable.
2. Remove battery.
3. Make alignment mark on the engine hood and hinges before removal in order to return the hood to original position exactly.
4. Remove engine hood.
5. Drain engine coolant from radiator.
6. Disconnect throttle valve control cable from throttle valve on intake manifold.
7. Remove air duct with air cleaner cover.
8. Remove air cleaner assembly.
9. Disconnect three engine harness connectors from chassis harness of left rear side engine compartment.
10. Disconnect vacuum hose on the brake booster.
11. Disconnect cooling fan harness connector on the left of fan shroud.
12. Disconnect ground cable connector from left and right of front wheel arch upper side.
13. Remove clutch piping bracket from right side of clutch housing.
14. Remove fuel piping bracket from transmission.
15. Remove four nuts from exhaust front pipe exhaust manifold side and remove two bolts from rear side of exhaust front pipe. Remove exhaust front pipe.



027RW005

16. Remove transmission mounting fixing bolts and nut from cross member.




022RW014


17. Remove transmission front under cover from front portion of clutch housing.
18. Disconnect two fuel pipes at right side of transmission by quick type fuel hose connector.

CAUTION: Plug fuel pipe on engine side and fuel hose from fuel tank.


19. Disconnect canister hose next to fuel piping connector.
20. Remove propeller shaft fixing bolt from rear side transmission.
21. Remove fixing bolts between clutch housing and transmission, then move transmission.
22. Remove power steering pump assembly then place the power steering pump along with piping.
23. Disconnect two chassis harness connectors from right rear side engine compartment (under fuse box) and remove two harness clips.
24. Remove engine ground cable from chassis frame.
25. Remove radiator lower hose from engine side.
26. Remove two heater hoses from right side panel.
27. Remove radiator grille.
28. Remove harness clip from behind right horn.
29. Remove engine mounting bolt from chassis frame side.



022RW005



022RW005



022RW006


30. Lift up the engine assembly.

Installation

CAUTION: When assembling the engine and transmission, confirm that dowels have been mounted in the specified positions at the engine side. If assembled in the condition that dowels have not been mounted in the specified position, transmission damage can result.

1. position the engine assembly in the engine compartment.
2. Tighten engine mounting bolt to frame side to the specified torque.

Torque: 41 N·m (30 lb ft)




022RW006

3. Install harness clip behind right horn.
4. Install the radiator grille and install flasher lamp assembly.
5. Install two heater hoses to right side panel.
6. Install radiator lower hose to engine.
7. Install engine ground cable to chassis frame.
8. Connect two chassis harness connectors to right rear side engine room (under fuse box) and install two harness clips.
9. Install power steering pump assembly and tighten fixing bolts.
10. Install transmission assembly, refer to installation procedure for Transmission section in this manual.
11. Install propeller shaft, refer to installation procedure for Propeller section in this manual.
12. Connect canister hose next to fuel piping connector.
13. Connect two fuel pipes at right side transmission by quick type connector.

6A-38 ENGINE MECHANICAL (X22SE 2.2L)

14. Install transmission front under cover to front portion of clutch housing.
15. Install transmission mounting fixing bolts and nuts to cross member.

Torque: 50 N·m (36 lb ft)




16. Install exhaust front pipe to exhaust manifold and silencer, then tighten fixing nuts and bolts to the specified torque.

Torque

25 N·m (18 lb ft) for nut

68 N·m (50 lb ft) for bolt



17. Install fuel piping bracket to transmission.
18. Install clutch piping bracket to right side of clutch housing.
19. Connect ground cable connector to left and right of front wheel arch upper side.
20. Connect cooling fan harness connector on the left of fan shroud.
21. Connect vacuum hose to the brake booster.

22. Connect three engine harness connectors to chassis harness of left rear side of engine compartment.
23. Install air cleaner assembly.
24. Install air duct with air cleaner cover to specified torque.

Torque

7 N·m (5.1 lb ft) for air duct fixing

3 N·m (2.2 lb ft) for air duct clamp bolt


25. Connect throttle valve control cable to throttle valve on the intake manifold.
Confirm the free play of throttle valve control cable.

Free play: 5.7 to 6.3 mm

26. Install engine hood to original position.
Refer to installation procedure for Body section in this manual.
27. Install battery, connect positive cable and ground cable.
28. Fill engine coolant to full level in the coolant reservoir tank.

Cylinder Head

Cylinder Head and Associated Parts



011RW010

Legend

- | | |
|---------------------------------|---|
| (1) Cylinder Head Bolt | (6) Camshaft Exhaust |
| (2) Camshaft Pulley Fixing Bolt | (7) Camshaft Intake |
| (3) Camshaft Pulley | (8) Tappet (HLA) |
| (4) Camshaft Oil Seal | (9) Split Collar |
| (5) Camshaft Bracket Bolt | (10) Valve Spring and Spring Upper Seat |
| | (11) Valve |

Disassembly

NOTE:

- During disassembly, be sure that the valve train components are kept together and identified so that they can be reinstalled in their original locations.


- Before removing the cylinder head from the engine and before disassembling the valve mechanism, perform a compression test and note the results.

1. Remove camshaft pulley fixing bolt (2), then pulley (3).
2. Remove camshaft bracket fixing bolt (5), camshaft bracket, then camshaft exhaust (6), and intake side (7).


3. Remove cylinder head.

Use J-42623.

4. Valve spring, valve spring caps, compress valve spring — use J-8062 (1) and Adapter J-42619 (2).
Valve keepers.




5. Valves, valve stem seals — use commercially available remover pliers. Valve spring seats from cylinder head.




Inspection and Repair

1. Check length and width of cylinder head sealing surfaces for deformation and diagonals for warpage — use straight edge and feeler gauge.



2. Height of cylinder head (sealing surface to sealing surface).

Dimension (I) – 134 mm



Reassembly


1. Valves, valve stem seals. Refer to Valve Spring, Oil Controller, Valve, Valve Guide in this section.
2. Valve spring, valve spring caps. Refer to Valve Spring, Oil Controller, Valve, Valve Guide in this section.
3. Install tappet (HLA).
4. Cylinder head with new cylinder head bolts to cylinder block.
Tighten the bolts in 4 steps.

1st step: 25 N·m (18 lb ft)

2nd step: 90°

3rd step: 90°


4th step: 90°



5. Camshaft in cylinder head. Refer to Camshaft in this section.
6. Camshaft pulley. Refer to Camshaft in this section.

Valve Spring, Valve, Valve Guide

Valve Spring, Valve, Valve Guide and Associated Parts



011RW024


Legend

- | | |
|----------------------------------|------------------------|
| (1) Camshaft Pulley Fixing Bolts | (8) Tappet |
| (2) Camshaft Pulley | (9) Split Collar |
| (3) Camshaft Bracket Fixing Bolt | (10) Spring Upper Seat |
| (4) Camshaft Assembly Intake | (11) Valve Spring |
| (5) Camshaft Assembly Exhaust | (12) Oil Seal |
| (6) Cylinder Head Bolt | (13) Spring Lower Seat |
| (7) Cylinder Head | (14) Valve Guide |
| | (15) Valve |

Disassembly


1. Remove camshaft pulley (1), (2).
2. Remove camshaft assembly (Intake) (3), (4).
3. Remove camshaft assembly (Exhaust side) (5).
4. Remove cylinder head (6), (7).
5. Remove tappet (8).

6. Use J-8062 valve spring compressor and J-42619 adapter to remove split collar (9).



011RW014

7. Remove spring upper seat and valve spring (10), (11).
8. Valve, valve guide – use commercially available remover pliers.
Valve spring lower seat from cylinder head.



011RW013


Inspection and Repair

1. Use a internal micrometer to measure the diameter valve guide.

Valve stem play

Intake : 0.03 to 0.057 mm (0.0012 to 0.0022 in)

Exhaust : 0.04 to 0.067 mm (0.0016 to 0.0026 in)



011RW020

Valve Guide

CAUTION: Taking care not to damage the valve seat contact surface, when removing carbon adhering to the valve head. Carefully inspect the valve stem for scratching or abnormal wear. If these conditions are present, the valve and the valve guide must be replaced as a set.

Valve Seat

Valve seat width in cylinder head

Intake: 1.0 to 1.5 mm (0.039 to 0.0585 in)


Exhaust: 1.7 to 2.2 mm (0.0663 to 0.0858 in)

Valve Seat Insert Correction

Remove the carbon from the valve seat insert surface.

Valve Seat Insert Replacement


1. Arc weld the rod at several points. Be careful not to damage the aluminum section.
2. Allow the rod to cool for a few minutes. This will cause the valve seat to shrink.
3. Strike the rod and pull it out.




4. Carefully clean the valve seat press-fit section on the cylinder head side.
5. Heat the press-fit section with steam or some other means to cause expansion. Cool the valve seat with dry ice or some other means.
6. Insert the press-fit section into the valve seat horizontally.
7. Lap the valve and the seat.

Reassembly

1. Install oil controller (3) and spring lower seat (2). Using oil controller replacer J-42622, drive in a new oil controller.




2. Install valve to valve guide. Before install valve guide apply engine oil to the outside of the valve stem.
3. Install valve spring to cylinder head. Attach the valve spring to the lower spring seat.
4. Install lower valve spring seat, valve spring and upper valve spring seat then put split collars on the upper spring seat, using J-8062 valve spring compressor for install the split collars.



5. Install tappet.
6. Install camshaft assembly.
○Refer to installation procedure for Camshaft in this manual.

Camshaft

Camshaft and Associated Parts




011RW023

Legend

- | | |
|---------------------------------|----------------------------------|
| (1) Camshaft Pulley Fixing Bolt | (4) Camshaft Bracket |
| (2) Camshaft Pulley | (5) Camshaft Bracket Fixing Bolt |
| (3) Oil Seal | (6) Camshaft Assembly Exhaust |
| | (7) Camshaft Assembly Intake |


Disassembly

1. Remove fixing bolt (1) for camshaft pulley (2).
2. Remove oil seal (3).



014RW035

3. Remove oil seal (3).
4. Remove twenty fixing bolts (5) from inlet and exhaust camshaft bracket, then camshaft brackets (4).



5. Remove camshaft assembly (6), (7).

Reassembly

1. Install camshaft drive gear assembly and tighten three bolts to specified torque.

Torque: 50 N·m (37 lb ft) + 60° + 15°


2. Install camshaft assembly and camshaft brackets, tighten twenty bolts on one side bank to the specified torque.

1. Apply engine oil to camshaft journal and bearing surface of camshaft bracket.
2. Align timing mark on intake camshaft and exhaust camshaft to timing mark on camshaft drive gear (one dot).
3. Tighten twenty bolts on numerical order one side bank shown in the illustration.

Torque: 8 N·m (6 lb ft)


4. If it required to replace oil seal of camshaft drive gear, use J-42609 for install the oil seal.
5. Tighten bolt for camshaft drive gear assembly pulley to the specified torque.

Torque: 50 N·m (37 lb ft) + 60° + 15°



Crankshaft

Crankshaft and Associated Parts



015RW008

Legend

- | | |
|----------------------------|--|
| (1) Cylinder Head Assembly | (6) Balance Unit Assembly |
| (2) Oil Pump Assembly | (7) Piston and Connecting Rod Assembly |
| (3) Pan | (8) Main Bearing Cap |
| (4) Pan Support | (9) Crankshaft |
| (5) Oil Strainer | (10) Cylinder Block Assembly |

Disassembly

1. Remove cylinder head assembly (1). Refer to "Cylinder head" in this manual.
2. Remove oil pan (3).

CAUTION: Take care not to damage or deform the sealing flange surface of crankcase.

3. Remove oil pan support (4).

4. Remove oil strainer (5).
5. Remove oil pump assembly (5).
6. Balance unit assembly.
7. Remove piston and connecting rod assembly (7). Refer to "Piston, Piston Ring and Connecting Rod" in this manual.
8. Remove flywheel.
9. Remove rear oil seal and oil baffle plate.

10. Remove main bearing cap (8).
11. Remove crankshaft (9).
12. Remove crankshaft pulse pickup sensor disc.

Inspection and Repair

1. Crankshaft


Set the dial indicator as shown in the illustration and measure the crankshaft thrust clearance. If the thrust clearance exceeds the specified limit, replace the thrust bearings as a set.

Thrust Clearance

Standard : 0.01 mm–0.02 mm

(0.0004 in–0.0008 in)


Limit : 0.21 mm (0.0118 in)



014RW079

Main Bearing Clearance

1. Remove the bearing caps and measure the oil clearance.
2. Remove the main bearing cap fixing bolts.
Arrange the removed main bearing caps in the cylinder number order.
Remove the main bearings.
3. Remove the crankshaft.
Remove the main bearings.
4. Clean the upper and lower bearings as well as the crankshaft main journal.
5. Check the bearings for damage or excessive wear.
The bearings must be replaced as a set if damage or excessive wear is discovered during inspection.
6. Set the upper bearings and the thrust washers to their original positions.
Carefully install the crankshaft.
7. Set the lower bearings to the bearing cap original position.
8. Apply plastigage to the crankshaft journal unit as shown in the illustration.



014RW055

9. Install main bearing caps, and tighten each bolt to the specified torque.

Main bearing caps bolts.

Torque:

1st step: 50 N·m (37 lb ft)

2nd step: 45°

3rd step: 15°


Torque : 39 N·m (29lb ft)

10. Measure the plastigage width and determine the oil clearance. If the oil clearance exceeds the specified limit, replace the main bearings as a set and/or replace the crankshaft.

Standard : 0.015 mm–0.04 mm

(0.0007 in–0.0016 in)

Limit : 0.12 mm (0.0047 in)



014RW077

11. Clean the plastigage from the bearings and the crankshaft.
Remove the crankshaft and the bearings.


Crankshaft (12) Inspection

Inspect the surface of the crankshaft journal and crank pins for excessive wear and damage. Inspect the oil seal fitting surfaces for excessive wear and damage. Inspect the oil ports for obstructions.

Inspection and Repair

1. Carefully set the crankshaft. Slowly rotate the crankshaft and measure the runout. If the crankshaft runout exceeds the specified limit, the crankshaft must be replaced.

Runout : 0.03 mm (0.0012 in)




014RW078

2. Measure the diameter and the uneven wear of main journal and crank pin. If the crankshaft wear exceeds the specified limit, crankshaft must be replaced.

**Main journal diameter : 57.934 mm–57.980 mm
(2.259 in–2.261 in)**

**Crank pin diameter : 48.939 mm–48.982 mm
(1.909 in.–1.91 in.)**



015RS009

Crankshaft Bearing Selection

When installing new crankshaft bearings or replacing bearings, refer to the selection table below. Select and install the new crankshaft bearings.


Crankshaft grinding dimensions	mm (in)
Production and Service	
Crankshaft bearing journal dia.	
Standard size	
white	57.974 to 57.981 (2.260–2.261)
green	57.981 to 57.988 (2.261–2.2615)
brown	57.988 to 57.995 (2.2615–2.2618)
Undersize 0.25 (0.0097)	
green/blue	57.732 to 57.738 (2.2515–2.2517)
brown/blue	57.738 to 57.745 (2.2517–2.252)
Undersize 0.5 (0.0195)	
green/white	57.482 to 57.488 (2.2418–2.242)
brown/white	57.488 to 57.495 (2.242–2.2423)
Guide bearing width	
Standard size	25.950 to 26.002 (1.012–1.014)
Undersize 0.25 (0.0097)	26.150 to 26.202 (1.019–1.021)
Undersize 0.5 (0.0195)	26.350 to 26.402 (1.027–1.029)

NOTE: Take care to ensure the bearings are positioned correctly.

Crankshaft pulse pickup sensor disc inspection and repair.

Inspect the crankshaft pulse pickup sensor disc for excessive wear and damage.

Replace the crankshaft pulse pickup sensor disc if the inspection exceeds wear and damage.



015RW039

Reassembly

1. Crankshaft (12).

- Install the crankshaft pulse pickup sensor disc.

Torque: 13 N·m (10 lb ft)

- Install the main bearings to the cylinder block and the main bearing caps.
- Be sure that they are positioned correctly.
- Apply new engine oil to the upper and lower main bearing faces.

NOTE: Do not apply engine oil to the main bearing back faces.

- Carefully mount the crankshaft.
- Apply engine oil to the thrust washer.
- Assemble the thrust washer to the No.3 bearing journal. The oil grooves must face the crankshaft.
- Tighten the crankshaft bearing cap bolts in 3 steps:


1st step: 50 N·m (36 lb ft)

2nd step: 45°

3rd step: 15°

2. Rear oil seal (10).


- Coat lip of seal rings thinly with protective grease.
- Install seal ring into cylinder block, use J-42616 (1) and J-42613 (2).



015RW009

3. Flywheel (9).

1. Thoroughly clean and remove the oil from the threads of crankshaft.
2. Remove the oil from the crankshaft and flywheel mounting faces.
3. Mount the flywheel on the crankshaft and then install the washer.
4. Use stopper (J-42618) to hold the crankshaft.



015RW010

5. Prevent from rotating.

Tighten the flywheel bolts in 3 steps:

1st step: 65 N·m (48 lb ft)


2nd step: 30°

3rd step: 15°

NOTE: Do not reuse the bolt.


4. Piston and connecting rod assembly (8)

- Apply engine oil to the cylinder bores, the connecting rod bearings and the crankshaft pins. Check to see that the piston ring end gaps are correctly positioned.
 - Piston rings position (A) every 180°.
- Oil scraper rings (B) — offset 25 to 50 mm/1 to 2 in. to left and right from gap of intermediate ring.



015RW026

- Insert the piston/connecting rod assemblies into each cylinder with the piston ring compressor. The front marks must be facing the front of the engine.
- Match the numbered caps with the numbers on the connecting rods. Align the punched marks on the connecting rods and caps.
- Arrow (1) on piston head points to engine timing side, bead on connecting rod points to flywheel side.



015RW038

○Tighten the bolts in 3 steps:

1st step: 35 N·m (25 lb ft)

2nd step: 45°

3rd step: 15°

5. Install the balance unit assembly and tighten the bolts in 2 steps:

1st step: 20 N·m (14 lb ft)

2nd step: 45°

Refer to the "Balance Unit Assembly" section of this manual.

6. Install oil pump assembly (5), refer to "Oil Pump" in this manual.

7. Install oil strainer.

Torque: 8 N·m (5.8 lb ft)

8. Install oil pan support and tighten the bolts to the specified torque.

Torque: 20 N·m (14 lb ft)

9. Install oil pan.

1. Completely remove all residual sealant, lubricant and moisture from the sealing surfaces. The surfaces must be perfectly dry.
2. Apply a correct width bead of sealant (TB-1207C or its equivalent) to the contact surfaces of the oil pan. There must be no gaps in the bead.
3. The oil pan support must be installed within 5 minutes after sealant application.
4. Tighten the bolts in to steps.


1st step: 8 N·m (5.8 lb ft)

2nd step: 30°

10. Install cylinder head assembly, refer to "Cylinder Head" in this manual.

Piston and Connecting Rod

Piston, Connecting Rod and Associate Parts



015RW037

Legend

- | | |
|----------------------------|--|
| (1) Cylinder Head Assembly | (7) Piston and Connecting Rod Assembly |
| (2) Cylinder Head Gasket | (8) Piston Ring |
| (3) Oil Pan Assembly | (9) Piston Pin |
| (4) Pan Support | (10) Piston |
| (5) Oil Strainer | (11) Connecting Rod |
| (6) Balance Unit Assembly | (12) Connecting Rod Cap |

Disassembly


1. Remove cylinder head assembly (1), refer to "Cylinder Head Removal" in this manual.
2. Remove cylinder head gasket (2).
3. Remove oil pan assembly and oil pan support (3) refer to "Oil Pan and Oil Pan Support" in this manual.
4. Remove oil strainer.
5. Remove balance unit assembly.
6. Remove connecting rod cap with connecting rod lower.

7. Remove piston and connecting rod assembly (7).

NOTE: Before removing piston and connecting rod assembly, measure thrust clearance.

- Remove any ridge or carbon build up from the top end of the cylinder.

8. Remove the piston rings (8) with a piston ring expander. Arrange the removed piston rings in the cylinder number order.



9. Remove the piston pin (9).

- Heat the connecting rod and the piston pin with oil heater, when its temperature is kept at 280°C–320°C.
- Push the piston pin with brass bar.

NOTE: Keep the parts removed from each cylinder separate. All parts must be reinstalled in their original positions.

10. Piston (10).

11. Connecting rod (11).

Inspection and Repair

Pistons (10)

Carefully clean away all the carbon adhering to the piston head and the piston ring grooves.

NOTE: Never use a wire brush to clean the pistons. Damage will result. Visually check each piston for cracking, scoring, and other signs of excessive wear. If any of the above conditions are found, the piston must be replaced.

Piston Rings (8)

Any worn or damaged part discovered during engine overhaul must be replaced with a new one.

1. Ring end gap measurement

- Insert the piston ring into the bore.
- Push the ring by the piston, at a right angle to the wall, into the point at which the cylinder bore diameter is the smallest.
- Measure the ring end gap.

Compression Ring

1st ring

Standard: 0.30 mm–0.50 mm
(0.0118 in.–0.0195 in)

2nd ring

Standard: 0.30 mm–0.50 mm
(0.0118 in.–0.0195 in)


Oil ring

Standard: 0.40 mm–1.40 mm
(0.0156 in.–0.0546 in)

2. Measure the clearance between the piston ring groove and the piston ring with a feeler gauge. If the piston ring groove / piston ring clearance exceeds the specified limit, the piston must be replaced.

Compression Ring Clearance

Standard : 0.02 mm–0.04 mm
(0.0008 in.–0.0016 in)



015RW025


Piston Pin (9)

NOTE: Do not reuse the old piston pin.

1. Use a micrometer to measure the new piston pin outside diameter in both directions at three different positions.
2. Measure the inside diameter of the connecting rod small end. If the fitting interference between the small end and pin does not conform to the specified value, the connecting rod must be replaced.

Standard : 0.02 mm–0.041 mm

(0.0008 in–0.0016 in)



3. Insert the new pin into the piston and rotate it. If the pin rotates smoothly with no backlash, the clearance is normal. If there is backlash or roughness, measure the clearance. If the clearance exceeds the specified limit, the piston must be replaced.

Clearance

Standard : 0.011 mm–0.014 mm

(0.0004 in.–0.0005 in)

Connecting Rods (11)

1. Measure the oil clearance between the connecting rod and the crankshaft.

1. Remove the connecting rod cap nuts and the rod caps (12).

Arrange the removed rod caps in the cylinder number order.

2. Clean the rod bearings and the crankshaft pins.
3. Carefully check the rod bearings. If even one bearing is found to be damaged or badly worn, the entire bearing assembly must be replaced as a set. Reinstall the bearings in their original positions. Apply plastigage to the crank pin.

4. Reinstall the rod caps (12) to their original positions.

Tighten the rod cap nuts.

1st step: 35 N·m (26 lb ft)

2nd step: 45°

3rd step: 15°

NOTE: Do not allow the crankshaft to rotate.

5. Remove the rod caps.
6. Measure the width of the plastigage and determine the oil clearance. If the oil clearance exceeds the limit, replace the rod bearing as a set.

Standard : 0.006 mm–0.031 mm

(0.0002 in–0.0012 in)

Limit : 0.12 mm (0.0047 in)

7. Clean the plastigage from the bearings and the crankshaft pins.

6A-56 ENGINE MECHANICAL (X22SE 2.2L)

Crankshaft grinding dimensions	mm (in)
(continued)	
Production and Service	
Con-rod bearing journal dia.	
Standard size	
(no color code)	48.970 to 48.988 (1.9098–1.9105)
Undersize 0.25 (0.0097)	
blue	48.720 to 48.738 (1.9001–1.9008)
Undersize 0.5 (0.0195)	
white	48.470 to 48.488 (1.8903–1.891)
Con-rod bearing journal width	
Standard size	
(no color code)	26.460 to 26.580 (1.0319–1.036)
Undersize 0.25 (0.0097)	
blue	26.460 to 26.580 (1.0319–1.036)
Undersize 0.5 (0.0195)	
white	26.460 to 26.580 (1.0319–1.036)
Con-rod width	26.338 to 26.390 (1.0271–1.0292)

Reassembly

1. Install connecting rod
2. Install piston
3. Install piston pin

○Apply a thin coat of engine oil to the piston pin. Try to insert the piston pin into the piston pin hole with normal finger pressure.

NOTE: When changing piston / connecting rod combinations, do not change the piston / piston pin combination and do not reuse the old piston pin.

○Attach the piston to the connecting rod with the piston front mark and the connecting rod front mark on the same side.


○Heat the connecting rod small end to a suitable temperature to ensure smooth installation.

4. Install piston ring with the piston ring expander.

○New piston rings with “Top” uppermost — use commercially available pliers.

○Position ring gaps:

- 1 — Compression rings 180° to each other as illustrated.
- 2 — Offset oil control rings 25 to 50 mm/1 to 2 in. from gap of second compression ring.



○After installation, apply engine oil to the entire circumference of the piston rings. Check to see that all the rings rotate smoothly.

5. Install piston and connecting rod assembly.

○Insert the bearings into the connecting rods and caps. Apply new engine oil to the bearing faces and nuts.

○Tighten the connecting rod cap nuts in 3 steps:

1st step : 35 N-m (26 lb ft)

2nd step: 45°

3rd step: 15°


NOTE: Do not apply engine oil to the bearing back faces.

6. Oil gallery, refer to "Crankshaft and Main Bearing" in this manual.
7. Oil strainer and O-ring.
8. Install balance unit assembly, refer to "Balance Unit Assembly" in this manual.

9. Install oil pan support assembly, refer to "Oil Pan and Oil Pan Support" in this manual.
 10. Install cylinder head gasket.
 11. Install cylinder head assembly.
- Refer to "Cylinder Head" in this manual.

Cylinder Block

Cylinder Block and Associated Parts



015RW008

Legend

- | | |
|----------------------------|--|
| (1) Cylinder Head Assembly | (6) Balance Unit Assembly |
| (2) Oil Pump Assembly | (7) Piston and Connecting Rod Assembly |
| (3) Oil Pan | (8) Main Bearing Cap |
| (4) Oil Pan Support | (9) Crankshaft |
| (5) Oil Strainer | (10) Cylinder Block |

Disassembly

1. Remove cylinder head assembly.
2. Remove cylinder head gasket.
3. Remove oil pan assembly.
4. Remove oil pan support.
5. Remove oil strainer.
6. Remove oil pump assembly.
7. Remove balance unit assembly.
8. Remove piston and connecting rod assembly.
9. Remove flywheel.
10. Remove rear oil seal retainer assembly.
11. Remove main bearing cap.
12. Remove crankshaft.
13. Remove cylinder block.

Inspection and Repair

1. Remove the cylinder head gasket and any other material adhering to the upper surface of the cylinder block. Be very careful not to allow any material to accidentally drop into the cylinder block. Be very careful not to scratch the cylinder block.
2. Carefully remove the oil pump, rear oil seal retainer, and crankcase assembly installation surface seal.
3. Wipe the cylinder block clean.
4. Visually inspect the cylinder block. If necessary, use a flaw detector to perform a dye penetrate and hydraulic (or air pressure) test. If cracking or other damage is discovered, the cylinder block must either be repaired or replaced.

Flatness

1. Using a straight edge and feeler gauge, check that the upper surface of the cylinder block is not warped.


CAUTION: Be very careful not to allow any material to accidentally drop into the upper surface of the cylinder block. Be very careful not to scratch the upper surface of the cylinder block.

2. The cylinder block must be reground or replaced if the warpage exceeds the limit.

Warpage

Limit : 0.40 mm (0.0156 in)

Maximum repairable limit: 0.40 mm (0.0156 in)



012RW013

Cylinder Bore

Use a cylinder gauge to measure the cylinder bore diameter in both the axial and thrust directions. Each measurement should be made at six points.

CAUTION: Be very careful not to allow any material to accidentally drop into the upper surface of the cylinder block. Be very careful not to scratch the upper surface of the cylinder block.

If the measurement exceeds the specified limit, the cylinder block must be replaced.

Diameter

**Grade 1 : 85.975 mm–85.985 mm
(3.3530 in–3.3534 in)**

**Grade 2 : 85.985 mm–86.025 mm
(3.3534 in–3.3550 in)**

Oversize : 0.5 mm (0.0195 in)

NOTE: For information on piston diameter, please refer to the section "Inspection of the Piston and Connecting Rod Assembly" in this manual.


Reassembly

1. Install cylinder block.
2. Install crankshaft.
 - Install the main bearings to the cylinder block and the main bearing caps.
 - Be sure that they are positioned correctly.
 - Apply new engine oil to the upper and lower main bearing faces.

NOTE: Do not apply engine oil to the bearing back faces.

- Carefully mount the crankshaft.
- Apply engine oil to the thrust washer.

3. Install rear oil seal.
 - Coat lip of seal rings thinly with protective grease.
 - Install seal ring into cylinder block, use J-42616 (1) and J-42613 (2).



4. Install flywheel


1. Thoroughly clean and remove the oil from the threads of crankshaft.
2. Remove the oil from the crankshaft and flywheel mounting faces.
3. Mount the flywheel on the crankshaft and then install the washer.
4. Use stopper (J-42618) to hold the crankshaft. Prevent from rotating. Tighten the flywheel bolts in 3 steps:

1st step: 65 N·m (48 lb ft)

2nd step: 30°

3rd step: 15°

NOTE: Do not reuse the bolt.



5. Install piston and connecting rod assembly.


- Apply engine oil to the cylinder bores, the connecting rod bearings and the crankshaft pins.

NOTE: Do not apply engine oil to the bearing back faces.

- Position ring gaps:

1 — Compression rings 180° to each other as illustrated (A).

2 — Offset oil control rings 25 to 50 mm/1 to 2 in. from gap of second compression ring (B).



6. Install balance unit assembly and tighten the bolts in 2 steps in the order shown:

1st step : 20 N·m (14 lb ft)

2nd step : 45°

7. Install oil pump assembly, refer to "Oil Pump" in this manual.


8. Install oil strainer.
9. Install oil pan support.
10. Install oil pan assembly.

6A-60 ENGINE MECHANICAL (X22SE 2.2L)

1. Completely remove all residual sealant, lubricant and moisture from the sealing surfaces. The surfaces must be perfectly dry.
2. Apply a correct width bead of sealant (TB-1207C or its equivalent) to the contact surfaces of the crankcase. There must be no gaps in the bead.
3. The oil pan must be installed within 5 minutes after sealant application.
4. Tighten the bolts and nuts to the specified torque in 2 steps:
1st step : 8 N·m (5.8 lb ft)
2nd step : 30°
11. Install cylinder head gasket.
12. Install cylinder head assembly, refer to "Cylinder Head" in this manual.

Cylinder Head Cover

Cylinder Head Cover and Associated parts




010RW004

Legend

- | | |
|--------------------------|-------------------------|
| (1) Ignition Cable Cover | (2) Spark Plug |
| | (3) Cylinder Head Cover |


Removal

1. Remove two bolts and remove ignition cable cover (1) from cylinder head cover (3).
2. Disconnect ignition cable and remove spark plug (2).
3. Disconnect ignition cable from ignition plug.
4. Disconnect camshaft angle sensor harness and crankshaft angle sensor harness from behind generator.
5. Remove four bolts and remove the crankshaft pulley.



020RW014

6. Remove timing belt front cover.
7. Loose fixing bolt of timing belt rear cover, then remove the camshaft angle sensor.




020RW012

8. Remove ten cylinder head cover fixing bolts and remove the cylinder head cover.

Installation

1. Install the camshaft angle sensor and tighten timing rear cover bolt.

Torque: 8 N·m (5.9 lb ft)



020RW012

2. Install the cylinder head cover and tighten bolts to the specified torque.


Torque: 8 N·m (5.9 lb ft)

3. Install the timing belt front cover then tighten fixing bolts to the specified torque.

Torque: 6 N·m (4.4 lb ft)

4. Install the crankshaft pulley, tighten fixing bolts to the specified torque.


Torque: 20 N·m (14 lb ft)



020RW014

6A-62 ENGINE MECHANICAL (X22SE 2.2L)

5. Move drive belt tensioner to loose side using wrench then install the drive belt to normal position.




033RW001

6. Connect ignition cable to ignition plug.
7. Install ignition cable cover to cylinder head cover and tighten two bolts to the specified torque.

Torque: 3 N·m (2 lb ft)

Balance Unit Assembly

Balance Unit Assembly Associated Parts




051RW012

Legend

- | | |
|---------------------|---------------------------|
| (1) Oil Pan | (3) Oil Strainer |
| (2) Oil Pan Support | (4) Balance Unit Assembly |
| | (5) Shim |


Disassembly

1. Remove the oil pan.
2. Remove the oil pan support.
3. Remove the oil strainer (1) from oil pump and the oil baffle plate (2).




Adjustment


1. Turn crankshaft in engine rotational direction to alignment mark (2) 1st cylinder "TDC".




2. In this crankshaft position, the flattened side (arrows) of both balancer shafts must face downward and must be on a horizontal line.



3. Screw measuring device J-43038 (3) with long knurled bolt (1) into 1st balancer shaft (intake side) and tighter hard-tight measuring arm (5) must point in "9 o'clock" direction shown in this illustration. Install dial gauge holder with dial gauge (4) on cylinder block.



4. Place pre tensioned probe (6) of gauge on measuring arm of measuring device J-43038. The probe must be set precisely between the notch marks, square to the plane surface (7).




5. Determine the left and right stops by turning the knurled bolt (2).


Set the dial of the gauge to zero.

Use the knurled bolt (2) to move the 2nd balancer shaft (exhaust side) back and forth. Again — simultaneously read off the tooth backlash from the gauge.


The permissible tooth backlash is: 0.02 mm to 0.06 mm (0.0008 to 0.0024 in).



6. The tooth backlash must be measured in 4 different positions — turn the crankshaft further at the fastening bolt of the timing belt drive gear by 45° in the engine rotational direction until the measuring arm (2) is at "6 o'clock".



7. Then loosen the knurled bolt (3) fix the measuring arm at "9 o'clock" again and repeat the measurement.



8. If the value determined in one of the 4 measurements lies outside the tolerance 0.02 mm to 0.06 mm (0.0008 to 0.0024 in), the tooth backlash must be adjusted.

6A-66 ENGINE MECHANICAL (X22SE 2.2L)

9. Remove balance unit from cylinder block/crankshaft bearing caps and remove with balancer piece. The balancer piece has a number (code), for easy assignment. The tooth backlash can be adjusted by using a balancer piece with a different thickness.

Code	Thickness of balancer piece in mm
55	0.535 to 0.565
58	0.565 to 0.595
61	0.595 to 0.625
64	0.625 to 0.655
67	0.655 to 0.685
70	0.685 to 0.715
73	0.715 to 0.745
76	0.745 to 0.775
79	0.775 to 0.805
82	0.805 to 0.835
85	0.835 to 0.865

NOTE: The next larger or smaller balancer alters the tooth backlash by 0.02 mm (0.0008 in).


Example of selection of balancer piece: The installed balancer piece with the code “70” gave a tooth backlash of 0.08 mm (0.0031 in).

If a balancer piece with the code “67” is now installed, the tooth backlash will be approx. 0.06 mm (0.0024 in).


CAUTION: Only one balancer piece may be installed.

Reassembly

1. Turn crankshaft in engine rotational direction to alignment mark (2) 1st cylinder “TDC”.



2. Turn balancer shafts until the flattened sides (arrows) of both balancer shafts face downward and are on a horizontal line.



3. Install selected balancer piece (2) with balancer shaft unit to cylinder block/crankshaft bearing cap — tighten all fixing bolts to the specified torque.

Torque: 20 N·m (15 lb ft)

4. After installing the balancer shaft unit, recheck the tooth backlash and readjust if necessary.

NOTE: If the balancer shaft unit has to be replaced, use the thickest balancer piece with the code “85” for the initial assembly — this guarantees tooth backlash in all conditions.


5. Install oil strainer to oil pump with new seal ring and insert fixing bolts with locking agent to the specified torque.

Torque: 8 N·m (6 lb ft)

6. Install oil pan support.

Torque: 20 N·m (14 lb ft)

- Adjust surfaces of the cylinder block and the oil pan support.



035RW026

7. Install oil pan.


1st step: 8 N·m (5.8 lb ft)

2nd step: 30°

Main Data and Specifications


Torque Specifications

Camshaft bracket, Timing gear camshaft side, Cylinder head



011RW021


Timing gear crankshaft (center bolt), Timing belt cover front, Timing belt cover rear, Timing belt tensioner, Camshaft angle sensor



020RW011


6A-70 ENGINE MECHANICAL (X22SE 2.2L)

Crankshaft main bearing, Oil pan support, Oil pan, Balance unit assembly, Connrod Cap, Oil pump, Oil strainer




015RW023

Spark plug, Throttle body, EGR valve adaptor assembly, Bypass housing assembly, Thermostat assembly, inlet manifold assembly, Exhaust manifold assembly, heat shield, Ignition cable cover



011RW022

Engine mount



022RW010

Special Tools











ILLUSTRATION	TOOL NO. TOOL NAME
 015RW027	J-42613 Installer; Rear crankshaft seal ring
 015RW030	J-42609 Remover/Installer; Crankshaft carrier seal
 901RW106	J-8062 Compressor; Valve spring (Use with J-3289-20 base)
 901RW185	J-43037 Locking tool camshaft gear
 015RW031	J-42616 Installer; Rear crankshaft seal
 015RW035	J-42618 Locking device; Flywheel

ILLUSTRATION	TOOL NO. TOOL NAME
 015RW034	J-42619 Adapter; Valve spring
 011RW026	J-42622 Installer sleeve; Valve stem seal
 015RW028	J-42623 Socket wrench; Cylinder head bolt
 015RW033	J-42620 Holding wrench; Driven gear fix

RODEO

ENGINE

ENGINE COOLING (X22SE 2.2L)

CONTENTS


Service Precaution	6B-1	Removal	6B-6
General Description	6B-2	Inspection	6B-6
Diagnosis	6B-4	Installation	6B-6
Draining and Refilling Cooling System	6B-4	Radiator	6B-7
Water Pump	6B-5	Radiator and Associated Parts	6B-7
Water Pump and Associated Parts	6B-5	Removal	6B-7
Removal	6B-5	Inspection	6B-8
Inspection	6B-5	Installation	6B-8
Installation	6B-5	Main Data and Specifications	6B-9
Thermostat	6B-6	Special Tool	6B-9

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



111RW001


Legend

- | | |
|------------------|-----------------------------|
| (1) Water Pump | (5) Coolant Distributor |
| (2) Thermostat | (6) Cylinder Block and Head |
| (3) Radiator | (7) Throttle Body |
| (4) Reserve Tank | (8) Heater |

The Cooling System is a pressurized type, where the water pump, which is cambelt driven, forces the circulation of the coolant through the cylinder block and head. The thermostat regulates the flow of coolant between the radiator and the bypass circuit. The heater is part of the bypass circuit. The throttle body pre-heat is a separate circuit which is not regulated by the thermostat. An oil cooler may be fitted as part of this circuit.

Water Pump


The water pump is centrifugal type and is driven by timing belt.



030RW003

Thermostat


The thermostat is a bypass type and is a wax pellet type with a air hole (1).



031RW003

Radiator

The radiator is a flow type with corrugated fins.



110RX005

Antifreeze Solution

- Relation between Mixing ratio and Freezing temperature of the engine coolant varies with the ratio of antifreeze solution in water. Proper mixing ratio can be determined by referring to the chart. Supplemental inhibitors or additives claiming to increase cooling capability that have not been specifically approved by Isuzu are not recommended for addition to the cooling system.

○ Calculating mixing ratio


Mixing ratio

$$= \frac{\text{Antifreeze solution (Lit/gal.)}}{\text{Antifreeze solution (Lit/gal.)} + \text{Water (Lit/gal.)}}$$

F06RW005

NOTE: Antifreeze solution + Water = Total cooling system capacity.

- **Total Cooling System Capacity**
7.2Lit (1.90US gal)



111RW002

○ Mixing ratio

Check the specific gravity of engine coolant in the cooling system temperature ranges from 0°C to 50°C using a suction type hydrometer, then determine the density of the engine coolant by referring to the table.

Diagnosis

Engine Cooling Trouble

Condition	Possible cause	Correction
Engine overheating	Low Engine Coolant level	Replenish
	Thermo mater unit faulty	Replace
	Faulty thermostat	Replace
	Faulty Engine Coolant temperature sensor	Repair or replace
	Clogged radiator	Clean or replace
	Faulty radiator cap	Replace
	Low engine oil level or use of improper engine oil	Replenish or change oil
	Clogged exhaust system	Clean exhaust system or replace faulty parts
	Faulty Throttle Position sensor	Replace throttle valve assembly
	Open or shorted Throttle Position sensor circuit	Repair or replace
	Damaged cylinder head gasket	Replace
Engine overcooling	Faulty thermostat	Replace
Engine slow to warm-up	Faulty thermostat	Replace
	Thermo unit faulty	Replace

Draining and Refilling Cooling System

Before draining the cooling system, inspect the system and perform any necessary service to ensure that it is clean, does not leak and is in proper working order. The engine coolant (EC) level should be between the "MIN" and "MAX" lines of reserve tank when the engine is cold. If low, check for leakage and add EC up to the "MAX" line. There should not be any excessive deposit of rust or scales around the radiator cap or radiator filler hole, and the EC should also be free from oil. Replace the EC if excessively dirty.

1. Completely drain the cooling system by opening the drain plug at the bottom of the radiator.
2. Remove the radiator cap.


WARNING: TO AVOID THE DANGER OF BEING BURNED, DO NOT REMOVE THE CAP WHILE THE ENGINE AND RADIATOR ARE STILL HOT. SCALDING FLUID AND STEAM CAN BE BLOWN OUT UNDER PRESSURE.

3. Disconnect all hoses from the EC reserve tank. Scrub and clean the inside of the reserve tank with soap and water. Flush it well with clean water, then drain it. Install the reserve tank and hoses.
4. Refill the cooling system with the EC using a solution that is at least 50 percent antifreeze but no more than 70 percent antifreeze.

4. Refill the cooling system with the EC using a solution that is at least 50 percent antifreeze but no more than 70 percent antifreeze.
5. Fill the radiator to the base of the filler neck. Fill the EC reserve tank to "MAX" line when the engine is cold.
6. Block the drive wheels and firmly apply the parking brake. Shift an automatic transmission to "P" (Park) or a manual transmission to neutral.
7. Remove the radiator cap. Start the engine and warm it up at 2,500 ~ 3,000 rpm for about 30 minutes.
8. When the air comes out from the radiator filler neck and the EC level has gone down, replenish with the EC. Repeat this procedure until the EC level does not go down. Then stop the engine and install the radiator cap. Let the engine cool down.
9. After the engine has cooled, replenish with EC up to the "MAX" line of the reserve tank.
10. Start the engine. With the engine running at 3,000 rpm, make sure there is no running water sound from the heater core (behind the center console).
11. If the running water sound is heard, repeat steps 8 to 10.

Water Pump

Water Pump and Associated Parts



030RW004

Legend

(1) Water Pump Assembly

(2) O Ring

(3) Bolt

Removal

1. Disconnect battery ground cable.
2. Drain coolant.
3. Radiator hose (on inlet pipe side).
4. Remove timing belt, refer to "Timing Belt" in this manual.
5. Remove water pump assembly.

Inspection

Make necessary repair and parts replacement if extreme wear or damage is found during inspection. Should any of the following problems occur, the entire water pump assembly must be replaced:

- ☐ Crack in the water pump body
- ☐ EC leakage from the seal unit
- ☐ Play or abnormal noise in the bearing
- ☐ Cracks or corrosion in the impeller

Installation

1. Before installing water pump, coat sealing surface with silicon grease.
2. Install water pump assembly and tighten bolts to the specified torque.

Torque: 25 N·m (18 lb ft)

3. Timing belt


☐ Install timing belt, refer to timing belt installation step in "Timing Belt" in this manual.

4. Connect radiator hose and replenish EC.
5. Connect battery ground cable.

Thermostat

Removal

1. Disconnect battery ground cable.
2. Drain engine coolant from the radiator and engine.
3. Disconnect radiator hose from the inlet pipe.
4. Remove thermostat housing.



Installation

1. Before installing thermostat, coat sealing surface with silicon grease.
2. Install gasket.
3. Install thermostat housing and tighten bolts to the specified torque.

Torque: 15 N·m (11 lb ft)

4. Install rubber hose.
5. Replenish engine coolant (EC).
6. Start engine and check for EC leakage.

Inspection

Suspend the thermostat in a water-filled container using thin wire. Place a thermometer next to the thermostat. Do not directly heat the thermostat. Gradually increase the water temperature. Stir the water so that the entire water is same temperature. Confirm the temperature when the valve first begins to open.

Valve opening temperature 92°C (197.6°F)


Confirm the temperature when the valve is fully opened.

Valve full open temperature 107°C (224.6°F)

Make necessary repair and parts replacement if extreme wear or damage is found during inspection.

Radiator

Radiator and Associated Parts




110RX004

Legend

- | | |
|--------------------------|---------------------|
| (1) Radiator | (4) Radiator Cap |
| (2) Bracket | (5) Radiator Hose |
| (3) Cooling Fan Assembly | (6) Lower Fan Guide |

Removal

1. Disconnect battery ground cable.
2. Disconnect cooling fan motor connector.
3. Loosen a drain plug to drain EC.
4. Disconnect radiator inlet hose and outlet hose from the engine.
5. Remove fan guide, clips on both sides and the bottom lower with fan shroud.
6. Disconnect the reserve tank hose from radiator.
7. Remove bracket(2).



110RX003

6B-8 ENGINE COOLING (X22SE 2.2L)

8. Lift out the radiator assembly with hose, taking care not to damage the radiator core with fan blade.
9. Remove rubber cushions on both sides at the bottom.

Inspection

Radiator Cap

Measure the valve opening pressure of the pressurizing valve with a radiator filler cap tester. Replace the cap if the valve opening pressure is outside the standard range.


**Valve opening pressure kPa (psi) 93.3 ~ 122.7
(13.5 ~ 17.8)**

Cap tester: J-24460-01

Adapter: J-33984-A

Check the condition of the vacuum valve in the center of the valve seat side of the cap. If considerable rust or dirt is found, or if the valve seat cannot be moved by hand, clean or replace the cap.

**Valve opening vacuum kPa (psi) 1.96 ~ 4.91
(0.28 ~ 0.71)**



110RS006

Radiator Core

1. A bent fin may result in reduced ventilation and overheating may occur. All bent fins must be straightened. Pay close attention to the base of the fin when it is being straightened.
2. Remove all dust, bugs and other foreign material.

Flushing the Radiator

Thoroughly wash the inside of the radiator and the engine coolant passages with cold water and mild detergent. Remove all sign of scale and rust.


Cooling System Leakage Check

Use a radiator cap tester to force air into the radiator through the filler neck at the specified pressure of 196 kPa (28.5 psi) with a cap tester:

- Leakage from the radiator
- Leakage from the coolant pump
- Leakage from the water hoses
- Check the rubber hoses for swelling.

Cap tester: J-24460-01


Adapter: J-33984-A



110RX002

Installation

1. Install rubber cushions on both sides of radiator bottom.
2. Install radiator assembly with hose, taking care not to damage the radiator core with a fan blade.
3. Install bracket and support the radiator upper tank with the bracket and secure the radiator.
4. Connect reserve tank hose.
5. Install lower fan guide (6).
6. Connect radiator inlet hose and outlet hose to the engine.



110RX003

7. Connect battery ground cable.
8. Pour engine coolant up to filler neck of radiator, and up to MAX mark of reserve tank.
Important operation (in case of 100% engine coolant change) procedure for filling with engine coolant.
 - Remove radiator cap.
 - Fill with engine coolant (EC) to the radiator filler neck.
 - Fill with EC to the "MAX" line on the reservoir.
 - Start the engine with the radiator cap removed and bring to operating temperature by running engine at 2,500 ~ 3,000 rpm for 30 minutes.
 - By EC temperature gauge reading make sure that the thermostat is open.



- If air bubbles come up to the radiator filler neck, replenish with EC. Repeat until the EC level does not drop any further. Install the radiator cap and stop the engine.
- Replenish EC to the "MAX" line on the reservoir and leave as it is until the engine gets cool.
- After the engine gets cool, start the engine and make sure there is no water running noise heard from the heater core while the engine runs at 3000 rpm.
- Should water running noise be heard, repeat the same procedure from the beginning.

Main Data and Specifications

General Specifications

Cooling system	Engine Coolant forced circulation
Radiator	(1 tube in row) Tube type corrugated
Heat radiation capacity	54,000 kcal/h (62.8 kw)
Heat radiation area	7.677m ² (0.878ft ²)
Radiator front area	0.264m ² (0.028ft ²)
Radiator dry weight (with fan)	32N (7.2lb)
Radiator cap valve opening pressure	93.3 ~ 122.7kpa (13.5 ~ 17.8psi)
Engine coolant capacity	1.8lit (0.48 US gal)
Engine coolant pump	Centrifugal type
Thermostat	Bypass type
Engine coolant total capacity	7.2lit (1.9 US gal)

Special Tool

ILLUSTRATION	TOOL NO. TOOL NAME
 901RW072	J-24460-01 Tester; radiator cap
 901RW073	J-33984-A Adapter; radiator cap

RODEO

ENGINE

ENGINE FUEL (X22SE 2.2L)

CONTENTS


Service Precaution	6C-1	Cautions During Work	6C-7
General Description	6C-2	Removal	6C-7
Fuel Metering	6C-3	Reuse of Quick-Connector	6C-9
Fuel Filter	6C-4	Assembling Advice	6C-9
Fuel Filter and Associated Parts	6C-4	Fuel Pump Relay	6C-10
Removal	6C-4	General Description	6C-10
Inspection	6C-4	Fuel Tank	6C-10
Installation	6C-4	Fuel Tank and Associated Parts	6C-10
Inspection	6C-4	Removal	6C-11
In-Tank Fuel Filter	6C-4	Installation	6C-11
Fuel Pump Flow Test	6C-5	Fuel Gage Unit	6C-11
Fuel Pump	6C-6	Removal and Installation	6C-11
Fuel Pump and Associated Parts	6C-6	Fuel Filler Cap	6C-12
Removal	6C-6	General Description	6C-12
Installation	6C-6	Inspection	6C-12
Fuel Tube / Quick – Connector Fittings	6C-7	Main Data and Specifications	6C-13
Precautions	6C-7	Special Tool	6C-13

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



140RX008

Legend

- | | |
|-----------------------------------|---------------------------------|
| (1) Fuel Filter Cap | (7) Intake Manifold |
| (2) Fuel Tank | (8) Fuel Pressure Control Valve |
| (3) Rollover Valve | (9) Duty Solenoid Valve |
| (4) Fuel Pump and Sender Assembly | (10) Throttle Valve |
| (5) Fuel Filter | (11) Canister |
| (6) Fuel Rail | (12) Evapo Pipe |

When working on the fuel system, there are several things to keep in mind:

- Any time the fuel system is being worked on, disconnect the negative battery cable except for those tests where battery voltage is required.
- Always keep a dry chemical (Class B) fire extinguisher near the work area.
- Replace all pipes with the same pipe and fittings that were removed.
- Clean and inspect "O" rings. Replace if required.
- Always relieve the line pressure before servicing any fuel system components.
- Do not attempt repairs on the fuel system until you have read the instructions and checked the pictures relating to that repair.
- Adhere to all Notices and Cautions.

All gasoline engines are designed to use only unleaded gasoline. Unleaded gasoline must be used for proper emission control system operation.

Its use will also minimize spark plug fouling and extend engine oil life. Using leaded gasoline can damage the emission control system and could result in loss of emission warranty coverage.

All cars are equipped with an Evaporative Emission Control System. The purpose of the system is to minimize the escape of fuel vapors to the atmosphere.

Fuel Metering

The Powertrain Control Module (PCM) is in complete control of this fuel delivery system during normal driving conditions.

The intake manifold function, like that of a diesel, is used only to let air into the engine. The fuel is injected by separate injectors that are mounted over the intake manifold.

The Manifold Absolute Pressure (MAP) sensor measures the changes in the intake manifold pressure which result from engine load and speed changes, which the MAP sensor converts to a voltage output.

This sensor generates the voltage to change corresponding to the flow of the air drawn into the engine. The changing voltage is transformed into an electric signal and provided to the PCM.

With receipt of the signals sent from the MAP sensor, Intake Air Temperature sensor and others, the PCM determines an appropriate fuel injection pulse width feeding such information to the fuel injector valves to effect an appropriate air/fuel ratio.

The Multiport Fuel Injection system utilizes an injection system where the injectors turn on at every crankshaft revolution. The PCM controls the injector on time so that the correct amount of fuel is metered depending on driving conditions.

Two interchangeable "O" rings are used on the injector that must be replaced when the injectors are removed.

The fuel rail is attached to the top of the intake manifold and supplies fuel to all the injectors.


Fuel is recirculated through the rail continually while the engine is running. This removes air and vapors from the fuel as well as keeping the fuel cool during hot weather operation.

The fuel pressure control valve that is mounted on the fuel rail maintains a pressure differential across the injectors under all operating conditions. It is accomplished by controlling the amount of fuel that is recirculated back to the fuel tank based on engine demand.

See Section "Driveability and Emission" for more information and diagnosis.

Fuel Filter

Fuel Filter and Associated Parts



140RX007

Legend

- (1) Fuel Hose
- (2) Fuel Filter

- (3) Fuel Filter Holder
- (4) Fuel Hose

Removal

CAUTION: When repair to the fuel system has been completed, start engine and check the fuel system for loose connections or leakage. For the fuel system diagnosis, see Section "Driveability and Emission".

1. Disconnect battery ground cable.
2. Remove fuel filler cap.
3. Disconnect fuel hoses(1) from fuel filter on both engine side and fuel tank side.
4. Fuel filter fixing bolt.
 - Remove the fuel filter fixing bolt on fuel filter holder(3).
5. Remove fuel filter(2).

Inspection

1. Replace the fuel filter if the fuel leaks from fuel filter body or if the fuel filter body itself is damaged.
2. Replace the filter if it is clogged with dirt or sediment.
3. Check the drain and if it is clogged with dust, clean it out with air.

Installation

1. Install the fuel filter in the proper direction.
2. Install fuel filter holder fixing bolt.
3. Connect fuel hoses on engine side and fuel tank side.
4. Install fuel filler cap
5. Connect the battery ground cable.

Inspection

After installation, start engine and check for fuel leak age.


In-Tank Fuel Filter

The filter is located on the lower end of the fuel pickup tube in the fuel tank. It prevents dirt from entering the fuel pipe and also stops water unless the filter is completely submerged in the water. It is a self cleaning type, not requiring scheduled maintenance. Excess water and sediment in the tank restricts fuel supply to the engine, resulting in engine stop. In such a case, the tank must be cleaned thoroughly.

Fuel Pump Flow Test

If reduction of fuel supply is suspected, perform the following checks.

1. Make sure that there is fuel in the tank.
2. With the engine running, check the fuel feed pipe and hose from fuel tank to injector for evidence of leakage. Retighten, if pipe or hose connection is loose. Also, check pipes and hoses for squashing or clogging.
3. Insert the hose from fuel feed pipe into a clean container, and check for fuel pump flow rate.
4. Connect the pump relay terminals with a jumper wire(1) as shown and start the fuel pump to measure delivery.



CAUTION: Never generate sparks when connecting a jumper wire.

Delivery	Delivery
15 seconds	0.38 liters minimum


If the measure value is out of standard, conduct the pressure test.

Pressure test

For the pressure test to the fuel system, see Section 6E "Fuel Control System".

Fuel Pump

Fuel Pump and Associated Parts



140RX004

Legend

- | | |
|-----------------------------------|-----------------------------------|
| (1) Fuel Feed Port | (6) Connector; Fuel Level Sensor |
| (2) Fuel Tube/Quick Connector | (7) Snap Ring (or Fuel pump lock) |
| (3) Fuel Return Port | (8) Hose; Evaporative Fuel |
| (4) Fuel Pump and Sender Assembly | (9) Hose; Air Breather |
| (5) Connector; Fuel Feed Pump | (10) Hose; Fuel Filler |
| | (11) Fuel Tank Assembly |

Removal

CAUTION: When repair to the fuel system has been completed, start engine and check the fuel system for loose connection or leakage. For the fuel system diagnosis, see Section "Driveability and Emission".

1. Disconnect battery ground cable.
2. Loosen fuel filler cap.
3. Support underneath of the fuel tank assembly (11) with a lifter.
4. Remove fuel tank assembly(11). Refer to "Fuel Tank Removal" in this section.
5. Remove Fuel Tube/Quick Connector (2).

NOTE: Handling of the fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

6. Remove fuel pump and sender (FPAS) assembly(4) fixing snapping and remove the FPAS assembly.

NOTE:

- After removing pump assembly (4), cover fuel tank to prevent any dust entering.
- Remove the fuel pump lock, when using J-39763.

Installation

1. Install FPAS assembly(4).
2. Install Fuel Tube/Quick Connector (2).

NOTE: Handling of the fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

3. Install fuel tank assembly(11). Refer to "Fuel Tank Installation".
4. Fill the tank with fuel and tighten fuel filler cap.
5. Connect battery ground cable.

Fuel Tube / Quick – Connector Fittings

Precautions

- Lighting of Fires Prohibited.
- Keep flames away from your work area to prevent the inflammable from catching fire.
- Disconnect the battery negative cable to prevent shorting during work.
- When welding or conducting other heat-generating work on other parts, be sure to provide pretreatment to protect the piping system from thermal damage or spattering.

Cautions During Work


Do not expose the assembly to battery electrolyte or do not wipe the assembly with a cloth used to wipe off spilt battery electrolyte.

The piping wet with battery electrolyte cannot be used. Be careful not to give a bending or twisting force to the piping during the work. If deformed, replace with a new piping.

Removal

1. Open the fuel cap to relieve the fuel pressure in the tank.

If the fuel quick-connect fittings are dusty, clean with an air blower, etc. and then remove it.




141RW036

As some pressure may remain in the piping, cover the connector with a cloth, etc. to prevent the splashing of fuel in the first disconnection of the piping.


6C-8 ENGINE FUEL (X22SE 2.2L)

2. For removal of the delivery pipe (feeding fuel to the engine), hold the connector in one hand, and hold the retainer tab with the other hand and pull out the connector, as illustrated. The pipe can be removed with the retainer attached.




141RW019

3. For removal of the return pipe (returning fuel to the tank), hold the pipe in one hand, and pull out the connector with the other hand while pressing the square relieve button of the retainer, as illustrated.



141RW020


NOTE: This work should be done by hands. Do not use any tools. Should the pipe can hardly be removed from the connector, use a lubricant (light oil) and/or push and pull the connector longitudinally until the pipe is removed.



141RW021

When reusing the delivery pipe retainer, reuse without removing the retainer from the pipe. If the retainer is damaged or deformed, however, replace with a new retainer.

Cover the connectors removed with a plastic bag, etc. to prevent the entry of dust or rain water.




141RW022

Reuse of Quick-Connector

(Delivery Pipe)

- Replace the pipe and connector if scratch, dent or crack is found.
- Remove mud and dust from the pipe and make sure that the end including spool is free of defects, such as scratch, rust, and dent, which may cause poor sealability. If defective, replace with a new pipe.
- If the retainer removed according to the removal step above is attached to the pipe, clean and insert it straight into the quick-connector till it clicks. After it clicks, try pulling it out to make sure that it is not drawn and is securely locked.


NOTE: The retainer, once removed from the pipe, cannot be reused. Just replace with a new retainer. Insert the new retainer into the connector side until it clicks, and connect the pipe as inserting it into the retainer until it clicks.



141RW018

(Return Pipe)

- Replace the pipe and connector if scratch, dent or crack is found.
- Remove mud or dust from the pipe and make sure that the end including spool is free from defects, such as scratch, rust, and dent, which may cause poor sealability. If defective, replace with a new pipe.
- After cleaning the pipe, insert it straight into the connector until it clicks. After it clicks, try pulling it out to make sure that it is not drawn and is securely locked.



141RW017

Assembling Advice

Application of engine oil or light oil to the pipe facilitates connecting work. The work should be started immediately after lubrication, since dust may stick to the pipe surface to cause poor sealability if a long time passes after lubrication.

Test/Inspection After Assembling

1. Reconnect the battery negative cable.
2. Turn the ignition key to the "ON" position and check pump startup sound. As the pump is actuated to raise fuel pressure, check and see fuel leak from the piping system.
3. Make sure of no fuel leakage by conducting the above fuel leak check a few times.
4. Start the engine and make sure of stable idling speed and normal vehicle run. The entry of dust during the work may sometimes affect the fuel injection system.

Fuel Pump Relay


General Description

In order to control the FPAS operation, the FPAS relay is provided. When the starter switch is turned to "ON" position, the FPAS relay operates the FPAS for 2 seconds.

When it is turned to "START" position, the Engine Control Module receives the reference pulse from the Ignition Control Module and it operates the relay, again causing the FPAS to feed fuel.

Fuel Tank

Fuel Tank and Associated Parts



140RX005

Legend

- | | |
|--------------------------------------|------------------------------------|
| (1) Roll Over&Float Valve | (10) Fuel Pump and Sender Assembly |
| (2) Retaining Cover | (11) Fuel Feed Port |
| (3) Hose; Evaporative Fuel | (12) Fuel Tube/Quick Connector |
| (4) Hose; Air Breather | (13) Fuel Return Port |
| (5) Hose; Fuel Filler | (14) Bolt; Fuel Tank Asm. Fixing |
| (6) Bolt; Fuel Tank Protector Fixing | (15) Protector; Fuel Tank |
| (7) Snap Ring | (16) Fuel Tank Assembly |
| (8) Connector; Fuel Level Sensor | (17) Hose; Fuel Feed |
| (9) Connector; Fuel Feed Pump | (18) Hose; Fuel Return |
| | (19) Protector; Heat |

Removal

CAUTION: When repair to the fuel system has been completed, start engine and check the fuel system for loose connection or leakage. For the fuel system diagnosis, see Section "Driveability and Emission".

1. Disconnect battery ground cable.
2. Loosen fuel filler cap.
3. Support underneath of the fuel tank protector (15) with a lifter.
4. Disconnect evaporative fuel hose (3) at the canister.
5. Disconnect fuel feed hose (17) and fuel return hose (18) near the fuel filter.

NOTE: Plug both ends of the fuel hoses to prevent fuel leakage.

6. Disconnect air breather hose (4) and fuel filler hose (5) at the fuel filler neck.

NOTE: Cover fuel hose to prevent any dust entering.

7. Remove the four fuel tank assembly fixing bolts (14) at four corners of the tank.
8. Let down the tank and disconnect the wiring connectors (8,9) and the emission hose at the emission port on the fuel pump and sending assembly (10).
9. Remove fuel tank assembly along with protectors (15,19) .
10. Remove retaining cover (2) and roll over&float valve (1) along with the evaporative fuel hose and pipe (3).
11. Remove Fuel Tube/Quick Connector (12).

NOTE: Handling of fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

12. Remove fuel pump and sender assembly (10) by removing the snap ring (7) along with the fuel hoses (17,18).
13. Remove protectors (15,19) by removing the six fixing bolts (6).

Installation

1. Install protectors (15,19) and tighten the six fixing bolts to the specified torque.

Torque: 68 N·m (50 lb ft)

2. Install fuel pump and sender assembly by fitting in the snap ring (7).
3. Install Fuel Tube/Quick Connector (12).

NOTE: Handling of fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

4. Install roll over&float valve (1) by fitting in the retaining cover (2).
5. Lift up fuel tank assembly and connect the emission hose to the emission port and the wiring connectors (8,9) on the fuel pump and sending assembly (10).
6. Install fuel tank assembly along with protectors and tighten the four fixing bolts to the specified torque.

Torque: 68 N·m (50 lb ft)

7. Connect fuel filler hose (5) and air breather hose (4), and clip them firmly.
8. Connect fuel feed hose (17) and fuel return hose (18), and clip them firmly.
9. Connect evaporative fuel hose (3).
10. Tighten fuel filler cap.
11. Connect battery ground cable.

Fuel Gage Unit

Removal and Installation


As for removal and installation of the Fuel Gauge Unit, refer to "Fuel Tank" of this section 6C as the fuel gauge unit is combined with the fuel pump and sender assembly.

Fuel Filler Cap

General Description

Fuel filler cap includes vacuum valve.

In case any high vacuum happen in tank, the valve works to adjust the pressure to prevent the tank from being damaged.



Legend

- (1) Vacuum Valve
- (2) Fuel Filler Cap

Inspection

Check the seal ring in the filler cap for presence of any abnormality and for seal condition.

Replace the filler cap, if abnormal.


CAUTION:

The fuel filler cap valve has characteristics.


A defective valve, no valve at all or a valve with the wrong characteristics will do a lot of harm to engine operating characteristics; be sure to use the same fuel filler cap as installed in this vehicle.

Main Data and Specifications

Torque Specification



Special Tool

ILLUSTRATION	TOOL NO. TOOL NAME
 140RW009	J-39763 Remover; fuel pump lock (For S/W)

RODEO

ENGINE

ENGINE ELECTRICAL (X22SE 2.2L)

CONTENTS

Service Precaution	6D1-1	Jump Starting	6D1-3
Battery	6D1-2	Battery Removal	6D1-4
General Description	6D1-2	Battery Installation	6D1-4
Diagnosis	6D1-2	Main Data and Specifications	6D1-5
Battery Charging	6D1-3		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Battery

General Description

There are six battery fluid caps on top of the battery. These are covered by a paper label.

The battery is completely sealed except for the six small vent holes on the side. These vent holes permit the escape of small amounts of gas generated by the battery. This type of battery has the following advantages over conventional batteries:

1. There is no need to add water during the entire service life of the battery.
2. The battery protects itself against overcharging. The battery will refuse to accept an extensive charge. (A conventional battery will accept an excessive charge, resulting in gassing and loss of battery fluid.)
3. The battery is much less vulnerable to self discharge than a conventional type battery.

Diagnosis

1. Visual Inspection

Inspect the battery for obvious physical damage, such as a cracked or broken case, which would permit electrolyte loss.

Replace the battery if obvious physical damage is discovered during inspection.

Check for any other physical damage and correct it as necessary.


2. Hydrometer Check

There is a built-in hydrometer (Charge test indicator(1)) at the top of the battery. It is designed to be used during diagnostic procedures.

Before trying to read the hydrometer, carefully clean the upper battery surface.

If your work area is poorly lit, additional light may be necessary to read the hydrometer.


- a. BLUE RING OR DOT VISIBLE(5) – Go to Step 4.
- b. BLUE RING OR DOT NOT VISIBLE(4) – Go to Step 3.



3. Fluid Level Check

The fluid level should be between the upper level line(2) and lower level line(3) on side of battery.

- a. CORRECT FLUID LEVEL – Charge the battery.
- b. BELOW LOWER LEVEL – Replace battery.



061RX001

4. Voltage Check

1. Put voltmeter test leads to battery terminals.
 - a. VOLTAGE IS 12.4V OR ABOVE – Go to Step 5.
 - b. VOLTAGE IS UNDER 12.4V – Go to procedure (2) below.
2. Determine fast charge amperage from specification. (See Main Data and Specifications in this section). Fast charge battery for 30 minutes at amperage rate no higher than specified value. Take voltage and amperage readings after charge.
 - a. VOLTAGE IS ABOVE 16V AT BELOW 1/3 OF AMPERAGE RATE – Replace battery.
 - b. VOLTAGE IS ABOVE 16V AT ABOVE 1/3 OF AMPERAGE RATE – Drop charging voltage to 15V and charge for 10 – 15 hours. Then go to Step 5.
 - c. VOLTAGE IS BETWEEN 12V AND 16V – Continue charging at the same rate for an additional 3–1/2 hours. Then go to Step 5.
 - d. VOLTAGE BELOW 12V – Replace Battery.

5. Load Test

1. Connect a voltmeter and a battery load tester across the battery terminals.
2. Apply 300 ampere load for 15 seconds to remove surface charge from the battery. Remove load.
3. Wait 15 seconds to let battery recover. Then apply specified load from specifications (See Main Data and Specifications in this section). Read voltage after 15 seconds, then remove load.

061RX001

- a. VOLTAGE DOES NOT DROP BELOW THE MINIMUM LISTED IN THE TABLE – The battery is good and should be returned to service.
- b. VOLTAGE IS LESS THAN MINIMUM LISTED – Replace battery.

ESTIMATED TEMPERATURE		MINIMUM VOLTAGE
°F	°C	V
70	21	9.6
60	16	9.5
50	10	9.4
40	4	9.3
30	-1	9.1
20	-7	8.9
10	-12	8.7
0	-18	8.5
The battery temperature must be estimated by feel and by the temperature the battery has been exposed to for the preceding few hours.		

Battery Charging

Observe the following safety precautions when charging the battery:

- Never attempt to charge the battery when the fluid level is below the lower level line on the side of the battery. In this case, the battery must be replaced.
- Pay close attention to the battery during charging procedure.
Battery charging should be discontinued or the rate of charge reduced if the battery feels hot to the touch.
battery charging should be discontinued or the rate of charge reduced if the battery begins to gas or spew electrolyte from the vent holes.
- In order to more easily view the hydrometer blue dot or ring, it may be necessary to jiggle or tilt the battery.
- Battery temperature can have a great effect on battery charging capacity.
- The sealed battery used on this vehicle may be either quick charged or slow charged in the same manner as other batteries.
Whichever method you decide to use, be sure that you completely charge the battery. Never partially charge the battery.

Jump Starting

Jump Starting with an Auxiliary (Booster) Battery

CAUTION: Never push or tow the vehicle in an attempt to start it. Serious damage to the emission system as well as other vehicle parts will result.

Treat both the discharged battery and the booster battery with great care when using jumper cables. Carefully follow the jump starting procedure, being careful at all times to avoid sparking.

WARNING: FAILURE TO CAREFULLY FOLLOW THE JUMP STARTING PROCEDURE COULD RESULT IN THE FOLLOWING:

- Serous personal injury, particularly to your eyes.
- Property damage from a battery explosion, battery acid, or an electrical fire.
- Damage to the electronic components of one or both vehicles particularly.

Never expose the battery to an open flame or electrical spark. Gas generated by the battery may catch fire or explode.

Remove any rings, watches, or other jewelry before working around the battery. Protect your eyes by wearing an approved set of goggles.

Never allow battery fluid to come in contact with your eyes or skin.

Never allow battery fluid to come in contact with fabrics or painted surfaces.

Battery fluid is a highly corrosive acid.

Should battery fluid come in contact with your eyes, skin, fabric, or a painted surface, immediately and thoroughly rinse the affected area with clean tap water.

Never allow metal tools or jumper cables to come in contact with the positive battery terminal, or any other metal surface of the vehicle. This will protect against a short circuit.

Always keep batteries out of reach of young children.

Jump Starting Procedure

- Set the vehicle parking brake.

If the vehicle is equipped with an automatic transmission, place the selector level in the "PARK" position.

If the vehicle is equipped with a manual transmission place the shift lever in the "NEUTRAL" position.

Turn "OFF" the ignition.

Turn "OFF" all lights and any other accessory requiring electrical power.

- Look at the built-in hydrometer.

If the indication area of the built-in hydrometer is completely clear, do not try to jump start.

6D1-4 ENGINE ELECTRICAL (X22SE 2.2L)

3. Attach the end of one jumper cable to the positive terminal of the booster battery.
Attach the other end of the same cable to the positive terminal of the discharged battery.

Do not allow the vehicles to touch each other. This will cause a ground connection, effectively neutralizing the charging procedure.

Be sure that the booster battery has a 12 volt rating.

4. Attach one end of the remaining cable to the negative terminal of the booster battery.

Attach the other end of the same cable to a solid engine ground (such as the air conditioning compressor bracket or the generator mounting bracket) of the vehicle with the discharged battery.

The ground connection must be at least 450 mm (18 in.) from the battery of the vehicle whose battery is being charged.

WARNING: NEVER ATTACH THE END OF THE JUMPER CABLE DIRECTLY TO THE NEGATIVE TERMINAL OF THE DEAD BATTERY.

5. Start the engine of the vehicle with the good battery.
Make sure that all unnecessary electrical accessories have been turned "OFF".
6. Start the engine of the vehicle with the dead battery.
7. To remove the jumper cables, follow the above directions in reverse order.
Be sure to first disconnect the negative cable from the vehicle with the discharged battery.

Battery Installation


1. Install battery (5).
2. Install retainer (4).
3. Install retainer screw and rods (3).

NOTE: Make sure that the rod is hooked on the body side.

4. Install positive cable (2).
5. Install negative cable (1).

Battery Removal

1. Remove negative cable (1).
2. Remove positive cable (2).
3. Remove retainer screw and rods (3).
4. Remove retainer (4).
5. Remove battery (5).



061RX002

Main Data and Specifications**General Specifications**

Model	24-600
Voltage (V)	12
Cold Cranking Performance (Amp)	600
Reserve Capacity (Min)	118
Load Test (Amp)	300
BCI Group No.	24

RODEO

ENGINE

IGNITION SYSTEM (X22SE 2.2L)

CONTENTS

Service Precaution	6D2-1	Crankshaft Angle Sensor	6D2-3
General Description	6D2-1	Removal	6D2-3
Diagnosis	6D2-1	Installation	6D2-3
Ignition Module	6D2-2	Main Data and Specifications	6D2-4
Removal	6D2-2		
Installation	6D2-2		
Spark Plug	6D2-2		
Removal	6D2-2		
Inspection and Repair	6D2-2		
Installation	6D2-3		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.**

General Description

Ignition is done by the Ignition Module that fires. Since the cylinder on exhaust stroke requires less energy to fire its spark plug, energy from the ignition coils can be utilized to fire the mating cylinder on compression stroke. A notch in the timing disc on the crankshaft activates the crank angle sensor which then sends information such as firing order and starting timing of ignition coil to the PCM. By receiving signals such as crank position, engine speed, water temperature and Manifold Absolute Pressure (MAP), the PCM controls the ignition timing.


Diagnosis

Refer to Section Drivability and Emissions for the diagnosis to electronic ignition system (EI system).

Ignition Module

Removal

1. Disconnect battery ground cable.
2. Ignition module connector.
3. Removal ignition module (1).




080RW001

Installation

1. Install the ignition module (1).
Connect ignition module connector and ignition coil, then tighten bolt to the specified torque.

Torque: 20 N·m (15 lb ft)



080RW001

2. Connect battery ground cable.

Spark Plug

Removal

1. Remove spark plugs.

Inspection and Repair

The spark plug affects entire engine performance and therefore its inspection is very important.

- Check electrode and insulator for presence of cracks, and replace if any.
- Check electrode for wear, and replace if necessary.
- Check gasket for damage, and replace if necessary.
- Measure insulation resistance with an ohmmeter, and replace if faulty.
- Adjust spark plug gap to 0.7 mm (0.027 in) ~ 0.8 mm (0.031 in).
- Check fuel and electrical systems if spark plug is extremely dirty.
- Use spark plugs having low heat value (hot type plug) if fuel and electrical systems are normal.
- Use spark plugs having high heat value (cold type plug) if insulator and electrode are extremely burned.

Sooty Spark Plugs

Much deposit of carbon or oil on the electrode and insulator of spark plug reduces the engine performance.

Possible causes:

- Too rich mixture
- Presence of oil in combustion chamber
- Incorrectly adjusted spark plug gap

Burning Electrodes

This fault is characterized by scorched or heavily oxidized electrode or blistered insulator nose.

Possible causes:


- Too lean mixture
- Improper heat value

Measuring Insulation Resistance

- Measure insulation resistance using a 500 volt megohm meter.


- Replace spark plugs if measured value is out of standard.

Insulation resistance: 50 MΩ or more



011RS010

- Clean threads and metal body with a wire brush.
- File the electrode tip if electrode is extremely worn.
- Bend the ground electrode to adjust the spark plug gap.



011RS011

Cleaning Spark Plugs

- Clean spark plugs with a spark plug cleaner.
- Raise the ground electrode to an angle of 45 to 60 degrees. if electrode is wet, dry it before cleaning.
- After spark plug is thoroughly cleaned, check insulator for presence of cracks.


Installation

- Spark plugs
 - Tighten spark plugs to the specified torque.
- Torque: 25 N·m (18 lb ft)**

Crankshaft Angle Sensor

Removal

- Disconnect battery ground cable
- Wiring connector from crankshaft angle sensor.
- Remove crankshaft angle sensor from cylinder block.



015RW021

Installation

- Install crankshaft angle sensor into the cylinder block. Before installation, apply small amount of engine oil to the O-ring.
- Torque: 6 N·m (4 lb ft)**
- Reconnect wiring connector to crankshaft angle sensor.

Main Data and Specifications

General Specifications

Ignition System	
Ignition Form	Electronic Ignition System (EI system) with Crankshaft angle Sensor
Spark Plug	
Type	Electronic Spark Control
No. of Coils and Type	2 Solid State
Coil Location	Engine-mounted
Torque	20 N·m (14 lb ft)

RODEO

ENGINE

STARTING AND CHARGING SYSTEM (X22SE 2.2L)

CONTENTS

Service Precaution	6D3-1	General Description	6D3-7
Starting System	6D3-2	General On-Vehicle Inspection	6D3-7
General Description	6D3-2	Generator	6D3-8
Diagnosis	6D3-2	Removal	6D3-8
Starter	6D3-3	Inspection	6D3-8
Removal	6D3-3	Installation	6D3-9
Installation	6D3-3	Disassembly	6D3-9
Disassembled View	6D3-4	Inspection and Repair	6D3-11
Inspection and Repair	6D3-5	Reassembly	6D3-13
Characteristic Test	6D3-6	Main Data and Specifications	6D3-14
Charging System	6D3-7		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Starting System

General Description

Cranking Circuit

The cranking system consists of a battery, starter, starter switch, starter relay, etc. These main components are connected.

Starter

The cranking system employs a magnetic type reduction starter in which the motor shaft is also used as a pinion shaft. When the starter switch is turned on, the contacts of magnetic switch are closed, and the armature rotates. At the same time, the plunger is attracted, and the pinion is pushed forward by the shift lever to mesh with the ring gear.

Then, the ring gear runs to start the engine. When the engine starts and the starter switch is turned off, the plunger returns, the pinion is disengaged from the ring gear, and the armature stops rotation. When the engine speed is higher than the pinion, the pinion idles, so that the armature is not driven.


Diagnosis

Condition	Possible cause	Correction
Starter does not run	Charging failure	Repair charging system
	Battery Failure	Replace Battery
	Terminal connection failure	Repair or replace terminal connector and/or wiring harness
	Starter switch failure	Repair or replace starter switch
	Starter failure	Repair or replace starter

Starter


Removal

1. Battery ground cable.
2. Remove harness connectors (1) and (2).



065RW022

3. Remove bolts from starter (1), (2).




065RW024

Installation

1. Install starter assembly(6).
2. Install mounting bolts and tighten bolts to specified torque (1), (2).


Torque: 25 N·m (18 lb ft)



065RW024

3. Connect harness.
4. Reconnect the battery ground cable.

Disassembled View



065RW023

Legend


- | | |
|---------------------|----------------------------|
| (1) Bolt | (7) Armature |
| (2) Magnetic Switch | (8) Yoke Assembly |
| (3) Gear Case | (9) Brush and Brush Holder |
| (4) Piston | (10) Washer |
| (5) Piston Shaft | (11) Rear Cover |
| (6) Center Bracket | (12) Through Bolt |

Inspection and Repair


Repair or replace necessary parts if extreme wear or damage is found during inspection.

Armature

Check for continuity between commutator and segment. Replace commutator if there is no continuity (i.e., disconnected).



Check for continuity between commutator and shaft. Also, check for continuity between commutator and armature core, armature core and shaft. Replace commutator if there is continuity (i.e., internally grounded).




Brush

Measure the length of brush.

Replace with a new one, if it is below the limit.

Brush Holder


Check for continuity between brush holder (+) (4) and base (-). Replace, if there is continuity (i.e., insulation is broken).



Magnetic Switch


Check for continuity of shunt coil between terminals S and M.

Replace, if there is no continuity (i.e., coil is disconnected).




Continuity of Series Coil

Check for continuity between terminals S and M. Replace, if there is no continuity (i.e., coil is disconnected).




Continuity of Contacts

With the plunger faced downward, push down the magnetic switch. In this state, check for continuity between terminals B and M. Replace, if there is no continuity (i.e., contacts are faulty).



Pinion

Check if the pinion rotates smoothly in drive direction by hand, or if it is locked when it is rotated in reverse. If not, replace the pinion.




Characteristic Test

For easily confirming the characteristics, conduct the noload test as follows:

Rating as short as 30 seconds requires rapid testing.

Fix the starter on the test bench, and wire as shown in illustration. When the switch is closed, the current flows and the starter runs under no load. At this time, measure current, voltage and speed to check if they satisfy the standard.



Legend

- (1) Volt Meter
- (2) Revolution Indicator
- (3) Battery
- (4) Ammeter
- (5) Switch

Charging System

General Description

The charging system is an IC integral regulator charging system and its main components are connected as shown in illustration.

The regulator is a solid state type and it is mounted along with the brush holder assembly inside the generator installed on the rear end cover.

The generator does not require particular maintenance such as voltage adjustment. The rectifier connected to the stator coil has eight diodes to transform AC voltage into DC voltage.

This DC voltage is connected to the output terminal of generator.

General On-Vehicle Inspection

The operating condition of charging system is indicated by the charge warning lamp. The warning lamp comes on when the starter switch is turned to "ON" position. The charging system operates normally if the lamp goes off when the engine starts.

If the warning lamp shows abnormality or if undercharged or overcharged battery condition is suspected, perform diagnosis by checking the charging system as follows:


1. Check visually the belt and wiring connector.
2. With the engine stopped, turn the stator switch to "ON" position and observe the warning lamp.

If lamp does not come on:

Disconnect wiring connector from generator, and ground the terminal "L" on connector side.

If lamp comes on:

Repair or replace the generator.



066RW021

Legend

(1) Regulator


(2) Indicator Lamp

(3) Generator Assembly

Generator

Removal


1. Disconnect battery ground cable.
2. Move drive belt tensioner to loose side using wrench then remove drive belt.
3. Disconnect terminal "B" wiring connector and connector.
4. Remove generator bracket (1), (2) and remove generator assembly.



065RW025

Inspection

Generator Power and Circuit Diagram



066RW020


Legend

- (1) Load resistor, set parallel to battery
- (2) Battery
- (3) Voltmeter
- (4) Ammeter
- (5) Ignition Lock
- (6) Charge Telltale
- (7) Generator

1. Disconnect battery.
2. Close off connecting cable from alternator terminal "B+".
3. Set ammeter (measuring range 100A) in disconnected line.
4. Connect controllable load resistor to battery terminal.
5. Set resistor in front of connection to "0"; connect first to battery, then to resistor.
6. Connect tachometer.
7. Connect oscilloscope according to manufacturer's instructions.
8. Connect battery.
9. Start engine and read off resulting current at various engine speeds.


Generator Power

1. Adjust load resistor, if the required load currents are not attained.
2. The shape of the voltage curves on oscilloscope curve should be regular.
3. Test value: 5 to 7A.
4. If the required minimum current intensity is not attained, or if the oscilloscope picture shows variations, the alternator should be overhauled.



066RW016

Regulated Voltage Circuit Diagram



066RW019

Legend

- (1) Battery
- (2) Ignition Lock
- (3) Charge Telltale
- (4) Resistor, for attainment of load current with the battery set in series
- (5) Voltmeter
- (6) Ammeter
- (7) Generator


Installation

1. Install generator assembly and bring generator assembly to the position to be installed.
2. Install generator bracket (1), (2) and tighten to the specified torque.

Torque:

Long bolt: 35 N·m (26 lb ft)

Short bolt: 20 N·m (15 lb ft)




065RW025

3. Connect wiring harness connector.
4. Move drive belt tensioner to loose side using wrench, then install drive belt to normal position.
5. Reconnect battery ground cable.

Disassembly


1. Belt pulley nut.




066RW016

6D3-10 STARTING AND CHARGING SYSTEM (X22SE 2.2L)


2. Spring ring, washer, belt pulley halves, spacing ring, fan pinion, pulley spring.
3. Voltage regulator with brush holder.




4. Drive bearing with clawpole armature.
5. Mark housing halves.
6. 4 fastening bolts.




7. Clawpole armature from drive bearing.
8. Lay suitable pipe piece (1) underneath.



9. Bearing cover of drive bearing.
10. Ball bearing from drive bearing.



11. Ball bearing from armature shaft.




066RW012

12. Nut from connecting pins "B+" and "D+".

13. Washers and insulating material.

14. Diode plate.

15. Remove together with stator winding from slip ring bearing.




066RW008

16. Spray sleeve (if present).

17. Carefully bend off diode plate.

18. Unsolder stator winding from diode plate.




066RW010

Inspection and Repair

Repair or replace necessary parts if extreme wear or damage is found during inspection.

Rotor Assembly


1. Check the rotor slip ring surfaces for contamination and roughness. If rough, polish with #500-600 sandpaper.



066RS014


6D3-12 STARTING AND CHARGING SYSTEM (X22SE 2.2L)

2. Measure the slip ring diameter, and replace if it exceeds the limit.




066RS015

3. Check resistance between slip rings, and replace if there is no continuity.



066RS016


4. Check for continuity between slip ring and rotor core. In case of continuity, replace the rotor assembly.



066RS017

Stator Coil

1. Measure resistance between respective phases.
2. Measure insulation resistance between stator coil and core with a mega-ohmmeter. If less than standard, replace the coil.




066RS018

Brush


Measure the brush length.
If more than limit, replace the brush.

Standard: 5 mm (0.20 in)



Rectifier Assembly

Check for continuity across "1" and "2" in the $\times 100W$ range of multimeter.



Change polarity, and make sure that there is continuity in one direction, and not in the reverse direction. In case of continuity in both directions, replace the rectifier assembly.


Reassembly

To reassemble, follow the disassembly steps in the reverse order, noting the following points:

1. Install pulley on the rotor.

Clamp pulley to the vise, and tighten nut to the specified torque.

Torque: 40 N·m (30 lb ft)



Main Data and Specifications

General Specifications

Battery voltage	V	12
Rated output	A	100
Direction of rotation (as viewed from pulley side)		Clockwise
Maximum speed	rpm	18000

RODEO

CONTROL SYSTEM

RODEO 2.2L ENGINE DRIVEABILITY AND EMISSIONS

CONTENTS

SPECIFICATIONS	6E1-6	On-Board Diagnostic Tests	6E1-29
TIGHTENING SPECIFICATIONS	6E1-6	Comprehensive Component Monitor	
DIAGRAMS AND SCHEMATICS	6E1-7	Diagnostic Operation	6E1-29
PCM WIRING DIAGRAM (1 of 10)	6E1-7	System Status And Drive Cycle For	
PCM WIRING DIAGRAM (2 of 10)	6E1-8	Satisfying Federal Inspection/Maintenance	
PCM WIRING DIAGRAM (3 of 10)	6E1-9	(I/M 240) Regulations	6E1-30
PCM WIRING DIAGRAM (4 of 10)	6E1-10	Common OBD II Terms	6E1-30
PCM WIRING DIAGRAM (5 of 10)	6E1-11	The Diagnostic Executive	6E1-31
PCM WIRING DIAGRAM (6 of 10)	6E1-12	DTC Types	6E1-32
PCM WIRING DIAGRAM (7 of 10)	6E1-13	Decimal/Binary/Hexadecimal Conversions	6E1-33
PCM WIRING DIAGRAM (8 of 10)	6E1-14	Verifying Vehicle Repair	6E1-33
PCM WIRING DIAGRAM (9 of 10)	6E1-15	Reading Diagnostic Trouble Codes Using A	
PCM WIRING DIAGRAM (10 of 10)	6E1-16	Tech 2 Scan Tool	6E1-33
PCM PINOUTS	6E1-17	Tech 2 Features	6E1-35
PCM Pinout Table, 32-Pin Red		Getting Started	6E1-35
Connector - Row "A"	6E1-17	Operating Procedure (Example)	6E1-36
PCM Pinout Table, 32-Pin Red		DTC Modes	6E1-37
Connector - Row "B"	6E1-18	DTC Information Mode	6E1-37
PCM Pinout Table, 32-Pin White		Miscellaneous Test	6E1-38
Connector - Row "C"	6E1-19	Lamps Test	6E1-38
PCM Pinout Table, 32-Pin White		Relays Test	6E1-39
Connector - Row "D"	6E1-20	EVAP Test	6E1-41
PCM Pinout Table, 32-Pin White		Idle Air Control System Test	6E1-42
Connector - Row "E"	6E1-21	Fuel System Test	6E1-44
PCM Pinout Table, 32-Pin White		EGR Control Test	6E1-45
Connector - Row "F"	6E1-22	Injector Balance Test	6E1-46
COMPONENT LOCATOR	6E1-23	Plotting Snapshot Graph	6E1-47
Undercarriage Component Locator Table	6E1-25	Plotting Graph Flow Chart (Plotting graph	
Fuse And Relay Panel (Underhood		after obtaining vehicle information)	6E1-48
Electrical Center)	6E1-25	Flow Chart for Snapshot Replay (Plotting	
DIAGNOSIS Strategy-Based Diagnostics ..	6E1-27	Graph)	6E1-49
Strategy-Based Diagnostics	6E1-27	PRIMARY SYSTEM-BASED DIAGNOSTICS	6E1-50
DTC Stored	6E1-27	Primary System-Based Diagnostics	6E1-50
No DTC	6E1-27	Fuel Control Heated Oxygen Sensors ...	6E1-50
No Matching Symptom	6E1-27	HO2S Heater	6E1-50
Intermittents	6E1-27	Catalyst Monitor Heated Oxygen Sensors	
No Trouble Found	6E1-27	And Diagnostic Operation	6E1-50
Verifying Vehicle Repair	6E1-27	MISFIRE MONITOR DIAGNOSTIC	
GENERAL SERVICE INFORMATION	6E1-28	OPERATION	6E1-51
OBD II Serviceability Issues	6E1-28	Misfire Monitor Diagnostic Operation	6E1-51
Emissions Control Information Label	6E1-28	Misfire Counters	6E1-51
Maintenance Schedule	6E1-29	FUEL TRIM SYSTEM MONITOR DIAGNOSTIC	
Visual/Physical Engine Compartment		OPERATION	6E1-52
Inspection	6E1-29	Fuel Trim System Monitor Diagnostic	
Basic Knowledge Of Tools Required	6E1-29	Operation	6E1-52
SERIAL DATA COMMUNICATIONS	6E1-29	Fuel Trim Cell Diagnostic Weights	6E1-52
Class II Serial Data Communications	6E1-29		
ON-BOARD DIAGNOSTIC (OBD II)	6E1-29		

6E1-2 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

ON-BOARD DIAGNOSTIC (OBD II) SYSTEM CHECK	6E1-53	DIAGNOSTIC TROUBLE CODE (DTC) P0112 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT LOW INPUT	6E1-120
A/C CLUTCH CONTROL CIRCUIT DIAGNOSIS	6E1-56	DIAGNOSTIC TROUBLE CODE (DTC) P0113 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT HIGH INPUT	6E1-123
ELECTRONIC IGNITION SYSTEM DIAGNOSIS	6E1-59	DIAGNOSTIC TROUBLE CODE (DTC) P0117 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT LOW INPUT	6E1-126
EVAP CANISTER PURGE SOLENOID	6E1-59	DIAGNOSTIC TROUBLE CODE (DTC) P0118 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT HIGH INPUT	6E1-129
VISUAL CHECK OF THE EVAPORATIVE EMISSION CANISTER	6E1-59	DIAGNOSTIC TROUBLE CODE (DTC) P0121 THROTTLE POSITION (TP) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM	6E1-132
IDLE AIR CONTROL (IAC) VALVE	6E1-59	DIAGNOSTIC TROUBLE CODE (DTC) P0122 THROTTLE POSITION (TP) SENSOR CIRCUIT LOW INPUT	6E1-135
FUEL SYSTEM PRESSURE TEST	6E1-59	DIAGNOSTIC TROUBLE CODE (DTC) P0123 THROTTLE POSITION (TP) SENSOR CIRCUIT HIGH INPUT	6E1-138
FUEL METERING SYSTEM CHECK	6E1-59	DIAGNOSTIC TROUBLE CODE (DTC) P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL ...	6E1-141
FUEL INJECTOR COIL TEST PROCEDURE AND FUEL INJECTOR BALANCE TEST PROCEDURE	6E1-60	DIAGNOSTIC TROUBLE CODE (DTC) P0131 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 1)	6E1-144
Test Description	6E1-60	DIAGNOSTIC TROUBLE CODE (DTC) P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1)	6E1-147
Injector Coil Test Procedure (Steps 1-6) And Injector Balance Test Procedure (Steps 7-11)	6E1-61	DIAGNOSTIC TROUBLE CODE (DTC) P0133 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1)	6E1-150
POWERTRAIN CONTROL MODULE (PCM) DIAGNOSIS	6E1-65	DIAGNOSTIC TROUBLE CODE (DTC) P0134 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1)	6E1-153
MULTIPLE PCM INFORMATION SENSOR DTCs SET	6E1-65	DIAGNOSTIC TROUBLE CODE (DTC) P0135 O2 SENSOR HEATER CIRCUIT MALFUNCTION (BANK 1 SENSOR 1)	6E1-156
EXHAUST GAS RECIRCULATION (EGR) DIAGNOSIS	6E1-69	DIAGNOSTIC TROUBLE CODE (DTC) P0137 O2 SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2)	6E1-159
ENGINE Tech 2 DATA DEFINITIONS AND RANGES	6E1-69	DIAGNOSTIC TROUBLE CODE (DTC) P0138 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2)	6E1-162
TYPICAL SCAN DATA VALUES	6E1-72	DIAGNOSTIC TROUBLE CODE (DTC) P0140 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 2)	6E1-165
NO MALFUNCTION INDICATOR LAMP (MIL)	6E1-76	DIAGNOSTIC TROUBLE CODE (DTC) P0141 O2 SENSOR HEATER CIRCUIT MALFUNCTION (BANK 1 SENSOR 2)	6E1-168
MALFUNCTION INDICATOR LAMP (MIL) ON STEADY	6E1-79	DIAGNOSTIC TROUBLE CODE (DTC) P0171 SYSTEM TOO LEAN (BANK 1)	6E1-171
ENGINE CRANKS BUT WILL NOT RUN ...	6E1-81	DIAGNOSTIC TROUBLE CODE (DTC) P0172 SYSTEM TOO RICH (BANK 1)	6E1-175
FUEL SYSTEM ELECTRICAL TEST	6E1-87		
FUEL SYSTEM DIAGNOSIS	6E1-90		
IDLE AIR CONTROL (IAC) SYSTEM CHECK	6E1-95		
EXHAUST GAS RECIRCULATION (EGR) SYSTEM CHECK	6E1-98		
MANIFOLD ABSOLUTE PRESSURE (MAP) OUTPUT CHECK	6E1-100		
EVAPORATIVE (EVAP) EMISSIONS CANISTER PURGE VALVE SOLENOID CHECK	6E1-102		
Upshift Lamp System Check (Manual Transmission Only)	6E1-105		
PCM DIAGNOSTIC TROUBLE CODES	6E1-108		
DIAGNOSTIC TROUBLE CODE (DTC) P0106 MANIFOLD ABSOLUTE PRESSURE (MAP) CIRCUIT/RANGE PERFORMANCE PROBLEM	6E1-111		
DIAGNOSTIC TROUBLE CODE (DTC) P0107 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT LOW INPUT	6E1-114		
DIAGNOSTIC TROUBLE CODE (DTC) P0108 MANIFOLD ABSOLUTE PRESSURE (MAP) CIRCUIT HIGH INPUT	6E1-117		

DIAGNOSTIC TROUBLE CODE (DTC) P0201 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 1	6E1-179	DIAGNOSTIC TROUBLE CODE (DTC) P0404 EXHAUST GAS RECIRCULATION (EGR) CIRCUIT RANGE/PERFORMANCE	6E1-237
DIAGNOSTIC TROUBLE CODE (DTC) P0202 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 2	6E1-182	DIAGNOSTIC TROUBLE CODE (DTC) P0405 EXHAUST GAS RECIRCULATION (EGR) SENSOR CIRCUIT LOW	6E1-241
DIAGNOSTIC TROUBLE CODE (DTC) P0203 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 3	6E1-185	DIAGNOSTIC TROUBLE CODE (DTC) P0406 EXHAUST GAS RECIRCULATION (EGR) SENSOR CIRCUIT HIGH	6E1-244
DIAGNOSTIC TROUBLE CODE (DTC) P0204 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 4	6E1-188	DIAGNOSTIC TROUBLE CODE (DTC) P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD	6E1-248
DIAGNOSTIC TROUBLE CODE (DTC) P0300 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED	6E1-191	DIAGNOSTIC TROUBLE CODE (DTC) P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM MALFUNCTION	6E1-251
DIAGNOSTIC TROUBLE CODE (DTC) P0301 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED	6E1-195	DIAGNOSTIC TROUBLE CODE (DTC) P0442 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM SMALL LEAK DETECTED	6E1-256
DIAGNOSTIC TROUBLE CODE (DTC) P0302 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED	6E1-199	DIAGNOSTIC TROUBLE CODE (DTC) P0443 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT MALFUNCTION	6E1-260
DIAGNOSTIC TROUBLE CODE (DTC) P0303 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED	6E1-203	DIAGNOSTIC TROUBLE CODE (DTC) P0446 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM VENT CONTROL CIRCUIT MALFUNCTION	6E1-263
DIAGNOSTIC TROUBLE CODE (DTC) P0304 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED	6E1-207	DIAGNOSTIC TROUBLE CODE (DTC) P0449 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM VENT VALVE/SOLENOID CIRCUIT MALFUNCTION	6E1-267
DIAGNOSTIC TROUBLE CODE (DTC) P0325 KNOCK SENSOR (KS) CIRCUIT MALFUNCTION	6E1-211	DIAGNOSTIC TROUBLE CODE (DTC) P0461 FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE	6E1-270
DIAGNOSTIC TROUBLE CODE (DTC) P0327 KNOCK SENSOR (KS) CIRCUIT LOW INPUT	6E1-214	DIAGNOSTIC TROUBLE CODE (DTC) P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT	6E1-272
DIAGNOSTIC TROUBLE CODE (DTC) P0336 CRANKSHAFT POSITION (CKP) SENSOR CIRCUIT RANGE/PERFORMANCE	6E1-217	DIAGNOSTIC TROUBLE CODE (DTC) P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT	6E1-274
DIAGNOSTIC TROUBLE CODE (DTC) P0337 CRANKSHAFT POSITION (CKP) SENSOR CIRCUIT LOW INPUT	6E1-219	DIAGNOSTIC TROUBLE CODE (DTC) P0480 COOLING FAN 1 CONTROL CIRCUIT MALFUNCTION	6E1-276
DIAGNOSTIC TROUBLE CODE (DTC) P0341 CAMSHAFT POSITION (CMP) SENSOR CIRCUIT RANGE/PERFORMANCE	6E1-222	DIAGNOSTIC TROUBLE CODE (DTC) P0481 COOLING FAN 2 CONTROL CIRCUIT MALFUNCTION	6E1-279
DIAGNOSTIC TROUBLE CODE (DTC) P0342 CAMSHAFT POSITION (CMP) SENSOR CIRCUIT LOW INPUT	6E1-225	DIAGNOSTIC TROUBLE CODE (DTC) P0502 VEHICLE SPEED SENSOR (VSS) CIRCUIT LOW INPUT	6E1-282
DIAGNOSTIC TROUBLE CODE (DTC) P0351 IGNITION COIL "A" PRIMARY/SECONDARY CIRCUIT MALFUNCTION	6E1-228	DIAGNOSTIC TROUBLE CODE (DTC) P0506 IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED	6E1-284
DIAGNOSTIC TROUBLE CODE (DTC) P0352 IGNITION COIL "B" PRIMARY/SECONDARY CIRCUIT MALFUNCTION	6E1-230	DIAGNOSTIC TROUBLE CODE (DTC) P0507 IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED	6E1-287
DIAGNOSTIC TROUBLE CODE (DTC) P0401 EXHAUST GAS RECIRCULATION (EGR) FLOW INSUFFICIENT DETECTED	6E1-232	DIAGNOSTIC TROUBLE CODE (DTC) P0532 A/C REFRIGERANT PRESSURE SENSOR CIRCUIT LOW INPUT	6E1-290
DIAGNOSTIC TROUBLE CODE (DTC) P0402 EXHAUST GAS RECIRCULATION (EGR) EXCESSIVE FLOW DETECTED	6E1-235		

6E1-4 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

DIAGNOSTIC TROUBLE CODE (DTC) P0533 A/C REFRIGERANT PRESSURE SENSOR CIRCUIT HIGH INPUT	6E1-293	DIAGNOSTIC TROUBLE CODE (DTC) P1441 EVAPORATIVE EMISSION (EVAP) SYSTEM FLOW DURING NON-PURGE	6E1-340
DIAGNOSTIC TROUBLE CODE (DTC) P0562 SYSTEM VOLTAGE LOW	6E1-296	DIAGNOSTIC TROUBLE CODE (DTC) P1546 A/C COMPRESSOR CLUTCH OUTPUT CIRCUIT MALFUNCTION	6E1-343
DIAGNOSTIC TROUBLE CODE (DTC) P0563 SYSTEM VOLTAGE HIGH	6E1-298	Diagnostic Trouble Code (DTC) P1625 PCM Unexpected Reset	6E1-346
DIAGNOSTIC TROUBLE CODE (DTC) P0601 INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR	6E1-300	DIAGNOSTIC TROUBLE CODE (DTC) P1627 PCM A/D CONVERSION MALFUNCTION .	6E1-348
DIAGNOSTIC TROUBLE CODE (DTC) P1106 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE	6E1-302	DIAGNOSTIC TROUBLE CODE (DTC) P1635 5 VOLT REFERENCE VOLTAGE CIRCUIT MALFUNCTION	6E1-350
DIAGNOSTIC TROUBLE CODE (DTC) P1107 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE	6E1-304	DIAGNOSTIC TROUBLE CODE (DTC) P1640 ODM OUTPUT CIRCUIT FAULT	6E1-352
DIAGNOSTIC TROUBLE CODE (DTC) P1111 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE	6E1-306	SYMPTOM DIAGNOSIS	6E1-355
DIAGNOSTIC TROUBLE CODE (DTC) P1112 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE .	6E1-309	DEFAULT MATRIX TABLE	6E1-378
DIAGNOSTIC TROUBLE CODE (DTC) P1114 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE	6E1-311	Camshaft Position (CMP) Sensor	6E1-381
DIAGNOSTIC TROUBLE CODE (DTC) P1115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE	6E1-313	Crankshaft Position (CKP) Sensor	6E1-382
DIAGNOSTIC TROUBLE CODE (DTC) P1121 THROTTLE POSITION (TP) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE	6E1-316	EEPROM	6E1-384
DIAGNOSTIC TROUBLE CODE (DTC) P1122 THROTTLE POSITION (TP) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE	6E1-318	Engine Coolant Temperature (ECT) Sensor .	6E1-384
DIAGNOSTIC TROUBLE CODE (DTC) P1133 O2 SENSOR INSUFFICIENT SWITCHING (BANK 1 SENSOR 1)	6E1-320	Heated Oxygen Sensor (HO2S)	6E1-385
DIAGNOSTIC TROUBLE CODE (DTC) P1134 O2 SENSOR TRANSITION TIME RATIO (BANK 1 SENSOR 1)	6E1-323	Intake Air Temperature (IAT) Sensor	6E1-386
DIAGNOSTIC TROUBLE CODE (DTC) P1171 FUEL SYSTEM LEAN DURING ACCELERATION	6E1-326	Manifold Absolute Pressure (MAP) Sensor .	6E1-387
DIAGNOSTIC TROUBLE CODE (DTC) P1336 CRANKSHAFT POSITION SENSOR (CKP) SYSTEM VARIATION NOT LEARNED	6E1-329	Malfunction Indicator Lamp (MIL)	6E1-388
DIAGNOSTIC TROUBLE CODE (DTC) P1380 ABS ROUGH ROAD SYSTEM FAULT	6E1-332	Powertrain Control Module (PCM)	6E1-388
DIAGNOSTIC TROUBLE CODE (DTC) P1381 ABS ROUGH ROAD CLASS 2 SERIAL DATA FAULT	6E1-334	Throttle Position (TP) Sensor	6E1-391
DIAGNOSTIC TROUBLE CODE (DTC) 1404 EXHAUST GAS RECIRCULATION (EGR) CLOSED VALVE	6E1-337	Vehicle Speed Sensor (VSS)	6E1-392
		Air Filter	6E1-393
		Idle Air Control (IAC) Valve	6E1-394
		Intake Air Duct	6E1-395
		Knock Sensor	6E1-397
		Oil Pressure Switch	6E1-398
		FUEL METERING SYSTEM Accelerator Cable Assembly	6E1-398
		Accelerator Pedal Replacement	6E1-400
		Fuel Filler Cap	6E1-401
		Fuel Filter	6E1-401
		Fuel Injectors	6E1-403
		Fuel Pressure Regulator	6E1-404
		Fuel Pump Assembly	6E1-406
		Fuel Pump Relay	6E1-408
		Fuel Rail Assembly	6E1-408
		Fuel Tank	6E1-410
		Throttle body (TB)	6E1-411
		ELECTRONIC IGNITION SYSTEM Ignition Control Module (ICM)	6E1-413
		Ignition Coil	6E1-413
		Spark Plugs	6E1-414
		Spark Plug Cables	6E1-415
		EMISSIONS Catalytic Converter	6E1-416
		Air Conditioning Relay	6E1-416
		Ignition Timing Adjustment	6E1-416
		EVAP Canister Hoses	6E1-416
		EVAP Canister	6E1-416

EVAP Canister Vent Solenoid	6E1-417	Accelerator Controls	6E1-432
EVAP Canister Purge Valve Solenoid	6E1-417	Battery Voltage Correction Mode	6E1-432
Linear Exhaust Gas Recirculation (EGR) Valve	6E1-418	CMP Signal	6E1-432
Wiring and Connectors	6E1-420	Clear Flood Mode	6E1-432
PCM Connectors And Terminals	6E1-420	Deceleration Fuel Cutoff (DFCO) Mode ...	6E1-432
Connectors And Terminals	6E1-420	Engine Speed/Vehicle Speed/ Fuel Disable Mode	6E1-432
Wire Harness Repair: Twisted Shielded Cable	6E1-420	Fuel Cutoff Mode	6E1-432
Twisted Leads	6E1-421	Fuel Injector	6E1-432
Weather-Pack Connector	6E1-422	Fuel Metering System Components	6E1-433
Com-Pack III	6E1-424	Fuel Metering System Purpose	6E1-433
Metri-Pack	6E1-424	Fuel Pressure Regulator	6E1-433
GENERAL DESCRIPTION — PCM AND SENSORS	6E1-425	Fuel Pump Electrical Circuit	6E1-433
58X Reference PCM Input	6E1-425	Fuel Rail	6E1-433
A/C Request Signal	6E1-425	Idle Air Control (IAC) Valve	6E1-434
Crankshaft Position (CKP) Sensor	6E1-425	Run Mode	6E1-434
Camshaft Position (CMP) Sensor And Signal	6E1-425	Starting Mode	6E1-434
Engine Coolant Temperature (ECT) Sensor	6E1-425	Throttle Body Unit	6E1-434
Electrically Erasable Programmable Read Only Memory (EEPROM)	6E1-426	GENERAL DESCRIPTION — ELECTRONIC IGNITION SYSTEM	6E1-435
Fuel Control Heated Oxygen Sensor (Pre Catalyst)	6E1-426	Camshaft Position (CMP) Sensor	6E1-435
Catalyst Monitor Heated Oxygen Sensor (Post Catalyst)	6E1-426	Crankshaft Position (CKP) Sensor	6E1-435
Intake Air Temperature (IAT) Sensor	6E1-427	Electronic Ignition	6E1-435
Linear Exhaust Gas Recirculation (EGR) Control	6E1-427	Ignition Coils	6E1-435
Manifold Absolute Pressure (MAP) Sensor	6E1-427	Ignition Control	6E1-435
Powertrain Control Module (PCM)	6E1-428	Ignition Control Module (ICM)	6E1-436
PCM Function	6E1-428	Ignition Control PCM Output	6E1-436
PCM Components	6E1-428	Powertrain Control Module (PCM)	6E1-436
PCM Voltage Description	6E1-428	Spark Plug	6E1-437
PCM Inputs/Outputs	6E1-428	A/C CLUTCH DIAGNOSIS	6E1-438
PCM Service Precautions	6E1-429	A/C Clutch Circuit Operation	6E1-438
Reprogramming the PCM	6E1-429	A/C Clutch Circuit Purpose	6E1-438
Tooth Error Correction (TEC) Service Bay Guidelines	6E1-429	A/C Request Signal	6E1-438
Throttle Position (TP) Sensor	6E1-430	GENERAL DESCRIPTION — EVAPORATIVE EMISSION (EVAP) SYSTEM	6E1-439
Transmission Range Switch	6E1-430	EVAP Emission Control System Purpose .	6E1-439
Vehicle Speed Sensor (VSS)	6E1-430	EVAP Emission Control System Operation	6E1-439
Use of Circuit Testing Tools	6E1-431	Enhanced Evaporative Emission Control System	6E1-439
Aftermarket Electrical And Vacuum Equipment	6E1-431	System Fault Detection	6E1-440
Electrostatic Discharge Damage	6E1-431	GENERAL DESCRIPTION — EXHAUST GAS RECIRCULATION (EGR) SYSTEM ..	6E1-440
Upshift Lamp	6E1-431	EGR Purpose	6E1-440
GENERAL DESCRIPTION — AIR INDUCTION	6E1-431	Linear EGR Valve	6E1-440
Air Induction System	6E1-431	Linear EGR Control	6E1-440
GENERAL DESCRIPTION — FUEL METERING	6E1-432	Linear EGR Valve Operation And Results Of Incorrect Operation	6E1-441
Acceleration Mode	6E1-432	EGR Pintle Position Sensor	6E1-441
		GENERAL DESCRIPTION — POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM	6E1-441
		Crankcase Ventilation System Purpose ...	6E1-441
		SPECIAL TOOLS	6E1-442


SPECIFICATIONS

TIGHTENING SPECIFICATIONS


Application	N-m	Lb Ft	Lb In
Crankshaft Position Sensor Mounting Bolt	9	—	78
EGR Nut	14	—	130
Engine Coolant Temperature Sensor	30	22	—
Fuel Drain Plug	20	14	—
Fuel Pressure Regulator Attaching Screw	6.5	—	60
Fuel Rail Bolts	7	—	75
Fuel Tank Undercover Retaining Bolts	36	27	—
Heated Oxygen Sensor	5	40	—
Spark Plugs	25	18	—
Throttle Body Mounting Bolts	13	—	120
VSS Retaining Bolt	13	—	120
Camshaft Gear to Camshaft	45	33	—
Camshaft Bearing Cover to Camshaft Housing	8	—	71
Crankshaft Bearing Cover to Cylinder Block	50+45'+15'1	37	—
Crankshaft Pulse Pick-up Sensor Disc to Crankshaft	13	—	115
Drive Disc to Crankshaft	60 ₅	44	—
Dual-Mass Flywheel to Crankshaft	65+30'+15'1	48	—
Engine Bracket to Cylinder Block	60	44	—
Exhaust Manifold to Cylinder Head	22 ₂	16	—
Front Toothed Belt Cover to Rear Toothed Belt Cover	4	—	35
Heat Sleeves in Cylinder Head	30 ₃	22	—
Intake Manifold to Cylinder Head	22	16	—
Oil Pan Bolt to Oil Pan	55	41	—
Oil Inlet Pipe Bracket to Cylinder Block	6	—	53
Oil Intake Pipe to Oil Pump	84,5	—	71
Rod Bearing Cover to Rod	35+45'+15'1	26	—
Spark Plug to Cylinder Head	25	18	—
Thrust Plate Cover to Camshaft Housing	8	—	71
Thrust Plate to Camshaft Housing	8	—	71
Toothed Belt Drive Gear to Crankshaft	130+40'+15'1	96	—
Toothed Belt Tension Roller to Oil Pump	25	18	—
Torsional Vibration Damper to Toothed Belt Drive Gear	20	15	—
1. Use new bolt(s). 2. Use new nuts. 3. Insert with Molycote Paste. 4. If not possible to use new bolts, then recut bolts before reuse and insert with locking compound. 5. Maximum installation time including torque check is 10 minutes.	—	—	—

DIAGRAMS AND SCHEMATICS

PCM WIRING DIAGRAM (1 of 10)




PCM WIRING DIAGRAM (2 of 10)




PCM WIRING DIAGRAM (3 of 10)




PCM WIRING DIAGRAM (4 of 10)




PCM WIRING DIAGRAM (5 of 10)




PCM WIRING DIAGRAM (6 of 10)




PCM WIRING DIAGRAM (7 of 10)



PCM WIRING DIAGRAM (8 of 10)




PCM WIRING DIAGRAM (9 of 10)




D06RX034

PCM WIRING DIAGRAM (10 of 10)



PCM PINOUTS


PCM Pinout Table, 32-Pin Red Connector – Row "A"



TS23344

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
A1	5 Volt Reference Signal	RED	5.0 V	5.0 V	Appropriate Sensor
A2	Knock Sensor Input	YEL	—	3.0 V (MAX)	General Description and Operation, Knock Sensor
A3	Not Used	—	—	—	—
A4	Battery Feed	RED/WHT	B+	B+	Chassis Electrical
A5	Idle Air Control (IAC) "A" High	BLU	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A6	IAC "A" Low	BLU/WHT	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A7	IAC "B" Low	BLU/BLK	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A8	IAC "B" High	BLU/RED	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A9	Not Used	—	—	—	—
A10	Not Used	—	—	—	—
A11	Not Used	—	—	—	—
A12	Low Fuel Warning Lamp Control	PNK	0.4–0.9 V	B+	Chassis Electrical
A13	Malfunction Indicator Lamp (MIL) Control	WHT/GRN	0.4–0.9 V	B+	Chassis Electrical
A14	Rear Defogger Relay	RED/WHT	B+	B+	Classis Electrical
A15	EVAP Canister Vent Solenoid Control	RED/BLU	B+	0–5 V (varies)	General Description and Operation, EVAP Emission Control System
A16	Not Used	—	—	—	—


PCM Pinout Table, 32-Pin Red Connector – Row "B"



TS23344

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
B1	5 Volt Reference Signal	BLU/ORG	5.0 V	5.0 V	Appropriate Sensor
B2	Not Used	—	—	—	—
B3	Not Used	—	—	—	—
B4	Not Used	—	—	—	—
B5	Fuel Tank Level Sensor	ORN/GRN	—	—	General Description and Operation, Fuel Pump
B6	Fuel Tank Vapor Pressure Sensor Input	GRY	0.2 to 4.9 V (0.5V = +5in H ₂ O)	0.2 to 4.9 V (4.5V = -15 in H ₂ O)	General Description and Operation, Fuel Pump
B7	Exhaust Gas Recirculation (EGR) Position Feedback	YEL/RED	0.6 V	0.6 V	General Description and Operation, Linear EGR Control
B8	Intake Air Temperature (IAT) Sensor	YEL/GRN	~3V (0V = 151°C)	~3 V (5V = -40°C)	General Description and Operation, IAT
B9	A/C Pressure Sensor Signal	GRN	~1 V	~1 V	A/C System
B10	Not Used	—	—	—	—
B11	Power Steering Pressure (PSP) Switch Input	GRN/YEL	B+	B+	General Description and Operation, PSP
B12	Illumination Switch	GRN/YEL	B+	B+	Chassis Electrical
B13	Class 2 Data	ORN/BLK	0.0 V	0.0 V	Diagnosis, Class 2 Serial Data
B14	A/C Compressor Clutch Relay Control Compressor	GRN/RED	0 (A/C OFF)	B+ (A/C ON)	General Description and Operation, A/C Clutch Circuit Operation
B15	Upshift Lamp Control	YEL/GRN	—	—	—
B16	EVAP Canister Purge Valve Solenoid	BRN/WHT	—	—	General Description and Operation, EVAP


PCM Pinout Table, 32-Pin White Connector – Row "C"



TS23345

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
C1	Injector Cylinder #2	GRN/RED	B+ Varies	B+ Varies	General Description and Operation, Fuel Injector
C2	Not Used	—	—	—	—
C3	Not Used	—	—	—	—
C4	Ignition Control Module (ICM) Input	RED	0.0 V	0.1 V	General Description and Operation, Fuel Injector
C5	Crankshaft Position (CKP) Sensor Low	BLUE	4.98 V	0.76 V (at idle)	General Description and Operation, Crankshaft Position Sensor
C6	Crankshaft Position Sensor (CKP) High	GRN	5V	5V	General Description and Operation, Crankshaft Position Sensor
C7	PCM Ground	BLK/BLU	0.0 V	0.0 V	Chassis Electrical
C8	PCM Ground	BLK/BLU	0.0 V	0.0 V	Chassis Electrical
C9	PCM Ground	BLK/BLU	0.0 V	0.0 V	Chassis Electrical
C10	Tachometer Signal	BLK/RED	—	—	General Description and Operation
C11	Fuel Gauge PWM Output	YEL/RED	Varies with Fuel Level	Varies with Fuel Level	General Description and Operation
C12	High Fan Relay Control	RED/YEL	10.5 V	B+	Chassis Electrical
C13	Low Fan Relay Control	RED/BLU	—	—	Chassis Electrical
C14	Bank 1 HO2S 1 High	WHT	0.3 V	−0.1 to 1.1 V	General Description and Operation, Fuel HO2S 1
C15	Bank 1 HO2S 1 Low	RED	0.0 V	0.1 V	General Description and Operation, Fuel HO2S 1
C16	Bank 1 HO2S 2 High	RED	0.3 V	−0.1 to 1.1 V	General Description and Operation, Catalyst HO2S 2


PCM Pinout Table, 32-Pin White Connector – Row "D"



TS23345

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
D1	Injector Cylinder #3	GRN/ORN	B+	B+	General Description and Operation, Fuel Injector
D2	Not Used	—	—	—	—
D3	Injector Cylinder #1	GRN/WHT	B+	B+	General Description and Operation, Fuel Injector
D4	Not Used	—	—	—	—
D5	Ignition Control Module (ICM) Input	RED/BLK	—	—	General Description and Operation
D6	Not Used	—	—	—	—
D7	VSS Input	BLU/BLK	—	—	Chassis Electrical
D8	Sensor Ground 5 V Reference A Return	GRN	0.0 V	0.0 V	Appropriate Sensor
D9	Sensor Ground 5 V Reference B Return	BLU/YEL	0.0 V	0.0 V	Appropriate Sensor
D10	Not Used	—	—	—	—
D11	Camshaft Position Sensor Input	BLU	5.0 V	4.6 V	General Description and Operation, Camshaft Position Sensor
D12	Not Used	—	—	—	—
D13	Not Used	—	—	—	—
D14	Not Used	—	—	—	—
D15	Not Used	—	—	—	—
D16	Bank 1 HO2S 2 Low	GRN	0.0 V	0.1 V	General Description and Operation, Catalyst HO2S 2


PCM Pinout Table, 32-Pin White Connector – Row "E"



TS23346

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
E1	Not Used	—	—	—	—
E2	Fan Control	RED/GRN	0.0V	B+	Chassis Electrical
E3	Not Used	—	—	—	—
E4	Not Used	—	—	—	—
E5	Ignition Feed	BLK/YEL	B+	B+	General Description and Operation
E6	Exhaust Gas Recirculation (EGR) Valve Low	YEL	B+ Varies	B+ Varies	General Description and Operation, EGR Control
E7	Not Used	—	—	—	—
E8	Throttle Position (TP) Sensor Input	BLU	0.25 V (0% = 0.25 V)	0.25 V (at idle) (100% = 4.75 V)	General Description and Operation, Throttle Position Sensor
E9	Engine Coolant Temperature (ECT) Sensor Input	BLU/RED	2.3 V (0 V = 151°C)	2.1 V (5 V = -40°C)	General Description and Operation, Engine Coolant Temperature (ECT) Sensor
E10	Not Used	—	—	—	—
E11	Not Used	—	—	—	—
E12	Rear Defogger Switch	YEL/GRN	B+	B+	Chassis Electrical
E13	Fuel Pump (FP) Relay Control	PNK/WHT	0.0 V	B+	On-Vehicle Service, Fuel Pump Relay
E14	Not Used	—	—	—	—
E15	A/C Request (Thermo Relay)	GRN/BLK	0.0 V	0.0 V	Electric Cooling Fans
E16	Ignition Feed	RED/BLU	B+	B+	General Description and Operation


PCM Pinout Table, 32-Pin White Connector – Row "F"




TS23346


PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
F1	Not Used	—	—	—	—
F2	Not Used	—	—	—	—
F3	Not Used	—	—	—	—
F4	Not Used	—	—	—	—
F5	Not Used	—	—	—	—
F6	Not Used	—	—	—	—
F7	Not Used	—	—	—	—
F8	Manifold Absolute Pressure (MAP) Sensor Input	GRY	~4.7 V (0 V = 10kPa)	~1.1 V (5 V = 104kPa)	General Description and Operation, Manifold Absolute Pressure
F9	Not Used	—	—	—	—
F10	Not Used	—	—	—	—
F11	Not Used	—	—	—	—
F12	DLC (Digital Input)	—	—	—	Class 2 Serial Data
F13	Injector "C" Cylinder #4	GRN	B+	B+	General Description and Operation, Fuel Injector
F14	Not Used	—	—	—	—
F15	Not Used	—	—	—	—
F16	Ignition Feed	RED/BLU	B+	B+	General Description and Operation

COMPONENT LOCATOR





010RX001



028RX001

Engine Component Locator Table


Number	Name	Location
1	Engine Coolant Temperature (ECT) Sensor	Rear of engine, near ignition coils
2	Linear Exhaust Gas Recirculation (EGR) Valve	On the left rear of the engine at the bulkhead
3	Heated Oxygen Sensor (HO2S), Bank 1, Sensor 1	On the exhaust pipe, left side of engine, immediately behind the exhaust manifold
4	Air Cleaner	Left front of the engine bay
5	Intake Air Temperature (IAT) Sensor	On the intake air duct near the air cleaner
6	Camshaft Position (CMP) Sensor	Inside the front cover assembly
7	Positive Crankcase Ventilation (PCV) Port	On the right front corner of the valve cover
8	Fuel Pressure Regulator	On the forward end of the fuel rail, to the right of the PVC port
9	Throttle Body	Between the intake air duct and the intake manifold
10	Fuse/Relay Box	Along the inside of the right fender
11	Throttle Position (TP) Sensor	On the front of the throttle body
12	Idle Air Control (IAC) Valve	On the rear of the throttle body
13	EVAP Canister Vent Solenoid	At the right rear of the engine, behind the Throttle body
14	Ignition Control Module (ICM)	Mounted on a heat sink on the lower right side of the engine block, above the starter motor
15	Manifold Absolute Pressure (MAP) Sensor	Bolted to the front edge of the intake manifold, under the fuel rail

Undercarriage Component Locator Table

Name	Location
Fuel Pump Assembly	Installed in the top of the fuel tank
EVAP Canister	Behind rear axle, near fuel tank filler nozzle
EVAP Canister Purge Valve Solenoid	Behind rear axle, near fuel tank filler nozzle
Heated Oxygen Sensor (HO2S) Bank 1, Sensor 2	Threaded into the exhaust pipe behind the catalytic converter
Vehicle Speed Sensor (VSS)	Protrudes from the right side of the transmission housing, near the output shaft
Crankshaft Position (CKP) Sensor	Lower left hand front of engine, behind power steering pump bracket

Fuse And Relay Panel (Underhood Electrical Center)

Underhood (U/H) Fuse and Relay Panel



DIAGNOSIS Strategy-Based Diagnostics

Strategy-Based Diagnostics

The strategy-based diagnostic is a uniform approach to repair all Electrical/Electronic (E/E) systems. The diagnostic flow can always be used to resolve an E/E system problem and is a starting point when repairs are necessary. The following steps will instruct the technician how to proceed with a diagnosis:

1. Verify the customer complaint.
 - To verify the customer complaint, the technician should know the normal operation of the system.
2. Perform preliminary checks.
 - Conduct a thorough visual inspection.
 - Review the service history.
 - Detect unusual sounds or odors.
 - Gather diagnostic trouble code information to achieve an effective repair.
3. Check bulletins and other service information.
 - This includes videos, newsletters, etc.
4. Refer to service information (manual) system check(s).
 - "System checks" contain information on a system that may not be supported by one or more DTCs. System checks verify proper operation of the system. This will lead the technician in an organized approach to diagnostics.
5. Refer to service diagnostics.

DTC Stored

Follow the designated DTC chart exactly to make an effective repair.

No DTC

Select the symptom from the symptom tables. Follow the diagnostic paths or suggestions to complete the repair. You may refer to the applicable component/system check in the system checks.

No Matching Symptom

1. Analyze the complaint.
2. Develop a plan for diagnostics.
3. Utilize the wiring diagrams and the theory of operation.

Combine technician knowledge with efficient use of the available service information.

Intermittents

Conditions that are not always present are called intermittents. To resolve intermittents, perform the following steps:

1. Observe history DTCs, DTC modes, and freeze-frame data.
2. Evaluate the symptoms and the conditions described by the customer.

3. Use a check sheet or other method to identify the circuit or electrical system component.
4. Follow the suggestions for intermittent diagnosis found in the service documentation.

Most Scan Tools, such as the Tech 2, have data-capturing capabilities that can assist in detecting intermittents.

No Trouble Found

This condition exists when the vehicle is found to operate normally. The condition described by the customer may be normal. Verify the customer complaint against another vehicle that is operating normally. The condition may be intermittent. Verify the complaint under the conditions described by the customer before releasing the vehicle.

1. Re-examine the complaint.

When the complaint cannot be successfully found or isolated, a re-evaluation is necessary. The complaint should be re-verified and could be intermittent as defined in *Intermittents*, or could be normal.
2. Repair and verify.

After isolating the cause, the repairs should be made. Validate for proper operation and verify that the symptom has been corrected. This may involve road testing or other methods to verify that the complaint has been resolved under the following conditions:

 - Conditions noted by the customer.
 - If a DTC was diagnosed, verify a repair by duplicating conditions present when the DTC was set as noted in the Failure Records or Freeze Frame data.

Verifying Vehicle Repair

Verification of the vehicle repair will be more comprehensive for vehicles with OBD II system diagnostics. Following a repair, the technician should perform the following steps:

IMPORTANT: Follow the steps below when you verify repairs on OBD II systems. Failure to follow these steps could result in unnecessary repairs.

1. Review and record the Failure Records and the Freeze Frame data for the DTC which has been diagnosed (Freeze Frame data will only be stored for an A or B type diagnostic and only if the MIL ("Check Engine" lamp) has been requested).
2. Clear the DTC(s).
3. Operate the vehicle within conditions noted in the Failure Records and Freeze Frame data.
4. Monitor the DTC status information for the DTC which has been diagnosed until the diagnostic test associated with that DTC runs.

GENERAL SERVICE INFORMATION

OBD II Serviceability Issues

With the introduction of OBD II diagnostics across the entire passenger car and light-duty truck market in 1996, illumination of the MIL ("Check Engine" lamp) due to a non-vehicle fault could lead to misdiagnosis of the vehicle, increased warranty expense and customer dissatisfaction. The following list of non-vehicle faults does not include every possible fault and may not apply equally to all product lines.

Fuel Quality

Fuel quality is not a new issue for the automotive industry, but its potential for turning on the MIL ("Check Engine" lamp) with OBD II systems is new.

Fuel additives such as "dry gas" and "octane enhancers" may affect the performance of the fuel. If this results in an incomplete combustion or a partial burn, it will show up as a Misfire DTC P0300. The Reid Vapor Pressure of the fuel can also create problems in the fuel system, especially during the spring and fall months when severe ambient temperature swings occur. A high Reid Vapor Pressure could show up as a Fuel Trim DTC due to excessive canister loading. High vapor pressures generated in the fuel tank can also affect the Evaporative Emission diagnostic as well.

Using fuel with the wrong octane rating for vehicle may cause driveability problems. Many of the major fuel companies advertise that using "premium" gasoline will improve the performance of vehicle. Most premium fuels use alcohol to increase the octane rating of the fuel. Although alcohol-enhanced fuels may raise the octane rating, the fuel's ability to turn into vapor in cold temperatures deteriorates. This may affect the starting ability and cold driveability of the engine.

Low fuel levels can lead to fuel starvation, lean engine operation, and eventually engine misfire.

Non-OEM Parts

All of the OBD II diagnostics have been calibrated to run with OEM parts. Something as simple as a high-performance exhaust system that affects exhaust system back pressure could potentially interfere with the operation of the EGR valve and thereby turn on the MIL ("Check Engine" lamp). Small leaks in the exhaust system near the post catalyst oxygen sensor can also cause the MIL ("Check Engine" lamp) to turn on.

Aftermarket electronics, such as transceiver, stereos, and anti-theft devices, may radiate EMI into the control system if they are improperly installed. This may cause a false sensor reading and turn on the MIL ("Check Engine" lamp).

Environment

Temporary environmental conditions, such as localized flooding, will have an effect on the vehicle ignition system. If the ignition system is rain-soaked, it can temporarily cause engine misfire and turn on the MIL ("Check Engine" lamp).

Refueling

A new OBD II diagnostic was introduced in 1996 on some vehicles. This diagnostic checks the integrity of the entire evaporative emission system. If the vehicle is restarted after refueling and the fuel cap is not secured correctly, the on-board diagnostic system will sense this as a system fault and turn on the MIL ("Check Engine" lamp) with a DTC P0440.

Vehicle Marshaling

The transportation of new vehicles from the assembly plant to the dealership can involve as many as 60 key cycles within 2 to 3 miles of driving. This type of operation contributes to the fuel fouling of the spark plugs and will turn on the MIL ("Check Engine" lamp) with a P0300 Misfire DTC.

Poor Vehicle Maintenance

The sensitivity of OBD II diagnostics will cause the MIL ("Check Engine" lamp) to turn ON if the vehicle is not maintained properly. Restricted air filters, fuel filters, and crankcase deposits due to lack of oil changes or improper oil viscosity can trigger actual vehicle faults that were not previously monitored prior to OBD II. Poor vehicle maintenance can't be classified as a "non-vehicle fault", but with the sensitivity of OBD II diagnostics, vehicle maintenance schedules must be more closely followed.

Severe Vibration

The Misfire diagnostic measures small changes in the rotational speed of the crankshaft. Severe driveline vibrations in the vehicle, such as caused by an excessive amount of mud on the wheels, can have the same effect on crankshaft speed as misfire and therefore may set a Misfire DTC P0300.

Related System Faults

Many of the OBD II system diagnostics will not run if the PCM detects a fault on a related system or component. One example would be that if the PCM detected a Misfire fault, the diagnostics on the catalytic converter would be suspended until the Misfire fault was repaired. If the Misfire fault was severe enough, the catalytic converter could be damaged due to overheating and would never set a Catalyst DTC until the Misfire fault was repaired and the Catalyst diagnostic was allowed to run to completion. If this happens, the customer may have to make two trips to the dealership in order to repair the vehicle.

Emissions Control Information Label

The engine compartment "Vehicle Emissions Control Information Label" contains important emission specifications and setting procedures. In the upper left corner is exhaust emission information. This identifies the emission standard (Federal, California, or Canada) of the engine, the displacement of the engine in liters, the class of the vehicle, and the type of fuel metering system. There is also an illustrated emission components and vacuum hose schematic.

This label is located in the engine compartment of every vehicle. If the label has been removed it should be replaced, it can be ordered from Isuzu Dealer ship.

Maintenance Schedule

Refer to the Maintenance Schedule.

Visual/Physical Engine Compartment Inspection

Perform a careful visual and physical engine compartment inspection when performing any diagnostic procedure or diagnosing the cause of an emission test failure. This can often lead to repairing a problem without further steps. Use the following guidelines when performing a visual/physical inspection:

- Inspect all vacuum hoses for pinches, cuts, disconnection, and Droper routing.
- Inspect hoses that are difficult to see behind other components.
- Inspect all wires in the engine compartment for proper connections, burned or chafed spots, pinched wires, contact with sharp edges or contact with hot exhaust manifolds or pipes.

Basic Knowledge Of Tools Required

NOTE: Lack of basic knowledge of this powertrain when performing diagnostic procedures could result in an incorrect diagnosis or damage to powertrain components. Do not attempt to diagnose a powertrain problem without this basic knowledge.

A basic understanding of hand tools is necessary to effectively use this section of the Service Manual.

SERIAL DATA COMMUNICATIONS

Class II Serial Data Communications

Government regulations require that all vehicle manufacturers establish a common communication system. This vehicle utilizes the "Class II" communication system. Each bit of information can have one of two lengths: long or short. This allows vehicle wiring to be reduced by transmitting and receiving multiple signals over a single wire. The messages carried on Class II data streams are also prioritized. If two messages attempt to establish communications on the data line at the same time, only the message with higher priority will continue. The device with the lower priority message must wait. The most significant result of this regulation is that it provides Tech 2 manufacturers with the capability to access data from any make or model vehicle that is sold.

The data displayed on the other Tech 2 will appear the same, with some exceptions. Some Scan Tools will only be able to display certain vehicle parameters as values that are a coded representation of the true or actual value. For more information on this system of coding, refer to Decimal/Binary/Hexadecimal Conversions. On this vehicle the Tech 2 displays the actual values for vehicle parameters. It will not be necessary to perform any conversions from coded values to actual values.

ON-BOARD DIAGNOSTIC (OBD II)

On-Board Diagnostic Tests

A diagnostic test is a series of steps, the result of which is a pass or fail reported to the diagnostic executive. When a diagnostic test reports a pass result, the diagnostic executive records the following data:

- The diagnostic test has been completed since the last ignition cycle.
- The diagnostic test has passed during the current ignition cycle.
- The fault identified by the diagnostic test is not currently active.

When a diagnostic test reports a fail result, the diagnostic executive records the following data:

- The diagnostic test has been completed since the last ignition cycle.
- The fault identified by the diagnostic test is currently active.
- The fault has been active during this ignition cycle.
- The operating conditions at the time of the failure.

Remember, a fuel trim DTC may be triggered by a list of vehicle faults. Make use of all information available (other DTCs stored, rich or lean condition, etc.) when diagnosing a fuel trim fault.

Comprehensive Component Monitor Diagnostic Operation

Comprehensive component monitoring diagnostics are required to monitor emissions-related input and output powertrain components. The *CARB OBD II Comprehensive Component Monitoring List Of Components Intended To illuminate The MIL* is a list of components, features or functions that could fall under this requirement.

Input Components:

Input components are monitored for circuit continuity and out-of-range values. This includes rationality checking. Rationality checking refers to indicating a fault when the signal from a sensor does not seem reasonable, i.e. Throttle Position (TP) sensor that indicates high throttle position at low engine loads or MAP voltage). Input components may include, but are not limited to the following sensors:

- Vehicle Speed Sensor (VSS)
- Crankshaft Position (CKP) sensor
- Throttle Position (TP) sensor
- Engine Coolant Temperature (ECT) sensor
- Camshaft Position (CMP) sensor
- Manifold Absolute Pressure (MAP) sensor

In addition to the circuit continuity and rationality check the ECT sensor is monitored for its ability to achieve a steady state temperature to enable "Closed Loop" fuel control.

Output Components:

Output components are diagnosed for proper response to control module commands. Components where functional monitoring is not feasible will be monitored for circuit continuity and out-of-range values if applicable.

Output components to be monitored include, but are not limited to the following circuit:

- ☐ Idle Air Control (IAC) Motor
- ☐ EVAP Canister Purge Valve Solenoid
- ☐ A/C relays
- ☐ Cooling fan relay(s)
- ☐ VSS output
- ☐ MIL control
- ☐ Cruise control inhibit

Refer to PCM and Sensors in General Descriptions.

Passive and Active Diagnostic Tests

A passive test is a diagnostic test which simply monitors a vehicle system or component. Conversely, an active test, actually takes some sort of action when performing diagnostic functions, often in response to a failed passive test. For example, the EGR diagnostic active test will force the EGR valve open during closed throttle decel and/or force the EGR valve closed during a steady state. Either action should result in a change in manifold pressure.

Intrusive Diagnostic Tests

This is any on-board test run by the Diagnostic Management System which may have an effect on vehicle performance or emission levels.

Warm-Up Cycle

A warm-up cycle means that engine at temperature must reach a minimum of 70°C (160°F) and rise at least 22°C (40°F) over the course of a trip.

Freeze Frame

Freeze Frame is an element of the Diagnostic Management System which stores various vehicle information at the moment an emissions-related fault is stored in memory and when the MIL is commanded on. These data can help to identify the cause of a fault. Refer to Storing And Erasing Freeze Frame Data for more detailed information.

Failure Records

Failure Records data is an enhancement of the OBD II Freeze Frame feature. Failure Records store the same vehicle information as does Freeze Frame, but it will store that information for any fault which is stored in on-board memory, while Freeze Frame stores information only for emission-related faults that command the MIL ON.

System Status And Drive Cycle For Satisfying Federal Inspection/Maintenance (I/M 240) Regulations

I/M Ready Status means a signal or flag for each emission system test that had been set in the PCM. I/M Ready Status indicates that the vehicle on-board emissions diagnostics have been run. I/M Ready Status is not concerned whether the emission system passed or failed the test, only that on-board diagnosis is complete. Not all vehicles use all possible I/M flags.

Common OBD II Terms**Diagnostic**

When used as a noun, the word diagnostic refers to any on-board test run by the vehicle's Diagnostic Management System. A diagnostic is simply a test run on a system or component to determine if the system or component is operating according to specification. There are many diagnostics, shown in the following list:

- ☐ Misfire
- ☐ Oxygen sensors
- ☐ Oxygen sensor heaters
- ☐ EGR
- ☐ Catalyst monitoring

Enable Criteria

The term "enable criteria" is engineering language for the conditions necessary for a given diagnostic test to run. Each diagnostic has a specific list of conditions which must be met before the diagnostic will run. "Enable criteria" is another way of saying "conditions required". The enable criteria for each diagnostic is listed on the first page of the DTC description in Section 6E1 under the heading "Conditions for Setting the DTC". Enable criteria varies with each diagnostic, and typically includes, but is not limited to the following items:

- ☐ engine speed
- ☐ vehicle speed
- ☐ ECT
- ☐ MAP
- ☐ barometric pressure
- ☐ IAT
- ☐ TP
- ☐ high canister purge
- ☐ fuel trim
- ☐ A/C ON

Trip

Technically, a trip is a key on–run–key off cycle in which all the enable criteria for a given diagnostic are met, allowing the diagnostic to run. Unfortunately, this concept is not quite that simple. A trip is official when all the enable criteria for a given diagnostic are met. But because the enable criteria vary from one diagnostic to another, the definition of trip varies as well. Some diagnostics are run when the vehicle is at operating temperature, some when the vehicle first starts up; some require that the vehicle be cruising at a steady highway speed, some run only when the vehicle is at idle; some diagnostics function with the TCC disabled. Some run only immediately following a cold engine start–up.

A trip then, is defined as a key on–run–key off cycle in which the vehicle was operated in such a way as to satisfy the enabling criteria for a given diagnostic, and this diagnostic will consider this cycle to be one trip. However, another diagnostic with a different set of enable criteria (which were not met) during this driving event, would not consider it a trip. No trip will occur for that particular diagnostic until the vehicle is driven in such a way as to meet all the enable criteria.

The Diagnostic Executive

The Diagnostic Executive is a unique segment of software which is designed to coordinate and prioritize the diagnostic procedures as well as define the protocol for recording and displaying their results. The main responsibilities of the Diagnostic Executive are listed as follows:

- Commanding the MIL ("Check Engine" lamp) ON and OFF
- DTC logging and clearing
- Freeze Frame data for the first emission related DTC recorded
- Non–emission related Service Lamp (future)
- Operating conditions Failure Records buffer, (the number of records will vary)
- Current status information on each diagnostic
- System Status (I/M ready)

The Diagnostic Executive records DTCs and turns ON the MIL when emission–related faults occur. It can also turn OFF the MIL if the conditions cease which caused the DTC to set.

Diagnostic Information

The diagnostic charts and functional checks are designed to locate a faulty circuit or component through a process of logical decisions. The charts are prepared with the requirement that the vehicle functioned correctly at the time of assembly and that there are no multiple faults present.

There is a continuous self–diagnosis on certain control functions. This diagnostic capability is complimented by the diagnostic procedures contained in this manual. The language of communicating the source of the malfunction is a system of diagnostic trouble codes. When a malfunction is detected by the control module, a diagnostic trouble code is set and the Malfunction Indicator Lamp (MIL) ("Check Engine" lamp) is illuminated.

Malfunction Indicator Lamp (MIL)

The Malfunction Indicator Lamp (MIL) looks the same as the MIL you are already familiar with ("Check Engine" lamp). However, OBD II requires that it illuminate under a strict set of guide lines.

Basically, the MIL is turned ON when the PCM detects a DTC that will impact the vehicle emissions.

The MIL is under the control of the Diagnostic Executive. The MIL will be turned ON if an emissions–related diagnostic test indicates a malfunction has occurred. It will stay ON until the system or component passes the same test, for three consecutive trips, with no emissions–related faults.

If the vehicle is experiencing a misfire malfunction which may cause damage to the Three–Way Catalytic Converter (TWC), the MIL will flash once per second. This will continue until the vehicle is outside of speed and load conditions which could cause possible catalyst damage, and the MIL will stop flashing and remain ON steady.

Extinguishing the MIL

When the MIL is ON, the Diagnostic Executive will turn OFF the MIL after *three (3) consecutive* trips that a "test passed" has been reported for the diagnostic test that originally caused the MIL to illuminate.

Although the MIL has been turned OFF, the DTC will remain in the PCM memory (both Freeze Frame and Failure Records) until *forty(40) warm–up cycles after no faults* have been completed.

If the MIL was set by either a fuel trim or misfire–related DTC, additional requirements must be met. In addition to the requirements stated in the previous paragraph, these requirements are as follows:

- The diagnostic tests that are passed must occur with 375 RPM of the RPM data stored at the time the last test failed.
- Plus or minus ten (10) percent of the engine load that was stored at the time the last test failed.
- Similar engine temperature conditions (warmed up or warming up) as those stored at the time the last test failed.

Meeting these requirements ensures that the fault which turned on the MIL has been corrected.

The MIL ("Check Engine" lamp) is on the instrument panel and has the following functions:

- It informs the driver that a fault that affects vehicle emission levels has occurred and that the vehicle should be taken for service as soon as possible.
- As a bulb and system check, the MIL will come ON with the key ON and the engine not running. When the engine is started, the MIL will turn OFF.

- When the MIL remains ON while the engine is running, or when a malfunction is suspected due to a driveability or emissions problem, a Powertrain On-Board Diagnostic (OBD) System Check must be performed. The procedures for these checks are given in On-Board Diagnostic (OBD II) System Check. These checks will expose faults which may not be detected if other diagnostics are performed first.

DTC Types

Each DTC is directly related to a diagnostic test. The Diagnostic Management System sets DTC based on the failure of the tests during a trip or trips. Certain tests must fail two (2) consecutive trips before the DTC is set. The following are the four (4) types of DTCs and the characteristics of those codes:

- Type A
 - Emissions related
 - Requests illumination of the MIL of the first trip with a fail
 - Stores a History DTC on the first trip with a fail
 - Stores a Freeze Frame (if empty)
 - Stores a Fail Record
 - Updates the Fail Record each time the diagnostic test fails
 - Type B
 - Emissions related
 - "Armed" after one (1) trip with a fail
 - "Disarmed" after one (1) trip with a pass
 - Requests illumination of the MIL on the *second consecutive trip* with a fail
 - Stores a History DTC on the second consecutive trip with a fail (The DTC will be armed after the first fail)
 - Stores a Freeze Frame on the second consecutive trip with a fail (if empty)
 - Stores a Fail Record when the first test fails (not dependent on *consecutive trip* fails)
 - Updates the Fail Record each time the diagnostic test fails
- (Some special conditions apply to misfire and fuel trim DTCs)
- Type C (if the vehicle is so equipped)
 - Non-Emissions related
 - Requests illumination of the Service Lamp or the service message on the Drive Information Center (DIC) on the *first trip* with a fail
 - Stores a History DTC on the *first trip* with a fail
 - Does not store a Freeze Frame
 - Stores Fail Record when test fails
 - Updates the Fail Record each time the diagnostic test fails
 - Type D. (*Type D* non-emissions related are not utilized on certain vehicle applications).
 - Non-Emissions related
 - Does not request illumination of any lamp
 - Stores a History DTC on the *first trip* with a fail
 - Does not store a Freeze Frame
 - Stores Fail Record when test fails
 - Updates the Fail Record each time the diagnostic test fails

IMPORTANT: Only four Fail Records can be stored. Each Fail Record is for a different DTC. It is possible that there will not be Fail Records for every DTC if multiple DTCs are set.

Special Cases of Type B Diagnostic Tests

Unique to the misfire diagnostic, the Diagnostic Executive has the capability of alerting the vehicle operator to potentially damaging levels of misfire. If a misfire condition exists that could potentially damage the catalytic converter as a result of high misfire levels, the Diagnostic Executive will command the MIL to "flash" at a rate of once per second during those the time that the catalyst damaging misfire condition is present.

Fuel trim and misfire are special cases of *Type B* diagnostics. Each time a fuel trim or misfire malfunction is detected, engine load, engine speed, and engine coolant temperature are recorded.

When the ignition is turned OFF, the last reported set of conditions remain stored. During subsequent ignition cycles, the stored conditions are used as a reference for similar conditions. If a malfunction occurs during two consecutive trips, the Diagnostic Executive treats the failure as a normal *Type B* diagnostic, and does not use the stored conditions. However, if a malfunction occurs on two non-consecutive trips, the stored conditions are compared with the current conditions. The MIL will then illuminate under the following conditions:

- When the engine load conditions are within 10% of the previous test that failed.
- Engine speed is within 375 rpm, of the previous test that failed.
- Engine coolant temperature is in the same range as the previous test that failed.

Storing and Erasing Freeze Frame Data and Failure Records

Government regulations require that engine operating conditions be captured whenever the MIL is illuminated. The data captured is called Freeze Frame data. The Freeze Frame data is very similar to a single record of operating conditions. Whenever the MIL is illuminated, the corresponding record of operating conditions is recorded to the Freeze Frame buffer.

Freeze Frame data can only be overwritten with data associated with a misfire or fuel trim malfunction. Data from these faults take precedence over data associated with any other fault. The Freeze Frame data will not be erased unless the associated history DTC is cleared.

Each time a diagnostic test reports a failure, the current engine operating conditions are recorded in the *Failure Records* buffer. A subsequent failure will update the recorded operating conditions. The following operating conditions for the diagnostic test which failed *typically* include the following parameters:

- Air Fuel Ratio
- Air Flow Rate

- Fuel Trim
- Engine Speed
- Engine Load
- Engine Coolant Temperature
- Vehicle Speed
- TP Angle
- MAP/BARO
- Injector Base Pulse Width
- Loop Status

Intermittent Malfunction Indicator Lamp


In the case of an "intermittent" fault, the MIL ("Check Engine" lamp) may illuminate and then (after three trips) go OFF. However, the corresponding diagnostic trouble code will be stored in the memory. When unexpected diagnostic trouble codes appear, check for an intermittent malfunction.

A diagnostic trouble code may reset. Consult the "Diagnostic Aids" associated with the diagnostic trouble code. A physical inspection of the applicable sub-system most often will resolve the problem.

Data Link Connector (DLC)

The provision for communicating with the control module is the Data Link Connector (DLC). It is located at the lower left of the instrument panel. The DLC is used to connect to the Tech 2 Scan tool. Some common uses of the Tech 2 are listed below:

- Identifying stored Diagnostic Trouble Codes (DTCs)
- Clearing DTCs
- Performing output control tests
- Reading serial data



TS24064

Decimal/Binary/Hexadecimal Conversions

Beginning in 1996, Federal Regulations require that all auto manufacturers selling vehicles in the United States provide Scan tool manufacturers with software information to display vehicle operating parameters. All Scan tool manufacturers will display a variety of vehicle

information which will aid in repairing the vehicle. Some Scan Tools will display encoded messages which will aid in determining the nature of the concern. The method of encoding involves the use of a two additional numbering systems: Binary and Hexadecimal.

The binary number system has a base of two numbers. Each digit is either a 0 or a 1. A binary number is an eight digit number and is read from right to left. Each digit has a position number with the farthest right being the 0 position and the farthest left being the 7 position. The 0 position, when displayed by a 1, indicates 1 in decimal. Each position to the left is double the previous position and added to any other position values marked as a 1.

A hexadecimal system is composed of 16 different alpha numeric characters. The alpha numeric characters used are numbers 0 through 9 and letters A through F. The hexadecimal system is the most natural and common approach for Scan Tool manufacturers to display data represented by binary numbers and digital code.

Verifying Vehicle Repair

Verification of vehicle repair will be more comprehensive for vehicles with OBD II system diagnostics. Following a repair, the technician should perform the following steps:

1. Review and record the Fail Records and/or Freeze Frame data for the DTC which has been diagnosed (Freeze Frame data will only be stored for an A or B type diagnostic and only if the MIL has been requested).
2. Clear DTC(s).
3. Operate the vehicle within conditions noted in the Fail Records and/or Freeze Frame data.
4. Monitor the DTC status information for the DTC which has been diagnosed until the diagnostic test associated with that DTC runs.

Following these steps are very important in verifying repairs on OBD II systems. Failure to follow these steps could result in unnecessary repairs.

Reading Diagnostic Trouble Codes Using A Tech 2 Scan Tool

The procedure for reading diagnostic trouble code(s) is to use a diagnostic Scan tool. When reading DTC(s), follow instructions supplied by tool manufacturer.

Clearing Diagnostic Trouble Codes

IMPORTANT: Do not clear DTCs unless directed to do so by the service information provided for each diagnostic procedure. When DTCs are cleared, the Freeze Frame and Failure Record data which may help diagnose an intermittent fault will also be erased from memory.

If the fault that caused the DTC to be stored into memory has been corrected, the Diagnostic Executive will begin to count the "warm-up" cycles with no further faults detected, the DTC will automatically be cleared from the PCM memory.

To clear Diagnostic Trouble Codes (DTCs), use the diagnostic Scan tool "clear DTCs" or "clear information" function. When clearing DTCs follow instructions supplied by the tool manufacturer.

6E1-34 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

When a Tech 2 is not available, DTCs can also be cleared by disconnecting one of the following sources for at least thirty (30) seconds.


NOTE: To prevent system damage, the ignition key must be OFF when disconnecting or reconnecting battery power.

- The power source to the control module. Examples: fuse, pigtail at battery PCM connectors etc.

- The negative battery cable. (Disconnecting the negative battery cable will result in the loss of other on-board memory data, such as preset radio tuning).

Tech 2

From 98 MY, Isuzu dealer service departments are recommended to use the Tech 2 scan tool. Please refer to the Tech 2 user guide.



901RW180

Legend


- | | |
|------------------------------|-----------------------|
| (1) PCMCIA Card | (3) SAE 16/19 Adaptor |
| (2) R232 Loop Back Connector | (4) DLC Cable |
| | (5) Tech 2 |

Tech 2 Features

1. Tech 2 is a 12 volt system. Do not apply 24 volt.
2. After connecting and/or installing, the Vehicle Communications Interface (VCI) module, PCMCIA card and DLC connector to the Tech 2, connect the tool to the vehicle DLC.
3. Make sure the Tech 2 is powered OFF when removing or installing the PCMCIA card.
4. The PCMCIA card has a capacity of 10 Megabytes which is 10 times greater than the memory of the Tech 1 Mass Storage Cartridge.
5. The Tech 2 has the capability of two snapshots.
6. The PCMCIA card is sensitive to magnetism and static electricity, so care should be taken in the handling of the card.
7. The Tech 2 can plot a graph when replaying a snapshot.
8. Always return to the Main Menu by pressing the EXIT key several times before shutting down.
9. To clear Diagnostic Trouble Codes (DTCs), open Application Menu and press "F1: Clear DTC Info".

Getting Started

- Before operating the Isuzu PCMCIA card with the Tech 2, the following steps must be performed:
 1. The Isuzu 98 System PCMCIA card (1) inserts into the Tech 2 (5).
 2. Connect the SAE 16/19 adapter (3) to the DLC cable (4).
 3. Connect the DLC cable to the Tech 2 (5)
 4. Make sure the vehicle ignition is off.
 5. Connect the Tech 2 SAE 16/19 adapter to the vehicle DLC.



740RW060

6. Turn on the vehicle ignition.

7. Power the Tech 2 ON and Verify the Tech 2 power up display.




060RW009


NOTE: The RS232 Loop back connector is only to use for diagnosis of Tech 2 and refer to user guide of the Tech 2.

Operating Procedure (Example)

The power up screen is displayed when you power up the tester with the Isuzu system PCMCIA card. Follow the operating procedure below.





060RX060



060RX058


Menu

- The following table shows which functions are used for the available equipment versions.



The following is a brief description of each of the sub menus in DTC Info and DTC. The order in which they appear here is alphabetical and not necessarily the way they will appear on the Tech 2.

DTC Modes




On OBD II vehicles there are five options available in Tech 2 DTC mode to display the enhanced information available. After selecting DTC, the following menu appears:

- DTC Info
- Freeze Frame
- Fail Records (not all applications)
- Clear Info

DTC Information Mode

Use the DTC info mode to search for a specific type of stored DTC information. There are six choices. The service manual may instruct the technician to test for DTCs in a certain manner. Always follow published service procedures.



DTC Status

This selection will display any DTCs that have not run during the current ignition cycle or have reported a test failure during this ignition up to a maximum of 33 DTCs. DTC tests which run and pass will cause that DTC number to be removed from Tech 2 screen.

Fail This Ignition

This selection will display all DTCs that have failed during the present ignition cycle.

History

This selection will display only DTCs that are stored in the PCM's history memory. It will display all type A and B DTCs that have requested the MIL and have failed within the last 40 warm-up cycles. In addition, it will display all type C and type D DTCs that have failed within the last 40 warm-up cycles.

Last Test Failed

This selection will display only DTCs that have failed the last time the test run. The last test may have run during a previous ignition cycle if a type A or type B DTC is displayed. For type C and type D DTCs, the last failure must have occurred during the current ignition cycle to appear as Last Test Fail.

MILSVC or Message Request

This selection will display only DTCs that are requesting the MIL. Type C and type D DTCs cannot be displayed using this option. This selection will report type B DTCs only after the MIL has been requested.

Not Run Since Code Cleared

This option will display up to 33 DTCs that have not run since the DTCs were last cleared. Since any displayed DTCs have not run, their condition (passing or failing) is unknown.

Test Failed Since Code Cleared

This selection will display all active and history DTCs that have reported a test failure since the last time DTCs were cleared. DTCs that last failed more than 40 warm-up cycles before this option is selected will not be displayed.

Miscellaneous Test

This test consists of eight menus-Lights, Relays, EVAP, IAC System, Fuel System, EGR Control, Variable Intake Manifold Solenoid, and Injector Balance Tests.

In these tests, Tech 2 sends operating signals to the systems to confirm their operations thereby to judge the normality of electric circuits.

To judge intermittent trouble,

1. Confirm DTC freeze frame data, and match the freeze frame data as test conditions with the data list displayed by Miscellaneous Test.
2. Confirm DTC setting conditions, and match the setting conditions as test conditions with the data list displayed by Miscellaneous Test.
3. Refer to the latest Service Bulletin.
Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.


Lamps Test

This test is conducted check MIL and Low Fuel Lamp for its working.

Tech2 must be used for this test.


Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.




060RW228

4. Select F0:Lamps Test in the Miscellaneous Test.



060RX043



060RX044

5. Select F0:Malfunction Indicator Lamp.

Malfunction Indicator Lamp	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Malfunction Indicator Lamp Off	
Quit	Off On

060RX019

6. Push "On" soft key.

7. Make sure Lamp illuminates.

8. If lamp illuminates, the Lamp is operating correctly.

9. Select F1:Up Shift Lamp

Up Shift Lamp	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Up Shift Lamp Off	
Quit	Off On

060RX045

Select F2:Low Fuel Lamp

Low Fuel Lamp	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Low Fuel Lamp Off	
Quit	Off On

060RX020

10. Push "On" soft key.

11. Make sure Lamp illuminates.

12. If Lamp illuminates, the Lamp is operaing correctly.

Relays Test

This test is conducted to check Fuel Pump Relay, A/C Clutch Low Fan and High Fan for prepor operation. Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Ignition SW is "On".
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu
F0 : Diagnostic Trouble Codes
F1 : Data Display
F2 : Snapshot
F3 : Miscellaneous Test

060RW228

4. Select F1:Relay Test in the Miscellaneous Test.

Miscellaneous Test
F0 : Lamps
F1 : Relays
F2 : EVAP
F3 : IAC System
F4 : Fuel System
F5 : EGR Control
F6 : Injector Balance Test

060RX046

5. Select F0:Fuel Pump Relay.

Relays
F0 : Fuel Pump Relay
F1 : A/C Clutch Relay
F2 : Low Fan Relay
F3 : High Fan Relay

060RX047

6. Push "On" soft key.

Fuel Pump Relay	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Fuel Pump	On
Quit	Off On

060RX022

7. Control Fuel Pump Relay and check a data list.

8. If the data list changes, the Fuel Pump Relay is normal.

9. Select F1:A/C Clutch Relay.

10. *Run the Engine at idle.

11. Turn on Air Conditioning.

A/C Clutch Relay
Turn On Air Conditioning !

060RX023

12. Push "On" and "Off" of soft key.

13. Control A/C Clutch Relay and check a data list.

14. If the data list changes, the A/C Clutch Relay is normal.

15. Select F2: Low Fan Relay.

Low Fan Relay	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Low Fan	On
Quit	Off On

060RX048

16. Push "On" and "Off" of soft key.

17. Control Low Fan Relay and check a data list.

18. If the data list changes, the Low Fan Relay is normal.

19. Run the Fan Motor.

20. Select F3: High Fan Relay.

High Fan Relay	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
High Fan	On
Quit	Off On

060RX049

21. Push "On" and "Off" of soft key.

22. Control High Fan Relay and check a data list.

If the data list changes, the High Fan Relay is normal.

23. Run the Fan Motor.

EVAP Test

This test is conducted check EVAP system for its working. Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu
F0 : Diagnostic Trouble Codes
F1 : Data Display
F2 : Snapshot
F3 : Miscellaneous Test

060RW228

4. Select F2:EVAP Test in the Miscellaneous Test.

Miscellaneous Test
F0 : Lamps
F1 : Relays
F2 : EVAP
F3 : IAC System
F4 : Fuel System
F5 : EGR Control
F6 : Injector Balance Test

060RX050

5. Select F0: Purge Solenoid.

EVAP	
F0 : Purge Solenoid	
F1 : Vent Solenoid	

060RX025

10. Select F1:EVAP Vent Solenoid.

EVAP	
F0 : Purge Solenoid	
F1 : Vent Solenoid	

060RX025

6. Push "Decrease" or "Increase" soft key.

Purge Solenoid	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
EVAP Purge Solenoid	60%
Quit	Decrease Increase

060RX026

11. Push "On" or "Off" of soft key.

Vent Solenoid	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
EVAP Vent Solenoid	OFF
Quit	Off On

060RX027

7. Control EVAP Purge Solenoid and check a data list.

8. If the data list changes, the purge Solenoid is normal.
Ignition SW is "On".

9. Turn engine off, turn ignition SW "On".

12. Control EVAP Vent Solenoid and check a data list.

13. If the data list changes, the EVAP Vent Solenoid is normal.

Idle Air Control System Test


This test is conducted check to IAC system for proper operation.

Tech 2 must be used for this test.

Test Procedure:


1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.

3. Select F3: Miscellaneous Test in the Application Menu.




060RW228

4. Select F3: IAC System Test in the Miscellaneous Test.



060RX051

5. Select F1: IAC Control Test.




060RX052

6. Push "Increase" or "Decrease" soft key.

7. Control IAC system and check a data list.

○F0: IAC Control



060RX015

8. Select F1: IAC Reset.

9. Push "Reset IAC" soft key.

10. Control IAC Reset and check data list.

11. If data list changes, the IAC has been Reset.

IAC Reset	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Idle Air Control	21 Steps
Quit	Reset IAC

06ORW231-1

4. Select F4: Fuel System in the Miscellaneous Menu.

Miscellaneous Test
F0 : Lamps
F1 : Relays
F2 : EVAP
F3 : IAC System
F4 : Fuel System
F5 : EGR Control
F6 : Injector Balance Test

06ORX053

Fuel System Test

This test is conducted check Fuel Level Gauge for proper operation.

Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Ignition SW is "On".
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu
F0 : Diagnostic Trouble Codes
F1 : Data Display
F2 : Snapshot
F3 : Miscellaneous Test

06ORW228

5. Select F1: Fuel Gauge Level

Fuel System
F0 : Fuel Trim Reset
F1 : Fuel Gauge Level

06ORX028

6. Push "Decrease" or "Increase" of soft key.

Fuel Gauge Level	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Fuel Level	50%
Quit	Decrease Increase

060RX030

7. Control Fuel Level and check data list.

8. If data list changes, the Fuel Gauge Level is normal.

9. Select F0: Fuel Trim Reset.

Fuel System
F0 : Fuel Trim Reset
F1 : Fuel Gauge Level

060RX028

10. Push "Reset" of soft key.

Fuel Trim Reset	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Fuel Trim	
Quit	Reset

060RX029

EGR Control Test

This test is conducted check EGR valve for proper operation.

Tech 2 must be used for this test.


Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu
F0 : Diagnostic Trouble Codes
F1 : Data Display
F2 : Snapshot
F3 : Miscellaneous Test


060RW228

4. Select F5: EGR Control Test in the Miscellaneous Test.




060RX054

3. Select F3: Miscellaneous Test in the Application Menu.




060RW228

5. Control EGR Valve and check data list.



060RX017

4. Select F6: Injector Balance Test in the Miscellaneous Test.



060RX055

6. If the change, the EGR Control is normal.

Injector Balance Test

This test is conducted to make sure the appropriate electric signals are being sent to injectors Nos. 1-6.

Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.

5. Select injector number and push "injector off" of soft key.


Injector Balance Test	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Injector 1	On
Quit	Injector OFF
	Select injector

060RW230-1

6. Make sure of engine speed change.
7. If engine speed changes, the injector electric circuit is normal.
If engine speed does not change, the injector electric circuit or the injector itself is not normal.

Plotting Snapshot Graph


This test selects several necessary items from the data list to plot graphs and makes data comparison on a long term basis. It is an effective test particularly in emission related evaluations.




060RX037

For trouble diagnosis, you can collect graphic data (snapshot) directly from the vehicle. You can replay the snapshot data as needed. Therefore, accurate diagnosis is possible, even though the vehicle is not available.

Plotting Graph Flow Chart (Plotting graph after obtaining vehicle information)



Flow Chart for Snapshot Replay (Plotting Graph)



PRIMARY SYSTEM-BASED DIAGNOSTICS

Primary System-Based Diagnostics

There are primary system-based diagnostics which evaluate system operation and its effect on vehicle emissions. The primary system-based diagnostics are listed below with a brief description of the diagnostic function:

Oxygen Sensor Diagnosis

The fuel control heated oxygen sensor (HO2S 1) is diagnosed for the following conditions:

- ☐ Heater performance (time to activity on cold start)
- ☐ Slow response
- ☐ Response time (time to switch R/L or L/R)
- ☐ Inactive signal (output steady at bias voltage – approx. 450 mV)
- ☐ Signal fixed high
- ☐ Signal fixed low

The catalyst monitor heated oxygen sensor (HO2S 2) is diagnosed for the following conditions:

- ☐ Heater performance (time to activity on cold start).
- ☐ Signal fixed low during steady state conditions or power enrichment (hard acceleration when a rich mixture should be indicated).
- ☐ Signal fixed high during steady state conditions or deceleration mode (deceleration when a lean mixture should be indicated).
- ☐ Inactive sensor (output steady at approx. 438 mV).

If the oxygen sensor pigtail wiring, connector or terminal are damaged, the entire oxygen sensor assembly must be replaced. DO NOT attempt to repair the wiring, connector or terminals. In order for the sensor to function properly, it must have clean reference air provided to it. This clean air reference is obtained by way of the oxygen sensor wire(s). Any attempt to repair the wires, connector or terminals could result in the obstruction of the reference air and degrade oxygen sensor performance. Refer to On-Vehicle Service, Heated Oxygen Sensors.

Fuel Control Heated Oxygen Sensors


The main function of the fuel control heated oxygen sensors is to provide the control module with exhaust stream oxygen content information to allow proper fueling and maintain emissions within mandated levels. After it reaches operating temperature, the sensor will generate a voltage, inversely proportional to the amount of oxygen present in the exhaust gases. The control module uses the signal voltage from the fuel control heated oxygen sensors while in "Closed Loop" to adjust fuel injector pulse width. While in "Closed Loop", the PCM can adjust fuel delivery to maintain an air/fuel ratio which allows the best combination of emission control and driveability. The fuel control heated oxygen sensors are also used to determine catalyst efficiency.

HO2S Heater

Heated oxygen sensors are used to minimize the amount of time required for "Closed Loop" fuel control to begin

operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensor (HO2S 1) to become active. Oxygen sensor heaters are required by the catalyst monitor sensor (HO2S 2) to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further away from the engine.

Catalyst Monitor Heated Oxygen Sensors And Diagnostic Operation



To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NOx, converting it to nitrogen. The PCM has the ability to monitor this process using the pre-catalyst and post-catalyst heated oxygen sensors. The pre-catalyst sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The post-catalyst sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the pre-catalyst signal will be far more active than that produced by the post-catalyst sensor.

In addition to catalyst monitoring, the heated oxygen sensors have a limited role in controlling fuel delivery. If the sensor signal indicates a high or low oxygen content for an extended period of time while in "Closed Loop", the PCM will adjust the fuel delivery slightly to compensate.

- ☐ For the 2.2L engine, the pre-catalyst monitor sensor is designated Bank 1 HO2S 1. The post-catalyst sensor is Bank 1 HO2S 2.

Catalyst Monitor Outputs

The catalyst monitor diagnostic is sensitive to the following conditions:

- Exhaust leaks
- HO₂S contamination
- Alternate fuels

Exhaust system leaks may cause the following:

- Preventing a degraded catalyst from failing the diagnostic.
- Causing a false failure for a normally functioning catalyst.
- Preventing the diagnostic from running.

Some of the contaminants that may be encountered are phosphorus, lead, silica, and sulfur. The presence of these contaminants will prevent the TWC diagnostic from functioning properly.

Three-Way Catalyst Oxygen Storage Capacity

The Three-Way catalyst (TWC) must be monitored for efficiency. To accomplish this, the control module monitors the pre-catalyst HO₂S and post-catalyst HO₂S oxygen sensors. When the TWC is operating properly, the post-catalyst oxygen sensor will have significantly less activity than the pre-catalyst oxygen sensor. The TWC stores and releases oxygen as needed during its normal reduction and oxidation process. The control module will calculate the oxygen storage capacity using the difference between the pre-catalyst and post catalyst oxygen sensor's voltage levels. If the activity of the post-catalyst oxygen sensor approaches that of the pre-catalyst oxygen sensor, the catalyst's efficiency is degraded.

Stepped or staged testing level allow the control module to statistically filter test information. This prevents falsely passing or falsely failing the oxygen storage capacity test. The calculations performed by the on-board diagnostic system are very complex. For this reason, post catalyst oxygen sensor activity should not be used to determine oxygen storage capacity unless directed by the service manual.

Two stages are used to monitor catalyst efficiency. Failure of the first stage will indicate that the catalyst requires further testing to determine catalyst efficiency. The second stage then looks at the inputs from the pre and post catalyst HO₂S sensors more closely before determining if the catalyst is indeed degraded. This further statistical processing is done to increase the accuracy of oxygen storage capacity type monitoring. Failing the first (stage 1) test DOES NOT indicate a failed catalyst. The catalyst may be marginal or the fuel sulfur content could be very high.

Aftermarket HO₂S characteristics may be different from the original equipment manufacturer sensor. This may lead to a false pass or a false fail of the catalyst monitor diagnostic. Similarly, if an aftermarket catalyst does not contain the same amount of cerium as the original part, the correlation between oxygen storage and conversion efficiency may be altered enough to set a false DTC.

MISFIRE MONITOR DIAGNOSTIC OPERATION

Misfire Monitor Diagnostic Operation

The misfire monitor diagnostic is based on crankshaft rotational velocity (reference period) variations. The PCM determines crankshaft rotational velocity using the crankshaft position sensor and camshaft position sensor. When a cylinder misfires, the crankshaft slows down momentarily. By monitoring the crankshaft and camshaft position sensor signals, the PCM can calculate when a misfire occurs.

For a non-catalyst damaging misfire, the diagnostic will be required to monitor a misfire present for between 1000-3200 engine revolutions.

For catalyst-damaging misfire, the diagnostic will respond to misfire within 200 engine revolutions.

Rough roads may cause false misfire detection. A rough road will cause torque to be applied to the drive wheels and drive train. This torque can intermittently decrease the crankshaft rotational velocity. This may be falsely detected as a misfire.

Misfire Counters

Whenever a cylinder misfires, the misfire diagnostic counts the misfire and notes the crankshaft position at the time the misfire occurred. These "misfire counters" are basically a file on each engine cylinder. A current and a history misfire counter are maintained for each cylinder. The misfire current counters (Misfire Cur #1-4) indicate the number of firing events out of the last 200 cylinder firing events which were misfires. The misfire current counter will display real time data without a misfire DTC stored. The misfire history counters (Misfire Hist#1-4) indicate the total number of cylinder firing events which were misfires. The misfire history counters will display 0 until the misfire diagnostic has failed and a DTC P0300 is set. Once the misfire DTC P0300 is set, the misfire history counters will be updated every 200 cylinder firing events. A misfire counter is maintained for each cylinder.

If the misfire diagnostic reports a failure, the diagnostic executive reviews all of the misfire counters before reporting a DTC. This way, the diagnostic executive reports the most current information.

When crankshaft rotation is erratic, a misfire condition will be detected. Because of this erratic condition, the data that is collected by the diagnostic can sometimes incorrectly identify which cylinder is misfiring.

Use diagnostic equipment to monitor misfire counter data on OBD II-compliant vehicles. Knowing which specific cylinder(s) misfired can lead to the root cause, even when dealing with a multiple cylinder misfire. Using the information in the misfire counters, identify which cylinders are misfiring. If the counters indicate cylinders numbers 1 and 4 misfired, look for a circuit or component common to both cylinders number 1 and 4.

Misfire counter information is located in the "Specific Eng." menu, "Misfire Data" sub-menu of the data list.

The misfire diagnostic may indicate a fault due to a temporary fault not necessarily caused by a vehicle

emission system malfunction. Examples include the following items:

- ☐ Contaminated fuel
- ☐ Low fuel
- ☐ Fuel-fouled spark plugs
- ☐ Basic engine fault

FUEL TRIM SYSTEM MONITOR DIAGNOSTIC OPERATION

Fuel Trim System Monitor Diagnostic Operation

This system monitors the averages of short-term and long-term fuel trim values. If these fuel trim values stay at their limits for a calibrated period of time, a malfunction is indicated. The fuel trim diagnostic compares the averages of short-term fuel trim values and long-term fuel trim values to rich and lean thresholds. If either value is within the thresholds, a pass is recorded. If both values are outside their thresholds, a rich or lean DTC will be recorded.


The fuel trim system diagnostic also conducts an intrusive test. This test determines if a rich condition is being caused by excessive fuel vapor from the EVAP canister. In order to meet OBD II requirements, the control module uses weighted fuel trim cells to determine the need to set a fuel trim DTC. A fuel trim DTC can only be set if fuel trim counts in the weighted fuel trim cells exceed specifications. This means that the vehicle could have a fuel trim problem which is causing a problem under certain conditions (i.e., engine idle high due to a small vacuum leak or rough idle due to a large vacuum leak) while it operates fine at other times. No fuel trim DTC would set (although an engine idle speed DTC or HO2S DTC may set). Use the Tech 2 to observe fuel trim counts while the problem is occurring.

A fuel trim DTC may be triggered by a number of vehicle faults. Make use of all information available (other DTCs stored, rich or lean condition, etc.) when diagnosing a fuel trim fault.

Fuel Trim Cell Diagnostic Weights

No fuel trim DTC will set regardless of the fuel trim counts in cell 0 unless the fuel trim counts in the weighted cells are also outside specifications. This means that the vehicle could have a fuel trim problem which is causing a problem under certain conditions (i.e. engine idle high due to a small vacuum leak or rough due to a large vacuum leak) while it operates fine at other times. No fuel trim DTC would set (although an engine idle speed DTC or HO2S DTC may set). Use the Tech 2 to observe fuel trim counts while the problem is occurring.

ON-BOARD DIAGNOSTIC (OBD II) SYSTEM CHECK



D06RX036

Circuit Description

The on-board diagnostic system check is the starting point for any driveability complaint diagnosis. Before using this procedure, perform a careful visual/physical check of the PCM and engine grounds for cleanliness and tightness.

The on-board diagnostic system check is an organized approach to identifying a problem created by an electronic engine control system malfunction.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for poor connections or a damaged harness. Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or

damaged terminals, poor terminal-to-wire connection, and damaged harness.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The MIL ("Check Engine" lamp) should be ON steady with the ignition ON/engine OFF. If not, isolate the malfunction in the MIL circuit.
2. Checks the Class 2 data circuit and ensures that the PCM is able to transmit serial data.
3. This test ensures that the PCM is capable of controlling the MIL and the MIL driver circuit is not shorted to ground.
4. If the engine will not start, the Cranks But Will Not Run chart should be used to diagnose the condition.

7. A Tech 2 parameter which is not within the typical range may help to isolate the area which is causing the problem.

10. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is replaced, the new PCM must be programmed. Refer to PCM Replacement and Programming Procedures in Powertrain Control Module (PCM) and Sensors.


On-Board Diagnostic (OBD II) System Check

Step	Action	Value(s)	Yes	No
1	1. Ignition ON, engine OFF. 2. Observe the malfunction indicator lamp (MIL or "Check Engine lamp"). Is the MIL ("Check Engine lamp") ON?	—	Go to Step 2	Go to No MIL
2	1. Ignition OFF. 2. Install a Tech 2. 3. Ignition ON. 4. Attempt to display PCM engine data with the Tech 2. Does the Tech 2 display PCM data?	—	Go to Step 3	Go to Step 8
3	1. Using the Tech 2 output tests function, select MIL dash lamp control and command the MIL OFF. 2. Observe the MIL. Did the MIL turn OFF?	—	Go to Step 4	Go to MIL ("Check Engine Lamp") On Steady
4	Attempt to start the engine. Did the engine start and continue to run?	—	Go to Step 5	Go to Cranks But Will Not Run
5	Select "Display DTCs" with the Tech 2. Are any DTCs stored?	—	Go to Step 6	Go to Step 7
6	Are two or more of the following DTCs stored? P0107, P0113, P0118, P0122, P0123.	—	Go to "Multiple PCM Information Sensor DTCs Set"	Go to applicable DTC table
7	Compare PCM data values displayed on the Tech 2 to the typical engine scan data values. Are the displayed values normal or close to the typical values?	—	Go to "Typical Scan" Data Value	Go to indicated Component System Checks
8	1. Ignition OFF, disconnect the PCM. 2. Ignition ON, engine OFF. 3. Check the Class 2 data circuit for an open, short to ground, or short to voltage. Also, check the DLC ignition feed circuit for an open or short to ground and the DLC ground circuits for an open. 4. If a problem found, repair as necessary. Was a problem found?	—	Go to Step 2	Go to Step 9

On-Board Diagnostic (OBD II) System Check (Cont'd)

Step	Action	Value(s)	Yes	No
9	<p>1. Attempt to reprogram the PCM. Refer to Powertrain Control Module (PCM) in On-Vehicle Service.</p> <p>2. Attempt to display PCM data with the Tech 2.</p> <p>Does the Tech 2 display PCM engine data?</p>	—	Go to <i>Step 2</i>	Go to <i>Step 10</i>
10	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to Powertrain Control Module (PCM) in On-Vehicle Service.</p> <p>And also refer to latest service bulletin</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

A/C CLUTCH CONTROL CIRCUIT DIAGNOSIS



D06RX037

Circuit Description

When air conditioning and blower fan are selected, and if the system has a sufficient refrigerant charge, a 12-volt signal is supplied to the A/C request input of the powertrain control module (PCM). The A/C request signal may be temporarily cancelled during system operation by the electronic thermostat in the evaporator case. The electronic thermostat may intermittently remove the control circuit ground for the A/C thermostat relay to prevent the evaporator from forming ice. When the A/C request signal is received by the PCM, the PCM supplies a ground from the compressor clutch relay if the engine operating conditions are within acceptable ranges. With the A/C compressor relay energized, battery voltage is supplied to the compressor clutch coil.

The PCM will enable the compressor clutch to engage whenever A/C has been selected with the engine running, unless any of the following conditions are present:

- The throttle is greater than 90%.
- The ignition voltage is below 10.5 volts.
- The engine speed is greater than 4500 RPM for 5 seconds or 5400 RPM.
- The engine coolant temperature (ECT) is greater than 125°C (257°F)
- The intake air temperature (IAT) is less than 5°C (41°F).
- The power steering pressure switch signals a high pressure condition position.

Diagnostic Aids

To diagnose an intermittent fault, check for the following conditions:

- Poor connection at the PCM – Inspect harness connections for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery voltage, and open circuits. If the harness appears to be OK, observe the A/C clutch while moving connectors and wiring harnesses related to the A/C. A sudden clutch malfunction will indicate the source of the intermittent.

be used in diagnosing the system. The Tech 2 has the ability to read the A/C request input to the PCM. The Tech 2 can display when the PCM has commanded the A/C clutch ON. The Tech 2 should have the ability to override the A/C request signal and energize the A/C compressor relay.

A/C Clutch Diagnosis

This chart should be used for diagnosing the electrical portion of the A/C compressor clutch circuit. A Tech 2 will

A/C Clutch Control Circuit Diagnosis

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition ON, engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTCs. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P1546. Does the Tech 2 indicate DTC P1546 "Ran and Passed"?	—	<i>Refer to Diagnostic Aids</i>	Go to Step 3
3	1. Ignition OFF. 2. Remove the A/C Compressor Relay from the Underhood Electrical Center. 3. Ignition ON, engine OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the Fused pins of the A/C Compressor Clutch Relat connector. Does the DVM read the following value?	12 Volts	Go to Step 5	Go to Step 4
4	Check the suspect circuit(s) between the A/C Compressor Clutch Relay connector and the Fuse for the following conditions: <ul style="list-style-type: none"> ○ A short to ground ○ An open circuit ○ A short to voltage Was the problem found?	—	Verify repair	—
5	1. Ignition OFF. 2. Disconnect the Powertrain Controlm Module (PCM) connectors from the PCM. 3. Check the A/C Compressor Clutch Relay control circuit between the PCM and Underhood Electrical Center for the following conditions: <ul style="list-style-type: none"> ○ A short to ground ○ An open circuit ○ A short to voltage Was the problem found?	—	Verify repair	Go to Step 6

A/C Clutch Control Circuit Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Reinstall the A/C Compressor Clutch Relay. 2. Using a fused jumper, ground the A/C Compressor Clutch Relay control circuit at the PCM connector. 3. Ignition ON, engine OFF. Does the A/C Compressor turn ON?	—	Go to <i>Step 9</i>	Go to <i>Step 7</i>
7	1. Ignition OFF. 2. Check the A/C Compressor Clutch circuit between the A/C Compressor Clutch Relay and A/C Compressor Clutch for the following conditions: <ul style="list-style-type: none"> <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to <i>Step 8</i>
8	Replace the A/C Compressor Clutch Relay. Is the action complete?	—	Verify repair	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

ELECTRONIC IGNITION SYSTEM DIAGNOSIS


If the engine cranks but will not run or immediately stalls, the Engine Cranks But Will Not Start chart must be used to determine if the failure is in the ignition system or the fuel system. If DTC P0300, P0341, P0342, or P0336 is set, the appropriate diagnostic trouble code chart must be used for diagnosis.

If a misfire is being experienced with no DTC set, for diagnosis, refer to the Symptoms section.

EVAP CANISTER PURGE SOLENOID

A continuous purge condition with no purge commanded by the PCM will set a DTC P1441. A fault (small leak) in the EVAP purge vacuum system will set a DTC P0442. Refer to the DTC charts for further information.


VISUAL CHECK OF THE EVAPORATIVE EMISSION CANISTER



014RX001

- If the canister is cracked or damaged, replace the canister.
- If fuel is leaking from the canister, replace the canister and check hoses and hose routing.

IDLE AIR CONTROL (IAC) VALVE



0006

The Tech 2 displays the IAC pintle position in counts. A count of "0" indicates the PCM is commanding the IAC pintle to be driven all the way into a fully-seated position. This is usually caused by a vacuum leak.

The higher the number of counts, the more air is being commanded to bypass the throttle blade. In order to diagnose the IAC system, refer to IAC System Check.

For other possible causes of idle problems, refer to Rough, Unstable, or Incorrect Idle, Stalling in Symptoms.

FUEL SYSTEM PRESSURE TEST

A fuel system pressure test is part of several of the diagnostic charts and symptom checks. To perform this test, refer to Fuel System Diagnosis.

FUEL METERING SYSTEM CHECK

Some failures of the fuel metering system will result in an "Engine Cranks But Will Not Run" symptom. If this condition exists, refer to the Cranks But Will Not Run chart. This chart will determine if the problem is caused by the ignition system, the PCM, or the fuel pump electrical circuit.


For the fuel system wiring schematic, refer to Fuel System Electrical Test.

If there is a fuel delivery problem, to diagnose the fuel injectors, the fuel pressure regulator, and the fuel pump, refer to Fuel System Diagnosis.

If a malfunction occurs in the fuel metering system, it usually results in either a rich HO2S signal or a lean HO2S signal. This condition is indicated by the HO2S voltage, which causes the PCM to change the fuel calculation (fuel injector pulse width) based on the HO2S reading. Changes made to the fuel calculation will be indicated by a change in the long term fuel trim values which can be

monitored with a Tech 2. Ideal long term fuel trim values are around 0%; for a lean HO2S signal, the PCM will add fuel, resulting in a fuel trim value above 0%. Some variations in fuel trim values are normal because all engines are not exactly the same. If the evaporative emission canister purge is ON, the long term fuel trim may be as low as -38%. If the long term fuel trim values are greater than +23%, for items which can cause a lean HO2S signal, refer to DTC P0131, DTC P0171, and DTC 1171.

FUEL INJECTOR COIL TEST PROCEDURE AND FUEL INJECTOR BALANCE TEST PROCEDURE



T32003

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

- Relieve the fuel pressure by connecting the J 34730-1 Fuel Pressure Gauge to the fuel pressure connection on the fuel rail.

CAUTION: In order to reduce the risk of fire and personal injury, wrap a shop towel around the fuel pressure connection. The towel will absorb any fuel leakage that occurs during the connection of the fuel pressure gauge. Place the towel in an approved container when the connection of the fuel pressure gauge is complete.

Place the fuel pressure gauge bleed hose in an approved gasoline container.

With the ignition switch OFF open the valve on the fuel pressure gauge.

- Record the lowest voltage displayed by the DVM after the first second of the test. (During the first second, voltage displayed by the DVM may be inaccurate due to the initial current surge.)

Injector Specifications:

Resistance Ohms	Voltage Specification at 10°C–35°C (50°F–95°F)
11.8 – 12.6	5.7 – 6.6


- The voltage displayed by the DVM should be within the specified range.
- The voltage displayed by the DVM may increase throughout the test as the fuel injector windings warm and the resistance of the fuel injector windings changes.
- An erratic voltage reading (large fluctuations in voltage that do not stabilize) indicates an intermittent connection within the fuel injector.

- Injector Specifications:

Highest Acceptable Voltage Reading Above/Below 35°C/10°C (95°F/50°F)	Acceptable Subtracted Value
9.5 Volts	0.6 Volt

- The Fuel Injector Balance Test portion of this chart (Step 7 through Step 11) checks the mechanical (fuel delivery) portion of the fuel injector. An engine cool-down period of 10 minutes is necessary in order to avoid irregular fuel pressure readings due to "Hot Soak" fuel boiling.

Injector Coil Test Procedure (Steps 1-6) And Injector Balance Test Procedure (Steps 7-11)



R262001

CYLINDER				
	1	2	3	4
1st Reading	296 kPa (43psi)	296 kPa (43psi)	296 kPa (43psi)	296 kPa (43psi)
2nd Reading	131 kPa (19 psi)	117 kPa (17 psi)	124 kPa (18 psi)	145 kPa (21 psi)
Amount of Drop (1st Reading-2nd Reading)	165 kPa (24 psi)	179 kPa (26 psi)	172 kPa (25 psi)	151 kPa (22 psi)
Av. drop = 166 kPa/24 psi +/-10 kPa/1.5 psi = 156 - 176 kPa or 22.5 - 25.5 psi	OK	Faulty, Rich (Too Much Fuel Drop)	OK	Faulty, Lean (Too Little Fuel Drop)

NOTE: These figures are examples only.

Injector Coil Test Procedure (Steps 1–6) And Injector Balance Test Procedure (Steps 7–11)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	1. Turn the engine OFF. NOTE: In order to prevent flooding of a single cylinder and possible engine damage, relieve the fuel pressure before performing the fuel injector coil test procedure. 2. Relieve the fuel pressure. Refer to Test Description Number 2. 3. Connect the J 39021–5V Fuel Injector Tester to B+ and ground, and to the J39021–90 Injector Switch Box. 4. Connect the injector switch box to the grey fuel injector harness connector located at the front of the EVAP canister bracket. 5. Set the amperage supply selector switch on the fuel injector tester to the "Coil Test" 0.5 amp position. 6. Connect the leads from the J 39200 Digital Voltmeter (DVM) to the fuel injector tester. Refer to the illustrations associated with the test description. 7. Set the DVM to the tenths scale (0.0). 8. Observe the engine coolant temperature. Is the engine coolant temperature within the specified values?	10°C (50°F) to 35°C (95°F)	Go to <i>Step 3</i>	Go to <i>Step 5</i>
3	1. Set the injector switch box to injector #1. 2. Press the "Push to Start Test" button on the fuel injector tester. 3. Observe the voltage reading on the DVM. IMPORTANT: The voltage reading may rise during the test. 4. Record the lowest voltage observed after the first second of the test. 5. Set the injector switch box to the next injector and repeat steps 2, 3, and 4. Did any fuel injector have an erratic voltage reading (large fluctuations in voltage that did not stabilize) or a voltage reading outside of the specified values?	5.7–6.6 V	Go to <i>Step 4</i>	Go to <i>Step 7</i>
4	Replace the faulty fuel injector(s). Refer to Fuel Injector. Is the action complete?	—	Go to <i>Step 7</i>	—


Injector Coil Test Procedure (Steps 1–6) And Injector Balance Test Procedure (Steps 7–11) (Cont'd)

Step	Action	Value(s)	Yes	No
5	<ol style="list-style-type: none"> 1. Set the injector switch box to injector #1. 2. Press the "Push to Start Test" button on the fuel injector tester. 3. Observe the voltage reading on the DVM. <p>IMPORTANT: The voltage reading may rise during the test.</p> <ol style="list-style-type: none"> 4. Record the lowest voltage observed after the first second of the test. 5. Set the injector switch box to the next injector and repeat steps 2, 3, and 4. <p>Did any fuel injector have an erratic voltage reading (large fluctuations in voltage that did not stabilize) or a voltage reading above the specified value?</p>	9.5 V	Go to Step 4	Go to Step 6
6	<ol style="list-style-type: none"> 1. Identify the highest voltage reading recorded (other than those above 9.5 V). 2. Subtract the voltage reading of each injector from the highest voltage selected in step 1. Repeat until you have a subtracted value for each injector. <p>For any injector, is the subtracted value in step 2 greater than the specified value?</p>	0.6 V	Go to Step 4	Go to Step 7
7	<p>CAUTION: In order to reduce the risk of fire and personal injury, wrap a shop towel around the fuel pressure connection. The towel will absorb any fuel leakage that occurs during the connection of the fuel pressure gauge. Place the towel in an approved container when the connection of the fuel pressure gauge is complete.</p> <ol style="list-style-type: none"> 1. Connect the J 34730-1 Fuel Pressure Gauge to the fuel pressure test port. 2. Energize the fuel pump using the Tech 2. 3. Place the bleed hose of the fuel pressure gauge into an approved gasoline container. 4. Bleed the air out of the fuel pressure gauge. 5. With the fuel pump running, observe the reading on the fuel pressure gauge. <p>Is the fuel pressure within the specified values?</p>	296 kPa– 376 kPa (43–55 psi)	Go to Step 8	Go to Fuel System Diagnosis
8	<p>Turn the fuel pump OFF.</p> <p>Does the fuel pressure remain constant?</p>	—	Go to Step 9	Go to Fuel System Diagnosis

Injector Coil Test Procedure (Steps 1–6) And Injector Balance Test Procedure (Steps 7–11) (Cont'd)


Step	Action	Value(s)	Yes	No
9	<ol style="list-style-type: none"> 1. Connect the J 39021–5V Fuel Injector Tester and J39021–90 Injector Switch Box to the fuel injector harness connector. 2. Set the amperage supply selector switch on the fuel injector tester to the "Balance Test" 0.5–2.5 amp position. 3. Using the Tech 2 turn the fuel pump ON then OFF in order to pressurize the fuel system. 4. Record the fuel pressure indicated by the fuel pressure gauge after the fuel pressure stabilizes. This is the first pressure reading. 5. Energize the fuel injector by depressing the Push to Start Test button on the fuel injector tester. 6. Record the fuel pressure indicated by the fuel pressure gauge after the fuel pressure gauge needle has stopped moving. This is the second pressure reading. 7. Repeat steps 1 through 6 for each fuel injector. 8. Subtract the second pressure reading from the first pressure reading for one fuel injector. The result is the pressure drop value. 9. Obtain a pressure drop value for each fuel injector. 10. Add all of the individual pressure drop values. This is the total pressure drop. 11. Divide the total pressure drop by the number of fuel injectors. This is the average pressure drop. <p>Does any fuel injector have a pressure drop value that is either higher than the average pressure drop or lower than the average pressure drop by the specified value?</p>	10 kPa (1.5 psi)	Go to Step 10	Go to OBD System Check
10	<p>Re-test any fuel injector that does not meet the specification. Refer to the procedure in step 11.</p> <p>NOTE: Do not repeat any portion of this test before running the engine in order to prevent the engine from flooding.</p> <p>Does any fuel injector still have a pressure drop value that is either higher than the average pressure drop or lower than the average pressure drop by the specified value?</p>	10 kPa (1.5 psi)	Go to Step 11	Go to Symptoms
11	<p>Replace the faulty fuel injector(s). Refer to Fuel Injector.</p> <p>Is the action complete?</p>	—	Verify repair	—

POWERTRAIN CONTROL MODULE (PCM) DIAGNOSIS



014RX002

To read and clear diagnostic trouble codes, use a Tech 2.



901RX031

IMPORTANT: Use of a Tech 2 is recommended to clear diagnostic trouble codes from the PCM memory. Diagnostic trouble codes can also be cleared by turning the ignition OFF and disconnecting the battery power from the PCM for 30 seconds. Turning off the ignition and disconnecting the battery power from the PCM will cause all diagnostic information in the PCM memory to be cleared. Therefore, all the diagnostic tests will have to be re-run.

Since the PCM can have a failure which may affect only one circuit, following the diagnostic procedures in this section will determine which circuit has a problem and where it is.

If a diagnostic chart indicates that the PCM connections or the PCM is the cause of a problem, and the PCM is replaced, but this does not correct the problem, one of the following may be the reason:

- There is a problem with the PCM terminal connections. The terminals may have to be removed from the connector in order to check them properly.
- EEPROM program is not correct for the application. Incorrect components or reprogramming the PCM with the wrong EEPROM program may cause a malfunction and may or may not set a DTC.
- The problem is intermittent. This means that the problem is not present at the time the system is being checked. In this case, make a careful physical inspection of all components and wiring associated with the affected system and refer to the Symptoms portion of the manual.
- There is a shorted solenoid, relay coil, or harness. Solenoids and relays are turned ON and OFF by the PCM using internal electronic switches called drivers. A shorted solenoid, relay coil, or harness will not damage the PCM but will cause the solenoid or relay to be inoperative.

MULTIPLE PCM INFORMATION SENSOR DTCs SET

Circuit Description

The powertrain control module (PCM) monitors various sensors to determine the engine operating conditions. The PCM controls fuel delivery, spark advance, and emission control device operation based on the sensor inputs.

The PCM provides a sensor ground to all of the sensors. The PCM applies 5 volts through a pull-up resistor, and determines the status of the following sensors by monitoring the voltage present between the 5-volt supply and the resistor:

- The Fuel Tank Vapor Pressure Sensor
- The throttle position (TP) sensor
- The manifold absolute pressure (MAP) sensor

The PCM provides the following sensors with a 5-volt reference and a sensor ground signal:

- The Linear exhaust gas recirculation (EGR) valve
- The A/C Pressure Sensor

The PCM monitors the separate feedback signals from these sensors in order to determine their operating status.

Diagnostic Aids

Be sure to inspect PCM and engine grounds for being secure and clean.

A short to voltage in one of the sensor input circuits may cause one or more of the following DTCs to be set:

- P0108/P1106
- P0113/P1111
- P0118/P1115
- P0123/P1121
- P0463

If a sensor input circuit has been shorted to voltage, ensure that the sensor is not damaged. A damaged sensor

will continue to indicate a high or low voltage after the affected circuit has been repaired. If the sensor has been damaged, replace it.

An open in the sensor ground circuit between the PCM and the splice will cause one or more of the following DTCs to be set:

- ☐ P0108/P1106
- ☐ P0113/P1111
- ☐ P0118/P1115
- ☐ P0123/P01121
- ☐ P0453/P0463

A short to ground in the 5-volt reference A circuit will cause one or more of the following DTCs to be set:

- ☐ P0107/P1107
- ☐ P0122/P1122
- ☐ P0112/P1112
- ☐ P0117/P1114
- ☐ P0454/P0462
- ☐ P0405
- ☐ P0532

Check for the following conditions:

- ☐ **Poor connection at PCM.** Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and a poor terminal-to-wire connection.
- ☐ **Damaged harness.** Inspect the wiring harness for damage. If the harness is not damaged, observe an affected sensor's displayed value on the Tech 2 with the ignition ON and the engine OFF while you move the connectors and the wiring harnesses related to the following sensors:
 - ☐ IAT
 - ☐ ECT
 - ☐ TP
 - ☐ MAP
 - ☐ EGR
 - ☐ Fuel Tank Vapor Pressure Sensor
 - ☐ A/C Pressure Sensor


Multiple PCM Information Sensor DTCs Set

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Turn the ignition OFF, disconnect the PCM. 2. Turn the ignition ON, check the 5 volt reference circuits for the following conditions: <ul style="list-style-type: none"> ○ A poor connection at the PCM. ○ An open between the PCM connector and the splice. ○ A short to ground. ○ A short to voltage. Is there an open or short?	—	Go to Step 3	Go to Step 4
3	Repair the open or short. Is the action complete?	—	Verify repair	—
4	Check the sensor ground circuit for the following conditions: <ul style="list-style-type: none"> ○ A poor connection at the PCM or the affected sensors. ○ An open between the PCM connector and the affected sensors. Is there an open or a poor connection?	—	Go to Step 5	Go to Step 6
5	Repair the open or the poor connection. Is the action complete?	—	Verify repair	—
6	Measure the voltage between the EGR pintle position sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 7	Go to Step 13
7	Measure the voltage between the MAP sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 8	Go to Step 14
8	Measure the voltage between the TP sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 9	Go to Step 15
9	Measure the voltage between the IAT sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 10	Go to Step 16
10	Measure the voltage between the ECT sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 20	Go to Step 17
11	Measure the voltage between the A/C Pressure Sensor circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 13	Go to Step 19

Multiple PCM Information Sensor DTCs Set (Cont'd)

Step	Action	Value(s)	Yes	No
12	1. Disconnect the EGR valve. 2. Measure the voltage between the EGR pintle position sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 12	Go to Step 17
13	Replace the EGR valve. Is the action complete?	—	Verify repair	—
14	Locate and repair the short to voltage in the MAP sensor signal circuit. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to voltage in the TP sensor signal circuit. Is the action complete?	—	Verify repair	—
16	Locate and repair the short to voltage in the IAT sensor signal circuit. Is the action complete?	—	Verify repair	—
17	Locate and repair the short to voltage in the ECT sensor signal circuit. Is the action complete?	—	Verify repair	—
18	Locate and repair the short to voltage in the A/C Pressure Sensor circuit. Is the action complete?	—	Verify repair	—
19	Locate and repair the short to voltage in the EGR pintle position sensor signal circuit. Is the action complete?	—	Verify repair	—
20	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to OBD System Check	—

EXHAUST GAS RECIRCULATION (EGR) DIAGNOSIS



An EGR flow check diagnosis of the linear EGR system is covered by DTC P0401, P0404, and P0405. If EGR diagnostic trouble code P0401 is encountered, refer to the DTC charts.

ENGINE Tech 2 DATA DEFINITIONS AND RANGES

A/C CLUTCH – Tech 2 Displays ON or OFF

Indicates whether the PCM has commanded the A/C clutch ON. Used in A/C system diagnostics.

A/C REQUEST – Tech 2 Displays YES or NO

Indicates the state of the A/C request input circuit from the HVAC controls. The PCM uses the A/C request signal to determine whether A/C compressor operation is being requested.

AIR/FUEL RATIO – Tech 2 Range 0.0–25.5

Air/fuel ratio indicates the PCM commanded value. In "Closed Loop", the air/fuel ratio should normally be displayed around "14.2–14.7." A lower air/fuel ratio indicates a richer commanded mixture, which may be seen during power enrichment or TWC protection modes. A higher air/fuel ratio indicates a leaner commanded mixture. This can be seen during deceleration fuel mode.

BARO kPa – Tech 2 Range 10–105 kPa/0.00–5.00 Volts

The barometric pressure reading is determined from the MAP sensor signal monitored during key up and wide open throttle (WOT) conditions. The barometric pressure is used to compensate for altitude differences and is normally displayed around "61–104" depending on altitude and barometric pressure.

CMP ACT. COUNTER – Cam Position Activity

DECEL FUEL MODE – Tech 2 Displays ACTIVE or INACTIVE

"ACTIVE" displayed indicates that the PCM has detected conditions appropriate to operate in deceleration fuel mode. The PCM will command the deceleration fuel mode when it detects a closed throttle position while the vehicle is traveling over 20 mph. While in the deceleration fuel mode, the PCM will decrease the amount of fuel delivered by entering "Open Loop" and decreasing the injector pulse width.

DESIRED EGR POS. – Tech 2 Range 0%–100%

Represents the EGR pintle position that the PCM is commanding.

DESIRED IDLE – Tech 2 Range 0–3187 RPM

The idle speed that the PCM is commanding. The PCM will compensate for various engine loads based on engine coolant temperature, to keep the engine at the desired speed.

ECT – (Engine Coolant Temperature) Tech 2 Range –40°C to 151°C (–40°F to 304°F)

The engine coolant temperature (ECT) is mounted in the coolant stream and sends engine temperature information to the PCM. The PCM applies 5 volts to the ECT sensor circuit. The sensor is a thermistor which changes internal resistance as the temperature changes. When the sensor is cold (high resistance), the PCM monitors a high signal voltage and interprets that as a cold engine. As the sensor warms (decreasing resistance), the voltage signal will decrease and the PCM will interpret the lower voltage as a warm engine.

EGR DUTY CYCLE – Tech 2 Range 0%–100%

Represents the EGR valve driver PWM signal from the PCM. A duty cycle of 0% indicates that no EGR flow is being commanded; a 100% duty cycle indicates maximum EGR flow commanded.

EGR FEEDBACK – Tech 2 Range 0.00–5.00 Volts

Indicates the EGR pintle position sensor signal voltage being monitored by the PCM. A low voltage indicates a fully extended pintle (closed valve); a voltage near 5 volts indicates a retracted pintle (open valve).

EGR TEST COUNT – Tech 2 Range 0–255

Indicates the number of EGR flow test samples collected during the current ignition cycle. Under normal operation, only one sample is allowed during an ignition cycle. If the PCM battery feed has been disconnected or a DTC P0401 has been cleared, 10 EGR flow test samples will be allowed during the ignition cycle. This is to allow repair verification during a single ignition cycle.

ENGINE LOAD – Tech 2 Range 0%–100%

Engine load is calculated by the PCM from engine speed and MAP sensor readings. Engine load should increase with an increase in RPM or air flow.

ENGINE RUN TIME – Tech 2 Range 00:00:00–99:99:99 Hrs:Min:Sec

Indicates the time elapsed since the engine was started. If the engine is stopped, engine run time will be reset to 00:00:00.

ENGINE SPEED – Range 0–9999 RPM

Engine speed is computed by the PCM from the 58X reference input. It should remain close to desired idle under various engine loads with engine idling.

EVAP PURGE PWM – Tech 2 Range 0%–100%

Represents the PCM commanded PWM duty cycle of the EVAP purge solenoid valve. "0%" displayed indicates no purge; "100%" displayed indicates full purge.

EVAP VACUUM SWITCH – Tech 2 Displays PURGE or NO PURGE

The EVAP purge vacuum switch is a normally closed switch positioned in the purge line between the canister and the EVAP purge solenoid. The EVAP purge vacuum switch will open when vacuum increases to greater than 5 inches of water in the purge line. The EVAP purge vacuum switch is used by the PCM to monitor EVAP canister purge solenoid operation and purge system integrity. The EVAP purge vacuum switch should be closed to ground with no vacuum present (0% EVAP purge PWM). With EVAP purge PWM at 25% or greater, the EVAP purge vacuum switch should be open and "PURGE" should be indicated.

FUEL PUMP – Tech 2 Displays ON or OFF

Indicates the PCM commanded state of the fuel pump relay driver circuit.

FUEL TRIM CELL – Tech 2 Range 0–21

The fuel trim cell is dependent upon engine speed and MAF sensor readings. A plot of RPM vs. MAF is divided into 22 cells. Fuel trim cell indicates which cell is currently active.

FUEL TRIM LEARN – Tech 2 Displays NO or YES

When conditions are appropriate for enabling long term fuel trim corrections, fuel trim learn will display YES. This indicates that the long term fuel trim is responding to the short term fuel trim. If the fuel trim learn displays NO, then long term fuel trim will not respond to changes in short term fuel trim.

GENERATOR CONTROL – Tech 2 Displays ACTIVE or INACTIVE.**HO2S BANK 1, SEN. 1 – Tech 2 Range 0–1000 mV**

Represents the fuel control exhaust oxygen sensor output voltage. Should fluctuate constantly within a range between 10 mV (lean exhaust) and 1000 mV (rich exhaust) while operating in "Closed Loop".

HO2S BANK 1, SEN. 2 – Tech 2 Range 0–1000 mV

Represents the exhaust oxygen sensor output voltage. Should fluctuate constantly within a range between 10 mV (lean exhaust) and 1000 mV (rich exhaust) while operating in "Closed Loop". This is used along with HO2S Bank 1, Sensor 3 to determine the catalytic converter efficiency in the manual transmission models.

HO2S BANK 1, SEN. 1 – Tech 2 Displays NOT READY or READY

Indicates the status of the exhaust oxygen sensor. The Tech 2 will indicate that the exhaust oxygen sensor is ready when the PCM detects a fluctuating HO2S voltage sufficient to allow "Closed Loop" operation. This will not occur unless the exhaust sensor is warmed up.

HO2S WARM UP TIME BANK 1, SEN. 1 – Tech 2**Range 00:00:00–99:99:99 HRS:MIN:SEC**

Indicates warm-up time for each HO2S. The HO2S warm-up time is used for the HO2S heater test. The PCM will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the HO2S to become active, a DTC will set. If the engine was warm when started, HO2S warm-up will display "00:00:00."

IAC POSITION – Tech 2 Range 0–255 Counts

Displays the commanded position of the idle air control pintle in counts. A larger number of counts means that more air is being commanded through the idle air passage. Idle air control should respond fairly quickly to changes in engine load to maintain desired idle RPM.

IAT (INTAKE AIR TEMPERATURE) – Tech 2 Range –40°C to 151°C (–40°F to 304°F)

The PCM converts the resistance of the intake air temperature sensor to degrees. Intake air temperature (IAT) is used by the PCM to adjust fuel delivery and spark timing according to incoming air density.

IGNITION 1 – Tech 2 Range 0–25.5 Volts

This represents the system voltage measured by the PCM at its ignition feed.

INJ. PULSE BANK 1 – Tech 2 Range 0–1000 msec.

Indicates the amount of time the PCM is commanding each injector ON during each engine cycle. A longer injector pulse width will cause more fuel to be delivered. Injector pulse width should increase with increased engine load.

LONG TERM FUEL TRIM BANK 1

The long term fuel trim is derived from the short term fuel trim values and represents a long term correction of fuel delivery for the bank in question. A value of 0% indicates that the fuel delivery requires no compensation to maintain the PCM commanded air/fuel ratio. A negative value significantly below 0% indicates that the fuel system is rich and fuel delivery is being reduced (decreased injector pulse width). A positive value significantly greater than 0% indicates that a lean condition exists and the PCM is compensating by adding fuel (increased injector pulse width). Because long term fuel trim tends to follow short term fuel trim, a value in the negative range due to canister purge at idle should not be considered unusual. Fuel trim values at maximum authority may indicate an excessively rich or lean system.

LOOP STATUS – Tech 2 Displays OPEN or CLOSED

"CLOSED" indicates that the PCM is controlling fuel delivery according to oxygen sensor voltage. In "OPEN" the PCM ignores the oxygen sensor voltage and bases the amount of fuel to be delivered on TP sensor, engine coolant, and MAF sensor inputs only.

MAP – Tech 2 Range 10–105 kPa (0.00–4.97 Volts)

The manifold absolute pressure (MAP) sensor measures the change in the intake manifold pressure from engine load, EGR flow, and speed changes. As intake manifold pressure increases, intake vacuum decreases, resulting in a higher MAP sensor voltage and kPa reading. The MAP sensor signal is used to monitor intake manifold pressure changes during the EGR flow test, to update the BARO reading, and as an enabling factor for several of the diagnostics.

MIL – Tech 2 Displays ON or OFF

Indicates the PCM commanded state of the malfunction indicator lamp ("Check Engine Lamp").

MISFIRE CUR. CYL. #1/#2/#3/#4 – Tech 2 Range 0–255 Counts

The misfire current counters increase at a rate according to the number of possible misfires being detected on each cylinder. The counters may normally display some activity, but the activity should be nearly equal for all the cylinders.

MISFIRE CUR. CYL. #1/#2/#3/#4 – Tech 2 Range 0–65535 Counts

The misfire history counters display the relative level of misfire that has been detected on each cylinder. The misfire history counters will not update or show any activity until a misfire DTC (P0300) has become active.

MISFIRE FAILURES SINCE FIRST FAIL – Tech 2 Range 0–65535 Counts

Indicates the number of 200 crankshaft revolution sample periods during which the level of misfire was sufficiently high to report a fail.

MISFIRE PASSES SINCE FIRST FAIL – Tech 2 Range 0–65535 Counts

Indicates the number of 200 crankshaft revolution sample periods during which the level of misfire was sufficiently low to report a pass.

POWER ENRICHMENT – Tech 2 Displays ACTIVE or INACTIVE

"ACTIVE" displayed indicates that the PCM has detected conditions appropriate to operate in power enrichment mode. The PCM will command power enrichment mode when a large increase in throttle position and load is detected. While in the power enrichment mode, the PCM will increase the amount of fuel delivered by entering "Open Loop" and increasing the injector pulse width. This is done to prevent a possible sag or hesitation from occurring during acceleration.

RICH/LEAN BANK 1 – Tech 2 Displays RICH or LEAN

Indicates whether oxygen sensor voltage is above a 600 mV threshold voltage ("RICH") or below a 3000 mV threshold voltage ("LEAN"). Should change constantly while in "Closed Loop", indicating that the PCM is controlling the air/fuel mixture properly.

SHORT TERM FT BANK 1

Short term fuel trim to a bank represents a short term correction to the bank fuel delivery by the PCM in response to the amount of time the bank fuel control oxygen sensor voltage spends above or below the 450 mV threshold. If the oxygen sensor voltage has mainly remained less than 450 mV, indicating a lean air/fuel mixture, short term fuel trim will increase into the positive range above 0% and the PCM will pass fuel. If the oxygen sensor voltage stays mainly above the threshold, short term fuel trim will decrease below 0% into the negative range while the PCM reduces fuel delivery to compensate for the indicated rich condition. Under certain conditions such as extended idle and high ambient temperatures, canister purge may cause short term fuel trim to read in the negative range during normal operation. Fuel trim values at maximum authority may indicate an excessively rich or lean system.

SPARK – Tech 2 Range –64° to 64°

Displays the amount of spark advance being commanded by the PCM on the IC circuit.

START-UP ECT – Tech 2 Range –40° C to 151° C (–40° F to 304° F)

Indicates the engine coolant temperature at the time that the vehicle was started. Used by the HO2S diagnostic to determine if the last start-up was a cold start.

START-UP ECT – Tech 2 Range –40° C to 151° C (–40° F to 304° F)

Indicates the intake air temperature at the time that the vehicle was started. Used by the HO2S diagnostic to determine if the last start-up was a cold start.

TOTAL MISFIRE CURRENT COUNT – Tech 2 Range 0–255

Indicates the total number of cylinder firing events that were detected as being misfires during the last 200 crankshaft revolution sample period.

TP ANGLE – Tech 2 Range 0%–100%

TP (throttle position) angle is computed by the PCM from the TP sensor voltage. TP angle should display "0%" at idle and "100%" at wide open throttle.

TP SENSOR – Tech 2 Range 0.00–5.00 Volts

The voltage being monitored by the PCM on the TP sensor signal circuit.

UPSHIFT LAMP (MANUAL TRANSMISSION)

VEHICLE SPEED – Tech 2 Range 0–255 km/h (0–155 mph)

The vehicle speed sensor signal is converted into km/h and mph for display.

WEAK CYLINDER – Tech 2 Displays Cylinder Number

This indicates that the PCM has detected crankshaft speed variations that indicate 2% or more cylinder firing events are misfires.

TYPICAL SCAN DATA VALUES

Use the Typical Scan Data Values Table only after the On-Board Diagnostic System Check has been completed, no DTC(s) were noted, and you have determined that the on-board diagnostics are functioning properly. Tech 2 values from a properly-running engine may be used for comparison with the engine you are diagnosing. The typical scan data values represent values that would be seen on a normally-running engine.

NOTE: A Tech 2 that displays faulty data should not be used, and the problem should be reported to the Tech 2 manufacturer. Use of a faulty Tech 2 can result in misdiagnosis and unnecessary replacement of parts.

2.2L L-4 Engine

Only the parameters listed below are referred to in this service manual for use in diagnosis. For further information on using the Tech 2 to diagnose the PCM and related sensors, refer to the applicable reference section listed below. If all values are within the typical range described below, for diagnosis, refer to the Symptoms section.

Test Conditions

Engine running, lower radiator hose hot, transmission in park or neutral, "Closed Loop", accessories OFF, brake not applied and air conditioning OFF.

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
Engine Speed	Engine	RPM	Within -50 to +100 of "Desired Idle"	Actual engine speed	General Description and Operation
Desired Idle Speed	Engine	RPM	750	800	General Description and Operation, Idle Air Control
Engine Coolant Temperature	Engine	°C	80 – 100 (176 – 212 °F)	80 – 100 (176 – 212 °F)	General Description and Operation, Engine coolant temperature sensor
Start Up ECT	Engine	°C	–	–	General Description and Operation, Engine coolant temperature sensor
Intake Air Temperature	Engine	°C	0 – 100, depends on underhood	0 – 80, depends on underhood	General Description and Operation, Intake Air temperature sensor
Start Up IAT	Engine	°C	–	–	General Description and Operation, Intake Air temperature sensor
Manifold Absolute Pressure	Engine	kPa	23 – 40	19 – 32	General Description and Operation, Manifold Absolute Pressure Sensor. DTC P0106,P0107,P0108,P1106, P1107
Manifold Absolute Pressure	Engine	V	0.65 – 1.32	0.46 – 1.10	General Description and Operation, Manifold Absolute Pressure Sensor. DTC P0106,P0107,P0108,P1106, P1107
Barometric Pressure	Engine	kPa	61 – 104 (depends on altitude and barometric)	61 – 104 (depends on altitude and barometric)	General Description and Operation
Throttle Position	Engine	%	0	3 – 5	General Description and Operation, Throttle Position Sensor. DTC P0121,P0122,P0123,P1121, P1122


Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
Throttle Position Sensor	Engine	V	0.35 – 0.39	0.55 – 0.59	General Discription and Operation, Throttle Position Sensor. DTC P0121,P0122,P0123,P1121, P1122
Calculated Air Flow	Engine	g/s	2.8 – 3.2	8.5 – 8.7	General Discription and and Operation, Manifold Air Flow sensor
Air Fuel Ratio	Engine	Ratio:_to1	14.6:1	14.6:1	General Discription and Operation, Fuel System Metering Purpose, Fuel Trim
Spark Advance	Engine	°CA	10 – 12	27 – 29	General Discription and and Operation, Electronic Ignition System
Engine Load	Engine	%	–	–	–
Fuel system Status	Engine	Closed Loop	–	–	EVAP System
EGR Duty Cycle	Engine	%	0	0	General Discription and and Operation, Liner EGR Operation and Results of Incorrect Operation
Desired EGR Position	Engine	%	0	0	General Discription and and Operation, EGR Pintle Position Sensor
EGR Normalized	Engine	%	0	0	–
EGR Feed Back	Engine	V	0.6 – 0.8	0.6 – 0.8	–
EGR Closed Pintle Position	Engine	Steps	20 – 40	20 – 40	General Discription and and Operation, EGR Pintle Position Sensor
Knock Counter	Engine	Yes/No	Yes	Yes	DTC P0325,P0327
Knock Retard	Engine	°CA	–	–	DTC P0325,P0327
A/C Pressure Sensor	Engine	mV	0	–	DTC P0532,P0533
A/C Clutch Relay	Engine	On/Off	Off	–	General Discription and and Operation, A/C Culutch Circuit Operation
A/C Request	Engine	Yes/No	No	–	General Discription and and Operation, A/C Request Signal
Low Fan Comanded	Engine	Yes/No	–	–	General Discription and and Operation, Cooling Fan Control. DTC P0480,P0481
High Fan Comanded	Engine	Yes/No	–	–	General Discription and and Operation, Cooling Fan Control. DTC P0480,P0481
Camshaft Activity	Engine	Counts	0 – 255	0 – 255	DTC P0341,P0342
EVAP Vent Valve	Engine	On/Off	Off	Off	Diagnosis, EVAP Canister Purge Solenoid And EVAP Vacuum Switch and Visual Check. DTC P1441

6E1-74 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
EVAP Purge Solenoid	Engine	%	17 – 19	35 – 37	Diagnosis, EVAP Emission Canister Purge Valve Check
Low Fuel Lamp	Engine	On/Off	–	–	Engine Fuel. DTC P0461,P0462,P0463
Fuel Level Sensor	Engine	V	–	–	Engine Fuel. DTC P0461,P0462,P0463
Fuel Level	Engine	%	–	–	Engine Fuel. DTC P0461,P0462,P0463
Fuel Pump	Engine	On/Off	On	On	Engine Fuel System
Fuel Tank Pressure Sensor	Engine	V	1.47 – 1.53	1.65 – 1.71	Diagnosis, EVAP Canister Purge Solenoid And EVAP System
Deceleration Fuel Cutoff	Engine	Inactive/Active	Inactive	Inactive	General Discription and and Operation
Idle Air Control	Engine	Steps	–	–	General Discription and and Operation, Intake Air temperature sensor
Vehicle Speed	Engine	MPH or km/h	0	0	Manual Transmission
Ignition Voltage	Engine	V	12.8 – 14.1	12.8 – 14.1	General Discription and and Operation, Electronic Ignition System
Malfunction Indicator Lamp	Engine	On/Off	Off	Off	On–Board Diagnostic System Check
Up Shift Lamp	Engine	On/Off	Off	Off	Up–Shift Lamp system Check
Time From Start	Engine	_:.:_	_:.:_	_:.:_	–
Misfire Current Cyl.#1	Engine Misfire	Counts	0	0	DTC P0300,P0301
Misfire Current Cyl.#2	Engine Misfire	Counts	0	0	DTC P0300,P0302
Misfire Current Cyl.#3	Engine Misfire	Counts	0	0	DTC P0300,P0303
Misfire Current Cyl.#4	Engine Misfire	Counts	0	0	DTC P0300,P0304
Misfire History Cyl.#1	Engine Misfire	Counts	0	0	DTC P0300,P0301
Misfire History Cyl.#2	Engine Misfire	Counts	0	0	DTC P0300,P0302
Misfire History Cyl.#3	Engine Misfire	Counts	0	0	DTC P0300,P0303
Misfire History Cyl.#4	Engine Misfire	Counts	0	0	DTC P0300,P0304
Misfire Failure Since First Fail	Engine Misfire	Counts	0	0	DTC P0300
Misfire Presses Since First Fail	Engine Misfire	Counts	0	0	DTC P0300
Total Misfire	Engine Misfire	Counts	0	0	DTC P0300

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
Weak Cylinder	Engine Misfire	Cylinder #	–	–	DTC P0300,P0301,P0302,P0303,P0304
Misfire Delay Counter	Engine Misfire	Counts	0	0	DTC P0300,P0301,P0302,P0303,P0304
ABS Rough Road	Engine Misfire	Value	Okey	Okey	DTC P1380,P1381
ABS Rough Road Counts	Engine Misfire	Counts	0	0	DTC P1380,P1381
B1 O2 Sensor Ready	Engine HO2S	Yes/No	Yes	Yes	General Discription and and Operation, Fuel Control HO2S. DTC P0135
B1S1 Status (Bank1,Sensor1)	Engine HO2S	Rich/Lean	–	–	General Discription and and Operation, Fuel Control HO2S
B1S1 O2 Sensor (Bank1,Sensor1)	Engine HO2S	mV	50 – 950 changing quickly	50 – 950 changing quickly	General Discription and and Operation, Fuel Control HO2S
B1S2 O2 Sensor (Bank1,Sensor2)	Engine HO2S	mV	100 – 700 changing slowly	100 – 700 changing slowly	General Discription and and Operation, Fuel Metering System
B1S2 O2S Warm Up Time	Engine HO2S	sec	0	–	General Discription and and Operation, Catalyst Monitor Heated Oxygen Sensor
Fuel Trim Learned	Engine HO2S	Yes/No	Yes	Yes	Diagnosis, Fuel Trim Monitor
Fuel Trim Cell	Engine HO2S	Cell No.	18	2 or 6	Diagnosis, Fuel Trim Cell Diagnostic Weights
B1 Long Fuel Trim	Engine HO2S	%	–	–	DTC P0171,P0172
B2 Short Fuel Trim	Engine HO2S	%	–	–	DTC P0171,P0172
Power Enrichment	Engine HO2S	Yes/No	No	No	General Discription and and Operation, Acceleration Mode
Braodcast Code	–	2.2 letter	–	–	–

NO MALFUNCTION INDICATOR LAMP (MIL)



D06RX038

Circuit Description

The "Check Engine" lamp (MIL) should always be illuminated and steady with the ignition ON and the engine stopped. Ignition feed voltage is supplied to the MIL bulb through the meter fuse. The powertrain control module (PCM) turns the MIL ON by grounding the MIL driver circuit.

Diagnostic Aids

An intermittent MIL may be caused by a poor connection, rubbed-through wire insulation, or a wire broken inside the insulation. Check for the following items:

- Inspect the PCM harness and connections for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- If the engine runs OK, check for a faulty light bulb, an open in the MIL driver circuit, or an open in the instrument cluster ignition feed.
- If the engine cranks but will not run, check for an open PCM ignition or battery feed, or a poor PCM to engine ground.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. A "No MIL" condition accompanied by a no-start condition suggests a faulty PCM ignition feed or battery feed circuit.
9. Using a test light connected to B+, probe each of the PCM ground terminals to ensure that a good ground is present. Refer to PCM Terminal End View for terminal locations of the PCM ground circuits.
12. In this step, temporarily substitute a known good relay for the PCM relay. The horn relay is nearby, and it can be verified as "good" simply by honking the horn. Replace the horn relay after completing this step.

17. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is replaced, the new PCM must be programmed. Refer to PCM Replacement and Programming Procedures in Powertrain Control Module (PCM) and Sensors.


No Malfunction Indicator Lamp (MIL)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Attempt to start the engine. Does the engine start?	—	Go to Step 3	Go to Step 6
3	Check the meter fuse for the instrument cluster ignition feed circuit. Is the fuse OK?	—	Go to Step 4	Go to Step 16
4	1. Ignition ON. 2. Engine OFF. 3. Probe the ignition feed circuit at the cluster connector with a test light to ground. Is the test light ON?	—	Go to Step 5	Go to Step 13
5	1. Ignition OFF. 2. Disconnect the PCM. 3. Jumper the MIL driver circuit at the PCM connector to ground. 4. Ignition ON. Is the MIL ON?	—	Go to Step 10	Go to Step 11
6	Check the PCM ignition feed and battery feed fuses (15A Engine fuse and 15A ECM fuse). Are both fuses OK?	—	Go to Step 7	Go to Step 15
7	1. Ignition OFF. 2. Disconnect the PCM. 3. Ignition ON. 4. Probe the ignition feed circuit at the PCM harness connector with a test light to ground. Is the test light ON?	—	Go to Step 8	Go to Step 12
8	Probe the battery feed circuit at the PCM harness connector with a test light to ground. Is the test light ON?	—	Go to Step 9	Go to Step 14
9	Check for a faulty PCM ground connection. Was a problem found?	—	Verify repair	Go to Step 10
10	Check for damaged terminals at the PCM. Was a problem found?	—	Verify repair	Go to Step 17
11	Check for an open MIL driver circuit between the PCM and the MIL. Was a problem found?	—	Verify repair	Go to Step 18
12	Substitute a known "good" relay for the PCM main relay. Was the malfunction fixed?	—	Verify repair	Go to Step 13

No Malfunction Indicator Lamp (MIL) (Cont'd)

Step	Action	Value(s)	Yes	No
13	Repair the open in the ignition feed circuit. Is the action complete?	—	Verify repair	—
14	Locate and repair the open PCM battery feed circuit. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in the PCM ignition feed circuit or PCM battery feed circuit. Is the action complete?	—	Verify repair	—
16	Locate and repair the short to ground in the ignition feed circuit to the instrument cluster, and replace the fuse. Is the action complete?	—	Verify repair	—
17	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to PCM in On-Vehicle Service for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.	—	Verify repair	—
18	Check the MIL driver circuit for a poor connection at the instrument panel connector. Was a problem found?	—	Verify repair	Go to Instrument Panel in Electrical Diagnosis

MALFUNCTION INDICATOR LAMP (MIL) ON STEADY



D06RX039

Circuit Description

The malfunction indicator lamp (MIL) should always be illuminated and steady with the ignition ON and the engine stopped. Ignition feed voltage is supplied directly to the MIL indicator. The powertrain control module (PCM) turns the MIL ON by grounding the MIL driver circuit.

The MIL should not remain ON with the engine running and no DTC(s) set. A steady MIL with the engine running and no DTC(s) suggests a short to ground in the MIL driver circuit.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation, or a wire broken inside the insulation. Check for the following items:

- Poor connection or damaged harness – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. If the MIL does not remain ON when the PCM is disconnected, the MIL driver wiring is not faulty.
3. If the MIL driver circuit is OK, the instrument panel cluster is faulty.
6. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is replaced, the new PCM must be programmed. Refer to PCM Replacement and Programming Procedures in Powertrain Control Module (PCM) and Sensors.


Malfunction Indicator Lamp (MIL) ON Steady

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition OFF, disconnect the PCM. 2. Ignition ON, observe the MIL (Service Engine Soon lamp). Is the MIL ON?	—	Go to Step 3	Go to Step 5
3	1. Ignition OFF, disconnect the instrument panel cluster. 2. Check the MIL driver circuit between the PCM and the instrument panel cluster for a short to ground. 3. If a problem is found, repair as necessary. Was the MIL driver circuit shorted to ground?	—	Go to OBD System Check	Go to Step 4
4	Replace the instrument panel cluster. Is the action complete?	—	Go to OBD System Check	—
5	1. Ignition OFF, reconnect the PCM. 2. Ignition ON, reprogram the PCM. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. 3. Using the Tech 2 output controls function, select MIL dash lamp control and command the MIL OFF. Did the MIL turn OFF?	—	Go to OBD System Check	Go to Step 6
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to OBD System Check	—

ENGINE CRANKS BUT WILL NOT RUN



D06RX027



Circuit Description

The electronic ignition system uses a dual coil method of spark distribution. In this type of ignition system, the powertrain control module (PCM) triggers the correct driver inside the ignition control module (ICM), which then triggers the correct ignition coil based on the 58X signal received from the crankshaft position sensor (CKP). The spark plug connected to the coil fires when the ICM opens the ground circuit for the coil's primary circuit. During crank, the PCM monitors the CKP 58X signal. The CKP signal is used to determine which cylinder will fire first. After the CKP 58X signal has been processed by the PCM, it will command all four injectors to allow a priming shot of fuel for all the cylinders. After the priming, the injectors are left OFF during the next four 58X reference pulses from the CKP. This allows each cylinder a chance to use the fuel from the priming shot. During this waiting period, a camshaft position (CMP) signal pulse will have been received by the PCM. The CMP signal allows the PCM to operate the injectors sequentially based on camshaft position. If the camshaft position signal is not

present at start-up, the PCM will begin sequential fuel delivery with a 1-in-4 chance that fuel delivery is correct. The engine will run without a CMP signal, but will set a DTC code.

Diagnostic Aids

An intermittent problem may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for the following items:

- Poor connection or damaged harness – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- Faulty engine coolant temperature sensor – Using a Tech 2, compare engine coolant temperature with intake air temperature on a completely cool engine. Engine coolant temperature should be within 10°C of intake air temperature. If not, replace the ECT sensor.

Engine Cranks But Will Not Run

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Use the Tech 2 and check for any DTC's. Are any DTC's stored?	—	Go to Applicable DTC Table	Go to Step 3
3	Check the 15A ignition coil fuse, the 15A engine device fuse, and the 15A ECM fuse. Was a fuse blown?	—	Go to Step 4	Go to Step 5
4	Check for a short to ground and replace the fuse. Is the action complete?	—	Verify repair	—
5	1. Ignition ON. 2. Use a grounded test lamp to verify that B+ is available at the ignition coil fuse, the engine device fuse, and the ECM fuse. Was B+ available at the fuses?	—	Go to Step 7	Go to Step 6
6	Repair the open ignition feed circuit.	—	Go to Fuel System Electrical Test	Go to Fuel System Diagnosis
7	1. Disconnect the ignition secondary wire at the No.1. 2. Install a spark tester J 26792 at the end of the disconnected ignition coil. 3. Clip the spark tester J 26792 to a good ground (not near the battery). 4. Observe the spark tester while the engine is cranking. Was a crisp blue spark observed? (Only one or two sparks followed by no result is considered the same as "No Spark.")	—	Go to Step 16	Go to Step 8

Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Disconnect the ignition module harness connector. 2. Check for an open or short circuit between the ignition control module and the PCM? Was a problem found?	—	Go to Step 9	Go to Step 10
9	Repair the faulty circuit.	—	Verify repair	—
10	1. Ignition ON. 2. Using a Digital Voltmeter (DVM) check the ignition wire coil at the ignition module harness connector? Was the voltage equal to the specified value?	B+	Go to Step 12	Go to Step 11
11	Repair the open circuit.	—	Verify repair	—
12	1. Ignition OFF. 2. With DVM, check for an open in the ground wire at the ignition module harness connector. Was the ground wire OK?	—	Go to Step 14	Go to Step 13
13	Repair the faulty wire.	—	Verify repair	—
14	Replace the ignition module, verify the repair. Attempt to start the engine. Is there still a problem?	—	Go to Step 15	Verify repair
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
16	Use an ohmmeter to check the ignition coil primary winding resistance. Was the primary winding resistance approximately equal to the specified value?	0.8–18 Ω	Go to Step 17	Go to Step 18
17	Use an ohmmeter to check the ignition coil secondary winding resistance. Was the secondary winding resistance equal to the specified value?	9,000–12,000 Ω	Go to Step 19	Go to Step 18
18	Replace the ignition coil.	—	Verify repair	—
19	Test the resistance of the coil-to-spark plug secondary ignition wire. Was the resistance greater than the specified value?	10,000 Ω per foot	Go to Step 20	Go to Step 21


Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
20	Replace the coil-to-spark plug secondary ignition wire and any other secondary wires which exceed the specified value. Is there still a problem?	10,000 Ω per foot	Go to Step 21	Verify repair
21	1. Remove the spark plugs from all cylinders. 2. Visually inspect the spark plug electrodes. 3. Replace any spark plugs with loose or missing electrodes or cracked insulators. Did your inspection reveal any spark plugs exhibiting excessing fouling?	—	Correct the fouling condition	Go to Step 33
22	Verfiy repair. Attempt to start the engine. Is there still a problem?	—	Go to Step 23	Go to Step 22
23	1. Ignition OFF, install a fuel pressure gauge at the test fitting on the fuel supply line in the engine compartment. CAUTION: Use a shop cloth to absorb any fuel leakage while making the connection. 2. Check the engine and observe the fuel pressure. Is the fuel pressure within the specified values, and does it hold steady for 2 seconds?	285–375 kPa (43–55 psi)	Go to Step 25	Go to Step 24
24	Is any fuel pressure indicated?	—	Go to Fuel System Electrical Test	Go to Fuel System Diagnosis
25	1. Install switch box J 39021-2 and J 39021-90 at the injector test connector. 2. Activate an injector. Did the fuel pressure drop when the injector was activated?	—	Go to Step 26	Go to Fuel System Diagnosis
26	Pressurize the fuel system using the ignition ON and use the injector switch box to test pressure drop for each injector. Was there a pressure drop when each injector was activated?	—	Go to Step 27	Go to Fuel System Diagnosis
27	1. Remove the switch box and install an injector test light J 39021-45 at the injector test harness connector. 2. Crank the engine. Are any of the lights blinking when the engine is cranked?	—	Go to Step 33	Go to Step 28
28	1. Raise the vehicle and disconnect the CKP sensor harness. 2. Ignition ON. 3. With a test light to ground, probe the CKP ignition feed harness terminal. Did the light illuminate?	—	Go to Step 29	Go to Step 30

Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
29	1. Ignition ON. 2. At the CKP harness connector, connect a test lamp between the ignition and ground terminals. Did the lamp illuminate?	—	Go to Step 31	Go to Step 32
30	Check the CKP High circuit between the sensor and the PCM for a short to ground or open circuit. Was a problem found?	—	Verify repair	Go to Step 33
31	Replace the CKP position sensor. Is there still a problem?	—	Go to Step 34	—
32	Check the CKP Low circuit between the sensor and the PCM for: an open circuit, a short to ground, or short to voltage. Was the problem found?	—	Verify repair	Go to Step 33
33	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.	—	Verify repair	—
34	1. Test the fuel for contamination. 2. If a problem is found, clean the fuel system and correct the contaminated fuel condition as necessary. Replace the fuel filter and replace any injectors that are not delivering fuel (see Injector Balance Test). Was a problem found?	—	Verify repair	Go to Step 35
35	To diagnose the following conditions, refer to Engine Mechanical: ○ Slipped camshaft drive belt. ○ Leaking or sticky valves or rings. ○ Excessive valve deposits. ○ Loose or worn rocker arms. ○ Weak valve springs ○ Leaking head gasket. Is the action complete?	—	Verify repair	—

FUEL SYSTEM ELECTRICAL TEST



D06RX040

Circuit Description

When the ignition switch is first turned ON, the powertrain control module (PCM) energizes the fuel pump relay which applies power to the in-tank fuel pump. The fuel pump relay will remain ON as long as the engine is running or cranking and the PCM is receiving 58X crankshaft position pulses. If no 58X crankshaft position pulses are present, the PCM de-energizes the fuel pump relay within 2 seconds after the ignition is turned ON or the engine is stopped.

The fuel pump delivers fuel to the fuel rail and injectors, then to the fuel pressure regulator. The fuel pressure regulator controls fuel pressure by allowing excess fuel to be returned to the fuel tank. With the engine stopped and ignition ON, the fuel pump can be turned ON by using a command by the Tech 2.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation, or a wire broken inside the insulation. Check for the following items:

- Poor connection or damaged harness – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. If the fuel pump is operating but incorrect pressure is noted, the fuel pump wiring is OK and the "Fuel System Pressure Test" chart should be used for diagnosis.

CAUTION: To reduce the risk of fire and personal injury:

- It is necessary to relieve fuel system pressure before connecting a fuel pressure gauge. Refer to Fuel Pressure Relief Procedure, below.
- A small amount of fuel may be released when disconnecting the fuel lines. Cover fuel line fittings with a shop towel before disconnecting, to catch any fuel that may leak out. Place the towel in an approved container when the procedure is completed.

Fuel Pressure Relief Procedure

1. Remove the fuel cap.

2. Remove the fuel pump relay from the underhood relay center.
3. Start the engine and allow it to stall.
4. Crank the engine for an additional 3 seconds.

Fuel Gauge Installation

1. Remove the shoulder fitting cap.
2. Install fuel gauge J 34730-1 to the fuel feed line located in front of and above the right side valve cover.
3. Reinstall the fuel pump relay.


Fuel System Electrical Test

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Read the "Caution" above. 2. Relieve the fuel system pressure and install the fuel pump pressure gauge to the test fitting. 3. Use a Tech 2 to command the fuel pump ON. Is there an immediate pressure build-up which indicates the pump is running?	—	Go to Step 3	Go to Step 4
3	1. Verify that the pump is not running by removing the fuel filler cap and listening. 2. Command the pump ON with the Tech 2. Did the pump turn OFF after 2 seconds?	—	Test completed	Go to Step 12
4	1. Ignition OFF. 2. Remove the fuel pump relay. 3. Ignition SW "On", Engin Off. 4. Using a test light connected to ground, probe the battery feed to the relay. Did the light illuminate?	—	Go to Step 6	Go to Step 5
5	Repair short or open battery feed to fuel pump relay. Is the action complete?	—	Verify repair	—
6	1. Connect a test light between the two wires that connect to the fuel pump relay pull-in coil. 2. Ignition ON. Did the test light illuminate for 2 seconds and then turn off?	—	Go to Step 12	Go to Step 7
7	1. With a test light connected to battery (—), probe the fuel pump relay connector at the wire which runs from the relay pull-in coil to the PCM. 2. Ignition ON. Did the test light illuminate for 2 seconds and then turn off?	—	Go to Step 8	Go to Step 9
8	Locate and repair open in the fuel pump relay ground circuit. Is the action complete?	—	Verify repair	—

Fuel System Electrical Test (Cont'd)

Step	Action	Value(s)	Yes	No
9	Check for short or open between the PCM and the fuel pump relay. Was a problem found?	—	Verify repair	Go to Step 10
10	1. Check the fuel pump relay circuit for a poor terminal connection at the PCM. 2. If a problem is found, replace terminal as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
12	1. Reconnect the fuel pump relay. 2. Disconnect the fuel pump electrical connector at the fuel tank. 3. Using a test light connected to ground, probe the fuel pump feed wire (harness side). 4. Command the fuel pump ON with a Tech 2. Did the light illuminate for 2 seconds?	—	Go to Step 15	Go to Step 13
13	1. Honk the horn to verify that the horn relay is functioning. 2. Substitute the horn relay for the fuel pump relay. 3. Leave the test light connected as in step 12. 4. Command the fuel pump ON with the Tech 2. Did the test light illuminate for 2 seconds when the fuel pump was commanded ON?	—	Go to Step 17	Go to Step 14
14	1. Re-connect the horn relay in its proper location. 2. Check for a short circuit, blown fuse or open circuit between the relay and the fuel tank. Is the action complete?	—	Verify repair	—
15	1. With the fuel pump electrical connector at the fuel tank disconnected, connect a test light between the feed wire and the ground wire (harness side). 2. Command the fuel pump ON with a Tech 2. Did the test light illuminate for 2 seconds?	—	Go to Step 18	Go to Step 16
16	Repair the open circuit in the fuel pump ground wire. Is the action complete?	—	Verify repair	—
17	1. Re-connect the horn relay in its proper location. 2. Replace the fuel pump relay. Is the action complete?	—	Verify repair	—
18	Replace the fuel pump. Is the action complete?	—	Verify repair	—

FUEL SYSTEM DIAGNOSIS



D06RX040

Circuit Description

When the ignition switch is turned ON, the powertrain control module (PCM) will turn ON the in-tank fuel pump. The in-tank fuel pump will remain ON as long as the engine is cranking or running and the PCM is receiving 58X crankshaft position pulses. If there are no 58X crankshaft position pulses, the PCM will turn the in-tank fuel pump OFF 2 seconds after the ignition switch is turned ON or 2 seconds after the engine stops running. The in-tank fuel pump is an electric pump within an integral reservoir. The in-tank fuel pump supplies fuel through an in-line fuel filter to the fuel rail assembly. The fuel pump is designed to provide fuel at a pressure above the pressure needed by the fuel injectors. A fuel pressure regulator, attached to the fuel rail, keeps the fuel available to the fuel injectors at a regulated pressure. Unused fuel is returned to the fuel tank by a separate fuel return line.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Connect the fuel pressure gauge to the fuel feed line as shown in the fuel system illustration. Wrap a shop towel around the fuel pressure connection in order to absorb any fuel leakage that may occur when installing the fuel pressure gauge. With the ignition switch ON and the fuel pump running, the fuel pressure indicated by the fuel pressure gauge should be 283–376 kPa (41–55 psi). This pressure is controlled by the amount of pressure the spring inside the fuel pressure regulator can provide.
3. A fuel system that cannot maintain a constant fuel pressure has a leak in one or more of the following areas:
 - The fuel pump check valve.
 - The fuel pump flex line.

- The valve or valve seat within the fuel pressure regulator.
 - The fuel injector(s)
4. Fuel pressure that drops off during acceleration, cruise, or hard cornering may cause a lean condition. A lean condition can cause a loss of power, surging, or misfire. A lean condition can be diagnosed using a Tech 2. If an extremely lean condition occurs, the oxygen sensor(s) will stop toggling. The oxygen sensor output voltage(s) will drop below 500 mV. Also, the fuel injector pulse width will increase.

IMPORTANT: Make sure the fuel system is not operating in the "Fuel Cut-Off Mode."

When the engine is at idle, the manifold pressure is low (high vacuum). This low pressure (high vacuum) is applied to the fuel pressure regulator diaphragm. The low pressure (high vacuum) will offset the pressure being applied to the fuel pressure regulator diaphragm by the spring inside the fuel pressure regulator. When this happens, the result is lower fuel pressure. The fuel pressure at idle will vary slightly as the barometric pressure changes, but the fuel pressure at idle should always be less than the fuel pressure noted in step 2 with the engine OFF.

16. Check the spark plug associated with a particular fuel injector for fouling or saturation in order to determine if that particular fuel injector is leaking. If checking the spark plug associated with a particular fuel injector for fouling or saturation does not determine that a particular fuel injector is leaking, use the following procedure:
- Remove the fuel rail, but leave the fuel lines and injectors connected to the fuel rail. Refer to Fuel Rail Assembly in On-Vehicle Service.
 - Lift the fuel rail just enough to leave the fuel injector nozzles in the fuel injector ports.

CAUTION: In order to reduce the risk of fire and personal injury that may result from fuel spraying on the engine, verify that the fuel rail is positioned over the fuel injector ports and verify that the fuel injector retaining clips are intact.

- **Pressurize the fuel system by connecting a 10 amp fused jumper between B+ and the fuel pump relay connector.**
 - **Visually and physically inspect the fuel injector nozzles for leaks.**
17. A rich condition may result from the fuel pressure being above 376 kPa (55 psi). A rich condition may cause a DTC P0132 or a DTC P0172 to set. Driveability conditions associated with rich conditions can include hard starting (followed by black smoke) and a strong sulfur smell in the exhaust.

20. This test determines if the high fuel pressure is due to a restricted fuel return line or if the high fuel pressure is due to a faulty fuel pressure regulator.

21. A lean condition may result from fuel pressure below 333 kPa (48 psi). A lean condition may cause a DTC P0131 or a DTC P0171 to set. Driveability conditions associated with lean conditions can include hard starting (when the engine is cold), hesitation, poor driveability, lack of power, surging, and misfiring.

22. Restricting the fuel return line causes the fuel pressure to rise above the regulated fuel pressure. Command the fuel pump ON with the Tech 2. The fuel pressure should rise above 376 kPa (55 psi) as the fuel return line becomes partially closed.

NOTE: Do not allow the fuel pressure to exceed 414 kPa (60 psi). Fuel pressure in excess of 414 kPa (60 psi) may damage the fuel pressure regulator.

CAUTION: To reduce the risk of fire and personal injury:

- **It is necessary to relieve fuel system pressure before connecting a fuel pressure gauge. Refer to Fuel Pressure Relief Procedure, below.**
- **A small amount of fuel may be released when disconnecting the fuel lines. Cover fuel line fittings with a shop towel before disconnecting, to catch any fuel that may leak out. Place the towel in an approved container when the procedure is completed.**

Fuel Pressure Relief Procedure

1. Remove the fuel cap.
2. Remove the fuel pump relay from the underhood relay center.
3. Start the engine and allow it to stall.
4. Crank the engine for an additional 3 seconds.

Fuel Gauge Installation

1. Remove the shoulder fitting cap.
2. Install fuel gauge J 34730-1 to the fuel feed line located on the upper right side of the engine near the EGR valve.
3. Reinstall the fuel pump relay.

Fuel System Diagnosis

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Turn the ignition OFF. 2. Turn the air conditioning system OFF. 3. Relieve fuel system pressure and install the fuel pressure gauge. 4. Turn the ignition ON. NOTE: The fuel pump will run for approximately 2 seconds. Use the Tech 2 to command the fuel pump ON. 5. Observe the fuel pressure indicated by the fuel pressure gauge with the fuel pump running. Is the fuel pressure within the specified limits?	283–376 kPa (41–55 psi)	Go to Step 3	Go to Step 17
3	NOTE: The fuel pressure will drop when the fuel pump stops running, then it should stabilize and remain constant. Does the fuel pressure indicated by the fuel pressure gauge remain constant?	—	Go to Step 4	Go to Step 12
4	1. When the vehicle is at normal operating temperature, turn the ignition ON to build fuel pressure and observe the measurement on the gauge. 2. Start the engine and observe the fuel pressure gauge. Did the reading drop by the amount specified after the engine was started?	21–105 kPa (3–15 psi)	Go to Step 5	Go to Step 9
5	Is fuel pressure dropping off during acceleration, cruise, or hard cornering?	—	Go to Step 6	Check for improper fuel
6	Visually and physically inspect the following items for a restriction: <input type="radio"/> The in-pipe fuel filter. <input type="radio"/> The fuel feed line. Was a restriction found?	—	Verify repair	Go to Step 7
7	Remove the fuel tank and visually and physically inspect the following items: <input type="radio"/> The fuel pump strainer for a restriction. <input type="radio"/> The fuel line for a leak. <input type="radio"/> Verify that the correct fuel pump is in the vehicle. Was a problem found in any of these areas?	—	Verify repair	Go to Step 8
8	Replace the fuel pump. Is the action complete?	—	Verify repair	—
9	1. Disconnect the vacuum hose from the fuel pressure regulator. 2. With the engine idling, apply 12–14 inches of vacuum to the fuel pressure regulator. Does the fuel pressure indicated by the fuel pressure gauge drop by the amount specified?	21–105 kPa (3–15 psi)	Go to Step 10	Go to Step 11


Fuel System Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
10	Locate and repair the loss of vacuum to the fuel pressure regulator. Is the action complete?	—	Verify repair	—
11	Replace the fuel pressure regulator. Is the action complete?	—	Verify repair	—
12	1. Run the fuel pump with the Tech 2. 2. After pressure has built up, turn off the pump and clamp the supply hose shut with suitable locking pliers which will not damage the hose. Does the fuel pressure indicated by the fuel pressure gauge remain constant?	—	Go to Step 13	Go to Step 15
13	Visually inspect the fuel supply line and repair any leaks. Was a problem found?	—	Verify repair	Go to Step 14
14	Remove the fuel tank and inspect for leaky hose or in-tank fuel line. Was a problem found?	—	Verify repair	Go to Step 8
15	1. If the pliers are still clamped to the fuel supply hose, remove the locking pliers. 2. With suitable locking pliers which will not damage the hose, clamp the fuel return line to prevent fuel from returning to the fuel tank. 3. Run the fuel pump with the Tech 2. 4. After pressure has built up, remove power to the pump. Does the fuel pressure indicated by the fuel pressure gauge remain constant?	—	Go to Step 11	Go to Step 16
16	Locate and replace any leaking fuel injector(s). Is the action complete?	—	Verify repair	—
17	Is the fuel pressure indicated by the fuel pressure gauge above the specified limit?	376 kPa (55 psi)	Go to Step 18	Go to Step 21
18	1. Relieve the fuel pressure. Refer to the Fuel Pressure Relief. 2. Disconnect the fuel return line from the fuel rail. 3. Attach a length of flexible hose to the fuel rail return outlet passage. 4. Place the open end of the flexible hose into an approved gasoline container. 5. Run the fuel pump with the Tech 2. 6. Observe the fuel pressure indicated by the fuel pressure gauge with the fuel pump running. Is the fuel pressure within the specified limits?	290–376 kPa (42–55 psi)	Go to Step 19	Go to Step 20
19	Locate and correct the restriction in the fuel return line. Is the action complete?	—	Verify repair	—
20	Visually and physically inspect the fuel rail outlet passages for a restriction. Was a restriction found?	—	Verify repair	Go to Step 11

Fuel System Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
21	Is the fuel pressure indicated by the fuel pressure gauge above the specified value?	0 kPa (0 psi)	Go to Step 22	Go to Step 23
22	1. Command the fuel pump ON with the Tech 2. 2. Using suitable pliers which will not damage the fuel hose, gradually apply pressure with the pliers to pinch the flexible fuel return hose closed. CAUTION: Do not let the fuel pressure exceed the second specified value. Does the fuel pressure indicated by the fuel pressure gauge rise above the first specified value?	414 kPa (60 psi)	Go to Step 11	Go to Step 7
23	1. Command the fuel pump ON with the Tech 2. 2. Remove the fuel filler cap and listen for the sound of the fuel pump running. 3. Turn the pump off. Was the fuel pump running?	—	Go to Step 7	Go to Fuel System Electrical Test Chart

IDLE AIR CONTROL (IAC) SYSTEM CHECK



D06RX041

Circuit Description

The powertrain control module (PCM) controls engine idle speed with the idle air control (IAC) valve. To increase idle speed, the PCM retracts the IAC valve pintle away from its seat, allowing more air to bypass the throttle bore. To decrease idle speed, it extends the IAC valve pintle towards its seat, reducing bypass air flow. A Tech 2 will read the PCM commands to the IAC valve in counts. Higher counts indicate more air bypass (higher idle). Lower counts indicate less air is allowed to bypass (lower idle).

Diagnostic Aids

A slow, unstable, or fast idle may be caused by a non-IAC system problem that cannot be overcome by the IAC valve. Out of control range IAC Tech 2 counts will be above 60 if idle is too low, and zero counts if idle is too

high. The following checks should be made to repair a non-IAC system problem:

- Vacuum leak (high idle) – If idle is too high, stop the engine. Fully extend (low) IAC with the IAC motor analyzer J 39027–A. Start the engine. If idle speed is above 800 RPM, locate and correct the vacuum leak, including the PCV system. Check for binding of the throttle blade or linkage.
- Lean heated oxygen sensor signal (high air/fuel ratio) – The idle speed may be too high or too low. Engine speed may vary up and down, and disconnecting the IAC valve does not help. Diagnostic trouble codes P0131, P0151, P0171, or P0174 may be set. Tech 2 oxygen (O2) voltage will be less than 100 mV (0.1 V). Check for low regulated fuel pressure, water in fuel, or a restricted injector.

- Rich heated oxygen sensor signal (low air/fuel ratio) – The idle speed will be too low. Tech 2 IAC counts will usually be above 80. The system is obviously rich and may exhibit black smoke in the exhaust.
 - Tech 2 O₂ voltage will be fixed at about 750 mV (0.75 V). Check for high fuel pressure, or a leaking or sticking injector. A silicon-contaminated heated oxygen sensor will show an O₂ voltage slow to respond on the Tech 2.
 - Throttle body – Remove the IAC valve and inspect the bore for foreign material.
 - IAC valve electrical connections – IAC valve connections should be carefully checked for proper contact.
 - PCV valve – An incorrect or faulty PCV valve may result in an incorrect idle speed. Refer to Diagnosis, Rough Idle, Stalling.
If intermittent poor driveability or idle symptoms are resolved by disconnecting the IAC, carefully recheck the connections and valve terminal resistance, or replace the IAC.
1. The IAC motor analyzer J 39027–A is used to extend and retract the IAC valve. Valve movement is verified by an engine speed change. If no change in engine speed occurs, the valve can be resettled when removed from the throttle body.
 2. This step checks the quality of the IAC movement in step 1. Between 700 revolutions per minute (RPM) and about 1500 RPM, the engine speed should change smoothly with each flash of the tester light in both extend and retract. If the IAC valve is retracted beyond the control range (about 1500 RPM), it may take many flashes to extend the IAC valve before engine speed will begin to drop. This is normal on certain engines. Fully extending the IAC may cause engine stall. This may be normal.
 6. Steps 1 and 2 verified the proper IAC valve operation. This step checks the IAC circuits. Each lamp on the noid light should flash red and green while the IAC valve is cycled. While the sequence of color is not important, if either light is OFF or does not flash red and green, check the circuits for faults, beginning with poor terminal contacts.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:


Idle Air Control (IAC) System Check

Step	Action	Value(s)	Yes	No
1	1. Ignition OFF. 2. Connect the IAC motor analyzer J 39027–A to the IAC valve. 3. Set the parking brake. 4. Block the wheels. 5. Turn the air conditioning OFF. 6. Idle the engine in Park (A/T) or Neutral (M/T). 7. Install the Tech 2. Display the RPM. 8. Use the IAC motor analyzer J 39027–A to extend and retract the IAC valve. 9. The engine speed should decrease and increase as the IAC is cycled. Does the RPM change?	—	Go to Step 2	Go to Step 3
2	RPM should change smoothly with each flash of the IAC motor analyzer J 39027–A light. Does the RPM change within the range specified?	700–1500 RPM	Go to Step 6	Go to Step 3
3	Check the IAC passages. Are the IAC passages blocked?	—	Go to Step 4	Go to Step 5
4	Clear any obstruction from the IAC passages. Is the action complete?	—	Verify repair	—
5	Replace the IAC. Refer to On–Vehicle Service, Idle Air Control Valve. Is the action complete?	—	Verify repair	—

Idle Air Control (IAC) System Check (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Install the appropriate IAC noid light from J 39027-A into the powertrain control module harness. 2. Cycle the IAC motor analyzer J 39027-A and observe the noid lights. 3. Both the lights should cycle red and green, but never OFF, as the RPM is changed over its range. Do the noid lights cycle red and green?	—	Go to Step 7	Go to Step 8
7	1. Use the other connector on the IAC motor analyzer J 39027-A pigtail. 2. Check the resistance across the IAC coils. Measure the resistance between terminal A and terminal B. 3. Measure the resistance between terminal C and terminal D. Is the resistance within the specified range?	40–80 Ω	Go to Step 9	Go to Step 10
8	If the circuits did not test green and red, check the following: <ul style="list-style-type: none"> <input type="radio"/> Faulty connector terminal contacts <input type="radio"/> Open circuits, including connections <input type="radio"/> Circuits shorted to ground or voltage <input type="radio"/> Faulty powertrain control module connector(s) or powertrain control module. Are repairs necessary?	—	Go to Step 13	—
9	1. Check the resistance between the IAC terminal B and terminal C. 2. Check the resistance between the IAC terminal A and terminal D. Is the resistance infinite?	—	Go to Step 11	Go to Step 12
10	Replace the IAC. Refer to On-Vehicle Service, Idle Air Control Valve. Is the action complete?	—	Go to Step 7	—
11	Check the IAC valve and circuit. Are the IAC valve and circuit OK?	—	Refer to Diagnostic Aids	Go to Step 12
12	Replace the IAC. Refer to On-Vehicle Service, Idle Air Control Valve. Is the action complete?	—	Go to Step 9	—
13	Repair or replace the faulty component(s). Is the action complete?	—	Go to Step 6	—

EXHAUST GAS RECIRCULATION (EGR) SYSTEM CHECK



D06RX055

Circuit Description

A properly operating exhaust gas recirculation (EGR) system will directly affect the air/fuel requirements of the engine. Since the exhaust gas introduced into the air/fuel mixture is an inert gas (contains very little or no oxygen), less fuel is required to maintain a correct air/fuel ratio. Introducing exhaust gas into the combustion chamber lowers combustion temperatures and reduces the formation of oxides of nitrogen (NOx) in the exhaust gas. Lower combustion temperatures also prevent detonation. If the EGR pintle were to stay closed, the inert exhaust gas would be replaced with air and the air/fuel mixture would be leaner. The powertrain control module (PCM) would compensate for the lean condition by adding fuel, resulting in higher long term fuel trim values.

Diagnostic Aids


The EGR valve chart is a check of the EGR system. An EGR pintle constantly in the closed position could cause detonation and high emissions of NOx. It could also result in high long term fuel trim values in the open throttle cell, but not in the closed throttle cell. An EGR pintle constantly in the open position would cause rough idle. Also, an EGR valve mounted incorrectly (rotated 180°) could cause a rough idle without setting an EGR DTC. Check for the following items:

- EGR passages – Check for restricted or blocked EGR passages.
- Manifold absolute pressure sensor – A manifold absolute pressure sensor may shift in calibration enough to affect fuel delivery. Refer to Manifold Absolute Pressure Output Check.

Exhaust Gas Recirculation (EGR) System Check

Step	Action	Value(s)	Yes	No
1	Check the EGR valve for looseness. Is the EGR valve loose?	—	Go to Step 2	Go to Step 3
2	Tighten the EGR valve. Is the action complete?	—	Verify repair	—
3	1. Place the transmission selector in Park or Neutral. 2. Start the engine and idle until warm ("Closed Loop"). 3. Using a Tech 2, command EGR "50% ON." Does the engine idle rough and lose RPMs?	—	EGR system working properly. No problem found.	Go to Step 4
4	1. Engine OFF. 2. Ignition ON. 3. Using a test light to ground, check the EGR harness between the ignition feed and ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 5
5	Repair the EGR harness ignition feed. Was the problem corrected?	—	Verify repair	Go to Step 6
6	1. Remove the EGR valve. 2. Visually and physically inspect the EGR valve pintle, valve passages and adapter for excessive deposits, obstructions or any restrictions. Does the EGR valve have excessive deposits, obstructions or any restrictions?	—	Go to Step 7	Go to Step 8
7	Clean or replace EGR system components as necessary. Was the problem corrected?	—	Verify repair	Go to Step 8
8	1. Ground the EGR valve metal case to battery (-). 2. Using a Tech 2, command EGR ON and observe the EGR valve pintle for movement. Does the EGR valve pintle move according to command?	—	Go to Step 9	Go to DTC P0404 chart
9	1. Remove the EGR inlet and outlet pipes from the intake and exhaust manifolds. 2. Visually and physically inspect manifold EGR ports and EGR inlet and outlet pipes for blockage or restriction caused by excessive deposits or other damage. Do the manifold EGR ports or inlet and outlet pipes have excessive deposits, obstructions, or any restrictions?	—	Go to Step 10	EGR system working properly. No problem found.
10	Clean or replace EGR system components as necessary. Is the action complete?	—	Verify repair	—

MANIFOLD ABSOLUTE PRESSURE (MAP) OUTPUT CHECK



D06RX042

Circuit Description

The manifold absolute pressure (MAP) sensor measures the changes in the intake MAP which result from engine load (intake manifold vacuum) and engine speed changes; and converts these into a voltage output. The powertrain control module (PCM) sends a 5-volt reference voltage to the MAP sensor. As the MAP changes, the output voltage of the sensor also changes. By monitoring the sensor output voltage, the PCM knows the MAP. A lower pressure (low voltage) output voltage will be about 1–2 volts at idle. Higher pressure (high voltage) output voltage will be about 4–4.8 volts at wide open throttle. The MAP sensor is also used, under certain conditions, to measure barometric pressure, allowing the PCM to make adjustments for different altitudes. The PCM uses the MAP sensor to diagnose proper operation of the EGR system, in addition to other functions.

Test Description

IMPORTANT: Be sure to use the same diagnostic test equipment for all measurements.


The number(s) below refer to the step number(s) on the Diagnostic Chart:

1. When you compare the Tech 2 readings to a known good vehicle, it is important to compare vehicles that use MAP sensors that have the same part number.
 2. Applying 34 kPa (10 Hg) vacuum to the MAP sensor should cause the voltage to be 1.5–2.1 volts less than the voltage at step 1. Upon applying vacuum to the sensor, the change in voltage should be instantaneous. A slow voltage change indicates a faulty sensor.
 3. Check the vacuum hose to the sensor for leaking or restriction. Be sure that no other vacuum devices are connected to the MAP hose.
- IMPORTANT:** Make sure the electrical connector remains securely fastened.
4. Disconnect the sensor from the bracket. Twist the sensor with your hand to check for an intermittent connection. Output changes greater than 0.10 volt indicate a bad sensor.

Manifold Absolute Pressure (MAP) Output Check

Step	Action	Value(s)	Yes	No
1	1. Turn the ignition OFF and leave it OFF for 15 seconds. 2. Ignition ON. Do not crank engine. 3. The Tech 2 should indicate a manifold absolute pressure (MAP) sensor voltage. 4. Compare this scan reading to the scan reading of a known good vehicle obtained using the exact same procedure as in Steps 1-4. Is the voltage reading the same +/- 0.40 volt?	—	Go to Step 2	Go to Step 5
2	1. Disconnect the vacuum hose at the MAP sensor and plug the hose. 2. Connect a hand vacuum pump to the MAP sensor. 3. Start the engine. 4. Apply 34 kPa (10 Hg) of vacuum and note the voltage change. Is the voltage change 1.5-2.1 volts less than step 1?	—	Go to Step 3	Go to Step 4
3	Check the sensor hose for leakage or restriction. Does the hose supply vacuum to the MAP sensor only?	—	Go to Step 5	Go to Step 4
4	Repair the hose to ensure the hose supplies vacuum to the MAP sensor only. Is the action complete?	—	Verify repair	—
5	Check the sensor connection. Is the sensor connection good?	—	Go to Step 6	Go to Step 7
6	Refer to On-Vehicle Service, MAP Sensor. Is the action complete?	—	Verify repair	—
7	Repair the poor connection. Is the action complete?	—	Verify repair	—

EVAPORATIVE (EVAP) EMISSIONS CANISTER PURGE VALVE SOLENOID CHECK



D06RX056

Circuit Description

Canister purge is controlled by a solenoid valve that allows manifold vacuum to purge the canister. The powertrain control module (PCM) supplies a ground to energize the solenoid valve (purge ON). The EVAP purge solenoid control is turned ON time is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM and the purge solenoid is enabled when the appropriate conditions have been met:

- The engine run time after start is more than 60 seconds.
- The engine coolant temperature is above 30°C (86°F).
- The fuel control system is operating in the Closed-Loop mode.

Diagnostic Aids

- Make a visual check of vacuum hoses.
- Check the throttle body for possible cracked.
- Check the malfunction indicator lamp for a possible mechanical problem.

Test Description

The number(s) below refer to the step number(s) on the Diagnostic Chart:

1. Check to see if the solenoid is open or closed. The solenoid is normally de-energized in this step, so it should be closed.
2. This step checks to determine if the solenoid was open due to an electrical circuit problem or a defective solenoid.
3. This should normally energize the solenoid, opening the valve and allowing the vacuum to drop (purge ON).


Evaporative (EVAP) Emissions Canister Purge Valve Solenoid Check

Step	Action	Value(s)	Yes	No
1	1. Ignition OFF. 2. Ignition ON, engine OFF. 3. At the throttle body, disconnect the hose that goes to the pump solenoid. 4. Using a hand vacuum pump with an attached vacuum gauge J 23738-A, apply vacuum (10" Hg or 34 kPa) to the solenoid. Does the solenoid hold vacuum?	—	Go to Step 3	Go to Step 2
2	1. Disconnect the solenoid electrical connector. 2. As in Step 1, apply vacuum (10" Hg or 34 kPa) to the solenoid. Does the solenoid hold vacuum?	—	Go to Step 4	Go to Step 7
3	1. At the throttle body, put a cap over the vacuum port where the hose was disconnected for testing. This is to prevent a vacuum leak when the engine is started. 2. Ignition OFF. 3. Install the Tech 2. 4. Apply vacuum to the purge solenoid with the hand vacuum pump. 5. Start the engine, run at 2500 RPM. 6. Using the Tech 2 command the purge solenoid ON. Did the vacuum drop when the purge was turned on?	—	Go to Step 8	Go to Step 9
4	Check for a short to ground or open in the wire between the solenoid and the PCM. Is there a problem?	—	Go to Step 5	Go to Step 6
5	Repair the faulty wire. Is the action complete?	—	Verify repair	—
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
7	Replace the faulty purge solenoid. Refer to On-Vehicle Service, EVAP Canister Purge Solenoid. Is the action complete?	—	Verify repair	—

Evaporative (EVAP) Emissions Canister Purge Valve Solenoid Check (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Turn the ignition OFF. 2. At the throttle body, install a vacuum gauge where the hose from the purge solenoid was disconnected for testing. 3. Start the engine. 4. Stabilize the engine speed at about 2500 RPM. 5. Momentarily snap the throttle open and let it return to idle. Is there approximately 10" Hg (34 kPa) of vacuum available at the EVAP emission canister purge solenoid?	—	No problem found in the EVAP emission canister purge valve check.	Refer to Diagnostic Aids
9	1. Turn the Ignition OFF. 2. Disconnect the solenoid's electrical connector. 3. Connect a test lamp between the harness terminals. 4. Turn the Ignition ON. Does the test lamp light?	—	Go to Step 7	Go to Step 10
10	Probe each terminal of the solenoid valve electrical connector with a test lamp to ground. Does the test lamp light on both terminals?	—	Go to Step 11	Go to Step 12
11	Repair the short to voltage in the wire between the solenoid and the PCM. Is the action complete?	—	Verify repair	—
12	Does the ignition feed terminals light the test lamp?	—	Go to Step 13	Go to Step 14
13	Check for an open in the wire between the purge solenoid and the PCM. Was there an open circuit?	—	Go to Step 15	Go to Step 6
14	Repair the open in the ignition feed wire. Is the action complete?	—	Verify repair	—
15	Repair the open wire. Is the action complete?	—	Verify repair	—

Upshift Lamp System Check (Manual Transmission Only)



D06RX063

Circuit Description

The shift lamp indicates the best transmission shift point for maximum fuel economy.

The lamp is controlled by the Power Train Control Module (PCM) and is turned "ON" by grounding the YEL/GRN wire.

The PCM is used information from the following inputs to control the upshift lamp.

- Engine Coolant temperature (ECT) Sensor
- Throttle Position Sensor
- Vehicle Speed Sensor
- Engine Speed

The PCM uses the measured RPM and the vehicle speed to calculate what gear the vehicle is in.

It's this calculation that determines when the upshift lamp should be turned "ON".

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation. Check for poor connections or a damaged harness.

Inspect the PCM harness and connector for proper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection and damaged harness.

Test Description

1. This should not turn "ON" the up-shift lamp. If the lamp is "ON", there is a short to ground in YEL/GRN or a fault PCM.
2. This checks the upshift lamp circuit up to the PCM connector.

If the up-shift lamp illuminates, then the PCM connector is faulty or PCM does not have the ability to ground the circuit.

Up-Shift Lamp System Check

Step	Action	Value(s)	Yes	No
1	1. Verify the customer complaints in accordance with mentioned below: Go to the adequate Step Chart first. <ul style="list-style-type: none"> ○ At the 1st gear position, the lamp doesn't illuminate: Go to Step Chart ○ At the 3rd gear position, the lamp doesn't illuminate: Go to Step Chart ○ Upshift Lamp doesn't illuminate always. 2. Ignition "ON", engine "OFF". 3. Using the Tech 2, check to see if the upshift lamp turn "ON" or "OFF". Does the upshift lamp stay "OFF"?	—	Go to Step 2	Go to Step 12
2	Check for an open of 15A Turn Backup Fuse. Was a problem found?	—	Go to Step 3	Go to Step 4 Refer to Section 8
3	Replace the fuse. Is the action complete?	Verify Repair	—	—
4	Check for an burned out the Upshift Lamp. Was a problem found?	—	Go to Step 5	Go to Step 6
5	Replace the Upshift Lamp. Is the action complete?	Verify Repair	—	—
6	1. Check for an Clutch Switch operation and the fixing condition. 2. Check for an open or short of clutch switch. 3. Check for an open or short of WHT/GRN wiring harness between Turn Backup Fuse and Clutch Switch. Was a problem found?	—	Go to Step 7	Go to Step 8
7	1. Replace the Clutch Switch. Or, 2. Repair for an open or short of WHT/GRN wiring harness. Is the action complete?	Verify Repair	—	—
8	1. Check for an open or short of 1-2 Transmission Switch. 2. Check for an open or short of 3-4 Transmission Switch. 3. Check for an open or short of GRN wiring harness between Clutch Switch and Transmission Switches. Was a problem found?	—	Go to Step 9	Go to Step 10
9	1. Replace the applicable Transmission Switch. or, 2. Repair for an open or short of GRN wiring harness. Is the action complete?	Verify Repair	—	—

Up-Shift Lamp System Check (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Check for an open or short in the Alarmer and Relay Control Unit. 2. Check for an open of BLU/ORN wiring harness between Transmission Switches and Alarmer Relay Control Unit. Was a problem found?	—	Go to Step 11	Go to Step 12
11	1. Replace the Alarmer and Relay Control Unit. Or, 2. Repair for an open of BLU/ORN wiring harness between Alarmer and Relay Control Unit and PCM connector. Is the action complete?	Verify Repair	—	Go to Step 15
12	1. Ignition "OFF". 2. Disconnect the PCM connectors. 3. Shift the gear to 1 st or 4 th gear position. 4. Turn ignition "ON", but <i>don't start the engine</i> . Does the Upshift Lamp Stay "ON"?	—	Go to Step 13	Go to Step 15
13	Check for an short to ground of YEL/GRN wiring harness between Alarmer and PCM connector. Was a problem found?	—	Go to Step 14	Go to Step 15
14	Repair for an open YEL/GRN wiring harness. Is the action complete?	Verify Repair	—	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed refer to ON-Vehicle Service in Power Train Control Module and Sensor for procedure. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	—	—

PCM DIAGNOSTIC TROUBLE CODES

The following table lists the diagnostic trouble codes supported by this vehicle application. If any DTCs not listed here are displayed by a Scan Tool, the Tech 2 data

may be faulty; notify the Tech 2 manufacturer of any DTCs displayed that are not included in the following table.

PCM Diagnostic Trouble Codes


DTC	Description	Type	Illuminate MIL
P0106	MAP Circuit/Range Performance Problem	B	Yes
P0107	MAP Sensor Circuit Low Input	A	Yes
P0108	MAP Sensor Circuit High Input	A	Yes
P0112	IAT Sensor Circuit Low Input	A	Yes
P0113	IAT Sensor Circuit High Input	A	Yes
P0117	ECT Sensor Circuit Low Input	A	Yes
P0118	ECT Sensor Circuit High Input	A	Yes
P0121	TP Sensor Circuit Range/Performance Problem	A	Yes
P0122	TP Sensor Circuit Low Input	A	Yes
P0123	TP Sensor Circuit High Input	A	Yes
P0125	Insufficient Coolant Temperature for Closed Loop Fuel Control	B	Yes
P0131	O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)	A	Yes
P0132	O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)	A	Yes
P0133	O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)	B	Yes
P0134	O2 Sensor Circuit No Activity Detected (Bank Sensor 1)	A	Yes
P0135	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)	B	Yes
P0137	O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)	A	Yes
P0138	O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)	A	Yes
P0140	O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)	A	Yes
P0141	O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)	B	Yes
P0171	Fuel Trim System Too Lean (Bank 1)	B	Yes
P0172	Fuel Trim System Too Rich (Bank 1)	B	Yes
P0201	Injector Circuit Malfunction – Cylinder 1	A	Yes
P0202	Injector Circuit Malfunction – Cylinder 2	A	Yes
P0203	Injector Circuit Malfunction – Cylinder 3	A	Yes
P0204	Injector Circuit Malfunction – Cylinder 4	A	Yes
P0300	Random/Multiple Cylinder Misfire Detected	B	Yes
P0301	Cylinder Misfire Detected (#1)	B	Yes
P0302	Cylinder Misfire Detected (#2)	B	Yes
P0303	Cylinder Misfire Detected (#3)	B	Yes
P0304	Cylinder Misfire Detected (#4)	B	Yes
P0325	Knock Sensor Circuit Malfunction	B	Yes
P0327	Knock Sensor Circuit Low Input	B	Yes
P0336	CKP Sensor Circuit Range/Performance	B	Yes
P0337	CKP Sensor Circuit Low Input	B	Yes
P0341	CMP Sensor Circuit Range/Performance	B	Yes
P0342	CMP Sensor Circuit Low Input	B	Yes
P0351	Ignition Coil "A" Primary/Secondary	A	Yes

DTC	Description	Type	Illuminate MIL
P0352	Ignition Coil "B" Primary/Secondary	A	Yes
P0401	EGR Flow Insufficient Detected	A	Yes
P0402	EGR Excessive Flow Detected	B	Yes
P0404	EGR Circuit Range/Performance	B	Yes
P0405	EGR Sensor Circuit Low	A	Yes
P0406	EGR Sensor Circuit High	A	Yes
P0420	Catalyst System Efficiency Below Threshold	A	Yes
P0440	EVAP Control System Malfunction	A	Yes
P0442	EVAP Control System Small Leak Detected	A	Yes
P0443	EVAP Control System Purge Control Valve Circuit Malfunction	A	Yes
P0446	EVAP Control System Vent Control Circuit Malfunction	B	Yes
P0449	EVAP Control System Vent Valve/Solenoid Circuit Malfunction	A	Yes
P0461	Fuel Level Sensor Circuit Range/Performance	B	Yes
P0462	Fuel Level Sensor Circuit Low Input	B	Yes
P0463	Fuel Level Sensor Circuit High Input	B	Yes
P0480	Cooling Fan 1 Control Circuit Malfunction	D	No
P0481	Cooling Fan 2 Control Circuit Malfunction	D	No
P0502	VSS Circuit Low Input	B	Yes
P0506	Idle Control System RPM Lower than expected	B	Yes
P0507	Idle Control System RPM Higher than expected	B	Yes
P0532	A/C Refrigerant Pressure Sensor Circuit Low	D	No
P0533	A/C Refrigerant Pressure Sensor Circuit High	D	No
P0562	System Voltage Low	D	No
P0563	System Voltage High	A	Yes
P0601	Internal Control Module Memory Check Sum Error	A	Yes
P1106	MAP Sensor Circuit Intermittent High Voltage	D	No
P1107	MAP Sensor Circuit Intermittent Low Voltage	D	No
P1111	IAT Sensor Circuit Intermittent High Voltage	D	No
P1112	IAT Sensor Circuit Intermittent Low Voltage	D	No
P1114	ECT Sensor Circuit Intermittent Low Voltage	D	No
P1115	ECT Sensor Circuit Intermittent High Voltage	D	No
P1121	TP Sensor Circuit Intermittent High Voltage	D	No
P1122	TP Sensor Circuit Intermittent Low Voltage	D	No
P1133	O2 Sensor Insufficient Switching (Bank 1 Sensor 1)	B	Yes
P1134	O2 Sensor Transition Time Ratio (Bank 1 Sensor1)	B	Yes
P1171	Fuel System Lean During Acceleration	A	Yes
P1336	CKP System Variation Not Learned	A	Yes
P1380	ABS Rough Road System Fault	D	No
P1381	ABS Rough Road Class 2 Serial Data Fault	D	No
P1404	EGR Closed Valve	B	Yes
P1441	EVAP System Flow During Non-Purge	B	Yes
P1546	A/C Compressor Clutch Output Circuit Malfunction	D	No
P1625	PCM Unexpected Reset	D	Yes

6E1-110 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

DTC	Description	Type	Illuminate MIL
P1627	PCM A/D Conversion Malfunction	A	Yes
P1635	5 Volt Reference Voltage Circuit Malfunction	A	Yes
P1640	ODM Output Circuit Fault	D	No

DIAGNOSTIC TROUBLE CODE (DTC) P0106 MANIFOLD ABSOLUTE PRESSURE (MAP) CIRCUIT/RANGE PERFORMANCE PROBLEM



D06RX042

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure. The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (low manifold pressure) to above 4 volts with the ignition ON engine not running or at wide-open throttle (high manifold pressure).

A "speed density" method of determining engine load is used on the 2.2L engine. This is calculated using inputs from the MAP sensor, RPM, CKP Sensor, and the Intake Air Temperature (IAT) sensor. The MAP sensor is the main sensor used in this calculation, and measuring engine load is its main function. The MAP sensor is also used to determine manifold pressure changes while the exhaust gas recirculation (EGR) flow test diagnostic is being run, to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). Refer to DTC P0401.

The PCM monitors the MAP signals for voltages outside the normal range (10–104 kPa) of the MAP sensor. If the PCM detects a MAP signal voltage that is excessively low, Diagnostic Trouble Code P0106 will be set. Diagnostic Trouble Code P0106 is a Type B Code.

Conditions for Setting the DTC

- No ECT, CKP, EGR, EVAP, MAP or TP sensor DTC's present.
- Engine speed is steady, changing less than 20 RPM.

- Throttle position is steady, throttle angle changes less than 5%.
- EGR flow rate is steady, changing less than 2%.
- IAC valve counts are steady, changing less than 3 counts.
- Engine speed is between 1000 RPM and 4000 RPM.
- ECT is above -10°C (14°F).
- No change in brake switch, A/C clutch, 3 or power steering pressure switch status.

The above conditions are met for longer than 1.5 seconds and the following condition is met in two consecutive trips:

- Actual MAP value varies more than 10 kPa.
- The MAP value must vary for a total of 10 seconds over a 20-second period of time that the samples were monitored.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will default to a BARO value of 79.3 kPa.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0106 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0106 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The MAP sensor shares a 5 Volt Reference with the TP sensor and Fuel Pressure sensor.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.

- The MAP sensor shares a ground with the TP sensor and Fuel Pressure sensor.
- Damaged harness – Inspect the wiring harness for damage; an open circuit, a short to ground, or a short to voltage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If Diagnostic Trouble Code P0106 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set. If it is determined that the Diagnostic Trouble Code occurs intermittently, performing the Diagnostic Trouble Code P1106 or P1107 Diagnostic Chart may isolate the cause of the fault.


DTC P0106 MAP Circuit/Range Performance Problem

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, engine OFF 2. Review and record Tech 2 Failure Records data, then clear the DTC's. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for Diagnostic Trouble Code P0106. Does the Tech 2 indicate that DTC P0106 ran and passed?	—	Go to Step 3	Go to Step 4
3	1. Check for the following condition: <ul style="list-style-type: none"> ○ Vacuum hoses disconnected, damaged, or incorrectly routed? ○ Intake manifold vacuum leaks; ○ Vacuum leaks at throttle body; ○ Vacuum leaks at EGR valve flange and pipes; 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to Diagnostic Aids
4	1. Disconnect the Manifold Absolute Pressure (MAP) sensor electrical connector. 2. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	0 V 10.3 kPa	Go to Step 6	Go to Step 5
5	Check the MAP sensor signal circuit; between the MAP sensor and the Powertrain Control Module (PCM), for a short to voltage?	—	Verify repair	Go to Step 12
6	Check the MAP sensor circuit, between the MAP sensor and the PCM, the following conditions: <ul style="list-style-type: none"> ○ A short to ground ○ An open circuit Was the problem found?	—	Verify repair	Go to Step 7

DTC P0106 MAP Circuit/Range Performance Problem (Cont'd)

Step	Action	Value(s)	Yes	No
7	<p>Check the 5 volt signal circuit, between the MAP sensor and the PCM, for the following conditions:</p> <ul style="list-style-type: none"> <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage <p>Was the problem found?</p>	—	Verify repair	Go to Step 8
8	<p>1. Ignition OFF.</p> <p>2. Place a fused jumper between the MAP sensor circuit and the 5 volt signal circuit, both at the wiring harness' MAP sensor connector.</p> <p>3. Ignition ON, engine OFF.</p> <p>4. Observe the MAP value displayed on the Tech 2?</p> <p>Does the Tech 2 read the following value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)</p>	5 volts 104 kPa	Go to Step 9	Go to Step 12
9	<p>Check the MAP sensor ground circuit, between the MAP sensor and the PCM, for the following conditions:</p> <ul style="list-style-type: none"> <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage <p>Was the problem found?</p>	—	Verify repair	Go to Step 10
10	<p>1. Ignition OFF.</p> <p>2. Place a Digital Multimeter (DVM), set to measure voltage, between the ground circuit and the 5 volt signal circuit, both at the wiring harness' MAP sensor connector.</p> <p>3. Ignition ON, engine OFF.</p> <p>5 volts</p> <p>Does the DVM read the following value?</p>	—	Go to Step 11	Go to Step 12
11	<p>Replace the MAP sensor.</p> <p>Verify repair.</p>	—	—	—
12	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Verify repair.</p>	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0107 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT LOW INPUT



D06RX042

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure. The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (low manifold pressure) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (high manifold pressure).

A "speed density" method of determining engine load is used on the 2.2L engine. This is calculated using inputs from the MAP sensor, the CKP Sensor, and the Intake Air Temperature (IAT) sensor. The MAP sensor is the main sensor used in this calculation, and measuring engine load is its main function. The MAP sensor is also used to determine manifold pressure changes while the exhaust gas recirculation (EGR) flow test diagnostic is being run, to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). Refer to DTC P0401.

The PCM monitors the MAP signals for voltages outside the normal range (10–104 kPa) of the MAP sensor. If the PCM detects a MAP signal voltage that is excessively low, Diagnostic Trouble Code P0107 will be set. DTC P0107 is a Type A Code.

Conditions for Setting the DTC

- No TP sensor Diagnostic Trouble Codes present.
- Engine is running.

- System voltage greater than 11 volts.
- Throttle angle is above 0% if engine speed is less than or equal to 1300 RPM.
- Throttle angle is above 5% if engine speed is above 1300 RPM.
- The MAP sensor indicates manifold absolute pressure below 11 kPa for a total of approximately 10 seconds over a 16-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will default to a BARO value of 79.3 kPa.
- The PCM will use a MAP value based on speed density calculation.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0107 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0107 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The MAP sensor shares a 5 Volt Reference with the TP sensor and Fuel Pressure sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.
- The MAP sensor shares a ground with the TP sensor and Fuel Pressure sensor.
- Damaged harness – Inspect the wiring harness for damage, shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK,

observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

- A faulty 5 volt reference circuit could also set a TP Sensor Diagnostic Trouble Code because the two sensors share the same 5 volt reference pin at the PCM.

If Diagnostic Trouble Code P0107 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set. If it is determined that the Diagnostic Trouble Code occurs intermittently, performing the Diagnostic Trouble Code P0107 Diagnostic Chart may isolate the cause of the fault.


DTC P0107 – MAP Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, engine OFF. 2. With the throttle closed, observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	0V 10.3 kPa at sea level	Go to Step 4	Go to Step 3
3	1. Ignition ON, engine OFF. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor «Diagnostic Trouble Code» info for Diagnostic Trouble Code P0107. Does the Tech 2 indicate Diagnostic Trouble Code P0107 failed?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Ignition OFF. 2. Disconnect the MAP sensor electrical connector. 3. Jumper the 5 volt reference circuit and the MAP signal together at the MAP sensor harness connector. 4. Ignition ON. 5. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	5 V 104 kPa	Go to Step 10	Go to Step 5
5	1. Disconnect the jumper. 2. Connect a fused jumper between the 5 Volt signal circuit and the MAP sensor signal circuit at the MAP sensor harness connector. 3. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	5 V 104 kPa	Go to Step 6	Go to Step 8

DTC P0107 – MAP Sensor Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Ignition OFF. 2. Disconnect the PCM and check the 5 volt reference circuit for an open or short to ground. 3. If the 5 volt reference circuit is open or shorted to ground, repair it as necessary. Was the 5 volt reference circuit open or shorted to ground?	—	Verify repair	Go to Step 7
7	Check the 5 volt reference circuit for a poor connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 11
8	1. Ignition OFF. 2. Disconnect the PCM, and check the MAP signal circuit for an open, short to ground, or short to the sensor ground circuit. 3. If the MAP sensor signal circuit is open or shorted to ground, repair it as necessary. Was the MAP signal circuit open or shorted to ground?	—	Verify repair	Go to Step 9
9	Check the MAP sensor signal circuit for a poor connection at the PCM and the MAP sensor; replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 11
10	Replace the MAP sensor. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0108 MANIFOLD ABSOLUTE PRESSURE (MAP) CIRCUIT HIGH INPUT



D06RX042

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure. The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (low manifold pressure) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (high manifold pressure).

A "speed density" method of determining engine load is used on the 2.2L engine. This is calculated using inputs from the MAP sensor, RPM, CKP Sensor, and the Intake Air Temperature (IAT) sensor. The MAP sensor is the main sensor used in this calculation, and measuring engine load is its main function. The MAP sensor is also used to determine manifold pressure changes while the exhaust gas recirculation (EGR) flow test diagnostic is being run, to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). Refer to DTC P0401.

The PCM monitors the MAP signals for voltages outside the normal range (10–104 kPa) of the MAP sensor. If the PCM detects a MAP signal voltage that is excessively low, Diagnostic Trouble Code P0108 will be set. DTC P0108 is a Type A Code.

Conditions for Setting the DTC

- No TP sensor Diagnostic Trouble Codes present.
- Engine is running.

- Throttle position is below 2.7% if engine speed is below 1000 RPM.
- Throttle position is below 10% if engine speed is above 1000 RPM.
- The MAP sensor indicates manifold absolute pressure above 90 kPa for a total of approximately 10 seconds over a 16-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will default to a BARO value of 79.3 kPa.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0108 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0108 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

6E1-118 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- The MAP sensor shares a 5 Volt Reference with the TP sensor and Fuel Pressure sensor.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.

- The MAP sensor share a ground with the TP sensor and Fuel Pressure sensor.

- Damaged harness – Inspect the wiring harness for damage; an open circuit, a short to ground, or a short to voltage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If Diagnostic Trouble Code P0108 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set.


DTC P0108 MAP Sensor Circuit High Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. If the engine idle is rough, unstable or incorrect, repair the idle problem before using this chart. Refer to Symptoms section. 2. With the engine idling, note the MAP value on the Tech 2. Is the MAP reading above the specified value?	About 4V 90 kPa	Go to Step 4	Go to Step 3
3	1. Ignition ON engine OFF 2. Review and record Tech 2 Failure Records data, then clear the DTC's. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for Diagnostic Trouble Code P0108. Does the Tech 2 indicate that DTC P0108 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Ignition OFF. 2. Disconnect the MAP sensor electrical connector. 3. Ignition ON. 4. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	0 V 10.3 kPa	Go to Step 5	Go to Step 6
5	Check the MAP sensor signal circuit; between the MAP sensor and the Powertrain Control Module (PCM), for a short to voltage. Was the problem found?	—	Verify repair	Go to Step 12
6	Check the MAP sensor circuit, between the MAP sensor and the PCM, the following conditions: ○ A short to ground ○ An open circuit Was the problem found?	—	Verify repair	Go to Step 7
7	Check the 5 volt signal circuit, between the MAP sensor and the PCM for the following conditions: ○ An open circuit ○ A short to ground ○ A short to voltage Was the problem found?	—	Verify repair	Go to Step 8

DTC P0108 MAP Sensor Circuit High Input (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition OFF. 2. Place a fused jumper between the MAP sensor circuit and the 5 volt signal circuit, both at the wiring harness' MAP sensor connector. 3. Ignition ON, Engine OFF. 4. Observe the MAP value displayed on the Tech 2? Does the Tech 2 read the following value?	5 volts 104 kPa	Go to Step 9	Go to Step 12
9	Check the MAP sensor ground circuit, between the MAP sensor and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 10
10	1. Ignition OFF. 2. Place a Digital Multimeter (DVM), set to measure voltage, between the ground circuit and the 5 volt signal circuit, both at the wiring harness' MAP sensor connector. 3. Ignition ON, Engine OFF. Does the DVM read the following value?	5 Volts	Go to Step 11	Go to Step 12
11	Replace the MAP sensor. Verify repair.	—	—	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0112 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT LOW INPUT



D06RX043

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance is lower, causing the PCM to monitor a lower voltage. Diagnostic Trouble Code P0112 will set when the PCM detects an excessively low signal voltage (short to ground) on the intake air temperature sensor signal circuit. DTC P0112 is a Type A Code.

Conditions for Setting the DTC

- The engine has been running for over 2 minutes.
- Vehicle speed is greater than 48 km/h (30 mph).
- IAT signal voltage less than 0.10 volts for a total of 12.5 seconds over a 25-second period of time.

The above conditions are met for at least 2 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will use a default IAT valve based on PCM inputs and engine run time.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0112 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0112 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage, shorts to ground, shorts to battery and open circuits. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

If Diagnostic Trouble Code P0112 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Verifies that the fault is present.
3. If Diagnostic Trouble Code P0112 can be repeated only by duplicating the Failure Records condition, refer to the Temperature vs. Resistance Value table.

The table may be used to test the IAT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be stored above or below a certain temperature. If this is the case, replace the IAT sensor. If the IAT sensor appears to be OK, the fault is intermittent; refer to Diagnostic Aids.


Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P0112 Intake Air Temperature (IAT) Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, engine OFF. 2. Using a Tech 2, monitor the intake air temperature (IAT). Is the intake air temperature greater than the specified value?	148°C (283°F)	Go to Step 4	Go to Step 3
3	1. Ignition ON, engine OFF. Review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor the "DTC" info for Diagnostic Trouble Code P0112. Does the Tech 2 indicate DTC P0112 failed this ignition?	—	Refer to Test Description	Refer to Diagnostic Aids
4	1. Ignition OFF. 2. Disconnect the IAT sensor electrical connector. 3. Ignition ON. 4. Observe the intake air temperature on the Tech 2. Is the intake air temperature below the specified value?	-38°C (-36°F)	Go to Step 6	Go to Step 5
5	1. Ignition OFF. 2. Disconnect the PCM electrical connectors. 3. Check the IAT sensor signal circuit for a short to ground. Is the IAT sensor signal circuit shorted to ground?	—	Verify Repair	Go to Step 7
6	Replace the IAT sensor. Is the action complete?	—	Verify Repair	—
7	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify Repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0113 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT HIGH INPUT



D06RX043

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance is lower causing the PCM to monitor a lower voltage. Diagnostic Trouble Code P0113 will set when the PCM detects an excessively high signal voltage on the intake air temperature sensor signal circuit. DTC P0113 is a Type A Code.

Conditions for Setting the DTC

- The engine has been running for over 4 minutes.
- Vehicle speed is less than 32 km/h (20 mph).
- ECT signal temperature is above 60°C (140°F).
- Mass air flow is less than 20g/second.
- IAT signal voltage almost 5 volts which indicates an intake air temperature less than -39°C (-38°F) for a total of 12.5 seconds over a 25-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will use a default IAT valve based on PCM inputs and engine run time.

- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0113 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0113 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage, shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

If Diagnostic Trouble Code P0113 cannot be duplicated, the information included in the Failure Records data can

6E1-124 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Verifies that the fault is present.

3. If Diagnostic Trouble Code P0113 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Values" table.

The table may be used to test the IAT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be open above or below a certain temperature. If this is the case, replace the IAT sensor. If the IAT sensor appears to be OK, the fault is intermittent; refer to Diagnostic Aids.

Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700


DTC P0113 Intake Air Temperature (IAT) Sensor Circuit High Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Ignition ON, engine OFF. Observe the "Intake Air Temp" display on the Tech 2. Is the "Intake Air Temp" below the specified value?	5V -38°C (-36°F)	Go to Step 4	Go to Step 3
3	1. Ignition ON, engine OFF. 2. Review and record Tech 2 Failure Records data parameters. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor «Diagnostic Trouble Code» info for Diagnostic Trouble Code P0113. Does the Tech 2 indicate Diagnostic Trouble Code P0113 failed?	—	Refer to Test Description	Refer to Diagnostic Aids
4	1. Ignition OFF. 2. Disconnect the IAT sensor electrical connector. 3. Jumper the IAT signal circuit and the sensor ground circuit together at the IAT sensor harness connector. 4. Ignition ON. 5. Observe the "Intake Air Temp" display on the Tech 2. Is the "Intake Air Temp" at the specified value?	0V 140°C (284°F)	Go to Step 6	Go to Step 5
5	1. Jumper the IAT signal circuit at the IAT sensor harness connector to chassis ground. 2. Observe the "Intake Air Temp" display on the Tech 2. Is the "Intake Air Temp" at the specified value?	0V 140°C (284°F)	Go to Step 7	Go to Step 8

DTC P0113 Intake Air Temperature (IAT) Sensor Circuit High Input (Cont'd)

Step	Action	Value(s)	Yes	No
6	Check for poor connections at the IAT sensor and replace terminals if necessary. Did any terminals require replacement?	—	Verify Repair	Go to Step 10
7	1. Ignition OFF. 2. Disconnect the PCM, and check the IAT sensor ground circuit for an open. 3. If the IAT sensor ground circuit is open, repair it as necessary. Was the IAT sensor ground circuit open?	—	Verify repair	Go to Step 9
8	1. Ignition OFF. 2. Disconnect the PCM, and check the IAT signal circuit for an open. 3. If the IAT sensor signal circuit is open, repair it as necessary. Was the IAT signal circuit open?	—	Verify repair	Go to Step 9
9	Check for a poor sensor ground or IAT signal circuit terminal connection at the PCM and replace terminal(s) if necessary. Did any of the terminals need to be replaced?	—	Verify repair	Go to Step 11
10	Replace the IAT sensor Is the action complete?	—	Verify repair	—
11	Replace the PCM IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0117 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT LOW INPUT



D06RX044

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in the engine coolant stream. The powertrain control module (PCM) applies a voltage (about 5 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes lower, and the ECT signal voltage measured at the PCM drops. With a fully warmed-up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts. DTC P0117 is a Type A Code.

Conditions for Setting the DTC

- Engine running time is longer than two minutes.
- The ECT sensor signal indicates an engine coolant temperature greater than 150°C (302°F) (about 0.14 V) for a total of 12.5 seconds over a 25-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will substitute the ECT reading with a default engine coolant temperature value. The default value is based on start-up intake air temperature and running time.

- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0117 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0117 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage, shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

If Diagnostic Trouble Code P0117 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the

Diagnostic Trouble Code was last set. If it is determined that the Diagnostic Trouble Code occurs intermittently, performing the Diagnostic Trouble Code P1114 Diagnostic Chart may isolate the cause of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2.Verifies that the fault is present.

3.If Diagnostic Trouble Code P0117 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Values" table.

The table may be used to test the ECT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be shorted above or below a certain temperature. If this is the case, replace the ECT sensor. If the ECT sensor appears to be OK, the fault is intermittent; refer to Diagnostic Aids.


Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P0117 – Engine Coolant Temperature (ECT) Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON engine OFF. 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" below the specified value?	139°C (282°F)	Go to Step 4	Go to Step 3
3	1. Ignition ON engine OFF. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0117. Does the Tech 2 indicate DTC P0117 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Disconnect the ECT sensor electrical connector. 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" at or below the specified value?	-39°C (-38°F)	Go to Step 6	Go to Step 5
5	1. Ignition OFF. 2. Disconnect the PCM and check the ECT signal circuit for a short to ground or a short to the sensor ground circuit. 3. If the ECT signal circuit is shorted, repair it as necessary. Was the ECT signal circuit shorted to ground?	—	Verify repair	Go to Step 7
6	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
7	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0118 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT HIGH INPUT



D06RX044

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in the engine coolant stream. The powertrain control module (PCM) applies a voltage (about 5 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes less, and the ECT signal voltage measured at the PCM drops. With a fully warmed up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts. If the PCM detects a continuous open in the ECT sensor or circuit, then a code P0118 will set. DTC P0118 is a type A code.

Conditions for Setting the DTC

- Engine running time is longer than 2.5 minutes.
- The ECT sensor signal indicates an engine coolant temperature of -39°C (-38°F) or less (about 5 volts) for a total of 12.5 seconds over a 25-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will substitute the ECT reading with a default engine coolant temperature value. The default value is based on start-up intake air temperature and running time.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0118 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0118 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage, shorts to ground, shorts to battery positive, and open circuit. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

If Diagnostic Trouble Code P0118 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the

6E1-130 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Diagnostic Trouble Code was last set. If it is determined that the Diagnostic Trouble Code occurs intermittently, performing the DTC P1115 Diagnostic Chart may isolate the cause of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Verifies that the fault is present.

3. If Diagnostic Trouble Code P0118 can be repeated only by duplicating the Failure Records condition, refer to the "Temperature vs. Resistance Value" table.

The table may be used to test the ECT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be shorted above or below a certain temperature. If this is the case, replace the ECT sensor. If the ECT sensor appears to be OK, the fault is intermittent; refer to Diagnostic Aids.

Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700


DTC P118 – ECT Sensor Circuit High Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON engine OFF. 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" below the specified value?	-39°C (-38°F)	Go to Step 4	Go to Step 3
3	1. Ignition ON engine OFF. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor the "DTC" info for Diagnostic Trouble Code P0118. Does the Tech 2 indicate Diagnostic Trouble Code P0118 failed?	—	Refer to Test Description	Refer to Diagnostic Aids
4	1. Disconnect the ECT sensor electrical connector. 2. Jumper the ECT signal circuit and the sensor ground circuit together at the ECT sensor harness connector. 3. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" at or above the specified value?	140°C (284°F)	Go to Step 6	Go to Step 5
5	1. Jumper the ECT signal circuit at the ECT sensor harness connector to chassis ground. 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" at or above the specified value?	140°C (284°F)	Go to Step 7	Go to Step 8
6	Check for poor connections at the ECT sensor and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 10

DTC P118 – ECT Sensor Circuit High Input (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition OFF. 2. Disconnect the PCM, and check the ECT sensor ground circuit for an open. 3. If the ECT sensor ground circuit is open, repair it as necessary. Was the ECT sensor ground circuit open?	—	Verify repair	Go to Step 9
8	1. Ignition OFF. 2. Disconnect the PCM, and check the ECT signal circuit for an open. 3. If the ECT sensor signal circuit is open, repair it as necessary. Was the ECT signal circuit open?	—	Verify repair	Go to Step 9
9	Check for a poor sensor ground or ECT signal circuit terminal connection at the PCM and replace terminal(s) if necessary. Did any of the terminals need to be replaced?	—	Verify repair	Go to Step 11
10	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0121 THROTTLE POSITION (TP) SENSOR CIRCUIT RANGE/PERFORMANCE PROBLEM



D06RX045

Circuit Description

The throttle position (Throttle Position) sensor circuit provides a voltage signal that changes relative to throttle blade angle. The signal voltage will vary from about 0.25 volts at closed throttle to about 4.75 volts at wide open throttle (WOT).

The Throttle Position (TP) signal is used by the powertrain control module (PCM) for fuel control and most of the PCM-controlled outputs. The PCM monitors throttle position and compares actual throttle positions from the TP sensor to a predicted TP value calculated from engine speed. If the PCM detects an out-of-range condition, then a DTC code P0121 will set. DTC P0121 is type A code.

Conditions for Setting the DTC

- The Engine is running.
 - No MAP, ECT, TP, CKP, EGR, EVAP or DTC's are set.
 - IAC is between 10 and 160 counts.
 - ECT is above -10°C (14°F).
 - The MAP value changes by less than 2 kPa.
- All the above mentioned conditions are met, and one of the following conditions occurs for a total of 12.5 seconds over a 25-second period of time.

Stuck High-

- MAP value is below 55 kPa.

- Actual TP value is greater than the PCM's estimated TP value (Estimated TP value is based on MAP and RPM).

Stuck Low-

- MAP value is below 50 kPa.
- Actual TP value is less than the PCM's estimated TP value (Estimated TP value is based on MAP and RPM).

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.
- The PCM will use a default throttle position based on MAP and RPM.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0121 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0121 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Skewed MAP signal or faulty MAP sensor – An incorrect MAP signal may cause the PCM to incorrectly calculate the predicted TP sensor value during high engine load situations. Check for an unusually low MAP reading. This condition can cause DTC P0121 to be set.
- The TP sensor shares a 5 Volt reference with the MAP sensor and Fuel Pressure sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.
- The TP sensor shares a ground with the MAP sensor and the Fuel Pressure sensor.
- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken

locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage; an open circuit, a short to ground, or a short to voltage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0121 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P1122 or P1121 Diagnostic Chart may isolate the cause of the fault.

DTC P0121 TP Sensor/Range Performance Problem

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON engine OFF 2. Review and record Tech 2 Failure Records data, then clear the DTC's. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0121. Does the Tech 2 indicate that DTC P0121 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition ON, engine OFF. 2. Monitor the TP value on the Tech 2 while moving the throttle between 0% and 100%. Does the TP value on the Tech 2 move smoothly from 0% (0.25 volts) to 100% (4.75 volts)? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 4	Go to Step 11
4	1. Ignition OFF. 2. Disconnect the Throttle Position (TP) Sensor electrical connector, located on the RH side of the Throttle body. 3. Start the vehicle, and monitor the TP value with the Tech 2. Does the TP value on the Tech 2 hold steadily within the given range?	0–0.25 volts 0%	Go to Step 6	Go to Step 5
5	Check the TP sensor signal circuit; between the TP sensor and the Powertrain Control Module (PCM), for a short to voltage. Was the problem found?	—	Verify repair	Go to Step 12
6	Check the TP sensor circuit, between the TP sensor and the PCM, the following conditions: ○ A short to ground ○ An open circuit Was the problem found?	—	Verify repair	Go to Step 7

DTC P0121 TP Sensor/Range Performance Problem (Cont'd)

Step	Action	Value(s)	Yes	No
7	Check the 5 volt signal circuit, between the TP sensor and the PCM, for the following conditions: <ul style="list-style-type: none"> ○ An open circuit ○ A short to ground ○ A short to voltage Was the problem found?	—	Verify repair	Go to Step 8
8	1. Ignition OFF. 2. Place a fused jumper between the TP sensor circuit and the 5 volt signal circuit both at the wiring harness' TP sensor connector. 3. Ignition ON, Engine OFF. 4. Observe the TP value displayed on the Tech 2? Does the Tech 2 read the following value?	about 5 volts 100%	Go to Step 9	Go to Step 12
9	Check the TP sensor ground circuit, between the TP sensor and the PCM, for the following conditions: <ul style="list-style-type: none"> ○ An open circuit ○ A short to ground ○ A short to voltage Was the problem found?	—	Verify repair	Go to Step 10
10	1. Ignition OFF. 2. Place a Digital Multimeter (DVM), set to measure voltage, between the ground circuit and the 5 volt signal circuit, both at the wiring harness' TP sensor connector. 3. Ignition ON, Engine OFF. Does the DVM read the following value?	about 5 volts	Go to Step 11	Go to Step 12
11	Replace the TP sensor. Verify repair.	—	—	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—



6E1-136 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

If Diagnostic Trouble Code P0122 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set. If it is determined

that the Diagnostic Trouble Code occurs intermittently, performing the Diagnostic Trouble Code P1122 Diagnostic Chart may isolate the cause of the fault.


DTC P0122 – TP Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON engine OFF. 2. With the throttle closed, observe the "Throttle Position Sensor" display on the Tech 2. Is the "Throttle Position Sensor" below the specified value?	0.22 V	Go to Step 4	Go to Step 3
3	1. Ignition ON engine OFF. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor the "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0122. Does the Tech 2 indicate DTC P0122 failed?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Ignition OFF. 2. Disconnect the TP sensor electrical connector. 3. Jumper the 5 volt reference circuit and the Throttle Position signal together at the Throttle Position sensor harness connector. 4. Ignition ON. Observe the "Throttle Position Sensor" display on the Tech 2. Is the "Throttle Position Sensor" at the specified value?	5 V	Go to Step 10	Go to Step 5
5	1. Disconnect jumper. 2. Connect a test light between B+ and the Throttle Position sensor signal circuit at the Throttle Position sensor harness connector. Observe the "Throttle Position Sensor" display on the Tech 2. Is the "Throttle Position Sensor" at the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	5 V	Go to Step 6	Go to Step 8
6	1. Ignition OFF. 2. Disconnect the PCM and check the 5 volt reference circuit for an open or short to ground. 3. If the 5 volt reference circuit is open or shorted to ground, repair it as necessary. Was the 5 volt reference circuit open or shorted to ground?	—	Verify repair	Go to Step 7
7	Check the 5 volt reference circuit for a poor connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 12

DTC P0122 – TP Sensor Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition OFF. 2. Disconnect the PCM, and check the TP signal circuit for an open, short to ground, or short to the sensor ground circuit. 3. If the TP sensor signal circuit is open or shorted to ground, repair it as necessary. Was the TP signal circuit open or shorted to ground?	—	Verify repair	Go to Step 9
9	Check the TP sensor signal circuit for a poor connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 12
10	Check the TP sensor signal circuit for a poor connection at the TP sensor and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 11
11	Replace the TP sensor. Is the action complete?	—	Verify repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0123 THROTTLE POSITION (TP) SENSOR CIRCUIT HIGH INPUT



Circuit Description

The throttle position (TP) sensor circuit provides a voltage signal that changes relative to throttle blade angle. The signal voltage will vary from below 1 volt at closed throttle to about 4 volts at wide open throttle (WOT). The TP signal is used by the powertrain control module (PCM) for fuel control and most of the PCM-controlled outputs. If the PCM detects a continuous open in the TP sensor or circuit, then a code P0123 will set. DTC P0123 is a type A code.

Conditions for Setting the DTC

- The ignition is ON.
- Throttle Position sensor voltage is greater than 4.78 volts for a total of 0.78 second over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- The PCM will use a default throttle position based on MAP and RPM.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0123 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0123 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The TP sensor shares a 5 Volt reference with the MAP sensor and Fuel Pressure sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The TP sensor share a ground with the MAP and the Fuel Pressure sensor.
- Damaged harness – Inspect the wiring harness for damage, shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, observe the Throttle Position sensor display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.

D06RX045

- Faulty Throttle Position sensor – With the ignition key ON engine OFF observe the TP sensor display on the Tech 2 while slowly depressing the accelerator to wide open throttle. If a voltage over 4.88 volts is seen at any point in normal accelerator travel, replace the TP sensor.

If Diagnostic Trouble Code P0123 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the Diagnostic Trouble Code was last set. If it is determined that the Diagnostic Trouble Code occurs intermittently, performing the Diagnostic Trouble Code P1121 Diagnostic Chart may isolate the cause of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

7. Components that share the TP sensor 5 volt reference circuit include the following devices:

- EGR valve
- Fuel Tank Pressure sensor
- MAP sensor

Disconnect the component while observing the Throttle Position sensor display on the Tech 2. If the reading changes drastically when this component is disconnected, replace the component that affected the reading.


DTC P0123 – TP Sensor Circuit High Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, engine OFF. 2. With the throttle closed, observe the "Throttle Position Sensor" display on the Tech 2. Is the "Throttle Position Sensor" above the specified value?	4.78 V	Go to Step 4	Go to Step 3
3	1. Ignition ON, engine OFF. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0123. Does the Tech 2 indicate Diagnostic Trouble Code P0123 failed?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Disconnect the Throttle Position sensor electrical connector. 2. Observe the "Throttle Position Sensor" display on the Tech 2. Is the "Throttle Position Sensor" near the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	0 V	Go to Step 5	Go to Step 6
5	Probe the sensor ground circuit at the Throttle Position sensor harness connector with a test light connected to B+. Is the test light ON?	—	Go to Step 7	Go to Step 10
6	1. Ignition OFF disconnect the PCM. 2. Ignition ON engine OFF. 3. Check for a short to voltage on the TP sensor signal circuit. 4. If the TP sensor signal circuit is shorted, repair it as necessary. Was the TP sensor signal circuit shorted?	—	Verify repair	Go to Step 12

DTC P0123 – TP Sensor Circuit High Input (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition ON. 2. Monitor the "Throttle Position Sensor" Tech 2 display while disconnecting each of the components that share the 5 volt reference circuit (one at a time). 3. If the "Throttle Position Sensor" Tech 2 display changes, service the component(s) that caused the display to change when disconnected. Does disconnecting any of these components cause the "Throttle Position Sensor" display to change?	—	Verify repair	Go to Step 8
8	1. Ignition OFF disconnect the PCM. 2. Ignition ON, engine OFF. 3. Check for a short to B+ on the 5 volt reference circuit. 4. If the 5 volt reference circuit is shorted, repair it as necessary. Was the 5 volt reference circuit shorted?	—	Verify repair	Go to Step 9
9	Check for poor electrical connections at the Throttle Position sensor and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 11
10	1. Ignition OFF. 2. Disconnect the PCM, and check for an open sensor ground circuit to the Throttle Position sensor. 3. If a problem is found, repair it as necessary. Was the sensor ground circuit to the Throttle Position sensor open?	—	Verify repair	Go to Step 12
11	Replace the Throttle Position sensor. Is the action complete?	—	Verify repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0125 INSUFFICIENT COOLANT TEMPERATURE FOR CLOSED LOOP FUEL CONTROL



D06RX044

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "Closed Loop" air/fuel metering system is used. When the vehicle is first started, the powertrain control module (PCM) controls fuel delivery in "Open Loop" ignoring the heated oxygen sensor (HO2S) signals and calculating air/fuel ratio based on inputs from the engine coolant temperature, throttle position, and mass air flow sensors.

If the PCM detects that the ECT sensor has not reached a sufficient reading to achieve "Closed Loop" within a specified amount of time, DTC P0125 will set. DTC P0125 is a type B code.

Conditions for Setting the DTC

- No MAP, IAT, ECT, TP, Misfire, Injector, or VSS DTC codes set.

All the above mentioned conditions are true and any combination of the following three tests fail three times in two consecutive ignition cycles (for a total of six failures):

Warm Case Test

- Start-up ECT value is less than 29°C (84°F).
- IAT is greater than 10°C (50°F).
- Accumulated airflow is greater than 1500 grams.
- Engine run time is greater than 90 seconds.

- Time for coolant to reach stabilized "Closed Loop" value is less than 120 seconds.

Cold Case Test

- IAT is between -7°C (20°F) and 10°C (50°F)
- Accumulated airflow is greater than 2000 grams.
- Engine run time is less than 225 seconds.
- Time for coolant to reach stabilized "Closed Loop" value is less than 300 seconds.

Other Case Test

- IAT is between -30°C (-22°F) and -7°C (20°F).
- Accumulated airflow is greater than 3600 grams.
- Engine run time is less than 450 seconds.
- Time for coolant to reach stabilized "Closed Loop" value is less than 600 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

6E1-142 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

- A history Diagnostic Trouble Code P0125 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0125 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

DTC P0125 set indicates a faulty ECT sensor. Comparing the engine coolant temperature displayed on a Tech 2 with actual coolant temperature measured with a thermometer may isolate this condition. If the displayed engine coolant temperature is not close to the actual coolant temperature, replace the ECT sensor.

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for back-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged Harness – Inspect the wiring harness for damage; open circuits, shorts to ground, or shorts to voltage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0125 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Comparing the engine coolant temperature displayed on a Tech 2 with actual coolant temperature measured with a thermometer may isolate this condition. If the displayed engine coolant temperature is not close to the actual coolant temperature, replace the ECT sensor. If the temperatures are closed, the fault is intermittent; refer to Diagnostic Aids.

7. Engine Coolant Temperature

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P0125 Insufficient Coolant Temperature for Closed Loop Fuel Control

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any ECT sensor DTC's set?	—	Go to applicable ECT sensor DTC chart	Go to Step 3
3	1. Allow the engine to cool completely. 2. Check the cooling system coolant level (refer to Cooling and Radiator). Is the coolant level OK?	—	Go to Step 4	Go to Step 9
4	1. Start the engine. 2. With the engine idling, monitor "ENG COOL TEMP" display on the Tech 2. Does "ENG COOL TEMP" increase to above the specified value within 2 minutes?	21°C (70°F)	Refer to Diagnostic Aids	Go to Step 5
5	Check for proper operation of the thermostat (refer to Cooling and Radiator). Is the thermostat operating correctly?	—	Go to Step 6	Go to Step 9

DTC P0125 Insufficient Coolant Temperature for Closed Loop Fuel Control (Cont'd)

Step	Action	Value(s)	Yes	No
6	Compare engine coolant temperature displayed on the Tech 2 to the actual coolant temperature measured with a thermometer. (Observe normal precautions when opening the cooling system.) Is the Tech 2 engine coolant temperature indication close to the measured temperature?	—	Go to Step 9	Go to Step 7
7	1. Ignition OFF. 2. Disconnect the PCM. 3. Using a DVM, measure the resistance of the ECT at the PCM connector. 4. Compare the DVM reading with the chart in "Test Description." Is the chart value approximately equal to the thermometer reading?	—	Go to Step 12	Go to Step 8
8	Check for the following conditions in the wiring between the ECT and the PCM: ○ An open circuit ○ A short to ground ○ A short to voltage	—	Go to Step 10	Go to Step 11
9	Refer to Cooling and Radiator for cooling system diagnosis and repair condition as necessary. Is the action complete?	—	Verify Repair	—
10	Replace the faulty terminal(s) or repair faulty wiring as necessary. Is the action complete?	—	Verify Repair	—
11	Replace the ECT sensor. Is the action complete?	—	Verify Repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify Repair	—



The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal and low circuits. When measured with a 10 mega Ω digital voltmeter, this may display as low as 350 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "Closed Loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 1 voltage remains excessively low for an extended period of time, Diagnostic Trouble Code P0131 will be set. DTC P0131 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
 - Vehicle is operating in "Closed Loop".
 - Engine coolant temperature is above 60°C (140°F)
 - "Closed Loop" commanded air/fuel ratio is between 14.5 and 14.8.
 - Throttle angle is between 3% and 19%.
- All above conditions met for 0.3 seconds and the following condition is met:
- Bank 1 HO2S 1 signal voltage remains below 22 mV during normal "Closed Loop" operation for a total of 76.5 seconds over a 90-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open Loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0131 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0131 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Heated oxygen sensor wiring – The sensor pigtail may be routed incorrectly and/or contacting the exhaust system. Also, check for shorts to ground, shorts to battery positive and open circuits.
- Poor PCM to engine block grounds.
- Fuel pressure – The system will go lean if pressure is too low. The PCM can compensate for some decrease. However, if fuel pressure is too low, a Diagnostic

Trouble Code P0131 may be set. Refer to Fuel System Diagnosis.

- Lean injector(s) – Perform "Injector Balance Test."
- Vacuum leaks – Check for disconnected or damaged vacuum hoses and for vacuum leaks at the intake manifold, throttle body, EGR system, and PCV system.
- Exhaust leaks – An exhaust leak may cause outside air to be pulled into the exhaust gas stream past the HO2S, causing the system to appear lean. Check for exhaust leaks that may cause a false lean condition to be indicated.
- Fuel contamination – Water, even in small amounts, can be delivered to the fuel injectors. The water can cause a lean exhaust to be indicated. Excessive alcohol in the fuel can also cause this condition. For the procedure to check for fuel contamination, Refer to Fuel System Diagnosis.

If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. Diagnostic Trouble Code P0131 failing during operation may indicate a condition described in the "Diagnostic Aids" above. If the Diagnostic Trouble Code P0131 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0131 – O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under "Conditions for Setting the Diagnostic Trouble Code" criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Does the Bank 1 HO2S 1 voltage remain below the specified value?	300 mV	Go to Step 4	Go to Step 3
3	1. Ignition ON engine OFF review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0131 until the Diagnostic Trouble Code P0131 test runs. Note test result. Does Tech 2 indicate DTC P0131 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Turn the ignition OFF. 2. Disconnect the PCM. 3. Check the Bank 1 HO2S 1 high and low circuits for a short to ground or a short to the heater ground circuit. Are the Bank 1 HO2S 1 signal circuits shorted to ground?	—	Go to Step 5	Go to Step 6
5	Repair the Bank 1 HO2S 1 signal circuit. Is the action complete?	—	Verify repair	—

DTC P0131 – O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Turn the ignition OFF HO2S 1 and PCM disconnected. 2. Check for continuity between the high and low signal circuits. Was there continuity between the high and low circuits?	—	Go to Step 7	Go to Step 8
7	Repair the short between the high and low circuits. Is the action complete?	—	Verify repair	—
8	1. Ignition OFF. 2. Reconnect the PCM, leave the sensor disconnected. 3. Ignition ON. Does the Tech 2 indicate Bank 1 HO2S 1 voltage near the specified value?	430–450 mV	Refer to Diagnostic Aids	Go to Step 9
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On–Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0132 O2 SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 1)



D06RX046

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal and low circuits. When measured with a 10 mega Ω digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "Closed Loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 1 voltage remains excessively high for an extended period of time, Diagnostic Trouble Code P0132 will be set. DTC P0132 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
 - Engine coolant temperature is above 60°C (140°F).
 - "Closed Loop" commanded air/fuel ratio is between 14.5 and 14.8.
 - Throttle angle is between 3% and 19%.
- All above conditions met for 0.3 seconds or vehicle in Deceleration Fuel Cut-Off (DFCO) mode for 3 seconds, and one of the following two conditions met:
- Bank 1 HO2S 1 signal voltage remains above 952 mV during normal "Closed Loop" operation for a total of 76.5 seconds over a 90-second period.

OR

- Bank 1 HO2S 1 signal voltage remains above 500 mV during "deceleration fuel cutoff mode" (DFCO) operation for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open Loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0132 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0132 can be cleared by using the Scan Tool's "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check the following items:

- Fuel pressure – The system will go rich if pressure is too high. The PCM can compensate for some increase. However, if fuel pressure is too high, a

6E1-148 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Diagnostic Trouble Code P0132 may be set. Refer to Fuel System Diagnosis.

- Perform "Injector Balance Test" – Refer to Fuel System Diagnosis.
- Check the EVAP canister for fuel saturation – If full of fuel, check canister control and hoses. Refer to Evaporative (EVAP) Emission Control System.
- Check for a leak in the fuel pressure regulator diaphragm by checking the vacuum line to the regulator for the presence of fuel.
- An intermittent TP sensor output will cause the system to go rich due to a false indication of the engine accelerating.
- Silicon contamination of the HO2S can also cause a high HO2S voltage to be indicated. This condition is indicated by a powdery white deposit on the portion of the HO2S exposed to the exhaust stream. If contamination is noticed, replace the affected HO2S.
- Operate the vehicle while monitoring the HO2S voltage with a Tech 2. If the HO2S voltage is limited within a

range between 300 mV to 600 mV, check the HO2S high and low circuit wiring and associated terminal connections. If the wiring and connections are OK, replace the HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. Diagnostic Trouble Code P0132 failing during "deceleration fuel cutoff mode" operation may indicate a condition described in the "Diagnostic Aids" above. If the Diagnostic Trouble Code P0132 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated. Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0132 – O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within parameters specified under "Conditions for Setting the DTC" included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Does the Bank 1 HO2S 1 voltage remain above the specified value?	952 mV (500 mV in deceleration fuel cutoff mode)	Go to Step 4	Go to Step 3
3	1. Ignition ON review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0132 until the Diagnostic Trouble Code P0132 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0132 failed this ignition?	—	Refer to Diagnostic Aids	Go to Step 4
4	1. Ignition OFF. 2. Disconnect Bank 1 HO2S 1. 3. Ignition ON. 4. At HO2S 1 connector (PCM side) use a Digital Voltmeter (DVM) to measure voltages at the high and low signal terminals. Are the voltages in the specified range?	5–14 V	Go to Step 5	Go to Step 6
5	Repair short to voltage in signal circuit.	—	Verify repair	—

DTC P0132 – O2 Sensor Circuit High Voltage (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Ignition OFF. 2. Disconnect the PCM connector. 3. Check for damage to the PCM pins and terminals. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Ignition ON, engine OFF. 2. Disconnect Bank 1 HO2S 1 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Is Bank 1 HO2S 1 voltage below the specified value?	10 mV	Go to Step 8	Go to Step 9
8	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0133 O2 SENSOR CIRCUIT SLOW RESPONSE (BANK 1 SENSOR 1)



D06RX046

Circuit Description

The powertrain control module (PCM) continuously monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "Closed Loop" has been enabled. During the monitoring period the PCM counts the number of times that a rich-to-lean and lean-to-rich response is indicated and adds the amount of time it took to complete all transitions. With this information, an average time for each transition can be determined. If the average response time is too slow, a Diagnostic Trouble Code P0133 will be set. A DTC P0133 is a type B code. A lean-to-rich transition is indicated when the HO2S voltage changes from less than 300 mV to greater than 600 mV. A rich-to-lean transition is indicated when the HO2S voltage changes from more than 600 mV to less than 300 mV. An HO2S that responds too slowly is likely to be faulty and should be replaced.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- Engine coolant temperature is greater than 60°C (140°F).
- Engine is operating in "Closed Loop".
- Engine has been running for at least 2 minutes.
- Engine speed is between 1500 RPM and 3500 RPM.
- Canister purge solenoid duty cycle is greater than 2%.
- Calculated air flow is between 17 and 32 g/second.

All above conditions are met for 1 second and the following condition is met:

- 90 seconds after "Closed Loop" has been enabled, Bank 1 HO2S 1 average transition time between 300 mV and 600 mV is too slow. The lean-to-rich average transition response time was longer than 100 milliseconds or rich-to-lean average transition response time was longer than 105 milliseconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator Lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.
- "Open Loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0133 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0133 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 1 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If Diagnostic Trouble Code P0133 cannot be duplicated, reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often

the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Verifies that the fault is currently present.
3. HO2S transition time, ratio mean volts and switching Diagnostic Trouble Codes set for multiple sensors indicate probable contamination. Before replacing the sensors, isolate and correct the source of the contamination to avoid damaging the replacement sensors.


DTC P0133 – O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	NOTE: If any DTCs are set (except P1133 and/or P1134), refer to those DTCs before proceeding with this diagnostic chart. 1. Install the Tech 2. 2. Idle the engine at operating temperature. 3. Operate the vehicle within parameters specified under "Conditions for Setting the Diagnostic Trouble Code" included in Diagnostic Support. 4. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0133 until the Diagnostic Trouble Code P0133 test runs. 5. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0133 failed this ignition?	—	Go to Step 3	Refer to Diagnostic Aids
3	Did the Tech 2 also indicate Diagnostic Trouble Code P1133 and/or P1134 failed this ignition?	—	Go to Step 8	Go to Step 4
4	1. Perform "Exhaust System Leak Test" (refer to Exhaust System). After "Exhaust System Leak Test" has been performed, return to this diagnostic 2. If an exhaust leak is found, repair as necessary. Was an exhaust leak isolated?	—	Go to Step 2	Go to Step 5
5	Visually/physically inspect the following items: ○ Ensure that the Bank 1 HO2S 1 is securely installed. ○ Check for corrosion on terminals. ○ Check terminal tension (at Bank 1 HO2S 1 and at the PCM). ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Go to Step 9	Go to Step 6

DTC P0133 – O2 Sensor Circuit Slow Response (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Disconnect Bank 1 HO2S 1. 2. Ignition ON. 3. Using a Digital Voltmeter (DVM) at the PCM side of the HO2S 1 connector, measure the voltage between the high signal circuit and ground. Also measure the voltage between the low signal circuit and ground. Are both voltages in the specified range?	3–4 V	Go to Step 7	Go to Step 10
7	1. With Bank 1 HO2S 1 disconnected, jumper the high and low (PCM side) signal circuits to ground. 2. Ignition ON. 3. Using a Tech 2, monitor the Bank 1 HO2S 1 voltage. Does the Tech 2 indicate less than 10 mV and immediately return to about 450 mV when the jumper is removed?	—	Go to Step 12	Go to Step 13
8	Replace the affected heated oxygen sensors. NOTE: Before replacing sensors, the cause of the contamination must be determined and corrected. <input type="radio"/> Fuel contamination. <input type="radio"/> Use of improper RTV sealant. <input type="radio"/> Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—
9	Repair condition as necessary. Is the action complete?	—	Verify repair	—
10	Check for faulty PCM connections or terminal damage. Is the action complete?	—	Verify repair	Go to Step 11
11	Repair open, short or grounded signal circuit. Is the action complete?	—	Verify repair	—
12	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0134 O₂ SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 1)



D06RX046

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) high and low circuits. When measured with a 10 M Ω digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "Closed Loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 1 voltage remains at or near the 450 mV bias for an extended period of time, Diagnostic Trouble Code P0134 will be set, indicating an open sensor signal or sensor low circuit. DTC P0134 is a type B code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
 - Engine run time is longer than 120 seconds.
 - Oxygen sensor heater has been determined to be functioning properly, and the oxygen sensor has warmed to operating temperature.
- All the above conditions are met and the following condition is met:
- Bank 1 HO2S 1 signal voltage remains between 400 mV and 500 mV for a total of 76.5 seconds over a 90-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the second time the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.
- "Open Loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0134 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0134 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- Faulty HO2S heater or heater circuit – With the ignition ON engine OFF after a cooldown period, the HO2S 1 voltage displayed on the Tech 2 is normally 455–460 mV. A reading over 1000 mV indicates a signal line shorted to voltage. A reading under 5 mV indicates a

6E1-154 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

signal line shorted to ground or signal lines shorted together. Disconnect the HO2S and connect a test light between the HO2S ignition feed and heater ground circuits. If the test light does not light for 2 seconds when the ignition is turned on, repair the open ignition feed or sensor ground circuit as necessary. If the test light lights and the HO2S signal and low circuits are OK, replace the HO2S.

- Intermittent test – With the ignition ON monitor the HO2S signal voltage while moving the wiring harness

and related connectors. If the fault is induced, the HO2S signal voltage will change. This may help isolate the location of the malfunction.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0134 – O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the engine above 1200 RPM for three minutes. Does the Tech 2 indicate Bank 1 HO2S 1 voltage varying outside the specified values?	400–500 mV	Go to Step 3	Go to Step 4
3	1. Ignition ON, engine OFF review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0134 until the Diagnostic Trouble Code P0134 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0134 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids
4	Check for a damaged harness. Was a problem found?	—	Verify repair	Go to Step 5
5	Check for poor Bank 1 HO2S 1 high and low circuit terminal connections at the Bank 1 HO2S 1 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 6
6	Check for poor Bank 1 HO2S 1 high and low circuit terminal connections at the PCM and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 7
7	1. Ignition OFF. 2. With the PCM disconnected, check continuity of the Bank 1 HO2S 1 high circuit. 3. If the Bank 1 HO2S 1 high circuit measures over 0.5 Ω , repair open or poor connection as necessary. Was a Bank 1 HO2S 1 high circuit problem found and corrected?	—	Verify repair	Go to Step 8

DTC P0134 – O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition OFF. 2. With the PCM disconnected, check continuity of the Bank 1 HO2S 1 low circuit. 3. If the Bank 1 HO2S 1 low circuit measures over 5 Ω , repair open or poor connection as necessary. Was a Bank 1 HO2S 1 low circuit problem found and corrected?	—	Verify repair	Go to Step 9
9	1. Ignition ON, engine OFF. 2. Disconnect Bank 1 HO2S 1 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Is Bank 1 HO2S 1 voltage approximately equal to the specified value?	10 mV	Go to Step 10	Go to Step 11
10	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0135 O2 SENSOR HEATER CIRCUIT MALFUNCTION (BANK 1 SENSOR 1)



D06RX046

Circuit Description

Heated oxygen sensors are used to minimize the amount of time required for "Closed Loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by catalyst monitor sensors Bank 1 HO2S 2 and Bank 2 HO2S 2 to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further from the engine.

The powertrain control module (PCM) will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the Bank 1 HO2S 1 to become active, a Diagnostic Trouble Code P0135 will set. DTC P0135 is a type B Code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- Intake air temperature (IAT) is less than 32°C (90°F) at start-up.

- Engine coolant temperature (ECT) is less than 32°C (90°F) at start-up.
- IAT and ECT are within 5°C (9°F) of each other at start-up.
- Ignition voltage is between 11 and 16.6 V.
- Average calculated air flow is less than 18 g/second during sample period.
- Throttle angle is less than 40%.
- Bank 1 HO2S 1 voltage does not change more than 148 mV from the bias voltage (between 400 mV and 500 mV) for a longer amount of time than it should. The maximum amount of time to come up to operating range is 240 seconds. This warm-up time depends on the engine coolant temperature at start-up and intake air temperature at start-up.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history Diagnostic Trouble Code P0135 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0135 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. The HO2S should be allowed to cool before performing this test. If the HO2S heater is functioning, the signal voltage will gradually increase or decrease as the sensor element warms. If the heater is not functioning, the HO2S signal will remain near the 450 mV bias voltage.
4. Ensures that the ignition feed circuit to the HO2S is not open or shorted. The test light should be connected to a good chassis ground, in case the HO2S low or HO2s heater ground circuit is faulty.
5. Checks the HO2S heater ground circuit.
6. Checks for an open or shorted HO2S heater element.
10. An open HO2S signal or low circuit can cause the HO2S heater to appear faulty. Check these circuits before replacing the sensor.


DTC P0135 – O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	NOTE: If the engine has just been operating, allow engine to cool for about one half hour before proceeding. 1. Ignition OFF, engine OFF. 2. Install a Tech 2. 3. Ignition ON engine OFF monitor the Bank 1 HO2S 1 voltage. Does the HO2S voltage go from bias voltage to above and below the specified values?	Above 650 mV or below 250 mV	Refer to Diagnostic Aids	Go to Step 3
3	Inspect the fuse for the Bank 1 HO2S 1 ignition feed. Is the fuse open?	—	Go to Step 15	Go to Step 4
4	1. Ignition OFF. 2. Raise the vehicle. 3. Disconnect the Bank 1 HO2S 1 electrical connector. 4. Using a test light connected to a good ground (do not use Bank 1 HO2S 1 heater ground or Bank 1 HO2S 1 low), probe the ignition feed circuit at the Bank 1 HO2S 1 electrical connector (PCM harness side). Does the test light illuminate?	—	Go to Step 5	Go to Step 7
5	Connect the test light between the Bank 1 HO2S 1 ignition feed and the Bank 1 HO2S 1 heater ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 8

DTC P0135 – O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Allow the HO2S to cool for at least 10 minutes. 2. Using a Digital Voltmeter (DVM), measure the resistance between the Bank 1 HO2S 1 ignition feed and the Bank 1 HO2S 1 heater ground at the Bank 1 HO2S 1 pigtail. Is the HO2S heater resistance within the specified values?	3–6 ohms	Go to Step 9	Go to Step 10
7	Repair the open Bank 1 HO2S 1 ignition feed circuit to Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
8	Repair the open Bank 1 HO2S 1 heater ground circuit to Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
9	1. Check for a poor connection at the Bank 1 HO2S 1 harness terminals. 2. If a poor connection is found, replace terminals. Was a poor connection found?	—	Verify repair	Go to Step 10
10	Check for a poor Bank 1 HO2S 1 high or low circuit terminal connection at the Bank 1 HO2S 1 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 11
11	1. Ignition OFF. 2. Disconnect the PCM and check the continuity of the Bank 1 HO2S 1 signal circuit and the Bank 1 HO2S 1 low circuit. 3. If the Bank 1 HO2S 1 high circuit or HO2S low circuit measures over 5 Ω , repair open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	Check for a poor Bank 1 HO2S 1 low circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 13
13	Check for a poor Bank 1 HO2S 1 high circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
14	Replace the Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in Bank 1 HO2S 1 ignition feed circuit and replace the fault fuse. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0137 O₂ SENSOR CIRCUIT LOW VOLTAGE (BANK 1 SENSOR 2)



D06RX047

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 1 HO₂S 1 and the Bank 1 HO₂S 2 heated oxygen sensors. The Bank 1 HO₂S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 1 HO₂S 1 signal will be far more active than that produced by the Bank 1 HO₂S 2 sensor. If the Bank 1 HO₂S 2 signal voltage remains excessively low for an extended period of time, Diagnostic Trouble Code P0137 will be set. DTC P0137 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- Engine is operating in "Closed Loop".

- Engine coolant temperature is above 60°C (140°F).
- "Closed Loop" commanded air/fuel ratio is between 14.5 and 14.8.
- Throttle angle is between 3% and 19%.
All above conditions met for 0.3 seconds or for 3.0 seconds, if in "Deceleration Fuel Cut-Off" (DFCO) mode, and the following two conditions are met:
- Bank 1 HO₂S 2 signal voltage remains below 22 mV during normal "Closed Loop" operation for a total of 106.25 seconds over a 125-second period of time.
- OR
- Bank 1 HO₂S 2 signal voltage remains below 426 mV during power enrichment (P.E.) mode fuel control operation for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

6E1-160 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

- A history Diagnostic Trouble Code P0137 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0137 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Heated oxygen sensor wiring – The sensor pigtail may be mispositioned and/or contacting the exhaust system.
- Poor PCM to engine grounds.
- Fuel pressure – A condition which causes a lean exhaust can cause Diagnostic Trouble Code P0137 to set. The system will go lean if pressure is too low. The PCM can compensate for some decrease. However, if fuel pressure is too low, a Diagnostic Trouble Code P0137 may be set. Refer to Fuel System Diagnosis.
- Lean injector(s) – Perform "Injector Balance Test."
- Vacuum leaks – Check for disconnected or damaged vacuum hoses and for vacuum leaks at the intake manifold, throttle body, EGR system, and PCV system.
- Exhaust leaks – An exhaust leak may cause outside air to be pulled into the exhaust gas stream past the HO2S, causing the Diagnostic Trouble Code P0137 to set. Check for exhaust leaks near the Bank 1 HO2S 2 sensor.
- Fuel contamination – Water, even in small amounts, can be delivered to the fuel injectors. The water can cause a lean exhaust to be indicated. Excessive alcohol in the fuel can also cause this condition. For procedure to check for fuel contamination, refer to Fuel System Diagnosis.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. Diagnostic Trouble Code P0137 being set in power enrichment mode conditions may indicate a condition described in the "Diagnostic Aids" above. If the Diagnostic Trouble Code P0137 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated. Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0137 – O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under "Conditions for Setting the Diagnostic Trouble Code" criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 2 voltage. Does the Bank 1 HO2S 2 voltage remain below the specified value?	26 mV	Go to Step 4	Go to Step 3
3	1. Ignition ON, engine OFF review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0137 until the Diagnostic Trouble Code P0137 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0137 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Turn ignition OFF. 2. Disconnect the PCM. 3. Check the Bank 1 HO2S 2 high and low signal circuits for a short to ground or a short to the heater ground circuit. Were Bank 1 HO2S 2 signal circuits shorted?	—	Go to Step 5	Go to Step 6
5	Repair the Bank 1 HO2S 2 signal circuit. Is the action complete?	—	Verify repair	—

DTC P0137 – O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Ignition OFF. 2. Leave the PCM and HO2S 2 disconnected. 3. Check for continuity between the high and low signal circuits. Was there continuity between the high and low circuits?	—	Go to Step 7	Go to Step 8
7	Repair the short between the high and low circuits. Is the action complete?	—	Verify repair	—
8	1. Ignition OFF. 2. Reconnect the PCM, leave HO2S 2 disconnected. 3. Ignition ON. Does the Tech 2 indicate Bank 1 HO2S 2 voltage near the specified value?	430–450 mV	Refer to Diagnostic Aids	Go to Step 9
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0138 O₂ SENSOR CIRCUIT HIGH VOLTAGE (BANK 1 SENSOR 2)



D06RX047

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 1 HO₂S 1 and the Bank 1 HO₂S 2 heated oxygen sensors. The Bank 1 HO₂S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 1 HO₂S 1 signal will be far more active than that produced by the Bank 1 HO₂S 2 sensor. If the Bank 1 HO₂S 2 signal voltage remains excessively high for an extended period of time, Diagnostic Trouble Code P0138 will be set. DTC P0138 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- Engine is operating in "Closed Loop".

- "Closed Loop" commanded air/fuel ratio is between 14.5 and 14.8.
- Engine coolant temperature is above 60°C (140°F).
- Throttle angle is between 3% and 19%.

All above conditions met for 3.0 seconds or in "Deceleration Fuel Cutoff" DFCCO mode, and one of the following two conditions are met:

- Bank 1 HO₂S 2 signal voltage remains above 952 mV during normal "Closed Loop" operation for a total of 106.25 seconds over a 125-second period of time.

OR

- Bank 1 HO₂S 2 signal voltage remains above 474 mV during deceleration fuel cutoff mode operation for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0138 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- Diagnostic Trouble Code P0138 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check the following items:

- Fuel pressure – An excessively rich fuel mixture can cause a Diagnostic Trouble Code P0138 to be set. Refer to Fuel System Diagnosis.
- Rich injector(s) – Perform "Injector Balance Test."
- Leaking injector – Refer to Fuel System Diagnosis.
- Evaporative emissions (EVAP) canister purge – Check for fuel saturation. If full of fuel, check the canister control and hoses. Refer to Evaporative Emission (EVAP) Control System.
- Check for a leaking fuel pressure regulator diaphragm by checking the vacuum line to the regulator for the presence of fuel.
- TP sensor – An intermittent TP sensor output will cause the system to go rich, due to a false indication of the engine accelerating.
- Shorted Heated Oxygen Sensor (HO2S) – If the HO2S is internally shorted the HO2S voltage displayed on the Tech 2 will be over 1 volt. Silicon contamination of the HO2S can also cause a high HO2S voltage. This condition is indicated by a powdery white deposit on the portion of the HO2S exposed to the exhaust stream. If contamination is evident, replace the affected HO2S.

- Open HO2S Signal, Low Circuit or Faulty HO2S – A poor connection or open in the HO2S signal or low circuit can cause the DTC to set during deceleration fuel mode. An HO2S which is faulty and not allowing a full voltage swing between the rich and lean thresholds can also cause this condition. Operate the vehicle while monitoring the HO2S voltage with a Tech 2. If the HO2S voltage is limited within a range between 300 mV to 600 mV, check the HO2S signal and low circuit wiring and associated terminal connections. If the wiring and connections are OK, replace the HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. Diagnostic Trouble Code P0138 being set during deceleration fuel mode operation may indicate a condition described in the "Diagnostic Aids" above. If the Diagnostic Trouble Code P0138 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated. Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0138 – O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within parameters specified under "Conditions for Setting the Diagnostic Trouble Code" included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Does the Bank 1 HO2S 2 voltage remain above the specified value?	952 mV	Go to Step 4	Go to Step 3
3	1. Ignition ON review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0138 until the Diagnostic Trouble Code P0138 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0138 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids

DTC P0138 – O2 Sensor Circuit High Voltage (Bank 1 Sensor 2) (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Ignition OFF. 2. Disconnect Bank 1 HO2S 2. 3. Ignition ON. 4. At HO2S 2 connector (PCM side) use a DVM to measure voltages at the high and low signal terminals. Are the voltages in the specified range?	5–14 V	Go to Step 5	Go to Step 6
5	Repair short to voltage in signal circuit.	—	Verify repair	—
6	1. Ignition OFF. 2. Disconnect the PCM connector. 3. Check for damage to the PCM pins and terminals. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Ignition ON, engine OFF. 2. Disconnect Bank 1 HO2S 2 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Is Bank 1 HO2S 2 voltage below the specified value?	10 mV	Go to Step 8	Go to Step 9
8	Replace Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0140 O2 SENSOR CIRCUIT NO ACTIVITY DETECTED (BANK 1 SENSOR 2)



D06RX047

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 1 HO₂S 1 and the Bank 1 HO₂S 2 heated oxygen sensors. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 1 HO₂S 1 signal will be far more active than that produced by the Bank 1 HO₂S 2 sensor. If the Bank 1 HO₂S 2 signal voltage remains between 400 mV and 500 mV for an extended period of time, Diagnostic Trouble Code P0140 will be set. DTC P0140 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- Engine run time is longer than 120 seconds.

- Oxygen sensor heater is functioning properly, and the oxygen sensor has reached operating temperature.
- Engine is operating in "Closed Loop".
- Bank 1 HO₂S 2 signal voltage remains between 426 mV and 474 mV for a total of 106.25 seconds over a 125-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0140 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0140 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or

damaged terminals, poor terminal-to-wire connection, shorts to ground, shorts to battery positive and open circuits.

- Faulty HO2S heater or heater circuit – With the ignition ON engine OFF the HO2S voltage displayed on a Tech 2 should gradually drop to below 250 mV. If not, disconnect the HO2S and connect a test light between the HO2S ignition feed and heater ground circuits. If the test light does not light, repair the open ignition feed or sensor ground circuit as necessary. If the test light lights and the HO2S signal and low circuits are OK, replace the HO2S.
- Intermittent test – With the ignition ON monitor the HO2S signal voltage while moving the wiring harness and related connectors. If the fault is induced, the

HO2S signal voltage will change. This may help isolate the location of the malfunction.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

- 3.If the Diagnostic Trouble Code P0140 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated. Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

DTC P0140 – O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the engine above 1200 RPM for two minutes. Does the Tech 2 indicate Bank 1 HO2S 2 voltage vary outside the specified value?	425–475 mV	Go to Step 3	Go to Step 4
3	1. Ignition ON engine OFF review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0140 until the Diagnostic Trouble Code P0140 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0140 failed this ignition?	—	Go to Step 4	Refer to Diagnostic Aids
4	Check for a poor Bank 1 HO2S 2 high or low signal circuit terminal connection at the Bank 1 HO2S 2 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 5
5	1. Ignition OFF. 2. Disconnect the PCM. 3. Check for poor Bank 1 HO2S 2 high or low signal circuit terminal connection at the PCM and replace the terminal if necessary. Did either terminal require replacement?	—	Verify repair	Go to Step 6
6	Check continuity of the Bank 1 HO2S 2 signal circuits. If either Bank 1 HO2S 2 signal circuit measures over 5 Ω , repair open or poor connection as necessary. Was a Bank 1 HO2S 2 signal circuit problem found and corrected?	—	Verify repair	Go to Step 7

DTC P0140 – O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2) (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Reconnect the PCM harness. 2. Ignition ON. 3. With the Bank 1 HO2S 2 sensor harness disconnected, use a Digital Voltmeter (DVM) to measure the voltage between the HO2S heater ground wire and each signal circuit wire. Does each signal circuit measure in the specified range?	3–4 V	Go to Step 9	Go to Step 8
8	Check for a short to ground or voltage in both signal circuits. Was a problem found?	—	Verify repair	Go to Step 11
9	1. Jumper the high and low signal wires to the heater ground wire. 2. Ignition ON. Using a Tech 2, is the Bank 1 HO2S 2 voltage in the specified range?	0–10 mV	Go to Step 10	Go to Step 11
10	Replace Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—



The powertrain control module (PCM) will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the Bank HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the Bank 1 HO2S 2 to become active, a Diagnostic Trouble Code P0141 will set. DTC P0141 is a type B code.

- No related Diagnostic Trouble Codes.
- Intake air temperature (IAT) is less than 32°C (90°F) at start-up.

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history Diagnostic Trouble Code P0141 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0141 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. The HO2S should be allowed to cool before performing this test. If the HO2S heater is functioning, the signal voltage will gradually increase or decrease as the sensor element warms. If the heater is not functioning, the HO2S signal will remain near the 450 mV bias voltage.
4. This ensures that the ignition feed circuit to the HO2S is not open or shorted. The test light should be connected to a good chassis ground, in case the HO2S low or HO2S heater ground circuit is faulty.
5. This checks the HO2S heater ground circuit.
6. This checks for an open or shorted HO2S heater element.
11. An open HO2S signal or low circuit can cause the HO2S heater to appear faulty. Check these circuits before replacing the sensor.


DTC P0141 – O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	NOTE: If the engine has just been operating, allow the engine to cool for about one half hour before proceeding. 1. Ignition OFF, engine OFF. 2. Install the Tech 2. 3. Ignition ON, engine OFF monitor the Bank 1 HO2S 2 voltage. Does the HO2S voltage go from bias voltage to above or below the specified values?	Above 650 mV or below 250 mV	Refer to Diagnostic Aids	Go to Step 3
3	Inspect the fuse for Bank 1 HO2S 2 ignition feed. Is the fuse open?	—	Go to Step 15	Go to Step 4
4	1. Ignition OFF. 2. Raise the vehicle. 3. Disconnect the Bank 1 HO2S 2 electrical connector. 4. Using a test light connected to a good ground (do not use Bank 1 HO2S 2 heater ground or Bank 1 HO2S 2 low), probe the ignition feed circuit at the Bank 1 HO2S 2 electrical connector (PCM harness side). Does the test light illuminate?	—	Go to Step 5	Go to Step 7
5	Connect the test light between the Bank 1 HO2S 2 ignition feed and the Bank 1 HO2S 2 heater ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 8

DTC P0141 – O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Allow the HO2S to cool for at least 10 minutes. 2. Using a Digital Voltmeter (DVM), measure the resistance between the Bank 1 HO2S 2 ignition feed and the Bank 1 HO2S 2 heater ground at the Bank 1 HO2S 2 pigtail. Is the HO2S resistance within the specified values?	3–6 Ω	Go to Step 9	Go to Step 10
7	Repair the open Bank 1 HO2S 2 ignition feed circuit to Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
8	Repair the open Bank 1 HO2S 2 heater ground circuit. Is the action complete?	—	Verify repair	—
9	1. Check for a poor connection at the Bank 1 HO2S 2 harness terminals. 2. If a poor connection is found, replace the terminals. Was a poor connection found?	—	Verify repair	Go to Step 10
10	1. Ignition OFF. 2. Disconnect the PCM and check the continuity of the Bank 1 HO2S 2 signal circuit and the Bank 1 HO2S 2 low circuit. 3. If the Bank 1 HO2S 2 signal circuit or the HO2S low circuit measures over 5 Ω , repair the open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	Check for a poor Bank 1 HO2S 2 high or low circuit terminal connection at the Bank 1 HO2S 2 harness connector and replace the terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 12
12	Check for a poor Bank 1 HO2S 2 low circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 13
13	Check for a poor Bank 1 HO2S 2 high circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
14	Replace Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in Bank 1 HO2S 2 ignition feed circuit and replace the faulty fuse. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0171 SYSTEM TOO LEAN (BANK 1)



D06RX048

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "Closed Loop" air/fuel metering system is used. While in "Closed Loop", the powertrain control module (PCM) monitors the Bank 1 HO2S 1 signal and adjusts fuel delivery based upon the HO2S signal voltage. A change made to fuel delivery will be indicated by the long and short term fuel trim values which can be monitored with a Tech 2. Ideal fuel trim values are around 0%; if the HO2S signal indicates a lean condition the PCM will add fuel, resulting in fuel trim values above 0%. If a rich condition is detected, the fuel trim values will be below 0%, indicating that the PCM is reducing the amount of fuel delivered. If an excessively lean condition is detected on Bank 1, the PCM will set Diagnostic Trouble Code P0171. DTC P0171 is a type B code.

The PCM's maximum authority to control long term fuel trim allows a range between -14% and +20%. The PCM monitors fuel trim under various engine speed/load fuel trim cells before determining the status of the fuel trim diagnostic.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of the following: EGR Diagnostic Trouble Codes, HO2S Diagnostic Trouble Codes, (response, transition, open, low volts, no activity), TP sensor Diagnostic Trouble Codes, MAP Diagnostic Trouble

Codes, IAT Diagnostic Trouble Codes, canister purge Diagnostic Trouble Codes, EVAP Diagnostic Trouble Codes, injector circuit Diagnostic Trouble Codes, or misfire Diagnostic Trouble Codes.

- Engine coolant temperature is between 65°C (149°F) and 104°C (219°F).
- Intake air temperature is between -40°C (-40°F) and 120°C (248°F).
- Manifold absolute pressure is between 23.75 kPa and 99 kPa.
- Engine speed is between 400 and 6000 RPM.
- Barometric pressure is greater than 72.3 kPa.
- System voltage is greater than 9.5v.
- Engine is operating in "Closed Loop".
- The average of the short term fuel trim samples is greater than 0.97 and the average of adaptive index multiplier samples is greater than 1.21.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0171 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0171 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, observe the Bank 1 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the engine harness. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Diagnostic Trouble Codes other than P0171 may indicate a condition present which may cause a lean condition. If this is the case, repairing the condition which caused the other Diagnostic Trouble Code will most likely correct the Diagnostic Trouble Code P0171.
4. If the Diagnostic Trouble Code P0171 test passes while the Failure Records conditions are being duplicated, the lean condition is intermittent. Refer to Diagnostic Aids or Symptoms for additional information on diagnosing intermittent problems.


DTC P0171 – System Too Lean (Bank 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any DTCs set other than P0171?	—	Go to the applicable DTC charts and repair the other DTCs before proceeding with this chart.	Go to Step 3
3	1. Start the engine and operate the vehicle in "Closed Loop". 2. Observe the "BANK 1 L.T. FUEL TRIM" and display on the Tech 2. Are the displayed values greater than the specified values?	L.T. Fuel Trim: 20%	Go to Step 5	Go to Step 4
4	1. Review and record the Tech 2 Failure Records data. 2. Clear the Diagnostic Trouble Code P0171 and operate the vehicle to duplicate the Failure Records conditions. 3. Monitor the Tech 2 "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0171 while operating the vehicle to duplicate the Failure Records conditions. 4. Continue operating the vehicle until the Diagnostic Trouble Code P0171 test runs and note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0171 failed this ignition?	—	Go to Step 5	The lean condition is not present. If a driveability symptom still exists, refer to Symptoms section.
5	Visually and physically inspect the vacuum hoses for disconnects, splits, kinks, improper routing and improper connections and repair any problem found. Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to Step 6
6	Visually and physically inspect the crankcase ventilation valve for proper installation and repair any problem found (refer to Crankcase Ventilation System). Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to Step 7
7	Start the engine and note the idle quality. Is a high or unsteady idle being experienced?	—	Go to Step 8	Go to Step 10
8	With the engine idling, observe the "IDLE AIR CONTROL" display on the Tech 2. Is the displayed value above the specified value?	Above 5 counts	Go to Step 10	Go to Step 9
9	1. Visually and physically inspect the throttle body, intake manifold, EGR valve and the EGR feed pipe for vacuum leaks. 2. Repair any vacuum leaks as necessary. Did your inspection reveal a vacuum leak?	—	Verify repair	Go to Step 10

DTC P0171 – System Too Lean (Bank 1) (Cont'd)

Step	Action	Value(s)	Yes	No
10	Perform the "Idle Air Control (IAC) Valve Check" and correct any IAC problem as necessary. Did this test isolate a problem requiring repair?	—	Verify repair	Go to Step 11
11	Check the fuel for excessive water, alcohol, or other contaminants (see Diagnosis in Engine Fuel for the procedure) and correct the contaminated fuel condition if present (see Engine Fuel). Was the fuel contaminated?	—	Verify repair	Go to Step 12
12	1. Visually and physically inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight, and in their proper locations. 2. If a faulty ground condition is present, correct it as necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 13
13	Perform the procedure in "Fuel System Pressure Test" and repair fuel system problem if necessary. Did the test isolate a condition requiring repair?	—	Verify repair	Go to Step 14
14	Perform the "Evaporative Emissions Control (EVAP) Canister Purge Valve Check" and repair EVAP system problem if necessary. Did the test isolate a problem?	—	Verify repair	Go to Step 15
15	1. Visually and physically inspect the intake manifold, injector O-rings, EGR adapter, EGR valve and the EGR feed pipes for vacuum leaks. 2. Repair any problem that is found. Did your inspection reveal a problem?	—	Verify repair	Go to Step 16
16	Visually and physically inspect the Bank 1 exhaust manifold for leaks and loose or missing hardware and correct any problem found. Did your inspection reveal a problem?	—	Verify repair	Go to Step 17
17	Perform the "Injector Balance Test," and correct any problem found (refer to Fuel Metering System). Did the test isolate a problem?	—	Verify repair	Go to Step 18
18	1. Visually and physically inspect the Bank 1 HO2S 1 to ensure that it is installed securely and that the Bank 1 HO2S 1 pigtail and wiring harness are not contacting the exhaust or otherwise damaged. 2. If a problem is found, correct it as necessary. Did your inspection reveal a problem?	—	Verify repair	Refer to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P0172 SYSTEM TOO RICH (BANK 1)



D06RX048

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "Closed Loop" air/fuel metering system is used. While in "Closed Loop", the powertrain control module (PCM) monitors the Bank 1 heated oxygen sensor (HO2S) 1 and adjusts fuel delivery based upon the HO2S signal voltages. A change made to fuel delivery will be indicated by the long and short term fuel trim values which can be monitored with a Tech 2. Ideal fuel trim values are around 0%; if the HO2S signals are indicating a lean condition the PCM will add fuel, resulting in fuel trim values above 0%. If a rich condition is detected, the fuel trim values will be below 0%, indicating that the PCM is reducing the amount of fuel delivered. If an excessively rich condition is detected on Bank 1, the PCM will set Diagnostic Trouble Code P0172. DTC P0172 is a type B code.

The PCM's maximum authority to control long term fuel trim allows a range between -14% and +20%. The PCM's maximum authority to control short term fuel trim allows a range between -11% and +20%. The PCM monitors fuel trim under various engine speed/load fuel trim cells before determining the status of the fuel trim diagnostic.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of the following was set: EGR Diagnostic Trouble Codes, HO2S Diagnostic Trouble Codes, (response, transition, open, low volts, no activity), TPS Diagnostic Trouble Codes, MAP Diagnostic Trouble Codes, IAT

Diagnostic Trouble Codes, canister purge Diagnostic Trouble Codes, EVAP Diagnostic Trouble Codes, injector circuit Diagnostic Trouble Codes, or misfire Diagnostic Trouble Codes.

- Engine coolant temperature is between 65°C (149°F) and 104°C (219°F).
- Intake air temperature is between -40°C (-40°F) and 120°C (248°F).
- Manifold absolute pressure is between 23.75 kPa and 99 kPa.
- System voltage is greater than 9.5 volts.
- Engine speed is between 400 and 6000 RPM.
- Barometric pressure is greater than 72.3 kPa.
- Engine is operating in "Closed Loop".
- The average of the long term full trim samples is less than 1.03 and the average of the adaptive index multiplier samples is less than or equal to 0.82.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history Diagnostic Trouble Code P0172 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0172 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, observe the Bank 1 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the engine harness. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Diagnostic Trouble Codes other than P0172 may indicate a condition present which may cause a lean condition. If this is the case, repairing the condition which caused the other DTC will most likely correct the DTC P0172.
4. If the Diagnostic Trouble Code P0172 test passes while the Failure Records conditions are being duplicated, the rich condition is intermittent. Refer to Diagnostic Aids or Symptoms for additional information on diagnosing intermittent problems.

—


DTC P0172 – System Too Rich (Bank 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any Diagnostic Trouble Codes set other than P0172?	—	Go to the applicable DTC charts and repair the other DTCs before proceeding with this chart.	Go to Step 3
3	1. Start the engine and operate the vehicle in "Closed Loop". 2. Observe "BANK 1 L.T. FUEL TRIM" display on the Tech 2. Are the displayed values more negative than the specified values?	L.T. Fuel Trim: -14%	Go to Step 5	Go to Step 4
4	1. Review and record the Tech 2 Failure Records data. 2. Clear the Diagnostic Trouble Code P0172 and operate the vehicle to duplicate the Failure Records conditions. 3. Monitor the Tech 2 "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0172 while operating the vehicle to duplicate the Failure Records conditions. 4. Continue operating the vehicle until the Diagnostic Trouble Code P0172 test runs and note test result. Does the Tech 2 indicate Diagnostic Trouble Code P0172 failed this ignition?	—	Go to Step 5	The rich condition is not present. If a driveability symptom still exists, refer to Symptoms.
5	Visually and physically inspect the air filter element and replace it if necessary. Did the air filter require replacement?	—	Verify repair	Go to Step 6
6	Visually and physically inspect the air intake duct for collapse or restriction and repair if necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 7
7	Start the engine and note the idle quality. Is a low or unsteady idle being experienced?	—	Go to Step 8	Go to Step 10
8	With the engine idling, observe the "IDLE AIR CONTROL" display on the Tech 2. Is the "IDLE AIR CONTROL" value below the specified value?	Below 100 counts	Go to Step 10	Go to Step 9
9	1. Ignition OFF. 2. Physically inspect the throttle body bore, throttle plate, and IAC passages for coking and foreign objects. 3. If a problem was found, repair as necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 10

DTC P0172 – System Too Rich (Bank 1) (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Perform the "Idle Air Control (IAC) Valve Check." 2. If a problem is found, repair as necessary. Did the test isolate a problem requiring repair?	—	Verify repair	Go to Step 11
11	1. Disconnect the vacuum hose from the fuel pressure regulator and inspect the hose for the presence of fuel. 2. If fuel is present in the vacuum hose, replace the fuel pressure regulator (refer to Fuel Metering System). Did the fuel pressure regulator require replacement?	—	Verify repair	Go to Step 12
12	Ignition ON engine OFF monitor the TP Angle display on the Tech 2 while slowly depressing the accelerator pedal. Does the TP Angle display increase steadily and evenly from minimum value at closed throttle to maximum value at wide-open throttle?	Minimum 0% Maximum 100%	Go to Step 13	Go to Step 17
13	1. Perform the "Fuel System Pressure Test." 2. If the test isolates a problem, repair as necessary (refer to Engine Fuel or Fuel Metering System). Did the test isolate a problem requiring repair?	—	Verify repair	Go to Step 14
14	1. Perform the "Evaporative Emissions Control (EVAP) Canister Purge Valve Check." 2. If the test isolates a problem, repair as necessary. Did the test isolate a problem requiring repair?	—	Verify repair	Go to Step 15
15	1. Perform the "Injector Balance Test." 2. If the test isolates a problem, repair as necessary (refer to Fuel Metering System). Did the test isolate a problem requiring repair?	—	Verify repair	Go to Step 16
16	1. Remove and visually/physically inspect the Bank 1 HO2S 1 for silicon contamination. This will be indicated by a powdery white deposit on the portion of the HO2S that is exposed to the exhaust stream. 2. If contamination is evident on the Bank 1 HO2S 1, replace the contaminated sensors. Did the sensor require replacement?	—	Verify repair	Refer to Diagnostic Aids
17	1. Check the TP sensor mounting screws and tighten or replace them as necessary if they are loose or missing. 2. If the screws are OK, replace the TP sensor. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0201 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 1



Circuit Description

The powertrain control module (PCM) has four individual injector driver circuits. Each controls an injector. When a driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The PCM measures a voltage drop through a fixed resistor and controls it. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a Diagnostic Trouble Code is set. This Diagnostic Trouble Code is also set if an injector driver is shorted to voltage. DTC P0201 is a type A code.

Conditions for Setting the DTC

- ☐ The battery voltage is more than 9 volts.
- ☐ Engine is running.
- ☐ Fuel pump is ON.
- ☐ The injector voltage does not equal the ignition voltage when the injector is commanded OFF or the injector voltage does not equal 0 volts when the injector is commanded ON.
- ☐ The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- "Open Loop" fuel control will be in effect.

- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history Diagnostic Trouble Code P0201 will clear after 40 consecutive warm-up cycles occur without a fault.
- Diagnostic Trouble Code P0201 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids


An injector driver circuit that is open or shorted to voltage will cause a Diagnostic Trouble Code P0201 to set. It will also cause a misfire due to an inoperative injector. A misfire Diagnostic Trouble Code will also be set indicating which cylinder is inoperative.

Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. This step determines if Diagnostic Trouble Code P0201 is the result of a hard failure or an intermittent condition.
5. This step tests the harness wiring and PCM control of the injectors using a test light.
- The fuel injector test connector is a gray 5 pin connector at the right rear of the valve cover. It can be identified by a blue connector lock which is tethered to the harness.
- J 39021-45 is a test light with one light for each cylinder. The test light fits on the injector test connector.
- If the test light is ON steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to voltage.
- If the test light blinks, the PCM and the wiring to the injectors are OK. Fuel Injector Coil Test Procedure will check if the injectors are faulty.
7. Because the test light was ON steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.



13. Normal injector resistance is slightly more than if tested directly at the injector because it includes resistance of the harness wires. The normal value is about 13.5 Ω .


DTC P0201 – Injector Circuit Malfunction – Cylinder 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Will the engine start?	—	Go to Step 3	Go to Engine Cranks But Will Not Run Chart
3	1. Install the Tech 2. Clear the Diagnostic Trouble Code. 2. Idle the engine for one minute. Does Diagnostic Trouble Code P0201 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition ON and the engine OFF and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0201 reset?	—	Go to Step 5	Go to Diagnostic Aids
5	1. Ignition OFF. 2. Disconnect the injector test connector. 3. Install the injector test light J 39021-45 on the injector test connector. 4. Crank the engine while observing the light for cylinder 1. Does the injector test light blink?	—	Go to Fuel Injector Coil Test Procedure	Go to Step 6
6	Note whether the injector test light was OFF or ON steady in step 5. Was the test light ON steady while cranking the engine?	—	Go to Step 7	Go to Step 10

DTC P0201 – Injector Circuit Malfunction – Cylinder 1 (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 9
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to OBD System Check	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to OBD System Check	—
10	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each terminal on the PCM side of the injector test connector. Only the Ign+ terminal should illuminate the test light. Besides the Ign+, did any other terminal illuminate the test light?	—	Go to Step 11	Go to Step 12
11	Repair the short to voltage in the injector driver circuit.	—	Verify repair	—
12	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each pin on the injector side of the connector. Did any terminal illuminate the test light?	—	Go to Step 11	Go to Step 13
13	1. Disconnect the injector test connector. 2. Ignition OFF. 3. Clip one lead of an ohmmeter to the ignition pin on the injector side of the test connector. 4. Touch the other lead to each of the other four pins in the test connector, one pin at a time. Instead of normal injector resistance, did the ohmmeter indicate an open in one of the injector circuits?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit or open injector.	—	Verify repair	—
15	Check for an open circuit between the injector test connector and the PCM connector for the Injector 1 control circuit. Was there an open circuit?	—	Go to Step 16	Go to Step 9
16	Repair the open circuit.	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0202 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 2



Circuit Description

The powertrain control module (PCM) has four individual injector driver circuits. Each controls an injector. When a driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The PCM measures a voltage drop through a fixed resistor and controls it. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a Diagnostic Trouble Code is set. This Diagnostic Trouble Code is also set if an injector driver is shorted to voltage. DTC P0202 is a type A code.

Conditions for Setting the DTC

- ☐ The battery voltage is greater than 9 volts.
- ☐ Engine is running.
- ☐ Fuel pump is ON.
- ☐ The injector voltage does not equal the ignition voltage when the injector is commanded OFF or the injector voltage does not equal 0 volts when the injector is commanded ON.
- ☐ The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- "Open Loop" fuel control will be in effect.

- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history Diagnostic Trouble Code P0202 will clear after 40 consecutive warm-up cycles occur without a fault.
- Diagnostic Trouble Code P0202 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

An injector driver circuit that is open or shorted to voltage will cause a Diagnostic Trouble Code P0202 to set. It will also cause a misfire due to an inoperative injector. A misfire Diagnostic Trouble Code will also be set indicating which cylinder is inoperative.

Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. This step determines if Diagnostic Trouble Code P0202 is the result of a hard failure or an intermittent condition.

5. This step tests the harness wiring and PCM control of the injectors using a test light.


The fuel injector test connector is a gray 5 pin connector at the right rear of the valve cover. It can be identified by a blue connector lock which is tethered to the harness.

J 39021-45 is a test light with one light for each cylinder. The test light fits on the injector test connector.

If the test light is ON steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to voltage.

If the test light blinks, the PCM and the wiring to the injectors are OK. Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was ON steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.



901RX033

13. Normal injector resistance is slightly more than if tested directly at the injector because it includes resistance of the harness wires. The normal value is about 13.5 Ω .


DTC P0202 – Injector Circuit Malfunction – Cylinder 2

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Will the engine start?	—	Go to Step 3	Go to Engine Cranks But Will Not Run Chart
3	1. Install the Tech 2. Clear the Diagnostic Trouble Code. 2. Idle the engine for one minute. Does Diagnostic Trouble Code P0202 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition ON and the engine OFF and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0202 reset?	—	Go to Step 5	Go to Diagnostic Aids
5	1. Ignition OFF. 2. Disconnect the injector test connector. 3. Install the injector test light J 39021-45 on the injector connector. 4. Crank the engine while observing the light for cylinder 2. Does the injector test light blink?	—	Go to Fuel Injector Coil Test Procedure	Go to Step 6
6	Note whether the injector test light was OFF or ON steady in step 5. Was the test light ON steady while cranking the engine?	—	Go to Step 7	Go to Step 10

DTC P0202 – Injector Circuit Malfunction – Cylinder 2 (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 9
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to OBD System Check	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to OBD System Check	—
10	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each terminal on the PCM side of the injector test connector. Only the Ign+ terminal should illuminate the test light. Besides the Ign+, did any other terminal illuminate the test light?	—	Go to Step 11	Go to Step 12
11	Repair the short to voltage in the injector driver circuit.	—	Verify repair	—
12	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each pin on the injector side of the connector. Did any terminal illuminate the test light?	—	Go to Step 11	Go to Step 13
13	1. Disconnect the injector test connector. 2. Ignition OFF. 3. Clip one lead of an ohmmeter to the ignition pin on the injector side of the test connector. 4. Touch the other lead to each of the other four pins in the test connector, one pin at a time. Instead of normal injector resistance, did the ohmmeter indicate an open in one of the injector circuits?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit or open injector.	—	Verify repair	—
15	Check for an open circuit between the injector test connector and the PCM connector for the Injector 2 control circuit. Was there an open circuit?	—	Go to Step 16	Go to Step 9
16	Repair the open circuit.	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0203 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 3



D06RX049

Circuit Description

The powertrain control module (PCM) has four individual injector driver circuits. Each controls an injector. When the driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The PCM measures a voltage drop through a fixed resistor and controls it. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a Diagnostic Trouble Code is set. This Diagnostic Trouble Code is also set if an injector driver is shorted to voltage. DTC P0203 is a type A code.

Conditions for Setting the DTC

- The battery voltage is greater than 9 volts.
- Engine is running.
- Fuel pump is ON.
- The injector voltage does not equal the ignition voltage when the injector is commanded OFF or the injector voltage does not equal 0 volts when the injector is commanded ON.
- The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- "Open Loop" fuel control will be in effect.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history Diagnostic Trouble Code P0203 will clear after 40 consecutive warm-up cycles occur without a fault.
- Diagnostic Trouble Code P0203 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

An injector driver circuit that is open or shorted to voltage will cause a Diagnostic Trouble Code P0203 to set. It will also cause a misfire due to an inoperative injector. A misfire Diagnostic Trouble Code will also be set indicating which cylinder is inoperative. Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. This step determines if Diagnostic Trouble Code P0203 is the result of a hard failure or an intermittent condition.
5. This step tests the harness wiring and PCM control of the injectors using a test light.


The fuel injector test connector is a gray 5 pin connector at the right rear of the valve cover. It can be identified by a blue connector lock which is tethered to the harness.

J 39021-45 is a test light with one light for each cylinder. The test light fits on the injector test connector.

If the test light is ON steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to voltage.

If the test light blinks, the PCM and the wiring to the injectors are OK. Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was ON steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.



901RX034

13. Normal injector resistance is slightly more than if tested directly at the injector because it includes resistance of the harness wires. The normal value is about 13.5 Ω .


DTC P0203 – Injector Circuit Malfunction – Cylinder 3

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Will the engine start?	—	Go to Step 3	Go to Engine Cranks But Will Not Run Chart
3	1. Install the Tech 2. Clear the Diagnostic Trouble Code. 2. Idle the engine for one minute. Does Diagnostic Trouble Code P0203 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition ON and the engine OFF and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0203 reset?	—	Go to Step 5	Go to Diagnostic Aids
5	1. Ignition OFF. 2. Disconnect the injector test connector. 3. Install the injector test light J 39021-45 on the injector connector. 4. Crank the engine while observing the light for cylinder 3. Does the injector test light blink?	—	Go to Fuel Injector Coil Test Procedure	Go to Step 6
6	Note whether the injector test light was OFF or ON steady in step 5. Was the test light ON steady while cranking the engine?	—	Go to Step 7	Go to Step 10

DTC P0203 – Injector Circuit Malfunction – Cylinder 3 (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 9
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to OBD System Check	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to OBD System Check	—
10	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each terminal on the PCM side of the injector test connector. Only the Ign+ terminal should illuminate the test light. Besides the Ign+, did any other terminal illuminate the test light?	—	Go to Step 11	Go to Step 12
11	Repair the short to voltage in the injector driver circuit.	—	Verify repair	—
12	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each pin on the injector side of the connector. Did any terminal illuminate the test light?	—	Go to Step 11	Go to Step 13
13	1. Disconnect the injector test connector. 2. Ignition OFF. 3. Clip one lead of an ohmmeter to the ignition pin on the injector side of the test connector. 4. Touch the other lead to each of the other four pins in the test connector, one pin at a time. Instead of normal injector resistance, did the ohmmeter indicate an open in one of the injector circuits?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit or open injector.	—	Verify repair	—
15	Check for an open circuit between the injector test connector and the PCM connector for the Injector 3 control circuit. Was there an open circuit?	—	Go to Step 16	Go to Step 9
16	Repair the open circuit.	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0204 INJECTOR CIRCUIT MALFUNCTION – CYLINDER 4



Circuit Description

The powertrain control module (PCM) has four individual injector driver circuits. Each controls an injector. When the driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The PCM measures a voltage drop through a fixed resistor and controls it. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a Diagnostic Trouble Code is set. This Diagnostic Trouble Code is also set if an injector driver is shorted to voltage. DTC P0204 is a type A code.

Conditions for Setting the DTC

- ☐ The battery voltage is greater than 9 volts.
- ☐ Engine is running.
- ☐ Fuel pump is ON.
- ☐ The injector voltage does not equal the ignition voltage when the injector is commanded OFF or the injector voltage does not equal 0 volts when the injector is commanded ON.
- ☐ The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- "Open Loop" fuel control will be in effect.

- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history Diagnostic Trouble Code P0204 will clear after 40 consecutive warm-up cycles occur without a fault.
- Diagnostic Trouble Code P0204 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

An injector driver circuit that is open or shorted to voltage will cause a Diagnostic Trouble Code P0204 to set. It will also cause a misfire due to an inoperative injector. A misfire Diagnostic Trouble Code will also be set indicating which cylinder is inoperative.

Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:


3. This step determines if Diagnostic Trouble Code P0204 is the result of a hard failure or an intermittent condition.
5. This step tests the harness wiring and PCM control of the injectors using a test light.

The fuel injector test connector is a gray 5 pin connector at the right rear of the valve cover. It can be identified by a blue connector lock which is tethered to the harness.

J 39021-45 is a test light with one light for each cylinder. The test light fits on the injector test connector.

If the test light is ON steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to voltage.

If the test light blinks, the PCM and the wiring to the injectors are OK. Fuel Injector Coil Test Procedure will check if the injectors are faulty.
7. Because the test light was ON steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.



901RX035

13. Normal injector resistance is slightly more than if tested directly at the injector because it includes resistance of the harness wires. The normal value is about 13.5 Ω .


DTC P0204 – Injector Circuit Malfunction – Cylinder 4

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Will the engine start?	—	Go to Step 3	Go to Engine Cranks But Will Not Run Chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0204 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition ON and the engine OFF and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0204 reset?	—	Go to Step 5	Go to Diagnostic Aids
5	1. Ignition OFF. 2. Disconnect the injector test connector. 3. Install the injector test light J 39021-45 on the injector connector. 4. Crank the engine while observing the light for cylinder 4. Does the injector test light blink?	—	Go to Fuel Injector Coil Test Procedure	Go to Step 6
6	Note whether the injector test light was OFF or ON steady in step 5. Was the test light ON steady while cranking the engine?	—	Go to Step 7	Go to Step 10

DTC P0204 – Injector Circuit Malfunction – Cylinder 4 (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 9
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to OBD System Check	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to OBD System Check	—
10	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each terminal on the PCM side of the injector test connector. Only the Ign+ terminal should illuminate the test light. Besides the Ign+, did any other terminal illuminate the test light?	—	Go to Step 11	Go to Step 12
11	Repair the short to voltage in the injector driver circuit.	—	Verify repair	—
12	1. Disconnect the injector test connector. 2. Ignition ON. 3. Use a test light connected to ground to probe each pin on the injector side of the connector. Did any terminal illuminate the test light?	—	Go to Step 11	Go to Step 13
13	1. Disconnect the injector test connector. 2. Ignition OFF. 3. Clip one lead of an ohmmeter to the ignition pin on the injector side of the test connector. 4. Touch the other lead to each of the other four pins in the test connector, one pin at a time. Instead of normal injector resistance, did the ohmmeter indicate an open in one of the injector circuits?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit or open injector.	—	Verify repair	—
15	Check for an open circuit between the injector test connector and the PCM connector for the Injector 3 control circuit. Was there an open circuit?	—	Go to Step 16	Go to Step 9
16	Repair the open circuit.	—	—	Verify repair

DIAGNOSTIC TROUBLE CODE (DTC) P0300 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED



D06RX050

Circuit Description

If the PCM determines that the engine is misfiring and cannot determine the actual cylinder that is misfiring then it will log the trouble code P0300. This is normally the case where the misfire is caused by the ignition coil(s) which would then cause a misfire to happen in more than one cylinder.

Conditions for Setting the DTC

- None of the following Diagnostic Trouble Codes are present: TP sensor, MAP sensor, CMP sensor, VSS, ECT, CKP sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The engine coolant temperature sensor (ECT) indicates an engine temperature between -6.75°C (20°F) and 120°C (248°F).
- Throttle angle is steady and throttle angle changes less than 2.73% per 100 milliseconds.
- The PCM detects a crankshaft RPM variation indicating a misfire that is sufficient to cause catalytic converter damage or emissions levels to exceed the mandated standard.
- TP sensor reads less than 3.125%.
- Vehicle speed is greater than 33km/h (20mph).
- Engine under load.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- "Open Loop" fuel control will be in effect.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0300 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0300 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

The Tech 2 displays "Misfire Cur. # 1 through #4" can be useful to determine whether the misfire is isolated to a single cylinder.

- Damaged or faulty ignition coils – Check for cracks or other damage.

6E1-192 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

- Substitute a known good coil – Swap the ignition coils and retest. If misfire follows the coil, replace the ignition coil.

If the misfire is random, check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Air induction system – Check for disconnected or damaged vacuum hoses, incorrectly installed or faulty PCV valve, or for vacuum leaks at the throttle body, EGR valve, and intake manifold mounting surfaces.
- Fuel pressure – Perform a fuel system pressure test. A faulty fuel pump, plugged filter, or faulty fuel system pressure regulator will contribute to a lean condition.
- Excessive engine vibration – This may falsely set a P0300. Refer to Engine Mechanical Diagnosis to check for a falsely Mechanical condition or component.
- Injector(s) – Perform an injector coil/balance test to locate faulty injector(s) contributing to a lean or flooding condition. In addition to the above test, check the condition of the injector O-rings.
- EGR – Check for a leaking valve, adapter, or feed pipes which will contribute to a lean condition or excessive EGR flow.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0300 – Random/Multiple Cylinder Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	<ol style="list-style-type: none"> 1. Start and idle the engine. 2. Review and record the Tech 2 Freeze Frame data. 3. Operate the vehicle to duplicate the conditions present when the Diagnostic Trouble Code was set (as defined by the Freeze Frame data). 4. Monitor the Tech 2 "Misfire Cur. #" display for each cylinder. <p>Is "Misfire Cur. #" display increasing for any cylinder (indicating a misfire currently occurring)?</p>	—	Go to Step 3	Refer to Diagnostic Aids
3	<ol style="list-style-type: none"> 1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. 2. If a problem is found, repair or replace the vacuum hoses as necessary. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 4
4	<ol style="list-style-type: none"> 1. Visually and physically inspect the following areas for vacuum leaks: <ul style="list-style-type: none"> ○ Intake manifold ○ Injector O-rings ○ EGR valve ○ EGR feed pipes <p>Did your inspection reveal a vacuum leak?</p>	—	Verify repair	Go to Step 5
5	<ol style="list-style-type: none"> 1. Inspect the crankcase ventilation valve for proper installation or a cracked hose. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 6
6	<ol style="list-style-type: none"> 1. Remove and visually/physically inspect the ignition coils. Ensure that the coils are free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coils. <p>Was a problem found?</p>	—	Verify repair	Go to Step 7
7	<ol style="list-style-type: none"> 1. Remove the EGR valve and visually/physically inspect the pintle to ensure that it is not sticking partially open. Also, inspect the EGR valve pintle and seat for carbon deposits or burrs that may interfere with the pintle closing completely. 2. If a problem is found, clean the EGR valve pintle and seat or replace the EGR valve as necessary. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 8
8	<ol style="list-style-type: none"> 1. Install a spark tester at the spark plug end of the ignition wire for the cylinder that is indicated by the "Misfire Cur. Counters" or "Misfire Hist. Counters" as having the most severe misfire (largest number of counts). 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. <p>Is adequate spark present?</p>	—	Go to Step 13	Go to Step 9

DTC P0300 – Random/Multiple Cylinder Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Remove the spark plugs from the cylinders that were indicated as misfiring. 2. Visually inspect the spark plug electrodes. Does your inspection reveal any spark plugs exhibiting excessive fouling?	—	Go to Engine Mechanical Diagnosis	Go to Step 10
10	1. Visually inspect the spark plug insulators for cracks, carbon tracking, or other damage. 2. If a problem is found, replace the faulty spark plug(s) as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 11
11	Replace the ignition control module.	—	Verify repair	—
12	1. Inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight and in their proper locations. 2. If a problem is found, correct the faulty ground condition as necessary. Did your inspection reveal a poor ground?	—	Verify repair	Go to Step 13
13	1. Perform the "Fuel System Pressure Test" procedure. 2. If a problem is found, repair as necessary (refer to Engine Fuel or Fuel Metering System). Was a fuel system problem found?	—	Verify repair	Go to Step 14
14	1. Check the fuel for excessive water, alcohol, or other contaminants (refer to Diagnosis in Engine Fuel for procedure). Was the fuel contaminated?	—	Verify repair	Go to Step 15
15	1. Perform the "Injector Coil/Balance Test." 2. If a problem is found, replace the faulty injector(s) as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 16
16	Check for an engine mechanical problem. Refer to Engine Mechanical Diagnosis to diagnose the following conditions: <ul style="list-style-type: none"> <input type="radio"/> A faulty or incorrect camshaft <input type="radio"/> Leaking or sticky valves or piston rings <input type="radio"/> Excessive valve deposits <input type="radio"/> Loose or worn rocker arms <input type="radio"/> Weak valve springs <input type="radio"/> Incorrect valve timing <input type="radio"/> A leaking head gasket <input type="radio"/> A loose or broken motor mount 	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0301 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED



D06RX050

Circuit Description

If the PCM determines that the engine is misfiring and can determine the actual cylinder that is misfiring then it will log the individual trouble code for that cylinder P0301. This is normally the situation in the case of a failed fuel injector, spark plug or ignition lead.

Conditions for Setting the DTC

- None of the following Diagnostic Trouble Codes are present: TP sensor, MAP sensor, CMP sensor, VSS, ECT, CKP sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The engine coolant temperature sensor (ECT) indicates an engine temperature between -6.75°C (20°F) and 120°C (248°F).
- Throttle angle is steady and throttle angle changes less than 2.73% per 100 milliseconds.
- The PCM detects a crankshaft RPM variation indicating a misfire that is sufficient to cause catalytic converter damage or emissions levels to exceed the mandated standard.
- TP sensor reads less than 3.125%.
- Vehicle speed is greater than 33km/h (20mph).
- Engine under load.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- "Open Loop" fuel control will be in effect.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0301 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0301 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

The Tech 2 displays "Misfire Cur. # 1 through #4" can be useful to determine whether the misfire is isolated to a single cylinder.

- Damaged or faulty ignition coils – Check for cracks or other damage.

- Substitute a known good coil – Swap the ignition coils and retest. If misfire follows the coil, replace the ignition coil.

If the misfire is random, check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Air induction system – Check for disconnected or damaged vacuum hoses, incorrectly installed or faulty PCV valve, or for vacuum leaks at the throttle body, EGR valve, and intake manifold mounting surfaces.
- Fuel pressure – Perform a fuel system pressure test. A faulty fuel pump, plugged filter, or faulty fuel system pressure regulator will contribute to a lean condition.
- Excessive engine vibration – This may falsely set a P0301. Refer to Engine Mechanical Diagnosis to check for a falsely Mechanical condition or component.
- Injector(s) – Perform an injector coil/balance test to locate faulty injector(s) contributing to a lean or flooding condition. In addition to the above test, check the condition of the injector O-rings.
- EGR – Check for a leaking valve, adapter, or feed pipes which will contribute to a lean condition or excessive EGR flow.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0301 – Random/Multiple Cylinder Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Start and idle the engine. 2. Review and record the Tech 2 Freeze Frame data. 3. Operate the vehicle to duplicate the conditions present when the Diagnostic Trouble Code was set (as defined by the Freeze Frame data). 4. Monitor the Tech 2 "Misfire Cur. #" display for each cylinder. Is "Misfire Cur. #" display increasing for any cylinder (indicating a misfire currently occurring)?	—	Go to Step 3	Refer to Diagnostic Aids
3	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. 2. If a problem is found, repair or replace the vacuum hoses as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 4
4	1. Visually and physically inspect the following areas for vacuum leaks: ○ Intake manifold ○ Injector O-rings ○ EGR valve ○ EGR feed pipes Did your inspection reveal a vacuum leak?	—	Verify repair	Go to Step 5
5	Inspect the crankcase ventilation valve for proper installation or a cracked hose. Did your inspection reveal a problem?	—	Verify repair	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coils. Ensure that the coils are free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coils. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Install a spark tester at the spark plug end of the ignition wire for the cylinder that is indicated by the "Misfire Cur. Counters" or "Misfire Hist. Counters" as having the most severe misfire (largest number of counts). 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 12	Go to Step 8
8	1. Remove the spark plugs from the cylinders that were indicated as misfiring. 2. Visually inspect the spark plug electrodes. Does your inspection reveal any spark plugs exhibiting excessive fouling?	—	Go to Engine Mechanical Diagnosis	Go to Step 9

DTC P0301 – Random/Multiple Cylinder Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Visually inspect the spark plug insulators for cracks, carbon tracking, or other damage. 2. If a problem is found, replace the faulty spark plug(s) as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 10
10	Replace the ignition control module.	—	Verify repair	—
11	1. Inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight and in their proper locations. 2. If a problem is found, correct the faulty ground condition as necessary. Did your inspection reveal a poor ground?	—	Verify repair	Go to Step 12
12	1. Perform the "Fuel System Pressure Test" procedure. 2. If a problem is found, repair as necessary (refer to Engine Fuel or Fuel Metering System). Was a fuel system problem found?	—	Verify repair	Go to Step 13
13	1. Check the fuel for excessive water, alcohol, or other contaminants (refer to Diagnosis in Engine Fuel for procedure). Was the fuel contaminated?	—	Verify repair	Go to Step 14
14	1. Perform the "Injector Coil/Balance Test." 2. If a problem is found, replace the faulty injector(s) as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 15
15	Check for an engine mechanical problem. Refer to Engine Mechanical Diagnosis to diagnose the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or piston rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ Incorrect valve timing ○ A leaking head gasket ○ A loose or broken motor mount 	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0302 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED



D06RX050

Circuit Description

If the PCM determines that the engine is misfiring and can determine the actual cylinder that is misfiring then it will log the individual trouble code for that cylinder P0302. This is normally the situation in the case of a failed fuel injector, spark plug or ignition lead.

Conditions for Setting the DTC

- None of the following Diagnostic Trouble Codes are present: TP sensor, MAP sensor, CMP sensor, VSS, ECT, CKP sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The engine coolant temperature sensor (ECT) indicates an engine temperature between -6.75°C (20°F) and 120°C (248°F).
- Throttle angle is steady and throttle angle changes less than 2.73% per 100 milliseconds.
- The PCM detects a crankshaft RPM variation indicating a misfire that is sufficient to cause catalytic converter damage or emissions levels to exceed the mandated standard.
- TP sensor reads less than 3.125%.
- Vehicle speed is greater than 33km/h (20mph).
- Engine under load.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- "Open Loop" fuel control will be in effect.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0302 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0302 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

The Tech 2 displays "Misfire Cur. # 1 through #4" can be useful to determine whether the misfire is isolated to a single cylinder.

- Damaged or faulty ignition coils – Check for cracks or other damage.

- Substitute a known good coil – Swap the ignition coils and retest. If misfire follows the coil, replace the ignition coil.

If the misfire is random, check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Air induction system – Check for disconnected or damaged vacuum hoses, incorrectly installed or faulty PCV valve, or for vacuum leaks at the throttle body, EGR valve, and intake manifold mounting surfaces.
- Fuel pressure – Perform a fuel system pressure test. A faulty fuel pump, plugged filter, or faulty fuel system pressure regulator will contribute to a lean condition.
- Excessive engine vibration – This may falsely set a P0302. Refer to Engine Mechanical Diagnosis to check for a falsely Mechanical condition or component.
- Injector(s) – Perform an injector coil/balance test to locate faulty injector(s) contributing to a lean or flooding condition. In addition to the above test, check the condition of the injector O-rings.
- EGR – Check for a leaking valve, adapter, or feed pipes which will contribute to a lean condition or excessive EGR flow.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0302 – Random/Multiple Cylinder Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	<ol style="list-style-type: none"> 1. Start and idle the engine. 2. Review and record the Tech 2 Freeze Frame data. 3. Operate the vehicle to duplicate the conditions present when the Diagnostic Trouble Code was set (as defined by the Freeze Frame data). 4. Monitor the Tech 2 "Misfire Cur. #" display for each cylinder. <p>Is "Misfire Cur. #" display increasing for any cylinder (indicating a misfire currently occurring)?</p>	—	Go to Step 3	Refer to Diagnostic Aids
3	<ol style="list-style-type: none"> 1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. 2. If a problem is found, repair or replace the vacuum hoses as necessary. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 4
4	<ol style="list-style-type: none"> 1. Visually and physically inspect the following areas for vacuum leaks: <ul style="list-style-type: none"> ○ Intake manifold ○ Injector O-rings ○ EGR valve ○ EGR feed pipes <p>Did your inspection reveal a vacuum leak?</p>	—	Verify repair	Go to Step 5
5	<ol style="list-style-type: none"> 1. Inspect the crankcase ventilation valve for proper installation or a cracked hose. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 6
6	<ol style="list-style-type: none"> 1. Remove and visually/physically inspect the ignition coils. Ensure that the coils are free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coils. <p>Was a problem found?</p>	—	Verify repair	Go to Step 7
7	<ol style="list-style-type: none"> 1. Install a spark tester at the spark plug end of the ignition wire for the cylinder that is indicated by the "Misfire Cur. Counters" or "Misfire Hist. Counters" as having the most severe misfire (largest number of counts). 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. <p>Is adequate spark present?</p>	—	Go to Step 12	Go to Step 8
8	<ol style="list-style-type: none"> 1. Remove the spark plugs from the cylinders that were indicated as misfiring. 2. Visually inspect the spark plug electrodes. <p>Does your inspection reveal any spark plugs exhibiting excessive fouling?</p>	—	Go to Engine Mechanical Diagnosis	Go to Step 9

DTC P0302 – Random/Multiple Cylinder Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Visually inspect the spark plug insulators for cracks, carbon tracking, or other damage. 2. If a problem is found, replace the faulty spark plug(s) as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 10
10	Replace the ignition control module.	—	Verify repair	—
11	1. Inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight and in their proper locations. 2. If a problem is found, correct the faulty ground condition as necessary. Did your inspection reveal a poor ground?	—	Verify repair	Go to Step 12
12	1. Perform the "Fuel System Pressure Test" procedure. 2. If a problem is found, repair as necessary (refer to Engine Fuel or Fuel Metering System). Was a fuel system problem found?	—	Verify repair	Go to Step 13
13	1. Check the fuel for excessive water, alcohol, or other contaminants (refer to Diagnosis in Engine Fuel for procedure). Was the fuel contaminated?	—	Verify repair	Go to Step 14
14	1. Perform the "Injector Coil/Balance Test." 2. If a problem is found, replace the faulty injector(s) as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 15
15	Check for an engine mechanical problem. Refer to Engine Mechanical Diagnosis to diagnose the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or piston rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ Incorrect valve timing ○ A leaking head gasket ○ A loose or broken motor mount 	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0303 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED



D06RX050

Circuit Description

If the PCM determines that the engine is misfiring and can determine the actual cylinder that is misfiring then it will log the individual trouble code for that cylinder P0303. This is normally the situation in the case of a failed fuel injector, spark plug or ignition lead.

Conditions for Setting the DTC

- None of the following Diagnostic Trouble Codes are present: TP sensor, MAP sensor, CMP sensor, VSS, ECT, CKP sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The engine coolant temperature sensor (ECT) indicates an engine temperature between -6.75°C (20°F) and 120°C (248°F).
- Throttle angle is steady and throttle angle changes less than 2.73% per 100 milliseconds.
- The PCM detects a crankshaft RPM variation indicating a misfire that is sufficient to cause catalytic converter damage or emissions levels to exceed the mandated standard.
- TP sensor reads less than 3.125%.
- Vehicle speed is greater than 33km/h (20mph).
- Engine under load.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- "Open Loop" fuel control will be in effect.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0303 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0303 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

The Tech 2 displays "Misfire Cur. # 1 through #4" can be useful to determine whether the misfire is isolated to a single cylinder.

- Damaged or faulty ignition coils – Check for cracks or other damage.

- Substitute a known good coil – Swap the ignition coils and retest. If misfire follows the coil, replace the ignition coil.

If the misfire is random, check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Air induction system – Check for disconnected or damaged vacuum hoses, incorrectly installed or faulty PCV valve, or for vacuum leaks at the throttle body, EGR valve, and intake manifold mounting surfaces.
- Fuel pressure – Perform a fuel system pressure test. A faulty fuel pump, plugged filter, or faulty fuel system pressure regulator will contribute to a lean condition.
- Excessive engine vibration – This may falsely set a P0303. Refer to Engine Mechanical Diagnosis to check for a falsely Mechanical condition or component.
- Injector(s) – Perform an injector coil/balance test to locate faulty injector(s) contributing to a lean or flooding condition. In addition to the above test, check the condition of the injector O-rings.
- EGR – Check for a leaking valve, adapter, or feed pipes which will contribute to a lean condition or excessive EGR flow.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0303 – Random/Multiple Cylinder Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	<ol style="list-style-type: none"> 1. Start and idle the engine. 2. Review and record the Tech 2 Freeze Frame data. 3. Operate the vehicle to duplicate the conditions present when the Diagnostic Trouble Code was set (as defined by the Freeze Frame data). 4. Monitor the Tech 2 "Misfire Cur. #" display for each cylinder. <p>Is "Misfire Cur. #" display increasing for any cylinder (indicating a misfire currently occurring)?</p>	—	Go to Step 3	Refer to Diagnostic Aids
3	<ol style="list-style-type: none"> 1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. 2. If a problem is found, repair or replace the vacuum hoses as necessary. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 4
4	<ol style="list-style-type: none"> 1. Visually and physically inspect the following areas for vacuum leaks: <ul style="list-style-type: none"> ○ Intake manifold ○ Injector O-rings ○ EGR valve ○ EGR feed pipes <p>Did your inspection reveal a vacuum leak?</p>	—	Verify repair	Go to Step 5
5	<ol style="list-style-type: none"> 1. Inspect the crankcase ventilation valve for proper installation or a cracked hose. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 6
6	<ol style="list-style-type: none"> 1. Remove and visually/physically inspect the ignition coils. Ensure that the coils are free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coils. <p>Was a problem found?</p>	—	Verify repair	Go to Step 7
7	<ol style="list-style-type: none"> 1. Install a spark tester at the spark plug end of the ignition wire for the cylinder that is indicated by the "Misfire Cur. Counters" or "Misfire Hist. Counters" as having the most severe misfire (largest number of counts). 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. <p>Is adequate spark present?</p>	—	Go to Step 12	Go to Step 8
8	<ol style="list-style-type: none"> 1. Remove the spark plugs from the cylinders that were indicated as misfiring. 2. Visually inspect the spark plug electrodes. <p>Does your inspection reveal any spark plugs exhibiting excessive fouling?</p>	—	Go to Engine Mechanical Diagnosis	Go to Step 9

DTC P0303 – Random/Multiple Cylinder Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Visually inspect the spark plug insulators for cracks, carbon tracking, or other damage. 2. If a problem is found, replace the faulty spark plug(s) as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 10
10	Replace the ignition control module.	—	Verify repair	—
11	1. Inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight and in their proper locations. 2. If a problem is found, correct the faulty ground condition as necessary. Did your inspection reveal a poor ground?	—	Verify repair	Go to Step 12
12	1. Perform the "Fuel System Pressure Test" procedure. 2. If a problem is found, repair as necessary (refer to Engine Fuel or Fuel Metering System). Was a fuel system problem found?	—	Verify repair	Go to Step 13
13	1. Check the fuel for excessive water, alcohol, or other contaminants (refer to Diagnosis in Engine Fuel for procedure). Was the fuel contaminated?	—	Verify repair	Go to Step 14
14	1. Perform the "Injector Coil/Balance Test." 2. If a problem is found, replace the faulty injector(s) as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 15
15	Check for an engine mechanical problem. Refer to Engine Mechanical Diagnosis to diagnose the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or piston rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ Incorrect valve timing ○ A leaking head gasket ○ A loose or broken motor mount 	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0304 RANDOM/MULTIPLE CYLINDER MISFIRE DETECTED



D06RX050

Circuit Description

If the PCM determines that the engine is misfiring and can determine the actual cylinder that is misfiring then it will log the individual trouble code for that cylinder P0304. This is normally the situation in the case of a failed fuel injector, spark plug or ignition lead.

Conditions for Setting the DTC

- None of the following Diagnostic Trouble Codes are present: TP sensor, MAP sensor, CMP sensor, VSS, ECT, CKP sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The engine coolant temperature sensor (ECT) indicates an engine temperature between -6.75°C (20°F) and 120°C (248°F).
- Throttle angle is steady and throttle angle changes less than 2.73% per 100 milliseconds.
- The PCM detects a crankshaft RPM variation indicating a misfire that is sufficient to cause catalytic converter damage or emissions levels to exceed the mandated standard.
- TP sensor reads less than 3.125%.
- Vehicle speed is greater than 33km/h (20mph).
- Engine under load.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- "Open Loop" fuel control will be in effect.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0304 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0304 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

The Tech 2 displays "Misfire Cur. # 1 through #4" can be useful to determine whether the misfire is isolated to a single cylinder.

- Damaged or faulty ignition coils – Check for cracks or other damage.

- Substitute a known good coil – Swap the ignition coils and retest. If misfire follows the coil, replace the ignition coil.

If the misfire is random, check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Air induction system – Check for disconnected or damaged vacuum hoses, incorrectly installed or faulty PCV valve, or for vacuum leaks at the throttle body, EGR valve, and intake manifold mounting surfaces.
- Fuel pressure – Perform a fuel system pressure test. A faulty fuel pump, plugged filter, or faulty fuel system pressure regulator will contribute to a lean condition.
- Excessive engine vibration – This may falsely set a P0304. Refer to Engine Mechanical Diagnosis to check for a falsely Mechanical condition or component.
- Injector(s) – Perform an injector coil/balance test to locate faulty injector(s) contributing to a lean or flooding condition. In addition to the above test, check the condition of the injector O-rings.
- EGR – Check for a leaking valve, adapter, or feed pipes which will contribute to a lean condition or excessive EGR flow.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0304 – Random/Multiple Cylinder Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	<ol style="list-style-type: none"> 1. Start and idle the engine. 2. Review and record the Tech 2 Freeze Frame data. 3. Operate the vehicle to duplicate the conditions present when the Diagnostic Trouble Code was set (as defined by the Freeze Frame data). 4. Monitor the Tech 2 "Misfire Cur. #" display for each cylinder. <p>Is "Misfire Cur. #" display increasing for any cylinder (indicating a misfire currently occurring)?</p>	—	Go to Step 3	Refer to Diagnostic Aids
3	<ol style="list-style-type: none"> 1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. 2. If a problem is found, repair or replace the vacuum hoses as necessary. <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 4
4	<ol style="list-style-type: none"> 1. Visually and physically inspect the following areas for vacuum leaks: <ul style="list-style-type: none"> ○ Intake manifold ○ Injector O-rings ○ EGR valve ○ EGR feed pipes <p>Did your inspection reveal a vacuum leak?</p>	—	Verify repair	Go to Step 5
5	<p>Inspect the crankcase ventilation valve for proper installation or a cracked hose.</p> <p>Did your inspection reveal a problem?</p>	—	Verify repair	Go to Step 6
6	<ol style="list-style-type: none"> 1. Remove and visually/physically inspect the ignition coils. Ensure that the coils are free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coils. <p>Was a problem found?</p>	—	Verify repair	Go to Step 7
7	<ol style="list-style-type: none"> 1. Install a spark tester at the spark plug end of the ignition wire for the cylinder that is indicated by the "Misfire Cur. Counters" or "Misfire Hist. Counters" as having the most severe misfire (largest number of counts). 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. <p>Is adequate spark present?</p>	—	Go to Step 12	Go to Step 8
8	<ol style="list-style-type: none"> 1. Remove the spark plugs from the cylinders that were indicated as misfiring. 2. Visually inspect the spark plug electrodes. <p>Does your inspection reveal any spark plugs exhibiting excessive fouling?</p>	—	Go to Engine Mechanical Diagnosis	Go to Step 9

DTC P0304 – Random/Multiple Cylinder Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Visually inspect the spark plug insulators for cracks, carbon tracking, or other damage. 2. If a problem is found, replace the faulty spark plug(s) as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 10
10	Replace the ignition control module.	—	Verify repair	—
11	1. Inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight and in their proper locations. 2. If a problem is found, correct the faulty ground condition as necessary. Did your inspection reveal a poor ground?	—	Verify repair	Go to Step 12
12	1. Perform the "Fuel System Pressure Test" procedure. 2. If a problem is found, repair as necessary (refer to Engine Fuel or Fuel Metering System). Was a fuel system problem found?	—	Verify repair	Go to Step 13
13	1. Check the fuel for excessive water, alcohol, or other contaminants (refer to Diagnosis in Engine Fuel for procedure). Was the fuel contaminated?	—	Verify repair	Go to Step 14
14	1. Perform the "Injector Coil/Balance Test." 2. If a problem is found, replace the faulty injector(s) as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 15
15	Check for an engine mechanical problem. Refer to Engine Mechanical Diagnosis to diagnose the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or piston rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ Incorrect valve timing ○ A leaking head gasket ○ A loose or broken motor mount 	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0325 KNOCK SENSOR (KS) CIRCUIT MALFUNCTION



D06RX061

Circuit Description

The knock sensor (KS) system is used to detect engine detonation. The knock sensor produced an AC voltage signal. The knock sensor sends this signal to the PCM. The amplitude and the frequency of the AC voltage signal depends upon the knock level being detected. The PCM will then retard the spark timing based on the signals from the Knock Sensor. DTC P0325 is a type B code.

Conditions for Setting the DTC

- Engine run time is greater than 10 seconds.
 - No P0327 Diagnostic Trouble Code set.
 - Engine speed is above 2500 rpm.
- All the above mentioned conditions are met, and the following conditions are met for 8.75 seconds within a 10 second monitoring period:
- Any of the four A/D voltages exceeds 1.5625 Volts.
 - Instantaneous A/D delta Voltage falls below 0.019531 Volts.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate the second time the fault is detected.
- The PCM will record operating conditions at the time the diagnostic fails.
- A history Diagnostic Trouble Code is stored.

- The PCM will use a calculated spark retard value in order to minimize the knock during the conditions when the knock is likely to occur. The calculated value will vary based on the engine speed and load.

Conditions for Clearing the MIL/DTC

- The MIL will turn off after 3 consecutive ignition cycles in which the diagnostic runs without a fault.
- A history Diagnostic Trouble Code will clear after 40 consecutive warm up cycles without a fault.
- A Tech 2 can clear the Diagnostic Trouble Codes.

Diagnostic Aids

Correct any abnormal engine noise before using the diagnostic table.
Check for an open ignition feed circuit.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame data and failure records data on the Tech 2 if applicable. This creates an electronic copy of the data taken when the malfunction occurred. The information is then stored on the Tech 2 for later reference.

6E1-212 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

2. If the conditions for the test as described above are met, a Diagnostic Trouble Code P0325 will set and MIL will illuminate.
4. If the engine has an internal knock or audible noise that causes a knocking type noise on the engine block, the knock sensor may be responding to the noise.
6. The Tech 2 displays knock sensor activity in counts, approximately 20–50 at idle. The counts should increase when engine speed is increased and the counts should decrease when engine speed is decreased.
7. Any circuitry, that is suspected as causing the complaint, should be thoroughly checked for backed out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal to wiring connections or physical damage to the wiring harness.

8. If the KS module was previously replaced and the Diagnostic Trouble Code resets, a malfunctioning PCM is indicated.

NOTE: Replacement PCMs must be reprogrammed. Refer to On–Vehicle Service in Powertrain Control Module and Sensors for procedures.

9. Checking the internal resistance of the knock sensor verifies if the knock sensor or the wiring to the knock sensor is OK.


DTC P0325 KS Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the Powertrain "On–Board Diagnostic (OBD) System Check" performed? —	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Start the engine. 2. Install a Tech 2. 3. Clear the Diagnostic Trouble Codes. 4. Run the engine at slightly more than 10% throttle angle. Does the Malfunction Indicator Lamp (MIL) illuminate?	—	Go to Step 4	Go to Step 3
3	1. Turn the ignition switch ON, with engine OFF. 2. Review the Freeze Frame data and note the parameters. 3. Operate the vehicle within the Conditions and Conditions for Setting the DTC as noted. Does the Malfunction Indicator Lamp (MIL) illuminate?	—	Go to Step 4	Go to Step 13
4	Listen to the engine while raising and lowering the engine speed. Is a knock or audible noise present?	—	Go to Step 5	Go to Step 6
5	Repair the mechanical engine problem or a loose bracket or component. Is the action complete?	—	Go to Step 13	—
6	Slowly increase the engine speed to the specified value. Does the KS Activity increase with the engine speed?	2500 RPM	Go to Step 7	Go to Step 11
7	Check for a poor connection at the PCM connector, Knock sensor signal circuit and repair as necessary. Was a repair necessary?	—	Go to Step 13	Go to Step 8

DTC P0325 KS Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
8	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Go to Step 13	—
9	<p>1. Turn the ignition switch OFF.</p> <p>2. Disconnect the PCM connectors at the PCM.</p> <p>3. With a Digital Voltmeter (DVM) connected to ground, measure the resistance of the knock sensor through the knock sensor signal circuit.</p> <p>Is the measured value within the specified value?</p>	90K – 110K Ω	Go to Step 7	Go to Step 10
10	<p>Check the knock sensor electrical connector for a poor connection and repair as necessary.</p> <p>Was a repair necessary?</p>	—	Go to Step 13	Go to Step 11
11	<p>Check the knock sensor signal circuit for an open or a short to ground or to voltage and repair as necessary.</p> <p>Was a repair necessary?</p>	—	Go to Step 13	Go to Step 12
12	<p>Replace the Knock Sensor (KS).</p> <p>Is the action complete?</p>	—	Go to Step 13	—
13	<p>1. Using the Tech 2, clear the Diagnostic Trouble Codes.</p> <p>2. Start the engine and idle at normal operating temperature.</p> <p>3. Operate the vehicle within the conditions for setting this Diagnostic Trouble Code as specified in the supporting text.</p> <p>Does the Tech 2 indicate that this diagnostic has ran and passed?</p>	—	Go to Step 14	Go to Step 2
14	<p>Check is any additional Diagnostic Trouble Codes are set.</p> <p>Are any Diagnostic Trouble Codes displayed that have not been diagnosed?</p>	—	Go to applicable DTC table	System OK

DIAGNOSTIC TROUBLE CODE (DTC) P0327 KNOCK SENSOR (KS) CIRCUIT LOW INPUT



D06RX051

Circuit Description

The PCM uses the Knock Sensor (KS) in order to detect engine detonation. This allows the PCM to retard the Ignition Control (IC) spark timing based on the KS signal the PCM receives. The circuitry within the knock sensor pulls down the PCM-supplied 5 volt signal, so that under a no knock condition the signal on the KS circuit measures about 1.3 volts. The knock sensors produce an AC signal that rides on the 1.3 volts DC. The signal's amplitude and frequency are dependent upon the amount of the knock being experienced.

The PCM determines whether the knock is occurring by comparing the signal level on the KS circuit with a voltage level on the noise channel. The noise channel allows the CM to reject any false knock signal by indicating the amount of normal engine mechanical noise present. The normal engine noise varies depending on the engine speed and load. Then the ECM determines that an abnormally high noise channel voltage level is being experienced, a Diagnostic Trouble Code P0327 sets. This DTC is a type B DTC.

Conditions for Setting the DTC

A/D Test

The following conditions are met for 7.5 seconds within a 10 second monitoring period:

- Engine speed is equal to or greater than 2000 RPM.

- A/D Voltage is less than or equal to 0.0977 Volts.

Gain Test

The following conditions are met for 7.5 seconds within a 10 second monitoring period:

- Engine speed is greater than 2500 RPM.
- Gain is equal to or greater than 23.875 dB.

Action Taken When the DTC Sets

- The PCM will illuminate the MIL the second time the fault is detected.
- The PCM will store the conditions which were present then the Diagnostic Trouble Code set.
- The PCM will use a calculated spark retard value in order to minimize the knock during the conditions when the knock is likely to occur. The calculated value will vary based on the engine speed and load.

Conditions for Clearing the MIL/DTC

- A history Diagnostic Trouble Code will clear after 40 consecutive warm-up cycles have occurred without a fault.
- The Tech 2 "Clear Info" will clear the Diagnostic Trouble Code.

Diagnostic Aids

Check for the following conditions:

A poor connection at the PCM. Inspect the knock sensor and the PCM connectors for: , broken locks, improperly formed or damaged terminals.

- Backed out terminals
 - Broken locks
 - Improperly formed or damaged terminals
- Also, check the wiring harness for: shorts to ground, shorts to battery positive, and open circuits.
- A misrouted harness. Inspect the knock sensor harness in order to ensure that it is not routed too close to high voltage wires such as spark plug leads.
 - Improper Knock Sensor torque specification. Torque the Knock Sensor to 19N·m (14 lbs·ft). Refer to Fastener Notice.

Review the Fail Records vehicle mileage since the diagnostic test last failed in order to help determine how often the conditions that caused the DTC to set occur. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

- 2. Ensures that the fault is present.
- 6. Ensures that the knock sensor is capable of detecting detonation.


DTC P0327 KS Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the Powertrain "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Operate the engine within the conditions specified in the diagnostic support Conditions for Setting the DTC. 2. Using a Tech 2, monitor the Diagnostic Trouble Code information for Diagnostic Trouble Code P0327 until the Diagnostic Trouble Code P0327 test runs. 3. Observe the test results. Does the Tech 2 indicate the DTC P0327 failed this ignition?	—	Go to Step 4	Go to Step 3
3	1. Turn ON the Ignition leaving the engine OFF. 2. Review the Tech 2 Fail Records data. 3. IMPORTANT: Before clearing the DTCs, use the Tech 2 to record the Freeze Frame and the Failure Records for reference. This data will be lost when the Clear Info function is used. 4. Record the Tech 2 Fail Records data. 5. Operate the vehicle within the Fail Records conditions. 6. Using a Tech 2, monitor the DTC info for the DTC P0327 until the DTC P0327 test runs. 7. Observe the test results. Does the Tech 2 indicate the DTC P0327 Failed This Ignition?	—	Go to Step 4	Go to Diagnostic Aids
4	1. Disconnect the KS Sensor electrical connector. 2. Using a Digital Voltmeter (DVM), measure the voltage between the KS signal circuit at the knock sensor harness connectors and ground. Is the voltage at the specified value?	Approx. 5.0 V	Go to Step 5	Go to Step 8
5	Measure the resistance of the KS sensor by connecting the between the KS sensor terminal and the engine block. Is the resistance of the KS sensor near the specified value?	100K Ω	Go to Step 6	Go to Step 9

DTC P0327 KS Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Check the KS signal circuit for a poor terminal connection at the knock sensor. 2. If a problem is found, repair as necessary. Refer to Wiring Repairs in Engine Electrical. Was a problem found?	—	Go to Step 7	Go to Step 9
7	1. Re-Connect the KS Sensor in order to monitor the voltage between the KS sensor terminal and the engine ground. 2. Tap on the engine lift bracket, near the KS Sensor, while observing the signal indicated on the Tech 2. Is any signal indicated on the while tapping on the engine lift bracket?	—	Go to Step 11	Go to Step 8
8	1. Turn OFF the ignition. 2. Disconnect the PCM. 3. Turn ON the ignition. 4. Check the KS signal circuit between the PCM and the KS sensor connector for an open, a short to voltage, or a short to ground. 5. If a wiring problem is found, repair as necessary. Was a problem found?	—	Go to Step 11	Go to Step 10
9	Replace the KS Sensor. Refer to Knock Sensor. Is the action complete?	—	Go to Step 11	—
10	Replace the PCM. IMPORTANT: If the PCM is faulty, reprogram the PCM. Refer to PCM Replacement/Programming. Is the action complete?	—	Go to Step 11	—
11	1. Using the Tech 2, select the DTC and the Clear Info. 2. Start the engine. 3. Idle at the normal operating temperature. 4. Select the DTC and the Specific. 5. Enter the DTC number which was set. 6. Operate the vehicle within the conditions for setting this DTC as specified in the supporting text. Does the Tech 2 indicate that this diagnostic ran and passed?	—	Go to Step 12	Go to Step 2
12	Using the Tech 2, select the Capture Info and the Review Info. Are any DTCs displayed that have not been diagnosed?	—	Go to applicable DTC table	System OK

DIAGNOSTIC TROUBLE CODE (DTC) P0336 CRANKSHAFT POSITION (CKP) SENSOR CIRCUIT RANGE/PERFORMANCE



D06RX062

Circuit Description

The 58X reference signal is produced by the crankshaft position (CKP) sensor. During one crankshaft revolution, 58 crankshaft pulses will be produced. The powertrain control module (PCM) uses the 58X reference signal to calculate engine RPM and crankshaft position. The PCM constantly monitors the number of pulses on the 58X reference circuit and compares them to the number of camshaft position (CMP) signal pulses being received. If the PCM receives an incorrect number of pulses on the 58X reference circuit, Diagnostic Trouble Code P0336 will set. Diagnostic Trouble Code P0336 is a type B code.

Conditions for Setting the DTC

- Engine is running.
- Extra or missing pulse is detected between consecutive 58X reference pulses.
- Above condition is detected in 10 of 100 crankshaft rotations.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0336 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0336 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for:

- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, disconnect the PCM, turn the ignition on and observe a voltmeter connected to the 58X reference circuit at the PCM harness connector while moving connectors and wiring harnesses related to the PCM. A change in voltage will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to


6E1-218 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

be set occurs. This may assist in diagnosing the condition.

DTC P0336 – CKP Sensor Circuit Range/Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Attempt to start the engine. Does the engine start?	—	Go to Step 3	Refer to Engine Cranks But Will Not Run chart
3	1. Review and record Failure Records information. 2. Clear Diagnostic Trouble Code P0336. 3. Start the engine and idle for 1 minute. 4. Observe Diagnostic Trouble Codes. Is Diagnostic Trouble Code P0336 set?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Disconnect the PCM and CKP sensor. 2. Check for an open or a short to ground in the 58X reference circuit between the CKP sensor connector and the PCM harness connector. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Reconnect the PCM and CKP sensor. 2. Connect a Digital Voltmeter (DVM) to measure voltage on the 58X reference circuit at the PCM connector. 3. Observe the voltage while cranking the engine. Is the voltage near the specified value?	2.5 V	Go to Step 8	Go to Step 6
6	Check the connections at the CKP sensor and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 7
7	Replace the CKP sensor. IMPORTANT: The PCM must go through the Scan Tool's Tooth Error Correction (TEC) procedure after CKP Sensor replacement. Refer to the Tooth Error Correction procedure. Is the action complete?	—	Verify repair	—
8	Check connections at the PCM and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 9
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0337 CRANKSHAFT POSITION (CKP) SENSOR CIRCUIT LOW INPUT



D06RX062

Circuit Description

The 58X reference signal is produced by the crankshaft position (CKP) sensor. During one crankshaft revolution, 58 crankshaft reference pulses will be produced. The powertrain control module (PCM) uses the 58X reference signal to calculate engine RPM and crankshaft position. The PCM constantly monitors the number of pulses on the 58X reference circuit and compares them to the number of camshaft position (CMP) signal pulses being received. If the PCM does not receive pulses on the 58X reference circuit, Diagnostic Trouble Code P0337 will set. Diagnostic Trouble Code P0337 is a type B code.

Conditions for Setting the DTC

- No camshaft position (CMP) sensor DTCs are set.
- Engine cranking.
- Crankshaft position (CKP) sensor signal is not present between two cam pulses.
- CKP reference pulse is not detected within 24 CMP pulses.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0337 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0337 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for:

- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, disconnect the PCM, turn the ignition on and observe a voltmeter connected to the 58X reference circuit at the PCM harness connector while moving connectors and wiring harnesses related to the PCM. A change in voltage will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to

6E1-220 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

be set occurs. This may assist in diagnosing the condition.


DTC P0337 – CKP Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Disconnect the CKP sensor. 2. Ignition ON. 3. Using a Digital Voltmeter (DVM), verify that 5 V reference and ground are being supplied at the sensor connector (PCM side). Are 5 V and ground being supplied to the sensor?	—	Go to Step 5	Go to Step 3
3	1. Ignition ON. 2. With a DVM, backprobe the PCM connector 5 V reference and ground connections. Are 5 V reference and ground available at the PCM?	—	Go to Step 4	Go to Step 9
4	Check 5 V reference or ground between the CKP sensor and PCM and repair the open circuit, short to ground or short to voltage. Is the action complete?	—	Verify repair	—
5	1. Ignition OFF. 2. Disconnect the PCM and CKP sensor. 3. Check for an open or a short to ground in the 58X reference circuit between the CKP sensor connector and the PCM harness connector. 4. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Reconnect the PCM and CKP sensor. 2. Connect a DVM to measure voltage on the 58X reference circuit at the PCM connector. 3. Observe the voltage while cranking the engine. Is the voltage near the specified value?	2.5 V	Go to Step 9	Go to Step 7
7	Check the connections at the CKP sensor and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 8
8	Replace the CKP sensor. IMPORTANT: The PCM must go through the Scan Tool's Tooth Error Correction (TEC) procedure after a CKP Sensor replacement. Refer to Tooth Error Correction (TEC) procedure. Is the action complete?	—	Verify repair	—

DTC P0337 – CKP Sensor Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
9	Check the connections at the PCM and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 10
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0341 CAMSHAFT POSITION (CMP) SENSOR CIRCUIT RANGE/PERFORMANCE



D06RX053

Circuit Description

The camshaft position (CMP) sensor signal is produced by the CMP sensor pulses when the engine is running and crankshaft position (CKP) sync pulses are also being received. The powertrain control module (PCM) uses the CMP signal pulses to initiate sequential fuel injection. The PCM constantly monitors the number of pulses on the CMP signal circuit and compares the number of CMP pulses to the number of 58X reference pulses received. If the PCM receives an incorrect number of pulses on the CMP reference circuit, Diagnostic Trouble Code P0341 will set and the PCM will initiate injector sequence without the CMP signal with a one in four chance that injector sequence is correct. The engine will continue to start and run normally, although the misfire diagnostic will be affected if a misfiring condition occurs. DTC P0341 is a type B code.

Conditions for Setting the DTC

- The engine is running (CMP reference pulses are being received).
- Above condition fails for 10 occurrences within 100 test samples (15.6 m/s).

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.

- The PCM will initiate injector sequence without the CMP signal with a one in four chance that injector sequence is correct.
- The PCM will store conditions which were present when the Diagnostic Trouble Code (DTC) was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code (DTC) P0341 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code (DTC) P0341 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- If a CKP Diagnostic Trouble Code (DTC) is also indicated, there may be a problem with the ground circuit because the CMP ground is spliced to the CKP ground wire.
- If a fuel injector Diagnostic Trouble Code (DTC) is also indicated, there may be a problem with the power supply to the CMP. The wire supplying CMP power is spliced to the wire supplying power to the fuel injectors. An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for the following conditions:

- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, disconnect the PCM, turn the ignition ON and observe a voltmeter connected to the CMP signal circuit at the

PCM harness connector while moving connectors and wiring harnesses related to the CMP sensor. A change in voltage will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code (DTC) to be set occurs. This may assist in diagnosing the condition.


DTC P0341 – CMP Sensor Circuit Range/Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" information for DTC P0341 until the DTC P0341 test runs. Does the Tech 2 indicate DTC P0341 failed this ignition cycle?	—	Go to Step 3	Refer to Diagnostic Aids
3	1. Monitor voltage on the CMP signal circuit while cranking the engine. Does the voltage toggle between the specified values?	0–4 V	Go to Step 4	Go to Step 7
4	Check for a poor connection of the CMP signal wire at the PCM terminal. Was a poor connection found?	—	Go to Step 5	Go to Step 6
5	Repair the damaged pin or terminal at the PCM.	—	Verify repair	—
6	Replace the PCM IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the repair complete?	—	—	Verify repair
7	1. Disconnect the CMP connector from the CMP Sensor. 2. Ignition ON. 3. At the CMP connector, use a Digital Voltmeter (DVM) to check the voltage between the voltage signal wire and sensor ground. Does the DVM indicate the specified value?	B+	Go to Step 12	Go to Step 8
8	1. Ignition ON. 2. Use a DVM to measure between the ground and the CMP positive connector. Does the DVM indicate the specified value?	B+	Go to Step 10	Go to Step 9

DTC P0341 – CMP Sensor Circuit Range/Performance (Cont'd)

Step	Action	Value(s)	Yes	No
9	Repair the open circuit. Is the repair complete?	—	Verify repair	—
10	1. Ignition ON. 2. Use a DVM to measure at the CMP connector between the battery + and the CMP ground wire. Does the DVM indicate the specified value?	B+	Go to Step 12	Go to Step 11
11	Repair the open ground wire. Is the repair complete?	—	Verify repair	—
12	Use an ohmmeter to check continuity of the signal wire between the CMP and the PCM. Was there an open circuit?	—	Go to Step 13	Go to Step 14
13	Repair the open signal wire. Is the action complete?	—	Verify repair	—
14	1. Ignition ON. 2. Check the signal wire for a short to ground or a short to voltage. Was a problem found?	—	Go to Step 15	Go to Step 16
15	Repair the signal circuit problem. Is the action complete?	—	Verify repair	—
16	Replace the CMP Sensor. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0342 CAMSHAFT POSITION (CMP) SENSOR CIRCUIT LOW INPUT



D06RX053

Circuit Description

The camshaft position (CMP) sensor signal is produced by the CMP sensor pulses when the engine is running and crankshaft position (CKP) sync pulses are also being received. The PCM uses the CMP signal pulses to initiate sequential fuel injection. The PCM constantly monitors the number of pulses on the CMP signal circuit and compares the number of CMP pulses to the number of 58X reference pulses received. If the PCM does not receive pulses on the CMP reference circuit, Diagnostic Trouble Code (DTC) P0342 will set and the PCM will initiate injector sequence without the CMP signal with a one in four chance that injector sequence is correct. The engine will continue to start and run normally, although the misfire diagnostic will be affected if a misfiring condition occurs. Diagnostic Trouble Code (DTC) P0342 is a type B code.

Conditions for Setting the DTC

- The engine is running.
- The CMP sensor signal is not received by the PCM once every 4 cylinders.
- The above condition occurs for 10 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.

- The PCM will initiate injector sequence without the CMP signal with a one in four chance that injector sequence is correct.
- The PCM will store conditions which were present when the Diagnostic Trouble Code (DTC) was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code (DTC) P0342 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code (DTC) P0342 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- If a CKP Diagnostic Trouble Code (DTC) is also indicated, there may be a problem with the ground circuit because the CMP ground is spliced to the CKP ground wire.
- If a fuel injector Diagnostic Trouble Code (DTC) is also indicated, there may be a problem with the power supply to the CMP. The wire supplying CMP power is spliced to the wire supplying power to the fuel injectors.

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for the following:

6E1-226 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, disconnect the PCM, turn the ignition ON and observe a voltmeter connected to the CMP signal circuit at the

PCM harness connector while moving connectors and wiring harnesses related to the CMP sensor. A change in voltage will indicate the location of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

- 2. Ensures that the fault is present.


DTC P0342 – Camshaft Position Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON. 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" information for DTC P0342 until the DTC P0342 test runs. Did the Tech 2 indicate DTC P0342 failed this ignition cycle?	—	Go to Step 3	Refer to Diagnostic Aids
3	1. Use a Digital Voltmeter (DVM) to monitor voltage on the CMP signal circuit while cranking the engine. Does the voltage toggle between the specified values?	0–4 V	Go to Step 4	Go to Step 7
4	Check for a poor connection of the CMP signal wire at the PCM terminal. Was a poor connection found?	—	Go to Step 5	Go to Step 6
5	Repair the damaged pin or terminal at the PCM.	—	Verify repair	—
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the repair complete?	—	Verify repair	—
7	1. Disconnect the CMP connector from the CMP Sensor. 2. Ignition ON. 3. At the CMP connector, check the voltage between the voltage signal wire and sensor ground. Does the DVM indicate the specified value?	B+	Go to Step 12	Go to Step 8
8	1. Ignition ON. 2. Use a DVM to measure between the ground and the CMP positive connector. Does the DVM indicate the specified value?	B+	Go to Step 10	Go to Step 9
9	Repair the open circuit. Is the repair complete?	—	Verify repair	—

DTC P0342 – Camshaft Position Sensor Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Ignition ON. 2. Use a DVM to measure at the CMP connector between the battery + and the CMP ground wire. Does the DVM indicate the specified value?	B+	Go to Step 12	Go to Step 11
11	Repair the open ground wire. Is the repair complete?	—	Verify repair	—
12	Use an ohmmeter to check continuity of the signal wire between the CMP and the PCM. Was there an open circuit?	—	Go to Step 13	Go to Step 14
13	Repair the open signal wire. Is the action complete?	—	Verify repair	—
14	1. Ignition ON. 2. Check the signal wire for a short to ground or a short to voltage. Was a problem found?	—	Go to Step 15	Go to Step 16
15	Repair the signal circuit problem. Is the action complete?	—	Verify repair	—
16	Replace the CMP Sensor. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0351 IGNITION COIL "A" PRIMARY/SECONDARY CIRCUIT MALFUNCTION



D06RX054

Circuit Description

The ignition control circuit provides a zero volt or a 5 volt signal to the ignition control module. The normal circuit voltage is zero volts. When the module receives the 5 volt signal from the powertrain control module (PCM), it provides a ground path for the B+ voltage supplied to the ignition primary coil. When the PCM turns off the 5 volts to the module, the module will remove the ground path of the ignition primary coils; causing the magnetic field produces a voltage in the secondary coils which fires the spark plug.

The circuit between the PCM and the ignition control module is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem in the ignition control circuit, it will set DTC P0351. DTC P0351 is a type A code.

Conditions for Setting the DTC

- Ignition ON.
- Output voltage is not equal to 5 volts when output is ON.
- Output voltage is not equal to 0 volt when output is OFF.
- Twenty test failures within 40 samples of continuous circuit monitoring.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0351 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0351 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at the PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.
- Damaged harness – Inspect the wiring harness for damage; Open circuits, shorts to ground, or shorts to Voltage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0351 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often

the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P0351 Ignition Coil "A" Primary/Secondary Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Check for a faulty connection or damaged terminals at the ignition control module. Was a problem found?	—	Verify Repair	Go to Step 3
3	Check for a faulty connection or damaged terminals at the PCM connector. Was a problem found?	—	Verify Repair	Go to Step 4
4	1. Ignition OFF. 2. Disconnect the PCM and the ignition control module. 3. Check the ignition control circuit for a short to voltage. Was a problem found?	—	Verify Repair	Go to Step 5
5	Check the ignition control circuit for a short to voltage. Was a problem found?	—	Verify Repair	Go to Step 6
6	Check for an open in the ignition control circuit. Was a problem found?	—	Verify Repair	Go to Step 7
7	Replace the ignition control module. Verify repair. Is there still a problem?	—	Go to Step 8	—
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the repair complete?	—	Verify Repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0352 IGNITION COIL "B" PRIMARY/SECONDARY CIRCUIT MALFUNCTION



D06RX054

Circuit Description

The ignition control circuit provides a zero volt or a 5 volt signal to the ignition control module. The normal circuit voltage is zero volts. When the module receives the 5 volt signal from the powertrain control module (PCM), it provides a ground path for the B+ voltage supplied to the ignition primary coil. When the PCM turns off the 5 volts to the module, the module will remove the ground path of the ignition primary coils; causing the magnetic field produces a voltage in the secondary coils which fires the spark plug.

The circuit between the PCM and the ignition control module is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem in the ignition control circuit, it will set DTC P0352. DTC P0352 is a type A code.

Conditions for Setting the DTC

- Ignition ON.
- Output voltage is not equal to 5 volts when output is ON.
- Output voltage is not equal to 0 volt when output is OFF.
- Twenty test failures within 40 samples of continuous circuit monitoring.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0352 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0352 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at the PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.
- Damaged harness – Inspect the wiring harness for damage; Open circuits, shorts to ground, or shorts to Voltage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0351 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often

the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P0352 Ignition Coil "B" Primary/Secondary Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Check for a faulty connection or damaged terminals at the ignition control module. Was a problem found?	—	Verify Repair	Go to Step 3
3	Check for a faulty connection or damaged terminals at the PCM connector. Was a problem found?	—	Verify Repair	Go to Step 4
4	1. Ignition OFF. 2. Disconnect the PCM and the ignition control module. 3. Check the ignition control circuit for a short to voltage. Was a problem found?	—	Verify Repair	Go to Step 5
5	Check the ignition control circuit for a short to voltage. Was a problem found?	—	Verify Repair	Go to Step 6
6	Check for an open in the ignition control circuit. Was a problem found?	—	Verify Repair	Go to Step 7
7	Replace the ignition control module. Verify repair. Is there still a problem?	—	Go to Step 8	—
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the repair complete?	—	Verify Repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0401 EXHAUST GAS RECIRCULATION (EGR) FLOW INSUFFICIENT DETECTED



D06RX055

Circuit Description

The powertrain control module (PCM) tests the exhaust gas recirculation (EGR) system during deceleration by momentarily commanding the EGR valve to open while monitoring the manifold absolute pressure (MAP) sensor signal. When the EGR valve is opened, the PCM monitors the change in MAP input signal. The PCM compares the MAP change to a RPM vs. BARO table. When the PCM interprets the change in MAP to be out of limits, the PCM will set DTC P0401. The number of test samples required to accomplish this may vary according to the severity of the detected flow error.

Normally, the PCM will only allow one EGR flow test sample to be taken during an ignition cycle. To aid in verifying a repair, the PCM allows twelve test samples during the first ignition cycle following a Tech 2 "Clear Info" or a battery disconnect. Between nine and twelve samples should be sufficient for the PCM to determine adequate EGR flow and pass the EGR test. DTC P0401 is a type A code.

Conditions for Setting the DTC

- No TP sensor, VSS, EVAP Purge, IAC, IAT sensor, MAP sensor, EGR Pintle Position sensor, ECT sensor, misfire DTCs set.
- Barometric pressure is above 72 kPa.

- Engine coolant temperature is greater than 60°C (140°F).
- System voltage is between 11.5 and 16 volts.
- Vehicle speed is greater than 23 km/h (14 mph).
- IAC position is steady, changing less than 5 counts.
- A/C clutch status is unchanged.

Start Test

- TP angle is less than 0.8%.
- EGR duty cycle is less than 1%.
- MAP is steady, changing less than 1 kPa.
- Engine speed is between 1200 RPM and 2000 RPM.
- Compensated MAP between 10.3 kPa and 49.8 kPa.

Run Test

- Delta MAP is recorded during valve open conditions.
 - EGR valve is ramped over a time interval.
- Run Test will be aborted if any of the following are true:
- Vehicle speed changes by greater than 16 km/h (10mph).
 - Engine RPM changes by greater than 100 rpm.
 - EGR is opened less than 95% of the commanded amount.

During the Start Test and the Run Test, the EGR is closed then opened. The associated change in MAP is compared with the PCM's expected change value. If the

difference between the two values exceeds the PCM's internal limit, a Diagnostic Trouble Code P0401 will set. DTC P0401 is a type A code.

NOTE: Several deceleration cycles will be necessary to run a sufficient number of EGR flow tests to determine a "pass" or "fail" condition.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate the first time the fault is detected.
- A history Diagnostic Trouble Code is stored.
- A history Diagnostic Trouble Code will clear after 40 consecutive warm up cycles without a fault.
- The MIL will turn OFF after three consecutive ignition cycles in which the diagnostic runs without a fault.

Conditions for Clearing the DTC

- The MIL will turn OFF after three consecutive ignition cycles in which the diagnostic runs without a fault.
- A history Diagnostic Trouble Code will clear after 40 consecutive warm up cycles without a fault.
- Diagnostic Trouble Codes can be cleared by using the Tech 2.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Actual EGR Position display on the Tech 2 while moving connectors and wiring harnesses related to the EGR valve. A change in the display will indicate the location of the fault.
- Ensure EGR valve is correctly mounted. See On-Vehicle Service.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

NOTE: If the EGR valve shows signs of excessive heat, check the exhaust system for blockage (possibly a plugged catalytic converter) using the "Restricted Exhaust System Check."

DTC P0401 – Exhaust Gas Recirculation Flow Insufficient Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Start the engine. 2. Monitor the MAP signal with a Tech 2 while idling. 3. While idling, depress the accelerator pedal about halfway down and immediately let the engine return to idle. Did the MAP value on the Tech 2 show an immediate large change?	—	Go to Step 4	Go to Step 3
3	Replace the MAP sensor.	—	Verify repair	—
4	1. Inspect the exhaust system for modification of original installed parts or leaks. 2. If a problem was found, repair exhaust system as necessary. Was a condition present that required repair?	—	Go to Step 7	Go to Step 5
5	1. Remove the EGR valve. 2. Visually and physically inspect the pintle, valve passages and the adapter for excessive deposits or any kind of a restriction. 3. If a problem is found, clean or replace EGR system components as necessary. Was a condition present that required repair?	—	Go to Step 7	Go to Step 6
6	1. Remove the EGR inlet and outlet pipes from the exhaust manifold and the intake manifold. 2. Inspect the manifold EGR ports and the EGR inlet and outlet pipes for a blockage caused by excessive deposits or other damage. 3. If a problem is found, correct the condition as necessary. Was a condition present that required repair?	—	Go to Step 7	Refer to Diagnostic Aids
7	1. Review and record the Tech 2 Failure Records data. 2. Clear Diagnostic Trouble Code and monitor the Tech 2 System Info Screen while operating the vehicle as specified in "Diagnostic Aids." 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0401 until the Diagnostic Trouble Code P0401 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0401 failed this ignition?	—	—	Repair complete

DIAGNOSTIC TROUBLE CODE (DTC) P0402 EXHAUST GAS RECIRCULATION (EGR) EXCESSIVE FLOW DETECTED



D06RX055

Circuit Description

The Powertrain Control Module (PCM) closes the Exhaust Gas Recirculation (EGR) system on engine start-up to test for excessive (any) flow. If the PCM determines that EGR flow occurred on start-up, in two consecutive trips, then DTC P0402 will set. DTC P0402 is a type B code.

Conditions for Setting the DTC

- Intake Air Temperature (IAT) is above 5°C (41°F).
 - Engine RPM is less than 500 RPM.
 - EGR Pintle Position if greater than 55 counts.
- The above mentioned conditions must be met for 0.6 seconds during engine start-up on two consecutive trips.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Actual EGR Position display on the Tech 2 while moving connectors and wiring harnesses related to the EGR valve. A change in the display will indicate the location of the fault.
- Ensure EGR valve is correctly mounted. See On-Vehicle Service.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

NOTE: If the EGR valve shows signs of excessive heat, check the exhaust system for blockage (possible a plugged catalytic converter) using the "Restricted Exhaust System Check."

DTC P0402 EGR Excessive Flow Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Review and record the Tech 2 Failure Records data. 2. Clear Diagnostic Trouble Code and monitor the Tech 2 System Info Screen while operating the vehicle as specified in "Diagnostic Aids." 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P0401 until the Diagnostic Trouble Code P0401 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P0401 failed this ignition?	—	Go to Diagnostic Aids	Go to Step 3
3	1. Inspect the exhaust system for modification of original installed parts or leaks. 2. If a problem was found, repair exhaust system as necessary. Was a condition present that required repair?	—	Verify repair	Go to Step 4
4	1. Remove the EGR valve. 2. Visually and physically inspect the pintle, valve passages and the adapter for excessive deposits or any kind of a restriction. 3. If a problem if found, clean or replace EGR system components as necessary. Was a condition present that required repair?	—	Verify repair	Go to Step 5
5	1. Remove the EGR inlet and outlet pipes from the exhaust manifold and the intake manifold. 2. Inspect the manifold EGR ports and the EGR inlet and outlet pipes for a blockage caused by excessive deposits or other damage. 3. If a problem is found, correct the condition as necessary. Was a condition present that required repair?	—	Verify repair	Refer to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P0404 EXHAUST GAS RECIRCULATION (EGR) CIRCUIT RANGE/PERFORMANCE



D06RX055

Circuit Description

An Exhaust Gas Recirculation (EGR) system is used to lower Oxides of Nitrogen (NOx) emission levels caused by high combustion temperatures. It accomplishes this by feeding small amounts of exhaust gases back into the combustion chamber. When the air/fuel mixture is diluted with the exhaust gases, combustion temperatures are reduced.

A linear EGR valve is used on this system. The linear EGR valve is designed to accurately supply exhaust gases to the engine without the use of intake manifold vacuum. The valve controls exhaust flow going into the intake manifold from the exhaust manifold through an orifice with a PCM controlled pintle. The PCM controls the pintle position using inputs from the Throttle Position (TP) and Manifold Absolute Pressure (MAP) sensors. The PCM then commands the EGR valve to operate when necessary by controlling an ignition signal through the PCM. This can be monitored on a Tech 2 as the Desired EGR Position.

The PCM monitors the results of its command through a feedback signal. By sending a 5 volt reference and a ground to the EGR valve, a voltage signal representing the EGR valve pintle position is sent to the PCM. This feedback signal can also be monitored on a Tech 2 and is the actual position of the EGR pintle. The Actual EGR position should always be near the commanded or Desired EGR Position.

If the PCM detects a large difference between the desired EGR position and actual EGR position, then Diagnostic Trouble Code P0404 will set. DTC P0404 is a type B code.

Conditions for Setting the DTC

- IAT is greater than 5°C (41°F).
- EGR commanded ON (Desired EGR Position is greater than 0%).
- Actual EGR Position differs from Desired EGR Position by more than 15% for 5 seconds.

Action Taken When the DTC Sets

- Malfunction Indicator Lamp (MIL) will illuminate the second time the fault is detected.
- The PCM will record operating conditions at the time the diagnostic fails.
- A history Diagnostic Trouble Code is stored.
- The EGR Valve is disabled.

Conditions for Clearing the MIL/DTC

- The MIL will turn OFF after three consecutive ignition cycles in which the diagnostic runs without a fault.
- Diagnostic Trouble Code(s) can be cleared by using a Tech 2.

Diagnostic Aids

Due to the moisture associated with exhaust systems, the EGR valve may freeze and stick in colder weather at times. After the vehicle is brought into a warm shop for repairs, the valve warms and the problem disappears. By watching the Actual EGR and Desired EGR Positions on a cold vehicle with a Tech 2, the fault can be verified easily. Check the freeze frame data to determine if the Diagnostic Trouble Code was set when the vehicle was cold by viewing the Engine Coolant Temperature (ECT).

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 if applicable. This created an electronic copy of the data taken when the fault occurred. The information is then stored on the Tech 2 for later reference.
2. Commanding the EGR valve open determines whether the EGR system can control the EGR valve accurately and if the fault is present.
3. When the EGR valve electrical connector is disconnected, the Tech 2 should display the Actual EGR Position as 0%. If it does not, the fault lies either in the EGR signal circuit or the PCM.
4. A test light, when connected to ground, will glow dimly when the EGR valve is commanded to 25%, and brighter as the EGR valve is commanded to 100%. If the test light flashes, check the sensor ground for an open.
5. An open or poor connection condition may have caused this Diagnostic Trouble Code to set. Be sure to check the terminals for being backed out, improperly formed or damaged, and for poor tension.
7. The test light will have glowed brightly in the previous step if the EGR control circuit was shorted to B+ and the Actual EGR Position on the Tech 2 will display 100%. A test light that did not illuminate, indicates that the circuit may be open or shorted to ground.
9. If the EGR valve 5 volt reference is shorted to voltage, the DVM will read battery voltage and additional Diagnostic Trouble Codes may be set and engine performance will be poor.
12. The replacement PCM must be reprogrammed and the Tooth Error Correction (TEC) procedure must be performed. Refer to the latest procedures for PCM reprogramming and Powertrain Control Module for the Tooth Error Correction (TEC) Procedure.
13. Although the circuitry acted correctly when checked, a problem may still lie within the terminals which would not show up in probe type testing. Be sure to check the terminals for being backed out, improperly formed or damaged, and for poor tension.
17. All circuits to the EGR valve are OK at this point. The fault lies internally in the EGR valve and therefore must be replaced. Be sure all gasket material is removed from the EGR mounting surface. Even a small amount of material may cause a Diagnostic Trouble Code P0401 to set. For on vehicle service of the EGR Valve, refer to EGR Valve.
18. Check the terminals for being backed out, improperly formed or damaged, and for poor tension.
19. Clearing the Diagnostic Trouble Codes is a very important step for this diagnostic. The clearing function allows the EGR valve to relearn a new pintle position as the old position was inaccurate due to the malfunction that caused the Diagnostic Trouble Code. The Diagnostic Trouble Code must be cleared with the ignition switch ON, with the engine OFF or when the engine is idling. If the PCM sees a EGR command, the new pintle position will not be learned.


DTC P0404 EGR Circuit Range/Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Turn the ignition switch ON, with the engine OFF. 2. Install a Tech 2. 3. Command the EGR valve to the specified values. Does the Actual EGR Position follow the Desired EGR Position?	25%, 50%, 75%, 100%	Go to Step 19	Go to Step 3
3	1. Turn the ignition switch ON, with the engine OFF. 2. Disconnect the EGR valve electrical connector. 3. With a test light connected to B+, probe the ground circuit to the EGR valve. Does the light illuminate?	—	Go to Step 4	Go to Step 5
4	1. Connect the test light to ground. 2. Probe the EGR control circuit to the EGR valve. 3. Command the EGR valve to the specified values using a Tech 2. As the command is raised, does the test light glow brighter, flash or maintain a steady glow?	25%, 50%, 75%, 100%	Go to Step 6	Go to Step 7
5	Repair the open or poor connection in the EGR ground circuit. Is the action complete?	—	Go to Step 19	—
6	With the test light still connected to ground, probe the signal circuit. Is the action complete?	—	Go to Step 8	Go to Step 9
7	With the test light still connected to ground, again probe the control circuit without commanding the EGR valve with the Tech 2. Does the test light illuminate?	—	Go to Step 10	Go to Step 11
8	Check the signal circuit for a short to voltage and repair as necessary. Was a repair necessary?	—	Go to Step 19	Go to Step 12
9	With a Digital Voltmeter (DVM) connected to ground, probe the 5 V reference circuit. Is the voltage measured near the specified value?	5 V	Go to Step 13	Go to Step 14
10	Check the control circuit for a short to voltage and repair as necessary. Was a repair necessary?	—	Go to Step 19	Go to Step 12
11	Connect the test light to B+ and again probe the control circuit. Does the light illuminate?	—	Go to Step 15	Go to Step 16

DTC P0404 EGR Circuit Range/Performance (Cont'd)

Step	Action	Value(s)	Yes	No
12	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Go to Step 19	—
13	<p>Check the EGR ground circuit for a poor connection or proper terminal tension at the PCM and repair as necessary.</p> <p>Was a repair necessary?</p>	—	Go to Step 19	Go to Step 17
14	<p>Check the 5 V reference circuit for a short to voltage and repair as necessary.</p> <p>Was a repair necessary?</p>	—	Go to Step 19	Go to Step 12
15	<p>Check the control circuit for a short to ground and repair as necessary?</p> <p>Was a repair necessary?</p>	—	Go to Step 19	Go to Step 12
16	<p>Check the control circuit for an open or poor connection at the EGR valve electrical connector and repair as necessary.</p> <p>Was a repair necessary?</p>	—	Go to Step 19	Go to Step 18
17	<p>Replace the EGR valve.</p> <p>Is the action complete?</p>	—	Go to Step 19	—
18	<p>Check the PCM electrical connector for a poor connection and repair as necessary.</p> <p>Was a repair necessary?</p>	—	Go to Step 19	Go to Step 12
19	<p>1. Using the Tech 2, clear Diagnostic Trouble Codes.</p> <p>2. Start engine and idle at normal operating temperature.</p> <p>3. Operate vehicle within the conditions for setting this Diagnostic Trouble Code as specified in the supporting text.</p> <p>Does the Tech 2 indicate that this diagnostic "Ran and Passed?"</p>	—	Verify repair	Go to Step 2

DIAGNOSTIC TROUBLE CODE (DTC) P0405 EXHAUST GAS RECIRCULATION (EGR) SENSOR CIRCUIT LOW



Circuit Description

An Exhaust Gas Recirculation (EGR) system is used to lower Oxides of Nitrogen (NOx) emission levels caused by high combustion temperatures. It accomplishes this by feeding small amounts of exhaust gases back into the combustion chamber. When the air/fuel mixture is diluted with the exhaust gases, combustion temperatures are reduced.

A linear EGR valve is used on this system. The linear EGR valve is designed to accurately supply exhaust gases to the engine without the use of intake manifold vacuum. The valve controls exhaust flow going into the intake manifold from the exhaust manifold through an orifice with a PCM controlled pintle. The PCM controls the pintle position using inputs from the Throttle Position (TP) and Manifold Absolute Pressure (MAP) sensors. The PCM then commands the EGR valve to operate when necessary by controlling an ignition signal through the PCM. This can be monitored on a Tech 2 as the Desired EGR Position.

The PCM monitors the results of its command through a feedback signal. By sending a 5 volt reference and a ground to the EGR valve, a voltage signal representing the EGR valve pintle position is sent to the PCM. This feedback signal can also be monitored on a Tech 2 and is the actual position of the EGR pintle. The Actual EGR Position should always be near the commanded or Desired EGR Position.

If the PCM detects a continuous short to ground in the signal circuit or the sensor, then Diagnostic Trouble Code P0405 will set. DTC P0405 is a type A code.

Conditions for Setting the DTC

- IAT is greater than 5°C (41°F).
- The PCM sees less than 0.10 voltage from the EGR valve sensor.
- A malfunction is present for 10 seconds.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate the first time the malfunction is detected.
- The PCM will record operating conditions at the time the diagnostic fails.
- A history Diagnostic Trouble Code is stored.
- The EGR Valve is disabled.

Conditions for Clearing the MIL/DTC

- The MIL will turn OFF after three consecutive ignition cycles in which the diagnostic runs without a fault.
- A history Diagnostic Trouble Code will clear after 40 consecutive warm up cycles without a fault.
- Diagnostic Trouble Codes can be cleared by using the Tech 2.

Diagnostic Aids

Due to the moisture associated with exhaust systems, the EGR valve may freeze and stick in colder weather at times. After the vehicle is brought into a warm shop for repairs, the valve warms and the problem disappears. By watching the Actual EGR and Desired EGR Positions on a cold vehicle with a Tech 2, the fault can be verified easily. Check the freeze frame data to determine if the Diagnostic Trouble Code set when the vehicle was cold by viewing the Engine Coolant Temperature (EGR).

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 if applicable. This creates an electronic copy of the data taken when the fault occurred. The information is then stored on the Tech 2 for later reference.
2. Commanding the EGR valve open determines whether the EGR system can control the EGR valve accurately and if the fault is present.
3. If the EGR valve 5 volt reference is shorted to ground, the DVM will read no voltage and an additional Diagnostic Trouble Code will be set and engine performance will be poor. When this circuit is open, only a Diagnostic Trouble Code P0405 will be set.
4. Jumping the 5 volt reference circuit to the signal circuit checks the signal circuit and PCM. The Tech 2 should display the Actual EGR Position as 100% if the signal circuit and PCM are OK.
6. Although the PCM and circuitry acted correctly in the previous step, a problem may still lie within the terminals which would not show up in probe type testing. Check the terminals for being backed out, improperly formed or damaged, and for poor tension.
10. All circuits to the EGR valve are OK at this point. The fault lies internally in the EGR valve and therefore must be replaced. Be sure all gasket material is removed from the EGR mounting surface. Even a small amount of material may cause a Diagnostic Trouble Code P0405 to set. Refer the EGR Valve for on vehicle service of the EGR valve.
13. The replacement PCM must be reprogrammed and the crankshaft position system variation procedure must be performed. Refer to the latest procedures for PCM reprogramming and Powertrain Control Module for the Tooth Error Correction Variation Procedure.
14. Check the terminals for being backed out, improperly formed or damaged, and for poor tension.


DTC P0405 – EGR Sensor Circuit Low

Step	Action	Value(s)	Yes	No
1	Was the Powertrain On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Turn the ignition switch ON, with the engine OFF. 2. Install a Tech 2. 3. Command the EGR valve to the specified values. Does the Actual EGR Position follow the Desired EGR Position?	25%, 50%, 75%, 100%	Go to Step 15	Go to Step 3
3	1. Turn the ignition switch ON, with the engine OFF. 2. Disconnect the EGR valve electrical connector. 3. With a Digital Voltmeter (DVM) connected to ground, probe the 5 V reference circuit to the EGR valve. Does the DVM read near the specified value?	5 V	Go to Step 4	Go to Step 5
4	Jumper the EGR valve 5 volt reference circuit to the signal circuit. Does the Actual EGR Position display the specified value?	100%	Go to Step 6	Go to Step 7
5	1. Connect the test light to B+. 2. Probe the 5 V reference circuit to the EGR valve. Does the test light illuminate?	—	Go to Step 8	Go to Step 9

DTC P0405 – EGR Sensor Circuit Low (Cont'd)

Step	Action	Value(s)	Yes	No
6	Check the 5 V reference and signal circuit's for a poor connection or proper terminal tension and repair as necessary. Was a repair necessary?	—	Go to Step 15	Go to Step 10
7	1. Connect the test light to B+. 2. Probe the signal circuit to the EGR valve. Does the light illuminate?	—	Go to Step 11	Go to Step 12
8	Check for a short to ground in the EGR valve 5 V reference circuit and repair as necessary. Was a repair necessary?	—	Go to Step 15	Go to Step 13
9	Check for an open in the EGR valve 5 V reference circuit and repair as necessary. Was a repair necessary?	—	Go to Step 15	Go to Step 14
10	Replace the EGR valve. Is the action complete?	—	Go to Step 15	—
11	Check for a short to ground in the EGR valve signal circuit and repair as necessary. Was a repair necessary?	—	Go to Step 15	Go to Step 13
12	Check for an open in the EGR valve signal circuit and repair as necessary. Was a repair necessary?	—	Go to Step 15	Go to Step 14
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to Step 15	—
14	Check the affected circuit for a poor connection or proper terminal at the PCM and repair as necessary. Was a repair necessary?	—	Go to Step 15	Go to Step 13
15	1. Using the Tech 2, clear the Diagnostic Trouble Codes. 2. Start engine and idle at normal operating temperature. 3. Operate vehicle within the conditions for setting this Diagnostic Trouble Code as specified in the supporting text. Does the Tech 2 indicate that this diagnostic ran and passed?	—	Verify repair	Go to Step 2

DIAGNOSTIC TROUBLE CODE (DTC) P0406 EXHAUST GAS RECIRCULATION (EGR) SENSOR CIRCUIT HIGH



D06RX055

Circuit Description

An Exhaust Gas Recirculation (EGR) system is used to lower Oxides of Nitrogen (NOx) emission levels caused by high combustion temperatures. It accomplishes this by feeding small amounts of exhaust gases back into the combustion chamber. When the air/fuel mixture is diluted with the exhaust gases, combustion temperatures are reduced.

A linear EGR valve is used on this system. The linear EGR valve is designed to accurately supply exhaust gases to the engine without the use of intake manifold vacuum. The valve controls exhaust flow going into the intake manifold from the exhaust manifold through an orifice with a PCM controlled pintle. The PCM controls the pintle position using inputs from the Throttle Position (TP) and Manifold Absolute Pressure (MAP) sensors. The PCM then commands the EGR valve to operate when necessary by controlling an ignition signal through the PCM. This can be monitored on a Tech 2 as the Desired EGR Position.

The PCM monitors the results of its command through a feedback signal. By sending a 5 volt reference and a ground to the EGR valve, a voltage signal representing the EGR valve pintle position is sent to the PCM. This feedback signal can also be monitored on a Tech 2 and is the actual position of the EGR pintle. The Actual EGR Position should always be near the commanded or Desired EGR Position.

If the PCM detects a continuous short to ground in the signal circuit or the sensor, then DTC P0406 will set. Diagnostic Trouble Code P0406 is a type A code.

Conditions for Setting the DTC

- IAT is greater than 5°C (41°F).
- The PCM sees less than 0.10 voltage from the EGR valve sensor.
- A malfunction is present for 10 seconds.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate.
- The PCM will record operating conditions at the time the diagnostic fails.
- A history Diagnostic Trouble Code is stored.
- The EGR Valve is disabled.

Conditions for Clearing the MIL/DTC

- The MIL will turn OFF after three consecutive ignition cycles in which the diagnostic runs without a fault.
- A history Diagnostic Trouble Code will clear after 40 consecutive warm-up cycles without a fault.
- Diagnostic Trouble Code(s) can be cleared by using the Tech 2.

Diagnostic Aids

Due to the moisture associated with exhaust systems, the EGR valve may freeze and stick in colder weather at

times. After the vehicle is brought into a warm shop for repairs, the valve warms and the problem disappears. By watching the Actual EGR and Desired EGR Positions on a cold vehicle with a Tech 2, the fault can be verified easily. Check the freeze frame data to determine if the Diagnostic Trouble Code set when the vehicle was cold by viewing the Engine Coolant Temperature (ECT).


DTC P0406 EGR Sensor Circuit High

Step	Action	Value(s)	Yes	No
1	Was the Powertrain "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Turn the ignition switch ON, with the engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTC's. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0406. Does the Tech 2 indicate DTC P0406 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Disconnect the Linear Exhaust Gas Recirculation (EGR) Valve from the wiring harness. 3. Ignition ON, Engine OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the ignition feed circuit at the Linear Exhaust Gas Recirculation (EGR) Valve wiring harness connector. Does the DVM read the following value?	12 Volts	Go to Step 6	Go to Step 4
4	Check the ignition feed circuit, between the EGR sensor and the "Engine IG." fuse, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	—
5	Using a DVM, check the resistance of the EGR solenoid. Does the DVM read the following value?	less than 5 Ω	Go to Step 6	Go to Step 14
6	Check the EGR solenoid valve Low circuit, between the EGR sensor and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 15
7	1. Ignition OFF. 2. Disconnect the Linear Gas Recirculation (EGR) Valve from the wiring harness. 3. Ignition ON, Engine OFF. 4. Observe the EGR value on the Tech 2. Does the Tech 2 display the following value(s)?	0 Volts 0%	Go to Step 9	Go to Step 8
8	Check the EGR position feedback circuit, between the EGR sensor and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 15

DTC P0406 EGR Sensor Circuit High (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Ignition ON, Engine OFF. 2. Using a Digital Voltmeter (DVM), check for voltage on the 5 volt Reference signal circuit at the Linear Exhaust Gas Recirculation (EGR) Valve wiring harness connector. Does the DVM read the following value?	about 5 volts	Go to Step 11	Go to Step 10
10	Check the 5 volt Reference signal circuit, between the EGR and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 11
11	1. Ignition OFF. 2. Place a DVM between the 5 volt Reference signal circuit and the 5 volt signal return (ground) circuit at the EGR wiring harness connector. 3. Ignition ON, Engine OFF. Does the DVM read the following value?	about 5 volts	Go to Step 13	Go to Step 12
12	Check the 5 volt signal return (ground) circuit, between the EGR and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 15
13	1. Ignition OFF. 2. Place a fused jumper wire between the 5 volt Reference signal circuit and the EGR valve position feedback circuit at the EGR wiring harness connector. 3. Ignition ON, Engine OFF. 4. Observe the EGR value on the Tech 2. Does the Tech 2 display the following value(s)?	5 volts 100%	Go to Step 14	Go to Step 15
14	Replace the Linear Exhaust Gas Recirculation (EGR) Valve. Verify Repair.	—	—	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0420 CATALYST SYSTEM EFFICIENCY BELOW THRESHOLD



D06RX048

Circuit Description

The PCM uses the Bank 1 HO₂S 1 and the Bank 1 HO₂S 2 heated oxygen sensors. The Bank 1 HO₂S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 1 HO₂S 1 signal will be far more active than that produced by the Bank 1 HO₂S 2 sensor. If the PCM detects a level of Bank 1 HO₂S 2 activity that indicates the catalyst is no longer operating efficiently, Diagnostic Trouble Code P0420 will be set. DTC P0420 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- The engine is operating in "Closed Loop".
- Engine air load is below 99.6%.
- Engine coolant temperature is above 60°C (140°F).
- Calculated air flow is between 10 g/second and 32 g/second.
- Change in engine load is below 3.91%.
- Engine speed is below 3500 RPM.
- Vehicle speed is between 24 km/h and 123 km/h (15 mph and 75 mph).
- Catalyst temperature is above 399°C (750°F).

- The PCM determines that the catalyst's oxygen storage capacity is below the acceptable threshold.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0420 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0420 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive and open circuits. If the harness appears to be OK, observe the display on the Tech 2 while moving

connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

○ Bank 1 HO2S 1/Bank 1 HO2S 2 Activity Test:

Ensure that the engine is fully warmed up.

Using a Tech 2, monitor Bank 1 HO2S 1 and Bank 1 HO2S 2 displays in "Neutral" while using the Tech 2 IAC RPM control function to maintain a mass air flow of 10 g/second. Compare the amount of activity (frequency and amplitude) on Bank 1 HO2S 1 to the activity on Bank 1 HO2S 2 over a 30 second period.

If the amount of activity on Bank 1 HO2S 2 is nearly as great as the activity on Bank 1 HO2S 1, a problem exists. Use the Diagnostic Trouble Code P0420 diagnostic chart. If much less activity is noted on Bank 1 HO2S 2, the system is functioning properly.

The "TWC Monitor Test Counter" displayed on the Tech 2 may be used to monitor the progress of the TWC diagnostic. To complete the TWC diagnostic with a good catalyst, the counter must be allowed to increment to 49 samples and roll over to 0 at least twice. A failed catalyst will require three or more 50-sample tests to report a failure.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

7. Difficulty completing the Diagnostic Trouble Code P0420 "Status This Ign." test may be encountered in areas where test conditions cannot be maintained easily, especially in urban areas. To minimize the amount of driving required to complete the Diagnostic Trouble Code P0420 "Status This Ign." test, use the following procedure:


- Allow the engine to warm completely.
- With the vehicle in "Neutral," monitor the calculated air flow on the Tech 2 and hold part throttle to maintain a reading of over 12 g/second for at least 2 minutes. This will achieve the "warm catalyst" required for running the test.
- Operate the vehicle in second or third gear to remain in the Diagnostic Trouble Code P0420 test conditions described in "Conditions for Setting the Diagnostic Trouble Code" as much as possible. If you must stop the vehicle, maintain the "warm catalyst" criteria as follows:
 - Place the vehicle in "Neutral."
 - Hold part throttle to maintain a calculated air flow reading of over 15 g/second for the duration of the stop.

The "TWC Monitor Test Counter" displayed on the Tech 2 may be used to monitor the progress of the TWC diagnostic. To complete the TWC diagnostic with a good catalyst, the counter must be allowed to increment to 49 samples and roll over to 0 at least twice.

DTC P0420 – Catalyst System Efficiency Below Threshold

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any other O2 Sensor Diagnostic Trouble Codes set?	—	Diagnose other Diagnostic Trouble Code(s) first	Go to Step 3
3	1. Visually and physically inspect the three-way catalytic converter for damage. Check for the following: <ul style="list-style-type: none"> <input type="radio"/> dents <input type="radio"/> severe discoloration caused by excessive temperatures <input type="radio"/> holes <input type="radio"/> internal rattle caused by damaged catalyst 2. Also, ensure that the three-way catalytic converter is a proper original equipment manufacturer part. Did your inspection reveal a problem?	—	Go to Step 6	Go to Step 4
4	1. Visually and physically inspect the exhaust system between the three-way catalytic converter and the rear converter flange for leaks, damage, and loose or missing hardware. 2. If a problem is found, repair as necessary. Did your inspection reveal a problem?	—	Go to Step 7 to verify repair	Go to Step 5
5	1. Visually and physically inspect the Bank 1 HO2S 2. 2. Ensure that the Bank 1 HO2S 2 is secure and that the pigtail and wiring harness is not contacting the exhaust pipe or is not otherwise damaged. 3. If a problem is found, repair as necessary. Did your inspection reveal a problem?	—	Go to Step 7 to verify repair	Go to Step 6
6	Replace the three-way catalytic converter. NOTE: Check for conditions which may cause catalyst damage (refer to Diagnostic Aids). Is the action complete?	—	Go to Step 7 to verify repair	—
7	1. Review and record the Tech 2 Failure Records data. 2. Clear Diagnostic Trouble Code P0420. 3. Start the engine and allow it to warm up until the engine coolant temperature monitored on the Tech 2 is above the specified value. 4. Run the engine to maintain the specified mass air flow range for at least 2 minutes. 5. Operate the vehicle to maintain Diagnostic Trouble Code P0420 test conditions (for detailed instructions, refer to Diagnostic Trouble Code Test Description in Diagnostic Support). 6. Using a Tech 2, monitor "Diagnostic Trouble Code" info for DTC P0420 until the DTC P0420 test runs. 7. Note the test result. Does the Tech 2 indicate DTC P0420 passed this ignition?	Engine coolant temp: greater than 60°C (140°F) Calculated air flow: between 7 g/second and 41 g/second	Verify repair	Go to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P0440 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM MALFUNCTION



D06RX056

Circuit Description

The evaporative system includes the following components:

- Fuel tank
- EVAP vent solenoid
- Fuel tank pressure sensor
- Fuel pipes and hoses
- Fuel vapor lines
- Fuel cap
- EVAP canister
- Purge lines
- EVAP canister purge valve
- EVAP service port

The evaporative emission system is checked by applying vacuum to the EVAP system and monitoring for a vacuum decay. The PCM monitors the vacuum level through the fuel tank pressure sensor signal.

At an appropriate time, the EVAP canister purge valve and the EVAP vent solenoid are turned ON, allowing the engine to draw a small vacuum on the entire evaporative emission system. After the desired vacuum level has been achieved, the EVAP canister purge valve is turned OFF, sealing the system. If a sufficient vacuum level cannot be achieved, a large leak is indicated. This can be caused by the following conditions:

- Missing or faulty fuel cap
- Disconnected or faulty fuel tank pressure sensor

- Disconnected, damaged, pinched, or blocked fuel tank vapor line
- Disconnected or faulty EVAP canister purge valve
- Disconnected or faulty EVAP vent solenoid
- Open ignition feed circuit to the EVAP vent or purge solenoid

- Damaged EVAP canister

- Leaking fuel sender assembly O-ring

- Leaking fuel tank or fuel filler neck

Any of the above conditions can set a Diagnostic Trouble Code P0440. DTC P0440 is a type A code.

Conditions for Setting the DTC

- Diagnostic Trouble Codes P0106, P0107, P0108, P0112, P0113, P0117, P0118, P0121, P0122, P0123, P0125, P0131, P0132, P0133, P0134 and P1133 not set.
- The BARO is greater than 72.3 kPa.
- IAT and ECT are between 3.5°C (38.5°F) and 90.5°F at engine start up.
- The difference between IAT and ECT at start up is less than 6.75°C (12.2°F).
- The Vehicle Speed is less than 98 km/h (60 mph).
- The Fuel Tank Level Sensor reads between 10% and 90%.
- Fuel Level counts vary by less than 15 counts in a 0.125 second time frame.
- Maximum Engine Run time is at least 540 seconds.

- The difference between the actual Fuel Tank Pressure and the expected Fuel Tank Pressure is less than the PCM's expectations.

The above conditions are met, and the following condition is met once:

- The EVAP system is unable to achieve or maintain vacuum during the diagnostic test. The amount of decay will vary with the fuel level.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate.
- The PCM will disable the EVAP purge valve solenoid.
- The PCM will record operating conditions at the time the diagnostic fails. The Freeze Frame and Failure Records buffers will store this information.
- A history Diagnostic Trouble Code is stored.

Conditions for Clearing the MIL/DTC

- The MIL will turn OFF after one ignition cycle in which the diagnostic runs without a fault.
- Freeze Frame information and the history Diagnostic Trouble Code will clear after one ignition cycle in which the diagnostic runs without a fault.
- Diagnostic Trouble Codes can be cleared with the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- A missing, loose, or damaged fuel cap.
- Missing or damaged O-rings at the EVAP canister fuel vapor fittings and the purge line fittings.
- A cracked EVAP canister.
- Damaged or disconnected source vacuum line. EVAP purge line, vent hose or fuel tank vapor line.
- The Fuel Pressure Sensor shares a 5 Volt reference with the MAP sensor and TP sensor.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.

- The Fuel Pressure Sensor share a ground with the MAP sensor and the TP sensor.
- A poor connection at the PCM: Inspect the harness connectors for backed out terminals, improper mating, broken locks, improperly formed or damaged terminals.
- Damaged harness: Inspect the wiring harness to the EVAP vent solenoid, the EVAP purge solenoid, and the fuel tank pressure sensor for shorts to ground, shorts to battery positive and open circuits.
- A kinked, pinched or plugged vacuum source, EVAP purge, or fuel tank vapor line. Verify that the lines are not restricted.

Check for charcoal particles. Refer to Carbon Particles Removal from EVAP System before starting repairs.

Reviewing the Fail Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 if applicable. This creates an electronic copy of the data taken when the malfunction occurred. The information is then stored on the Tech 2 for later reference.
4. If a vent solenoid or EVAP canister purge valve electrical malfunction is present, the purge system will not operate correctly. Repairing the electrical malfunction will very likely correct the condition that set Diagnostic Trouble Code P0440.
5. Check the fuel tank pressure sensor at ambient pressure.
7. Forces the fuel tank pressure sensor to re-zero.
8. Determines whether or not the EVAP system is sealed sufficiently to be pressurized. If not, the large leak must be located and corrected before continuing with diagnosis.
9. Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.
12. Ensures that sufficient source vacuum is present at the EVAP canister purge valve.
13. Check for a stuck closed EVAP canister purge valve.
20. Insures proper system integrity.

DTC P0440 EVAP Control System Malfunction

Step	Action	Value(s)	Yes	No
1	Was the Powertrain On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	Is Diagnostic Trouble Code P0461, P0462 or P0463 also set?	—	Go to Applicable DTC Chart	Go to Step 3
3	1. Visually/Physically check the fuel cap for missing or loose conditions. 2. Replace or tighten the fuel cap if necessary. Was a loose or missing fuel cap found?	—	Go to Step 20	Go to Step 4
4	1. Install a Tech 2. 2. Command the EVAP canister purge valve and vent solenoid ON and OFF with the Tech 2. Does the purge valve and vent solenoid click when commanded ON and OFF?	—	Go to Step 5	Go to PCM Outputs Diagnosis
5	1. Turn the ignition switch OFF. 2. Remove the fuel cap. 3. Turn the ignition switch ON. Is the Fuel Tank Pressure at the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	1.51V	Go to Step 8	Go to Step 6
6	Has the battery been disconnected?	—	Go to EVAP Control System Diagnosis	Go to Step 7
7	Disconnect the battery, wait 20 seconds then reconnect the battery. Is the action complete?	—	Go to Step 5	—
8	IMPORTANT: Before continuing with this diagnosis, zero the EVAP Pressure and Vacuum gauges on the EVAP pressure/purge cart J41413. Also, read the temperature variation instruction card. (refer to tool operating instructions). 1. Reinstall the fuel cap. 2. Using the Tech 2, command the EVAP vent solenoid ON (closed). 3. Connect the EVAP pressure/purge cart J41413 to the EVAP service port. 4. Attempt to pressurize the EVAP system to the specified value using the EVAP pressure/purge cart J41413 (monitor the pressure using the gauges on the cart with the switch in the HOLD position). Can the specified value be achieved?	5 in. H2O	Go to Step 9	Go to Step 10
9	1. Maintain the fuel tank pressure at the specified value? 2. Observe the Fuel Tank Pressure on the Tech 2. Is the Fuel Tank Pressure at the specified value?	1.47~1.51V	Go to Step 12	Go to Step 11


DTC P0440 EVAP Control System Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Disconnect the fuel tank vapor line and the EVAP purge line from the EVAP canister. 2. Block the canister fitting for the fuel tank vapor line. 3. Connect a hand vacuum pump to the canister fitting for the EVAP purge line. 4. Ensure that the EVAP vent solenoid is still commanded ON (closed). 5. Attempt to apply the specified vacuum to the EVAP canister. Can vacuum be maintained at the specified value?	5 in. Hg (17 kPa)	Go to Step 15	Go to Step 14
11	1. Visually/physically check for the following conditions: <ul style="list-style-type: none"> ○ Restricted fuel tank vapor line. ○ Restricted EVAP purge line. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 20	Go to EVAP Control System Diagnosis
12	1. Disconnect the throttle body to EVAP emission canister purge valve vacuum hose from the EVAP canister purge valve. 2. Connect a hand vacuum pump to the EVAP canister purge valve vacuum source fitting. 3. Apply the specified amount of vacuum to the EVAP canister purge valve. 4. Command the EVAP purge valve ON, using the Tech 2. Does the EVAP canister purge valve release the vacuum?	10 in. of Hg (34 kPa)	Go to Step 13	Go to Step 17
13	1. Connect the in. Hg vacuum gauge on the EVAP pressure/purge port J41413 of the vacuum source line. 2. Start the engine. 3. Stabilize the engine rpm near the specified value. 4. Momentarily depress the throttle open and then immediately let the throttle return to idle. Did the vacuum gauge read greater than the specified value when the throttle was opened then closed?	2500 RPM 10 in. Hg	Go to Diagnostic Aids	Go to Step 18
14	1. Visually/physically check for the following conditions: <ul style="list-style-type: none"> ○ Vent hose disconnected or damaged. ○ EVAP canister damaged. 2. If a problem is found, repair as necessary. Was a repair necessary?	—	Go to Step 20	Go to Step 19
15	1. Visually/physically check for the following conditions: <ul style="list-style-type: none"> ○ Missing or malfunctioning fuel cap. ○ Disconnected or leaking fuel tank vapor line. ○ Disconnected or damaged EVAP purge line. 2. If a problem is found, repair as necessary. Was a repair necessary?	—	Go to Step 20	Go to Step 16

DTC P0440 EVAP Control System Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
16	<ol style="list-style-type: none"> Using the Tech 2, command the EVAP vent solenoid ON. With the cart connected to the EVAP service port continuously attempt to pressurize the EVAP system by leaving the cart control knob in the pressurized position. Using the ultrasonic leak detector J41416, locate and repair any leaks in the EVAP system (it may be necessary to partially lower the fuel tank to examine the top tank connections). <p>Is the action complete?</p>	—	Go to Step 20	—
17	<p>Replace the EVAP canister purge valve. Refer to Diagnostic Aids</p> <p>Is the action complete?</p>	—	Go to Step 20	—
18	<p>Locate and repair the cause of no source or vacuum to the EVAP canister purge valve.</p> <p>Is the action complete?</p>	—	Go to Step 20	—
19	<p>Replace the EVAP vent solenoid. Refer to Diagnostic Aids</p> <p>Is the action complete?</p>	—	Go to Step 20	—
20	<p>IMPORTANT: Review the temperature variation instructions included with J41413 before performing this step.</p> <ol style="list-style-type: none"> Turn the ignition switch ON, with the engine OFF. Using the Tech 2, command the EVAP vent solenoid ON (closed). Pressurize the EVAP system to the specified value using the EVAP pressure/purge cart J41413 (monitor pressure using the gauge on the cart). Switch the rotary switch on the cart to HOLD and observe the EVAP pressure gauge. <p>Does the pressure decrease to less than the specified value within 2 minutes?</p>	2.14V	System OK	Go to Step 3

DIAGNOSTIC TROUBLE CODE (DTC) P0442 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM SMALL LEAK DETECTED



D06RX056

Circuit Description

The evaporative system includes the following components:

- Fuel tank.
- EVAP vent solenoid.
- Fuel tank pressure sensor.
- Fuel pipes and hoses.
- Fuel vapor lines.
- Fuel cap.
- EVAP canister.
- Purge lines.
- EVAP canister purge valve.
- EVAP service port.

The evaporative emission system is checked by applying vacuum to the EVAP system and monitoring for a vacuum decay. The PCM monitors the vacuum level through the fuel tank pressure sensor signal. At an appropriate time, the EVAP canister purge valve and the EVAP vent solenoid are turned ON, allowing the engine to draw a small vacuum on the entire evaporative emission system. After the desired vacuum level has been achieved, the EVAP canister purge valve is turned OFF, sealing the system. A leak is detected by monitoring for a decrease in vacuum level over a given time period, when all other variables remain constant. A small leak in the system will cause Diagnostic Trouble Code P0442 to be set. DTC P0442 is a type A code.

Conditions for Setting the DTC

- The BARO is greater than 72.3 kPa.
- No: MAP, TPS, IAT, ECT, EGR, EVAP, VSS, or System Voltage Diagnostic Trouble Codes.
- IAT and ECT at startup are between 3.5°C (38°F) and 32°C (90°F).
- The difference between IAT and ECT at startup is less than 6.75°C (12.2°F).
- Vehicle Speed is less than or equal to 98 km/h (60 mph).
- Fuel Level counts vary by less than 8 counts in a 0.125 second time frame.
- The Fuel Tank Level Sensor reads between 10% and 90%.
- Maximum Engine Run time is at least 540 seconds.
- The difference between the actual Fuel Tank Pressure and the expected Fuel Tank Pressure is less than the PCM's expectation.
- Fuel Tank Pressure slope is less than or equal to 1mm (0.03 inches) of water.

The above conditions are met, and the following condition is met once:

- A single 15 second vacuum decay slope and three 5 second vacuum slopes are all greater than or equal to the PCM's upper threshold.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate.

- The PCM will record operating conditions at the time the diagnostic fails. The Freeze Frame and Failure Records buffers will store this information.
- A history Diagnostic Trouble Code is stored.

Conditions for Clearing the MIL/DTC

- The MIL will turn OFF after 3 consecutive ignition cycles in which the diagnostic runs without a fault.
- A history Diagnostic Trouble Code will clear after 40 consecutive warm up cycles without a fault.
- A Tech 2 can clear the Diagnostic Trouble Codes.

Diagnostic Aids

- A loose, missing, or damaged fuel cap.
- Missing or damaged O-rings at the fuel vapor fittings and the EVAP purge line canister fittings.
- Cracked EVAP canister.
- Damaged source vacuum line, EVAP purge line, EVAP vent hose or fuel vapor line.
- The Fuel Pressure Sensor shares a 5 Volt reference with the MAP sensor and TP sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The Fuel Pressure Sensor share a ground with the MAP sensor and the TP sensor.
- Poor connection at PCM: Inspect harness connectors for backed out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.
- Damaged harness: Inspect the wiring harness to the EVAP vent solenoid, the EVAP purge solenoid, and the

fuel tank pressure sensor for an intermittent open or intermittent short circuit.

Check for charcoal particles. Refer to Carbon Particle Removal from EVAP System before starting repairs. Reviewing the Fail Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that causes the Diagnostic Trouble Code to set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 if applicable. This creates an electronic copy of the data taken when the malfunction occurred. The information is then stored on the Tech 2 for later reference.
3. If a vent solenoid or EVAP canister purge valve electrical malfunction is present, the purge system will not operate correctly. Repairing the electrical malfunction will very likely correct the condition that set Diagnostic Trouble Code P0442.
4. Checks the fuel tank pressure sensor at ambient pressure.
6. Forces the fuel tank pressure sensor to re-zero.
7. Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.

DTC P0442 EVAP Control System Small Leak Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	Is Diagnostic Trouble Code P0461, P0462, or P0463 also set?	—	Go to Applicable DTC Table	Go to Step 3
3	1. Install a Tech 2. 2. Command the EVAP canister purge valve and vent solenoid ON and OFF with the Tech 2? Does the purge valve and vent solenoid click ON and OFF?	—	Go to Step 4	Go to PCM Outputs Diagnosis
4	1. Turn the ignition switch OFF. 2. Remove the fuel cap. 3. Turn the ignition switch ON. Is the Fuel Tank Pressure at the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	1.51V	Go to Step 7	Go to Step 5
5	Has the battery been disconnected?	—	Go to EVAP Control System Diagnosis	Go to Step 6


DTC P0442 EVAP Control System Small Leak Detected (Cont'd)

Step	Action	Value(s)	Yes	No
6	Disconnect the battery, wait 20 seconds then reconnect the battery. Is the action complete?	—	Go to Step 4	—
7	IMPORTANT: Before continuing with this diagnosis, zero the EVAP Pressure and Vacuum Gauges on the EVAP pressure/purge cart J41413. Also read the temperature variation instruction card. (Refer to tool operating instructions). 1. Reinstall the fuel cap. 2. Using the Tech 2, command the EVAP vent solenoid ON (closed). 3. Connect the EVAP pressure/purge cart J41413 to the EVAP service port. 4. Pressurize the EVAP system to the specified value using the EVAP pressure/purge cart J41413 (monitor the pressure using the gauge on the cart with the switch in the HOLD position). 5. Observe the Fuel Tank Pressure on the Tech 2. Is the Fuel Tank Pressure at the specified value?	5 in. H ₂ O (±2 in. H ₂ O)	Go to Step 8	Go to EVAP Control System Diagnosis
8	IMPORTANT: Review the temperature variation instructions included with the J41413 before performing this step. 1. Turn the ignition switch ON, with the engine OFF. 2. Using the Tech 2, command the EVAP vent solenoid ON (closed). 3. Pressurize the EVAP system to the specified value using the EVAP pressure/purge cart J41413 (monitor the pressure using the gauge on the cart). 4. Switch the rotary switch on the cart to HOLD and observe the EVAP pressure gauge. Does the pressure decrease to less than the specified value within 2 minutes?	1.47 – 1.51V	Go to Step 9	Refer to Diagnostic Aids
9	1. Disconnect the fuel tank vapor line and the EVAP purge line from the EVAP canister. 2. Block the fuel tank vapor line fitting on the canister. 3. Connect a hand vacuum pump to the EVAP purge line fitting on the canister. 4. Ensure that the EVAP vent solenoid is still commanded ON (closed). 5. Attempt to apply vacuum to the canister. Can the specified vacuum be maintained?	5 in. Hg	Go to Step 12	Go to Step 10
10	1. Visually/physically check for the following conditions: ○ Vent hose disconnected or damaged. ○ EVAP canister damaged 2. If a problem is found, repair as necessary Was a repair necessary?	—	Go to Step 14	Go to Step 11
11	Replace the EVAP vent solenoid. Refer to Diagnostic Aids Is the action complete?	—	Go to Step 14	—

DTC P0442 EVAP Control System Small Leak Detected (Cont'd)

Step	Action	Value(s)	Yes	No
12	1. Visually/physically check for the following conditions: <ul style="list-style-type: none"> ○ Malfunctioning fuel cap. ○ Leaking fuel tank vapor line. ○ Damaged EVAP purge line. 2. If a problem is found, repair as necessary Was a repair necessary?	—	Go to Step 14	Go to Step 13
13	1. Using the Tech 2, command the EVAP vent solenoid ON (closed). 2. With the EVAP pressure/purge cart J41413 connected to the EVAP system by leaving the cart control knob in the pressurized position. 3. Using the ultrasonic leak detector J41416, locate and repair the leak in the EVAP system (it may be necessary to partially lower the fuel tank to examine the top tank connections). Is the action complete?	—	Go to Step 14	—
14	IMPORTANT: Review the temperature variation instructions included with the J41413 before performing this step. 1. Turn the ignition switch ON, with engine OFF. 2. Using the Tech 2, command the EVAP vent solenoid ON (closed). 3. Pressurize the EVAP system to the specified value using the EVAP pressure/purge cart J41413 (monitor the pressure using the gauge on the cart). 4. Switch the rotary switch on the cart to HOLD and observe the EVAP pressure gauge. Does the pressure decrease to less than the specified value within 2 minutes?	2.14V	System OK	Go to Step 3

DIAGNOSTIC TROUBLE CODE (DTC) P0443 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM PURGE CONTROL VALVE CIRCUIT MALFUNCTION



D06RX056

Circuit Description

The Powertrain Control Module (PCM) controls the Evaporative Emission (EVAP) Canister Purge Solenoid Valve through the use of a control (ground) circuit. If the PCM commands the Purge solenoid to maximum duty cycle (100%) but the voltage remains High (12 Volts); or, if the PCM commands the Purge solenoid to minimum duty cycle (0%) but the voltage remains Low (0 volts), then DTC P0443 will set. DTC P0443 is a type A code.

Conditions for Setting the DTC

- Ignition voltage is greater than 10 volts
 - Engine run time is greater than 32 seconds
- The above mentioned conditions are met and one of the following two conditions are met for 25 seconds within a 50 seconds test sample:
- PCM senses voltage is High with the EVAP Canister Purge Solenoid commanded ON.
 - PCM senses voltage is Low with the EVAP Canister Purge Solenoid commanded OFF.

Action Taken When the DTC Sets

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) the first time the fault is detected.

- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL after three consecutive trips without a reported failure.
- A History DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- Poor connections, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also check for open circuits, shorts to ground, and shorts to voltage.
- The Fuel Pressure Sensor shares a 5 Volt reference with the MAP sensor and TP sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The Fuel Pressure Sensor share a ground with the MAP sensor and the TP sensor.


DTC P0443 EVAP Control System Purge Control Valve Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTC's. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0443. Does the Tech 2 indicate DTC P0443 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Disconnect the EVAP Canister Purge Solenoid from the wiring harness connector from the EVAP Canister Purge Solenoid. 3. Ignition ON, Engine OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the "Engine IG." Fuse pin of the EVAP Canister Purge Solenoid wiring harness connector. Does the DVM read the following value?	12 Volts	Go to Step 5	Go to Step 4
4	Check the suspect circuit between the EVAP Canister Purge Solenoid connector and the "Engine IG." Fuse for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	—
5	Using a DVM, check the resistance of the EVAP Canister Purge Solenoid. Does the DVM read the following value?	less than 5 Ω	Go to Step 6	Go to Step 7
6	1. Ignition OFF. 2. Disconnect the Powertrain Control Module (PCM) connectors from the PCM. 3. Check the EVAP Canister Purge Solenoid control circuit between the PCM and EVAP Canister Purge Solenoid for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 8

DTC P0443 EVAP Control System Purge Control Valve Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
7	Replace the EVAP Canister Purge Solenoid. Verify Repair.	—	—	—
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0446 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM VENT CONTROL CIRCUIT MALFUNCTION



D06RX056

Circuit Description

The evaporative system includes the following components:

- Fuel tank.
- EVAP vent solenoid.
- Fuel tank pressure sensor.
- Fuel pipes and hoses.
- Fuel vapor lines.
- Fuel cap.
- EVAP canister.
- Purge lines.
- EVAP canister purge valve.
- EVAP service port.

The evaporative emission system is checked by applying vacuum to the EVAP system and monitoring for a vacuum decay. The PCM monitors the vacuum level through the fuel tank pressure sensor signal.

At an appropriate time, the EVAP canister purge valve and the EVAP vent solenoid are turned ON, allowing the engine to draw a small vacuum on the entire evaporative emission system. After the desired vacuum level has been achieved, the EVAP canister purge valve is turned OFF, sealing the system.

A restricted or blocked EVAP canister vent path is detected by drawing a vacuum on the EVAP system, turning OFF the EVAP vent solenoid and the EVAP canister purge valve (EVAP vent solenoid Open, EVAP purge PWM 0%) and monitoring the fuel tank vacuum

sensor input. With the EVAP vent solenoid open, any vacuum in the system should decrease quickly unless the vent path is blocked. A blockage can be caused by the following conditions:

- Faulty EVAP vent solenoid (stuck closed).
- Plugged, kinked or pinched vent hose.
- Shorted EVAP vent solenoid driver circuit.
- Plugged evaporative canister.

If any of these conditions are present, Diagnostic Trouble Code P0446 will set. DTC P0446 is a type B code.

Conditions for Setting the DTC

- The BARO is greater than 72.3 kPa.
- No: MAP, TPS, IAT, ECT, EGR, EVAP, VSS or System Voltage Diagnostic Trouble Codes.
- IAT and ECT at startup are between 3.5°C (38°F) and 32°C (90°F).
- The difference between IAT and ECT at startup is less than 6.75°C (12.2°F).
- The Fuel Tank Level Sensor reads between 10% and 90%.
- The difference between the actual Fuel Tank Pressure and the expected Fuel Tank Pressure is less than the PCM's expectation.
- Fuel Tank Pressure slope is less than or equal to 1mm (0.03 inches) of water.

The above conditions are met, and the following condition is met once:

- Fuel Tank vacuum is greater than 39 cm (15.35 inches) of water.

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate.
- The PCM will records operating conditions at the time the diagnostic fails. The Freeze Frame and Failure Records buffers will store this information.
- A history Diagnostic Trouble Code is stored.

Conditions for Clearing the MIL/DTC

- The MIL will turn off after 3 consecutive ignition cycles in which the diagnostic runs without a fault.
- A history DTC will clear after 40 consecutive warm up cycles without a fault.
- A Tech 2 can clear the DTC's.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM: Inspect harness connectors for backed out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.
- The Fuel Pressure Sensor shares a 5 Volt reference with the MAP sensor and TP sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The Fuel Pressure Sensor share a ground with the MAP sensor and the TP sensor.
- Damaged harness: Inspect the wiring harness to the EVAP vent solenoid and the fuel tank pressure sensor for shorts to ground, shorts to battery positive, and open circuits.
- Kinked, pinched or plugged vent hose: Verify that the vent hose between the canister and the EVAP vent solenoid is not restricted.

Check for charcoal particles. Refer to Carbon Particles Removal from EVAP System before starting repairs.

Reviewing the Fail Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that causes the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 if applicable. This creates an electronic copy of the data taken when the malfunction occurs. This may assist in diagnosing the condition.
3. If a vent solenoid electrical malfunction is present, the purge system will not operate correctly. Repairing the electrical malfunction will very likely correct the condition that set Diagnostic Trouble Code P0446.
4. Checks the fuel tank pressure sensor at ambient pressure.
6. Forces the fuel tank pressure sensor to re-zero.
7. Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.
9. Checks for a blocked EVAP canister.
13. Duplicates the Powertrain On-Board Diagnostic test.


DTC P0446 EVAP Control System Vent Control Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	Is Diagnostic Trouble Code P0461, P0462, or P0463 also set?	—	Go to Applicable DTC chart	Go to Step 3
3	1. Install a Tech 2. 2. Command the EVAP canister purge valve and vent solenoid ON and OFF with the Tech 2? Does the purge valve and vent solenoid click ON and OFF? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 4	Go to PCM Outputs Diagnosis
4	1. Turn the ignition switch OFF. 2. Remove the fuel cap. 3. Turn the ignition switch ON. Is the Fuel Tank Pressure at the specified value?	1.51V	Go to Step 7	Go to Step 5
5	Has the battery been disconnected?	—	Go to EVAP Control System Diagnosis	Go to Step 6
6	Disconnect the battery, wait 30 seconds, then reconnect the battery. Is the action complete?	—	Go to Step 4	—
7	IMPORTANT: Before continuing with this diagnosis, zero the EVAP Pressure and Vacuum Gauges on the EVAP pressure/purge cart J41413. Also read the temperature variation instruction card. (Refer to tool operating instructions). 1. Reinstall the fuel cap. 2. Using the Tech 2, command the EVAP vent solenoid ON (closed). 3. Connect the EVAP pressure/purge cart J41413 to the EVAP service port. 4. Pressurize the EVAP system to the specified value using the EVAP pressure/purge cart J41413 (monitor the pressure using the gauge on the cart with the switch in the "HOLD" position). 5. Observe the Fuel Tank Pressure on the Tech 2. Is the Fuel Tank Pressure at the specified value?	1.52 – 1.69V	Go to Step 8	Go to EVAP Control System Diagnosis
8	1. Maintain the specified EVAP pressure. 2. Using the Tech 2, command the EVAP vent solenoid OFF (open) while observing the EVAP pressure gauge on the cart J41413. Does the EVAP pressure return to the specified value within 5 seconds?	0 in. H2O	Refer to Diagnostic Aids	Go to Step 9

DTC P0446 EVAP Control System Vent Control Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Disconnect the large vent hose (marked air) from the EVAP canister. 2. Switch the rotary switch on the cart J41413 to PURGE. 3. Start the engine and allow the engine to reach operating temperature. 4. Observe the vacuum gauge for 5 seconds while holding the engine speed at the specified value. Does the vacuum remain below the specified value?	30 in. H ₂ O 2500 RPM	Go to Step 10	Go to Step 12
10	1. Inspect the EVAP vent hose between the EVAP canister and the EVAP vent solenoid for being kinked, pinched, or other wise blocked. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 13	Go to Step 11
11	Replace the EVAP vent solenoid. Refer to Diagnostic Aids Is the action complete?	—	Go to Step 13	—
12	Replace the EVAP canister. Refer to EVAP Canister Replacement. Is the action complete?	—	Go to Step 13	—
13	1. Using the Tech 2, command the EVAP vent solenoid ON (closed). 2. Pressurize the EVAP system to the specified value. 3. Switch the rotary switch on the cart J41413 to HOLD. 4. Using the Tech 2, command the EVAP vent solenoid OFF (open) while observing the EVAP pressure gauge on the cart J41413. Does the EVAP pressure return to the specified value within 5 seconds?	1.51V	System OK	Go to Step 3

DIAGNOSTIC TROUBLE CODE (DTC) P0449 EVAPORATIVE EMISSION (EVAP) CONTROL SYSTEM VENT VALVE/SOLENOID CIRCUIT MALFUNCTION



D06RX056

Circuit Description

The Powertrain Control Module (PCM) controls the Evaporative Emission (EVAP) Canister Vent Solenoid Valve through the use of a control (ground) circuit. If the PCM commands the Vent solenoid but the voltage remains High (12 Volts); or, if the PCM commands the Vent solenoid OFF but the voltage remains Low (0 volts), then DTC P0449 will set. DTC P0449 is a type A code.

Conditions for Setting the DTC

- Ignition voltage is greater than 10 volts.
- Engine run time is greater than 32 seconds.
- The above mentioned conditions are met and one of the following two conditions are met for 25 seconds within a 50 seconds test sample:
 - PCM senses voltage is High with the EVAP Canister Vent Solenoid commanded ON.
 - PCM senses voltage is Low with the EVAP Canister Vent Solenoid commanded OFF.

Action Taken When the DTC Sets

- The PCM will illuminate the Malfunction Indicator Lamp (MIL).

- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL after three consecutive trips without a reported failure.
- A History DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- Poor connections, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also check for open circuits, shorts to ground, and shorts to voltage.
- The Fuel Pressure Sensor shares a 5 Volt reference with the MAP sensor and TP sensor.
 - If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The Fuel Pressure Sensor share a ground with the MAP sensor and the TP sensor.


DTC P0449 EVAP Control System Vent Valve/Solenoid Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTC's. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0449. Does the Tech 2 indicate DTC P0449 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Disconnect the EVAP Canister Purge Solenoid from the wiring harness connector from the EVAP Canister Purge Solenoid. 3. Ignition ON, Engine OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the "Engine IG." Fuse pin of the EVAP Canister Purge Solenoid wiring harness connector. Does the DVM read the following value?	12 Volts	Go to Step 5	Go to Step 4
4	Check the suspect circuit between the EVAP Canister Purge Solenoid connector and the "Engine IG." Fuse for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	—
5	Using a DVM, check the resistance of the EVAP Canister Purge Solenoid. Does the DVM read the following value?	less than 5 Ω	Go to Step 6	Go to Step 4
6	1. Ignition OFF. 2. Disconnect the Powertrain Control Module (PCM) connectors from the PCM. 3. Check the EVAP Canister Purge Solenoid control circuit between the PCM and EVAP Canister Purge Solenoid for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	—

DTC P0449 EVAP Control System Vent Valve/Solenoid Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
7	Replace the EVAP Canister Purge Solenoid.	—	Verify repair.	Go to Step 7
8	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p>	—	Verify repair.	Go to Step 8

DIAGNOSTIC TROUBLE CODE (DTC) P0461 FUEL LEVEL SENSOR CIRCUIT RANGE/PERFORMANCE



D06RX057

Circuit Description

The Fuel Level sensor is an important input to the PCM for the Enhanced Evaporative System Diagnostic. The PCM needs the fuel level information in order to know the volume of fuel in the tank. The fuel level affects the rate of change in air pressure in the EVAP system. Several of the Enhanced Evaporative System Diagnostic sub-test are dependent upon correct fuel level information. The diagnostic will not run when the tank is greater than 85% or less than 15% full. (This sensor signal disables the misfire when the fuel levels are less than 15%). DTC P0461 is a type D Code.

Conditions for Setting the DTC

- The Fuel Tank Level Slosh Test is completed.
- The Tank Level Main Test is completed.
- The Fuel Tank Level Data is Valid.
- The Fuel Level signal changes by less than 7 counts (0.14 volts) over a distance of 240 km (146 miles).

Action Taken When the DTC Sets

- The PCM will not turn on the MIL.

Conditions for Clearing the DTC

- The PCM turns the MIL off after 3 consecutive driving trips without a fault condition present.
- A history DTC will clear if no fault conditions have been detected for 40 warm-up cycles (coolant temperature has risen 40°F from the start-up coolant temperature and the engine coolant temperature exceeds 160°F during that same ignition cycle) or the Tech 2 clearing feature has been used.

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart:

4. This step determines if the fuel gauge and fuel level sender module are operating correctly.

DTC P0461 Fuel Level Sensor Circuit Range/Performance

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Install the Tech 2. 2. Turn ON the ignition. 3. Compare the fuel level on the Tech 2 with the vehicle fuel gauge. Are the levels approximately the same?	—	Go to Step 3	Go to Step 5
3	1. Record the vehicle fuel gauge reading. 2. Turn OFF the ignition. 3. Disconnect the PCM's connector. 4. Turn ON the ignition. Did the vehicle fuel gauge reading change?	—	Go to Step 4	Go to Step 5
4	1. Turn the ignition OFF. 2. Disconnect the fuel tank level sensor connector. 3. Using a fused jumper wire, jump the fuel level input to the fuel level sensor ground. 4. Turn the ignition ON. Does the Tech 2 and the fuel gauge indicate the specified value?	0% (Empty)	Go to Step 5	Go to Step 6
5	Replace the Fuel tank level sensor.	—	Go to Step 7	—
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to Step 7	—
7	1. Using the Tech 2, select the Diagnostic Trouble Code, and Clear Info. 2. Start the engine. 3. Idle at the normal operating temperature. 4. Select the DTC and the Specific 5. Enter the DTC number which was set. 6. Operate the vehicle within the conditions for setting this DTC. Does the Tech 2 indicate that this diagnostic Ran and Passed?	—	System OK	Go to Step 2

DIAGNOSTIC TROUBLE CODE (DTC) P0462 FUEL LEVEL SENSOR CIRCUIT LOW INPUT



D06RX057

Circuit Description

The Fuel Level Sensor is an important input to the PCM for the Enhanced Evaporative System Diagnostic. The PCM needs the fuel level information in order to know the volume of fuel in the tank. The fuel level affects the rate of change in air pressure in the EVAP system. Several of the Enhanced Evaporative System Diagnostic sub-test are dependent upon correct fuel level information. The diagnostic will not run when the tank is greater than 85% or less than 15% full. (This sensor signal disables the misfire when the fuel levels are less than 15%). If the PCM detects a continuous short to ground in the Fuel Level sensor or circuit, then a code P0462 will set. DTC P0462 is a type D code.

Conditions for Setting the DTC

- The Fuel Tank Slosh Test is completed.
- The Fuel Tank Main Level Test is completed.
- The Fuel Tank Level Data is valid.
- The Fuel Level signal voltage is less than 0.06 volts for a period greater than 20 seconds.

Action Taken When the DTC Sets

- The PCM will not turn on the MIL.

Conditions for Clearing the DTC

- The PCM turns the MIL OFF after 3 consecutive driving trips without a fault condition present.
- A history Diagnostic Trouble Code will clear if no fault conditions have been detected for 40 warm-up cycles (coolant temperature has risen 40°F from the start-up coolant temperature and the engine coolant temperature exceeds 160°F during that same ignition cycle) or the Tech 2 clearing feature has been used.

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart:

4. This step checks the wiring, connections, and the PCM.
6. This step checks the wiring, connections, and the PCM.

DTC P0462 Fuel Level Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Install the Tech 2. 2. Ignition ON. 3. Observe the fuel level on the Tech 2. Does the Tech 2 display the specified value?	0%–1%	Go to Step 4	Go to Step 3
3	Refer to Fuel Gauge Diagnosis.	—	—	—
4	With a Digital Voltmeter (DVM) to ground, probe the fuel level sensor input at the Fuel Level sensor. Is the voltage less than the specified value?	0.13 V	Go to Step 5	Go to Step 6
5	Check for a open in the fuel level sensor input circuit. Was a problem found?	—	Go to Step 7	Go to Step 6
6	With a DVM to ground, probe the fuel level module output at the Fuel Level sensor. Is the voltage greater than the specified value?	2.9 V	Go to Step 9	Go to Step 10
7	Repair the open in the fuel level sensor input circuit. Is the action complete?	—	Go to Step 11	—
8	Repair the open in the fuel level output circuit. Is the action complete?	—	Go to Step 11	—
9	Repair the short to voltage in the fuel level output circuit. Is the action complete?	—	Go to Step 11	—
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to Step 11	—
11	1. Using the Tech 2, select the DTC and the Clear Info. 2. Start the engine. 3. Idle at the normal operating temperature. 4. Select the Diagnostic Trouble Code and the Specific. 5. Enter the number which was set. 6. Operate the vehicle within the conditions for setting this Diagnostic Trouble Code as specified in the supporting text. Does the Tech 2 indicate that this diagnostic Ran and Passed?	—	System OK	Go to Step 2

DIAGNOSTIC TROUBLE CODE (DTC) P0463 FUEL LEVEL SENSOR CIRCUIT HIGH INPUT



Circuit Description

The Fuel Level sensor is an important input to the PCM for the Enhanced Evaporative System Diagnostic. The PCM needs the fuel level information in order to know the volume of fuel in the tank. The fuel level affects the rate of change in air pressure in the EVAP system. Several of the Enhanced Evaporative System Diagnostic sub-tests are dependent upon correct fuel level information. The diagnostic will not run when the tank is greater than 85% or less than 15% full. (This sensor signal disables the misfire when the fuel levels are less than 15%). If the PCM detects a continuous short to voltage in the Fuel Level sensor or circuit, then a DTC P0463 will set. DTC P0463 is a type D code.

Conditions for Setting the DTC

- The Fuel Tank Level Slosh Test is completed.
- The Fuel Tank Level Main Test is completed.
- The Fuel Tank Level Data is valid.
- The Fuel Level signal voltage is greater than 4.9 volts for a period greater than 20 seconds.

Action Taken When the DTC Sets

- The PCM will not turn on the MIL.

Conditions for Clearing the DTC

- The PCM turns the MIL off after 3 consecutive driving trips without a fault condition present.
- A history DTC will clear if no fault conditions have been detected for 40 warm-up cycles (coolant temperature has risen 40°F from the start-up coolant temperature and the engine coolant temperature exceeds 160°F during that same ignition cycle) or the Tech 2 clearing feature has been used.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:


5. This step checks the wiring, connections, and the PCM.
7. This step checks the wiring, connections, and the PCM.

D06RX057

DTC P0463 Fuel Level Sensor Circuit High Input

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Install the Tech 2. Observe the fuel level on the Tech 2. Does the Tech 2 display the specified value?	99% – 100%	Go to Step 4	Go to Step 3
3	Refer to Fuel Gauge Diagnosis.	—	—	—
4	With a Digital Voltmeter (DVM) to ground, probe the Fuel Level sensor input at the Sensor Input cavity. Is the voltage greater than the specified value?	2.9 V	Go to Step 5	Go to Step 6
5	Check for a open in the Fuel Level sensor ground. Was a problem found?	—	Go to Step 7	Go to Step 6
6	Check for an open in the Fuel Level sensor ground. Was a problem found?	—	Go to Step 9	Go to Step 10
7	Repair the short to voltage in the fuel level input circuit. Is the repair complete?	—	Go to Step 11	—
8	Repair the short to voltage in the fuel level output circuit. Is the repair complete?	—	Go to Step 11	—
9	Repair the open in the fuel level sensor ground. Is the repair complete?	—	Go to Step 11	—
10	Replace the PCM. IMPORTANT: The replacement PCM must be reprogrammed. Refer to PCM Replacement/Programming. Is the action complete?	—	Go to Step 11	—
11	1. Using the Tech 2, select the DTC and the Clear Info. 2. Start the engine. 3. Idle at the normal operating temperature. 4. Select the Diagnostic Trouble Code and the Specific. 5. Enter the Diagnostic Trouble Code number which was set. 6. Operate the vehicle within the conditions for setting this Diagnostic Trouble Code as specified in the supporting text. Does the Tech 2 indicate that this diagnostic Ran and Passed?	—	System OK	Go to Step 2

DIAGNOSTIC TROUBLE CODE (DTC) P0480 COOLING FAN 1 CONTROL CIRCUIT MALFUNCTION



D06RX058

Circuit Description

The Powertrain Control Module (PCM) controls the engagement of the cooling fan Low speed through the use of a relay and a control circuit. If the PCM commands the fan to Low speed and then senses that the fan did not turn ON, or if the PCM commands the fan OFF from Low speed and then senses that the fan did not turn OFF, the PCM will set a DTC P0480. DTC P0480 is a type D code.

Conditions for Setting the DTC

- Ignition voltage is greater than 10 volts.
 - Engine run time is greater than 32 seconds.
- The above conditions are met and one of the following conditions are met for 25 seconds within a 50 second test sample:
- PCM sensed voltage is High with the Low Speed Fan OFF.
- OR
- PCM sensed voltage is Low with the Low Speed Fan ON.

Action Taken When the DTC Sets

- The PCM will not turn on the Malfunction Indicator Lamp.
- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the DTC

- A history DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using the Scan Tool's Clear Info" function.

Diagnostic Aids

- Poor connections or a damaged harness – Inspect the harness connectors for: backed out terminals, improper mating or damaged terminals. Also check for open circuits, shorts to ground, and shorts to voltage.


DTC P0480 Cooling Fan 1 Control Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTCs. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0480. Does the Tech 2 indicate that DTC P0480 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Remove the Low Fan Relay from the Underhood Electrical Center. 3. Ignition OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the "ELEC. FAN" Fuse pin of the Low fan Relay connector. Does the DVM read the following value?	12 Volts	Go to Step 4	Go to Step 3
4	1. Ignition ON. 2. Using a DVM, check for voltage on the "ENGINE FAN" Fuse pin of the Low Fan Relay connector. Does the DVM read the following value?	12 Volts	Go to Step 6	Go to Step 5
5	Check the suspect circuit between the Low Fan Relay connector and Fuse for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	—
6	1. Ignition OFF. 2. Disconnect the Powertrain Control Module (PCM) connectors from the PCM. 3. Check the Low Fan Relay control circuit between the PCM and Underhood Electrical Center for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 7
7	1. Reinstall the Low Fan Relay. 2. Using a fused jumper, ground the Low Fan Relay control circuit at the PCM connector. 3. Ignition ON, Engine OFF. Does the fan run at low speed?	—	Go to Step 9	Go to Step 8

DTC P0480 Cooling Fan 1 Control Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
8	Replace the Low Fan Relay. Is the action complete?	—	Verify repair	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0481 COOLING FAN 2 CONTROL CIRCUIT MALFUNCTION



D06RX058

Circuit Description

The Powertrain Control Module (PCM) controls the engagement of the cooling fan Low speed through the use of a relay and a control circuit. If the PCM commands the fan to Low speed and then senses that the fan did not turn ON, or if the PCM commands the fan OFF from Low speed and then senses that the fan did not turn OFF, the PCM will set a DTC P0481. DTC P0481 is a type D code.

Conditions for Setting the DTC

- Ignition voltage is greater than 10 volts.
 - Engine run time is greater than 32 seconds.
- The above conditions are met and one of the following conditions are met for 25 seconds within a 50 second test sample:
- PCM sensed voltage is High with the High Speed Fan OFF.
- OR
- PCM sensed voltage is High with the High Speed Fan ON.

Action Taken When the DTC Sets

- The PCM will not turn on the Malfunction Indicator Lamp.
- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the DTC

- A history DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- Poor connections or a damaged harness – Inspect the harness connectors for: backed out terminals, improper mating or damaged terminals. Also check for open circuits, shorts to ground, and shorts to voltage.


DTC P0481 Cooling Fan 2 Control Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTCs. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0480. Does the Tech 2 indicate that DTC P0480 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Remove the Low Fan Relay from the Underhood Electrical Center. 3. Ignition OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the "ELEC. FAN" Fuse pin of the Low fan Relay connector. Does the DVM read the following value?	12 Volts	Go to Step 4	Go to Step 3
4	1. Ignition ON. 2. Using a DVM, check for voltage on the "ENGINE FAN" Fuse pin of the Low Fan Relay connector. Does the DVM read the following value?	12 Volts	Go to Step 6	Go to Step 5
5	Check the suspect circuit between the Low Fan Relay connector and Fuse for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	—
6	1. Ignition OFF. 2. Disconnect the Powertrain Control Module (PCM) connectors from the PCM. 3. Check the Low Fan Relay control circuit between the PCM and Underhood Electrical Center for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 7
7	1. Reinstall the High Fan Relay. 2. Using a fused jumper, ground the High Fan Relay control circuit at the PCM connector. 3. Ignition ON, Engine OFF. Does the fan run at High speed?	—	Go to Step 9	Go to Step 8

DTC P0481 Cooling Fan 2 Control Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
8	Replace the High Fan Relay. Is the action complete?	—	Verify repair	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0502 VEHICLE SPEED SENSOR (VSS) CIRCUIT LOW INPUT



D06RX069

Circuit Description

The vehicle speed sensor has a magnet rotated by the transmission output shaft. Attached to the sensor is a hall effect circuit that interacts with the magnetic field created by the rotating magnet. A 12-volt operating supply for the speed sensor hall circuit is supplied from the meter fuse. The VSS pulses to ground the 5-volt signal sent from the powertrain control module (PCM) on the reference circuit. The PCM interprets vehicle speed by the number of pulses to ground per second on the reference circuit. DTC P0502 is a type B code.

Conditions for Setting the DTC

- Engine is running.
 - Engine coolant temperature is above 60°C (140°F).
 - System voltage is between 10 and 16 volts.
- When the above conditions are met, one of the following tests will run:

Decel Test

- MAP is less than 35 kPa.
 - Throttle Position is less than 0.8%.
 - Engine Speed is between 1500 RPM and 3500 RPM.
- The Decel Test will fail if vehicle speed is less than 8 km/h (5mph).

The Decel Test will pass if vehicle speed is greater than 24 km/h (15mph).

Power Test

- MAP is greater than 50 kPa.
 - Throttle Position is between 25% and 70%.
 - Engine Speed is between 2700 RPM and 4400 RPM.
- The Power Test will fail if vehicle speed is less than 8 km/h (5 mph).
The Power Test will pass if vehicle speed is greater than 8km/h (5mph) without any VSS DTC's present, or if vehicle speed is greater than 49 km/h (30mph) with VSS Diagnostic Trouble Codes present.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the second time the fault is detected.
- Base shift logic on RPM only.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0502 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- Diagnostic Trouble Code P0502 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- Poor connection at PCM: Inspect harness connectors for backed out terminals, improper mating, broken


locks, improperly formed or damaged terminals, and poor terminal to wire connection.

- Damaged harness: Inspect the wiring harness to the EVAP vent solenoid, the EVAP purge solenoid, and the fuel tank pressure sensor for an intermittent open or intermittent short circuit.

DTC P0502 – VSS Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition OFF. 2. Disconnect the VSS connector. 3. Using a test light to battery +, probe the connector ground wire. Did the light illuminate?	—	Go to Step 4	Go to Step 3
3	Repair the open in the sensor ground circuit.	—	Verify repair	—
4	1. Ignition ON, sensor disconnected. 2. Using a Digital Voltmeter (DVM), measure at the VSS connector between ground and voltage supply. Was the measurement near the specified value?	Battery voltage	Go to Step 6	Go to Step 5
5	Repair the open or short to ground in the VSS sensor circuit.	—	Verify repair	—
6	1. Ignition OFF. 2. Check the BLU/BLK wire between the VSS sensor connector and the PCM for the following conditions: ○ An open circuit ○ A short to ground Was the faulty condition located?	—	Verify repair	Go to Step 9
7	Using a DVM, measure the resistance between the VSS sensor body and transmission case (ground). Is the resistance above the specified value?	10 K Ω	Verify repair	Go to Step 9
8	1. Remove the VSS from the transmission case. 2. Visually inspect the VSS for damage. Does the VSS appear to be OK?	—	Verify repair	—
9	Replace the VSS.	—	Verify repair	—
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0506 IDLE CONTROL SYSTEM RPM LOWER THAN EXPECTED



D06RX041

Circuit Description

The powertrain control module (PCM) controls engine idle speed by adjusting the position of the idle air control (IAC) motor pintle. The IAC is a bi-directional stepper motor driven by two coils. The PCM applies current to the IAC coils in steps (counts) to extend the IAC pintle into a passage in the throttle body to decrease air flow. The PCM reverses the current to retract the pintle, increasing air flow. This method allows highly accurate control of idle speed and quick response to changes in engine load. If the PCM detects a condition where too low of an idle speed is present and the PCM is unable to adjust idle speed by increasing the IAC counts, DTC P0506 will set, indicating a problem with the idle control system. DTC P0506 is a type B code.

Conditions for Setting the DTC

- No intrusive tests being run.
- Engine run time is more than 125 seconds.
- No TPS, VSS, ECT, EGR, MAP, IAT, misfire, low voltage, fuel system or canister purge Diagnostic Trouble Codes are set.
- Barometric pressure is greater than 72.7 kPa.
- Canister purge duty cycle is above 0%.
- Engine coolant temperature (ECT) is above 50°C (122°F).
- Intake air temperature above -40°C (-40°F).

- MAP is less than 60 kPa.
- Ignition voltage is between 9.5 volts and 16 volts.
- The throttle is closed.
- All conditions are met for 10 seconds.
- Engine speed is at least 100 RPM lower than desired idle, based upon PCM expectations.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- Diagnostic Trouble Code P0506 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM or IAC motor – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits.
- Restricted air intake system – Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system.
- Throttle body – Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate.

- Large vacuum leak – Check for a condition that causes a large vacuum leak, such as an incorrectly installed or faulty PCV valve or brake booster hose disconnected. Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0506 – Idle Control System RPM Lower Than Expected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any other Diagnostic Trouble Codes set?	—	Go to other Diagnostic Trouble Code first	Go to Step 3
3	1. Start the engine. 2. Turn all accessories OFF (A/C, rear defroster, etc.) 3. Using a Tech 2, command RPM up to 1500, down to 500, and then up to 1500 while monitoring "Engine Speed" on the Tech 2. Does the "Engine Speed" remain within the specified value of "Desired Idle" for each RPM command?	+/-50 RPM	No trouble found. Go to Diagnostic Aids	Go to Step 4
4	1. Disconnect the IAC. 2. Install IAC Noid Light J 37027A or equivalent. 3. With the engine running, command RPM up to 1500, down to 500, and then up to 1500 while observing the noid light. Does each noid light cycle red and green (never OFF)?	—	Go to Step 6	Go to Step 5
5	1. Check the following circuits for an open, short to voltage, short to ground, or poor connection at the PCM: ○ IAC "A" low ○ IAC "A" high ○ IAC "B" low ○ IAC "B" high 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
6	Visually/physically inspect for the following conditions: ○ Throttle body tampering (adjustment screw plug removed). ○ Restricted air intake system. Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system. ○ Throttle body. Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. Do any of the above require a repair?	—	Refer to appropriate section for on-vehicle service	Go to Step 7

DTC P0506 – Idle Control System RPM Lower Than Expected (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Check for a poor connection at the IAC harness connector. 2. If a problem is found, replace faulty terminals as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	Using a Digital Voltmeter (DVM), check the IAC valve solenoids (A and B) for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground (the IAC body) <input type="radio"/> A short together Was the problem found?	—	—	—
9	Replace the IAC valve. Is the action complete?	—	Verify repair	—
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0507 IDLE CONTROL SYSTEM RPM HIGHER THAN EXPECTED



D06RX041

Circuit Description

The powertrain control module (PCM) controls engine idle speed by adjusting the position of the idle air control (IAC) motor pintle. The IAC is a bi-directional stepper motor driven by two coils. The PCM applies current to the IAC coils in steps (counts) to extend the IAC pintle into a passage in the throttle body to decrease air flow. The PCM reverses the current to retract the pintle, increasing air flow. This method allows highly accurate control of idle speed and quick response to changes in engine load. If the PCM detects a condition where too high of an idle speed is present and the PCM is unable to adjust idle speed by increasing the IAC counts, Diagnostic Trouble Code P0507 will set, indicating a problem with the idle control system. DTC P0507 is a type B code.

Conditions for Setting the DTC

- No intrusive tests being run.
- Engine run time is more than 125 seconds.
- No TPS, VSS, ECT, EGR, MAP, IAT, misfire, low voltage, fuel system or canister purge DTCs are set.
- Barometric pressure is greater than 72.7 kPa.
- Canister purge duty cycle is above 0%.
- Intake air temperature above -40°C (-40°F).
- Engine coolant temperature (ECT) is above 50°C (122°F).
- Ignition voltage is between 9.5 volts and 16 volts.

- The throttle is closed.
- All conditions are met for 10 seconds.
- MAP is less than 60 kPa.
- Engine speed is at least 200 RPM lower than desired idle, based upon PCM's expectations.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0507 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0507 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM or IAC motor – Inspect harness connectors for backed-out terminals,

improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits.
- Vacuum leak – Check for a condition that causes a vacuum leak, such as disconnected or damaged hoses, leaks at EGR valve and EGR pipe to intake manifold, leak at the throttle body, a faulty or incorrectly installed PCV valve, leaks at the intake manifold, etc.

- Throttle body – Check for sticking throttle plate. Also inspect the IAC passage for deposits or objects which will not allow the IAC pintle to fully extend or properly seat.

If Diagnostic Trouble Code P0507 cannot be duplicated, reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


DTC P0507 – Idle Control System RPM Higher Than Expected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any other Diagnostic Trouble Codes set?	—	Go to other Diagnostic Trouble Code first	Go to Step 3
3	1. Start the engine. 2. Turn all accessories OFF (A/C, rear defroster, etc.) 3. Using a Tech 2, command RPM up to 1500, down to 500, and then up to 1500 while monitoring "Engine Speed" on the Tech 2. Does the "Engine Speed" remain within the specified value of "Desired Idle" for each RPM command?	+/-50 RPM	No trouble found. Go to Diagnostic Aids	Go to Step 4
4	1. Disconnect the IAC. 2. Install IAC Noid Light J 37027A or equivalent. 3. With the engine running, command RPM up to 1500, down to 500, and then up to 1500 while observing the noid light. Does each noid light cycle red and green (never OFF)?	—	Go to Step 6	Go to Step 5
5	1. Check the following circuits for an open, short to voltage, short to ground, or poor connection at the PCM: ○ IAC "A" low ○ IAC "A" high ○ IAC "B" low ○ IAC "B" high 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
6	Visually/physically inspect for the following conditions: ○ Vacuum leaks ○ Throttle body tampering (adjustment screw plug removed). ○ Throttle plate or throttle shaft for binding. ○ Accelerator and cruise control cables for being mis-adjusted or for binding. ○ Faulty, missing, or incorrectly installed PCV valve. Do any of the above require a repair?	—	Refer to appropriate section for on-vehicle service	Go to Step 7

DTC P0507 – Idle Control System RPM Higher Than Expected (Cont'd)

Step	Action	Value(s)	Yes	No
7	<p>1. Check for a poor connection at the IAC harness connector.</p> <p>2. If a problem is found, replace faulty terminals as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 8
8	<p>Using a Digital Voltmeter (DVM), check the IAC valve solenoids (A and B) for the following conditions:</p> <ul style="list-style-type: none"> <input type="radio"/> An open circuit <input type="radio"/> A short to ground (the IAC body) <input type="radio"/> A short together <p>Was the problem found?</p>	—	Go to Step 9	Go to Step 10
9	<p>Replace the IAC valve.</p> <p>Is the action complete?</p>	—	Verify repair	—
10	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0532 A/C REFRIGERANT PRESSURE SENSOR CIRCUIT LOW INPUT



D06RX060

Circuit Description

The Powertrain Control Module (PCM) monitors the A/C refrigerant pressure through the use of a three wire sensor. If the PCM senses the pressure falls below a threshold value, then DTC P0532 will set. DTC P0532 is a type D code.

Conditions for Setting the DTC

- A/C pressure sensor is below 5 counts (0.1 volt) for 125 seconds within a 250 seconds test sample.

Action Taken When the DTC Sets

- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the DTC

- A History DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using a Scan Tool's "Clear Info" function.

Diagnostic Aids

Poor Conditions, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also, check for open circuits, shorts to ground, and shorts to voltage.


DTC P0532 A/C Refrigerant Pressure Sensor Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Scan Tool's Failure Records data, then clear the DTC's. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0532. Does the Tech 2 indicate DTC P0532 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Disconnect the A/C refrigerant pressure sensor wiring harness connector from the A/C refrigerant pressure sensor. 3. Start the vehicle, and monitor the A/C refrigerant pressure value with the Tech 2. Does the A/C refrigerant pressure sensor value on the Tech 2 hold steadily at the given value?	less than 0.1 volts	Go to Step 5	Go to Step 4
4	Check the A/C refrigerant pressure sensor signal circuit, between the A/C refrigerant pressure sensor and the Powertrain Control Module (PCM), for a short to voltage. Was the problem found?	—	Verify repair	Go to Step 12
5	Check the A/C refrigerant pressure sensor signal circuit, between the A/C refrigerant pressure sensor and the PCM for the following conditions: ○ A short to ground ○ An open circuit Was the problem found?	—	Verify repair	Go to Step 6
6	Check the 5 volt signal circuit, between the A/C refrigerant pressure sensor and the PCM, for the following conditions: ○ An open circuit ○ A short to voltage ○ A short to ground Was the problem found?	—	Verify repair	Go to Step 7
7	1. Ignition OFF. 2. Place a Digital Voltmeter (DVM), set to measure voltage between the 5 volt signal circuit and ground. 3. Ignition ON, Engine OFF. Does the DVM indicate the following value?	about 5 volts	Go to Step 8	Go to Step 12

DTC P0532 A/C Refrigerant Pressure Sensor Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition OFF. 2. Place a fused jumper between the A/C refrigerant pressure sensor and the 5 volt signal circuit, both at the wiring harnesses A/C refrigerant pressure sensor connector. 3. Ignition ON, Engine OFF. 4. Observe the A/C refrigerant pressure sensor value displayed on the Tech 2. Does the Tech 2 read the following value?	about 5 volts	Go to Step 9	Go to Step 12
9	Check the A/C refrigerant pressure sensor and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 10
10	1. Ignition OFF. 2. Place a Digital Voltmeter (DVM), set to measure voltage between the ground circuit and the 5 volt signal circuit, both at the wiring harnesses A/C refrigerant pressure sensor connector. 3. Ignition ON, Engine OFF. Does the DVM indicate the following value?	about 5 volts	Go to Step 11	Go to Step 12
11	Replace the A/C refrigerant pressure sensor. Verify Repair.	—	—	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0533 A/C REFRIGERANT PRESSURE SENSOR CIRCUIT HIGH INPUT



D06RX060

Circuit Description

The Powertrain Control Module (PCM) monitors the A/C refrigerant pressure through the use of a three wire sensor. If the PCM senses the pressure falls below a threshold value, then DTC P0533 will set. DTC P0533 is a type D code.

Conditions for Setting the DTC

- A/C pressure sensor is above 250 counts (4.88 volts) for 125 seconds within a 250 seconds test sample.

Action Taken When the DTC Sets

- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the DTC

- A history DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using a Scan Tool's "Clear Info" function.

Diagnostic Aids

- Poor Conditions, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also, check for open circuits, shorts to ground, and shorts to voltage.


DTC P0533 A/C Refrigerant Pressure Sensor Circuit High Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Scan Tool's Failure Records data, then clear the DTC's. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P0533. Does the Tech 2 indicate DTC P0533 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Disconnect the A/C refrigerant pressure sensor wiring harness connector from the A/C refrigerant pressure sensor. 3. Start the vehicle, and monitor the A/C refrigerant pressure value with the Tech 2. Does the A/C refrigerant pressure sensor value on the Tech 2 hold steadily at the given value?	less than 0.1 volts	Go to Step 5	Go to Step 4
4	Check the A/C refrigerant pressure sensor signal circuit, between the A/C refrigerant pressure sensor and the Powertrain Control Module (PCM), for a short to voltage. Was the problem found?	—	Verify repair	Go to Step 12
5	Check the A/C refrigerant pressure sensor signal circuit, between the A/C refrigerant pressure sensor and the PCM for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit Was the problem found?	—	Verify repair	Go to Step 6
6	Check the 5 volt signal circuit, between the A/C refrigerant pressure sensor and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to voltage <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	Go to Step 7
7	1. Ignition OFF. 2. Place a Digital Voltmeter (DVM), set to measure voltage between the 5 volt signal circuit and ground. 3. Ignition ON, Engine OFF. Does the DVM indicate the following value?	about 5 volts	Go to Step 8	Go to Step 12

DTC P0533 A/C Refrigerant Pressure Sensor Circuit High Input (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition OFF. 2. Place a fused jumper between the A/C refrigerant pressure sensor and the 5 volt signal circuit, both at the wiring harnesses A/C refrigerant pressure sensor connector. 3. Ignition ON, Engine OFF. 4. Observe the A/C refrigerant pressure sensor value displayed on the Tech 2. Does the Tech 2 read the following value?	about 5 volts	Go to Step 9	Go to Step 12
9	Check the A/C refrigerant pressure sensor and the PCM, for the following conditions: <input type="radio"/> An open circuit <input type="radio"/> A short to ground <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 10
10	1. Ignition OFF. 2. Place a Digital Voltmeter (DVM), set to measure voltage between the ground circuit and the 5 volt signal circuit, both at the wiring harnesses A/C refrigerant pressure sensor connector. 3. Ignition ON, Engine OFF. Does the DVM indicate the following value?	about 5 volts	Go to Step 11	Go to Step 12
11	Replace the A/C refrigerant pressure sensor. Verify Repair.	—	—	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P0562 SYSTEM VOLTAGE LOW



Circuit Description

The powertrain control module (PCM) monitors the system voltage on the ignition feed terminal to the PCM. A system voltage Diagnostic Trouble Code will set whenever the voltage is below a calibrated value. DTC P0562 is a type D code.

Conditions for Setting the DTC

- ☐ Ignition ON.
- ☐ System voltage is below 11.5 volts for 4 minutes.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store as Failure Records conditions which were present when the Diagnostic Trouble Code was set. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC


- A history Diagnostic Trouble Code P0562 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0562 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- If the Diagnostic Trouble Code sets when an accessory is operated, check for a poor connection or excessive current draw.
- Check for an open circuit in the PCM main relay's control (ground) circuit.
- Check for open circuits or shorts to ground on the PCM's battery or ignition inputs.
- Check for a faulty PCM main relay.

DTC P0562 System Voltage Low

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Using a Digital Voltmeter (DVM), measure the battery voltage at the battery. Is the battery voltage greater than the specified value?	11.5 V	Go to Step 3	Charge battery, then go to Step 3
3	1. Install the Tech 2. 2. Select "Ignition Volts" on the Tech 2. 3. Start the engine and raise the engine speed to 2000 RPM. 4. Load the electrical system by turning on the headlights, high blower, etc. Is the ignition voltage approximately equal to the specified value?	13.2 V	Go to Step 4	Go to Starting/Charging
4	1. Ignition OFF. 2. Disconnect the PCM connector at the PCM. 3. Ignition ON, Engine OFF 4. Using a DVM, measure the voltage at the PCM Main Relay's two power inputs to the PCM. Is it approximately equal to battery voltage?	—	Check for excessive current draw with ignition OFF, engine OFF.	Go to Step 5
5	1. Check for faulty connections at the PCM harness terminals. 2. Repair as necessary. Was a repair necessary?	—	Verify repair	Go to Step 6
6	Check for an open battery feed circuit to the PCM. Is the action complete?	—	Verify repair	Go to Step 7
7	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0563 SYSTEM VOLTAGE HIGH

D06RX061

Circuit Description

The powertrain control module (PCM) monitors the system voltage on the ignition feed terminals to the PCM. A system voltage Diagnostic Trouble Code will set whenever the voltage is above a calibrated value. DTC P0563 is a type A code.

Conditions for Setting the DTC

- Ignition ON.
- System voltage is above 16.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL) for the first time the malfunction is detected.
- The PCM will store as Failure Records conditions which were present when the Diagnostic Trouble Code was set. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history Diagnostic Trouble Code P0563 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0563 can be cleared by using the Scan Tool's "Clear Info" function.


Diagnostic Aids

Check for a faulty charging system components.

DTC P0563 System Voltage High

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition OFF, engine OFF. 2. Using a Digital Voltmeter (DVM), measure the battery voltage at the battery. Is the battery voltage greater than the specified value?	16 V	Go to Step 3	Go to Step 4
3	1. Charge the battery and clean the battery terminals. 2. Clean the battery ground cable connection if corrosion is indicated. Is the battery voltage greater than the specified value?	16 V	Replace battery	Go to Step 4
4	1. Turn OFF all the accessories. 2. Install the Tech 2. 3. Select the ignition voltage parameter on the data list. 4. Start the engine and raise the engine speed to 2000 RPM. Is the voltage above the specified value?	16 V	Go to Step 5	Go to Step 6
5	Replace or repair the generator (see Charging System). Is a malfunction present?	—	Verify repair	—
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P0601 INTERNAL CONTROL MODULE MEMORY CHECK SUM ERROR



014RX002

Circuit Description

The powertrain control module (PCM) used in this vehicle utilizes an electrically erasable programmable read-only memory (EEPROM). The EEPROM contains program information and the calibrations required for engine, transmission, and powertrain diagnostics operation. Unlike the PROM used in past applications, the EEPROM is not replaceable. When the PCM is replaced or a calibration update is required, the PCM must be programmed using a Tech 2. For the EEPROM programming procedure, Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. If the PCM detects a check sum error then DTC P0601 will set. DTC P0601 is a type A code.

Conditions for Setting the DTC

- The PCM detects an internal program fault (check sum error).

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the malfunction is detected.

- The PCM will store conditions which were present when the Diagnostic Trouble Code was set in the Failure Records data only.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P0601 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P0601 can be cleared by using the Scan Tool's "Clear Info" function.


Diagnostic Aids

- Diagnostic Trouble Code P0601 indicates that the contents of the EEPROM have changed since the PCM was programmed. The only possible repair is PCM reprogramming or replacement. Check service bulletins to program the replacement PCM with the correct software and calibration for the vehicle.

DTC P0601 Internal Control Module Memory Check Sum Error

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Reprogram PCM with most recent calibrations. Refer to Service Bulletins and PCM Reprogramming. Is there still a problem?	—	Go to Step 3	Verify repair
3	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1106 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE



D06RX042

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure. The MAP sensor signal voltage to the PCM varies from below 2 volts at idle (low manifold pressure) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (high manifold pressure).

A "speed density" method of determining engine load is used on the 2.2L engine. This is calculated using inputs from the MAP sensor, RPM, the CKP sensor, and the Intake Air Temperature (IAT) sensor. The MAP sensor is the main sensor used in this calculation, and measuring engine load is its main function.

The MAP sensor is also used to determine manifold pressure changes while the linear EGR flow test diagnostic is being run, to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). Refer to Diagnostic Trouble Code 401. The PCM compares the MAP sensor signal to a calculated MAP based on throttle position and various other engine load factors. If the PCM detects a MAP signal that is intermittently above the calculated value, Diagnostic Trouble Code P1106 will set. DTC P1106 is a type D code.

Conditions for Setting the DTC

- No TP sensor Diagnostic Trouble Codes are present.
- Engine is running.

- Throttle angle is below 2.7% if engine speed is below 1000 RPM.
- Throttle angle is below 10% if engine speed is above 1000 RPM.
- The MAP sensor indicates an intermittent manifold absolute pressure above 90 kPa for a total of approximately 5 seconds over a 16-second period of time.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1106 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1106 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Leaking or plugged vacuum supply line to the MAP sensor.
- Inspect PCM harness connectors for backed-out terminals, improper mating, broken locks, improperly

formed or damaged terminals, and poor terminal-to-wire connection.

- The MAP sensor shares a 5 Volt Reference with the TP sensor and Fuel Pressure sensor.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.

- The MAP sensor shares a ground with the TP sensor and Fuel Pressure sensor.
- Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If


the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

DTC P1106 – MAP Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0108 also set?	—	Go to DTC P0108 chart first	Go to Step 3
3	Are Diagnostic Trouble Code P0463, and/or P1121 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor sensor ground circuit terminal connection at the MAP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the MAP signal circuit between the MAP sensor connector and the PCM for an intermittent short to voltage. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to voltage on the 5 volt reference circuit between the PCM and the following components: ○ Fuel Tank Vapor Pressure Sensor ○ TP sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor sensor ground circuit terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the sensor ground circuit. Was a problem found? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to Diagnostic Aids
9	Replace the faulty harness connector terminal for the sensor ground circuit. Is the action complete?	—	Verify repair	—
10	Locate and repair the intermittent open/short circuit in the wiring harness as necessary. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1107 MANIFOLD ABSOLUTE PRESSURE (MAP) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE



D06RX042

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure. The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (low manifold pressure) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (high manifold pressure).

A "speed density" method of determining engine load is used on the 2.2L engine. This is calculated using inputs from the MAP sensor, the CKP sensor, and the Intake Air Temperature (IAT) sensor. The MAP sensor is the main sensor used in this calculation, and measuring engine load is its main function.

The MAP sensor is also used to determine manifold pressure changes while the linear EGR flow test diagnostic is being run, to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). Refer to DTC P0401.

The PCM compares the MAP sensor signal to a calculated MAP based on throttle position and various other engine load factors. If the PCM detects a MAP signal that is intermittently below the calculated value, DTC P1107 will set. DTC P1107 is a type D code.

Conditions for Setting the DTC

- No TP sensor Diagnostic Trouble Codes are present.
- Engine is running.

- Throttle angle is below 0% if engine speed is less than 1300 RPM.
- Throttle angle is below 5% if engine speed is above 1300 RPM.
- The MAP sensor indicates an intermittent manifold absolute pressure above 11 kPa for a total of approximately 5 seconds over a 16-second period of time.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1107 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1107 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken

locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- The MAP sensor shares a 5 Volt Reference with the TP sensor and Fuel Pressure sensor.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.

- The MAP sensor shares a ground with the TP sensor and Fuel Pressure sensor.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive,


and open circuits. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

DTC P1107 – MAP Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0107 also set?	—	Go to DTC P0107 chart first	Go to Step 3
3	Is DTC P1122 and/or P0462 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor 5 volt reference circuit terminal connection at the MAP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the MAP signal circuit between the MAP sensor connector and the PCM for an intermittent open or short to ground. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to ground on the 5 volt reference circuit between the PCM and the following components: ○ Fuel Tank Vapor Pressure Sensor ○ TP sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor 5 volt reference terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the 5 volt reference circuit. Was a problem found? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to Diagnostic Aids
9	Replace the faulty harness connector terminal for the 5 volt reference circuit and/or the MAP signal circuit as necessary. Is the action complete?	—	Verify repair	—
10	Repair the intermittent open/short circuit in the wiring harness as necessary. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1111 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE



D06RX043

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance is lower causing the PCM to monitor a lower voltage. Diagnostic Trouble Code P1111 will set when the PCM intermittently detects an excessively high signal voltage on the intake air temperature sensor signal circuit. DTC P1111 is a type D code.

Conditions for Setting the DTC

- The engine has been running for over 4 minutes.
- Vehicle speed is less than 32 km/h (20 mph).
- Engine coolant temperature is above 60°C (140°F).
- Calculated air flow is less than 20g/second.
- IAT signal voltage indicates an intake air temperature intermittently less than -39°C (-38°F) (4.94 volts) for approximately 2.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will substitute a default value for intake air temperature.

- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Failure Records data only. This information will not be stored as Freeze Frame data.
- Diagnostic Trouble Code P1111 does not illuminate the MIL.

Conditions for Clearing the DTC

- A history DTC P1111 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1111 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to

be set occurs. This may assist in diagnosing the condition.


Intake Air Temperature Sensor

°C	°F	Ω
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1111 – IAT Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0113 also set?	—	Go to DTC P0113 chart first	Go to Step 3
3	1. Check for a poor sensor ground circuit terminal connection at the IAT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 4
4	1. Check for a poor IAT signal circuit terminal connection at the IAT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Check the IAT signal circuit between the IAT sensor connector and the PCM for an intermittent open. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Check the IAT signal circuit between the IAT sensor connector and the PCM for an intermittent short to voltage. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Check for a poor sensor ground circuit terminal connection at the PCM. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Check for an intermittent open or a faulty splice in the sensor ground circuit. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P1112 INTAKE AIR TEMPERATURE (IAT) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE



D06RX043

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance becomes lower, causing the PCM to monitor a lower voltage. Diagnostic Trouble Code P1112 will set when the PCM intermittently detects an excessively low signal voltage on the intake air temperature sensor signal circuit. DTC P1112 is a type D code.

Conditions for Setting the DTC

- The engine has been running for over 2 minutes.
- Vehicle speed is greater than 48 km/h (30 mph).
- IAT signal voltage is greater than 148°C (298°F) (about 0.10 volt) for a total of 2.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Failure

Records data only. This information will not be stored as Freeze Frame data.

- The PCM will substitute a default value for intake air temperature.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1112 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1112 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to

6E1-310 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

- Verifies that the fault is present.
- If DTC P1112 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Value Chart."

The chart may be used to test the IAT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be shorted above or below a certain temperature. If this is the case, replace the IAT sensor.


Intake Air Temperature Sensor

°C	°F	Ω
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1112 – IAT Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0112 also set?	—	Go to DTC P0112 chart first	Go to Step 3
3	1. Check the IAT signal circuit between the IAT sensor connector and the PCM for an intermittent short to ground. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P1114 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE



D06RX044

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in the engine coolant stream. The powertrain control module (PCM) applies a voltage (about 5.0 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes less, and the ECT signal voltage measured at the PCM drops. With a fully warmed up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts. If the PCM detects an ECT signal that is intermittently below the range of the ECT sensor, Diagnostic Trouble Code P1114 will set. DTC P1114 is a type D code.

Conditions for Setting the DTC

- Engine run time longer than 2 minutes.
- The ECT sensor signal is intermittently greater than 150°C (302°F) (about 0.10 volt) for a total of 10 seconds over a 100-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Failure

Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1114 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1114 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


Engine Coolant Temperature Sensor

°C	°F	Ω
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1114 – ECT Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0117 also set?	—	Go to DTC P0117 first	Go to Step 3
3	1. Check the ECT signal circuit between the ECT sensor connector and the PCM for an intermittent short to ground. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P1115 ENGINE COOLANT TEMPERATURE (ECT) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE



Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in the engine coolant stream. The powertrain control module (PCM) applies a voltage (about 5.0 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes less, and the ECT signal voltage measured at the PCM drops. With a fully warmed up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts. If the PCM detects an ECT signal that is intermittently above the range of the ECT sensor, Diagnostic Trouble Code P1115 will set. Diagnostic Trouble Code P1115 is a type D code.

Conditions for Setting the DTC

- Engine run time longer than 180 seconds.
- The ECT sensor signal is intermittently greater than -39°C (-38°F) (4.94 volts) for a total of 10 seconds over a 100-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Failure

Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1115 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1115 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.


Engine Coolant Temperature Sensor

°C	°F	Ω
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1115 ECT Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0118 also set?	—	Go to DTC P0118 first	Go to Step 3
3	1. Check for a poor sensor ground circuit terminal connection at the ECT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 4
4	1. Check for a poor ECT signal circuit terminal connection at the ECT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Check the ECT signal circuit between the ECT sensor connector and the PCM for an intermittent open. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Check the ECT signal circuit between the ECT sensor connector and the PCM for an intermittent short to voltage. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Check for a poor sensor ground circuit terminal connection at the PCM. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Check for an intermittent open or a faulty splice in the sensor ground circuit. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to Diagnostic Aids

DIAGNOSTIC TROUBLE CODE (DTC) P1121 THROTTLE POSITION (TP) SENSOR CIRCUIT INTERMITTENT HIGH VOLTAGE



D06RX045

Circuit Description

The throttle position (TP) sensor circuit provides a voltage signal that changes relative to the throttle blade angle. The signal voltage will vary from less than 1 volt at closed throttle to more than 4 volts at wide open throttle (WOT). The TP signal is used by the powertrain control module (PCM) for fuel control and for most of the PCM controlled outputs. If the PCM detects a TP signal that is intermittently above the range of the TP sensor, Diagnostic Trouble Code P1121 will be set. DTC P1121 is a type D code.

Conditions for Setting the DTC

- The ignition is ON.
- TP sensor indicates a throttle position voltage intermittently greater than 4.88 volts for a total of 0.15 seconds over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1121 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1121 can be cleared by using the Scan Tool's "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The TP sensor shares a 5 Volt reference with the MAP sensor and Fuel Pressure sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The TP sensor share a ground with the MAP and the Fuel Pressure sensor.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the throttle position display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.


If Diagnostic Trouble Code P1121 cannot be duplicated, reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help to determine how often

the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

DTC P1121 – TP Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is Diagnostic Trouble Code P0123 also set?	—	Go to DTC P0123 first	Go to Step 3
3	Is Diagnostic Trouble Code P0463 and/or P1106 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor sensor ground circuit terminal connection at the TP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the TP signal circuit between the TP sensor connector and the PCM for an intermittent short to voltage. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to voltage on the 5 volt reference circuit between the PCM and the following components: ○ MAP Sensor ○ Fuel Tank Vapor Pressure Sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor sensor ground terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the sensor ground circuit. Was a problem found? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to Diagnostic Aids
9	Replace the faulty harness connector terminal for the sensor ground circuit. Is the action complete?	—	Verify repair	—
10	Repair intermittent open/short circuit in wiring harness as necessary. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1122 THROTTLE POSITION (TP) SENSOR CIRCUIT INTERMITTENT LOW VOLTAGE



D06RX045

Circuit Description

The throttle position (TP) sensor circuit provides a voltage signal that changes relative to the throttle blade angle. The signal voltage will vary from less than 1 volt at closed throttle to more than 4 volts at wide open throttle (WOT). The TP signal is used by the powertrain control module (PCM) for fuel control and for most of the PCM controlled outputs. If the PCM detects a TP signal that is intermittently above the range of the TP sensor, Diagnostic Trouble Code P1122 will be set. DTC P1122 is a type D code.

Conditions for Setting the DTC

- The ignition is ON.
- TP sensor indicates a throttle position signal intermittently less than 0.10 volt for a total of 0.15 seconds over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the Diagnostic Trouble Code set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history Diagnostic Trouble Code P1122 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1122 can be cleared by using the Scan Tool's "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the throttle position display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.
- The TP sensor shares a 5 Volt reference with the MAP sensor and Fuel Pressure sensor.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.

- The TP sensor share a ground with the MAP and the Fuel Pressure sensor.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help to determine how often the condition that caused the Diagnostic Trouble Code to

be set occurs. This may assist in diagnosing the condition.

DTC P1122 – TP Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0122 also set?	—	Go to DTC P0122 first	Go to Step 3
3	Is DTC P1107 and/or P0462 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor 5 volt reference circuit or TP signal circuit terminal connection at the TP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the TP signal circuit between the TP sensor connector and the PCM for an intermittent short to ground. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to ground on the 5 volt reference circuit between the PCM and the following components: ○ Fuel Tank Vapor Pressure Sensor ○ MAP Sensor Was a problem found?	—	Go to Step 9	Go to Step 8
7	Check for a poor 5 volt reference circuit terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the 5 volt reference circuit. Was a problem found? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to Diagnostic Aids
9	Replace the faulty harness connector terminal(s) for the 5 volt reference circuit and/or the TP signal circuit as necessary. Is the action complete?	—	Repair complete. If a driveability symptom still exists, refer to Symptoms.	—
10	Repair intermittent open/short circuit in wiring harness as necessary. Is the action complete?	—	Repair complete. If a driveability symptom still exists, refer to Symptoms.	—

DIAGNOSTIC TROUBLE CODE (DTC) P1133 O2 SENSOR INSUFFICIENT SWITCHING (BANK 1 SENSOR 1)



D06RX046

Circuit Description

The powertrain control module (PCM) monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "Closed Loop" has been enabled. During this test period the PCM counts the number of times that the HO2S signal voltage crosses the rich-to-lean and lean-to-rich threshold. If the PCM determines that the HO2S did not switch enough times, Diagnostic Trouble Code P1133 will be set.

A lean-to-rich switch is determined when the HO2S voltage changes above and below 450 mV. DTC P1133 is a type B code.

Conditions for Setting the DTC

- Engine coolant temperature (ECT) is above 60°C (140°F).
- Engine is operating in "Closed Loop".
- The engine has been running for at least two minutes.
- Canister purge duty cycle is greater than 2%.
- Calculated air flow between 17 and 32 grams/sec.
- Engine speed is between 1500 RPM and 3500 RPM.
- Above conditions are present for 1 second.
- 90 seconds after "Closed Loop" and has been achieved, the PCM monitors the oxygen sensor as it switches above and below 450 mV. If fewer than 12 rich-to-lean and 12 lean-to-rich switches are detected, Diagnostic Trouble Code P1133 will be set.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- "Open Loop" fuel control will be in effect.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P1133 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1133 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

A malfunction in the HO2S heater ignition feed or ground circuit may cause a Diagnostic Trouble Code P1133 to set. Check HO2S heater circuitry for intermittent faults or poor connections. If connections and wiring are OK and Diagnostic Trouble Code P1133 continues to set, replace the Bank 1 HO2S 1.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help to determine how often

the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. A condition that affects other heated oxygen sensors indicates probable contamination. To avoid damaging the replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

5. This step checks for conditions which may cause the heated oxygen sensor to appear faulty. Correct any of the described conditions if present.

11. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

DTC P1133 – O2 Sensor Insufficient Switching (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	IMPORTANT: If any Diagnostic Trouble Codes are set refer to those Diagnostic Trouble Codes before proceeding with this diagnostic chart. 1. Engine idling at operating temperature. 2. Operate the vehicle within parameters specified under "Conditions for Setting the Diagnostic Trouble Code" criteria. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P1133 until the Diagnostic Trouble Code P1133 test runs. 4. Note the test result. Does the Tech 2 indicate Diagnostic Trouble Code P1133 failed this ignition?	—	Go to Step 3	Refer to Diagnostic Aids
3	Did the Tech 2 also indicate that the P1153 or P1154 tests failed?	—	Go to Step 11	Go to Step 4
4	1. Perform the "Exhaust System Leak Test" (refer to Exhaust System). After the "Exhaust System Leak Test" has been performed, return to this diagnostic. 2. If an exhaust leak is found, repair as necessary. Was an exhaust leak isolated?	—	Go to Step 2	Go to Step 5
5	Visually/physically inspect the following items: ○ Ensure that the Bank 1 HO2S 1 is securely installed. ○ Check for corrosion on the terminals. ○ Check the terminals at Bank 1 HO2S 1 and at the PCM. ○ Check for damaged wiring; shorts to ground, shorts to battery positive, and open circuits. Was a problem found in any of the above areas?	—	Verify repair	Go to Step 6
6	1. Disconnect Bank 1 HO2S 1. 2. Ignition ON. 3. Using a Digital Voltmeter (DVM) at the PCM side of the connector, check the voltage between the high signal circuit and ground. Also measure between the low signal circuit and ground. Are both voltages in the specified range?	3–4 mV	Go to Step 9	Go to Step 7

DTC P1133 – O2 Sensor Insufficient Switching (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition OFF. 2. Check for damage to PCM pins or terminals. Was a problem found?	—	Verify repair	Go to Step 8
8	Check for a short to voltage or ground or an open in the signal circuit. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Ignition OFF. 2. Disconnect the PCM connector. 3. With the HO2S disconnected, check for high and low signal circuits shorted together between the PCM and HO2S. Was a problem found?	—	Verify repair	Go to Step 10
10	With the PCM connected and Bank 1 HO2S 1 disconnected from the harness, check Bank 1 HO2S 1 with a Tech 2. Is the voltage in the specified range?	430–470 mV	Go to Step 11	Go to Step 12
11	Replace the affected heated oxygen sensors. NOTE: Before replacing the sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination. ○ Use of improper RTV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—



A malfunction in the HO2S heater ignition feed or ground circuit may cause a Diagnostic Trouble Code P1133 to set. Check HO2S heater circuitry for intermittent faults or poor connections. If connections and wiring are OK and

6E1-324 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Diagnostic Trouble Code P1134 continues to set, replace the Bank 1 HO2S 1.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the Diagnostic Trouble Code to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

3. A condition that affects other heated oxygen sensors indicates probable contamination. To avoid damaging the replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

5. This step checks for conditions which may cause the heated oxygen sensor to appear faulty. Correct any of the described conditions if present.

11. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.


DTC P1134 – O2 Sensor Transition Time Ratio (Bank 1 Sensor 1)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	IMPORTANT: If any DTCs are set refer to those DTCs before proceeding with this diagnostic chart. 1. Idle the engine at operating temperature. 2. Operate the vehicle within parameters specified under "Conditions for Setting the Diagnostic Trouble Code" criteria included in Diagnostic Support. 3. Using a Tech 2, monitor "Diagnostic Trouble Code" info for Diagnostic Trouble Code P1134 until the Diagnostic Trouble Code P1134 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P1134 failed this ignition?	—	Go to Step 3	Refer to Diagnostic Aids
3	1. Perform the "Exhaust System Leak Test" (refer to Exhaust System). After the "Exhaust System Leak Test" has been performed, return to this diagnostic. 2. If an exhaust leak is found, repair as necessary. Was an exhaust leak isolated?	—	Verify repair	Go to Step 4
4	Visually/physically inspect the following items: <ul style="list-style-type: none">○ Ensure that the Bank 1 HO2S 1 is securely installed.○ Check for corrosion on the terminals.○ Check the terminals at Bank 1 HO2S 1 and at the PCM.○ Check for damaged wiring; shorts to ground, shorts to battery positive, and open circuits. Was a problem found in any of the above areas?	—	Go to Step 7	Go to Step 5
5	1. Disconnect Bank 1 HO2S 1. 2. Ignition ON. 3. Using a Digital Voltmeter (DVM) at the PCM side of the connector, check the voltage between the high signal circuit and ground. Also measure between the low signal circuit and ground. Are both voltages in the specified range?	3-4 V	Go to Step 6	Go to Step 8

DTC P1134 – O2 Sensor Transition Time Ratio (Bank 1 Sensor 1) (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. With Bank 1 HO2S 1 disconnected, jumper the high and low (PCM side) signal circuits to ground. 2. Ignition ON. 3. Using a Tech 2, monitor the Bank 1 HO2S 1 voltage. Does the Tech 2 indicate less than 10 mV and immediately return to about 450 mV when the jumper is removed?	—	Go to Step 10	Go to Step 11
7	Repair condition as necessary. Is the action complete?	—	Verify repair	—
8	Check for faulty PCM connections or terminal damage. Is the action complete?	—	Verify repair	Go to Step 9
9	Repair open, short or grounded signal circuit. Is the action complete?	—	Verify repair	Go to Step 6
10	Remove the Bank 1 HO2S 1 and examine it for signs of: ○ Fuel contamination; ○ Improper RTV sealant (white powdery coating on sensor); ○ Engine oil/coolant consumption. Were signs of contamination observed?	—	Go to Step 13	Go to Step 12
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the repair complete?	—	Verify repair	—
12	Replace the Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1171 FUEL SYSTEM LEAN DURING ACCELERATION



D06RX048

Circuit Description

The powertrain control module (PCM) internal circuitry can identify if the vehicle fuel system is capable of supplying adequate amounts of fuel during heavy acceleration (power enrichment). The PCM monitors the voltage of the oxygen sensor during power enrichment. When a power enrichment mode of operation is requested during "Closed Loop" operation (by heavy acceleration), the PCM will provide more fuel to the engine. Under these conditions the PCM should detect a "rich" condition (high oxygen sensor voltage). If this "rich" exhaust is not detected at this time, a Diagnostic Trouble Code P1171 will set. A plugged fuel filter or restricted fuel line can prevent adequate amounts of fuel from being supplied during power enrichment mode. DTC P1171 is a type A code.

Conditions for Setting the DTC

- No related Diagnostic Trouble Codes.
- Engine is operating in "Closed Loop".
- Engine coolant temperature is above 60°C (140°F).
- While in "power enrichment" mode the oxygen sensor voltage remains below 400 mV for 3 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the Diagnostic Trouble Code was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history Diagnostic Trouble Code P1171 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Diagnostic Trouble Code P1171 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

- A restricted fuel filter or fuel line can supply adequate amounts of fuel at idle, but may not be able to supply enough fuel during heavy acceleration.
- Water or alcohol in the fuel may cause low HO₂S voltage during acceleration.
- Check for faulty or plugged fuel injector(s).
- Check for low fuel.

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart:

4. When the engine is idling or at steady cruise, the HO2S voltage should vary from between approximately 100 mV to 900 mV. During "power enrichment" mode, more fuel is needed and the HO2S voltage should rise above 447 mV. This step checks to see if the HO2S is operating properly.
5. Wrap a shop towel around the fuel pressure connector to absorb any small amount of fuel leakage that may occur when installing the gauge. Ignition ON, pump pressure should be 235-320 kPa.
7. Add Caution: Use correct pliers so damage to fuel lines will not occur.

DTC P1171 – Fuel System Lean During Acceleration

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Are any component-related Diagnostic Trouble Codes set?	—	Go to component DTC charts	Go to Step 3
3	1. Check the vehicle's fuel tank for an adequate amount of fuel. 2. Add fuel to the vehicle's fuel tank if the tank is almost empty. Was fuel added to the vehicle's fuel tank?	—	Go to Step 4	Go to Step 5
4	1. Using a Tech 2, observe HO2S 1 voltage while running warm engine(75°C–95°C [167°F–203°F]) at 1200 RPM. 2. HO2S 1 voltage should vary within the specified range. Does the voltage toggle back and forth within the specified range?	100– 900 mV	Go to Diagnostic Aids	Go to Step 5
5	1. Disconnect the fuel pump relay and crank the engine to relieve the fuel pressure. 2. Install the fuel pressure gauge. 3. Start the engine and idle at normal operating temperature. 4. Disconnect the vacuum line going to the fuel pressure regulator. With the engine running, is the fuel pressure within the specified range?	284– 325 kPa	Go to OBD System Check	Go to Step 6
6	Check for restricted fuel lines or restricted in-line filter. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Ignition OFF. 2. Ignition ON, engine OFF. 3. Using a Tech 2, enable the fuel pump to operate. 4. Using pliers, slowly close the return line (do not exceed the first specified value). Using the pliers, can the fuel pressure be manipulated to exceed the second specified value?	414 kPa 325 kPa	Go to Diagnostic Aids	Go to Step 8
8	Check for: ○ Faulty fuel pump ○ Restricted fuel pump strainer (sock) ○ Incorrect fuel pump ○ Incorrect fuel being used ○ Hot fuel	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1336 CRANKSHAFT POSITION SENSOR (CKP) SYSTEM VARIATION NOT LEARNED



014RX002

Circuit Description

In order to detect engine misfire at higher engine speeds, the Powertrain Control Module (PCM) must know of any variation between the crankshaft sensor pulse. Most variations are due to the machining of the crankshaft reluctor wheel, however, other sources of variation are also possible. A Crankshaft Position Sensor Tooth Error Correction (TEC) procedure must be performed any time a change is made to the crankshaft sensor, crankshaft, or if the PCM measures the variations and then calculates compensation factors needed to enable the PCM to accurately detect engine misfire at all speeds and loads. The Tech 2 must be used to command the PCM to learn these variations. If for any reason the PCM is unable to learn these variations or they are out of an acceptable range, the PCM will set a DTC P1336. A PCM that has not had the Crankshaft Position Sensor Tooth Error Correction (TEC) Procedure performed due to replacement or reprogramming will also set a DTC P1336. DTC P1336 is a type A code.

Conditions for Setting the DTC

- No ECT, Knock, CKP, CMP or injector sensor DTCs.
- PCM has not successfully learned crankshaft position Tooth Error Correction (TEC) within 5 attempts or 5 Km (3 miles).

Action Taken When the DTC Sets

- The Malfunction Indicator Lamp (MIL) will illuminate the first time the error is detected.
- The PCM will record operating conditions at the time the diagnostic fails. This information will be stored in the Freeze Frame and Failure Records buffers.
- A history DTC is stored.

Conditions for Clearing the MIL/DTC

- The MIL will turn OFF after three consecutive ignition cycles in which the diagnostic runs without a fault.
- A history DTC will clear after 40 consecutive warm up cycles without a fault.
- DTC(s) can be cleared by using the Tech 2.

Diagnostic Aids

- Refer to "TEC Learn Procedure"

CAUTION: When performing the Crankshaft Position Sensor Tooth Error Correction (TEC) Procedure always set the vehicle parking brake and block the drive wheels. Release the throttle immediately when the engine starts to decelerate. Once the learn procedure is completed, engine control will be returned to the operator and the engine will respond to throttle position.

DTC P1336 will only set if the PCM has not learned the crankshaft position sensor Tooth Error Correction (TEC). The PCM only needs to learn this variation once per life

cycle of the vehicle unless the crank sensor to crankshaft relationship is disturbed. Removing a part for inspection and then reinstalling the same part is considered a disturbance. A fully warmed up engine is critical to learning the variation correctly. If a valid learn occurs, no other learns can be completed that ignition cycle. If the engine cuts out before the specified learn procedure engine speed or at normal fuel cut-off RPM. The PCM is not in the learn procedure mode. Review the Crankshaft Position Sensor Tooth Error Correction (TEC) Procedure and re-enable the learn procedure. Verify that the Tech 2 says "Test in Progress."

Excessive Crankshaft Variation Symptom

Tech 2 Display	Possible Causes
Factors out of range	Reluctor wheel-matching quality, run out, incorrect air gap
Opposing factors out of range	Disturbance-noise on crank sensor circuit, reattempt the Learn procedure
Sum out of range	Engine too cold, reattempt the Learn Procedure
Crank pulse count error	Crank or Cam sensor DTCs set-Repair first

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 if applicable. This created an electronic copy of the data taken when the fault occurred. The information is then stored on the Tech 2 for later reference.
2. Engine temperature if critical to properly learn the Crankshaft Position Sensor Tooth Error Correction (TEC). Failure to properly warm the engine before performing this procedure will result in an inaccurate measurement of the Crankshaft Position Sensor Tooth Error Correction (TEC). The PCM learns this variation as the engine is decelerating and then allows engine control to be returned to the operator. All accessories must be turned OFF when learning the Crankshaft Position System angle variation. If the A/C is not disabled when the learn procedure is enable, the PCM will disable the A/C. When the PCM is ready to allow the learn procedure to run, the Tech 2 will display "Test in Progress."
3. If after the specified number attempts the PCM cannot learn the crankshaft position Sensor Tooth Error Correction (TEC) then the variation is too large and no variation problem is corrected.
4. Being unable to learn the Crankshaft Position Sensor Tooth Error Correction (TEC) indicates that the variation is out of range. Using the Excessive Crankshaft Variation Trouble shooting will help to diagnose the area where the problem lies.

DTC P1336 CKP System Variation Not Learned

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	<p>Perform the Crankshaft Position Sensor Tooth Error Correction(TEC) Learning Procedure as follows: When performing the Crankshaft Position Sensor Tooth Error Correction (TEC) Learning Procedure always set the vehicle parking brake and block the drive wheels. Release the throttle immediately when the engine starts to decelerate. Once the learn procedure is completed, engine control will be returned to the operator and the engine will respond to throttle position.</p> <ol style="list-style-type: none"> 1. Install a Tech 2. 2. Put vehicle in Park or Neutral. 3. Run the engine until it is above the specified temperature. 4. Set the vehicle parking brake and block the drive wheels. 5. Turn all accessories OFF. 6. Enable the Crankshaft Position Sensor Tooth Error Correction (TEC) Learning Procedure with the Tech 2. 7. Raise the engine RPM to the specified value RELEASING the throttle as soon as the engine shuts out. <p>Does the Tech 2 indicate that Crankshaft Position System variation has been learned?</p>	70°C (158°F) 3920 RPM	Go to Step 5	Go to Step 3
3	<p>Attempt Crankshaft Position System Variation Learning Procedures many times as the specified value.</p> <p>Does the Tech 2 indicate that Crankshaft Position System variation has been learned?</p>	5	Go to Step 5	Go to Step 4
4	<p>Repair Check for a problem with the a Crank Sensor to Crankshaft relationship and repair as necessary? Refer to the Excessive Crankshaft Variation Symptom Table.</p>	—	Go to Step 5	—
5	<ol style="list-style-type: none"> 1. Using the Tech 2, clear DTCs. 2. Start the engine and idle at normal operating temperature. 3. Operate vehicle within the conditions for setting this DTC as specified in the supporting text. <p>Does the Tech 2 indicate that this diagnostic "Ran and Passed?"</p>	—	Go to Step 6	Go to Step 2
6	<p>Check if any additional DTCs are set.</p> <p>Are any DTCs displayed that have not been diagnosed?</p>	—	Go to applicable DTC table	System OK

DIAGNOSTIC TROUBLE CODE (DTC) P1380 ABS ROUGH ROAD SYSTEM FAULT



014RX002

Circuit Description

The PCM identifies an engine misfire by detecting the variations in crankshaft speed. The crankshaft speed variations can also occur when a vehicle is operated over a rough surface. The ABS (Anti-Lock Brake System) can detect when the vehicle is on a rough surface based on the wheel acceleration/deceleration data supplied by each wheel speed sensor. The EBCM (Electronic Brake Control Module) over the Class 2 serial data line sends this information to the PCM. The PCM then uses this information in order to determine if the crankshaft variations are being caused by an actual engine misfire or from being driven on a rough surface.

This Diagnostic determines if the ABS system is not capable of detecting a rough road situation. DTC P1380 is a type D code.

Conditions for Setting the DTC

- 20 unusable ABS data values within a 50 value sample.

Conditions for Clearing the DTC

- A history DTC clears after 40 consecutive warm-up cycles without a fault.
- The Tech 2 can clear the DTC.

Diagnostic Aids

The setting of this DTC indicates that a misfire was detected and that the PCM could not determine if the

detected misfire was true or due to operating the vehicle on a rough surface. A misfire can be a true misfire with or without setting this DTC. Check the EBCM for poor connections at the Class 2 serial data terminals. Be sure no true misfire exists after repairing the cause of this DTC.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The Powertrain OBD System Check prompts the technician to complete some basic checks and store the freeze frame and failure records data on the Tech 2 is applicable. This creates an electronic copy of the data taken when the malfunction occurred. The information is then stored on the Tech 2 for later reference.
2. ABS DTCs are found by selecting Chassis on the Tech 2.
3. Be careful to clear only DTCs and not the captured information stored on the Tech 2. The Tech 2 will issue a warning if this is about to happen.
4. A DTC P1380 being reset indicated that the PCM is not receiving the correct information from the EBCM due to an ABS DTC.
5. When DTC P1380 is set, and ABS DTC should also be set.
6. Refer to Section 5E of the service manual for ABS DTCs and repairs.


8. Repair any condition that remains and is causing a misfire by following the table for any DTC that has set.

9. Replacement PCMs must be reprogrammed. Refer to the latest Isuzu Technical Communication System information for programming procedures.

DTC P1380 ABS Rough Road System Fault

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Turn the ignition switch ON, with the engine OFF. 2. Install the Tech 2. 3. Check for any ABS DTCs. Were any ABS DTCs set?	—	Go to Step 6	Go to Step 3
3	1. Turn the ignition switch ON, with the engine OFF. 2. Review the Freeze Frame data and note the parameters. Did a misfire DTC set?	—	Go to Step 4	Go to Step 10
4	Was a DTC P1380 also set?	—	Go to Step 5	Go to Step 8
5	Did a ABS DTC also set?	—	Go to Step 6	Go to Step 9
6	Repair the condition causing the ABS DTC. Is the action complete?	—	Go to Step 7	—
7	Check if any additional DTCs are set. Are any DTCs displayed that has not been diagnosed?	—	Go to applicable DTC table	System OK
8	Repair the condition causing the misfire. Is the action complete?	—	Go to Step 10	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to Step 10	—
10	1. Using the Tech 2, clear the DTCs. 2. Start the engine and idle at normal operating temperature. 3. Operate the vehicle within the conditions for setting this DTC as specified in the supporting text. Does the Tech 2 indicate that this diagnostic has "Ran and Passed?"	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1381 ABS ROUGH ROAD CLASS 2 SERIAL DATA FAULT



014RX002

Circuit Description

The PCM identifies an engine misfire by detecting the variations in crankshaft speed. The crankshaft speed variations can also occur when a vehicle is operated over a rough surface. The ABS (Anti-Lock Brake System) can detect when the vehicle is on a rough surface based on the wheel acceleration/deceleration data supplied by each wheel speed sensor. The EBCM (Electronic Brake Control Module) over the Class 2 serial data line sends this information to the PCM. The PCM then uses this information in order to determine if the crankshaft variations are being caused by an actual engine misfire or from being driven on a rough surface. DTC P1381 is a type D code.

Conditions for Setting the DTC

- ☐ A DTC P0300–P0304 has been set.
- ☐ The vehicle speed is greater than 1 mph (2 km/h).
- ☐ The Manifold Absolute Pressure (MAP) is below 99.7 kPa.
- ☐ The engine speed is below 3406 RPM.
- ☐ The PCM has not received any ABS information for 2.5 seconds.

Action Taken When the DTC Sets

- ☐ The PCM records the operating conditions at the time the diagnostic fails. The Failure Records buffers stores this information.

- ☐ A history DTC is stored.
- ☐ The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions for Clearing the DTC

- ☐ A history DTC clears after 40 consecutive warm up cycles without a fault.
- ☐ The Tech 2 can clear the DTC.

Diagnostic Aids

The setting of this DTC indicates that a misfire was detected and that the PCM could not determine if the detected misfire was true or due to operating the vehicle on a rough surface. A misfire can be a true misfire with or without setting this DTC. Check the EBCM for poor connections at the Class 2 serial data terminals. Be sure no true misfire exists after repairing the cause of this DTC.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:


1. The Powertrain OBD System Check indicates that a misfire was detected and that the PCM could not determine if the detected misfire was true or due to operating the vehicle on a rough surface. A misfire can be a true misfire with or without setting this DTC. Check the EBCM for poor connections at the Class 2 serial data terminals. Be sure no true misfire exists after repairing the cause of this DTC.

3. Refer to the ABS portion of the service manual for ABS DTCs and repairs. Performing the ABS Diagnostic System Check is the first step in diagnosing a serial data problem.
4. Be careful to clear only DTCs and not the captured information stored on the Tech 2. The Tech 2 will issue a warning if this is about to happen.
5. A DTC P1381 being reset indicates that the PCM is not receiving serial data from the EBCM due to a EBCM problem.
6. When DTC P1381 is set, ABS serial data should not be able to be displayed.
7. Repair any condition that is causing a misfire by following the table for any DTC that has set.
10. Replacement PCMs must be reprogrammed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures.

DTC P1381 ABS Rough Road Class 2 Serial Data Fault

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to Powertrain OBD System Check
2	1. Turn the ignition switch ON, with the engine OFF. 2. Install the Tech 2. 3. Attempt to display the ABS data on the Tech 2. Can the ABS be displayed?	—	Go to Step 4	Go to Step 3
3	Repair the condition causing the ABS data not to be displayed. Is the action complete?	—	Go to Step 4	Go to Step 10
4	1. Clear the DTCs. 2. Operate the vehicle within the same conditions as indicated within the Freeze Frame data and Conditions for Setting the DTC as noted while driving on rough surfaces. Did a misfire DTC set?	—	Go to Step 5	Go to Step 8
5	Was a DTC P1380 also set?	—	Go to Step 6	Go to Step 7
6	Can the ABS data be displayed?	—	Go to Step 10	Go to Step 4
7	Repair the condition causing the misfire. Is the action complete?	—	Go to Step 8	—
8	1. Using the Tech 2, clear the DTCs. 2. Start the engine and idle at normal operating temperature. 3. Operate the vehicle within the conditions for setting this DTC as specified in the supporting text. Does the Tech 2 indicate that this diagnostic has "Ran and Passed?"	—	Go to Step 9	Go to Step 2
9	Check if any additional DTCs are set. Are any DTCs displayed that have not been diagnosed?	—	Go to applicable DTC table	System OK
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) 1404 EXHAUST GAS RECIRCULATION (EGR) CLOSED VALVE



D06RX055

Circuit Description

The powertrain control module (PCM) monitors the exhaust gas recirculation (EGR) valve pintle position input to ensure that the valve responds properly to commands from the PCM to detect a fault if the pintle position sensor and control circuits are open or shorted. If the PCM detects a pintle position signal voltage below the normal range of the pintle position sensor, or a signal voltage that is not within a tolerance considered acceptable for proper EGR control system operation, the PCM will set a DTC P1404.

Conditions for Setting the DTC

- IAT is above 5°C (41°)
- EGR actual position is 16 counts below the EGR low threshold for at least 6.3 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history DTC P1404 will clear after 40 consecutive warm up cycles without a fault.
- DTC P1404 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Excessive deposits on EGR valve pintle or seat – Check for deposits that may interfere with the EGR valve pintle extending completely or cause the pintle to stick.
- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the EGR actual position display on the Tech 2 while moving connectors and wiring harnesses related to the EGR valve. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

NOTE: If the EGR valve show signs of excessive heat, check the exhaust system for blockage (possible a plugged catalytic converter) using the "Restricted Exhaust System Check".


DTC P1404 EGR Closed Valve

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Turn the ignition switch ON, with the engine OFF. 2. Review and record the Tech 2 Failure Records data, the clear the DTCs. 3. Operate the vehicle within the Failure Records conditions noted. 4. Using the Tech 2, monitor "DTC" info for DTC P1404. Does the Tech 2 indicate DTC P1404 "Ran and Passed"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Disconnect the Linear Exhaust Gas Recirculation (EGR) Valve from the wiring harness. 3. Ignition ON, Engine OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the Ignition feed circuit at the Linear Exhaust Gas Recirculation (EGR) Valve wiring harness connector. Does the DVM read the following value?	12 volts	Go to Step 6	Go to Step 4
4	Check the Ignition feed circuit, between the EGR sensor and the "Engine IG." fuse, for the following conditions: <input type="radio"/> An Open circuit <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	—
5	Using a DVM, check the resistance of the EGR solenoid. Does the DVM read the following value?	less than 5 Ω	Go to Step 6	Go to Step 14
6	Check the EGR solenoid valve Low circuit, between the EGR sensor and the PCM, for the following conditions: <input type="radio"/> An Open circuit <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	Go to Step 15
7	1. Ignition OFF. 2. Disconnect the Linear Exhaust Gas Recirculation (EGR) Valve from the wiring harness. 3. Ignition ON, Engine OFF. 4. Observe the EGR value on the Tech 2. Does the Tech 2 display the following value(s)?	0 volts 0%	Go to Step 9	Go to Step 8
8	Check the EGR position feedback circuit, between the EGR sensor and the PCM, for the following conditions: <input type="radio"/> An Open circuit <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	Go to Step 15

DTC P1404 EGR Closed Valve (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Ignition ON, engine OFF. 2. Using a Digital Voltmeter (DVM), check for voltage on the 5 volt Reference signal circuit at the Linear Exhaust Gas Recirculation (EGR) Valve wiring harness connector. Does the DVM read the following value?	about 5 volts	Go to Step 11	Go to Step 10
10	Check the 5 volt reference signal circuit, between the EGR and the PCM, for the following conditions: <input type="radio"/> An Open circuit <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	Go to Step 11
11	1. Ignition OFF. 2. Place a DVM between the 5 volt reference signal circuit and the 5 volt signal return (ground) circuit at the EGR wiring harness connector. 3. Ignition ON, Engine OFF. Does the DVM read the following value?	about 5 volts	Go to Step 13	Go to Step 12
12	Check the 5 volt signal return (ground) circuit, between the EGR and the PCM, for the following conditions: <input type="radio"/> An Open circuit <input type="radio"/> A short to ground Was the problem found?	—	Verify repair	Go to Step 15
13	1. Ignition OFF. 2. Place a fused jumper wire between the 5 volt reference signal circuit and the EGR valve position feedback circuit at the EGR wiring harness connector. 3. Ignition ON, Engine OFF. 4. Observe the EGR value on the Tech 2. Does the Tech 2 display the following value?	5 volts 100%	Go to Step 14	Go to Step 15
14	Replace the Linear Exhaust Gas Recirculation (EGR) Valve. Verify repair.	—	—	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P1441 EVAPORATIVE EMISSION (EVAP) SYSTEM FLOW DURING NON-PURGE



D06RX056

Circuit Description

Canister purge is controlled by a solenoid valve that allows manifold vacuum to purge the canister. The powertrain control module (PCM) supplies a ground to energize the solenoid valve (purge ON). The EVAP purge solenoid control is pulse-width modulated (PWM) and is turned ON and OFF several times a second. The duty cycle (pulse width) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM and the output is commanded when the appropriate conditions have been met.

The EVAP purge vacuum switch is a normally closed switch positioned in the purge line between the canister and the EVAP purge solenoid. The EVAP purge vacuum switch will open when vacuum increases to greater than 5 inches of water pressure in the purge line. The PCM monitors the EVAP purge vacuum switch signal to determine if the evaporative emission control system is working properly. If the switch is open (purge flow detected) when the PCM is not commanding the EVAP purge solenoid ON, DTC P1441 will be set. DTC P1441 is a type A code.

Conditions for Setting the DTC

- No active system voltage, ECT sensor, IAT sensor, VS sensor, MAP sensor, vacuum switch, or TP sensor DTCs set.

- BARO reading is above 72.3 kPa.
- Start-up intake air temperature (IAT) and start-up engine coolant temperature (ECT) are both between 3.5°C (38°F) and 32°C (90°F).
- The difference between start-up ECT and start-up IAT is less than 6.75°C (12.2°F).
- The Fuel Tank Level Sensor reads between 10% and 90%.
- The vehicle speed is less than 98 km/h (60 mph).
- Fuel tank vacuum is greater than 15.25 cm (6 inches) of water for 0.5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL OFF on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1441 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1441 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The Fuel Pressure Sensor shares a 5 Volt reference with the MAP sensor and TP sensor.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The Fuel Pressure Sensor share a ground with the MAP sensor and the TP sensor.
- Damaged harness – Inspect the wiring harness for damage; shorts to ground, shorts to battery positive, and open circuits. If the harness appears to be OK, observe the EVAP vacuum switch display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often

the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. The canister purge vacuum switch is normally closed when no vacuum (purge) is present. With the ignition ON and the engine OFF, there shouldn't be any vacuum (purge) present in the EVAP system.
3. Determines if the PCM is able to control the EVAP purge solenoid valve.
4. Determines if the DTC will set under the conditions present when the DTC was originally stored. If not, the fault is intermittent.
5. Checks for a grounded EVAP purge solenoid driver circuit, a faulty EVAP vacuum switch, or a leaking EVAP purge solenoid valve.

DTC P1441 – EVAP System Flow During Non-Purge

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "OFF." 2. Remove the fuel filler cap. 3. Ignition "ON." Observe "Fuel Tank Pressure" on the Tech 2. Is "Fuel Tank Pressure" at the specified value?	1.51 V	Go to Step 3	Go to <i>P0452 or P0453</i>
3	1. Re-install the fuel filler cap. 2. Using the Tech 2, command the EVAP Vent Solenoid Valve "ON" (Closed). 3. Disconnect the canister side rubber hose end that hose is connected between the Purge Solenoid Valve and Canister. IMPORTANT: Before continuing with the diagnosis, zero the EVAP pressure and vacuum gauges on EVAP pressure / purge cart J41413 (refer to the tool operating instructions). And then monitor the fuel tank inner pressure using the Tech 2. Does the fuel tank pressure hold the specified value?	1.52 - 1.60 V	Go to Step 4	Go to Step 6

DTC P1441 – EVAP System Flow During Non-Purge (Cont'd)

Step	Action	Value(s)	Yes	No
4	<ol style="list-style-type: none"> 1. Disconnect the EVAP pressure / purge cart J41413, and then plug the hose end. 2. Disconnect the rubber hose end of engine vacuum source side, (the hose connected between Purge Solenoid Valve and engine). 3. Connect a vacuum hand pump to this rubber hose end. 4. Then apply -15 in H₂O vacuum by the vacuum pump. 5. Monitor the fuel tank inner pressure using the Tech 2. <p>Does the fuel tank inner pressure hold the specified value?</p>	1.47 - 1.51 V	Go to <i>Step 6</i>	Go to <i>Step 5</i>
5	Replace the Purge Solenoid Valve.	—	Verify repair	—
6	<ol style="list-style-type: none"> 1. Check for leaks, kinks or pinched hoses at the EVAP system rubber hose line, and also check if the rubber hoses are correctly connected or not. 2. Check for a leak from Vent Solenoid Valve and EVAP system rubber hoses, and also check for clogged Filter of air separator which is located near the vent solenoid valve. <p>Was a problem found? Using the Vacuum Hose Routing Diagram, repair or re-connect the rubber hoses correctly.</p>	—	Verify repair	Go to <i>Step 7</i>
7	<ol style="list-style-type: none"> 1. Start engine. 2. Remove the Fuel Filler Cap. 3. Using the Tech 2, command the EVAP Vent Solenoid Valve "ON" (closed) and Purge Solenoid Valve "OFF" (0%). 4. Replace the Fuel Filler Cap. 5. Run the engine at 2500RPM constant while monitoring "Fuel Tank Vacuum" on the Tech 2. <p>Does the fuel tank vacuum remain at the specified value while the EVAP Vent Solenoid Valve "ON" (closed) and Purge Solenoid Valve "OFF" (0%)?</p>	30 - 40%	Verify repair	Go to <i>Diagnostic Aids</i>



- Poor connections, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also check for open circuits, shorts to ground, and shorts to voltage.


DTC P1546 A/C Compressor Clutch Output Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTCs. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P1546. Does the Tech 2 indicate DTC P1546 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	1. Ignition OFF. 2. Remove the A/C Compressor Clutch Relay from the Underhood Electrical Center. 3. Ignition ON, Engine OFF. 4. Using a Digital Voltmeter (DVM), check for voltage on the Fused pins of the A/C Compressor Clutch Relay connector. Does the DVM read the following value?	12 Volts	Go to Step 5	Go to Step 4
4	Check the suspect circuit(s) between the A/C Compressor Clutch Relay connector and the Fuse for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	—
5	1. Ignition OFF. 2. Disconnect the Powertrain Control Module (PCM) connectors from the PCM. 3. Check the A/C Compressor Clutch Relay control circuit between the PCM and Underhood Electrical Center for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 6
6	1. Reinstall the A/C Compressor Clutch Relay. 2. Using a fused jumper, ground the A/C Compressor Clutch Relay control circuit at the PCM connector. 3. Ignition ON, Engine OFF. Does the A/C Compressor turn ON?	—	Go to Step 9	Go to Step 7
7	1. Ignition OFF. 2. Check the A/C Compressor Clutch circuit between the A/C Compressor Clutch Relay and A/C Compressor Clutch for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 8

DTC P1546 A/C Compressor Clutch Output Circuit Malfunction (Cont'd)

Step	Action	Value(s)	Yes	No
8	Replace the A/C Compressor Clutch Relay. Is the action complete?	—	Verify repair	—
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

Diagnostic Trouble Code (DTC) P1625 PCM Unexpected Reset



014RX002

Circuit Description

The powertrain control module (PCM) monitors unexpected PCM reset. This will not turn on MIL light on, only records code DTC P1625.

Conditions for Setting the DTC

- Clock or COP (Computer Operating Properly) reset.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history DTC P1625 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1625 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:


- P1625 alone stored does not need diagnosis. Clear DTC code.

NOTE: DTC P1625 is a DTC to record a PCM reset history. If DTC P1625 is not reset and no engine abnormality is found after clearance of DTC, it is not necessary to do any farther processing.

DTC P1625-PCM Unexpected Reset

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition is "On". 2. Install the Tech 2. 3. Start the engine at let it Idle. 4. On the Tech 2, select "DTC info". Does the Tech 2 indicate DTC P1625 failed?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	1. Ignition is "On". 2. Clear DTC P1625 by using the Tech 2 "Clear Info". 3. Start the engine at let it Idle. 4. On the Tech 2, select "DTC info". Does the Tech 2 indicate DTC P1625 failed?	—	Go to Step 4	Go to <i>Diagnostic Aids</i>
4	1. Check for aftermarket electronics, such as transceiver stereos, and anti theft devices, they may radiate EMI into the control system if they are improperly installed. (This may cause a false sensor reading and turn on the MIL.) 2. If a problem is found, repair as necessary. Was the problem found?	—	Verify repair	—

DIAGNOSTIC TROUBLE CODE (DTC) P1627 PCM A/D CONVERSION MALFUNCTION



014RX002

Circuit Description

The Powertrain Control Module (PCM) monitors the 5 volt reference signal when the Ignition is ON. If the PCM senses an Analog to Digital (A/D) conversion error within the PCM, then DTC P1627 will set. DTC P1627 is a type A code.

Conditions for Setting the DTC

- Engine is running.
- Any A/D DTC's set.

Action Taken When the DTC Sets

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) the first time the fault is detected.
- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the MIL/DTC

- The PCM will turn OFF the MIL on the third consecutive trip without a reported failure.
- A History DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using the Scan Tool's "Clear Info" function.


Diagnostic Aids

- Poor connections, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also, check for open circuits, shorts to ground, and shorts to voltage.

DTC P1627 PCM A/D Conversion Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTCs. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P1627. Does the Tech 2 indicate DTC P1627 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	Check the suspect 5 volt reference circuit(s) for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 4
4	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P1635 5 VOLT REFERENCE VOLTAGE CIRCUIT MALFUNCTION



D06RX062

Circuit Description

The Powertrain Control Module (PCM) monitors the 5 volt reference signal when the Ignition is ON. If the PCM senses the 5 volt reference signal circuit is above 5.12 volts or below 4.88 volts, then DTC P1635 will set. DTC P1635 is a type A code.

Conditions for Setting the DTC

- Ignition voltage is greater than 6.3 volts.
 - Engine is running.
- The above mentioned conditions are met and one of the following two conditions are met for 5 seconds within a 10 second test sample:
- PCM senses the 5 volt reference signal circuit is above 5.12 volts.
- OR
- PCM senses the 5 volt reference signal circuit is below 4.88 volts.

Action Taken When the DTC Sets

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) the first time the fault is detected.
- The PCM will store the conditions that were present when the DTC was set as Freeze Frame and in Failure Records.

Conditions for Clearing the MIL/DTC


- The PCM will turn OFF the MIL on the third consecutive trip without a reported failure.
- A History DTC will clear after 40 consecutive trips without a reported failure.
- The DTC can be cleared using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Poor connections, or a damaged harness – Inspect the harness connectors for: backed-out terminals, improper mating or damaged terminals. Also, check for open circuits, shorts to ground, and shorts to voltage.

DTC P1635 5 Volt Reference Voltage Circuit Malfunction

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Ignition ON, Engine OFF. 2. Review and record Tech 2 Failure Records data, then clear the DTCs. 3. Operate the vehicle within the Failure Records conditions as noted. 4. Using the Tech 2, monitor "DTC" info for DTC P1635. Does the Tech 2 indicate DTC P1635 "Ran and Passed?"	—	Refer to Diagnostic Aids	Go to Step 3
3	Check the suspect 5 volt reference circuit(s) for the following conditions: <input type="radio"/> A short to ground <input type="radio"/> An open circuit <input type="radio"/> A short to voltage Was the problem found?	—	Verify repair	Go to Step 4
4	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to On-Vehicle Service in Powertrain Control Module and Sensors for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Verify repair.	—	—	—

DIAGNOSTIC TROUBLE CODE (DTC) P1640 ODM OUTPUT CIRCUIT FAULT

014RX002

Circuit Description

Output driver modules (ODMs) are used by the powertrain control module (PCM) to turn ON many of the current driven devices that are needed to control various engine and transmission functions. Each ODM is capable of controlling up to 11 separate outputs by applying ground to the device which the PCM is commanding ON. ODMs have the capability of diagnosing each output circuit individually. DTC P1640 set indicates an improper voltage level has been detected on an ODM output. If the PCM detects an open circuit condition and a shorted to voltage circuit condition on the same circuit at the same time, then DTC P1640 will set. DTC P1640 is a type D code.

Conditions for Setting the DTC

- Ignition ON.
- Above conditions occur for at least 2.5 seconds.
- The PCM detects an open circuit condition and a shorted to voltage circuit condition on the same circuit at the same time.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- A history DTC P1640 will clear after 40 consecutive warm up cycles occur without a fault.
- DTC P1640 can be cleared by using the Scan Tool's "Clear Info" function.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.
- Damaged harness Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition ON and observe a voltmeter connected to the MIL driver circuit at the PCM harness connector while moving connectors and wiring harnesses relates to the MIL. A change in voltage will indicate the location of the fault.
- Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

The following PCM pins are controlled by output driver modules (ODMs):

- A13 MIL LAMP
- A14 Rear Defogger
- B15 Up Shift
- B14 A/C Clutch

- A15 EVAP Canister Vent Solenoid
- B16 EVAP Canister Purge Solenoid
- A1 2 Low Fuel
- C10 Tacho Meter
- C11 Fuel Gauge
- C13 Fan Low
- C12 Fan High

2. The Tech 2 Driver Module Status indicates the PCM pin that is affected.
9. The Tech 2 may indicate "short circuit" even when the problem is an open circuit. The cause of an open circuit may be in the component itself.
11. A short to ground on the ignition side of the component will blow the fuse. Since the fuse was checked in Step 2, a short to ground would be between the affected component and the PCM.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

DTC P1640 –Output Driver Module (ODM) "A" Fault

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Check the fuse for the driver circuit that was shown as faulty. Was the fuse blown?	—	Go to Step 3	Go to Step 4
3	1. Check for a short to ground between the fuse and the affected component. 2. Replace the fuse after making any necessary repairs. Is the action complete?	—	Verify repair	—
4	1. Disconnect the PCM connector for the affected driver circuit. Is there any damage to the PCM pin or connector?	—	Go to Step 5	Go to Step 6
5	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
6	Was the Lamp of circuit for "Check Engine"?	—	Go to Step 7	Go to Step 13
7	1. Leave the PCM connector for the lamp driver circuit disconnected. 2. Ignition "ON." 3. Using a DVM, check the voltage at the PCM connector for the affected lamp driver circuit. Was the voltage equal to the specified value?	B+	Go to Step 15	Go to Step 8
8	1. Ignition "ON." 2. Check for battery voltage at the fuse for the affected lamp circuit. Was battery voltage available at the fuse?	—	Go to Step 10	Go to Step 9
9	Repair the open circuit between the ignition switch and the fuse. Is the action complete?	—	Verify repair	—
10	1. Ignition "OFF." 2. Disconnect the PCM connector for the affected driver terminal. 3. Connect an ohmmeter between a good ground and the PCM connector for the affected driver. Did the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 12

DTC P1640 –Output Driver Module (ODM) “A” Fault (Cont’d)

Step	Action	Value(s)	Yes	No
11	Repair the short to ground between the affected component and its PCM driver terminal. Is the action complete?	—	Verify repair	—
12	Repair the open circuit between the fuse and the PCM driver terminal for the affected circuit. Is the action complete?	—	Verify repair	—
13	1. Connect the PCM. 2. Start the engine and let it idle. 3. Backprobe the affected terminal at the PCM with a DVM. Was the voltage equal to the specified value?	B+	Go to <i>Step 15</i>	Go to <i>Step 14</i>
14	1. Run the engine at idle. 2. Check for battery voltage at the fuse for the affected circuit. Was battery voltage available at the fuse?	—	Go to <i>Step 10</i>	Go to <i>Step 9</i>
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

SYMPTOM DIAGNOSIS

PRELIMINARY CHECKS

Before using this section, perform the "On-Board Diagnostic (OBD) System Check" and verify all of the following items:

- The powertrain control module (PCM) and malfunction indicator lamp (MIL)(Check Engine lamp) are operating correctly.
- There are no DTC(s) stored.
- Tech 2 data is within normal operating range. Refer to Typical Scan Data Values.
- Verify the customer complaint and locate the correct symptom in the table of contents. Perform the procedure included in the symptom chart.

VISUAL/PHYSICAL CHECK

Several of the symptom procedures call for a careful visual/physical check. This can lead to correcting a problem without further checks and can save valuable time. This check should include the following items:

- PCM grounds for cleanliness, tightness and proper location.
- Vacuum hoses for splits, kinks, and proper connections, as shown on the "Vehicle Emission Control Information" label. Check thoroughly for any type of leak or restriction.
- Air intake ducts for collapsed or damaged areas.
- Air leaks at throttle body mounting area, manifold absolute pressure (MAP) sensor and intake manifold sealing surfaces.
- Ignition component for cracking, hardness, and carbon tracking.
- Wiring for proper connections, pinches and cuts.

INTERMITTENTS

An intermittent problem may or may not turn on the malfunction indicator lamp (MIL) or store a Diagnostic Trouble Code. DO NOT use the Diagnostic Trouble Code (DTC) charts for intermittent problems. The fault must be present to locate the problem.

Most intermittent problems are caused by faulty electrical connections or wiring. Perform a careful visual/physical check for the following conditions:

- Poor mating of the connector halves or a terminal not fully seated in the connector (backed out).
- Improperly formed or damaged terminal.
- All connector terminals in the problem circuit should be carefully checked for proper contact tension.
- Poor terminal-to-wire connection. This requires removing the terminal from the connector body to check.

Road test the vehicle with a J 39200 Digital Multimeter connected to a suspected circuit. An abnormal voltage

when the malfunction occurs is a good indication that there is a fault in the circuit being monitored.

Use a Tech 2 to help detect intermittent conditions.

The Scan Tools have several features that can be used to locate an intermittent condition. Use the following feature to find intermittent faults:

- Using a Scan Tool's "Freeze Frame" buffer or "Failure Records" buffer can aid in locating an intermittent condition. Review and record the information in the freeze frame or failure record associated with the intermittent DTC being diagnosed. The vehicle can be driven within the conditions that were present when the DTC originally set.

To check for loss of diagnostic code memory, disconnect the MAP sensor and idle the engine until the MIL (Check Engine lamp) comes on. Diagnostic Trouble Code P0107 should be stored and kept in memory when the ignition is turned OFF. If not, the PCM is faulty. When this test is completed, make sure that you clear the Diagnostic Trouble Code P0107 from memory.

An intermittent MIL (Check Engine lamp) with no stored Diagnostic Trouble Code may be caused by the following:

- Ignition coil shorted to ground and arcing at ignition wires or plugs.
- MIL (Check Engine lamp) wire to PCM shorted to ground.
- Poor PCM grounds. Refer to the PCM wiring diagrams.

Check for improper installation of electrical options such as lights, cellular phones, etc. Check all wires from the PCM to the ignition coils for poor connections.

Check for an open diode across the A/C compressor clutch and check for other open diodes (refer to wiring diagrams in Electrical Diagnosis).

If problem has not been found, refer to PCM Connector Symptom tables.

- Check the "Broadcast Code" of the PCM, and compare it with the latest Isuzu service bulletins and/or Isuzu EEPROM reprogramming equipment to determine if an update to the PCM's reprogrammable memory has been released. To check the "Broadcast Code," connect the Tech 2, then look for "ID info," then select "Broadcast Code." This should display a 4 character code, such as "XBYA" (example only). This identifies the contents of the reprogrammable software and calibration contained in the PCM. If the Broadcast code is not the most current available, it is advisable to reprogram the PCM's EEPROM memory, which may either help identify a hard-to-find problem or may fix the problem.

HARD START SYMPTOM

DEFINITION:

Engine cranks, but does not start for a long time. Does eventually run, or may start but immediately stalls.

6E1-356 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	Check engine coolant temperature (ECT) sensor for shift in value. 1. After 8 hours with the hood up and the engine not running, connect the Tech 2. 2. Ignition ON, engine not running. 3. Using the Tech 2, compare Engine Coolant Temperature to Intake Air Temperature. Are ECT and IAT within the specified value of each other?	$\pm 5^{\circ}\text{C}$ ($\pm 9^{\circ}\text{F}$)	Go to Step 8	Go to Step 5
5	1. Using a Tech 2, display the engine coolant temperature and note the value. 2. Check the resistance of the engine coolant temperature sensor. 3. For resistance specifications, refer to Temperature vs. Resistance chart in DTC P0118. Is the actual resistance near the resistance value in the chart for the temperature that was noted?	—	Go to Step 7	Go to Step 6
6	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
7	Locate and repair high resistance or connection in the ECT signal circuit or the ECT signal circuit or the PCM sensor ground.	—	Verify repair	—
8	Check for a faulty, plugged, or incorrectly installed PCV valve. Was a problem found?	—	Verify repair	Go to Step 9
9	Visually/Physically inspect the secondary ignition wires. Check for the following conditions: <ul style="list-style-type: none"> ○ Verify that all ignition wire resistance are less than the specified value. ○ Verify that ignition wires are correctly routed to eliminate cross-firing. ○ Verify that ignition wires are not arcing to ground. Spraying the secondary ignition wires with a light mist of water may help locate an intermittent problem. Was a problem found?	22.4 k Ω	Verify repair	Go to Step 10
10	Check for proper ignition voltage output with a spark tester J 26792. Was a problem found?	—	Verify repair	Go to Step 11

RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION 6E1-357

Step	Action	Value(s)	Yes	No
11	1. Remove the spark plugs and check for gas or oil fouling cracks, wear, improper gap, burned electrodes, heavy deposits, or improper heat range. 2. If spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs. Was a problem found?	—	Verify repair	Go to Step 12
12	Check for a loose ignition control module ground. Was a problem found?	—	Verify repair	Go to Step 13
13	1. Check the ignition coil secondary resistance. 2. Replace the coil if it is not within the specified range of resistance. Did the coil require replacement?	9 k Ω –12 k Ω	Verify repair	Go to Step 14
14	Check IAC operation. Perform the procedure in the diagnostic chart DTC P0506, Step 6. Was a problem found?	—	Verify repair	Go to Step 15
15	Check for water or alcohol contaminated fuel. Was a problem found?	—	Verify repair	Go to Step 16
16	Perform the procedure in Fuel System Pressure Test to determine if there is a problem with fuel delivery. Was a problem found?	—	Verify repair	Go to Step 17
17	Check for the following engine mechanical problems (refer to Engine Mechanical): ○ Low compression ○ Leaking cylinder head gaskets ○ Worn camshaft ○ Camshaft drive belt slipped or stripped Was a problem found?	—	Verify repair	Go to Step 18
18	1. Review all diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system Was a problem found?	—	Verify repair	Contact Technical Assistance

SURGES AND/or CHUGGLES SYMPTOM

DEFINITION:

Engine power variation under steady throttle or cruise.
Feels like the vehicle speeds up and slows down with no change in the accelerator pedal.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	Be sure that the driver understands A/C compressor operation as explained in the owner's manual. Inform the customer how the A/C clutch operate. Is the customer experiencing a normal condition?	—	System OK	Go to Step 5
5	Check the fuel control Heated Oxygen Sensor (HO2S1). When monitored on the Tech 2, the HO2S1 should respond quickly to different throttle positions. If it doesn't check for silicon or other contaminants from fuel or use of improper RTV sealant. The sensors may have a white powdery coating. Silicone contamination sends a rich exhaust signal which causes the PCM to command an excessively lean air/fuel mixture. Was a problem found?	—	Verify repair	Go to Step 6
6	Check the fuel pressure. Refer to Fuel System Pressure Test. Was a problem found?	—	Verify repair	Go to Step 7
7	Monitor "Long Term Fuel Trim" on the Tech 2. Is "Long Term Fuel Trim" in the negative range (rich condition)?	—	Go to Step 8	Go to Step 9
8	Check items that can cause the engine to run rich. Refer to Diagnostic Aids in DTC P0172. Was a problem found?	—	Verify repair	Go to Step 10
9	Check items that can cause the engine to run lean. Refer to Diagnostic Aids in DTC P0171. Was a problem found?	—	Verify repair	Go to Step 10
10	Check for proper ignition voltage output with the spark tester J 26792. Was a problem found?	—	Verify repair	Go to Step 11
11	Check for a loose ignition control module ground. Was a problem found?	—	Verify repair	Go to Step 12

Step	Action	Value(s)	Yes	No
12	<p>Visually/Physically inspect the secondary ignition wires. Check for the following conditions.</p> <ul style="list-style-type: none"> ○ Verify that all ignition wire resistance are less than the specified value. ○ Verify that ignition wires are correctly routed to eliminated cross-firing. ○ Verify that ignition wires are not arcing to ground. Spraying the secondary ignition wires with a light mist of water may help to locate an intermittent problem. <p>Was a problem found?</p>	22.4 Ω	Verify repair	Go to Step 13
13	<p>1. Check ignition coil secondary resistance.</p> <p>2. Replace the coil if it is not within the specified range of resistance.</p> <p>Did the coil require replacement?</p>	9 kΩ– 12 kΩ	Verify repair	Go to Step 14
14	<p>1. Remove the spark plugs and check for gas or oil fouling, cracks, wear, improper gap, burned electrodes, heavy deposits or improper heat range.</p> <p>2. If spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 15
15	<p>1. Check the injector connectors.</p> <p>2. If any of the connectors are connected at an improper cylinder, correct as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>Check the PCM grounds to verify that they are clean and tight. Refer to the PCM wiring diagrams in Electrical Diagnosis.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 17
17	<p>Visually/physically check the vacuum hoses for splits, kinks and proper connections and routing as shown on the "Vehicle Emission Control Information" label.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 18
18	<p>Check the exhaust system for a possible restriction:</p> <ul style="list-style-type: none"> ○ damaged or collapsed pipes ○ internal muffler failure ○ Refer to Restricted Exhaust System Check to measure back pressure and determine if the catalytic converter is plugged. 	—	Verify repair	Go to Step 19
19	<p>1. Review all the diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection. ○ Tech 2 data. ○ Freeze Frame data/Failure Records buffer. ○ All electrical connections within a suspected circuit and/or system. <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

LACK OF POWER, SLUGGISH OR SPONGY SYMPTOM**DEFINITION:**

Engine delivers less than expected power. Little or no increase in speed when accelerator pedal is pushed down part-way.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	1. Remove and check the air filter element for dirt or restrictions. Refer to Air Intake System in On-Vehicle Service. 2. Replace the air filter element if necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	Check for proper ignition voltage output with the spark tester J 26792. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Remove the spark plugs and check gas or oil fouling, cracks, wear, improper gap, burned electrodes, heavy deposits or improper heat range. 2. If spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs. Was a problem found?	—	Verify repair	Go to Step 7
7	Check the fuel pressure. Refer to Fuel System Test. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Install the Tech 2. 2. Run the engine at idle. 3. On the Tech 2, select F3: Miscellaneous Test, F6: Variable Intake Manifold. 4. Repeat Switch ON or OFF of VIM solenoid valve by using the Tech 2. 5. Check the solenoid working sound. 6. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	Check for water or alcohol contaminated fuel. Was a problem found?	—	Verify repair	Go to Step 10
10	Check the PCM grounds to verify that they are clean and tight. Refer to the PCM wiring diagrams in Electrical Diagnosis. Was a problem found?	—	Verify repair	Go to Step 11

RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION 6E1-361

Step	Action	Value(s)	Yes	No
11	<p>Check the exhaust system for a possible restriction:</p> <ul style="list-style-type: none"> ○ Damaged or collapsed pipes ○ Internal muffler failure ○ Refer to Restricted Exhaust System Check to measure backpressure and determine if the catalytic converter is plugged. <p>Was a problem found?</p>	—	Verify repair	Go to Step 12
12	<p>Check for the following engine mechanical problems:</p> <ul style="list-style-type: none"> ○ Low compression ○ Leaking cylinder head gasket ○ Worn or incorrect camshaft ○ Loose timing belt <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>1. Review all the diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection. ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer. ○ All electrical connections within suspected circuit and/or system. <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

DETONATION/SPARK KNOCK SYMPTOM

DEFINITION:

A mild to severe ping, usually worse under acceleration.
The engine makes sharp metallic knocks that change with throttle opening.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	1. If Tech 2 readings are normal and there are no engine mechanical faults, fill the fuel tank with a known quality gasoline that has a minimum octane rating of 87. Refer to Typical Scan Values. 2. Re-evaluate the vehicle performance. Is detonation present?	—	Go to Step 5	Verify repair
5	1. Check for obvious overheating problems: <ul style="list-style-type: none"> ○ Low engine coolant. ○ Restricted air flow to radiator, or restricted water flow through radiator. ○ Incorrect coolant solution. It should be a 50/50 mix of approved antifreeze/water. ○ Incorrect EGR operation. Refer to DTC P0401. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	Check fuel pressure. Refer to Fuel System Pressure Test. Was a problem found?	—	Verify repair	Go to Step 7
7	Check items that can cause an engine to run lean. Refer to Diagnostic Aids in DTC P0171. Was a problem found?	—	Verify repair	Go to Step 8
8	Check spark plugs for proper heat range. Refer to General Information. Were incorrect spark plugs installed?	—	Verify repair	Go to Step 9
9	1. Remove excessive carbon buildup with a top engine cleaner. Refer to instructions on the top engine cleaner can. 2. Re-evaluate vehicle performance. Is detonation still present?	—	Go to Step 10	Verify repair

RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION 6E1-363

Step	Action	Value(s)	Yes	No
10	<p>Check for an engine mechanical problem. Perform a cylinder compression check. Refer to Engine Mechanical.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 11
11	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

**ROUGH, UNSTABLE, OR INCORRECT
IDLE, STALLING SYMPTOM****DEFINITION:**

Engine runs unevenly at idle. If severe, the engine or vehicle may shake. Engine idle speed may vary in RPM. Either condition may be severe enough to stall the engine.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed, including the rotor, ignition coil and secondary ignition wires?	—	Go to Step 4	Go to Visual / Physical Check
4	Verify that the EGR valve is not mounted backwards. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Check for incorrect idle speed. Ensure that the following conditions are present: ○ Engine fully warm. ○ Accessories are OFF. 2. Using a Tech 2, monitor IAC position. Is the IAC position within the specified values?	Between 10 and 50 counts	Go to Step 8	Go to Step 7
6	1. Visually/physically inspect for the following conditions: ○ Restricted air intake system. Check for a restricted air filter element, or foreign objects blocking the air intake system. ○ Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. ○ Check for a condition that causes a large vacuum leak, such as an incorrectly installed or faulty crankcase ventilation valve brake booster hose. Was a problem found?	—	Verify repair	Go to Step 7
7	Using a Tech 2, monitor TP angle with the engine idling. Is the TP angle at the specified value and steady?	0%	Go to Step 8	For further diagnosis, refer to DTC P0123
8	Check for proper ignition voltage output with the spark tester J 26792. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Remove the spark plugs and check for gas or oil fouling, cracks, wear, improper gap, burned electrodes, heavy deposits or improper heat range. 2. If spark plugs are fouled, the cause of the fouling must be determined before replacing the spark plugs. Was a problem found?	—	Verify repair	Go to Step 10

RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION 6E1-365

Step	Action	Value(s)	Yes	No
10	Check for a loose ignition control module ground. Refer to Electrical Ignition System. Was a problem found?	—	Verify repair	Go to Step 11
11	Monitor "Long Term Fuel Trim" on the Tech 2. Is "Long Term Fuel Trim" in the negative range (rich condition)?	—	Go to Step 12	Go to Step 13
12	Check the items that can cause the engine to run rich. Refer to Diagnostic Aids in DTC P0172. Was a problem found?	—	Verify repair	Go to Step 13
13	Is "Long Term Fuel Trim" significantly in the positive range (lean condition)? —	—	Go to Step 14	Go to Step 15
14	Check items that can cause the engine to run leading. Refer to "Diagnostic Aids" in DTC P0171. Was a problem found?	—	Verify repair	Go to Step 14
15	Check the injector connections. If any of the injectors are connected to an incorrect cylinder, correct as necessary. Was a problem found?	—	Verify repair	Go to Step 16
16	Perform the Injector Coil/Balance Test. Was a problem found?	—	Verify repair	Go to Step 17
17	1. Check the following engine mechanical problems: <ul style="list-style-type: none"> <input type="radio"/> Low compression <input type="radio"/> Leaking cylinder head gasket <input type="radio"/> Worn or incorrect camshaft <input type="radio"/> Sticking or leaking valves <input type="radio"/> Valve timing <input type="radio"/> Broken valve springs <input type="radio"/> Camshaft drive belt slipped or stripped. Was a problem found?	—	Verify repair	Go to Step 18
18	1. Check for faulty motor mounts. Refer to Engine Mechanical for inspection of mounts. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 19
19	1. Review all diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All electrical connections within a suspected circuit and/or system Was a problem found?	—	Verify repair	Contact Technical Assistance

POOR FUEL ECONOMY SYMPTOM**DEFINITION:**

Fuel economy, as measured by an actual road test, is noticeably lower than expected. Also, economy is noticeably lower than it was on this vehicle at one time, as previously shown by an actual road test.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	Check owner's driving habits. ○ Is the A/C ON full time (defroster mode ON)? ○ Are tires at the correct pressure? ○ Are excessively heavy loads being carried? ○ Is acceleration too much, too often?	—	Go to Step 5	Go to Step 6
5	Review the items in Step 4 with the customer and advise as necessary. Is the action complete?	—	System OK	—
6	1. Visually/physically check: Vacuum hoses for splits, kinks, and improper connections and routing as shown on the "Vehicle Emission Control Information" label. Was a problem found?	—	Verify repair	Go to Step 7
7	Remove and check the air filter element for dirt or for restrictions. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Remove the spark plugs and check for gas or oil fouling, cracks, wear, improper gap, burned electrodes or heavy deposits. 2. Is spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs. Was a problem found?	—	Verify repair	Go to Step 9
9	Check for low engine coolant level. Was a problem found?	—	Verify repair	Go to Step 10
10	Check for an incorrect or faulty engine thermostat. Refer to Engine Cooling. Was a problem found?	—	Verify repair	Go to Step 11
11	Check for low engine compression. Refer to Engine Mechanical. Was a problem found?	—	Verify repair	Go to Step 12

Step	Action	Value(s)	Yes	No
12	<p>Check for excessive exhaust system back-pressure. Refer to Restricted Exhaust System Check. Possible problems could be:</p> <ul style="list-style-type: none"> <input type="radio"/> Damaged or collapsed pipes. <input type="radio"/> Internal muffler failure. <input type="radio"/> Plugged catalytic converter. <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>Check for proper calibration of the speedometer.</p> <p>Does the speed indicated on the speedometer closely match the vehicle speed displayed on the Tech 2?</p>	—	Go to Step 15	Go to Step 14
14	<p>Diagnose and repair the inaccurate speedometer condition as necessary. Refer to Vehicle Speed Sensor in Electrical Diagnosis.</p>	—	Verify repair	—
15	<p>Check the air intake system and the crankcase for air leaks.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>1. Review all the diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All connections within a suspected circuit and/or system <p>Was a problem found?</p>	—	Verify repair	Go to Step 17
17	<p>Perform the procedure in Fuel System Pressure Test.</p> <p>Was the fuel pressure normal?</p>	—	Contact Technical Assistance	Verify repair

EXCESSIVE EXHAUST EMISSIONS OR ODORS SYMPTOM**DEFINITION:**

Vehicle fails an emission test. There is excessive "rotten egg" smell. (Excessive odors do not necessarily indicate excessive emissions.)

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Go to Step 13	Go to Step 3
3	Was visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	Check for vacuum leaks (vacuum lines, intake manifold, throttle body, etc.) Were any vacuum leaks found?	—	Go to Step 13	Go to Step 5
5	1. Check fuel cap for proper installation. 2. Secure the fuel cap if necessary. Was a problem found?	—	Go to Step 13	Go to Step 6
6	1. Check the fuel pressure. Refer to Fuel System Pressure Test. Was a problem found?	—	Go to Step 13	Go to Step 7
7	1. Check for faulty, plugged or incorrectly installed PCV valve. 2. Verify that the PCV system is not plugged. Was a problem found?	—	Go to Step 13	Go to Step 8
8	Check the injector connections. If any of the injectors are connected to an incorrect cylinder, correct as necessary. Was a problem found?	—	Go to Step 13	Go to Step 9
9	Perform the Injector Coil/Balance Test. Was a problem found?	—	Go to Step 13	Go to Step 10
10	Check for a problem with the engine cooling system. Was a problem found?	—	Go to Step 13	Go to Step 11
11	Check the EVAP canister for fuel loading. Refer to Evaporative Emission Control System. Was a problem found?	—	Go to Step 13	Go to Step 12
12	1. Remove excessive carbon build-up with a top engine cleaner. Refer to the instructions on the top engine cleaner can. 2. Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to Step 14
13	Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to Step 14
14	Does the exhaust emission test indicate excessive HC levels, or is "Long Term Fuel Trim" significantly in the negative range (rich condition)?	—	Go to Step 15	Go to Step 16

Step	Action	Value(s)	Yes	No
15	1. Check items that can cause the engine to run rich. Refer to Diagnostic Aids in DTC P0172 Diagnostic Support. Make any necessary repairs. 2. Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to Step 17
16	1. Check items that can cause the engine to run lean. Refer to Diagnostic Aids in DTC P0171. Make any necessary repairs. 2. Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to Step 17
17	Check the EGR system (refer to DTC P0401). Was a problem found?	—	Verify repair	Go to Step 18
18	Check for the following engine mechanical problems. <input type="radio"/> Low compression <input type="radio"/> Leaking cylinder head gasket <input type="radio"/> Worn or incorrect camshaft <input type="radio"/> Sticking or leaking valves <input type="radio"/> Valve timing <input type="radio"/> Broken Valve springs Was a problem found?	—	Verify repair	Go to Step 19
19	1. Review all the diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All electrical connections within a suspected circuit and/or system Was a problem found?	—	Verify repair	Contact Technical Assistance

DIESELING, RUN-ON SYMPTOM

DEFINITION:

Engine continues to run after key is turned OFF, but runs very rough. If engine runs smoothly, check the ignition switch and adjustment.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	1. Check for a short between B+ and the ignition feed circuit. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Review all the diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All connections within a suspected circuit and/or system Was a problem found?	—	Verify repair	Contact Technical Assistance

BACKFIRE SYMPTOM

DEFINITION:

Fuel ignites in the intake manifold, or in the exhaust system, making a loud popping noise.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	Check for proper ignition voltage output with spark tester J 26792. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Remove the spark plugs and check for gas or oil fouling, cracks, wear, improper gap, burned electrodes or heavy deposits. 2. If spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Visually/physically inspect the secondary ignition wires. Check for the following conditions: <ul style="list-style-type: none"> ○ Verify that all ignition wire resistances are less than the specified value. ○ Verify that ignition wires are correctly routed to eliminate cross-firing. ○ Verify that ignition wires are not arcing to ground. Spraying the secondary ignition wires with a light mist of water may help locate an intermittent problem. Was a problem found?	—	Verify repair	Go to Step 7
7	Check for an intermittent ignition system malfunction: <ul style="list-style-type: none"> ○ Intermittent CKP 58X signal. ○ Intermittent ignition feed circuit or sensor ground circuit to the crankshaft position sensor. Was a problem found?	—	Verify repair	Go to Step 8
8	To determine if there is a problem with fuel delivery, refer to Fuel System Diagnosis. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for the following engine mechanical problems: <ul style="list-style-type: none"> ○ Low compression ○ Leaking cylinder head gasket ○ Worn or incorrect camshaft ○ Incorrect valve timing ○ Sticking or leaking valves ○ Camshaft drive belt slipped or stripped. Was a problem found?	—	Verify repair	Go to Step 10

6E1-372 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Step	Action	Value(s)	Yes	No
10	Check the intake and exhaust manifold(s) for casting flash. Refer to Engine Mechanical. Was a problem found?	—	Verify repair	Go to Step 11
11	1. Review all the diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system Was a problem found?	—	Verify repair	Contact Technical Assistance

CUTS OUT, MISSES SYMPTOM

DEFINITION:

Steady pulsation or jerking that follows engine speed;
usually more pronounced as engine load increases.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	Check the PCM grounds to verify that they are clean and tight. Refer to the PCM wiring diagrams in Electrical Diagnosis. Was a problem found?	—	Verify repair	Go to Step 5
5	Monitor "Long Term Fuel Trim" on the Tech 2. Is the "Long Term Fuel Trim" in the negative range (rich condition)?	—	Go to Step 6	Go to Step 7
6	Check items that can cause the engine to run rich. Refer to "Diagnostic Aids" in DTC P0172. Was a problem found?	—	Verify repair	Go to Step 9
7	Is the long term fuel trim significantly in the positive range (lean condition)?	—	Go to Step 8	Go to Step 9
8	Check items that can cause the engine to run lean. Refer to Diagnostic Aids in DTC P0171. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for incorrect idle speed. Ensure that the following conditions are present: ○ Engine fully warm. ○ Accessories are OFF. 2. Using a Tech 2, monitor the IAC position. Is the IAC position within the specified values?	Between 5 and 50 counts	Go to Step 11	Go to Step 10
10	1. Visually/physically inspect for the following conditions: ○ Restricted air intake system. Check for a restricted air filter element, or foreign objects blocking the air intake system. ○ Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. ○ Check for a condition that causes a large vacuum leak, such as an incorrectly installed or faulty crankcase ventilation valve or brake booster hose disconnected. Was a problem found?	—	Verify repair	Go to Step 11

6E1-374 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Step	Action	Value(s)	Yes	No
11	Check the injector connections. If any of the injectors are connected to an incorrect cylinder, correct as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	1. Perform the Injector Coil/Balance Test. Was a problem found?	—	Verify repair	Go to Step 13
13	1. Check for fuel in the pressure regulator vacuum hose. 2. If fuel is present, replace the fuel pressure regulator assembly. Was a problem found?	—	Verify repair	Go to Step 14
14	Check for proper ignition voltage output with spark tester J 26792. Was a problem found?	—	Verify repair	Go to Step 15
15	1. Remove spark plugs and check for gas or oil fouling, cracks, wear, improper gap, burned electrodes of heavy deposits. 2. If spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs. Was a problem found?	—	Verify repair	Go to Step 16
16	Check for a loose ignition control module ground. Was a problem found?	—	Verify repair	Go to Step 17
17	Using a Tech 2, monitor the TP angle with the engine idling. Is the TP angle at the specified value and steady?	0%	Go to Step 18	For further diagnosis, refer to DTC P0123
18	Check the PCV valve for proper operation. Was a problem found?	—	Verify repair	Go to Step 19
19	Check for the following engine mechanical problems: <ul style="list-style-type: none"> ○ Low compression ○ Leaking cylinder head gasket ○ Worn or incorrect camshaft ○ Incorrect valve timing ○ Sticking or leaking valves ○ Camshaft drive belt slipped or stripped. Was a problem found?	—	Verify repair	Go to Step 20
20	Check for faulty motor mounts. Refer to Engine Mechanical for inspection of the mounts. Was a problem found?	—	Verify repair	Go to Step 21
21	1. Review all the diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system Was a problem found?	—	Verify repair	Contact Technical Assistance

HESITATION, SAG, STUMBLE SYMPTOM

DEFINITION:

Momentary lack of response as the accelerator is pushed down. Can occur at any vehicle speed. Usually most pronounced when first trying to make the vehicle move, as from a stop sign. May cause the engine to stall if severe enough.

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to Visual / Physical Check
4	1. Check the fuel control heated oxygen sensor (HO2S1). The HO2S1 should respond quickly to different throttle positions. If it doesn't, check for silicon or other contaminants from fuel or use of improper RTV sealant. The sensors may have a white powdery coating. Silicon contamination sends a rich exhaust signal which causes the PCM to command an excessively lean air/fuel mixture. Was a problem found?	—	Verify repair	Go to Step 5
5	Check the fuel pressure. Refer to Fuel System Pressure Test. Was a problem found?	—	Verify repair	Go to Step 6
6	Observe the "TP angle" display on the Tech 2 while slowly increasing throttle pedal. Does the TP angle display steadily increase from 0% at closed throttle to 100% at WOT?	—	Go to Step 7	Go to Step 13
7	Monitor "Long Term Fuel Trim" on the Tech 2. Is the "Long Term Fuel Trim" in the negative range (rich condition)?	—	Go to Step 8	Go to Step 9
8	Check items that can cause the engine to run rich. Refer to Diagnostic Aids in DTC P0172. Was a problem found?	—	Verify repair	Go to Step 10
9	Check items that can cause the engine to run lean. Refer to Diagnostic Aids in DTC P0171. Was a problem found?	—	Verify repair	Go to Step 10
10	Check for proper ignition voltage output with spark tester J 26792 (ST-125). For the procedure, refer to Electronic Ignition System. Was a problem found?	—	Verify repair	Go to Step 11
11	Check for a loose ignition control module ground. Was a problem found?	—	Verify repair	Go to Step 12

6E1-376 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Step	Action	Value(s)	Yes	No
12	<p>Visually/physically inspect the secondary ignition wires. Check for the following conditions:</p> <ul style="list-style-type: none"> ○ Verify that all ignition wire resistances are less than the specified value. ○ Value that ignition wires are correctly routed to eliminate cross-firing. ○ Verify that ignition wires are not arcing to ground. Spraying the secondary ignition wires with a light mist of water may help locate an intermittent problem. <p>Was a problem found?</p>	30,000 Ω	Verify repair	Go to Step 14
13	Replace the TP sensor.	—	Verify repair	—
14	<p>1. Check the ignition coil secondary resistance.</p> <p>2. Replace the coil if it is not within the specified value.</p> <p>Was a problem found?</p>	9 k Ω – 12k Ω	Verify repair	Go to Step 15
15	<p>1. Remove the spark plugs and check for gas or oil fouling, cracks, wear, improper gap, burned electrodes of heavy deposits.</p> <p>2. If spark plugs are fouled, the cause of fouling must be determined before replacing the spark plugs.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>Check the PCM grounds to verify that they are clean and tight. Refer to the PCM wiring diagrams in Electrical Diagnosis.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 17
17	<p>Visually/physically check vacuum hoses for splits, kinks, and proper connections and routing as shown on the Vehicle Emission Control Information label.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 18
18	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

RESTRICTED EXHAUST SYSTEM CHECK

Step	Action	Value(s)	Yes	No
1	Was the On-Board Diagnostic (OBD) System Check performed?	—	Go to Step 2	Go to OBD System Check
2	1. Remove the HO2S2. ○ For removal procedures, refer to Heated Oxygen Sensors in On-Vehicle Service. 2. Install the Exhaust Backpressure Tester in place of the Bank 1 HO2S. 3. Idle the engine at normal operating temperature. Does the reading on the gauge exceed the specified value?	8.62 kPa (1.25 psi)	Go to Step 5	Go to Step 3
3	With the exhaust back-pressure tester in place of HO2S, and the engine at normal operating temperature: Increase the engine speed to 2000 RPM while observing the gauge. Does the reading exceed the amount of the value column?	8.62 kPa (1.25 psi)	Go to Step 5	Go to Step 4
4	1. Re-install the HO2S2. (Refer to Heated Oxygen Sensors in On-Vehicle Service for installation procedure.) 2. Remove the HO2S1. 3. Install the Exhaust Back-Pressure Tester BT8515V or equivalent in place of the HO2S1. 4. Bring the engine to normal operating temperature while observing the gauge. 5. Increase the engine speed to 2000 RPM (allow 10 seconds for pressure build) and observe the gauge. Did the reading exceed the specified value?	8.62 kPa (1.25 psi)	Go to Step 6	System OK
5	Repair a restriction in the exhaust system after the catalytic converter. Possible faults include: ○ Collapsed pipe ○ Internal muffler failure	—	Verify repair	—
6	Replace the restricted catalytic converter.	—	Verify repair	—

NOTE: Diagnostic Trouble Codes will be set by running the vehicle to normal operating temperature after a cold start with the O2 sensor disconnected. After performing these tests, use the Tech 2 to erase the Diagnostic Trouble Codes that were set by the lack of O2 sensor activity.

DEFAULT MATRIX TABLE

SERVICE PROCEDURE DEFAULT STRATEGY

A referral strategy has been established to assist the technician with additional information when the cause of the failure cannot be determined. If no problem is found after performing diagnostics, then for further diagnostic information, refer to the default matrix table.

DEFAULT MATRIX TABLE

Strategy Based Diagnostic Charts	Initial Diagnosis	Default Section(s)
On-Board Diagnostic (OBD) System Check	Vehicle does not enter diagnostics.	Chassis Electrical
On-Board Diagnostic (OBD) System Check	Vehicle enters diagnostics and communicates with the Tech 2. MIL is ON in diagnostics. Engine does not start and run.	Ignition System Check
On-Board Diagnostic (OBD) System Check	Engine starts and runs, no PCM codes set. Customer complains of vibration.	—
PCM Power and Ground Check	On-Board Diagnostic (OBD) System Check.	Chassis Electrical
PCM Power and Ground Check	On-Board Diagnostic (OBD) System Check. PCM power and ground circuits OK. Data link voltage incorrect.	Chassis Electrical

Symptoms	Initial Diagnosis	Default Section(s)
Intermittents	<ol style="list-style-type: none"> On-board diagnostic (OBD) system check. Careful visual/physical inspections. 	Chassis Electrical
Hard Starts	<ol style="list-style-type: none"> OBD system check. Sensors (ECT, MAP, TP); MAP output chart. Fuel system electrical test, fuel system diagnosis. Ignition system. IAC system check. 	Engine Mechanical Ignition System Check Exhaust System Diagnosis
Surges and/or Chuggles	<ol style="list-style-type: none"> OBD system check. Heated oxygen sensors. Fuel system diagnosis. Ignition system. 	Calibration ID "Broadcast Code"/Service Bulletins Ignition System Check Generator Output Exhaust System Diagnosis
Lack of Power, Sluggish or Spongy	<ol style="list-style-type: none"> OBD system check. Fuel system diagnosis. Ignition system. EGR operation. EGR system check. 	Refer to Exhaust System in Engine Exhaust TCC Operation Calibration ID/Service Bulletins
Detonation / Spark Knock	<ol style="list-style-type: none"> OBD system check. EGR operation. EGR system check. Fuel system diagnosis. Ignition system. 	Cooling System Ignition System Check Calibration ID/Service Bulletins

Hesitation, Sag, Stumble	<ol style="list-style-type: none"> 1. OBD system check. 2. TP. 3. MAP output check. 4. Fuel system diagnosis. 5. Fuel injector and fuel injector balance test. 6. EVAP emission canister purge valve. 7. Ignition system. 	EGR Operation EGR System Check Generator Output Voltage (refer to Chassis Electrical) Calibration ID/Service Bulletins Ignition System Check
Cuts Out, Misses	<ol style="list-style-type: none"> 1. OBD system check. 2. Cylinder balance test. 	Ignition System Check
Rough, Unstable, or Incorrect Idle, Stalling	<ol style="list-style-type: none"> 1. OBD system check. 2. Fuel injector and fuel injector balance test. 3. EVAP emission canister purge valve check. 4. Ignition system. 5. IAC operation. 6. EGR operation. 	MAP Output Check Throttle Linkage IAC System Check EGR System Check A/C Clutch Control Circuit Diagnosis Crankcase Ventilation System Calibration ID/Service Bulletins Generator Output Voltage (refer to Chassis Electrical) Exhaust Diagnosis
Poor Fuel Economy	<ol style="list-style-type: none"> 1. OBD system check. 2. Careful visual/physical inspection. 3. Ignition system. 4. Cooling system. 	TCC Operation Exhaust System (refer to Engine Exhaust)
Engine Cranks But Will Not Run	<ol style="list-style-type: none"> 1. OBD system check. 	Fuel System Electrical Diagnosis Fuel System Diagnosis Fuel Injector Fuel Injector Balance Test
Excessive Exhaust Emissions or Odors	<ol style="list-style-type: none"> 1. OBD system check. 2. Emission test. 3. Cooling system. 4. Fuel system diagnosis. 5. Fuel injector and fuel injector balance test. 6. EVAP emission canister purge valve. 7. Crankcase ventilation system. 8. Ignition system. 9. MAP output check. 	EGR System Check Exhaust Diagnosis Calibration ID/Service Bulletins
Dieseling, Run-On	<ol style="list-style-type: none"> 1. OBD system check. 2. Careful visual/physical inspection. 3. Fuel system diagnosis. 	—
Backfire	<ol style="list-style-type: none"> 1. OBD system check. 2. Ignition system. 3. Fuel system diagnosis. 4. Fuel injector and fuel injector balance test. 5. EGR operation, EGR system check. 	Exhaust System Diagnosis, Intake Casting Flash, Ignition System Check


6E1-380 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION

Misfire	<ol style="list-style-type: none">1. OBD system check.2. Ignition system.3. Fuel system diagnosis.4. Fuel injector and fuel injector balance test.	Vibrations, Transmission, Driveshaft and Axle
Catalyst Monitor	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Heated oxygen sensors.	Exhaust System
Fuel Trim	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Fuel system diagnosis.4. Heated oxygen sensors.	Exhaust System Intake Air System
Evaporative Emissions	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Fuel system diagnosis.	—
Heated Oxygen Sensors	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.	Exhaust System


Camshaft Position (CMP) Sensor

Removal Procedure


1. Disconnect the negative battery cable.
2. Remove spark plug cover on top of valve cover by removing four retaining bolts.
3. Disconnect electrical connector from the sensor.



4. Remove drive belt. Refer to Engine Mechanical Section.
5. Remove top harness cover installed on timing belt cover by removing a retaining screw.
6. Remove the retaining bolts holding crankshaft pulley, and pull crankshaft pulley while wiggling. Refer to Engine Mechanical Section.
7. Remove the retaining screws for timing belt cover and timing belt cover.




8. Remove the retaining bolt for the sensor and pull up camshaft position sensor.




Installation Procedure

1. Insert camshaft position sensor in position.
2. Install retaining bolt.




3. Install the timing belt cover and the retaining screws.
4. Install the crank shaft pulley and the mounting bolts. Holes for mounting bolts are off the pitch. The pulley can be mounted only one way to install all mounting bolts. Tighten the bolts. Refer to Engine Mechanical section.

5. Install the drive belt. Refer to Engine Mechanical Section.



014RX005

6. Install the top harness cover onto timing belt cover.
7. Connect electrical connector to the sensor and securely lock it.
8. Install the spark plug cover.
9. Connect the negative battery cable.




014RX004

Crankshaft Position (CKP) Sensor


Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the drive belt. Refer to Engine Mechanical Section.



014RX003


3. Remove the power steering pump and mounting-bracket from engine. Refer to Engine Mechanical Section.
4. Disconnect electrical connector from the sensor.



014RX006

5. Remove the retaining bolt and sensor from the engine block.


NOTE: Use caution to avoid any hot oil that might drip out.



0013


Installation Procedure

1. Install the crank shaft position sensor to its position.
2. Install and tighten the mounting bolt. Refer to Engine Mechanical Section.




0013

3. Reinstall the power steering pump and bracket to the engine.



014RX006

4. Reinstall the accessory drive belt.
5. Connect the negative battery cable.




014RX003

IMPORTANT: PCM must re-learn Crankshaft Position when the CKP sensor is replaced. Refer to CKP sensor learn mode on the Tech 2, or Tooth Error Correction in the Service Manual.

EEPROM

EEPROM


The Electronically Erasable Programmable Read Only Memory (EEPROM) is a permanent memory that is physically soldered within the PCM. The EEPROM contains program and calibration information that the PCM needs to control Powertrain operation.



EEPROM Programming

1. Connect Tech 2 to the vehicle DLC and retrieve information from the PCM. Ensure that the following condition have been met:
 - Battery is fully charged.
 - The Ignition is in ON position.
 - Tech 2 cable is securely connected to DLC.
2. Download latest program and calibration from ITCS. Always use latest ITCS software to program PCM. Refer to Up-to-date ITCS user's guide.
3. Reconnect Tech 2 to the DLC and program PCM.
 - Make sure the ignition is recycled after information is retrieved.

- Ensure the ignition is stay in ON position after programming is started.



Functional Check


1. Perform the On-Board Diagnostic System Check.
2. Start the engine and run for least one minute.
3. Check for DTCs using Tech 2.
4. If the PCM fails to program, proceed as follow:
 - Ensure that all PCM connections are OK.
 - Check the ITCS for latest version software.
 - Attempt to program PCM again. If PCM still cannot be programmed properly, replace PCM. The replacement PCM must be programmed.

Engine Coolant Temperature (ECT) Sensor

Removal Procedure

1. Disconnect the negative battery cable.
2. Drain enough engine coolant so that the coolant level will be below the ECT sensor.
3. Remove electrical connector from the sensor located on the intake manifold above the ignition coil.


4. Unscrew the sensor from the manifold.



014RX008

Installation Procedure

1. Install the sensor into the intake manifold. Do not over tighten.
2. Connect electrical connector.
3. Add engine coolant to required level. Refer to Engine Cooling System Section.
4. Connect the negative battery cable.



0016

Heated Oxygen Sensor (HO2S)


Removal Procedure

1. Disconnect the negative battery cable.
2. Locate the two oxygen sensors.
 - Bank 1 sensor 1 is mounted on the exhaust pipe ahead of the catalytic converter.

- Bank 1 sensor 2 is mounted on the exhaust pipe behind the catalytic converter.

3. Disconnect pig tail electrical connector.

IMPORTANT: The pigtail is permanently attached to the sensor. Be careful not to pull the wires out.




014RX010

4. Unscrew sensors from the exhaust pipe. Because of the expansion and contraction of the metal in the exhaust system over time, this may be difficult if the engine temperature is below 48 degree C.

Inspection Procedure

NOTE: Both sensors are identical. Inspect each in the same way.

1. Inspect the pigtail and the electrical connector for grease, dirt, corrosion and bare wire or worn insulation.
2. Inspect the louvered end of the sensor for grease, dirt, excessive carbon build up or other contaminants.




TS23739

Installation Procedure


NOTE: If HO2S is reinstalled after removal, special anti-seize compound or the equivalent should be applied to the threads. Special anti-seize compound, (P/N 5613695), is used on the HO2S threads. This compound consists of glass beads suspended in a liquid graphite solution. The graphite burns away with exhaust heat, but the glass beads will remain, making the sensor easier to remove.

1. Apply anti-seize compound or the equivalent to the thread.




2. Install HO2S on the exhaust pipe.
3. Tighten the sensor to 55 Nm (40 lb ft)
4. Connect the pig tail to the wiring harness.
5. Connect the negative battery cable.

(Pre-Catalytic Converter Heater Oxygen Sensor Location)




(Post-Catalytic Converter Heater Oxygen Sensor Location)



Intake Air Temperature (IAT) Sensor


Removal Procedure

1. Disconnect the negative battery cable.
2. The IAT sensor is located in the intake air duct between the air filter and the throttle body.



3. Disconnect the electrical connector from the sensor.


4. Remove the sensor from intake air duct by using a rocking motion while pulling the sensor.



0018

Installation Procedure

1. Install the IAT sensor into intake air duct. Make sure the sensor is pushed all the way into the intake air duct.
2. Connect electrical connector.
3. Connect the negative battery cable.




014RX011

Manifold Absolute Pressure (MAP) Sensor

Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect the electrical connector from the sensor. (The MAP sensor is located on the intake manifold behind throttle body.)
3. Remove a mounting bolt securing the sensor to the manifold.
4. Remove the sensor from the intake manifold using rocking motion while pulling the sensor.



014RX012

Installation Procedure

1. Push MAP sensor into the manifold. Make sure the sensor is pushed always into its position.
2. Install a mounting bolts and tighten.
3. Connect electrical connector.
4. Connect the negative battery cable.



014RX013

Malfunction Indicator Lamp (MIL)

Malfunction Indicator Lamp (MIL)

Refer to Instrument Panel Removal Procedure.


Powertrain Control Module (PCM)

Electrostatic Discharge (ESD) Damage

Electronic components used in the control system are often designed to carry very low voltage. Electronic components are susceptible to damage caused by electrostatic discharge. Less than 100 volts of static electricity can cause damage to some electronic components. By comparison, it takes as much as 4000 volts for a person to even feel the zap of a static discharge. There are several ways for a person to become statically charged. The most common methods of charging are by friction and by induction. An example of charging by friction is a person sliding across a car seat. Charging by induction occurs when a person with well insulated shoes stands near a highly charged object and momentarily touches ground. Charge of the same polarity are drained off leaving the person highly charged with opposite polarity. Static charge can cause damage, therefore, it is important to use care when handling and testing electronic components.

NOTE: To prevent possible Electrostatic Discharge damage, follow these guidelines:

- Do not touch the control module connector pins or soldered components on the control module circuit board.
- Do not open the replacement part package until the part is ready to be installed.
- Before removing the parts from the package, ground the package to a known good ground on the vehicle.
- If the parts been handled while sliding across the seat, or while sitting from standing position, or walking a distance, touch a known good ground before installing the parts.



014RX002

NOTE: To prevent internal PCM damage, the ignition must be OFF position in order to disconnect or reconnect power to the PCM (for example: battery cable, pig tail, PCM fuse, jumper cable, etc.).


IMPORTANT: When replacing the production PCM with a service PCM, it is important to transfer the broadcast code and production PCM number to the service PCM label. This will allow positive identification of PCM parts throughout the service life of the vehicle. Do not record this information on PCM metal cover.

IMPORTANT: The ignition should always be in the OFF position in order to install or remove the PCM connectors. Service of the PCM should normally consist of either replacement of the PCM or EEPROM reprogramming. If the diagnostic procedure call for the PCM to be replaced, the replacement PCM should be checked first to ensure it has the correct part number. If it is, remove the faulty PCM and install the new service PCM. The service PCM EEPROM will need to be programmed. Additionally, after programming, the CKP Sensor Tooth Error Correction (TEC) Learn procedure will need to be performed.

Removal Procedure

1. Disconnect the negative battery cable.
2. Block the wheels.
3. Remove ashtray inner.


4. Remove a screw located behind ashtray.



014RX014

5. Pull out Face trim of console.

6. Remove two screws located inside of center console storage box and pull up rear part of center console.




014RX015

7. Unscrew the shift knob.

8. Remove four screw holding front part of the console and pull the console up.

9. Disconnect the red, white and blue electrical connector at the PCM.




014RX016

10. Remove two nuts in the front of PCM.

11. Remove two nuts in the rear of PCM.


12. Pull the PCM out from dashboard.




014RX002

Installation Procedure


1. Place PCM into its position and secure by four mounting screws.




2. Connect all three connectors to PCM. All connectors are color keyed. Same color male and female connectors join together.



3. Install the front center console and secure by four retaining screws.




4. Install the rear center console and secure it by two retaining screw into storage box.



5. Snap face plate into its position and secure it by a screw.
6. Insert ashtray inner.
7. Insert the shift knob.
8. Connect the negative battery cable.

9. Remove wheel blocks.




014RX014

Throttle Position (TP) Sensor

Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the TPS electrical connector.
3. Remove the two screws and TP sensor from the throttle body.

NOTE: Do not clean the TP sensor by soaking it in solvent. The sensor will be damaged as a result.




101RX002

Function Check

Use a Tech 2 to check the TP sensor output voltage at closed throttle.


- The voltage should be under 0.25 volts.
- If the reading is greater than 0.25 volts, check the throttle shaft to see if it is binding. Check that the throttle cable is properly adjusted, also. Refer to Throttle Cable Adjustment.
- If the throttle shaft is not binding and the throttle cable is properly adjusted, install a new TP sensor.



101RX003


Installation Procedure

1. Install the TP sensor on the throttle body with two screws.



101RX003

2. Connect the electrical connector.
3. Connect the negative battery cable.




Vehicle Speed Sensor (VSS)

Removal Procedure


1. Disconnect the negative battery cable.
2. VSS is located on the right side of the transmission case just ahead of the rear propeller shaft. Disconnect the VSS electrical connector.
3. Remove the bolt and the VSS from the transmission case by wiggling it slightly and pulling it straight out.

IMPORTANT: Have a container ready to catch any fluid that leaks out when the VSS is removed from the transfer case.




Inspection Procedure

1. Inspect the electrical connector for signs of corrosion or warping. Replace the VSS if the electrical connector is corroded or warped.
2. Inspect the VSS driven gear for chips, breaks, or worn condition. Replace the VSS if the driven gear is chipped, broken or worn.
3. Inspect the O-ring for wear, nicks, tears, or looseness. Replace the O-ring if necessary.




Installation Procedure

1. Install the VSS in the transmission case with the notch for the connector facing the rear.
2. Secure the VSS with mounting bolt. Tighten the bolt to 16 Nm (12 lb ft).




3. Connect electrical connector to the VSS.
4. Check the transmission oil level. Add oil if necessary.

5. Connect the negative battery cable.



014RX020

4. Remove the air filter element.




014RX023

Air Filter

Removal Procedure


1. Disconnect electrical connector at the IAT sensor.
2. Release the four latches securing the lid to the air cleaner housing.
3. Remove the air cleaner lid.



014RX019

Installation Procedure


1. Install the air filter element in the air cleaner housing.



014RX023


2. Install the air cleaner lids.
3. Secure the three latches, holding the lid on the air cleaner housing.

4. Connect the electrical connector to the IAT sensor.



014RX019

NOTE: Do not clean the IAC valve by soaking it in solvent. The valve will be damaged as a result.




014RX022

Idle Air Control (IAC) Valve

Removal Procedure

1. Disconnect the negative battery cable.




101RX002

2. Disconnect the IAC electrical connector.

3. Remove the two screws and IAC valve from the throttle body.

Cleaning and Inspection Procedure

- Clean the IAC valve O-ring sealing surface, pintle valve seat and air passage.
- Use carburetor cleaner and a parts cleaning brush to remove carbon deposit. Do not use a cleaner that contain methyl ethyl ketone. This is an extremely strong solvent and not necessary for this type of deposit.
- Shiny spots on the pintle are normal and do not indicate misalignment or a bent pintle shaft.
- Inspect the IAC valve O-ring for cuts, cracks or distortion. Replace the O-ring if damaged.




0006

Measurement Procedure

- In order to install a new IAC valve, measure the distance between the tip of the pintle and the mounting flange. If that measurement is 28 mm or less, the valve need no adjustment. If the measurement is greater than 28 mm, apply finger pressure and retract the valve. The force required to retract the pintle on a new valve will not damage the valve, shaft or pintle.

NOTE: Do not push or pull on the IAC valve pintle on IAC valve that have been in service. The force required to move the pintle may damage it.


IMPORTANT: Use an identical replacement part in order to replace a valve. IAC valve pintle shape and diameter are designed for the specific application.



TS23746


Installation Procedure

1. Install IAC valve on the throttle valve body with the two screws. Tighten the screw to 1 Nm (9 lb in).



014RX022

2. Connect electrical connector to IAC valve.
3. Connect the negative battery cable.




101RX002

Intake Air Duct

Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect electrical connector at IAT sensor.
3. Remove the IAT sensor if necessary. Refer to Intake Air Temperature Sensor Removal.



014RX011


4. Loosen retaining clamps at the throttle body and at the air filter box.

5. Disconnect brake booster vacuum hose at intake manifold and at brake booster.



014RX025


6. Remove retaining nut at the intake air duct bracket at top of valve cover.
7. Disconnect the intake air duct from the throttle body and at the air filter box.



014RX019


Installation Procedure

1. Connect the intake air duct at the throttle body and at the air filter box. Make sure retaining hole is inserted to the intake air duct bracket.



014RX019


2. Tighten retaining clamp at the throttle body and at the air filter box.
3. Install a nut to the intake air duct bracket and tighten.
4. Connect brake booster vacuum hose to intake manifold and to brake booster and secure them with clamps.



014RX026

5. Install IAT sensor if necessary. Refer to Intake Air Temperature Sensor Installation.
6. Connect electrical connector at IAT sensor.

7. Connect the negative battery cable.




014RX011

IMPORTANT: Use an identical replacement part in order to replace a valve. IAC valve pintle shape and diameter are designed for the specific application.

Knock Sensor


Removal Procedure

1. Disconnect negative battery cable.
2. Disconnect pig tail electrical connector at near the top of generator.



014RX027

3. Unscrew retaining bolt from Knock Sensor located passenger side of engine block just front of starter.




014RX028

4. Remove Knock Sensor with retaining bolt.

Installation Procedure

1. Install Knock Sensor with retaining bolt.
2. Connect pig tail electrical connector.
3. Connect battery negative cable.




014RX029


Oil Pressure Switch

Removal Procedure

1. Disconnect battery negative cable.
2. Disconnect electrical connector at Oil Pressure Switch.




3. Unscrew Oil Pressure Switch from Oil Filter Mounting Housing.



Installation Procedure

1. Install Oil Pressure Switch into Oil Filter Mounting Housing and tighten.


2. Connect electrical connector.
3. Connect battery negative cable.




FUEL METERING SYSTEM Accelerator Cable Assembly

Removal Procedure

1. Loosen the adjusting nut on the cable bracket mounting on the throttle body.
2. Remove the cable clip from holding bracket.



3. Remove accelerator control cable (on the throttle valve end).




101RW006

4. Remove the accelerator control cable (on the accelerator pedal end).
5. Remove the grommet.
6. Remove the accelerator control cable.

Inspection Procedure

Check the following items, and replace the control cable if any abnormality is found:


- ☐ The control cable should move smoothly.
- ☐ The control cable should not be bent or kinked.
- ☐ The control cable should be free of damage and corrosion.



014RX032


Installation Procedure

1. Install the accelerator control cable.
2. Install the grommet.
3. Install the accelerator control cable on the accelerator pedal.



014RX032


4. Install the accelerator control cable on the throttle valve.



101RW006

5. Install the cable clip to the holding bracket.

6. Adjust the accelerator cable. Refer to Accelerator Cable Adjustment Section.




Accelerator Cable Adjustment

Adjustment Procedure

1. Loosen the adjusting nut.
2. Loosen the jam nut.
3. Pull the outer cable while fully closing the throttle valve.
4. Tighten the adjusting nut.
5. Tighten the jam nut.
6. Loosen the adjusting nut by three turns.
7. Tighten the jam nut again.
8. Manually operate valve.


IMPORTANT: The valve lever must return up to the stopper screw. If the valve lever does not reach the stopper screw, repeat the procedure again from Step 1.



Accelerator Pedal Replacement


Removal Procedure

1. Disconnect the accelerator pedal control cable from the accelerator pedal assembly.
2. Remove the two screws retaining the accelerator pedal to the bulkhead.
3. Remove the accelerator pedal from the bulkhead.



Installation Procedure

1. Install the accelerator pedal assembly to the bulkhead with two screws.
2. Connect the accelerator control cable to the accelerator pedal assembly.
3. Adjust accelerator cable if necessary. Refer to Accelerator Cable Adjustment Section.



Fuel Filler Cap


Fuel Filler Cap

The Fuel filter cap includes a vacuum valve and a pressure valve. If high vacuum or pressure occurs in the fuel tank, each valve works to adjust the pressure in order to prevent damage to the tank at the EGR valve.

Inspection Procedure

NOTE: Replace the fuel filler cap with the same type of filler cap that was originally installed on the vehicle.


- Check the seal ring in the filler cap for any abnormality and for seal condition.
- Replace the filler cap if any abnormality is found.




Fuel Filter

Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the fuel filler cap.




3. Disconnect the fuel lines from the fuel filter on the engine side.
4. Disconnect the fuel line from the fuel filter on the fuel tank side.




5. Remove the bolt on the fuel filter holder.

6. Remove the fuel filter.




Inspection Procedure

1. Replace the fuel filter when the following occur:
 - Fuel leaks from the fuel filter body
 - The fuel filter body is damaged
 - The fuel filter is clogged with dust or sediment
2. If the drain hole is clogged at filler neck is clogged with dust, clean the drain hole with air.



Installation Procedure

1. Install the fuel filter in the correct direction.
2. Install the bolt on the fuel filter holder.
3. Connect the fuel line on the engine side.
4. Connect the fuel line on the fuel tank side.
5. Install the fuel filler cap.
6. Connect the negative battery cable.



Fuel Injectors


Removal Procedure

NOTE: If the fuel injectors are leaking, the engine oil may be contaminated with fuel. Check the oil for signs of contamination and change the oil and filter if necessary.


NOTE: Use care in removing the fuel injector in order to prevent damage to the fuel injector electrical connector pins or fuel injector nozzles. The fuel injector is an electrical component and should not be immersed in any type of cleaner as this may damage the fuel injector.

IMPORTANT: Fuel injectors are serviced as complete assembly only.

1. Disconnect the negative battery cable.




2. Disconnect electrical connector from fuel injector.
3. Remove the fuel rail. Refer to Fuel Rail Removal Procedure.



4. Remove the fuel injector retainer clip.
5. Remove fuel injector assembly from fuel rail.

6. Remove O-ring from the fuel injector.
7. Remove O-ring backup from fuel injector.




Inspection Procedure

1. Inspect O-ring for crack, damage or leaks.
2. Replace worn or damaged O-ring.
3. Lubricate the new O-rings with engine oil before installation.


Installation Procedure

1. Lubricate the new O-ring with engine oil.
2. Install the O-ring backup on the fuel injector.
3. Install new O-ring on the fuel injector.
4. Install all four injector on the fuel rail.
5. Use new injector retainer clip to retain the injector to the fuel rail.
6. Coat the end of the fuel injector with engine oil.



7. Install fuel rail assembly. Refer to Fuel Rail Installation Procedure.

8. Connect the negative battery cable.




Fuel Pressure Regulator

Removal Procedure

CAUTION: To reduce the risk of fire and personal injury, it is necessary to relieve the fuel system pressure before servicing the fuel system components.


CAUTION: After relieving the fuel system pressure, a small amount of fuel may be released when servicing fuel lines or connections. Reduce the chance of personal injury by covering the fuel line fitting with a shop towel before disconnecting the fittings. The towel will absorb any fuel that may leak out. When the disconnect is completed, place the towel in an approved container.

NOTE: Compressed air must never be used to test or clean a fuel pressure regulator, as damage to the fuel pressure regulator may occur.




NOTE: To prevent damage to the fuel pressure regulator, do not immerse the pressure regulator in solvent.

1. Depressurize the fuel system. Refer to Fuel Pressure Relief Procedure.
2. Disconnect the negative battery cable.
3. Remove the fuel pump relay.
4. Disconnect the vacuum line from fuel pressure regulator.




5. Remove the fuel pressure regulator retaining screw.
6. Remove the fuel pressure regulator retaining bracket.
7. Remove the fuel pressure regulator from fuel rail.




Installation Procedure

1. Insert the fuel pressure regulator into the fuel rail.



014RX039


2. Install the fuel pressure regulator retaining bracket and tighten with a screw.
3. Connect vacuum line onto the fuel pressure regulator.



014RX038

4. Install the fuel pump relay.
5. Connect the negative battery cable.

6. Crank the engine until it starts. Cranking the engine may take longer than usual due to trapped air in the fuel line.




014RX035

Fuel Pressure Relief Procedure

CAUTION: To reduce the risk of fire and personal injury, it is necessary to relieve the fuel system pressure before servicing the fuel system components.

CAUTION: After relieving the fuel system pressure, a small amount of fuel may be released when servicing fuel lines or connections. Reduce the chance of personal injury by covering the fuel line fitting with a shop towel before disconnecting the fittings. The towel will absorb any fuel that may leak out. When the disconnect is completed, place the towel in an approved container.


1. Remove the fuel filler cap.




041RW005

6E1-406 RODEO X22SE 2.2L ENGINE DRIVEABILITY AND EMISSION


2. Remove the fuel pump relay from the underhood relay box.
3. Start the engine and allow it to stall.
4. Crank the engine for about 30 seconds.
5. Disconnect the negative battery cable.



4. Remove fuel tank. Refer to Fuel Tank Removal Procedure.
5. Using J-39763, twist the fuel pump counter-clockwise to release from fuel tank.




6. Lift fuel pump to remove from fuel tank.



Fuel Pump Assembly


Removal Procedure

1. Disconnect the negative battery cable.
2. Drain all fuel from fuel tank from filler neck.
3. Remove the fuel pump relay from the fuse and relay box at right side of engine room.



Inspection Procedure


Inspect in-tank fuel filter for tears, damage or evidence of dirt derbies or water in the fuel. If any of these condition exist, replace the in-tank fuel filter.



041RX003


Installation Procedure

1. Insert the fuel pump assembly into fuel tank and place them at its position.




041RX002

2. Using J-39763, twist fuel pump assembly clock wise into the lock.



901RX036

3. Install the fuel tank. Refer to Fuel Tank Installation Procedure.
4. Install the fuel pump relay.
5. Connect the negative battery cable.



041RX004


Fuel Pump Relay

Removal Procedure

1. Remove the fuse and relay box cover located right side of engine room.
2. Determine correct relay by consulting to the diagram on the cover.
3. Insert a small screwdriver or use thumb pressure to release the retainer of the relay.
4. Pull the relay straight up and out of the fuse and relay box.

Installation Procedure

1. Inserts the relay into the correct place in the fuse and relay box with the catch slot aligned to retainer.
2. Press down until the catch of retainer engages.
3. Install fuse and relay box cover.




Fuel Rail Assembly

Removal Procedure

NOTE:

- Use care when removing the fuel rail assembly in order to prevent damage to the injector electrical connector terminal and the injector spray tips.
- Fitting should be capped and holes plugged during servicing to prevent dirt and other contaminants from entering open lines and passage.

IMPORTANT: An eight-digit identification number is stamped on side of the fuel rail. Refer to this number when you service the fuel rail or when a replacement part is required.




1. Depressurize the fuel system. Refer to Fuel Pressure Relief Procedure.
2. Disconnect the fuel inlet at the rear of the engine.
3. Disconnect the fuel return line at front of the engine.
4. Disconnect the injector electrical connectors.
5. Remove the nuts holding wiring harness onto fuel rail.
6. Remove the bolts retaining fuel rail to the intake manifold.

Lift up the injectors carefully to separate them from intake manifold.


Lift up the fuel rail with injectors as assembly. Do not separate the fuel injectors from fuel rail.

If an injector become separated from fuel rail, injector backup O-ring and injector retainer clip must be replaced.

Drain residual fuel from fuel rail into an approved container.




7. If removal of fuel pressure regulator is necessary. Refer to Fuel Pressure Regulator Removal Procedure.
8. If removal of fuel injector is necessary. Refer to Fuel Injectors Removal Procedure.



014RX037


4. Install two fuel rail retaining bolts. Tighten fuel rail retaining bolts to 19 Nm (14 lb ft)
5. Place wiring harness in its place and secure it with two nuts.
6. Connect electrical connector to each fuel injector.



014RX036


Installation Procedure

1. Install the fuel injectors if necessary. Refer to Fuel Injector Installation Procedure.
2. Install the fuel pressure regulator if necessary. Refer to Fuel Pressure Regulator Installation Procedure.
3. Place the fuel injector rail assembly on the manifold and insert the injectors into each port by pushing fuel rail.



014RX037

7. Connect the fuel supply line securely. Do not over tighten.
8. Connect the fuel return line securely. Do not over tighten.
9. Connect the negative battery cable.
10. Crank the engine until it start. Cranking the engine may take longer than usual due to trapped air in the fuel system. Check for leak. If fuel leak is observed, stop engine immediately. Before correct fuel leak, be sure to depressurize system again.




014RX035

Fuel Tank


Removal Procedure

1. Disconnect the negative battery cable.
2. Remove fuel filler cap.
3. Drain the fuel from fuel filler neck.
4. Disconnect the fuel filler hose at fuel tank.
5. Disconnect the air breather hose at the fuel tank.
6. Disconnect the evaporator hose at the fuel tank.
7. Hold entire fuel tank at the bottom with stands.
8. Disconnect fuel supply lines and fuel return line at near the fuel filter inside of body frame.




041RX005

9. Remove four bolts (two in front and two in rear) holding fuel tank to the frame.
10. Lower tank assembly from the vehicle a little to make access space on top.
11. Disconnect two electrical connectors at fuel pump.



041RX006


12. Remove fuel tank assembly from the vehicle.
13. Remove four nuts retaining tank under guard to the tank.
14. Remove the tank from the guard.



041RX002

Installation Procedure


1. Secure fuel tank into under guard with four retaining bolts, if necessary.
2. Place the fuel tank assembly onto stands.
3. Lift the fuel tank assembly near the position.
4. Connect two electrical connectors at fuel pump.
5. Lift the fuel pump to its position and secure it with four mounting bolts. Make sure that all hoses and fuel lines are out of way between the fuel tank and the fuel tank bracket. Tighten the fuel tank retaining bolts to 36 Nm (27 lb ft).




041RX007

6. Connect fuel supply and return lines.

7. Connect the fuel filler hose, the air breather hose and EVAP hose onto fuel tank and secure them with clamps.



8. Pour fuel into fuel tank.
9. Install fuel filler cap securely.
10. Connect the battery negative cable.




Throttle body (TB)


Removal Procedure

1. Disconnect the negative battery cable.
2. Drain the cooling system. Refer to Cooling System.
3. Remove the air intake duct. Refer to Air Intake Duct Removal Procedure.
4. Remove the accelerator cable from throttle. Refer to Accelerator Cable Assembly Removal Procedure.
5. Disconnect the electrical connectors from the throttle position sensor and the idle air control valve solenoid.
6. Disconnect all vacuum hoses below air horn.

7. Disconnect coolant lines.



8. Remove the mounting bolts retaining the throttle body the intake manifold.
9. Lift up the throttle body from the intake manifolds.




10. Remove the gaskets from the intake manifolds.
11. Remove the IAC. Refer to Idle Air Control Valve Solenoid Removal Procedure.
12. Remove TPS. Refer to Throttle Position Sensor Removal Procedure.

Inspection Procedure

NOTE: Do not use solvent of any type when you clean the gasket surfaces on the intake manifold and the throttle body assembly. The gasket surface and the throttle body assembly may be damaged as results.


1. If the throttle body gasket needs to be released, remove any gasket material that may be stuck to the mating surfaces of the manifold.

2. Do not leave any scratches in the aluminum casting.




Installation Procedure


1. Install IAC valve onto the throttle body. Refer to Idle Air Control Valve Solenoid Installation Procedure.
2. Install TPS onto the throttle body if necessary. Refer to TPS Installation Procedure.
3. Place the gasket then the throttle body on the manifold.
4. Install four mounting bolt. Tighten the throttle body mounting bolt to 13.5 Nm (10 lb ft).



5. Connect coolant line and secure them with clamps.
6. Connect all vacuum hoses and secure them with clamps if necessary.
7. Install accelerator control cable bracket onto the throttle body.
8. Connect accelerator control cable to throttle plate.



9. Connect electrical connector at IAC valve and TPS.
10. Install the air intake duct. Refer to Air Intake Duct Installation Procedure.
11. Fill the cooling system with required coolant. Refer to Engine Cooling System.
12. Connect the negative battery cable.




ELECTRONIC IGNITION SYSTEM Ignition Control Module (ICM)

Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the electrical connector from the ignition control module.
3. Remove the two attaching screws.
4. Remove the ignition control module from the engine block.

Installation Procedure

1. Fasten the module to the engine block with two screws.
2. Reconnect the electrical connector.
3. Reconnect the negative battery terminal.




Ignition Coil

Removal Procedure


1. Disconnect the negative battery cable.
2. Drain the cooling system. Refer to Engine Cooling System.
3. Remove the heater supply and return hose.
4. Remove the coolant return hose.
5. Disconnect all four spark plug cables from the coil.
6. Disconnect electrical connector from the ignition coil.
7. Remove three mounting bolt from the ignition coil.

8. Remove the ignition coil from the bracket.



Installation Procedure

1. Install the ignition coil onto the bracket with three mounting bolts.
2. Connect electrical connector at the ignition coil.
3. Connect spark plug cable to the ignition coil.
4. Connect heater supply and return hose and secure them with clamps.
5. Connect coolant return line and secure them with clamps.
6. Fill the cooling system with required coolant. Refer to Engine Cooling System.
7. Connect the negative battery cable.



Spark Plugs


Removal Procedure

Type: NGK BPR6ES-11


Spark Gap : 1.05 MM (0.040")

Spark Plug Torque : 25 Nm (18 lb ft)

1. Disconnect the negative battery cable.
2. Remove four bolt holding spark plug cover plate to top of valve cover, and remove the cover plate.
3. Pull ignition wire using hocks attached to end of spark plug cable.




4. Remove the spark plug.



Inspection Procedure

1. Check the insulator for cracks. Replace the spark plug if crack are present.

2. Check the electrode condition and replace the spark plug if necessary.



If the spark plug electrodes and insulators are fouled with carbon or oil, the engine will not operate efficiently.


There are number of possible causes:

- ☐ Fuel mixture is too rich.
- ☐ Oil in the combustion chamber.
- ☐ The spark plug gap is not set correctly.

If spark plug fouling is excessive, check the fuel and electrical system for possible causes of trouble. If fuel and electrical system are normal, install spark plug of a higher heat range which have the same physical dimensions as the original equipment spark plug.

The following symptoms are characteristics of spark plugs that are running too hot:

- ☐ Fuel mixture is too lean.
- ☐ Heat range is incorrect.




If vehicle usage does not conform to normal driving conditions, a more suitable spark plug may be substituted.

If fuel and electrical system are normal, in most cases of this sort, the problem can be corrected by using a colder

type spark plug with the same physical dimensions as the original equipment spark plug.


3. Check the gaskets for damage and replace if necessary.
4. Measure the spark plug gap. The specification is 1.05 mm (0.040").
5. Adjust the spark gap by bending the grounded electrode.



014RX048

Installation Procedure

1. Tighten the spark plug to the 25 Nm (18 lb ft).
2. Push the spark plug cable in until it snaps in.
3. Install spark plug cover onto valve cover and secure it with four retaining bolts.




014RX049

Spark Plug Cables

Spark Plug Cables

The cable contains a synthetic conductor which is easily damaged. Never stretch or kink the cable. Disconnect the cable from spark plug and the ignition coil.

The original equipment cables and the ignition coil are marked to show correct location of the cables. If spark plug cables or the ignition coil are replaced previously, before cables are removed from the ignition coil, mark the cables and the coil so they can be reconnected in the same position.




014RX050

Inspection Procedure

NOTE: Never puncture the spark plug cable's insulation with a needle or the pointed end of a probe into the cable. An increase in resistance would be created which would cause the cable to become defective.

1. If the cable has broken or cracked insulation, it must be replaced.
2. If the terminals are corroded or loose, the cable must be replaced.
3. Check that the cable resistance does not exceed 10 k Ω per foot.



014RX051

EMISSIONS Catalytic Converter


Catalytic Converter

Refer to Engine Exhaust.

Air Conditioning Relay

Removal Procedure

1. Remove the fuse and relay box cover at right side of engine room.
2. Refer to the diagram on the cover to determine which is the correct relay.
3. Insert small screwdriver or use thumb pressure to release the retainer of the relay.
4. Pull the relay straight up and out of the fuse and relay box.



014RX052

Installation Procedure

1. Insert the relay into the correct place in the fuse and relay box with the catch slot aligned to retainer.
2. Press down until the catch of retainer engages.
3. Install fuse and relay box cover.

Ignition Timing Adjustment

Ignition Timing Adjustment

There is no timing adjustment. The timing signal is furnished by the CKP and the CMP signal. PCM control the ignition timing.

EVAP Canister Hoses

EVAP Canister Hoses

To see the routing of the EVAP canister hoses, refer to Vehicle Emission Control Information in Diagnosis or

Emission Label located bottom side of the hood. Use 6148M or equivalent when you replace the EVAP canister hoses.


EVAP Canister

Removal Procedure

1. Disconnect all hoses.
2. Remove two mounting bracket nuts.

Inspection Procedure


1. Inspect the hoses for cracks, damage and leaks.
2. Inspect the canister for damages.



014RX001

Installation Procedure

1. Install EVAP canister onto crossmember with two mounting bolts.
2. Connect all hoses and secure them with clamps.




014RX054

EVAP Canister Vent Solenoid

Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect electrical connector at the vent valve.
3. Disconnect vent hoses from the solenoid valve.
4. Remove the filter and vent valve solenoid assembly by pulling it out from bracket.
5. Remove a screw holding the solenoid.
6. Remove vent valve solenoid from filter.



014RX055

Installation Procedure

1. Install the vent valve solenoid to the filter and secure it with a screw.
2. Insert the vent valve assembly onto EVAP canister bracket.
3. Connect all hoses and secure them with clamps.
4. Connect electrical connector at vent valve solenoid.
5. Connect the negative battery cable.




014RX054

EVAP Canister Purge Valve Solenoid


Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect electrical connector from EVAP purge solenoid located just front of the ignition coil.
3. Disconnect the vacuum hoses from the solenoid.
4. Remove the ignition coil. Refer to Ignition Coil Removal Procedure.




014RX044

5. Remove the three bolts holding the ignition coil bracket.
6. Remove the ignition coil bracket with the purge solenoid still attached to it.
7. Insert small screw driver into the catch from the bottom hole to release the catch.
8. Slide EVAP purge solenoid out form the ignition bracket.



Installation Procedure


1. Insert EVAP purge solenoid valve onto the ignition coil bracket.
2. Install the ignition coil bracket to back of intake manifold.
3. Install the ignition coil. Refer to Ignition Coil Installation Procedure.
4. Connect vacuum hoses and electrical connector at the purge valve.



Linear Exhaust Gas Recirculation (EGR) Valve

Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect electrical connector at EGR valve.
3. Disconnect the electrical connector at Intake Air Temperature Sensor.
4. Remove air intake duct. Refer to Air Intake Duct Removal Procedure.
5. Remove crankshaft breather hose.
6. Remove two bolts holding EGR valve.
7. Remove EGR valve and gasket from the manifold.



Inspection Procedure

1. Inspect the air passage for a restrtiction. If there is restriction, remove the object. Do not use any type of solvent, it may damage electrical system of EGR valve.


2. Inspect restriction for valve movement. If there is restriction remove the object.



014RX056

Installation Procedure

1. Place the gasket and EGR valve on to the intake manifold.
2. Install mounting bolts and tighten.
3. Connect electrical connector at EGR valve
4. Connect the crankshaft breather hose and secure it with clamps.
5. Install the air intake duct. Refer to Air Intake Duct Installation Procedure.
6. Connect the negative battery cable.



014RX057

Wiring and Connectors

Wiring Harness Service

The control module harness electrically connects the control module to the various solenoids, switches and sensors in the vehicle engine compartment and passenger compartment.

Replace wire harnesses with the proper part number replacement.

Because of the low amperage and voltage levels utilized in powertrain control systems, it is essential that all wiring in environmentally exposed areas be repaired with crimp and seal splice sleeves.

The following wire harness repair information is intended as a general guideline only. Refer to Chassis Electrical for all wire harness repair procedures.

PCM Connectors And Terminals

Removal Procedure

1. Remove the connector terminal retainer.
2. Push the wire connected to the affected terminal through the connector face so that the terminal is exposed.
3. Service the terminal as necessary.

Installation Procedure

1. Bend the tab on the connector to allow the terminal to be pulled into position within the connector.
2. Pull carefully on the wire to install the connector terminal retainer.

Connectors And Terminals

Connectors And Terminals

Use care when probing a connector and when replacing terminals. It is possible to short between opposite terminals. Damage to components could result. Always use jumper wires between connectors for circuit checking. NEVER probe through Weather-Pack seals. Use an appropriate connector test adapter kit which contains an assortment of flexible connectors used to probe terminals during diagnosis. Use an appropriate fuse remover and test tool for removing a fuse and to adapt the fuse holder to a meter for diagnosis.


Open circuits are often difficult to locate by sight because oxidation or terminal misalignment are hidden by the connectors. Merely wiggling a connector on a sensor, or in the wiring harness, may temporarily correct the open circuit. Intermittent problems may also be caused by oxidized or loose connections.

Be certain of the type of connector/terminal before making any connector or terminal repair. Weather-Pack and Com-Pack III terminals look similar, but are serviced differently.


Wire Harness Repair: Twisted Shielded Cable

Removal Procedure

1. Remove the outer jacket.
2. Unwrap the aluminum/mylar tape. Do not remove the mylar.




3. Untwist the conductors.
4. Strip the insulation as necessary.



Installation Procedure


1. Splice the wires using splice clips and rosin core solder.
2. Wrap each splice to insulate.

3. Wrap the splice with mylar and with the drain (uninsulated) wire.



049

4. Tape over the whole bundle to secure.




050

Twisted Leads

Removal Procedure


1. Locate the damaged wire.
2. Remove the insulation as required.



051


Installation Procedure

1. Use splice clips and rosin core solder in order to splice the two wires together.




052

2. Cover the splice with tape in order to insulate it from the other wires.




053

3. Twist the wires as they were before starting this procedure.



054

4. Tape the wires with electrical tape.



055

Weather-Pack Connector


Tools Required

J 28742-A Weather-Pack II Terminal Remover

Removal Procedure

A Weather-Pack connector can be identified by a rubber seal at the rear of the connector. This engine room connector protects against moisture and dirt, which could form oxidation and deposits on the terminals. This protection is important, because of the low voltage and the low amperage found in the electronic systems.


1. Open the secondary lock hinge on the connector.




070

2. Use tool J 28742-A or the equivalent to remove the pin and the sleeve terminals. Push on J 28742-A to release.

NOTE: Do not use an ordinary pick or the terminal may be bent or deformed. Unlike standard blade terminals, these terminals cannot be straightened after they have been improperly bent.



3. Cut the wire immediately behind the cable seal.




Installation Procedure

Make certain the connectors are properly seated and all of the sealing rings are in place when you reconnect the leads. The secondary lock hinge provides a backup locking feature for the connector. The secondary lock hinge is used for added reliability. This flap should retain the terminals even if the small terminal lock tangs are not positioned properly.

Do not replace the Weather-Pack connections with standard connections. Read the instructions provided with the Weather-Pack connector and terminal packages.

1. Replace the terminal.
2. Slip the new seal onto the wire.
3. Strip 5 mm (0.2") of insulation from the wire.
4. Crimp the terminal over the wire and the seal.




5. Push the terminal and the connector to engage the locking tangs.
6. Close the secondary locking hinge.

Com-Pack III

Com-Pack III

The Com-Pack III terminal looks similar to some Weather-Pack terminals. This terminal is not sealed and is used where resistance to the environment is not required. Use the standard method when repairing a terminal. Do not use the Weather-Pack terminal tool J 28742-A or equivalent. These will damage the terminals.



070

Metri-Pack


Tools Required

J 35689 Terminal Remover

Removal Procedure

Some connectors use terminals called Metri-Pack Series 150. These may be used at the engine coolant temperature (ECT) sensor.

1. Slide the seal (1) back on the wire.
2. Insert the J 35689 tool or equivalent (3) in order to release the terminal locking tang (2).
3. Push the wire and the terminal out through the connector. If you reuse the terminal, reshape the locking tang.




060

Installation Procedure

Metri-Pack terminals are also referred to as "pull-to-seat" terminals.

1. In order to install a terminal on a wire, the wire must be inserted through the seal (2) and through the connector (3).
2. The terminal (1) is then crimped onto the wire.
3. Then the terminal is pulled back into the connector to seat it in place.



061

GENERAL DESCRIPTION — PCM AND SENSORS

58X Reference PCM Input

The powertrain control module (PCM) uses this signal from the crankshaft position (CKP) sensor to calculate engine RPM and crankshaft position at all speeds. The PCM also uses the pulses on this circuit to initiate injector pulses. If the PCM receives no pulses on this circuit, DTC P0337 will set. If the PCM receives a number of pulses other than the expected amount, DTC P0336 will set. The engine will not start and run without using the 58X reference signal.


A/C Request Signal

This signal tells the PCM when the A/C mode is selected at the A/C control switch. The PCM uses this signal to adjust the idle speed before turning ON the A/C clutch. The A/C compressor will be inoperative if this signal is not available to the PCM.

For A/C wiring diagrams and diagnosis for the A/C electrical system, refer to A/C Clutch Circuit Diagnosis.

Crankshaft Position (CKP) Sensor

The crankshaft position (CKP) sensor provides a signal used by the powertrain control module (PCM) to calculate the ignition sequence. The CKP sensor initiates the 58X reference pulses which the PCM uses to calculate RPM and crankshaft position. For additional information, refer to Electronic Ignition System.



Camshaft Position (CMP) Sensor And Signal


The camshaft position (CMP) sensor sends a signal to the PCM. The PCM uses this signal as a "sync pulse" to trigger the injectors in the proper sequence. The PCM uses the CMP signal to indicate the position of the #1

piston during its power stroke. The CMP allows the PCM to calculate true sequential fuel injection (SFI) mode of operation. If the PCM detects an incorrect CMP signal while the engine is running, DTC P0341 will set.

If the CMP signal is lost while the engine is running, the fuel injection system will shift to a calculated sequential fuel injection mode based on the last fuel injection pulse, and the engine will continue to run. It will run in the calculated sequential mode with a 1-in-4 chance of the injector sequence being correct.

For further information, refer to

DTC P0341
DTC P0342.




014RX007

Engine Coolant Temperature (ECT) Sensor

The engine coolant temperature (ECT) sensor is a thermistor (a resistor which changes value based on temperature) mounted in the engine coolant stream. Low coolant temperature produces a high resistance of about 100,000 Ω at -40°C (-40°F). High temperature causes a low resistance of about 70 Ω at 130°C (266°F).

The PCM supplies a 5-volt signal to the ECT sensor through resistors internal to the PCM and then measures the voltage after the internal resistor. This signal voltage will be high when the engine is cold and low when the engine is hot. By measuring the voltage, the PCM calculates the engine coolant temperature. Engine coolant temperature affects most of the systems that the PCM controls.

The Tech 2 displays engine coolant temperature in degrees. After engine start-up, the temperature should rise steadily to about 85°C (185°F). It then stabilizes when the thermostat opens. If the engine has not been run for several hours (overnight), the engine coolant temperature and intake air temperature displays should be close to each other. A hard fault in the engine coolant sensor circuit will set DTC P0117 or DTC P0118. An intermittent fault will set a DTC P1114 or P1115.



0016

Electrically Erasable Programmable Read Only Memory (EEPROM)

The electrically erasable programmable read only memory (EEPROM) is a permanent memory chip that is physically soldered within the PCM. The EEPROM contains the program and the calibration information that the PCM needs to control powertrain operation.

Unlike the PROM used in past applications, the EEPROM is not replaceable. If the PCM is replaced, the new PCM will need to be programmed. Equipment containing the correct program and calibration for the vehicle is required to program the PCM.


Fuel Control Heated Oxygen Sensor (Pre Catalyst)

The fuel control heated oxygen sensor (Bank 1 HO2S 1) is mounted in the exhaust stream where it can monitor the oxygen content of the exhaust gas. The oxygen present in the exhaust gas reacts with the sensor to produce a voltage output. This voltage should constantly fluctuate from approximately 100 mV to 900 mV. The heated oxygen sensor voltage can be monitored with a Tech 2. By monitoring the voltage output of the oxygen sensor, the PCM calculates the pulse width command for the injectors to produce the proper combustion chamber mixture.

- Low HO2S voltage is a lean mixture which will result in a rich command to compensate.
- High HO2S voltage is a rich mixture which will result in a lean command to compensate.

An open Bank 1 HO2S 1 signal circuit will set a DTC P0134 and the Tech 2 will display a constant voltage between 400–500 mV. A constant voltage below 300 mV in the sensor circuit (circuit grounded) will set DTC P0131. A constant voltage above 800 mV in the circuit will set DTC P0132. A slow transition between 300mV and 800mV will cause a DTC P0133 to set. A fault in the Bank

1 HO2S 1 heater circuit will cause DTC P0135 to set. The PCM can also detect HO2S response problems. If the response time of an HO2S is determined to be too slow, the PCM will store a DTC that indicates degraded HO2S performance.



0012


Catalyst Monitor Heated Oxygen Sensor (Post Catalyst)

Three-way catalytic converters are used to control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx). The catalyst within the converters promotes a chemical reaction. This reaction oxidizes the HC and CO present in the exhaust gas and converts them into harmless water vapor and carbon dioxide. The catalyst also reduces NOx by converting it to nitrogen. The PCM can monitor this process using the Bank 1 HO2S 2 heated oxygen sensor. The Bank 1 HO2S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO2S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst. This indicates the catalyst's ability to efficiently convert exhaust gases. If the catalyst is operating efficiently, the Bank 1 HO2S 1 signal will be more active than the signal produced by the Bank 1 HO2S 2 sensor.


The catalyst monitor sensors operate the same as the fuel control sensors. The Bank 1 HO2S 2 sensor's main function is catalyst monitoring, but it also has a limited role in fuel control. If a sensor output indicates a voltage either above or below the 450 mV bias voltage for an extended period of time, the PCM will make a slight adjustment to fuel trim to ensure that fuel delivery is correct for catalyst monitoring.

A problem with the Bank 1 HO2S 2 signal circuit will set DTC P0137, P0138, P0140, OR P0141, depending on the specific condition. A fault in the heated oxygen sensor heater element or its ignition feed or ground will result in

lower oxygen sensor response. This may cause incorrect catalyst monitor diagnostic results.



TS24067



D06RX025

Legend

- (1) Bank 1 Sensor 1 (Fuel Control)
- (2) Catalytic Converter
- (3) Bank 1 Sensor 2 (Catalyst Monitor)

Intake Air Temperature (IAT) Sensor


The intake air temperature (IAT) sensor is a thermistor which changes its resistance based on the temperature of air entering the engine. Low temperature produces a high resistance of about 100,000 Ω at -40°C (-104°F). High temperature causes low resistance of about 70 Ω at 130°C (266°F). The PCM supplies a 5-volt signal to the sensor through a resistor internal to the PCM, and then monitors the signal voltage. The voltage will be high when the incoming air is cold. The voltage will be low when the incoming air is hot. By measuring the voltage, the PCM calculates the incoming air temperature. The IAT sensor signal is used to adjust spark timing according to the incoming air density.

The Tech 2 displays the temperature of the air entering the engine. The temperature should read close to the ambient air temperature when the engine is cold and rise as underhood temperature increases. If the engine has not been run for several hours (overnight), the IAT sensor temperature and engine coolant temperature should read close to each other. A failure in the IAT sensor circuit will set DTC P0112, DTC P1111, DTC P1112, or DTC P0113.

Linear Exhaust Gas Recirculation (EGR) Control

The PCM monitors the exhaust gas recirculation (EGR) actual position and adjusts the pintle position accordingly. The PCM uses information from the following sensors to control the pintle position:

- ☐ Engine coolant temperature (ECT) sensor.
- ☐ Throttle position (TP) sensor.
- ☐ Manifold Absolute Pressure (MAP) sensor.



0017


Manifold Absolute Pressure (MAP) Sensor

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure (vacuum). The MAP sensor signal voltage to the PCM varies from below 2 volts at idle (high vacuum) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (low vacuum).

The MAP sensor is used to determine the following:

- ☐ Manifold pressure changes while the linear EGR flow test diagnostic is being run. Refer to DTC P0401.
- ☐ Engine vacuum level for other diagnostics.
- ☐ Barometric pressure (BARO).

If the PCM detects a voltage that is lower than the possible range of the MAP sensor, DTC P0107 will be set. A signal voltage higher than the possible range of the sensor will set DTC P0108. An intermittent low or high voltage will set DTC P1107 or P1106, respectively. The PCM can detect a shifted MAP sensor. The PCM compares the MAP sensor signal to a calculated MAP based on throttle position and various engine load factors. If the PCM detects a MAP signal that varies excessively above or below the calculated value, DTC P0106 will set.




014RX013

Powertrain Control Module (PCM)

The powertrain control module (PCM) is located in the passenger compartment below the center console. The PCM controls the following:

- Fuel metering system.
- Ignition timing.
- On-board diagnostics for powertrain functions.

The PCM constantly observes the information from various sensors. The PCM controls the systems that affect vehicle performance. The PCM performs the diagnostic function of the system. It can recognize operational problems, alert the driver through the Check Engine lamp, and store diagnostic trouble codes (DTCs). DTCs identify the problem areas to aid the technician in making repairs.



014RX002

PCM Function

The PCM supplies either 5 or 12 volts to power various sensors or switches. The power is supplied through resistors in the PCM which are so high in value that a test light will not light when connected to the circuit. In some

cases, even an ordinary shop voltmeter will not give an accurate reading because its resistance is too low. Therefore, a digital voltmeter with at least 10 meg Ω input impedance is required to ensure accurate voltage readings. Tool J 39200 meets this requirement.

The PCM controls output circuits such as the injectors, IAC, cooling fan relays, etc., by controlling the ground or the power feed circuit through transistors or through either of the following two devices:

- Output Driver Module (ODM)
- Quad Driver Module (QDM)

PCM Components

The PCM is designed to maintain exhaust emission levels to government mandated standards while providing excellent driveability and fuel efficiency. The PCM monitors numerous engine and vehicle functions via electronic sensors such as the throttle position (TP) sensor, heated oxygen sensor (HO2S), and vehicle speed sensor (VSS). The PCM also controls certain engine operations through the following:

- Fuel injector control
- Ignition control module
- Evaporative emission (EVAP) purge
- A/C clutch control

PCM Voltage Description

The PCM supplies a buffered voltage to various switches and sensors. It can do this because resistors in the PCM which are so high in value that a test light may not illuminate when connected to the circuit. An ordinary shop voltmeter may not give an accurate reading because the voltmeter input impedance is too low. Use a 10-megohm input impedance digital voltmeter (such as J 39200) to assure accurate voltage readings.

The input/output devices in the PCM include analog-to-digital converters, signal buffers, counters, and special drivers. The PCM controls most components with electronic switches which complete a ground circuit when turned ON. These switches are arranged in groups of 4 and 7, called either a quad driver module (QDM), which can independently control up to 4 output terminals, or Output Driver Module (ODM) which can independently control up to 7 outputs. Not all outputs are always used.

PCM Inputs/Outputs

Inputs – Operating Conditions Read

- Air Conditioning Compressor Clutch ON or OFF
- Engine Coolant Temperature
- Crankshaft Position
- Exhaust Oxygen Content
- Manifold Absolute Pressure
- Battery Voltage
- Throttle Position
- Fuel Tank Vapor Pressure
- Fuel Tank Level
- Exhaust Gas Recirculation (EGR) Feedback
- Knock


- Vehicle Speed
- Fuel Pump Voltage
- Power Steering Pressure
- Intake Air Temperature
- Camshaft Position

Outputs – Systems Controlled

- EVAP Canister Purge Solenoid
- Exhaust Gas Recirculation (EGR)
- Ignition Control
- Fuel Injector Control
- Idle Air Control
- Coolant Fan Relays
- Electric Fuel Pump Relay Compressor Clutch Relay
- Air Conditioning
- Diagnostics
 - OBD II Malfunction Indicator Lamp (Check Engine lamp)
 - Data Link Connector (DLC)
 - Data Output
- Tachometer Signal

PCM Service Precautions

The PCM is designed to withstand normal current draws associated with vehicle operation. Avoid over loading any circuit. When testing for opens and shorts, do not ground or apply voltage to any of the PCM's circuits unless instructed to do so. These circuits should only be tested using digital voltmeter J 39200. The PCM should remain connected to the PCM or to a recommended breakout box.



Reprogramming the PCM

The Rodeo allows reprogramming of the PCM without removing it from the vehicle. This provides a flexible and cost-effective method of making changes in software calibrations.

Refer to the latest Isuzu Technical Communication System information for reprogramming or flashing procedures.

Tooth Error Correction (TEC) Service Bay Guidelines

Deceleration Fuel Cut-Off

This procedure is very convenient because it can be done in the service bay.

CAUTION: Appropriate safety measures should be taken to assure the safest conditions possible for all those people in the nearby vicinity of where the tooth error learn procedure is being performed.

Vehicle Preparation Requirements and Safety Issues

The vehicle needs sufficient engine oil, automatic transmission fluid, manual transmission gear box oil, power steering fluid, coolant, and brake fluid. Engine noise and exhaust should be considered by each assembly plant when deciding the location to perform the tooth error learn. Proper safety precautions should be taken. Anticipate unusual events such as a manual transmission accidentally being bumped into gear or a foot slipping off a clutch at high engine speed. The vehicle may cause other vehicles to be hit. If the transmission is in Park during the high engine speeds, the transmission Park Ratchet experiences excessive vibration and may momentarily slip. The vehicle is typically then in a Neutral type state and may roll, especially if the vehicle is on an incline. Under this condition the transmission should not slip into gear.

The following summarizes the engine preparation requirements for a tooth error learn.

Requirements:

1. At least 4 minutes of engine run time is required to have occurred at least once during the life of the vehicle to insure that all of the oil passages are flushed of debris from machining, casting, and assembly.
2. At least 5 seconds of engine run time is required during the same key cycle as the tooth error learn to fill the oil passages and provide proper lubrication. 10 seconds is the preferred guideline.
3. At least 65 degrees Celsius Coolant temperature. Engine oil temperature of 38 degrees Celsius is required for lubrication, which correlates (in most engines) to 65 degrees Celsius Coolant temperature. This is a recommendation to insure a sufficiently lubricated engine 65 degrees Celsius Coolant temperature correlates to an engine oil temperature of 38 degrees Celsius.
4. Vehicle must be in Park or Neutral. For a manual transmission vehicle, the clutch does not need to be depressed. The tooth error learn may be performed with either:
 1. Gear box in Neutral, it does not matter if the clutch is depressed or not.
 2. Gear Box in a gear and clutch depressed.

NOTE: The first option is the recommended option due to safety concerns. The second option has the risk of the

operators foot slipping off of the clutch with the vehicle being revved up and in gear.

5. A/C should always be turned OFF before performing the TEC learn procedure.
6. A Class II command from the Tech 2 is required to invoke the TEC learn procedure.
7. No Camshaft and/or Crankshaft Sensor DTC Codes present.

Tooth Error Learn Procedures

The following steps are required to learn the tooth error once the above mentioned vehicle preparation requirements are met:

1. Make sure that the tooth error learn procedure has been invoked with the Tech 2, other wise when the throttle is depressed, the RPM would go to the high RPM fuel cutoff and not be cutoff at the lower tooth error learning fuel cutoff limit.
2. Depress the brake pedal for safety reasons.
3. Depress the throttle pedal to Wide Open Throttle (WOT) and keep the throttle at 100% for the duration of the Tooth Error Correction (TEC) learning process until the TEC is learned or the number of attempts to learn has been exceeded. The RPM will be limited to the upper TEC RPM limit until one of the two above mentioned conditions are met and the throttle is released to less than 5% Throttle Position Sensor (TPS). After this, the RPM limit will be the normal redline RPM limit.
4. The tooth error learning diagnostic will learn the tooth error as the engine decelerates in fuel cutoff.
5. During the tooth error learning procedure. TEC specific information is available which will indicate that the tooth error was properly learned and completed.

Considerations For Locating The Tooth Error Learning Procedure

The area that the tooth error learn is done should be well ventilated or have vehicle exhaust elimination system which attaches to the tail pipe and draws the vehicle exhaust out of the building.


CAUTION: Appropriate safety measures should be taken to assure the safest conditions possible for all those people in the nearby vicinity of where the tooth error learn procedure is being performed. If possible, anchored or secured safety barriers should be in place in at least the front of the vehicle and in the back of the vehicle if possible to reduce the possibility of accidents. The figure below shows the proper placement of a frontal safety barrier.

The area that the tooth error learn is done should be well ventilated or have vehicle exhaust elimination system which attaches to the tail pipe and draws the vehicle exhaust out of the building.

Throttle Position (TP) Sensor

The throttle position (TP) sensor is a potentiometer connected to the throttle shaft on the throttle body. The

PCM monitors the voltage on the signal line and calculates throttle position. As the throttle valve angle is changed (accelerator pedal moved), the TP sensor signal also changes. At a closed throttle position, the output of the TP sensor is about 0.25 volts. As the throttle valve opens, the output increases so that at wide open throttle (WOT), the output voltage should be about 4.75 volts. The PCM calculates fuel delivery based on throttle valve angle (driver demand). A broken or loose TP sensor may cause intermittent bursts of fuel from an injector and unstable idle because the PCM thinks the throttle is moving. A hard failure in the TP sensor 5-volt reference or signal circuits will set either a DTC P0122 or DTC P0123. A hard failure with the TP sensor ground circuit may set DTC P0123 and DTC P0122. Once a DTC is set, the PCM will use an artificial default value based on engine RPM and mass air flow for the throttle position, and some vehicle performance will return. A high idle may result when either DTC P0122 or DTC P0123 is set. The PCM can detect intermittent TP sensor faults. DTC P1121 or DTC P1122 will set if an intermittent high or low circuit failure is being detected.



Transmission Range Switch

IMPORTANT: The vehicle should not be driven with the transmission range switch disconnected; idle quality will be affected.


The four inputs from the transmission range switch indicate to the PCM which position is selected by the transmission selector lever. This information is used for ignition timing, EVAP canister purge, EGR and IAC valve operation.

For more information on the transmission range switch, refer to 4L30-E Automatic Transmission.

Vehicle Speed Sensor (VSS)

The PCM determines the speed of the vehicle by converting a pulsing voltage signal from the vehicle speed

sensor (VSS) into miles per hour. The PCM uses this signal to operate the speedometer.



Use of Circuit Testing Tools

Do not use a test light to diagnose the powertrain electrical systems unless specifically instructed by the diagnostic procedures. Use Connector Test Adapter Kit J 35616 whenever diagnostic procedures call for probing connectors.

Aftermarket Electrical And Vacuum Equipment

Aftermarket (add-on) electrical and vacuum equipment is defined as any equipment which connects to the vehicle's electrical or vacuum systems that is installed on a vehicle after it leaves the factory. No allowances have been made in the vehicle design for this type of equipment.

NOTE: No add-on vacuum equipment should be added to this vehicle.

NOTE: Add-on electrical equipment must only be connected to the vehicle's electrical system at the battery (power and ground).


Add-on electrical equipment, even when installed to these guidelines, may still cause the powertrain system to malfunction. This may also include equipment not connected to the vehicle electrical system such as portable telephones and radios. Therefore, the first step in diagnosing any powertrain problem is to eliminate all aftermarket electrical equipment from the vehicle. After this is done, if the problem still exists, it may be diagnosed in the normal manner.

Electrostatic Discharge Damage

Electronic components used in the PCM are often designed to carry very low voltage. Electronic components are susceptible to damage caused by electrostatic discharge. Less than 100 volts of static electricity can cause damage to some electronic components. By comparison, it takes as much as 4000 volts for a person to feel even the zap of a static discharge.

There are several ways for a person to become statically charged. The most common methods of charging are by friction and induction.

- An example of charging by friction is a person sliding across a vehicle seat.
- Charge by induction occurs when a person with well-insulated shoes stands near a highly charged object and momentarily touches ground. Charges of the same polarity are drained off leaving the person highly charged with the opposite polarity. Static charges can cause damage, therefore it is important to use care when handling and testing electronic components.



NOTE: To prevent possible electrostatic discharge damage, follow these guidelines:

- Do not touch the PCM connector pins or soldered components on the PCM circuit board.
- Do not touch any electronic sensor module component leads.
- Do not open the replacement part package until the part is ready to be installed.
- Before removing the part from the package, ground the package to a known good ground on the vehicle.
- If the part has been handled while sliding across the seat, while sitting down from a standing position, or while walking a distance, touch a known good ground before installing the part.

Upshift Lamp

Refer to Up shift lamp diagnosis.


GENERAL DESCRIPTION — AIR INDUCTION

Air Induction System

The air induction system filters contaminants from the outside air, and directs the progress of the air as it is drawn into the engine. A remote-mounted air cleaner prevents dirt and debris in the air from entering the

engine. The air duct assembly routes filtered air to the throttle body. Air enters the engine by the following steps:

1. Through the throttle body.
2. Into the intake manifold.
3. Through the cylinder head intake ports.
4. Into the cylinders.



GENERAL DESCRIPTION — FUEL METERING

Acceleration Mode

The PCM provides extra fuel when it detects a rapid increase in the throttle position and the air flow.

Accelerator Controls

The accelerator control system is a cable-type system with specific linkage adjustments. Refer to Cable Adjustment.

Battery Voltage Correction Mode

When battery voltage is low, the PCM will compensate for the weak spark by increasing the following:

- ☐ The amount of fuel delivered.
- ☐ The idle RPM.

CMP Signal

The PCM uses the camshaft position (CMP) sensor signal to determine the position of the number 1 piston during its power stroke, allowing the PCM to calculate true sequential multiport fuel injection (SFI). Loss of this signal will set a DTC P0341 or DTC P0342. If the CMP signal is lost while the engine is running, the fuel injection system will shift to a calculated sequential fuel injection based on the last fuel injection pulse, and the engine will continue to run. The engine can be restarted and will run in the calculated sequential mode with the fault is present, with a 1-in-4 chance of being correct.

Clear Flood Mode

Clear a flooded engine by pushing the accelerator pedal down all the way. The PCM then de-energizes the fuel injectors. The PCM holds the fuel injectors de-energized as long as the throttle remains above 80% and the engine speed is below 800 RPM. If the throttle position becomes less than 80%, the PCM again begins to pulse the injectors ON and OFF, allowing fuel into the cylinders.

Deceleration Fuel Cutoff (DFCO) Mode

The PCM reduces the amount of fuel injected when it detects a decrease in the throttle position and the air flow. When deceleration is very fast, the PCM may cut off fuel completely for short periods.

Engine Speed/Vehicle Speed/ Fuel Disable Mode

The PCM monitors engine speed. It turns off the fuel injectors when the engine speed increases above 6000 RPM. The fuel injectors are turned back on when engine speed decreases below 5750 RPM.

Fuel Cutoff Mode


No fuel is delivered by the fuel injectors when the ignition is OFF. This prevents engine run-on. In addition, the PCM suspends fuel delivery if no reference pulses are detected (engine not running) to prevent engine flooding.

Fuel Injector

The sequential multiport fuel injection (SFI) fuel injector is a solenoid-operated device controlled by the PCM. The PCM energizes the solenoid, which opens a valve to allow fuel delivery.

The fuel is injected under pressure in a conical spray pattern at the opening of the intake valve. Excess fuel not used by the injectors passes through the fuel pressure regulator before being returned to the fuel tank.

A fuel injector which is stuck partly open will cause a loss of fuel pressure after engine shut down, causing long crank times.



Fuel Metering System Components

The fuel metering system is made up of the following parts:

- ☐ The fuel injectors.
- ☐ The throttle body.
- ☐ The fuel rail.
- ☐ The fuel pressure regulator.
- ☐ The PCM.
- ☐ The crankshaft position (CKP) sensor.
- ☐ The camshaft position (CMP) sensor.
- ☐ The idle air control (IAC) valve.
- ☐ The fuel pump.
- ☐ The fuel pump relay.
- ☐ The fuel tank vapor pressure sensor.

Basic System Operation

The fuel metering system starts with the fuel in the fuel tank. An electric fuel pump, located in the fuel tank, pumps fuel to the fuel rail through an in-line fuel filter. The pump is designed to provide fuel at a pressure above the pressure needed by the injectors. A fuel pressure regulator in the fuel rail keeps fuel available to the fuel injectors at a constant pressure. A return line delivers unused fuel back to the fuel tank. Refer to Section 6C for further information on the fuel tank, line filter, and fuel pipes.

Fuel Metering System Purpose


The basic function of the air/fuel metering system is to control the air/fuel delivery to the engine. Fuel is delivered to the engine by individual fuel injectors mounted in the intake manifold near each intake valve.

The main control sensor is the heated oxygen sensor (HO2S) located in the exhaust system. The HO2S tells the PCM how much oxygen is in the exhaust gas. The PCM changes the air/fuel ratio to the engine by controlling the amount of time that the fuel injector is ON. The best mixture to minimize exhaust emissions is 14.7 parts of air to 1 part of gasoline by weight, which allows the catalytic converter to operate most efficiently. Because of the constant measuring and adjusting of the air/fuel ratio, the fuel injection system is called a "Closed Loop" system. The PCM monitors signals from several sensors in order to determine the fuel needs of the engine. Fuel is delivered under one of several conditions called "modes." All modes are controlled by the PCM.

Fuel Pressure Regulator

The fuel pressure regulator is a diaphragm-operated relief valve mounted on the fuel rail with fuel pump pressure on one side and manifold pressure on the other side. The fuel pressure regulator maintains the fuel pressure available to the injector at three times barometric pressure adjusted for engine load. It may be serviced separately.

If the pressure is too low, poor performance and a DTC P0171, or DTC P1171 will be the result. If the pressure is too high, a DTC P0172 will be the result. For information on diagnosing fuel pressure conditions, refer to Fuel System Diagnosis.



014RX038


Fuel Pump Electrical Circuit

When the key is first turned ON, the PCM energizes the fuel pump relay for two seconds to build-up the fuel pressure quickly. If the engine is not started within two seconds, the PCM shuts the fuel pump off and waits until the engine is cranked. When the engine is cranked and the 58X crankshaft position signal has been detected by the PCM, the PCM supplies 12 volts to the fuel pump relay to energize the electric in-tank fuel pump.

An inoperative fuel pump will cause a "no-start" condition. A fuel pump which does not provide enough pressure will result in poor performance.

Fuel Rail

The fuel rail is mounted to the top of the engine and distributes fuel to the individual injectors. Fuel is delivered to the fuel inlet tube of the fuel rail by the fuel lines. The fuel goes through the fuel rail to the fuel pressure regulator. The fuel pressure regulator maintains a constant fuel pressure at the injectors. Remaining fuel is then returned to the fuel tank.




014RX036

Idle Air Control (IAC) Valve

The purpose of the idle air control (IAC) valve is to control engine idle speed, while preventing stalls due to changes in engine load. The IAC valve, mounted in the throttle body, controls bypass air around the throttle plate. By moving the conical valve (pintle) in (to decrease air flow) or out (to increase air flow), a controlled amount of air can move around the throttle plate. If the RPM is too low, the PCM will retract the IAC pintle, resulting in more air moving past the throttle plate to increase the RPM. If the RPM is too high, the PCM will extend the IAC pintle, allowing less air to move past the throttle plate, decreasing the RPM.

The IAC pintle valve moves in small steps called counts. During idle, the proper position of the IAC pintle is calculated by the PCM based on battery voltage, coolant temperature, engine load, and engine RPM. If the RPM drops below a specified value, and the throttle plate is closed, the PCM senses a near-stall condition. The PCM will then calculate a new IAC pintle valve position to prevent stalls.

If the IAC valve is disconnected and reconnected with the engine running, the idle RPM will be wrong. In this case, the IAC must be reset. The IAC resets when the key is cycled ON then OFF. When servicing the IAC, it should only be disconnected or connected with the ignition OFF. The position of the IAC pintle valve affects engine start-up and the idle characteristics of the vehicle. If the IAC pintle is fully open, too much air will be allowed into the manifold. This results in high idle speed, along with possible hard starting and a lean air/fuel ratio. DTC P0507 may set. If the IAC pintle is stuck closed, too little air will be allowed in the manifold. This results in a low idle speed, along with possible hard starting and a rich air/fuel ratio. DTC P0506 may set. If the IAC pintle is stuck part-way open, the idle may be high or low and will not respond to changes in the engine load.



0006

Run Mode

The run mode has the following two conditions:

- ☐ Open Loop
- ☐ Closed Loop

When the engine is first started, the system is in "Open Loop" operation. In "Open Loop," the PCM ignores the signal from the heated oxygen sensor (HO2S). It calculates the air/fuel ratio based on inputs from the TP, ECT, and MAP sensors.

The system remains in "Open Loop" until the following conditions are met:

- ☐ The HO2S has a varying voltage output showing that it is hot enough to operate properly (this depends on temperature).
- ☐ The ECT has reached a specified temperature.
- ☐ A specific amount of time has elapsed since starting the engine.
- ☐ Engine speed has been greater than a specified RPM since start-up.

The specific values for the above conditions vary with different engines and are stored in the programmable read only memory (PROM). When these conditions are met, the system enters "Closed Loop" operation. In "Closed Loop," the PCM calculates the air/fuel ratio (injector on-time) based on the signal from the HO2S. This allows the air/fuel ratio to stay very close to 14.7:1.

Starting Mode


When the ignition is first turned ON, the PCM energizes the fuel pump relay for two seconds to allow the fuel pump to build up pressure. The PCM then checks the engine coolant temperature (ECT) sensor and the throttle position (TP) sensor to determine the proper air/fuel ratio for starting.

The PCM controls the amount of fuel delivered in the starting mode by adjusting how long the fuel injectors are energized by pulsing the injectors for very short times.

Throttle Body Unit

The throttle body has a throttle plate to control the amount of air delivered to the engine. The TP sensor and IAC valve are also mounted on the throttle body.

Vacuum ports located behind the throttle plate provide the vacuum signals needed by various components. Engine coolant is directed through a coolant cavity in the throttle body to warm the throttle valve and to prevent icing.



014RX040


GENERAL DESCRIPTION — ELECTRONIC IGNITION SYSTEM

Camshaft Position (CMP) Sensor

The camshaft position (CMP) sensor sends a signal to the PCM. The PCM uses this signal as a "sync pulse" to trigger the injectors in the proper sequence. The PCM uses the CMP signal to indicate the position of the #1 piston during its power stroke. The CMP allows the PCM to calculate true sequential fuel injection (SFI) mode of operation. If the PCM detects an incorrect CMP signal while the engine is running, DTC P0341 will set.

If the CMP signal is lost while the engine is running, the fuel injection system will shift to a calculated sequential fuel injection mode based on the last fuel injection pulse, and the engine will continue to run. It will run in the calculated sequential mode with a 1-in-4 chance of the injector being correct.

For additional information, refer to DTC P0342.



014RX007

Crankshaft Position (CKP) Sensor


The crankshaft position (CKP) sensor provides a signal used by the powertrain control module (PCM) to calculate the ignition sequence. The sensor initiates the 58X reference pulses which the PCM uses to calculate RPM and crankshaft position. For additional information, refer to Electronic Ignition System.

Electronic Ignition

The electronic ignition system controls fuel combustion by providing a spark to ignite the compressed air/fuel mixture at the correct time. To provide optimum engine performance, fuel economy, and control of exhaust emissions, the PCM controls the spark advance of the ignition system. Electronic ignition has the following advantages over a mechanical distributor system:

- No moving parts.
- Less maintenance.
- Remote mounting capability.
- No mechanical load on the engine.


- More coil cooldown time between firing events.
- Elimination of mechanical timing adjustments.
- Increased available ignition coil saturation time.



0013

Ignition Coils

The 2.2L engine uses 2 ignition coils, 1 per 2 cylinders. A two-wire connector provides a 12-volt primary supply through the 15-amp ignition coil fuse, and the ground wire is connected to a ground-switching ignition module. Radio frequency interference produced by the coil is controlled by a condenser which is mounted near the ignition coil.



014RX044

Ignition Control


The ignition control (IC) spark timing is the PCM's method of controlling the spark advance and the ignition dwell. The IC spark advance and the ignition dwell are calculated by the PCM using the following inputs:

- Engine speed.
- Crankshaft position (58X reference).
- Camshaft position (CMP) sensor.


- Engine coolant temperature (ECT) sensor.
- Throttle position (TP) sensor.
- Vehicle speed (vehicle speed sensor).
- PCM and ignition system supply voltage.

Ignition Control Module (ICM)


The powertrain control module (PCM) controls engine ignition through a solid-state switching unit called the ignition control module (ICM). The software in the PCM uses input from several sensors to determine the timing, duration, and strength of the spark.



- The crankshaft position (CKP) sensor sends the PCM a 58X signal related to the exact position of the crankshaft.



- The camshaft position (CMP) sensor sends a signal related to the position of the camshaft.



Based on these sensor signals, as well as engine load and engine coolant temperature information, the PCM controls the switching function of the ICM by sending it a 5V signal. As long as the ICM receives the signal, it allows battery voltage to the ignition coil. That voltage allows a magnetic field to build in the coil.

When the PCM requires a spark plug to fire, it shuts off the 5V signal to the ICM grounding it internally. This triggers the ICM to switch off the battery voltage to the ignition coil, which causes the field to collapse. The lines of magnetic force pass through the secondary portion of the coil as they collapse. As they intersect the coil, they induce high voltage in the secondary ignition circuit which travels toward ground through the spark plug.

Ignition Control PCM Output

The PCM provides a zero volt (actually about 100 mV to 200 mV) or a 5-volt output signal to the ignition control (IC) module. When the ignition control (IC) module receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the coil and creates a magnetic field in the coil. When the PCM shuts off the 5-volt signal to the ignition control module, the ground path for the primary coil is broken. The magnetic field collapses and induces a high voltage secondary impulse which fires the spark plug and ignites the air/fuel mixture.

Powertrain Control Module (PCM)

The PCM is responsible for maintaining proper spark and fuel injection timing for all driving conditions. To provide optimum driveability and emissions, the PCM monitors the input signals from the following components in order to calculate spark timing:

- Engine coolant temperature (ECT) sensor.
- Intake air temperature (IAT) sensor.
- Throttle position (TP) sensor.
- Vehicle speed sensor (VSS).
- Crankshaft position (CKP) sensor.

Spark Plug

Although worn or dirty spark plugs may give satisfactory operation at idling speed, they frequently fail at higher engine speeds. Faulty spark plugs may cause poor fuel economy, power loss, loss of speed, hard starting and generally poor engine performance. Follow the scheduled maintenance service recommendations to ensure satisfactory spark plug performance. Refer to Maintenance and Lubrication.

Normal spark plug operation will result in brown to grayish-tan deposits appearing on the insulator portion of the spark plug. A small amount of red-brown, yellow, and white powdery material may also be present on the insulator tip around the center electrode. These deposits are normal combustion by-products of fuels and lubricating oils with additives. Some electrode wear will also occur.


Engines which are not running properly are often referred to as "misfiring." This means the ignition spark is not igniting the air/fuel mixture at the proper time. While other ignition and fuel system causes must also be considered, possible causes include ignition system conditions which allow the spark voltage to reach ground in some other manner than by jumping across the air gap at the tip of the spark plug, leaving the air/fuel mixture unburned. Refer to DTC P0300.

Misfiring may also occur when the tip of the spark plug becomes overheated and ignites the mixture before the spark jumps. This is referred to as "pre-ignition."


Spark plugs may also misfire due to fouling, excessive gap, or a cracked or broken insulator. If misfiring occurs before the recommended replacement interval, locate and correct the cause.

Carbon fouling of the spark plug is indicated by dry, black carbon (soot) deposits on the portion of the spark plug in the cylinder. Excessive idling and slow speeds under light engine loads can keep the spark plug temperatures so low that these deposits are not burned off. Very rich fuel mixtures or poor ignition system output may also be the cause. Refer to DTC P0172.

Oil fouling of the spark plug is indicated by wet oily deposits on the portion of the spark plug in the cylinder, usually with little electrode wear. This may be caused by oil during break-in of new or newly overhauled engines. Deposit fouling of the spark plug occurs when the normal red-brown, yellow or white deposits of combustion by-products become sufficient to cause misfiring. In some cases, these deposits may melt and form a shiny glaze on the insulator around the center electrode. If the fouling is found in only one or two cylinders, valve stem clearances or intake valve seals may be allowing excess lubricating oil to enter the cylinder, particularly if the deposits are heavier on the side of the spark plug facing the intake valve.




Excessive gap means that the air space between the center and the side electrodes at the bottom of the spark plug is too wide for consistent firing. This may be due to improper gap adjustment or to excessive wear of the electrode during use. A check of the gap size and comparison to the gap specified for the vehicle in Maintenance and Lubrication will tell if the gap is too wide. A spark plug gap that is too small may cause an unstable idle condition. Excessive gap wear can be an indication of continuous operation at high speeds or with engine loads, causing the spark to run too hot. Another possible cause is an excessively lean fuel mixture.




Low or high spark plug installation torque or improper seating can result in the spark plug running too hot and can cause excessive center electrode wear. The plug and the cylinder head seats must be in good contact for proper heat transfer and spark plug cooling. Dirty or damaged threads in the head or on the spark plug can keep it from seating even though the proper torque is applied. Once spark plugs are properly seated, tighten them to the torque shown in the Specifications Table. Low torque may result in poor contact of the seats due to a loose spark plug. Overtightening may cause the spark plug shell to be

stretched and will result in poor contact between the seats. In extreme cases, exhaust blow-by and damage beyond simple gap wear may occur.

Cracked or broken insulators may be the result of improper installation, damage during spark plug re-gapping, or heat shock to the insulator material. Upper insulators can be broken when a poorly fitting tool is used during installation or removal, when the spark plug is hit from the outside, or is dropped on a hard surface. Cracks in the upper insulator may be inside the shell and not visible. Also, the breakage may not cause problems until oil or moisture penetrates the crack later.



A broken or cracked lower insulator tip (around the center electrode) may result from damage during re-gapping or from "heat shock" (spark plug suddenly operating too hot).



- Damage during re-gapping can happen if the gapping tool is pushed against the center electrode or the insulator around it, causing the insulator to crack. When re-gapping a spark plug, make the adjustment by bending only the ground side terminal, keeping the tool clear of other parts.

- "Heat shock" breakage in the lower insulator tip generally occurs during several engine operating conditions (high speeds or heavy loading) and may be caused by over-advanced timing or low grade fuels. Heat shock refers to a rapid increase in the tip temperature that causes the insulator material to crack.

Spark plugs with less than the recommended amount of service can sometimes be cleaned and re-gapped, then returned to service. However, if there is any doubt about the serviceability of a spark plug, replace it. Spark plugs with cracked or broken insulators should always be replaced.

A/C CLUTCH DIAGNOSIS

A/C Clutch Circuit Operation

A 12-volt signal is supplied to the A/C request input of the PCM when the A/C is selected through the A/C control switch.

The A/C compressor clutch relay is controlled through the PCM. This allows the PCM to modify the idle air control position prior to the A/C clutch engagement for better idle quality. If the engine operating conditions are within their specified calibrated acceptable ranges, the PCM will enable the A/C compressor relay. This is done by providing a ground path for the A/C relay coil within the PCM. When the A/C compressor relay is enabled, battery voltage is supplied to the compressor clutch coil. The PCM will enable the A/C compressor clutch whenever the engine is running and the A/C has been requested. The PCM will not enable the A/C compressor clutch if any of the following conditions are met:

- The engine speed is greater than 6315 RPM.
- The ECT is greater than 119°C (246°F).
- The throttle is more than 80% open.

A/C Clutch Circuit Purpose

The A/C compressor operation is controlled by the powertrain control module (PCM) for the following reasons:

- It improves idle quality during compressor clutch engagement.
- It improves wide open throttle (WOT) performance.
- It provides A/C compressor protection from operation with incorrect refrigerant pressures.

The A/C electrical system consists of the following components:

1. The A/C control switch.
2. The A/C refrigerant pressure switches.
3. The A/C compressor clutch.
4. The A/C compressor clutch relay.
5. The PCM.

A/C Request Signal

This signal tells the PCM when the A/C mode is selected at the A/C control switch. The PCM uses this input to adjust the idle speed before turning on the A/C clutch. The A/C compressor will be inoperative if this signal is not available to the PCM.

For A/C wiring diagrams and diagnosis for the A/C electrical system, refer to A/C Clutch Circuit Diagnosis.

GENERAL DESCRIPTION — EVAPORATIVE EMISSION (EVAP) SYSTEM

EVAP Emission Control System Purpose

The basic evaporative emission (EVAP) control system used on all vehicles is the charcoal canister storage method. Gasoline vapors from the fuel tank flow into the canister through the inlet labeled "TANK." These vapors are absorbed into the activated carbon (charcoal) storage device (canister) in order to hold the vapors when the vehicle is not operating. The canister is purged by PCM control when the engine coolant temperature is over 60°C (140°F), the IAT reading is over 10°C (50°F), and the engine has been running. Air is drawn canister through the air inlet grid. The air mixes with the vapor and the mixture is drawn into the intake manifold.

EVAP Emission Control System Operation

The EVAP canister purge is controlled by a solenoid valve that allows the manifold vacuum to purge the canister. The Powertrain control module (PCM) supplies a ground to energize the solenoid valve (purge on). The EVAP purge solenoid control is pulse-width modulated (PWM) (turned on and off several times a second). The duty cycle (pulse width) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM. The output is commanded when the appropriate conditions have been met. These conditions are:

- The engine is fully warmed up.
- The engine has been running for a specified time.
- The IAT reading is above 10°C (50°F).
- A continuous purge condition with no purge commanded by the PCM will set a DTC P1441.

Poor idle, stalling and Poor driveability can be caused by:

- A malfunctioning purge solenoid.
- A damaged canister.
- Hoses that are split, cracked, or not connected properly.

Enhanced Evaporative Emission Control System

The basic purpose of the Enhanced Evaporative Emissions control system is the same as other EVAP systems. A charcoal-filled canister captures and stores gasoline fumes. When the PCM determines that the time is right, it opens a purge valve which allows engine vacuum to draw the fumes into the intake manifold. The difference between this and other systems is that the PCM monitors the vacuum and/or pressure in the system to determine if there is any leakage. If the PCM determines that the EVAP system is leaking or not functioning properly, it sets a Diagnostic Trouble Code (DTC) in the PCM memory.

The enhanced EVAP system is required to detect evaporative fuel system leaks as small as 0.040 in. (1.0 mm) between the fuel filler cap and purge solenoid. The system can test the evaporative system integrity by applying a vacuum signal (ported or manifold) to the fuel tank to create a small vacuum. The PCM then monitors the ability of the system to maintain the vacuum. If the vacuum remains for a specified period of time, there are no evaporative leaks and a PASS report is sent to the diagnostic executive. If there is a leak, the system either will not achieve a vacuum, or a vacuum cannot be maintained. Usually, a failure can only be detected after a cold start with a trip of sufficient length and driving conditions to run the needed tests. The enhanced EVAP system diagnostic will conduct up to eight specific sub-tests to detect fault conditions. If the diagnostic fails a sub-test, the PCM will store a Diagnostic Trouble Code (DTC) to indicate the type of fault detected.

Electrical Components

The electrical components that make up the enhanced EVAP system are:

Fuel Tank Pressure Sensor – The fuel tank pressure sensor is a three-wire strain gauge sensor similar to a common MAP sensor. However, the fuel tank pressure sensor has very different electrical characteristics due to its pressure differential design. The sensor measures the difference between the air pressure (or vacuum) in the fuel tank and the outside air pressure.

The sensor mounts at the top of the fuel pump assembly. A three-wire electrical harness connects it to the PCM. The PCM supplies a five-volt reference voltage and a ground to the sensor. The sensor will return a voltage between 0.1 and 4.9 volts. When the air pressure in the fuel tank is equal to the outside air pressure, such as when the fuel cap is removed, the output voltage of the sensor will be 1.3 to 1.7 volts.

When the air pressure in the fuel tank is 4.5 in. H₂O (1.25 kPa), the sensor output voltage will be 0.5 +/- 0.2 V. When there is neither vacuum nor pressure in the fuel tank, the sensor voltage will be 1.5 V. At -14 in. H₂O (-3.75 kPa), the sensor voltage will be 4.5 +/- 0.2 V.

EVAP Canister Purge Solenoid – Normally closed, the purge solenoid opens upon the PCM's signal to allow engine vacuum to purge gasoline fumes from the canister. Mounted on top of the upper intake manifold assembly.

EVAP Canister Vent Solenoid – Located next to the canister, the vent solenoid opens to allow air into the EVAP system. Fresh air is necessary to completely remove gasoline fumes from the canister during purge. The EVAP vent solenoid closes to seal off the evaporative emissions system for leak testing.

Fuel Level Sensor – The fuel level sensor is an important input to the PCM for the enhanced EVAP system diagnostic. The PCM needs fuel level information to know the volume of fuel in the tank. The fuel level affects the rate of change of air pressure in the EVAP system. Several of the enhanced EVAP system diagnostic sub-tests are dependent upon correct fuel level information. The diagnostic will not run when the tank is less than 15% or more than 85% full. Be sure to diagnose any Fuel Level Sensor DTCs first, as they can cause other DTCs to set.

Manifold Absolute Pressure (MAP) Sensor – The PCM compares the signals from the fuel tank pressure sensor and the MAP sensor to ensure that a relative vacuum is maintained in the EVAP system.

Non-Electrical Components

Purge/Vacuum Hoses – Made of rubber compounds, these hoses route the gasoline fumes from their sources to the canister and from the canister to the intake air flow.

EVAP Canister – Mounted on a bracket ahead of the fuel tank, the canister stores fuel vapors until the PCM determines that engine conditions are right for them to be removed and burned.

Fuel Tank – The tank has a built-in air space designed for the collection of gasoline fumes.

Vacuum Source – The vacuum source is split between two ports, one on either side of the throttle body.

Fuel Cap – The fuel cap is designed to be an integral part of the EVAP system.

System Fault Detection

The EVAP leak detection strategy is based on applying vacuum to the EVAP system and monitoring vacuum decay. The PCM monitors vacuum level via the fuel tank pressure sensor. At an appropriate time, the EVAP purge solenoid and the EVAP vent solenoid are turned ON, allowing the engine vacuum to draw a small vacuum on the entire evaporative emission system.

After the desired vacuum level has been achieved, the EVAP purge solenoid is turned OFF, sealing the system. A leak is detected by monitoring for a decrease in vacuum level over a given time period, all other variables remaining constant. A small leak in the system will cause DTC P0442 to be set.

If the desired vacuum level cannot be achieved in the test described above, a large leak or a faulty EVAP purge solenoid is indicated.

Leaks can be caused by the following conditions:

- Disconnected or faulty fuel tank pressure sensor
- Missing or faulty fuel cap
- Disconnected, damaged, pinched, or blocked EVAP purge line
- Disconnected or damaged EVAP vent hose
- Disconnected, damaged, pinched, or blocked fuel tank vapor line
- Disconnected or faulty EVAP purge solenoid
- Disconnected or faulty EVAP vent solenoid
- Open ignition feed circuit to the EVAP vent or purge solenoid
- Damaged EVAP canister

- Leaking fuel sender assembly O-ring

- Leaking fuel tank or fuel filler neck

A restricted or blocked EVAP vent path is detected by drawing vacuum into the EVAP system, turning OFF the EVAP vent solenoid and the EVAP purge solenoid (EVAP vent solenoid OPEN, EVAP purge Pulse Width Modulate (PWM) "0%") and monitoring the fuel tank vacuum sensor input. With the EVAP vent solenoid open, any vacuum in the system should decrease quickly unless the vent path is blocked. A blockage like this will set DTC P0446 and can be caused by the following conditions:

- Faulty EVAP vent solenoid (stuck closed)
- Plugged, kinked or pinched vent hose
- Shorted EVAP vent solenoid driver circuit
- Plugged EVAP canister

The PCM supplies a ground to energize the purge solenoid (purge ON). The EVAP purge control is PWM, or turned ON and OFF, several times a second. The duty cycle (pulse width) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM and the output is commanded when the appropriate conditions have been met.

The system checks for conditions that cause the EVAP system to purge continuously by commanding the EVAP vent solenoid ON and the EVAP purge solenoid OFF (EVAP vent solenoid CLOSED, EVAP purge PWM "0%"). If fuel tank vacuum level increases during the test, a continuous purge flow condition is indicated, which will set a DTC P1441. This can be caused by the following conditions:

- EVAP purge solenoid leaking
- EVAP purge and engine vacuum lines switched at the EVAP purge solenoid
- EVAP purge solenoid driver circuit grounded

GENERAL DESCRIPTION — EXHAUST GAS RECIRCULATION (EGR) SYSTEM

EGR Purpose

The exhaust gas recirculation (EGR) system is used to reduce emission levels of oxides of nitrogen (NOx). NOx emission levels are caused by a high combustion temperature. The EGR system lowers the NOx emission levels by decreasing the combustion temperature.

Linear EGR Valve

The main element of the system is the linear EGR valve. The EGR valve feeds small amounts of exhaust gas back into the combustion chamber. The fuel/air mixture will be diluted and combustion temperatures reduced.

Linear EGR Control

The PCM monitors the EGR actual position and adjusts the pintle position accordingly. The PCM uses information from the following sensors to control the pintle position:

- Engine coolant temperature (ECT) sensor.
- Throttle position (TP) sensor.

Linear EGR Valve Operation And Results Of Incorrect Operation

The linear EGR valve is designed to accurately supply EGR to the engine independent of intake manifold vacuum. The valve controls EGR flow from the exhaust to the intake manifold through an orifice with a PCM-controlled pintle. During operation, the PCM controls pintle position by monitoring the pintle position feedback signal. The feedback signal can be monitored with a Tech 2 as "Actual EGR Pos." "Actual EGR Pos." should always be near the commanded EGR position ("Desired EGR Pos."). The PCM also tests for EGR flow. If incorrect flow is detected, DTC P0401 will set. If DTC P0401 is set, refer to the DTC charts.

The linear EGR valve is usually activated under the following conditions:


- ☐ Warm engine operation.
- ☐ Above-idle speed.

Too much EGR flow at idle, cruise or cold operation may cause any of the following conditions to occur:

- ☐ Engine stalls after a cold start.
- ☐ Engine stalls at idle after deceleration.
- ☐ Vehicle surges during cruise.
- ☐ Rough idle.
- ☐ DTC P0300 (misfire detected).

Too little or no EGR flow may allow combustion temperatures to get too high. This could cause:

- ☐ Spark knock (detonation).
- ☐ Engine overheating.
- ☐ Emission test failure.
- ☐ DTC P0401 (EGR Flow Insufficient detected).
- ☐ Poor fuel economy.



EGR Pintle Position Sensor

The PCM monitors the EGR valve pintle position input to ensure that the valve responds properly to commands from the PCM and to detect a fault if the pintle position sensor and control circuits are open or shorted. If the PCM detects a pintle position signal voltage outside the normal range of the pintle position sensor, or a signal


voltage that is not within a tolerance considered acceptable for proper EGR system operation, the PCM will set DTC P0404.

GENERAL DESCRIPTION — POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM

Crankcase Ventilation System Purpose

The crankcase ventilation system is used to consume crankcase vapors in the combustion process instead of venting them to the atmosphere. Fresh air from the throttle body is supplied to the crankcase and mixed with blow-by gases. This mixture is then passed through the positive crankcase ventilation (PCV) port into the intake manifold.

While the engine is running, exhaust gases and small amounts of the fuel/air mixture escape past the piston rings and enter the crankcase. These gases are mixed with clean air entering through a tube from the air intake duct.



During normal, part-throttle operation, the system is designed to allow crankcase gases to flow through the PCV valve into the throttle body to be consumed by normal combustion.

A plugged valve or PCV hose may cause the following conditions:

- ☐ Rough idle.
- ☐ Stalling or slow idle speed.
- ☐ Oil leaks.
- ☐ Sludge in the engine.

A leaking PCV hose would cause:

- ☐ Rough idle.
- ☐ Stalling.
- ☐ High idle speed.

SPECIAL TOOLS


















ILLUSTRATION	TOOL NO. TOOL NAME	ILLUSTRATION	TOOL NO. TOOL NAME
	J 39200 High Impedance Multimeter (Digital Voltmeter – DVM)		J 26792/BT-7220-1 Spark Tester
	(1) PCMCIA Card (2) RS232 Loop Back Connector (3) SAE 16/19 Adapter (4) DLC Cable (5) TECH-2		J 39021-Box Port Fuel Injection Diagnostic Kit
	J 37027-A IAC Motor Analyzer		J 23738-A Vacuum Pump with Gauge
	J 34142-B Unpowered Test Light		BT-8515-V Exhaust Back Pressure Tester
	J 39021-5V Port Fuel Injector Tester		J 39194-B Heated Oxygen Sensor Wrench
	J 35616-A/BT-8637 Connector Test Adapter Kit		J 35689-A Terminal Remover

ILLUSTRATION	TOOL NO. TOOL NAME
	J 28742-A Weather Pack II Terminal Remover
	J 39021-90 Injector Switch Box
	J 39021-45 Injector Test Light
	J 41413¹ EVAP Pressure/Purge Diagnostic Station
	J 41416² Ultrasonic Leak Detector

1. J 41413 EVAP Pressure/Purge Diagnostic Station is a multipurpose tool which is used to perform several diagnostic procedures for enhanced emission testing. The station will accommodate a nitrogen gas filled cylinder which is used to pressurize the vehicle EVAP system for a leakdown test and leak location test when a vehicle is repaired for leakage in the enhanced evaporative emission control system. It also has two additional gauges (inches of mercury and inches of water) which are used to measure both source vacuum and EVAP canister purge vacuum to verify correct operation and vapor flow within the canister purge circuit.
2. J 41416 Ultrasonic Leak Detector is a microprocessor-based device used to detect leaks in the enhanced evaporative emission control system. The evaporative system is pressurized to 30 inches of water using the J 41413 EVAP Pressure/Purge Diagnostic System. Small leaks in the EVAP system will emit sound at a high frequency undetectable by a human ear but detectable with the J 41416. The technician traces along the evaporative system and can pinpoint leaks due to corroded lines, cracked hoses, or a damaged EVAP component. The detector includes a high quality set of headphones to block out surrounding shop noise and the LED sensitivity meter allows a visual reference for locating leaks in conjunction with the audio output heard through the headphones. Powered by (1) nine volt battery.

RODEO

ENGINE

ENGINE EXHAUST (X22SE 2.2L)

CONTENTS


Service Precaution	6F-1	Removal	6F-4
General Description	6F-2	Installation	6F-4
Front Exhaust Pipe	6F-3	Rear Exhaust pipe	6F-5
Front Exhaust Pipe and Associated Parts .	6F-3	Rear Exhaust pipe and Associated Parts .	6F-5
Removal	6F-3	Removal	6F-5
Installation	6F-3	Installation	6F-5
Exhaust Silencer	6F-4	Main Data and Specifications	6F-6
Exhaust Silencer and Associated Parts ...	6F-4		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



150RX004

When inspecting or replacing exhaust system components, make sure there is adequate clearance from all points on the underbody to prevent overheating the floor pan and possible damage to the passenger compartment insulation and trim materials.

Check complete exhaust system and nearby body areas and rear compartment lid for broken, damaged, missing or mispositioned parts, open seams, holes, loose connections or other deterioration which could permit exhaust fumes to seep into the rear compartment or passenger compartment. Dust or water in the rear compartment may be an indication of a problem in one of these areas. Any faulty areas should be corrected immediately.

Hangers

Various types of hangers are used to support exhaust system(s). These include conventional rubber straps, rubber rings, and rubber blocks.

The installation of exhaust system supports is very important, as improperly installed supports can cause annoying vibrations which can be difficult to diagnose.

Three Way Catalytic Converter

The three way catalytic converter is an emission control device added to the exhaust system to reduce pollutants from the exhaust gas stream.

CAUTION: The catalytic converter requires the use of unleaded fuel only.

Periodic maintenance of the exhaust system is not required. If the vehicle is raised for other service, it is advisable to check the condition of the complete exhaust system.

A dual bed monolith catalytic converter is used in combination with three way catalytic converter.

Catalytic Types:

Three way (Reduction/Oxidation) catalyst


The catalyst coating on the three way (reduction) converter contains platinum and rhodium which lowers the levels of nitrous oxide (NOx) as well as hydrocarbons (HC) and carbon monoxide (Co).

Gasket

The gasket must be replaced whenever a new exhaust pipe, muffler or catalytic converter is installed.

Front Exhaust Pipe

Front Exhaust Pipe and Associated Parts



150RX001

Legend

- | | |
|---|--|
| (1) Front Exhaust Pipe Fixing Nuts | (4) Front Exhaust Pipe Mounting Rubber |
| (2) O2 Sensor | (5) O2 Sensor |
| (3) Front Exhaust Pipe with Three Way Catalytic Converter | (6) Front Exhaust Pipe Fixing Bolt |
| | (7) Front Exhaust Pipe Fixing Bolt (Clamp) |
| | (8) Front Exhaust Pipe Mounting Bracket |

Removal

1. Disconnect battery ground cable.
2. Raise the vehicle and support with suitable safety stands.
3. Disconnect O2 sensor harness connector and remove front side O2 sensor (2),(5).
4. Remove front exhaust pipe fixing bolts (6),(7).
5. Remove front exhaust pipe fixing four stud nuts from exhaust manifold (1).
6. Remove front exhaust pipe (3).

Installation

1. Install front exhaust pipe (3) and tighten four stud nuts (1) and two bolts (6) to the specified torque:

Torque:

Stud Nuts : 28 N·m (21 lb ft)

Bolts (6) : 43 N·m (32 lb ft)


Bolts (7) : 23 N·m (17 lb ft)

2. Tighten front side O2 sensor and reconnect O2 sensor harness connector.

Torque : 55 N·m (41 lb ft)

Exhaust Silencer

Exhaust Silencer and Associated Parts



150RW032

Legend

- | | |
|------------------------------------|----------------------------------|
| (1) Exhaust Silencer | (5) Mounting Rubber |
| (2) Front Exhaust Pipe Fixing Bolt | (6) Mounting Rubber |
| (3) Exhaust Silencer Fixing Nuts | (7) Mounting Rubber |
| (4) Exhaust Rear Pipe | (8) Exhaust Silencer Fixing Nuts |

Removal


1. Disconnect battery ground cable.
2. Raise the vehicle and support with suitable safety stands.
3. Remove exhaust silencer fixing nuts (3) then disconnect rear exhaust pipe from exhaust silencer.
4. Remove exhaust silencer fixing nuts (2) then disconnect exhaust silencer from front exhaust pipe (5).
5. Remove exhaust silencer mounting nuts (8) from chassis side then remove exhaust silencer (1).

Installation

1. Install the exhaust silencer (1) chassis side and tighten two nuts (8) to the specified torque.
Nuts: 15 N·m (11 lb ft)
2. Install the exhaust silencer and tighten two Bolts (2) on front exhaust pipe to specified torque.
Bolts: 43 N·m (32 lb ft)
3. Install the rear exhaust pipe and tighten two nuts (3) on exhaust silencer to specified torque.
Nuts: 43 N·m (32 lb ft)

Rear Exhaust pipe

Rear Exhaust pipe and Associated Parts



150RW032

Legend

- | | |
|------------------------------------|----------------------------------|
| (1) Exhaust Silencer | (5) Mounting Rubber |
| (2) Front Exhaust Pipe Fixing Bolt | (6) Mounting Rubber |
| (3) Exhaust Silencer Fixing Nuts | (7) Mounting Rubber |
| (4) Exhaust Rear Pipe | (8) Exhaust Silencer Fixing Nuts |

Removal

1. Disconnect battery ground cable.
2. Raise the vehicle and support with suitable safety stands.
3. Remove rear exhaust pipe fixing nuts (3), then disconnect rear exhaust pipe from exhaust silencer.
4. Remove mounting rubber (5), (6).
5. Remove rear exhaust pipe (4).


Installation

1. Install the mounting rubber (5), (6).
2. Install the exhaust pipe (4) and tighten two nuts (3) on exhaust silencer to specified torque.

Nuts: 43 N·m (32 lb ft)

Main Data and Specifications

Torque Specifications



150RX002

RODEO

ENGINE

ENGINE LUBRICATION (X22SE 2.2L)

CONTENTS

Service Precaution	6G-1
General Description	6G-2
Oil Pump	6G-3
Oil Pump and Associated Parts	6G-3
Disassembly	6G-4
Inspection and Repair	6G-4
Reassembly	6G-4

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.


CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

A gear-type oil pump is directly driven by the crankshaft and draws oil from the oil pan, via the suction pipe. It then passes the pressured oil through a full-flow disposable oil filter, to the main oil gallery in the cylinder block. An oil pump pressure relief valve and oil filter bypass valve are incorporated in the system.

From the main oil gallery in the cylinder block, the cylinder head and crankshaft main bearings are supplied with oil.

The camshaft bearings and hydraulic tappets are supplied through the main feed galleries in the cylinder head. Vent valves allow air to be expelled from the oil galleries in the cylinder head. The balance shaft journals are directly fed from the crankshaft main bearings. The connecting rod bearings are fed via passages in the crankshaft. The oil returns to the oil pan via passages in the cylinder block.




C06RW004

Legend

- | | |
|------------------------|---------------------------------|
| (1) Oil Strainer | (9) Connecting Rod Bearing |
| (2) Oil Pump | (10) Connecting Rod |
| (3) Relief Valve | (11) Piston |
| (4) Oil Filter | (12) Oil Gallery; Cylinder Head |
| (5) Safety Valve | (13) Camshaft |
| (6) Oil Gallery | (14) Camshaft Journal |
| (7) Crankshaft Bearing | (15) HLV |
| (8) Crankshaft | (16) Vent Valve |
| | (17) Oil Pan |

Oil Pump

Oil Pump and Associated Parts

**Legend**

- (1) Oil Pump Assembly
- (2) Oil Pressure Switch

- (3) Gasket
- (4) Sleeve

Disassembly

1. Remove crankshaft timing pulley.
2. Remove oil pan.
3. Remove oil pan support.
4. Remove oil strainer.
5. Remove oil pump assembly.
6. Remove oil pressure switch.
7. Remove gasket.
8. Remove sleeve.


Inspection and Repair

CAUTION: Make necessary correction or parts replacement if wear, damage or any other abnormal conditions are found through inspection.

Body and Gears

The pump assembly must be replaced if one or more of the conditions below is discovered during inspection:
Indentation of gear pair — use feeler strip and straight edge.


**Dimension : 0.03 mm to 0.10 mm
(0.0012 to 0.0039 in)**



051RW014

Oil Strainer

Check the oil strainer for cracking and scoring. If cracking and scoring are found, the oil strainer must be replaced.



051RW013

Reassembly

1. Install oil pressure switch to the oil pump.
Torque : 40 N·m (37 lb ft)
2. Install the oil pump with the sleeve and the gasket.
Torque : 6 N·m (4.4 lb ft)
3. Install oil strainer.
Torque : 8 N·m (5.8 lb ft)
4. Install Oil pan support.
Torque : 20 N·m (14 lb ft)
5. Install the oil pan.
Tighten the bolts in 2 steps:
1st step: 8 N·m (5.8 lb ft)
2nd step: 30°
6. Install crankshaft timing pulley.
Tighten the bolts in 2 steps:
1st step: 130 N·m (94 lb ft)
2nd step: 45°

RODEO

ENGINE

ENGINE SPEED CONTROL SYSTEM (X22SE 2.2L)

CONTENTS


Service Precaution	6H-1	Accelerator Pedal	6H-3
Accelerator Pedal Control Cable	6H-2	Accelerator Pedal and Associated Parts ..	6H-3
Removal	6H-2	Removal	6H-3
Inspection	6H-2	Installation	6H-3
Installation	6H-2		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Accelerator Pedal Control Cable



035RX004

Removal

1. Loosen the nut(5) on the cable bracket mounted.
2. Remove cable clip(3).
3. Disconnect accelerator pedal (AP) control cable(6). (on throttle valve side)
4. Disconnect AP control cable(1). (on AP pedal(7) side)
5. Remove grommet(2).
6. Remove AP control cable(4).

Installation

1. Install AP control cable(4).
2. Install grommet(2).
3. Connect AP control cable(1). (on AP pedal(7) side)
4. Connect AP control cable(6). (on throttle valve side)
5. Install cable clip(3).
6. Install nut(5).


Inspection

Check the following items, and replace the control cable if any abnormality is found:

- ☐ The control cable should move smoothly.
- ☐ The control cable should not be bent or kinked.
- ☐ The control cable should be free of damage and corrosion.

Accelerator Pedal

Accelerator Pedal and Associated Parts



Legend

- (1) Accelerator Pedal Control Cable
- (2) Accelerator Pedal Assembly

Removal

1. Accelerator pedal control cable(1).
2. Accelerator pedal assembly(2).

Installation

1. Accelerator pedal assembly (2).
2. Accelerator pedal control cable (1).

RODEO

ENGINE

INDUCTION (X22SE 2.2L)

CONTENTS

Service Precaution	6H-1
Air Cleaner Filter	6H-2
Removal	6H-2
Inspection	6H-2
Installation	6H-2

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Air Cleaner Filter

Removal


1. Remove positive ventilation hose connector.
2. Remove intake air temperature sensor.
3. Remove mass air flow sensor.
4. Remove air cleaner duct assembly.
5. Remove air cleaner element.

Inspection

Check the air cleaner filter for damage or dust clogging. Replace if it is damaged, or clean if it is clogged.

Cleaning Method

Tap the air cleaner filter gently so as not to damage the paper filter, or clean the element by blowing with compressed air of about 490 kPa (71 psi) from the clean side if it is extremely dirty.



130RW002

Installation

1. Install air cleaner element.
2. Attach the air cleaner duct cover to the body completely, then clamp it with the clip.
3. Install mass air flow sensor.
4. Install mass air temperature sensor.
5. Install positive crankcase ventilation hose connector.

RODEO

ENGINE

CONTENTS

Engine Mechanical	6A-1	Driveability and Emissions	6E1-1
Engine Cooling	6B-1	Engine Exhaust	6F-1
Engine Fuel	6C-1	Engine Lubrication	6G-1
Engine Electrical	6D1-1	Engine Speed Control System	6H-1
Ignition System	6D2-1	Induction	6J-1
Starting and Charging System	6D3-1		

ENGINE MECHANICAL (6VD1 3.2L)

CONTENTS

Service Precaution	6A-2	Removal	6A-39
General Description	6A-3	Installation	6A-40
Engine Diagnosis	6A-4	Crankshaft and Main Bearings	6A-41
Cylinder Head Cover LH	6A-19	Removal	6A-41
Removal	6A-19	Installation	6A-42
Installation	6A-20	Rear Oil Seal	6A-46
Cylinder Head Cover RH	6A-21	Removal	6A-46
Removal	6A-21	Installation	6A-46
Installation	6A-21	Engine Assembly	6A-47
Common Chamber	6A-22	Removal	6A-47
Removal	6A-22	Installation	6A-47
Installation	6A-22	Cylinder Head	6A-51
Exhaust Manifold LH	6A-24	Cylinder Head and Associated Parts	6A-51
Removal	6A-24	Disassembly	6A-51
Installation	6A-24	Clean	6A-52
Exhaust Manifold RH	6A-25	Inspection and Repair	6A-52
Removal	6A-25	Reassembly	6A-53
Installation	6A-25	Valve Spring, Oil Controller, Valve, Valve Guide	6A-55
Crankshaft Pulley	6A-26	Valve Spring, Oil Controller, Valve, Valve Guide and Associated Parts	6A-55
Removal	6A-26	Disassembly	6A-55
Installation	6A-26	Inspection and Repair	6A-56
Timing Belt	6A-27	Reassembly	6A-59
Removal	6A-27	Camshaft	6A-62
Installation	6A-28	Camshaft and Associated Parts	6A-62
Camshaft	6A-32	Disassembly	6A-62
Removal	6A-32	Inspection and Repair	6A-63
Installation	6A-33	Reassembly	6A-65
Cylinder Head	6A-36	Crankshaft	6A-68
Removal	6A-36	Crankshaft and Associated Parts	6A-68
Installation	6A-36	Disassembly	6A-68
Valve Stem Oil Controller , Valve Spring and Valve Guide	6A-38	Inspection and Repair	6A-69
Removal	6A-38	Inspection and Repair	6A-71
Installation	6A-38	Reassembly	6A-72
Piston, Piston Ring and Connecting Rod ...	6A-39		

6A-2 ENGINE MECHANICAL (6VD1 3.2L)

Piston and Connecting Rod	6A-76	Cylinder Block and Associated Parts	6A-83
Piston, Connecting Rod and Associate Parts	6A-76	Disassembly	6A-83
Disassembly	6A-76	Inspection and Repair	6A-84
Inspection and Repair	6A-77	Reassembly	6A-85
Reassembly	6A-81	Main Data and Specification	6A-88
Cylinder Block	6A-83	Special Tool	6A-94

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

Engine Cleanliness And Care

An automobile engine is a combination of many machined, honed, polished and lapped surfaces with tolerances that are measured in the thousandths of a millimeter (ten thousandths of an inch). Accordingly, when any internal engine parts are serviced, care and cleanliness are important. Throughout this section, it should be understood that proper cleaning and protection of machined surfaces and friction areas is part of the repair procedure. This is considered standard shop practice even if not specifically stated.

- A liberal coating of engine oil should be applied to all friction areas during assembly to protect and lubricate the surfaces on initial operation.
- Whenever valve train components, pistons, piston rings, connecting rods, rod bearings, and crankshaft journal bearings are removed for service, they should be retained in order.
- At the time of installation, they should be installed in the same locations and with the same mating surfaces as when removed.
- Battery cables should be disconnected before any major work is performed on the engine. Failure to disconnect cables may result in damage to wire harness or other electrical parts.
- The six cylinders of this engine are identified by numbers; Right side cylinders 1, 3 and 5, Left side cylinders 2, 4 and 6, as counted from crankshaft pulley side to flywheel side.

General Information on Engine Service

The following information on engine service should be noted carefully, as it is important in preventing damage and contributing to reliable engine performance.

- When raising or supporting the engine for any reason, do not use a jack under the oil pan. Due to the small clearance between the oil pan and the oil pump strainer, jacking against the oil pan may cause damage to the oil pick-up unit.
- The 12-volt electrical system is capable of damaging circuits. When performing any work where electrical terminals could possibly be grounded, the ground cable of the battery should be disconnected at the battery.
- Any time the intake air duct or air cleaner is removed, the intake opening should be covered. This will protect against accidental entrance of foreign material into the cylinder which could cause extensive damage when the engine is started.

Cylinder Block

The cylinder block is made of aluminum die-cast casting for 75°V-type six cylinders. It has a rear plate integrated structure and employs a deep skirt. The cylinder liner is cast and the liner inner diameter and crankshaft journal diameter are classified into grades. The crankshaft is supported by four bearings of which width is different between No.2, No.3 and No.1, No.4; the width of No.3 bearing on the body side is different in order to support the thrust bearing. The bearing cap is made of nodular cast iron and each bearing cap uses four bolts and two side bolts.

Cylinder Head

The cylinder head, made of aluminum alloy casting employs a pent-roof type combustion chamber with a spark plug in the center. The intake and exhaust valves are placed in V-type design. The ports are cross-flow type.

Valve Train

Intake and exhaust camshaft on the both side of banks are driven through an camshaft drive gear by timing belt. The valves are operated by the camshaft and the valve clearance is adjusted to select suitable thickness shim.

Intake Manifold

The intake manifold system is composed of the aluminum cast common chamber and intake manifold attached with six fuel injectors.

Exhaust Manifold

The exhaust manifold is made of nodular cast iron.

Pistons and Connecting Rods

Aluminum pistons are used after selecting the grade that meets the cylinder bore diameter. Each piston has two compression rings and one oil ring. The piston pin made of chromium steel is offset 1mm toward the thrust side, and the thrust pressure of piston to the cylinder wall varies gradually as the piston travels. The connecting rods are made of forged steel. The connecting rod bearings are graded for correct size selection.

Crankshaft and Bearings

The crankshaft is made of Ductile cast-iron. Pins and journals are graded for correct size selection for their bearing.

Engine Diagnosis

Hard Starting

1. Starting Motor Does Not Turn Over

Troubleshooting Procedure

Turn on headlights and starter switch.

Condition	Possible cause	Correction
Headlights go out or dim considerably	Battery run down or under charged	Recharge or replace battery
	Terminals poorly connected	Clean battery posts and terminals and connect properly
	Starting motor coil circuit shorted	Overhaul or replace
	Starting motor defective	Overhaul or replace

2. Ignition Trouble — Starting Motor Turns Over But Engine Does Not Start

Spark Test

Disconnect an ignition coil from any spark plug. Connect the spark plug tester J-26792 (ST-125), start the engine, and check if a spark is generated in the spark plug tester.

Before starting the engine, make sure that the spark plug tester is properly grounded. To avoid electrical shock, do not touch the part where insulation of the ignition coil is broken while the engine is running.

Condition	Possible cause	Correction
Spark jumps across gap	Spark plug defective	Clean, adjust spark gap or replace
	Ignition timing incorrect	Refer to Ignition System
	Fuel not reaching fuel injector(s) or engine	Refer to item 3 (Trouble in fuel system)
	Valve timing incorrect	Adjust
	Engine lacks compression	Refer to item 4 (Engine lacks compression)
No sparking takes place	Ignition coil disconnected or broken	Connect properly or replace
	Electronic Ignition System with module	Replace
	Poor connections in engine harness	Correct
	Powertrain Control Module cable disconnected or defective	Correct or replace

3. Trouble In Fuel System

Condition	Possible cause	Correction
Starting motor turns over and spark occurs but engine does not start.	Fuel tank empty	Fill
	Water in fuel system	Clean
	Fuel filter clogged	Replace filter
	Fuel pipe clogged	Clean or replace
	Fuel pump defective	Replace
	Fuel pump circuit open	Correct or replace
	Evaporative Emission Control System circuit clogged	Correct or replace
	Multiport Fuel Injection System faulty	Refer to "Electronic Fuel Injection" section

4. Engine Lacks Compression

Condition	Possible cause	Correction
Engine lacks compression	Spark plug loosely fitted or spark plug gasket defective	Tighten to specified torque or replace gasket
	Valve timing incorrect	Adjust
	Cylinder head gasket defective	Replace gasket
	Valve incorrectly seated	Lap valve
	Valve stem seized	Replace valve and valve guide
	Valve spring weakened or broken	Replace
	Cylinder or piston rings worn	Overhaul engine
	Piston ring seized	Overhaul engine.

Engine Compression Test Procedure

1. Start and run the engine until the engine reaches normal operating temperature.
 2. Turn the engine off.
 3. Remove all the spark plugs.
 4. Remove ignition coil fuse (15A) and disable the ignition system.
 5. Remove the fuel pump relay from the relay and fuse box.
 6. Engage the starter and check that the cranking speed is approximately 300 rpm.
 7. Install cylinder compression gauge into spark plug hole.
 8. With the throttle valve opened fully, keep the starter engaged until the compression gage needle reaches the maximum level. Note the reading.
 9. Repeat the test with each cylinder.
- If the compression pressure obtained falls below the limit, engine overhaul is necessary.

Limit; 1000 kPa (145 psi)

Rough Engine Idling or Engine Stalling

Condition	Possible cause	Correction
Trouble in fuel injection system	Idle air control valve defective	Replace
	Throttle shutting off incomplete	Correct or replace
	Throttle position sensor circuit open or shorted	Correct or replace
	Fuel injector circuits open or shorted	Correct or replace
	Fuel injectors damaged	Replace
	Fuel pump relay defective	Replace
	Mass Airflow Sensor circuit open or poor connections	Correct or replace
	Mass Airflow Sensor defective	Replace
	Manifold Absolute Pressure Sensor circuit open or poor connections	Correct or replace
	Manifold Absolute Pressure Sensor defective	Replace
	Engine Coolant Temperature Sensor circuit open or poor connections	Correct or replace
	Engine Coolant Temperature Sensor defective	Replace
	Intake Air Temperature sensor circuit open or poor connections	Correct or replace
	Intake Air Temperature sensor defective	Replace
	Knock Sensor (KS) cable broken or poor connections	Correct or replace
	KS defective	Replace
	KS Module circuits open or ground	Correct or replace
	KS Module defective	Replace
	Vehicle Speed Sensor circuit open or shorted	Correct or replace
	Vehicle Speed Sensor defective	Replace
Trouble in emission control system	Powertrain Control Module defective	Replace
	Exhaust Gas Recirculation Valve circuit open or poor connections	Correct or replace
	Exhaust Gas Recirculation Valve faulty	Replace
	Canister purge valve circuit open or poor connections	Correct or replace
	Canister purge valve defective	Replace
	Evaporative Emission Canister Purge control valve defective	Replace
	Trouble in ignition system	Refer to "Hard Start"

Condition	Possible cause	Correction
Others	Engine lacks compression	Refer to "Hard Start"
	Valve incorrectly seated	Lap valve
	Air Cleaner Filter clogged	Replace filter element
	Valve timing incorrect	Readjust
	Idle air control valve broken	Replace
	Fast idle solenoid defective	Replace
	Positive Crankcase Ventilation valve defective or clogged	Replace

Rough Engine Running

Condition	Possible cause	Correction
Engine misfires periodically	Ignition coil layer shorted	Replace
	Spark plugs fouling	Clean or install hotter type plug
	Spark plug(s) insulator nose leaking	Replace
	Fuel injector(s) defective	Replace
	Powertrain control module faulty	Replace
Engine knocks periodically	Spark plugs running too hot	Install colder type spark plugs
	Powertrain control module faulty	Replace
Engine lacks power	Spark plugs fouled	Clean
	Fuel injectors defective	Replace
	Mass Airflow Sensor or Intake Airflow Sensor circuit defective	Correct or replace
	Manifold Absolute Pressure (MAP) Sensor or Manifold Absolute Pressure Sensor circuit defective	Correct or replace
	Engine Coolant Temperature Sensor or Engine Coolant Temperature Sensor circuit defective	Correct or replace
	Powertrain Control Module faulty	Replace
	Intake Air Temperature Sensor or Intake Air Temperature Sensor circuit defective	Correct or replace
	Throttle Position Sensor or Throttle Position Sensor circuit defective	Correct or replace
	Knock Sensor or Knock Sensor circuits defective	Correct or replace
	Knock Sensor Module or Knock Sensor Module circuits defective	Correct or replace

Hesitation

Condition	Possible cause	Correction
Hesitation on acceleration	Throttle Position Sensor adjustment incorrect	Replace throttle valve assembly
	Throttle Position Sensor circuit open or shorted	Correct or replace
	Excessive play in accelerator linkage	Adjust or replace
	Mass Airflow Sensor circuit open or poor connections	Correct or replace
	Mass Airflow Sensor defective	Replace
	Manifold Absolute Pressure (MAP) Sensor circuit open or shorted	Correct or replace
	MAP Sensor defective	Replace
	Intake Air Temperature (IAT) Sensor circuit open or poor connections	Correct or replace
	Knock Sensor (KS) circuit open or poor connections	Correct or replace
	KS defective	Replace
	KS Module circuits open or shorted	Correct or replace
	KS Module defective	Replace
	IAT Sensor defective	Replace
Hesitation at high speeds (Fuel pressure too low)	Fuel tank strainer clogged	Clean or replace
	Fuel pipe clogged	Clean or replace
	Fuel filter clogged	Replace
	Defective fuel pump system	Check and replace
	Fuel Pressure Control Valve leaking	Replace
Hesitation at high speeds (Fuel injector not working normally)	Power supply or ground circuit for Multiport Fuel Injection System shorted or open	Check and correct or replace
	Fuel Injector defective	Replace
	Cable of Multiport Fuel Injection System circuit open or poor connections	Correct or replace

Condition	Possible cause	Correction
Hesitation at high speeds	Powertrain Control Module defective	Replace
	Throttle Position Sensor cable broken or poor connections	Correct or replace
	Throttle Position Sensor defective	Replace
	Engine Coolant Temperature Sensor circuit open or shorted	Correct or replace
	Engine Coolant Temperature Sensor defective	Replace
	Mass Airflow Sensor circuit open or poor connections	Correct or replace
	Mass Airflow Sensor defective	Replace
	MAP Sensor cable broken or poor connections	Correct or replace
	MAP Sensor defective	Replace
	IAT Sensor circuit open or poor connections	Correct or replace
	IAT Sensor defective	Replace
	KS circuit open or poor connections	Correct or replace
	KS defective	Replace
	KS Module circuit open or shorted	Correct or replace
	KS Module defective	Replace
	Throttle valve not fully opened	Check and correct or replace
	Air Cleaner Filter clogged	Replace filter element
	Power supply voltage too low	Check and correct or replace

Engine Lacks Power

Condition	Possible cause	Correction
Trouble in fuel system	Fuel Pressure Control Valve not working normally	Replace
	Fuel injector clogged	Clean or replace
	Fuel pipe clogged	Clean
	Fuel filter clogged or fouled	Replace
	Fuel pump drive circuit not working normally	Correct or replace
	Fuel tank not sufficiently breathing due to clogged Evaporative Emission Control System circuit	Clean or replace
	Water in fuel system	Clean
	Inferior quality fuel in fuel system	Use fuel of specified octane rating
	Powertrain Control Module supplied poor voltage	Correct circuit
	Throttle Position Sensor cable broken or poor connections	Correct or replace
	Throttle Position Sensor defective	Replace
	Mass Airflow Sensor not working normally	Replace
	Manifold Absolute Pressure Sensor not working normally	Replace
	Intake Air Temperature Sensor not working normally	Replace
	Engine Coolant Temperature Sensor circuit open or shorted	Correct or replace
	Engine Coolant Temperature Sensor defective	Replace
	Powertrain Control Module defective	Replace
Trouble in intake or exhaust system	Air Cleaner Filter clogged	Replace filter element
	Air duct kinked or flattened	Correct or replace
Ignition failure	_____	Refer to Hard Start Troubleshooting Guide
	Heat range of spark plug inadequate	Install spark plugs of adequate heat range
	Ignition coil defective	Replace

Condition	Possible cause	Correction
Engine overheating	Level of Engine Coolant too low	Replenish
	Fan clutch defective	Replace
	Incorrect fan installed	Replace
	Thermostat defective	Replace
	Engine Coolant pump defective	Correct or replace
	Radiator clogged	Clean or replace
	Radiator filler cap defective	Replace
	Level of oil in engine crankcase too low or wrong engine oil	Change or replenish
	Resistance in exhaust system increased	Clean exhaust system or replace defective parts
	Throttle Position Sensor adjustment incorrect	Replace with Throttle Valve ASM
	Throttle Position Sensor circuit open or shorted	Correct or replace
	Cylinder head gasket damaged	Replace
Engine overcooling	Thermostat defective	Replace (Use a thermostat set to open at 82°C (180°F))
Engine lacks compression	—————	Refer to Hard Start
Others	Tire inflation pressure abnormal	Adjust to recommended pressures
	Brake drag	Adjust
	Clutch slipping	Adjust or replace
	Level of oil in engine crankcase too high	Correct level of engine oil
	Exhaust Gas Recirculation Valve defective	Replace

Engine Noisy

Abnormal engine noise often consists of various noises originating in rotating parts, sliding parts and other mov-

ing parts of the engine. It is, therefore, advisable to locate the source of noise systematically.

Condition	Possible cause	Correction
Noise from crank journals or from crank bearings (Faulty crank journals and crank bearings usually make dull noise that becomes more evident when accelerating)	Oil clearance increased due to worn crank journals or crank bearings	Replace crank bearings and crankshaft or regrind crankshaft and install the undersize bearing
	Crankshaft out of round	Replace crank bearings and crankshaft or regrind crankshaft and install the undersize bearing
	Crank bearing seized	Crank bearing seized Replace crank bearings and crankshaft or regrind crankshaft and install the undersize bearing

6A-12 ENGINE MECHANICAL (6VD1 3.2L)

Troubleshooting Procedure

Short out each spark plug in sequence using insulated spark plug wire removers. Locate cylinder with defective

bearing by listening for abnormal noise that stops when spark plug is shorted out.

Condition	Possible cause	Correction
Noise from connecting rods or from connecting rod bearings (Faulty connecting rods or connecting rod bearings usually make an abnormal noise slightly higher than the crank bearing noise, which becomes more evident when engine is accelerated)	Bearing or crankshaft pin worn	Replace connecting rod bearings and crankshaft or regrind crankshaft pin and install the undersize bearing
	Crankpin out of round	Replace connecting rod bearings and crankshaft or regrind crankshaft pin and install the undersize bearing
	Connecting rod bent	Correct or replace
	Connecting rod bearing seized	Replace connecting rod bearings and crankshaft or regrind crankshaft pin and install the undersize bearing

Troubleshooting Procedure

Abnormal noise stops when the spark plug on the cylinder with defective part is shorted out.

Condition	Possible cause	Correction
Piston and cylinder noise (Faulty piston or cylinder usually makes a combined mechanical thumping noise which increases when engine is suddenly accelerated but diminishes gradually as the engine warms up)	Piston clearance increased due to cylinder wear	Replace piston and cylinder body
	Piston seized	Replace piston and cylinder body
	Piston ring broken	Replace piston and cylinder body
	Piston defective	Replace pistons and others

Troubleshooting Procedure

Short out each spark plug and listen for change in engine noise.

Condition	Possible cause	Correction
Piston pin noise (Piston makes noise each time it goes up and down)	Piston pin or piston pin hole worn	Replace piston, piston pin and connecting rod assy

Troubleshooting Procedure

The slapping sound stops when spark plug on bad cylinder is shorted out.

Condition	Possible cause	Correction
Timing belt noise	Timing belt tension is incorrect	Replace pusher or adjust the tension pulley or replace timing belt
	Tensioner bearing defective	Replace
	Timing belt defective	Replace
	Timing pulley defective	Replace
	Timing belt comes in contact with timing cover	Replace timing belt and timing cover
Valve noise	Valve clearance incorrect	Replace adjusting shim
	Valve and valve guide seized	Replace valve and valve guide
	Valve spring broken or weakened	Replace
	Valve seat off-positioned	Correct
	Camshaft worn out	Replace
Crankshaft noise	Crankshaft end play excessive (noise occurs when clutch is engaged)	Replace thrust bearing
Engine knocking	Preignition due to use of spark plugs of inadequate heat range	Install Spark Plugs of adequate heat range
	Carbon deposits in combustion chambers	Clean
	Fuel too low in octane rating	Replace fuel
	Wide Open Throttle enrichment system failure	Refer to Section 6E
	Selection of transmission gear incorrect	Caution operator of incorrect gear selection
	Engine overheating	Refer to "Engine Lacks Power"
Others	Water pump defective	Replace
	Drive belt slipping	Replace auto tensioner or drive belt

Abnormal Combustion

Condition	Possible cause	Correction
Trouble in fuel system	Fuel pressure control valve defective	Replace
	Fuel filter clogged	Replace
	Fuel pump clogged	Clean or replace
	Fuel tank or fuel pipe clogged	Clean or replace
	Fuel injector clogged	Clean or replace
	Fuel pump relay defective	Replace
	Power supply cable for fuel pump broken or poor connections	Reconnect, correct or replace
	Mass Airflow (MAF) Sensor circuit open or defective	Correct or replace
	MAF Sensor defective	Replace
	Manifold Absolute Pressure Sensor circuit open or shorted	Correct or replace
	Manifold Absolute Pressure Sensor defective	Replace
	Engine Coolant Temperature (ECT) Sensor circuit open or shorted	Correct or replace
	ECT Sensor defective	Replace
	Throttle Position Sensor adjustment incorrect	Readjust
	Throttle Position Sensor defective	Replace
	Throttle Position Sensor connector poor connections	Reconnect
	Vehicle Speed Sensor cable poor connections or defective	Correct or replace
	Vehicle Speed Sensor loosely fixed	Fix tightly
	Vehicle Speed Sensor in wrong contact or defective	Replace
	Powertrain Control Module cable poor connections or defective	Correct or replace
Trouble in emission control system	Heated Oxygen Sensor circuit open	Correct or replace
	Heated Oxygen Sensor defective	Replace
	Signal vacuum hose loosely fitted or defective	Correct or replace
	EGR Valve circuit open or shorted	Correct or replace
	Exhaust Gas Recirculation Valve defective	Replace
	ECT Sensor circuit open or shorted	Correct or replace
	Canister Purge Valve circuit open or shorted	Correct or replace
	Canister Purge Valve defective	Replace
	ECT Sensor defective	Replace
	Positive Crankcase Ventilation (PCV) valve and hose clogged	Correct or replace
	Evaporator system	Refer to Section 6E
Trouble in ignition system	—————	Refer to "Engine Lacks Power"

Condition	Possible cause	Correction
Trouble in cylinder head parts	Carbon deposits in combustion chamber	Remove carbon
	Carbon deposit on valve, valve seat and valve guide	Remove carbon

Engine Oil Consumption Excessive

Condition	Possible cause	Correction
Oil leaking	Oil pan drain plug loose	Retighten or replace gasket
	Crankcase fixing bolts loosened	Retighten
	Oil pan setting bolts loosened	Retighten
	Oil pan gasket broken	Replace gasket
	Front cover retaining bolts loose or gasket broken	Retighten or replace gasket
	Head cover fixing bolts loose or gasket broken	Retighten or replace gasket
	Oil cooler adapter cracked	Replace
	Oil cooler center bolt loose	Retighten
	Oil cooler O-ring broken	Replace
	Oil cooler piping loose or broken	Retighten or replace
	Oil filter adapter cracked	Replace
	Oil filter attachings bolt loose or rubber gasket broken	Retighten or replace oil filter
	Oil cooler broken	Replace
	Crankshaft front or rear oil seal defective	Replace oil seal
	Oil pressure unit loose or broken	Retighten or replace
	Blow-by gas hose broken	Replace hose
	Positive Crankcase Ventilation Valve clogged	Clean
	Engine/Transmission coupling failed	Replace oil seal
Oil leaking into combustion chambers due to poor seal in valve system	Valve stem oil seal defective	Replace
	Valve stem or valve guide worn	Replace valve and valve guide
Oil leaking into combustion chambers due to poor seal in cylinder parts	Cylinders and pistons worn excessively	Replace cylinder body assembly and pistons
	Piston ring gaps incorrectly positioned	Correct
	Piston rings set with wrong side up	Correct
	Piston ring sticking	Replace cylinder body assembly and pistons
	Piston ring and ring groove worn	Replace pistons and others
	Return ports in oil rings clogged	Clean piston and replace rings
Positive Crankcase Ventilation System malfunctioning	Positive Crankcase Ventilation Valve clogged	Clean
Others	Improper oil viscosity	Use oil of recommended S.A.E. viscosity
	Continuous high speed driving and/or severe usage such as trailer towing	Continuous high speed operation and/or severe usage will normally cause increased oil consumption

Fuel Consumption Excessive

Condition	Possible cause	Correction
Trouble in fuel system	Mixture too rich or too lean due to trouble in fuel injection system	Refer to "Abnormal Combustion"
	Fuel cut function does not work	Refer to "Abnormal Combustion"
Trouble in ignition system	Misfiring or abnormal combustion due to trouble in ignition system	Refer to "Hard Start" or "Abnormal Combustion"
Others	Engine idle speed too high	Reset Idle Air Control Valve
	Returning of accelerator control sluggish	Correct
	Fuel system leakage	Correct or replace
	Clutch slipping	Correct
	Brake drag	Correct
	Selection of transmission gear incorrect	Caution operator of incorrect gear selection
	Excessive Exhaust Gas Recirculation flow due to trouble in Exhaust Gas Recirculation system	Refer to "Abnormal Combustion"

Lubrication Problems

Condition	Possible cause	Correction
Oil pressure too low	Wrong oil in use	Replace with correct engine oil
	Relief valve sticking	Replace
	Oil pump not operating properly	Correct or replace
	Oil pump strainer clogged	Clean or replace strainer
	Oil pump worn	Replace
	Oil pressure gauge defective	Correct or replace
	Crankshaft bearing or connecting rod bearing worn	Replace
Oil contamination	Wrong oil in use	Replace with correct engine oil
	Oil filter clogged	Replace oil filter
	Cylinder head gasket damage	Replace gasket
	Burned gases leaking	Replace piston and piston rings or cylinder body assembly
Oil not reaching valve system	Oil passage in cylinder head or cylinder body clogged	Clean or correct

Engine Oil Pressure Check

- Check for dirt, gasoline or water in the engine oil.
 - Check the viscosity of the oil.
 - Check the viscosity of the oil.
 - Change the oil if the viscosity is outside the specified standard.
 - Refer to the "Maintenance and Lubrication" section of this manual.
- Check the engine oil level.
The level should fall somewhere between the "ADD" and the "FULL" marks on the oil level dipstick.
If the oil level does not reach the "ADD" mark on the oil level dipstick, engine oil must be added.

- Remove the oil pressure unit.
- Install an oil pressure gauge.
- Start the engine and allow the engine to reach normal operating temperature (About 80°C).
- Measure the oil pressure.
Oil pressure should be:
392–550 kPa (56.9–80.4 psi) at 3000 rpm.
- Stop the engine.
- Remove the oil pressure gauge.
- Install the oil pressure unit.
- Start the engine and check for leaks.

Malfunction Indicator Lamp

The instrument panel "CHECK ENGINE" Malfunction Indicator Lamp (MIL) illuminates by self diagnostic system


when the system checks the starting of engine, or senses malfunctions.

Condition	Possible cause	Correction
"CHECK ENGINE" MIL does not illuminate at the starting of engine	Bulb defective	Replace
	MIL circuit open	Correct or replace
	Command signal circuit to operate self diagnostic system shorted	Correct or replace
	Powertrain Control Module (PCM) cable loosely connected, disconnected or defective	Correct or replace
	PCM defective	Replace
"CHECK ENGINE" MIL illuminates, and stays on	Deterioration of heated oxygen sensor internal element	Replace
	Heated oxygen sensor connector terminal improper contact	Reconnect properly
	Heated oxygen sensor lead wire shorted	Correct
	Heated oxygen sensor circuit open	Correct or replace
	Deterioration of engine coolant temperature sensor internal element	Replace
	Engine coolant temperature sensor connector terminal improper contact	Reconnect properly
	Engine coolant temperature sensor lead wire shorted	Correct
	Engine coolant temperature sensor circuit open	Correct or replace
	Throttle position sensor open or shorted circuits	Correct or replace
	Deterioration of crankshaft position sensor	Replace
	Crankshaft position sensor circuit open or shorted	Correct or replace
	Vehicle speed sensor circuit open	Correct or replace
	Manifold absolute pressure sensor circuit open or shorted	Correct or replace
	Intake air temperature sensor circuit open or shorted	Correct or replace
	Fuel injector circuit open or shorted	Correct or replace
	PCM driver transistor defective	Replace PCM
	Malfunctioning of PCM RAM (Random Access Memory) or ROM (Read Only Memory)	Replace PCM

Cylinder Head Cover LH

Removal


1. Disconnect battery ground cable.
2. Remove air cleaner duct assembly.



Legend

- (1) Positive Crankcase Ventilation Hose Connector
- (2) Intake Air Temperature Sensor
- (3) Air Cleaner Duct Assembly
- (4) Air Cleaner Element
- (5) Mass Air Flow Sensor


3. Disconnect positive crankcase ventilation hose.
4. Remove camshaft angle sensor connector.
5. Remove ground cable fixing bolt on cylinder head cover.
6. Ignition coil connector and ignition coil.
 - Disconnect the three connectors from the ignition coils.
 - Remove harness bracket bolt on cylinder head cover.
 - Remove fixing bolts on ignition coils.



Legend

- (1) Ignition Coil Connector
- (2) Bolt
- (3) Ignition Coil Assemblies

7. Remove fixing bolt for fuel injector harness bracket.
8. Remove eight fixing bolts, then the cylinder head cover.




Installation

1. Install cylinder head cover.

- Clean the sealing surface of cylinder head and cylinder head cover to remove oil and sealing materials completely.
- Apply sealant (TB-1207B or equivalent) of bead diameter 2-3 mm at eight place of arched area of camshaft bracket on front and rear sides.
- The cylinder head cover must be installed within 5 minutes after sealant application to prevent hardening of sealant.
- Tighten bolts to the specified torque.

Torque : 9 N·m (80 lb in)




010RW006

2. Install fuel injection harness bracket and tighten bolt to the specified torque.

Torque : 9 N·m (80 lb in)

3. Connect ignition coil connector and ignition coil, then tighten bolt to the specified torque.

Torque : 4 N·m (35 lb in)



060RW018

Legend

- (1) Ignition Coil Connector
- (2) Bolt
- (3) Ignition Coil Assembly

4. Connect ground cable and tighten bolts to the specified torque.


Torque : 9 N·m (80 lb in)

- 5. Connect camshaft angle sensor connector.
- 6. Install positive crankcase ventilation hose.
- 7. Install air cleaner duct assembly.


Cylinder Head Cover RH

Removal

1. Disconnect battery ground cable.
2. Disconnect ventilation hose from cylinder head cover.
3. Disconnect three ignition coil connectors from ignition coils and remove harness bracket bolts on cylinder head cover then remove ignition coil fixing bolts on ignition coils and remove ignition coils.
4. Remove heater pipe fixing bolts from the bracket.
5. Disconnect fuel injector harness connector then remove fuel injector harness bracket bolt.
6. Remove exhaust gas recirculation (EGR) pipe.
 - Remove flare nut from EGR valve.
 - Remove fixing bolt of EGR pipe bracket on rear end cylinder head.
 - Remove two fixing bolt and nut on exhaust manifold.




7. Remove eight fixing bolts then the cylinder head cover.



Installation

1. Install cylinder head cover.
 - Clean the sealing surface of cylinder head and cylinder head cover to remove oil and sealing materials completely.
Apply sealant (TB-1207B or equivalent) of bead diameter 2-3 mm at eight place of arched area of camshaft bracket on front and rear sides.
 - The cylinder head cover must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.
 - Tighten bolts to the specified torque.

Torque : 9 N·m (80 lb in)



2. Install exhaust gas recirculation pipe and tighten to specified torque.

Torque:

Exhaust manifold side: 28 N·m (21 lb ft)

Flare nut: 44 N·m (33 lb ft)

Cylinder head side: 25 N·m (18 lb ft)

3. Tighten fuel injector harness bracket bolts to specified torque then reconnect fuel injector harness connector.

Torque : 7.8 N·m (5.7 lb ft)

4. Install heater pipe bolt to the specified torque.

Torque : 21 N·m (15 lb ft)

5. Connect ignition coil connector and tighten ignition coil fixing bolts to specified torque.


Torque : 4 N·m (35 lb in)

6. Connect ventilation hose to cylinder head.

Common Chamber

Removal


1. Disconnect battery ground cable.
2. Remove air cleaner duct assembly.



Legend

- (1) Positive Crankcase Ventilation Hose Connector
- (2) Intake Air Temperature Sensor
- (3) Air Cleaner Duct Assembly
- (4) Air Cleaner Element
- (5) Air Flow Sensor

3. Disconnect accelerator pedal cable from throttle body and cable bracket.
4. Disconnect vacuum booster hose from common chamber.
5. Disconnect connector from manifold absolute pressure sensor, idle air control valve, throttle position sensor, solenoid valve, electric vacuum sensing valve, and EGR valve.
6. Disconnect vacuum hose on canister VSV and positive crankcase ventilation hose, fuel rail assembly with pressure control valve bracket.
7. Remove ventilation hose from throttle valve and intake duct and remove water hose.
8. Remove the four throttle body fixing bolts.
9. Remove exhaust gas recirculation valve assembly fixing bolt and nut on common chamber and remove EGR valve assembly.
10. Remove two bolts from common chamber rear side for remove fuel hose bracket.
11. Remove common chamber four bolts and four nuts then remove the common chamber.



Legend

- (1) Common Chamber
- (2) Throttle Valve Assembly
- (3) Bolt

Installation

1. Install common chamber and tighten bolts and nuts to the specified torque.

Torque :

Bolt : 25 N·m (18 lb ft)

Nut : 25 N·m (18 lb ft)

2. Install fuel hose bracket and tighten bolts to specified torque.

Torque : 10 N·m (89 lb in)

3. Install exhaust gas recirculation valve assembly and tighten bolt and nut to the specified torque.

Torque : 25 N·m (18 lb ft)

4. Install throttle body and tighten bolts to the specified torque.

Torque : 25 N·m (18 lb ft)


5. Install ventilating hose to throttle valve and intake duct.

6. Connect vacuum hoses on canister VSV and positive crankcase ventilation hose. Tighten bolts for fuel rail assembly with pressure control valve bracket.

Torque : 25 N·m (18 lb ft)

7. Connect each connector without fail.
8. Connect vacuum booster hose.
9. Connect accelerator pedal cable.

10. Install air cleaner duct assembly.




Legend

- (1) Positive Crankcase Ventilation Hose Connector
- (2) Intake Air Temperature Sensor
- (3) Air Cleaner Duct Assembly
- (4) Air Cleaner Element.
- (5) Air Flow Sensor

Exhaust Manifold LH

Removal

1. Disconnect battery ground cable.
2. Remove air cleaner duct assembly.




130RW001

Legend

- (1) Positive Crankcase Ventilation Hose Connector
- (2) Intake Air Temperature Sensor
- (3) Air Cleaner Duct Assembly
- (4) Air Cleaner Element
- (5) Air Flow Sensor

3. Disconnect O₂ sensor connector.
4. Remove exhaust front pipe three stud nuts from exhaust side and two nuts from rear end of exhaust front pipe.



035RW006

Legend

- (1) Exhaust Front Pipe LH
- (2) O₂ Sensor

5. Remove heat protector two fixing bolts then the heat protector.
6. Remove a bolt on engine LH side for air conditioner (A/C) compressor bracket and loosen two bolts for A/C compressor then move A/C compressor to front side.
7. Remove exhaust manifold eight fixing nuts and remove exhaust manifold from the engine.

Installation

1. Install exhaust manifold and tighten exhaust manifold fixing nuts to the specified torque with new nuts.


Torque: 57 N·m (42 lb ft)

2. Install heat protector.
3. Install exhaust front pipe and tighten three stud nuts and two nuts to the specified torque.

Torque :

Stud nuts: 67 N·m (49 lb ft)

Nuts: 43 N·m (32 lb ft)



035RW016

Legend

- (1) O₂ Sensor
- (2) Exhaust Front Pipe LH

4. Set A/C compressor to normal position and tighten two bolts and a bolt to the specified torque.


Torque : 40 N·m (30 lb ft)

5. Reconnect O₂ sensor connector.
6. Install air cleaner duct assembly.

Exhaust Manifold RH

Removal

1. Disconnect battery ground cable.
2. Remove torsion bar. Refer to removal procedure in Front Suspension section.
3. Remove exhaust front pipe three stud nuts and two nuts then disconnect exhaust front pipe.




Legend

- (1) Exhaust Front Pipe RH
- (2) O2 Sensor

4. Remove heat protector two fixing bolts then the heat protector.

5. Remove exhaust gas recirculation (EGR) pipe fixing bolt and nut from exhaust manifold, remove a nut from EGR valve and a bolt from rear side of cylinder head for bracket of EGR pipe then remove the EGR pipe.



Legend

- (1) Exhaust Gas Recirculation (EGR) Valve
- (2) EGR Pipe

6. Remove exhaust manifold eight fixing nuts then the exhaust manifold.

Installation

1. Install exhaust manifold and tighten bolts to the specified torque.

Torque : 57 N-m (42 lb ft)

2. Install the EGR pipe, tighten bolt and nut on exhaust manifold to specified torque.

Torque : 28 N-m (21 lb ft)

Tighten nut to EGR valve to the specified torque.

Torque : 44 N-m (33 lb ft)

Tighten the bolt for EGR pipe bracket to specified torque.

Torque : 25 N-m (18 lb ft)

3. Install heat protector

4. Install exhaust front pipe and tighten three stud nuts and two nuts to the specified torque.

Torque:

Stud nuts: 67 N-m (49 lb ft)


Nuts: 43 N-m (32 lb ft)

5. Install the torsion bar and readjust the vehicle height. Refer to installation and vehicle height adjustment procedure for front suspension.

Crankshaft Pulley

Removal


1. Disconnect battery ground cable.
2. Remove air cleaner assembly.



Legend

- (1) Positive Crankcase Ventilation Hose Connector
- (2) Intake Air Temperature Sensor
- (3) Air Cleaner Duct Assembly
- (4) Air Cleaner Element
- (5) Air Flow Sensor

3. Remove radiator upper fan shroud from radiator.
4. Move serpentine belt tensioner to loose side using wrench then remove serpentine belt.



Legend

- (1) Crankshaft Pulley
- (2) Cooling Fan Pulley
- (3) Tensioner
- (4) Generator
- (5) Air Conditioner Compressor
- (6) Power Steering Oil Pump
- (7) Serpentine Belt

5. Remove cooling fan assembly four fixing nuts, then the cooling fan assembly.
6. Remove crankshaft pulley assembly using J-8614-01 crankshaft holder, hold crankshaft pulley then remove center bolt and pulley.

Installation

1. Install crankshaft pulley using J-8614-01 crankshaft holder, hold the crankshaft pulley and tighten center bolt to the specified torque.

Torque : 167 N·m (123 lb ft)

2. Install cooling fan assembly and tighten bolts/nuts to the specified torque.

Torque : 22 N·m (16 lb ft) for fan pulley and fan bracket.


Torque : 7.5 N·m (66.4 lb in) for fan and clutch assembly.

3. Move serpentine belt tensioner to loose side using wrench, then install serpentine belt to normal position.
4. Install radiator upper fan shroud.
5. Install air cleaner assembly.

Timing Belt

Removal

1. Disconnect battery ground cable.
2. Remove air cleaner assembly.
3. Remove radiator upper fan shroud from radiator.
4. Move drive belt tensioner to loose side using wrench then remove drive belt.



850RW001


Legend

- (1) Crankshaft Pulley
- (2) Cooling Fan Pulley
- (3) Tensioner
- (4) Generator
- (5) Air Conditioner Compressor
- (6) Power Steering Oil Pump
- (7) Drive Belt

5. Remove cooling fan assembly four nuts, then the cooling fan assembly.
6. Remove cooling fan drive pulley assembly.
7. Remove idle pulley assembly.
8. Remove serpentine belt tensioner assembly.
9. Remove power steering pump assembly.
10. Remove crankshaft pulley assembly using J-8614-01 crankshaft holder, hold crankshaft pulley remove center bolt, then the pulley.

11. Remove right side timing belt cover then left side timing belt cover.
12. Remove lower timing belt cover
13. Remove pusher.

CAUTION: The pusher prevents air from entering the oil chamber. Its rod must always be facing upward.



014RW011

Legend

- (1) Up Side
- (2) Down Side
- (3) Direction For Installation
- (4) Locking Pin


14. Remove timing belt.

CAUTION:

1. Do not bend or twist the belt, otherwise its core could be damaged. The belt should not be bent at a radius less than 30 mm.
2. Do not allow oil or other chemical substances to come in contact with the belt. They will shorten the life.
3. Do not attempt to pry or stretch the belt with a screw driver or any other tool during installation.
4. Store timing belt in a cool and dark place. Never expose the belt direct sunlight or heat.

Installation

NOTE: For correct belt installation, the letter on the belt must be able to be read as viewed from the front of the vehicle.



014RW005

Legend

- (1) Crankshaft Timing Pulley
- (2) RH Bank Camshaft Drive Gear Pulley
- (3) Water Pump Pulley
- (4) Idle Pulley
- (5) LH Bank Camshaft Drive Gear Pulley
- (6) Tension Pulley
- (7) Alignment Mark on Oil Pump.
- (8) Alignment Mark on Timing Belt


1. Install timing belt.

1. Align groove of crankshaft timing pulley with mark on oil pump.

Align the mark on the crankshaft timing pulley with alignment mark (white dots line) on the timing belt.

Secure the belt with a double clip.


NOTE: When timing marks are aligned, No.2 piston will be on Top Dead Center.



014RW003

Legend

- (1) Alignment Mark on Oil Pump
- (2) Groove on Crankshaft Timing Pulley
- (3) Alignment Mark on Crankshaft Timing Pulley
- (4) Alignment Mark on Timing Belt




014RW006

Legend

- (1) Timing Belt
- (2) Engine Rotation Direction
- (3) Cylinder Head Side

2. Align the marks on the camshaft drive gear pulleys with the corresponding alignment marks on the cylinder head covers.




014RW004

Legend

- (1) Alignment Mark on Camshaft Drive Gear Pulley
- (2) Alignment Mark on Cylinder Head Cover.
- (3) Alignment Mark on Timing Belt (White Line)

3. Align the alignment mark (white line) on the timing belt with alignment mark on the RH bank camshaft drive gear pulley (on the left side as viewed from the front of the vehicle).
Secure the belt with a double clip.




014RW008

4. Align the alignment mark (white line) on the timing belt with the alignment mark on the LH bank camshaft drive gear pulley.

When aligning the timing marks, use a wrench to turn the camshaft drive gear pulley, then set the timing mark between timing belt and camshaft drive gear pulley.

Secure the belt with a double clip.

NOTE: It is recommended for easy installation that the belt be secured with a double clip after it is installed to each pulley.



014RW009

5. Install crankshaft pulley temporarily and tighten center bolt by hand (do not use a wrench).


Turn the crankshaft pulley clockwise to give some belt slack between the crankshaft timing pulley and the RH bank camshaft drive gear pulley.

6A-30 ENGINE MECHANICAL (6VD1 3.2L)

2. Install pusher and tighten bolt to the specified torque.

1. Install the pusher while pushing the tension pulley to the belt.
2. Pull out pin from the pusher.

NOTE: When reusing the pusher, press the pusher with approximately 100Kg to retract the rod, and insert a pin (1.4 mm piano wire).



Legend

- (1) Up Side
- (2) Down Side
- (3) Direction for Installation
- (4) Locking Pin


3. Remove double clips from timing belt pulleys.
Turn the crankshaft pulley clockwise by two turns.

Torque : 25 N·m (18 lb ft)

3. Install timing belt cover.
Remove crankshaft pulley that was installed in step 1 item 5.


Tighten bolts to the specified torque.

Torque: 19 N·m (14 lb ft)



Legend

- (1) Timing Belt Cover RH
- (2) Timing Belt Cover LH
- (3) Timing Belt Cover Lower



Legend

- (1) Timing Belt Cover
- (2) Rubber Bushing
- (3) Sealing Rubber
- (4) Cylinder Body

4. Install crankshaft pulley using J-8614-01, hold the crankshaft pulley and tighten center bolt to the specified torque.

Torque : 167 N·m (123 lb ft)

5. Install fan pulley bracket and tighten fixing bolts to the specified torque.

Torque : 22 N·m (16 lb ft)

6. Install power steering pump assembly and tighten to the specified torque.

Torque :

M8 bolt : 22 N·m (16 lb ft)


M10 bolt : 46 N·m (34 lb ft)

7. Install cooling fan assembly and tighten bolts/nuts to the specified torque.

Torque : 22 N·m (16 lb ft) for fan pulley and fan bracket.

Torque : 7.5 N·m (66.4 lb in) for fan and clutch assembly.

8. Move drive belt tensioner to loose side using wrench, then install drive belt to normal position.



850RW001

Legend


- (1) Crankshaft Pulley
- (2) Cooling Fan Pulley
- (3) Tensioner
- (4) Generator
- (5) Air Conditioner Compressor
- (6) Power Steering Oil Pump
- (7) Drive Belt

9. Install radiator upper fan shroud.
10. Install air cleaner assembly.


Camshaft

Removal

1. Disconnect battery ground cable.
2. Remove crankshaft pulley.
○Refer to removal procedure for Crankshaft Pulley in this manual.
3. Remove timing belt.
○Refer to removal procedure for Timing Belt in this manual.
4. Remove cylinder head cover LH.
○Refer to removal procedure for Cylinder Head Cover LH in this manual.
5. Remove cylinder head cover RH.
○Refer to removal procedure for Cylinder Head Cover RH in this manual.
6. Remove twenty fixing bolts from inlet and exhaust camshaft bracket on one side bank, then camshaft brackets.



7. Remove camshaft assembly.
8. Remove fixing bolt for camshaft drive gear pulley.
9. Remove three fixing bolts from camshaft drive gear retainer, then camshaft drive gear assembly.



Legend

- (1) Right Bank
- (2) Left Bank
- (3) Timing Mark on Retainer

Installation

1. Install camshaft drive gear assembly and tighten three bolts to the specified torque.


Torque : 10 N·m (89 lb in)

2. Tighten bolt for camshaft drive gear assembly pulley to the specified torque.

Torque : 98 N·m (72 lb ft)

3. Tighten sub gear setting bolt.


1. Use J-42686 to turn sub gear to right direction until it aligns with the M5 bolt hole between camshaft driven gear and sub gear.
2. Tighten the M5 bolt to a suitable torque to prevent the sub gear from moving.



014RW041

4. Install camshaft assembly and camshaft brackets, tighten twenty bolts on one side bank to the specified torque.


1. Apply engine oil to camshaft journal and bearing surface of camshaft bracket.
2. Align timing mark on intake camshaft (one dot for right bank, two dot for left bank) and exhaust camshaft (one dot for right bank, two dots for left bank) to timing mark on camshaft drive gear (one dot).



014RW020

Legend


- (1) Intake Camshaft Timing Gear for Right Bank
- (2) Intake Camshaft Timing Gear for Left Bank
- (3) Exhaust Camshaft Timing Gear
- (4) Discrimination Mark
(LI: Left bank intake, RI: Right bank intake)
(LE: Left bank exhaust, RE: Right bank exhaust)



014RW023

Legend

- (1) Right Bank Camshaft Drive Gear
- (2) Left Bank Camshaft Drive Gear
- (3) Timing Mark on Drive Gear
- (4) Dowel Pin



014RW024


Legend

- (1) Right Bank
- (2) Left Bank

- (3) Alignment Mark on Camshaft Drive Gear
- (4) Alignment Mark on Camshaft
- (5) Alignment Mark on Retainer

3. Tighten twenty bolts on numerical order an one side bank as shown in the illustration.

Torque : 10 N·m (89 lb in)



014RW031

5. Install cylinder head cover RH.

○Refer to installation procedure for CYLINDER HEAD COVER RH in this manual.

6. Install cylinder head cover LH.

○Refer to installation procedure for CYLINDER HEAD COVER LH in this manual.

7. Install timing belt.

○Refer to installation procedure for TIMING BELT in this manual.

8. Install crankshaft pulley.

○Refer to installation procedure for CRANKSHAFT PULLEY in this manual.


9. Install Accelerator pedal cable.

THIS PAGE INTENTIONALLY LEFT BLANK

Cylinder Head

Removal

1. Remove engine hood.
2. Disconnect battery ground cable.
3. Drain radiator coolant.
4. Drain engine oil.
5. Remove crankshaft pulley.
 - Refer to removal procedure for Crankshaft Pulley in this manual.
6. Remove timing belt.
 - Refer to removal procedure for Timing Belt in this manual.
7. Remove cylinder head cover LH.
 - Refer to removal procedure for Cylinder Head Cover LH in this manual.
8. Remove cylinder head cover RH.
 - Refer to removal procedure for Cylinder Head Cover RH in this manual.
9. Remove common chamber.
 - Refer to removal procedure for Common Chamber in this manual.
10. Remove cylinder head assembly.
 1. Loosen eight bolts for tight cylinder head.
 2. Remove cylinder head assembly.



Legend


- (1) Cylinder Head
- (2) Cylinder Head Bolt
- (3) Camshaft

Installation

1. Install cylinder head assembly to cylinder block.
 1. Put cylinder head gasket on the cylinder block.

NOTE: There is discrimination mark "R" for right bank and "L" for left bank on the cylinder head gasket as shown in the illustration.

Do not reuse cylinder head gasket.



2. Align dowel pin hole to dowel pin on the cylinder block.
3. Tighten two bolts temporarily by hand to prevent the cylinder head assembly from moving.
4. Using J-24239-01 cylinder head bolt wrench, tighten bolts in numerical order as shown in the illustration to the specified torque.


NOTE: Do not reuse cylinder head bolts.

Do not apply any lubricant to the cylinder head bolts.

Torque :

Temporary : 29 N·m (21 lb ft)

Final : 64 N·m (47 lb ft)



2. Install common chamber.
 - Refer to installation procedure for Common Chamber in this manual.
3. Install cylinder head cover RH.
 - Refer to installation procedure for Cylinder Head Cover RH in this manual.
4. Install cylinder head cover LH.
 - Refer to installation procedure for Cylinder Head Cover LH in this manual.
5. Install timing belt.
 - Refer to installation procedure for Timing Belt in this manual.
6. Install crankshaft pulley.
 - Refer to installation procedure for Crankshaft Pulley in this manual.
7. Install Accelerator pedal cable.


Valve Stem Oil Controller , Valve Spring and Valve Guide

Removal

1. Disconnect battery ground cable.
2. Drain engine oil.
 - Drain engine coolant.
3. Remove cylinder head assembly.
 - Refer to removal procedure for Cylinder Head in this manual.
4. Remove camshaft.
 - Refer to removal procedure for Camshaft in this manual.
5. Remove tappets with shim.

NOTE: Do not damage shim surface.


6. Remove valve springs using J-8062 valve spring compressor and J-42898 valve spring compressor adapter then remove upper valve spring seat and lower seat.



7. Remove oil controller using J-37281 oil controller remover, remove each valve stem oil controller.
8. Remove valve guide using J-37985 valve guide replacer.

Installation


1. Install valve guide using J-42899 valve guide installer.
2. Install oil controller using J-38537 oil controller installer.
3. Install lower valve spring seat, valve spring and upper valve spring seat then put split collars on the upper spring seat, using J-8062 valve spring compressor and J-42898 valve spring compressor adapter to install the split collars.



4. Install tappet with shim.
5. Install camshaft assembly.
 - Refer to installation procedure for Camshaft in this manual.
6. Install cylinder head assembly.
 - Refer to installation procedure for Cylinder Head in this manual.
7. Fill engine oil until full level.
8. Fill engine coolant.

Piston, Piston Ring and Connecting Rod

Removal



F06RW011

Legend

- | | |
|----------------------------|---|
| (1) Cylinder Head | (4) Oil Strainer |
| (2) Crankcase with Oil Pan | (5) Oil Gallery |
| (3) Oil Pipe | (6) Piston with Connecting Rod Assembly |

1. Remove cylinder head assembly.


○Refer to removal procedure for Cylinder Head in this manual.

2. Remove crankcase with oil pan.

○Refer to removal procedure for Oil Pan and Crankcase in this manual.

6A-40 ENGINE MECHANICAL (6VD1 3.2L)

3. Remove oil strainer fixing bolts, remove oil strainer assembly with O-ring.



Legend

- (1) Oil Pump
- (2) Oil Strainer
- (3) Oil Gallery
- (4) From Oil Filter
- (5) To Oil Filter

4. Remove three fixing bolts, oil pipe with O-ring.
5. Remove eight fixing bolts, oil gallery.
6. Remove piston with connecting rod assembly, before removing the bearing cap, remove carbon on the top of cylinder bore and push piston with connecting rod out from the top of cylinder bore.


Installation

1. Install piston with connecting rod assembly.
 - Apply engine oil to cylinder bore, connecting rod bearing and crank pin.
When installing the piston, its front mark must face the engine front side.
 - The bearing cap number must be the same as connecting rod number.
 - Apply engine oil to the thread and seating surface of each nut.
 - Tighten nuts to the specified torque.

Torque : 54 N·m (40 lb ft)

- After tightening the nuts, make sure that the crankshaft rotates smoothly.

NOTE: Do not apply engine oil to the bearing back faces and connecting rod bearing fitting surfaces.



Legend


- (1) Piston Front Mark
- (2) Piston Grade
- (3) Connecting Rod Front Mark

2. Install oil gallery and tighten the bolts in two steps, in the order shown in illustration.

Torque :

1st step : 29 N·m (21 lb ft)

2nd step : 55°–65°



3. Install oil pipe with O-ring.

Torque : 10 N·m (89 lb in)

4. Install oil strainer assembly with O-ring.

Torque : 25 N·m (18 lb ft)

5. Install crankcase with oil pan.


- Refer to installation procedure for Oil Pan and Crankcase in this manual.

6. Install cylinder head assembly.

- Refer to installation procedure for Cylinder Head in this manual.

Crankshaft and Main Bearings

Removal



F06RW010

Legend

- | | |
|----------------------------|----------------------------------|
| (1) Engine Assembly | (8) Oil Pump Assembly |
| (2) Crankshaft Pulley | (9) Cylinder Body Side Bolt |
| (3) Timing Belt Cover | (10) Oil Gallery |
| (4) Timing Belt | (11) Flywheel |
| (5) Crankcase with Oil Pan | (12) Rear Oil Seal Retainer |
| (6) Oil Pipe | (13) Connecting Rod Cap |
| (7) Oil Strainer | (14) Crankshaft Main Bearing Cap |
| | (15) Crankshaft and Main Bearing |

1. Remove engine assembly.

○Refer to removal procedure for Engine Assembly in this manual.

2. Remove timing belt.

○Refer to removal procedure for Timing Belt in this manual.

3. Remove oil pan and crankcase.

○Refer to removal procedure for Oil Pan and Crankcase in this manual.

4. Remove oil pipe with O-ring.

5. Remove oil strainer assembly with O-ring.


6. Remove oil pump assembly.
 - Refer to removal procedure for Oil Pump in this manual.
7. Remove cylinder body side bolts.
8. Remove oil gallery.
9. Remove flywheel.
10. Remove rear oil seal retainer.
 - Refer to removal procedure for Rear Oil Seal in this manual.
11. Remove connecting rod caps.
12. Remove crankshaft main bearing caps.
13. Remove crankshaft and main bearings.

Installation


1. Install crankshaft and main bearings.
 - Install main bearing in the cylinder block and main bearing cap respectively.
 - Apply new engine oil to upper and lower main bearings.

NOTE:

- Do not apply engine oil to the bearing back faces.
- Make sure that main bearings are in correct position.
- Install crankshaft with care.
- Apply engine oil to the thrust washer.
- Install thrust washer on No.3 journal.
- Oil grooves in thrust washer must face the crankshaft.



015RS012



015RS013

2. Install crankshaft main bearing caps.
 - Apply engine oil to the thread and seating surface of each bearing cap fixing bolt.

NOTE:


- Do not apply engine oil to the bearing back faces.
- Install bearing caps in the order of numbers, starting with cylinder block front side.
- Tighten main bearing fixing bolts to the specified torque.

Torque : 39 N·m (29 lb ft)

- After tightening the bolts, make sure that the crankshaft rotates smoothly.
3. Install connecting rod caps.
 - The cap number must be same as connecting rod number.
 - Apply engine oil to the thread and seating surface of each nut.
 - Tighten nuts to the specified torque.

Torque : 54 N·m (40 lb ft)

- After tightening the nuts, make sure that the crankshaft rotates smoothly.
4. Install rear oil seal retainer.
 - Remove oil on cylinder block and retainer fitting surface.
 - Apply sealant (TB1207B or equivalent) to retainer fitting surface as shown in illustration.
 - The oil seal retainer must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.


**Legend**

- (1) Around Bolt Holes
- (2) Around Dowel Pin

○ Apply engine oil to oil seal lip and align a dowel pin hole in the cylinder block with that in the retainer.

○ Tighten retainer fixing bolts to the specified torque.

Torque : 18 N·m (13 lb ft)


**5. Install flywheel.**

- Clean tapped holes in the crankshaft.
- Remove oil on crankshaft and flywheel fitting surface.

NOTE:

- Do not reuse the bolts.
- Do not apply oil or thread lock to the bolts.
- Tighten fixing bolts to the specified torque.

Torque : 54 N·m (40 lb ft)

**6. Install oil gallery.**

- Clean contact surface of oil gallery and main bearing cap.

Apply engine oil to oil gallery fixing bolts and tighten the bolts in two steps, in the order shown.

Torque :


1st step : 29 N·m (21 lb ft)

2nd step : 55°–65°

7. Install cylinder body side bolts and tighten bolts in order to the specified torque.

Torque : 39 N·m (29 lb ft)

NOTE: Do not apply the oil to the bolts.

**8. Install oil pump assembly.**

- Remove oil on cylinder block and oil pump mounting surface.


- Apply sealant (TB1207B or equivalent) to the oil pump mounting surface.

- The oil pump assembly must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.

6A-44 ENGINE MECHANICAL (6VD1 3.2L)


- Apply engine oil to oil seal lip.
- Install oil pump in the cylinder block and tighten fixing bolts to the specified torque.

Torque : 25 N·m (18 lb ft)



Legend

- (1) Around Bolt Holes
- (2) Around Dowel Pin



9. Install oil strainer with O-ring, tighten to the specified torque.

Torque : 25 N·m (18 lb ft)

10. Install oil pipe with O-ring, tighten fixing bolts to the specified torque.

Torque : 25 N·m (18 lb ft)

11. Install crankcase.



- Remove oil on crankcase mounting surface and dry the surface.

- Properly apply a 4.5 mm (0.7 in) wide bead of sealant (TB1207C or equivalent) to the crankcase mounting surface. The bead must be continuous.

- The crankcase must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.

- Tighten fixing bolts to the specified torque.

Torque : 10 N·m (89 lb in)



12. Install oil pan


- Remove oil on oil pan mounting surface and dry the surface.

- Properly apply a 4.5 mm (0.7 in) wide bead of sealant (TB1207C or equivalent) to the oil pan mounting surface. The bead must be continuous.


- The oil pan must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.

○Tighten fixing bolts to the specified torque.

Torque : 25 N·m (18 lb ft)



013RW003



013RW002

13. Install timing belt.

○Refer to installation procedure for Timing Belt in this manual.

14. Install engine assembly.

○Refer to installation procedure for Engine Assembly in this manual.

Rear Oil Seal


Removal

1. Remove transmission assembly.
○See Transmission section in this manual.
2. Remove flywheel.
3. Remove rear oil seal using a seal remover.

NOTE: Take care not to damage the crankshaft or oil seal retainer when removing oil seal.

Installation

1. Apply engine oil to oil seal lip and install oil seal using J-39201.




015RS017

2. Install flywheel.
○Clean tapped holes in the crankshaft.
○Remove oil on the crankshaft and flywheel mounting surface.
○Tighten fixing bolts to the specified torque.

NOTE: Do not reuse the bolts and do not apply oil or thread lock to the bolts.

Torque : 54 N·m (40 lb ft)




015RS018

3. Install transmission.

○See Transmission section in this manual.

CAUTION: When assembling the engine and transmission, confirm that dowels have been mounted in the specified positions at the engine side. Take care that dowel positions are different between the manual transmission and the automatic transmission.


Otherwise, the transmission may be damaged.



012RS009

Engine Assembly

Removal




515RX001

1. Disconnect battery ground and positive cable.
 2. Remove battery.
 3. Make alignment mark on the engine hood and hinges before removal in order to return the hood to original position exactly.
 4. Remove engine hood.
 5. Drain radiator coolant.
 6. Disconnect accelerator cable and automatic cruise control cable from throttle valve on common chamber.
 7. Disconnect air duct with air cleaner cover.
 8. Remove air cleaner assembly.
 9. Disconnect canister vacuum hose.
 10. Disconnect vacuum booster hose.
 11. Disconnect three engine harness connectors.
 12. Disconnect harness connector to transmission (left front side of engine compartment), disconnect shift on the fly harness connector from front side of front axle and remove transmission harness bracket from engine left side.
 13. Disconnect ground cable between engine and frame.
 14. Disconnect bonding cable connector on the back of right dash panel.
 15. Disconnect bonding cable terminal on the left bank.
 16. Disconnect starter harness connector from starter.
 17. Disconnect generator harness connector from generator.
 18. Disconnect coolant reserve tank hose from radiator.
 19. Remove radiator upper and lower hoses.
 20. Remove upper fan shroud.
 21. Remove cooling fan assembly four fixing nuts, then the cooling fan assembly.
 22. Move drive belt tensioner to loose side using wrench then remove drive belt.
 23. Remove power steering pump fixing bolts, then power steering pump. Place the power steering pump along with piping on the body side.
 24. Remove air conditioning compressor fixing bolts from bracket and place the compressor along with piping on the body side.
 25. Remove four O₂ sensor harness connectors (two each bank) from exhaust front pipe.
 26. Remove three exhaust pipe fixing nuts from each bank.
 27. Remove two exhaust pipe fixing nuts from each exhaust pipe, then move exhaust pipe to rear side of vehicle.
 28. Remove flywheel dust covers.
 29. Disconnect two heater hoses from engine.
 30. Disconnect fuel hose from right side of transmission.
- CAUTION: Plug fuel pipe on engine side and fuel hose from fuel tank.**
31. Remove transmission assembly. Refer to Transmission section in this manual.
 32. Support the engine by engine hoist.
 33. Remove two left side engine mount fixing bolts from engine mount on chassis side.
 34. Remove two right side engine mount fixing bolts from engine mount on chassis side.
 35. Remove engine assembly.

Installation

CAUTION: When assembling the engine and transmission, confirm that dowels have been mounted in the specified positions at the engine side. Also take care that dowel positions are different between the manual transmission and the automatic transmission.

Otherwise, the transmission may be damaged.



012RS009

1. Install engine assembly. Tighten engine mount fixing bolts to frame to the specified torque.


Torque: 41 N·m (30 lb ft)

2. Reconnect fuel hose to fuel pipe on engine.
3. Install transmission assembly. Refer to Transmission section in this manual.
4. Reconnect two heater hoses to engine.
5. Install flywheel dust covers.
6. Install exhaust pipe and temporarily tighten two (each bank) rear exhaust flange nuts then tighten three stud nuts (each bank) between exhaust manifold and exhaust pipe, finally tighten rear side nuts to the specified torque.

Torque:

Nuts: 43 N·m (32 lb ft)


Stud nuts: 67 N·m (49 lb ft)



035RW005

Legend

- (1) Exhaust Front Pipe RH
- (2) O2 Sensor



035RW016

Legend

- (1) O2 Sensor
- (2) Exhaust Front Pipe LH

7. Reconnect O2 sensor connector.
8. Install cooling fan assembly and tighten bolts/nuts to the specified torque.
Torque : 22 N·m (16 lb ft) for fan pulley and fan bracket.
Torque : 7.5 N·m (66.4 lb in) for fan and clutch assembly.
9. Install air conditioner compressor to engine and tighten to the specified torque.

6VD1

Torque : 43 N·m (32 lb ft)


10. Install power steering pump, tighten fixing bolt to the specified torque.

Torque :

M8 bolts : 22N·m (16 lb ft)

M10 bolts : 46 N·m (34 lb ft)

11. Move drive belt tensioner to loose side using wrench, then install drive belt to normal position.




850RW001

Legend

- (1) Crankshaft Pulley
- (2) Cooling Fan Pulley
- (3) Tensioner
- (4) Generator
- (5) Air Conditioner Compressor
- (6) Power Steering Oil Pump
- (7) Drive Belt

- 12. Install upper fan shroud.
- 13. Reconnect radiator upper and lower hoses.
- 14. Reconnect coolant reserve tank hose to radiator.
- 15. Reconnect generator harness connector.
- 16. Reconnect starter harness connector.
- 17. Reconnect bonding cable terminal on left bank
- 18. Reconnect bonding cable terminal on the back of right dash panel.
- 19. Reconnect ground cable between engine and chassis.
- 20. Reconnect harness connector to transmission and install transmission harness bracket on engine left side.
- 21. Reconnect three engine harness connectors.
- 22. Reconnect vacuum booster hose.
- 23. Reconnect canister vacuum hose.
- 24. Install air cleaner assembly.
- 25. Reconnect air duct.
- 26. Reconnect accelerator cable and automatic cruise control cable to throttle valve on common chamber.



035RW007

Legend


- (1) Throttle Valve Assembly
- (2) Throttle Lever
- (3) Idle Air Control Valve
- (4) Throttle Position Sensor

6A-50 ENGINE MECHANICAL (6VD1 3.2L)

27. Install engine hood to the original position.
 - Refer to installation procedure for Body section in this manual.
28. Install Accelerator pedal cable.

Cylinder Head

Cylinder Head and Associated Parts



011RW008

Legend

- | | |
|--|---|
| (1) Spark Plug | (8) Camshaft Intake |
| (2) Cylinder Head Bolt | (9) Retainer Fixing Bolt |
| (3) Camshaft Drive Gear Pulley Fixing Bolt | (10) Retainer Assembly |
| (4) Camshaft Drive Gear Pulley | (11) Tappet with Shim |
| (5) Camshaft Bracket Fixing Bolt | (12) Split Collar |
| (6) Camshaft Bracket | (13) Valve Spring and Spring Upper Seat |
| (7) Camshaft Exhaust | (14) Valve |

Disassembly


NOTE:

- During disassembly, be sure that the valve train components are kept together and identified so that they can be reinstalled in their original locations.

- Before removing the cylinder head from the engine and before disassembling the valve mechanism, perform a compression test and note the results.

1. Remove camshaft drive gear pulley fixing bolt (3), then pulley (4).

2. Remove camshaft bracket fixing bolt (5), camshaft bracket (6), then camshaft exhaust (7), and intake side (8).
3. Remove tappet with shim (11).
4. Use the J-8062 valve spring compressor and J-42898 valve spring compressor adapter to remove the split collar (12), valve spring with upper seat (13) and valve (14).



5. Remove spark plug (1).

CAUTION: Do not remove the spark plugs when the head and plugs are hot. Clean dirt and debris from spark plug recess areas before removal.

Clean

Cylinder head

Carefully remove all varnish, soot and carbon from the bare metal. Do not use a motorized wire brush on any gasket sealing surface.

Inspection and Repair

1. Cylinder head gasket and mating surfaces for leaks, corrosion and blow-by. If the gasket has failed, determine the cause.
 - Insufficient torque on head bolts
 - Improper installation
 - Loose or warped cylinder head
 - Missing dowel pins
 - Warped case surface

2. Cylinder head for cracks, especially between valve seats and in the exhaust ports.
3. Cylinder head deck for corrosion, sand particles in head and porosity.

CAUTION:

- Do not attempt to weld the cylinder head. Replace it.
 - Do not reuse cylinder head bolts.
4. Cylinder head deck, common chamber and exhaust manifold mating surfaces for flatness. These surfaces may be reconditioned by milling. If the surfaces are "out of flat" by more than specification, the surface should be ground to within specifications. Replace the head if it requires machining beyond the repairable limit.

Head surface and manifold surface

Standard: 0.05 mm (0.002 in) or less

Warpage limit: 0.2 mm (0.0079 in)


Maximum Repairable limit: 0.2 mm (0.0079 in)

Head height

Standard height : 133.2 mm (5.2441 in)

Warpage limit : 0.2 mm (0.0079 in)

Maximum Repairable limit : 133.0 mm (5.2362 in)



5. Water jacket sealing plugs seating surfaces.

011RW019


Reassembly

1. Install Spark plug and tighten all the spark plugs to specified torque.

Torque: 18 N·m (13 lb ft)

2. Tighten sub gear setting bolt.


1. Use J-42686 gear spring lever to turn sub gear to right direction until the M5 bolt aligns with the hole between camshaft driven gear and sub gear.
2. Tighten the M5 bolt to a suitable torque to prevent the sub gear from moving.



3. Install camshaft drive gear assembly and tighten three bolts to the specified torque.


Torque: 10 N·m (89 lb in)

4. Install camshaft assembly and camshaft brackets, tighten twenty bolts on one side bank to the specified torque.
 1. Apply engine oil to camshaft journal and bearing surface of camshaft bracket.
 2. Align timing mark on intake camshaft (one dot for right bank, two dots for left bank) and exhaust camshaft (one dot for right bank, two dots for left bank) to timing mark on camshaft drive gear (one dot).




Legend

- (1) Intake Camshaft Timing Gear for Right Bank
- (2) Intake Camshaft Timing Gear for Left Bank
- (3) Exhaust Camshaft Timing Gear
- (4) Discrimination Mark
- LI: Left Bank Intake
- RI: Right Bank Intake
- LE: Left Bank Exhaust
- RE: Right Bank Exhaust



Legend

- (1) Right Bank Camshaft Drive Gear
- (2) Left Bank Camshaft Drive Gear
- (3) Timing Mark on Drive Gear
- (4) Dowel Pin



014RW024


Legend

- (1) Right Bank
- (2) Left Bank

- (3) Alignment Mark on Camshaft Drive Gear
- (4) Alignment Mark on Camshaft
- (5) Alignment Mark on Retainer

3. Tighten twenty bolts in numerical order on each bank as shown in the illustration.

Torque: 10 N·m (89 lb in)




014RW031

5. Tighten bolt for camshaft drive gear assembly pulley to the specified torque.

Torque: 98 N·m (72 lb ft)

Valve Spring, Oil Controller, Valve, Valve Guide

Valve Spring, Oil Controller, Valve, Valve Guide and Associated Parts



014RW039


Legend

- | | |
|-----------------------------------|------------------------|
| (1) Camshaft Bracket Fixing Bolts | (7) Spring Upper Seat |
| (2) Camshaft Assembly Inlet | (8) Valve Spring |
| (3) Camshaft Assembly Exhaust | (9) Oil Controller |
| (4) Shim | (10) Spring Lower Seat |
| (5) Tappet | (11) Valve Guide |
| (6) Split Collar | (12) Valve |

Disassembly

1. Remove camshaft bracket fixing bolts (1).
2. Remove camshaft assembly (intake).
3. Remove camshaft assembly (Exhaust side).
4. Remove shim (4) and tappet (5).

5. Use the J-8062 valve spring compressor and J-42898 valve spring compressor adapter to remove split collar.



014RW042

6. Remove valve spring.
7. Remove valve.
8. Remove oil controller and spring lower seat.
9. Remove the valve guide using the J-42899 valve guide replacer.

Inspection and Repair


Valve Spring

CAUTION: Visually inspect the valve springs and replace them if damage or abnormal wear is evident.

1. Measure the free height of the springs. The springs must be replaced if the free height is below the specified limit.

Standard : 44.6 mm (1.756 in)


Limit : 43.6 mm (1.717 in)



014RS004

2. Measure the valve spring squareness with a steel square and replace the valve springs if the measured value exceeds the specified limit.

Limit : 2 mm (0.079 in)




014RS005

3. Using a spring tester to compress the springs to the installed height, measure the compressed spring tension, and replace the springs if the measured tension is below the specified limit.

At installed height: 35.0 mm (1.38 in)

Standard: 196 N (44 lb)

Limit: Less than 181 N (41 lb)



014RS006

Valve Guide

CAUTION: Take care not to damage the valve seat contact surface, when removing carbon adhering to the valve head. Carefully inspect the valve stem for scratches or abnormal wear. If these conditions are present, the valve and the valve guide must be replaced as a set.

1. Measure the valve stem diameter with a micrometer. If the valve stem diameter is less than the specified limit, the valve and the valve guide must be replaced as a set.

Diameter of Valve Stem

Intake


Standard : 5.977 mm–5.959 mm
(0.2353 in–0.2346 in)

Limit : 5.90 mm (0.2323 in)

Exhaust

Standard : 5.952 mm–5.970 mm
(0.2343 in–0.2350 in)

Limit : 5.90 mm (0.2323 in)



2. Measure the inside diameter of the valve guide with a micrometer. Subtract the measured outer diameter of the valve stem from the measured inner diameter of the valve guide. If the value exceeds the specified limit, the valve and the valve guide must be replaced as a set.

Inside Diameter of the Valve Guide

Inlet clearance

Standard : 0.023 mm–0.056 mm
(0.0009 in–0.0022 in)

Limit : 0.20 mm (0.00787 in)


Exhaust clearance

Standard : 0.030 mm–0.063 mm
(0.0012 in–0.0025 in)

Limit : 0.20 mm (0.00787 in)

Valve Guide Replacement


1. Using Valve guide replacer: J-42899, drive out the valve guide from the combustion chamber side.



2. Apply engine oil to the outside of the valve guide. Using valve guide replacer J-42899, drive in a new valve guide from the camshaft side, and check the valve guide height.

Valve guide upper end height: 13.0 mm (0.5118 in)

(Measured from the cylinder head upper face)



3. Check the clearance. If the clearance is less than the specified value, ream the inside diameter of valve guide. Using a sharp 6 mm reamer, ream the valve guide to obtain the specified clearance.

Valve Seat

1. Measure the protrusion of the valve stem when a new valve is installed in the cylinder head. If the protrusion of the valve stem exceeds the limit, replace the valve seat insert or the cylinder head assembly.

Protrusion of valve stem

Intake


Standard: 39.32 mm (1.5480 in)

Limit: 39.47 mm (1.5539 in)

Exhaust

Standard: 39.3 mm (1.5472 in)

Limit: 39.45 mm (1.5531 in)




014RW047

2. Measure the valve seat contact width. Make the necessary corrections if the seat contact surface is damaged or rough or if the contact width wear exceeds the limit.

Valve seat contact width

Standard: 1.1 mm (0.0433 in)

Limit: 1.7 mm (0.0669 in)




014RS011

Contact Surface Angle on Valve Seat on Valve

1. Measure contact surface angle on valve seat.
2. If the measured value exceeds the limit, replace valve, valve guide and valve seat as a set.

Valve contact surface angle: 45°




014RS012

Valve Seat Insert Correction


1. Remove the carbon from the valve seat insert surface.
2. Use a valve cutter to minimize scratches and other rough areas. This will bring the contact width back to the standard value. Remove only the scratches and rough areas. Do not cut away too much. Take care not to cut away unblemished areas of the valve seat surface.

Valve seat angle degree: 90°



014RW050


3. Apply abrasive compound to the valve seat insert surface.
4. Insert the valve into the valve guide.
5. Turn the valve while lapping it to fit the valve seat insert.
6. Check that the valve contact width is correct.
7. Check that the valve seat insert surface is in contact with the entire circumference of the valve.



014RS014

Valve Seat Insert Replacement

1. Arc weld the rod at several points. Be careful not to damage the aluminum section.
2. Allow the rod to cool for a few minutes. This will cause the valve seat to shrink.
3. Strike the rod and pull it out.



014RS015


4. Carefully clean the valve seat press-fit section on the cylinder head side.
5. Heat the press-fit section with steam or some other means to cause expansion. Cool the valve seat with dry ice or some other means.
6. Insert the press-fit section into the valve seat horizontally.

Standard fitting interference: 0.14 mm–0.09 mm (0.0055 in–0.0035 in)

7. After insertion, use a seat grinder to grind finish the seating face. Carefully note the seating angle, the contact width, and the depression.
8. Lap the valve and the seat.


Reassembly

1. Install valve guide (1) to cylinder head. Apply engine oil to the outside of the valve guide. Using valve guide replacer J-42899, drive in a new valve guide from the camshaft side.
2. Install oil controller (3) and spring lower seat (2). Using oil controller replacer J-37281, drive in a new oil controller.




014RW058

3. Install valve to valve guide. Before install valve guide apply engine oil to the outside of the valve stem.
4. Install valve spring to cylinder head. Attach the valve spring to the lower spring seat. The painted area of the valve spring should be facing downward.



014RS020

5. Install lower valve spring seat, valve spring and upper valve spring seat then put split collars on the upper spring seat, using the J-8062 valve spring compressor and J-42898 valve spring compressor adapter to install the split collars.




014RW042

6. Install tappet with shim.
7. Install camshaft assembly.
 - Refer to installation procedure for Camshaft in this manual.

Valve Clearance Adjustments

NOTE: To adjust valve clearance, apply engine oil to the cam as well as to the adjusting shim (2) with the cylinder head built on the cylinder block, give a few turns to the camshaft by means of timing pulley tightening bolt, and measure valve clearance when the nose of cam is just opposite to maximum cam lift (1) as shown in illustration below.



014RW081

Legend

- (1) Cam
- (2) Shim
- (3) Tappet

Valve Clearance Standard Value (cold)

Intake: 0.23 mm–0.33 mm
(0.0091 in–0.0130 in)

Exhaust: 0.25 mm–0.35 mm
(0.0098 in–0.0138 in)




Selection of Adjusting Shim

Shim to be selected = (Thickness of removed shim) + (Valve clearance measurement – Standard value)

Based on the above formula, the best suited shim should be selected from 41 sorts of shim (differently thick at 0.02mm (0.0008 in) intervals from 2.40mm (0.0945 in) through 3.2mm (0.1260 in) thick). Install the shim and check valve clearance.


Replacement of Shim

Let the cam push down the edge of tappet by using J-42689 valve clearance adjusting tool and push out the shim with a flat blade screw driver as shown in illustrations below.



Camshaft

Camshaft and Associated Parts



014RW040


Legend

- (1) Camshaft Bracket Fixing Bolt
- (2) Camshaft Bracket
- (3) Camshaft Assembly Intake
- (4) Camshaft Assembly Exhaust
- (5) Pulley Fixing Bolt

- (6) Camshaft Drive Gear Pulley
- (7) Retainer Fixing Bolt
- (8) Retainer
- (9) Camshaft Drive Gear
- (10) Oil Seal


Disassembly

1. Remove fixing bolt (5) for camshaft drive gear pulley using J-43041 universal holder.



014RW060

2. Remove twenty fixing bolts from inlet and exhaust camshaft bracket on one side bank, then camshaft brackets (2).



014RW027


3. Remove camshaft assembly (3), (4).
4. Remove three fixing bolts (7) from camshaft drive gear retainer (8), then camshaft drive gear assembly.

Inspection and Repair

1. Use a micrometer to measure the cam lobe height and uneven wear. Replace the camshaft if either the lobe height or the uneven wear exceeds the specified limit.

Lobe height : 44.709 mm (1.7602 in)

Uneven wear : 0.05 mm (0.0020 in)



014RW043

2. Use a micrometer to measure the diameter and the uneven wear of the camshaft journals. Replace the camshaft if the diameter or the uneven wear exceeds the specified limit.


Journal Diameter

Standard : 25.972 mm–25.993 mm

(1.0225 in–1.0233 in)

Limit : 25.8 mm (1.0157 in)

Uneven wear : 0.05 mm (0.0020 in)



014RS023


3. Place the camshaft on V-blocks.

Slowly rotate the camshaft and measure the runout with a dial indicator.

Replace the camshaft if the runout exceeds the specified limit.

Run out

Limit : 0.1 mm (0.0039 in)



014RW044


6A-64 ENGINE MECHANICAL (6VD1 3.2L)

4. Measure the camshaft journal oil clearance.

1. Measure the camshaft bracket housing inside diameter.

NOTE: Tighten camshaft bracket (2) to specified torque before measuring the camshaft bracket inside diameter.

Torque : 10 N·m (89 lb in)




2. Subtract the camshaft outside diameter from the camshaft bracket housing inside diameter.

Oil Clearance

**Standard : 0.027 mm–0.078 mm
(0.0011 in–0.0031 in)**


Limit : 0.11 mm (0.0043 in)



5. Replace the cylinder head and/or camshaft if the measured oil clearance exceeds the specified limit.

1. Carefully clean the camshaft journal, the camshaft bracket, and the cylinder head.
2. Install camshaft assembly and camshaft brackets (2), tighten twenty bolts (1) on one side bank to the specified torque.

Torque: 10 N·m (89 lb in)




3. Measure the camshaft thrust clearance with a dial indicator. Replace the camshaft and/or the cylinder head if the camshaft thrust clearance exceeds the specified limit.

Camshaft thrust Clearance

**Standard : 0.03 mm–0.08 mm
(0.0012 in.–0.0031 in.)**

Limit : 0.12 mm (0.0047 mm)




Reassembly

1. Install camshaft drive gear assembly and tighten three bolts to specified torque.

Torque: 10 N·m (89 lb in)


2. Tighten sub gear setting bolt.

1. Use J-42686 to turn sub gear to right direction until the M5 bolt hole aligns between camshaft driven gear and sub gear.
2. Tighten M5 bolt suitable torque for prevent moving the sub gear.




3. Install camshaft assembly and camshaft brackets, tighten twenty bolts on one side bank to the specified torque.

1. Apply engine oil to camshaft journal and bearing surface of camshaft bracket.
2. Align timing mark on intake camshaft (one dot for right bank, two dots for left bank) and exhaust camshaft (one dot for right bank, two dots for left bank) to timing mark on camshaft drive gear (one dot).




Legend

- (1) Intake Camshaft Timing Gear for Right Bank
- (2) Intake Camshaft Timing Gear for Left Bank
- (3) Exhaust Camshaft Timing Gear
- (4) Discerning Mark
- LI: Left Bank Intake
- RI: Right Bank Intake
- LE: Left Bank Exhaust
- RE: Right Bank Exhaust



Legend

- (1) Right Bank Camshaft Drive Gear
- (2) Left Bank Camshaft Drive Gear
- (3) Timing Mark on Drive Gear
- (4) Dowel Pin



014RW024


Legend

- (1) Right Bank
- (2) Left Bank

- (3) Alignment Mark on Camshaft Drive Gear
- (4) Alignment Mark on Camshaft
- (5) Alignment Mark on Retainer


3. Tighten twenty bolts in numerical order on one side bank as shown in the illustration.

Torque: 10 N·m (89 lb in)



014RW031


4. If the oil seal requires replacement, use the J-42985 to install the oil seal.



014RW034


5. Tighten bolt for camshaft drive gear assembly pulley to the specified torque using the J-43041 universal holder.

Torque: 98 N·m (72 lb ft)



Crankshaft

Crankshaft and Associated Parts



013RW009

Legend

- | | |
|-------------------------------|--|
| (1) Cylinder Head Assembly | (8) Piston and Connecting Rod Assembly |
| (2) Crankcase with Oil Pan | (9) Flywheel |
| (3) Oil Pipe and O-ring | (10) Rear Oil Seal Retainer and Oil Seal |
| (4) Oil Strainer and O-ring | (11) Main Bearing Cap |
| (5) Oil Pump Assembly | (12) Crankshaft |
| (6) Cylinder Block Side Bolts | (13) Main Bearing Cap Fixing Bolts |
| (7) Oil Gallery | (14) Oil Gallery Fixing Bolts |

Disassembly

1. Remove cylinder head assembly (1). Refer to "Cylinder Head" in this manual.
2. Remove crankcase with oil pan (2). Refer to "Oil Pan and Crankcase" in this manual.

CAUTION: Take care not to damage or deform the sealing flange surface of crankcase.

3. Remove oil pipe and O-ring (3).
4. Remove oil strainer and O-ring (4).
5. Remove oil pump assembly (5).
6. Remove crankcase side bolts (6).

7. Remove oil gallery (7).
8. Remove piston and connecting rod assembly (8).
Refer to "Piston, Piston Ring and Connecting Rod" in this manual.
9. Remove flywheel (9).
10. Remove rear oil seal retainer (10).
11. Remove main bearing cap (11).
12. Remove crankshaft (12).

Inspection and Repair


1. Crankshaft

Set the dial indicator as shown in the illustration and measure the crankshaft thrust clearance. If the thrust clearance exceeds the specified limit, replace the thrust bearings as a set.

Thrust Clearance

Standard : 0.06 mm–0.24 mm
(0.0024 in–0.0094 in)


Limit : 0.30 mm (0.0118 in)



015RS003

Main Bearing Clearance


1. Remove the bearing caps and measure the oil clearance.
2. Remove the main bearing cap fixing bolts in the sequence shown in the illustration.
Arrange the removed main bearing caps in the cylinder number order.
Remove the main bearings.



015RS004

3. Remove the crankshaft.
Remove the main bearings.
4. Clean the upper and lower bearings as well as the crankshaft main journal.
5. Check the bearings for damage or excessive wear.
The bearings must be replaced as a set if damage or excessive wear is discovered during inspection.
6. Set the upper bearings and the thrust washers to their original positions.
Carefully install the crankshaft.
7. Set the lower bearings to the bearing cap original position.
8. Apply plastigage to the crankshaft journal unit as shown in the illustration.

NOTE: Do not set the plastigage on the oil hole.



015RS005

6A-70 ENGINE MECHANICAL (6VD1 3.2L)

9. Install main bearing caps, oil gallery and crank case bolts in the order shown, and tighten each bolt to the specified torque.

NOTE: Do not apply engine oil to the crank case side bolts.

Main bearing cap bolts.

Torque: 39 N·m (29lb ft)

Oil gallery fixing bolts.

Torque:


1st step: 29 N·m (21 lb ft)

2nd step 55° ~ 65°

Crank case side bolts


Torque : 39 N·m (29lb ft)

NOTE: Do not allow the crankshaft to rotate.



015RS006

10. Remove the main bearing caps in the sequence shown in the illustration.




015RS004

11. Measure the plastigage width and determine the oil clearance. If the oil clearance exceeds the specified limit, replace the main bearings as a set and/or replace the crankshaft.

Standard : 0.019 mm–0.043 mm

(0.0007 in–0.0017 in)

Limit : 0.08 mm (0.0031 in)



015RS008

12. Clean the plastigage from the bearings and the crankshaft.

Remove the crankshaft and the bearings.


Crankshaft (12) Inspection

Inspect the surface of the crankshaft journal and crank pins for excessive wear and damage. Inspect the oil seal fitting surfaces for excessive wear and damage. Inspect the oil ports for obstructions.

Inspection and Repair

1. Carefully set the crankshaft on the V-blocks. Slowly rotate the crankshaft and measure the runout. If the crankshaft runout exceeds the specified limit, the crankshaft must be replaced.

Runout : 0.04 mm (0.0016 in)




015RS007

2. Measure the diameter and the uneven wear of main journal and crank pin. If the crankshaft wear exceeds the specified limit, crankshaft must be replaced.

**Main journal diameter : 63.918 mm–63.933 mm
(2.5165 in–2.5170 in)**

**Crank pin diameter : 53.922 mm–53.937 mm
(2.1229 in.–2.1235 in.)**

Uneven wear limit : 0.005 mm (0.0002 in)




015RS009

Crankshaft Bearing Selection

When installing new crankshaft bearings or replacing bearings, refer to the selection table below. Select and install the new crankshaft bearings, paying close attention to the cylinder block journal hole.


1. Diameter size mark (1) and the crankshaft journal.



015RS010


2. Diameter size mark (1).

The diameter size marks are stamped on the No.1 crankshaft balancer as shown in the illustration.



015RS011

NOTE: Take care to ensure the bearings are positioned correctly.



Legend

- (1) Number 1 and 4 main bearing upper and lower
- (2) Number 2 and 3 main bearing upper
- (3) Number 2 and 3 main bearing lower


1 Size Mark	Main Bearing Bore Diameter	Crank Shaft Main Journal Diameter	2 Size Mark	Crank Shaft Bearing Size Mark (Upper Side)	Crank Shaft Bearing Size Mark (Lower Side)	Oil Clearance (Reference)
1	68.994-69.000 (2.7163-2.7165)	63.918-63.925 (2.5165-2.5167)	2	Blue	Blue	0.030-0.049 (0.0012-0.0019)
		63.926-63.933 (2.5168-2.5170)	1	Brown	Brown	0.028-0.047 (0.0011-0.0019)
2	68.987-68.993 (2.7160-2.7163)	63.918-63.925 (2.5165-2.5167)	2			0.029-0.048 (0.0011-0.0019)
		63.926-63.933 (2.5168-2.5170)	1	Green	Green	0.027-0.046 (0.0011-0.0018)
3	68.980-68.986 (2.7157-2.7160)	63.918-63.925 (2.5165-2.5167)	2			0.028-0.047 (0.0011-0.0019)
		63.926-63.933 (2.5168-2.5170)	1	Yellow	Yellow	0.026-0.045 (0.0010-0.0018)

Reassembly

1. Crankshaft (12)


- Install the main bearings to the cylinder block and the main bearing caps.
- Be sure that they are positioned correctly.
- Apply new engine oil to the upper and lower main bearing faces.

NOTE: Do not apply engine oil to the main bearing back faces.



015RS012

- Carefully mount the crankshaft.
- Apply engine oil to the thrust washer.
- Assemble the thrust washer to the No.3 bearing journal. The oil grooves must face the crankshaft.




015RS013

2. Rear oil seal (10)

- Remove the oil from the cylinder block and the retainer mounting surface.
- Apply sealant (TB-1207B or equivalent) to the retainer mounting surface, following the pattern shown in the illustration.

The retainer must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.



015RW002

Legend


- (1) Around Bolt Holes
- (2) Around Dowel Pin

- Apply engine oil to the oil seal lip.
- Align the cylinder block dowel pin holes with the rear retainer dowel pins.
- Tighten the rear retainer fixing bolts. New bolts should be used when installing rear retainer.


Torque: 18 N·m (13 lb ft)

NOTE: Be very careful not to disengage the oil seal garter spring during installation of the rear retainer.

If the seal was removed from retainer for replacement, apply engine oil to the oil seal lip and install the oil seal using J-39201 oil seal installer.



015RW001



015RS017


3. Flywheel (9)

1. Thoroughly clean and remove the oil from the threads of crankshaft.
2. Remove the oil from the crankshaft and flywheel mounting faces.
3. Mount the flywheel on the crankshaft and then install the washer.

4. Hold the crankshaft to prevent from rotating then install the bolts in the order shown to the specified torque.


Torque: 54 N·m (40 lb ft)

NOTE: Do not reuse the bolt and do not apply oil or thread lock to the bolt.



4. Piston and connecting rod assembly (8)

- Apply engine oil to the cylinder bores, the connecting rod bearings and the crankshaft pins. Check to see that the piston ring end gaps are correctly positioned.



Legend

- (1) No.1 Compression Ring
- (2) No.2 Compression Ring
- (3) Oil Ring Side Rail Upper
- (4) Oil Ring Side Rail Lower
- (5) Piston Front Mark

- Insert the piston/connecting rod assemblies into each cylinder with the piston ring compressor. The front marks must be facing the front of the engine.

- Match the numbered caps with the numbers on the connecting rods. Align the punched marks on the connecting rods and caps.


- Apply engine oil to the threads and seating faces of the nuts.

- Tighten the nuts.

Torque: 54 N·m (40 lb ft)

After tightening the cap nuts, check to see that the crankshaft rotates smoothly.


NOTE: Do not apply engine oil to the bearing back faces.



5. Install oil gallery (7) and tighten the bolts in 2 steps, in the order shown.

1st step: 29 N·m (22 lb ft)

2nd step: 55° ~ 65°




051RS009

6. Cylinder block side bolts (6)

○Tighten all the bolts to the specified torque in the order shown.

NOTE: Do not apply engine oil to the crank case side bolts.

Torque: 39 N·m (29 lb ft)



7. Install oil pump assembly (5), refer to "Oil pump" in this manual.

8. Install oil strainer and O-ring (4).


9. Install oil pipe and O-ring (3) and tighten the bolts.

Torque: 25 N·m (18 lb ft)

10. Install crankcase with oil pan (2).

1. Completely remove all residual sealant, lubricant and moisture from the sealing surfaces. The surfaces must be perfectly dry.
2. Apply a correct width bead of sealant (TB—1207C or its equivalent) to the contact surfaces of the oil pan. There must be no gaps in the bead.
3. The crankcase assembly must be installed within 5 minutes after sealant application.
4. Tighten the bolts and nuts to the specified torque.

Torque : 10 N·m (89 lb in)


**Legend**

- (1) Portion Between Bolt Holes
- (2) Bolt Hole Portion

11. Install cylinder head assembly, refer to "Cylinder head" in this manual.

Piston and Connecting Rod

Piston, Connecting Rod and Associate Parts



015RW019

Legend

- | | |
|-----------------------------|--|
| (1) Cylinder Head Assembly | (7) Piston and Connecting Rod Assembly |
| (2) Cylinder Head Gasket | (8) Piston Ring |
| (3) Crankcase with Oil Pan | (9) Piston Pin |
| (4) Oil Pipe and O-ring | (10) Piston |
| (5) Oil Strainer and O-ring | (11) Connecting Rod |
| (6) Oil Gallery | (12) Connecting Rod Cap |

Disassembly

1. Remove cylinder head assembly (1). Refer to "Cylinder Head Removal" in this manual.
2. Remove cylinder head gasket (2).
3. Remove crankcase with oil pan (3). Refer to "Oil Pan and Crankcase" in this manual.
4. Remove oil pipe and O-ring (4).


5. Remove oil strainer and O-ring (5).

6. Remove oil gallery (6).

7. Remove connecting rod cap with connecting rod lower bearing (12).

8. Remove piston and connecting rod assembly (7).


NOTE: Before removing piston and connecting rod assembly, measure thrust clearance.



015RS031

○Remove any ridge or carbon build up from the top end of the cylinder.


9. Remove the piston rings (8) with a piston ring expander. Arrange the removed piston rings in the cylinder number order.



015RS022

10. Remove the piston pin (9) using J-24086-C piston pin service set and piston support with a press.

NOTE: Keep the parts removed from each cylinder separate. All parts must be reinstalled in their original positions. Heating the connecting rod will permit easy removal of the piston pin.



015RS023

Legend

- (1) Press Ram
- (2) Piston
- (3) Connecting Rod
- (4) Piston Pin

11. Piston (10)

12. Connecting rod (11)

Inspection and Repair

Pistons (10)

Carefully clean away all the carbon adhering to the piston head and the piston ring grooves.


NOTE: Never use a wire brush to clean the pistons. Damage will result. Visually check each piston for cracking, scoring, and other signs of excessive wear. If any of the above conditions are found, the piston must be replaced.

Piston Diameter

1. Measure the piston outside diameter with micrometer at the piston grading position and a right angle to the piston pin.

Piston grading position (from piston head)

Piston grading position : 43.0 mm (1.6929 in)



015RV014


The size mark (1) for piston outside diameter is represented as shown in Figure.

Outside Diameter

**Size Mark A : 93.360 mm–93.370 mm
(3.6756 in–3.6760 in)**


**Size Mark B : 93.371 mm–93.380 mm
(3.6760 in–3.6764 in)**

**Size Mark C : 93.381 mm–93.390 mm
(3.6764 in–3.6768 in)**



015RS025

Measure the cylinder bore inside diameter (refer to "Cylinder Block" in this manual).



012RS002

Piston Rings (8)

Any worn or damaged part discovered during engine overhaul must be replaced with a new one.

1. Ring end gap measurement

- Insert the piston ring into the bore.
- Push the ring by the piston, at a right angle to the wall, into the point at which the cylinder bore diameter is the smallest.
- Measure the ring end gap.

Compression Ring

1st ring

**Standard: 0.300 mm–0.400 mm
(0.0118 in–0.0157 in)**

Limit: 1.0 mm (0.0394 in)

2nd ring


**Standard: 0.450 mm–0.600 mm
(0.0177 in–0.0236 in)**

Limit: 1.2 mm (0.0472 in)

Oil ring

**Standard: 0.150 mm–0.450 mm
(0.0059 in–0.0177 in)**

Limit: 1.05 mm (0.0413 in)




015RS026

○Positioning mark (1) is painted as shown in the illustration.

Marked T : No.1 Compression ring

Marked T2 : No.2 Compression ring




015RS027

2. Measure the clearance between the piston ring groove and the piston ring with a feeler gauge. If the piston ring groove / piston ring clearance exceeds the specified limit, the piston must be replaced.

Compression Ring Clearance

**Standard : 0.025 mm–0.065 mm
(0.0006 in.–0.0015 in)**

Limit : 0.1mm (0.0059 in)




015RS028

Piston Pin (9)

NOTE: Do not reuse the old piston pin.

1. Use a micrometer to measure the new piston pin outside diameter in both directions at three different positions.
2. Measure the inside diameter of the connecting rod small end. If the fitting interference between the small end and pin does not conform to the specified value, the connecting rod must be replaced.

Standard : 0.023 mm–0.038 mm (0.0009 in–0.0015 in)



015RS029

3. Insert the new pin into the piston and rotate it. If the pin rotates smoothly with no backlash, the clearance is normal. If there is backlash or roughness, measure the clearance. If the clearance exceeds the specified limit, the piston must be replaced.

Clearance

Standard : 0.010 mm–0.017 mm
(0.0004 in.–0.0007 in)

Limit : 0.040 mm (0.0016 in)

Connecting Rods (11)


1. Check the connecting rod alignment If either the bend or the twist exceeds the specified limit, the connecting rod must be replaced.

Bend per 100 mm (3.937 in)

Limit: 0.15 (0.0059)

Twist per 100 mm (3.937 in)

Limit: 0.20 (0.0078)




015RS030

2. Measure the connecting rod thrust clearance. Use a feeler gauge to measure the thrust clearance at the large end of the connecting rod. If the clearance exceeds the specified limit, the connecting rod must be replaced.

Standard : 0.16 mm–0.35 mm
(0.0063 in.–0.0138 in)

Limit : 0.40 mm (0.0157 in)




015RS031

3. Measure the oil clearance between the connecting rod and the crankshaft.

1. Remove the connecting rod cap nuts and the rod caps (12).
Arrange the removed rod caps in the cylinder number order.

2. Clean the rod bearings and the crankshaft pins.

3. Carefully check the rod bearings. If even one bearing is found to be damaged or badly worn, the entire bearing assembly must be replaced as a set. Reinstall the bearings in their original positions. Apply plastigage to the crank pin.



015RS032

4. Reinstall the rod caps (12) to their original positions.

Tighten the rod cap nuts.


Torque: 54 N·m (40 lb ft)

NOTE: Do not allow the crankshaft to rotate.

5. Remove the rod caps.
6. Measure the width of the plastigage and determine the oil clearance. If the oil clearance exceeds the limit, replace the rod bearing as a set.

**Standard : 0.019 mm–0.043 mm
(0.0007 in–0.0017 in)**

Limit : 0.08 mm (0.0031 in)




015RS008

7. Clean the plastigage from the bearings and the crankshaft pins.

Con-rod Bearing Selection

Select and install the new connecting rod bearings, paying close attention to the connecting rod big end diameter size mark (1).

NOTE: Take care not to confuse the alignment mark (2) and the size mark (1) during the installation procedure.



015RS034

1 Size Mark	Big end Bore Diameter	Crankshaft Pin Diameter	Connecting Rod Bearing Thickness (Reference)	Color of Size Mark	Oil Clearance (Reference)
A	56.994-57.000 (2.2439-2.2441)	53.922-53.937 (2.1229-2.1235)	1.512-1.516 (0.0595-0.0597)	Yellow	0.025-0.054 (0.0010-0.0021)
B	56.988-56.994 (2.2436-2.2439)		1.508-1.512 (0.0594-0.0595)	Green	0.027-0.056 (0.0011-0.0022)
C	56.982-56.988 (2.2434-2.2436)		1.504-1.508 (0.0592-0.0594)	Pink	0.029-0.058 (0.0011-0.0023)


Reassembly

1. Install connecting rod
2. Install piston
3. Install piston pin

- Apply a thin coat of engine oil to the piston pin. Try to insert the piston pin into the piston pin hole with normal finger pressure.

NOTE: When changing piston / connecting rod combinations, do not change the piston / piston pin combination and do not reuse the old piston pin.

- Attach the piston to the connecting rod with the piston front mark and the connecting rod front mark on the same side.




015RS036

6A-82 ENGINE MECHANICAL (6VD1 3.2L)

○With J-24086-C Piston pin service set and a press, press fit the piston pin.

NOTE: Heat the connecting rod small end to a suitable temperature to ensure smooth installation.




Legend

- (1) Press Ram
- (2) Piston
- (3) Connecting Rod
- (4) Piston Pin

4. Install piston ring with the piston ring expander.
The compression ring must be set with the T mark (1) facing up.

Marked T : No.1 Compression ring

Marked T2 : No.2 Compression ring



○Install piston rings in the following sequence.


1. Oil ring
 1. Expander ring
 2. Upper side rail
 3. Lower side rail
2. 2nd compression ring
3. 1st compression ring

○The compression rings must be set with the T or T2 mark facing up.

Marked T : No.1 Compression ring

Marked T2 : No.2 Compression ring

○After installation, apply engine oil to the entire circumference of the piston rings. Check to see that all the rings rotate smoothly.



5. Install piston and connecting rod assembly.

○Insert the bearings into the connecting rods and caps. Apply new engine oil to the bearing faces and nuts.

○Tighten the connecting rod cap nuts


Torque : 54 N-m (40 lb ft)

NOTE: Do not apply engine oil to the bearing back faces.

6. Oil gallery, refer to "Crankshaft and main bearing" in this manual.
7. Oil strainer and O-ring.
8. Oil pipe and O-ring.
9. Install crankcase with oil pan, refer to "Oil pan and Crankcase" in this manual.
10. Install cylinder head gasket.
11. Install Cylinder head assembly.
 - Refer to "Cylinder head" in this manual.

Cylinder Block

Cylinder Block and Associated Parts



012RW010

Legend

- | | |
|-------------------------------|--|
| (1) Cylinder Head Assembly | (8) Oil Gallery |
| (2) Cylinder Head Gasket | (9) Piston and Connecting Rod Assembly |
| (3) Crankcase with Oil Pan | (10) Flywheel |
| (4) Oil Pipe and O-ring | (11) Rear Oil Seal Retainer Assembly |
| (5) Oil Strainer and O-ring | (12) Main Bearing Cap |
| (6) Oil Pump Assembly | (13) Crankshaft |
| (7) Cylinder Block Side Bolts | (14) Cylinder Block |

Disassembly

1. Remove cylinder head assembly.
2. Remove cylinder head gasket.
3. Remove crankcase with oil pan.
4. Remove oil pipe and O-ring.
5. Remove oil strainer and O-ring.
6. Remove oil pump assembly.
7. Remove crankcase side bolts.
8. Remove oil gallery.
9. Remove piston and connecting rod assembly.
10. Remove flywheel.

11. Remove rear oil seal retainer assembly.
12. Remove main bearing cap.
13. Remove crankshaft.
14. Remove cylinder block.

Inspection and Repair

1. Remove the cylinder head gasket and any other material adhering to the upper surface of the cylinder block. Be very careful not to allow any material to accidentally drop into the cylinder block. Be very careful not to scratch the cylinder block.
2. Carefully remove the oil pump, rear oil seal retainer, and crankcase assembly installation surface seal.
3. Wipe the cylinder block clean.
4. Visually inspect the cylinder block. If necessary, use a flaw detector to perform a dye penetrate and hydraulic (or air pressure) test. If cracking or other damage is discovered, the cylinder block must either be repaired or replaced.

Flatness

1. Using a straight-edge and feeler gauge, check that the upper surface of the cylinder block is not warped.


CAUTION: Be very careful not to allow any material to accidentally drop into the upper surface of the cylinder block. Be very careful not to scratch the upper surface of the cylinder block.

2. The cylinder block must be reground or replaced if the warpage exceeds the limit.

Warpage

Limit : 0.15 mm (0.0059 in)

Maximum repairable limit: 0.15 mm (0.0059 in)



Cylinder Bore

Use a cylinder gauge to measure the cylinder bore diameter in both the axial and thrust directions. Each measurement should be made at six points.

CAUTION: Be very careful not to allow any material to accidentally drop into the upper surface of the cylinder block. Be very careful not to scratch the upper surface of the cylinder block.

Cylinder Bore Inside Diameter

Limit : 93.530 (3.6823)


If the measurement exceed the specified limit, the cylinder block must be replaced.

Diameter

**Grade A : 93.400 mm–93.410 mm
(3.6772 in–3.6776 in)**


**Grade B : 93.411 mm–93.420 mm
(3.6776 in–3.6779 in)**

**Grade C : 93.421 mm–93.430 mm
(3.6780 in–3.6783 in)**



NOTE: For information on piston diameter, please refer to the section "Inspection of the Piston and Connecting Rod Assembly" in this manual.

- The "Grade" mark (1) is stamped at the position illustrated.




012RS006

Reassembly

1. Install cylinder block.
2. Install crankshaft.
 - Install the main bearings to the cylinder block and the main bearing caps.
 - Be sure that they are positioned correctly.
 - Apply new engine oil to the upper and lower main bearing faces.

NOTE: Do not apply engine oil to the bearing back faces.




015RS012

Legend

- (1) Number 1 and 4 main bearing upper and lower.
- (2) Number 2 and 3 main bearing upper.
- (3) Number 2 and 3 main bearing lower.


- Carefully mount the crankshaft.
- Apply engine oil to the thrust washer.
- Assemble the thrust washer to the No. 3 bearing journal. The oil grooves must face the crankshaft.



015RS013

3. Install rear oil seal retainer.

- Remove oil on cylinder block and retainer fitting surface.
- Apply sealant (TB1207B or equivalent) to retainer fitting surface as shown in illustration.
- The oil seal retainer must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.



015RW002

Legend


- (1) Around Bolt Holes
- (2) Around Dowel Pin

6A-86 ENGINE MECHANICAL (6VD1 3.2L)

○Apply engine oil to oil seal lip and align a dowel pin hole in the cylinder block with that in the retainer.

○Tighten retainer fixing bolts to the specified torque.

Torque: 25 N·m (18.4 lb ft)




015RW001

4. Install flywheel

1. Thoroughly clean and remove the oil from the threads of crankshaft.
2. Remove the oil from the crankshaft and flywheel mounting faces.
3. Mount the flywheel on the crankshaft and then install the washer.
4. Holding the crankshaft stationary, tighten the flywheel bolts in the order shown.

Torque: 54 N·m (40 lb ft)

NOTE: Do not reuse the bolts and do not apply oil or thread lock to the bolts.




015RS018

5. Install piston and connecting rod assembly.

○Apply engine oil to the cylinder bores, the connecting rod bearings and the crankshaft pins.

NOTE: Do not apply engine oil to the bearing back faces.

○Check to see that the piston ring end gaps are correctly positioned.




015RS019

Legend

- (1) No.1 Compression Ring
- (2) No.2 Compression Ring
- (3) Oil Ring Side Rail Upper
- (4) Oil Ring Side Rail Lower
- (5) Piston Front Mark

○Insert the piston/connecting rod assemblies into each cylinder with the piston ring compressor.

○The front marks (1) must be facing the front of the engine.




015RS020

6. Install oil gallery and tighten the bolts in 2 steps in the order shown.

1st step : 29 N·m (22 lb ft)


2nd step : 55° ~ 65°



012RS007

7. Install cylinder block side bolts (1) and tighten crankcase bolts in sequence shown in the illustration.

Torque : 39 N·m (29 lb ft)



012RW005

8. Install oil pump assembly. Refer to "Oil Pump" in this manual.


9. Install oil strainer and O-ring.

10. Install oil pipe and O-ring.

11. Install crankcase with oil pan.

1. Completely remove all residual sealant, lubricant and moisture from the sealing surfaces. The surfaces must be perfectly dry.
2. Apply a correct width bead of sealant (TB- 1207C or its equivalent) to the contact surfaces of the crankcase. There must be no gaps in the bead.
3. The oil pan must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.
4. Tighten the bolts and nuts to the specified torque.

Torque : 10 N·m (89 lb in)



013RW010

Legend

- (1) Portion Between Both Holes
- (2) Bolt Hole Portions

12. Install cylinder head gasket.

13. Install cylinder head assembly. Refer to "Cylinder Head" in this manual.


Main Data and Specification

General Specification

Item	Specifications
	6VD1
Engine type, number of cylinders and arrangement	Water cooled, four cycle V6
Form of combustion chamber	Pent-roof type
Valve mechanism	4-Cams, 4-Valves, DOHC Gear & Belt Drive
Cylinder liner type	Casted in cylinder drive
Total piston displacement	3165 cc
Cylinder bore x stroke	93.4mm x 77mm (3.677 in x 3.031 in)
Compression ratio	9.1
Compression pressure at 300rpm	1.37 MPa (14.0 Kg/cm ²)
Engine idling speed rpm	Non adjustable (750)
Valve clearance	Intake: 0.28 mm (0.11 in)
	Exhaust: 0.30mm (0.12in)
Oil capacity	5.3 liters
Ignition timing	Non adjustable (16° BTDC at idle rpm)
Spark plug	PK16PR11, RC10PYP4, K16PR-P11
Plug gap	1.0 mm–1.1 mm(0.0394 in – 0.0433 in)


Torque Specifications

Ignition coil, Spark plug, Crankshaft angle sensor and Under cover




E06RW001

Cylinder head cover, Cylinder head, Camshaft bracket, Common chamber, EGR valve and EGR pipe




E06RW012

Crankshaft main bearing, Flywheel, Crankcase, Oil pan, Timing belt tensioner, Timing pulley, timing belt cover, Oil pump, Oil gallery, Oil strainer and water pump




E06RW002

Connecting rod and Water pump



E06RW011

Engine mount



E06RW028

Special Tool


















ILLUSTRATION	TOOL NO. TOOL NAME	ILLUSTRATION	TOOL NO. TOOL NAME
 901RT033	J-21687-02 Remover; tie rod end	 901RW171	J-42985 Installer; Camshaft oil seal
 901RT034	J-36390 Wrench; Oil filter	 901RT040	J-39206 Installer; Pilot bearing
 901RW106	J-8062 Compressor; Valve spring (1) J-42898 Adapter; Compressor, Valve spring (2)	 901RT041	J-8614-01 Holder; Crankshaft
 901RT036	J-37281 Remover; Oil controller	 901RT042	J-37228 Seal cutter
 901RT037	J-38537 Installer; Oil controller	 901RT043	J-39201 Installer; Real oil seal
 901RT038	J-29107 Universal pitman arm puller	 901RT044	J-39202 Installer; Oil pump oil seal

ILLUSTRATION	TOOL NO. TOOL NAME
 901RTO46	J-24239-1 Cylinder head bolt wrench
 901RW182	J-42899 Replacer; Valve guide (1,2) J-42687 Installer; Valve guide (1) J-37985-1 Remover; Valve guide (2)
 901RW109	J-42689 Adjusting Tool; Valve clearance
 901RW110	J-42686 Lever; Gear spring
 901RW115	J-43041 Holder; Universal

RODEO

ENGINE

ENGINE COOLING (6VD1 3.2L)

CONTENTS


Service Precaution	6B-1	Installation	6B-7
General Description	6B-2	Radiator	6B-8
Diagnosis	6B-4	Radiator and Associated Parts	6B-8
Draining and Refilling Cooling System	6B-5	Removal	6B-8
Water Pump	6B-6	Inspection	6B-9
Water Pump and Associated Parts	6B-6	Installation	6B-10
Removal	6B-6	Drive Belt and Cooling Fan	6B-11
Inspection	6B-6	Drive Belt and Associated Parts	6B-11
Installation	6B-6	Inspection	6B-11
Thermostat	6B-7	Installation	6B-11
Thermostat and Associated Parts	6B-7	Main Data and Specifications	6B-12
Removal	6B-7	Special Tool	6B-13
Inspection	6B-7		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



030RW001


Legend

- | | |
|--------------------|---------------------|
| (1) Water Pump | (7) Cylinder Head |
| (2) Thermostat | (8) Right Bank |
| (3) Radiator | (9) Throttle Body |
| (4) Reserve Tank | (10) Cylinder Block |
| (5) Cooling Fan | (11) Cylinder Head |
| (6) Cylinder Block | (12) Left Bank |
| | (13) Heater |

The cooling system is a pressurized Engine Coolant (EC) forced circulation type which consists of a water pump, thermostat cooling fan, radiator and other components. The automatic transmission fluid is cooled by the EC in radiator.

Water Pump


The EC pump is a centrifugal impeller type and is driven by a timing belt.



030RS001

Thermostat


The thermostat is a wax pellet type with a air hole(1) and is installed in the thermostat housing.



031RW002

Radiator

The radiator is a tube type with corrugated fins. In order to raise the boiling point of the coolant, the radiator is fitted with a cap in which the valve is operated at 88.2 ~ 117.6 kPa (12.8 ~ 17.0 psi) pressure. (No oil cooler provided for M/T)



110RW023

Antifreeze Solution

- Relation between the mixing ratio and freezing temperature of the EC varies with the ratio of anti-freeze solution in water. Proper mixing ratio can be determined by referring to the chart. Supplemental inhibitors or additives claiming to increase cooling capability that have not been specifically approved by Isuzu are not recommended for addition to the cooling system.

○ Calculating mixing ratio


Mixing ratio

$$= \frac{\text{Antifreeze solution (Lit/gal.)}}{\text{Antifreeze solution (Lit/gal.)} + \text{Water (Lit/gal.)}}$$

F06RW005

NOTE: Antifreeze solution + Water = Total cooling system capacity.

- Total Cooling System Capacity
- M/T 11.1Lit (2.93Us gal)
- A/T 10.0Lit (2.64Us gal)




B06RW002

6B-4 ENGINE COOLING (6VD1 3.2L)

○ Mixing ratio

Check the specific gravity of engine coolant in the cooling system temperature ranges from 0°C to 50°C using a suction type hydrometer, then determine the density of the engine coolant by referring to the table.



Diagnosis


Engine Cooling Trouble

Condition	Possible cause	Correction
Engine overheating	Low Engine Coolant level	Replenish
	Incorrect fan installed	Replace
	Thermo meter unit faulty	Replace
	Faulty thermostat	Replace
	Faulty Engine Coolant temperature sensor	Repair or replace
	Clogged radiator	Clean or replace
	Faulty radiator cap	Replace
	Low engine oil level or use of improper engine oil	Replenish or change oil
	Clogged exhaust system	Clean exhaust system or replace faulty parts
	Faulty Throttle Position sensor	Replace throttle valve assembly
	Open or shorted Throttle Position sensor circuit	Repair or replace
	Damaged cylinder head gasket	Replace
Engine overcooling	Faulty thermostat	Replace
Engine slow to warm-up	Faulty thermostat	Replace
	Thermo unit faulty	Replace

Draining and Refilling Cooling System

Before draining the cooling system, inspect the system and perform any necessary service to ensure that it is clean, does not leak and is in proper working order. The engine coolant (EC) level should be between the "MIN" and "MAX" lines of reserve tank when the engine is cold. If low, check for leakage and add EC up to the "MAX" line. There should not be any excessive deposit of rust or scales around the radiator cap or radiator filler hole, and the EC should also be free from oil. Replace the EC if excessively dirty.

1. Completely drain the cooling system by opening the drain plug (2) at the bottom of the radiator.



2. Remove the radiator cap.

WARNING: TO AVOID THE DANGER OF BEING BURNED, DO NOT REMOVE THE CAP WHILE THE ENGINE AND RADIATOR ARE STILL HOT. SCALDING FLUID AND STEAM CAN BE BLOWN OUT UNDER PRESSURE.

3. Disconnect all hoses from the EC reserve tank.

Scrub and clean the inside of the reserve tank with soap and water. Flush it well with clean water, then drain it. Install the reserve tank and hoses.

4. Refill the cooling system with the EC using a solution that is at least 50 percent antifreeze but no more than 70 percent antifreeze.

5. Fill the radiator to the base of the filler neck.

Fill the EC reserve tank to "MAX" line when the engine is cold.

6. Block the drive wheels and firmly apply the parking brake. Shift an automatic transmission to "P" (Park) or a manual transmission to neutral.

7. Remove the radiator cap. Start the engine and warm it up at 2,500 ~ 3,000 rpm for about 30 minutes.

8. When the air comes out from the radiator filler neck and the EC level has gone down, replenish with the EC. Repeat this procedure until the EC level does not go down. Then stop the engine and install the radiator cap. Let the engine cool down.

9. After the engine has cooled, replenish with EC up to the "MAX" line of the reserve tank.


10. Start the engine. With the engine running at 3,000 rpm, make sure there is no running water sound from the heater core (behind the center console).

11. If the running water sound is heard, repeat steps 8 to 10.

110RW002

Water Pump

Water Pump and Associated Parts



030RS002

Legend

- | | |
|-----------------|-------------------------|
| (1) Timing Belt | (3) Water Pump Assembly |
| (2) Idle Pulley | (4) Gasket |

Removal

1. Disconnect battery ground cable.
2. Drain coolant.
3. Radiator hose (on inlet pipe side).
4. Remove timing belt. Refer to "Timing Belt" in this manual.
5. Remove Idle pulley.
6. Remove water pump assembly.
7. Remove gasket.

Inspection

Make necessary repair and parts replacement if extreme wear or damage is found during inspection. Should any of the following problems occur, the entire water pump assembly must be replaced.

- ☐ Crack in the water pump body
- ☐ EC leakage from the seal unit
- ☐ Play or abnormal noise in the bearing
- ☐ Cracks or corrosion in the impeller


Installation

1. Install gasket, clean the mating surface of gasket before installation.
2. Install water pump assembly and tighten bolts to the specified torque.

Torque: 25 N·m (18 lb ft)

- ☐ Tightening order
- The tightening order are in the illustrate.

NOTE: To prevent the oil leakage, apply the LOCTITE 262 or an equivalent, to the arrow marked fixing bolt thread.



030RW008

3. Idle pulley

- ☐ Install idle pulley and tighten bolt to the specified torque.

Torque: 52 N·m (38 lb ft)


4. Timing belt

- ☐ Install timing belt. Refer to timing belt installation step in "Timing Belt" in this manual.

5. Connect radiator inlet hose and replenish EC.
6. Connect battery ground cable.

Thermostat

Thermostat and Associated Parts



Legend


- (1) Thermostat Housing
- (2) Thermostat
- (3) Outlet Pipe

Removal

1. Disconnect battery ground cable.
2. Drain engine coolant from the radiator and engine.
3. Disconnect radiator hose from the inlet pipe.
4. Remove thermostat housing.
5. Remove thermostat(2).

Inspection

Suspend the thermostat in a water-filled container using thin wire. Place a thermometer next to the thermostat. Do not directly heat the thermostat. Gradually increase the water temperature. Stir the water so that the entire water is same temperature.



Confirm the temperature when the valve first begins to open.

**Valve opening temperature 74.5C ~ 78.5°C
(166.1°F ~ 173.3°F)**

Confirm the temperature when the valve is fully opened.

**Valve full open temperature and lift More than
8.5mm (0.33 in) at 90°C (194°F)**

Make necessary repair and parts replacement if extreme wear or damage is found during inspection.

Installation


1. Install thermostat into the outlet pipe(4) making sure that the air hole is in the up position.
2. Install thermostat housing and tighten bolts to the specified torque.

Torque: 25 N·m (18 lb ft)

3. Installation rubber hose.
4. Replenish engine coolant (EC).
5. Start engine and check for EC leakage.

Radiator

Radiator and Associated Parts




110RW010

Legend


- | | |
|--|-----------------------|
| (1) Oil Cooler Hose For Automatic Transmission | (4) Reserve Tank Hose |
| (2) Radiator Hose | (5) Radiator Assembly |
| (3) Fan Guide, Lower | (6) Reserve Tank |

Removal

1. Disconnect battery ground cable.
2. Loosen a drain plug(2) to drain EC.
3. Disconnect oil cooler hose(1) on automatic transmission (A/T).
4. Disconnect radiator inlet hose and outlet hose from the engine.
5. Remove fan guide(1), clips(3) on both sides and the bottom lock, then remove fan guide lower(3) with fan shroud(4).




110RW002



110RW001

6. Disconnect the reserve tank hose(4) from radiator.



7. Lift up and remove the radiator assembly with hose, taking care not to damage the radiator core with a fan blade.

8. Remove rubber cushions on both sides at the bottom.

Inspection

Radiator Cap

Measure the valve opening pressure of the pressurizing valve with a radiator filler cap tester.

Replace the cap if the valve opening pressure is outside the standard range.


Valve opening pressure kPa (psi) 93.3 ~ 122.7 (13.5 ~17.8)

Cap tester: J-24460-01

Adapter: J-33984-A

Check the condition of the vacuum valve in the center of the valve seat side of the cap. If considerable rust or dirt is found, or if the valve seat cannot be moved by hand, clean or replace the cap.

Valve opening vacuum kPa (psi) 0 ~ 6.9 (0 ~ 1.0)



Radiator Core

1. A bent fin may result in reduced ventilation and overheating may occur. All bent fins must be straightened. Pay close attention to the base of the fin when it is being straightened.

2. Remove all dust, bugs and other foreign material.

Flushing the Radiator

Thoroughly wash the inside of the radiator and the engine coolant passages with cold water and mild detergent. Remove all signs of scale and rust.

Cooling System Leakage Check


Use a radiator cap tester to force air into the radiator through the filler neck at the specified pressure of 196 kPa (28.5 psi) with a cap tester:

- ☐ Leakage from the radiator
- ☐ Leakage from the coolant pump
- ☐ Leakage from the water hoses
- ☐ Check the rubber hoses for swelling.

6B-10 ENGINE COOLING (6VD1 3.2L)


Cap tester: J-24460-01

Adapter: J-33984-A



Installation

1. Install rubber cushions on both sides of radiator bottom.
2. Install radiator assembly with hose, taking care not to damage the radiator core with a fan blade.
3. Connect reserve tank hose (4).
4. Install lower fan guide (3).
5. Connect radiator inlet hose and outlet hose to the engine.
6. Connect oil cooler hose (1) to automatic transmission.



7. Connect battery ground cable.

8. Pour engine coolant up to filler neck of radiator, and up to MAX mark of reserve tank.




Important operation (in case of 100% engine coolant change) procedure for filling with engine coolant.

- Remove radiator cap.
- Fill with engine coolant (EC) to the radiator filler neck.
- Fill with EC to the "MAX" line on the reservoir.
- Start the engine with the radiator cap removed and bring to operating temperature by running engine at 2,500 ~ 3,000 rpm for 30 minutes.
- By EC temperature gauge reading make sure that the thermostat is open.
- If air bubbles come up to the radiator filler neck, replenish with EC repeat until the EC level does not drop any further. Install the radiator cap and stop the engine.
- Replenish EC to the "MAX" line on the reservoir and leave as it is until the engine gets cool.
- After the engine gets cool, start the engine and make sure there is no water running noise heard from the heater core while the engine runs at 3,000 rpm.
- Should water running noise be heard, repeat the same procedure from the beginning.

Drive Belt and Cooling Fan

Drive Belt and Associated Parts



015RW005

Legend

- | | |
|-------------------------|---------------------------------------|
| (1) Crankshaft Pulley | (4) Water Pump and Cooling Fan Pulley |
| (2) Generator | (5) Idle Pulley |
| (3) Power Steering Pump | (6) Tension Pulley |
| | (7) Drive Belt |

The drive belt adjustment is not required as automatic drive belt tensioner is equipped.

Inspection

Check drive belt for wear or damage, and replace with a new one as necessary.

Installation

Install cooling fan assembly and tighten bolts/nuts to the specified torque.

Torque : 22 N·m (16 lb ft) for fan pulley and fan bracket.

Torque : 7.5 N·m (66.4 lb in) for fan and clutch assembly.

NOTE: Fan belts for 6VD1 Gasoline Engine mounted on 98MY Rodeo(UE) have been brought into one. As a result, the rotating direction of a fan belt is opposite to the direction of cooling fan for 93 to 97MY 6VD1 with no interchangeability.

Therefore, incorrect installation of a fan may cause the air for cooling to flow in the opposite direction, this resulting in the poor performance of the air-conditioner and a rise temperature in engine cooling water.


6B-12 ENGINE COOLING (6VD1 3.2L)

Main Data and Specifications

General Specifications



	M/T	A/T
Cooling system	Engine coolant forced circulation	
Radiator	Tube type corrugated (2 tube in row)	
Heat radiation capacity	70,000 kcal/h	77,800 kcal/h
Heat radiation area	9.74m ² (104.8ft ²)	11.74m ² (126.4ft ²)
Radiator front area	0.263m ² (2.83ft ²)	
Radiator dry weight	42N (9.4lb)	45N (10.1lb)
Radiator cap valve opening pressure	93.3 ~ 122.7kpa (13.5 ~ 17.8psi)	
Engine coolant capacity	2.5lit (0.6 US gal)	2.4lit (0.6 US gal)
Engine coolant pump	Centrifugal impeller type	
Delivery	300 (317) or more	
Pump speed	5000 ± 50 rpm	
Thermostat	Wax pellet type with air hole	
Valve opening temperature	74.5 ~ 78.5°C (166.1 ~ 173.3°F)	
Engine coolant total capacity	11.1lit (2.93 US gal)	10.0lit (2.64 US gal)

Torque Specifications



E06RW004

Special Tool

ILLUSTRATION	TOOL NO. TOOL NAME
 901RW072	J-24460-01 Tester; radiator cap
 901RW073	J-33984-A Adapter; radiator cap

RODEO

ENGINE

ENGINE FUEL

CONTENTS


Service Precaution	6C-1	Cautions During Work	6C-7
General Description	6C-2	Removal	6C-7
Fuel Metering	6C-3	Reuse of Quick-Connector	6C-9
Fuel Filter	6C-4	Assembling Advice	6C-9
Removal	6C-4	Fuel Pump Relay	6C-10
Inspection	6C-4	General Description	6C-10
Installation	6C-4	Fuel Tank	6C-10
Inspection	6C-5	Fuel Tank and Associated Parts	6C-10
In-Tank Fuel Filter	6C-5	Removal	6C-11
Fuel Pump Flow Test	6C-5	Installation	6C-11
Fuel Pump	6C-6	Fuel Gauge Unit	6C-11
Fuel Pump and Associated Parts	6C-6	Removal and Installation	6C-11
Removal	6C-6	Fuel Filler Cap	6C-12
Installation	6C-6	General Description	6C-12
Fuel Tube / Quick - Connector Fittings	6C-7	Inspection	6C-12
Precautions	6C-7	Main Data and Specifications	6C-13

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



140RW066

Legend

- | | |
|-----------------------------------|----------------------------------|
| (1) Fuel Filler Cap | (8) Fuel Rail Left |
| (2) Fuel Tank | (9) Left Bank |
| (3) Rollover Valve | (10) Fuel Pressure Control Valve |
| (4) Fuel Pump and Sender Assembly | (11) Common Chamber |
| (5) Fuel Filter | (12) Duty Solenoid Valve |
| (6) Fuel Rail Right | (13) Throttle Valve |
| (7) Right Bank | (14) Canister |
| | (15) Evapo Pipe |

When working on the fuel system, there are several things to keep in mind:

- Any time the fuel system is being worked on, disconnect the negative battery cable except for those tests where battery voltage is required.
- Always keep a dry chemical (Class B) fire extinguisher near the work area.
- Replace all pipes with the same pipe and fittings that were removed.
- Clean and inspect "O" rings. Replace if required.
- Always relieve the line pressure before servicing any fuel system components.
- Do not attempt repairs on the fuel system until you have read the instructions and checked the pictures relating to that repair.
- Adhere to all Notices and Cautions.

All gasoline engines are designed to use only unleaded gasoline. Unleaded gasoline must be used for proper emission control system operation.

Its use will also minimize spark plug fouling and extend engine oil life. Using leaded gasoline can damage the emission control system and could result in loss of emission warranty coverage.

All cars are equipped with an Evaporative Emission Control System. The purpose of the system is to minimize the escape of fuel vapors to the atmosphere.

Fuel Metering

The Powertrain Control Module (PCM) is in complete control of this fuel delivery system during normal driving conditions.

The intake manifold function, like that of a diesel, is used only to let air into the engine. The fuel is injected by separate injectors that are mounted over the intake manifold.

The Manifold Absolute Pressure (MAP) sensor measures the changes in the intake manifold pressure which result from engine load and speed changes, which the MAP sensor converts to a voltage output.

This sensor generates the voltage to change corresponding to the flow of the air drawn into the engine. The changing voltage is transformed into an electric signal and provided to the PCM.

With receipt of the signals sent from the MAP sensor, Intake Air Temperature sensor and others, the PCM determines an appropriate fuel injection pulse width feeding such information to the fuel injector valves to effect an appropriate air/fuel ratio.

The Multiport Fuel Injection system utilizes an injection system where the injectors turn on at every crankshaft revolution. The PCM controls the injector on time so that the correct amount of fuel is metered depending on driving conditions.

Two interchangeable "O" rings are used on the injector that must be replaced when the injectors are removed.

The fuel rail is attached to the top of the intake manifold and supplies fuel to all the injectors.

Fuel is recirculated through the rail continually while the engine is running. This removes air and vapors from the fuel as well as keeping the fuel cool during hot weather operation.


The fuel pressure control valve that is mounted on the fuel rail maintains a pressure differential across the injectors under all operating conditions. It is accomplished by controlling the amount of fuel that is recirculated back to the fuel tank based on engine demand.

See Section "Driveability and Emission" for more information and diagnosis.

Fuel Filter

Removal


CAUTION: When repair to the fuel system has been completed, start engine and check the fuel system for loose connection or leakage. For the fuel system diagnosis, see Section "Driveability and Emission".



Legend

- (1) Fuel Filler Cap

1. Disconnect battery ground cable.
2. Remove Fuel filler cap(1).



Legend

- (1) Fuel Hose
(2) Fuel Filter Fixing Bolt
(3) Fuel Filter


3. Disconnect fuel hoses(1) from fuel filter on both engine side and fuel tank side.
4. Fuel filter fixing bolt(2).
○ Remove the fuel filter fixing bolt(2) on fuel filter holder.
5. Remove fuel filter(3).

Inspection

1. Replace the fuel filter if the fuel leaks from fuel filter body or if the fuel filter body itself is damaged.
2. Replace the filter if it is clogged with dirt or sediment.
3. Check the drain of receive rubber and if it is clogged with dust, clean it up with air.

Installation

1. Install the fuel filter in the proper direction.
2. Install fuel filter holder fixing bolt.
3. Connect fuel hoses on engine side(1) and fuel tank side(2).



4. Install fuel filler cap
5. Connect the battery ground cable.

Inspection

After installation, start engine and check for fuel leakage.

In-Tank Fuel Filter


The filter is located on the lower end of fuel pickup tube in the fuel tank. It prevents dirt from entering the fuel pipe and also stops water unless the filter is completely submerged in the water. It is a selfcleaning type, not requiring scheduled maintenance. Excess water and sediment in the tank restricts fuel supply to the engine, resulting in engine stoppage. In such a case, the tank must be cleaned thoroughly.

Fuel Pump Flow Test

If reduction of fuel supply is suspected, perform the following checks.

1. Make sure that there is fuel in the tank.
2. With the engine running, check the fuel feed pipe and hose from fuel tank to injector for evidence of leakage. Retighten, if pipe or hose connection is loose. Also, check pipes and hoses for squashing or clogging.
3. Insert the hose from fuel feed pipe into a clean container, and check for fuel pump flow rate.

4. Connect the pump relay terminals with a jumper wire(1) as shown and start the fuel pump to measure delivery.



140RW015

CAUTION: Never generate sparks when connecting a jumper wire.

Delivery	Delivery
15 seconds	0.38 liters minimum


If the measure value is out of standard, conduct the pressure test.

Pressure test

For the pressure test to the fuel system, see Section 6E "Fuel Control System".

Fuel Pump

Fuel Pump and Associated Parts



140RX004

Legend

- | | |
|-----------------------------------|----------------------------------|
| (1) Fuel Feed Port | (6) Connector; Fuel Level Sensor |
| (2) Fuel Tube/Quick Connector | (7) Snap Ring |
| (3) Fuel Return Port | (8) Hose; Evaporative Fuel |
| (4) Fuel Pump and Sender Assembly | (9) Hose; Air Breather |
| (5) Connector; Fuel Feed Pump | (10) Hose; Fuel Filler |
| | (11) Fuel Tank Assembly |

Removal

CAUTION: When repair to the fuel system has been completed, start engine and check the fuel system for loose connection or leakage. For the fuel system diagnosis, see Section "Driveability and Emission".

1. Disconnect battery ground cable.
2. Loosen fuel filler cap.
3. Support underneath of the fuel tank assembly (11) with a lifter.
4. Remove fuel tank assembly(11). Refer to "Fuel Tank Removal" in this section.
5. Remove Fuel Tube/Quick Connector (2).

NOTE: Handling of the fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

6. Remove fuel pump and sender (FPAS) assembly (4) fixing snap ring and remove the FPAS assembly.

NOTE: After removing pump assembly (4), cover fuel tank to prevent any dust entering.

Installation

1. Install FPAS assembly(4).
2. Install Fuel Tube/Quick Connector (2).

NOTE: Handling of the fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

3. Install fuel tank assembly(11). Refer to "Fuel Tank Installation".
4. Fill the tank with fuel and tighten fuel filler cap.
5. Connect battery ground cable.

Fuel Tube / Quick – Connector Fittings

Precautions

- Lighting of Fires Prohibited.
- Keep flames away from your work area to prevent the inflammable from catching fire.
- Disconnect the battery negative cable to prevent shorting during work.
- When welding or conducting other heat-generating work on other parts, be sure to provide pretreatment to protect the piping system from thermal damage or spattering.

Cautions During Work


Do not expose the assembly to battery electrolyte or do not wipe the assembly with a cloth used to wipe off spilt battery electrolyte.

The piping wet with battery electrolyte cannot be used. Be careful not to give a bending or twisting force to the piping during the work. If deformed, replace with a new piping.

Removal

1. Open the fuel cap to relieve the fuel pressure in the tank.

If the fuel quick-connect fittings are dusty, clean with an air blower, etc. and then remove it.




141RW036

As some pressure may remain in the piping, cover the connector with a cloth, etc. to prevent the splashing of fuel in the first disconnection of the piping.


6C-8 ENGINE FUEL (6VD1 3.2L)

2. For removal of the delivery pipe (feeding fuel to the engine), hold the connector in one hand, and hold the retainer tab with the other hand and pull out the connector, as illustrated. The pipe can be removed with the retainer attached.




141RW019

3. For removal of the return pipe (returning fuel to the tank), hold the pipe in one hand, and pull out the connector with the other hand while pressing the square relieve button of the retainer, as illustrated.



141RW020


NOTE: This work should be done by hands. Do not use any tools. Should the pipe can hardly be removed from the connector, use a lubricant (light oil) and/or push and pull the connector longitudinally until the pipe is removed.



141RW021

When reusing the delivery pipe retainer, reuse without removing the retainer from the pipe. If the retainer is damaged or deformed, however, replace with a new retainer.

Cover the connectors removed with a plastic bag, etc. to prevent the entry of dust or rain water.




141RW022

Reuse of Quick-Connector

(Delivery Pipe)

- Replace the pipe and connector if scratch, dent or crack is found.
- Remove mud and dust from the pipe and make sure that the end including spool is free of defects, such as scratch, rust, and dent, which may cause poor sealability. If defective, replace with a new pipe.
- If the retainer removed according to the removal step above is attached to the pipe, clean and insert it straight into the quick-connector till it clicks. After it clicks, try pulling it out to make sure that it is not drawn and is securely locked.

NOTE: The retainer, once removed from the pipe, cannot be reused. Just replace with a new retainer. Insert the new retainer into the connector side until it clicks, and connect the pipe as inserting it into the retainer until it clicks.




141RW017

Assembling Advice

Application of engine oil or light oil to the pipe facilitates connecting work. The work should be started immediately after lubrication, since dust may stick to the pipe surface to cause poor sealability if a long time passes after lubrication.

Test/Inspection After Assembling

1. Reconnect the battery negative cable.
2. Turn the ignition key to the "ON" position and check pump startup sound. As the pump is actuated to raise fuel pressure, check and see fuel leak from the piping system.
3. Make sure of no fuel leakage by conducting the above fuel leak check a few times.
4. Start the engine and make sure of stable idling speed and normal vehicle run. The entry of dust during the work may sometimes affect the fuel injection system.



141RW018

(Return Pipe)

- Replace the pipe and connector if scratch, dent or crack is found.
- Remove mud or dust from the pipe and make sure that the end including spool is free from defects, such as scratch, rust, and dent, which may cause poor sealability. If defective, replace with a new pipe.
- After cleaning the pipe, insert it straight into the connector until it clicks. After it clicks, try pulling it out to make sure that it is not drawn and is securely locked.

Fuel Pump Relay


General Description

In order to control the FPAS operation, the FPAS relay is provided. When the starter switch is turned to "ON" position, the FPAS relay operates the FPAS for 2 seconds.

When it is turned to "START" position, the Engine Control Module receives the reference pulse from the Ignition Control Module and it operates the relay, again causing the FPAS to feed fuel.

Fuel Tank

Fuel Tank and Associated Parts



140RX005

Legend

- | | |
|--------------------------------------|------------------------------------|
| (1) Roll Over&Float Valve | (10) Fuel Pump and Sender Assembly |
| (2) Retaining Cover | (11) Fuel Feed Port |
| (3) Hose; Evaporative Fuel | (12) Fuel Tube/Quick Connector |
| (4) Hose; Air Breather | (13) Fuel Return Port |
| (5) Hose; Fuel Filler | (14) Bolt; Fuel Tank Asm. Fixing |
| (6) Bolt; Fuel Tank Protector Fixing | (15) Protector; Fuel Tank |
| (7) Snap Ring | (16) Fuel Tank Assembly |
| (8) Connector; Fuel Level Sensor | (17) Hose; Fuel Feed |
| (9) Connector; Fuel Feed Pump | (18) Hose; Fuel Return |
| | (19) Protector; Heat |

Removal

CAUTION: When repair to the fuel system has been completed, start engine and check the fuel system for loose connection or leakage. For the fuel system diagnosis, see Section "Driveability and Emission".

1. Disconnect battery ground cable.
2. Loosen fuel filler cap.
3. Support underneath of the fuel tank protector (15) with a lifter.
4. Disconnect evaporative fuel hose (3) at the canister.
5. Disconnect fuel feed hose (17) and fuel return hose (18) near the fuel filter.

NOTE: Plug both ends of the fuel hoses to prevent fuel leakage.

6. Disconnect air breather hose (4) and fuel filler hose (5) at the fuel filler neck.

NOTE: Cover fuel hose to prevent any dust entering.

7. Remove the four fuel tank assembly fixing bolts (14) at four corners of the tank.
8. Let down the tank and disconnect the wiring connectors (8,9).
9. Remove fuel tank assembly along with protectors (15,19).
10. Remove retaining cover (2) and roll over & float valve (1) along with the evaporative fuel hose and pipe (3).
11. Remove Fuel Tube/Quick Connector (12).

NOTE: Handling of the fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

12. Remove fuel pump and sender assembly (10) by removing the snap ring (7) along with the fuel hoses (17,18).
13. Remove protectors (15,19) by removing the six fixing bolts (6).

Installation

1. Install protectors (15,19) and tighten the six fixing bolts to the specified torque.

Torque: 68 N·m (50 lb ft)

2. Install fuel pump and sender assembly by fitting in of the snap ring (7).
3. Install Fuel Tube/Quick connector (12).

NOTE: Handling of the fuel tube sure to refer "Fuel Tube/Quick Connector Fittings" in this section.

4. Install roll over & float valve (1) by fitting in of the retaining cover (2).
5. Lift up fuel tank assembly and connect the wiring connectors (8,9).
6. Install fuel tank assembly along with protectors and tighten the four fixing bolts to the specified torque.

Torque: 68 N·m (50 lb ft)

7. Connect fuel filler hose (5) and air breather hose (4), and clip them firmly.
8. Connect fuel feed hose (17) and fuel return hose (18), and clip them firmly.
9. Connect evaporative fuel hose (3).
10. Tighten fuel filler cap.
11. Connect battery ground cable.

Fuel Gauge Unit

Removal and Installation


As for removal and installation of the Fuel Gauge Unit, refer to "Fuel Tank" of this section 6C as the fuel gauge unit is combined with the fuel pump and sender assembly.

Fuel Filler Cap

General Description

Fuel filler cap includes vacuum valve.

In case any high vacuum happen in tank, the valve works to adjust the pressure to prevent the tank from being damaged.



Legend

- (1) Vacuum Valve
- (2) Fuel Filler Cap

Inspection

Check the seal ring in the filler cap for presence of any abnormality and for seal condition.

Replace the filler cap, if abnormal.


CAUTION:

The fuel filler cap valve has characteristics.

A defective valve, no valve at all or a valve with the wrong characteristics will do a lot of harm to engine operating characteristics; be sure to use the same fuel filler cap as installed in this vehicle.

Main Data and Specifications

Torque Specification



RODEO

ENGINE

ENGINE ELECTRICAL (6VD1 3.2L)

CONTENTS

Service Precaution	6D1-1	Jump Starting	6D1-3
Battery	6D1-2	Battery Removal	6D1-4
General Description	6D1-2	Battery Installation	6D1-4
Diagnosis	6D1-2	Main Data and Specifications	6D1-5
Battery Charging	6D1-3		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Battery

General Description

There are six battery fluid caps on the top of the battery. These are covered by a paper label.

The battery is completely sealed except for the six small vent holes on the side. These vent holes permit the escape of small amounts of gas generated by the battery. This type of battery has the following advantages over conventional batteries:

1. There is no need to add water during the entire service life of the battery.
2. The battery protects itself against overcharging. The battery will refuse to accept an extensive charge. (A conventional battery will accept an excessive charge, resulting in gassing and loss of battery fluid.)
3. The battery is much less vulnerable to self discharge than a conventional type battery.

Diagnosis

1. Visual Inspection

Inspect the battery for obvious physical damage, such as a cracked or broken case, which would permit electrolyte loss.

Replace the battery if obvious physical damage is discovered during inspection.

Check for any other physical damage and correct it as necessary.


2. Hydrometer Check

There is a built-in hydrometer (Charge test indicator(1)) at the top of the battery. It is designed to be used during diagnostic procedures.

Before trying to read the hydrometer, carefully clean the upper battery surface.

If your work area is poorly lit, additional light may be necessary to read the hydrometer.

- a. BLUE RING OR DOT VISIBLE(5) – Go to Step 4.
- b. BLUE RING OR DOT NOT VISIBLE(4) – Go to Step 3.




061RX001

3. Fluid Level Check

The fluid level should be between the upper level line(2) and lower level line(3) on side of battery.

- a. CORRECT FLUID LEVEL – Charge the battery.
- b. BELOW LOWER LEVEL – Replace battery.



061RX001

4. Voltage Check

1. Put voltmeter test leads to battery terminals.

- a. VOLTAGE IS 12.4V OR ABOVE – Go to Step 5.
- b. VOLTAGE IS UNDER 12.4V – Go to procedure (2) below.

2. Determine fast charge amperage from specification. (See Main Data and Specifications in this section).

Fast charge battery for 30 minutes at amperage rate no higher than specified value.

Take voltage and amperage readings after charge.

- a. VOLTAGE IS ABOVE 16V AT BELOW 1/3 OF AMPERAGE RATE – Replace battery.
- b. VOLTAGE IS ABOVE 16V AT ABOVE 1/3 OF AMPERAGE RATE – Drop charging voltage to 15V and charge for 10 – 15 hours. Then go to Step 5.
- c. VOLTAGE IS BETWEEN 12V AND 16V – Continue charging at the same rate for an additional 3–1/2 hours. Then go to Step 5.
- d. VOLTAGE BELOW 12V – Replace Battery.

5. Load Test

1. Connect a voltmeter and a battery load tester across the battery terminals.
2. Apply 300 ampere load for 15 seconds to remove surface charge from the battery. Remove load.
3. Wait 15 seconds to let battery recover. Then apply specified load from specifications (See Main Data and Specifications in this section).

Read voltage after 15 seconds, then remove load.

- a. VOLTAGE DOES NOT DROP BELOW THE MINIMUM LISTED IN THE TABLE – The battery is good and should be returned to service.
- b. VOLTAGE IS LESS THAN MINIMUM LISTED – Replace battery.

ESTIMATED TEMPERATURE		MINIMUM VOLTAGE
°F	°C	V
70	21	9.6
60	16	9.5
50	10	9.4
40	4	9.3
30	-1	9.1
20	-7	8.9
10	-12	8.7
0	-18	8.5
The battery temperature must be estimated by feel and by the temperature the battery has been exposed to for the preceding few hours.		

Battery Charging

Observe the following safety precautions when charging the battery:

1. Never attempt to charge the battery when the fluid level is below the lower level line on the side of the battery. In this case, the battery must be replaced.
2. Pay close attention to the battery during charging procedure.
Battery charging should be discontinued or the rate of charge reduced if the battery feels hot to the touch.
Battery charging should be discontinued or the rate of charge reduced if the battery begins to gas or spew electrolyte from the vent holes.
3. In order to more easily view the hydrometer blue dot or ring, it may be necessary to jiggle or tilt the battery.
4. Battery temperature can have a great effect on battery charging capacity.
5. The sealed battery used on this vehicle may be either quick charged or slow charged in the same manner as other batteries.
Whichever method you decide to use, be sure that you completely charge the battery. Never partially charge the battery.

Jump Starting

Jump Starting with an Auxiliary (Booster) Battery

CAUTION: Never push or tow the vehicle in an attempt to start it. Serious damage to the emission system as well as other vehicle parts will result.

Treat both the discharged battery and the booster battery with great care when using jumper cables. Carefully follow the jump starting procedure, being careful at all times to avoid sparking.

WARNING: FAILURE TO CAREFULLY FOLLOW THE JUMP STARTING PROCEDURE COULD RESULT IN THE FOLLOWING:

1. Serious personal injury, particularly to your eyes.
2. Property damage from a battery explosion, battery acid, or an electrical fire.
3. Damage to the electronic components of one or both vehicles particularly.

Never expose the battery to an open flame or electrical spark. Gas generated by the battery may catch fire or explode.

Remove any rings, watches, or other jewelry before working around the battery. Protect your eyes by wearing an approved set of goggles.

Never allow battery fluid to come in contact with your eyes or skin.

Never allow battery fluid to come in contact with fabrics or painted surfaces.

Battery fluid is a highly corrosive acid.

Should battery fluid come in contact with your eyes, skin, fabric, or a painted surface, immediately and thoroughly rinse the affected area with clean tap water.

Never allow metal tools or jumper cables to come in contact with the positive battery terminal, or any other metal surface of the vehicle. This will protect against a short circuit.

Always keep batteries out of reach of young children.

Jump Starting Procedure

1. Set the vehicle parking brake.

If the vehicle is equipped with an automatic transmission, place the selector level in the "PARK" position.

If the vehicle is equipped with a manual transmission, place the shift lever in the "NEUTRAL" position.

Turn "OFF" the ignition.

Turn "OFF" all lights and any other accessory requiring electrical power.

2. Look at the built-in hydrometer.

If the indication area of the built-in hydrometer is completely clear, do not try to jump start.

6D1-4 ENGINE ELECTRICAL (6VD1 3.2L)

3. Attach the end of one jumper cable to the positive terminal of the booster battery.
Attach the other end of the same cable to the positive terminal of the discharged battery.

Do not allow the vehicles to touch each other. This will cause a ground connection, effectively neutralizing the charging procedure.

Be sure that the booster battery has a 12 volt rating.

4. Attach one end of the remaining cable to the negative terminal of the booster battery.

Attach the other end of the same cable to a solid engine ground (such as the air conditioning compressor bracket or the generator mounting bracket) of the vehicle with the discharged battery.


The ground connection must be at least 450 mm (18 in.) from the battery of the vehicle whose battery is being charged.

WARNING: NEVER ATTACH THE END OF THE JUMPER CABLE DIRECTLY TO THE NEGATIVE TERMINAL OF THE DEAD BATTERY.

5. Start the engine of the vehicle with the good battery.
Make sure that all unnecessary electrical accessories have been turned "OFF".
6. Start the engine of the vehicle with the dead battery.
7. To remove the jumper cables, follow the above directions in reverse order.

Be sure to first disconnect the negative cable from the vehicle with the discharged battery.

Battery Removal



1. Remove negative cable (1).
2. Remove positive cable (2).
3. Remove retainer screw and rods (3).
4. Remove retainer (4).
5. Remove battery (5).

Battery Installation

1. Install battery (5).
2. Install retainer (4).
3. Install retainer screw and rods (3).

NOTE: Make sure that the rod is hooked on the body side.

4. Install positive cable (2).
5. Install negative cable (1).

Main Data and Specifications**General Specifications**

Model	24R-600
Voltage (V)	12
Cold-Cranking Performance (Amp)	600
Reserve Capacity (Min)	118
Load Test (Amp)	300
BCI Group No.	24

RODEO

ENGINE

IGNITION SYSTEM (6VD1 3.2L)

CONTENTS

Service Precaution	6D2-1	Removal	6D2-4
General Description	6D2-2	Inspection and Repair	6D2-4
Diagnosis	6D2-2	Installation	6D2-4
Ignition Coil	6D2-3	Crankshaft Angle Sensor	6D2-5
Removal	6D2-3	Removal	6D2-5
Inspection and Repair	6D2-3	Installation	6D2-5
Installation	6D2-3	Main Data and Specifications	6D2-6
Spark Plug	6D2-4		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

Ignition is done by the electronic ignition (EI) that directly fires the spark plugs from ignition coils through spark plug wires without using a distributor. A pair of ignition coils for the cylinders having different phases by 360° (No.1 and No.4, No.2 and No.5, No.3 and No.6) are fired simultaneously.

Since the cylinder on exhaust stroke requires less energy to fire its ignition plug, energy from the ignition coils can be utilized to fire the mating cylinder on compression stroke. After additional 360° rotation, respective cylinder strokes are reversed.

The EI consists of six ignition coils, ignition control module, crank angle sensor, powertrain control module (PCM) and other components.


The ignition coils are connected with the PCM by means of a 32 pin connector.

The ignition control module turns on/off the primary circuit of ignition coils, and also it controls the ignition timing at the engine speed below 538 rpm.

A notch in the timing disc on the crankshaft activates the crank angle sensor which then sends information such as firing order and starting timing of each ignition coil to the PCM.

Further, the EI employs ignition control (IC) to control similar to a distributor system.

By receiving signals such as crank position, engine speed, water temperature and Manifold Absolute Pressure (MAP), the PCM controls the ignition timing.



D06RX001


Diagnosis

Refer to Section Drivability and Emissions for the diagnosis to electronic ignition system (EI system).

Ignition Coil

Removal

1. Disconnect battery ground cable.
2. Ignition coil connector and ignition coil.
 - Disconnect three connector from ignition coil.
 - Remove harness bracket bolt on cylinder head cover.
 - Remove fixing bolts on ignition coil.



060RW001

Legend

- (1) Ignition Coil Connector
- (2) Bolt
- (3) Ignition Coil Assembly


Inspection and Repair

Check the ignition coil assembly for insulation. Check terminals for corrosion or damage, and replace as necessary.

Measuring resistance of ignition coil assembly.

Terminal No.	Limit
1 to 2	Without 0 ohm or infinity maximum ohm.
1 to 3	Same as above
2 to 3	Same as above

Measure resistance of ignition coil assembly, and replace the ignition coil assembly if its value exceeds the standard.




060RW006

Installation

1. Install the ignition coil assembly (3).
Connect ignition coil connector (1) and ignition coil (3), then tighten bolt (2) to the specified torque.

Torque: 4 N·m (35 lb in)



060RW001

2. Connect battery ground cable.

Spark Plug

Removal

1. Remove spark plugs.

Inspection and Repair

The spark plug affects entire engine performance and therefore its inspection is very important.

- Check electrode and insulator for presence of cracks, and replace if any.
- Check electrode for wear, and replace if necessary.
- Check gasket for damage, and replace if necessary.
- Measure insulation resistance with an ohmmeter, and replace if faulty.
- Adjust spark plug gap to 1.0 mm (0.04 in) ~ 1.1 mm (0.043 in).
- Check fuel and electrical systems if spark plug is extremely dirty.
- Use spark plugs having low heat value (hot type plug) if fuel and electrical systems are normal.
- Use spark plugs having high heat value (cold type plug) if insulator and electrode are extremely burned.

Sooty Spark Plugs

Much deposit of carbon or oil on the electrode and insulator of spark plug reduces the engine performance.

Possible causes:

- Too rich mixture
- Presence of oil in combustion chamber
- Incorrectly adjusted spark plug gap

Burning Electrodes

This fault is characterized by scorched or heavily oxidized electrode or blistered insulator nose.


Possible causes:

- Too lean mixture
- Improper heat value

Measuring Insulation Resistance

- Measure insulation resistance using a 500 volt megaohm meter.
- Replace spark plugs if measured value is out of standard.


Insulation resistance: 50 MΩ or more



011RS010

Cleaning Spark Plugs

- Clean spark plugs with a spark plug cleaner.
- Raise the ground electrode to an angle of 45 to 60 degrees. If electrode is wet, dry it before cleaning.
- After spark plug is thoroughly cleaned, check insulator for presence of cracks.
- Clean threads and metal body with a wire brush.
- File the electrode tip if electrode is extremely worn.
- Bend the ground electrode to adjust the spark plug gap.



011RS011

Installation


1. Spark plugs
 - Tighten spark plugs to the specified torque.

Torque: 18 N·m (13 lb ft)

Crankshaft Angle Sensor

Removal

1. Disconnect battery ground cable
2. Wiring connector from crankshaft angle sensor.
3. Remove crankshaft angle sensor from cylinder block.



Installation

1. Install crankshaft angle sensor into the cylinder block.
Before installation, apply small amount of engine oil to the O-ring.

Torque: 10 N·m (89 lb in)


2. Reconnect wiring connector to crankshaft angle sensor.

Main Data and Specifications

General Specifications

Ignition System	
Ignition Form	Electronic Ignition System (EI system) with Crankshaft angle Sensor
Spark Plug	
Type	K16PR-P11 RC10PYP4 PK16PR11
Plug gap	1.0 mm (0.04 in) – 1.1 mm (0.043 in)
Torque	18 N·m (13 lb ft)

Torque Specifications



E06RW001

RODEO

ENGINE

STARTING AND CHARGING SYSTEM (6VD1 3.2L)

CONTENTS

Service Precaution	6D3-1	General Description	6D3-18
Starting System	6D3-2	General On-Vehicle Inspection	6D3-18
General Description	6D3-2	Generator	6D3-19
Diagnosis	6D3-4	Removal	6D3-19
Starter	6D3-5	Inspection	6D3-19
Removal	6D3-5	Installation	6D3-20
Installation	6D3-5	Disassembled View	6D3-20
Disassembled View	6D3-6	Disassembly	6D3-21
Disassembly	6D3-7	Inspection and Repair	6D3-22
Inspection and Repair	6D3-9	Reassembly	6D3-24
Reassembly	6D3-13	Bench Test	6D3-25
Main Data and Specifications	6D3-15	Main Data and Specifications	6D3-26
Charging System	6D3-18		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Starting System

General Description

Cranking Circuit

The cranking system consists of a battery, starter, starter switch, starter relay, etc. These main components are connected.

Starter

The cranking system employs a magnetic type reduction starter in which the motor shaft is also used as a pinion shaft. When the starter switch is turned on, the contacts of magnetic switch are closed, and the armature rotates. At the same time, the plunger is attracted, and the pinion is pushed forward by the shift lever to mesh with the ring gear.

Then, the ring gear runs to start the engine. When the engine starts and the starter switch is turned off, the plunger returns, the pinion is disengaged from the ring gear, and the armature stops rotation. When the engine speed is higher than the pinion, the pinion idles, so that the armature is not driven.




Diagnosis

Condition	Possible cause	Correction
Starter does not run	Charging failure	Repair charging system
	Battery Failure	Replace Battery
	Terminal connection failure	Repair or replace terminal connector and/or wiring harness
	Starter switch failure	Repair or replace starter switch
	Starter failure	Repair or replace starter

Starter


Removal

1. Battery ground cable.
2. Disconnect Heated O₂ Sensor connector (1).
3. Remove exhaust front left pipe(2).



035RW016

4. Remove heat protector(3).
5. Disconnect starter wiring connector from terminals "B" and "S"(4).
6. Remove starter assembly mounting bolts on inside and outside(5).
7. Remove starter assembly toward the bottom of engine(6).



065RW001

Installation

1. Install starter assembly(6).


2. Install mounting bolts and tighten bolts to specified torque(5).

Torque: 40 N·m (30 lb ft)

3. Reconnect the connectors to terminals "B" and "S" and tighten Terminals "B" to specified torque.

Torque: 9 N·m (80 lb in)

4. Install heat protector(3).



065RW001

5. Install exhaust front left pipe and tighten bolts and nuts to specified torque(2).


Stud Nuts

Torque: 67 N·m (49 lb ft)

Nuts

Torque: 43 N·m (32 lb ft)


6. Connect Heated O₂ Sensor connector (1).



035RW016

7. Reconnect the battery ground cable.

Disassembled View




065RW002

Legend


- | | |
|------------------------|---------------------------|
| (1) Bolt (2 pcs) | (14) Center Bracket |
| (2) Ball Bearing | (15) Pinion Shaft |
| (3) Pinion | (16) Planet Gear (3) |
| (4) Shift Lever | (17) Internal Gear |
| (5) Dust Cover | (18) Center Bracket (A) |
| (6) Torsion Spring | (19) Yoke Assembly |
| (7) Dust Cover | (20) Armature |
| (8) Magnetic Switch | (21) Brush |
| (9) Nut | (22) Brush Holder |
| (10) Gear Case | (23) Thrust Washer |
| (11) Bearing Cover | (24) Rear Cover |
| (12) E-ring | (25) Screw (2 pcs) |
| (13) Thrust Washer (2) | (26) Through Bolt (2 pcs) |

Disassembly

1. Loosen the nut(1) on terminal "M" of magnetic switch and disconnect the connector cable.
2. Remove bolt (2 pcs) (2).




3. Remove magnetic switch(5).
4. Remove dust cover(4).
5. Remove torsion spring bolts, then the magnetic switch assembly.
6. Remove torsion spring(3) from magnetic switch assembly(5).




7. Remove screw (2 pcs) (8).
8. Remove through bolt (2 pcs) (7).

9. Remove screws and through bolts, then the rear cover(9) then remove thrust washer(10).
10. Remove brush holder(6).




11. Raise a brush spring to detach brushes (4 pcs) from the commutator face and pull off the brush holder(12) and brush(11).



12. Remove yoke assembly(14).
13. Remove armature(15).
14. Pull off the yoke assembly, then remove armature, washer and center bracket.(A) (13).


6D3-8 STARTING AND CHARGING SYSTEM (6VD1 3.2L)

NOTE: In disassembling the yoke assembly, hold the armature and pull off slowly the yoke assembly. Because of strong magnetic force, avoid placing a metallic part near armature.



15. Remove dust cover(17).


16. Remove a dust cover and shift lever(16) from the gear case.



17. Remove ball bearing(19).


18. Remove bearing cover(20).

19. Remove a ball bearing and bearing cover from the gear case(18).




20. Internal gear(21).


21. Remove internal gear and planet gear(3) (22).



22. Remove an E-ring(23) from the pinion shaft using a flat blade screwdriver.



23. Holding the pinion shaft, push pinion toward the center bracket and turn the pinion clockwise or counterclockwise by one tooth of spline, then pull off the pinion.
 24. Remove thrust washer(24).
 25. Remove center bracket
 26. Remove pinion shaft.



Inspection and Repair


Repair or replace necessary parts if extreme wear or damage is found during inspection.

Armature


Measure the outer diameter of commutator, and replace with a new one if it is out of the limit.

Standard: 33.0 mm (1.30 in)

Limit: 32.0 mm (1.26 in)




Check for continuity between commutator and segment. Replace commutator if there is no continuity (i.e., disconnected).



6D3-10 STARTING AND CHARGING SYSTEM (6VD1 3.2L)

Check for continuity between commutator and shaft. Also, check for continuity between commutator and armature core, armature core and shaft. Replace commutator if there is continuity (i.e., internally grounded).



Measure runout of armature core and commutator with a dial gauge. Repair or replace, if it exceeds the limit.

Armature


Standard: 0.05 mm (0.002 in) Max.

Limit: 0.10 mm (0.004 in)


Commutator

Standard: 0.05 mm (0.002 in) Max.

Limit: 0.10 mm (0.004 in)




Polish the commutator surface with sandpaper #500 to #600 if it is rough.



Measure the depth of insulator in commutator. Repair, if it is below the limit.

Standard: 0.05 mm to 0.8 mm (0.02 in to 0.03 in)

Limit: 0.2 mm (0.008 in)



Legend


- (1) Steel Saw
- (2) Insulator
- (3) Commutator Segments

Brush

Measure the length of brush.
Replace with a new one, if it is below the limit.


Standard: 16 mm (0.63 in)

Limit: 11 mm (0.43 in)



Brush Holder


Check for continuity between brush holder (+) (4) and base (-). Replace, if there is continuity (i.e., insulation is broken).



Magnetic Switch

Check for continuity of shunt coil between terminals S and M.


Replace, if there is no continuity (i.e., coil is disconnected).



Continuity of Series Coil

Check for continuity between terminals S and M.


Replace, if there is no continuity (i.e., coil is disconnected).



6D3-12 STARTING AND CHARGING SYSTEM (6VD1 3.2L)


Continuity of Contacts

With the plunger faced downward, push down the magnetic switch. In this state, check for continuity between terminals B and M. Replace, if there is no continuity (i.e., contacts are faulty).




Pinion

Check if the pinion rotates smoothly in drive direction by hand, or if it is locked when it is rotated in reverse. If not, replace the pinion.




Yoke Assembly

Check a magnet inside the yoke.
Replace the yoke assembly if it is broken.



Ball Bearing


Clamp the inner race of the ball bearing with your finger, and check for sticking or play when rotating the outer race.
Replace, if abnormality is found.



Measure inner diameter of bushing in the rear cover, and replace if it exceeds the limit.

Standard: 12.50 mm to 12.527 mm (0.492 in to 0.4932 in)

Limit: 12.60 mm (0.4961 in)




065RS028

Measure inner diameter of bushing in the center bracket (P), and replace if it exceeds the limit.

Standard: 18.01 mm to 18.127 mm (0.7091 in to 0.7137 in)

Limit: 18.15 mm (0.7146 in)



065RS029

Reassembly

To install, follow the removal steps in the reverse order, noting the following points:

Grease application places

- Bushing in rear cover and center bracket
- Gears in reduction gear
- Shift lever operating portion
- Sliding portion of pinion
- Plunger sliding portion of magnetic switch

Reassembling Yoke Assembly

Before reassembly, make sure that no metallic parts attach to the yoke assembly. Because of strong magnetic force, hold the yoke assembly and insert it slowly into the armature.

Torque


Torque for each part (See Torque Specifications in this section)

Pinion Jump-out Dimension

Connect the “+” cable of battery to terminal S and the “-” cable to terminal M. Turn the switch on, and measure pinion travel dimension in thrust direction from the jump-out position.

In measuring the dimension, pull the pinion out a little in the arrow direction.


Dimension(L): 0.05 mm to 1.5 mm (0.002 in to 0.06 in)



065RS030

6D3-14 STARTING AND CHARGING SYSTEM (6VD1 3.2L)

If the measured value is out of standard, insert dust cover, or disassemble and adjust.




Characteristic Test

For easily confirming the characteristics, conduct the no load test as follows:

Rating as short as 30 seconds requires rapid testing.

Fix the starter on the test bench, and wire as shown in illustration. When the switch is closed, the current flows and the starter runs under no load. At this time, measure current, voltage and speed to check if they satisfy the standard.




Legend

- (1) Volt Meter
- (2) Tachometer
- (3) Battery
- (4) Ammeter
- (5) Switch


Main Data and Specifications**General Specifications**

Model	Specification
Rating	
Voltage	12 V
Output	1.4 Kw
Time	30 sec
Number of teeth of pinion	9
Rotating direction(as viewed from pinion)	Clockwise
Weight(approx.)	37 N
No-load characteristics	
Voltage /Current	11.5V/90A or less
Speed	3000rpm or more
Load characteristics	
Voltage/current	8.5V/350A or more
Torque	13.2N·m or more
Speed	1000rpm or more
Locking characteristics	
Voltage/current	2.4V/500A or less
Torque	11.8N·m or more

Torque Specifications



E06RW023




150RW029

Charging System

General Description

The IC integral regulator charging system and its main components are connected as shown in illustration. The regulator is a solid state type and it is mounted along with the brush holder assembly inside the generator installed on the rear end cover. The generator does not require particular maintenance such as voltage adjustment.

The rectifier connected to the stator coil has diodes to transform AC voltage into DC voltage. This DC voltage is connected to the output terminal of generator.



F06RX002

General On-Vehicle Inspection

A basic wiring diagram is shown in the illustration. When operating normally, the indicator bulb will come on when the switch is turned on, and will then go out when the engine starts. If the indicator operates abnormally, or if an undercharged or overcharged battery condition occurs, the following procedure may be used to diagnose the charging system. Remember that an undercharged battery is often caused by accessories being left on overnight, or by a defective switch which allows a bulb, such as a trunk or glove box light, to stay on.

OBSERVE THE FOLLOWING PROCEDURE:


1. Visually check belt and wiring.
2. Go to step 5. for vehicles without charge indicator light.
3. Switch on, engine stopped, light should be on. If not, detach harness at generator, ground "L" terminal lead.
- a. Lamp lights, replace or repair generator.
- b. Lamp does not light, locate open circuit between grounding lead and ignition switch. Bulb may be open.
4. Switch on, engine running at moderate speed. Light should be off. If not, detach wiring harness at generator.
 - a. If light goes off, replace or repair generator.
 - b. If light stays on, check for grounded "L" terminal wire in harness.
5. Battery undercharged or overcharged.
 - a. Detach wiring harness connector from generator.
 - b. With switch on, engine not running connect voltmeter from ground to "L" terminal in wiring harness, and to "IG" terminal. If used. Wiring harness may connect to either "L" or "IG" or both.
 - c. Zero reading indicates open circuit between terminal and battery. Connect as required.

- d. Re-connect harness connector to generator, run engine at moderate speed, with electrical accessories turned off.
 - e. Measure voltage across battery. If above 16.0V, replace or repair generator.
 - f. Connect ammeter at generator output terminal. Turn on accessories, load battery with carbon pile to obtain maximum amperes output. Maintain voltage at 13.0V or above.
1. If within 15 amperes of rated output, generator is OK.
 2. If not within 15 amperes of rated output, replace or repair generator.

Generator


Removal

1. Disconnect battery ground cable.
2. Move drive belt tensioner to loose side using wrench then remove drive belt (1).
3. Disconnect the wire from terminal "B" and disconnect the connector (4).
4. Remove generator fixing bolt (3).
5. Remove generator assembly (2).



Inspection

1. Disconnect the wiring connector from generator.
2. With the engine stopped, turn starter switch to "on" and connect a voltmeter between connector terminal L (1) and ground or between terminal IG (2) and ground.



If voltage is not present, the line between battery and connector is disconnected and so requires repair.

3. Reconnect the wiring connector to the generator, run the engine at middle speed, and turn off all electrical devices other than engine.
4. Measure battery voltage. If it exceeds 16V, repair or replace the generator.
5. Connect an ammeter to output terminal of generator, and measure output current under load by turning on the other electrical devices (eg., headlights). At this time the amperes must not be less than 15A and the voltage must not be less than 13V.

Installation

1. Install generator assembly to the position.
2. Install generator assembly and tighten the fixing bolts to the specified torque.

Torque:


M10 bolt: 41 N·m (30 lb ft)

M8 bolt: 21 N·m (15 lb ft)

3. Connect wiring harness connector and direct terminal "B".

4. Move drive belt tensioner to loose side using wrench, then install drive belt to normal position.
5. Reconnect battery ground cable.

Disassembled View



Legend


- | | |
|--------------------------|----------------------------|
| (1) Pulley Nut | (7) Nut |
| (2) Pulley | (8) Terminal Insulator |
| (3) Front Cover Assembly | (9) Rear Cover Assembly |
| (4) Rotor Assembly | (10) Rectifier |
| (5) Stator Assembly | (11) Brush Holder Assembly |
| (6) Through Bolt | (12) Regulator Assembly |

066RW022


Disassembly

1. Remove the through bolt.
Insert the tip of a pry bar into the gaps between the front cover and the stator core.
Pry apart and separate the front cover, rotor, the rear cover and stator.


NOTE: Take care not to scratch or otherwise damage the stator coil with pry bar.




2. Clamp the rotor in a vise and then remove the nut and pulley.
3. Remove the rotor assembly from front cover.



4. Remove screws with bearing retainer from front cover and remove bearing.




5. Remove the mounting nuts holding the "B" terminal, the diode, and the brush holder.
6. Separate the rear cover from the stator.



6D3-22 STARTING AND CHARGING SYSTEM (6VD1 3.2L)


7. Remove bolts which secure stator terminal to rectifier terminal, and remove stator.



066RS030

8. Remove Bolts which secure regulator, rectifier and brush-holder, and separate these parts.

NOTE: Do not apply a shock or load to regulator, rectifier and brush holder.



066RW025

Inspection and Repair


Repair or replace necessary parts if extreme wear or damage is found during inspection.

Rotor Assembly

1. Check the face of the slip rings for contamination and roughness. If found to be scored, dress with a fine sandpaper (#500–600). If found to be contaminated, clean with a cloth saturated with alcohol.
2. Measure the outside diameter of the slip rings.

Standard: 27mm (1.06in)


Limit: 26mm (1.02in)



066RS032


3. Check resistance between slip rings, and replace if there is no continuity.

Standard: 3.75Ω or less



066RS033


4. Check for continuity between slip ring and rotor core.
In case of continuity, replace the rotor assembly.



066RS017

2. Check for continuity across one of the stator coils and stator core. If a continuity exists, replace the coil.

Standard: More than 1MΩ




066RS035

Stator Coil

1. Check for continuity across the stator coils. If no continuity exists, replace the coils.
Resistance value at 20°C.

Standard: Approx. 0.07Ω




066RS034

Brush

- Measure the brush length.
If more than limit, replace the brush.

Standard: 18.0mm (0.709in)


Limit: 5.5mm (0.217in)



066RW024

Rectifier Assembly

1. Measure the resistance between each diode terminal and aluminum diode fin in forward and reverse directions with the connection of the tester leads switched. The diodes are normal if resistance is nearly zero ohms in one direction and is infinitely high in the other direction.
2. If a diode has no resistance or equal resistance in both directions, it is defective and should be replaced together with the holder.




066RS036

IC Regulator Assembly

Connect a variable resistor, two 12V batteries, a fixed resistor, and a voltmeter to the IC regulator as shown in illustration.

- Measuring equipment specifications
 - Fixed resistor (R1) : 10 Ohms /3W
 - Variable resistor (Rv) : 0-300 Ohms/12W
 - Batteries (BAT1, BAT2) : 12V (2 Batteries)
 - DC voltmeter : 0-50V/0.5 steps (4 Check points)
- Measuring procedure
 - Measure the voltage "V1" across the first battery (BAT1). If the reading is between 10 and 13 volts, the battery is normal.
 - Measure the voltage "V3" across both the batteries (BAT1, BAT2). If the reading is between 20 and 26 volts, the batteries are normal.
 - Gradually increase the resistance of the variable resistor from zero. Measure the voltage "V2" (the voltage across the F and E terminals).
Check to see that the voltage across "V1" changes at this time. If there is no change, the voltage regulator is faulty and must be replaced.
 - Measure the voltage at "V4" (the voltage across the variable resistor center tap and terminal E with the variable resistor resistance held constant). The measure voltage should be within the specified (14.4 ± 0.3 volts) limits. If it is not, the regulator must be replaced.



066RX003


Reassembly

To reassemble, follow the disassembly steps in the reverse order, noting the following points:

NOTE:


- Never make battery connections with polarities reversed, or battery will be shorted via the diodes. This will cause damage to the diodes.
- Do not connect generator B terminal to ground; it is connected directly to the battery. This cable will burn if it is connected to ground.
- Make sure to disconnect the positive (+) terminal of the battery when quick-charging battery. Diodes may be damaged due to abnormal pulse voltage generated by the quick charger.
- When reassembling the front section to rear section, insert a stiff wire into hole in the rear face of the rear cover from the outboard side to support the brush in raised position, then insert the front section to which rotor is assembled.
- Reassemble parts carefully to be sure they fit into their original position, paying attention to the insulated portions.
- Wipe insulating tubes, washers and plates clean and install them in position carefully to avoid getting oil or grease on them.

1. Using a press with a socket wrench attached, reassemble rotor and rear end cover assembly in the front cover.




2. Install pulley on the rotor.
Secure the pulley directly in the vise between two copper plates, and tighten nut to the specified torque.

Torque: 111 N·m (82 lb ft)



Bench Test


Conduct a bench test of the generator.



Preparation

Remove generator from the vehicle (see "Generator removal").

1. Secure generator to the bench test equipment and connect wires.
Terminal "IG" for energization
Terminal "L" for neutral (warning lamp)
Terminal "B" for output
2. Conduct the generator characteristic test.
Characteristics of generator are shown in illustration.
Repair or replace the generator if its outputs are abnormal.



STANDARD CHARACTERISTICS CURVE
(HOT CONDITION) AT 13.5V

066RX001

Main Data and Specifications

General Specifications

Battery voltage	V	12
Rated output	A	90
Direction of rotation (as viewed from pulley side)		Clockwise
Rated rotation speed	rpm	5000
Maximum speed	rpm	18000

RODEO

ENGINE

RODEO 3.2L ENGINE DRIVEABILITY AND EMISSIONS

CONTENTS

Specification	6E2-6	Basic Knowledge of Tools Required	6E2-30
Tightening Specifications	6E2-6	Serial Data Communications	6E2-30
Diagrams and Schematics	6E2-7	Class II Serial Data Communications	6E2-30
PCM Wiring Diagram (1 of 8)	6E2-7	On-Board Diagnostic (OBD II)	6E2-30
PCM Wiring Diagram (2 of 8)	6E2-8	On-Board Diagnostic Tests	6E2-30
PCM Wiring Diagram (3 of 8)	6E2-9	Comprehensive Component Monitor	
PCM Wiring Diagram (4 of 8)	6E2-10	Diagnostic Operation	6E2-30
PCM Wiring Diagram (5 of 8)	6E2-11	System Status and Drive Cycle for	
PCM Wiring Diagram (6 of 8)	6E2-12	Satisfying Federal Inspection/Maintenance	
PCM Wiring Diagram (7 of 8)	6E2-13	(I/M 240) Regulations	6E2-31
PCM Wiring Diagram (8 of 8)	6E2-14	Common OBD II Terms	6E2-31
PCM Pinouts	6E2-15	The Diagnostic Executive	6E2-32
PCM Pinout Table, 32-Way Red		DTC Types	6E2-33
Connector – Row “A”	6E2-15	Decimal/Binary/Hexadecimal Conversions	6E2-34
PCM Pinout Table, 32-Way Red		Verifying Vehicle Repair	6E2-34
Connector – Row “B”	6E2-16	Reading Diagnostic Trouble Codes Using	
PCM Pinout Table, 32-Way White		the TECH 2 Scan Tool	6E2-34
Connector – Row “C”	6E2-17	Tech 2	6E2-35
PCM Pinout Table, 32-Way White		Tech 2 Features	6E2-36
Connector – Row “D”	6E2-18	Getting Started	6E2-36
PCM Pinout Table, 32-Way Blue		Operating Procedure (For Example)	6E2-37
Connector – Row “E”	6E2-19	DTC Modes	6E2-38
PCM Pinout Table, 32-Way Blue		DTC Information Mode	6E2-38
Connector – Row “F”	6E2-20	Miscellaneous Test	6E2-39
Component Locators	6E2-21	Lamps Test	6E2-39
Engine Component Locator Table	6E2-22	Relays Test	6E2-40
Undercarriage Component Locator	6E2-23	EVAP Test	6E2-41
Undercarriage Component Locator Table	6E2-23	Idle Air Control System Test	6E2-43
Sensors and Miscellaneous Component		Fuel System Test	6E2-44
Locators	6E2-24	EGR Control Test	6E2-46
Fuse and Relay Panel (Underhood		Variable Intake Manifold Solenoid Test ...	6E2-46
Electrical Center)	6E2-27	Injector Balance Test	6E2-47
Diagnosis	6E2-28	Plotting Snapshot Graph	6E2-48
Strategy-Based Diagnostics	6E2-28	Plotting Graph Flow Chart (Plotting graph	
Strategy-Based Diagnostics	6E2-28	after obtaining vehicle information)	6E2-49
DTC Stored	6E2-28	Flow Chart for Snapshot Replay	
No DTC	6E2-28	(Plotting Graph)	6E2-50
No Matching Symptom	6E2-28	To upload Snapshots to a PC and Download	
Intermittents	6E2-28	Diagnostic Software from a CD ROM Disk	6E2-51
No Trouble Found	6E2-28	Primary System-Based Diagnostics	6E2-51
Verifying Vehicle Repair	6E2-28	Primary System-Based Diagnostics	6E2-51
General Service Information	6E2-29	Fuel Control Heated Oxygen Sensors	6E2-51
OBD II Serviceability Issues	6E2-29	HO2S Heater	6E2-51
Emissions Control Information Label	6E2-29	Catalyst Monitor Heated Oxygen Sensors	
Maintenance Schedule	6E2-30	and Diagnostic Operation	6E2-51
Visual/Physical Engine Compartment			
Inspection	6E2-30		

6E2-2 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

Misfire Monitor Diagnostic Operation	6E2-52	Diagnostic Trouble Code (DTC) P0112 IAT	
Misfire Monitor Diagnostic Operation	6E2-52	Sensor Circuit Low Voltage	6E2-137
Misfire Counters	6E2-52	Diagnostic Trouble Code (DTC) P0113 IAT	
Fuel Trim System Monitor Diagnostic		Sensor Circuit High Voltage	6E2-140
Operation	6E2-53	Diagnostic Trouble Code (DTC) P0117 ECT	
Fuel Trim System Monitor Diagnostic		Sensor Circuit Low Voltage	6E2-143
Operation	6E2-53	Diagnostic Trouble Code (DTC) P0118 ECT	
Fuel Trim Cell Diagnostic Weights	6E2-53	Sensor Circuit High Voltage	6E2-146
On-Board Diagnostic (OBD II) System Check	6E2-54	Diagnostic Trouble Code (DTC) P0121 TP	
A/C Clutch Control Circuit Diagnosis	6E2-57	System Performance	6E2-149
Electronic Ignition System Diagnosis	6E2-63	Diagnostic Trouble Code (DTC) P0122 TP	
EVAP Canister Purge Solenoid	6E2-63	Sensor Circuit Low Voltage	6E2-152
Visual Check of The Evaporative Emission		Diagnostic Trouble Code (DTC) P0123 TP	
Canister	6E2-63	Sensor Circuit High Voltage	6E2-155
Fuel Metering System Check	6E2-63	Diagnostic Trouble Code (DTC) P0125 ECT	
Idle Air Control (IAC) Valve	6E2-63	Excessive Time to Closed Loop Fuel	
Fuel System Pressure Test	6E2-63	Control	6E2-158
Fuel Injector Coil Test Procedure and Fuel		Diagnostic Trouble Code (DTC) P0131 HO2S	
Injector Balance Test Procedure	6E2-63	Circuit Low Voltage Bank 1 Sensor 1	6E2-161
Knock Sensor Diagnosis	6E2-68	Diagnostic Trouble Code (DTC) P0132 HO2S	
Powertrain Control Module (PCM) Diagnosis	6E2-68	Circuit High Voltage Bank 1 Sensor 1	6E2-164
Multiple PCM Information Sensor DTCS Set	6E2-68	Diagnostic Trouble Code (DTC) P0133 HO2S	
Exhaust Gas Recirculation (EGR) Diagnosis	6E2-71	Slow Response Bank 1 Sensor 1	6E2-167
Engine Tech 2 Data Definitions and Ranges	6E2-71	Diagnostic Trouble Code (DTC) P0134 HO2S	
Typical Scan Data Values	6E2-74	Circuit Insufficient Activity Bank 1 Sensor 1	6E2-171
No Malfunction Indicator Lamp (MIL)	6E2-81	Diagnostic Trouble Code (DTC) P0135 HO2S	
Malfunction Indicator Lamp (MIL) "ON"		Heater Circuit Bank 1 Sensor 1	6E2-174
Steady	6E2-84	Diagnostic Trouble Code (DTC) P0137 HO2S	
Engine Cranks But Will Not Run	6E2-87	Circuit Low Voltage Bank 1 Sensor 2	6E2-177
Fuel System Electrical Test	6E2-92	Diagnostic Trouble Code (DTC) P0138 HO2S	
Fuel System Diagnosis	6E2-95	Circuit High Voltage Bank 1 Sensor 2	6E2-180
Idle Air Control (IAC) System Check	6E2-100	Diagnostic Trouble Code(DTC) P0140 HO2S	
Knock Sensor (KS) System Check		Circuit Insufficient Activity Bank 1 Sensor 2	6E2-183
(Engine Knock, Poor Performance,		Diagnostic Trouble Code (DTC) P0141 HO2S	
or Poor Economy)	6E2-103	Heater Circuit Bank 1 Sensor 2	6E2-186
Exhaust Gas Recirculation (EGR) System		Diagnostic Trouble Code (DTC) P0151 HO2S	
Check	6E2-105	Circuit Low Voltage Bank 2 Sensor 1	6E2-189
Manifold Absolute Pressure (MAP) Output		Diagnostic Trouble Code (DTC) P0152 HO2S	
Check	6E2-107	Circuit High Voltage Bank 2 Sensor 1	6E2-192
Evaporative (EVAP) Emissions Canister		Diagnostic Trouble Code (DTC) P0153 HO2S	
Purge Valve Check	6E2-109	Slow Response Bank 2 Sensor 1	6E2-195
Up-Shift Lamp System Check	6E2-112	Diagnostic Trouble Code (DTC) P0154 HO2S	
PCM Diagnostic Trouble Codes	6E2-115	Circuit Insufficient Activity Bank 2 Sensor 1	6E2-199
Diagnostic Trouble Code (DTC) P0101 MAF		Diagnostic Trouble Code (DTC) P0155 HO2S	
System Performance	6E2-119	Heater Circuit Bank 2 Sensor 1	6E2-202
Diagnostic Trouble Code (DTC) P0102 MAF		Diagnostic Trouble Code (DTC) P0157 HO2S	
Sensor Circuit Low Frequency	6E2-122	Circuit Low Voltage Bank 2 Sensor 2	6E2-205
Diagnostic Trouble Code (DTC) P0103 MAF		Diagnostic Trouble Code (DTC) P0158 HO2S	
Sensor Circuit High Frequency	6E2-125	Circuit High Voltage Bank 2 Sensor 2	6E2-208
Diagnostic Trouble Code (DTC) P0106 MAP		Diagnostic Trouble Code (DTC) P0160 HO2S	
System Performance	6E2-128	Circuit Insufficient Activity Bank 2 Sensor 2	6E2-211
Diagnostic Trouble Code (DTC) P0107 MAP		Diagnostic Trouble Code (DTC) P0161 HO2S	
Sensor Circuit Low Voltage	6E2-131	Heater Circuit Bank 2 Sensor 2	6E2-214
Diagnostic Trouble Code (DTC) P0108 MAP		Diagnostic Trouble Code (DTC) P0171 Fuel	
Sensor Circuit High Voltage	6E2-134	Trim System Too Lean Bank 1	6E2-217

Diagnostic Trouble Code (DTC) P0172 Fuel Trim System Rich Bank 1	6E2-221	Diagnostic Trouble Code (DTC) P0401 EGR Flow Insufficient	6E2-304
Diagnostic Trouble Code (DTC) P0174 Fuel Trim System Lean Bank 2	6E2-225	Diagnostic Trouble Code (DTC) P0402 EGR Pintle Crank Error	6E2-307
Diagnostic Trouble Code (DTC) P0175 Fuel Trim System Rich Bank 2	6E2-229	Diagnostic Trouble Code (DTC) P0404 EGR Open Stuck	6E2-309
Diagnostic Trouble Code (DTC) P0201 Injector 1 Control Circuit	6E2-233	Diagnostic Trouble Code (DTC) P0405 EGR Low Voltage	6E2-311
Diagnostic Trouble Code (DTC) P0202 Injector 2 Control Circuit	6E2-236	Diagnostic Trouble Code (DTC) P0406 EGR High Voltage	6E2-314
Diagnostic Trouble Code (DTC) P0203 Injector 3 Control Circuit	6E2-239	Diagnostic Trouble Code (DTC) P0420 TWC System Low Efficiency Bank 1	6E2-317
Diagnostic Trouble Code (DTC) P0204 Injector 4 Control Circuit	6E2-242	Diagnostic Trouble Code (DTC) P0430 TWC System Low Efficiency Bank 2	6E2-320
Diagnostic Trouble Code (DTC) P0205 Injector 5 Control Circuit	6E2-245	Diagnostic Trouble Code (DTC) P0440 EVAP System	6E2-323
Diagnostic Trouble Code (DTC) P0206 Injector 6 Control Circuit	6E2-248	Diagnostic Trouble Code (DTC) P0442 EVAP System Small Leak Detected	6E2-328
Diagnostic Trouble Code (DTC) P0300 Engine Misfire Detected	6E2-251	Diagnostic Trouble Code (DTC) P0446 EVAP Canister Vent Blocked	6E2-333
Diagnostic Trouble Code (DTC) P0301 Cylinder 1 Misfire Detected	6E2-255	Diagnostic Trouble Code (DTC) P0452 Fuel Tank Pressure Sensor Low Voltage	6E2-336
Diagnostic Trouble Code (DTC) P0302 Cylinder 2 Misfire Detected	6E2-257	Diagnostic Trouble Code (DTC) P0453 Fuel Tank Pressure Sensor High Voltage	6E2-339
Diagnostic Trouble Code (DTC) P0303 Cylinder 3 Misfire Detected	6E2-259	Diagnostic Trouble Code (DTC) P0462 Fuel Level Sensor Circuit-Low Voltage	6E2-342
Diagnostic Trouble Code (DTC) P0304 Cylinder 4 Misfire Detected	6E2-261	Diagnostic Trouble Code (DTC) P0463 Fuel Level Sensor Circuit-High Voltage	6E2-345
Diagnostic Trouble Code (DTC) P0305 Cylinder 5 Misfire Detected	6E2-263	Diagnostic Trouble Code (DTC) P0502 VSS Circuit Low Input	6E2-347
Diagnostic Trouble Code (DTC) P0306 Cylinder 6 Misfire Detected	6E2-265	Diagnostic Trouble Code (DTC) P0506 Idle Air Control System Low RPM	6E2-350
Diagnostic Trouble Code (DTC) P0325 KS Module Circuit	6E2-267	Diagnostic Trouble Code (DTC) P0507 Idle Air Control System High RPM	6E2-353
Diagnostic Trouble Code (DTC) P0327 KS Sensor Circuit	6E2-269	Diagnostic Trouble Code (DTC) P0562 System Voltage Low	6E2-356
Diagnostic Trouble Code (DTC) P0336 58X Reference Signal Circuit	6E2-272	Diagnostic Trouble Code (DTC) P0563 System Voltage High	6E2-358
Diagnostic Trouble Code (DTC) P0337 CKP Sensor Circuit Low Frequency	6E2-275	Diagnostic Trouble Code (DTC) P0601 PCM Memory	6E2-359
Diagnostic Trouble Code (DTC) P0341 CMP Sensor Circuit Performance	6E2-278	Diagnostic Trouble Code (DTC) P1106 MAP Sensor Circuit Intermittent High Voltage ...	6E2-360
Diagnostic Trouble Code (DTC) P0342 CMP Sensor Circuit Low	6E2-282	Diagnostic Trouble Code (DTC) P1107 MAP Sensor Circuit Intermittent Low Voltage	6E2-362
Diagnostic Trouble Code (DTC) P0351 Ignition 1 Control Circuit	6E2-286	Diagnostic Trouble Code (DTC) P1111 IAT Sensor Circuit Intermittent High Voltage ...	6E2-364
Diagnostic Trouble Code (DTC) P0352 Ignition 2 Control Circuit	6E2-289	Diagnostic Trouble Code (DTC) P1112 IAT Sensor Circuit Intermittent Low Voltage	6E2-367
Diagnostic Trouble Code (DTC) P0353 Ignition 3 Control Circuit	6E2-292	Diagnostic Trouble Code (DTC) P1114 ECT Sensor Circuit Intermittent Low Voltage	6E2-369
Diagnostic Trouble Code (DTC) P0354 Ignition 4 Control Circuit	6E2-295	Diagnostic Trouble Code (DTC) P1115 ECT Sensor Circuit Intermittent High Voltage ...	6E2-371
Diagnostic Trouble Code (DTC) P0355 Ignition 5 Control Circuit	6E2-298	Diagnostic Trouble Code (DTC) P1121 TP Sensor Circuit Intermittent High Voltage ...	6E2-374
Diagnostic Trouble Code (DTC) P0356 Ignition 6 Control Circuit	6E2-301	Diagnostic Trouble Code (DTC) P1122 TP Sensor Circuit Intermittent Low Voltage	6E2-376

6E2-4 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

Diagnostic Trouble Code (DTC) P1133 HO2S Insufficient Switching Bank 1 Sensor 1	6E2-378	Fuel Gauge Unit	6E2-471
Diagnostic Trouble Code (DTC) P1134 HO2S Transition Time Ratio Bank 1 Sensor 1	6E2-382	Fuel Injectors	6E2-471
Diagnostic Trouble Code (DTC) P1153 HO2S Insufficient Switching Bank 2 Sensor 1	6E2-386	Fuel Pressure Regulator	6E2-472
Diagnostic Trouble Code (DTC) P1154 HO2S Circuit Transition Time Ratio Bank 2 Sensor 1	6E2-390	Fuel Metering System	6E2-474
Diagnostic Trouble Code (DTC) P1171 Fuel System Lean Dueing Acceleration	6E2-394	Fuel Pump Assembly	6E2-474
Diagnostic Trouble Code (DTC) P1380 ABS Rough Road ABS System Fault	6E2-397	Fuel Pump Relay	6E2-475
Diagnostic Trouble Code (DTC) P1381 ABS Rough Road Class 2 Serial Link Error	6E2-398	Fuel Rail Assembly	6E2-475
Diagnostic Trouble Code (DTC) P1404 EGR Stuck Closed	6E2-399	Fuel Tank	6E2-476
Diagnostic Trouble Code (DTC) P1441 EVAP System Flow During Non-Purge	6E2-402	Throttle Body (TB)	6E2-476
Diagnostic Trouble Code (DTC) P1508 IAC System Low RPM	6E2-405	Electronic Ignition System	6E2-478
Diagnostic Trouble Code (DTC) P1509 IAC System High RPM	6E2-408	Catalytic Converter	6E2-479
Diagnostic Trouble Code (DTC) P1618 Serial Peripheral Interface (SPI) PCM Interprocessor Communication Error	6E2-411	Air Conditioning Relay	6E2-479
Diagnostic Trouble Code (DTC) P1625 PCM Unexpected Reset	6E2-412	EVAP Canister Hoses	6E2-479
Diagnostic Trouble Code (DTC) P1640 Output Driver Module (ODM) "A" Fault	6E2-413	EVAP Canister	6E2-480
Diagnostic Trouble Code (DTC) P1650 Quad Driver Module "A" Fault	6E2-415	EVAP Canister Vent Solenoid	6E2-481
Symptom Diagnosis	6E2-418	Fuel Tank Pressure Sensor	6E2-482
Default Matrix Table	6E2-446	EVAP Canister Purge Solenoid	6E2-483
On-Vehicle Service Camshaft Position (CMP) Sensor	6E2-449	Fuel Tank Vent Valve	6E2-484
Crankshaft Position (CKP) Sensor	6E2-450	Linear Exhaust Gas Recirculation (EGR) Valve	6E2-484
Engine Coolant Temperature (ECT) Sensor ..	6E2-450	Positive Crankcase Ventilation (PCV) Valve ..	6E2-485
Heated Oxygen Sensor (HO2S)	6E2-451	Wiring and Connectors	6E2-485
Intake Air Temperature (IAT) Sensor	6E2-453	PCM Connectors and Terminals	6E2-486
Knock Sensor (KS)	6E2-454	Wire Harness Repair: Twisted Shielded Cable	6E2-486
Mass Air Flow (MAF) Sensor	6E2-455	Twisted Leads	6E2-487
Manifold Absolute Pressure (MAP) Sensor ..	6E2-456	Weather-Pack Connector	6E2-488
Malfunction Indicator Lamp (MIL)	6E2-456	Com-Pack III	6E2-489
Powertrain Control Module (PCM)	6E2-457	Metri-Pack	6E2-489
EEPROM	6E2-458	General Description (PCM and Sensors) ...	6E2-491
Throttle Position (TP) Sensor	6E2-459	58X Reference PCM Input	6E2-491
Vehicle Speed Sensor (VSS)	6E2-459	A/C Request Signal	6E2-491
Air Cleaner/Air Filter	6E2-461	Crankshaft Position (CKP) Sensor	6E2-491
Idle Air Control (IAC) Valve	6E2-462	Camshaft Position (CMP) Sensor and Signal	6E2-491
Common Chamber	6E2-463	Engine Coolant Temperature (ECT) Sensor	6E2-491
Accelerator Cable Assembly	6E2-463	Electrically Erasable Programmable Read Only Memory (EEPROM)	6E2-492
Accelerator Pedal Replacement	6E2-466	Fuel Control Heated Oxygen Sensors	6E2-492
Fuel Filter Cap	6E2-468	Catalyst Monitor Heated Oxygen Sensors	6E2-492
Fuel Filter	6E2-468	Intake Air Temperature (IAT) Sensor	6E2-493
		Knock Sensor	6E2-493
		Linear Exhaust Gas Recirculation (EGR) Control	6E2-494
		Mass Air Flow (MAF) Sensor	6E2-494
		Manifold Absolute Pressure (MAP) Sensor	6E2-494
		Powertrain Control Module (PCM)	6E2-495
		PCM Function	6E2-495
		PCM Components	6E2-495
		PCM Voltage Description	6E2-495
		PCM Input/Outputs	6E2-495
		PCM Service Precautions	6E2-496
		Reprogramming The PCM	6E2-496
		Throttle Position (TP) Sensor	6E2-496

Transmission Fluid Temperature (TFT) Sensor	6E2-496	Camshaft Position (CMP) Sensor	6E2-501
Transmission Range Switch	6E2-496	Crankshaft Position (CKP) Sensor	6E2-501
Vehicle Speed Sensor (VSS)	6E2-497	Electronic Ignition	6E2-501
Use of Circuit Testing Tools	6E2-497	Ignition Coils	6E2-502
Aftermarket Electrical and Vacuum Equipment	6E2-497	Ignition Control	6E2-502
Electrostatic Discharge Damage	6E2-497	Ignition Control PCM Output	6E2-503
Upshift Lamp	6E2-498	Knock Sensor (KS) PCM Input	6E2-503
General Description (Air Induction)	6E2-498	Powertrain Control Module (PCM)	6E2-503
Air Induction System	6E2-498	Spark Plug	6E2-503
General Description (Fuel Metering)	6E2-498	A/C Clutch Diagnosis	6E2-505
Acceleration Mode	6E2-498	A/C Clutch Circuit Operation	6E2-505
Accelerator Controls	6E2-498	A/C Clutch Circuit Purpose	6E2-505
Battery Voltage Correction Mode	6E2-498	A/C Request Signal	6E2-505
CMP Signal	6E2-498	General Description (Evaporative (EVAP) Emission System)	6E2-506
Clear Flood Mode	6E2-498	EVAP Emission Control System Purpose ..	6E2-506
Deceleration Mode	6E2-498	EVAP Emission Control System Operation ..	6E2-506
Engine Speed/Vehicle Speed/Fuel Disable Mode	6E2-498	Enhanced Evaporative Emission Control System	6E2-506
Fuel Cutoff Mode	6E2-498	General Description (Exhaust Gas Recirculation (EGR) System)	6E2-509
Fuel Injector	6E2-498	EGR Purpose	6E2-509
Fuel Metering System Components	6E2-499	Linear EGR Valve	6E2-510
Fuel Metering System Purpose	6E2-499	Linear EGR Control	6E2-510
Fuel Pressure Regulator	6E2-499	Linear EGR Valve Operation and Results of Incorrect Operation	6E2-510
Fuel Pump Electrical Circuit	6E2-499	EGR Pintle Position Sensor	6E2-510
Fuel Rail	6E2-499	General Description (Positive Crankcase Ventilation (PCV) System)	6E2-510
Idle Air Control (IAC) Valve	6E2-500	Crankcase Ventilation System Purpose ...	6E2-510
Run Mode	6E2-500	Crankcase Ventilation System Operation ..	6E2-511
Starting Mode	6E2-500	Special Tools	6E2-512
Throttle Body Unit	6E2-501		
General Description (Electronic Ignition System)	6E2-501		


Specification

Tightening Specifications

Application	N-m	Lb Ft.	Lb In.
Camshaft Position Sensor Retaining Screw	9	—	78
Crankshaft Position Sensor Mounting Bolt	9	—	78
EGR Bolt	14	—	122
EGR Nut	14	—	122
Engine Coolant Temperature Sensor	30	22	—
Fuel Pressure Regulator Attaching Screw	6.5	—	56
Fuel Rail Bolts	7	—	61
Fuel Tank Undercover Retaining Bolts	36	27	—
Heated Oxygen Sensor	5	—	43
Lower Intake Manifold to Engine Block Nuts	25	18	—
Spark Plugs	18	13	—
Throttle Body Mounting Bolts	13	—	113
Upper Intake Manifold to Lower Intake Manifold Bolts	25	18	—
VSS Retaining Bolt	13	—	113

Diagrams and Schematics


PCM Wiring Diagram (1 of 8)




PCM Wiring Diagram (2 of 8)




PCM Wiring Diagram (3 of 8)



PCM Wiring Diagram (4 of 8)




U P=Microprocessor




D06RX006

PCM Wiring Diagram (6 of 8)




D06RX007

PCM Wiring Diagram (7 of 8)




D06RX008

PCM Wiring Diagram (8 of 8)



PCM Pinouts


PCM Pinout Table, 32-Way Red Connector – Row “A”



TS23344

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
A1	5 Volt Reference “A”	RED	5.0 V	5.0 V	Appropriate Sensor
A2	Knock Sensor	YEL	0.0 V	0.0 V	General Description and Operation, Knock Sensor
A3	Not Used				
A4	Battery Feed (ECM Fuse)	RED/WHT	B+	B+	Chassis Electrical
A5	Idle Air Control (IAC) “A” High	BLU	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A6	IAC “A” Low	BLU/WHT	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A7	IAC “B” Low	BLU/BLK	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A8	IAC “B” High	BLU/RED	B+/0.8 V	B+/0.8 V	General Description and Operation, IAC
A9	Automatic Transmission Fluid (ATF) Lamp	ORN/BLK	B+	B+	Automatic Transmission (4L30E)
A10	Winter Lamp	PNK/GRN	B+	B+	Automatic Transmission (4L30E)
A11	Power Lamp	PNK/WHT	B+	B+	Automatic Transmission (4L30E)
A12	Not Used				
A13	Malfunction Indicator (Check Engine or MIL) Lamp	WHT/GRN	0.0 V	B+	Chassis Electrical
A14	“Check Transmission” (AT) Lamp Driver	VIO	B+	B+	Chassis Electrical
	Up shift light (MT)	YEL/GRN	B+	B+	Chassis Electrical
A15	EVAP Canister Purge Signal	RED/BLU	B+	5.7 V	General Description and Operation, EVAP Emission Control System
A16	Band Apply	YEL/BLK	B+	B+	Automatic Transmission (4L30E)


PCM Pinout Table, 32-Way Red Connector – Row “B”



TS23344

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
B1	5 Volt Reference “B”	BLU/ORN	5.0 V	5.0 V	Appropriate Sensor
B2	Ignition coil #4	RED/WHT	0.0 V	0.1 V	General Description and Operation, ICM
B3	Ignition coil #2	RED/BLK	0.0 V	0.1 V	General Description and Operation, ICM
B4	Ignition coil #6	RED/GRN	0.0 V	0.1 V	General Description and Operation, ICM
B5	Fuel Level Sensor	ORN/GRN	1.8 V (Tank empty)	1.8 V (Tank empty)	General Description and Operation, Enhanced EVAP System
B6	Fuel Tank Pressure Sensor	GRY	1.5 V (Ambient pressure)	1.5 V (Ambient pressure)	General Description and Operation, Enhanced EVAP System
B7	Exhaust Gas Recirculation (EGR)	YEL/RED	0.6 V	0.6 V	General Description and Operation, Linear EGR Control
B8	Intake Air Temperature (IAT) Sensor	YEL/GRN	≈3 V (depends on temperature)	≈3 V (depends on temperature)	General Description and Operation, IAT
B9	Not Used	—	—	—	—
B10	Not Used	—	—	—	—
B11	Power Steering Pressure (PSP) Switch	GRN/YEL	B+	B+	General Description and Operation, PSP
B12	Illuminated Switch	GRN/YEL	B+	B+	Chassis Electrical
B13	Class 2 Data	ORN/BLK	0.0 V	0.0 V	Diagnosis, Class 2 Serial Data
B14	A/C Clutch	GRY/RED	B+ (A/C OFF)	B+ (A/C OFF)	General Description and Operation, A/C Clutch Circuit Operation
B15	Low Fuel Lamp	PNK	B+ (Lamp OFF)	B+ (Lamp OFF)	—
B16	Fuel Gauge PWM	YEL/RED	B+	Switching from 13.9 to 14.3 V	General Description and Operation, Enhanced EVAP System


PCM Pinout Table, 32-Way White Connector – Row “C”



TS23345

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
C1	Injector Cylinder #4	GRN/RED	B+	B+	General Description and Operation, Fuel Injector
C2	Shift “B” Solenoid	BRN/BLK	0.0 V	0.0 V	Automatic Transmission (4L30E)
C3	Injector Cylinder #6	GRN/YEL	B+	B+	General Description and Operation, Fuel Injector
C4	Ignition Control (IC) Cylinder #1	RED	0.0 V	0.1 V	General Description and Operation, Fuel Injector
C5	Crankshaft Position Sensor, “A” Circuit	YEL	0.3 V	2.2 V	General Description and Operation, Crankshaft Position Sensor
C6	Not Used	—	—	—	—
C7	PCM Ground	BLK/WHT	0.0 V	0.0 V	Chassis Electrical
C8	PCM Ground	BLK/RED	0.0 V	0.0 V	Chassis Electrical
C9	PCM Ground	BLK/BLU	0.0 V	0.0 V	Chassis Electrical
C10	Tachometer	BLK/RED	8.8 V	10.0 (at idle)	Chassis Electrical
C11	Variable Intake Manifold	WHT/BLU	0.0 V	0, B+ (More than 3600 rpm)	Manual Transmission
C12	Rear Defogger Relay	RED/WHT	B+	B+	Chassis Electrical
C13	Canister Cut Valve	BRN/WHT	6.0 V (Tank empty)	5.7 V (Tank empty)	General Description and Operation, Enhanced EVAP system
C14	Bank 2 HO2S 1 High	WHT	0.3 V	0.0-0.8 V	General Description and Operation, Fuel HO2S 1
C15	Bank 2 HO2S 1 Low	RED	0.0 V	0.1 V	General Description and Operation, Fuel HO2S 1
C16	Bank 2 HO2S 2 High	ORN/BLU	0.3 V	0.7 V	General Description and Operation, Catalyst HO2S 2


PCM Pinout Table, 32-Way White Connector – Row “D”



TS23345


PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
D1	Injector Cylinder #2	GRN/ORN	B+	B+	General Description and Operation, Fuel Injector
D2	Torque Converter Clutch (TCC)	RED/YEL	0.0 V	0.0 V	On-Vehicle Service, Torque Converter Clutch
D3	Injector Cylinder #1	GRN/WHT	B+	B+	General Description and Operation, Fuel Injector
D4	Serial Data (8192)	RED	5.0 V	5.0 V	Chassis Electrical
D5	Ignition Control, Cylinder #5	RED/YEL	0.0 V	0.1 V	General Description and Operation, Ignition Control Module
D6	Ignition Control, Cylinder #3	RED/BLU	0.0 V	0.1 V	General Description and Operation
D7	Speedometer	BLU/BLK	0.0 V	0.1 V (at rest)	Chassis Electrical
D8	Sensor Ground 5V Reference A Return	GRN	0.0 V	0.0 V	Appropriate Sensor
D9	Sensor Ground 5 V Reference B Return	GRN	0.0 V	0.0 V	Appropriate Sensor
D10	Mass Air Flow (MAF)	YEL	4.9 V	4.2 V	General Description, Mass Air Flow Sensor
D11	Camshaft Position Sensor	BLU	5.0 V	4.6 V	General Description and Operation, Camshaft Position Sensor
D12	Bank 1 HO2S 2 Low	BLU	0.0 V	0.1 V	General Description and Operation, Catalyst Monitor HO2S 2
D13	Bank 1 HO2S 2 High	GRN	0.3 V	0.6 V	General Description and Operation, Catalyst Monitor HO2S 2
D14	Bank 1 HO2S 1 Low	BLU	0.0 V	0.1 V	General Description and Operation, Fuel HO2S 1
D15	Bank 1 HO2S 1 High	PNK	0.3 V	0.0-0.8 V	General Description and Operation, Fuel HO2S 1
D16	Bank 2 HO2S 2 Low	WHT/BLU	0.0 V	0.1 V	General Description and Operation, Catalyst HO2S 2

PCM Pinout Table, 32-Way Blue Connector – Row “E”



TS23346

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
E1	Vehicle Speed Sensor Signal	YEL	0.0 V	0.1 V	Automatic Transmission (4L30E)
E2	Vehicle Speed Sensor Low	BRN	0.0 V	0.0 V	Automatic Transmission (4L30E)
E3	Pressure Control Solenoid Low	RED/GRN	0.0 V	0.0 V	Automatic Transmission (4L30E)
E4	Pressure Control Solenoid High	RED/BLK	0.0 V	0.0 V	Automatic Transmission (4L30E)
E5	Exhaust Gas Recirculation (EGR) Ignition	BLK/YEL	B+	B+	General Description and Operation, EGR Control
E6	Exhaust Gas Recirculation (EGR) Solenoid	YEL	B+	B+	General Description and Operation, EGR Control
E7	Transmission Range Signal “B”	PNK	0.0 V	0.0 V	Automatic Transmission (4L30E)
E8	Throttle Position (TP) Sensor	BLU	0.6 V	0.6 V (at idle)	General Description and Operation, Throttle Position Sensor
E9	Engine Coolant Temperature (ECT) Sensor	BLU/RED	2.3 V	2.1 V	General Description and Operation, Engine Coolant Temperature (ECT) Sensor
E10	Not Used	—	—	—	—
E11	Crankshaft Position (CKP) Sensor +5 Volt Reference	BRN	5.0 V	5.0 V	General Description and Operation, Crankshaft Position Sensor
E12	Transmission Range Signal “A”	PNK/BLU	B+	B+	Automatic Transmission (4L30E)
E13	Fuel Pump (FP) Relay	PNK/WHT	0.0 V	B+	On-Vehicle Service, Fuel Pump Relay
E14	Shift High (BAND APPLY)	BRN/WHT	B+	B+	Automatic Transmission (4L30E)
E15	A/C Request	GRN/BLK	0.0 V	0.0 V	Electric Cooling Fans
E16	Ignition Feed (1 of 2 F16)	RED/BLU	B+	B+	—


PCM Pinout Table, 32-Way Blue Connector – Row “F”

TS23346

PIN	PIN Function	Wire Color	IGN ON	ENG RUN	Refer To
F1	Not Used	—	—	—	—
F2	Transmission Range Signal “C”	BLU/WHT	0.0 V	0.0 V	Automatic Transmission (4L30E)
F3	Transmission Range Signal “P”	PNK/BLK	B+	B+	Automatic transmission (4L30E)
F4	Brake Switch	RED	0.0 V	0.0 V	Automatic transmission (4L30E)
F5	Power Switch	PPL/RED	B+	B+	Automatic Transmission (4L30E)
F6	Winter Switch	PPL/GRN	B+	B+	Automatic Transmission (4L30E)
F7	Transmission Fluid Temperature	GRN/RED	2.2 V	1.1 V	Automatic Transmission (4L30E)
F8	Manifold Absolute Pressure (MAP)	GRY	4.7 V	1.1 V	General Description and Operation, Manifold Absolute Pressure
F9	Rear Defogger Switch	YEL/GRN	B+	B+	Chassis Electrical
F10	Cruise Control	GRY/BLU	B+	B+	Automatic transmission (4L30E)
F11	Kickdown Switch	LT BLU	B+	B+	Automatic Transmission (4L30E)
F12	Diag	ORN/BLU	B+	B+	—
F13	Injector Cylinder #3	GRN	B+	B+	General Description and Operation, Fuel Injector
F14	Shift “A” Solenoid	YEL/GRN	B+	B+	Automatic Transmission (4L30E)
F15	Injector Cylinder #5	GRN/BLK	B+	B+	General Description and Operation, Fuel Injector
F16	Ignition Feed (1 of 2 E16)	RED/BLU	B+	B+	—

Component Locators


Engine Component Locator



6E2-22 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS**Engine Component Locator Table**

Number	Name	Location
1	Linear Exhaust Gas Recirculation (EGR) Valve	Rear right side of the engine
2	Throttle Position (TP) Sensor	On the right of the throttle body
3	Intake Air Temperature (IAT) Sensor	On the intake air duct near the throttle body
4	Check Engine (MIL) Light	On the instrument panel beneath the tachometer
5	Positive Crankcase Ventilator (PCV) Valve	On the left of the cylinder head cover
6	Air Cleaner	Left front of the engine bay
7	Mass Air Flow (MAF) Sensor	Attached to the air filter box
8	Camshaft Position (CMP) Sensor	On the rear right side of the left cylinder head cover
9	Fuel Pressure Regulator	Rear right side of the engine
10	Idle Air Control (IAC) Valve	On the left of the throttle body
11	Common Chamber	Top of the engine
12	EVAP Canister Purge Valve	Bolted to the front of the coolant pipe
13	Fuse/Relay Box	Along the inside of the right fender
14	Manifold Absolute Pressure (MAP) Sensor	Bolted to the top the upper intake manifold
15	Throttle Body	Between the intake air duct and the upper intake manifold
16	Engine Coolant Temperature Sensor	On the coolant crossover pipe at the front of the engine, near the throttle body

Undercarriage Component Locator










014RW142

Undercarriage Component Locator Table

Number	Name	Location
1	Fuel Pump Assembly and Fuel Tank Pressure Sensor	Installed in the top of the fuel tank
2	Fuel Gauge Unit	Installed in the top of the fuel tank
3	Evaporative (EVAP) Canister	On the top of the bracket that is located behind of the cross member
4	EVAP Canister Vent Solenoid	On the top of the bracket that is located behind of the cross member
5	Fuel Filter	Located along the inside of the right frame rail, ahead of the fuel tank
6	Vehicle Speed Sensor (VSS)	Protrudes from the transmission housing, just ahead of the propeller shaft
7	Heated Oxygen Sensor (Bank 1, HO2S 2)	Threaded into the exhaust pipe behind the right-hand catalytic converter
8	Heated Oxygen Sensor (Bank 1, HO2S 1)	Threaded into the exhaust pipe ahead of the right-hand catalytic converter
9	Heated Oxygen Sensor (Bank 2, HO2S 1)	Threaded into the exhaust pipe ahead the left-hand catalytic converter
10	Heated Oxygen Sensor (Bank 2, HO2S 2)	Threaded into the exhaust pipe behind the left-hand catalytic converter


Sensors and Miscellaneous Component Locators






CANISTER PURGE VACCUM SWITCH


141RW008




025RW008



055RW003




T321078




FUEL FILTER

041RW013



060RW007



028RW001

Diagnosis

Strategy-Based Diagnostics

Strategy-Based Diagnostics

The strategy-based diagnostic is a uniform approach to repair all Electrical/Electronic (E/E) systems. The diagnostic flow can always be used to resolve an E/E system problem and is a starting point when repairs are necessary. The following steps will instruct the technician how to proceed with a diagnosis:

1. Verify the customer complaint.
 - To verify the customer complaint, the technician should know the normal operation of the system.
2. Perform preliminary checks.
 - Conduct a thorough visual inspection.
 - Review the service history.
 - Detect unusual sounds or odors.
 - Gather diagnostic trouble code information to achieve an effective repair.
3. Check bulletins and other service information.
 - This includes videos, newsletters, etc.
4. Refer to service information (manual) system check(s).
 - "System checks" contain information on a system that may not be supported by one or more DTCs. System checks verify proper operation of the system. This will lead the technician in an organized approach to diagnostics.
5. Refer to service diagnostics.

DTC Stored

Follow the designated DTC chart exactly to make an effective repair.

No DTC

Select the symptom from the symptom tables. Follow the diagnostic paths or suggestions to complete the repair. You may refer to the applicable component/system check in the system checks.

No Matching Symptom

1. Analyze the complaint.
2. Develop a plan for diagnostics.
3. Utilize the wiring diagrams and the theory of operation.

Combine technician knowledge with efficient use of the available service information.

Intermittents

Conditions that are not always present are called intermittents. To resolve intermittents, perform the following steps:

1. Observe history DTCs, DTC modes, and freeze frame data.
2. Evaluate the symptoms and the conditions described by the customer.
3. Use a check sheet or other method to identify the circuit or electrical system component.
4. Follow the suggestions for intermittent diagnosis found in the service documentation.

Most scan tools, such as the Tech 2, have data-capturing capabilities that can assist in detecting intermittents.

No Trouble Found

This condition exists when the vehicle is found to operate normally. The condition described by the customer may be normal. Verify the customer complaint against another vehicle that is operating normally. The condition may be intermittent. Verify the complaint under the conditions described by the customer before releasing the vehicle.

1. Re-examine the complaint.

When the complaint cannot be successfully found or isolated, a re-evaluation is necessary. The complaint should be re-verified and could be intermittent as defined in *Intermittents*, or could be normal.

2. Repair and verify.

After isolating the cause, the repairs should be made. Validate for proper operation and verify that the symptom has been corrected. This may involve road testing or other methods to verify that the complaint has been resolved under the following conditions:

- Conditions noted by the customer.
- If a DTC was diagnosed, verify a repair by duplicating conditions present when the DTC was set as noted in the Failure Records or Freeze Frame data.

Verifying Vehicle Repair

Verification of the vehicle repair will be more comprehensive for vehicles with OBD II system diagnostics. Following a repair, the technician should perform the following steps:

IMPORTANT: Follow the steps below when you verify repairs on OBD II systems. Failure to follow these steps could result in unnecessary repairs.

1. Review and record the Failure Records and the Freeze Frame data for the DTC which has been diagnosed (Freeze Frame data will only be stored for an A or B type diagnostic and only if the MIL ("Check Engine" lamp) has been requested).
2. Clear the DTC(s).
3. Operate the vehicle within conditions noted in the Failure Records and Freeze Frame data.
4. Monitor the DTC status information for the DTC which has been diagnosed until the diagnostic test associated with that DTC runs.

General Service Information

OBD II Serviceability Issues

With the introduction of OBD II diagnostics across the entire passenger car and light-duty truck market in 1996, illumination of the MIL ("Check Engine" lamp) due to a non-vehicle fault could lead to misdiagnosis of the vehicle, increased warranty expense and customer dissatisfaction. The following list of non-vehicle faults does not include every possible fault and may not apply equally to all product lines.

Fuel Quality

Fuel quality is not a new issue for the automotive industry, but its potential for turning on the MIL ("Check Engine" lamp) with OBD II systems is new.

Fuel additives such as "dry gas" and "octane enhancers" may affect the performance of the fuel. If this results in an incomplete combustion or a partial burn, it will show up as a Misfire DTC P0300. The Reid Vapor Pressure of the fuel can also create problems in the fuel system, especially during the spring and fall months when severe ambient temperature swings occur. A high Reid Vapor Pressure could show up as a Fuel Trim DTC due to excessive canister loading. High vapor pressures generated in the fuel tank can also affect the Evaporative Emission diagnostic as well.

Using fuel with the wrong octane rating for the vehicle may cause driveability problems. Many of the major fuel companies advertise that using "premium" gasoline will improve the performance of the vehicle. Most premium fuels use alcohol to increase the octane rating of the fuel. Although alcohol-enhanced fuels may raise the octane rating, the fuel's ability to turn into vapor in cold temperatures deteriorates. This may affect the starting ability and cold driveability of the engine.

Low fuel levels can lead to fuel starvation, lean engine operation, and eventually engine misfire.

Non-OEM Parts

All of the OBD II diagnostics have been calibrated to run with OEM parts. Something as simple as a high-performance exhaust system that affects exhaust system back pressure could potentially interfere with the operation of the EGR valve and thereby turn on the MIL ("Check Engine" lamp). Small leaks in the exhaust system near the post catalyst oxygen sensor can also cause the MIL ("Check Engine" lamp) to turn on.

Aftermarket electronics, such as transceiver, stereos, and anti-theft devices, may radiate EMI into the control system if they are improperly installed. This may cause a false sensor reading and turn on the MIL ("Check Engine" lamp).

Environment

Temporary environmental conditions, such as localized flooding, will have an effect on the vehicle ignition system. If the ignition system is rain-soaked, it can temporarily cause engine misfire and turn on the MIL ("Check Engine" lamp).

Refueling

A new OBD II diagnostic was introduced in 1996 on some vehicles. This diagnostic checks the integrity of the entire evaporative emission system. If the vehicle is restarted after refueling and the fuel cap is not secured correctly, the on-board diagnostic system will sense this as a system fault and turn on the MIL ("Check Engine" lamp) with a DTC P0440.

Vehicle Marshaling

The transportation of new vehicles from the assembly plant to the dealership can involve as many as 60 key cycles within 2 to 3 miles of driving. This type of operation contributes to the fuel fouling of the spark plugs and will turn on the MIL ("Check Engine" lamp) with a P0300 Misfire DTC.

Poor Vehicle Maintenance

The sensitivity of OBD II diagnostics will cause the MIL ("Check Engine" lamp) to turn on if the vehicle is not maintained properly. Restricted air filters, fuel filters, and crankcase deposits due to lack of oil changes or improper oil viscosity can trigger actual vehicle faults that were not previously monitored prior to OBD II. Poor vehicle maintenance can't be classified as a "non-vehicle fault", but with the sensitivity of OBD II diagnostics, vehicle maintenance schedules must be more closely followed.

Severe Vibration

The Misfire diagnostic measures small changes in the rotational speed of the crankshaft. Severe driveline vibrations in the vehicle, such as caused by an excessive amount of mud on the wheels, can have the same effect on crankshaft speed as misfire and therefore may set a Misfire DTC P0300.

Related System Faults

Many of the OBD II system diagnostics will not run if the PCM detects a fault on a related system or component. One example would be that if the PCM detected a Misfire fault, the diagnostics on the catalytic converter would be suspended until Misfire fault was repaired. If the Misfire fault was severe enough, the catalytic converter could be damaged due to overheating and would never set a Catalyst DTC until the Misfire fault was repaired and the Catalyst diagnostic was allowed to run to completion. If this happens, the customer may have to make two trips to the dealership in order to repair the vehicle.

Emissions Control Information Label

The engine compartment "Vehicle Emissions Control Information Label" contains important emission specifications and setting procedures. In the upper left corner is exhaust emission information. This identifies the emission standard (Federal, California, or Canada) of the engine, the displacement of the engine in liters, the class of the vehicle, and the type of fuel metering system. There is also an illustrated emission components and vacuum hose schematic.

This label is located in the engine compartment of every vehicle. If the label has been removed it should be replaced. It can be ordered from Isuzu Dealer ship.

Maintenance Schedule

Refer to the *Maintenance Schedule*.

Visual/Physical Engine Compartment Inspection

Perform a careful visual and physical engine compartment inspection when performing any diagnostic procedure or diagnosing the cause of an emission test failure. This can often lead to repairing a problem without further steps. Use the following guidelines when performing a visual/physical inspection:

- Inspect all vacuum hoses for pinches, cuts, disconnections, and proper routing.
- Inspect hoses that are difficult to see behind other components.
- Inspect all wires in the engine compartment for proper connections, burned or chafed spots, pinched wires, contact with sharp edges or contact with hot exhaust manifolds or pipes.

Basic Knowledge of Tools Required

NOTE: Lack of basic knowledge of this powertrain when performing diagnostic procedures could result in an incorrect diagnosis or damage to powertrain components. Do not attempt to diagnose a powertrain problem without this basic knowledge.

A basic understanding of hand tools is necessary to effectively use this section of the Service Manual.

Serial Data Communications

Class II Serial Data Communications

Government regulations require that all vehicle manufacturers establish a common communication system. This vehicle utilizes the "Class II" communication system. Each bit of information can have one of two lengths: long or short. This allows vehicle wiring to be reduced by transmitting and receiving multiple signals over a single wire. The messages carried on Class II data streams are also prioritized. If two messages attempt to establish communications on the data line at the same time, only the message with higher priority will continue. The device with the lower priority message must wait. The most significant result of this regulation is that it provides Tech 2 manufacturers with the capability to access data from any make or model vehicle that is sold.

The data displayed on the other Tech 2 will appear the same, with some exceptions. Some scan tools will only be able to display certain vehicle parameters as values that are a coded representation of the true or actual value. For more information on this system of coding, refer to *Decimal/Binary/Hexadecimal Conversions*. On this vehicle the Tech 2 displays the actual values for vehicle parameters. It will not be necessary to perform any conversions from coded values to actual values.

On-Board Diagnostic (OBD II)

On-Board Diagnostic Tests

A diagnostic test is a series of steps, the result of which is a pass or fail reported to the diagnostic executive. When a diagnostic test reports a pass result, the diagnostic executive records the following data:

- The diagnostic test has been completed since the last ignition cycle.
- The diagnostic test has passed during the current ignition cycle.
- The fault identified by the diagnostic test is not currently active.

When a diagnostic test reports a fail result, the diagnostic executive records the following data:

- The diagnostic test has been completed since the last ignition cycle.
- The fault identified by the diagnostic test is currently active.
- The fault has been active during this ignition cycle.
- The operating conditions at the time of the failure.

Remember, a fuel trim DTC may be triggered by a list of vehicle faults. Make use of all information available (other DTCs stored, rich or lean condition, etc.) when diagnosing a fuel trim fault.

Comprehensive Component Monitor Diagnostic Operation

Comprehensive component monitoring diagnostics are required to monitor emissions-related input and output powertrain components. The *CARB OBD II Comprehensive Component Monitoring List Of Components Intended To illuminate MIL* is a list of components, features or functions that could fall under this requirement.

Input Components:

Input components are monitored for circuit continuity and out-of-range values. This includes rationality checking. Rationality checking refers to indicating a fault when the signal from a sensor does not seem reasonable, i.e. Throttle Position (TP) sensor that indicates high throttle position at low engine loads or MAP voltage. Input components may include, but are not limited to the following sensors:

- Vehicle Speed Sensor (VSS)
- Transmission Output Speed Sensor (TOSS)
- Crankshaft Position (CKP) Sensor
- Knock Sensor (KS)
- Throttle Position (TP) Sensor
- Engine Coolant Temperature (ECT) Sensor
- Camshaft Position (CMP) Sensor
- Manifold Absolute Pressure (MAP) Sensor
- Mass Air Flow (MAF) Sensor

In addition to the circuit continuity and rationality check the ECT sensor is monitored for its ability to achieve a steady state temperature to enable closed loop fuel control.

Output Components:

Output components are diagnosed for proper response to control module commands. Components where functional monitoring is not feasible will be monitored for circuit continuity and out-of-range values if applicable. Output components to be monitored include, but are not limited to, the following circuit:

- Idle Air Control (IAC) Motor
- Control module controlled EVAP Canister Purge Valve
- Electronic Transmission controls
- A/C relays
- Cooling fan relay
- VSS output
- MIL control

Refer to PCM and Sensors in General Descriptions.

Passive and Active Diagnostic Tests

A passive test is a diagnostic test which simply monitors a vehicle system or component. Conversely, an active test, actually takes some sort of action when performing diagnostic functions, often in response to a failed passive test. For example, the EGR diagnostic active test will force the EGR valve open during closed throttle decel and/or force the EGR valve closed during a steady state. Either action should result in a change in manifold pressure.

Intrusive Diagnostic Tests

This is any on-board test run by the Diagnostic Management System which may have an effect on vehicle performance or emission levels.

Warm-Up Cycle

A warm-up cycle means that engine at temperature must reach a minimum of 70°C (160°F) and rise at least 22°C (40°F) over the course of a trip.

Freeze Frame

Freeze Frame is an element of the Diagnostic Management System which stores various vehicle information at the moment an emissions-related fault is stored in memory and when the MIL is commanded on. These data can help to identify the cause of a fault. Refer to *Storing And Erasing Freeze Frame Data* for more detailed information.

Failure Records

Failure Records data is an enhancement of the OBD II Freeze Frame feature. Failure Records store the same vehicle information as does Freeze Frame, but it will store that information for any fault which is stored in on-board memory, while Freeze Frame stores information only for emission-related faults that command the MIL on.

System Status and Drive Cycle for Satisfying Federal Inspection/Maintenance (I/M 240) Regulations

I/M Ready Status means a signal or flag for each emission system test that had been set in the PCM. I/M Ready Status indicates that the vehicle on-board emissions diagnostics have been run. I/M Ready Status is not concerned whether the emission system passed or failed the test, only that on-board diagnosis is complete. Not all vehicle use all possible I/M flags.

Common OBD II Terms

Diagnostic

When used as a noun, the word diagnostic refers to any on-board test run by the vehicle's Diagnostic Management System. A diagnostic is simply a test run on a system or component to determine if the system or component is operating according to specification. There are many diagnostics, shown in the following list:

- Misfire
- Oxygen sensors
- Oxygen sensor heaters
- EGR
- Catalyst monitoring

Enable Criteria

The term "enable criteria" is engineering language for the conditions necessary for a given diagnostic test to run. Each diagnostic has a specific list of conditions which must be met before the diagnostic will run. "Enable criteria" is another way of saying "conditions required". The enable criteria for each diagnostic is listed on the first page of the DTC description in Section 6E3 under the heading "Conditions for Setting the DTC". Enable criteria varies with each diagnostic, and typically includes, but is not limited to the following items:

- engine speed
- vehicle speed
- ECT
- MAF/MAP
- barometric pressure
- IAT
- TP
- high canister purge
- fuel trim
- TCC enabled
- A/C on

Trip

Technically, a trip is a key on-run-key off cycle in which all the enable criteria for a given diagnostic are met, allowing the diagnostic to run. Unfortunately, this concept is not quite that simple. A trip is official when all the enable criteria for a given diagnostic are met. But because the enable criteria vary from one diagnostic to another, the definition of trip varies as well. Some diagnostic are run when the vehicle is at operating temperature, some when the vehicle first starts up; some require that the vehicle be cruising at a steady highway speed, some run only when the vehicle is idle; some diagnostics function with the TCC disables. Some run only immediately following a cold engine start-up.

A trip then, is defined as a key on-run-key off cycle in which the vehicle was operated in such a way as to satisfy the enabling criteria for a given diagnostic, and this diagnostic will consider this cycle to be one trip. However, another diagnostic with a different set of enable criteria (which were not met) during this driving event, would not consider it a trip. No trip will occur for that particular diagnostic until the vehicle is driven in such a way as to meet all the enable criteria.

The Diagnostic Executive

The Diagnostic Executive is a unique segment of software which is designed to coordinate and prioritize the diagnostic procedures as well as define the protocol for recording and displaying their results. The main responsibilities of the Diagnostic Executive are listed as follows:

- Commanding the MIL ("Check Engine" lamp) on and off
- DTC logging and clearing
- Freeze Frame data for the first emission related DTC recorded
- Non-emission related Service Lamp (future)
- Operating conditions Failure Records buffer, (the number of records will vary)
- Current status information on each diagnostic
- System Status (I/M ready)

The Diagnostic Executive records DTCs and turns on the MIL when emission-related faults occur. It can also turn off the MIL if the conditions cease which caused the DTC to set.

Diagnostic Information

The diagnostic charts and functional checks are designed to locate a faulty circuit or component through a process of logical decisions. The charts are prepared with the requirement that the vehicle functioned correctly at the time of assembly and that there are no multiple faults present.

There is a continuous self-diagnosis on certain control functions. This diagnostic capability is complemented by the diagnostic procedures contained in this manual. The language of communicating the source of the malfunction is a system of diagnostic trouble codes. When a malfunction is detected by the control module, a diagnostic trouble code is set and the Malfunction Indicator Lamp (MIL) ("Check Engine" lamp) is illuminated.

Malfunction Indicator Lamp (MIL)

The Malfunction Indicator Lamp (MIL) looks the same as the MIL you are already familiar with ("Check Engine" lamp). However, OBD II requires that it illuminate under a strict set of guide lines.

Basically, the MIL is turned on when the PCM detects a DTC that will impact the vehicle emissions.

The MIL is under the control of the Diagnostic Executive. The MIL will be turned on if an emissions-related diagnostic test indicates a malfunction has occurred. It will stay on until the system or component passes the same test, for three consecutive trips, with no emission related faults.

If the vehicle is experiencing a misfire malfunction which may cause damage to the Three-Way Catalytic Converter (TWC), the MIL will flash once per second. This will continue until the vehicle is outside of speed and load conditions which could cause possible catalyst damage, and the MIL will stop flashing and remain on steady.

Extinguishing the MIL

When the MIL is on, the Diagnostic Executive will turn off the MIL after *three(3) consecutive* trips that a "test passed" has been reported for the diagnostic test that originally caused the MIL to illuminate.

Although the MIL has been turned off, the DTC will remain in the PCM memory (both Freeze Frame and Failure Records) until *forty(40) warm-up cycles after no faults* have been completed.

If the MIL was set by either a fuel trim or misfire-related DTC, additional requirements must be met. In addition to the requirements stated in the previous paragraph, these requirements are as follows:

- The diagnostic tests that are passed must occur with 375 RPM of the RPM data stored at the time the last test failed.
- Plus or minus ten (10) percent of the engine load that was stored at the time the last failed.
- Similar engine temperature conditions (warmed up or warming up) as those stored at the time the last test failed.

Meeting these requirements ensures that the fault which turned on the MIL has been corrected.

The MIL ("Check Engine" lamp) is on the instrument panel and has the following functions:

- It informs the driver that a fault that affects vehicle emission levels has occurred and that the vehicle should be taken for service as soon as possible.
- As a bulb and system check, the MIL will come "ON" with the key "ON" and the engine not running. When the engine is started, the MIL will turn "OFF."

- When the MIL remains "ON" while the engine is running, or when a malfunction is suspected due to a driveability or emissions problem, a Powertrain On-Board Diagnostic (OBD) System Check must be performed. The procedures for these checks are given in On-Board Diagnostic (OBD II) System Check. These checks will expose faults which may not be detected if other diagnostics are performed first.

DTC Types

Each DTC is directly related to a diagnostic test. The Diagnostic Management System sets DTC based on the failure of the tests during a trip or trips. Certain tests must fail two (2) consecutive trips before the DTC is set. The following are the four (4) types of DTCs and the characteristics of those codes:

- Type A
 - Emissions related
 - Requests illumination of the MIL of the first trip with a fail
 - Stores a History DTC on the first trip with a fail
 - Stores a Freeze Frame (if empty)
 - Stores a Fail Record
 - Updates the Fail Record each time the diagnostic test fails
- Type B
 - Emissions related
 - "Armed" after one (1) trip with a fail
 - "Disarmed" after one (1) trip with a pass
 - Requests illumination of the MIL on the *second consecutive trip* with a fail
 - Stores a History DTC on the second consecutive trip with a fail (The DTC will be armed after the first fail)
 - Stores a Freeze Frame on the second consecutive trip with a fail (if empty)
 - Stores a Fail Record when the first test fails (not dependent on *consecutive trip* fails)
 - Updates the Fail Record each time the diagnostic test fails

(Some special conditions apply to misfire and fuel trim DTCs)

- Type C (if the vehicle is so equipped)
 - Non-Emissions related
 - Requests illumination of the Service Lamp or the service message on the Drive Information Center (DIC) on the *first trip* with a fail
 - Stores a History DTC on the *first trip* with a fail
 - Does not store a Freeze Frame
 - Stores Fail Record when test fails
 - Updates the Fail Record each time the diagnostic test fails
- Type D (Type D non-emissions related are not utilized on certain vehicle applications).
 - Non-Emissions related
 - Does not request illumination of any lamp
 - Stores a History DTC on the *first trip* with a fail

- Does not store a Freeze Frame
- Stores Fail Record when test fails
- Updates the Fail Record each time the diagnostic test fails

Only four Fail Records can be stored. Each Fail Record is for a different DTC. It is possible that there will not be Fail Records for every DTC if multiple DTCs are set.

Special Cases of Type B Diagnostic Tests

Unique to the misfire diagnostic, the Diagnostic Executive has the capability of alerting the vehicle operator to potentially damaging levels of misfire. If a misfire condition exists that could potentially damage the catalytic converter as a result of high misfire levels, the Diagnostic Executive will command the MIL to "flash" at a rate of once per seconds during those the time that the catalyst damaging misfire condition is present.

Fuel trim and misfire are special cases of *Type B* diagnostics. Each time a fuel trim or misfire malfunction is detected, engine load, engine speed, and engine coolant temperature are recorded.

When the ignition is turned off, the last reported set of conditions remain stored. During subsequent ignition cycles, the stored conditions are used as reference for similar conditions. If a malfunction occurs during two consecutive trips, the Diagnostic Executive treats the failure as a normal *Type B* diagnostic, and does not use the stored conditions. However, if a malfunction occurs on two non-consecutive trips, the stored conditions are compared with the current conditions. The MIL will then illuminate under the following conditions:

- When the engine load conditions are within 10% of the previous test that failed.
- Engine speed is within 375 rpm, of the previous test that failed.
- Engine coolant temperature is in the same range as the previous test that failed.

Storing and Erasing Freeze Frame Data and Failure Records

Government regulations require that engine operating conditions be captured whenever the MIL is illuminated. The data captured is called Freeze Frame data. The Freeze Frame data is very similar to a single record of operating conditions. Whenever the MIL is illuminated, the corresponding record of operating conditions is recorded to the Freeze Frame buffer.

Freeze Frame data can only be overwritten with data associated with a misfire or fuel trim malfunction. Data from these faults take precedence over data associated with any other fault. The Freeze Frame data will not be erased unless the associated history DTC is cleared.

Each time a diagnostic test reports a failure, the current engine operating conditions are recorded in the *Failure Records* buffer. A subsequent failure will update the recorded operating conditions. The following operating conditions for the diagnostic test which failed *typically* include the following parameters:

- Air Fuel Ratio
- Air Flow Rate
- Fuel Trim
- Engine Speed

- Engine Load
- Engine Coolant Temperature
- Vehicle Speed
- TP Angle
- MAP/BARO
- Injector Base Pulse Width
- Loop Status

Intermittent Malfunction Indicator Lamp


In the case of an "intermittent" fault, the MIL ("Check Engine" lamp) may illuminate and then (after three trips) go "OFF". However, the corresponding diagnostic trouble code will be stored in the memory. When unexpected diagnostic trouble codes appear, check for an intermittent malfunction.

A diagnostic trouble code may reset. Consult the "Diagnostic Aids" associated with the diagnostic trouble code. A physical inspection of the applicable sub-system most often will resolve the problem.

Data Link Connector (DLC)

The provision for communication with the control module is the Data Link Connector (DLC). It is located at the lower left of the instrument panel. The DLC is used to connect to the Tech 2 Scan Tool. Some common uses of the Tech 2 are listed below:

- Identifying stored Diagnostic Trouble Codes (DTCs).
- Clearing DTCs.
- Performing output control tests.
- Reading serial data.



TS24064

Decimal/Binary/Hexadecimal Conversions

Beginning in 1996, Federal Regulations require that all auto manufacturer selling vehicles in the United States provide Scan Tool manufacturers with software information to display vehicle operating parameters. All Scan Tool manufacturers will display a variety of vehicle information which will aid in repairing the vehicle. Some scan tools will display encoded messages which will aid in

determining the nature of the concern. The method of encoding involves the use of a two additional numbering systems: Binary and Hexadecimal.

The binary number system has a base of two numbers. Each digit is either a 0 or a 1. A binary number is an eight digit number and is read from right to left. Each digit has a position number with the farthest right being the 0 position and the farthest left being the 7 position. The 0 position, when displayed by a 1, indicates 1 in decimal. Each position to the left is double the previous position and added to any other position values marked as a 1.

A hexadecimal system is composed of 16 different alpha numeric characters. The alpha numeric characters used are numbers 0 through 9 and letters A through F. The hexadecimal system is the most natural and common approach for Scan Tool manufacturers to display data represented by binary numbers and digital code.

Verifying Vehicle Repair

Verification of vehicle repair will be more comprehensive for vehicles with OBD II system diagnostic. Following a repair, the technician should perform the following steps:

1. Review and record the Fail Records and/or Freeze Frame data for the DTC which has been diagnosed (Freeze Frame data will only be stored for an A or B type diagnostic and only if the MIL has been requested).
2. Clear DTC(s).
3. Operate the vehicle within conditions noted in the Fail Records and/or Freeze Frame data.
4. Monitor the DTC status information for the DTC which has been diagnosed until the diagnostic test associated with that DTC runs.

Following these steps are very important in verifying repairs on OBD II systems. Failure to follow these steps could result in unnecessary repairs.

Reading Diagnostic Trouble Codes Using the TECH 2 Scan Tool

The procedure for reading diagnostic trouble code(s) is to use a diagnostic Scan Tool. When reading DTC(s), follow instructions supplied by tool manufacturer.

For the 1998 model year, Isuzu dealer service departments will continue to use Tech II.

Clearing Diagnostic Trouble Codes

IMPORTANT: Do not clear DTCs unless directed to do so by the service information provided for each diagnostic procedure. When DTCs are cleared, the Freeze Frame and Failure Record data which may help diagnose an intermittent fault will also be erased from memory.

If the fault that caused the DTC to be stored into memory has been corrected, the Diagnostic Executive will begin to count the "warm-up" cycles with no further faults detected, the DTC will automatically be cleared from the PCM memory.

To clear Diagnostic Trouble Codes (DTCs), use the diagnostic Scan Tool "clear DTCs" or "clear information" function. When clearing DTCs follow instructions supplied by the tool manufacturer.


When a Tech 2 is not available, DTCs can also be cleared by disconnecting *one* of the following sources for at least thirty (30) seconds.

NOTE: To prevent system damage, the ignition key must be "OFF" when disconnecting or reconnecting battery power.

- The power source to the control module. Examples: fuse, pigtail at battery PCM connectors etc.
- The negative battery cable. (Disconnecting the negative battery cable will result in the loss of other on-board memory data, such as preset radio tuning).

Tech 2

From 98 MY, Isuzu dealer service departments are recommended to use the Tech 2 Scan Tool. Please refer to the Tech 2 user guide.



Legend

- (1) PCMCIA Card
- (2) RS 232 Loop Back Connector

- (3) SAE 16/19 Adaptor
- (4) DLC Cable
- (5) Tech-2


901RW180

Tech 2 Features

1. Tech 2 is a 12 volt system. Do not apply 24 volt.
2. After connecting and/or installing, the Vehicle Communications Interface (VCI) module, PCMCIA card and DLC connector to the Tech 2, connect the tool to the vehicle DLC.
3. Make sure the Tech 2 is powered OFF when removing or installing the PCMCIA card.
4. The PCMCIA card has a capacity of 10 Megabytes which is 10 times greater than the memory of the Tech 1 Mass Storage Cartridge.
5. The Tech 2 has the capability of two snapshots.
6. The PCMCIA card is sensitive to magnetism and static electricity, so care should be taken in the handling of the card.
7. The Tech 2 can plot a graph when replaying a snapshot.
8. Always return to the Main Menu by pressing the EXIT key several times before shutting down.
9. To clear Diagnostic Trouble Codes (DTCs), open Application Menu and press "F1: Clear DTC Info".

Getting Started

- Before operating the Isuzu PCMCIA card with the Tech 2, the following steps must be performed:
 1. The Isuzu 98 System PCMCIA card (1) inserts into the Tech 2 (5).
 2. Connect the SAE 16/19 adapter (3) to the DLC cable (4).
 3. Connect the DLC cable to the Tech 2 (5)
 4. Make sure the vehicle ignition is off.
 5. Connect the Tech 2 SAE 16/19 adapter to the vehicle DLC.



6. Turn on the vehicle ignition.

7. Power the Tech 2 ON and Verify the Tech 2 power up display.




060RW009

NOTE: The RS232 Loop back connector is only to use for diagnosis of Tech 2. Refer to user guide of the Tech 2.


740RW060

Operating Procedure (For Example)

The power up screen is displayed when you power up the tester with the Isuzu systems PCMCIA card. Follow the operating procedure below.




060RX060




060RX059

Menu

- ☐ The following table shows which functions are used for the available equipment versions.




DTC Modes



On OBD II vehicles there are five options available in Tech 2 DTC mode to display the enhanced information available. After selecting DTC, the following menu appears:

- ☐ DTC Info
- ☐ Freeze Frame
- ☐ Fail Records (not all applications)


- ☐ Clear Info



The following is a brief description of each of the sub menus in DTC Info and DTC. The order in which they appear here is alphabetical and not necessarily the way they will appear on the Tech 2.

DTC Information Mode

Use the DTC info mode to search for a specific type of stored DTC information. There are six choices. The service manual may instruct the technician to test for DTCs in a certain manner. Always follow published service procedures.



DTC Status

This selection will display any DTCs that have not run during the current ignition cycle or have reported a test failure during this ignition up to a maximum of 33 DTCs. DTC tests which run and pass will cause that DTC number to be removed from Tech 2 screen.

Fail This Ignition

This selection will display all DTCs that have failed during the present ignition cycle.

History

This selection will display only DTCs that are stored in the PCM's history memory. It will display all type A and B DTCs that have requested the MIL and have failed within the last 40 warm-up cycles. In addition, it will display all type C and type D DTCs that have failed within the last 40 warm-up cycles.

Last Test Failed

This selection will display only DTCs that have failed the last time the test ran. The last test may have run during a previous ignition cycle if a type A or type B DTC is displayed. For type C and type D DTCs, the last failure must have occurred during the current ignition cycle to appear as Last Test Fail.

MILSVC or Message Request

This selection will display only DTCs that are requesting the MIL. Type C and type D DTCs cannot be displayed using this option. This selection will report type B DTCs only after the MIL has been requested.

Not Run Since Code Cleared

This option will display up to 33 DTCs that have not run since the DTCs were last cleared. Since any displayed DTCs have not run, their condition (passing or failing) is unknown.

Test Failed Since Code Cleared

This selection will display all active and history DTCs that have reported a test failure since the last time DTCs were cleared. DTCs that last failed more than 40 warm-up cycles before this option is selected will not be displayed.

Miscellaneous Test

This test consists of eight menus-Lights, Relays, EVAP, IAC System, Fuel System, EGR Control, Variable Intake Manifold Solenoid, and Injector Balance Tests.

In these tests, Tech 2 sends operating signals to the systems to confirm their operations thereby to judge the normality of electric circuit.

To judge intermittent trouble,

1. Confirm DTC freeze frame data, and match the freeze frame data as test conditions with the data list displayed by Miscellaneous Test.
2. Confirm DTC setting conditions, and match the setting conditions as test conditions with the data list displayed by Miscellaneous Test.

3. Refer to the latest Service Bulletin.

Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.


Lamps Test

This test is conducted check MIL and Low Fuel Lamp for its working.

Tech2 must be used for this test.


Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.



060RW228

4. Select F0:Lamps Test in the Miscellaneous Test.



060RX035

5. Select F0:Malfunction Indicator Lamp.

Malfunction Indicator Lamp	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Malfunction Indicator Lamp Off	
Quit	Off On

060RX019

6. Push "On" soft key.

7. Make sure Lamp illuminates.

8. If lamp illuminates, the Lamp is operating correctly.

9. Select F1:Low Fuel Lamp

Low Fuel Lamp	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Low Fuel Lamp	Off
Quit	Off On

060RX020

10. Push "On" soft key.

11. Make sure Lamp illuminates.

12. If Lamp illuminates, the Lamp is operating correctly.

Relays Test

This test is conducted to check Fuel Pump Relay and A/C Clutch for proper operation.

Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Ignition SW is "On".

3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu
F0 : Diagnostic Trouble Codes
F1 : Data Display
F2 : Snapshot
F3 : Miscellaneous Test


060RW228

4. Select F1:Relay Test in the Miscellaneous Test.

Miscellaneous Test
F0 : Lamps
F1 : Relays
F2 : EVAP
F3 : IAC System
F4 : Fuel System
F5 : EGR Control
F6 : Variable Intake Manifold Solenoid
F7 : Injector Balance Test


060RX034

5. Select F0:Fuel Pump Relay.



060RX021

6. Push "On" soft key.



060RX022

7. Control Fuel Pump Relay and check data list.

8. If the data list changes, the Fuel Pump Relay is normal.

9. Select F1:A/C Clutch Relay.

10. *Run the Engine at idle.

11. Turn on Air Conditioning.



060RX023

12. Push "On" and "Off" soft keys.

13. Control A/C Clutch Relay and check data list.


14. If the data list changes, the A/C Clutch Relay is normal.

EVAP Test

This test is conducted check EVAP system for its working. Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.



060RW228

4. Select F2:EVAP Test in the Miscellaneous Test.

Miscellaneous Test
F0 : Lamps
F1 : Relays
F2 : EVAP
F3 : IAC System
F4 : Fuel System
F5 : EGR Control
F6 : Variable Intake Manifold Solenoid
F7 : Injector Balance Test

060RX036

5. Select F0: Purge Solenoid.

EVAP
F0 : Purge Solenoid
F1 : Vent Solenoid

060RX025

6. Push "Decrease" or "Increase" soft key.

Purge Solenoid	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
EVAP Purge Solenoid	60%
Quit	Decrease Increase

060RX026

7. Control EVAP Purge Solenoid and check data list.

8. If the data list changes, the Purge Solenoid is normal.

9. Turn engine off, turn ignition SW "On".

10. Select F1:EVAP Vent Solenoid.

EVAP
F0 : Purge Solenoid
F1 : Vent Solenoid

060RX025

11. Push "On" or "Off" soft key.

Vent Solenoid	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
EVAP Vent Solenoid	OFF
Quit	Off On

060RX027

12. Control EVAP Vent Solenoid and check data list.

13. If the data list changes, the EVAP Vent Solenoid is normal.

Idle Air Control System Test

This test is conducted to check IAC system for proper operation.

Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu	
F0 : Diagnostic Trouble Codes	
F1 : Data Display	
F2 : Snapshot	
F3 : Miscellaneous Test	

060RW228

4. Select F3: IAC System Test in the Miscellaneous Test.

Miscellaneous Test	
F0 : Lamps	
F1 : Relays	
F2 : EVAP	
F3 : IAC System	
F4 : Fuel System	
F5 : EGR Control	
F6 : Variable Intake Manifold Solenoid	
F7 : Injector Balance Test	

060RX007

5. Select F1: IAC Control Test.

Application Menu	
F0 : RPM Control	
F1 : IAC Control	
F2 : IAC Reset	

060RW235

6. Push "Increase" or "Decrease" soft key.

6E2-44 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

7. Instruct IAC system and check data list.

IAC Control	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Idle Air Control	21 Steps
Quit	Decrease Increase

060RX015

8. If the data list changes, the IAC control is normal.

9. Select F0: RPM Control Test

RPM Control	
Engine Speed	1000 RPM
Desired Idle Speed	1000 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Desired Idle Speed	750 RPM
Quit	Decrease Increase

060RX016

10. Push "Increase" or "Decrease" soft key.

11. Control RPM and check data list.

12. If the data list changes, the RPM control is normal.

13. Select F2: IAC Reset.

14. Push "Reset IAC" soft key.

15. Control IAC Reset and check data list.

16. If data list changes, the IAC has been Reset.

IAC Reset	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Idle Air Control	21 Steps
Quit	Reset IAC

060RW231-1

Fuel System Test

This test is conducted check Fuel Level Gauge for proper operation.

Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Ignition SW is "On".
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu
F0 : Diagnostic Trouble Codes
F1 : Data Display
F2 : Snapshot
F3 : Miscellaneous Test

060RW228

4. Select F4: Fuel System in the Miscellaneous Menu.

Miscellaneous Test
F0 : Lamps
F1 : Relays
F2 : EVAP
F3 : IAC System
F4 : Fuel System
F5 : EGR Control
F6 : Variable Intake Manifold Solenoid
F7 : Injector Balance Test

060RX032

6. Push "Decrease" or "Increase" soft key.

Fuel Gauge Level	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Tenperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Fuel Level	50%
Quit	Decrease Increase

060RX030

5. Select F1: Fuel Gauge Level

Fuel System
F0 : Fuel Trim Reset
F1 : Fuel Gauge Level

060RX028

7. Control Fuel Level and check data list.

8. If data list chougues the Fuel Gauge Level is normal.

9. Select F0: Fuel Trim Reset.

Fuel System
F0 : Fuel Trim Reset
F1 : Fuel Gauge Level

060RX028

10. Push "Reset" soft key.

Fuel Trim Reset	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperatur	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Fuel Level	50%
Quit	Reset

060RX029

EGR Control Test

This test is conducted check EGR valve for proper operation.

Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.

Application Menu	
F0 : Diagnostic Trouble Codes	
F1 : Data Display	
F2 : Snapshot	
F3 : Miscellaneous Test	

060RW228

4. Select F5: EGR Control Test in the Miscellaneous Test.

Miscellaneous Test	
F0 : Lamps	
F1 : Relays	
F2 : EVAP	
F3 : IAC System	
F4 : Fuel System	
F5 : EGR Control	
F6 : Variable Intake Manifold Solenoid	
F7 : Injector Balance Test	

060RX008

5. Control EGR Valve and check data list.

EGR Control	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperatur	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Desired EGR Position	0%
Quit	Decrease Increase

060RX017

6. If data list changes, the EGR Control is normal.

Variable Intake Manifold Solenoid Test


This test is conducted check VIM Solenoid for proper operation.

Tech 2 must be used for this test.

Test Procedure:


1. Connect Tech 2 to the vehicle DLC.
2. Ignition SW is "On".

3. Select F3: Miscellaneous Test in the Application Menu.




060RW228

4. Select F6: Variable Intake Manifold Solenoid Test.



060RX033

5. Push "On" or "Off" soft key.



060RX028

6. Control VIM Solenoid and check data list.


7. If data list changes, the VIM Solenoid is normal.

Injector Balance Test

This test is conducted to make sure the appropriate electric signals are being sent to injectors Nos. 1-6. Tech 2 must be used for this test.

Test Procedure:

1. Connect Tech 2 to the vehicle DLC.
2. Run the Engine at idle.
3. Select F3: Miscellaneous Test in the Application Menu.



060RW228

4. Select F7: Injector Balance Test in the Miscellaneous Test.

Miscellaneous Test	
F0 :	Lamps
F1 :	Relays
F2 :	EVAP
F3 :	IAC System
F4 :	Fuel System
F5 :	EGR Control
F6 :	Variable Intake Manifold Solenoid
F7 :	Injector Balance Test

060RX006

5. Select injector number and push "injector off" of soft key.

Injector Balance Test	
Engine Speed	750 RPM
Desired Idle Speed	750 RPM
Engine Coolant Temperat	75 °C
Start Up ECT(Engine Co	20 °C
Intake Air Temperature	20 °C
Start Up IAT(Intake Ai	20 °C
Manifold Absolute Press	19 KPa
Injector 1	On
Quit	Injector OFF
	Select injector

060RW230-1


6. Make sure of engine speed change.

7. If engine speed changes, the injector electric circuit is normal.

If engine speed does not changes, the injector electric circuit or the injector itself is not normal.

Plotting Snapshot Graph


This test selects several necessary items from the data list to plot graphs and makes data comparison on a long term basis. It is an effective test particularly in emission related evaluations.




060RX037

For trouble diagnosis, you can collect graphic data (snapshot) directly from the vehicle. You can replay the snapshot data as needed. Therefore, accurate diagnosis is possible, even though the vehicle is not available.

Plotting Graph Flow Chart (Plotting graph after obtaining vehicle information)



Flow Chart for Snapshot Replay (Plotting Graph)



To upload Snapshots to a PC and Download Diagnostic Software from a CD ROM Disk

Both these functions are driven from the PC with instructions shown on the PC Monitor.

The procedure:

1. Power off Tech 2.
2. Connect RS232 cable between Tech 2 and the PC.
3. Power up Tech 2, Main Title screen will show, do not move on the main menu.
4. Access functionality on PC and obey instructions.

Primary System-Based Diagnostics

Primary System-Based Diagnostics

There are primary system-based diagnostics which evaluate system operation and its effect on vehicle emissions. The primary system-based diagnostics are listed below with a brief description of the diagnostic function:

Oxygen Sensor Diagnosis

The fuel control heated oxygen sensors (Bank 1 HO2S 1 and Bank 2 HO2S 1) are diagnosed for the following conditions:

- ☐ Heater performance (time to activity on cold start)
- ☐ Slow response
- ☐ Response time (time to switch R/L or L/R)
- ☐ Inactive signal (output steady at bias voltage – approx. 450 mV)
- ☐ Signal fixed high
- ☐ Signal fixed low

The catalyst monitor heated oxygen sensors (Bank 1 HO2S 2 and Bank 2 HO2S 2) are diagnosed for the following conditions:

- ☐ Heater performance (time to activity on cold start).
- ☐ Signal fixed low during steady state conditions or power enrichment (hard acceleration when a rich mixture should be indicated).
- ☐ Signal fixed high during steady state conditions or deceleration mode (deceleration when a lean mixture should be indicated).
- ☐ Inactive sensor (output steady at approx. 438 mV).

If the oxygen sensor pigtail wiring, connector or terminal are damaged, the entire oxygen sensor assembly must be replaced. DO NOT attempt to repair the wiring, connector or terminals. In order for the sensor to function properly, it must have clean reference air provided to it. This clean air reference is obtained by way of the oxygen sensor wire(s). Any attempt to repair the wires, connector or terminals could result in the obstruction of the reference air and degrade oxygen sensor performance. Refer to *On-Vehicle Service Heated Oxygen Sensors*.

Fuel Control Heated Oxygen Sensors


The main function of the fuel control heated oxygen sensors is to provide the control module with exhaust stream oxygen content information to allow proper fueling and maintain emissions within mandated levels. After it

reaches operating temperature, the sensor will generate a voltage, inversely proportional to the amount of oxygen present in the exhaust gases. The control module uses the signal voltage from the fuel control heated oxygen sensors while in closed loop to adjust fuel injector pulse width. While in closed loop, the PCM can adjust fuel delivery to maintain an air/fuel ratio which allows the best combination of emission control and driveability. The fuel control heated oxygen sensors are also used to determine catalyst efficiency.

HO2S Heater

Heated oxygen sensors are used to minimize the amount of time required for closed loop fuel control to begin operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors (Bank 1 HO2S 1 and Bank2 HO2S 1) to become active. Oxygen sensor heaters are required by catalyst monitor and sensors (Bank 1 HO2S 2 and Bank 2 HO2S 2) to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further away from the engine.

Catalyst Monitor Heated Oxygen Sensors and Diagnostic Operation



TS24067

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NOx, converting it to nitrogen. The PCM has the ability to monitor this process using the pre-catalyst and post-catalyst heated oxygen sensors. The pre-catalyst sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The post-catalyst sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is

operating efficiently, the pre-catalyst signal will be far more active than that produced by the post-catalyst sensor.

In addition to catalyst monitoring, the heated oxygen sensors have a limited role in controlling fuel delivery. If the sensor signal indicates a high or low oxygen content for an extended period of time while in closed loop, the PCM will adjust the fuel delivery slightly to compensate.

- For the 3.2L, the pre-catalyst sensors are designated Bank 1 HO2S 1 and Bank 2 HO2S 1. The post-catalyst sensors are Bank 1 HO2S 2 and Bank 2 HO2S 2.

Catalyst Monitor Outputs

The catalyst monitor diagnostic is sensitive to the following conditions:

- Exhaust leaks
- HO2S contamination
- Alternate fuels

Exhaust system leaks may cause the following:

- Preventing a degraded catalyst from failing the diagnostic.
- Causing a false failure for a normally functioning catalyst.
- Preventing the diagnostic from running.

Some of the contaminants that may be encountered are phosphorus, lead, silica, and sulfur. The presence of these contaminants will prevent the TWC diagnostic from functioning properly.

Three-Way Catalyst Oxygen Storage Capacity

The Three-Way catalyst (TWC) must be monitored for efficiency. To accomplish this, the control module monitors the pre-catalyst HO2S and post-catalyst HO2S oxygen sensors. When the TWC is operating properly, the post-catalyst oxygen sensor will have significantly less activity than the pre-catalyst oxygen sensor. The TWC stores and releases oxygen as needed during its normal reduction and oxidation process. The control module will calculate the oxygen storage capacity using the difference between the pre-catalyst and post catalyst oxygen sensor's voltage levels. If the activity of the post-catalyst oxygen sensor approaches that of the pre-catalyst oxygen sensor, the catalyst's efficiency is degraded.

Stepped or staged testing level allow the control module to statistically filter test information. This prevents falsely passing or falsely failing the oxygen storage capacity test. The calculations performed by the on-board diagnostic system are very complex. For this reason, post catalyst oxygen sensor activity should not be used to determine oxygen storage capacity unless directed by the service manual.

Two stages are used to monitor catalyst efficiency. Failure of the first stage will indicate that the catalyst requires further testing to determine catalyst efficiency. The second stage then looks at the inputs for the pre and post catalyst HO2S sensors more closely before determining if the catalyst is indeed degraded. This further statistical processing is done to increase the accuracy of oxygen storage capacity type monitoring. Failing the first (stage 1) test DOES NOT indicate a failed catalyst. The catalyst may be marginal or the fuel sulfur content could be very high.

Aftermarket HO2S characteristics may be different from the original equipment manufacturer sensor. This may lead to a false pass or a false fail of the catalyst monitor diagnostic. Similarly, if an aftermarket catalyst does not contain the same amount of cerium as the original part, the correlation between oxygen storage and conversion efficiency may be altered enough to set a false DTC.

Misfire Monitor Diagnostic Operation

Misfire Monitor Diagnostic Operation

The misfire monitor diagnostic is based on crankshaft rotational velocity (reference period) variations. The PCM determines crankshaft rotational velocity using the crankshaft position sensor and camshaft position sensor. When a cylinder misfires, the crankshaft slows down momentarily. By monitoring the crankshaft and camshaft position sensor signals, the PCM can calculate when a misfire occurs.

For a non-catalyst damaging misfire, the diagnostic will be required to monitor a misfire present for between 1000-3200 engine revolutions.

For catalyst-damaging misfire, the diagnostic will respond to misfire within 200 engine revolutions.

Rough roads may cause false misfire detection. A rough road will cause torque to be applied to the drive wheels and drive train. This torque can intermittently decrease the crankshaft rotational velocity. This may be falsely detected as a misfire.

On automatic transmission-equipped vehicles, a rough road sensor, works together with the misfire detection system.

Misfire Counters

Whenever a cylinder misfires, the misfire diagnostic counts the misfire and notes the crankshaft position at the time the misfire occurred. These "misfire counters" are basically a file on each engine cylinder. A current and a history misfire counter are maintained for each cylinder. The misfire current counters (Misfire Cur #1-6) indicate the number of firing events out of the last 200 cylinder firing events which were misfires. The misfire current counter will display real time data without a misfire DTC stored. The misfire history counters (Misfire Hist #1-6) indicate the total number of cylinder firing events which were misfires. The misfire history counters will display 0 until the misfire diagnostic has failed and a DTC P0300 is set. Once the misfire DTC P0300 is set, the misfire history counters will be updated every 200 cylinder firing events. A misfire counter is maintained for each cylinder.

If the misfire diagnostic reports a failure, the diagnostic executive reviews all of the misfire counters before reporting DTC. This way, the diagnostic executive reports the most current information.

When crankshaft rotation is erratic, a misfire condition will be detected. Because of this erratic condition, the data that is collected by the diagnostic can sometimes incorrectly identify which cylinder is misfiring. Misfires are counted from more than one cylinder. Cylinder #1 has the majority of counted misfires. In this case, the Misfire Counters would identify cylinder #1 as the misfiring cylinder. The misfires in the other counters were just background noise caused by the erratic misfire rotation of the crankshaft. If the number of accumulated misfires is sufficient for the diagnostic to identify a true misfire, the diagnostic will set DTC P0300 – Misfire Detected.

Use diagnostic equipment to monitor misfire counter data on OBD II-compliant vehicles. Knowing which specific cylinder(s) misfired can lead to the root cause, even when dealing with a multiple cylinder misfire. Using the information in the misfire counters, identify which cylinders are misfiring. If the counter indicate cylinders numbers 1 and 4 misfired, look for a circuit or component common to both cylinders number 1 and 4.

Misfire counter information is located in the “Specific Eng.” menu, “Misfire Data” sub-menu of the data list.

The misfire diagnostic may indicate a fault due to a temporary fault not necessarily caused by a vehicle emission system malfunction. Examples include the following items:

- ☐ Contaminated fuel
- ☐ Low fuel
- ☐ Fuel-fouled spark plugs
- ☐ Basic engine fault

Fuel Trim System Monitor Diagnostic Operation

Fuel Trim System Monitor Diagnostic Operation

This system monitors the averages of short-term and long-term fuel trim values. If these fuel trim values stay at their limits for a calibrated period of time, a malfunction is indicated. The fuel trim diagnostic compares the averages of short-term fuel trim values and long-term fuel trim values to rich and lean thresholds. If either value is within the thresholds, a pass is recorded. If both values are outside their thresholds, a rich or lean DTC will be recorded.

The fuel trim system diagnostic also conducts an intrusive test. This test determines if a rich condition is being caused by excessive fuel vapor from the EVAP canister. In order to meet OBD II requirements, the control module uses weighted fuel trim cells to determine the need to set a fuel trim DTC. A fuel trim DTC can only be set if fuel trim counts in the weighted fuel trim cells exceed specifications. This means that the vehicle could have a fuel trim problem which is causing a problem under certain conditions (i.e., engine idle high due to a small vacuum leak or rough idle due to a large vacuum leak) while it operates fine at other times. No fuel trim DTC


would set (although an engine idle speed DTC or HO2S DTC may set). Use the Tech 2 to observe fuel trim counts while the problem is occurring.

A fuel trim DTC may be triggered by a number of vehicle faults. Make use of all information available (other DTCs stored, rich or lean condition, etc.) when diagnosing a fuel trim fault.

Fuel Trim Cell Diagnostic Weights

No fuel trim DTC will set regardless of the fuel trim counts in cell 0 unless the fuel trim counts in the weighted cells are also outside specifications. This means that the vehicle could have a fuel trim problem which is causing a problem under certain conditions (i.e. engine idle high due to a small vacuum leak or rough due to a large vacuum leak) while it operates fine at other times. No fuel trim DTC would set (although an engine idle speed DTC or HO2S DTC may set). Use the Tech 2 to observe fuel trim counts while the problem is occurring.

On-Board Diagnostic (OBD II) System Check



D06RX010

Circuit Description

The on-board diagnostic system check is the starting point for any driveability complaint diagnosis. Before using this procedure, perform a careful visual/physical check of the PCM and engine grounds for cleanliness and tightness.

The on-board diagnostic system check is an organized approach to identifying a problem created by an electronic engine control system malfunction.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for poor connections or a damaged harness. Inspect the PCM harness and connector for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

1. The MIL ("Check Engine" lamp) should be "ON" steady with the ignition "ON"/engine "OFF." If not, the "No MIL" chart should be used to isolate the malfunction.
2. Checks the Class 2 data circuit and ensures that the PCM is able to transmit serial data.
3. This test ensures that the PCM is capable of controlling the MIL ("Check Engine" lamp) and the MIL ("Check Engine" lamp) driver circuit is not shorted to ground.
4. If the engine will not start, the *Cranks But Will Not Run* chart should be used to diagnose the condition.
7. A Tech 2 parameter which is not within the typical range may help to isolate the area which is causing the problem.

10. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is replaced, the new PCM must be programmed. *Refer to PCM Replacement and Programming Procedures in Powertrain Control Module (PCM) and Sensors.*


On- Board Diagnostic (OBD II) System Check

Step	Action	Value(s)	Yes	No
1	1. Ignition "ON," engine "OFF." 2. Observe the malfunction indicator lamp (MIL or "Check Engine lamp"). Is the MIL ("Check Engine lamp") "ON?"	—	Go to Step 2	Go to No MIL ("Check Engine" lamp)
2	1. Ignition "OFF." 2. Install Tech 2. 3. Ignition "ON." 4. Attempt to display PCM engine data with the Tech 2. Does the Tech 2 display PCM data?	—	Go to Step 3	Go to Step 8
3	1. Using the Tech 2 output tests function, select MIL ("Check Engine lamp") dash lamp control and command the MIL ("Check Engine lamp") "OFF." (Refer to Miscellaneous Test) 2. Observe the MIL ("Check Engine lamp"). Did the MIL ("Check Engine lamp") turn "OFF?"	—	Go to Step 4	Go to MIL ("Check Engine" lamp) On Steady
4	Attempt to start the engine. Did the engine start and continue to run?	—	Go to Step 5	Go to Cranks But Will Not Run
5	Select "Display DTCs" with the Tech 2. Are any DTCs stored?	—	Go to Step 6	Go to Step 7
6	Are two or more of the following DTCs stored? P0107, P0108, P0113, P0118, P0122, P0123, P0712, P1406.	—	Go to "Multiple PCM Information Sensor DTCs Set"	Go to applicable DTC table
7	Compare PCM data values displayed on the Tech 2 to the typical engine scan data values. Are the displayed values normal or close to the typical values?	—	Go to Symptom	Refer to indicated Component System Checks
8	1. Ignition "OFF," disconnect the PCM. 2. Ignition "ON," engine "OFF." 3. Check the Class 2 data circuit for an open, short to ground, or short to voltage. Also, check the DLC ignition feed circuit for an open or short to ground and the DLC ground circuit for an open. 4. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 2	Go to Step 9

On- Board Diagnostic (OBD II) System Check (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Attempt to reprogram the PCM. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. 2. Attempt to display PCM data with the Tech 2. Does the Tech 2 display PCM engine data?	—	Go to <i>Step 2</i>	Go to <i>Step 10</i>
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to <i>Step 2</i>	—

A/C Clutch Control Circuit Diagnosis



Circuit Description

When air conditioning and blower fan are selected, and if the system has a sufficient refrigerant charge, a 12-volt signal is supplied to the A/C request input of the powertrain control module (PCM). The A/C request signal may be temporarily canceled during system operation by the electronic thermostat in the evaporator case. The electronic thermostat may intermittently remove the control circuit ground for the A/C thermostat relay to prevent the evaporator from forming ice. When the A/C request signal is received by the PCM, the PCM supplies a ground from the compressor clutch relay if the engine operating conditions are within acceptable ranges. With the A/C compressor relay energized, voltage is supplied to the compressor clutch coil. The PCM will enable the compressor clutch to engage whenever A/C has been selected with the engine running, unless any of the following conditions are present:

- The throttle is greater than 90%.
- The ignition voltage is below 10.5 volts.
- The engine speed is greater than 4500 RPM for 5 seconds or 5400 RPM.
- The engine coolant temperature (ECT) is greater than 125 °C (257 °F).
- The intake air temperature (IAT) is less than 5 °C (41 °F).
- The power steering pressure switch signals a high pressure condition.

Diagnostic Aids

To diagnose an intermittent fault, check for the following conditions:

- Poor connection at the PCM—Inspect connections for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness—Inspect the wiring harness for damage. If the harness appears to OK, observe the A/C clutch while moving connectors and wiring harnesses related to the A/C. A sudden clutch malfunction will indicate the source of the intermittent fault.

A/C Clutch Diagnosis

This chart should be used for diagnosing the electrical portion of the A/C compressor clutch circuit. A Tech 2 will be used in diagnosing the system. The Tech 2 has the ability to read the A/C request input to the PCM. The Tech 2 can display when the PCM has commanded the A/C clutch "ON." The Tech 2 should have the ability to override the A/C request signal and energize the A/C compressor relay.

Test Description

IMPORTANT: Do not engage the A/C compressor clutch with the engine running if an A/C mode is not selected at the A/C control switch.

The numbers below refer to the step numbers on the Diagnostic Chart:

3. This a test determine is the problem is with the refrigerant system. If the switch is open, A/C pressure gauges will be used to determine if the pressure switch is faulty or if the system is partially discharged or empty.
4. Although the normal complaint will be the A/C clutch failing to engage, it is possible for a short circuit to cause the clutch to run when A/C has not been selected. This step is a test for that condition.
7. There is an extremely low probability that both relays will fail at the same time, so the substitution process is one way to check the A/C Thermostat relay. Use a known good relay to do a substitution check.
9. The blower system furnishes a ground for the A/C control circuit, and it also shares a power source through the Heater and A/C Relay. The blower must be "ON" in order to test the A/C system.

A/C Clutch Control Circuit Diagnosis

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any other DTCs stored?	—	Go to the other DTC chart(s) first	Go to Step 3
3	1. Disconnect the electrical connector at the pressure switch located on the receiver/drier. 2. Use an ohmmeter to check continuity across the pressure switch (BRN to GRN/WHT). Is the pressure switch open?	—	Go to Air Conditioning to diagnose the cause of the open pressure switch	Go to Step 4

A/C Clutch Control Circuit Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
4	IMPORTANT: Before continuing with the diagnosis, the following conditions must be met: <ul style="list-style-type: none"> ○ The intake air temperature must be greater than 15°C. (60°F). ○ The engine coolant temperature must be less than 119°C (246°F). 1. A/C "OFF." 2. Start the engine and idle for 1 minute. 3. Observe the A/C compressor. Is the A/C compressor clutch engaged even though A/C has not been requested?	—	Go to Step 45	Go to Step 5
5	1. Idle the engine. 2. A/C "ON". 3. Blower "ON". 4. Observe the A/C compressor. Is the A/C compressor magnetic clutch engaged?	—	Refer to <i>Diagnostic Aids</i>	Go to Step 6
6	1. Engine idling. 2. A/C "ON". 3. Blower "ON". 4. Observe the "A/C Request" display on the Tech 2. (Refer to the miscellaneous test) Does the "A/C Request" display indicate "Yes?"	—	Go to Step 34	Go to Step 7
7	Temporarily substitute the A/C compressor relay in place of the A/C thermostat relay, then repeat Step 5. Did the "A/C Request" display indicate "Yes?"	—	Go to Step 8	Go to Step 9
8	Replace the original A/C thermostat relay. Is the action complete?	—	Verify repair	—
9	Dose the blower operate?	—	Go to Step 10	Go to Step 11
10	Repair the blower. Is the action complete?	—	Verify repair	—
11	Check for a faulty 10A A/C fuse in the passenger compartment fuse panel. Was the 10A fuse OK?	—	Go to Step 13	Go to Step 12
12	Check for short circuit and make repairs if necessary. Replace the 10A A/C fuse. Is the action complete?	—	Verify repair	—
13	1. Ignition "ON." 2. Use a DVM to check voltage at the positive A/C switch wire (BRN). Was voltage equal to the specified value?	B+	Go to Step 15	Go to Step 14
14	Repair the open wire (BRN) between the A/C switch and the A/C fuse. Is the action complete?	—	Verify repair	—

A/C Clutch Control Circuit Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
15	1. Remove the glove box to gain access to the A/C thermostat. 2. Disconnect the thermostat connector. 3. Attach a fused jumper between ground and the GRN/RED wire at the thermostat. 4. A/C "ON." 5. Blower "ON." Does A/C request indicate "YES" on the Tech 2?	—	Go to Step 16	Go to Step 23
16	1. Ignition "ON." 2. A/C switch "ON". 3. Use a DVM to check voltage at the electronic A/C thermostat. Was voltage equal to the specified value?	B+	Go to Step 20	Go to Step 17
17	Check for an open (LT GRN/BLK) wire between the thermostat and the A/C switch. Was the wire open?	—	Go to Step 18	Go to Step 19
18	Repair the open wire (LT GRN/BLK) between the thermostat and the A/C switch. Is the action complete?	—	Verify repair	—
19	Replace the A/C switch. Is the action complete?	—	Verify repair	—
20	Use an ohmmeter to check continuity between the electronic A/C thermostat and the blower switch. Was there an open circuit?	—	Go to Step 21	Go to Step 22
21	Repair the open wire (WHT) between the thermostat and the blower switch. Is the action complete?	—	Verify repair	—
22	Replace the electronic A/C thermostat. Is the an action complete?	—	Verify repair	—
23	Check for an open circuit between A/C thermostat relay and PCM A/C request terminal (E-15). Was there an open circuit?	—	Go to Step 24	Go to Step 25
24	Repair the open circuit between the PCM and A/C thermostat relay. Is the action complete?	—	Verify repair	—
25	Check for an open circuit between the engine device fuse and the A/C thermostat relay (WHT/GRN). Was there an open circuit?	—	Go to Step 26	Go to Step 27
26	Repair the open circuit between the engine device fuse and the A/C thermostat relay. Is the action complete?	—	Verify repair	—
27	1. Ignition "ON." 2. Use a DVM to check voltage at the A/C pressure switch (BRN). Was voltage equal to the specified value?	B+	Go to Step 29	Go to Step 28

A/C Clutch Control Circuit Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
28	Repair the open circuit between the 10A A/C fuse and the pressure switch. Is the action complete?	—	Verify repair	—
29	Use an ohmmeter to check continuity between the pressure switch (GRN/WHT) and the A/C thermostat relay (GRN/WHT). Was the circuit open?	—	Go to Step 30	Go to Step 31
30	Repair the open circuit between the pressure switch and the A/C thermostat relay. Is the action complete?	—	Verify repair	—
31	Check for damaged pin or terminal at E-15 of the PCM. Was a damaged pin or terminal found?	—	Go to Step 32	Go to Step 33
32	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
33	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
34	1. Remove the A/C compressor relay. 2. Ignition "ON." 3. Use a DVM to check voltage at both of the BRN wires at the A/C compressor relay socket. Is the voltage equal to the specified value?	B+	Go to Step 36	Go to Step 35
35	Repair the faulty BRN wire between the A/C fuse and the A/C compressor relay . Is the action complete?	—	Verify repair	—
36	1. A/C compressor relay removed. 2. Engine idling. 3. A/C "ON." 4. Blower "ON." 5. Use a DVM to measure voltage between the GRY/RED wire at the A/C compressor relay socket and battery+. Did the DVM indicate the specified value?	B+	Go to Step 40	Go to Step 37
37	Check for an open GRY/RED wire between PCM terminal B-14 and the A/C compressor relay. Was the wire open?	—	Go to Step 38	Go to Step 39
38	Repair the open GRY/RED wire between the PCM and the A/C compressor relay. Is the action complete?	—	Verify repair	—

A/C Clutch Control Circuit Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
39	Check for a damaged pin or terminal at B-14 of the PCM. Was a damaged pin or a terminal found?	—	Go to Step 32	Go to Step 33
40	1. A/C compressor relay removed. 2. Connect a fused jumper at the A/C compressor relay socket between either BRN wire and the BRN/YEL wire. 3. Engine idling. 4. A/C "ON." 5. Blower "ON." Did the compressor magnetic clutch engage?	—	Go to Step 41	Go to Step 42
41	Repair the A/C compressor relay. Is the action complete?	—	Verify repair	—
42	Check for an open circuit between the A/C compressor relay and the A/C clutch. Was an open circuit found?	—	Go to Step 43	Go to Step 44
43	Repair the open circuit between the compressor Clutch and the A/C compressor relay. Is the action complete?	—	Verify repair	—
44	Service the compressor clutch or replace the compressor due to a faulty internal overheat switch. Is the action complete?	—	Verify repair	—
45	1. Remove the A/C compressor relay. 2. Idle the engine. Is the compressor clutch still engaged when A/C is not selected?	—	Go to Step 46	Go to Step 47
46	Repair the short to voltage between the A/C clutch and A/C compressor relay. Is the action complete?	—	Verify repair	—
47	1. Reinstall the A/C compressor relay. 2. Remove the A/C thermostat relay. 3. Engine idling. Is the compressor clutch still engaged when A/C is not selected?	—	Go to Step 48	Go to Step 50
48	Use a DVM to check for a short to ground between the A/C compressor relay and B-14 of the PCM. Was a short detected?	—	Go to Step 49	Go to Step 33
49	Repair the short to ground between the PCM and A/C compressor relay. Is the action complete?	—	Verify repair	—
50	Repair the short to ground between the A/C thermostat relay and the electronic thermostat. Is the action complete?	—	Verify repair	—

Electronic Ignition System Diagnosis

If the engine cranks but will not run or immediately stalls, the Engine Cranks But Will Not Start chart must be used to determine if the failure is the ignition system or the fuel system. If DTC P0300 through P306, P0341, or P0336 is set, the appropriate diagnostic trouble code chart must be used for diagnosis.

If a misfire is being experienced with no DTC set, refer to the *Symptoms* section for diagnosis.

EVAP Canister Purge Solenoid

A continuous purge condition with no purge commanded by the PCM will set a DTC P1441. Refer to the DTC charts for further information.

Visual Check of The Evaporative Emission Canister

- If the canister is cracked or damaged, replace the canister.
- If fuel is leaking from the canister, replace the canister and check hoses and hose routing.

Fuel Metering System Check

Some failures of the fuel metering system will result in an "Engine Cranks But Will Not Run" symptom. If this condition exists, refer to the *Engine Cranks But Will Not Run* chart. This chart will determine if the problem is caused by the ignition system, the PCM, or the fuel pump electrical circuit.

Refer to *Fuel System Electrical Test* for the fuel system wiring schematic.

If there is a fuel delivery problem, refer to *Fuel System Diagnosis*, which diagnoses the fuel injectors, the fuel pressure regulator, and the fuel pump. If a malfunction occurs in the fuel metering system, it usually results in either a rich HO2S signal or a lean HO2S signal. This condition is indicated by the HO2S voltage, which causes the PCM to change the fuel calculation (fuel injector pulse width) based on the HO2S reading. Changes made to the fuel calculation will be indicated by a change in the long term fuel trim values which can be monitored with a Tech 2. Ideal long term fuel trim values are around 0%; for a lean HO2S signal, the PCM will add fuel, resulting in a fuel trim value above 0%. Some variations in fuel trim values are normal because all engines are not exactly the same. If the evaporative emission canister purge is "ON," the long term fuel trim may be as low as -38%. If the fuel trim values are greater than +23%, refer to *DTC P0131, DTC P0151, DTC P0171, and DTC 1171* for items which can cause a lean HO2S signal.

Idle Air Control (IAC) Valve


The Tech 2 displays the IAC pintle position in counts. A count of "0" indicates the PCM is commanding the IAC pintle to be driven all the way into a fully-seated position. This is usually caused by a large vacuum leak.

The higher the number of counts, the more air is being commanded to bypass the throttle blade. Refer to IAC System Check in order to diagnose the IAC system. Refer to *Rough, Unstable, or Incorrect Idle, Stalling* in *Symptoms* for other possible causes of idle problems.

Fuel System Pressure Test

A fuel system pressure test is part of several of the diagnostic charts and symptom checks. To perform this test, refer to *Fuel Systems Diagnosis*.

Fuel Injector Coil Test Procedure and Fuel Injector Balance Test Procedure



T32003

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Relieve the fuel pressure by connecting the J 34730-1 Fuel Pressure Gauge to the fuel pressure connection on the fuel rail.

CAUTION: In order to reduce the risk of fire and personal injury, wrap a shop towel around the fuel pressure connection. The towel will absorb any fuel leakage that occurs during the connection of the fuel pressure gauge. Place the towel in an approved container when the connection of the fuel pressure gauge is complete.

Place the fuel pressure gauge bleed hose in an approved gasoline container.

With the ignition switch "OFF," open the valve on the fuel pressure gauge.

3. Record the lowest voltage displayed by the DVM after the first second of the test. (During the first second, voltage displayed by the DVM may be inaccurate due to the initial current surge.)

Injector Specifications:

Resistance Ohms	Voltage Specification at 10°C-35°C (50°F-95°F)
11.8 – 12.6	5.7 – 6.6

- The voltage displayed by the DVM should be within the specified range.

6E2-64 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS


- The voltage displayed by the DVM may increase throughout the test as the fuel injector windings warm and the resistance of the fuel injector windings changes.
- An erratic voltage reading (large fluctuations in voltage that do not stabilize) indicates an intermittent connection within the fuel injector.

5. Injector Specifications:

Highest Acceptable Voltage Reading Above/Below 35°C/10°C (95°F/50°F)	Acceptable Subtracted Value
9.5 Volts	0.6 Volts

7. The Fuel Injector Balance Test portion of this chart (Step 7 through Step 11) checks the mechanical (fuel delivery) portion of the fuel injector. An engine cool-down period of 10 minutes is necessary in order to avoid irregular fuel pressure readings due to "Hot Soak" fuel boiling.

Injector Coil Test Procedure (Steps 1-6) and Injector Balance Test Procedure (Steps 7-11)



R262001

CYLINDER	1	2	3	4	5	6
1st Reading (1)	296 kPa (43 psi)	296 kPa (43 psi)	296 kPa (43 psi)	296 kPa (43 psi)	296 kPa (43 psi)	296 kPa (43 psi)
2nd Reading (2)	131 kPa (19 psi)	117 kPa (17 psi)	124 kPa (18 psi)	145 kPa (21 psi)	131 kPa (19 psi)	130 kPa (19 psi)
Amount of Drop (1st Reading-2nd Reading)	165 kPa (24 psi)	179 kPa (26 psi)	172 kPa (25 psi)	151 kPa (22 psi)	165 kPa (24 psi)	166 kPa (24 psi)
Av. drop = 166 kPa/24 psi ±10 kPa/1.5 psi = 156- 176 kPa or 22.5- 25.5 psi	OK	Faulty, Rich (Too Much Fuel Drop)	OK	Faulty, Lean (Too Little Fuel Drop)	OK	OK

NOTE: These figures are examples only.

Injector Coil Test Procedure (Steps 1-6) and Injector Balance Test Procedure (Steps 7-11)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	<p>1. Turn the engine "OFF."</p> <p>NOTE: In order to prevent flooding of a single cylinder and possible engine damage, relieve the fuel pressure before performing the fuel injector coil test procedure.</p> <p>2. Relieve the fuel pressure. Refer to <i>Test Description Number 2</i>.</p> <p>3. Connect the J 39021-5V Fuel Injector Tester to B+ and ground, and to the J 39021-90 Injector Switch Box.</p> <p>4. Connect the injector switch box to the grey fuel injector harness connector located at the rear of the air cleaner assembly.</p> <p>5. Set the amperage supply selector switch on the fuel injector tester to the "Coil Test" 0.5 amp position.</p> <p>6. Connect the leads from the J 39200 Digital Voltmeter (DVM) to the injector tester. Refer to the illustrations associated with the test description.</p> <p>7. Set the DVM to the tenths scale (0.0).</p> <p>8. Observe the engine coolant temperature.</p> <p>Is the engine coolant temperature within the specified values?</p>	10°C (50°F) to 35°C (95°F)	Go to Step 3	Go to Step 5
3	<p>1. Set injector switch box injector #1.</p> <p>2. Press the "Push to Start Test" button on the fuel injector tester.</p> <p>3. Observe the voltage reading on the DVM.</p> <p>IMPORTANT: The voltage reading may rise during the test.</p> <p>4. Record the lowest voltage observed after the first second of the test.</p> <p>5. Set the injector switch box to the next injector and repeat steps 2, 3, and 4.</p> <p>Did any fuel injector have an erratic voltage reading (large fluctuations in voltage that did not stabilize) or a voltage reading outside of the specified values?</p>	5.7-6.6 V	Go to Step 4	Go to Step 7
4	<p>Replace the faulty fuel injector(s). Refer to <i>Fuel Injector</i>.</p> <p>Is the action complete?</p>	—	Go to Step 7	—

Injector Coil Test Procedure (Steps 1-6) and Injector Balance Test Procedure (Steps 7-11) (Cont'd)

Step	Action	Value(s)	Yes	No
5	<ol style="list-style-type: none"> 1. Set injector switch box injector #1. 2. Press the "Push to Start Test" button on the fuel injector tester. 3. Observe the voltage reading on the DVM. <p>IMPORTANT: The voltage reading may rise during the test.</p> <ol style="list-style-type: none"> 4. Record the lowest voltage observed after the first second of the test. 5. Set the injector switch box to the next injector and repeat steps 2, 3, and 4. <p>Did any fuel injector have an erratic voltage reading (large fluctuations in voltage that did not stabilize) or a voltage reading above the specified value?</p>	9.5 V	Go to Step 4	Go to Step 6
6	<ol style="list-style-type: none"> 1. Identify the highest voltage reading recorded (other than those above 9.5 V). 2. Subtract the voltage reading of each injector from the highest voltage selected in step 1. Repeat until you have a subtracted value for each injector. <p>For any injector, is the subtracted Value in step 2 greater than the specified value?</p>	0.6 V	Go to Step 4	Go to Step 7
7	<p>CAUTION: In order to reduce the risk of fire and personal injury, wrap a shop towel around the fuel pressure connection. The towel will absorb any fuel leakage that occurs during the connection of the fuel pressure gauge. Place the towel in an approved container when the connection of the fuel pressure gauge is complete.</p> <ol style="list-style-type: none"> 1. Connect the J 34730-1 Fuel Pressure Gauge to the fuel pressure test port. 2. Energize the fuel pump using the Tech 2. 3. Place the bleed hose of the fuel pressure gauge into an approved gasoline container. 4. Bleed the air out of the fuel pressure gauge. 5. With the fuel pump running, observe the reading on the fuel pressure gauge. <p>Is the fuel pressure within the specified values?</p>	296 kPa-376 kPa (43-55 psi)	Go to Step 8	Go to Fuel System Diagnosis
8	<p>Turn the fuel pump "OFF."</p> <p>Does the fuel pressure remain constant?</p>	—	Go to Step 9	Go to Fuel System Diagnosis

Injector Coil Test Procedure (Steps 1-6) and Injector Balance Test Procedure (Steps 7-11) (Cont'd)

Step	Action	Value(s)	Yes	No
9	<ol style="list-style-type: none"> 1. Connect the J 39021-5V Fuel Injector Tester and J 39021-90 Injector Switch Box the fuel injector harness connector. 2. Set the amperage supply selector switch on the fuel injector tester to the "Balance Test" 0.5-2.5 amp position. 3. Using the Tech 2 turn the fuel pump "ON" then "OFF" in order to pressurize the fuel system. 4. Record the fuel pressure indicated by the fuel pressure gauge after the fuel pressure stabilizes. This is the first pressure reading. 5. Energize the fuel injector by depressing the "Push to Start Test" button on the fuel injector tester. 6. Record the fuel pressure indicated by the fuel pressure gauge after the fuel pressure gauge needle has stopped moving. This is the second pressure reading. 7. Repeat steps 1 through 6 for each fuel injector. 8. Subtract the second pressure reading from the first pressure reading for one fuel injector. The result is the pressure drop value. 9. Obtain a pressure drop value for each fuel injector. 10. Add all of the individual pressure drop values. This is the total pressure drop. 11. Divide the total pressure drop by the number of fuel injectors. This is the average pressure drop. <p>Does any fuel injector have a pressure drop value that is either higher than the average pressure drop or lower than the average pressure drop by the specified value?</p>	10 kPa (1.5 psi)	Go to Step 10	Go to OBD System Check
10	<p>Re-test any fuel injector that does not meet the specification. Refer to the procedure in step 9.</p> <p>NOTE: Do not repeat any portion of this test before running the engine in order to prevent the engine from flooding.</p> <p>Does any fuel injector still have a pressure drop value that is either higher than the average pressure drop or lower than the average pressure drop by the specified value?</p>	10 kPa (1.5 psi)	Go to Step 11	Go to Symptoms
11	<p>Replace the faulty fuel injector(s). Refer to <i>Fuel Injector</i>.</p> <p>Is the action complete?</p>	—	Verify repair	—

Knock Sensor Diagnosis

The Tech 2 has two data displays available for diagnosing the knock sensor (KS) system. The two displays are described as follows:

- "Knock Retard" indicates the number of degrees that the spark timing is being retarded due to a knock condition.
- "KS Noise Channel" indicates the current voltage level being monitored on the noise channel.

DTCs P0325 and P0327 are designed to diagnose the KS module, the knock sensor, and the related wiring. The problems encountered with the KS system should set a DTC. However, if no DTC was set but the KS system is suspect because of a detonation complaint, refer to *Detonation/Spark Knock* in *Symptoms*.

Powertrain Control Module (PCM) Diagnosis

To read and clear diagnostic trouble codes, use a Tech 2.

IMPORTANT: Use of a Tech 2 is recommended to clear diagnostic trouble codes from the PCM memory. Diagnostic trouble codes can also be cleared by turning the ignition "OFF" and disconnecting the battery power from the PCM for 30 seconds. Turning off the ignition and disconnecting the battery power from the PCM will cause all diagnostic information in the PCM memory to be cleared. Therefore, all the diagnostic tests will have to be re-run.

Since the PCM can have a failure which may affect only one circuit, following the diagnostic procedures in this section will determine which circuit has a problem and where it is.

If a diagnostic chart indicates that the PCM connections or the PCM is the cause of a problem, and the PCM is replaced, but this does not correct the problem, one of the following may be the reason:

- There is a problem with the PCM terminal connections. The terminals may have to be removed from the connector in order to check them properly.
- EEPROM program is not correct for the application. Incorrect components or reprogramming the PCM with the wrong EEPROM program may cause a malfunction and may or may not set a DTC.
- The problem is intermittent. This means that the problem is not present at the time the system is being checked. In this case, refer to the *Symptoms* portion of the manual and make a careful physical inspection of all components and wiring associated with the affected system.
- There is a shorted solenoid, relay coil, or harness. Solenoids and relays are turned "ON" and "OFF" by the PCM using internal electronic switches called drivers. A shorted solenoid, relay coil, or harness will not damage the PCM but will cause the solenoid or relay to be inoperative.

Multiple PCM Information Sensor DTCS Set

Circuit Description

The powertrain control module (PCM) monitors various sensors to determine the engine operating conditions. The PCM controls fuel delivery, spark advance, transmission operation, and emission control device operation based on the sensor inputs.

The PCM provides a sensor ground to all of the sensors. The PCM applies 5 volts through a pull-up resistor, and determines the status of the following sensors by monitoring the voltage present between the 5-volt supply and the resistor:

- The engine coolant temperature (ETC) sensor
- The intake air temperature (IAT) sensor
- The transmission fluid temperature (TFT) sensor

The PCM provides the following sensors with a 5-volt reference and a sensor ground signal:

- The exhaust gas recirculating (EGR) pintle position sensor
- The throttle position (TP) sensor
- The manifold absolute pressure (MAP) sensor

The PCM monitors the separate feedback signals from these sensors in order to determine their operating status.

Diagnostic Aids

IMPORTANT: Be sure to inspect PCM and engine grounds for being secure and clean.

A short to voltage in one of the sensor input circuits may cause one or more of the following DTCs to be set:

- P0108/P1106
- P0113/P1111
- P0118/P1115
- P0123/P1121
- P0560
- P0712

IMPORTANT: If a sensor input circuit has been shorted to voltage, ensure that the sensor is not damaged. A damaged sensor will continue to indicate a high or low voltage after the affected circuit has been repaired. If the sensor has been damaged, replace it.

An open in the sensor ground circuit between the PCM and the splice will cause one or more of the following DTCs to be set:

- P0108/P1106
- P0113/P1111
- P0118/P1115
- P0123/P1121
- P0712

A short to ground in the 5-volt reference A or B circuit will cause one or more of the following DTCs to be set:

- P0107/P1107
- P0122/P1122
- P1406

An the in the 5-volt reference circuit A, between the PCM and the splice will cause one or more of the following DTCs to be set:

- ☐ P0122/P1122
- ☐ P1406

An the in the 5-volt reference circuit B, between the PCM and the splice will cause one or more of the following DTCs to be set:

- ☐ P0107/P1107

Check for the following conditions:

- ☐ **Poor connection at PCM.** Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damage terminals, and a poor terminal-to-wire connection.
- ☐ **Damaged harness.** Inspect the wiring harness for damage. If the harness is not damaged, observe an affected sensor's displayed value on the Tech 2 with the ignition "ON" and the engine "OFF" while you move the connectors and the wiring harnesses related to the following sensors:
 - ☐ IAT
 - ☐ ECT
 - ☐ TP

- ☐ MAP
- ☐ EGR
- ☐ TFT

Test Description

9. A faulty EGR valve can leak a small amount of current from the ignition feed circuit to the 5-volt reference A circuit. If the problem does not exist with the EGR valve disconnected, replace the EGR valve.
- 11-15. If a sensor input circuit has been shorted to voltage, ensure that the sensor has not been damaged. A damaged IAT or ECT sensor will continue to indicate a high voltage or a low temperature after the affected circuit has been repaired. A damaged TP, MAP, fuel tank pressure, or EGR pintle position sensor will indicate a high voltage, a low voltage, or a fixed value after the affected circuit has been repaired. If the sensor has been damaged, replace it.

Multiple PCM Information Sensor DTCs Set

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Turn the ignition "OFF," disconnect the PCM. 2. Turn the ignition "ON," check the 5 volt reference A circuit for the following conditions: <ul style="list-style-type: none"> <input type="radio"/> A poor connection at the PCM. <input type="radio"/> An open between the PCM connector and the splice. <input type="radio"/> A short to ground. <input type="radio"/> A short to voltage. Is there an open or short?	—	Go to Step 3	Go to Step 4
3	Repair the open or short. Is the action complete?	—	Verify repair	—
4	Check the sensor ground circuit for the following conditions: <ul style="list-style-type: none"> <input type="radio"/> A poor connection at the PCM or the affected sensors. <input type="radio"/> An open between the PCM connector and the affected sensors. Is there an open or a poor connection?	—	Go to Step 5	Go to Step 6
5	Repair the open or the poor connection. Is the action complete?	—	Verify repair	—
6	Measure the voltage between the EGR pintle position sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 7	Go to Step 11

Multiple PCM Information Sensor DTCs Set (Cont'd)

Step	Action	Value(s)	Yes	No
7	Measure the voltage between the MAP sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 8	Go to Step 14
8	Measure the voltage between the TP sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 9	Go to Step 15
9	Measure the voltage between the IAT sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 10	Go to Step 16
10	Measure the voltage between the ECT sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 11	Go to Step 17
11	1. Disconnect the EGR valve. 2. Measure the voltage between the EGR pintle position sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 13	Go to Step 18
12	Measure the voltage between the TFT sensor signal circuit at the PCM harness connector and ground. Does the voltage measure near the specified value?	0 V	Go to Step 20	Go to Step 19
13	Replace the EGR valve. Is the action complete?	—	Verify repair	—
14	Locate and repair the short to voltage in the MAP sensor signal circuit. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to voltage in the TP sensor signal circuit. Is the action complete?	—	Verify repair	—
16	Locate and repair the short to voltage in the IAT sensor signal circuit. Is the action complete?	—	Verify repair	—
17	Locate and repair the short to voltage in the ECT sensor signal circuit. Is the action complete?	—	Verify repair	—
18	Locate and repair the short to voltage in the EGR pintle position sensor signal circuit. Is the action complete?	—	Verify repair	—

Multiple PCM Information Sensor DTCs Set (Cont'd)

Step	Action	Value(s)	Yes	No
19	Locate and repair the short to voltage in the TFT sensor signal circuit. Is the action complete?	—	Verify repair	—
20	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to <i>OBD System Check</i>	—

Exhaust Gas Recirculation (EGR) Diagnosis

An EGR flow check diagnosis of the linear EGR system is covered by DTC P0401. Pintle position error diagnosis is covered by DTC P0402, P0404, P1404, P0405, P0406. If EGR diagnostic trouble codes P0401 and/or P0402, P0404, P1404, P0405, P0406 are encountered, refer to the DTC charts.

Engine Tech 2 Data Definitions and Ranges

A/C CLUTCH—Tech 2 Displays ON or OFF—

Indicates whether the PCM has commanded the A/C clutch ON. Used in A/C system diagnostic.

A/C REQUEST — Tech 2 Displays YES or NO —

Indicates the state of the A/C request input circuit from the HVAC controls. The PCM uses the A/C request signal to determine whether A/C compressor operation is being requested.

AIR/FUEL RATIO — Tech 2 Range 0.0-25.5 —

Air/fuel ratio indicates the PCM commanded value. In closed loop, the air/fuel ratio should normally be displayed around “14.2–14.7.” A lower air/fuel ratio indicates a richer commanded mixture, which may be seen during power enrichment or TWC protection modes. A higher air/fuel ratio indicates a leaner commanded mixture. This can be seen during deceleration fuel mode.

BARO kPa — Tech 2 Range 10-105 kPa/0.00-5.00 Volts —

The barometric pressure reading is determined from the MAP sensor signal monitored during key up and wide open throttle (WOT) conditions. The barometric pressure is used to compensate for altitude differences and is normally displayed around “61-104” depending on altitude and barometric pressure.

CHECK TRANS LAMP—AUTO TRANSMISSION—

Indicates the need to check for a DTC with the Tech 2 when the lamp is flashing 0.2 seconds ON and 0.2 seconds OFF.

CMP ACT. COUNTER —Cam Position Activity DECEL FUEL MODE—Tech 2 Display ACTIVE or INACTIVE—

“ACTIVE” displayed indicates that the PCM has detected conditions appropriate to operate in deceleration fuel mode. The PCM will command the deceleration fuel mode when it detects a closed throttle position while the vehicle is traveling over 20 mph. While in the decreasing fuel mode, the PCM will decrease the amount of fuel delivered by entering open loop and decreasing the injector pulse width.

DESIRED EGR POS.—Tech 2 Range 0%-100%—

Represents the EGR pintle position that the PCM is commanding.

DESIRED IDLE — Tech 2 Range 0-3187 RPM —

The idle speed that the PCM is commanding. The PCM will compensate for various engine loads based on engine coolant temperature, to keep the engine at the desired speed.

ECT — (Engine Coolant Temperature) Tech 2 Range —40°C to 151°C (–40°F to 304°F) —

The engine coolant temperature (ECT) is mounted in the coolant stream and sends engine temperature information to the PCM. The PCM applies 5 volts to the ECT sensor circuit. The sensor is a thermistor which changes internal resistance as temperature changes. When the sensor is cold (high resistance), the PCM monitors a high signal voltage and interprets that as a cold engine. As the sensor warms (decreasing resistance), the voltage signal will decrease and the PCM will interpret the lower voltage as a warm engine.

EGR DUTY CYCLE — Tech 2 Range 0%-100% —

Represents the EGR valve driver PWM signal from the PCM. A duty cycle of 0% indicates that no EGR flow is being commanded; a 100% duty cycle indicates maximum EGR flow commanded.

EGR FEEDBACK — Tech 2 Range 0.00-5.00 Volts —

Indicates the EGR pintle position sensor signal voltage being monitored by the PCM. A low voltage indicates a fully extended pintle (closed valve); a voltage near 5 volts indicates a retracted pintle (open valve).

EGR TEST COUNT — Tech 2 Range 0-255 —

Indicates the number of EGR flow test samples collected during the current ignition cycle. Under normal operation, only one sample is allowed during an ignition cycle. If the PCM battery feed has been disconnected or a DTC P0401 has been cleared, 10 EGR flow test samples will be allowed during the ignition cycle. This is to allow repair verification during a single ignition cycle.

ENGINE LOAD — Tech 2 Range 0%-100% —

Engine load is calculated by the PCM from engine speed and MAF sensor readings. Engine load should increase with an increase in RPM or air flow.

ENGINE RUN TIME — Tech 2 Range 00:00:00-99:99:99 Hrs:Min:Sec —

Indicates the time elapsed since the engine was started. If the engine is stopped, engine run time will be reset to 00:00:00.

ENGINE SPEED — Range 0-9999 RPM —

Engine speed is computed by the PCM from the 58X reference input. It should remain close to desired idle under various engine loads with engine idling.

EVAP PURGE PWM — Tech 2 Range 0%-100% —

Represents the PCM commanded PWM duty cycle of the EVAP purge solenoid valve. "0%" displayed indicates no purge; "100%" displayed indicates full purge.

EVAP VENT VALVE— Tech 2 Displays PURGE or NO PURGE—

The EVAP purge vacuum valve is a normally closed valve positioned in the purge line between the canister and the EVAP purge solenoid. The EVAP purge vacuum valve will open when vacuum increases to greater than 5 inches of water in the purge line. The EVAP purge vacuum valve is used by the PCM to monitor EVAP canister purge solenoid operation and purge system integrity. The EVAP purge vacuum valve should be closed to ground with no vacuum present (0% EVAP purge PWM). With EVAP purge PWM at 25% or greater, the EVAP purge vacuum valve should be open and "PURGE" should be indicated.

FUEL PUMP — Tech 2 Displays ON or OFF —

Indicates the PCM commanded state of the fuel pump relay driver circuit.

FUEL TRIM CELL — Tech 2 Range 0-21 —

The fuel trim cell is dependent upon engine speed and MAF sensor readings. A plot of RPM vs. MAF is divided into 22 cells. Fuel trim cell indicates which cell is currently active.

FUEL TRIM LEARN — Tech 2 Displays NO or YES —

When conditions are appropriate for enabling long term fuel trim corrections, fuel trim learn will display "YES." This indicates that the long term fuel trim is responding to the short term fuel trim. If the fuel trim learn displays "NO," then long term fuel trim will not respond to changes in short term fuel trim.

HO2S BANK 1, SEN. 1—Tech 2 Range 0-1132 mV—

Represents the fuel control exhaust oxygen sensor output voltage. Should fluctuate constantly within a range between 10 mV (lean exhaust) and 1000 mV (rich exhaust) while operating in closed loop.

HO2S BANK 1, SEN. 2—Tech 2 Range 0-1000mV—

Monitors the exhaust oxygen sensor output voltage. The PCM monitors the operating efficiency of catalytic converter by comparing the output voltages of sensor 1 and sensor 2 in this bank. If the catalytic converter is operating efficiently, the output voltage of sensor 1 will give a greater fluctuation than that of sensor 2. If the PCM detects an abnormal level of voltage fluctuation from sensor 2, a DTC P0420 will be set, indicating that the catalytic converter for this bank is no longer operating efficiently.

HO2S BANK2, SEN. 1—Tech 2 Range 0–1132 mV—

Represents the fuel control exhaust oxygen sensor output voltage. Should fluctuate constantly within a range between 10mV (lean exhaust) and 1000 mV (rich exhaust) while operating in closed loop.

HO2S BANK 2, SEN. 2—Tech 2 Range 0-1000 mV—

Monitors the exhaust oxygen sensor output voltage. The PCM monitors the operating efficiency of catalytic converter by comparing the output voltages of sensor 1 and sensor 2 in this bank. If the catalytic converter is operating efficiently, the output voltage of sensor 1 will give a greater fluctuation than that of sensor 2. If the PCM detects an abnormal level of voltage fluctuation from sensor 2, a DTC P0430 will be set, indicating that the catalytic converter for this bank is no longer operating efficiently.

HO2S BANK 1, SEN. 1—Tech 2 Displays READY YES/NO—

Indicates the status of the exhaust oxygen sensor. The Tech 2 will indicate that the exhaust oxygen sensor is ready when the PCM detects a fluctuating HO2S voltage sufficient to allow closed loop operation. This will not occur unless the exhaust oxygen sensor is warmed up.

HO2S BANK 2, SEN. 1—Tech 2 Displays READY YES/NO—

Indicates the status of the exhaust oxygen sensor. The Tech 2 will indicate that the exhaust oxygen sensor is ready when the PCM detects a fluctuating HO2S voltage sufficient to allow closed loop operation. This will not occur unless the exhaust oxygen sensor is warmed up.

HO2S WARM UP TIME BANK 1, SEN. 1/BANK 1, SEN 2/BANK 2, SEN. 1/BANK 2, SEN. 2—Tech 2 Range 00:00:00-99:99:99 HRS:MIN:SEC—

Indicates warm-up time for each HO2S. The HO2S warm-up time is used for the HO2S heater test. The PCM will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the HO2S to become active, a DTC will set. If the engine was warm when started, HO2S warm-up will the display "00:00:00".

IAC POSITION — Tech 2 Range 0-255 Counts —

Displays the commanded position of the idle air control pintle in counts. A larger number of counts means that more air is being commanded through the idle air passage. Idle air control should respond fairly quickly to changes in engine load to maintain desired idle RPM.

IAT (INTAKE AIR TEMPERATURE)— Tech 2 Range -40°C to 151°C (-40°F to 304°F) —

The PCM converts the resistance of the intake air temperature sensor to degrees. Intake air temperature (IAT) is used by the PCM to adjust fuel delivery and spark timing according to incoming air density.

IGNITION 1 — Tech 2 Range 0-25.5 Volts —

This represents the system voltage measured by the PCM at its ignition feed.

INJ. PULSE BANK 1/INJ. PULSE BANK 2— Tech 2 Range 0-1000 msec. —

Indicates the amount of time the PCM is commanding each injector "ON" during each engine cycle. A longer injector pulse width will cause more fuel to be delivered. Injector pulse width should increase with increased engine load.

KNOCK RETARD — Tech 2 Range 0.0 -25.5 —

Indicates the amount of spark the PCM is removing from IC spark advance in response to the signal from the knock sensors.

KS NOISE CHANNEL (Knock Sensor)—

Indicates the output from the KS noise channel. There is always some electrical noise in an engine compartment and to avoid mistaking this as engine knock, the output from the knock sensor is compared to the output from the noise channel. A knock condition is not set unless the knock sensor output is greater than the noise channel output.

LONG TERM FUEL TRIM BANK 1/BANK 2 —

The long term fuel trim is derived from the short term fuel trim values and represents a long term correction of fuel delivery for the bank in question. A value of 0% indicates that fuel delivery requires no compensation to maintain the PCM commanded air/fuel ratio. A negative value significantly below 0% indicates that the fuel system is rich and fuel delivery is being reduced (decreased injector pulse width). A positive value significantly greater than 0% indicates that a lean condition exists and the PCM is compensating by adding fuel (increased injector pulse width). Because long term fuel trim tends to follow short term fuel trim, a value in the negative range due to canister purge at idle should not be considered unusual. Fuel trim values at maximum authority may indicate an excessively rich or lean system.

LOOP STATUS — Tech 2 Displays OPEN or CLOSED —

"CLOSED" indicates that the PCM is controlling fuel delivery according to oxygen sensor voltage. In "OPEN" the PCM ignores the oxygen sensor voltage and bases the amount of fuel to be delivered on TP sensor, engine coolant, and MAF sensor inputs only.

MAF — Tech 2 Range 0.0-512 gm/s —

MAF (mass air flow) is the MAF input frequency converted to grams of air per second. This indicates the amount of air entering the engine.

MAP — Tech 2 Range 10-105 kPa (0.00-4.97 Volts)—

The manifold absolute pressure (MAP) sensor measures the change in the intake manifold pressure from engine load, EGR flow, and speed changes. As intake manifold pressure increases, intake vacuum decreases, resulting in a higher MAP sensor voltage and kPa reading. The MAP sensor signal is used to monitor intake manifold pressure changes during the EGR flow test, to update the BARO reading, and as an enabling factor for several of the diagnostics.

MIL — Tech 2 Displays ON or OFF —

Indicates the PCM commanded state of the malfunction indicator lamp.

MISFIRE CUR.CYL #1 /#2 /#3 /#4 / #5 / #6 — Tech 2 Range 0-255 Counts —

The misfire current counters increase at a rate according to the number of the possible misfires being detected on each cylinder. The counters may normally display some activity, but the activity should be nearly equal for all the cylinders.

MISFIRE CUR.CYL #1 /#2 /#3 /#4 / #5 / #6 — Tech 2 Range 0-65535 Counts —

The misfire history counters display the relative level of misfire that has been detected on each cylinder. The misfire history counters will not update or show any activity until a misfire DTC (P0300) has become active.

MISFIRE FAILURES SINCE FIRST FAIL — Tech 2 Range 0-65535 Counts —

Indicates the number of 200 crankshaft revolution sample periods during which the level of misfire was sufficiently high to report a fail.

MISFIRE PASSES SINCE FIRST FAIL — Tech 2 Range 0-65535 Counts —

Indicates the number of 200 crankshaft revolution sample periods during which the level of misfire was sufficiently low to report a pass.

POWER ENRICHMENT — Tech 2 Displays ACTIVE or INACTIVE —

"ACTIVE" displayed indicates that the PCM has detected conditions appropriate to operate in power enrichment mode. The PCM will command power enrichment mode when a large increase in throttle position and load is detected. While in power enrichment mode, the PCM will increase the amount of fuel delivered by entering open loop and increasing the injector pulse width. This is done to prevent a possible sag or hesitation from occurring during acceleration.

RICH/LEAN BANK 1/ BANK 2 — Tech 2 Displays RICH or LEAN —

Indicates whether oxygen sensor voltage is above a 600 mV threshold voltage ("RICH") or below a 3000 mV threshold voltage ("LEAN"). Should change constantly while in closed loop, indicating that the PCM is controlling the air/fuel mixture properly.

SHORT TERM FT BANK1/BANK2—

Short term fuel trim to a bank represents a short term correction to bank fuel delivery by the PCM in response to the amount of time the bank fuel control oxygen sensor voltage spends above or below the 450 mV threshold. If the oxygen sensor voltage has mainly remained less than 450 mV, indicating a lean air/fuel mixture, short term fuel trim will increase into the positive range above 0% and the PCM will pass fuel. If the oxygen sensor voltage stays mainly above the threshold, short term fuel trim will decrease below 0% into the negative range while the PCM reduces fuel delivery to compensate for the indicated rich condition. Under certain conditions such as extended idle and high ambient temperatures, canister purge may cause short term fuel trim to read in the negative range during normal operation. Fuel trim values at maximum authority may indicate an excessively rich or lean system.

SPARK — Tech 2 Range -64° to 64° —

Displays the amount of spark advance being commanded by the PCM on the IC circuit.

START-UP ECT — Tech 2 Range -40°C to 151°C (-40°F to 304°F) —

Indicates the engine coolant temperature at the time that the vehicle was started. Used by the HO2S diagnostic to determine if the last start-up was a cold start.

START-UP IAT — Tech 2 Range -40°C to 151°C (-40°F to 304°F) —

Indicates the intake air temperature at the time that the vehicle was started. Used by the HO2S diagnostic to determine if the last start-up was a cold start.

TOTAL MISFIRE CURRENT COUNT—Tech 2 Range 0-255—

Indicates the total number of cylinder firing events that were detected as being misfires during the last 200 crankshaft revolution sample period.

TP — Tech 2 Range 0%-100% —

TP (throttle position) angle is computed by the PCM from the TP sensor voltage. TP angle should display "0%" at idle and "100%" at wide open throttle.

TP SENSOR — Tech 2 Range 0.00-5.00 Volts —

The voltage being monitored by the PCM on the TP sensor signal circuit.

CATALYST PROTECTION MODE— Tech 2 Displays YES or NO —

"YES" displayed indicates that the PCM has detected conditions appropriate to operate in TWC protection mode. The PCM will decrease the air/fuel ratio to a value that depends on mass air flow (higher mass air flow = lower air/fuel ratio).

UPSHIFT LAMP (MANUAL TRANSMISSION) VEHICLE SPEED—Tech 2 Range 0-255 km/h (0-155 mph)—

The vehicle speed sensor signal is converted into km/h and mph for display.

WEAK CYLINDER —Tech 2 Displays Cylinder Number—

This indicates that the PCM has detected crankshaft speed variations that indicate 2% or more cylinder firing events are misfires.

Typical Scan Data Values

Use the Typical Scan Data Values Table only after the On-Board Diagnostic System Check has been completed, no DTC(s) were noted, and you have determined that the on-board diagnostics are functioning properly. Tech 2 values from a properly-running engine may be used for comparison with the engine you are diagnosing. The typical scan data values represent values that would be seen on a normally-running engine.

NOTE: A Tech 2 that displays faulty data should not be used, and the problem should be reported to the Tech 2 manufacturer. Use of a faulty Tech 2 can result in misdiagnosis and unnecessary replacement of parts.

Only the parameters listed below are referred to in this service manual for use in diagnosis. For further information on using the Tech 2 to diagnose the PCM and related sensors, refer to the applicable reference section listed below. If all values are within the typical range described below, refer to the *Symptoms* section for diagnosis.

Test Conditions

Engine running, lower radiator hose hot, transmission in park or neutral, closed loop, accessories off, brake not applied and air conditioning off.

3.2L V-6 Engine (Automatic and Manual Transmission)

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
A/C Clutch	Engine	On/Off	Off	Off	General Description and Operation, A/C Clutch Circuit Operation
A/C Request	Engine	Yes/No	No	No	General Description and Operation, A/C Request Signal
Air/Fuel Ratio	Engine	Ratio: _ to 1	14.7	14.7	General Description and Operation, Fuel System Metering Purpose
BARO kPa	Engine	kPa	61-104 (depends on altitude and barometric)	61-104 (depends on altitude and barometric)	General Description and Operation
Broadcast Code	ID info from "SELECT MODE" Application Menu	3.2 letters	Depends on latest level of engine/transmission software and calibration. Review Technical Service Bulletins or dealership reprogramming tools for most current level.	Depends on latest level of engine/transmission software and calibration. Review Technical Service Bulletins or dealership reprogramming tools for most current level.	—
Check Trans Lamp (Auto Trans)	Engine	On/Off	Off	Off	4L30-E Automatic Transmission Diagnosis
CMP Act. Counter (Cam Position Activity)	Engine	Counts	0-255, always increasing	0-255, always increasing	DTC P0341 and P0342
Decel Fuel Mode	Engine	Active/Inactive	Inactive	Inactive	General Description and Operation, Deceleration Mode
Desired EGR Position	Engine	Percent	0%	0%	General Description and Operation, EGR Pintle Position Sensor
Desired Idle	Engine	RPM	750	800	General Description and Operation, Idle Air Control (IAC) Valve
ECT (Engine Coolant Temp)	Engine	Degrees C, Degrees F	80-100°C (176-212°F)	80-100°C (176-212°F)	General Description and Operation, Engine Coolant Temperature (ECT) Sensor
EGR Closed Valve Pintle Position	Eng: EGR	Steps	20-40	20-40	General Description and Operation, EGR Pintle Position Sensor
EGR Duty Cycle	Engine	Percent	0%	0%	General Description and Operation, Linear EGR Operation and Results of Incorrect Operation
EGR Feedback	Eng: EGR	X.XX Volts	0.43-0.80	0.43-0.80	—

6E2-76 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
EGR Normalized	Engine	Percent	0%	0%	—
EGR Test Count	Eng: EGR	Counts	0-14	0-14	—
Engine Load	Engine	Percent	2.0% - 5.5%	9.0% - 20.0%	General Description and Operation, Mass Air Flow (MAF) Sensor
Time From Start	Engine	Sec	Varies. Resets at each engine start.	Varies. Resets at each engine start.	—
Engine Speed	Engine	RPM	Within -50 to +100 of "Desired Idle"	Actual engine speed	DTCs: P1508, P1509
EVAP Purge Solenoid	Engine	Percent	65%	99%	Diagnosis, EVAP Emission Canister Purge Valve Check
EVAP Diagnostic Solenoid	Eng: EVAP	On/Off	Off	Off	DTC P0446
Freeze Frame (FZ) Fail Cntr.	DTC	Counts	—	—	Diagnosis, Storing and Erasing Freeze Frame Data
Freeze Frame (FZ) Pass Cntr.	DTC	Counts	—	—	Diagnosis, Storing and Erasing Freeze Frame Data
Freeze Frame (FZ) Not Run Cntr.	DTC	Counts	—	—	Diagnosis, Storing and Erasing Freeze Frame Data
Fuel Level	Engine	Percent Duty Cycle	1%-90% PWM Duty Cycle (Low = Full)	1%-90% PWM Duty Cycle (Low = Full)	—
Fuel Level Sensor	Eng: EVAP	X.XX Volts	0.44-2.02; Depends on fuel level (Low = Full)	0.44-2.02; Depends on fuel level (Low = Full)	—
Fuel Pump	Engine	On/Off	On	On	Engine Fuel
Fuel Tank Pressure Sensor	Eng: EVAP	X.XX Volts	1.02-1.86	1.02-2.57	—
Fuel Trim Cell	Engine	Cell number	18 (manual trans), 20 (auto trans)	2 or 6	Diagnosis, Fuel Trim Cell Diagnostic Weights
Fuel Trim Learn	Engine	Disabled/Enabled	Enabled	Enabled	Diagnosis, Fuel Trim Monitor
HO2S Bank 1 Sen.1 (millivolts)	Engine	Millivolts	50-950 changing quickly	50-950, always changing quickly	General Description and Operation, Fuel control HO2S
HO2S Bank 1 Sen.2 (millivolts)	Engine	Millivolts	200-700 changing slowly	250-650 changing slowly	General Description and Operation, Fuel Metering System
HO2S Bank 1 Sen.2 (millivolts)	Engine	Millivolts	50-950 changing quickly	50-950 changing quickly	General Description and Operation, Fuel Metering System

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
HO2S Bank 1 Sen.3 (millivolts)	Engine	Millivolts	200-700 changing slowly	250-650 changing slowly	General Description and Operation, Catalyst Monitor Heated Oxygen Sensor (Manual Trans)
HO2S Bank 2 Sen.1 (millivolts)	Engine	Millivolts	50-950 changing quickly	50-950 changing quickly	General Description and Operation, Fuel Control HO2S
HO2S Bank 2 Sen.2 (millivolts) (Auto trans)	Engine	Millivolts	200-700 changing slowly	250-650 changing slowly	General Description and Operation, Fuel Metering System
HO2S Bank 1 Sen.1 (ready/not ready)	Eng: HO2S	Ready Yes/No	Ready Yes	Ready Yes	General Description and Operation, Fuel Control HO2S; DTC: P0135
HO2S Bank 2 Sen.1 (ready/not ready)	Eng: HO2S	Ready Yes/No	Ready Yes	Ready Yes	General Description and Operation, Fuel Control HO2S
HO2S Warm-Up Time Bank 1 Sen.1	Eng: HO2S	Seconds	25-45	25-45	General Description and Operation, Fuel Control HO2S
HO2S Warm-Up Time Bank 1 Sen.2	Eng: HO2S	Seconds	60-100	60-100	General Description and Operation, Fuel Control HO2S
HO2S Warm-Up Time Bank 2 Sen.1	Eng: HO2S	Seconds	25-45	25-45	General Description and Operation, Fuel Control HO2S
HO2S Warm-Up Time Bank 2 Sen.2	Eng: HO2S	Seconds	60-100	60-100	General Description and Operation, Catalyst Monitor Heated Oxygen Sensor (Auto Trans)
IAC Position	Engine	Steps	10-50	30-110	—
IAT (Intake Air Temp)	Engine	Degrees C, Degrees F	0-100°C, depends on underhood	0-80°C, depends on underhood	General Description and Operation, Intake Air Temperature (IAT) Sensor
Ignition 1	Engine	Volts	12.8-14.1	12.8-14.1	General Description and Operation, Electronic Ignition System
Inj. Pulse Bank 1	Engine	Millisecond s	2.0-4.0	2.5-4.5	General Description, Fuel Metering, Fuel Injector
Inj. Pulse Bank 2	Engine	Millisecond s	2.0-4.0	2.5-4.5	General Description, Fuel Metering, Fuel Injector
Knock Retard	Engine	Degrees °CA	0	0	General Description and Operation, Knock Sensor Purpose and Operation; DTCs: P0352, P0327
KS Noise Channel (Knock Sensor)	Engine	Volts	0.10-0.40	0.50-1.75	General Description and Operation, Knock Sensor Purpose and Operation; DTCs: P0352, P0327
Long Term FT Bank 1 (Long Term Fuel Trim)	Engine	Counts and Percent	112 to 150 counts, -12% to +17%	115 to 147 counts, -10% to +15%	Diagnosis, Fuel Trim System Monitor; DTCs: P0171, P0172

6E2-78 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
Long Term FT Bank 2 (Long Term Fuel Trim)	Engine	Counts and Percent	112 to 150 counts, -12% to +17%	115 to 147 counts, -10% to +15%	Diagnosis, Fuel Trim System Monitor; DTCs: P0171, P0175
Loop Status	Engine	Open/Closed	Closed	Closed	General Description and Operation, Fuel Metering System; DTCs: P0125-P0155
MAF (Mass Air Flow)	Engine	Grams per second	2.85-6.65	9.5-16.5	General Description and Operation, MAF; DTCs: P101, P0102, P0103
MAP kPa (Manifold Absolute Pressure)	Engine	Kilopascals	23-40	19-32	General Description and Operation, Manifold Absolute Pressure (MAP) Sensor; DTCs: P0106, P0107, P0108
MAP volts (Manifold Absolute Pressure)	Engine	Volts	0.65-1.32	0.46-1.10	General Description and Operation, Manifold Absolute Pressure (MAP) Sensor; DTCs: P0106, P0107, P0108
MIL	Engine	On/Off	Off	Off	On-Board Diagnostic System Check
Mileage Since First Failure	Capture Info	Miles	—	—	—
Mileage Since Last Failure	Capture Info	Miles	—	—	—
Misfire Cur. Cyl #1	Eng: Misfire	Counts	0-2	0-2	DTC P0300
Misfire Cur. Cyl #2	Misfire	Counts	0-2	0-2	DTC P0300
Misfire Cur. Cyl #3	Misfire	Counts	0-2	0-2	DTC P0300
Misfire Cur. Cyl #4	Misfire	Counts	0-2	0-2	DTC P0300
Misfire Cur. Cyl #5	Misfire	Counts	0-2	0-2	DTC P0300
Misfire Cur. Cyl #6	Misfire	Counts	0-2	0-2	DTC P0300
Misfire Hist. Cyl #1	Misfire	Counts	0	0	DTC P0300
Misfire Hist. Cyl #2	Misfire	Counts	0	0	DTC P0300
Misfire Hist. Cyl #3	Misfire	Counts	0	0	DTC P0300
Misfire Hist. Cyl #4	Misfire	Counts	0	0	DTC P0300
Misfire Hist. Cyl #5	Misfire	Counts	0	0	DTC P0300
Misfire Hist. Cyl #6	Misfire	Counts	0	0	DTC P0300
Misfire Failures Since First Fail	Misfire	Counts	0	0	DTC P0300

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
Misfire Passes Since First Fail	Misfire	Counts	0	0	DTC P0300
PNP (Park/Neutral Position)	Engine	P-N / R-D-3-2-L	P-N	P-N	4L30-E Automatic Transmission Diagnosis
Power Enrichment	Engine	Inactive/Ac tive	Inactive	Inactive	General Description and Operation, Acceleration Mode
Rich/Lean Bank 1	Engine	Rich/Lean	Always changing	Always changing	General Description and Operation, Fuel Control HO2S
Rich/Lean Bank 2	Engine	Rich/Lean	Always changing	Always changing	General Description and Operation, Fuel Control HO2S
Shrt Term FT Bank 1 (Short Term Fuel Trim)	Engine	Counts and Percent	112 to 154 counts, -12% to +20%	112 to 154 counts, -12% to +20%	Diagnosis, Fuel Trim System Monitor; DTCs: P0171, P0172
Shrt Term FT Bank 2 (Short Term Fuel Trim)	Engine	Counts and Percent	112 to 154 counts, -12% to +20%	112 to 154 counts, -12% to +20%	Diagnosis, Fuel Trim System Monitor; DTCs: P0174, P0175
Spark (Advance)	Engine	Degrees Before Top Dead Center	15-22	34-44	General Description and Operation, Electronic Ignition System
Start-Up ECT (Engine Coolant Temp)	Eng: HO2S	Degrees C, Degrees F	Depends on engine coolant temperature at time of start-up	Depends on engine coolant temperature at time of start-up	General Description and Operation, Engine Coolant Temperature (ECT) Sensor
Start-Up IAT (Intake Air Temp)	Eng: HO2S	Degrees C, Degrees F	Depends on intake air temperature at time of start-up	Depends on intake air temperature at time of start-up	General Description and Operation, Intake Air Temperature (IAT) Sensor
TCC Engaged (Torque Converter Clutch)	Engine	No/Yes	No	No	4L30-E Automatic Transmission Diagnosis
Torque Management	Engine	Inactive/Ac tive	Inactive	Inactive	4L30-E Automatic Transmission Diagnosis
Total Misfire Current Count	Misfire	Counts	0-5	0-5	DTC P0300
TP (Throttle Position)	Engine	Percent	0	—	General Description and Operation, Throttle Position (TP) Sensor; DTCs: P0121, P0122,P0123
TP Sensor (Throttle Position)	Engine	Volts	0.50-0.82	0.60-1.00	General Description and Operation, Throttle Position (TP) Sensor; DTCs: P0121, P0122,P0123
Catalyst Protection Mode	Eng:	No/Yes	No	No	General Description, Fuel Metering, catalytic Converter Protection Mode

6E2-80 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

Tech 2 Parameter	Data List	Units Displayed	Typical Data Values (IDLE)	Typical Data Values (2500 RPM)	Refer To
Upshift Lamp (manual trans)	Engine	On/Off	Off	Off	Manual Transmission
Vehicle Speed	Engine	MPH / km/h	0	0	4L30-E Automatic Transmission Diagnosis
Weak Cylinder	Eng: Misfire	Cylinder #	—	—	DTC P0300

No Malfunction Indicator Lamp (MIL)



Circuit Description

The “Check Engine” lamp (MIL) should always be illuminated and steady with the ignition “ON” and the engine stopped. Ignition feed voltage is supplied to the MIL bulb through the meter fuse. The powertrain control module (PCM) turns the MIL “ON” by grounding the MIL driver circuit.

Diagnostic Aids

An intermittent MIL may be caused by a poor connection, rubbed-through wire insulation, or a wire broken inside the insulation. Check for the following items:

- Inspect the PCM harness and connections for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- If the engine runs OK, check for a faulty light bulb, an open in the MIL driver circuit, or an open in the instrument cluster ignition feed.

- If the engine cranks but will not run, check for an open PCM ignition or battery feed, or a poor PCM to engine ground.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. A “No MIL” condition accompanied by a no-start condition suggests a faulty PCM ignition feed or battery feed circuit.
9. Using a test light connected to B+, probe each of the PCM ground terminals to ensure that a good ground is present. Refer to *PCM Terminal End View* for terminal locations of the PCM ground circuits.
12. In this step, temporarily substitute a known good relay for the PCM relay. The horn relay is nearby, and it can be verified as “good” simply by honking the horn. Replace the horn relay after completing this step.

17. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is replaced, the new PCM must be programmed. Refer to *PCM Replacement and Programming Procedures* in *Powertrain Control Module (PCM) and Sensor*.


No Malfunction Indicator Lamp (MIL)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Attempt to start the engine. Does the engine start?	—	Go to Step 3	Go to Step 6
3	Check the meter fuse for the instrument cluster ignition feed circuit. Is the fuse OK?	—	Go to Step 4	Go to Step 16
4	Ignition "ON," probe the ignition feed circuit at the cluster connector with a test light to ground. Is the test light "ON?"	—	Go to Step 5	Go to Step 13
5	1. Ignition "OFF." 2. Disconnect the PCM. 3. Jumper the MIL driver circuit at the PCM connector to ground. 4. Ignition "ON." Is the MIL "ON?"	—	Go to Step 10	Go to Step 11
6	Check the PCM ignition feed and battery feed fuses (15 A engine fuse and 15 A PCM fuse). Are both fuses OK?	—	Go to Step 7	Go to Step 15
7	1. Ignition "OFF." 2. Disconnect the PCM. 3. Ignition "ON." 4. Probe the ignition feed circuit at the PCM harness connector with a test light to ground. Is the test light "ON?"	—	Go to Step 8	Go to Step 12
8	Probe the battery feed circuit at the PCM harness connector with a test light to ground. Is the test light "ON?"	—	Go to Step 9	Go to Step 14
9	Check for a faulty PCM ground connection. Was a problem found?	—	Verify repair	Go to Step 10
10	Check for damaged terminals at the PCM. Was a problem found?	—	Verify repair	Go to Step 17
11	Check for an open MIL driver circuit between the PCM and the MIL. Was a problem found?	—	Verify repair	Go to Step 18
12	Substitute a known "good" relay for the PCM main relay. Was the malfunction fixed?	—	Verify repair	Go to Step 13

No Malfunction Indicator Lamp (MIL) (Cont'd)

Step	Action	Value(s)	Yes	No
13	Repair the open in the ignition feed circuit. Is the action complete?	—	Verify repair	—
14	Locate and repair the open PCM battery feed circuit. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in the PCM ignition feed circuit or PCM battery feed circuit. Is the action complete?	—	Verify repair	—
16	Locate and repair the short to ground in the ignition feed circuit to the instrument cluster, and replace the fuse. Is the action complete?	—	Verify repair	—
17	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>PCM</i> in <i>ON-Vehicle Service</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
18	Check the MIL driver circuit for a poor connection at the instrument panel connector. Was a problem found?	—	Verify repair	Go to <i>Instrument Panel in Electrical Diagnosis</i>

Malfunction Indicator Lamp (MIL) "ON" Steady



D06RX012

Circuit description

The "Check Engine" lamp (MIL) should always be illuminated and steady with ignition "ON" and the engine stopped. Ignition feed voltage is supplied directly to the MIL indicator. The powertrain control module (PCM) turns the MIL "ON" by grounding the MIL driver circuit. The MIL should not remain "ON" with the engine running and no DTC(s) set. A steady MIL with the engine running and no DTC(s) suggests a short to ground in the MIL driver circuit.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation, or a wire broken inside the insulation. Check for the following items:

- Poor connection or damaged harness – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.


Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. If the MIL does not remain "ON" when the PCM is disconnected, the MIL driver wiring is not faulty.
3. If the MIL driver circuit is OK, the instrument panel cluster is faulty.
6. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is replaced, the new PCM must be programmed. Refer to *PCM Replacement and Programming Procedures in Powertrain Control Module (PCM) and Sensors*.

Malfunction Indicator Lamp (MIL) "ON" Steady

Step	Action	Value(s)	Yes	No
1	Was the "On-Board diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "OFF," disconnect PCM. 2. Ignition "ON," observe the MIL (Service Engine Soon lamp). Is the MIL "ON?"	—	Go to Step 3	Go to Step 5
3	1. Ignition "OFF," disconnect the instrument panel cluster. 2. Check the MIL driver circuit between the PCM and the instrument panel cluster for a short to ground. 3. If a problem is found, repair as necessary. Was the MIL driver circuit shorted to ground?	—	Go to <i>OBD System Check</i>	Go to Step 4
4	Replace the instrument panel cluster. Is the action complete?	—	Go to <i>OBD System Check</i>	—
5	1. Ignition "OFF," reconnect the PCM. 2. Ignition "ON," reprogram the PCM. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensor</i> for procedures. 3. Using the Tech 2 output controls function, select MIL dash lamp control and command the MIL "OFF." (Refer to the miscellaneous test) Did the MIL turn "OFF?"	—	Go to <i>OBD System Check</i>	Go to Step 6
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>ON-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Go to <i>OBD System Check</i>	—



Engine Cranks But Will Not Run

Circuit Description

The electronic Ignition system uses a coil-at-plug method of spark distribution. In this type of ignition system, the powertrain control module (PCM) triggers the correct driver inside the ignition coil, which then triggers the correct ignition coil based on the 58X signal received from the crankshaft position sensor (CKP). The spark plug connected to the coil fires when the ignition coil opens the ground circuit for the coil's primary circuit.

During crank, the PCM monitors the CKP 58X signal. The CKP signal is used to determine which cylinder will fire first. After the CKP 58X signal has been processed by the PCM, it will command all six injectors to allow a priming shot of fuel for all the cylinders. After the priming, the injectors are left "OFF" during the next six 58X reference pulses from the CKP. This allows each cylinder a chance to use the fuel from the priming shot. During this waiting period, a camshaft position (CMP) signal pulse will have been received by the PCM. The CMP signal allows the PCM to operate the injectors sequentially based on camshaft position. If the camshaft position signal is not present at start-up, the PCM will begin sequential fuel delivery with a 1-in-6 chance that fuel delivery is correct. The engine will run without a CMP signal, but will set a DTC code.

Diagnostic Aids

An intermittent problem may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for the following items:

- Poor connection or damaged harness – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- Faulty engine coolant temperature sensor – Using a Tech 2, compare engine coolant temperature with intake air temperature on a completely cool engine. Engine coolant temperature should be within 10°C of intake air temperature. If not, replace the ECT sensor.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

5. An obvious cause of low fuel pressure would be an empty fuel tank.
6. The engine will easily start and run if a few injectors are disabled. It is not necessary to test all injectors at this time since this step is only a test to verify that all of the injectors have not been disabled by fuel contamination.
7. A blinking test light verifies that the PCM is monitoring the 58X crankshaft reference signal and is capable of activating the injectors. If there is an open or shorted driver circuit, DTCs 201–206 and a misfire DTC 301–306 should be set.
19. By using a spark tester, each ignition coil's ability to produce 25,000 volts is verified.
25. If there is an open or shorted driver circuit, DTCs 201–206 and a misfire DTC 301–306 should be set. All six injector driver circuits can be checked at one time without removing the intake manifold if a J 39021-95 test light is available. This is the alternative procedure:
 - With the ignition "OFF," disconnect the gray connector located at the rear of the air filter, attached to a bracket on the purge canister.
 - Connect test light J 39021-95 to the connector. Do any of the light constantly illuminate or fail to blink when the engine is cranked? If so, repair the short or open circuit, or replace the PCM if indicated.

This procedure only tests the driver circuit as far as the test connection, so step 31 is added to test the circuit all the way to the injector.

Engine Cranks But Will Not Run

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Check the 15 A ignition coil fuse, the 15 A engine device fuse, and the 15A PCM fuse. Was a fuse blown?	—	Go to Step 3	Go to Step 4
3	Check for a short to ground and replace the fuse. Is the action complete?	—	Verify repair	—

Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Ignition "OFF," install a fuel pressure gauge at the test fitting on the fuel supply line in the engine compartment. (Use a shop cloth to absorb any fuel leakage while making the connection.) 2. Ignition "ON," observe the fuel pressure. Is the fuel pressure within the specified values, and does it hold steady?	285-375 kPa (43-55 psi)	Go to <i>Step 6</i>	Go to <i>Step 5</i>
5	Is any fuel pressure indicated?	—	Go to <i>Fuel System Electrical Test</i>	Go to <i>Fuel System Diagnosis</i>
6	Install the switch box J 39021-2 at the injector test connector and activate an injector. Did the fuel pressure drop when the injector was activated?	—	Go to <i>Step 7</i>	Go to <i>Step 18</i>
7	Install an injector test light at the #2 cylinder injector harness connector (or install J 39021-65 test light to the the injector test connector). Does the light blink when the engine is cranked?	—	Go to <i>Step 8</i>	Go to <i>Step 24</i>
8	1. Ignition "OFF." 2. Disconnect the 6-pin connector at the ignition coil. 3. With a test light to B+, probe each of the 6 exposed ignition module pins, one at a time, while the engine is cranked. (Use the gray narrow METRA-PAK® flexible female connector from the J-35616 kit to make the pin accessible.) Does the light flash at each pin when the engine is cranked?	—	Go to <i>Step 12</i>	Go to <i>Step 9</i>
9	1. Remove the 5-pin connector at the ignition coil. 2. Ignition "ON." 3. Use a test light at the harness connector to verify that the module is being supplied with B+ and ground. Was a problem found?	—	Go to <i>Step 10</i>	Go to <i>Step 11</i>
10	Repair the open ignition feed circuit or ground circuit to the ignition coil. Is the action complete?	—	Verify repair	—
11	Repair the ignition module. Is the action complete?	—	Verify repair	—
12	1. Reconnect the ignition coil connector. 2. Remove the electrical connector from each coil. 3. With a test light to B+, probe each of the coil connectors at the wire which runs to the ignition module. (Wire color will match the wire color at the ignition module 6-pin connector – green, or green with a tracer.) Does the light flash at each coil connector when the engine is cranked?	—	Go to <i>Step 14</i>	Go to <i>Step 13</i>
13	Check for an open circuit between the ignition coil. Is the action complete?	—	Verify repair	—

Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
14	1. Ignition "ON." 2. While the coil connectors are disconnected, touch each coil connector's ignition feed terminal with a grounded test light (the ignition feed wire is black with orange tracer). Did the test light illuminate?	—	Go to Step 16	Go to Step 15
15	Repair the open ignition feed circuit. Is the action complete?	—	Verify repair	—
16	While the coil connectors are disconnected, touch each connector's secondary ground terminal with a test light to B+. (The ground wires are black.) Did the test light illuminate at each coil connector?	—	Go to Step 18	Go to Step 17
17	Repair the open secondary ground circuit. Is the action complete?	—	Verify repair	—
18	1. Test the fuel for contamination. 2. If a problem is found, clean the fuel system and correct the contaminated fuel condition as necessary. Replace the fuel filter and replace any injectors that are not delivering fuel (see Injector Balance Test). Was a problem found?	—	Verify repair	Go to Step 19
19	1. Remove any ignition coil and install a spark tester at the spark plug end of the coil. 2. Observe the tester while the engine is cranking. Was a crisp, blue spark observed? Only one or two sparks followed by no result is considered the same as "No Spark."	—	Go to Step 21	Go to Step 20
20	Replace the ignition coil, and return to Step 19 to test the remaining coils. Is the action complete?	—	Verify repair	—
21	Repeat Step 19 for each coil. Remove only one coil at a time, and reinstall each coil on its spark plug after testing, but do not refasten coils with screws at this time. After all coils have passed the spark test, does the engine start?	—	Refasten all coils with their screws	Go to Step 22
22	1. Remove the spark plugs from all cylinders. 2. Visually inspect the spark plug electrodes. 3. Replace any spark plugs with loose or missing electrodes or cracked insulators. Did your inspection reveal any spark plugs exhibiting excessive fouling?	—	Correct the fouling condition	Go to Step 23


Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
23	Refer to <i>Engine Mechanical Diagnosis</i> to diagnose the following conditions: <ul style="list-style-type: none"> ○ Faulty or incorrect camshaft drive belts ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ Incorrect valve timing ○ Leaking head gasket Is the action complete?	—	Verify repair	Go to <i>Step 25</i>
24	Observe the "Engine Speed" data display on the Tech 2 while cranking the engine. Is the engine RPM indicated?	—	Go to <i>Step 25</i>	Go to <i>Step 34</i>
25	1. Disconnect the 7-pin gray connector at the rear of the air filter beneath the point where the air duct attaches to the MAF sensor. 2. Ignition "ON." 3. Using a test light connected to ground, probe the ignition terminal at the PCM (female) side of the 7-pin connector. Is the test light "ON?"	—	Go to <i>Step 26</i>	Go to <i>Step 32</i>
26	1. At the PCM (female) side of the connector mentioned in step 25, connect a test light between the ignition + terminal and one of the injector driver circuits at the same connector. 2. Ignition "ON." 3. Observe the test light, and repeat the test for each injector driver circuit. Did the test light stay on when checking any of the 6 injector driver circuits?	—	Go to <i>Step 27</i>	Go to <i>Step 29</i>
27	1. Ignition "OFF," disconnect the PCM. 2. Ignition "ON," observe the test light. Is the test light "ON?"	—	Go to <i>Step 28</i>	Go to <i>Step 33</i>
28	Locate and repair the short to ground in the injector driver circuit. Is the action complete?	—	Verify repair	—
29	1. Using the same test location as in step 26, connect a test light between the ignition terminal and one of the driver circuits. 2. Crank the engine and observe the test light. 3. Repeat for each injector driver circuit. Did the light blink during the test for each circuit?	—	Go to <i>Step 31</i>	Go to <i>Step 30</i>
30	Check for an open injector driver circuit. Was a problem found?	—	Verify repair	Go to <i>Step 33</i>

Engine Cranks But Will Not Run (Cont'd)

Step	Action	Value(s)	Yes	No
31	<p>1. At the injector (male) side of the gray connector mentioned in step 25, connect an ohmmeter between the ignition pin and one of the driver circuit pins.</p> <p>2. Check for continuity in the circuit.</p> <p>3. Repeat for each injector circuit. The readings should be approximately equal to the specified value for injector resistance.</p> <p>Was a problem found?</p>	12.5 ohms	Verify repair	Go to Step 8
32	<p>Repair the ignition feed circuit.</p> <p>Is the action complete?</p>	—	Verify repair	—
33	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—
34	<p>1. Raise the vehicle and disconnect the CKP sensor harness.</p> <p>2. Ignition "ON."</p> <p>3. With a test light to ground, probe the harness ignition feed terminal.</p> <p>Did the light illuminate?</p>	—	Go to Step 36	Go to Step 35
35	<p>Check the ignition feed wire between the sensor and the PCM for a short to ground or open circuit.</p> <p>Is the action complete?</p>	—	Verify repair	—
36	<p>1. Ignition "ON."</p> <p>2. At the CKP harness connector, connect a test light between the ignition and ground terminals.</p> <p>Did the light illuminate?</p>	—	Go to Step 38	Go to Step 37
37	<p>Check the sensor ground circuit for an open or short to voltage.</p> <p>Is the action complete?</p>	—	Verify repair	—
38	<p>Check the signal circuit between the sensor and the PCM for a short to ground, short to voltage, or an open.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 39
39	<p>Replace the CKP position sensor.</p> <p>Is the action complete?</p>	—	Verify repair	Go to Step 33

Fuel System Electrical Test



D06RX014

Circuit Description

When the ignition switch is first turned "ON," the powertrain control module (PCM) energizes the fuel pump relay which applies power to the in-tank fuel pump. The fuel pump relay will remain "ON" as long as the engine is running or cranking and the PCM is receiving 58X crankshaft position pulses. If no 58X crankshaft position pulses are present, the PCM de-energizes the fuel pump relay within 2 seconds after the ignition is turned "ON" or the engine is stopped.

The fuel pump delivers fuel to the fuel rail and injectors, then to the fuel pressure regulator. The fuel pressure regulator controls fuel pressure by allowing excess fuel to be returned to the fuel tank. With the engine stopped and ignition "ON," the fuel pump can be turned "ON" by using a command by the Tech 2.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation, or a wire broken inside the insulation. Check for the following items:

- Poor connection or damaged harness – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. If the fuel pump is operating but incorrect pressure is noted, the fuel pump wiring is OK and the "Fuel System Pressure Test" chart should be used for diagnosis.

CAUTION: To reduce the risk of fire and personal injury:

- It is necessary to relieve fuel system pressure before connecting a fuel pressure gauge. Refer to Fuel Pressure Relief Procedure, below.
- A small amount of fuel may be released when disconnecting the fuel lines. Cover fuel line fittings with a shop towel before disconnecting, to catch any fuel that may leak out. Place the towel in an approved container when the procedure is completed.

2. Remove the fuel pump relay from the underhood relay center.
3. Start the engine and allow it to stall.
4. Crank the engine for an additional 3 seconds.

Fuel Gauge Installation

1. Remove the shoulder fitting cap.
2. Install fuel gauge J 34730-1 to the fuel feed line located in front of and above the right side valve cover.
3. Reinstall the fuel pump relay.

Fuel Pressure Relief Procedure

1. Remove the fuel cap.


Fuel System Electrical Test

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	<ol style="list-style-type: none"> 1. Read the "Caution" above. 2. Relieve the fuel system pressure and install the fuel pump pressure gauge to the test fitting. 3. Ignition SW is "ON". 4. Use a Tech 2 to command the fuel pump "ON." (Refer to Miscellaneous Test) Is there an immediate pressure build-up which indicates the pump is running?	—	Go to Step 3	Go to Step 4
3	<ol style="list-style-type: none"> 1. Verify that the pump is not running by removing the fuel filler cap and listening. 2. Command the pump "ON" with the Tech 2. Did the pump turn "OFF" after 2 seconds?	—	Test completed	Go to Step 12
4	<ol style="list-style-type: none"> 1. Ignition "OFF." 2. Remove the fuel pump relay. 3. Using a test light connected to ground, probe the battery feed to the relay. Did the light illuminate?	—	Go to Step 6	Go to Step 5
5	Repair short or open battery feed to fuel pump relay. Is the action complete?	—	Verify repair	—
6	<ol style="list-style-type: none"> 1. Connect a test light between the two wires that connect to the fuel pump relay pull-in coil. 2. Ignition "ON." Did the test light illuminate for 2 seconds and then turn off?	—	Go to Step 12	Go to Step 7
7	<ol style="list-style-type: none"> 1. With a test light connected to battery (–), probe the fuel pump relay connector at the wire which runs from the relay pull-in coil to the PCM. 2. Ignition "ON." Did the test light illuminate for 2 seconds and then turn off?	—	Go to Step 8	Go to Step 9
8	Locate and repair open in the fuel pump relay ground circuit. Is the action complete?	—	Verify repair	—

Fuel System Electrical Test (Cont'd)

Step	Action	Value(s)	Yes	No
9	Check for short or open between the PCM and the fuel pump relay. Was a problem found?	—	Verify repair	Go to Step 10
10	1. Check the fuel pump relay circuit for a poor terminal connection at the PCM. 2. If a problem is found, replace terminal as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
12	1. Reconnect the fuel pump relay. 2. Disconnect the fuel pump electrical connector at the fuel tank. 3. Using a test light connected to ground, probe the fuel pump feed wire (harness side). 4. Command the fuel pump "ON" with a Tech 2. Did the light illuminate for 2 seconds?	—	Go to Step 15	Go to Step 13
13	1. Substitute a known good relay for the fuel pump relay. 2. Leave the test light connected as in step 12. 3. Command the fuel pump "ON" with the Tech 2. 4. After this test, re-connect the known good relay in its proper location. Did the test light illuminate for 2 seconds when the fuel pump was commanded "ON?"	—	Go to Step 17	Go to Step 14
14	Check for a short circuit, blown fuse or open circuit between the relay and the fuel tank. Is the action complete?	—	Verify repair	—
15	1. With the fuel pump electrical connector at the fuel tank disconnected, connect a test light between the feed wire and the ground wire (harness side). 2. Command the fuel pump "ON" with a Tech 2. Did the test light illuminate for 2 seconds?	—	Go to Step 18	Go to Step 16
16	Repair the open circuit in the fuel pump ground wire. Is the action complete?	—	Verify repair	—
17	Replace the fuel pump relay. Is the action complete?	—	Verify repair	—
18	Replace the fuel pump. Is the action complete?	—	Verify repair	—

Fuel System Diagnosis



140RW022

Legend

- | | |
|-----------------------------------|----------------------------------|
| (1) Fuel Filler Cap | (8) Fuel Rail Left |
| (2) Fuel Tank | (9) Left Bank |
| (3) Rollover Valve | (10) Fuel Pressure Control Valve |
| (4) Fuel Pump and Sender Assembly | (11) Common Chamber |
| (5) Fuel Filter | (12) Duty Solenoid Valve |
| (6) Fuel Rail Right | (13) Throttle Valve |
| (7) Right Bank | (14) Canister |
| | (15) Evap Shut Off Valve |

Circuit Description

When the ignition switch is turned "ON," the powertrain control module (PCM) will turn "ON" the in-tank fuel pump. The in-tank fuel pump will remain "ON" as long as the engine is cranking or running and the PCM is receiving 58X crankshaft position pulses. If there are no 58X crankshaft position pulses, the PCM will turn the in-tank fuel pump "OFF" 2 seconds after the ignition switch is turned "ON" or 2 seconds after the engine stops running. The in-tank fuel pump is an electric pump within an integral reservoir. The in-tank fuel pump supplies fuel through an in-line fuel filter to the fuel rail assembly. The fuel pump is designed to provide fuel at a pressure above the pressure needed by the fuel injectors. A fuel pressure regulator, attached to the fuel rail, keeps the fuel available to the fuel injectors at a regulated pressure. Unused fuel is returned to the fuel tank by a separate fuel return line.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Connect the fuel pressure gauge to the fuel feed line as shown in the fuel system illustration. Wrap a shop towel around the fuel pressure connection in order to absorb any fuel leakage that may occur when installing the fuel pressure gauge. With the ignition switch "ON" and the fuel pump running, the fuel pressure indicated by the fuel pressure gauge should be 333-376 kPa (48-55 psi). This pressure is controlled by the amount of pressure the spring inside the fuel pressure regulator can provide.
3. A fuel system that cannot maintain a constant fuel pressure has a leak in one or more of the following areas:
 - The fuel pump check valve.
 - The fuel pump flex line.

- The valve or valve seat within the fuel pressure regulator.
- The fuel injector(s).

4. Fuel pressure that drops off during acceleration, cruise, or hard cornering may cause a lean condition. A lean condition can cause a loss of power, surging, or misfire. A lean condition can be diagnosed using a Tech 2. If an extremely lean condition occurs, the oxygen sensor(s) will stop toggling. The oxygen sensor output voltage(s) will drop below 500 mV. Also, the fuel injector pulse width will increase.

IMPORTANT: Make sure the fuel system is not operating in the "Fuel Cut-Off Mode."

When the engine is at idle, the manifold pressure is low (high vacuum). This low pressure (high vacuum) is applied to the fuel pressure regulator diaphragm. The low pressure (high vacuum) will offset the pressure being applied to the fuel pressure regulator diaphragm by the spring inside the fuel pressure regulator. When this happens, the result is lower fuel pressure. The fuel pressure at idle will vary slightly as the barometric pressure changes, but the fuel pressure at idle should always be less than the fuel pressure noted in step 2 with the engine "OFF."

16. Check the spark plug associated with a particular fuel injector for fouling or saturation in order to determine if that particular fuel injector is leaking. If checking the spark plug associated with a particular fuel injector for fouling or saturation does not determine that a particular fuel injector is leaking, use the following procedure:
- Remove the fuel rail, but leave the fuel lines and injectors connected to the fuel rail. Refer to *Fuel Rail Assembly in On-Vehicle Service*.
 - Lift the fuel rail just enough to leave the fuel injector nozzles in the fuel injector ports.

CAUTION: In order to reduce the risk of fire and personal injury that may result from fuel spraying on the engine, verify that the fuel rail is positioned over the fuel injector ports and verify that the fuel injector retaining clips are intact.

- **Pressurize the fuel system by connecting a 10 amp fused jumper between B+ and the fuel pump relay connector.**
- **Visually and physically inspect the fuel injector nozzles for leaks.**

17. A rich condition may result from the fuel pressure being above 376 kPa (55 psi). A rich condition may cause a DTC P0132 or a DTC P0172 to set. Driveability conditions associated with rich conditions can include hard starting (followed by black smoke) and a strong sulfur smell in the exhaust.

20. This test determines if the high fuel pressure is due to a restricted fuel return line or if the high fuel pressure is due to a faulty fuel pressure regulator.

21. A lean condition may result from fuel pressure below 333 kPa (48 psi). A lean condition may cause a DTC P0131 or a DTC P0171 to set. Driveability conditions associated with lean conditions can include hard starting (when the engine is cold), hesitation, poor driveability, lack of power, surging, and misfiring.

22. Restricting the fuel return line causes the fuel pressure to rise above the regulated fuel pressure. Command the fuel pump "ON" with the Tech 2. The fuel pressure should rise above 376 kPa (55 psi) as the fuel return line becomes partially closed.

NOTE: Do not allow the fuel pressure to exceed 414 kPa (60 psi). Fuel pressure in excess of 414 kPa (60 psi) may damage the fuel pressure regulator.

CAUTION: To reduce the risk of fire and personal injury:

- **It is necessary to relieve fuel system pressure before connecting a fuel pressure gauge. Refer to Fuel Pressure Relief Procedure, below.**
- **A small amount of fuel may be released when disconnecting the fuel lines. Cover fuel line fittings with a shop towel before disconnecting, to catch any fuel that may leak out. Place the towel in an approved container when the procedure is completed.**

Fuel Pressure Relief Procedure

1. Remove the fuel cap.
2. Remove the fuel pump relay from the underhood relay center.
3. Start the engine and allow it to stall.
4. Crank the engine for an additional 3 seconds.

Fuel Gauge Installation

1. Remove the shoulder fitting cap.
2. Install fuel gauge J 34730-1 to the fuel supply line located in front of and above the right side valve cover.
3. Reinstall the fuel pump relay.

Fuel System Diagnosis

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Turn the ignition "OFF." 2. Turn the air conditioning system "OFF." 3. Relieve fuel system pressure and install the fuel pressure gauge. 4. Turn the ignition "ON." NOTE: The fuel pump will run for approximately 2 seconds. Use the Tech 2 to command the fuel pump "ON". (Refer to Miscellaneous Test) 5. Observe the fuel pressure indicated by the fuel pressure gauge with the fuel pump running. Is the fuel pressure within the specified limits?	290-376 kPa (42-55 psi)	Go to Step 3	Go to Step 17
3	NOTE: The fuel pressure will drop when the fuel pump stops running, then it should stabilize and remain constant. Does the fuel pressure indicated by the fuel pressure gauge remain constant?	—	Go to Step 4	Go to Step 12
4	1. When the vehicle is at normal operation temperature, turn the ignition "ON" to build fuel pressure and observe the measurement on the gauge. 2. Start the engine and observe the fuel pressure gauge. Did the reading drop by the amount specified after the engine was started?	21-105 kPa (3-15 psi)	Go to Step 5	Go to Step 9
5	Is fuel pressure dropping off during acceleration, cruise, or hard cornering?	—	Go to Step 6	Check for improper fuel
6	Visually and physically inspect the following items for a restriction: ○ The in-pipe fuel filter. ○ The fuel feed line. Was a restriction found?	—	Verify repair	Go to Step 7
7	Remove the fuel tank and visually and physically inspect the following items: ○ The fuel pump strainer for a restriction. ○ The fuel line for a leak. ○ Verify that the correct fuel pump is in the vehicle. Was a problem found in any of these areas?	—	Verify repair	Go to Step 8
8	Replace the fuel pump. Is the action complete?	—	Verify repair	—
9	1. Disconnect the vacuum hose from the fuel pressure regulator. 2. With the engine idling, apply 12-14 inches of vacuum to the fuel pressure regulator. Does the fuel pressure indicated by the fuel pressure gauge drop by the amount specified?	21-105 kPa (3-15 psi)	Go to Step 10	Go to Step 11

Fuel System Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
10	Locate and repair the loss of vacuum to the fuel pressure regulator. Is the action complete?	—	Verify repair	—
11	Replace the fuel pressure regulator. Is the action complete?	—	Verify repair	—
12	1. Run the fuel pump with the Tech 2. 2. After pressure has built up, turn off the pump and clamp the supply hose shut with suitable locking pliers which will not damage the hose. Does the fuel pressure indicated by the fuel pressure gauge remain constant?	—	Go to Step 13	Go to Step 15
13	Visually inspect the fuel supply line and repair any leaks. Was a problem found?	—	Verify repair	Go to Step 14
14	Remove the fuel tank and inspect for leaky hose or in-tank fuel line. Was a problem found?	—	Verify repair	Go to Step 8
15	1. If the pliers are still clamped to the fuel supply hose, remove the locking pliers. 2. With suitable locking pliers which will not damage the hose, clamp the fuel return line to prevent fuel from returning to the fuel tank. 3. Run the fuel pump with the Tech 2. 4. After pressure has built up, remove power to the pump. Does the fuel pressure indicated by the fuel pressure gauge remain constant?	—	Go to Step 11	Go to Step 16
16	Locate and replace any leaking fuel injector(s). Is the action complete?	—	Verify repair	—
17	Is the fuel pressure indicated by the fuel pressure gauge above the specified limit?	376 kPa (55 psi)	Go to Step 18	Go to Step 21
18	1. Relieve the fuel pressure. Refer to the <i>Fuel Pressure Relief</i> . 2. Disconnect the fuel return line from the fuel rail. 3. Attach a length of flexible hose to the fuel rail return outlet passage. 4. Place the open end of the flexible hose into an approved gasoline container. 5. Run the fuel pump with the Tech 2. 6. Observe the fuel pressure indicated by the fuel pressure gauge with the fuel pump running. Is the fuel pressure within the specified limits?	290-376 kPa (42-55 psi)	Go to Step 19	Go to Step 20
19	Locate and correct the restriction in the fuel return line. Is the action complete?	—	Verify repair	—
20	Visually and physically inspect the fuel rail outlet passages for a restriction. Was a restriction found?	—	Verify repair	Go to Step 11

Fuel System Diagnosis (Cont'd)

Step	Action	Value(s)	Yes	No
21	Is the fuel pressure indicated by the fuel pressure gauge above the specified value?	0 kPa (0 psi)	Go to <i>Step 22</i>	Go to <i>Step 23</i>
22	<p>1. Command the fuel pump "ON" with the Tech 2.</p> <p>2. Using suitable pliers which will not damage the fuel hose, gradually apply pressure with the pliers to pinch the flexible fuel return hose closed.</p> <p>CAUTION: Do not let the fuel pressure exceed the second specified value.</p> <p>Does the fuel pressure indicated by the fuel pressure gauge rise above the first specified value?</p>	376 kPa (55 psi). 414 kPa (60 psi).	Go to <i>Step 11</i>	Go to <i>Step 7</i>
23	<p>1. Command the fuel pump "ON" with the Tech 2.</p> <p>2. Remove the fuel filler cap and listen for the sound of the fuel pump running.</p> <p>3. Turn the pump off.</p> <p>Was the fuel pump running?</p>	—	Go to <i>Step 7</i>	Go to <i>Fuel System Electrical Test Chart</i>

Idle Air Control (IAC) System Check

Circuit Description

The powertrain control module (PCM) controls engine idle speed with the idle air control (IAC) valve. To increase idle speed, the PCM retracts the IAC valve pintle away from its seat, allowing more air to bypass the throttle bore. To decrease idle speed, it extends the IAC valve pintle towards its seat, reducing bypass air flow. A Tech 2 will read the PCM commands to the IAC valve in counts. Higher counts indicate more air bypass (higher idle). Lower counts indicate less air is allowed to bypass (lower idle).

Diagnostic Aids

A slow, unstable, or fast idle may be caused by a non-IAC system problem that cannot be overcome by the IAC valve. Out of control range IAC Tech 2 counts will be above 60 if idle is too low, and zero counts if idle is too high. The following checks should be made to repair a non-IAC system problem:

- Vacuum leak (high idle) – If idle is too high, stop the engine. Fully extend (low) IAC with the IAC motor analyzer J 39027-A. Start the engine. If idle speed is above 800 RPM, locate and correct the vacuum leak, including the PCV system. Check for binding of the throttle blade or linkage.
- Lean heated oxygen sensor signal (high air/fuel ratio) – The idle speed may be too high or too low. Engine speed may vary up and down, and disconnecting the IAC valve does not help. Diagnostic trouble codes P0131, P0151, P0171, or P0174 may be set. Tech 2 oxygen (O₂) voltage will be less than 100 mV (0.1 V). Check for low regulated fuel pressure, water in fuel, or a restricted injector.
- Rich heated oxygen sensor signal (low air/fuel ratio) – The idle speed will be too low. Tech 2 IAC counts will usually be above 80. The system is obviously rich and may exhibit black smoke in the exhaust. Tech 2 O₂ voltage will be fixed at about 750 mV (0.75 V). Check for high fuel pressure, or a leaking or sticking injector. A silicon-contaminated heated oxygen sensor will show an O₂ voltage slow to respond on the Tech 2.

- Throttle body – Remove the IAC valve and inspect the bore for foreign material.
- IAC valve electrical connections – IAC valve connections should be carefully checked for proper contact.
- PCV valve – An incorrect or faulty PCV valve may result in an incorrect idle speed. Refer to *Diagnosis, Rough Idle, Stalling*. If intermittent poor driveability or idle symptoms are resolved by disconnecting the IAC, carefully recheck the connections and valve terminal resistance, or replace the IAC.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

1. The IAC motor analyzer J 39027-A is used to extend and retract the IAC valve. Valve movement is verified by an engine speed change. If no change in engine speed occurs, the valve can be resettled when removed from the throttle body.
2. This step checks the quality of the IAC movement in step 1. Between 700 revolutions per minute (RPM) and about 1500 RPM, the engine speed should change smoothly with each flash of the tester light in both extend and retract. If the IAC valve is retracted beyond the control range (about 1500 RPM), it may take many flashes to extend the IAC valve before engine speed will begin to drop. This is normal on certain engines. Fully extending the IAC may cause engine stall. This may be normal.
6. Steps 1 and 2 verified the proper IAC valve operation. This step checks the IAC circuits. Each lamp on the noid light should flash red and green while the IAC valve is cycled. While the sequence of color is not important, if either light is "OFF" or does not flash red and green, check the circuits for faults, beginning with poor terminal contacts.


Idle Air Control (IAC) System Check

Step	Action	Value(s)	Yes	No
1	1. Ignition "OFF." 2. Connect the IAC motor analyzer J 37027-A to the IAC valve. 3. Set the parking brake. 4. Block the wheels. 5. Turn the air conditioning "OFF." 6. Idle the engine in Park (A/T) or Neutral (M/T). 7. Install the Tech 2. Display the RPM. 8. Use the IAC motor analyzer J 39027-A to extend and retract the IAC valve. 9. The engine speed should decrease and increase as the IAC is cycled. Does the RPM change?	—	Go to Step 2	Go to Step 3
2	RPM should change smoothly with each flash of the IAC motor analyzer J 39027-A light. Does the RPM change within the range specified?	700-1500 RPM	Go to Step 6	Go to Step 3
3	Check the IAC passages. Are the IAC passages OK?	—	Go to Step 4	Go to Step 5
4	Clear any obstruction from the IAC passages. Is the action complete?	—	Verify repair	—
5	Replace the IAC. Refer to <i>On-Vehicle Service, Idle Air Control Valve</i> . Is the action complete?	—	Verify repair	—
6	1. Install the appropriate IAC noid light from J 39027-A into the powertrain control module harness. 2. Cycle the IAC motor analyzer J 39027-A and observe the noid lights. 3. Both the lights should cycle red and green, but never "OFF," as the RPM is changed over its range. Do the noid lights cycle red and green?	—	Go to Step 7	Go to Step 8
7	1. Use the other connector on the IAC motor analyzer J 39027-A pigtail. 2. Check the resistance across the IAC coils. Measure the resistance between terminal A and terminal B. 3. Measure the resistance between terminal C and terminal D. Is the resistance within the specified range?	40-80 ohms	Go to Step 9	Go to Step 10
8	If the circuits did not test green and red, check the following: <ul style="list-style-type: none"> ○ Faulty connector terminal contacts ○ Open circuits, including connections ○ Circuits shorted to ground or voltage ○ Faulty powertrain control module connection or powertrain control module. Are repairs necessary?	—	Go to Step 13	—

Idle Air Control (IAC) System Check (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Check the resistance between the IAC terminal B and terminal C. 2. Check the resistance between the IAC terminal A and terminal D. Is the resistance infinite?	—	Go to Step 11	Go to Step 12
10	Replace the IAC. Refer to <i>On-Vehicle Service, Idle Air Control Valve</i> . Is the action complete?	—	Go to Step 7	—
11	Check the IAC valve and circuit. Are the IAC valve and circuit OK?	—	Refer to <i>Diagnostic Aids</i>	Go to Step 12
12	Replace the IAC. Refer to <i>On-Vehicle Service, Idle Air Control Valve</i> . Is the action Complete?	—	Go to Step 9	—
13	Repair as necessary. Is the action complete?	—	Go to Step 6	—

Knock Sensor (KS) System Check (Engine Knock, Poor Performance, or Poor Economy)



Circuit Description

The knock sensor (KS) sends an AC voltage signal to the powertrain control module (PCM). As the KS detects engine knock, the signal to the PCM changes in amplitude and frequency. The PCM retards timing if the engine speed is over 900 RPM.

Diagnostic Aids

If the KS system checks OK, but detonation is the complaint, refer to *Diagnosis, Detonation/Spark Knock*.

Test Description

The numbers below refer to the step numbers on the Diagnostic Chart.

9. The change in signal speed depends on how hard the tapping is done. Normally there is about 1.5 to 10 mV at PCM pin A2 with the engine off. Loud tapping should be able to make the reading jump to 20-25 mV AC.


Knock Sensor (KS) System Check (Engine Knock, Poor Performance, or Poor Economy)

Step	Action	Value(s)	Yes	No
1	Is DTC P0325 or P0327 set?	—	Go to DTC P0325 or DTC P0327	Go to Step 2
2	Run the engine at 1500 RPM. Is there an internal engine knock?	—	Go to Step 3	Go to Step 4
3	Repair the mechanical problem. Is the action complete?	—	Verify repair	—
4	1. Install the Tech 2. 2. Turn the ignition "ON." 3. On the Tech 2 select F0: Data List, F4: Specific Engine, F3: Misfire. 4. Cycle through the list until "Knock Retard" is displayed. Is knock retard at the specified value?	0°	Go to Step 5	Go to Step 6

Knock Sensor (KS) System Check (Engine Knock, Poor Performance, or Poor Economy) (Cont'd)

Step	Action	Value(s)	Yes	No
5	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—
6	<p>1. Start the engine.</p> <p>2. Monitor the knock retard display on the Tech 2 while changing the throttle setting to place different loads on the engine.</p> <p>Is knock retard at the specified value? (Turn the ignition "OFF.")</p>	0°	Go to Step 9	Go to Step 7
7	<p>1. At the rear of the engine, behind the rear fuel injector on the side, disconnect the 2-wire knock sensor harness connector.</p> <p>NOTE: The connector for the knock sensor cannot easily be removal unless common chamber is removed. (Knock Sensor is on Right side of block). Also, there are two (2) shield grounded wires.</p> <p>The connector only has one wire (Yellow). Please use another method.</p> <p>2. Attach the positive lead of DVM to B+.</p> <p>3. On the main harness side of the connector, use the negative lead of the DVM to probe the connector pin that is connected to black wire.</p> <p>Does the DVM indicate the specified value? (Reconnect the knock sensor harness.)</p>	B+	Go to Step 9	Go to Step 8
8	<p>Repair the open black wire ground for the shield which prevents stray electromagnetic pulses from affecting the knock signal.</p> <p>Is the action complete?</p>	—	Verify repair	—
9	<p>1. Reconnect the wire harness if it was previously disconnected in Step 7.</p> <p>2. Set a DVM to AC voltage.</p> <p>3. With the DVM, backprobe the PCM connector at A2.</p> <p>4. Tap the engine lift bracket with a socket extension.</p> <p>Did the DVM show an increase in AC voltage while tapping on the lift bracket?</p>	—	System OK	Go to Step 10
10	<p>Replace the knock sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—

Exhaust Gas Recirculation (EGR) System Check



D06RW055

Circuit Description

A properly operation exhaust gas recirculation (EGR) system will directly affect the air/fuel requirements of the engine. Since the exhaust gas introduced into the air/fuel mixture is an inert gas (contains very little or no oxygen), less fuel is required to maintain a correct air/fuel ratio. Introducing exhaust gas into the combustion chamber lowers combustion temperatures and reduces the formation of oxides of nitrogen (NOx) in the exhaust gas. Lower combustion temperatures also prevent detonation. If the EGR pintle were to stay closed, the inert exhaust gas would be replaced with air and the air/fuel mixture would be leaner. The powertrain control module (PCM) would compensate for the lean condition by adding fuel, resulting in higher long term fuel trim values.

Diagnostic Aids

The EGR valve chart is a check of the EGR system. An EGR pintle constantly in the closed position could cause detonation and high emissions of NOx. It could also result in high long term fuel trim values in the open throttle cell, but not in the closed throttle cell. An EGR pintle constantly in the open position would cause a rough idle. Also, an EGR mounted incorrectly (rotated 180°) could cause rough idle. Check for the following items:

- EGR passages – Check for restricted or blocked EGR passages.
- Manifold absolute pressure sensor – A manifold absolute pressure sensor may shift in calibration enough to affect fuel delivery. Refer to *Manifold Absolute Pressure Output Check*.


Exhaust Gas Recirculation (EGR) System Check

Step	Action	Value(s)	Yes	No
1	Check the EGR valve for looseness. Is the EGR valve Loose?	—	Go to Step 2	Go to Step 3
2	Tighten the EGR valve. Is the action complete?	—	Verify repair	—

Exhaust Gas Recirculation (EGR) System Check (Cont'd)

Step	Action	Value(s)	Yes	No
3	1. Place the transmission selector in Park or Neutral. 2. Start the engine and idle until warm. 3. Using a Tech 2, command EGR "50% ON." (Refer to Miscellaneous Test) Does the engine idle rough and lose RPMs?	—	EGR system working properly. No problem found.	Go to <i>Step 4</i>
4	1. Engine "OFF." 2. Ignition "ON." 3. Using a test light to ground, check the EGR harness between the EGR valve and the ignition feed. Does the test light illuminate?	—	Go to <i>Step 6</i>	Go to <i>Step 5</i>
5	Repair the EGR harness ignition feed. Was the problem corrected?	—	Verify repair	Go to <i>Step 6</i>
6	1. Remove the EGR valve. 2. Visually and physically inspect the EGR valve pintle, valve passages and adapter for excessive deposits, obstructions or any restrictions. Does the EGR valve have excessive deposits, obstructions or any restrictions?	—	Go to <i>Step 7</i>	Go to <i>Step 8</i>
7	Clean or replace EGR system components as necessary. Was the problem corrected?	—	Verify repair	Go to <i>Step 8</i>
8	1. Ground the EGR valve metal case to battery (–). 2. Using a Tech 2, command EGR "ON" and observe the EGR valve pintle for movement. Does the EGR valve pintle move according to command?	—	Go to <i>Step 9</i>	Go to <i>DTC P1406 chart</i>
9	1. Remove the EGR inlet and outlet pipes from the intake and exhaust manifolds. 2. Visually and physically inspect manifold EGR ports and EGR inlet and outlet pipes for blockage or restriction caused by excessive deposits or other damage. Do the manifold EGR ports or inlet and outlet pipes have excessive deposits, obstructions, or any restrictions?	—	Go to <i>Step 10</i>	EGR system working properly. No problem found.
10	Clean or replace EGR system components as necessary. Is the action complete?	—	Verify repair	—

Manifold Absolute Pressure (MAP) Output Check



Circuit Description

The manifold absolute pressure (MAP) sensor measures the changes in the intake MAP which result from engine load (intake manifold vacuum) and engine speed changes; and converts these into a voltage output. The powertrain control module (PCM) sends a 5-volt reference voltage to the MAP sensor. As the MAP changes, the output voltage of the sensor also changes. By monitoring the the sensor output voltage, the PCM knows the MAP. A lower pressure (low voltage) output voltage will be about 1-2 volts at idle. Higher pressure (high voltage) output voltage will be about 4-4.8 volts at wide open throttle. The MAP sensor is also used, under certain conditions, to measure barometric pressure, allowing the PCM to make adjustments for different altitudes. The PCM uses the MAP sensor to diagnose proper operation of the EGR system, in addition to other functions.

Test Description

IMPORTANT: Be sure to use the same diagnostic test equipment for all measurements.

The number(s) below refer to the step number(s) on the Diagnostic Chart.

1. Applying 34 kPa (10 Hg) vacuum to the MAP sensor should cause the voltage to be 1.5-2.1 volts less than the voltage at step 1. Upon applying vacuum to the sensor, the change in voltage should be instantaneous. A slow voltage change indicates a faulty sensor.


IMPORTANT: Make sure the electrical connector remains securely fastened.

2. Disconnect the sensor from the bracket. Twist the sensor with your hand to check for an intermittent connection. Output changes greater than 0.10 volt indicate a bad sensor.

Manifold Absolute Pressure (MAP) Output Check

Step	Action	Value(s)	Yes	No
1	1. Turn the ignition "OFF" and leave it "OFF" for 15 seconds. 2. Ignition "ON." Don't crank engine. 3. The Tech 2 should indicate a manifold absolute pressure (MAP) sensor voltage. 4. Compare this scan reading to scan reading of a known good vehicle obtained using the exact same procedure as in Steps 1-4. Is the voltage reading the same ± 0.40 volt?	—	Go to Step 2	Go to Step 5
2	1. Disconnect the MAP sensor and plug inlet manifold. 2. Connect a hand vacuum pump to the MAP sensor. 3. Start the engine. 4. Apply 34 kPa (10 Hg) of vacuum and note the voltage change. Is the voltage change 1.5-2.1 volts less than step 1?	—	Go to Step 3	Go to Step 4
3	Check the sensor cover for leakage or restriction. Does the cover supply vacuum to the MAP sensor only?	—	Go to Step 5	Go to Step 4
4	Repair the material to block. Is the action complete?	—	Verify repair	—
5	Check the sensor connection. Is the sensor connection good?	—	Go to Step 5	Go to Step 6
6	Refer to <i>On-Vehicle Service, MAP Sensor</i> . Is the action complete?	—	Verify repair	—
7	Repair the poor connection. Is the action complete?	—	Verify repair	—

Evaporative (EVAP) Emissions Canister Purge Valve Check



D06RX016

Circuit Description

The evaporative emissions canister purge is controlled by a solenoid that allows manifold and/or vacuum to purge the canister when it is energized. The powertrain control module (PCM) supplies a ground to energize the solenoid valve (purge "ON"). The EVAP purge solenoid control is turned "ON" and "OFF" several times a second. The duty cycle (pulse width or "ON" time) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM and the purge solenoid is enabled when the appropriate conditions have been met:

- The engine run time after start is more than 60 seconds.
- The engine coolant temperature is above 30°C (86°F).
- The fuel control system is operating in the closed-loop mode.

Diagnostic Aids

- Make a visual check of vacuum hoses.
- Check the throttle body for possible cracked.
- Check the malfunction indicator lamp for a possible mechanical problem.

Test Description

The number(s) below refer to the step number(s) on the Diagnostic Chart.

1. Check to see if the solenoid is open or closed. The solenoid is normally de-energized in this step, so it should be closed.
2. This step checks to determine if the solenoid was open due to an electrical circuit problem or a defective solenoid.
3. This should normally energize the solenoid, opening the valve and allowing the vacuum to drop (purge "ON").


Evaporative (EVAP) Emissions Canister Purge Valve Check

Step	Action	Value(s)	Yes	No
1	1. Ignition "OFF." 2. Ignition "ON," engine "OFF." 3. At the throttle body, disconnect the hose that goes to the pump solenoid. 4. Using a hand vacuum pump with an attached vacuum gauge J 23738-A, apply vacuum (10" Hg or 34 kPa) to the solenoid. Does the solenoid hold the vacuum?	—	Go to Step 3	Go to Step 2
2	1. Disconnect the solenoid electrical connector. 2. As in Step 1, apply vacuum (10" Hg or 34 kPa) to the solenoid. Does the solenoid hold the vacuum?	—	Go to Step 4	Go to Step 7
3	1. At the throttle body, put a cap over the vacuum port where the hose was disconnected for testing. This is to prevent a vacuum leak when the engine is started. 2. Ignition "OFF." 3. Install the Tech 2. 4. Apply vacuum to the purge solenoid with the hand vacuum pump. 5. Start the engine, run at 2500 RPM. 6. Using the Tech 2, select F0: Engine, F3: Misc. Tests, F0: EVAP Purge. 7. Turn the purge solenoid "ON." Did the vacuum drop when the purge was turned on?	—	Go to Step 8	Go to Step 9
4	Check for a short to ground in the RED/BLU wire. Is there a short?	—	Go to Step 5	Go to Step 6
5	Repair the short to ground. Is the action complete?	—	Verify repair	—
6	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
7	Replace the faulty purge solenoid. Refer to <i>On-Vehicle Service, EVAP Canister Purge Solenoid</i> . Is the action complete?	—	Verify repair	—

Evaporative (EVAP) Emissions Canister Purge Valve Check (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Turn the ignition "OFF." 2. At the throttle body, install a vacuum gauge where the hose from the purge solenoid was disconnected for testing. 3. Start the engine. 4. Stabilize the engine speed at about 2500 RPM. 5. Momentarily snap the throttle open and let it return to idle. Is there approximately 10" Hg (34 kPa) of vacuum available at the EVAP emission canister purge solenoid?	—	No problem found in the EVAP emission canister purge valve check	Refer to <i>Diagnostic Aids</i>
9	1. Disconnect the solenoid electrical connector. 2. Connect a test lamp between the harness terminals. Does the test lamp light?	—	Go to Step 7	Go to Step 10
10	Probe terminal A and terminal B with a test lamp to ground. Does the test lamp light on both terminals?	—	Go to Step 11	Go to Step 12
11	Repair the short to voltage in the RED/BLUE wire. Is the action complete?	—	Verify repair	—
12	Does on of the terminals light the test lamp?	—	Go to Step 13	Go to Step 14
13	Check for an open in the RED/BLU wire between the purge solenoid and the PCM. Was there an open circuit?	—	Go to Step 15	Go to Step 6
14	Repair the open in the BLK/YEL wire. Is the action complete?	—	Verify repair	—
15	Repair the open in the RED/BLU wire. Is the action complete?	—	Verify repair	—

Up-Shift Lamp System Check



Circuit Description

The shift lamp indicates the best transmission shift point for maximum fuel economy.

The lamp is controlled by the Power Train Control Module (PCM) and is turned "ON" by grounding the BLK wire.

The PCM is used information from the following inputs to control the upshift lamp.

- Engine Coolant temperature (ECT) Sensor
- Throttle Position Sensor
- Vehicle Speed Sensor
- Engine Speed

The PCM uses the measured RPM and the vehicle speed to calculate what gear the vehicle is in.

It's this calculation that determines when the upshift lamp should be turned "ON".

Inspect the PCM harness and connector for proper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection and damaged harness.

Test Description

1. This should not turn "ON" the up-shift lamp. If the lamp is "ON", there is a short to ground in BLK or a fault PCM.
2. This checks the upshift lamp circuit up to the PCM connector.

If the up-shift lamp illuminates, then the PCM connector is faulty or PCM does not have the ability to ground the circuit.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation. Check for poor connections or a damaged harness.

Up-Shift Lamp System Check

Step	Action	Value(s)	Yes	No
1	<p>1. Verify the customer complaints in accordance with mentioned below: Go to the adequate Step Chart first.</p> <ul style="list-style-type: none"> ○ At the 1st gear position, the lamp doesn't illuminate: Go to Step Chart ○ At the 3rd gear position, the lamp doesn't illuminate: Go to Step Chart ○ Upshift Lamp doesn't illuminate always. <p>2. Ignition "ON", engine "OFF".</p> <p>3. Using the Tech 2, check to see if the upshift lamp turn "ON" or "OFF".</p> <p>Does the upshift lamp stay "OFF"?</p>	—	Go to Step 2	Go to Step 12
2	<p>Check for an open of 15A Turn Backup Fuse.</p> <p>Was a problem found?</p>	—	Go to Step 3	Go to Step 4 Refer to Section 8
3	<p>Replace the fuse.</p> <p>Is the action complete?</p>	Verify Repair	—	—
4	<p>Check for an burned out the Upshift Lamp.</p> <p>Was a problem found?</p>	—	Go to Step 5	Go to Step 6
5	<p>Replace the Upshift Lamp.</p> <p>Is the action complete?</p>	Verify Repair	—	—
6	<p>1. Check for an Clutch Switch operation and the fixing condition.</p> <p>2. Check for an open or short of clutch switch.</p> <p>3. Check for an open or short of WHT/GRN wiring harness between Turn Backup Fuse and Clutch Switch.</p> <p>Was a problem found?</p>	—	Go to Step 7	Go to Step 8

Up-Shift Lamp System Check (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Replace the Clutch Switch. Or, 2. Repair for an open or short of WHT/GRN wiring harness. Is the action complete?	Verify Repair	—	—
8	1. Check for an open or short of 1-2 Transmission Switch. 2. Check for an open or short of 3-4 Transmission Switch. 3. Check for an open or short of GRN wiring harness between Clutch Switch and Transmission Switches. Was a problem found?	—	Go to Step 9	Go to Step 10
9	1. Replace the applicable Transmission Switch. or, 2. Repair for an open or short of GRN wiring harness. Is the action complete?	Verify Repair	—	—
10	1. Check for an open or short in the Alarmer and Relay Control Unit. 2. Check for an open of BLU/ORN wiring harness between Transmission Switches and Alarmer Relay Control Unit. Was a problem found?	—	Go to Step 11	Go to Step 12
11	1. Replace the Alarmer and Relay Control Unit. Or, 2. Repair for an open of BLU/ORN wiring harness between Alarmer and Relay Control Unit and PCM connector. Is the action complete?	Verify Repair	—	Go to Step 15
12	1. Ignition "OFF". 2. Disconnect the PCM connectors. 3. Shift the gear to 1 st or 4 th gear position. 4. Turn ignition "ON", but <i>don't start the engine</i> . Does the Upshift Lamp Stay "ON"?	—	Go to Step 13	Go to Step 15
13	Check for an short to ground of YEL/GRN wiring harness between Alarmer and PCM connector. Was a problem found?	—	Go to Step 14	Go to Step 15
14	Repair for an open YEL/GRN wiring harness. Is the action complete?	Verify Repair	—	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed refer to <i>ON-Vehicle Service in Power Train Control Module and Sensor</i> for procedure. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	—	—

PCM Diagnostic Trouble Codes

The following table lists the diagnostic trouble codes supported by this vehicle application. If any DTCs not listed here are displayed by a Tech 2, the Tech 2 data may be faulty; notify the Tech 2 manufacturer of any DTCs displayed that are not included in the following table.

PCM Diagnostic Trouble Codes

DTC	Description	Type	Illuminate MIL
P0101	MAF System Performance	B	Yes
P0102	MAF Sensor Circuit Low Frequency	A	Yes
P0103	MAF Sensor Circuit High Frequency	A	Yes
P0106	MAP System Performance	B	Yes
P0107	MAP Sensor Circuit Low Voltage	A	Yes
P0108	MAP Sensor Circuit High Voltage	A	Yes
P0112	IAT Sensor Circuit Low Voltage	A	Yes
P0113	IAT Sensor Circuit High Voltage	A	Yes
P0117	ECT Sensor Circuit Low Voltage	A	Yes
P0118	ECT Sensor Circuit High Voltage	A	Yes
P0121	TP System Performance	A	Yes
P0122	TP Sensor Circuit Low Voltage	A	Yes
P0123	TP Sensor Circuit High Voltage	A	Yes
P0125	ECT Excessive Time to Closed Loop Fuel Control	B	Yes
P0131	HO2S Circuit Low Voltage Bank 1 Sensor 1	A	Yes
P0132	HO2S Circuit High Voltage Bank 1 Sensor 1	A	Yes
P0133	HO2S Slow Response Bank 1 Sensor 1	B	Yes
P0134	HO2S Circuit Insufficient Activity Bank 1 Sensor 1	A	Yes
P0135	HO2S Heater Circuit Bank 1 Sensor 1	B	Yes
P0137	HO2S Circuit Low Voltage Bank 1 Sensor 2	A	Yes
P0138	HO2S Circuit High Voltage Bank 1 Sensor 2	A	Yes
P0140	HO2S Circuit Insufficient Activity Bank 1 Sensor 2	A	Yes
P0141	HO2S Heater Circuit Bank 1 Sensor 2	B	Yes
P0151	HO2S Circuit Low Voltage Bank 2 Sensor 1	A	Yes
P0152	HO2S Circuit High Voltage Bank 2 Sensor 1	A	Yes
P0153	HO2S Slow Response Bank 2 Sensor 1	B	Yes
P0154	HO2S Circuit Insufficient Activity Bank 2 Sensor 1	A	Yes
P0155	HO2S Heater Circuit Bank 2 Sensor 1	B	Yes
P0157	HO2S Circuit Low Voltage Bank 2 Sensor 2	A	Yes
P0158	HO2S Circuit High Voltage Bank 2 Sensor 2	A	Yes
P0160	HO2S Circuit Insufficient Activity Bank 2 Sensor 2	A	Yes
P0161	HO2S Heater Circuit Bank 2 Sensor 2	B	Yes
P0171	Fuel Trim System Lean Bank 1	B	Yes
P0172	Fuel Trim System Rich Bank 1	B	Yes
P0174	Fuel Trim System Lean Bank 2	B	Yes
P0175	Fuel Trim System Rich Bank 2	B	Yes
P0201	Injector 1 Control Circuit	A	Yes

6E2-116 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

DTC	Description	Type	Illuminate MIL
P0202	Injector 2 Control Circuit	A	Yes
P0203	Injector 3 Control Circuit	A	Yes
P0204	Injector 4 Control Circuit	A	Yes
P0205	Injector 5 Control Circuit	A	Yes
P0206	Injector 6 Control Circuit	A	Yes
P0300	Engine Misfire Detected	B	Yes
P0301	Cylinder 1 Misfire Detected	B	Yes
P0302	Cylinder 2 Misfire Detected	B	Yes
P0303	Cylinder 3 Misfire Detected	B	Yes
P0304	Cylinder 4 Misfire Detected	B	Yes
P0305	Cylinder 5 Misfire Detected	B	Yes
P0306	Cylinder 6 Misfire Detected	B	Yes
P0325	KS Module Circuit	B	No
P0327	KS Sensor Circuit	B	No
P0336	58X Reference Signal Circuit	B	Yes
P0337	CKP Sensor Circuit Low Frequency	B	Yes
P0341	CMP Sensor Circuit Performance	B	Yes
P0342	CMP Sensor Circuit Low	B	Yes
P0351	Ignition 1 Control Circuit	A	Yes
P0352	Ignition 2 Control Circuit	A	Yes
P0353	Ignition 3 Control Circuit	A	Yes
P0354	Ignition 4 Control Circuit	A	Yes
P0355	Ignition 5 Control Circuit	A	Yes
P0356	Ignition 6 Control Circuit	A	Yes
P0401	EGR Flow Insufficient	A	Yes
P0402	EGR Pintel Crank Open Error	B	Yes
P0404	EGR Open Stuck	B	Yes
P0405	EGR Lo Volt	A	Yes
P0406	EGR Hi Voltage	A	Yes
P0420	TWC System Low Efficiency Bank 1	A	Yes
P0430	TWC System Low Efficiency Bank 2	A	Yes
P0440	EVAP System	A	Yes
P0442	EVAP System Small Leak Detected	B	Yes
P0446	EVAP Canister Vent Blocked	A	Yes
P0452	Tank Pressure Sensor Lo Voltage	A	Yes
P0453	Fuel Tank Pressure Sensor Hi Voltage	A	Yes
P0462	Fuel Level Sensor Circuit – Low Voltage	D	No
P0463	Fuel Level Sensor Circuit – High Voltage	D	No
P0502	VSS Circuit Low Input	B	Yes
P0506	Idle Air Control System Low RPM	B	Yes
P0507	Idle Air Control System High RPM	B	Yes
P0562	System Voltage Low	D	No
P0563	System Voltage High	D	No


RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS 6E2-117

DTC	Description	Type	Illuminate MIL
P0601	PCM Memory	A	Yes
P0705	Transmission Rang Sensor Illegal Position (Refer to <i>4L30-E Automatic Transmission</i>)	D	No
P0706	Transmission Range Sensor Performance (Refer to <i>4L30-E Automatic Transmission</i>)	D	No
P0712	Transmission Fluid Temperature (TFT) Low Voltage (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	D	No
P0713	Transmission Fluid Temperature (TFT) High Voltage (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	D	No
P0719	Brake Switch Circuit Low (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	D	No
P0722	Output Speed Sensor Circuit No Signal (Refer to <i>4L30-E Automatic Transmission</i>)	A	Yes
P0723	Output Speed Sensor Circuit Intermittent Signal (Refer to <i>4L30-E Automatic Transmission</i>)	A	Yes
P0724	Brake Switch Circuit High (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	D	Yes
P0730	Incorrect Gear Ratio (Refer to <i>4L30-E Automatic Transmission</i>)	C	No
P0742	Torque Converter Clutch (TCC) Circuit Stuck On (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes
P0748	Transmission Pressure Control Solenoid (PCS) – Electrical Circuit Fault (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	C	No
P0751	Transmission Shift Solenoid “A” Performance or Stuck OFF (Automatic Transmission Only)	B	Yes
P0753	Transmission Shift Solenoid “A” – Electrical Circuit Fault (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes
P0756	Transmission Shift Solenoid “B” Performance Stuck OFF (Automatic Transmission Only)	B	Yes
P0758	Transmission Shift Solenoid “B” – Electrical Circuit Fault (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes
P1106	MAP Sensor Circuit Intermittent High Voltage	D	No
P1107	MAP Sensor Circuit Intermittent Low Voltage	D	No
P1111	IAT Sensor Circuit Intermittent High Voltage	D	No
P1112	IAT Sensor Circuit Intermittent Low Voltage	D	No
P1114	ECT Sensor Circuit Intermittent Low Voltage	D	No
P1115	ECT Sensor Circuit Intermittent High Voltage	D	No
P1121	TP Sensor Circuit Intermittent High Voltage	D	No
P1122	TP Sensor Circuit Intermittent Low Voltage	D	No
P1133	HO2S Insufficient Switching Bank 1 Sensor 1	B	Yes
P1134	HO2S Transition Time Ratio Bank 1 Sensor 1	B	Yes
P1153	HO2S Insufficient Switching Bank 2 Sensor 1	B	Yes
P1154	HO2S Transition Time Ratio Bank 2 Sensor 1	B	Yes
P1171	Fuel System Lean During Acceleration	A	Yes
P1380	ABS Rough Road ABS System Fault	D	Yes
P1381	ABS Rough Class 2 Serial Link Error	D	Yes
P1404	EGR Closed Stuck	D	Yes
P1441	EVAP System Flow During Non-Purge	B	Yes

6E2-118 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

DTC	Description	Type	Illuminate MIL
P1508	IAC System Low RPM	B	Yes
P1509	IAC System High RPM	B	Yes
P1618	Serial Peripheral Interface (SPI) PCM Interprocessor Communication Error (Automatic Transmission Only)	A	Yes
P1625	PCM Unexpected Reset	A	Yes
P1640	Driver-1-Input High Voltage	D	No
P1650	Quad Driver Module "A" Fault	D	Yes
P1790	TRANS ROM Checksum Error (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes
P1792	TRANS EEPROM Checksum Error (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes
P1835	TRANS Kick Down Switch Malfunction (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	D	No
P1850	Brake Band Apply Solenoid Manlfuction (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	D	No
P1860	TCC PWM Solenoid Circuit Fault (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes
P1870	Transmission Component Slipping (Refer to <i>4L30-E Automatic Transmission Diagnosis</i>)	A	Yes

Diagnostic Trouble Code (DTC) P0101 MAF System Performance



D06RW057

Circuit Description

The mass air flow (MAF) sensor measures the amount of air which passes through it into the engine during a given time. The powertrain control module (PCM) uses the mass air flow information to monitor engine operating conditions for fuel delivery calculations. A large quantity of air entering the engine indicates an acceleration or high load situation, while a small quantity of air indicates deceleration or idle.

The MAF sensor produces a frequency signal which can be monitored using a Tech 2. The frequency will vary within a range of around 4 to 7 g/s at idle to around 25 to 40 g/s at maximum engine load. DTC P0101 will be set if the signal from the MAF sensor does not match a predicted value based on throttle position and engine RPM.

Conditions for Setting the DTC

- The engine is running.
- No TP sensor or MAP sensor DTCs are set.
- The throttle is steady, TP angle doesn't change by more than 1%.
- System voltage is between 11.5 volts and 16 volts.
- Calculated air flow is between 25 g/second and 40 g/second.
- Above conditions present for at least 1 second.
- MAF signal frequency indicates an airflow significantly higher or lower than a predicted value based on throttle position and engine RPM for a total of 12.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM calculates an airflow value based on idle air control valve position, throttle position, RPM and barometric pressure.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0101 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0101 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

An intermittent may be caused by the following:

- Poor connections.
 - Mis-routed harness.
 - Rubbed through wire insulation.
 - Broken wire inside the insulation.
- Refer to Intermittents under service category Symptoms. Any un-metered air may cause this DTC to set. Check for the following:

6E2-120 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- ☐ The duct work at the MAF sensor for leaks.
- ☐ An engine vacuum leak.
- ☐ The PCV system for vacuum leaks.
- ☐ An incorrect PCV valve.
- ☐ The engine oil dip stick not fully seated.
- ☐ The engine oil fill cap loose or missing.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. The MAF system performance or "rationality" diagnostic uses the MAP sensor signal along with other input to calculate an expected airflow rate that is then compared to the actual measured airflow from the MAF sensor. The first few steps of this table verify that the MAP sensor is working properly.
6. Verifies the signal circuit from the MAF sensor electrical connector to the PCM.
Verifies whether a ground and B+ circuit is available.


DTC P0101 – MAF System Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "OFF." 2. Disconnect the Mass Air Flow (MAF) Sensor harness connector from the MAF Sensor. 3. Place an unpowered test lamp between the 12 volt signal circuit and the ground circuit, both at the MAF Sensor connector. 4. Ignition "ON," Engine "OFF." Did the test lamp illuminate?	—	Go to Step 6	Go to Step 3
3	1. Ignition "ON," Engine "OFF." 2. Using a Digital Voltmeter (DVM), check the 12 volt signal circuit for the correct voltage. Did the DVM indicate a value within the following range?	11.5 to 12.5 Volt	Go to Step 5	Go to Step 4
4	1. Ignition "OFF." 2. Check the 12 volt signal circuit for the following conditions: <ul style="list-style-type: none"><input type="radio"/> An open circuit<input type="radio"/> A short to ground Was the problem found?	—	Verify repair	—
5	Check the MAF ground circuit for the following conditions: <ul style="list-style-type: none"><input type="radio"/> An open circuit<input type="radio"/> A short to voltage Was a problem found?	—	Verify repair	—
6	1. Ignition "OFF." 2. Check the MAF Sensor signal circuit between the PCM and the MAF Sensor for the following conditions: <ul style="list-style-type: none"><input type="radio"/> An open circuit<input type="radio"/> A short to ground<input type="radio"/> A short to battery voltage Was a problem found?	—	Verify repair	Go to Step 7

DTC P0101 – MAF System Performance (Cont'd)

Step	Action	Value(s)	Yes	No
7	<ol style="list-style-type: none"> 1. Connect the MAF Sensor wiring harness connector to the MAF Sensor. 2. Connect the Tech 2 to the vehicle. 3. Place the Transmission in Park/Neutral, and fully apply the Parking Brake. 4. Start the engine. 5. Select the Mass Air Flow (MAF) parameter on the Tech 2. <p>With the engine idling, does the Tech 2 display the following value(s)?</p>	4 to 7 g/s	Go to Step 8	Go to Step 9
8	<p>Observe the Tech 2 value while increasing the engine RPM to its upper limit.</p> <p>Does the Tech 2 display the following value(s)?</p>	25 to 40 g/s	Go to Step 10	Go to Step 9
9	<p>Replace the MAF Sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—
10	<p>Replace the PCM.</p> <p>IMPORTANT: The PCM must be reprogrammed. Refer to PCM reprogramming.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0102 MAF Sensor Circuit Low Frequency



D06RW057

Circuit Description

The mass air flow (MAF) sensor measures the amount of air which passes through it into the engine during a given time. The powertrain control module (PCM) uses the mass air flow information to monitor engine operating conditions for fuel delivery calculations. A large quantity of air entering the engine indicates an acceleration or high load situation, while a small quantity of air indicates deceleration or idle.

The MAF sensor produces a frequency signal which can be monitored using a Tech 2. The frequency will vary within a range of around 4 to 7 g/s at idle to around 1900 Hz at maximum engine load. DTC P0102 will be set if the signal from the MAF sensor is below the possible range of a normally operating MAF sensor.

Conditions for Setting the DTC

- The engine is running above 500 RPM for greater than 10 seconds.
- System voltage is above 11.5 volts.
- MAF signal frequency is below 1.6 g/s for a total of 50-percent of the last 1000 samples monitored. A sample is taken every cylinder event.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM calculates an air flow value based on idle air control valve position, throttle position, RPM and barometric pressure.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0102 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0102 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Misrouted harness – Inspect the MAF sensor harness to ensure that it is not routed too close to high voltage wires.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 while moving connectors and wiring harnesses related to the MAF sensor. A change in the display will indicate the location of the fault.
- Plugged intake air duct or filter element – A wide-open throttle acceleration from a stop should cause the mass air flow displayed on a Tech 2 to increase from

about 3-6 g/second at idle to 100 g/second or greater at the time of the 1-2 shift. If not, check for a restriction. If DTC P0102 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. This step verifies that the problem is present at idle.
4. A voltage reading of less than 4 or over 5 volts at the MAF sensor signal circuit indicates a fault in the wiring or a poor connection.
5. This verifies that ignition feed voltage and a good ground are available at the MAF sensor.


DTC P0102 – MAF Sensor Circuit Low Frequency

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. 2. With the engine idling, monitor "MAF Frequency" display on the Tech 2. Is the "MAF Frequency" below the specified value?	2.85 – 6.65 g/s	Go to Step 4	Go to Step 5
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0102. Does the Tech 2 indicate DTC P0102 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Ignition "OFF." 2. Disconnect the MAF sensor connector. 3. Ignition "ON," engine "OFF." 4. Using a DVM, measure voltage between the MAF sensor signal circuit and battery ground. Is the voltage near the specified value?	5 V	Go to Step 5	Go to Step 8
5	Connect a test light between the MAF sensor ignition feed and ground circuits at the MAF sensor harness connector. Is the test light "ON?"	—	Go to Step 13	Go to Step 6
6	Connect a test light between the MAF sensor ignition feed circuit and battery ground. Is the test light "ON?"	—	Go to Step 12	Go to Step 7
7	1. Check for a poor connection at the MAF sensor. 2. If a poor connection is found, replace the faulty terminal(s). Was a poor connection found?	—	Verify repair	Go to Step 11
8	1. Ignition "OFF." 2. Disconnect the MAF sensor. 3. Disconnect the PCM connector for the MAF signal circuit. 4. Ignition "ON," engine "OFF." 5. With the DVM, measure the voltage between the MAF signal terminal at the PCM and battery ground. Is the voltage under the specified value?	4 V	Go to Step 9	Go to Step 10

DTC P0102 – MAF Sensor Circuit Low Frequency (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Ignition "OFF." 2. Disconnect the PCM white connector. 3. Ignition "ON." 4. Check the MAF sensor signal circuit for a short to 5 volts. Is the action complete?	—	Verify repair	—
10	1. Ignition "OFF." 2. Disconnect the PCM white connector. 3. Ignition "ON." 4. Check the MAF sensor signal circuit between the PCM and the MAF sensor for an open, short to ground, or short to the MAF ground circuit. Is the action complete?	—	Verify repair	Go to Step 13
11	Locate and repair the open in the ground circuit to the MAF sensor. Is the action complete?	—	Verify repair	—
12	Locate and repair the open in the ignition feed circuit to the MAF sensor. Is the action complete?	—	Verify repair	—
13	Replace the MAF sensor. Is the action complete?	—	Verify repair	Go to Step 14
14	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0103 MAF Sensor Circuit High Frequency



D06RW057

Circuit Description

The mass air flow (MAF) sensor measures the amount of air which passes through it into the engine during a given time. The powertrain control module (PCM) uses the mass air flow information to monitor engine operating conditions for fuel delivery calculations. A large quantity of air entering the engine indicates an acceleration or high load situation, while a small quantity of air indicates deceleration or idle.

The MAF sensor produces a frequency signal which can be monitored using a Tech 2. The frequency will vary within a range of around 4 to 7 g/s at idle to around 9000 Hz at maximum engine load. DTC P0103 will be set if the signal from the MAF sensor is above the possible range of a normally operating MAF sensor.

Conditions for Setting the DTC

- The engine is running above 500 RPM for more than 10 seconds.
- System voltage is above 11.5 volts.
- MAF signal frequency is above 40 g/s for a total of 50 percent of the last 200 samples monitored. A sample is taken every cylinder event.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- The PCM calculates an airflow value based on idle air control valve position, throttle position, RPM and barometric pressure.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0103 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0103 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

If DTC P0103 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.


2. This step verifies that the problem is present at idle.

4. A frequency reading with the MAF sensor connector disconnected indicates an electromagnetic interference (EMI) related fault.
9. This vehicle is equipped with a PCM which utilizes an electrically erasable programmable read only memory (EEPROM). When the PCM is being replaced, the new PCM must be programmed. Refer to *PCM Replacement and Programming Procedures* in *Powertrain Control Module (PCM) and Sensor*.

DTC P0103 – MAF Sensor Circuit High Frequency

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0103. Does the Tech 2 indicate DTC P0103 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Start the engine. 2. With the engine idling, monitor "MAF Frequency" display on the Tech 2. Is "MAF Frequency" above the specified value?	40 g/s	Go to Step 4	Go to Step 7
4	1. Ignition "OFF." 2. Disconnect the MAF sensor connector. 3. Ignition "ON," engine idling. 4. Using a Tech 2, monitor "MAF Frequency." Does the Tech 2 indicate a "MAF Frequency" at the specified value?	0 g/s	Go to Step 5	Go to Step 6
5	Replace the MAF sensor. Is the action complete?	—	Verify repair	Go to Step 8
6	1. Check the MAF harness for incorrect routing near high voltage components (solenoids, relays, motors). 2. If incorrect routing is found, correct the harness routing. Was a problem found?	—	Verify repair	Go to Step 6
7	1. With the engine idling, monitor "MAF Frequency" display on the Tech 2. 2. Quickly snap open throttle to wide open throttle while under a road load and record value. Does the Tech 2 indicate "MAF Frequency" above the specified value?	40 g/s	Go to Step 5	Go to Step 8
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0106 MAP System Performance



D06RX015

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure (vacuum). The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (high vacuum) to above 4 volts at wide-open throttle (low vacuum) at sea level.

The MAP sensor is used to determine: manifold pressure changes while the linear exhaust gas recirculation (EGR) flow test diagnostic is being run (refer to DTC P0401), engine vacuum level for some other diagnostics, and barometric pressure (BARO). The PCM compares the MAP sensor signal to a calculated MAP based on throttle position and various engine load factors. If the PCM detects a MAP signal that varies excessively above or below the calculated value, DTC P0106 will set.

Conditions for Setting the DTC

- No TP sensor DTCs are present.
- Engine speed is steady, changing less than 100 RPM.
- Throttle position is steady, throttle angle changes less than 1%.
- EGR flow rate is steady, changing less than 4%.
- IAC valve counts are steady, changing less than 10 counts.
- No change in brake switch, A/C clutch, TCC or power steering pressure switch status.
- Above conditions are met for longer than 1 second.
- Actual MAP value varies more than 10 kPa.

- The MAP value must vary for a total of 10 seconds over a 20-second period of time that the samples were monitored.
- The failure must occur for 2 consecutive trips.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will default to a BARO value of 79.3 kPa.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0106 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0106 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0106 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently,

performing the DTC P1106 or P1107 Diagnostic Chart may isolate the cause of the fault.

- The MAP sensor shares a 5 Volt Reference with the Rough Road sensor. If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.
- The MAP sensor shares a ground with the Rough Road Sensor, the ECT sensor, and the Transmission Fluid Temperature sensor.

DTC P0106 – MAP System Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0106. Does the Tech 2 indicate DTC P0106 failed? (If no, start with diagnostic chart other sensors in the circuit and see if 5 V returns)	—	Go to Step 4	Go to Step 3
3	1. Check for the following conditions: <ul style="list-style-type: none"> ○ Vacuum hoses disconnected, damaged, or incorrectly routed; ○ Intake manifold vacuum leaks; ○ Vacuum leaks at throttle body; ○ Vacuum leaks at EGR valve flange and pipes; ○ Crankcase ventilation valve faulty, missing or incorrectly installed. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to <i>Diagnostic Aids</i>
4	1. Disconnect the MAP sensor electrical connector. 2. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	11 kPa	Go to Step 5	Go to Step 13
5	1. Connect a test light between B+ and the MAP sensor signal circuit at the MAP sensor harness connector. 2. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	105 kPa	Go to Step 6	Go to Step 9
6	1. Jumper the 5 volt reference "A" circuit and the MAP signal circuit together at the MAP sensor harness connector. 2. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	104 kPa	Go to Step 7	Go to Step 8
7	1. Ignition "OFF." 2. Disconnect the PCM and check the sensor ground circuit for high resistance, an open between the PCM and the MAP sensor, or for a poor connection at the PCM. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 11

DTC P0106 – MAP System Performance (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Check the 5 volt reference "A" circuit for high resistance, an open between the PCM and the MAP sensor, or a poor connection at the PCM. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10
9	1. Ignition "OFF." 2. Disconnect the PCM, and check the MAP sensor signal circuit for high resistance, an open, a short to ground, or a short to the sensor ground circuit. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10
10	1. Check the MAP sensor signal circuit for a poor connection at the PCM. 2. If a problem is found, repair as necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
11	1. Check for a poor connection at the MAP sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	Replace the MAP sensor. Is the action complete?	—	Verify repair	—
13	1. Ignition "OFF," disconnected the PCM. 2. Ignition "ON," check the MAP signal circuit for a short to voltage or a short to the 5 volt reference "A" circuit. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 14
14	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—



MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0107 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P0107 Diagnostic Chart may isolate the cause of the fault.

○ The MAP sensor shares a 5 Volt Reference with the Fuel pressure sensor. If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.

○ The MAP sensor shares a ground with the Fuel pressure Sensor, the ECT sensor, and the Transmission Fluid Temperature sensor.


DTC P0107 – MAP Sensor Circuit Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. With the throttle closed, observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value?	11 kPa at sea level	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0107. Does the Tech 2 indicate DTC P0107 failed?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Ignition "OFF." 2. Disconnect the MAP sensor electrical connector. 3. Jumper the 5 volt reference "A" circuit and the MAP signal together at the MAP sensor harness connector. 4. Ignition "ON." 5. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	5 V 104 kPa	Go to Step 10	Go to Step 5
5	1. Disconnect the jumper. 2. Connect a test light between B+ and the MAP sensor signal circuit at the MAP sensor harness connector. 3. Observe the MAP value displayed on the Tech 2. Is the MAP value near the specified value.	5 V 104 kPa	Go to Step 6	Go to Step 8
6	1. Ignition "OFF." 2. Disconnect the PCM and check the 5 volt reference "A" circuit for an open or short to ground. 3. If the 5 volt reference "A" circuit is open or shorted to ground, repair it as necessary. Was the 5 volt reference "A" circuit open or shorted to ground?	—	Verify repair	Go to Step 7
7	Check the 5 volt reference "A" circuit for a poor connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 11

DTC P0107 – MAP Sensor Circuit Low Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
8	<p>1. Ignition "OFF."</p> <p>2. Disconnect the PCM, and check the MAP signal circuit for an open, short to ground, or short to the sensor ground circuit.</p> <p>3. If the MAP sensor signal circuit is open or shorted to ground, repair it as necessary.</p> <p>Was the MAP signal circuit open or shorted to ground?</p>	—	Verify repair	Go to <i>Step 9</i>
9	<p>Check the MAP sensor signal circuit for a poor connection at the PCM and the MAP sensor; replace the terminal if necessary.</p> <p>Did the terminal require replacement?</p>	—	Verify repair	Go to <i>Step 11</i>
10	<p>Replace the MAP sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—
11	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0108 MAP Sensor Circuit High Voltage



D06RX015

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure (vacuum). The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (high vacuum) to above 4 volts with the key "ON," engine not running or at wide- open throttle (low vacuum). The MAP sensor is used to determine manifold pressure changes while the linear EGR flow test diagnostic is being run (refer to *DTC P0401*), to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). The PCM monitors the MAP signals for voltages outside the normal range of the MAP sensor. If the PCM detects a MAP signal voltage that is excessively high, DTC P0108 will be set.

Conditions for Setting the DTC

- No TP sensor DTCs present.
- Engine is running for more than 10 seconds.
- Throttle position is below 3% if engine speed is below 1000 RPM.
- Throttle position is below 10% if engine speed is above 1000 RPM.
- The MAP sensor indicates an intermittent manifold absolute pressure above 80 kPa for a total of approximately 10 seconds over a 16-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will default to a BARO value of 79.3 kPa.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0108 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0108 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0108 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P1108 Diagnostic Chart may isolate the cause of the fault.

- The MAP sensor shares a 5 Volt Reference with the Fuel pressure sensor. If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.
- The MAP sensor shares a ground with the Fuel pressure Sensor, the ECT sensor, and the Transmission Fluid Temperature sensor.


DTC P0108 – MAP Sensor Circuit High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. If the engine idle is rough, unstable or incorrect, repair the idle problem before using this chart. Refer to <i>Symptoms</i> section. 2. With the engine idling, note the MAP value on the Tech 2. Is the MAP reading above the specified value?	90 kPa	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0108. Does the Tech 2 indicate DTC P0108 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Ignition "OFF." 2. Disconnect the MAP sensor electrical connector. 3. Ignition "ON." 4. Note the MAP sensor voltage displayed on the Tech 2. Is the MAP sensor voltage at the specified value? (If no, start with diagnostic chart for other sensors in the circuit and see if 5 V returns)	0.0 V 11 kPa	Go to Step 5	Go to Step 6
5	Probe the sensor ground circuit with a test light to B+. Is the test light "ON?"	—	Go to Step 7	Go to Step 9
6	1. Check the MAP signal circuit for a short to voltage or a short to the 5 volt reference "A" circuit. 2. If the MAP sensor signal circuit is shorted, repair circuit as necessary. Was the MAP sensor signal circuit shorted?	—	Verify repair	Go to Step 11
7	1. Check for a poor sensor ground terminal connection at the MAP sensor electrical connector. 2. If a problem is found, replace the faulty terminal. Did the terminal require replacement?	—	Verify repair	Go to Step 8
8	Check for a plugged or leaking vacuum supply to the MAP sensor. Is the vacuum supply plugged or leaking?	—	Verify repair	Go to Step 12
9	1. Check for a poor sensor ground terminal connection at the PCM. 2. If a problem is found, replace the faulty terminal. Did the terminal require replacement?	—	Verify repair	Go to Step 10

DTC P0108 – MAP Sensor Circuit High Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Check the continuity of the MAP sensor ground circuit. 2. If the MAP sensor ground circuit measures over 5 ohms, repair open or poor connection. Was a condition found and corrected?	—	Verify repair	Go to <i>Step 11</i>
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify Repair	—
12	Replace the MAP sensor. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0112 IAT Sensor Circuit Low Voltage



D06RW078

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance is lower, causing the PCM to monitor a lower voltage. DTC P0112 will set when the PCM detects an excessively low signal voltage on the intake air temperature sensor signal circuit.

Conditions for Setting the DTC

- The engine has been running for over 2 minutes.
- Vehicle speed is greater than 30 mph (48 km/h) .
- IAT signal voltage indicates an intake air temperature greater than 148°C (298°F) (about 5 volts) for a total of 12.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0112 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0112 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault. If DTC P0112 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Verifies that the fault is present.

3. If DTC P0112 can be repeated only by duplicating the Failure Records condition, refer to the *Temperature vs. Resistance Value* table. The table may be used to test the IAT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be stored above or below a certain temperature. If this is the case, replace the IAT sensor. If the IAT sensor appears to be OK, the fault is intermittent; refer to *Diagnostic Aids*.


Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P0112 – IAT Sensor Circuit Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Using a Tech 2, monitor the intake air temperature (IAT). Is the intake air temperature greater than the specified value?	148°C (283°F)	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." Review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor the "DTC" info for DTC P0112. Does the Tech 2 indicate DTC P0112 failed this ignition?	—	Refer to <i>Test Description</i>	Refer to <i>Diagnostic Aids</i>
4	1. Ignition "OFF." 2. Disconnect the IAT sensor electrical connector. 3. Ignition "ON." 4. Observe the intake air temperature on the Tech 2. Is the intake air temperature below the specified value?	-38°C (-36°F)	Go to Step 6	Go to Step 5
5	1. Ignition "OFF." 2. Disconnect the PCM electrical connectors. 3. Check the IAT sensor signal circuit for a short to ground. Is the IAT sensor signal circuit shorted to ground?	—	Verify repair	Go to Step 7
6	Replace the IAT sensor. Is the action complete?	—	Verify repair	—
7	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0113 IAT Sensor Circuit High Voltage



D06RW078

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance is lower causing the PCM to monitor a lower voltage. DTC P0113 will set when the PCM detects an excessively high signal voltage on the intake air temperature sensor signal circuit.

Conditions for Setting the DTC

- The engine has been running for over 4 minutes.
- Vehicle speed is less than 20 mph (32 km/h).
- ECT signal temperature is above 60°C (140°F).
- Mass air flow is less than 20 g/second.
- IAT signal voltage indicates an intake air temperature less than -39°C (-38°F) for total of 12.5 seconds over a 25-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0113 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0113 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

If DTC P0113 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart:

2. Verifies that the fault is present.

3. If DTC P0113 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Values" table. The table may be used to test the IAT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be open above or below a certain temperature. If this is the case, replace the IAT sensor. If the IAT sensor appears to be OK, the fault is intermittent; refer to *Diagnostic Aids*.

Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700


DTC P0113 –IAT Sensor Circuit High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Ignition "ON," engine "OFF." Observe the "Intake Air Temp" display on the Tech 2. Is the "Intake Air Temp" below the specified value?	-38°C (-36°F)	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data parameters. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0113. Does the Tech 2 indicate DTC P0113 failed?	—	Refer to <i>Test Description</i>	Refer to <i>Diagnostic Aids</i>
4	1. Ignition "OFF." 2. Disconnect the IAT sensor electrical connector. 3. Jumper the IAT signal circuit and the sensor ground circuit together at the IAT sensor harness connector. 4. Ignition "ON." 5. Observe the "Intake Air Temp" display on the Tech 2. Is the "Intake Air Temp" at the specified value?	140°C (284°F)	Go to Step 6	Go to Step 5
5	1. Jumper the IAT signal circuit at the IAT sensor harness connector to chassis ground. 2. Observe the "Intake Air Temp" display on the Tech 2. Is the "Intake Air Temp" at the specified value?	140°C (284°F)	Go to Step 7	Go to Step 8

DTC P0113 –IAT Sensor Circuit High Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
6	Check for poor connections at the IAT sensor and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to <i>Step 10</i>
7	1. Ignition "OFF." 2. Disconnect the PCM, and check the IAT sensor ground circuit for an open. 3. If the IAT sensor ground circuit is open, repair it as necessary. Was the IAT sensor ground circuit open?	—	Verify repair	Go to <i>Step 9</i>
8	1. Ignition "OFF." 2. Disconnect the PCM, and check the IAT signal circuit for an open. 3. If the IAT sensor signal circuit is open, repair it as necessary. Was the IAT signal circuit open?	—	Verify repair	Go to <i>Step 9</i>
9	Check for a poor sensor ground or IAT signal circuit terminal connection at the PCM and replace terminal(s) if necessary. Did any of the terminals need to be replaced?	—	Verify repair	Go to <i>Step 11</i>
10	Replace the IAT sensor. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0117 ECT Sensor Circuit Low Voltage



D06RW058

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted on a coolant crossover pipe at the front of the engine. The powertrain control module (PCM) applies a voltage (about 5 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes lower, and the ECT signal voltage measured at the PCM drops. With a fully warmed-up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts.

Conditions for Setting the DTC

- Engine running time is longer than one minute.
- The ECT sensor signal indicates an engine coolant temperature greater than 150°C (302°F) (about 0.10 V) for a total of 50 seconds over a 100-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will substitute the ECT reading with a default engine coolant temperature value. The default value is based on start-up intake air temperature and running time.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0117 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0117 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

If DTC P0117 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P1114 Diagnostic Chart may isolate the cause of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Verifies that the fault is present.
3. If DTC P0117 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Values" table. The table may be used to test the ECT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be shorted above or below a certain temperature. If this is the case, replace the ECT sensor. If the ECT sensor appears to be OK, the fault is intermittent; refer to *Diagnostic Aids*.


Engine Coolant Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P0117 – ECT Sensor Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" below the specified value?	139°C (282°F)	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0117. Does the Tech 2 indicate DTC P0117 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Disconnect the ECT sensor electrical connector. 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" at the specified value?	–39°C (–38°F)	Go to Step 6	Go to Step 5
5	1. Ignition "OFF." 2. Disconnect the PCM and check the ECT signal circuit for a short to ground or a short to the sensor ground circuit. 3. If the ECT signal circuit is shorted, repair it as necessary. Was the ECT signal circuit shorted to ground?	—	Verify repair	Go to Step 7
6	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
7	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0118 ECT Sensor Circuit High Voltage



D06RW058

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in on a coolant crossover pipe at the front of the engine. The powertrain control module (PCM) applies a voltage (about 5 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes less, and the ECT signal voltage measured at the PCM drops. With a fully warmed-up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts.

Conditions for Setting the DTC

- Engine running time is longer than 1.5 minutes.
- The ECT sensor signal indicates an engine coolant temperature of -39°C (-38°F) or less (about 5 volts) for a total of 50 seconds over a 100-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will substitute the ECT reading with a default engine coolant temperature value. The default value is based on start-up intake air temperature and running time.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0118 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0118 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

If DTC P0118 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P1115 Diagnostic Chart may isolate the cause of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Verifies that the fault is present.
3. If DTC P0118 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Value" table. The table may be used to test the ECT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be shorted above or below a certain temperature. If this is the case, replace the ECT sensor. If the ECT sensor appears to be OK, the fault is intermittent; refer to *Diagnostic Aids*.

Engine Coolant Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700


DTC P0118 – ECT Sensor Circuit High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" below the specified value?	-39°C (-38°F)	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor the "DTC" info for DTC P0118. Does the Tech 2 indicate DTC P0118 failed?	—	Refer to <i>Test Description</i>	Refer to <i>Diagnostic Aids</i>
4	1. Disconnect the ECT sensor electrical connector. 2. Jumper the ECT signal circuit and the sensor ground circuit together at the ECT sensor harness connector. 3. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" at the specified value?	140°C (284°F)	Go to Step 6	Go to Step 5
5	1. Jumper the ECT signal circuit at the ECT sensor harness connector to chassis ground. 2. Observe the "Eng Cool Temp" display on the Tech 2. Is the "Eng Cool Temp" at the specified value?	140°C (284°F)	Go to Step 7	Go to Step 8
6	Check for poor connections at the ECT sensor and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 10

DTC P0118 – ECT Sensor Circuit High Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition "OFF." 2. Disconnect the PCM, and check the ECT sensor ground circuit for an open. 3. If the ECT sensor ground circuit is open, repair it as necessary. Was the ECT sensor ground circuit open?	—	Verify repair	Go to <i>Step 9</i>
8	1. Ignition "OFF." 2. Disconnect the PCM, and check the ECT signal circuit for an open. 3. If the ECT sensor signal circuit is open, repair it as necessary. Was the ECT signal circuit open?	—	Verify repair	Go to <i>Step 9</i>
9	Check for a poor sensor ground or ECT signal circuit terminal connection at the PCM and replace terminal(s) if necessary. Did any of the terminals need to be replaced?	—	Verify repair	Go to <i>Step 11</i>
10	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0121 TP System Performance



D06RW059

Circuit Description

The throttle position (TP) sensor circuit provides a voltage signal that changes relative to throttle blade angle. The signal voltage will vary from about 0.6 volts at closed throttle to about 4.5 volts at wide open throttle (WOT). The TP signal is one of the most important inputs used by the powertrain control module (PCM) for fuel control and many of the PCM-controlled outputs. The PCM monitors throttle position and compares actual throttle position from the TP sensor to a predicted TP value calculated from engine speed. If the PCM detects an out-of-range condition, DTC P0121 will set.

Conditions for Setting the DTC

- The engine is running.
- No MAP DTCs, or P0121, P0122, P1122, P0123 DTCs are set.
- MAP reading is below 55 kPa.
- Throttle is steady, throttle angle is changing less than 1%.
- Predicted throttle angle is not close to actual throttle angle.
- Above conditions are present for a total of 12.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- The PCM will use a default throttle position based on mass air flow and RPM.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0121 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0121 can be cleared by using the Tech 2 "Clear info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Skewed MAP signal or faulty MAP sensor – An incorrect MAP signal may cause the PCM to incorrectly calculate the predicted TP sensor value during high engine load situations. Check for an unusually low MAP reading. This condition can cause DTC P0121 to be set.
- The TP Sensor shares a 5 Volt reference with the EGR Valve.
If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The TP Sensor share a ground with the EGR Valve and the IAT Sensor.

6E2-150 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0121 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P1122 and DTC P1121 Diagnostic Charts may isolate the cause of the fault.


DTC P0121 –TP System Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine not running. 2. Observe the MAP reading on the Tech 2. Is the MAP reading less than the specified value?	65 kPa	Go to Step 3	Go to Step 6
3	1. Disconnected the MAP sensor. 2. Connect a test light between the 5 volt reference "A" circuit and the MAP signal circuit at the MAP sensor harness connector. 3. Observe the MAP reading on the Tech 2. Is the MAP reading less than the specified value? (If no, start with diagnosis chart for other sensors in the circuit and see if 5V returns.)	65 kPa	Go to Step 5	Go to Step 4
4	1. Check the MAP signal circuit between the PCM and the MAP sensor for an open, short to ground, or short to the MAP ground circuit. 2. If the MAP signal circuit is open or shorted, repair it as necessary. Was the MAP signal circuit open or shorted?	—	Verify repair	Go to Step 12
5	Replace the MAP sensor. Is the action complete?	—	Verify repair	—
6	Observe the TP angle reading on the Tech 2 while slowly opening the throttle. Does the TP angle increase steadily and evenly from the closed throttle value to the wide open throttle value?	Closed throttle = 0% Wide open throttle = 100%	Refer to <i>Diagnostic Aids</i>	Go to Step 7
7	1. Disconnect the TP sensor. 2. Observe the TP sensor reading on the Tech 2. Is the TP sensor reading near the specified value?	0 V	Go to Step 8	Go to Step 9
8	1. Connect a test light between the 5 volt reference "A" circuit and the TP sensor signal circuit at the TP sensor harness connector. 2. Observe the TP sensor reading on the Tech 2. Is the TP sensor reading at the specified value?	5 V	Go to Step 11	Go to Step 10

DTC P0121 –TP System Performance (Cont'd)

Step	Action	Value(s)	Yes	No
9	<p>Check the following items:</p> <ol style="list-style-type: none"> 1. TP signal circuit for a short to voltage. 2. TP sensor ground circuit for high resistance between the PCM and the TP sensor. 3. TP sensor ground circuit for a poor connection. 4. If a problem is found, repair wiring harness as necessary. <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 12</i>
10	<p>Check the following items:</p> <ol style="list-style-type: none"> 1. TP signal circuit or 5 volt reference "A" circuit for a poor connection. 2. TP signal circuit or 5 volt reference "A" circuit for high resistance between the PCM and the TP sensor. 3. If a problem is found, repair wiring harness as necessary. <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 12</i>
11	<p>Replace the TP sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—
12	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0122 TP Sensor Circuit Low Voltage



Circuit Description

The throttle position (TP) sensor circuit provides a voltage signal that changes relative to throttle blade angle. The signal voltage will vary from below 0.6 volts at closed throttle to about 4.5 volts at wide open throttle (WOT). The TP signal is used by the powertrain control module (PCM) for fuel control and many of the PCM-controlled outputs.

Conditions for Setting the DTC

- The ignition is "ON."
- TP sensor signal voltage is less than 0.22 volt for a total of 0.78 second over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- The PCM will use a default throttle position based on mass air flow and RPM.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0122 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0122 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The TP Sensor shares a 5 Volt reference with the EGR Valve.
 - If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.
- The TP Sensor share a ground with the EGR Valve and the IAT Sensor.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the throttle position display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.

If DTC P0122 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently, performing the DTC P1122 Diagnostic Chart may isolate the cause of the fault.

D06RW059


DTC P0122 –TP Sensor Circuit Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. With the throttle closed, observe the "TP Sensor" display on the Tech 2. Is the "TP Sensor" below the specified value?	0.22 V	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor the "DTC" info for DTC P0122. Does the Tech 2 indicate DTC P0122 failed?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Ignition "OFF." 2. Disconnect the TP sensor electrical connector. 3. Jumper the 5 volt reference "A" circuit and the TP signal together at the TP sensor harness connector. 4. Ignition "ON." Observe the "TP Sensor" display on the Tech 2. Is the "TP Sensor" at the specified value?	5 V	Go to Step 10	Go to Step 5
5	1. Disconnect jumper. 2. Connect a test light between B+ and the TP sensor signal circuit at the TP sensor harness connector. Observe the "TP Sensor" display on the Tech 2. Is the "TP Sensor" at the specified value? (If no, start with diagnosis chart for other sensors in the circuit and see if 5V returns.)	5 V	Go to Step 6	Go to Step 8
6	1. Ignition "OFF." 2. Disconnect the PCM and check the 5 volt reference "A" circuit for an open or short to ground. 3. If the 5 volt reference "A" circuit is open or shorted to ground, repair it as necessary. Was the 5 volt reference "A" circuit open or shorted to ground?	—	Verify repair	Go to Step 7
7	Check the 5 volt reference "A" circuit for a poor connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 12
8	1. Ignition "OFF." 2. Disconnect the PCM, and check the TP signal circuit for an open, short to ground, or short to the sensor ground circuit. 3. If the TP sensor signal circuit is open or shorted to ground, repair it as necessary. Was the TP signal circuit open or shorted to ground?	—	Verify repair	Go to Step 9

DTC P0122 –TP Sensor Circuit Low Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
9	Check the TP sensor signal circuit for a poor connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to <i>Step 12</i>
10	Check the TP sensor signal circuit for a poor connection at the TP sensor and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to <i>Step 11</i>
11	Replace the TP sensor. Is the action complete?	—	Verify repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0123 TP Sensor Circuit High Voltage



D06RW059

Circuit Description

The throttle position (TP) sensor circuit provides a voltage signal that changes relative to throttle blade angle. The signal voltage will vary from about 0.6 volts at closed throttle to about 4.5 volts at wide open throttle (WOT). The TP signal is one of the most important inputs used by the powertrain control module (PCM) for fuel control and many of the PCM-controlled outputs.

Conditions for Setting the DTC

- The ignition is "ON."
- TP sensor signal voltage is greater than 4.88 volts for a total of 0.78 second over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- The PCM will use a default throttle position based on mass air flow and RPM.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0123 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0123 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- The TP sensor shares a 5 Volt Reference with the EGR Position sensor. Check the 5 Volt reference if these DTCs are also set.
- The TP sensor shares a ground with the IAT sensor and the EGR position Sensor. Check the ground if these other DTCs are also set.
- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the TP sensor display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.
- Faulty TP sensor – With the ignition key "ON," engine "OFF," observe the TP sensor display on the Tech 2 while slowly depressing the accelerator to wide open throttle. If a voltage over 4.88 volts is seen at any point in normal accelerator travel, replace the TP sensor.

If DTC P0123 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set. If it is determined that the DTC occurs intermittently,

performing the DTC P1121 Diagnostic Chart may isolate the cause of the fault.

Test Description

Number (s) below refer to the step number(s) on the Diagnostic Chart.

7. Components that share the TP sensor 5 volt reference

“A” circuit include the following device:

○ EGR valve

Disconnect the component while observing the TP sensor display on the Tech 2. If the reading changes drastically when this component is disconnected, replace the component that affected the reading.


DTC P0123 – TP Sensor Circuit High Voltage

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition “ON,” engine “OFF.” 2. With the throttle closed, observe the “TP Sensor” display on the Tech 2. Is the “TP Sensor” above the specified value?	4.88 V	Go to Step 4	Go to Step 3
3	1. Ignition “ON,” engine “OFF.” 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor “DTC” info for DTC P0123. Does the Tech 2 indicate DTC P0123 failed.	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Disconnect the TP sensor electrical connector. 2. Observe the “TP Sensor” display on the Tech 2.(If no, start with diagnostic chart other sensors in the circuit and see if 5 V returns) Is the “TP Sensor” near the specified value?	0 V	Go to Step 5	Go to Step 6
5	Probe the sensor ground circuit at the TP sensor harness connector with a test light connected to B+. Is the test light “ON?”	—	Go to Step 7	Go to Step 10
6	1. Ignition “OFF,” disconnect the PCM. 2. Ignition “ON,” engine “OFF.” 3. Check for a short to voltage on the TP sensor signal circuit. 4. If the TP sensor signal circuit is shorted, repair it as necessary. Was the TP sensor signal circuit shorted?	—	Verify repair	Go to Step 12
7	1. Ignition “ON.” 2. Monitor the “TP Sensor” Tech 2 display while disconnecting each of the components that share the 5 volt reference “A” circuit (one at a time). 3. If the “TP Sensor” Tech 2 display changes, replace the component that caused the display to change when disconnected. Does disconnecting any of these components cause the “TP Sensor” display to change?	—	Verify repair	Go to Step 8

DTC P0123 – TP Sensor Circuit High Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition "OFF," disconnect the PCM. 2. Ignition "ON," engine "OFF." 3. Check for a short to B+ on the 5 volt reference "A" circuit. 4. If the 5 volt reference "A" circuit is shorted, repair it as necessary. Was the 5 volt reference "A" circuit shorted?	—	Verify repair	Go to <i>Step 9</i>
9	Check for poor electrical connections at the TP sensor and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to <i>Step 11</i>
10	1. Ignition "OFF." 2. Disconnect the PCM, and check for an open sensor ground circuit to the TP sensor. 3. If a problem is found, repair it as necessary. Was the sensor ground circuit to the TP sensor open?	—	Verify repair	Go to <i>Step 12</i>
11	Replace the TP sensor. Is the action complete?	—	Verify repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0125 ECT Excessive Time to Closed Loop Fuel Control



D06RW058

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "closed loop" air/fuel metering system is used. When the vehicle is first started, the powertrain control module (PCM) controls fuel delivery in "open loop," ignoring the heated oxygen sensor (HO2S) signals and calculating air/fuel ratio based on inputs from the engine coolant temperature, throttle position, and mass air flow sensors. The PCM will begin using the Bank 1 HO2S 1 and Bank 2 HO2S 1 signals for controlling fuel delivery under "closed loop" conditions when the following conditions have been met:

- The HO2S output signals are varying, indicating that the sensors are hot enough to operate properly.
- The engine coolant temperature sensor indicates coolant temperature above 50°C (122°F).
- Time since start-up is at least 16 seconds for a warm engine or 23 seconds for a cold engine.

Conditions for Setting the DTC

- No active IAT or ECT DTC(s) are present.
- Engine is running.
- Vehicle speed is greater than 5 mph (8 km/h).
- Intake air temperature is greater than -10°C (14°F) 0°C (32°F).
- Start-up engine coolant temperature is between -10°C (-14°F) and 28°C (82°F).

- For a warm engine (intake air temperature is greater than 10°C/50°F), engine coolant temperature sufficient to allow "closed loop" operation (50°C/122°F) is not achieved within 2 minutes of start-up. For a cold engine (intake air temperature between -7°C and 10°C), engine coolant temperature sufficient to allow "closed loop" operation (50°C/122°F) is not achieved within 10 minutes of start-up.

- The above condition fails 20 consecutive times.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0125 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0125 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

DTC P0125 set indicates a faulty ECT sensor. Comparing the engine coolant temperature displayed on a Tech 2 with actual coolant temperature measured with a thermometer may isolate this condition. If the displayed engine coolant temperature is not close to the actual coolant temperature, replace the ECT sensor.

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0125 cannot be duplicated, the information included in the Failure Records data can be useful in determining vehicle mileage since the DTC was last set.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Comparing the engine coolant temperature displayed on a Tech 2 with actual coolant temperature measured with a thermometer may isolate this condition. If the displayed engine coolant temperature is not close to the actual coolant temperature, replace the ECT sensor. If the temperatures are close, the fault is intermittent; refer to *Diagnostic Aids*.

Engine Coolant Temperature

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
–5	23	12300
–15	5	21450
–30	–22	52700
–40	–40	100700


DTC P0125 –ECT Excessive Time to Closed Loop Fuel Control

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any ECT sensor DTCs set?	—	Go to applicable ECT sensor DTC chart	Go to Step 3
3	1. Allow the engine to cool completely. 2. Check the cooling system coolant level (refer to <i>Cooling and Radiator</i>). Is the coolant level OK?	—	Go to Step 4	Go to Step 9
4	1. Start the engine. 2. With the engine idling, monitor “ENG COOL TEMP” display on the Tech 2. Does “ENG COOL TEMP” increase to above the specified value within 2 minutes?	21°C (70°F)	Refer to <i>Diagnostic Aids</i>	Go to Step 5
5	Check for proper operation of the thermostat (refer to <i>Cooling and Radiator</i>). Is the thermostat operating correctly?	—	Go to Step 6	Go to Step 9

DTC P0125 –ECT Excessive Time to Closed Loop Fuel Control (Cont'd)

Step	Action	Value(s)	Yes	No
6	Compare engine coolant temperature displayed on the Tech 2 to the actual coolant temperature measured with a thermometer. (Observe normal precautions when opening the cooling system.) Is the Tech 2 engine coolant temperature indication close to the measured temperature?	—	Go to Step 9	Go to Step 7
7	1. Ignition "OFF." 2. Disconnect the PCM. 3. Using a DVM, measure the resistance of the ECT at the PCM connector. 4. Compare the DVM reading with the chart in "Test Description." Is the chart value approximately equal to the thermometer reading?	—	Go to Step 12	Go to Step 8
8	Check for high resistance in wiring related to the ECT sensor. Also, check for poor connections at the ECT sensor and the PCM. Was a problem found?	—	Go to Step 10	Go to Step 11
9	Refer to <i>Cooling and Radiator</i> for cooling system diagnosis and repair condition as necessary. Is the action complete?	—	Verify repair	—
10	Replace the faulty terminal(s) or repair faulty wiring as necessary. Is the action complete?	—	Verify repair	—
11	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0131 HO2S Circuit Low Voltage Bank 1 Sensor 1



D06RW081

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal high and signal low circuits. When measured with a 10 megaohm digital voltmeter, this may display as low as 350 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 1 voltage remains excessively low for an extended period of time, DTC P0131 will be set.

Conditions for Setting the DTC

- No related DTCs.
- Vehicle is operating in "closed loop."
- Engine coolant temperature is above 60°C (140°F)
- "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8.
- Throttle angle is between 3% and 19%.
- Bank 1 HO2S 1 signal voltage remains below 22 mV during normal "closed loop" operation for a total of 77 seconds over a 90-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0131 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0131 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Heated oxygen sensor wiring – The sensor pigtail may be routed incorrectly and contacting the exhaust system.
- Poor PCM to engine block grounds.
- Fuel pressure – The system will go lean if pressure is too low. The PCM can compensate for some

decrease. However, If fuel pressure is too low, a DTC P0131 may be set. Refer to *Fuel System Diagnosis*.

- Lean injector(s) – Perform “Injector Balance Test.”
- Vacuum leaks – Check for disconnected or damaged vacuum hoses and for vacuum leaks at the intake manifold, throttle body, EGR system, and PCV system.
- Exhaust leaks – An exhaust leak may cause outside air to be pulled into the exhaust gas stream past the HO2S, causing the system to appear lean. Check for exhaust leaks that may cause a false lean condition to be indicated.
- MAF sensor – The system can go lean if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if the lean condition is corrected. If so, replace the MAF sensor.
- Fuel contamination – Water, even in small amounts, can be delivered to the fuel injectors. The water can cause a lean exhaust to be indicated. Excessive

alcohol in the fuel can also cause this condition. Refer to *Fuel System Diagnosis* for the procedure to check for fuel contamination.

- If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to step numbers on the diagnostic chart.

3. DTC P0131 failing during operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0131 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0131 –HO2S Circuit Low Voltage Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Does the Bank 1 HO2S 1 voltage remain below the specified value?	22 mV	Go to Step 4	Go to Step 3
3	1. Ignition “ON,” engine “OFF,” review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0131 until the DTC P0131 test runs. Note test result. Does Tech 2 indicate DTC P0131 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Turn the ignition “OFF.” 2. Disconnect the PCM. 3. Check the Bank 1 HO2S 1 high and low circuits for a short to ground or a short to the heater ground circuit. Are the Bank 1 HO2S 1 signal circuits shorted to ground?	—	Go to Step 5	Go to Step 6
5	Repair the Bank 1 HO2S 1 signal circuit. Is the action complete?	—	Verify repair	—
6	1. Turn the ignition “OFF,” HO2S 1 and PCM disconnected. 2. Check for continuity between the high and low signal circuits. Was there continuity between the high and low circuits?	—	Go to Step 7	Go to Step 8

DTC P0131 –HO2S Circuit Low Voltage Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
7	Repair the short between the high and low circuits. Is the action complete?	—	Verify repair	—
8	1. Ignition "OFF." 2. Reconnect the PCM, leave the sensor disconnected. 3. Ignition "ON." Does the Tech 2 indicate Bank 1 HO2S 1 voltage between the specified values?	425–475 mV	Refer to <i>Diagnostic Aids</i>	Go to <i>Step 9</i>
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0132 HO2S Circuit High Voltage Bank 1 Sensor 1



D06RW081

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal high and signal low circuits. When measured with a 10 megaohm digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 1 voltage remains excessively high for an extended period of time, DTC P0132 will be set.

Conditions for Setting the DTC

- No related DTCs.
 - Engine coolant temperature is above 60°C (140°F)
 - "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8.
 - Throttle angle is between 3% and 19%.
 - Bank 1 HO2S 1 signal voltage remains above 952 mV during normal "closed loop" operation for a total of 77 seconds over a 90-second period.
- OR
- Bank 1 HO2S 1 signal voltage remains above 500 mV during "deceleration fuel cutoff mode" operation for 3 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0132 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0132 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check the following items:

- Fuel pressure – The system will go rich if pressure is too high. The PCM can compensate for some increase. However, if fuel pressure is too high, a DTC P0132 may be set. Refer to *Fuel System Diagnosis*.
- Perform "Injector Balance Test" – Refer to *Fuel System Diagnosis*.
- Check the EVAP canister for fuel saturation – If full of fuel, check canister control and hoses. Refer to *Evaporative (EVAP) Emission Control System*.

- MAF sensor –The system can go rich if MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if the rich condition is corrected. If so, replace the MAF sensor.
- Check for a leak in the fuel pressure regulator diaphragm by checking the vacuum line to the regulator for the presence of fuel. There should be no fuel in the vacuum line.
- An intermittent TP sensor output will cause the system to go rich due to a false indication of the engine accelerating.
- Shorted Heated Oxygen Sensor (HO2S) –If the HO2S is internally shorted, the HO2S voltage displayed on the Tech 2 will be over 1 volt. Try disconnecting the affected HO2S with the key “ON,” engine “OFF.” If the displayed HO2S voltage changes from over 1000 mV to around 450 mV, replace the HO2S. Silicon contamination of the HO2S can also cause a high HO2S voltage to be indicated. This condition is indicated by a powdery white deposit on the portion of the HO2S exposed to the exhaust stream. If contamination is noticed, replace the affected HO2S.
- Open HO2S Signal Circuit or Faulty HO2S—A poor connection or open in the HO2S signal circuit can cause the DTC to set during deceleration fuel mode.

An HO2S which is faulty and not allowing a full voltage swing between the rich and lean thresholds can also cause this condition. Operate the vehicle by monitoring the HO2S voltage with a Tech 2. If the HO2S voltage is limited within a range between 300 mV to 600 mV, check the HO2S signal circuit wiring and associated terminal conditions.

- If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0132 failing during “deceleration fuel cutoff mode” operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0132 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0132 – HO2S Circuit High Voltage Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within parameters specified under “Conditions for Setting the DTC” included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Does the Bank 1 HO2S 1 voltage remain above the specified value?	952 mV (500 mV in deceleration fuel cutoff mode)	Go to Step 4	Go to Step 3
3	1. Ignition “ON,” review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0132 until the DTC P0132 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0132 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Ignition “OFF.” 2. Disconnect Bank 1 HO2S 1. 3. Ignition “ON.” 4. At HO2S Bank 1 Sensor 1 connector (PCM side) use a DVM to measure voltages at the high and low signal terminals. Are the voltages in the specified range?	3-4 V	Go to Step 5	Go to Step 6
5	Repair short to voltage in signal circuit. Is the action complete?	—	Verify repair	—

DTC P0132 – HO2S Circuit High Voltage Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Ignition "ON," engine "OFF." 2. At Bank 1 HO2S 1 connector (PCM side) jumper both the HO2S high and low signal circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Is Bank 1 HO2S 1 voltage below the specified value?	10 mV	Go to <i>Step 7</i>	Go to <i>Step 8</i>
7	1. Disconnect the jumpers to ground from Bank 1 HO2S 1 PCM-side connector. 2. With the HO2S 1 connector disconnected, monitor Bank 1 HO2S 1 voltage. Is Bank 1 HO2S 1 voltage between the specified values?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to <i>Step 8</i>
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0133 HO2S Slow Response Bank 1 Sensor 1



D06RW081

Circuit Description

The powertrain control module (PCM) continuously monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "closed loop" has been enabled. During the monitoring period the PCM counts the number of times that a rich-to-lean and lean-to-rich response is indicated and adds the amount of time it took to complete all rich-to-lean transitions and lean-to-rich transitions. With this information, an average time for rich-to-lean and lean-to-rich transitions can be determined. If the average response time of either transition is too slow, a DTC P0133 will be set.

A lean-to-rich transition is indicated when the HO2S voltage changes from less than 300 mV to greater than 600 mV. A rich-to-lean transition is indicated when the HO2S voltage changes from more than 600 mV to less than 300 mV. An HO2S that responds too slowly is likely to be faulty and should be replaced.

Conditions for Setting the DTC

- No related DTCs.
- Engine coolant temperature (ETC) is above 50°C (122°F) for automatic transmission; 75°C (167°F) for manual transmission.
- Engine is operating in "closed loop."
- Engine has been running for at least 1 minute.
- Engine speed is between 1500 RPM and 3000 RPM.
- Canister purge duty cycle is greater than 2%.
- Mass air flow is between 9 g/second and 42 g/second.

- All above conditions are met for 3 seconds.
- 90 seconds after "closed loop" has been enabled, Bank1 HO2S 1 average transition time between 300 mV and 600 mV is too slow. The lean-to-rich average transition response time was longer than 94 milliseconds or rich-to-lean average transition response time was longer than 105 milliseconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator Lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0133 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0133 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken

locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 1 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

If DTC P0133 cannot be duplicated, reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Verifies that the fault is currently present.
3. HO2S transition time, ratio mean volts and switching DTCs set for multiple sensors indicate probable contamination. Before replacing the sensors, isolate and correct the source of the contamination to avoid damaging the replacement sensors.

DTC P0133 – HO2S Slow Response Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	NOTE: If any DTCs are set (expect P0153, P1133, P1134, P1153, and/or P1154), refer to those DTCs before proceeding with this diagnostic chart. 1. Install the Tech 2. 2. Idle the engine at operating temperature. 3. Operate the vehicle within parameters specified under "Conditions for Setting the DTC" included in Diagnostic Support. 4. Using a Tech 2, monitor "DTC" info for DTC P0133 until the DTC P0133 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0133 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	Did the Tech 2 also indicate DTC P0153, P1133, P1134, P1153, and/or P1154 failed this ignition?	—	Go to Step 17	Go to Step 4
4	Check for leaks at the pipe joints. Are the joints leaking?	—	Go to Step 5	Go to Step 6
5	Tighten the U-bolt nuts at the leaking joints. Is the action complete?	—	Go to Step 2	—
6	Check for gaskets that are damaged or improperly installed. Are there damaged or misaligned gaskets?	—	Go to Step 7	Go to Step 8
7	1. Replace damaged gaskets. 2. Align the connections. 3. Tighten the connections. Is the action complete?	—	Go to Step 2	—
8	Check for loose exhaust flange connections. Are the flange connections loose?	—	Go to Step 2	Go to Step 10
9	Tighten the stud nuts or bolts to specifications. Is the action complete?	—	Go to Step 2	—
10	Check for burned or corroded exhaust pipes. Are the exhaust pipes burned or corroded?	—	Go to Step 11	Go to Step 12


DTC P0133 – HO2S Slow Response Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
11	Replace the exhaust pipes, as required. Is the action complete?	—	Go to Step 2	—
12	Check for leaks at the exhaust manifold. Are there leaks at the exhaust manifold?	—	Go to Step 13	Go to Step 14
13	Tighten the bolts to specifications to replace the manifold if necessary. Is the action complete?	—	Go to Step 2	—
14	Visually/physically inspect the following items: <ul style="list-style-type: none"> ○ Ensure that the Bank 1 HO2S 1 is securely installed. ○ Check for corrosion on terminals. ○ Check terminal tension (at Bank 1 HO2S 1 and at the PCM). ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Go to Step 18	Go to Step 15
15	1. Disconnect Bank 1 HO2S 1. 2. Ignition "ON." 3. Using a DVM at the PCM side of the HO2S 1 connector, measure the voltage between the high signal circuit and ground. Also measure the voltage between the low signal circuit and ground. Are both voltages in the specified range?	3-4 V	Go to Step 16	Go to Step 19
16	1. With Bank 1 HO2S 1 disconnected, jumper the high and low (PCM side) signal circuits to ground. 2. Ignition "ON." 3. Using a Tech 2, monitor the Bank 1 HO2S 1 voltage. Does the Tech 2 indicate less than 10 mV and immediately return to about 450 mV when the jumper is removed?	—	Go to Step 21	Go to Step 22
17	Replace the affected heated oxygen sensors. NOTE: Before replacing sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination. ○ Use of improper RTV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—
18	Repair condition as necessary. Is the action complete?	—	Verify repair	—
19	Check for faulty PCM connections or terminal damage. Is the action complete?	—	Verify repair	Go to Step 20
20	Repair open, short or grounded signal circuit. Is the action complete?	—	Verify repair	—

DTC P0133 – HO2S Slow Response Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
21	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
22	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0134 HO2S Circuit Insufficient Activity Bank 1 Sensor 1



D06RW060

Circuit Description

- The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) high and low circuits. When measured with a 10 megohm digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 1 voltage remains at or near the 450 mV bias for an extended period of time, DTC P0134 will be set, indicating an open sensor signal or sensor low circuit.
- Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature for accurate exhaust oxygen content readings further from the engine.

Conditions for Setting the DTC

- No related DTCs.
- Battery voltage is above 10 volts.
- Engine run time is longer than 40 seconds.
- Oxygen sensor heater has been determined to be functioning properly.
- Bank 1 HO2S 1 signal voltage remains between 400 mV and 500 mV for a total of 77 seconds over a 90-second period of time.

Action Take When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0134 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0134 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- Faulty HO2S heater or heater circuit – With the ignition “ON,” engine “OFF,” after a cool down period, the HO2S 1 voltage displayed on the Tech 2 is normally 455-460 mV. A reading over 1000 mV indicates a signal line shorted to voltage. A reading under 5 mV indicates a signal line shorted to ground or signal lines shorted together. Disconnect the HO2S and connect a test light between the HO2S ignition feed and heater ground circuits. If the test light does not light for 2 seconds when the ignition is turned on, repair the open ignition feed or sensor ground circuit as necessary. If the test light lights and the HO2S signal and low circuits are OK, replace the HO2S.

- Intermittent test – With the Ignition “ON,” monitor the HO2S signal voltage while moving the wiring harness and related connectors. If the fault is induced, the HO2S signal voltage will change. This may help isolate the location of the malfunction.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. If the DTC P0134 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0134 –HO2S Circuit Insufficient Activity Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the engine above 1200 RPM for two minutes. Does the Tech 2 indicate Bank 1 HO2S 1 voltage varying outside the specified values?	400-500 mV	Go to Step 3	Go to Step 4
3	1. Ignition “ON,” engine “OFF,” review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0134 until the DTC P0134 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0134 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	Check for a damaged harness. Was a problem found?	—	Verify repair	Go to Step 5
5	Check for poor Bank 1 HO2S 1 high and low circuit terminal connections at the Bank 1 HO2S 1 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 6
6	Check for poor Bank 1 HO2S 1 high and low circuit terminal connections at the PCM and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 7

DTC P0134 –HO2S Circuit Insufficient Activity Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition "OFF." 2. With the PCM disconnected, check continuity of the Bank 1 HO2S 1 high circuit. 3. If the Bank 1 HO2S 1 high circuit measures over 5.0 ohms, repair open or poor connection as necessary. Was a Bank 1 HO2S 1 high circuit problem found and corrected?	—	Verify repair	Go to <i>Step 8</i>
8	1. Ignition "OFF." 2. With the PCM disconnected, check continuity of the Bank 1 HO2S 1 low circuit. 3. If the Bank 1 HO2S 1 low circuit measures over 5 ohms, repair open or poor connection as necessary. Was a Bank 1 HO2S 1 low circuit problem found and corrected?	—	Verify repair	Go to <i>Step 9</i>
9	1. Ignition "ON," engine "OFF." 2. Disconnect Bank 1 HO2S 1 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 1 voltage. Is Bank 1 HO2S 1 voltage in the specified range?	0-10 mV	Go to <i>Step 10</i>	Go to <i>Step 11</i>
10	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0135 HO2S Heater Circuit Bank 1 Sensor 1



D06RW060

Circuit Description

Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further from the engine. The powertrain control module (PCM) will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the Bank 1 HO2S 1 to become active, a DTC P0135 will set. The time it should take the HO2S to reach operating temperature is based on the accumulated amount of air that has passed through the MAF sensor and into the engine (more accumulated air flow = shorter time to HO2S activity).

Conditions for Setting the DTC

- No related DTCs.
- Intake air temperature (IAT) is less than 32°C (90°F) at start-up.

- Engine coolant temperature (ECT) is less than 32°C (90°F) at start-up.
- IAT and ECT are within 6°C (11°F) of each other at start-up.
- Ignition voltage is between 11 and 18 V.
- Average mass air flow is less than 21 g/second during sample period.
- Bank 1 HO2S 1 voltage does not change more than 150 mV from the bias voltage (between 400 mV and 500 mV) for a longer amount of time than it should. The maximum amount of time to come up to operating range is 150 seconds. This warm-up time depends on the engine coolant temperature at start-up and accumulate air flow since start-up.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0135 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0135 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. The HO2S should be allowed to cool before performing this test. If the HO2S heater is functioning, the signal voltage will gradually increase or decrease as the sensor element warms. If the heater is not functioning, the HO2S signal will remain near the 450 mV bias voltage.
4. Ensures that the ignition feed circuit to the HO2S is not open or shorted. The test light should be connected to a good chassis ground, in case the HO2S low or HO2S heater ground circuit is faulty.
5. Checks the HO2S heater ground circuit.
6. Checks for an open or shorted HO2S heater element.
10. An open HO2S signal or low circuit can cause the HO2S heater to appear faulty. Check these circuits before replacing the sensor.


DTC P0135 – HO2S Heater Circuit Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	NOTE: If the engine has just been operating, allow the engine to cool for at least 15 minutes before proceeding. 1. Remove the fuel pump relay. 2. Connect a fused jumper at the fuel pump relay socket, between the battery positive at the relay and the relay wire that leads to the fuel pump and O2S fuses. 3. Ignition "OFF." 4. Install a Tech 2. 5. Ignition "ON," engine "OFF." 6. Monitor the Bank 1 HO2S 1 voltage for several minutes. Did the HO2S voltage go from bias voltage to above or below the specified values?	Above 650 mV or below 250 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 3
3	Inspect the fuse for the Bank 1 HO2S 1 ignition feed. Is the fuse open?	—	Go to Step 15	Go to Step 4
4	1. Ignition "OFF." 2. Raise the vehicle. 3. Disconnect the Bank 1 HO2S 1 electrical connector. 4. Using a test light connected to a good ground (do not use Bank 1 HO2S 1 heater ground or Bank 1 HO2S 1 low), probe the ignition feed circuit at the Bank 1 HO2S 1 electrical connector (PCM harness side). Does the test light illuminate?	—	Go to Step 5	Go to Step 7

DTC P0135 – HO2S Heater Circuit Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
5	Connect the test light between the Bank 1 HO2S 1 ignition feed and the Bank 1 HO2S 1 heater ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 8
6	1. Allow the HO2S to cool for at least 15 minutes. 2. Using a DVM, measure the resistance between the Bank 1 HO2S 1 ignition feed and the Bank 1 HO2S 1 heater ground at the Bank 1 HO2S 1 pigtail. Is the HO2S heater resistance within the specified values?	3-6 ohms	Go to Step 9	Go to Step 10
7	Repair the open Bank 1 HO2S 1 ignition feed circuit to Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
8	Repair the open Bank 1 HO2S 1 heater ground circuit to Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
9	1. Check for a poor connection at the Bank 1 HO2S 1 harness terminals. 2. If a poor connection is found, replace terminals. Was a poor connection found?	—	Verify repair	Go to Step 10
10	Check for a poor Bank 1 HO2S 1 high or low circuit terminal connection at the Bank 1 HO2S 1 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 11
11	1. Ignition "OFF." 2. Disconnect the PCM and check the continuity of the Bank 1 HO2S 1 signal circuit and the Bank 1 HO2S 1 low circuit. 3. If the Bank 1 HO2S 1 high circuit or HO2S low circuit measures over 5 ohms, repair open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	Check for a poor Bank 1 HO2S 1 low circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 13
13	Check for a poor Bank 1 HO2S 1 high circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
14	Replace the Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in Bank 1 HO2S 1 ignition feed circuit and replace the fault fuse. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0137 HO2S Circuit Low Voltage Bank 1 Sensor 2



D06RW082

Circuit Description

The powertrain control module (PCM) supplies bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal high and signal low circuits. When measured with a 10 megaohm impedance digital voltmeter, this may display as low as 350 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when exhaust is rich, down through about 10 mV when the exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 2 signal voltage remains excessively low for an extended period of time, DTC P0137 will be set.

Conditions for Setting the DTC

- No related DTCs.
- Engine is operating in "closed loop."
- Engine coolant temperature is above 60°C (140°F).
- "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8.
- Throttle angle is between 3% and 19%.
- Bank 1 HO2S 2 signal voltage remains below 22 mV during normal "closed loop" operation for a total of 106 seconds over a 125-second period of time.

OR

- Bank 1 HO2S 2 signal voltage remains below 400 mV during power enrichment mode fuel control operation for up to 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0137 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0137 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Heated oxygen sensor wiring – The sensor pigtail may be mispositioned and contacting the exhaust system.
- Poor PCM to engine grounds.
- Fuel pressure – A condition which causes a lean exhaust can cause DTC P0137 to set. The system will go lean if pressure is too low. The PCM can compensate for some decrease. However, if fuel

6E2-178 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

pressure is too low, a DTC P0137 may be set. Refer to *Fuel System Diagnosis*.

- Lean injector(s) – Perform “Injector Balance Test.”
- Vacuum leaks – Check for disconnected or damaged vacuum hoses and for vacuum leaks at the intake manifold, throttle body, EGR system, and PCV system.
- Exhaust leaks – An exhaust leak may cause outside air to be pulled into the exhaust gas stream past the HO2S, causing the DTC P0137 to set. Check for exhaust leaks near the Bank 1 HO2S 2 sensor.
- MAF sensor – The system can go lean if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if the lean condition is corrected. If so, replace the MAF sensor.
- Fuel contamination – Water, even in small amounts, can be delivered to the fuel injectors. The water can cause a lean exhaust to be indicated. Excessive alcohol in the fuel can also cause this condition. Refer

to *Fuel System Diagnosis* for procedure to check for fuel contamination.

- If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0137 failing during operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0137 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0137 –HO2S Circuit Low Voltage Bank 1 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 2 voltage. Does the Bank 1 HO2S 2 voltage remain below the specified value?	22 mV	Go to Step 4	Go to Step 3
3	1. Ignition “ON,” engine “OFF,” review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0137 until the DTC P0137 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0137 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Turn ignition “OFF.” 2. Disconnect the PCM. 3. Check the Bank 1 HO2S 2 high and low signal circuits for a short to ground or a short to the heater ground circuit. Were Bank 1 HO2S 2 signal circuits shorted?	—	Go to Step 5	Go to Step 6
5	Repair the Bank 1 HO2S 2 signal circuit. Is the action complete?	—	Verify repair	—
6	1. Ignition “OFF.” 2. Leave the PCM and HO2S 2 disconnected. 3. Check for continuity between the high and low signal circuits. Was there continuity between the high and low circuits?	—	Go to Step 7	Go to Step 8

DTC P0137 –HO2S Circuit Low Voltage Bank 1 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
7	Repair the short between the high and low circuits. Is the action complete?	—	Verify repair	—
8	1. Ignition "OFF." 2. Reconnect the PCM, leave HO2S 2 disconnected. 3. Ignition "ON." Does the Tech 2 indicate Bank 1 HO2S 2 voltage near the specified value?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to <i>Step 9</i>
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0138 HO2S Circuit High Voltage Bank 1 Sensor 2



D06RW082

Circuit Description

The powertrain control module (PCM) supplies bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal high and signal low circuits. When measured with a 10 megaohm digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when exhaust is rich, down through about 10 mV when the exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 1 HO2S 2 voltage remains excessively high for an extended period of time, DTC P0138 will be set.

Conditions for Setting the DTC

- ☐ No related DTCs.
- ☐ Engine is operating in "closed loop."
- ☐ "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8.
- ☐ Engine coolant temperature is above 60°C (140°F).
- ☐ Throttle angle is between 3% and 19%.
- ☐ Bank 1 HO2S 2 signal voltage remains above 952 mV during normal "closed loop" operation for a total of 106 seconds over a 125-second period of time.

OR

- ☐ Bank 1 HO2S 2 signal voltage remains above 500 mV during deceleration fuel cut-off mode operation for up to 3 seconds.

Action Taken When the DTC Sets

- ☐ The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- ☐ The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- ☐ The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- ☐ A history DTC P0138 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P0138 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- ☐ Fuel pressure – An excessively rich fuel mixture can cause a DTC P0138 to be set. Refer to *Fuel System Diagnosis*.
- ☐ Rich injector(s) – Perform "Injector Balance Test."
- ☐ Leaking injector – Refer to *Fuel System Diagnosis*.

- Evaporative emissions (EVAP) canister purge – Check for fuel saturation. If full of fuel, check the canister control and hoses. Refer to *Evaporative Emission (EVAP) Control System*.
- MAF sensor –The system can go rich if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if the rich condition is corrected. If so, replace the MAF sensor.
- Check for a leak in fuel pressure regulator diaphragm by checking the vacuum line to the regulator for the presence of fuel. There should be no fuel in the vacuum line.
- TP sensor – An intermittent TP sensor output will cause the system to go rich, due to a false indication of the engine accelerating.
- Shorted Heated Oxygen Sensor (HO2S) – If the HO2S is internally shorted the HO2S voltage displayed on the Tech 2 will be over 1 volt. Try disconnecting the affected HO2S with the key “ON,” engine “OFF.” If the displayed HO2S voltage changes from over 1000 mV to around 450 mV, replace the HO2S. Silicon contamination of the HO2S can also cause a high HO2S voltage to be indicated. This condition is indicated by a powdery white deposit on the portion of the HO2S exposed to the exhaust stream. If contamination is noticed, replace the affected HO2S.

- Open HO2S Signal Circuit of Faulty HO2S – A poor connection or open in the HO2S signal circuit can cause the DTC to set during deceleration fuel mode. An HO2S which is faulty and not allowing a full voltage swing between the rich and lean thresholds can also cause this condition. Operate the vehicle while monitoring the HO2S voltage with a Tech 2. If the HO2S voltage is limited within a range between 300 mV to 600 mV, check the HO2S signal circuit wiring and associated terminal connections.
- If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0138 being set during deceleration fuel mode operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0138 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0138 – HO2S Circuit High Voltage Bank 1 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	<ol style="list-style-type: none"> 1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 1 HO2S 2 voltage. Does the Bank 1 HO2S voltage remain above the specified value?	952 mV (500 mV in deceleration fuel cutoff mode)	Go to Step 4	Go to Step 3
3	<ol style="list-style-type: none"> 1. Ignition “ON,” review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0138 until the DTC P0138 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0138 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	<ol style="list-style-type: none"> 1. Ignition “OFF.” 2. Disconnect Bank 1 HO2S 1. 3. Ignition “ON.” 4. At the HO2S Bank 1 Sensor 2 connector (PCM side), use a DVM to measure voltages at the high and low signal terminals. Are the voltages above the specified range?	3-4 V	Go to Step 5	Go to Step 6

DTC P0138 – HO2S Circuit High Voltage Bank 1 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
5	Repair short to voltage in the signal circuit. Is the action complete?	—	Verify repair	—
6	1. Ignition "ON," engine "OFF." 2. At Bank 1 HO2S 2 connector (PCM side) jumper both the HO2S high and low signal circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 2 voltage. Is Bank 1 HO2S 2 voltage below the specified value?	10 mV	Go to Step 7	Go to Step 8
7	1. Disconnect the jumpers to ground from Bank 1 HO2S 2 PCM-side connector. 2. With the HO2S 2 connector disconnected, monitor BANK 1 HO2S 2 voltage. Is the Bank 1 HO2S 2 voltage between the specified values?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 8
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code(DTC) P0140 HO2S Circuit Insufficient Activity Bank 1 Sensor 2



D06RW061

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 1 HO₂S 1 and the Bank 1 HO₂S 2 heated oxygen sensors. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If catalyst is operating efficiently, the Bank 1 HO₂S 1 signal will be far more active than that produced by the Bank 1 HO₂S 2 sensor. If the Bank 1 HO₂S 2 signal voltage remains between 400 mV and 500 mV for an extended period of time, DTC P0140 will be set. Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO₂S 1 and Bank 2 HO₂S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to

maintain a sufficiently high temperature for accurate exhaust oxygen content readings further from the engine.

Conditions for Setting the DTC

- ☐ No related DTCs.
- ☐ Battery voltage is above 10 volts.
- ☐ Engine run time is longer than 40 seconds.
- ☐ Oxygen sensor heater is functioning properly.
- ☐ Engine is operating in "closed loop"
- ☐ Bank 1 HO₂S 2 signal voltage remains between 426 mV and 474 mV for a total of 106 seconds over a 125-second period of time.

Action Taken When the DTC Sets

- ☐ The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- ☐ The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Cleaning the MIL/DTC

- ☐ The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- ☐ A history DTC P0140 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P0140 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- Faulty HO2S heater or heater circuit – With the ignition “ON,” engine “OFF,” the HO2S voltage displayed on a Tech 2 should gradually drop to below 250 mV. If not, disconnect the HO2S and connect a test light between the HO2S ignition feed and heater ground circuits. If the test light does not light, repair the open ignition feed or sensor ground circuit as necessary. If the test light lights and the HO2S signal and low circuits are OK, replace the HO2S.

- Intermittent test – With the ignition “ON,” monitor the HO2S signal voltage while moving the wiring harness and related connectors. If the fault is induced, the HO2S signal voltage will change. This may help isolate the location of the malfunction.

Test Description

Number (s) below refer to the step number (s) on the Diagnostic Chart.

3. If the DTC P0140 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0140 – HO2S Circuit Insufficient Activity Bank 1 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the engine above 1200 RPM for two minutes. Does the Tech 2 indicate Bank 1 HO2S 2 voltage varying outside the specified values?	425-475 mV	Go to Step 3	Go to Step 4
3	1. Ignition “ON,” engine “OFF,” review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0140 until the DTC P0140 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0140 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	Check for a damaged harness. Was a problem found?	—	Verify repair	Go to Step 5
5	Check for poor Bank 1 HO2S 2 high and low circuit terminal connections at the Bank 1 HO2S 2 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 6
6	Check for poor Bank 1 HO2S 2 high and low circuit terminal connections at the PCM and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 7
7	1. Ignition “OFF.” 2. With the PCM disconnected, check continuity of the Bank 1 HO2S 2 high circuit. 3. If the Bank 1 HO2S 2 high circuit measures over 5.0 ohms, repair open or poor connection as necessary. Was a Bank 1 HO2S 2 high circuit problem found and corrected?	—	Verify repair	Go to Step 8

DTC P0140 – HO2S Circuit Insufficient Activity Bank 1 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition "OFF." 2. With the PCM disconnected, check continuity of the Bank 1 HO2S 2 high circuit. 3. If the Bank 1 HO2S 2 low circuit measures over 5.0 ohms, repair open or poor connection as necessary. Was a Bank 1 HO2S 2 low circuit problem found and corrected?	—	Verify repair	Go to <i>Step 9</i>
9	1. Ignition "ON," engine "OFF." 2. Disconnect Bank 1 HO2S 2 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 1 HO2S 2 voltage. Is Bank 1 HO2S 2 voltage in the specified range?	0-10 mV	Go to <i>Step 10</i>	Go to <i>Step 11</i>
10	Replace Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0141 HO2S Heater Circuit Bank 1 Sensor 2



D06RW061

Circuit Description

Heated oxygen sensors are used to minimize the amount of time required for closed loop fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further from the engine.

The powertrain control module (PCM) will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the Bank HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the Bank 1 HO2S 2 to become active, a DTC P0141 will set. The time it should take the HO2S to reach operating temperature is based on the total amount of air that has passed through the MAF sensor and into the engine (more total airflow = shorter time to HO2S activity).

Conditions for Setting the DTC

- No related DTCs.
- Intake air temperature (IAT) is less than 32°C (90°F) at start-up.

- Engine coolant temperature (ECT) is less than 32°C (90°F) at start-up.
- IAT and ECT are within 6°C (11°F) of each other at start-up.
- Ignition voltage is between 11 volts and 18 volts.
- Average mass airflow is less than 23 g/second during the sample period.
- Bank 1 HO2S 2 voltage does not change more than 150 mV from the bias voltage (between 400 mV-500 mV) for a longer amount of time than it should. The maximum amount of time to come up to operating range is 300 seconds. This warm-up time depends on the engine coolant temperature at start-up and accumulated air flow since start-up.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0141 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0141 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. The HO2S should be allowed to cool before performing this test. If the HO2S heater is functioning, the signal voltage will gradually increase or decrease as the sensor element warms. If the heater is not functioning, the HO2S signal will remain near the 450 mV bias voltage.
4. This ensures that the ignition feed circuit to the HO2S is not open or shorted. The test light should be connected to a good chassis ground, in case the HO2S low or HO2S heater ground circuit is faulty.
5. This checks the HO2S heater ground circuit.
6. This checks for an open or shorted HO2S heater element.
11. An open HO2S signal or low circuit can cause the HO2S heater to appear faulty. Check these circuits before replacing the sensor.


DTC P0141 – HO2S Heater Circuit Bank 1 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	NOTE: If the engine has just been operating, allow the engine to cool for at least 15 minutes before proceeding. 1. Remove the fuel pump relay. 2. Connect a fused jumper at the fuel pump relay socket, between the battery positive at the relay and the relay wire that leads to the fuel pump and O2S fuses. 3. Ignition "OFF." 4. Install a Tech 2. 5. Ignition "ON," engine "OFF." 6. Monitor the Bank 1 HO2S 1 voltage for several minutes. Did the HO2S voltage go from bias voltage to above or below the specified values?	Above 650 mV or below 250 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 3
3	Inspect the fuse for Bank 1 HO2S 2 ignition feed. Is the fuse open?	—	Go to Step 15	Go to Step 4
4	1. Ignition "OFF." 2. Raise the vehicle. 3. Disconnect the Bank 1 HO2S 2 electrical connector. 4. Using a test light connected to a good ground (do not use Bank 1 HO2S 2 heater ground or Bank 1 HO2S 2 low), probe the ignition feed circuit at the Bank 1 HO2S 2 electrical connector (PCM harness side). Does the test light illuminate?	—	Go to Step 5	Go to Step 7

DTC P0141 – HO2S Heater Circuit Bank 1 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
5	Connect the test light between the Bank 1 HO2S 2 ignition feed and the Bank 1 HO2S 2 heater ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 8
6	1. Allow the HO2S to cool for at least 15 minutes. 2. Using a DVM, measure the resistance between the Bank 1 HO2S 2 ignition feed and the Bank 1 HO2S 2 heater ground at the Bank 1 HO2S 2 pigtail. Is the HO2S resistance within the specified values?	3-6 ohms	Go to Step 9	Go to Step 10
7	Repair the open Bank 1 HO2S 2 ignition feed circuit to Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
8	Repair the open Bank 1 HO2S 2 heater ground circuit. Is the action complete?	—	Verify repair	—
9	1. Check for a poor connection at the Bank 1 HO2S 2 harness terminals. 2. If a poor connection is found, replace the terminals. Was a poor connection found?	—	Verify repair	Go to Step 10
10	1. Ignition "OFF." 2. Disconnect the PCM and check the continuity of the Bank 1 HO2S 2 signal circuit and the Bank 1 HO2S 2 low circuit. 3. If the Bank 1 HO2S 2 signal circuit or the HO2S low circuit measures over 5 ohms, repair the open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	1. Ignition "OFF." 2. Disconnect the PCM and check the continuity of the Bank 1 HO2S 1 signal circuit and the Bank 1 HO2S 1 low circuit. 3. If the Bank 1 HO2S 1 high circuit or the HO2S low circuit measures over 5 ohms, repair the open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	Check for a poor Bank 1 HO2S 2 low circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 13
13	Check for a poor Bank 1 HO2S 2 high circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
14	Replace Bank 1 HO2S 2. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in Bank 1 HO2S 2 ignition feed circuit and replace the faulty fuse. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0151 HO2S Circuit Low Voltage Bank 2 Sensor 1



D06RW083

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal high and signal low circuits. When measured with a 10 megaohm digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 2 HO2S 1 voltage remains excessively low for an extended period of time, DTC P0151 will be set.

Conditions for Setting the DTC

- No related DTCs.
- The engine is operating in "closed loop."
- Engine coolant temperature is above 60°C (140°F).
- "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8.
- Throttle angle is between 3% and 19%.
- Bank 2 HO2S 1 signal voltage remains below 22 mV during normal "closed loop" operation for a total of 77 seconds over a 90-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0151 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0151 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Heated oxygen sensor wiring – The sensor pigtail may be mispositioned and contacting the exhaust system.
- Poor PCM to engine block grounds.
- Fuel pressure – The system will go lean if pressure is too low. The PCM can compensate for some decrease. However, if fuel pressure is too low, a DTC P0151 may be set. Refer to *Fuel System Diagnosis*.
- Lean injector(s) – Perform "Injector Balance Test."

- Vacuum leaks – Check for disconnected or damaged vacuum hoses and for vacuum leaks at the intake manifold, throttle body, EGR system, and PCV system.
- Exhaust leaks – An exhaust leak may cause outside air to be pulled into the exhaust gas stream past the HO2S, causing the system to appear lean. Check for exhaust leaks that may cause a false lean condition to be indicated.
- MAF sensor –The system can go lean if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if the lean condition is corrected. If so, replace the MAF sensor.
- Fuel contamination – Water, even in small amounts, can be delivered to the fuel injectors. The water can cause a lean exhaust to be indicated. Excessive alcohol in the fuel can also cause this condition. Refer to *Fuel System Diagnosis* for the procedure to check for fuel contamination.

- If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0151 failing during operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0151 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicate.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0151 — HO2S Circuit Low Voltage Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 2 HO2S 1 voltage. Does the Bank 2 HO2S 1 voltage remain below the specified value?	22 mV	Go to Step 4	Go to Step 3
3	1. Ignition “ON,” engine “OFF,” review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0151 until the DTC P0151 test runs. 4. Note test result. Does the Tech 2 indicate DTC P0151 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Turn ignition “OFF.” 2. Disconnect the PCM. 3. Check the Bank 2 HO2S 1 high and low signal circuits for a short to ground or a short to the heater ground circuit. Were Bank 2 HO2S 1 signal circuits shorted?	—	Go to Step 5	Go to Step 6
5	Repair the Bank 2 HO2S 1 signal circuit. Is the action complete?	—	Verify repair	—
6	1. Ignition “OFF.” 2. Leave the PCM and HO2S 1 disconnected. 3. Check for continuity between the high and low signal circuits. Was there continuity between the high and low circuits?	—	Go to Step 7	Go to Step 8

DTC P0151 — HO2S Circuit Low Voltage Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
7	Repair the short between the high and low circuits. Is the action complete?	—	Verify repair	—
8	1. Ignition "OFF." 2. Reconnect the PCM, leave HO2S 1 disconnected. 3. Ignition "ON." Does the Tech 2 indicate Bank 2 HO2S 1 voltage near the specified value?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to <i>Step 9</i>
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0152 HO2S Circuit High Voltage Bank 2 Sensor 1



D06RW083

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) signal high and signal low circuits. When measured with a 10 megaohm digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing the injector pulse width as necessary. If the Bank 2 HO2S 1 voltage remains excessively high for an extended period of time, DTC P0152 will be set.

Conditions for Setting the DTC

- No related DTCs.
- The engine is operating in "closed loop."
- The engine coolant temperature is above 60°C (140°F).
- "Closed loop" commanded air/fuel ratio between 14.5 and 14.8.
- Throttle angle between 3% and 19%.
- Bank 2 HO2S 1 signal voltage remains above 952 mV during normal "closed loop" operation for a total of 77 seconds over a 90-second period.

OR

- Bank 2 HO2S 1 signal voltage remains above 500 mV during deceleration fuel cutoff mode operation for up to 3 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0152 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0152 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Fuel pressure – The system will go rich if pressure is too high. The PCM can compensate for some increase. However, if fuel pressure is too high, a DTC P0152 may be set. Refer to *Fuel System Diagnosis*.
- Rich injector(s) – Perform "Injector Balance Test."

- Leaking injector – Refer to *Fuel System Diagnosis*.
- Evaporative emissions (EVAP) system – Check the canister for fuel saturation. If the canister is full of fuel, check EVAP control system components and hoses. Refer to *Evaporative Emission (EVAP) Control System*.
- MAF sensor – The system can go rich if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if rich condition is corrected. If so, replace MAF sensor.
- Check for leaking fuel pressure regulator diaphragm by checking vacuum line to regulator for the presence of fuel. There should be no fuel in the vacuum line.
- TP sensor – An intermittent TP sensor output will cause the system to go rich, due to a false indication of the engine accelerating.
- Shorted Heated Oxygen Sensor (HO2S)– If the HO2S is internally shorted, the HO2S voltage displayed on the Tech 2 will be over 1 volt. Try disconnecting the affected HO2S with the key “ON,” engine “OFF.” If the displayed HO2S voltage changes from over 1000 mV to around 450 mV, replace the HO2S. Silicon contamination of the HO2S can cause a high HO2S voltage to be indicated. This condition is indicated by powdery white deposit on the portion of the HO2S exposed to the exhaust stream. If contamination is noticed, replace the affected HO2S.

- Open HO2S Signal Circuit of Faulty HO2S– A poor connection or open in the HO2S signal circuit can cause the DTC to set during deceleration fuel mode. An HO2S which is faulty and not allowing a full voltage switch between the rich and lean thresholds can also cause the condition. Operate the vehicle while monitoring the HO2S voltage with a Tech 2. If the HO2S is voltage limited within a range between 300 mV to 600 mV, check the HO2S signal circuit wiring and associated terminal connections.
- If none of the above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0152 failing during deceleration fuel cutoff mode operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0152 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0152 – HO2S Circuit High Voltage Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Engine is at operating temperature. 3. Operate the vehicle within the parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 2 HO2S 1 voltage. Does the Bank 2 HO2S 1 voltage remain above the specified value?	952 mV (500 mV in deceleration fuel cut-off mode)	Go to Step 4	Go to Step 3
3	1. Ignition “ON.” 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor “DTC” info for DTC P0152 until the DTC P0152 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0152 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Ignition “OFF.” 2. Disconnect Bank 2 HO2S 1. 3. Ignition “ON.” 4. At HO2S Bank 2 Sensor 1 connector (PCM side) use a DVM to measure voltages at the high and low signal terminals. Are the voltages in the specified range?	3-4 V	Go to Step 5	Go to Step 6

DTC P0152 – HO2S Circuit High Voltage Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
5	Repair short to voltage in signal circuit. Is the action complete?	—	Verify repair	—
6	1. Ignition "ON," engine "OFF." 2. At Bank 2 HO2S 1 connector (PCM side) jumper both the HO2S high and low signal circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 2 HO2S 1 voltage. Is Bank 2 HO2S 1 voltage below the specified value?	10 mV	Go to Step 7	Go to Step 8
7	1. Disconnect the jumpers to ground from Bank 2 HO2S 1 PCM-side connector. 2. With the HO2S 1 connector disconnected, monitor Bank 2 HO2S 1 voltage. Is the Bank 2 HO2S 1 voltage between the specified values?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 8
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0153 HO2S Slow Response Bank 2 Sensor 1



D06RW083

Circuit Description

The powertrain control module (PCM) continuously monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "closed loop" has been enabled. During the monitoring period the PCM counts the number of times that a rich-to-lean and lean-to-rich response is indicated and adds the amount of time it took to complete all rich-to-lean transitions and lean-to-rich transitions. With this information, an average time for rich-to-lean and lean-to-rich transitions can be determined. If the average response time of either transition is too slow, a DTC P0153 will be set.

A lean-to-rich transition is indicated when the HO2S voltage changes from less than 300 mV to greater than 600 mV. A rich-to-lean transition is indicated when the HO2S voltage changes from more than 600 mV to less than 300 mV. An HO2S that responds too slowly is likely to be faulty and should be replaced.

Conditions for Setting the DTC

- No related DTCs.
- Engine coolant temperature (ECT) is above 50°C (122°F) for automatic transmission; 75° (167°F) for manual transmission.
- The engine is operating in "closed loop."
- Engine has been running for at least one minute.
- Canister purge duty cycle is above 2%.
- Engine speed is between 1500 RPM and 3000 RPM.
- Mass air flow is between 9 g/second and 42 g/second.

- All above conditions are met for 3 seconds.
- 90 seconds after "closed loop" has been enabled, Bank 2 HO2S 1 average transition time between 300 mV and 600 mV is too slow. The lean-to-rich average transition response time was longer than 94 milliseconds or the rich-to-lean average transition response time was longer than 105 milliseconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0153 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0153 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 2 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often

the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Verifies that the fault is currently present.
3. HO2S transition time, ratio mean volts and switching DTCs set for multiple sensors indicate probable contamination. Before replacing the sensors, isolate and correct the source of the contamination to avoid damaging the replacement sensors.

DTC P0153 – HO2S Slow Response Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	NOTE: If any DTCs are set, (except P0133, P1133, P1134, P1153, and/or P1154), refer to those DTCs before proceeding with this diagnostic chart. 1. Install the Tech 2. 2. Idle the engine at operating temperature. 3. Operate the vehicle within parameters specified under "Conditions for Setting the DTC" criteria included in Diagnostic Support. 4. Using a Tech 2, monitor "DTC" info for DTC P0153 until the DTC P0153 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0153 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	Did the Tech 2 also indicate DTC P0153, P1133, P1134, P1153, and/or P1154 test failed this ignition?	—	Go to Step 17	Go to Step 4
4	Check for leaks at the pipe joints. Are the joints leaking?	—	Go to Step 5	Go to Step 6
5	Tighten the U-bolt nuts at the leaking joint. Is your action complete?	—	Go to Step 2	—
6	Check for gaskets that are damaged or improperly installed. Are there damaged or misaligned gaskets?	—	Go to Step 7	Go to Step 8
7	1. Replace the damaged gaskets. 2. Align the connections. 3. Tighten the connections. Is your action complete?	—	Go to Step 2	—
8	Check for loose exhaust flange connections. Are the flange connections loose?	—	Go to Step 9	Go to Step 10
9	Tighten the stud nuts or bolts to specifications. Is your action complete?	—	Go to Step 2	—
10	Check for burned or corroded exhaust pipes. Are the exhaust pipes burned or corroded?	—	Go to Step 11	Go to Step 12


DTC P0153 – HO2S Slow Response Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
11	Replace the exhaust pipes, as required. Is your action complete?	—	Go to Step 2	—
12	Check for leaks at the exhaust manifold. Are there leaks at the exhaust manifold?	—	Go to Step 13	Go to Step 14
13	Tighten the bolts to specifications or replace the manifold if necessary. Is your action complete?	—	Go to Step 2	—
14	1. Visually/physically inspect the following items: <ul style="list-style-type: none"> ○ Ensure that the Bank 2 HO2S 1 is securely installed. ○ Check for corrosion on terminals. ○ Check terminal tension (at Bank 2 HO2S 1 and at the PCM). ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Go to Step 18	Go to Step 15
15	1. Disconnect Bank 2 HO2S 1. 2. Ignition "ON." 3. Using a DVM at the PCM side of the HO2S 1 connector, measure the voltage between the high signal circuit and ground. Are both voltages in the specified range?	3-4 V	Go to Step 16	Go to Step 19
16	1. With Bank 2 HO2S 1 disconnected, jumper the high and low (PCM side) signal circuits to ground. 2. Ignition "ON." 3. Using a Tech 2, monitor the Bank 2 HO2S 1 voltage. Does the Tech 2 indicate less than 10 mV and immediately return to about 450 mV when the jumper is removed?	—	Go to Step 21	Go to Step 22
17	Replace the affected heated oxygen sensors. NOTE: Before replacing the sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination. ○ Use of improper RV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—
18	Repair condition as necessary. Is the action complete?	—	Verify repair	—
19	Check for faulty PCM connections or terminal damage. Is the action complete?	—	Verify repair	Go to Step 20
20	Repair open, short or grounded signal circuit. Is the action complete?	—	Verify repair	—

DTC P0153 – HO2S Slow Response Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
21	Replace Bank 2 HO2S 1. Is the action complete?	—	Verify repair	—
22	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0154 HO2S Circuit Insufficient Activity Bank 2 Sensor 1



D06RW064

Circuit Description

The powertrain control module (PCM) supplies a bias voltage of about 450 mV between the heated oxygen sensor (HO2S) high and low circuits. When measured with a 10 megaohm digital voltmeter, this may display as low as 320 mV. The oxygen sensor varies the voltage within a range of about 1000 mV when the exhaust is rich, down through about 10 mV when exhaust is lean. The PCM constantly monitors the HO2S signal during "closed loop" operation and compensates for a rich or lean condition by decreasing or increasing injector pulse width as necessary. If the Bank 2 HO2S 1 voltage remains at or near the 450 mV bias for an extended period of time, DTC P0154 will be set, indicating an open sensor signal or sensor low circuit.

Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heater are required by post-catalyst monitor sensors to maintain a sufficiently high temperature for accurate exhaust oxygen content readings further from the engine.

Conditions for Setting the DTC

- No related DTCs.
- Battery voltage is above 10 volts.
- Engine running time is longer than 40 seconds.
- Oxygen sensor heater is functioning properly.
- Bank 2 HO2S 1 signal voltage remains between 400 mV and 500 mV for a total of 77 seconds over a 90-second period of time.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- "Open loop" fuel control will be in effect.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0154 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0154 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire-connection, and damaged harness.
- Faulty HO2S heater or heater circuit – With the ignition “ON,” engine “OFF,” the HO2S 1 voltage displayed on the Tech 2 is normally 455-460 mV. A reading over 1000 mV indicates a signal line shorted to voltage. A reading under 5 mV indicates a signal line shorted to ground or signal lines shorted together. If not, disconnect the HO2S and connect a test light between the HO2S ignition feed and heater ground circuits. If the test light does not light for 2 seconds when the ignition is turned on, repair the open ignition feed or sensor ground circuit as necessary. If the test light lights and the HO2S signal and low circuits are OK, replace the HO2S.

- Intermittent test – With the ignition “ON,” monitor the HO2S signal voltage while moving the wiring harness and related connectors. If the fault is induced, the HO2S signal voltage will change. This may help isolate the location of the malfunction.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. If the DTC P0154 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0154 – HO2S Circuit Insufficient Activity Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the engine above 1200 RPM for two minutes. Does the Tech 2 indicate Bank 2 HO2S 1 voltage varying outside the specified values?	400-500 mV	Go to Step 3	Go to Step 4
3	1. Ignition “ON,” engine “OFF.” 2. Review and record Tech 2 Failure Records data and note parameters. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor “DTC” info for DTC P0154 until the DTC P0154 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0154 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	Check for a damaged harness. Was a problem found?	—	Verify repair	Go to Step 5
5	Check for a poor Bank 2 HO2S 1 high and low circuit terminal connections at the Bank 2 HO2S 1 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 6
6	Check for a poor Bank 2 HO2S 1 high and low circuit terminal connections at the PCM and replace terminal(s) if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 7

DTC P0154 – HO2S Circuit Insufficient Activity Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition "OFF." 2. With the PCM disconnected check continuity of the Bank 2 HO2S 1 low circuit. 3. If the Bank 2 HO2S 1 high circuit measures over 5.0 ohms, repair open or poor connection as necessary. Was a Bank 2 HO2S 1 high circuit problem found and corrected?	—	Verify repair	Go to <i>Step 8</i>
8	1. Ignition "OFF." 2. With the PCM disconnected check continuity of the Bank 2 HO2S 1 low circuit. 3. If the Bank 2 HO2S 1 low circuit measures over 5 ohms, repair open or poor connection as necessary. Was a Bank 2 HO2S 1 low circuit problem found and corrected?	—	Verify repair	Go to <i>Step 9</i>
9	1. Ignition "ON," engine "OFF." 2. Disconnect Bank 2 HO2S 1 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 2 HO2S 1 voltage. Is the Bank 2 HO2S 1 voltage in the specified range?	0-10 mV	Go to <i>Step 10</i>	Go to <i>Step 11</i>
10	Replace Bank 2 HO2S 1. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0155 HO2S Heater Circuit Bank 2 Sensor 1



D06RW064

Circuit Description

Heated oxygen sensors are used to minimize the amount of time required for closed loop fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further from the engine.

The powertrain control module (PCM) will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started the PCM will monitor the HO2S voltage. When the Bank HO2S voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the Bank 2 HO2S 1 to become active, a DTC P0155 will set. The time it should take the HO2S to reach operating temperature is based on the total amount of air that has passed through the mass air flow (MAF) sensor and into the engine (more total air flow = shorter time to HO2S activity).

Conditions for Setting the DTC

- No related DTCs.
- Intake air temperature (IAT) is less than 32°C (90°F) at start-up.

- Engine coolant temperature (ECT) is less than 32°C (90°F) at start-up.
- IAT and ECT are within 6°C (11°F) of each other at start-up.
- Ignition voltage is between 11 volts and 18 volts.
- Average mass air flow for the sample period is less than 23 g/second.
- Bank 1 HO2S 2 voltage does not change more than 150 mV from the bias voltage (between 400 mV-500 mV) for a longer amount of time than it should. The maximum amount of time to come up to operating range is 150 seconds. This warm-up time depends on the engine coolant temperature at start-up and accumulated air flow since start-up.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0155 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0155 can be cleared by using the Tech 2 "Clear info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. The HO2S should be allowed to cool before performing this test. If the HO2S heater is functioning, the signal voltage will gradually increase or decrease as the sensor element warms. If the heater is not functioning, the HO2S signal will remain near the 450 mV bias voltage.
4. Ensures that the ignition feed circuit to the HO2S is not open or shorted. The test light should be connected to a good chassis ground, in case the HO2S low or HO2S heater ground circuit is faulty.
5. Checks the HO2S heater ground circuit.
6. Checks for an open or shorted HO2S heater element.
10. An open HO2S signal or low circuit can cause the HO2S heater to appear faulty. Check these circuits before replacing the sensor.


DTC P0155 –HO2S Heater Circuit Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	NOTE: If the engine has just been operating, allow the engine to cool for at least 15 minutes before proceeding. 1. Remove the fuel pump relay. 2. Connect a fused jumper at the fuel pump relay socket, between the battery positive at the relay and the relay wire that leads to the fuel pump and O2S fuses. 3. Ignition "OFF." 4. Install a Tech 2. 5. Ignition "ON," engine "OFF." 6. Monitor the Bank 1 HO2S 1 voltage for several minutes. Did the HO2S voltage go from bias voltage to above or below the specified value?	Above 650 mV or below 250 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 3
3	Inspect the fuse for the Bank 2 HO2S 1 ignition feed. Is the fuse open?	—	Go to Step 15	Go to Step 4
4	1. Ignition "OFF." 2. Raise the vehicle. 3. Disconnect the Bank 2 HO2S 1 electrical connector. 4. Using a test light connected to a known good ground (do not use Bank 2 HO2S 1 heater ground or Bank 2 HO2S 1 low), probe the ignition feed circuit at the Bank 2 HO2S 1 electrical connector (PCM harness side). Does the test light illuminate?	—	Go to Step 5	Go to Step 7

DTC P0155 –HO2S Heater Circuit Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
5	Connect the test light between Bank 2 HO2S 1 ignition feed and Bank 2 HO2S 1 heater ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 8
6	1. Allow the HO2S to cool for at least 15 minutes. 2. Using a DVM, measure resistance between the Bank 2 HO2S 1 ignition feed and the Bank 2 HO2S 1 heater ground at the Bank 2 HO2S 1 pigtail. Is the HO2S resistance within the specified values?	3-6 ohms	Go to Step 9	Go to Step 10
7	Repair the open Bank 2 HO2S 1 ignition feed circuit to Bank 2 HO2S 1. Is the action complete?	—	Verify repair	—
8	Repair the open Bank 2 HO2S 1 heater ground circuit. Is the action complete?	—	Verify repair	—
9	1. Check for a poor connection at the Bank 2 HO2S 1 harness terminals. 2. If a poor connection is found, replace terminals. Was a poor connection found?	—	Verify repair	Go to Step 10
10	Check for a poor Bank 2 HO2S 1 signal or low circuit terminal connection at the Bank 2 HO2S 1 harness connector and replace terminal(s) if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 11
11	1. Ignition "OFF." 2. Disconnect the PCM and check the continuity of the Bank 2 HO2S 1 signal circuit and the Bank 2 HO2S 1 low circuit. 3. If the Bank 2 HO2S 1 signal circuit or HO2S low circuit measures over 5 ohms, repair open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	Check for a poor Bank 2 HO2S 1 low circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 13
13	Check for a poor Bank 2 HO2S 1 signal circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
14	Replace Bank 2 HO2S 1. Is the action complete?	—	Verify repair	—
15	Locate and repair short to ground in Bank 2 HO2S 1 ignition feed circuit and replace the faulty fuse. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0157 HO2S Circuit Low Voltage Bank 2 Sensor 2



D06RW065

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 2 HO2S 1 and the Bank 2 HO2S 2 heated oxygen sensors. The Bank 2 HO2S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 2 HO2S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 2 HO2S 1 signal will be far more active than that produced by the Bank 2 HO2S 2 sensor. If the Bank 2 HO2S 2 signal voltage remains excessively low for an extended period of time, DTC P0157 will be set.

Conditions for Setting the DTC

- No related DTCs.
- The engine is operating in "closed loop."
- Engine coolant temperature is above 60°C (140°F).

- "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8
 - Throttle angle is between 3% and 19%.
 - Bank 2 HO2S 2 signal voltage remains below 22 mV during normal "closed loop" operation for a total of 106 seconds over a 125-second period of time.
- OR
- Bank 2 HO2S 2 signal voltage remains below 400 mV during "power enrichment" mode fuel control operation for up to 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0157 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0157 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Heated oxygen sensor wiring – The sensor pigtail may be mispositioned and contacting the exhaust system.
- Poor PCM to engine grounds.
- Fuel pressure – A condition which causes a lean exhaust can cause DTC P0157 to set. The system will go lean if pressure is too low. The PCM can compensate for some decrease. However, if fuel pressure is too low, a DTC P0157 may be set. Refer to *Fuel System Diagnosis*.
- Lean injector(s) – Perform “Injector Balance Test.”
- Vacuum leaks – Check for disconnected or damaged vacuum hoses and for vacuum leaks at the intake manifold, throttle body, EGR system, and PCV system.
- Exhaust leaks – An exhaust leak may cause outside air to be pulled into the exhaust gas stream past the HO2S, causing the DTC P0157 to set. Check for exhaust leaks near the Bank 1 HO2S 2 sensor.
- MAF sensor – The system can go lean if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if the lean condition is corrected. If so, replace the MAF sensor.

- Fuel contamination – Water, even in small amounts, can be delivered to the fuel injectors. The water can cause a lean exhaust to be indicated. Excessive alcohol in the fuel can also cause this condition. Refer to *Fuel System Diagnosis* for the procedure to check for fuel contamination.

- If none of above conditions are present, replace the affected HO2S 2.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0157 failing during operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0157 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0157 – HO2S Circuit Low Voltage Bank 2 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within the parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 2 HO2S 2 voltage. Does the Bank 2 HO2S 2 voltage remain below the specified value?	22 mV	Go to Step 4	Go to Step 3
3	1. Ignition “ON,” engine “OFF.” 2. Review and record Tech 2 Failure Records data and note parameters. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor “DTC” info for DTC P0157 until the DTC P0157 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0157 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	1. Turn the ignition “OFF.” 2. Disconnect the PCM. 3. Check the Bank 2 HO2S 2 high and low signal circuits for a short to ground or a short to the heater ground circuit. Were Bank 2 HO2S 2 signal circuits shorted?	—	Go to Step 5	Go to Step 6
5	Repair the Bank 1 HO2S 2 signal circuit. Is the action complete?	—	Verify repair	—

DTC P0157 – HO2S Circuit Low Voltage Bank 2 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Ignition "OFF." 2. Leave the PCM and HO2S 2 disconnected. 3. Check for continuity between the high and low signal circuits. Was there continuity between the high and low circuits?	—	Go to Step 7	Go to Step 8
7	Repair the short between the high and low circuits. Is the action complete?	—	Verify repair	—
8	1. Ignition "OFF." 2. Reconnect the PCM, leave HO2S 2 disconnected. 3. Ignition "ON." Does the Tech 2 indicate Bank 2 HO2S 2 voltage near the specified value?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 9
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0158 HO2S Circuit High Voltage Bank 2 Sensor 2



D06RW065

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 2 HO2S 1 and the Bank 2 HO2S 2 heated oxygen sensors. The Bank 2 HO2S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 2 HO2S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 2 HO2S 1 signal will be far more active than that produced by the Bank 2 HO2S 2 sensor. If the Bank 2 HO2S 2 signal voltage remains excessively high for an extended period of time, DTC P0158 will be set.

Conditions for Setting the DTC

- No related DTCs.
- Engine is operating in "closed loop."
- "Closed loop" commanded air/fuel ratio is between 14.5 and 14.8.

- Engine coolant temperature is above 60°C (140°F).
- Throttle angle is between 3% and 19%.
- Bank 2 HO2S 2 signal voltage remains above 952 mV during normal "closed loop" operation for a total of 106 seconds over a 125-second period.

OR

- Bank 2 HO2S 2 signal voltage remains above 500 mV during deceleration fuel cutoff mode operation for up to 3 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0158 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0158 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Fuel pressure – An excessively rich fuel mixture can cause a DTC P0158 to be set. Refer to *Fuel System Diagnosis*.
- Rich injector(s) – Perform “Injector Balance Test.”
- Leaking injector – Refer to *Fuel System Diagnosis*.
- Evaporative emissions (EVAP) canister purge – Check for fuel saturation. If full of fuel, check canister control and hoses. Refer to *Evaporative Emission (EVAP) Control System*.
- MAF sensor –The system can go rich if the MAF sensor signal indicates an engine airflow measurement that is not correct. Disconnect the MAF sensor to see if a rich condition is corrected. If so, replace the MAF sensor.
- Check for a leaking fuel pressure regulator diaphragm by checking the vacuum line to the regulator for the presence of fuel. There should be no fuel in the vacuum line.
- TP sensor – An intermittent TP sensor output will cause the system to go rich, due to a false indication of the engine accelerating.
- Shorted Heated Oxygen Sensor (HO2S) – If the HO2S is internally shorted, the HO2S voltage displayed on the Tech 2 will be over 1 volt. Try disconnecting the affected HO2S with the key “ON,” engine “OFF.” If the displayed HO2S voltage changes from over 1000 mV to around 450 mV, replace the HO2S. Silicon contamination of the HO2S can also cause a high HO2S voltage to be indicated. This condition is

indicated by a powdery white deposit on the portion of the HO2S exposed to the exhaust stream. If contamination is noticed, replace the affected HO2S.

- Open HO2S signal or low circuit, or faulty HO2S – A poor connection or open in the HO2S signal or low circuit can cause the DTC to set during deceleration fuel cutoff mode operation. An HO2S which is faulty and does not allow full voltage swing between the rich and lean thresholds can also cause this condition. Operate the vehicle while monitoring the HO2S voltage with a Tech 2. If the HO2S voltage is limited within a range between 300 mV to 600 mV, check the HO2S signal and low circuit wiring and associated terminal connections. If the wiring and connections are OK, replace the HO2S.
- If none of above conditions are present, replace the affected HO2S.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. DTC P0158 being set during deceleration fuel cutoff mode operation may indicate a condition described in the “Diagnostic Aids” above. If the DTC P0158 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0158 – HO2S Circuit High Voltage Bank 2 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the vehicle within parameters specified under “Conditions for Setting the DTC” criteria included in Diagnostic Support. 4. Using a Tech 2, monitor Bank 2 HO2S 2 voltage. Does the Bank 2 HO2S 2 voltage remain above the specified value?	952 mV (500 mV in deceleration fuel cut-out mode)	Go to Step 4	Go to Step 3
3	1. Ignition “ON.” 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor “DTC” info for DTC P0158 until the DTC P0158 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0158 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0158 – HO2S Circuit High Voltage Bank 2 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Ignition "OFF." 2. Disconnect Bank 2 HO2S 2. 3. Ignition "ON." 4. At the HO2S Bank 2 Sensor 2 connector (PCM side), use a DVM to measure voltages at the high and low signal terminals. Are the voltages in the specified range?	3-4 V	Go to Step 5	Go to Step 6
5	Repair short to voltage in signal circuit. Is the action complete?	—	Verify repair	—
6	1. Ignition "ON," engine "OFF." 2. At Bank 2 HO2S 2 connector (PCM side) jumper both the HO2S high and low signal circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 2 HO2S 2 voltage. Is Bank 2 HO2S 2 voltage below the specified value?	10 mV	Go to Step 7	Go to Step 8
7	1. Disconnect the jumpers to ground from Bank 2 HO2S 2 PCM-side connector. 2. With the HO2S 2 connector disconnected, monitor Bank 2 HO2S 2 voltage. Is Bank 2 HO2S 2 voltage between the specified values?	425-475 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 8
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0160 HO2S Circuit Insufficient Activity Bank 2 Sensor 2



D06RW066

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalytic converter is used. The catalyst within the converter promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 2 HO2S 1 and the Bank 2 HO2S 2 heated oxygen sensors. The Bank 2 HO2S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 2 HO2S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 2 HO2S 1 signal will be far more active than that produced by the Bank 2 HO2S 2 sensor. If the Bank 2 HO2S 2 signal voltage remains between 400 mV and 500 mV for an extended period of time, DTC P0160 will be set. Heated Oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a

sufficiently high temperature for accurate exhaust oxygen content readings further from the engine.

Conditions for Setting the DTC

- ☐ No related DTCs.
- ☐ Battery voltage is above 10 volts.
- ☐ Engine run time is longer than 40 seconds.
- ☐ Oxygen sensor heater is functioning properly.
- ☐ Engine is in "closed loop" operation.
- ☐ Bank 2 HO2S 2 signal voltage remains between 426 mV and 474 mV for a total of 106 seconds over a 125-second period of time.

Action Taken When the DTC Sets

- ☐ The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- ☐ The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- ☐ The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- ☐ A history DTC P0160 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P0160 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, poor terminal-to-wire connection, and damaged harness.
- Faulty HO2S heater or heater circuit – With the ignition “ON,” engine “OFF,” the HO2S voltage displayed on a Tech 2 should gradually drop to below 250 mV. If not, disconnect the HO2S and connect a test light between the HO2S ignition feed and heater ground circuits. If the test light does not light, repair the open ignition feed or sensor ground circuit as necessary. If the test light lights and the HO2S signal and low circuits are OK, replace the HO2S.

- Intermittent test – With the ignition “ON,” monitor the HO2S signal voltage while moving the wiring harness and related connectors. If the fault is induced, the HO2S signal voltage will change. This may help isolate the location of the malfunction.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

- 3.If the DTC P0160 test passes while the Failure Records conditions are being duplicated, an intermittent condition is indicated.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0160 – HO2S Circuit Insufficient Activity Bank 2 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Install the Tech 2. 2. Run the engine at operating temperature. 3. Operate the engine above 1200 RPM for two minutes. Does the Tech 2 indicate Bank 2 HO2S 2 voltage varying outside the specified values?	425-475 mV	Go to Step 3	Go to Step 4
3	1. Ignition “ON,” engine “OFF,” review and record Tech 2 Failure Records data and note parameters. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor “DTC” info for DTC P0160 until the DTC P0160 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0160 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	Check for a damaged harness. Was problem found?	—	Verify repair	Go to Step 5
5	Check for poor Bank 2 HO2S 2 high and low circuit terminal connections at the Bank 2 HO2S 2 harness connector and replace terminal(s) if necessary. Did either terminal require replacement?	—	Verify repair	Go to Step 6
6	Check for poor Bank 2 HO2S 2 high and low circuit terminal connections at the PCM and replace terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 7
7	1. Ignition “OFF.” 2. With the PCM disconnected, check continuity of the Bank 2 HO2S 2 high circuit. 3. If the Bank 2 HO2S 2 high circuit measures over 5.0 ohms, repair open or poor connections as necessary. Was a Bank 2 HO2S 2 high circuit problem found and corrected?	—	Verify repair	Go to Step 8

DTC P0160 – HO2S Circuit Insufficient Activity Bank 2 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Ignition "OFF." 2. With the PCM disconnected, check continuity of the Bank 2 HO2S 2 low circuit. 3. If the Bank 2 HO2S 2 low circuit measures over 5 ohms, repair open or poor connections as necessary. Was a Bank 2 HO2S 2 low circuit problem found and corrected?	—	Verify repair	Go to <i>Step 9</i>
9	1. Ignition "ON," engine "OFF." 2. Disconnect Bank 2 HO2S 2 and jumper the HO2S high and low circuits (PCM side) to ground. 3. Using a Tech 2, monitor Bank 2 HO2S 2 voltage. Is Bank 2 HO2S 2 voltage in the specified range?	0-10 mV	Go to <i>Step 10</i>	Go to <i>Step 11</i>
10	Replace Bank 2 HO2S 2. Is the action complete?	—	Verify repair	—
11	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0161 HO2S Heater Circuit Bank 2 Sensor 2



D06RW066

Circuit Description

Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature which allows accurate exhaust oxygen content readings further from the engine. The powertrain control module (PCM) will run the heater test only after a cold start (determined by engine coolant and intake air temperature at the time of start-up) and only once during an ignition cycle. When the engine is started, the PCM will monitor the HO2S voltage. When the Bank 2 HO2S 2 voltage indicates a sufficiently active sensor, the PCM looks at how much time has elapsed since start-up. If the PCM determines that too much time was required for the Bank 2 HO2S 2 to become active, a DTC P0161 will set. The time it should take the HO2S to reach operating temperature is based on the total amount of air that has passed through the MAF sensor and into the engine (more total air flow = shorter time to HO2S activity).

Conditions for Setting the DTC

- No related DTCs.
- Intake air temperature (IAT) is less than 32°C (90°F) at start-up.

- Engine coolant temperature (ECT) is less than 32°C (90°F) at start-up.
- IAT and ECT are within 6°C (11°F) of each other at start-up.
- Ignition voltage is between 11 volts and 18 volts.
- Average mass air flow for the sample period is less than 23 g/second.
- Bank 2 HO2S 2 voltage does not change more than 150 mV from the bias voltage (between 400 mV-500 mV) for a longer amount of time than it should. The maximum amount of time to come up to operating range is 300 seconds. This warm-up time depends on the engine coolant temperature at start-up and accumulated air flow since start-up.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0161 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0161 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. The HO2S should be allowed to cool before performing this test. If the HO2S heater is functioning, the signal voltage will gradually increase or decrease as the sensor element warms. If the heater is not functioning, the HO2S signal will remain near the 450 mV bias voltage.
4. This ensures that the ignition feed circuit to the HO2S is not open or shorted. The test light should be connected to a good chassis ground, in case the HO2S low or HO2S heater ground circuit is faulty.
5. This checks the HO2S heater ground circuit.
6. This checks for an open or shorted HO2S heater element.
11. An open HO2S signal or low circuit can cause the HO2S heater to appear faulty. Check these circuits before replacing the sensor.


DTC P0161 –HO2S Heater Circuit Bank 2 Sensor 2

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	NOTE: If the engine has just been operating, allow the engine to cool for at least 15 minutes before proceeding. 1. Remove the fuel pump relay. 2. Connect a fused jumper at the fuel pump relay socket, between the battery positive at the relay and the relay wire that leads to the fuel pump and O2S fuses. 3. Ignition "OFF." 4. Install a Tech 2. 5. Ignition "ON," engine "OFF." 6. Monitor the Bank 2 O2S 2 voltage for several minutes. Did the HO2S voltage go from bias voltage to above or below the specified values?	Above 650 mV or Below 250 mV	Refer to <i>Diagnostic Aids</i>	Go to Step 3
3	Inspect the fuse for the Bank 2 HO2S 2 ignition feed. Is the fuse open?	—	Go to Step 15	Go to Step 4
4	1. Ignition "OFF." 2. Raise the vehicle. 3. Disconnect the Bank 2 HO2S 2 electrical connector. 4. Using a test light connected to a known good ground (do not use Bank 2 HO2S 2 heater ground or Bank 2 HO2S 2 low), probe the ignition feed circuit at the Bank 2 HO2S 2 electrical connector (PCM harness side). Does the test light illuminate?	—	Go to Step 5	Go to Step 7

DTC P0161 –HO2S Heater Circuit Bank 2 Sensor 2 (Cont'd)

Step	Action	Value(s)	Yes	No
5	Connect the test light between the Bank 2 HO2S 2 ignition feed and the Bank 2 HO2S 2 heater ground. Does the test light illuminate?	—	Go to Step 6	Go to Step 8
6	1. Allow the HO2S to cool for at least 15 minutes. 2. Using a DVM, measure resistance between the Bank 2 HO2S 2 ignition feed and the Bank 2 HO2S 2 heater ground at the Bank 2 HO2S 2 pigtail. Is the HO2S resistance within the specified values?	3-6 ohms	Go to Step 9	Go to Step 10
7	Repair the open Bank 2 HO2S 2 ignition feed circuit to Bank 2 HO2S 2. Is the action complete?	—	Verify repair	—
8	Repair the open Bank 2 HO2S 2 heater ground circuit. Is the action complete?	—	Verify repair	—
9	1. Check for a poor connection at the Bank 2 HO2S 2 harness terminals. 2. If a poor connection is found, replace the terminals. Was a poor connection found?	—	Verify repair	Go to Step 10
10	1. Ignition "OFF." 2. Disconnect the PCM and check the continuity of the Bank 2 HO2S 2 signal circuit and the Bank 2 HO2S 2 low circuit. 3. If the Bank 2 HO2S 2 signal circuit or HO2S low circuit measures over 5 ohms, repair the open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	1. Ignition "OFF." 2. Disconnect the PCM and check the continuity of the Bank 2 HO2S 2 signal circuit and the Bank 2 HO2S 2 low circuit. 3. If the Bank 2 HO2S 2 signal circuit or HO2S low circuit measures over 5 ohms, repair the open or poor connection as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	Check for a poor Bank 2 HO2S 2 low circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 13
13	Check for a poor Bank 2 HO2S 2 high circuit terminal connection at the PCM and replace the terminal if necessary. Did the terminal require replacement?	—	Verify repair	Go to Step 14
14	Replace Bank 2 HO2S 2. Is the action complete?	—	Verify repair	—
15	Locate and repair the short to ground in the Bank 2 HO2S 2 ignition feed circuit and replace the faulty fuse. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0171 Fuel Trim System Too Lean Bank 1



D06RW068

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "closed loop" air/fuel metering system is used. While in "closed loop," the powertrain control module (PCM) monitors the Bank 1 HO₂S 1 and Bank 2 HO₂S 1 signals and adjusts fuel delivery based upon the HO₂S signal voltages. A change made to fuel delivery will be indicated by the long and short term fuel trim values which can be monitored with a Tech 2. Ideal fuel trim values are around 0%; if the HO₂S signals are indicating a lean condition the PCM will add fuel, resulting in fuel trim values above 0%. If a rich condition is detected, the fuel trim values will be below 0%, indicating that the PCM is reducing the amount of fuel delivered. If an excessively lean condition is detected on Bank 1, the PCM will set DTC P0171.

The PCM's maximum authority to control long term fuel trim allows a range between -15% (automatic transmission) or -12% (manual transmission) and +20%. The PCM monitors fuel trim under various engine speed/load fuel trim cells before determining the status the fuel trim diagnostic.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of the following: EGR DTCs, HO₂S DTCs, (response, transition, open, low volts, no activity), MAF DTCs, TP sensor DTCs, MAP DTCs, IAT DTCs, canister purge DTCs, EVAP DTCs, injector circuit DTCs, or misfire DTCs.

- Engine coolant temperature is between 25°C (77°F) and 100°C (212°F).
- Intake air temperature is between -40°C (-40°F) and 120°C (248°F).
- Manifold absolute pressure is between 24 kPa and 99 kPa.
- Throttle angle is steady below 95%.
- Vehicle speed is below 136 km/h (85 mph).
- Engine speed is between 400 and 6000 RPM.
- Barometric pressure is greater than 72.5 kPa.
- Mass air flow (MAF) is between 2 g/second and 200 g/second.
- Ignition voltage is above 9.5 volts.
- Fuel system is in "closed loop."
- Canister purge duty cycle is greater than 0% if on.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history DTC P0171 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0171 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 1 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the engine harness. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. DTCs other than P0171 and P0174 may indicate a condition present which may cause a lean condition. If this is the case, repairing the condition which caused the other DTC will most likely correct the DTC P0171/P0174.
4. If the DTC P0171 test passes while the Failure Records conditions are being duplicated, the lean condition is intermittent. Refer to *Diagnostic Aids* or *Symptoms* for additional information on diagnosing intermittent problems.


DTC P0171 –Fuel Trim System Lean Bank 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any DTCs set other than P0171 and P0174?	—	Go to the applicable DTC charts and repair the other DTCs before proceeding with this chart	Go to Step 3
3	1. Start the engine and operate the vehicle in "closed loop." 2. Observe the "B1 Long Term Fuel Trim" display on the Tech 2. Is the displayed value greater than the specified value?	L.T. Fuel Trim: +20%	Go to Step 5	Go to Step 4
4	1. Review and record the Tech 2 Failure Records data. 2. Clear the DTC P0171/P0174 and operate the vehicle to duplicate the Failure Records conditions. 3. Monitor the Tech 2 "DTC" info for DTC P0171 while operating the vehicle to duplicate the Failure Records conditions. 4. Continue operating the vehicle until the DTC P0171 test runs and note the test result. Does the Tech 2 indicate DTC P0171 failed this ignition?	—	Go to Step 5	The lean condition is not present. If a driveability symptom still exists, refer to <i>Symptoms</i> section.
5	Was DTC P0174 also set?	—	Go to Step 6	Go to Step 15
6	Visually and physically inspect the vacuum hoses for disconnections, splits, kinks, improper routing and improper connections and repair any problem found. Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to Step 7
7	Visually and physically inspect the crankcase ventilation valve for proper installation and repair any problem found (refer to <i>Crankcase Ventilation System</i>). Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to Step 8
8	1. Inspect the MAF sensor inlet screen for damage or for the presence of foreign objects which may partially block the air flow sample through the MAF sensor. 2. Correct any problem that is found as necessary. Did your inspection of the MAF sensor reveal a condition requiring repair?	—	Verify repair	Go to Step 9
9	Start the engine and note the idle quality. Is a high or unsteady idle being experienced?	—	Go to Step 10	Go to Step 11
10	1. Visually and physically inspect the throttle body, intake manifold, EGR valve and the EGR feed pipe for vacuum leaks. 2. Repair any vacuum leaks as necessary. Did your inspection reveal a vacuum leak?	—	Verify repair	Go to Step 11

DTC P0171 –Fuel Trim System Lean Bank 1 (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check the fuel for excessive water, alcohol, or other contaminants (see <i>Diagnosis in Engine Fuel</i> for the procedure) and correct the contaminated fuel condition if present (see <i>Engine Fuel</i>). Was the fuel contaminated?	—	Verify repair	Go to Step 12
12	1. Visually and physically inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight, and in their proper locations. 2. If a faulty ground condition is present, correct it as necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 13
13	1. Disconnect the MAF sensor electrical connector. 2. Operate the vehicle in “closed loop” while monitoring the “B1 Long Term Fuel Trim” displayed on the Tech 2. Does “BANK 1 S.T. FUEL TRIM” value decrease to near the specified value?	0%	Go to Step 19	Go to Step 14
14	Perform the procedure in the “Fuel System Pressure Test” and repair fuel system problem if necessary. Did Fuel System Pressure Test isolate a condition requiring repair?	—	Verify repair	Go to Step 15
15	1. Visually and physically inspect the intake manifold, injector O-rings, EGR adapter, EGR valve and the EGR feed pipes for vacuum leaks. 2. Repair any problem that is found. Did your inspection reveal a problem?	—	Verify repair	Go to Step 16
16	Visually and physically inspect the Bank 1 exhaust manifold for leaks and loose or missing hardware and correct any problem found. Did your inspection reveal a problem?	—	Verify repair	Go to Step 17
17	Perform the “Injector Balance Test,” and correct any problem found (refer to <i>Fuel Metering System</i>). Did Injector Balance Test isolate a problem?	—	Verify repair	Go to Step 18
18	1. Visually and physically inspect the Bank 1 HO2S 1 to ensure that it is installed securely and that the Bank 1 HO2S 1 pigtail and wiring harness are not contacting the exhaust or otherwise damaged. 2. If a problem is found, correct it as necessary. Did your inspection reveal a problem?	—	Verify repair	Refer to <i>Diagnostic Aids</i>
19	Replace the MAF sensor. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0172 Fuel Trim System Rich Bank 1



D06RW068

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "closed loop" air/fuel metering system is used. While in "closed loop," the powertrain control module (PCM) monitors the Bank 1 heated oxygen sensors (HO2S) 1 and Bank 2 HO2S 1 signals and adjusts fuel delivery based upon the HO2S signal voltages. A change made to fuel delivery will be indicated by the long and short term fuel trim values which can be monitored with a Tech 2. Ideal fuel trim values are around 0%; if the HO2S signals are indicating a lean condition the PCM will add fuel, resulting in fuel trim values above 0%. If a rich condition is detected, the fuel trim values will be below 0%, indicating that the PCM is reducing the amount of fuel delivered. If an excessively rich condition is detected on Bank 1, the PCM will set DTC P0172.

The PCM's maximum authority to control long term fuel trim allows a range between -15% (automatic transmission) or -12 (manual transmission) and +20%. The PCM's maximum authority to control short term fuel trim allows a range between -11% and +20%. The PCM monitors fuel trim under various engine speed/load fuel trim cells before determining the status of the fuel trim diagnostic.

Conditions for Setting the DTC

- No Tech 2 test is being run.

- None of the following was set: EGR DTCs, HO2S DTCs, (response, transition, open, low volts, no activity), MAF DTCs, TPS DTCs, MAP DTCs, IAT DTCs, canister purge DTCs, EVAP DTCs, injector circuit DTCs, or misfire DTCs.
- Engine coolant temperature is between 25°C (77°F) and 100°C (212°F).
- Intake air temperature is between -40°C (-40°F) and 120°C (248°F).
- Manifold absolute pressure is between 24 kPa and 99 kPa.
- Throttle angle is steady below 95%.
- Vehicle speed is below 136 km/h (85 mph).
- Engine speed is between 400 and 6000 RPM.
- Barometric pressure is greater than 72.5 kPa.
- Mass air flow (MAF) is between 2 g/second and 200 g/second.
- Ignition voltage is above 9.5 volts.
- Fuel system is in "closed loop."
- Canister purge duty cycle is greater than 0%, if "ON."

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0172 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0172 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 1 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the engine

harness. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. DTCs other than P0172 and P0175 may indicate a condition present which may cause a lean condition. If this is the case, repairing the condition which caused the other DTC will most likely correct the DTC P0172/P0175.
4. If the DTC P0172 test passes while the Failure Records conditions are being duplicated, the rich condition is intermittent. Refer to *Diagnostic Aids* or *Symptoms* for additional information on diagnosing intermittent problems.

DTC P0172 – Fuel Trim System Rich Bank 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any DTCs set other than P0172 and P0175?	—	Go to the applicable DTC charts and repair the other DTCs before proceeding with this chart	Go to Step 3
3	1. Start the engine and operate the vehicle in "closed loop." 2. Observe "B1 Long Term Fuel Trim" display on the Tech 2. Is the displayed value more negative than the specified value?	L.T. Fuel Trim: -15% (auto. trans.) OR -12% (man. trans.)	Go to Step 5	Go to Step 4
4	1. Review and record the Tech 2 Failure Records data. 2. Clear the DTC P0172/P0175 and operate the vehicle to duplicate the Failure Records conditions. 3. Monitor the Tech 2 "DTC" info for DTC P0172 while operating the vehicle to duplicate the Failure Records conditions. 4. Continue operating the vehicle until the DTC P0172 test runs and note test result. Does the Tech 2 indicate DTC P0172 failed this ignition?	—	Go to Step 5	The rich condition is not present. If a driveability symptom still exists, refer to <i>Symptoms</i> .
5	Is DTC P0175 also set?	—	Go to Step 6	Go to Step 15
6	Visually and physically inspect the air filter element and replace it if necessary. Did the air filter require replacement?	—	Verify repair	Go to Step 7


DTC P0172 – Fuel Trim System Rich Bank 1 (Cont'd)

Step	Action	Value(s)	Yes	No
7	Visually and physically inspect the air intake duct for collapse or restriction and repair if necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 8
8	Inspect the MAF sensor inlet screen for damage or for the presence of foreign objects which may partially block air flow through the screen and correct any problem found. Did your inspection of the MAF sensor reveal a condition requiring repair or replacement?	—	Verify repair	Go to Step 9
9	Start the engine and note the idle quality. Is a low or unsteady idle being experienced?	—	Go to Step 10	Go to Step 11
10	1. Ignition "OFF." 2. Physically inspect the throttle body bore, throttle plate, and IAC passages for coking and foreign objects. 3. If a problem was found, repair as necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 11
11	1. Disconnect the vacuum hose from the fuel pressure regulator and inspect the hose for the presence of fuel. 2. If fuel is present in the vacuum hose, replace the fuel pressure regulator (refer to <i>Fuel Metering System</i>). Did the fuel pressure regulator require replacement?	—	Verify repair	Go to Step 12
12	Ignition "ON," engine "OFF," monitor the TP Angle display on the Tech 2 while slowly depressing the accelerator pedal. Does the TP Angle display increase steadily and evenly from minimum value at closed throttle to maximum value at wide-open throttle?	Minimum 0% Maximum 100%	Go to Step 13	Go to Step 21
13	1. Disconnect the MAF sensor electrical connector. 2. Operate the vehicle in "closed loop" while monitoring the "B1 Long Term Fuel Trim" and "B1 Short Term Fuel Trim" display on the Tech 2. Did both values change to near the specified value?	0%	Go to Step 22	Go to Step 14
14	1. Perform "Fuel System Pressure Test." 2. If Fuel System Pressure Test isolates a problem, repair as necessary (refer to <i>Engine Fuel</i> or <i>Fuel Metering System</i>). Did the Fuel System Pressure Test isolate a problem requiring repair?	—	Verify repair	Go to Step 15
15	1. Ignition "ON," engine "OFF." 2. Connect a test light between the harness connector terminals of canister purge solenoid. Is the test light on?	—	Go to Step 16	Go to Step 19
16	Check for short to ground in the wire (red/blue) between the canister purge solenoid and PCM terminal A-15. Was there a short to ground?	—	Go to Step 17	Go to Step 18

DTC P0172 – Fuel Trim System Rich Bank 1 (Cont'd)

Step	Action	Value(s)	Yes	No
17	Repair the short to ground. Is the action complete?	—	Verify repair	—
18	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
19	1. Perform the "Injector Balance Test." 2. If Injector Balance Test isolates a problem, repair as necessary (refer to <i>Fuel Metering System</i>). Did the Injector Balance Test isolate a problem requiring repair?	—	Verify repair	Go to Step 20
20	1. Remove and visually/physically inspect the Bank 1 HO2S 1 for silicon contamination. This will be indicated by a powdery white deposit on the portion of the HO2S that is exposed to the exhaust stream. 2. If contamination is evident on the Bank 1 HO2S 1, replace the contaminated sensors. Did the sensor require replacement?	—	Verify repair	Refer to <i>Diagnostic Aids</i>
21	1. Check the TP sensor mounting screws and tighten or replace them as necessary if they are loose or missing. 2. If the screws are OK, replace the TP sensor. Is the action complete?	—	Verify repair	—
22	Replace the MAF sensor. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0174 Fuel Trim System Lean Bank 2



D06RW069

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "closed loop" air/fuel metering system is used. While in "closed loop," the powertrain control module (PCM) monitors the Bank 1 HO₂S 1 and Bank 2 HO₂S 1 signals and adjusts fuel delivery based upon the HO₂S signal voltages. A change made to fuel delivery will be indicated by the long and short term fuel trim values which can be monitored with a Tech 2. Ideal fuel trim values are around 0%; if the HO₂S signals are indicating a lean condition the PCM will add fuel, resulting in fuel trim values above 0%. If a rich condition is detected, the fuel trim values will be below 0%, indicating that the PCM is reducing the amount of fuel delivered. If an excessively lean condition is detected on Bank 2, the PCM will set DTC P0174.

The PCM's maximum authority to control long term fuel trim allows a range between -15%(automatic transmission) or -12%(manual transmission) and +20%. The PCM monitors fuel trim under various engine speed/load fuel trim cells before determining the status of the fuel trim diagnostic.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of the following DTCs are set: idle system, EGR, HO₂S, (response, transition, open, low volts, no activity), MAF, TP sensor, MAP, IAT, canister purge, EVAP, injector circuit, or misfire.

- Engine coolant temperature is between 25°C (77°F) and 100°C (212°F).
- Intake air temperature is between -40°C (-40°F) and 120°C (248°F).
- Manifold absolute pressure is between 24 kPa and 99 kPa.
- Throttle angle is steady below 95%.
- Vehicle speed is below 136 km/h (85 mph).
- Engine speed is between 400 and 6000 RPM.
- Barometric pressure is greater than 72.5 kPa.
- Mass air flow is between 2 g/second and 200 g/second.
- Ignition voltage is above 9.5 volts.
- Fuel system is in "closed loop."
- Canister purge duty cycle is greater than 15%, if "ON."

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the failure is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0174 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P0174 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 2 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the engine harness. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. DTCs other than P0171 and P0174 may indicate a condition present which may cause a lean condition. If this is the case, repairing the condition which caused the other DTC will most likely correct the DTC P0171/P0174.
4. If the DTC P0174 test passes while the Failure Records conditions are being duplicated, the lean condition is intermittent. Refer to *Diagnostic Aids* or *Symptoms* for additional information on diagnosing intermittent problems.


DTC P0174 – Fuel Trim System Lean Bank 2

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Are any DTCs set other than P0174 and P0171?	—	Go to the applicable DTC charts and repair the other DTCs before proceeding with this chart.	Go to <i>Step 3</i>
3	1. Start the engine and operate the vehicle in “closed loop.” 2. Observe the “B2 Long Term Fuel Trim” display on the Tech 2. Is the displayed values greater than the specified values?	L.T. Fuel Trim: +20%	Go to <i>Step 5</i>	Go to <i>Step 4</i>
4	1. Review and record Tech 2 Failure Records data. 2. Clear the DTC P0171/P0174 and operate the vehicle to duplicate the Failure Records conditions. 3. Monitor the Tech 2 “DTC” info for DTC P0174 while operating the vehicle to duplicate the Failure Records conditions. 4. Continue operating the vehicle until the DTC P0174 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0174 failed this ignition?	—	Go to <i>Step 5</i>	The lean condition is not present. If a driveability symptom still exists, refer to <i>Symptoms</i> section.
5	Was DTC P0171 also set?	—	Go to <i>Step 6</i>	Go to <i>Step 15</i>
6	Visually and physically inspect the vacuum hoses for disconnects, splits, kinks, improper routing and improper disconnections and repair any problem found. Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to <i>Step 7</i>
7	Visually and physically inspect the crankcase ventilation valve for proper installation and repair any problem found (refer to <i>Crankcase Ventilation System</i>). Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to <i>Step 8</i>
8	1. Inspect the MAF sensor inlet screen for damage or for the presence of foreign objects which may partially block the air flow sample through the MAF sensor. 2. Correct any problem that is found as necessary. Did your inspection of the MAF sensor reveal a condition requiring repair?	—	Verify repair	Go to <i>Step 9</i>
9	Start the engine and note the idle quality. Is a high or unsteady idle being experienced?	—	Go to <i>Step 10</i>	Go to <i>Step 11</i>

DTC P0174 – Fuel Trim System Lean Bank 2 (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Visually and physically inspect the throttle body, intake manifold, EGR valve and the EGR feed pipe for vacuum leaks. 2. Repair any vacuum leaks as necessary. Did your inspection reveal a vacuum leak?	—	Verify repair	Go to Step 11
11	Check the fuel for excessive water, alcohol, or other contaminants (see <i>Diagnosis</i> in <i>Engine Fuel</i> for procedure) and correct the contaminated fuel condition is present (see <i>Engine Fuel</i>). Was the fuel contaminated?	—	Verify repair	Go to Step 12
12	1. Visually and physically inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight, and in their proper locations. 2. If a faulty ground condition is present, correct it as necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 13
13	1. Disconnect the MAF sensor electrical connector. 2. Operate the vehicle in "closed loop" while monitoring the "B2 Short Term Fuel Trim" displayed on the Tech 2. Does the "B2 Short Term Fuel Trim" value decrease to near the specified value?	0%	Go to Step 19	Go to Step 14
14	Perform the procedure in the "Fuel System Pressure Test" and repair fuel system problem if necessary. Did the Fuel System Pressure Test isolate a condition requiring repair?	—	Verify repair	Go to Step 15
15	1. Visually and physically inspect the intake manifold, injector O-rings, EGR adapter, EGR valve and the EGR feed pipes for vacuum leaks. 2. Repair any problem that is found. Did your inspection reveal a problem?	—	Verify repair	Go to Step 16
16	Visually and physically inspect the Bank 2 exhaust manifold for leaks and loose or missing hardware and correct any problem found. Did your inspection reveal a problem?	—	Verify repair	Go to Step 17
17	Perform the "Injector Balance Test," and correct any problem found (refer to <i>Fuel Metering System</i>). Did the Injector Balance Test isolate a problem?	—	Verify repair	Go to Step 18
18	1. Visually and physically inspect the Bank 2 HO2S 1 to ensure that it is installed securely and that the Bank 2 HO2S 1 pigtail and wiring harness are not contacting the exhaust or otherwise damaged. 2. If a problem is found, correct it as necessary. Did your inspection reveal a problem?	—	Verify repair	Refer to <i>Diagnostic Aids</i>
19	Replace the MAF sensor. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0175 Fuel Trim System Rich Bank 2



D06RW069

Circuit Description

To provide the best possible combination of driveability, fuel economy, and emission control, a "closed loop" air/fuel metering system is used. While in "closed loop," the powertrain control module (PCM) monitors the Bank 1 HO₂S 1 and Bank 2 HO₂S 1 signals and adjusts fuel delivery based upon the HO₂S signal voltages. A change made to fuel delivery will be indicated by the long and short term fuel trim values which can be monitored with a Tech 2. Ideal fuel trim values are around 0%; if the HO₂S signals are indicating a lean condition the PCM will add fuel, resulting in fuel trim values above 0%. If a rich condition is detected, the fuel trim values will be below 0%, indicating that the PCM is reducing the amount of fuel delivered. If an excessively rich condition is detected on Bank 2, the PCM will set DTC P0175.

The PCM's maximum authority to control long term fuel trim allows a range between -15%(automatic transmission) or -12%(manual transmission) and +20%. The PCM's maximum authority to control short term fuel trim allows a range between -11% and +20%. The PCM monitors fuel trim under various engine speed/load fuel trim cells before determining the status of the fuel trim diagnostic.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of the following DTCs are set: idle system, EGR, HO₂S, (response, transition, open, low volts, no

activity), MAF, TPS, MAP, IAT, canister purge, EVAP, injector circuit, or misfire.

- Engine coolant temperature is between 25°C (77°F) and 100°C (212°F).
- Intake air temperature is between -40°C (-40°F) and 120°C (248°F).
- Manifold absolute pressure is between 24 kPa and 99 kPa.
- Throttle angle is steady below 95%.
- Vehicle speed is below 136 km/h (85 mph).
- Engine speed is between 400 and 6000 RPM.
- Barometric pressure is greater than 72.5 kPa.
- Mass air flow (MAF) is between 2 g/second and 200 g/second.
- Ignition voltage is above 9.5 volts.
- Fuel system is in "closed loop."
- Canister purge duty cycle is greater than 15%, if "ON."

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the failure is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

6E2-230 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- A history DTC P0175 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0175 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Bank 2 HO2S 1 display on the Tech 2 while moving connectors and wiring harnesses related to the engine harness. A change in the display will indicate the location of the fault.

Reviewing the Failure Records Vehicle mileage since the diagnostic test last failed may help determine how often

the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. DTCs other than P0172 and P0175 may indicate a condition present which may cause a lean condition. If this is the case, repairing the condition which caused the other DTC will most likely correct the DTC P0172/P0175.
4. If the DTC P0175 test passes while the Failure Records conditions are being duplicated, the rich condition is intermittent. Refer to *Diagnostic Aids* or *Symptoms* for additional information on diagnosing intermittent problems.

DTC P0175 – Fuel Trim System Rich Bank 2

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any DTCs set other than P0172 and P0175?	—	Go to the applicable DTC charts and repair the other DTCs before proceeding with this chart.	Go to <i>Step 3</i>
3	1. Start the engine and operate the vehicle in "closed loop." 2. Observe the "BANK 2 L.T. FUEL TRIM" display on the Tech 2. Is the displayed value more negative than the specified value?	L.T. Fuel Trim: -15% (auto. trans.) OR -12% (man. trans.)	Go to <i>Step 5</i>	Go to <i>Step 4</i>
4	1. Review and record the Tech 2 Failure Records data. 2. Clear the DTC P0172/P0175 and operate the vehicle to duplicate the Failure Records conditions. 3. Monitor the Tech 2 "DTC" info for DTC P0175 while operating the vehicle to duplicate the Failure Records conditions. 4. Continue operating the vehicle until the DTC P0175 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0175 failed this ignition?	—	Go to <i>Step 5</i>	The rich condition is not present. If a driveability symptom still exists, refer to <i>Symptoms</i> .
5	Was DTC P0172 also set?	—	Go to <i>Step 6</i>	Go to <i>Step 15</i>
6	Visually and physically inspect the air filter element and replace it if necessary. Did the air filter require replacement?	—	Verify repair	Go to <i>Step 7</i>

DTC P0175 – Fuel Trim System Rich Bank 2 (Cont'd)

Step	Action	Value(s)	Yes	No
7	Visually and physically inspect the air intake duct for collapse or restriction and repair if necessary. Did your inspection reveal a problem requiring repair?	—	Verify repair	Go to Step 8
8	Inspect the MAF sensor inlet screen for damage or for the presence of foreign objects which may partially block air flow through the screen and correct any problem found. Did your inspection of the MAF sensor reveal a condition requiring repair or replacement?	—	Verify repair	Go to Step 9
9	Start the engine and note the idle quality. Is a low or unsteady idle being experienced?	—	Go to Step 10	Go to Step 11
10	1. Turn the ignition off and physically inspect the throttle body bore, throttle plate, and IAC passages for coking and foreign objects. 2. If a problem was found, repair as necessary. Did your inspection reveal a condition requiring repair?	—	Verify repair	Go to Step 11
11	1. Disconnect the vacuum hose from the fuel pressure regulator and inspect the hose for the presence of fuel. 2. If fuel is present in the vacuum hose, replace the fuel pressure regulator (refer to <i>Fuel Metering System</i>). Did the fuel pressure regulator require replacement?	—	Verify repair	Go to Step 12
12	1. Ignition "ON," engine "OFF." 2. Monitor the TP Angle display on the Tech 2 while slowly depressing the accelerator pedal. Does the TP Angle display increase steadily and evenly from minimum value at closed throttle to maximum value at wide-open throttle?	Minimum 0% Maximum 100%	Go to Step 13	Go to Step 21
13	1. Disconnect the MAF sensor electrical connector. 2. Operate the vehicle in "closed loop" while monitoring the "B1 Long Term Fuel Trim" and "BANK 2 S.T. FUEL TRIM" display on the Tech 2. Did both values change to near the specified value?	0%	Go to Step 22	Go to Step 14
14	1. Perform the "Fuel System Pressure Test." 2. If Fuel System Pressure Test isolates a problem, repair as necessary (refer to <i>Engine Fuel</i> or <i>Fuel Metering System</i>). Did the Fuel System Pressure Test isolate a condition requiring repair?	—	Verify repair	Go to Step 15
15	1. Ignition "ON," engine "OFF." 2. Connect a test light between the harness connector terminals of canister purge solenoid. Is the test light on?	—	Go to Step 16	Go to Step 19
16	Check for short to ground in the wire (red/blue) between the canister purge solenoid and PCM terminal A-15. Was there a short to ground?	—	Go to Step 17	Go to Step 18

DTC P0175 – Fuel Trim System Rich Bank 2 (Cont'd)

Step	Action	Value(s)	Yes	No
17	Repair the short to ground. Is the action complete?	—	Verify repair	—
18	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
19	1. Perform the "Injector Balance Test." 2. If the Injector Balance Test isolates a problem, repair as necessary (refer to <i>Fuel Metering System</i>). Did the Injector Balance Test isolate a problem requiring repair?	—	Verify repair	Go to Step 20
20	1. Remove and visually/physically inspect the Bank 2 HO2S 1 for silicon contamination. This will be indicated by a powdery white deposit on the portion of the HO2S that is exposed to the exhaust stream. 2. If contamination is evident on the Bank 2 HO2S 1, replace the contaminated sensor. Did the sensor require replacement?	—	Verify repair	Refer to Diagnostic Aids
21	1. Check the TP sensor mounting screws and tighten or replace them as necessary if they are loose or missing. 2. If the screws are OK, replace the TP sensor. Is the action complete?	—	Verify repair	—
22	Replace the MAF sensor. Is the action complete?	—	Verify repair	—


5. A special injector test connector is provided so that the injectors can be electrically tested without removal of the manifold. The test connector can be identified by the blue connector lock which is tethered to the wiring harness. If the light for cylinder 1 is "ON" steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to ground.

If the test light blinks while cranking, the PCM and the wiring to the injectors are OK. The Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was "ON" steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.

9. The reading should be about 12-14Ω.

10. Locating the open in the harness or in the injector will require removal of the manifold to provide access.




DTC P0201 – Injector 1 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Will the engine start?	—	Go to Step 3	Go to <i>Engine Cranks But Will Not Run</i> chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0201 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition "ON" and the engine "OFF" and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0201 reset?	—	Go to Step 5	Go to <i>Diagnostic Aids</i>

DTC P0201 – Injector 1 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
5	1. Engine "OFF." 2. Disconnect the injector connector. 3. Install an injector test light J-39021-65 on the injector test connector. 4. Crank the engine and note the light. Does the injector test light blink?	—	Go to <i>Fuel Injector Coil Test Procedure</i>	Go to Step 6
6	Note whether the injector test light for cylinder 1 was "OFF" or "ON" steady in step 5. Was the test light "ON" steady while cranking the engine?	—	Go to Step 7	Go to Step 9
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 15
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to <i>OBD System Check</i>	—
9	1. Disconnect the injector test connector. 2. At the injector side of the harness, connect an ohmmeter between the positive wire (red with blue tracer) and the wire for cylinder 1 (green with white tracer). Does the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 10
10	Repair the open injector harness wire or open injector. Is the action complete?	—	Verify repair	—
11	At the PCM side of the injector test connector, check the green/white wire for a short to voltage. Was there a short to voltage?	—	Go to Step 12	Go to Step 13
12	Repair the short to voltage. Is the action complete?	—	Verify repair	—
13	Check for an open circuit between the injector test connector and the PCM. Was there an open circuit?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0202 Injector 2 Control Circuit



D06RW070

Circuit Description

The powertrain control module (PCM) has six individual injector driver circuits. Each controls an injector. When a driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a DTC is set. This DTC is also set if an injector driver is shorted to voltage or if there is an open circuit.

Conditions for Setting the DTC

- The battery voltage is more than 9 volts.
- The engine is turning, determined by 58X crankshaft position input signal.
- The injector voltage does not equal the ignition voltage when the injector is commanded "OFF" or the injector voltage does not equal 0 volts when the injector is commanded "ON."
- The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn "OFF" the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history DTC P0202 will clear after 40 consecutive warm-up cycles occur without a fault.
- DTC P0202 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

An injector driver circuit that is open or shorted to voltage will cause a DTC P0202 to set. It will also cause a misfire due to an inoperative injector. A misfire DTC will also be set indicating which cylinder is inoperative. Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

The number(s) below refer to the step number(s) on the Diagnostic Chart.

3. This step determines if DTC P0202 is the result of a hard failure or an intermittent condition.


5. A special injector test connector is provided so that the injectors can be electrically tested without removal of the manifold. The test connector can be identified by the blue connector lock which is tethered to the wiring harness. If the light for cylinder 2 is "ON" steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to ground.

If the test light blinks while cranking, the PCM and the wiring to the injectors are OK. Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was "ON" steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.

9. The reading should be about 12-14Ω.

10. Locating the open in the harness or in the injector will require removal of the manifold to provide access.



R321055

DTC P0202 – Injector 2 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Will the engine start?	—	Go to Step 3	Go to <i>Engine Cranks But Will Not Run</i> chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0202 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition "ON" and the engine "OFF" and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0202 reset?	—	Go to Step 5	Go to <i>Diagnostic Aids</i>

DTC P0202 – Injector 2 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
5	1. Engine "OFF." 2. Disconnect the injector test connector. 3. Install an injector test light J-39021-65 on injector test connector 4. Crank the engine and note the light. Does the cylinder 2 test light blink?	—	Go to <i>Fuel Injector Coil Test Procedure</i>	Go to <i>Step 6</i>
6	Note whether the injector test light for cylinder 2 was "OFF" or "ON" steady in step 5. Was the test light "ON" steady while cranking the engine?	—	Go to <i>Step 7</i>	Go to <i>Step 9</i>
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to <i>Step 8</i>	Go to <i>Step 15</i>
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to <i>OBD System Check</i>	—
9	1. Disconnect the injector test connector. 2. At the injector side of the harness, connect an ohmmeter between the positive wire (red with blue tracer) and the wire for cylinder 2 (green with orange tracer). Does the ohmmeter indicate continuity?	—	Go to <i>Step 11</i>	Go to <i>Step 10</i>
10	Repair the open injector harness wire or open injector. Is the action complete?	—	Verify repair	—
11	At the PCM side of the injector test connector, check the green/orange wire for a short to voltage. Was there a short to voltage?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the short to voltage. Is the action complete?	—	Verify repair	—
13	Check for an open circuit between the injector test connector and the PCM. Was there an open circuit?	—	Go to <i>Step 14</i>	Go to <i>Step 15</i>
14	Repair the open circuit. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—


5. A special injector test connector is provided so that the injectors can be electrically tested without removal of the manifold. The test connector can be identified by the blue connector lock which is tethered to the wiring harness. If the light for cylinder 3 is "ON" steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to ground.

If the test light blinks while cranking, the PCM and the wiring to the injectors are OK. The Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was "ON" steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.

9. The reading should be about 12-14Ω.

10. Locating the open in the harness or in the injector will require removal of the manifold to provide access.



R321056


DTC P0203 – Injector 3 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Will the engine start?	—	Go to Step 3	Go to <i>Engine Cranks But Will Not Run</i> chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0203 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition "ON" and the engine "OFF" and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0203 reset?	—	Go to Step 5	Go to <i>Diagnostic Aids</i>

DTC P0203 – Injector 3 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
5	1. Engine "OFF." 2. Disconnect the injector test connector . 3. Install an injector test light J-39021-65 on injector connector 4. Crank the engine and note the light. Does the cylinder 3 test light blink?	—	Go to <i>Fuel Injector Coil Test Procedure</i>	Go to Step 6
6	Note whether the injector test light for cylinder 3 was "OFF" or "ON" steady in step 5. Was the test light "ON" steady while cranking the engine?	—	Go to Step 7	Go to Step 9
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 15
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to <i>OBD System Check</i>	—
9	1. Disconnect the injector test connector. 2. At the injector side of the harness, connect an ohmmeter between the positive wire (red with blue tracer) and the wire for cylinder 3 (green). Does the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 10
10	Repair the open injector harness wire or open injector. Is the action complete?	—	Verify repair	—
11	At the PCM side of the injector test connector, check the green wire for a short to voltage. Was there a short to voltage?	—	Go to Step 12	Go to Step 13
12	Repair the short to voltage. Is the action complete?	—	Verify repair	—
13	Check for an open circuit between the injector test connector and the PCM. Was there an open circuit?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0204 Injector 4 Control Circuit



Circuit Description

The powertrain control module (PCM) has six individual injector driver circuits. Each controls an injector. When the driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a DTC is set. This DTC is also set if an injector driver is shorted to voltage or if there is an open circuit.

Conditions for Setting the DTC

- The battery voltage is more than 9 volts.
- The engine is turning, determined by the 58X crankshaft position input signal.
- The injector voltage does not equal the ignition voltage when the injector is commanded "OFF" or the injector voltage does not equal 0 volts when the injector is commanded "ON."
- The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn “OFF” the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history DTC P0204 will clear after 40 consecutive warm-up cycles occur without a fault.
- DTC P0204 can be cleared by using the Tech 2 “Clear Info” function or by disconnecting the PCM battery feed.

Diagnostic Aids

An injector driver circuit that is open or shorted to voltage will cause a DTC P0204 to set. It will also cause a misfire due to an inoperative injector. A misfire DTC will also be set indicating which cylinder is inoperative. Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

The number(s) below refer to the step number(s) on the Diagnostic Chart.

3. This step determines if DTC P0204 is the result of a hard failure or an intermittent condition.


5. A special injector test connector is provided so that the injectors can be electrically tested without removal of the manifold. The test connector can be identified by the blue connector lock which is tethered to the wiring harness. If the light for cylinder 4 is "ON" steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to ground.

If the test light blinks while cranking, the PCM and the wiring to the injectors are OK. The Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was "ON" steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.

9. The reading should be about 12-14Ω.

10. Locating the open in the harness or in the injector will require removal of the manifold to provide access.



R321057

DTC P0204 – Injector 4 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Will the engine start?	—	Go to Step 3	Go to <i>Engine Cranks But Will Not Run</i> chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0204 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition "ON" and the engine "OFF" and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0204 reset?	—	Go to Step 5	Go to <i>Diagnostic Aids</i>

DTC P0204 – Injector 4 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
5	1. Engine "OFF." 2. Disconnect the injector test connector. 3. Install an injector test light J-39021-65 on injector test connector. 4. Crank the engine and note the light. Does the cylinder 4 test light blink?	—	Go to <i>Fuel Injector Coil Test Procedure</i>	Go to Step 6
6	Note whether the injector test light was "OFF" or "ON" steady in step 5. Was the test light "ON" steady while cranking the engine?	—	Go to Step 7	Go to Step 9
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 15
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to <i>OBD System Check</i>	—
9	1. Disconnect the injector test connector. 2. At the injector side of the harness, connect an ohmmeter between the positive wire (red with blue tracer) and the wire for cylinder 4 (green/red). Does the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 10
10	Repair the open injector harness wire or open injector. Is the action complete?	—	Verify repair	—
11	At the PCM side of the injector test connector, check the green/red wire for a short to voltage. Was there a short to voltage?	—	Go to Step 12	Go to Step 13
12	Repair the short to voltage. Is the action complete?	—	Verify repair	—
13	Check for an open circuit between the injector test connector and the PCM. Was there an open circuit?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—


5. A special injector test connector is provided so that the injectors can be electrically tested without removal of the manifold. The test connector can be identified by the blue connector lock which is tethered to the wiring harness. If the light for cylinder 5 is "ON" steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to ground.

If the test light blinks while cranking, the PCM and the wiring to the injectors are OK. Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was "ON" steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.

9. The reading should be about 12-14Ω.

10. Locating the open in the harness or in the injector will require removal of the manifold to provide access.




DTC P0205 – Injector 5 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Will the engine start?	—	Go to Step 3	Go to <i>Engine Cranks But Will Not Run</i> chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0205 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition "ON" and the engine "OFF" and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0205 reset?	—	Go to Step 5	Go to <i>Diagnostic Aids</i>

DTC P0205 – Injector 5 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
5	1. Engine "OFF." 2. Disconnect the injector test connector. 3. Install an injector test light J-39021-65 on the injector test connector. 4. Crank the engine and note the light. Does the cylinder 5 test light blink?	—	Go to <i>Fuel Injector Coil Test Procedure</i>	Go to Step 6
6	Note whether the injector test light was "OFF" or "ON" steady in step 5. Was the test light "ON" steady while cranking the engine?	—	Go to Step 7	Go to Step 9
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to Step 8	Go to Step 15
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to <i>OBD System Check</i>	—
9	1. Disconnect the injector test connector. 2. At the injector side of the harness, connect an ohmmeter between the positive wire (red with blue tracer) and the wire for cylinder 5 (green with black tracer). Does the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 10
10	Repair the open injector harness wire or open injector. Is the action complete?	—	Verify repair	—
11	At the PCM side of the injector test connector, check the green/black wire for a short to voltage. Was there a short to voltage?	—	Go to Step 12	Go to Step 13
12	Repair the short to voltage. Is the action complete?	—	Verify repair	—
13	Check for an open circuit between the injector test connector and the PCM. Was there an open circuit?	—	Go to Step 14	Go to Step 15
14	Repair the open circuit. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0206 Injector 6 Control Circuit



Circuit Description

The powertrain control module (PCM) has six individual injector driver circuits. Each controls an injector. When the driver circuit is grounded by the PCM, the injector is activated. The PCM monitors the current in each driver circuit. The voltage on each driver is monitored to detect a fault. If the voltage is not what the PCM expects to monitor on the circuit, a DTC is set. This DTC is also set if an injector driver is shorted to voltage or if there is an open circuit.

Conditions for Setting the DTC

- The battery voltage is more than 9 volts.
- The engine is turning, determined by 58X crankshaft position input signal.
- The injector voltage does not equal the ignition voltage when the injector is commanded "OFF" or the injector voltage does not equal 0 volts when the injector is commanded "ON."
- The above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn “OFF” the MIL on the third consecutive trip cycle in which the diagnostic has been run and the fault is no longer present.
- A history DTC P0206 will clear after 40 consecutive warm-up cycles occur without a fault.
- DTC P0206 can be cleared by using the Tech 2 “Clear Info” function or by disconnecting the PCM battery feed.

Diagnostic Aids

An injector driver circuit that is open or shorted to voltage will cause a DTC P0206 to set. It will also cause a misfire due to an inoperative injector. A misfire DTC will also be set indicating which cylinder is inoperative. Long term and short term fuel trims that are excessively high or low are a good indication that an injector is faulty. Use Fuel Injector Coil Test Procedure to check for faulty injectors.

Test Description

The number(s) below refer to the step number(s) on the Diagnostic Chart.

3. This step determines if DTC P0206 is the result of a hard failure or an intermittent condition.


5. A special injector test connector is provided so that the injectors can be electrically tested without removal of the manifold. The test connector can be identified by the blue connector lock which is tethered to the wiring harness. If the light for cylinder 6 is "ON" steady before cranking the engine as well as while cranking the engine, then the injector driver circuit is shorted to ground.

If the test light blinks while cranking, the PCM and the wiring to the injectors are OK. The Fuel Injector Coil Test Procedure will check if the injectors are faulty.

7. Because the test light was "ON" steady, voltage to the injector is OK, but the driver circuit is grounded at all times. This step determines if the circuit is shorted to ground or the PCM is faulty.

9. The reading should be about 12-14Ω.

10. Locating the open in the harness or in the injector will require removal of the manifold to provide access.



DTC P0206 – Injector 6 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Will the engine start?	—	Go to Step 3	Go to <i>Engine Cranks But Will Not Run</i> chart
3	1. Install the Tech 2. Clear the DTC. 2. Idle the engine for one minute. Does DTC P0206 reset?	—	Go to Step 5	Go to Step 4
4	1. Review the Freeze Frame data with the ignition "ON" and the engine "OFF" and note the parameters. 2. Operate the vehicle within the Freeze Frame conditions as noted. Does P0206 reset?	—	Go to Step 5	Go to <i>Diagnostic Aids</i>

DTC P0206 – Injector 6 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
5	1. Engine "OFF." 2. Disconnect the injector test connector. 3. Install an injector test light J-39021-65 on injector test connector. 4. Crank the engine and note the light. Does the cylinder 6 test light blink?	—	Go to <i>Fuel Injector Coil Test Procedure</i>	Go to <i>Step 6</i>
6	Note whether the injector test light was "OFF" or "ON" steady in step 5. Was the test light "ON" steady while cranking the engine?	—	Go to <i>Step 7</i>	Go to <i>Step 9</i>
7	1. Disconnect the PCM connector for the affected injectors. 2. With a test light connected to B+, probe the affected injector driver circuit. Does the test light illuminate?	—	Go to <i>Step 8</i>	Go to <i>Step 15</i>
8	Repair short to ground in the injector driver circuit. Is the action complete?	—	Go to <i>OBD System Check</i>	—
9	1. Disconnect the injector test connector. 2. At the injector side of the harness, connect an ohmmeter between the positive wire (red with blue tracer) and the wire for cylinder 6 (green with yellow tracer). Does the ohmmeter indicate continuity?	—	Go to <i>Step 11</i>	Go to <i>Step 10</i>
10	Repair the open injector harness wire or open injector Is the action complete?	—	Verify repair	—
11	At the PCM side of the injector test connector, check the green/yellow wire for a short to voltage. Was there a short to voltage?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the short to voltage. Is the action complete?	—	Verify repair	—
13	Check for an open circuit between the injector test connector and the PCM. Was there an open circuit?	—	Go to <i>Step 14</i>	Go to <i>Step 15</i>
14	Repair the open circuit. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0300 Engine Misfire Detected

Circuit Description

The powertrain control module (PCM) is able to detect a misfire by monitoring the 58X reference and the camshaft position input signals. If the PCM detects crankshaft speed variations that indicate 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a true misfire condition, DTC P0300 will be set. If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following DTCs occur: TP sensor, MAF sensor, CMP sensor, VSS, ECT sensor, ABS rough road sensor, CKP sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The engine temperature sensor (ECT) indicates an engine temperature between -7°C (20°F) and 120°C (248°F).
- Throttle angle is steady and throttle changes less than 3% per 125 milliseconds.
- The PCM detects a crankshaft RPM variation indicating a misfire that is sufficient to cause catalytic converter damage or emissions levels to exceed the mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will disable the TCC operation.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0300 will clear after 40 consecutive warm-up cycles occur without a fault.
- DTC P0300 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

The Tech 2 display "Misfire Cur. #1 through #6" can be useful to determine whether the misfire is isolated to a single cylinder.

- Damaged or faulty ignition coil – Check for cracks or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.

If the misfire is random, check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- MAF – A mass air flow (MAF) sensor output that causes the PCM to sense a lower than normal air flow will cause a lean condition.
- Air induction system – Air leaks into the induction system which bypass the MAF sensor will cause a lean condition. Check for disconnected or damaged vacuum hoses, incorrectly installed or faulty PCV valve, or for vacuum leaks at the throttle body, EGR valve, and intake manifold mounting surfaces.
- Fuel pressure – Perform a fuel system pressure test. A faulty fuel pump, plugged filter, or faulty fuel system pressure regulator will contribute to a lean condition.
- Injector(s) – Perform an injector coil/balance test to locate faulty injector(s) contributing to a lean or flooding condition. In addition to the above test, check the condition of the injector O-rings.
- EGR – Check for a leaking valve, adapter, or feed pipes which will contribute to a lean condition or excessive EGR flow.
- Fuel quality – Using fuel with the wrong octane rating for the vehicle may cause driveability problems. Although alcohol-enhanced fuels may raise the octane rating, the fuel's ability to turn into vapor in cold temperatures deteriorates. This may affect the cold driveability of the engine. The Reid Vapor Pressure of the fuel can also create problems in the fuel system, especially during the spring and fall when changes by the refineries may not coincide with changes in the weather.
- Vehicle marshalling – The transportation of new vehicles from the assembly plant to the dealership can involve as many as 60 key cycles within 2 to 3 miles of driving. This type of operation contributes to the fuel fouling of the spark plugs and will turn on the MIL with a P0300 Misfire DTC.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P0300 – Engine Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record the Tech 2 Freeze Frame data. 3. Operate the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data). 4. Monitor the Tech 2 "Misfire Current Cyl #" display for each cylinder. Is "Misfire Cur. #" display increasing for any cylinder (indicating a misfire currently occurring)?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. 2. If a problem is found, repair or replace the vacuum hoses as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 4
4	1. Visually and physically inspect the following areas for vacuum leaks: <ul style="list-style-type: none"> ○ The intake manifold ○ The injector O-rings ○ The EGR adapter ○ The EGR feed pipes 2. If a problem is found, repair the vacuum leak as necessary. Did your inspection reveal a vacuum leak?	—	Verify repair	Go to Step 5
5	1. Visually and physically inspect the crankcase ventilation valve for improper installation or damaged grommet. 2. If a problem is found, repair as necessary (refer to <i>Crankcase Ventilation System</i>). Did your inspection reveal a problem?	—	Verify repair	Go to Step 6
6	1. Inspect the MAF sensor inlet screen for damage or for the presence of foreign objects that may partially block the air flow sample through the MAF sensor. 2. If a problem is found, repair or replace the MAF sensor as necessary. Did your inspection of the MAF sensor reveal a condition requiring repair or replacement?	—	Verify repair	Go to Step 7
7	1. Remove the EGR valve and visually/physically inspect the valve to ensure that the pintle is not sticking partially open. Also, inspect the EGR valve pintle and seat for carbon deposits or burrs that may interfere with the pintle closing completely. 2. If a problem is found, clean the EGR valve pintle and seat or replace the EGR valve as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 8

DTC P0300 – Engine Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Install a spark tester at the spark plug end of the ignition coil for a cylinder that indicated a misfire. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 14	Go to Step 9
9	1. Remove and visually/physically inspect the ignition coil(s) associated with the cylinders that were indicated as misfiring. Ensure that the coil(s) are free of cracks. 2. If a problem is found, replace the damaged ignition coil(s) as necessary. Did any ignition coils require replacement?	—	Verify repair	Go to Step 10
10	1. Remove the spark plugs from the cylinders that were indicated as misfiring. 2. Visually inspect the spark plug electrodes. Does your inspection reveal any spark plugs exhibiting excessive fouling?	—	Go to Engine Mechanical Diagnosis	Go to Step 11
11	1. Visually inspect the spark plug insulators for cracks, carbon tracking, or other damage. 2. If a problem is found, replace the faulty spark plug(s) as necessary. Did your inspection reveal a problem?	—	Verify repair	Go to Step 12
12	1. Disconnect the MAF sensor electrical connector. 2. Operate the vehicle in "closed loop" while monitoring the "B1 Long Term Fuel Trim" and "B1 Short Term Fuel Trim" display on the Tech 2. Do both values decrease below the specified values?	"BANK 1 L.T. FUEL TRIM" below +20%; "BANK 1 S.T. FUEL TRIM" below +50%	Go to Step 13	Replace the ignition coil of the affected cylinder
13	Replace the ignition coil. Is the action complete?	—	Verify repair	—
14	1. Visually and physically inspect the PCM injector grounds, power grounds and sensor grounds to ensure that they are clean, tight and in their proper locations. 2. If a problem is found, correct the faulty ground condition as necessary. Did your inspection reveal a poor ground?	—	Verify repair	Go to Step 15
15	1. Perform the "Fuel System Pressure Test" procedure. 2. If a problem is found, repair as necessary (refer to <i>Engine Fuel or Fuel Metering System</i>). Was a fuel system problem found?	—	Verify repair	Go to Step 16
16	1. Check the fuel for excessive water, alcohol, or other contaminants (refer to <i>Diagnosis in Engine Fuel</i> for procedure). 2. If a problem is found, correct the contaminated fuel condition as necessary. Was the fuel contaminated?	—	Verify repair	Go to Step 17

DTC P0300 – Engine Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
17	1. Perform the "Injector Coil/Balance Test." 2. If a problem is found, replace faulty injector(s) as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to <i>Step 18</i>
18	1. Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ Incorrect valve timing ○ A leaking head gasket ○ A loose or broken motor mount 2. If a problem is found, repair as necessary. Was a basic engine mechanical problem found and repaired?	—	Verify repair	Go to <i>Step 19</i>
19	1. Check for a transmission TCC problem. Refer to <i>4L30-E Automatic Transmission Diagnosis</i> . 2. If a problem is found, repair the transmission as necessary. Refer to <i>4L30-E Automatic Transmission Unit Repair</i> . Was a transmission problem found and repaired?	—	Verify repair	Go to <i>Step 20</i>
20	Replace the MAF sensor. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0301 Cylinder 1 Misfire Detected

Circuit Description

The powertrain control module (PCM) has the ability to detect a misfire by monitoring the 58X reference and the camshaft position sensor input signals. If the PCM detects a crankshaft speed variation that indicates 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a misfire, the PCM attempts to calculate which cylinder is misfiring by associating crankshaft angle (using the camshaft position sensor signal) with the RPM variation (using the 58X reference). If cylinder #1 is isolated as the misfiring cylinder, DTC P0301 will set.

If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following DTCs occur: TP sensor, MAF sensor, camshaft position sensor, vehicle speed sensor, ECT sensor, ABS rough road sensor, crankshaft position sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The ECT indicates an engine temperature between -7°C (28°F) and 120°C (248°F).
- The throttle angle is steady.
- The PCM is detecting a crankshaft RPM variation that indicates a misfire on cylinder #1 sufficient to cause three-way catalytic converter damage or emissions levels to exceed mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive ignition cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0301 will clear after 40 consecutive ignition cycles occur without a fault.
- DTC P0301 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Injector – Perform the injector coil/balance test to locate a faulty injector that contributes to a lean condition on the affected cylinder. In addition to the above test, check the condition of the injector O-ring.
- Faulty spark plug – Check for a cracked insulator, carbon tracking, incorrect gap, and worn electrodes.
- Damaged or faulty ignition coil – Check for cracks or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.

DTC P0301 — Cylinder 1 Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record Tech 2 Freeze Frame data. 3. Monitor "Misfire Cur. #1" on the Tech 2. Is "Misfire Cur. #1" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Go to Step 3
3	Monitor "Misfire Hist. #1" while operating the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data recorded in Step 2). Is "Misfire Hist. #1" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0301 — Cylinder 1 Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. Also, inspect the intake manifold for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 5
5	1. Install a spark tester at the spark plug end of the cylinder #1 ignition coil. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 8	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coil associated with cylinder #1. Ensure that the coil is free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coil as necessary. Did the visual inspection reveal a problem?	—	Verify repair	Go to Step 7
7	1. Measure the ignition coil primary resistance. 2. If resistance is not within the specified value, replace the faulty ignition coil. Did the ignition coil require replacement?	2.6 - 2.7 k Ω	Verify repair	Go to Step 12
8	Remove the cylinder #1 spark plug and visually inspect the spark plug electrode. Does the inspection reveal excessive fouling?	—	Go to Contamination Diagnosis chart in Engine Mechanical Diagnosis	Go to Step 9
9	1. Visually inspect the spark plug insulator for cracks, carbon tracking, or other damage. 2. If the spark plug is damaged, replace the spark plug. Did the inspection reveal a problem?	—	Verify repair	Go to Step 10
10	1. Perform the "Injector Coil/Balance Test." 2. If any faulty injectors are found, replace them as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 11
11	1. Inspect the injector O-rings for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 12
12	Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose and repair the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ A leaking head gasket Was a basic engine mechanical problem found?	—	Verify repair	Refer to Diagnostic Aids

Diagnostic Trouble Code (DTC) P0302 Cylinder 2 Misfire Detected

Circuit Description

The powertrain control module (PCM) has the ability to detect a misfire by monitoring the 58X reference and the camshaft position sensor input signals. If the PCM detects crankshaft speed variations that indicate 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a misfire, the PCM attempts to calculate which cylinder is misfiring by associating crankshaft angle (using the camshaft position sensor signal) with the RPM variation (using the 58X reference). If cylinder #2 is isolated as the misfiring cylinder, DTC P0302 will set.

If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following DTCs occur: TP sensor, MAF sensor, camshaft position sensor, vehicle speed sensor, ECT sensor, ABS rough road sensor, crankshaft position sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The ECT indicates an engine temperature between -7°C (28°F) and 120°C (248°F).
- The throttle angle is steady.
- The PCM is detecting a crankshaft RPM variation that indicates a misfire on cylinder #2 sufficient to cause three-way catalytic converter damage or emissions levels to exceed mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive ignition cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0302 will clear after 40 consecutive ignition cycles occur without a fault.
- DTC P0302 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Injector – Perform the injector coil/balance test to locate a faulty injector that contributes to a lean condition on the affected cylinder. In addition to the above test, check the condition of the injector O-ring.
- Faulty spark plug – Check for a cracked insulator, carbon tracking, incorrect gap, and worn electrodes.
- Damaged or faulty ignition coil – Check for cracks, carbon tracking or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.

DTC P0302 – Cylinder 2 Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record Tech 2 Freeze Frame data. 3. Monitor "Misfire Cur. #2" on the Tech 2. Is "Misfire Cur. #2" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Go to Step 3
3	Monitor "Misfire Hist. #2" while operating the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data recorded in Step 2). Is "Misfire Hist. #2" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0302 – Cylinder 2 Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. Also, inspect the intake manifold for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 5
5	1. Install a spark tester at the spark plug end of the cylinder #2 ignition coil. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 8	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coil associated with cylinder #2. Ensure that the coil is free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coil as necessary. Did the visual inspection reveal a problem?	—	Verify repair	Go to Step 7
7	1. Measure the ignition coil primary resistance. 2. If resistance is not within the specified value, replace the faulty ignition coil. Did the ignition coil require replacement?	2.6 - 2.7 k Ω	Verify repair	Go to Step 12
8	Remove the cylinder #2 spark plug and visually inspect the spark plug electrode. Does the inspection reveal excessive fouling?	—	Go to Contamination Diagnosis chart in Engine Mechanical Diagnosis	Go to Step 9
9	1. Visually inspect the spark plug insulator for cracks, carbon tracking, or other damage. 2. If the spark plug is damaged, replace the spark plug. Did the inspection reveal a problem?	—	Verify repair	Go to Step 10
10	1. Perform the "Injector Coil/Balance Test." 2. If any faulty injectors are found, replace them as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 11
11	1. Inspect the injector O-rings for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 12
12	Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose and repair the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ A leaking head gasket Was a basic engine mechanical problem found?	—	Verify repair	Refer to Diagnostic Aids

Diagnostic Trouble Code (DTC) P0303 Cylinder 3 Misfire Detected

Circuit Description

The powertrain control module (PCM) has the ability to detect a misfire by monitoring the 58X reference and the camshaft position sensor input signals. If the PCM detects a crankshaft speed variation that indicates 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a misfire, the PCM attempts to calculate which cylinder is misfiring by associating crankshaft angle (using the camshaft position sensor signal) with the RPM variation (using the 58X reference). If cylinder #3 is isolated as the misfiring cylinder, DTC P0303 will set.

If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following DTCs occur: TP sensor, MAF sensor, camshaft position sensor, vehicle speed sensor, ECT sensor, ABS rough road sensor, crankshaft position sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The ECT indicates an engine temperature between -7°C (28°F) and 120°C (248°F).
- The throttle angle is steady.
- The PCM is detecting a crankshaft RPM variation that indicates a misfire on cylinder #3 sufficient to cause three-way catalytic converter damage or emissions levels to exceed mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive ignition cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0303 will clear after 40 consecutive ignition cycles occur without a fault.
- DTC P0303 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Injector – Perform the injector coil/balance test to locate a faulty injector that contributes to a lean condition on the affected cylinder. In addition to the above test, check the condition of the injector O-ring.
- Faulty spark plug – Check for a cracked insulator, carbon tracking, incorrect gap, and worn electrodes.
- Damaged or faulty ignition coil – Check for cracks, carbon tracking or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.

DTC P0303 — Cylinder 3 Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record Tech 2 Freeze Frame data. 3. Monitor "Misfire Cur. #3" on the Tech 2. Is "Misfire Cur. #3" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Go to Step 3
3	Monitor "Misfire Hist. #3" while operating the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data recorded in Step 2). Is "Misfire Hist. #3" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0303 — Cylinder 3 Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. Also, inspect the intake manifold for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 5
5	1. Install a spark tester at the spark plug end of the cylinder #3 ignition coil. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 8	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coil associated with cylinder #3. Ensure that the coil is free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coil as necessary. Did the visual inspection reveal a problem?	—	Verify repair	Go to Step 7
7	1. Measure the ignition coil primary resistance. 2. If resistance is not within the specified value, replace the faulty ignition coil. Did the ignition coil require replacement?	2.6 - 2.7 k Ω	Verify repair	Go to Step 12
8	Remove the cylinder #3 spark plug and visually inspect the spark plug electrode. Does the inspection reveal excessive fouling?	—	Go to Contamination Diagnosis chart in Engine Mechanical Diagnosis	Go to Step 9
9	1. Visually inspect the spark plug insulator for cracks, carbon tracking, or other damage. 2. If the spark plug is damaged, replace the spark plug. Did the inspection reveal a problem?	—	Verify repair	Go to Step 10
10	1. Perform the "Injector Coil/Balance Test." 2. If any faulty injectors are found, replace them as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 11
11	1. Inspect the injector O-rings for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 12
12	Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose and repair the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ A leaking head gasket Was a basic engine mechanical problem found?	—	Verify repair	Refer to Diagnostic Aids

Diagnostic Trouble Code (DTC) P0304 Cylinder 4 Misfire Detected

Circuit Description

The powertrain control module (PCM) has the ability to detect a misfire by monitoring the 58X reference and the camshaft position sensor input signals. If the PCM detects a crankshaft speed variation that indicates 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a misfire, the PCM attempts to calculate which cylinder is misfiring by associating crankshaft angle (using the camshaft position sensor signal) with the RPM variation (using the 58X reference). If cylinder #4 is isolated as the misfiring cylinder, DTC P0304 will set.

If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following DTCs occur: TP sensor, MAF sensor, camshaft position sensor, vehicle speed sensor, ECT sensor, ABS rough road sensor, crankshaft position sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The ECT indicates an engine temperature between -7°C (28°F) and 120°C (248°F).
- The throttle angle is steady.
- The PCM is detecting a crankshaft RPM variation that indicates a misfire on cylinder #4 sufficient to cause three-way catalytic converter damage or emissions levels to exceed mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive ignition cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0304 will clear after 40 consecutive ignition cycles occur without a fault.
- DTC P0304 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Injector – Perform the injector coil/balance test to locate a faulty injector that contributes to a lean condition on the affected cylinder. In addition to the above test, check the condition of the injector O-ring.
- Faulty spark plug – Check for a cracked insulator, carbon tracking, incorrect gap, and worn electrodes.
- Damaged or faulty ignition coil – Check for cracks, carbon tracking or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.

DTC P0304 – Cylinder 4 Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record Tech 2 Freeze Frame data. 3. Monitor "Misfire Cur. #4" on the Tech 2. Is "Misfire Cur. #4" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Go to Step 3
3	Monitor "Misfire Hist. #4" while operating the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data recorded in Step 2). Is "Misfire Hist. #4" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0304 – Cylinder 4 Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. Also, inspect the intake manifold for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 5
5	1. Install a spark tester at the spark plug end of the cylinder #4 ignition wire. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 8	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coil associated with cylinder #4. Ensure that the coil is free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coil as necessary. Did the visual inspection reveal a problem?	—	Verify repair	Go to Step 7
7	1. Measure the ignition coil primary resistance. 2. If resistance is not within the specified value, replace the faulty ignition coil. Did the ignition coil require replacement?	2.6 - 2.7 kΩ	Verify repair	Go to Step 12
8	Remove the cylinder #4 spark plug and visually inspect the spark plug electrode. Does the inspection reveal excessive fouling?	—	Go to Contamination Diagnosis chart in Engine Mechanical Diagnosis	Go to Step 9
9	1. Visually inspect the spark plug insulator for cracks, carbon tracking, or other damage. 2. If the spark plug is damaged, replace the spark plug. Did the inspection reveal a problem?	—	Verify repair	Go to Step 10
10	1. Perform the "Injector Coil/Balance Test." 2. If any faulty injectors are found, replace them as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 11
11	1. Inspect the injector O-rings for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 12
12	Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose and repair the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ A leaking head gasket Was a basic engine mechanical problem found?	—	Verify repair	Refer to Diagnostic Aids

Diagnostic Trouble Code (DTC) P0305 Cylinder 5 Misfire Detected

Circuit Description

The powertrain control module (PCM) has the ability to detect a misfire by monitoring the 58X reference and the camshaft position sensor input signals. If the PCM detects a crankshaft speed variation that indicates 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a misfire, the PCM attempts to calculate which cylinder is misfiring by associating crankshaft angle (using the camshaft position sensor signal) with the RPM variation (using the 58X reference). If cylinder #5 is isolated as the misfiring cylinder, DTC P0305 will set.

If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following DTCs occur: TP sensor, MAF sensor, camshaft position sensor, vehicle speed sensor, ECT sensor, ABS rough road sensor, crankshaft position sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The ECT indicates an engine temperature between -7°C (28°F) and 120°C (248°F).
- The throttle angle is steady.
- The PCM is detecting a crankshaft RPM variation that indicates a misfire on cylinder #5 sufficient to cause three-way catalytic converter damage or emissions levels to exceed mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive ignition cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0305 will clear after 40 consecutive ignition cycles occur without a fault.
- DTC P0305 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Injector – Perform the injector coil/balance test to locate a faulty injector that contributes to a lean condition on the affected cylinder. In addition to the above test, check the condition of the injector O-ring.
- Faulty spark plug – Check for a cracked insulator, carbon tracking, incorrect gap, and worn electrodes.
- Damaged or faulty ignition coil – Check for cracks, carbon tracking or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.

DTC P0305 - Cylinder 5 Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record Tech 2 Freeze Frame data. 3. Monitor "Misfire Cur. #5" on the Tech 2. Is "Misfire Cur. #5" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Go to Step 3
3	Monitor "Misfire Hist. #5" while operating the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data recorded in Step 2). Is "Misfire Hist. #5" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0305 - Cylinder 5 Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. Also, inspect the intake manifold for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 5
5	1. Install a spark tester at the spark plug end of the cylinder #5 ignition wire. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 8	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coil associated with cylinder #5. Ensure that the coil is free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coil as necessary. Did the visual inspection reveal a problem?	—	Verify repair	Go to Step 7
7	1. Measure the ignition coil primary resistance. 2. If resistance is not within the specified value, replace the faulty ignition coil. Did the ignition coil require replacement?	2.6 - 2.7 k Ω	Verify repair	Go to Step 12
8	Remove the cylinder #5 spark plug and visually inspect the spark plug electrode. Does the inspection reveal excessive fouling?	—	Go to Contamination Diagnosis chart in Engine Mechanical Diagnosis	Go to Step 9
9	1. Visually inspect the spark plug insulator for cracks, carbon tracking, or other damage. 2. If the spark plug is damaged, replace the spark plug. Did the inspection reveal a problem?	—	Verify repair	Go to Step 10
10	1. Perform the "Injector Coil/Balance Test." 2. If any faulty injectors are found, replace them as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 11
11	1. Inspect the injector O-rings for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 12
12	Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose and repair the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ A leaking head gasket Was a basic engine mechanical problem found?	—	Verify repair	Refer to Diagnostic Aids

Diagnostic Trouble Code (DTC) P0306 Cylinder 6 Misfire Detected

Circuit Description

The powertrain control module (PCM) has the ability to detect a misfire by monitoring the 58X reference and the camshaft position sensor input signals. If the PCM detects a crankshaft speed variation that indicates 1% or more of cylinder firing events are misfires, the PCM will disable the torque converter clutch (TCC). If the RPM variation detected indicates a misfire, the PCM attempts to calculate which cylinder is misfiring by associating crankshaft angle (using the camshaft position sensor signal) with the RPM variation (using the 58X reference). If cylinder #6 is isolated as the misfiring cylinder, DTC P0306 will set.

If the ABS Rough Road sensor input signal to the PCM determines that a rough road condition is present, the misfire diagnostic will be temporarily disabled.

Conditions for Setting the DTC

- None of the following occur: TP sensor, MAF sensor, camshaft position sensor, vehicle speed sensor, ECT sensor, ABS rough road sensor, crankshaft position sensor.
- The engine speed is between 600 and 6250 RPM.
- The system voltage is between 11 and 16 volts.
- The ECT indicates an engine temperature between -7°C (28°F) and 120°C (248°F).
- The throttle angle is steady.
- The PCM is detecting a crankshaft RPM variation that indicates a misfire on cylinder #6 sufficient to cause three-way catalytic converter damage or emissions levels to exceed mandated standard.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- If the misfire is severe enough to cause possible catalyst damage, the PCM will flash the MIL for as long as the misfire remains at catalyst damaging levels.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive ignition cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0306 will clear after 40 consecutive ignition cycles occur without a fault.
- DTC P0306 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- System grounds – Ensure all connections are clean and properly tightened.
- Injector – Perform the injector coil/balance test to locate a faulty injector that contributes to a lean condition on the affected cylinder. In addition to the above test, check the condition of the injector O-ring.
- Faulty spark plug – Check for a cracked insulator, carbon tracking, incorrect gap, and worn electrodes.
- Damaged or faulty ignition coil – Check for cracks or other damage.
- Substitute a known good coil – Swap the ignition coils and retest. If the misfire follows the coil, replace the ignition coil.


DTC P0306 – Cylinder 6 Misfire Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Start the engine. Run the engine at idle. 2. Review and record Tech 2 Freeze Frame data. 3. Monitor "Misfire Cur. #6" on the Tech 2. Is "Misfire Cur. #6" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Go to Step 3
3	Monitor "Misfire Hist. #6" while operating the vehicle to duplicate the conditions present when the DTC was set (as defined by the Freeze Frame data recorded in Step 2). Is "Misfire Hist. #6" increasing (indicating a misfire currently occurring)?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>

DTC P0306 – Cylinder 6 Misfire Detected (Cont'd)

Step	Action	Value(s)	Yes	No
4	1. Visually and physically inspect the vacuum hoses for splits, kinks, and improper connections. Also, inspect the intake manifold for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 5
5	1. Install a spark tester at the spark plug end of the cylinder #6 ignition wire. 2. Crank the engine while observing the spark tester. A crisp, blue spark should be observed. Is adequate spark present?	—	Go to Step 8	Go to Step 6
6	1. Remove and visually/physically inspect the ignition coil associated with cylinder #6. Ensure that the coil is free of cracks and carbon tracking. 2. If a problem is found, replace the damaged ignition coil as necessary. Did the visual inspection reveal a problem?	—	Verify repair	Go to Step 7
7	1. Measure the ignition coil primary resistance. 2. If resistance is not within the specified value, replace the faulty ignition coil. Did the ignition coil require replacement?	2.6 - 2.7 k Ω	Verify repair	Go to Step 12
8	Remove the cylinder #6 spark plug and visually inspect the spark plug electrode. Does the inspection reveal excessive fouling?	—	Go to Contamination Diagnosis chart in Engine Mechanical Diagnosis	Go to Step 9
9	1. Visually inspect the spark plug insulator for cracks, carbon tracking, or other damage. 2. If the spark plug is damaged, replace the spark plug. Did the inspection reveal a problem?	—	Verify repair	Go to Step 10
10	1. Perform the "Injector Coil/Balance Test." 2. If any faulty injectors are found, replace them as necessary. Did any of the injectors require replacement?	—	Verify repair	Go to Step 11
11	1. Inspect the intake manifold and the injector O-rings for a vacuum leak. 2. If a problem is found, repair it as necessary. Did the inspection reveal a problem?	—	Verify repair	Go to Step 12
12	Check for an engine mechanical problem. Refer to <i>Engine Mechanical Diagnosis</i> to diagnose and repair the following conditions: <ul style="list-style-type: none"> ○ A faulty or incorrect camshaft ○ Leaking or sticky valves or rings ○ Excessive valve deposits ○ Loose or worn rocker arms ○ Weak valve springs ○ A leaking head gasket Was a basic engine mechanical problem found?	—	Verify repair	Refer to Diagnostic Aids

Diagnostic Trouble Code (DTC) P0325 KS Module Circuit



D06RW035-1

Circuit Description

The knock sensor is used to detect engine detonation, allowing the powertrain control module (PCM) to retard ignition control (IC) spark timing based on the knock sensor (KS) signal being received. The knock sensor produces an AC signal so that under a no knock condition the signal on the KS circuit measures about 0.007 V AC. The KS signal's amplitude and frequency depend upon the amount of knock being experienced. The PCM contains a non-replaceable knock filter module called a signal-to-noise enhancement filter (SNEF) module. This filter module in the PCM determines whether knock is occurring by comparing the signal level on the KS circuit with the voltage level on the noise channel. The noise channel allows the PCM to reject any false knock signal by knowing the amount of normal engine mechanical noise present. Normal engine noise varies depending on engine speed and load. When the PCM determines that an abnormally low noise channel voltage level is being experienced, a DTC P0325 will set.

Conditions for Setting the DTC

- Engine has been running for at least 30 seconds.
- The PCM determines that its internal signal from its knock filter module indicates a continuous knocking condition for more than 10 seconds.

Action Taken When the DTC Sets

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

- The PCM will use a "substitute" default spark retard value of 6 degrees to minimize knock during conditions when knock is likely to occur.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0325 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0325 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the knock sensor and PCM connectors for backed-out terminals, broken locks, and improperly formed or damaged terminals.
- Misrouted harness – Inspect the knock sensor harness to ensure that it is not routed too close to high voltage circuits such as spark plug coils.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Ensures that the fault is present.

DTC P0325 – KS Module Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	<p>IMPORTANT: If an engine knock can be heard, repair the engine mechanical problem before proceeding with this diagnostic.</p> <p>1. Operate the vehicle within parameters specified under criteria included in "Conditions for Setting the DTC."</p> <p>2. Using a Tech 2, monitor "DTC" info for DTC P0325 until the DTC P0325 test runs.</p> <p>3. Note the test result.</p> <p>Does the Tech 2 indicate DTC P0325 failed this ignition?</p>	—	Go to Step 4	Go to Step 3
3	<p>1. Ignition "ON," engine "OFF."</p> <p>2. Review and record Tech 2 Failure Records data for DTC P0325.</p> <p>3. Operate the vehicle within Failure Records conditions.</p> <p>4. Using a Tech 2, monitor "DTC" info for DTC P0325 until the DTC P0325 test runs.</p> <p>Does the Tech 2 indicate DTC P0325 test failed this ignition?</p>	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0327 KS Sensor Circuit



Circuit Description

The powertrain control module (PCM) uses the knock sensor to detect engine detonation, allowing the PCM to retard ignition control (IC) spark timing based on the knock sensor (KS) signal being received. The knock sensor produces an AC signal so that under a no knock condition the signal on the KS circuit measures about 0.007 V AC. The signal amplitude and frequency are dependent upon the amount of knock being experienced. The PCM monitors the KS signal and can diagnose the KS sensor and circuitry.

Conditions for Setting the DTC

- Engine running time is at least 10 seconds.
- The TP sensor is greater than 5%.
- The ECT sensor is greater than 60°C (140°F).
- Engine speed is between 2000 and 4000 RPM.
- The knock sensor signal voltage is less than 0.20 volts, or greater than 4.8 volts.
- All conditions are present for more than 15 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

- The PCM will use a calculated spark retard value to minimize knock during conditions when knock is likely to occur. The calculated value will vary based on engine speed and load.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0327 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0327 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Ensures that the fault is present.


DTC P0327 – KS Sensor Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	IMPORTANT: If an engine knock can be heard, repair the engine mechanical problem before proceeding with this diagnostic. 1. Operate the engine within the conditions specified in diagnostic support "Conditions for Setting the DTC." 2. Using a Tech 2, monitor "DTC" info for DTC P0327 until the DTC P0327 test runs. 3. Note the test result. Does the Tech 2 indicate DTC P0327 failed this ignition?	—	Go to Step 4	Go to Step 3
3	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions. 4. Using a Tech 2, monitor "DTC" info for DTC P0327 until the DTC P0327 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0327 failed this ignition?	—	Go to Step 4	Refer to <i>Diagnostic Aids</i>
4	Using a test light to battery +, check the black/blue wire (PCM side) to verify that the shield connection is good. Did the test light illuminate?	—	Go to Step 6	Go to Step 5
5	Repair the open shield ground. Is the action complete?	—	Verify repair	—
6	1. Ignition "OFF," disconnect the PCM. 2. Check the KS signal circuit for a poor terminal connection at the PCM. 3. If a problem is found, replace the faulty terminal. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Ignition "OFF," PCM disconnected. 2. Check the KS signal circuit between the PCM and the knock sensor connector for an open, a short to voltage, or a short to ground. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Ignition "OFF," PCM disconnected. 2. Knock sensor connected. 3. Measure the resistance of the knock sensor by connecting the DVM between the PCM connector and the engine block. Is the resistance of the knock sensor near the specified value?	100K ohms	Go to Step 9	Go to Step 10

DTC P0327 – KS Sensor Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
9	<p>1. Ignition "OFF," PCM disconnected.</p> <p>2. Connect the DVM to monitor AC voltage between the PCM connector and engine ground.</p> <p>3. Tap on the engine lift bracket with a socket extension while observing the signal indicated on the DVM.</p> <p>Is any signal indicated on the DVM while tapping on the engine lift bracket?</p>	—	Go to <i>Step 11</i>	Go to <i>Step 10</i>
10	<p>Replace the knock sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—
11	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0336 58X Reference Signal Circuit



D06RX017

Circuit Description

The 58X reference signal is produced by the crankshaft position (CKP) sensor. During one crankshaft revolution, 58 crankshaft pulses will be produced. The powertrain control module (PCM) uses the 58X reference signal to calculate engine RPM and crankshaft position. The PCM constantly monitors the number of pulses on the 58X reference circuit and compares them to the number of camshaft position (CMP) signal pulses being received. If the PCM receives an incorrect number of pulses on the 58X reference circuit, DTC P0336 will set.

Conditions for Setting the DTC

- Engine is running.
- Extra or missing pulse is detected between consecutive 58X reference pulses.
- Above condition is detected in 10 of 100 crankshaft rotations.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0336 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0336 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for:


- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition on and observe a voltmeter connected to the 58X reference circuit at the PCM harness connector while moving connectors and wiring harnesses related to the ICM. A change in voltage will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P0336 – 58X Reference Signal Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Attempt to start the engine. Does the engine start?	—	Go to Step 3	Go to <i>"Engine Cranks But Will Not Run"</i> chart
3	1. Review and record Failure Records information. 2. Clear DTC P0336. 3. Start the engine and idle for 1 minute. 4. Observe DTCs. Is DTC P0336 set?	—	Go to Step 4	Refer to Diagnostic Aids
4	1. Disconnect the PCM and CKP sensor. 2. Check for an open or a short to ground in the 58X reference circuit between the CKP sensor connector and the PCM harness connector. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Reconnect the PCM and CKP sensor. 2. Connect a DVM to measure voltage on the 58X reference circuit at the PCM connector. 3. Observe the voltage while cranking the engine. Is the voltage near the specified value?	2.5 V	Go to Step 8	Go to Step 6
6	Check the connections at the CKP sensor and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 7
7	Replace the CKP sensor. Use caution to avoid any hot oil that may drip out. Is the action complete?	—	Verify repair	—
8	Check connections at the PCM and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to Step 10
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0337 CKP Sensor Circuit Low Frequency



D06RX017

Circuit Description

The 58X reference signal is produced by the crankshaft position (CKP) sensor. During one crankshaft revolution, 58 crankshaft reference pulses will be produced. The powertrain control module (PCM) uses the 58X reference signal to calculate engine RPM and crankshaft position. The PCM constantly monitors the number of pulses on the 58X reference circuit and compares them to the number of camshaft position (CMP) signal pulses being received. If the PCM does not receive pulses on the 58X reference circuit, DTC P0337 will set.

Conditions for Setting the DTC

- No camshaft position (CMP) sensor DTCs are set.
- Engine cranking.
- Crankshaft position (CKP) sensor signal is not present between two cam pulses.

- CKP reference pulse is not detected within 8 CMP pulses.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0337 will clear after 40 consecutive warm-up cycles have occurred without a fault.

6E2-276 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- DTC P0337 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for:

- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition on and observe a voltmeter connected to the 58X reference circuit at the PCM harness connector while moving connectors and wiring harnesses related to the ICM. A change in voltage will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0337 – CKP Sensor Circuit Low Frequency

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Attempt to start the engine. Does the engine start?	—	Go to Step 3	Go to <i>Chart 3</i>
3	1. Review and record Failure Records information. 2. Clear DTC P0337. 3. Start the engine and idle for 1 minute. 4. Observe DTCs. Is DTC P0337 set?	—	Go to Step 4	Refer to <i>Diagnostic Aid</i>
4	1. Disconnect the CKP sensor. 2. Ignition "ON." 3. Using a DVM, verify that 5 V reference and ground are being supplied at the sensor connector (PCM side). Are 4-6 volts and ground available at the sensor?	—	Go to Step 7	Go to Step 5
5	1. Ignition "ON." 2. With a DVM, backprobe the PCM connector 5 V reference and ground connections. Are 5 V reference and ground available at the PCM?	—	Go to Step 6	Go to Step 11
6	Check 5 V reference or ground between the CKP sensor and PCM and repair the open circuit, short to ground or short to voltage. Is the action complete?	—	Verify repair	—
7	1. Ignition "OFF." 2. Disconnect the PCM and CKP sensor. 3. Check for an open or a short to ground in the 58X reference circuit between the CKP sensor connector and the PCM harness connector. 4. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Reconnect the PCM and CKP sensor. 2. Connect a DVM to measure voltage on the 58X reference circuit at the PCM connector. 3. Observe the voltage while cranking the engine. Is the voltage near the specified value?	2.5 V	Go to Step 11	Go to Step 9

DTC P0337 – CKP Sensor Circuit Low Frequency (Cont'd)

Step	Action	Value(s)	Yes	No
9	Check the connections at the CKP sensor and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to <i>Step 10</i>
10	Replace the CKP sensor. Use caution and avoid hot oil that may drip out. Is the action complete?	—	Verify repair	—
11	Check the connections at the PCM and replace the terminals if necessary. Did any terminals require replacement?	—	Verify repair	Go to <i>Step 12</i>
12	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0341 CMP Sensor Circuit Performance



D06RX017

Circuit Description

The CMP signal is produced by the camshaft position (CMP) sensor pulses when the engine is running and crankshaft position (CKP) sync pulses are also being received. The powertrain control module (PCM) uses the CMP signal pulses to initiate sequential fuel injection. The PCM constantly monitors the number of pulses on the CMP signal circuit and compares the number of CMP pulses to the number of 58X reference pulses received. If the PCM receives an incorrect number of pulses on the CMP reference circuit, DTC P0341 will set and the PCM will initiate injector sequence without the CMP signal with a one in six chance that injector sequence is correct. The engine will continue to start and run normally, although the misfire diagnostic will be affected if a misfiring condition occurs.

Conditions for Setting the DTC

- The engine is running (1X CMP reference pulses are being received).
- The CMP sensor signal is not detected at the correct interval every 6 cylinders.
- Above condition fails for 100 occurrences within 200 test samples.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will initiate the injector sequence without the CMP signal with a one in six chance that the injector sequence is correct.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0341 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0341 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for:

- Poor connection — Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness — Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition on and observe a voltmeter connected to the CMP signal circuit at the PCM harness connector while moving connectors and wiring harnesses related to the ICM and the CMP sensor. A change in voltage will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

NOTE: On early-built Troopers, the Tech 2 indication for "CMP ACT. COUNTER" (Cam Position Sensor activity) will continue to count up, even if no cam position signal is being received by the PCM. This problem can be corrected by reprogramming the PCM with the latest EEPROM program.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Ensures that the fault is present.

12. Determines whether the fault is being caused by a missing camshaft magnet or a faulty sensor. The voltage measured in this step should read around 4 volts, toggling to near 0 volts when the CMP sensor interfaces with the camshaft magnet.


DTC P0341 —CMP Sensor Circuit Performance

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" info for DTC P0341 until the DTC P0341 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0341 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Disconnect the CMP sensor. 2. Measure the voltage between the sensor feed circuit and the sensor ground circuit at the CMP sensor harness connector. Does the voltage measure near the specified value?	4-6 V	Go to Step 4	Go to Step 5
4	Measure the voltage between the CMP sensor signal circuit and the sensor ground circuit at the CMP sensor harness connector. Does the voltage measure near the specified value?	4-6 V	Go to Step 11	Go to Step 8
5	If the voltage measured in step 3 was less than 4-6 volts, proceed directly to step 6 without completing this step. If the voltage in step 3 was greater than 4-6 V, repair the short to voltage in the CMP feed circuit. Is the action complete?	—	Verify repair	—
6	1. Check for poor connections at the camshaft position sensor. 2. If a problem is found, repair it as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Ignition "OFF," disconnect the PCM and the CMP sensor. 2. Check the following circuits for an open between the ignition control module and the CMP sensor: ○ The sensor feed circuit. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
8	1. Ignition "OFF," disconnect the PCM (leave the CMP sensor disconnected). 2. Ignition "ON," check the following circuits: ○ The CMP sensor signal circuit for an open or a short to voltage. ○ The CMP sensor input signal circuit for a short to ground. 3. If a problem is found, repair it as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	Check for a short or open in the sensor ground circuit. Was a problem found?	—	Verify repair	Go to Step 10

DTC P0341 —CMP Sensor Circuit Performance (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Check for poor connections at the PCM. 2. If a problem is found, repair it as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	Backprobe the PCM connector with a DVM to monitor voltage on the camshaft position input signal circuit while cranking the engine with the sensor connected. (Use rubber band, tape, or an assistant to keep the DVM lead in contact with the sensor terminal during this test.) Does the voltage toggle between the specified values?	4-0 V	Go to Step 15	Go to Step 12
12	1. Remove the CMP sensor. 2. Place a magnet on the CMP sensor. (If you use a magnet that is too small to cover the face of the sensor, test on every part of the sensor face because only a small area will respond to this test.) Does the DVM display a voltage near the specified value?	—	Go to Step 13	Go to Step 14
13	Replace the faulty or missing camshaft position sensor magnet. Is the action complete?	—	Verify repair	—
14	Replace the camshaft position sensor. Is the action complete?	—	Verify repair	—
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0342 CMP Sensor Circuit Low



D06RX017

Circuit Description

The CMP signal produced by the camshaft position (CMP) sensor pulses when the engine is running and crankshaft position (CKP) sync pulses are also being received. The hall type CMP sensor and the CKP sensor share 5 V and ground connections at the powertrain control module (PCM). The third wire at the sensor is a signal circuit to the PCM. The PCM uses the CMP signal pulses to initiate sequential fuel injection. The PCM constantly monitors the number of pulses on the CMP signal circuit and compares the number of CMP pulses to the number of 58X reference pulses received. If the PCM does not receive pulses on the CMP reference circuit, DTC P0342 will set and the PCM will initiate injector sequence without the CMP signal with a one in six chance that injector sequence is correct. The engine will continue to start and run normally, although the misfire diagnostic will be affected if a misfiring condition occurs.

Conditions for Setting the DTC

- The engine is running.
- The CMP sensor signal is not received by the PCM once every 6 cylinders.
- The above condition occurs for 10 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will initiate injector sequence without the CMP signal with a one in six chance that the injector sequence is correct.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0342 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0342 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

An intermittent may be caused by a poor connection, rubbed-through wire insulation or a wire broken inside the insulation. Check for:

- Poor connection – Inspect the PCM harness and connectors for improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition on and observe a voltmeter connected to the CMP signal circuit at the PCM harness connector while moving connectors and wiring harnesses related to the ICM and the CMP sensor. A change in voltage will indicate the location of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Ensures that the fault is present.

14. Determines whether the fault is being caused by a damaged camshaft or a faulty PCM. The voltage measured in this step should read around 4 volts, toggling to near 0 volts when the CMP sensor interfaces with the camshaft magnet.

DTC P0342 —CMP Sensor Circuit Low

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Records conditions as noted. 4. Using a Tech 2, monitor "DTC" information for DTC P0342 until the DTC P0342 test runs. 5. Note test result. Does the Tech 2 indicate DTC P0342 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Ignition "ON." 2. Disconnect the CMP sensor. 3. Measure the voltage between the sensor feed circuit and the sensor ground circuit at the CMP sensor harness connector. Does the voltage measure near the specified value?	4-6 V	Go to Step 7	Go to Step 4
4	1. Ignition "OFF," disconnect the PCM and the CMP sensor. 2. Check for poor connections at the camshaft position sensor. 3. If a problem is found, repair it as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Check for poor connections at the PCM. 2. If a problem is found, repair it as necessary. Was a problem found?	—	Verify repair	Go to Step 6


DTC P0342 —CMP Sensor Circuit Low (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Check the following circuits between the PCM and the CMP sensor: <ul style="list-style-type: none"> ○ The sensor feed circuit. Open or short to ground? ○ The sensor ground circuit. Open or short to voltage? 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	—
7	1. Ignition "ON," engine "OFF." 2. Measure the voltage between the CMP sensor signal circuit and the sensor ground circuit at the CMP sensor harness connector. Does the voltage measure near the specified value?	4-6 V	Go to Step 8	Go to Step 9
8	1. Turn the ignition "OFF." 2. Disconnect the PCM and connect a DVM to monitor voltage on the camshaft position signal circuit at the PCM connector. 3. Ignition "ON." 4. Monitor the voltage display on the DVM while repeatedly touching the CMP sensor signal circuit at the CMP sensor connector with a test light to ground. Does the DVM voltage display switch between 0 and approximately 5 volts when the test light is touched to the CMP sensor signal circuit?	—	Go to Step 12	Go to Step 9
9	1. Ignition "OFF." 2. Leave the PCM disconnected. 3. Ignition "ON." 4. Probe the camshaft position signal circuit at the PCM connector with a test light to B+. 5. If the test light is "ON," locate and repair the short to ground in the camshaft position input signal circuit. Was either circuit shorted to ground?	—	Verify repair	Go to Step 10
10	1. Ignition "OFF." 2. Leave the PCM disconnected. 3. Ignition "ON." 4. Probe the camshaft position signal circuit with a test light to ground. 5. If the test light is "ON," locate and repair the short to voltage in the camshaft position input signal circuit. Was the test light "ON"?	—	Verify repair	Go to Step 11
11	1. Ignition "OFF," disconnect the PCM (leave the CMP sensor disconnected). 2. Ignition "ON," check the following circuit: <ul style="list-style-type: none"> ○ The CMP sensor signal circuit for an open. 3. If a problem is found, repair it as necessary. Was a problem found?	—	Verify repair	—

DTC P0342 —CMP Sensor Circuit Low (Cont'd)

Step	Action	Value(s)	Yes	No
12	<p>1. Ignition "ON."</p> <p>2. Remove the CMP sensor.</p> <p>3. Place a magnet on the CMP sensor. If you use a magnet that is too small to cover the face of the sensor, test on every part of the sensor face because only a small area will respond to this test.</p> <p>Does the DVM display a voltage near the specified value?</p>	0 V	Go to <i>Step 14</i>	Go to <i>Step 13</i>
13	<p>Replace the camshaft position sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—
14	<p>Replace the PCM.</p> <p>NOTE: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0351 Ignition 1 Control Circuit



D06RX018

Circuit Description

The powertrain control module's (PCM) control circuit 1 provides a zero-volt or a 5-volt output signal to the ignition coil. The normal voltage on the circuit is zero volts. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the number 1 ignition coil. When the PCM shuts off the 5 volts to the ignition coil, the ignition coil turns "OFF." This causes the ignition coil primary magnetic field to collapse, producing a voltage in the secondary coil which fires the spark plug.

The circuit between the PCM and ignition coil is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem on ignition control circuit 1, it will set a DTC P0351.

Conditions for Setting the DTC

- The ignition is "ON."
- The engine is turning, determined by the 58X crankshaft position input signal.

- The output voltage is not equal to 5 volts when output is "ON."
- The output voltage is not equal to 0 volts when output is "OFF."
- Twenty test failures occur within 40 samples of continuous spark events.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0351 will clear after 40 consecutive warm-up cycles occur without a fault.

- DTC P0351 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0351 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0351 – Ignition 1 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Record conditions as noted. 4. Use a Tech 2 to monitor the "DTC" information for DTC P0351 until the DTC P0351 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0351 failed this ignition cycle?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	Check for faulty connection at ignition coil. Was a problem found?	—	Verify repair	Go to Step 4
4	Check for faulty connection at PCM connector. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Ignition "ON," engine "OFF." 2. Back probe the ignition control circuit 1 at the PCM with a DVM. Is the voltage near the specified value?	25-55 mV	Go to Step 6	Go to Step 9
6	1. Ignition "ON," engine running. 2. Back probe the ignition control circuit at the PCM for the cylinder being tested. Is the voltage in the specified range, rapidly toggling back and forth to a reading 20-50 mV higher?	100-180 mV	Go to Step 7	Go to Step 13
7	1. Ignition "OFF." 2. Disconnect the 3-pin connector at the ignition coil. 3. Check ignition control circuit 1 voltage at the ignition coil connector while cranking the engine. Does the voltage measure between the specified values?	200-1200 mV	Go to Step 8	Go to Step 11
8	Replace the ignition coil. Is the action complete?	—	Verify repair	—
9	1. Ignition "OFF." 2. Disconnect the PCM and the ignition coil. 3. Check ignition control circuit 1 for short to ground. Was a problem found?	—	Verify repair	Go to Step 10
10	Check ignition control circuit 1 for short to voltage. Was a problem found?	—	Verify repair	Go to Step 13

DTC P0351 – Ignition 1 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check for an open ignition control circuit 1. Was the ignition control circuit open?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the open ignition control circuit. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0352 Ignition 2 Control Circuit



D06RW072

Circuit Description

The powertrain control module's (PCM) control circuit 2 provides a zero-volt or a 5-volt output signal to the ignition coil. The normal voltage on the circuit is zero volts. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the number 2 ignition coil. When the PCM shuts off the 5 volts to the ignition coil, the ignition coil turns "OFF." This causes the ignition coil primary magnetic field to collapse, producing a voltage in the secondary coil which fires the spark plug.

The circuit between the PCM and ignition coil is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem on ignition control circuit 2, it will set a DTC P0352.

Conditions for Setting the DTC

- The ignition is "ON."
- The engine is turning, determined by the 58 X crankshaft position input signal.

- The output voltage is not equal to 5 volts when output is "ON."
- The output voltage is not equal to 0 volts when output is "OFF."
- Twenty test failures occur within 40 samples of continuous spark events.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0352 will clear after 40 consecutive warm-up cycles occur without a fault.

6E2-290 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- DTC P0352 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0352 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0352 – Ignition 2 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Record conditions as noted. 4. Use a Tech 2 to monitor the "DTC" information for DTC P0352 until the DTC P0352 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0352 failed this ignition cycle?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	Check for faulty connection at ignition coil. Was a problem found?	—	Verify repair	Go to Step 4
4	Check for faulty connection at PCM connector. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Ignition "ON," engine "OFF." 2. Back probe the ignition control circuit 2 at the PCM with a DVM . Is the voltage near the specified value?	25-55 mV	Go to Step 6	Go to Step 9
6	1. Ignition "ON," engine running. 2. Back probe the ignition control circuit at the PCM for the cylinder being tested. Is the voltage in the specified range, rapidly toggling back and forth to a reading 20-50 mV higher?	100-180 mV	Go to Step 7	Go to Step 13
7	1. Ignition "OFF." 2. Disconnect the 3-pin connector at the ignition coil. 3. Check ignition control circuit 2 voltage at the ignition coil connector while cranking the engine connector. Does the voltage measure between the specified values?	200-1200 mV	Go to Step 8	Go to Step 11
8	Replace the ignition coil. Is the action complete?	—	Verify repair	—
9	1. Ignition "OFF." 2. Disconnect the PCM and the ignition coil. 3. Check ignition control circuit 2 for short to ground. Was a problem found?	—	Verify repair	Go to Step 10
10	Check ignition control circuit 2 for short to voltage. Was a problem found?	—	Verify repair	Go to Step 13

DTC P0352 – Ignition 2 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check for an open ignition control circuit 2. Was the ignition control circuit open?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the open ignition control circuit. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0353 Ignition 3 Control Circuit



D06RX018

Circuit Description

The powertrain control module's (PCM) control circuit 3 provides a zero-volt or a 5-volt output signal to the ignition coil. The normal voltage on the circuit is zero volts. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the number 3 ignition coil. When the PCM shuts off the 5 volts to the ignition coil, the ignition coil turns "OFF." This causes the ignition coil primary magnetic field to collapse, producing a voltage in the secondary coil which fires the spark plug.

The circuit between the PCM and ignition coil is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem on ignition control circuit 3, it will set a DTC P0353.

Conditions for Setting the DTC

- The ignition is "ON."
- The engine is turning, determined by the 58X crankshaft position input signal.

- The output voltage is not equal to 5 volts when output is "ON."
- The output voltage is not equal to 0 volts when output is "OFF."
- Twenty test failures occur within 40 samples of continuous spark events.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0353 will clear after 40 consecutive warm-up cycles occur without a fault.

- DTC P0353 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0353 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0353 – Ignition 3 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Record conditions as noted. 4. Use a Tech 2 to monitor the "DTC" information for DTC P0353 until the DTC P0353 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0353 failed this ignition cycle?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	Check for faulty connection at ignition coil. Was a problem found?	—	Verify repair	Go to Step 4
4	Check for faulty connection at PCM connector. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Ignition "ON," engine "OFF." 2. Back probe the ignition control circuit 3 at the PCM with a DVM. Is the voltage near the specified value?	25-55 mV	Go to Step 6	Go to Step 9
6	1. Ignition "ON," engine running. 2. Back probe the ignition control circuit at the PCM for the cylinder being tested. Is the voltage in the specified range, rapidly toggling back and forth to a reading 20-50 mV higher?	100-180 mV	Go to Step 7	Go to Step 13
7	1. Ignition "OFF." 2. Disconnect the 3-pin connector at the ignition coil. 3. Check ignition control circuit 3 voltage at the ignition coil connector while cranking the engine. Does the voltage measure between the specified values?	200-1200 mV	Go to Step 8	Go to Step 11
8	Replace the ignition coil. Is the action complete?	—	Verify repair	—
9	1. Ignition "OFF." 2. Disconnect the PCM and the ignition coil. 3. Check ignition control circuit 3 for short to ground. Was a problem found?	—	Verify repair	Go to Step 10
10	Check ignition control circuit 3 for short to voltage. Was a problem found?	—	Verify repair	Go to Step 13

DTC P0353 – Ignition 3 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check for an open ignition control circuit 3. Was the ignition control circuit open?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the open ignition control circuit. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0354 Ignition 4 Control Circuit



D06RX018

Circuit Description

The powertrain control module's (PCM) control circuit 4 provides a zero-volt or a 5-volt output signal to the ignition coil. The normal voltage on the circuit is zero volts. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the number 4 ignition coil. When the PCM shuts off the 5 volts to the ignition coil, the ignition coil turns "OFF." This causes the ignition coil primary magnetic field to collapse, producing a voltage in the secondary coil which fires the spark plug.

The circuit between the PCM and ignition coil is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem on ignition control circuit 4, it will set a DTC P0354.

Conditions for Setting the DTC

- The ignition is "ON."
- The engine is turning, determined by the 58X crankshaft position input signal.

- The output voltage is not equal to 5 volts when output is "ON."
- The output voltage is not equal to 0 volts when output is "OFF."
- Twenty test failures occur within 40 samples of continuous spark events.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0354 will clear after 40 consecutive warm-up cycles occur without a fault.

- DTC P0354 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0354 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0354 – Ignition 4 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Record conditions as noted. 4. Use a Tech 2 to monitor the "DTC" information for DTC P0354 until the DTC P0354 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0354 failed this ignition cycle?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	Check for faulty connection at ignition coil. Was a problem found?	—	Verify repair	Go to Step 4
4	Check for faulty connection at PCM connector. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Ignition "ON," engine "OFF." 2. Back probe the ignition control circuit 4 at the PCM with a DVM. Is the voltage near the specified value?	25-55 mV	Go to Step 6	Go to Step 9
6	1. Ignition "ON," engine running. 2. Back probe the ignition control circuit at the PCM for the cylinder being tested. Is the voltage in the specified range, rapidly toggling back and forth to a reading 20-50 mV higher?	100-180 mV	Go to Step 7	Go to Step 13
7	1. Ignition "OFF." 2. Disconnect the 3-pin connector at the ignition coil. 3. Check ignition control circuit 4 voltage at the ignition coil connector while cranking the engine. Does the voltage measure between the specified values?	200-1200 mV	Go to Step 8	Go to Step 11
8	Replace the ignition coil. Is the action complete?	—	Verify repair	—
9	1. Ignition "OFF." 2. Disconnect the PCM and the ignition coil. 3. Check ignition control circuit 4 for short to ground. Was a problem found?	—	Verify repair	Go to Step 10
10	Check ignition control circuit 4 for short to voltage. Was a problem found?	—	Verify repair	Go to Step 13

DTC P0354 – Ignition 4 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check for an open ignition control circuit 4. Was the ignition control circuit open?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the open in ignition control circuit. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0355 Ignition 5 Control Circuit



D06RX018

Circuit Description

The powertrain control module's (PCM) control circuit 5 provides a zero-volt or a 5-volt output signal to the ignition coil. The normal voltage on the circuit is zero volts. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the number 5 ignition coil. When the PCM shuts off the 5 volts to the ignition coil, the ignition coil turns "OFF." This causes the ignition coil primary magnetic field to collapse, producing a voltage in the secondary coil which fires the spark plug.

The circuit between the PCM and ignition coil is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem on ignition control circuit 5, it will set a DTC P0355.

Conditions for Setting the DTC

- The ignition is "ON."
- The engine is turning, determined by the 58X crankshaft position input signal.

- The output voltage is not equal to 5 volts when output is "ON."
- The output voltage is not equal to 0 volts when output is "OFF."
- Twenty test failures occur within 40 samples of continuous spark events.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0355 will clear after 40 consecutive warm-up cycles occur without a fault.

- DTC P0355 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0355 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0355 – Ignition 5 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Record conditions as noted. 4. Use a Tech 2 to monitor the "DTC" information for DTC P0355 until the DTC P0355 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0355 failed this ignition cycle?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	Check for faulty connection at ignition coil. Was a problem found?	—	Verify repair	Go to Step 4
4	Check for faulty connection at PCM connector. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Ignition "ON," engine "OFF." 2. Back probe the ignition control circuit 5 at the PCM with a DVM. Is the voltage near the specified value?	25-55 mV	Go to Step 6	Go to Step 9
6	1. Ignition "ON," engine running. 2. Back probe the ignition control circuit at the PCM for the cylinder being tested. Is the voltage in the specified range, rapidly toggling back and forth to a reading 20-50 mV higher?	100-180 mV	Go to Step 7	Go to Step 13
7	1. Ignition "OFF." 2. Disconnect the 3-pin connector at the ignition coil. 3. Check ignition control circuit 5 voltage at the ignition coil connector while cranking the engine. Does the voltage measure between the specified values?	200-1200 mV	Go to Step 8	Go to Step 11
8	Replace the ignition coil. Is the action complete?	—	Verify repair	—
9	1. Ignition "OFF." 2. Disconnect the PCM and the ignition coil. 3. Check ignition control circuit 5 for short to ground. Was a problem found?	—	Verify repair	Go to Step 10
10	Check ignition control circuit 5 for short to voltage. Was a problem found?	—	Verify repair	Go to Step 13

DTC P0355 – Ignition 5 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check for an open ignition control circuit 5. Was the ignition control circuit open?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the open ignition control circuit. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0356 Ignition 6 Control Circuit



D06RX018

Circuit Description

The powertrain control module's (PCM) control circuit 6 provides a zero-volt or a 5-volt output signal to the ignition coil. The normal voltage on the circuit is zero volts. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the number 6 ignition coil. When the PCM shuts off the 5 volts to the ignition coil, the ignition coil turns "OFF." This causes the ignition coil primary magnetic field to collapse, producing a voltage in the secondary coil which fires the spark plug.

The circuit between the PCM and ignition coil is monitored for an open circuit, short to voltage, and short to ground. When the PCM detects a problem on ignition control circuit 6, it will set a DTC P0356.

Conditions for Setting the DTC

- The ignition is "ON."
- The engine is turning, determined by the 58X crankshaft position input signal.

- The output voltage is not equal to 5 volts when output is "ON."
- The output voltage is not equal to 0 volts when output is "OFF."
- Twenty test failures occur within 40 samples of continuous spark events.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle in which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0356 will clear after 40 consecutive warm-up cycles occur without a fault.

6E2-302 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- DTC P0356 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connections.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Tech 2 display related to DTC P0356 while moving the connector and wiring related to the ignition system. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0356 – Ignition 6 Control Circuit

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF." 2. Review and record Tech 2 Failure Records data. 3. Operate the vehicle within Failure Record conditions as noted. 4. Use a Tech 2 to monitor the "DTC" information for DTC P0356 until the DTC P0356 test runs. 5. Note the test result. Does the Tech 2 indicate DTC P0356 failed this ignition cycle?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	Check for faulty connection at ignition coil. Was a problem found?	—	Verify repair	Go to Step 4
4	Check for faulty connection at PCM connector. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Ignition "ON," engine "OFF." 2. Back probe the ignition control circuit 6 at the PCM with a DVM. Is the voltage near the specified value?	25-55 mV	Go to Step 6	Go to Step 9
6	1. Ignition "ON," engine running. 2. Back probe the ignition control circuit at the PCM for the cylinder being tested. Is the voltage in the specified range, rapidly toggling back and forth to a reading 20-50 mV higher?	100-180 mV	Go to Step 7	Go to Step 13
7	1. Ignition "OFF." 2. Disconnect the 3-pin connector at the ignition coil. 3. Check ignition control circuit 6 voltage at the ignition coil connector while cranking the engine. Does the voltage measure between the specified values?	200-1200 mV	Go to Step 8	Go to Step 11
8	Replace the ignition coil. Is the action complete?	—	Verify repair	—
9	1. Ignition "OFF." 2. Disconnect the PCM and the ignition coil. 3. Check ignition control circuit 6 for short to ground. Was a problem found?	—	Verify repair	Go to Step 10
10	Check ignition control circuit 6 for short to voltage. Was a problem found?	—	Verify repair	Go to Step 13

DTC P0356 – Ignition 6 Control Circuit (Cont'd)

Step	Action	Value(s)	Yes	No
11	Check for an open ignition control circuit 6. Was the ignition control circuit open?	—	Go to <i>Step 12</i>	Go to <i>Step 13</i>
12	Repair the open ignition control circuit. Is the action complete?	—	Verify repair	—
13	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0401 EGR Flow Insufficient



D06RW055

Circuit Description

The powertrain control module (PCM) tests the exhaust gas recirculation (EGR) system during deceleration by momentarily commanding the EGR valve to open while monitoring the manifold absolute pressure (MAP) sensor signal. When the EGR valve is opened, the PCM monitors the change in MAP input signal. The PCM compares the MAP change to a RPM vs. BARO table. When the PCM interprets the change in MAP to be out of limits, the PCM will set DTC P0401. The number of test samples required to accomplish this may vary according to the severity of the detected flow error.

Normally, the PCM will only allow one EGR flow test sample to be taken during an ignition cycle. To aid in verifying a repair, the PCM allows twelve test samples during the first ignition cycle following a Tech 2 "Clear Info" or a battery disconnect. Between nine and twelve samples should be sufficient for the PCM to determine adequate EGR flow and pass the EGR test.

Conditions for Setting the DTC

- No TP sensor, vehicle speed sensor (VSS), misfire, IAC, IAT sensor, MAP sensor, EGR Pintle Position sensor, ECT sensor, misfire, or automatic transmission DTCs set.
- Barometric pressure is above 75 kPa.
- Engine coolant temperature is greater than 60°C (140°F).
- Ignition voltage between 11.5 and 16 volts.

- Vehicle speed is greater than 24 km/h (15 mph).
- IAC position is steady, changing less than 10 counts.

- A/C clutch status is unchanged.
- TCC status is unchanged.

Start Test

- TP angle is less than 1%.
- EGR duty cycle is less than 1%.
- MAP is steady, changing less than 2 kPa.
- Engine speed is between 1100 RPM and 2000 RPM.
- MAP between 10 kPa and 40 kPa.

The test will be aborted if the vehicle speed changes by more than 16 km/h (10 mph), engine speed changes by more than 100 RPM or the EGR is opened less than 95% of commanded position.

- The PCM will only run the EGR test during a closed throttle condition.
- The PCM will only run the EGR test at vehicle speeds above 24 km/h (15 mph).
- Several deceleration cycles will be necessary to run a sufficient number of EGR flow tests.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the Actual EGR Position display on the Tech 2 while moving connectors and wiring harnesses

related to the EGR valve. A change in the display will indicate the location of the fault.

- Ensure EGR valve is correctly mounted. See *On-Vehicle Service*.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

NOTE: If the EGR valve shows signs of excessive heat, check the exhaust system for blockage (possibly a plugged catalytic converter) using the "Restricted Exhaust System Check."

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart

3. A malfunctioning MAP sensor can set an EGR DTC. The MAP sensor could send a constant signal which is not low enough to set a low MAP DTC. The constant signal from the MAP sensor also may not be high enough to set a high MAP DTC. This step verifies that the MAP sensor is responding.

DTC P0401 – EGR Flow Insufficient

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Is DTC P1406 also set?	—	Go to <i>DTC 1406</i>	Go to Step 3
3	1. Start the engine. 2. Monitor the MAP signal with a Tech 2 while idling. 3. While idling, jab the accelerator pedal about halfway down and immediately let the engine return to idle. Did the MAP value on the Tech 2 show an immediate large change?	—	Go to Step 5	Go to Step 4
4	Replace the MAP sensor. Is the action complete?	—	Verify repair	—
5	1. Inspect the exhaust system for modification of original installed parts or leaks. 2. If a problem was found, repair exhaust system as necessary. Was a condition present that required repair?	—	Go to Step 8	Go to Step 6
6	1. Remove the EGR valve. 2. Visually and physically inspect the pintle, valve passages and the adapter for excessive deposits or any kind of a restriction. 3. If a problem is found, clean or replace EGR system components as necessary. Was a condition present that required repair?	—	Go to Step 8	Go to Step 7
7	1. Remove the EGR inlet and outlet pipes from the exhaust manifold and the intake manifold. 2. Inspect the manifold EGR ports and the EGR inlet and outlet pipes for a blockage caused by excessive deposits or other damage. 3. If a problem is found, correct the condition as necessary. Was a condition present that required repair?	—	Go to Step 8	Refer to <i>Diagnostic Aids</i>
8	1. Review and record the Tech 2 Failure Records data. 2. Clear DTC and monitor the Tech 2 System Info Screen while operating the vehicle as specified in "Diagnostic Aids." 3. Using a Tech 2, monitor "DTC" info for DTC P0401 until the DTC P0401 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P0401 failed this ignition?	—	Go to <i>Diagnostic Aids</i>	Repair complete

Diagnostic Trouble Code (DTC) P0402 EGR Pintle Crank Error



Circuit Description

The powertrain control module (PCM) monitors the EGR valve pintle position input to ensure that the valve responds properly to commands from the PCM, and to detect a fault if pintle position is stuck open. If the PCM detects a pintle position signal indicates more than 21.5% and more than for 625 msec during cranking, the PCM will set DTC P0402.

Conditions for Setting the DTC

- Ignition voltage is between 11 and 16 volts.
- Intake Air temp is more than 3°C
- At Engine revolution less than 600 RPM, EGR pintle position indicates more than 21.5% and more than for 625 msec.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL “OFF” on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history DTC P0402 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0402 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:


- Foreign material on EGR valve between pintle and seat may cause EGR stuck open. Inspect foreign material in EGR valve.
- Excessive carbon deposit may cause unsmooth operation of EGR valve shaft. Inspect carbon deposit and clean up inside of carbon deposit.
- Poor connection or damaged harness—inspect the wiring harness for damage. If the harness appears to be OK, observe the EGR actual position display on the Tech 2 while moving connectors and wiring harnesses related to EGR valve. A change in the display will indicate the location of the fault.

NOTE: If the EGR valve shows signs of excessive heat, check the exhaust system for blockage (possibly a plugged catalytic converter) using the “Restricted Exhaust System Check”.

DTC P0402 – EGR Pintle Crank Open Error

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON", engine "OFF", review and record Tech 2 Failure Records data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P0402 until the DTC P0402 test runs. Note the result. Does the Tech 2 indicates DTC P0402 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Disconnect the EGR valve harness connector. 2. Inspect the EGR valve and connectors for damaged pin or terminals. Were there any damaged pins or terminals?	—	Go to Step 4	Go to Step 5
4	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
5	1. Remove EGR valve from Engine. 2. Inspect EGR valve whether there is any foreign material between seat and pintle. Was any foreign material in EGR valve?	—	Go to Step 6	Go to Step 7
6	1. Remove EGR valve foreign material from EGR valve and clean up inside. 2. Visually inspect damage of pintle and seat, which leakage may occur. Was there any severe damage which affects function?	—	Go to Step 7	Verify repair Go to Step 8
7	1. Reconnect. 2. Ignition "OFF". 3. Install the Tech 2. 4. Run the engine at idle. 5. On Tech-II, select special function for EGR. 6. Use the "UP" arrow to increase the EGR from 0% to 40%. Did EGR work properly?	—	—	Go to Step 8
8	Replace the EGR valve. Does DTC P0402 still fail "DTC" test on the Tech 2?	—	Go to Step 9	Verify repair
9	Replace the EGR valve. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0404 EGR Open Stuck



D06RW055

Circuit Description

The powertrain control module (PCM) monitors the EGR valve pintle position input to ensure that the valve responds properly to commands from the PCM, and to detect a fault if pintle position is different from commanded position. If the PCM detects a pintle position signal indicates more than 15 points different between current and commanded and more than 15 seconds, the PCM will set DTC P0404.

Conditions for Setting the DTC

- Ignition voltage is between 11 and 16 volts.
- Intake Air temp is more than 3°C.
- Desire EGR position is more than 0.
- The difference between desired EGR and current EGR is less than 3%.
- Difference EGR pintle position between current and commanded position becomes more than 15% and last more than 15 seconds, and this condition meets three times in a trip. Then it trigger, the PCM lights on.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) as soon as failure detected after consecutive 2nd trip in which the fault is detected.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0404 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0404 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids


Check for the following conditions:

- Excessive carbon deposit on EGR valve shaft may cause EGR stuck open or unsmooth operation. Those carbon deposit may occur by unusual port operation. Clean up carbon may make smooth function of EGR valve.
- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the EGR actual position display on the Tech 2 while moving connectors and wiring harnesses related to EGR valve. A change in the display will indicate the location of the fault.

DTC P0404 – EGR Open Stuck

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P0404 until the DTC P0404 test runs. Note the result. Does the Tech 2 indicates DTC P0404 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Disconnect the EGR valve harness connector. 2. Inspect the EGR valve and connectors for damaged pin or terminals. Were there any damaged pins or terminals?	—	Go to Step 4	Go to Step 5
4	Repair the damaged pin or terminal.	—	Verify repair	Is the action complete?
5	1. Remove EGR valve from Engine. 2. Inspect EGR valve whether there is any excessive carbon deposit on EGR shaft. Was excessive carbon deposit on EGR valve shaft?	—	Go to Step 6	Go to Step 7
6	1. Clean up EGR valve shaft and inside of EGR valve. 2. Visually inspect damage of pintle and seat if is bent, leakage may occur. Was there any severe damage which affects function?	—	Go to Step 8	Verify repair Go to Step 7
7	1. Reconnect. 2. Ignition "OFF". 3. Install the Tech 2. 4. Run the engine at idle. 5. On the Tech 2, select EGR control test. 6. Use the "UP" arrow to increase the EGR from 0% to 40%. Did EGR work properly?	—	—	Go to Step 8
8	Replace the EGR valve. Does DTC P0404 still fail "DTC" test on the Tech 2?	—	Go to Step 9	Verify repair
9	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0405 EGR Low Voltage



Circuit Description

The powertrain control module (PCM) monitors the EGR valve pintle position input to ensure that the valve responds properly to command from the PCM. If current pintle position voltage indicates less than 0.1 V and last more than 10 seconds, then the PCM will set DTC P0405.

Conditions for Setting the DTC

- Ignition voltage is between 11 and 16 volts.
- EGR pintle position output voltage is less than 0.1 volt and last more than 10 sec. Action taken when the DTC sets.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) as soon as failure detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL “OFF” on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0402 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0405 can be cleared by using the Tech 2 “Clear Info” function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the EGR actual position display on the Tech 2 while moving connectors and wiring harnesses related to EGR valve. A change in the display will indicate the location of the fault.


DTC P0405 – EGR Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P0405 until the DTC P0405 test runs. Note the result. Does the Tech 2 indicates DTC P0405 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Disconnect the EGR valve harness connector. 2. Inspect the EGR valve and connectors for damaged pin or terminals. Were there any damaged pins or terminals?	—	Go to Step 4	Go to Step 5
4	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
5	1. Disconnect the EGR harness connector. 2. Ignition "ON". 3. At the EGR valve, use a DVM to check the voltage at the 5 volt reference wire (RED) and ground (B). Did the DVM indicate the specified value?	4–6 V	Go to Step 6	Go to Step 7
6	1. Disconnect the EGR harness connector. 2. Measure resistance between terminal B and D. Was resistance in range?	5–5.5 K Ω	Go to Step 10	Go to Step 17
7	1. Ignition "ON". 2. At the PCM connector, backprobe with a DVM at the 5 volt reference for the EGR valve. Did the DVM indicate the specified value?	4–6 V	Go to Step 8	Go to Step 18
8	Repair the open 5 volt reference circuit. Is the action complete?	—	Verify repair	—
9	Repair the damaged sensor ground wire. Is the action complete?	—	Verify repair	—
10	1. Disconnect the EGR harness 2. Use an ohmmeter to measure between the pintle position pin and the sensor ground pin on the EGR valve. NOTE: J-35616 Connector Test Adapter Kit may be useful for gaining access to the recessed pins on the valve. Was the ohmmeter reading approximately equal to the specified value?	1 to 1.25 K Ω	Go to Step 13	Go to Step 17
11	1. Ignition "ON". 2. Backprobe with a DVM to measure voltage at EGR valve pintle position pin and sensor ground pin. Was voltage in range?	Less than 0.1 V	Go to Step 17	Go to Step 12

DTC P0405 – EGR Low Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
12	1. Ignition "ON". 2. Backprobe with a DVM to measure voltage at PCM sensor ground pin and pintle position pin. Was voltage in range?	Less than 0.1 V	Go to Step 13	Go to Step 18
13	1. Ignition "OFF". 2. Disconnect the EGR harness. 3. Check short circuit between EGR pintle position circuit and EGR ground circuit. Was any short circuit?	—	Go to Step 14	Go to Step 18
14	Locate and repair the short to ground in the pintle position circuit Is the action complete?	—	Verify repair	—
15	1. Ignition "OFF". 2. Disconnect the PCM. 3. Ignition "ON". 4. Measure the voltage between the EGR pintle position circuit and ground. Is the measured voltage near the specified value?	Less than 0.1 V	Go to Step 17	Go to Step 16
16	Check for a short circuit between other wires and the pintle position circuit Is there any short circuit?	—	Repair short circuit Verify repair	Go to Step 17
17	Replace the EGR valve. Does DTC P1404 still fail "DTC test on the Tech 2?"	—	Go to Step 18	Verify repair
18	Examine the PCM pin and terminal connection. Was there a damaged terminal?	—	Go to Step 4	Go to Step 19
19	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0406 EGR High Voltage



D06RW055

Circuit Description

The powertrain control module (PCM) monitors the EGR valve pintle position input to ensure that the valve responds properly to command from the PCM. If current pintle position voltage indicates more than 4.8 V and last more than 10 seconds, then the PCM will set DTC P0406.

Conditions for Setting the DTC

- Ignition voltage is between 11 and 16 volts.
- EGR pintle position output voltage is more than 4.8 volt and last more than 10 sec.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) as soon as failure detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0402 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0404 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection or damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the EGR actual position display on the Tech 2 while moving connectors and wiring harnesses related to EGR valve. A change in the display will indicate the location of the fault.


DTC P0406 – EGR High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P0406 until the DTC P0406 test runs. Note the result. Does the Tech 2 indicates DTC P0406 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Disconnect the EGR valve harness connector. 2. Inspect the EGR valve and connectors for damaged pin or terminals. Were there any damaged pins or terminals?	—	Go to Step 4	Go to Step 5
4	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	Is the action complete?
5	1. Disconnect the EGR harness connector. 2. Ignition "ON". 3. At the EGR valve, use a DVM to check the voltage at the 5 volt reference wire (RED). Did the DVM indicate the specified value?	4–6 V	Go to Step 8	Go to Step 6
6	1. Ignition "ON". 2. At the PCM connector, backprobe with a DVM at the 5 volt reference for the EGR valve. Did the DVM indicate the specified value?	4–6 V	Go to Step 7	Go to Step 16
7	Repair the open 5 volt reference circuit Is the action complete?	—	Verify repair	—
8	1. Ignition "OFF" 2. Disconnect the EGR harness. 3. Use a DVM to check for an resistance between D (5 V reference) and B (Sensor Ground) at EGR sensor terminals. NOTE: J-35616 Connector Test Adapter Kit may be useful for gaining access to the recessed pins on the valve. Was the measured resistance in range?	5 to 5 K Ω	Go to Step 9	Go to Step 15
9	1. Ignition "OFF". 2. Disconnect the EGR harness. 3. Use a DVM to check for an resistance between B and C at EGR sensor terminal. Is there an open circuit?	—	Go to Step 15	Go to Step 10
10	1. Ignition "OFF". 2. Disconnect the EGR harness at PCM connector. 3. Use a DVM to check for shorted wire between A1 and B7. Is there a shorted wire?	—	Go to Step 14	Go to Step 11

DTC P0406 – EGR High Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
11	1. Ignition "ON". 2. Use a DVM to backprove at terminal C of EGR valve for voltage. Was measured voltage more than 4.8 V?	more than 4.8 V	Go to Step 12	Go to Step 12
12	1. Ignition "ON". 2. Stay the EGR harness connected. 3. Check voltage by backproving at PCM B7 terminal. Was voltage more than 4.8 V?	4.8 V	Go to Step 16	Go to Step 13
13	1. Locate short circuit at EGR harness between RED to RED or GREEN, RED to YEL. 2. Replace EGR harness. Is the action complete?	—	Verify repair	—
14	Replace EGR harness. Is the action complete?	—	Verify repair	—
15	Replace the EGR valve. Does DTC P1404 still fail "DTC test on the Tech 2?"	—	Go to Step 16	Verify repair
16	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0420 TWC System Low Efficiency Bank 1



T321075

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalyst (TWC) is used. The catalyst promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 1 HO₂S 1 and the Bank 1 HO₂S 2 heated oxygen sensors. The Bank 1 HO₂S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 1 HO₂S 1 signal will be far more active than that produced by the Bank 1 HO₂S 2 sensor. If the PCM detects a level of Bank 1 HO₂S 2 activity that indicates the catalyst is no longer operating efficiently, DTC P0420 will be set.

Conditions for Setting the DTC

- No related DTCs.
- The engine is operating in "closed loop."
- Engine air load is below 99%.
- Engine coolant temperature is above 60°C (140°F).
- Mass air flow is between 8 g/second and 50 g/second.
- Change in engine load is below 8%.
- Engine speed is below 3500 RPM.
- Vehicle speed is between 26 km/h and 123 km/h (16 mph and 75 mph).
- Catalyst temperature is above 399°C (750°F).
- The PCM determines that the catalyst's oxygen storage capacity is below the acceptable threshold.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0420 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0420 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

- Bank 1 HO₂S 1/Bank 1 HO₂S 2 Activity Test:

- Ensure that the engine is fully warmed up.
- Using a Tech 2, monitor Bank 1 HO₂S 1 and Bank 1 HO₂S 2 displays in "Park" while using the Tech 2 IAC RPM control function to maintain a mass air flow of 10 g/second. Compare the amount of activity (frequency and amplitude) on Bank 1 HO₂S 1 to the activity on Bank 1 HO₂S 2 over a 30 second period.

If the amount of activity on Bank 1 HO₂S 2 is nearly as great as the activity on Bank 1 HO₂S 1, a problem exists. Use the DTC P0420 diagnostic chart. If much less activity is noted on Bank 1 HO₂S 2, the system is functioning properly.

The "TWC Monitor Test Counter" displayed on the Tech 2 may be used to monitor the progress of the TWC diagnostic. To complete the TWC diagnostic with a good catalyst, the counter must be allowed to increment to 49 samples and roll over to 0 at least twice. A failed catalyst will require three or more 50-sample tests to report a failure.

Test Description


Number(s) below refer to the step number(s) on the Diagnostic Chart.

7. Difficulty completing the DTC P0420 "Status This Ign." test may be encountered in areas where test conditions cannot be maintained easily, especially in urban areas. To minimize the amount of driving required to complete the DTC P0420 "Status This Ign." test, use the following procedure:
 - Allow the engine to warm completely.
 - With the vehicle in "Park," monitor mass air flow on the Tech 2 and hold part throttle to maintain a reading of over 12 g/second for at least 2 minutes. This will achieve the "warm catalyst" required for running the test.
 - Operate the vehicle in second or third gear to remain in the DTC P0420 test conditions described in "Conditions for Setting the DTC" as much as possible. If you must stop the vehicle, maintain the "warm catalyst" criteria as follows:
 - Place the vehicle in "Park" or "Neutral."
 - Hold part throttle to maintain a mass air flow reading of over 15 g/second for the duration of the stop.

DTC P0420 –TWC System Low Efficiency Bank 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any other DTCs set (such as P0140, P0146)?	—	Diagnose other DTC(s) first	Go to Step 3
3	<p>1. Visually and physically inspect the three-way catalytic converter for damage. Check for the following:</p> <ul style="list-style-type: none"> <input type="radio"/> dents <input type="radio"/> severe discoloration caused by excessive temperatures <input type="radio"/> holes <input type="radio"/> internal rattle caused by damaged catalyst <p>2. Also, ensure that the three-way catalytic converter is a proper original equipment manufacturer part.</p> <p>Did your inspection reveal a problem?</p>	—	Go to Step 6	Go to Step 4
4	<p>1. Visually and physically inspect the exhaust system between the three-way catalytic converter and the rear converter flange for leaks, damage, and loose or missing hardware.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Did your inspection reveal a problem?</p>	—	Go to Step 7 to verify repair	Go to Step 5
5	<p>1. Visually and physically inspect the Bank 1 HO2S 2.</p> <p>2. Ensure that the Bank 1 HO2S 2 is secure and that the pigtail and wiring harness is not contacting the exhaust pipe or is not otherwise damaged.</p> <p>3. If a problem is found, repair as necessary.</p> <p>Did your inspection reveal a problem?</p>	—	Go to Step 7 to verify repair	Go to Step 6
6	<p>Replace the three-way catalytic converter.</p> <p>NOTE: Check for conditions which may cause catalyst damage (refer to <i>Diagnostic Aids</i>).</p> <p>Is the action complete?</p>	—	Go to Step 7 to verify repair	—
7	<p>1. Review and record the Tech 2 Failure Records data.</p> <p>2. Clear DTC P0420.</p> <p>3. Start the engine and allow it to warm up until the engine coolant temperature monitored on the Tech 2 is above the specified value.</p> <p>4. Run the engine to maintain the specified mass air flow range for at least 2 minutes.</p> <p>5. Operate the vehicle to maintain DTC P0420 test conditions (refer to <i>DTC Test Description</i> in <i>Diagnostic Support</i> for detailed instructions).</p> <p>6. Using a Tech 2, monitor "DTC" info for DTC P0420 until the DTC P0420 test runs.</p> <p>7. Note the test result.</p> <p>Does the Tech 2 indicate DTC P0420 passed this ignition?</p>	<p>Engine coolant temp: greater than 60°C (140°F).</p> <p>Mass air flow: between 8 g/second and 50 g/second</p>	Repair complete. If a driveability symptom still exists, refer to <i>Symptoms</i> .	Go to the Diagnostic Aids.

Diagnostic Trouble Code (DTC) P0430 TWC System Low Efficiency Bank 2



T321075

Circuit Description

To control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NO_x), a three-way catalyst (TWC) is used. The catalyst promotes a chemical reaction which oxidizes the HC and CO present in the exhaust gas, converting them into harmless water vapor and carbon dioxide. The catalyst also reduces NO_x, converting it to nitrogen. The powertrain control module (PCM) has the ability to monitor this process using the Bank 2 HO₂S 1 and the Bank 2 HO₂S 2 heated oxygen sensors. The Bank 2 HO₂S 1 sensor produces an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 2 HO₂S 2 sensor produces an output signal which indicates the oxygen storage capacity of the catalyst; this in turn indicates the catalyst's ability to convert exhaust gases efficiently. If the catalyst is operating efficiently, the Bank 2 HO₂S 1 signal will be far more active than that produced by the Bank 2 HO₂S 2 sensor. If the PCM detects a level of Bank 2 HO₂S 2 activity that indicates the catalyst is no longer operating efficiently, DTC P0430 will be set.

Conditions for Setting the DTC

- No related DTCs.
- The engine is operating in "closed loop."
- Engine air load is below 99%.
- Engine coolant temperature is above 60°C (140°F).
- Mass air flow is between 8 g/second and 50 g/second.
- Change in engine load is below 8%.
- Engine speed is below 3500 RPM.
- Vehicle speed is between 26 km/h and 123 km/h (16 mph and 75 mph).
- Catalyst temperature is above 399°C (750°F).
- The PCM determines that the catalyst's oxygen storage capacity is below the acceptable threshold.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.

- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0430 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0430 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

- Bank 2 HO₂S 1/Bank 2 HO₂S 2 Activity Test:

- Ensure that the engine is fully warmed up.
- Using a Tech 2, monitor Bank 2 HO₂S 1 and Bank 2 HO₂S 2 displays in "Park" while using the Tech 2 IAC RPM control function to maintain a mass air flow of 10 g/second. Compare the amount of activity (frequency and amplitude) on Bank 2 HO₂S 1 to the activity on Bank 2 HO₂S 2 over a 30 second period.

If the amount of activity on Bank 2 HO₂S 2 is nearly as great as the activity on Bank 2 HO₂S 1, a problem exists. Use the DTC P0430 diagnostic chart. If much less activity is noted on Bank 2 HO₂S 2, the system is functioning properly.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.


7. Difficulty completing the DTC P0430 "Status This Ign." test may be encountered in areas where test conditions cannot be maintained easily, especially in urban areas. To minimize the amount of driving required to complete the DTC P0430 "Status This Ign." test, use the following procedure:
 - Allow the engine to warm completely.
 - With the vehicle in "Park," monitor mass air flow on the Tech 2 and hold part throttle to maintain a reading of over 12 g/second for at least 2 minutes. This will achieve the "warm catalyst" required for running the test.
 - Operate the vehicle in second or third gear to remain in the DTC P0430 test conditions described in "Conditions for Setting the DTC" as much as possible. If you must stop the vehicle, maintain the "warm catalyst" criteria as follows:
 - Place the vehicle in "Park" or "Neutral."
 - Hold part throttle to maintain a mass air flow reading of over 15 g/second for the duration of the stop.

The "TWC Monitor Test Counter" displayed on the Tech 2 may be used to monitor the progress of the TWC diagnostic. To complete the TWC diagnostic with a good catalyst, the counter must be allowed to increment to 49 samples and roll over to 0 at least twice.

DTC P0430 –TWC System Low Efficiency Bank 2

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Are any other DTCs set (such as P0160)?	—	Diagnose other DTC(s) first	Go to <i>Step 3</i>
3	1. Visually and physically inspect the three-way catalytic converter for damage. Check for the following: <ul style="list-style-type: none"> ○ dents ○ severe discoloration caused by excessive temperatures ○ holes ○ internal rattle caused by damaged catalyst 2. Also, ensure that the three-way catalytic converter is a proper original equipment manufacturer part. Did your inspection reveal a problem?	—	Go to <i>Step 6</i>	Go to <i>Step 4</i>
4	1. Visually and physically inspect the exhaust system between the three-way catalytic converter and the rear converter flange for leaks, damage, and loose or missing hardware. 2. If a problem is found, repair as necessary. Did your inspection reveal a problem?	—	Go to <i>Step 7</i> to verify repair	Go to <i>Step 5</i>
5	1. Visually and physically inspect the Bank 2 HO2S 1. 2. Ensure that the Bank 2 HO2S 2 is secure and that the pigtail and wiring harness is not contacting the exhaust pipe or is not otherwise damaged. 3. If a problem is found, repair as necessary. Did your inspection reveal a problem?	—	Go to <i>Step 7</i> to verify repair	Go to <i>Step 6</i>
6	Replace the three-way catalytic converter. NOTE: Check for conditions which may cause catalyst damage (refer to <i>Diagnostic Aids</i>). Is the action complete?	—	Go to <i>Step 7</i> to verify repair	—
7	1. Review and record the Tech 2 Failure Records data. 2. Clear DTC P0430. 3. Start the engine and allow it to warm up until the engine coolant temperature monitored on the Tech 2 is above the specified value. 4. Run the engine to maintain the specified mass air flow range for at least 2 minutes. 5. Operate the vehicle to maintain DTC P0430 test conditions (refer to <i>DTC Test Description</i> in <i>Diagnostic Support</i> for detailed instructions). 6. Using a Tech 2, monitor "DTC" info for DTC P0430 until the DTC P0430 test runs. 7. Note the test result. Does the Tech 2 indicate DTC P0430 passed this ignition?	Engine coolant temp: greater than 60°C (140°F). Mass air flow: between 8 g/second and 50 g/second	Repair complete. If a driveability symptom still exists, refer to <i>Symptoms</i> .	Go to the <i>Diagnostic Aids</i> .

Diagnostic Trouble Code (DTC) P0440 EVAP System



D06RX019

Circuit Description

The evaporative system includes the following components:

- Fuel tank
- EVAP canister vent solenoid
- Fuel tank pressure sensor
- Fuel pipes and hoses
- Vapor lines
- Fuel cap
- Evaporative emissions canister
- Purge lines
- EVAP canister purge solenoid

The evaporative leak detection diagnostic strategy is based on applying vacuum to the EVAP system and monitoring vacuum decay. The powertrain control module (PCM) monitors vacuum level via the fuel tank pressure sensor input. At an appropriate time, the EVAP canister purge solenoid and the EVAP canister vent

solenoid are turned "ON," allowing engine vacuum to draw a small vacuum on the entire evaporative emissions system. If a sufficient vacuum level cannot be achieved, a large leak or a faulty EVAP canister purge solenoid is indicated. This can be caused by the following conditions:

- Disconnected or faulty fuel tank pressure sensor
- Missing or faulty fuel cap
- Disconnected, damaged, pinched, or blocked EVAP purge line
- Disconnected or damaged EVAP vent hose
- Disconnected, damaged, pinched, or blocked fuel tank vapor line
- Disconnected or faulty EVAP canister purge solenoid
- Disconnected or faulty EVAP canister vent solenoid
- Open ignition feed circuit to the EVAP canister vent solenoid or the EVAP canister purge solenoid
- Damaged EVAP canister
- Leaking fuel sender assembly O-ring
- Leaking fuel tank or fuel filler neck

Any of the above conditions can set DTC P0440.

Conditions for Setting the DTC

- ☐ No TP sensor, ODM, IAT sensor, or MAP sensor DTCs set.
- ☐ Start-up engine coolant temperature is less than 32°C (90°F).
- ☐ Start-up engine coolant temperature is not more than 7°C (13°F) greater than start-up intake air temperature.
- ☐ Start-up intake air temperature is greater than 4°C (39°F).
- ☐ Start-up intake air temperature is not more than 2°C (4°F) greater than start-up engine coolant temperature.
- ☐ Vehicle speed is less than 75 mph (120 km/h).
- ☐ Throttle position is greater than 7% but less than 30%.
- ☐ Minimal fuel slosh.
- ☐ Fuel tank level is between 15% and 85%.
- ☐ BARO is greater than 75 kPa.
- ☐ The EVAP system is unable to achieve or maintain vacuum during the diagnostic test.
- ☐ Above conditions are present for 60 to 180 seconds.

Action Taken When the DTC Sets

- ☐ The PCM will illuminate the MIL during the second key cycle in which the DTC sets.
- ☐ The PCM will store conditions which were present when the DTC set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- ☐ The PCM will turn the MIL "OFF" when the diagnostic has been run and the fault condition is no longer present.
- ☐ A history DTC P0440 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P0440 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- ☐ Cracked or punctured EVAP canister.
- ☐ Damaged or disconnected source vacuum line, EVAP purge line, vent hose or fuel tank vapor line.
- ☐ Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.
- ☐ Damaged harness—Inspect the wiring harness to the EVAP canister vent solenoid, EVAP canister purge solenoid and the fuel tank pressure sensor for an intermittent open or short circuit.
- ☐ Kinked, pinched, or plugged vacuum source, EVAP purge, or fuel tank vapor line—Verify that the lines are not restricted.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. If an EVAP canister vent solenoid or an EVAP canister purge solenoid electrical fault is present, the purge system will not operate correctly. Repairing the electrical fault will very likely correct the condition that set DTC P0440.
3. Checks the fuel tank pressure sensor at ambient pressure.
4. Determines whether or not the EVAP system can be sealed sufficiently to be pressurized. If not, the large leak must be located and corrected before continuing with diagnosis.
5. Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.
8. Checks for a blocked EVAP canister purge solenoid. The PCM commands the EVAP canister purge solenoid "OFF" (open) and the vent solenoid "ON" (closed) with the Tech 2 "System Perf." EVAP output control function activated. Any pressure in the system should be released through the EVAP canister purge solenoid within a few seconds when "System Perf." is activated.
9. Ensures that sufficient source vacuum is present at the EVAP canister purge solenoid.

DTC P0440 – EVAP System

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Is DTC P0442 or P0446?	—	Go to <i>other DTC (P0442 or P0446)</i>	Go to Step 3
3	1. Ignition "OFF." 2. Remove the fuel cap. 3. Ignition "ON." 4. Observe "Fuel Tank Pressure" on the Tech 2. Does the Tech 2 indicate "Fuel Tank Pressure" at the specified value?	1.51V	Go to Step 4	Go to <i>DTCP0452 or P0453</i>
4	IMPORTANT: Before continuing with diagnosis, zero the EVAP pressure and vacuum gauges on the EVAP pressure/purge cart J 41413 (refer to tool operating instructions). 1. Replace the fuel cap. 2. Capture Failure Records data for DTC P0440 and clear DTCs. 3. Using the Tech 2, command the EVAP canister vent solenoid "ON" (closed). 4. Connect the EVAP pressure/purge cart J 41413 to the EVAP service port. 5. Attempt to pressurize the EVAP system using the EVAP pressure/purge cart J 41413 (monitor pressure using gauge on cart). Can EVAP system be pressurized to specified value?	5 in. H2O	Go to Step 5	Go to Step 6
5	1. Maintain fuel tank pressure at 5 inches at H2O. 2. Observe "Fuel Tank Vacuum" on the Tech 2. Does Tech 2 indicate "Fuel Tank Vacuum" at the specified value?	1.47 – 1.51V	Go to Step 8	Go to Step 7
6	1. Disconnect the fuel tank vapor line and the EVAP purge line from the EVAP canister. 2. Block the canister fitting for the fuel tank vapor line. 3. Connect a hand vacuum pump to the canister fitting for the EVAP purge line. 4. Ensure that the EVAP canister vent solenoid is still commanded "ON" (closed). 5. Attempt to apply vacuum to the EVAP canister. Can the vacuum be maintained at the specified value?	5 in. Hg	Go to Step 11	Go to Step 10
7	1. Visually/physically check for the following conditions: ○ Restricted fuel tank vapor line. ○ Restricted EVAP purge line. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 16	Go to <i>DTCP0452 or P0453</i>


DTC P0440 – EVAP System (Cont'd)

Step	Action	Value(s)	Yes	No
8	1. Disconnect the vacuum source line at the EVAP canister purge solenoid and plug the vacuum source fitting on the solenoid. 2. Using the Tech 2 output tests function, select "System Perf." and activate. 3. Pressurize the EVAP system to the specified value 5 in. H ₂ O (monitor pressure using gauge on cart). 4. Observe the EVAP pressure gauge on the EVAP pressure/purge cart J 41413 while removing the plug from the EVAP canister purge solenoid. Does "Fuel Tank Pressure" decrease to the specified value within 15 seconds while "System Perf." is activated?	0 in. H ₂ O	Go to Step 9	Go to Step 13
9	1. Connect the in. Hg vacuum gauge on the EVAP pressure/purge cart J 41413 to the vacuum source line. 2. Ignition "ON," engine idling. 3. Run the engine above 2000 RPM and observe source vacuum level (monitor vacuum using gauge on cart). Does source vacuum level exceed the specified value?	15 in. Hg	Refer to <i>Diagnostic Aids</i>	Go to Step 14
10	1. Visually/physically check for the following conditions: ○ Vent hose disconnected or the damaged. ○ EVAP canister damaged. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 16	Go to Step 15
11	1. Visually/physically check for the following conditions: ○ Missing or faulty fuel cap. ○ Disconnected or leaking fuel tank vapor line. ○ Disconnected or damaged EVAP purge line. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 16	Go to Step 12
12	1. Using Tech 2, command the EVAP canister vent solenoid "ON" (closed). 2. With the cart connected to the EVAP service port, continuously attempt to pressurize the EVAP system by leaving the cart control knob in the pressurize position. 3. Using ultrasonic leak detector J 41416, locate and repair leak in EVAP system. (It may be necessary to partially lower the fuel tank to examine the connections on top of the tank.) Is the action complete?	—	Go to Step 16	—
13	Replace the EVAP canister purge solenoid. Is the action complete?	—	Go to Step 16	—
14	Locate and repair cause of no source vacuum to the EVAP canister purge solenoid. Is the action complete?	—	Go to Step 16	—

DTC P0440 – EVAP System (Cont'd)

Step	Action	Value(s)	Yes	No
15	Replace the EVAP canister vent solenoid. Is the action complete?	—	Go to <i>Step 16</i>	—
16	1. Ignition "ON," engine not running. 2. Using the Tech 2, command the EVAP canister vent solenoid "ON" (closed). 3. Using the EVAP pressure/purge cart J 41413, pressurize and monitor the EVAP system to 15 in. H ₂ O. 4. Switch the rotary switch on the cart to "HOLD" and observe the EVAP pressure gauge. Does the pressure decrease to less than the specified value within 2 minutes?	2.14V	Go to <i>Step 3</i>	Verify repair

Diagnostic Trouble Code (DTC) P0442 EVAP System Small Leak Detected



D06RX019

Circuit Description

The evaporative system includes the following components:

- Fuel tank
- EVAP canister vent solenoid
- Fuel tank pressure sensor
- Fuel pipes and hoses
- Vapor lines
- Fuel cap
- Evaporative emissions canister
- Purge lines
- EVAP canister purge solenoid

The evaporative leak detection diagnostic strategy is based on applying vacuum to the EVAP system and monitoring vacuum decay. The powertrain control module (PCM) monitors vacuum level via the fuel tank pressure sensor input. At an appropriate time, the EVAP canister purge solenoid and the EVAP canister vent

solenoid are turned "ON," allowing engine vacuum to draw a small vacuum on the entire evaporative emissions system. After the desired vacuum level has been achieved, the EVAP canister purge solenoid is turned "OFF," sealing the system. A leak is detected by monitoring for a decrease in vacuum level over a given time period, all other variables remaining constant. A small leak in the system will cause DTC P0442 to be set.

Conditions for Setting the DTC

- No TP sensor, ODM, IAT sensor, or MAP sensor DTCs set.
- The DTC P0440 diagnostic test has passed.
- A vacuum decay condition, indicating a small leak, is detected during the diagnostic test.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) during the second key cycle in which the DTC sets.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0442 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0442 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Cracked or punctured EVAP canister.
- Damaged source vacuum line, EVAP purge line, EVAP vent hose or fuel tank vapor line.
- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.
- Damaged harness—Inspect the wiring harness to the EVAP canister vent solenoid, EVAP canister purge solenoid and the fuel tank pressure sensor for an intermittent open or short circuit.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.


2. If an EVAP canister vent solenoid or an EVAP canister purge solenoid electrical fault is present, the purge system will not operate correctly. Repairing the electrical fault will very likely correct the condition that set DTC P0442.
3. Checks the fuel tank pressure sensor at ambient pressure.
4. Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.

DTC P0442 – EVAP System Leak Detected

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "OFF." 2. Remove the fuel cap. 3. Ignition "ON." 4. Observe "Fuel Tank Pressure" on the Tech 2. Does the Tech 2 indicate "Fuel Tank Pressure" at the specified value?	1.51V	Go to Step 3	Go to <i>Fuel Tank Pressure System</i>
3	IMPORTANT: Before continuing with diagnosis, zero the EVAP pressure and vacuum gauges on EVAP pressure/purge cart J 41413 (refer to tool operating instructions). 1. Replace the fuel cap. 2. Capture Failure Records data for DTC P0442 and clear DTCs. 3. Connect the EVAP pressure/purge cart J 41413 to the EVAP service port. 4. Using the Tech 2, command the EVAP canister vent solenoid "ON" (closed). 5. Using the EVAP pressure/purge cart J 41413, pressurize the EVAP system to the specified value. 6. Observe "Fuel Tank Pressure" on the Tech 2. Does the Tech 2 indicate "Fuel Tank Pressure" at the specified value?	1.52 – 1.67V	Go to Step 4	Go to <i>Fuel Tank Pressure System</i>
4	1. Ignition "ON," engine idling. 2. Using the Tech 2, command the EVAP canister vent solenoid "ON" (closed). 3. Using the EVAP pressure/purge cart J 41413, pressurize the EVAP system to 15 in. H ₂ O. 4. Switch the rotary switch on the cart to "HOLD" and observe the EVAP pressure gauge. Does the pressure decrease to less than the specified value within 2 minutes?	10 in. H ₂ O	Go to Step 5	Refer to <i>Diagnostic Aids</i>
5	1. Disconnect the fuel tank vapor line and the EVAP purge line from the EVAP canister. 2. Block the canister fitting for the fuel tank vapor line. 3. Connect a hand vacuum pump to the canister fitting for the EVAP purge line. 4. Ensure that the EVAP canister vent solenoid is still commanded "ON" (closed). 5. Attempt to apply vacuum to the EVAP canister. Can the vacuum be maintained at the specific value?	5 in. Hg	Go to Step 8	Go to Step 6
6	1. Visually/physically check for the following conditions: ○ Vent hose disconnected or damaged. ○ EVAP canister damaged. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 10	Go to Step 7

DTC P0442 – EVAP System Leak Detected (Cont'd)

Step	Action	Value(s)	Yes	No
7	Replace the EVAP canister vent solenoid. Is the action complete?	—	Go to <i>Step 10</i>	—
8	1. Visually/physically check for the following conditions: <ul style="list-style-type: none"> ○ Missing or faulty fuel cap. ○ Disconnected or leaking fuel tank vapor line. ○ Disconnected or damaged EVAP purge line. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to <i>Step 10</i>	Go to <i>Step 9</i>
9	1. Using Tech 2, command the EVAP canister vent solenoid "ON" (closed). 2. With the cart connected to the EVAP service port, continuously attempt to pressurize the EVAP system by leaving the cart control knob in the pressurize position. 3. Using ultrasonic leak detector J 41416, locate and repair leak in EVAP system. (It may be necessary to partially lower the fuel tank to examine the connections on top of the tank.) Is the action complete?	—	Go to <i>Step 10</i>	—
10	1. Ignition "ON," engine not running. 2. Using the Tech 2, command the EVAP canister vent solenoid "ON" (closed). 3. Using the EVAP pressure/purge cart J 41413, pressurize and monitor the EVAP system to 15 in. H ₂ O. 4. Switch the rotary switch on the cart to "HOLD" and observe the EVAP pressure gauge. Does the pressure decrease to less than the specified value within 2 minutes?	10 in. H ₂ O	Go to <i>Step 2</i>	Verify repair



Diagnostic Trouble Code (DTC) P0446 EVAP Canister Vent Blocked

Circuit Description

The evaporative system includes the following components:

- ☐ Fuel tank
- ☐ EVAP canister vent solenoid
- ☐ Fuel tank pressure sensor
- ☐ Fuel pipes and hoses
- ☐ Vapor lines
- ☐ Fuel cap
- ☐ Evaporative emissions canister
- ☐ Purge lines
- ☐ EVAP canister purge solenoid

An incorrect fuel tank pressure sensor signal is detected by monitoring fuel tank pressure when the key is first turned "ON" during a cold start. If the fuel tank pressure signal is out of range, DTC P0446 will set. A restricted or blocked EVAP vent path is detected by monitoring fuel tank pressure during normal operation (EVAP canister vent solenoid open, EVAP canister purge solenoid normal). With the EVAP canister vent solenoid open, vacuum level in the system should be very low unless the vent path is blocked. A blockage can be caused by the following condition:

- ☐ Faulty EVAP canister vent solenoid (stuck closed).
 - ☐ Plugged, kinked or pinched vent hose.
 - ☐ Shorted EVAP canister vent solenoid driver circuit.
 - ☐ Plugged evaporative canister.
- If any of these conditions are present, DTC P0446 will set.

Conditions for Setting the DTC

- ☐ No TP sensor, ODM, IAT sensor, or MAP sensor DTCs set.
- ☐ Start-up engine coolant temperature is less than 32°C (90°F).
- ☐ Start-up engine coolant temperature is not more than 7°C (13°F) greater than start-up intake air temperature.
- ☐ Start-up intake air temperature is greater than 4°C (39°F).
- ☐ Start-up intake air temperature is not more than 2°C (4°F) greater than start-up engine coolant temperature.
- ☐ Vehicle speed is less than 75 mph (120 km/h).
- ☐ Throttle position is greater than 7% but less than 30%.
- ☐ Minimal fuel slosh.
- ☐ Fuel tank level is between 15% and 85%.
- ☐ BARO is greater than 75 kPa.
- ☐ Fuel tank pressure is not between -1.5 and 1.5 in. H₂O when ignition is turned "ON."

OR

- ☐ No TP sensor, ODM, IAT sensor, or MAP sensor DTCs set.

- ☐ DTC P0442 diagnostic test has passed.
- ☐ Normal system operation is commanded (EVAP canister vent solenoid open, EVAP canister purge solenoid normal).
- ☐ Fuel tank pressure is less than -10 in. H₂O.
- ☐ Above conditions are present for 60 to 180 seconds.

Action Taken When the DTC Sets

- ☐ The PCM will illuminate the MIL during the second key cycle in which the DTC sets.
- ☐ The PCM will store conditions which were present when the DTC set as Freeze Frame and Failure Records data.

Conditions for Clearing the MIL/DTC

- ☐ The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- ☐ A history DTC P0446 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P0446 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- ☐ Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal to wire connection.
- ☐ Damaged harness—Inspect the wiring harness to the EVAP canister vent solenoid, EVAP canister purge solenoid and the fuel tank pressure sensor for an intermittent open or short circuit.
- ☐ Kinked, pinched, or plugged vent hose—Verify that the vent hose between the EVAP canister and EVAP canister vent solenoid is not restricted.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.


2. If a vent solenoid electrical fault is present, the purge system will not operate correctly. Repairing the electrical fault will very likely correct the condition that set DTC P0446.
3. Checks the fuel tank pressure sensor at ambient pressure.
4. Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.
6. Checks for a blocked EVAP canister.

DTC P0446– EVAP Canister Vent Blocked

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition “ON.” 2. Capture Failure Records data for DTC P0446 and clear DTCs. 3. Ignition “OFF.” 4. Remove the fuel cap. 5. Ignition “ON.” 6. Observe “Fuel Tank Pressure” on the Tech 2. Does Tech 2 indicate “Fuel Tank Pressure” at the specified value?	1.51V	Go to Step 3	Go to <i>Fuel Tank Pressure System</i>
3	IMPORTANT: Before continuing with diagnosis, zero the EVAP pressure and vacuum gauges on the EVAP pressure/purge cart J 41413 (refer to tool operating instructions). 1. Replace the fuel cap. 2. Using the Tech 2, command the EVAP vent solenoid “ON” (closed). 3. Connect the EVAP pressure/purge cart J 41413 to the EVAP service port. 4. Using the EVAP pressure/purge cart J 41413, pressurize the EVAP system to the specified value. 5. Observe “Fuel Tank Pressure” on the Tech 2. Does Tech 2 indicate “Fuel Tank Pressure” at the specified value?	1.52 – 1.67V	Go to Step 4	Go to <i>Fuel Tank Pressure System</i>
4	1. Maintain the EVAP pressure at 5 in. at H2O. 2. Using Tech 2, command the EVAP vent solenoid “OFF” (open) while observing the EVAP pressure gauge on the cart J 41413. Does the EVAP pressure return to the specified value within 5 seconds?	0 in. H2O	Refer to <i>Diagnostic Aids</i>	Go to Step 5
5	1. Disconnect the large vent hose (marked “AIR”) from the EVAP canister. 2. Switch the rotary switch on the cart J 41413 to “PURGE.” 3. Ignition “ON,” engine idling at normal operating temperature. 4. Observe vacuum gauge for 5 seconds while holding the engine speed at 2500 RPM. Does the vacuum remain less than the specified value?	30 in. H2O	Go to Step 6	Go to Step 8
6	1. Inspect the vent hose between the EVAP canister and the EVAP canister vent solenoid for kinks, pinched areas, or any other form of blockage. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 9	Go to Step 7
7	Replace the EVAP canister vent solenoid. Is the action complete?	—	Go to Step 9	—

DTC P0446– EVAP Canister Vent Blocked (Cont'd)

Step	Action	Value(s)	Yes	No
8	Replace the EVAP canister. Is the action complete?	—	Go to <i>Step 9</i>	—
9	<ol style="list-style-type: none"> Using Tech 2, command the EVAP canister vent solenoid "ON" (closed). Using the EVAP pressure/purge cart J 41413, pressurize and monitor the EVAP system to 15 in. H₂O. Switch the rotary switch on cart J 41413 to "HOLD." Using the Tech 2, command the EVAP canister vent solenoid "OFF" (open) while observing the EVAP pressure gauge on cart J 41413. <p>Does the EVAP pressure return to the specified value within 5 seconds?</p>	0 in. H ₂ O	Verify repair	Go to <i>Step 2</i>

Diagnostic Trouble Code (DTC) P0452 Fuel Tank Pressure Sensor Low Voltage

D06RX020

Circuit Description

The powertrain control module (PCM) monitors fuel tank pressure sensor of the Enhanced Evapo system. When the tank pressure output indicates low voltage, PCM will set DTC P0452.

Conditions for Setting the DTC

- Ignition voltage is between 0.3 and 4.7 volts.
- Tank sensor output is less than 0.2 volts for 12.5 sec.
- 100 test failures within a 200 tests.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) as soon as failure detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history DTC P0402 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0404 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Open circuit of 5 volt reference line – Inspect wiring harness from PCM to the sensor. The PCM turns P0452, and P0107 at the same time.
- Open circuit or short circuit to ground line – Inspect wiring harness from PCM to the sensor. The PCM turns P0452 and P0107 at the same time.
- Tank fuel pressure sensor malfunction may cause P0452.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0452 – Tank Pressure Sensor Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P0452 until the DTC P0452 test runs. Note the result. Does the Tech 2 indicates DTC P0452 or P0452/P0107 failed this ignition?	—	P0452/P0107 turn on Go to Step 3 P0452 turns on Go to Step 6	Refer to <i>Diagnostic Aids</i>
3	1. Ignition "OFF". 2. Disconnect connector at the PCM. 3. Ignition "ON". 4. At the PCM connector, measure voltage with a DVM at B1 and B6 terminals. Was the voltage in range of voltage?	4–6 V	Go to Step 4	Go to Step 10
4	1. Ignition "OFF". 2. Connect the PCM connector to the PCM. 3. Backprobe with a DVM at fuel tank pressure sensor between 5 V reference terminal and sensor ground terminal. Was the voltage within range?	4–6 V	For P0452 go to Step 5 and for P0107, go to diagnosis section.	Go to Step 5
5	1. Locate open wiring of 5 volt reference circuit from the PCM to fuel tank pressure sensor. 2. Repair wiring harness. Is the action complete?	—	Verify repair	—
6	1. Ignition "ON" 2. At the PCM connector, backprobe with a DVM at the sensor output for the voltage. Was voltage within the range?	Less than 0.2 V	Go to Step 7	Go to Step 10
7	At the sensor output terminal, backprobe with a DVM at the sensor output Was voltage within the range?	Less than 0.2 V	Go to Step 9	Go to Step 8
8	1. Locate open circuit or short circuit to ground line. 2. Repair the harness. Is the action complete?	—	Verify repair	—

DTC P0452 – Tank Pressure Sensor Low Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
9	1. Locate open circuit or short circuit to ground line. 2. Repair the harness. Is the action complete?	—	Verify repair	—
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0453 Fuel Tank Pressure Sensor High Voltage



Circuit Description

The powertrain control module (PCM) monitors fuel tank pressure sensor of the Enhanced Evapo system. When the tank pressure output indicates high voltage, PCM will set DTC P0453.

Conditions for Setting the DTC

- Tank sensor output is more than 4.9 volts for 12.5 sec.
- 100 test failures within a 200 tests.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) as soon as failure detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL “OFF” on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.

- A history DTC P0453 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- Info function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Open circuit of sensor ground line – Inspect wiring harness from PCM to the sensor. The PCM turns P0453, and P0108 at the same time.
- Open circuit or short circuit to 5 volt reference line – Inspect wiring harness from PCM to the sensor. The PCM turns P0453 and P0108 at the same time.
- Tank fuel pressure sensor malfunction may cause P0453.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P0453 – Fuel Tank Pressure Sensor High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P0452 until the DTC P0452 test runs. Note the result. Does the Tech 2 indicates DTC P0452 or P0452/P0107 failed this ignition?	—	P0453/P0108 turn on Go to <i>Step 3</i> P0452 turns on Go to <i>Step 6</i>	Refer to <i>Diagnostic Aids</i>
3	1. Ignition "OFF". 2. Disconnect connector at the PCM. 3. Ignition "ON". 4. At the PCM connector, measure voltage with a DVM at B1 and B6 terminals. Was the voltage in range of voltage?	4–6 V	Go to <i>Step 4</i>	Go to <i>Step 10</i>
4	1. Ignition "OFF". 2. Connect the PCM connector to the PCM. 3. Disconnect sensor harness at fuel pressure sensor. Measure voltage with a DVM at the end of the tank pressure wiring between 5 V reference terminal and sensor ground terminal. Was the voltage within range?	4–6 V	For P0453 go to <i>Step 6</i> and for P0108, go to diagnosis section.	Go to <i>Step 5</i>
5	1. Locate open wiring of ground line from the PCM to fuel tank pressure sensor. 2. Repair wiring harness. Is the action complete?	—	Verify repair	—
6	1. Ignition "ON". 2. At the PCM connector, backprobe with a DVM at the sensor output for the voltage. Was voltage within the range?	More than 4.9 V	Go to <i>Step 7</i>	Go to <i>Step 10</i>
7	At the sensor output terminal, backprobe with a DVM at the sensor output. Was the voltage within range?	More than 4.9 V	Go to <i>Step 9</i>	Go to <i>Step 8</i>
8	1. Locate open circuit or short circuit to ground line. 2. Repair the harness. Is the action complete?	—	Verify repair	—

DTC P0453 – Fuel Tank Pressure Sensor High Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
9	Replace the tank pressure sensor. Is the action complete?	—	Verify repair	—
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0462 Fuel Level Sensor Circuit–Low Voltage

D06RW080

Circuit Description

The fuel level sensor is an important input to powertrain control module (PCM) for the enhanced evaporative system diagnostic. Fuel level information is needed for the PCM to know the volume of fuel in the tank. The fuel level affects the rate of change in air pressure in the evaporative system. Several of the enhanced evaporative system diagnostic sub-tests are dependent upon correct fuel level information. The diagnostic will not run when the tank is greater than 85%, or less than 15% full. Fuel level DTCs should be diagnosed before other evaporative system DTCs because they can cause other DTCs to be set.

The sending unit is a float in the fuel tank which moves a wiper arm across a variable resistor. Low fuel level causes high resistance in the sending unit, and this is recognized by the PCM because the circuit operates at a corresponding low voltage. When the circuit is continuously open or has a high resistance connection, DTC P0462 is set.

Conditions for Setting the DTC

- Fuel tank level “slosh test” is completed.
- Fuel tank level “main test” is completed.
- Fuel tank level data is valid.
- Fuel tank level signal is less than a specified value.
- There are 100 test failures within a 200-test sample.

Action Taken When the DTC Sets

- The PCM will not turn the malfunction indicator lamp (MIL) “ON.”
- The PCM will store conditions which were present when the DTC was set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- The PCM will turn the MIL “OFF” after three consecutive trips without a fault condition present. A history DTC will be cleared if no fault conditions have been detected for 40 warm-up cycles (engine coolant temperature has risen 4°C (40°F) from the start-up ECT, and ECT exceeds 71°C (160°F) during that same ignition cycle).
- DTC P0462 can be cleared by using the scan tool “Clear Info” function or by disconnecting the PCM battery feed.

Diagnostic Aids

- Damaged harness—Inspect the wiring harness for damage. If the harness appears to be OK, observe the fuel level display on the scan tool while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

8. The following chart can be used to check the sending unit:


DTC P0462– Fuel Level Sensor Circuit –Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Were any ECT or MAP DTCs set? (ECT and MAP Sharing Ground with PCM term D9)	—	Go to other DTC chart	Go to <i>Step 3</i>
3	1. Disconnected the fuel level sensor harness from its connector at the fuel tank. 2. Ignition “ON,” engine “OFF.” 3. Using a DVM, measure the voltage between the sensor harness positive and ground wires. Is the voltage approximately equal to the specified value?	5 V	Go to <i>Step 7</i>	Go to <i>Step 4</i>
4	1. Ignition “ON,” engine “OFF.” 2. With a DVM, backprobe the PCM connector at the terminal which supplies 5 volts to the fuel level sensor. Is the voltage approximately equal to the specified value?	5 V	Go to <i>Step 5</i>	Go to <i>Step 10</i>
5	1. Ignition “ON,” engine “OFF.” 2. Fuel level sensor disconnected from wiring harness. 3. With a DVM, probe the 5-volt supply wire at the sensor harness. Is the voltage approximately equal to the value measured in Step 4?	—	Go to <i>Step 6</i>	Go to <i>Step 10</i>
6	Check for open or high resistance connection in the ground wire between the PCM and the fuel level sensor. Is the action complete?	—	Verify repair	—
7	Remove the fuel level sensor and check the following: ○ Does the arm move freely? ○ Are the wires open or intermittently open when wiggled? ○ Do the resistance values match the specification chart? Was a problem found?	—	Go to <i>Step 8</i>	Go to <i>Step 10</i>
8	Replace the fuel level sensor. Is the action complete?	—	Verify repair	—

DTC P0462– Fuel Level Sensor Circuit –Low Voltage (Cont'd)

Step	Action	Value(s)	Yes	No
9	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—
10	<p>Short to ground between the PCM connector and the fuel level sensor.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0463 Fuel Level Sensor Circuit–High Voltage



D06RW080

Circuit Description

The fuel level sensor is an important input to powertrain control module (PCM) for the enhanced evaporative system diagnostic. Fuel level information is needed for the PCM to know the volume of fuel in the tank. The fuel level affects the rate of change in air pressure in the evaporative system. Several of the enhanced evaporative system diagnostic sub-tests are dependent upon correct fuel level information. The diagnostic will not run when the tank is greater than 85% or less than 15%, full. Fuel level DTCs should be diagnosed before other evaporative system DTCs because they can cause other DTCs to be set.

The sending unit is a float in the fuel tank which moves a wiper arm across a variable resistor. High fuel level causes low resistance in the sending unit. This is recognized by the PCM because the circuit operates at a corresponding high voltage. When the circuit is continuously shorted to a voltage source greater than a specified value, or when the 5 volt signal is shorted to ground, DTC P0463 is set.

Conditions for Setting the DTC

- Fuel tank level “slosh test” is completed.
- Fuel tank level “main test” is completed.
- Fuel tank level data is valid.
- Fuel tank level signal is greater than a specified value.
- There are 100 test failures within a 200-test sample.

Action Taken When the DTC Sets

- The PCM will not turn the malfunction indicator lamp (MIL) “ON.”
- The PCM will store conditions which were present when the DTC set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the DTC

- The PCM will turn the MIL “OFF” after three consecutive trips without a fault condition present. A history DTC will be cleared if no fault conditions have been detected for 40 warm-up cycles (engine coolant temperature has risen 4°C (40°F) from the start-up ECT, and ECT exceeds 71°C (160°F) during that same ignition cycle) or the scan tool clearing function has been used.
- DTC P0463 can be cleared by using the scan tool “Clear Info” function or by disconnecting the PCM battery feed.

Diagnostic Aids

- Damaged harness–Inspect the wiring harness for damage. If the harness appears to be OK, observe the fuel level display on the scan tool while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.


2. The ECT and MAP sensors share a ground at PCM terminal D9.

9. Equates the resistance values at various float positions to the following fuel gauge readings:

DTC P0463– Fuel Level Sensor Circuit –High Voltage

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Were any ECT or MAP DTCs set? (ECT and MAP Sharing Ground with PCM term D9)	—	Go to other DTC chart	Go to Step 3
3	1. Disconnected the fuel level sensor harness from its connector at the fuel tank. 2. Ignition “ON,” engine “OFF.” 3. Using a DVM, measure the voltage between the sensor harness positive and ground wires. Is the voltage approximately equal to the specified value?	5 V	Go to Step 9	Go to Step 4
4	With the negative DVM lead connected to ground, use the positive DVM lead to probe the sensor ground wire with the harness still disconnected. Does the DVM indicate a short to a voltage source?	—	Go to Step 5	Go to Step 6
5	Repair short to voltage between the sensor and the PCM. Is the repair complete?	—	Verify repair	—
6	With the negative DVM lead connected to ground, use the positive DVM lead to probe the sensor positive wire with the harness still disconnected. Does the DVM indicate a voltage greater than the specified value?	5 V	Go to Step 5	Go to Step 7
7	Open circuit between the PCM connector and the fuel level sensor?	—	Verify repair	Go to Step 8
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—
9	Remove the fuel level sensor and check the following: ○ Does the arm move freely? ○ Are the wire leads shorted together? ○ Do the resistance values match the specification chart? Was a problem found?	—	Go to Step 10	Go to Step 8
10	Replace the fuel level sensor. Is the repair complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0502 VSS Circuit Low Input



D06RX021

Circuit Description

The vehicle speed sensor has a magnet rotated by the transmission output shaft. Attached to the sensor is a hall effect circuit that interacts with the magnetic field created by the rotating magnet. A 12-volt operating supply for the speed sensor hall circuit is supplied from the meter fuse. The VSS pulses to ground the 9-volt signal sent from the powertrain control module (PCM) on the reference circuit. The PCM interprets vehicle speed by the number of pulses to ground per second on the reference circuit.

Conditions for Setting the DTC

- Engine is running.
- Engine coolant temperature is above 60°C (140°F).
- Engine speed is between 1800 RPM and 2500 RPM.
- Throttle angle is between 10% and 40%.
- Engine load is greater than 50 kPa.
- MAP sensor indicates greater than 50 kPa manifold pressure.

- PCM detects no VSS signal for 12.5 seconds over a period of 25 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0502 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0502 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

9. To avoid backprobing the VSS and possibly damaging a seal or terminal, the VSS output can be tested at the point where the transmission harness connected to the engine harness. The green 16-way connector is adjacent to a blue 16-way connector, and it can be easily accessed by removing the air cleaner assembly. The green 16-way connector is separated, and battery voltage is applied to the VSS through the yellow wire at one corner of the connector. The VSS output can be monitored with a DVM connected to the blue wire with a black tracer. The two wires are next to each other in the 16-way connector. The test connections are made on the transmission side of the connector, the side that is not clipped to the body sheetmetal.

14. The speedometer-to-PCM VSS signal wire is spliced to a wire leading to the cruise control module. If a short to ground or voltage is found between the PCM and speedometer, it could be located between the splice and the cruise control module.


DTC P0502 –VSS Circuit Low Input

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Does the speedometer work?	—	Go to Step 10	Go to Step 3
3	1. Disconnect the VSS connector. 2. Ignition "ON." 3. Using a test light to battery +, probe the connector ground wire. Did the light illuminate?	—	Go to Step 5	Go to Step 4
4	Repair the sensor ground. Is the action complete?	—	Verify repair	—
5	1. Ignition "ON," sensor disconnected. 2. Using a DVM, measure at the VSS connector between ground and voltage supply. Was the measurement near the specified value?	Battery voltage	Go to Step 7	Go to Step 6
6	Repair the open or short to ground which may have blown the meter fuse. Is the action complete?	—	Verify repair	—
7	1. Ignition "ON," VSS disconnected. 2. Using a DVM, measure at the VSS connector between ground and the blue/black wire from the speedometer. Was the measurement near the specified value?	7.5-8 V	Go to Step 9	Go to Step 8
8	Check for an open or short circuit between the speedometer and the VSS. Was an open or short circuit located?	—	Verify repair	Go to Step 9
9	Replace the speedometer. Is the action complete?	—	Verify repair	—

DTC P0502 –VSS Circuit Low Input (Cont'd)

Step	Action	Value(s)	Yes	No
10	<p>1. Ignition "OFF."</p> <p>2. Disconnect the MAF sensor. The connector attaches the VSS wires from the transmission harness to the left-side engine harness.</p> <p>3. Disconnect the green 16-way connector.</p> <p>4. Select a terminal adapter from kit J 35616 that can be used with a jumper to supply B+ to the yellow (transmission side of the connector). There are 2 yellow wires at that connector, but the correct one is in the corner position.</p> <p>5. Use another terminal adapter to attach a voltmeter to the blue wire with a black tracer (next to the wire in the previous step.)</p> <p>6. At the transmission side of the green 16-way connector, locate the black wire next to the VSS yellow ign+ wire. The black wire is the VSS ground wire. Use a terminal adapter to attach a jumper to ground to the black VSS ground wire at the transmission side of the connector.</p> <p>7. Raise the rear wheels off the ground with transmission in neutral.</p> <p>Does the DVM toggle back and forth between 0.6 V and 10 V as the wheels (and driveshaft) are rotated?</p>	—	Go to Step 12	Go to Step 11
11	<p>Replace the VSS.</p> <p>Is the action complete?</p>	—	Verify repair	—
12	<p>Check for an open or short between the PCM and the speedometer.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0506 Idle Air Control System Low RPM



T321115

Circuit Description

The powertrain control module (PCM) controls engine idle speed by adjusting the position of the idle air control (IAC) motor pintle. The IAC is a bi-directional stepper motor driven by two coils. The PCM applies current to the IAC coils in steps (counts) to extend the IAC pintle into a passage in the throttle body to decrease air flow. The PCM reverses the current to retract the pintle, increasing air flow. This method allows highly accurate control of idle speed and quick response to changes in engine load. If the PCM detects a condition where too low of an idle speed is present and the PCM is unable to adjust idle speed by increasing the IAC counts, DTC P0506 will set, indicating a problem with the idle control system.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- No TPS, VSS, ECT, EGR, MAF, MAP, IAT, misfire, low voltage, fuel system, canister purge, injector control, or ignition control DTCs are set.
- Barometric pressure is above 75 kPa.
- Canister purge duty cycle is above 10%.
- Engine running time is more than 125 seconds.
- Vehicle speed is less than 1 mph.
- Engine coolant temperature (ECT) is above 50°C.
- Ignition voltage is between 9.5 volts and 16.7 volts.
- The throttle is closed.
- EVAP purge duty cycle more than 10%.
- All conditions are met for 10 seconds.

- Engine speed is more than 100-200 RPM lower than desired idle based upon coolant temperature.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- DTC P0506 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM or IAC motor – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage.
- Restricted air intake system – Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system.
- Throttle body – Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC

passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate.

- Large vacuum leak – Check for a condition that causes a large vacuum leak, such as an incorrectly installed or faulty PCV valve or brake booster hose disconnected.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0506 – Idle Air Control System Low RPM

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any other DTCs set?	—	Go to other DTC first	Go to Step 3
3	<p>1. Start the engine.</p> <p>2. Turn all accessories “OFF” (A/C, rear defroster, etc.)</p> <p>3. Using a Tech 2, command RPM up to 1500, down to 500, and then up to 1500 while monitoring “Engine Speed” on the Tech 2.</p> <p>NOTE: This Tech 2 command may cause the engine to “cut out” when RPM goes above 1500. If this occurs, the “cutting out” will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500RPM.</p> <p>Does the “Engine Speed” remain within the specified value of “Desired Idle” for each RPM command?</p>	±50 RPM	No trouble found. Go to <i>Diagnostic Aids</i>	Go to Step 4
4	<p>1. Disconnect the IAC.</p> <p>2. Install IAC Node Light J 37027A or equivalent.</p> <p>3. With the engine running, command RPM up to 1500, down to 500, and then up to 1500 while observing the node light.</p> <p>NOTE: This Tech 2 command may cause the engine to “cut out” when RPM goes above 1500. If this occurs, the “cutting out” will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500RPM.</p> <p>Does each node light cycle red and green (never “OFF”)?</p>	—	Go to Step 6	Go to Step 5
5	<p>1. Check the following circuits for an open, short to voltage, short to ground, or poor connection at the PCM:</p> <ul style="list-style-type: none"> ○ IAC “A” low ○ IAC “A” high ○ IAC “B” low ○ IAC “B” high <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 9

DTC P0506 – Idle Air Control System Low RPM (Cont'd)

Step	Action	Value(s)	Yes	No
6	<p>Visually/physically inspect for the following conditions:</p> <ul style="list-style-type: none"> ○ Restricted air intake system. Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system. ○ Throttle body. Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. <p>Do any of the above require a repair?</p>	—	Refer to appropriate section for on-vehicle service	Go to <i>Step 7</i>
7	<p>1. Check for a poor connection at the IAC harness connector.</p> <p>2. If a problem is found, replace faulty terminals as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 8</i>
8	<p>Replace the IAC valve.</p> <p>Is the action complete?</p>	—	Verify repair	—
9	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0507 Idle Air Control System High RPM



T321115

Circuit Description

The powertrain control module (PCM) controls engine idle speed by adjusting the position of the idle air control (IAC) motor pintle. The IAC is a bi-directional stepper motor driven by two coils. The PCM applies current to the IAC coils in steps (counts) to extend the IAC pintle into a passage in the throttle body to decrease air flow. The PCM reverses the current to retract the pintle, increasing air flow. This method allows highly accurate control of idle speed and quick response to changes in engine load. If the PCM detects a condition where too high of an idle speed is present and the PCM is unable to adjust idle speed by increasing the IAC counts, DTC P0507 will set, indicating a problem with the idle control system.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- No TPS, VSS, ECT, EGR, MAF, MAP, IAT, misfire, low voltage, fuel system, canister purge, injector control or ignition control DTCs are set.
- Barometric pressure is above 75 kPa.
- Canister purge duty cycle is above 10%.
- Engine running time is more than 125 seconds.
- Vehicle speed is less than 1 mph.
- Engine coolant temperature (ECT) is above 50°C.
- Ignition voltage is between 9.5 volts and 16.7 volts.
- The throttle is closed.
- EVAP purge duty cycle is more than 10%.
- All conditions are met for 10 seconds.

- Engine speed is more than 100-200 RPM higher than desired idle based upon coolant temperature.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0507 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0507 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM or IAC motor – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage.

6E2-354 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- Vacuum leak – Check for a condition that causes a vacuum leak, such as disconnected or damaged hoses, leaks at EGR valve and EGR pipe to intake manifold, leak at the throttle body, a faulty or incorrectly installed PCV valve, leaks at the intake manifold, etc.
- Throttle body – Check for sticking throttle plate. Also inspect the IAC passage for deposits or objects which

will not allow the IAC pintle to fully extend or properly seat.

If DTC P0507 cannot be duplicated, reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P0507 – Idle Air Control System High RPM

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any other DTCs set?	—	Go to other DTC first	Go to Step 3
3	1. Start the engine. 2. Turn all accessories "OFF" (A/C, rear defroster, etc.) 3. Using a Tech 2, command RPM up to 1500, down to 500, and then up to 1500 while monitoring "Engine Speed" on the Tech 2. NOTE: This Tech 2 command may cause the engine to "cut out" when RPM goes above 1500. If this occurs, the "cutting out" will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500RPM. Does "Engine Speed" remain within the specified value of "Desired Idle" for each RPM command?	± 50 RPM	No trouble found. Go to <i>Diagnostic Aids</i>	Go to Step 4
4	1. Disconnect the IAC. 2. Install IAC Node Light J 37027A or equivalent. 3. With the engine running, command RPM up to 1500, down to 500, and then up to 1500 while observing the node light. NOTE: This Tech 2 command may cause the engine to "cut out" when RPM goes above 1500. If this occurs, the "cutting out" will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500RPM. Does each node light cycle red and green (never "OFF")?	—	Go to Step 6	Go to Step 5
5	1. Check the following circuits for an open, short to voltage, short to ground, or poor connection at the PCM: ○ IAC "A" low ○ IAC "A" high ○ IAC "B" low ○ IAC "B" high 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9

DTC P0507 – Idle Air Control System High RPM (Cont'd)

Step	Action	Value(s)	Yes	No
6	<p>Visually/physically inspect for the following conditions:</p> <ul style="list-style-type: none"> ○ Vacuum leaks ○ Throttle plate or throttle shaft for binding. ○ Accelerator and cruise control cables for being mis-adjusted or for binding. ○ Faulty, missing, or incorrectly installed PCV valve. <p>Do any of the above require a repair?</p>	—	Refer to appropriate section for on-vehicle service	Go to Step 7
7	<p>1. Check for a poor connection at the IAC harness connector.</p> <p>2. If a problem is found, replace faulty terminals as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 8
8	<p>Replace the IAC valve.</p> <p>Is the action complete?</p>	—	Verify repair	—
9	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0562 System Voltage Low



D06RX022

Circuit Description

The powertrain control module (PCM) monitors the system voltage on the ignition feed terminal to the PCM. A system voltage DTC will set whenever the voltage is below a calibrated value.

Conditions for Setting the DTC

- Ignition "ON."
- System voltage is below 11.5 volts for 15 minutes.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store as Failure Records conditions which were present when the DTC was set. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P0562 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0562 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

If the DTC sets when an accessory is operated, check for a poor connection or excessive current draw.

DTC P0562 – System Voltage Low

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Using a DVM, measure the battery voltage at the battery. Is the battery voltage greater than the specified value?	11.5 V	Go to Step 3	Charge battery, then go to Step 3
3	1. Install a Tech 2. 2. Select "Ignition Volts" on the Tech 2. 3. Start the engine and raise the engine speed to the specified value. 4. Load the electrical system by turning on the headlights, high blower, etc. Is the ignition voltage approximately equal to the specified value?	2000 RPM 12.8-14.1 V	Go to Step 4	Go to <i>Starting/Charging</i>
4	1. Ignition "OFF." 2. Disconnect the PCM connector at the PCM. 3. Using a DVM, measure the battery voltage at the PCM connector A-4. Is it approximately equal to battery voltage?	—	Check for excessive current draw with ignition "OFF," engine "OFF."	Go to Step 5
5	1. Check for faulty connections at the PCM harness terminals. 2. Repair as necessary. Was a repair necessary?	—	Verify repair	Go to Step 6
6	Check for an open battery feed circuit to the PCM. Is the action complete?	—	Verify repair	Go to Step 7
7	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0563 System Voltage High

Circuit Description

The powertrain control module (PCM) monitors the system voltage on the ignition feed terminals to the PCM. A system voltage DTC will set whenever the voltage is above a calibrated value.

Conditions for Setting the DTC

- Ignition "ON."
- System voltage is above 16 volts for 15 minutes.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).

- The PCM will store as Failure Records only conditions which were present when the DTC was set. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P0563 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0563 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

If the DTC sets when an accessory is operated, check for a poor connection or defective accessory.

DTC P0563 – System Voltage High

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Using a DVM, measure the battery voltage at the battery. Is the battery voltage less than the specified value?	11.5 V	Go to Step 3	Go to Step 4
3	1. Charge the battery and clean the battery terminals. 2. Clean the battery ground cable connection if corrosion is indicated. Is the battery voltage less than the specified value?	11.5 V	Replace battery	Go to Step 4
4	1. Turn "OFF" all the accessories. 2. Install a Tech 2. 3. Select the ignition voltage parameter on the Tech 2. 4. Start the engine and raise the engine RPM to the specified value. Is the voltage more than 2.5 volts greater than the measurement taken in step 2 or 3?	2000 RPM	Go to <i>Starting/Charging</i>	Go to Step 5
5	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P0601 PCM Memory

Circuit Description

The powertrain control module (PCM) used in this vehicle utilizes an electrically erasable programmable read-only memory (EEPROM). The EEPROM contains program information and the calibrations required for engine, transmission, and powertrain diagnostics operation. Unlike the PROM used in past applications, the EEPROM is not replaceable. When the PCM is replaced or a calibration update is required, the PCM must be programmed using a Tech 2. Refer to *On-Vehicle Service* in *Powertrain Control Module and Sensors* for the EEPROM programming procedure.

Conditions for Setting the DTC

- The PCM detects an internal program fault (check sum error).

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).

- The PCM will store conditions which were present when the DTC was set in the Failure Records data only.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P0601 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P0601 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

- DTC P0601 indicates that the contents of the EEPROM have changed since the PCM was programmed. The only possible repair is PCM replacement. Remember to program the replacement PCM with the correct software and calibration for the vehicle.

DTC P0601 – PCM Memory

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest Service Bulletin.</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—


- Inspect the wiring harness for damage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1106 –MAP Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Is DTC P0108 also set?	—	Go to <i>DTC P0108</i> chart first	Go to Step 3
3	Are DTC P1111, P1115, and/or P1121 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor sensor ground circuit terminal connection at the MAP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the MAP signal circuit between the MAP sensor connector and the PCM for an intermittent short to voltage. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to voltage on the 5 volt reference "A" circuit between the PCM and the following components: ○ MAP sensor ○ EGR valve ○ TP sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor sensor ground circuit terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the sensor ground circuit. Was a problem found?	—	Go to Step 10	Refer to <i>Diagnostic Aids</i>
9	Replace the faulty harness connector terminal for the sensor ground circuit. Is the action complete?	—	Verify repair	—
10	Locate and repair the intermittent open/short circuit in the wiring harness as necessary. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1107 MAP Sensor Circuit Intermittent Low Voltage



D06RX015

Circuit Description

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure (vacuum). The MAP sensor signal voltage to the powertrain control module (PCM) varies from below 2 volts at idle (high vacuum) to above 4 volts with the ignition "ON," engine not running or at wide-open throttle (low vacuum). The MAP sensor is used to determine manifold pressure changes while the linear EGR flow test diagnostic is being run (refer to *DTC P0401*), to determine engine vacuum level for some other diagnostics and to determine barometric pressure (BARO). The PCM compares the MAP sensor signal to a calculated MAP based on throttle position and various engine load factors. If the PCM detects a MAP signal that is intermittently below the calculated value, DTC P1107 will be set.

Conditions for Setting the DTC

- ☐ No TP sensor DTCs are present.
- ☐ Engine is running.
- ☐ Ignition voltage is more than 11 volts.
- ☐ Throttle angle is above 1% if engine speed is less than 1000 RPM.
- ☐ Throttle angle is above 2% if engine speed is above 1000 RPM.
- ☐ The MAP sensor indicates an intermittent manifold absolute pressure below 11 kPa for a total of

approximately 5 seconds over a 16-second period of time.

Action Taken When the DTC Sets

- ☐ The PCM will not illuminate the malfunction indicator lamp (MIL).
- ☐ The PCM will store conditions which were present when the DTC was set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- ☐ A history DTC P1107 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P1107 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- ☐ The MAP sensor shares a 5 Volt Reference with the Rough Road sensor. If these codes are also set, it could indicate a problem with the 5 Volt reference circuit.
- ☐ The MAP sensor share a ground with the Rough Road Sensor and the ECT Sensor. Check the ground if these other DTCs are also set.
- ☐ Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken

locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- The TP Sensor shares a 5 Volt reference with the EGR Valve.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.

- The TP Sensor share a ground with the EGR Valve and the IAT Sensor.


- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the MAP display on the Tech 2 while moving connectors and wiring harnesses related to the sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1107 –MAP Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Is DTC P0107 also set?	—	Go to <i>DTC P0107</i> chart first	Go to Step 3
3	Is DTC P1122 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor 5 volt reference "A" circuit or MAP signal circuit terminal connection at the MAP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the MAP signal circuit between the MAP sensor connector and the PCM for an intermittent open or short to ground. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to ground on the 5 volt reference "A" circuit between the PCM and the following components: ○ MAP sensor ○ EGR valve ○ TP sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor 5 volt reference "A" terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the 5 volt reference "A" circuit. Was a problem found? (If no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to <i>Diagnostic Aids</i>
9	Replace the faulty harness connector terminal(s) for the 5 volt reference "A" circuit and/or the MAP signal circuit as necessary. Is the action complete?	—	Verify repair	—
10	Repair intermittent open/short circuit in the wiring harness as necessary. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1111 IAT Sensor Circuit Intermittent High Voltage



D06RW078

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance is lower causing the PCM to monitor a lower voltage. DTC P1111 will set when the PCM intermittently detects an excessively high signal voltage on the intake air temperature sensor signal circuit.

Conditions for Setting the DTC

- The engine has been running for over 4 minutes.
- Vehicle speed is less than 20 mph (32 km/h).
- Engine coolant temperature is above 60°C (140°F).
- Mass air flow is less than 20g/second.
- IAT signal voltage indicates and intake air temperature intermittently less than -39°C (-38°F) (about 5 volts) for approximately 2.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will substitute a default value for intake air temperature.

- The PCM will store conditions which were present when the DTC set as Failure Records data only. This information will not be stored as Freeze Frame data.
- DTC P1111 does not illuminate the MIL.

Conditions for Clearing the MIL/DTC

- A history DTC P1111 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1111 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1111 –IAT Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Is DTC P0113 also set?	—	Go to <i>DTC P0113</i> chart first	Go to <i>Step 3</i>
3	Is DTC P1106, P1115, and/or P1121 also set?	—	Go to <i>Step 6</i>	Go to <i>Step 4</i>
4	1. Check for a poor sensor ground circuit terminal connection at the IAT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 5</i>
5	1. Check for a poor IAT signal circuit terminal connection at the IAT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 6</i>
6	1. Check the IAT signal circuit between the IAT sensor connector and the PCM for an intermittent open. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 7</i>
7	1. Check the IAT signal circuit between the IAT sensor connector and the PCM for an intermittent short to voltage. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 8</i>
8	1. Check for a poor sensor ground circuit terminal connection at the PCM. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 9</i>
9	1. Check for an intermittent open or a faulty splice in the sensor ground circuit. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to <i>Diagnostic Aids</i>

Diagnostic Trouble Code (DTC) P1112 IAT Sensor Circuit Intermittent Low Voltage



D06RW078

Circuit Description

The intake air temperature (IAT) sensor is a thermistor which measures the temperature of the air entering the engine. The powertrain control module (PCM) applies 5 volts through a pull-up resistor to the IAT sensor. When the intake air is cold, the sensor resistance is high and the PCM will monitor a high signal voltage on the IAT signal circuit. If the intake air is warm, the sensor resistance becomes lower, causing the PCM to monitor a lower voltage. DTC P1112 will set when the PCM intermittently detects an excessively low signal voltage on the intake air temperature sensor signal circuit.

Conditions for Setting the DTC

- The engine has been running for over 2 minutes.
- Vehicle speed is greater than 30 mph (48 km/h).
- IAT signal voltage is greater than 148°C (298°F) (about 0.10 volt) for a total of 2.5 seconds over a 25-second period of time.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records data only. This information will not be stored as Freeze Frame data.

- The PCM will substitute a default value for intake air temperature.

Conditions for Clearing the MIL/DTC

- A history DTC P1112 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1112 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the IAT display on the Tech 2 while moving connectors and wiring harnesses related to the IAT sensor. A change in the IAT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

2. Verifies that the fault is present.
3. If DTC P1112 can be repeated only by duplicating the Failure Records conditions, refer to the "Temperature vs. Resistance Value Chart." The chart may be used to test the IAT sensor at various temperatures to evaluate the possibility of a "shifted" sensor that may be shorted above or below a certain temperature. If this is the case, replace the IAT sensor.


Intake Air Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1112 –IAT Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Is DTC P0112 also set?	—	Go to <i>DTC P0112</i> first	Go to <i>Step 3</i>
3	1. Check the IAT signal circuit between the IAT sensor connector and the PCM for an intermittent short to ground. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to <i>Diagnostic Aids</i>

Diagnostic Trouble Code (DTC) P1114 ECT Sensor Circuit Intermittent Low Voltage



D06RW058

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in the engine coolant stream. The powertrain control module (PCM) applies a voltage (about 5.0 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes less, and the ECT signal voltage measured at the PCM drops. With a fully warmed up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts. If the PCM detects an ECT signal that is intermittently below the range of the ECT sensor, DTC P1114 will set.

Conditions for Setting the DTC

- Engine run time longer than 60 seconds.
- The ECT sensor signal is intermittently greater than 150°C (302°F) (about 0.10 volt) for a total of 10 seconds over a 100-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).

- The PCM will store conditions which were present when the DTC set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P1114 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1114 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


Engine Coolant Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1114 –ECT Sensor Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Is DTC P0117 also set?	—	Go to <i>DTC P0117</i> first	Go to <i>Step 3</i>
3	1. Check the ECT signal circuit between the ECT sensor connector and the PCM for an intermittent short to ground. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to <i>Diagnostic Aids</i>

Diagnostic Trouble Code (DTC) P1115 ECT Sensor Circuit Intermittent High Voltage



D06RW058

Circuit Description

The engine coolant temperature (ECT) sensor is a thermistor mounted in the engine coolant stream. The powertrain control module (PCM) applies a voltage (about 5.0 volts) through a pull-up resistor to the ECT signal circuit. When the engine coolant is cold, the sensor (thermistor) resistance is high, therefore the PCM will measure a high signal voltage. As the engine coolant warms, the sensor resistance becomes less, and the ECT signal voltage measured at the PCM drops. With a fully warmed up engine, the ECT signal voltage should measure about 1.5 to 2.0 volts. If the PCM detects an ECT signal that is intermittently above the range of the ECT sensor, DTC P1115 will set.

Conditions for Setting the DTC

- Engine running time longer than 90 seconds.
- The ECT sensor signal is intermittently greater than -39°C (-38°F) (about 5 volts) for a total of 10 seconds over a 100-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).

- The PCM will store conditions which were present when the DTC was set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P1115 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1115 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the ECT display on the Tech 2 while moving connectors and wiring harnesses related to the ECT sensor. A change in the ECT display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Engine Coolant Temperature Sensor

°C	°F	OHMS
Temperature vs. Resistance Values (approximate)		
100	212	177
80	176	332
60	140	667
45	113	1188
35	95	1802
25	77	2796
15	59	4450
5	41	7280
-5	23	12300
-15	5	21450
-30	-22	52700
-40	-40	100700

DTC P1115 –ECT Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	Is DTC P0118 also set?	—	Go to <i>DTC P0118</i> chart first	Go to <i>Step 3</i>
3	Is DTC P1106, P1111, and/or P1121 also set?	—	Go to <i>Step 8</i>	Go to <i>Step 4</i>
4	1. Check for a poor sensor ground circuit terminal connection at the ECT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 5</i>
5	1. Check for a poor ECT signal circuit terminal connection at the ECT sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 6</i>
6	1. Check the ECT signal circuit between the ECT sensor connector and the PCM for an intermittent open. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 7</i>
7	1. Check the ECT signal circuit between the ECT sensor connector and the PCM for an intermittent short to voltage. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 8</i>
8	1. Check for a poor sensor ground circuit terminal connection at the PCM. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 9</i>
9	1. Check for an intermittent open or a faulty splice in the sensor ground circuit. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Refer to <i>Diagnostic Aids</i>



The throttle position (TP) sensor circuit provides voltage signal that changes relative to the throttle blade angle. The signal voltage will vary from about 0.6 volts at closed throttle to about 4.5 volts at wide open throttle (WOT). The TP signal is one of the most important inputs used by the powertrain control module (PCM) for fuel control and for most of the PCM controlled outputs. If the PCM detects a TP signal that is intermittently above the range of the TP sensor, DTC P1121 will be set.

Conditions for Setting the DTC

- The ignition is “ON.”
- TP sensor indicates a throttle position voltage intermittently greater than 4.9 volts for a total of 0.15 seconds over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P1121 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P1121 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect the harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The TP Sensor shares a 5 Volt reference with the EGR Valve.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.

- The TP Sensor share a ground with the EGR Valve and the IAT Sensor.

Check the ground if these other DTCs are also set.

- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the throttle position display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.

If DTC P1121 cannot be duplicated, reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help to determine how often the condition that

caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1121 –TP Sensor Circuit Intermittent High Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to OBD System Check
2	Is DTC P0123 also set?	—	Go to DTC P0123 first	Go to Step 3
3	Is DTC P1111, P1115, and/or P1106 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor sensor ground circuit terminal connection at the TP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the TP signal circuit between the TP sensor connector and the PCM for an intermittent short to voltage. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to voltage on the 5 volt reference "A" circuit between the PCM and the following components: ○ MAP sensor ○ EGR valve ○ TP sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor sensor ground terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the sensor ground circuit. Was a problem found? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to Diagnostic Aids
9	Replace the faulty harness connector terminal for the sensor ground circuit. Is the action complete?	—	Verify repair	—
10	Repair intermittent open/short circuit in wiring harness as necessary. Is the action complete?	—	Verify repair	—



The throttle position (TP) sensor circuit provides voltage signal that changes relative to the throttle blade angle. The signal voltage will vary from about 0.6 volts at closed throttle to about 4.5 volts at wide open throttle (WOT). The TP signal is one of the most important inputs used by the powertrain control module (PCM) for fuel control and for most of the PCM controlled outputs. If the PCM detects a TP signal that is intermittently above the range of the TP sensor, DTC P1121 will be set.

Conditions for Setting the DTC

- The ignition is "ON."
- TP sensor indicates a throttle position signal intermittently less than 0.22 volt for a total of 0.15 seconds over a 1.5-second period.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records data only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P1122 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P1122 can be cleared by using the Tech 2 “Clear Info” function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- The TP Sensor shares a 5 Volt reference with the EGR Valve.

If these codes are also set, it could indicate a problem with the 5 Volt reference circuit or components itself.

- The TP Sensor share a ground with the EGR Valve and the IAT Sensor.

Check the ground if these other DTCs are also set.


- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, observe the throttle position display on the Tech 2 while moving connectors and wiring harnesses related to the TP sensor. A change in the display will indicate the location of the fault.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help to determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1122 –TP Circuit Intermittent Low Voltage

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Is DTC P0122 also set?	—	Go to <i>DTC P0122</i> first	Go to Step 3
3	Is DTC P1107 also set?	—	Go to Step 6	Go to Step 4
4	Check for a poor 5 volt reference "A" circuit or TP signal circuit terminal connection at the TP sensor. Was a problem found?	—	Go to Step 9	Go to Step 5
5	Check the TP signal circuit between the TP sensor connector and the PCM for an intermittent open or short to ground. Was a problem found?	—	Go to Step 10	Go to Step 8
6	Check for an intermittent short to ground on the 5 volt reference "A" circuit between the PCM and the following components: ○ MAP sensor ○ EGR valve ○ TP sensor Was a problem found?	—	Go to Step 10	Go to Step 7
7	Check for a poor 5 volt reference "A" circuit terminal connection at the PCM. Was a problem found?	—	Go to Step 9	Go to Step 8
8	Check for an intermittent open or a faulty splice in the 5 volt reference "A" circuit. Was a problem found? (if no, start with the diagnosis chart for other sensors in the circuit and see if 5V returns.)	—	Go to Step 10	Refer to <i>Diagnostic Aids</i>
9	Replace the faulty harness connector terminal(s) for the 5 volt reference "A" circuit and/or the TP signal circuit as necessary. Is the action complete?	—	Repair complete. If a driveability symptom still exists, refer to <i>Symptoms</i> .	—
10	Repair the intermittent open/short circuit in wiring harness as necessary. Is the action complete?	—	Repair complete. If a driveability symptom still exists, refer to <i>Symptoms</i> .	—

Diagnostic Trouble Code (DTC) P1133 HO2S Insufficient Switching Bank 1 Sensor 1



D06RW060

Circuit Description

The powertrain control module (PCM) monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "closed loop" and stoichiometric operation have been enabled. During this test period the PCM counts the number of times that the HO2S signal voltage crosses the rich-to-lean and lean-to-rich threshold. If the PCM determines that the HO2S did not switch enough times, DTC P1133 will be set.

A lean-to-rich switch is determined when the HO2S voltage changes above and below 450 mV.

Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature for accurate exhaust oxygen content readings further from the engine.

Conditions for Setting the DTC

- Engine coolant temperature (ECT) is above 50°C (122°F) for automatic transmission; 75°C (167°F) for manual transmission.
- Engine is operating in "closed loop".
- The engine has been running at least one minute.

- Canister purge duty cycle is greater than 2%.
- Engine speed is between 1500 RPM and 3000 RPM.
- Mass air flow (MAF) is between 9 g/second and 42 g/second.
- Above conditions are present for 3 seconds.
- 90 seconds after "closed loop" and stoichiometric operation have been achieved, the PCM monitors the oxygen sensor as it switches above and below 450 mV. If fewer than 23 rich-to-lean and lean-to-rich switches are detected, DTC P1133 will be set.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- "Open loop" fuel control will be in effect.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1133 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1133 can be cleared by using Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

A malfunction in the HO2S heater ignition feed or ground circuit may cause a DTC P1133 to set. Check HO2S heater circuitry for intermittent faults or poor connections. If connections and wiring are OK and DTC P1133 continues to set, replace the Bank 1 HO2S 1.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help to determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. A condition that affects other heated oxygen sensors indicates probable contamination. To avoid damaging the replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

5. This step checks for conditions which may cause the heated oxygen sensor to appear faulty. Correct any of the described conditions if present.

11. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

DTC P1133 –HO2S Insufficient Switching Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	IMPORTANT: If any DTCs are set (except P1153 or P1154) refer to those DTCs before proceeding with this diagnostic chart. 1. Engine idling at operating temperature. 2. Operating the vehicle within parameters specified under "Conditions for Setting the DTC" criteria included in Diagnostic Support. 3. Using a Tech 2, monitor "DTC" info for DTC P1133 until the DTC P1133 test runs. 4. Note the test result. Does the Tech 2 indicate DTC P1133 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	Did the Tech 2 also indicate that the P1153 or P1154 tests failed?	—	Go to Step 20	Go to Step 4
4	Check for leaks at the exhaust pipe joints. Are the joints leaking?	—	Go to Step 5	Go to Step 6
5	Tighten the bolt/nuts at the leaking joints. Is your action complete?	—	Go to Step 2	—
6	Check for gaskets that are damaged or improperly installed. Are there damaged or misaligned gaskets?	—	Go to Step 7	Go to Step 8
7	1. Replace the damaged gaskets. 2. Align the connections. 3. Tighten the connections. Is your action complete?	—	Go to Step 2	—
8	Check for loose exhaust flange connections. Are the flange connections loose?	—	Go to Step 9	Go to Step 10
9	Tighten the stud nuts or bolts to specifications. Is your action complete?	—	Go to Step 2	—
10	Check for burned or corroded exhaust pipes. Are the exhaust pipes burned or corroded?	—	Go to Step 11	Go to Step 12


DTC P1133 –HO2S Insufficient Switching Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
11	Replace the exhaust pipes, as required. Is your action complete?	—	Go to Step 2	—
12	Check for leaks at the exhaust manifold. Are there leaks at the exhaust manifold?	—	Go to Step 13	Go to Step 14
13	Tighten the bolts to specifications or replace the manifold if necessary. Is your action complete?	—	Go to Step 2	—
14	Visually/physically inspect the following items: <ul style="list-style-type: none"> ○ Ensure that the Bank 1 HO2S 1 is securely installed. ○ Check for corrosion on the terminals. ○ Check the terminals at Bank 1 HO2S 1 and at the PCM. ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Verify repair	Go to Step 15
15	1. Disconnect Bank 1 HO2S 1. 2. Ignition "ON." 3. Using a DVM at the PCM side of the connector, check the voltage between the high signal circuit and ground. Also measure between the low signal circuit and ground. Are both voltages in the specified range?	3-4 mV	Go to Step 18	Go to Step 16
16	1. Ignition "OFF." 2. Check for damage to PCM pins or terminals. Was a problem found.	—	Verify repair	Go to Step 17
17	Check for a short to voltage or ground or an open in the signal circuit. Was a problem found?	—	Verify repair	Go to Step 18
18	1. Ignition "OFF." 2. Disconnect the PCM connector. 3. With the HO2S disconnected, check for high and low signal circuits shorted together between the PCM and HO2S. Was a problem found?	—	Verify repair	Go to Step 19
19	With the PCM connected and Bank 1 HO2S 1 disconnected from the harness, check Bank 1 HO2S 1 with a Tech 2. Is the voltage in the specified range?	425-475 mV	Go to Step 21	Go to Step 22
20	Replace the affected heated oxygen sensors. NOTE: Before replacing the sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination ○ Use of improper RTV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—

DTC P1133 –HO2S Insufficient Switching Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
21	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
22	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. and also refer to latest service bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action compete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1134 HO2S Transition Time Ratio Bank 1 Sensor 1



D06RW060

Circuit Description

The powertrain control module (PCM) monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "closed loop" and stoichiometric operation have been established. During the monitoring period the PCM counts the number of times that the HO2S responds from rich-to-lean and from lean-to-rich and adds the amount of time it took to complete all transitions. With this information, an average time for all transitions can be determined. The PCM then divides the rich-to-lean average by the lean-to- rich average to obtain a ratio. If the HO2S transition time ratio is not within this range, DTC P1134 will be set, indicating that the oxygen sensor is not responding as expected to changes in exhaust oxygen content.

Conditions for Setting the DTC

- No related DTCs.
- Engine coolant temperature (ECT) is above 50°C (122°F) for automatic transmission; 75°C (167°F) for manual transmission.
- Engine is operating in "closed loop."
- The engine has been running for at least one minute.
- Canister purge duty cycle is greater than 2%.
- Engine speed is between 1500 RPM and 3000 RPM.
- Mass air flow (MAF) is between 9 g/second and 42 g/second.

- Above conditions are present for a 3-second monitoring period.
- 90 seconds after "closed loop" and stoichiometric operation have been enabled, Bank 1 HO2S 1 transition ratio between lean-to-rich and rich-to-lean is less than 0.44 or greater than 3.8.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after second consecutive trip in which the fault is detected.
- "Open loop" fuel control will be in effect.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1134 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1134 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

A malfunction in the HO2S heater ignition feed or ground circuit may cause a DTC P1134 to set. Check HO2S heater circuitry for intermittent faults or poor connections. If connections and wiring are OK and DTC P1134 continues to set, replace the Bank 1 HO2S 1.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

3. A condition that affects other heated oxygen sensors indicates probable contamination. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.
5. This step checks for conditions which may cause the heated oxygen sensor to appear faulty. Correct any of the described conditions if present.
8. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

DTC P1134 –HO2S Transition Time Ratio Bank 1 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	IMPORTANT: If any DTCs are set (except P1153 and/or P1154), refer to those DTCs before proceeding with this diagnostic chart. 1. Idle the engine at operating temperature. 2. Operate the vehicle within parameters specified under "Conditions for Setting the DTC" criteria included in Diagnostic Support. 3. Using a Tech 2, monitor "DTC" info for DTC P1134 until the DTC P1134 test runs. 4. Note the test result. Does Tech 2 indicate DTC 1134 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	Did the Tech 2 also indicate P1153, and/or P1154 test failed?	—	Go to Step 17	Go to Step 4
4	Check for leaks at the exhaust pipe joints. Are the joints leaking?	—	Go to Step 5	Go to Step 6
5	Tighten the U-bolt nuts at the leaking joints. Is your action complete?	—	Go to Step 2	—
6	Check for gaskets that are damaged or improperly installed. Are there damaged or misaligned gaskets?	—	Go to Step 7	Go to Step 8
7	1. Replace the damaged gaskets. 2. Align the connections. 3. Tighten the connections. Is your action complete?	—	Go to Step 2	—
8	Check for loose exhaust flange connections. Are the flange connections loose?	—	Go to Step 9	Go to Step 10
9	Tighten the stud nuts or bolts to specifications. Is your action complete?	—	Go to Step 2	—
10	Check for burned or corroded exhaust pipes. Are the exhaust pipes burned or corroded?	—	Go to Step 11	Go to Step 12


DTC P1134 –HO2S Transition Time Ratio Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
11	Replace the exhaust pipes, as required. Is your action complete?	—	Go to Step 2	—
12	Check for leaks at the exhaust manifold. Are there leaks at the exhaust manifold?	—	Go to Step 13	Go to Step 14
13	Tighten the bolts to specifications or replace the manifold if necessary. Is your action complete?	—	Go to Step 2	—
14	Visually/physically inspect the following items: <ul style="list-style-type: none"> ○ Ensure that the Bank 1 HO2S 1 is securely installed. ○ Check for corrosion on terminals. ○ Check the terminal tension (at Bank 1 HO2S 1 and at the PCM). ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Go to Step 18	Go to Step 15
15	1. Disconnect Bank 1 HO2S 1. 2. Ignition "ON." 3. Using a DVM at the PCM side of the HO2S 1 connector, measure the voltage between the high signal circuit and ground. 4. Also measure the voltage between the low signal circuit and ground. Are both voltages in the specified range?	3-4V	Go to Step 16	Go to Step 19
16	1. With Bank 1 HO2S 1 disconnected, jumper the high and low (PCM side) signal circuits to ground. 2. Ignition "ON." 3. Using a Tech 2, monitor the Bank 1 HO2S 1 voltage. Does the Tech 2 indicate less than 10 mV and immediately return to about 450 mV when the jumper is removed?	—	Go to Step 21	Go to Step 22
17	Replace affected heated oxygen sensors. NOTE: Before replacing sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination. ○ Use of improper RTV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—
18	Repair condition as necessary. Is the action complete?	—	Verify repair	—
19	Check for faulty PCM connections or terminal damage. Is the action complete?	—	Verify repair	Go to Step 20
20	Repair open, short or grounded signal circuit. Is the action complete?	—	Verify repair	Go to Step 7

DTC P1134 –HO2S Transition Time Ratio Bank 1 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
21	Replace Bank 1 HO2S 1. Is the action complete?	—	Verify repair	—
22	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1153 HO2S Insufficient Switching Bank 2 Sensor 1



D06RW064

Circuit Description

The powertrain control module (PCM) monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "closed loop" and stoichiometric operation have been enabled. During this test period the PCM counts the number of times that the HO2S signal voltage crosses the rich-to-lean and lean-to-rich thresholds. If the PCM determines that the HO2S did not switch enough times, DTC P1153 will be set.

A lean-to-rich switch is determined when the HO2S voltage changes above and below 450 mV.

Heated oxygen sensors are used to minimize the amount of time required for "closed loop" fuel control operation and to allow accurate catalyst monitoring. The oxygen sensor heater greatly decreases the amount of time required for fuel control sensors Bank 1 HO2S 1 and Bank 2 HO2S 1 to become active. Oxygen sensor heaters are required by post-catalyst monitor sensors to maintain a sufficiently high temperature for accurate exhaust oxygen content readings further from the engine.

Conditions for Setting the DTC

- The engine is operating in "closed loop."
- Engine coolant temperature (ECT) is above 50°C (122°F) for automatic transmission; 75°C (167°F) for manual transmission.
- The engine has been running at least one minute.

- Canister purge duty cycle is greater than 2%.
- Engine speed is between 1500 RPM and 3000 RPM.
- Mass air flow is between 9 g/second and 42 g/second.
- Above conditions are present for a 3 seconds.
- 90 seconds after "closed loop" and stoichiometric operation have been enabled, the PCM monitors the oxygen sensor switching above and below 450 mV. If fewer than 27 rich-to-lean and lean-to-rich switches for Bank 2 HO2S 1 are detected, DTC P1153 will set.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- "Open loop" fuel control will be in effect.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1153 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1153 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

A malfunction in the HO2S heater ignition feed or ground circuit may cause a DTC P1153 to set. Check HO2S heater circuitry for intermittent faults or poor connections. If connections and wiring are OK and DTC P1153 continues to set, replace the Bank 2 HO2S 1.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

3. A condition that affects other heated oxygen sensors indicates probable contamination. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.
5. This step checks for conditions which may cause the heated oxygen sensor to appear faulty. Correct any of the described conditions if present.
8. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

DTC P1153 –HO2S Insufficient Switching Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	IMPORTANT: If any DTCs are set, (except P1133 and/or P1134), refer to those DTCs before proceeding with this diagnostic chart. 1. Idle the engine at operating temperature. 2. Operate the vehicle within parameters specified under "Conditions for Setting the DTC" criteria included in Diagnostic Support. 3. Using a Tech 2, monitor "DTC" info for DTC P1153 until the DTC P1153 test runs. Note the test result. Does Tech 2 indicate DTC failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	Did the Tech 2 also indicate P1133 and/or P1134 test failed?	—	Go to Step 20	Go to Step 4
4	Check for leaks at the exhaust pipe joints. Are the joints leaking?	—	Go to Step 5	Go to Step 6
5	Tighten the U-bolt nuts at the leaking joints. Is your action complete?	—	Go to Step 2	—
6	Check for gaskets that are damaged or improperly installed. Are there damaged or misaligned gaskets?	—	Go to Step 7	Go to Step 8
7	1. Replace the damaged gaskets. 2. Align the connections. 3. Tighten the connections. Is your action complete?	—	Go to Step 2	—
8	Check for loose exhaust flange connections. Are the flange connections loose?	—	Go to Step 9	Go to Step 10
9	Tighten the stud nuts or bolts to specifications. Is your action complete?	—	Go to Step 2	—
10	Check for burned or corroded exhaust pipes. Are the exhaust pipes burned or corroded?	—	Go to Step 11	Go to Step 12


DTC P1153 –HO2S Insufficient Switching Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
11	Replace the exhaust pipes, as required. Is your action complete?	—	Go to Step 2	—
12	Check for leaks at the exhaust manifold. Are there leaks at the exhaust manifold?	—	Go to Step 13	Go to Step 14
13	Tighten the bolts to specifications or replace the manifold if necessary. Is your action complete?	—	Go to Step 2	—
14	Visually/physically inspect the following items: <ul style="list-style-type: none"> ○ Ensure that the Bank 2 HO2S 1 is securely installed. ○ Check for corrosion on terminals. ○ Check the terminal tension at Bank 2 HO2S 1 and at the PCM. ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Verify repair	Go to Step 15
15	1. Disconnect Bank 2 HO2S 1. 2. Ignition "ON." 3. Using a DVM at the PCM side of the connector, check the voltage between the high signal circuit and ground. Also measure between the low signal circuit and ground. Are both voltages in the specified range?	3-4V	Go to Step 18	Go to Step 16
16	1. Ignition "ON." 2. Check for damage to PCM pins or terminals. Was a problem found?	—	Verify repair	Go to Step 17
17	Check for short to voltage or ground or an open in the signal circuit. Was a problem found?	—	Verify repair	Go to Step 18
18	1. Ignition "OFF." 2. Disconnect the PCM connector. 3. With HO2S disconnected, check for high and low signal circuits shorted together between the PCM and HO2S. Was a problem found?	—	Verify repair	Go to Step 19
19	With the PCM connected and Bank 2 HO2S 1 disconnected from the harness, check Bank 2 HO2S 1 with a Tech 2. Is the voltage in the specified range?	425-475 mV	Go to Step 21	Go to Step 22
20	Replace affected heated oxygen sensors. NOTE: Before replacing sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination. ○ Use of improper RTV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—

DTC P1153 –HO2S Insufficient Switching Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
21	Replace Bank 2 HO2S 1. Is the action complete?	—	Verify repair	—
22	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1154 HO2S Circuit Transition Time Ratio Bank 2 Sensor 1



D06RW064

Circuit Description

The powertrain control module (PCM) monitors the heated oxygen sensor (HO2S) activity for 90 seconds after "closed loop" and stoichiometric operation have been enabled. During the monitor period the PCM counts the number of times that the HO2S responds from rich-to-lean and from lean-to-rich and adds the amount of time it took to complete all transitions. With this information, an average time for all transitions can be determined. The PCM then divides the rich-to-lean average by the lean-to-rich average to obtain a ratio. If the HO2S transition time ratio is not within this range, DTC P1154 will be set, indicating that the oxygen sensor is not responding as expected to changes in exhaust oxygen content.

Conditions for Setting the DTC

- No related DTCs.
- Engine coolant temperature (ETC) is above 50°C (122°F) for automatic transmission; 75°C (167°F) for manual transmission.
- The engine is operating in "closed loop."
- The engine has been running for at least one minute.
- Canister purge duty cycle is greater than 2%.
- Engine speed is between 1500 RPM and 3000 RPM.
- Mass air flow is between 9 g/second and 42 g/second.
- Above conditions are present for a 3-second monitoring period.

- 90 seconds after "closed loop" and stoichiometric operation have been enabled, Bank 2 HO2S 1 transition ratio between lean to rich and rich to lean is less than 0.44 or greater than 3.8.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- "Open loop" fuel control will be in effect.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1154 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1154 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

A malfunction in the HO2S heater ignition feed or ground circuit may cause a DTC P1154 to set. Check HO2S heater circuitry for intermittent faults or poor connections. If connections and wiring are OK and DTC P1154 continues to set, replace the Bank 2 HO2S 1.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

3. A condition that affects other heated oxygen sensors indicates probable contamination. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

5. This step checks for conditions which may cause the heated oxygen sensor to appear faulty. Correct any of the described conditions if present.

8. To avoid damaging replacement sensors, correct the condition which caused the contamination before replacing the affected sensors.

DTC P1154 –HO2S Transition Time Ratio Bank 2 Sensor 1

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	IMPORTANT: If any other DTCs are set (except P1133 and/or P1134), refer to those DTCs before proceeding with this diagnostic chart. 1. Idle the engine at operating temperature. 2. Operate the vehicle within parameters specified under "Conditions for Setting the DTC" criteria included in Diagnostic Support. 3. Using a Tech 2, monitor "DTC" info for DTC P1154 until the DTC P1154 test runs. Note the test result. Does Tech 2 indicate DTC failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	Did the Tech 2 also indicate P1133, and/or P1134 test failed?	—	Go to Step 17	Go to Step 4
4	Check for leaks at the exhaust pipe joints. Are the joints leaking?	—	Go to Step 5	Go to Step 6
5	Tighten the U-bolt nuts at the leaking joints. Is your action complete?	—	Go to Step 2	—
6	Check for gaskets that are damaged or improperly installed. Are there damaged or misaligned gaskets?	—	Go to Step 7	Go to Step 8
7	1. Replace the damaged gaskets. 2. Align the connections. 3. Tighten the connections. Is your action complete?	—	Go to Step 2	—
8	Check for loose exhaust flange connections. Are the flange connections loose?	—	Go to Step 9	Go to Step 10
9	Tighten the stud nuts or bolts to specifications. Is your action complete?	—	Go to Step 2	—
10	Check for burned or corroded exhaust pipes. Are the exhaust pipes burned or corroded?	—	Go to Step 11	Go to Step 12
11	Replace the exhaust pipes, as required. Is your action complete?	—	Go to Step 2	—


DTC P1154 –HO2S Transition Time Ratio Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
12	Check for leaks at the exhaust manifold. Are there leaks at the exhaust manifold?	—	Go to Step 13	Go to Step 14
13	Tighten the bolts to specifications or replace the manifold if necessary. Is your action complete?	—	Go to Step 2	—
14	Visually/physically inspect the following items: <ul style="list-style-type: none"> ○ Ensure that the Bank 2 HO2S 1 is securely installed. ○ Check for corrosion on terminals. ○ Check terminal tension (at Bank 2 HO2S 1 and at the PCM). ○ Check for damaged wiring. Was a problem found in any of the above areas?	—	Go to Step 18	Go to Step 15
15	1. Disconnect Bank 2 HO2S 1. 2. Ignition "ON." 3. Using a DVM at the PCM side of the HO2S 1 connector, measure the voltage between the high signal circuit and ground. 4. Also measure the voltage between the low signal circuit and ground. Are both voltages in the specified range?	3-4V	Go to Step 16	Go to Step 19
16	1. With Bank 2 HO2S 1 disconnected, jumper the high and low (PCM side) signal circuits to ground. 2. Ignition "ON." 3. Using a Tech 2, monitor the Bank 2 HO2S 1 voltage. Does the Tech 2 indicate less than 10 mV and immediately return to about 450 mV when the jumper is removed?	—	Go to Step 21	Go to Step 22
17	Replace affected heated oxygen sensors. NOTE: Before replacing sensors, the cause of the contamination must be determined and corrected. <ul style="list-style-type: none"> ○ Fuel contamination. ○ Use of improper RTV sealant. ○ Engine oil/coolant consumption. Is the action complete?	—	Verify repair	—
18	Repair condition as necessary. Is the action complete?	—	Verify repair	—
19	Check for faulty PCM connections or terminal damage. Is the action complete?	—	Verify repair	Go to Step 20
20	Repair open, short or grounded signal circuit. Is the action complete?	—	Verify repair	—

DTC P1154 –HO2S Transition Time Ratio Bank 2 Sensor 1 (Cont'd)

Step	Action	Value(s)	Yes	No
21	Replace Bank 2 HO2S 1. Is the action complete?	—	Verify repair	—
22	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest Service Bulletin. Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1171 Fuel System Lean During Acceleration



D06RX023

Circuit Description

The powertrain control module (PCM) internal circuitry can identify if the vehicle fuel system is capable of supplying adequate amounts of fuel during heavy acceleration (power enrichment). The PCM monitors the voltage of the oxygen sensor during power enrichment. When a power enrichment mode of operation is requested during "closed loop" operation (by heavy acceleration), the PCM will provide more fuel to the engine. Under these conditions the PCM should detect a "rich" condition (high oxygen sensor voltage). If this "rich" exhaust is not detected at this time, a DTC P1171 will set. A plugged fuel filter, restricted fuel line, restricted in-tank filter or defective fuel pump can prevent adequate amounts of fuel from being supplied during power enrichment mode.

Conditions for Setting the DTC

- No related DTCs.

- Engine is operating in "closed loop power enrichment" mode for 3 seconds.
- Engine coolant temperature is above 60°C (140°F).
- While in "power enrichment" mode the oxygen sensor voltage remains below 400 mV for 3 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) the first the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1171 will clear after 40 consecutive warm-up cycles have occurred without a fault.

- DTC P1171 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

- A restricted fuel filter or fuel line, restricted in-tank filter, or a defective fuel pump may supply adequate amounts of fuel at idle, but may not be able to supply enough fuel during heavy acceleration.
- Water or alcohol in the fuel may cause low HO2S voltage during acceleration.
- Check for faulty or plugged fuel injector(s).
- Check for low fuel.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

4. When the engine is idling or at steady cruise, the HO2S voltage should vary from between approximately 100 mV to 900 mV. It is possible to measure a satisfactory fuel pressure at idle even though the pressure may drop at high flow requirements. It may be necessary to watch fuel pressure at high engine load.
5. Wrap a shop towel around the fuel pressure connector to absorb any small amount of fuel leakage that may occur when installing gauge. Ignition "ON," pump pressure should be 280-320kPa.
7. Add Caution: Use correct pliers so damage to fuel lines will not occur.

DTC P1171 – Fuel System Lean During Acceleration

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Are any component-related DTCs set?	—	Go to component DTC charts	Go to Step 3
3	1. Check the vehicle's fuel tank for an adequate amount of fuel. 2. Add fuel to the vehicle's fuel tank if the tank is almost empty. Was fuel added to the vehicle's fuel tank?	—	Go to Step 4	Go to Step 5
4	1. Place the transmission in park. 2. Using a Tech 2, observe HO2S 1 voltage while running warm engine 75°C-95°C (167°F-203°F) at 1200 RPM. 3. HO2S 1 voltage should vary within the specified range. 4. Quickly open the throttle halfway for a few seconds. Did the voltage suddenly rise toward the high end of the specified range?	100-900 mV	Go to <i>Fuel System Diagnosis</i>	Go to Step 5
5	1. Disconnect the fuel pump relay and crank the engine to relieve the fuel pressure. 2. Install the fuel pressure gauge. 3. Start the engine and idle at normal operating temperature. 4. Disconnect the vacuum line going to the fuel pressure regulator. With the engine running, is the fuel pressure within the specified range?	280-325 kPa (41-46 psi)	Go to <i>OBD System Check</i>	Go to Step 6
6	Check for restricted fuel lines or restricted in-line filter. Was a problem found?	—	Verify repair	Go to Step 7

DTC P1171 – Fuel System Lean During Acceleration (Cont'd)

Step	Action	Value(s)	Yes	No
7	1. Ignition "OFF." 2. Remove the fuel pump relay and replace it with a fused jumper which will connect the relay's battery terminal to the terminal leading to the fuel pump fuse. 3. While the fuel pump is operating, use pliers to slowly close the return line (do not exceed the first specified value). Using the pliers to restrict the return line, can the fuel pressure be manipulated to exceed the second specified value?	414 kPa (60 psi) 325 kPa (46 psi)	Go to <i>Diagnostic Aids</i>	Go to <i>Step 8</i>
8	Check for: <input type="radio"/> Faulty fuel pump <input type="radio"/> Restricted fuel pump strainer (sock) <input type="radio"/> Incorrect fuel pump <input type="radio"/> Incorrect fuel being used <input type="radio"/> Hot fuel Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1380 ABS Rough Road ABS System Fault

Circuit Description

The powertrain control module (PCM) monitors ABS fault signal. When PCM receives fault signal, PCM will set DTC P1380.

Conditions for Setting the DTC

- ☐ Vehicle speed is more than 5 mph.
- ☐ Load is less than 99%.
- ☐ Engine revolution is less than 6250 rpm.
- ☐ PCM receives ABS fault signals from ABS unit.
- ☐ Ignition on.
- ☐ Misfire DTCs exist.
- ☐ 100 test failures within 120 test samples.

Action Taken When the DTC Sets

- ☐ The PCM will store DTC 1380 only, no MIL turn on.

Conditions for Clearing the MIL/DTC

- ☐ A history DTC P1380 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC 1380 can be cleared by using Tech-II or disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- ☐ PCM and ABS communication line short circuit to other line may cause faulty signal. Inspect communication line.
- ☐ Follow ABS ECU diagnosis procedure, refer to ABS procedure page.

DTC P1380 – ABS Rough Road ABS System Fault

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC" info for DTC P1380 and Misfire DTCs until the DTC P1380 and Misfire DTCs test runs. Note the result. Does the Tech 2 indicates DTC P1380 and Misfire DTCs failed this ignition?	—	Refer to ABS diagnosis After inspecting ABS, repeat Step 2 If problem still exists, go to Step 3	Clear DTC by Tech 2
3	Check short circuit among communication line of PCM/ABS and others. Does short circuit exist?	—	Repair wiring Verify repair	Go to Step 4
4	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1381 ABS Rough Road Class 2 Serial Link Error

Circuit Description

The powertrain control module (PCM) monitors no ABS signal. When PCM does not receive ABS signal, PCM will set DTC P1381.

Conditions for Setting the DTC

- ☐ PCM does not receive ABS signals from ABS ECU.
- ☐ Vehicle speed is more than 0 mph.
- ☐ Load is less than 99%.
- ☐ Engine revolution is less than 6250rpm.
- ☐ 2.5 second after key on.
- ☐ Misfire DTCs exist.
- ☐ 100 test failures within 120 test samples.

Action Taken When the DTC Sets

- ☐ The PCM will store DTC 1381 only, MIL on.

Conditions for Clearing the MIL/DTC

- ☐ A history code DTC P1381 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P1381 can be cleared by Tech-II or by disconnecting the PCM battery feed.

Diagnostic Aids


Check for the following conditions:

- ☐ Inspect open circuit of communication wire between ABS ECU and PCM.
 - ☐ Follow ABS ECU diagnosis procedure.
- Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1381 – ABS Rough Road Class 2 Serial Link Error

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC inf. for DTC P1381 and Misfire DTCs until the DTC P1381 and Misfire DTCs test runs. Note the result. Does the Tech 2 indicates DTC P1381 and Misfire DTCs failed this ignition?	—	Refer to ABS diagnosis After inspecting ABS, repeat Step 2 If problem still exists, go to Step 3	Clear DTC by Tech 2
3	Check open circuit among communication line of PCM/ABS and others. Does short circuit exist?	—	Repair wiring Verify repair	Go to Step 4
4	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1404 EGR Stuck Closed



D06RW055

Circuit Description

The powertrain control module (PCM) monitors the EGR valve pintle position input to ensure that the valve responds properly to commands from the PCM, and to detect a fault if current pintle zero position is different from the learned zero position. If the PCM detects a pintle position signal indicates more than 30 % different between current zero position and the learned zero position for more than 5 seconds, and this condition exists 3 times during trip, then the PCM will set DTC P1404.

Conditions for Setting the DTC

- Ignition voltage is between 11 and 16 volts.
- Intake Air temp is more than 3°C.
- Desired EGR position is 0.
- Difference of EGR pintle position between current and the learned zero is more than 30 % for more than 5 seconds, and exists three time to the above condition during a trip the PCM will set DTC 1404. Then it trigger the PCM lights on.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after consecutive 2nd trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1404 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1404 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Excessive carbon deposit on EGR valve shaft and/or foreign material may cause the EGR valve not to fully seated. The carbon deposit may occur by unusual port operation. Remove foreign material and/or excessive carbon deposit on EGR valve shaft may allow the EGR valve to be fully seated.
- Poor connection or damaged harness – Inspect the wiring harness for damage.


Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1404 – EGR Stuck Closed

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "ON," engine "OFF", review and record Tech 2 Failure Records Data. 2. Operate the vehicle within Failure Records conditions as noted. 3. Using a Tech 2, monitor "DTC inf. for DTC P1404 until the DTC P1404 test runs. Note the result. Does the Tech 2 indicates DTC P1404 failed this ignition?	—	Go to Step 3	Refer to <i>Diagnostic Aids</i>
3	1. Disconnect the EGR valve harness connector. 2. Inspect the EGR valve and connectors for damaged pin or terminals. Were there any damaged pins or terminals?	—	Go to Step 4	Go to Step 5
4	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
5	1. Remove EGR valve from Engine. 2. Inspect EGR valve for is any excessive carbon deposit on EGR shaft. 3. Inspect for any foreign material inside of EGR valve. Was excessive carbon deposit on EGR valve shaft and/or foreign material in EGR valve ?	—	Go to Step 6	Go to Step 7
6	1. Clean up EGR valve shaft and inside of EGR valve. 2. Remove foreign material from EGR valve. 3. Visually inspect damage of pintle and seat to see if it is bent If damaged leakage may occur. Was there any severe damage which affects function?	—	Go to Step 8	Verify repair Go to Step 7
7	1. Install the EGR valve. 2. Ignition "OFF". 3. Install the Tech 2. 4. Run the engine at idle. 5. On the Tech 2, select EGR control test. 6. Use the "UP" arrow to increase the EGR from 0% to 40%. Did EGR work properly?	—	—	Go to Step 8
8	1. Reset the learned zero EGR valve position. 2. Repeat step 7. Did EGR work properly?	—	Verify repair	Go to Step 9

DTC P1404 – EGR Stuck Closed (Cont'd)

Step	Action	Value(s)	Yes	No
9	Replace the EGR valve. Does DTC P1404 still fail "DTC" test on the Tech 2?	—	Go to <i>Step 10</i>	Verify repair
10	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1441 EVAP System Flow During Non-Purge

755RW028

Legend

- | | |
|---------------------------------|----------------------------------|
| (1) Induction Air Control Valve | (10) Front Side Member |
| (2) Air Separator | (11) Vacuum Tank |
| (3) Solenoid Valve | (12) Check Valve |
| (4) Canister | (13) Evapo Service Port |
| (5) Rear Side Member | (14) Vacuum Switch Valve |
| (6) Radiator | (15) Fuel Pressure Control Valve |
| (7) Throttle Body | (16) Vacuum Tank |
| (8) Solenoid Valve (Duty) | (17) Vacuum Switch Valve |
| (9) PCV Valve | (18) Induction Air Control Valve |

The evaporative system as defined by federal regulation includes the following components:

- Fuel tank
- EVAP canister vent solenoid
- Fuel tank pressure sensor
- Fuel pipes and hoses
- Vapor lines
- Fuel cap
- Evaporative emission (EVAP) canister
- Purge lines
- EVAP canister purge solenoid

The EVAP purge solenoid valve allows manifold vacuum to purge the canister. The Powertrain Control Module (PCM) supplies a ground to energize the solenoid valve (purge "ON"). The EVAP purge solenoid control is Pulse

Width Modulated (PWM), or turned "ON" and "OFF" several times a second. The duty cycle (pulse width) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM and the output is commanded when the appropriate conditions have been met.

The system checks for conditions that cause the EVAP system to purge continuously by commanding the EVAP vent solenoid "ON" and EVAP purge solenoid "OFF" (EVAP vent solenoid "CLOSED," EVAP purge PWM "0%"). If the fuel tank vacuum level increases during the test, a continuous purge flow condition is indicated. This can be caused by the following conditions:

- EVAP purge solenoid leaking
- EVAP purge and engine vacuum lines switched at the EVAP purge solenoid

- EVAP purge solenoid driver circuit grounded
- If any of these conditions are present, DTC P1441 will set.

Conditions for Setting the DTC

- No TP sensor, ODM, IAT sensor, or MAP sensor DTCs are set.
- Intake air temperature is above 0°C (32°F).
- Fuel tank level is between 15% and 85%.
- A continuous open purge flow condition is detected during the diagnostic test.

Action Taken When the DTC Sets

- The PCM will illuminate the Malfunction Indicator lamp (MIL) during the second key cycle trip in which the DTC sets.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1441 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1441 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- *Poor connection at PCM.* Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.

- *Damaged harness.* Inspect the wiring harness for damage. If the harness appears to be OK, connect the EVAP pressure/purge port J41413 to the EVAP service port, pressurize the EVAP system to 10 in. H₂O and observe the "Fuel Tank Vacuum" display on the Tech 2 while moving connectors and wiring harnesses related to the EVAP purge solenoid. A sudden change in the display will indicate the location of the fault.

- *Incorrect vacuum line routing.* Verify that the source vacuum line routing to the EVAP purge solenoid is correct and that the EVAP purge and source vacuum lines to the EVAP purge solenoid are not switched.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

- 2.If an EVAP purge solenoid electrical fault is present, the purge system will not operate correctly. repairing the electrical fault will very likely correct the condition that set DTC P1441.
- 3.Checks the fuel tank vacuum sensor at ambient pressure.
- 4.Checks for a stuck open EVAP purge solenoid.
- 5.Verifies that the fuel tank pressure sensor accurately reacts to EVAP system pressure changes.
- 7.If the EVAP purge and engine vacuum lines are switched at the EVAP purge solenoid, the solenoid valve will leak vacuum.


DTC P1441 – EVAP System Flow During Non-Purge

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition "OFF." 2. Remove the fuel filler cap. 3. Ignition "ON." Observe "Fuel Tank Pressure" on the Tech 2. Is "Fuel Tank Pressure" at the specified value?	1.51 V	Go to Step 3	Go to <i>P0452 or P0453</i>

DTC P1441 – EVAP System Flow During Non-Purge (Cont'd)

Step	Action	Value(s)	Yes	No
3	<ol style="list-style-type: none"> 1. Re-install the fuel filler cap. 2. Using the Tech 2, command the EVAP Vent Solenoid Valve "ON" (Closed). 3. Disconnect the canister side rubber hose end that hose is connected between the Purge Solenoid Valve and Canister. <p>IMPORTANT: Before continuing with the diagnosis, zero the EVAP pressure and vacuum gauges on EVAP pressure / purge cart J41413 (refer to the tool operating instructions).</p> <p>And then monitor the fuel tank inner pressure using the Tech 2.</p> <p>Does the fuel tank pressure hold the specified value?</p>	1.52 - 1.60 V	Go to Step 4	Go to Step 6
4	<ol style="list-style-type: none"> 1. Disconnect the EVAP pressure / purge cart J41413, and then plug the hose end. 2. Disconnect the rubber hose end of engine vacuum source side, (the hose is connected between Purge Solenoid Valve and engine). 3. Connect a vacuum hand pump to this rubber hose end. 4. Then apply -15 in H2O vacuum by the vacuum pump. 5. Monitor the fuel tank inner pressure using the Tech 2. <p>Does the fuel tank inner pressure hold the specified value?</p>	1.47 - 1.51 V	Go to Step 6	Go to Step 5
5	Replace the Purge Solenoid Valve.	—	Verify repair	—
6	<ol style="list-style-type: none"> 1. Check the leak, kinks or pinched hoses at the EVAP system rubber hose line, and also check if the rubber hoses are correctly connected or not. 2. Check for a leak from Vent Solenoid Valve and EVAP system rubber hoses, and also check for clogged Filter of air separator which is located near the vent solenoid valve. <p>Was a problem found? Using the Vacuum Hose Routing Diagram, repair or re-connect the rubber hoses correctly.</p>	—	Verify repair	Go to Step 7
7	<ol style="list-style-type: none"> 1. Start engine. 2. Remove the Fuel Filler Cap. 3. Using the Tech 2, command the EVAP Vent Solenoid Valve "ON" (closed) and Purge Solenoid Valve "OFF" (0%). 4. Replace the Fuel Filler Cap. 5. Run the engine at 2500RPM constant while monitoring "Fuel Tank Vacuum" on the Tech 2. <p>Does the fuel tank vacuum remain at the specified value while the EVAP Vent Solenoid Valve "ON" (closed) and Purge Solenoid Valve "OFF" (0%)?</p>	30 - 40%	Verify repair	Go to Diagnostic Aids

Diagnostic Trouble Code (DTC) P1508 IAC System Low RPM



T321115

Circuit Description

The powertrain control module (PCM) controls engine idle speed by adjusting the position of the idle air control (IAC) motor pintle. The IAC is a bi-directional stepper motor driven by two coils. The PCM applies current to the IAC coils in steps (counts) to extend the IAC pintle into a passage in the throttle body to decrease air flow. The PCM reverses the current to retract the pintle, increasing air flow. This method allows highly accurate control of idle speed and quick response to changes in engine load. If the PCM detects a condition where too low of an idle speed is present and the PCM is unable to adjust idle speed by increasing the IAC counts, DTC P1508 will set, indicating a problem with the idle control system.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of these DTCs are set: TP sensor, VSS, ECT, EGR, fuel system, MAF, MAP, IAT, canister purge, injector control or ignition control.
- Barometric pressure is above 75 kPa.
- Engine coolant temperature (ECT) is above 50°C (120°F).
- Vehicle speed is less than 1 mph.
- The engine has been running for at least 125 seconds.
- Canister purge duty cycle is above 10%.
- Ignition voltage is between 9.5 volts and 16.7 volts.
- The throttle is closed.
- Engine speed is lower than desired idle.

- Engine speed is more than 100-200 RPM lower than desired idle, based upon coolant temperature.
- All of the above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1508 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1508 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM or IAC motor – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring for damage.

6E2-406 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- Restricted air intake system – Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system.
- Throttle body – Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate.
- Large vacuum leak – Check for a condition that causes a large vacuum leak, such as an incorrectly installed or

faulty PCV valve or a disconnected brake booster hose.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.


DTC P1508 –IAC System Low RPM

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	1. Start the engine. 2. Turn all accessories “OFF”(A/C, rear defroster, etc). 3. Using a Tech 2, command RPM up to 1500, down to 500, and then up to 1500 while monitoring the “Engine Speed” on the Tech 2. NOTE: This Tech 2 command may cause the engine to “cut out” when RPM goes above 1500. If this occurs, the “cutting out” will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500 RPM. Does the “Engine Speed” remain within the specified value of the “Desired Idle” for each RPM command?	± 50 RPM	No trouble found. Go to <i>Diagnostic Aids</i>	Go to <i>Step 3</i>
3	1. Disconnect the IAC. 2. Install IAC Noid Light J 37027 or equivalent. 3. With the engine running, command RPM up to 1500, down to 500, and then up to 1500 while observing the noid light. NOTE: This Tech 2 command may cause the engine to “cut out” when RPM goes above 1500. If this occurs, the “cutting out” will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500 RPM. Does each noid light cycle red and green (never “OFF”)?	—	Go to <i>Step 5</i>	Go to <i>Step 4</i>
4	1. Check the following circuits for an open, short to voltage, short ground, or poor connections at the PCM: ○ IAC “A” Low. ○ IAC “A” High. ○ IAC “B” Low. ○ IAC “B” High. 2. If a problem is found, repair as necessary, Was a problem found?	—	Verify repair	Go to <i>Step 8</i>

DTC P1508 –IAC System Low RPM (Cont'd)

Step	Action	Value(s)	Yes	No
5	<p>Visually/physically inspect for following conditions:</p> <ul style="list-style-type: none"> ○ Restricted air intake system. Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system. ○ Throttle body. Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. <p>Do any of the above require a repair?</p>	—	Refer to appropriate section for on-vehicle service	Go to <i>Step 6</i>
6	<p>1. Check for a poor connection at the IAC harness connector.</p> <p>2. If a problem is found, replace faulty terminals as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 7</i>
7	<p>Replace the IAC valve.</p> <p>Is the action complete?</p>	—	Verify repair	—
8	<p>Replace the PCM.</p> <p>IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures.</p> <p>And also refer to latest service bulletin</p> <p>Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM.</p> <p>Is the action complete?</p>	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1509 IAC System High RPM



T321115

Circuit Description

The powertrain control module (PCM) controls engine idle speed by adjusting the position of the idle air control (IAC) motor pintle. The IAC is a bi-directional stepper motor driven by two coils. The PCM applies current to the IAC coils in steps (counts) to extend the IAC pintle into a passage in the throttle body to decrease air flow. The PCM reverses the current to retract the pintle, increasing air flow. This method allows highly accurate control of idle speed and quick response to changes in engine load. If the PCM detect a condition where too high of an idle speed is present and the PCM is unable to adjust idle speed by increasing the IAC counts, DTC P1509 will set, indicating a problem with the idle control system.

Conditions for Setting the DTC

- No Tech 2 test is being run.
- None of these DTCs are set: TP sensor, VSS, ECT, EGR, fuel system, MAF, MAP, IAT, canister purge, injector control or ignition control.
- Barometric pressure is above 75 kPa.
- Engine coolant temperature is above 50°C (120°F).
- Engine speed is more than 100-200 RPM higher than desired idle, based upon coolant temperature.
- The engine has been running for at least 125 seconds.
- Vehicle speed is less than 1 mph.
- Canister purge duty cycle is above 10%.
- Ignition voltage is between 9.5 volts and 16.7 volts.
- Engine speed is higher than desired idle.

- All of the above conditions are met for 5 seconds.

Action Taken When the DTC Sets

- The PCM will illuminate the malfunction indicator lamp (MIL) after the second consecutive trip in which the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1509 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1509 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM or IAC motor – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring for damage.
- Vacuum leak – Check for a condition that causes a vacuum leak, such as disconnected or damaged hoses, leaks at the EGR valve and the EGR pipe to the

intake manifold, leaks at the throttle body, faulty or incorrectly installed PCV valve, leaks at the intake manifold, etc.

- Throttle body – Check for sticking throttle plate. Also inspect the IAC passage for deposits or objects which keep the IAC pintle from fully extending.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

DTC P1509 –IAC System High RPM

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	<p>1. Start the engine.</p> <p>2. Turn all accessories “OFF” (A/C, rear defroster, etc.).</p> <p>3. Using a Tech 2, command RPM up to 1500, down to 500, and then up to 1500 while monitoring “Engine Speed” on the Tech 2.</p> <p>NOTE: This Tech 2 command may cause the engine to “cut out” when RPM goes above 1500. If this occurs, the “cutting out” will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500 RPM.</p> <p>Does the “Engine Speed” remain within the specified value of “Desired Idle” for each RPM command?</p>	± 50 RPM	No trouble found. Go to <i>Diagnostic Aids</i>	Go to <i>Step 3</i>
3	<p>1. Disconnect the IAC.</p> <p>2. Install IAC Noid Light J 37027 or equivalent.</p> <p>3. With the engine running, command RPM up to 1500, down to 500, and then up to 1500 while observing the noid light.</p> <p>NOTE: This Tech 2 command may cause the engine to “cut out” when RPM goes above 1500. If this occurs, the “cutting out” will stop when the Tech 2 command for the test is discontinued, or if the Tech 2 command is changed to less than 1500 RPM.</p> <p>Does each noid light cycle red and green (never “OFF”)?</p>	—	Go to <i>Step 5</i>	Go to <i>Step 4</i>
4	<p>1. Check the following circuits for an open, short to voltage, short ground, or poor connections at the PCM:</p> <ul style="list-style-type: none"> ○ IAC “A” Low. ○ IAC “A” High. ○ IAC “B” Low. ○ IAC “B” High. <p>2. If a problem its found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 8</i>
5	<p>Visually/physically inspect for the following conditions:</p> <ul style="list-style-type: none"> ○ Vacuum leaks. ○ Throttle plate or throttle shaft for binding. ○ Accelerator and cruise control cables for being misadjusted or for binding. ○ Faulty, missing, or incorrectly installed PCV valve. <p>Do any of the above require a repair?</p>	—	Refer to appropriate section for on-vehicle service	Go to <i>Step 6</i>

DTC P1509 –IAC System High RPM (Cont'd)

Step	Action	Value(s)	Yes	No
6	1. Check for a poor connection at the IAC harness connector. 2. If a problem is found, replace faulty terminals as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 7</i>
7	Replace the IAC valve. Is the action complete?	—	Verify repair	—
8	Replace the PCM. IMPORTANT: The replacement PCM must be programmed, Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1618 Serial Peripheral Interface (SPI) PCM Interprocessor Communication Error

Circuit Description

The serial peripheral interface (SPI) communication is used internally by the PCM to send messages between the engine processor and the automatic transmission processor. Included in each message sent between the two-processors is a checksum of the message. Both the engine processor and automatic transmission processor will compare this check sum value with the calculated value. If the checksums don't match, the processor will view the new data as being corrupted and ignore the values. The processor will then use the previous message. The receiving processor will then send a message to the sending processor informing it that it's last message was corrupted.

Conditions for Setting the DTC

- Battery voltage is above 9.0 V for 2 seconds.
- The PCM detects an internal program fault (check sum of data communications error).
- Check sum fault present for 3 out 6 seconds.
- No TCM resets for 2 seconds.

Action Taken When the DTC Sets

- The PCM will flash the "Check Trans" lamp the first time the fault is detected.
- The PCM will store conditions which were present when the DTC was set as Freeze Frame and in the Failure Records data.
- The automatic transmission will operate in the "safety mode" to protect the mechanical parts of the transmission. Shift quality and/or gear changes may not be normal.

Conditions for Clearing the MIL/DTC

- The PCM will turn the "Check Trans" lamp "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault is no longer present.
- A history DTC P1618 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1618 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

DTC P1618 – Serial Peripheral Interface (SPI) PCM Interprocessor Communication Error

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Is the EEPROM calibration the latest version available?	—	Go to Step 4	Go to Step 3
3	Reprogram the PCM with the latest available calibrations. Does DTC 1618 re-appear when the <i>OBD System Check</i> is repeated?	—	Go to Step 4	Repair completed
4	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1625 PCM Unexpected Reset

Circuit Description

The powertrain control module (PCM) monitors unexpected PCM reset. This will not turn on MIL light on, only records code DTC P1625.

Conditions for Setting the DTC

- Clock or COP (Computer Operating Properly) reset.

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- A history DTC P1625 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- DTC P1625 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- P1625 alone stored does not need diagnosis. Clear DTC code.

DTC P1625 – PCM Unexpected Reset

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Ignition is "ON". 2. Install the Tech 2. 3. Start the engine at let it Idle. 4. On the Tech 2, select "DTC info". Does the Tech 2 indicate DTC P1625 failed?	—	Go to Step 3	Go to <i>Diagnostic Aids</i>
3	1. Ignition is "ON". 2. Clear DTC P1625 by using the Tech 2 "Clear Info". 3. Start the engine at let it Idle. 4. On the Tech 2, select "DTC info". Does the Tech 2 indicate DTC P1625 failed?	—	Go to Step 4	Go to <i>Diagnostic Aids</i>
4	1. Check for aftermarket electronics, such as transceiver, stereos, and anti theft devices. May radiate EMI into the control system if they are improperly installed. (This may cause a false sensor reading and turn on the MIL.) 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1640 Output Driver Module (ODM) "A" Fault

Action Taken When the DTC Sets

- The PCM will not illuminate the malfunction indicator lamp (MIL).
- The PCM will store conditions which were present when the DTC was set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- A history DTC P1640 will clear after 40 consecutive warm-up cycles occur without a fault.
- DTC P1650 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition "ON" and observe a voltmeter connected to the suspect driver circuit at the PCM harness connector while moving connectors and wiring harnesses relates to the MIL. A change in voltage will indicate the location of the fault.
- Poor connection at component – Examine for damaged connectors, unplugged connector, or damaged terminals at the following locations: canister purge solenoid, Fuel level check. An open ignition feed

circuit at any of these components will cause DTC P1650 to be set.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

The following PCM pins are controlled by output driver modules (ODMs):

- A13 – MIL (Check Engine)
- A14 – Check T/M or Up-Shift
- A15 – EVAP Canister Purge
- A16 – Band Apply (4L30E)
- B14 – A/C Clutch
- B15 – Low Fuel Lamp
- B16 – CCP Solenoid and VIM

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

4. The Tech 2 Driver Module Status indicates the PCM pin that is affected.
9. The Tech 2 may indicate "short circuit" even when the problem is an open circuit. The cause of an open circuit may be in the component itself.
11. A short to ground on the ignition side of the component will blow the fuse. Since the fuse was checked in Step 2, a short to ground would be between the affected component and the PCM.

DTC P1640 –Output Driver Module (ODM) "A" Fault

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Check the fuse for the driver circuit that was shown as faulty. Was the fuse blown?	—	Go to Step 3	Go to Step 4
3	1. Check for a short to ground between the fuse and the affected component. 2. Replace the fuse after making any necessary repairs. Is the action complete?	—	Verify repair	—
4	1. Disconnect the PCM connector for the affected driver circuit. Is there any damage to the PCM pin or connector?	—	Go to Step 5	Go to Step 6
5	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
6	Were either of the lamp circuits for "Check Engine" or "Check Trans." indicated as faulty by the Tech 2?	—	Go to Step 7	Go to Step 13

DTC P1640 –Output Driver Module (ODM) “A” Fault (Cont’d)

Step	Action	Value(s)	Yes	No
7	1. Leave the PCM connector for the lamp driver circuit disconnected. 2. Ignition “ON.” 3. Using a DVM, check the voltage at the PCM connector for the affected lamp driver circuit. Was the voltage equal to the specified value?	B+	Go to Step 15	Go to Step 8
8	1. Ignition “ON.” 2. Check for battery voltage at the fuse for the affected lamp circuit. Was battery voltage available at the fuse?	—	Go to Step 10	Go to Step 9
9	Repair the open circuit between the ignition switch and the fuse. Is the action complete?	—	Verify repair	—
10	1. Ignition “OFF.” 2. Disconnect the PCM connector for the affected driver terminal. 3. Connect an ohmmeter between a good ground and the PCM connector for the affected driver. Did the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 12
11	Repair the short to ground between the affected component and its PCM driver terminal. Is the action complete?	—	Verify repair	—
12	Repair the open circuit between the fuse and the PCM driver terminal for the affected circuit. Is the action complete?	—	Verify repair	—
13	1. Connect the PCM. 2. Start the engine and let it idle. 3. Backprobe the affected terminal at the PCM with a DVM. Was the voltage equal to the specified value?	B+	Go to Step 15	Go to Step 14
14	1. Run the engine at idle. 2. Check for battery voltage at the fuse for the affected circuit. Was battery voltage available at the fuse?	—	Go to Step 10	Go to Step 9
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service in Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Diagnostic Trouble Code (DTC) P1650 Quad Driver Module "A" Fault

Circuit Description

The Quad Driver Module (QDMs) are used by the powertrain control module (PCM) to turn "ON" current-driven devices that are needed to control two engine functions. The PCM monitors open or short circuit of either of Canister Control Purge (CCP) Vent solenoid or Variable Intake Manifold (VIM).

Conditions for Setting the DTC

- ☐ Ignition "ON".
- ☐ Engine running.
- ☐ No DTC 1618.
- ☐ Ignition voltage.
- ☐ Output voltage does not equal voltage is not less than 1 volt when out put is "ON".
- ☐ Above conditions occur for at least 0.5 second.

Action Taken When the DTC Sets

- ☐ The PCM will not illuminate the malfunction indicator lamp (MIL).
- ☐ The PCM will store conditions which were present when the DTC was set as Failure Records only. This information will not be stored as Freeze Frame data.

Conditions for Clearing the MIL/DTC

- ☐ The PCM will turn the MIL "OFF" on the third consecutive trip cycle during which the diagnostic has been run and the fault condition is no longer present.
- ☐ A history DTC P1650 will clear after 40 consecutive warm-up cycles have occurred without a fault.
- ☐ DTC P1650 can be cleared by using the Tech 2 "Clear Info" function or by disconnecting the PCM battery feed.

Diagnostic Aids

Check for the following conditions:

- ☐ Poor connection at PCM – Inspect harness connectors for backed-out terminals, improper mating, broken locks, improperly formed or damaged terminals, and poor terminal-to-wire connection.
- ☐ Damaged harness – Inspect the wiring harness for damage. If the harness appears to be OK, disconnect the PCM, turn the ignition "ON" and observe a voltmeter connected to the suspect driver circuit at the PCM harness connector while moving connectors and wiring harnesses relates to the MIL. A change in voltage will indicate the location of the fault.
- ☐ Poor connection at component – Examine for damaged connectors, unplugged connector, or damaged terminals at the following locations: canister purge solenoid, fuel level sensor. An open ignition feed circuit at any of these components will cause DTC P1650 to be set.

Reviewing the Failure Records vehicle mileage since the diagnostic test last failed may help determine how often the condition that caused the DTC to be set occurs. This may assist in diagnosing the condition.

The following PCM pins are controlled by quad driver modules (QDMs):

- ☐ C11 – Variable Intake Manifold
- ☐ C13 – Canister Cut Valve

Test Description

Number(s) below refer to the step number(s) on the Diagnostic Chart.

4. The Tech 2 Driver Module Status indicates the PCM pin that is affected.
9. The Tech 2 may indicate "short circuit" even when the problem is an open circuit. The cause of an open circuit may be in the component itself.
11. A short to ground on the ignition side of the component will blow the fuse. Since the fuse was checked in Step 2, a short to ground would be between the affected component and the PCM.

DTC P1650 – Quad Driver Module (QDM) “M” Fault

Step	Action	Value(s)	Yes	No
1	Was the “On-Board Diagnostic (OBD) System Check” performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	Check the fuse for the driver circuit that was shown as faulty. Was the fuse blown?	—	Go to Step 3	Go to Step 4
3	1. Check for a short to ground between the fuse and the affected component. 2. Replace the fuse after making any necessary repairs. Is the action complete?	—	Verify repair	—
4	1. Disconnect the PCM connector for the affected driver circuit. Is there any damage to the PCM pin or connector?	—	Go to Step 5	Go to Step 6
5	Repair the damaged pin or terminal. Is the action complete?	—	Verify repair	—
6	Were either of the lamp circuits for “Check Engine” or “Check Trans.” indicated as faulty by the Tech 2?	—	Go to Step 7	Go to Step 13
7	1. Leave the PCM connector for the lamp driver circuit disconnected. 2. Ignition “ON.” 3. Using a DVM, check the voltage at the PCM connector for the affected lamp driver circuit. Was the voltage equal to the specified value?	B+	Go to Step 15	Go to Step 8
8	1. Ignition “ON.” 2. Check for battery voltage at the fuse for the affected lamp circuit. Was battery voltage available at the fuse?	—	Go to Step 10	Go to Step 9
9	Repair the open circuit between the ignition switch and the fuse. Is the action complete?	—	Verify repair	—
10	1. Ignition “OFF.” 2. Disconnect the PCM connector for the affected driver terminal. 3. Connect an ohmmeter between a good ground and the PCM connector for the affected driver. Did the ohmmeter indicate continuity?	—	Go to Step 11	Go to Step 12
11	Repair the short to ground between the affected component and its PCM driver terminal. Is the action complete?	—	Verify repair	—
12	Repair the open circuit between the fuse and the PCM driver terminal for the affected circuit. Is the action complete?	—	Verify repair	—

DTC P1650 – Quad Driver Module (QDM) “M” Fault (Cont’d)

Step	Action	Value(s)	Yes	No
13	1. Connect the PCM. 2. Start the engine and let it idle. 3. Backprobe the affected terminal at the PCM with a DVM. Was the voltage equal to the specified value?	B+	Go to <i>Step 15</i>	Go to <i>Step 14</i>
14	1. Run the engine at idle. 2. Check for battery voltage at the fuse for the affected circuit. Was battery voltage available at the fuse?	—	Go to <i>Step 10</i>	Go to <i>Step 9</i>
15	Replace the PCM. IMPORTANT: The replacement PCM must be programmed. Refer to <i>On-Vehicle Service</i> in <i>Powertrain Control Module and Sensors</i> for procedures. And also refer to latest service bulletin Check to see if the Latest software is released or not. And then Down Load the LATEST PROGRAMMED SOFTWARE to the replacement PCM. Is the action complete?	—	Verify repair	—

Symptom Diagnosis

Preliminary Checks

Before using this section, perform the "On-Board Diagnostic (OBD) System Check" and verify all of the following items:

- The powertrain control module (PCM) and malfunction indicator lamp (MIL) (Check Engine lamp) are operating correctly.
- There are no DTC(s) stored.
- Tech 2 data is within normal operating range. Refer to *Typical Scan Data Values*.
- Verify the customer complaint and locate the correct symptom in the table of contents. Perform the procedure included in the symptom chart.

Visual/Physical Check

Several of the symptom procedures call for a careful visual/physical check. This can lead to correcting a problem without further checks and can save valuable time.

This check should include the following items:

- PCM grounds for cleanliness, tightness and proper location.
- Vacuum hoses for splits, kinks, and proper connections, as shown on the "Vehicle Emission Control Information" label. Check thoroughly for any type of leak or restriction.
- Air intake ducts for collapsed or damaged areas.
- Air leaks at throttle body mounting area, mass air flow (MAF) sensor and intake manifold sealing surfaces.
- Ignition components for cracking, hardness, and carbon tracking.
- Wiring for proper connections, pinches and cuts.

Intermittents

IMPORTANT: An intermittent problem may or may not turn on the malfunction indicator lamp (MIL) or store a DTC. DO NOT use the Diagnostic Trouble Code (DTC) charts for intermittent problems. The fault must be present to locate the problem.

Most intermittent problems are caused by faulty electrical connections or wiring. Perform a careful visual/physical check for the following conditions:

- Poor mating of the connector halves or a terminal not fully seated in the connector (backed out).
- Improperly formed or damaged terminal.
- All connector terminals in the problem circuit should be carefully checked for proper contact tension.
- Poor terminal-to-wire connection. This requires removing the terminal from the connector body to check.

Road test the vehicle with a J 39200 Digital Multimeter connected to a suspected circuit. An abnormal voltage when the malfunction occurs is a good indication that there is a fault in the circuit being monitored.

Use a Tech 2 to help detect intermittent conditions. The scan tool has several features that can be used to locate

an intermittent condition. Use the following feature to find intermittent faults:

- Using a Tech 2's "Freeze Frame" buffer or "Failure Records" buffer can aid in locating an intermittent condition. Review and record the information in the freeze frame or failure record associated with the intermittent DTC being diagnosed. The vehicle can be driven within the conditions that were present when the DTC originally set.

To check for loss of diagnostic code memory, disconnect the MAP sensor and idle the engine until the MIL (Service Engine Soon lamp) comes on. DTC P0107 should be stored and kept in memory when the ignition is turned "OFF." If not, the PCM is faulty. When this test is completed, make sure that you clear the DTC P0107 from memory.

An intermittent MIL (Check Engine lamp) with no stored DTC may be caused by the following:

- Ignition coil shorted to ground and arcing at ignition wires or plugs.
- MIL (Check Engine lamp) wire to PCM shorted to ground.
- Poor PCM grounds. Refer to the PCM wiring diagrams.

Check for improper installation of electrical options such as lights, cellular phones, etc. Check all wires from the PCM to the ignition coils for poor connections.

Check for an open diode across the A/C compressor clutch and check for other open diodes (refer to wiring diagrams in *Electrical Diagnosis*).

If problem has not been found, refer to *PCM Connector Symptom* tables.

- Check the "Broadcast Code" of the PCM, and compare it with the latest Isuzu service bulletins and/or Isuzu EEPROM reprogramming equipment to determine if an update to the PCM's reprogrammable memory has been released. To check the "Broadcast Code," connect the Tech 2, then look for "ID info," then select "Broadcast Code." This should display a 4 character code, such as "XBYA" (example only). This identifies the contents of the reprogrammable software and calibration contained in the PCM. If the Broadcast code is not the most current available, it is advisable to reprogram the PCM's EEPROM memory, which may either help identify a hard-to-find problem or may fix the problem.

Hard Start Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Engine cranks, but does not start for a long time. Does eventually run, or may start but immediately stalls. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	Check engine coolant temperature (ECT) sensor for shift in value. After 8 hours with the hood up and the engine not running, connect the Tech 2. With the ignition "ON" and the engine not running, compare engine coolant temperature to intake air temperature. Are ECT and IAT within the specified value of each other?	$\pm 5^{\circ}\text{C}$ ($\pm 9^{\circ}\text{F}$)	Go to Step 9	Go to Step 5
5	1. Using a Tech 2, display the engine coolant temperature and note the value. 2. Check the resistance of the engine coolant temperature sensor. 3. Refer to <i>Engine Coolant Temperature Sensor Temperature vs. Resistance</i> chart on <i>DTC P0118 Diagnostic Support</i> for resistance specifications. Is the resistance value near the resistance for the temperature noted?	—	Go to Step 7	Go to Step 6
6	Replace the ECT sensor. Is the action complete?	—	Verify repair	—
7	Locate and repair high resistance or poor connection in the ECT signal circuit or the ECT sensor ground. Is the action complete?	—	Verify repair	—
8	1. Check for a faulty, plugged, or incorrectly installed PCV valve. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for water-or alcohol-contaminated fuel. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10
10	1. Perform the procedure in <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	1. Check for proper ignition voltage output with spark tester J 26792 (ST-125). Refer to <i>Electric Ignition System</i> for procedure. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 12

Hard Start Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
12	<p>1. Remove spark plugs. Check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i>.</p> <p>NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 13</i>
13	<p>1. Check for a loose ignition coil ground. Refer to <i>Electronic Ignition System</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 14</i>
14	<p>1. Remove the ignition coils and check the ignition coils for cracks or carbon tracking.</p> <p>2. If a problem is found, replace affected coil(s) as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 15</i>
15	<p>1. Check IAC operation. Perform the procedure in the <i>DTC P0506, Step 6</i> diagnostic table.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 16</i>
16	<p>1. Check for the following engine mechanical problems (refer to <i>Engine Mechanical</i>):</p> <ul style="list-style-type: none"> <input type="radio"/> Low compression <input type="radio"/> Leaking cylinder head gaskets <input type="radio"/> Worn or incorrect camshaft <input type="radio"/> Camshaft drive belt slipped or stripped <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 17</i>
17	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All electrical connections within a suspected circuit and/or system. <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

Surges and/or Chuggles Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Engine power variation under steady throttle or cruise. Feels like the vehicle speeds up and slows down with no change in the accelerator pedal. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	Be sure that the driver understands transmission torque converter clutch and A/C compressor operation as explained in the owner's manual. Inform the customer how the TCC and the A/C clutch operate. Is the customer experiencing a normal condition?	—	System OK	Go to Step 5
5	1. Check the the fuel control heated oxygen sensors (HO2S, B1S1 and B2S1). The fuel control heated oxygen sensors (HO2S) should respond quickly to different throttle positions. If they don't, check them for silicone or other contaminants from fuel or use of improper RTV sealant. The sensors may have a white powdery coating. Silicone contamination causes a high but false HO2S signal voltage (rich exhaust indication). The PCM will then reduce the amount of fuel delivered to the engine, causing a severe driveability problem. For more information, refer to <i>Powertrain Control Module (PCM) and Sensors</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Check the fuel pressure. Refer to <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	Monitor the long term fuel trim on the Tech 2. Is the long term fuel trim significantly in the negative range (rich condition)?	—	Go to Step 8	Go to Step 9
8	1. Check items that can cause the engine to run rich. Refer to <i>Diagnostic Aids in DTC P0172 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 10	Verify repair
9	1. Check items that can cause the engine to run lean. Refer to <i>Diagnostic Aids in DTC P0171</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 10	Verify repair

Surges and/or Chuggles Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Check for proper ignition voltage output with spark tester J 26792 (ST-125). Refer to <i>Electric Ignition System</i> for procedure. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	1. Check for a loose ignition coil ground. Refer to <i>Electric Ignition System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	1. Check the ignition coils for cracks or carbon tracking. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 14
13	1. Remove the spark plugs and check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i> . NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 14
14	1. Check the injector connections. 2. If any of the injector connectors are connected to an incorrect cylinder, correct as necessary. Was a problem found?	—	Verify repair	Go to Step 15
15	1. Check PCM grounds for the cleanliness, tightness and proper locations. Refer to the PCM wiring diagrams in <i>Electrical Diagnosis</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 16
16	1. Check MAF sensor connections. 2. If a problem is found, replace the faulty terminals as necessary. Refer to <i>Electrical Diagnosis</i> for wiring repair procedures. Was a problem found?	—	Verify repair	Go to Step 17
17	1. Visually/physically check vacuum hoses for splits, kinks, and proper connections and routing as shown on the "Vehicle Emission Control Information" label. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 18

Surges and/or Chuggles Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
18	<p>1. Check the exhaust system for possible restriction:</p> <ul style="list-style-type: none"> ○ Inspect the exhaust system for damaged or collapsed pipes. ○ Inspect the muffler for heat distress or possible internal failure. ○ Check for a possible plugged three-way catalytic converter by checking the exhaust system back pressure. Refer to <i>Restricted Exhaust System Check</i>. <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 19</i>
19	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system. <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

Lack of Power, Sluggish or Spongy Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Engine delivers less than expected power. Little or no increase in speed when accelerator pedal is pushed down part-way. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Remove and check the air filter element for dirt or restrictions. Refer to <i>Air Intake System</i> in <i>On-Vehicle Service</i> . 2. Replace the air filter element if necessary. Was a repair required?	—	Verify repair	Go to Step 5
5	1. Check for low fuel pressure. Refer to <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Check for water-or alcohol-contaminated fuel. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Using a Tech 2, monitor the knock sensor (KS) system for excessive spark retard activity. Refer to <i>Knock Sensor (KS) System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Install the Tech 2. 2. Run the engine at idle. 3. On the Tech 2, select F3: Miscellaneous Test, F6: Variable Intake Manifold. 4. Repeat Switch ON or OFF of VIM solenoid valve by using the Tech 2. 5. Check the working solenoid sound if the actuator works normally. 6. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for proper ignition voltage output with spark tester J 26792 (ST-125). Refer to <i>Electronic Ignition System</i> for procedure. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10

Lack of Power, Sluggish or Spongy Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
10	<p>1. Remove the spark plugs and check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i>.</p> <p>NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 11
11	<p>1. Check the ignition coils for cracks or carbon tracking.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 12
12	<p>1. Check the PCM grounds for the cleanliness, tightness and proper locations. Refer to the PCM wiring diagrams in <i>Electrical Diagnosis</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>1. Check the exhaust system for possible restriction:</p> <ul style="list-style-type: none"> ○ Inspect the exhaust system for damaged or collapsed pipes. ○ Inspect the muffler for heat distress or possible internal failure. ○ Check for a possible plugged three-way catalytic converter by checking the exhaust system back pressure. Refer to <i>Restricted Exhaust System Check</i>. <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 14
14	<p>1. Check the torque converter clutch (TCC) for proper operation. Refer to <i>4L30-E Transmission Diagnosis</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 15
15	<p>1. Check for an engine mechanical problem. Check for low compression, incorrect or worn camshaft, loose timing belt, etc. Refer to <i>Engine Mechanical</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system. <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

Detonation/Spark Knock Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: A mild to severe ping, usually worse under acceleration. The engine makes sharp metallic knocks that change with throttle opening. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	If Tech 2 readings are normal (refer to <i>Typical Scan Values</i>) and there are no engine mechanical faults, fill the fuel tank with a known quality gasoline that has a minimum octane rating of 87 and re-evaluate the vehicle performance. Is detonation present?	—	Go to Step 5	Verify repair
5	1. Check the transmission range switch circuit. Use a Tech 2 and be sure the Tech 2 indicates that the vehicle is in drive with the gear selector in drive or overdrive. 2. If a problem is found, diagnose and repair the transmission range switch as necessary (refer to <i>4L30-E Automatic Transmission Diagnosis</i>). Was a problem found?	—	Verify repair	Go to Step 6
6	1. Check TCC operation. Refer to <i>4L30-E Transmission Diagnosis</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Check for obvious overheating problems: <ul style="list-style-type: none"> ○ Low engine coolant. ○ Restricted air flow to radiator, or restricted water flow through radiator. ○ Correct coolant solution should be a 50/50 mix of approved antifreeze/coolant and water. Refer to <i>Engine Cooling</i>. ○ EGR operation. Refer to <i>DTC P0401</i>. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Check fuel pressure. Refer to <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9

Detonation/Spark Knock Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
9	<p>1. Check items that can cause an engine to run lean (long term fuel trim significantly in the positive range). For a lean condition, refer to <i>Diagnostic Aids</i> in <i>DTC P0171 Diagnostic Support</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 10</i>
10	<p>1. Spark plugs for proper heat range. Refer to <i>General Information</i>.</p> <p>2. If incorrect spark plugs are installed, replace spark plugs as necessary.</p> <p>Did any spark plugs require replacement?</p>	—	Verify repair	Go to <i>Step 11</i>
11	<p>1. Remove excessive carbon buildup with a top engine cleaner. Refer to instructions on the top engine cleaner can.</p> <p>2. Re-evaluate vehicle performance.</p> <p>Is detonation still present?</p>	—	Go to <i>Step 12</i>	Verify repair
12	<p>1. Check for an engine mechanical problem. Perform a cylinder compression check. Refer to <i>Engine Mechanical</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to <i>Step 13</i>
13	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system. <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

Rough, Unstable, or Incorrect Idle, Stalling Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Engine runs unevenly at idle. If severe, the engine or vehicle may shake. Engine idle speed may vary in RPM. Either condition may be severe enough to stall the engine. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Go to Step 13	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Check the PCM grounds for cleanliness, tightness and proper routing. Refer to the PCM wiring diagrams in <i>Electrical Diagnosis</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	Observe the long term fuel trim on the Tech 2. Is the long term fuel trim significantly in the negative range (rich condition)?	—	Go to Step 6	Go to Step 7
6	1. Check items that can cause the engine to run rich. Refer to <i>Diagnostic Aids in DTC P0172 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
7	Is the long term fuel trim significantly in the positive range (lean condition)?	—	Go to Step 8	Go to Step 9
8	1. Check items that can cause the engine to run lean. Refer to <i>Diagnostic Aids in DTC P0171 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for incorrect idle speed. Ensure that the following conditions are present: <ul style="list-style-type: none"> ○ The engine is fully warm. ○ The accessories are "OFF." 2. Using a Tech 2, monitor the IAC position. Is the IAC position within the specified values?	Between 10 and 50 counts	Go to Step 11	Go to Step 10

Rough, Unstable, or Incorrect Idle, Stalling Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
10	<p>1. Visually/physically inspect for the following conditions:</p> <ul style="list-style-type: none"> ○ Restricted air intake system. Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system. ○ Throttle body. Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. ○ Large vacuum leak. Check for a condition that causes a large vacuum leak, such as an incorrectly installed or faulty crankcase ventilation valve or a disconnected brake booster hose. <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 8
11	<p>Check the injector connections. If any of the injectors are connected to an incorrect cylinder, correct as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 12
12	<p>1. Perform the "Injector Coil/Balance Test" in <i>Fuel Metering System</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>1. Check for fuel in the pressure regulator vacuum hose.</p> <p>2. If fuel is present, replace the fuel pressure regulator assembly. Refer to <i>Fuel Metering System</i>.</p> <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 14
14	<p>1. Check for proper ignition voltage output with spark tester J 26792 (ST-125). Refer to <i>Electronic Ignition System</i> for the procedure.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 15
15	<p>1. Remove spark plugs. Check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i>.</p> <p>NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>1. Check for a loose ignition coil ground. Refer to <i>Electrical Ignition System</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 17

Rough, Unstable, or Incorrect Idle, Stalling Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
17	1. Check ignition coils for cracks or carbon tracking. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 18</i>
18	Using a Tech 2, monitor the throttle position (TP) angle with the engine idling. Is the TP angle at the specified value and steady?	0%	Go to <i>Step 19</i>	Refer to <i>DTC P0123</i> for further diagnosis
19	1. Check the positive crankcase ventilation (PCV) valve for proper operation. Refer to <i>Crankcase Ventilation System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 20</i>
20	1. Check the transmission range switch circuit. Use a Tech 2 and be sure the Tech 2 indicates that the vehicle is in drive with the gear selector in drive or overdrive. 2. If a problem is found, diagnose and repair the transmission range switch as necessary (refer to <i>4L30-E Automatic Transmission Diagnosis</i>). Was a problem found?	—	Verify repair	Go to <i>Step 21</i>
21	1. Check for the following engine mechanical items. Refer to <i>Engine Mechanical</i> for diagnosis procedures: <ul style="list-style-type: none"> <input type="radio"/> Low compression <input type="radio"/> Sticking or leaking valves <input type="radio"/> Worn camshaft lobe(s) <input type="radio"/> Camshaft drive belt slipped or stripped <input type="radio"/> Incorrect valve timing <input type="radio"/> Worn rocker arms <input type="radio"/> Broken valve springs 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 22</i>
22	1. Check for faulty motor mounts. Refer to <i>Engine Mechanical</i> for inspection of mounts. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 23</i>
23	1. Review all diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All electrical connections within a suspected circuit and/or system. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Contact Technical Assistance

Poor Fuel Economy Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Fuel economy, as measured by an actual road test, is noticeably lower than expected. Also, economy is noticeably lower than it was on this vehicle at one time, as previously shown by an actual road test. (Larger than standard tires will cause odometer readings to be incorrect, and that may cause fuel economy to appear poor when it is actually normal.) Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	Check owner's driving habits. <input type="radio"/> Is the A/C "ON" full time (defroster mode "ON")? <input type="radio"/> Are tires at the correct pressure? <input type="radio"/> Are excessively heavy loads being carried? <input type="radio"/> Is acceleration too much, too often? Was a problem found?	—	Go to Step 5	Go to Step 6
5	Review the items in Step 4 with the customer and advise as necessary. Is the action complete?	—	System OK	—
6	1. Visually/physically check: Vacuum hoses for splits, kinks, and improper connections and routing as shown on the "Vehicle Emission Control Information" label. 2. If a problem is found, repair as necessary. Was a repair required?	—	Verify repair	Go to Step 7
7	1. Remove and check the air filter element for dirt or for restrictions. Refer to <i>Air Intake System</i> . 2. Replace the air filter element if necessary. Was a repair required?	—	Verify repair	Go to Step 8
8	1. Remove spark plugs and check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Spark Plug Replacement</i> . NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for low engine coolant level. Refer to <i>Engine Cooling</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10

Poor Fuel Economy Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
10	1. Check for an incorrect or faulty engine thermostat. Refer to <i>Engine Cooling</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 11
11	1. Check for low engine compression. Refer to <i>Engine Mechanical</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 12
12	1. Check the TCC operation. Refer to <i>4L30-E Transmission Diagnosis</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 13
13	1. Check the exhaust system for possible restriction: <ul style="list-style-type: none"> ○ Inspect the exhaust system for damaged or collapsed pipes. ○ Inspect the muffler for heat distress or possible internal failure. ○ Check for a possible plugged three-way catalytic converter by checking the exhaust system back pressure. Refer to <i>Restricted Exhaust System Check</i>. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 14
14	Check for proper calibration of the speedometer. Does the speed indicated on the speedometer closely match the vehicle speed displayed on the Tech 2?	—	Go to Step 16	Go to Step 15
15	Diagnose and repair an inaccurate speedometer condition as necessary. Refer to <i>Vehicle Speed Sensor</i> in <i>Electrical Diagnosis</i> . Was a problem found?	—	Verify repair	—
16	1. Check the air intake system and the crankcase for air leaks. Refer to <i>Air Intake System</i> and <i>Crankcase Ventilation System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 17
17	1. Review all diagnostic procedures within this table. 2. When all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All connections within a suspected circuit and/or system. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 18
18	Perform the procedure in <i>Fuel System Pressure Test</i> . Was the fuel pressure normal?	—	Contact Technical Assistance	Verify repair

Excessive Exhaust Emissions or Odors Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Vehicle fails an emission test. Vehicle has excessive "rotten egg" smell. (Excessive odors do not necessarily indicate excessive emissions.) Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Go to Step 13	Go to Step 3
3	Was a thorough visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Check for vacuum leaks. Check vacuum lines, intake manifold, throttle body, etc. 2. If a problem is found, repair as necessary. Were any vacuum leaks located?	—	Go to Step 13	Go to Step 5
5	1. Check the fuel cap for proper installation. 2. Secure the fuel cap if necessary. Was the fuel cap installed properly?	—	Go to Step 6	Go to Step 13
6	1. Check the fuel pressure. Perform the procedure in <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 13	Go to Step 7
7	1. Check for a faulty, plugged, or incorrectly installed crankcase ventilation valve; also check the crankcase ventilation system for plugging. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 13	Go to Step 8
8	1. Check the injector connections. 2. If any of the injectors are connected to an incorrect cylinder, correct as necessary. Was a problem found?	—	Go to Step 13	Go to Step 9
9	1. Perform the "Injector Coil/Balance Test" in <i>Fuel Metering System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 13	Go to Step 10
10	1. Refer to <i>Engine Cooling</i> for cooling system diagnosis. 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 13	Go to Step 11
11	1. Check EVAP canister for fuel loading. Refer to <i>Evaporative Emission Control System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to Step 13	Go to Step 12

Excessive Exhaust Emissions or Odors Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
12	1. Remove excessive carbon buildup with a top engine cleaner. Refer to the instructions on the top engine cleaner can. 2. Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to <i>Step 14</i>
13	Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to <i>Step 14</i>
14	Does the exhaust emission test indicate excessive CO and HC levels or is long term fuel trim significantly in the negative range (rich condition)?	—	Go to <i>Step 15</i>	Go to <i>Step 16</i>
15	1. Check items that can cause the engine to run rich. Refer to <i>Diagnostic Aids</i> in <i>DTC P0172 Diagnostic Support</i> . Make any necessary repairs. 2. Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to <i>Step 17</i>
16	1. Check items that can cause the engine to run lean. Refer to <i>Diagnostic Aids</i> in <i>DTC P0171 Diagnostic Support</i> . Make any necessary repairs. 2. Perform the exhaust emission test. Does the vehicle pass the test?	—	System OK	Go to <i>Step 17</i>
17	1. Check the EGR system (refer to <i>DTC P0401</i>). 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to <i>Step 13</i>	Go to <i>Step 18</i>
18	1. Check for an engine mechanical problem. Perform a cylinder compression check (refer to <i>Engine Mechanical</i>). 2. If a problem is found, repair as necessary. Was a problem found?	—	Go to <i>Step 13</i>	Go to <i>Step 19</i>
19	1. Review all diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system. 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Contact Technical Assistance

Dieseling, Run-On Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Engine continues to run after key is turned "OFF," but runs very rough. If engine runs smooth, check ignition switch and adjustment. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Check for a short between B+ and any of the ignition feed circuits. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Review all diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records butter ○ All electrical connections within a suspected circuit and/or system 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Contact Technical Assistance

Backfire Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Fuel ignites in the intake manifold, or in the exhaust system, making a loud popping noise. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Check for proper ignition voltage coil output with spark tester J 26792 (ST-125). Refer to <i>Electronic Ignition System</i> for procedure. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Remove spark plugs and check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i> . NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs. Refer to <i>DTC P0172</i> to determine the cause of a rich condition or <i>Engine Mechanical</i> for an oil fouling condition. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	1. Visually/physically inspect the ignition coils for cracks. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 7
7	1. Check for an intermittent ignition system malfunction: <ul style="list-style-type: none"> ○ Intermittent CKP 58X signal. ○ Intermittent ignition feed circuit or sensor ground circuit to the crankshaft position sensor. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 8
8	1. Check the fuel pressure. Refer to <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9

Backfire Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
9	<p>1. Check for the following engine mechanical conditions. Refer to <i>Engine Mechanical</i> for diagnosis procedures:</p> <ul style="list-style-type: none"> <input type="radio"/> Low compression <input type="radio"/> Sticking or leaking valves <input type="radio"/> Worn camshaft lobe(s) <input type="radio"/> Camshaft drive belt slipped or stripped <input type="radio"/> Incorrect valve timing <p>2. If a problem is found, repair as necessary. Was a problem found?</p>	—	Verify repair	Go to <i>Step 10</i>
10	<p>1. Check the intake and exhaust manifold(s) for casting flash. Refer to <i>Engine Mechanical</i>.</p> <p>2. If a problem is found, repair as necessary. Was a problem found?</p>	—	Verify repair	Go to <i>Step 11</i>
11	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All electrical connections within a suspected circuit and/or system. <p>3. If a problem is found, repair as necessary. Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

Cuts Out, Misses Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Steady pulsation or jerking that follows engine speed; usually more pronounced as engine load increases. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Go to Step 13	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Check the PCM grounds for clearness, tightness and proper routing. Refer to the PCM wiring diagrams in <i>Electrical Diagnosis</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	Observe the long term fuel trim on the Tech 2. Is the long term fuel trim significantly in the negative range (rich condition)?	—	Go to Step 6	Go to Step 7
6	1. Check items that can cause the engine to run rich. Refer to <i>Diagnostic Aids</i> in <i>DTC P0172 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
7	Is the long term fuel trim significantly in the positive range (lean condition)?	—	Go to Step 8	Go to Step 9
8	1. Check items that can cause the engine to run lean. Refer to <i>Diagnostic Aids</i> in <i>DTC P0171 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 9
9	1. Check for incorrect idle speed. Ensure that the following conditions are present: <ul style="list-style-type: none"> ○ The engine is fully warm. ○ The accessories are "off." 2. Using a Tech 2, monitor the IAC position. Is the IAC position within the specified values?	Between 5 and 50 counts	Go to Step 11	Go to Step 10

Cuts Out, Misses Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
10	<p>1. Visually/physically inspect for the following conditions:</p> <ul style="list-style-type: none"> ○ Restricted air intake system. Check for a possible collapsed air intake duct, restricted air filter element, or foreign objects blocking the air intake system. ○ Throttle body. Check for objects blocking the IAC passage or throttle bore, excessive deposits in the IAC passage and on the IAC pintle, and excessive deposits in the throttle bore and on the throttle plate. ○ Large vacuum leak. Check for a condition that causes a large vacuum leak, such as an incorrectly installed or faulty PCV valve or brake booster hose disconnected. <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 8
11	<p>Check the injector connections. If any of the injectors are connected to an incorrect cylinder, correct as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 12
12	<p>1. Perform the "Injector Coil/Balance Test" in <i>Fuel Metering System</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>1. Check for fuel in the pressure regulator vacuum hose.</p> <p>2. If fuel is present, replace the fuel pressure regulator assembly. Refer to <i>Fuel Metering System</i>.</p> <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 14
14	<p>1. Check for proper ignition voltage output with spark tester J 26792 (ST-125). Refer to <i>Electronic Ignition System</i> for the procedure.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 15
15	<p>1. Remove spark plugs. Check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i>.</p> <p>NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>1. Check for a loose ignition coil ground. Refer to <i>Electronic Ignition System</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 17

Cuts Out, Misses Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
17	1. Check ignition coils for cracks or carbon tracking. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 18</i>
18	Using a Tech 2, monitor the TP angle with the engine idling. Is the TP angle at the specified value and steady?	0%	Go to <i>Step 19</i>	Refer to <i>DTC P0123</i> for further diagnosis
19	1. Check the PCV valve for proper operation. Refer to <i>Crankcase Ventilation System</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 20</i>
20	1. Check the transmission range switch circuit. Use a Tech 2 and be sure the Tech 2 indicates that the vehicle is in drive with the gear selector in drive or overdrive. 2. If a problem is found, diagnose and repair the transmission range switch as necessary (refer to <i>4L30-E Automatic Transmission Diagnosis</i>). Was a problem found?	—	Verify repair	Go to <i>Step 21</i>
21	1. Check the following engine mechanical items. Refer to <i>Engine Mechanical</i> for diagnosis procedures: <ul style="list-style-type: none"> <input type="radio"/> Low compression <input type="radio"/> Sticking or leaking valves <input type="radio"/> Worn camshaft lobe(s) <input type="radio"/> Camshaft drive belt slipped or stripped <input type="radio"/> Incorrect valve timing <input type="radio"/> Worn rocker arms <input type="radio"/> Broken valve springs 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 22</i>
22	1. Check for faulty motor mounts. Refer to <i>Engine Mechanical</i> for inspection of mounts. 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to <i>Step 23</i>
23	1. Review all diagnostic procedures within this table. 2. If all procedures have been completed and no malfunctions have been found, review/inspect the following: <ul style="list-style-type: none"> <input type="radio"/> Visual/physical inspection <input type="radio"/> Tech 2 data <input type="radio"/> Freeze Frame data/Failure Records buffer <input type="radio"/> All electrical connections within a suspected circuit and/or system 3. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Contact Technical Assistance

Hesitation, Sag, Stumble Symptom

Step	Action	Value(s)	Yes	No
1	DEFINITION: Momentary lack of response as the accelerator is pushed down. Can occur at any vehicle speed. Usually most pronounced when first trying to make the vehicle move, as from a stop sign. May cause the engine to stall if severe enough. Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Perform a bulletin search. 2. If a bulletin that addresses the symptom is found, correct the condition as instructed in the bulletin. Was a bulletin found that addresses the symptom?	—	Verify repair	Go to Step 3
3	Was a visual/physical check performed?	—	Go to Step 4	Go to <i>Visual/Physical Check</i>
4	1. Check the fuel control heated oxygen sensors (HO2S, B1S1 and B2S1). The fuel control heated oxygen sensors (HO2S) should respond quickly to different throttle positions. If they don't, check them for silicon or other contaminants from fuel or use of improper RTV sealant. The sensors may have a white powdery coating. Silicon contamination causes a high but false HO2S signal voltage (rich exhaust indication). The PCM will then reduce the amount of fuel delivered to the engine, causing a severe driveability problem. For more information, refer to <i>Powertrain Control Module (PCM) and Sensors</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 5
5	1. Check the fuel pressure. Refer to <i>Fuel System Pressure Test</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 6
6	Observe the TP angle display on the Tech 2 while slowly increasing throttle pedal. Does the TP angle display steadily increase from 0% at closed throttle to 100% at WOT?	—	Go to Step 7	Go to Step 18
7	Monitor the long term fuel trim on the Tech 2. Is the long term fuel trim significantly in the negative range (rich condition)?	—	Go to Step 8	Go to Step 9
8	1. Check items that can cause the engine to run rich. Refer to <i>Diagnostic Aids in DTC P0172 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10
9	1. Check items that can cause the engine to run lean. Refer to <i>Diagnostic Aids in DTC P0171 Diagnostic Support</i> . 2. If a problem is found, repair as necessary. Was a problem found?	—	Verify repair	Go to Step 10

Hesitation, Sag, Stumble Symptom (Cont'd)

Step	Action	Value(s)	Yes	No
10	<p>1. Check for proper ignition voltage output with spark tester J 26792 (ST-125). Refer to <i>Electronic Ignition System</i> for the procedure.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 11
11	<p>1. Check for a loose ignition coil ground. Refer to <i>Electronic Ignition System</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 12
12	<p>1. Check the ignition coils for cracks or carbon tracking.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 13
13	<p>1. Remove spark plugs and check for wet plugs, cracks, wear, improper gap, burned electrodes, or heavy deposits. Refer to <i>Electronic Ignition System</i>.</p> <p>NOTE: If spark plugs are gas or oil fouled, the cause of the fouling must be determined before replacing the spark plugs.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 14
14	<p>1. Check the PCM grounds for clearness, tightness and proper routing. Refer to the PCM wiring diagrams in <i>Electrical Diagnosis</i>.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 15
15	<p>1. Check the MAF sensor connections.</p> <p>2. If a problem is found, replace the faulty terminals as necessary. Refer to <i>Electrical Diagnosis</i> for wiring repair procedures.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 16
16	<p>1. Visually/physically check vacuum hoses for splits, kinks, and proper connections and routing as shown on the "Vehicle Emission Control Information" label.</p> <p>2. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Go to Step 17
17	<p>1. Review all diagnostic procedures within this table.</p> <p>2. If all procedures have been completed and no malfunctions have been found, review/inspect the following:</p> <ul style="list-style-type: none"> ○ Visual/physical inspection ○ Tech 2 data ○ Freeze Frame data/Failure Records buffer ○ All electrical connections within a suspected circuit and/or system <p>3. If a problem is found, repair as necessary.</p> <p>Was a problem found?</p>	—	Verify repair	Contact Technical Assistance

Bank 1 Restricted Exhaust System Check (Manual Transmission)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performs?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	1. Remove the Bank 1 HO2S 3. 2. Install the Exhaust Backpressure Tester (BT-8515-V or equivalent) in place of the Bank 1 HO2S 3. 3. Run the engine at normal operating temperature. 4. Increase the engine speed to 2000 RPM and allow 10 seconds for pressure to build. 5. Observe the exhaust system backpressure reading on the gauge. Does the reading exceed the amount in the value column?	8.62 kPa (1.25 psi)	Go to Step 3	Go to Step 4
3	Repair the restriction in the exhaust system after the catalytic converter. Possible faults include: ○ Collapsed pipe ○ Heat distress ○ Internal muffler failure Is the action complete?	—	Verify repair	—
4	1. Install the Bank 1 HO2S 3. 2. Install the Exhaust Backpressure Tester in place of Bank 1 HO2S 2. 3. Run the engine at normal operating temperature. 4. Increase the engine speed to 2000 RPM and allow 10 seconds for pressure to build. 5. Observe the exhaust system backpressure reading on the gauge. Does the reading exceed the amount in the value column?	8.62 kPa (1.25 psi)	Go to Step 5	No trouble found. If a driveability symptom exists, refer to symptom charts
5	Repair the restriction in the catalytic converter. Is the action complete?	—	Verify repair	—

NOTE: DTCs will be set by running the vehicle to normal operating temperature after a cold start with the O2 sensor disconnected. After performing these tests, use the Tech 2 to erase the DTCs that were set by the lack of O2 sensor activity.

Bank 1 Restricted Exhaust System Check (Automatic Transmission)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performs?	—	Go to <i>Step 2</i>	Go to <i>OBD System Check</i>
2	1. Remove the Bank 1 HO2S 2. ○ Refer to <i>On-Vehicle Service, Heated Oxygen Sensors</i> for removal procedures. 2. Install the Exhaust Backpressure Tester (BT-8515-V or equivalent) in place of the Bank 1 HO2S 2. 3. Run the engine at normal operating temperature. 4. Increase the engine speed to 2000 RPM and allow 10 seconds for pressure to build. 5. Observe the exhaust system backpressure reading on the gauge. Does the reading exceed the amount in the value column?	8.62 kPa (1.25 psi)	Go to <i>Step 3</i>	Go to <i>Step 4</i>
3	Repair the restriction in the exhaust system after the catalytic converter. Possible faults include: ○ Collapsed pipe ○ Heat distress ○ Internal muffler failure Is the action complete?	—	Verify repair	—
4	1. Install the Bank 1 HO2S 2. ○ Refer to <i>On-Vehicle, Heated Oxygen Sensors</i> for installation procedures. 2. Install the Exhaust Backpressure Tester in place of Bank 1 HO2S 1. 3. Run the engine at normal operating temperature. 4. Increase the engine speed to 2000 RPM and allow 10 seconds for pressure to build. 5. Observe the exhaust system backpressure reading on the gauge. Does the reading exceed the amount in the value column?	8.62 kPa (1.25 psi)	Go to <i>Step 5</i>	No trouble found. If a driveability symptom exists, refer to <i>Section B-1</i> symptom charts
5	Repair the restriction in the catalytic converter. Is the action complete?	—	Verify repair	—

NOTE: DTCs will be set by running the vehicle to normal operating temperature after a cold start with the O2 sensor disconnected. After performing these tests, use the Tech 2 to erase the DTCs that were set by the lack of O2 sensor activity.

Bank 2 Restricted Exhaust System Check (Automatic Transmission)

Step	Action	Value(s)	Yes	No
1	Was the "On-Board Diagnostic (OBD) System Check" performed?	—	Go to Step 2	Go to <i>OBD System Check</i>
2	<ol style="list-style-type: none"> Remove the Bank 2 HO2S 2. <ul style="list-style-type: none"> Refer to <i>On-Vehicle Service, Heated Oxygen Sensors</i> for removal procedures. Install the Exhaust Backpressure Tester (BT-8515-V or equivalent) in place of the Bank 2 HO2S 2. Run the engine at normal operating temperature. Increase the engine speed to 2000 RPM and allow 10 seconds for pressure to build. Observe the exhaust system backpressure reading on the gauge. <p>Does the reading exceed the amount in the value column?</p>	8.62 kPa (1.25 psi)	Go to Step 3	Go to Step 4
3	<p>Repair the restriction in the exhaust system after the catalytic converter.</p> <p>Possible faults include:</p> <ul style="list-style-type: none"> Collapsed pipe Heat distress Internal muffler failure <p>Is the action complete?</p>	—	Verify repair	—
4	<ol style="list-style-type: none"> Install the Bank 2 HO2S 2. <ul style="list-style-type: none"> Refer to <i>On-Vehicle Service, Heated Oxygen Sensors</i> for installation procedures. Install the Exhaust Backpressure Tester in place of Bank 1 HO2S 1. Run the engine at normal operating temperature. Increase the engine speed to 2000 RPM and allow 10 seconds for pressure to build. Observe the exhaust system backpressure reading on the gauge. <p>Does the reading exceed the amount in the value column?</p>	8.62 kPa (1.25 psi)	Go to Step 5	No trouble found. If a driveability symptom exists, refer to <i>Section B-1</i> symptom charts
5	<p>Repair the restriction in the catalytic converter.</p> <p>Is the action complete?</p>	—	Verify repair	—

NOTE: DTCs will be set by running the vehicle to normal operating temperature after a cold start with the O2 sensor disconnected. After performing these tests, use the Tech 2 to erase the DTCs that were set by the lack of O2 sensor activity.

Default Matrix Table

Service Procedure Default Strategy

A referral strategy has been established to assist the technician with additional information when the cause of the failure cannot be determined. If no problem is found after performing diagnostics, then refer to the default matrix table for further diagnostic information.

Default Matrix Table

Strategy Based Diagnostic Charts	Initial Diagnosis	Default Section(s)
On-Board Diagnostic (OBD) System Check	Vehicle does not enter diagnostics.	Chassis Electrical
On-Board Diagnostic (OBD) System Check	Vehicle enters diagnostics and communicates with the Tech 2. MIL is "ON" in diagnostics. Engine does not start and run.	Ignition System Check
On-Board Diagnostic (OBD) System Check	Engine starts and runs, no PCM codes set. Customer complains of vibration.	—
On-Board Diagnostic (OBD) System Check	Engine starts and runs, no PCM codes set. Customer complains of harsh or soft shift, poor performance, delayed or no engagement into drive or reverse, transmission fluid leak, transmission noise or vibration, or improper TCC operation.	Automatic Transmission
PCM Power and Ground Check	On-Board Diagnostic (OBD) System Check.	Chassis Electrical
PCM Power and Ground Check	On-Board Diagnostic (OBD) System Check. PCM power and ground circuits OK. Data link voltage incorrect.	Chassis Electrical
On-Board Diagnostic (OBD) System Check	Engine starts and runs, no PCM codes set. Customer complains of harsh or soft shift, poor performance, delayed or no engagement into drive or reverse, transmission fluid leak, transmission noise or vibration, or improper TCC operation.	Automatic Transmission

Symptoms	Initial Diagnosis	Default Section(s)
Intermittents	<ol style="list-style-type: none"> On-board diagnostic (OBD) system check. Careful visual/physical inspections. 	Chassis Electrical
Hard Starts	<ol style="list-style-type: none"> OBD system check. Sensors (ECT, MAP, MAF, TP) ; MAP output chart. Fuel system electrical test, fuel system diagnosis. Ignition system. IAC system check. 	Engine Mechanical, Ignition System Check, Exhaust System Diagnosis
Surges and/or Chuggles	<ol style="list-style-type: none"> OBD system check. Heated oxygen sensors. Fuel system diagnosis. Ignition system. 	Calibration ID "Broadcast" /Service Bulletins, Ignition System Check, Generator Output, Exhaust System Diagnosis, 4L30-E System Test

Lack of Power, Sluggish or Spongy	<ol style="list-style-type: none"> 1. OBD system check. 2. Fuel system diagnosis. 3. Ignition system. 4. Knock sensor. 5. EGR operation. 6. EGR system check. 	Refer to <i>Exhaust System</i> in <i>Engine Exhaust</i> , TCC Operation, Calibration ID/Service Bulletins
Detonation/Spark Knock	<ol style="list-style-type: none"> 1. OBD system check. 2. Transmission range switch. 3. EGR operation. 4. EGR system check. 5. TCC operation. 6. Fuel system diagnosis. 7. Ignition system. 8. Knock sensor. 	TCC operation, Cooling System, Ignition System Check, Calibration ID/Service Bulletins
Hesitation, Sag, Stumble	<ol style="list-style-type: none"> 1. OBD system check. 2. TP. 3. MAP output check. 4. Fuel system diagnosis. 5. Fuel injector and fuel injector balance test. 6. EVAP emission canister purge valve. 7. Ignition system. 	EGR Operation, EGR System Check, Generator Output Voltage (refer to <i>Chassis Electrical</i>), Calibration ID/Service Bulletins, Ignition System Check
Cuts Out, Misses	<ol style="list-style-type: none"> 1. OBD system check. 2. Cylinder balance test. 	Ignition System Check
Rough, Unstable, or Incorrect Idle, Stalling	<ol style="list-style-type: none"> 1. OBD system check. 2. Fuel injector and fuel injector balance test. 3. EVAP emission canister purge valve check. 4. Ignition system. 5. IAC operation. 6. EGR operation. 	MAP Output Check, Throttle Linkage, IAC System Check, EGR System Check, A/C Clutch Control Circuit Diagnosis, Crankcase Ventilation System, Calibration ID/Service Bulletins, Generator Output Voltage (refer to <i>Chassis Electrical</i>), Exhaust Diagnosis
Poor Fuel Economy	<ol style="list-style-type: none"> 1. OBD system check. 2. Careful visual/physical inspection. 3. Ignition system. 4. Cooling system. 	TCC Operation, Exhaust System (refer to <i>Engine Exhaust</i>)
Engine Cranks But Will Not Run	<ol style="list-style-type: none"> 1. OBD system check. 	Fuel System Electrical Diagnosis, Fuel System Diagnosis, Fuel Injector and Fuel Injector Balance Test.
Excessive Exhaust Emissions or Odors	<ol style="list-style-type: none"> 1. OBD system check. 2. Emission test. 3. Cooling system. 4. Fuel system diagnosis. 5. Fuel injector and fuel injector balance test. 6. EVAP emission canister purge valve. 7. Crankcase ventilation system. 8. Ignition system. 9. MAP output check. 	EGR System Check, Exhaust Diagnosis, Calibration ID/Service Bulletins


6E2-448 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

Dieseling, Run-On	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Fuel system diagnosis.	—
Backfire	<ol style="list-style-type: none">1. OBD system check.2. Ignition system.3. Fuel system diagnosis.4. Fuel injector and fuel injector balance test.5. EGR operation, EGR system check.	Exhaust System Diagnosis, Intake Casting Flash, Ignition System Check
Misfire	<ol style="list-style-type: none">1. OBD system check.2. Ignition system.3. Fuel system diagnosis.4. Fuel injector and fuel injector balance test.	Vibrations, Transmission, Driveshaft and Axle
Catalyst Monitor	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Heated oxygen sensors.	Exhaust System
Fuel Trim	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Fuel system diagnosis.4. Heated oxygen sensors, MAF sensors.	Exhaust System Intake Air System
Evaporative Emissions	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.3. Fuel system diagnosis.	—
Heated Oxygen Sensors	<ol style="list-style-type: none">1. OBD system check.2. Careful visual/physical inspection.	Exhaust System


On-Vehicle Service Camshaft Position (CMP) Sensor

Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the engine cover.
3. Remove the common chamber assembly.
Refer to Common Chamber in Engine Mechanical.



4. Disconnect the electrical connector to the CMP sensor.



5. Remove the CMP retaining bolt from the side of left cylinder head.
6. Remove the CMP sensor from the cylinder head.


Inspection Procedure

1. Inspect the sensor O-ring for cracks or leaks.
2. Replace the O-ring if it is worn or damaged.
3. Lubricate the new O-ring with engine oil.


4. Install the lubricated O-ring.

Installation Procedure

1. Install the CMP sensor in the cylinder head.
 2. Install the CMP sensor retaining bolt.
- Tighten**
 ○ Tighten the retaining screw to 9 N·m (78 lb in.).
3. Connect the electrical connector to the CMP sensor.



4. Install the common chamber assembly.
Refer to Common Chamber in Engine Mechanical.




5. Install the engine cover.
6. Connect the negative battery cable.

Crankshaft Position (CKP) Sensor

Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the electrical connector to the CKP sensor.
3. Remove one bolt and the CKP sensor from the right side of the engine block, just behind the mount.

NOTE: Use caution to avoid any hot oil that might drip out.



TS22909

Inspection Procedure


1. Inspect the sensor O-ring for cracks or leaks.
2. Replace the O-ring if it is worn or damaged.
3. Lubricate the new O-ring with engine oil.
4. Install the lubricated O-ring.

Installation Procedure

1. Install the CKP sensor in the engine block.
2. Install the CKP sensor mounting bolt.

Tighten

○ Tighten the mounting bolt to 9 N·m (78 lb in.).



TS22909


3. Connect the electrical connector to the CKP sensor.
4. Connect the negative battery cable.

Engine Coolant Temperature (ECT) Sensor

Removal Procedure


NOTE: Care must be taken when handling the engine coolant temperature (ECT) sensor. Damage to the ECT sensor will affect proper operation of the fuel injection system.

1. Disconnect the negative battery cable.
2. Drain the radiator coolant. Refer to *Draining and Refilling Cooling System in Engine Cooling*.
3. Disconnect the electrical connector.




014RW127

4. Remove the ECT sensor from the coolant crossover.



3. Connect the electrical connector.




Installation Procedure

1. Apply sealer or the equivalent to the threads of the ECT sensor.
2. Install the ECT sensor in the coolant crossover.

Tighten

- Tighten the ECT sensor to 30 N·m (22 lb ft.).




4. Fill the radiator with coolant. Refer to *Draining and Refilling Cooling System* in *Engine Cooling*.
5. Connect the negative battery cable.

Heated Oxygen Sensor (HO2S)


Removal Procedure

1. Disconnect the negative battery cable.
2. Locate the four oxygen sensors.




6E2-452 RODEO 6VD1 3.2L ENGINE DRIVEABILITY AND EMISSIONS

- Bank 1 sensor 1 is mounted on the exhaust pipe ahead of the right-hand catalytic converter.




TS22912

- Bank 1 sensor 2 is mounted behind the right-hand catalytic converter.




TS22913

- Bank 2 sensor 1 is mounted on the exhaust pipe ahead of the left-hand catalytic converter.



TS22914

- Bank 2 sensor 2 is mounted behind the left-hand catalytic converter.



TS22915


3. Disconnect the pigtail from the wiring harness.

IMPORTANT: The pigtail is permanently attached to the sensor. Be careful not to pull the wires out.

NOTE: Do not use a torch to remove an HO₂S unless the sensor is being replaced. Using a torch could damage the sensor.

4. Remove the sensor from the exhaust pipe.


- Because of the expansion and contraction of the metal in the exhaust system over time, this may be difficult if the engine temperature is below 48°C (120°F).



Inspection Procedure

All four sensors are identical. Inspect each in the same way.

1. Inspect the pigtail and the electrical connector for grease, dirt, corrosion, and bare wires or worn insulation.
2. Inspect the louvered end of the sensor for grease, dirt, or other contaminations.




Installation Procedure

IMPORTANT:

- A special anti-seize compound, P/N 5613695, is used on the HO2S threads. This compound consists of glass beads suspended in a liquid graphite solution. The graphite burns away with engine heat, but the glass beads will remain, making the sensor easier to remove.
 - New or service sensors will already have the compound applied to the threads. If a sensor is removed and is to be reinstalled for any reason, the threads must have anti-seize compound applied.
1. Apply anti-seize compound or the equivalent to the threads of the oxygen sensor, if necessary.
 2. Install the oxygen sensor on the exhaust pipe in its original position.

Tighten

- Tighten the oxygen sensor to 55 N·m (40 lb in.).




3. Connect the pigtail to the wiring harness.
4. Connect the negative battery cable.

Intake Air Temperature (IAT) Sensor

Removal Procedure

1. Disconnect the negative battery cable.
2. Remove the engine cover
3. The IAT sensor is located in the intake air duct, behind the throttle body.


4. Disconnect the electrical connector from the IAT sensor.



5. Remove the IAT sensor from the intake air duct by using a rocking motion while pulling the sensor.

Installation Procedure

1. Install the IAT sensor into the grommet in the intake air duct.
2. Connect the IAT electrical connector.




3. Install the engine cover.
4. Connect the negative battery cable.


Knock Sensor (KS)

Removal Procedure

1. Disconnect the negative battery cable.
2. Drain the cooling system. Refer to *Draining and Filling the Cooling System* in *Engine Cooling*.
3. Remove the engine cover.
4. Remove the common chamber assembly. Refer to Common Chamber in *Engine Mechanical*.



5. Disconnect the electrical connector from the knock sensor.



6. Unscrew the knock sensor from the engine block.


Installation Procedure

NOTE: Do not apply thread sealant to the sensor threads. The sensor is coated at the factory and applying additional sealant will affect the sensor's ability to detect detonation.

1. Screw the knock sensor into the engine block.


Tighten

- Tighten the knock sensor to 20 N·m (177 lb in.).



014RW103

2. Connect the electrical connector to the knock sensor.
3. Install the common chamber assembly.
Refer to Common Chamber in Engine Mechanical.




014RW106

4. Install the engine cover.
5. Fill the cooling system.
Refer to Draining and Filling the Cooling System in Engine Cooling.
6. Connect the negative battery cable.

Mass Air Flow (MAF) Sensor


Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the electrical connector from the MAF sensor.



TS23740

3. Loosen the clamps which secure the intake air duct and the air cleaner to the MAF sensor.
4. Remove the intake air duct from the MAF sensor.
5. Remove the MAF sensor from the air cleaner.




TS23781

Installation Procedure

1. Install the MAF sensor on the air cleaner with the clamp.

2. Install the intake air duct and the clamp on the MAF sensor.




3. Tighten the clamps to secure the MAF sensor to the intake air duct and the air cleaner.
4. Connect the MAF electrical connector.
5. Connect the negative battery cable.

Manifold Absolute Pressure (MAP) Sensor


Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the electrical connector from the MAP sensor.




3. Remove the bolt securing the MAP sensor to the mounting bracket on the common chamber.

4. Remove the MAP sensor from the mounting bracket.



Installation Procedure

1. Install the MAP sensor in the mounting bracket.
2. Install the mounting bracket retaining bolt on the common chamber.
3. Connect the MAP electrical connector.



4. Connect the negative battery cable.

Malfunction Indicator Lamp (MIL)

Removal and Installation Procedure

Refer to Warning light bulb, indicator light valve, illumination light bulb, A/T indicator light bulb in Meter and Gauge.

Powertrain Control Module (PCM)

Service Precaution

NOTE: To prevent possible electrostatic discharge damage to the PCM, do not touch the connector pins or soldered components on the circuit board.

Electrostatic Discharge (ESD) Damage

Electronic components used in the control systems are often designed to carry very low voltage. Electronic components are susceptible to damage caused by electrostatic discharge. Less than 100 volts of static electricity can cause damage to some electronic components. By comparison, it takes as much as 4,000 volts for a person to even feel the zap of a static discharge.

There are several ways for a person to become statically charged. The most common methods of charging are by friction and by induction. An example of charging by friction is a person sliding across a car seat.

Charging by induction occurs when a person with well insulated shoes stands near a highly charged object and momentarily touches ground. Charges of the same polarity are drained off leaving the person highly charged with the opposite polarity. Static charges can cause damage, therefore, it is important to use care when handling and testing electronic components.

NOTE: To prevent possible Electrostatic Discharge damage, follow these guidelines:

- Do not touch the control module connector pins or soldered components on the control module circuit board.
- Do not open the replacement part package until the part is ready to be installed.
- Before removing the part from the package, ground the package to a known good ground on the vehicle.
- If the part has been handled while sliding across the seat, or while sitting down from a standing position, or while walking a distance, touch a known good ground before installing the part.

NOTE: To prevent internal PCM damage, the ignition must be in the "OFF" position in order to disconnect or reconnect power to the PCM (for example: battery cable, PCM pigtail, PCM fuse, jumper cables, etc.).

IMPORTANT: When replacing the production PCM with a service PCM, it is important to transfer the broadcast code and production PCM number to the service PCM label. This will allow positive identification of PCM parts throughout the service life of the vehicle. Do not record this information on the metal PCM cover.


IMPORTANT: The ignition should always be in the "OFF" position in order to install or remove the PCM connectors.

Service of the PCM should normally consist of either replacement of the PCM or EEPROM programming. If the diagnostic procedures call for the PCM to be replaced, the PCM should be checked first to ensure it is the correct part. If it is, remove the faulty PCM and install the new service PCM.

The service PCM EEPROM will not be programmed. DTC P0601 indicates the check sum error.


Removal Procedure

1. Disconnect the negative battery cable.
2. Block the wheels.
3. Remove the two screws attaching the rear console and lift the upward rear console, then disconnect the switch connector.
4. Remove the lower cluster assembly by pulling the cover toward the rear.
5. Remove the transfer knob.
6. Remove the six screws attaching the upper console and front console.




014RW128

7. Disconnect the red, white, and blue electrical connectors at the PCM.
8. Remove the two screws in the front of the PCM.
9. Remove the one screws at the left rear of the PCM.
10. Pull the PCM straight out from the dashboard.




Installation Procedure

1. Insert the PCM into the dashboard.
 - Line up the holes in front for the mounting screws.
2. Install the PCM with two screws in the front and one screw at the left rear.
3. Plug the red, white, and blue connectors into the appropriate sockets.



4. Install the front console and lower console.
5. Install the transfer knob.

6. Connect the switch connector and install the rear console.



If the PCM is replaced, the new PCM will need to be programmed.

EEPROM

General Description

The Electronically Erasable Programmable Read Only Memory (EEPROM) is a permanent memory that is physically soldered within the PCM. The EEPROM contains program and calibration information that the PCM needs to control powertrain operation.

EEPROM Programming

1. Step-up – Ensure that the following conditions have been met:
 - The battery is fully charged.
 - The ignition is “ON.”
 - The Vehicle Interface Module cable connection at the DLC is secure.
2. Program the PCM using the latest software matching the vehicle. Refer to up-to-date Techline equipment user's instructions.
3. If the PCM fails to program, proceed as follows:
 - Ensure that all PCM connections are OK.
 - Check the Techline equipment for the latest software version.
 - Attempt to program the PCM. If the PCM still cannot be programmed properly, replace the PCM. The replacement PCM must be programmed.


Functional Check

1. Perform the On-Board Diagnostic System Check.
2. Start the engine and run for one minute.
3. Scan for DTCs using the Tech 2.

Throttle Position (TP) Sensor

Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the TPS electrical connector.
3. Remove the bolts and the TP sensor from the throttle body.



NOTE: Do not clean the TP sensor by soaking it in solvent. The sensor will be damaged as a result.


Function Check

Use a Tech 2 to check the TP sensor output voltage at closed throttle.

- The voltage should be under 0.85 volt.
- If the reading is greater than 0.85 volt, check the throttle shaft to see if it is binding. Check that the throttle cable is properly adjusted, also. Refer to *Throttle Cable Adjustment*.
- If the throttle shaft is not binding and the throttle cable is properly adjusted, install a new TP sensor.

Installation Procedure

1. Install the TP sensor on the throttle body with the bolts.




2. Connect the TP electrical connector.
3. Install the negative battery cable.

Vehicle Speed Sensor (VSS)

Removal Procedure


CAUTION: The VSS is located on the right side of the transfer case just ahead of the rear propeller shaft and very close to the exhaust pipes. Be sure that the exhaust pipes are cool enough to touch before trying to remove the VSS. If the pipes are hot, you could be burned.

1. Disconnect the negative battery cable.
2. Disconnect the VSS electrical connector.



3. Remove the bolt and the clamp securing the VSS in place.

IMPORTANT: Have a container ready to catch any fluid that leaks out when the VSS is removed from the transfer case.



4. Remove the VSS from the transfer case by wiggling it slightly and pulling it straight out.

Inspection Procedure

1. Inspect the electrical connector for signs of corrosion or warping. Replace the VSS if the electrical connector is corroded or warped.
2. Inspect the VSS driven gear for chips, breaks, or worn condition. Replace the VSS if the driven gear is chipped, broken or worn.
3. Inspect the O-ring for wear, nicks, tears, or looseness. Replace the O-ring if necessary.


Installation Procedure

1. Install the VSS in the transfer case with the notch for the connector facing the rear.


2. Secure the VSS in place with the clamp and the bolt.

Tighten

○Tighten the bolt to 16 N·m (12 lb ft.).



3. Connect the VSS electrical connector.




4. Check the transfer case oil level. Add fluid if necessary.
5. Connect the negative battery cable.


Air Cleaner/Air Filter

Removal Procedure


1. Loosen the clamp between the air cleaner lid and the mass air flow sensor.
2. Release the four latches securing the lid to the air cleaner housing.
3. Remove the air cleaner lid.



4. Remove the air filter element.




5. Remove the retaining bolts and the air cleaner housing from the vehicle.




Installation Procedure


1. Install the air cleaner housing in the vehicle with the retaining bolts.



2. Install the air filter element in the air cleaner housing.



3. Install the air cleaner lid on the MAF sensor and the air cleaner housing.




4. Tighten the clamp and secure the four latches between the lid and the air cleaner housing.

Idle Air Control (IAC) Valve

Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect the IAC electrical connector.
3. Remove the bolts and the IAC valve from the throttle body.

NOTE: Do not clean the IAC valve by soaking it in solvent. The valve will be damaged as a result.



Cleaning, Inspection, and Measurement Procedure


- Clean the IAC valve O-ring sealing surface, pintle valve seat and air passage.
 - Use carburetor cleaner and a parts cleaning brush to remove carbon deposits. Do not use a cleaner that contains methyl ethyl ketone. This is an extremely strong solvent and not necessary for this type of deposit.
 - Shiny spots on the pintle are normal and do not indicate misalignment or a bent pintle shaft.
 - If the air passage has heavy deposits, remove the throttle body for complete cleaning.



- Inspect the IAC valve O-ring for cuts, cracks, or distortion. Replace the O-ring if damaged.
- In order to install a new IAC valve, measure the distance between the tip of the pintle and the mounting flange. If that measurement is 28 mm (1.1 in.) or less, the valve needs no adjustment. If the measurement is greater than 28 mm (1.1 in.), apply finger pressure and retract the valve. The force required to retract the pintle on a new valve will not damage the valve, shaft, or pintle.

NOTE: Do not push or pull on the IAC valve pintle on IAC valves that have been in service. The force required to move the pintle may damage it.

IMPORTANT: Use an identical replacement part in order to replace a valve. IAC valve pintle shape and diameter are designed for the specific application.




Installation Procedure

1. Install the IAC valve on the throttle body with the bolts.

Tighten

- Tighten the bolts to 1 N·m (9 lb in.).



2. Connect the IAC valve electrical connector.
3. Install the negative battery cable.

Common Chamber


Removal and Installation Procedure

Refer to Common Chamber in Engine Mechanical.


Accelerator Cable Assembly

Removal Procedure


1. Remove the engine cover.
2. Loosen the adjusting nut on the cable bracket mounting on the common chamber.



3. Remove the accelerator control cable (on the throttle valve end).




4. Remove the accelerator control cable (on the accelerator pedal end).



5. Remove the grommet.

6. Remove the accelerator control cable.




Inspection Procedure

Check the following items, and replace the control cable if any abnormality is found:

- ☐ The control cable should move smoothly.
- ☐ The control cable should not be bent or kinked.
- ☐ The control cable should be free of damage and corrosion.


Installation Procedure

1. Install the accelerator control cable.




2. Install the grommet.


3. Install the accelerator control cable (on the accelerator pedal end).



4. Install the accelerator control cable (on the throttle valve end).



5. Install the adjusting nut.




6. Adjust the accelerator cable at the throttle body.
Refer to *Accelerator Cable Adjustment*.
7. Install the engine cover.

Adjustment Procedure

1. Loosen the adjusting nut and lock nut.
2. Pull outer cable closing fully the throttle valve.


3. Tighten adjusting nut and lock nut temporarily.



4. Loosen adjusting nut by three turns and tighten lock nut. Then, manually operating the throttle valve, make sure that the valve lever returns up to the stopper screw.

IMPORTANT: The valve lever must return up to the stopper screw. If the valve lever does not reach the stopper screw, repeat the procedure again from step 1.


5. If it does not reach the stopper screw, repeat from step 1.




Accelerator Pedal Replacement

Removal Procedure


1. Disconnect the cruise control cable from the accelerator pedal assembly.




2. Disconnect the accelerator pedal control cable from the accelerator pedal assembly.



3. Disconnect the wiring harness from the kick-down switch.




4. Remove the two screws from the accelerator pedal assembly.




5. Remove the accelerator pedal assembly from the bulkhead.

Installation Procedure


1. Install the accelerator pedal assembly on the bulkhead.
2. Install the two screws to the accelerator pedal assembly.




3. Connect the wiring harness to the kick-down switch.



4. Connect the accelerator pedal control cable to the accelerator pedal assembly.




5. Connect the cruise control cable to the accelerator pedal assembly.




Pedal Stroke Adjustment Procedure

1. Loosen the jam nut and rotate the kick-down switch counterclockwise.



TS24039

2. Fully depress the pedal and hold it by hand. Rotate the switch clockwise until the switch clicks.
3. Rotate the switch 1/2 turn further and lock it in this position by tightening the jam nut.



TS24040


4. Step on the accelerator pedal and make sure there is a clicking sound at the full-stroke position.

Fuel Filler Cap

General Description

The fuel filler cap includes a vacuum valve and a pressure valve.

If high vacuum or high pressure occurs in the fuel tank, each valve works to adjust the pressure in order to prevent damage to the tank at the EGR valve.



TS23767

Inspection Procedure


NOTE: Replace the fuel filler cap with the same type of filler cap that was originally installed on the vehicle.

- Check the seal ring in the filler cap for any abnormality and for seal condition.
- Replace the filler cap if any abnormality is found.

Fuel Filter

Removal Procedure


1. Disconnect the negative battery cable.
2. Remove the fuel filler cap.




041RW005

3. Disconnect the fuel line from the fuel filter on the engine side.


4. Disconnect the fuel line from the fuel filter on the fuel tank side.



5. Remove the bolt on the fuel filter holder.




6. Remove the fuel filter.




Inspection Procedure

1. Replace the fuel filter when the following occur:
 - Fuel leaks from the fuel filter body.
 - The fuel filter body is damaged.
 - The fuel filter is clogged with dirt or sediment.
2. If the drain hole is clogged, clean the drain.




Installation Procedure

1. Install the fuel filter in the correct direction.




2. Install the bolt on the fuel filter holder.




3. Connect the fuel line on the engine side.

4. Connect the fuel line on the fuel tank side.



5. Install the fuel filler cap.




6. Connect the negative battery cable.

Fuel Gauge Unit

Removal Procedure

Refer to *Fuel Gauge Unit In Engine Fuel*.



014RW133

Fuel Injectors

Removal Procedure


NOTE: If the fuel injectors are leaking, the engine oil may be contaminated with fuel. Check the oil for signs of contamination and change the oil and the filter if necessary.

NOTE: Use care in removing the fuel injectors in order to prevent damage to the fuel injector electrical connector pins or the fuel injector nozzles. The fuel injector is an electrical component and should not be immersed in any type of cleaner as this may damage the fuel injector.

IMPORTANT: Fuel injectors are serviced as a complete assembly only.


1. Disconnect the negative battery cable.
2. Remove the upper intake manifold. Refer to *Common Chamber in Engine Mechanical*.

3. Remove the fuel rail. Refer to *Fuel Rail*.



014RW106

4. Remove the injector retainer clip.



F06RW017

5. Remove the fuel injector assembly.
6. Remove the O-ring from the fuel injector.
7. Remove the O-ring backup from the fuel injector.


Inspection Procedure

1. Inspect the O-rings for cracks or leaks.
2. Replace worn or damaged O-rings.
3. Lubricate the new O-rings with engine oil before installation.

Installation Procedure


1. Install the O-ring backup on the fuel injector.
2. Install the new O-ring on the fuel injector.

3. Install the fuel injector on the fuel rail.



F06RW017

4. Use new fuel injector retainer clips to retain the fuel injector to the fuel rail.
5. Coat the end of the fuel injector with engine oil.
6. Install the fuel rail. Refer to *Fuel Rail*.



014RW106

7. Install the upper intake manifold. Refer to *Common Chamber in Engine Mechanical*.
8. Install the engine cover.
9. Connect the negative battery cable.

Fuel Pressure Regulator

Removal Procedure

CAUTION: To reduce the risk of fire and personal injury, it is necessary to relieve the fuel system pressure before servicing the fuel system components.


CAUTION: After relieving the system pressure, a small amount of fuel may be released when servicing fuel lines or connections. Reduce the chance of

personal injury by covering the fuel line fittings with a shop towel before disconnecting the fittings. The towels will absorb any fuel that may leak out. When the disconnect is completed, place the towel in an approved container.

NOTE: Compressed air must never be used to test or clean a fuel pressure regulator, as damage to the fuel pressure regulator may result.


NOTE: To prevent damage to the fuel pressure regulator, do not immerse the pressure regulator in solvent.

1. Depressurize the fuel system. Refer to *Fuel Pressure Relief Procedure*.
2. Disconnect the negative battery cable.
3. Remove the fuel pump relay. Refer to *Fuel Pump Relay*.
4. Remove the pressure regulator hose from the fuel pressure regulator.




014RW110

5. Remove the two bolts from the protector that secures the common chamber.



014RW109

6. Remove the fuel pressure regulator attaching screw.




F06RW016

7. Remove the fuel pressure regulator from the fuel rail.

Disassembly Procedure

1. Remove the O-ring from the fuel pressure regulator.
2. Loosen the swivel nut.
3. Remove the fuel return line from the fuel pressure regulator.
4. Remove the O-ring from the fuel return line.
 - The O-ring may be left inside the fuel pressure regulator instead of on the fuel return line.



F06RW016

Assembly Procedure

1. Install a new O-ring on the fuel return line.
2. Install the fuel return line on the fuel pressure regulator.

NOTE: Do not over-tighten the swivel nut on the fuel pressure regulator. The fuel pressure regulator can be damaged and fuel may leak if the swivel nut is over-tightened.


3. Tighten the swivel nut.
4. Install a new O-ring on the fuel pressure regulator.

Installation Procedure

1. Install the fuel pressure regulator attaching screw.


Tighten

- Tighten the fuel pressure regulator attaching screw to 3 N·m (26 lb in.).




F06RW016

2. Install the fuel pressure regulator on the fuel rail.
3. Install the two bolts to the protector that secures the common chamber.



014RW109

4. Install the pressure regulator hose to the fuel pressure regulator.



5. Install the fuel pump relay. Refer to *Fuel Pump Relay*.
6. Connect the negative battery cable.
7. Crank the engine until it starts. Cranking the engine may take longer than usual due to trapped air in the fuel lines.

Fuel Metering System


Fuel Pressure Relief Procedure

CAUTION: To reduce the risk of fire and personal injury, it is necessary to relieve the fuel system pressure before servicing the fuel system components.

CAUTION: After relieving the system pressure, a small amount of fuel may be released when servicing fuel lines or connections. Reduce the chance of personal injury by covering the fuel line fittings with a shop towel before you disconnect the fittings. The towels will absorb any fuel that may leak out. When the disconnect is completed, place the towel in an approved container.

1. Remove the fuel cap.

2. Remove the fuel pump relay from the underhood relay box. Refer to *Fuel Pump Relay*.




3. Start the engine and allow it to stall.
4. Crank the engine for 30 seconds.
5. Disconnect the negative battery cable.

Fuel Pump Assembly

Removal Procedure


Refer to *Fuel Tank In Fuel Pump Relay*.



Fuel Pump Relay


Removal Procedure

1. Remove the fuse and relay box cover from under the hood.
2. Consult the diagram on the cover to determine which is the correct relay.
3. Pull the relay straight up and out of the fuse and relay box.



Installation Procedure

1. Insert the relay into the correct place in the fuse and relay box with the catch slot facing forward.



2. Press down until the catch engages.
 - An audible "click" will be heard.
3. Install the fuse and relay box cover.


Fuel Rail Assembly

Removal Procedure

NOTE:

- Do not attempt to remove the fuel inlet fitting on the fuel rail. It is staked in place. Removing the fuel inlet fitting will result in damage to the fuel rail or the internal O-ring seal.
- Use care when removing the fuel rail assembly in order to prevent damage to the injector electrical connector terminals and the injector spray tips.
- Fittings should be capped and holes plugged during servicing to prevent dirt and other contaminants from entering open lines and passages.


IMPORTANT: An eight-digit identification number is stamped on the side of the fuel rail. Refer to this number when you service the fuel rail or when a replacement part is required.



Before removal, the fuel rail assembly may be cleaned with a spray type engine cleaner. Follow the spray package instructions. Do not immerse the fuel rails in liquid cleaning solvent.

1. Depressurize the fuel system. Refer to Fuel Pressure Relief Procedure in this Section.
2. Disconnect the negative battery cable.
3. Remove the engine cover.
4. Disconnect the accelerator pedal cable from throttle body and cable bracket.
5. Disconnect the connectors from manifold absolute pressure sensor, solenoid valve, electric vacuum sensing valve.
6. Disconnect the vacuum hose on canister VSV and positive crankcase ventilation hose.
7. Remove the common chamber Refer to the common chamber in Engine Mechanical.
 1. Lift up carefully on the fuel injectors. Do not separate the fuel injectors from the fuel rail.


2. If an injector becomes separated from the fuel rail, the injector O-ring seals and the retainer clip must be replaced.
3. Drain residual fuel into an approved container.



8. If removal of the fuel pressure regulator is necessary, refer to *Fuel Pressure Regulator*.
9. If removal of the fuel injectors is necessary, refer to *Fuel Injectors*.

Installation Procedure

1. If the fuel injectors were removed, install them. Refer to *Fuel Injectors*.
2. If the fuel pressure regulator was removed, install it. Refer to *Fuel Pressure Regulator*.
3. Install the common chamber. Refer to common chamber in engine Mechanical.




4. Connect the vacuum hose on Canister VSV and positive crankcase ventilation hose.
5. Connect the connectors to manifold absolute pressure sensor, solenoid valve, electric vacuum sensing valve.
6. Connect the accelerator pedal cable to throttle body and cable bracket.
7. Install the engine cover.
8. Connect the negative battery cable.
9. Crank the engine until it starts. Cranking the engine may take longer than usual due to trapped air in the fuel rail and in the injectors.

Fuel Tank

Removal Procedure

Refer to *Fuel Tank In Fuel Pump Relay*.




Throttle Body (TB)

Removal Procedure


1. Disconnect the negative battery cable.
2. Drain the cooling system. Refer to *Cooling System*.
3. Remove the accelerator cable assembly. Refer to *Accelerator Cable in Engine Speed Control System*.
4. Disconnect the electrical connectors:
 - Throttle position (TP) sensor.
 - Idle air control (IAC) solenoid.

- Intake air temperature (IAT) sensor. Refer to *Intake Air Temperature Sensor*.



035RW023

5. Disconnect the vacuum hose below the air horn.
6. Remove the intake air duct clamp.
7. Disconnect the intake air duct.
8. Disconnect the coolant lines from the throttle body.
9. Remove the bolts from the common chamber.
10. Remove the throttle body from the common chamber.
11. Remove the gasket from the upper intake manifold.



035RW024

12. Remove the IAC. Refer to *Idle Air Control (IAC) Solenoid*.
13. Remove the TP sensor. Refer to *Throttle Position (TP) Sensor*.

Inspection Procedure

NOTE: Do not use solvent of any type when you clean the gasket surfaces on the intake manifold and the throttle body assembly. The gasket surfaces and the throttle body assembly may be damaged as a result.

- If the throttle body gasket needs to be replaced, remove any gasket material that may be stuck to the mating surfaces of the manifold.
- Do not leave any scratches in the aluminum casting.


Installation Procedure

1. Install the TP sensor. Refer to *Throttle Position (TP) Sensor*.
2. Install the IAC. Refer to *Idle Air Control (IAC) Solenoid*.
3. Install the gasket on the common chamber.
4. Install the throttle body on the common chamber.
5. Secure the gasket and the throttle body with the four bolts.

- The vacuum lines must be properly routed under the throttle body before tightening the mounting bolts.

Tighten


- Tighten the throttle body mounting bolts to 24 N·m (17 lb ft.).



035RW024

6. Install the coolant lines.
7. Connect all the vacuum lines.
8. Install the intake air duct.
9. Tighten the intake air duct clamp.
10. Connect all the electrical connectors:
 - Throttle position (TP) sensor.
 - Idle air control (IAC) solenoid.

- Intake air temperature (IAT) sensor. Refer to *Intake Air Temperature Sensor*.




035RW023

11. Install the accelerator cable assembly. Refer to *Accelerator Cable in Engine Speed Control System*.
12. Fill the cooling system. Refer to *Cooling System*.
13. Install the negative battery cable.

Electronic Ignition System


Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the electrical connector at the coil module.
3. Remove the two screws that secure the coil module to the rocker cover.



014RW108

4. Remove the coil module and the spark plug boot from the spark plug.
- Twist the coil module while pulling it straight up.



014RW091

5. Use the spark plug socket in order to remove the spark plug from the engine.

Spark Plug Gap Check

- Check the gap of all spark plugs before installation.
- Use a round wire feeler gauge to ensure an accurate check.
- Plugs installed with the wrong gap can cause poor engine performance and excessive emissions.

Installation Procedure


NOTE: The plug must thread smoothly into the cylinder head and be fully seated. Use a thread chaser if necessary to clean the threads in the cylinder head. Cross-threading or failure to fully seat the spark plug can cause plug overheating, exhaust blow-by gases, or thread damage. Do not overtighten the spark plugs. Over tightening can cause aluminum threads to strip.

1. Install the spark plug in the engine. Use the appropriate spark plug socket.


Tighten

- Tighten the spark plug to 18 N-m (13 lb ft.).

2. Install the coil module and spark plug boot over the spark plug.



3. Secure the coil module to the rocker cover with two screws.



4. Connect the electrical connector at the coil module.
5. Connect the negative battery cable.

Catalytic Converter


Removal and Installation Procedure

Refer to *Engine Exhaust in Engine*.

Air Conditioning Relay

Removal Procedure

1. Remove the fuse and relay box cover from under the hood.
2. Consult the diagram on the cover to determine which is the correct relay.
3. Pull the relay straight up and out of the fuse and relay box.



Installation Procedure

1. Insert the relay into the correct place in the fuse and relay box with the catch slot facing forward.
2. Press down until the catch engages.
 - An audible "click" will be heard.
3. Install the fuse and relay box cover.

EVAP Canister Hoses


Service Information

To view the routing of the EVAP canister hoses, refer to *Vehicle Emission Control Information in Diagnosis*. Use 6148M or equivalent when you replace the EVAP canister hoses.


EVAP Canister

Removal Procedure


1. Disconnect the negative battery cable.
2. Disconnect the two hoses from the EVAP canister.




3. Disconnect the fuel vapor connector and the purge hose from the EVAP canister vent solenoid.



4. Remove the two retaining bolts the EVAP canister to the mounting bracket on the cross member.



5. Remove the retaining bolt on the mounting bracket the slide the canister out of mounting bracket.




Inspection Procedure

1. Inspect the hoses for cracks and leaks.
2. Inspect the canister for a damaged case.


Installation Procedure

1. Slide the canister into mounting bracket the install the mounting bracket bolt.



014RW129


2. Install the retaining bolts the EVAP canister to the mounting bracket on the cross member.



014RW131

3. Connect the fuel vapor connector to the EVAP canister vent solenoid.

4. Connect the two hoses to the EVAP canister.




014RW130

5. Disconnect the negative battery cable.

EVAP Canister Vent Solenoid


Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the connector and hose.



014RW132

3. Slide the out of EVAP canister vent solenoid from mounting bracket.




Inspection Procedure


1. Check for cracks or leaks.
2. Energize the solenoid and try to blow through it. The solenoid should not allow passage of air when energized. (J 35616 Connector Test Kit can be used to easily attach jumper wires from the battery to the solenoid).

Installation Procedure

1. Slide the into EVAP canister vent solenoid from mounting bracket.



2. Connect the connector and hose.




3. Connect the negative battery cable.

Fuel Tank Pressure Sensor

Removal Procedure

1. Remove the fuel pump assembly. Refer to *Fuel Tank In Fuel Pump*.
2. Carefully pry the fuel tank pressure sensor out of the top of the fuel pump assembly.




Inspection Procedure

1. Inspect the vapor pressure sensor for cracks in the housing and corrosion on the electrical terminals.
2. Inspect the rubber grommet for tears and signs of rot.

Installation Procedure

1. Install the rubber grommet on the fuel pump assembly.




014RW133

2. Install the fuel tank vapor pressure sensor on the fuel pump assembly.
 - Insert the sensor nipple firmly into the grommet.
 - Keep twisting and pushing the sensor until the wide portion of the nipple shows on the other side of the grommet.
3. Install the fuel pump assembly on the fuel tank. Refer to *Fuel Tank In Fuel Pump*.

EVAP Canister Purge Solenoid


Removal Procedure

1. Disconnect the electrical connector from the EVAP canister purge solenoid.
2. Disconnect the vacuum hoses from the EVAP canister purge solenoid.



014RW136


3. Remove the EVAP canister purge solenoid retaining bolt from the upper intake manifold.
4. Remove the EVAP canister purge solenoid.



014RW137


Installation Procedure

1. Install the EVAP canister purge solenoid on the upper intake manifold.
2. Install the EVAP canister purge solenoid retaining bolt.
3. Connect the vacuum hoses to the EVAP canister purge solenoid.



014RW137

4. Connect the electrical connector to the EVAP canister purge solenoid.



014RW138

Fuel Tank Vent Valve


Removal and Installation Procedure

Refer to *Fuel Pump*

Linear Exhaust Gas Recirculation (EGR) Valve


Removal Procedure

1. Disconnect the negative battery cable.
2. Disconnect the electrical connector at the EGR valve.



014RW139

3. Remove the bolt and the nut from the upper intake manifold.




014RW098

4. Remove the EGR valve from the upper intake manifold.
5. Remove the gasket from the upper intake manifold.

Installation Procedure


1. Install the gasket on the upper intake manifold.
2. Install the EGR valve on the upper intake manifold.
3. Secure the EGR valve and the gasket with the bolt and the nut.

NOTE: It is possible to install the EGR valve rotated 180° from the correct position. Make sure that the base of the valve is placed so that it aligns with the mounting flange.



014RW098

4. Connect the electrical connector at the EGR valve.




5. Connect the negative battery cable.

Positive Crankcase Ventilation (PCV) Valve

Removal Procedure

1. Remove the vacuum hose at the PCV valve.
 - Slide the clamp back to release the hose.
2. Pull the PCV valve from the rubber grommet in the right valve cover.




Inspection Procedure

1. Shake the valve and listen for the rattle of the needle inside the valve.
2. If the valve does not rattle, replace the valve.

Installation Procedure

1. Push the PCV valve into the rubber grommet in the left valve cover.
2. Install the vacuum hose on the PCV valve and secure the vacuum hose with the clamp.



Wiring and Connectors

Wiring Harness Service

The control module harness electrically connects the control module to the various solenoids, switches and sensors in the vehicle engine compartment and passenger compartment.

Replace wire harnesses with the proper part number replacement.

Because of the low amperage and voltage levels utilized in powertrain control systems, it is essential that all wiring in environmentally exposed areas be repaired with crimp and seal splice sleeves.

The following wire harness repair information is intended as a general guideline only. Refer to *Chassis Electrical* for all wire harness repair procedures.

Connectors and Terminals

Use care when probing a connector and when replacing terminals. It is possible to short between opposite terminals. Damage to components could result. Always use jumper wires between connectors for circuit checking. NEVER probe through Weather-Pack seals. Use an appropriate connector test adapter kit which contains an assortment of flexible connectors used to probe terminals during diagnosis. Use an appropriate fuse remover and test tool for removing a fuse and to adapt the fuse holder to a meter for diagnosis.

Open circuits are often difficult to locate by sight because oxidation or terminal misalignment are hidden by the connectors. Merely wiggling a connector on a sensor, or in the wiring harness, may temporarily correct the open circuit. Intermittent problems may also be caused by oxidized or loose connections.

Be certain of the type of connector terminal before making any connector or terminal repair. Weather-Pack and Com-Pack III terminals look similar, but are serviced differently.

PCM Connectors and Terminals

Removal Procedure

1. Remove the connector terminal retainer.
2. Push the wire connected to the affected terminal through the connector face so that the terminal is exposed.
3. Service the terminal as necessary.


Installation Procedure

1. Bend the tab on the connector to allow the terminal to be pulled into position within the connector.
2. Pull carefully on the wire to install the connector terminal retainer.

Wire Harness Repair: Twisted Shielded Cable


Removal Procedure

1. Remove the outer jacket.
2. Unwrap the aluminum/mylar tape. Do not remove the mylar.




3. Untwist the conductors.

4. Strip the insulation as necessary.




Installation Procedure

1. Splice the wires using splice clips and rosin core solder.
2. Wrap each splice to insulate.
3. Wrap the splice with mylar and with the drain (uninsulated) wire.



4. Tape over the whole bundle to secure.




050

Twisted Leads

Removal Procedure


1. Locate the damaged wire.
2. Remove the insulation as required.



051


Installation Procedure

1. Use splice clips and rosin core solder in order to splice the two wires together.




052

2. Cover the splice with tape in order to insulate it from the other wires.




053

3. Twist the wires as they were before starting this procedure.



4. Tape the wires with electrical tape. Hold in place.



Weather-Pack Connector


Tools Required

J 28742-A Weather-Pack II Terminal Remover

Removal Procedure


A Weather-Pack connector can be identified by a rubber seal at the rear of the connector. This engine room connector protects against moisture and dirt, which could lead from oxidation and deposits on the terminals. This protection is important, because of the low voltage and the low amperage found in the electronic systems.

1. Open the secondary lock hinge on the connector.




2. Use tool J 28742-A or the equivalent to remove the pin and the sleeve terminals. Push on J 28742-A to release.


NOTE: Do not use an ordinary pick or the terminal may be bent or deformed. Unlike standard blade terminals, these terminals cannot be straightened after they have been improperly bent.



3. Cut the wire immediately behind the cable seal.



5. Push the terminal and the connector to engage the locking tangs.




6. Close the secondary locking hinge.

Installation Procedure

Make certain the connectors are properly seated and all of the sealing rings are in place when you reconnect the leads. The secondary lock hinge provides a backup locking feature for the connector. The secondary lock hinge is used for added reliability. This flap should retain the terminals even if the small terminal lock tangs are not positioned properly.

Do not replace the Weather-Pack connections with standard connections. Read the instructions provided with the Weather-Pack connector and terminal packages.

1. Replace the terminal.
2. Slip the new seal onto the wire.
3. Strip 5 mm (0.2") of insulation from the wire.
4. Crimp the terminal over the wire and the seal.



Com-Pack III

General Information

The Com-Pack III terminal looks similar to some Weather-Pack terminals. This terminal is not sealed and is used where resistance to the environment is not required. Use the standard method when repairing a terminal. Do not use the Weather-Pack terminal tool J 28742-A or equivalent. These will damage the terminals.

Metri-Pack

Tools Required


J 35689 Terminal Remover

Removal Procedure

Some connectors use terminals called Metri-Pack Series 150. These may be used at the engine coolant temperature (ECT) sensor.

1. Slide the seal (1) back on the wire.

2. Insert the J 35689 tool or equivalent (3) in order to release the terminal locking tang (2).




3. Push the wire and the terminal out through the connector. If you reuse the terminal, reshape the locking tang.

Installation Procedure

Metri-Pack terminals are also referred to as “pull-to-seat” terminals.

1. In order to install a terminal on a wire, the wire must be inserted through the seal (2) and through the connector (3).
2. The terminal (1) is then crimped onto the wire.



3. Then the terminal is pulled back into the connector to seat it in place.

General Description (PCM and Sensors)

58X Reference PCM Input

The powertrain control module (PCM) uses this signal from the crankshaft position (CKP) sensor to calculate engine RPM and crankshaft position at all engine speeds. The PCM also uses the pulses on this circuit to initiate injector pulses. If the PCM receives no pulses on this circuit, DTC P0337 will set. The engine will not start and run without using the 58X reference signal.

A/C Request Signal


This signal tells the PCM when the A/C mode is selected at the A/C control head. The PCM uses this to adjust the idle speed before turning "ON" the A/C clutch. The A/C compressor will be inoperative if this signal is not available to the PCM.

Refer to *A/C Clutch Circuit Diagnosis* for A/C wiring diagrams and diagnosis for the A/C electrical system.

Crankshaft Position (CKP) Sensor

The crankshaft position (CKP) sensor provides a signal used by the powertrain control module (PCM) to calculate the ignition sequence. The CKP sensor initiates the 58X reference pulses which the PCM uses to calculate RPM and crankshaft position.

Refer to *Electronic Ignition System* for additional information.




Camshaft Position (CMP) Sensor and Signal

The camshaft position (CMP) sensor sends a CMP signal to the PCM. The PCM uses this signal as a "syncpulse" to trigger the injectors in the proper sequence. The PCM

uses the CMP signal to indicate the position of the #1 piston during its power stroke. This allows the PCM to calculate true sequential fuel injection (SFI) mode of operation. If the PCM detects an incorrect CMP signal while the engine is running, DTC P0341 will set. If the CMP signal is lost while the engine is running, the fuel injection system will shift to a calculated sequential fuel injection mode based on the last fuel injection pulse, and the engine will continue to run. As long as the fault is present, the engine can be restarted. It will run in the calculated sequential mode with a 1-in-6 chance of the injector sequence being correct.

Refer to *DTC P0341* for further information.




Engine Coolant Temperature (ECT) Sensor

The engine coolant temperature (ECT) sensor is a thermistor (a resistor which changes value based on temperature) mounted in the engine coolant stream. Low coolant temperature produces a high resistance of 100,000 ohms at -40°C (-40°F). High temperature causes a low resistance of 70 ohms at 130°C (266°F). The PCM supplies a 5-volt signal to the ECT sensor through resistors in the PCM and measures the voltage. The signal voltage will be high when the engine is cold and low when the engine is hot. By measuring the voltage, the PCM calculates the engine coolant temperature. Engine coolant temperature affects most of the systems that the PCM controls.

The Tech 2 displays engine coolant temperature in degrees. After engine start-up, the temperature should rise steadily to about 85°C (185°F). It then stabilizes when the thermostat opens. If the engine has not been run for several hours (overnight), the engine coolant temperature and intake air temperature displays should be close to each other. A hard fault in the engine coolant

sensor circuit will set DTC P0177 or DTC P0118. An intermittent fault will set a DTC P1114 or P1115.



0016

Electrically Erasable Programmable Read Only Memory (EEPROM)

The electrically erasable programmable read only memory (EEPROM) is a permanent memory chip that is physically soldered within the PCM. The EEPROM contains the program and the calibration information that the PCM needs to control powertrain operation.

Unlike the PROM used in past applications, the EEPROM is not replaceable. If the PCM is replaced, the new PCM will need to be programmed. Equipment containing the correct program and calibration for the vehicle is required to program the PCM.


Fuel Control Heated Oxygen Sensors

The fuel control heated oxygen sensors (Bank 1 HO2S 1 and Bank 2 HO2S 1) are mounted in the exhaust stream where they can monitor the oxygen content of the exhaust gas. The oxygen present in the exhaust gas reacts with the sensor to produce a voltage output. This voltage should constantly fluctuate from approximately 100 mV to 900 mV. The heated oxygen sensor voltage can be monitored with a Tech 2. By monitoring the voltage output of the oxygen sensor, the PCM calculates the pulse width command for the injectors to produce the proper combustion chamber mixture.

- Low HO2S voltage is a lean mixture which will result in a rich command to compensate.
- High HO2S voltage is a rich mixture which will result in a lean command to compensate.

An open Bank 1 HO2S 1 signal circuit will set a DTC P0134 and the Tech 2 will display a constant voltage between 400-500 mV. A constant voltage below 300 mV in the sensor circuit (circuit grounded) will set DTC P0131. A constant voltage above 800 mV in the circuit will set DTC P0132. Faults in the Bank 2 HO2S 1 signal circuit will cause DTC 0154 (open circuit), DTC P0151 (grounded circuit), or DTC P0152 (signal voltage high) to set. A fault in the Bank 1 HO2S 1 heater circuit will cause

DTC P0135 to set. A fault in the Bank 2 HO2S 1 heater circuit will cause DTC P0155 to set. The PCM can also detect HO2S response problems. If the response time of an HO2S is determined to be too slow, the PCM will store a DTC that indicates degraded HO2S performance.



0012



Catalyst Monitor Heated Oxygen Sensors

Three-way catalytic converters are used to control emissions of hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx). The catalyst within the converters promotes a chemical reaction. This reaction oxidizes the HC and CO present in the exhaust gas and converts them into harmless water vapor and carbon dioxide. The catalyst also reduces NOx by converting it to nitrogen. The PCM can monitor this process using the Bank 1 HO2S 2 and the Bank 2 HO2S 2 heated oxygen sensors. The Bank 1 HO2S 1 and the Bank 2 HO2S 1 sensors produce an output signal which indicates the amount of oxygen present in the exhaust gas entering the three-way catalytic converter. The Bank 1 HO2S 2 and the Bank 2 HO2S 2 sensors produce an output signal which indicates the oxygen storage capacity of the catalyst. This indicates the catalyst's ability to efficiently convert exhaust gases. If the catalyst is operating efficiently, the Bank 1 HO2S 1 and the Bank 2 HO2S 1 signals will be more active than the signals produced by the Bank 1 HO2S 2 and the Bank 2 HO2S 2 sensors.

The catalyst monitor sensors operate the same as the fuel control sensors. The Bank 1 HO2S 2 and the Bank 2 HO2S 2 sensors' main function is catalyst monitoring, but they also have a limited role in fuel control. If a sensor output indicates a voltage either above or below the 450 mV bias voltage for an extended period of time, the PCM will make a slight adjustment to fuel trim to ensure that fuel delivery is correct for catalyst monitoring.

A problem with the Bank 1 HO2S 2 signal circuit will set DTC P0137, P0138, or P0140, depending on the specific condition. A problem with the Bank 2 HO2S 2 signal circuit will set DTC P0157, P0158, or P0160, depending on the specific condition. A fault in the heated oxygen sensor heater element or its ignition feed or ground will

result in lower sensor response. This may cause incorrect catalyst monitor diagnostic results.



Legend

- (1) Bank 1 Sensor 1 (Fuel Control)
- (2) Catalytic Converter
- (3) Bank 1 Sensor 2 (Catalyst Monitor)
- (4) Bank 2 Sensor 1 (Fuel Control)
- (5) Bank 2 Sensor 2 (Catalyst Monitor)

Intake Air Temperature (IAT) Sensor

The intake air temperature (IAT) sensor is a thermistor which changes its resistance based on the temperature of air entering the engine. Low temperature produces a high resistance of 100,000 ohms at -40°C (-40°F). High temperature causes low resistance of 70 ohms at 130°C (266°F). The PCM supplies a 5-volt signal to the sensor through a resistor in the PCM and monitors the signal voltage. The voltage will be high when the incoming air is cold. The voltage will be low when the incoming air is hot. By measuring the voltage, the PCM calculates the

incoming air temperature. The IAT sensor signal is used to adjust spark timing according to the incoming air density.

The Tech 2 displays the temperature of the air entering the engine. The temperature should read close to the ambient air temperature when the engine is cold and rise as underhood temperature increases. If the engine has not been run for several hours (overnight), the IAT sensor temperature and engine coolant temperature should read close to each other. A fault in the IAT sensor circuit will set DTC P0112 or DTC P0113.

Knock Sensor

Insufficient gasoline octane levels may cause detonation in some engines. Detonation is an uncontrolled explosion (burn) in the combustion chamber. This uncontrolled explosion results from a flame front opposite that of the normal flame front produced by the spark plug. The rattling sound normally associated with detonation is the result of two or more opposing pressures (flame fronts) colliding within the combustion chamber. Light detonation is sometimes considered normal, but heavy detonation could result in engine damage.

A knock sensor system is used to control detonation. This system is designed to retard spark timing up to 20 degrees to reduce detonation in the engine. This allows the engine to use maximum spark advance to improve driveability and fuel economy.

The knock sensor system has two major components:


- The knock sensor (KS) module.
- The knock sensor.

The knock sensor, mounted in the engine block near the cylinders, detects abnormal vibration in the engine. The sensor produces an AC output signal of about 10 millivolts. The signal amplitude and frequency are dependent on the amount of knock being experienced. The signal voltage increases with the severity of the knock. This signal voltage is input to the PCM. The PCM then retards the ignition control (IC) spark timing based on the KS signal being received.

The PCM determines whether knock is occurring by comparing the signal level on the KS circuit with the voltage level on the noise channel. The noise channel allows the PCM to reject any false knock signal by indicating the amount of normal engine mechanical noise present. Normal engine noise varies depending on the engine speed and load. If the voltage level on the KS noise channel circuit is below the range considered normal, DTC P0327 will set, indicating a fault in the KS circuit or the knock sensor. If the PCM determines that an abnormal minimum or maximum noise level is being experienced, DTC P0325 will set.

The PCM contains a knock sensor (KS) module. The KS module contains the circuitry which allows the PCM to utilize the KS signal and diagnose the KS sensor and the KS circuitry. If the KS module is missing or faulty, a continuous knock condition will be indicated, and the PCM will set DTC P0325.

Although it is a plug-in device, the KS module is not replaceable. If the KS module is faulty, the entire PCM must be replaced.



0009


Linear Exhaust Gas Recirculation (EGR) Control

The PCM monitors the exhaust gas recirculation (EGR) actual position and adjusts the pintle position accordingly. The PCM uses information from the following sensors to control the pintle position:

- Engine coolant temperature (ECT) sensor.
- Throttle position (TP) sensor.
- Mass air flow (MAF) sensor.

Mass Air Flow (MAF) Sensor

The mass air flow (MAF) sensor measures the difference between the volume and the quantity of air that enters the engine. "Volume" means the size of the space to be filled. "Quantity" means the number of air molecules that will fit into the space. This information is important to the PCM because heavier, denser air will hold more fuel than lighter, thinner air. The PCM adjusts the air/fuel ratio as needed depending on the MAF value. The Tech 2 reads the MAF value and displays it in terms of grams per second (gm/s). At idle, the Tech 2 should read between 4-7 gm/s on a fully warmed up engine. Values should change quickly on acceleration. Values should remain stable at any given RPM. A failure in the MAF sensor or circuit will set DTC P0101, DTC P0102, or DTC P0103.



0007


Manifold Absolute Pressure (MAP) Sensor

The manifold absolute pressure (MAP) sensor responds to changes in intake manifold pressure (vacuum). The MAP sensor signal voltage to the PCM varies from below 2 volts at idle (high vacuum) to above 4 volts with the ignition ON, engine not running or at wide-open throttle (low vacuum).

The MAP sensor is used to determine the following:

- Manifold pressure changes while the linear EGR flow test diagnostic is being run. Refer to *DTC P0401*.
- Engine vacuum level for other diagnostics.
- Barometric pressure (BARO).

If the PCM detects a voltage that is lower than the possible range of the MAP sensor, DTC P0107 will be set. A signal voltage higher than the possible range of the sensor will set DTC P0108. An intermittent low or high voltage will set DTC P1107 or DTC P1106, respectively. The PCM can detect a shifted MAP sensor. The PCM compares the MAP sensor signal to a calculated MAP based on throttle position and various engine load factors. If the PCM detects a MAP signal that varies excessively above or below the calculated value, DTC P0106 will set.



Powertrain Control Module (PCM)

The powertrain control module (PCM) is located in the passenger compartment below the center console. The PCM controls the following:

- Fuel metering system.
- Transmission shifting (automatic transmission only).
- Ignition timing.
- On-board diagnostics for powertrain functions.


The PCM constantly observes the information from various sensors. The PCM controls the systems that affect vehicle performance. The PCM performs the diagnostic function of the system. It can recognize operational problems, alert the driver through the MIL (Service Engine Soon lamp), and store diagnostic trouble codes (DTCs). DTCs identify the problem areas to aid the technician in making repairs.

- IPCM-6KT for automatic transmission-equipped vehicles.

PCM Function

The PCM supplies either 5 or 12 volts to power various sensors or switches. The power is supplied through resistances in the PCM which are so high in value that a test light will not light when connected to the circuit. In some cases, even an ordinary shop voltmeter will not give an accurate reading because its resistance is too low. Therefore, a digital voltmeter with at least 10 megohms input impedance is required to ensure accurate voltage readings. Tool J 39200 meets this requirement. The PCM controls output circuits such as the injectors, IAC, cooling fan relays, etc., by controlling the ground or the power feed circuit through transistors or through either of the following two devices:

- Output Driver Module (ODM)
- Quad Driver Module (QDM)



PCM Components

The PCM is designed to maintain exhaust emission levels to government mandated standards while providing excellent driveability and fuel efficiency. The PCM monitors numerous engine and vehicle functions via electronic sensors such as the throttle position (TP) sensor, heated oxygen sensor (HO2S), and vehicle speed sensor (VSS). The PCM also controls certain engine operations through the following:

- Fuel injector control
- Ignition control module
- Knock sensor
- Automatic transmission shift functions
- Cruise control
- Evaporative emission (EVAP) purge
- A/C clutch control

PCM Voltage Description

The PCM supplies a buffered voltage to various switches and sensors. It can do this because resistance in the PCM is so high in value that a test light may not illuminate when connected to the circuit. An ordinary shop voltmeter may not give an accurate reading because the voltmeter input impedance is too low. Use a 10-megohm input impedance digital voltmeter (such as J 39200) to assure accurate voltage readings.

The input/output devices in the PCM include analog-to-digital converters, signal buffers, counters, and special drivers. The PCM controls most components with electronic switches which complete a ground circuit when turned "ON." These switches are arranged in groups of 4 and 7, called either a surface-mounted quad driver module (QDM), which can independently control up to 4 output terminals, or QDMs which can independently control up to 7 outputs. Not all outputs are always used.

PCM Input/Outputs

Inputs – Operating Conditions Read

- Air Conditioning "ON" or "OFF"

- Engine Coolant Temperature
- Crankshaft Position
- Exhaust Oxygen Content
- Electronic Ignition
- Manifold Absolute Pressure
- Battery Voltage
- Throttle Position
- Vehicle Speed
- Fuel Pump Voltage
- Power Steering Pressure
- Intake Air Temperature
- Mass Air Flow
- Engine Knock
- Camshaft Position

Outputs – Systems Controlled

- EVAP Canister Purge
- Exhaust Gas Recirculation (EGR)
- Ignition Control
- Fuel Control
- Idle Air Control
- Electric Fuel Pump
- Air Conditioning
- Diagnostics
 - Malfunction Indicator Lamp
 - Data Link Connector (DLC)
 - Data Output
- Transmission Control Module
- Alternator Gain Control

PCM Service Precautions

The PCM is designed to withstand normal current draws associated with vehicle operation. Avoid overloading any circuit. When testing for opens and shorts, do not ground or apply voltage to any of the PCM's circuits unless instructed to do so. These circuits should only be tested using digital voltmeter J 39200. The PCM should remain connected to the PCM or to a recommended breakout box.


Reprogramming The PCM

Reprogramming of the PCM without removing it from the vehicle. This provides a flexible and cost-effective method of making changes in software calibrations. Refer to the latest Techline information on reprogramming or flashing procedures.

Throttle Position (TP) Sensor

The throttle position (TP) sensor is a potentiometer connected to the throttle shaft on the throttle body. The PCM monitors the voltage on the signal line and calculates throttle position. As the throttle valve angle is changed (accelerator pedal moved), the TP sensor signal also changes. At a closed throttle position, the output of the TP sensor is low. As the throttle valve opens, the output increases so that at wide open throttle (WOT), the output voltage should be above 4 volts.

The PCM calculates fuel delivery based on throttle valve angle (driver demand). A broken or loose TP sensor may cause intermittent bursts of fuel from an injector and unstable idle because the PCM thinks the throttle is moving. A hard failure in the TP sensor 5-volt reference or signal circuits will set either a DTC P0122 or DTC P0123. A hard failure with the TP sensor ground circuit may set DTC P0123 and DTC P0112. Once a DTC is set, the PCM will use an artificial default value based on engine RPM and mass air flow for the throttle position, and some vehicle performance will return. A high idle may result when either DTC P0122 or DTC P0123 is set. The PCM can detect intermittent TP sensor faults. DTC P1121 or DTC P1122 will set if an intermittent high or low circuit failure is being detected. The PCM can also detect a shifted TP sensor. The PCM monitors throttle position and compares the actual TP sensor reading to a predicted TP value calculated from engine speed. If the PCM detects an out-of-range condition, DTC P0121 will be set.



Transmission Fluid Temperature (TFT) Sensor

The transmission fluid temperature sensor is a thermistor which changes its resistance based on the temperature of the transmission fluid. For a complete description of the TFT sensor, refer to *4L30-E Automatic Transmission Diagnosis*.

A failure in the TFT sensor or associated wiring will cause DTC P0712 or DTC P0713 to set. In this case, engine coolant temperature will be substituted for the TFT sensor value and the transmission will operate normally.

Transmission Range Switch


IMPORTANT: The vehicle should not be driven with the transmission range switch disconnected; idle quality will be affected.

The four inputs from the transmission range switch indicate to the PCM which position is selected by the transmission selector lever. This information is used for ignition timing, EVAP canister purge, EGR and IAC valve operation.

For more information on the transmission on the transmission range switch, refer to *4L30-E Automatic Transmission*.

Vehicle Speed Sensor (VSS)

The PCM determines the speed of the vehicle by converting a pulsing voltage signal from the vehicle speed sensor (VSS) into miles per hour. The PCM uses this signal to operate the cruise control, speedometer, and the TCC and shift solenoids in the transmission. For more information on the TCC and shift solenoids, refer to *4L30-E Automatic Transmission*.



Use of Circuit Testing Tools

Do not use a test light to diagnose the powertrain electrical systems unless specifically instructed by the diagnostic procedures. Use Connector Test Adapter Kit J 35616 whenever diagnostic procedures call for probing connectors.

Aftermarket Electrical and Vacuum Equipment

Aftermarket (add-on) electrical and vacuum equipment is defined as any equipment which connects to the vehicle's electrical or vacuum systems that is installed on a vehicle after it leaves the factory. No allowances have been made in the vehicle design for this type of equipment.

NOTE: No add-on vacuum equipment should be added to this vehicle.


NOTE: Add-on electrical equipment must only be connected to the vehicle's electrical system at the battery (power and ground).

Add-on electrical equipment, even when installed to these guidelines, may still cause the powertrain system to malfunction. This may also include equipment not connected to the vehicle electrical system such as portable telephones and radios. Therefore, the first step in diagnosing any powertrain problem is to eliminate all aftermarket electrical equipment from the vehicle. After

this is done, if the problem still exists, it may be diagnosed in the normal manner.

Electrostatic Discharge Damage

Electronic components used in the PCM are often designed to carry very low voltage. Electronic components are susceptible to damage caused by electrostatic discharge. Less than 100 volts of static electricity can cause damage to some electronic components. By comparison, it takes as much as 4000 volts for a person to feel even the zap of a static discharge.



There are several ways for a person to become statically charged. The most common methods of charging are by friction and induction.

- An example of charging by friction is a person sliding across a vehicle seat.
- Charge by induction occurs when a person with well insulated shoes stands near a highly charged object and momentarily touches ground. Charges of the same polarity are drained off leaving the person highly charged with the opposite polarity. Static charges can cause damage, therefore it is important to use care when handling and testing electronic components.

NOTE: To prevent possible electrostatic discharge damage, follow these guidelines:

- Do not touch the PCM connector pins or soldered components on the PCM circuit board.
- Do not touch the knock sensor module component leads.
- Do not open the replacement part package until the part is ready to be installed.
- Before removing the part from the package, ground the package to a known good ground on the vehicle.
- If the part has been handled while sliding across the seat, while sitting down from a standing position, or while walking a distance, touch a known good ground before installing the part.


Upshift Lamp

Refer to *Manual Transmission*.

General Description (Air Induction)**Air Induction System**

The air induction system filters contaminants from the outside air, and directs the progress of the air as it is drawn into the engine. A remote-mounted air cleaner prevents dirt and debris in the air from entering the engine. The air duct assembly routes filtered air to the throttle body. Air enters the engine by the following steps:

1. Through the throttle body.
2. Into the common chamber.
3. Through the cylinder head intake ports.
4. Into the cylinders.

**General Description (Fuel Metering)****Acceleration Mode**

The PCM provides extra fuel when it detects a rapid increase in the throttle position and the air flow.

Accelerator Controls

The accelerator control system is a cable-type system with specific linkage adjustments.

Refer to *Cable Adjustment*.

Battery Voltage Correction Mode

When battery voltage is low, the PCM will compensate for the weak spark by increasing the following:

- The amount of fuel delivered.

- The idle RPM.

- Ignition dwell time.

CMP Signal

The PCM uses this signal to determine the position of the number 1 piston during its power stroke, allowing the PCM to calculate true sequential multiport fuel injection (SFI). Loss of this signal will set a DTC P0341. If the CMP signal is lost while the engine is running, the fuel injection system will shift to a calculated sequential fuel injection based on the last fuel injection pulse, and the engine will continue to run. The engine can be restarted and will run in the calculated sequential mode as long as the fault is present, with a 1-in-6 chance of being correct.

Clear Flood Mode

Clear a flooded engine by pushing the accelerator pedal down all the way. The PCM then de-energizes the fuel injectors. The PCM holds the fuel injectors de-energized as long as the throttle remains above 80% and the engine speed is below 800 RPM. If the throttle position becomes less than 80%, the PCM again begins to pulse the injectors "ON" and "OFF," allowing fuel into the cylinders.

Deceleration Mode

The PCM reduces the amount of fuel injected when it detects a decrease in the throttle position and the air flow. When deceleration is very fast, the PCM may cut off fuel completely for short periods.

Engine Speed/Vehicle Speed/Fuel Disable Mode

The PCM monitors engine speed. It turns off the fuel injectors when the engine speed increases above 6400 RPM. The fuel injectors are turned back on when engine speed decreases below 6150 RPM.

Fuel Cutoff Mode


No fuel is delivered by the fuel injectors when the ignition is "OFF." This prevents engine run-on. In addition, the PCM suspends fuel delivery if no reference pulses are detected (engine not running) to prevent engine flooding.

Fuel Injector

The sequential multiport fuel injection (SFI) fuel injector is a solenoid-operated device controlled by the PCM. The PCM energizes the solenoid, which opens a valve to allow fuel delivery.

The fuel is injected under pressure in a conical spray pattern at the opening of the intake valve. Excess fuel not used by the injectors passes through the fuel pressure regulator before being returned to the fuel tank.

A fuel injector which is stuck partly open will cause a loss of fuel pressure after engine shut down, causing long crank times.



0003

Fuel Metering System Components

The fuel metering system is made up of the following parts:

- ☐ The fuel injectors.
- ☐ The throttle body.
- ☐ The fuel rail.
- ☐ The fuel pressure regulator.
- ☐ The PCM.
- ☐ The crankshaft position (CKP) sensor.
- ☐ The camshaft position (CMP) sensor.
- ☐ The idle air control (IAC) valve.
- ☐ The fuel pump.
- ☐ The fuel pump relay.

Basic System Operation

The fuel metering system starts with the fuel in the fuel tank. An electric fuel pump, located in the fuel tank, pumps fuel to the fuel rail through an in-line fuel filter. The pump is designed to provide fuel at a pressure above the pressure needed by the injectors. A fuel pressure regulator in the fuel rail keeps fuel available to the fuel injectors at a constant pressure. A return line delivers unused fuel back to the fuel tank. Refer to *Section 6C* for further information on the fuel tank, line filter, and fuel pipes.

Fuel Metering System Purpose

The basic function of the air/fuel metering system is to control the air/fuel delivery to the engine. Fuel is delivered to the engine by individual fuel injectors mounted in the intake manifold near each intake valve.


The main control sensor is the heated oxygen sensor (HO2S) located in the exhaust system. The HO2S tells the PCM how much oxygen is in the exhaust gas. The PCM changes the air/fuel ratio to the engine by controlling the amount of time that fuel injector is "ON." The best mixture to minimize exhaust emissions is 14.7 parts of air

to 1 part of gasoline by weight, which allows the catalytic converter to operate most efficiently. Because of the constant measuring and adjusting of the air/fuel ratio, the fuel injection system is called a "closed loop" system. The PCM monitors signals from several sensors in order to determine the fuel needs of the engine. Fuel is delivered under one of several conditions called "modes." All modes are controlled by the PCM.

Fuel Pressure Regulator

The fuel pressure regulator is a diaphragm-operated relief valve mounted on the fuel rail with fuel pump pressure on one side and manifold pressure on the other side. The fuel pressure regulator maintains the fuel pressure available to the injector at three times barometric pressure adjusted for engine load. It may be serviced separate.

If the pressure is too low, poor performance and a DTC P0131, DTC P0151, DTC P0171 or DTC P1171 will be the result. If the pressure is too high, excessive odor and/or a DTC P0132, DTC P0152, DTC P0172 or DTC P0175 will be the result. Refer to *Fuel System Diagnosis* for information on diagnosing fuel pressure conditions.



0011

Fuel Pump Electrical Circuit


When the key is first turned "ON," the PCM energizes the fuel pump relay for two seconds to build up the fuel pressure quickly. If the engine is not started within two seconds, the PCM shuts the fuel pump off and waits until the engine is cranked. When the engine is cranked and the 58 X crankshaft position signal has been detected by the PCM, the PCM supplies 12 volts to the fuel pump relay to energize the electric in-tank fuel pump.

An inoperative fuel pump will cause a "no-start" condition. A fuel pump which does not provide enough pressure will result in poor performance.

Fuel Rail

The fuel rail is mounted to the top of the engine and distributes fuel to the individual injectors. Fuel is delivered to the fuel inlet tube of the fuel rail by the fuel lines. The fuel goes through the fuel rail to the fuel

pressure regulator. The fuel pressure regulator maintains a constant fuel pressure at the injectors. Remaining fuel is then returned to the fuel tank.




Idle Air Control (IAC) Valve

The purpose of the idle air control (IAC) valve is to control engine idle speed, while preventing stalls due to changes in engine load. The IAC valve, mounted in the throttle body, controls bypass air around the throttle plate. By moving the conical valve (pintle) in (to decrease air flow) or out (to increase air flow), a controlled amount of air can move around the throttle plate. If the RPM is too low, the PCM will retract the IAC pintle, resulting in more air moving past the throttle plate to increase the RPM. If the RPM is too high, the PCM will extend the IAC pintle, allowing less air to move past the throttle plate, decreasing the RPM.

The IAC pintle valve moves in small steps called counts. During idle, the proper position of the IAC pintle is calculated by the PCM based on battery voltage, coolant temperature, engine load, and engine RPM. If the RPM drops below a specified value, and the throttle plate is closed, the PCM senses a near-stall condition. The PCM will then calculate a new IAC pintle valve position to prevent stalls.

If the IAC valve is disconnected and reconnected with the engine running, the idle RPM will be wrong. In this case, the IAC must be reset. The IAC resets when the key is cycled "ON" then "OFF." When servicing the IAC, it should only be disconnected or connected with the ignition "OFF."

The position of the IAC pintle valve affects engine start-up and the idle characteristics of the vehicle. If the IAC pintle is fully open, too much air will be allowed into the manifold. This results in high idle speed, along with possible hard starting and a lean air/fuel ratio. DTC P0507 or DTC P1509 may set. If the IAC pintle is stuck closed, too little air will be allowed in the manifold. This results in a low idle speed, along with possible hard starting and a rich air/fuel ratio. DTC P0506 or DTC P1508 may set. If the IAC pintle is stuck part-way open, the idle may be high or low and will not respond to changes in the engine load.



Run Mode

The run mode has the following two conditions:

- Open loop
- Closed loop

When the engine is first started the system is in "open loop" operation. In "open loop," the PCM ignores the signal from the heated oxygen sensor (HO2S). It calculates the air/fuel ratio based on inputs from the TP, ECT, and MAF sensors.

The system remains in "open loop" until the following conditions are met:

- The HO2S has a varying voltage output showing that it is hot enough to operate properly (this depends on temperature).
- The ECT has reached a specified temperature.
- A specific amount of time has elapsed since starting the engine.
- Engine speed has been greater than a specified RPM since start-up.

The specific values for the above conditions vary with different engines and are stored in the programmable read only memory (PROM). When these conditions are met, the system enters "closed loop" operation. In "closed loop," the PCM calculates the air/fuel ratio (injector on-time) based on the signal from the HO2S. This allows the air/fuel ratio to stay very close to 14.7:1.

Starting Mode


When the ignition is first turned "ON," the PCM energizes the fuel pump relay for two seconds to allow the fuel pump to build up pressure. The PCM then checks the engine coolant temperature (ECT) sensor and the throttle position (TP) sensor to determine the proper air/fuel ratio for starting.

The PCM controls the amount of fuel delivered in the starting mode by adjusting how long the fuel injectors are energized by pulsing the injectors for very short times.

Throttle Body Unit

The throttle body has a throttle plate to control the amount of air delivered to the engine. The TP sensor and IAC valve are also mounted on the throttle body. Vacuum ports located behind the throttle plate provide the vacuum signals needed by various components.

Engine coolant is directed through a coolant cavity in the throttle body to warm the throttle valve and to prevent icing.




0019

General Description (Electronic Ignition System)

Camshaft Position (CMP) Sensor

The camshaft position (CMP) sensor is located on the timing cover near the camshaft sprocket. As the camshaft sprocket turns, a magnet in the sprocket activates the Hall-effect switch in the CMP sensor. When the Hall-effect switch is activated, it grounds the signal line to the PCM, pulling the camshaft position sensor signal circuit's applied voltage low. This is a CMP signal. The CMP signal is created as piston #1 is approximately 25° after top dead center on the power stroke. If the correct CMP signal is not received by the PCM, DTC P0341 will be set.



0014


Crankshaft Position (CKP) Sensor

The crankshaft position (CKP) sensor provides a signal used by the powertrain control module (PCM) to calculate the ignition sequence. The sensor initiates the 58X reference pulses which the PCM uses to calculate RPM and crankshaft position. Refer to *Electronic Ignition System* for additional information.

Electronic Ignition

The electronic ignition system controls fuel combustion by providing a spark to ignite the compressed air/fuel mixture at the correct time. To provide optimum engine performance, fuel economy, and control of exhaust emissions, the PCM controls the spark advance of the ignition system. Electronic ignition has the following advantages over a mechanical distributor system:


- No moving parts.
- Less maintenance.
- Remote mounting capability.
- No mechanical load on the engine.
- More coil cooldown time between firing events.
- Elimination of mechanical timing adjustments.
- Increased available ignition coil saturation time.



0013

Ignition Coils

A separate coil-at-plug module is located at each spark plug. The coil-at-plug module is attached to the engine with two screws. It is installed directly to the spark plug by an electrical contact inside a rubber boot. A three-way connector provides 12-volt primary supply from the 15-amp ignition fuse, a ground-switching trigger line from the PCM, and a ground.




0001

Ignition Control

The ignition control (IC) spark timing is the PCM's method of controlling the spark advance and the ignition dwell. The IC spark advance and the ignition dwell are calculated by the PCM using the following inputs:


- Engine speed.
- Crankshaft position (58X reference).
- Camshaft position (CMP) sensor.

- Engine coolant temperature (ECT) sensor.
- Throttle position (TP) sensor.
- Knock signal (knock sensor).
- Park/Neutral position (PRNDL input).
- Vehicle speed (vehicle speed sensor).
- PCM and ignition system supply voltage.
- The crankshaft positron (CKP) sensor sends the PCM a 58X signal related to the exact position of the crankshaft.




TS22909

- The camshaft position (CMP) sensor sends a signal related to the position of the camshaft.
- The knock sensor tells the PCM if there is any problem with pre-ignition or detonation. This information allows the PCM to retard timing, if necessary.




TS24037

Based on these sensor signals and engine load information, the PCM sends 5V to each ignition coil.



The PCM applies 5V signal voltage to the ignition coil requiring ignition. This signal sets on the power transistor of the ignition coil to establish a grounding circuit for the primary coil, applying battery voltage to the primary coil. At the ignition timing, the PCM stops sending the 5V signal voltage. Under this condition the power transistor of the ignition coil is set off to cut the battery voltage to the primary coil, thereby causing a magnetic field generated in the primary coil to collapse. On this moment a line of magnetic force flows to the secondary coil, and when this magnetic line crosses the coil, high voltage induced by the secondary ignition circuit to flow through the spark plug to the ground.



Ignition Control PCM Output

The PCM provides a zero volt (actually about 100 mV to 200 mV) or a 5-volt output signal to the ignition control (IC) module. Each spark plug has its own primary and secondary coil module ("coil-at-plug") located at the spark plug itself. When the ignition coil receives the 5-volt signal from the PCM, it provides a ground path for the B+ supply to the primary side of the coil-at-plug module. This energizes the primary coil and creates a magnetic field in

the coil-at-plug module. When the PCM shuts off the 5-volt signal to the ignition control module, the ground path for the primary coil is broken. The magnetic field collapses and induces a high voltage secondary impulse which fires the spark plug and ignites the air/fuel mixture. The circuit between the PCM and the ignition coil is monitored for open circuits, shorts to voltage, and shorts to ground. If the PCM detects one of these events, it will set one of the following DTCs:

- P0351: Ignition coil Fault on Cylinder #1
- P0352: Ignition coil Fault on Cylinder #2
- P0353: Ignition coil Fault on Cylinder #3
- P0354: Ignition coil Fault on Cylinder #4
- P0355: Ignition coil Fault on Cylinder #5
- P0356: Ignition coil Fault on Cylinder #6

Knock Sensor (KS) PCM Input

The knock sensor (KS) system is comprised of a knock sensor and the PCM. The PCM monitors the KS signals to determine when engine detonation occurs. When a knock sensor detects detonation, the PCM retards the spark timing to reduce detonation. Timing may also be retarded because of excessive mechanical engine or transmission noise.

Powertrain Control Module (PCM)

The PCM is responsible for maintaining proper spark and fuel injection timing for all driving conditions. To provide optimum driveability and emissions, the PCM monitors the input signals from the following components in order to calculate spark timing:

- Engine coolant temperature (ECT) sensor.
- Intake air temperature (IAT) sensor.
- Mass air flow (MAF) sensor.
- PRNDL input from transmission range switch.
- Throttle position (TP) sensor.
- Vehicle speed sensor (VSS) .
- Crankshaft position (CKP) sensor.

Spark Plug

Although worn or dirty spark plugs may give satisfactory operation at idling speed, they frequently fail at higher engine speeds. Faulty spark plugs may cause poor fuel economy, power loss, loss of speed, hard starting and generally poor engine performance. Follow the scheduled maintenance service recommendations to ensure satisfactory spark plug performance. Refer to *Maintenance and Lubrication*.


Normal spark plug operation will result in brown to grayish-tan deposits appearing on the insulator portion of the spark plug. A small amount of red-brown, yellow, and white powdery material may also be present on the insulator tip around the center electrode. These deposits are normal combustion by-products of fuels and lubricating oils with additives. Some electrode wear will also occur. Engines which are not running properly are often referred to as "misfiring." This means the ignition spark is not igniting the air/fuel mixture at the proper time. While other ignition and fuel system causes must also be

considered, possible causes include ignition system conditions which allow the spark voltage to reach ground in some other manner than by jumping across the air gap at the tip of the spark plug, leaving the air/fuel mixture unburned. Refer to *DTC P0300*. Misfiring may also occur when the tip of the spark plug becomes overheated and ignites the mixture before the spark jumps. This is referred to as "pre-ignition."


Spark plugs may also misfire due to fouling, excessive gap, or a cracked or broken insulator. If misfiring occurs before the recommended replacement interval, locate and correct the cause.

Carbon fouling of the spark plug is indicated by dry, black carbon (soot) deposits on the portion of the spark plug in the cylinder. Excessive idling and slow speeds under light engine loads can keep the spark plug temperatures so low that these deposits are not burned off. Very rich fuel mixtures or poor ignition system output may also be the cause. Refer to *DTC P0172*.

Oil fouling of the spark plug is indicated by wet oily deposits on the portion of the spark plug in the cylinder, usually with little electrode wear. This may be caused by oil during break-in of new or newly overhauled engines. Deposit fouling of the spark plug occurs when the normal red-brown, yellow or white deposits of combustion by products become sufficient to cause misfiring. In some cases, these deposits may melt and form a shiny glaze on the insulator around the center electrode. If the fouling is found in only one or two cylinders, valve stem clearances or intake valve seals may be allowing excess lubricating oil to enter the cylinder, particularly if the deposits are heavier on the side of the spark plug facing the intake valve.




Excessive gap means that the air space between the center and the side electrodes at the bottom of the spark plug is too wide for consistent firing. This may be due to improper gap adjustment or to excessive wear of the electrode during use. A check of the gap size and comparison to the gap specified for the vehicle in *Maintenance and Lubrication* will tell if the gap is too wide. A spark plug gap that is too small may cause an unstable idle condition. Excessive gap wear can be an indication of continuous operation at high speeds or with engine loads, causing the spark to run too hot. Another possible cause is an excessively lean fuel mixture.



Low or high spark plug installation torque or improper seating can result in the spark plug running too hot and can cause excessive center electrode wear. The plug and the cylinder head seats must be in good contact for proper heat transfer and spark plug cooling. Dirty or damaged threads in the head or on the spark plug can keep it from seating even though the proper torque is applied. Once spark plugs are properly seated, tighten them to the torque shown in the Specifications Table. Low torque may result in poor contact of the seats due to a loose spark plug. Overtightening may cause the spark plug shell to be stretched and will result in poor contact between the seats. In extreme cases, exhaust blow-by and damage beyond simple gap wear may occur.


Cracked or broken insulators may be the result of improper installation, damage during spark plug re-gapping, or heat shock to the insulator material. Upper insulators can be broken when a poorly fitting tool is used during installation or removal, when the spark plug is hit from the outside, or is dropped on a hard surface. Cracks in the upper insulator may be inside the shell and not

visible. Also, the breakage may not cause problems until oil or moisture penetrates the crack later.



TSZ3994

A broken or cracked lower insulator tip (around the center electrode) may result from damage during re-gapping or from "heat shock" (spark plug suddenly operating too hot).



TSZ3993

- Damage during re-gapping can happen if the gapping tool is pushed against the center electrode or the insulator around it, causing the insulator to crack. When re-gapping a spark plug, make the adjustment by bending only the ground side terminal, keeping the tool clear of other parts.
- "Heat shock" breakage in the lower insulator tip generally occurs during several engine operating conditions (high speeds or heavy loading) and may be caused by over-advanced timing or low grade fuels. Heat shock refers to a rapid increase in the tip temperature that causes the insulator material to crack.

Spark plugs with less than the recommended amount of service can sometimes be cleaned and re-gapped, then returned to service. However, if there is any doubt about the serviceability of a spark plug, replace it. Spark plugs

with cracked or broken insulators should always be replaced.

A/C Clutch Diagnosis

A/C Clutch Circuit Operation

A 12-volt signal is supplied to the A/C request input of the PCM when the A/C is selected through the A/C control switch.

The A/C compressor clutch relay is controlled through the PCM. This allows the PCM to modify the idle air control position prior to the A/C clutch engagement for better idle quality. If the engine operating conditions are within their specified calibrated acceptable ranges, the PCM will enable the A/C compressor relay. This is done by providing a ground path for the A/C relay coil within the PCM. When the A/C compressor relay is enabled, battery voltage is supplied to the compressor clutch coil. The PCM will enable the A/C compressor clutch whenever the engine is running and the A/C has been requested. The PCM will not enable the A/C compressor clutch if any of the following conditions are met:

- The throttle is greater than 90%.
- The engine speed is greater than 6315 RPM.
- The ECT is greater than 119°C (246°F).
- The IAT is less than 5°C (41°F).
- The throttle is more than 80% open.

A/C Clutch Circuit Purpose

The A/C compressor operation is controlled by the powertrain control module (PCM) for the following reasons:

- It improves idle quality during compressor clutch engagement.
- It improves wide open throttle (WOT) performance.
- It provides A/C compressor protection from operation with incorrect refrigerant pressures.

The A/C electrical system consists of the following components:

- The A/C control head.
- The A/C refrigerant pressure switches.
- The A/C compressor clutch.
- The A/C compressor clutch relay.
- The PCM.

A/C Request Signal

This signal tells the PCM when the A/C mode is selected at the A/C control head. The PCM uses this to adjust the idle speed before turning on the A/C clutch. The A/C compressor will be inoperative if this signal is not available to the PCM.

Refer to *A/C Clutch Circuit Diagnosis* for A/C wiring diagrams and diagnosis for A/C electrical system.

General Description (Evaporative (EVAP) Emission System)

EVAP Emission Control System Purpose

The basic evaporative emission (EVAP) control system used on all vehicles is the charcoal canister storage method. Gasoline vapors from the fuel tank flow into the canister through the inlet labeled "TANK." These vapors are absorbed into the activated carbon (charcoal) storage device (canister) in order to hold the vapors when the vehicle is not operating. The canister is purged by PCM control when the engine coolant temperature is over 60°C (140°F), the IAT reading is over 10°C (50°F), and the engine has been running. Air is drawn into the canister through the air inlet grid. The air mixes with the vapor and the mixture is drawn into the intake manifold.

EVAP Emission Control System Operation

The EVAP canister purge is controlled by a solenoid valve that allows the manifold vacuum to purge the canister. The powertrain control module (PCM) supplies a ground to energize the solenoid valve (purge on). The EVAP

Enhanced Evaporative Emission Control System

The basic purpose of the Enhanced Evaporative Emissions control system is the same as other EVAP systems. A charcoal-filled canister captures and stores gasoline fumes. When the PCM determines that the time is right, it opens a purge valve which allows engine vacuum to draw the fumes into the intake manifold.

The difference between this and other systems is that the PCM monitors the vacuum and/or pressure in the system to determine if there is any leakage. If the PCM determines that the EVAP system is leaking or not functioning properly, it sets a Diagnostic Trouble Code (DTC) in the PCM memory.

The enhanced EVAP system is required to detect evaporative fuel system leaks as small as 0.040 in. (1.0 mm) between the fuel filler cap and purge solenoid. The

purge solenoid control is pulse-width modulated (PWM) (turned on and off several times a second). The duty cycle (pulse width) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM. The output is commanded when the appropriate conditions have been met. These conditions are:

- The engine is fully warmed up.
- The engine has been running for a specified time.
- The IAT reading is above 10°C (50°F).

A continuous purge condition with no purge commanded by the PCM will set a DTC P1441.

Poor idle, stalling and poor driveability can be caused by:

- A malfunctioning purge solenoid.
- A damaged canister.
- Hoses that are split, cracked, or not connected properly.

system can test the evaporative system integrity by applying a vacuum signal (ported or manifold) to the fuel tank to create a small vacuum. The PCM then monitors the ability of the system to maintain the vacuum. If the vacuum remains for a specified period of time, there are no evaporative leaks and a PASS report is sent to the diagnostic executive. If there is a leak, the system either will not achieve a vacuum, or a vacuum cannot be maintained. Usually, a failure can only be detected after a cold start with a trip of sufficient length and driving conditions to run the needed tests. The enhanced EVAP system diagnostic will conduct up to eight specific sub-tests to detect fault conditions. If the diagnostic fails a sub-test, the PCM will store a Diagnostic Trouble Code (DTC) to indicate the type of detected.



Legend

- | | |
|---|--|
| (1) Vent Solenoid | (12) Vent Filter |
| (2) EVAP Purge Solenoid | (13) Fuel Tank Pressure Sensor |
| (3) Throttle Body | (14) Fuel Tank Pressure Signal to PCM |
| (4) Fuel Filler Neck | (15) 5 Volt Reference "A" Circuit from PCM |
| (5) Fuel Tank | (16) Sensor Ground Circuit from PCM |
| (6) Rollover Valve | (17) Fuel Level Sensor |
| (7) EVAP Canister | (18) Fuel Level Signal to PCM |
| (8) Ignition Feed | (19) 5 Volt Return |
| (10) EVAP Purge Solenoid Driver Signal from PCM | |

Electrical Components

The electrical components that make up the enhanced EVAP system are:


- Fuel Tank Pressure Sensor. The fuel tank pressure sensor is a three-wire strain gauge sensor similar to a common MAP sensor. However, the fuel tank pressure sensor has very different electrical characteristics due to its pressure differential design. The sensor measures the difference between the air pressure (or vacuum) in the fuel tank and the outside air pressure.

The sensor mounts at the top of the fuel pump assembly. A three-wire electrical harness connects it to the PCM. The PCM supplies a five-volt reference


voltage and a ground to the sensor. The sensor will return a voltage between 0.1 and 4.9 volts. When the air pressure in the fuel tank is equal to the outside air pressure, such as when the fuel cap is removed, the output voltage of the sensor will be 1.3 to 1.7 volts.

When the air pressure in the fuel tank is 4.5 in. H₂O (1.25 kPa), the sensor output voltage will be 0.5 ± 0.2 V. When there is neither vacuum nor pressure in the fuel tank, the sensor voltage will be 1.5 V. At -14 in. H₂O (-3.75 kPa), the sensor voltage will be 4.5 ± 0.2 V.


- EVAP Canister Purge Solenoid. Normally closed, the purge solenoid opens upon the PCM's signal to allow engine vacuum to purge gasoline fumes from the canister. Mounted on the water pipe to front of the engine assembly.




- EVAP Canister Vent Solenoid. Located next to the canister, the vent solenoid opens to allow air into the EVAP system. Fresh air is necessary to completely remove gasoline fumes from the canister during purge. The EVAP vent solenoid closes to seal off the evaporative emissions system for leak testing.



- Fuel Level Sensor. The fuel level sensor is an important input to the PCM for the enhanced EVAP system diagnostic. The PCM needs fuel level information to know the volume of fuel in the tank. The fuel level affects the rate of change of air pressure in the EVAP system. Several of the enhanced EVAP system diagnostic sub-tests are dependent upon correct fuel level information. The diagnostic will not run when the tank is less than 15% or more than 85% full. Be sure to diagnose any Fuel Level Sensor DTCs first, as they can cause other DTCs to set.




- Manifold Absolute Pressure (MAP) Sensor. The PCM compares the signals from the fuel tank pressure sensor and the MAP sensor to ensure that a relative vacuum is maintained the EVAP system.



Non-Electrical Components

- Purge/Vacuum Hoses. Made of rubber compounds, these hoses route the gasoline fumes from their sources to the canister and from the canister to the intake air flow.
- EVAP Canister. Mounted on a bracket ahead of the fuel tank, the canister stores fuel vapors until the PCM determines that engine conditions are right for them to be remove and burned.
- Fuel Tank. The tank has a built-in air space designed for the collection of gasoline fumes.



- Vacuum Source. The vacuum source is split between two ports, one on either side of the throttle body.
- Fuel Cap. The fuel cap is designed to be an integral part of the EVAP system.

System Fault Detection

The EVAP leak detection strategy is based on applying vacuum to the EVAP system and monitoring vacuum decay. The PCM monitors vacuum level via the fuel tank pressure sensor. At an appropriate time, the EVAP purge solenoid and the EVAP vent solenoid are turned "ON," allowing the engine vacuum to draw a small vacuum on the entire evaporative emission system.

After the desired vacuum level has been achieved, the EVAP purge solenoid is turned "OFF," sealing the system. A leak is detected by monitoring for a decrease in vacuum level over a given time period, all other variables remaining constant. A small leak in the system will cause DTC P0442 to be set.

If the desired vacuum level cannot be achieved in the test described above, a large leak or a faulty EVAP purge solenoid is indicated.

Leaks can be caused by the following conditions:

- Disconnected or faulty fuel tank pressure sensor
- Missing or faulty fuel cap
- Disconnected, damaged, pinched, or blocked EVAP purge line

- Disconnected or damaged EVAP vent hose
- Disconnected, damaged, pinched, or blocked fuel tank vapor line
- Disconnected or faulty EVAP purge solenoid
- Disconnected or faulty EVAP vent solenoid
- Open ignition feed circuit to the EVAP vent or purge solenoid
- Damaged EVAP canister
- Leaking fuel sender assembly O-ring
- Leaking fuel tank or fuel filler neck

A restricted or blocked EVAP vent path is detected by drawing vacuum into the EVAP system, turning "OFF" the EVAP vent solenoid and the EVAP purge solenoid (EVAP vent solenoid "OPEN," EVAP purge Pulse Width Modulate (PWM) "0%") and monitoring the fuel tank vacuum sensor input. With the EVAP vent solenoid open, any vacuum in the system should decrease quickly unless the vent path is blocked. A blockage like this will set DTC P0446 and can be caused by the following conditions:

- Faulty EVAP vent solenoid (stuck closed)
- Plugged, kinked or pinched vent hose
- Shorted EVAP vent solenoid driver circuit
- Plugged EVAP canister

The PCM supplies a ground to energize the purge solenoid (purge "ON"). The EVAP purge control is PWM, or turned "ON" and "OFF," several times a second. The duty cycle (pulse width) is determined by engine operating conditions including load, throttle position, coolant temperature and ambient temperature. The duty cycle is calculated by the PCM and the output is commanded when the appropriate conditions have been met.


The system checks for conditions that cause the EVAP system to purge continuously by commanding the EVAP vent solenoid "ON" and the EVAP purge solenoid "OFF" (EVAP vent solenoid "CLOSED," EVAP purge PWM "0%"). If fuel tank vacuum level increases during the test, a continuous purge flow condition is indicated, which will set a DTC P1441. This can be cause by the following conditions:

- EVAP purge solenoid leaking
- EVAP purge and engine vacuum lines switched at the EVAP purge solenoid
- EVAP purge solenoid driver circuit grounded

General Description (Exhaust Gas Recirculation (EGR) System)

EGR Purpose

The exhaust gas recirculation (EGR) system is use to reduce emission levels of oxides of nitrogen (NOx). NOx emission levels are caused by a high combustion temperature. The EGR system lowers the NOx emission levels by decreasing the combustion temperature.



057RW002

Linear EGR Valve

The main element of the system is the linear EGR valve. The EGR valve feeds small amounts of exhaust gas back into the combustion chamber. The fuel/air mixture will be diluted and combustion temperatures reduced.

Linear EGR Control

The PCM monitors the EGR actual position and adjusts the pintle position accordingly. The uses information from the following sensors to control the pintle position:

- Engine coolant temperature (ECT) sensor.
- Throttle position (TP) sensor.
- Mass air flow (MAF) sensor.

Linear EGR Valve Operation and Results of Incorrect Operation

The linear EGR valve is designed to accurately supply EGR to the engine independent of intake manifold vacuum. The valve controls EGR flow from the exhaust to the intake manifold through an orifice with a PCM controlled pintle. During operation, the PCM controls pintle position by monitoring the pintle position feedback signal. The feedback signal can be monitored with a Tech 2 as "Actual EGR Pos." "Actual EGR Pos." should always be near the commanded EGR position ("Desired EGR Pos."). If a problem with the EGR system will not allow the PCM to control the pintle position properly, DTC P1406 will set. The PCM also tests for EGR flow. If incorrect flow is detected, DTC P0401 will set. If DTCs P0401 and/or P1406 are set, refer to the DTC charts.

The linear EGR valve is usually activated under the following conditions:


- Warm engine operation.
- Above-idle speed.

Too much EGR flow at idle, cruise or cold operation may cause any of the following conditions to occur:

- Engine stalls after a cold start.
- Engine stalls at idle after deceleration.
- Vehicle surges during cruise.
- Rough idle.
- DTC P0300 (misfire detected).

Too little or no EGR flow may allow combustion temperatures to get too high. This could cause:

- Spark knock (detonation).
- Engine overheating.
- Emission test failure.
- DTC P0401 (EGR flow test).
- Poor fuel economy.



0017

EGR Pintle Position Sensor

The PCM monitors the EGR valve pintle position input to ensure that the valve responds properly to commands from the PCM and to detect a fault if the pintle position sensor and control circuits are open or shorted. If the PCM detects a pintle position signal voltage outside the normal range of the pintle position sensor, or a signal voltage that is not within a tolerance considered acceptable for proper EGR system operation, the PCM will set DTC P1406.

General Description (Positive Crankcase Ventilation (PCV) System)


Crankcase Ventilation System Purpose

The crankcase ventilation system is used to consume crankcase vapors in the combustion process instead of venting them to the atmosphere. Fresh air from the throttle body is supplied to the crankcase and mixed with blow-by gases. This mixture is then passed through the


positive crankcase ventilation (PCV) valve into the common chamber.

Crankcase Ventilation System Operation

The primary control is through the positive crankcase ventilation (PCV) valve. The PCV valve meters the flow at a rate that depends on the intake vacuum. The PCV valve restricts the flow when the inlet vacuum is highest. In addition, the PCV valve can seal the common chamber off in case of sudden high pressure in the crankcase.



While the engine is running, exhaust fumes and small amounts of the fuel/air mixture escape past the piston rings and enter the crankcase. These gases are mixed with clean air entering through a tube from the air intake duct.



During normal, part-throttle operation, the system is designed to allow crankcase gases to flow through the PCV valve into the throttle body to be consumed by normal combustion.

A plugged valve or PCV hose may cause the following conditions:

- ☐ Rough idle.
- ☐ Stalling of slow idle speed.
- ☐ Oil leaks.
- ☐ Sludge in the engine.

A leaking PCV hose would cause:

- ☐ Rough idle.
- ☐ Stalling.
- ☐ High idle speed.

Special Tools

















ILLUSTRATION	TOOL NO. TOOL NAME	ILLUSTRATION	TOOL NO. TOOL NAME
	J 39200 High Impedance Multimeter (Digital Voltmeter – DVM)		J 37027-A IAC Motor Analyzer
	(1) PDMCIA Card (2) RS232 Loop Back Connector (3) SAE 16/19 Adapter (4) DLC Cable (5) TECH-2		J 23738-A Vacuum Pump with Gauge
	J 34142-B Unpowered Test Light		BT-8515/8515V Exhaust Back Pressure Tester
	Connector Test Adapter Kit J 35616-A/BT-8637		J 39194-B Heated Oxygen Sensor Wrench
	J 26792/BT-7220-1 Spark Tester		J 35689-A Terminal Remover
	J 34730-E Port Fuel Injection Diagnostic Kit		J 28742-A Weather Pack II Terminal Remover

ILLUSTRATION	TOOL NO. TOOL NAME
	J 39021-90 Injector Switch Box
	J 39021-65 Injector Test Light
	J 41413¹ EVAP Pressure/Purge Diagnostic Station
	J 41416² Ultrasonic Leak Detector

1. J 41413 EVAP Pressure/Purge Diagnostic Station is a multipurpose tool which is used to perform several diagnostic procedures for enhanced emission testing. The station will accommodate a nitrogen gas filled cylinder which is used to pressurize the vehicle EVAP system for a leakdown test and leak location test when a vehicle is repaired for leakage in the enhanced evaporative emission control system. It also has two additional gauges (inches of mercury and inches of water) which are used to measure both source vacuum and EVAP canister purge vacuum to verify correct operation and vapor flow within the canister purge circuit.
2. J 41416 Ultrasonic Leak Detector is a microprocessor-based device used to detect leaks in the enhanced evaporative emission control system. The evaporative system is pressurized to 30 inches of water using the J 41413 EVAP Pressure/Purge Diagnostic System. Small leaks in the EVAP system will emit sound at a high frequency undetectable by a human ear but detectable with the J 41416. The technician traces along the evaporative system and can pinpoint leaks due to corroded lines, cracked hoses, or a damaged EVAP component. The detector includes a high quality set of headphones to block out surrounding shop noise and the LED sensitivity meter allows a visual reference for locating leaks in conjunction with the audio output heard through the headphones. Powered by (1) nine volt battery.

RODEO

ENGINE

ENGINE EXHAUST (6VD1 3.2L)

CONTENTS


Service Precaution	6F-1	Forked Exhaust Pipe	6F-5
General Description	6F-2	Forked Exhaust Pipe and Associated Parts	6F-5
Three Way Catalytic Converter RH and Forked Exhaust Pipe	6F-3	Removal	6F-5
Three Way Catalytic Converter RH and Forked Exhaust Pipe and Associated Parts	6F-3	Installation	6F-5
Removal	6F-3	Exhaust Silencer	6F-6
Installation	6F-3	Exhaust Silencer and Associated Parts ...	6F-6
Three Way Catalytic Converter LH and Forked Exhaust Pipe	6F-4	Removal	6F-6
Three Way Catalytic Converter LH and Forked Exhaust Pipe and Associated Parts	6F-4	Installation	6F-6
Removal	6F-4	Rear Exhaust pipe	6F-7
Installation	6F-4	Rear Exhaust pipe and Associated Parts .	6F-7
		Removal	6F-7
		Installation	6F-7
		Main Data and Specifications	6F-8

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description



150RW023

When inspecting or replacing exhaust system components, make sure there is adequate clearance from all points on the underbody to prevent overheating the floor pan and possible damage to the passenger compartment insulation and trim materials.

Check complete exhaust system and nearby body areas and rear compartment lid for broken, damaged, missing or mispositioned parts, open seams, holes, loose connections or other deterioration which could permit exhaust fumes to seep into the rear compartment or passenger compartment. Dust or water in the rear compartment may be an indication of a problem in one of these areas. Any faulty areas should be corrected immediately.

Hangers

Various types of hangers are used to support exhaust system(s). These include conventional rubber straps, rubber rings, and rubber blocks.

The installation of exhaust system supports is very important, as improperly installed supports can cause annoying vibrations which can be difficult to diagnose.

Three Way Catalytic Converter

The three way catalytic converter is an emission control device added to the exhaust system to reduce pollutants from the exhaust gas stream.

CAUTION: The catalytic converter requires the use of unleaded fuel only.

Periodic maintenance of the exhaust system is not required. If the vehicle is raised for other service, it is advisable to check the condition of the complete exhaust system.

A dual bed monolith catalytic converter is used in combination with three way catalytic converter.

Catalytic Converter Types:

Three way (Reduction/Oxidation) catalyst


The catalyst coating on the three way (reduction) converter contains platinum and rhodium which lowers the levels of nitrous oxide (NOx) as well as hydrocarbons (HC) and carbon monoxide (Co).

Gasket

The gasket must be replaced whenever a new exhaust pipe, muffler or catalytic converter is installed.

Three Way Catalytic Converter RH and Forked Exhaust Pipe

Three Way Catalytic Converter RH and Forked Exhaust Pipe and Associated Parts



150RW024

Legend

- (1) Three Way Catalytic Converter Fixing Nuts
- (2) O2 Sensor Terminal Connector
- (3) Three Way Catalytic Converter RH
- (4) Mounting Rubber
- (5) Forked Exhaust Pipe Fixing Bolts

- (6) O2 Sensor Terminal Connector
- (7) Mass Damper
- (8) Forked Exhaust Pipe
- (9) Forked Exhaust Pipe Fixing Nuts
- (10) Exhaust Silencer Fixing Nuts
- (11) Forked Exhaust Pipe Fixing Bolts

Removal

1. Disconnect battery ground cable.
2. Lift up the vehicle and support with suitable safety stands.
3. Disconnect O2 sensor harness connectors (2) (6).
4. Remove the forked exhaust pipe fixing bolts and nuts (5) (9) (11) and the exhaust silencer fixing nuts (10), then remove the forked exhaust pipe (8) and the mass damper.
5. Remove the three way catalytic converter fixing nuts (1) and the mounting rubber (4), then remove the three way catalytic converter (3).

Installation

1. Install the three way catalytic converter (3) and the mounting rubber (4), and tighten the fixing nuts (1) to the specified torque.

Torque

Nuts : 67 N·m (49 lb ft)

2. Install the forked exhaust pipe (8) and the mass damper (7), and tighten the fixing bolts (5) & nuts (9) (10) to the specified torque.

Torque


Bolts&Nuts : 43 N·m (32 lb ft)

Nuts : 43 N·m (32 lb ft)

3. Connect the O2 sensor connectors (2) (6).

Three Way Catalytic Converter LH and Forked Exhaust Pipe

Three Way Catalytic Converter LH and Forked Exhaust Pipe and Associated Parts



150RW025

Legend

- | | |
|--------------------------------------|--|
| (1) Forked Exhaust Pipe Fixing Bolts | (6) Forked Exhaust Pipe Fixing Bolts |
| (2) Mass Damper | (7) Mounting Rubber |
| (3) Forked Exhaust Pipe | (8) O2 Sensor Terminal Connector |
| (4) Forked Exhaust Pipe Fixing Nuts | (9) Three Way Catalytic Converter LH |
| (5) Exhaust Silencer Fixing Nuts | (10) O2 Sensor Terminal Connector |
| | (11) Three Way Catalytic Converter Fixing Nuts |

Removal

1. Disconnect battery ground cable.
2. Lift up the vehicle and support with suitable safety stands.
3. Disconnect O2 sensor harness connectors (8) (10).
4. Remove the forked exhaust pipe fixing bolts and nuts (1) (4) (6) and the exhaust silencer fixing nuts (5), then remove the forked exhaust pipe (3) and the mass damper (2).
5. Remove the three way catalytic converter fixing nuts (11) and the mounting rubber (7), then remove the three way catalytic converter (9).

Installation

1. Install the three way catalytic converter (9) and the mounting rubber (7), and tighten the fixing nuts (11) to the specific torque.

Torque

Nuts: 67 N·m (49 lb ft)

2. Install the forked exhaust pipe (3) and the mass damper (2), and tighten the fixing bolts (1) (6) and nuts (4) (5) to the specified torque.

Torque


Bolts&Nuts: 43 N·m (32 lb ft)

Nuts: 43 N·m (32 lb ft)

3. Connect the O2 sensor connectors (8) (10).

Forked Exhaust Pipe

Forked Exhaust Pipe and Associated Parts



150RW026

Legend

- | | |
|--------------------------------------|--------------------------------------|
| (1) Mass Damper | (4) Forked Exhaust Pipe Fixing Nuts |
| (2) Forked Exhaust Pipe Fixing Bolts | (5) Exhaust Silencer Fixing Nuts |
| (3) Forked Exhaust Pipe | (6) Forked Exhaust Pipe Fixing Bolts |

Removal

1. Disconnect battery ground cable.
2. Lift up the vehicle and support with suitable safety stands.
3. Remove the forked exhaust pipe fixing bolts & nuts (2) (4) (6) and the exhaust silencer fixing nuts (5), then remove the forked exhaust pipe (3) and the mass damper (1).

Installation

1. Install the forked exhaust pipe (3) and the mass damper (1), and tighten the fixing bolts (2) (6) and the nuts (4) (5) to the specified torque.


Torque

Bolts&nuts : 43 N·m (32 lb ft)

Nuts : 43 N·m (32 lb ft)

Exhaust Silencer

Exhaust Silencer and Associated Parts



150RW027

Legend

- | | |
|--------------------------------|-----------------------------------|
| (1) Forked Exhaust Pipe | (3) Exhaust Silencer |
| (2) Support Rubber Fixing Nuts | (4) Exhaust Silencer Fixing Nuts |
| | (5) Rear Exhaust Pipe Fixing Nuts |

Removal

1. Disconnect battery ground cable.
2. Lift up the vehicle and support with suitable safety stands.
3. Remove the support rubber fixing nuts (2), the exhaust silencer fixing nuts (4) and rear exhaust pipe fixing nuts (5), then remove the exhaust silencer (3).

Installation

1. Install the exhaust silencer (3) and tighten the fixing nuts (4) (5) to the specified torque.

Torque

Nuts: 43 N·m (32 lb ft)


2. Tighten the support rubber fixing nuts (2) to the specified torque.

Torque

Bolts: 15 N·m (11 lb ft)

Rear Exhaust pipe

Rear Exhaust pipe and Associated Parts



Legend

- (1) Mounting Rubber
- (2) Rear Exhaust Pipe Fixing Nuts
- (3) Mounting Rubber
- (4) Rear Exhaust Pipe

Removal

1. Disconnect battery ground cable.
2. Lift up the vehicle and support with suitable safety stands.
3. Remove the rear exhaust fixing nuts (2) and the mounting rubbers (1) (3), then remove the rear exhaust pipe (4).

Installation


1. Install the rear exhaust pipe (4) and the mounting rubbers (1) (3), then tighten the fixing nuts (2) to the specified torque.

Torque

Nuts: 43 N·m (32 lb ft)

Main Data and Specifications

Torque Specifications



150RW033

RODEO

ENGINE

ENGINE LUBRICATION (6VD1 3.2L)

CONTENTS


Service Precaution	6G-1	Oil Pump	6G-9
General Description	6G-2	Removal	6G-9
Oil Pump	6G-3	Installation	6G-9
Oil Pump and Associated Parts	6G-3	Oil Pump Oil Seal	6G-11
Disassembly	6G-4	Removal	6G-11
Inspection and Repair	6G-4	Installation	6G-11
Reassembly	6G-5	Oil Filter	6G-12
Oil Pan and Crankcase	6G-7	Removal	6G-12
Removal	6G-7	Installation	6G-12
Installation	6G-7	Main Data and Specification	6G-13

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description




C06RW003

Legend

- | | |
|-------------------------|---|
| (1) Oil Strainer | (10) Connecting Rod Bearing |
| (2) Oil Pump | (11) Connecting Rod |
| (3) Relief Valve | (12) Piston |
| (4) Oil Pressure Switch | (13) Oil Gallery; Cylinder Head |
| (5) Oil Filter | (14) Camshaft |
| (6) Safety Valve | (15) Camshaft Journal |
| (7) Oil Gallery | (16) Front Journal; Camshaft Drive Gear |
| (8) Crankshaft Bearing | (17) Rear Journal; Camshaft Drive Gear |
| (9) Crankshaft | (18) Oil Pan |

Oil Pump

Oil Pump and Associated Parts



051RW005

Legend

- | | |
|------------------------------|--------------------|
| (1) Crankshaft Timing Pulley | (8) Relief Valve |
| (2) Crankcase with Oil Pan | (9) Oil Pump Cover |
| (3) Oil Pipe | (10) Driven Gear |
| (4) Oil Strainer | (11) Drive Gear |
| (5) Oil Pump Assembly | (12) Oil Seal |
| (6) Plug | (13) O-ring |
| (7) Spring | (14) Oil Pump Body |

Disassembly


1. Remove crankshaft timing pulley.
2. Remove crankcase with oil pan.
3. Remove oil pipe.
4. Remove oil strainer.
5. Remove oil pump assembly.
6. Remove plug.
7. Remove spring.
8. Remove relief valve.
9. Remove oil pump cover.
10. Remove driven gear.
11. Remove drive gear.
12. Remove oil seal.
13. Remove O-ring.

Inspection and Repair

CAUTION: Make necessary correction or parts replacement if wear, damage or any other abnormal conditions are found during inspection.

Relief Valve (8)

- Check to see that the relief valve slides freely.
- The oil pump must be replaced if the relief valve does not slide freely.
- Replace the spring and/or the oil pump assembly (5) if the spring is damaged or badly worn.



Body (14) and Gears (10, 11)


The pump assembly must be replaced if one or more of the conditions below is discovered during inspection.

- Badly worn or damaged driven gear (10).
- Badly worn drive gear (11) driving face.
- Badly scratched or scored body sliding face (14) or driven gear (10).
- Badly worn or damaged gear teeth.

Measure the clearance between the body and the driven gear with a feeler gauge.

**Standard : 0.10 mm–0.18 mm
(0.0039 in.–0.0070 in)**


Limit : 0.20mm (0.0079 in)



- Measure the clearance between the drive gear and driven gear with a feeler gauge.

**Standard : 0.11 mm–0.24 mm
(0.0043 in–0.0094 in)**

Limit : 0.35mm (0.0138 in)




- Measure the side clearance with a precision straight edge and a feeler gauge.

Clearance


**Standard : 0.03 mm–0.09 mm
(0.0011 in–0.0035 in)**

Limit : 0.15mm (0.0059 in)



Oil Strainer

Check the oil strainer for cracking and scoring. If cracking and scoring are found, the oil strainer must be replaced.



Reassembly


1. Install drive gear (11).
2. Install driven gear (10).
3. Install oil pump cover (9) and first, loosely tighten all of the attaching screws. Next, tighten the attaching screws to the specified torque.

Torque : 10 N·m (89 lb in)

After installation, check that the gear rotates smoothly.

4. Install relief valve (8) and apply engine oil to the relief valve and spring (7).
5. Install spring (7).
6. Install the plug (6).

Torque : 8 N·m (69 lb in)




7. Install oil pump assembly (5).


- Carefully remove any oil from the cylinder body and the pump. Apply sealant (TB-1207B or equivalent) to the pump fitting face as shown in illustration. Take care that sealant is not applied to oil port surfaces. The oil pump assembly must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.

CAUTION: Do not apply an excessive amount of sealant to the contact surface. Applying too much sealant will overflow the contact surfaces. This could cause serious damage to the engine.

- Attach oil pump assembly to cylinder body.
- Tighten the oil pump fixing bolts.

Torque : 25 N·m (18 lb·ft)






Legend

- (1) Around Bolt Holes
- (2) Around Dowel Pin

8. Install the new oil seal (12). Apply engine oil to the oil seal lip before installation then use J-39202 oil seal Installer, install oil seal.



9. Install oil strainer (4) with O-ring (13).

Torque: 25 N-m (18 lb ft)


10. Install oil pipe (3) with O-ring (13).

Torque: 25 N-m (18 lb ft)

11. Install crankcase with oil pan (2).

- Remove oil on crankcase mounting surface and dry the surface.
- Apply a proper 4.5 mm (0.7 in) wide bead of sealant (TB1207C or equivalent) to the crankcase mounting surface. The bead must be continuous.
- The crankcase must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.
- Tighten fixing bolts to the specified torque.

Torque : 10 N-m (89 lb in)




12. Install crankshaft timing pulley.

Oil Pan and Crankcase

Removal

1. Disconnect battery ground cable.
2. Drain engine oil.
3. Lift vehicle by supporting the frame.
4. Remove front wheels.
5. Remove oil level dipstick from level gauge tube.
6. Remove stone guard.
7. Remove radiator under fan shroud.
8. Remove suspension cross member fixing bolts, 2 pcs each per side and remove suspension cross member.
9. Remove the steering unit assembly.
10. Remove axle housing assembly four fixing bolts from housing isolator side and mounting bolts from wheel side. At this time support the axle with a garage jack and remove axle housing assembly.
11. Remove oil pan fixing bolts.
12. Remove oil pan, using J-37228 sealer cutter, remove oil pan.




013RS003

13. Remove crankcase fixing bolts.
14. Remove crankcase, using J-37228 sealer cutter, remove crankcase.

NOTE: Do not deform or damage the flange of oil pan and crankcase.

Replace the oil pan and/or crankcase if deformed or damaged.



013RS003


Installation

1. Install crankcase.

1. Remove residual sealant, lubricant and moisture from mounting surface, then dry thoroughly.
2. Properly apply a 4.5 mm (0.7 in) wide bead of sealant (TB-1207C or equivalent) to mounting surface of crankcase.

Sealant bead must be continuous.

- The crankcase must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.




013RW010

6G-8 ENGINE LUBRICATION (6VD1 3.2L)

3. Install crankcase, tighten crankcase fixing bolts to the specified torque.

Torque : 10 N-m (89 lb in)




013RW004

2. Install oil pan

1. Remove residual sealant, lubricant and moisture from mounting surface, then dry thoroughly.
2. Properly apply a 4.5 mm (07 in) wide bead of sealant (TB-1207C or equivalent) to mounting surface of oil pan.

Sealant beat must be continuous.

- The crankcase must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.



013RW003

3. Install oil pan, tighten oil pan fixing bolts to the specified torque.

Torque : 10 N-m (89 lb in)


3. Install axle housing assembly and tighten fixing bolts to the specified torque.

Axle case bolts

Torque : 82 N-m (60 lb ft)

Mounting bolts

Torque : 152 N-m (112 lb ft)




013RW005

4. Install relay lever assembly and tighten fixing bolts.

Torque: 44 N-m (32 lb ft)

5. Install suspension cross member and tighten fixing bolts to the specified torque.

Torque : 78 N-m (58 lb ft)



013RW007

6. Install radiator under fan shroud.
7. Install stone guard.
8. Install engine oil level dipstick.

9. Fill engine oil until full level on engine oil gauge dipstick.

Oil Pump


Removal

1. Disconnect battery ground cable.
2. Drain engine oil.
3. Remove crankcase assembly.
 - Refer to removal procedure for Oil Pan and Crankcase in this manual.
4. Remove crankshaft pulley.
 - Refer to removal procedure for Crankshaft Pulley in this manual.
5. Remove timing belt.
 - Refer to removal procedure for Timing Belt in this manual.
6. Remove timing pulley from crankshaft.
7. Remove four fixing bolts from oil filter assembly.
8. Remove oil strainer fixing bolts, remove oil strainer assembly with O-ring.
9. Remove three bolts from oil pipe and O-ring.
10. Remove eight oil pump fixing bolts, then oil pump assembly.
11. Remove sealant from mounting surface of oil pump assembly, cylinder block and take care not to damage mounting surfaces of oil pump and cylinder block.

Installation

1. Install oil pump assembly
 - Apply sealant (TB-1207B or equivalent) to the oil pump mounting surfaces as shown in the illustration.
 - The oil pump assembly must be installed within 5 minutes after sealant application to prevent premature hardening of sealant.

NOTE: Do not apply sealant to the oil ports.




051RW002

6G-10 ENGINE LUBRICATION (6VD1 3.2L)

- Use J-39202 installer when installing new oil seal.
- Apply engine oil to oil seal lip.
- Install oil pump assembly to the cylinder block.


NOTE: Do not damage oil seal during installation of oil pump assembly.



015RS001

- Tighten fixing bolts to the specified torque.

Torque : 25 N·m (18 lb ft)



051RW001

2. Install oil pipe with O-ring, tighten fixing bolt to the specified torque.


Torque : 10 N·m (89 lb in)

3. Install oil strainer with O-ring, tighten fixing bolt to the specified torque.

Torque : 25 N·m (18 lb ft)

4. Install oil filter assembly and tighten bolts to the specified torque.

Torque : 25 N·m (18 lb ft)



050RW001

Legend

- (1) Oil Pump
- (2) Oil Filter
- (3) Oil Gallery
- (4) From Oil Filter
- (5) To Oil Filter

5. Install timing pulley on crankshaft.

Install timing belt.

- Refer to installation procedure for Timing Belt in this manual.

6. Install crankshaft pulley.

- Refer to install procedure for Crankshaft Pulley in this manual.

7. Install crankcase assembly.

- Refer to installation procedure for Oil Pan and Crankcase in this manual.

8. Refill engine oil until full level on engine oil dipstick.

Oil Pump Oil Seal


Removal

1. Disconnect battery ground cable.
2. Drain engine oil.
3. Remove crankshaft pulley.
 - Refer to removal procedure for Crankshaft Pulley in this manual.
4. Remove timing belt.
 - Refer to removal procedure for Timing Belt in this manual.
5. Remove timing pulley from crankshaft.
6. Remove oil pump oil seal using a sealer puller.

NOTE: Take care not to damage sealing surfaces of oil pump and crankshaft when removing oil seal.

Installation

1. Install oil pump oil seal, apply engine oil to oil seal lip, then install oil seal using J-39202 installer.



2. Install timing pulley to crankshaft.
3. Install timing belt.
 - Refer to installation procedure for Timing Belt in this manual.
4. Install crankshaft pulley.
 - Refer to installation procedure for CRANKSHAFT PULLEY in this manual.
5. Refill engine oil until full level.


Oil Filter

Removal

1. Disconnect battery ground cable.
2. Drain engine oil.
3. Remove oil filter using J-36390 filter wrench.

Installation

1. Clean filter fitting surface and apply small amount of engine oil to sealing surface.
2. Install oil filter cartridge by hand until it comes in contact with sealing surface then rotate additional 2/3 turn to tighten using J-36390 filter wrench.



Legend

- (1) Oil Pump
- (2) Oil Filter
- (3) Oil Gallery
- (4) From Filter
- (5) To Filter

-
3. Fill engine oil until full level on dipstick.
 4. Reconnect battery ground cable.


Main Data and Specification

General Specification

Item	Specifications
	6VD1
Oil capacity	5.3 liters

Torque Specifications

Crankcase, Oil pan, Timing belt tensioner, Timing pulley, timing belt cover, Oil pump, Oil gallery, Oil strainer



E06RW025

RODEO

ENGINE

ENGINE SPEED CONTROL SYSTEM (6VD1 3.2L)

CONTENTS


Service Precaution	6H-1	Accelerator Pedal	6H-3
Accelerator Pedal Control Cable	6H-2	Accelerator Pedal and Associated Parts ..	6H-3
Removal	6H-2	Removal	6H-3
Inspection	6H-2	Installation	6H-3
Installation	6H-2		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Accelerator Pedal Control Cable



101RX001

Removal

1. Loosen the nut(5) on the cable bracket mounted on the common chamber.
2. Remove cable clip(3).
3. Disconnect accelerator pedal (AP) control cable(6). (on throttle valve side)
4. Disconnect AP control cable(1). (on AP pedal(7) side)
5. Remove molding cap(2).
6. Remove AP control cable(4).

Installation

1. Install AP control cable(4).
2. Install molding cap(2).
3. Connect AP control cable(1). (on AP side)
4. Connect AP control cable(6). (on throttle valve side)
5. Install cable clip(3).
6. Install nut(5).


Inspection

Check the following items, and replace the control cable if any abnormality is found:

- ☐ The control cable should move smoothly.
- ☐ The control cable should not be bent or kinked.
- ☐ The control cable should be free of damage and corrosion.

Accelerator Pedal

Accelerator Pedal and Associated Parts



035RX002

Legend

- (1) Accelerator Pedal Control Cable
- (2) Accelerator Pedal Assembly

Removal

1. Accelerator Pedal control cable(1).
2. Wire Harness (A/T ONLY).
3. Accelerator Pedal assembly(2).

Installation

1. Accelerator Pedal assembly(2).
2. Wire Harness (A/T ONLY).
3. Accelerator Pedal control cable(1).

ENGINE

INDUCTION (6VD1 3.2L)

CONTENTS

Service Precaution	6J-1
Air Cleaner Element	6J-2
Removal	6J-2
Inspection	6J-2
Installation	6J-2

Service Precaution


WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Air Cleaner Element


Removal

1. Remove positive ventilation hose connector(1).
2. Remove intake air temperature sensor(2).
3. Remove air flow sensor(3).
4. Remove air cleaner duct assembly(4).
5. Remove air cleaner element(5).



Installation

1. Install air cleaner element(5).
2. Attach the mass air cleaner duct cover to the body completely, then clamp it with the clip(4).
3. Install air flow sensor(3).
4. Install air temperature sensor(2).
5. Install positive crankcase ventilation hose connector(1).




Inspection

Check the air cleaner filter for damage or dust clogging. Replace if it is damaged, or clean if it is clogged.

Cleaning Method

Tap the air cleaner filter gently so as not to damage the paper filter, or clean the element by blowing with compressed air of about 490 kPa (71 psi) from the clean side if it is extremely dirty.



RODEO

TRANSMISSION

CONTENTS

Automatic Transmission (4L30-E)	7A
Transmission Control System (4L30-E)	7A1
Manual Transmission	7B
Clutch	7C

AUTOMATIC TRANSMISSION (4L30-E)

CONTENTS

Service Precaution	7A-2	Solenoid (Main Case Valve Body)	7A-44
Construction	7A-3	Removal	7A-44
Range Reference Chart	7A-4	Installation	7A-44
Normal Operation of 1999 4L30-E Transmission	7A-5	Solenoid (Adapter Case Valve Body)	7A-45
Diagnosis	7A-5	Removal	7A-45
Driver Information	7A-5	Installation	7A-45
General Diagnosis Procedure	7A-8	Valve Body Assembly (Main Case)	7A-46
Preliminary Inspection Chart	7A-9	Removal	7A-46
Checking Transmission Fluid Level and Condition	7A-10	Installation	7A-46
Test Driving	7A-11	Valve Body Assembly (Adapter Case)	7A-47
Mechanical / Hydraulic Diagnosis Check Trans Indicator Chart	7A-12	Removal	7A-47
Mechanical / Hydraulic Diagnosis Symptoms Index	7A-13	Installation	7A-47
Stall Test	7A-22	Powertrain Control Module (PCM)	7A-48
Line Pressure Test	7A-23	Removal	7A-48
Shift Speed Chart	7A-24	Installation	7A-48
Lockup Speed Chart	7A-25	Speed Sensor (Extension Housing)	7A-49
Changing Transmission Fluid	7A-26	Removal	7A-49
Selector Lever	7A-26	Installation	7A-49
Inspection	7A-26	Transmission Oil Temperature Sensor (Adapter Case)	7A-49
Removal	7A-26	Removal	7A-49
Installation	7A-27	Installation	7A-49
Select Cable	7A-28	Front Oil Seal (Converter Housing)	7A-50
Removal	7A-28	Removal	7A-50
Installation	7A-30	Installation	7A-50
Shift Lock Cable	7A-32	Rear Oil Seal (Extension Housing)	7A-50
Removal	7A-32	Removal	7A-50
Installation	7A-33	Installation	7A-50
Mode Switch	7A-34	Transmission (4L30-E)	7A-51
Removal	7A-34	Disassembly	7A-51
Installation	7A-34	Reassembly	7A-55
Transmission	7A-36	Converter Housing and Oil Pump Assembly	7A-65
Transmission and Associated Parts	7A-36	Disassembled View	7A-65
Removal	7A-37	Disassembly	7A-65
Installation	7A-39	Inspection and Repair	7A-65
		Reassembly	7A-65

7A-2 AUTOMATIC TRANSMISSION (4L30-E)


Oil Pump	7A-66	Disassembly	7A-73
Disassembled View	7A-66	Inspection and Repair	7A-73
Disassembly	7A-66	Reassembly	7A-73
Inspection and Repair	7A-66	Second Clutch	7A-74
Reassembly	7A-66	Disassembled View	7A-74
Main Case Valve Body	7A-67	Disassembly	7A-74
Disassembled View	7A-67	Inspection and Repair	7A-75
Disassembly	7A-68	Reassembly	7A-75
Inspection and Repair	7A-68	3-4 Accumulator Piston	7A-76
Reassembly	7A-68	Disassembled View	7A-76
Adapter Case Valve Body	7A-69	Disassembly	7A-76
Disassembled View	7A-69	Inspection and Repair	7A-76
Disassembly	7A-69	Reassembly	7A-77
Inspection and Repair	7A-69	Reverse Clutch Piston and Center Support .	7A-78
Reassembly	7A-69	Disassembled View	7A-78
Third Clutch and Sprag Unit	7A-70	Disassembly	7A-79
Disassembled View	7A-70	Inspection and Repair	7A-79
Disassembly	7A-70	Reassembly	7A-79
Inspection and Repair	7A-71	Overrun Clutch and Turbine Shaft	7A-80
Reassembly	7A-71	Disassembled View	7A-80
Third Clutch	7A-71	Disassembly	7A-81
Disassembled View	7A-71	Inspection and Repair	7A-81
Disassemble	7A-72	Reassembly	7A-81
Inspection and Repair	7A-72	Main Data and Specification	7A-83
Reassembly	7A-72	Special Tools	7A-87
Sprag Unit	7A-73	4L30-E Parts List	7A-90
Disassembled View	7A-73		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Construction




A07RS001

Legend

- | | |
|-----------------------------------|--|
| (1) Torque Converter Clutch (TCC) | (7) Third Clutch (C3) |
| (2) Fourth Clutch (C4) | (8) Ravigneaux Planetary Gear Set |
| (3) Overrun Clutch (OC) | (9) Brake Band (B) |
| (4) Overdrive Unit | (10) Overdrive Free Wheel (One Way Clutch) (OFW) |
| (5) Reverse Clutch (RC) | (11) Sprag Free Wheel (One Way Clutch) (PFW) |
| (6) Second Clutch (C2) | |

Range Reference Chart




RANGE	GEAR	SOL A N.C.	SOL B N.O.	O/DRIVE ROLLER CLUTCH (OFW)	OVERRUN CLUTCH (OC)	FOURTH CLUTCH (C4)	THIRD CLUTCH (C3)	REVERSE CLUTCH (RC)	SECOND CLUTCH (C2)	PRINCIPLE SPRAG ASSEMBLY (PFW)	BAND ASSEMBLY (B)	ENGINE BRAKING
P-N		OFF	ON		APPLIED							NO
R	REVERSE	OFF	ON	LD	APPLIED			APPLIED		LD		NO
D	1ST	OFF	ON	LD	APPLIED					LD	APPLIED	NO
	2ND	ON	ON	LD	APPLIED				APPLIED	FW	APPLIED	YES
	3RD	ON	OFF	LD	APPLIED		APPLIED		APPLIED	NE		YES
	4TH	OFF	OFF	FW		APPLIED	APPLIED		APPLIED	NE		YES
3	1ST	OFF	ON	LD	APPLIED					LD	APPLIED	NO
	2ND	ON	ON	LD	APPLIED				APPLIED	FW	APPLIED	YES
	3RD	ON	OFF	LD	APPLIED		APPLIED		APPLIED	NE		YES
2	1ST	OFF	ON	LD	APPLIED		APPLIED			LD	APPLIED	YES
	2ND	ON	ON	LD	APPLIED				APPLIED	FW	APPLIED	YES
L	1ST	OFF	ON	LD	APPLIED		APPLIED			LD	APPLIED	YES

LD : LOCKED IN DRIVE

FW : FREEWHEELING

NE : NOT EFFECTIVE



Normal Operation of 1999 4L30-E Transmission

Torque Converter Clutch (TCC)

Application Conditions:

The TCC is normally applied in 2nd, 3rd and 4th gears only when all of the following conditions exist:

- The engine coolant temperature is above 70°C (158°F).
- The brake pedal is released.
- The shift pattern requests TCC apply.

Moreover, TCC is always applied in 2nd, 3rd and 4th gears when the transmission oil temperature is above 135°C (275°F).

This mode should be canceled at 125°C (257°F).

ATF Warning Lamp

The ATF warning lamp will be constantly on (not flashing) if the transmission oil temperature is above 140°C (284°F).

The ATF warning lamp goes off again when the transmission oil temperature is below 120°C (248°F).

Special Shift Pattern When The Engine Is Cold:

A special shift pattern is activated when the engine coolant temperature is below 70°C (158°F). (3–4 shifts, for example, are delayed for small throttle openings and will occur a few MPH higher.)

Diagnosis

Introduction

The systematic troubleshooting information covered by this Section offers a practical and systematic approach to diagnosing 4L30-E transmission, using information that can be obtained from road tests, electrical diagnosis, oil pressure checks or noise evaluation.

The key to correcting a complaint is to make use of all of the available symptoms and logically letting them direct you to the cause.

When dealing with automatic transmission complaints, it is best to gather as many symptoms as possible before making the decision to remove the transmission from the vehicle.

Frequently, the correction of the complaint does not require removal of the transmission from the vehicle.

Driver Information

To analyze the problem fill out a complete description of the owner's complaint.

Please draw a circle around the right information and complete the following form. (The next page is an example of a completed form.) You can draw a circle around many numbers if you are not sure.

7A-6 AUTOMATIC TRANSMISSION (4L30-E)


A - Today's date :	Month :	Day :	Year :
B - End User Name, Address :			
C - Date of Problem :	Month :	Day :	Year :
D - Mileage : Miles / Km	E - With Ignition ON is CHECK TRANS Indicator : 1- Flashing 2- Not Flashing		F - Car load when problem occurred : 1 - Towing a trailer 2- people OR Kg
G - Weather conditions when problem : 1- Clear 2- Cloudy 3- Rain 4- Snow 5- Unstable 6- Any	H - Weather Temperature when problem: 1- Hot 2- Warm 3- Cool 4- Cold 5- Unstable 6- Any	I - Road Conditions when problem : 1- Any 2- Inter City 3- Outside City 4- Highway 5- Uphill 6- Downhill 7- Unpaved 8- Snow 9- Others :	J - Frequency of the Problem : 1- Always 2- Occasional : times/day, times/month 3- Only Once 4- Others :
K - Engine Condition : 1- Always 2- At Cold 3- During Warming up 4- After Warming or Hot 5- Others	L - Engine Speed when the problem occurred : 1- Idling 2- Starting 3- Stalling 4- High RPM 5- Low RPM	M - Transmission Condition when it occurred : 1- Any 2- Idling 3- Starting 4- Driving 5- Accelerating 6- Coasting 7- In corner 8- Shifting	
N - If there is a Transmission driveability problem BEFORE THE CHECK TRANS INDICATOR WAS FLASHING : 1- No Power in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 2- No shift in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 3- Shift Shock in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 4- Shift Slip in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 5- Shift Delayed in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 6- Shift Point too high in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 7- Shift Point too low in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 8- TCC Shudder in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 9- Noise in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1 Noise type : 1- Buzz 2- Whine 3- Clunk 4- Rattle 5- Whistle // 6- light 7- medium 8- heavy 10- Other : in Range : All - P - R - N - D - 3 - 2 - L during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1			
O - Other customer concern and comments			
P - Isuzu Vehicle Code :	Q - VIN Number
R - Date of Vehicle Registration	Month :	Day :	Year :
S - Trans. model :	T - A/T Serial Number :
U - Your name :		
V - Dealer Name, Address, Phone			

F07RT036

Example of form completed.


A - Today's date :		Month : April.....	Day : 13.....	Year : 1994.....																																	
B - End User Name, Address :		Dave Smith 6584, Arlington road Plymouth MI 48170 USA																																			
C - Date of Problem :		Month : April.....	Day : 8.....	Year : 1994.....																																	
D - Mileage : 12230... <u>mi</u> / Km		E - With Ignition ON is CHECK TRANS Indicator : <u>1</u> - Flashing 2 - Not Flashing		F - Car load when problem occurred : 1 - Towing a trailer 2 - <u>2</u> people OR Kg																																	
G - Weather conditions when problem : 1 - Clear 2 - Cloudy 3 - Rain 4 - Snow 5 - Unstable <u>6</u> - Any		H - Weather Temperature when problem : 1 - Hot 2 - Warm 3 - Cool 4 - Cold 5 - Unstable <u>6</u> - Any		I - Road Conditions when problem : 1 - Any 2 - Inter City 3 - Outside City <u>4</u> - Highway 5 - Uphill 6 - Downhill 7 - Unpaved <u>8</u> - Snow 9 - Others																																	
J - Frequency of the Problem : 1 - Always <u>2</u> - Occasional : times/day, times/month 3 - Only Once 4 - Others :		this means do not take this into account																																			
K - Engine Condition : 1 - Always 2 - At Cold 3 - During Warming up <u>4</u> - After Warming or Hot 5 - Others					L - Engine Speed when the problem occurred : 1 - Idling 2 - Starting 3 - Stalling <u>4</u> - High RPM 5 - Low RPM																																
M - Transmission Condition when it occurred : 1 - Any 2 - Idling 3 - Starting 4 - Driving <u>5</u> - Accelerating <u>6</u> - Coasting 7 - In corner <u>8</u> - Shifting																																					
N - If there is a Transmission driveability problem BEFORE THE CHECK TRANS INDICATOR WAS FLASHING :																																					
<table border="0"> <tr> <td>1 - No Power</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>2 - No shift</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td><u>3</u> - Shift Shock</td> <td>in Range : All - P - R - N - D - <u>3</u> - 2 - L</td> <td>during a : <u>upshift</u> : 1-2 / 2-3 / <u>3-4</u> or <u>downshift</u> : <u>4-3</u> / 3-2 / 2-1</td> </tr> <tr> <td>4 - Shift Slip</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>5 - Shift Delayed</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>6 - Shift Point too high</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>7 - Shift Point too low</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>8 - TCC Shudder</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>9 - Noise</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> <tr> <td>Noise type : 1 - Buzz 2 - Whine 3 - Clunk 4 - Rattle 5 - Whistle // 6 - light 7 - medium 8 - heavy</td> <td></td> <td></td> </tr> <tr> <td>10 - Other :</td> <td>in Range : All - P - R - N - D - 3 - 2 - L</td> <td>during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1</td> </tr> </table>					1 - No Power	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	2 - No shift	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	<u>3</u> - Shift Shock	in Range : All - P - R - N - D - <u>3</u> - 2 - L	during a : <u>upshift</u> : 1-2 / 2-3 / <u>3-4</u> or <u>downshift</u> : <u>4-3</u> / 3-2 / 2-1	4 - Shift Slip	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	5 - Shift Delayed	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	6 - Shift Point too high	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	7 - Shift Point too low	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	8 - TCC Shudder	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	9 - Noise	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1	Noise type : 1 - Buzz 2 - Whine 3 - Clunk 4 - Rattle 5 - Whistle // 6 - light 7 - medium 8 - heavy			10 - Other :	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1
1 - No Power	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
2 - No shift	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
<u>3</u> - Shift Shock	in Range : All - P - R - N - D - <u>3</u> - 2 - L	during a : <u>upshift</u> : 1-2 / 2-3 / <u>3-4</u> or <u>downshift</u> : <u>4-3</u> / 3-2 / 2-1																																			
4 - Shift Slip	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
5 - Shift Delayed	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
6 - Shift Point too high	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
7 - Shift Point too low	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
8 - TCC Shudder	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
9 - Noise	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
Noise type : 1 - Buzz 2 - Whine 3 - Clunk 4 - Rattle 5 - Whistle // 6 - light 7 - medium 8 - heavy																																					
10 - Other :	in Range : All - P - R - N - D - 3 - 2 - L	during a : upshift : 1-2 / 2-3 / 3-4 or downshift : 4-3 / 3-2 / 2-1																																			
O - Other customer concern and comments : (This is just an example). Shift shock very harsh overall during a downshift. Not sure if it's the 4-3 or 3-2.																																					
P - Isuzu Vehicle Code :		94 UCR	Q - VIN Number	4S2CV58ZXM4324047																																	
R - Date of Vehicle Registration		Month : November.	Day :18.....	Year : 1993.....																																	
S - Trans. model :		4L30-E	T - A/T Serial Number :	96 358 654																																	
U - Your name :		Joe Spring																																			
V - Dealer Name, Address, Phone Kent Helfrich Home-town ISUZU 900 - 999 - 9999																																					

General Diagnosis Procedure



F07RT038

Preliminary Inspection Chart



F07RX002

Checking Transmission Fluid Level and Condition

Checking fluid level and condition (color and odor) at regular intervals will provide early diagnosis information about the transmission. This information may be used to correct a condition that, if not detected early, could result in major transmission repairs.

IMPORTANT: When new, automatic transmission fluid is red in color. As the vehicle is driven, the transmission fluid will begin to look darker in color. The color may eventually appear light brown.

A dark brown color with burnt odor may indicate excessive fluid deterioration and signal a need for fluid change.

Fluid Level

When adding or changing fluid, use only DEXRON®-III. Refer to Maintenance and Lubrication in General Information section for maintenance information and servicing interval.

CAUTION: DO NOT OVERFILL.

Overfilling will cause foaming, loss of fluid, abnormal shifting and possible damage to the transmission.

1. Park the vehicle on level ground and apply the parking brake firmly.
2. Check fluid level with engine running at idle.

NOTE: Be sure that transmission fluid temperature is below 30°C (86°F).

3. Move the selector lever through all gear ranges.
4. Move the selector lever to "Park".
5. Let engine idle for 3 minutes and open the overfill screw (1).
6. Add released transmission fluid until it flows out over the overfill screw opening.
7. Let engine idle until a fluid temperature between 32°C (90°F) and 57°C (135°F) is reached, then close the overfill screw (1).


Torque: 38 N•m (28 lb ft)

NOTE: To prevent fluid leaks, the overfill screw and oil drain screws gasket must be replaced each time these screws are removed.

NOTE: Check transmission fluid temperature with scan tool.

Minimum fluid level → 57°C (135°F)

Maximum fluid level → 32°C (90°F)



242RW003

CAUTION: Do not open overfill screw with engine stopped.

CAUTION: DO NOT CHECK FLUID LEVEL UNDER THESE CONDITIONS:

- ☐ Immediately after driving at sustained highway speeds.
- ☐ In heavy city traffic during hot weather.
- ☐ If vehicle is towing a trailer.

If the vehicle has been operated under these conditions, shut the engine off and allow the vehicle to "cool" for thirty (30) minutes. After the cool down period, restart the vehicle and continue from step 2 above.

Fluid Condition

	FLUID CONDITION			
	NORMAL*		CONTAMINATED	
COLOR	RED OR LIGHT BROWN	BROWN	NON-TRANSPARENT / PINK	BROWN
DRAIN REQUIRED?	NO	YES	YES	YES
CONTAMINATION	NONE	Very small amount of foreign material in bottom of pan	Contamination by coolant or other source	Large pieces of metal or other foreign material in bottom of pan
CORRECT LEVEL AND CONDITION	1. LOW LEVEL: A. Add fluid to obtain proper level & check for external leaks. See chart 16 on page 7A-39. B. Correct cause of leak. 2. HIGH LEVEL: – Remove excess fluid	– Remove both pans – Change filter – Flush cooler – Add new fluid – Check level	– Repair/replace radiator cooler – Transmission overhaul required – Check for: ○ Damaged plates and seals ○ Contaminated solenoids – Flush cooler – Add new fluid – Check level	– Transmission overhaul required – Flush cooler and cooler lines – Add new fluid – Check level

*Fluid should be changed according to maintenance schedule.

Test Driving

Some 4L30-E automatic transmission complaints will require a test drive as a part of the diagnostic procedure. Some codes will not set unless the vehicle is moving. The purpose of the test drive is to duplicate the customer's complaint condition and set a current Powertrain Control Module (PCM) trouble code. Perform this procedure before each 4L30-E automatic transmission repair, and again after repairs are made.

IMPORTANT:

- Duplicate the condition under which the customer's complaint was observed.
- Depending on the complaint, the line pressure gauge and the scan tool scan tool may be required during the test drive.
- During the test drive, it is important to record all necessary data from the areas being monitored, for use in diagnosis. Also listen for and note any unusual noises.

The following procedure should be used to test drive 4L30-E automatic transmission complaint vehicles:

1. Turn the ignition ON without starting the engine. Check that the "CHECK TRANS" lamp comes on for approximately 2 to 3 seconds and then goes out and remains out.
 - If the lamp is flashing, GOTO Check Trans Indicator in Transmission Control System (4L30-E) section.
 - If no serial data is present, GOTO OBD System Check. Refer to Driveability and Emissions in Engine section.

○ If the lamp stays ON or stays OFF, GOTO "Check Trans" Check in Transmission Control System (4L30-E) section.

2. Drive the vehicle. During the test drive, be sure that the transmission achieves normal operating temperature (approx. 20 minutes).
Allow the transmission to go through all of its gear ranges, checking shift timing and firmness. Duplicate the owner's complaint condition as closely as possible during the test drive.
3. If, during the test drive, the "CHECK TRANS" lamp comes on, use the scan tool to check for trouble codes.
4. If, during the test drive, a problem is felt, but the "CHECK TRANS" lamp does not come on and no trouble codes are present, drive the vehicle with the PCM disconnected (manually shifting the vehicle).
 - In Manual L, the vehicle operates in first gear.
 - In Manual 2, the vehicle operates in third gear.
 - In Manual 3 or "D", the vehicle operates in fourth gear.
 If the problem still exists with the PCM disconnected, refer to Mechanical/Hydraulic Diagnosis in this section.
5. If no problem has been found at this point, check all underhood connections that supply power to the PCM and ignition fuses. Physically and visually inspect all the PCM harness connectors for loose or corroded terminals. Inspect the PCM ground points.


Mechanical / Hydraulic Diagnosis

Check Trans Indicator Chart

Perform Preliminary Inspection First!

When the "CHECK TRANS" indicator is flashing, it indicates that a problem related to the transmission, the Powertrain Control Module (PCM), or the vehicle harness has occurred.

The system is now operating in a "BACKUP MODE" where the risk of further damaging the transmission has been reduced. The vehicle may be shifted manually. If the initial problem is intermittent or seldom, switching the engine OFF/ON might allow normal operation again until the problem reoccurs.



F07RT013

Mechanical / Hydraulic Diagnosis Symptoms Index**Perform Preliminary Inspection First!**

CHART	SYMPTOMS
1	NO ENGINE START IN NEUTRAL OR PARK
2	NO FORWARD GEARS IN ANY RANGE/NO REVERSE
3	NO ENGINE BRAKE IN ANY RANGE
4	POOR SHIFTING IN ALL GEARS (ALL HARSH OR ALL SOFT)
5a	DELAYS IN DRIVE AND REVERSE
5b	DELAYS IN REVERSE ONLY
6	DIAGNOSTIC TROUBLE CODE (DTC) P0730
7	HARSH 1-2 SHIFT
8	HARSH 3-4 SHIFT
9a	3-2 DOWNSHIFT COMPLAINT
9b	HARSH SHIFT WHEN SHIFTING INTO "D" OR ACCELERATING FROM STOP
9c	COASTDOWN HARSH SHIFT OR CLUNK AT 3-2 DOWNSHIFT
10	INTERMITTENT 4TH TO 2ND GEAR DOWNSHIFT AT STEADY SPEED
11	ENGINE FLARE AT SHIFTING DURING TURNING ONLY
12	ENGINE FLARE DURING 1-2 OR 2-3 SHIFT
13	SHUDDER ONLY DURING TORQUE CONVERTER CLUTCH (TCC) APPLYING
14	POSSIBLE CAUSES OF TRANSMISSION NOISE
15a	POSSIBLE CAUSES OF LOW LINE PRESSURE
15b	POSSIBLE CAUSES OF HIGH LINE PRESSURE
16	POSSIBLE CAUSES OF TRANSMISSION FLUID LEAKS

NOTE: Numbers with parenthesis on the following charts refer to Parts List at end of this section.

Chart 1: No Engine Start In Neutral Or Park

Step	Action	Yes	No
1	Does engine start when shift lever moved from drive to neutral mostly in hot condition?	Go to Step 2	Go to Step 3
2	Does engine start in park at any condition?	Re-test vehicle	Go to Step 4
3	Does engine also not start in neutral when shift lever moved from park to neutral?	Go to Step 5	Go to Step 4
4	Check mode switch (63) setting. Readjust if necessary. Problems fixed?	Re-test vehicle	Go to Step 5
5	Check start circuit of mode switch (63) open in neutral. Was open found?	Locate and repair open(s).	Replace mode switch (63).

7A-14 AUTOMATIC TRANSMISSION (4L30-E)**Chart 2: No Forward Gears In Any Range/No Reverse**

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15a: Possible Causes of Low Line Pressure in this section.
2	1. Check internal linkage: – Manual linkage (58) not moving manual valve (326). 2. Check for internal mechanical damage: – Turbine shaft (506) broken loose. – Overrun roller clutch (576) broken loose. Was the problem found?	Repair or replace	—

Chart 3: No Engine Brake In Any Range

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15a: Possible Causes of Low Line Pressure in this section.
2	1. Check for overrun clutch leaks caused by: – Damaged piston lip (513) – Check ball defective (504) 2. Check for overrun lockout valve (705) stuck by foreign material. 3. Check for leaks at turbine shaft (506) caused by: – Teflon seal rings damaged (508) – Excessive wear of turbine shaft bearing surfaces. Was the problem found?	Repair or replace	—

Chart 4: Poor Shifting In All Gears (All Harsh Or All Soft)

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Go to Step 3
2	1. Check for these conditions which could affect clutch apply time: – Defective band apply solenoid (323). – Defective servo or/and accumulator piston. – Excessive clutch piston travel. 2. Check of possible causes of internal leaks: – Cut or damaged sealing ring(s) – Damaged sealing gasket(s) 3. Check ball missing or out of location in 2nd and 3rd clutch pistons. Was the problem found?	Repair or replace	—
3	Was the line pressure high?	Go to Step 4	Use Chart 15a: Possible Causes of Low Line Pressure in this section.
4	Were DTCs P0560 and P0705 set?	Diagnose those DTC(s) first.	Use Chart 15b: Possible Causes of High Line Pressure in this section.

Chart 5a: Delays In Drive and Reverse

NOTE: A short delay (less than 3 seconds) when first engaging drive or reverse after allowing vehicle to sit overnight is normal.

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	More than 3 second delay in drive and reverse with engine off 1 hour or less. Teflon seals (508) on turbine shaft damaged. Repair	Use Chart 15a: Possible Causes of Low Line Pressure in this section.

Chart 5b: Delays In Reverse Only

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15a: Possible Causes of Low Line Pressure in this section.
2	Main case valve body gasket (88) damaged. – Reverse check ball (85) in valve body (84) missing or out of location. – Check for restrictions at valve body transfer plate orifice. Was the problem found?	Repair	—

Chart 6: Diagnostic Trouble Code (DTC) P0730

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15b: Possible Causes of High Line Pressure in this section.
2	<ol style="list-style-type: none"> 1st and 2nd gear missing or 3rd and 4th gear missing. Check appropriate shift valve. If OK replace solenoid. No engine brake in any range (All ranges in Drive and Reverse are OK) Check for suspected conditions modifying delays to clutch apply: <ul style="list-style-type: none"> – Overrun clutch seal damaged. – Excessive overrun clutch piston travel. – Defective 3–4 accumulator piston. – Causes of internal leaks. – Causes of burned clutch plates. 1st and 4th gear missing or 2nd and 3rd gear missing. Shift solenoid A stuck. Replace shift solenoid A. DTC P0730 is set in D range 1st gear above 3500 rpm. Go to Step 3. DTC P0730 is set in D range 3rd gear between 55-80 mph. <p>NOTE: Perform this test within safe and legal limits. Check for suspected conditions modifying delays to clutch apply:</p> <ul style="list-style-type: none"> – 4th clutch seal damaged. – Excessive 4th clutch piston travel. – Defective 3–4 accumulator piston. – Causes of internal leaks. – Causes of burned clutch plates. <p>Was the problem found?</p>	Repair or replace	—
3	Check 3rd gear in “D” in winter mode. Does vehicle move?	Shift solenoid A stuck. Replace shift solenoid A.	Goto Step 4
4	<p>Check for suspected conditions modifying delays to clutch apply:</p> <ul style="list-style-type: none"> – 2nd clutch seal damaged. – Excessive 2nd clutch piston travel. – Defective accumulator piston. – Causes of internal leaks. – Check ball missing or out of location in 2nd clutch. – Seals cut, damaged or missing. – Gaskets defective. – Causes of burned clutch plates. <p>Was the problem found?</p>	Repair or replace	—

Chart 7: Harsh 1–2 Shift

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Check for 1–2 accumulator valve (320) stuck by foreign material in main case valve body.	Use Chart 15b: Possible Causes of High Line Pressure in this section.

Chart 8: Harsh 3–4 Shift

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15b: Possible Causes of High Line Pressure in this section.
2	1. Check for 3–4 accumulator valve (407) stuck in adapter case valve body (401). 2. Check for 3–4 accumulator piston (18) stuck in adapter case (20). Was the problem found?	Repair or replace	—

Chart 9a: 3–2 Downshift Complaint

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15a: Possible Causes of Low Line Pressure in this section.
2	Does DTC P1850 set?	Diagnose P1850 first.	Replace band and apply solenoid (PWM) (323).

Chart 9b: Harsh Shift When Shifting Into “D” Or Accelerating From Stop

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15b: Possible Causes of High Line Pressure in this section.
2	Does DTC P1850 set?	Diagnose P1850 first.	Replace band and apply solenoid (PWM) (323).

7A-18 AUTOMATIC TRANSMISSION (4L30-E)**Chart 9c: Coastdown Harsh Shift Or Clunk At 3-2 Downshift**

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15b: Possible Causes of High Line Pressure in this section.
2	Does DTC P1850 set?	Diagnose P1850 first.	Replace band apply solenoid (PWM) (323).

Chart 10: Intermittent 4TH TO 2ND Gear Downshift At Steady Speed

Step	Action	Yes	No
1	Check for consistent speed sensor reading with scan tool. Was the reading correct?	Replace mode switch for intermittent contact.	Go to Step 2
2	1. Check for wiring harness damage or short to ground. If OK, go to (2). 2. Check transmission speed sensor connections. If OK, go to (3). 3. Replace transmission speed sensor. Was the replacement complete?	—	Replace speed sensor.

Chart 11: Engine Flare At Shifting During Turning Only (Usually With Warm Engine)

Step	Action	Yes	No
1	Check for oil leaks at transmission. Was the problem found?	Replace transmission oil filter and gasket.	—

Chart 12: Engine Flare During 1-2 Or 2-3 Shift

Step	Action	Yes	No
1	Check line pressure. Refer to Line Pressure Test in this section. Was line pressure normal?	Go to Step 2	Use Chart 15a: Possible Causes of Low Line Pressure in this section.
2	1. Check for a stuck 1-2 accumulator valve (320). 2. Check for servo piston (106) leaks. 3. Check for a stuck band apply solenoid (323). Was line pressure normal?	Repair or replace	—

Chart 13: Shudder Only During Torque Converter Clutch (TCC) Applying

Step	Action	Yes	No
1	<p>1. TCC shudder is one of the most commonly misdiagnosed conditions in an automatic transmission. The key to diagnosing TCC shudder is to note when it happens and under what conditions. Once the TCC has been fully applied, it is nearly impossible to make it shudder. TCC shudder (short burst of noise normally less than 1 second) will only occur during clutch applying. It is not a steady state condition.</p> <p>2. Drive until whole drivetrain is at normal operating temperature.</p> <ul style="list-style-type: none"> – On 4WD vehicles, the test must be performed with transfer case selector lever in "2H" position. – Shudder is a short burst of noise normally less than 1 second in duration, and can be induced by the following maneuver: <p>3. From coast condition at 50 mph in "D" range (Normal mode), depress the throttle to 1/4-1/3 throttle. If present, shudder will occur within 5 seconds together with TCC application. (The scan tool may be used to determine the exact time of TCC).</p> <p>Was the problem found?</p>	<p>Replace transmission fluid and filter (remove both pans) and flush cooler lines.</p> <p>Replace converter assembly and O-ring on turbine shaft</p>	<p>Perform mechanical inspection of other drivetrain components.</p>

Chart 14: Possible Causes of Transmission Noise

CAUTION: Before checking transmission for what is believed to be transmission noise, ensure presence and positioning of insulating plugs, pads etc. Also make sure that noise does not come from other drivetrain components.

Condition	Possible cause	Correction
Whine or Buzz	Oil level low	Fill with ATF, check for external leaks.
	Plugged or restricted oil filter	Inspect oil filter. Replace oil filter or ATF as necessary.
	Damaged oil filter gasket	Replace oil filter gasket.
Knocking noise from front of transmission.	Loose bolts (Converter to flex plate)	Tighten to specifications.
	Cracked or broken flex plate	Replace flex plate.
	Converter damaged	Replace converter.
Knocking noise while driving, mostly on acceleration.	Transmission mount loose or broken	Tighten mount bolts or replace transmission mount.
	Cooler line mounts loose or broken	Tighten or replace cooler line mounts.
	Cooler lines touching body or frame	Repair or replace as necessary.
Knocking noise when vehicle is stationary.	Loose flex plate mounting bolts	Tighten to specifications.
	Cracked or broken flex plate	Replace flex plate.
	Damaged converter	Replace converter.

Chart 15a: Possible Causes of Low Line Pressure

Step	Action	Yes	No
1	Check oil level. Was the problem found?	Fill with ATF.	Go to Step 2
2	Check for defective throttle position sensor. Was the problem found?	Replace throttle position sensor.	Go to Step 3
3	Check for plugged, loose, or damaged oil filter (79). Was the problem found?	Inspect oil filter, tighten bolts or replace oil filter (79).	Go to Step 4
4	Check for a stuck force motor plunger (404). (Adapter case valve body) Was the problem found?	Replace force motor plunger (404).	Go to Step 5
5	Check for a stuck feed limit valve (412). (Adapter case valve body) Was the problem found?	Replace feed limit valve (412).	Go to Step 6
6	Check for loose converter bolts (4 & 5). Was the problem found?	Tighten converter bolts (4 & 5).	Go to Step 7
7	Check for a stuck pressure regulator valve (208). (Oil pump) Was the problem found?	Replace pressure regulator valve (208).	Go to Step 8
8	Check for a stuck boost valve (205). (Oil pump) Was the problem found?	Replace boost valve (205).	Go to Step 9
9	Check for blocked intermediate oil passages to pressure regulator valve. (Oil pump) Was the problem found?	Replace oil pump.	Go to Step 10
10	Check for defective oil pump (9, 201, 202 & 209). Was the problem found?	Replace oil pump.	Go to Step 11
11	Check for internal leaks. – Check balls missing or out of location in valve bodies – Seals cut or damaged – Gaskets defective, etc. Was the problem found?	Install balls, or correct ball location. Replace seals. Replace gaskets.	—

Chart 15b: Possible Causes of High Line Pressure

NOTE: If transmission is operating in backup mode, high line pressure will be present.

Step	Action	Yes	No
1	Check for defective throttle position sensor. Was the problem found?	Replace throttle position sensor.	Go to Step 2
2	Check for a stuck force motor plunger (404). (Open circuit/intermittent) (Adapter case valve body) Was the problem found?	Replace force motor plunger (404).	Go to Step 3
3	Check for a stuck feed limit valve (412). (Adapter case valve body) Was the problem found?	Replace feed limit valve (412).	Go to Step 4
4	Check converter bolts (4 & 5). Was the problem found?	Tighten converter bolts (4 & 5).	Go to Step 5
5	Check for a stuck pressure regulator valve (208). (Oil pump) Was the problem found?	Replace pressure regulator valve (208).	Go to Step 6
6	Check for a stuck boost valve (205). (Oil pump) Was the problem found?	Replace boost valve (205).	Go to Step 7
7	Check for internal leaks. – Check balls missing or out of location in valve bodies – Seals cut or missing – Gaskets defective, etc. Was the problem found?	Install balls, or correct ball location. Replace seals. Replace gaskets.	—


Chart 16: Possible Causes of Transmission Fluid Leaks

Before attempting to correct an oil leak, the actual source of the leak must be determined. In many cases, the source of the leak may be difficult to determine due to "wind flow" around the engine and transmission. The suspected area should be wiped clean before inspecting for the source of the leak.

Oil leaks around the engine and transmission are generally carried toward the rear of the vehicle by the air stream. In determining the source of an leak, the following two checks should be made:

1. With the engine running, check for external line pressure leaks.
2. With the engine off, check for oil leaks due to the raised oil level caused by drainback of converter oil into the transmission.

Possible Causes of Fluid Leaks Due To Sealing Malfunction



240RS002

Legend

- | | |
|---|--|
| (1) Electrical Connector (Main Case) Seal | (9) Oil Cooler Connectors (2) |
| (2) Transmission Vent (Breather) | (10) Oil Pan Gasket (Adapter Case) |
| (3) Speed Sensor O-ring | (11) Converter housing attaching bolts not correctly torqued |
| (4) Extension (Adapter) Lip Seal | (12) Converter Housing Lip Seal |
| (5) Extension (Adapter) to Main Case Gasket | (13) Line Pressure Tap Plug |
| (6) Oil Drain Plug Gasket | (14) Electrical Connector (Adapter Case) Seal |
| (7) Oil Pan Gasket (Main Case) | (15) Adapter Case Seal Rings (2) |
| (8) Selector Shaft Seal | |

Stall Test

The stall test allows you to check the transmission for internal abrasion and the one way clutch for slippage. Torque converter performance can also be evaluated. The stall test results together with the road test results will identify transmission components requiring servicing or adjustment.

Stall Test Procedure:

1. Check the level of the engine coolant, the engine oil, and the automatic transmission fluid. Replenish if necessary.
2. Block the wheels and set the parking brake.
3. Connect a tachometer to the engine.
4. Start the engine and allow it to idle until the engine coolant temperature reaches 70 – 80°C (158 – 176°F).

5. Hold the brake pedal down as far as it will go.

6. Place the selector in the "D" range.

7. Gradually push the accelerator pedal to the floor. The throttle valve will be fully open.

Note the engine speed at which the tachometer needle stabilizes.

Stall Speed : 2,200 ±150 rpm

NOTE: Do not continuously run this test longer than 5 seconds.

8. Release the accelerator pedal.

9. Place the selector in the "N" range.

10. Run the engine at 1,200 rpm for one minute. This will cool the transmission fluid.


11. Repeat Steps 7 – 10 for the "3", "2", "L" and "R" ranges.

Line Pressure Test

The line pressure test checks oil pump and control valve pressure regulator valve function. It will also detect oil leakage.

Line Pressure Test Procedure:

1. Check the level of the engine coolant, the engine oil, and the automatic transmission fluid.
Replenish if required.
2. Block the wheels and set the parking brake.
3. Remove the pressure detection plug at the left side of the transmission case.
Set J-29770-A pressure gauge and adapter to the pressure detection plug hole.



241RS001

4. Start the engine and allow it to idle until the engine coolant temperature reaches 70 – 80°C (158 – 176°F).
5. Hold the brake pedal down as far as it will go.
6. Place the selector in the “D” range.
7. Note the pressure gauge reading with the engine idling.
8. Gradually push the accelerator pedal to the floor. The throttle valve will be fully open.
Note the pressure gauge reading with the accelerator pedal fully depressed.

NOTE: Do not continuously run this test longer than 5 seconds.

9. Release the accelerator pedal.
10. Place the selector in the “N” range.
11. Run the engine at 1,200 rpm for one minute.
This will cool the transmission fluid.
12. Repeat Steps 7 – 11 for the “3”, “2”, “L”, and “R” ranges.
13. Install a pressure detection plug to the transmission case, applying recommended thread locking agent (LOCTITE 242) or its equivalent to thread of plug. Make sure that thread is cleaned before applying locking agents.
14. Tighten the pressure detection plug to the specified torque.

Torque: 9 – 14N·m (7 – 10lb ft)

MODE	LEVER POSITION	ENGINE SPEED	LINE PRESSURE		FORCE MOTOR CURRENT
			kPa	PSI	
NORMAL/POWER	D,3,2,L	IDLE	312–363	45.2–52.6	VARIABLE
WINTER	D	IDLE	312 – 363	45.2 – 52.6	0.9 – 1.0A
NORMAL/POWER WINTER	REVERSE	IDLE	419 – 486	60.7 – 70.5	0.9 – 1.0A
NORMAL/POWER	D, 3, 2, L	STALL SPEED	1,236 – 1320	179.3 – 191.4	0.1 – 0.2A
WINTER	D	STALL SPEED	1,236 – 1320	179.3 – 191.4	0.1 – 0.2A
NORMAL/POWER WINTER	REVERSE	STALL SPEED	1,634 – 1743	236.9 – 252.8	0.1 – 0.2A

Shift Speed Chart

Transfer gear ratio:	High: 1.000
Rear axle ratio:	4.100

“Normal mode”

Upshift

Range	Throttle opening	1 → 2 (First Gear) (Second Gear) Km/h (mph)	2 → 3 (Second Gear) (Third Gear) Km/h (mph)	3 → 4 (Third Gear) (Fourth Gear) Km/h (mph)
D (Drive)	Fully opened	52 ~ 58 (33 ~ 36)	105 ~ 111 (66 ~ 69)	158 ~ 164 (99 ~ 102)
	Half throttle	33 ~ 39 (21 ~ 24)	60 ~ 66 (37 ~ 41)	100 ~ 106 (62 ~ 66)
3 (Third)	Fully opened	52 ~ 58 (33 ~ 36)	105 ~ 111 (66 ~ 69)	—
	Half throttle	33 ~ 39 (21 ~ 24)	60 ~ 66 (37 ~ 41)	—
2 (Second)	Fully opened	52 ~ 58 (33 ~ 36)	—	—
	Half throttle	33 ~ 39 (21 ~ 24)	—	—

Downshift

Range	Throttle opening	1 ← 2 (First Gear) (Second Gear) Km/h (mph)	2 ← 3 (Second Gear) (Third Gear) Km/h (mph)	3 ← 4 (Third Gear) (Fourth Gear) Km/h (mph)
D (Drive)	Fully opened	42 ~ 48 (26 ~ 30)	93 ~ 99 (58 ~ 62)	149 ~ 155 (93 ~ 97)
	Half throttle	16 ~ 22 (10 ~ 14)	35 ~ 42 (22 ~ 26)	70 ~ 76 (43 ~ 47)
	Fully closed	13 ~ 20 (8 ~ 12)	16 ~ 22 (10 ~ 14)	28 ~ 34 (17 ~ 21)
3 (Third)	Fully opened	42 ~ 48 (26 ~ 30)	93 ~ 99 (58 ~ 62)	—
	Half throttle	16 ~ 22 (10 ~ 14)	35 ~ 42 (22 ~ 26)	—
	Fully closed	13 ~ 20 (8 ~ 12)	16 ~ 22 (10 ~ 14)	—
2 (Second)	Fully opened	43 ~ 49 (27 ~ 31)	101 ~ 107 (63 ~ 67)	—
	Half throttle	16 ~ 22 (9 ~ 13)	98 ~ 104 (61 ~ 65)	—
	Fully closed	13 ~ 20 (8 ~ 12)	85 ~ 91 (53 ~ 57)	—
L (First)	—	53 ~ 59 (33 ~ 37)	—	—

“Power mode”

Upshift

Range	Throttle opening	1 → 2 (First Gear) (Second Gear) Km/h (mph)	2 → 3 (Second Gear) (Third Gear) Km/h (mph)	3 → 4 (Third Gear) (Fourth Gear) Km/h (mph)
D (Drive)	Fully opened	52 ~ 58 (33 ~ 36)	105 ~ 111 (66 ~ 69)	180 ~ 186 (113 ~ 116)
	Half throttle	38 ~ 45 (24 ~ 28)	77 ~ 83 (48 ~ 52)	129 ~ 133 (80 ~ 84)
3 (Third)	Fully opened	52 ~ 58 (33 ~ 36)	105 ~ 111 (66 ~ 69)	—
	Half throttle	38 ~ 45 (24 ~ 28)	77 ~ 83 (48 ~ 52)	—
2 (Second)	Fully opened	52 ~ 58 (33 ~ 36)	—	—
	Half throttle	38 ~ 45 (24 ~ 28)	—	—

Downshift

Range	Throttle opening	1 ← 2 (First Gear) (Second Gear) Km/h (mph)	2 ← 3 (Second Gear) (Third Gear) Km/h (mph)	3 ← 4 (Third Gear) (Fourth Gear) Km/h (mph)
D (Drive)	Fully opened	43 ~ 49 (27 ~ 31)	96 ~ 102 (60 ~ 64)	170 ~ 176 (106 ~ 110)
	Half throttle	22 ~ 28 (14 ~ 17)	55 ~ 61 (34 ~ 38)	102 ~ 108 (63 ~ 67)
	Fully closed	13 ~ 20 (8 ~ 12)	25 ~ 31 (16 ~ 19)	48 ~ 54 (30 ~ 33)
3 (Third)	Fully opened	43 ~ 49 (27 ~ 31)	96 ~ 102 (60 ~ 64)	—
	Half throttle	22 ~ 28 (14 ~ 17)	55 ~ 61 (34 ~ 38)	—
	Fully closed	13 ~ 20 (8 ~ 12)	25 ~ 31 (16 ~ 19)	—
2 (Second)	Fully opened	43 ~ 49 (27 ~ 31)	101 ~ 107 (63 ~ 67)	—
	Half throttle	22 ~ 28 (14 ~ 17)	98 ~ 104 (61 ~ 65)	—
	Fully closed	13 ~ 20 (8 ~ 12)	85 ~ 91 (53 ~ 57)	—
L (First)	—	53 ~ 59 (33 ~ 37)	—	—

“Winter mode”

D range, winter mode ON → OFF	32 ~ 38 Km/h (20 ~ 24 mph)
-------------------------------	----------------------------

Lockup Speed Chart

Transfer gear ratio:	High: 1.000
Rear axle ratio:	4.100

D range Throttle opening 9%	Mode	Lock-Up ON			Lock-Up OFF		
		2nd Km/h (mph)	3rd Km/h (mph)	4th Km/h (mph)	2nd Km/h (mph)	3rd Km/h (mph)	4th Km/h (mph)
	Normal	79 ~ 85 (49 ~ 53)	58 ~ 64 (36 ~ 40)	69 ~ 75 (43 ~ 47)	74 ~ 80 (46 ~ 50)	49 ~ 55 (30 ~ 34)	65 ~ 71 (40 ~ 44)
	Power	79 ~ 85 (49 ~ 53)	84 ~ 90 (52 ~ 56)	84 ~ 90 (52 ~ 56)	74 ~ 80 (46 ~ 50)	76 ~ 82 (47 ~ 51)	81 ~ 87 (50 ~ 54)

Changing Transmission Fluid

There is no need to change the transmission fluid unless the transmission is used under one or more of the following heavy duty conditions.

- A. Repeated short trips
- B. Driving on rough roads
- C. Driving on dusty roads
- D. Towing a trailer

If the vehicle is used under these conditions, change the fluid every 20,000 miles (32,000 km.)

1. Place a large drain pan under the oil pan.
2. Remove the transmission oil drain screw (2) and drain fluid.
3. Tighten drain screw (2).

Torque: 38 N•m (28 lb ft)

4. Remove the transmission overfill screw (1) and fill transmission through overfill screw opening, using DEXRON®-III ATF.

NOTE: Add transmission fluid until it flows out over the overfill screw opening.

5. Let engine idle until a fluid temperature between 32°C (90°F) and 57°C (135°F) is reached.
6. Add transmission fluid until it flows out over the overfill screw opening, then close the overfill screw (1).


Torque: 38 N•m (28 lb ft)

NOTE: To prevent fluid leaks, the overfill screw and oil drain screws gasket must be replaced each time these screws are removed.

NOTE: Check transmission fluid temperature with scan tool.

7. Reset "Oil Life Monitor" data by using Tech 2.

Refer to Tech 2 OBD II Connection in Transmission Control System (4L30-E) section.



242RW003

Selector Lever

Inspection

1. Make sure that when the shifter control lever is shifted from "P" to "L", a "clicking" can be felt at each shift position. Make sure that the gear corresponds to that of the position plate indicator.
2. Check to see if the shifter lever can be shifted as shown in illustration.


P ⇄ R ⇄ N ⇄ D ⇄ 3 ⇄ 2 ⇄ L

➡ Button must be pressed.

↔ Button need not be pressed.

Removal


1. Disconnect battery ground cable.
2. Set ignition Key in "LOCK" position and selector lever in "P" position.
3. Remove transfer control lever knob.
4. Remove lower cluster assembly.



740RW021


5. Remove rear console.

C07RW009




256RW005

6. Remove center console.




256RW006

7. Remove selector lever knob and cover.



256RW020


8. Disconnect select cable.
○Refer to Select Cable in this section.
9. Disconnect shift lock cable.
○Refer to Shift Lock Cable in this section.
10. Disconnect harness connector.
11. Remove selector lever subassembly.



256RX001

Installation

1. Install selector lever subassembly.
2. Connect harness connector.
3. Connect shift lock cable.
○Refer to Shift Lock Cable in this section.
4. Connect select cable.
○Refer to Select Cable in this section.
5. Install selector lever knob and cover.



256RX002

6. Install center console.
7. Install rear console.

7A-28 AUTOMATIC TRANSMISSION (4L30-E)


8. Install lower cluster assembly.
9. Install transfer control lever knob.
10. Connect negative (-) battery cable.

11. After installation, make sure that the selector lever operates normally, and that each selector position is properly indicated. (The red mark shows through the window.)


Select Cable

Removal

1. Set selector lever in "P" position.
2. Remove transfer control lever knob, lower cluster assembly, rear console, center console, selector lever knob and cover.
 - Refer to Selector Lever in this section.
3. Disconnect inner cable by pulling projection on pin.




4. Press down claws and disconnect cable assembly.



5. Disconnect PCM harness connectors and remove nuts that fasten grommet in select cable assembly.


A07RW017

6. Disconnect inner cable.




210RW013

7. Slide sleeve and disconnect cable assembly.



A07RW062


8. Pull lock.



9. Draw select cable assembly into the interior side.


Installation

1. Set selector lever in "P" position.
2. Let out select cable transmission side end from floor hole.
3. Fit outer cable into bracket in selector lever assembly.




A07RW016

4. Set inner cable end in selector lever and push pin into selector lever hole and inner cable end.



256RW023


5. Check that lock projects.



A07RW015

6. Connect adjust end fitting attachment to the bracket on transmission.


7. Set select lever "P" position and connect inner cable to select lever.



210RW013

7A-32 AUTOMATIC TRANSMISSION (4L30-E)

8. Push lock into adjust end fitting attachment.




9. Install grommet.

10. About following installation steps, refer to Selector Lever in this section.


Shift Lock Cable

Removal

1. Set ignition key in "LOCK" position and selector lever in "P" position.
2. Remove transfer control lever knob, lower cluster assembly, rear console, center console, selector lever knob and cover.
○Refer to Selector Lever in this section.
3. Disconnect inner cable from selector lever assembly then push claw and disconnect cable assembly.




4. Disconnect lock adjust.



5. Remove instrument panel lower cover and steering column cover.


6. Remove spring pin and disconnect inner cable.
○Disconnect outer cable from bracket.



256RW008


Installation

1. Set ignition key in "LOCK" position and selector lever in "P" position.
2. Connect outer cable to bracket near steering lock.
○Connect inner cable to steering lock and install spring pin.
3. Install steering column cover and instrument lower cover.
4. Install adjust body of cable assembly to bracket in selector lever assembly.
○Install inner cable to lever, pulling inner cable with outer cable.




256RW018

5. Check that cable moves smoothly, lightly pulling outer cable rearward.



256RW019

6. Connect lock adjust, aligning "T" mark in the "Up" position.




256RW017

7. About following installation steps, refer to Select Lever in this section.
8. Check the shift lock operation:
 - a. Selector lever should not be moved out of "P" position with ignition key in "Lock" position.
 - b. Selector lever can be moved out of "P" position with ignition key in "ON" position only when brake pedal is depressed.
 - c. ignition key can be turned to "LOCK" position only when selector lever is in "P" position (key can be pulled out).
9. If a. and c. fail, readjust cable. If b. fails, readjust connector wiring and brake pedal switch.

Mode Switch

Removal

1. Place selector lever in neutral.
2. Disconnect battery ground cable.
3. Remove mode switch cover (1).
4. Disconnect selector lever (2) from the mode switch.
5. Remove bracket with cable (3).
6. Disconnect transmission harness from the mode switch connector (4).
7. Remove bracket with mode switch connector from the transmission case.
8. Remove mode switch connector (4) from the bracket (5).
9. Remove two mode switch bolts and nut then remove mode switch (6).



Installation

To install, follow the removal steps in the reverse order, noting the following points;

1. Torque

Mode switch bolt: 13 N•m (113 lb in)

Selector lever nut: 23 N•m (17 lb ft)


2. Mode switch setting procedure

Perform either of the following adjustment procedures:

Procedure 1


- a. Place selector lever in neutral.
- b. Remove selector lever from the mode switch.

- c. Remove the mode switch cover.
- d. Loosen the two 10 mm screws.
- e. Rotate the mode switch until the slot in the mode switch housing aligns with the selector shaft bushing, and insert a 3/32 in. (2.4 mm) drill bit or punch (1) into the slot.
- f. Tighten the screws to 13 N•m (113 lb in).
- g. After completing adjustment, snap the mode switch cover into place.
- h. Reinstall the selector lever.




Procedure 2

- a. Place selector lever in neutral.
- b. Disconnect transmission harness connector from mode switch connector.
- c. Remove mode switch connector with bracket from the transmission case.
- d. Connect multimeter (resistance mode) to terminals 1(E) and 4(H) on mode switch connector.
- e. Loosen two mounting screws.
- f. Rotate mode switch slightly in both directions to determine the range (approx. 5 degrees) of electrical contact.
- g. Position mode switch in middle of contact range.
- h. Tighten two mounting screws.
- i. Remove multimeter and install mode switch harness connector with bracket to the transmission case.
- j. Connect transmission harness connector to mode switch connector.



Transmission

Transmission and Associated Parts



240RW010


Legend

- | | |
|---------------------------------|-----------------------------------|
| (1) Transfer Protector (4×4) | (9) Third Crossmember |
| (2) Fairing Plate | (10) Transmission Oil Cooler Pipe |
| (3) Rear Propeller Shaft | (11) Starter |
| (4) Front Propeller Shaft (4×4) | (12) Under Cover |
| (5) Center Exhaust Pipe | (13) Transfer Control Lever (4×4) |
| (6) Full Pipe Heat Protector | (14) Select Cable |
| (7) Harness Heat Protector | (15) Torque Converter Bolt |
| (8) Rear Mount Nut | (16) Engine-Transmission Bolt |
| | (17) Transmission Assembly |

Removal



NOTE: Before remove transmission and transfer assembly from vehicle, change the transfer mode to 2WD using push button on dash panel.

1. Disconnect battery ground cable.
2. Remove transfer protector (4×4) and fairing plate.




3. Remove rear propeller shaft and front propeller shaft (4×4).

NOTE: Apply alignment marks on the flange at both front and rear sides.




4. Remove center exhaust pipe.




7A-38 AUTOMATIC TRANSMISSION (4L30-E)

5. Remove fuel pipe heat protector and clip.




6. Disconnect transmission harness connector and clip.
Connector : Adapter case, mode switch, main case, magnetic sensor, transfer switch (4×4), 2-4 actuator (4×4) and car speed sensor.

7. Remove harness heat protector.



8. Support transmission with a jack.


Remove rear mount nuts from 3rd crossmember.



9. Remove third crossmember.


10. Disconnect transmission oil cooler pipes from A/T side.

11. Remove oil pipe clamp and bracket from the converter housing.




12. Loosen oil cooler pipe clamp bolt at the engine mount side.

13. Remove select cable by disconnecting inner cable from select lever and removing outer cable with bracket.




256RW025

14. Remove starter.
15. Remove flywheel under covers from the transmission and engine.
16. Remove transfer control lever fixing bolts and push up transfer control lever.



262RW015

17. Remove flywheel-torque converter fixing bolts (6 pieces) by turning crankshaft.



240RW005

18. Remove engine-transmission fixing bolts.
19. Pull out transmission from the engine.

Installation


1. Slowly raise transmission jack until front of the transmission is aligned with rear of the engine. Join the transmission to the engine.
2. Tighten engine-transmission bolts as shown in the figure.

Exploded view diagram of the engine cover assembly. The diagram shows the following components and their dimensions:

- Clip; breather hose**: 45, 21, 27, 1.2
- T/M case**: 45, 21, 27
- Cylinder block**: 45, 21, 27
- Bracket; fuel pipe**: 50, 21, 27, 2.5
- T/M case**: 70, 32, 20
- Cylinder block**: 70, 32, 20
- 8(69lb in)**: 10, 0.9, 20
- T/M case**: 10, 0.9, 20
- Under cover**: 10, 0.9, 20
- 8(69lb in) (6 places)**: 10, 0.9, 11
- Crank case**: 10, 0.9, 11
- Under cover**: 10, 0.9, 11
- 40(30)**: 40, 25, 20
- T/M case**: 40, 25, 20
- Crank case**: 40, 25, 20
- 76(56)**: 40, 17, 27
- T/M case**: 50, 25, 30
- Cylinder block**: 50, 25, 30
- 76(56)**: 50, 25, 30
- T/M case**: 10, 0.9, 20
- Under cover**: 10, 0.9, 20

Torque : N·m (lb ft)
Length : mm

7. Install select cable by connecting inner cable to select lever and installing outer cable with bracket.




256RW025

8. Connect transmission oil cooler pipes to A/T.

Torque: 54 N•m (40 lb ft)

9. Install oil cooler pipe clamp and bracket to the converter housing.



253RW001


10. Tighten oil cooler pipe clamp bolt at the engine mount side.

11. Install third crossmember.

Torque: 50 N•m (37 lb ft)

12. Install rear mount nuts.


Torque: 50 N•m (37 lb ft)



F07RW008

13. Install harness heat protector.

Torque: 6 N•m (52 lb ft)




815RW002

14. Connect transmission harness connector and clip.

Connector : Adapter case, mode switch, main case, magnetic sensor, transfer switch, 2-4 actuator and car speed sensor.


15. Connect fuel pipe to transmission side.

7A-42 AUTOMATIC TRANSMISSION (4L30-E)




141RX001

(4×4)




240RW014

(4×2)




141RW006

16. Install fuel pipe heat protector and clip.



17. Install center exhaust pipe.


Torque: 43 N•m (32 lb ft)



18. Install front propeller shaft & rear propeller shaft.

Torque: 63 N•m (46 lb ft)



19. Install transfer protector and fairing plate.



Solenoid (Main Case Valve Body)

Removal


1. Raise the vehicle and support it on jack stands.
2. Disconnect battery ground cable.
3. Drain fluid.
4. Remove sixteen 10 mm screws, main case oil pan, magnet, and gasket.
5. Remove three 13 mm screws, oil filter.
6. Disconnect wiring harness from band control solenoid and shift solenoids. Pull only on connectors, not on wiring harness.
7. Remove spring pin for shift solenoid A, shift solenoid B, and band control solenoid respectively, using suitable pliers taking care not to damage solenoids.



8. Remove shift solenoid A, shift solenoid B, band control solenoid, and gaskets from main case valve body. Do not pull on wiring harness. Remove solenoids by grasping the metal tip.

Installation

1. Install shift solenoid A, shift solenoid B, band control solenoid with new gaskets to main case valve body respectively.
2. Carefully install spring pin with hammer to avoid damage to valve body, etc.



3. Connect wiring harness to solenoids.
4. Install oil filter with a new gasket and the three 13 mm screws, tighten to the specified torque.

Torque: 20 N•m (15 lb ft)

5. Install magnet, main case oil pan with new gasket, and sixteen 10 mm screws. Tighten the screws to the specified torque.

Torque: 11 N•m (96 lb in)

6. Fill transmission through the overfill screw hole of oil pan, using ATF DEXRON®-III, Refer to Changing Transmission Fluid in this section.
7. Connect battery ground cable.


Solenoid (Adapter Case Valve Body)

Removal

1. Raise the vehicle and support it on jack stands.
2. Disconnect battery ground cable.
3. Drain fluid.
4. Remove adapter case oil pan twelve fixing 10 mm screws, adapter case oil pan, and gasket.


NOTE: Oil pan still contains transmission fluid. Place a large drain container under the oil pan and drain the fluid carefully.

5. Disconnect wiring harness from force motor solenoid and converter clutch solenoid. Pull only on connectors, not on wiring harness.
6. Remove 11 mm bolt and converter clutch solenoid with two O-rings.



210RW011

7. Remove 11 mm bolt, retainer, and force motor solenoid.



210RW009

Installation

1. Install force motor solenoid, retainer, and 11 mm bolt to adapter case valve body. Tighten the bolt to the specified torque.

Torque: 10 N•m (87 lb in)

2. Install converter clutch solenoid with two O-rings, and 11 mm bolt to adapter case valve body. Tighten the bolt to the specified torque.

Torque : 10 N•m (87 lb in)

3. Connect wiring harness assembly to solenoids.
4. Install adapter case oil pan, new gasket, and twelve 10 mm screws. Tighten the screws to the specified torque.

Torque : 11 N•m (96 lb in)

5. Fill transmission through overfill screw hole oil pan, using ATF DEXRON®-III, Refer to Changing Transmission Fluid in this section.
6. Connect battery ground cable.


Valve Body Assembly (Main Case)

Removal

1. Raise the vehicle and support it on jack stands.
2. Disconnect battery ground cable.
3. Drain fluid.
4. Remove sixteen 10 mm screws, main case oil pan, magnet and gasket.
5. Remove three 13 mm oil filter fixing screws, then remove oil filter.
6. Remove two 13 mm manual detent fixing screws, then remove roller and spring assembly.
7. Disconnect wiring harness from band control solenoid and shift solenoids. Pull only on connectors, not on wiring harness.
8. Remove four 13 mm servo cover fixing screws, then remove servo cover and gasket.
9. Remove seven 13 mm valve body fixing screws.
 - Disconnect ground wire from the main case valve body.
10. Remove main case valve body with manual valve link and transfer plate. Note the position of the link (long end into valve, short end into range selector lever).
11. Remove transfer plate gasket from main case.
12. Remove two check balls from main case.

Installation

1. Install two check balls to main case.




2. Inspect electrical 4 pin connector and seal of main case. Replace if necessary.
3. Use two J-25025-B guide pin to install main case.
 - Install valve body complete assembly and manual valve link.

NOTE: Valve must be extended as the short end of manual valve link is connected to the range selector lever. Long end of link goes into valve.


4. Install seven 13 mm screws, and tighten them to the specified torque.

Torque: 20 N•m (15 lb ft)



5. Install 8.5 mm connector of ground wire under the head of this valve body bolt and reinstall it. Tighten the bolt to the specified torque.

Torque: 20 N•m (15 lb ft)



6. Remove two guide pins from main case.
7. Install servo cover gasket, cover, and four 13 mm screws. Tighten the screws to the specified torque.

Torque: 25 N•m (18 lb ft)

8. Connect wiring harness to band control and shift solenoids.
9. Install roller and spring assembly to manual detent.
 - Install two 13 mm screws, and tighten them to the specified torque.

Torque: 20 N•m (15 lb ft)

10. Install oil filter and three 13 mm screws. Tighten to the specified torque.

Torque : 20 N•m (15 lb ft)

11. Install oil pan gasket, magnet, oil pan and sixteen 10 mm screws. Tighten the screws to the specified torque.

Torque: 11 N•m (96 lb in)

12. Fill transmission through overfill screw hole of oil pan, using ATF DEXRON®-III., refer to Changing Transmission Fluid in this section.

13. Connect battery ground cable.

Valve Body Assembly (Adapter Case)

Removal

1. Raise the vehicle and support it on jack stands.
2. Disconnect battery ground cable.
3. Drain fluid.
4. Remove twelve 10 mm adapter case oil pan fixing screws, adapter case oil pan, and gasket.

NOTE: Oil pan still contains transmission fluid. Place a large drain container under the oil pan.

Drain the fluid carefully.

5. Disconnect wiring harness from force motor solenoid and converter clutch solenoid. Pull only on connectors, not on wiring harness.
6. Remove seven 13 mm screws from adapter case valve body assembly, then remove transfer plate, two gaskets, and adapter case valve body.

Installation

1. Inspect electrical 5 pin connector and seal of adapter case. Replace if necessary.
2. Install gasket, transfer plate, and gasket.
3. Install adapter case valve body and seven 13 mm screws. Tighten the screws to the specified torque.

Torque: 20 N•m (15 lb ft)

4. Connect wiring harness assembly to converter clutch solenoid and force motor.
5. Install oil pan gasket, oil pan, and twelve 10 mm screws. Tighten the screws to the specified torque.


Torque: 11 N•m (96 lb ft)

6. Fill transmission through the overfill screw hole of oil pan, using ATF DEXRON®-III, refer to Changing Transmission Fluid in this section.
7. Connect battery ground cable.

Powertrain Control Module (PCM)

Removal

1. Disconnect battery ground cable.
2. Remove transfer control lever knob, lower cluster assembly, center console and front console.
3. Disconnect PCM wiring harness connectors from PCM.
4. Remove four PCM retaining screws.
5. Remove two brackets from PCM.



828RW003

Installation

1. Install two brackets to PCM.
2. Install four PCM retaining screws.
3. Connect PCM wiring harness connectors to PCM.
4. Install center console, rear console, lower cluster assembly and transfer control lever knob.
5. Connect battery ground cable.

Speed Sensor (Extension Housing)

Removal

1. Disconnect battery ground cable.
2. Raise the vehicle and support it on jack stands.
3. Disconnect speed sensor harness connector from speed sensor.
4. Remove one 10 mm screw and speed sensor with O-ring.

Installation

1. Inspect the speed sensor O-ring, and replace it if necessary.
2. Install speed sensor assembly and 10 mm screw.
Torque: 9 N•m (78 lb in)
3. Connect speed sensor harness connector to speed sensor.
4. Connect battery ground cable.

Transmission Oil Temperature Sensor (Adapter Case)

Removal

1. Raise the vehicle and support it on jack stands.
2. Disconnect battery ground cable.
3. Drain fluid.
4. Remove twelve 10 mm adapter case oil pan fixing screws, adapter case oil pan, and gasket.

NOTE: Oil pan still contains transmission fluid. Place a large drain container under the oil pan and drain the fluid carefully.


5. Disconnect wiring harness from force motor solenoid, converter clutch solenoid, and 5 pin connector of adapter case. Pull only on connectors, not on wiring harness.
6. Disconnect ground wire from converter clutch solenoid wiring harness connector.
7. Remove wiring harness assembly (transmission oil temperature sensor).

Installation

1. Connect ground wire to converter clutch solenoid wiring harness connector of the wiring harness assembly.
2. Install wiring harness assembly to converter clutch solenoid, force motor, and 5 pin connector of adapter case.
3. Install oil pan gasket, oil pan and twelve 10 mm fixing screws. Tighten the screws to the specified torque.

Torque: 11 N•m (96 lb ft)

4. Fill transmission through the overfill screw hole of oil pan, using ATF DEXRON®-III.
Refer to Changing Transmission Fluid in this section.
5. Connect battery ground cable.




243RW002

Front Oil Seal (Converter Housing)

Removal

1. Remove transmission assembly from the vehicle ,refer to Transmission in this section.
2. Remove torque converter from converter housing.
3. Remove three screws and oil seal ring from converter housing.



Installation

1. Apply clean ATF to the new oil seal ring lip.
○ Install oil seal ring to converter housing, tighten to the specified torque.


Torque: 3 N•m (26 lb in)

2. Install torque converter to converter housing.
3. Install transmission assembly case to the vehicle, refer to Transmission in this section.

Rear Oil Seal (Extension Housing)

Removal

1. Remove transfer case assembly from the vehicle. Refer to Transfer Case in Drive Line/Axle section.
2. Remove rear oil seal from transmission extension housing.



Installation

1. Use J-36797 extension housing oil seal installer, and install the rear oil seal to the transmission extension housing.
2. Install the transfer case assembly to the vehicle. Refer to Transfer Case in Drive Line/Axle section.

Transmission (4L30-E)

Disassembly

NOTE: During the disassembly and reassembly, perform the following:


- Wash each part thoroughly, and blow air through each oil passage and groove to eliminate blockage.
- Seal rings, roll pins, and gaskets should be replaced.
- When assembling the components, apply DEXRON®-III Automatic Transmission Fluid (ATF) to each seal, rotating part, and sliding part.
- Do not dip part facings, such as clutch or brake drive plates, in cleaner when washing it.
Also, always coat parts with new ATF two or three times after cleaning with solvent.

1. Remove torque converter (1).

- Drain fluid from torque converter.

- Attach J-8763-02 holding fixture to the transmission and set it on J-3289-20 holding fixture base.


NOTE: Do not overtighten the tool, as case damage may result.



420RW021

2. Remove O-ring (2) from turbine shaft.
3. Remove two 10mm mode switch screws, selector lever nut, cover, and mode switch (3).
4. Remove twelve 10mm adapter case oil pan (4) fixing screws, adapter oil pan, and gasket.
5. Disconnect electrical wiring connections (5) from solenoids and 5 pin connector of adapter case. Pull on connectors only, not on wiring harness.
6. Remove seven 13mm adapter case valve body (6) fixing screws, adapter case valve body assembly, transfer plate, and two gaskets.
 - Remove wiring harness and 5 pin connector.
7. Remove sixteen 10mm main case oil pan (7) fixing screws, main oil pan, magnet, and gasket.
8. Remove three 13mm oil filter (8) fixing screws and oil filter.
9. Remove two 13mm manual detent (9) fixing screws, roller and spring, and manual detent.
10. Disconnect wiring harness assembly (10) from band apply solenoid, shift solenoids, and main case 4 pin connector.
Pull on connectors only, not on wiring harness.
11. Remove four 13mm servo cover (11) fixing screws, servo cover, and gasket.
12. Remove seven 13mm valve body screws and ground wire from main case.
 - Remove wiring harness assembly (5) from the adapter case side.
 - Remove main valve body assembly (12) with manual valve link and transfer plate. Note the position of the link (long end into valve, short end into range selector lever).
 - Remove 4 pin connector.
 - Remove gasket transfer plate from main case.
13. Remove two check balls (13) from main case.

240RW022



16. Rotate transmission to horizontal position, pan side down.

○Remove one 10mm screw, and speed sensor (18) with "O" ring.

17. Remove seven 8mm extension housing hexagon socket head screws, extension housing assembly (19), and gasket.

18. Remove retaining ring (20). (4x4)


NOTE: Use extra long, needle nose pliers.

○Remove flange nut (20). (4x2)

○Remove flange and O-ring (20). (4x2)

19. Remove speed wheel (21).

20. Remove wheel parking lock (with seal ring) (22).



21. Rotate transmission to vertical position, converter housing up.


○Loosen the converter housing and oil pump assembly fixing screws, but do not remove, the five 13 mm inner screws unless oil pump disassembly is required.

○Remove seven outer screws.

○Remove converter housing and oil pump assembly (23).


22. Remove gasket (24).

23. Remove selective thrust washer (25).



241RW004


24. Remove fourth clutch retainer (26).
25. Grasp turbine shaft and lift out the overrun clutch housing assembly (27) and fourth clutch plates (28).
26. Remove thrust bearing assembly (29).
27. Remove overdrive internal gear (30).
28. Remove thrust washer (31).



252RS001

29. Remove adapter case and center support assembly (with fourth clutch piston) (32).
30. Remove seal ring (33).
31. Remove selective thrust washer (34) and two O-ring seals (35) from main case.
32. Use J-23327 and J-23327-90 compressor to compress the fourth clutch spring retainer and springs (37).
 - Release snap ring (36) from groove.
 - Remove clutch compressor and snap ring (36).
33. Remove retainer and spring assembly (37).
34. Insert two converter housing/main case screws to hold adapter case while pulling out fourth clutch piston (38).
 - Remove fourth clutch piston assembly (38) from the adapter case.
 - Remove converter housing/main case screws.
35. Grasp intermediate shaft, twist and pull out the second and third clutch drum assemblies with reverse clutch plates while holding onto output shaft (39).

36. Separate second (40) and third clutch (41) assemblies.
37. Remove thrust washer (42).
38. Remove reverse clutch plates (43 and 44) and reverse clutch pressure plate (45).
39. Remove bearing (46) and washer (47).
40. Remove planetary carrier assembly (48).
41. Remove thrust bearing (49).
42. Remove reaction sun gear (50)
43. Remove needle bearing (51).
44. Remove brake drum (52).
45. Remove brake band (53).
46. Remove thrust bearing (54).




47. Rotate case to horizontal position, valve body side facing up.
 - Remove spring pin (55), using cutting pliers, then remove parking lock and selector lever assembly (56).

NOTE: Insert wire in the center of the spring pin to prevent it from collapsing during removal. Be aware of pin height. Protect machined face of main case.

48. Remove parking lock and range selector lever 17 mm nut (57).
49. Remove parking lock and range selector lever (56), and actuator assembly.
50. Remove selector shaft (58).

NOTE: Inspect the shaft for burrs before removing to prevent damaging seal. If necessary, remove burrs by lightly sanding with an oilstone.



249RS004

Reassembly

1. Inspect selector shaft seal and replace it if necessary.


NOTE: Use a seal installer when replacing the seal.

- Install selector shaft.

NOTE: Spring pin groove must be positioned inside the case.

2. Install spring pin. Be sure the selector shaft can move freely. Do not push the pin flush with the case surface. Leave enough height for removal.
3. Install actuator assembly (1).
4. Install parking lock and range selector lever (2) and new 17 mm nut. Tighten the nut to the specified torque.

Torque: 22 N•m (16 lb ft)



5. Rotate main case to vertical position, extension end facing down.

○ Install brake band assembly (3).

NOTE: Be sure to align servo pin area with the servo hole.

6. Install thrust bearing (4).

NOTE: The case bushing acts as a guide for the thrust bearing.

7. Install brake drum (5).

8. Install reaction sun gear (6).


9. Install needle bearing (7).

10. Inspect planetary carrier assembly (8) for wear and damage. If necessary replace it.

○ Measure pinion end play clearance with a feeler gauge.

Clearance: 0.13mm–0.89mm (0.005 in–0.035 in)

If clearance is outside specified value, replace the planetary carrier assembly.



11. Install the thrust bearing (9) on the output shaft.


NOTE: Use petroleum jelly to hold the thrust bearing in place.

12. Align planetary pinions. Each pinion is marked with double points to indicate the master tooth space and exactly opposite with a single point to indicate the master tooth. The markings on the planetary carrier consist of double lines which are to be lined up with the double points on two opposite pinions; the single lines are to be lined up with the single points on the other two pinions.

○ After all four pinions are lined up, slide on the third clutch assembly. Rotate third clutch and check mark alignment. Considering that the ring gear tooth between the double points of one planetary pinion is tooth number 1, count the teeth to check that the single points on the two adjacent pinions are between teeth 23 and 24 of the ring gear, and that the ring gear tooth between the double points of the opposite pinion is tooth number 46. If the ring gear and pinions are not lined up, remove and realign them.

13. Install planetary carrier (8) with third clutch (12).


NOTE: Do not force. When properly aligned, the parts will fit together easily.



14. Remove the third clutch (12).

15. Install bearing (11) and washer (10).

NOTE: Use petroleum jelly to hold the washer and bearing in place.




16. Carefully align the second clutch plate inner tangs.


- Install thrust washer, tangs pointing downward, and locating tang positioned in slot on second clutch hub.

NOTE: Use petroleum jelly to hold thrust washer in place.

- 17. Install third clutch and intermediate shaft assembly (13) into the second clutch drum (14).
- 18. Install second and third clutch assemblies into the main case. Twist output shaft and clutch assemblies to ensure proper fit.



- 19. Install pressure plate (15) with lip side up, tang facing valve body face.
- 20. Install reverse clutch plates. Start with a steel plate (17) and alternate with a lined plate (16).
- 21. Install waved clutch plate (18) with center tang facing valve body side.





22. Second clutch end play measurement

- 1. Install the J-23085-A Selective washer gauging tool (with spacer ring) on the case flange and against the intermediate shaft.
- 2. Position the inner shaft of the gauging tool against the thrust surface of the second clutch hub.
- 3. Tighten thumb screw. Remove the tool.
- 4. Fit the spacer ring on the inner shaft of the tool.

7A-58 AUTOMATIC TRANSMISSION (4L30-E)


5. Measure the gap and select appropriate washer as shown in the chart.

Selective Thrust Washer	
Gap: mm(in)	Color
1.53 – 1.63 (0.060 – 0.064)	Yellow
1.72 – 1.82 (0.068 – 0.072)	Red
1.91 – 2.01 (0.075 – 0.079)	Black
2.10 – 2.20 (0.083 – 0.087)	Natural
2.29 – 2.39 (0.090 – 0.094)	Green
2.48 – 2.58 (0.098 – 0.102)	Blue
FOLLOWING THE PROCEDURE SHOULD RESULT IN FINAL END-PLAY FROM 0.36 mm TO 0.79 mm (0.014 in TO 0.031 in)	



23. Inspect fourth clutch piston seals and replace if necessary.


- Lubricate J-38554 fourth clutch piston fitter and install it on fourth clutch piston (19).
- Install fourth clutch piston (19) in adapter case (20).
- Remove fitter.




24. Install retainer and spring assembly (22) into fourth clutch piston (21).

25. Install snap ring (23) in adapter case.

- Install J-23327 and J-23327-90 fourth clutch spring compressor.
- Seat snap ring in groove.
- Remove compressor.




252RW002



252RS004


26. Install selective washer using petroleum jelly.
27. Install two O-ring seals (24) in main case and adapter case/main case seal ring (25).
28. Install J-38588 guide pins.
 - Install adapter case and center support assembly to main case.



242RS004

29. Install thrust washer (26) into adapter case, with tangs pointing downwards.
 30. Preassemble overdrive internal gear (27) and thrust bearing assembly (28) onto the turbine shaft and overrun clutch assembly.
- NOTE: Install bearing assembly, black side up. Use petroleum jelly to keep assembly in place.
31. Install overdrive carrier (30) and internal gear assembly into adapter case.
 32. Install fourth clutch plates (29) in the following order: Steel, Lined, Steel, Steel, Lined, Steel. Steel plates go in with short tang facing towards valve body surface.
 33. Install fourth clutch retainer (31) with the notch facing up and positioned towards valve body surface.

7A-60 AUTOMATIC TRANSMISSION (4L30-E)




252RW004


34. Overdrive clutch end play measurement

1. Install the J-23085-A selective washer gauging tool on the adapter case flange and against the input shaft.
2. Position the inner shaft of the tool against the thrust surface of the overrun clutch housing.
3. Tighten thumb screw. Remove the tool.
4. Measure gap. Select appropriate size washer as shown in the chart.
5. Set selective thrust washer aside.

Selective Thrust Washer	
Gap: mm(in)	Color
1.53 – 1.63 (0.060 – 0.064)	Yellow
1.72 – 1.82 (0.068 – 0.072)	Red
1.91 – 2.01 (0.075 – 0.079)	Black
2.10 – 2.20 (0.083 – 0.087)	Natural
2.29 – 2.39 (0.090 – 0.094)	Green
2.48 – 2.58 (0.098 – 0.102)	Blue
FOLLOWING THE PROCEDURE SHOULD RESULT IN FINAL END-PLAY FROM 0.1 mm TO 0.8 mm (0.004 in TO 0.03 in)	



252RS005



252RS006

35. Install selective washer (32).

NOTE: Use petroleum jelly to hold selective washer in place.


36. Install gasket (33).

37. Install converter housing and oil pump assembly (34) to adapter case.

○Fit and tighten seven outer 13 mm screws.

Torque: 39 N•m (29 lb ft)

- Ensure free rotation of pump using J-23082-01 pump rotation tool.




38. Overdrive clutch end play measurement.

1. Fit J-25022 and J-24773-1 turbine shaft puller on turbine shaft.
2. Position axial play checking tool on converter housing mating face.
3. Pull turbine shaft upwards with puller until first resistance is met. (due to weight of overdrive assembly)
4. Maintain shaft in this position and set indicator to zero.
5. Pull turbine shaft further upwards with puller. Read end play shown on indicator.

End play: 0.1mm – 0.8mm (0.004 in – 0.031in)

6. Remove axial play checking tool and puller.

NOTE: If end play is not correct, repeat selective washer selection.



39. Inspect extension housing oil seal and replace if necessary, using J-36797 extension housing oil seal installer.

- Rotate transmission to horizontal position, with valve body side down.
- Inspect parking wheel seal ring. Replace if necessary.
- Install wheel parking lock assembly (35).

40. Install speed wheel (36) and snap ring (37). (4×4)

NOTE: Use extra long, needle nose pliers.

Install flange, O-ring and nut. (4×2)

41. Install gasket onto extension assembly with a thin coating of oil.



- Install extension housing assembly (38), and align parking pawl shaft.
- Install actuator assembly into extension assembly.
- Install seven 8 mm hexagon socket head screws.

Torque: 32 N•m (24 lb ft)

42. Inspect speed sensor O-ring. Replace if necessary.

- Install speed sensor assembly (39) and 10 mm screw.

Torque: 9 N•m (78 lb in)




43. Main case end play measurement.

1. Attach axial play checking tool on the extension housing and set indicator to zero on output shaft.
2. Manually push output shaft upwards.

End play: 0.36mm – 0.80mm (0.014 in – 0.031in)

3. Remove axial play checking tool.
4. If end play is not correct, repeat selective washer selection.




44. Inspect servo piston seal ring. Replace if necessary.


- Ensure brake band is correctly positioned. Rotate output shaft if necessary.
- Install J-38428 servo piston fitter in servo bore.
- Install apply rod (40), round end toward band, return spring (41) and piston assembly (42).

45. Install the J-23075 servo spring compressor with offset to rear of case.

- Compress servo piston seal ring, using fitter while tightening the tool screw.
- Install servo piston retaining ring (43).
- Remove tool.
- Adjust the brake band by tightening the servo adjusting screw to 4.5 N·m torque. Be certain the lock nut is loose, then back-off the screw five turns exactly. Hold piston sleeve with wrench and tighten lock nut to 18.5 N·m torque. Be certain the adjusting screw does not turn.



46. Install two check balls (44).



47. Inspect main case electrical connector and seal, replace if necessary.

- Install electrical 4 pin connector/main case and wiring harness.

48. Install two J-25025-B guide pins into main case.

- Install main case valve body complete assembly (45) and manual valve link.

NOTE: Valve must be extended as the short end of manual valve link is connected to the range selector lever. Long end of link goes into valve.


- Install seven 13 mm screws, tighten the specified torque.

Torque: 20 N•m (15 lb ft)

- Pass ground wire of adapter case wiring harness assembly through the hole joining adapter fluid area and main case fluid area.

- Assemble 8.5 mm connector of ground wire under the head of this valve body bolt and reinstall it.

- Remove two guide pins.



49. Install servo cover gasket, cover (46) and four 13 mm screws.

Torque: 25 N•m (18 lb ft)

50. Connect wiring harness (47) to band control, shift solenoids, and main case 4 pin connector.

51. Install manual detent roller and spring assembly (48) with clip.

- Install two 13 mm screws.

Torque: 20 N•m (15 lb ft)

52. Install oil filter (49) and three 13 mm screws.

Torque: 20 N•m (15 lb ft)

53. Install oil pan gasket, magnet, main oil pan (50), sixteen 10 mm screws.

Torque: 11 N•m (96 lb in)

54. Inspect adapter case electrical connector and seal. Replace if necessary.

- Install electrical five pin connector and harness assembly (52) in bottom of adapter case.

55. Install gasket, transfer plate, and gasket.

- Install adapter case valve body (51) complete and seven 13 mm screws.

Torque: 20 N•m (15 lb ft)

7A-64 AUTOMATIC TRANSMISSION (4L30-E)

56. Connect wiring harness assembly (52) to converter clutch solenoid, force motor, and 5 pin connector.

57. Install oil pan gasket, adapter case oil pan (53), and twelve 10 mm screws.

Torque: 11 N•m (96 lb in)

○Rotate transmission, with bottom pan facing down.

58. Install mode switch (54), two 10 mm screws, selector lever nut, and cover.

10 mm screw

Torque: 13 N•m (113 lb in)

Nut

Torque: 23 N•m (17 lb ft)

○Adjust using setting tool, refer to Mode Switch in this section.

59. Install O-ring (55) on turbine shaft.


60. Install torque converter (56)

The converter assembly must be replaced under any of the following conditions:

- Evidence of damage to the pump assembly.
- Metal particles are found after flushing the cooler lines.
- External leaks in hub weld area.
- Converter pilot broken, damaged, or poor fit into crankshaft.
- Converter hub scored or damaged.
- Internal failure in stator.
- Contamination from engine coolant.
- Excess end play.


○Rotate transmission, bell housing up. Spin converter to insure proper fit.

61. Fill transmission through the overfill screw hole of oil pan, using ATF DEXRON®-III. Refer to Changing Transmission Fluid in this section.



Converter Housing and Oil Pump Assembly

Disassembled View



241RW003

Legend

- | | |
|-----------------------|-----------------------|
| (1) Converter Housing | (4) Wear Plate |
| (2) Outer Seal Ring | (5) Oil Pump Assembly |
| (3) Gasket | (6) Oil Seal Ring |

Disassembly

1. Remove oil pump assembly from converter housing.
2. Remove outer seal ring.
3. Remove gasket.
4. Remove wear plate.
5. Remove oil seal ring.

Inspection and Repair


Visual Check:

If any damage, deformation, or local wear is found in a converter housing, outer seal ring, wear plate, or oil seal ring, replace it.

Reassembly

1. Install wear plate onto oil pump assembly.
2. Install converter housing onto complete oil pump assembly. Align with two short J-38588 guide pins on outer bolt holes.
 - Loosely install five 13mm bolts.
 - Center converter housing using J-38557 centering tool.
 - Tighten five inner 13mm bolts in an alternating pattern.

Torque: 20 N•m (15 lb ft)



241RW002


3. Install oil seal ring (3 screws).

Torque: 3 N•m (26 lb in)

4. Install gasket.
5. Install outer seal ring.

Oil Pump

Disassembled View



241RS014

Legend

- | | |
|------------------------------------|---|
| (1) Oil Pump Drive Gear | (10) Throttle Signal Accumulator Piston |
| (2) Oil Pump Driven Gear | (11) Sleeve Pin |
| (3) Pin | (12) Sleeve |
| (4) Plug | (13) Boost Valve |
| (5) Spring | (14) Spring Seat |
| (6) Converter Clutch Control Valve | (15) Valve Spring |
| (7) Snap Ring | (16) Spring Seat |
| (8) Spring Seat | (17) Pressure Regulator valve |
| (9) Spring | (18) Oil Pump Assembly |

Disassembly

1. Remove oil pump drive gear (1) and driven gear (2).
2. Remove pin (3) from oil pump assembly (18).
3. Remove plug (4), spring (5), and converter clutch control valve (6).
4. Remove snap ring (7) from oil pump assembly (18).
5. Remove spring seat (8), spring (9), and throttle signal accumulator piston (10).
6. Remove sleeve pin (11) from oil pump assembly (18).
7. Remove sleeve (12), boost valve (13), spring seat (14), valve spring (15), spring seat (16), and pressure regulator valve (17).

Inspection and Repair

Visual Check:


If any damage, deformation or wear is found, replace the damaged part.

Reassembly

1. Lubricate and preinstall pressure regulator spring seat (16) on valve (17), with the flat side against shoulder.
2. Install pressure regulator valve (17) and spring seat (16) assembly, valve spring (15), and spring seat (14) with the flat side away from spring to oil pump assembly (18).
3. Assemble boost valve (13) into sleeve (12).
4. Install boost valve and sleeve assembly, and sleeve pin (11) to oil pump assembly (18).
5. Install throttle signal accumulator piston (10), spring (9), and spring seat (8), with the flat side away from the spring, and snap ring (7) to oil pump assembly (18).
6. Install converter clutch control valve (6), spring (5), plug (4), and pin (3) to oil pump assembly (18).
7. Install oil pump driven gear (2) and drive gear (1).

Main Case Valve Body

Disassembled View



244RS010

Legend

- | | |
|--------------------------------|------------------------------------|
| (1) Gaskets and Transfer Plate | (15) Spring |
| (2) Manual Valve | (16) Spring Pin |
| (3) Band Control Solenoid | (17) Plug |
| (4) Pin | (18) Spring |
| (5) Waved Washer | (19) Low Pressure Control Valve |
| (6) Spring Pin | (20) Spring Pin |
| (7) Solenoid A | (21) Plug |
| (8) Retainer | (22) Band Control Screen Assembly |
| (9) 1-2/3-4 Shift Valve | (23) Spring Pin |
| (10) Spring | (24) Plug |
| (11) Spring Pin | (25) 1-2 Accumulator Valve |
| (12) Solenoid B | (26) 1-2 Accumulator Control Valve |
| (13) Retainer | (27) Check ball |
| (14) 2-3 Shift Valve | (28) Main Case Valve Body |

Disassembly

1. Remove two 11mm bolts from valve body (28), then remove gaskets and transfer plate (1).
2. Remove manual valve (2).
3. Push in band control solenoid (3) to compress waved washer (5), and remove pin (4).
4. Remove band control solenoid (3) and waved washer (5).
5. Remove spring pin (6) with a 3 mm dia. punch.
6. Remove solenoid A (7) by grasping the metal tip. Do not grasp the connector housing.
7. Remove retainer (8), 1-2/3-4 shift valve (9) and spring (10).
8. Remove spring pin (11) with a 3 mm dia. punch.
9. Remove solenoid B (12) by grasping the metal tip. Do not grasp the connector housing.
10. Remove retainer (13), 2-3 shift valve (14), and spring (15).
11. Remove spring pin (16), plug (17), spring (18) and low pressure control valve (19).
12. Remove spring pin (20), plug (21), and band control screen assembly (22).
13. Remove spring pin (23), plug (24), 1-2 accumulator valve (25), and 1-2 accumulator control valve (26).
14. Remove 1 check ball (27) from valve body (28).

Inspection and Repair

Inspect for the following, and replace any damaged or worn parts:


1. Damage or wear to each valve.
2. Damage in oil passages.
3. Cracks or damage to valve body.
4. Valve operations.
5. Spring fatigue.

Reassembly

1. Install 1-2 accumulator control valve (26), 1-2 accumulator valve (25), plug (24), and spring pin (23).
2. Install band control screen assembly (22), plug (21), and spring pin (20).
3. Install low pressure control valve (19), spring (18), plug (17), and spring pin (16).
4. Install spring (15), 2-3 shift valve (14), retainer (13), solenoid B (12), and spring pin (11).
5. Install spring (10), 1-2/3-4 shift valve (9), retainer (8), solenoid A (7), and spring pin (6).
6. Install waved washer (5), band control solenoid (3), and pin (4).
7. Install manual valve (2).
8. Install check ball (27) to valve body (28).
9. Install gasket (valve body/transfer plate) and transfer plate using two J-3387-2 guide pins.

○ Install two 11mm bolts.

Torque: 13 N•m (113 lb in)




244RS004

○ Install gasket (transfer plate/main case).

Adapter Case Valve Body

Disassembled View



243RW001

Legend

- | | |
|--|----------------------------------|
| (1) Converter Clutch Solenoid Assembly | (8) Spring |
| (2) Retainer | (9) Retaining Ring |
| (3) Force Motor Solenoid | (10) Feed limit Valve |
| (4) Retainer | (11) Plug Retainer |
| (5) Plug | (12) O-ring |
| (6) 3/4 Accumulator Valve | (13) Plug |
| (7) 3/4 Accumulator Control Valve | (14) Force Motor Screen Assembly |
| | (15) Adapter Case Valve Body |

Disassembly

1. Remove 11mm bolt from valve body.
 - Remove converter control solenoid assembly (1).
2. Remove 11mm bolt and retainer (2) from valve body.
 - Remove force motor solenoid (3).
3. Remove retainer (4), plug (5), 3/4 accumulator valve (6), and 3/4 accumulator control valve (7)
4. Remove spring (8), retaining ring (9), and feed limit valve (10).
5. Remove plug retainer (11), O-ring (12), plug (13), and force motor screen assembly (14).
 - Use 5 mm bolt to pull plug.

Inspection and Repair

Inspect for the following, and replace any damaged or worn parts:

1. Damage or wear to each valve.
2. Damage in oil passages.
3. Cracks or damage to valve body.
4. Valve operations.
5. Spring fatigue.

Reassembly

1. Install force motor screen assembly (14), plug (13), O-ring (12), and plug retainer (11).
2. Install feed limit valve (10), retaining ring (9), and spring (8).

7A-70 AUTOMATIC TRANSMISSION (4L30-E)

3. Install 3/4 accumulator control valve (7), 3/4 accumulator valve (6), plug (5), and retainer (4).

4. Install force motor solenoid (3).

○Place solenoid terminals pointing towards mating face.

○Install retainer (2) and bolt.

Torque: 10 N•m (87 lb in)


5. Install converter clutch solenoid assembly with two O-rings (1) to valve body.

○Install bolt.

Torque: 10 N•m (87 lb in)

Third Clutch and Sprag Unit

Disassembled View




248RW001

Legend

- | | |
|--|---------------------------------------|
| (1) Retaining Ring | (5) Thrust Washer |
| (2) Input Sun Gear and Sprag Unit Assembly | (6) Clutch Plates |
| (3) Retaining Washer | (7) Third Clutch Spring Cushion Plate |
| (4) Bearing | (8) Third Clutch Drum Assembly |

Disassembly

1. Place the third clutch drum and intermediate shaft assembly upright, using the overdrive internal gear as a support.
2. Locate the ends of the retaining ring. Depress one end of the ring using a small screwdriver instead of the depressor handle provided with the tool J-38450-A. Slide one blade down between the third clutch drum and the retaining ring.
3. Remove a screwdriver and repeat this step for the other end of retaining ring.
4. Install the remaining four blades approximately (five) notches apart using a screwdriver to depress the retaining ring.
5. Pull up on input sun gear and sprag unit assembly (1 and 2) to release the retaining ring from third clutch drum assembly (8).
6. Remove the tool blades.



248RX001

7. Remove retaining washer (3), bearing (4), thrust washer (5), and clutch plates (6 and 7) from the third clutch drum assembly (8).

Inspection and Repair

Visual Check:


If any damage, deformation or wear is found, replace the damaged part.

Reassembly

1. Place third clutch drum and intermediate shaft assembly upright, using the overdrive internal gear as a support.
2. Install third clutch spring cushion plate (7), bevel face down.
3. Install third clutch plates (6) into third clutch drum assembly (8). Start with the steel clutch plate and alternate with lined plates.
4. Install thrust washer (5), bearing (4) and retaining washer (3).
5. Fully engage the hub spline of the input sun gear and sprag unit assembly (2) into the third clutch inner tangs.
 - Simultaneously rotate the outer sprag race to engage into the third clutch drum assembly (8).

6. Place J-38450-A blades between the retaining ring and the third clutch drum approximately (five) notches apart, and one blade at each end of the retaining ring (1). Push down on sprag assembly until the assembly is seated into the third clutch drum assembly (8).


7. Remove the tool blades and engage retaining ring into groove of third clutch drum.



24BRX002

Third Clutch

Disassembled View



24BRX006

Legend


- | | |
|--------------------|-----------------------|
| (1) Retaining Ring | (3) Springs |
| (2) Spring Seat | (4) Piston Assembly |
| | (5) Third Clutch Drum |

Disassemble

1. Compress spring seat using the J-23075 spring compressor and J-23075-12 adapter tool.

NOTE: Do not overstress the springs and seat. This will cause damage to the spring seat.

- Remove the tool.
- Remove retaining ring (1).



2. Release the spring seat (2).

NOTE: Do not let the spring seat catch in the ring groove.

- Remove spring seat (2) and springs (3).
3. Remove piston assembly (4) from third clutch drum (5).

Inspection and Repair

Visual check:

If any damage, deformation or wear is found, replace the damaged part.


Operation check:

Shake the piston and listen for check ball movement. Movement indicates proper check ball operation. Replace the piston if the check ball is missing or falls out.

Reassembly

1. The lip of the piston seal must point toward the front of the transmission. Lubricate the seal lip with transmission fluid.

- Install piston assembly (4) into the third clutch drum (5). Use the J-23084 third clutch piston installer to protect the outer seal during installation.
- Remove the seal installer.



2. Install twelve springs (3) and spring seat (2).

3. Place retaining ring (1) onto spring seat.


- Compress the piston springs, using the J-23075 piston spring compressor and J-23075-12 adapter.

CAUTION: Do not overstress the springs and seat. Do not let the spring seat catch in the ring groove. This may cause damage to the spring seat.

- Install spring seat retaining ring (1).
- Remove the piston spring compressor and adapter.

Sprag Unit

Disassembled View



248RS009

Legend

- (1) Retaining Ring
- (2) Sprag Outer Race
- (3) Ring

- (4) Sprag Assembly
- (5) Ring
- (6) Third Clutch Hub and Sun Gear Assembly

Disassembly

1. Remove the sprag outer race, retaining ring, and sprag assembly from the third clutch hub and sun gear assembly.
2. Remove the rings and sprag assembly from the sprag outer race.

NOTE: Check correct rotation by holding the sun gear in your left hand and turning the outer race. The outer sprag race should turn freely towards you and should lock turning away from you.

Inspection and Repair


Visual Check:

If any damage, deformation or local wear is found, replace the damaged part.

Reassembly

NOTE: Flared shoulder of the sprag cage faces the sun gear. This procedure must be followed exactly to be sure that the sprag assembly is installed properly.


1. Install rings and sprag assembly onto the third clutch hub and sun gear.
2. Install sprag outer race and retaining ring assembly over the sprag cage assembly.
 - Place third clutch hub and sun gear assembly on a flat surface, sun gear facing up. Place sprag outer race and sprag assembly over the sun gear assembly, push down and turn the input sun counterclockwise at the same time.



248RS010

Second Clutch

Disassembled View




247RW001

Legend

- | | |
|--------------------|-------------------------|
| (1) Retaining Ring | (6) Waved Washer |
| (2) Ring Gear | (7) Retaining Ring |
| (3) Retaining Ring | (8) Spring Seat |
| (4) Spacer | (9) Springs |
| (5) Clutch Plates | (10) Piston Assembly |
| | (11) Second Clutch Drum |

Disassembly

1. Remove retaining ring (1) from second clutch drum (11).
2. Remove ring gear (2), retaining ring (3), and spacer (4).
3. Remove clutch plates (5) and waved washer (6).
4. Remove retaining ring (7) using J-23327 compressor to compress the spring seat (8).
5. Remove spring seat (8), springs (9) and piston assembly (10) from second clutch drum (11).



247RS006

Inspection and Repair

Visual Check:

If any damage, deformation or wear is found, replace the damaged part.

Operation Check:

Shake the piston and listen for check ball movement. Movement indicates proper check ball operation. Replace the piston if the check ball is missing or falls out.

Reassembly

1. Install piston assembly (10) into the second clutch drum (11).

○Lubricate the lip seal with transmission fluid. Use the J-23080-A second clutch piston installer to protect the outer piston lip seal.

NOTE: Lip of the seal should point toward front of transmission.

○Remove the installer.

2. Install twenty-two piston springs (9) and spring seat (8) on the second clutch piston (10). Place retaining ring (7) onto spring seat.

○Use the J-23327 compressor to compress the piston springs.

NOTE: Do not let spring seat catch in ring groove.


○Remove the compressor.

3. Install waved plate (6) and clutch plates (5). Start with a steel plate and alternate with lined plates.

○Align second clutch inner tangs.

4. Install spacer (4), with the fluted end toward clutch plates.


5. Install retaining ring (3), ring gear (2) and retaining ring (1).



247RS007

3-4 Accumulator Piston

Disassembled View




Legend

- (1) Snap Ring
- (2) Cover


- (3) Spring
- (4) Piston Assembly

Disassembly

1. Install the J-38559-A cover compressor on adapter case.
○Compress piston cover then remove snap ring.



2. Install the J-41096 cover remover and J-38584 adapter to center hole of cover.
○Use the J-23907 slide hammer to remove cover.
3. Remove spring and piston assembly.



Inspection and Repair


Visual Check:

If any damage, deformation or wear is found, replace the damaged part.

Reassembly

1. Place the J-38553 piston fitter into adaptor case and push the piston into position, using suitable diameter tube.


○Remove the piston fitter.



2. Install spring and cover.
3. Install snap ring, using the J-38559-A compressor tool.


○Install snap ring in groove.

○Remove the compressor tool.



Reverse Clutch Piston and Center Support

Disassembled View



242RS006

Legend

- | | |
|---------------------|-----------------------------|
| (1) Retaining Ring | (7) Transfer Plate |
| (2) Spring Seat | (8) Gasket |
| (3) Springs | (9) Restrictor |
| (4) Piston Assembly | (10) Retainer Plate |
| (5) Center Support | (11) Plug |
| (6) Gasket | (12) Spring |
| | (13) Overrun Lock Out Valve |


Disassembly

1. Install the J-23327 compressor tool on spring seat, then compress the spring seat.

○Remove retaining ring (1).

NOTE: Do not over-stress the springs and seat, as this will cause damage to the spring seat.

○Remove the compressor tool.



247RS008

2. Remove spring seat (2) and springs (3).
3. Remove piston assembly (4).
4. Remove 8 bolts from center support (5), then remove center support (5) from adapter case.
5. Remove gasket transfer plate/outer support (6), center support transfer plate (7), and gasket transfer plate/adapter case (8).
6. Remove restrictor (9) from adapter case housing.
7. Remove retainer plate (10), plug (11), spring (12), and overrun lock out valve (13) from center support (5).

Inspection and Repair

Visual Check:


If any damage, deformation or wear is found, replace the damaged part.

Reassembly

1. Install overrun lock out valve (13) and spring (12) to center support.

NOTE: Ensure correct assembly of valve. The spring should be located over the long small diameter end.

2. Install plug (11) and retainer plate (10).
3. Place restrictor (9) in the lube overdrive channel in the adapter case housing.



242RS005


4. Install gasket transfer plate/adapter case (8), center support transfer plate (7), and gasket transfer plate/center support (6).
5. Install center support (5) with 8 bolts.

Torque : 25 N•m (18 lb ft)

6. Install piston assembly (4) into center support (5).
 7. Install twenty four springs (3), spring seat (2), and retaining ring (1).
- Install the J-23327 compressor and compress spring seat (2) and springs (3), then seat snap ring (1) in groove.
- Remove the tool.

Overrun Clutch and Turbine Shaft

Disassembled View




252RW005

Legend

- | | |
|--------------------------------|---|
| (1) Snap Ring | (8) Snap Ring |
| (2) Overdrive Carrier Assembly | (9) Overrun Roller Clutch Cam |
| (3) Sun Gear | (10) Roller Clutch Assembly |
| (4) Turbine Shaft | (11) Overrun Clutch Release Spring Retainer |
| (5) Snap Ring | (12) Diaphragm Spring |
| (6) Backing Plate | (13) Piston Assembly |
| (7) Clutch Plates | (14) Overrun Clutch Drum |
| | (15) Turbine Shaft Seal Rings |


Disassembly

1. Position overrun clutch assembly upright, using the overdrive internal gear as a support.
○ Remove snap ring (1).



252RS009

2. Remove overdrive carrier assembly (2), sun gear (3) and turbine shaft (4).
3. Remove snap ring (5), backing plate (6), and clutch plates (7).
4. Compress diaphragm spring with the J-23327-91 compressor then remove snap ring (8).



252RS010

5. Remove overrun roller clutch cam (9) and roller clutch assembly (10).
6. Remove overrun clutch release spring retainer (11) and diaphragm spring (12).
7. Remove piston assembly (13) from overrun clutch drum (14).
8. Remove turbine shaft seal rings (15).


Inspection and Repair

Overdrive Carrier Check

- Check pinion end play with a feeler gauge.

Clearance: 0.24mm–0.64mm (0.0094in–0.025in)

If clearance is outside specified value, replace overdrive carrier assembly.




252RS011

Visual Check:

If any damage, deformation or wear is found, replace the damaged part.

Reassembly

1. Install turbine shaft seal rings (15) with grease (petroleum jelly).




241RS008

2. Install the J-38555 inner installer on the drum (14).
○ Pre-install piston assembly into J-38555 outer installer.
○ Install overrun clutch piston assembly (13). Use the outer installer while pushing piston into drum (14).


7A-82 AUTOMATIC TRANSMISSION (4L30-E)

○Remove the installer.



NOTE: Turn the assembly in a counter-clockwise direction only until roller clutch enters the outer race. After installation, rotate the assembly and listen for loose rollers.

11. Install turbine shaft (4) and snap ring (1).




3. Install diaphragm spring (12).
4. Install overrun clutch release spring retainer (11) (lip faces upwards), overrun roller clutch assembly (10) and cam (9).
5. Place snap ring loosely on spring retainer.
 - Hold the J-23327-91 compressor in a vise and compress piston return spring with compressor.
 - Set snap ring (8) in ring groove.
 - Remove the compressor.
6. Install clutch plates (7), start with steel plate and alternate with lined plates.
7. Install backing plate (6).
8. Install snap ring (5).
9. Install overdrive sun gear with countersink pointing downwards.
10. Install the overdrive carrier assembly (2).


Main Data and Specification**General Specifications**

			Remarks		
Model			THM 4L30–E		
Engine			V6 3.2L 6VD1		
Type			Automatic four speed overdrive in 4th gear lock-up clutch torque converter		
Control systems	Shift control		Hydraulic		
	Shift pattern		Electronic		
	Shift quality		Electronic		
	Lock-up clutch		Electronic		
Gear ratio	1st		2.856		
	2nd		1.618		
	3rd		1.000		
	4th (O/D)		0.723		
	Reverse		2.000		
Gear set			Noiseless, high torque capability		
Oil used	Name		ATF DEXRON®–III		
	Q'ty liter (qt)		8.6 (9.1)		
Torque converter			2,200 ± 150		
	Reverse clutch		RC	4	Number of discs
	Second clutch		C2	6	
	Third clutch		C3	6	
	Brake band		Double wrap		
	Fourth clutch		C4	2	Number of discs
	Overrun clutch		OC	1	
	Overdrive		OFW	10	Number of rollers
	Principal		PFW	26	Number of sprags
	Ravigneaux type gear train (planetary gear set)	Input sun gear		30	Number of teeth
		Pinion gear		19	
		Long pinion		23	
		Ring gear		90	
		Long pinion		19	
		Output sun gear		46	
	Overdrive carrier (planetary gear set)	Sun gear		31	
		Pinion gear		24	
		Ring gear		81	

Torque Specifications




E07RX004



E07RX008

7A-86 AUTOMATIC TRANSMISSION (4L30-E)



E07RW014

Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
 901RT071	J-23075 Spring compressor (For servo piston)
 901RX007	J-38450-A Third clutch snap ring compressor
 901RT073	J-23075-12 Third clutch spring compressor adapter (Use with J-23075)
 901RT074	J-23084 Third clutch piston installer
 901RT075	J-23327 Third clutch spring compressor
 901RT076	J-23080-A Second clutch piston installer

ILLUSTRATION	TOOL NO. TOOL NAME
 901RT077	J-23085-A Selective washer gaging tool
 901RT078	J-23327-90 Fourth clutch spring compressor (Use with J-23327)
 901RT079	J-38553 3/4 Accumulator piston fitter
 901RT080	J-41096 Cover remover (Use with J-38584)
 901RT081	J-38584 Slide hammer adapter (Use with J-23907)
 901RT082	J-38554 Fourth clutch piston fitter

7A-88 AUTOMATIC TRANSMISSION (4L30-E)







ILLUSTRATION	TOOL NO. TOOL NAME
 901RT003	J-38588 Guide pins; adapter case to main case
 901RT004	J-38555 Overrun clutch piston seal installer set
 901RT005	J-3387-2 Guide pins; gasket and transfer plate to valve body
 901RT006	J-25022 Turbine shaft puller (Use with J-24773-1)
 901RT007	J-23129 Oil seal remover (Use with J-23907 and J-38584)
 901RT008	J-38557 Oil pump centering tool













ILLUSTRATION	TOOL NO. TOOL NAME
 901RT009	J-23082-01 Oil pump rotation tool
 901RT090	J-25025-B Guide pins; valve body to main case
 901RT091	J-38428 Servo piston fitter
 901RT092	J-23327-91 Overrun clutch spring compressor
 901RT093	J-38559-A 3/4 Accumulator piston cover compressor
 901RT094	J-8763-02 Holding fixture

ILLUSTRATION	TOOL NO. TOOL NAME
 <p>901RT095</p>	<p>J-36797 A/T extension housing oil seal installer (Inside)</p>
 <p>901RT096</p>	<p>J-3289-20 Holding fixture base</p>
 <p>901RT097</p>	<p>J-29770-A Pressure gauge</p>
 <p>901RT098</p>	<p>J-24773-1 End play fixture (Use with J-25022)</p>
 <p>901RT099</p>	<p>J-23907 Slide hammer</p>

4L30-E Parts List

Case and Associated Parts




241RW015

Legend

- | | |
|---|---|
| (1) Torque Converter | (17) Pin, 3-4 Accumulator Piston |
| (2) Screw, Seal Ring Assembly | (18) Piston, 3-4 Accumulator |
| (3) Seal Ring Assembly, Converter Housing | (19) Ring, 3-4, Accumulator Piston |
| (4) Screw, Converter Housing/Main Case | (20) Case, Adapter |
| (5) Screw, Converter Housing/Oil Pump | (22) Connector, Electrical/Adapter Case |
| (6) Housing, Converter | (23) Screw, Pan |
| (7) Plug, Converter Housing | (27) Restrictor, Oil |
| (8) Seal, O-ring | (28) Gasket, Transfer Plate/Adapter |
| (9) Wear Plate, Oil Pump Body | (29) Plate, Transfer Adapter/Center Support |
| (10) Pump Assembly, Oil | (30) Support Assembly, Center |
| (11) Gasket | (31) Screw, Center Support |
| (12) Washer, Thrust Selective | (32) Ring, Oil Seal |
| (13) Ring, Snap | (33) Seal, O-ring Main Case |
| (14) Cover, 3-4 Accumulator Piston | (34) Fitting, Cooler |
| (15) Seal, O-ring, 3-4 Accumulator | (35) Fitting Assembly, Cooler |
| (16) Spring, 3-4 Accumulator Piston | (36) Case, Main |
| | (37) Breather, Pipe |

(38) Seal, O-ring	(73) Plate, Adapter Valve Body/Transfer
(39) Reservoir	(74) Pan, Bottom/Main Case
(42) Gasket, Extension Case	(75) Gasket, Bottom Pan/Main Case
(43) Extension Assembly	(76) Gasket, Oil Drain or Overfill Screw
(44) Seal, O-ring/Speed Sensor	(77) Screw, Oil Drain or Overfill
(45) Sensor Assembly, Speed	(78) Magnet, Chip Collector
(46) Screw, Speed Sensor	(79) Filter Oil
(47) Nut, Output Shaft/Drive Flange	(80) Harness Assembly, Main Case
(48) Seal, O-ring/Drive Flange	(82) Roller and Spring Assembly, Manual Detent
(49) Flange, Drive	(84) Valve Body Assembly, Main Case
(50) Seal, Extension Assembly	(85) Ball, Check
(51) Bearing, Needle/Extension	(86) Gasket, Main V.B./Transfer Plate
(52) Screw, Extension/Main Case	(87) Plate, Main V.B./Transfer
(53) Spring, Parking Pawl Lock	(88) Gasket, Transfer/Main Case
(54) Pawl, Parking Lock	(89) Screw, Transfer Plate on V.B.
(55) Connector, Electrical/Main Case	(90) Screw, Servo Cover
(56) Actuator Assembly, Parking Lock	(91) Cover, Servo Piston
(57) Nut, Parking Lock Lever	(92) Gasket, Cover/Servo Piston
(58) Link, Manual Valve	(93) Ring, Retaining Servo Piston
(59) Pin, Spring	(94) Clip, Servo Piston
(60) Lever, Parking Lock and Range Selector	(95) Nut, Servo Screw
(61) Shaft, Selector	(96) Screw, Servo Piston
(62) Seal, Selector Shaft	(97) Piston, Servo
(63) Mode Switch Assembly	(98) Seal, Ring/Servo Piston
(64) Screw & Conical Washer Assembly	(99) Spring, Cushion/Servo Piston
(65) Shield, Mode Switch	(100) Seat, Cushion Spring
(67) Pan, Bottom/Adapter Case	(101) Sleeve, Servo Piston Adjust
(68) Gasket, Bottom Pan/Adapter Case	(102) Rod, Apply/Servo Piston
(69) Harness Assembly, Adapter Case	(103) Spring, Return/Servo Piston
(70) Screw, Valve Body	(104) Gasket, Adapter Case/Transfer Plate
(71) Valve Body Assembly, Adapter Case	(105) Powertrain Control Module
(72) Gasket, Adapter Valve Body	(106) Servo Piston Assembly

Pump Assembly




241RS019

Legend


- | | |
|---|--|
| (201) Gear, Oil Pump Drive | (209) Pump Assembly, Oil |
| (202) Gear, Oil Pump Driven | (210) Valve, Converter Clutch Control |
| (203) Pin, Boost Valve Sleeve | (211) Spring, Converter Clutch Control Valve |
| (204) Sleeve, Boost Valve | (212) Plug, Converter Clutch Control Valve |
| (205) Valve, Boost | (213) Pin, Spring |
| (206) Seat, Spring/Pressure Regulator Valve | (214) Piston, Throttle Signal Accumulator |
| (207) Spring, Pressure Regulator Valve | (215) Spring, Throttle Signal Accumulator |
| (208) Valve, Pressure Regulator | (216) Seat, Spring/Throttle Signal Accumulator |
| | (217) Ring, Snap/Throttle Signal Accumulator |

Valve Body Assemblies

**Legend**

- | | |
|--------------------------------------|---|
| (301) Body, Valve Main Case | (311) Spring, Valve Low Pressure Control |
| (302) Pin, Spring | (312) Valve, Low Pressure Control |
| (303) Solenoid Assembly, ON/OFF N.C. | (317) Ball, Check |
| (304) Valve, 1-2 & 3-4 Shift | (318) Valve, 1-2 Accumulator Control |
| (305) Spring, 1-2 & 3-4 (2-3) Shift | (320) Valve, 1-2 Accumulator |
| (306) Retainer, Valve | (321) Washer, Waved PWM Solenoid |
| (307) Solenoid Assembly, ON/OFF N.O. | (322) Pin, Solenoid PWM |
| (308) Valve, 2-3 Shift | (323) Solenoid Assembly, Band Control PWM |
| (309) Pin, Spring | (324) Screen Assembly, PWM Solenoid |
| (310) Plug, Valve Bore | (325) Plug, Screen |
| | (326) Valve, Manual |

7A-94 AUTOMATIC TRANSMISSION (4L30-E)




243RW003

Legend

- | | |
|--------------------------------------|---|
| (401) Body, Valve/Adapter Case | (410) Spring, Feed Limit Valve |
| (402) Screw, Solenoid Force Motor | (411) Ring, Retainer |
| (403) Retainer, Force Motor | (412) Valve, Feed Limit |
| (404) Solenoid, Force Motor | (413) Seal, O-ring Plug Filter |
| (405) Plug, 3-4 Accumulator | (414) Plug, Screen |
| (406) Plug and Spring Retainer | (415) Screen Assembly, Force Motor |
| (407) Valve, 3-4 Accumulator | (416) Solenoid, Torque Conv. Clutch ON/OFF N.C. |
| (409) Valve, 3-4 Accumulator Control | (417) Plug Retainer |

Overdrive Internal Components




252RW003

Legend

- | | |
|---|--|
| (501) Retainer, 4th Clutch | (520) Plate, Waved/Overrun Clutch |
| (502) Plate, 4th Clutch (Steel) | (521) Plate, Overrun Clutch (Steel) |
| (503) Plate Assembly, 4th Clutch (Lined) | (522) Plate Assembly, Overrun Clutch (Lined) |
| (504) Retainer and Ball Assembly, Check Valve | (523) Plate, Backing/Overrun Clutch |
| (505) Seal, O-ring/Turbine Shaft | (524) Ring, Snap/Overrun Clutch Housing |
| (506) Shaft, Turbine | (525) Carrier Assembly, Overdrive Complete |
| (508) Ring, Oil Seal/Turbine Shaft | (526) Ring, Snap/Turbine Shaft/Carrier |
| (510) Housing, Overrun Clutch | (527) Bearing Assembly, Thrust |
| (513) Piston, Overrun Clutch | (528) Gear, Overdrive Internal |
| (514) Spring, Overrun Clutch Release | (529) Washer, Thrust/Internal Gear/Support |
| (515) Retainer, Release Spring/Overrun Clutch | (530) Ring, Snap/Adapter/4th Clutch Spring |
| (516) Roller Assembly, Overdrive Clutch | (531) Retainer and spring assembly, 4th clutch |
| (517) Cam, Overdrive Roller Clutch | (532) Piston, 4th Clutch |
| (518) Ring, Snap/Overrun Clutch Hub | (533) Seal, 4th Clutch Piston (Inner) |
| (519) Gear, Overdrive Sun | (534) Seal, 4th Clutch Piston (outer) |

Internal Components



247RW002


Legend

- | | |
|--|--|
| (608) Seal, Reverse Clutch Piston (Inner) | (627) Plate Assembly, 2nd Clutch (Lined) |
| (609) Seal, Reverse Clutch Piston (Outer) | (628) Spacer, 2nd Clutch |
| (610) Piston, Reverse Clutch | (629) Ring, Retaining |
| (611) Spring, Piston Clutch | (630) Gear, Ring |
| (612) Seat, Spring/Reverse Clutch | (631) Washer, Thrust/2nd Clutch/3rd Clutch |
| (613) Ring, Retaining | (632) Thrust Washer, Clutch Hub |
| (614) Plate, Waved/Reverse Clutch | (634) Drum Assembly, 3rd Clutch |
| (615) Plate, Reverse Clutch (Steel) | (635) Seal, 3rd clutch piston (Inner) |
| (616) Plate Assembly, Reverse Clutch (Lined) | (636) Washer, Retaining |
| (617) Plate, Reverse Clutch Pressure/Selective | (637) Seal, 3rd Clutch Piston (Outer) |
| (618) Drum Assembly, 2nd Clutch | (638) Piston 3rd Clutch |
| (620) Seal, 2nd Clutch Piston (Inner) | (639) Seat, Spring/3rd Clutch |
| (621) Seal, 2nd Clutch Piston (Outer) | (640) Ring, Retaining |
| (622) Piston, 2nd Clutch | (641) Plate, Spring Cushion/3rd Clutch |
| (623) Seat, Spring/2nd Clutch | (642) Plate, 3rd Clutch (Steel) |
| (625) Plate, Waved/2nd Clutch | (643) Plate Assembly, 3rd Clutch (Lined) |
| (626) Plate, 2nd Clutch (Steel) | (644) Washer, Thrust/Input Sun |
| | (645) Bearing, Input Shaft/Gear Assembly |

(646) Gear Assembly, Input Sun
 (647) Race Assembly, Sprag
 (648) Ring, Retaining/Sprag
 (649) Ring, Retaining
 (650) Cage Assembly, Sprag
 (651) Bearing, Output Shaft/Input Sun
 (652) Washer, Output Shaft/Input Sun
 (653) Carrier Assembly, Planetary

(658) Gear, Reaction Sun
 (659) Drum, Reaction Sun
 (664) Band Assembly, Brake
 (667) Seal, Ring/Wheel Parking Lock
 (668) Wheel, Parking Lock
 (672) Wheel, Speed
 (673) Ring, Retaining
 (675) Bearing, Thrust Assembly

Center Support Assembly



241RS010

Legend

(701) Center Support
 (702) Retainer Plate

(703) Plug, Lockout
 (704) Spring, Overrun Lockout
 (705) Valve, Overrun Lockout

RODEO

TRANSMISSION

TRANSMISSION CONTROL SYSTEM (4L30-E)

CONTENTS

Service Precaution	7A1-2	DTC P0560 System Voltage Malfunction ...	7A1-28
General Description	7A1-2	DTC P0705 Transmission Range Switch (Mode Switch) Illegal Position	7A1-31
Electronic Control Diagram	7A1-3	DTC P0706 Transmission Range Switch (Mode Switch) Performance	7A1-34
Powertrain Control Module (PCM)	7A1-4	DTC P0711 Transmission Fluid Temperature (TFT) Sensor Circuit Range/Performance ..	7A1-37
Control System Diagram	7A1-5	DTC P0712 Transmission Fluid Temperature (TFT) Sensor Circuit Low Input	7A1-40
Shift Control	7A1-6	DTC P0713 Transmission Fluid Temperature (TFT) Sensor Circuit High Input	7A1-43
Band Apply Control	7A1-6	DTC P0719 TCC Brake Switch Circuit High (Stuck On)	7A1-46
Torque Converter Clutch Control	7A1-6	DTC P0722 Transmission Output Speed Sensor (OSS) Low Input	7A1-49
Line Pressure Control	7A1-6	DTC P0723 Transmission Output Speed Sensor (OSS) Intermittent	7A1-52
On-Board Diagnostic System	7A1-6	DTC P0724 TCC Brake Switch Circuit Low (Stuck Off)	7A1-55
Fail-Safe Mechanism	7A1-6	DTC P0730 Transmission Incorrect Gear Ratio	7A1-57
Torque Management Control	7A1-6	DTC P0742 Torque Converter Clutch (TCC) Circuit Stuck On	7A1-60
ATF Warning Control	7A1-6	DTC P0748 Pressure Control Solenoid (PCS) (Force Motor) Circuit Electrical	7A1-62
Shift Mode Control	7A1-7	DTC P0751 Shift Solenoid A Performance Without Input Speed	7A1-64
Gear Shift Control	7A1-8	DTC P0753 Shift Solenoid A Electrical	7A1-66
Winter Drive Mode	7A1-9	DTC P0756 Shift Solenoid B Performance Without Input Speed	7A1-69
Backup Mode	7A1-9	DTC P0758 Shift Solenoid B Electrical	7A1-71
Functions of Input / Output Components ..	7A1-10	DTC P1790 ROM Transmission Side Bad Check Sum	7A1-75
Diagnosis	7A1-11	DTC P1792 EEPROM Transmission Side Bad Check Sum	7A1-76
Electronic Diagnosis	7A1-11	DTC P1835 Kickdown Switch Always On ...	7A1-77
Check Trans Indicator	7A1-11	DTC P1850 Brake Band Apply Solenoid Malfunction	7A1-79
Diagnostic Check	7A1-11	DTC P1860 TCC Solenoid Electrical	7A1-83
“Check Trans” Check	7A1-12	DTC P1870 Transmission Component Slipping	7A1-86
Tech-2 OBD II Connection	7A1-13		
F0: Transmission Data	7A1-17		
F1: PC Solenoid Data	7A1-18		
OBD II Diagnostic Management System ..	7A1-19		
16 – Terminal Data Link Connector (DLC) .	7A1-20		
Malfunction Indicator Lamp (MIL)	7A1-21		
Types Of Diagnostic Trouble Codes (DTCs)	7A1-21		
Clear DTC	7A1-21		
DTC Check	7A1-22		
PCM Precaution	7A1-22		
Information On PCM	7A1-22		
Intermittent Conditions	7A1-23		
Transmission and PCM Identification	7A1-23		
Isuzu Rodeo	7A1-24		
Diagnostic Trouble Code (DTC) Identification	7A1-25		
DTC P0218 Transmission Fluid Over Temperature	7A1-26		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

The 4L30-E is a 4-speed fully automatic transmission. It uses a microcomputer as a control unit to judge running conditions including throttle opening rate and vehicle speed, then it sets the shifting point in the optimum timing so that best driving performance can be achieved.

In addition, the built-in shift mode select function can select three shift modes according to the driver's preference:

- Normal mode –Normal shift pattern.
- Winter mode –Starts in 3rd gear to reduce slippage on ice or snow.
- Power mode has a delayed upshift for when more powerful acceleration is required.

Also, the built-in fail-safe function ("backup mode") assures driving performance even if the vehicle speed sensor, throttle signal or any solenoid fails.

Further, the self-diagnostic function conducts diagnosis in a short time when the control system fails, thus improving serviceability.


The major features of 4L30-E are as follows:

- A compact structure consisting of 2 sets of planetary gears and flat torque converter.
- Electronic control selects the optimum shift mode according to the driving conditions.
- Electronic control maintains the optimum hydraulic pressure for clutch, band brake as well as transmission so that shift feeling is improved.
- Two sets of planetary gears reduce friction of power train.

Also, a lockup mechanism in the torque converter reduces fuel consumption.

- Wide gear ratio and high torque rate of torque converter provide excellent starting performance.


Electronic Control Diagram



C07RW025


7A1-4 TRANSMISSION CONTROL SYSTEM (4L30-E)

Powertrain Control Module (PCM)



TPS: Throttle Position Sensor
TCC: Torque Converter Clutch

Control System Diagram



C07RW027

Shift Control

The transmission gear is shifted according to the shift pattern selected by the driver. In shifting gears, the gear ratio is controlled by the ON/ OFF signal using the shift solenoid A and the shift solenoid B.

Band Apply Control

The band apply is controlled when in the 3-2 downshift (engine overrun prevention) and the garage shift (shock control).

The band apply solenoid is controlled by the signal from the Pulse Width Modulation (PWM) to regulate the flow of the oil.

Torque Converter Clutch Control

The clutch ON/OFF is controlled by moving the converter clutch valve through shifting Torque Converter Clutch (TCC) solenoid using the ON/OFF signal.

Line Pressure Control

The throttle signal allows the current signal to be sent to the force motor. After receiving the current signal, the force motor activates the pressure regulator valve to regulate the line pressure.

On-Board Diagnostic System

Several malfunction displays can be stored in the Powertrain Control Module (PCM) memory, and read out of it afterward.

The serial data lines, which are required for the testing of the final assembly and the coupling to other electronic modules, can be regulated by this function.

Fail-Safe Mechanism

If there is a problem in the transmission system, the PCM will go into a "backup" mode.

The vehicle can still be driven, but the driver must use the select lever to shift gears.

Torque Management Control

The transmission control side sends the absolute spark advance signal to the engine control side while the transmission is being shifted. This controls the engine spark timing in compliance with the vehicle running condition to reduce the shocks caused by the change of speed.

ATF Warning Control

The oil temperature sensor detects the ATF oil temperature to control the oil temperature warning, TCC, and the winter mode.

Shift Mode Control

① Mode Type

Mode Type	Select lever position
Normal drive mode (NOR)	Entire range (excluding "R")
Power drive mode (PWR)	Entire range (excluding "R")
Winter drive mode	"D" range only

② Mode selection


Mode Type	SWITCH (SW)		LAMP	
	POW/NOR. SW	WINTER SW	POWER DRIVE LAMP	WINTER DRIVE LAMP
Normal drive mode (NOR)	OFF	OFF	OFF	OFF
Power drive mode (PWR)	ON	OFF	ON	OFF
Winter drive mode	ON/OFF	ON	OFF	ON

However, the winter switch prevails over the PWR/NOR switch.
The mode becomes normal drive mode when the winter switch is operated from ON to OFF.

③ Comparison of mode

- (1) The normal drive mode is set at the normal shift points.
- (2) The shift points of the power drive mode are shifted to the higher speed side, compared to the normal drive mode.
- (3) The winter drive mode is a special mode used exclusively for starting in third gear.

Shift diagram



Gear Shift Control

① Shift pattern

SELECT LEVER RANGE	SHIFT PATTERN
D (Drive)	1⇌2TCC ⇌3TCC ⇌4TCC
3 (Third)	1⇌2TCC ⇌3TCC ←4TCC
2 (Second)	1⇌2TCC ←3TCC
L (First)	1←2

TCC = Torque Converter Clutch

② Gear position

The gear is selected by ON/OFF of two solenoids.

Gear \ SOL	A	B
4 (Fourth)	×	×
3 (Third)	○	×
2 (Second)	○	○
1 (First)	×	○
P (park)		
R (Reverse)	×	○
N (Neutral)		

○ = ON

× = OFF

Shift solenoid A
(Normally closed)

ON → PRESSURE TO
SHIFT VALVE

Shift solenoid B
(Normally open)


OFF → PRESSURE TO
SHIFT VALVE

③ Selecting gear position

Seven types of positions can be selected according to 5 signals from the mode switch as below.

SELECT LEVER RANGE	MODE SW TERMINALS				
	5(D)	8(A)	7(B)	6(C)	3(G)
P (park)	•	•			•
R (Reverse)	•	•	•		
N (Neutral)	•		•		•
D (Drive)	•		•	•	
3 (Third)	•	•	•	•	•
2 (Second)	•	•		•	
L (First)	•			•	•

• = Continuity



Winter Drive Mode

1. The winter switch will operate when switched on after all of the following conditions are present:
 - a. The gear select position is "D" range only.
 - b. Vehicle speed is 7 mph (11 km/h) or less.
 - c. Transmission oil temperature is 120°C (248°F) or less.
 - d. Kickdown switch is off.
 - e. Accelerator opening is at 8% or less.

2. Cancel Release

1. Cancellation by driver
 - a. Turning off the winter drive mode switch
 - b. Shifting select position to "3", "2", or "L" (Winter drive mode is not canceled by selecting "D", "N", "R", or "P")
 - c. Ignition key is turned off.
2. Automatic cancellation
 - a. When vehicle runs at 21mph (34 km/h) or more for 1 second or more
 - b. When transmission oil temperature reaches 140°C (284°F) or above

NOTE: The mode returns to normal drive mode automatically after the winter drive mode is canceled.

Backup Mode

If a major system failure occurs which could affect safety or damage the transmission under normal vehicle operation, the diagnostic system detects the fault and overrides the Powertrain Control Module (PCM).

The "CHECK ENGINE" light comes on and the "CHECK TRANS" light flashes to alert the driver, and the transmission must be manually shifted as follows:

Select lever position	Gear Ratio Selected
D	4 (Fourth)
Manual 3	4 (Fourth)
Manual 2	3 (Third)
Manual L	1 (First)
R	Reverse

Shifts are firmer to prevent clutch slip and consequent wear. The fault should be corrected as soon as possible.

7A1-10 TRANSMISSION CONTROL SYSTEM (4L30-E)

Functions of Input / Output Components

Components		Function
I N P U T S I G N A L	Speed sensor (fixed to transmission (T/M))	Senses rotation of output shaft and feeds the data to Powertrain Control Module (PCM).
	Throttle position sensor (TPS) (fixed to engine)	Senses the extent of throttle valve opening and the speed of the throttle valve lever motion to open the valve and feeds the data to PCM.
	Brake Switch (SW) (fixed to brake pedal)	Senses whether the driver has pressed the brake pedal or not and feeds the information to PCM.
	Kickdown SW (fixed to accelerator pedal)	Senses whether the driver has pushed the accelerator pedal fully or not and feeds the information to PCM.
	Mode SW (fixed to T/M)	Senses the select lever position, and feeds the information to PCM.
	Power drive SW (fixed to front console)	Senses whether the driver has selected the power mode, and feeds the information to PCM.
	T/M oil temp. sensor	Senses the T/M oil temperature and feeds the data to PCM.
	Engine coolant temperature sensor	Senses the engine coolant temperature, and feeds the data to PCM.
	Engine speed signal	Feeds the signals monitoring engine speed to PCM from crank angle sensor.
	Air conditioning information	Senses whether the air conditioner has been switched on or not, and feeds the information to PCM.
	Winter switch (fixed to front console)	Senses whether the driver has selected the winter mode, and feeds the information to PCM.
	Cruise controller (Overdrive OFF signal)	Downshift takes place when Overdrive OFF signal is received from auto cruise control unit.
O U T P U T S I G N A L	Shift solenoid A, B	Selects shift point and gear position suited to the vehicle running condition on the basis of PCM output.
	Band apply solenoid	Controls oil flow suited to the vehicle running condition on the basis of PCM output.
	Torque Converter Clutch solenoid	Controls clutch engagement/disengagement suited to the vehicle running condition on the basis of PCM output.
	Force motor (Pressure regulator valve)	Adjusts the oil pump delivery pressure to line pressure suited to the vehicle running condition on the basis of PCM output.
	Power drive mode lamp	Informs the driver whether the vehicle is in power mode or not.
	Winter drive mode lamp	Informs the driver whether the vehicle is in winter mode or not.
	T/M monitor lamp ("CHECK TRANS")	Informs the driver of failure in the system.
	ATF warning lamp	Lights when ATF oil temperature rises. (only 4×4)

Diagnosis

Electronic Diagnosis


How To Diagnose The Problem

1. To avoid incorrect diagnostics, this book needs to be followed accurately. Unless stated, **do not jump directly to a section that could contain the solution. Some important information may be missed.**
2. The sections in CAPITALS and bold are the main sections that can be found in the contents.
3. The GOTO "**SECTION**" means to continue to check going to the "section".
4. The GOTHROUGH "**SECTION**" means to go through the "section" and then to go back to the place the GOTHROUGH was written.
5. BASIC ELECTRIC CIRCUITS:
You should understand the basic theory of electricity. This includes the meaning of voltage, amps, ohms, and what happens in a circuit with an open or shorted wire. You should also be able to read and understand wiring diagrams.

Check Trans Indicator

Find CHECK TRANS indicator and verify if it is

- A. Flashing: GOTO **DIAGNOSTIC CHECK.**
- B. Staying on: GOTHROUGH **CHECK TRANS CHECK.**
- C. Is never ON when the ignition key is turned on: GOTHROUGH **CHECK TRANS CHECK**
- D. Is ON during 2 to 3 seconds at ignition but OFF after: Normal operation. No DTC or malfunction.



821RW105

Diagnostic Check

This test determines if the transmission or its input, or output, connections, or sensors are failing.

1. Connect the TECH-2: GOTHROUGH **TECH-2 OBD II CONNECTION.**

2. Turn on the ignition but not the engine.

3. Push "F2" on TECH-2 to see the Diagnostic Trouble Code (DTC):

4. Do you have a DTC?


YES: write down all code numbers and do the **DTC CHECK**

NO: the DTC can not help you find the problem.

1. GOTHROUGH **"CHECK TRANS" CHECK**


2. IF it is flashing and the flash is 0.2 seconds ON and 0.2 seconds OFF, this means that you should have a DTC stored. Please recheck GOTO **DIAGNOSTIC CHECK** and if you find the same problem, replace the Powertrain Control Module (PCM).

Normal



C07RW007

Abnormal




C07RW008


7A1-12 TRANSMISSION CONTROL SYSTEM (4L30-E)

“Check Trans” Check

- Indicator is ON during 2 to 3 seconds at ignition (or when the engine is cranked) but it is OFF after the engine starts. The indicator is working normally GOTO **DIAGNOSTIC CHECK**.




Normal




- Indicator is flashing and the flash is 0.2 seconds ON and 0.2 seconds OFF always when ignition is on (engine cranked or not). This means that there is a malfunction. GOTO **DIAGNOSTIC**

Abnormal



- Indicator is staying ON always when Ignition is ON.
 - This means that connection between the lamp and the PCM is shorted to ground.
 - Verify if instrument panel terminal 6 of connector I-1 is shorted to ground.
 - Verify if the PCM connector C1 (RED) terminal A14 is shorted to ground.
 - Verify that the instrument panel terminal 12 of connector I-1 is connected to battery.
 - IF problem solved: GOTO **CHECK TRANS INDICATOR**.
NO: Replace Powertrain Control Module (PCM).
- Indicator is staying OFF with the ignition ON (engine OFF).
 - This means that connection between the lamp and the PCM is shorted to battery or opened.
 - Verify if instrument panel terminal 6 of connector I-1 is shorted to battery or open.
 - Verify if the PCM connector C1 (RED) terminal A14 is shorted to battery or open.
 - Verify that the instrument panel terminal 12 of connector I-1 is connected to battery. If not, check the fuses and the connections (terminal 11 of connector H-27) voltage.
 - IF problem solved: GOTO **CHECK TRANS INDICATOR**.
NO: Replace Powertrain Control Module (PCM).




D07RW017

Tech-2 OBD II Connection


In order to access OBD II Powertrain Control Module (PCM) data, use of the Tech 2 scan tool kit (7000086) is required.

1. The electronic diagnosis equipment is composed of:
 1. Tech 2 (7000057) hand-held scan tool unit and DLC cable (3000095).



901RW176


2. SAE 16/19 Pin Adapter (3000098)(1), RS232 Loop Back Connector (3000112)(2), and PCMCIA Card (3000117)(3).



F07RW033

7A1-14 TRANSMISSION CONTROL SYSTEM (4L30-E)

2. Connecting the TECH-2




901RW180

Legend

- | | |
|--------------------------------|-----------------------|
| (1) PCMCIA Card | (3) SAE 16/19 Adaptor |
| (2) RS 232 Loop Back Connector | (4) DLC Cable |
| | (5) Tech-2 |

○Before operating the Isuzu PCMCIA card with the Tech 2, the following steps must be performed:

1. The Isuzu 98 System PCMCIA card (1) inserts into the Tech 2 (5).
2. Connect the SAE 16/19 adapter (3) to the DLC cable (4).
3. Connect the DLC cable to the Tech 2 (5)
4. Make sure the vehicle ignition is off.
5. Connect the Tech 2 SAE 16/19 adapter to the vehicle DLC.




740RW060

6. The vehicle ignition turns on.
7. Verify the Tech 2 power up display.



060RW009


8. The power up screen is displayed when you power up the tester with the Isuzu systems PCMCIA card. Follow the operating procedure below.



060RX004

NOTE: The RS232 Loop back connector is only to use for diagnosis of Tech 2 and refer to user guide of the Tech 2.


7A1-16 TRANSMISSION CONTROL SYSTEM (4L30-E)



Once the test vehicle has been identified an "Application (Powertrain) Menu" screen appears. Please select the appropriate application.

Data Display


When F1: Data Display is selected, a "Data Display Menu" screen appears. Please select either "Transmission Data" or "PC Solenoid Data".



060RX009

Function Tests (Reset Oil Life Monitor)

When F4: Function Tests is selected from the "Powertrain Menu", a "Reset Oil Life Monitor Menu" screen appears. When the ATF has been replaced, select "F0" and reset "Oil Life Monitor" data.



060RX056


F0: Transmission Data

Item	Unit	Engine running at idle
Engine Speed	RPM	750 ~ 900 RPM
Vehicle Speed	km/h, MPH	0 MPH
Throttle Position	%	0 %
Throttle Position Sensor	V	0.5 ~ 1.0 V
Manifold Absolute Pressure	kPa	approx. 40 kPa
Barometric Pressure	kPa	approx. 102 kPa
AT Output Speed (Automatic Transmission)	RPM	0 RPM
AT Input Speed Ratio (Automatic Transmission)		0.0
Ignition Voltage	V	12.8 ~ 14.1 V
AT Oil Temperature (Automatic Transmission)	°C, °F	70 ~ 80°C (158 ~ 176°F)
AT Oil Life Monitor (Automatic Transmission)	%	100 %
Commanded Gear		1
Current Gear		1
Mode Switch C	Inactive, Active	Inactive
Mode Switch B	Inactive, Active	Inactive
Mode Switch A	Inactive, Active	Active
Mode Switch G	Inactive, Active	Active
Actual Gear		Park
1-2 Shift Solenoid A	Off, On	Off
2-3 Shift Solenoid B	Off, On	On
Brake Switch	Off, On	Off
Solenoid Brake Band	Off, On	Off
TCC Slip Speed	RPM	750 ~ 900 RPM
TCC Status	Disabled, Enabled	Enabled
TCC Solenoid	Off, On	Off
TCC Duty Cycle	%	0 %
TCC Apply Mode	No Apply, In Apply	No Apply
TCC Release Mode	No, Yes	No
TCC On Mode	No, Yes	No
TCC Off Mode	No, Yes	Yes
Default Gear	No, Yes	No
Engine Warm	No, Yes	Yes
A/C Request	Yes, No	Yes
A/C Clutch Relay	Off, On	On
Winter Switch	Off, On	Off
Winter Drive Lamp	Off, On	Off
Kickdown Switch	Off, On	Off
ATF Lamp (Automatic Transmission)	Off, On	Off
Power Switch	Normal, Power	Normal
Power Drive Lamp	Off, On	Off
ABS Status	On, Off	Off

7A1-18 TRANSMISSION CONTROL SYSTEM (4L30-E)

F1: PC Solenoid Data

Item	Unit	Engine running at idle
Engine Speed	RPM	750 ~ 900 RPM
Vehicle Speed	km/h, MPH	0 MPH
Throttle Position	%	0 %
Throttle Position Sensor	V	0.5 ~ 1.0 V
Manifold Absolute Pressure	kPa	approx. 40 kPa
Barometric Pressure	kPa	approx. 102 kPa
PCS Current (Pressure Control Solenoid)	A	approx. 1.0 A
PCS Actual Current (Pressure Control Solenoid)	A	approx. 1.0 A
PCS Duty Cycle (Pressure Control Solenoid)	%	approx. 45 %
Desired PCS Pressure (Pressure Control Solenoid)	kPa	43 ~ 52 kPa
Shift Pressure (Line Pressure)	kPa	43 ~ 52 kPa
Transmission Temperature	°C, °F	75 ~ 110°C (167 ~ 230°F)

OBD II Diagnostic Management System**Powertrain Control Module (PCM) Location**

828RW004

Class 2 Serial Data Bus


OBD II technology requires a much more sophisticated PCM than does OBD I technology. The OBD II PCM diagnostic management system not only monitors systems and components that can impact emissions, but they also run active tests on these systems and components. The decision making functions of OBD II PCM have also greatly increased. To accommodate this expansion in diagnostic complexity, Isuzu engineers have designed the Class 2 serial data bus, which meets SAE J1850 recommended practice for serial data.

"Serial Data" refers to information which is transferred in a linear fashion – over a single line, one bit at a time. A "Data Bus" is an electronic pathway through which serial data travels.


RODEO previously used a 5 volt data bus called UART, which is an acronym for "Universal Asynchronous Receive and Transmit". When neither the vehicle's control module nor the diagnostic tool, such as a TECH-2, are "talking," the voltage level of the bus at rest is 5 volts. The two computers talk to each other at a rate of 8,192 bits per second, by toggling or switching the voltage on the data bus from 5 volts to ground.

Class 2 data, which is used on OBD II vehicles, is quite different. Data is transferred at a rate of 10.4 kilobits per second, and the voltage is toggled between zero and 7 volts.

UART



CLASS 2



C07RT006


Class 2 data is also pulse width modulated. Each bit of information can have one of two lengths: long or short. On the other hand, UART data bits come in only one length (short). The pulse width modulation of Class 2 data allows better utilization of the data line.

The message carried on Class 2 data streams are also prioritized. This means that if two devices try to communication on the data line at the same time, only the higher priority message will continue. The device with the lower priority message must wait.


NOTE: The Class 2 data wire is always terminal 2 of the new 16-terminal Data Link Connector (DLC).

16 – Terminal Data Link Connector (DLC)

OBD II standardizes Data Link Connector (DLC) configurations. The DLC, formerly referred to as the ALDL, will be a 16-terminal connector found on the lower left side of the driver's side instrument panel. All manufacturers must conform to this 16-terminal standard.



826RW002



810RT022

- PIN 1 – (Not used)
- PIN 2 – J1850 Bus + L line on 2-wire systems, or single wire (Class 2)
- PIN 3 – (Not used)
- PIN 4 – Chassis ground pin
- PIN 5 – Signal ground pin
- PIN 6 – PCM diagnostic enable
- PIN 7 – (Not used)
- PIN 8 – (Not used)
- PIN 9 – Primary UART
- PIN 10 – (Not used)
- PIN 11 – (Not used)
- PIN 12 – ABS diagnostic or CCM diagnostic enable
- PIN 13 – SIR diagnostic enable
- PIN 14 – (Not used)
- PIN 15 – (Not used)
- PIN 16 – Battery power from vehicle unswitched (4 AMP MAX.)

Malfunction Indicator Lamp (MIL)

The Malfunction Indicator Lamp (MIL) looks the same as the MIL you are already familiar with ("CHECK ENGINE" lamp). However, OBD II requires that it illuminate under a strict set of guidelines. Basically, the MIL is turned on when the PCM detects a DTC that will impact the vehicle's emissions.

The MIL is under the control of the Diagnostic Executive. The MIL will be turned on if a component or system which has an impact on vehicle emissions indicates a malfunction or fails to pass an emissions-related diagnostic test. It will stay on until the system or component passes the same test, for three consecutive trips, with no emissions-related faults.

Types Of Diagnostic Trouble Codes (DTCs)

The Diagnostic Executive classifies Diagnostic Trouble Codes (DTCs) into certain categories. Each type has different requirements to set the code, and the Diagnostic

Executive will only illuminate the Malfunction Indicator Lamp (MIL) for emissions-related DTCs. DTCs fall into four categories: A, B, C, and D; only types A and B are emission related. The following descriptions define these categories:

TYPE A

Will store the DTC and turn on the MIL ("Check Engine" lamp) on the first trip in which an emission-related diagnostic test has run and reported a "test failed" to the Diagnostic Executive.

TYPE B

Will store the DTC and turn on the MIL on the second consecutive trip in which an emission-related diagnostic test has run and reported a "test failed" to the Diagnostic Executive. After one failure, the type B DTC is "armed," or prepared to store a history code and turn on the MIL if a second failure occurs. One passed test will disarm a type B DTC. Some special conditions apply to misfire and fuel trim DTCs. For a type B DTC to store and turn on the MIL, two ignition cycles are required.

TYPE C

Will store the DTC and turn on a "SERVICE" lamp ("Check Trans" lamp) on the first trip that a non-emission-related diagnostic test has run and reported a "test failed" to the Diagnostic Executive. This type of DTC will be used in future applications.

TYPE D

Will store a DTC but will not turn on the MIL on the first trip that a non-emission-related diagnostic test has run and reported a "test failed" to the Diagnostic Executive. These codes can be very helpful for vehicle service when the driver may comment about a condition, but the MIL did not turn on.

Clear DTC

NOTE: If you clear the DTC (Diagnostic Trouble Codes) you will not be able to read any codes recorded during the last occurrence.

NOTE: To use the DTC again to identify a problem, you will need to reproduce the fault or the problem. This may require a new test drive or just turning the ignition on (this depends on the nature of the fault).


1. IF you have a TECH-2:

1. Connect the TECH-2 if it is still not connected **GOT THROUGH TECH-2 OBD II CONNECTION.**
2. Push "F4" and answer "Yes" to the question "Do you really want to clear the codes?"
 - a. When a malfunction remains as it is the TECH-2 displays "4L30E CODES NOT CLEARED". This means that the problem is still there or that the recovery was not done. Please **GOTO DTC CHECK.**
 - b. When a malfunction has been repaired and the recovery is done the TECH-2 displays "4L30E CODES CLEARED".

7A1-22 TRANSMISSION CONTROL SYSTEM (4L30-E)

2. IF you have no TECH-2:

To clear the DTC, remove Fuse "Stop" (CB-13, 15A) for at least 10 seconds.



826RW003

DTC Check

1. Diagnostic Trouble Codes (DTC) have been identified by TECH-2.
2. You have written the list of the DTCs. The order of the malfunctions has no meanings for this PCM. Usually only one or two malfunctions should be set for a given problem.
3. Check directly the DTCs you identified. The DTCs are sorted by number. Refer to Diagnostic Trouble Code (DTC) Identification in this section.

PCM Precaution

The PCM can be damaged by:

1. The electrostatic discharge
2. The short circuit of some terminals to voltage or to ground.

Electrostatic Discharge Damage Description:

1. Electronic components used to control systems are often designed to carry very low voltage, and are very susceptible to damage caused by electrostatic discharge. It is possible for less than 100 volts of static electricity to cause damage to some electronic components. By comparison, it takes as much as 4,000 volts for a person to even feel the zap of a static discharge.

2. There are several ways for a person to become statically charged. The most common methods of charging are by friction and induction. An example of charging by friction is a person sliding across a car seat, in which a charge of as much as 25,000 volts can build up. Charging by induction occurs when a person with well insulated shoes stands near a highly charged object and momentarily touches ground. Charges for the same polarity are drained off, leaving the person highly charged with the opposite polarity. Static charges of either type can cause damage, therefore, it is important to use care when handling and testing electronic components.

NOTICE: To prevent possible electrostatic discharge damage:

1. Do not touch the PCM connector pins or soldered components on the PCM circuit board.
2. Be sure to follow the guidelines listed below if servicing any of these electronic components:
3. Do not open the replacement part package until it is time to install the part.
4. Avoid touching electrical terminals of the part.
5. Before removing the part from its package, ground the package to a known good ground on the vehicle.
6. Always touch a known good ground before handling the part. This step should be repeated before installing the part if the part has been handled while sliding across the seat, while sitting down from a standing position or while walking some distance.

Information On PCM

1. The Powertrain Control Module (PCM) is located in the center console and is the control center of the electronic transmission control system.
2. The PCM must be maintained at a temperature below 185°F (85°C) at all times. This is most essential if the vehicle is put through a paint baking process. The PCM will become inoperative if its temperature exceeds 85°C (185°F). Therefore, it is recommended that the PCM be removed or that temporary insulation be placed around the PCM during the time the vehicle is in a paint oven or other high temperature process.
3. The PCM is designed to process the various inputs and then respond by sending the appropriate electrical signals to control transmission upshift, downshift, shift feel and torque converter clutch engagement.
4. The PCM constantly interprets information from the various sensors, and controls the systems that affect transmission and vehicle performance. By analyzing operational problems, the PCM is able to perform a diagnostic function by displaying DTC(s) and aid the technician in making repairs.

Intermittent Conditions

If the TECH-2 displays a diagnostic trouble code as intermittent, or if after a test drive a DTC does not reappear though the detection conditions for this DTC are present, the problem is most likely a faulty electrical connection or loose wiring. Terminals and grounds should always be the prime suspect. Intermittents rarely occur inside sophisticated electronic components such as the PCM.

Use the DTC information to understand which wires and sensors are involved.

When an intermittent problem is encountered, check suspect circuits for:

1. Poor terminal to wire connection.
2. Terminals not fully seated in the connector body (backed out).
3. Improperly formed or damaged terminals.
4. Loose, dirty, or corroded ground connections:
HINT: Any time you have an intermittent in more than one circuit, check whether the circuits share a common ground connection.
5. Pinched or damaged wires.
6. Electromagnetic Interference (EMI):
HINT: Check that all wires are properly routed away from spark plug wires, distributor wires, coil, and generator. Also check for improperly installed electrical options, such as lights, 2-way radios, etc.

Use the F3: SNAPSHOT mode of the TECH-2 to help isolate the cause of an intermittent fault. The snapshot mode will record information before and after the problem occurs. Set the snapshot to "trigger" on the suspect DTC or, if you notice the reported symptom during the test drive, trigger the snapshot manually.

After the snapshot has been triggered, command the TECH-2 to play back the flow of data recorded from each of the various sensors. Sign of an intermittent fault in a sensor circuit is a sudden unexplainable jump in data values out of the normal range.


Transmission and PCM Identification

The chart below contains a list of all important information concerning rear axle ratio, Powertrain Control Module (PCM), and transmission identification.

VEHICLE		Rr axle Ratio	PCM	TRANSMISSION		
Type	Engine		ISUZU Parts No.	Calibration Code	Isuzu Part No.	Model Code
Isuzu / Rodeo	3.2L V6	4.100	8-09364-929-0	G20	8-96018-004-3	FL (4×4)
			8-09364-959-0	G20	8-96018-005-3	FM (4×2)

7A1-24 TRANSMISSION CONTROL SYSTEM (4L30-E)

Isuzu Rodeo




240RX004

Diagnostic Trouble Code (DTC) Identification

DTC NUMBER	DTC NAME	DTC TYPE	MIL "CHECK ENGINE"	"CHECK TRANS"
P0218	Transmission Fluid Over Temperature	D		
P0560	System Voltage Malfunction	D		
P0705	Transmission Range Switch (Mode Switch) Illegal Position	D		
P0706	Transmission Range Switch (Mode Switch) Performance	D		
P0711	Transmission Fluid Temperature (TFT) Sensor Circuit-Range/Performance	D		
P0712	Transmission Fluid Temperature Sensor Circuit Low Input (TFT)	D		
P0713	Transmission Fluid Temperature (TFT) Sensor Circuit High Input	D		
P0719	TCC Brake Switch Circuit High (Stuck ON)	D		
P0722	Transmission Output Speed Sensor (OSS) Low Input	B	ON	Flash
P0723	Transmission Output Speed Sensor (OSS) Intermittent	B	ON	Flash
P0724	TCC Brake Switch Circuit Low (Stuck OFF)	D		
P0730	Transmission Incorrect Gear Ratio Flash	C		Flash
P0742	Torque Converter Clutch (TCC) Circuit Stuck ON	B	ON	Flash
P0748	Pressure Control Solenoid (PCS) (FORCE MOTOR) Circuit Electrical	C		Flash
P0751	Shift Solenoid A Performance Without Input Speed	B	ON	Flash
P0753	Shift Solenoid A Electrical	B	ON	Flash
P0756	Shift Solenoid B Performance Without Input Speed	B	ON	Flash
P0758	Shift Solenoid B Electrical	B	ON	Flash
P1790	ROM Transmission Side Bad Check Sum	B	ON	Flash
P1792	EEPROM Transmission Side Bad Check Sum	B	ON	Flash
P1835	Kick Down Switch Always ON	D		
P1850	Brake Band Apply Solenoid Malfunction	D		
P1860	TCC Solenoid Electrical	B	ON	Flash
P1870	Transmission Component Slipping	B	ON	Flash

DTC TYPE	DEFINITION
B	Emission related, turn on MIL (Check Engine) and flashing Check Trans after 2 consecutive trips with failure
C	Non-emission related, flashing Check Trans on 1st failure
D	Non-emission related, no lamps

NOTE: On the following charts, refer to Powertrain Control Module (PCM) section for Wiring System and the Body and Accessories section for circuit diagram details, parts location, and connector configuration.

DTC P0218 Transmission Fluid Over Temperature

D07RW018

Circuit Description

The Transmission Fluid Temperature (TFT) sensor is a thermister that controls the signal voltage to the PCM. The PCM supplies a 5-volt reference to the sensor on circuit GRN/RED. When the transmission fluid is cold, the sensor resistance is high and the PCM will sense high signal voltage. As the fluid temperature warms to a normal transmission operating temperature of 100°C (212°F), the sensor resistance becomes less and the voltage decreases to 1.5 to 2.0 volts.

This DTC detects a high transmission temperature for a long period of time. This is a type "D" DTC.

Conditions For Setting The DTC

- No TFT DTCs P0712 or P0713.
- TFT is greater than 135°C (275°F).
- All conditions met for 21 seconds.

Action Taken When The DTC Sets

- Hot mode TCC Shift Pattern.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).
- ATF Lamp ON. (greater than 145°C (293°F))
- Disable E-side TCC OFF request.

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warm-up cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connections at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well.

Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.

- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- Check harness routing for a potential short to ground in circuit GRN/RED.
- Scan tool TFT sensor temperature should rise steadily to about 100°C (212°F), then stabilize.
- Check for a "skewed" (mis-scaled) sensor by comparing the TFT sensor temperature to the ambient temperature after a vehicle cold soak. A "skewed" sensor can cause delayed garage shifts or TCC complaints.
- Check for a possible torque converter stator problem.
- Verify customer driving habits, trailer towing, etc.

Test Description


The numbers below refer to the step numbers on the diagnostic chart.

3. This test checks for a "skewed" sensor or shorted circuit.
4. This test simulates a TFT DTC P0713.

DTC P0218 Transmission Fluid Over Temperature

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	Perform the following checks: <input type="radio"/> Check for possible engine system problems. <input type="radio"/> Transmission fluid checking procedure. Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) Section. Were the checks performed?	Go to Step 3	—
3	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when "Clear Info" function is used. 3. Record the DTC "Failure Records". Is the TFT sensor signal voltage less than 0.33 volts?	Go to Step 4	Go to Diagnostic Aids
4	1. Turn the ignition "off". 2. Disconnect the transmission 16-way connector H-10 (additional DTCs may set). Is the TFT sensor signal voltage greater than 4.92 volts?	Go to Internal Wiring Harness Check	Go to Step 5
5	Inspect/repair circuit GRN/RED for a short to ground. Was a problem found?	Go to Step 7	Go to Step 6
6	1. Inspect the PCM for poor connections. 2. Replace the PCM if no poor connections were found. Is the replacement complete?	Go to Step 7	—
7	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: TFT is less than 125°C (257°F) for at least 10 seconds. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0560 System Voltage Malfunction



D07RW019

Circuit Description

Circuit RED/WHT is the battery voltage feed for the PCM. Circuit RED/BLU is the ignition voltage feed for the PCM. This DTC detects a low voltage or a high voltage. This is a type "D" DTC.

Conditions For Clearing The DTC

System Voltage Low:

- Engine speed is greater than 1,000 rpm.
- System voltage is less than 10 volts at a maximum transmission temperature of 150°C (302°F).
- System voltage is less than 7.3 volts at a minimum transmission temperature of -40°C (-40°F).
- All conditions met for 4 seconds.

System Voltage High:

- System voltage is greater than 16 volts for 2 seconds.

Action Taken When The DTC Sets

- Fixed to 4th gear.
- Maximum line pressure.
- Inhibit TCC engagement.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Charging the battery with a battery charger and jump starting an engine may set DTC(s). If DTC(s) set when an accessory is operated, check for faulty connections or excessive current draw.
- Check for faulty connections at the starter solenoid or fusible link.
- Check for loose/damaged terminals at generator.
- Check belt wear/tension.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

- 4. This test checks charging system voltage.
- 5. This test checks battery voltage input at the PCM.
- 7. This test checks ignition voltage input at the PCM.


DTC P0560 System Voltage Malfunction

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Failure Records". Note: If any other DTCs are present, refer to their applicable diagnostic charts before continuing. 4. Using the J-39200 DVOM, measure the battery voltage across the battery terminals. Record the measurement for future reference. Is the voltage higher than 10.5 volts?	Go to Step 3	Go to Engine Electrical in Engine section
3	Start the engine and warm to normal operating temperature. Is the generator/check engine light "on"?	Go to Starting and Charging System in Engine section	Go to Step 4
4	1. Increase the engine speed to 1,000–1,500 rpm. 2. Observe scan tool system voltage. Is the system voltage within 13–15 volts.	Go to Step 5	Go to Starting and Charging System in Engine section
5	1. Turn the ignition switch "off". 2. Disconnect the C1(RED) and C3 (BLUE) PCM connector (additional DTCs will set). 3. With the engine "off", turn the ignition switch "on". 4. Using the J39200 DVOM, measure the battery voltage input at PCM connector terminals C1–A4 and C3–E16. Is there a voltage variance between the voltage measured at the battery (taken in Step 2) and at terminals C1–A4 and C3–E16 that is greater than 0.5 volts?	Go to Step 6	Go to Step 7
6	Repair the high resistance condition in circuit RED/WHT. Was the circuit repaired?	Go to Step 11	—
7	1. Disconnect the J3 (BLUE) PCM connector. 2. Measure the ignition voltage input at PCM connector terminals C3–E16 and C3–F16. Is there a voltage variance between the voltage measured at the battery (taken in Step 2) and at terminals C3–E16 and C3–F16 that is greater than 0.5 volts?	Go to Step 8	Go to Step 9
8	Repair the high resistance condition in circuit RED/BLU. Was the circuit repaired?	Go to Step 11	—
9	Check PCM connector terminals C1–A4, C3–E16 and C3–F16 for bent, damaged, or backed out connector pins. Also check for weak terminal tension. Was a problem found?	Go to Step 11	Go to Step 10

7A1-30 TRANSMISSION CONTROL SYSTEM (4L30-E)

DTC P0560 System Voltage Malfunction (Cont'd)

Step	Action	Yes	No
10	Replace the PCM. Is the replacement complete?	Go to Step 11	—
11	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle under the following conditions: Start the vehicle and warm to normal operating temperature. The PCM must see a system voltage between 10 and 16 volts. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0705 Transmission Range Switch (Mode Switch) Illegal Position

D07RW020

Circuit Description

- The range switch supplies the Powertrain Control Module (PCM) with information regarding the selector lever position: P, R, N, D 3, 2 or L. The selector lever position is indicated by the state of four ON/OFF contacts. The range switch is located on one side of the transmission. It is on the transmission manual shaft and is fixed to the main case.
- The range switch is also used to provide the information P or N to the engine crank wiring. The engine can be cranked only if connector M-16 terminal 4(H) is connected to terminal 1(E) which is connected to ground.
- The range switch is also used to provide the backup lamp power in reverse. This is the reason why the range switch is supplied through a 15A fuse (CB-15). This fuse can burn due to a short circuit in the back up lamp.

This DTC detects when a fuse is open or the range switch circuit does not work. This is a type "D" DTC.

Conditions For Setting The DTC

- Range switch illegal positions met for 5 seconds.

Action Taken When The DTC Sets

- Default to D position.
- Inhibit torque management.
- Maximum line pressure.

- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Refer to accompanying chart for the normal range signals and the illegal combinations.
- Inspect the wiring for poor electrical connections at the PCM and at the transmission 8-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- Refer to the "Range Switch Logic Table" or "Functional Test Procedure" for further information.

7A1-32 TRANSMISSION CONTROL SYSTEM (4L30-E)

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This test checks the indicated range signal to the manual valve actually selected.
6. This test checks for continuity between each selected range switch connector terminals.


Range Switch Logic Table

Range Position	Range Switch Pin			
	A	B	C	P(G)
Park	ON	OFF	OFF	ON
Reverse	ON	ON	OFF	OFF
Neutral	OFF	ON	OFF	ON
D4	OFF	ON	ON	OFF
D3	ON	ON	ON	ON
2	ON	OFF	ON	OFF
L	OFF	OFF	ON	ON
Illegal	OFF	OFF	OFF	OFF
Illegal	OFF	OFF	OFF	ON

DTC P0705 Transmission Range Switch (Mode Switch) Illegal Position

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	Perform the following checks: ○ The transmission linkage from the select lever to the manual valve is adjusted properly. ○ Diagnostic circuit check. Were the checks performed?	Go to Step 3	—
3	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Select each transmission range: D1, D2, D3, D4, N, R, and P. Does each selected transmission range match the scan tool "Range Switch" display?	Go to Diagnostic Aids	Go to Step 4
4	Are all range switch pin displays incorrect?	Go to Step 5	Go to Step 6
5	Check fuse and wiring to the 8-way connector terminal 5(D) for opens. Refer to Mode Switch in Automatic Transmission (4L30-E) section. If no problem was found, replace the range switch. Is the replacement complete?	Go to Step 9	—
6	1. Disconnect the 8-way range switch connector. 2. Using ohmmeter, check continuity between terminal 5(D) and respectively terminals 3(G), 6(C), 7(B) and 8(A) of the 8-way range switch connector. 3. Move shift selector lever through all positions and compare results with "Range Switch Logic Table". Is one range switch pin display incorrect?	Go to Step 7	Go to Step 8
7	Check the affected wiring and connector, and repair. Is the repair complete?	Go to Step 9	—
8	Check the Powertrain Control Module (PCM) connectors for poor connection. If no problem was found, replace the PCM. Is the replacement complete?	Go to Step 9	—
9	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and road test the vehicle. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0706 Transmission Range Switch (Mode Switch) Performance



D07RW020

Circuit Description

- The range switch supplies the Powertrain Control Module (PCM) with information regarding the selector lever position: P, R, N, D, 3, 2 or L. The selector lever position is indicated by the state of four ON/OFF contracts. The range switch is located on one side of the transmission. It is on the transmission manual shaft and is fixed to the main case.
- The range switch is also used to provide the information P or N to the engine crank wiring. The engine can be cranked only if connector M-16 terminal 4(H) is connected to terminal 1(E) which is connected to ground.
- The range switch is also used to provide the back up lamp power in reverse. This is the reason why the mode switch is supplied through a 15A fuse (CB-15). This fuse can burn due to a short circuit in the back up lamp.
- This DTC detects an invalid state of the range switch or the range switch circuit by deciphering the range switch inputs. This is a type "D" DTC.

Conditions For Setting The DTC

This DTC will set if any of the following conditions occurs:

Condition 1 ("R" bad position):

- Engine is running.
- No output speed DTCP0722, P0723.

- Output speed greater than 3,200 RPM.
- Range switch indicates "R".
- All conditions met for 4 seconds.

Condition 2 ("P" or "N" bad position):

- Engine is running.
- No TPS codes.
- Engine speed is less than 3,000 RPM.
- TP angle is greater than 20%.
- Range switch indicates "P" or "N".
- All conditions met for 4 seconds.

Action Taken When The DTC Sets

- Default to "D" position.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Refer to the accompanying chart for the normal range signals and the illegal combinations.
- Inspect the wiring for poor electrical connections at the PCM and at the transmission 8-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- Refer to the "Range Switch Logic Table" or "Functional Test Procedure" for further information.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This test checks the indicated range signal to the manual valve actually selected.
6. This test checks for continuity between each selected range switch connector terminals.


Range Switch Logic Table

Range Position	Range Switch Pin			
	A	B	C	P(G)
Park	ON	OFF	OFF	ON
Reverse	ON	ON	OFF	OFF
Neutral	OFF	ON	OFF	ON
D4	OFF	ON	ON	OFF
D3	ON	ON	ON	ON
2	ON	OFF	ON	OFF
L	OFF	OFF	ON	ON
Illegal	OFF	OFF	OFF	OFF
Illegal	OFF	OFF	OFF	ON

DTC P0706 Transmission Range Switch (Mode Switch) Performance

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	Perform the following checks: ○ The transmission linkage from the select lever to the manual valve is adjusted properly. ○ Diagnostic circuit check. Were the checks performed?	Go to Step 3	—
3	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Select each transmission range: D1, D2, D3, D4, N, R, and P. Does each selected transmission range match the scan tool "Range Switch" display?	Go to Diagnostic Aids	Go to Step 4
4	Are all range switch pin displays incorrect?	Go to Step 5	Go to Step 6
5	Check fuse and wiring to the 8-way connector terminal 5(D) for opens. Refer to Mode Switch in Automatic Transmission (4L30-E) section. If no problem was found, replace the range switch. Is the replacement complete?	Go to Step 9	—
6	1. Disconnect the 8-way range switch connector. 2. Using ohmmeter, check continuity between terminal 5(D) and respectively terminals 3(G), 6(C), 7(B) and 8(A) of the 8-way range switch connector. 3. Move shift selector lever through all positions and compare results with "Range Switch Logic Table". Is one range switch pin display incorrect?	Go to Step 7	Go to Step 8
7	Check the affected wiring and connector, and repair. Is the repair complete?	Go to Step 9	—
8	Check the Powertrain Control Module (PCM) connectors for poor connection. If no problem was found, replace the PCM. Is the replacement complete?	Go to Step 9	—
9	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and road test the vehicle. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0711 Transmission Fluid Temperature (TFT) Sensor Circuit Range/Performance



D07RW018

Circuit Description

The TFT sensor is a thermister that controls the signal voltage to the PCM. The PCM supplies a 5 volt reference signal to the sensor on circuit GRN/RED. When the transmission fluid is cold, the sensor resistance is high and the PCM detects high signal voltage. As the transmission fluid temperature increases to normal operating temperature of 100°C (212°F), the sensor resistance becomes less and the voltage decreases to 1.5 to 2 volts.

When the PCM detects a TFT sensor that remains at the startup value, or a sensor that has a change delta of greater than 20°C (36°F) less than 1 second, DTC P0711 sets. DTC P0711 is a type D.

Conditions For Setting The DTC

- No VSS DTCs P0722 or P0723.
- No Transmission Component Slipping DTC P1870.
- Engine running.
- TFT is between 20 A/D (Analog/Digital) counts and 248 A/D counts.
- TFT is between -40°C (-40°F) and +21°C (69.8°F) at engine startup.
- Engine coolant temperature is greater than 70°C (150°F).
- Engine coolant temperature has changed by greater than 50°C (90°F) since engine startup.
- Vehicle speed has been greater than 5 mph for greater than 410 seconds since engine startup (cumulative timer).
- TCC slip speed has been greater than 120 rpm for greater than 410 seconds since engine startup (cumulative timer).
- Battery voltage is between 10 and 16 volts.

All of the above is true and either of the following occurs:

- If the sensor is stuck, the TFT has not changed for greater than 2 counts (from startup temperature) for greater than 410 seconds.
- If the sensor shows an unrealistic change, the TFT exhibits a change delta of greater than 20°C (36°F), greater than 14 times in 7 seconds.

Action Taken When The DTC Sets

- Transmission default temperature will be:
 - 80°C (176°F) if engine temperature code is set.
 - 100°C (212°F) if engine temperature is warm.
 - 80°C (176°F) if engine run time is greater than 5 minutes.
 - 21°C (69.8°F) if engine run time is less than 5 minutes.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connection at the PCM. Inspect the wiring for poor electrical connections at the transmission 16-way connector H-10. Look for the following conditions:
 - a. A bent terminal
 - b. A backed out terminal

7A1-38 TRANSMISSION CONTROL SYSTEM (4L30-E)

- c. A damaged terminal
 - d. Poor terminal tension
 - e. A chafed wire
 - f. A broken wire inside the insulation
- When diagnosing for an intermittent short or open connection, move the wiring harness while watching the test equipment for a change.
- First diagnose and clear any engine DTCs or TP Sensor codes. Then inspect for any transmission DTCs that may have reset.

Resistance Chart

°C	°F	Resistance (kΩ)
-40	-40	672
0	32	65
20	68	25
80	176	2.5
120	248	0.78
150	304	0.37

Test Description

The number below refers to the step number on the diagnostic chart:


3. This test checks PCM and associated wiring up to the 16-way connector H-10. If the voltage increases to match chart the problem is isolated to the transmission wiring.

DTC P0711 Transmission Fluid Temperature (TFT) Sensor Circuit Range/Performance

Step	Action	Yes	No
1	Was the Powertrain On-Board Diagnostic (OBD) System Check performed?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	Perform the transmission fluid checking procedure. Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section. Did you perform the fluid checking procedure?	Go to Step 3	Go to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section
3	1. Install the scan tool. 2. With the engine "off", turn the ignition switch to the "on" position. NOTE: Before clearing DTCs, use the scan tool in order to record the Freeze Frame and Failure Records for reference. The Clear Info function will erase the data. 3. Record the DTC Freeze Frame and Failure Records. 4. Select TFT on the scan tool. 5. While observing the scan tool display, move or massage the engine wiring harness from PCM connectors F7 and D9 to the transmission 16-way connector H-10. Does the TFT change by more than $\pm 20^{\circ}\text{C}$ (36°F)?	Go to Step 6	Go to Step 4

DTC P0711 Transmission Fluid Temperature (TFT) Sensor Circuit Range/Performance (Cont'd)

Step	Action	Yes	No
4	<ol style="list-style-type: none"> 1. Turn the ignition "off". 2. Disconnect the transmission 16-way connector H-10. 3. Install Jumper Harness on the transmission side of the 16-way connector H-10. 4. Using the J39200 DVOM and J35616 Connector Test Adapter Kit, connect the DVOM leads from terminal M6-3(C) to terminal M6-5(D). 5. Set the DVOM on MIN/MAX to measure resistance. 6. Record the TFT sensor resistance. 7. Move or massage the automatic transmission wiring harness assembly from the 16-way connector H-10 to the TFT sensor connector. <p>Does the DVOM MAX display a resistance greater than the value recorded in Action item 6 of this step?</p>	Go to Step 7	Go to Step 5
5	<p>Does the DVOM MIN display a resistance less than the value recorded in Action item 6 of step 4?</p>	Go to Step 8	—
6	<p>Inspect circuit GRN/RED and GRN of the engine wiring harness for an intermittent open or short condition. Repair the circuits if necessary.</p> <p>Did you find a problem?</p>	Go to Step 12	Go to Step 11
7	<p>Inspect the automatic transmission wiring harness assembly for an intermittent open in circuits GRN/RED and GRN, BLU/YEL.</p> <p>Did you find a problem?</p>	Go to Step 9	Go to Step 10
8	<p>Inspect the automatic transmission wiring harness assembly for an intermittent shorted condition in circuits GRN/RED and GRN, BLU/YEL.</p> <p>Did you find a problem?</p>	Go to Step 9	Go to Step 10
9	<p>Replace the automatic transmission wiring harness assembly.</p> <p>Is the replacement complete?</p>	Go to Step 12	—
10	<p>Replace TFT Sensor. Refer to Transmission Oil Temperature Sensor (Adapter Case) in Automatic Transmission (4L30-E) section.</p> <p>Is the replacement complete?</p>	Go to Step 12	—
11	<p>Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section.</p> <p>Is the replacement complete?</p>	Go to Step 12	—
12	<p>In order to verify your repair, perform the following procedure.</p> <ol style="list-style-type: none"> 1. Select DTC. 2. Select Clear Info. 3. Drive the vehicle and ensure the following conditions are met: <ul style="list-style-type: none"> ○The TFT changes by more than 2.25°C (4.05°F) for 11 seconds since startup. ○The TFT does not change by more than 20°C (36°F) within 0.200 second for a period of at least 11 seconds. 4. Select Specific DTC. 5. Enter DTC P0711. <p>Has the test run and passed?</p>	System OK	<p>Begin the diagnosis again</p> <p>Go to Step 1</p>

DTC P0712 Transmission Fluid Temperature (TFT) Sensor Circuit Low Input

D07RW018

Circuit Description

The TFT sensor is a thermister that controls the signal voltage to the PCM. The PCM supplies a 5-volt reference signal to the sensor on circuit GRN/RED. When the transmission fluid is cold, the sensor resistance is high. The PCM detects high signal voltage. As the transmission fluid temperature increases to the normal operating temperature of 100°C (212°F), the sensor resistance becomes less and the voltage decreases to 1.5 to 2 volts. With transmission fluid over temperature and DTC P0218 also set, check the transmission cooling system.

This DTC detects a continuous short to ground in the TFT signal circuit or the TFT sensor. This is a type "D" DTC.

Conditions For Setting The DTC

- Battery voltage is between 10 and 16 volts.
- Ignition is "on".
- TFT sensor indicating a voltage less than 0.4 volts.
- All conditions met for 20 seconds.

Action Taken When The DTC Sets

- Transmission default temperature will be:
 - 80°C (176°F) if engine temperature code is set.
 - 100°C (212°F) if engine temperature is warm.
 - 80°C (176°F) if engine run time is greater than 5 minutes.
 - 21°C (69.8°F) if engine run time is less than 5 minutes.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Check harness routing for a potential short to ground in circuit GRN/RED. Scan tool TFT display should rise steadily to about 100°C (212°F), then stabilize.
- Inspect the wiring for poor electrical connection at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- The temperature to resistance value scale may be used to test the TFT sensor at the various temperature levels to evaluate the possibility of a "skewed" (mis-scaled) sensor.
 - A "skewed" sensor could result in delayed garage shifts or TCC complaints.
- Verify customer driving habits, trailer towing, etc.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This test checks for a short to ground or a "skewed" sensor.
4. This test checks for an internal fault within the transmission by creating an open.

Resistance Chart


°C	°F	Resistance (kΩ)
-40	-40	672
0	32	65
20	68	25
80	176	2.5
120	248	0.78
150	304	0.37

DTC P0712 Transmission Fluid Temperature (TFT) Sensor Circuit Low Input

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	Perform the transmission fluid checking procedure. Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section Was the fluid checking procedure performed?	Go to Step 3	Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section
3	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". Does the scan tool display a TFT sensor signal voltage less than 0.4 volts?	Go to Step 4	Go to Diagnostic Aids
4	1. Turn the ignition "off". 2. Disconnect the transmission 16-way connector H-10. 3. Turn the ignition "on". Does the TFT signal voltage change to match the voltage 4.92 volts?	Go to Step 5	Go to Step 10
5	Using the J39200 DVOM, measure the resistance between terminals 3(C) and 5 (D). Is the resistance within specifications? (See Resistance Chart.)	Go to Diagnostic Aids	Go to Step 6
6	1. Disconnect the transmission 5-way connector M-6. 2. Using the J39200 DVOM, measure the resistance between terminals 3(C) and 5(D). Is the resistance within specifications? (See Resistance Chart.)	Go to Diagnostic Aids	Go to Step 7
7	1. Remove the transmission oil pan. Refer to Transmission Oil Temperature Sensor (Adapter Case) in Automatic Transmission (4L30-E) section. 2. Check the internal wiring harness for a short to ground. Was a problem found?	Go to Step 9	Go to Step 8

7A1-42 TRANSMISSION CONTROL SYSTEM (4L30-E)**DTC P0712 Transmission Fluid Temperature (TFT) Sensor Circuit Low Input (Cont'd)**

Step	Action	Yes	No
8	1. Disconnect the internal wiring harness at the TFT sensor. 2. Measure the resistance of the TFT sensor. Is the resistance within specifications? (See Resistance Chart.)	Go to Diagnostic Aids	Go to Step 9
9	Replace the TFT Sensor. Is the replacement complete?	Go to Step 13	—
10	Check circuit GRN/RED for a short to ground. Was a problem found?	Go to Step 13	Go to Step 11
11	Check the PCM for faulty connections. Was a problem found?	Go to Step 13	Go to Step 12
12	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 13	—
13	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: TFT sensor indicates a voltage greater than 0.33 volts for 2 seconds. 2. Review the scan tool "DTC info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0713 Transmission Fluid Temperature (TFT) Sensor Circuit High Input

D07RW018

Circuit Description

The TFT sensor is a thermistor that controls the signal voltage to the PCM. The PCM supplies a 5-volt reference signal to the sensor on circuit GRN/RED. When the transmission fluid is cold, the sensor resistance is high and the PCM will sense high signal voltage. As the transmission fluid temperature warms to the normal operating temperature of 100°C (212°F), the sensor resistance becomes less and the voltage decreases to about 1.5 to 2 volts.

This DTC detects a continuous open or short to power in the TFT signal circuit or the TFT sensor. This is a type "D" DTC.

Conditions For Setting The DTC

- Battery voltage is between 10 and 16 volts.
- Ignition is "on".
- TFT sensor indicating a voltage greater than 4.86 volts.
- All conditions met for 20 seconds.

Action Taken When The DTC Sets

- Transmission default temperature will be:
 - 80°C (176°F) if engine temperature code is set.
 - 100°C (212°F) if engine temperature is warm.
 - 80°C (176°F) if engine run time is greater than 5 minutes.
 - 21°C (69.8°F) if engine run time is less than 5 minutes.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connection at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- Scan tool displays transmission fluid temperature in degrees. After transmission is operating, the temperature should rise steadily to about 100°C (212°F), then stabilize.
- The temperature to resistance value scale may be used to check the TFT sensor at the various temperature levels to evaluate the possibility of a "skewed" (mis-scaled) sensor.

A "skewed" sensor could result in hard shifts or TCC complaints.

7A1-44 TRANSMISSION CONTROL SYSTEM (4L30-E)

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This check verifies problem in the TFT sensor circuit.
4. This test simulates a TFT sensor DTC P0712. If the PCM recognizes the low signal voltage (high temperature), and the scan tool displays 146°C (295°F) or greater, the PCM and wiring are OK.
5. This test checks the TFT sensor and internal wiring harness.

Resistance Chart


°C	°F	Resistance (kΩ)
-40	-40	672
0	32	65
20	68	25
80	176	2.5
120	248	0.78
150	304	0.37

DTC P0713 Transmission Fluid Temperature (TFT) Sensor Circuit High Input

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	Perform the transmission fluid checking procedure. Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section. Was the fluid checking procedure performed?	Go to Step 3	Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section
3	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". Does the scan tool display a TFT sensor signal voltage greater than 4.86 volts?	Go to Step 4	Go to Diagnostic Aids
4	1. Turn the ignition "off". 2. Disconnect the transmission 16-way connector H-10. 3. Install a fused jumper wire from terminal 3(C) to 5(D) on the engine harness. 4. Turn the ignition "on". Does the TFT signal voltage drop to less than 0.4 volts?	Go to Step 5	Go to Step 10
5	1. Turn the ignition "off". 2. Using the J39200 DVOM, measure the resistance between terminals 3(C) and 5(D). Is the resistance within specifications? (See Resistance Chart.)	Go to Diagnostic Aids	Go to Step 6
6	1. Disconnect the transmission 5-way connector M-6. 2. Using the J39200 DVOM, measure the resistance between terminals 3(C) and 5(D). Is the resistance within specifications? (See Resistance Chart.)	Go to Diagnostic Aids	Go to Step 7

DTC P0713 Transmission Fluid Temperature (TFT) Sensor Circuit High Input (Cont'd)

Step	Action	Yes	No
7	1. Remove the transmission oil pan. 2. Check the internal wiring harness for an open. Refer to Transmission Oil Temperature Sensor (Adapter Case) in Automatic Transmission (4L30-E) section. Was a problem found and corrected?	Go to Step 14	Go to Step 8
8	1. Disconnect the internal wiring harness at the TFT sensor. 2. Measure the resistance of the TFT sensor. Is the resistance within specifications? (See Resistance Chart.)	Go to Diagnostic Aids	Go to Step 9
9	Replace TFT sensor. Refer to Transmission Oil Temperature Sensor (Adapter Case) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 14	—
10	Check circuit GRN/RED for an open or short to B+. Was a problem found?	Go to Step 14	Go to Step 11
11	Check circuit GRN, BLU/YEL for an open. Was a problem found?	Go to Step 14	Go to Step 12
12	Check the PCM for faulty or intermittent connections. Was a problem found?	Go to Step 14	Go to Step 13
13	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 14	—
14	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: 2. TFT sensor indicates a voltage less than 4.92 volts for 2 seconds. 3. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0719 TCC Brake Switch Circuit High (Stuck On)

D07RW021

Circuit Description

The TCC brake switch is used to indicate brake pedal status. The normally opened brake switch signal voltage circuit is opened.

Brake switch supplies a B+ signal on circuit RED to the PCM, when the brakes are applied. The PCM uses this signal to deenergize the TCC solenoid when the brakes are applied.

This DTC detects a closed brake switch during accelerations. This is a type "D" DTC.

Conditions For Setting The DTC

- No OSS DTCs P0722 or P0723.
- The PCM detects a closed brake switch/circuit (12 volts) for 2 seconds, and the following events occur seven consecutive times: vehicle speed is less than 8 km/h (5 mph); then vehicle speed is between 8 and 32 km/h (5 and 20 mph) for 4 seconds; then vehicle speed is greater than 32 km/h (20 mph) for 4 seconds.

Action Taken When The DTC Sets

- If throttle opening is greater than 10% and vehicle speed is greater than 45 km/h (28 mph), then disregard brake switch contingency for TCC off mode.
- The PCM will not illuminate Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.

- The DTC will be cleared from history when the vehicle has achieved 40 warm-up cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connections at the PCM and TCC brake switch. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move or massage the wiring harness while observing test equipment for a change.
- Check customer driving habits and/or unusual driving conditions (i.e. stop and go, highway).
- Check brake switch for proper mounting and adjustment.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

- 3. This test checks for voltage at the brake switch.
- 6. This test checks the brake switch.
- 9. This test checks circuit RED at the PCM.

DTC P0719 TCC Brake Switch Circuit High (Stuck On)


Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". If ABS code is set, check applicable fuse. NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Apply then release the brake pedal. Does the scan tool display "TCC Brake Switch" as "closed" with the brake pedal applied, and then display "open" when the brake pedal is released?	Go to Diagnostic Aids	Go to Step 3
3	1. Connect the test light to ground. 2. Back probe ignition feed circuit terminal I18-1 at the brake switch. Is the test light "on"?	Go to Step 4	Go to Step 5
4	1. Connect the test light to ground. 2. Back probe circuit terminal I18-4 at the brake switch. Is the test light "off"?	Go to Step 8	Go to Step 6
5	Repair the open in battery feed circuit terminal I18-1 to the brake switch. If fuse is open, check circuit terminal I18-4 for a short to ground. Is the repair complete?	Go to Step 14	—
6	Disconnect brake switch connector I-18 and ignition switch "on". Is the test light "on"?	Go to Step 9	Go to Step 7
7	Check the brake switch short (I18-1 and I18-4). Was a problem found?	Go to Step 10	Go to Step 11
8	Check circuit terminal I18-4 for a short to voltage. Ignition switch "on". Is the test light "on"?	Go to Step 9	Go to Step 11
9	1. Disconnect the C3 (BLUE) PCM connector. 2. Check circuit terminal I18-4 for a short to voltage. Was a problem found?	Go to Step 14	Go to Step 11
10	Replace the brake switch. Is the replacement complete?	Go to Step 14	—
11	1. Turn the ignition "off". 2. Reconnect the C3 (BLUE) PCM connector. 3. Turn the ignition "on". Does the scan tool display "TCC Brake Switch" as "open" with the brake applied, then display "closed" with the brake pedal released?	Go to Diagnostic Aids	Go to Step 12
12	Check the PCM for faulty or intermittent connections. Was a problem found and corrected?	Go to Step 14	Go to Step 13

7A1-48 TRANSMISSION CONTROL SYSTEM (4L30-E)

DTC P0719 TCC Brake Switch Circuit High (Stuck On) (Cont'd)

Step	Action	Yes	No
13	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 14	—
14	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: The PCM brake switch signal must indicate 0 volts for 1 seconds with the brake pedal applied. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0722 Transmission Output Speed Sensor (OSS) Low Input



D07RW022

Circuit Description

Output speed information is provided to the PCM by the OSS, which is a permanent magnet (PM) generator. The PM generator produces a pulsing AC voltage. The AC voltage level and number of pulses increases as the speed of the vehicle increases. The PCM then converts the pulsing voltage to output speed, which is used for calculations. The vehicle speed can be displayed with a scan tool.

This DTC detects a low output speed when there is a high engine speed in a drive gear range. This is a type "B" DTC.

Conditions For Setting The DTC

- No MAP DTCs P0107 or P0108, P0106, P1106, P1107.
- No TP DTCs P0122 or P0123.
- Not in Park or Neutral.
- TP angle is greater than 10%.
- Engine vacuum is between 0 and 70kPa.
- Engine speed is between 3000 and 7000 rpm.
- Transmission output speed is less than 0 rpm.
- All conditions met for 5 seconds.

Action Taken When The DTC Sets

- Fixed to 4th gear.
- Maximum line pressure.
- Inhibit TCC engagement.
- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool. The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- An OSS DTC P0722 will set when no output speed is detected at start off.
- Inspect the wiring for poor electrical connection at the PCM. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move or massage the wiring harness while observing test equipment for a change.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

5. This test checks the OSS circuit.
6. This test checks the integrity of the OSS.
8. This test checks the 5-volt and ground circuit of the PCM.


7A1-50 TRANSMISSION CONTROL SYSTEM (4L30-E)

DTC P0722 Transmission Output Speed Sensor (OSS) Low Input

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	<ol style="list-style-type: none"> 1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". <p>NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used.</p> <ol style="list-style-type: none"> 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Raise the drive wheels. 5. Start the engine. 6. Place the transmission in any drive range. <p>With the drive wheels rotating, does the "Trans Output Speed" increase with the drive wheel speed?</p>	Go to Diagnostic Aids	Go to Step 3
3	Does the speedometer work?	Go to Step 4	Go to Step 5
4	<p>Check for the most current and/or incorrect calibration.</p> <p>Is the calibration current?</p>	Go to Step 17	Go to Step 5
5	<ol style="list-style-type: none"> 1. Turn the ignition "off". 2. Disconnect the C3 (BLUE) PCM connector. 3. Using the J39200 DVOM, measure the resistance between harness connector terminals C3-E1 and C3-E2. <p>Is the reading 3000 ohms?</p>	Go to Step 6	Go to Step 7
6	<ol style="list-style-type: none"> 1. Select AC volts. 2. Rotate the rear wheels, ensuring the driveshaft is turning. <p>Is the voltage greater than 0.5 volts?</p>	Go to Step 8	Go to Step 9
7	<p>Inspect circuits YEL and BRN for a poor connection or an open circuit.</p> <p>Was a problem found?</p>	Go to Step 18	Go to Step 9
8	<ol style="list-style-type: none"> 1. Reconnect the C3 (BLUE) PCM connector. 2. Disconnect the OSS harness from the OSS. 3. With the engine "off", turn the ignition "on". 4. Using the J 39200 DVOM, measure the voltage at the OSS harness connector terminals M15-1 and M15-2. <p>Is the reading between 4.0 to 5.1 volts?</p>	Go to Step 17	Go to Step 11
9	<ol style="list-style-type: none"> 1. Remove the OSS. 2. Check the output shaft speed sensor rotor for damage or misalignment. Refer to Speed Sensor (Extension Housing) in Automatic Transmission (4L30-E) section. <p>Was a problem found?</p>	Go to Step 18	Go to Step 10
10	<p>Replace the OSS.</p> <p>Is the replacement complete?</p>	Go to Step 18	—
11	Was the reading in step 8 less than 4.0 volts?	Go to Step 13	Go to Step 12
12	Was the reading in Step 8 greater than 5.1 volts?	Go to Step 16	—
13	<p>Using the J 39200 DVOM to chassis ground, measure the voltage on circuit RED.</p> <p>Is the reading between 4.0 to 5.1 volts?</p>	Go to Step 14	Go to Step 15

DTC P0722 Transmission Output Speed Sensor (OSS) Low Input (Cont'd)

Step	Action	Yes	No
14	Repair the open in circuit BRN. Is the repair complete?	Go to Step 18	—
15	Check circuit YEL for a short to ground or open. Was a problem found and corrected?	Go to Step 18	Go to Step 17
16	Repair the short to B+ in circuit YEL. Is the repair complete?	Go to Step 18	—
17	Replace the PCM. Refer to Powertrain Control Module (PCM) in automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 18	—
18	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle under the following conditions: Transmission output speed is greater than 101 rpm for 3 seconds. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0723 Transmission Output Speed Sensor (OSS) Intermittent

D07RW022

Circuit Description

Output speed information is provided to the PCM by the OSS, which is a permanent magnet (PM) generator. The PM generator produces a pulsing AC voltage. The AC voltage level and number of pulses increases as the speed of the vehicle increases. The PCM then converts the pulsing voltage to output speed, which is used for calculations. The vehicle speed can be displayed with a scan tool.

This DTC detects a low output speed when there is a high engine speed in a drive gear range. This is a type "B" DTC.

Conditions For Setting The DTC

In Park or Neutral:

- Transmission output speed change is greater than 10000 rpm.
- Conditions met for 6 seconds.
- Engine running time is greater than 2 seconds.

Not in Park or Neutral:

- Transmission output speed change is greater than 512 rpm.
- Conditions met for 0.075 seconds
- Engine running time is greater than 2 seconds.
- Engine vacuum is less than 70 kPa.
- Output speed is greater than 1380 rpm for 1 second.
- NORAW-NOLAST < 60 rpm for 6 seconds.
 - NORAW: Latest raw data of output shaft speed.
 - NOLAST: Filtered previous data of output speed.

Action Taken When The DTC Sets

- Fixed to 4th gear.
- Maximum line pressure.
- Inhibit TCC engagement.

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- A OSS DTC P0723 will set when output speed has been detected and is lost.
- Inspect the wiring for poor electrical connection at the PCM. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:


5. This test checks the OSS circuit.
6. This test checks the integrity of the OSS.
8. This test checks the 5-volt and ground circuit of the PCM.

DTC P0723 Transmission Output Speed Sensor (OSS) Intermittent

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Raise the drive wheels. 5. Start the engine. 6. Place the transmission in any drive range. With the drive wheels rotating, does the "Trans Output Speed" increase with the drive wheel speed?	Go to Diagnostic Aids	Go to Step 3
3	Does the speedometer work?	Go to Step 4	Go to Step 5
4	Check for the most current and/or incorrect calibration. Is the calibration current?	Go to Step 17	Go to Step 5
5	1. Turn the ignition "off". 2. Disconnect the C3 (BLUE) PCM connector. 3. Using the J39200 DVOM, measure the resistance between harness connector terminals C3-E1 and C3-E2. Is the reading 3,000 ohms?	Go to Step 6	Go to Step 7
6	1. Select AC volts. 2. Rotate the rear wheels, ensuring the driveshaft is turning. Is the voltage greater than 0.5 volts?	Go to Step 8	Go to Step 9
7	Inspect circuits YEL and BRN for a poor connection or an open circuit. Was a problem found?	Go to Step 18	Go to Step 9
8	1. Reconnect the C3 (BLUE) PCM connector. 2. Disconnect the OSS harness from the OSS. 3. With the engine "off", turn the ignition "on". 4. Using the J 39200 DVOM, measure the voltage at the OSS harness connector terminals M15-1 and M15-2. Is the reading between 4.0 to 5.1 volts?	Go to Step 17	Go to Step 11
9	1. Remove the OSS. 2. Check the output shaft speed sensor rotor for damage or misalignment. Refer to Speed Sensor (Extension Housing) in Automatic Transmission (4L30-E) section. Was a problem found?	Go to Step 18	Go to Step 10
10	Replace the OSS. Is the replacement complete?	Go to Step 18	—
11	Was the reading in step 8 less than 4.0 volts?	Go to Step 13	Go to Step 12
12	Was the reading in Step 8 greater than 5.1 volts?	Go to Step 16	—
13	Using the J 39200 DVOM to chassis ground, measure the voltage on circuit YEL. Is the reading between 4.0 to 5.1 volts?	Go to Step 14	Go to Step 15

7A1-54 TRANSMISSION CONTROL SYSTEM (4L30-E)**DTC P0723 Transmission Output Speed Sensor (OSS) Intermittent (Cont'd)**

Step	Action	Yes	No
14	Repair the open in circuit BRN. Is the repair complete?	Go to Step 18	—
15	Check circuit YEL for a short to ground or open. Was a problem found and corrected?	Go to Step 18	Go to Step 17
16	Repair the short to B+ in circuit YEL. Is the repair complete?	Go to Step 18	—
17	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 18	—
18	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle under the following conditions: Transmission output speed is greater than 101 rpm for 3 seconds. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0724 TCC Brake Switch Circuit Low (Stuck Off)

D07RW021

Circuit Description

The TCC brake switch is used to indicate brake pedal status. The normally opened brake switch signal voltage supplies a B+ signal on circuit GRN/YEL to the PCM when the brakes are applied. The PCM uses this signal to deenergize the TCC solenoid when the brakes are applied.

This DTC detects an open brake switch during decelerations. This is a type "D" DTC.

Conditions For Setting The DTC

- No OSS DTCs P0722 or P0723.
- The PCM detects an open brake switch/circuit (0 volts) during decelerations and the following events occur seven consecutive times: vehicle speed is greater than 32 km/h (20 mph) for 4 seconds; then vehicle speed is between 8 and 32 km/h (5 and 20 mph) for 4 seconds; then vehicle speed is less than 8 km/h (5 mph).

Action Taken When The DTC Sets

- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.

- The DTC will also be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connection at the PCM. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- Check customer driving habits and/or unusual traffic conditions (i.e. stop and go, expressway).
- Check brake switch for proper mounting and adjustment.

Test Description


The numbers below refer to the step numbers on the diagnostic chart:

- 3. This test checks for voltage at the brake switch.
- 6. This test checks the brake switch.

DTC P0724 TCC Brake Switch Circuit Low (Stuck Off)

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emissions in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Failure Records". 4. Apply then release the brake pedal. Does the scan tool display "TCC Brake Switch" as "closed" with the brake pedal applied, and then display "open" when the brake pedal is released?	Go to Diagnostic Aids	Go to Step 3
3	1. Connect the test light to ground. 2. Back probe ignition feed circuit terminal I18-1 at the brake switch. Is the test light "on"?	Go to Step 4	Go to Step 5
4	1. Connect the test light to ground. 2. Back probe circuit terminal I18-4 at the brake switch. 3. Apply the brake pedal. Is the test light "on" when the brake pedal is applied?	Go to Step 7	Go to Step 6
5	Repair the open in ignition feed circuit terminal I18-1 to the brake switch. If fuse is open, check circuit terminal I18-4. Is the repair complete?	Go to Step 11	—
6	1. Disconnect I18 connector. 2. Check the resistance between terminal I18-1 and I18-4. Is the resistance 0 ohm with the brake pedal applied?	Go to Step 7	Go to Step 8
7	Check circuit terminal I18-4 for a open. Was a problem found?	Go to Step 11	Go to Step 9
8	Replace the brake switch. Is the replacement complete?	Go to Step 11	—
9	Check PCM for faulty connections. Was a problem found?	Go to Step 11	Go to Step 10
10	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 11	—
11	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: The PCM brake switch signal must indicate 12 volts for 1 seconds with the brake pedal released. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0730 Transmission Incorrect Gear Ratio



RANGE	GEAR	SOL A N.C.	SOL B N.O.	O/DRIVE ROLLER CLUTCH (OFW)	OVERRUN CLUTCH (OC)	FOURTH CLUTCH (C4)	THIRD CLUTCH (C3)	REVERSE CLUTCH (RC)	SECOND CLUTCH (C2)	PRINCIPLE SPRAG ASSEMBLY (PFW)	BAND ASSEMBLY (B)	ENGINE BRAKING
P-N		OFF	ON		APPLIED							NO
R	REVERSE	OFF	ON	LD	APPLIED			APPLIED		LD		NO
D	1ST	OFF	ON	LD	APPLIED					LD	APPLIED	NO
	2ND	ON	ON	LD	APPLIED				APPLIED	FW	APPLIED	YES
	3RD	ON	OFF	LD	APPLIED		APPLIED		APPLIED	NE		YES
	4TH	OFF	OFF	FW		APPLIED	APPLIED		APPLIED	NE		YES
3	1ST	OFF	ON	LD	APPLIED					LD	APPLIED	NO
	2ND	ON	ON	LD	APPLIED				APPLIED	FW	APPLIED	YES
	3RD	ON	OFF	LD	APPLIED		APPLIED		APPLIED	NE		YES
2	1ST	OFF	ON	LD	APPLIED		APPLIED			LD	APPLIED	YES
	2ND	ON	ON	LD	APPLIED				APPLIED	FW	APPLIED	YES
L	1ST	OFF	ON	LD	APPLIED		APPLIED			LD	APPLIED	YES

LD : LOCKED IN DRIVE

FW : FREEWHEELING

NE : NOT EFFECTIVE

D07RT015

Circuit Description

- The Powertrain Control Module (PCM) calculates the slippage of the converter and transmission based upon the engine speed, the output speed, and the current gear ratio.
- The slippage of the converter at a high enough engine speed is low. The transmission should not slip more than a given value when there is no shift.
- This DTC detects a slip at each gear. This is a type "C" DTC.

Conditions For Setting The DTC

- No Output Speed Sensor DTC(s) P0722, P0723.
- Not in Park, Neutral or Reverse.
- Engine speed is greater than 3500 rpm.
- 3 seconds since upshift.

- 3 seconds since downshift.
- 3 seconds since garage shift (N→D).
- And one of the following conditions occur:
 - Slip is greater than 753 rpm in 1st gear.
 - Slip is greater than 713 rpm in 2nd gear.
 - Slip is greater than 694 rpm on 3rd gear.
 - Slip is greater than 685 rpm on 4th gear.
- All conditions met for 5.5 seconds.

Action Taken When The DTC Sets

- Maximum line pressure.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).
- The PCM will illuminate the CHECK TRANS Lamp.

7A1-58 TRANSMISSION CONTROL SYSTEM (4L30-E)

Conditions For Clearing The DTC/CHECK TRANS Lamp

- The PCM will turn "off" the CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from PCM memory by using a scan tool. The DTC can also be cleared from memory when the vehicle has made 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC Actions Taken items when the fault conditions no longer exist and the ignition is cycles "off" long enough to power down the PCM.

Diagnostic Aids

- Check for intermittent output speed sensor circuit problems.
- Check for possible incorrect calibration. (PCM part No., tire specifications, and rear axle ratio)

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This step checks for possible low fluid level causing slipping resulting in an undefined gear ratio.
4. This step checks for correct gear ratios for commanded gears.
5. This step checks for low line pressure.


DTC P0730 Transmission Incorrect Gear Ratio

Step	Action	Yes	No
1	Were you sent here from the "On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	Visually inspect the transmission cooling system for fluid leaks. ○ Refer to Chart 16: Possible Causes of Transmission Fluid Leaks of Mechanical/Hydraulic Diagnosis Symptoms Index in Automatic Transmission (4L30-E) section. Was condition found and corrected?	Go to Step 7	Go to Step 3
3	Refer to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section. Has transmission fluid checking procedure been performed?	Go to Step 4	Go to Checking Transmission Fluid Level and Condition in Automatic Transmission (4L30-E) section
4	1. Install the scan tool. 2. Turn the ignition switch to the "on" position. 3. Engine not running. NOTE: Before clearing DTC(s) use the scan tool to record the "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 4. Record the Failure Record data. 5. Use the scan tool snapshot mode to record transmission gear ratios. 6. Drive vehicle in transmission gear ranges 1, 2, 3, and D with the engine speed is greater than 3,500 rpm for 5.5 seconds. 7. Record each transmission gear. 1st:2.73 – 2.99 2nd:1.54 – 1.71 3rd:0.93 – 1.05 4th:0.66 – 0.78 Does commanded gear ratio match ranges as shown?	Refer to Diagnostic Aids	Go to Step 5

DTC P0730 Transmission Incorrect Gear Ratio (Cont'd)

Step	Action	Yes	No
5	Perform line pressure check. ○ Refer to Line Pressure Test in Automatic Transmission (4L30-E) section. Was condition found and corrected?	Go to Step 7	Go to Step 6
6	Check for possible clutch slippage. ○ Refer to Chart 6: Diagnostic Trouble Code (DTC) P0730 of Mechanical/Hydraulic Diagnosis Symptoms Index in Automatic Transmission (4L30-E) section. Was condition found and corrected?	Go to Step 7	—
7	1. After the repair is complete, use the scan tool to select "DTC", then "Clear info" function. 2. Operate the vehicle under the following conditions: ○ Drive the vehicle in D4 with the engine speed greater than 3,500 rpm to obtain any one of the following gear ratios for seven seconds. 1st 1:2.73 – 1:2.99 2nd 1:1.54 – 1:1.71 3rd 1:0.93 – 1:1.05 4th 1:0.66 – 1:0.78 Has the last test failed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0742 Torque Converter Clutch (TCC) Circuit Stuck On



D07RW023

Circuit Description

The PCM energizes the TCC solenoid by creating an ignition voltage on circuit RED/YEL. When ignition voltage is energized by the PCM, the TCC solenoid stops converter signal oil from exhausting. This causes converter signal oil pressure to increase and move the TCC valve. The TCC solenoid will deenergize when the PCM no longer provides an ignition voltage. When the TCC solenoid is deenergized, it will exhaust fluid and release the TCC.

This DTC detects low torque converter slip when the TCC is commanded "off". This is a type "B" DTC.

Conditions For Setting The DTC

The following conditions occur once per TCC cycle, three consecutive times:

- No TP DTCs P0122 or P0123.
- No OSS DTCs P0722 or P0723.
- No TCC solenoid DTC P1860.
- TP angle is greater than 20%.
- Engine speed is greater than 500 rpm and less than 3000 rpm.
- Engine vacuum is between 0 and 70 kPa.
- Commanded gear is not 1st.
- Gear range is D4.
- TCC is commanded "off".
- No TCC stuck off DTC P1870
- TCC slip speed is between -20 and 40 rpm for 4 seconds.
- Vehicle speed is greater than 25 km/h (15 mph) and less than 120 km/h (75 mph).
- Speed ratio is greater than 0.9 and less than 1.8.

Action Taken When The DTC Sets

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.
- Inhibit TCC engagement.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- If the TCC is mechanically stuck "on" with the parking brake applied and any gear range selected, the TCC fluid will mechanically apply the TCC, possibly causing an engine stall.


Test Description

The number below refers to the step number on the diagnostic chart:

3. This test checks the mechanical state of the TCC.
(When the PCM commands the TCC solenoid "off", the slip speed should increase).

DTC P0742 Torque Converter Clutch (TCC) Circuit Stuck On

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Using the scan tool, verify the "TP Sensor" operation. Are the "TP Sensor" values within 0.6 – 5.0 volts?	Go to Step 3	Go to Diagnostic Aids
3	Drive the vehicle in the D4 drive range in fourth gear under steady acceleration, with a TP angle greater than 20%. Does the scan tool display "TCC Slip Speed" between -30 and +30 rpm, while the displayed TCC solenoid state is "off"?	Go to Step 4	Go to Diagnostic Aids
4	The TCC is mechanically stuck "on". Check the following items: ○ Clogged exhaust orifice in the TCC solenoid. ○ Converter clutch apply valve stuck in the apply position. ○ Misaligned or damaged valve body gasket. ○ Restricted release passage. Was a problem found and corrected?	Go to Step 5	—
5	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: TCC slip speed must be between 200 and 2,500 rpm for 4 seconds. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0748 Pressure Control Solenoid (PCS) (Force Motor) Circuit Electrical

D07RW013

Circuit Description

The PCS is a PCM-controlled device used to regulate transmission line pressure. The PCM compares TPS voltage, engine rpm, and other inputs to determine the line pressure appropriate for a given load. The PCM will regulate the pressure by applying a varying amperage to the PCS. The applied amperage can vary from 0.1 to 1 amp, and is monitored by the PCM.

This DTC detects a continuous open or short to ground in the PCS circuit or the PCS. This is a type "C" DTC.

Conditions For Setting The DTC

- Battery voltage is between 10 and 16 volts.
- The PCM detects that the difference between commanded and actual current is 200 milliamperes (mA) for over 1 second.

Action Taken When the DTC Sets

- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).
- Maximum line pressure.
- The PCM will illuminate the CHECK TRANS Lamp.

Conditions For Clearing The DTC/CHECK TRANS Lamp

- The PCM will turn "off" the CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.

- The DTC can be cleared from PCM history by using a scan tool.
- The DTC will be cleared from memory when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connection at the PCM and at the transmission 5-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.


Test Description

The numbers below refer to the step numbers on the diagnostic chart:

2. This test checks the ability of the PCM to command the PCS.
3. This test checks the PCS and internal wiring harness for incorrect resistance.

DTC P0748 Pressure Control Solenoid (PCS) (Force Motor) Circuit Electrical

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Failure Records". 4. While the engine is operating, put the transmission in Park. 5. Using the scan tool, apply 0.1 amp through 1.0 amp while observing "PC Ref. Current" and "PC Act. Current". Is the "PC Act. Current" reading always within 0.16 amp?	Go to Diagnostic Aids	Go to Step 3
3	1. Turn the ignition "off". 2. Disconnect the transmission 5-way connector M-6. 3. Using the J39200 DVOM, measure the resistance between terminals M6-2(B) and M6-1(E). Is the resistance within 3-7 ohms?	Go to Step 7	Go to Step 4
4	1. Remove the transmission oil pan. Refer to Solenoid (Adapter Case Valve Body) in Automatic Transmission (4L30-E) section. 2. Disconnect the internal wiring harness at the PCS. 3. Measure the resistance of the PCS. Is the resistance within 3-7 ohms?	Go to Step 6	Go to Step 5
5	Replace the PCS. Is the replacement complete?	Go to Step 10	—
6	Repair the internal wiring harness for an open. Is the repair complete?	Go to Step 10	—
7	Inspect/repair circuits C3-E4, M6-2(B), C3-E3, M6-1(E). Was a problem found?	Go to Step 10	Go to Step 8
8	Inspect/repair circuits C3-E4, M6-2(B), C3-E3, M6-1(E) for a short to ground or poor connections. Was a problem found?	Go to Step 10	Go to Step 9
9	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 10	—
10	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: The PCS duty cycle is not at its electrical high or low limit. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0751 Shift Solenoid A Performance Without Input Speed**Circuit Description**

The shift solenoid A is used to control fluid flow acting on the 1-2 and 3-4 shift valves. The solenoid is a normally close exhaust valve that is used with the shift solenoid B to allow four different shifting combinations.

The DTC detects a 2-3 only or a 1-4 only shift pattern depending on the state of the mechanical failure. This is a type "B" DTC.

Conditions For Setting The DTC

- No TP DTCs P0122 or P0123.
- No OSS DTCs P0722 or P0723.
- No TCC solenoid DTC P0742, P1860.
- No shift solenoid A DTC P0753.
- No shift solenoid B DTC P0758.
- Gear range is D4.
- Vehicle speed is greater than 10 km/h (6.25 mph).
- Transmission temperature is between 20° and 125° C (68° and 257° F).

All the above conditions have been met and the combination of conditions 1, 2, 3, and 4 or 1, 2, 3, and 5 occur two consecutive times.

Condition 1:

- Commanded 1-2 shift.
- TP angle is between 10 and 60%.
- TP angle is constant within +/-3%.
- Vehicle speed is between 18 and 50 km/h (11 and 31 mph).
- Within 2.2 seconds, the engine speed in 2nd gear must be 100 rpm greater than the last speed in 1st gear.

Condition 2:

- Commanded 2-3 shift.
- TP angle is between 13 and 60%.

- TP angle is constant within +/-5%.
- Vehicle speed is between 30 and 88 km/h (20 and 45 mph).
- Within 2 seconds, the engine speed in 3rd gear must be 64 rpm less than the last speed in 2nd gear.

Condition 3:

- Commanded 3-4 shift.
- TP angle is between 7 and 60%.
- TP angle is constant within +/-5%.
- Vehicle speed is between 40 and 140 km/h (25 and 87 mph).
- Within 0.7 seconds, the engine speed in 4th gear must be -60 rpm greater than the last speed in 3rd gear.

Condition 4:

- Commanded 4th gear.
- TCC is "on".
- TP angle is between 13 and 60%.
- Speed ratio is between 0.85 and 1.2 (speed ratio is engine speed ÷ output speed).
- TCC slip speed is between 100 and 2000 rpm for 3 seconds.

Condition 5:

- Commanded 4th gear.
- TCC is "on".
- TP angle is between 13 and 60%.
- Speed ratio is between 0.5 and 0.85.
- TCC slip speed is between -50 and 500 rpm for 3 seconds.

Action Taken When the DTC Sets

- Maximum line pressure.

- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Verify that the transmission meets the specifications in the 4L30-E shift speed chart.
- Other internal transmission failures may cause more than one shift to occur.
- A shift solenoid A performance problem could set a shift solenoid B DTC P0756 or a transmission component slipping DTC P1870.

Test Description


The numbers below refer to the step numbers on the diagnostic chart:

2. This test checks the function of the range switch (mode switch).
3. This test checks that the scan tool commanded all shifts, all shifts solenoids responded correctly, but all the shifts did not occur.

DTC P0751 Shift Solenoid A Performance Without Input Speed

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. With the engine operating, apply the brake pedal and select each transmission range D1, D2, D3, D4, N, R, and P. Does each selected transmission range match the "TR Switch" on the scan tool?	Go to Step 3	Go to "Range Switch Logic Table"
3	1. While the engine is operating, raise the drive wheels. 2. With the transmission in D4 range, use the scan tool to command 1st, 2nd and 3rd, and 4th gears while accelerating the vehicle. Was a 2-3 or 1-4 only shift pattern detected? (Road testing the vehicle may be necessary).	Go to Step 4	Go to Diagnostic Aids
4	Check the shift solenoid/hydraulic circuit for: ○ One or both of the shift solenoids for an internal malfunction. ○ Contamination or sediment in one or both of the shift solenoids. ○ Damaged seals on one or both of the shift solenoids. Refer to Solenoid (Main Case Valve Body) in Automatic Transmission (4L30-E) section. Was a problem found and corrected?	Go to Step 5	Go to Diagnostic Aids
5	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and road test the vehicle. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0753 Shift Solenoid A Electrical



D07RW014

Circuit Description

- The shift solenoid A is a simple on/off solenoid located in the main case valve body. The solenoid is the normally closed type. In second or third gear the Powertrain Control Module (PCM) energizes the solenoid to open a fluid inlet port. When the port is open, fluid pressure actuates the shift valve.
- The solenoid is activated by a current. This current is produced by applying a voltage to one side (the High side) and a ground to the other side (Low side).
- The High Side Driver (HSD) is a circuit of the PCM that acts as a switch between the solenoids and the supply voltage. The High side of the solenoid is permanently supplied with voltage, except in BACKUP MODE or when ignition is off the HSD is turned off.

This DTC detects a continuous open or short to ground in the shift solenoid A circuit or the shift solenoid A. This is a type "B" DTC.

Conditions For Setting The DTC

- Ignition is "on", Engine "run".
- Battery voltage is between 10 and 16 volts.
- The PCM commands the solenoid "on" and the voltage remains high (B+), or the PCM commands the solenoid "off" and the voltage remains low (zero volts).
- All conditions met for 0.33 seconds.

Action Taken When The DTC Sets

- Maximum line pressure.
- Immediate landing to 4th gear.
- Inhibit TCC engagement.
- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connection at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.

- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.
- An open ignition feed circuit can cause multiple DTCs to set.
- A shift solenoid B DTC P0756 could also set with a shift solenoid A electrical failure.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This test checks for power to the shift solenoid A from the ignition through the PCM.

5. This test measures the resistance of the component.
9. This test checks the function of the shift solenoid A and the transmission internal wiring harness.

Shift Solenoid Status Chart

Gear	Shift solenoid A	Shift solenoid B
1st	OFF	ON
2nd	ON	ON
3rd	ON	OFF
4th	OFF	OFF


DTC P0753 Shift Solenoid A Electrical

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "on", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". Were DTCs P0753, P0758, P1860 set?	Go to Step 3	Go to Diagnostic Aids
3	1. Turn the ignition "on". 2. Using the J39200 DVOM, measure the voltage between PCM connector terminals C3-E14 and C2-C8 (GND). Is the voltage within 10-12 volts?	Go to Step 4	Go to Step 5
4	1. Turn the ignition "off". 2. Disconnect the C3 (BLUE) PCM connector. 3. Turn the ignition "on". 4. Using the J39200 DVOM, measure the voltage between PCM connector terminals C3-F14 and ground. Is the voltage within 10 - 12 volts?	Go to Step 11	Go to Step 5
5	1. Turn the ignition "off". 2. Disconnect the C3 (BLUE) PCM connector. 3. Using the J39200 DVOM, measure the resistance between PCM connector terminals C3-E14 and C3-F14. Is the resistance within 18 - 20 ohms?	Go to Step 6	Go to Step 7
6	1. Disconnect the C1 (RED) and C2 (WHITE) PCM connectors. 2. Using the J39200 DVOM, check a continuity between PCM terminals C3-F14 and ground. Is there a continuity?	Go to Step 12	Go to Step 8
7	1. Disconnect the 16-way harness connector H-10. 2. Using the J39200 DVOM, measure the resistance between terminals H10-6 and H10-5. Is the resistance within 18-20 ohms?	Go to Step 14	Go to Step 9

7A1-68 TRANSMISSION CONTROL SYSTEM (4L30-E)**DTC P0753 Shift Solenoid A Electrical (Cont'd)**

Step	Action	Yes	No
8	Using the J39200 DVOM, check a continuity between C3 (BLUE) PCM terminal E14 and ground. Is there a continuity?	Go to Step 13	Go to Step 10
9	1. Disconnect the transmission main case 4 pin connector M-7. 2. Using the J39200 DVOM, measure the resistance between terminals M7-3(D) and M7-4(C). Is the resistance within 18-20 ohms?	Go to Step 15	Go to Step 16
10	Check every connection at the PCM connector. Was a problem found?	Go to Step 18	Go to Step 17
11	The wiring harness between PCM connector terminals C3-F14 and transmission harness terminal M7-3(D) is shorted to voltage. Was a problem found and corrected?	Go to Step 19	—
12	The wiring harness between PCM connector terminal J3-F14 and transmission harness terminal M7-3(D) is shorted to ground. Was a problem found and corrected?	Go to Step 19	—
13	The wiring harness between PCM connector terminals C3-E14 and transmission harness terminal M7-4(C) is shorted to ground. Was a problem found and corrected?	Go to Step 19	—
14	The wiring harness between PCM connector C3 and transmission 16-way connector H-10 is open or poor connection. Was a problem found and corrected?	Go to Step 19	—
15	The wiring harness between transmission 16-way connector H-10 and transmission main case connector M-7 is open or has a poor connection. Was a problem found and corrected?	Go to Step 19	—
16	The shift solenoid A is faulty. Replace the shift solenoid A. Refer to Solenoid (Main Case Valve Body) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 19	—
17	The PCM may be faulty. Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 19	—
18	Repair the PCM connector connection. Was a problem found and corrected?	Go to Step 19	—
19	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle under the following conditions: ○The shift solenoid A is commanded "on" and the voltage drops to zero. ○The shift solenoid A is commanded "off" and the voltage increases to B+. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0756 Shift Solenoid B Performance Without Input Speed



Circuit Description

The shift solenoid B is used to control fluid flow acting on the 2–3 shift valves. The solenoid is a normally open exhaust valve that is used with the shift solenoid (A) to allow four different shift combinations.

This DTC detects a non 2-3 upshift and a non 1st gear when 1st gear is commanded, or 1st gear when 4th gear is commanded. This is a type "B" DTC.

Conditions For Setting The DTC

- ☐ No TP DTCs P0122 or P0123.
- ☐ No OSS DTCs P0722 or P0723.
- ☐ No TCC solenoid DTC P0742, P1860.
- ☐ No shift solenoid DTCs P0753, P0758.
- ☐ No MAP DTCs, P0106, P1106, P0107, P1107, or P0108.
- ☐ Vehicle speed is greater than 10 km/h (6.25 mph).
- ☐ Gear range is D4.
- ☐ Engine vacuum is between 0 and 70 kPa.
- ☐ Engine speed is less than 6000 rpm.
- ☐ Transmission fluid temperature is between 20° and 125°C (68° and 257°F).
- ☐ TCC is "off".

All of the above conditions have been met and either one of the following fail conditions occurs:

- The solenoid is stuck “on” and conditions 3 and 4 are present two consecutive times.
- The solenoid is stuck “off” and conditions 1 and 3 are present two consecutive times.

Condition 1:

- TP angle is greater than 45%.
- 1st gear is commanded for 3 seconds.
- Speed ratio is between 0.5 and 2.65 (speed ratio is engine speed ÷ output speed).
- Transmission output speed is between 320 and 2,000 rpm.

- TCC slip speed is between -200 and $-4,000$ rpm for 1.8 seconds.

Condition 2:

- ☐ Not used.

Condition 3:

- ☐ Commanded 2–3 shift.
- ☐ TP angle is between 10 and 60%.
- ☐ TP angle is within $\pm 5\%$.
- ☐ 3rd gear is commanded for 2 second.
- ☐ 3rd gear speed ratio is greater than the last 2nd gear speed ratio minus 0.05.
- ☐ 3rd gear TCC slip speed is greater than or equal to the last 2nd gear TCC slip speed plus 520 rpm for 1.8 seconds.
- ☐ Discontinue test if time since shift commanded is 5.57 seconds.

Condition 4:

- ☐ TP angle is greater than 10%.
- ☐ 4th gear is commanded for 1 second.
- ☐ Speed ratio is between 2.0 and 4.0.
- ☐ Transmission output speed is between 0 and 8192 rpm.
- ☐ TCC slip speed is between 2000 and 5000 rpm for 3 seconds.

Action Taken When the DTC Sets

- Maximum line pressure.
- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS LAMP.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.

7A1-70 TRANSMISSION CONTROL SYSTEM (4L30-E)

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- A shift solenoid A electrical failure could also set a shift solenoid B performance DTC P0756.
- A shift solenoid B electrical failure could also set a shift solenoid B performance DTC P0756.


Test Description

The numbers below refer to the step numbers on the diagnostic chart:

2. This test checks the function of the range switch (mode switch).
3. This test checks for selected gear ratio vs. a ratio not obtainable under normal driving conditions.

DTC P0756 Shift Solenoid B Performance Without Input Speed

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. With the engine operating, apply the brake pedal and select each transmission range D1, D2, D3, D4, N, R, and P. Does each selected transmission range match the "TR Switch" on the scan tool?	Go to Step 3	Go to "Range Switch Logic Table"
3	1. While the engine is operating, raise the drive wheels. 2. With the transmission in D4, range use the scan tool to command 1st, 2nd, and 3rd, and 4th gears while accelerating the vehicle. Was 1st gear commanded and not achieved, or 4th gear commanded and other than 4th gear occurred? (Road testing the vehicle may be necessary.)	Go to Step 4	Go to Diagnostic Aids
4	Check the shift solenoid/hydraulic circuit for: ○ One or both of the shift solenoids for an internal malfunction. ○ Contamination or sediment in one or both of the shift solenoids. ○ Damaged seals on the one or both of the shift solenoids. Refer to Solenoid (Main Case Valve Body) in Automatic Transmission (4L30-E) section. Was a problem found and corrected?	Go to Step 5	Go to Diagnostic Aids
5	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and road test the vehicle. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P0758 Shift Solenoid B Electrical

D07RW014

Circuit Description

- The shift solenoid B is a simple on/off solenoid located in the main case valve body. It is normally open. When the port is open, fluid pressure actuates the shift valve. In first or second gear, the Powertrain Control Module (PCM) energizes the solenoid to close a fluid inlet port.
- The solenoid is activated by current. This current is produced by applying a voltage to one side (the High side) and a ground to the other side (Low side).
- The High Side Driver (HSD) is a circuit of the PCM that acts as a switch between the solenoids and the supply voltage. The High side of the solenoid is permanently supplied with voltage. In BACKUP MODE or when the ignition is off, the HSD is turned off.

This DTC detects a continuous open or short to ground in the shift solenoid B circuit or shift solenoid B. This is a type "B" DTC.

Conditions For Setting The DTC

- Ignition is "on", Engine "run".
- Battery voltage is between 10 and 16 volts.
- The PCM commands the solenoid "on" and the voltage remains high (B+), or the PCM commands the solenoid "off" and the voltage remains low (zero volts).
- All conditions met for 0.33 seconds.

Action Taken When The DTC Sets

- Fixed to 4th gear.
- Maximum line pressure.
- Inhibit TCC engagement.
- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connections at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.

7A1-72 TRANSMISSION CONTROL SYSTEM (4L30-E)

- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

5. This test measures the resistance of the component.
7. This test checks the function of the shift solenoid B and the transmission internal wiring harness.
11. This test checks for power to the shift solenoid B from the ignition through the PCM.

Shift Solenoid Status Chart

Gear	Shift solenoid A	Shift solenoid B
1st	OFF	ON
2nd	ON	ON
3rd	ON	OFF
4th	OFF	OFF

DTC P0758 Shift Solenoid B Electrical

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "on", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". Were DTCs P0753, P0758, P1860 set?	Go to Step 4	Go to Step 3
3	1. The engine "on". 2. Apply brake pedal and select transmission range "D". 3. Press and hold down the winter switch and select transmission mode "winter". Does the scan tool display DTC P0758 at 3rd gear?	Go to Step 8	Go to Diagnostic Aids
4	1. Turn the ignition "off". 2. Disconnect the C2 (WHITE) and C3 (BLUE) PCM connectors. 3. Turn the ignition "on". 4. Using the J39200 DVOM, measure the voltage between PCM connector terminals C2-C2 and C2-C8. Is the voltage within 10 – 12 volts?	Go to Step 15	Go to Step 5
5	1. Turn the ignition "off". 2. Using the J39200 DVOM, measure the resistance between PCM connector terminals C2-C2 and C3-E14. Is the resistance within 18 – 20 ohms?	Go to Step 16	Go to Step 6
6	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, measure the resistance between terminals H10-12 and H10-5. Is the resistance within 18 – 20 ohms?	Go to Step 17	Go to Step 7
7	1. Disconnect the transmission main case connector M-7. 2. Using the J39200 DVOM, measure the resistance between terminals M7-1(A) and M7-4(C). Is the resistance within 18 – 20 ohms?	Go to Step 18	Go to Step 19

DTC P0758 Shift Solenoid B Electrical (Cont'd)

Step	Action	Yes	No
8	1. Turn the ignition "off". 2. Disconnect the C2 (WHITE) and C3 (BLUE) PCM connectors. 3. Using the J39200 DVOM, measure the resistance between PCM connector terminals C2-C2 and C3-E14. Is the resistance within 18 – 20 ohms?	Go to Step 9	Go to Step 10
9	Using the J39200 DVOM, check a continuity between PCM connector terminal C2-C2 and ground. Is there a continuity?	Go to Step 20	Go to Step 11
10	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, measure the resistance between terminals H10-12 and H10-5. Is the resistance within 18-20 ohms?	Go to Step 21	Go to Step 12
11	Using the J39200 DVOM, check a continuity between PCM connector terminal C3-E14 and ground. Is there a continuity?	Go to Step 22	Go to Step 13
12	1. Disconnect the transmission main case connector M-7. 2. Using the J39200 DVOM, measure the resistance between terminals M7-1(A) and M7-4(C). Is the resistance within 18 – 20 ohms?	Go to Step 23	Go to Step 24
13	Check every connection of the PCM and transmission 16-way connector H-10. Was a problem found and corrected?	Go to Step 26	Go to Step 14
14	1. Connect the C2 (WHITE) and C3 (BLUE) PCM connectors to the PCM. 2. Turn the ignition "on", the engine "on". 3. Repeat Step 3. Does the scan tool display DTC P0758 at 3rd gear?	Go to Step 25	Go to Diagnostic Aids
15	The wiring harness between PCM connector terminal C2-C2 and transmission main case terminal M7-1(A) is shorted to voltage. Was a problem found and corrected?	Go to Step 26	—
16	The PCM internal terminal C2-C2 is shorted to voltage. Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 26	—
17	The wiring harness between PCM connector and transmission 16-way connector is shorted. Was a problem found and corrected?	Go to Step 26	—
18	The wiring harness between transmission 16-way connector and transmission main case connector is shorted. Was a problem found and corrected?	Go to Step 26	—
19	The shift solenoid B is faulty, or the internal wiring harness from the shift solenoid B is shorted. Was a problem found and corrected?	Go to Step 26	—
20	The wiring harness between PCM connector terminal C2-C2 and transmission main case connector terminal M7-1(A) is shorted to ground. Was a problem found and corrected?	Go to Step 26	—

7A1-74 TRANSMISSION CONTROL SYSTEM (4L30-E)**DTC P0758 Shift Solenoid B Electrical (Cont'd)**

Step	Action	Yes	No
21	The wiring harness between PCM connector terminal C2-C2 and transmission 16-way connector terminal H10-12, or between PCM connector terminal C3-E14 and 16-way connector terminal H10-5 is open. Was a problem found and corrected?	Go to Step 26	—
22	The wiring harness between PCM connector terminal C3-E14 and transmission main case connector terminal M7-4(C) is shorted to ground. Was a problem found and corrected?	Go to Step 26	—
23	The wiring harness between transmission 16-way connector terminal H10-12 and transmission main case connector terminal M7-1(A), or between H10-5 and M7-4(C) is open. Was a problem found and corrected?	Go to Step 26	—
24	The internal wiring harness from the shift solenoid B is open, or the shift solenoid B is faulty. Was a problem found and corrected?	Go to Step 26	—
25	Replace the PCM. Is the replacement complete?	Go to Step 26	—
26	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle under the following conditions: ○The shift solenoid B is commanded "on" and voltage drops to zero. ○The shift solenoid B is commanded "off" and voltage increases to B+. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P1790 ROM Transmission Side Bad Check Sum

Circuit Description

Transmission Side Read Only Memory (ROM) and Electronically Erasable Programmable Read Only Memory (EEPROM) is an electronic circuit that controls the transmission controls in the Powertrain Control Module (PCM).

This DTC detects a check sum error. This is a type "B" DTC.

Conditions For Setting The DTC

- Detects check sum error for 1 second.

Action Taken When The DTC Sets

- Maximum line pressure.
- Immediate landing to 4th gear.
- Inhibit TCC engagement.

- The PCM will illuminate the Malfunction Indicate Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

DTC P1790 ROM Transmission Side Bad Check Sum

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Failure Records". Was DTC P1790 set?	Go to Step 5	Go to Step 3
3	Was DTC P1792 set?	Go to Step 4	—
4	1. Remove the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. 2. Using the ITCS reprogram the transmission EEPROM. Was the reprogramming complete?	Go to Step 6	—
5	Replace the PCM. Is the replacement complete?	Go to Step 6	—
6	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P1792 EEPROM Transmission Side Bad Check Sum

Circuit Description

Transmission Side Read Only Memory (ROM) and Electronically Erasable Programmable Read Only Memory (EEPROM) is an electronic circuit that controls the transmission controls in the Powertrain Control Module (PCM).

This DTC detects a check sum error. This is a type "B" DTC.

Conditions For Setting The DTC

- Detects check sum error for 1 second.

Action Taken When The DTC Sets

- Maximum line pressure.
- Immediate landing to 4th gear.
- Inhibit TCC engagement.


- The PCM will illuminate the Malfunction Indicate Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

DTC P1792 EEPROM Transmission Side Bad Sum

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Failure Records". Was DTC P1790 set?	Go to Step 5	Go to Step 3
3	Was DTC P1792 set?	Go to Step 4	—
4	1. Remove the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. 2. Using the ITCS reprogram the transmission EEPROM. Was the reprogramming complete?	Go to Step 6	—
5	Replace the PCM. Is the replacement complete?	Go to Step 6	—
6	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and operate the vehicle. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P1835 Kickdown Switch Always On

D07RW015

Circuit Description

- When the driver presses the accelerator pedal down fully, the kickdown switch closes, sending a ground signal to the Powertrain Control Module (PCM).
- This information is used to perform shifts at high engine speed.
- When the kickdown switch is closed, the Throttle Position Sensor (TPS) is already at 100%.
- This DTC detects a closed kickdown switch when TP angle is less than 70%.
- This is a type "D" DTC.

Conditions For Setting The DTC

- No TP DTCs P0122 or P0123.
- TP angle is less than 70%.
- Kickdown switch is "on".
- All conditions met for 1 second.

Action Taken When The DTC Sets.

- Kickdown mode control is off.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Check the wiring harness for a short to ground between the PCM and kickdown switch.
- Check the kickdown switch for failure.
- Check kickdown adjustment.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:


2. This test checks for short to ground or kickdown switch failure.
4. This test checks for regulation kickdown switch.

7A1-78 TRANSMISSION CONTROL SYSTEM (4L30-E)

DTC P1835 Kickdown Switch Always On

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "on", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Failure Records". Does the scan tool display "Kickdown switch" "low" (closed switch)?	Go to Step 3	Go to Step 4
3	1. Turn the ignition "off". 2. Disconnect the C3 (BLUE) PCM connector. 3. Using the J39200 DVOM, check a continuity between PCM connector terminal C3-F11 and ground. Is there a continuity?	Go to Step 5	Go to Step 8
4	The TP angle goes from 0% to 100% with the accelerator pedal depressed. Does the kickdown switch "on" when TP angle is below 70%?	Go to Step 6	Go to Diagnostic Aids
5	1. Disconnect the kickdown switch connector C-29. 2. Using the J39200 DVOM, check a continuity between terminals C29-1 and C29-2. Is there a continuity?	Go to Step 7	Go to Step 9
6	Adjust the kickdown switch. Does the kickdown switch "on" when TP angle is above 95%?	Go to Step 10	—
7	Replace the kickdown switch. Is the replacement complete?	Go to Step 10	—
8	Replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 10	—
9	Repair the short to ground in circuit LT BLUE. Is the repair complete?	Go to Step 10	—
10	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following condition is met: The torque converter stator temperature switch circuit does not indicate a hot mode when the transmission fluid temperature is less than 60°C (140°F) for at least 5 seconds. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P1850 Brake Band Apply Solenoid Malfunction



Circuit Description

- The brake band apply solenoid is a normally open solenoid which controls the flow of fluid for brake band application. The Powertrain Control Module (PCM) uses Pulse Width Modulation (PWM) and changes the duty cycle to control the solenoid. The PCM turns the solenoid on (energized) and off (deenergized) at a constant frequency. The length of time the solenoid is energized during each on/off cycle is called the pulse width. By varying or “modulating” the pulse width, the solenoid output pressure is changed. Since the solenoid is normally open, increasing the pulse width increases the duty cycle and decreases the output pressure. PWM control provides smooth band application without an accumulator. The band is only applied in first and second gears.
- In the event of an electrical failure (open), the solenoid regulates at the maximum oil flow (0% duty cycle).
- The solenoid is activated by a current. This current is produced by applying a voltage to one side (the High side) and a ground to the other side (Low side).
- The High Side Driver (HSD) is a circuit of the PCM that acts as a switch between the solenoids and the supply voltage. The High side of the solenoid is permanently supplied with voltage. When the ignition is off, the HSD is turned off.

This DTC detects a continuous open or short to ground in the brake band apply solenoid circuit or the brake band apply solenoid. This is a type “D” DTC.

Conditions For Setting The DTC

- Battery voltage is between 10 and 16 volts.
- Ignition is “on”, Engine “run”.
- The PCM commands the solenoid “on” and the voltage remains high (B+), or the PCM commands the solenoid “off” and the voltage remains low (zero volts).
- All conditions met in 1.3 seconds.

Action Taken When The DTC Sets

- Inhibit brake band apply solenoid.
- The PCM will not illuminate the Malfunction Indicator Lamp (MIL).

Conditions For Clearing The DTC

- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

7A1-80 TRANSMISSION CONTROL SYSTEM (4L30-E)

Diagnostic Aids

- Inspect the wiring for poor electrical connection at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This test checks for power to the brake band apply solenoid from the ignition through the PCM.
4. This test checks the resistance of the transmission internal wiring harness and brake band apply solenoid.
5. This test checks the ability of the PCM and wiring to control the ground circuit.

DTC P1850 Brake Band Apply Solenoid Malfunction

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "on", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". Were DTCs P0753, P0758 set?	Go to Step 3	Go to Step 4
3	Using the J39200 DVOM, back probe between PCM connector terminals C3-E14 and C2-C8. Is the voltage between 10 to 12 volts?	Go to Step 5	Go to Step 6
4	1. Turn the ignition "off". 2. Disconnect the C1 (RED) and C3 (BLUE) PCM connectors. 3. Using the J39200 DVOM, measure the resistance between PCM connector terminals C1-A16 and C3-E14. Is the resistance within 10-12 ohms?	Go to Step 12	Go to Step 13
5	Using the J39200 DVOM, back probe between PCM connector terminals C1-A16 and C2-C8. Is the voltage between 10 to 12 volts?	Go to Step 26	Go to Step 4
6	1. Turn the ignition "off". 2. Disconnect the C1 (RED) and C3 (BLUE) PCM connectors. 3. Using the J39200 DVOM, check continuity between PCM terminal C3-E14 and ground. Is there a continuity?	Go to Step 7	Go to Step 9
7	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, check continuity between connector H10-7 and ground. Is there a continuity?	Go to Step 8	Go to Step 17
8	1. Disconnect the transmission main case connector M-7. 2. Using the J39200 DVOM, check continuity between the terminal M7-2(B) and ground. Is there continuity?	Go to Step 18	Go to Step 19


DTC P1850 Brake Band Apply Solenoid Malfunction (Cont'd)

Step	Action	Yes	No
9	1. Disconnect the J1 (RED) PCM Connector. 2. Using the J39200 DVOM, measure the resistance between the PCM connector terminals C1-A16 and C3-E14. Is the resistance within 10-12 ohms?	Go to Step 26	Go to Step 10
10	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, measure the resistance between the terminal H10-7 and H10-5. Is the resistance within 10-12 ohms?	Go to Step 17	Go to Step 11
11	1. Disconnect the transmission main case connector M-7. 2. Using the J39200 DVOM, measure the resistance between the terminals M7-2(B) and M7-4(C). Is the resistance within 10-12 ohms?	Go to Step 20	Go to Step 21
12	Using the J39200 DVOM, check continuity between PCM terminal C1-A16 and ground. Is there continuity?	Go to Step 14	Go to Step 26
13	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, measure the resistance between the terminal H10-7 and H10-5. Is the resistance within 10-12 ohms?	Go to Step 24	Go to Step 15
14	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, check continuity between terminal H10-7 and ground. Is there a continuity?	Go to Step 16	Go to Step 22
15	1. Disconnect the transmission main case connector M-7. 2. Using the J39200 DVOM, measure the resistance between the terminals M7-2(B) and M7-4(C). Is the resistance within 10-12 ohms?	Go to Step 25	Go to Step 21
16	1. Disconnect the transmission main case connector M-7. 2. Using the J39200 DVOM, check continuity between terminal M7-2(B) and ground. Is there a continuity?	Go to Step 18	Go to Step 23
17	The wiring harness between PCM terminal C3-E14 and transmission 16-way connector terminal H10-5 is open. Was a problem found and corrected?	Go to Step 27	—
18	The brake band apply solenoid is faulty, or the internal wiring harness from the brake band apply solenoid is shorted to ground. Was a problem found and corrected?	Go to Step 27	—
19	The wiring harness between the transmission 16-way connector terminal H10-5 and the transmission main case connector terminal M7-4(C) is shorted to ground. Was a problem found and corrected?	Go to Step 27	—
20	The wiring harness between the transmission 16-way connector terminal H10-5 and the transmission main case connector terminal M7-4(C) is open. Was a problem found and corrected?	Go to Step 27	—
21	The brake band apply solenoid is faulty, or the internal wiring harness from the brake band apply solenoid is open. Was a problem found and corrected?	Go to Step 27	—

7A1-82 TRANSMISSION CONTROL SYSTEM (4L30-E)**DTC P1850 Brake Band Apply Solenoid Malfunction (Cont'd)**

Step	Action	Yes	No
22	The wiring harness between the PCM connector terminal C1-A16 and transmission 16-way connector terminal H10-7 is shorted to ground. Was a problem found and corrected?	Go to Step 27	—
23	The wiring harness between the transmission 16-way connector terminal H10-7 and the transmission main case connector terminal M7-2(B) is shorted to ground. Was a problem found and corrected?	Go to Step 27	—
24	The wiring harness between the PCM connector terminal C1-A16 and the 16-way connector terminal H10-7 is open. Was a problem found and corrected?	Go to Step 27	—
25	The wiring harness between the transmission 16-way connector terminal H10-7 and the transmission main case connector terminal M7-2(B) is open. Was a problem found and corrected?	Go to Step 27	—
26	Check every connection at the PCM. If OK, replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 27	—
27	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: ○The brake band apply solenoid is commanded "on" and the volts drop to zero. ○The brake band apply solenoid is commanded "off" and the volts increase to B+. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P1860 TCC Solenoid Electrical



D07RW016

Circuit Description

The PCM allows current to flow through the solenoid coil. This current flow through the solenoid coil creates a magnetic field that magnetizes the solid core. The magnetized core attracts the check ball to seat against spring pressure. This blocks the exhaust for the TCC signal fluid and allows 2-3 drive fluid to feed to TCC signal fluid. The TCC signal fluid pressure acts on the TCC regulator valve to regulate line pressure and to apply fluid pressure to the torque converter clutch shift valve. When the TCC shift valve is in the apply position, regulated apply fluid pressure is directed through the TCC valve to apply the torque converter clutch. The TCC solenoid is used in conjunction with the TCC solenoid to regulate fluid to the torque converter. The TCC solenoid is attached to the valve body within the transmission. This DTC detects a continuous open or short to ground or ignition in the TCC circuit or the TCC solenoid. This is a type "B" DTC.

Conditions For Setting The DTC

- Battery voltage is between 10 and 16 volts.
- No shift solenoid A DTCs P0751 or P0753.
- No shift solenoid B DTCs P0756 or P0758.
- Ignition "on". Engine "run".
- The PCM commands the solenoid "on" and the voltage remains low (zero volts).
- The PCM commands the solenoid "off" and the voltage remains high (B+).
- All conditions met for 0.25 seconds.

Action Taken When The DTC Sets

- Inhibit TCC engagement.
- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Inspect the wiring for poor electrical connections at the PCM and at the transmission 16-way connector. Look for possible bent, backed out, deformed or damaged terminals. Check for weak terminal tension as well. Also check for a chafed wire that could short to bare metal or other wiring. Inspect for a broken wire inside the insulation.
- When diagnosing for a possible intermittent short or open condition, move the wiring harness while observing test equipment for a change.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

3. This test checks for voltage to the solenoid.
4. This test checks the ability of the PCM and wiring to control the ignition circuit.
9. This test checks the resistance of the TCC solenoid and the internal wiring harness.


7A1-84 TRANSMISSION CONTROL SYSTEM (4L30-E)**DTC P1860 TCC Solenoid Electrical**

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "on", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records".	Go to Step 3	Go to Step 4
3	Using the J39200 DVOM, back probe between PCM connector terminals C2-D2 and C2-C8. Is the voltage 0?	Go to Step 5	Go to Step 6
4	1. Apply brake pedal and select transmission range "D". 2. Do a test drive, and increase the vehicle speed to TCC "on" at 4th. Does the scan tool display DTC P1860 at TCC "ON"?	Go to Step 10	Go to Diagnostic Aids
5	1. Turn the ignition "off". 2. Disconnect the C2 (WHITE) PCM connector. 3. Using the J39200 DVOM, measure the resistance between PCM connector terminals C2-D2 and C2-C8. Is the resistance within 18 – 20 ohms?	Go to Step 7	Go to Step 8
6	The wiring harness between PCM connector terminal C2-D2 and transmission adapter case connector terminal M6-4(A) is shorted to voltage. Was a problem found and corrected?	Go to Step 19	Go to Step 20
7	Intermittent condition. Check the wiring harness and terminals between PCM connector J2 and transmission adapter case connector M-6. Was a problem found and corrected?	Go to Step 19	Go to Step 20
8	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, measure the resistance between terminal H10-4 and ground. Is the resistance within 18 – 20 ohms?	Go to Step 16	Go to Step 9
9	1. Disconnect the transmission adapter case connector M-6. 2. Using the J39200 DVOM, measure the resistance between terminal M6-4(A) and ground. Is the resistance within 18 – 20 ohms?	Go to Step 17	Go to Step 18
10	1. Turn the ignition "off". 2. Disconnect the C2 (WHITE) PCM connector. 3. Using the J39200 DVOM, measure the resistance between terminals C2-D2 and C2-C8. Is the resistance within 18 – 20 ohms?	Go to Step 19	Go to Step 11

DTC P1860 TCC Solenoid Electrical (Cont'd)

Step	Action	Yes	No
11	1. Disconnect the transmission 16-way connector H-10. 2. Using the J39200 DVOM, measure the resistance between terminal H10-4 and ground. Is the resistance within 18-20 ohms?	Go to Step 13	Go to Step 12
12	1. Disconnect the transmission adapter case connector M-6. 2. Using the J39200 DVOM, measure the resistance between terminal M6-4(A) and ground. Is the resistance within 18-20 ohms?	Go to Step 14	Go to Step 15
13	The wiring harness between PCM connector terminal C2-D2 and transmission 16-way connector terminal H10-4 is shorted to ground. Was a problem found and corrected?	Go to Step 21	—
14	The wiring harness between transmission 16-way connector H-10 and adapter case connector M-6 is shorted to ground. Was a problem found and corrected?	Go to Step 21	—
15	The TCC solenoid is faulty, or the internal wiring harness from the TCC solenoid is shorted to ground. Was a problem found and corrected?	Go to Step 21	—
16	The wiring harness between PCM connector terminal C2-D2 and transmission 16-way connector terminal H10-4 is open. Was a problem found and corrected?	Go to Step 21	—
17	The wiring harness between transmission 16-way connector terminal H10-4 and adapter case terminal M6-4(A) is open. Was a problem found and corrected?	Go to Step 21	—
18	The TCC solenoid is faulty, or the internal wiring harness from the TCC solenoid is open. Was a problem found and corrected?	Go to Step 21	—
19	Check every connection at the PCM. If OK, replace the PCM. Refer to Powertrain Control Module (PCM) in Automatic Transmission (4L30-E) section. Is the replacement complete?	Go to Step 21	—
20	Check the PCM connector terminal C2-D2, transmission 16-way connector terminal H10-4 and transmission adapter case connector terminal M6-4(A). Was a problem found and corrected?	Go to Step 21	—
21	1. After the repair is complete, use the scan tool to select "DTC", then "Clear Info" function and ensure the following conditions are met: ○The TCC solenoid is commanded "on" and the volts increase to B+. ○The TCC solenoid is commanded "off" and the volts drop to zero. 2. Review the scan tool "DTC Info". Has the last test failed or is the current DTC displayed?	Begin diagnosis again Go to Step 1	Repair verified Exit DTC table

DTC P1870 Transmission Component Slipping



D07RW023

Circuit Description

The PCM monitors the difference in engine speed and transmission output speed. In D3 drive range with the TCC engaged, the engine speed should closely match transmission output speed.

This DTC detects excessive TCC slip when the TCC is engaged. This is a type "B" DTC.

Conditions For Setting The DTC

The following conditions are met for three TCC cycles with reported excessive TCC slip conditions.

- No TP DTCs P0122 or P0123.
- No OSS DTCs P0722 or P0723.
- No shift solenoid A DTCs P0751 or P0753.
- No shift solenoid B DTCs P0756 or P0758.
- No TCC PWM solenoid DTC P1860.
- No TCC solenoid DTC P0742.
- Engine speed is between 800 and 3,360 rpm.
- Engine vacuum is between 0 and 70 kPa.
- Gear range is D4.
- TP angle is between 12 and 70%.
- TFT is between 20° and 141°C (68° and 286°F).
- TCC is "on" for 3 seconds.
- TCC slip speed is between 200 rpm and 800 rpm for 10 seconds.
- Vehicle speed is between 38 km/h (24 mph) and 110 km/h (69 mph).

- Speed ratio is between 0.6 and 0.95.
- No MAP DTCs P0106 or P1106 or P0107 or P1107 or P0108.

Action Taken When The DTC Sets

- Only stored in memory.
- The PCM will illuminate the Malfunction Indicator Lamp (MIL) and CHECK TRANS Lamp.

Conditions For Clearing The MIL/DTC

- The PCM will turn off the MIL and CHECK TRANS Lamp after three consecutive ignition cycles without a failure reported.
- The DTC can be cleared from the PCM history by using a scan tool.
- The DTC will be cleared from history when the vehicle has achieved 40 warmup cycles without a failure reported.
- The PCM will cancel the DTC default actions when the fault no longer exists and the ignition is cycled "off" long enough to power down the PCM.

Diagnostic Aids

- Range switch malfunction could set a DTC P1870.
- A mechanical failure of the shift solenoids, TCC solenoid, or TCC PWM solenoid could set a DTC P1870.
- Internal transmission failures may set a DTC P1870.

- An intermittent or incorrect engine speed signal may set a DTC P1870.

Test Description

The numbers below refer to the step numbers on the diagnostic chart:

- This test checks the indicated range signal to the actual selected range. A faulty switch could set a DTC P1870.
- This test checks the torque converter for slippage while in a commanded lockup state.

Range Switch Logic Table

Range Position	Range Switch Pin			
	A	B	C	P(G)
Park	ON	OFF	OFF	ON
Reverse	ON	ON	OFF	OFF
Neutral	OFF	ON	OFF	ON
D4	OFF	ON	ON	OFF
D3	ON	ON	ON	ON
2	ON	OFF	ON	OFF
L	OFF	OFF	ON	ON
Illegal	OFF	OFF	OFF	OFF
Illegal	OFF	OFF	OFF	ON

DTC P1870 Transmission Component Slipping

Step	Action	Yes	No
1	Were you sent here from the "Powertrain On-Board Diagnostic (OBD) System Check"?	Go to Step 2	Go to OBD System Check Refer to Driveability and Emission in Engine section
2	1. Install the scan tool. 2. With the engine "off", turn the ignition switch "on". NOTE: Before clearing DTC(s), use the scan tool to record "Freeze Frame" and "Failure Records" for reference, as data will be lost when the "Clear Info" function is used. 3. Record the DTC "Freeze Frame" and "Failure Records". 4. Apply the brake pedal. 5. Select each transmission range: D1, D2, D3, D4, N, R, and P. Does each selected transmission range match the scan tool "TR Switch" display?	Go to Step 3	Go to "Range Switch Logic Table"
3	Drive the vehicle in 4th gear while the TCC is engaged. At any time is the "TCC Slip Speed" greater than 130 rpm for 8 seconds while the TCC is engaged?	Go to System Diagnosis Charts	Go to Diagnostic Aids

RODEO

TRANSMISSION

MANUAL TRANSMISSION MUA 5C (4X2, 4X4) AND TREMEC T5R(4X2)

CONTENTS

Service Precaution	7B-2	Disassembled View	7B-53
General Description	7B-2	Disassembly	7B-54
Diagnosis (MUA)	7B-5	Inspection and Repair	7B-55
Diagnosis (TREMEC T5R)	7B-6	Reassembly	7B-58
Rear Oil Seal (4X2)	7B-7	Transmission Case (TREMEC T5R)	7B-64
Disassembled View	7B-7	Disassembled View	7B-64
Removal	7B-7	Disassembly	7B-65
Installation	7B-7	Inspection and Repair	7B-71
Transmission (MUA)	7B-8	Reassembly	7B-76
Disassembled View	7B-8	Mainshaft (TREMEC T5R)	7B-82
Removal	7B-9	Disassembled View	7B-82
Installation	7B-13	Disassembly	7B-82
Transmission (TREMEC T5R)	7B-18	Reassembly	7B-85
Disassembled View	7B-18	Input Shaft (TREMEC T5R)	7B-87
Removal	7B-19	Disassembled View	7B-87
Installation	7B-21	Disassembly	7B-87
Transmission Case	7B-25	Reassembly	7B-88
Major Component (MUA, 4X2)	7B-25	Input Bearing Retainer (TREMEC T5R)	7B-89
Disassembly	7B-26	Disassembled View	7B-89
Reassembly	7B-27	Disassembly	7B-89
Transmission Case and Transfer Case	7B-30	Reassembly	7B-89
Major Component (MUA, 4X4)	7B-30	Counter Shaft (TREMEC T5R)	7B-90
Disassembly	7B-31	Disassembled View	7B-90
Reassembly	7B-34	Disassembly	7B-90
Intermediate Plate with Gear Assembly, Detent, Shift Arm, and		Reassembly	7B-91
Interlock Pin (MUA)	7B-40	Extension Housing (TREMEC T5R)	7B-92
Disassembled View	7B-40	Disassembled View	7B-92
Disassembly	7B-41	Disassembly	7B-92
Inspection and Repair	7B-42	Reassembly	7B-93
Reassembly	7B-43	Shift Cover (TREMEC T5R)	7B-94
Reverse Gear and 5th Gear (MUA)	7B-44	Disassembled View	7B-94
Disassembled View	7B-44	Disassembly	7B-94
Disassembly	7B-45	Reassembly	7B-95
Inspection and Repair	7B-47	Pre-Installation Checks (TREMEC T5R)	7B-98
Reassembly	7B-47	Main Data and Specifications	7B-100
Top Gear Shaft, Main Gear Shaft, and Counter Gear Shaft (MUA)	7B-53	Special Tools (MUA)	7B-106
		Special Tools (TREMEC T5R)	7B-108


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.


General Description

MUA5C Transmission



A07RW039

4X4




A07RW040

The MUA5C is a constant mesh transmission, synchronized in all speeds. The transmission is designed for a great reduction of the shift effort and the quietest possible operation.

Principle parts of the transmission are the integral clutch housing, intermediate plate, the transfer case, the rear cover, and the gears.

The transmission control box and transfer control box are built into the transmission and transfer case.

TREMEC T5R Transmission



A07RS031

The TREMEC T5R (77 mm 5 speed) is a constant mesh transmission, synchronized in all speeds except reverse. The main components are:

1. Input shaft gear.

- An integral shaft is splined to engage with the clutch driven plate.
- The gear drives the countershaft.
- A tapered roller bearing supports the shaft in case.

2. Countershaft gear.

- The countershaft gear is one unit for constant rotation with the input shaft gear.
- Tapered roller bearings support the countershaft gear in the case.
- Thrust washer limits the play of the countershaft gear.
- An extra gear is mounted to the countershaft gear for 5th speed.

3. Mainshaft.

- The drive gears rotate freely on the mainshaft and are in constant mesh with countershaft gear.
- Key-type synchronizers engage the gears.
- The 1st and 2nd synchronizer hub is machined in place.

- A tapered roller bearing supports the mainshaft in the rear of the case.

- Roller bearings support the mainshaft independently in the input shaft gear.

- The input shaft gear and mainshaft are engaged by a synchronizer for direct drive in top gear.

- Thrust washers limit the play of the mainshaft.

4. Reverse idler gear.

- The idler gear drives the mainshaft in reverse.
- The idler gear is supported on its own shaft.
- A reverse brake feature brakes the countershaft gear in the reverse shift sequence.

5. Shift lever.

- The shift lever is mounted on the extension housing and holds the offset lever.
- The shift lever moves the shaft which is mounted in the transmission top cover.
- Shift forks mounted on shaft move the synchronizers to engage the gears.
- A pin-type interlock blocks the other forks when one is moved.

Diagnosis (MUA)


Condition	Possible cause	Correction
Abnormal noise	Flywheel pilot bearing worn	Replace
	Bearings worn or broken (Mainshaft, counter shaft, and transfer shaft)	Replace
	Gear tooth contact surfaces worn or scuffed (Mainshaft, counter shaft, reverse idler gear and transfer gears)	Replace
	Splines worn (Mainshaft, synchronizer clutch hub)	Replace
	Gear or bearing thrust face seized	Replace
	Lack of backlash between meshing gears	Replace
Hard Shifting	Improper clutch pedal free play	Readjust
	Change lever sliding portions worn	Repair or replace Regrease
	Shift block, shift rod and/or control box sliding faces worn	Replace
	Shift arm and synchronizer sleeve groove worn	Replace worn parts
	Thrust washer, collar, and/or gear thrust faces worn (Mainshaft and counter shaft thrust play)	Replace worn parts
	Synchronizer parts worn	Replace
Walking or Jumping out of gear	Detent ball worn	Replace
	Detent spring weakened or broken	Replace
	Shift rod and/or control box sliding faces worn	Replace
	Shift arm and synchronizer sleeve groove worn	Replace worn parts
	Thrust washer, collar, and/or gear thrust faces worn (Mainshaft and counter shaft thrust play)	Replace worn parts
	Bearings worn or broken	Replace
	Splines worn (Mainshaft, synchronizer hub)	Replace
	Synchronizer spring weakened or broken	Replace
Oil leakage	Loose drain plug(s) and/or filler plug(s)	Tighten Replenish oil
	Defective or improperly installed gasket(s)	Replace
	Oil seal worn or scratched	Replace

Diagnosis (TREMEC T5R)

Condition													Possible Faulty Component	
Shift hop-out	Shift gear clash	Shift block-out	Hard shift	Noise in reverse only	Noise in 5th only	Noise in 4th only	Noise in 3th only	Noise in 2nd only	Noise in 1st only	Noise in all speeds	Leak at rear	Leak at center		Leak at front
												●	●	Transmission case
											●	●		Extension housing (TREMEC.T5R)/rear cover (MUA)
●			●									●	●	Shift cover/shift shaft (TREMEC.T5R)/shift rod (MUA)
●			●								●			Shift control lever
			●										●	Input bearing retainer (TREMEC.T5R)/front cover (MUA)
										●				Input gear set
●							●			●				3rd speed gear/set
●								●		●				2nd speed gear/set
				●										Reverse speed gear/set
●									●	●				1st speed gear/set
●										●				5th speed gear/set
			●							●				Clutch housing and release system parts
			●							●				Crankshaft pilot bushing and release bearing
										●				Input bearing
										●				Mainshaft pilot bearing
●										●				Mainshaft thrust bearing
							●			●				3rd speed gear bearing
								●		●				2nd speed gear bearing
									●	●				1st speed gear bearing
				●										Reverse idler gear bushing
										●				Counter shaft front bearing
										●				Counter shaft rear bearing (TREMEC.T5R)/center bearing (MUA)
●										●				Counter shaft thrust bearing
					●					●				5th speed drive gear bearing
											●			Slip yoke bushing
											●			Slip yoke seal
											●			Speedometer drive/driven gears
											●			Speedometer driven gear housing
													●	Input shaft seal
●	●	●						●	●	●				1-2 synchronizer assembly
●	●	●				●	●			●				3-4 synchronizer assembly
●	●	●		●						●				5th synchronizer assembly
							●							Reverse overcenter spring (OFF)

Rear Oil Seal (4X2)

Disassembled View



220RW042

Legend

(1) Rear Propeller Shaft

(2) Rear Oil Seal (MUA)


(3) Rear Oil Seal (TREMEC T5R)

Removal

1. Raise and support vehicle with suitable jack stands.
2. Remove propeller shaft flange yoke bolts and nuts at the differential side.
Remove propeller shaft from the transmission main shaft spline.
3. Use a screwdriver to pry the rear oil seal from the rear cover(MUA) or extension housing(TREMEC T5R).

Installation

1. Install a new oil seal(2) or (3) using the installer J-29769 (MUA) or J-38763 (TREMEC T5R).



220RS044


2. Insert the splined yoke into the transmission mainshaft spline.
3. Install the propeller shaft flange yoke to the drive pinion flange.

Torque: 63 N·m (46 lb ft)

4. Check transmission fluid level.
5. Lower vehicle.

Transmission (MUA)

Disassembled View



220RW040


Legend

- | | |
|---|--|
| (1) Gear Control Lever Knob | (11) Fuel Pipe Heat Protector |
| (2) Transfer Control Lever Knob | (12) Harness Clamp |
| (3) Center Console | (13) Harness Heat Protector |
| (4) Grommet Assembly | (14) Slave Cylinder |
| (5) Gear Control Lever and Transfer Control Lever | (15) Dust Cover |
| (6) Transfer Protector | (16) Rear Mount Nut |
| (7) Fairing Plate | (17) Third Crossmember |
| (8) Rear Propeller Shaft | (18) Starter |
| (9) Front Propeller Shaft | (19) Flywheel Undercover |
| (10) Center Exhaust Pipe | (20) Transmission Retaining Nut and Bolt |
| | (21) Transmission |

Removal


NOTE: Before removing transmission assembly(4X4) from vehicle, change the transfer mode to 2WD using the 4WD push button on dash panel.

1. Disconnect battery ground cable.
2. Remove gear control lever knob(1).
3. Remove transfer control lever knob(2) (4X4).
4. Remove lower cluster assembly.




740RW021

5. Remove rear console.




256RW005

6. Remove center console(3).



F07RW023


7. Remove grommet assembly(4).



262RW027


7B-10 MANUAL TRANSMISSION

8. Remove gear control lever(5) and transfer control lever(5) (4X4).
9. Raise and support vehicle with suitable stands. Remove transfer protector(6) (4X4) and fairing plate(7).




10. Remove rear propeller shaft(8).

NOTE: Apply alignment marks on the flange at both front and rear sides.




11. Remove front propeller shaft(9) (4X4).


NOTE: Apply alignment marks on the flange at both front and rear sides.



12. Remove center exhaust pipe(10) (6VD1 engine).



13. Remove fuel pipe heat protector(11) and clip.




141RW004

14. Disconnect transmission harness connectors and clip.

Connector: Transfer switch (4X4), 2-4 actuator (4X4), speed sensor, back up switch 1-2 and 3-4 indicator switch.


15. Remove transmission harness clamps(12) from the transmission case and bracket.



220RS028

16. Remove harness heat protector(13) (6VD1 engine).


17. Remove slave cylinder(14) and flexible hose fixing bracket (X22SE engine).



205RW001

18. Remove dust covers(15) (6VD1 engine).


19. Support transmission with a transmission jack.




220RS001

7B-12 MANUAL TRANSMISSION

20. Remove engine rear mount nuts(16) from third crossmember.




F07RW008



022RW001


21. Remove third crossmember(17) by removing six fixing bolts.
22. Remove starter(18) (6VD1 engine).
23. Remove flywheel under cover(19). 6VD1 engine:3 pieces, X22SE engine:1 piece.
24. Use clutch release bearing remover J-39207 to disconnect the clutch release bearing from the clutch pressure plate (6VD1 engine).



220RS002


25. Pull the shift fork toward the transmission to press the clutch release bearing against the clutch (6VD1 engine).
26. Insert the clutch release bearing remover between the wedge collar and the release bearing (6VD1 engine).

NOTE: Be sure not to insert the remover between the wedge collar and the clutch.



220RS003

27. Turn the remover to separate the release bearing (6VD1 engine).




220RS004

28. Remove transmission retaining nuts and bolts(20).
Remove transmission(21) from the vehicle.

Installation

1. Apply a thin coat of molybdenum disulfide grease to the top gear shaft spline.
2. Slowly operate the transmission jack until the front of transmission is aligned with the rear of the engine.
The slope of the engine and the transmission must be the same.
3. Align the top gear shaft spline with the clutch driven plate spline.




220RS007

7B-14 MANUAL TRANSMISSION

4. Install the transmission to the engine.


Tighten the transmission nuts and bolts as shown in the figure.



225RX003

X22SE engine
MUA

Torque : N·m (lb ft)
Length : mm




225RX002

5. Apply a force of 59 – 78 N (13.2 – 17.6 lb) to the tip of the shift fork in the direction of the transmission to engage the clutch pressure plate and release bearing.

NOTE: A click sound is heard when the release bearing and the tip of the diaphragm spring engage each other.

Check to see if they are securely engaged by pushing the tip of the shift fork toward the engine side while applying a force of about 25 N (5.5 lb). If the shift fork will not move, then they are securely engaged.



220RS006

7B-16 MANUAL TRANSMISSION

6. Install flywheel under cover(19). 6VD1 engine 3 pieces, X22SE engine 1 piece.

Torque: 8 N·m (69 lb in)

7. Install starter(18).

Torque: 40 N·m (30 lb ft)

8. Install third crossmember(17).

Torque: 50 N·m (37 lb ft)


9. Install engine rear mount nuts(16).

Torque: 40 N·m (30 lb ft)

Remove the transmission jack from transmission side.

10. Apply grease to top hole portion of the shift fork.
Install slave cylinder(14) and flexible hose fixing bracket (X22SE engine).

Torque: 43 N·m (32 lb ft)



Legend

- (1) Apply Grease

11. Install clutch dust covers(15) to clutch housing (6VD1 engine).



Torque: 6 N·m (52 lb in)

12. Connect transmission harness connectors and clip.
Connector: transfer switch (4X4), 2-4 actuator (4X4), car speed sensor, 1-2 and 3-4 indicator switch.


13. Install bracket and transmission harness clamps(12) to the transmission case.

14. Install harness heat protector(13) (6VD1 engine).

15. Connect fuel pipe to transmission side.




16. Install fuel pipe heat protector(11) and clip.



17. Install center exhaust pipe(10) (6VD1 engine).


Torque: 43 N-m (32 lb ft)



18. Install front(9) (4X4) and rear propeller shaft(8).

Torque: 63 N-m (46 lb ft)

19. Install transfer protector(6) (4X4) and fairing plate(7).
Lower the vehicle.



20. Install gear control lever(5) and transfer control lever(5) (4X4).

21. Install grommet assembly(4).


22. Install center console(3), rear console and lower cluster assembly.

23. Install transfer control lever knob(2) (4X4) and gear control lever knob(1).

24. Connect battery ground cable.

Transmission (TREMEC T5R)

Disassembled View




220RW043

Legend

- | | |
|-----------------------------|---------------------------------------|
| (1) Gear Control Lever Knob | (8) Propeller Shaft |
| (2) Lower Cluster Assembly | (9) Fuel Pipe Heat Protector |
| (3) Rear Console | (10) Flywheel Undercover |
| (4) Center Console | (11) Transmission Mounting Rubber Nut |
| (5) Grommet Assembly | (12) Transmission Mount Rubber |
| (6) Gear Control Lever | (13) Third Crossmember |
| (7) Slave Cylinder | (14) Transmission |


Removal

1. Disconnect battery ground cable.
2. Remove gear control lever knob(1) and place gear shift lever in the neutral position.
3. Remove lower cluster assembly(2).




740RW021

4. Remove rear console(3).




256RW005

5. Remove center console(4).



F07RW019


6. Remove grommet assembly(5).




262RW024

7B-20 MANUAL TRANSMISSION

7. Remove gear control lever(6).




8. Raise and support vehicle with suitable jack stands. Remove flexible hose bracket and slave cylinder(7) with pipe.




9. Remove propeller shaft flange yoke bolts and nuts at the defferential side.

NOTE: Apply alignment marks on the flange at both front and rear sides.




10. Remove propeller shaft(8) from the transmission main shaft spline.

11. Remove fuel pipe heat protector(9) and clip.



12. Disconnect reverse switch and speed sensor harness connector.
13. Remove two cover bolts from the clutch housing and flywheel under cover(10).
14. Support the transmission with a transmission jack.
15. Remove two transmission mounting rubber nuts(11).




16. Remove transmission mount rubber(12).
17. Remove six crossmember bolts and third crossmember(13).
18. Remove transmission retaining nuts and bolts.
Remove the transmission(14) from the vehicle.

Installation

1. Apply a thin coat of molybdenum disulfide grease to the top gear shaft spline.
2. Slowly operate the transmission jack until the front of transmission jack is aligned with rear of the engine. The slope of the engine and the transmission must be the same.
3. Align the top gear shaft spline with the clutch driven plate spline.
Install the transmission(14) to the engine.
4. Tighten the transmission nuts and bolts as shown in the figure.
Flexible hose bracket bolt is installed at the step of slave cylinder installation.

7B-22 MANUAL TRANSMISSION



5. Install the transmission mounting rubber(12) to the transmission case.


Torque: 41 N·m (30 lb ft)

6. Install the third crossmember(13) to the frame.

Torque: 76 N·m (56 lb ft)



7. Install the transmission to third crossmember.

Torque: 41 N·m (30 lb ft)




Remove the transmission jack from transmission side.

8. Install flywheel under cover(10).
9. Connect reverse switch and speed sensor harness connector.
10. Connect fuel pipe to transmission side.



11. Install fuel pipe heat protector(9) and clip.



12. Insert propeller shaft splined yoke into the transmission mainshaft spline.
Install the propeller shaft flange yoke to the drive pinion flange.

Torque: 50 N·m (37 lb ft)


13. Install slave cylinder(7) and flexible hose bracket.

Slave cylinder bolt

Torque: 50 N·m (37 lb ft)


Flexible hose bracket bolt

Torque: 40 N·m (30 lb ft)




7B-24 MANUAL TRANSMISSION

14. Lower the vehicle and install gear control lever(6).



262RW025

15. Install grommet assembly(5).



262RW024


16. Install center console(4), rear console(3) and lower cluster assembly(2).

Install gear control lever knob(1).

17. Connect battery ground cable.

Transmission Case

Major Component (MUA, 4X2)




220RW050

Legend


- | | |
|-------------------------------------|--|
| (1) Clutch Release Bearing | (7) Speedometer Sensor and Speedometer Driven Gear |
| (2) Shift Fork | (8) Gear Control Box Assembly |
| (3) Fulcrum Bridge | (9) Rear Cover with Oil Seal |
| (4) Front Cover (with Oil Seal) | (10) 1-2 and 3-4 Indicator Switch, Pin, and Ball |
| (5) Counter Front Bearing Snap Ring | (11) Intermediate Plate with Gear Assembly |
| (6) Top Gear Bearing Snap Ring | (12) Transmission Case |

Disassembly


1. Clean the exterior of the unit with solvent.
2. Remove the drain plug from the transmission case and drain the lubricant.
3. Remove the clutch release bearing(1) from the transmission case.




4. Remove the snap pin.
Remove the shift fork pin and shift fork(2) from the fulcrum bridge.



5. Remove the fulcrum bridge bolts.
Remove the fulcrum bridge(3) from the transmission case.
Remove the front cover(4) and gasket from the transmission case.



6. Remove snap ring(5) fixing counter front bearing.
7. Use a pair of snap ring pliers to remove the snap ring(6) fixing top gear bearing.



8. Remove the speedometer sensor(7).
Remove the plate(7).
Remove the driven gear bushing and driven gear(7).

NOTE: Apply a reference mark to the driven gear bushing before removal.

9. Remove gear control box assembly(8).
10. Remove the rear cover assembly from the transmission case.
11. Remove 1-2 and 3-4 indicator switch(10), pin(10) and ball(10).
Remove intermediate plate with gear assembly(11) from transmission case(12).

Reassembly

- 1. Apply recommended liquid gasket (LOCTITE 17430) or its equivalent to the transmission case(12), intermediate plate(11) and rear cover(9) fitting surfaces.
- 2. Install the intermediate plate with gear assembly(11) to the transmission case(12).
Pull out the top gear shaft until the ball bearing snap ring groove protrudes from the transmission case front cover fitting face.
Avoid subjecting the mainshaft to sudden shock or stress.
- 3. Tighten the transmission rear cover bolts to the specified torque.


Torque: 37 N-m (27 lb ft)

NOTE:

Notes When Tightening the Bolt:

- After cleaning the bolt hole, dry it thoroughly with air.
- After cleaning the screw face of a removed bolt or new one, dry it thoroughly. Apply recommended liquid gasket (LOCTITE 242) or its equivalent before tightening it.
- 4. Install a new gasket and gear control box assembly(8).
Install the harness clips and brackets and then tighten four new gear control box bolts to the specified torque.

Torque: 20 N-m (14 lb ft)



- 5. Install the O-ring(4) to the speedometer driven gear bushing(3).
Install the driven gear to the speedometer driven gear bushing(3).
- 6. Install the speedometer driven gear assembly(7) to the transmission rear cover(9).
Install the plate(1) to the transmission rear cover(9).

Torque: 15 N-m (11 lb ft)

- 7. Install the speedometer sensor(7).

Torque: 27 N-m (20 lb ft)

Type	Drive gear teeth × Driven gear teeth
A	6 × 17 6 × 18
B	6 × 20

225RW008

7B-28 MANUAL TRANSMISSION

8. Install top gear bearing snap ring(6) and counter front bearing snap ring(5).

○Use a pair of snap ring pliers to install the snap rings to the mainshaft and countershaft.

○The snap rings must be fully inserted into the bearing snap ring groove.

9. Install front cover (with oil seal) (4).


Front Cover Oil Seal Replacement

○Remove the oil seal from the front cover.

○Apply engine oil to a new oil seal outer circumference.

○Apply recommended grease to the oil seal lip.

○Use the oil seal installer J-26540 to install the oil seal to the front cover.



10. Install a new packing and front cover(4) to the transmission case.

NOTE: Take care not to damage the oil seal.

Notes When Tightening the Bolt:

○After cleaning the bolt hole, dry it thoroughly with air.


○After cleaning the screw face of a removed bolt or new one, dry it thoroughly. Apply recommended liquid gasket (LOCTITE 242) or its equivalent before tightening it.

Tighten six new front cover bolts to the specified torque.

Torque: 25 N-m (18 lb ft)

11. Install the fulcrum bridge(3) to the transmission case. Tighten three fulcrum bridge bolts to the specified torque.


Torque: 38 N-m (28 lb ft)




12. Apply grease to the pin hole inner circumferences and thrust surfaces.

Attach the shift fork(2) to the fulcrum bridge(3) by inserting the shift fork pin from the bottom side of the fulcrum bridge.

Install the washer and snap pin.




13. Apply grease to the areas as shown in the figure.




○ Install the release bearing(1) to the shift fork(2) in the proper direction.

NOTE: Ensure release bearing is properly positioned during installation, as shown in the figure.



Transmission Case and Transfer Case

Major Component (MUA, 4X4)




220RW041

Legend


- | | |
|--|--|
| (1) Clutch Release Bearing | (15) Ball Bearing |
| (2) Shift Fork | (16) Lock Nut |
| (3) Fulcrum Bridge | (17) High-Low Clutch Hub and Sleeve |
| (4) Front Cover (with Oil Seal) | (18) Transfer Input Gear |
| (5) Counter Front Bearing Snap Ring | (19) Needle Bearing |
| (6) Top Gear Bearing Snap Ring | (20) Bearing Collar |
| (7) Speedometer Sensor and Speedometer Driven Gear | (21) Ball |
| (8) Front Companion Flange | (22) Plate |
| (9) Rear Companion Flange | (23) Bearing Snap Ring |
| (10) Gear Control Box Assembly | (24) Front Output Gear Assembly |
| (11) 2WD-4WD Actuator Assembly | (25) Bearing Snap Ring |
| (12) Transfer Rear Case Assembly | (26) Counter Gear Assembly |
| (13) Detent, Shift Arm, and Interlock Pin | (27) 1-2 and 3-4 Indicator Switch, Pin, and Ball |
| (14) Bearing Snap Ring | (28) Transfer Case Assembly |
| | (29) Intermediate Plate with Gear Assembly |
| | (30) Transmission Case |

Disassembly

1. Clean the exterior of the unit with solvent.
2. Remove the drain plug from the transmission case and transfer case and drain the lubricant.
3. Remove the clutch release bearing(1) from the transmission case.




4. Remove the snap pin.
Remove the shift fork pin and shift fork(2) from the fulcrum bridge(3).



5. Remove the fulcrum bridge bolts.


○ Remove the fulcrum bridge(3) from the transmission case.

Remove the front cover(4) and gasket from the transmission case.



6. Remove counter front bearing snap ring(5) and top gear bearing snap ring(6).

Use a pair of snap ring pliers to remove the snap ring.




7B-32 MANUAL TRANSMISSION


7. Remove the speedometer sensor(7).
Remove the plate(7).
Remove the driven gear bushing and driven gear(7).

NOTE: Apply a reference mark to the driven gear bushing before removal.


8. Remove front companion flange(8) and rear companion flange(9) using the flange holder J-8614-11 to remove the end nut.



9. Disconnect breather hose from transmission and remove gear control box assembly(10).
10. Remove 2WD-4WD actuator assembly(11) by performing the following steps:
 1. Disconnect the actuator breather hose from 2WD-4WD actuator assembly(11).




2. Remove the 2WD-4WD actuator assembly bolts.
3. Pull the 2WD-4WD actuator assembly with 2WD-4WD shift rod.




Legend

- (1) Shift Rod: 2WD-4WD (Position: 2WD)
- (2) 2WD-4WD Actuator Assembly
- (3) Pull
- (4) Rear Case Assembly
- (5) Position: 4WD
- (6) Position: 2WD

4. Offset the actuator assembly.



5. Remove the actuator assembly.



220RW029


Legend

- (7) Position: 4WD
(8) Mode: 2WD

NOTE: Before removing the transmission and transfer assembly from vehicle, change the transfer mode to 2WD using the 4WD push button switch on dash panel.


11. Remove the transfer rear cover assembly(12) from the transfer case(28).
12. Regarding detent, shift arm, and interlock pin(13) disassembly, refer to Detent, Shift Arm, and Interlock Pin in Drive Line/Axle section.
13. Use a pair of snap ring pliers to remove the bearing snap ring(14).

14. Use a bearing remover J-37217 and puller J-37487 to remove the ball bearing(15).



262RW032

15. Install the front companion flange temporarily.
Use the flange holder J-8614-11 and lock nut wrench J-37219 to remove the lock nut(16).
Remove the front companion flange.




226RW137


7B-34 MANUAL TRANSMISSION

16. Remove high-low clutch sleeve(17).

Use the universal puller to remove the high-low clutch hub(17) and transfer input gear(18).




17. Remove needle bearing(19), bearing collar(20), ball(21), and plate(22).



18. Use a pair of snap ring pliers to remove the bearing snap ring(23).

19. Use a plastic hammer to tap the front output gear assembly(24) free.



20. Remove bearing snap ring(25) by using a pair of snap ring pliers.

21. Remove the counter gear assembly(26) from the transfer case(28).

22. Remove 1-2 and 3-4 indicator switch, pin and ball(27).

23. Remove the transfer case assembly(28) from the transmission case.

○Refer to Transfer Case Assembly in Drive Line/Axle section for repair of transfer case assembly.

24. Pull out intermediate plate with gear assembly(29) from transmission case.

Reassembly

1. Apply recommended liquid gasket (LOCTITE 17430) or its equivalent to the transmission case(30), intermediate plate(29) and transfer case(28) fitting surfaces.

2. Install the intermediate plate with gear assembly(29) to the transmission case(30).

Pull out the top gear shaft until the ball bearing snap ring groove protrudes from the transmission case front cover fitting face.

Avoid subjecting the mainshaft to sudden shock or stress.

3. Install the transfer case assembly(28) to the intermediate plate with gear assembly.

Tighten the eight transmission-transfer case bolts to the specified torque.

Torque: 37 N·m (27 lb ft)

Refer to Transfer Rear Case Assembly in Drive Line/Axle section for oil seal replacement.

4. Install 1-2 and 3-4 indicator switch, pin and ball(27).

5. Install the counter gear assembly(26) to the transfer case(28).


6. Use a pair of snap ring pliers to install the snap ring(25) to the transfer case(28).

NOTE: The snap ring must be fully inserted into the transfer case snap ring groove.

7. Install front output gear assembly(24).
8. Use a pair of snap ring pliers to install the snap ring (23) to the transfer case(28).


NOTE: The snap ring must be fully inserted into the transfer case snap ring groove.

9. Install plate(22), ball(21), bearing collar(20), needle bearing(19), and transfer input gear(18).
10. Install High-low clutch hub and sleeve(17).
The clutch hub face (with the heavy boss) must be facing the transfer input gear side.




11. Install the front companion flange temporarily.
○Use the flange holder J-8614-11 and lock nut wrench J-37219 to install the lock nut(16).

Torque: 137 N·m (101 lb ft)




12. Use the punch to stake the lock nut at one spot.
13. Use a suitable drift and hammer to install the ball bearing(15).



14. Use a pair of snap ring pliers to install the bearing snap ring(14).
15. Regarding detent, shift arm, and interlock pin(13) assembly, refer to Detent, Shift Arm, and Interlock Pin in Drive Line/Axle section.


7B-36 MANUAL TRANSMISSION

16. Apply recommended liquid gasket (LOCTITE 17430) or its equivalent to the transfer rear case fitting faces.



17. Perform the following steps before fitting the transfer rear case(12):

1. Shift the High-Low shift rod to the 4H side.
2. The cut-away portion of select rod head should align with the rear case hole's stopper.




18. Tighten the eleven transfer rear case bolts to the specified torque.

Torque: 37 N·m (27 lb ft)

19. Install 2WD-4WD actuator assembly(11) by performing the following steps.

1. Shift the 2WD-4WD shift rod to the 4WD side.


2. Join the rod grooves of 2WD-4WD actuator assembly and shift rod.



Legend

- (11) Shift Rod: 2WD-4WD (Position: 4WD)
 (12) 2WD-4WD Actuator Assembly (Mode: 2WD)
 (13) Rear Case Assembly

3. Push the 2WD-4WD actuator assembly with 2WD-4WD shift rod till the shift rod reaches the 2WD position.



Legend

- (14) Position: 2WD
 (15) Mode: 2WD

4. Tighten the 2WD-4WD actuator bolts to the specified torque.


Torque: 19 N·m (14 lb ft)

5. Connect the actuator breather hose to actuator.

20. Install a new packing and gear control box assembly(10).

Install the harness clips and brackets and then tighten four new gear control box bolts to the specified torque.

Torque: 20 N·m (14 lb ft)



21. Install the rear and front companion flange(9) (8).

Install the O-ring(9).

Use the flange holder J-8614-11 to tighten the flange nuts(9) (8) to the transfer case.


Tighten new transfer flange nuts(9) (8) to the specified torque.

Rear Companion Flange

Torque: 167 N·m (123 lb ft)

Front Companion Flange

Torque: 137 N·m (101 lb ft)





22. Use the punch J-39209 to stake the rear companion flange nut at two spots.

Punch: J-39209


○ Stake the front companion flange nut at one spot.

NOTE: Be sure to confirm that there is no crack at the staked portion of the flange nut after staking.





23. Install the O-ring (4) to the speedometer driven gear bushing(3).
Install the driven gear to the speedometer driven gear bushing(3).
Install the speedometer driven gear assembly(7) to the transfer rear cover.



24. Install the plate to the transfer rear cover.

Torque: 15 N·m (11 lb ft)

25. Install the speedometer sensor.

Torque: 27 N·m (20 lb ft)

26. Install top gear bearing snap ring(6) and counter front bearing snap ring(5).

Use a pair of snap ring pliers to install the snap rings to the mainshaft and countershaft.

The snap rings must be fully inserted into the bearing snap ring groove.

27. Install a new packing and front cover (with oil seal) (4) to the transmission case.

NOTE: Take care not to damage the oil seal.


Notes When Tightening the Bolt:

- After cleaning the bolt hole, dry it thoroughly with air.
 - After cleaning the screw face of a removed bolt or new one, dry it thoroughly. Apply recommended liquid gasket (LOCTITE 242) or its equivalent before tightening it.
- Tighten six new front cover bolts to the specified torque.

Torque: 25 N·m (18 lb ft)

28. Install the fulcrum bridge(3) to the transmission case.
Tighten three fulcrum bridge bolts to the specified torque.


Torque: 38 N·m (28 lb ft)




29. Apply grease to the pin hole inner circumferences and thrust surfaces.

Attach the shift fork(2) to the fulcrum bridge(3) by inserting the shift fork pin from the bottom side of the fulcrum bridge.

Install the washer and snap pin.




30. Apply grease to the areas shown in the figure.




Install the release bearing(1) to the shift fork(2) in the proper direction.

NOTE: Ensure release bearing is properly positioned during installation, as shown in the figure.



Intermediate Plate with Gear Assembly, Detent, Shift Arm, and Interlock Pin (MUA)

Disassembled View



220RS010


Legend

- | | |
|---|---|
| (1) Detent Spring Plate and Gasket | (7) 1st-2nd Shift Rod |
| (2) Detent Spring | (8) 3rd-4th Shift Rod |
| (3) Detent Ball | (9) 3rd-4th Shift Arm |
| (4) Spring | (10) 1st-2nd Shift Arm |
| (5) Rev-5th Shift Rod | (11) Interlock Pin |
| (6) Rev-5th Shift Arm and Reverse Inhibitor | (12) Intermediate Plate and Gear Assembly |

Disassembly


1. Remove detent spring plate and gasket(1), detent spring(2) and detent ball(3).

Use a magnetic hand to remove the detent balls from the intermediate plate.




2. Remove spring(4).
3. Remove rev-5th shift rod(5), and rev-5th shift arm and reverse inhibitor(6).
Remove 1st-2nd shift rod(7), 3rd-4th shift rod(8), 3rd-4th shift arm(9), and 1st-2nd shift arm (10).


○Hold a round bar against the shift rod end.



○Use a spring pin remover to remove the shift arm spring pins from the shift arms and the shift rods.



○Move the 3rd-4th shift rod forward.



○Remove the rev-5th, 1st-2nd and 3rd-4th shifter rods carefully. Interlock pins are located between the shifter rods in the intermediate plate.

4. Remove interlock pin(11) from intermediate plate and gear assembly(12).

Inspection and Repair


Make the necessary adjustments, and part replacements if excessive wear or damage is discovered during inspection.

Shift Arm Thickness

- Use a micrometer to measure the shift arm thickness. If the measured value is less than the specified limit, the shift arm must be replaced.

Shift Arm Thickness

	Standard	Limit
1st-2nd	9.60-9.85 mm (0.378-0.388 in)	9.0 mm (0.354 in)
3rd-4th Rev.5th	9.60-9.80 mm (0.378-0.386 in)	




230RS006

Detent Spring Free Length

- Use a vernier caliper to measure the detent spring free length. If the measured value is less than the specified limit, the detent spring must be replaced.

Detent Spring Free Length

Standard	Limit
26.8 mm (1.06 in)	26.2 mm (1.03 in)




220RS012

Detent Spring Tension

- Use a spring tester to measure the valve spring tension. If the measured value is less than the specified limit, the detent spring must be replaced.

Detent Spring Tension


Compressed height	Standard
20 mm (0.787 in)	87.2 - 97.1 N (19.6 - 21.8 lb)



220RS013

Reassembly


1. Install 1st-2nd shift arm(10) and 3rd-4th shift arm(9) to intermediate plate and gear assembly(12).
2. Install 3rd-4th shift rod(8) and 1st-2nd shift rod(7).
 - Install the interlock pin(11) to the shift rod.
 - Install the shift rod together with the interlock pin to the intermediate plate.
 - Do not allow the interlock pin to fall from the shift rod.
 - Hold a round bar against the shift rod end lower face to protect it against damage.
 - Install a new spring pin.
 - Never reinstall the used spring pin.



230RS007

3. Install rev-5th shift arm and reverse inhibitor(6) and rev-5th shift rod(5).
 - Apply oil to the reverse inhibitor inner surface.
 - Install the interlock pin(11) to the shift rod.
 - Install the shift rod together with the interlock pin to the intermediate plate.
 - Do not allow the interlock pin to fall from the shift rod.
 - Hold a round bar against the shift rod end lower face to protect it against damage.
 - Install a new spring pin.
 - Never reinstall the used spring pin.
4. Install spring(4).
5. Put detent balls(3) in the intermediate plate holes.
 - Apply oil to the detent balls.
6. Install detent springs(2) and detent spring plate and gasket(1).
 - Install a new gasket and the detent spring plate.
 - Tighten the detent spring plate bolts to the specified torque.

Torque: 20 N·m (14 lb ft)




220RS030

Legend

- (1) Warped

Reverse Gear and 5th Gear (MUA)

Disassembled View




226RS094

Legend


- | | |
|-----------------------------------|------------------------------------|
| (1) Oil Seal Collar (4X4) | (14) Reverse Idler Gear |
| (2) Ball Bearing (4X4) | (15) Reverse Idler Shaft |
| (1) Bearing Snap Ring (4X2) | (16) Bearing Snap Ring |
| (2) Ball Bearing (4X2) | (17) Ball Bearing |
| (3) Bearing Snap Ring (4X2) | (18) Counter 5th Gear |
| (4) Speedometer Drive Gear (4X2) | (19) Counter Reverse Gear |
| (5) Clip (4X2) | (20) 5th Gear |
| (6) Retainer Snap Ring (4X2) | (21) 5th Block Ring |
| (7) Retainer | (22) Needle Bearing |
| (8) Thrust Plate | (23) Mainshaft Nut |
| (9) Thrust Washer and Lock Ball | (24) Rev-5th Synchronizer Assembly |
| (10) Reverse Idler Gear Snap Ring | (25) Reverse Block Ring |
| (11) Reverse Idler Gear Assembly | (26) Reverse Gear |
| (12) Idle Shaft Pin | (27) Needle Baring |
| (13) Thrust Washer | (28) Bearing Plate and Screw |
| | (29) Bearing Snap Ring |
| | (30) Intermediate Plate |

Disassembly


1. Use a pair of snap ring pliers to remove the bearing snap ring(1). (4X2)
2. Set the bearing remover J-37217 and puller J-37487 to the bearing and the mainshaft end to remove ball bearing(2). (4X2)




3. Remove bearing snap ring(3), speedometer drive gear(4), clip(5), retainer snap ring(6) and retainer(7). (4X2)
4. Set the retaining ring remover J-37222 and puller J-37487 to the retainer(7) and the mainshaft end. (4X4)



5. Remove the retainer(7) together with the bearing(2) and the oil seal collar(1). (4X4)
The universal puller may be used in place of the retaining ring remover.
6. Remove thrust plate(8) and thrust washer and lock ball(9).
7. Use a pair of snap ring pliers to remove reverse idler gear snap ring(10).




8. Remove the reverse idler gear assembly(11) from the intermediate plate(30).



9. Remove idle shaft pin(12), thrust washer(13), reverse idler gear(14), and reverse idler shaft(15).
10. Use a pair of snap ring pliers to remove the snap ring(16).


7B-46 MANUAL TRANSMISSION

11. Attach the bearing remover to the counter gear shaft.
Use the bearing remover to remove the ball bearing(17) and the counter 5th gear(18).




226RS006

12. Remove counter reverse gear(19).
13. Remove 5th gear(20), 5th block ring(21), and needle bearing (2 piece type) (22).




226RS007

14. Engage the 3rd-4th synchronizer with the 3rd gear.
Engage the 1st-2nd synchronizer with the 1st gear.
Attach the holding fixture J-37224 and base J-3289-20 to the mainshaft and the counter gear.




226RS008

- Use the mainshaft nut wrench J-37219 to remove the mainshaft nut(23).




226RS009

15. Use pry bars between the reverse gear(26) and bearing plate(28) to remove the Rev-5th synchronizer assembly(24) together with reverse block ring(25) and reverse gear(26).




16. Remove needle bearing(27).

17. Use the torx bit wrench J-37225(T45) to remove the bearing plate and screw(28) from the intermediate plate.



18. Use the snap ring pliers(2) to remove the mainshaft bearing snap ring(1) (29).



19. Hold the snap ring open with the pliers.

Push the intermediate plate(30) toward the rear of the transmission to remove it.


The bearing snap ring will come free.

Inspection and Repair

Refer to Top Gear Shaft, Main Gear Shaft, and Counter Gear in this section for inspection and repair.

Reassembly


1. Mesh the counter gear with the mainshaft assembly. Install the holding fixture J-37224 and base J-3289-20 to the mainshaft and the counter gear.



7B-48 MANUAL TRANSMISSION



2. Place the holding fixture (with the mainshaft and the counter shaft) in a vise.
Install the intermediate plate(30).
3. Install bearing snap ring(29).
4. Apply recommended thread locking agents (LOCTITE 242) or its equivalent to each of the bearing plate screw threads.
Install bearing plate and screw(28).
Tighten the screws to the specified torque by using torx bit wrench J-37225.

Torque: 15 N·m (11 lb ft)




5. Install needle bearing(27), reverse gear(26), and reverse block ring(25).
6. Assemble rev-5th synchronizer assembly(24) by performing the following steps.
 1. Turn the clutch hub face(1) toward the sleeve groove(2) (rear side) on the outer circumference.
 2. Check that the inserts(3) fit snugly into the block ring insert grooves.
 3. Check that the inserts springs(4) are fitted to the inserts as shown in the illustration.
 4. Check that the clutch hub(5) and the sleeve(6) slide smoothly.
5. Install the synchronizer assembly to the mainshaft.

The clutch hub face (with the heavy boss) must be facing the reverse gear side.



7. Mesh the 1st-2nd and 3rd-4th synchronizers with both the 1st and 3rd gears (double engagement).




226RS015

This will prevent the mainshaft from turning.


8. Install the new mainshaft hub nut.
Use the mainshaft nut wrench J-37219 to tighten the mainshaft nut(23) to the specified torque.

Torque: 137 N·m (101 lb ft)



226RS016

9. Use a punch to stake the mainshaft nut.




226RW153

10. Install needle bearing(22), 5th block ring(21), and 5th gear(20).

11. Apply engine oil to the counter reverse gear(19) and the reverse gear(26).


Install the counter reverse gear(19) to the counter shaft.

The reverse gear projection must be facing the intermediate plate.



226RW151


12. Install the counter 5th gear(18) to the transmission.



226RS019

13. Install ball bearing(17) and bearing snap ring by performing the following steps:


- Select the snap ring which will provide the minimum clearance between the ball bearing and the snap ring.



226RS020

- There are six snap ring sizes available.

The snap rings are color-coded to indicate their thickness.



226RS021

Ball Bearing and Snap Ring Clearance

Standard: 0–0.15 mm (0–0.0059 in)

Snap Ring Availability


Thickness	Color Coding
1.1 mm (0.043 in)	White
1.2 mm (0.047 in)	Yellow
1.3 mm (0.051 in)	Blue
1.4 mm (0.055 in)	Pink
1.5 mm (0.059 in)	Green
1.6 mm (0.063 in)	Brown

- Use a pair of snap ring pliers to install the snap ring(16) to the counter gear shaft.

The snap ring must be fully inserted into the counter gear shaft snap ring groove.

14. Assemble reverse idler shaft(15), reverse idler gear(14), thrust washer(13), and idle shaft pin(12) into reverse idler gear assembly(11).

15. Select reverse idler gear snap ring(10) which will provide the minimum clearance between the intermediate plate(30) and the snap ring(10).




○There are three snap ring sizes available. The snap rings are color-coded to indicate their thickness.

Intermediate Plate and Snap Ring Clearance
Standard: 0 – 0.15 mm (0 – 0.0059 in)

Snap Ring Availability

Thickness	Color Coding
1.2 mm (0.047 in)	White
1.3 mm (0.051 in)	Yellow
1.4 mm (0.055 in)	Blue



○Use a pair of snap ring pliers to install the snap ring to the reverse idler shaft. The snap ring must be fully inserted into the reverse idler shaft snap ring groove.


16. Install thrust washer and lock ball(9) by performing the following steps:

○Use a thickness gauge to measure the clearance between the 5th gear and the thrust washer.

5th Gear and Thrust Washer Clearance

Standard: 0.10 – 0.25 mm (0.004 – 0.010 in)

○Measure clearance “A” as shown in the figure.




○Select appropriate thrust washer from chart.
○There are four thrust washer sizes available.
○The thrust washers are color coded to indicate their thickness.

7B-52 MANUAL TRANSMISSION

Thrust Washer Availability


Thickness mm (in)	Color Coding	A mm (in)	Clearance mm (in)
7.9 (0.311)	White	8.05–8.1 (0.317–0.319)	0.15–0.25 (0.006–0.010)
8.0 (0.315)	Yellow	8.1–8.2 (0.319–0.323)	0.1–0.25 (0.004–0.010)
8.1 (0.319)	Green	8.2–8.3 (0.323–0.327)	0.1–0.25 (0.004–0.010)
8.2 (0.323)	Bluen	8.3–8.36 (0.327–0.329)	0.1–0.21 (0.004–0.008)



226RS024


- Apply grease to the thrust washer and the lock ball.
- Install the thrust washer and the lock ball.

17. Install thrust plate(8) and retainer(7).
18. Install retaining snap ring(6), clip(5), speedometer drive gear(4), and bearing snap ring(3). (4X2)
19. Use the installer J-37223 to install the ball bearing(2) to the mainshaft. (4X2)



226RS096

20. Install bearing snap ring(1). (4X2)
 21. Apply engine oil to the bearing inner and outer circumference. (4X4)
- Use the installer J-37223 to install the ball bearing(2) to the mainshaft in proper direction. (4X4)




226RS025

22. Install oil seal collar(1). (4X4)

Top Gear Shaft, Main Gear Shaft, and Counter Gear Shaft (MUA)

Disassembled View




226RS026

Legend


- | | |
|-----------------------------------|------------------------------------|
| (1) Top Gear Shaft Snap Ring | (16) 1st Outside Ring |
| (2) Top Gear Shaft | (17) 1st Block Ring |
| (3) Ball Bearing | (18) Needle Bearing |
| (4) Needle Bearing | (19) Clutch Hub Snap Ring |
| (5) Top Block Ring | (20) 1st-2nd Synchronizer Assembly |
| (6) Mainshaft Snap Ring | (21) 2nd Block Ring |
| (7) 3rd-4th Synchronizer Assembly | (22) 2nd Outside Ring |
| (8) 3rd Block Ring | (23) 2nd Inside Ring |
| (9) 3rd Gear | (24) 2nd Gear |
| (10) Needle Bearing | (25) Needle Bearing |
| (11) Needle Bearing Collar | (26) Mainshaft |
| (12) Mainshaft Ball Bearing | (27) Bearing Snap Ring |
| (13) 1st Gear Thrust Bearing | (28) Front Rollar Bearing |
| (14) 1st Gear | (29) Center Roller Bearing |
| (15) 1st Inside Ring | (30) Counter Gear Shaft |

Disassembly


1. Use a pair of snap ring pliers to remove the top gear shaft snap ring(1).
2. Remove top gear shaft(2) with ball bearing(3).
3. Use a bench press and the bearing remover J-22912-01 to remove the ball bearing(3).



4. Remove needle bearing(4) and top block ring(5), mainshaft snap ring.
5. Use a pair of snap ring pliers to remove the mainshaft snap ring(6).




6. Use a bench press and the bearing remover J-22912-01 to remove the 3rd-4th synchronizer assembly(7) as a set. Disassemble the synchronizer assembly.




Legend

- (1) Springs
- (2) Sleeve
- (3) Clutch Hub
- (4) Inserts


7. Remove 3rd block ring(8), 3rd gear(9), and needle bearing(10).
8. Remove needle bearing collar(11).
9. Use a bench press and the bearing remover J-22912-01 to remove the 1st gear(14) together with the mainshaft ball bearing(12) and 1st gear thrust bearing(13).



- 10. Disassemble 1st inside ring(15), 1st outside ring(16), and 1st block ring(17).
- 11. Remove needle bearing(18).
- 12. Use a pair of snap ring pliers to remove the clutch hub snap ring(19).




- 13. Use a bench press and the bearing remover J-22912-01 to remove the 2nd gear(24) together with 1st-2nd synchronizer assembly(20), 2nd block ring(21), 2nd outside ring(22), and 2nd inside ring(23).
Disassemble the synchronizer assembly.



- Legend**
- (1) Springs
 - (2) Sleeve
 - (3) Clutch Hub
 - (4) Inserts

- 14. Remove needle bearing(25) from mainshaft(26).
- 15. Remove bearing snap ring(27)

- 16. Use a bench press and the bearing remover J-22912-01 to remove the front roller bearing(28).




- 17. Remove center roller bearing(29) from counter gear shaft(30).

Inspection and Repair

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.

Block Ring and Dog Teeth Clearance

- Use a thickness gauge to measure the clearance between the block ring and the dog teeth.




If the measured value exceeds the specified limit, the block ring must be replaced.

Block Ring and Dog Teeth Clearance

Standard	Limit
1.5 mm (0.059 in)	0.8 mm (0.032 in)

1st-2nd Synchronizer (3-CONE)

- Use a thickness gauge to measure the clearance between the block ring and the dog teeth.




If the measured value exceeds the specified limit, the 1st-2nd synchronizer assembly must be replaced.

Block Ring and Dog Teeth Clearance

Standard	Limit
1.5 mm (0.059 in)	0.8 mm (0.032 in)

Block Ring and Insert Clearance

- Use a vernier caliper or thickness gauge to measure the clearance between the block ring and the insert.




If the measured value exceeds the specified limit, the block ring and the insert must be replaced.

Block and Insert Clearance

	Standard	Limit
3rd-4th	3.46 – 3.74 mm (0.136 – 0.147 in)	4.0 mm (0.158 in)
1st-2nd	4.34 – 4.66 mm (0.171 – 0.183 in)	4.9 mm (0.193 in)
Rev-5th	3.59 – 3.91 mm (0.141 – 0.154 in)	4.1 mm (0.161 in)

Clutch Hub and Insert Clearance

- Use a thickness gauge to measure the clearance between the clutch hub and the insert.




If the measured value exceeds the specified limit, the clutch hub and the insert must be replaced.

Clutch Hub and Insert Clearance

	Standard	Limit
3rd-4th	0.01 – 0.19 mm (0.0004 – 0.0075 in)	0.3 mm (0.012 in)
1st-2nd	0.09 – 0.31 mm (0.0035 – 0.0122 in)	0.4 mm (0.016 in)
Rev-5th		

Mainshaft Run-out

- Install the mainshaft to V-blocks.
- Use a dial indicator to measure the mainshaft central portion run-out.




If the measured mainshaft run-out exceeds the specified limit, the mainshaft must be replaced.

Mainshaft Run-out
Limit: 0.05 mm (0.0020 in)

Gear Inside Diameter

- Use an inside dial indicator to measure the gear inside diameter.




If the measured value is less than the specified limit, the gear must be replaced.

Gear Inside Diameter

	Standard	Limit
1st 3rd	45.000 – 45.013 mm (1.771 – 1.772 in)	45.100 mm (1.776 in)
2nd	52.000 – 52.013 mm (2.047 – 2.048 in)	52.100 mm (2.051 in)
Rev.	48.000 – 48.013 mm (1.889 – 1.890 in)	48.100 mm (1.894 in)
5th	32.000 – 32.013 mm (1.259 – 1.260 in)	32.100 mm (1.246 in)

Reverse Idler Gear and Idler Gear Shaft Clearance

- Use a micrometer to measure the idler gear shaft diameter.
- Use an inside dial indicator to measure the idler gear inside diameter.




- Calculate the idler gear and idler gear shaft clearance.
Idler gear inside diameter-idler gear shaft diameter = idler gear and idler gear shaft clearance.
If the measured value exceeds the specified limit, the idler gear and/or the idler gear shaft must be replaced.

Idler Gear and Idler Gear Shaft Clearance
Standard: 0.041–0.074 mm (0.016–0.0029 in)
Limit: 0.150 mm (0.0059 in)

Clutch Hub Spline Play

- Set a dial indicator to the clutch hub to be measured.



- Move the clutch hub as far as possible to both the right and the left.

Note the dial indicator reading.

If the measured value exceeds the specified limit, the clutch hub must be replaced.

Clutch Hub Spline Play


	Standard	Limit
1st-2nd	0 – 0.1 mm (0 – 0.004 in)	0.2 mm (0.008 in)
3rd-4th		
Rev. 5th	0 – 0.2 mm (0 – 0.008 in)	0.3 mm (0.012 in)

Ball Bearing Play

- Use a dial indicator to measure the ball bearing play.

Ball Bearing Play

Limit: 0.2 mm (0.008 in)



226RS043


Reassembly

1. Install center roller bearing(29) to counter gear shaft(30).

- Apply engine oil to the bearing inner and outer circumferences.

- Install the roller bearing in the proper direction.

NOTE: Check that outer race moves only in the direction of arrow.



226RS044


2. Install front roller bearing(28) by performing the following steps.

- Use bearing installer to install the front roller bearing inner race to the counter gear shaft.

- Install the outer race and roller assembly.

The snap ring groove must be facing the transmission front side.

○Use bearing installer J-35283 to install the ring.




226RS045

Legend

- (1) Ring
- (2) Outer Race and Roller Assembly
- (3) Inner Race


3. Install bearing snap ring(27) to mainshaft(26).
4. Apply engine oil to the needle bearing(25) and the 2nd gear thrust surfaces.
Install the needle bearing(25) and the 2nd gear(24) to the mainshaft.
The 2nd gear dog teeth must be facing the transmission rear side.



226RS046

5. Assemble 2nd inside ring(23), 2nd outside ring(22), and 2nd block ring(21).

○Apply engine oil to the synchronizer ring friction surfaces.



226RS047


Legend

- (1) Block Ring
- (2) Outside Ring
- (3) Inside Ring
- (4) 2nd Gear
- (5) Needle Bearing


6. Assemble 1st-2nd synchronizer assembly by performing the following steps:

1. Check that the inserts(3) fit snugly into the block ring insert grooves.
2. Check that the inserts springs(4) are fitted to the inserts as shown in the illustration.
3. Check that the clutch hub(5) and the sleeve(6) slide smoothly.
4. Install the synchronizer assembly to the mainshaft.

The clutch hub face (with the heavy boss) must be facing the 2nd gear side.




226RS048



226RS050

There are three snap ring sizes available.


The snap rings are color coded to indicate their thickness.



226RS049

7. Install clutch hub snap ring(19) by performing the following steps:

- Select the snap ring which will provide the minimum clearance between the 1st-2nd clutch hub and the snap ring.



226RS021

Clutch Hub and Snap Ring Clearance


Standard: 0 – 0.1 mm (0 – 0.004 in)

Snap Ring Availability

Thickness	Color Coding
1.80 mm (0.071 in)	White
1.85 mm (0.073 in)	Yellow
1.90 mm (0.075 in)	Blue

- Use a pair of snap ring pliers to install the snap ring to the mainshaft.

The snap ring must be fully inserted into the mainshaft snap ring groove.




8. Install needle bearing(18), 1st block ring(17), 1st outside ring(16), 1st inside ring(15), and 1st gear(14).

○Apply engine oil to the needle bearing, 1st gear thrust surfaces and synchronizer ring friction surfaces.

○Install the needle bearing and the 1st gear to the mainshaft.

The 1st gear dog teeth must be facing the transmission front side.




Legend

- (1) 1st Gear
- (2) Needle Bearing
- (3) Inside Ring
- (4) Outside Ring
- (5) Block Ring

9. Install the 1st gear thrust bearing and the race(13) to the main shaft.

The thrust bearing side must be facing the transmission front side.




10. Apply engine oil to the mainshaft ball bearing(12) and the mainshaft(26).

Install the ball bearing(12) and needle bearing collar(11) to the mainshaft(26).

The ball bearing snap ring groove must be facing the transmission rear side.


Use a bench press and installer J-6133-01 to slowly force the collar into place.



7B-62 MANUAL TRANSMISSION

11. Apply engine oil to the needle bearing and the 3rd gear thrust surfaces.
Install the needle bearing(10) and the 3rd gear(9) to the mainshaft.

The 3rd gear dog teeth must be facing the transmission front side.




226RS056

12. Install 3rd block ring(8).


13. Check and install 3rd-4th synchronizer assembly(7) by the following steps:

1. Check that the inserts(3) fit snugly into the block ring insert grooves.
2. Check that the insert springs(4) are fitted to the inserts as shown in the illustration.
3. Check that the clutch hub(5) and the sleeve(6) slide smoothly.
4. Install the synchronizer assembly to the mainshaft.

The clutch hub face (with the heavy boss) must be facing the 3rd gear side.




226RW221



226RS049

14. Select and install mainshaft snap ring(6) in the following way:


- Select the snap ring which will provide the minimum clearance between the 3rd-4th clutch hub and the snap ring.



226RS058

There are three snap ring sizes available.

The snap rings are color coded to indicate their thickness.




Clutch Hub and Snap Ring Clearance
Standard: 0 – 0.1 mm (0 – 0.004 in)

Snap Ring Availability

Thickness	Color Coding
1.80 mm (0.071 in)	White
1.85 mm (0.073 in)	Yellow
1.90 mm (0.075 in)	Blue

- Use a pair of snap ring pliers to install the snap ring to the mainshaft.
The snap ring must be fully inserted into the mainshaft snap ring groove.

15. Install top block ring(5).
16. Apply grease to the bearing inner and outer circumferences and install needle bearing(4).
17. Use a bench press to install the top gear shaft ball bearing(3) to the top gear shaft(2).




The snap ring groove must be facing the transmission front side.

18. Use a pair of snap ring pliers to install the top gear shaft snap ring(1) to the bearing.

Transmission Case (TREMEC T5R)

Disassembled View




220RW061

Legend

- | | |
|---|--|
| (1) Offset Lever Roll Pin | (12) Input Shaft Bearing Retainer, Bearing Outer Race and Shim(s) |
| (2) Extension Housing Assembly | (13) Input Shaft Assembly |
| (3) Offset Lever, Detent Ball and Spring | (14) 4th Gear Blocking Ring, Mainshaft Thrust Bearing and Race, Mainshaft Needle Bearing (15 Rollres) and Spacer |
| (4) Oiling Funnel | (15) Mainshaft Rear Bearing Outer Race |
| (5) Shift Cover Assembly | (16) Mainshaft Assembly |
| (6) 5-R shift Lever Clip | (17) Counter Shaft Rear Bearing Retainer and Shim |
| (7) 5-R Lever Pivot Bolt | (18) Reverse Idler Shaft Roll Pin, Reverse Idler Shaft, Reverse Idler Gear and O-ring |
| (8) 5th Synchronizer Snap Ring, Splined Washer, Revers Cone, Reverse Blocking Ring, 5th Synchronizer, 5th Shift Fork and Rail | (19) Counter Shaft Rear Bearing Outer Race |
| (9) 5-R Shift Lever, Reverse Fork and Spring | (20) Counter Shaft Rear Bearing |
| (10) 5th Drive Gear and 5th Synchronizer Blocking Ring | (21) Counter Shaft Assembly |
| (11) Slip Yoke Seal, Snap Ring, Speedometer Drive Gear and Clip, and 5th Driven Gear Snap Ring | (22) Transmission Case |


Disassembly

1. Clean the exterior of the unit with solvent.
2. Remove the clutch release bearing and shift fork.
3. Remove the 4 bolts that hold the clutch housing to the case.




4. Mount the transmission in the holding fixture J-36842.

Install the transmission with its holding fixture into the holding fixture base J-3289-20 mounted on the end of a work bench.



5. Remove the drain plug from the transmission case and drain the lubricant.




6. Remove the speedometer driven gear assembly, using a 10 mm wrench to remove the clamp bolt. Pull out the sleeve/gear.

7. Position the offset lever(3) in the "3-4" neutral position.

NOTE: Removal of the offset lever in a position other than "3-4" may result in driving a roll pin(1) into the detent/guide plate without releasing the lever(3) from the shift shaft. Further disassembly will be difficult if this occurs.

8. Using a 3/16-inch diameter pin punch and a hammer, remove the offset lever roll pin(1) attaching the offset lever to the shift shaft.




7B-66 MANUAL TRANSMISSION


9. Remove the 8 bolts that hold the extension housing to the case, using a 15 mm wrench.
Note that two bolts use sealer.

Separate the extension housing assembly(2) from the case and shift cover. The offset lever(3) will also separate from the shift shaft.


NOTE: Do not attempt to remove the offset lever while the extension housing is still bolted to the case. The lever has a positioning lug which engages the detent/guide plate and prevents moving the lever far enough to remove it.



10. Remove the offset lever(3) from the extension housing, along with the detent ball(3) and spring(3). Remove the roll pin(1) from either the offset lever or extension housing.




11. Carefully pry the oiling funnel(4) from the rear of the counter shaft. This may be a very snug fit, and the funnel may become damaged during removal unless extreme care is used.




12. Remove the 10 bolts that hold the shift cover to the case, using a 10 mm wrench.

NOTE: Two of the shift cover bolts are also alignment dowels. Note the location of these bolts for assembly.


Remove the shift cover assembly(5) from the case by sliding it sideways toward the drain plug side of the case for a distance of 1 inch. Then lift the cover straight up from the case. You may need to break the sealer bond between the cover and case before you can separate them.




13. Remove the 5-R shift lever clip(6), using a pair of needlenose pliers.



14. Remove the 5-R lever pivot bolt(7), using a T-50 bit and ratchet. Note that this bolt uses sealer.




15. Remove the 5th synchronizer snap ring(8) from the rear of the counter shaft, using a pair of snap ring pliers.




Remove splined washer(8), reverse cone(8) and reverse blocking ring(8).

Remove the 5th synchronizer assembly(8), together with its fork/rail assembly(8), from the counter shaft.




7B-68 MANUAL TRANSMISSION


16. Using a 22 mm wrench, remove the backup lamp switch from the 5-R shift lever side of the case. Note that the threads use sealer.
Lift the 5-R lever(9) out of the transmission case.




Remove the spring from the case.
Remove the reverse fork and spring assembly(9) along with the 5-R lever(9).




17. Remove the 5th drive gear(10) and blocking ring(10) from the counter shaft.
18. Remove slip yoke seal(11) and snap ring(11) from the mainshaft.




19. Remove speedometer drive gear(11) and clip(11) by using speed drive gear puller J-38878.




20. Remove 5th driven gear snap ring.



21. Scribe alignment marks on the case and input bearing retainer and remove the four input shaft bearing retainer bolts, using a 13 mm wrench. Note the thread sealer on these bolts. Remove the input bearing retainer(12), together with the bearing outer race(12) and shim(s) (12).




22. Remove the input shaft assembly(13) from the case by rotating it until the flat surface on the clutch tooth ring on the shaft allows it to clear the counter shaft.




23. Remove these 4th gear blocking ring, mainshaft thrust bearing and race, mainshaft needle bearing (15 rollers) and spacer(14) either from the input(13) or mainshaft.

24. Push the mainshaft rearward to remove the mainshaft rear bearing outer race(15).

25. Tilt and lift the mainshaft assembly(16) from the case.






226RS106


26. Remove the counter shaft rear bearing retainer by:

- Bending back the lock tabs with a punch and hammer.
- Removing the four bolts, using a 13 mm wrench, or T-40 bit and ratchet.
- Removing the retainer(17) and shim(17) from the case.




226RS107

27. Remove the roll pin(18) that holds the reverse idler shaft in the case, using a 3/16-inch diameter pin punch and a hammer.




226RS108

28. Remove the reverse idler assembly by pushing the shaft rearward and out of the case. Lift the reverse idler gear(18) and O-ring(18) out of the case. Pull out reverse idle shaft(18) rearward.




226RS109


29. Remove the counter shaft rear bearing outer race(19) by pushing it rearward.



Remove the rear bearing assembly from the counter shaft by using gear puller J-8433, bearing and gear puller J-22912-01 and split plate.



30. Remove the counter shaft assembly(21) as shown in the figure from transmission case(22).




Inspection and Repair

1. Clean all parts with solvent and dry them with compressed air.
2. Inspect these parts for cracks and damaged sealing surfaces:


- Case
- Extension housing
- Shift cover
- Input bearing retainer
- Counter shaft rear bearing retainer.

Use a fine mill file to dress minor scratches or burrs. Replace severely damaged parts. Replace the counter shaft rear bearing retainer if the tangs are broken.




7B-72 MANUAL TRANSMISSION

3. Look at surfaces on the above parts which support bearings and shafts. Replace parts which have excessive wear in these areas. Do not replace gears if phosphate coatings are worn.




4. Examine the bearing surfaces of the following parts:

- Input shaft
- Mainshaft and its gears
- Counter shaft and the fifth drive gear.




- Reverse idler shaft and its gear.



Replace parts which show signs of excessive wear. Do not file surfaces which have been hardened and precision ground.


5. Inspect shift mechanism parts as follows:

- Look for wear on the shift shaft.
- Look at the detent/guide plate and offset lever for worn edges or grooves where the detent ball and lug travel.




○Look for worn edges on these parts:

- Selector arm
- Interlock plate
- Selector plates for the 1–2 and 3–4 shift forks




- 5–R shift lever and the rollers on the reverse fork and the 5th shift rail/fork.



○Look for worn mating surfaces on the following parts:


- 1–2 shift fork, pads and synchronizer sleeve



- 3–4 shift fork, pads and synchronizer sleeve
- 5th shift rail/fork, pads and synchronizer sleeve
- Reverse fork and the mating sleeve surface of the reverse idler gear.


6. Inspect the following bearings for excessive wear:

- Crankshaft pilot bushing for the front of the input shaft
- Clutch release bearing
- Input shaft bearing
- Mainshaft pilot bearing rollers
- Mainshaft thrust bearing and its mating surfaces





7B-74 MANUAL TRANSMISSION

- Speed gear roller bearing on the mainshaft
- Mainshaft rear bearing
- Counter shaft front and rear bearings.




Replace any bearing and its races that show roughness.

7. Inspect the gear tooth surfaces on all the gear sets. Replace all mating gears in a set if any one has excessive wear on the meshing surfaces of its teeth. Look for fractures, pitting, scoring and spalling.




8. Disassemble the three synchronizer assemblies:


- The 1-2, which has three-piece assemblies.



○The 3-4, which has sintered metal blocking rings.




○The 5-R, which uses single-piece brass blocking rings.



○Examine the fit between the hub and sleeve of each synchronizer.

Besides binding shift linkage, an excessively tight or loose hub-to-sleeve fit will cause what is known as a "hard shift".




○Measure the clearance between the blocking ring and the speed gear.


Excessive wear on either the blocking ring or the speed gear cone surface will cause "shift blockout" or "gear clash".

Blocking Ring to Gear Clearance

	Standard
1-2 gear	0.87 – 1.4 mm (0.032 – 0.056 in)
3-4 gear	0.88 – 1.5 mm (0.035 – 0.059 in)




- Look for evidence of gear clash on both the synchronizer sleeve teeth or the clutch teeth on the speed gear.



226RS124


Finally, look at the synchronizer sleeve and speed gear clutch tooth area for cause of "hopout".



226RS125


Reassembly

1. Use a hydraulic press and the J-6133-01 installer to press the counter shaft rear bearing assembly(20) onto the counter shaft(21). Use tool J-37357 to support the counter shaft in the transmission case(22).



226RS126

2. Install the counter shaft rear bearing outer race(19) and retainer(17) without the shim.




226RS127

- Tighten the retainer bolts, using a 13 mm socket (or a T-40 bit) and a torque wrench.

Torque: 20 N·m (15 lb ft)

- Mount a dial indicator on the case and set it up to measure counter shaft end play.
- Move the counter shaft up and down and read the total amount of indicator travel.




226RS128

- Select shim which is the same thickness as the indicator reading, or up to 0.004 inch less than the reading.

Counter Shaft		Selective Shims	
Thickness		Thickness	
mm	(inches)	mm	(inches)
2.553	(0.1005)	3.239	(0.1275)
2.59	(0.102)	3.28	(0.129)
2.629	(0.1035)	3.315	(0.1305)
2.67	(0.105)	3.35	(0.132)
2.705	(0.1065)	3.391	(0.1335)
2.74	(0.108)	3.43	(0.135)
2.781	(0.1095)	3.467	(0.1365)
2.82	(0.111)	3.51	(0.138)
2.858	(0.1125)	3.543	(0.1395)
2.90	(0.114)	3.58	(0.141)
2.934	(0.1155)	3.620	(0.1425)
2.97	(0.117)	3.66	(0.144)
3.010	(0.1185)	3.696	(0.1455)
3.05	(0.120)	3.73	(0.147)
3.086	(0.1215)	3.772	(0.1485)
3.12	(0.123)	3.81	(0.150)
3.162	(0.1245)	3.848	(0.1515)
3.20	(0.126)	3.886	(0.1530)

- Remove the counter shaft rear bearing retainer and outer race.


- 3. Install the reverse idler shaft(18), gear(18), and O-ring(18).
- Use a 3/16-inch diameter pin punch and hammer to install the reverse idler shaft roll pin(18).



226RS129

- 4. Install the counter shaft rear bearing outer race(19), shim(17) and retainer(17).
- Tightening the bolts.

Torque: 20 N·m (15 lb ft)



226RS130

- 5. Bend the lock tabs on the retainer, using a punch and hammer.
- 6. Install the mainshaft assembly(16) into the case.
- 7. Install the mainshaft rear bearing outer race(15) into the rear of the case.
- 8. Install 4th speed blocking ring(14) onto the front of the mainshaft.


Install the mainshaft thrust race(14), bearing(14), and spacer(14) onto the front of the mainshaft.

Apply petroleum jelly to the mainshaft pilot bearing rollers(14) (there are 15 rollers) and install them into the input shaft.


7B-78 MANUAL TRANSMISSION

9. Install the input shaft(13) onto the front of the mainshaft.
10. Install the input bearing retainer(12) and bearing outer race(12) without shim onto the front of the case. Tighten the four bolts, using a 13 mm socket and a torque wrench.

Torque: 20 N·m (15 lb ft)




11. Install the 5th speed drive gear(10) and 5th synchronizer blocking ring(10) on the rear of the counter shaft.
12. Install the 5-R lever with reverse fork(9) and spring(9) into the case.



13. Assemble the 5th synchronizer and rail/fork and install them as follows:

- Guide the rail(8) through the reverse fork(9) and into the front of the case.



- Push the 5th synchronizer assembly(8) onto the splines of the counter shaft together with 5th shift fork and rail(8).
- Install the reverse blocking ring, reverse cone(8), splined washer(8) and 5th synchronizer snap ring(8).
- Align the slot of the 5-R shift lever with the roller of the 5th shift rail.

14. Install oiling funnel(4).


15. Coat the threads of the 5-R lever pivot bolt(7) with sealer and install it(7) into the case. Make sure that the 5-R lever is properly aligned with the pivot bolt. Tighten the pivot bolt, using T-50 bit and a torque wrench.

Torque: 27 N·m (20 lb ft)

16. Install the 5-R lever clip(6) using a pair of needle-nose pliers.

Use a pair of needle nose pliers to attach the reverse fork spring to its pin inside the case.


Check the operation of the 5-R shift mechanism at this time.



230RS024

17. Install the 5th driven gear snap ring(11), using snap ring pliers.

Install the clip(11) and speedometer drive gear(11) onto the rear of the mainshaft, using installer J-6133-01 and a hammer. Be sure the speedometer gear retaining clip is fully seated.




226RS132

18. Install the slip yoke snap ring(11) onto the end of the mainshaft, using a pair of snap ring pliers.

19. Apply a 3 mm (1/8 in) bead of RTV sealant on the sealing surface of the shift cover.

Make sure that the 1-2 and 3-4 synchronizer sleeves are in Neutral position, as well as the 5-R shift lever.

Lower the cover onto the case, allowing the 1-2 and 3-4 forks to slide onto their sleeves. Slide the shift cover assembly(5) toward the 5-R lever side just before the cover contacts the case.




230RS025

Install the ten cover-to-case bolts, beginning with the two alignment-type bolts, using a 10 mm socket and a torque wrench.

Torque: 14 N·m (10 lb ft)


20. Must align reverse cone with the tab(8) in the "Up" (12 o'clock) position.




226RS133

7B-80 MANUAL TRANSMISSION

21. Apply a 3 mm (1/8 in) bead of RTV sealant to the sealing surface of the extension housing. Lubricate the detent/guide plate in the extension housing with lithium grease. Install the detent ball(3) in the "3-4" position of the detent pattern of the plate. Place the offset lever(3) with detent spring(3) in the extension housing detent/guide plate area and push the extension housing(2) against the case and shift cover(5).



Guide the offset lever(3) onto the shift shaft as you push the extension housing(2). You will have to compress the detent spring(3) against its ball(3) to fit the parts easily.




Apply sealer to the threads of the top two extension housing-to-case bolts and install them. Install the other six bolts as well. Tighten the bolts, using a 15 mm socket and a torque wrench.

Torque: 30 N·m (23 lb ft)

Apply sealer to the threads of the back-up lamp switch and the drain plug and install them, using suitable wrenches.

22. Install the offset lever-to-shift shaft roll pin(1), using a hammer.
23. Turn the transmission case on end, and mount a dial indicator on the extension housing. Set up the indicator to measure input/mainshaft end play. Move the input/mainshaft up and down and read the total amount of indicator travel.




- Select a shim which is the same thickness as the indicator reading (± 0.001 inch).

This will give an end play of zero.

Input/Main Shaft		Selective Shims	
Thickness		Thickness	
mm	(inches)	mm	(inches)
0.30	(0.012)	0.79	(0.031)
0.36	(0.014)	0.81	(0.032)
0.41	(0.016)	0.84	(0.033)
0.46	(0.018)	0.86	(0.034)
0.51	(0.020)	0.89	(0.035)
0.56	(0.022)	0.91	(0.036)
0.58	(0.023)	0.94	(0.037)
0.61	(0.024)	0.97	(0.038)
0.64	(0.025)	0.99	(0.039)
0.66	(0.026)	1.02	(0.040)
0.69	(0.027)	1.04	(0.041)
0.71	(0.028)	1.07	(0.042)
0.74	(0.029)	1.09	(0.043)
0.76	(0.030)	1.12	(0.044)

- Remove the input bearing retainer.
- Install the selected shim(s) (12) behind the input bearing outer race(12) in the retainer.
If two shims are used, put the thinner one in first.



- Install the input shaft bearing retainer(12) against the case.

Torque: 20 N·m (15 lb ft)


- Recheck the input/mainshaft end play.
Change the shim again if end play is not zero (± 0.001 inch).
- Apply a 1/8-inch(3 mm) bead of RTV sealant on the sealing surface of the retainer.
- Apply sealer to the threads of the four retainer bolts.
- Install the input shaft bearing retainer(12) against the case.

Torque: 20 N·m (15 lb ft)

- 24. Install the speedometer driven gear assembly.
- 25. Remove the transmission from the holding fixture.
- 26. Loosen the fill plug and fill with DEXRON®-III Automatic Transmission Fluid.


- 27. Install the clutch housing to the case.

Torque: 76 N·m (56 lb ft)




- 28. Install the clutch release bearing and shift fork.

- 29. Clean the sealing surface of the shift control lever and inspect it for warpage.



Mainshaft (TREMEC T5R)

Disassembled View



226RS136


Legend

- | | |
|--|--|
| (1) 3rd-4th Synchronizer Assembly (Spring, Sleeve, Insert, & Hub), Blocking Ring, and 3rd Gear | (8) Spring, Reverse Sliding Gear, Insert |
| (2) 3rd Gear Needle Bearing and Spacer | (9) 5th Driven Gear and Snap Ring |
| (3) Snap Ring | (10) Mainshaft Rear Bearing |
| (4) Thrust Washer | (11) 1st Gear |
| (5) 2nd Gear, Bearing and Spacer | (12) 1st Gear Bearing and Sleeve |
| (6) Spiral Retaining Ring | (13) 1st Blocking Ring Assembly (Inner Cone, Outer Cone Race, 1st Blocking Ring) |
| (7) Thrust Washer and 2nd Blocking Ring Assembly (Inner Cone, Outer Cone Race & 2nd Blocking Ring) | (14) Mainshaft (with 1-2 Hub) |

Disassembly


1. 3rd-4th synchronizer assembly, blocking ring and 3rd gear.

- Scribe an alignment mark on both the 3-4 synchronizer hub and sleeve. Use these marks for correct reassembly.
- Using a hydraulic press and the bearing and gear puller plate J-22912-01, remove the 3-4 synchronizer assembly(1), block ring(1) and the 3rd gear(1).




226RS137

2. Remove needle bearing(2) and spacer(2).



226RW149


3. Second gear snap ring(3), using a pair of snap ring pliers.



226RW150


4. Remove thrust washer(4).

5. Remove 2nd gear(5), bearing(5) and spacer(5).



226RS140


6. Remove spiral retaining ring, using a pocket screwdriver.



226RS141

7B-84 MANUAL TRANSMISSION

7. Remove thrust washer(7) and 2nd blocking ring assembly(7) (inner cone, outer cone race & 2nd blocking ring).



226RS142

8. Scribe an alignment mark on both the shaft and hub(14) and reverse sliding gear(8). Use these marks for correct reassembly.


Remove the reverse sliding gear(8) from shaft and along with these parts:

The three keys

One of the two springs.

NOTE: Do not attempt to remove the 1-2 synchronizer hub from the mainshaft.


The hub and shaft are permanently assembled and machined as a matched set.



226RS143


9. Remove the 5th driven gear snap ring(9) from the rear of mainshaft, using a pair of snap ring pliers.

Using a hydraulic press and the bearing and gear puller plate J-22912-01, remove the fifth driven gear(9) from the mainshaft.




226RS144

10. Remove the mainshaft rear bearing(10) from the shaft.




226RS145


11. Remove 1st gear(11).



12. Remove 1st gear bearing(12) and sleeve(12).




13. Remove the three-piece first blocking ring assembly(13). Also remove the remaining synchronizer spring from mainshaft (with 1-2 hub) (14).



Reassembly


1. Assemble the three synchronizers. Make sure that the hubs and sleeves are matched and that the inserts are installed properly. Attach the hooked ends of the springs to the same inserts and install them in opposite directions. Also align blocking rings with inserts during installation steps.

NOTE: Soak the paper-lined blocking rings in DEXRON®-III before installing them.




7B-86 MANUAL TRANSMISSION


2. Install the three-piece blocking ring assembly(13) for 1st speed.
3. Install 1st bearing sleeve(12) and bearing(12).
4. Install 1st gear(11).
Make sure blocking rings align with inserts.
5. Install mainshaft rear bearing(10).




6. Using a hydraulic press and the installer J-25234, install the 5th driven gear(9) on the mainshaft. Support the mainshaft with the mainshaft support J-5590.
- While the mainshaft is still on the press bed, install the snap ring(9) for the fifth driven gear. If it does not fit, continue pressing the 5th driven gear until it is fully seated.



7. Install the three-piece 2nd blocking ring assembly(7) for 2nd speed.
Install the thrust washer(7) for the blocking ring inner cone.
8. Install spiral retaining ring(6) by using spiral snap ring installer J-37360.




9. Install 2nd speed gear spacer(5), bearing(5) and 2nd gear(5).
10. Install thrust washer(4) and snap ring(3).
11. Install 3rd gear spacer(2) and needle bearing(2).
12. Install the 3rd gear(1) and the 3rd speed blocking ring(1).
13. Install the 3-4 synchronizer assembly(1). Use a hydraulic press and synchronizer & gear installer J-37372 to press the hub onto the mainshaft. Be sure to align the blocking ring with the synchronizer inserts while installing the hub.



Input Shaft (TREMEC T5R)

Disassembled View



226RS154

Legend

- (1) Bearing
- (2) Input Shaft
- (3) Needle Bearing (15 rollers)


- (4) Spacer
- (5) Thrust Needle Bearing
- (6) Thrust Race

Disassembly


If you have not done so previously, remove these parts from the input shaft:

- Mainshaft thrust race (6), thrust needle bearing(5) and spacer(4)
- Mainshaft needle bearing rollers(3) (there are 15 rollers)

1. Using a hydraulic press and bearing and gear puller J-22912-01, remove the input shaft bearing(1) from input shaft(2).




226RS155



226RS156

Reassembly


1. Use a hydraulic press, installer J-6133-1 and bearing and gear puller J-22912-01 to install the input shaft bearing(1) onto the input shaft(1).



2. Using petroleum jelly, install the 15 rollers(3) and spacer(4) into the rear of the input shaft(2). Also install the mainshaft thrust bearing(5) and its race(6) in the rear of the input shaft(2).

Input Bearing Retainer (TREMEC T5R)

Disassembled View




Legend

- (1) Input Bearing Retainer
- (2) Input Shaft Seal
- (3) Shim
- (4) Bearing Outer Race


Disassembly

If you have not done so previously, remove these parts from the input bearing retainer(1):

- Bearing outer race(4)
- Shim(s) (3)




1. Remove the input shaft seal(2), using Input seal remover J-29369-2 and slide hammer J-23907.




Reassembly

1. Install the input shaft seal(2) in the retainer(1), using the installer J-37375 and a soft-faced hammer.
2. Install the input bearing outer race(4) in the retainer(1) without the shim(3) behind it.



Counter Shaft (TREMEC T5R)

Disassembled View



226RS162

Legend

(1) Counter Shaft Front Bearing Outer Race and O-ring


(2) Counter Shaft Front Bearing

(3) Counter Shaft


Disassembly

1. Using a hydraulic press and bearing race receiver and case support J-37358, remove the counter shaft front bearing outer race(1). Remove the O-ring(1).

2. Remove the counter shaft front bearing(2) from the counter shaft(3). Use a hydraulic press, counter shaft front bearing remover J-37359 and bearing and gear puller J-22912-01.




226RS163




226RS164

Reassembly


1. Install the counter shaft front bearing(2) onto the counter shaft(3), using a hydraulic press, installer J-37357 and bearing and gear puller J-22912-01.



2. Install a new O-ring(1) on the counter shaft outer race(1) and lubricate it.




3. Using installer and driver handle, lightly tap the outer race(1) into its bore until the O-ring is compressed.
4. Using a hydraulic press, installer J-37357 and driver handle J-8092, install the outer race(1) until its shoulder rests on the inside of the case.



Extension Housing (TREMEC T5R)

Disassembled View




Z26RW148

Legend

- (1) Vent
- (2) Slip Yoke Seal
- (3) Slip Yoke Bushing
- (4) Extension Housing


Disassembly

1. Remove the vent(1) from the extension housing(4).




Z20RW054

2. Remove the slip yoke seal(2) from the rear of the extension housing(4), using remover J-26941 and slide hammer J-23907.



Z20RW056


3. Remove the slip yoke bushing(3) from the rear of the extension housing(4), using remover J-23062-14 and driver handle J-8092.




Z20RW055

Reassembly

1. Install the slip yoke bushing(3) into the rear of the extension housing(4), using installer J-23062-14 (with J-8092 driver handle) and a hammer.




2. Install the slip yoke seal(2) into the rear of the extension housing(4), using installer J-38763 and a soft-faced hammer.



3. Install the vent(1) into the extension housing.

Shift Cover (TREMEC T5R)

Disassembled View




230RW008

Legend

- | | |
|-------------------------------------|-------------------------------------|
| (1) Selector Arm Roll Pin | (6) Interlock Plate |
| (2) Shift Shaft | (7) 1-2 Shift Fork and Fork Pads(2) |
| (3) 3-4 Shift Fork and Fork Pads(2) | (8) Shift Shaft Bore Plug |
| (4) Selector Plate(2) | (9) O-ring Seal |
| (5) Selector Arm | (10) Shift Cover |


Disassembly

1. Remove the selector arm roll pin(1), using a 3/16-inch diameter pin punch and hammer.



230RS028

2. Remove the shift shaft(2) from the other parts. Note the correct position of both the interlock plate(6) and selector arm(5) before you remove them from the cover(10).




3. Remove 3-4 shift fork and fork pads two(3).
4. Remove selector plate two(4), selector arm(5), and interlock plate(6).
5. Remove 1-2 shift fork and fork pads two(7).
6. Remove shift shaft bore plug(8) and O-ring seal(9) from shift cover(10).


Reassembly

1. If the shift shaft bore plug(8) was removed, coat plug outer surface with sealer and install the plug(8) into the cover (10) until it is flush.
2. Install the fork pads(7) and selector plate(4) onto the 1-2 shift fork(7).

3. Push the shift shaft(2) into the cover(10) until front of the shaft is at the cover's rear inside edge.




4. Place the 1-2 shift fork(7) into the cover(10) with its selector plate(4) facing the front of the cover.




7B-96 MANUAL TRANSMISSION

5. Push the shift shaft through the 1-2 shift fork.




230RS032

6. Place the selector arm(5) and interlock plate(6) in the cover(10). Note the position of the interlock plate(6) and selector arm(5).



230RS033


7. Push the shift shaft through the selector arm(5).



230RS034


8. Install the fork pads(3) and selector plate(4) onto the 3-4 shift fork(3).

9. Place the 3-4 shift fork(3) in the cover(10) with its selector plate(4) facing the rear of the cover. Note the position of the 3-4 and 1-2 selector plates(4).




230RS035

10. Push the shift shaft(2) through the 3-4 shift fork(3) and into the front of the cover(10).




230RS036

11. Install the roll pin(1) that holds the selector arm(5) to the shift shaft(2).



230RS038


12. Lubricate and install the O-ring(9) on the rear of the shift cover(10).



230RS038

Check the shift cover parts for proper assembly by doing the following:


- Insert a 3/16-inch diameter pin punch into the offset lever hole of the shift shaft(2).
- Hold the shift cover(10) parallel to the floor and rotate the shift shaft(2) so that the punch is vertical.



230RS039


7B-98 MANUAL TRANSMISSION

- Look at the selector arm: it should be aligned with the 3-4 shift fork select plate.




Pre-Installation Checks (TREMEC T5R)

1. Separate the clutch release fork from its ball stud and remove the ball stud from the clutch housing.




2. Inspect these parts:

- Ball stud
- Fork
- Release bearing
- Fingers of the pressure plate spring.




Replace any parts which have excessive wear.

3. Check the alignment of the clutch housing to the engine in these steps:
 - Place the magnetic base for a dial indicator on the pressure plate spring fingers.
 - Make sure the base is secure.




- Check the housing bore alignment by:
 - Mounting the dial indicator against the bore



201RS032

- Rotating the engine one revolution while recording total dial indicator needle travel
- Check the housing face alignment by:
 - Mounting the dial indicator against the housing face




201RS033

- Rotating the engine one revolution while recording total dial indicator needle travel
- If either reading is greater than 0.254 mm (0.010 inch), place special shims between the engine and clutch housing to correct the misalignment.

4. Check the condition of these clutch system parts if you suspect excessive wear:

- Pressure plate assembly
- Driven disc (especially the torsional damping springs)
- Flywheel
- Input shaft pilot bearing.



015RS076

Replace any parts which have excessive wear.

5. Reassemble the clutch system parts. Be sure to lubricate the clutch release bearing bore and fork groove and also the head of the fork pivot.

Main Data and Specifications

General Specifications


(MUA)

		4X2	4X4
Transmission type		Fully synchronized forward and reverse gears	
Transfer case		—	Synchronized type gears shifting between the 2- and 4-wheel drive mode. Constant mesh type gears between "low" and "high"
Control method		Remote control with the gear shift lever on the floor.	
Gear ratio: Transmission	1st	3.767	
	2nd	2.248	
	3rd	1.404	
	4th	1.000	
	5th	0.809	
	Rev.	3.873	
Gear ratio: Transfer	High	—	1.000
	Low	—	2.050
Transmission oil capacity		2.95 lit. (3.12 US qt)	
Transfer oil capacity		—	1.45 lit. (1.53 US qt)
Type of lubricant		Engine oil: Refer to the chart in "SECTION 0"	

(TREMEC T5R)

Transmission type		Fully synchronized 5-forward gears with sliding selective type reverse gear.
Control method		Remote control with the gear shift level on the floor.
Gear ratio:	1st	3.76
	2nd	2.18
	3rd	1.42
	4th	1.00
	5th	0.81
	Rev.	3.76
Speedometer gear ratio		7/22
Oil capacity		2.13 lit. (2.3 US qt)
Type of lubricant		DEXRON®-III Automatic Transmission Fluid


Torque Specifications



E07RW015


About arrow mark, refer to Transmission(MUA) Installation in this section.

Torque Specifications (Cont'd)



E07RW017

Torque Specifications (Cont'd)




E07RW019



Downloaded from www.Manualslib.com manuals search engine

Torque Specifications (Cont'd)



E07RW016

Special Tools (MUA)







ILLUSTRATION	TOOL NO. TOOL NAME
 901RW143	J-37222 Mainshaft collar remover
 901RW132	J-37487 Puller
 901RW124	J-37224 Holding fixture
 901RS213	J-3289-20 Holding fixture base
 901RW122	J-37219 Wrench
 901RW125	J-37225 Tork bit wrench (T-45)











ILLUSTRATION	TOOL NO. TOOL NAME
 901RW123	J-37223 Mainshaft end bearing installer
 901RS239	J-22912-01 Bearing remover/installer
 901RW142	J-29769 Rear cover oil seal installer
 901RW116	J-26540 Front cover oil seal installer
 901RW137	J-6133-01 Mainshaft collar installer
 901RW135	J-39207 Remover; Clutch release bearing

ILLUSTRATION	TOOL NO. TOOL NAME
 <small>901HW0/1</small>	J-8614-11 Flange holder
 <small>901RS226</small>	J-39209 Punch; end nut
 <small>901RW120</small>	J-35283 Counter shaft bearing installer
 <small>901RW143</small>	J-37217 Bearing remover

Special Tools (TREMEC T5R)













ILLUSTRATION	TOOL NO. TOOL NAME	ILLUSTRATION	TOOL NO. TOOL NAME
 901RW121	J-36842 Holding fixture; Transmission	 901RW126	J-37357 Installer; Counter shaft bearing
 901RS213	J-3289-20 Base; Holding fixture	 901RW117	J-25234 Installer; 5th driven gear
 901RW136	J-8433 Gear puller	 901RW136	J-5590 Mainshaft support
 901RW134	J-38878 Puller; Speed drive gear	 901RW129	J-37360 Spiral snap ring installer
 901RS239	J-22912-01 Puller plate	 901RW130	J-37372 Synchronizer & gear installer
 901RW137	J-6133-01 Installer; Bearing & gear	 901RW119	J-29369-2 Remover; Input seal & slip yoke seal









ILLUSTRATION	TOOL NO. TOOL NAME
 901RT099	J-23907 Slide hammer
 901RW131	J-37375 Installer; Input bearing retainer seal
 901RW127	J-37358 Bearing race receiver & case support
 901RW126	J-37359 Counter shaft front bearing remover
 901RS234	J-26941 Remover; extension housing oil seal
 901RW067	J-8092 Driver handle

ILLUSTRATION	TOOL NO. TOOL NAME
 901RW116	J-23062-14 Remover & installer; extension housing bushing
 901RW133	J-38763 Installer; extension housing oil seal

TRANSMISSION

CLUTCH

CONTENTS

Service Precaution	7C-1	Inspection and Repair	7C-20
General Description	7C-2	Installation	7C-24
Diagnosis	7C-8	Clutch Control	7C-26
Clutch Assembly (X22SE, TREMEC T5R / MUA)	7C-9	Parts Location View	7C-26
Clutch Assembly (X22SE, TREMEC T5R) and Associated Parts	7C-9	Removal	7C-27
Clutch Assembly (X22SE, MUA) and Associated Parts	7C-10	Inspection and Repair	7C-27
Removal	7C-10	Installation	7C-28
Inspection and Repair	7C-11	Master Cylinder	7C-30
Installation	7C-15	Slave Cylinder	7C-31
Clutch Assembly (6VD1, MUA)	7C-18	Disassembled View	7C-31
Clutch Assembly (6VD1, MUA) and Associated Parts	7C-18	Disassembly	7C-31
Removal	7C-18	Inspection and Repair	7C-31
		Reassembly	7C-32
		Main Data and Specifications	7C-33
		Special Tools	7C-36

Service Precaution


WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.


General Description

Clutch


X22SE, TREMEC T5R



X22SE, MUA



6VD1, MUA



The clutch assembly consists of the pressure plate assembly and the driven plate assembly.


The clutch pedal is connected to the release bearing through the shift fork.

The driven plate assembly is installed between the flywheel and the pressure plate. Diaphragm spring pressure holds the driven plate against the flywheel and the pressure plate to provide the friction necessary to engage the clutch.

Depressing the clutch pedal moves the shift fork against the release bearing. The release bearing force overcomes the force of the diaphragm spring and separates the driven plate from the flywheel and pressure plate to disengage the clutch.

For 6VD1 (3.2L) engine model, the pull-type clutch is employed.

Master Cylinder



A07RW007


The master cylinder converts mechanical energy into hydraulic energy. Depressing the clutch pedal causes the push rod to move against the piston to close the return port.

Clutch fluid is forced out of the master cylinder. Releasing the clutch pedal causes the return spring to force the piston back to its original position.

7C-4 CLUTCH


Slave Cylinder

X22SE, TREMEC T5R




A07RW029

X22SE, MUA



A07RW028

6VD1, MUA



A07RW037


The slave cylinder converts hydraulic energy into mechanical energy. Hydraulic fluid supplied by the master cylinder moves the slave cylinder piston to

actuate the shift fork. The mechanical energy produced by the slave cylinder is directly proportional to the diameters of the master cylinder and the slave cylinder.

7C-6 CLUTCH


Pressure Plate Assembly

X22SE, TREMEC T5R/MUA



A07RW024


6VD1, MUA




A07RW025

The pressure plate assembly consists of the clutch cover, the pressure plate with diaphragm spring.

Operating the clutch pedal causes the pressure plate to move in an axial direction to engage and disengage the clutch.

Driven Plate Assembly**X22SE, TREMEC T5R/MUA**

A07RW026

6VD1, MUA

A07RW027

The driven plate assembly consists of the plate and the facing.

The plate consists of the clutch center, the cushioning plate, and the torsion springs.


The facing is riveted to both sides of the cushioning plate. The cushioning plate provides a longer service life by minimizing wear and vibration at the clutch contact surfaces.

Diagnosis

Condition	Possible cause	Correction
Dragging	Air in circuit.	Bleed and check for damage.
	Driven plate worn or warped.	Replace.
	Clutch fork off the ball stud.	Install correctly and lubricate.
	Diaphragm spring weak or tip of fingers worn.	Replace.
	Driven plate sticking on splines.	Clean and free splines and lubricate with grease.
	Pilot bearing worn or damaged.	Replace.
	Master cylinder and slave cylinder seals worn.	Replace.
Slipping	Clutch facing worn.	Replace.
	Driven plate friction pads worn or oilsoaked.	Replace and check for leaks as needed.
	Diaphragm spring weak.	Replace pressure plate.
	Pressure plate or flywheel warped.	Replace.
	Master cylinder and slave cylinder seals worn.	Replace as needed.
Chattering	Clutch facing in poor contact or facing warped.	Replace.
	Surface of facing hardened.	Replace.
	Driven plate friction pads oil soaked.	Replace and check for leaks.
	Damper springs weakened or broken.	Replace.
	Rivets on clutch plate loosened.	Replace.
	Pressure plate or flywheel warped.	Replace as needed.
Rattling	Diaphragm spring weak.	Replace the pressure plate.
	Clutch fork loose or off the ball stud.	Replace the retaining spring or install the fork correctly.
	Driven plate springs weak or oil in the damper.	Replace and check for leaks as needed.
Release bearing noisy with the clutch engaged	Release bearing binding.	Clean, or replace if damaged, and lubricate.
	Clutch fork off the ball stud or loose spring tension.	Install correctly, and lubricate.
	Linkage return springs weak.	Replace.
Noisy	Release bearing worn or damaged.	Replace.
	Clutch fork off the ball stud.	Install correctly and lubricate.
	Pilot bearing loose.	Replace.
Pedal stays on the floor when disengaged	Release bearing binding.	Free up, or replace, and lubricate.
	Diaphragm spring weak.	Replace the pressure plate.
Pedal is hard to push	Hydraulic line blocked or crimped.	Clean out or replace.
	Master or slave cylinders binding.	Repair or replace as needed.
	Driven plate worn.	Replace.
Squeaking	Ball stud not lubricated or incorrectly lubricated.	Lubricate with high temperature grease.

Clutch Assembly (X22SE, TREMEC T5R / MUA)

Clutch Assembly (X22SE, TREMEC T5R) and Associated Parts




201RX001

Legend

- (1) Transmission Assembly
- (2) Pressure Plate Assembly
- (3) Driven Plate Assembly

- (4) Release Bearing
- (5) Shift Fork
- (6) Crank Shaft Bearing

Clutch Assembly (X22SE, MUA) and Associated Parts



Legend


- (1) Transmission Assembly
- (2) Pressure Plate Assembly
- (3) Driven Plate Assembly

- (4) Release Bearing
- (5) Shift Fork
- (6) Crank Shaft Bearing

Removal

1. Remove transmission assembly, refer to "MANUAL TRANSMISSION" of Section 7B for "REMOVAL AND INSTALLATION" procedure.

2. Use the clutch pilot aligner (7) J-33169 (TREMEC) / J-42877 (MUA) to prevent the driven plate assembly from falling free.




201RX002

Legend

- (3) Driven Plate Assembly
- (2) Pressure Plate Assembly
- (7) Pilot Aligner

3. Mark the flywheel, clutch cover and pressure plate (2) lug for alignment when installing.
4. Loosen the clutch cover bolts in the numerical order shown in the illustration.



201RS036


5. Remove pressure plate assembly (2) and driven plate assembly (3).
6. Remove release bearing (4).

NOTE: The release bearing is permanently packed with lubricant and should not be soaked in cleaning solvent, as this will dissolve the lubricant.

7. Remove shift fork.

○ Do not remove crank shaft bearing (6) except for replacement.

Remove the crank shaft bearing (6) using remover J-5822 and sliding hammer J-23907.



015RS077

Inspection and Repair

Make necessary adjustments, repairs, and part replacements if wear, damage, or other problems are discovered during inspection.


Pressure Plate Assembly

Visually inspect the pressure plate friction surface for excessive wear and heat cracks. If excessive wear or deep heat cracks are present, the pressure plate must be replaced.

7C-12 CLUTCH

Pressure Plate Warpage

Use a straight edge and a feeler gauge to measure the pressure plate friction surface flatness in four directions.



201RS038


If any of the measured values exceed the specified limit, the pressure plate must be replaced.

Pressure Plate Warpage

Limit: 0.3mm (0.012in)

Clutch Cover

Visually inspect the entire clutch cover for excessive wear, cracking, and other damage. The clutch cover must be replaced if any of these conditions are present.




201RS039

Clutch Set Force

1. Invert the pressure plate assembly.
2. Place a new driven plate over the pressure plate. A metal sheet with thickness of 8.0mm (0.315in) may be used in place of the driven plate.
3. Compress the pressure plate assembly until the distance becomes 4mm (0.157in).
4. Note the pressure gauge reading.

Clutch Set Force

Standard: 5488N (1235lb)




201RW015

Diaphragm Spring Finger Height

1. Place a 8.0mm (0.315in) spacer beneath the pressure plate.
2. Fully compress the pressure plate and diaphragm spring.
There are two ways to do this:
 - a. Use a bench press to press down on the assembly from the top.
 - b. Tighten the fixing bolts.
3. Measure the spring finger height from base to spring tip.
If the measured value exceeds the specified limit, the pressure plate assembly must be replaced.

Spring Finger Height


Standard: 37.5 mm – 39.5 mm (1.48 in – 1.56 in)




Shift Fork

1. Visually inspect the surfaces of the shift fork making contact with the shift block.
2. Remove any minor stepping or abrasion from the shift block with an oil stone.
3. Apply molybdenum disulfide type grease to the areas as shown in the figure.

MUA




TREMEC T5R



Driven Plate Assembly


1. Visually inspect the torsion spring for looseness, breakage, and weakening. If any of these conditions are discovered, the driven plate assembly must be replaced.
2. Visually inspect the facing surfaces for cracking and excessive scorching. Visually inspect the facing surfaces for the presence of oil or grease. If any of these conditions are discovered, the facing must be cleaned or replaced.



3. Check that the driven plate moves smoothly on the transmission top gear shaft spline. Minor ridges on the top gear shaft spline may be removed with an oil stone.

Driven Plate Warpage

1. Insert the clutch pilot aligner J-33169 (TREMEC) / J-42877 (MUA) into the driven plate splined hub. The clutch pilot aligner must be held perfectly horizontal.
2. Set a dial indicator to the driven plate outside circumference.



3. Slowly turn the driven plate. Read the dial indicator as you turn the driven plate. If the measured value exceeds the specified limit, the driven plate assembly must be replaced.

Driven Plate Warpage

Standard: 0.7 mm (0.028 in)

Limit: 1.0 mm (0.039 in)


Driven Plate Splined Hub Spline Wear

1. Clean the driven plate splined hub.
2. Install the driven plate to the transmission top gear shaft spline.
3. Set a surface gauge to the driven plate outside circumference.
4. Slowly turn the driven plate counterclockwise. Measure the spline rotation play as you turn the driven plate.

Driven Plate Splined Hub Spline Wear

Standard: 0.5 mm (0.020 in)

Limit: 1.0 mm (0.039 in)



201RS009

Rivet Head Depression


Use a depth gauge or a straight edge with steel rule to measure the rivet head depression (1) from the facing surface (2).

Be sure to measure the rivet head depression on both sides of the driven plate. If the measured value is less than the specified limit, the facing must be replaced.

Rivet Head Depression

Standard: MIN 1.3 mm (0.051 in)


Limit: 0.2 mm (0.008 in)



201RS010

Pressure Plate Assembly

Check the cover for cracks and distortion, and the diaphragm spring for heat distortion, loosened rivets. Check the diaphragm spring for wear.




201RS047

Installation

1. Clean and lubricate with grease.
2. Use installer J-1522 to install crankshaft bearing (6).

X22SE




015RS078


7C-16 CLUTCH

3. Apply molybdenum disulfide type grease to the areas as shown in the figure and install shift fork (5).


MUA




TREMEC T5R



4. Pack the inside recess (A) and coat the outside groove (B) of the release bearing with grease as shown in the figure.




5. Install driven plate assembly by using aligner J-33169 (TREMEC) / J-42877 (MUA).



6. Tighten the bolts holding the pressure plate assembly (2) in the order shown in the figure.

Torque: 18N·m (13 lb ft)



201RS050


7. Remove the aligner.

NOTE: Do not strike the aligner with a hammer to remove it.

8. Install transmission assembly (1) to the engine. Refer to Transmission Installation in Manual Transmission section.

Shift Fork Lubrication

TREMEC T5R



201RW013


Legend

- (1) Clutch Housing
- (2) Shift Fork
- (3) Ball Stud
- (4) Plug

1. Remove the plug from the clutch housing.
2. Lubricate the shift fork through a lubrication hole of ball stud with grease using a grease gun.
3. Install the plug to the clutch housing.

Clutch Assembly (6VD1, MUA)

Clutch Assembly (6VD1, MUA) and Associated Parts



201RS023


Legend

- | | |
|-----------------------------|--|
| (1) Transmission Assembly | (4) Release Bearing |
| (2) Pressure Plate Assembly | (5) Shift Fork |
| (3) Driven Plate Assembly | (6) Fulcrum Bridge |
| | (7) Flywheel Assembly and Crankshaft Bearing |

Removal

1. Refer to "MANUAL TRANSMISSION" of Section 7B for "REMOVAL AND INSTALLATION" procedure of transmission assembly (1).

2. Use the pilot aligner J24547 to prevent the driven plate assembly (3) from falling free.




201RS001

Legend

- (2) Pressure Plate Assembly
- (3) Driven Plate Assembly
- (8) Pilot Aligner


3. Mark the flywheel, clutch cover and pressure plate lug for alignment when installing.

4. Remove the release bearing (4) from the transmission case.




201RS024

5. Remove the snap pin. Remove the shift fork pin and shift fork from the fulcrum bridge.



201RS025


6. Remove the fulcrum bridge bolts. Remove the fulcrum bridge (6) from the transmission case.



201RS026

7C-20 CLUTCH

- Do not remove crankshaft bearing (7) except for replacement.
- Use the remover J-5822 and sliding hammer J-23907 to remove the crankshaft bearing.




Inspection and Repair

Make necessary correction or parts replacement if wear, damage, or any other abnormal condition are found through inspection.

Pressure Plate Assembly

- Visually check the pressure plate friction surface for excessive wear and heat cracks. If excessive wear or deep heat cracks are present, the pressure plate must be replaced.




Pressure Plate Warpage

- Use a straight edge and a feeler gauge to measure the pressure plate friction surface flatness in four directions. If any of the measured values exceed the specified limit, the pressure plate must be replaced.


Pressure Plate Warpage

Limit: 0.3 mm (0.012 in)



Clutch Cover

- Visually check the entire clutch cover for excessive wear, cracking, and other damage. The clutch cover must be replaced if any of these conditions are present.




Clutch Set Force

1. Invert the pressure plate assembly.
2. Place a new driven plate over the pressure plate. A metal sheet with thickness of 8.0mm (0.315in) may be used in place of the driven plate.
3. Compress the pressure plate assembly until the distance becomes 12mm (0.472in).
4. Note the pressure gauge reading. If the measured value is less than the specified limit, the pressure plate assembly must be replaced.

Clutch Set Force

Standard: 7208N (1621lb)

Limit: 6669N (1499lb)



Diaphragm Spring Finger Height

1. Place a new driven plate or a 8.0mm (0.315in) spacer beneath the pressure plate.
2. Fully compress the pressure plate and diaphragm spring.

There are two ways to do this:


 - a. Use a bench press to press down on the assembly from the top.
 - b. Tighten the fixing bolts.

NOTE: Preload on diaphragm spring finger must be 4998N (11-22lb) in direction of release, when clutch cover assembly is bolted to the flywheel.

3. Measure the spring height from base to spring tip. If the measured value exceeds the specified limit, the pressure plate assembly must be replaced.


Spring Finger Height

Standard: 49.9 – 51.9 mm (1.965– 2.043 in)



Driven Plate Assembly

- Visually check the torsion spring for looseness, breakage, and weakening. If any of these conditions are discovered, the driven plate assembly must be replaced.
- Visually check the facing surfaces for cracking and excessive scorching. Visually inspect the facing surfaces for the presence of oil or grease. If any of these conditions are discovered, the facing must be cleaned or replaced.
- Check that the driven plate moves smoothly on the transmission top gear shaft spline. Minor ridges on the top gear shaft spline may be removed with an oil stone.




Driven Plate Warpage

1. Insert the clutch pilot aligner J-24547 into the driven plate splined hub. The clutch pilot aligner must be held perfectly horizontal.
2. Set a dial indicator to the driven plate outside circumference.
3. Slowly turn the driven plate. Read the dial indicator as you turn the driven plate. If the measured value exceeds the specified limit, the driven plate assembly must be replaced.

Driven Plate Warpage

Standard: 0.7mm (0.028in)

Limit: 1.0mm (0.039in)



201RS008


Driven Plate Splined Hub Spline Wear

1. Clean the driven plate splined hub.
2. Install the driven plate to the transmission top gear shaft spline.
3. Set a surface gauge to the driven plate outside circumference.
4. Slowly turn the driven plate counterclockwise. Measure the spline rotation play as you turn the driven plate. If the measured value exceeds the specified limit, the driven plate assembly must be replaced.

Driven Plate Warpage

Standard: 0.5mm (0.020in)

Limit: 1.0mm (0.039in)




201RS009

Rivet Head Depression

- Use a depth gauge or a straight edge with steel rule to measure the rivet head depression (1) from the facing surface (2).
- Be sure to measure the rivet head depression on both sides of the driven plate. If the measured value is less than the specified limit, the driven plate assembly must be replaced.

Rivet Head Depression


	Standard	Limit
Fly wheel side	1.2–1.8mm (0.047–0.071in)	0.2mm (0.008in)
Pressure plate side	1.6–2.2mm (0.062–0.087in)	



201RS010


Release Bearing

- Visually check the release bearing for excessive play, noise and breakage. If any of these conditions are discovered, the release bearing must be replaced.



201RS011

- When replacing the release bearing (4), replace both the wedge collar (10) and wire ring (11) at the same time.




201RS012

Legend

- (2) Pressure Plate Assembly
- (4) Release Bearing
- (10) Wedge collar
- (11) Wire Ring

Wedge Collar (10)


- Visually check the surfaces of the wedge collar making contact with the release bearing for excessive wear and damage.
- Replace exhibiting excessive wear or damage.



201RS013

Shift Fork


- Visually check the surfaces of the shift fork making contact with the release bearing for excessive wear and damage.
- Remove any minor stepping or abrasion from shift fork with an oil stone. Replace exhibiting excessive wear or damage.



201RS014

Installation


1. Clean and lubricate with grease.
2. Use the installer J-26516-A and driver handle J-8092 to install the crankshaft bearing (7).



015RS046


3. Install the fulcrum bridge (6) to the transmission case. Tighten three fulcrum bridge bolts to the specified torque.

Torque: 38 N-m (28 lb ft)




201RS026

4. Apply molybdenum disulfide type grease to the pin hole inner circumferences and thrust surfaces. Attach the shift fork (5) to the fulcrum bridge (6) and insert the pin from below of the fulcrum bridge. Install the washer and snap pin.



201RS018


5. Apply molybdenum disulfide type grease to the areas shown in the figure.




201RS015

Install the release bearing (4) in the proper direction.


NOTE: Ensure release bearing is properly positioned during installation, as shown in the figure.



6. Use the pilot aligner J-24547 to install the driven plate assembly (3).



7. Tighten the bolts holding the pressure plate assembly (2) in the order shown in the figure.



Torque: 18 N·m (13 lb ft)


8. Remove the aligner.

NOTE: Do not strike the aligner with a hammer to remove it.

9. Install transmission assembly to the engine.

Clutch Control

Parts Location View




205RW004-1

Legend

- | | |
|-------------------------------|------------------------------|
| (1) Pin and Jaw Joint Pin | (4) Slave Cylinder Assembly |
| (2) Pedal Assembly and Switch | (5) Master Cylinder Assembly |
| (3) Oil Line Pipe | (6) Oil Line Hose |

Removal

1. Disconnect the ground battery cable.
2. Remove the instrument panel lower cover (7) and driver knee bolster panel assembly (8).




740RW023

Legend

- (7) Driver Lower Cover
- (8) Driver Knee Bolster Panel


3. Remove pin and jaw joint pin (1).
4. Remove pedal assembly and switch (2).
5. Remove oil line pipe (3).
6. Remove slave cylinder assembly (4).

X22SE MUA (4×4)



205RW001

TREMEC T5R



205RW002

7. Remove master cylinder assembly (5).
8. Remove oil line hose (6).

Inspection and Repair


Make necessary adjustments, repairs, and part replacements if wear, damage or other problems are discovered during inspection.

Installation

Clutch Pedal Adjustment

1. With clutch switch.

1. Disconnect clutch switch connector.
2. Loosen lock nut, then turn switch out until there is a gap between the switch plunger and clutch pedal.




Legend

- (7) Push Rod
- (8) Clutch Switch

2. Loosen clutch master cylinder push rod lock nut. Turn push rod by hand to set clutch pedal height to within specification. Tighten push rod lock nut.


Clutch Pedal Height

178 – 188 mm (7.01 – 7.40 in)



3. With clutch switch.

1. Turn the clutch switch until the switch bolt just touches the clutch pedal arm.
2. Adjust clutch switch by backing it out half a turn, and measure the clearance between the clutch pedal arm and the clutch switch bolt end.



Legend

- (8) Clutch Switch
- (10) Clutch Pedal Arm
- (11) Lock Nut
- (12) Bracket
- (13) Back Out Switch 1/2 Turn

3. Lock the lock nut.

4. Connect clutch switch connector.

Clutch Switch and Clutch Pedal Clearance

0.5 – 1.5 mm (0.020 – 0.059 in)

4. After adjusting the clutch pedal height, push the clutch pedal by hand to ensure the clutch pedal free play is within specification.

Pedal Free Play


5 – 15 mm (0.20 – 0.59 in)

5. Perform clutch pedal engagement height inspection:

1. Operate the parking brake lever and block the wheels.
2. Start the engine, fully step on the clutch pedal slowly and move the shift lever 1st position.
3. With the engine idling, release the clutch pedal slowly and measure its stroke – just prior to its clutching position.

Clutch Pedal Engagement Height (H3)

MIN. 30 mm (1.18 in)



6. If the measured value exceeds the specified limit, check the following points and repair if necessary:


- Hydraulic circuit for fluid leakage or air in circuit.
- Clutch disc warped.
- Diaphragm spring weakened or tip of fingers worn.
- Driven plate sticking on sprines.
- Release bearing worn or damaged.
- Master cylinder and slave cylinder worn.

Torque

- Master cylinder to dash panel
16 N·m (12 lb ft)
- Clutch pedal to dash panel
15 N·m (11 lb ft)
- Master cylinder push rod to yoke
17 N·m (12 lb ft)
- Clutch pipe to master cylinder
16 N·m (12 lb ft)
- Clutch pipe to flex, hose
20 N·m (14 lb ft)
- Slave cylinder to case
43 N·m (32 lb ft)
- Slave cylinder bleeder screw
8 N·m (69 lb in)
- Clutch pipe to slave cylinder
20 N·m (14 lb ft)


Bleeding

1. Check the level of clutch fluid in the reservoir and replenish if necessary.




2. Bleeding the slave cylinder.

1. Remove the rubber cap from the bleeder screw and wipe clean the bleeder screw. Connect a vinyl tube to the bleeder screw and insert the other end of the vinyl tube into a transparent container.
2. Pump the clutch pedal repeatedly and hold it depressed.



3. Loosen the bleeder screw to release clutch fluid with air bubbles into the container, then tighten the bleeder screw immediately.
4. Release the clutch pedal carefully. Repeat the above operation until air bubbles disappear from the clutch fluid being pumped out into the container. During the bleeding operation, keep the clutch fluid reservoir filled to the specified level. Reinstall the rubber cap.

Master Cylinder




208RX001

NOTE: Disassembling and assembling the master cylinder is not approved.

Slave Cylinder

Disassembled View



206RS002

Legend

- (1) Push Rod
- (2) Boot

- (3) Piston and Piston Cup
- (4) Spring
- (5) Cylinder Body

Disassembly


1. Disassemble boot (1), push rod (2), piston and piston cup (3), and spring (4) from cylinder body (5).

Inspection and Repair

Make the necessary adjustments, repairs, and part replacements if excessive wear or damage is discovered during inspection.

Cylinder Body


1. Clean the cylinder body.
2. Check the fluid return port for restrictions and clean it if necessary.



206RS003

Piston and Piston Cup


1. Visually inspect the disassembled piston and piston cup for excessive wear and damage.



206RS004

Replace the inner parts with new parts if necessary.

2. Measure the clearance between slave cylinder wall and piston.



206RS005

If the measured value exceeds the specified limit, the slave cylinder assembly must be replaced.

Standard: 0.07 mm (0.0028 in)


Limit: 0.15 mm (0.0059 in)

Reassembly

To reassemble, follow the disassembly steps in the reverse order, noting the following points:

Piston Assembly

1. Before installing the parts, apply a thin coat of rubber grease.
2. Install cup in groove in piston with the lip turned to the front of cylinder. Use care so as not to scratch the cylinder.



206RS006


Main Data and Specifications

General Specifications

Engine	X22SE	6VD1
Type	Dry single plate type with diaphragm spring	
Size	240 mm (9.45 in)	260 mm (10.24 in)
Pressure plate		
Outside diameter	299 mm (11.77 in)	332 mm (13.07 in)
Clamping force	5488 N (1235 lb)	7208 N (1621 lb)
Spring finger height	37.5 – 39.5 mm (1.476 – 1.555 in)	49.9 – 51.9 mm (1.965 – 2.043 in)
Driven plate		
Outside diameter × inside diameter	240 × 160 mm (9.45 × 6.30 in)	260 × 170 mm (10.24 × 6.70 in)
Thickness		
Clutch disengaged	8.3 mm (0.327 in)	8.6 mm (0.339 in)
Clutch engaged	8.0 mm (0.315 in)	8.0 mm (0.315 in)
Total friction area	251 × 2 cm ² (39 × 2 in ²)	304 × 2 cm ² (47 × 2 in ²)
Clutch control type	Hydraulic	
Clutch pedal free play	5 – 15 mm (0.20 – 0.59 in)	
Clutch pedal stroke	165.5 – 175.5 mm (6.52 – 6.91 in)	
Clutch pedal height	178 – 188 mm (7.01 – 7.40 in)	

Torque Specifications


X22SE, TREMEC T5R



208RX002


7C-34 CLUTCH

X22SE, MUA




E07RX007

6VD1, MUA



E07RW006



205RX001

Special Tools










ILLUSTRATION	PART NO. PART NAME
 901RW150	J-24547 Driven plate aligner (6VD1)
 901RW150	J-33169 Driven plate aligner (X22SE TREMEC)
 901RW150	J-42877 Driven plate aligner (X22SE MUA)
 901RT099	J-5822 and J-23907 Pilot bearing remover and Sliding hammer
 901RS214	J-22888 Bearing puller
 901RW151	J-2241-11 Adapter

ILLUSTRATION	PART NO. PART NAME
 901RW152	J-26516-A Crankshaft pilot bearing installer (6VD1)
 901RS241	J-1522 Crankshaft pilot bearing installer (X22SE)
 901RS241	J-8092 Driver handle

RODEO

BODY AND ACCESSORIES

LIGHTING SYSTEM

CONTENTS

Service Precaution	8A-1	Spotlight Bulb	8A-11
Headlight Bulb	8A-2	Luggage Room Light Bulb	8A-11
Headlight Assembly	8A-2	HVAC Bezel Illumination Light Bulb	8A-12
Headlight Adjustment	8A-3	Shift Lever Illumination Light Bulb (A/T)	8A-12
Fog Light Bulb	8A-3	Vanity Mirror Illumination Light Bulb	8A-13
Fog Light Assembly	8A-4	Starter Switch	8A-13
Fog Light Adjustment	8A-4	Lighting Switch (Combination Switch)	8A-14
Side Marker Light Bulb	8A-4	Dimmer-Passing Switch (Combination Switch)	8A-14
Front Combination Light Assembly	8A-5	Door Switch	8A-15
Taillight Bulb	8A-5	Rear Defogger Switch	8A-15
License Plate Light Bulb (Bumper Type)	8A-6	Key Remind Switch (Starter Switch)	8A-16
License Plate Light Bulb (Tailgate Type)	8A-6	Hazard Warning Light Switch	8A-16
Stoplight Bulb	8A-7	Stoplight Switch	8A-16
High Mounted Stoplight Assembly	8A-7	Backup Light Switch (M/T)	8A-17
High Mounted Stoplight Bulb	8A-8	Turn Signal Light Switch (Combination Switch)	8A-17
Backup Light Bulb	8A-8	Illumination Controller	8A-17
Front Turn Signal Light Bulb	8A-9	Light and Bulb Specifications	8A-18
Rear Turn Signal Light Bulb	8A-9		
Dome Light Bulb	8A-10		
Courtesy Light Bulb	8A-10		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.


CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fasteners joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fasteners. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Headlight Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the headlight bulb (2).
 - Disconnect the connector (3).
 - Release the socket retaining ring (1).

CAUTION: The halogen light bulb produces heat and temperature rises high, therefore, if the glass surface is contaminated it will be burnt by heat leaving stains which will not come out. This may reduce the illuminating power or damage the bulb due to thermal deformation during evaporation. In order to prevent this problem, do not touch the glass surface with your fingers.



825RW062


Installation

To install, follow the removal steps in the reverse order.

Headlight Assembly

Removal

1. Disconnect the battery ground cable.
2. Remove the radiator grille (1).
 - Remove eight clips and a screw.
3. Remove the side marker light (3).
 - Remove three screws.
 - Disconnect the connector.
4. Remove the headlight assembly (2).
 - Disconnect the connector.
 - Remove four screws.



825RW063

Installation

To install, follow the removal steps in the reverse order.

CAUTION: After installing the headlight, be sure to adjust the headlight aim.


Headlight Adjustment

Preparation

Place the unloaded vehicle on a level surface and check to see if the inflation pressure of the tires is correct, the lenses are clean, and the battery is sufficiently charged. Adjust the aim with the headlight tester, if necessary. When adjusting, follow the procedure of the tester manufacture's.

Vertical Adjustment


Use a screwdriver for vertical adjustment.



825RW064

Horizontal Adjustment

Use a screwdriver for horizontal adjustment.




825RW066

Fog Light Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the fog light bulb (2).
 - Open the rear cover (1).
 - Remove the dust cover.
 - Disconnect the bulb connector.
 - Remove the clip (3).



801RW002


Installation

To install, follow the removal steps in the reverse order.

Fog Light Assembly

Removal


1. Disconnect the battery ground cable.
2. Remove the fog light assembly (1).
 - Disconnect the connector.
 - Remove two nuts from the bracket.



Fog Light Adjustment

Vertical Adjustment

Turn the adjusting screw with a screwdriver to adjust the aim of the fog light vertically.



Installation


To install, follow the removal steps in the reverse order.

CAUTION: After installing the fog light, be sure to adjust the fog light aim.

Side Marker Light Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the radiator grille.
 - Refer to Engine Hood and Fender in section.
3. Remove the front combination light (2).
 - Remove three screws.
4. Remove the bulb (1).
 - Remove the side marker light socket by turning it counterclockwise.
 - Remove the bulb by turning it counterclockwise while pushing it at the same time.



Installation

To install, follow the removal steps in the reverse order.

Front Combination Light Assembly

Removal

1. Disconnect the battery ground cable.
2. Remove the side combination light.
 - Refer to Side Marker Light Bulb in this section.
3. Disconnect the connector.


Installation

To install, follow the removal steps in the reverse order.

Taillight Bulb


Removal

1. Disconnect the battery ground cable.
2. Remove the rear combination light assembly (1).
 - Remove three screws.
3. Pull out the rear combination light assembly to ward you.



825RW068

4. Remove the bulb (1).
 - Remove the taillight socket by turning it counterclockwise.
 - Remove the bulb by turning it counterclockwise while pushing it at the same time.



825RW069


Installation

To install, follow the removal steps in the reverse order.

License Plate Light Bulb (Bumper Type)

Removal

1. Disconnect the battery ground cable.
2. Remove the lens cover (3).
 - Remove two screws.
3. Remove the lens (2).
4. Remove the bulb (1).
 - Pull out the bulb from the socket.




Installation

To install, follow the removal steps in the reverse order.

License Plate Light Bulb (Tailgate Type)

Removal

1. Disconnect the battery ground cable.
2. Remove the lens cover (3).
 - Remove two screws.
3. Remove the bulb (2).
 - Pull out the bulb from the socket (1).



Installation

To install, follow the removal steps in the reverse order.

Stoplight Bulb

Removal and Installation

Refer to Taillight Bulb in this section.


High Mounted Stoplight Assembly

Removal

1. Disconnect the battery ground cable.
2. Remove the high mount stoplight assembly (2).
 - Remove the cover (3).
 - Disconnect the connectors (1).
 - Remove two screws.

Installation

To install, follow the removal steps in the reverse order.




803RX001

High Mounted Stoplight Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the cover.
3. Disconnect the connectors (2).
4. Remove the bulb (1).
 - Remove the socket by turning it counterclockwise.




Installation

To install, follow the removal steps in the reverse order.

Backup Light Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the rear combination light assembly.
 - Refer to the Taillight Bulb removal step 2 in this section.
3. Remove the bulb (1).
 - Remove the backup light socket by turning it counterclockwise.
 - Remove the bulb by turning it counterclockwise while pushing it at the same time.



Installation

To install, follow the removal steps in the reverse order.

Front Turn Signal Light Bulb

Removal and Installation

Refer to Side Marker Light Bulb in this section.


Rear Turn Signal Light Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the rear combination light assembly.
 - Refer to the Taillight Bulb removal step in this section.
3. Remove the bulb (1).
 - Remove the rear turn signal light socket by turning it counterclockwise.
 - Remove the bulb by turning it counterclockwise while pushing it at the same time.

Installation

To install, follow the removal steps in the reverse order.




825RW074

Dome Light Bulb

Removal

1. Disconnect the battery ground cable.
 2. Remove the lens (2).
 3. Remove the bulb (1).
- Pull out the bulb.



825RW075


Installation

To install, follow the removal steps in the reverse order.

Courtesy Light Bulb

Removal

1. Disconnect the battery ground cable.
 2. Remove the lens (2).
 3. Remove the bulb (1).
- Pull out the bulb.



825RW076

Installation

To install, follow the removal steps in the reverse order.


Spotlight Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the lens (2).
3. Remove the bulb (1).
- Pull out the bulb.

Installation

To install, follow the removal steps in the reverse order.




Luggage Room Light Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the lens (2).
3. Remove the bulb (1).
- Pull out the bulb.

Installation

To install, follow the removal steps in the reverse order.



HVAC Bezel Illumination Light Bulb

Removal and Installation

Refer to Control Panel Illumination bulb in Heating, Ventilation and Air Conditioning (HVAC) section.


Shift Lever Illumination Light Bulb (A/T)

Removal

1. Disconnect the battery ground cable.
2. Remove the console assembly.
 - Remove four screws.
3. Remove the bulb (1).
 - Turn the bulb socket counterclockwise.
 - Pull out the bulb from the socket.

Installation

To install, follow the removal steps in the reverse order.



825RW078


Vanity Mirror Illumination Light Bulb

Removal

1. Disconnect the battery ground cable.
 2. Remove the lens (1).
 3. Remove the bulb (2).
- Attach some scotch tape to the bulb and pull it out.

Installation

To install, follow the removal steps in the reverse order.



743RW005

Starter Switch

Removal and Installation

Refer to Lock cylinder in steering section.

Lighting Switch (Combination Switch)

Removal and Installation

Refer to Combination Switch in Steering section.

Dimmer-Passing Switch (Combination Switch)


Removal and Installation

Refer to Combination Switch in Steering section.

Door Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the door switch (2).
 - Remove the screw (1).
 - Disconnect the connector (3).




Installation

To install, follow the removal steps in the reverse order.

Rear Defogger Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the meter cluster assembly (1).
 - Refer to Instrument Panel Assembly in Body Structure section.
3. Remove the rear defogger switch (2).
 - Disconnect the switch connector.
 - To remove the switch, push the lock from the back side of the meter cluster assembly.



Installation

To install, follow the removal steps in the reverse order.

Key Remind Switch (Starter Switch)

Removal and Installation

Refer to Lock Cylinder in Steering section.


Hazard Warning Light Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the meter cluster assembly (1).
 - Refer to Instrument Panel Assembly in Body Structure section.
3. Remove the hazard warning switch (2).
 - Disconnect the switch connector.
 - To remove the switch, push the lock from the back side of the meter cluster assembly.

Installation

To install, follow the removal steps in the reverse order.



Stoplight Switch


Removal and Installation

Refer to Stoplight Switch in Brake section.

Backup Light Switch (M/T)

Removal

1. Disconnect the battery ground cable.
2. Remove the backup light switch (1).
 - Disconnect the connector (2).



Installation

To install, follow the removal steps in the reverse order, noting the following point.

1. Apply liquid gasket to the screw portion of the switch to prevent oil leak.

Turn Signal Light Switch (Combination Switch)


Removal and Installation

Refer to Combination Switch in Steering section.

Illumination Controller

Removal

1. Disconnect the battery ground cable.
2. Remove the instrument panel driver lower cover assembly (3).
 - Refer to Instrument Panel Assembly in Body Structure section.
3. Remove the illumination controller (2).
 - Disconnect the controller connector.
 - Remove the controller knob (1).
 - Remove the nut.
 - Remove the controller from the back side of the instrument panel driver lower cover assembly.




Installation

To install, follow the removal steps in the reverse order.

Light and Bulb Specifications

Light and Bulb Specifications



801RX001

Legend

- | | |
|---|--|
| (1) Map Light | (7) Luggage Room Light |
| (2) Meter | (8) Dome Light |
| (3) Fog Light | (9) Courtesy Light |
| (4) Headlight | (10) Rear Turn Signal Light |
| (5) Front Turn Signal Light/Front Side Marker Light/Parking Light | (11) Taillight/Stoplight |
| (6) High Mounted Stoplight | (12) Backup Light |
| | (13) License Plate Light (Bumper Type) |
| | (14) License Plate Light (Tailgate Type) |

Light Name		Bulb No.	Rated Power	Number of Bulbs	Lens Color	Remarks
Headlight		—	65w/45w	2	White	Halogen
Front Turn signal Light/ Front Side Marker Light/Parking Light		—	21w/5w	2	Amber	
Fog Light		—	55w	2	White	Halogen
Rear Turn Signal Light		—	21w	2	Amber	
Backup Light		—	21w	2	White	
Taillight/Stoplight		—	21w/5w	2	Red	
High Mount Stoplight		—	5w	4	Red	
License Plate Light (Tailgate type)		—	5w (5W)	1 (2)	White	
Map Light		—	5w	2	White	
Dome Light		—	7w	1	White	
Luggage Room Light		—	5w	1	White	
Courtesy Light		—	3.4w	4	White	
Indicator/Warning Light	Check Trans	—	1.4w	1	Red	Meter
	A/T Oil Temp	—	3w	1	Red	Meter
	Cruise Set	—	1.4w	1	Green	Meter
	Power Drive	—	1.4w	1	Amber	Meter
	Winter Drive	—	1.4w	1	Green	Meter
	Turn Signal	—	1.4w	2	Green	Meter
	Upshift	—	1.4w	1	Amber	Meter
	High Beam	—	1.4w	1	Blue	Meter
	ABS	—	1.4w	1	Amber	Meter
	Seat Belt	—	2w	1	Red	Meter
	Malfunction Indicator (Check Engine)	—	1.4w	1	Amber	Meter
	Low Fuel	—	1.4w	1	Amber	Meter
	4WD	—	1.4w	1	Green	Meter
	Oil Pressure	—	1.4w	1	Red	Meter
	Brake System	—	1.4w	1	Red	Meter
	Charge	—	1.4w	1	Red	Meter
	A/T Shift Position	—	1.4w	7	P,N,D,3,2,L :Green R: Amber	Meter
	Air Bag	—	2w	1	Red	Meter
Illumination Light	Meter	—	3.4w	4		Meter
	Shift lever	—	1.4w	1	White	Shift lever

RODEO

BODY AND ACCESSORIES

WIPER / WASHER SYSTEM

CONTENTS

Service Precaution	8B-1	General Description	8B-8
Windshield Wiper/Washer System	8B-2	Rear Wiper and Washer Switch	8B-8
General Description	8B-2	Removal	8B-8
Windshield Wiper And Washer Switch	8B-2	Installation	8B-8
Removal and Installation	8B-2	Rear Wiper Motor	8B-9
Windshield Wiper Motor	8B-2	Removal	8B-9
Removal	8B-2	Installation	8B-9
Installation	8B-2	Rear Washer Motor	8B-10
Windshield Washer Motor	8B-3	Removal	8B-10
Removal	8B-3	Installation	8B-10
Installation	8B-3	Alarm and Relay Control Unit	8B-10
Windshield Washer Spray Pattern	8B-4	Removal	8B-10
Windshield Wiper Linkage	8B-5	Installation	8B-10
Windshield Wiper Linkage and Associated Parts	8B-5	Rear Wiper Arm/Blade	8B-11
Removal	8B-5	Removal	8B-11
Installation	8B-5	Installation	8B-11
Windshield Wiper Arm/Blade	8B-6	Rear Washer Nozzle	8B-11
Removal	8B-6	Removal	8B-11
Installation	8B-6	Installation	8B-11
Windshield Wiper Blade Rubber	8B-7	Rear Washer Spray Pattern	8B-11
Removal	8B-7	Rear Wiper Blade Rubber	8B-12
Installation	8B-7	Removal	8B-12
Rear Wiper/Washer System	8B-8	Installation	8B-12
		Main Data and Specifications	8B-13

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Windshield Wiper/Washer System

General Description

The circuit consists of the starter switch, windshield wiper & washer switch, windshield wiper motor, windshield washer motor and alarm & relay control unit.

When the windshield wiper & washer switch is turned on with the starter switch on, the battery voltage is applied to the wiper motor to activate the wiper.

The washer motor squirts glass cleaning fluid while the washer switch is being pushed. The alarm & relay control unit relay is used to control motion of the wiper.

Windshield Wiper And Washer Switch

Removal and Installation

Refer to Combination Switch in Steering section.

Windshield Wiper Motor

Removal

1. Disconnect the battery ground cable.
2. Disconnect the connector(2).
3. Remove 4 mounting bolts.
4. Remove the nut of the wiper motor shaft, and disconnect the linkage.
5. Remove the windshield wiper motor(1).

CAUTION: To facilitate the removal of the nuts, be sure to put out the tip portion of the linkage sufficiently through the mounting hole of the motor by sliding the wiper blade slowly.


Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Tighten the wiper motor shaft nut to the specified torque.

Torque: 14 N·m (122 lb in)

2. Remove the wiper arms on both sides, and rotate the wiper motor until it gets to the autostop position to reinstall the wiper blade.




Windshield Washer Motor

Removal

1. Disconnect the battery ground cable.
2. Remove the fender inner liner (right side).
3. Disconnect the windshield washer motor connector and the rear washer motor connector.
4. Disconnect the windshield washer hose connector and the rear washer hose connector.
5. Remove the filler neck (2).
 - Remove the bolt.
6. Remove the washer tank (1).
 - Remove the three nuts.
7. Pull the windshield washer motor (4) from the washer tank.


Installation

To install, follow the removal steps in the reverse order.



880RW028

Windshield Washer Spray Pattern




880RW005

Legend

- (1) Spray Target
- (2) Washer Nozzle

Windshield Wiper Linkage

Windshield Wiper Linkage and Associated Parts



880RW004

Legend

- (1) Windshield Wiper Arm/Blade
- (2) Vent Cowl Cover

- (3) Windshield Wiper Linkage Assembly
- (4) Windshield Wiper Motor

Removal

1. Disconnect the battery ground cable.
2. Remove the windshield wiper arm/blade.
3. Remove the vent cowl cover.
4. Remove the windshield wiper motor.
5. Remove the pivot assembly mounting nuts, fixing screws.
6. Take out the windshield wiper linkage assembly from the opening of the cowl.


Installation

To install, follow the removal steps in the reverse order.

Windshield Wiper Arm/Blade


Removal

1. Dry the cap(2) off with the tip of a screwdriver.
2. Remove the nut.
3. Remove the wiper arm/blade(1).



Installation

To install, follow the removal steps in the reverse order, noting the following points:



1. Before installing the wiper arm/blade to the shaft, confirm that the motor stops at the autostop position.
2. Set the wiper arm/blade so that the tips of both blades are positioned about 40 mm (1.57 in) from the upper edge of the cowl cover as shown in the figure.
3. Tighten the nuts to the specified torque.


Torque: 23 N·m (17 lb ft)

Windshield Wiper Blade Rubber


Removal

1. Push the wiper blade lock(1) while pulling the wiper blade in the arrow direction as shown in the figure.

CAUTION: When the wiper blade has been removed, wrap the tip of the wiper arm with cloth, to avoid damaging the glass.



2. Pull the end of rubber and remove the projection(3) from the click of the blade stay (2).




3. Pull the rubber out in the same direction.


Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Install the click of the blade stay in the groove of the new rubber and slide it in. Complete wiper blade installation by pushing the click.



2. Finally, check that the click of the stay has caught in the hole of the rubber.



Rear Wiper/Washer System

General Description

The circuit consists of the starter switch, rear wiper & washer switch, rear wiper motor, rear washer motor and Alarm & relay control unit.



When the rear wiper & washer switch is turned on with the starter switch on, the battery voltage is applied to the wiper motor to activate the wiper.

The washer motor squirts glass cleaning fluid while the washer switch is being pushed. The alarm & relay control unit is used to control motion of the wiper.

Rear Wiper and Washer Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the dash side trim panel(1).
3. Remove the lower cover assembly(2).
- Refer to Instrument panel Assembly in Body Structure section.



Installation

To install, follow the removal steps in the reverse order, noting the following point:


1. Push the switch with your fingers until it locks securely.

4. Remove the meter cluster assembly(4).
5. Remove the rear wiper & washer switch (5).
- Disconnect the connector.
- Push the lock from the back side of the meter cluster assembly.

Rear Wiper Motor

Removal


1. Disconnect the battery ground cable.
2. Remove the tailgate trim pad.
3. Remove the wiper arm/blade.
Refer to Rear Wiper Arm/Blade in section.
4. Remove the rear wiper motor (1).
○ Disconnect the connector.
○ Remove the rear wiper motor fixing screws.



Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Before installing the wiper arm/blade to the motor shaft, confirm that the motor stops at the autostop position.
2. Install the wiper arm/blade so that the wiper arm (2) contact with the stopper portion (3) on the hatch gate cover (1) as shown in the figure.




3. Tighten the motor shaft nut to the specified torque.
Torque: 10 N·m (87 lb in)
4. Tighten the wiper arm nut to the specified torque.
Torque: 14 N·m (122 lb in)

Rear Washer Motor

Removal

1. Disconnect the battery ground cable.
2. Remove the fender inner liner (right side).
3. Disconnect the windshield washer motor connector and the rear washer motor connector.
4. Disconnect the windshield washer hose connector and the rear washer hose connector.
5. Remove the filler neck (2).
 - Remove the bolt.
6. Remove the washer tank (1).
 - Remove the three nuts.
7. Pull out the rear washer motor (3) from the washer tank.




Installation

To install, follow the removal steps in the reverse order.

Alarm and Relay Control Unit

Removal

1. Disconnect the battery ground cable.
2. Remove the instrument panel (1).
3. Remove the alarm and relay control unit (2).
 - Disconnect the connector.




Installation

To install, follow the removal steps in the reverse order.

Rear Wiper Arm/Blade

Removal

1. Remove the arm nut(2).
2. Remove the wiper arm/blade(1).



885RW007


Installation

Refer to Rear Wiper Motor in section.

Rear Washer Nozzle

Removal

1. Remove the washer nozzle(1).
○Pull out the washer nozzle from the washer hose (2).




885RW003

Installation

To install, follow the removal steps in the reverse order.

Rear Washer Spray Pattern



885RW006

Legend


- (1) Washer Nozzle
- (2) Spray Target

Rear Wiper Blade Rubber

Removal

1. Remove the wiper blade from the wiper arm.
2. Push out the wiper rubber from the wiper blade by sliding it horizontally while holding down the rubber on the wiper blade convex (1) side.


CAUTION: When the wiper blade has been removed, wrap the tip of the wiper arm with cloth, to avoid damaging the glass.




Installation

1. Install the wiper blade rubber.

○ Insert the tip of wiper rubber (2) from the opposite side of removal in the arrow direction.



○ Check if the convex part (3) of wiper blade is installed in the groove of the wiper rubber.



Main Data and Specifications**Torque Specifications**

Application	N·m	Lb Ft	Lb In
Windshield Wiper Motor Shaft Nut	14	—	122
Windshield Wiper Arm Nuts	23	17	—
Rear Wiper Motor Shaft Nut	10	—	87
Rear Wiper Arm Nut	14	—	122

RODEO

BODY AND ACCESSORIES

ENTERTAINMENT

CONTENTS

Service Precaution	8C-1	Front Accessory Socket	8C-4
Cigarette Lighter	8C-2	Rear Accessory Socket	8C-4
General Description	8C-2	Radio	8C-5
Removal	8C-2	Removal	8C-5
Installation	8C-2	Installation	8C-5
Digital Clock	8C-2	Speaker	8C-6
Removal	8C-2	Front Speaker	8C-6
Installation	8C-3	Tweeter Assembly	8C-6
Rod Type Antenna	8C-3	Rear Speaker	8C-6
Removal	8C-3	Horn	8C-7
Installation	8C-3	Removal	8C-7
Accessory Socket	8C-4	Installation	8C-7

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fasteners joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fasteners. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Cigarette Lighter


General Description

When the cigarette lighter is pushed in with the starter switch at either "ACC" or "ON" position, a circuit is formed in the cigarette lighter case to heat the lighter coil.

The cigarette lighter springs back to its original position after the lighter coil is heated.

Removal

1. Disconnect the battery ground cable.
2. Remove the lower cluster assembly (1).
 - Refer to the Instrument Panel Assembly in Body Structure section.
3. Remove the cigarette lighter assembly (2).
 - Disconnect the connectors.
 - Remove the socket (3).



826RW004-1

Installation


To install, follow the removal steps in the reverse order, noting the following point:

1. When installing the bezel, align the projected portion of the socket with the notch of the bezel.

Digital Clock


Removal

1. Disconnect the battery ground cable.
2. Remove the dash side trim panel-LH (1).
 - Refer to Instrument Panel Assembly in Body Structure section.
3. Remove the lower cover assembly (2).
 - Refer to instrument Panel Assembly in Body Structure section.



821RW254-1

4. Remove the meter cluster assembly (4).
Refer to Instrument Panel Assembly in Body Structure section.
5. Remove the digital clock (3).
 - Remove the fixing screw.
 - Disconnect the connector.



821RW092-1


Installation

To install, follow the removal steps in the reverse order.

Rod Type Antenna

Removal

1. Disconnect the battery ground cable.
2. Turn the antenna rod (1) counterclockwise to remove it.
3. Remove three screws and nine clips to remove the fender inner liner (2).
4. Disconnect the feeder cable connector (3) at the inside of the vehicle, remove the housing bracket screw, turn the lock nut counterclockwise to remove it together with the base mold and then remove the housing.



890RW020

Installation


To install, follow the removal steps in the reverse order, noting the following point:

Accessory Socket

Front Accessory Socket

Removal

1. Disconnect the battery ground cable.
2. Remove the front console assembly.
3. Remove the front accessory socket (2).
 - Disconnect the connectors (1).
 - Pull out the front accessory socket from the socket cover (3).



810RW005


Installation

To install, follow the removal steps in the reverse order, noting the following point:

Rear Accessory Socket

Removal

1. Disconnect the battery ground cable.
2. Remove the quarter trim lower cover.
3. Remove the rear accessory socket (2).
 - Disconnect the connectors (1).
 - Pull out the front accessory socket from the socket cover (3).



810RW004


Installation

To install, follow the removal steps in the reverse order, noting the following point:


Radio

Removal

1. Disconnect the battery ground cable.
2. Remove the lower cluster assembly (1).
 - Refer to Instrument Panel Assembly in Body Structure section.



3. Remove the radio (5).
 - Remove the two fixing screws.
 - Disconnect the connector (3) and the antenna cable (4).



Installation


To install, follow the removal steps in the reverse order, noting the following point:

Speaker

Front Speaker

Removal

1. Disconnect the battery ground cable.
2. Pull the grille (1) to release the locks and then remove it.
3. Remove four screws and disconnect the connector (3) to remove the speaker (2).



890RX012


Installation

To install, follow the removal steps in the reverse order, noting the following point:

Tweeter Assembly

Removal

1. Disconnect the battery ground cable.
2. Remove the front door trim pad (2).
 - Refer to Front Window Regulator, Glass And Glass Run in Body Structure section:
3. Remove the tweeter (1).
 - Disconnect the connector.



635RW009


Installation

To install, follow the removal steps in the reverse order, noting the following point:

Rear Speaker

Removal

1. Disconnect the battery ground cable.
2. Remove the roof rear lining (1).
 - Release the locks and clips.
3. Remove the speaker (2).
 - Remove the four screws.
 - Disconnect the connector (3).



890RV019-1


Installation

To install, follow the removal steps in the reverse order, noting the following point:

Horn

Removal

1. Disconnect the battery ground cable.
2. Remove the radiator grille.
 - Refer to Engine Hood and Fender in Body Structure section.
3. Remove the horn (1).
 - Disconnect the connector.
 - Remove the horn mounting bolt.



82BRX001

Installation

To install, follow the removal steps in the reverse order.

RODEO

BODY AND ACCESSORIES

WIRING SYSTEM

CONTENTS

Service Precaution	8D-2	Circuit Diagram	8D-116
General Description	8D-3	Parts Location	8D-117
Main Data and Specifications	8D-25	Diagnosis	8D-118
Start and Charging	8D-45	Dome Light, Luggage Room Light, Courtesy Light, Map Light, Seat Belt Switch and Warning Buzzer	8D-119
General Description	8D-45	General Description	8D-119
Circuit Diagram	8D-46	Circuit Diagram	8D-120
Parts Location	8D-49	Parts Location	8D-125
Powertrain Control Module (PCM)	8D-50	Power Door Lock	8D-126
General Description	8D-50	General Description	8D-126
Circuit Diagram	8D-51	Circuit Diagram	8D-127
Parts Location	8D-64	Parts Location	8D-131
Circuit Diagram	8D-67	Diagnosis	8D-132
Parts Location	8D-77	Power Window	8D-134
Headlight and Fog Light	8D-79	General Description	8D-134
General Description	8D-79	Circuit Diagram	8D-135
Circuit Diagram	8D-80	Parts Location	8D-136
Parts Location	8D-82	Diagnosis	8D-137
Diagnosis	8D-83	Cruise Control	8D-141
Front Side Marker Light, Parking Light, Tail Light and License Plate Light	8D-86	General Description	8D-141
General Description	8D-86	Circuit Diagram	8D-142
Circuit Diagram	8D-87	Parts Location	8D-144
Parts Location	8D-89	Diagnosis	8D-145
Diagnosis	8D-90	Diagnosis	8D-147
Interior Illumination Light	8D-93	Anti-Lock Brake System (ABS)	8D-149
General Description	8D-93	General Description	8D-149
Circuit Diagram	8D-94	Circuit Diagram	8D-150
Parts Location	8D-98	Parts Location	8D-153
Turn Signal Light, Hazard Warning Light	8D-99	A/T Shift Lock	8D-154
General Description	8D-99	General Description	8D-154
Circuit Diagram	8D-100	Circuit Diagram	8D-155
Parts Location	8D-103	Parts Location	8D-156
Diagnosis	8D-104	Windshield Wiper and Washer	8D-157
Stoplight	8D-106	General Description	8D-157
General Description	8D-106	Circuit Diagram	8D-158
Circuit Diagram	8D-107	Parts Location	8D-160
Parts Location	8D-108	Diagnosis	8D-161
Diagnosis	8D-109	Rear Wiper/Washer	8D-167
Backup Light	8D-111	General Description	8D-167
General Description	8D-111	Circuit Diagram	8D-168
Circuit Diagram	8D-112	Parts Location	8D-171
Parts Location	8D-113	Diagnosis	8D-172
Diagnosis	8D-114	Rear Defogger/Mirror Defogger	8D-177
Horn	8D-115	General Description	8D-177
General Description	8D-115		

8D-2 WIRING SYSTEM

Circuit Diagram	8D-178	Parts Location	8D-221
Parts Location	8D-180	Diagnosis	8D-222
Diagnosis	8D-181	A/T Shift Indicator	8D-228
Audio	8D-184	General Description	8D-228
General Description	8D-184	Circuit Diagram	8D-229
Circuit Diagram	8D-185	Parts Location	8D-231
Parts Location	8D-186	Heater and Air Conditioning	8D-232
Cigarette Lighter, Digital Clock and Accessory Socket	8D-187	General Description	8D-232
General Description	8D-187	Circuit Diagram	8D-233
Circuit Diagram	8D-188	Parts Location	8D-236
Parts Location	8D-189	Sun Roof	8D-237
Diagnosis	8D-190	General Description	8D-237
Power Door Mirror	8D-191	Circuit Diagram	8D-238
General Description	8D-191	Parts Location	8D-239
Circuit Diagram	8D-192	Diagnosis	8D-240
Parts Location	8D-194	Supplemental Restraint System (SRS) –	
Diagnosis	8D-195	Air Bag	8D-241
Keyless Entry and Anti-Theft System	8D-196	General Description	8D-241
General Description	8D-196	Circuit Diagram	8D-242
Circuit Diagram	8D-197	Parts Location	8D-243
Parts Location	8D-202	Shift on the Fly System	8D-244
Diagnosis	8D-203	General Description	8D-244
Meter and Warning/Indicator Light	8D-213	Circuit Diagram	8D-245
General Description	8D-213	Parts Location	8D-247
Circuit Diagram	8D-214	Harness Connector Faces	8D-248

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fasteners joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fasteners. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

The chassis electrical system is a 12-volt system with a negative ground polarity.

Wire size are appropriate to respective circuits, and classified by color. (The classification of harnesses by color is shown on the circuit diagram for ease of harness identification.)

The wire size is determined by load capacity and the length of wire required.

The vehicle harness are: body harness, chassis harness, engine room harness, instrument harness, transmission harness, engine ECGI harness, dome light harness, door harness, rear body harness, tailgate harness, SRS harness and battery cables.

The harnesses are protected either by tape or corrugated tube, depending on harness location.

The circuit for each system consists of the power source, wire, fuse, relay, switch, load parts and ground, all of which are shown on the circuit diagram.

In this section, each electrical device is classified by system.


For major parts shown on the circuit based on the circuit diagram for each system, a summary, diagnosis of troubles and inspection procedures are detailed.

Notes for Working on Electrical Items

Disconnecting the Battery Cable

1. All switches should be in the "OFF" position.
2. Disconnect the battery ground cable (2).
3. Disconnect the battery positive cable (1).

CAUTION: It is important that the battery ground cable be disconnected first. Disconnecting the battery positive cable first can result in a short circuit.



061RW002

Connecting the Battery Cable

Follow the disconnecting procedure in the reverse order.

CAUTION: Clean the battery terminal and apply a light coat of grease to prevent terminal corrosion.

Disconnecting the Connector

Some connectors have a tang lock to hold the connectors together during vehicle operation.


Some tang locks are released by pulling them towards you (1).

Other tang locks are released by pressing them forward (2).

Determine which type of tang lock is on the connector being handled.


Firmly grasp both sides (male and female) of the connector.

Release the tang lock and carefully pull the two halves of the connector apart.




D08RW128

Never pull on the wires to separate the connectors. This will result in wire breakage as shown in the figure.



D08RW129


When removing the connector for relay (MR5B type) (3), unfasten the tang lock of the connector by using a screwdriver, then pull the relay out as shown in the figure.



Connecting the Connector


Firmly grasp both sides (male and female) of the connector. Be sure that the connector pins and pin holes match. Be sure that both sides of the connector are aligned with each other.

Firmly but carefully push the two sides of the connector together until a distinct click is heard.




Connector Inspection

Use a circuit tester to check the connector for continuity. Insert the test probes (1) from the connector wire side.




Never insert the circuit tester test probes (2) into the connector open end to test the continuity.

Broken or open connector terminals will result.



Waterproof Connector Inspection


It is not possible to insert the test probes (2) into the connector wire side of a waterproof connector. Use one side of a connector (1) with its wires cut to make the test. Connect the test connector (3) to the connector to be tested. Connect the test probes to the cut wires to check the connector continuity.



D08RW134

Connector Pin Removal – Connector Housing Tang Lock Type


1. Insert a slender shaft (1) into the connector housing open end (5).
2. Push the tang lock (2) up (in the direction of the arrow in the illustration). Pull the wire (3) with pin (4) free from the wire side of the connector.



D08RW135

Connector Pin Removal – Pin Tang Lock Type


1. Insert a slender shaft (1) into the connector housing open end (5).
2. Push the tang lock (2) flat (toward the wire (3) side of the connector). Pull the wire with pin (4) free from the wire side of the connector.



D08RW136

Connector Pin Insertion


1. Check that the tang lock (1) is fully up.
2. Insert the pin (3) from the connector wire (2) side. Push the pin in until the tang lock closes firmly.
3. Gently pull on the wires to make sure that the connector pin is firmly set in place.



D08RW137

Parts Handling


Be careful when handling electrical parts. They should not be dropped or thrown, because short circuiting or other damage may result.



D08RW138


Cable Harness

1. When installing the parts, be careful not to pinch or wedge the wiring harness.
2. All electrical connections must be kept clean and tight.




D08RW139

3. Use a grommet or guard tube to protect the wiring harness from contacting a sharp edge or surface.




D08RW139

4. Position the wiring harness with enough clearance from the other parts and guard the wiring harness with a vinyl tube (2) and clips (1) to avoid direct contact.



D08RW141


5. The wiring harness between engine and chassis should be long enough to prevent chafing or damage due to various vibrations.




Splicing Wire

1. If the harness is taped, remove the tape. To avoid wire insulation damage, use a sewing "seam ripper" (available from sewing supply stores) to cut open the harness.
If the harness has a black plastic conduit, simply pull out the desired wire.
2. Begin by cutting as little wire off the harness as possible. You may need the extra length of wire later if you decide to cut more wire off to change the location of a splice. You may have to adjust splice locations to make certain that each splice is at least 1-1/2" (40 mm) away from other splices, harness branches, or connectors.
3. When replacing a wire, use a wire of the same size as the original wire.
Check the stripped wire for nicks or cut stands. If the wire is damaged, repeat the procedure on a new section of wire. The two stripped wire ends should be equal in length.
4. Select the proper clip to secure the splice.
To determine the proper clip size for the wire being spliced, follow the directions included with your clips. Select the correct anvil on the crimper. (On most crimpers your choice is limited to either a small or large anvil.)
Overlap the two stripped wire ends and hold them between your thumb and forefinger as shown in the figure.

The center the spline clip (1) under the stripped wires and hold it in place.



- Open the crimping tool to its full width and rest one handle on a firm flat surface.
- Center the back of the splice clip on the proper anvil and close the crimping tool to the point where the back of the splice clip touches the wings of the clip.
- Make sure that the clip and wires are still in the correct position. Then, apply steady pressure until the crimping tool closes as shown in the figure.




8D-8 WIRING SYSTEM

Before crimping the ends of the clip (1), be sure that:

- The wires extend beyond the clip in each direction.
- No strands of wire are cut loose, and
- No insulation is caught under the clip.


Crimp the splice again, once on each end.

Does not let the crimping tool (2) extend beyond the edge of the clip or you may damage or nick the wires as shown in the figure.



5. Apply 60/40 resin core solder to the opening in the back of the clip as shown in the figure.

Follow the manufacturer's instructions for the solder equipment you are using.




6. Center and roll the splicing tape.


The tape should cover the entire splice.

Roll on enough tape to duplicate the thickness of the insulation on the existing wires.

Does not flag the tape. Flagged tape may not provide enough insulation, and the flagged ends will tangle with the other wires in the harness as shown in the figure.















If the wire does not belong in a conduit or other harness covering, tape the wire again. Use a winding motion to cover the first piece of tape as shown in the figure.









Symbols and Abbreviations







Symbols



Symbol	Meaning of Symbol
	Fuse
	Fusible link
	Fusible link wire
	Switch
	Switch
	Switch (Normal close type)

Symbol	Meaning of Symbol
	Contact wiring
	Battery
	Diode
	Electronic parts
	Resistor
	Speaker

8D-10 WIRING SYSTEM

Symbol	Meaning of Symbol
	Buzzer
	Circuit breaker
	Bulb
	Double filament bulb
	Motor
	Variable register Rheostat

Symbol	Meaning of Symbol
	Coil (inductor), solenoid, magnetic valve
	Relay
	Connector
	Light emitting diode
	Reed switch
	Condenser

Symbol	Meaning of Symbol
	Horn
	Vacuum switching valve

8D-12 WIRING SYSTEM

Abbreviations

Abbreviation	Meaning of Abbreviation
A	Ampere (S)
ABS	Anti-lock brake system
ASM	Assembly
AC	Alternating current
A/C	Air conditioner
ACC	Accessories
A/T	Automatic transmission
C/B	Circuit breaker
CSD	Cold start device
DIS	Direct ignition system
EBCM	Electronic brake control module
ECGI	Electronic control gasoline injection
ECM	Engine control module
ECU	Electronic control unit
EFE	Early fuel evaporation
EGR	Exhaust gas recirculation
4A/T	4-speed automatic transmission
4WD	Four-wheel drive
FL	Fusible link
FRT	Front
H/L	Headlight
IC	Integrated circuit
IG	Ignition



Abbreviation	Meaning of Abbreviation
kW	Kilowatt
LH	Left hand
LWB	Long wheel base
M/T	Manual transmission
OD	Over drive
OPT	Option
PCM	Powertrain control module
QOS	Quick on start
RH	Right hand
RR	Rear
SDM	Sensing and diagnostic module
SRS	Supplemental restraint system
ST	Start
STD	Standard
SW	Switch
SWB	Short wheel base
3A/T	3-speed automatic transmission
V	Volt
VSV	Vacuum switching valve
W	Watt (S)
WOT	Wide open throttle
W/	With
W/O	Without

Parts for Electrical Circuit

Wiring – Wire color

All wires have color-coded insulation.

Wires belonging to a system's main harness will have a single color (1). Wires belonging to a system's subcircuits will have a colored stripe (2). Striped wires use the following code to show wire size and colors.



Wiring – Wire Color Coding

Abbreviations are used to indicate wire color within a circuit diagram.


Refer to the following table.

Color-coding	Meaning
B	Black
W	White
R	Red
G	Green
Y	Yellow
L	Blue
O	Orange
BR	Brown
LG	Light green
GR	Grey
P	Pink
LB	Light blue
V	Violet

8D-14 WIRING SYSTEM

Wiring – Wire Size

The size of wire used in a circuit is determined by the amount of current (amperage), the length of the circuit, and the voltage drop allowed. The following wire size and load capacity, shown below, are specified by AWG (American Wire Gauge) (Nominal size means approximate cross sectional area (1).)



D08RW151

Wiring – Wire Size Table

Nominal size	Cross sectional area (mm ²)	Outside diameter (mm)	Allowable current (A)	AWG size (cross reference)
0.3	0.372	1.5	9	22
0.5	0.563	1.7	12	20
0.85	0.885	1.9	16	18
1.25	1.287	2.2	21	16
2	2.091	2.7	28	14
3	3.296	3.6	37.5	12
5	5.227	4.4	53	10
8	7.952	5.5	67	8
15	13.36	7.0	75	6
20	20.61	8.2	97	4

Fuse


Fuses are the most common form of circuit protection used in vehicle wiring. A fuse is a thin piece of wire or strip of metal encased in a glass or plastic housing. It is wired in series with the circuit it protects. When there is an overload of current in a circuit, such as a short to ground, the metal strip is designed to burn out and interrupt the flow of current. This prevents a surge of high current from reaching and damaging other components in the circuit.

Determine the cause of the overloaded before replacing the fuse.

The replacement fuse must have the same amperage specification as the original fuse.

Never replace a blown fuse with a fuse of a different amperage specification.

Doing so can result in an electrical fire or other serious circuit damage. A blown fuse is easily identified as shown in the figure.




Fusible Link

The fusible link is primarily used to protect circuits where high amounts of current flow and where it would not be practical to use a fuse. For example, the starter circuit. When a current overload occurs, the fusible link melts open and interrupts the flow of current so as to prevent the rest of the wiring harness from burning.

Determine the cause of the overload before replacing the fusible link. the replacement fusible link must have the same amperage specification as the original fusible link. Never replace a blown fusible link with fusible link of a different amperage specification. Doing so can result in an electrical fire or other serious circuit damage.


A blown fusible link is easily identified as shown in the figure.

**Fusible Link Specifications**

Type	Rating	Case Color	Maximum Circuit Current (A)
Connector	30A	Pink	15
Connector	40A	Green	20
Bolted	50A	Red	25
Bolted/Connector	60A	Yellow	30
Bolted	80A	Black	40
Bolted	100A	Blue	50

Circuit Breaker

The circuit breaker is a protective device designed to open the circuit when a current load is in excess of rated breaker capacity. If there is a short or other type of overload condition in the circuit, the excessive current will open the circuit between the circuit breaker terminals. The reset knob (1) pops out when the circuit is open. Push the reset knob in place to restore the circuit after repairing it.




D08RW155

Relay

Battery and load location may require that a switch be placed some distance from either component. This means a longer wire and a higher voltage drop (1).



The installation of a relay between the battery and the load reduces the voltage drop (2).

Because the switch controls the relay, amperage through the switch can be reduced.



D08RW156























Relay Specifications and Configurations

Color	Rated voltage/Coil resistance		Name/ Color	Rated voltage/Coil resistance	Internal circuit
1T (MR5C)/ Black	12V/ Approx. 90Ω Minimum operating voltage: 7V at 77°F (25°C)		1M (M02)/ Black	12V/ Approx. 130Ω Minimum operating voltage: 7V at 77°F (25°C)	

F00RX012

*Relay contact shown in the wiring diagram indicates condition before actuation.

Diode – Diode Specifications and Configurations


SHAPE	MARK / COLOR	CONSTRUCTION	CHECKING: THERE SHOULD BE CONTINUITY IN EITHER A OR B WHEN A CIRCUIT TESTER IS CONNECTED WITH DIODE TERMINAL																																					
	 BLACK		<table><tr><td colspan="2">TERMINAL NO.</td><td colspan="2"></td></tr><tr><td colspan="2"></td><td>2</td><td>1</td></tr><tr><td rowspan="2">CONNECTION PATTERN</td><td>A</td><td>⊕</td><td>⊖</td></tr><tr><td>B</td><td>⊖</td><td>⊕</td></tr></table>	TERMINAL NO.						2	1	CONNECTION PATTERN	A	⊕	⊖	B	⊖	⊕																						
TERMINAL NO.																																								
		2	1																																					
CONNECTION PATTERN	A	⊕	⊖																																					
	B	⊖	⊕																																					
	 BLACK		<table><tr><td colspan="2">TERMINAL NO.</td><td colspan="3"></td></tr><tr><td colspan="2"></td><td>3</td><td>2</td><td>1</td></tr><tr><td rowspan="4">CONNECTION PATTERN</td><td rowspan="2">A</td><td>⊖</td><td>⊕</td><td></td></tr><tr><td></td><td>⊕</td><td>⊖</td></tr><tr><td rowspan="2">B</td><td>⊕</td><td>⊖</td><td></td></tr><tr><td></td><td>⊖</td><td>⊕</td></tr></table>	TERMINAL NO.							3	2	1	CONNECTION PATTERN	A	⊖	⊕			⊕	⊖	B	⊕	⊖			⊖	⊕												
	TERMINAL NO.																																							
			3	2	1																																			
	CONNECTION PATTERN	A	⊖	⊕																																				
				⊕	⊖																																			
		B	⊕	⊖																																				
			⊖	⊕																																				
 BLACK		<table><tr><td colspan="2">TERMINAL NO.</td><td colspan="3"></td></tr><tr><td colspan="2"></td><td>3</td><td>2</td><td>1</td></tr><tr><td rowspan="4">CONNECTION PATTERN</td><td rowspan="2">A</td><td>⊖</td><td>⊕</td><td></td></tr><tr><td></td><td>⊕</td><td>⊖</td></tr><tr><td rowspan="2">B</td><td>⊕</td><td>⊖</td><td></td></tr><tr><td></td><td>⊖</td><td>⊕</td></tr></table>	TERMINAL NO.							3	2	1	CONNECTION PATTERN	A	⊖	⊕			⊕	⊖	B	⊕	⊖			⊖	⊕													
TERMINAL NO.																																								
		3	2	1																																				
CONNECTION PATTERN	A	⊖	⊕																																					
			⊕	⊖																																				
	B	⊕	⊖																																					
			⊖	⊕																																				
 BLACK		<table><tr><td colspan="2">TERMINAL NO.</td><td colspan="3"></td></tr><tr><td colspan="2"></td><td>4</td><td>3</td><td>2</td><td>1</td></tr><tr><td rowspan="6">CONNECTION PATTERN</td><td rowspan="3">A</td><td></td><td></td><td>⊕</td><td>⊖</td></tr><tr><td></td><td>⊖</td><td>⊕</td><td></td></tr><tr><td>⊖</td><td></td><td>⊕</td><td></td></tr><tr><td rowspan="3">B</td><td></td><td></td><td>⊖</td><td>⊕</td></tr><tr><td></td><td>⊕</td><td>⊖</td><td></td></tr><tr><td>⊕</td><td></td><td>⊖</td><td></td></tr></table>	TERMINAL NO.							4	3	2	1	CONNECTION PATTERN	A			⊕	⊖		⊖	⊕		⊖		⊕		B			⊖	⊕		⊕	⊖		⊕		⊖	
TERMINAL NO.																																								
		4	3	2	1																																			
CONNECTION PATTERN	A			⊕	⊖																																			
			⊖	⊕																																				
		⊖		⊕																																				
	B			⊖	⊕																																			
			⊕	⊖																																				
		⊕		⊖																																				

Diode – Maximum Rating (Temp. = 77°F (25°C))


Items	Rating	Remarks
Peak reverse voltage	400V	
Transient peak reverse voltage	500V	
Average output current	1.5A	Temp. = 104°F (40°C)
Working ambient temperature	–22°F~176°F (–30°C~80°C)	
Storage temperature	–40°F~212°F (–40°C~100°C)	

Connector

- The connector pin shape (2) determines whether the connector is male (3) or female (1).




- The symbol illustrated in the figure is used as connector, in the circuit of this section.




Legend

- (4) Female Side Connector
- (5) Male Side Connector


- Connector is identified with a connector number (6)



- The applicable terminal number (7) is shown for each connector.




- Connector terminal numbers (10) are clearly shown. Make side connector (9) terminal numbers are in sequence from upper right to lower left. Female side connector (8) terminal numbers are in sequence from upper left to lower right.



D08RW163


NOTE:

1. For those connectors on which specific terminal numbers or symbols are shown (such as PCM), the terminal numbers or symbols are used in the circuit diagram, irrespective of the above rule. Refer to the following figure.



D08RW164


2. The connectors used for relays have their own terminal number assignment, irrespective of the above rule. Refer to the following figure.



Double Lock Type Connector

Doublelock type yellow color connectors are used for supplemental restraint system—air bag circuit. When removing the cable harness, disconnect the connector by unlocking at two places, outside (1) and inside (2). In such a case, do not pull the cables. Otherwise, cable disconnection may occur.

When connecting the connector, insert the connector completely and lock at outside. Imperfect locking may cause malfunction of SRS system circuit.




F00RX010

Reading the Circuit Diagram

In this section, each system has its own parts location illustration and circuit diagram. And harness connector faces used in the circuit diagram are shown at the end of this section.

Parts Location


The parts location shows the location of the connectors (1) and the harness (2) used in each harness routing.



D08RX044

Circuit Diagram











The circuit diagram shows the power supply (1) the load or loads (2) and the grounding point(s) (3).



Harness Connector Faces


The harness connector faces show each connector's number (1), configuration (2) and the pin number (3).

8D-278 WIRING SYSTEM

1	NO.	Connector face	NO.	Connector face
	D-1		D-11	
	D-2		D-12	
	2		D-13	
	3		D-14	
	D-4		D-15	
	D-5		D-16	
	D-6			

Main Data and Specifications

Fuse, Fusible Link and Circuit Breaker Location



810RX003

Legend

- (1) Relay & Fuse Box (Engine Room)
- (2) Relay & Fuse Box (Instrument panel)


Relay & Fuse Box (Engine Room)

Fuse		
No.	Capacity	Indication on label
1	15A	HAZARD
2	10A	HORN
3	—	—
4	20A	BLOWER
5	10A	A/C
6	—	—
7	—	—
8	10A	H/L LIGHT-LH
9	10A	H/L LIGHT-RH
10	15A	FOG LIGHT
11	20A	O2 SENSOR
12	20A	FUEL PUMP
13	15A	ECM
14	—	—
15	60A	IGN.
16	100A	MAIN
17	60A	ABS
18	30A	(COND. FAN)
19	—	—
20	30A	ELEC. FAN

Relay & Fuse Box (Instrument panel)

Fuse		
No.	Capacity	Indication on label
1	20A	ACC. SOCKET
2	10A	(AUDIO)
3	15A	CIGAR LIGHTER
4	15A	TAIL/ILLUMI. LIGHT
5	10A	DOME LIGHT
6	15A	STOP LIGHT
7	20A	(POWER DOOR LOCK)
8	10A	(MIRROR DEFOG)
9	15A	(REAR DEFOG)
10	15A	(REAR DEFOG)
11	15A	METER
12	15A	ENGINE IG.
13	15A	IG. COIL
14	15A	BACK UP/TURN LIGHT
15	15A	ELEC. IG.
16	20A	FRONT WIPER & WASHER
17	10A	(REAR WIPER & WASHER)
18	10A	(ANTI THEFT)
19	15A	(AUDIO)
20	10A	STARTER
21	30A	(POWER WINDOW)
22	10A	SRS
23	—	—

Fuse Block Circuit-1 (6VD1)




D08RW476


Fuse Block Circuit-1 (X22SE)



Fuse Block Circuit-2



Fuse Block Circuit-3



Fuse Block Circuit-4



Reference Table of Fuse, Fusible Link and Circuit Breaker**Fuse (Relay and Fuse Box - Engine Room)**

Fuse No.	Capacity	Indication on label	Parts (Load)
1	15A	HAZARD	Hazard warning light
2	10A	HORN	Alarm & relay control unit, Horn, Anti - theft horn
5	20A	BLOWER	Blower motor, Blower resistor
5	10A	A/C	A/C thermostat relay, Electronic thermostat, A/C compressor relay, Magnetic clutch
8	10A	H/L LIGHT - LH	Headlight - LH, High beam indicator light, Fog light relay
9	10A	H/L LIGHT - RH	Headlight - RH
10	15A	FOG LIGHT	Fog light
11	20A	O ₂ SENSOR	Oxygen sensor
12	20A	FUEL PUMP	Fuel pump
13	15A	ECM	Engine control module
14	—	—	—
15	60A	IGN.	
16	100A	MAIN	
17	60A	ABS	EHCUC
18	30A	COND. FAN	(6VD1) Condenser fan unit
20	30A	ELEC. FAN	(X22SE) Electric fan relay, Electric fan

Fuse (Relay & Fuse Box - Instrument Panel)

Fuse No.	Capacity	Indication on label	Parts (Load)
1	20A	ACC. SOCKET	Acc socket relay, Acc socket
2	10A	(AUDIO)	Audio
3	15A	CIGAR LIGHTER	Cigarette Lighter
4	15A	TAIL/ILLUMI. LIGHT	Tail relay, Parking light & Side marker light, Tail light License plate light, Illumination controller, Illumination light, A/T shift indicator control unit
5	10A	DOME LIGHT	Stop light, Dome light, Courtesy light - LH, Courtesy light - RH, Courtesy light RR - LH, Courtesy light RR - RH, Luggage room light, Alarm & relay control unit, Digital clock, Audio
6	15A	STOP LIGHT	Stop light switch, Rear combination light - LH, Rear combination light - RH, High mounted stop light
7	20A	(POWER DOOR LOCK)	FRT door lock & Power window SW, Door lock actuator, Anti- theft indicator light
8	10A	(MIRROR DEFOG)	Mirror defogger
9	15A	(REAR DEFOG)	Rear defogger
10	15A	(REAR DEFOG)	Rear defogger
11	15A	METER	Indicator and warning lights (meter), Meter gauge, Vehicle speed sensor
12	15A	ENGINE IG.	Generator, ECM main relay, VSV; purge solenoid, Coil drive, PCM, EGR valve

Fuse (Relay & Fuse Box - Instrument Panel)

Fuse No.	Capacity	Indication on label	Parts (Load)
13	15A	IG. COIL	Ignition coil
14	15A	BACKUP/TURN LIGHT	Mode SW, PCM, Turn signal light, Backup light, Cruise control unit, A/T shift indicator control unit
15	15A	ELEC. IG.	Alarm & relay control unit, Rear defogger relay, Mirror defogger - LH, Mirror defogger - RH, Rear defogger SW, Power window relay, Cruise control unit, Shift lock relay, 4WD control unit, VSV; FRT axle (c), VSV; FRT axle (d)
16	20A	FRONT WIPER & WASHER	Windshield wiper motor, Windshield washer motor, Alarm & relay control unit
17	10A	(REAR WIPER & WASHER	Rear wiper motor, Rear washer motor, Alarm & relay & control unit
18	10A	ANTI THEFT	Anti - theft control unit
19	15A	(AUDIO)	Audio
20	10A	STARTER	Starter, Starter relay, Anti - theft controller
22	10A	SRS	SRS warning light, SDM

PCM: Power train module, VSV: Vacuum switching valve

Fusible Link (Relay and Fuse Box - Engine Room)


Fuse Link No.	Capacity	Indication on label
15	60A	IGN.
16	100A	MAIN
17	60A	ABS
18	30A	COND. FAN
20	30A	ELEC. FAN

ABS: Anti - lock Brake System

Circuit Breaker (Relay & Fuse Box - Instrument Panel)

Fuse No.	Capacity	Indication on label	Parts (Load)
21	30A	(POWER WINDOW)	Power window relay, Power window SW, Power window motor, Sun roof motor, Sun roof control unit, Sun roof SW, Safety stop SW, Limit SW, Power seat switch, Front tilt motor & SW, Rear tilt motor & SW, Slide motor, Recliner motor & Sw

Relay Location



810RX004

Legend

(1) Relay & Fuse Box (Engine Room)

(2) Relay & Fuse Box (Instrument panel)




(3) Relay Box (Engine Room)

Relay List

Connector No.		X-1	X-2	X-3	X-4	X-5	X-6	X-7	X-8	X-9
Usage		Head light	Fog light	Starter	A/C comp.	Thermo	Heater	Fuel pump	ECM	COND FAN
Engine	6VD1	○	○	○	○	○	○	○	○	○
	X22SE	○	○	○	○	○	○	○	○	—

Connector No.		X-10	X-15	X-16	I-34	I-35	I-36	I-37	I-38	I-39
Usage		—	Elec-fan-hi	Elec-fan-lo	Taillight	Power window	—	—	ACC socket	Rear defogger
Engine	6VD1	—	—	—	○	○	—	—	○	○
	X22SE	—	○	○	○	○	—	—	○	○

Diode Location



810RW011-1

Legend

- (1) X-11
- (2) X-12
- (3) X-13
- (4) X-14

- (5) I-44
- (6) I-45
- (7) Relay & Fuse Box (Instrument panel)
- (8) Relay & Fuse Box (Engine Room)


Diode List

Connector No.		X-11	X-12	X-13	X-14	I-44	I-45
Usage		Brake	—	—	—	Tailgate SW, Door SW. Doom light, Anti-theft	Anti-theft, Alarm & relay control unit
Engine	6VD1	○	—	—	—	○	○
	X22SE	○	—	—	—	○	○


Grounding Point**Reference Table**

Connector No.	Cable harness	Location	Parts (Load)
B-6	Body harness	Body-Center	Vanity mirror illumination, RR turn signal light - RH, Sun roof control unit, Sun roof motor, Spot light, Taillight - RH, Stoplight - RH
B-8			Vanity mirror illumination, Rear defogger relay, Rear defogger SW, FRT door lock & power window SW - RH, Cruise control unit, Digital clock, Cigarette lighter, Mirror defogger - RH, Blower motor, Blower resistor, Electronic thermostat, A/T shift lock, Flasher unit, Audio Door lock actuator, FRT power window & door lock SW - LH, RR wiper intermittent relay, Mirror defogger - LH, Seat belt SW, Stoplight - LH Anti - theft controller, Heater & A/C relay, Tail relay, PCM, Headlight, High beam indicator light, Lighting relay, Fog light relay, Illumination controller, Flasher unit, Cornering relay, Power window relay, Headlight wiper motor, Turn signal indicator light, Luggage room light, Map light, Alarm & relay control unit Fuel pump, RR door lock & power window SW, Shift lock controller, Power door mirror motor, Mirror defogger SW, Seat belt warning light Fuel tank unit, Fuel warning light.
C-16	Engine room harness	Fender-LH	FRT combination light - LH, FRT turn signal light - LH, Cornering light - LH, Vehicle speed snsor Windshield washer motor (FRT) Brake warning light, PCM Data link connector FRT combination light - RH, Cornering light - RH, FRT turn signal light - RH Fog light, EHCUC Kick down SW Oxygen sensor, FRT-LH, FRT-RH, RR-LH, RR-RH, 4WD indicator light, VSV; FRT axle
C-36	Engine room harness	Fender-RH	Windshield wiper motor Engine hood SW Windshield washer motor, Windshield washer motor
E-28	Engine ECGI harness	Common chamber	Ignition coil, Coil driver, EGR valve, I.A.T.S., T.P.S. PCM, ECM main relay, Fuel pump relay, Cam position sensor
E-30			Crank position sensor, Knock sensor, PCM, Mass air flow sensor, Data link connector
I-43	Instrument harness	Body-FRT	SDM

Location – 1



D08RW050






D08RW054

Legend

- (1) B-6, B-7, B-8
- (2) 2-4WD Control Unit

- (3) C-36
- (4) EHC

Location – 2




Legend

- (1) E-28
- (2) I-43

- (3) H-32
- (4) P-7
- (5) Frame

Location – 3




D08RW051

Legend

- (1) P-10
- (2) Battery


Cable Harness Routing



D08RX045

Legend


- | | |
|----------------------------------|-----------------------------------|
| (1) Battery (-) Cable | (18) Ext. Anti-Lock Brake Harness |
| (2) Battery (+) Cable | (19) Door Harness (FRT LH) |
| (3) H-2, H-3 | (20) Chassis Harness |
| (4) Battery Cable Harness | (21) H-30 |
| (5) H-7, H-8 | (22) H-15, H-31, H-32 |
| (6) Transmission Harness (X22SE) | (23) C-16 |
| (7) H-12, H-19 | (24) Body Harness |
| (8) I-41, I-42 | (25) Engine Harness |
| (9) Body Harness | (26) H-4, H-5, H-6 |
| (10) Instrument Harness | (27) H-9, H-10, H-11 |
| (11) Door Harness (RR RH) | (28) Transmission Harness (6VD1) |
| (12) H-29 | (29) C-36 |
| (13) H-20, H-21, H-22, H-34 | (30) Engine Room Harness |
| (14) Hatch Glass Harness | (31) P-6 |
| (15) Roof Harness | (32) P-1 |
| (16) Tail Gate Harness | (33) H-1 |
| (17) Door Harness (RR LH) | (34) Battery |
| | (35) P-5 |



D08RX046

Legend

- | | |
|--------------------------|------------------------|
| (1) Instrument Harness | (13) Tail Gate Harness |
| (2) I-17 | (14) G-10, G-11 |
| (3) H-33 | (15) G-12 |
| (4) D-12 | (16) B-8 |
| (5) Door Mirror (RH) | (17) B-23 |
| (6) H-19 | (18) H-28 |
| (7) Body Harness | (19) I-39 |
| (8) H-21 | (20) I-46 |
| (9) H-20 | (21) Relay & Fuse Box |
| (10) Hatch Glass Harness | (22) H-31 |
| (11) G-9 | (23) D-3 |
| (12) Body Harness | (24) Door Mirror (LH) |



D08RX047

Legend

- | | |
|--------------------------|-------------------------|
| (1) FRT/RR Washer Tank | (11) G-11 |
| (2) Engine Room Harness | (12) H-22 |
| (3) C-36 | (13) H-23 |
| (4) H-13 | (14) B-8 |
| (5) I-41, I-42 | (15) I-16 |
| (6) Body Harness | (16) Instrument Harness |
| (7) Tail Gate SW | (17) H-31 |
| (8) G-6 | (18) I-46 |
| (9) RR Wiper Motor | (19) I-43 |
| (10) Hatch Gate Actuator | (20) C-16 |


Start and Charging

General Description

This system consists of starter, AC generator, starter relay, clutch start SW (M/T), mode SW (A/T) and heater & A/C relay.


When starter SW is set to "ST" position with A/T select lever at "P" (Parking) or "N" (Neutral) position (Mode SW "ON"), or clutch pedal depressed (Clutch start SW "ON"), battery positive voltage is applied to starter solenoid coil through starter relay to start starter. At the same time, starter relay cuts off blower motor and A/C circuit.

Circuit Diagram-1 (6VD1)




D08RX014

Circuit Diagram-1 (X22SE)




D08RX015

Circuit Diagram-3



Parts Location



D08RX017

Legend

- (1) X-3, X-6
- (2) H-2, H-3
- (3) C-36
- (4) H-13, H-14
- (5) I-26
- (6) B-8
- (7) Starter Switch
- (8) I-20 (M/T)
- (9) H-17

- (10) Mode Switch (A/T)
- (11) M-16
- (12) H-11
- (13) P-4
- (14) P-3
- (15) P-8
- (16) P-9
- (17) P-7
- (18) H-2

Powertrain Control Module (PCM)

General Description


The Powertrain Control Module (PCM) is located in the passenger compartment.

The PCM constantly monitors the information from various sensors, and controls the systems that affect vehicle performance.

The PCM performs the diagnostic function of the system. It can recognize operational problems, alert the driver through the Malfunction Indicator Light (MIL) and store a Diagnostic Trouble Code (DTC) or DTC(s) which identify the problem areas to aid the technician in making repairs. The PCM is designed to process the various input informations and then send the necessary electrical responses to control fuel delivery, spark timing and other emission control systems. The input information has an interrelation to more than one output therefore, if the one input failed, it could affect more than one system operation.


Refer to Driveability and Emission in Engine Section and Automatic Transmission in Transmission section.

Circuit Diagram-1 (6VD1)




D08RX018

Circuit Diagram-2 (6VD1)




Circuit Diagram-3 (6VD1)




D08RX020


Circuit Diagram-4 (6VD1)




Circuit Diagram-5 (6VD1)




Circuit Diagram-6 (6VD1)




Circuit Diagram-7 (6VD1)




Circuit Diagram-8 (6VD1)




Circuit Diagram-9 (6VD1-4WD)



Circuit Diagram-9 (6VD1-2WD)




Circuit Diagram-10 (6VD1)




Circuit Diagram-11 (6VD1)

PCM: POWERTRAIN CONTROL MODULE




Circuit Diagram-12 (6VD1)



D08RX030

Parts Location – 1 (6VD1)



D08RX031


Legend

- | | |
|----------------------------|--------------------|
| (1) Battery | (19) E-39 |
| (2) X-7, X-8 | (20) E-25 |
| (3) H-12, H-13, H-14 | (21) E-24 |
| (4) I-41, I-42 | (22) E-20 |
| (5) PCM (C-1, C-2, C-3) | (23) E-34 |
| (6) I-2 | (24) E-35 |
| (7) H-15, H-17, H-31, H-32 | (25) E-30 |
| (8) F-1 | (26) E-8 |
| (9) H-25 | (27) E-14 |
| (10) I-43 | (28) E-13 |
| (11) C-16 | (29) E-33 |
| (12) H-9, H-10, H-11 | (30) E-5 |
| (13) C-37 | (31) E-43 |
| (14) E-27 | (32) E-42 |
| (15) E-26 | (33) E-41 |
| (16) E-37 | (34) E-40 |
| (17) E-38 | (35) H-4, H-5, H-6 |
| (18) E-7 | (36) E-6 |
| | (37) E-12 |

(38) E-4
(39) E-32
(40) E-11

(41) E-36
(42) E-28

Parts Location – 2 (Transmission control)




D08RX032

Legend

(1) M-10	(11) H-25
(2) M-20	(12) C-34
(3) E-5	(13) H-15
(4) B-11	(14) M-10
(5) B-24	(15) M-15
(6) B-8	(16) M-7
(7) B-13, B-14	(17) M-16
(8) I-2	(18) M-6
(9) I-9	(19) M-17
(10) F-3	(20) M-18
	(21) H-9


Circuit Diagram-1 (X22SE)



Circuit Diagram-2 (X22SE)




Circuit Diagram-3 (X22SE)




D08RX035


Circuit Diagram-4 (X22SE)




Circuit Diagram-5 (X22SE)




Circuit Diagram-6 (X22SE)




Circuit Diagram–7 (X22SE)



Circuit Diagram-8 (X22SE)




Circuit Diagram-9 (X22SE)




Circuit Diagram-10 (X22SE)

PCM: POWERTRAIN CONTROL MODULE



Parts Location



D08RX043

Legend

(1) X-7, X-8	(19) E-5
(2) X-11, X-12	(20) E-6
(3) C-36	(21) E-12
(4) H-13, H-14, H-19	(22) E-33
(5) I-41, I-42	(23) E-25
(6) C-1, C-2, C-3 (PCM)	(24) E-11
(7) C-37	(25) E-26
(8) I-1	(26) E-32
(9) I-2, I-9	(27) E-43
(10) F-3	(28) E-9
(11) F-1	(29) E-4
(12) E-1	(30) E-3
(13) E-14	(31) H-6
(14) E-27	(32) H-5
(15) E-7	(33) H-4
(16) E-28, E-30	(34) H-25
(17) E-37	(35) C-16
(18) E-8	(36) B-8
	(37) M-14

8D-78 WIRING SYSTEM

(38) M-13
(39) C-11
(40) M-10

(41) C-35
(42) H-8


Headlight and Fog Light

General Description


The circuit consists of headlight, fog light, lighting switch, dimmer-passing switch, fog light switch, high beam indicator, lighting relay and fog light relay. When lighting switch is turned on by setting it at headlight position, lighting relay is activated to turn on headlight. Optical axis of headlight can be turned up or down by operating dimmer switch while headlight is on. Passing switch is independent of lighting switch, and optical axis of passing light can be turned up only while switch lever is pulled up and held in this state.

When fog light switch is turned on while headlight on at low-beam, fog light relay is activated to turn on fog light.

Circuit Diagram-1




Circuit Diagram-2



D08RW008

Parts Location



D08RW107

Legend

- | | |
|---------------------------|----------------------|
| (1) X-1, X-2 | (10) H-32 |
| (2) C-36 | (11) C-16 |
| (3) H-14 | (12) C-22 |
| (4) B-8 | (13) Fog Light - LH |
| (5) Lighting SW | (14) C-21 |
| (6) I-10 | (15) Head Light - LH |
| (7) I-5 | (16) C-32 |
| (8) H-17 | (17) C-17 |
| (9) I-32 (Combination SW) | (18) Fog Light - RH |
| | (19) Head Light - RH |

Diagnosis

Both Headlights Inoperative

Step	Action	Value(s)	Yes	No
1	Check the ground terminal B-8. B-8 grounded securely?	—	Go to Step 2	Ground it securely
2	Disconnect the combination switch connector I-32. Is there continuity between SW connector terminals?	—	Go to Step 3	Repair or replace the combination sw
3	Is there continuity between lighting relay connector terminals?	—	Go to Step 4	Reinstall or replace the lighting relay
4	Check voltage between connector X-1 terminals 5 and 2 ground. Is there open circuit between battery positive terminal and lighting relay?	—	Go to Step 5	Repair open circuit
5	Check voltage between connector I-32 terminal 10 ground. Is there open circuit between lighting relay and lighting sw?	—	Go to Step 6	Repair open circuit or connector contact
6	Check continuity between connector I-32 terminal 2 and 4 ground. Is there open circuit?	—	Repair open circuit or connector contact	—

Headlight On The Left (or Right) Side Inoperative

Step	Action	Value(s)	Yes	No
1	Is the fuse (10A) (or 15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the headlight bulb on the left (or right) side normal?	—	Go to Step 3	Replace the bulb
3	Repair a poor connection at the connectors or an open circuit between fuse (10A) and C-21 terminal 3 (or fuse (10A) and C-22 terminal 3) Is the action complete?	—	Verify repair	—

Headlights In Low-Beam Inoperative

Step	Action	Value(s)	Yes	No
1	1. Remove the connector dimmer-passing sw (combination sw). 2. Set the switch at the low-beam position. Is there continuity between the sw connector I-32 terminals 5 and 15?	—	Go to Step 2	Repair or replace the dimmer-passing sw
2	Repair poor connection at the connectors or an open circuit between I-32 terminal 5 and H-14 terminal 15. Is the action complete?	—	Verify repair	—

Headlight In High-Beam Inoperative

Step	Action	Value(s)	Yes	No
1	1. Disconnect the connector of the dimmer-passing sw (combination sw). 2. Set the switch at the high-beam position. With the switch at the high-beam, is there continuity between the sw connector I-32 terminals 1 and 4?	—	Go to Step 2	Repair or replace the dimmer-passing sw
2	Repair poor connection at the connectors or a broken wire between connector I-32 terminals 1 and H-14 terminals 14. Is the action complete?	—	Verify repair	—

Headlights Remain On When Lighting Switch Turned Off

Step	Action	Value(s)	Yes	No
1	Is the lighting relay normal?	—	Go to Step 2	Replace the lighting relay
2	1. Disconnect the connector of the lighting sw. 2. With the lighting switch at off position. Is there continuity between the lighting switch connector I-32 terminal 2 and 9?	—	Replace the lighting switch	Repair an open circuit between the lighting relay and the lighting switch

Headlight Comes On With Lighting Switch At Parking Light Position

Step	Action	Value(s)	Yes	No
1	1. Disconnect the connector of the lighting sw. 2. Set the switch at the parking light position. Is there continuity between connector I-32 terminals 2 and 9?	—	—	Repair or replace the dimmer-passing sw

(While Headlight Is On In Low-Beam) Both Fog Lights Inoperative

Step	Action	Value(s)	Yes	No
1	Is fuse (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the fog light relay normal?	—	Go to Step 3	Replace the fog light relay
3	1. Remove the fog light sw. 2. Set the switch at the fog light position. Is there continuity between the sw connector I-5 terminals 3 and 4?	—	Go to Step 4	Repair or replace the fog light sw
4	Is the battery voltage applied between the fog light sw harness side connector I-5 terminal 3 and ground?	—	Go to Step 5	Repair a poor connection at the connectors or an open circuit between fuse (15A) and connector X-2 terminals 4 and 2 or connector I-5 terminal 3
5	Repair a poor connection at the connectors or an open circuit between connector I-5 terminal 4 and connector H-26 terminal 16. Is the action complete?	—	Verify repair	—

(While Headlight Is On In Low-Beam) Fog Light On the Left (or Right) Side Inoperative

Step	Action	Value(s)	Yes	No
1	Is the fog light bulb normal?	—	Go to Step 2	Replace the bulb
2	Repair a poor connection at the connectors or an open circuit between connector C-22 terminal 2 and C-16 terminal (or connector C-17 terminal 2 and C-36 terminal). Is the action complete?	—	Verify repair	—

NOTE: Connectors in parenthesis "()" indicates the check point of the fog light-RH.


Front Side Marker Light, Parking Light, Tail Light and License Plate Light

General Description

The circuit consists of lighting switch, front side marker light, tail light and license plate light.


All these lights come on when lighting switch is turned on with the switch to either parking or headlight position.

Circuit Diagram-1




D08RW012

Circuit Diagram-2



D08RW013

Parts Location



D08RW108

Legend

- | | |
|-------------------------|---------------------------------|
| (1) H-19 | (10) I-32, I-34 |
| (2) B-9 | (11) H-32 |
| (3) Tail Light - RH | (12) H-30 |
| (4) License Plate Light | (13) B-6, B-8 |
| (5) G-8 | (14) C-23 |
| (6) Tail Light - LH | (15) FRT Combination Light - LH |
| (7) B-13 | (16) H-25 |
| (8) H-23 | (17) C-31 |
| (9) H-27 | (18) FRT Combination Light - RH |

Diagnosis

Both Tail Lights Inoperative

Step	Action	Value(s)	Yes	No
1	Is fuse (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the tail relay normal?	—	Go to Step 3	Replace the tail relay
3	Is B-8 terminal ground securely?	—	Go to Step 4	Ground B-8 terminal securely
4	Remove the connector of the lighting switch. Is there continuity between I-32 terminals 3 and 2 when the switch is turned to parking or headlight position?	—	Go to Step 5	Repair or replace the lighting switch
5	Is the battery voltage applied between the harness side connectors I-32 terminal 3 and the ground?	—	Go to Step 6	Repair a poor connection at the connectors or an open circuit between fuse (15A) and I-32 terminal 3
6	Repair a poor connection at the connectors or an open circuit between I-34 terminal 1 and H-25 terminal 14 or B-13 terminal 4 (B-9 terminal 4 and B-8 terminal) Is the action complete?	—	Verify repair	—

Tail Light On The Left (or Right) Side Inoperative

Step	Action	Value(s)	Yes	No
1	Is the taillight bulb on the left (or right) side normal?	—	Go to Step 2	Replace the bulb
2	Is there continuity between H-25 terminal 14 and B-13 terminal 13 (B-9 terminal 3)?	—	—	Repair a poor connection of the connectors or an open circuit in the circuit.
3	Repair a poor connection of the connectors or an open circuit between B-13 terminal 4 (B-9 terminal 4) and B-8 terminal. Is the action complete?	—	Verify repair	—

NOTE: Connectors in parenthesis "()" indicates the check point of the taillight on the right side.

Both Front Side Marker Lights Inoperative

Step	Action	Value(s)	Yes	No
1	Is fuse (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the tail relay normal?	—	Go to Step 3	Replace the tail relay
3	Is B-8 terminal (B-6 terminal) grounded securely?	—	Go to Step 4	Ground B-8 terminal (B-6 terminal) terminal securely
4	Remove the connector of the lighting switch. Is there any continuity between I-32 terminals and 2 when the switch is turned to parking or headlight position?	—	Go to Step 5	Repair or replace the lighting switch
5	Is the battery voltage applied between the harness side connector I-32 terminal 3 and the ground?	—	Go to Step 6	Repair a poor connection at the connectors or an open circuit between fuse I-34 terminal 3 and I-32 terminal 3
6	Repair a poor connection at the connectors or an open circuit between I-34 terminal 1 and H-19 terminal 6, or B-8 terminal and (I-31 terminal 4 and B-6 terminal). Is the action complete?	—	Verify repair	—

Front Side Marker Light On The Left (or Right) Side Inoperative

Step	Action	Value(s)	Yes	No
1	Is the front side marker light bulb on the left (or right) side normal?	—	Go to Step 2	Replace the bulb
2	Is there continuity between H-19 terminal 6 and C-32 terminal 3 (C-31 terminal 3)?	—	Go to Step 3	Repair a poor connection at the connectors or an open circuit in the circuit
3	Repair a poor connection at the connectors or an open circuit between C-23 terminal (C-31 terminal 4) and B-8 terminal (B-6 terminal). Is the action complete?	—	Verify repair	—

NOTE: Connectors in parenthesis "()" indicates the check point of the taillight on the right side.

License Plate Light Inoperative

Step	Action	Value(s)	Yes	No
1	Is the tail light normal?	—	Go to Step 2	Repair the taillight (refer to diagnosis «both taillights inoperative» in this section)
2	Is the license plate light bulb normal?	—	Go to Step 3	Replace bulb
3	Is B-8 terminal?	—	Go to Step 4	Ground it securely
4	Is the battery voltage applied between G-8 terminal 2 and the ground?	—	Go to Step 5	Repair a poor connection at the connectors or an open circuit in the circuit.
5	Repair a poor connection at the connectors or an open circuit between G-8 terminal 1 and B-8 terminal. Is the action complete?	—	Verify repair	—

Interior Illumination Light


General Description

The circuit consists of lighting switch, tail relay, illumination controller and illumination lights.


All these lights come on when lighting switch is turned on with the switch to either parking or headlight position.

The brightness of illumination lights except the ones for ashtray and glove box, can be adjusted by illumination controller.

Circuit Diagram-1




Circuit Diagram-2




D08RW040

Circuit Diagram-3




Circuit Diagram-4



D08RW042

Parts Location



D08RW106

Legend

- | | |
|----------|-----------------|
| (1) I-33 | (11) I-5 |
| (2) L-5 | (12) I-6 |
| (3) I-11 | (13) I-19 |
| (4) I-27 | (14) I-7 |
| (5) I-17 | (15) I-32, I-34 |
| (6) I-16 | (16) B-8 |
| (7) I-1 | (17) I-15 |
| (8) I-2 | (18) H-25 |
| (9) I-9 | (19) I-40 |
| (10) L-4 | (20) B-24 |


Turn Signal Light, Hazard Warning Light

General Description


The circuit consists of turn signal/cornering switch (combination switch) turn signal light, hazard warning switch and flasher unit. When turn signal light switch is turned on with starter switch on, turn signal light will operate. When turn signal light is flashing, indicator light in meter also starts flashing. When hazard warning switch is turned on, current flows to flasher unit through hazard warning switch to cause hazard warning light to flash independent of position of starter switch. At the same time, indicator lights in meter also start flashing.


When turn signal lever is set in either left or right direction while headlight is on, incorporated into combination switch is activated to illuminate.

Circuit Diagram-1




Circuit Diagram-2





Parts Location



D08RW110

Legend

- | | |
|--------------------------------|---------------------------------|
| (1) FRT Turn Signal light – RH | (9) H-23 |
| (2) C-36 | (10) Relay & Fuse Box |
| (3) H-14, H-19 | (11) H-32 |
| (4) B-9 | (12) I-32, I-47 |
| (5) RR Turn Signal light – RH | (13) C-16 |
| (6) I-2 | (14) C-23 |
| (7) RR Turn Signal light – LH | (15) FRT Turn Signal light – LH |
| (8) B-13 | (16) B-8 |
| | (17) C-18 |

Diagnosis

Turn Signal Light Does Not Flash

Step	Action	Value(s)	Yes	No
1	Is fuse (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the flasher unit normal?	—	Go to Step 3	Replace the flasher unit
3	1. Disconnect the connectors of the hazard warning switch. 2. Turn the starter switch on. Is the battery voltage applied between the hazard warning switch harness side connector I-11 terminals 3 and the ground?	—	Go to Step 4	Repair poor connection at the connectors or an open circuit between the fuse (15A) and I-11 terminals 3
4	Set the hazard warning switch turned off. Is there continuity between the switch I-11 terminals 4 and 3?	—	Go to Step 5	Repair or replace the switch
5	Disconnect the connectors of the flasher unit. Is the battery voltage applied between the flasher unit harness side connector I-47 terminal 2 and the ground?	—	Go to Step 6	Repair a poor connection at the connectors or an open circuit between the harness side connectors I-11 terminal 3 and I-47 terminal 2
6	Is B-8 terminal ground securely?	—	Go to Step 7	Ground it securely
7	Is there continuity between the harness side I-47 terminal 2 and B-8 terminal?	—	Go to Step 8	Repair a poor connection at the connectors or an open circuit between I-47 terminal 2 and B-8 terminal
8	Disconnect the connectors at the turn signal light switch. Is there continuity between the switch connectors I-32 terminal 6 and 7 (when turning to the left), and between I-32 terminal 6 and 8 (when turning to the right)?	—	Go to Step 9	Repair or replace the switch
9	Repair a poor connection of the connectors or an open circuit between the harness side connectors I-47 terminal 1 and I-32 terminal 6. Is the action complete?	—	Verify repair	—

Turn Signal Light Flashes Too Quickly

Reinstall or replace the bulb, repair an open circuit in the circuit, or the ground connection.

Hazard Warning Lights Does Not Flash

Step	Action	Value(s)	Yes	No
1	Is fuse (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the hazard warning switch normal?	—	Go to Step 3	Replace the hazard warning switch
3	Repair a poor connection of the connectors or an open circuit between the harness side connectors I-11 terminal 5 and 14 fuse (15A) Is the action complete?	—	Verify repair	—

Stoplight


General Description

The circuit consists of stoplight, high mounted stoplight and stoplight switch or brake switch.

With brake pedal depressed, stoplight switch or brake switch is turned to on to illuminate stoplight.


Brake switch controls not only the operation of stoplight but also the input of cruise cancel signals to cruise control unit.

Circuit Diagram



D08RW038

Parts Location



D08RW111

Legend

- (1) Stop light SW
- (2) I-18
- (3) B-9
- (4) Stop light - RH
- (5) H-21
- (6) G-10, G-11

- (7) High Mounted Stop Light
- (8) Stop light - LH
- (9) B-13
- (10) H-23
- (11) H-32
- (12) B-6, B-8

Diagnosis

Both Stoplights Inoperative

Step	Action	Value(s)	Yes	No
1	Is fuse 6 (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is B-8 terminal ground securely?	—	Go to Step 3	Replace the securely
3	Is the battery voltage applied I-18 terminal 1 of the stoplight sw?	—	Go to Step 4	Repair poor connection at connectors or an open circuit between the fuse 6 (15A) and I-18 terminal 1
4	Remove the stoplight sw. Is there continuity between I-18 terminal 1 and 4 of the switch when push rod is out?	—	Go to Step 5	Replace the stoplight sw
5	Does the push rod of the stoplight sw operate smoothly?	—	Go to Step 6	Replace the stoplight sw
6	Repair a poor connection of connectors or an open circuit between I-18 terminal 4 and H-32 terminal 7. Is the action complete?	—	Verify repair	—

Stoplight On The Left (or Right) Side Inoperative

Step	Action	Value(s)	Yes	No
1	Is the stoplight bulb on the left (or right) side normal?	—	Go to Step 2	Replace the bulb
2	Is there any continuity between the stoplight connector B-13 terminal 3 (B-9 terminal 3) and H-32 terminal 7?	—	Go to Step 3	Replace a poor connection at connectors or an open circuit in the circuit
3	Repair a poor connection at connectors or an open circuit between B-13 terminal 4 (B-9 terminal 4) and B-8 terminal (B-6 terminal)? Is the action complete?	—	Verify repair	

High Mounted Stoplight Inoperative

Step	Action	Value(s)	Yes	No
1	Is B-9 terminal ground securely?	—	Go to Step 2	Ground it securely
2	Remove the high mount stoplight. Is there any continuity between the high mount stoplight connector G-11 terminal 1 and G-10 terminal 1?	—	Go to Step 3	Repair or replace the high mount stoplight
3	Is the battery voltage applied between G-11 terminal 1 and the ground when the brake pedal is depressed?	—	Go to Step 4	Repair a poor connection at the connectors or an open circuit between G-11 terminal 1 and H-21 terminal 1
4	Repair a poor connection at the connectors or an open circuit between G-10 terminal 1 and B-6 terminal. Is the action complete?	—	Verify repair	—


Backup Light

General Description


The circuit consists of backup light switch (M/T), mode switch (A/T) and backup light.

When shift lever is set to "R" position, backup light switch (M/T) or mode switch (A/T) is activated to illuminate backup light.

Circuit Diagram



Parts Location



D08RW112

Legend

- | | |
|-----------------------|----------------------|
| (1) B-9 | (6) Mode SW |
| (2) Backup Light - RH | (7) M-16 |
| (3) Backup Light - LH | (8) H-10, H-11 |
| (4) B-13 | (9) M-8, M-9 |
| (5) H-1, H-17 | (10) Backup Light SW |

Diagnosis

Both Backup Lights Inoperative

Step	Action	Value(s)	Yes	No
1	Is fuse 14 (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is B-8 terminal ground securely?	—	Go to Step 3	Replace the securely
3	Turn the starter sw on. Is the battery voltage applied between the mode sw (or backup light sw) harness side connector M-16 terminal 5 (M-8 terminal 1) and the ground?	—	Go to Step 4	Repair poor connection at connectors or an open circuit between the fuse 6 (15A) and M-16 terminal 5 or (M-8 terminal 1)
4	1. Set the transmission gear to the reverse position. 2. Disconnect the mode sw (or backup light sw) connector. Is there continuity between switch side connectors M-16 terminal 2 and 5 (M-5 terminal 1 and M-9 terminal 1)	—	Go to Step 5	Replace the stoplight sw
5	Repair a poor connection at the connectors or an open circuit between M-16 terminal 2 (M-9 terminal 1) and H-15 terminal 12)	—	—	Replace the stoplight sw

NOTE: Connectors in parenthesis “()” indicates the model with manual transmission.

Backup Light On The Left (or Right) Side Inoperative

Step	Action	Value(s)	Yes	No
1	Is the backup light bulb on the left (or right) side normal?	—	Go to Step 2	Replace the bulb
2	Is there any continuity between the backup light harness side connectors B-13 terminal 5 (B-9 terminal 5) and H-15 terminal 12?	—	Go to Step 3	Replace a poor connection at connectors or an open circuit in the circuit
3	Repair a poor connection at connectors or an open circuit between backup light harness side connector B-13 terminal 4 (B-9 terminal 4) and B-8 terminal (B-6 terminal) Is the action complete?	—	Verify repair	—

NOTE: Connectors in parenthesis “()” indicates the model with manual transmission.

Backup Lights Remain On

Step	Action	Value(s)	Yes	No
1	Repair or replace the mode sw (backup light sw) Is the action complete?	—	Verify repair	—


Horn

General Description


The circuit consists of horn (high note), horn (low note), horn relay and horn switch.

When horn switch is pushed, (independent of position of starter switch) horn relay is activated to sound horns.

Circuit Diagram



Parts Location



D08RX120

Legend

- | | |
|--------------------------------|----------------------|
| (1) H-14 | (5) I-32 |
| (2) I-41, I-42 | (6) Horn (Low note) |
| (3) Alarm & Relay Control Unit | (7) C-14 |
| (4) Horn Switch | (8) C-12 |
| | (9) Horn (High note) |

Diagnosis

Horn Do Not Sound

Step	Action	Value(s)	Yes	No
1	Is the fuse 2 normal?	—	Go to Step 2	Replace the fuse
2	Remove the horn relay. Is the battery voltage applied between horn relay harness side connector I-41 terminal 2 or connector I-42 terminal 2 and the ground?	Approx. 12V	Go to Step 4	Go to Step 3
3	Repair an open circuit between the fuse 2 and connector I-41 terminal 2 or connector I-42 terminal 2. Is the action complete?	—	Go to Step 2	—
4	Connect the battery positive terminal with the horn relay side connector I-41 terminal 2 or connector I-42 terminal 2 and the negative terminal with connector I-42 terminal 20 or 15. Is there continuity between horn relay side connector I-41 terminal 2 and 1 or connector I-42 terminal 2 and connector I-41 terminal 4?	—	Go to Step 5	Replace the relay
5	1. Disconnect the horn switch connector I-49. 2. Press the horn switch. Is there continuity between the switch side connector I-49 terminal 1 and the ground?	—	Go to Step 6	Repair or replace the switch
6	Is there continuity between harness side connector I-42 terminal 20 or 15 and harness side connector I-49 terminal 1?	—	Go to Step 8	Go to Step 7
7	Repair an open circuit between connector I-42 terminal 20 or 15 and connector I-49 terminal 1. Is the action complete?	—	Verify repair	—
8	Repair an open circuit between the horn relay and the horns. Is the action complete?	—	Verify repair	—

Horn Do Not Shut Off

Step	Action	Value(s)	Yes	No
1	Disconnect the horn connector C-12 or C-14. Is the battery voltage applied between harness side connector C-12 or C-14 terminal 1 and the ground?	Approx. 0V	Replace the relay	Go to Step 2
2	Disconnect the horn switch connector I-49. Is there continuity between switch side connector I-49 terminal 1 and the ground?	—	Repair or replace the switch	Go to Step 3
3	Repair a short circuit between the horn relay and the horn switch. Is the action complete?	—	Verify repair	—

Dome Light, Luggage Room Light, Courtesy Light, Map Light, Seat Belt Switch and Warning Buzzer

General Description

The circuit consists of door switch, dome light, luggage room light, courtesy light, map light seat belt switch, seat belt warning light, key cylinder switch and alarm & relay control unit.

Dome light comes on with dome light switch turned to door position and any door open.


The buzzer sounds when starter switch is turned to either "ACC" or "OFF" position and FRT door-LH, is opened with lighting switch on.

The buzzer sounds when FRT door-LH is opened with starter key left in starter switch key cylinder.

The buzzer also sounds when starter switch is turned to "ON" position with seat belt unfastened.


These functions are controlled by alarm & relay control unit.

Circuit Diagram-1 (M/T)




D08RX053


Circuit Diagram-1 (A/T)



Circuit Diagram-2 (M/T)




Circuit Diagram-2 (A/T)




D08RX056

Circuit Diagram-3



Parts Location



D08RX063

Legend

- | | |
|--------------------------|-----------------------------|
| (1) I-41, I-42 | (19) RR Courtesy-Light-LH |
| (2) FRT Door SW-RH | (20) H-24 |
| (3) B-1 | (21) FRT Door SW-LH |
| (4) D-29 | (22) H-30 |
| (5) RR Courtesy-Light-RH | (23) FRT Door SW-LH |
| (6) B-21 | (24) D-7 |
| (7) RR Door SW-RH | (25) H-28 |
| (8) Map Light | (26) H-31, H-32 |
| (9) L-2 | (27) I-34, I-44, I-45, I-46 |
| (10) Dome Light | (28) H-22 |
| (11) L-3 | (29) I-1 |
| (12) B-11 | (30) B-8 |
| (13) Luggage Room Light | (31) B-22 |
| (14) G-1 (LWB) | (32) H-29 |
| (15) Tail Gate Harness | (33) FRT Courtesy-Light-RH |
| (16) H-22 | (34) D-18 |
| (17) RR Door SW-LH | (35) H-33 |
| (18) B-16 | (36) H-19 |

Power Door Lock


General Description

The door lock system consists of door lock switch and door lock actuator. Door lock switch on driver's side can actuate the door lock mechanism.

Locking or unlocking the lock switch on the driver side causes the door lock mechanism to be locked or unlocked.

At this time, the current flows for approx. 1 second from door lock switch on driver's side to door lock actuator to run the motor.


Circuit Diagram-1




D08RX064




Circuit Diagram (With Anti-Theft)-1



Circuit Diagram (With Anti-Theft)-2



Parts Location



D08RX068

Legend

- | | |
|----------------------------------|---------------------------------|
| (1) H-33 | (12) G-7 |
| (2) D-14 | (13) Door Lock Actuator (RR LH) |
| (3) Door Lock Actuator (FRT RH) | (14) H-34 |
| (4) I-26 | (15) D-23 |
| (5) H-29 | (16) H-24 |
| (6) Door Lock Switch (FRT RH) | (17) D-5, D-6 |
| (7) D-17 | (18) Door Lock Switch (FRT LH) |
| (8) D-28 | (19) D-8 |
| (9) Door Lock Actuator (RR RH) | (20) H-28 |
| (10) I-4 | (21) H-31, H-32 |
| (11) Door Lock Actuator (FRT LH) | (22) B-8 |

Diagnosis

All The Doors Do Not Lock And Unlock By Door Lock SW-LH

Step	Action	Value(s)	Yes	No
1	Is the fuse 7 normal?	—	Go to Step 2	Replace the fuse
2	Is B-8 grounded securely?	—	Go to Step 3	Ground it securely
3	Disconnect the front door lock and power window switch-LH connector D-5. Is there continuity between harness side connector D-5 terminal 7 and the ground B-8?	—	Go to Step 5	Go to Step 4
4	Repair an open circuit between connector D-5 terminal 7 and the ground B-8. Is the action complete?	—	Go to Step 3	—
5	Is the battery voltage applied between harness side connector D-5 terminal 11 and the ground?	Approx. 12V	Go to Step 7	Go to Step 6
6	Repair an open circuit between the fuse 7 and connector D-5 terminal 11. Is the action complete?	—	Verify repair	—
7	Replace the front door lock & power window switch-LH. Is the action complete?	—	Verify repair	—

All The Doors Do Not Get Locked (Or Unlocked) By FRT Door Lock SW-RH

Step	Action	Value(s)	Yes	No
1	Is B-8 grounded securely?	—	Go to Step 2	Ground it securely
2	Disconnect the front door lock and power window switch-RH connector D-17. Is there continuity between harness side connector D-17 terminal 3 and the ground B-8?	—	Go to Step 4	Go to Step 3
3	Repair an open circuit between connector D-17 terminal 3 and the ground B-8. Is the action complete?	—	Go to Step 2	—
4	Is there continuity between the front door lock & power window switch-RH side connector D-17 terminal 7 and 3 with the switch turned to unlock position, and terminal 6 and 3 with the switch turned to lock position?	—	Go to Step 5	Replace the switch
5	Repair an open circuit between the front door lock and power window switch-LH and the front door lock and power window switch-RH. Is the action complete?	—	Verify repair	—

Door Lock Does Not Operate By Door Lock Key SW-LH

Step	Action	Value(s)	Yes	No
1	Disconnect the door lock key switch-LH connector D-6. Is there continuity between switch side connector D-6 terminal 4 and 3 with the switch turned to the lock side, and switch side connector D-6 terminal 1 and 3 with the switch turned to the unlock side?	—	Go to Step 2	Repair or replace the switch
2	Is there continuity between harness side connector D-6 terminal 3 and the ground B-8?	—	Go to Step 4	Go to Step 3
3	Repair an open circuit between connector D-6 terminal 3 and the ground B-8. Is the action complete?	—	Verify repair	—
4	Repair an open circuit between connector D-5 terminal 9 and connector D-6 terminal 4, and connector D-5 terminal 6 and connector D-6 terminal 1. Is the action complete?	—	Verify repair	—

Power Window


General Description

The power window system consists of power window switches and power window motors on driver and passenger sides and power window relay.

With the starter switch in "ON" position, the battery voltage is supplied through power window relay to the power window switches on driver and passenger sides. Selection of up or down switch changes over the motor rotating direction to open or close the window.


When the lock switch on the switch panel on the driver side is pressed, the power window switch is in open state. As a result, the power source to the other switches are cut off, and the power window motors do not run.

Circuit Diagram-1



D08RW318

Parts Location



D08RW074

Legend

- | | |
|---------------------------------|----------------------------------|
| (1) H-33 | (13) Power Window SW (RR LH) |
| (2) D-11 | (14) D-22 |
| (3) Power Window Motor (FRT RH) | (15) D-20 |
| (4) Power Window SW (FRT RH) | (16) Power Window Motor (RR LH) |
| (5) D-17 | (17) H-24 |
| (6) Power Window Motor (RR RH) | (18) D-5 |
| (7) D-25 | (19) D-2 |
| (8) D-27 | (20) Power Window Motor (FRT LH) |
| (9) Power Window SW (RR RH) | (21) H-32 |
| (10) Starter SW | (22) H-28 |
| (11) H-14 | (23) I-35 |
| (12) Power Window SW (FRT LH) | (24) Power Window Relay |
| | (25) H-29 |

Diagnosis

All Window Do Not Operate

Step	Action	Value(s)	Yes	No
1	Is fuse (15A) normal?	—	Go to Step 2	Replace the fuse
2	Is the circuit breaker C/B-1 (30A) normal?	—	Go to Step 3	Replace the circuit breaker
3	Are connector B-8 terminal ground securely?	—	Go to Step 4	Ground them securely
4	Is the power window relay normal?	—	Go to Step 5	Replace the relay
5	Is the battery voltage applied between connector I-35 terminal 2 and the ground?	—	Go to Step 6	Repair a poor connection at the connectors or an open circuit between connector I-35 terminal 2
6	Turn the starter sw ON. Is the battery voltage applied between connector I-35 terminal 3 and the ground?	—	Go to Step 7	Repair a poor connection at the connectors or an open circuit between fuse (15A) and connector I-35 terminal 2
7	Is the battery voltage applied between connector D-5 terminal 4 and the ground?	—	Go to Step 8	Repair a poor connection at the connectors or an open circuit between connector I-35 terminal 1 and D-5 terminal 4

8D-138 WIRING SYSTEM

Step	Action	Value(s)	Yes	No
8	Is the battery voltage applied between connector B-8 terminal and the ground?	—	Go to Step 9	Repair a poor connection at the connectors or an open circuit between connector D-5 terminal 7 and B-8 terminal or connector I-35 terminal 4 and B-8 terminal
9	Replace the driver side power window (& door lock) switch. Is the action complete?	—	Verify repair	—

Lock SW Does Not Function

Repair or replace the power window sw on the drivers side.

Window On The Drivers Side Does Not Operate

Step	Action	Value(s)	Yes	No
1	Start checking the items for "All windows do not operate" in this section. Is there any defective part?	—	Go to Step 2	Repair or replace the defective parts
2	Disconnect the connector of the driver side power window (& door lock) switch. Connect the connectors D-5 terminal 3 to the battery (+) terminal, and D-5 terminal to the (–) terminals. Does the motor rotate in the "up" direction of the window?	—	Go to Step 3	Repair a poor connection at connectors
3	Connect the D-5 terminal 5 to the (+) terminal and D-5 terminal 3 to the (–) terminal. Does the motor rotate in the "down" direction of the window?	—	—	Repair a poor connection at connectors

Window On The Front Passenger's Side Does Not Operate

Step	Action	Value(s)	Yes	No
1	Is the driver side window operation normal?	—	Go to Step 2	Refer to "window on the driver side does not operate" in this diagnosis for repair
2	1. Disconnect the connector of the front passenger's power window (& door lock) switch 2. Connect the connector D-17 terminal 1 to the battery (+) terminal, and D-17 terminal 4 to the (–) terminal. Does the motor rotate in the "up" direction of the window?	—	Go to Step 3	Repair a poor connection at connectors
3	Connect the D-17 terminal 4 to the (+) terminal and D-17 terminal 1 to the (–) terminal. Does the motor rotate in the "down" direction of the window?	—	—	Repair a poor connection at connectors

Rear Window On The Left (Or Right) Side Does Not Operate

Step	Action	Value(s)	Yes	No
1	Is the driver side window operation normal?	—	Go to Step 2	Refer to “window on the driver side does not operate” in this diagnosis for repair
2	1. Disconnect the connector of the rear left (or right) side power window switch. 2. When connecting the connector D-22 terminal 5 (D-27 terminal 5) to the battery (+) terminal, and D-22 terminal 6 (D-22 terminal 6) to the (–) terminal. Does the motor rotate in the “up” direction of the window?	—	Go to Step 3	Repair a poor connection at connectors
3	Connect the D-22 terminal 6 (D-27 terminal 5) to the battery (+) terminal, and D-22 terminal 6 (D-22 terminal 6) to the (–) terminal. Does the motor rotate in the “down” direction of the window?	—	—	Repair a poor connection at connectors

Cruise Control

General Description

The circuit consists of cruise control unit, cruise main switch, combination switch clutch switch (M/T), mode switch (A/T), brake switch, actuator and indicator lights. Cruise control system keeps the vehicle running at a fix speed until a signal canceling this fixed speed is received. When the cruise main switch is turned on with the vehicle in the running mode, the battery voltage is applied to the control unit.

When a signal from the combination switch is input to the control unit while vehicle is in this state, the actuator is activated to operate the system. Also, while the system is operating, the cruise indicator light in the meter panel lights up.

Set Function

When the cruise main switch turned on and the set switch is depressed with the vehicle speed within the set limit and cancel operation is refused the vehicle speed when the set switch is released is stored in the control unit as the set speed. But in case of the vehicle speed is over maximum limit speed of cruise control, maximum limit speed in the control unit is stored as the set speed.

Resume Function

Unless the vehicle speed falls below the minimum speed limit after canceling the set speed by the cancel switch, pushing the resume switch causes the vehicle to resume the speed before cancellation.

Acceleration Function

During cruise control driving, pushing the acceleration switch (on time is more than 0.6 sec.) causes an increase in cruise speed and vehicle accelerates at a controlled

rate until acceleration switch released. Vehicle speed at the acceleration switch released plus 1.0 km/h is stored in the control unit as the set speed.

Tap up Function

During cruise control driving, pushing the coast switch (on time is more than 0.6 sec.) causes a decrease in cruise speed and the vehicle decelerate at a controlled rate until coast switch released. Vehicle speed at the coast switch released ,minus 1.0 km/h is stored in the control unit as the set speed.

Tap down Function

During cruise control driving, the set speed can be lowered 1.6 km/h each time by operating the coast switch quickly within 0.6 sec.

Cancel Function

During cruise control driving, the cruise control is released if the control unit receives a signal from the cancel switch, mode switch, clutch switch or brake switch. But the set speed is not erased.


Down Cancel Function

The cruise control is canceled when the vehicle speed becomes the set speed minus 20 km/h during the cruise control working and the set speed is erased.

Over Drive (OD) Cancel Function


OD cancel function is required when the vehicle speed becomes the set speed minus 3 km/h during the cruise control working. OD cancel function is enabled when the acceleration function and/or resume function are working except the vehicle speed is in more than 120 km/h.

Circuit Diagram-1




D08RX070

Circuit Diagram-2



Parts Location



D08RX069

Legend

- | | |
|----------------------------|-----------------------------|
| (1) Cruise Pump & Actuator | (12) I-18 |
| (2) C-26 | (13) I-6 |
| (3) H-12 | (14) I-14 |
| (4) H-19 | (15) H-15, H-16, H-31, H-32 |
| (5) (PCM) C-3 | (16) Clutch Switch |
| (6) Cruise Control Unit | (17) Brake Switch |
| (7) B-18 | (18) M-10 |
| (8) I-31 | (19) Mode Switch |
| (9) I-9 | (20) M-16 |
| (10) I-46 | (21) H-10 |
| (11) Starter SW | (22) B-8 |
| | (23) Throttle Valve |

Diagnosis

The cruise control unit uses the cruise main indicator light and diagnosis the failure, when the control unit detects abnormality on the table below.

PART	POSSIBLE CAUSE	DETECTION PERIOD	DTC
Actuator	Motor system short circuit	Energizing motor	1-1
	Clutch system open circuit	Energizing clutch	1-2
	Clutch system open circuit	Energizing clutch	1-2
	Mechanical defect	Cruise controlling	1-3
	Close side of motor system open circuit	Cruise controlling	1-1
Cruise control unit	Close side of motor system open circuit	While starter SW on	1-4
	Clutch output abnormality	While starter SW on	1-4
Vehicle speed sensor	Signal of vehicle speed disconnection	Cruise controlling	2-1
	Signal of vehicle speed abnormality	Cruise controlling	2-1
Switch	Turning on switch at all times	While starter SW on	3-1
	Turning on switch at the same time	While starter SW on	3-1


DTC : Diagnostic Trouble Code

DTC Display Condition

1. While starter switch on and vehicle speed is 0 km/h, the DTC output begins in top priority by cancel switch turn on and off being repeated three times for 2 sec. while cruise main switch pushing on, and stops the DTC output whether vehicle speed is more than 10 km/h or the resume switch is turned on.
2. The cruise control unit outputs the DTC(s) in order from small figure of the code.
3. The header of display of DTC(s) is assumed 4 sec., and it is 2 sec. between different kind of codes.
4. The DTC(s) are erased with the starter switch turned off.


DTC Display Format

1. When no DTCs are detected. (The unit : sec.)



F08RW003

2. When two or more DTCs are detected. (The unit : sec.)



F08RW004

Diagnosis

DTC 1-1 Motor System Short Circuit

Step	Action	Value(s)	Yes	No
1	1. Turn the starter switch off. 2. Disconnect the actuator connector C-26. 3. Measure resistance between actuator side connector terminal 1 and 2. NOTE: If the control plate position is fully opened or fully closed, resistance can not be measured. Is the resistance within range specified in the value(s) column?	More than 4.2Ω	Go to Step 2	Replace the actuator
2	Measure continuity between harness side connector C-26 terminal 1 and the ground, terminal 2 and the ground, and terminals 1 and 2. Are the result same as specified in the value(s) column?	No continuity	Replace the control unit	Repair or replace the harness

DTC 1-2 Clutch System Open or Short Circuit

Step	Action	Value(s)	Yes	No
1	1. Turn the starter switch off. 2. Disconnect the actuator connector C-26. 3. Measure resistance between actuator side connector terminal 3 and 4. Is the resistance within range specified in the value(s) column?	34.7 – 42.4Ω	Go to Step 2	Replace the actuator
2	1. Disconnect the brake switch connector I-18. 2. Check continuity between switch side connector terminal 2 and 3. Is there continuity between terminals?	—	Go to Step 3	Adjust or replace the switch
3	1. Reconnect the brake switch connector I-18 2. Check continuity between harness side connector B-18 terminal 6 and I-18 terminal 3, C-26 terminal 4 and B-18 terminal 8. Is there continuity between terminals?	—	Go to Step 4	Repair open circuit
4	Check continuity between harness side connector C-26 terminal 3 and ground, C-26 terminal 4 and ground, B-18 terminals 6 and the ground. Are the results same as specified in the value(s) column?	No continuity	Replace the control unit	Repair short circuit

DTC 1-3 Mechanical Defect

Step	Action	Value(s)	Yes	No
1	1. Turn the starter switch off. 2. Disconnect the actuator connector C-26. 3. Connect the battery positive terminal to the actuator side connector terminal 3 and the battery negative terminal to terminal 4. Does the control plate move by hand?	—	Replace the actuator	Go to Step 2
2	Connect the battery positive terminal to the actuator side connector terminal 1 and 3, and the battery negative terminal to terminal 2 and 4. Do the control plate move to full open side?	—	Go to Step 3	Replace the actuator
3	Connect the battery positive terminal to the actuator side connector terminal 2 and 3, and the battery negative terminal to terminal 1 and 4. Does the control plate move to full close side?	—	Go to Step 4	Replace the actuator
4	Check continuity between harness side connector C-26 terminal 1 and B-18 terminal 7, C-26 terminal 2 and B-18 terminal 15. Is there continuity between terminals?	—	Replace the control unit	Repair or replace harness

DTC 1-4 Close Side of Motor System Open Circuit

Step	Action	Value(s)	Yes	No
1	1. Turn the starter switch off. 2. Disconnect the actuator connector C-26. 3. Measure resistance between actuator side connector terminal 1 and 2. NOTE: If the control plate position is fully opened or fully closed, resistance can not be measured. Is the resistance within range specified in the value(s) column?	More than 4.2Ω	Go to Step 2	Replace the actuator
2	Measure continuity between harness side connector C-26 terminal 2 and B-18 terminal 15, C-26 terminal 1 and B-18 terminal 7. Is there continuity between terminals?	—	Replace the control unit	Repair or replace the harness

Anti-Lock Brake System (ABS)

General Description


The circuit consists of the starter switch, stoplight switch, EHCU wheel speed sensor, ABS warning light, BRAKE warning light, and data link connector.

When the service brake is applied while in the running mode, the EHCU (Electronic Hydraulic Control Unit) judges which wheel is about to lock by using the wheel rotation speed signals sent from the three wheel speed sensors at the front wheels and rear differential. And the brake fluid pressure applied to the four wheels is controlled by the EHCU to prevent the wheels from locking.

Based on the wheel rotation speed signals input from the wheel speed sensor, the EHCU sends out signals to the hydraulic unit to increase, maintain or decrease the brake fluid pressure. The EHCU uses these signals to control the fluid pressure which is applied to the front and rear wheels.


Refer to Brake Control System in Brakes section in detail.

Circuit Diagram-1




D08RX108

Circuit Diagram-2





Parts Location



D08RX107

Legend


- | | |
|----------------------|-------------------|
| (1) Battery | (11) F-4 |
| (2) Relay & Fuse Box | (12) H-26 |
| (3) C-36 | (13) H-25 |
| (4) C-5 | (14) H-15 |
| (5) C-4 | (15) C-16 |
| (6) H-12, 13, 14 | (16) C-13 |
| (7) I-18 | (17) H-5 |
| (8) Starter Switch | (18) B-19 |
| (9) I-1 | (19) E-30 (6VD1) |
| (10) C-34 | (20) E-28 (X22SE) |
| | (21) C-33 |

A/T Shift Lock


General Description

With the starter switch in the "ON" position and the shift lever in "P" position, the shift lever cannot be shifted from "P" to another position unless the brake pedal is depressed. This is because, unless the brake pedal is depressed, the solenoid pin underneath the shift lever retracts and the link lever then locks the shift lever cam.

Circuit Diagram-1



Parts Location



D08RW076

Legend

- | | |
|--|-----------------|
| (1) Fuse & Relay Box | (9) B-13 |
| (2) H-2 | (10) H-23 |
| (3) Brake Pedal | (11) B-9 |
| (4) Brake SW (with Cruise Control), Stop Light
(without Cruise Control) | (12) Starter SW |
| (5) I-18 | (13) I-46 |
| (6) Stop Light (RR Combination Light RH) | (14) B-12 |
| (7) H-22 | (15) I-40 |
| (8) Stop Light (RR Combination Light LH) | (16) B-8 |
| | (17) H-14 |

Windshield Wiper and Washer


General Description

The system consists of a windshield wiper and washer switch, alarm & relay control unit, windshield wiper motor and windshield washer motor. With the starter switch in the "ON" position, when the windshield wiper switch is turned on ("ON" or "HI") the battery voltage is applied to the windshield wiper motor to operate the wipers.

When the "MIST" or "INT" switch is turned on, the operation of the wipers is controlled by the alarm & relay control unit. The windshield washer motor operates to squirt the washing solution when the washer switch is pressed.




Circuit Diagram-2 (A/T)



D08RX076

Parts Location



D08RX074

Legend

- | | |
|---|-----------------------------|
| (1) Windshield Washer Motor | (9) Combination Switch |
| (2) H-13 | (10) C-16 |
| (3) C-27 | (11) Relay and Fuse Box |
| (4) C-36 | (12) H-32 |
| (5) I-14, 42 | (13) I-31, I-46 |
| (6) Alarm & Relay Control Unit | (14) B-8 |
| (7) FRT Windshield Wiper, Washer Switch | (15) Windshield Motor |
| (8) Stater Switch | (16) Windshield Washer Tank |
| | (17) C-28 |

Diagnosis

Windshield Wiper Does Not Operate At Any Switch Position

Step	Action	Value(s)	Yes	No
1	Is the fuse 16 normal?	—	Go to Step 2	Replace the fuse
2	Is C-36 grounded securely?	—	Go to Step 3	Ground it securely
3	Disconnect the windshield wiper motor connector C-27. Is there continuity between harness side connector C-27 terminal 3 and the ground?	—	Go to Step 5	Go to Step 4
4	Repair an open circuit between connector C-27 terminal 3 and the ground C-36. Is the action complete?	—	Go to Step 3	
5	1. Disconnect the windshield wiper & washer switch connector I-31. 2. Turn the starter switch on. Is the battery voltage applied between harness side connector I-31 terminal 3 and the ground?	Approx. 12V	Go to Step 7	Go to Step 6
6	Repair an open circuit between the fuse 16 and connector I-31 terminal 3. Is the action complete?	—	Go to Step 5	—
7	Is the continuity between the windshield wiper and washer switch terminal normal?	—	Repair or replace the windshield wiper motor	Repair or replace the switch

Windshield Wiper Does Not Operate At "INT" Position

Step	Action	Value(s)	Yes	No
1	1. Disconnect the windshield wiper and washer switch connector I-31. 2. Turn the windshield wiper and washer switch to INT position. Is there continuity between switch side connector I-31 terminal 2 and 3, 5 and 6 and 8 and 13?	—	Go to Step 2	Repair or replace the switch
2	Is B-8 grounded securely?	—	Go to Step 3	Ground it securely
3	1. Reconnect the windshield wiper and washer switch connector I-31. 2. Disconnect the alarm and relay control unit connector I-41 and I-42. 3. Turn the starter switch on. Is the battery voltage applied between harness side connector I-42 terminal 12 or 9 and the ground?	Approx. 12V	Go to Step 5	Go to Step 4
4	Repair an open circuit between connector I-31 terminal 2 and connector I-42 terminal 12 or connector I-42 terminal 9. Is the action complete?	—	Verify repair	—
5	Is the battery voltage applied between harness side connector I-41 terminal 3 or connector I-41 terminal 25 and the ground?	Approx. 12V	Replace the alarm and relay control unit	Go to Step 6
6	Repair an open circuit between the fuse 16 and connector I-41 terminal 3 or connector I-41 terminal 25. Is the action complete?	—	Verify repair	—

Intermittent Interval Does Not Change

Step	Action	Value(s)	Yes	No
1	Disconnect the windshield wiper and washer switch connector I-31. Does the resistance value between the switch side connector I-31 terminal 8 and 13 vary within the range specified in the value(s) column while the intermittent knob is being turned?	0Ω – 2KΩ	Go to Step 2	Replace the switch
2	1. Reconnect the windshield wiper and washer switch connector I-31. 2. Disconnect the alarm and relay control unit connector I-41 and I-42. Does the resistance value between harness side connector I-42 terminal 21 or connector I-42 terminal 5 and the ground vary within the range specified in the value(s) column while the intermittent knob is being turned?	0Ω – 2KΩ	Replace the alarm and relay control unit	Go to Step 3
3	Repair a short circuit between connector I-31 terminal 8 and connector I-42 terminal 21 or connector I-42 terminal 5. Is there action complete?	—	Verify repair	—

Windshield Wiper Does Not Operate At “LO” Position

Step	Action	Value(s)	Yes	No
1	Repair or replace the windshield wiper and washer switch. NOTE: There should be continuity between switch side connector I-31 terminal 3 and 5 with the switch turned to the LOW position. Is the action complete?	—	Verify repair	—

Windshield Wiper Does Not Operate At “HI” Position

Step	Action	Value(s)	Yes	No
1	1. Disconnect the windshield wiper and washer switch connector I-31. 2. Turn the windshield wiper and washer switch to the HIGH position. Is there continuity between switch side connector I-31 terminal 3 and 4?	—	Go to Step 2	Repair or replace the switch
2	1. Reconnect the windshield wiper and washer switch connector I-31. 2. Disconnect the windshield wiper motor connector C-27. 3. Turn the starter switch on. Is the battery voltage applied between harness side connector C-27 terminal 1 and the ground?	Approx. 12V	Repair or replace the windshield wiper motor	Go to Step 3
3	Repair an open circuit between connector I-31 terminal 4 and connector C-27 terminal 1. Is the action complete?	—	Verify repair	—

Auto-Stop Function Of The Windshield Wiper Motor Does Not Operate

Step	Action	Value(s)	Yes	No
1	Disconnect the windshield wiper and washer switch connector I-31. Turn the windshield wiper and washer switch off. Is there continuity between switch side connector I-31 terminal 5 and 6?	—	Go to Step 2	Repair or replace the switch
2	Disconnect the windshield wiper motor connector C-27. Turn the starter switch on. Is the battery voltage applied between harness side connector C-27 terminal 6 and the ground?	Approx. 12V	Go to Step 4	Go to Step 3
3	Repair an open circuit between the fuse 16 and connector C-27 terminal 6. Is the action complete?	—	Go to Step 2	—
4	1. Connect the battery positive terminal with motor side connector C-27 terminal 2 and the battery negative terminal with terminal 3. 2. While the motor is operating at low speed, disconnect the battery positive terminal from terminal 2 and then connect it with terminal 6 again. 3. Under this condition, connect motor side connector terminal 5 with terminal 2. Does the motor stop at the correct position?	—	Go to Step 5	Repair or replace the motor
5	Disconnect the alarm and relay control unit connector I-41 and I-42. Is the battery voltage applied between harness side connector I-41 terminal 3 or connector I-41 terminal 25 and the ground?	Approx. 12V	Go to Step 7	Go to Step 6
6	Repair an open circuit between the fuse 16 and connector I-41 terminal 3 or connector I-41 terminal 25. Is the action complete?	—	Go to Step 5	—
7	1. Reconnect the windshield wiper and washer switch connector I-31 and windshield wiper motor connector C-27. 2. Turn the windshield wiper and washer switch to the low position. Is the battery voltage applied between harness side connector I-41 terminal 4 or connector I-42 terminal 1 and the ground?	Approx. 12V intermittently	Go to Step 9	Go to Step 8
8	Repair an open circuit between connector C-27 terminal 5 and connector I-41 terminal 4 or connector I-42 terminal 1. Is the action complete?	—	Go to Step 7	—

Step	Action	Value(s)	Yes	No
9	1. Connect the alarm and relay control unit harness side connector I-41 terminal 4 and connector I-42 terminal 11 or connector I-42 terminal 1 and 24. 2. Turn the windshield wiper and washer switch to the off position. Does the motor stop at the correct position?	—	Replace the alarm and relay control unit	Go to Step 10
10	Repair an open circuit between connector I-31 terminal 6 and connector I-42 terminal 11 or connector I-42 terminal 24. Is the action complete?	—	Verify repair	—

Windshield Wiper Motor Does Not Stop

Step	Action	Value(s)	Yes	No
1	Repair or replace the windshield wiper and washer switch. NOTE: There should be continuity between the switch side connector I-31 terminal 5 and 6 only when the switch is turned to the off position. Is the action complete?	—	Verify repair	—

Windshield Washer Motor Does Not Operate


Step	Action	Value(s)	Yes	No
1	Does the windshield wiper motor operate?	—	Go to Step 6	Go to Step 2
2	Is the fuse 16 normal?	—	Go to Step 3	Replace the fuse
3	1. Disconnect the windshield wiper and washer switch connector I-31. 2. Turn the starter switch on. Is the battery voltage applied between harness side connector I-31 terminal 1 and the ground?	Approx. 12V	Go to Step 5	Go to Step 4
4	Repair an open circuit between the fuse 16 and connector I-31 terminal 1. Is the action complete?	—	Go to Step 3	—
5	Is C-16 grounded securely?	—	Go to Step 6	Ground it securely
6	Turn the windshield wiper and washer switch to the washer position. Is there continuity between switch side connector I-31 terminal 1 and 7?	—	Go to Step 7	Repair or replace the switch
7	1. Disconnect the windshield washer motor connector C-28. 2. Connect the battery positive terminal with the motor side connector C-28 terminal 1 and connect the battery negative terminal with terminal 2. Does the motor operate?	—	Go to Step 8	Repair or replace the motor
8	1. Reconnect the windshield wiper and washer switch connector I-31. 2. Turn the starter switch on. Is the battery voltage applied between harness side connector C-28 terminal 2 and the ground?	Approx. 12V	Go to Step 10	Go to Step 9
9	Repair an open circuit between connector I-31 terminal 7 and connector C-28 terminal 1. Is the action complete?	—	Verify repair	—
10	Repair an open circuit between connector C-28 terminal 2 and the ground C-16. Is the action complete?	—	Verify repair	—

Rear Wiper/Washer

General Description


The system consists of the rear wiper and washer switch, the rear wiper motor, the rear washer motor the alarm & relay control unit and relays. The rear wiper provides intermittent and riseup functions and is controlled by the alarm & relay control unit. When the hatch gate is open, the rear wiper does not operate. The hatch gate actuator does not operate while the rear wiper is operating.

Circuit Diagram-1 (M/T)




D08RX081

Circuit Diagram-1 (A/T)





Parts Location



D08RX084

Legend

- | | |
|--------------------------------|-------------------------------|
| (1) C-30 | (8) Rear Wiper Moter |
| (2) FRT & Rear Washer Tank | (9) H-22 |
| (3) C-36 | (10) B-8 |
| (4) H-13 | (11) Rear Wiper/Washer Switch |
| (5) I-41, 42 | (12) I-16 |
| (6) Alarm & Relay Control Unit | (13) I-46 |
| (7) G-6 | (14) H-31 |

Diagnosis

Rear Wiper Motor Does Not Operate

Step	Action	Value(s)	Yes	No
1	Is the fuse 17 normal?	—	Go to Step 2	Replace the fuse
2	1. Disconnect the rear wiper/washer switch connector I-16. 2. Turn the rear wiper switch on. Is there continuity between switch side connector I-16 terminal 5 and 7?	—	Go to Step 3	Repair or replace the switch
3	Turn the starter switch on Is the battery voltage applied between harness side connector I-16 terminal 5 and the ground?	Approx. 12V	Go to Step 5	Go to Step 4
4	Repair an open circuit between the fuse 17 and connector I-16 terminal 5. Is the action complete?	—	Go to Step 3	—
5	Disconnect the alarm & relay control unit connector I-41 and I-42. Is the battery voltage applied between harness side connector I-41 terminal 12 or connector I-42 terminal 26 and the ground?	Approx. 12V	Go to Step 7	Go to Step 6
6	Repair an open circuit between the fuse 17 and connector I-41 terminal 12 or connector I-42 terminal 26. Is the action complete?	—	Go to Step 5	—
7	Is there continuity between harness side connector I-16 terminal 7 and harness side connector I-42 terminal 5 or connector I-41 terminal 15?	—	Go to Step 9	Go to Step 8
8	Repair an open circuit between connector I-16 terminal 7 and connector I-42 terminal 5 or connector I-41 terminal 15. Is the action complete?	—	Go to Step 7	—
9	1. Disconnect the rear wiper motor connector G-6. 2. Connect the battery positive terminal with the motor side connector G-6 terminal 4 and the battery negative terminal with the motor side connector G-6 terminal 6. Does the motor operate?	—	Go to Step 10	Repair or replace the motor
10	Is there continuity between harness side connector I-41 terminal 6 or connector I-42 terminal 12 and harness side connector G-6 terminal 4?	—	Go to Step 12	Go to Step 11
11	Repair an open circuit between connector I-41 terminal 6 or connector I-42 terminal 12 and connector G-6 terminal 4. Is the action complete?	—	Go to Step 10	—

Step	Action	Value(s)	Yes	No
12	Is there continuity between harness side connector I-41 terminal 5 or I-42 terminal 11 and harness side connector G-6 terminal 6?	—	Go to Step 13	Replace the alarm & relay control unit
13	Repair an open circuit between connector G-6 terminal 6 and connector I-41 terminal 5 or connector I-42 terminal 11. Is the action complete?	—	Verify repair	—

Auto-Stop Function Of The Rear Wiper Motor Does Not Operate

Step	Action	Value(s)	Yes	No
1	1. Disconnect the rear wiper motor connector G-6 2. Connect the battery positive terminal with the motor side connector G-6 terminal 4 and the battery negative terminal with terminal 6. 3. While the motor is operating, disconnect the battery positive terminal from terminal 4 and then connect it with terminal 5 again. 4. Under this condition, connect the motor side connector terminal 1 with terminal 4. Does the motor stop at the correct position?	—	Go to Step 2	Repair or replace the motor
2	Turn the start switch on Is the battery voltage applied between harness side connector G-6 terminal 5 and the ground?	Adpprox. 12V	Go to Step 4	Go to Step 3
3	Repair an open circuit between the fuse 17 and connector G-6 terminal 5. Is the action complete?	—	Go to Step 2	—
4	Disconnect the alarm & relay control unit connector I-41 and I-42. Is there continuity between harness side connector G-6 terminal 1 and harness side connector I-42 terminal 2 or connector I-42 terminal 8?	—	Replace the alarm & relay control unit	Go to Step 5
5	Repair an open circuit between connector G-6 terminal 1 and connector I-42 terminal 2 or connector I-42 terminal 8. Is the action complete?	—	Verify repair	—

Rear Wiper Motor Does Not Operate With Rear Wiper/Washer Switch At Wiper Position

Step	Action	Value(s)	Yes	No
1	1. Disconnect the rear wiper/washer switch connector I-16. 2. Turn the switch to rear wiper position. Is there continuity between the switch side connector I-16 terminal 5 and 7?	—	Go to Step 2	Repair or replace the switch
2	1. Reconnect the rear wiper/washer switch connector I-16. 2. Disconnect the alarm & relay control unit connector I-41 and I-42. 3. Turn the starter switch on. Is the battery voltage applied between harness side connector I-42 terminal 5 or connector I-41 terminal 15 and the ground?	Approx. 12V	Replace the alarm & relay control unit	Go to Step 3
3	Repair an open circuit between connector I-16 terminal 7 and connector I-42 terminal 5 or connector I-41 terminal 15. Is the action complete?	—	Verify repair	—

Rear Wiper Motor Does Not Operate With Rear Wiper/Washer Switch At Washer Position

Step	Action	Value(s)	Yes	No
1	1. Disconnect the rear wiper/washer switch connector I-16. 2. Turn the switch to the washer position. Is there continuity between the switch side connector I-16 terminal 8 and 4?	—	Go to Step 2	Repair or replace the switch
2	1. Reconnect the rear wiper/washer switch connector I-16. 2. Disconnect the alarm & relay control unit connector I-41 and I-42. 3. Turn the starter switch on. Is the battery voltage applied between harness side connector I-42 terminal 6 or connector I-41 terminal 16 and the ground?	Approx. 12V	Replace the alarm & relay control unit	Go to Step 3
3	Repair an open circuit between connector I-16 terminal 4 and connector I-42 terminal 6 or connector I-41 terminal 16. Is the action complete?	—	Verify repair	—

Rear Wiper Motor Does Not Stop Operating

Step	Action	Value(s)	Yes	No
1	1. Disconnect the rear wiper/washer switch connector I-16. 2. Turn the switch to the off position. NOTE: There should be no continuity. Is there continuity between the switch side connector I-16 terminal 5 and 7?	—	Repair or replace the switch	Replace the alarm & relay control unit

Rear Washer Motor Does Not Operate

Step	Action	Value(s)	Yes	No
1	Does the rear wiper motor operate?	—	Go to Step 6	Go to Step 2
2	Is the fuse 17 normal?	—	Go to Step 3	Replace the fuse
3	1. Disconnect the rear wiper/washer switch connector I-16. 2. Turn the switch to the rear washer position. Is there continuity between the switch side connector I-16 terminal 8 and 4?	—	Go to Step 4	Replace the switch
4	Turn the starter switch on. Is the battery voltage applied between harness side connector I-16 terminal 8 and the ground?	Approx. 12V	Go to Step 6	Go to Step 5
5	Repair an open circuit between the fuse 17 and connector I-16 terminal 8. Is the action complete?	—	Go to Step 4	—
6	1. Disconnect the rear wiper motor connector C-30. 2. Connect the battery positive terminal with the motor side connector C-30 terminal 1 and the battery negative terminal with terminal 2. Does the motor operate?	—	Go to Step 7	Repair or replace the motor
7	Reconnect the rear wiper/washer switch connector I-16. Is the battery voltage applied between harness side connector C-30 terminal 1 and the ground?	Approx. 12V	Go to Step 9	Go to Step 8
8	Repair an open circuit between connector I-16 terminal 4 and connector C-30 terminal 1. Is the action complete?	—	Verify repair	—
9	Repair an open circuit between connector C-30 terminal 2 and the ground C-36. Is the action complete?	—	Verify repair	—

Rear Defogger/Mirror Defogger


General Description

The system consists of the rear defogger and mirror defogger switch, the rear defogger, mirror defogger relay, the rear defogger, mirror defogger and the Powertrain Control Module (PCM).


When the rear defogger and mirror defogger switch is turned on with the starter switch on, the rear defogger and mirror defogger relay is activated and the battery voltage is applied to the rear defogger and mirror defogger.

The PCM is provided with the timer. When the operation time of the timer elapses which has been set in advance, the rear defogger and mirror defogger relay is automatically deactivated and the rear defogger and mirror defogger is turned off.

Circuit Diagram-1




Circuit Diagram-2



D08RX078

Parts Location



D08RX077

Legend

- | | |
|---|---|
| (1) I-17 | (10) G-10, G-11 |
| (2) RR Defogger Switch & Mirror Defogger Switch | (11) G-12 |
| (3) H-33 | (12) B-6 |
| (4) D-12 | (13) B-8 |
| (5) H-19 | (14) PCM |
| (6) H-21 | (15) Relay and Fuse Box |
| (7) Luggage Room Light | (16) H-31 |
| (8) H-20 | (17) I-39 (Rear Defogger & Mirror Defogger Relay) |
| (9) G-9 | (18) H-28 |
| | (19) D-3 |

Diagnosis

Rear Defogger Does Not Operate

Step	Action	Value(s)	Yes	No
1	Are the fuse 9, 10 and 17 normal?	—	Go to Step 2	Replace the fuse(s)
2	Are B-6 and/or B-8 grounded securely?	—	Go to Step 3	Ground it (them) securely
3	Remove the rear defogger relay. Is the battery voltage applied between the rear defogger relay harness side connector I-39 terminal 2 and the ground?	Approx. 12V	Go to Step 5	Go to Step 4
4	Repair an open circuit between the battery and connector I-39 terminal 2. Is the action complete?	—	Go to Step 3	—
5	Turn the starter switch on. Is the battery voltage applied between harness side connector I-39 terminal 4 and the ground?	Approx. 12V	Go to Step 7	Go to Step 6
6	Repair an open circuit between the fuse 17 and connector I-39 terminal 4. Is the action complete?	—	Go to Step 5	—
7	Disconnect the PCM connector C-1, C-2 and C-3. Is there continuity between harness side connector I-39 terminal 3 and harness side connector C-2 terminal C12 or connector C-1 terminal A14?	—	Go to Step 11	Go to Step 8
8	Repair an open circuit between connector I-39 terminal 3 and connector C-2 terminal C12 or connector C-1 terminal A14. Is the action complete?	—	Go to Step 7	—
9	Is there continuity between harness side connector I-17 terminal 4 and connector C-3 terminal F9 or connector C-3 terminal E12?	—	Go to Step 11	Go to Step 10
10	Repair an open circuit between connector I-17 terminal 4 and connector C-3 terminal F9 or connector C-3 terminal E12. Is the action complete?	—	Go to Step 9	—
11	Is there continuity between harness side connector I-17 terminal 3 and the ground?	—	Go to Step 13	Go to Step 12
12	Repair an open circuit between connector I-17 terminal 3 and the ground B-8. Is the action complete?	—	Go to Step 11	—
13	1. Reconnect the rear defogger relay. 2. Ground the PCM harness side connector C-2 terminal C12 or connector C-1 terminal A14. Is the battery voltage applied between the rear defogger harness side connector G-9 terminal 1 and the ground?	Approx. 12V	Go to Step 14	—
14	Is there continuity between the rear defogger harness side connector G-12 terminal 1 and the ground?	—	Go to Step 16	Go to Step 15

8D-182 WIRING SYSTEM

Step	Action	Value(s)	Yes	No
15	Repair an open circuit between connector G-12 terminal 1 and the ground B-6. Is the action complete?	—	Go to Step 14	—
16	1. Reconnect the rear defogger switch connector I-17. 2. Turn the rear defogger switch on. Is the battery voltage applied between the PCM harness side connector C-3 terminal F9 or connector C-3 terminal E12 and the ground?	Approx. 12V	Go to Step 17	Replace the rear defogger switch.
17	1. Reconnect the PCM connector C-2 and C-3 or C-1. 2. Turn the rear defogger switch on. Is the battery voltage applied between the rear defogger harness side connector G-9 terminal 1 and the ground?	—	Go to Step 19	Go to Step 18
18	Replace the PCM. Is the action complete?	—	Verify repair	—
19	Repair broken heat wire or connector poor contact of the rear defogger. Is the action complete?	—	Verify repair	—

Rear Defogger Timer Does Not Function


Step	Action	Value(s)	Yes	No
1	Replace the PCM. Is the action complete?	—	Verify repair	—

Audio

General Description


The audio circuit is designed for the current to flow through the receiver circuit when the radio switch is turned on with the starter switch in "ACC" or "ON". Current runs through the memory circuit of the audio regardless of the position of the starter switch.

Circuit Diagram-1



D08RX099

Parts Location



D08RX100

Legend

- | | |
|----------------------|-----------------------|
| (1) H-33 | (11) D-4 |
| (2) D-10 | (12) D-10 |
| (3) FRT Speaker (RH) | (13) FRT Speaker (LH) |
| (4) D-13 | (14) H-28 |
| (5) Tweeter (RH) | (15) H-31 |
| (6) RR Speaker (RH) | (16) Relay & Fuse Box |
| (7) B-10 | (17) I-46 |
| (8) RR Speaker (LH) | (18) B-8 |
| (9) B-12 | (19) I-15 |
| (10) Tweeter (LH) | (20) H-19 |


Cigarette Lighter, Digital Clock and Accessory Socket

General Description

When the cigarette lighter is pushed in with the starter switch at either "ACC" or "ON" position, a circuit is formed in the cigarette lighter case to heat the lighter coil.


The cigarette lighter is sprung back to its original position after the lighter coil is heated.

Circuit Diagram-1



D08RX098

Parts Location



D08RX097

Legend

- | | |
|---------------------------|-----------------------------|
| (1) Radio | (8) B-14, B-15 |
| (2) I-27 | (9) Relay & Fuse Box |
| (3) Digital Clock | (10) I-38 |
| (4) B-8 | (11) H-32 |
| (5) I-46 | (12) Cigarette Lighter |
| (6) Starter Switch | (13) Front Accessory Socket |
| (7) Rear Accessory Socket | (14) I-28, I-29 |
| | (15) I-21, I-22 |

Diagnosis

Cigarette Lighter Does Not Work

Step	Action	Value(s)	Yes	No
1	Is the fuse 3 normal?	—	Go to Step 2	Replace the fuse
2	Is B-8 grounded securely?	—	Go to Step 3	Ground it securely
3	1. Disconnect the cigarette lighter connector I-22. 2. Turn the starter switch to the ACC or ON position. Is the battery voltage applied between harness side connector I-22 terminal 1 and the ground?	Approx. 12V	Go to Step 5	Go to Step 4
4	Repair an open circuit between the fuse 3 and connector I-22 terminal 1. Is the action complete?	—	Go to Step 3	—
5	Disconnect the cigarette lighter connector I-21. Is there continuity between harness side connector I-21 terminal 1 and the ground B-8?	—	Repair or replace the cigarette lighter assembly	Go to Step 6
6	Repair an open circuit between connector I-21 terminal 1 and the ground B-8. Is the action complete?	—	Verify repair	—

Cigarette Lighter Does Not Spring Out After Being Heated

Step	Action	Value(s)	Yes	No
1	Is the cigarette lighter deformed?	—	Replace the cigarette lighter	Replace the cigarette lighter assembly

Power Door Mirror

General Description


The system consists of the starter switch, door mirror switch, defogger switch and door mirrors on both sides.

When the door mirror switch is operated with the starter switch at either "ACC" or "ON" position, the motor in the door mirror (on either side) rotates to allow the horizontal and vertical adjustment of mirror angles.


When the door mirror defogger switch is turned "ON", (with the starter switch at "ON" position), the heaters in both left and right mirrors are activated to defog both mirrors at the same time.



Circuit Diagram-2



Parts Location



D08RW078

Legend

- | | |
|----------------------|-----------|
| (1) D-12 | (8) H-28 |
| (2) Door Mirror (RH) | (9) H-31 |
| (3) I-46 | (10) I-12 |
| (4) Starter SW | (11) B-8 |
| (5) Door Mirror SW | (12) I-15 |
| (6) Door Mirror (LH) | (13) H-33 |
| (7) D-3 | (14) H-19 |

Diagnosis

Mirrors On Both Sides Operate Only In The Vertical (Or Horizontal) Direction

Step	Action	Value(s)	Yes	No
1	Repair or replace the door mirror control sw. Is the action complete?	—	Verify repair	—

Mirror On Left Sides Operate Only In The Vertical (Or Horizontal) Direction

Step	Action	Value(s)	Yes	No
1	Is the continuity in the door mirror control switch normal?	—	Go to Step 2	Repair or replace the door mirror control switch
2	Is the door mirror normal?	—	Go to Step 3	Repair or replace the door mirror
3	Repair a poor connection of connectors or an open circuit between connector I-12 terminal 6 and D-3 terminal 4 (or connector I-12 terminal 8 and D-3 terminal 7) Is the action complete?	—	Verify repair	

NOTE: Connectors shown in the parenthesis “()” indicate a check point of the mirror that does not operate in the horizontal direction.

Mirror On The Right Side Operates Only In The Vertical (Or Horizontal) Direction

Step	Action	Value(s)	Yes	No
1	Is the continuity in the door mirror control switch normal?	—	Go to Step 2	Repair or replace the door mirror control switch
2	Is the door mirror normal?	—	Go to Step 3	Repair or replace the door mirror
3	Repair a poor connection of connectors or an open circuit between connector I-12 terminal 6 and D-12 terminal 4 (or connector I-12 terminal 8 and D-12 terminal 7) Is the action complete?	—	Verify repair	

NOTE: Connectors shown in the parenthesis “()” indicate a check point of the mirror that does not operate in the horizontal direction.

Keyless Entry and Anti-Theft System

General Description

The circuit consists of the starter switch, anti-theft & keyless entry controller, anti-theft horn, front door and tailgate key switch (detect and tamper switch), door lock (& power window) switch, door lock actuator for each door, engine hood switch, clutch start switch (M/T), ANTI-THEFT indicator light and mode switch (A/T). The system operates as follows: After locking the starter switch and removing the starter key (this sets the alarm), if the door is unlocked in any way other than with the proper key, the headlights start flashing, the horn sounds, and the starter circuit is disabled. (However, the engine hood and all the doors must be locked and closed.)

Once the system has been placed in the warning or alarm condition, it can be released only when the starter switch is shifted from "OFF" to "ACC" by the starter key, or when the lock of the front door or the tailgate is released (to activate the detect switch) by the starter key.


Under this system the doors can be locked/unlocked by merely pressing the remote control buttons without inserting the ignition key.

Further, when you meet with a robbery, etc. in or near your vehicle, you can inform people around of the danger via horn and light by pressing the remote control panic button. The remote control is effective within the radius of 32.8 ft (10 meters) of your vehicle. This effective zone may be varied depending on the conditions around.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. There limits are designed to against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Circuit Diagram-1




Circuit Diagram-2




D08RX059

Circuit Diagram-3




D08RX060

Circuit Diagram-4




D08RX061

Circuit Diagram–5



Parts Location



D08RX102

Legend

- | | |
|-------------------------------|--------------------------------|
| (1) H-33 | (15) G-7 |
| (2) H-12, H-13, H-14, H-19 | (16) H-34 |
| (3) X-1 | (17) D-23 |
| (4) C-19 | (18) D-8 |
| (5) C-20 | (19) D-6 |
| (6) D-8 | (20) H-24 |
| (7) I-26 | (21) D-5 |
| (8) H-29 | (22) Door Lock Switch (FRT LH) |
| (9) Door Lock Switch (FRT RH) | (23) D-14 |
| (10) D-17 | (24) H-28 |
| (11) D-16, D-14 | (25) I-32 |
| (12) D-28 | (26) H-16, H-17, H-31, H-32 |
| (13) I-20 | (27) B-8 |
| (14) I-4 | (28) M-16 |
| | (29) H-10, H-11 |

Diagnosis

Diagnosis Procedure

1. Check to see if the battery voltage is normal.
2. Check to see if the fuse is normal.
3. Replace the anti-theft controller with one reserved for test. If a trouble recurs even after replacing the controller, find out the cause of the trouble by referring to "System check procedure" and the following list.

IIT-EM	MALFUNCTION	POSSIBLE CAUSE	DETECTING METHOD	REMARKS
A	ANTI-THEFT indicator light does not flash	Defective contact of door switch, or open circuit in door switch wiring	With door open, dome light and courtesy light do not come on	Burnt out indicator light bulb possible
		Short circuit in the detect switch	Check controller connector	Refer to "Connector check procedure" in this system
B	indicator light does not change to fully ON condition, or does not come on at all	Engine hood, doors and tailgate are not fully closed and locked	Check to see if doors are closed and locked	
		Defective door switch, or short circuit in switch wiring	Dome light and courtesy light remain lit on after closing doors	
		Defective tamper switch, or short circuit in wiring	Check controller connector	Refer to "Connector check procedure" in this system
		Defective lock switch, or short circuit in wiring	Check controller connector	Refer to "Connector check procedure" in this system
		Defective engine hood switch, or short circuit in wiring	Check controller connector	Refer to "Connector check procedure" in this system
		Defective tailgate switch, or short circuit in wiring	Luggage room light remains lit after closing tailgate	
C	ANTI-THEFT indicator light does not turn off (Steadily on)	Defective controller		
D	When door is opened by pulling up locking knob, alarm does not operate	Poor contact of lock switch, or open circuit in wiring	Check alarm operation (See No. 46 of "System check procedure," possible cause is a poor contact of lock switch or a open circuit in wiring)	
		Broken wire in wiring to headlight and horn, or a blown fuse	Check to see if headlights go out Check controller connector	Refer to "Connector check procedure" in this system
E	Alarm does not stop	Defective contact of detect switch, or damaged switch wiring	Check controller connector	Refer to "Connector check procedure" in this system
F	Even when door unlocked with key, alarm operates	Defective contact of detect switch, or damaged switch wiring	Check controller connector	Refer to "Connector check procedure" in this system
		Door detect switch is assembled to wrong door	When key is turned to lock position, alarm stops	

8D-204 WIRING SYSTEM

IIT-EM	MALFUNCTION	POSSIBLE CAUSE	DETECTING METHOD	REMARKS
G	Alarm does not operate even with tailgate open	Defective contact of tailgate switch, or defective wiring	When luggage room light switch is turned on with tailgate open, luggage room light does not come on	
H	Even when tailgate is opened with key, alarm does not stop	Defective contact of tailgate detect switch, or damaged wiring	Check controller connector	Refer to "Connector check procedure" in this system
I	Even when engine hood is opened with remote release, alarm does not operate	Damaged engine hood switch or wiring		
J	Even when starter switch is turned, alarm does not stop	Defective contact of starter switch	With starter switch turned to "ACC" position, audio, cigarette lighter and door mirrors (on "ACC" circuit) do not operate	
K	Indicator light continues flashing	Damaged door switch, or a short circuit in wiring	After closing door, dome light and courtesy light remain on	
		Damaged tamper switch, or a short circuit in wiring	Check controller connector	Refer to "Connector check procedure" in this system

System Check Procedure

STEP	OPERATION	ITEM TO BE CHECKED	ITEM OF MALFUNCTION	REMARKS
1	Turn starter key to "ON" position	Check to see if engine hood, tailgate and doors are closed and locked		
2	Open windows fully			
3	Pull out starter key after turning it back to "OFF" position	Check to see if indicator light remains lit off	K	
4	Unlock left front door with locking knob			
5	Open left front door (And get out of the vehicle)	Check to see if indicator light flashes	A	
		Check to see if dome light and courtesy light illuminate		
6	Close left front door			Be sure to lock door with locking knob
7	Lock left front door	Check to see if indicator light changes from flashing to steadily on	B	
8	Wait about 10 seconds	Check to see if indicator light turns off in about 10 seconds	C	Activate alarm device
9	Unlock left front door with locking knob	Check to see if alarm operates (with headlight flashing, and horn blaring intermittently)	D	All doors are unlocked
10	Insert key into key cylinder of left front door and turn it in unlock direction	Check to see if alarm stops	E	With key set at unlock position, check to see if alarm stops
11	Lock left front door	Check to see if indicator light turns on	B	All doors are locked
12	Wait for about 10	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
13	Unlock left front door with key	Check to see if alarm does not operate	F	
14	lock left front door with key	Check to see if indicator light turns on	B	
15	Wait for about 10 seconds	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
16	Unlock left rear door with locking knob	Check to see if alarm starts	D	Only left rear door is unlocked
17	Insert key into key cylinder of left front door and turn it to unlock direction	Check to see if alarm stops	E	With key set at unlock position, check to see if alarm stops (All doors are unlocked)
18	Open left rear door	Check to see if indicator light flashes	A	
		Check to see if dome light and courtesy light come on		
19	With one person in vehicle, close left rear door			
20	Lock left front door with locking knob	Check to see if indicator light is steadily on	B	All doors are locked
21	Wait about 10 seconds	Check to see if indicator light turns off in about 10 seconds	C	Activate alarm device

8D-206 WIRING SYSTEM

STEP	OPERATION	ITEM TO BE CHECKED	ITEM OF MALFUNCTION	REMARKS
22	Unlock tailgate from inside with locking knob	Check to see if alarm operates	D	Only tailgate is unlocked
23	Open tailgate, insert key into key cylinder of tailgate and turn it in lock direction	Check to see if alarm stops	H	With key set at unlock position, check to see if alarm stops
24	Leave tailgate open	Check to see if indicator light flashes	A	
		Check to see if luggage room light comes on	G	
25	Close tailgate			
26	Insert key into tailgate key cylinder and turn it in lock direction	Check to see if indicator light changes over from flashing into lighting condition	B	
27	Wait about 10 seconds	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
28	Unlock tailgate with key	Check to see if alarm does not operate	F	
29	Lock tailgate with key	Check to see if indicator light comes on	B	
30	Wait about 10 seconds	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
31	Unlock right rear door with locking knob	Check to see if alarm operates	D	Only right rear door is unlocked
32	Insert key into key cylinder of right front door and turn it in unlock direction	Check to see if alarm stops	E	With key at unlock position, check to see if alarm stops (With all doors unlocked)
33	Open right rear door	Check to see if indicator light flashes	A	
		Check to see if dome light and courtesy light come on		
34	Close right rear door			
35	Insert key into key cylinder of right front door and turn it in lock direction	Check to see if indicator light stays on steadily	B	
36	Wait about 10 seconds	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
37	Unlock right front door with locking knob	Check to see if alarm operates	D	Only right front door is unlocked
38	Insert key into key cylinder of right front door and turn it in unlock direction	Check to see if alarm stops	E	With key at unlock position, check to see if alarm stops (With all doors unlocked)
39	Open right front door	Check to see if indicator light flashes	A	
		Check to see if dome light and courtesy light come on		
40	Close right front door			

STEP	OPERATION	ITEM TO BE CHECKED	ITEM OF MALFUNCTION	REMARKS
41	Lock right front door with key	Check to see if indicator light stays on steadily	B	
42	Wait about 10 seconds	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
43	Unlock right front door with key	Check to see if alarm does not operate	F	
44	lock right front door with key	Check to see if indicator light stays on steadily	B	
45	Wait about 10 seconds	Check to see if indicator light goes off after about 10 seconds	C	Activate alarm device
46	Open engine hood with engine hood release handle	Check to see if alarm operates	I	
47	Insert key into starter switch and turn it to "ACC" position	Check to see if alarm stops	J	

NOTE: When the connector of the anti-theft controller is disconnected, the starter is inoperative.

In the checking of short wheel base model, Step Nos. 16 through 21 and Step Nos. 31 through 36 are omitted.

Connector Checking Table

Check the anti-theft and keyless entry control unit harness side connector I-26 by using a circuit tester.

TERMI- NAL NO.	CONNECTION	CHECK ITEM	OPERATION	CIRCUIT CONDITION
1	Key cylinder switch	Voltage	Key inserted	Approx. 12V
2	Tail relay	Voltage	Lighting SW "OFF"	Approx. 12V
3	FRT door switch—LH, RH	Continuity	Open door	Continuity
			Close door	No continuity
5	Key switch lock	Continuity	Lock with key	Continuity
6	Door lock key switch—LH, RH	Continuity	Lock with key	Continuity
7	FRT door lock switch—LH, RH	Continuity	Lock	Continuity
10	Anti-theft horn	Voltage	—	Approx. 12V
11	Door switch	Continuity	Unlock with locking knob	Continuity
			Lock with locking knob	No Continuity
12	Battery	Voltage	—	Approx. 12V
17	Actuator	Continuity	Unlock	Continuity
			Lock	No continuity
18	Engine hood switch	Continuity	Open engine food	Continuity
			Close engine hood	No continuity
19	Detect switch	Continuity	Unlock with key	Continuity
			Lock with key	No continuity
20	Door lock key switch—LH, RH	Continuity	Unlock	Continuity
21	FRT door lock switch—LH, RH	Continuity	Unlock	Continuity
23	Ground	Continuity	—	Continuity
24	Starter switch	Voltage	Starter switch "ACC"	Approx. 12V
25	Indicator light	Voltage	—	Approx. 12V
26	Dome light	Voltage	Dome light "DOOR" position	Approx. 12V
27	Lighting relay	Voltage	Headlight "OFF"	Approx. 12V
28	Starter relay	Volatge	Mode switch "P" or "N"	Approx. 12V
			Clutch pedal depressed	Approx. 12V

ID Code New Registration

This procedure erases all registered ID codes and registers a new received ID code instead.

Step	Action	Value(s)	Yes	No
1	1. Open the driver's side door. 2. Turn the starter switch off. Is the action complete?	—	Go to Step 2	—
2	Turn the starter switch to ACC position and then off three times within five seconds after step 1. Is the action complete within five seconds?	—	Go to Step 3	Finished
3	Close the door and then open it two times within ten seconds after step 2. Is the action complete within ten seconds?	—	Go to Step 4	Finished
4	1. Turn the starter switch to ACC position and then off five times. 2. Close the door and then open it. NOTE: This step must be performed within ten seconds after step 3. Is the action complete?	—	Go to Step 5	Finished
5	The control unit makes lock/unlock response once with interval of one second. Is the response complete?	—	Go to Step 6	—
6	Operate the lock or unlock button of transmitter within twenty seconds after step 5. Is the action complete?	—	Go to Step 7	Finished
7	The control unit makes lock/unlock response once with interval of one second as ID temporary registration. Is the response complete?	—	Go to Step 8	—
8	Operate the lock or unlock button of transmitter within twenty seconds after step 7. Is the action complete?	—	Go to Step 9	Finished
9	The control unit compares temporary registered ID code with receiving ID code Is temporary registered ID code the same as receiving ID code?	—	Go to Step 10	Go to Step 11
10	The control unit makes lock/unlock response three times with interval of one second. Is the response complete?	—	Finished	—
11	The control unit erases all registered ID codes and registers new ID code. Is the registration complete?	—	Go to Step 12	Go to Step 13
12	The control unit makes lock/unlock response once with interval of one second. Is the response complete?	—	Finished	—
13	The control unit makes lock/unlock response three times with interval of one second. Is the response complete?	—	Finished	—

ID Code Additional Registration

This procedure additionally registers a new received ID code with holding registered ID codes. When total number of registered ID codes and newly registered ID code exceeds four, they are erased in order of older one.

Step	Action	Value(s)	Yes	No
1	1. Open the driver's side door. 2. Turn the starter switch off. Is the action complete?	—	Go to Step 2	—
2	Turn the starter switch to ACC position and then off three times within five seconds after step 1. Is the action complete within five seconds?	—	Go to Step 3	Finished
3	Close the door and then open it two times within ten seconds after step 2. Is the action complete within ten seconds?	—	Go to Step 4	Finished
4	1. Turn the starter switch to ACC position and then off three times. 2. Close the door and then open it. NOTE: This step must be performed within ten seconds after step 3. Is the action complete?	—	Go to Step 5	Finished
5	The control unit makes lock/unlock response two times with interval of one second. Is the response complete?	—	Go to Step 6	—
6	Operate the lock or unlock button of transmitter within twenty seconds after step 5. Is the action complete?	—	Go to Step 7	Finished
7	The control unit makes lock/unlock response two times with interval of one second as ID temporary registration. Is the response complete?	—	Go to Step 8	—
8	Operate the lock or unlock transmitter within twenty seconds after step 7. Is the action complete?	—	Go to Step 9	Finished
9	The control unit compares temporary registered ID code with receiving ID code Is temporary registered ID code the same as receiving ID code?	—	Go to Step 10	Go to Step 11
10	The control unit makes lock/unlock response with interval of one second. Is the response complete?	—	Finished	—
11	The control unit registers new ID code. Is the registration complete?	—	Go to Step 12	Go to Step 13
12	The control unit makes lock/unlock response once with interval of one second. Is the response complete?	—	Finished	—
13	The control unit makes lock/unlock response three times with interval of one second. Is the response complete?	—	Finished	—

ID Code Check

This procedure checks how many kinds of ID code are registered.

Step	Action	Value(s)	Yes	No
1	1. Open the driver's side door. 2. Turn the starter switch off. Is the action complete?	—	Go to Step 2	—
2	Turn the starter switch to ACC position and then off three times within five seconds after step 1. Is the action complete within five seconds?	—	Go to Step 3	Finished
3	Close the door and then open it two times within ten seconds after step 2. Is the action complete within ten seconds?	—	Go to Step 4	Finished
4	1. Turn the starter switch to ACC position and then off. 2. Close the door and then open it. NOTE: This step must be performed within ten seconds after step 3. Is the action complete?	—	Go to Step 5	Finished
5	The control unit makes lock/unlock response twice as many the number of registered ID code with interval of two seconds. (In case of no registered code, the response is made ten times.) Is the response complete?	—	Finished	—

Answer Back (Anti-theft Horn Operation) Change Mode

Anti-theft horn, as an answer back function for the transmitter operation, changes from available into unavailing or from unavailing into available by this procedure.

Step	Action	Value(s)	Yes	No
1	Open the driver's side door. Is the action complete?	—	Go to Step 2	—
2	Lock the door and then unlock it three times within ten seconds after step 1. Is the action complete within five seconds?	—	Go to Step 3	Finished
3	Close the door and then open it two times within ten seconds after step 2. Is the action complete within ten seconds?	—	Go to Step 4	Finished
4	1. Lock the door and unlock it three times. 2. Close the door and then open it. NOTE: This step must be performed within ten seconds after step 3. Is the action complete?	—	Go to Step 5	Finished
5	Answer back mode changes. Is this step complete?	—	Go to Step 6	Go to Step 7
6	The control unit makes lock/unlock response once with interval of one second. Is the response complete?	—	Finished	—
7	The control unit makes lock/unlock response three times with interval of one second. Is the response complete?	—	Finished	—

Meter and Warning/Indicator Light


General Description

The circuit consists of the starter switch, meter assembly, vehicle speed sensor, transmission switch, lighting switch, turn signal switch, thermo unit, oil pressure unit, Powertrain Control Module, fuel tank unit, 4WD SW, oil pressure switch, parking brake switch, brake fluid switch, seat belt switch, illumination controller.

The meter ASM contains the speedometer, tachometer, voltmeter, engine coolant temperature gauge, oil pressure gauge, fuel gauge and warning/indicator lights. The meter warning/indicator lights and their bulb sockets are a unit, they are installed from the back of the speedometer assembly.




Circuit Diagram – 1 (A/T)






Circuit Diagram – 3






Circuit Diagram – 5




D08RX128

Circuit Diagram – 6



D08RX127

Parts Location



D08RX133

Legend

- | | |
|--------------------------------|-----------------------------------|
| (1) H-2 | (15) I-14 |
| (2) H-12, H-13, H-14, H-19 | (16) Fuel Tank Unit |
| (3) I-41, I-42 | (17) Fuel Tank |
| (4) Alarm & Relay Control Unit | (18) C-16 |
| (5) E-6 | (19) H-15, H-16, H-17, H-31, H-32 |
| (6) M-11 | (20) C-6 |
| (7) M-10 | (21) H-5, H-6 |
| (8) B-8 | (22) B-23 |
| (9) I-1 | (23) M-3, M-4 |
| (10) I-10 | (24) M-12 |
| (11) Combination Meter | (25) H-10 |
| (12) I-2 | (26) C-15 |
| (13) I-9 | (27) E-1 |
| (14) I-7 | (28) M-1, M-2 |

Diagnosis

Speedometer

Speedometer and Odometer Do Not Function

Step	Action	Value(s)	Yes	No
1	Does the vehicle speed sensor output in 4 pulses/1 rotation?	—	Go to Step 2	Replace the vehicle speed sensor
2	Are the circuits between the vehicle speed sensor and the meter, and the fuse (11) and the ground normal?	—	Replace the speedometer	Repair a poor connection at the connectors or an open circuit in the circuit

Speedometer Does Not Function (Odometer Is Normal)

Step	Action	Value(s)	Yes	No
1	Replace the speedometer assembly Is the action complete?	—	Verify repair	—

Odometer Does Not Function (Speedometer Is Normal)

Step	Action	Value(s)	Yes	No
1	Replace the speedometer assembly Is the action complete?	—	Verify repair	—

Speedometer Needle Fluctuates (May Be Wide Fluctuation)

Step	Action	Value(s)	Yes	No
1	Does the vehicle speed sensor normally?	—	Go to Step 2	Replace the speedometer
2	1. The oscilloscope waveform is deformed. 2. Replace the vehicle speed sensor, or repair a poor connection at the connectors in the circuit or a failure in the cable harness. Is the action complete?	—	Verify repair	—

Speedometer Needle Jumps Erratically

Step	Action	Value(s)	Yes	No
1	Does the vehicle speed sensor output normally?	—	Go to Step 2	Replace the speedometer
2	An abnormal periodic waveform is output by oscilloscope. Replace the vehicle speed sensor, or repair a poor connection at the connectors in the circuit or a failure in the cable harness. Is the action complete?	—	Verify repair	—

Inspection Of Waveform By Oscilloscope

Step	Action	Value(s)	Yes	No
1	1. Disconnect the battery ground cable. 2. Remove four screws of the meter assembly. 3. Connect a resistance of 1.3 to 5k ohm (1.4W or more) between the harness side connector I-1 terminal 12 and I-2 terminal 12 of the meter. 4. Install a speedometer tester. 5. Turn on the starter SW. 6. Check the waveform at the time when the vehicle speed is at 37 mph. Is the pulse input normal?	—	Replace the speedometer	Replace the vehicle speed sensor, or repair a poor connection of the connectors in the circuit or a failure in the cable harness.

Tachometer**Tachometer Needle Fluctuates (May Be Wide Fluctuation)**

Step	Action	Value(s)	Yes	No
1	Is the pulse input normal?	—	Replace the tachometer	Go to Step 2
2	Replace the PCM, repair a poor connection of the connector in the circuit or a failure in the cable harness. Is the action complete?	—	Verify repair	—

Tachometer Needle Jumps Erratically

Step	Action	Value(s)	Yes	No
1	Is the pulse input normal?	—	Replace the tachometer	Go to Step 2
2	Replace the ignition control module, or repair a poor connection of the connector in the circuit or a failure in the cable harness. Is the action complete?	—	Verify repair	—

Engine Coolant Temperature Gauge**Needle Does Not Move**

Step	Action	Value(s)	Yes	No
1	Is the connector of the engine coolant temperature unit connected securely?	—	Go to Step 2	Connect the connector securely
2	Disconnect the connector of the engine coolant temperature unit. Connect a 3.4 W bulb between the harness side connector E-19 terminal 1 and the ground of the thermo unit. When the starter SW is turned ON, does the gauge pointer move about 10 seconds after that?	—	Go to Step 3	Go to Step 4

8D-224 WIRING SYSTEM

Step	Action	Value(s)	Yes	No
3	Is the engine coolant temperature unit normal?	—	Repair a poor connection at the connector	Replace the unit
4	Is the circuit between the engine coolant temperature gauge and the engine coolant temperature unit normal?	—	Replace the meter assembly	Replace a poor connection of the connectors or an open circuit.

Gauge Reading Is Too Low (Or High)

Step	Action	Value(s)	Yes	No
1	Does the thermostat operate normally?	—	Go to Step 2	Replace the thermostat
2	Turn the starter switch on. When inserting and pulling out the thermostat connector E-19 terminal 1 several times, does the indication of the gauge vary?	—	Go to Step 3	Go to Step 4
3	Repair a poor connection at the connector of the thermo unit.	—		
4	Is the engine coolant temperature unit normal?	—	Repair an open or short circuit	Replace the unit

Needle Overshoots (Or Goes Up To The "H" Range)

Step	Action	Value(s)	Yes	No
1	Disconnect the connector of the engine coolant temperature unit. When the starter sw is turned on, does the pointer reach to the "H" range?	—	Go to Step 2	Replace the unit
2	Is there a short circuit between the engine coolant temperature unit and the engine coolant temperature (ECT) gauge?	—	Go to Step 3	Go to Step 4
3	Repair the short circuit. Is the action complete?	—	Verify repair	—
4	Is the printed circuit of the meter assembly grounded securely?	—	Go to Step 5	Repair or replace the printed circuit board
5	Check the ECT gauge, and replace it if necessary. Is the action complete?	—	Verify repair	—

Diagnosis

Even When The Tank Is Not Full Of Fuel, The Needle Overshoots (Or Goes Up To "F")

Step	Action	Value(s)	Yes	No
1	1. Disconnect the connector of the fuel tank unit. 2. Turn the starter sw on. Does the needle still point to "F"?	—	Go to Step 4	Go to Step 2
2	Remove the fuel tank unit. Does the float arm operate smoothly?	—	Go to Step 3	Replace the fuel tank unit.
3	Are the resistance values of the fuel tank unit at "E" and "F" points normal?	—		Replace the fuel tank unit.
4	Is the circuit between the fuel tank unit and the fuel gauge normal?	—	Go to Step 5	Repair a short circuit in the circuit.
5	Is the printed circuit of the meter assembly grounded securely?	—	Check the fuel gauge, and replace it if necessary.	Repair or replace the printed circuit board.

When The Parking Brake Lever Is Pulled, The Indicator Light Does Not Light Up

Step	Action	Value(s)	Yes	No
1	1. Disconnect the parking brake switch connector. 2. Connect the harness side connector to the ground. 3. Turn the starter switch on. Does the indicator light light up?	—	Go to Step 4	Go to Step 2
2	Does the indicator light have a burned out bulb, or is the socket poorly connected?	—	Replace the bulb or repair the poor connection at the socket.	Go to Step 3
3	Is there continuity in the circuit between the parking brake switch connector B-23 terminal 1 and I-1 terminal 8 (meter)?	—	—	Repair a poor connection at the connectors or an open circuit in the circuit.
4	Is the parking brake switch installed to the correct position?	—	Go to Step 5	Adjust the installation position.
5	Pull the parking brake. Is there continuity between the switch connector B-23 terminal 1 and ground?	—	Ground the parking brake switch securely.	Repair or replace the parking brake switch.

Even When The Parking Brake Lever Is Released, The Indicator Light Does Not Go Off

Step	Action	Value(s)	Yes	No
1	Is the parking brake switch installed to the correct position, and does it operate normally?	—	Go to Step 2	Adjust the switch installation position.
2	Disconnect the parking brake switch connector B-23. Does the indicator light go off?	—	Repair or replace the switch.	Go to Step 3
3	Is the brake fluid sufficient?	—	Go to Step 4	Replenish the brake fluid.
4	Is the brake fluid switch normal?	—	Go to Step 5	Replace the brake fluid tank.
5	Repair a short circuit between the parking brake switch connector B-23 terminal 1 and I-1 terminal 8, or the brake fluid switch connector I-1 terminal 8 and C-6 terminal 2. Is the action complete?	—	Verify repair	—

While The Engine Is Operating, The Oil Pressure Warning Light Does Not Go Off

Step	Action	Value(s)	Yes	No
1	Is the engine oil pressure normal?	—	Go to Step 2	Refer to the "Engine" section of this manual.
2	Disconnect the oil pressure switch connector E-1 disconnected. Does the warning light go off?	—	Go to Step 3	Repair a short circuit between connector E-1 terminal 1 and I-1 terminal 4 (meter).
3	Is there continuity between the oil pressure switch connector E-1 terminal 1 and the body ground?	—	—	Replace the oil pressure switch.

Even When The Fuel Tank Is Full Of Fuel, The Fuel Warning Light Lights Up

Step	Action	Value(s)	Yes	No
1	Disconnect the fuel tank unit connector F-1. Does the warning light go off?	—	Go to Step 2	Repair a short circuit between the fuel tank unit harness side connectors PCM B15 and connector I-9 terminal 9 (meter).
2	Is the fuel tank unit normal?	—	—	Replace the fuel tank unit.

Even When The Fuel Tank Is Empty, The Fuel Warning Light Does Not Light Up

Step	Action	Value(s)	Yes	No
1	Does the warning light have a burned out bulb, or is the socket poorly connected?	—	Replace the bulb, or repair a poor connection at the socket.	Go to Step 2
2	Is the fuel tank unit normal?	—	Go to Step 3	Replace the fuel tank unit.
3	Repair a poor connection at the connector or an open circuit in the circuit between the harness side connector F-1 terminal 4 and I-2 terminal 13 (meter). Is the action complete?	—	Verify repair	—

Starter Switch

Refer to "START AND CHARGING" in this section.

Lighting Switch / Dimmer Passing Switch / Headlight

Refer to "HEADLIGHT AND FOG LIGHT" in the section.

Turn Signal Switch

Refer to "TURN SIGNAL LIGHT, HAZARD WARNING LIGHT, CORNERING LIGHT, BACKUP LIGHT AND HORN" in this section.

Illumination Controller


Refer to "FRONT SIDE MAKER LIGHT, PARKING LIGHT, TAILLIGHT, LICENSE PLATE LIGHT AND ILLUMINATION LIGHT" in the section.

A/T Shift Indicator

General Description


The circuit consists of the starter switch, lighting switch, mode switch, A/T shift indicator control unit and A/T shift indicator (meter).

Circuit Diagram-1




D08RW225

Circuit Diagram-2



Parts Location



D08RW086

Legend

- (1) Battery
- (2) X-3
- (3) C-36
- (4) I-42
- (5) B-8
- (6) I-46
- (7) Starter SW
- (8) I-10

- (9) H-15
- (10) I-34
- (11) Relay Box
- (12) H-32
- (13) H-17
- (14) M-16
- (15) H-11
- (16) H-19

Heater and Air Conditioning


General Description

The heater and air conditioning system consists of a dual pressure switch, A/C switch, electronic thermostat, blower motor, fan switch, magnetic clutch for A/C compressor, blower resistor and relays.

Although start and stop of the air conditioner is done with ON/OFF of A/C switch, the electronic thermostat, A/C Compressor relay, thermo switch relay, dual pressure switch and ECM, (V6:PCM) release the magnetic clutch to temporarily stop A/C operation under the preset conditions in order to control the room temperature, prevent the temperature rise of engine coolant, and reduce the engine load.


Refer to HVAC system in Heating and Air Conditioning.

Circuit Diagram-1




D08RX113


Circuit Diagram-2



Circuit Diagram-3



Parts Location



D08RX112

Legend

- | | |
|----------------------------|-------------------------------|
| (1) Relay & Fuse Box | (11) C-16 |
| (2) X-4, X-5, X-6, X-9 | (12) H-17, H-32 |
| (3) C-36 | (13) H-5 |
| (4) H-12, H-19 | (14) B-3 |
| (5) B-4 | (15) E-3 |
| (6) I-23 | (16) C-11 (6VD1 M/T) |
| (7) Air Conditioning Bezel | (17) C-9 (6VD1 A/T) |
| (8) I-24 | (18) Condenser |
| (9) B-8 | (19) Condenser Fan (6VD1 A/T) |
| (10) I-1 | (20) C-24 (6VD1 A/T) |
| | (21) B-5 |


Sun Roof

General Description


The circuit consists of the starter switch, sun roof switch, sun roof control unit, safety stop switch, limit switch, and sun roof motor.

When the sun roof switch is turned on, the battery voltage is applied to the sun roof control unit through the circuit breaker and the power window relay on the circuit. Accordingly, when the sun roof switch is set to "Open" or "Close" position, the open or close relay incorporated into the control unit is activated to change the rotational direction of the sun roof motor to open or close the sun roof.

Also, the operational process (full close → limit stop → full open → safety stop → full close) of the sun roof is controlled by the control unit in accordance with signals received from the safety stop switch and limit switch.



Parts Location



D08RW095

Legend

- | | |
|---------------------------|----------------|
| (1) H-29 | (6) Starter SW |
| (2) Sun Roof SW | (7) H-30 |
| (3) Sun Roof Motor | (8) I-35 |
| (4) L-1 | (9) H-32 |
| (5) Sun Roof Control Unit | (10) B-8 |

Diagnosis

Sun Roof Does Not Open, Sun Roof Does Not Close

Step	Action	Value(s)	Yes	No
1	Turn the starter switch on. Is the battery voltage applied between connector L-1 terminal 1 and the ground?	—	Go to Step 2	Refer to item No. 5 "Power source circuit diagnosis" in this diagnosis.
2	Is connector B-8 grounded securely?	—	Go to Step 3	Ground it securely.
3	Is the sun roof switch normal?	—	Go to Step 4	Repair or replace the switch.
4	Is there any continuity between connector L-1 terminal 2 and connector B-6?	—	—	Replace the control unit.

Power Source Circuit Diagnosis

Step	Action	Value(s)	Yes	No
1	Is there any continuity between the terminals of C/B-1 (30A)?	—	Go to Step 2	Push in the reset button of circuit breaker and check the continuity again. If there is o continuity after pushing reset button, replace it with new one.
2	Is fuse (10A) normal?	—	Go to Step 3	Replace the fuse.
3	Is the power window relay normal?	—	Go to Step 4	Replace the relay.
4	Turn the starter switch on. Is the battery voltage applied between connector I-35 terminal 3 and the ground, connector I-35 terminal 2 and the ground?	—	Go to Step 5	Repair a poor connection of the connectors or an open circuit between fuse (15A) and connector I-35 terminal 3 or I-35 terminal 2.
5	Is connector B-8 grounded securely?	—	Go to Step 6	Ground it securely.
6	Repair a poor connection of the connectors or an open circuit between connector I-35 terminal 3 and connector B-8. Is the action complete?	—	Verify repair	—


Supplemental Restraint System (SRS) – Air Bag

General Description


The circuit consists of the starter switch, Sensing and Diagnostic Module 9SDM), inflator (driver & passenger) and warning light.

Refer to Supplemental Restraint System (SRS) in Accessories.

Circuit Diagram-1



Parts Location



D08RW090

Legend


- | | |
|--------------------------------|-----------|
| (1) Passenger Air Bag Assembly | (8) C-34 |
| (2) I-30 | (9) H-32 |
| (3) I-1 | (10) I-43 |
| (4) SRS Coil Assembly | (11) I-14 |
| (5) Driver Air Bag Assembly | (12) I-46 |
| (6) I-18, I-49 | (13) SDM |
| (7) H-16 | (14) I-25 |


Shift on the Fly System

General Description


The circuit consists of the starter switch, 4WD control unit, actuator (transfer), 4WD switch, front axle vacuum switching valve relay, front axle vacuum switching valve, front axle switch and 4WD indicator (meter). Refer to Driveline Control System Section.

Circuit Diagram-1





Parts Location





















D08RX118










Legend










- | | |
|----------------------|----------------------|
| (1) Battery | (10) C-32 |
| (2) Relay & Fuse Box | (11) I-19 |
| (3) C-4 | (12) B-19 |
| (4) M-11 | (13) C-16 |
| (5) B-8 | (14) H-15, H-32 |
| (6) C-31 | (15) H-18 |
| (7) I-1 | (16) C-15 |
| (8) Starter Switch | (17) M-12 |
| (9) I-2 | (18) H-9, H-10, H-11 |

Harness Connector Faces










No.	Connector face
B-1	
B-2	
B-3	
B-4	
B-5	
B-6	
B-7	
B-8	
B-9	










No.	Connector face
B-10	
B-11	
B-12	
B-13	
B-14	
B-15	
B-16	
B-17	
B-18	










No.	Connector face
B-19	
B-20	
B-21	
B-22	
B-23	
B-24	
C-1	
C-2	
C-3	










No.	Connector face
C-4	
C-5	
C-6	
C-7	
C-8	
C-9	
C-10	
C-11	
C-12	

8D-250 WIRING SYSTEM









No.	Connector face
C-13	
C-14	
C-15	
C-16	
C-17	
C-18	
C-19	
C-20	
C-21	










No.	Connector face
C-22	
C-23	
C-24	
C-25	
C-26	
C-27	
C-28	
C-29	
C-30	












No.	Connector face
C-31	
C-32	
C-33	
C-34	
C-35	
C-36	
C-37	
D-1	
D-2	







No.	Connector face
D-3	
D-4	
D-5	
D-6	
D-7	
D-8	
D-9	
D-10	
D-11	

8D-252 WIRING SYSTEM








No.	Connector face
D-12	
D-13	
D-14	
D-15	
D-16	
D-17	
D-18	
D-19	NOT USED
D-20	










No.	Connector face
D-21	
D-22	
D-23	
D-24	
D-25	
D-26	
D-27	
D-28	
D-29	










No.	Connector face
E-1	
E-2	NOT USED
E-3	 
E-4	 
E-5	
E-6	
E-7	
E-8	
E-9	 











No.	Connector face
E-10	NOT USED
E-11	
E-12	
E-13	
E-14	
E-15 ~ E-18	NOT USED
E-19	
E-20	
E-21 ~ E-23	NOT USED

8D-254 WIRING SYSTEM



















No.	Connector face
E-24	
E-25	
E-26	
E-27	
E-28	
E-29	NOT USED
E-30	
E-31	NOT USED
E-32	



















No.	Connector face
E-33	
E-34 ~ E-36	NOT USED
E-37	 (6VD1)  (X22SE)
E-38	
E-39	
E-40	
E-41	
E-42	
E-43	



















No.	Connector face
E-44	
E-45	
F-1	
F-2	
F-3	
F-4	
G-1	
G-2 ~ G-3	NOT USED
G-4 (Soft Top Model)	 

No.	Connector face
G-4 (Resin Top Model)	
G-5	
G-6	
G-7	 (without anti-theft)  (with anti-theft)
G-8	
G-9	
G-10	
G-11	
G-12	

8D-256 WIRING SYSTEM

No.	Connector face	
H-1		
H-2 (X22S E)		
H-2 (6VD1)		
H-3		
H-4		
H-5		
H-6		
H-7		
H-8		










No.	Connector face	
H-9		
H-10 (A/T)		
H-10 (M/T)		
H-11		
H-12		
H-13		
H-14		
H-15		
H-16		










No.	Connector face	No.	Connector face
H-17 (A/T)		H-24	 (without anti-theft)
H-17 (M/T)		H-25	
H-18		H-26	
H-19		H-27	
H-20		H-28	 (with power window)
H-21		H-28	 (without power window)
H-22		H-29	 (with anti-theft)
H-23		H-29	 (without anti-theft)
H-24	 (with anti-theft)	H-30 (LWB)	

8D-258 WIRING SYSTEM










No.	Connector face
H-30 (SWB)	
H-31	
H-32	
H-33	
H-33	
H-34	
H-34	
H-35 ~ H-36	NOT USED
H-37	










No.	Connector face
I-1	
I-2	
I-3	
I-4	
I-5	
I-6	
I-7	
I-8	
I-9	










No.	Connector face
I-10	
I-11	
I-12	
I-13	
I-14	
I-15	
I-16	
I-17	
I-18	









No.	Connector face
I-19	
I-20	
I-21	
I-22	
I-23	
I-24	
I-25	
I-26	
I-27	

8D-260 WIRING SYSTEM










No.	Connector face
I-28	
I-29	
I-30	
I-31	
I-32	
I-33	
I-34	
I-35	
I-36	










No.	Connector face
I-37	
I-38	
I-39	
I-40	
I-41	
I-42	
I-43	
I-44	
I-45	











No.	Connector face
I-46	
I-47	
I-48	
I-49	
L-1	
L-2	
L-3	
L-4	
L-5	










No.	Connector face
M-1	
M-2	
M-3	
M-4	
M-5	NOT USED
M-6	
M-7	
M-8	
M-9	

8D-262 WIRING SYSTEM

No.	Connector face
M-10	
M-11	
M-12	
M-13	
M-14	
M-15	
M-16	
M-17	
M-18	

No.	Connector face
M-19	
M-20	
M-21	
P-1	
P-2	
P-3	
P-4	
P-5	
P-6	

No.	Connector face
P-7	
P-8	  (X22SE)
P-9	
P-10	
X-1	
X-2	
X-3	
X-4	
X-5	

No.	Connector face
X-6	
X-7	
X-8	
X-9	
X-10	
X-11	
X-12	
X-13	
X-14	

RODEO

BODY AND ACCESSORIES

METER AND GAUGE

CONTENTS

Service Precaution	8E-1	Removal	8E-10
General Description	8E-1	Installation	8E-10
Meter Assembly	8E-2	Vehicle Speed Sensor	8E-11
General Description	8E-2	Removal	8E-11
Layout for Meters/Gauges, Warning Lights, Indicator Lights and Illumination Lights ...	8E-2	Installation	8E-11
Table for Meter/Gauge Connector Terminal Connections	8E-6	Fuel Tank Unit	8E-11
Removal	8E-10	Removal	8E-11
Installation	8E-10	Installation	8E-11
Warning Light Bulb, Indicator Light Bulb, Illumination Light Bulb, A/T Indicato r Light Bulb	8E-10	Main Data and Specifications	8E-12

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use ONLY the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

The circuit consists of the starter switch, meter assembly, Vehicle speed sensor, transmission switch, lighting switch, turn signal switch, thermo unit, oil pressure unit, Powertrain Control Module (PCM), fuel tank unit, 4WD switch, oil pressure switch, parking brake switch, brake fluid switch, seat belt switch, illumination controller, multi meter and ambient sensor.


Meter Assembly

General Description

The meter assembly has the speedometer, tachometer, engine coolant temperature gauge, fuel gauge and warning/indicator lights. In addition, the meter assembly.

Layout for Meters/Gauges, Warning Lights, Indicator Lights and Illumination Lights

Meter Assembly W/A/T (Front View)




825RW057

Legend

- | | |
|--------------------------------------|-------------------------|
| (1) Engine Coolant Temperature Gauge | (5) Fuel Gauge |
| (2) Tachometer | (6) Reset Knob |
| (3) Warning Light Lens | (7) Warning Light Lens |
| (4) Speedometer | (8) A/T Shift Indicator |

Meter Assembly W/A/T (Rear View)



825RW053


Legend

- (9) Illumination Light
- (10) LCD Light

- (11) Illumination Light
- (12) Illumination Light
- (13) Illumination Light

8E-4 METER AND GAUGE

Meter Assembly W/M/T (Front View)




825RW056

Legend

- | | |
|--------------------------------------|------------------------|
| (1) Engine Coolant Temperature Gauge | (4) Speedometer |
| (2) Tachometer | (5) Fuel Gauge |
| (3) Warning Light Lens | (6) Reset Knob |
| | (7) Warning Light Lens |

Meter Assembly W/M/T (Rear View)




825RX016

Legend

- (9) Illumination Light
- (10) LCD Light

- (11) Illumination Light
- (12) Illumination Light
- (13) Illumination Light

Table for Meter/Gauge Connector Terminal Connections **Meter Assembly W/M/T**



825RX014

Meter Assembly W/M/T

Connector No. I-10	
Terminal	Function
1	—
2	—
3	—
4	—
5	—
6	—
7	—
8	—
9	High-beam indicator light (—)
10	High-beam indicator light (+)


Connector No. I-9	
Terminal	Function
1	Illumination (—)
2	Illumination (+)
3	—
4	—
5	—
6	—
7	—
8	—
9	Fuel warning light
10	—
11	Battery (+)
12	—

Connector No. I-2	
Terminal	Function
1	Turn signal indicator light (Left)
2	Turn signal indicator light (Right)
3	Ground
4	—
5	Illumination (—)
6	Tachometer
7	Up shift indicator light (—)
8	Up shift indicator light (+)
9	ABS indicator light
10	—
11	—
12	Speedometer
13	PCM (Fuel)
14	Gnd

Connector No. I-1	
Terminal	Function
1	—
2	—
3	—
4	Oil pressure warning light
5	Check engine warning light
6	Check trans warning light
7	Engine coolant temperature gauge
8	Brake warning light
9	Ground (Gauge)
10	Charge warning light
11	—
12	Starter switch
13	Air bag warning light
14	—
15	Seat belt warning light
16	Illumination (+)

8E-8 METER AND GAUGE

Meter Assembly W/A/T



825RX013

Meter Assembly W/A/T

Connector No. I-10	
Terminal	Function
1	L position (A/T)
2	2 position (A/T)
3	3 position (A/T)
4	D position (A/T)
5	N position (A/T)
6	R position (A/T)
7	P position (A/T)
8	A/T shift indicator control unit
9	High-beam indicator light (-)
10	High-beam indicator light (+)

Connector No. I-9	
Terminal	Function
1	Illumination (-)
2	Illumination (+)
3	—
4	—
5	—
6	Winter drive indicator light
7	Power drive indicator light
8	Cruise set indicator light
9	Fuel warning light
10	—
11	Battery (+)
12	—


Connector No. I-2	
Terminal	Function
1	Turn signal indicator light (Left)
2	Turn signal indicator light (Right)
3	Ground
4	—
5	Illumination (-)
6	Tachometer
7	—
8	—
9	ABS indicator light
10	4WD indicator light
11	—
12	Speedometer
13	P.C.M (Fuel)
14	Gnd

Connector No. I-1	
Terminal	Function
1	—
2	—
3	—
4	Oil pressure warning light
5	Check engine warning light
6	Check trans warning light
7	Engine coolant temperature gauge
8	Brake warning light
9	Ground (Gauge)
10	Charge warning light
11	—
12	Starter switch
13	Air bag warning light
14	A/T oil temp warning light
15	Seat belt warning light
16	Illumination (+)


8E-10 METER AND GAUGE

Removal

1. Disconnect the battery ground cable.
2. Remove the Dash Side Trim Panel -LH.
3. Remove the lower cover Assembly(1).
Refer to the Instrument Panel Assembly in Body Structure section.
4. Remove the meter cluster Assembly(2).
Refer to the Instrument Panel Assembly in Body Structure section.



5. Remove four fixing screws and disconnect the meter connectors to remove the meter assembly(3).



CAUTION: The removed meter assembly should be placed upright or with its face side up.


Installation

To install, follow the removal steps in the reverse order.

Warning Light Bulb, Indicator Light Bulb, Illumination Light Bulb, A/T Indicator Light Bulb

Removal

1. Disconnect the battery ground cable.
2. Remove the meter assembly(1).
Refer to the Meter Assembly removal steps in Meter and Gauge section.
3. Hold the bulb socket by hand and rotate it counterclockwise to remove the socket & bulb(2) from the meter body.




Installation

To install, follow the removal steps in the reverse order.

Vehicle Speed Sensor

Removal

1. Disconnect the battery ground cable.
2. Disconnect the connector, remove the vehicle speed sensor body by rotating it and then remove the vehicle speed sensor(1).



220RX003

Installation

To install, follow the removal steps in the reverse order, noting the following points.


1. Tighten the vehicle speed sensor to the specified torque.

Torque: 27 N·m (20 lb ft)

Fuel Tank Unit

Removal

1. Disconnect the battery ground cable.
2. Remove the fuel tank(1).
Refer to the Fuel Tank removal steps in Engine section
3. Disconnect the connectors, remove five screws and then remove the fuel tank unit(2).



825RW060

Installation

To install, follow the removal steps in the reverse order.

Main Data and Specifications

Torque Specifications

Application	N·m	Lb Ft	Lb In
Vehicle Speed Sensor Fixing	27	20	—

RODEO

BODY AND ACCESSORIES

BODY STRUCTURE

CONTENTS

Service Precaution	8F-2	Removal	8F-33
Frame	8F-3	Installation	8F-35
General Description	8F-3	Rear Window Regulator, Glass and	
Frame Dimensions	8F-3	Glass Run	8F-36
General Description (Bumper)	8F-4	Parts Location	8F-36
Front Bumper	8F-4	Removal	8F-37
Parts Location	8F-4	Installation	8F-39
Removal	8F-5	Rear Tailgate (Lower Side)	8F-40
Installation	8F-5	Parts Location	8F-40
Rear Bumper	8F-6	Removal	8F-41
Parts Location	8F-6	Installation	8F-41
Removal	8F-6	Rear Hatchgate (Upper Side)	8F-42
Installation	8F-6	Parts Location	8F-42
General Description (Sheet Metal)	8F-8	Removal	8F-43
Engine Hood and Fender	8F-8	Installation	8F-43
Parts Location	8F-8	Adjustment	8F-45
Removal	8F-9	Spare Tire Carrier	8F-46
Installation	8F-10	Parts Location	8F-46
Body Dimension	8F-12	Removal	8F-46
General Description (Body)	8F-25	Installation	8F-46
Instrument Panel Assembly	8F-25	Headlining	8F-47
Parts Location	8F-25	Parts Location	8F-47
Removal	8F-26	Removal	8F-48
Installation	8F-27	Installation	8F-48
Front Door Assembly	8F-28	Windshield	8F-49
Parts Location	8F-28	Parts Location	8F-49
Removal	8F-28	Removal	8F-50
Installation	8F-29	Installation	8F-50
Rear Door Assembly	8F-30	Rear Quarter Glass	8F-53
Parts Location	8F-30	Parts Location	8F-53
Removal	8F-30	Removal	8F-54
Installation	8F-31	Installation	8F-54
Front Window Regulator, Glass and		Main Data and Specifications	8F-54
Glass Run	8F-32	Special Tools	8F-57
Parts Location	8F-32		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fasteners. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.


Frame

General Description

Proper frame alignment is important to assure normal vehicle life and performance of many other parts of the

vehicle. If the vehicle has been involved in a fire, collision or has been overloaded, it is necessary to check the frame alignment.

Frame Dimensions



501RX001


General Description (Bumper)

Front and rear bumpers consist of bumper fascia, support, and reinforcement.

The absorbing capability for both front and rear bumper systems are achieved through reinforcements in each bumper.

Front Bumper

Parts Location



601RW006


Legend

- (1) Backbar
- (2) Front Bumper Reinforcement Assembly

- (3) Support Assembly
- (4) Bumper Support
- (5) Front Bumper

Removal

1. Disconnect front fog light connector.
2. Remove front bumper fixing bolts.
 - Remove the two bolts from both sides of the front bumper.



601RW004

3. Remove front bumper assembly.
4. Remove the four bolts at each backbar and remove backbars.
5. Remove front fog light assembly.

Installation


To install, follow the removal steps in reverse order noting the following points:

1. Tighten the front bumper assembly fixing bolts to the specified torque.

Torque : 147 N·m (108 lb ft)

2. Front bumper adjustment


- When the bolts fixing front bumper assembly are tightened, adjustment should be made between the back bar and front side bumper so that a clearance of 14.5 mm (0.57 in) is provided between the lower side of the fender and the upper side of the front bumper.



614RX002

Rear Bumper

Parts Location



690RW007

Legend

- (1) Rear Bumper Assembly
- (2) Rear Bumper Fixing Bolts

Removal


1. Remove rear bumper fixing bolts.
 - Remove two bolts from each side.
2. Remove rear bumper assembly.

Installation

To install, follow the removal steps in reverse order noting the following points:

1. Partially tighten the rear bumper bolts (2) (3) and adjust the clearance between the body (tailgate) and the rear bumper (1).
Then fully tighten the rear bumper bolts (2) (3).


Torque : 147 N·m (108 lb ft)




690RW008

2. Rear bumper adjustment

- When the bolts fixing rear bumper assembly are tightened, adjustment should be made with shims so that a clearances shown in the figure below are provided between the body (tailgate) (4) and the rear bumper (5).



690RW005



690RW009


General Description (Sheet Metal)

This section includes items of front end sheet metal that are attached by bolts, screws or clips and related accessory components.

Anticorrosion materials have been applied to the interior surfaces of some metal panels to provide rust resistance. When servicing these panels, areas on which this material has been disturbed should be properly recoated with service-type anticorrosion material.

Engine Hood and Fender

Parts Location



610RW006


Legend

- (1) Hood Hinge
- (2) Engine Hood Assembly
- (3) Radiator Grille
- (4) Front Bumper Assembly


- (5) Headlight
- (6) Combination Light
- (7) Inner Liner
- (8) Fender

Removal


1. Open the hood.
2. Support the hood.
3. Remove windshield washer nozzle tube.
4. Remove hood hinge bolts.
 - Before removing the hinges from the engine hood, scribe a mark showing location of the hinges to facilitate installation in the original position.




5. Remove engine hood.
6. Remove radiator grille.
 - Raise the clips on the radiator grille.



7. Remove front combination lamp assembly.
 - Disconnect fixing screw and connector.



8. Remove inner liner fixing screws and remove inner liner.




9. Remove instrument panel driver and passenger lower covers.
10. Disconnect antenna cable.

8F-10 BODY STRUCTURE

11. Remove front fender panel.

○Disconnect 8 fixing bolts.



Installation

To install, follow the removal steps in the reverse order noting the following points:


1. Tighten the front fender panel fixing bolts to the specified torque.

Torque : 6.5 N·m (56 lb in)

2. Tighten the engine hood fixing bolts to the specified torque.

Torque : 9.8 N·m (85 lb in)

3. Adjust the clearance between the each of the panels.



○Check the fender and front door (3).

Clearance : 5.0 mm (0.196 in)

Height (step) : Flush

○Check the front door and rear door (2).

Clearance : 6.0 mm (0.23 in)

Height (step) : Flush


○Check the rear door and body (1).

Clearance : 5.0 mm (0.196 in)

Height (step) : Flush

Adjust clearance with door hinges.

Adjust height (step) by tapping on the fender lightly with a rubber hammer.




○Check the engine hood and fender (4).

Clearance : 4.5 mm (0.18 in)


Height (step) : 0.5 mm (0.02 in)

Adjust clearance with the hinges on the engine hood.

Adjust height (step) with the hood rests (5).








610RX001











610RW004







Body Dimension

Front Section





















8F-14 BODY STRUCTURE









Room Section






























Rear Section











Side Body Section










General Description (Body)

This publication contains essential removal, installation, adjustment and maintenance procedures.

Instrument Panel Assembly

Parts Location



740RX043


Legend

- | | |
|---|---|
| (1) Cross Beam | (11) Audio Sub Box |
| (2) Vent Duct Assembly | (12) Control Lever Assembly |
| (3) Instrument Panel Bracket | (13) Front Console Assembly |
| (4) Instrument Panel Assembly | (14) Lower Center Cover |
| (5) Passenger Inflator Module | (15) Instrument Panel Driver Lower Cover Assembly |
| (6) Dash Side Trim Panel | (16) Driver Knee Bolster Assembly |
| (7) Passenger Knee Bolster Reinforcement Assembly | (17) Meter Cluster Assembly |
| (8) Glove Box | (18) Instrument Panel Center Reinforcement |
| (9) Passenger Lower Bracket | (19) Meter Assembly |
| (10) Radio Assembly | (20) Instrument Harness Assembly |


Removal

CAUTION: For precautions on installation or removal of SRS – air bag system, refer to Supplemental Restraint System (SRS) – AIR BAG in Restraint section.

1. Disconnect the battery ground cable.
2. Remove lower center cover.
 - Remove screw (1) and pull out the cover at the clip positions.
 - Disconnect the cigarette lighter connector (2).



3. Remove front and rear console.
4. Remove dash side trim panels
 - Remove sill plates, then remove panels.
5. Remove glove box.
 - Remove the 2 fixing screws.



6. Remove instrument panel driver lower cover assembly.

- Remove the engine hood opener 2 fixing screws and 6 fixing screws.




7. Remove meter cluster assembly.
 - Remove 5 fixing screws, 2 clips and 8 switch connectors.
8. Remove driver knee bolster assembly.
 - Remove the 6 fixing bolts and screw.
9. Remove control lever assembly.
 - Remove 4 bolts and disconnect 3 control cables on the unit side and 3 harness connectors.
10. Remove radio and audio sub box assembly.
 - Remove 4 screws.
11. Remove Instrument panel assembly.

CAUTION: For precautions on installation or removal of SRS – air bag system, refer to Supplemental Restraint System (SRS) – AIR BAG in Restraint section.

- Disconnect the instrument harness connectors (6 connectors on the driver's side, 3 connectors on the passenger side and 2 connectors on the center side, the passenger inflator module connector, the radio antenna cable plug, and the ground cable fixing bolt on the left dash side panel.

- Remove the 8 bolts and the 3 nuts.




740RW038

12. Remove passenger inflator module.

- Remove 2 fixing bolts and 4 fixing nuts.

CAUTION: For precautions on installation or removal of SRS – air bag system, refer to Supplemental Restraint System in Restraint section.



827RW024

13. Remove meter assembly.

- Remove 4 fixing screws and disconnect the meter harness connectors.

14. Remove vent duct assembly.

- Remove 5 fixing screws.

15. Remove passenger lower bracket.

- Remove 3 screws.

16. Remove passenger knee bolster reinforcement.


- Remove 9 screws.

17. Remove instrument panel center reinforcement.

- Remove 6 screws.

18. Remove instrument panel harness assembly (1).

- Remove the clips.




740RW031

19. Remove instrument panel brackets

- Remove 2 fixing nuts and 2 fixing bolts for each bracket.

20. Remove cross beam.

- Remove 5 fixing nuts and 2 fixing bolts (upper) and 6 fixing bolts (lower).



840RW005

Installation


To install, follow the removal steps in the reverse order, noting the following points:

1. Adjust control cable.

- Refer to Control Lever Assembly in Heating, Ventilation and Air Conditioning section.

Front Door Assembly

Parts Location




630RW002

Legend

- | | |
|-------------------------|-----------------------------|
| (1) Front Door Assembly | (3) Door Harness Connection |
| (2) Lower Hinge Bolt | (4) Door Check Arm Pin |
| | (5) Upper Hinge Bolt |

Removal


1. Disconnect the battery ground cable.
2. Apply a setting mark on the body side hinge.
3. Remove door check arm pin.



630RW001

4. Remove upper and lower hinge bolts.


- Position a wood block under the door for protection and support the door assembly with hands during removal or installation.



63GRW003

5. Remove door harness connection.

- Pull the door harness grommet out in order to disconnect the harness connection.



63GRW004

6. Remove front door assembly.

Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. Align the door fitting to the body by referring to Engine Hood and Fender.
2. Tighten the door hinge bolts to the specified torque.

Torque : 34 N·m (25 lb ft)

3. Apply chassis grease to the door check arm pin and the door hinge moving surface.

Rear Door Assembly

Parts Location



650RW003

Legend

- (1) Rear Door Assembly
- (2) Lower Hinge Bolt


- (3) Door Harness Connection
- (4) Door Check Arm Pin
- (5) Upper Hinge Bolt

Removal


1. Disconnect the battery ground cable.
2. Apply a setting mark on the body side hinge.
3. Remove door check arm pin.

4. Remove upper and lower hinge bolts.

○ Position a wood block under the door for protection and support the door assembly with hands during removal or installation.




630RW003



650RW001

5. Remove door harness connection.

- Pull the door harness grommet out in order to disconnect the door harness connection.



6. Remove rear door assembly.

Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. Align the door fitting to the body by refer to Engine Hood and Fender in this section.
2. Tighten the door hinge bolts to the specified torque.

Torque : 34 N·m (25 lb ft)

3. Apply chassis grease to the check arm pin and the door hinge moving surface.

Front Window Regulator, Glass and Glass Run

Parts Location




635RW005

Legend


- | | |
|------------------------|--|
| (1) Glass Run | (10) Courtesy Light Lens |
| (2) Glass | (11) Speaker Grille |
| (3) Window Regulator | (12) Grip Cover |
| (4) Waist Seal | (13) Inside Handle |
| (5) Outside Handle | (14) Power Window Switch/Window Regulator Handle |
| (6) Locking Link | (15) Speaker Assembly |
| (7) Door Lock Assembly | (16) Tweeter |
| (8) Waterproof Sheet | (17) Door Mirror Cover |
| (9) Door Trim Panel | (18) Door Mirror Assembly |

Removal


1. Disconnect the battery ground cable.
2. Remove power window switch/regulator handle.
 - Pry out the power window switch and remove the connectors.




- To remove the regulator handle (1), remove the clip (2) at the root of the handle by using wire with hook.



3. Remove the screw while pulling the inside lever toward you and then remove the inside handle.




4. Remove speaker grille (3).
 - Pull out the front side of the grille.
5. Remove speaker assembly (2).
 - Remove 4 screws and disconnect the speaker harness connector (1).





8F-34 BODY STRUCTURE


6. Remove door mirror cover.
7. Remove grip cover.
8. Remove 5 screws (1), (3) and pull out the trim panel at the 6 clip positions (2).



9. Remove waterproof sheet.
10. Remove 2 screws through the access hole and pull out the glass upward.




11. Remove window regulator.
 - Disconnect the window regulator motor harness connector, if equipped with power windows.
12. Remove glass run.
 - Pull the glass run (6) out from the door frame groove.



Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. Install the regulator handle as shown in the illustration, if equipped without power windows.



2. Check to see that the window regulator operates smoothly and the glass opens and closes properly. Install the waterproof sheet with no clearance between the door panel and the waterproof sheet.

Rear Window Regulator, Glass and Glass Run

Parts Location




655RW001

Legend


- | | |
|------------------------|--|
| (1) Glass Run | (8) Rear Corner Garnish |
| (2) Glass | (9) Door Trim Panel |
| (3) Fixed Glass | (10) Courtesy Light Lens |
| (4) Window Regulator | (11) Power Window Switch/Window Regulator Handle |
| (5) Outside Handle | (12) Inside Handle |
| (6) Door Lock Assembly | (13) Waterproof Sheet |
| (7) Bracket | (14) Waist Seal |

Removal


1. Disconnect the battery ground cable.
2. Remove rear corner garnish.
3. Remove window regulator handle.
 - Remove the clip on the rear side of the regulator handle using a wire.




4. Remove the screw while pulling the inside lever toward you and then remove the inside handle.
5. Remove the 1 screws at the pull case.



6. Remove rear corner garnish.
7. Pull out the trim panel at the 8 clip positions.
 - Disconnect the power window switch connector and courtesy light connector.




8. Remove power window switch, if equipped.
9. Remove bracket.
10. Remove waterproof sheet (1).
 - Taking notice of the door harness, peel the waterproof sheet off the door panel carefully.



8F-38 BODY STRUCTURE


11. Remove fixed glass.

- Remove one bolt and screw as shown in the figure, then pull it upward.




12. Remove glass.

- First, align the height of regulator to the access hole. Remove 2 screws attaching bottom channel and regulator, then remove the glass.




- Remove the window glass by tilting it as necessary.



13. Remove window regulator.

- Remove the window regulator fixing bolts and pull the regulator out from the lower hole of the door panel.




14. Remove glass run.

- Pull the glass run out from the door frame.

Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. Install the regulator handle as shown in the illustration, if equipped without power windows.



2. Check to see that the window regulator operates smoothly and the glass opens and closes properly. Install the waterproof sheet with no clearance between the door panel and the waterproof sheet.

Rear Tailgate (Lower Side)

Parts Location




681RW001

Legend


- | | |
|-----------------------------|---------------------------------------|
| (1) Hatchgate Lock Assembly | (8) Trim Cover Assembly |
| (2) Tailgate Assembly | (9) Rear Wiper Motor |
| (3) Tailgate Bell Crank | (10) Dove Tail |
| (4) Hinges | (11) Key Cylinder |
| (5) Plug | (12) Tailgate Lock Assembly |
| (6) Tailgate Stopper Link | (13) Hatchgate Lock Actuator Assembly |
| (7) Waterproof Sheet | (14) Outside Handle |
| | (15) Tailgate Waist Seal |

Removal

1. Disconnect the battery ground cable.
2. Remove tailgate trim cover assembly (3).
 - Remove the 2 screws (2) holding the hatchgate lock assembly (1) first, and pull up the trim cover after detaching the clips from tailgate panel.



3. Remove waterproof sheet.
 - Remove waterproof sheet, exercising special care so as not to break it them.
4. Remove hatchgate lock.
 - Disconnect the lock link and connector and remove the 3 fixing bolts.
5. Remove key cylinder.
 - Disconnect the locking links.
 - Remove the key cylinder retaining clip with screwdriver to remove the key cylinder.




6. Remove hatchgate lock actuator assembly.
 - Disconnect the actuator harness connector.
 - Remove 2 nuts holding hatchgate lock actuator assembly from inside.
7. Remove outside handle.
 - Remove the 2 bolts holding the outside handle from inside.
8. Remove tailgate lock assembly.
 - Remove 3 screws holding the lock assembly.
9. Remove dove tail.
10. Remove tailgate locking links.
11. Remove rear wiper motor.
12. Remove tailgate stopper link.
13. Remove tailgate assembly.
 - Remove the tailgate assembly, taking care so as not to damage the hinge. Tailgate assembly is heavy and removal operation require two people
14. Remove tailgate waist seal.

Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. When setting up links, pay attention to the position and direction of the links.




Legend

- (1) Tailgate Lock Link
- (2) Outside Handle
- (3) Key Cylinder Lock Link
- (4) Cancel Mechanism

Rear Hatchgate (Upper Side)

Parts Location




682RW002

Legend

- | | |
|--------------------------|------------------------------------|
| (1) High Mount Stoplight | (8) Ball Stud Fastener |
| (2) Hatchgate Hinge | (9) Hatchgate Glass |
| (3) Hinge Collar | (10) Hatchgate Striker |
| (4) Hatchgate Glass Seal | (11) Striker Fastener |
| (5) Hatchgate Gas Stay | (12) High Mount Stoplight Fastener |
| (6) Hatchgate Ball Stud | (13) Outside Handle Collar |
| (7) Ball Stud Spacer | (14) Outside Handle |
| | (15) High Mount Stoplight Spacer |

Removal

1. Disconnect the battery ground cable.
2. Disconnect the high mount stoplight and rear defogger harness connectors.
3. Remove hatchgate ball stud (LH and RH)
 - Remove gas stay fixing screw and pull up the gas stay assembly (3) from the ball stud by spreading the retainer (2) holding the ball stud at the end of the gas stay with screwdriver (1), etc.




683RW004

4. Remove hatchgate hinge nuts from body side.
5. Remove hatchgate glass.
 - When pulling down the hatchgate glass, exercise special care so as not to damage it.
Hatchgate glass assembly is heavy and removal operation requires the two people.
6. Remove the 2 screws to remove hatchgate striker and fastener.
7. Remove outside handle.
8. Remove hinges.
9. Remove high mount stoplight.
10. Remove hatchgate finisher.

Installation


To install, follow the removal steps in the reverse order, noting the following points:

1. Attach the upper seal (1) to the hatchgate glass (2) indicated portion (3) so that the end of the glass contacts the bottom of the upper seal.



682RW003


2. When installing the hatchgate glass, first attach the hinge to the hatchgate glass. Align the stud of the hinge to the hole at body while supporting the hatchgate glass with two people at indicated positions (1), and then partially tighten the hinge to body nut (2). After adjustment (refer to Adjustment in this section) is completed, fully tighten the nut, hinge to body nut.
 - Hatchgate hinge assembly for left and right sides from each other.



682RW005

8F-44 BODY STRUCTURE

3. When installing gas stay assembly (1), first install the gas stay onto the rear quarter panel with fixing screw (2) and fastener (3) and then attach the gas stay upper end to the ball stud by spreading the retainer with screwdriver, etc. Gas stay assemblies for left and right sides differ from each other (The letter (4) L(LH) or R(RH) is embossed on the gas stay assembly.)



683RW005

4. When installing hatchgate striker assembly, first partially tighten the fixing screw and close the hatchgate and tailgate. Then fully tighten the fixing screw with the condition that the striker fits the hatchgate lock assembly at the tailgate.

Make sure that clearance exists between hatchgate striker and lock assembly.

After installation, again make sure that the striker fits the lock assembly properly.

5. Tighten the nut; hinge to body (LH and RH)

Torque : 6 N·m (52 lb in)

6. Tighten the screw; glass and hinge fix (LH and RH)

Torque : 6 N·m (52 lb in)


NOTE: When installing the hinge to the body, exercise special care not to damage the body paint surface.

7. Tighten the hatchgate striker fixing screw.

Torque : 6 N·m (52 lb in)

Adjustment

- Hatchgate alignment is obtained by moving hatchgate hinges.




682RW004

Legend

- | | |
|--------------------------|-----------------------------|
| (1) Hatchgate Striker | (5) Trim Cover |
| (2) Hatchgate Glass | (6) Hatchgate Lock Assembly |
| (3) Tailgate Outer Panel | (7) Quarter Trim |
| (4) Tailgate Inner Panel | (8) Hatchgate Glass Seal |
| | (9) Quarter Outer Panel |

Spare Tire Carrier

Parts Location



530RW003

Legend

- (1) Spare Tire
- (2) Spare Tire Carrier

Removal


1. Remove spare tire (1).
2. Remove spare tire carrier (2) by using spare tire carrier nut wrench J-34355.

Installation

1. Spare tire carrier.
 - Tighten the carrier fixing bolts to the specified torque.**Torque : 31 N·m (23 lb ft)**
2. Spare tire
 - Tighten the spare tire fixing bolts to the specified torque.**Torque : 118 N·m (87 lb ft)**

Headlining

Parts Location




666RW001

Legend

- | | |
|-----------------------------------|---------------------------------------|
| (1) Interior Trim Panels | (6) Headlining (With Sun Roof) |
| (2) Clip | (7) Sun Roof Finisher (With Sun Roof) |
| (3) Headlining (Without Sun Roof) | (8) Sun Roof Switch (With Sun Roof) |
| (4) Assist Grip | (9) Sunvisors |
| (5) Dome Light | (10) Sunvisor Holder |


Removal

1. Disconnect the battery ground cable.
2. Remove interior trim panels.
 - Refer to Interior Trim Panels in this section.
3. Remove dome light.
 - Remove the dome light lens and the fixing screws.
 - Disconnect the dome light connectors.
4. Remove sun roof switch.
 - Pry the clip free from the sun roof switch bracket and disconnect the connector.



665RW002

5. Remove sunvisors.
 - Remove the fixing screw and pull out the sunvisor holder (1) to remove it.
 - Disconnect the vanity mirror illumination connector.




743RS006

6. Remove sun roof finisher (With sun roof).
7. Remove headlining.
 - Remove the headlining fixing clips.

Installation

To install, follow the removal steps in the reverse order, noting the following points.


1. Install the headlining so that the fixing clips will not come off.
2. To install the sun roof finisher (1), first fit it in at one place with the headlining (3) close to the sun roof frame complete (2), then install the entire finisher tightly by hitting it with a plastic hammer, not allowing it to move up.



665RW003

Windshield

Parts Location




607RX002

Legend

- | | |
|------------------------------|-----------------------------|
| (1) Windshield Wiper Arm | (4) Windshield Side Molding |
| (2) Windshield Upper Molding | (5) Windshield Support |
| (3) Windshield | (6) Front Cowl Cover |

Removal


1. Disconnect the battery ground cable.
2. Remove windshield wiper arm.
 - Refer to Wiper/Washer System in this section.
3. Remove windshield side molding.
 - Pull the molding out from drip rail.
4. Remove front cowl cover.
5. Remove windshield support.
6. Remove upper moulding.
7. Remove windshield.
 - Use a knife to cut through part of the adhesive caulking material.
 - Secure one end of a piece of steel piano wire (0.02 inches in diameter) to a piece of wood that can serve as a handle.
 - Use a pair of needle nose pliers to insert the other end of the piano wire through the adhesive caulking material at the edge of the windshield glass.
 - Secure the other end of the piano wire to another piece of wood.
 - With the aid of an assistant, carefully move the piano wire with a sawing motion to cut through the adhesive caulking material around the entire circumference of the windshield glass.



- Clean the remaining adhesive caulking material from the area of the body which holds the windshield.

Installation

1. Install windshield glass
 - Clean the windshield glass bonding surface.
 - Use a soft rag and unleaded gasoline to wipe off any adhesive remaining on the body.
 - Mount the glass as shown in the illustration. Attach spacers in 10 locations.




- Apply primer #A435-95 or equivalent to the body side bonding surface. The primer should extend 25 mm (0.98 in.)
- Apply primer #435-40 or equivalent to the windshield glass side bonding surface.
- The primer should extend 25 mm (0.98 in.) from end of the glass.

NOTE: Allow curing time of at least 1 min after application of the primer before applying adhesive.

607RS014

607RW004



607RW003

Legend


- (1) Adhesive
- (2) Sealing Dam

- (3) Primer Coating Area
- (4) Windshield
- (5) Upper Molding

○Apply sealing adhesive (ESSEX #551-11 or equivalent).

If you are using an air gun, air pressure should be maintained at 147 – 294 kpa (21.3 – 42.6 psi).

NOTE: Bonding shall be done within 5 minutes after the adhesive has been applied.




607RS016

8F-52 BODY STRUCTURE

Adjust the setting of the windshield glass with suction discs.


NOTE: The windshield installation procedure should be performed from beginning to end without pausing. If you allow time to elapse between steps, excessive amounts of adhesive may be extruded from around the windshield.



607RS017

2. Install upper molding.

- Before installation of the windshield molding (at the upper part of the windshield), spray hot water at a temperature of about 60°C (140°F) onto the windshield glass and the adhesive. This will cause curing.



607RS018

- Install the molding as soon as hot water has been applied. Using a roller, push molding in until it bottoms.


3. Install windshield support.

- Install immediately after completing the gap adjustment.

4. Install front cowl cover.

5. Install side molding.

- Use unleaded gasoline and a soft cloth to wipe away any excess adhesive.
- Cure the bonding at a temperature of 20°C – 30°C (68°F – 86°F) for 24 hours.
- Check that the windshield does not leak water.




607RS019

6. Install windshield wiper arm.

Rear Quarter Glass

Parts Location



641RX004

Legend

- | | |
|---------------------------------|--|
| (1) Quarter Trim Panel | (6) Clip |
| (2) Rear Quarter Glass Moulding | (7) Velcro Fastener |
| (3) Rear Quarter Glass | (8) Primer applying range (Glass side & Body side) |
| (4) Clip | (9) Sealant |
| (5) Body Panel | |

Removal

1. Disconnect the battery ground cable.
2. Remove rear quarter trim panel.
 - Refer to Exterior/Interior Trim in this section.
3. Remove rear quarter glass.
 - Refer to Windshield removal procedure in this section.

Installation


1. Rear quarter glass.
 - Clean the bonding surfaces of both the glass and the body panel.
 - Be absolutely sure to apply glass primer to the side glass.
 - Be absolutely sure to apply body primer fully to the body.

NOTE: Immediately wipe off the primer left on the body or extruded sealant.


- Attach the fastener to the indicated position of body with sealant as shown in the figure.
 - Apply sealant to the circumference of glass as shown in the figure.
 - Insert the location pins on glass into the panel, push the glass against the panel, and bond them.
 - Attach the molding to the body with sealant.
 - Cure the bonding at a temperature of 20°C – 30°C (68°F – 86°F) for 24 hours.
 - Check that the rear quarter glass does not leak water.
2. Install rear quarter trim panel.

Main Data and Specifications


Torque Specification




636RW013




650RW005





682RW007




681RW004



501RX003



Special Tools

ILLUSTRATION	TOOL NO. TOOL NAME
 <p>901RW111</p>	<p>J-34355 Spare Tire Carrier Nut Wrench</p>

BODY AND ACCESSORIES

SEATS

CONTENTS

Service Precaution	8G-1	Rear Seat Assembly	8G-3
Front Seat Assembly	8G-2	Rear Seat Assembly and Associated Parts	8G-3
Front Seat Assembly and Associated Parts	8G-2	Removal	8G-3
Removal	8G-2	Installation	8G-3
Installation	8G-2	Main Data and Specifications	8G-4


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Front Seat Assembly

Front Seat Assembly and Associated Parts



750RW013

Legend

(1) Seat Assembly

(2) Adjuster Cover

(3) Bolt

Removal

1. Disconnect the battery ground cable.
2. Remove the adjuster cover.
3. Remove the bolt.
4. Remove the front seat assembly.

Installation


To install, follow the removal steps in the reverse order, noting the following points:

1. Tighten the front seat assembly fixing bolts to the specified torque.

Torque: 39 N·m (29 lb ft)

Rear Seat Assembly

Rear Seat Assembly and Associated Parts



755RW022

Legend

- | | |
|--------------------------------|-----------------------------------|
| (1) Bolt; Seatback | (5) Bracket; Seat Cushion To Body |
| (2) Rear Seatback Assembly | (6) Rear Seat Cushion Cover |
| (3) Rear Seat Cushion Assembly | (7) Bolt; Seat Cushion |
| (4) Body Floor Panel | (8) Nut; Seatback |

Removal

1. Remove the rear seat cushion cover.
2. Remove the seat cushion fixing bolt.
3. Remove the rear seat cushion assembly.
4. Remove the seatback fixing nut.
5. Remove the seatback fixing bolt.
6. Remove the rear seat assembly.

Installation


To install, follow the removal steps in the reverse order, noting the following point:

1. Tighten the rear seat fixing bolts to the specified torque.


Torque: 39 N·m (29 lb ft)

Main Data and Specifications

Torque Specifications



750RW012



755RW054

RODEO

BODY AND ACCESSORIES

SECURITY AND LOCKS

CONTENTS

Service Precaution	8H-1	Tailgate Lock, Hatchgate Lock and Associated Parts	8H-9
Front Door Lock Assembly	8H-2	Removal	8H-10
Front Door Lock Assembly and Associated Parts	8H-2	Installation	8H-10
Removal	8H-3	Key	8H-11
Installation	8H-4	Key Coding	8H-11
Front Outside Handle	8H-5	Key Styles	8H-11
Front Outside Handle and Associated Parts	8H-5	Power Door Lock System	8H-12
Removal	8H-5	General Description	8H-12
Installation	8H-5	Door Lock Key Switch	8H-12
Rear Door Lock Assembly	8H-6	Front Door Lock Actuator	8H-12
Rear Door Lock Assembly and Associated Parts	8H-6	Rear Door Lock Actuator	8H-12
Removal	8H-7	Tailgate Lock Actuator	8H-12
Installation	8H-7	Anti-Theft System	8H-12
Rear Outside Handle	8H-8	General Description	8H-12
Rear Outside Handle and Associated Parts	8H-8	Anti-Theft & Keyless Entry Controller	8H-12
Removal	8H-8	Anti-Theft Indicator	8H-13
Installation	8H-8	Anti-Theft Horn	8H-13
Tailgate Lock and Hatchgate Lock	8H-9	Engine Hood Switch	8H-14
		Anti-theft & Keyless Entry Control Unit/ Transmitter Replacement	8H-14


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fasteners joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fasteners. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Front Door Lock Assembly

Front Door Lock Assembly and Associated Parts




635RW008

Legend


- | | |
|-------------------------|--|
| (1) Outside Handle | (7) Speaker Grille |
| (2) Door Locking Link | (8) Grip Cover |
| (3) Door Lock Assembly | (9) Inside Handle |
| (4) Waterproof Sheet | (10) Power Window Switch/Window Regulator Handle |
| (5) Door Trim Panel | (11) Speaker Assembly |
| (6) Courtesy Light Lens | |

Removal


1. Disconnect the battery ground cable.
2. Remove power window switch (1)/regulator handle.
 - Pry out the power window switch and remove the connectors.




- To remove the regulator handle (1), remove the clip (2), at the root of the handle by using wire with hook.



3. Remove the screw while pulling the inside lever toward you and then remove the inside handle.




4. Remove speaker grille (3).
 - Pull out the front side of the grille.
5. Remove speaker assembly (2).
 - Remove 4 screws and disconnect the speaker harness connector (1).




8H-4 SECURITY AND LOCKS

6. Remove courtesy light lens.
7. Remove 5 screws (1), (3) and pull out the door trim panel at the 6 clip (2) positions.




8. Remove the waterproof sheet.
○Taking notice of the door harness, peel the waterproof sheet off the door panel carefully.
9. Raise the glass up to the uppermost position, and then remove the rear guide rail.
10. Disconnect the locking links then remove the door lock assembly fixing screws and door lock assembly.



Installation

To install, follow the removal steps in the reverse order, noting the following points:


1. Apply chassis grease to the lock assembly and striker moving surface.
2. Install the regulator handle as shown in the illustration, if equipped without power windows.



3. Check that the door lock operates smoothly.

Front Outside Handle

Front Outside Handle and Associated Parts



635RW008

Legend

- | | |
|-------------------------|--|
| (1) Outside Handle | (7) Speaker Grille |
| (2) Door Locking Link | (8) Grip Cover |
| (3) Door Lock Assembly | (9) Inside Handle |
| (4) Waterproof Sheet | (10) Power Window Switch/Window Regulator Handle |
| (5) Door Trim Panel | (11) Speaker Assembly |
| (6) Courtesy Light Lens | |

Removal

1. Disconnect the battery ground cable.
2. Remove the door trim panel.
○Refer to Front Door Lock Assembly in this section.
3. Remove the waterproof sheet.
○Taking notice of the door harness, peel the waterproof sheet off the door panel carefully.
4. Disconnect the locking links and remove the outside handle.
5. Remove the fixing clip to remove the door lock cylinder.


Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. Be sure to install the door lock cylinder at a right angle to the outside handle.
2. Check for smooth outside handle and lock cylinder operation.

Rear Door Lock Assembly

Rear Door Lock Assembly and Associated Parts




655RW005

Legend


- | | |
|-------------------------|---|
| (1) Outside Handle | (6) Courtesy Light Lens |
| (2) Door Lock Assembly | (7) Power Window Switch/Window Regulator Handle |
| (3) Bracket | (8) Inside Handle |
| (4) Rear Corner Garnish | (9) Waterproof Sheet |
| (5) Door Trim Panel | |

Removal


1. Disconnect the battery ground cable.
2. Remove rear corner garnish.
3. Remove courtesy light lens.
4. Remove window regulator handle.
 - Remove the clip on the rear side of the regulator handle using a wire.



5. Remove the screw while pulling the inside lever toward you and then remove the inside handle.
6. Remove the 2 screws at the pull case and courtesy light.



7. Pull out the trim panel at the 8 clip positions.
 - Disconnect the power window switch connector and courtesy light connector.




8. Remove power window switch, if equipped.
9. Remove bracket.
10. Remove waterproof sheet.
 - Taking notice of the door harness, peel the waterproof sheet off the door panel carefully.
11. Disconnect the locking links and remove the door lock assembly fixing screws to remove the door lock assembly.

Installation

To install, follow the removal steps in the reverse order, noting the following points.


1. Apply chassis grease to the lock assembly and striker moving surface.
2. Install the regulator handle as shown in the illustration, if equipped without power windows.



3. Check that the door lock operates smoothly.

Rear Outside Handle

Rear Outside Handle and Associated Parts



655RW005

Legend

- | | |
|-------------------------|---|
| (1) Outside Handle | (6) Courtesy Light Lens |
| (2) Door Lock Assembly | (7) Power Window Switch/Window Regulator Handle |
| (3) Bracket | (8) Inside Handle |
| (4) Rear Corner Garnish | (9) Waterproof Sheet |
| (5) Door Trim Panel | |

Removal

1. Disconnect the battery ground cable.
2. Remove the door trim panel.
○Refer to Rear Door Lock Assembly in this section.
3. Remove the waterproof sheet.
○Taking notice of the door harness, peel the waterproof sheet off the door panel carefully.
4. Disconnect the locking link and remove fixing bolts to remove the outside handle.


Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. Check that the outside handle operates smoothly.

Tailgate Lock and Hatchgate Lock

Tailgate Lock, Hatchgate Lock and Associated Parts




681RW005

Legend

- | | |
|-------------------------------|--------------------------------------|
| (1) Hatchgate Lock Assembly | (5) Trim Cover Assembly |
| (2) Tailgate Assembly | (6) Key Cylinder |
| (3) Tailgate Lock Relay Lever | (7) Tailgate Lock Assembly |
| (4) Waterproof sheet | (8) Outside Handle |
| | (9) Hatchgate Lock Actuator Assembly |


Removal

1. Disconnect the battery ground cable.
2. Remove tailgate trim cover assembly (3).
 - Remove the 2 screws (2) holding the hatchgate lock assembly (1) first, and pull up the trim cover while detaching the clips from tailgate panel.



683RW001

3. Remove waterproof sheet.
 - Remove waterproof sheet, exercising special care so as not to break it them.
4. Remove hatchgate lock.
 - Disconnect the lock link and connector and remove the 3 fixing bolts.
5. Remove key cylinder.
 - Disconnect the lock links.
 - Remove the key cylinder retaining clip with screw driver to remove the key cylinder.




683RW002

6. Remove hatchgate lock actuator assembly.
 - Disconnect the actuator harness connector.
 - Remove 2 bolts holding hatchgate lock actuator assembly from inside.
7. Remove outside handle.
 - Remove the 2 bolts holding the outside handle from inside.
8. Remove tailgate lock assembly.
 - Remove 3 screws holding the lock assembly.

Installation

To install, follow the removal steps in the reverse order, noting the following points:

1. When setting up links, pay attention to the position and direction of the links.



683RW003


Legend

- (1) Tailgate Lock Link
- (2) Outside Handle
- (3) Key Cylinder Link
- (4) Cancel Mechanism

2. Apply chassis grease to the lock assembly and striker moving surface.
3. Check that the tailgate lock operates correctly after installing it.

Key

Key Coding



Legend

- (1) Key (Actual size)
- (2) Key Code Tag

- (3) Position
- (4) Level


One key is used for the ignition, door, and tailgate lock cylinders. The keys are cut on both edges to make them reversible.

Key identification is obtained from the five character key code stamped on the key code tag. From this key code, the key code cutting combination can be determined from a code list (available to owners of key cutting equipment from suppliers).

If key codes are not available from records or tags, the key code can be obtained from the right hand door lock cylinder (if lock has not been replaced). Lock cylinders supplied by the factory as service parts are unmarked.

If the original key is available, the key code cutting combination can be determined by laying the key on the diagram shown in the figure.

Key Styles



Legend

- (1) Blank Key Style "A"
- (2) Blank Key Style "B"

The keys come in styles A or B depending on the key code cutting combination. When the first position in the combination is a 1, 2 or 3, Style A is used. When the first position is a 4, Style B (factory pre-cut key) is used.

Power Door Lock System

General Description

The circuit consists of the door lock (& power window) switch, door lock actuator for the front and rear door, tailgate lock actuator and the door lock key switch.

The front door lock switch-LH is always provided with the battery voltage.

The key or the inside lock button on the both driver's and the front passenger's door can activate the lock mechanism of all the doors (including the tailgate).

When the driver's door lock switch or the front passenger's door lock switch is turned on, current flows for about one second to the door lock actuator of each door connected in parallel with the front door lock (& power window) switch-LH to activate the actuator to lock and unlock the doors.

Door Lock Key Switch

Removal and Installation

- Refer to the Front Door Lock Assembly removal and installation steps in this section.

Front Door Lock Actuator

Removal and Installation

- Refer to the Front Door Lock Assembly removal and installation steps in this section.

Rear Door Lock Actuator

Removal and Installation

- Refer to the Rear Door Lock Assembly removal and installation steps in this section.

Tailgate Lock Actuator

Removal and Installation

- Refer to the Tailgate Lock Assembly removal and installation steps in this section.

Anti-Theft System

General Description

The circuit consists of the starter switch, anti-theft & keyless entry controller, anti-theft horn, front door and tailgate key switch (detect and tamper) switch, door lock actuator for each door, engine hood switch, clutch start switch (M/T), ANTI-THEFT indicator light and mode switch (A/T).


The system operates as follows: After locking the starter switch and removing the starter key (this sets the alarm), if the door is unlocked in any way other than with the proper key, the headlights start flashing, the horn sounds, and the starter circuit is disabled. (However, the engine hood and all the doors must be locked and closed.)

Once the system has been placed in the warning or alarm condition, it can be released only when the starter switch is shifted from "OFF" to "ACC" by the starter key, or when the lock of the front door or the tailgate is released (to activate the detect switch) by the starter key.

Anti-Theft & Keyless Entry Controller

Removal

1. Disconnect the battery ground cable.
2. Remove the instrument panel assembly (1).
 - Refer to the Instrument Panel Assembly in Body Structure section.
3. Remove the anti-theft & keyless entry controller (2).
 - Disconnect the connector.
 - Remove two fixing screws.



826RW007


Installation

To install, follow the removal steps in the reverse order.

Anti-Theft Indicator

Removal

1. Disconnect the battery ground cable.
2. Remove the instrument panel driver lower cover assembly (1).
 - Refer to the Instrument Panel Assembly in Body Structure section.
3. Remove the anti-theft indicator (2).
 - To remove the indicator, push the lock from the back side of the instrument panel driver lower cover assembly.




Installation

To install, follow the removal steps in the reverse order.

Anti-Theft Horn

Removal

1. Disconnect the battery ground cable.
2. Remove the anti-theft horn (1).
 - Disconnect the connector.
 - Remove a fixing bolt.




Installation

To install, follow the removal steps in the reverse order.

Engine Hood Switch

Removal

1. Disconnect the battery ground cable.
2. Disconnect the connector.
3. Remove the engine hood switch (1).



Installation

To install, follow the removal steps in the reverse order.

Anti-theft & Keyless Entry Control Unit/Transmitter Replacement

Anti-theft & Keyless Entry Control Unit Replacement

1. Remove and install the control unit.
 - Refer to Anti-theft & Keyless Entry Control Unit Removal and Installation in this section.
2. Register ID code.
 - Refer to ID Code Registration in this section.
3. Check that the keyless entry system works normally.

Transmitter Replacement

1. Prepare a new transmitter.
2. Register ID code.
 - Refer to ID Code Registration in this section.
3. Check that the keyless entry system works normally.

Transmitter Battery Replacement

1. Remove a screw to remove the cover.
2. Remove the batteries.
3. Set the new batteries into the transmitter.
4. Install the cover to the transmitter.
5. Check that the keyless entry system works normally.

RODEO

BODY AND ACCESSORIES

SUN ROOF/CONVERTIBLE TOP

CONTENTS

Service Precaution	8I-1	Sun Roof Switch	8I-7
Sun Roof Glass	8I-2	Removal	8I-7
Sun Roof Glass and Associated Parts	8I-2	Installation	8I-7
Removal	8I-2	Sun Roof Control Unit	8I-8
Installation	8I-3	Removal	8I-8
Sun Roof Deflector	8I-3	Installation	8I-8
Removal	8I-3	Safety Stop Switch	8I-8
Installation	8I-3	Removal	8I-8
Sunshade	8I-4	Installation	8I-8
Disassembled View	8I-4	Limit Switch	8I-9
Removal	8I-4	Removal	8I-9
Installation	8I-5	Installation	8I-9
Sun Roof Frame Complete Assembly	8I-6	Sun Roof Motor	8I-9
Sun Roof Frame Complete Assembly and		Removal	8I-9
Associated Parts	8I-6	Installation	8I-9
Removal	8I-6	Main Data and Specifications	8I-10
Installation	8I-7		


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Sun Roof Glass

Sun Roof Glass and Associated Parts




665RW004

Legend

- (1) Sun Roof Weatherstrip
- (2) Sun Roof Glass

Removal

1. Tilt the sun roof and open the sunshade.
2. Disconnect the battery ground cable.
3. Pull out the front of sight shield (2).
4. Remove four sun roof glass fixing Torx screws (3) to remove the sun roof glass (1).



665RW011

Installation

1. Be sure to install the sun roof weatherstrip so that the joint of the weatherstrip is on the rear side of the vehicle.
2. Temporary install the glass to the sun roof frame.
3. Open and shut the sun roof four to five times to position correctly the sun roof weatherstrip and the glass in the longitudinal and latitudinal setting positions.

4. Adjust the setting position to flush the surface between the roof panel and weatherstrip of sunroof glass.
5. Tighten the sun roof glass fixing screws to the specified torque.


Torque: 4 N·m (35 lb in)

6. After the sun roof glass is installed, recheck the roof panel and sun roof glass for vertical install position. If out of standard, adjust with fixing screws.

Sun Roof Deflector

Removal

1. Open the sun roof.
 - Let a 5 mm drill go through 2 blind rivets (2) to disengage riveted portions.
2. Remove the sun roof deflector (1).




665RW008

Installation

To install, follow the removal steps in the reverse order.

Sunshade

Disassembled View



665RW012


Legend

- (1) Sun Roof Glass
- (2) Sight Shield

- (3) Sunshade Stopper
- (4) Sunshade


Removal

1. Tilt the sun roof.
2. Disconnect the battery ground cable.
3. Remove the sun roof glass.
○Refer to Sun Roof Glass in this section.
4. Pull the sight shield upward using screwdriver.




665RW006

5. Remove 2 sunshade stopper fixing screws and remove sunshade stopper (1).



66SRW007

6. Pull out the sunshade (4) up to the guide rail edge. Lift the front of sunshade and clear the projection (3) of sunshade through the notch (2) of guide rail edge, then draw the sunshade out of the roof.




66SRW009

Installation

To install, follow the removal steps in the reverse order.

Sun Roof Frame Complete Assembly

Sun Roof Frame Complete Assembly and Associated Parts



665RW005


Legend

- | | |
|-------------------------|--------------------------------------|
| (1) Sun Roof Drain Hose | (2) Sun Roof Frame Complete Assembly |
| | (3) Headlining |

Removal

1. Disconnect the battery ground cable.
2. Remove the headlining.
Refer to Headlining in Body Structure section.

3. Disconnect the sun roof drain hose at the sun roof frame side as shown in the figure.



66SRW010

4. Disconnect the sun roof harness connection.
5. Remove 2 sun roof frame complete assembly fixing nuts (front side) and 6 fixing bolts from the frame complete assembly, and then remove the sun roof frame complete assembly.

NOTE: Be sure to remove the frame complete assembly while supporting it.


Installation

1. Install the sun roof frame complete assembly.
2. After installing the frame complete assembly, loosen the sun roof glass fixing nuts and adjust the sun roof glass setting position.
Refer to Sun Roof Glass in this section.
3. Install the sun roof drain hose.
4. Install the headlining.
Refer to Headlining in Body Structure section.

Sun Roof Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the sun roof switch (1).
 - Remove the switch by pushing the spring with the tip of a screwdriver.
 - Disconnect the switch connector.



825RW091


Installation

To install, follow the removal steps in the reverse order.

Sun Roof Control Unit

Removal

1. Disconnect the battery ground cable.
2. Remove the headlining (2).
Refer to the Headlining removal steps in Exterior/Interior Trim section.
3. Remove the sun roof control unit (1).
 - Disconnect two connectors.
 - Remove two screws.



665RW013


Installation

To install, follow the removal steps in the reverse order.

Safety Stop Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the sun roof drive unit assembly (1) to remove the safety stop switch (2).
Refer to the Sun Roof Frame Complete Assembly disassembly steps in this section.



665RS022


Installation

To install, follow the removal steps in the reverse order.

Limit Switch

Removal

1. Disconnect the battery ground cable.
 2. Remove the sun roof drive unit assembly (1) to remove the limit switch (2).
- Refer to the Sun Roof Frame Complete Assembly disassembly steps in this section.



665RS025


Installation

To install, follow the removal steps in the reverse order.

Sun Roof Motor

Removal

1. Disconnect the battery ground cable.
2. Remove the headlining (2).
Refer to the Headlining removal steps in Exterior/Interior Trim section.
3. Remove the sun roof motor (1).
 - Disconnect the connector.
 - Remove three nuts and two screws.



665RW014

Installation

To install, follow the removal steps in the reverse order.

Main Data and Specifications

Torque Specifications

Application	N·m	Lb Ft	Lb In
Sun Roof Glass Fixing Screws	4	—	35

RODEO

BODY AND ACCESSORIES

EXTERIOR / INTERIOR TRIM

CONTENTS

Service Precaution	8J-1	Removal	8J-6
Consoles	8J-2	Installation	8J-7
Consoles and Associated Parts	8J-2	Interior Trim Panels	8J-8
Removal	8J-2	Interior Trim Panels and Associated Parts	8J-8
Installation	8J-2	Removal	8J-8
Front Door Trim Panel	8J-3	Installation	8J-9
Front Door Trim Panel and Associated Parts	8J-3	Power Door Mirror System	8J-9
Removal	8J-3	General Description	8J-9
Installation	8J-5	Door Mirror Switch	8J-9
Rear Door Trim Panel	8J-6	Power Window System	8J-10
Rear Door Trim Panel and Associated Parts	8J-6	General Description	8J-10
		Power Window Switch Driver Seat Side ..	8J-10
		Power Window Motor	8J-11


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Consoles

Consoles and Associated Parts



745RX002

Legend

(1) Front Console

(2) Console Brackets

(3) Rear Console Assembly

Removal

1. Disconnect the battery ground cable.
2. Remove the shift knob (M/T) / transfer knob (A/T).
3. Remove the front console assembly.
 - Remove four fixing screws and disconnect the switch connectors.
4. Remove the front seat assembly (RH).
 - Refer to the Front Seat Assembly removal steps in Seats section.

5. Remove the rear console assembly.

- Remove two fixing screws.


Open the rear cover, remove two nuts, then the center console assembly.

Installation

To install, follow the removal steps in the reverse order.

Front Door Trim Panel

Front Door Trim Panel and Associated Parts



635RW005


Legend

- | | |
|---|--|
| (1) Glass Run | (10) Courtesy Light Lens |
| (2) Glass | (11) Speaker Grill |
| (3) Window Regulator/Power Window Regulator | (12) Grip Cover |
| (4) Outer Waste Seal | (13) Inside Handle |
| (5) Outside Handle | (14) Power Window Switch/Window Regulator Handle |
| (6) Door Lock Cylinder | (15) Speaker Assembly |
| (7) Door Lock Assembly/Door Lock Actuator | (16) Tweeter |
| (8) Waterproof Sheet | (17) Door Mirror Cover |
| (9) Door Trim Panel | (18) Door Mirror Assembly |

Removal

1. Disconnect the battery ground cable.


2. Remove the door mirror cover (2).



635RW006

3. Remove the regulator handle (1).


- Pull the hook (2) out and remove the regulator handle.



631RW004

4. Remove the power window switch (1).

- Pry the power window switch out and disconnect the switch connector.



825RW097


5. Remove the speaker cover.

6. Remove the front speaker.

- Remove the front speaker fixing screws in order to disconnect the speaker connector.

7. Remove the inside handle fixing screw.


CAUTION: Take care not to apply excessive force on the inside handle link, lest this link is elongated, which could make it impossible to operate the door with the inside handle.



632RW003

8. Remove the door trim panel.

- Remove 5 fixing screws (1), (3) in order to take off 6 clips (2) from the door panel.



- Disconnect the courtesy light connector to lift the door trim panel and unlock the engagement of the waist seal section. Then, pass the inside handle through the mounting hole of the trim panel, and detach the trim panel.


9. Remove the inside handle.

Installation

To install, follow the removal steps in the reverse order.

Rear Door Trim Panel

Rear Door Trim Panel and Associated Parts



655RW001

Legend


- | | |
|---|--|
| (1) Glass Run | (8) Rear Door Corner Garnish |
| (2) Glass | (9) Door Trim Panel |
| (3) Fix Window Glass | (10) Courtesy Light Lens |
| (4) Window Regulator/Power Window Regulator | (11) Power Window Switch/Window Regulator Handle |
| (5) Outside Handle | (12) Inside Handle |
| (6) Door Lock Assembly | (13) Waterproof Sheet |
| (7) Bracket | (14) Outer Waste Seal |

Removal

1. Disconnect the battery ground cable.

2. Remove the regulator handle(1).


○ Pull the hook(2) out and remove the regulator handle.



631RW002

3. Remove the power window switch.

- Remove the one screw and pry the power window switch out and disconnect the switch connector.




655RW003

CAUTION: Take care not to apply excessive force on the inside handle link, lest this link be elongated, which could make it impossible to operate the door with the inside handle.

4. Remove the door trim panel.

- Remove two fixing screws to take off eight clips from the door panel.



655RW002

- Unplug the courtesy light connector to lift the trim panel and unlock the engagement of the waist seal section, then pass the inside lever through the mounting hole of the trim panel, and detach the trim panel.


5. Remove the inside handle.

Installation

To install, follow the removal steps in the reverse order.

Interior Trim Panels

Interior Trim Panels and Associated Parts




643RW002

Legend

- | | |
|--------------------------|-----------------------------|
| (1) Quarter Trim Cover | (3) Center Lower Trim Cover |
| (2) Rear Roof Trim Cover | (4) Front Pillar Trim Cover |
| | (5) Center Upper Trim Cover |


Removal

1. Disconnect the battery ground cable.
2. Remove the rear end floor trim cover.
3. Remove the luggage room light.
 - Remove the luggage room light lens (1) and the fixing screw.
 - Disconnect the luggage room light connector.



825RW100

4. Remove the rear roof trim cover.
 - Pry the trim cover clips free from the body panel.
5. Remove the rear seat belt lower anchor bolt cover and the lower anchor bolt (5).
6. Remove the quarter trim cover (1).
 - Remove the tool box lid (3) and 3 fixing screws (4). Pry the quarter trim cover retainers (2) free from the body panel.



7. Remove the center lower trim cover.
 - Remove the front seat belt lower anchor bolt cover and lower anchor bolt.
 - Remove the sill plate and pry the trim cover clips free from the body panel.
8. Remove the center upper trim cover.
 - Turn up the finisher and pry the trim cover clips free from the body panel.
9. Remove the front pillar trim cover
 - Turn up the finisher and pry the trim cover clips free from the body panel.

Installation

To install, follow the removal steps in the reverse order, noting the following point:

1. Tighten the seat belt anchor bolt to the specified torque.

Torque: 39 N·m (29 lb ft)

Power Door Mirror System

General Description

The system consists of the starter switch, door mirror switch, rear defogger/mirror defogger switch and door mirrors on both sides.


When the door mirror switch is operated with the starter switch at either "ACC" or "ON" position, the motor in the door mirror (on either side) rotates to allow the horizontal and vertical adjustment of mirror angles.

When the rear defogger/mirror defogger switch is turned "ON" (with the starter switch at "ON" position), the heaters in both left and right mirrors and the rear windshield glass are active defog both mirrors and rear windshield glass at the same time.

Door Mirror Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the instrument panel lower cover (2).
Refer to the instrument panel assembly in Body Structure section.
3. Remove the door mirror switch (1).



Rear Defogger/Mirror Defogger Switch

Refer to the Rear Defogger/Mirror switch removal and installation steps in Lighting System section.

Door Mirrors

Refer to the Door mirrors removal and installation steps in Exterior/Interior Trim section.

Power Window System

General Description


The power window system consists of power window switches and power window motors on driver and passenger sides and power window relay. With the starter switch in "ON" position, the battery voltage is supplied through power window relay to the power window switches on driver and passenger sides. Selection of up or down switch changes the motor rotating direction to open or close the window.

When the lock switch on the switch panel on the driver side is pressed, the power window switch is in open state. As a result, the power source to the other switches are cut off, and the power window motors do not run.

Power Window Switch Driver Seat Side

Removal

1. Disconnect the battery ground cable.
2. Remove the switch (1).
 - Pull out the switch by pushing the spring with the tip of a screwdriver.
 - Disconnect the connector.



825RW080


Installation

To install, follow the removal steps in the reverse order.

Front Passenger Seat Side

Removal

1. Disconnect the battery ground cable.
2. Remove the switch (1).
 - Pull out the switch by pushing the spring with the tip of a screwdriver.
 - Disconnect the connector.



825RW087


Installation

To install, follow the removal steps in the reverse order.


Rear-Left and Right Sides

Removal

1. Disconnect the battery ground cable.
2. Remove the rear door trim pad (2).
 - Refer to the Rear Door Trim Pad removal steps in Exterior/Interior Trim section.
 - Disconnect the rear power window switch (1) connector.
3. Remove the rear power window switch (1).
 - Remove the switch fixing screw from the back side of the rear door trim (2).



825RW081




825RW079

Installation

To install, follow the removal steps in the reverse order.

Power Window Motor**Driver Seat Side****Removal**

1. Disconnect the battery ground cable.
2. Remove the window regulator assembly (2).
 - Refer to the Window Regulator and Glass removal steps in Body Structure section.
3. Remove the power window motor (1).
 - Remove three screws.



825RW096

Installation


To install, follow the removal steps in the reverse order.

Front Passenger Seat Side**Removal and Installation**

Refer to the Front Window Motor — Driver Seat side removal and installation steps in this section.

Rear-Left Side**Removal**

1. Disconnect the battery ground cable.
2. Remove the rear window regulator assembly (2).
 - Refer to the Rear Window Regulator and Glass removal steps in Body Structure section.
3. Remove the power window motor (1).
 - Remove three screws.



825RW095

Installation

To install, follow the removal steps in the reverse order.

Rear-Right Side**Removal and Installation**

Refer to the Rear Power Window Motor — Left Side removal and installation steps in this section.

RODEO

RESTRAINTS

CONTENTS

Seat Belt System	9A
Supplemental Restraint System (SRS)	9J
Restraint Control System	9J1

SEAT BELT SYSTEM

CONTENTS

Service Precaution	9A-1	Removal	9A-3
Front Seat Belt	9A-2	Installation	9A-4
Front Seat Belt and Associated Parts	9A-2	Front Seat Buckle Assembly	9A-5
Removal	9A-2	Removal	9A-5
Installation	9A-2	Installation	9A-5
Rear Seat Belt	9A-3	Main Data and Specifications	9A-6
Rear Seat Belt and Associated Parts	9A-3		


Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Front Seat Belt

Front Seat Belt and Associated Parts



760RW040

Legend

- | | |
|---|------------------------------------|
| (1) Door Seal Finisher (Front & Rear) | (6) Seat Belt Lower Anchor Bolt |
| (2) Adjustable Shoulder Anchor Assembly | (7) Center Pillar Lower Trim Cover |
| (3) Seat Belt Upper Anchor Bolt | (8) Retractor |
| (4) Center Pillar Upper Trim Cover | (9) Rear Sill Plate |
| (5) Front Seat Belt Assembly | (10) Front Sill Plate |

Removal

1. Disconnect the battery ground cable.
2. Remove the sill plate (Front & Rear).
3. Remove the seat belt lower anchor bolt.
4. Remove the center pillar lower trim cover.
5. Remove the door seal finisher (Front & Rear).
6. Remove the center pillar upper trim cover.
7. Remove the seat belt upper anchor bolt.
8. Remove the retractor.
9. Remove the adjustable shoulder anchor assembly.

Installation

To install, follow the removal steps in the reverse order, noting the following points.

1. Tighten the adjustable shoulder anchor assembly fixing bolts to the specified torque.


Torque: 39 N·m (29 lb ft)

2. Tighten the seat belt anchor bolts (Upper & Lower) and the retractor fixing bolts to the specified torque.

Torque: 39 N·m (29 lb ft)

Rear Seat Belt

Rear Seat Belt and Associated Parts



755RW068

Legend


- | | |
|---|---------------------------------|
| (1) Adjustable Shoulder Anchor Assembly | (7) Rear End Floor Trim Cover |
| (2) Seat Belt Upper Anchor Bolt | (8) Seat Belt Lower Anchor Bolt |
| (3) Slider Plate Trim Assembly | (9) Rear Seat Belt Assembly |
| (4) Quarter Trim Cover | (10) Retractor |
| (5) Rear Roof Trim Cover | (11) Rear Sill Plate |
| (6) Tailgate Weather Strip | (12) Rear Door Seal Finisher |

Removal

1. Disconnect the battery ground cable.
2. Remove the tailgate weather strip.
3. Remove the rear end floor trim cover.
4. Remove the luggage room light.
 - Remove the luggage room light lens (1) and the fixing screw.

9A-4 SEAT BELT SYSTEM

○Disconnect the luggage room light connector.



5. Remove the rear roof trim cover.


○Pry the trim cover clips free from the body panel.

6. Remove the rear sill plate.

7. Remove the rear seat belt lower anchor bolt cover and the lower anchor bolt (5).

8. Remove the quarter trim cover (1).


○Remove the tool box lid (3) and 3 fixing screws (4).
Pry the quarter trim cover retainers (2) free from the body panel.



9. Remove the slider plate trim assembly (2).

○Remove the two fixing screws from the adjustable shoulder anchor (1).

○Pull out the seat belt through the slider plate trim (3).



10. Remove the seat belt upper anchor bolt.

11. Remove the retractor.

12. Remove the rear seat belt assembly.

13. Remove the adjustable shoulder anchor assembly.

○Remove the two fixing bolts.

Installation

To install, follow the removal steps in the reverse order, noting the following point.

1. Tighten the adjustable shoulder anchor assembly fixing bolts to the specified torque.

Torque: 39 N·m (29 lb ft)


2. Tighten the seat belt anchor bolts (Upper & Lower) and the retractor fixing bolts to the specified torque.

Torque: 39 N·m (29 lb ft)

Front Seat Buckle Assembly

Removal

1. Disconnect the battery ground cable.
2. Disconnect the seat belt warning connector (driver's side) and remove a clip.
3. Remove the front seat buckle assembly (1).



Installation


To install, follow the removal steps in the reverse order, noting the following point.

1. Tighten the buckle anchor bolt to the specified torque.

Torque: 39 N·m (29 lb ft)

Main Data and Specifications

Torque Specifications



RODEO

RESTRAINTS

SUPPLEMENTAL RESTRAINT SYSTEM

CONTENTS

Service Precaution	9J-2	Deployment Inside Vehicle (Vehicle Scrapping Procedure)	9J-15
General Description	9J-2	Deployed Air Bag Assembly Handling	9J-18
Restraint Devices	9J-2	Special Tools	9J-18
System Description	9J-3	J-41433 SRS Driver/Passenger Load Tool	9J-18
SRS Component and Wiring Location View	9J-4	J-39200 DVM	9J-19
Component Description	9J-4	Scan Tool	9J-19
SDM (Sensing and Diagnostic Module) ...	9J-4	J-35616-A Connector Test Adapter Kit ...	9J-19
“Air Bag” Warning Lamp	9J-5	J-42986 SRS Deployment Tool	9J-19
SRS Coil Assembly	9J-5	J-42987 SRS Adapter For Load Tool	9J-20
Air Bag Assemblies	9J-5	J-41497 SRS Deployment Fixture	9J-20
Steering Column	9J-6	Tech 2 Scan Tool	9J-21
Knee Bolster	9J-6	Service Precaution	9J-24
Definition	9J-6	Disabling The SRS	9J-24
Diagnosis	9J-7	Enabling The SRS	9J-24
Diagnostic Trouble Codes	9J-7	Handling / Installation / Diagnosis	9J-24
Scan Tool Diagnostics	9J-7	Inspections Required After An Accident ..	9J-24
Use of Special Tools	9J-8	Sensing and Diagnostic Module (SDM)	9J-25
SRS Connector Body Face Views	9J-8	Service Precautions	9J-25
Repairs and Inspections Required After an Accident	9J-8	Removal	9J-25
Accident With Deployment – Component Replacement and Inspections	9J-9	Installation	9J-26
Accident With or Without Deployment—Component Inspection	9J-9	Driver Air Bag Assembly	9J-26
SDM Replacement Guidelines	9J-9	Service Precautions	9J-26
Wiring Damage	9J-9	Removal	9J-26
SRS Connector (Plastic Body And Terminal Metal Pin) Damage	9J-9	Installation	9J-27
SRS Wire Pigtail Damage	9J-9	Steering Wheel	9J-27
On-Vehicle Service	9J-9	Service Precautions	9J-27
Service Precautions	9J-9	Removal	9J-27
Disabling The SRS	9J-9	Installation	9J-28
Enabling The SRS	9J-9	SRS Coil Assembly	9J-29
Handling / Installation / Diagnosis	9J-10	Service Precaution	9J-29
Air Bag Assembly Handling / Shipping / Scrapping	9J-10	Removal	9J-29
Live (Undeployed) Air Bag Assembly	9J-10	Installation	9J-29
Air Bag Assembly Shipping Procedure For Live (Undeployed) Air Bag Assemblies ...	9J-11	Steering Column	9J-31
Deployed Air Bag Assembly	9J-11	Service Precaution	9J-31
Air Bag Assembly Scrapping Procedure ..	9J-11	Removal	9J-31
Deployment Outside Vehicle (Driver Air Bag Assembly)	9J-11	Installation	9J-32
Deployment Outside Vehicle (Passenger Air Bag Assembly)	9J-13	Passenger Air Bag Assembly	9J-33
		Service Precaution	9J-33
		Removal	9J-33
		Installation	9J-33

Service Precaution


WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

General Description

CAUTION: When fasteners are removed, always reinstall them at the same location from which they were removed. If a fastener needs to be replaced, use the correct part number fastener for that application. If the correct part number fastener is not available, a fastener of equal size and strength (or stronger) may be used. Fasteners that are not reused, and those requiring thread locking compound will be called out. The correct torque value must be used when installing fasteners that require it. If the above conditions are not followed, parts or system damage could result.

Restraint Devices




827RS035

Legend

- (1) Deployed Air Bag
- (2) Knee Bolster
- (3) Seat Belt

The Supplemental Restraint System (SRS) helps supplement the protection offered by the driver and front passenger seat belts by deploying an air bag from the center of the steering wheel and from the top of the right side of the instrument panel.

The air bag deploys when the vehicle is involved in a frontal crash of sufficient force up to 30 degrees off the centerline of the vehicle. To further absorb the crash energy there is a knee bolster located beneath the instrument panel for both the driver and passenger, and the steering column is collapsible.




827RS036

System Description

The SRS consists of the Sensing and Diagnostic Module (SDM), the driver air bag assembly, the SRS coil assembly, the passenger air bag assembly, and the "AIR BAG" warning lamp in the instrument cluster. The SDM, SRS coil assembly (driver side only), driver air bag assembly, passenger air bag assembly and connector wire make up the deployment loops. The function of the deployment loops is to supply current through air bag assembly, which will cause deployment of the air bags in the event of a frontal crash of sufficient force, up to 30 degrees off the centerline of the vehicle. The air bag


assemblies are only supplied enough current to deploy when the SDM detects vehicle velocity changes severe enough to warrant deployment.

The SDM contains a sensing device which converts vehicle velocity change to an electrical signal. The electrical signal generated is processed by the SDM and then compared to a value stored in memory. When the generated signal exceeds the stored value, the SDM will cause current to flow through the air bag assembly deploying the air bags.



D06RW002

SRS Component and Wiring Location View



810RW003

Legend

- (1) Battery
- (2) Relay & Fuse Box
- (3) Passenger Air Bag Assembly
- (4) SDM
- (5) Meter Assembly
- (6) SRS Coil Assembly
- (7) Driver Air Bag Assembly
- (8) Starter Switch
- (9) Fuse Box, SRS-1

Component Description

SDM (Sensing and Diagnostic Module)


WARNING: DURING SERVICE PROCEDURES, BE VERY CAREFUL WHEN HANDLING A SENSING AND DIAGNOSTIC MODULE (SDM). NEVER STRIKE OR JAR THE SDM. NEVER POWER UP THE SRS WHEN THE SDM IS NOT RIGIDLY ATTACHED TO THE VEHICLE. ALL SDM AND MOUNTING BRACKET FASTENERS MUST BE CAREFULLY TORQUED AND THE ARROW MUST BE POINTED TOWARD THE FRONT OF THE VEHICLE TO ENSURE PROPER OPERATION OF THE SRS. THE SDM COULD BE ACTIVATED WHEN POWERED WHILE NOT RIGIDLY

ATTACHED TO THE VEHICLE WHICH COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY.

The Sensing and Diagnostic Module (SDM) is designed to perform the following functions in the SRS:

1. **Energy Reserve** — The SDM maintains 24-Volt Loop Reserve (24VLR) energy supply to provide deployment energy when ignition voltage is lost in a frontal crash.
2. **Frontal Crash Detection** — The SDM monitors vehicle velocity changes to detect frontal crashes which are severe enough to warrant deployment.
3. **Air Bag Deployment** — When a frontal crash of sufficient force is detected, the SDM will cause enough current to flow through the air bag assembly to deploy the air bag.
4. **Malfunction Detection** — The SDM performs diagnostic monitoring of SRS electrical components and sets a diagnostic trouble code when a malfunction is detected.
5. **Frontal Crash Recording** — The SDM records information regarding SRS status during frontal crash.
6. **Malfunction Diagnosis** — The SDM displays SRS diagnostic trouble codes and system status information through the use of a scan tool.
7. **Driver Notification** — The SDM warns the vehicle driver of SRS malfunctions by controlling the "Air Bag" warning lamp.

The SDM is connected to the SRS wiring harness by a 24-pin connector. This harness connector uses a shorting clip across certain terminals in the contact area. This shorting clip connects the "AIR BAG" warning lamp to ground when the SDM harness connector is disconnected or CPA (Connector Position Assurance) is not inserted even if completely connected. This will cause the "AIR BAG" warning lamp to come "ON" steady whenever the ignition switch is at the ON or START positions with the SDM disconnected.




827RW023

“Air Bag” Warning Lamp

Ignition voltage is applied to the “AIR BAG” warning lamp when the ignition switch is at the ON or START positions. The SDM controls the lamp by providing ground with a lamp driver. The “AIR BAG” warning lamp is used in the SRS to do the following:

1. Verify lamp and SDM operation by flashing SEVEN (7) times when the ignition switch is first turned “ON”.
2. Warn the vehicle driver of SRS electrical system malfunctions which could potentially affect the operation of the SRS. These malfunctions could result in nondeployment in case of a frontal crash or deployment for conditions less severe than intended.

The “AIR BAG” warning lamp is the key to driver notification of SRS malfunctions. For proper lamp operation, refer to the “SRS Diagnostic System Check” in this section.




821RW116

SRS Coil Assembly

The SRS coil assembly consists of two current carrying coils. This is attached to the steering column and allow rotation of the steering wheel while maintaining continuous contact of the driver deployment loop to the driver air bag assembly.

There is a shorting clip on the yellow 2-pin connector near the base of steering column which connects the SRS coil to the SRS wiring harness.

The shorting clip shorts to the SRS coil and driver air bag assembly when the yellow 2-pin connector is disconnected. The circuit to the driver air bag assembly is shorted in this way to help prevent unwanted deployment of the air bag when servicing the steering column or other SRS components.



826RS071


Air Bag Assemblies

The air bag assembly consist of an inflatable air bag assembly and an inflator (a canister of gas-generating material and an initiating device). When the vehicle is in a frontal crash of sufficient force.

The SDM causes current flow through the deployment loops. Current passing through the inflator ignites the material in the air bag assembly. The gas produced from this reaction rapidly inflates the air bag assembly.

There is a shorting clip on the driver air bag assembly connector which connects the SRS coil assembly. The shorting clip shorts across the driver air bag assembly circuits when driver air bag assembly connector is disconnected.


The circuit to the driver air bag assembly is shorted in this way to help prevent unwanted deployment of the air bag when servicing the driver air bag assembly, the steering column or other SRS components.



827RX001

9J-6 SUPPLEMENTAL RESTRAINT SYSTEM

There is a shorting clip on the passenger air bag assembly connector which connects to the SRS harness. The shorting clip shorts across the passenger air bag assembly circuit when the passenger air bag assembly connector is disconnected. The circuit to the passenger air bag assembly is shorted in this way to help prevent unwanted deployment of the air bag when servicing the passenger air bag assembly, the instrument panel or other SRS components.




Legend

- (1) Passenger Air Bag Door
- (2) Passenger Air Bag Assembly
- (3) Passenger Air Bag Harness
- (4) Reinforcement
- (5) Cross Beam


Steering Column

The steering column absorbs energy and is designed to compress in a frontal crash to decrease the chance of injury to the driver.



Knee Bolster

The knee bolsters are used to absorb energy to protect knees and control the forward movement of the vehicle's front seat occupants during a frontal crash, by limiting leg movement.



Definition

Air Bag

An inflatable cloth cushion designed to deploy in certain frontal crashes. It supplements the protection offered by the seat belts by distributing the impact load more evenly over the vehicle occupant's head and torso.

Asynchronous

Performed in a nonperiodic fashion, (i. e., no defined time or interval).

(B+)

Battery voltage, (B+) The voltage available at the battery at the time of the indicated measurement. With the key "ON" and the engine not running, the system voltage will likely be between 12 and 12.5 volts. At idle the voltage may be 14 to 16 volts. The voltage could be as low as 10 volts during engine cranking.

Bulb Check

The SDM will cause the "AIR BAG" warning lamp to flash seven times and then go "OFF" whenever the ignition switch transitions to the ON position from any other ignition switch position and no malfunctions are detected.

"CONTINUOUS MONITORING"

Tests performed by the SDM on the SRS every 100 milliseconds while "Ignition 1" voltage is in the normal operating voltage range at the SDM.

Data Link Connector (DLC)

Formerly "DLC" a connector which allows communication with an external computer, such as a scan tool.

Datum Line

A base line parallel to the plane of the underbody or frame from which all vertical measurements originate.

Deploy

To inflate the air bag.

Deployment Loops

The circuits which supply current to the air bag assemblies to deploy the air bag.

Diagnostic Trouble Code (DTC)

Formerly "Code", a numerical designator used by the SDM to indicate specific SRS malfunctions.

Driver Current Source

An output of the SDM which applies current into the driver air bag assembly circuit during the "Initiator Assembly Resistance Test".

Driver Air Bag Assembly

An assembly located in the steering wheel hub consisting of an inflatable bag, an inflator and an initiator.

EEPROM

Electronically Erasable Programmable Read Only Memory. Memory which retains its contents when power is removed from the SDM.

Ignition Cycle

The voltage at the SDM "Ignition 1" inputs, with ignition switch "ON", is within the normal operating voltage range for at least ten seconds before turning ignition switch "OFF".

Ignition 1

A battery voltage (B+) circuit which is only powered with the ignition switch in the ON, or START positions.

Initiator

The electrical component inside the air bag assembly which, when sufficient current flows, sets off the chemical reaction that inflates the air bag.

"Initiator Assembly Resistance Test"

Tests performed once each ignition cycle when no malfunctions are detected during "Turn-ON" or "Continuous Monitoring." This test checks for the correct SDM configuration for the vehicle, shorts to "Ignition 1" in the deployment loops, high resistance or opens in the "Driver Side High", "Driver Side Low", "Passenger Side High" and "Passenger Side Low" circuits and measures the resistance of the inflator assembly consisting of: 1) Initiators, 2) SRS coil assembly (driver side only), 3) Connectors and associated wiring.

Normal Operating Voltage Range

The voltage measured between the SDM "Ignition 1" terminals and "Ground" terminals is between 9 and 16 volts.

Passenger Current Source

An output of the SDM which applies current into the passenger air bag assembly circuit during the "Initiator Assembly Resistance Test".

Passenger Air Bag Assembly

An assembly located in the right side of the instrument panel consisting of an inflatable bag, an inflator and an initiator.

Scan Tool

An external computer used to read diagnostic information from onboard computers via the data link connector.

SDM

Sensing and Diagnostic Module which provides reserve energy to the deployment loops, deploys the air bags when required and performs diagnostic monitoring of all SRS components.

Serial Data

Information representing the status of the SRS.

SRS

Supplemental Restraint System.

SRS Coil Assembly

An assembly of two current-carrying coils in the driver deployment loop that allows the rotation of the steering wheel while maintaining the continuous contact of the driver deployment loop to the driver air bag assembly.

SRS Wiring Harness

The wires and connectors that electrically connect the components in the SRS.

"Turn-ON"

Test which the SDM performs on the SRS once during each ignition cycle immediately after "Ignition 1" voltage is applied to the SDM and before "Continuous Monitoring".

Diagnosis

WARNING: TO AVOID DEPLOYMENT WHEN TROUBLESHOOTING THE SRS, DO NOT USE ELECTRICAL TEST EQUIPMENT SUCH AS A BATTERY-POWERED OR AC-POWERED VOLTMETER, OHMMETER, ETC., OR ANY TYPE OF ELECTRICAL EQUIPMENT OTHER THAN THAT SPECIFIED IN THIS MANUAL. DO NOT USE A NON-POWERED PROBE-TYPE TESTER. INSTRUCTIONS IN THIS MANUAL MUST BE FOLLOWED CAREFULLY, OTHERWISE PERSONAL INJURY MAY RESULT.

Diagnostic Trouble Codes

The "SRS Diagnostic System Check" must always be the starting point of any SRS diagnosis. The "SRS Diagnostic System Check" checks for proper "AIR BAG" warning lamp operation and checks for SRS diagnostic trouble codes using the scan tool.

1. Current diagnostic trouble codes – Malfunctions that are presently being detected. Current diagnostic trouble codes are stored in RAM (Random Access Memory).
2. History diagnostic trouble codes – All malfunctions detected since the last time the history memory was cleared. History diagnostic trouble codes are stored in EEPROM.

Scan Tool Diagnostics

A scan tool is used to read current and history diagnostic trouble codes and to clear all diagnostic trouble codes after a repair is completed. The scan tool must be updated to communicate with the SRS through a replaceable cartridge before it can be used for SRS diagnostics. To use the scan tool, connect it to the data link connector and turn the ignition switch "ON". The scan

tool reads serial data from the SDM "Serial Data" line terminal "24" to the data link connector terminal "9".


Use of Special Tools

WARNING: TO AVOID DEPLOYMENT WHEN TROUBLESHOOTING THE SRS, DO NOT USE ELECTRICAL TEST EQUIPMENT SUCH AS A BATTERY-POWERED OR AC-POWERED VOLTMETER, OHMMETER, ETC, OR ANY TYPE OF ELECTRICAL EQUIPMENT OTHER THAN THAT SPECIFIED IN THIS MANUAL. DO NOT USE A NON POWERED PROBE-TYPE TESTER. INSTRUCTIONS

IN THIS MANUAL MUST BE FOLLOWED CAREFULLY, OTHERWISE PERSONAL INJURY MAY RESULT. YOU SHOULD BE FAMILIAR WITH THE TOOLS LISTED IN THIS SECTION UNDER THE HANDLING SRS SPECIAL TOOLS.

You should be able to measure voltage and resistance. You should be familiar with proper use of a scan tool such as the Tech 2 Diagnostic Computer, SRS Driver/Passenger Load Tool J-41433, Connector Test Adapter Kit J-35616-A, and the DVM (Digital Multimeter) J-39200.

SRS Connector Body Face Views



D06RW003

Legend

- (1) SDM
- (2) Driver Air Bag Assembly
- (3) Passenger Air Bag Assembly

- (4) "Air Bag" Warning Lamp
- (5) SRS Coil Assembly
- (6) DLC

Repairs and Inspections Required After an Accident

NOTE: If any SRS components are damaged, they must be replaced. If SRS component mounting points are damaged, they must be replaced.

- Never use SRS parts from another vehicle. This does not include remanufactured parts purchased from an authorized dealer; they may be used for SRS repairs.

- Do not attempt to service the SDM, the SRS coil assembly, or the air bag assembly. Service of these items is by replacement only.
- Verify the part number of replacement air bag assembly.

CAUTION: Never use the air bag assembly from another vehicle and difference model year air bag assembly.

The air bag assembly has identification colors on the bar code label from '99 model as follows.

White color for driver air bag assembly.
Yellow color for passenger air bag assembly.
Use only the air bag assembly for Rodeo (UE) models.

CAUTION: Proper operation of the sensors and Supplemental Restraint System (SRS) requires that any repairs to the vehicle structure return it to the original production configuration. Deployment requires, at a minimum, replacement of the SDM, air bag assembly and dimensional inspection of the steering column. Any visible damage to the SDM mounting bracket (s) requires replacement, and the steering column must be dimensionally inspected, whether deployment occurred or not.

Accident With Deployment – Component Replacement and Inspections

Certain SRS components must be replaced or inspected for damage after a frontal crash involving air bag deployment. Those components are:

- Air bag assembly
- SDM

CAUTION: Refer to “SDM Replacement Guidelines” below for important information on SDM replacement in both deployment and non deployment crashes.

- SRS coil assembly—Inspect wiring and connector for any signs of scorching, melting, or damage due to excessive heat. Replace if damaged. Refer to SRS coil assembly in this section.

Accident With or Without Deployment—Component Inspection

Certain SRS and restraint system components must be inspected after any crash, whether the air bag deployed or not. Those components are:

- Steering column—Dimensionally inspect per “Checking Steering Column for Accident Damage” in 3 of this workshop manual.
- Knee bolsters and mounting points—Inspect for any distortion, bending, cracking, or other damage.
- I/P steering column reinforcement plate—Inspect for any distortion, bending, cracking, or other damage.
- I/P braces—Inspect for any distortion, bending, cracking, or other damage.
- Seat belts and mounting points—Refer to “Seat Belts” in 10 of this workshop manual.

SDM Replacement Guidelines

SDM replacement policy requires replacement of SDM, after crash involving air bag deployment when “SRS Warning Lamp” turn “ON”, “SRS Diagnosis” should be done according to “Section 9J1”.

Wiring Damage

If any SRS wire harness is damaged, it should be replaced. Don't repair SRS. It is replace only.

SRS Connector (Plastic Body And Terminal Metal Pin) Damage

If any connector or terminal in the SRS wire harness (except pigtails) is damaged, it should be replaced.

SRS Wire Pigtail Damage

If the wiring pigtail (a wire or wires attached directly to the device, not by a connector) is damaged, the entire component (with pigtail) must be replaced. Examples of “pigtail” components are the driver air bag assembly, the passenger air bag assembly, and the SRS coil assembly.

On-Vehicle Service

Service Precautions

WARNING: WHEN PERFORMING SERVICE ON OR AROUND SRS COMPONENTS OR SRS WIRING, FOLLOW THE PROCEDURES LISTED BELOW TO TEMPORARILY DISABLE THE SRS. FAILURE TO FOLLOW PROCEDURES COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY OR OTHERWISE UNNEEDED SRS REPAIRS.

The SDM in Driver—Passenger SRS can maintain sufficient voltage to cause a deployment for up to 15 seconds after the ignition switch is turned “OFF”, the battery is disconnected, or the fuse powering the SDM is removed.

Many of the service procedures require removal of the “SRS-1” fuse, and disconnection of the air bag assembly from the deployment loop to avoid an accidental deployment. If the air bag assembly is disconnected from the deployment loop as noted in the “Disabling the SRS” procedure that follows, service can begin immediately without waiting for the 15 second time period to expire.

Disabling The SRS

Removal

Turn the ignition switch to “lock” and remove key.

1. Remove SRS fuse SRS-1, from left dash side lower fuse block or disconnect battery.
2. Disconnect yellow 2-pin connector at the base of steering column.
3. Remove glove box assembly, Refer to “Passenger Air Bag Assembly Replacement” in section 9J-28.
4. Disconnect yellow 2-pin connector behind the glove box assembly.

CAUTION: With the “SRS-1” fuse removed and ignition switch “ON”, “AIR BAG” warning lamp will be “ON”. This is normal operation and does not indicate an SRS malfunction.

Enabling The SRS

Installation

CAUTION: Never use the air bag assembly from another vehicle and difference model year air bag assembly.

9J-10 SUPPLEMENTAL RESTRAINT SYSTEM

The air bag assembly has identification colors on the bar code label from '99 model as follows.

White color for driver air bag assembly.

Yellow color for passenger air bag assembly.

Use only the air bag assembly for Rodeo (UE) models.

Turn ignition switch to "LOCK" and remove key.

1. Connect yellow 2-pin connector passenger air bag assembly.
2. Install glove box assembly, refer to "Passenger Air Bag Assembly Replacement" in section 9J-28.
3. Connect yellow 2-pin connector at the base of steering column.
4. Install "AIR BAG" fuse SRS-1 to left dash side lower fuse block or connect battery.

Turn ignition switch to "ON" and verify that the "AIR BAG" warning lamp flashes seven times and then turns "OFF" If it does not operate as described, perform the "SRS Diagnostic System Check" in section 9J1-3.


Handling / Installation / Diagnosis

1. Air bag assembly should not be subjected to temperatures above 65°C (150°F).
2. Air bag assembly, and SDM should not be used if they have been dropped from a height of 100 centimeters (3.28 feet).
3. When a SDM is replaced, it must be oriented with the arrow on the sensor pointing toward the front of the vehicle. It is very important for the SDM to be located flat on the mounting surface, parallel to the vehicle datum line. It is important that the SDM mounting surface is free of any dirt or other foreign material.
4. Do not apply power to the SRS unless all components are connected or a diagnostic chart requests it, as this will set a diagnostic trouble code.
5. The "SRS Diagnostic System Check" must be the starting point of any SRS diagnostics. The "SRS Diagnostic System Check" will verify proper "AIR BAG" warning lamp operation and will lead you to the correct chart to diagnose any SRS malfunctions. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis, and incorrect parts replacement.

Air Bag Assembly Handling / Shipping / Scrapping



Live (Undeployed) Air Bag Assembly

Special care is necessary when handling and storing a live (undeployed) air bag assembly. The rapid gas generation produced during deployment of the air bag could cause the air bag assembly, or an object in front of the air bag assembly, to be thrown through the air in the unlikely event of an accidental deployment.



827RW009

WARNING: WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG OPENING IS POINTED AWAY FROM YOU. IN CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. NEVER CARRY THE AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF THE MODULE.



827RS044

Air Bag Assembly Shipping Procedure For Live (Undeployed) Air Bag Assemblies

Service personnel should refer to the latest Service Bulletins for proper SRS air bag assembly shipping procedures.

Deployed Air Bag Assembly

You should wear gloves and safety glasses. After the air bag assembly has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by products of the chemical reaction. Sodium hydroxide dust (similar to lye soap) is produced as a by product of the deployment reaction. The sodium hydroxide then quickly reacts with atmospheric moisture and is converted to sodium carbonate and sodium bicarbonate (baking soda). Therefore, it is unlikely that sodium hydroxide will be present.

Air Bag Assembly Scrapping Procedure

During the course of a vehicle's useful life, certain situations may arise which will necessitate the disposal of a live (undeployed) air bag assembly. This information covers proper procedures for disposing of a live air bag assembly.

Before a live air bag assembly can be disposed of, it must be deployed. A live air bag assembly must not be disposed of through normal refuse channels.

WARNING: FAILURE TO FOLLOW PROPER SUPPLEMENTAL RESTRAINT SYSTEM (SRS) AIR BAG ASSEMBLY DISPOSAL PROCEDURES CAN RESULT IN AIR BAG DEPLOYMENT WHICH MAY CAUSE PERSONAL INJURY. AN UNDEPLOYED AIR BAG ASSEMBLY MUST NOT BE DISPOSED OF THROUGH NORMAL REFUSE CHANNELS. THE UNDEPLOYED AIR BAG ASSEMBLY CONTAINS SUBSTANCES THAT CAN CAUSE SEVERE ILLNESS OR PERSONAL INJURY IF THE SEALED CONTAINER IS DAMAGED DURING DISPOSAL. DISPOSAL IN ANY MANNER INCONSISTENT WITH PROPER PROCEDURES MAY BE A VIOLATION OF FEDERAL, STATE, AND / OR LOCAL LAW.

In situations which require deployment of a live air bag assembly module, deployment may be accomplished inside or outside the vehicle. The method employed depends upon the final disposition of the particular vehicle, as noted in "Deployment Outside Vehicle" and "Deployment Inside Vehicle" in this section.

Deployment Outside Vehicle (Driver Air Bag Assembly)

Deployment outside the vehicle is proper when the vehicle is to be returned to service. This includes, for example, situations in which the vehicle will be returned to useful service after a functionally or cosmetically deficient air bag assembly is replaced. Deployment and disposal of a malfunctioning air bag assembly is, of course, subject to any required retention period.

For deployment of a live (undeployed) air bag assembly outside the vehicle, the deployment procedure must be


followed exactly. Always wear safety glasses during this deployment procedure until a deployed air bag assembly is scrapped or until an undeployed air bag assembly is shipped. Before performing the procedures you should be familiar with servicing the SRS and with proper handling of the air bag assembly. Procedures should be read fully before they are performed.

The following procedure requires use of J-41434 SRS deployment harness with appropriate pigtail adapter. Do not attempt procedure without J-41434 adapter.

WARNING: FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED MAY RESULT IN PERSONAL INJURY. NEVER CONNECT DEPLOYMENT HARNESS TO ANY POWER SOURCE BEFORE CONNECTING DEPLOYMENT HARNESS TO THE DRIVER AIR BAG ASSEMBLY. DEPLOYMENT HARNESS SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. WEAR SAFETY GLASSES THROUGHOUT THIS ENTIRE DEPLOYMENT AND DISPOSAL PROCEDURE.

NOTE: This information applies only to driver air bag assembly. Refer to "Deployment Outside Vehicle (Passenger Air Bag Assembly)" in this section for information on passenger air bag assembly scrapping.

1. Turn ignition switch to "LOCK", remove key and put on safety glasses.
2. Inspect J-41434 SRS Deployment Harness and appropriate pigtail adapter for damage. If harness or pigtail adapter is damaged, discard and obtain a replacement.
3. Short the two SRS deployment harness leads together by fully seating one banana plug into the other. SRS deployment harness shall remain shorted and not be connected to a power source until the air bag is to be deployed.




827RS004

9J-12 SUPPLEMENTAL RESTRAINT SYSTEM


4. Connect the appropriate pigtail adapter to the SRS deployment harness.
5. Remove the driver air bag assembly from vehicle. Refer to Inflator Module Removal in this Section 9J-3.

WARNING: WHEN STORING A LIVE AIR BAG ASSEMBLY OR WHEN LEAVING A LIVE AIR BAG ASSEMBLY UNATTENDED ON A BENCH OR OTHER SURFACE, ALWAYS FACE THE AIR BAG AND TRIM COVER UP AND AWAY FROM THE SURFACE. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. FAILURE TO FOLLOW PROCEDURES MAY RESULT IN PERSONAL INJURY.

6. Place the driver air bag assembly on a work bench or other surface away from all loose or flammable objects with its trim cover facing up, away from the surface.



7. Clear a space on the ground about 183 cm (six feet) in diameter where the driver air bag assembly is to be deployed. A paved, outdoor location where there is no activity is preferred. If an outdoor location is not available, a space on the shop floor where there is no activity and sufficient ventilation is recommended. Ensure no loose or flammable objects are within the deployment area.



8. Place the driver air bag assembly, with its trim cover facing up, on the ground in the space just cleared.
9. Stretch the SRS deployment harness and pigtail adapter from the driver air bag assembly to its full length.
10. Place a power source near the shorted end of the SRS deployment harness. Recommended application: 12 volts minimum, 2 amps minimum. A vehicle battery is suggested.
11. Connect the driver air bag assembly to the pigtail adapter on the SRS deployment harness. Deployment harness shall remain shorted and not be connected to a power source until the air bag is to be deployed. The driver air bag assembly will immediately deploy the air bag when a power source is connected to it.

NOTE: Ensure that the pigtail adapter is firmly seated into the driver air bag assembly connector. Failure to fully seat the connectors may leave the shorting bar located in the driver air bag assembly connector functioning (shorted) and may result in non deployment of the driver air bag assembly.

12. Verify that the area around the driver air bag assembly is clear of all people and loose or flammable objects.
13. Verify that the driver air bag assembly is resting with its trim cover facing up.
14. Notify all people in the immediate area that you intend to deploy the driver air bag. The deployment will be accompanied by a substantial noise which may startle the uninformed.
15. Separate the two banana plugs on the SRS deployment harness.

NOTE: When the air bag deploys, the driver air bag assembly may jump about 30 cm (one foot) vertically. This is a normal reaction of the driver air bag to the force of the rapid gas expansion inside the air bag.

NOTE: When the air bag deploys, the rapid gas expansion will create a substantial noise. Notify all

people in the immediate area that you intend to deploy the driver air bag.

WARNING: DEPLOYMENT HARNESS SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. CONNECTING THE DEPLOYMENT HARNESS TO THE POWER SOURCE SHOULD ALWAYS BE THE LAST STEP IN THE AIR BAG ASSEMBLY DEPLOYMENT PROCEDURE. FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED MAY RESULT IN PERSONAL INJURY.

16. Connect the SRS deployment harness wires to the power source to immediately deploy the driver air bag. Recommended application: 12 volts minimum, 2 amps minimum. A vehicle battery is suggested.
17. Disconnect the SRS deployment harness from the power source.
18. Short the two SRS deployment harness leads together by fully seating one banana plug into the other.
19. In the unlikely event that the driver air bag assembly did not deploy after following these procedures, proceed immediately with Steps 24 through 26. If the driver air bag assembly did deploy, proceed with Steps 20 through 23.
20. Put on a pair of shop gloves and safety glasses to protect your hands and eyes from possible irritation and heat when handling the deployed driver air bag assembly. After the driver air bag assembly has been deployed, the surface of the air bag may contain a powdery residue. This power consists primarily of cornstarch (used to lubricate the bag as it inflates) and by products of the chemical reaction. Sodium hydroxide dust (similar to lye soap) is produced as a by product of the deployment reaction. The sodium hydroxide then quickly reacts with the atmospheric moisture and is converted to sodium carbonate and sodium bicarbonate (baking soda). Therefore, it is unlikely that sodium hydroxide will be present after deployment.

WARNING: SAFETY PRECAUTIONS MUST BE OBSERVED WHEN HANDING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE METAL SURFACES OF THE AIR BAG ASSEMBLY WILL BE VERY HOT. ALLOW THE INFLATOR MODULE TO COOL BEFORE HANDLING ANY METAL PORTION OF IT. DO NOT PLACE THE DEPLOYED AIR BAG ASSEMBLY NEAR ANY FLAMMABLE OBJECTS. FAILURE TO FOLLOW PROCEDURES MAY RESULT IN FIRE OR PERSONAL INJURY.

AFTER A DRIVER AIR BAG ASSEMBLY HAS BEEN DEPLOYED, THE METAL CANISTER AND SURROUNDING AREAS OF THE DRIVER AIR BAG ASSEMBLY WILL BE VERY HOT. DO NOT TOUCH THE METAL AREAS OF THE DRIVER AIR BAG ASSEMBLY FOR ABOUT TEN MINUTES AFTER DEPLOYMENT. IF THE DEPLOYED DRIVER AIR BAG ASSEMBLY MUST BE MOVED BEFORE IT IS COOL,

WEAR GLOVES AND HANDLE BY THE AIR BAG OR TRIM COVER.

21. Disconnect the pigtail adapter from the driver air bag assembly as soon after deployment as possible. This will prevent damage to the pigtail adapter or SRS deployment harness due to possible contact with the hot driver air bag assembly canister. The pigtail adapter can be reused. They should, however, be inspected for damage after each deployment and replaced if necessary.
22. Dispose of the deployed driver air bag assembly through normal refuse channels after it has cooled for at least 30 minutes.
23. Wash your hands with mild soap and water afterward.

NOTE: The remaining steps are to be followed in the unlikely event that the driver air bag assembly did not deploy after following these procedures.

24. Ensure that the SRS deployment harness has been disconnected from the power source and that its two banana plugs have been shorted together by fully seating one banana plug into the other.
25. Disconnect the pigtail adapter from the driver air bag assembly.

WARNING: WHEN STORING A LIVE AIR BAG ASSEMBLY OR WHEN LEAVING A LIVE INFLATOR MODULE UNATTENDED ON A BENCH OR OTHER SURFACE, ALWAYS FACE THE BAG AND TRIM COVER UP AND AWAY FROM THE SURFACE. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. FAILURE TO FOLLOW PROCEDURES MAY RESULT IN PERSONAL INJURY.

26. Temporarily store the driver air bag assembly with its trim cover facing up, away from the surface upon which it rests.

Deployment Outside Vehicle (Passenger Air Bag Assembly)

WARNING: FAILURE TO FOLLOW PROPER SRS AIR BAG ASSEMBLY DISPOSAL PROCEDURES CAN RESULT IN AIR BAG DEPLOYMENT WHICH MAY CAUSE PERSONAL INJURY. UNDEPLOYED AIR BAG ASSEMBLIES MUST NOT BE DISPOSED OF THROUGH NORMAL REFUSE CHANNELS. THE UNDEPLOYED AIR BAG ASSEMBLY CONTAINS SUBSTANCES THAT CAN CAUSE SEVERE ILLNESS OR PERSONAL INJURY IF THE SEALED CONTAINER IS DAMAGED DURING DISPOSAL. DISPOSAL IN ANY MANNER INCONSISTENT WITH PROPER PROCEDURES MAY BE A VIOLATION OF FEDERAL, STATE AND/OR LOCAL LAWS.

Deployment out of the vehicle is proper when the vehicle is to be returned to service. This includes, for example, situations in which a functionally or cosmetically deficient air bag assembly is replaced. Deployment and disposal of an air bag assembly is, of course, subject to any required retention period.

For deployment of a live air bag assembly out of the vehicle, the deployment procedure must be followed exactly. ALWAYS wear safety glasses during this

9J-14 SUPPLEMENTAL RESTRAINT SYSTEM


deployment procedure until the deployed air bag assembly is scrapped. Before performing the procedures, you should be familiar with servicing the SRS system and with proper handling of the air bag assembly. Procedures should be read fully before they are performed.

The following procedure requires use of J-42986 SRS Deployment Harness with the appropriate pigtail adapter. The procedure also requires the use of J-41497 Passenger Side SRS Module Deployment Fixture. Do not attempt this procedure without J-42986 and fixture J-41497.


WARNING: FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED MAY RESULT IN PERSONAL INJURY. NEVER CONNECT DEPLOYMENT HARNESS TO ANY POWER SOURCE BEFORE CONNECTING DEPLOYMENT HARNESS TO THE AIR BAG ASSEMBLY. DEPLOYMENT HARNESS SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. WEAR SAFETY GLASSES THROUGHOUT THIS ENTIRE DEPLOYMENT AND DISPOSAL PROCEDURE.

NOTE: This information applies only to passenger air bag assembly. Information for disposing of a live driver air bag assembly can be found in "Deployment Outside Vehicle" (Driver Air Bag Assembly) in this section.

1. Turn ignition switch to "LOCK" remove key, and put on safety glasses.
2. Inspect J-41434 SRS Deployment Harness and appropriate pigtail adapter for damage. If harness or pigtail is damaged, discard and obtain a replacement.
3. Short the two SRS Deployment Harness leads together by fully seating one banana plug into the other. The SRS Deployment Harness shall remain shorted and not be connected to a power source until the air bag is to be deployed.



4. Connect the appropriate pigtail adapter to the SRS Deployment Harness



5. Remove passenger air bag assembly from vehicle. Refer to "Passenger Air Bag Assembly Removal" in this Section.
6. Clear a space on the ground approximately 185 cm (six feet) in diameter where the fixture with attached air bag assembly is to be placed for deployment. A paved outdoor location where there is no activity is preferred. If an outdoor location is not available, a space on the shop floor where there is no activity and sufficient ventilation is recommended. Ensure that no loose or flammable objects are within the deployment area.
7. Place the J-41497 on the bench vice. This is necessary to provide sufficient stabilization of the fixture during deployment.
8. Attach the passenger air bag assembly in the J-41497. Air bag assembly must be mounted such that the bag will deploy upward. **SECURELY HAND-TIGHTEN ALL FASTENERS PRIOR TO DEPLOYMENT.**
9. Stretch the SRS Deployment Harness and pigtail adapter from the air bag assembly to its full length.
10. Place a power source near the shorted end of the SRS deployment harness. (Recommended application: 12 volts minimum, 2 amps minimum. A vehicle battery is suggested.)
11. Connect the air bag assembly to the pigtail adapter on the SRS deployment harness. The SRS Deployment Harness shall remain shorted and not be connected to a power source until the air bag is to be deployed. The air bag assembly will immediately deploy the air bag when a power source is connected to it.

NOTE: Ensure that the pigtail adapter is firmly seated into the air bag assembly connector. Failure to fully seat the connectors may leave the shorting bar located in the air bag assembly connector functioning (shorting the deployment circuit) and may result in non deployment of the air bag assembly.

12. Verify that the area around the passenger air bag assembly is clear of all people and loose or flammable objects.

13. Verify that the passenger air bag assembly is firmly and properly in J-41497.
14. Notify all people in the immediate area of your intention to deploy the passenger air bag assembly. The deployment will be accompanied by a substantial noise which may startle the uninformed.
15. Separate the two banana plugs on the SRS deployment harness.

NOTE: When air bag deploys, the rapid gas expansion will create a substantial noise. Notify all people in the immediate area that you intend to deploy the air bag assembly.

WARNING: DEPLOYMENT HARNESS SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. CONNECTING THE DEPLOYMENT HARNESS TO THE POWER SOURCE SHOULD ALWAYS BE THE LAST STEP IN THE AIR BAG ASSEMBLY DEPLOYMENT PROCEDURE. FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED MAY RESULT IN PERSONAL INJURY.

16. Connect the SRS deployment harness wires to the power source to immediately deploy the air bag assembly. Recommended application : 12 volts minimum, 2 amps minimum. A vehicle battery is suggested.
17. Disconnect the SRS deployment harness from the power source.
18. Short the two SRS deployment harness leads together by fully seating one banana plug into the other.
19. In the unlikely event that the passenger air bag assembly did not deploy after following these procedures, proceed immediately with Steps 24 through 26. If the passenger air bag assembly deployed as intended, proceed with Steps 20 through 23.
20. Put on a pair of shop gloves and safety glasses to protect your hands and eyes from possible irritation and heat when handling the deployed air bag assembly. After the air bag assembly has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by products of the chemical reaction. Sodium hydroxide dust (similar to lye soap) is produced as a by product of the deployment reaction. The sodium hydroxide quickly reacts with the atmospheric moisture and is converted to sodium carbonate and sodium bicarbonate (baking soda). Therefore, it is unlikely that sodium hydroxide will be present for very long after deployment.

WARNING: SAFETY PRECAUTIONS MUST BE OBSERVED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE METAL SURFACES OF THE AIR BAG ASSEMBLY WILL BE HOT. ALLOW THE AIR BAG ASSEMBLY TO COOL BEFORE HANDLING ANY METAL PORTION

OF IT. DO NOT PLACE THE DEPLOYED INFLATOR MODULE NEAR ANY FLAMMABLE OBJECTS. FAILURE TO FOLLOW PROCEDURES MAY RESULT IN FIRE OR PERSONAL INJURY. AFTER AN AIR BAG ASSEMBLY HAS BEEN DEPLOYED, THE METAL CANISTER AND SURROUNDING AREAS OF THE AIR BAG ASSEMBLY WILL BE HOT. DO NOT TOUCH THE METAL AREAS OF THE AIR BAG ASSEMBLY FOR ABOUT THIRTY MINUTES AFTER DEPLOYMENT. IF THE DEPLOYED AIR BAG ASSEMBLY MUST BE MOVED BEFORE IT IS COOL, WEAR GLOVES AND HANDLE BY THE AIR BAG ITSELF.

21. Disconnect the pigtail adapter from the air bag assembly as soon after deployment as possible to avoid damage to the pigtail adapter or SRS deployment harness from contacting the hot air bag assembly canister. The pigtail adapter and SRS deployment harness are designed to be reused. They should, however, be inspected for damage after each deployment and replaced if necessary.
 22. Dispose of the deployed air bag assembly through normal refuse channels after it has cooled for at least 30 minutes.
 23. Wash your hands with mild soap and water afterward.
- NOTE: The remaining steps are to be followed in the unlikely event that the air bag assembly did not deploy after following the above procedures.
24. Ensure that the SRS deployment harness has been disconnected from the power source and that its two banana plugs have been shorted together by fully seating one banana plug into the other.
 25. Disconnect the pigtail adapter from the air bag assembly.

WARNING: WHEN STORING A LIVE AIR BAG ASSEMBLY OR WHEN LEAVING A LIVE AIR BAG ASSEMBLY UNATTENDED ON A BENCH OR OTHER SURFACE, ALWAYS FACE THE BAG UP AND AWAY FROM THE SURFACE. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. FAILURE TO FOLLOW PROCEDURES MAY RESULT IN PERSONAL INJURY.

26. Temporarily store the air bag assembly with the bag facing up, away from the surface upon which it rests.

Deployment Inside Vehicle (Vehicle Scrampling Procedure)

Deployment inside vehicle is proper when the vehicle is to be destroyed or salvaged for component parts. This includes, but is not limited to, the following situations:

1. The vehicle has completed its useful life.
2. The vehicle has been damaged beyond repair in a non deployment type accident.
3. The vehicle has been stripped or damaged beyond repair in a theft.
4. The vehicle will be salvaged for component parts to be used on a vehicle with a different Vehicle Identification Number (VIN) as opposed to being rebuilt as same VIN. Never use SRS components from another vehicle.

WARNING: FAILURE TO FOLLOW PROPER SRS AIR BAG ASSEMBLY DISPOSAL PROCEDURES CAN RESULT IN AIR BAG DEPLOYMENT WHICH MAY CAUSE PERSONAL INJURY. UNDEPLOYED AIR BAG ASSEMBLIES MUST NOT BE DISPOSED OF THROUGH NORMAL REFUSE CHANNELS. THE UNDEPLOYED AIR BAG ASSEMBLY CONTAINS SUBSTANCES THAT CAN CAUSE SEVERE ILLNESS OR PERSONAL INJURY IF THE SEALED CONTAINER IS DAMAGED DURING DISPOSAL. DISPOSAL IN ANY MANNER INCONSISTENT WITH PROPER PROCEDURES MAY BE A VIOLATION OF FEDERAL, STATE AND/OR LOCAL LAWS.

1. Turn ignition switch to "LOCK", remove key and put on safety glasses.
2. Remove all loose objects from front seats.
3. Disconnect SRS coil assembly, yellow 2-pin connector located at the base of the steering column.
4. Cut the SRS coil assembly yellow 2-pin harness connector from the vehicle leaving at least 16 cm (six inches) of wire at the connector.
5. Strip 13 mm (1/2 inch) of insulation from yellow-green and yellow-black wire lead of the connector.
6. Cut two 900 cm (30 feet) deployment wires from 0.8 mm² (18 gauge) or thicker multi-strand wire. These wires will be used to fabricate the driver deployment harness.
7. Strip 13 mm (1/2 inch) of insulation from both ends of the wires cut in the previous step.
8. Short the wires by twisting together one end from each. Deployment wires shall remain shorted and not be connected to a power source until the air bag is to be deployed.

WARNING: FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED COULD RESULT IN PERSONAL INJURY. NEVER CONNECT DEPLOYMENT WIRES TO ANY POWER SOURCE BEFORE CONNECTING DEPLOYMENT WIRES TO THE AIR BAG ASSEMBLY LEADS. DEPLOYMENT WIRES SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. WEAR SAFETY GLASSES THROUGHOUT THIS ENTIRE DEPLOYMENT AND DISPOSAL PROCEDURE.

9. Twist together one connector wire lead to one deployment wire. The connection should be mechanically secure.
10. Bend twisted connection made in the previous step flat and wrap tightly with electrical tape to insulate and secure.
11. Twist together, bend and tape the remaining connector wire lead to the remaining deployment wire.
12. Connect the deployment harness to the driver air bag assembly, yellow 2-pin connector at the base of the steering column. Route deployment harness out the driver side of the vehicle.

WARNING: DEPLOYMENT WIRES SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED.

THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT.

CONNECTING THE DEPLOYMENT WIRES TO THE POWER SOURCE SHOULD ALWAYS BE THE FINAL STEP IN THE AIR BAG ASSEMBLY DEPLOYMENT PROCEDURE.

FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED COULD RESULT IN PERSONAL INJURY.

13. Disconnect passenger air bag assembly, yellow 2-pin connector located behind glove box assembly.
14. Cut the passenger air bag assembly harness connector from the vehicle leaving at least 16 cm (six inches) of wire at the connector.
15. Strip 13 mm (1/2 inch) of insulation from yellow-green and yellow-red wire lead of the connector.
16. Cut two 900 cm (30 feet) deployment wires from 0.8 mm² (18 gauge) or thicker multi-strand wire. These wires will be used to fabricate the passenger deployment harness.
17. Strip 13 mm (1/2 inch) of insulation from both ends of the wires cut in the previous step.
18. Short the wires by twisting together one end from each. Deployment wires shall remain shorted and not be connected to a power source until the air bag is to be deployed.

WARNING: FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED COULD RESULT IN PERSONAL INJURY. NEVER CONNECT DEPLOYMENT WIRES TO ANY POWER SOURCE BEFORE CONNECTING DEPLOYMENT WIRES TO THE AIR BAG ASSEMBLY LEADS. DEPLOYMENT WIRES SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN SAFETY GLASSES THROUGHOUT THIS ENTIRE DEPLOYMENT AND DISPOSAL PROCEDURE.

19. Twist together one connector wire lead to one deployment wire. The connection should be mechanically secure.
20. Bend twisted connection made in the previous step flat and wrap tightly with electrical tape to insulate and secure.
21. Twist together, bend and tape the remaining connector wire lead to the remaining deployment wire.
22. Connect the deployment harness to the passenger air bag assembly, yellow 2-pin connector located behind the glove box assembly. Route deployment harness out the passenger side of the vehicle.

WARNING: DEPLOYMENT WIRES SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. CONNECTING THE

DEPLOYMENT WIRES SHOULD ALWAYS BE THE FINAL STEP IN THE AIR BAG ASSEMBLY DEPLOYMENT PROCEDURE. FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED COULD RESULT IN PERSONAL INJURY.

23. Verify that the inside of the vehicle and the area surrounding the vehicle are clear of all people and loose or flammable objects.
24. Stretch the driver and passenger deployment harness to their full length.
25. Completely cover windshield area and front door window openings with a drop cloth, blanket or similar item. This reduces the possibility of injury due to possible fragmentation of the vehicle's glass or interior.
26. Notify all people in the immediate area that you intend to deploy the air bags. The deployment will be accompanied by a substantial noise which may startle the uninformed.
27. Separate the two ends of the driver deployment harness wires.

WARNING: DEPLOYMENT WIRES SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. CONNECTING THE DEPLOYMENT WIRES TO THE POWER SOURCE SHOULD ALWAYS BE THE FINAL STEP IN THE AIR BAG ASSEMBLY DEPLOYMENT PROCEDURE. FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED COULD RESULT IN PERSONAL INJURY.

NOTE: When the air bag deploys, the rapid gas expansion will create a substantial noise. Notify all people in the immediate area that you intend to deploy the air bags.

28. Connect the driver deployment harness wires to a power source to immediately deploy the driver air bag assembly. Recommended application: 12 volts minimum, 2 amps minimum. A vehicle battery is suggested.
29. Separate the two ends of the passenger deployment harness wires.

WARNING: DEPLOYMENT WIRES SHALL REMAIN SHORTED AND NOT BE CONNECTED TO A POWER SOURCE UNTIL THE AIR BAG IS TO A POWER SOURCE UNTIL THE AIR BAG IS TO BE DEPLOYED. THE AIR BAG ASSEMBLY WILL IMMEDIATELY DEPLOY THE AIR BAG WHEN A POWER SOURCE IS CONNECTED TO IT. CONNECTING THE DEPLOYMENT WIRES TO THE POWER SOURCE SHOULD ALWAYS BE THE FINAL STEP IN THE AIR BAG ASSEMBLY DEPLOYMENT PROCEDURE. FAILURE TO FOLLOW PROCEDURES IN THE ORDER LISTED COULD RESULT IN PERSONAL INJURY.

30. Connect the passenger deployment harness wires to a power source to immediately deploy the passenger air bag assembly. Recommended application: 12 volts minimum, 2 amps minimum. A vehicle battery is suggested. Put on a pair of shop gloves and safety glasses to protect your hands and eyes from possible irritation and heat when handling the deployed air bag assembly. After an air bag assembly has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by products of the chemical reaction. Sodium hydroxide dust (similar to lye soap) is produced as a by product of the deployment reaction. The sodium hydroxide then quickly reacts with atmospheric moisture and is converted to sodium carbonate and sodium bicarbonate (baking soda). Therefore, it is unlikely that sodium hydroxide will be present after deployment.

WARNING: SAFETY PRECAUTIONS MUST BE OBSERVED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE METAL SURFACES OF THE AIR BAG ASSEMBLY WILL BE VERY HOT. ALLOW THE AIR BAG ASSEMBLY TO COOL BEFORE HANDLING ANY METAL PORTION OF IT. DO NOT PLACE THE HOT DEPLOYED AIR BAG ASSEMBLY NEAR ANY FLAMMABLE OBJECTS. FAILURE TO FOLLOW PROCEDURES COULD RESULT IN FIRE OR PERSONAL INJURY.

After an air bag assembly has been deployed, the metal canister and surrounding areas of the air bag assembly will be very hot. Do not touch the metal areas of the air bag assembly for about 30 minutes after deployment. If the deployed air bag assembly must be moved before it is cool, wear gloves and handle by the air bag or trim cover.

31. Short the driver deployment harness wires by twisting together one end from each. Repeat this procedure for the passenger deployment harness.
32. Carefully remove drop cloth from vehicle and clean off any fragments or discard drop cloth entirely.
33. Disconnect driver deployment harness and passenger deployment harness from vehicle and discard.
34. In the unlikely event that either or both of the air bag assemblies did not deploy after following these procedures, proceed immediately with Steps 36 through 37. If the air bag assembly deployed, proceed to step 35.
35. With both air bags deployed, the vehicle may be scrapped in the same manner as a non-SRS equipped vehicle.

NOTE: The remaining steps are to be followed in the unlikely event that the air bag assembly did not deploy after following these procedures.

36. Remove the undeployed air bag assembly (s) from the vehicle. For driver air bag assembly refer to in the "Passenger Air Bag Assembly Removal" in this section 9J-28.

WARNING: WHEN STORING A LIVE AIR BAG ASSEMBLY OR WHEN LEAVING A LIVE AIR BAG

9J-18 SUPPLEMENTAL RESTRAINT SYSTEM

ASSEMBLY UNATTENDED ON A BENCH OR OTHER SURFACE, ALWAYS FACE THE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. FAILURE TO FOLLOW PROCEDURES COULD RESULT IN PERSONAL INJURY.

37. Temporarily store the air bag assembly with the air bag opening facing up, away from the surface upon which it rests.

Deployed Air Bag Assembly Handling

Put on a pair of shop gloves and safety glasses to protect your hands and eyes from possible irritation and heat when handling the deployed air bag assembly.

After the air bag assembly has been deployed, the surface of the air bag may contain a powdery residue. This powder consists primarily of cornstarch (used to lubricate the bag as it inflates) and by products of the chemical reaction. Sodium hydroxide dust (similar to lye soap) is produced as a by product of the deployment reaction. The sodium hydroxide then quickly reacts with atmospheric moisture and is converted to sodium carbonate and sodium bicarbonate (baking soda). Therefore, it is unlikely that sodium hydroxide will be present after deployment.

Special Tools

WARNING: TO AVOID DEPLOYMENT WHEN TROUBLESHOOTING THE SRS, DO NOT USE ELECTRICAL TEST EQUIPMENT SUCH AS A BATTERY-POWERED OR AC-POWERED VOLTMETER, OHMMETER, ETC., OR ANY TYPE OF ELECTRICAL EQUIPMENT OTHER THAN THAT SPECIFIED IN THIS MANUAL. DO NOT USE A NON POWERED PROBE-TYPE TESTER. INSTRUCTIONS IN THIS MANUAL MUST BE FOLLOWED CAREFULLY, OTHERWISE PERSONAL INJURY MAY RESULT.

J-41433 SRS Driver/Passenger Load Tool


The SRS Driver/Passenger Load Tool J-41433 is used only when called for in this section. It is used as a diagnostic aid and safety device to prevent inadvertent air bag assembly deployment.

The load tool has four yellow connectors attached to its case.

The three small connectors are electrically functional and serve as resistive load substitutions.

No more than two connectors are used at any time. One of the small connectors is used to substitute for the load of the driver air bag assembly when it is connected at the top of the column to the SRS coil assembly. Another small connector is used to substitute for the load of the driver air bag assembly and the SRS coil assembly when it is connected at the base of the column to the SRS wiring harness. The third small connector is used to substitute for the load of the passenger air bag assembly when connected to the passenger air bag assembly harness connector.


By substituting the resistance of the load tool when called for, a determination can be made as to whether an inflator circuit component is causing system malfunction and which component is causing the malfunction. The load tool should be used only when specifically called for in the diagnostic procedures.



901RS146

J-39200 DVM


The J-39200 DVM is the preferred DVM for use in SRS diagnosis and repair. However, J-34029-A may be used if J-39200 is not available. No other DVMs are approved for SRS diagnosis and repair.



901RS153

Scan Tool

The Tech 2 is used to read and clear SRS Diagnostic Trouble Codes (DTCs). Refer to the Tech 2 Operator's Manual for specific information on how to use the Tech 2.



901RW176

J-35616-A Connector Test Adapter Kit


The J-35616-A Connector Test Adapter Kit must be used whenever a diagnostic procedure requests checking or probing a terminal. Using the appropriate adapter will ensure that no damage to the terminal will occur from the DVM probe, such as spreading or bending. The adapter will also give an idea of whether contact tension is sufficient, helping to find an open or intermittent open due to poor terminal contact.



901RS151

J-42986 SRS Deployment Tool

The J-42986 SRS Deployment Tool must be used for deployment of the undeployed air bag.




901RW106

9J-20 SUPPLEMENTAL RESTRAINT SYSTEM

J-42987 SRS Adapter For Load Tool


The J-42987 SRS Adapter be used for connect previous load tool to new SRS system when inspect SRS system harness.



901RW107

J-41497 SRS Deployment Fixture


The J-41497 SRS Deployment Fixture must be used for deployment of the undeployed passenger side air bag.



901RW088

Tech 2 Scan Tool

From 1998 RODEO (UE), dealer service departments are recommended to use Tech 2. Please refer to Tech 2 scan tool user guide.



901RW180


Legend

- | | |
|--------------------------------|-----------------------|
| (1) PCMCIA Card | (3) SAE 16/19 Adaptor |
| (2) RS 232 Loop Back Connector | (4) DLC Cable |
| | (5) Tech-2 |

9J-22 SUPPLEMENTAL RESTRAINT SYSTEM

Getting Started

- Before operating the Isuzu PCMCIA card with the Tech 2, the following steps must be performed:
 1. The Isuzu 98 System PCMCIA card (1) inserts into the Tech 2 (5).
 2. Connect the SAE 16/19 adapter (3) to the DLC cable (4).
 3. Connect the DLC cable to the Tech 2 (5)
 4. Make sure the vehicle ignition is off.
 5. Connect the Tech 2 SAE 16/19 adapter to the vehicle DLC.




6. The vehicle ignition turns on.
7. Verify the Tech 2 power up display.




NOTE: The RS232 loop back connector is only to use for diagnosis of Tech 2 and refer to user guide of the Tech 2.

Operating Procedure

The power up screen is displayed when you power up the tester with the Isuzu systems PCMCIA card. Follow the operating procedure below.





06GRW013

Service Precaution

CAUTION: When fasteners are removed, always reinstall them at the same location from which they were removed. If a fastener needs to be replaced, use the correct part number fastener for that application. If the correct part number fastener is not available, a fastener of equal size and strength (or stronger) may be used. Fasteners that are not reused, and those requiring thread locking compound will be called out. The correct torque value must be used when installing fasteners that require it. If the above conditions are not followed, parts or system damage could result.

WARNING: WHEN PERFORMING SERVICE ON OR AROUND SRS COMPONENTS OR SRS WIRING, FOLLOW THE PROCEDURES LISTED BELOW TO TEMPORARILY DISABLE THE SRS. FAILURE TO FOLLOW PROCEDURES COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY OR OTHERWISE UNNEEDED SRS REPAIRS.

The SDM in Driver–Passenger SRS can maintain sufficient voltage to cause a deployment for up to 15 seconds after the ignition switch is turned “OFF,” the battery is disconnected, or the fuse powering the SDM is removed.

Many of the service procedures require removal of the “SRS–1” fuse, and disconnection of the air bag assembly from the deployment loop to avoid an accidental deployment. If the air bag assembly is disconnected from the deployment loop as noted in the “Disabling the SRS” procedure that follows, service can begin immediately without waiting for the 15 second time period to expire.

Disabling The SRS

Removal

Turn the ignition switch to “OFF” and turn the steering wheel so that the vehicle’s wheels are pointing straight ahead.

1. Remove SRS fuse SRS–1, from left dash side lower fuse block or disconnect battery.
2. Disconnect yellow 2–pin connector at the base of steering column.
3. Remove glove box assembly; Refer to “Passenger Air Bag Assembly Replacement” in this section.
4. Disconnect passenger air bag assembly yellow 2–pin connector behind the glove box assembly.

CAUTION: With the “SRS–2” fuse removed and ignition switch “ON,” the “AIR BAG” warning lamp will be “ON.” This is normal operation and does not indicate an SRS malfunction.

Enabling The SRS

Installation

Turn ignition switch to “LOCK” and remove key.

1. Connect yellow 2–pin connector passenger air bag assembly.
2. Install glove box assembly, Refer to “Passenger Air Bag Assembly Replacement” in this section.

3. Connect yellow 2–pin connector at the base of the steering column.
4. Install “AIR BAG” fuse SRS–1 to left dash side lower fuse block or connect battery.

Turn ignition switch to “ON” and verify that the “AIR BAG” warning lamp flashes seven times and then turns “OFF” If it does not operate as described, perform the “SRS Diagnostic System Check” in section 9J–2.

Handling / Installation / Diagnosis

1. Air bag assembly should not be subjected to temperatures above 65°C (150°F).
2. Air bag assembly, and SDM should not be used if they have been dropped from a height of 100 centimeters (3.28 feet) or more.
3. When a SDM is replaced, it must be oriented with the arrow on the SDM pointing toward the front of the vehicle. It is very important for the SDM to be located flat on the mounting surface, parallel to the vehicle datum line. It is important that the SDM mounting surface is free of any dirt or other foreign material.
4. Do not apply power to the SRS unless all components are connected or a diagnostic chart requests it, as this will set a diagnostic trouble code.
5. The “SRS Diagnostic System Check” must be the starting point of any SRS diagnostics. The “SRS Diagnostic System Check” will verify proper “AIR BAG” warning lamp operation and will lead you to the correct chart to diagnose any SRS malfunctions. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis, and incorrect parts replacements.

Inspections Required After An Accident

CAUTION: Certain SRS components must be replaced after a frontal crash involving air bag deployment.

In all types of accidents regardless of “Air Bag” deployment, visually inspect all of the following components and replace as required:

- Driver air bag assembly
- Passenger air bag assembly
- Steering wheel
- SRS coil assembly
- Steering column
- Knee bolster and instrument panel mounting attachments
- Driver seat and belt
- Passenger seat and belt
- SDM

SDM always should be checked according to “SDM Replacement Guidelines”.

CAUTION: Refer to “SDM replacement Guidelines” below for important information on SDM replacement in both deployment and non-deployment crashes.

Inspect SRS coil assembly wiring and steering wheel for any signs of scorching, melting, or damage due to excessive heat. If coil assembly wire or steering wheel is

damaged, replace them. The steering column and wheel must be dimensionally checked to determine if they are damaged. Refer to in this Section 9J-3 of this manual. Never use SRS parts from another vehicle. This does not include remanufactured parts purchased from an authorized Retailer; they may be used for SRS repairs. Do not attempt to repair the SDM, the SRS harness, the SRS coil assembly, the air bag assembly, the steering

wheel, or the steering column. Service of these items is replacement only. Verify replacement part numbers.

CAUTION: Proper operation of the SDM and Supplemental Restraint System (SRS) requires that any repairs to the vehicle structure return it to its original production configuration.

Sensing and Diagnostic Module (SDM)

Service Precautions


WARNING: DURING SERVICE PROCEDURES, BE VERY CAREFUL WHEN HANDLING SDM. NEVER STRIKE OR JAR SDM. UNDER SOME CIRCUMSTANCES, IT COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY OR IMPROPER OPERATION OF THE SUPPLEMENTAL RESTRAINT SYSTEM (SRS). SDM MOUNTING BRACKET BOLTS MUST BE CAREFULLY TORQUED TO ASSURE PROPER OPERATION. NEVER POWER UP THE SRS WHEN SDM IS NOT RIGIDLY ATTACHED TO THE VEHICLE. THE SDM COULD BE ACTIVATED WHEN POWERED WHILE NOT RIGIDLY ATTACHED TO THE VEHICLE WHICH COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY.

WARNING: PROPER OPERATION OF THE SENSING AND DIAGNOSTIC MODULE (SDM) REQUIRES THE SDM TO BE RIGIDLY ATTACHED TO THE VEHICLE STRUCTURE AND THAT THE ARROW ON THE SENSOR BE POINTING TOWARD THE FRONT OF THE VEHICLE.

SDM is specifically calibrated and is keyed to the SDM location SRS wiring harness. Caution should be used to ensure proper location of the SDM. The keying of the SDM to its location and wiring harness connectors should never be modified in the field.

Removal


1. Disable the SRS. (Refer to "Disable the SRS" in this manual)
2. Remove dressing panel around the radio and disconnect cigar lighter harness.
3. Remove the transfer shift lever knob.
4. Remove the center console.
5. Remove three connector from PCM.
6. Remove PCM with bracket.(Fixed four bolts)
7. Remove right side stay between instrument panel and floor.
8. Remove driver and passenger seat.
9. Turn over carpet to rear side.
10. Remove air conditioning duct for rear seat. (Transform the duct during removing it)



827RW023

11. Pull CPA (1) (Connector Position Assurance—red color) out and push connector lock down to disconnect the SDM harness connector (2).

12. Remove the three SDM fixing bolts (4) and remove SDM (3).




827RW022

Installation

1. Install the SDM (3) on bracket and fixing bolts (4) and tighten the fixing bolts to the specified torque.

Torque: 10 N·m ± 3 N·m (87 lb in ± 26 lb in)

2. Connect the SDM harness connector (2) and after that, put CPA into connector (1).



827RW022


3. Install air conditioning duct for rear seat to normal position.
4. Return carpet normal position.
5. Install right side stay between instrument panel and floor, tighten to the specified torque.

Torque: 10 N·m ± 3 N·m (87 lb in ± 26 lb in)

6. Install PCM with bracket and tighten to the specified torque.

Torque: 10 N·m ± 3 N·m (87 lb in ± 26 lb in)

7. Reconnect three connector to PCM.
8. Install the center console.
9. Install the transfer shift lever knob.
10. Install the dressing panel around the radio and reconnect cigar lighter harness.
11. Enable the SRS. (Refer to "Enabling the SRS" in this manual)



827RW023

Driver Air Bag Assembly

Service Precautions

WARNING: SAFETY PRECAUTIONS MUST BE FOLLOWED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE AIR BAG ASSEMBLY SURFACE MAY CONTAIN A SMALL AMOUNT OF SODIUM HYDROXIDE, A BY-PRODUCT OF THE DEPLOYMENT REACTION, THAT IS IRRITATING TO THE SKIN AND EYES. MOST OF THE POWDER ON THE AIR BAG ASSEMBLY IS HARMLESS. AS A PRECAUTION, WEAR GLOVES AND SAFETY GLASSES WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY, AND WASH YOUR HANDS WITH MILD SOAP AND WATER AFTERWARDS.

WARNING: WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG AND TRIM COVER ARE POINTED AWAY FROM YOU. NEVER CARRY AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF MODULE. IN THE CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. WHEN PLACING A LIVE AIR BAG


ASSEMBLY ON A BENCH OR OTHER SURFACE, ALWAYS FACE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE. NEVER REST A STEERING COLUMN ASSEMBLY ON THE STEERING WHEEL WITH THE AIR BAG ASSEMBLY FACE DOWN AND COLUMN VERTICAL. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG ASSEMBLY TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY COULD RESULT.

NOTE: In the event deployment has occurred, inspect coil assembly wire for any signs of scorching, melting or any other damage due to excessive heat. If the coil has been damaged, replace it.

Removal

1. Disable the SRS. (Refer to "Disabling the SRS" in this section.)
2. Remove air bag assembly from steering wheel by removing two bolts. Lift air bag assembly out of steering wheel.

3. Disconnect connector and remove air bag assembly.



827RW010

Installation

1. Connect air bag to wiring harness connector.

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of air bag to prevent lead wire from being pinched.

2. Install air bag into steering wheel and tighten bolts to specified sequence as shown in figure.

Torque: 8.8 N·m (78 lb in)


CAUTION: Never use the air bag assembly from another vehicle and difference model year air bag assembly.

The air bag assembly has identification colors on the bar code label from '99 model as follows.

White color for driver air bag assembly.

Yellow color for passenger air bag assembly.

Use only the air bag assembly for "UE".



827RW010

3. Enable the SRS. (Refer to "Enabling the SRS" in this section.)

Steering Wheel

Service Precautions

WARNING: SAFETY PRECAUTIONS MUST BE FOLLOWED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE AIR BAG ASSEMBLY SURFACE MAY CONTAIN A SMALL AMOUNT OF SODIUM HYDROXIDE, A BY-PRODUCT OF THE DEPLOYMENT REACTION, THAT IS IRRITATING TO THE SKIN AND EYES. MOST OF THE POWDER ON THE AIR BAG ASSEMBLY IS HARMLESS. AS A PRECAUTION, WEAR GLOVES AND SAFETY GLASSES WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY, AND WASH YOUR HANDS WITH MILD SOAP AND WATER AFTERWARDS.

WARNING: WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG AND TRIM COVER ARE POINTED AWAY FROM YOU. NEVER CARRY AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF MODULE. IN THE CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. WHEN PLACING A LIVE AIR BAG ASSEMBLY ON A BENCH OR OTHER SURFACE, ALWAYS FACE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE. NEVER REST A STEERING COLUMN ASSEMBLY ON THE STEERING WHEEL WITH THE AIR BAG ASSEMBLY FACE DOWN AND

COLUMN VERTICAL. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG ASSEMBLY TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY COULD RESULT.

NOTE: In the event deployment has occurred, inspect coil assembly wire for any signs of scorching, melting or any other damage due to excessive heat. If the coil has been damaged, replace it.


Removal

1. Disable the SRS. (Refer to "Disabling the SRS" in this section.)
2. Remove the air bag assembly (5) from steering wheel (6) by removing two bolts (7). Lift air bag assembly out of steering wheel.
3. Disconnect connector (2) and remove air bag assembly.
4. Disconnect horn lead (1)
5. Remove steering wheel attachment nut (4).
6. Move the tires to the straight ahead position before removing the steering wheel. Install steering wheel puller onto steering wheel and remove steering wheel with J-29752.

9J-28 SUPPLEMENTAL RESTRAINT SYSTEM

7. Apply a setting mark (3) across the steering wheel and shaft so parts can be reassembled in their original position.
8. Feed wiring through the wheel and remove wheel.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.




CAUTION: Never use the air bag assembly from another vehicle and difference model year air bag assembly.

The air bag assembly has identification colors on the bar code label from '99 model as follows.

White color for driver air bag assembly.

Yellow color for passenger air bag assembly.

Use only the air bag assembly for "UE".



6. Enable the SRS. (Refer to "Enabling The SRS" in this section.)

Installation

1. Install the steering wheel and align the setting marks (3).
2. Tighten the steering wheel fixing nut (4) to the specified torque.

Torque: 34 N·m (25 lb ft)

3. Connect horn lead (1).
4. Connect air bag to wiring harness connector (2).

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of air bag to prevent lead wire from being pinched.

5. Install air bag into steering wheel and tighten bolts (7) to specified sequence as show in figure.

Torque: 8.8 N·m (78 lb in)

SRS Coil Assembly

Service Precaution

WARNING: SAFETY PRECAUTIONS MUST BE FOLLOWED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE AIR BAG ASSEMBLY SURFACE MAY CONTAIN A SMALL AMOUNT OF SODIUM HYDROXIDE, A BY-PRODUCT OF THE DEPLOYMENT REACTION, THAT IS IRRITATING TO THE SKIN AND EYES. MOST OF THE POWDER ON THE AIR BAG ASSEMBLY IS HARMLESS. AS A PRECAUTION, WEAR GLOVES AND SAFETY GLASSES WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY, AND WASH YOUR HANDS WITH MILD SOAP AND WATER AFTERWARDS.

WARNING: WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG AND TRIM COVER ARE POINTED AWAY FROM YOU. NEVER CARRY AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF MODULE. IN THE CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. WHEN PLACING A LIVE AIR BAG ASSEMBLY ON A BENCH OR OTHER SURFACE, ALWAYS FACE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE. NEVER REST A STEERING COLUMN ASSEMBLY ON THE STEERING WHEEL WITH THE AIR BAG ASSEMBLY FACE DOWN AND COLUMN VERTICAL. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG ASSEMBLY TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY COULD RESULT.

NOTE: In the event deployment has occurred, inspect coil assembly wire for any signs of scorching, melting or any other damage due to excessive heat. If the coil has been damaged, replace it.

Removal


1. Disable the SRS. (Refer to "Disabling the SRS" in this section.)
2. Remove the air bag assembly (6) from steering wheel (7) by removing two bolts (8). Lift air bag assembly out of steering wheel.
3. Disconnect the 2-pin yellow connector (2) and remove air bag assembly.
4. Disconnect horn lead connector (1).
5. Remove the steering wheel attachment nut (5).
6. Move the tires to the straight ahead position before removing the steering wheel and remove wheel with J-29752.
7. Apply a setting mark (4) across the steering wheel and shaft so parts can be reassembled in their original position.
8. Feed wiring through the wheel and remove wheel.
9. Remove the steering lower cover.
10. Remove the driver knee bolster assembly.

11. Remove the steering column cover (3).
12. Disconnect the wiring harness connectors (10) located at the base of steering column.

CAUTION: Never apply force to the steering wheel in the direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.

13. Remove the combination switch assembly with SRS coil (9).

NOTE: SRS coil is a part of combination switch assembly, which cannot be replaced separately. Therefore, be sure not to remove the SRS coil from the combination switch assembly.



Installation

1. Install the combination switch assembly with SRS coil (9).
2. Connect the wiring harness connectors (10) located at the base of steering column.
3. Turn the SRS coil clockwise to full, return about 3 turns and align the neutral mark.

NOTE: Whenever installing the new combination switch with SRS coil, be sure to tear off the lock pin for aligning the neutral position before it is installed to the base of steering column.

CAUTION: When turning the SRS coil clockwise to full, stop turning if resistance is felt. Forced further turning may damage the cable in the SRS coil.

4. Install the steering column cover (3).

CAUTION: When installing the steering column cover, be sure to thread each harness as illustrated so that the harnesses starter switch, combination switch and SRS coil may not catch wiring.

5. Install the driver knee bolster assembly.
6. Install the steering lower cover.

9J-30 SUPPLEMENTAL RESTRAINT SYSTEM

7. Install the steering wheel and align the setting marks (4).
8. Tighten the steering wheel fixing nut (5) to the specified torque.

Torque: 34 N·m (25 lb ft)

9. Connect horn lead (1).
10. Connect air bag to wiring harness connector (2).

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of air bag to prevent lead wire from being pinched.

11. Install Air Bag (6) into steering wheel and tighten bolts (8) to specified sequence as figure.

Torque: 8.8 N·m (78 lb in)


CAUTION: Never use the air bag assembly from another vehicle and difference model year air bag assembly.

The air bag assembly has identification colors on the bar code label from '99 model as follows.

White color for driver air bag assembly.

Yellow color for passenger air bag assembly.

Use only the air bag assembly for "UE".



12. Enable the SRS. (Refer to "Enabling The SRS" in this section.)

825RX008

Steering Column

Service Precaution

WARNING: SAFETY PRECAUTIONS MUST BE FOLLOWED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE AIR BAG ASSEMBLY SURFACE MAY CONTAIN A SMALL AMOUNT OF SODIUM HYDROXIDE, A BY-PRODUCT OF THE DEPLOYMENT REACTION, THAT IS IRRITATING TO THE SKIN AND EYES. MOST OF THE POWDER ON THE AIR BAG ASSEMBLY IS HARMLESS. AS A PRECAUTION, WEAR GLOVES AND SAFETY GLASSES WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY, AND WASH YOUR HANDS WITH MILD SOAP AND WATER AFTERWARDS.

WARNING: WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG AND TRIM COVER ARE POINTED AWAY FROM YOU. NEVER CARRY AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF MODULE. IN THE CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. WHEN PLACING A LIVE AIR BAG ASSEMBLY ON A BENCH OR OTHER SURFACE, ALWAYS FACE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE. NEVER REST A STEERING COLUMN ASSEMBLY ON THE STEERING WHEEL WITH THE AIR BAG ASSEMBLY FACE DOWN AND COLUMN VERTICAL. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG ASSEMBLY TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY COULD RESULT.

NOTE: In the event deployment has occurred, inspect coil assembly wire for any signs of scorching, melting or any other damage due to excessive heat. If the coil has been damaged, replace it.

Removal

1. Disable the SRS. (Refer to "Disabling The SRS" in this section.)
2. Remove the air bag assembly (4) from steering wheel (2) by removing two bolts (5). Lift air bag assembly out of steering wheel.
3. Disconnect the 2-pin yellow connector (7) and remove air bag assembly.
4. Disconnect horn lead connector (8).
5. Remove the steering wheel attachment nut (3).
6. Move the tires to the straight ahead position before removing the steering wheel and removing wheel with J-29752.
7. Apply a setting mark (6) across the steering wheel and shaft so parts can be reassembled in their original position.
8. Feed wiring through the wheel and remove wheel.
9. Remove the steering lower cover.


10. Remove the driver knee bolster assembly.
11. Remove the steering column cover (1).
12. Disconnect the wiring harness connectors (10) located at the base of steering column.

CAUTION: Never apply force to the steering wheel in direction of the shaft by using a hammer or other impact tools in an attempt to remove the steering wheel. The steering shaft is designed as an energy absorbing unit.

13. Remove the combination switch assembly with SRS coil (9).

NOTE: SRS coil is a part of combination switch assembly, which cannot be replaced separately. Therefore, be sure not to remove the SRS coil from the combination switch assembly.

14. Remove the snap ring.
15. Remove the cushion rubber.
16. Disconnect shift lock cable (A/T only)
17. Disconnect the starter switch harness connector (12) located base of steering column.
18. Remove steering lock cylinder assembly (11).
19. Apply a setting mark across the universal joint and steering shaft to reassemble the parts in their original position.
20. Remove steering column assembly (13).



431RX002

Installation

1. Install the steering column assembly (13) and align the setting marks on the universal joint and steering shaft made during removal.
2. Tighten the steering column fixing bolts (dash panel side) to the specified torque.

Torque: 20 N·m (14 lb ft)

3. Tighten the steering column fixing nuts (Cross beam) to the specified torque.

Torque: 20 N·m (14 lb ft)

4. Tighten the universal joint to the specified torque.

Torque: 31 N·m (23 lb ft)

5. Install steering lock cylinder assembly (11).
6. Connect shift lock cable (For A/T)
7. Install cushion rubber.
8. Install snap ring.
9. Install the combination switch assembly with SRS coil (9).
10. Connect the wiring harness connector (10) located on the base of steering column.
11. Turn the SRS coil clockwise to full, return about 3 turns and align the neutral mark.

CAUTION: When turning the SRS coil clockwise to full, stop turning if resistance is felt. Further forced turning may damage the cable in the SRS coil.

12. Install steering column cover (1).

CAUTION: When installing the steering column cover, be sure to wire (through each harness) as illustrated so that the harnesses starter switch, combination switch and SRS coil may not catch wiring.

13. Install the steering wheel (2) and align the setting marks (6).
14. Tighten the steering wheel fixing nut (3) to the specified torque.

Torque: 34 N·m (25 lb ft)

15. Connect horn lead (8).
16. Connect air Bag wiring harness connector (7).

NOTE: Pass the lead wire through the tabs on the plastic cover (wire protector) of air bag to prevent lead wire from being pinched.

17. Install air bag into steering wheel and tighten bolts (5) to specified sequence as shown in figure.

Torque: 8.8 N·m (78 lb in)


CAUTION: Never use the air bag assembly from another vehicle and difference model year air bag assembly.

The air bag assembly has identification colors on the bar code label from '99 model as follows.

White color for driver air bag assembly.

Yellow color for passenger air bag assembly.

Use only the air bag assembly for "UE".



18. Enable the SRS (Refer to "Enabling The SRS" in this section.)

431RX002

Passenger Air Bag Assembly

Service Precaution

WARNING: SAFETY PRECAUTIONS MUST BE FOLLOWED WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY. AFTER DEPLOYMENT, THE AIR BAG ASSEMBLY SURFACE MAY CONTAIN A SMALL AMOUNT OF SODIUM HYDROXIDE, A BY-PRODUCT OF THE DEPLOYMENT REACTION, THAT IS IRRITATING TO THE SKIN AND EYES. MOST OF THE POWDER ON THE AIR BAG ASSEMBLY IS HARMLESS. AS A PRECAUTION, WEAR GLOVES AND SAFETY GLASSES WHEN HANDLING A DEPLOYED AIR BAG ASSEMBLY, AND WASH YOUR HANDS WITH MILD SOAP AND WATER AFTERWARDS.


WARNING: WHEN CARRYING A LIVE AIR BAG ASSEMBLY, MAKE SURE THE BAG AND TRIM COVER ARE POINTED AWAY FROM YOU. NEVER CARRY AIR BAG ASSEMBLY BY THE WIRES OR CONNECTOR ON THE UNDERSIDE OF MODULE. IN THE CASE OF AN ACCIDENTAL DEPLOYMENT, THE BAG WILL THEN DEPLOY WITH MINIMAL CHANCE OF INJURY. WHEN PLACING A LIVE AIR BAG ASSEMBLY ON A BENCH OR OTHER SURFACE, ALWAYS FACE BAG AND TRIM COVER UP, AWAY FROM THE SURFACE. NEVER REST A STEERING COLUMN ASSEMBLY ON THE STEERING WHEEL WITH THE AIR BAG ASSEMBLY FACE DOWN AND COLUMN VERTICAL. THIS IS NECESSARY SO THAT A FREE SPACE IS PROVIDED TO ALLOW THE AIR BAG ASSEMBLY TO EXPAND IN THE UNLIKELY EVENT OF ACCIDENTAL DEPLOYMENT. OTHERWISE, PERSONAL INJURY COULD RESULT.

NOTE: In the event deployment has occurred, inspect coil assembly wire for any signs of scorching, melting or any other damage due to excessive heat. If the coil has been damaged, replace it.

Removal

1. Disable the SRS. (Refer to "Disabling the SRS" in this section.)
2. Remove glove box assembly.
3. Disconnect passenger air bag assembly harness connector.
4. Remove air bag assembly fixing bolts and nuts.
5. Remove reinforcement.

6. Remove passenger air bag assembly from glove box opening of instrument panel.



827RX053

Legend

- (1) Passenger Air Bag Door
- (2) Passenger Air Bag Assembly
- (3) Passenger Air Bag Harness
- (4) Reinforcement
- (5) Cross Beam

Installation

1. Install passenger air bag assembly from glove box opening of instrument panel.
2. Install reinforcement from glove box opening of instrument panel.
3. Install air bag assembly fixing nuts and bolts, and tighten to specified torque.

Torque: 7.8 N·m (69 lb in)

4. Connect air bag assembly harness connector.
5. Install glove box assembly.
6. Enable the SRS (Refer to "Enabling the SRS" in this section.)

RODEO

RESTRAINTS

SRS CONTROL SYSTEM

CONTENTS

Service Precaution	9J1-1	DTC 17 Passenger Deployment Loop Open	9J1-19
Diagnostic Information	9J1-2	DTC 18 Passenger Deployment Loop	
Diagnostic Procedures	9J1-2	Short To Ground	9J1-21
Diagnostic Codes	9J1-2	DTC 19 Passenger Deployment Loop	
How To Read Trouble Codes	9J1-2	Short To Voltage	9J1-23
How To Clear Trouble Codes	9J1-2	DTC 21 Driver Deployment Loop	
Scan Tool Diagnostics	9J1-2	Resistance High	9J1-25
Basic Knowledge Required	9J1-2	DTC 22 Driver Deployment Loop	
Basic Electrical Circuits	9J1-2	Resistance Low	9J1-28
"Flash Code" Diagnostics	9J1-2	DTC 24 Driver Deployment Loop	
System Schematic	9J1-3	Short To Ground	9J1-31
SRS Diagnostic System Check	9J1-4	DTC 25 Driver Deployment Loop	
Chart A SDM Integrity Check	9J1-6	Short To Voltage	9J1-33
Chart B "AIR BAG" Warning Lamp Comes		DTC 26 Driver Deployment Loop Open	9J1-36
"ON" Steady	9J1-8	DTC 51 Deployment Event Commanded ...	9J1-39
Chart C "AIR BAG" Warning Lamp Does		DTC 53 Deployment Commanded	
Not Comes "ON" Steady	9J1-10	With Deployment Loop Fault Or Energy	
DTC 15 Passenger Deployment Loop		Reserves Out Of Range	9J1-41
Resistance High	9J1-13	DTC 61 Warning Lamp Circuit Failure	9J1-43
DTC 16 Passenger Deployment Loop		DTC 71 Internal SDM Fault	9J1-45
Resistance Low	9J1-16		

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED**, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.

Diagnostic Information

Diagnostic Procedures

WARNING: WHEN FASTENERS ARE REMOVED, ALWAYS REINSTALL THEN AT THE SAME LOCATION FROM WHICH THEY WERE REMOVED. IF A FASTENER NEEDS TO BE REPLACED, USE THE CORRECT PART NUMBER FASTENER FOR THAT APPLICATION. IF THE CORRECT PART NUMBER FASTENER IS NOT AVAILABLE, A FASTENER OF EQUAL SIZE AND STRENGTH (OR STRONGER) MAY BE USED. FASTENERS THAT ARE NOT REUSED, AND THOSE REQUIRING THREAD LOCKING COMPOUND WILL BE CALLED OUT. THE CORRECT TORQUE VALUE MUST BE USED WHEN INSTALLING FASTENERS THAT REQUIRE IT. IF THE ABOVE CONDITIONS ARE NOT FOLLOWED, PARTS OR SYSTEM DAMAGE COULD RESULT.

WARNING: TO AVOID DEPLOYMENT WHEN TROUBLESHOOTING THE SRS, DO NOT USE ELECTRICAL TEST EQUIPMENT SUCH AS A BATTERY-POWERED OR AC-POWERED VOLTMEETER, OHMMETER, ETC., OR ANY TYPE OF ELECTRICAL EQUIPMENT OTHER THAN THAT SPECIFIED IN THIS MANUAL. DO NOT USE A NONPOWERED, PROBE-TYPE TESTER. INSTRUCTIONS IN THIS MANUAL MUST BE FOLLOWED CAREFULLY, OTHERWISE PERSONAL INJURY MAY RESULT.

The diagnostic procedures used in this section are designed to aid in finding and repairing SRS problems. Outlined below are the steps to find and repair SRS problems quickly and effectively. Failure to carefully follow these procedures may result in extended diagnostic time, incorrect diagnosis and incorrect parts Replacement.

1. Perform The "SRS Diagnostic System Check."

The "SRS Diagnostic System Check" should always be the starting point of any SRS diagnostics. The "SRS Diagnostic System Check" checks for proper "AIR BAG" warning lamp operation and checks for SRS trouble codes using both "Flash Code" and "Scan Tool" Methods.

2. Refer To The Proper Diagnostic Chart As Directed By The "SRS Diagnostic System Check."

The "SRS Diagnostic System Check" will lead you to the correct chart to diagnose any SRS problems. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis and incorrect parts Replacement.

3. Repeat the "SRS Diagnostic System Check" After Any Repair Or Diagnostic Procedures Have Been Performed.

Performing the "SRS Diagnostic System Check" after all repair or diagnostic procedures will assure that the repair has been made correctly and that no other conditions exist.

Diagnostic Codes

The Sensing and Diagnostic Module (SDM) maintains a history record of all diagnostic codes that have been

detected since the SRS codes were last cleared during service.

1. Active Codes—Faults that are presently detected this ignition cycle. Active codes are stored in RAM (Random Access Memory).
2. History Codes—All faults detected since the last time the history fault memory was cleared. History codes are stored in EEPROM. (Electronically Erasable Programmable Read only Memory)

How To Read Trouble Codes

All codes (Active and history) can be read (or cleared) by using a scan tool or equivalent.

If a DTC is not available, have the vehicle serviced by dealer.

How To Clear Trouble Codes

Trouble codes can only be cleared by using a scan tool. If a scan tool is not available then inform the owner of the stored codes and suggest that the codes are cleared upon the next visit to a dealership.

Scan Tool Diagnostics

A scan tool can be used to read current and history codes and to clear all history codes after a repair is complete. The scan tool must be updated to communicate with the SRS through a replaceable cartridge for SRS diagnostics. To use the scan tool, connect it to the DLC and turn the ignition switch "ON". Then follow the manufacturer's directions for communication with the SRS. The scan tool reads serial data from the SDM "Serial Data" output (terminal 24) to the DLC.

Basic Knowledge Required

Before using this section of the Service Manual, there is some basic knowledge which will be required. Without this knowledge, you will have trouble using the diagnostic procedures in this section. Use care to prevent harm or unwanted deployment. Read all cautions in the service manual and on warning labels attached to SRS components.

Basic Electrical Circuits

You should understand the basic theory of electricity including series and parallel circuits, and understand the voltage drops across series resistors. You should know the meaning of voltage (volts), current (amps), and resistance (ohms). You should understand what happens in a circuit with an open or a shorted wire. You should be able to read and understand a wiring diagram.

"Flash Code" Diagnostics


Flash code diagnostics can be used to read current codes and to determine if history codes are present but cannot be used to clear codes or read history codes. Flash code diagnostics is enabled by grounding by terminal 13 shorting to terminal 4 of the DLC with the ignition switch "ON". Grounding terminal 13 of the DLC pulls the "Diagnostics Request" input (Terminal 1) of the SDM low and signals the SDM to enter the flash code diagnostic display mode.

The SDM displays the trouble codes by flashing the warning lamp. Each code that is displayed will consist of a number of flashes which represents the tens digit, a 1.2 second pause, following by a number of flashes which represents the ones digit of the code. Each code is displayed one time before moving on to the next code. After all of the codes have been displayed, the entire code sequence will continually be repeated until ground is removed from terminal 13 of the DLC.

Two special codes exist when reading in the flash code mode (Flash Code 12 and Flash Code 13). "Flash Code

12" will always be the first code displayed when the flash code mode is enabled. Code 12 is not an indication of a SRS problem but an indication that the flash code mode has been enabled. If there are no current or history codes present, the SDM will display code 12 until ground is removed from the DLC at terminal 13. "Flash Code 13" will be displayed if there are history codes. To read the history codes, a scan tool must be used.

System Schematic



D08RW002

SRS Diagnostic System Check

The diagnostic procedures used in this section are designed to find and repair SRS malfunctions. To get the best results, it is important to use the diagnostic charts and follow the sequence listed below:

- A. Perform the "SRS Diagnostic System Check."
The "SRS Diagnostic System Check" must be the starting point of any SRS diagnostics. The "SRS Diagnostic System Check" checks for proper "AIR BAG" warning lamp operation, the ability of the SDM to communicate through the "Serial Data" line and whether SRS diagnostic trouble codes exist.
- B. Refer to the proper diagnostic chart as directed by the "SRS Diagnostic System Check."
The "SRS Diagnostic System Check" will lead you to the correct chart to diagnose any SRS malfunctions. Bypassing these procedures may result in extended diagnostic time, incorrect diagnosis and incorrect parts replacement.
- C. Repeat the "SRS Diagnostic System Check" after any repair or diagnostic procedures have been performed.
Performing the "SRS Diagnostic System Check" after all repair or diagnostic procedures will ensure that the repair has been made correctly and that no other malfunctions exist

Circuit Description

When the ignition switch is first turned "ON", "ignition 1" voltage is applied from the "SRS-1" fuse to the SDM at the "ignition 1" input terminals "12". The SDM responds by flashing the "AIR BAG" warning lamp seven times while performing tests on the SRS.

Notes On System Check Chart:

Number(s) below refer to step number(s) on the "SRS Diagnostic System Check" chart.

1. The "AIR BAG" warning lamp should flash seven times after ignition is first turned "ON."
2. After the "AIR BAG" warning lamp flashes seven times, it should turn "OFF."
3. Improper operation of the "AIR BAG" warning lamp is indicated. This test differentiates a warning lamp stays "ON" condition from a warning lamp does not come "ON" condition.
4. This test checks for the proper operation of the "Serial Data" line. This test will also determine whether history diagnostic trouble codes are stored and, if so, identify them.
5. This test checks for proper operation of the "Serial Data" line. This test will also identify the stored diagnostic trouble codes and whether they are current or history.


Diagnostic Aids:

The order in which diagnostic trouble codes are diagnosed is very important. Failure to diagnose the diagnostic trouble codes in the order specified may result in extended diagnostic time, incorrect diagnosis and incorrect parts Replacement.

SRS Diagnostic System Check

Step	Action	Yes	No
1	Note the "AIR BAG" warning lamp when ignition switch is turned "ON." Does the "AIR BAG" warning lamp flash seven (7) times?	Go to Step 2	Go to Step 3
2	Note the "AIR BAG" warning lamp after it flashed 7 times. Does the "AIR BAG" warning lamp go "OFF"?	Go to Step 4	Go to Step 5
3	Note the "AIR BAG" warning lamp when ignition switch is turned "ON." Does the "AIR BAG" warning lamp come "ON" steady?	Go to Chart B.	Go to Chart C.
4	1. Ignition switch "OFF." 2. Connect a scan tool to data link connector. 3. Follow direction given in the scan tool instruction manual. 4. Ignition switch "ON." 5. Request the SRS diagnostic trouble code display recode all history diagnostic trouble code(s) specify as such, on repair order. Is diagnostic trouble code(s) displayed?	Ignition switch "OFF." When DTC 71 is set, go to DTC 71 chart. For all other history codes refer to "Diagnostics Aids" for that specific DTC. A history DTC indicates the malfunction has been repaired or is intermittent.	SRS is functional and free of malfunctions, no further diagnosis is required. If scan tool indicates "No Data Received," refer to chassis electrical section.
5	1. Ignition switch "OFF." 2. Connect a scan tool to data link connector. 3. Follow directions as given in the scan tool instruction manual. 4. Ignition switch "ON." 5. Request the SRS diagnostic trouble code display, recode all diagnostic trouble code(s), specifying as current or history on repair order. Is diagnostic trouble code(s) displayed?	Ignition switch "OFF." When DTC 53 is set, go to DTC 53 chart. When DTC 51 is set, go to DTC 51 chart. When DTC 19 is set, go to DTC 19 chart. When DTC 25 is set, go to DTC 25 chart. Diagnose remaining current DTCs from lowest to highest. When only history DTCs exist, Refer to "Diagnostics Aids" for that specific DTC. A history DTC indicates the malfunction has been repaired or is intermittent.	If scan tool indicates "No Data Received," refer to chassis electrical section.

Chart A SDM Integrity Check



D09RW002

Circuit Description:

When the SDM recognizes "ignition 1" voltage, applied to terminals "12", is greater than 9 volts, the "AIR BAG" warning lamp is flashed 7 times to verify operation. At this time the SDM performs "Turn-ON" tests followed by "Continuous Monitoring" tests. When a malfunction is detected, the SDM sets a current diagnostic trouble code and illuminates the "AIR BAG" warning lamp. The SDM will clear current diagnostic trouble codes and move them to a history file when the malfunction is no longer detected and/or the ignition switch is cycled, except for DTCs 51, 53 and 71. DTC 71 can only be cleared using a scan tool "Clear Codes" command in case that the malfunction on DTC 71 has been solved and no DTCs 51 and 53 were remained. DTCs 51, 53 and 71 can not be cleared after a "Clear Codes" command is issued.

Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:


1. This test confirms a current malfunction. If no current malfunction is occurring (history DTC set) the "Diagnostic Aids" for the appropriate diagnostic trouble code should be referenced. The SDM should not be replaced for a history diagnostic trouble code.
2. This test checks for a malfunction introduced into the SRS during the diagnostic process. It is extremely unlikely that a malfunctioning SDM would cause a new malfunction to occur during the diagnostic process.
3. When all circuitry outside the SDM has been found to operate properly, as indicated by the appropriate diagnostic chart, then and only then should the SDM be replaced.

Chart A SDM Integrity Check

WARNING: DURING SERVICE PROCEDURES. BE VERY CAREFUL WHEN HANDLING A SENSING AND DIAGNOSTIC MODULE (SDM). NEVER STRIKE OR JAR THE SDM. NEVER POWER UP THE SRS WHEN THE SDM IS NOT RIGIDLY ATTACHED TO THE VEHICLE. ALL SDM AND MOUNTING BRACKET FASTENERS MUST BE CAREFULLY TORQUED AND THE ARROW MUST BE POINTING TOWARD THE FRONT OF THE VEHICLE TO ENSURE PROPER OPERATION OF THE SRS. THE SDM COULD BE ACTIVATED WHEN POWERED WHILE NOT RIGIDLY ATTACHED TO THE VEHICLE WHICH COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY.

Step	Action	Yes	No
1	<p>1. This chart assumes that the "SRS Diagnostic System Check" and either a symptom chart or a diagnostic trouble code chart diagnosis have been performed When all circuitry outside the SDM has been found to operate properly, as indicated by the appropriate diagnostic chart, and the symptom or DTC remains current, the following diagnostic procedures must be performed to verify the need for SDM Replacement.</p> <p>2. Ignition switch "OFF."</p> <p>3. Reconnect all SRS components, ensure all components are properly mounted.</p> <p>4. Ensure the ignition switch has been "OFF" for at least 15 seconds.</p> <p>5. Note "AIR BAG" warning lamp as ignition switch is turned "ON."</p> <p>Does warning lamp flash 7 times then go "OFF"?</p>	<p>The symptom or DTC is no longer occurring.</p> <p>Clear SRS diagnostic trouble codes.</p> <p>Repeat the "SRS Diagnostic System Check."</p>	Go to Step 2
2	<p>Using a scan tool, request diagnostic trouble code display.</p> <p>Is the same symptom or DTC occurring as was when the "SRS Diagnostic System Check " was first performed?</p>	<p>Ignition switch "OFF."</p> <p>Go to the appropriate chart for the indicated malfunction.</p>	Go to Step 3
3	<p>1. Clear "SRS Diagnostic Trouble Codes."</p> <p>2. Ignition switch "OFF" for at least two minutes.</p> <p>3. Note "AIR BAG" warning lamp as ignition switch is turned "ON."</p> <p>Does warning lamp flash 7 times then go "OFF"?</p>	<p>SRS is functional and free of malfunctions.</p> <p>No further diagnosis is required.</p> <p>Go to Step 4</p>	<p>Ignition switch "OFF."</p> <p>Replace SDM.</p> <p>Go to Step 4</p>
4	<p>Reconnect all SRS components, ensure all components are properly mounted.</p> <p>Was this step finished?</p>	<p>Repeat the "SRS Diagnostic System Check."</p>	Go to Step 4

Chart B "AIR BAG" Warning Lamp Comes "ON" Steady



D09RW002

Circuit Description:

When the ignition switch is first turned "ON", "ignition 1" voltage is applied from the "MA01" meter fuse to "AIR BAG", warning lamp which is connected to "SRS warning lamp", terminal "7". The "SRS-1" fuses apply system voltage to the "ignition 1" inputs, terminals "12". The SDM responds by flashing the "AIR BAG" warning lamp 7 times. If "ignition 1" voltage is less than 9 volts, the "AIR BAG" warning lamp will come "ON" solid with no DTCs set.

Chart Test Description:


Number (s) below refer to step number (s) on the diagnostic chart.

2. This test checks for an open in the "ignition 1" circuit to the SDM.
3. This test checks for the voltage of "ignition 1."
4. This test determines whether the malfunction is a short to ground in CKT IB04 – GRN.

Chart B “AIR BAG” Warning Lamp Comes “ON” Steady

Step	Action	Yes	No
1	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Ignition switch “OFF.” 3. Connect scan tool to data link connector, Follow directions as given in the scan tool instruction manual. 4. Ignition switch “ON.” 5. Request SRS diagnostic trouble code display. Does scan tool indicate “No Data Received”?	Go to Step 2	Go to Step 3
2	1. Ignition switch “OFF.” 2. Inspect SDM harness connector connection to SDM. Is it securely connected to the SDM?	Ignition switch “OFF.” Replace SDM. Go to Step 5	Connect SDM securely to de-activate shorting clip in SDM harness connector. Go to Step 5
3	Using scan tool, request SRS data list. Is “ignition” more than 9 volts?	Go to Step 4	Ignition switch “OFF.” Replace SDM. Go to Step 5
4	1. Ignition switch “OFF.” 2. Disconnect SRS coil and passenger air bag assemblies. Yellow 2-pin connectors located at base of steering column and behind the glove box assembly. 3. Disconnect SDM. 4. Measure resistance from SDM harness connector terminal “6” to ground. Does J-39200 display “OL” (infinite)?	Go to Chart A.	Replace SRS harness. Go to Step 5
5	Reconnect all SRS components, ensure all components are properly mounted. Was this step finished?	Repeat the “SRS Diagnostic System Check.”	Go to Step 5

Chart C "AIR BAG" Warning Lamp Does Not Comes "ON" Steady



D09RW002

Circuit Description:

When the ignition switch is first turned "ON", "ignition 1" voltage is applied from the "MA01" meter fuse to the "AIR BAG" warning lamp which is connected to "SRS warning lamp", terminal "7". The "SRS-1" fuse apply system voltage to the "ignition 1" inputs, terminals "12". The SDM responds by flashing the "AIR BAG" warning lamp seven times. If "ignition 1" voltage is more than 16 volts, the "AIR BAG" warning lamp will be still "OFF" solid with no DTCs set.

Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:

1. This test decides whether power is available to SDM warning lamp power feed circuit.
2. This test determines whether the voltage is present in the warning lamp circuit.
3. This test determines if the malfunction is in the instrument cluster.
4. This test checks for open in the warning lamp circuitry.
5. This test isolates the IB04-GRN circuit and checks for a short in the IB04-GRN circuit to B+.
8. This test checks for a short from the SDM warning lamp power feed circuit to ground.
9. This test determines whether the short to ground is due to a short in the wiring.

Chart C “AIR BAG” Warning Lamp Does Not Comes “ON” Steady


Step	Action	Yes	No
1	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Ignition switch “OFF.” 3. Remove and inspect “MA01” meter fuse to the “AIR BAG” warning lamp. Is fuse good?	Go to Step 2	Go to Step 7
2	1. Ignition switch “OFF.” 2. Disconnect SRS coil and passenger air bag assemblies. Yellow 2-pin connectors located at base of steering column and behind the glove box assembly. 3. Disconnect SDM. 4. Ignition switch “ON.” 5. Measure voltage on SDM harness connector from terminal “7” to terminal “6” (ground). Is system voltage present on terminal “7”?	Go to Step 4	Go to Step 3
3	1. Ignition switch “OFF.” 2. Remove instrument meter cluster. 3. Check for proper connection to instrument cluster at IB04-GRN terminal. 4. If OK, then remove and inspect “AIR BAG” bulb. Is bulb good?	Go to Step 5	Replace bulb. Go to Step 6
4	1. Ignition switch “OFF.” 2. Disconnect instrument meter cluster harness connector. 3. Ignition switch “ON.” 4. Measure voltage on SDM harness connector from terminal “7” to terminal “6” (ground). Is voltage 1 volt or less?	Go to Chart A.	Replace SRS harness. Go to Step 6
5	1. Install bulb. 2. Measure resistance from instrument meter cluster harness connector IB04-GRN terminal to SDM harness connector terminal “7”. Is resistance 5.0 ohms or less?	Service instrument meter cluster. Go to Step 6	Replace SRS harness. Go to Step 6
6	Reconnect all SRS components, ensure all components are properly mounted. Was this step finished?	Repeat the “SRS Diagnostic System Check.”	Go to Step 6
7	Were you sent here from chart C?	Go to Step 8	Go to Step 1
8	1. Replace “MA01” meter fuse. 2. Ignition switch “ON” wait 10 seconds then ignition switch “OFF.” 3. Remove and inspect “MA01” meter fuse. Is fuse good?	Install “MA01” meter fuse. Go to Step 10	Go to Step 9

9J1-12 RESTRAINT CONTROL SYSTEM

Chart C “AIR BAG” Warning Lamp Does Not Comes “ON” Steady (Cont’d)

Step	Action	Yes	No
9	<ol style="list-style-type: none">1. Disconnect SRS coil and passenger air bag assemblies. Yellow 2-pin connectors located at base of steering column and behind the glove box assembly.2. Disconnect SDM.3. Replace “MA01” meter fuse.4. Ignition switch “ON” wait to 10 seconds.5. Ignition switch “OFF”.6. Remove and inspection “MA01” meter fuse. Is fuse good?	Install “MA01” meter fuse. Go to Chart A.	Replace SRS harness. Replace “MA01” meter fuse. Go to Step 10
10	Reconnect all SRS components, ensure all components are properly mounted. Was this step finished?	Repeat the “SRS Diagnostic System Check.”	Go to Step 10

DTC 15 Passenger Deployment Loop Resistance High



D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests "Ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM then proceeds with the "Resistance Measurement Test". "Passenger Bag Low" terminal "16" is grounded through a resistor and the passenger current source connected to "Passenger Bag High" terminal "15" allows a known amount of current to flow. By monitoring the voltage difference between "Passenger Bag High" and "Passenger Bag Low" the SDM calculates the combined resistance of the passenger air bag assembly, harness wiring CKTs IB07-YEL/GRN and IB08-YEL/RED connector terminal contact.

DTC Will Set When:

The combined resistance of the passenger air bag assembly, harness wiring CKTs IB07-YEL/GRN and IB08-YEL/RED, and connector terminal contact is above a specified value. This test is run once each ignition cycle during the "Resistance Measurement Test" when:

1. No "higher priority faults" are detected during "Turn-ON."
2. "Ignition 1" voltage is in the specified value.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

The ignition switch is turned "OFF."

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:


2. This test determines whether the malfunction is in the SDM.
3. This test verifies proper connection of the yellow 2-pin connector.
4. This test checks for proper contact and/or corrosion of the yellow 2-pin connector terminals.
5. The test checks for a malfunctioning passenger air bag assembly.
6. This test determines whether the malfunction is due to high resistance in the wiring.

Diagnostic Aids:

An intermittent condition is likely to be caused by a poor connection at the passenger air bag assembly harness connector terminals "1" and "2", SDM terminal "15" and "16", or a poor wire to terminal connection in CKTs IB07-YEL/GRN and IB08-YEL/RED. This test for this diagnostic trouble code is only run while the "AIR BAG" warning lamp is performing the bulb check, unless DTC 17 or DTC 26 is detected. When a scan tool "Clear Codes" command is issued and the malfunction is still present, the DTC will not reappear until the next ignition cycle.

DTC 15 Passenger Deployment Loop Resistance High

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	<ol style="list-style-type: none"> When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. Use scan tool data list function, read and record the passenger deployment loop resistance. <p>Is passenger resist more than 2.9 ohms?</p>	Go to Step 3	Go to Chart A.
3	<ol style="list-style-type: none"> Ignition switch "OFF." Make sure the passenger air bag assembly yellow 2-pin connector located behind the glove box assembly is seated properly. <p>Is the yellow 2-pin connector connected properly?</p>	Go to Step 4	Seat passenger air bag assembly yellow 2-pin connector properly. Go to Step 7
4	<ol style="list-style-type: none"> Disconnect and inspect the passenger air bag assembly yellow 2-pin connector located behind the glove box assembly. If OK, reconnect the passenger air bag assembly 2-pin connector. Ignition switch "ON." <p>Is DTC 15 current?</p>	Go to Step 5	Ignition switch "OFF." Go to Step 7
5	<ol style="list-style-type: none"> Ignition switch "OFF." Disconnect SRS coil and passenger air bag 2-pin connectors located at the base of the steering column and behind the glove box assembly. Connect J-41433 SRS driver / passenger load tool and appropriate adapters to SRS coil and passenger air bag assembly harness connectors. Ignition switch "ON." <p>Is DTC 15 current?</p>	Go to Step 6	Ignition switch "OFF." Replace the passenger air bag assembly. Go to Step 7
6	<ol style="list-style-type: none"> Ignition switch "OFF." There has been an increase in the total circuit resistance of the passenger inflator deployment loop. Use the high resolution ohmmeter mode of the DVM while checking CKTs IB07-YEL/GRN and IB08-YEL/RED, and SDM connector terminal "15" and "16" to locate the root cause. <p>Was a fault found?</p>	Replace SRS harness. Go to Step 7	Go to Chart A.
7	<ol style="list-style-type: none"> Reconnect all components ensure all component are properly mounted. Clear diagnostic trouble codes. <p>Was this step finished?</p>	Repeat the "SRS Diagnostic System Check."	Go to Step 7

DTC 16 Passenger Deployment Loop Resistance Low

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests "Ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM then proceeds with the "Resistance Measurement Test". "Passenger Bag Low" terminal "16" is grounded through a resistor and the passenger current source connected to "Passenger Bag High" terminal "15" allows a known amount of current to flow. By monitoring the voltage difference between "Passenger Bag High" and "Passenger Bag Low", the SDM calculates the combined resistance of the passenger air bag assembly, harness wiring CKTs IB07-YEL/GRN and IB08-YEL/RED connector terminal contact.

DTC Will Set When:

The combined resistance of the passenger air bag assembly, harness wiring CKTs IB07-YEL/GRN and IB08-YEL/RED, and connector terminal contact is above a specified value. This test is run once each ignition cycle during the "Resistance Measurement Test" when:

1. No "higher priority faults" are detected during "Turn-ON",
2. "Ignition 1" voltage is in the specified value.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

The ignition switch is turned "OFF."

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:


2. This test determines whether the malfunction is in the SDM.
3. This test verifies connection of the yellow 2-pin connector.
4. This test checks for proper operation of the shorting clip in the yellow 2-pin connector.
5. The test checks for a malfunction passenger air bag assembly.
6. This test determines whether the malfunctioning is due to shorting in the wiring.

Diagnostic Aids:

An intermittent condition is likely to be caused by a short between CKTs IB07-YEL/GRN and IB08-YEL/RED, or a malfunctioning shorting clip on the passenger air bag assembly which would require replacement of the air bag assembly. The test for this diagnostic trouble code is only run while "AIR BAG" warning lamp is performing the bulb check, unless DTC 17 or DTC 26 is detected. When a scan tool "Clear Codes" command is issued and the malfunction is still present, the DTC will not reappear until the next ignition cycle.

DTC 16 Passenger Deployment Loop Resistance Low

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Using scan tool data list function, read and record the passenger deployment loop resistance. Is passenger resist. less than 1.4 ohms?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Make sure the passenger air bag assembly yellow 2-pin connector located behind the glove box assembly is seated properly. Is the yellow 2-pin connector connected properly?	Go to Step 4	Seat passenger air bag assembly yellow 2-pin connector properly. Go to Step 7
4	1. Disconnect and inspect the passenger air bag assembly yellow 2-pin connector located behind the glove box assembly. 2. If OK, reconnect the passenger air bag assembly 2-pin connector. 3. Ignition switch "ON." Is DTC 16 current?	Go to Step 5	Ignition switch "OFF."Go to Step 7
5	1. Ignition switch "OFF." 2. Disconnect SRS coil and passenger air bag 2-pin connectors located at the base of the steering column and behind the glove box assembly. 3. Connect J-41433 SRS driver / passenger load tool and appropriate adapters to SRS coil and passenger air bag assembly harness connectors. 4. Ignition switch "ON." Is DTC 16 current?	Go to Step 6.	Ignition switch "OFF." Replace the passenger air bag assembly. Go to Step 7
6	1. Ignition switch "OFF." 2. There has been a decrease in the total circuit resistance of the passenger inflator deployment loop. 3. Use the high resolution ohmmeter mode of the DVM while checking CKTs IB07-YEL/GRN and IB08-YEL/RED, and SDM connector terminal "15" and "16" to locate the root cause. Was a fault found?	Replace SRS harness. Go to Step 7	Go to Chart A.
7	1. Reconnect all components, ensure all component are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 7

DTC 17 Passenger Deployment Loop Open

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. During "Continuous Monitoring" diagnostics, a fixed amount of current is flowing in the deployment loop. This produces proportional voltage drops in the loop. By monitoring the voltage difference between "Passenger Bag High" and "Passenger Bag Low", the SDM calculates the combined resistance of the passenger air bag assembly, harness wiring CKTs IB07-YEL/GRN and IB08-YEL/RED, and connector terminal contact.

DTC Will Set When:

The voltage difference between "Passenger Bag High" terminal "15" and "Passenger Bag Low" terminal "16" is

above or equal to a specified value for 500 milliseconds during "Continuous Monitoring".

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

The voltage difference between "Passenger Bag High" terminal "15" and "Passenger Bag Low" terminal "16" is below a specified value for 500 milliseconds during "Continuous Monitoring".

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:

2. This test determines whether the malfunction is in the SDM.

9J1-20 RESTRAINT CONTROL SYSTEM

3. This test verifies proper connection of the yellow 2-pin connector.
4. This test checks for proper contact and/or corrosion of the shorting clip in the yellow 2-pin connector terminals.
5. The test checks for a malfunctioning passenger air bag assembly.
6. This test determines whether there is an open in the wiring.


Diagnostic Aids:

An intermittent condition is likely to be caused by a poor connection at the passenger air bag assembly harness connector terminals "1" and "2," SDM terminals "15" and "16," or an open in CKT IB07-YEL/GRN and IB08-YEL/RED.

DTC 17 Passenger Deployment Loop Open

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Using scan tool data list function, read and record the passenger differential voltage. Is passenger differential voltage. more than 4.0 volts?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Make sure the passenger air bag assembly yellow 2-pin connector located behind the glove box assembly is seated properly. Is the yellow 2-pin connector connected properly?	Go to Step 4	Seat passenger air bag assembly yellow 2-pin connector properly. Go to Step 7
4	1. Disconnect and inspect the passenger air bag assembly yellow 2-pin connector located behind the glove box assembly. 2. If OK, reconnected the passenger air bag assembly yellow 2-pin connector. 3. Ignition switch "ON." Is DTC 17 current?	Go to Step 5	Ignition switch "OFF." Go to Step 7
5	1. Ignition switch "OFF." 2. Disconnect SRS coil and passenger air bag assembly yellow 2-pin connectors located at the base of the steering column and behind the glove box assembly. 3. Connect J-41433 SRS driver / passenger load tool and appropriate adapters to SRS coil and passenger air bag assembly harness connectors. 4. Ignition switch "ON." Is DTC 17 current?	Go to Step 6	Ignition switch "OFF." Replace the passenger air bag assembly. Go to Step 7
6	1. Ignition switch "OFF." 2. There has been an open circuit in the passenger inflator deployment loop. 3. Use the high resolution ohmmeter mode of the DVM while checking CKTs IB07-YEL/GRN and IB08-YEL/RED, and SDM connector terminal "15" and "16" to locate the root cause. Was a fault found?	Replace SRS harness. Go to Step 7	Go to Chart A.
7	1. Reconnect all components ensure all component are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 7

DTC 18 Passenger Deployment Loop Short To Ground



D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM monitors the voltages at "Driver Bag Low" terminal "4" and "Passenger Bag Low" terminal "16" to detect short to ground in the air bag assembly circuits.

DTC Will Set When:

Neither of the two air bag assemblies is open. "Ignition 1" is within the normal operating voltage range. Once these conditions are met and the voltage at "Passenger Bag Low" is below a specified value, DTC 18 will set. This test is run once each ignition cycle and "Continuous Monitoring".

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

This malfunction is no longer occurring and the ignition switch is turned "OFF".

DTC Chart Test Description:

Number(s) below refer to circled number(s) on the diagnostic chart:

2. This test determines whether the SDM is malfunctioning.
3. This test isolates the malfunction to one side of the passenger air bag assembly yellow 2-pin connector behind glove box compartment.
4. This test determines whether the malfunction is in CKT IB07-YEL/GRN.

9J1-22 RESTRAINT CONTROL SYSTEM


5. This test determines whether the malfunction is in CKT IB08-YEL/RED.

Diagnostic Aids:

An intermittent condition is likely to be caused by a short to ground in the passenger air bag assembly circuit. Inspect CKTs IB07-YEL/GRN and IB08-YEL/RED carefully for cutting or chafing. If the wiring pigtail of the passenger air bag assembly is damaged, the component must be replaced.

DTC 18 Passenger Deployment Loop Short To Ground

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Ignition switch "OFF." 3. Connect scan tool data link connector. Follow directions as given in the scan tool operator's manual. 4. Ignition switch "ON." 5. Read passenger sense LO. Is passenger sense LO less than 1.5 volts?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Disconnect passenger air bag assembly yellow 2-pin connector behind the glove box assembly.. 3. Leave driver air bag assembly connected. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to passenger air bag assembly harness connector. 4. Ignition switch "ON." Is DTC 18 current?	Go to Step 4	Ignition switch "OFF." Replace passenger air bag assembly. Go to Step 6
4	1. Ignition switch "OFF." 2. Disconnect SRS driver / passenger load tool. 3. Measure resistance on SDM harness connector from terminal "15" to terminal "6" (ground). Does J-39200 display "OL" (infinite)?	Go to Step 5	Replace SRS harness. Go to Step 6
5	Measure resistance on SDM harness connector from terminal "6" "16" to terminal (ground). Does J-39200 display "OL" (infinite)?	Go to Chart A.	Replace SRS harness. Go to Step 6
6	1. Reconnect all components, ensure all component are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 6

DTC 19 Passenger Deployment Loop Short To Voltage

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM monitors the voltages at "Driver Bag Low" terminal "4" and "Passenger Bag Low" terminal "16" to detect short to B+ in the air bag assembly circuits.

DTC Will Set When:

"Ignition 1" is within the normal operating voltage range. Once these conditions are met and the voltage at "Passenger Bag Low" is above a specified value, DTC 19 will set. This test is run once each ignition cycle and "Continuous Monitoring".

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets DTC 19 and also DTC 71.

DTC Will Clear When:

The SDM is replaced.

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:

2. This test determines whether the malfunction is in the SDM.
3. This test isolates the malfunction to one side of the passenger air bag assembly yellow 2-pin connector behind glove box compartment.
4. This test determines whether the malfunction is in CKT IB07-YEL/GRN.

9J1-24 RESTRAINT CONTROL SYSTEM

5. This test determines whether the malfunction is in CKT IB08-YEL/RED.

Diagnostic Aids:


An intermittent condition is likely to be caused by a short to B+ in the passenger air bag assembly circuit. Inspect CKTs IB07-YEL/GRN and IB08-YEL/RED carefully for

cutting or chafing. If the wiring pigtail of the passenger air bag assembly is damaged, the component must be replaced. A careful inspection of CKT IB07-YEL/GRN and IB08-YEL/RED, including the passenger air bag assembly pigtail is essential to ensure that the replacement SDM will not be damaged.

DTC 19 Passenger Deployment Loop Short To Voltage

CAUTION: When DTC 19 has been set, it is necessary to replace the SDM. Setting DTC 19 and 25 or 51 or 53 will also cause DTC 71 to set. When a scan tool "CLEAR CODES" command is issued and the malfunction is no longer present, DTC 71 will remain current. Ensure that the short to voltage condition is repaired prior to installing a replacement SDM to avoid damaging the SDM.

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Ignition switch "OFF." 3. Connect scan tool data link connector. Follow directions as given in the scan tool operator's manual. 4. Ignition switch "ON." 5. Read passenger sense LO. Is passenger sense LO more than 3.5 volts?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Disconnect passenger air bag assembly yellow 2-pin connector behind the glove box assembly. 3. Leave driver air bag assembly connected. 4. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to passenger air bag assembly harness connector. 5. Ignition switch "ON." Is passenger sense LO more than 3.5 volts?	Go to Step 4	Ignition switch "OFF." Replace passenger air bag assembly. Go to Step 6
4	1. Ignition switch "OFF." 2. Disconnect SDM. 3. Disconnect SRS driver / passenger load tool. 4. Measure resistance on SDM harness connector from terminal "15" to terminal "12" (IGNITION 1). Does J-39200 display "OL" (infinite)?	Go to Step 5	Replace SRS harness. Go to Step 6
5	Measure resistance on SDM harness connector from terminal "16" to terminal "12" (IGNITION 1). Does J-39200 display "OL" (infinite)?	Go to Chart A.	Replace SRS harness. Go to Step 6
6	1. Reconnect all components, ensure all component are properly mounted. 2. Ignition switch "ON." Is passenger sense LO less than 3.5 volts?	Ignition switch "OFF." Replace SDM. Go to Step 7	Go to Chart A.
7	1. Reconnect all components, ensure all component are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 7

DTC 21 Driver Deployment Loop Resistance High

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges.

The SDM then proceeds with the "Resistance Measurement Test" "Driver Bag Low" terminal "4" is grounded through a current sink and the driver current source connected to "Driver Bag High" terminal "3" allows a known amount of current to flow. By monitoring the voltage difference between "Driver Bag High" and "Driver Bag Low", the SDM calculates the combined resistance of the driver air bag assembly, SRS coil assembly, harness wiring CKTs IB05-YEL and IB06-YEL/BLK, and connector terminal contact.

DTC Will Set When:

The combined resistance of the driver air bag assembly, SRS Coil assembly, harness wiring CKTs IB05-YEL and IB06-YEL/BLK, and connector terminal contact is above a specified value. This test run once each ignition cycle during the "Resistance Measurement Test" when:

No "higher priority faults" are detected during "Turn-ON"

"Ignition 1" voltage is in the specified value.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets DTC 21.

DTC Will Clear When:

The ignition switch is turned "OFF".

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:


2. This test determines whether the malfunction is in the SDM.
3. This test verifies proper connection of the yellow 2-pin connector at the base of the steering column.
4. This test checks for proper contact and/or corrosion of the 2-pin connector terminals at the base of steering column.
5. This test isolate the malfunction to one side of the SRS coil assembly yellow 2-pin connector located at the base of the steering column.
6. This test determines whether the malfunction is due to high resistance in the wiring.
7. This test determines whether the malfunction is in the SRS coil assembly or the driver air bag assembly.

Diagnostic Aids:

An intermittent condition is likely to be caused by a poor connection at terminals "1" and "2" of the SRS coil 2-pin connector at the base of the steering column, terminal "1" and "2" of the driver air bag assembly 2-pin connector at the top of the steering column, SDM terminals "3" and "4" or a poor wire to terminal connection in CKT IB05-YEL or IB06-YEL/BLK. The test for this diagnostic trouble code is only run while the "AIR BAG" warning lamp is performing the bulb check, unless DTC 17 or DTC 26 is detected. When a scan tool "Clear Codes" command is issued and the malfunction is still present, the DTC will not reappear until the next ignition cycle.

DTC 21 Driver Deployment Loop Resistance High

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	<ol style="list-style-type: none"> When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. Use scan tool data list function, read and record the driver deployment loop resistance. <p>Is driver deployment loop resistance more than 4.4 ohms?</p>	Go to Step 3	Go to Chart A.
3	<ol style="list-style-type: none"> Ignition switch "OFF." Disconnect driver air bag assembly yellow 2-pin connector located at base of steering column is seated properly. <p>Is the 2-pin connector connected properly?</p>	Go to Step 4	Seat SRS coil assembly 2-pin connector properly.Go to Step 8
4	<ol style="list-style-type: none"> Disconnect and inspect the SRS coil assembly yellow 2-pin connector located base of steering column. If OK, reconnect the SRS coil assembly yellow 2-pin connector. Ignition switch "ON." <p>Is DTC 21 current?</p>	Go to Step 5	Ignition switch "OFF." Go to Step 8
5	<ol style="list-style-type: none"> Ignition switch "OFF." Disconnect SRS coil and passenger air bag assembly yellow 2-pin connectors located at the base of steering column and behind the glove box assembly. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to SRS coil and passenger air bag assembly harness connectors. Ignition switch "ON." <p>Is DTC 21 current?</p>	Go to Step 6	Go to Step 7
6	<ol style="list-style-type: none"> Ignition switch "OFF." There has been a increase in the total circuit resistance of the driver deployment loop. Use the high resolution ohmmeter mode of the DVM while checking CKTs IB05-YEL/IB06-GRN and YEL/BLK, and SDM connector terminal "3" and "4" to locate the root cause. <p>Was a fault found?</p>	Replace SRS harness. Go to Step 8	Go to Chart A.
7	<ol style="list-style-type: none"> Ignition switch "OFF." <p>Disconnect SRS driver / passenger load tool from SRS coil assembly harness connector.</p> <p>Connect SRS driver / passenger load tool J-41433 on the top of steering column.</p> <p>Reconnect SRS coil assembly harness connector as the base of steering column.</p> <p>Ignition switch "ON."</p> <p>Is DTC 21 current?</p>	Ignition switch "OFF." Replace SRS COIL ASSEMBLY. Refer to in this section 9J-24. Go to Step 8	Ignition switch "OFF." Replace driver air bag assembly. Go to Step 8
8	<p>Reconnect all components, ensure all component are properly mounted.</p> <p>Clear diagnostic trouble codes.</p> <p>Was this step finished?</p>	Repeat the "SRS Diagnostic System Check."	Go to Step 8.

DTC 22 Driver Deployment Loop Resistance Low

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM then proceeds with the "Resistance Measurement Test" "Driver Bag Low" terminal "4" is grounded through a current sink and the driver current source connected to "Driver Bag High" terminal "3" allows a known amount of current to flow. By monitoring the voltage difference between "Driver Bag High" and "Driver Bag Low" the SDM calculates the combined resistance of the driver air bag assembly, SRS coil assembly, harness wiring CKTs IB05-YEL and IB06-YEL/BLK and connector terminal contact.

DTC Will Set When:

The combined resistance of the driver air bag assembly, SRS coil assembly, harness wiring CKTs IB05-YEL and IB06-YEL/BLK and connector terminal contact is above a specified value. This test is run once each ignition cycle during the "Resistance Measurement Test" when:

1. No "higher priority faults" are detected during "Turn-ON"
2. "Ignition 1" voltage is in the specified value.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets DTC 22.

DTC Will Clear When:

The ignition switch is turned "OFF."

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:


2. This test determines whether the malfunction is in the SDM.
3. This test verifies proper connection of the yellow 2-pin connector at the base of the steering column.
4. This test checks for proper operation of the shorting clip in the yellow 2-pin connector.
5. This test isolate the malfunction to one side of the SRS coil assembly yellow 2-pin connector located at the base of steering column.
6. This test determines whether the malfunction is due to shorting in the wiring.
7. This test determines whether the malfunction is in the SRS coil assembly or the driver air bag assembly.

Diagnostic Aids:

An intermittent condition is likely to be caused by a short between CKT IB05-YEL or IB06-YEL/BLK or a malfunctioning shorting clip on the driver air bag assembly or SRS coil assembly which would require replacement of the component. The test for this diagnostic trouble code is only run while the "AIR BAG" warning lamp is performing the bulb check, unless DTC 17 or DTC 26 is detected. When a scan tool "Clear Codes" command is issued and the malfunction is still present, the DTC will not reappear until the next ignition cycle.

DTC 22 Driver Deployment Loop Resistance Low

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Use scan tool data list function, read and record the driver deployment loop resistance. Is driver resist. less than 1.9 ohms?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Make sure the SRS coil assembly yellow 2-pin connector located at the base of steering column is seated properly. Is the 2-pin connector connected properly?	Go to Step 4	Seat driver air bag assembly 2-pin connector properly. Go to Step 8
4	1. Disconnect and inspect the SRS coil assembly yellow 2-pin connector located base of steering column. 2. If OK, reconnect the driver air bag assembly yellow 2-pin connector. 3. Ignition switch "ON." Is DTC 22 current?	Go to Step 5	Ignition switch "OFF." Go to Step 8
5	1. Ignition switch "OFF." 2. Disconnect SRS coil and passenger air bag 2-pin connectors located at the base of steering column and behind the glove box assembly. 3. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to SRS coil and passenger air bag assembly harness connectors. 4. Ignition switch "ON." Is DTC 22 current?	Go to Step 6	Go to Step 7
6	1. Ignition switch "OFF." 2. There has been a decrease in the total circuit resistance of the driver deployment loop. 3. Use the high resolution ohmmeter mode of the DVM while checking CKTs IB05-YEL and IB06-YEL/BLK, and SDM connector terminal "3" and "4" to locate the root cause. Was a fault found?	Replace SRS harness. Go to Step 8	Go to Chart A.
7	1. Ignition switch "OFF." 2. Disconnect SRS driver / passenger load tool from SRS coil assembly harness connector. 3. Connect SRS driver / passenger load tool J-41433 to the top of steering column. 4. Reconnect SRS coil assembly harness connector as the base of steering column. 5. Ignition switch "ON." Is DTC 22 current?	Ignition switch "OFF." Replace SRS coil assembly. Refer to in this section 9J-24. Go to Step 8	Ignition switch "OFF." Replace driver air bag assembly. Go to Step 8
8	1. Reconnect all components, ensure all component are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 8

DTC 24 Driver Deployment Loop Short To Ground

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM monitors the voltage at "Driver Bag Low" terminal "4" and "Passenger Bag Low" terminal "16" to detect shorts to ground in the air bag assembly circuits.

DTC Will Set When:

Neither of the two air bag assemblies is open. "Ignition 1" is within the normal operating voltage range. This test is run once each ignition cycle and "Continuous Monitoring". Once these conditions are met and the voltage at "Driver Bag Low" is below a specified value, DTC 24 will set.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

The malfunction is no longer occurring and the ignition is turned "OFF."

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:

2. This test determines whether the SDM is malfunctioning
3. This test isolates the malfunction to one side of the SRS coil assembly yellow 2-pin connector at the base of the steering column.
4. This test determines whether the malfunction is in CKT IB05-YEL.

9J1-32 RESTRAINT CONTROL SYSTEM


5. This test determines whether the malfunction is in CKT IB06-YEL/BLK.
6. This test determines whether the malfunction is in the SRS coil assembly or the driver air bag assembly.

Diagnostic Aids:

An intermittent condition is likely to be caused by a short to ground in the driver air bag assembly circuit. Inspect CKTs IB05-YEL and IB06-YEL/BLK carefully for cutting or chafing.

DTC 24 Driver Deployment Loop Short To Ground

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	<ol style="list-style-type: none">1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A.2. Ignition switch "OFF."3. Connect scan tool data link connector. Follow directions as given in the scan tool operator's manual.Ignition switch "ON."4. Read driver sense LO. Is driver sense LO less than 1.5 volts?	Go to Step 3	Go to Chart A.
3	<ol style="list-style-type: none">1. Ignition switch "OFF."2. Disconnect SRS coil assembly yellow 2-pin connector located at base of the steering column. Leave passenger air bag assembly connected.3. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to SRS coil assembly harness connector.4. Ignition switch "ON." Is DTC 24 current?	Go to Step 4	Go to Step 6
4	<ol style="list-style-type: none">1. Ignition switch "OFF."2. Disconnect SDM.3. Disconnect SRS driver / passenger load tool.4. Measure resistance on SDM harness connector "3" to terminal "6" (ground). Does J-39200 display "OL" (infinite)?	Go to Step 5	Replace SRS harness. Go to Step 7
5	Measure resistance on SDM harness connector from terminal "4" to terminal "6" (ground). Does J-39200 display "OL" (infinite)?	Go to Chart A.	Replace SRS harness. Go to Step 7
6	<ol style="list-style-type: none">1. Ignition switch "OFF."2. Disconnect SRS driver / passenger load tool J-41433 from SRS coil assembly harness connector.3. Connect SRS driver / passenger load tool J-41433 and appropriate adapter J-35616-A to driver air bag assembly harness connector. Located top of the steering column.4. Reconnect SRS coil assembly harness connector as the base of steering column.5. Ignition switch "ON." Is DTC 24 current?	Ignition switch "OFF." Replace SRS coil assembly. Refer to in this section 9J-24. Go to Step 7	Ignition switch "OFF." Replace driver air bag assembly. Go to Step 7
7	<ol style="list-style-type: none">1. Reconnect all components, ensure all component are properly mounted.2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 7

DTC 25 Driver Deployment Loop Short To Voltage

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. The SDM monitors the voltage at "Driver Bag Low" terminal "4" and "Passenger Bag Low" terminal "16" to detect shorts to B+ in the air bag assembly circuits.

DTC Will Set When:

"Ignition 1" is in the normal operating voltage range. This test is run once each ignition cycle and "Continuous Monitoring". Once these conditions are met and the voltage at "Driver Bag Low" is above a specified value, DTC 25 will set.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets DTC 25 and also DTC 71

DTC Will Clear When:

The SDM is replaced.

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:

2. This test determines whether the SDM is malfunctioning.
3. This test isolates the malfunction to one side of the SRS coil assembly yellow 2-pin connector at the base of steering column.
4. This test determines whether the malfunction is in CKT IB05-YEL.
5. This test determines whether the malfunction is in CKT IB06-YEL/BLK.

9J1-34 RESTRAINT CONTROL SYSTEM

6. This test determines whether the malfunction is in the SRS coil assembly or the driver air bag assembly.


Diagnostic Aids:

An intermittent condition is likely to be caused by a short to B+ in the driver air bag assembly circuit. Inspect CKTs IB05-YEL and IB06-YEL/BLK carefully for cutting or chafing. If the wiring pigtail of the driver air bag assembly and SRS coil assembly is damaged, the components must be replaced. A careful inspection of CKT IB05-YEL and IB06-YEL/BLK, including the SRS coil assembly and driver air bag assembly is essential to ensure that the replacement SDM will not be damaged.

DTC 25 Driver Deployment Loop Short To Ignition

CAUTION: When DTC 25 has been set, it is necessary to replace the SDM. Setting DTC 25 will also cause DTC 71 to set. When a scan tool "CLEAR CODES" command is issued and the malfunction is no longer present, DTC 71 will remain current. Ensure that the short to voltage condition is repaired prior to installing a replacement SDM to avoid damaging the SDM.

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Ignition switch "OFF." 3. Connect scan tool data link connector. Follow directions as given in the scan tool operator's manual. 4. Ignition switch "ON." 5. Read driver sense LO. Is driver sense LO more than 3.5 volts?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Disconnect SRS coil assembly yellow 2-pin connector at the base of the steering column. Leave passenger air bag assembly connected. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to SRS coil assembly harness connector. 3. Ignition switch "ON." Is driver sense LO more than 3.5 volts?	Go to Step 4	Go to Step 6
4	1. Ignition switch "OFF." 2. Disconnect SDM. 3. Disconnect SRS drive / passenger load tool. 4. Measure resistance on SDM harness connector from terminal "3" to terminal "12" (Ignition 1). Does J-39200 display "OL" (infinite)?	Go to Step 5	Replace SRS harness. Go to Step 7
5	Measure resistance on SDM harness connector from terminal "4" to terminal "12" (Ignition 1). Does J-39200 display "OL" (infinite)?	Go to Chart A.	Replace SRS harness. Go to Step 7
6	1. Ignition switch "OFF." 2. Connect SRS driver / passenger load tool J-41433 and appropriate adapter J-35616-A to driver air bag assembly harness connector located at top of the steering column. 3. Reconnect SRS coil assembly harness connector at the base of steering column. 4. Ignition switch "ON." Is driver sense LO more than 3.5 volts?	Ignition switch "OFF." Replace SRS coil assembly. Go to Step 7	Ignition switch "OFF." Replace driver air bag assembly. Go to Step 7
7	1. Reconnect all components, ensure all components are properly mounted. 2. Ignition switch "ON." Is passenger sense LO less than 3.5 volts?	Replace SDM. Go to Step 8	Go to Chart A.
8	1. Reconnect all components, ensure all components are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 8

DTC 26 Driver Deployment Loop Open

D09RW002

Circuit Description:

When the ignition switch is turned "ON", the SDM will perform tests to diagnose critical malfunctions within itself. Upon passing these tests, "ignition 1", and deployment loop voltages are measured to ensure they are within their respective normal voltage ranges. During "Continuous Monitoring" diagnostics, a fixed amount of current is following in the deployment loop. This produces proportional voltage drops in the loop. By monitoring the voltage difference between "Driver Bag High" and "Driver Bag Low", the SDM calculates the combined resistance of the driver air bag assembly, SRS coil assembly, harness wiring CKTs IB05-YEL and IB06-YEL/BLK, and connector terminal contact.

DTC Will Set When:

The voltage difference between "Driver Bag High" terminal "3" and "Driver Bag Low" terminal "4" is above or

equal to a specified value for 500 milliseconds during "Continuous Monitoring."

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

The voltage difference between "Driver Bag High" terminal "3" and "Driver Bag Low" terminal "4" is below a specified value for 500 milliseconds during "Continuous Monitoring."

DTC Chart Test Description:

Number(s) below refer to circled number(s) on the diagnostic chart:

1. This test determines whether the malfunction is in the SDM.


2. This test verifies proper connection of the yellow 2-pin connector at the base of the steering column.
3. This test checks for proper contact and/or corrosion of the yellow 2-pin connector at the base of the steering column.
4. This test isolates the malfunction to one side of the SRS coil assembly yellow 2-pin connector located at the base of steering column.
5. This test determines whether the open is in the wiring.
6. This test determines whether the malfunction is in the SRS coil assembly or the driver air bag assembly.

Diagnostic Aids:

An intermittent condition is likely to be caused by a poor connection at the driver air bag assembly harness 2-pin connector terminals "1" and "2" at the top of the steering column, SRS coil assembly harness 2-pin connection terminals "1" and "2", SDM terminals "3" and "4", or an open in CKTs IB05-YEL and IB06-YEL/BLK.

DTC 26 Driver Deployment Loop Open

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. When measurements are requested in this chart use J-39200 DVM with correct terminal adapter from J-35616-A. 2. Use scan tool data list function, read and record the driver differential voltage. Is driver differential voltage more than 4.0 volts?	Go to Step 3	Go to Chart A.
3	1. Ignition switch "OFF." 2. Make sure the SRS coil assembly yellow 2-pin connector located at the base of steering column is seated properly. Is the yellow 2-pin connector connected properly?	Go to Step 4	Seat driver air bag assembly 2-pin connector. Go to Step 8
4	1. Disconnect and inspect the SRS coil assembly yellow 2-pin connector located base of steering column. 2. If OK, reconnect the SRS coil assembly yellow 2-pin connector. 3. Ignition switch "ON". Is DTC 26 current?	Go to Step 5	Ignition switch "OFF." Go to Step 8
5	1. Ignition switch "OFF." 2. Disconnect SRS coil and passenger air bag assembly, yellow 2-pin connectors located at the base of steering column and behind the glove box assembly. 3. Connect SRS driver / passenger load tool J-41433 and appropriate adapter to SRS coil and passenger air bag assembly harness connectors. 4. Ignition switch "ON." Is DTC 26 current?	Go to Step 6	Go to Step 7
6	1. Ignition switch "OFF." 2. There has been an open circuit in the driver deployment loop. Use the high resolution ohmmeter mode of the DVM while checking CKTs IB05 YEL and IB06 YEL/BLK, and SDM connector terminal "3" AND "4" to locate the root cause. Was a fault found?	Replace SRS harness. Go to Step 8	Go to Chart A.
7	1. Ignition switch "OFF." 2. Disconnect SRS driver / passenger load tool from SRS coil assembly harness connector. 3. Connect SRS driver / passenger load tool J-41433 on steering column. 4. Reconnect SRS coil assembly harness connector as the base of steering column. 5. Ignition switch "ON." Is DTC 26 current?	Ignition switch "OFF." Replace SRS coil assembly, refer to in this section 9J-3. Go to Step 8	Ignition switch "OFF." Replace driver air bag assembly. Go to Step 8
8	1. Reconnect all components, ensure all component are properly mounted. 2. Clear diagnostic trouble codes. Was this step finished?	Repeat the "SRS Diagnostic System Check."	Go to Step 8

DTC 51 Deployment Event Commanded

D09RW002

Circuit Description:

The SDM contains a sensing device which converts vehicle velocity changes to an electrical signal. The electrical signal generated is processed by the SDM and then compared to a value stored in memory. When the generated signal exceeds the stored value, the SDM will cause current to flow through the air bag assembly deploying the air bags and causing DTC 51 to set.

DTC Will Set When:

The SDM detects a frontal crash, up to 30 degrees off the centerline of the vehicle, of sufficient force to warrant deployment of the air bags.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp records "Crash Data", and sets a diagnostic trouble code.

DTC Will Clear When:

The SDM is replaced.

DTC Chart Test Description:

Number(s) below refer to step number(s) on the diagnostic chart:


2. If air bag assembly (s) has not deployed, DTC 51 may have falsely set.
3. If DTC 51 has set with no signs of frontal impact, the diagnostic trouble code has falsely set.

DTC 51 Deployment Event Commanded

WARNING: DURING SERVICE PROCEDURES. BE VERY CAREFUL WHEN HANDLING A SENSING AND DIAGNOSTIC MODULE (SDM). NEVER STRIKE OR JAR THE SDM. NEVER POWER UP THE SRS WHEN THE SDM IS NOT RIGIDLY ATTACHED TO THE VEHICLE. ALL SDM AND MOUNTING BRACKET FASTENERS MUST BE CAREFULLY TORQUED AND THE ARROW MUST BE POINTING TOWARD THE FRONT OF THE VEHICLE TO ENSURE PROPER OPERATION OF THE SRS. THE SDM COULD BE ACTIVATED WHEN POWERED WHILE NOT RIGIDLY ATTACHED TO THE VEHICLE WHICH COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY.

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	Ignition switch "OFF." Have air bag assemblies deployed?	Replace components and perform inspections as directed in "repairs and inspections required after an accident" in this section. Clear diagnostic trouble codes. Repeat the "SRS Diagnostic System Check."	Go to Step 3
3	Inspect front of vehicle and undercarriage for signs of impact. Were signs of impact found?	Replace components and perform inspections as directed in "repairs and inspections required after an accident" in this section. Clear diagnostic trouble codes. Repeat the "SRS Diagnostic System Check."	Ignition switch "OFF." Replace SDM. Reconnect all SRS system components, ensure all components are properly mounted. Repeat the "SRS Diagnostic System Check."

DTC 53 Deployment Commanded With Deployment Loop Fault Or Energy Reserves Out Of Range



D09RW002

Circuit Description:

The SDM contains a sensing drive which converts vehicle velocity changes to an electrical signal. The electrical signal generated is processed by the SDM and then compared to a value stored in memory. When the generated signal exceeds the stored value, the SDM will cause current to flow through the air bag assembly deploying the air bags. DTC 53 is set accompanying with DTC 51 when a deployment occurs while an air bag assembly circuit fault is present that could possible result in a no deployment situation in one or both air bag assemblies.

DTC Will Set When:

The SDM detects a frontal crash, up to 30 degrees off the centerline of the vehicle, of sufficient force to warrant deployment of the air bags and an inflator circuit fault is present.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp records "Crash Data", and sets a diagnostic trouble code.

DTC Will Clear When:

The SDM is replaced. If DTC 53 is set, one or more DTCs will be set in addition to DTC 53. Malfunction(s) setting DTC(s) (other than DTC 71) must be repaired so that DTC(s) will not be set when a new SDM is installed.

DTC Chart Test Description:


Number(s) below refer to step number(s) on the diagnostic chart:

2. If air bag assembly has not deployed, DTC 53 may have falsely set.
3. If DTC 53 has set with no signs of frontal impact, the diagnostic trouble code has falsely set.

DTC 53 Deployment Commanded With Deployment Loop Fault Or Energy Reserves Out Of Range

WARNING: DURING SERVICE PROCEDURES. BE VERY CAREFUL WHEN HANDLING A SENSING AND DIAGNOSTIC MODULE (SDM). NEVER STRIKE OR JAR THE SDM. NEVER POWER UP THE SRS WHEN THE SDM IS NOT RIGIDLY ATTACHED TO THE VEHICLE. ALL SDM AND MOUNTING BRACKET FASTENERS MUST BE CAREFULLY TORQUED AND THE ARROW MUST BE POINTING TOWARD THE FRONT OF THE VEHICLE TO ENSURE PROPER OPERATION OF THE SRS. THE SDM COULD BE ACTIVATED WHEN POWERED WHILE NOT RIGIDLY ATTACHED TO THE VEHICLE WHICH COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY.

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	Ignition switch "OFF." Have air bag assemblies deployed?	Replace components and perform inspections as directed in "repairs and inspections required after an accident" in this section. Clear diagnostic trouble codes. Repeat the "SRS Diagnostic System Check."	Go to Step 3
3	Inspect front of vehicle and undercarriage for signs of impact. Were signs of impact found?	Replace components and perform inspections as directed in "repairs and inspections required after an accident" in this section. Clear diagnostic trouble codes. Repeat the "SRS Diagnostic System Check."	Ignition switch "OFF." Replace SDM. Reconnect all SRS system components, ensure all components are properly mounted. Repeat the "SRS Diagnostic System Check."

DTC 61 Warning Lamp Circuit Failure

D09RW002

Circuit Description:

When the ignition switch is turned "ON", battery voltage is applied to the "AIR BAG" warning lamp and to the "ignition 1" input terminal "12". The SDM responds by flashing the "AIR BAG" warning lamp seven times. The SDM monitors the lamp driver output by comparing the output state at "SRS warning lamp" terminal "7" to the microprocessor commanded state. When "ignition 1" is in the specified value, and the output state Does not match the commanded state of the lamp driver for 500 milliseconds, DTC 61 is set.

DTC Will Set When:

"Ignition 1" voltage is in the specified value and the output state at the "SRS warning lamp" terminal does not match

the commanded state of the lamp driver for 500 milliseconds. This test is run every 100 milliseconds during "Continuous Monitoring" tests and once per each ignition cycle at the beginning.

Action Taken:

SDM attempts to turn "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

The ignition switch is turned "OFF."


Diagnostic Aids:

Refer to Charts B and C to diagnose warning lamp circuit malfunctions.

DTC 61 Warning Lamp Circuit Failure

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	1. Malfunctions within the "AIR BAG" warning lamp circuitry will set this diagnostic trouble code. 2. These malfunctions are addressed in the "SRS Diagnostic System Check" via Chart B and Chart C. 3. Failure to properly perform the "SRS Diagnostic System Check" may result in misdiagnosis. 4. Ignition switch "ON." 5. Clear SRS diagnostic trouble codes. Is DTC 61 SET?	Ignition switch "OFF." Go to Chart A.	Repeat the "SRS Diagnostic System Check."

DTC 71 Internal SDM Fault



D09RW002

Circuit Description:

DTC 71 is an indication of a potential internal SDM malfunction and will set if any of the following conditions are detected:

- 1) Deployment or microprocessor energy reserve failure.
- 2) EEPROM failure.
- 3) ROM failure.
- 4) RAM failure.
- 5) Calibration check sum failure.
- 6) Deployment switch faults.
- 7) Accelerometer fault.
- 8) Arming sensor fault.
- 9) Diagnostic current faults.
- 10) DTC 19
- 11) DTC 25
- 12) DTC 51
- 13) DTC 53

DTC Will Set When:

Any of the above indicated malfunctions are detected by the SDM. The malfunctions described above are tested mainly during "Continuous Monitoring" and some ones run each ignition cycle.

Action Taken:

SDM turns "ON" the "AIR BAG" warning lamp and sets a diagnostic trouble code.

DTC Will Clear When:

A scan tool "Clear Codes" commanded is received by the SDM. Some of the indicated malfunctions will only allow the "AIR BAG" warning lamp to go out. But when DTC 19, 25, 51, 53 are also set, SDM is Replaced.

DTC 71 Internal SDM Fault

WARNING: DURING SERVICE PROCEDURES. BE VERY CAREFUL WHEN HANDLING A SENSING AND DIAGNOSTIC MODULE (SDM). NEVER STRIKE OR JAR THE SDM. NEVER POWER UP THE SRS WHEN THE SDM IS NOT RIGIDLY ATTACHED TO THE VEHICLE. ALL SDM AND MOUNTING BRACKET FASTENERS MUST BE CAREFULLY TORQUED AND THE ARROW MUST BE POINTING TOWARD THE FRONT OF THE VEHICLE TO ENSURE PROPER OPERATION OF THE SRS. THE SDM COULD BE ACTIVATED WHEN POWERED WHILE NOT RIGIDLY ATTACHED TO THE VEHICLE WHICH COULD CAUSE DEPLOYMENT AND RESULT IN PERSONAL INJURY.

CAUTION: When DTC 19 or 25 or 51 or 53 has been set it is necessary to Replace the SDM. Setting DTC 19 and 25 or 51 or 53 will also cause DTC 71 to set. When a scan tool "CLEAR CODES" command is issued and the malfunction is no longer present, DTC 51 or 53 and DTC 71 will remain current. Ensure that the short to voltage condition DTC 19, 25 is repaired prior to installing a Replacement SDM to avoid damaging the SDM.

Step	Action	Yes	No
1	Was the "SRS Diagnostic System Check" performed?	Go to Step 2	Go to the "SRS Diagnostic System Check."
2	Note SRS "Diagnostic System Check." Is DTC 19 or 25 or 51 or 53 also set (current or history)? (Refer to notice above).	Go to DTC 19 if DTC 19 is set. Go to DTC 25 if DTC 25 is set. Go to DTC 51 if DTC 51 is set. Go to DTC 53 if DTC 53 is set.	Ignition switch "OFF." Replace SDM. Repeat the "SRS Diagnostic System Check."

RODEO

CONTROL SYSTEM

CRUISE CONTROL SYSTEM

CONTENTS

Service Precaution	10A-1	Cruise Actuator	10A-4
General Description	10A-1	Actuator Cable Diagram	10A-4
Diagnosis	10A-2	Removal	10A-4
Brake Switch	10A-2	Installation	10A-4
Removal and Installation	10A-2	Adjustment	10A-4
Adjustment	10A-2	Mode Switch	10A-5
Clutch Switch	10A-3	Removal and Installation	10A-5
Removal and Installation	10A-3	Cruise Control Main Switch	10A-5
Adjustment	10A-3	Removal	10A-5
Cruise Control Unit	10A-3	Installation	10A-5
Removal	10A-3	Cruise Control Switch (Combination Switch)	10A-6
Installation	10A-3	Removal and Installation	10A-6

Service Precaution

WARNING: THIS VEHICLE HAS A SUPPLEMENTAL RESTRAINT SYSTEM (SRS). REFER TO THE SRS COMPONENT AND WIRING LOCATION VIEW IN ORDER TO DETERMINE WHETHER YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING. WHEN YOU ARE PERFORMING SERVICE ON OR NEAR THE SRS COMPONENTS OR THE SRS WIRING, REFER TO THE SRS SERVICE INFORMATION. FAILURE TO FOLLOW WARNINGS COULD RESULT IN POSSIBLE AIR BAG DEPLOYMENT, PERSONAL INJURY, OR OTHERWISE UNNEEDED SRS SYSTEM REPAIRS.

CAUTION: Always use the correct fastener in the proper location. When you replace a fastener, use **ONLY** the exact part number for that application. ISUZU will call out those fasteners that require a replacement after removal. ISUZU will also call out the fasteners that require thread lockers or thread sealant. **UNLESS OTHERWISE SPECIFIED, do not use supplemental coatings (Paints, greases, or other corrosion inhibitors) on threaded fasteners or fastener joint interfaces. Generally, such coatings adversely affect the fastener torque and the joint clamping force, and may damage the fastener. When you install fasteners, use the correct tightening sequence and specifications. Following these instructions can help you avoid damage to parts and systems.**

General Description

The cruise control keeps the vehicle running at a fixed speed until a signal canceling this fixed speed is received. When the main switch "AUTO CRUISE" is turned on with the vehicle in the running mode, the battery voltage is applied to the control unit. When a signal from the control switch is input to the control unit while the vehicle is in this state, the cruise control actuator is activated to operate the system. Also, while the system is operating, the "AUTO CRUISE" indicator light in the meter assembly lights up.

1 . SET/COAST Switch Function

- 1. Set Function:** When the SET/COAST switch is pressed and released with the main switch on, the speed at which the vehicle is running at that moment is stored in the memory, and the vehicle automatically runs at the speed stored.
- 2. Coast-Down Function:** When the SET/COAST switch is kept on while the vehicle is running, the vehicle decelerates during that time. The speed at which vehicle is running when the control switch is turned off is stored in the memory, and the vehicle automatically returns to the stored speed.
- 3. Tap-Down Function:** When the SET/COAST switch is turned on and off instantaneously while the vehicle is running, the vehicle decelerates a mile for each on/off operation. The vehicle speed at which the vehicle was running when the SET/COAST was turned off last is stored in the memory, and the vehicle automatically returns to this stored speed.

2 . RESUME/ACCEL Switch Function

1. **Resume Function:** When the RESUME, ACCEL switch is turned on/off after the system is temporarily deactivated by pressing the brake or clutch pedal while the vehicle is running, the vehicle resumes, the speed stored before the system was released.
2. **Accelerate Function:** When the RESUME/ACCEL switch is kept on after the system is released completely, the vehicle accelerates its speed during that time. The vehicle speed at which the vehicle was running when the switch was turned off is stored in the memory, and the vehicle automatically returns to this speed.
3. **Tap-Up Function:** When the RESUME/ACCEL switch is turned on and off instantaneously while the vehicle is running, the vehicle decelerates a mile for each on/off operation. The vehicle speed at which the vehicle was running when the switch was turned off last is stored in the memory, and the vehicle automatically returns to this stored speed.

3 . CANCEL Function

1. Temporary Cancellation:

- When the brake pedal is pressed.
- When the clutch pedal is pressed. (M/T)
- When the select lever is shifted to any position other than "D", "3", "2" or "L". (A/T)
- When the vehicle speed has decreased about 12.5 mph (20 km/h) or more than the stored speed.

2. Complete Cancellation:

- When the starter switch or the main switch is turned off.
- When the failsafe function is activated.

Diagnosis

Refer to the Cruise Control System Diagnosis in Wiring System section.


Brake Switch

Removal and Installation

Refer to the Brake Pedal Replacement in Brake section.

Adjustment

1. Check that the brake pedal (3) is fully returned by pedal return spring.
2. Disconnect the switch connector.
3. Loosen the lock nut (2).
4. Rotate the brake switch (1) by hand until push rod disappears from brake switch tip (4).
5. Return the brake switch by a half turn.
6. Tighten the lock nut.
7. Connect the switch connector.



310RS028

Clutch Switch


Removal and Installation

Refer to the Clutch Control removal and installation steps in Clutch section.

Adjustment

1. Turn the clutch switch (1) until the switch plunger is fully retracted against the clutch pedal arm.
2. Adjust clutch switch by backing it out half a turn and measure the clearance (4) between the clutch pedal arm (3) and the clutch switch.
3. Lock the lock nut(2).
4. Connect clutch switch connector.

Clutch Switch (bolt) and Clutch Pedal Clearance
0.5 – 1.5 mm (0.020 – 0.059 in)




203RS016-1

Cruise Control Unit

Removal

1. Disconnect the battery ground cable.
2. Remove the rear console box assembly.
 - Remove four screws.
3. Remove the cover (3).
 - Remove four nuts.
4. Remove the cruise control unit (1).
 - Disconnect the connector (2).




82SRX017

Installation

To install, follow the removal steps in the reverse order.

Cruise Actuator

Actuator Cable Diagram




825RW083

Legend

- | | |
|------------------------------|---|
| (1) Cruise Actuator Assembly | (3) Accelerator Cable |
| (2) Cruise Control Cable | (4) Throttle Link (Cruise Control Side) |

Removal

1. Disconnect the battery ground cable.
2. Remove the cruise actuator assembly (4).
 - Disconnect the connector (3).
 - Remove the cable end (1) from the throttle link (cruise control side).
 - Loosen two fixing nuts (2).
 - Remove three actuator assembly fixing screws.



825RW049

Installation

To install, follow the removal steps in the reverse order, noting the following point:


1. Take care not to bend the cable excessively.

Adjustment

After installing the cruise actuator, the following steps must be carried out for cruise control cable adjustment.

1. Install the cruise control cable end (3) to the throttle link (4).
2. Put the screw portion of the cable in the bracket (5).
3. Put the nut (1) to the bracket and then tighten the nut (2).

- If the distance between the throttle link (4) and the throttle link lever (6) is out of the specified range, loosen the nut (2) to adjust it.



Mode Switch


Removal and Installation

Refer to the Mode Switch removal and installation steps in Automatic Transmission section.

Cruise Control Main Switch

Removal

1. Disconnect the battery ground cable.
2. Remove the meter cluster assembly (1).
○Refer to the Instrument Panel Assembly in Body Structure section.
3. Remove the rear defogger switch (2).
○Disconnect the switch connector.
○To remove the switch, push the lock from the back side of the instrument panel cluster assembly.



Installation

To install, follow the removal steps in the reverse order.

Cruise Control Switch (Combination Switch)

Removal and Installation

Refer to the Lighting Switch (Combination Switch) removal and installation steps in Lighting System section.