


















Table of Contents

	Service Information	1
	Exterior parts and muffler	2
	Inspection and adjustment	3
Engine	Lubrication System	4
	Cooling System	5
	Fuel System	6
	Engine Mounting / Dismounting	7
	Cylinder heads and valves	8
	Clutch	9
	Gear shift linkage	10
	Crankshaft, piston and transmission	11
Frame	Front wheel, suspension and steering	12
	Rear wheel, suspension	13
	Brake System	14
Electrical System	Charging system, alternator	15
	Ignition System	16
	Starting system, starter clutch	17
	Lamp, instruments and switches	18
	Wiring diagrams	19
	Troubleshooting	20

◆ **Symbol Marking**





Symbol Marks

Symbol	Meaning	Symbol	Meaning
	Danger: Its neglect may lead to serious injuries.		Important: Its neglect may lead to injury or damaging the parts.
			General caution: Tips of the work

Symbol	Meaning	Symbol	Meaning
	Apply oil: Unless specified, use designated or recommended oil.		Apply sealant
	Apply Molybdenum solution: The solution is a mixture of engine oil and Molybdenum grease		Replace with new parts whenever disassembled.
	Apply multi-purpose grease. (Lithium soap based NLG #2 equivalent. Example: SHELL Albania EP-2		Apply brake fluid. Use recommended grade (DOT4)
	Apply Molybdenum grease (3% or more Molybdenum, NLGI#2 equivalent) Mitsubishi multi purpose M2 Dow Corning Molycoat BR – 2 PLUS		Apply recommended cushion oil.
	Apply Molybdenum paste. (40% or more Disulphide Molybdenum. NLGI#2 equivalent). Local paste Molycote G-n Paste (Dow Corning)		Use exclusive tools
	Apply silicone grease Silicone grease G40M (ShinEtsu)		O.P. (Option) tool. Refer to parts list as these tools are considered to be parts.
	Apply screw locker. Use medium class unless specified.		Reference pages.

Serial number, Colour label.....	1-1	Exclusive tools.....	1-14
Specifications.....	1-2	Oil, grease and sealant.....	1-16
Maintenance.....	1-4	Wiring Diagram.....	1-18
Torque settings.....	1-11		

Serial Numbers, Colour Label





When ordering coloured parts, specify a model name and a colour code.

Item				Specification
Name				HONDA VT250/V25
Length				2,315mm
Width				845mm
Height				1,055mm
Wheel base				1,620mm
Powerplant type				MC15E
Total displacement				0.249∞
Fuel				Petrol/Unleaded
Vehicle weight		Front axle		83kg
		Rear axle		100kg
		Total		183kg
Seating Positions				2
Gross weight		Front axle		103kg
		Rear axle		190kg
		Total		293kg
Tyre		Front		120 / 80 – 17 61S
		Rear		150 / 80 – 15M/C 70S
Minimum clearance (ground)				130mm
Brake – stop distance (initial speed)				14.0m (initial 50km/h)
Minimum turning radius				3.1m
Powerplant	Starting method			Electric
	Type of the powerplant			Petrol 4 cycle/stroke
	Cylinder			V 2 abreast
	Combustion chamber			Pentroof
	Valve operation			D O H C chain driven
	Bore X stroke			60.0 x 44.1mm
	Compression ratio			11.0
	Maximum output power			27 PS / 10,000rpm
	Maximum torque			2.3kg-m / 7,500rpm
	Valve operation timing	Inlet	Open	15° BTDC (1mm lifted)
			Close	20° ABDC (1mm lifted)
		Exhaust	Open	30° BBDC (1mm lifted)
			Close	0° TDC (1mm lifted)
	Lubrication			Compress splash combined
	Oil pump			Trochoid
	Oil filter			Total flow filter net-paper combined
Cooling system			Water cooled (electric fan)	
Radiator			Colgate type (closed-sealed)	
Water pump			Centrifugal pump	
Fuel System	Air cleaner		Type	Filter paper type
	Carburettor		Gas valve dia.	VDD2
			Venturi dia.	32mm
				Variable (max lift 29mm)

Item			Specification	
Transmission	Clutch	Type	Multiple wet plate coil spring	
		Operation	Mechanical	
	Initial reduction	Type	Gear	
		Reduction ratio	1.821 (79/28)	
	Gear shift system	Type	Full time contact	
		Operation	Left foot pedal	
		Gear ratio	First	2.733 (41/15)
			Second	1.800 (36/20)
			Third	1.375 (33/24)
			Fourth	1.111 (30/27)
Fifth	0.965 (28/29)			
Final reduction	Type	Chain		
	Reduction ratio	2.714 (38/14)		
Wheels	Caster	35°00		
	Trail	159mm		
Steering	Steering angle	Left	38°	
		Right	38°	
Brake system	Type	Front	Hydraulic disc	
		Rear	Mechanical leading / trailing shoe	
Shock absorbing system	Suspension	Front wheel	Telescopic type	
		Rear	Swing arm type	
Frame			Double cradle	
Frame number			MC29 – 1000001	
Engine number			MC15E – 1200001	

◆ Maintenance Date

Lubrication

Item	Standard	Service Limit
Engine oil capacity Total capacity Oil change Oil and filter change	2.4℥ 1.9℥ 2.1℥	
Recommended oil (select the proper viscosity grade which matches your operating temperature range)	Honda Genuine GP (4 cycle motorcycle) SAE10W-40 or SAE20W-50	
<p>Oil Viscosity with temperature</p>  <p>Outside Temperature -10 0 10 20 30 40 °C</p>		
Oil pressure (at the oil pressure switch mount area)	5.0-6.0kg/cm ² (5,000rpm/80°C)	
Oil pump		
① tip clearance	0.15mm	0.20mm
② body clearance	0.15 – 0.22mm	0.35mm
③ side clearance	0.02 – 0.07mm	0.10mm
		



Cooling System

Item	Standard	Service Limit
Coolant		
Total	1.1℥	
Reserve tank capacity	0.2℥	
Standard density	30%	
Radiator cap valve opening pressure	1.1 – 1.4kg/cm ²	
Thermostat		
Valve opening temp (initial)	80 - 84°C	
Valve full-open temp.	95°C	
Full open lifting	8mm or more	

Fuel System

Item	Standard	Service Limit
Fuel tank capacity	11℥	
Carburettor		
Setting mark	VDD2A	
Main jet	#110	
Front	#108	
Rear	#35	
Slow jet		
Pilot screw opening		
Standard	3 revs rewind	
After idle drop	1 rev rewind	
Float level	6.8mm	
Inter cylinder synchronised pressure difference	40mm Hg or less	
Base carburettor	Rear cylinder carburettor	
Idling rpm	1,200 ± 100rpm	
Throttle grip free play (at the grip flange)	2 – 6mm	



Cylinder Head, Valve

Item	Standard	Service Limit
Cylinder compression	13.0 ± 2.0kg/cm ² - 400rpm	
Valve clearance	IN EX	0.15 – 0.19mm 0.20 – 0.24mm
Cylinder head distortion		0.10mm
Cam shaft	① Cam height IN EX ② Deflection (at journal)	32.4612 – 32.6212mm 32.3085 – 32.4685mm 0.02mm
		
Journal external dia.	A, C	21.949 – 21.970mm 21.861 – 21.882mm
Cam shaft journal oil clearance	A, C B	0.030 – 0.091mm 0.118 – 0.181mm
Locker arm internal diameter		10.000 – 10.015mm
Locker arm shaft external diameter		9.972 – 9.987mm
Valve stem external dia.	IN EX	4.975 – 4.990mm 4.955 – 4.970mm
Valve guide internal dia.	IN EX	5.000 – 5.012mm 5.000 – 5.012mm
Valve stem guide clearance	IN EX	0.010 – 0.037mm 0.030 – 0.057mm
Valve guide installation height	(h)	11.4 – 11.6mm
		
Valve seat contact width		1.0mm
Valve spring relaxed length		36.42mm


Clutch

Item	Standard	Service Limit
Clutch lever free play	10 – 20mm	
Clutch outer internal diameter	29.000 – 29.021mm	29.06mm
Clutch outer guide	External diameter Internal diameter	28.967 – 28.980mm 21.995 – 22.015mm
Oil pump drive sprocket internal dia	29.025 – 29.075mm	29.11mm
Clutch spring relaxed length	34.79mm	33.9mm
Clutch disc thickness	A B	3.62 – 3.70mm 2.9 – 3.0mm
Clutch plate distortion	-	0.30mm

Transmission

Item		Standard	Service Limit
Gear shift pattern		1 – N – 2 – 3 – 4 – 5	
Gear internal dia.	M4, M5	25.000-25.021mm	25.05mm
	C1	23.000-23.021mm	23.05mm
	C2, C3	28.000-28.021mm	28.05mm
Gear bush external dia.	M4, M5	24.959-24.980mm	24.92mm
	C1	22.959-22.980mm	22.92mm
	C2, C3	27.959-27.980mm	27.92mm
Gear bush internal dia.	M4	21.985-22.006mm	22.07mm
	C1	20.020-20.041mm	20.06mm
	C2	25.000-25.021mm	25.05mm
Gear bush clearance	M4, M5, C1, C2, C3	0.020-0.062mm	0.10mm
Main shaft external dia.	M4 bush	21.959-21.980mm	21.92mm
			
Counter shaft external dia.	C1 bush	19.987-20.000mm	19.97mm
	C2 bush	24.967-24.980mm	24.95mm
			
Bush shaft clearance	M4 bush	0.005-0.047mm	0.15mm
Shift fork	C1, C2 bush	0.020-0.054mm	0.15mm
	Catch thickness	5.93-6.00mm	5.60mm
Shift fork shaft external diameter	Internal diameter	12.000-12.021mm	12.04mm
		11.969-11.980mm	11.90mm

Cylinder, Piston

Item		Standard	Service Limit
Cylinder	Internal diameter	60.000 – 60.015mm	60.10mm
	Top surface distortion	-	0.10mm
	True-circle	-	0.05mm
	True-cylinder	-	0.05mm
Piston	External diameter (D)	59.970 – 59.990mm	59.86mm
	D-measuring point (H)	-	-
	Pin hole diameter (d)	16.002 – 16.008mm	16.028mm
			
Cylinder – Piston clearance		0.010 – 0.045mm	0.10mm
Piston pin external diameter		15.994 – 16.000mm	15.98mm
Piston – Piston pin clearance		0.002 – 0.014mm	0.048mm
Piston pin – Conrod clearance		0.016 – 0.040mm	0.10mm
Piston ring	Ring groove-ring clearance	0.025 – 0.060mm	0.10mm
	Top	0.025 – 0.055mm	0.10mm
	Second	0.20 – 0.35mm	0.65mm
	Ring cut out	0.20 – 0.35mm	0.50mm
Installing – direction work	Top	0.20 – 0.70mm	0.85mm
	Side rail	R mark towards top	-
	Top	R N mark towards top	-
	Second		

Crankshaft

Item		Standard	Limitation
Crankshaft type		Forged one-piece crankshaft	-
Crankshaft bearing type		Split plane bearing	-
Conrod	smaller end internal diameter	16.016 - 16.034mm	16.08mm
	bigger end side clearance	0.1 – 0.3mm	0.4mm
Crankpin oil clearance		0.028 – 0.052mm	0.07mm
Conrod bearing selection		(⇒ 11-14)	-
Main journal oil clearance		0.028 – 0.052mm	0.07mm
Main bearing selection		(⇒ 11-14)	-

Front / Rear Wheel

Item		Standard	Service Limit
Tyre groove depth	Front Rear		1.5mm 2.0mm
Tyre air pressure one person (normal/high speed)	Front Rear	2.00kg/cm ² 2.00kg/cm ²	
two people (normal)	Front Rear	2.00kg/cm ² 2.00kg/cm ²	
Front axle deflection			0.2mm
Wheel rim deflection	Radial Side		2.0mm 2.0mm
balance weight	Front		60g
Drive chain free play (when using a sidestand)		25 – 35mm	
Size / links	DID RK	DID520V6 / 110 RK520SMOZ2 / 110	


Front suspension

Item		Standard	Service Limit
Fork Stroke		150mm	
Pipe diameter		41mm	
Spring relaxed length		329.2mm	319.3mm
Pipe bent			0.20mm
Oil type		Honda Ultra Cushion Oil #10	
Oil level		150mm	
Oil capacity		477cc	
Steering load		0.93 – 1.40kg	

Rear Suspension

Item		Standard	Service Limit
Rear suspension stroke		57.5mm	
Rear cushion damper type		conventional type	

Brake System

Item		Standard	Service Limit
Front brake	Lever free play Brake fluid type Pad thickness	10 – 20mm DOT 4	Up to the wear limit groove
	Disc thickness	4.8 – 5.2mm	4.0mm
	Disc deflection		0.1mm
	Master cylinder internal diameter	11.000 – 11.043mm	11.055mm
	Master piston external diameter	10.957 – 10.984mm	10.945mm
	Caliper cylinder internal diameter	25.400 – 25.450mm	25.460mm
	Caliper piston external diameter	25.335 – 25.368mm	25.310mm
	Rear brake Pedal free play	20 – 30mm	
	Lining thickness	5.0mm	2.0mm
	Drum internal diameter	160.0 – 160.3mm	161mm

Charging System, Alternator

Item		Standard	Service Limit
Alternator	Type	Three – phased AC	
	Output	332 W / 5,000rpm	
	Charging coil resistance (20°C)	0.1 – 1.0 Ω	
Regulator / Rectifier			
	Type	Three phased AC total regulate	
		SCR short circuit	
Battery	Regulated voltage	14 – 16V / 5,000rpm	
	Capacity	12V – 6Ah	
	Charge current / time	Standard 0.7A / 5 – 10h	
		Rapid 3.0A / 1h	
	Leak current	0.1mm or less	
	Discharge voltage (20°C)	Full charge 13.0V or above	
		Charge req'd 12.3V or less	

Ignition System

Item		Standard	Service Limit
Ignition type		Full transistor battery ignition	
	Ignition sequence	Front ⇒ 270° ⇒ Rear ⇒ 450° ⇒ Front	
	Spark plug	CR8EH – 9 (NGK)	
	Standard	U24FER9 (NIPPON DENSO)	
	OP (High speed ops)	CR9EH – 9 (NGK)	
		U27FER9 (NIPPON DENSO)	
Ignition timing	Plug gap	0.8 – 0.9mm	
	F mark	BTDC 10° / 1,200 ± 100rpm	
	Advance starting rpm	2,200rpm	
	Advance stop rpm	10,500rpm	
	Max. advance	35° / 10,000 ± 100rpm	
Ignition coil	Resistance		
	Primary coil	2–4 Ω	
	Secondary coil (with plug gaps)	15-21kΩ	
	Secondary coil (without plug gaps)	11-15kΩ	
Pulse generator	Peak voltage	100V or above	
	Resistance (20°C)	340 – 420 Ω	
	Peak voltage	0.7V or above	

Starting System

Item	Standard	Service Limit
Starter motor brush length	12.5 – 13.0mm	6.5mm
Starter clutch driven gear boss external diameter	42.175 – 42.200mm	42.16mm

Lamps, Instruments and Switches

Item	Standard	Service Limit
Main fuse	30A	
Sub fuse	10A x 3, 15A x 1	
Head lamp (Hi/Lo)	12V – 60 / 55W	
Stop / Tail lamp	12V – 23 / 8W	
Front turn signal / position lamp	12V – 23 / 8W x 2	
Rear turn signal lamp	12V – 23W x 2	
Turn signal pilot lamp	12V – 1.7W	
High beam pilot lamp	12V – 1.7W	
Neutral indicator	12V – 1.7W	
Instrument illumination lamps	12V – 3.4W	
Thermo – sensor resistance	130 - 180Ω / 50°C	
	45 - 60Ω / 80°C	
	10 - 20Ω / 120°C	
Fan motor switch activation temperature	OFF⇒ON ON⇒OFF	
	98 – 102°C	
	93 - 97°C	

Standard Torque Settings

Type	Torque	Type	Torque
5mm bolt, nut	0.5kg-m	5mm screw	0.4kg-m
6mm bolt, nut	1.0kg-m	6mm screw / SH flange bolt	0.9kg-m
8mm bolt, nut	2.2kg-m	6mm flange bolt, nut	1.2kg-m
10mm bolt, nut	3.5kg-m	8mm flange bolt, nut	2.7kg-m
12mm bolt, nut	5.5kg-m	10mm flange bolt, nut	4.0kg-m

Tighten with the above specified torque unless specified in the following table.

- Notes:
1. Apply sealant
 2. Apply screw locker
 3. Stake
 4. Apply engine oil to the screw and the seat
 5. Apply grease
 6. V – Nut
 7. A lock nut (replace when removed)

Engine

Part	Number	Screw dia. (mm)	Torque (kg-m)	Notes
Lubrication:				
Oil drain bolt	1	12	3.0	
Oil filter centre bolt	1	12	1.8	
Oil pump mount bolt	3	6	1.2	
Oil pump cover bolt	3	6	1.3	
Oil pressure switch	1	-	1.2	Note 1
Oil pressure switch terminal bolt	1	4	0.23	
Oil pump driven sprocket bolt	1	6	1.5	Note 2
Cooling System:				
Water pump drain bolt	1	6	1.3	
Water pump housing cover bolt	1	6	1.3	
Fuel System:				
Boost joint	1	5	0.25	
Vacuum port plug	1	5	0.33	
Engine Mount / Dismount:				
Drive sprocket cover bolt	3	6	1.0	
Drive sprocket bolt	1	10	5.2	
Cylinder Head, Valve:				
Cylinder head cover bolt	8	6	1.0	
Spark plug	2	10	1.2	
Timing hole cap	1	45	1.8	Note 5
Cam shaft holder bolt	8	8	2.3	Note 4
8mm UBS bolt	4	8	3.4	Note 4
6mm UBS bolt	4	6	1.2	
6mm flange bolt	4	6	1.2	
Cylinder head bolt	4	8	3.4	Note 4
Cam sprocket bolt	4	7	1.9	Note 2
Valve adjust screw lock nut	4	5	1.0	Note 4
Locker arm shaft	4	20	5.0	Note 2
Cylinder head fin bolt	10	6	0.9	
Clutch:				
Clutch centre lock nut	1	20	8.5	Note 3,4
Gear shift linkage:				
Shift drum centre bolt	1	8	2.3	Note 2
Gear shift spindle return spring pin	1	8	2.5	

Part	Number	Diameter (mm)	Torque (kg-m)	Notes
Crankshaft, Piston and Transmission:				
Crankcase bolt	5	8	2.3	Note 4
8mm UBS bolt				
8mm flange bolt	2	8	2.3	Note 4
6mm special bolt	1	6	1.2	Note 4
6mm flange bolt	10	6	1.2	Note 4
Conrod bearing cap nut	4	7	2.4	Note 4
Charging System, Alternator:				
Flywheel bolt	1	10	8.5	Note 4
Starter, Starter Clutch:				
Primary drive gear bolt	1	10	8.5	Note 4
Starter clutch bolt	3	8	2.8	Note 2
Starter motor terminal nut	1	6	1.2	
Starter motor bolt	2	5	0.5	
Lamps, Instruments and Switches:				
Neutral switch	1	10	1.2	
Others:				
6mm SH flange bolt	-	6	1.0	

Frame

Part	Number	Diameter (mm)	Torque (kg-m)	Notes
Exterior Parts, Muffler:				
Exhaust pipe joint nut	4	6	1.3	
Muffler mount bolt	1	8	2.7	
Exhaust pipe band bolt	3	8	2.0	
Muffler protector bolt	1	6	1.3	
Front exhaust pipe mount bolt	1	8	2.7	
Cooling System:				
Radiator mount bolt	2	6	1.2	
Radiator side cover bolt	4	6	1.2	
Fan motor switch	1	16	1.8	
Thermo – sensor	1	-	0.9	Note 1
Fuel System:				
Fuel cock mount bolt	1	18	2.7	
Carburettor side cover bolt	4	5	0.4	
Air cleaner stay mount bolt	2	6	0.9	
Engine Mount:				
Front engine mount nut	1	10	4.5	
Rear lower engine mount nut	1	10	4.5	
Rear upper engine mount nut	1	10	4.5	
Carburettor side cover stay bolt	2	6	0.9	
Gear shift arm bolt	1	6	1.6	
Main step holder bolt	4	8	2.7	

Torque	Number Of parts	Diameter (mm)	Torque (kg-m)	Notes
Front Wheel, Suspension and Steering:				
Front master cylinder holder bolt	2	6	1.2	
Clutch lever bracket holder bolt	2	6	1.2	
Handle mount nut	2	12	7.0	
Front axle bolt	1	14	6.0	
Front axle holder strip bolt	4	8	2.2	
Front brake disc bolt	6	8	4.3	Note 7
Front caliper mount bolt	2	8	3.1	Note 7
Front fender bolt	4	6	1.2	
Fork top bridge split bolt	2	8	2.7	
Fork bottom bridge split bolt	2	10	4.0	
Fork cap	2	37	2.3	
Fork drain bolt	2	6	0.8	
Fork socket bolt	2	8	2.0	Note 2
Brake hose clamp nut	2	6	1.2	Note 6
Steering stem nut	1	24	10.5	
Steering bearing adjust nut	1	26	3.1	Note 4
Rear Wheel, Suspension:				
Rear axle nut	1	16	9.0	Note 6
Rear brake stopper arm nut	2	8	2.2	
Final driven sprocket nut	5	10	6.5	Note 6
Rear cushion upper mount bolt	2	6	0.9	
Rear cushion lower mount bolt	2	10	3.8	
Swing arm pivot nut	1	14	9.0	Note 6
Drive chain slider screw	2	5	0.6	
Drive chain adjuster lock nut	2	8	2.2	
Brake System:				
Bleed valve	1	8	0.6	
Pad pin plug	1	10	0.25	
Pad pin	1	10	1.8	
Brake hose oil bolt	2	10	3.5	
Front brake lever pivot bolt	1	6	0.1	
Front brake lever pivot nut	1	6	0.6	
Front brake switch screw	1	4	0.12	
Front brake reservoir cap screw	2	4	0.15	
Front caliper pin bolt A	1	8	2.3	Note 2
Front caliper pin bolt	1	8	1.3	Note 2
Rear brake arm bolt	1	8	2.9	Note 7
Rear brake pedal pivot bolt	1	8	2.7	
Rear brake middle arm bolt	1	8	2.7	
Lamps, Instruments and Switches:				
Main switch mount bolt	2	6	1.0	
Side stand switch bolt	1	6	1.0	
Others:				
Side stand pivot bolt	1	10	1.0	
Side stand pivot lock nut	1	10	3.0	
Gear shift pedal pivot bolt	1	8	2.7	

Special Tools

Tool Name	Tool Number	Application
Inspection / Adjustment: Drive chain cutter Cam shaft lifter Valve adjust driver Valve adjust wrench 8 x 9mm	07HMH-MR10102 07GMG-KV00100 07GMA-KT80110 07708-0030100	Drive chain replacement Valve clearance adjustment/inspection Valve clearance adjustment
Lubrication: Oil pressure gauge Oil pressure gauge attachment	07506-3000000 07510-4220100	Oil pressure measurement
Fuel System: Float level gauge	07401-0010000	Float level adjustment
Cylinder Head, Valve: Valve spring compressor Valve compressor attachment Valve guide driver Valve guide reamer, 5.010mm Valve seat cutter 45° seat surface cutter 24.5mm (IN) 45° seat surface cutter 22mm (EX) 32° plain cutter 24mm (IN) 32° plain cutter 22mm (EX) 60° internal surface cutter 22mm (IN,EX) Cutter holder 5.0mm	07757-0010000 07959-KM30101 07942-MA60000 07984-MA60001 07780-0010100 07780-0010701 07780-0012500 07780-0014202 07780-0014202 07781-0010400	Valve cotter removal/installation Valve guide removal/installation Valve guide cleaning/finishing Valve seat adjustment
Clutch: Lock nut wrench 17 x 27mm Clutch centre holder	07716-0020300 07GMB-KT70101	Clutch centre lock nut removal/installation
Front Wheel, Suspension and Steering: Fork seal driver Fork seal driver attachment Steering stem socket Steering stem driver Ball race remover - attachment - handle Bearing race remover Driver handle A Outer driver 42 x 47mm Outer driver 52 x 55mm	07947-KA50100 07947-KF00100 07916-3710101 07946-MB00000 07953-MJ10000 07953-MJ10200 07953-MJ10200 07946-3710500 07749-0010000 07746-0010300 07746-0010400	Fork guide bush, oil seal installation Steering bearing adjust nut removal/install Steering bearing lower inner race install Steering bearing upper outer race removal Steering bearing lower outer race removal Steering bearing outer race installation Steering bearing upper outer race install Steering bearing lower outer race install
Rear Wheel and Suspension: Driver shaft Bearing remover attachment Driver handle A Outer driver 28 x 30mm Pilot 22mm Outer driver 32 x 35mm Pilot 15mm	07946-MJ00100 07GMD-KT70200 07749-0010000 07946-1870100 07746-0041000 07746-0010100 07746-0040300	Swing arm pivot bearing removal Swing arm left pivot bearing removal Swing arm pivot bearing installation Swing arm left pivot bearing installation Swing arm right pivot bearing installation
Brake System: Snap ring pliers	07914-3230001	Master cylinder snap ring removal/install

Tool Name	Tool Number	Application
Charging System, Alternator: Multimeter (SANWA) Multimeter (KOWA) Universal holder Rotor puller	07308-0020001 TH – 5H 07725-0030000 07733-0020001	Regulate / Rectifier inspection Flywheel removal / installation
Ignition System: Peak voltage adapter	07HGJ-0020100	Peak voltage measurement
Starting System, Starter Clutch: Universal holder	07725-0030000	Primary drive gear bolt removal/installation



Engine



Application	Notes	Fluid Type
Crankcase 8mm UBS bolt thread, seat 8mm flange bolt thread, seat 6mm special bolt thread, seat 6mm flange bolt thread, seat Cylinder head bolt thread, seat Camshaft holder 8mm USB bolt thread, seat Piston external surface, piston pin hole Piston ring whole round Conrod bearing cap nut thread, seat Primary gear bolt thread, seat Flywheel, bolt thread, seat Valve adjust screw lock nut thread seat Clutch disc surface Clutch centre lock nut thread, seat Each bearing moving area Each O-Ring surface		Engine oil
Main bearing shaft holder / thrust surface Conrod bearing shaft holder surface Conrod small end internal diameter IN, EX valve stem (contact area with the valve guide) Locker arm contact surface, bearing Cam shaft cam surface, bearing Clutch outer contact surface M3, C4 and C5 gear (shift fork groove – all round) C1, C2, C3, M4 and M5 gear bush moving area Each gear matching area and bearings Each rotating contact surfaces		Molybdenum solution (engine oil): (Molybdenum grease) = 1:1
Crankcase contact surface ends Oil separator plate seal Breather joint Oil pressure switch thread Cylinder head half-round processed part	Do not apply to the main bearing. Do not apply to its end.	Sealant
Oil separator bolt thread Seal plate bolt thread Locker arm shaft thread Cam sprocket bolt thread Cam chain tensioner holder bolt thread Cam chain guide A, B bolts threads Oil pump driven sprocket bolt thread Shift drum bearing set plate bolt thread Shift fork shaft set plate bolt thread Shift drum centre bolt thread Starter clutch cover bolt thread Drive chain guide plate bolt thread	Coating width 6.5±1mm	Loctite
Timing hole cap thread Each oil seal lips		Multi purpose grease
Cylinder head cover gasket contact surface (cover side) Oil pan O-Ring groove	Wipe off any excess sealant	Bond (Cemedine #521)


Frame



Application	Notes	Fluid Type
Rear brake spindle pivot contact surface Main step contact area Pillion step contact area Gear shift pedal pivot contact area Rear brake pedal pivot contact area Rear brake pedal rod pin contact area Clutch lever pivot bolt Rear wheel sleeve surface Rear wheel O-Ring groove, O-Ring Wheel dust seal, oil seal lip Swing arm dust seal surface Swing arm needle bearing Steering bearing Steering bearing dust seal lip Speedometer gearbox Speedometer gear / pinion Rear brake cam, shoe contact surface Rear brake anchor pin shoe contact surface		Multi purpose grease
Side stand pivot Throttle pipe winder		Molybdenum grease
Steering handle grip rubber		Honda bond A
Caliper cylinder internal surface Caliper piston external surface Caliper piston seal Master cylinder internal surface Master cylinder piston external surface Master cylinder piston cup		Brake fluid DOT 4
Brake lever pivot, piston contact area Caliper pin contact area Caliper pin boot internal surface		Silicone grease
Rear brake cam felt seal Steering bearing adjust nut thread		Engine oil
Front fork oil seal lip Front fork O-Ring external surface Front fork dust seal lip		Honda Ultra cushion oil #10
Caliper pin bolt thread Fork socket bolt thread		Loctite
Thermo-sensor thread		Sealant

♦ Wiring Diagram









General Caution.....	2 – 1	Pivot plate cover.....	2 – 2
Troubleshooting.....	2 – 1	Fuel tank.....	2 – 3
Left side cover.....	2 – 2	Muffler and Exhaust Pipe.....	2 – 4
Right side cover.....	2 – 2	Rear Fender.....	2 – 6
Seat.....	2 - 2		

General Caution

- Petrol is highly flammable. Keep away from electrical spark as well as fire. Ventilate the working area.
- Muffler should be removed / installed when the engine is cool.

- Directions for removing / installing the exterior parts, the fuel tank and the muffler are given in this section.
- Refer to the wiring diagram for tubing / wiring.
- When removing the exterior parts, do not damage the projections or the grooves.
- Replace gaskets when removing / installing the muffler and the exhaust pipe.
- Check for exhaust leaks after installing the muffler.

Troubleshooting**Excessive exhaust noise**

- Muffler damaged
- Exhaust leak

Lack of power

- Muffler deformed
- Exhaust leak
- Muffler blocked


Left side cover removal / installation

Removal:

Insert the main switch key to the side cover lock cylinder and turn it right.
Pull a grommet on top of the side cover out from the frame boss. Then release the two catches from the grommets to remove the side cover.

Installation:


Insert the grommet to the frame boss. Insert the two catches to the frame grommets to install the side cover.
Turn the main switch key to the left to lock the cover.
Remove the key.



Right side cover removal / installation

Release three catches on the side cover from frame boss to remove the cover.

Reverse the procedure for its installation.




Seat removal / installation

Remove two socket bolts and one flange bolt.
Release the hook in the front from the frame to remove the seat.

Reverse the procedure for its installation.




Firmly insert the hook to the bottom of the cross plate on the frame.




Pivot plate cover removal / installation

Remove three socket bolts to remove the pivot plate cover.


Reverse the procedure for its installation.



♦ Fuel Tank Removal / Installation



When removing fuel tank, remove speedometer cable set screw on the front wheel side and remove the cable together with the tank.




- Highly flammable.
- Wipe off spilt petrol immediately.

Relevant Works

- Seat removal / installation (| 2-2)

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for its installation
(1)	Mount bolt / collar	1/1	
(2)	Vacuum tube	1	
(3)	Fuel tube	1	Disconnect it after turning the fuel cock OFF.
(4)	Speedometer cable set screw	1	
(5)	Speedometer cable	1	Pass through cable clamp
(6)	Speedometer lead coupler	1	Disconnect after moving the fuel tank back.
(7)	Fuel tank	1	Set the hook to the frame mount rubber when installing.

◆ Muffler and exhaust pipe removal/installation






The muffler should be removed / installed when the engine is cool.

Relevant Works

- Left and Right side cover removal / installation (| 2-2)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for its installation
(1)	Muffler protector bolt	1	Set the retainer to the two front muffler catches through grommet when installing. Loosen. No need to remove. Torques bolt (T40)
(2)	Muffler protector / grommet	1 / 2	
(3)	Exhaust pipe band bolt	2	
(4)	Rear muffler stainer bolt	2	Temporarily install and tighten the exhaust pipe band bolt first, when installing.
(5)	Muffler mount bolt / nut	1 / 1	
(6)	Washer	1	
(7)	Collar	1	Loosen. No need to remove.
(8)	Front muffler / rear muffler	1 / 1	
(9)	Muffler seal	2	
(10)	Exhaust pipe band bolt	1	Temporarily install and tighten the exhaust pipe joint nut and the band bolt first when installing.
(11)	Exhaust pipe joint nut	2	
(12)	Front exhaust pipe mount bolt	1	
(13)	Front exhaust pipe	1	Disconnect the pipe from the joint and remove from the top
(14)	Exhaust pipe gasket	1	
(15)	Seal	1	
(16)	Crankcase breather tube	1	
(17)	Exhaust pipe joint nut	2	
(18)	Rear exhaust pipe	1	
(19)	Exhaust pipe gasket	1	

◆ Rear Fender Removal/Installation



Relevant Works

- Seat removal / installation (| 2-2)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for its installation
(1)	Direction indicator / tail lamp lead connector	7	Loosen <ul style="list-style-type: none">• Remove together with the rear frame.• Clamp the direction indicator / tail lamp leads correctly when installing.
(2)	6mm bolt	2	
(3)	Cap nut	2	
(4)	8mm bolt	4	
(5)	Washer	4	
(6)	Rear side cover	2	
(7)	Rear fender	1	
(8)	Rear frame	1	

Service Information.....	3 - 1	Air Cleaner Element.....	3 - 12
Service Parts Layout.....	3 - 8	Valve Clearance.....	3 - 13
Drive Chain.....	3 - 10	Head Lamp Direction.....	3 - 14

Service Information

1. Pre-operation inspection does include high speed operation inspection.
2. λ is a compulsory service schedule and μ is a manufacturers recommendation.
3. X means it does not apply.
4. O is a regular replacement of safety parts. The schedule is for general operation. If the operating environment is quite different from the standard, the schedule should be adjusted.
5. A "high speed operation" means an operation at or above 80km/h.

Service Item			Schedule				Notes
			Pre-operation	1 month or 1000km	Every 6 months	Every 12 months	
Brake System	Hose	Brake hose replacement					O every four years
	Master/wheel cylinder, caliper	Master cylinder and wheel cylinder cups, dust seal and disc caliper rubber parts replacement.					O Bi-annual
	Brake pad	Pad wear			μ		Refer to 3 - 3
	Oil / grease	Brake fluid change					Annual
Powerplant	Main body	Air cleaner element change					Every 20,000km Inspect at each service
	Lubrication System	Engine oil change		μ			Initial one month or 1000km, then every 6000km.
		Oil filler change					Initial 13,000km, then every 12,000km
	Fuel System	Fuel hose change					O every four years
	Cooling System	Coolant change					O Bi-annual

Service Item			Schedule				Standard	Notes
			Pre-operation	1 month or 1000km	Every 6 months	Every 12 months		
Steering System	Handle	Free play, fit				λ		
		Movement				λ		
	Wheel	Turning (steering) angle				λ		
	Steering Fork	Damage			λ	λ		
		Fork spindle attachment			λ	λ		Steering stem
		Fork spindle bearing fit				λ		Steering stem
Brake System	Brake pedal	Free play and floor clearance when fully depressed			λ	λ	Freeplay pedal 20-30mm Lever (lever end) 10-20mm	
		Depressing surface and effectiveness	λ					
		Brake effectiveness		μ	λ	λ		
	Rod and cables	Fit and damage		μ		λ		
	Hose and pipe	Leak, damage and attachment		μ	λ	λ		
	Reservoir tank	Qty. level	λ		λ	λ	Qty level Front wheel: at or above MIN level	
	Master and wheel cylinder and disc caliper	Function, wear and damage				λ		
	Brake drum and brake shoe	Drum lining clearance			λ	λ		
		Shoe contact area and lining wear				λ		Indicator
		Drum wear and damage				λ	Diameter: Standard: Rear 160mm Limitation: Rear 161mm	

Service Item			Schedule				Standard			Notes
			Pre-operation	1 month or 1000km	Every 6 months	Every 12 months				
Brake System	Brake disc and pads	Disc pad clearance				λ				
		Pad wear				λ				Indicator
		Disc wear / damage				λ	Thickness: Standard: Front 5.0mm Limitation: Front 4.0mm			
Wheels	Wheels	Tyre pressure	λ	μ	λ	λ	Unit (kg/cm ²)			Check daily
									Front	Rear
							One person	Normal	2.00	2.00
								High speed	2.00	2.00
							2 people	Normal	2.00	2.00
							Tyre specification		120/80-17 61S	150/80-15M/C7 0s
		Tyre crack, damage	λ	μ	λ	λ				Check daily
		Tyre mark depth and unusual wear	λ	μ	λ	λ	Marking depth Front: 0.8mm Rear: 0.8mm			
		Debris on tyres	λ	μ	λ	λ				
		Wheel nut and wheel bolt tightness			λ	λ	Front axle holder torque: 1.8~2.5kg-m Front axle bolt torque: 5.5~6.5kg-m Rear axle nut torque: 8.0~10.0kg-m			Axle nut and axle holder
		Rim, side line		μ		λ	Wheel rim deflection at rim end: Front Side 2.0mm or less Radial 2.0mm or less Rear Side 2.0mm or less Radial 2.0mm or less			
		Front wheel bearing fit				λ				


Service Item			Schedule				Standard	Notes
			Pre-operation	1 month or 1000km	Every 6 months	Every 12 months		
Wheels	Wheel	Rear wheel bearing attachment / fit				λ		
Dampers	Chassis springs	Damage				λ		Cushion spring
	Suspension arm	Joint fit and arm damage				λ		
	Shock absorber	Oil leak and damage				λ		
		Attachment				λ		
Power transmission system	Clutch	Lever free play			λ	λ	At lever end 10 ~ 20mm	
		Movement		μ	λ	λ		
	Transmission	Oil leak and oil quantity			λ	λ	Oil quantity Observation window between MIN – MAX.	
		Operation, fit				λ		
	Propeller and drive shaft	Joint fit			λ	λ		X
		Spline fit				λ		X
		Free joint fit				λ		X
	Chain and sprocket	Chain tension		μ	λ	λ	When using a side stand at the centre of front and rear sprockets, 20 ~ 25mm maximum deflection.	
		Sprocket attachment and wear				λ		


Service Item			Schedule				Standard	Notes
			Pre-operation	1 month or 1000km	Every 6 months	Every 12 months		
Electrical System	Ignition System	Spark plug condition			λ	λ	Plug gap 0.8 ~ 0.9mm	
		Ignition timing			λ	λ		Service not required (service free system)
		Pulse generator			λ	λ		Service not required (non – contact)
		Advancing system (incl. Delaying system)				λ		Service not required (electrical advancing system)
	Battery	Battery fluid level			λ	λ		Service not required (sealed module)
		Specific gravity				λ		Service not required (sealed module)
		Terminal connection				λ		
	Wiring	Connection				λ		
Powerplant	Main Body	Starting and noise			λ	λ		
		Low speed and acceleration		μ	λ	λ	Idling rpm 1,200 ± 100rpm	
		Exhaust gas			λ	λ		
		Air cleaner element			λ	λ		

Service Item			Schedule				Standard	Notes
			Pre-operation	1 month or 1000km	Every 6 months	Every 12 months		
Powerplant	Main Body	Valve Clearance		μ		λ	(cold engine) Intake: 0.15 ~ 0.19mm Exhaust: 0.20 ~ 0.24mm	
	Lubrication System	Oil dirt and quantity			λ	λ	Oil level observation window between MIN – MAX lines	
		Oil leak			λ	λ		
		Oil quantity	λ		μ			Check before each ride
		Oil Filter				λ		Inspection not required. Cartridge type.
	Fuel System	Fuel leak			λ	λ		
		Carburetor linkage system				λ		
		Throttle valve and choke valve				λ		
		Fuel filter				λ		
		Fuel quantity	λ					
	Cooling System	Coolant level	λ		λ	λ	Reservoir tank between MIN – MAX lines.	
		Coolant leak	λ			λ		
		Radiator cap function				λ	Valve opening pressure 1.1 ~ 1.4kg/cm ²	
Lamps and Indicators		Operation			λ	λ		
		Flash, dirt and damage	λ					
Horn and Lock		Operation				λ		

Service Item		Schedule				Standard	Notes
		Pre-operation	1 month or 1000km	Every 6 months	Every 12 months		
Rearview Mirror	Mirror Image	λ					Rearview Mirror Inspect Daily
Reflector and registration plate holder	Dirt and Damage	λ					
Instruments	Operation				λ		
Exhaust Pipe and Muffler	Attachment and Damage				λ		
	Muffler Function				λ		
Chassis and body	Fit and Damage				λ		
Defects discovered on the previous days operation	Inspect the specific area.	λ					
Others	Chassis oil / greasing			λ	λ		

◆ Service Parts layout





Drive Chain

Replacement



- The master link joint pin is staked for the drive chain.
Use special tool and chain
- Never use the clip-type chain.


Loosen the drive chain.
Assemble the tool.

Excl. tool

Drive chain cutter
07HMH-MR10102




Read the instructions before using the staking tool.



Set the tool and cut the staked part.

Excl. tool

Drive chain cutter
07HMH-MR10102




Adjust the number of the new drive chain links with a drive chain cutter.



Include the master link to the number of links.

Standard links: 110 links
Replacement drive chain: DID520V6
RK520SM0Z2





Do not re-use the master link, the O-Rings or the link plate.

Set O-Rings to a new master link and install the master link from the inside of the chain. Do not jam the O-Rings.



- The stamped side of the master plate should face outwards.
- Do not jam the O-Rings




Install O-Rings and a link plate by using the exclusive tool.

Check the projection length of the master link joint pins from the link plate.

Standard: DID: 1.15 ~ 1.55mm

RK: 1.2 ~ 1.4mm

Stake the joint pin ends of the master link.



After staking, measure the staking size.

Staking size: DID: 5.4 ~ 5.6mm

RK: 5.5 ~ 5.8mm


If the size is out of the above range, redo staking by using a new master link, a link plate and O-Rings.

Inspect the staked area for cracks. Redo staking with a new master link, a link plate and O-Rings if there is any crack.


Note: Do not re-use old master link



Never use the clip-type chain joining link.



♦ Air Cleaner Element Replacement



Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation
(1)	Socket bolts	2	Release the top and bottom grooves on the element from the projections on the case to remove.
(2)	Right carburettor side cover	1	
(3)	Flange nut	2	
(4)	Flange bolt / collar	2/2	
(5)	Air cleaner case cover	1	
(6)	Air cleaner element	1	

Valve Clearance




The valve clearance should be checked when the engine is cold (at or below 35°C).

Remove the radiator (5-6).
Remove bolts to remove the horn and the radiator stay.
Remove four bolts to remove front cylinder head cover.

Remove fuel tank (2-3).
Remove two bolt caps.
Remove two torque bolts to disconnect the main switch bracket from the frame.
Remove four bolts to remove the rear cylinder head cover.

Remove the timing hole cap.
Rotate the crankshaft clockwise and align the crankshaft "T" marks (Rear: T1, Front: T2) with alignment marks on the right crankcase cover.
Check the cam top position of the measuring cylinder.







(Observing from the right of the body)

Set the cam shaft lifter to the camshaft so as to have the marked line on circular guide parallel to the cylinder head top surface.

Excl. tool


Cam shaft lifter
07GMG – KV00100



Insert a thickness gauge between the adjuster screw and a valve stem to measure the valve clearance.


Valve clearance: IN: 0.15 ~ 0.19mm
EX: 0.20 ~ 0.24mm

Adjust the clearance by rotating the adjust screw (loosen the lock nut) while the cam shaft lifter is attached.



Apply grease to the O-Ring and the thread of the timing hole cap and install the cap.


Torque: 1.8kg-m



Apply sealant to the half round part of the cylinder head and install the cylinder head cover. Tighten the cylinder head cover bolts.

Torque: 1.0kg-m

Mount the main switch bracket with two torque bolts.
Attach bolt caps.




Tighten the front bolt together with the earth terminal.

Install radiator (5-6).
Install fuel tank (2-3).

Head Lamp Adjustment

Place the vehicle on a horizontally flat surface and support it vertically.
Rotate adjust screws to adjust its direction.



General Caution.....	4 – 1	Oil filter replacement.....	4 – 3
Troubleshooting.....	4 – 1	Oil pump removal/installation.....	4 – 4
Lubrication diagram.....	4– 2	Oil pump assembly/disassembly.....	4 – 6

General Caution

- The oil pump may be serviced with the engine mounted to the frame.
- Keep the engine away from debris when removing / installing the pump.
- After the installation of the pump, check the oil pressure and inspect for oil leak.
- Refer to the main volume, Sec. 18 for the oil pressure switch inspection.

Troubleshooting**Insufficient oil quantity**

- Normal oil consumption.
- Oil leak to the outside of the engine.
- Piston ring wear / improper installation.
- Valve guide / stem wear.
- Valve stem seal damage.
- Cylinder / piston wear.

No oil pressure

- Insufficient amount of oil.
- Oil pump drive sprocket, drive chain and a driven sprocket disconnected / damaged.
- Oil pump failure.
- Internal oil leak in the engine.

Dirty Oil

- Oil / filter haven't been changed.
- Mixture with coolant (White)
 - water pump mechanical seal wear/damage.
 - Cylinder head gasket damage.
- Mixture with water (White)
 - water overflow from a storage tank.
- Piston ring wear.


Too high oil pressure

- Pressure relief valve does not open.
- Oil path, oil orifice jammed.
- Improper oil viscosity grade.

Too low oil pressure

- Pressure relief valve does not close.
- Oil strainer jammed.
- Oil filter jammed.
- Oil pump wear.
- Improper oil viscosity grade.
- Internal oil leak in the engine.
- Insufficient amount of oil.

◆ Lubrication Diagram



Oil Filter Replacement

Remove the oil drain bolt and drain the oil.
Remove the oil filter centre bolt and remove the oil filter cover, set spring, spring seat and the oil filter.

Replace the sealing washer for the oil drain bolt with a new one.

Install and tighten the oil drain bolt.

Torque: 3.0kg-m

Remove O-Rings from the oil filter centre bolt and the filter cover.

Apply engine oil to the new O-Rings and set them in the grooves on the oil filter cover and the centre bolt.


Install a new oil filter and set the spring seat, the set spring, the filter cover and the centre bolt.

Tighten the centre bolt.


Torque: 1.8kg-m

Refill with the recommended grade oil (1-4).

Start the engine and inspect for oil leaks.



◆ Oil Pump Removal/Installation




Relevant Works

- Right crankcase cover removal / installation (9-2).
- Front exhaust pipe (2-4).

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for its installation
(1)	Oil filter centre bolt / O-Ring	1/1	
(2)	Oil filter cover / O-Ring	1/1	
(3)	Oil filter set spring	1	
(4)	Spring seat	1	
(5)	Oil filter	1	
(6)	Oil pan bolt	9	
(7)	Oil pan	1	
(8)	Oil pan O-Ring	1	
(9)	24mm oil path collar	1	
(10)	O-Ring	1	
(11)	18mm oil path collar	1	
(12)	O-Ring	1	
(13)	Oil pump driven sprocket bolt	1	
(14)	Oil pump driven sprocket	1	Face the marked line inwards when installing
(15)	Oil strainer	1	Match the cutout with the projection on the oil pump.
(16)	Oil strainer gasket	1	
(17)	Oil pump mount bolt	3	
(18)	Oil pump	1	<ul style="list-style-type: none"> • Match the cutout of the water pump shaft with a projection on the oil pump shaft. • Assembly / disassembly (4-6)
(19)	Knock pin	1	
(20)	Oil orifice / O-Ring	1/1	

◆ Oil Pump Assembly/Disassembly

**Relevant Works**

- Oil pump removal / installation (4-4).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for its assembly.
(1)	Oil pump cover bolt	3	<ul style="list-style-type: none"> Face the screw hole end towards the cover. Set the drive pin to the groove on the inner rotor. (both for assembly)
(2)	Oil pump cover	1	
(3)	Knock pin	2	
(4)	Thrust washer	1	
(5)	Oil pump shaft	1	
(6)	Drive pin	1	
(7)	Inner rotor	1	
(8)	Outer rotor	1	
Relief valve			Do not remove unless needed.
(9)	Snap ring	1	
(10)	Spring seat	1	
(11)	Spring	1	
(12)	Piston	1	
(13)	Valve body	1	
(14)	O-Ring	1	

General Caution.....	5 – 1	Water pump assembly/disassembly..	5 – 5
Troubleshooting.....	5 – 1	Radiator removal/installation.....	5 – 6
Cooling system diagram.....	5 – 2	Radiator assembly/disassembly.....	5 – 7
Coolant drain.....	5 – 3	Reservoir and inner box removal /	
Thermostat		installation.....	5 - 8
assembly/disassembly.....	5 - 4		

General Caution



- If the coolant is suspected to be over 100°C, do not open the radiator cap until it cools down. Wrap the cap with a cloth when opening it.
- The cooling system should be serviced when the engine is cool.
- Keep your skin, eyes and clothes away from the coolant. Do not swallow it.
 - If the coolant contacts your skin and clothes, wash with soap and rinse it.
 - If the coolant contacts your eyes, rinse with water and consult a doctor.
 - If the coolant is swallowed, induce vomiting, gargle and consult a doctor.
 - Exercise caution with coolant storage and keep it away from the reach of children.
- Do not remove radiator cap unless you have to refill/drain coolant when the cooling system is disassembled.
- Keep the coolant away from the painted surfaces. If the coolant contacts the surface, wash with water.
- After the disassembly/inspection, inspect for coolant leak by using a radiator cap tester.
- Refer to the main volume Sec. 4 for the coolant refill and air bleeding.
- Refer to the main volume Sec. 18 for the fan motor switch, thermo sensor inspection.

Troubleshooting

Too high water temperature

- Water temp gauge or thermo sensor failure.
- Air in the cooling system.
- Thermostat failure (does not open).
- Radiator, hose or water jacket jam.
- Fan motor failure.
- Fan motor switch failure.
- Water pump failure.
- Insufficient coolant quantity.
- Radiator blocked.


Water leak

- Oil pump mechanical seal failure.
- O-Ring wear, loose contact.
- Radiator cap failure.
- Cylinder head gasket damaged.
- Loose hose connection.
- Hose wear / damage.

Too low water temperature

- Water temp gauge or thermo sensor failure.
- Thermostat failure.
- Fan motor switch failure.

◆ Cooling System Diagram




Coolant Drain




Do not open the radiator cap if the coolant is suspected to be above 100°C. Wait for the temperature to cool down and gently open it after wrapping the cap with a cloth.


Remove the stopper screw to remove the radiator cap.



Remove the drain bolt from the water pump and drain the coolant.




Remove the drain bolt from the front cylinder and drain the coolant.




Remove the left pivot plate cover (2-2). Disconnect the syphon tube and drain the coolant from a reservoir. Connect the syphon tube back to the reservoir. Install the drain bolt with a new sealing washer.

Torque: Water pump drain bolt 1.3kg-m.




♦ Thermostat Assembly / Disassembly

**Relevant Works**

- Coolant drain (5-3)
- Coolant refill / air bleeding

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for its assembly
(1)	Socket bolt	2	Loosen
(2)	Left carburetor side cover	1	
(3)	Thermo sensor connector	1	
(4)	Hose band screw	3	Remove from the hose
(5)	Thermostat case mount bolt	1	
(6)	Thermostat case	1	The air bleed hole should face forward when installing.
(7)	Thermostat case cover bolt	2	
(8)	Thermostat case cover	1	
(9)	O-Ring	1	
(10)	Thermostat	1	
(11)	Thermo sensor	1	

♦ Waterpump Assembly / Disassembly




Relevant Works

- Coolant drain (5-3)
- Coolant refill / air bleeding
- Left main step holder and drive sprocket cover removal/installation (15-8)

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for its assembly
(1)	Lower radiator hose band screw	1	Loosen
(2)	Water pump cover bolt	1	
(3)	Water pump mount bolt	2	
(4)	Water pump cover	1	
(5)	O-Ring	1	Remove from the pump body and a lower radiator hose. Remove from the pump cover.
(6)	Bolt / cable clamp	1/1	
(7)	Water pump body	1	<ul style="list-style-type: none"> • Remove from the engine together with the water pipe. • Match the water pump shaft cutout with the oil pump shaft projection when assembling.
(8)	O-Ring	1	
(9)	Water pipe	1	
(10)	O-Ring	2	Remove from water pump.

◆ Radiator Removal / Installation




Relevant Works

- Coolant drain (5-3)
- Coolant refill / air bleeding
- Fuel tank removal/installation (2-3)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for its installation
(1)	Upper radiator hose	1	Remove from mount boss by pushing towards the left.
(2)	Radiator syphon tube	1	
(3)	Lower radiator hose	1	
(4)	Radiator lead coupler	1	
(5)	Radiator mount bolt / collar	2/2	
(6)	Radiator	1	

♦ Radiator Assembly/Disassembly




Relevant Works

- Radiator removal / installation (5-6).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for its assembly
(1)	Radiator grill	1	Release the top side radiator catches first, then the lower side catches.
(2)	Radiator side cover bolt	4	
(3)	Radiator side cover	2	
(4)	Fan motor switch connector	1	Tighten the earth terminal together with the top bolt when assembling.
(5)	Shroud mount bolt	3	
(6)	Shroud / fan motor Assy	1	Correctly align the motor shaft and the fan plain when assembling.
(7)	Nut	1	
(8)	Fan	1	
(9)	Screw	3	
(10)	Fan motor	1	
(11)	Fan motor switch	1	
(12)	O-Ring	1	

♦ Reservoir and Inner box removal / installation



Relevant Works

- Rear fender removal / installation (2-6)
- Battery removal / installation (15-4)
- Swing arm removal / installation (13-6)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
	<u>Reservoir</u>		
(1)	Crankcase breather hose	1	Disconnect from rear cylinder head.
(2)	Storage tank blow-by hose	1	
(3)	Radiator syphon tube	1	
(4)	Reservoir mount bolt	1	
(5)	Reservoir	1	
	<u>Inner Box</u>		
(6)	Spark unit	1	
(7)	Direction indicator relay	1	
(8)	Fuse box	1	
(9)	Starter relay switch	1	
(10)	Bolt	2	
(11)	Inner box	1	

General Caution.....	6 – 1	Carburettor separation.....	6 – 4
Troubleshooting.....	6 – 1	Carburettor assembly/disassembly.....	6 – 6
Air chamber cover removal / installation.....	6 – 2	Carburettor synchronisation.....	6 – 8
Carburettor removal/installation.....	6 – 3	Pilot screw adjustment.....	6 – 8

General Caution



Petrol is highly flammable. Keep out of electrical spark as well as open fire.
Ventilate the working area, too, as evaporated petrol is also highly flammable.

- Do not overstress the cables to bend or twist. Damaged / deformed cables may cause failure.
- When assembling the component, replace the O-Ring.
- Drain the petrol in the carburetor before disassembling by loosening the float chamber drain screw. Place a collecting tray underneath.
- Cover the port with a cloth after removing a carburettor to prevent any objects to go into the engine.
- If the carburetor is to be stored for more than a month, drain petrol in the float chamber. Degraded petrol in the chamber may block the slow tubes and cause unstable idling.

Troubleshooting

Does not start

- Fuel does not reach the carburettor
 - fuel strainer blocked
 - fuel tube blocked
 - float valve stuck
 - improper float level
 - fuel tank cap breather hole blocked
 - fuel auto cock failure
- Too much fuel in cylinder
 - air cleaner blocked
 - carburettor overflow
- Intake system sucking secondary air
- Degraded petrol
- Bi-starter valve failure
- Slow system or bi-starter system blocked

The engine starts, but stops soon. Idling is unstable.

- Fuel system blocked
- Mixture too lean / too rich
- Fuel quality degraded
- Inlet taking secondary air
- Idling rpm improperly adjusted
- Fuel auto cock operation failure
- Pilot screw improperly adjusted
- Slow or bi-starter system jammed
- Float level improperly adjusted
- Fuel tank cap breather hole blocked
- Carburettor synchronisation failure
- Ignition system failure (Sec. 16)

Too lean mixture

- Fuel jet clogged
- Float valve failure
- Float level too low
- Fuel system clogged
- Carburettor air vent tube clogged
- Inlet taking secondary air
- Fuel auto cock operation failure
- Vacuum piston operation failure

Too rich mixture

- Bi-starter valve is always operating
- Float valve operation failure
- Float level too high
- Air jet clogged
- Air cleaner element is dirty
- Carburettor overflow


After burn when using engine brake

- Slow system mixture too lean
- Air cut valve operation failure

Backfire, misfire on acceleration

- Mixture too lean
- Ignition system fault (Sec. 16)



♦ Air chamber cover removal/installation

**Relevant Works**

- Right carburettor side cover removal/installation (3-12)
- Fuel tank removal/installation (2-3)
- Left carburettor side cover removal/installation (5-4)

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for its installation
(1)	Connecting tube band screw	1	Loosen
(2)	Stay bolt / collar	2/2	
(3)	Air cleaner stay mount bolt	2	Remove with the air cleaning stay
(4)	Air cleaner case	1	
(5)	Connector	3	Disconnect ignition coils and thermal sensor
(6)	Left carburettor side cover stay bolt	2	
(7)	Coupler	2	Disconnect from frame pin and move the harness upwards.
(8)	Main wire harness clip	1	
(9)	Storage tank blow-by hose	1	<ul style="list-style-type: none"> • Push it up until it touches the frame. Then move it towards front and remove it to the right. • Do not damage the mating surface of air chamber.
(10)	Air chamber cover screw	4	
(11)	Air chamber cover	1	

◆ Carburettor removal / installation




Adjust the throttle free play after installing the carburettor.

Relevant Works

- Air chamber cover removal/installation (6-2)

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for its installation
(1)	Choke knob	1	Loosen the nut and disconnect from the bracket.
(2)	Carburettor insulator band screw	2	Loosen the screws and remove the carburettor ASSY from the insulator.
(3)	Cable holder screw	2	
(4)	Throttle cable holder	1	
(5)	Throttle cable	2	Disconnect from throttle drum
(6)	Carburettor ASSY	1	<ul style="list-style-type: none"> • Separation (6-4) • Disassembly / assembly (6-6)



◆ Carburettor Separation




Relevant Works


- Carburettor removal/installation (6-3)

Works / Parts		Qty.	Notes
(1)	Separation Bi-starter valve / choke cable	2/1	Reverse the procedure for jointing. <ul style="list-style-type: none"> • Loosen bi-starter valve nut to disconnect the valve from the carburettor and disconnect the cable from clamp. • When jointing, clamp the cable correctly (see the figure below). Unlatch the lock plate catch. Remove together with the air funnel. Check the direction when jointing. Correctly clamp the tube (see the figure below).
(2)	Screw	4	
(3)	Lock plate	2	
(4)	Air chamber	1	
(5)	Air funnel	2	
(6)	Knock pin	4	
(7)	Fuel tube	2	
(8)	Cotter pin	2	
(9)	Washer	2	
(10)	Plastic washer	4	
(11)	Throttle link	1	
(12)	Air vent tube	2	
(13)	Carburettor joint screw/clamp	1/1	
(14)	Fuel joint / O-Ring	1/2	



◆ Carburettor Assembly/Disassembly





- The vacuum chamber, the float chamber and the jets can be serviced without removing the carburettor.
- Separate and store each part for the carburettor for re-assembly.

Relevant Works

- Carburettor separation (6-4)

Works / Parts		Qty.	Notes
(1) (2) (3) (4) (5) (6) (7)	Disassembly		Reverse the procedure for its assembly
	<u>Vacuum Chamber</u>		
	Screw	4	
	Vacuum chamber cover	1	Do not catch the diaphragm when assembling.
	Diaphragm spring	1	
	Diaphragm / vacuum piston	1/1	Set the lip to the groove on the carburetor body when assembling. Rotate to the left to remove it.
	Jet needle holder	1	
(8) (9) (10) (11) (12) (13) (14) (15) (16) (17) (18)	<u>Float chamber</u>		
	Screw	3	
	Float chamber	1	
	O-Ring	1	
	Float pin	1	
	Float	1	
	Float valve	1	
	Main jet	1	
	Needle jet holder	1	
	Slow jet	1	
	Float valve seat	1	
	Washer	1	
(19) (20) (21) (22) (23)	<u>Air cut valve</u>		
	Screw	2	
	Diaphragm cover	1	Do not catch the diaphragm and the O-Ring when assembling.
	Spring	1	
	Diaphragm	1	
(24) (25) (26) (27)	<u>Pilot Screw</u>		
	Pilot screw	1	
	O-Ring	1	
	Washer	1	
	Spring	1	
(24) (25) (26) (27)	<u>Pilot Screw</u>		
	Pilot screw	1	
	O-Ring	1	
	Washer	1	
	Spring	1	

Carburettor Synchronisation



General
Caution

The synchronisation should be checked after warming up.
Set the gear in neutral and the bike level.

Disconnect the rear cylinder boost joint and the vacuum tube.

Apply negative pressure to the vacuum tube and seal its end.

Disconnect vacuum port plug from a front cylinder.

Install a vacuum gauge adapter to the vacuum port.

Connect the vacuum gauge hose to the adapter and the boost joint.

Start the engine and adjust idle rpm with a throttle stop screw.

Idling rpm: $1,200 \pm 100\text{rpm}$


Using the intake negative pressure on the rear cylinder as a standard reference. Adjust the pressure difference with the front cylinder intake negative pressure by rotating an adjust screw.

Pressure difference: Within 40mmHg

Snap the throttle grip several times and check the pressure difference and idling rpm. Adjust as required.




Pilot Screw Adjustment

Idle drop method




General
Caution

- The pilot screw is pre-adjusted when manufactured. It does not require any adjustments unless the pilot screw or the carburettor body is replaced. Wind back to the recorded position when disassembled.
- Secure the body when servicing.
- The idling rpm varies if the cooling fan starts. Use a fan to cool down if necessary.
- Synchronise the carburettor before adjusting the pilot screw.




- 1) Connect a tachometer which can read 50rpm difference.
- 2) Tighten the pilot screws on each carburettor until it touches the end. Then wind back to standard position.

Standard position. - 3 turns out



- Do not overtighten the pilot screws as it may result in damaging the seat surface.




- 3) After warming up the engine, adjust the idling rpm with a throttle stop screw.
Idling rpm: $1,200 \pm 100\text{rpm}$
 - 4) Wind (back or forward) the rear cylinder carburettor pilot screw in $\frac{1}{2}$ turn increments and find out the position where the idling rpm becomes maximum.
 - 5) Repeat 4) for the front cylinder carburettor.
 - 6) After snapping a few times, wind the throttle stop screw to re-set the idling rpm.
 - 7) Gently wind forward the pilot screw for the rear cylinder carburettor until the rpm becomes 50rpm below standard idling rpm (complete the idle drop).
 - 8) Open the pilot screw from 7) to the standard rewinding rev after the idle drop.
Standard rewinding rev after the idle drop: 1 rev
 - 9) Repeat 7) and 8) for the front cylinder carburettor.
 - 10) Adjust the idling rpm with the throttle stop screw.
- If the result is faulty, redo from 4).

General Caution.....	7 – 1	Engine Mounting / Dismounting.....	7 - 2
----------------------	-------	------------------------------------	-------

General Caution

- Support the bottom of the engine with floor jacks when servicing.
- Do not damage the frame, the engine body, the cables and the harness.
- The following parts should be serviced with the engine dismounted from the frame.
 - Crankcase (Sec. 11)
 - Crankshaft and Piston (Sec. 11)
 - Transmission (Sec. 11)
- The following parts can be serviced without dismounting the engine.
 - Oil Pump (Sec. 4)
 - Water Pump (Sec. 5)
 - Carburettor (Sec. 6)
 - Camshaft (Sec. 8)
 - Cylinder Head, Valve (Sec. 8)
 - Clutch (Sec. 9)
 - Gear Shift Linkage (Sec. 10)
 - Alternator (Sec. 15)
 - Pulse Generator (Sec. 16)
 - Starter Clutch (Sec. 17)
 - Starter Motor (Sec. 17)

◆ Engine Mounting/Dismounting





- Turn the main switch OFF and disconnect (-) lead from the battery before commencing work.
- Adjust the jacking height so as not to apply stress on the engine mount bolts.
- Inspect and adjust the following items after mounting the engine.
 - Clutch lever free play
 - Drive chain tension

Relevant Works


- Front exhaust pipe removal / installation (2-4)
- Carburettor removal / installation (6-3)
- Radiator removal / installation (5-6)
- Right and left pivot plate cover removal / installation (2-2)

Works / Parts		Qty.	Notes
	Dismounting		Reverse the procedure for mounting.
(1)	Gear shift arm bolt	1	Align the punched marks on the arm and the gear shift spindle when installing.
(2)	Gear shift arm	1	
(3)	Bolt	2	
(4)	Left main stop holder	1	Remove together with the gear shift pedal and the arm.
(5)	Socket bolt	3	Loosen the drive chain before removing by loosening the rear axle nut, the lock nut and the drive chain adjust nut.
(6)	Drive sprocket cover	1	
(7)	Drive sprocket bolt / washer	1/1	
(8)	Drive sprocket	1	Disconnect it and remove the lead from the clamp and the engine.
(9)	Spark plug cap	2	
(10)	Alternator lead coupler	1	
(11)	Side stand lead coupler	1	Loosen the hose band screw and disconnect from the front and the rear cylinder heads.
(12)	Ignition coil connector	2	
(13)	Thermo sensor connector	1	
(14)	Water hose	2	Remove together with the ignition coil, thermostat case and the water hose.
(15)	Socket bolt	2	
(16)	Carburettor side cover stay	1	
(17)	Crankcase breather hose	1	Disconnect it from the rear cylinder head.
(18)	Pulse generator coupler	1	Disconnect it and remove the lead from the clamp
(19)	Clutch cable	1	Loosen the lock nut and the adjust nut. Then disconnect from the lifter arm to remove from the cable holder.
(20)	Bolt / Earth lead	1/1	When installing, be aware of the difference in each collar length: Check position of each.
(21)	Nut / Starter motor lead	1/1	
(22)	Bolt / Horn / Radiator stay	1/1/1	
(23)	Engine mount nut	2	(Rear upper collar 32.5mm) (Left rear lower collar 41.6mm) (Front collar 19.5mm) (Right rear lower collar 38.1mm)
(24)	Engine mount bolt	3	
(25)	Engine mount collar	5	
(26)	Engine Assy.	1	

General Caution.....	8 – 1	Camshaft and cylinder head removal/installation.....	8 – 3
Troubleshooting.....	8 – 2	Cylinder head assembly/disassembly.....	8 – 9

General Caution

- Camshafts and cylinder heads can be serviced without dismounting the engine.
- Mark each removed part so that they can be re-installed to the original position.
- All disassembled parts should be cleaned and dried with compressed air before measuring them.
- The engine oil for the camshaft lubrication is supplied through the cylinder head oil path. When assembling the cylinder head, clean the oil path.
- When assembling, apply Molybdenum solution to the valve stem and locker arm contact areas, cam shaft cam surface and journals for initial lubrication.
- Align the T1 mark on the starter clutch and the alignment mark on the right crankcase cover. If the valve timing is correct, the marked lines on all cam sprockets should align with the cylinder head tops and all cam shaft ID marks (IN.F, EX.F, IN.R and EX.R) should face upwards or downwards. If all of the camshaft ID marks are facing downwards, the rear cylinder is in fully compressed position.



Troubleshooting

- Cylinder head related troubles can be identified by measuring the compression and the noise from the engine top.

Too low compression

- Valve
 - Valve clearance improperly adjusted.
 - Valve wear / burn.
 - Valve timing failure.
 - Valve spring damage.
 - Valve seat inadequate contact.
- Cylinder Head
 - Cylinder head gasket leak
 - Cylinder head distortion or crack
 - Spark plug loose attachment
- Cylinder / Piston failure (Sec. 11)

Too high compression

- Carbon on piston heads and combustion chamber

White smoke from a muffler

- Valve guide or valve stem wear
- Valve stem seal damage
- Piston, piston ring and cylinder failure (Sec. 10)


Engine Noise

- Valve clearance improper adjustment
- Valve burned
- Valve spring damage
- Camshaft damage and wear
- Cam chain tensioner, guide wear and damage
- Cam chain, sprocket wear and damage
- Piston, conrod or transmission failure (Sec. 11)

Idling Fault

- Too low compression

◆ Camshaft and Cylinder Head Removal / Installation





- This page describes about the rear side. Repeat the same procedure for the front one.
- Before removing the camshaft holder, remove the timing hole cap and align T mark on the starter clutch (T1 for rear, T2 for front) with the marks on right crankcase cover and check the cylinder is in fully compressed position. Then loosen the bolts equally (by dividing it to 2 ~ 3 sequences).

Relevant Works

- Exhaust pipe removal / installation (2-4)
- Carburettor removal / installation (6-3)
- Radiator removal / installation (5-6)
- Spark plug removal / installation
- Main switch bracket removal / installation (3-13)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
	<u>Camshaft</u>		
(1)	Cylinder head	4	Apply sealant to the half round part on the cylinder head when installing.
(2)	Cylinder head cover	1	
(3)	Cylinder head cover gasket	1	
(4)	6mm flange bolt	2	
(5)	8mm UBS bolt	2	Do not drop it into the crankcase.
(6)	Washer	2	
(7)	Cam chain guide	1	
(8)	8mm UBS bolt	2	
(9)	Camshaft holder C/D	1/1	Do not drop them into the crankcase.
(10)	Knock pin	3	
(11)	Knock pin C	1	
(12)	Cam sprocket bolt	4	
(13)	6mm flange bolt	2	Remove together with the oil path pipe.
(14)	6mm UBS bolt	2	
(15)	8mm UBS bolt	2	
(16)	8mm flange bolt	1	
(17)	Camshaft holder A/B	1/1	Remove from the camshaft holder.
(18)	Oil path pipe / O-Ring	1 / 2	
(19)	Knockpin	4	Insert a screwdriver as shown in the figure to push the tensioner and loosen the cam chain to remove/install. Installation (8-4).
(20)	Cam sprocket	2	
(21)	<u>Intake / exhaust camshaft</u>	1/1	Inspection (8-4) Do not drop them into the crankcase. <ul style="list-style-type: none"> • Sling the cam chain to prevent it falling into the crankcase when removing the slipper. • Installation (8-4)
	<u>Cylinder Head</u>	3	
(22)	6mm flange bolt	1	
(23)	Cam chain tensioner	2	
(24)	Lock pin	2	
(25)	Tensioner arm pin	1	
(26)	Cam chain tensioner slipper		
		4	
		2	
(27)	Socket bolt	2	
(28)	Cylinder head fin	2	
(29)	8mm UBS bolt	1	
(30)	Washer	1	
(31)	Cylinder head	2	
(32)	Cylinder head gasket		
(33)	Knock pin		

Cam Chain tensioner inspection

Turn the tensioner upside down to drain oil in the oil chamber.



Slowly move the tensioner arm to drain oil in the high pressure chamber.

Inspect the tension of the tensioner spring by moving the tensioner arm. If the tension is inadequate, replace the tensioner.

Fill the tensioner oil chamber with oil and slowly move the tensioner arm to fill the high pressure chamber with oil. Check the arm is locked when it is moved suddenly.

If the arm cannot be locked, replace the tensioner.

After the inspection, drain oil from the high pressure chamber.



**Cam Chain tensioner slipper installation**

Fit the cam chain through the tensioner slipper and install the slipper to the tensioner.

Align the tensioner arm pin and the slipper flat end to install the arm pin and fix with a lock pin.



The front cylinder tensioner has its arm on the intake side and the rear cylinder tensioner has its arm on the exhaust side.

**Camshaft installation**

Check the camshaft identification.

ID marks	Installing location
IN.F	Front cylinder intake
EX.F	Front cylinder exhaust
IN.R	Rear cylinder intake
EX.R	Rear cylinder exhaust

Both front and rear cylinder camshafts were removed.



When both camshafts were removed, install the rear cylinder side first and then the front cylinder side.

Rear Cylinder side

Rotate the crankshaft to the right and align the starter clutch T1 mark with the mark on the right crankcase cover.

Apply Molybdenum solution to the camshaft cam surface and the bearings. Install the cam sprockets to the camshaft, facing the marked lines outwards.

Apply cam chain and set the camshafts.

Check the cam tops are facing upwards.

Set the cam chain to the cam sprocket so as to align the marked lines on the cam sprockets to the camshaft flange.

Align the bolt holes on the cam sprocket and the camshafts and install two cam sprocket bolts.

Apply clean engine oil to a new O-Ring and install it to the oil path pipe. Install the oil path pipe to the camshaft holders A and B. Install four knock pins on the camshaft holders A and B to the cylinder head.

Install the camshaft holders A and B and the oil path pipe to the cylinder head and temporarily tighten the bolts.

Rotate the crankshaft to the right for one rev and align the T1 mark on a starter clutch with the mark on the right crankcase cover to have the cylinder in fully compressed position.

Set four knock pins on camshaft holders C and D to the cylinder head.

Install the camshaft holders C and D to the cylinder head.

Remove the two 8mm temporarily installed bolts and install the cam chain guide.







Check the identification marks on the cam chain guides.

F: Front R: Rear


Tighten the camshaft holder bolts in 2 ~ 3 sequences for each opposite corner.

Torque:	8mm UBS bolt (Black):	3.4kg-m
	8mm UBS bolt:	2.3kg-m
	6mm bolt	1.2kg-m



Front Cylinder side

Check the T1 mark is aligned with the mark on the crankcase cover, which indicates that the rear cylinder is in fully compressed position. Install the front cylinder camshaft and the cam sprocket in the same manner as the rear side (do not install cam sprocket bolts yet). Rotate the crankshaft to the right for one revolution to align the T1 mark again. Set the cam tops of the front camshaft to the direction shown as follows:



Align the cam sprocket and the camshaft bolt holes to install two cam sprocket bolts. In the same manner with the rear cylinder, install the camshaft holder A and B. Then, rotate the crankshaft for one revolution to install remaining two cam sprocket bolts. Rotate the crankshaft to the right for approx 1





– ¼ rev (450°) to align the starter clutch T2 mark with the mark on the right crankcase cover to bring the front cylinder fully compressed.

In the same manner with the rear cylinder side, install the camshaft holders C and D, cam chain guide and tighten the bolts.

Only the rear cylinder camshaft was removed:

Remove the front cylinder head cover. Rotate the crankshaft to the right and align the starter clutch T2 mark with the mark on the right crankcase cover. Check the front cylinder is in fully compressed position (3-13). Rotate the crankshaft to the right for ¾ revolution (270°) to align T1 mark with the mark.


In the same manner with both cylinder camshaft removed case, install the rear cylinder camshaft, the cam sprocket and the camshaft holder.




Only the front cylinder camshaft was removed:

Remove a rear cylinder head cover.
Rotate the crankshaft to the right and align the starter clutch T1 mark with the mark on the right crankcase cover.
Check the rear cylinder is in fully compressed position (cam top facing upwards).

In the same manner with both cylinder camshaft removed case, install the front cylinder camshaft, cam sprocket and the camshaft holder.



♦ Cylinder Head Assembly/Disassembly



CAUTION

- Sort and store each part so it can be re-installed to its original place.
- Do not over compress the valve springs. It may deform the spring.

Relevant Works

- Cylinder head removal / installation

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for its assembly.
(1)	Locker arm shaft	2	Do not remove unless needed.
(2)	Wave washer	2	
(3)	O-Ring	2	
(4)	Locker arm	2	
(5)	Lock nut	4	
(6)	Valve adjust screw	4	The fine pitch end is to be installed to the cylinder head.
(7)	Valve cotter	8	
(8)	Valve retainer	4	
(9)	Valve spring	4	
(10)	Intake valve	2	
(11)	Exhaust valve	2	<p>CAUTION</p> <p>Slowly rotate it to install in order to prevent damaging the stem seal.</p> <p>Installation height: 11.4 ~ 11.6mm</p> <p>Set the CARB SIDE to the carburettor side, UP mark facing upwards when installing.</p>
(12)	Spring seat	4	
(13)	Stem seal	4	
(14)	Valve guide	4	
(15)	Carburettor insulator	4	

General Caution.....	9 – 1	Right crankcase cover removal/installation.....	9 – 2
Troubleshooting.....	9 – 1	Clutch removal / installation.....	9 – 4

General Caution

- The clutch can be serviced with the engine mounted.
- Engine oil viscosity and oil level affects the clutch operation. If the clutch is hard to release or if the vehicle is still moving forward with the clutch released, check the oil first.
- Remove any gasket stuck on the case mating surface.
- Do not damage the case mating surface when disassembling.
- Keep away from debris and dirt to prevent them going into the engine.

Troubleshooting

The majority of the clutch operation failure is improper clutch lever free play.
Before disassembling, check and adjust the free play.

Clutch lever is heavy

- Clutch cable damaged / rust
- Clutch lifter system damaged
- Clutch lifter bearing failure
- Clutch cable not running through correct places.

Unable to release the clutch or it keeps running

- Clutch free play too large
- Clutch plate distortion, bent
- Clutch centre lock nut is loosened
- Excess amount of engine oil or too high viscosity
- Clutch lifter system damaged
- Clutch cable incorrectly routed


Clutch slips when accelerating

- Clutch lifter mechanism jammed
- Clutch free play too little
- Clutch disc wear
- Clutch spring stretched

Clutch operation is unstable

- Clutch outer groove wear

◆ Right Crankcase Cover Removal/Installation






Inspect / adjust the clutch lever free play and the rear brake pedal free play after the installation.

Relevant Works

- Engine oil drain / refill

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	Rear brake pedal pivot bolt/nut	1/1	Remove the pedal from the bracket. Refer to the wiring diagram (1-18) to correctly clamp the leads when installed. Disconnect the cable from the clutch arm and remove together with the cable.
(2)	Bolt	2	
(3)	Right main step holder	1	
(4)	Step holder bracket	1	
(5)	Right crankcase cover bolt	12	
(6)	Clamp	4	
(7)	Clutch cable holder	1	
(8)	Right crankcase cover	1	
(9)	Gasket	1	
(10)	Knock pin	2	
<u>Clutch lifter disassembly</u>			
(11)	Lifter piece	1	Remove by rotating the clutch arm to the left. When installing, insert the spring end to the groove on the lower part of the lifter rod.
(12)	Snap ring	1	
(13)	Clutch arm / lifter rod	1	
(14)	Spring	1	
(15)	Oil seal	1	

◆ Clutch Removal/Installation





- When removing the oil pump driven sprocket bolt, loosen it before removing the clutch.
- There is no need to remove the starter clutch unless the clutch outer is to be removed.

Relevant Works

- Right crankcase cover removal/installation (9-2)
- Starter clutch removal/installation (17-6)


Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Clutch spring bolt	4	
(2)	Clutch lifter plate/bearing	1/1	
(3)	Clutch spring	4	
(4)	Clutch centre lock nut	1	Removal / installation (9-6)
(5)	Lock washer	1	Face the "OUTSIDE" mark outwards
(6)	Washer	1	
(7)	Clutch centre	1	Remove with ASSY from the clutch pressure plate, the clutch disc and the clutch plate.
(8)	Thrust washer	1	Install to the clutch centre guide correctly.
(9)	Clutch pressure plate	1	
(10)	Clutch disc A	6	
(11)	Clutch plate	6	
(12)	Clutch disc B	1	Internal diameter is bigger than the clutch disc A
(13)	Judder spring	1	Note the installing direction.
(14)	Spring seat	1	
(15)	Clutch outer	1	Set the oil pump drive sprocket projection to the clutch outer dent when installing.
(16)	Oil pump driven sprocket bolt	1	
(17)	Oil pump driven sprocket	1	Face the marked lines inwards.
(18)	Oil pump drive chain	1	
(19)	Oil pump drive sprocket	1	
(20)	Clutch outer guide	1	

Clutch centre lock nut removal / installation

When disconnecting the staked part or staking the lock nut, do not damage the main shaft.

Removal

Disconnect the staked parts on the lock nut.
Set the clutch centre holder with the clutch spring bolts.
Fix the clutch centre and remove the lock nut.



Excl. tool

Clutch centre holder 07GMB-KT70101

Installation

Apply engine oil to the new lock nut thread and the seat before installing it.
Fix the clutch centre with the clutch centre holder and tighten the lock nut.

Excl. tool

Clutch centre holder 07GMB-KT70101

Torque: 8.5kg-m

Stake the lock nut to the groove on a main shaft.

General Caution.....	10 – 1	Gear shift linkage removal/installation.....	10 – 2
Troubleshooting.....	10 – 1		

General Caution

Separate the crankcase to service the shift fork, the shift drum and the transmission (Sec. 11).


Troubleshooting**Difficult to set the gear**

- Gear shift spindle bent
- Stopper arm attachment failure
- Shift fork bent
- Shift fork shaft bent
- Shift drum guide groove damage
- Shift fork guide pin damaged

The gear disengages

- Stopper arm damage
- Stopper arm spring stretched
- Shift drum centre damaged
- Gear dog part wear
- Gear shift fork groove wear
- Shift fork wear / damage
- Shift fork guide pin wear
- Shift drum guide groove wear

◆ Gear shift linkage and shift drum removal/installation



Relevant Works

- Water pump removal / installation (5-5)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for its installation.
(1)	Bolt / Washer	3/1	
(2)	Shift linkage power	1	
(3)	Gasket	1	
(4)	Knockpin	2	
(5)	Gear shift spindle ASSY	1	
(6)	- snap ring	1	Do not remove unless required to do so.
(7)	- return spring	1	
(8)	Thrust washer	1	
(9)	Shifter collar	1	
(10)	Guide plate bolt	2	
(11)	Guide plate	1	Install together with the drum shifter.
(12)	Drum shifter	1	Install the spring, plunger and the ratchet pawl to the drum shifter and set the drum shifter to the guide plate.
(13)	Ratchet pawl	2	
(14)	Plunger	2	
(15)	Spring	2	
(16)	Shift drum centre bolt	1	When installing, temporarily set the guide plate and the bolt to tighten it.
(17)	Shift drum centre	1	When installing, push the stopper arm down with a screwdriver and align the drum centre hole with a shift drum pin.
(18)	Thrust washer	1	
(19)	Stopper arm ASSY	1	Remove together with the stopper arm spring.
(20)	- snap ring	1	
(21)	- washer	1	Do not remove unless required to do so.
(22)	- stopper arm	1	
(23)	Stopper arm spring	1	Remove from the stopper arm.
(24)	Guide plate spacer	1	
(25)	Shift drum bearing set plate	1	
(26)	Guide plate knockpin	2	
(27)	Shift drum pin	1	

General Caution.....	11 – 1	Countershaft assembly /disassembly.....	11 – 8
Troubleshooting.....	11 – 1	Crankshaft, piston and conrod removal/installation.....	11 – 10
Crankcase separation/assembly.....	11 – 2	Piston and conrod assembly/disassembly.....	11 - 12
Main shaft assembly/disassembly....	11 – 6	Bearing selection.....	11 - 14

General Caution

- The crankcase must be separated when servicing the crankshaft, piston, conrod and transmission.
- All detached parts should be sorted/stored for each cylinder. Mixing these parts between the cylinders may cause crankshaft and/or head damage as the oil clearance will vary.
- Do not damage the cylinders internal surface and the pistons external surface when cleaning, etc..
- Do not damage the crankcase mating surface.
- Do not damage the main bearing when removing/installing the crankshaft.
- Select the crankshaft bearing by using the colour code table. After replacing the bearing, check the oil clearance by using a plasticine gauge (refer to Sec. 9 in the main volume).
- Apply Molybdenum solution to the main bearing and the conrod bearing upon assembling.
- Apply sealant to the crankcase mating surface upon assembling. Wipe off all excess sealant.

Troubleshooting

Too low compression

- Piston ring wear, burn or damage
- Piston or cylinder wear
- Cylinder head, valve failure (Sec.8)

Too high compression

- Carbon on piston head and combustion chamber

White smoke from muffler

- Cylinder, piston or piston ring wear
- Piston ring installation fault
- Piston exterior surface, cylinder internal surface damage
- Cylinder head, valve failure (Sec. 8)

Engine Noise

- Piston pin, pin hole wear
- Conrod bearing wear
- Conrod bent
- Crankshaft main bearing wear
- Transmission gear wear
- Transmission bearing wear
- Cylinder head, valve failure (Sec. 8)


Difficult to select the gear

- Gear shift spindle bent
- Stopper arm installation fault
- Shift fork bent
- Shift fork shaft bent
- Shift drum guide groove damage
- Shift fork guide pin damage

Gear disconnects

- Stopper arm damage
- Stopper arm spring stretched
- Shift drum centre damage
- Gear dock wear
- Gear shift fork groove wear
- Shift fork wear/damage
- Shift fork guide pin wear
- Shift drum guide groove wear

◆ Crankcase Separation / Assembly






- Separate the crankcase and remove all sealant from the mating surface.
- When assembling the case, clean the mating surface and apply sealant to the hatched area

Relevant Works

- Engine mounting / dismounting (7-2)
- Clutch removal / installation (9-4)
- Gear shift linkage removal / installation (10-2)
- Starter motor removal / installation (17-4)
- Camshaft, cylinder head removal/installation (8-3)
- Pulse generator removal/installation (16-8)
- Alternator removal/installation (15-8)
- Oil pump removal/installation (4-4)

Works / Parts		Qty.	Notes
	Separation		Reverse the procedure for assembly.
(1)	6mm upper crankcase bolt	5	One bolt at the front is a special bolt with a washer.
(2)	8mm upper crankcase bolt	2	
(3)	6mm lower crankcase bolt	5	One bolt is already removed with the earth cable when dismantling the engine.
(4)	8mm lower crankcase bolt	5	
(5)	Lower crankcase	1	Apply Molybdenum solution to the gear shift fork grooves and set the shift forks to the grooves.
(6)	Knock pin	3	

◆ Transmission Removal / Installation




Relevant Works

- Crankcase separation / assembly (11-2)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Bolt	1	Place the cutout end to the right side. Set the identification mark to the right and set the guide pin to the guide pin groove on the shift drum.
(2)	Set plate	1	
(3)	Shift fork shaft	1	
(4)	Shift fork	3	
(5)	Shift drum/bearing	1/1	<ul style="list-style-type: none"> • Set the bearing groove to the set ring and the hole to the knockpin when installing. • Assembly / Disassembly (11-6,8)
(6)	Main shaft / Counter shaft	1/1	
(7)	Set ring	2	
(8)	Knockpin	2	
(9)	Counter shaft oil seal	1	

◆ Mainshaft Assembly / Disassembly






- Apply Molybdenum solution to the gear shift fork groove, gear matching area, bearing and the gear bush when assembling.
- Face the rounded surface of the washer/snap ring to the loading side.
- Do not re-use deformed snap rings.
- Set the open area of the snap rings to the grooves on the splines.

Relevant Works

- Transmission removal/installation (11-4)

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Needle bearing	1	Set the catch to the spline washer groove.
(2)	Thrust washer	1	
(3)	M2 gear (20T)	1	
(4)	Lock washer	1	
(5)	Spline washer	1	Align the bush and the shaft oil holes.
(6)	M5 gear (29T)	1	
(7)	M5 gear spline bush	1	
(8)	Spline washer	1	
(9)	Snap ring	1	
(10)	M3 gear (24T)	1	
(11)	Snap ring	1	
(12)	Spline washer	1	
(13)	M4 gear (27T)	1	
(14)	M4 gear bush	1	
(15)	Ballbearing (63/22)	1	
(16)	Main shaft (15T)	1	

♦ Countershaft Assembly/Disassembly



 : Gear shift fork groove, matching area, bearings and gear bush.




- Apply Molybdenum solution to the gear shift fork grooves, the matching area, the bearings and the gear bushes.
- The rounded side of the washers and the springs should face loading side.
- Do not re-use the deformed snap ring.
- The open area of the snap ring should be aligned with the groove on the spline.

Relevant Works

- Transmission removal/installation (11-4)

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Needle bearing	1	Align the bush and the shaft oil holes when assembling. Set the catch to the spline washer groove.
(2)	Thrust washer	1	
(3)	C1 gear (41T)	1	
(4)	C1 gear bush	1	
(5)	Thrust washer	1	
(6)	C4 gear (30T)	1	
(7)	Snap ring	1	
(8)	Spline washer	1	
(9)	C3 gear (33T)	1	
(10)	C3 gear spline bush	1	
(11)	Lock washer	1	
(12)	Spline washer	1	
(13)	C5 gear (28T)	1	
(14)	Snap ring	1	
(15)	Spline washer	1	
(16)	C2 gear (36T)	1	
(17)	C2 gear bush	1	
(18)	Thrust washer	1	
(19)	Counter shaft	1	

◆ Crankshaft, piston and conrod removal / installation






- Do not damage the main bearing when removing / installing the crankshaft.
- Sort and store all removed parts. Do not mix up parts (F&R) as clearance may vary.

Relevant Works

- Crankcase separation / assembly (11-2)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Bolt	2	<ul style="list-style-type: none"> • When installing, properly distribute the cam chain to both front and rear cylinder. • After installing, set the conrod to the crankpin. Do not damage the pin.
(2)	Cam chain guide B	1	
(3)	Conrod cap nut	4	
(4)	Conrod cap	2	
(5)	Crankshaft	1	
(6)	Cam chain	2	Selection (11-14) <ul style="list-style-type: none"> • Remove towards cylinder head side. • Assembly / disassembly (11-12). • Set the IN mark on the top of the piston to the carburetor side. By using a conventional piston ring compressor, install from the cylinder head side.
(7)	Bolt	2	
(8)	Cam chain guide A	1	
(9)	Main bearing	4	
(10)	Piston / Conrod Assy	2	

◆ Piston and Conrod Assembly / Disassembly





The direction of the conrod may be identified by the marks (F: Front, R: Rear)

Relevant Works

- Crankshaft, piston and conrod removal/installation (11-10)

Works / Parts		Qty.	Notes
	Disassembly		Reverse the procedure for the assembly.
(1)	Conrod bearing	2	<ul style="list-style-type: none"> • Selection (11-14) • Align its oil hole with the one on the conrod when assembling.
(2)	Conrod bolt	2	Do not remove unless required.
(3)	Piston pin clip	2	
(4)	Piston pin	1	
(5)	Piston	1	
(6)	Top ring	1	Set the IN mark on the front to the oil jet hole side. Set the IN mark on the rear to the opposite side of the oil jet hole.
(7)	Second ring	1	
(8)	Side rail	2	
(9)	Spacer	1	


Bearing Selection

Main Bearing

Record the main journal internal code on the crankcase.




- The code is marked on the left side of the upper crankcase as A or B.
- The left hand side indicates the rear cylinder and the right hand side indicates the front cylinder journal internal diameter code.



Record the crankshaft main journal external diameter code.



- The code is marked on the crankweight as 1 or 2.




From the two codes, select the replacement bearings (the bearings are colour coded).

Crankcase internal diameter code		A	B
Crankshaft external diameter code		35.000-35.008mm	35.008-35.016mm
1	32.002-32.010mm	C (Y)	B(G)
2	31.994-32.002mm	B(G)	A(B)

Main bearing thickness:

A (B): 1.498 – 1.502mm B: Brown
 B (G): 1.494 – 1.498mm G: Green
 C (Y): 1.490 – 1.494mm Y: Yellow




Conrod Bearing

Record the conrod internal diameter code.




- The code is marked on the conrod as 1 or 2.



Record the crankpin external diameter on the crankshaft.




- The code is marked on the crankweight as A or B.



Select the replacement conrod bearings from the two codes.
(The bearings are colour coded).



The front cylinder conrod bearings have one colour code while the ones for the rear cylinder have two colour code markings.



Conrod internal diameter code		1		2	
Crankpin external diameter code		36.000-36.008mm		36.008-36.016mm	
		Front	Rear	Front	Rear
A	32.992-33.000mm	C (Y)	C (Y,Y)	B(G)	B (G,G)
B	32.984-32.992mm	B(G)	B (G,G)	A(B)	A(B,B)

Conrod bearing thickness:

++

A (B) (B,B): 1.494 – 1.498mm B: Brown
 B (G) (G,G): 1.490 – 1.494mm G: Green
 C (Y) (Y,Y): 1.486 – 1.490mm Y: Yellow

VT250C-12. Front Wheel, Suspension and Steering

General Caution.....	12 – 1	Front wheel assembly/disassembly.....	12 - 5
Troubleshooting.....	12 – 1	Fork removal/installation.....	12 – 6
Steering handle removal/installation...	12 - 2	Fork assembly/disassembly.....	12 – 8
Front wheel removal / installation.....	12 – 4	Steering stem removal/installation.....	12 - 10

General Caution



Keep the brake disc and the pads away from oil/grease. If the oil/grease contact them, replace the pads and clean the brake disc.

- Firmly support the frame to lift the wheel when removing the wheel.
- Refer to Sec. 14 for the brake system service.
- Refer to Sec. 18 for the lamps, instruments and switches service.

Troubleshooting

Steering too heavy

- Steering bearing adjust nut over tightened
- Steering bearing damage/wear
- Inner/outer lace damage/wear/stop
- Steering stem deformation
- Tyre pressure too low
- Tyre wear

Front wheel heavy to rotate

- Wheel bearing failure
- Front axle bent
- Brake not released

Unstable steering


- Steering bearing damage/loose tightenings
- Unequal left/right cushions
- Front axle deformation, tyre tilted
- Frame deformed
- Tyre wear / unequal wear
- Wheel bearing loose fit
- Swing arm pivot loose fit

Front wheel deflection

- Rim deformed
- Wheel bearing failure
- Tyre fault
- Wheel unbalanced
- Axle related tightenings inadequate

VT250C-12. Front Wheel, Suspension and Steering

◆ Steering Handle Removal / Installation




VT250C-12. Front Wheel, Suspension and Steering

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Clutch switch connector	2	
(2)	Socket bolt	2	
(3)	Clutch lever bracket holder	1	
(4)	Clutch lever bracket	1	
(5)	Screw	2	
(6)	Left handle switch	1	
(7)	Left handle grip	1	
(8)	Spacer	1	
(9)	Front brake switch connector	2	
(10)	Socket bolt	2	
(11)	Master cylinder holder	1	
(12)	Master cylinder	1	
(13)	Screw	2	
(14)	Right steering handle switch	1	
(15)	Steering handle mount nut	2	
(16)	Washer	2	
(17)	Steering handle	1	Remove from the fork top bridge.
(18)	Throttle grip	1	Pull out from the steering handle.
(19)	Throttle cable	2	Disconnect from the throttle grip flange.

VT250C-12. Front Wheel, Suspension and Steering

♦ Front Wheel Removal/Installation



Keep the disc and pads away from oil/grease. If the oil/grease contacts the parts, replace the pads and clean the brake disc.


Relevant Works

- Support the frame and lift the front wheel.

Works / Parts		Qty.	Notes
Removal			
(1)	Speedometer cable set screw	1	When installing, align the speedo drive projection with the fork stopper. Loosen
(2)	Speedometer cable	1	
(3)	Right axle split bolt	2	
(4)	Axle bolt	1	
(5)	Left axle split bolt	2	
(6)	Axle	1	<ul style="list-style-type: none"> Loosen Set the axle groove to the fork side when tightening. <div>CAUTION</div> Do not operate the brake lever after removing the ASSY. Assembly / disassembly (12-5)
(7)	Front wheel ASSY.	1	
(8)	Side collar	1	
(9)	Speedo meter gear box (Speedo drive)	1	

VT250C-12. Front Wheel, Suspension and Steering

◆ Front Wheel Assembly / Disassembly



Replace both right and left wheel bearings together.


Relevant Works

- Front wheel removal / installation (12-4).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Left dust seal	1	Align the wheel rotating direction and the tyre rotating direction marks when assembling.
(2)	Speedometer gear retainer	1	
(3)	Brake disc bolt	6	
(4)	Brake disc	1	
(5)	Right dust seal	1	
(6)	Right wheel bearing (6004 UU)	1	
(7)	Distance collar	1	
(8)	Left wheel bearing (6004 UU)	1	
(9)	Front tyre	1	

VT250C-12. Front Wheel, Suspension and Steering

◆ Fork Removal / Installation



VT250C-12. Front Wheel, Suspension and Steering



- When disassembling the fork, loosen the fork cap after loosening the top bridge split bolt.
- Refer to the wiring diagram (1-18) for hose, cable and harness installation.


Relevant Works

- Front wheel removal / installation (12-4).

Works / Parts		Qty.	Notes
(1) (2) (3) (4) (5) (6) (7) (8) (9) (10) (11)	Removal		Reverse the procedure for the installation.
	Front fender bolt	4	
	Fender collar / brake hose clamp	2/1	
	Front fender	1	
	Front fender plate	1	
	Caliper mount bolt	2	<div>σ Caution</div>
	Front caliper	1	Do not sling the caliper with the brake hose.
			<div>σ Caution</div>
			Do not operate the brake lever after removing the caliper.
	Direction indicator holder bolt/collar	1/1	
	Front direction indicator	1	
	Fork top bridge split bolt	1	Loosen
	Fork bottom bridge split bolt	1	Loosen
	Fork ASSY	1	<ul style="list-style-type: none">• Assembly/disassembly (12-8)• Align the fork tube top and the top bridge top when installing.

VT250C-12. Front Wheel, Suspension and Steering



◆ Fork Assembly / Disassembly



VT250C-12. Front Wheel, Suspension and Steering


Relevant Works

- Fork removal / installation .

Works / Parts		Qty.	Notes
Disassembly			
(1)	Fork cap	1	
(2)	O-Ring	1	
(3)	Spacer	1	
(4)	Spring seat	1	
(5)	Fork spring	1	
(6)	Dust seal	1	
(7)	Stopper ring	1	
(8)	Fork socket bolt	1	Do not damage the fork tube contact area. If the seat pipe rotates together, loosen the bolt by temporarily setting the fork spring, spacer and the fork cap.
(9)	Sealing washer	1	
(10)	Seat pipe	1	
(11)	Rebound spring	1	
(12)	Piston ring	1	Do not remove from the seat pipe unless replacing it. Remove from the fork slider by pulling hard several times.
(13)	Fork tube	1	
(14)	Oil seal	1	Remove from the fork tube.
(15)	Back up ring	1	
(16)	Guide bush	1	
(17)	Fork tube bush	1	Do not remove from the seat pipe unless replacing it.
(18)	Oil lock piece	1	
Assembly			
(17)	Fork tube bush	1	Install to the fork tube.
(12)	Piston ring	1	Install to the seat pipe.
(11)	Rebound spring	1	Set inside the fork tube.
(10)	Seat pipe	1	
(18)	Oil lock piece	1	Install to the seat pipe.
(13)	Fork tube	1	Install to the fork slider.
(9)	Sealing washer	1	If the seat pipe rotates with the bolt, temporarily set the fork spring, spacer and the fork cap to tighten the bolt.
(8)	Fork socket bolt	1	
(16)	Guide bush	1	Install to the fork tube and set to the fork slider by using an exclusive tool.
(15)	Back up ring	1	
(14)	Oil seal	1	
(7)	Stopper ring	1	
(6)	Dust seal	1	Do not damage the fork tube contact area.
(5)	Fork spring	1	Set the fine pitch end downwards.
(4)	Spring seat	1	
(3)	Spacer	1	
(2)	O-Ring	1	
(1)	Fork cap	1	

VT250C-12. Front Wheel, Suspension and Steering

◆ Steering Stem Removal/Installation




VT250C-12. Front Wheel, Suspension and Steering



- Replace the steering bearing and the race together.
- Remove the steering stem nut while the fork is set to the stem.

Relevant Works

- Fork removal / installation (12-6).
- Headlamp case removal / installation (18-6).

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Nut	2	 Support the stem to prevent it falling off.
(2)	Brake hose clamp	1	
(3)	Headlamp case bracket	1	
(4)	Steering stem nut/washer	1/1	
(5)	Fork top bridge	1	
(6)	Lock nut	1	
(7)	Lock washer	1	
(8)	Steering bearing adjust nut	1	
(9)	Upper dust seal	1	
(10)	Upper inner race	1	
(11)	Upper bearing	1	
(12)	Steering stem	1	
(13)	Lower bearing	1	
(14)	Upper outer race	1	
(15)	Lower outer race	1	
(16)	Lower inner race	1	
(17)	Lower dust seal	1	

General Caution.....	13 – 1	Rear cushion removal/installation.....	13 - 5
Troubleshooting.....	13 – 1	Swing arm removal/installation.....	13 – 6
Rear wheel removal/installation.....	13 - 2	Swing arm assembly/disassembly.....	13 – 7
Rear wheel assembly/disassembly.....	13 – 4		

General Caution

Keep the brake drum and the lining away from oil/grease. If the oil/grease contact them, replace the brake drum and replace the brake shoe.

- Firmly support the frame when removing/installing the rear wheel, the rear cushion and the swing arm.
- Use the genuine rear cushion mount bolts/nuts.
- Refer to Sec. 14 for the rear brake service.

Troubleshooting**Rear wheel deflection**

- Wheel / rim deformation
- Wheel bearing damage
- Tyre fault
- Axle related tightenings fault
- Low tyre air pressure
- Swing arm pivot bearing failure
- Wheel unbalanced

Rear wheel heavy to rotate

- Wheel bearing failure
- Rear axle deformation
- Brake not released (Sec. 14)

Rear cushion too soft

- Rear cushion spring deformed
- Rear cushion spring adjuster adjustment fault
- Rear damper failure, oil leak
- Low tyre pressure


Rear cushion too hard

- Cushion installation fault
- Damper rod deformed
- Swing arm pivot bearing failure
- Swing arm pivot bolt bent
- Rear cushion spring adjuster adjustment fault
- Too high tyre pressure

Rear cushion noise

- Cushion case touching
- Loose tightenings

◆ Rear Wheel Removal / Installation





Keep the brake drum and the lining away from oil/grease. If the oil/grease contact them, replace the brake drum and replace the brake shoe.




After the installation, adjust the drive chain tension and adjust the rear brake pedal free play.

Relevant Work

- Firmly support the frame to lift the rear wheel.

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Rear brake adjust nut	1	
(2)	Rear brake rod	1	
(3)	Brake rod spring	1	
(4)	Brake arm joint	1	
(5)	Cotter pin	1	
(6)	Nut	1	
(7)	Washer	1	
(8)	Cushion rubber	1	
(9)	Stopper arm bolt	1	
(10)	Stopper arm	1	
(11)	Drive chain adjuster lock nut	2	Loosen completely
(12)	Drive chain adjust nut	2	
(13)	Rear axle nut	1	Tighten it after adjusting the drive chain tension when installing.
(14)	Washer	1	
(15)	Rear axle	1	
(16)	Drive chain	1	Move the rear wheel forward to remove it from the driven sprocket.
(17)	Rear wheel	1	Assembly / disassembly (13-4)
(18)	Rear brake panel side collar	1	Length: 35mm
(19)	Rear wheel side collar	1	Length: 29mm
(20)	Rear brake panel		Assembly / disassembly (14-8)
(21)	Drive chain adjuster	2	Set the adjust scale outwards and the UP mark upwards when installing.

◆ Rear Wheel Assembly / Disassembly




Replace both left and right wheel bearings together.

Relevant Work

- Rear wheel removal/installation (13-2).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Left dust seal	1	Do not remove from the driven flange unless required to do so. If they are to be removed, loosen the nuts before removing the driven flange from the wheel.
(2)	Final driven flange ASSY.	1	
(3)	- driven sprocket nut	5	
(4)	- final driven sprocket	1	
(5)	- distance collar B	1	Align the wheel rotating direction mark with the tyre rotating direction mark when installing.
(6)	- driven flange bearing (6204UU)	1	
(7)	O-Ring	1	
(8)	Damper rubber	5	
(9)	Left wheel bearing (6303UU)	1	
(10)	Distance collar	1	
(11)	Right wheel bearing (6303UU)	1	
(12)	Rear tyre	1	

◆ Rear Cushion Removal / Installation




Do not disassemble the rear cushion.

Relevant Work

- Seat removal/installation (2-2)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Lower mount bolt	1	
(2)	Upper mount bolt	1	
(3)	Washer	1	
(4)	Rear cushion	1	

◆ Swing Arm Removal / Installation




Relevant Work

- Rear wheel removal/installation (13-2)
- Rear cushion removal/installation (13-5)

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	Bolt	2	Set the cover groove to the catch on a swing arm
(2)	Drive chain cover	1	
(3)	Socket bolt	6	
(4)	Pivot plate cover	2	
(5)	Rear brake pedal return spring	1	Disconnect from the swing arm hook.
(6)	Rear brake middle arm split bolt	1	
(7)	Middle arm pivot shaft	1	Assembly / disassembly (13-7)
(8)	Swing arm pivot nut	1	
(9)	Swing arm pivot bolt	1	
(10)	Swing arm ASSY	1	

♦ Swing Arm Assembly / Disassembly



Relevant Work

- Swing arm removal / installation (13-6)


Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Cotter pin	1	Replace (13-8)
(2)	Nut	1	
(3)	Washer	1	
(4)	Spring washer	1	
(5)	Stopper arm bolt	1	
(6)	Rear brake stopper arm	1	
(7)	Tapping screw	2	
(8)	Chain slider washer	2	
(9)	Chain slider	1	
(10)	Right pivot collar	2	
(11)	Left pivot collar	1	
(12)	Dust seal	4	
(13)	Snap ring	1	
(14)	Right pivot ball bearing	1	
(15)	Left pivot needle bearing	1	

Swing arm pivot bearing replacement

By using a hydraulic press machine, remove the ball bearing from the swing arm right pivot.

Excl. tool


Driver shaft 07946-MJ00100



By using the press machine, remove the needle bearing from the swing arm left pivot.

Excl. tools



Bearing remover attachment 07GMD-KT70200
Driver shaft 07946-MJ00100



Apply grease to the new needle bearing.
Push the stamped side and insert it to the step surface in the left pivot.

Excl. tools

Driver handle A 07749-0010000
Outer driver 28 x 30mm 07946-1870100
Pilot 22mm 07746-0041000



Apply grease to the new ball bearing.
Push the stamped side and insert it to the right pivot.

Excl. tools

Driver handle A 07749-0010000
Outer driver 32 x 35mm 07746-0010100
Pilot 15mm 07746-0040300

General Caution.....	14 – 1	Front caliper assembly/disassembly.....	14 – 6
Troubleshooting.....	14 - 2	Rear brake panel assembly/disassembly...	14 – 8
Front brake pad replacement.....	14 – 3	Rear brake panel assembly/disassembly...	14 – 9
Front master cylinder assembly/disassembly.....	14 – 4		

General Caution



- Keep the disc and the pads from oil/grease. If the oil/grease contact them, replace the pads and clean the brake disc.
- Keep the brake drum and the lining from oil/grease. If oil/grease contact them, clean the drum and replace the brake shoe.

- Keep out of debris/water when refilling the brake fluid.
- Do not mix different brands of brake fluids.
- Do not re-use the drained brake fluid.
- Keep the painted, plastic and rubber surfaces away from the brake fluid.
- Do not re-use the sealing washers.
- Clean all removed parts with brake fluid and check the path of each with compressed air.
- If air entered the hydraulic system, bleed air from the system.

Troubleshooting**Hydraulic disc brake****Poor braking performance**

- Air in the braking system
- Brake fluid degraded by moisture
- Brake pad / disc dirty
- Master cylinder piston cup wear
- Brake pad wear
- Caliper (inside) dirty
- Caliper slide not smooth/dragging
- Brake pad / disc unequal wear
- Inadequate brake fluid
- Brake fluid path jammed
- Disc distortion / deformation
- Caliper piston stuck / wear
- Disc wear
- Master cylinder (inside) dirty
- Lever deformed

Brake lever is heavy / does not return

- Brake system jammed
- Caliper piston stuck / wear
- Caliper slide not smooth
- Brake fluid path jammed
- Caliper piston seal wear
- Master cylinder piston stuck / wear
- Lever deformed

Brake does not release (drag)

- Brake pad / disc dirty
- Wheel misaligned
- Brake pad / disc unequal / stop wear
- Disc distortion / deformation
- Caliper slide not smooth/dragging
- Debris in hydraulic system
- Lever deformed

Drum Brake**Poor braking performance**

- Brake linkage fault
- Brake lining wear
- Brake drum wear
- Brake cam wear
- Brake shoe attachment failure
- Brake lining unequal / step wear
- Brake lining dirt
- Brake drum dirt
- Brake shoe cam wear
- Brake arm sealation joint failure


Brake pedal does not / difficult to return

- Return spring deformed / damaged
- Brake linkage fault
- Brake drum dirt (adhesion)
- Brake lining dirt (adhesion)
- Brake cam wear / stuck
- Brake shoe installation fault
- Brake shoe cam wear / no grease
- Brake pedal pivot wear / no grease

Brake noise

- Brake lining wear
- Brake drum wear
- Brake lining unequal / step wear
- Brake lining dirt
- Brake drum dirt

◆ Front Brake Pad Replacement



CAUTION


- Keep the brake disc and the pads away from oil/grease. If the oil/grease contact them, replace the pads and clean the brake disc.
- After replacing the pads, operate the lever to push the piston out.

General Caution

- Replace the two pads together as a set.
- Before removing them, push the caliper body to the disc to push the caliper piston in.
- Do not operate the brake lever while replacing the brake pads.

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	Pad pin plug	1	Set the edge to the caliper bracket retainer when installing.
(2)	Pad pin	1	
(3)	Brake pad	2	

♦ Front Master Cylinder Assembly/Disassembly






Install both master cylinder piston / piston cup and the spring together into the cylinder.

Relevant Works

- Brake fluid change / air bleed.

Works / Parts		Qty.	Notes
	Disassembly		Reverse the procedure for the assembly.
(1)	Rear view mirror	1	Push the brake hose joint to the master cylinder stopper when tightening.
(2)	Front brake switch connector	2	
(3)	Brake hose oil bolt	1	
(4)	Sealing washer	2	Remove from the steering handle.
(5)	Brake hose	1	
(6)	Bolt	2	
(7)	Master cylinder holder	1	Set the switch projection to the master cylinder hole when installing.
(8)	Master cylinder ASSY	1	
(9)	Screw	2	
(10)	Reservoir cap	1	
(11)	Set plate	1	
(12)	Diaphragm	1	
(13)	Screw	1	
(14)	Front brake switch	1	
(15)	Lever pivot nut	1	
(16)	Lever pivot bolt	1	
(17)	Brake lever	1	
(18)	Boot	1	
(19)	Snap ring	1	
(20)	Washer	1	
(21)	Master piston / piston cup	1/1	
(22)	Spring	1	

◆ Front Brake Caliper Assembly/Disassembly






- Keep the disc and the pads away from oil/grease. If oil/grease contact them, replace the pad and clean the disc.
- After assembling the caliper, operate the lever to push the piston out.

Relevant Works

- Brake fluid change / air bleed.

Works / Parts		Qty.	Notes
	Disassembly		Reverse the procedure for the assembly.
(1)	Brake hose oil bolt	1	Push the brake hose joint to the caliper stopper when tightening.
(2)	Sealing washer	2	
(3)	Brake hose	1	
(4)	Pad pin plug	1	
(5)	Caliper mount bolt	2	Loosen the pad pin before removing it.
(6)	Front caliper ASSY	1	
(7)	Pad pin	1	
(8)	Brake pad	2	
(9)	Pad spring	1	
(10)	Caliper bracket	1	
(11)	Pad retainer	1	
(12)	Pin boot	1	
(13)	Pin bush boot	1	
(14)	Caliper piston	2	Record its position and set to the original position when installing.
(15)	Dust seal	2	
(16)	Piston seal	2	Do not damage the internal surface of the caliper.
(17)	Caliper pin bolt A	1	
(18)	Caliper pin bolt	1	Do not remove unless replacing.
(19)	Bleed valve	1	

◆ Rear Brake Panel Assembly/Disassembly




- Keep the brake lining surface away from oil/grease. If oil/grease contacts the surface, replace the brake shoe.

Relevant Works

- Rear wheel removal / installation (13-2).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Cotter pin	2	Firmly set from the direction shown in the figure when installing.
(2)	Anchor pin washer	1	
(3)	Brake shoe	2	
(4)	Shoe spring	2	Remove together with the shoe spring from the anchor pin and the brake cam.
(5)	Brake arm bolt	1	Do not install the shoes upside down (leading shoe and trailing shoe). Set the hook to the shoe hole from the brake panel side when installing.
(6)	Brake arm	1	
(7)	Indicator plate	1	Align the punched marks on the brake cam and the arm when assembling.
(8)	Felt seal	1	
(9)	Brake cam	1	

◆ Brake Pedal Removal/Installation

**Relevant Works**

- Right pivot plate cover removal / installation (13-6).

Works / Parts		Qty.	Notes
removal			Reverse the procedure for the installation.
(1)	Rear brake adjust nut	1	Disconnect from the swing arm hook. CAUTION <ul style="list-style-type: none"> • Remove from the brake rod. • Remove the brake pedal/rod ASSY from the frame
(2)	Brake rod spring	1	
(3)	Brake arm joint	1	
(4)	Rear brake pedal pivot bolt/nut	1/1	
(5)	Bolt	2	
(6)	Right main step holder/brake bracket	1/1	
(7)	Rear brake pedal return spring	1	
(8)	Rear brake middle arm split bolt	1	
(9)	Middle arm pivot shaft	1	
(10)	Rear brake switch spring	1	
(11)	Cotter pin	1	
(12)	Joint pin	1	
(13)	Rear brake rod	1	
(14)	Cotter pin	1	
(15)	Joint pin	1	
(16)	Rear brake middle arm	1	
(17)	Cotter pin	1	
(18)	Joint pin	1	
(19)	Rear brake middle rod	1	
(20)	Dust seal	2	

General Caution.....	15 – 1	Charging system inspection.....	15 - 5
Charging system layout.....	15 – 2	Regulate / rectifier.....	15 – 5
Troubleshooting.....	15 – 3	Alternator inspection.....	15 – 7
Battery removal / installation.....	15 – 4	Alternator removal/installation.....	15 - 8

General Caution





- Charging battery generates explosive gas. Keep it away from fire.
- Battery fluid (sulfuric acid) is highly toxic. Contact with clothes, skin or eyes may result in severe injury. If the fluid contacts the clothes/skin, wash out and rinse with large amount of water. If the fluid contacts the eyes, wash/rinse with water and consult the doctor. Change the affected clothes and wash the fluid off.



- This vehicle is equipped with an MF (maintenance free) battery. The MF battery has a unique charging system and therefore it is not compatible with conventional batteries.
- When charging the battery, dismount it from the frame and do not remove the fluid filler cap.
- Connection/disconnection of the terminals or the couplers while the current exists may result in over-voltage, which damages the regulate/rectifier and other electrical components.
Turn the ignition switch OFF when servicing the charging system/alternator or relevant parts.

- Repetition of full charging/discharging or leaving the battery in discharged status for a long time may reduce its performance and life and may also damage it. The reduced performance (capacity) battery may easily drop its voltage and go flat.
- Some battery overcharge may appear as such because of the battery fault. If one of the cells has short circuit, the battery terminal voltage will not achieve normal voltage. In this case the regulator will not activate and excess voltage is applied to the battery which reduces the cell battery fluid.
- Because of its self discharging effect, the battery should be charged every 3 months if it was left unused.
- In the following cases the supplemental charging may be required after filling the battery fluid on a new MF battery.
 - Terminal voltage (10min after filling the fluid) < 12.4V - charge until the voltage reaches 12.8V.
 - Battery fluid temperature $\leq 0^{\circ}\text{C}$ - charge for 2 ~ 3 hours with standard charging current.
- Follow the chart on 15-3 for the charging system troubleshooting.
- Majority of the failures are to do with the coupler / connector connection.
Check them before servicing the charging system.

◆ Charging System Layout




Troubleshooting**Battery Overcharge**


- Regulator / rectifier failure.
- Regulator / rectifier earth lead open circuit or loose connection.

Battery Undercharge / (flat battery)



Use fully – charged battery for the inspection.



◆ Battery Removal/Installation

**Relevant Works**

- Seat removal / installation.


Works / Parts		Qty.	Notes
Removal			Reverse the procedure for its installation.
(1)	Battery holder	1	<div> CAUTION Turn the main switch OFF. Disconnect the (-) lead first, then (+) lead.</div> <div> CAUTION When installing, connect the (+) lead first, then (-) lead.</div>
(2)	(-) lead	1	
(3)	(+) lead	1	
(4)	Battery	1	

Charging system inspection

Remove the seat (2-2)

Leak test

Turn the ignition switch OFF and disconnect the (-) lead from the battery.
Connect the (+) probe of the multimeter to the (-) lead, the (-) probe to the battery (-) terminal.
Leave the ignition switch OFF and measure the leak current.



- Select the 1 ampere / 1A range and reduce the range as required.
- Do not turn the ignition switch ON while measuring the current.


Leak current $\leq 0.1\text{mA}$

If the measured current is more than the above figure, there is a short circuit.
Disconnect the couplers/connectors one by one while measuring the current to find out the short circuit.

Charging status inspection

Use a battery with 13.0V (or above) terminal voltage for this inspection.


After warming up, install fully charged battery.
Connect a tachometer.
Connect a digital multimeter between the battery terminals.
Start the engine and establish the standard rpm for the regulating voltage.
Regulating voltage: 14 ~ 16V/5000rpm

**Regulate / Rectifier****Harness-side circuit inspection**

Remove the seat (2-2)

Disconnect the regulator/rectifier couplers and inspect the following circuits on the main harness side.

Item	Standard
Battery lead	Battery voltage between red/white (+) and body earth (-).
Ground earth	Conduction between green lead and the body earth.
Charging coil leads	0.1 ~ 1.0Ω (20°C) of resistance between yellow leads.




If the wire harness side inspections were all ok, inspect the regulator/rectifier coupler connection.

If the connections were fine, inspect the regulator/rectifier.

Regulator / Rectifier inspection

Remove the battery (15-4).


Remove two nuts to remove the regulator/rectifier.



Measure the resistance between its terminals.



- Do not touch the probes while measuring.
- Use the specified multimeters only. The other products may give different readings.
 - Genuine SANWA SP-15D Analogue
 - KOWA TH-5H Analogue
- Set the following range:
 - SANWA: K Ω range
 - KOWA: Rx100 Ω range
- If the readings are abnormal, change the batteries in the multimeter.



Resistance

Unit: K Ω (20 $^{\circ}$ C)

Probe (+) Probe (-)	B	A1	A2	A3	E
B		∞	∞	∞	∞
A1	0.5 - 10		∞	∞	∞
A2	0.5 - 10	∞		∞	∞
A3	0.5 - 10	∞	∞		∞
E	0.7 - 15	0.5 - 10	0.5 - 10	0.5 - 10	

If the readings are faulty, replace the regulator/rectifier.

Alternator inspection

The inspection can be conducted while the stator is installed to the engine.

Remove the right side cover (2-2).


Disconnect the alternator lead coupler.

Measure the charging coil resistance at the engine side coupler terminals.


Standard: $0.1 \sim 1.0\Omega$ (20°C)

Check there is no conduction between the engine side coupler terminals and the body earth.

If the resistance is out of the range, or if there is any conduction between the terminals and the body earth, replace the stator (15-8).



◆ Alternator Removal/Installation





- Place an oil pan underneath the engine when removing the left crankcase cover. Refill the oil after the installation.
- When installing, set the alternator leads correctly according to the wiring diagram (1-18).

Relevant Works

- Left side cover removal/installation (2-2).
- Left pivot plate cover removal/installation (2-2).


Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the assembly.
(1)	Gear shift arm bolt	1	When installing, align the punched marks on the arm and the gear shift spindle.
(2)	Gear shift arm	1	
(3)	Bolt	2	Remove together with the gear shift pedal and the arm.
(4)	Left main step holder	1	
(5)	Socket bolt	3	
(6)	Drive sprocket cover	1	
(7)	Left crankcase cover bolt/clamp	6/1	Removal / installation (15-10)
(8)	Left crankcase cover	1	
(9)	Gasket	1	
(10)	Flywheel bolt	1	
(11)	Washer	1	Remove the grommet from the crankcase and remove together with the lead.
(12)	Flywheel	1	
(13)	Alternator lead coupler	1	
(14)	Stator mount bolt	4	
(15)	Stator	1	

Flywheel bolt removal / installation**Removal**

Set the universal holder to fix the flywheel (as shown in the figure).
Loosen and remove the flywheel bolt.

Excl. tool


Universal holder 07725-0030000

**Installation**

Apply clean engine oil to the flywheel bolt thread and the seat and attach it.
Set the universal holder as shown in the figure.
Tighten the flywheel bolt.

Excl. tool

Universal holder 07725-0030000





Torque: 8.5kg-m

General Caution.....	16 – 1	Ignition coil.....	16 - 5
Ignition system layout.....	16 – 2	Pulse generator inspection.....	16 – 7
Troubleshooting.....	16 – 3	Ignition timing.....	16 – 7
Ignition system inspection.....	16 – 4	Pulse generator removal/installation.....	16 - 8

General Caution

- Follow the chart on 16-3 for the troubleshooting.
- The ignition timing cannot be adjusted because the electrical advancing system is fixed internally in the spark unit.
- Handle the spark unit with care. Dropping it or applying shock may cause failure. Connection / disconnection of the couplers and connects while having a current may damage the circuits. Turn the main switch OFF when servicing.
- The majority of the ignition system failures are caused by the faulty connections of the couplers and the connectors. Check them before the service.
- Only use a battery in good condition. Reduced capacity batteries may not produce adequate sparks by losing its power by cranking and also by low cranking speed.
- Improper selection of the spark plugs may result in engine trouble. Use the specified spark plugs.
- Follow the tables on 19-1 for the main switch conduction test.
- Refer to Sec 18 on the main volume for the neutral switch inspection.
- This vehicle is equipped with an ignition cut off type side stand. Refer to Sec. 16 on the main volume for its detail.
- Refer to Sec 18 for removal/installation of the side stand switch.

◆ Ignition System



Troubleshooting

- Check with a new (good) spark plug before starting the troubleshooting. Also check the plug cap and high tension lead attachment and the ignition coil for signs of crack, damage or moisture contamination.
- If only one ignition coil does not produce spark, swap the ignition coils and re-test. If there is not difference, measure the ignition coil primary voltage. If the spark appears, the original coil is faulty.
- The “Initial Voltage” of the ignition coil primary voltage is the measured voltage when the kill switch is in the RUN position and the main switch is ON (while not cranking the engine).

No spark from the spark plugs:

Status		Suspected cause (check from ①)
Ignition coil primary voltage	No initial voltage while the main switch is ON, the kill switch is RUN (the other electrical accessories are ok).	① Kill switch failure Black/White lead open circuit (kill switch-ignition coil) Faulty connection or open circuit of the lead on the ignition coil primary side terminal. If the initial voltage is ok when the spark unit is removed, the spark unit is faulty.
	The initial voltage is ok. However, the voltage drops 2 ~ 4V when cranking.	① Peak voltage adapter misconnection. Battery nearly flat. No voltage on spark unit (+) lead (black/white), or, spark unit coupler terminal connection fault. Spark unit earth lead (green) open circuit or faulty connection. Yellow/Blue, Blue/Yellow leads open circuit or faulty connection between the ignition coils and the spark unit. Ignition coil primary side lead short circuit. Neutral switch or side stand switch failure or relevant circuits fault (Yellow/Green, Green/White, Green leads and couplers). Pulse generator failure (measure the peak voltage). Spark unit failure (if ① ~ were all ok)
	The initial voltage is ok. However, little or no peak voltage when cranking.	① Peak voltage adapter misconnected. Peak voltage adapter failure. Spark unit failure (if ① and are ok)
	The initial voltage is ok. The peak voltage is below the standard.	① Too small internal resistance in the multimeter. Too low cranking speed • The battery nearly flat. Sampling time of the multimeter (it is ok if the standard voltage is achieved after a few attempts). Spark unit failure (if all of ① ~ are ok and no sparks on the plug)
	Both initial and peak voltages are fine but no spark.	① Spark plug fault or the ignition coil secondary current leak. Ignition coil failure.
Pulse Generator	Peak voltage	① Too small internal resistance of the multimeter. Too low cranking speed • The battery nearly flat Sampling time of the multimeter (it is ok if the standard voltage is achieved after a few attempts). Pulse generator failure (if all of ① ~ are ok)
	Little or not peak voltage	① Peak voltage adapter fault Pulse generator failure

Ignition system inspection




- If there is no spark, check all connections and measure each peak voltage.
- Use the multimeter with the impedance of 10MR/DCV or more.

Connect the digital multimeter to the peak voltage adapter.

Excl. tool

Peak voltage adapter 07HGJ-0020000

Conventional multimeter of 10MR/DCV or more impedance.



Ignition coil primary voltage



- Check all wirings beforehand.
- It should be inspected while cylinders give sufficient compression and the plugs and the plug caps are properly mounted.



Remove the left carburetor side cover (2-2).

Remove the front ignition coil (16-5).

If the engine ignites with normal system spark, the cranking speed is unstable.

Just like a normal spark test, leave the spark plug installed to the cylinder head, install new/good plugs to front and rear cylinder head, plug caps and earth to the engine.

Leave the primary lead connected to the ignition coil and connect the peak voltage adapter between the primary side lead and the body earth.



Connection:

Rear ignition coil: Yellow/Blue lead terminal (+) and the body earth (-).

Front ignition coil: Blue/Yellow lead terminal (+) and the body earth (-).

Turn the ignition switch ON and the kill switch to RUN.

Check the initial voltage. It should indicate almost battery voltage.

If there is inadequate/no voltage, the power circuit for the ignition coil is faulty. Refer to the troubleshooting before measuring the peak voltage.

Crank the engine with the starter motor and measure the primary side peak voltages for each ignition coil.

Peak Voltage: 100V or more



Do not touch the probe (metal part) while measuring. High voltage is hazardous.



Peak voltages for each ignition coil may differ from each other but it is fine as long as the voltages are above the standard.

If the measured voltages are below the standard, check the coupler/wire harness connection.

If the connections are fine, the spark unit may be faulty. Conduct the troubleshooting.

Pulse Generator



Install the spark plugs to the cylinder heads to check with actual compression existing.

Remove the seat (2-2).

Disconnect the coupler from the spark unit.

Connect the peak voltage adapter between the pulse generator or lead terminals on the wire harness end coupler (White / Yellow, Yellow).

White / Yellow – (+) and Yellow – (-).

Turn the ignition switch ON and the kill switch to RUN.

Crank the engine with the starter motor and measure the peak voltage of the pulse generator.

Peak Voltage: 0.7V or more




If the peak voltage measured at the spark unit end is below the standard, conduct the following inspection.

Remove the right side cover (2-2).

Disconnect the 4P black coupler between the pulse generator and the spark unit and connect the peak voltage adapter between the pulse generator lead terminals on the engine end coupler.

In the same manner with the spark unit end coupler, measure the peak voltage again and compare with the ones measured at the spark unit end.

- If the spark unit end is faulty and the engine end is fine, it is caused by faulty coupler connections or wire harness open circuit.
- If both ends are faulty, refer to the troubleshooting and consider it to be the pulse generator fault.



Ignition Coil

Removal / Installation

Front ignition coil:

Remove the fuel tank (2-3)


Remove plug caps from spark plugs.

Disconnect the primary leads from the ignition coil.

Remove two mount bolts and remove the ignition coil.


Rear ignition coil

Remove the left carburetor side cover (2-2).
Remove plug caps from the spark plugs.
Disconnect the primary lead from the ignition coil.
Remove two mount bolts to remove the ignition coil.

**Primary end coil inspection**


Measure the primary end coil resistance between the ignition terminals.

Standard: 2 ~ 4 Ω (20°C)

**Secondary end coil inspection**


Measure the secondary end coil resistance between the spark plug cap and the primary end green terminals.

Standard: 15 ~ 21k Ω (20°C)



If the measured resistance was out of the above range, disconnect the high tension lead from the ignition coil and measure the secondary end coil resistance as a single module.

Standard: 11 ~ 15k Ω (20°C)




Pulse generator inspection



The inspection can be conducted with the pulse generator installed to the engine.


Remove the right side cover (2-2).
Disconnect the 4P black coupler.
Measure the pulse generator resistance between the White/Yellow lead and the Yellow lead terminals on the engine end coupler.

Standard: 340 ~ 420Ω (20°C)




Ignition Timing

Warm up the engine.
Shut down the engine and connect the timing lamp to the high tension lead on the rear cylinder.
Connect a tachometer.
Remove the timing hole cap.
Start the engine and set to 1,200rpm (idling).
The F1 mark on a starter clutch should align with the mark on the right crankcase cover.




Gradually increase the engine rpm and the alignment mark on the right crankcase cover should come between the advance marks on the starter clutch at 5,000rpm.
Shut down the engine and connect the timing light to the front cylinder high tension lead.
Start the engine and set to 1,200rpm (idling).
The F2 mark on a starter clutch should align with the mark on the right crankcase cover.




Gradually increase the engine rpm and the alignment mark on the right crankcase cover should come between the advance marks on the starter clutch at 5,000rpm.

Apply grease to the timing hole cap O-Ring and the thread and install the cap.



Torque: 1.8kg-m.

◆ Pulse Generator Removal/Installation



Connect the pulse generator leads, oil pressure switch leads and the neutral switch leads correctly (1-18) when installing.

Relevant Works

- Right crankcase cover removal/installation (9-2).

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	4P black coupler	1	<ul style="list-style-type: none"> • Remove the grommet from the crankcase and remove the generator together with the leads. • Align the boss with the hole on a crankcase when installing.
(2)	Dust cover	1	
(3)	Terminal screw	1	
(4)	Oil pressure switch terminal	1	
(5)	Neutral switch connector	1	
(6)	Mount bolt	1	
(7)	Pulse generator	1	

General Caution.....	17 – 1	Starter motor assembly/disassembly.....	17 - 5
Starting system layout.....	17 – 2	Starter clutch removal/installation.....	17 – 6
Troubleshooting.....	17 – 3	Starter clutch assembly/disassembly....	17 – 7
Starter motor removal / installation....	17 – 4		

General Caution





Always turn the main switch OFF when servicing the starting system.
Unexpected activation of the starter motor may cause injury.

- If the battery is flat, the starter motor becomes too weak to crank. Whenever starting trouble occurs, try with well charged battery before troubleshooting.
- Excess current to the starter motor, attempting to crank, may damage the coil in the motor.
- Refer to the corresponding parts for the following parts:

• Clutch diode	Main volume	Sec 17
• Starter motor	“ “	Sec 17
• Starter relay switch	“ “	Sec 17 / Type A
• Clutch switch	“ “	Sec 18
• Neutral switch	“ “	Sec 18
• Sidestand switch	“ “	Sec 16 & 18
• Main switch	Wiring (19-1) conduction table	
- Follow the troubleshooting chart (17-3) for the starting system inspection.


◆ Starting System



Troubleshooting

The starter motor does not activate

- Check the main (30A) and sub (10A) fuses beforehand.
- Try with a well charged battery.
- The starter motor can be activated with the main switch ON, the kill switch on RUN and with the following status:
 - Transmission in neutral
 - The sidestand is retracted and the clutch lever is held if the transmission is in the position other than neutral.



Weak starter motor torque (unable to crank)

- Battery undercharged / flat
- Battery terminals connection fault
- Starter motor terminals connection fault
- Starter motor fault
- Brush wear/damage


The starter motor slips

- Starter clutch slip

The starter motor is ok but does not crank

- The crankshaft does not spin due to engine failure
- Starter reduction gear fault


◆ Starter Motor removal / installation



Turn the main switch OFF and disconnect the battery earth lead before starting any work.

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	Terminal nut	1	Assembly / disassembly (17-5)
(2)	Starter motor lead	1	
(3)	Mount bolt	2	
(4)	Starter motor	1	
(5)	O-Ring	1	

◆ Starter Motor Assembly / Disassembly




Relevant Works

- Starter motor removal / installation (17-4).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Case bolt	2	Set the catch to the groove on the front cover. Record the number (quantity) and order when disassembling. Record the number (quantity) and order when disassembling. Remove it after removing the brush. Record the order and the size when disassembling.
(2)	Washer	2	
(3)	O-Ring	2	
(4)	Front cover	1	
(5)	Seal ring	1	
(6)	Lock washer	1	
(7)	Insulator washer	1	
(8)	Shim	-	
(9)	Rear cover	1	
(10)	Seal ring	1	
(11)	Shim	-	
(12)	Armature	1	
(13)	Brush holder	1	
(14)	Nut	1	
(15)	Washer	1	
(16)	Insulator washer	3	
(17)	Terminal brush	1	
(18)	O-Ring	1	

◆ Starter Clutch Removal/Installation




Relevant Works

- Right crankcase cover removal / installation (9-2).
- Left crankcase cover removal / installation (15-8).

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	Starter reduction gear shaft	1	Fix the flywheel to remove the bolt (15-10).
(2)	Starter reduction gear	1	
(3)	Primary drive gear bolt	1	
(4)	Washer	1	
(5)	Starter clutch Assy	1	<ul style="list-style-type: none"> • Assembly / Disassembly (17-7) • Align the crankshaft with the wide spline when installing.
(6)	Thrust washer	1	
(7)	Spacer	1	Watch out the gear direction and align the crankshaft with the wide spline when installing.
(8)	Primary drive gear	1	

◆ Starter Clutch Assembly / Disassembly



Relevant Works

- Starter clutch removal / installation (17-6).

Works / Parts		Qty.	Notes
Disassembly			Reverse the procedure for the assembly.
(1)	Starter driven gear	1	Rotate it to the right to install when assembling.
(2)	Needle bearing	1	
(3)	Starter clutch cover bolt	3	
(4)	Starter clutch cover	1	
(5)	Roller	3	
(6)	Plunger	3	
(7)	Spring	3	
(8)	Spring pin	1	
(9)	Starter clutch body	1	

General Caution.....	18 – 1	Side stand switch removal/installation...	18 - 3
Bulb replacement.....	18 – 2	Instruments removal/installation.....	18 – 4
Main switch removal/installation.....	18 – 3	Headlamp case and pilot box Removal/installation.....	18 – 6

General Caution



The Halogen headlamp gets hot when it is illuminated. Do not touch the bulb immediately after turning it off. Wait for it to cool down.

- Do not touch the Halogen headlamp with bare hands or with dirty gloves. Oil on its surface may act as a hot spot, which cause distortion and damage on the bulb. When servicing (replacing) the bulb, follow the instructions below:
 - Do not replace it when it is turned on. Turn the main switch OFF and wait for the bulb to get cooled.
 - Wear clean gloves when replacing the bulb.
 - If oil stick on the glass surface, wipe off with a cloth using alcohol or thinner.
 - Install the dust cover after replacing the bulb.
- When checking any item using a battery, check the battery status first.
- The switch conduction test may be carried out without removing them.
- Refer to the corresponding sections for the following items:

• Direction indicator relay	Main volume	(sec. 18)
• Oil pressure warning lamp	“ “	(sec. 18)
• Thermo sensor	“ “	(sec. 18)
• Steering handle switches	Wiring diagram	(19-1) tables
• Brake switch	Main volume	(sec. 18)
• Horn	“ “	(sec. 18)
• Side stand indicator	“ “	(sec. 18)

Bulb Replacement**Headlamp**



The Halogen headlamp gets hot when it is illuminating. Do not touch immediately after turning it off. Wait for it to get cooled.

Remove two bolts and two collars to remove the headlamp from the case.


Disconnect the headlamp coupler.

Remove the dust cover.


Detach the retainer clip to remove the headlamp bulb.



Install a new bulb and fix it with the retainer clip.
Face the TOP mark upward to install the dust cover.
Connect the headlamp coupler.
Hook the catch on the top of the headlamp to the hook on the case to install the collar.
Firmly tighten the bolts.

**Direction Indicators**

Remove two screws to remove the direction indicator lens.
Push the bulb in and rotate to the left to remove it.
Check the lens gasket is fine and correctly set.
Replace the bulb and reverse the procedure to install it.




Brake / Tail lamp

Remove two screws to remove the tail lamp lens.

Push the brake/tail lamp in and rotate it to the left to remove it.

Check that the lens gasket is fine and correctly set.

Replace the bulb and reverse the procedure to install it.

**Main switch removal/installation**

Remove the fuel tank (2-3).


Disconnect the main switch lead coupler.

Detach the harness clip for the main harness and the main switch lead.

Remove two bolt caps.

Remove two torque bolts to remove the main switch.

Reverse the procedure for its installation.



Torque: bolts 1.0kg-m

Side stand switch removal/installation


Remove the left hand side cover (2-2).

Disconnect the side stand switch lead coupler.

Remove three socket bolts to remove the drive sprocket cover.

Support the frame to retract the side stand.

Remove the bolt to remove the side stand switch.



Set the side stand switch U-shaped groove to the return spring hook pin to install the switch.

Move the side stand to align the pivot hole with the switch rotor projection to install the switch.

Hold them to keep the hole and the projection aligned and tighten the bolt.

Torque: 1.0kg-m


Refer to the wiring diagram to set the side stand switch leads.

Connect the side stand switch coupler.

Install the drive sprocket cover with the three socket bolts.

Install the left side cover (2-2).

◆ Instruments removal/installation






When removing the instruments, remove the speedometer cable together with the speedometer by removing the set screw at the front wheel end.

Works / Parts		Qty.	Notes
Removal			Reverse the procedure for the installation.
(1)	Instrument leads coupler	1	<ul style="list-style-type: none"> • Disconnect from the speedo drive unit. • Set the cable to clamps when installing.
(2)	Speedometer cable set screw	1	
(3)	Speedometer cable	1	
(4)	Socket bolt / washer	4/4	Remove from the fuel tank.
(5)	Instruments cover ASSY	1	
(6)	Instruments illuminating lamp bulb socket	1	
(7)	Indicator lamp coupler	1	Loosen the cable nut and remove from the speedometer elbow boss.
(8)	Speedometer cable	1	
(9)	Screw	4	
(10)	Speedometer ASSY	1	
(11)	Screw	4	
(12)	Instrument bracket	2	
(13)	Screw	2	
(14)	Elbow boss	1	
(15)	Screw	1	
(16)	Trip meter reset knob	1	

◆ Head Lamp case and pilot box removal/installation




Relevant Works

- Headlamp removal/installation (18-2)

Works / Parts		Qty.	Notes
	Removal		Reverse the procedure for the installation.
(1)	Connectors / couplers	9/3	<ul style="list-style-type: none"> • Disconnect them and detach the harness from the clamp to pull them out from the case. • Refer to the wiring (1-18) for the installation.
(2)	Cap nut	2	
(3)	Mount bolt	2	
(4)	Cushion rubber	4	
(5)	Collar	2	
(6)	Headlamp case	1	
(7)	Screw	2	
(8)	Pilot box	1	

◆ Wiring Diagram




0030Z-KCR-0000


General Caution.....	20 – 1	Lack of power in high speed, insufficient speed	20 - 4
Unable or difficult to start.....	20 – 1	The engine becomes rough a few minutes after starting.....	20 - 4
Unstable idling or low rpm.....	20 – 2		
Unstable med ~ high rpm.....	20 - 3		


General Caution



This section describes the troubleshooting that involves the whole engine.

Refer to the corresponding sections for the troubleshooting not mentioned here.

Unable or difficult to start

Unstable idling or low rpm

Unstable med ~ high rpm

Lack of power in high speed / insufficient speed**The engine becomes rough a few minutes after starting**

To print chapters, click on the printer icon and fill in the page range.

1.	Service Information	3 - 23
2.	Exterior parts and muffler	24 - 29
3.	Inspection and adjustment	30 - 43
4.	Lubrication system	44 - 49
5.	Cooling system	50 - 57
6.	Fuel system	58 - 66
7.	Engine mounting/Dismounting	67 - 69
8.	Cylinder head/Valves	70 - 78
9.	Clutch	79 - 84
10.	Gearshift linkage	85 - 87
11.	Crankshaft/Piston/Transmission	88 - 102
12.	Frontwheel/Suspension/ Steering	103 - 113
13.	Rear wheel/Suspension	114 - 121
14.	Brake system	122 - 130
15.	Charging system/Alternator	131 - 140
16.	Ignition system	141 - 148
17.	Starting system/Starter clutch	149 - 155
18.	Lamps/Instruments/Switches	156 - 161
19.	Wiring diagram	162
20.	Troubleshooting	163 - 166