TABLE OF CONTENTS

Information on the hybrid system and adjusting and Before driving operating features such as door locks, mirrors, and steering column. When driving Driving, stopping and safe-driving information. Air conditioning and audio systems, as well as other in-**Interior features** terior features for a comfortable driving experience. **Maintenance and** Cleaning and protecting your vehicle, performing do-ityourself maintenance, and maintenance information. care When trouble What to do if the vehicle needs to be towed, gets a flat arises tire, or is involved in an accident. Vehicle specifi-Detailed vehicle information. cations Alphabetical listing of information contained in this man-Index

1	Before driving	1-6.	Opening the fuel tank	
			cap	104
1-1.	Hybrid system	1.7	Theft deterrent system	
	Hybrid system30	• • • •	Immobilizer system	107
			Double locking system	
1-2.	Key information		Alarm	
	Keys 42			
12	Opening, closing and	1-8.	Safety information	
1-5.	locking the doors		Correct driving posture	127
	Smart entry & start system 44		SRS airbags	129
	Push button start 59		Child restraint systems	140
	Wireless remote control 70		Installing child restraints	149
	Side doors72		Airbag manual on-off	
	Back door75		system	160
1-4.	Adjustable components (seats, mirrors,	2	When driving	
	steering wheel)			
	Front seats 80	2-1.	Driving procedures	
	Rear seats 81		Driving the vehicle	164
	Head restraints 84		Power (ignition) switch	175
	Seat belts 86		EV-Drive Mode	180
	Steering wheel 91		Transmission	
	Anti-glare inside rear view		Turn signal lever	
	mirror 92		Parking brake	
	Outside rear view mirrors 94		Horn	192
1-5.	Opening and closing the	2-2.	Instrument cluster	
1-5.	windows and moon roof	2-2.	Instrument cluster Gauges and meters	193
1-5.	windows and moon roof Power windows 97	2-2.	Gauges and metersIndicators and warning	
1-5.	windows and moon roof	2-2.	Gauges and meters	197

2-3.	Operating the lights and wipers	3	Interior features	
	Headlight switch	3-1.	Using the air conditioning system and defogger Air conditioning system 244 Rear window and outside rear view mirror defoggers	1
2-4.	Using other driving systems	3-2.	Using the audio system	2
	Cruise control		Audio system types	3
2-5.	Driving information Cargo and luggage		Operating a USB memory	4
	Trailer towing 240		Using the AUX port	5
		3-3.	Using the Bluetooth® audio system Bluetooth® audio system 295 Using the Bluetooth®	6
			audio system	
			enabled portable player 304 Bluetooth® audio system setup	

TABLE OF CONTENTS

Index

3-4.	Using the hands-free		Floor mat	352
	phone system		Luggage compartment	
	(for cellular phone)		features	353
	Hands-free phone system			
	(for cellular phone) features	4	Maintenance and care	
		4 1	viaintenance and care	
	Using the hands-free phone system			
	(for cellular phone) 314	4-1.	Maintenance and care	
	Making a phone call 320		Cleaning and protecting	
	Setting a cellular phone 323		the vehicle exterior	356
	Security and system		Cleaning and protecting	
	setup 327		the vehicle interior	360
	Using the phone book 331	4.0		
		4-2.	Maintenance	
3-5.	Using the interior lights		Maintenance	202
	Interior lights list		requirements	303
	• Interior light	12	Do-it-yourself maintenanc	^
	Personal lights	4-3.		E
	Halam the atomore fortune		Do-it-yourself service precautions	366
3-6.	Using the storage features		Hood	
	List of storage features 339		Positioning a floor jack	
	• Glove box		Engine compartment	
	• Cup holders 341		12-volt battery	381
	Auxiliary boxes 342		Tires	
	·		Tire inflation pressure	
3-7.	Other interior features		Wheels	
	Sun visors 343		Air conditioning filter	
	Vanity mirrors 344		Key battery	
	Clock		Checking and replacing	391
	Portable ashtray 346		fuses	400
	Cigarette lighter 347		Light bulbs	
	Power outlet 349		Ligite Suibo	F 1 1

Δ


Seat heaters 350


When trouble arises


5-1.	Essential information
	Emergency flashers 422
	If your vehicle needs to
	be towed 423
	If you think something
	is wrong 429
5-2.	Steps to take in an
	emergency
	If a warning light turns
	on or a warning buzzer
	sounds 430
	If a warning message is
	displayed 436
	If you have a flat tire
	(vehicles with a spare tire) 447
	If you have a flat tire
	(vehicles with an
	emergency tire
	puncture repair kit) 459
	If the hybrid system will
	not start 471
	If you lose your keys 473
	If the electronic key does
	not operate properly 474
	If the 12-volt battery is
	discharged 476
	If your vehicle overheats 481
	If the vehicle becomes
	stuck
	If your vehicle has to
	be stopped in an emergency488
	Ginergency 400


6 Vehicle specifications


6-1.	Specifications Maintenance data (fuel, oil level, etc.)	1
	Tuer information	_
6-2.	Customization	
	Customizable features 506	2
	ndex	3
Abb	reviation list 510	
Alpł	nabetical index 511	4
Wha	t to do if 521	
		5
		6

























Instrument panel **Pictorial index** (Left-hand drive vehicles) В ▶ Type A "DISP" switch P. 201 Telephone switch * Talk switch *,* P. 315 Cruise control switch * P. 219 ► Type B "DISP" switch P. 201 CTNPIAE272 Cruise control switch * P. 219























For your information

Main Owner's Manual

Please note that this manual covers all models and all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Toyota policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of equipment.

Accessories, spare parts and modification of your Toyota

Both genuine Toyota and a wide variety of other spare parts and accessories for Toyota vehicles are currently available on the market. Should it be determined that any of the genuine Toyota parts or accessories supplied with the vehicle need to be replaced, Toyota Motor Corporation recommends that genuine Toyota parts or accessories, be used to replace them. Other parts or accessories of matching quality can also be used. Toyota cannot accept any liability or guarantee spare parts and accessories which are not genuine Toyota products, nor for replacement or installation involving such parts. In addition, damage or performance problems resulting from the use of nongenuine Toyota spare parts or accessories may not be covered under warranty.

Installation of an RF-transmitter system

As the installation of an RF-transmitter system in your vehicle could affect electronic systems such as the multi-port fuel injection system/sequential multi-port fuel injection system, cruise control system, anti-lock brake system, SRS airbag system or seat belt pretensioner system, be sure to check with any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for precautionary measures or special instructions regarding installation.

Further information regarding frequency bands, power levels, antenna positions and installation provisions for the installation of RF-transmitters, is available on request at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

High voltage parts and cables on the hybrid vehicles emit approximately the same amount of electromagnetic waves as the conventional gasoline powered vehicles or home electronic appliances despite of their electromagnetic shielding.

Scrapping your Toyota

The SRS airbag and seat belt pretensioner devices in your Toyota contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, before you scrap your vehicle.

A CAUTION

General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the cigarette lighter, the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

A CAUTION

Dispose of the hybrid battery (traction battery)

If your vehicle is disposed of without the hybrid battery having been removed, there is a danger of serious electric shock if high voltage parts, cables and their connectors are touched. In the event of that your vehicle must be disposed of, the hybrid battery must be disposed of any authorized Toyota dealer or repairer, or another duly qualified and equipped professional. If the hybrid battery is not disposed of properly, they may cause electric shock that can result in death or serious injury.



Your vehicle contains batteries and/or accumulators. Do not discard them into the environment but cooperate with separate collection (Directive 2006/66/ EC).

Symbols used throughout this manual

Cautions & Notices



A CAUTION

This is a warning against anything which may cause injury to people if the warning is ignored. You are informed about what you must or must not do in order to reduce the risk of injury to yourself and others.



NOTICE


This is a warning against anything which may cause damage to the vehicle or its equipment if the warning is ignored. You are informed about what you must or must not do in order to avoid or reduce the risk of damage to your Toyota and its equipment.

Symbols used in illustrations



Safety symbol

The symbol of a circle with a slash through it means "Do not", "Do not do this", or "Do not let this happen".



Arrows indicating operations


- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- Indicates the outcome of an operation (e.g. a lid opens).

1 Before driving 1-1. Hybrid system 1-5. Opening and closing the windows and moon roof Hybrid system..... 30 Power windows...... 97 1-2. Key information Moon roof...... 100 Keys...... 42 1-6. Refueling 1-3. Opening, closing and Opening the fuel tank locking the doors cap...... 104 Smart entry & start 1-7. Theft deterrent system system 44 Push button start 59 Immobilizer system 107 Wireless remote control..... 70 Double locking system..... 113 Side doors 72 Alarm 115 Back door 75 1-8. Safety information 1-4. Adjustable components Correct driving posture 127 (seats, mirrors, SRS airbags..... 129 steering wheel) Child restraint systems 140 Front seats...... 80 Installing child Rear seats 81 restraints...... 149 Airbag manual on-off Head restraints 84 system 160 Seat belts...... 86 Steering wheel 91 Anti-glare inside rear view mirror......92 Outside rear view mirrors ... 94

1-1. Hybrid system **Hybrid system**

Your vehicle is a hybrid vehicle. It has characteristics different from conventional vehicles. Be sure you are closely familiar with the characteristics of your vehicle, and operate with care.

The hybrid system combines a gasoline engine and an electric motor (traction motor) according to driving conditions, improving fuel efficiency and reducing exhaust emissions.



- Gasoline engine
- Electric motor (Traction motor)

■ When stopped/during take-off

The gasoline engine stops when the vehicle is stopped. During take-off, the electric motor (traction motor) drives the vehicle. At slow speeds or when traveling down a gentle slope, the engine is stopped and the motor is used.

■ During normal driving

The gasoline engine is predominantly used. The electric motor (traction motor) charges the hybrid battery (traction battery) as necessary.

■ When accelerating sharply

The power of the hybrid battery (traction battery) is added via electric motor (traction motor) to that of the gasoline engine.

■ When braking (Regenerative brake)

The electric motor (traction motor) charges the hybrid battery (traction battery).

■ Regenerative braking

In the following situations, kinetic energy is converted to electric energy and deceleration force can be obtained in conjunction with the recharging of the hybrid battery (traction battery).

- The accelerator pedal is released while driving with shift position D or B selected.
- The brake pedal is depressed while driving with shift position D or B selected.

■ Conditions in which the gasoline engine may not stop

The gasoline engine starts and stops automatically. However, the followings are examples of conditions under which the engine may not stop automatically:

- The gasoline engine is warming up.
- The hybrid battery (traction battery) is being charged.
- The hybrid battery (traction battery) temperature is low or high.
- The temperature setting of the air conditioning system is high.

■ Charging the hybrid battery (traction battery)

- As the gasoline engine or regenerative brake charges the hybrid battery (traction battery), the battery does not need to be charged from an outside source. However, if the vehicle is left parked for a long time the hybrid battery will slowly discharge. For this reason, be sure to drive the vehicle at least once every several months for at least 30 minutes or 16 km (10 miles). If the hybrid battery becomes fully discharged and you are unable to jump-start the vehicle with the 12-volt battery, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.
- If the shift position is in N, the hybrid battery (traction battery) will not be charged. When driving in heavy traffic, operate the vehicle with the shift position in D or B to avoid discharging the battery.

■ Charging the 12-volt battery

→P. 478

■ After the 12-volt battery has discharged or has been changed or removed

The gasoline engine may not stop even if the vehicle is running on the hybrid battery (traction battery). If this continues for a few days, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ Sounds and vibrations specific to a hybrid vehicle

There may be no engine sounds or vibration even though the vehicle is able to move. Always push the P position switch and set the parking brake when parked.


The following sounds or vibrations may occur when the hybrid system is operating, and are not a malfunction.

- Motor sounds may be heard from the engine compartment.
- Sounds may be heard from the hybrid battery (traction battery) behind the rear seat when the hybrid system starts or stops.
- Sounds from the hybrid system may be heard when the back door is open.
- Sounds may be heard from the transmission when the gasoline engine starts or stops, when driving at low speeds, or during idling.
- Engine sounds may be heard when accelerating sharply.
- Sounds may be heard due to regenerative brake when you press the brake pedal or release the accelerator pedal.
- Other sounds, such as motors and mechanical noises, may be heard from the brake system when the brake pedal is depressed.
- Vibration may be felt when the gasoline engine starts or stops.
- You may hear cooling fan sounds coming from the air intake vents behind the rear seat.

■ Maintenance, repair, recycling, and disposal

Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional regarding maintenance, repair, recycling and disposal. Do not dispose of the vehicle yourself.

High voltage components




- Air conditioning compressor
- High voltage cables (orange color)
- 3 Power control unit and DC/DC converter
- 4 Caution label

- 5 Service plug
- 6 Hybrid battery (Traction battery)
- 7 Electric motor (Traction motor)

Take care when handling the hybrid system, as it contains a high voltage system (about 650 V at maximum) as well as parts that become extremely hot when the hybrid system is operating. Obey the caution labels attached to the vehicle.

■ Hybrid battery air vent




There is an air intake vent on the side of the rear right seatback for the purpose of cooling the hybrid battery (traction battery). If the vent becomes blocked, the hybrid battery may overheat, leading to a reduction in hybrid battery output.

Emergency shut off system

The emergency shut off system blocks off the high voltage current and stops the fuel pump to minimize the risk of electrocution and fuel leakage when a certain level of impact is detected by the impact sensor. If the emergency shut off system activates, your vehicle will not restart. To restart the hybrid system, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Energy monitor




You can view the status of your hybrid system on the multi-information display (→P. 200).

The following images are examples only, and may vary slightly from actual conditions.

Press the "DISP" switch on the steering wheel several times to select the energy monitor display.

When the vehicle is powered by the electric motor (traction motor)	
When the vehicle is powered by both the gasoline engine and the electric motor (traction motor)	
When the vehicle is powered by the gasoline engine	



Hybrid warning message

A message is automatically displayed when a malfunction occurs in the hybrid system or an improper operation is attempted.

If a warning message is shown on the multi-information display, read the message and follow the instructions. (\rightarrow P. 436)

■ If a warning light comes on or a warning message is displayed, or the 12-volt battery is disconnected

The hybrid system may not start. In that case, try to start the system again. If the "READY" indicator does not come on, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ Electromagnetic waves

- High voltage parts and cables on the hybrid vehicles incorporate electromagnetic shielding, and therefore emit approximately the same amount of electromagnetic waves as conventional gasoline powered vehicles or home electronic appliances.
- Your vehicle may cause sound interference in some third party-produced radio parts.
- Consult any authorized Toyota dealer or repairer, or another duly qualified and equipped professional before installing or removing third party-produced radio parts.

■ Running out of fuel

When the vehicle has run out of fuel and the hybrid system cannot be started, refuel the vehicle with at least enough gasoline to make the low fuel level warning light go off (\rightarrow P. 433). If there is only a small amount of fuel, the hybrid system may not be able to start. (The minimum amount of fuel to add to make the low fuel level warning light go out is about 12 L [3.2 gal., 2.7 lmp. gal.], when the vehicle is on a level surface. This value may vary when the vehicle is on a slope.)

■ Hybrid battery (traction battery)


The hybrid battery (traction battery) has a limited service life. The lifespan of the hybrid battery (traction battery) can change in accordance with driving style and driving conditions.

A CAUTION

High voltage precautions

The vehicle has high voltage DC and AC systems as well as a 12-volt system. DC and AC high voltage is very dangerous and can cause severe burns and electric shock that may result in death or serious injury.

- Never touch, disassemble, remove or replace the high voltage parts, cables and their connectors.
- The hybrid system will become hot after starting as the system uses high voltage. Be careful of both the high voltage and the high temperature, and always obey the caution labels attached to the vehicle.



- Never try to open the service plug access hole located in the luggage compartment. The service plug is used only when the vehicle is serviced and is subject to high voltage.
- Do not subject the service plug to strong impacts. Also, avoid splashing large amount of water onto the luggage compartment, for example while in a high-pressure car wash.

Hybrid battery (traction battery)

Your vehicle contains a sealed nickel-metal hydride battery. If disposed of improperly, it is hazardous to the environment and there is a risk of severe burns and electrical shock that may result in death or serious injury.

A CAUTION

Emergency shut off system

- Carefully check to see if there are exposed high voltage parts or cables.
 Never touch the parts or cables. (→P. 34)
- Carefully inspect the ground under the vehicle. If you find that liquid has leaked onto the ground, the fuel system may have been damaged. Leave the vehicle as soon as possible.

Road accident cautions

If your vehicle is involved in an accident, observe the following precautions to reduce the risk of injury.

- Stop the vehicle in a safe place to prevent subsequent accidents. While
 depressing the brake pedal, apply the parking brake and push the P position switch to stop the hybrid system. Then, slowly release the brake
 pedal.
- Do not touch the high voltage parts, cables and connectors.
- If electric wires are exposed inside or outside your vehicle, an electric shock may occur. Never touch exposed electric wires.
- If a fluid leak occurs, do not touch it as it may be strong alkaline electrolyte from the hybrid battery (traction battery). If it comes into contact with your skin or eyes, wash it off immediately with a large amount of water or if possible, boric acid solution. Seek immediate medical attention.
- If a fire occurs in the hybrid vehicle, leave the vehicle as soon as possible.
 Never use a fire extinguisher that is not meant for electric fires. Using even a small amount of water may be dangerous.
- If your vehicle needs to be towed, do so with the front wheels raised. If the wheels with the electric motor (traction motor) are on the ground when towing, the motor may continue to generate electricity. This may cause an electricity leakage leading to a fire. (→P. 423)

Nickel-metal hydride battery

Your vehicle contains a sealed nickel-metal hydride battery. If disposed of improperly, it is hazardous to the environment and there is a risk of severe burns and electrical shock that may result in death or serious injury.

↑ NOTICE


Hybrid battery air vent

- Do not put foreign objects over the air vent. The hybrid battery (traction battery) may overheat and be damaged.
- Clean the air vent regularly to prevent the hybrid battery (traction battery) from overheating.
- Do not wet or allow foreign substances to enter the air vent as this may cause a short circuit and damage the hybrid battery (traction battery).
- Do not load a large amount of water such as an aquarium into the vehicle.
 If water spills over the hybrid battery (traction battery), the battery may be damaged.
- When the rear seat belts are in use, make sure to pass them through the guides (→P. 82). Otherwise, the rear seat belts may cover the hybrid battery air vents.

1-2. Key information


Keys

The following keys are provided with the vehicle.



- Electronic keys
 - Operating the smart entry & start system (if equipped) (→P. 44)
 - Operating the push button start (if equipped) (→P. 59)
 - Operating the wireless remote control function (→P. 70)
- Mechanical keys
- Key number plate

Using the mechanical key



Take out the mechanical key.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key. (→P. 474)

■ Key number plate

Keep the plate in a safe place such as your wallet, not in the vehicle. In the event that a key is lost, a new key can be made by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, using the key number plate. $(\rightarrow P. 473)$

■ When riding in an aircraft

When bringing a key with wireless remote control function onto an aircraft, make sure you do not press any buttons on the key while inside the aircraft cabin. If you are carrying the key in your bag etc, ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the key to emit radio waves that could interfere with the operation of the aircraft.


↑ NOTICE

To prevent key damage

- Do not subject the keys to strong shocks, expose them to high temperatures by placing them in direct sunlight, or get them wet.
- Do not expose the keys to electromagnetic materials or attach any material that blocks electromagnetic waves to the key surface.
- Do not disassemble the electronic key.

1-3. Opening, closing and locking the doors Smart entry & start system*

The following operations can be performed simply by carrying the electronic key on your person, for example in your pocket. (The driver should always carry the electronic key.)




- 1 Locks and unlocks the doors (→P. 45)
- 2 Locks and unlocks the back door (\rightarrow P. 45)
- 3 Starts the hybrid system (→P. 175)

*: If equipped

Unlocking and locking the doors


► Front door handles



Grip the handle to unlock the doors.


Make sure to touch the sensor on the back of the handle.

The door cannot be unlocked for 3 seconds after the door is locked.



Press the lock button to lock the doors.


▶ Back door handle



Press the button to unlock the doors.

The door cannot be unlocked for 3 seconds after the door is locked.


1-3. Opening, closing and locking the doors



Press the button to lock the doors.


Antenna location and effective range


■ Antenna location



- Antennas outside the cabin
- 2 Antennas inside the cabin
- Antenna inside the luggage compartment
- 4 Antenna outside the luggage compartment

■ Effective range (areas within which the electronic key is detected)





The system can be operated when the electronic key is within about 0.7 m (2.3 ft.) of either of the outside front door handles and back door. (Only the doors detecting the key can be operated.)

When starting the hybrid system or changing "POWER" switch modes

The system can be operated when the electronic key is inside the vehicle.

■ Operation signals

The emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

■ Conditions affecting operation

The smart entry & start system uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart entry & start system and wireless remote control from operating properly: (Ways of coping: \rightarrow P. 474)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication devices
- When the electronic key has come into contact with, or is covered by a metallic object
- When multiple electronic keys are in the vicinity
- When carrying or using the electronic key together with the following devices that emit radio waves
 - · Another vehicle's electronic key
 - A wireless key that emits radio waves
 - · Personal computers
- If window tint with a metallic content or metallic objects are attached to the rear window

■ Battery-saving function

In the following circumstances, the entry function is disabled in order to prevent the vehicle and electronic key batteries from discharging.

- When the entry function has not been used for 2 weeks or more
- When the electronic key has been left within approximately 1 m (3 ft.) of the vehicle for 10 minutes or more

The system will resume operation when...

- The vehicle is locked using the door handle lock switch.
- The vehicle is locked/unlocked using the wireless remote control function. (→P. 70)
- The vehicle is locked/unlocked using the mechanical key. (→P. 474)

■ Key battery depletion

- The standard battery life is 1 to 2 years. (The battery becomes depleted even if the electronic key is not used.) If the smart entry & start system or the wireless remote control function does not operate, or the detection area becomes smaller, the battery may be depleted. Replace the battery when necessary. (→P. 397)
- If the battery becomes low, an alarm will sound in the cabin when the hybrid system stops. (→P. 441)
- To avoid serious deterioration, do not leave the electronic key within 1 m
 (3 ft.) of the following electrical appliances that produce a magnetic field.
 - TVs
 - · Personal computers
 - · Recharging cellular phones or cordless phones
 - · Table lamps

■ To operate the system properly

Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention may not function.)

■ Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases.
 - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
 - The electronic key is on the instrument panel, luggage cover, floor or in the glove box when the hybrid system is started or "POWER" switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the door will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone.
- Even if the electronic key is not inside the vehicle, it may be possible to start the hybrid system if the electronic key is near the window.
- The doors may unlock if a large amount of water splashes on the door handle, such as in the rain or in a car wash. (The doors will automatically be locked after approximately 30 seconds if the doors are not opened and closed.)
- Gripping the door handle when wearing a glove may not unlock the door.
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)

■ When the vehicle is not driven for extended periods

To prevent theft of the vehicle, do not leave the electronic key within 2 m (6 ft.) of the vehicle.

■ Security feature

If a door is not opened within approximately 30 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

■ Alarms and warning messages

A combination of exterior and interior alarms as well as warning messages shown on the multi-information display is used to prevent theft of the vehicle and accidents resulting from erroneous operation. Take appropriate measures in response to any warning message on the multi-information display. $(\rightarrow P. 436)$

The following table describes circumstances and correction procedures when only alarms are sounded.

Alarm	Situation	Correction procedure
Exterior alarm sounds once for 10 seconds	Tried to lock the vehicle using the entry function while a door was open	Close all of the doors and lock the doors again.
Interior alarm beeps repeatedly	Turned the "POWER" switch to ACCESSORY mode while the driver's door was open (Opened the driver's door when the "POWER" switch was in ACCESSORY mode.)	Turn the "POWER" switch off and close the driver's door.
	Turned the "POWER" switch off while the driver's door was open	Close the driver's door.

■ If the smart entry & start system does not operate properly

- Locking and unlocking the doors: Use the mechanical key. (→P. 474)
- Starting the hybrid system: →P. 474
- When the electronic key battery is fully depleted

→P. 397

■ Customization that can be configured at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional

It is possible to deactivate the smart entry & start system, etc. (Customizable features \rightarrow P. 506)

■ Certification for the smart entry & start system

Hereby, Toyota Motor Corporation, declares that this TMLF-3 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA

TOYOTA MOTOR CORPORATION

1, TOYOTA-CHO, TOYOTA, AICHI, 471-8571 (Head Office) or 471-8572 (Research & Development Group) JAPAN TEL:+81-565-28-2121

R&TTE Declaration of Conformity

We,

Manufacturer's Name: TOYOTA MOTOR CORPORATION

Manufacturer's Address: 1, Toyota -cho, Toyota, Aichi, 471-8572, Japan

hereby declare under our sole responsibility that the product:

Product Name: LF Oscillator Product Model: TMLF-3

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

-Health & safety requirements: EN60950-1: 2001

-EMC requirements: EN301 489-1 V1.4.1 & EN301 489-3 V1.4.1

-Effective uses of radio spectrum: EN300 330-2 V1.1.1

Supplementary information:

Signature:

* CE mark	C€
* Member states intended for use	EU and EFTA

<u>Date:</u> <u>June 21, 200</u>

Tomoki Katayama

Hereby, Toyota Motor Corporation, declares that this TMLF-3 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Toyota Motor Corporation vakuuttaa täten että TMLF-3 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Toyota Motor Corporation dat het toestel TMLF-3 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Toyota Motor Corporation déclare que l'appareil TMLF-3 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Toyota Motor Corporation att denna TMLF-3 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede Toyota Motor Corporation erklærer herved, at følgende udstyr TMLF-3 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Toyota Motor Corporation, dass sich das Gerät TMLF-3 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ME THN ΠΑΡΟΥΣΑ Toyota Motor Corporation ΔΗΛΩΝΕΙ ΟΤΙ TMLF-3 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

1-3. Opening, closing and locking the doors

Con la presente Toyota Motor Corporation dichiara che questo TMLF-3 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Toyota Motor Corporation declara que el TMLF-3 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Toyota Motor Corporation declara que este TMLF-3 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Toyota Motor Corporation, jiddikjara li dan TMLF-3 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Toyota Motor Corporation seadme TMLF-3 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Toyota Motor Corporation nyilatkozom, hogy a TMLF-3 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Toyota Motor Corporation týmto vyhlasuje, že TMLF-3 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Toyota Motor Corporation tímto prohlašuje, že tento TMLF-3 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Toyota Motor Corporation izjavlja, da je ta TMLF-3 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo Toyota Motor Corporation deklaruoja, kad šis TMLF-3 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Toyota Motor Corporation deklarē, ka TMLF-3 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Toyota Motor Corporation oświadcza, że TMLF-3 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Toyota Motor Corporation yfir því að TMLF-3 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Toyota Motor Corporation erklærer herved at utstyret TMLF-3 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Ovim, Toyota Motor Corporation, izjavljuje da ovaj TMLF-3 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

1-3. Opening, closing and locking the doors

Hereby, Tokai Rika Co., Ltd., declares that this B90EA is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B90EA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/ EC.

TOKAI RIKA

R&TTE Declaration of Conformity

We,

Manufacturer's Name: Tokai Rika Co., Ltd.

Manufacturer's Address: 260, Toyota 3-chome, Oguchi-cho, Niwa-gun, Aichi-ken,

480-0195, Japan

hereby declare under our sole responsibility that the product:

Product Name: Electronic Key Product Model: B90EA

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

Safety:

EN60950-1

EMC: Spectrum: EN301 489-1 & -3

EN300 220-2, EN300 330-2

Supplementary information:

* CE mark	CE
* Member states intended for use	EU and EFTA
* Member states with restrictive use	None

Date:

10 February 2009

Signature:

Yoshinobu Yokoyama General Manager,

Position of the signatory:

Security Electronic Engineering Div.

Wookinde apokoyana

Hereby, Tokai Rika Co., Ltd., declares that this B51UA is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B51UA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

TOKAI RIKA

R&TTE Declaration of Conformity

We,

Manufacturer's Name: Tokai Rika Co., Ltd.

Manufacturer's Address: 260, Toyota 3-chome, Oguchi-cho, Niwa-gun, Aichi-ken,

480-0195, Japan

hereby declare under our sole responsibility that the product:

Product Name: Tuner
Product Model: B51UA

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

Safety: EN60950-1
EMC: EN301 489-1 & -3
Spectrum: EN300 220-3

Supplementary information:

* CE mark	CE
* Member states intended for use	EU and EFTA
* Member states with restrictive use	None

Date: 22 February 2005

Signature:

Position of the signatory:

Tadashi Wakiya

General Manager,
Electronics Engineering Div.

A CAUTION

Caution regarding interference with electronic devices

- People with implanted pacemakers or cardiac defibrillators should maintain a reasonable distance between themselves and the smart entry & start system antennas. (→P. 46)
 - The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for details, such as the frequency of radio waves and timing of emitting the radio waves. Then, consult your doctor to see if you should disable the entry function.
- User of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.
 - Radio waves could have unexpected effects on the operation of such medical devices.


Ask any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for details for disabling the entry function.

1

1-3. Opening, closing and locking the doors **Push button start***

Starting and stopping the hybrid system can be performed simply by carrying the electronic key on your person, for example in your pocket.


(The driver should always carry the electronic key.)



*: If equipped


Antenna location and effective range

■ Antenna location



- Antennas inside the cabin
- 2 Antenna inside the luggage compartment

■ Effective range (areas within which the electronic key is detected)



When starting the hybrid system or changing "POWER" switch modes

The system can be operated when the electronic key is inside the vehicle.

■ Conditions affecting operation

The push button start uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the push button start and wireless remote control from operating properly: (Ways of coping: →P. 474)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication devices
- When the electronic key has come into contact with, or is covered by a metallic object
- When multiple electronic keys are in the vicinity
- When carrying or using the electronic key together with the following devices that emit radio waves
 - · Another vehicle's electronic key
 - · A wireless key that emits radio waves
 - · Personal computers
- If window tint with a metallic content or metallic objects are attached to the rear window

■ Key battery depletion

- The standard battery life is 1 to 2 years. (The battery becomes depleted even if the electronic key is not used.) If the push button start or the wireless remote control function does not operate, or the detection area becomes smaller, the battery may be depleted. Replace the battery when necessary. (→P. 397)
- If the battery becomes low, an alarm will sound in the cabin when the hybrid system stops. (→P. 441)
- To avoid serious deterioration, do not leave the electronic key within 1 m
 (3 ft.) of the following electrical appliances that produce a magnetic field.
 - TVs
 - · Personal computers
 - · Recharging cellular phones or cordless phones
 - · Table lamps

■ To operate the system properly

Make sure to carry the electronic key when operating the system.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly.

■ Alarms and warning messages

→P. 51

■ If the push button start does not operate properly

Starting the hybrid system: →P. 474

■ When the electronic key battery is fully depleted

→P. 397

Customization that can be configured at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional

It is possible to deactivate the push button start. (Customizable features \rightarrow P. 506)

■ Certification for the push button start

Hereby, Toyota Motor Corporation, declares that this TMLF-3 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA

TOYOTA MOTOR CORPORATION

1, TOYOTA-CHO, TOYOTA, AICHI, 471-8571(Head Office) or 471-8572(Research & Development Group) JAPAN TEL:+81-565-28-2121

R&TTE Declaration of Conformity

We,

Manufacturer's Name: TOYOTA MOTOR CORPORATION

Manufacturer's Address: 1, Toyota -cho, Toyota, Aichi, 471-8572, Japan

hereby declare under our sole responsibility that the product:

Product Name: LF Oscillator Product Model: TMLF-3

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

-Health & safety requirements: EN60950-1: 2001

-EMC requirements: EN301 489-1 V1.4.1 & EN301 489-3 V1.4.1

-Effective uses of radio spectrum: EN300 330-2 V1.1.1

Supplementary information:

* CE mark	C€
* Member states intended for use	EU and EFTA

Date:

June 21, 2005

Signature:

Tomoki Katayama/

1-3. Opening, closing and locking the doors

Hereby, Toyota Motor Corporation, declares that this TMLF-3 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Toyota Motor Corporation vakuuttaa täten että TMLF-3 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Toyota Motor Corporation dat het toestel TMLF-3 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Toyota Motor Corporation déclare que l'appareil TMLF-3 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Toyota Motor Corporation att denna TMLF-3 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede Toyota Motor Corporation erklærer herved, at følgende udstyr TMLF-3 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Toyota Motor Corporation, dass sich das Gerät TMLF-3 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ME THN ΠΑΡΟΥΣΑ Toyota Motor Corporation ΔΗΛΩΝΕΙ ΟΤΙ TMLF-3 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Con la presente Toyota Motor Corporation dichiara che questo TMLF-3 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Toyota Motor Corporation declara que el TMLF-3 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Toyota Motor Corporation declara que este TMLF-3 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Toyota Motor Corporation, jiddikjara li dan TMLF-3 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Toyota Motor Corporation seadme TMLF-3 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Toyota Motor Corporation nyilatkozom, hogy a TMLF-3 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Toyota Motor Corporation týmto vyhlasuje, že TMLF-3 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Toyota Motor Corporation tímto prohlašuje, že tento TMLF-3 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Toyota Motor Corporation izjavlja, da je ta TMLF-3 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

1-3. Opening, closing and locking the doors

Šiuo Toyota Motor Corporation deklaruoja, kad šis TMLF-3 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Toyota Motor Corporation deklarē, ka TMLF-3 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Toyota Motor Corporation oświadcza, że TMLF-3 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Toyota Motor Corporation yfir því að TMLF-3 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Toyota Motor Corporation erklærer herved at utstyret TMLF-3 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Ovim, Toyota Motor Corporation, izjavljuje da ovaj TMLF-3 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

Hereby, Tokai Rika Co., Ltd., declares that this B90EA is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B90EA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

TOKAI RIKA

R&TTE Declaration of Conformity

We,

Manufacturer's Name: Tokai Rika Co., Ltd.

Manufacturer's Address: 260, Toyota 3-chome, Oguchi-cho, Niwa-gun, Aichi-ken,

480-0195, Japan

hereby declare under our sole responsibility that the product:

Product Name: Electronic Key
Product Model: B90EA

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

Safety:

EN60950-1

EMC: EN301 489-1 & -3

Spectrum:

EN300 220-2, EN300 330-2

Supplementary information:

* CE mark	CE
* Member states intended for use	EU and EFTA
* Member states with restrictive use	None

Date:

10 February 2009

Signature:

Yoshinobu Yokoyama General Manager,

Position of the signatory:

Security Electronic Engineering Div.

yorkinde Apologana

1-3. Opening, closing and locking the doors

Hereby, Tokai Rika Co., Ltd., declares that this B51UA is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Ovim, Tokai Rika Co., Ltd., izjavljuje da ovaj B51UA je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

ΤΟΚΔΙ ΡΙΚΔ

R&TTE Declaration of Conformity

We,

Manufacturer's Name: Tokai Rika Co., Ltd.

Manufacturer's Address: 260, Toyota 3-chome, Oguchi-cho, Niwa-gun, Aichi-ken,

480-0195, Japan

hereby declare under our sole responsibility that the product:

Product Name: Tuner
Product Model: B51UA

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

Safety: EN60950-1
EMC: EN301 489-1 & -3
Spectrum: EN300 220-3

Supplementary information:

* CE mark	CE
* Member states intended for use	EU and EFTA
* Member states with restrictive use	None

<u>Date</u>: 22 February 2005

Signature: Tadashi Wakiya

Position of the signatory: General Manager, Electronics Engineering Div.

A CAUTION


Caution regarding interference with electronic devices

- People with implanted pacemakers or cardiac defibrillators should maintain a reasonable distance between themselves and the push button start antennas. (→P. 60)
 - The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for details, such as the frequency of radio waves and timing of emitting the radio waves. Then, consult your doctor to see if you should disable the entry function.
- User of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves.
 - Radio waves could have unexpected effects on the operation of such medical devices.

Ask any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for details for disabling the entry function.

1-3. Opening, closing and locking the doors Wireless remote control

The wireless remote control can be used to lock and unlock the vehicle from outside the vehicle.



- 1 Locks all doors
- 2 Unlocks all doors

■ Operation signals

The emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: Once; Unlocked: Twice)

■ Door lock buzzer

If a door is not fully closed, a buzzer sounds continuously if an attempt to lock the door is made. Fully close the door to stop the buzzer, and lock the vehicle once more.

■ Key battery depletion

→P. 49, 62

■ Security feature

If a door is not opened within approximately 30 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

■ When the key battery is fully depleted

→P. 397

■ Conditions affecting operation

→P. 48, 61

Settings (e.g. wireless remote control system) can be changed. (Customizable features \rightarrow P. 506)

Before driving

1-3. Opening, closing and locking the doors


Side doors

The vehicle can be locked and unlocked using the entry function, wireless remote control, key or door lock switch.

- Entry function (vehicles with a smart entry & start system)
 - →P. 44
- Wireless remote control
 - →P. 70
- Key


The doors can also be locked and unlocked with the mechanical key. (\rightarrow P. 474)

■ Door lock switch



- Unlocks all doors
- 2 Locks all doors

■ Inside lock button



- 1 Locks the door
- 2 Unlocks the door

The driver's door can be opened by pulling the inside handle even if the lock button is in the lock position.

Locking the front doors from the outside without a key


STEP 1 Move the inside lock button to the lock position.

STEP 2 Close the door while pulling the door handle.

The door cannot be locked if the "POWER" switch is in ACCESSORY or ON mode, or the electronic key is left inside the vehicle.

Depending on the position of the electronic key, the key may not be detected correctly and the door may be locked.

Rear door child-protector lock



The door cannot be opened from inside the vehicle when the locks are set.

- 1 Unlock
- 2 Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.

To prevent an accident

Observe the following precautions while driving the vehicle.

Failing to do so may result in a door opening and an occupant falling out, resulting in death or serious injury.

- Always use a seat belt.
- Ensure that all doors are properly closed.
- Do not pull the inside handle of the doors while driving. The doors may be opened and the passengers are thrown out of the vehicle and it may result in serious injury or death.
 - Be especially careful for the driver's door, as the door may be opened even if the inside lock button is in locked position.
- Set the rear door child protector locks when children are seated in the rear seats.


1

1-3. Opening, closing and locking the doors

Back door

The back door can be locked/unlocked and opened by the following procedures.

- Locking and unlocking the back door
- ► Entry function (vehicles with a smart entry & start system)
- →P. 44
- ▶ Door lock switch
- →P. 72
- ▶ Wireless remote control
- →P. 70
- Opening the back door



- 1 Push up
- 2 Raise

1-3. Opening, closing and locking the doors


■ When closing the back door



Lower the back door using the back door handle, and make sure to push the back door down from the outside to close it.

■ If the back door opener is inoperative

The back door can be operated from the inside.



Remove the cover.

To protect the cover, place a rag between the flathead screwdriver and the cover, as shown in the illustration.



Move the lever.

Caution while driving

- Keep the back door closed while driving.
 If the back door is left open, it may hit near-by objects while driving or luggage may be unexpectedly thrown out, causing an accident.
 In addition, exhaust gases may enter the vehicle, causing death or a serious health hazard. Make sure to close the back door before driving.
- Before driving the vehicle, make sure that the back door is fully closed. If the back door is not fully closed, it may open unexpectedly while driving, causing an accident.
- Never let anyone sit in the luggage compartment. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

When children are in the vehicle

Observe the following precautions.
Failure to do so may result in death or serious injury.

- Do not leave children alone in the luggage compartment.
 If a child is accidentally locked in the luggage compartment, they could have heat exhaustion.
- Do not allow a child to open or close the back door.
 Doing so may cause the back door to move unexpectedly, or cause the child's hands, head, or neck to be caught by the closing back door.

Operating the back door

Observe the following precautions.

Failure to do so may cause parts of the body to be caught, resulting in death or serious injury.

- Remove any heavy loads, such as snow and ice, from the back door before opening it. Failure to do so may cause the back door to fall closed again after it is opened.
- When opening or closing the back door, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the back door is about to open or close.
- Use caution when opening or closing the back door in windy weather as it may move abruptly in strong wind.





- The back door may fall if it is not opened fully. It is more difficult to open or close the back door on an incline than on a level surface, so beware of the back door unexpectedly opening or closing by itself. Make sure that the back door is fully open and secure before using the luggage compartment.
- When closing the back door, take extra care to prevent your fingers etc. from being caught.
- When closing the back door, make sure to press it lightly on its outer surface. If the back door handle is used to fully close the back door, it may result in hands or arms being caught.

- Do not pull on the back door damper stay to close the back door, and do not hang on the back door damper stay.
 - Doing so may cause hands to be caught or the back door damper stay to break, causing an accident.
- If a bicycle carrier or similar heavy object is attached to the back door, it
 may fall closed again after being opened, causing someone's hands, head
 or neck to be caught and injured. When installing an accessory part to the
 back door, using a genuine Toyota part is recommended.


↑ NOTICE

Back door damper stays

The back door is equipped with damper stays that hold the back door in place.

Observe the following precautions.

Failure to do so may cause damage to the back door damper stay, resulting in malfunction.



- Do not attach any foreign objects, such as stickers, plastic sheets, or adhesives to the damper stay rod.
- Do not touch the damper stay rod with gloves or other fabric items.
- Do not attach any accessories other than genuine Toyota parts to the back door.
- Do not place your hand on the damper stay or apply lateral forces to it.

1-4. Adjustable components (seats, mirrors, steering wheel) Front seats



- Seat position adjustment lever
- Seatback angle adjustment lever
- Vertical height adjustment lever*
 - *: Driver's seat only

A CAUTION

Seat adjustment

- Do not recline the seat more than necessary when the vehicle is in motion to reduce the risk of sliding under the lap belt.
 - If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
- After adjusting the seat, make sure that the seat is locked in position.

After returning the seat to the previous position


Try pushing the seat forward and backward to make sure it is secured in place.

1-4. Adjustable components (seats, mirrors, steering wheel)

Press the button to fold down the seatback.

1


Before driving



Rear seats


Folding down rear seatbacks

■ Before folding down rear seatbacks




Stow the rear center seat belt buckle.

■ Folding down rear seatbacks



Remove the seat belt from the guide.


In case you do not remove the seat belt from the guide, the seat belt might be locked when you fold down the rear seatbacks.



Fold the seatback down while pushing the seatback button.

Press the button down until the lock is completely released.

■ Returning rear seatbacks



Tilt the rear seatback up until it locks, making sure that you hold the seat belt to prevent it from getting caught between the seatback and the inner side of the vehicle.


Make sure the shoulder belt pass through the guide.

Seat adjustment

- Do not recline the seat more than necessary when the vehicle is in motion to reduce the risk of sliding under the lap belt. If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.
- Be careful not to catch your hand when reclining the seatback.

After returning the seatback to the upright position

Observe the following precautions. Failure to do so may result in death or serious injury.




 Make sure that the seatback is securely locked in position by lightly rocking it back and forth.

If the seatback is not securely locked, the red marking will be visible behind the seatback button. Make sure that the red marking is not visible.

• Check that the seat belts are not twisted or caught under the seat.

1-4. Adjustable components (seats, mirrors, steering wheel) **Head restraints**




1 Up

Pull the head restraints up.

2 Down


Push and hold the lock release button when lowering the head restraint.

■ Removing the head restraints



Pull the head restraint up while pushing the lock release button.

■ Adjusting the height of the head restraints



Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.

■ Adjusting the rear seat head restraints

Always raise the head restraint one level from the stowed position when in use.

Head restraint precautions


Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

1-4. Adjustable components (seats, mirrors, steering wheel) Seat belts


Make sure that all occupants are wearing their seat belts before driving the vehicle.

■ Correct use of the seat belts



- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.

■ Fastening and releasing the seat belt




- Fastening the belt

 Push the tab into the buckle until a clicking sound is heard.
- Releasing the belt

 Press the release button.


■ Adjusting the height of the belt (front seats)



- 1 Down
- 2 Up

Move the height adjuster up and down as needed until you hear a click.

Seat belt pretensioners (front seats)




The pretensioner helps the seat belt to quickly restrain the occupant by retracting the seat belt when the vehicle is subjected to certain types of severe frontal collision.

The pretensioner may not activate in the event of a minor frontal impact, a side impact or a rear impact.

■ Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

■ Pregnant women



Obtain medical advice and wear the seat belt in the proper way. $(\rightarrow P. 86)$

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants. Extend the shoulder belt completely over the shoulder and position the belt across the chest. Avoid belt contact over the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.

■ People suffering illness

Obtain medical advice and wear the seat belt in the proper way.

■ Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.

- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. $(\rightarrow P. 140)$
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions on P. 86 regarding seat belt usage.

Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

■ Seat belt regulations

If seat belt regulations exist in the country where you reside, please contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, for seat belt replacement or installation.



CAUTION

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.

Failing to do so may cause death or severe injury.

Wearing a seat belt

- Ensure that all passengers wear a seat belt.
- Always wear a seat belt properly.
- Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
- Toyota recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
- Do not recline the seat any more than necessary to achieve a proper seating position. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
- Do not wear the shoulder belt under your arm.
- Always wear your seat belt low and snug across your hips.

■ When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

Seat belt pretensioners


If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Seat belt damage and wear


- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an occupant from death or serious injury.
- Ensure that the belt and tab are locked and the belt is not twisted.
 If the seat belt does not function correctly, immediately contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional. Inappropriate handling of the pretensioner may prevent it from operating properly resulting in death or serious injury.

1-4. Adjustable components (seats, mirrors, steering wheel) **Steering wheel**

The steering wheel can be adjusted to a comfortable position.



Hold the steering wheel and press the lever down.



Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.

A CAUTION

Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

After adjusting the steering wheel


Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident and resulting in death or serious injury.

1-4. Adjustable components (seats, mirrors, steering wheel) Anti-glare inside rear view mirror

Glare from the headlights of vehicles behind can be reduced by using the following functions.

▶ Manual anti-glare inside rear view mirror



- Normal position
- 2 Anti-glare position

► Auto anti-glare inside rear view mirror

In automatic mode, sensors are used to detect the headlights of vehicles behind and automatically reduce the reflected light.




Turns automatic mode on/off

The indicator comes on when automatic mode is turned on.


The mirror will revert to the automatic mode each time the "POWER" switch is turned to ON mode.

Adjusting the height of rear view mirror (vehicles with an auto anti-glare inside rear view mirror)



Adjust the height of the rear view mirror by moving it up and down.

■ To prevent sensor error (vehicles with an auto anti-glare inside rear view mirror)



To ensure that the sensors operate properly, do not touch or cover them.

A CAUTION


Caution while driving

Do not adjust the position of the mirror while driving.

Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.


1-4. Adjustable components (seats, mirrors, steering wheel) Outside rear view mirrors

For some models, mirror angle can be adjusted using the switches.



Select a mirror to adjust.

- 1 Left
- 2 Right




Adjust the mirror.

- 1 Up
- 2 Right
- 3 Down
- 4 Left


Folding back the mirrors

► Manual operation



Push backward to fold the mirrors.

▶ Power operation



Press the switch to fold the mirrors.

Press it again to extend them to the original position.

- ■The outside rear view mirrors can be operated when
 - The "POWER" switch is in ACCESSORY or ON mode.
- When the mirrors are fogged up (vehicles with outside rear view mirror defoggers)

Turn on the mirror defoggers to defog the mirrors. (\rightarrow P. 251)

1-4. Adjustable components (seats, mirrors, steering wheel)

A CAUTION

When driving the vehicle

Observe the following precautions while driving.

Failing to do so may result in loss of control of the vehicle and cause an accident, resulting in death or serious injury.

- Do not adjust the mirrors while driving.
- Do not drive with the mirrors folded back.
- Both the driver and passenger side mirrors must be extended and properly adjusted before driving.

■ When a mirror is moving


To avoid personal injury and mirror malfunction, be careful not to get your hand caught by the moving mirror.

When the outside rear view mirror defoggers are operating (vehicles with outside rear view mirror defoggers)

Do not touch the rear view mirror surfaces, as they can become very hot and burn you.


1-5. Opening and closing the windows and moon roof **Power windows**

The power windows can be opened and closed using the following switches.



- Closing
- One-touch closing*
- 3 Opening
- One-touch opening*
- *: Pressing the switch in the opposite direction will stop window travel partway.

Lock switch



Press the switch down to lock the passenger window switches.

Use this switch to prevent children from accidentally opening or closing the passenger windows.

■ The power windows can be operated when

The "POWER" switch is in ON mode.

■ Operating the power window after turning the hybrid system off

The power window can be operated for approximately 45 seconds even after the "POWER" switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object becomes caught between the window and the window frame, window travel is stopped and the window is opened slightly.

■ When the power window does not close normally

If the jam protection function is operating abnormally and a window cannot be closed, perform the following operations using the power window switch on the relevant door.

- After stopping the vehicle, the window can be closed by holding the power window switch in the one-touch closing position while the "POWER" switch is turned to ON mode.
- If the window still cannot be closed even by carrying out the operation explained above, initialize the function by performing the following procedure.
- Hold the power window switch in the one-touch closing position.

 Continue holding the switch for a further 6 seconds after the window has closed.
- Continue holding the switch for a further 2 seconds after the window has opened completely.
- Hold the power window switch in the one-touch closing position once again. Continue holding the switch for a further 2 seconds after the window has closed.

If you release the switch while the window is moving, start again from the beginning.

If the window continues to close but then re-open slightly even after performing the above procedure correctly, have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Closing the windows

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- Do not allow children to operate the power windows.
 Closing a power window on someone can cause serious injury, and in some instances, even death.


Jam protection function

- Never try jamming any part of your body to activate the jam protection function intentionally.
- The jam protection function may not work if something gets caught just before the window fully closes.

1-5. Opening and closing the windows and moon roof **Moon roof***

Use the overhead switches to open, close, and tilt the moon roof up and down.

Opening and closing




1 Open

The moon roof stops slightly before the fully opened position to reduce wind noise. Push the switch again to fully open.

2 Close

Push the switch in either direction to stop the moon roof partway.

■ Tilt up and down



1 Tilt up

2 Tilt down

Push the switch in either direction to stop the moon roof partway.

*: If equipped

■ The moon roof can be operated when

The "POWER" switch is in ON mode.

■ Operating the moon roof after turning the hybrid system off

The moon roof can be operated for approximately 45 seconds even after the "POWER" switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

■ Jam protection function

If an object is detected between the moon roof and the frame while closing or tilting down, travel is stopped and the moon roof opens slightly.

■ Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

■ Moon roof open reminder function

An alarm will sound when the driver's door is opened with the moon roof not fully closed and the "POWER" switch off.

■ When the moon roof does not close normally

Perform the following procedure:

- If the moon roof closes but then re-opens slightly
- STEP 1 Stop the vehicle.
- The moon roof will close, reopen and pause for approximately 10 seconds.*² Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.
- Check to make sure that the moon roof is completely closed and then release the switch.
- If the moon roof tilts down but then tilts back up
- STEP 1 Stop the vehicle.
- Press and hold the "TILT UP" switch*1 until the moon roof moves into the tilt up position and stops.
- Release the "TILT UP" switch once and then press and hold the "TILT UP" switch again.*

 The moon roof will pause for approximately 10 seconds in the tilt up position.*

 Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.
- STEP 4 Check to make sure that the moon roof is completely closed and then release the switch.
- *1: If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
- *2: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the "TILT UP" switch, and the moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Opening the moon roof

Observe the following precautions.

Failing to do so may cause death or serious injury.

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

Closing the moon roof

Observe the following precautions.

Failing to do so may result in death or serious injury.

- Check to make sure that all passengers do not have any part of their bodies in a position where it could be caught when the moon roof is being operated.
- Do not allow children to operate the moon roof.
 Closing the moon roof on someone can cause death or serious injury.

Jam protection function

- Never try jamming any part of your body to activate the jam protection function intentionally.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.

1-6. Refueling


Opening the fuel tank cap

Perform the following steps to open the fuel tank cap.


■ Before refueling the vehicle

Turn the "POWER" switch off and ensure that all the doors and windows are closed.


■ Opening the fuel tank cap



Open the fuel filler door.




Turn the fuel tank cap slowly to open.



Hang the fuel tank cap on the back of the fuel filler door.

Closing the fuel tank cap



When replacing the fuel tank cap, turn it until a clicking sound is heard.

After releasing your hand, the cap will turn slightly in the opposite direction.

■ Fuel types

EU area:

Unleaded gasoline conforming to European standard EN228, Research Octane Number of 95 or higher

Except EU area:

Unleaded gasoline, Research Octane Number of 95 or higher

■ Use of ethanol blended gasoline in a gasoline engine

Toyota allows the use of ethanol blended gasoline where the ethanol content is up to 10%. Make sure that the ethanol blended gasoline to be used has a Research Octane Number that follows the above.

■ Fuel tank capacity

Approximately 45 L (11.9 gal., 9.9 lmp. gal.)



CAUTION

Refueling the vehicle

Observe the following precautions while refueling the vehicle.

Failure to do so may result in death or serious injury.

• Touch the vehicle or some other metal surface to discharge any static electricity.

Sparks resulting from discharging static electricity may cause the fuel vapors to ignite.

- Always hold the grips on the fuel tank cap and turn it slowly to remove it.
 A whooshing sound may be heard when the fuel tank cap is loosened.
 Wait until the sound cannot be heard before fully removing the cap.
 In hot weather, pressurized fuel may spray out of the filler neck and cause injury.
- Do not allow anyone that has not discharged static electricity from their bodies to come close to an open fuel tank.
- Do not inhale vaporized fuel.
 Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle.
 Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged.

This may cause static electricity to build up, resulting in a possible ignition hazard.

When replacing the fuel cap

Do not use anything but a genuine Toyota fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

↑ NOTICE

Refueling


Do not spill fuel during refueling.

Doing so may damage the vehicle, such as causing the exhaust systems to operate abnormally or damaging fuel system components or the vehicle's painted surface.

1-7. Theft deterrent system Immobilizer system

The vehicle's keys have built-in transponder chips that prevent the hybrid system from starting if the key has not been previously registered in the vehicle's on-board computer.

Never leave the keys inside the vehicle when you leave the vehicle.



The indicator light flashes after the "POWER" switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the "POWER" switch has been turned to ACCES-SORY or ON mode to indicate that the system has been canceled.

■ System maintenance

The vehicle has a maintenance-free type immobilizer system.

■ Conditions that may cause the system to malfunction

- If the key is in contact with a metallic object
- If the key is in close proximity to or touching a key to the security system (key with a built-in transponder chip) of another vehicle

■ Certification for the immobilizer system

Hereby, Toyota Motor Corporation, declares that this TMIMB-1 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

TOYOTA

TOYOTA MOTOR CORPORATION

1, TOYOTA-CHO, TOYOTA, AICHI, 471-8571(Head Office) or 471-8572(Research & Development Group) JAPAN TEL: (0565)28-2121

R&TTE Declaration of Conformity

We.

Manufacturer's Name: TOYOTA MOTOR CORPORATION

Manufacturer's Address: 1, Toyota-cho, Toyota, Aichi, 471-8572 Japan

hereby declare under our sole responsibility that the product:

Product Name: Immobilizer

Product Model: TMIMB-1

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is compliant with the following standards and/or other normative documents:

- Health & safety requirements: EN60950-1:2001

- EMC requirements: EN301 489-1 V1.4.1 & EN301 489-3 V1.4.1

- Effective use of radio spectrum: EN300 330-2 V1.1.1

Supplementary information:

* CE mark	C€
* Member states intended for use	EU and EFTA

Date: September 17, 2004

Signature: Managamae

Tomoaki Katayama

Hereby, Toyota Motor Corporation, declares that this TMIMB-1 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Toyota Motor Corporation vakuuttaa täten että TMIMB-1 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Hierbij verklaart Toyota Motor Corporation dat het toestel TMIMB-1 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Par la présente Toyota Motor Corporation déclare que l'appareil TMIMB-1 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Härmed intygar Toyota Motor Corporation att denna TMIMB-1 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Undertegnede Toyota Motor Corporation erklærer herved, at følgende udstyr TMIMB-1 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Toyota Motor Corporation, dass sich das Gerät TMIMB-1 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

ME THN ΠΑΡΟΥΣΑ Toyota Motor Corporation ΔΗΛΩΝΕΙ ΟΤΙ ΤΜΙΜΒ-1 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

1-7. Theft deterrent system

Con la presente Toyota Motor Corporation dichiara che questo TMIMB-1 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Por medio de la presente Toyota Motor Corporation declara que el TMIMB-1 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

Toyota Motor Corporation declara que este TMIMB-1 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Hawnhekk, Toyota Motor Corporation, jiddikjara li dan TMIMB-1 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Käesolevaga kinnitab Toyota Motor Corporation seadme TMIMB-1 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Alulírott, Toyota Motor Corporation nyilatkozom, hogy a TMIMB-1 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Toyota Motor Corporation týmto vyhlasuje, že TMIMB-1 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Toyota Motor Corporation tímto prohlašuje, že tento TMIMB-1 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Toyota Motor Corporation izjavlja, da je ta TMIMB-1 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Šiuo Toyota Motor Corporation deklaruoja, kad šis TMIMB-1 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Ar šo Toyota Motor Corporation deklarē, ka TMIMB-1 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Niniejszym Toyota Motor Corporation oświadcza, że TMIMB-1 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Hér með lýsir Toyota Motor Corporation yfir því að TMIMB-1 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Toyota Motor Corporation erklærer herved at utstyret TMIMB-1 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Ovim, Toyota Motor Corporation, izjavljuje da ovaj TMIMB-1 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

1-7. Theft deterrent system


⚠ NOTICE

■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

1-7. Theft deterrent system **Double locking system***

Unauthorized access to the vehicle is prevented by disabling the door unlocking function from both the interior and exterior of the vehicle.



Vehicles employing this system have labels on the window glass of both front doors.

Setting the double locking system

Turn the "POWER" switch off, have all the passengers exit the vehicle and ensure that all the doors are closed.

Using the entry function: Press the lock button on the outside door handle twice within 5 seconds.

Using the wireless remote control: Press twice within 5 seconds.

Canceling the double locking system

Using the entry function: Hold the outside door handle on the driver side.

Using the wireless remote control: Press $\ \mathbf{\Omega}$.

*: If equipped

1-7. Theft deterrent system

A CAUTION

■ Double locking system precaution

Never activate the double locking system when there are people in the vehicle, because all the doors cannot be opened from inside the vehicle.

1-7. Theft deterrent system Alarm*


The system sounds the alarm and flashes the lights when forcible entry is detected.

■ Triggering of the alarm

The alarm is triggered in the following situations when the alarm is set:

- A locked door is unlocked or opened in any way other than using the wireless remote control or entry function. The doors will lock again automatically.
- The hood is opened.
- The intrusion sensor detects something moving inside the vehicle. (An intruder gets in the vehicle.)
- The back door window is tapped or broken.
- The 12-volt battery is reconnected.

■ Setting the alarm system



Close the doors and hood, and lock all the doors using the entry function or wireless remote control. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.

*: If equipped

■ Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarm:

- Unlock the doors using the entry function or wireless remote control.
- Start the hybrid system. (The alarm will be deactivated or stopped after a few seconds.)


Intrusion sensor

The intrusion sensor detects an intruder or movement in the vehicle.

The intrusion sensor can be canceled using the cancel switch.

This system is designed to deter and prevent vehicle theft but does not guarantee absolute security against all intrusions.

■ Canceling the intrusion sensor



Turn the "POWER" switch off and press the intrusion sensor "OFF" switch.

A message will be shown on the multi-information display in the instrument cluster. Pressing the switch again will re-enable the intrusion sensor.

To set the alarm with the intrusion sensor disabled, the alarm must be set within 5 minutes after canceling the sensor.

■ System maintenance

The vehicle has a maintenance-free type alarm system.


■ Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following.

- Nobody is in the vehicle.
- The windows and moon roof (if equipped) are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.

■ Triggering of the alarm


The alarm may be triggered in the following situations. (Stopping the alarm deactivates the alarm system.)



 The doors are unlocked using the mechanical key.



 A person inside the vehicle opens a door or the hood.



 The 12-volt battery is recharged or replaced when the vehicle is locked.

■ Alarm-operated door lock

- When the alarm is operating, the doors are locked automatically to prevent intruders.
- Do not leave the key inside the vehicle when the alarm is operating, and make sure the key is not inside the vehicle when recharging or replacing the 12-volt battery.

■ Canceling and automatic re-enabling of the intrusion sensor


- The alarm will still be set even when the intrusion sensor is canceled.
- After the intrusion sensor is canceled, turning the "POWER" switch to ON mode or unlocking the doors using the wireless remote control door lock function will re-enable the intrusion sensor.
- The intrusion sensor will automatically be re-enabled if the alarm system is not set within 5 minutes after the intrusion sensor is canceled.
- The intrusion sensor will automatically be re-enabled when the alarm system is deactivated.
 (To cancel the intrusion sensor again, press the intrusion sensor "OFF" switch.)

■ Intrusion sensor considerations

The sensor may trigger the alarm in the following situations.




Persons or pets are in the vehicle.



 The vehicle is parked in a place where extreme vibrations or noises occur, such as in a parking garage.



 Ice or snow is removed from the vehicle, causing the vehicle to receive repeated impacts or vibrations.



 The wind or something similar causes an externally mounted reflectively coated windshield cover to move.

- Unstable items, such as dangling accessories or clothes hanging on the coat hooks, are in the vehicle.
- The windows or moon roof (if equipped) are open.
- The vehicle is inside an automatic or high-pressure car wash.
- The vehicle experiences impacts, such as hail, lightning strikes, or other kinds of repeated impacts or vibrations.

■ Certification for the alarm

FUJITSU TEN LIMITED Engineering Management Department Common Technology Group



2-28, Gosho-dori 1-chome, Hyogo-ku, Kobe, 652-8510, Japan Tel.: +81.78-682-2031 Fax.: +81.78-671-7160

DECLARATION of CONFORMITY

We, FUJITSU TEN LIMITED of the above address, hereby declare, at our sole responsibility, that the following product conforms to the Essential Requirements of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EC in accordance with the tests conducted to the appropriate requirements of the relevant standards, as listed herewith.

Product Name: Motion Sensor Model Number: FTL458 Reference Standards:

Radio: EN 300 440-1 V1.4.1(2008-05) EN 300 440-2 V1.2.1(2008-05) EMC: EN 301 489-1 V1.8.1(2008-04) EN 301 489-3 V1.4.1(2002-08) Safety: EN 60065 2002+Amd.11:2008

upplementary Information: CE Mark	C € 0891 ①		
Member states intend for use	EU and EFTA		
Member states with restrictive use	None		

Signature:

Position: Department General Manager

Engineering Management Department Common Technology Group

Date of issue: 23 September 2009 Place of issue: Kobe, Japan

No member states requires any restrictions of use for the equipment.

The latest "DECLARATION of CONFORMITY" (DoC) is available at the address stated in the DoC.

€08910

С настоящия документ FUJITSU TEN LIMITED декларира, че FTL458 е в съгласие с основните изисквания и съответните постановления на Директива 1999/5/FC.

FUJITSU TEN LIMITED tímto prohlašuje, že tento FTL458 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Undertegnede FUJITSU TEN LIMITED erklærer herved, at følgende udstyr FTL458 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt FUJITSU TEN LIMITED, dass sich das Gerät FTL458 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Käesolevaga kinnitab FUJITSU TEN LIMITED seadme FTL458 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Hereby, FUJITSU TEN LIMITED, declares that this FTL458 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Por medio de la presente FUJITSU TEN LIMITED declara que el FTL458 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

ME THN ΠΑΡΟΥΣΑ FUJITSU TEN LIMITED ΔΗΛΩΝΕΙ ΟΤΙ FTL458 ΣΥΜΜΟΡΦΩΝΕΤΑΙΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Par la présente FUJITSU TEN LIMITED déclare que l'appareil FTL458 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Con la presente FUJITSU TEN LIMITED dichiara che questo FTL458 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Ar šo FUJITSU TEN LIMITED deklarē, ka FTL458 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

1-7. Theft deterrent system

Šiuo FUJITSU TEN LIMITED deklaruoja, kad šis FTL458 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Hierbij verklaart FUJITSU TEN LIMITED dat het toestel FTL458 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Hawnhekk, FUJITSU TEN LIMITED, jiddikjara li dan FTL458 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Alulírott, FUJITSU TEN LIMITED nyilatkozom, hogy a FTL458 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Niniejszym FUJITSU TEN LIMITED oświadcza, że FTL458 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

FUJITSU TEN LIMITED declara que este FTL458 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Prin prezenta, FUJITSU TEN LIMITED declară că acest FTL458 este conform cu cerințele principale și cu celelalte prevederi relevante ale Directivei 1999/5/EC.

FUJITSU TEN LIMITED izjavlja, da je ta FTL458 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

FUJITSU TEN LIMITED týmto vyhlasuje, že FTL458 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

FUJITSU TEN LIMITED vakuuttaa täten että FTL458 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Härmed intygar FUJITSU TEN LIMITED att denna FTL458 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Hér með lýsir FUJITSU TEN LIMITED yfir því að FTL458 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

FUJITSU TEN LIMITED erklærer herved at utstyret FTL458 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

İşbu belge ile FUJITSU TEN LIMITED, bu FTL458 in 1995/5/EC Yönetmeliği esas gereksinimlerine ve diğer şartlarına uygun olduğunu beyan eder.

FUJITSU TEN LIMITED Engineering Management Department Common Technology Group

2-28, Gosho-dori 1-chome, Hyogo-ku, Kobe, 652-8510, Japan Tel.: +81.78-682-2031 Fax.: +81.78-671-7160



DECLARATION of CONFORMITY

We, FUJITSU TEN LIMITED of the above address, hereby declare, at our sole responsibility, that Telecommunications Terminal Equipment Directive 1999/5/EC in accordance with the tests conducted to the appropriate requirements of the relevant standards, as listed herewith.

Product Name: Model Number: **Motion Sensor** FTL313

Reference Standards:

Radio:

EN 300 440-1 V1.4.1(2008-05) V1.2.1(2008-05) EN 300 440-2

EMC: EN 301 489-1

V1.8.1(2008-04) EN 301 489-3 V1.4.1(2002-08)

Safety: EN 60065

2002+Amd.11:2008

Supplementary Information:

CE Mark

C€0891

Member states intend for use

EU and EFTA

Member states with restrictive use

The sensor installed to vehicles sold other than UK and Ireland

is not allowed to operate in UK

Signature:

Position:

Department General Manager Engineering Management Department Common Technology Group

23 September 2009

Date of issue: Place of issue: Kobe, Japan

The sensor installed to vehicles sold other than UK and Ireland is not allowed to operate in UK.

The latest "DECLARATION of CONFORMITY" (DoC) is available at the address stated in the DoC.

€08910

С настоящия документ FUJITSU TEN LIMITED декларира, че FTL313 е в съгласие с основните изисквания и съответните постановления на Директива 1999/5/EC.

FUJITSU TEN LIMITED tímto prohlašuje, že tento FTL313 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Undertegnede FUJITSU TEN LIMITED erklærer herved, at følgende udstyr FTL313 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt FUJITSU TEN LIMITED, dass sich das Gerät FTL313 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Käesolevaga kinnitab FUJITSU TEN LIMITED seadme FTL313 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Hereby, FUJITSU TEN LIMITED, declares that this FTL313 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Por medio de la presente FUJITSU TEN LIMITED declara que el FTL313 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

ME THN ΠΑΡΟΥΣΑ FUJITSU TEN LIMITED ΔΗΛΩΝΕΙ ΟΤΙ FTL313 ΣΥΜΜΟΡΦΩΝΕΤΑΙΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Par la présente FUJITSU TEN LIMITED déclare que l'appareil FTL313 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Con la presente FUJITSU TEN LIMITED dichiara che questo FTL313 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Ar šo FUJITSU TEN LIMITED deklarē, ka FTL313 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Šiuo FUJITSU TEN LIMITED deklaruoja, kad šis FTL313 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Hierbij verklaart FUJITSU TEN LIMITED dat het toestel FTL313 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Hawnhekk, FUJITSU TEN LIMITED, jiddikjara li dan FTL313 jikkonforma mal-ħtiģijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Alulírott, FUJITSU TEN LIMITED nyilatkozom, hogy a FTL313 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Niniejszym FUJITSU TEN LIMITED oświadcza, że FTL313 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

FUJITSU TEN LIMITED declara que este FTL313 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Prin prezenta, FUJITSU TEN LIMITED declară că acest FTL313 este conform cu cerințele principale și cu celelalte prevederi relevante ale Directivei 1999/5/EC.

FUJITSU TEN LIMITED izjavlja, da je ta FTL313 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

FUJITSU TEN LIMITED týmto vyhlasuje, že FTL313 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

FUJITSU TEN LIMITED vakuuttaa täten että FTL313 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

Härmed intygar FUJITSU TEN LIMITED att denna FTL313 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Hér með lýsir FUJITSU TEN LIMITED yfir því að FTL313 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

FUJITSU TEN LIMITED erklærer herved at utstyret FTL313 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

İşbu belge ile FUJITSU TEN LIMITED, bu FTL313 in 1995/5/EC Yönetmeliği esas gereksinimlerine ve diğer şartlarına uygun olduğunu beyan eder.

1-7. Theft deterrent system

1 1


NOTICE

■ To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

1-8. Safety information Correct driving posture

Drive in a good posture as follows:



- Sit upright and well back in the seat. (→P. 80)
- Adjust the position of the seat forward or backward to ensure the pedals can be reached and easily depressed to the extent required. (→P. 80)
- Adjust the seatback so that the controls are easily operable.
- Adjust the tilt and telescopic positions of the steering wheel downward so the airbag is facing your chest. (→P. 91)
- 5 Lock the head restraint in place with the center of the head restraint closest to the top of your ears. (→P. 84)
- Wear the seat belt correctly.(→P. 86)

While driving

- Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint, increasing the risk of death or serious injury to the driver or passenger.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident. The adjustment mechanism may also be damaged.


Adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury.

Fingers or hands may become jammed in the seat mechanism.

1-8. Safety information SRS airbags


The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.



- ► Front airbags
- Driver airbag/front passenger airbag

 Can help protect the head and chest of the driver and front passenger from impact with interior components.
- Driver's knee airbagCan help provide driver protection.
- ► Side and curtain shield airbags
- 3 Side airbags
 Can help protect the torso of the front seat occupants.
- Curtain shield airbags
 Can help protect primarily the head of outside occupants.

Airbag system components



- Driver's knee airbag
- 2 Airbag manual on-off switch
- 3 Front passenger airbag
- 4 Curtain shield airbags
- 5 Side airbags
- 6 Airbag manual on-off indicator
- Curtain shield airbag sensors

- 8 SRS warning light
- 9 Driver airbag
- Side and curtain shield airbag sensors
- Airbag sensor assembly
- 12 Front airbag sensors

The main SRS airbag system components are shown above. The SRS airbag system is controlled by the airbag sensor assembly. The airbag sensor assembly consists of a safing sensor and an airbag sensor.

In certain types of severe frontal or side impacts, the SRS airbag system triggers the airbag inflators. A chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

■ If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator)
 as well as the front seats, and parts of the front and rear pillars and roof
 side rail, may be hot for several minutes. The airbag itself may also be
 hot.
- The windshield may crack.

■ SRS airbag deployment conditions (front airbags)


- The SRS front airbags will deploy in the event of an impact that exceeds
 the set threshold level (the level of force corresponding to an approximately 20 30 km/h [12 18 mph] frontal collision with a fixed wall that
 does not move or deform).
- However, this threshold velocity will be considerably higher if the vehicle strikes an object, such as a parked vehicle or sign pole, which can move or deform on impact, or if the vehicle is involved in an underride collision (e.g. a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck, etc.).
- It is possible that in some collisions where the forward deceleration of the vehicle is very close to the designed threshold level, the SRS front airbags and the seat belt pretensioners may not activate together.

SRS airbag deployment conditions (side airbags and curtain shield airbags)

The SRS side airbags and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 1500 kg [3300 lb.] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 20 - 30 km/h [12 - 18 mph]).

■ Conditions under which the SRS airbags may deploy (inflate), other than a collision


The SRS front airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.



- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or vehicle falling

■ Types of collisions that may not deploy the SRS airbag (front airbags)


The SRS front airbags are generally not designed to inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.



- Collision from the side
- Collision from the rear
- Vehicle rollover


■ Types of collisions that may not deploy the SRS airbag (side airbags and curtain shield airbags)

The SRS side airbag and curtain shield airbag system may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.



- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle

The SRS side airbags and curtain shield airbags are not generally designed to inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.




- Collision from the front
- Collision from the rear
- Vehicle rollover


■ When to contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional

In the following cases, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.


Any of the SRS airbags have been inflated.




 The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS airbags to inflate.



 A portion of a door is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side airbags and curtain shield airbags to inflate.



 The pad section of the steering wheel or dashboard near the front passenger airbag cover or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.



- The surface of the seats with the side airbag is scratched, cracked or otherwise damaged.
- The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked or otherwise damaged.

SRS airbag precautions

Observe the following precautions regarding the airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly.
 - The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag.

Since the risk zone for the driver's airbag is the first 50 - 75 mm (2 - 3 in.) of inflation, placing yourself 250 mm (10 in.) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 250 mm (10 in.) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat.
 Although vehicle designs vary, many drivers can achieve the 250 mm (10 in.) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.
- If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

SRS airbag precautions

- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Toyota strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are the safest for infants and children. (\rightarrow P. 140)



Do not sit on the edge of the seat or lean against the dashboard.



- Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger.
- Do not drive the vehicle while the driver or passenger has items resting on their knees.


SRS airbag precautions



 Do not lean against the door, the roof side rail or the front, side and rear pillars.




 Do not allow anyone to kneel on the passenger seat toward the door or put their head or hands outside the vehicle.



 Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad or lower portion of the instrument panel.

These items can become projectiles when SRS driver, front passenger and driver's knee airbags deploy.

SRS airbag precautions



Do not attach anything to areas such as the door, windshield glass, side door glass, front and rear pillars, roof side rail or assist grip. (Except for the speed limit label →P. 462)

- If a vinyl cover is put on the area where the SRS driver's knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags.
- Do not strike or apply significant levels of force to the area of the SRS airbag components shown on P. 130. Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbag has deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.

SRS airbag precautions

If the areas where the SRS airbags are stored, such as the steering wheel
pad and front and rear pillar garnishes, are damaged or cracked, have
them replaced by any authorized Toyota dealer or repairer, or another duly
qualified and equipped professional.

Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags.
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rail.
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment.
- Installation of snow plows, winches, etc. to the front grille (bull bars, kangaroo bar etc.).
- Modifications to the vehicle's suspension system.
- Installation of electronic devices such as a two-way mobile radio, RF-transmitter or CD players.

1-8. Safety information Child restraint systems

Toyota strongly urges the use of child restraint systems.

Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one to the front passenger seat.

- Choose a child restraint system appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual. $(\rightarrow P. 149)$

 Toyota recommends that you use a child restraint system which conforms to the regulation "ECE No.44".

Types of child restraints

Child restraint systems are classified into the following 5 groups according to the regulation "ECE No.44".

Group 0: Up to 10 kg (22 lb.) (0 - 9 months)

Group 0⁺: Up to 13 kg (28 lb.) (0 - 2 years)


Group I: 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)

Group II: 15 to 25 kg (34 to 55 lb.) (4 years - 7 years)

Group III: 22 to 36 kg (49 to 79 lb.) (6 years - 12 years)

In this owner's manual, the following popular 3 types of child restraint systems that can be secured with the seat belts are explained.

▶ Baby seat



Equal to Group 0 and 0⁺ of "ECE No.44"

► Child seat



Equal to Group 0⁺ and I of "ECE No.44"

▶ Junior seat



Equal to Group II and III of "ECE No.44"

Child restraint system suitability for various seating positions

Provided information in the table shows your child restraint system suitability for various seating positions.

Seating position	Front passenger seat		Rear seat	
	Airbag manual on-off switch			
Mass groups	ON	OFF	Outside	Center
0 Up to 10 kg (22 lb.) (0 - 9 months)	X Never put	U	U	U
0 ⁺ Up to 13 kg (28 lb.) (0 - 2 years)	X Never put	U	U	U
I 9 to 18 kg (20 to 39 lb.) (9 months - 4 years)	Front facing — UF	U	U	U
	Rear facing — X Never put			
II, III 15 to 36 kg (34 to 79 lb.) (4 - 12 years)	UF	U	U	U

Key of letters inserted in the above table:

- U: Suitable for "universal" category child restraint system approved for the use in this mass group.
- UF: Suitable for forward-facing "universal" category child restraint system approved for the use in this mass group.
- X: Not suitable seat position for children in this mass group.

Other child restraint systems different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer and retailer.

Child restraint system suitability for various seating positions (with ISOFIX rigid anchor)

Provided information in the table shows your child restraint system suitability for various seating positions.

Mass groups	Size class	Fixture	Vehicle ISOFIX positions	
			Rear outside	
Carrycot	F	ISO/L1	X	
	G	ISO/L2	X	
		(1)	Х	
Group 0 Up to 10 kg (22 lb.)	E	ISO/R1	Х	
		(1)	Х	
	E	ISO/R1	X	
Group 0 ⁺	D	ISO/R2	X	
Up to 13 kg (28 lb.)	С	ISO/R3	X	
		(1)	X	
Group I 9 to 18 kg (20 to 39 lb.)	D	ISO/R2	X	
	С	ISO/R3	X	
	В	ISO/F2	IUF	
	B1	ISO/F2X	IUF	
	Α	ISO/F3	IUF	
		(1)	X	
Group II 15 to 25 kg (34 to 55 lb.)		(1)	Х	
Group III 22 to 36 kg (49 to 79 lb.)		(1)	Х	

(1) For the CRS which do not carry the ISO/XX size class identification (A to G), for the applicable mass group, the car manufacturer shall indicate the vehicle specific ISOFIX child restraint system(s) recommended for each position

Key letters inserted in the above table:

- IUF: Suitable for ISOFIX forward-facing child restraints systems of universal category approved for use in this mass group
- X: ISOFIX position not suitable for ISOFIX child restraint systems in this mass group and/or this size class.

Other child restraint systems different from the systems mentioned in the table can be used, but the suitability of the systems must be carefully checked with the child restraint system manufacturer and retailer.

■When installing the child restraint system on the front passenger seat



When you have to use a child restraint system in the front passenger seat, adjust the seatback to the most upright position.

■ Selecting an appropriate child restraint system

Get an appropriate child restraint system for the child. If a child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. $(\rightarrow P. 86)$

A CAUTION

Using a child restraint system

The use of a child restraint system not suitable for the vehicle may not properly secure the infant or child, resulting in serious injury or even death.

Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child
 must be properly restrained, using a seat belt or child restraint system
 depending on the age and size of the child. Holding a child in your arms is
 not a substitute for a child restraint system. In an accident, the child can be
 crushed against the windshield, or between you and the vehicle's interior.
- Toyota strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.

Child restraint precautions

- Never use a rear-facing child restraint system on the front passenger seat when the airbag manual on-off switch is "ON". (→P. 160) In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat when the airbag manual on-off switch is "ON".
- A forward-facing child restraint system should be allowed to be installed on the front passenger seat only when it is unavoidable. Always move the seat as far back as possible, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front and rear pillars or roof side rail from which the side airbags or curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or an accident.

When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death.

If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

■ When the child restraint system is not in use

- Keep the child restraint system properly secured on the seat even if it is not in use.
 - Do not store the restraint unsecured in the passenger compartment.
- If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the luggage compartment. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or accident.

1-8. Safety information Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the rear seats using a seat belt or a ISOFIX rigid anchor. Attach the top strap when installing a child restraint.




Seat belts (An ELR belt requires a locking clip.)



ISOFIX rigid anchors (ISOFIX child restraint system)

These exclusive fixing bars are provided for the outside rear seats. (Tags displaying the location of the anchorages are attached to the seats.)




Anchor brackets (for top strap)

Anchor brackets are provided for the outside rear seats.


Installing child restraints using a seat belt

■ Rear facing — Baby seat/child seat




Fold the seatback while pressing the seatback button. Return the seatback and secure it at the first lock position.


(→P. 83)



Place the child restraint system on the rear seat facing the rear of the vehicle.




Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted. Keep the lap portion of the belt tight.




Install a locking clip near the tab of the lap and shoulder belt by inserting the lap and shoulder webbing through the recesses of the locking clip.

■ Forward facing — Child seat




Fold the seatback while pressing the seatback button. Return the seatback and secure it at the first lock position.

(→P. 83)




Place the child restraint system on the seat facing the front of the vehicle.




Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted. Keep the lap portion of the belt tight.

1-8. Safety information




Install a locking clip near the tab of the lap and shoulder belt by inserting the lap and shoulder webbing through the recesses of the locking clip.

■ Junior seat



Fold the seatback while pressing the seatback button. Return the seatback and secure it at the first lock position.

(→P. 83)




Place the child restraint system on the seat facing the front of the vehicle.



Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.

Check that the shoulder belt is correctly positioned over the child's shoulder, and that the lap belt is as low as possible. $(\rightarrow P. 86)$


Installation with ISOFIX rigid anchor (ISOFIX child restraint system)



Fold the seatback while pressing the seatback button. Return the seatback and secure it at the first lock position.

(→P. 83)

1-8. Safety information




Check the positions of the exclusive fixing bars, and install the child restraint system to the seat.


The bars are installed in the clearance between the seat cushion and seatback.

If the child restraint has a top strap, the top strap should be latched onto the anchorages.

Child restraint systems with a top strap




Secure the child restraint using a seat belt or ISOFIX rigid anchors, and remove the head restraint.



Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top strap.

Make sure the top strap is securely latched.



Replace the head restraint.

■ When installing a child restraint system

You need a locking clip to install the child restraint system. Follow the instructions provided by the manufacturer of the system. If your child restraint system does not provide a locking clip, you can purchase the following item from any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Locking clip for child restraint system (Part No. 73119-22010)

When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of sudden braking, sudden swerving or an accident.




- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the righthand rear seat (left-hand drive vehicles) or the left-hand rear seat (right-hand drive vehicles).
- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- When installing a forward facing or junior child seat on the front passenger seat, move the seat as far back as possible.

Failing to do so may result in death or serious injury if the airbags deploy (inflate).



When installing a child restraint system





 Never install a rear-facing child restraint system on the front passenger seat when the airbag manual on-off switch is "ON". (→P. 160)

The force of the rapid inflation of the front passenger airbag can cause death or serious injury to children in the event of an accident.

There is a label on both sides of the passenger side sun visor, indicating it is forbidden to attach a rear-facing child restraint system to the front passenger seat.

Details of the label on the passenger side sun visor are shown in the illustrations below. The label includes information written in the language of your country.



CAUTION

When installing a child restraint system

► Type A

WARNING

VAROITUS AVISO ΠΡΟΣΟΧΗ **ADVARSEL**

© DO NOT place a rear facing child seat on the front seat unless the passenger Bairbag is deactivated. DEATH OR SERIOUS INJURY can occur. See owner's manual.

Placer ALDRIG et bagudvendt barnesæde på forsædet, uden at passagersædets placer frakoblet. Risiko for DØD ELLER ALVORLIG PERSONSKADE.



ÄLÄ aseta etuistuimelle selkä menosuuntaan asennettavaa lasten turvaistuinta silloin, kun matkustajan turvatyynyä ei ole kytketty pois toiminnasta. Seurauksena voi olla KUOLEMA TAI VAKAVA LOUKKAANTUMINEN. Katso lisäohjeet omistajan käsikirjasta.

NÃO instale uma cadeirinha para crianças voltada para trás no banco da frente sem plasactivar o airbag do passageiro. Risco de MORTE OU FERIMENTOS GRAVES. Consulte o manual do proprietário.

ΜΗΝ τοποθετείτε παιδικό κάθισμα οπίσθιου προσανατολισμού στο μπροστινό κάθισμα, Βημην Ιστισσείτε Ιστοίου Αυσισμό το Πιστοίου Προστατιστού Ενδέχεται να προκληθεί ΘΕΚΤΌς αν είναι απενεγρότισημένος ο αερόσακος συνοδηγού. Ενδέχεται να προκληθεί ΘΑΝΑΤΟΣ ή ΣΟΒΑΡΟΣ ΤΡΑΥΜΑΤΙΣΜΟΣ. Συμβουλευτείτε το βιβλίο οδηγιών χρήσης.

DU FÅR ALDRIG placera en bakátvänd barnstol i framsätet, om inte passagerar krockkudden är avaktiverad. DÖDSFALL ELLER ALLVARLIGA PERSONSKADOR kan inträffa. Se instruktionsbok.

▶ Type B

⚠ WARNING AVERTISSEMENT WARNUNG AVVISO ADVERTENCIA WAARSCHUWING

(a) DO NOT place a rear facing child seat on the front seat unless the passenger B airbag is deactivated. DEATH OR SERIOUS INJURY can occur. See owner's manual. NE JAMAIS placer un siège enfant positionné dos à la route sur le siège avant sauf si l'airbag passager est désactivé. Risque de MORT OU BLESSURE GRAVE. Voir le manuel du propriétaire.



KEINEN rückwärtsgerichteten Kindersitz auf dem Vordersitz verwenden, außer der DBeifahrer-Airbag ist deaktiviert. TOD ODER SCHWERE VERLETZUNGEN können die Folge sein. Siehe Betriebsanleitung.

NON posizionare il seggiolino per bambini rivolto in senso opposto a quello di marcia l sul sedile anteriore se l'airbag del passeggero non e'stato disattivato. Rischio di MORTE O LESIONI GRAVI. Consultare il manuale di uso e manutenzione.

NO coloque una silla para niños en sentido contrario al de la marcha del vehículo en el asiento del acompañante, excepto si el airbag del pasajero estuviera desactivado. Riesgo de MUERTE O HERIDAS GRAVES. Consulte el manual del propietario.

GEEN tegen de rijrichting in geplaatst kinderzitje op de voorstoel plaatsen, tenzij de passagiersairbag gedeactiveerd is. DOOD OF ZWARE VERWONDINGEN kunnen het gevolg zijn. Zie instruktieboekje.

■ When installing a child restraint system

- When a junior seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and tab are securely locked and the seat belt is not twisted.
- Push and pull the child seat in different directions to be sure it is secure.
- Follow all installation instructions provided by the child restraint system manufacturer.


To correctly attach a child restraint system to the anchorages

When using the lower anchorages, be sure that there are no foreign objects around the anchorages and that the seat belt is not caught behind the child restraint. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or accident.

1-8. Safety information Airbag manual on-off system


This system deactivates the front passenger airbag.

Only deactivate the airbags when using a child restraint system on the front passenger seat.




"PASSENGER AIRBAG" indicator

This indicator turns on when the airbag system is on. (Only when the "POWER" switch is in ON mode.)



2 Airbag manual on-off switch

Deactivating the front passenger airbag



Insert the key into the cylinder and rotate to the "OFF" position.

The "OFF" indicator turns on. (Only when the "POWER" switch is in ON mode.)

■ Airbag manual on-off indicator information

If any of the following problems occurs, it is possible that there is a malfunction in the system. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

- Neither "ON" nor "OFF" comes on.
- The indicator does not change when the airbag manual on-off switch is switched to the "ON" or "OFF" position.

A CAUTION

When installing a child restraint system

For safety reasons, always install the child restraint system in a rear seat. In the event that the rear seat cannot be used, the front seat can be used as long as the airbag manual on-off system is set to "OFF".

If the airbag manual on-off system is left "ON", the strong impact of the airbag deployment (inflation) may cause serious injury or even death.

When a child restraint system is not installed on the front passenger seat

Ensure that the airbag manual on-off system is set to "ON".

If it is left "OFF", the airbag may not deploy in the event of an accident, which may result in serious injury or even death.

1-8. Safety information

162

UK_AURIS_HV_EE

2 When driving 2-1. Driving procedures 2-4. Using other driving systems Driving the vehicle 164 Cruise control...... 219 Power (ignition) switch..... 175 Toyota parking EV-Drive Mode 180 assist-sensor 223 Transmission 183 Driving assist systems 228 Turn signal lever 190 Hill-start assist control...... 232 Parking brake 191 2-5. Driving information Cargo and luggage 234 2-2. Instrument cluster Winter driving tips 236 Gauges and meters 193 Trailer towing 240 Indicators and warning lights 197 Multi-information display 200 2-3. Operating the lights and wipers

washer...... 212

washer..... 217

switch 218

Windshield wipers and

Rear window wiper and

Headlight cleaner

2-1. Driving procedures **Driving the vehicle**

The following procedures should be observed to ensure safe driving.

Starting the hybrid system

→P. 175

Driving

STEP 1 With the brake pedal depressed, select the D position.

(→P. 183)

STEP 2 Release the parking brake.

(→P. 191)

Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

Stopping

STEP 1 With the shift position in D, depress the brake pedal.

STEP 2 If necessary, set the parking brake.

When the vehicle is stopped for an extended period of time, push the P position switch. $(\rightarrow P. 185)$

■ Parking the vehicle

STEP 1 With the shift position in D, depress the brake pedal.

STEP 2 Set the parking brake.

(→P. 191)

STEP 3 Push the P position switch.

(→P. 185)

Check that the shift position indicator shows P.

- STEP 4 Turn the "POWER" switch off to stop the hybrid system.
- STEP 5 Slowly release the brake pedal and check that the indicator on the "POWER" switch is off.
- STEP 6 Lock the door, making sure that you have the key on your person.

When parking on a hill, if necessary, block the wheels.

Starting on a steep uphill

STEP 1 Firmly set the parking brake and then select the D position.

STEP 2 Gently depress the accelerator pedal.

STEP 3 Release the parking brake.

■ Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

■ Breaking in your new Toyota

To extend the life of the vehicle, the following precautions are recommended to observe:

- For the first 300 km (200 miles): Avoid sudden stops.
- For the first 2000 km (1200 miles):
 - Do not drive at extremely high speeds.
 - · Avoid sudden acceleration.
 - Do not drive at a constant speed for extended periods.

■ Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. $(\rightarrow P. 494)$

■ For efficient use

- Select the D position when driving.
 In the N position, the gasoline engine operates but electricity cannot be generated.
 - The hybrid battery (traction battery) will be discharged requiring unnecessary engine power to recharge.
- Drive your vehicle smoothly.
 Avoid abrupt acceleration and deceleration. Gradual acceleration and deceleration will make more effective use of the traction motor without having to use gasoline engine power.
- Avoid repeated acceleration.
 Repeated acceleration consumes hybrid battery (traction battery) power, resulting in poor acceleration. Battery power can be restored by driving with the accelerator pedal slightly released.
- Push the P position switch when parking. In the N position, the hybrid battery (traction battery) does not recharge. Leaving the N position selected for an extended period of the time may discharge the hybrid battery. The vehicle cannot run if the hybrid battery is discharged.

■ Eco-friendly driving

Eco-friendly driving can be achieved by driving with Hybrid System Indicator. $(\rightarrow P. 195)$

■ Brake actuator

The brake actuator uses brake fluid pressurized by the pump to power-assist the brakes. If the brake actuator fails during driving, the brake system warning light comes on and the buzzer sounds intermittently. In this case, the brakes may not work properly. If they do not work well, depress the brake pedal firmly. If the brake system warning light comes on, immediately stop your vehicle and contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

In the following conditions, you may hear a sound in the engine compartment. This is not a malfunction.

- The driver's door is opened with the hybrid system turned off.
- The brake pedal is depressed with the hybrid system turned off.
- After the hybrid system is turned on.
- The brake pedal is depressed repeatedly with the hybrid system turned on.
- After the hybrid system is turned off.

The brake pedal may be hard to depress or the brake pedal stroke may be short before turning the hybrid system on. This is not a malfunction.

■ When braking the vehicle

When applying brakes, you may hear a sound coming from the motor generator.

However, this does not indicate any trouble.

CAUTION

When starting the vehicle

Always keep your foot on the brake pedal while stopped with the hybrid system operating. This prevents the vehicle from creeping.

When driving the vehicle

- Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.
 - · Accidentally depressing the accelerator pedal instead of the brake pedal will result in sudden acceleration that may lead to an accident that could result in death or serious injury.
 - When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
 - · Make sure to keep a correct driving posture even when moving the vehicle only slightly, allowing you to depress the brake and accelerator pedals properly.
 - Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- The driver should pay attention to pedestrians when the vehicle is powered only by the electric motor (traction motor). Because there is no hybrid system sounds, the pedestrians may misjudge the vehicle's movement.
- Do not drive the vehicle over or stop the vehicle near flammable materials. The exhaust system and exhaust gases can be extremely hot. This may cause a fire if there is any flammable material nearby.
- Do not let the vehicle roll backwards while a forward driving position is selected, or roll forward while R is selected.
 - Doing so may cause the hybrid system not to operate or lead to poor brake and steering performance, resulting in an accident or damage to the vehicle.

- If the smell of exhaust is noticed inside the vehicle, open the windows and check that the back door is closed. Large amounts of exhaust in the vehicle can cause driver drowsiness and an accident, resulting in death or a serious health hazard. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, immediately.
- Do not shift the shift position to P while the vehicle is moving.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift position to R while the vehicle is moving forward.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Do not shift the shift position to D while the vehicle is moving backward.
 Doing so can damage the transmission and may result in a loss of vehicle control.
- Moving the shift position to N while the vehicle is moving will disengage the hybrid system. Engine braking is not available with the hybrid system disengaged.
- During normal driving, do not turn off the hybrid system. Turning the hybrid system off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.
 - However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way: \rightarrow P. 488
- To help maintain a safe speed when driving down a steep hill, apply engine braking (use the B position for engine braking).
 Using the brakes continuously may cause the brakes to overheat and lose effectiveness. (→P. 183)
- When stopped on an inclined surface, use the brake pedal and parking brake to prevent the vehicle from rolling backward or forward and causing an accident.
- Do not use the accelerator pedal or depress the accelerator and brake pedals together to hold the vehicle on a hill.

- Do not adjust the display, the position of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.
 Doing so may result in a loss of vehicle control that can cause accidents that may result in death or serious injury.
- Always check that all passengers' arms, heads or other parts of their bodies are not outside the vehicle, as this may result in death or serious injury.

When driving on slippery road surfaces

- Sudden braking, acceleration and steering may cause tire slippage and reduce your ability to control the vehicle, resulting in an accident.
- Abrupt changes from shift position D to B and rapid changes in the engine speed could cause the vehicle to skid, resulting in an accident.
- After driving through a puddle, lightly depress the brake pedal to make sure that the brakes are functioning properly. Wet brake pads may prevent the brakes from functioning properly. If the brakes on only one side are wet and not functioning properly, steering control may be affected, resulting in an accident.

When changing the shift position

Be careful not to change the shift position with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

After the shift lever is operated, make sure to check the current shift position using the shift position indicator. (\rightarrow P. 193)

When the vehicle is stopped

- Do not race the hybrid system.
 If the vehicle is in any shift position other than P or N, the vehicle may accelerate suddenly and unexpectedly, and may cause an accident.
- Do not leave the vehicle with the hybrid system on for a long time.
 If such a situation cannot be avoided, park the vehicle in an open space and check that exhaust fumes do not enter the vehicle interior.
- Always keep a foot on the brake pedal while the hybrid system is operating to prevent an accident caused by the vehicle moving.

When the vehicle is parked

- Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.
 - Doing so may result in the following.
 - Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
 - The temperature inside the vehicle may cause the plastic lenses and plastic material of eye glasses to deform or crack.
 - Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
- Always apply the parking brake, push the P position switch, turn the hybrid system off and lock the vehicle.
 - Do not leave the vehicle unattended while the hybrid system is operating.
- Do not touch the exhaust pipe while the hybrid system is operating or immediately after turning the hybrid system off.
 Doing so may cause burns.
- Do not leave the hybrid system operating in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the hybrid system is operating, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.

When parking the vehicle

Be sure to firmly apply the parking brake and push the P position switch. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly, resulting in an accident if the accelerator pedal is accidentally depressed.

CAUTION

Exhaust gases

Exhaust gases include harmful carbon monoxide (CO) that is colorless and odorless. Inhaling exhaust gases may lead to death or a serious health hazard.

- If the vehicle is in a poorly ventilated area, stop the hybrid system. In a closed area, such as a garage, exhaust gases may collect and enter the vehicle. This may lead to death or a serious health hazard.
- The exhaust should be checked occasionally. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional. Failure to do so may allow exhaust gases to enter the vehicle, resulting in death or a serious health hazard.

When taking a nap in the vehicle

Always turn the hybrid system off. Otherwise, you may accidentally move the shift lever or depress the accelerator pedal, which could cause an accident or fire due to hybrid system overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard.

When braking the vehicle

- When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and may cause one side of the vehicle to brake differently than the other side. Also the parking brake may not securely hold the vehicle.
- If the power brake assist function does not operate, do not follow other vehicles closely and avoid downhill or sharp turns that require braking. In this case, braking is still possible, but it will require more force on the pedal than usual. Braking distance may also increase.
- The brake system consists of 2 individual hydraulic systems: If one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and braking distance becomes longer.
 - If this happens, do not continue to drive the vehicle. Have your brakes fixed immediately.

↑ NOTICE

When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time during driving. If the brake pedal is depressed while driving with the accelerator pedal depressed, driving torque may be restrained.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for a long time.
 - Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

If you hear a squealing or scraping noise (brake pad wear indicators)

Have the brake pads checked and replaced by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.

The rotor damage can result if the pads are not replaced when needed.

It is dangerous to drive the vehicle when the wear limits of the brake pads and/or those of the brake discs are exceeded.

If the vehicle will not shift out of the P position

There is a possibility that the 12-volt battery is discharged. Check the 12-volt battery in this situation.

<u></u> ∧ N

NOTICE

If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually press the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds.
- The vehicle will behave abnormally.

Information on what to do in case of a flat tire. (→P. 447, 459)

When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle.

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have any authorized Toyota dealer or repairer, or another duly qualified and equipped professional check the following.

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, hybrid system, transmission, etc.
- Lubricant condition for the bearings and suspension joints (where possible) and the function of all joints, bearings, etc.

As flooding may damage components involved in P position control, the parking lock may jam in the locked position.

2-1. Driving procedures

Power (ignition) switch

Performing the following operations when carrying the electronic key on your person starts the hybrid system or changes "POWER" switch modes.


■ Starting the hybrid system

STEP 1 Check that the parking brake is set.

STEP 2 Firmly depress the brake pedal.

The "POWER" switch indicator will turn green. If the indicator does not turn green, the hybrid system cannot be started.

When shift position N is selected, the hybrid system cannot start. Select the P position when starting the hybrid system. (\rightarrow P. 185)



Press the "POWER" switch.

After a few seconds, the "READY" indicator comes on with a beep sound.

The vehicle can move when the "READY" indicator is on, even if the engine is stopped.

Continue depressing the brake pedal until the hybrid system is completely started.

The hybrid system can be started from any "POWER" switch mode.

STEP 4 Check that the "READY" indicator is on.

The vehicle will not move when the "READY" indicator is off.

■ Stopping the hybrid system

STEP 1 Stop the vehicle by depressing the brake pedal.

STEP 2 Set the parking brake. (\rightarrow P. 191)

Push the P position switch to shift into P. (→P. 185)

Check that the shift position indicator on the instrument cluster shows P. (→P. 193)


STEP 4 Press the "POWER" switch.

STEP 5 Slowly release the brake pedal and check that the indicator on the "POWER" switch is off.

If you stop the hybrid system without setting the shift position to P, the shift position will be changed to P automatically. You can also change the shift position to P by pushing the P position switch.

■ Changing "POWER" switch modes

Modes can be changed by pressing the "POWER" switch with the brake pedal released. (The mode changes each time the switch is pressed.)



Off

Emergency flashers can be used.

2 ACCESSORY mode

Some electrical components such as the audio system can be used.

The "POWER" switch indicator turns amber.

3 ON mode

All electrical components can be used.

The "POWER" switch indicator turns amber.

■ If the hybrid system does not start

The immobilizer system may not have been deactivated. (→P. 107)

■ If the "READY" indicator does not come on

If the "READY" indicator does not come on when you press the "POWER" switch with the shift position in P and the brake pedal pressed, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional immediately.

■ When the "POWER" switch indicator flashes in amber

The system may be malfunctioning. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, immediately.

■ Auto power off function

If the vehicle is left in ACCESSORY or ON mode (hybrid system is not operating) for more than an hour with the shift position in P, the "POWER" switch will automatically turn off. However, this function cannot entirely prevent 12-volt battery discharge. Do not leave the vehicle with the "POWER" switch in ACCESSORY or ON mode for long periods of time when the hybrid system is not operating.

■ Operation of the "POWER" switch

- When operating the "POWER" switch, one short, firm press is enough. If the switch is pressed improperly, the hybrid system may not start or the "POWER" switch mode may not change. It is not necessary to press and hold the switch.
- If an attempt is made to restart the hybrid system immediately after turning the "POWER" switch off, the hybrid system may not start in some cases. After turning the "POWER" switch off, wait a few seconds before restarting the hybrid system.

■ When leaving the vehicle

If the indicator on the "POWER" switch stays on, the "POWER" switch is not yet off.

Turn the "POWER" switch off before you leave the vehicle.

■ Automatic P position selection function

- When the shift position is other than P, pressing the "POWER" switch with the vehicle stopped completely will cause the shift position to change to P automatically, and then the "POWER" switch will turn off.
- When turning the "POWER" switch off from a position other than P, firmly depress the brake pedal and confirm that the shift position* has changed to P before slowly releasing the brake pedal.
 - *: Even after the instrument panel display has been turned off, the shift position indicator will continue to be displayed for several seconds.
- If the P position control system malfunctions, the "POWER" switch will not be able to be turned off. In such a case, the switch can be turned off by applying the parking brake.
 - When the system malfunctions, immediately have your vehicle serviced by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional immediately.
- When the ambient temperature is low, such as during winter driving conditions

It may take time until the "READY" indicator comes on.

- Sounds and vibrations specific to a hybrid vehicle
 - →P. 33
- When the hybrid system is malfunctioning
 - →P. 432, 436
- Key battery depletion
 - →P. 49, 62
- When the electronic key battery is depleted
 - →P. 397
- **■** Conditions affecting operation
 - →P. 48, 61
- Note for the entry function
 - →P. 50

■When starting the hybrid system

Always start the hybrid system while sitting in the driver's seat. Do not depress the accelerator pedal while starting the hybrid system under any circumstances. Doing so may cause an accident resulting in death or serious injury.

Stopping the hybrid system in an emergency

If you want to stop the hybrid system in an emergency while driving the vehicle, press and hold the "POWER" switch for more than 3 seconds. However, do not touch the "POWER" switch while driving except in an emergency. Turning the hybrid system off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

№ NOTICE

To prevent 12-volt battery discharge


- Do not leave the "POWER" switch in ACCESSORY or ON mode for long periods if the hybrid system is not operating.
- If the hybrid system is off, but the indicator on the "POWER" switch is illuminated, this indicates that the "POWER" switch is still turned on. When exiting the vehicle, always check that the "POWER" switch is off.

When starting the hybrid system

If the hybrid system becomes difficult to start, have the hybrid system checked immediately.

2-1. Driving procedures **EV-Drive Mode**

In EV-Drive Mode the electric motor (traction motor), powered by the hybrid battery (traction battery), is used to drive the vehicle.



On/off

When EV-Drive Mode is turned on, the EV-Drive Mode indicator will come on. Pressing the switch when in EV-Drive Mode will return to normal driving (using the gasoline engine and electric motor [traction motor]).

■ Situations in which EV-Drive Mode cannot be turned on

The followings are examples of situations under which the EV-Drive Mode may not be turned on. If it cannot be turned on, a buzzer will sound and a message will be shown on the multi-information display.

- The temperature of the hybrid system is high.
 The vehicle has been left in the sun, driven on a hill, driven at high speeds, etc.
- The temperature of the hybrid system is low.
 The vehicle has been left in freezing temperatures for a long period of time etc.
- The gasoline engine is warming up.
- The hybrid battery (traction battery) is low.
 The remaining battery level indicated in the "Energy Monitor" display is low. (→P. 36)
- Vehicle speed is high.
- The accelerator pedal is depressed firmly or the vehicle is on a hill etc.
- The windshield defogger is in use.

■ Switching to EV-Drive Mode when the gasoline engine is cold

If the hybrid system is started while the gasoline engine is cold, the gasoline engine will start automatically after a short period of time in order to warm up. In this case, you will become unable to switch to EV-Drive Mode. After the hybrid system has started and the "READY" indicator has illuminated, press the "EV" switch before the gasoline engine starts to switch to EV-Drive Mode.

■ Automatic cancellation of EV-Drive Mode

When driving in EV-Drive Mode, the gasoline engine may automatically restart in the following situations. When EV-Drive Mode is canceled, a buzzer will sound and the EV-Drive Mode indicator will flash and go off.

- The hybrid battery (traction battery) becomes low. The remaining battery level indicated in the "Energy Monitor" display is low. (→P. 36)
- Vehicle speed becomes high.
- The accelerator pedal is depressed firmly or the vehicle is on a hill etc.

■ Possible driving distance when driving in EV-Drive Mode

Possible driving distance when driving in EV-Drive Mode is up to about 1 km (1/2 mile) if driven at a speed of about 40 km/h (25 mph) or less. (Possible driving distance depends on the hybrid battery [traction battery] level and driving conditions.)

■ Changing a driving mode when in EV-Drive Mode

EV-Drive Mode can be used in conjunction with Eco drive mode and power mode

However, EV-Drive Mode may be automatically canceled when used in conjunction with power mode.

■ Fuel economy

Your Toyota is designed to achieve the best possible fuel economy during normal driving (using the gasoline engine and electric motor [traction motor]). Driving in EV-Drive Mode more than necessary may lower fuel economy.

▲ CAUTION


While driving

When driving in EV-Drive Mode, pay special attention to the area around the vehicle. Because there is no engine noise, pedestrians, people riding bicycles or other people and vehicles in the area may not be aware of the vehicle starting off or approaching them, so take extra care while driving.

Transmission

Select a shift position appropriate for the driving conditions.

■ Shifting the shift lever



Operate the shift lever gently and ensure correct shifting operation.



When shifting to the D or R positions, move the shift lever along the shift gate.



To shift to the N position, slide the shift lever to the left and hold it. The shift position will change to N.



Shifting to B is only possible when shift position D is selected.

 The shift lever will always return to this position after a shifting operation.

When shifting from P to D or R, from D to R, or from R to D, ensure that the brake pedal is being depressed and that the vehicle is stationary.

When selecting a shift position, make sure that the shift position has been changed to the desired position by checking the shift position indicator provided on the instrument panel.

When a shift position other than D or B is selected, the arrow toward B disappears from the shift position indicator.


■ Shift position purpose

Shift position	Function
Р	Parking the vehicle or starting the hybrid system
R	Reversing
N	Neutral
D	Normal driving*
В	Applying moderate engine braking when driving down hills or on steep slopes

^{*:} For good fuel economy and noise reduction, the D position should usually be used.

■ P position switch

The shift position can be changed to P through the use of the P position switch.




Fully stop the vehicle and keep depressing the brake pedal, and then push the P position switch.

- When the shift position is changed to P, the switch indicator comes on.
- Check that the P position indicator is illuminated on the shift position indicator.

- Changing the shift position from P to other positions:
 - While depressing the brake pedal firmly, operate the shift lever. If the shift lever is operated without depressing the brake pedal, a buzzer will sound and the shifting operation will be disabled.
 - After the shift lever is operated, make sure to use the shift position indicator for checking that the desired shift position has been attained. (→P. 193)
 - The shift position cannot be changed from P to B directly.

■ Selecting a driving mode

The following modes can be selected to suit driving conditions.



Eco drive mode

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating and braking. The operation of the air conditioning system will be minimized.

Press the "ECO MODE" switch once more to cancel the Eco drive mode.

Eco drive mode will not be canceled until the "ECO MODE" switch is pressed, even if the "POWER" switch is turned off.

Press the "PWR MODE" switch to change the driving mode to power mode.

2 Power mode

Use when high levels of response and feeling are desirable, such as when driving in mountainous regions or when overtaking.

Press the "PWR MODE" switch once more to cancel the power mode.

Turning the "POWER" switch off will cancel power mode.

Press the "ECO MODE" switch to change the driving mode to Eco drive mode.

■ Using engine braking

To use engine braking, select the B position.

- During high speed driving, you may feel that deceleration by engine braking is less than that of a conventional vehicle.
- Do not continue normal driving with the transmission in B for a long time.
 This may cause decreased fuel economy. To prevent this, use D for normal driving.

■ Reverse warning buzzer

When shifting into R, a buzzer will sound to inform the driver that the shift lever is in R.

■ Eco drive mode

When the accelerator pedal is depressed in Eco drive mode, it may take more time to accelerate than usual. This is normal operation.

Alarms

If the shift position is changed in any of the following situations, a buzzer will sound and the shifting operation will be disabled or the shift position will automatically change to N. When this happens, select an appropriate shift position.

- Situations where the shifting operation will be disabled:
 - When the shift lever is changed from P to another position without depressing the brake pedal.
 - When the shift position is changed from P or N to B.
- Situations where the shift position will automatically change to N:
 - · When the P position switch is pushed while the vehicle is moving.
 - When shift position R is selected while the vehicle is moving forward.
 - When shift position D is selected while the vehicle is moving in reverse.
 - When the shift position is changed from R to B.

CAUTION

When driving on slippery road surfaces

Do not accelerate or shift gears suddenly.

Sudden changes in engine braking may cause the vehicle to spin or skid, resulting in an accident.

Shift lever precautions

Do not hang anything on the shift lever.

Doing so could prevent the shift lever from returning to position, causing unexpected accidents to occur when the vehicle is in motion.

NOTICE

Situations where P position control system malfunctions are possible

If any of the following situations occurs, P position control system malfunctions are possible.

Immediately stop the vehicle in a safe place on level ground, apply the parking brake, and then contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

- When a warning message indicating malfunction appears on the multiinformation display. (→P. 437)
- When the P position switch indicator flashes.
- When the shift position symbols (such as P and R) are flashing on the shift position indicator.
- When the shift position indicator remains off.

When in heavy traffic

If shift position N is selected, the hybrid battery (traction battery) will not be charged. To help prevent the battery from discharging, avoid leaving the N position selected for an extended period of time.

↑ NOTICE


If the vehicle cannot be shifted out of P

There is a possibility that the 12-volt battery is discharged. Check the 12-volt battery in this situation.

Notes regarding shift lever and P position switch operation

Avoid repeatedly operating the shift lever and P position switch in quick succession. The system protection function may activate and temporarily prevent the vehicle from shifting out of P. If this happens, wait for around 15 seconds before attempting to change the shift position again.

2-1. Driving procedures **Turn signal lever**



- Right turn
- 2 Left turn
- Move and hold the lever partway to signal a lane change.

The right hand signal will flash until you release the lever.

Move and hold the lever partway to signal a lane change.

The left hand signal will flash until you release the lever.


■ Turn signals can be operated when

The "POWER" switch is in ON mode.

■ If the indicators flash faster than usual

Check that a light bulb in the turn signal lights has not burned out.

2-1. Driving procedures Parking brake



■ Setting the parking brake

Fully set the parking brake while depressing the brake pedal.

2 Releasing the parking brake

Slightly raise the lever and then lower it completely while pressing the button.

■ Usage in winter time

See "Winter driving tips" for parking brake usage in winter time. (\rightarrow P. 236)


↑ NOTICE

Before driving

Fully release the parking brake.

Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

Horn




To sound the horn, press on or close to the mark.

■ After adjusting the steering wheel

Make sure that the steering wheel is securely locked. The horn may not sound if the steering wheel is not securely locked. $(\rightarrow P. 91)$

2-2. Instrument cluster **Gauges and meters**



The following gauges, meters and displays illuminate when the "POWER" switch is in ON mode.

- Hybrid System Indicator
 Displays the hybrid system output or regeneration level.
- 2 Fuel gauge
 Displays the quantity of fuel remaining in the tank.
- **3** Engine coolant temperature gauge Displays the engine coolant temperature.
- Speedometer
 Displays the vehicle speed.
- Multi-information display
 →P. 200

- Shift position indicatorDisplays the shift position.
- Odometer/trip meter display change button

Odometer: Displays the total distance the vehicle has been driven.


Trip meter: Displays the distance the vehicle has been driven since the meter was last reset. Trip meters "A" and "B" can be used to record and display different distances independently.

- B Odometer/trip meter display
- 9 Clock

→P. 345


Changing the display

Pressing this button switches among odometer, trip meter and instrument panel light control displays.



- Odometer
- 2 Trip meter A*1
- 3 Trip meter B*1
- Instrument panel light control display*2 (when the headlight switch is on and surrounding are dark enough)
- *1: Pressing and holding the button will reset the trip meter.
- *2: Pressing and holding the button will adjust brightness of the instrument panel lights.

■ Hybrid System Indicator



Eco Driving Indicator Light During Eco-friendly acceleration (Eco driving), Eco Driving Indicator Light will turn on.

Eco Driving Indicator Light will not operate in the following conditions:

- The shift position is anything other than D.
- The driving mode is set to power mode or EV-Drive Mode. (→P. 180, 186)
- The vehicle speed is approximately 130 km/h (80 mph) or higher.

2 Power area

Shows that the driving power is more than the upper limit of Eco driving (during full power driving etc.).

3 Eco area
Shows that the vehicle is driving in Eco-friendly.

4 Hybrid Eco area

Shows that gasoline engine power is not being used very often.

The gasoline engine will automatically stop and restart under various conditions.

5 Charge area Shows regenerative charging.

2-2. Instrument cluster

- By keeping the indicator needle within Eco area, more Eco-friendly driving can be achieved.
- Charge area indicates regeneration* status. Regenerated energy will be used to charge the battery.
- Eco Driving Indicator Light can be enabled or disabled. (→P. 203)
- *: When used in this manual, "regeneration" refers to the conversion of energy created by the movement of the vehicle into electrical energy.

↑ NOTICE


To prevent damage to the hybrid system and its components

The hybrid system may be overheating if the top segments of the engine coolant temperature gauge are flashing. In this case, immediately stop the vehicle in a safe place, and check the hybrid system after it has cooled completely. $(\rightarrow P. 481)$


2-2. Instrument cluster Indicators and warning lights

The indicator and warning lights on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

■ Instrument cluster



■ Center panel



Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator (→P. 190)



Cruise control indicator (→P. 219)



Headlight high beam indicator (→P. 206)



Slip indicator (→P. 229, 232)



Tail light indicator (→P. 206)



Shift position indicators (→P. 193)



Front fog light indicator $(\rightarrow P. 211)$



Power mode indicator (→P. 186)



Rear fog light indicator (→P. 211)



"ECO MODE" indicator (→P. 186)



Eco Driving Indicator Light (→P. 195)



EV-Drive Mode indicator (→P. 180)



Security indicator (→P. 107, 115)



"READY" indicator (→P. 175)




Airbag manual on-off indicator(→P. 160)

- *1: These lights turn on when the "POWER" switch is turned to ON mode to indicate that a system check is being performed. They will turn off after the hybrid system is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for details.
- *2: The light flashes to indicate that the system is operating.
- *3: The light does not turn on when the system is disable.

■ Warning lights

Warning lights inform the driver of malfunctions in any of the vehicle's systems. (\rightarrow P. 430)



- *1: These lights turn on when the "POWER" switch is turned to ON mode to indicate that a system check is being performed. They will turn off after the hybrid system is started, or after a few seconds. There may be a malfunction in a system if a light does not come on, or if the lights do not turn off. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for details.
- *2: The light flashes to indicate a malfunction.


A CAUTION

If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS airbag warning light not come on when you start the hybrid system, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, immediately if this occurs.

2-2. Instrument cluster Multi-information display

The multi-information display presents the driver with a variety of driving-related data, including the current outside temperature and date.



- Outside temperature display
- Date
- Energy monitor $(\rightarrow P. 36)$
- Trip information (→P. 201)


Displays driving range, fuel consumption and other cruising-related information.

- Eco Drive level (→P. 204)
- Warning messages

(→P. 436)


Automatically displayed when a malfunction occurs in one of the vehicle's system.

Switching the display



Display items can be switched by pressing the "DISP" switch.

■ Display items



Outside temperature and date

Displays the outside air temperature and date.

The temperature range that can be displayed is from -40°C (-40°F) to 50°C (122°F).

Energy monitor

Displays the status of the hybrid system. (\rightarrow P. 36)

When the energy monitor is displayed, the odometer/trip meter does not appear.

Instantaneous fuel consumption

Displays instantaneous fuel consumption.

4 Average fuel consumption

Displays the average fuel consumption since the function was reset.

- The function can be reset by pressing the "DISP" switch for longer than one second when the average fuel consumption is displayed.
- · Use the displayed average fuel consumption as a reference.

5 Cruise range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

- This distance is computed based on your average fuel consumption.
 As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

6 Average vehicle speed

Displays the average vehicle speed since the hybrid system was started or the function was reset.

The function can be reset by pressing the "DISP" switch for longer than one second when the average vehicle speed is displayed.

7 Elapsed time

Displays the elapsed time since the hybrid system was started or the function was reset.

The function can be reset by pressing the "DISP" switch for longer than one second when the elapsed time is displayed.

Set up screen


Language, date, date form and units can be set up. Also, the display of Eco Driving Indicator Light can be turned on or off.

Setting up display

Make sure that the vehicle is stopped in a safe place before beginning set up.

STEP 1 Display the "SET UP" screen.

Press and hold the "DISP" switch to enter the adjustment mode.



Press the "DISP" switch to select the desired item.

Press and hold the desired item to enter the adjustment screen.

To return to the "SET UP" screen after an adjustment is made, select "BACK" and then press and hold the "DISP" switch.


■ Selecting the language

Select the desired language.

Press and hold the "DISP" switch to input the choice.

Setting the date

STEP 1 Press the "DISP" switch to select the year.



After the year is adjusted, wait 5 seconds to select the month, and 5 more seconds to select the day.

■ Selecting the date form

Select the desired date form.

Press and hold the "DISP" switch to input the choice.

■ Selecting the units

Select the desired distance and consumption units.

Press and hold the "DISP" switch to input the choice.


Selecting to enable or disable Eco Driving Indicator Light (→P. 195)

Select "ON" or "OFF".

Press and hold the "DISP" switch to input the choice.

Eco Drive level

Displays the fuel consumption level of each trip when it ends.



When the hybrid system is turned off, this screen is displayed for several seconds. If a certain level of fuel efficiency is achieved, "EXCELLENT" will also appear.

■ When disconnecting and reconnecting 12-volt battery terminals

The following information data will be reset.

- Date
- Average fuel consumption
- Driving range
- Average vehicle speed
- Elapsed time

■ Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 25 km/h [16 mph])
- When the outside temperature has changed suddenly (at the entrance/ exit of a garage, tunnel, etc.)


⚠ NOTICE

■ The multi-information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

2-3. Operating the lights and wipers **Headlight switch**

The headlights can be operated manually or automatically.




The front position, tail, license plate and instrument panel lights turn on.

The headlights and all lights listed above turn on.

AUTO The headlights and (If equipped) front position lights turn on and off automatically.

(When the "POWER" switch is in ON mode)

Turning on the high beam headlights



■ With the headlights on, push the lever forward to turn on the high beams.


Pull the lever back to the center position to turn the high beams off.

2 Pull the lever toward you to flash the high beams.

Release the lever to turn them off. You can flash the high beams with the headlights on or off.

Manual headlight leveling dial (if equipped)

The level of the headlights can be adjusted according to the number of passengers and the loading condition of the vehicle.



- Raises the level of the headlights
- 2 Lowers the level of the head-lights

■ Guide to dial settings


Occupancy and luggage load conditions		Dial position
Occupants	Luggage load	Diai position
Driver	None	0
Driver and front pas- senger	None	0
All seats occupied	None	1
All seats occupied	Full luggage loading	1.5
Driver	Full luggage loading	2.5

Daytime running light system

To make your vehicle more visible to other drivers, the daytime running lights turn on automatically whenever the hybrid system is started. (However, the daytime running light system will be canceled when the headlight switch is operated manually or the automatic headlight system turns on the tail lights.) Daytime running lights are not designed for use at night.

- Deactivating/reactivating the daytime running light system Follow the procedure below.
- Turn the "POWER" switch, headlights, tail lights and automatic headlight system off and set the parking brake.
- STEP 2 Start the hybrid system.

You must perform step 3 within 5 seconds of starting the hybrid system.




Push the headlight switch forward and pull it back to the center position. (Repeat this operation 3 times or more.)

A buzzer will sound to indicate that the daytime running light system has been deactivated/reactivated.

If any of the following occurs during the deactivation/reactivation operation, the deactivation/reactivation operation will be canceled:

- · The hybrid system is turned off.
- · The parking brake is released.
- · The vehicle is moving.
- · The headlights are turned on.
- · The tail lights are turned on.
- The automatic headlight system is turned on.

■ Headlight control sensor (if equipped)



Headlight control sensor is located on the driver's side.

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield.

Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.

■ Automatic light off system (if equipped)

- When the light switch is in _00_ or ____ : The headlights and front fog lights turn off automatically if the "POWER" switch is turned to ACCESSORY mode or turned off.
- When the light switch is in AUTO: The headlights and all lights turn off automatically if the "POWER" switch is turned to ACCESSORY mode or turned off and the driver's door is opened.

To turn the lights on again, turn to ON mode, or turn the light switch off once and then back to -0.0^{-} or \bigcirc .

■ Light reminder buzzer (if equipped)

A buzzer sounds when the "POWER" switch is turned off or to ACCESSORY mode and the driver's door is opened while the lights are turned on.

Automatic headlight leveling system (vehicles with discharge headlights)

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

Customization that can be configured at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional

Settings of the light sensor sensitivity can be changed. (Customizable features \rightarrow P. 506)

2-3. Operating the lights and wipers

____N N0

NOTICE

■ To prevent 12-volt battery discharge

Do not leave the lights on longer than necessary when the hybrid system is not operating.

2-3. Operating the lights and wipers **Fog light switch**

The fog lights improve visibility in difficult driving conditions, such as in rain or fog.



- Turns the front and rear fog lights off
- 2 Turns the front fog lights on
- Turns both front and rear fog lights on

Releasing the switch ring returns it to # . (vehicles with an automatic headlight system)

Operating the switch ring again turns only the rear fog light off.


■ Fog lights can be used when

Front fog lights: The headlights or front position lights are turned on.


Rear fog light: The front fog lights are turned on.

2-3. Operating the lights and wipers Windshield wipers and washer


▶ Intermittent windshield wiper with interval adjuster
When intermittent windshield wiper operation is selected, wiper intervals can be adjusted.



- Intermittent windshield wiper operation
- 2 Low speed windshield wiper operation
- 3 High speed windshield wiper operation
- Temporary operation




- 5 Increases the intermittent windshield wiper frequency
- **6** Decreases the intermittent windshield wiper frequency



Wash/wipe operationWipers operate automatically.


► Rain-sensing windshield wipers

With "AUTO" selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.




- Rain-sensing windshield wiper operation
- 2 Low speed windshield wiper operation
- 3 High speed windshield wiper operation
- Temporary operation

2-3. Operating the lights and wipers



- 5 Sensor sensitivity (high)
- 6 Sensor sensitivity (low)



Wash/wipe operation

Wipers operate automatically. (After operating several times, the wipers operate one more time after a short delay to prevent dripping.)

With the headlight cleaner and discharge headlights: If the headlights are on, the headlight cleaners will operate once. (→P. 218)


■ The windshield wipers and washer can be operated when

The "POWER" switch is in ON mode.

■ Effects of vehicle speed on wiper operation (vehicles with rain-sensing windshield wipers)

Even when the wipers are not in "AUTO" mode, wiper operation varies depending on vehicle speed when the washer is being used (delay until drip prevention wiper sweep occurs).

■ Raindrop sensor (vehicles with rain-sensing windshield wipers)



 The sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present on the windshield.

- If the wiper switch is turned to the "AUTO" position while the "POWER" switch is in ON mode, the wiper will operate once to show that "AUTO" mode is activated.
- If the temperature of the raindrop sensor is 90°C (194°F) or higher, or -15°C (5°F) or lower, automatic operation may not occur. In this case, operate the wipers in any mode other than "AUTO".

■ If no windshield washer fluid sprays

Check that the washer nozzles are not blocked and if there is washer fluid in the windshield washer fluid reservoir.

A CAUTION

Caution regarding the use of windshield wipers in "AUTO" mode (vehicles with rain-sensing windshield wipers)

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in "AUTO" mode. Take care that your fingers or anything else do not become caught in the windshield wipers.

2-3. Operating the lights and wipers

↑ NOTICE

■ When the windshield is dry

Do not use the wipers, as they may damage the windshield.

■ When the washer fluid tank is empty


Do not operate the switch continually as the washer fluid pump may overheat.

When a nozzle becomes blocked

In this case, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional immediately.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

2-3. Operating the lights and wipers Rear window wiper and washer



- Intermittent window wiper operation
- Normal window wiper operation
- Washer/wiper dual operation
- Washer operation

■ The rear window wiper and washer can be operated when

The "POWER" switch is in ON mode.

♠ NOTICE

When the rear window is dry

Do not use the wipers, as they may damage the rear window.

When the washer fluid tank is empty

Do not operate the switch continually as the washer fluid pump may overheat.


When a nozzle becomes blocked

In this case, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional immediately.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

2-3. Operating the lights and wipers Headlight cleaner switch*

Washer fluid can be sprayed on the headlights.



Press the switch to clean the headlights.

■ The headlight cleaner can be operated when

The "POWER" switch is in ON mode and the headlight switch is turned on.

■ Windshield washer linked operation (vehicles with discharge head-lights)

When the windshield washer is operated with the "POWER" switch in ON mode and the headlights on, the headlight cleaner will operate once. $(\rightarrow P. 212)$

№ NOTICE


When the washer fluid tank is empty

Do not use this function when the washer fluid tank is empty. This may cause the washer fluid pump to overheat.

*: If equipped

2-4. Using other driving systems **Cruise control***


Use the cruise control to maintain a set speed without depressing the accelerator pedal.



1 Indicator


2 Cruise control switch

■ Setting the vehicle speed



Press the "ON-OFF" button to activate the cruise control.


Press the button again to deactivate the cruise control.



Accelerate or decelerate to the desired speed, and push the lever down to set the speed.

*: If equipped

■ Adjusting the set speed



- 1 Increase the speed
- Decrease the speed

Hold the lever until the desired speed setting is obtained.

Fine adjustment of the set speed can be made by lightly pushing the lever up or down and releasing it.

■ Canceling and resuming the constant speed control



■ Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied.

Pushing the lever up resumes the constant speed control.

■ Cruise control can be set when

- The shift position is in D.
- Vehicle speed is above approximately 40 km/h (25 mph).

Accelerating

The vehicle can be accelerated normally. After acceleration, the set speed resumes.

■ Automatic cruise control cancellation

Cruise control will stop maintaining the vehicle speed in any of the following situations.

- Actual vehicle speed falls more than approximately 16 km/h (10 mph) below the preset vehicle speed.
 - At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 40 km/h (25 mph).
- VSC is activated.

■ If the cruise control indicator light flashes

Press the "ON-OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, and have the vehicle inspected by your Toyota dealer.

A CAUTION

■ To avoid operating the cruise control by mistake

Switch the cruise control off using the "ON-OFF" button when not in use.

Situations unsuitable for cruise control

Do not use cruise control in any of the following situations. Doing so may result in loss of control and could cause an accident resulting in death or serious injury.

- In heavy traffic
- On roads with sharp bends
- On winding roads
- On slippery roads, such as those covered with rain, ice or snow
- On steep hills Vehicle speed may exceed the set speed when driving down a steep hill.
- During emergency towing


2

When driving

2-4. Using other driving systems Toyota parking assist-sensor*


Toyota parking assist-sensor uses sensors in the corners and rear of the vehicle to detect the distance between the vehicle and any obstacles, and informs the driver of this distance using the warning beeps.

Sensor types



- Rear corner sensors
- 2 Back sensors

■ Toyota parking assist-sensor switch



On/off

To turn the system on, press the switch. The indicator light comes on to inform the driver that the system is operational.


To turn the system off, press the switch again.

*: If equipped

2-4. Using other driving systems


Sensor detection distance and buzzer

▶ Back sensors




Distance shown as 1	Buzzer	
150 to 60 cm (4.9 to 1.9 ft.)	Long	
60 to 47.5 cm (1.9 to 1.6 ft.)	Medium	
47.5 to 35 cm (1.6 to 1.1 ft.)	Short	
Less than 35 cm (1.1 ft.)	Continuous	

▶ Rear corner sensors



Distance shown as 2	Buzzer	
50 to 37.5 cm (1.6 to 1.2 ft.)	Medium	
37.5 to 25 cm (1.2 to 0.8 ft.)	Short	
Less than 25 cm (0.8 ft.)	Continuous	

Obstacle detection range



- **1** Approx. 50 cm (1.6 ft.)
- 2 Approx. 150 cm (4.9 ft.)

The detection area of the sensors is shown to the left. If obstacles move too close to the sensors, they will not be detected.

The range of the sensors may change depending on the shape of the object etc.

■ The Toyota parking assist-sensor can be operated when

The "POWER" switch is in the ON mode, and the shift position is in R.

Sensor detection information

- Certain vehicle conditions and the surrounding environment may affect the ability of the sensor to correctly detect obstacles. Particular instances where this may occur are listed below.
 - There is dirt, snow or ice on the sensor. (Wiping the sensor will resolve this problem.)
 - The sensor is frozen. (Thawing the sensor will resolve this problem.)
 - · The sensor is covered in any way.
 - · In harsh sunlight or intense cold weather.
 - · When driving bumpy, sloped or gravel roads, or over grass.
 - If there is something producing ultrasonic waves nearby, such as another vehicle's horn, motorcycle engine noise, air braking sound from heavy-duty vehicles, or another vehicle using the park assist system
 - In heavy rain, or if water is splashed on the sensors.
 - The vehicle is leaning considerably to one side.
 - If a commercial fender pole or radio antenna is installed.
 - · If moving towards a high curb or a curb corner.
 - · If towing eyelet is installed on your vehicle.
 - The bumper or sensor receives a strong impact.
 - A non-genuine Toyota suspension (lowered suspension etc.) is installed.

In addition to the examples above, there are instances in which, because of their shapes, signs and other objects may be judged by the sensors to be closer than they are.

- The shape of the obstacle may prevent the sensor from detecting it. Pay particular attention to the following obstacles.
 - Thin objects such as wire, fencing or rope.
 - · Objects that absorb sound waves, such as cotton or snow.
 - · Objects with sharp corners.
 - · Low objects.
 - Objects where the upper section projects out over the lower section.

A CAUTION

■When using the Toyota parking assist-sensor

Observe the following precautions.

Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

- Do not use the sensor at speeds in excess of 10 km/h (6 mph).
- Do not attach any accessories within the sensor range.

↑ NOTICE

When washing the vehicle

Do not apply intensive bursts of water or steam to the sensor area. Doing so may result in the sensor malfunctioning.

2-4. Using other driving systems **Driving assist systems**

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

■ ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface.

■ Brake assist

Generates an increased level of braking force after the brake pedal is depressed, when the system detects a panic stop situation.

■ VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces.

■ VSC+ (Vehicle Stability Control+)

Provides cooperative control of the ABS, TRC, VSC and EPS. Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

■ TRC (Traction Control)

Helps to maintain drive power and prevent the front wheels from spinning when starting the vehicle or accelerating on slippery roads.


■ Hill-start assist control

→P. 232

■ EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel.

When the VSC/TRC systems are operating



If the vehicle is in danger of slipping or the front wheels spin, the indicator flashes to indicate that the VSC/TRC systems have been engaged.

A buzzer (intermittent) sounds to indicate that VSC is operating.

■ Sounds and vibrations caused by the ABS, brake assist, VSC and TRC

- A sound may be heard from the engine compartment when the hybrid system is started, just after the vehicle begins to move, if the brake pedal is depressed repeatedly, or 1 - 2 minutes after the hybrid system is stopped. This sound does not indicate that a malfunction has occurred in any of these systems.
- Any of the following conditions may occur when the above systems are operating. None of these indicate that a malfunction has occurred.
 - Vibrations may be felt through the vehicle body and steering.
 - A motor sound may be heard after the vehicle comes to a stop.
 - The brake pedal may pulsate slightly after the ABS is activated.
 - The brake pedal may move down slightly after the ABS is activated.

■ EPS operation sound

When the steering wheel operates, a motor sound (whirring sound) may be heard.

This does not indicate a malfunction.

■ Reduced effectiveness of EPS

The effectiveness of EPS is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the hybrid system off. The system should return to normal within 10 minutes.

A CAUTION

■ The ABS does not operate effectively when

- The limit of tire gripping have been exceeded.
- The vehicle hydroplanes while driving at high speed on the wet or slick road.

Stopping distance when the ABS is operating may exceed that of normal conditions

The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you in the following situations.

- When driving on dirt, gravel or snow-covered roads
- When driving with tire chains
- When driving over bumps in the road
- When driving over roads with potholes or roads with uneven pavement

TRC may not operate effectively when

Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRC is operating.

Do not drive the vehicle in conditions where stability and power may be lost.

When the VSC is activated

The slip indicator light flashes and a warning buzzer sounds. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes and a buzzer sounds.

A CAUTION

Replacing tires

Make sure that all tires are of the same size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the specified tire pressure level.

The ABS and VSC will not function correctly if different tires are fitted on the vehicle.


Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional for further information when replacing tires or wheels.

Handling of tires and suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause the system to malfunction.

2-4. Using other driving systems Hill-start assist control

Hill-start assist control helps to prevent the vehicle from rolling backwards when starting on incline or slippery slope.



To engage hill-start assist control, further depress the brake pedal when the vehicle is stopped completely.

A buzzer will sound once to indicate the system is activated. The slip indicator will also start flashing.

■ Hill-start assist control operating conditions

The system operates in the following situations:

- The shift position is other than P.
- The parking brake is not applied.
- The accelerator pedal is not depressed.

■ Hill-start assist control

- While hill-start assist control is operating, the brakes remain automatically applied after the driver releases the brake pedal. The stop lights and the high mounted stoplight turn on.
- Hill-start assist control operates for about 2 seconds after the brake pedal is released.
- If the slip indicator does not flash and the buzzer does not sound when the brake pedal is further depressed, slightly reduce the pressure on the brake pedal (do not allow the vehicle to roll backward) and then firmly depress it again. If the system still does not operate, check that the operating conditions explained above have been met.

■ Hill-start assist control buzzer

- When hill-start assist control is activated, the buzzer will sound once.
- In the following situations, hill-start assist control will be canceled and a buzzer will sound twice.
 - No attempt is made to drive the vehicle within approximately 2 seconds of releasing the brake pedal.
 - The P position switch is pushed.
 - · The parking brake is applied.
 - · The brake pedal is depressed again.
 - The brake pedal has been depressed for more than approximately 3 minutes.

■ If the slip indicator stays on...

It may indicate a malfunction in the system. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

A CAUTION

Hill-start assist control

- Do not overly rely on hill-start assist control. Hill-start assist control may not operate effectively on extremely steep inclines or roads covered in ice.
- Unlike the parking brake, hill-start assist control is not intended to hold the vehicle stationary for an extended period of time. Do not attempt to use hill-start assist control to hold the vehicle on an incline for an extended period of time, as doing so may lead to an accident.

2-5. Driving information Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load.

- Stow cargo and luggage in the luggage compartment whenever possible.
- Be sure all items are secured in place.
- Be careful to keep the vehicle level. Placing the weight as far forward as possible helps maintain vehicle balance.
- For better fuel economy, do not carry unnecessary weight.

A CAUTION

Things that must not be carried in the luggage compartment

The following things may cause a fire if loaded in the luggage compartment.

- Receptacles containing gasoline
- Aerosol cans

Storage precautions

Observe the following precautions. Failing to do so may result in death or serious injury.

- Do not place cargo or luggage in or on the following locations as the item may get under the brake or accelerator pedal and prevent the pedals from being depressed properly, block the driver's vision, or hit the driver or passengers, causing an accident.
 - · Driver's feet
 - Front passenger or rear seats (when stacking items)
 - Luggage cover
 - Instrument panel
 - · Dashboard
 - · Auxiliary box or tray that has no lid
- Do not stack anything in the luggage compartment higher than the seatbacks.
 - Such items may be thrown about and possibly injure people in the vehicle in the event of sudden braking or in an accident.
- Secure all items in the occupant compartment, as they may shift and injure someone during sudden braking, sudden swerving or an accident.
- Never allow anyone to ride in the luggage compartment. It is not designed for passengers. They should ride in their seats with their seat belts properly fastened. Otherwise, they are much more likely to suffer death or serious bodily injury, in the event of sudden braking, sudden swerving or an accident.

2-5. Driving information Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

■ Pre-winter preparations

- Use fluids that are appropriate to the prevailing outside temperatures.
 - · Engine oil
 - Engine/power control unit coolant
 - Washer fluid
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the front tires.

Ensure that all tires are the same size and brand, and that chains match the size of the tires.

■ Before driving the vehicle

Perform the following according to the driving conditions.

- Do not try to forcibly open a window, scrape an outside rear view mirror surface or move a wiper or outside rear view mirror that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Remove any ice that has accumulated on the vehicle chassis.
- Periodically check for and remove any excess ice or snow that may have accumulated in the wheel well or on the brakes.

■ When driving the vehicle


Accelerate the vehicle slowly and drive at a reduced speed suitable to road conditions.

■ When parking the vehicle

Park the vehicle and push the P position switch without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

Selecting tire chains

Use the correct tire chain size when mounting the tire chains. Chain size is regulated for each tire size.



Side chain:

- 3 mm (0.12 in.) in diameter
- 2 10 mm (0.39 in.) in width
- 3 30 mm (1.18 in.) in length Cross chain:
- 4 mm (0.16 in.) in diameter
- 5 14 mm (0.55 in.) in width
- 6 25 mm (0.98 in.) in length

Regulations on the use of tire chains

- Regulations regarding the use of tire chains vary according to location and type of road. Always check local regulations before installing chains.
- Install the chains on the front tires.
- Retighten the chains after driving 0.5 1.0 km (1/4 1/2 mile).

■ Tire chains

Observe the following precautions when installing and removing chains.

- Install and remove tire chains in a safe location.
- Install tire chains on the front tires.
- Install tire chains following the instructions provided in the accompanying manual.

A CAUTION

■ Driving with snow tires

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in a loss of vehicle control and cause death or serious injury.

- Use tires of the specified size.
- Maintain the recommended level of air pressure.
- Do not drive at speeds in excess of the speed limit or the speed limit specified for the snow tires being used.
- Snow tires should be installed on all wheels.


Driving with tire chains

Observe the following precautions to reduce the risk of accidents. Failing to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used or 50 km/h (30 mph), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden turns and braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.

2-5. Driving information **Trailer towing**

Toyota does not recommend towing a trailer with your vehicle. Toyota also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your Toyota is not designed for trailer towing or for the use of tow hitch mounted carriers.



	3-1.	Using the air conditionin system and defogger Air conditioning system Rear window and outside rear view mirror defoggers	244
	3-2.	Using the audio system Audio system types Using the radio Using the CD player Playing back MP3 and WMA discs Operating an iPod Operating a USB memory Optimal use of the audio system Using the AUX port Using the steering wheel audio switches	257 262 267 273 280 288 291
242			

(for cellular phone)...... 314

Making a phone call.......... 320 Setting a cellular phone.... 323

Security and system


Luggage compartment

features...... 353

243

UK AURIS HV EE

3-1. Using the air conditioning system and defogger Air conditioning system



Using the automatic mode



The air conditioning system will begin to operate.

STEP 2 Press "\" to increase the temperature and "\" to decrease the

temperature on TEMP

Adjusting the settings

■ Adjusting the temperature setting

Press "^" to increase the temperature and "\" to decrease the tem-

■ Adjusting the fan speed

Press "^" (increase) or "\" (decrease) on \$\frac{\top}{s}\$.


The fan speed is shown on the display. (7 levels)

Press storm to turn the fan off.

■ Changing the air outlets




The air outlets switch each time is pressed. The air flow shown on the display indicates the following.



> : Some models


Interior features

3-1. Using the air conditioning system and defogger




Air flows to the upper body and feet.





Mainly air flows to the feet.

Some models



Air flows to the feet and the windshield defogger operates.

Recirculated air mode will automatically switch to outside air mode.


: Some models

■ Switching air intake modes

Press .

The mode switches between outside air mode (indicator off) and recirculated air mode (indicator on) each time is pressed.

Defogging the windshield




Defogging

The air conditioning system operates automatically.

Recirculated air mode will automatically switch to outside air mode. It is not possible to return to recirculated air mode when the switch is on.


Adjusting the position of and opening and closing the air outlets

► Center outlets (type A)




- Direct air flow to the left or right, up or down.
- 2 Turn the knob up to open the vent and down to close the vent.

► Center outlets (type B)



- Direct air flow to the left or right, up or down.
- Turn the knob up to open the vent and down to close the vent.

▶ Right and left side outlets



- Direct air flow to the left or right, up or down.
- Turn the knob up to open the vent and down to close the vent.

■ Using the automatic mode

Fan speed is adjusted automatically in accordance with the temperature setting and ambient conditions. As a result, the following may occur.

- Immediately after is pressed, the fan may stop for a while until warm or cool air is ready to flow.
- Cool air may flow to the area around the upper body when the heater is on.

■ Using the recirculated air mode

The windows will fog up more easily if the recirculated air mode is used for an extended period.

■ Switching between outside air and recirculated air modes

Recirculated air mode or outside air mode may be automatically switched to in accordance with the temperature setting and the inside temperature.

■ Window defogger feature

Recirculated air mode may automatically switch to outside air mode in situations where the windows need to be defogged.

■ When outside air temperature approaches 0°C (32°F)

The air conditioning system may not operate even when



is pressed.

■ When 💢 is selected for the air outlets used

For your driving comfort, air flowing to the feet may be warmer than air flowing to the upper body depending on the temperature setting.

■ When Eco drive mode is on

- If the outside temperature exceeds a preset temperature, the system will switch to recirculated air mode.
- The effectiveness of the air conditioning will be lower than normal.
- The fan speed level drops below the normal rate.

■ Air conditioning odors

- During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
- To reduce potential odors from occurring:
 - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
 - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

3-1. Using the air conditioning system and defogger

A CAUTION

To prevent the windshield from fogging up

Do not use during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.


↑ NOTICE

■ To prevent 12-volt battery discharge

Do not leave the air conditioning system on longer than necessary when the hybrid system is off.

3-1. Using the air conditioning system and defogger Rear window and outside rear view mirror defoggers

The rear window defogger is used to defog the rear window. The outside rear view mirror defoggers are used to remove frost, dew or raindrops from the outside rear view mirrors.



The defoggers will automatically turn off after approximately 15 minutes.

■ Outside rear view mirror defoggers (if equipped)

Turning the rear window defogger on will turn the outside rear view mirror defoggers on.



A CAUTION


Outside rear view mirror defoggers

The surfaces of the outside rear view mirrors may become hot. To prevent burns do not touch the mirrors.

3-2. Using the audio system Audio system types*

Without "touch screen"

CD player with changer controller and AM/FM radio




Title	Page
Using the radio	P. 257
Using the CD player	P. 262
Playing back MP3 and WMA discs	P. 267
Operating an iPod	P. 273
Operating a USB memory	P. 280
Optimal use of the audio system	P. 288
Using the AUX port	P. 291
Using the steering wheel audio switches	P. 292

*: If equipped

With "touch screen"

Owners of models equipped with a "touch screen" should refer to the ""touch screen" Owner's manual".



■ Using cellular phones

Interference may be heard through the audio system's speakers if a cellular phone is being used inside or close to the vehicle while the audio system is operating.

∧ NOTICE

■ To prevent 12-volt battery discharge

Do not leave the audio system on longer than necessary when the hybrid system is off.

To avoid damaging the audio system

Take care not to spill drinks or other fluids over the audio system.

■ Certification for the "touch screen"

Panasonic Corporation Automotive Systems Company 4261 Ikonobe-Cho, Tsuzuki-Ku, Yokohama 224-8520 Japan

DECLARATION of CONFORMITY

We, Panasonic Corporation Automotive Systems Company 4261 lkonobe-cho, Tsuzuki-ku, Yokohama-shi, Kanagawa 224-8520 Japan

declare under our sole responsibility that the product:

Product : Bluetooth Module Assy

Model/Type: YEAP01A046 / YEAP01A049 / YEAP01A112

to which this declaration relates is in conformity with the essential requirements and other relevant requirements of the R&TTE Directive (1999/5/EC). The product is in conformity with the following standards:

RADIO : EN 300 328 V1.7.1; 2006-10 EMC : EN 301 489-1 V1.8.1; 2008-04

EN 301 489-3 V1.4.1: 2002-08 EN 301 489-17 V2.1.1: 2009-05

SAFETY: EN 60950-1: 2006 ÷ Amd.11: 2009



Date August 24, 2010

K. Teral Signature :

Name Kimito Terai Title Staff Engineer

Panasonic Corporation tímto prohlašuje, že tento YEAP01A046 / YEAP01A049 / YEAP01A112 je ve shodě se základními požadavky a dalšími příslušnými ustanoveními směrnice 1999/5/ES.

Undertegnede Panasonic Corporation erklærer herved, at følgende udstyr YEAP01A046 / YEAP01A049 / YEAP01A112 overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

Hiermit erklärt Panasonic Corporation, dass sich das Gerät YEAP01A046 / YEAP01A049 / YEAP01A112 in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 1999/5/EG befindet.

Käesolevaga kinnitab Panasonic Corporation seadme YEAP01A046 / YEAP01A049 / YEAP01A112 vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

Hereby, Panasonic Corporation, declares that this YEAP01A046 / YEAP01A049 / YEAP01A112 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

Por medio de la presente Panasonic Corporation declara que el YEAP01A046 / YEAP01A049 / YEAP01A112 cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Panasonic Corporation ΔΗΛΩΝΕΙ ΟΤΙ ΥΕΑΡ01Α046 / ΥΕΑΡ01Α049 / ΥΕΑΡ01Α112 ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1999/5/ΕΚ.

Par la présente Panasonic Corporation déclare que l'appareil YEAP01A046 / YEAP01A049 / YEAP01A112 est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

Con la presente Panasonic Corporation dichiara che questo YEAP01A046 / YEAP01A049 / YEAP01A112 è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

Ar šo Panasonic Corporation deklarē, ka YEAP01A046 / YEAP01A049 / YEAP01A112 atbilst Direktīvas 1999/5/EK būtiskajām prasībām un citiem ar to saistītajiem noteikumiem.

Šiuo Panasonic Corporation deklaruoja, kad šis YEAP01A046 / YEAP01A049 / YEAP01A112 atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

Hierbij verklaart Panasonic Corporation dat het toestel YEAP01A046 / YEAP01A049 / YEAP01A112 in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

3-2. Using the audio system

Hawnhekk, Panasonic Corporation, jiddikjara li dan YEAP01A046 / YEAP01A049 / YEAP01A112 jikkonforma mal-ħtiġijiet essenzjali u ma provvedimenti oħrajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

Alulfrott, Panasonic Corporation nyilatkozom, hogy a YEAP01A046 / YEAP01A049 / YEAP01A112 megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

Niniejszym Panasonic Corporation oświadcza, że YEAP01A046 / YEAP01A049 / YEAP01A112 jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 1999/5/EC.

Panasonic Corporation declara que este YEAP01A046 / YEAP01A049 / YEAP01A112 está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

Panasonic Corporation izjavlja, da je ta YEAP01A046 / YEAP01A049 / YEAP01A112 v skladu z bistvenimi zahtevami in ostalimi relevantnimi določili direktive 1999/5/ES.

Panasonic Corporation týmto vyhlasuje, že YEAP01A046 / YEAP01A049 / YEAP01A112 spĺňa základné požiadavky a všetky príslušné ustanovenia Smernice 1999/5/ES.

Panasonic Corporation vakuuttaa täten että YEAP01A046 / YEAP01A049 / YEAP01A112 tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.


Härmed intygar Panasonic Corporation att denna YEAP01A046 / YEAP01A049 / YEAP01A112 står I överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.

Hér með lýsir Panasonic Corporation yfir því að YEAP01A046 / YEAP01A049 / YEAP01A112 er í samræmi við grunnkröfur og aðrar kröfur, sem gerðar eru í tilskipun 1999/5/EC.

Panasonic Corporation erklærer herved at utstyret YEAP01A046 / YEAP01A049 / YEAP01A112 er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

Ovim, Panasonic Corporation, izjavljuje da ovaj YEAP01A046 / YEAP01A049 / YEAP01A112 je usklađen sa bitnim zahtjevima i drugim relevantnim odredbama Direktive 1999/5/EC.

3-2. Using the audio system Using the radio*



Setting station presets

■ Manually

Step 1 Search for desired stations by turning or pressing "^"

Press and hold the button (from 1 to 6) the station is to be set to until you hear a beep.

*: If equipped

Automatically

Press and hold AST until you hear a beep.

Up to 6 stations are set in order of reception quality. When the settings are finished, 2 beeps will be heard.

In the FM1 or FM2 mode, the stations automatically set by the audio system will be set in the FM3 presets.

RDS (Radio Data System)

This feature allows your radio to receive station and program information (classical, news, etc.) from radio stations that broadcast this information.

■ Listening to stations of the same network

Press AF .

AF-ON, REG-OFF modes: The station among those of the same

network with strong reception is

selected.

AF-ON, REG-ON modes: The station among those of the same

network with strong reception and broadcasting the same program is

selected.

Each time AF is pressed, the mode changes in the order of AF-ON, REG-OFF, AF-ON, REG-ON-AF-OFF, REG-OFF.

Specifying program type

Press PTY .

Each time $\[\]$ is pressed, the program type changes in the order of "NEWS" \rightarrow "SPORTS" \rightarrow "TALK" \rightarrow "POP" \rightarrow "CLASSICS".

■ Traffic information

Press TA .

TP mode: The system automatically switches to traffic information when a broadcast with a traffic information signal is received.

The station returns to the previous one when the traffic information ends.

TA mode: The system automatically switches to traffic information when a broadcast with a traffic information signal is received. In FM modes, the system will be mute unless traffic information is being broadcast.

The audio system returns to the previous mode when the traffic information ends.

Traffic information cannot be heard if the hands-free phone system is in use.

The audio system mode changes as follows each time TA is pressed.

FM modes: TP→TA→OFF

Modes other than FM modes: TA→OFF

■ Emergency broadcast reception mode

"ALARM" appears on the display in the event that an emergency broadcast is received, and the emergency broadcast is aired.

■ Certification for the radio (for Italy)

IL PRODUTTORE Panasonic Corporation Automotive Systems Company 4261, Ikenobe-cho, Tsuzuki-ku, Yokohama, 224-8520, JAPAN DI QUESTO APPARECCHIO MODELLO 86120-02F50 DICHIARA CHE ESSO E'CONFORME AL D.M.28.08.1995 Nr.548, OTTEMPERANDO ALLE PRESCRIZIONI DI CUI AL D.M.25.6.1985 (PARAGRAFO 3,ALL.A) ED AL D.M.27.8.1987 (PARAGRAFO 3,ALL.I)

IL PRODUTTORE FUJITSU TEN (EUROPE) GmbH, Mündelheimer Weg 39, 40472 Düsseldorf, Germania DI QUESTO APPARECCHIO MODELLO FT0001n DICHIARA CHE ESSO E'CONFORME AL D.M.28.08.1995 Nr.548, OTTEMPERANDO ALLE PRESCRIZIONI DI CUI AL D.M.25.06.1985 (PARAGRAFO 3,ALL.A) ED AL D.M.27.08.1987 (PARAGRAFO 3,ALL.I.).

■ EON (Enhanced Other Network) system (for traffic announcement function)

If the RDS station (with EON data) you are listening to is not broadcasting a traffic information program and the audio system is in the TA (traffic announcement) mode, the radio will be switched automatically to a station broadcasting a traffic information program in the EON AF list when traffic information begins.

■ When the 12-volt battery is disconnected

Stations presets are erased.

■ Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- When AST is used, automatic station selection and automatic registering of stations may not be possible.
- The radio antenna is mounted on the rear roof. The antenna can be removed from the base by turning it.


■ Digital Audio Broadcast (DAB) radio

The optional radio antenna and tuner are necessary for the use of Digital Audio Broadcast (DAB) radio.

↑ NOTICE

- To prevent damage, remove the antenna in the following cases.
 - The antenna will touch the ceiling of a garage.
 - A cover will be put on the roof.

3-2. Using the audio system Using the CD player*



Loading CDs

Insert a CD.

Ejecting CDs

Press and remove the CD.

Selecting a track

Press "^" to move up or "v" to move down using seek thack until the desired track number is displayed.

*: If equipped

Fast-forwarding and reversing tracks

To fast-forward or reverse, press and hold " ${\scriptstyle \wedge}$ " or " ${\scriptstyle \vee}$ " on



Selecting a CD (CD player with changer only)

To select the desired CD, press $3 (\lor)$ or $4 (\land)$.

Repeat play

■ To repeat a track

Press 2 (RPT).

To repeat all of the tracks on a CD (CD player with changer only)

Press and hold 2 (RPT) until you hear a beep.

Random playback

■ Current CD

Press 1 (RAND).

Tracks are played in a random order until 1 is pressed once more.

■ All CDs (CD player with changer only)

Press and hold 1 (RAND) until you hear a beep.

Tracks on all loaded CDs are played in a random order until 1 is pressed once more.

Switching the display

Press TEXT.

3-2. Using the audio system

■ Display

Up to 12 characters can be displayed at a time.

If there are 13 characters or more, pressing and holding TEXT for 1 second or more will display the remaining characters.

A maximum of 24 characters can be displayed.

If ______ is pressed for 1 second or more again or has not been pressed for 6 seconds or more, the display will return to the first 12 characters.

Depending on the contents recorded, the characters may not be displayed properly or may not be displayed at all.

■ Canceling random and repeat playback

Press 1 (RAND) or 2 (RPT) again.

■ Error message

"ERROR": This indicates a problem either in the CD or inside the player. The CD may be dirty, damaged or inserted up-side down.

■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.









CDs with copy-protect features may not be used.

■ CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected while the CD player is being used.

■If a CD is left inside the CD player or in the ejected position for extended periods

The CD may be damaged and may not play properly.

■ Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

A CAUTION

Certification for the CD player

This product is a class I laser product.

- A laser beam leak may result in hazardous radiation exposure.
- Do not open the cover of the player or attempt to repair the unit yourself. Refer servicing to qualified personnel.
- Laser power: No hazardous

↑ NOTICE


CDs and adapters that cannot be used

Do not use the following types of CDs or 8 cm (3 in.) CD adapters or Dual Disc.

Doing so may damage the CD player and/or the CD insert/eject function.




 CDs that have a diameter that is not 12 cm (4.7 in.)



Low-quality and deformed CDs

3-2. Using the audio system





 CDs with a transparent or translucent recording area




 CDs that have had tape, stickers or CD-R labels attached to them, or that have had the label peeled off

CD player precautions

Failure to follow the precautions below may result in serious damage to the CDs or the player itself.

- Do not insert anything other than CDs into the CD slot.
- Do not apply oil to the CD player.
- Store CDs away from direct sunlight.
- Never try to disassemble any part of the CD player.

3-2. Using the audio system Playing back MP3 and WMA discs*



Loading and ejecting MP3 and WMA discs

→P. 262

Selecting a CD (CD player with changer only)

To select the desired CD, press $3 (\lor)$ or $4 (\land)$.

Selecting a folder

To select the desired folder, press $\boxed{5}$ (\lor) or $\boxed{6}$ (\land).

To return to the first folder, press and hold $\boxed{5}$ (\lor) until you hear a beep.

*: If equipped

Selecting files

Turn or press "^" or "\" on Select the desired file.

Fast-forwarding and reversing files

Repeat play

■ To repeat a file

Press 2 (RPT).

■ To repeat all of the files on a folder

Press and hold 2 (RPT) until you hear a beep.

Random playback

- To play files from a particular folder in random order Press 1 (RAND).
- To play all of the files on a disc in random order

 Press and hold 1 (RAND) until you hear a beep.

Switching the display

Press TEXT.

Display

Up to 12 characters can be displayed at a time.

If there are 13 characters or more, pressing and holding TEXT for 1 second or more will display the remaining characters.

A maximum of 24 characters can be displayed.

If ______ is pressed for 1 second or more again or has not been pressed for 6 seconds or more, the display will return to the first 12 characters.

Depending on the contents recorded, the characters may not be displayed properly or may not be displayed at all.

■ Canceling random and repeat playback

Press 1 (RAND) or 2 (RPT) again.

■ Error messages

"ERROR": This indicates a problem either in the CD or inside the player.

The CD may be dirty, damaged or inserted up-side down.

"NO MUSIC": This indicates that the MP3/WMA file is not included in the CD.

■ Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.



■ CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected while the CD player is being used.

■If a CD is left inside the CD player or in the ejected position for extended periods

The CD may be damaged and may not play properly.

■ Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

■ MP3 and WMA files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards and to the media/formats recorded by them that can be used.

- MP3 file compatibility
 - Compatible standards MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3)
 - Compatible sampling frequencies MPEG1 LAYER3: 32, 44.1, 48 (kHz) MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz)
 - Compatible bit rates

MPEG1 LAYER3: 64, 80, 96, 112, 128, 160, 192, 224, 256, 320 (kbps) MPEG2 LSF LAYER3: 64, 80, 96, 112, 128, 144, 160 (kbps) * Compatible with VBR

- Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
 - Compatible standards WMA Ver. 7, 8, 9
 - Compatible sampling frequencies 32, 44.1, 48 (kHz)
 - · Compatible bit rates

Ver. 7, 8: CBR 48, 64, 80, 96, 128, 160, 192 (kbps)

Ver. 9: CBR 48, 64, 80, 96, 128, 160, 192, 256, 320 (kbps)

* Only compatible with 2-channel playback

Compatible media

Media that can be used for MP3 and WMA playback are CD-Rs and CD-RWs.

Playback in some instances may not be possible, depending on the status of the CD-R or CD-RW. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

Compatible disc formats

The following disc formats can be used.

- Disc formats: CD-ROM Mode 1 and Mode 2 CD-ROM XA Mode 2, Form 1 and Form 2
- File formats: ISO9660 Level 1, Level 2, (Romeo, Joliet)
 MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- · Maximum directory hierarchy: 8 levels
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- · Maximum number of files per disc: 255
- File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

Multi-sessions

As the audio system is compatible with multi-sessions, it is possible to play discs that contain MP3 and WMA files. However, only the first session can be played.

ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

MP3 and WMA playback

When a disc containing MP3 or WMA files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend you do not write in any files other than MP3 or WMA files or create any unnecessary folders.

If the discs contain a mixture of music data and MP3 or WMA format data, only music data can be played.

Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be mistakenly recognized and played as MP3 and WMA files. This may result in large amounts of interference and damage to the speakers.

Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of 128 kbps and a sampling frequency of 44.1 kHz.
- CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all
- When files other than MP3 or WMA files are recorded on a disc, it may take more time to recognize the disc and in some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S. and other countries.


↑ NOTICE

- CDs and adapters that cannot be used (→P. 265)
- CD player precautions (→P. 266)


3-2. Using the audio system Operating an iPod*

Connecting an iPod enables you to enjoy music from the vehicle speakers.

■ Connecting an iPod



Open the auxiliary box.




Open the cover and connect an iPod using an iPod cable.

Turn on the power of the iPod if it is not turned on.

STEP 3 Close the auxiliary box and press DIBCAUX.

*: If equipped



Selecting a play mode

Press to select iPod menu mode.

Changes the play mode in the following order:

"PLAYLISTS"→"ARTISTS"→"ALBUMS"→"SONGS"→
"PODCASTS"→"GENRES"→"COMPOSERS"→

"AUDIOBOOKS"

Press to select the desired play mode.

■ Play mode list

Play mode	First selection	Second selection	Third selection	Fourth selection
"PLAYLISTS"	Playlists select	Songs select	-	-
"ARTISTS"	Artists select	Albums select	Songs select	-
"ALBUMS"	Albums select	Songs select	-	-
"SONGS"	Songs select	-	-	-
"PODCASTS"	Albums select	Songs select	-	-
"GENRES"	Genre select	Artists select	Albums select	Songs select
"COMPOSERS"	Composers select	Albums select	Songs select	-
"AUDIOBOOKS"	Songs select	-	-	-

■ Selecting a list

to display the first selection list.

Press to select the desired item.

Pressing the knob changes to the second selection list.

Repeat the same procedure to select the desired item.

To return to the previous selection list, select "GO BACK" or press

4 ().

Selecting songs Turn or press "^" or "\" on select the desired song. Playing and pausing songs To play or pause a song, press 3 (\blacksquare). Fast-forwarding and reversing songs To fast-forward or reverse, press and hold "∧" or "∨" on Shuffle playback ■ Playing songs from one playlist or album in random order Press 1 (RAND). To cancel, press 1 (RAND) again. ■ Playing songs from all the playlists or albums in random order Press and hold 1 (RAND) until you hear a beep. To cancel, press 1 (RAND) again. Repeat play Press 2 (RPT).


To cancel, press 2 (RPT) again.


Switching the display

Press TEXT .

Each time the button is pressed, the display changes in the following order: Elapsed time \to Album title \to Track title \to Artist name

Adjusting sound quality and volume balance





■ About iPod

- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards.
- iPod is a trademark of Apple Inc., registered in the U.S. and other countries.

■ iPod functions

- When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. If a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it once again may resolve the problem.
- While connected to the system, the iPod cannot be operated with its own controls. It is necessary to use the controls of the vehicle's audio system instead.

■ iPod problems

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it.

For instructions on how to reset your iPod, refer to your iPod Owner's Manual.

■ Display

→P. 264

■ Error messages

"ERROR": This indicates a problem in the iPod or its connection.

"NO MUSIC": This indicates that there is no music data in the iPod.

"EMPTY": This indicates that some available songs are not found in a

selected playlist.

"UPDATE": This indicates that the version of the iPod is not compatible.

Upgrade your iPod software to the latest version.

■ Compatible models

Model	Generation	Software version
iPod	5th generation	Ver. 1.2.0 or higher
iPod nano	1st generation	Ver. 1.3.0 or higher
	2nd generation	Ver. 1.1.2 or higher
	3rd generation	Ver. 1.0.0 or higher
iPod touch	1st generation	Ver. 1.1.0 or higher
iPod classic	1st generation	Ver. 1.0.0 or higher

Depending on differences between models or software version etc., some models listed above might be incompatible with this system.

iPod 4th generation and earlier models are not compatible with this system. iPhone, iPod mini, iPod shuffle and iPod photo are not compatible with this system.

Items related to standards and limitations are as follows:

Maximum number of lists in device: 9999

Maximum number of songs in device: 65535

• Maximum number of songs per list: 65535

A CAUTION

Caution while driving

Do not connect iPod or operate the controls.

♠ NOTICE


To prevent damage to iPod

- Do not leave iPod in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the iPod.
- Do not push down on or apply unnecessary pressure to the iPod while it is connected as this may damage the iPod or its terminal.
- Do not insert foreign objects into the port as this may damage the iPod or its terminal.


3-2. Using the audio system Operating a USB memory*

Connecting a USB memory enables you to enjoy music from the vehicle speakers.

■ Connecting a USB memory



Open the auxiliary box.




Open the cover and connect a USB memory.

Turn on the power of the USB memory if it is not turned on.

STEP 3 Close the auxiliary box and press DIBCAUX.

*: If equipped



Selecting a folder

■ Selecting folders one at a time

Press $\boxed{5}$ (\lor) or $\boxed{6}$ (\land) to select the desired folder.

■ Returning to the first folder

Press and hold $\boxed{5}$ (\lor) until you hear a beep.

Selecting files

Turn or press "^" or "v" on RECK to select the desired file.

Fast-forwarding and reversing files

To fast-forward or reverse, press and hold " \wedge " or " \vee " on $\mathbb{T}^{(\triangle)}_{\text{SEEK}}$.



Random playback
■ Playing files from a folder in random order Press 1 (RAND).
To cancel, press 1 (RAND) again.
■ Playing all the files from a USB memory in random order
Press and hold 1 (RAND) until you hear a beep.
To cancel, press 1 (RAND) again.
Repeat play
■ Repeating a file Press 2 (RPT).
To cancel, press 2 (RPT) again.
■ Repeating all the files in a folder
Press and hold 2 (RPT) until you hear a beep.
To cancel, press 2 (RPT) again.

Switching the display

Press TEXT .

Each time the button is pressed, the display changes in the following order: Elapsed time \rightarrow Folder name \rightarrow File name \rightarrow Album title (MP3 only) \rightarrow Track title \rightarrow Artist name

■ USB memory functions

- Depending on the USB memory that is connected to the system, the device itself may not be operable and certain functions may not be available. If the device is inoperable or a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it once again may resolve the problem.
- If the USB memory still does not begin operation after being disconnected and reconnected, format the memory.

■ Display

→P. 264

■ Error messages

"ERROR": This indicates a problem in the USB memory or its con-

nection.

"NO SUPPORT": This indicates that no MP3/WMA files are included in the

USB memory.

3-2. Using the audio system

■ USB memory

Compatible devices

USB memory that can be used for MP3 and WMA playback

Compatible device formats

The following device formats can be used:

- USB communication formats: USB2.0 FS (12 mbps)
- File formats: FAT16/32 (Windows)
- · Correspondence class: Mass storage class

MP3 and WMA files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- · Maximum directory hierarchy: 8 levels
- Maximum number of folders in a device: 999 (including the root)
- · Maximum number of files in a device: 65025
- · Maximum number of files per folder: 255
- MP3 and WMA files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

There is a limit to the MP3 and WMA file standards that can be used and to the media/formats on which the files are recorded.

MP3 file compatibility

Compatible standards

MP3 (MPEG1 AUDIO LAYERII, III, MPEG2 AUDIO LAYERII, III, MPEG2.5)

· Compatible sampling frequencies

MPEG1 AUDIO LAYERII, III: 32, 44.1, 48 (kHz)

MPEG2 AUDIO LAYERII, III: 16, 22.05, 24 (kHz)

MPEG2.5: 8, 11.025, 12 (kHz)

Compatible bit rates (compatible with VBR)

MPEG1 AUDIO LAYERII, III: 32-320 (kbps)

MPEG2 AUDIO LAYERII, III: 32-160 (kbps)

MPEG2.5: 32-160 (kbps)

- Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
 - Compatible standards WMA Ver. 9
 - Compatible sampling frequencies HIGH PROFILE 32, 44.1, 48 (kHz)
 - Compatible bit rates HIGH PROFILE 32-320 (kbps, VBR)
- File names

The only files that can be recognized as MP3/WMA and played are those with the extension .mp3 or .wma.

ID3 and WMA tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3, 2.4 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

3-2. Using the audio system

MP3 and WMA playback

- When a device containing MP3 or WMA files is connected, all files in the USB memory are checked. Once the file check is finished, the first MP3 or WMA file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3 or WMA files or create any unnecessary folders.
- When the USB memory is connected and the audio source is changed to USB memory mode, the USB memory will start playing the first file in the first folder. If the same device is removed and reinserted (and the contents have not been changed), the USB memory will resume play from the same point in which it was last used.

Extensions

If the file extensions .mp3 and .wma are used for files other than MP3 and WMA files, they will be skipped (not played).

Playback

- To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
- There is a wide variety of freeware and other encoding software for MP3 and WMA files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
- Microsoft, Windows, and Windows Media are registered trademarks of Microsoft Corporation in the U.S.A. and other countries.



Caution while driving

Do not connect USB memory or operate the controls.

↑ NOTICE


■ If the auxiliary box lid cannot be fully closed

Depending on the size and shape of the USB memory that is connected to the system, the auxiliary box lid may not close fully. In this case, do not forcibly close the lid as this may damage the USB memory or the terminal, etc.

■ To prevent damage to USB memory

- Do not leave USB memory in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the player.
- Do not push down on or apply unnecessary pressure to the USB memory while it is connected as this may damage the USB memory or its terminal.
- Do not insert foreign objects into the port as this may damage the USB memory or its terminal.

3-2. Using the audio system Optimal use of the audio system*



- Displays the current mode
- Changes the following setting
- Sound quality and volume balance (→P. 289)

The sound quality and balance setting can be changed to produce the best sound.

 Automatic Sound Levelizer ON/OFF (→P. 289)

Using the audio control function

■ Changing sound quality modes

Pressing selects the mode to be changed in the following order.

*: If equipped

■ Adjusting sound quality

Turning adjusts the level.

Sound qual- ity mode	Mode displayed	Level	Turn to the left	Turn to the right
Bass*	"BAS"	-5 to 5	Low	High
Treble*	"TRE"	-5 to 5	LOW	riigii
Front/rear volume balance	"FAD"	F7 to R7	Shifts to rear	Shifts to front
Left/right volume balance	"BAL"	L7 to R7	Shifts to left	Shifts to right

^{*:} The sound quality level is adjusted individually in each audio mode.

■ Adjusting the Automatic Sound Levelizer (ASL)

When ASL is selected, turning to the right changes the amount of ASL in the order of LOW, MID and HIGH.

Turning to the left turns ASL off.

ASL automatically adjusts the volume and tone quality to compensate for varying noise levels while driving.

■ Trademark owned by SRS Labs, Inc. (vehicles without a hands-free phone system)






The audio systems utilize SRS FOCUS $^{\$}$ and SRS TruBass $^{\$}$ audio enhancement technologies, under license from SRS Labs, Inc., in all modes except AM radio mode.

FOCUS, TruBass, SRS and () symbols are trademarks of SRS Labs, Inc.


FOCUS and TruBass technologies are incorporated under license from SRS Labs, Inc.

3-2. Using the audio system Using the AUX port*

This port can be used to connect a portable audio device and listen to it through the vehicle's speakers.



Open the auxiliary box.



Open the cover and connect the portable audio device.

STEP 3 Close the auxiliary box and press DISCAUX .

■ Operating portable audio devices connected to the audio system

The volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable audio device itself.

■ When using a portable audio device connected to the power outlet


Noise may occur during playback. Use the power source of the portable audio device.

*: If equipped

3-2. Using the audio system

Using the steering wheel audio switches*

Some audio features can be controlled using the switches on the steering wheel.



- 1 Volume
- 2 Radio mode: Select radio stations

CD mode: Select tracks, files (MP3 and WMA) and discs

Bluetooth® audio mode (if equipped): Selects a track and album

iPod mode (if equipped): Selects a song

USB memory mode (if equipped): Selects a file and folder

3 Power on, select audio source

Turning on the power

Press when the audio system is turned off.

The audio system can be turned off by holding down until you hear a beep.

*: If equipped

Changing the audio source

Press when the audio system is turned on. The audio source changes as follows each time is pressed.

AM \rightarrow FM1 \rightarrow FM2 \rightarrow FM3 \rightarrow CD mode \rightarrow CD changer mode*¹ \rightarrow Bluetooth[®] audio mode*² \rightarrow AUX \rightarrow iPod or USB memory mode*² \rightarrow AM

- *1: If installed with a CD changer
- *2: If equipped

Adjusting the volume

Press "+" on to increase the volume and "-" to decrease the volume.

Hold down "+" or "-" on to continue increasing or decreasing the volume.

Selecting a radio station

- STEP 1 Press to select the radio mode.
- To scan for receivable stations, press and hold "\" or "\" on until you hear a beep.

Selecting a track/file or song

- Press to select CD, Bluetooth® audio, iPod or USB memory mode.
- STEP 2 Press "\" or "\" on to select the desired track/file or song.

3-2. Using the audio system

Selecting an album		
Selecting an abuni		
STEP 1 Press to select Bluetooth® audio mode.		
STEP 2 Press and hold "^" or "\" on 🚊 until you hear a beep.		
Selecting a folder (CD player without changer)		
STEP 1 Press to select CD or USB memory mode.		
STEP 2 Press and hold "∧" or "∨" on ⊜ until you hear a beep.		
Selecting a disc in the CD player (CD player with changer only)		
STEP 1 Press to select the CD mode.		
STEP 2 Press and hold "∧" or "∨" on □ until you hear a beep.		
A CAUTION		
■ To reduce the risk of an accident		
Exercise care when operating the audio switches on the steering wheel.		

3-3. Using the Bluetooth $^{\rm R}$ audio system Bluetooth $^{\rm R}$ audio system *

The Bluetooth[®] audio system enables you to enjoy music played on a portable digital audio player (portable player) from the vehicle speakers via wireless communication.

This audio system supports Bluetooth[®], a wireless data system capable of playing portable audio music without cables. If your portable player does not support Bluetooth[®], the Bluetooth[®] audio system will not function.

Title	Page
Using the Bluetooth® audio system	P. 299
Operating a Bluetooth® enabled portable player	P. 302
Setting up a Bluetooth [®] enabled portable player	P. 304
Bluetooth [®] audio system setup	P. 308

■ Conditions under which the system will not operate

- If using a portable player that does not support Bluetooth[®]
- If the portable player is switched off
- If the portable player is not connected
- If the portable player's battery is low
- If the portable player is behind the seat or in the glove box or console box
- If metal is covering or touching the portable player

*: If equipped

3-3. Using the Bluetooth® audio system

■ When transferring ownership of the vehicle

Be sure to initialize the system to prevent personal data from being improperly accessed. $(\rightarrow P. 329)$

■ About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

■ Compatible models

- Bluetooth[®] specifications:
 Ver. 1.1, or higher (recommended: Ver. 1.2)
- Following Profiles:
 - A2DP (Advanced Audio Distribution Profile) Ver. 1.0, or higher (Conformed: Ver. 1.2)
 - AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (Conformed: Ver. 1.3)

Portable players must correspond to the above specifications in order to be connected to the Bluetooth[®] audio system. However, please note that some functions may be limited depending on the type of portable player.

■ Certification for the Bluetooth® audio system

Panasonic Corporation Automotive Systems Company 2nd Business Unit, Multimedia 1 Business Group 4261 Ikonobe-cho, Tsuzuki-ku, Yokohama City 224-8520, Japan

DECLARATION of CONFORMITY

We. Matsushita Electric Industrial Co., Ltd. Panasonic Automotive Systems Company of the above address, hereby declare, at our sole responsibility that the following product conforms to the Essential Requirements of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EC in accordance with the tests conducted to the appropriate requirements of the relevant standards, as listed herewith.

EN60950-1: 2001, First Edition and EN60950-1: 2001 + A11: 2004, First Edition IEC 60065_2001 + Amd.1: 2005 / EN 60065_2002 + Amd.1:2006

CE

Year of affixing CE marking: 2008

Signature : Megwu Kajihara

: Engineer

Name : Meguru Kajihara

Date : July 4, 2008

Position

3-3. Using the Bluetooth® audio system



Caution while driving

Do not connect portable players or operate the controls.


↑ NOTICE

■ To prevent damage to portable players

Do not leave portable players in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the player.

3-3. Using the Bluetooth® audio system Using the Bluetooth® audio system*

■ Audio unit



1 Display

A message, name, number, etc. is displayed.

Lower-case characters and special characters cannot be displayed.


- Displays information that is too long to be displayed at one time on the display (press and hold)
- 3 Selects items such as menu and number

Turn: Selects an item
Press: Inputs the selected
item

4 Bluetooth® connection condition

If "BT" is not displayed, the Bluetooth[®] audio system cannot be used.

■ Microphone



*: If equipped

Using the Bluetooth® audio system for the first time

Before using the Bluetooth[®] audio system, it is necessary to register a Bluetooth[®] enabled portable player in the system. Follow the procedure below to register (pair) a portable player:



STEP 4 Select "Record Name" using , and say the name to be registered after the beep.

The name to be registered will be repeated aloud.

A passkey will be displayed.

STEP 6 Input the passkey into the audio player.

Refer to the manual that comes with the portable player for the operation of the portable player.

If the portable player has a Bluetooth[®] phone, the phone can be registered at the same time. (\rightarrow P. 316)

Menu list of the Bluetooth[®] audio system


■ Normal operation

First menu	Second menu	Operation detail
	"Pair Audio"	Registering a portable player
	"Select Audio"	Selecting a portable player to be used
"Setup"	"Change Name"	Changing the registered name of a portable player
	"List Audios"	Listing the registered portable players
	"Set Passkey"	Changing the passkey
	"Delete Audio"	Deleting a registered portable player

■ Operations that cannot be performed while driving

- Operating the system with
- Registering a portable player to the system
- Changing the passkey
 - →P. 307

3-3. Using the Bluetooth[®] audio system Operating a Bluetooth[®] enabled portable player*



Selecting an album

Press $\boxed{5}$ (\lor) or $\boxed{6}$ (\land).

Selecting tracks

Playing and pausing tracks

Press 3 (▶ ■).

*: If equipped

Fast-forwarding and reversing tracks

To fast-forward or reverse, press and hold " ${\scriptstyle \wedge}$ " or " ${\scriptstyle \vee}$ " on



Switching the display

Press TEXT .

Using the steering wheel audio switches

→P. 292

■ Bluetooth[®] audio system functions

Depending on the portable player that is connected to the system, certain functions may not be available.

■ Error messages

"BT AUDIO ERROR": This indicates a problem in the system.

3

Interior features

3-3. Using the Bluetooth® audio system Setting up a Bluetooth® enabled portable player*

Registering a portable player in the Bluetooth® audio system allows the system to function. The following functions can be used for registered portable players:

■ Functions and operation procedures

STEP 1 Press _____ until "BTA" is displayed.

and select "Setup" using and select "Setup" using

STEP 3 Select one of the following functions using .



- Registering a portable player "Pair Audio"
- Selecting a portable player to be used "Select Audio"
- Changing the registered name "Change Name"
- Listing the registered portable players "List Audios"
- Changing the passkey "Set Passkey"
- Deleting a registered portable player "Delete Audio"

*: If equipped

Registering a portable player

Select "Pair Audio" using , and perform the procedure for registering a portable player. (\rightarrow P. 300)

Selecting a portable player to be used

STEP 1 Select "Select Audio" using .

STEP 2 Select the portable player to be used, and select "Confirm" using ...

STEP 3 Select "From Car" or "From Audio", and select "Confirm" using



If "From Car" is selected, the portable player will be automatically connected whenever the "POWER" switch is in the ACCESSORY or ON mode.

3-3. Using the Bluetooth® audio system

Changing the registered name of a portable player

STEP 1 Select "Change Name" using .

STEP 2 Select the name of the portable player to be changed using .

STEP 3 Select "Record Name" using after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using .

Listing the registered portable players

Select "List Audios" using . The list of registered portable players will be read aloud.

When listing is complete, the system returns to "Setup".

STEP 2 Select a 4 to 8-digit number using .

The number should be input 1 digit at a time.

STEP 3 When the entire number to be registered as a passkey has

been input, press again.

If the number to be registered has 8 digits, pressing of the knob is not necessary.

Deleting a registered portable player

STEP 1 Select "Delete Audio" using

STEP 2 Select the portable player to be deleted and select "Confirm"

using The second .

If the portable player to be deleted is paired as a Bluetooth[®] phone, the registration of the mobile phone can be deleted at the same time. A voice guidance instruction to delete a mobile phone is heard.

■ The number of portable players that can be registered

Up to 2 portable players can be registered in the system.

3

Interior features

3-3. Using the Bluetooth $^{\mathbb{B}}$ audio system Bluetooth $^{\mathbb{R}}$ audio system setup *

■ System setup items and operation procedures

→P. 327

*: If equipped

3-4. Using the hands-free phone system (for cellular phone) Hands-free phone system (for cellular phone) features*

This system supports Bluetooth®, which allows you to make or receive calls without using cables to connect a cellular phone and the system, and without operating the cellular phone.

■ Hands-free system quick guide

STEP 1 Setting a cellular phone. (→P. 314)

STEP 2 Adding an entry to the phonebook (Up to 20 names can be stored). (\rightarrow P. 331)

STEP 3 Dialing by inputting a name. (\rightarrow P. 320)

*: If equipped

3-4. Using the hands-free phone system (for cellular phone)

Title	Page
Using the hands-free phone system ■ Using the hands-free phone system for the first time ■ Menu list of the hands-free phone system	P. 314
Making a phone call Dialing by inputting a name Speed dialing When receiving a phone call Transferring a call Using the call history memory	P. 320
Setting a cellular phone Registering a cellular phone Selecting the cellular phone to be used Changing a registered name Listing the registered cellular phones Deleting a cellular phone Changing the passkey Turning the hands-free phone automatic connection on/off	P. 323
Security and system setup Setting or changing the PIN Locking or unlocking the phone book Setting playback volume Displaying the Bluetooth® device address and name Initialization	P. 327
Using the phone book Adding a new phone number Setting speed dials Changing a registered name Deleting registered data Deleting speed dials Listing the registered data	P. 331

■ Conditions affecting operation

The hands-free phone system may not operate normally in the following situations:

- The cellular phone is turned off, or located outside the service area.
- The cellular phone has a low battery.
- The cellular phone is not connected to the system.

CTN33AI001

• The cellular phone is behind the seat or in the glove box, or metal material covers or touches the phone.

■ When transferring ownership of the vehicle

Be sure to initialize the system to prevent personal data from being improperly accessed.

■ Required profiles for the cellular phone

- HFP (Hands Free Profile) Ver. 1.0 or higher (Conformed: Ver. 1.5)
- OPP (Object Push Profile) Ver. 1.1
- About Bluetooth®



Bluetooth is a registered trademark of Bluetooth SIG. Inc.

■ Certification for the hands-free phone system

Panasonic Corporation Automotive Systems Company 2nd Business Unit, Multimedia 1 Business Group 4261 |konobe-cho, Tsuzuki-ku, Yokohama City 224-8520, Japan

DECLARATION of CONFORMITY

We. Matsushita Electric Industrial Co., Ltd. Panasonic Automotive Systems Company of the above address, hereby declare, at our sole responsibility that the following product conforms to the Essential Requirements of the Radio and Telecommunications Terminal Equipment Directive 1999/5/EC in accordance with the tests conducted to the appropriate requirements of the relevant standards, as listed herewith.

Product: Bluetooth module

Model/ Type Number: C5ZZZ0000041 / C5ZZZ0000042 / C5ZZZ0000043

* The difference of the variant model is as follows:

• Updated Hands-free version: 1.5 (current model has ver. 1.0)

Additional AV profile

Language available for Voice Recognition/ Guidance

There is no difference in the RF part or its external appearance and therefore no modification was made in radio/electrical characteristics.

Directive and Standards used: Radio: EN300 328 V1.7.1: 2006-10

EMC: EN301 489-1 V1.6.1: 2005-09 EN301 489-17 V1.2.1: 2002-08

LVD: IEC60950-1: 2001, First Edition and

EN60950-1: 2001 + A11: 2004, First Edition IEC 60065_2001 + Amd.1: 2005 / EN 60065_2002 +

CE

Amd.1:2006

Year of affixing CE marking: 2008

Signature : Megwu Kajihara

Name : Meguru Kajihara

Position : Engineer

Date : July 4, 2008



Caution while driving

Do not use a cellular phone, or connect the Bluetooth[®] phone.


↑ NOTICE

To prevent damage to a cellular phone

Do not leave a cellular phone in the vehicle. The temperature inside may become high resulting in damage to the phone.

3-4. Using the hands-free phone system (for cellular phone) Using the hands-free phone system (for cellular phone)*

■ Audio unit



1 Display

A message, name, phone number, etc. is displayed.

Lower-case characters and special characters cannot be displayed.

- Displays information that is too long to be displayed at one time on the display (press and hold)
- Selects speed dials
- Selects items such as menu or number


Turn: Selects an item
Press: Inputs the selected
item

5 Bluetooth[®] connection condition and reception level

If "BT" is not displayed, the hands-free phone system cannot be used.

*: If equipped

■ Steering wheel




1 Volume

The voice guidance volume cannot be adjusted using this button.

- On-hook switch Turns the hands-free system off/ends a call/refuses a call
- 3 Off-hook switch
 Turns the hands-free system on/starts a call
- Talk switch Turns the voice command system on (press)/turns the voice command system off (press and hold)

■ Microphone



Using the hands-free phone system for the first time

Before using the hands-free phone system, it is necessary to register a cellular phone in the system. The phone registration mode will be entered automatically when starting the system with no cellular phone registered. Follow the procedure below to register a cellular phone:

STEP 1 Press the off-hook switch or the talk switch.

STEP 2 Select "Pair Phone" using

STEP 3 Select "Record Name" using , and say the name to be registered after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using .

▶ Registration to the hands-free phone system only

STEP 5 Select "Phone Only" using

► Registration to the hands-free phone system and Bluetooth[®] audio system at the same time

STEP 5 Select "Int. Audio" using

A passkey will be displayed.

STEP 6 Input the passkey into the cellular phone.

Refer to the manual that comes with the cellular phone for the operation of the phone.

Menu list of the hands-free phone system

■ Normal operation

First menu	Second menu	Third menu	Operation detail
"Callback"	-	-	Dialing a number stored in the incoming call history memory
"Redial"	-	-	Dialing a number stored in the outgoing call history memory
"Phonebook"	"Add Entry"	-	Adding a new number
	"Change Name"	-	Changing a name in the phone book
	"Delete Entry"	-	Deleting the phone book data
	"Del Spd Dial"	-	Deleting a registered speed dial
	"List Names"	-	Listing the phone book data
	"Speed Dial"	-	Registering a speed dial

3-4. Using the hands-free phone system (for cellular phone)

First menu	Second menu	Third menu	Operation detail
"Setup"	"Security"	"Set PIN"	Setting a PIN code
		"Phbk Lock"	Locking the phone book
		"Phbk Unlock"	Unlocking the phone book
	"Phone Setup"	"Pair Phone"	Registering the cellular phone to be used
		"Change Name"	Changing a registered name of a cellular phone
		"Delete Phone"	Deleting a registered cellular phone
		"List Phones"	Listing the registered cellular phones
		"Select Phone"	Selecting a cellular phone to be used
		"Set Passkey"	Changing the passkey
		"Hands-free power"	Setting a Hands-free power on/off
	"System Setup"	"Playback Vol"	Setting playback volume
		"Device Name"	Displaying a device information
		"Initialize"	Initialization

■ Automatic volume adjustment

When vehicle speed is 80 km/h (50 mph) or more, the volume automatically increases. The volume returns to the previous volume setting when vehicle speed drops to 70 km/h (43 mph) or less.

■ When using a voice command

For numbers, say a combination of single digits from zero to nine, # (pound), * (star), and + (plus).

Say a command correctly and clearly.

■ Situations that the system may not recognize your voice

- When driving on a rough road
- When driving at high speeds
- When air is blowing out of the vents onto the microphone
- When the air conditioning fan emits a loud noise

■ Operations that cannot be performed while driving

- Operating the system with
- Registering a cellular phone to the system

■ Changing the passkey

→P. 325

3-4. Using the hands-free phone system (for cellular phone) Making a phone call*

■ Making a phone call

- Dialing by inputting a name
- Speed dialing
- Dialing a number stored in the outgoing history memory "Redial"
- Dialing a number stored in the incoming history memory "Call back"

■ Receiving a phone call

- Answering the phone
- Refusing the call
- Transferring a call
- Using the call history memory
 - Dialing
 - Storing data in the phone book
 - Deleting

Dialing by inputting a name

Press the talk switch and say a registered name after the beep.

The desired name or number is displayed.

STEP 2 Dial by one of the following methods:

- a. Press the off-hook switch.
- b. Select "Dial" using

*: If equipped

Speed dialing

- STEP 1 Press the off-hook switch.
- Press the preset button in which the desired number is registered.
- STEP 3 Press the off-hook switch.

When receiving a phone call

■ Answering the phone

Press the off-hook switch.

■ Refusing the call

Press the on-hook switch.

Transferring a call

A call can be transferred between the cellular phone and system while dialing, receiving a call, or during a call. Use one of the following methods:

- a. Operate the cellular phone.
 - Refer to the manual that comes with the cellular phone for the operation of the phone.
- b. Press the off-hook switch*.
- *: This operation can be performed only when transferring a call from the cellular phone to the system during a call.

Using the call history memory

Follow the procedure below to use a number stored in the call history memory:

STEP 1 Press the off-hook switch and select "Redial" (when using a number stored in the outgoing call history memory) or "Call back" (when using a number stored in the incoming call his-

STEP 2 Select the desired number using .



STEP 3 The following operations can be performed:

Dialing: Press the off-hook switch or select "Dial" using .



Storing the number in the phone book: Select "Store" and then

Deleting: Select "Delete" and then "Confirm" using



■ Call history

Up to 5 numbers can be stored in each of the outgoing and incoming call history memories.

■ When talking on the phone

- Do not talk simultaneously with the other party.
- Keep the volume of the received voice down. Otherwise, voice echo will increase.

3-4. Using the hands-free phone system (for cellular phone) Setting a cellular phone*

Registering a cellular phone in the hands-free phone system allows the system to function. The following functions can be used for registered cellular phones:

■ Functions and operation procedures

To enter the menu for each function, follow the steps below using



- Registering a cellular phone
 - 1. "Setup" \rightarrow 2. "Phone Setup" \rightarrow 3. "Pair Phone"
- Selecting the cellular phone to be used
 - 1. "Setup" \rightarrow 2. "Phone Setup" \rightarrow 3. "Select Phone"
- Changing a registered name
 - 1. "Setup" \rightarrow 2. "Phone Setup" \rightarrow 3. "Change Name"
- Listing the registered cellular phones
 - 1. "Setup" \rightarrow 2. "Phone Setup" \rightarrow 3. "List Phones"
- Deleting a cellular phone
 - 1. "Setup" \rightarrow 2. "Phone Setup" \rightarrow 3. "Delete Phone"
- Changing the passkey
 - 1. "Setup" → 2. "Phone Setup" → 3. "Set Passkey"
- Turning the hands-free phone automatic connection on/off
 - 1. "Setup" \rightarrow 2. "Phone Setup" \rightarrow 3. "Hands-free power"

Registering a cellular phone

Select "Pair Phone" using , and do the procedure for registering a cellular phone. (\rightarrow P. 316)

*: If equipped

Selecting the cellular phone to be used

STEP 1 Select "Select Phone" using .

STEP 2 Select the cellular phone to be used and select "Confirm"

using Take St.

Changing a registered name

STEP 1 Select "Change Name" using .

STEP 2 Select the cellular phone name to be changed using ...

STEP 3 Select "Record Name" using , and say the new name after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using .



lular phones to be read aloud.

When listing is complete, the system returns to "Phone Setup".

Deleting a cellular phone

STEP 1 Select "Delete Phone" using .



STEP 2 Select the cellular phone to be deleted and select "Confirm"



Changing the passkey

STEP 1 Select "Set Passkey" using .



STEP 2 Select a 4 to 8-digit number using .



The number should be input 1 digit at a time.


STEP 3 When the entire number to be registered as a passkey has

been input, press again.


If the number to be registered has 8 digits, pressing of the knob is not necessary.

Turning the hands-free phone automatic connection on/off

■ Turning off the automatic connection



■ Turning on the automatic connection



■ The number of cellular phones that can be registered
Up to 6 cellular phones can be registered in the system.

3-4. Using the hands-free phone system (for cellular phone) Security and system setup*

To enter the menu of each setting, follow the steps below using



■ Security setting items and operation procedures

- Setting or changing the PIN (Personal Identification Number)
 - 1. "Setup" \rightarrow 2. "Security" \rightarrow 3. "Set PIN"
- Locking the phone book
 - 1. "Setup" \rightarrow 2. "Security" \rightarrow 3. "Phbk Lock"
- Unlocking the phone book
 - 1. "Setup" \rightarrow 2. "Security" \rightarrow 3. "Phbk Unlock"

■ System setup items and operation procedures


- Setting playback volume
 - 1. "Setup" → 2. "System Setup" → 3. "Playback Vol"
- Displaying the Bluetooth® device address and name
 - 1. "Setup" \rightarrow 2. "System Setup" \rightarrow 3. "Device Name"
- Initialization
 - 1. "Setup" \rightarrow 2. "System Setup" \rightarrow 3. "Initialize"

Setting or changing the PIN

■ Setting a PIN

STEP 1 Select "Set PIN" using .

STEP 2 Enter a PIN using



*: If equipped

3-4. Using the hands-free phone system (for cellular phone)

■ Changing the PIN

STEP 1 Select "Set PIN" using .

Enter the registered PIN using .

STEP 3 Enter a new PIN using .

Input the code 1 digit at a time.

Locking or unlocking the phone book

STEP 1 Select "Phbk Lock" or "Phbk Unlock" using ...



STEP 2 Input the PIN and select "Confirm" using .



Input the code 1 digit at a time.

Setting playback volume

STEP 1 Select "Playback Vol" using .



STEP 2 Change the playback volume.

To decrease the volume: Turn counterclockwise.

To increase the volume: Turn clockwise.

- STEP 1 Select "Device Name" using ...
- to display the Bluetooth® device address and
- STEP 3 Select "Go Back" using to return to "System Setup".

Initialization

STEP 1 Select "Initialize" and then "Confirm" using



STEP 2 Select "Confirm" again using .

3-4. Using the hands-free phone system (for cellular phone)

■ Initialization

- The following data in the system can be initialized:
 - · Phone book
 - · Outgoing and incoming call history
 - · Speed dials
 - · Registered cellular phone data
 - · Security code
 - Registered Bluetooth[®] enabled portable player data
 - · Passkeys for the cellular phones
 - Passkey for the Bluetooth[®] audio players
 - · Playback volume
 - · Receiver volume
 - · Ring tone volume
- Once the initialization has been completed, the data cannot be restored to its original state.

■ When the phone book is locked

The following functions cannot be used:

- Dialing by inputting a name
- Speed dialing
- Dialing a number stored in the call history memory
- Using the phone book

3-4. Using the hands-free phone system (for cellular phone) Using the phone book*

To enter the menu of each setting, follow the steps below using



- Adding a new phone number
 - 1. "Phonebook" \rightarrow 2. "Add Entry"
- Setting speed dial
 - 1. "Phonebook" \rightarrow 2. "Speed Dial"
- Changing a registered name
 - 1. "Phonebook" → 2. "Change Name"
- Deleting registered data
 - 1. "Phonebook" \rightarrow 2. "Delete Entry"
- Deleting speed dial
 - 1. "Phonebook" \rightarrow 2. "Del Spd Dial"
- Listing the registered data
 - 1. "Phonebook" → 2. "List Names"

Adding a new phone number

The following methods can be used to add a new phone number:

- Transferring data from the cellular phone
- Inputting a phone number using



Selecting a phone number from outgoing or incoming call history

*: If equipped

■ Adding procedure

STEP 1 Select "Add Entry" using

STEP 2 Use one of the following methods to input a telephone number:

► Transferring data from the cellular phone

STEP2-1 Select "By Phone" and then "Confirm" using



STEP2-2 Transfer the data from the cellular phone.

Refer to the manual that comes with the cellular phone for the details of transferring data.

STEP2-3 Select the desired data using .



► Inputting a phone number using

STEP2-1 Select "Manual Input" using





Input the phone number 1 digit at a time.

STEP2-1 Select "Call History" using .

STEP2-2 Select "Outgoing" or "Incoming" using .

STEP2-3 Select the desired data using .

STEP 3 Select "Record Name" using name after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using .

STEP 5 Select "Confirm" again using .

In STEP 5, selecting "Speed Dial" instead of "Confirm" registers the newly added phone number as a speed dial.

Setting speed dials

STEP 1 Select "Speed Dial" using .

STEP 2 Select the desired data using .

STEP 3 Select the desired preset button, and register the data into speed dial by either of the following methods:

a. Press the desired preset button, and select "Confirm" using



b. Press and hold the desired preset button.

Changing a registered name

STEP 1 Select "Change Name" using .

Step 2 Select the desired name to be changed using .



STEP 3 Select "Record Name" using and say the new name after the beep.

The name to be registered will be repeated aloud.

STEP 4 Select "Confirm" using .

STEP 1 Select "Delete Entry" using .

STEP 2 Select the desired data to be deleted, and select "Confirm"



Deleting speed dials

STEP 1 Select "Del Spd Dial" using

STEP 2 Press the preset button in which the desired speed dial is reg-

istered, and select "Confirm" using

Listing the registered data

Select "List Names" using . The list of the registered data will be read aloud.

When listing is complete, the system returns to "Phonebook".

Pressing the off-hook switch while an entry is being read aloud selects the entry and calls the registered phone number.


■ Limitation of number of digits

A phone number that exceeds 24 digits cannot be registered.

3

Interior features

3-5. Using the interior lights **Interior lights list**



- Interior light (→P. 337)
- 2 Personal lights (→P. 338)
- 3 "POWER" switch light
- 4 Shift lever light (if equipped)

Interior features

■ Illuminated entry system

When the interior light switch is in the "DOOR" position, the interior light and "POWER" switch light automatically turn on/off according to "POWER" switch mode, the presence of the electronic key, whether the doors are locked/unlocked and whether the doors are open/closed.


■ To prevent the 12-volt battery from being discharged

If the interior light and "POWER" switch light remain on when the door is not fully closed and the interior light switch is in the "DOOR" position, the lights will go off automatically after 20 minutes.

■ Customization that can be configured at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional


Settings (e.g. The time elapsed before lights turn off) can be changed. (Customizable features →P. 506)

Interior light




- 1 On
- 2 Off
- 3 Door position

Personal lights



On/off

3-6. Using the storage features **List of storage features**



- 1 Auxiliary boxes
- 2 Cup holders
- 3 Glove box
- 4 Console box


A CAUTION

Items that should not left in the storage space

Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:

- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.

Glove box



Pull up the lever.


A CAUTION

Caution while driving

Keep the glove box closed.

Injuries may result in the event of an accident or sudden braking.

Console box




Lift the lid while pulling the lever.

▲ CAUTION

Caution while driving

Keep the console box closed.

Injuries may result in the event of an accident or sudden braking.



Push on the lid.

A CAUTION

_

Items unsuitable for the cup holder

Do not place anything other than cups or aluminum cans in the cup holders. Other items may be thrown out of the holders in the event of an accident or sudden braking and cause injury. If possible, cover hot drinks to prevent burns.

■When not in use


Keep the cup holders closed.

Injuries may result in the event of an accident or sudden braking.

Interior features


Auxiliary boxes

► Type A



Pull up the lever.

► Type B (if equipped)



Push the lid.

▲ CAUTION

Caution while driving

Keep the auxiliary boxes closed.


Injuries may result in the event of an accident or sudden braking.

■ Items unsuitable for storing (type B only)

Do not store items heavier than 0.2 kg (0.4 lb.).


Doing so may cause the holder to open and the items inside may fall out, resulting in an accident.

3-7. Other interior features Sun visors



- 1 Forward position: Flip down.
- Side position:
 Flip down, unhook, and swing to the side.


3-7. Other interior features Vanity mirrors



Slide the cover.

The light turns on when the cover is opened.

3-7. Other interior features **Clock**



Press and hold the "CLOCK" button to allow the hour indication to flash.

Press the "CLOCK" button to adjust the hours while the hour indication is flashing.

After adjusting the hours, wait 5 seconds to allow the minute indication to flash.

Press the "CLOCK" button to adjust the minutes while the minutes indication is flashing.

After adjusting the minutes, wait 5 seconds to return the clock automatically to display the time.


■ The clock is displayed when

The "POWER" switch is in ON mode.

■When the 12-volt battery is disconnected

The time display will automatically be set to 0:00.

3-7. Other interior features Portable ashtray*



The ashtray can be installed in a cup holder. (→P. 341)

A CAUTION

When not in use

Keep the ashtray closed.

Injuries may result in the event of sudden braking, sudden swerving or an accident.


To prevent fire

- Fully extinguish matches and cigarettes before putting them in the ashtray, then make sure the ashtray is fully closed.
- Do not place paper or any other type of flammable object in the ashtray.

*: If equipped

3-7. Other interior features Cigarette lighter*


► Type A



Push the cigarette lighter down.

The cigarette lighter will pop up when it is ready for use.

► Type B



Push the center of the cigarette lighter down.

The center of the cigarette lighter will pop up when it is ready for use.

■ The cigarette lighter can be used when

The "POWER" switch is in ACCESSORY or ON mode.

*: If equipped

3-7. Other interior features


A CAUTION

■ To avoid burns or fires

- Do not touch the metal parts of the cigarette lighter.
- Do not hold the cigarette lighter down. It could overheat and cause a fire.
- Type A only: Do not put any items on the center console because it may cause the cigarette lighter to be pushed down unintentionally. It could overheat or cause a fire.
- Do not insert anything other than the cigarette lighter or Toyota genuine compressor power plug (if equipped) into the outlet.

3-7. Other interior features Power outlet*

The power outlet can be used for 12 V accessories that run on less than 10 A.



■ The power outlet can be used when

The "POWER" switch is in ACCESSORY or ON mode.

♠ NOTICE

■ To avoid damaging the power outlet

Close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.

To prevent the fuse from being blown


Do not use an accessory that uses more than 12 V 10 A.

■ To prevent 12-volt battery discharge

Do not use the power outlets longer than necessary when the hybrid system is not operating.

*: If equipped

3-7. Other interior features Seat heaters*



- Heats the left front seat
- Heats the right front seat

The indicator light comes on.

■ The seat heaters can be used when

The "POWER" switch is in ON mode.

■ When not in use

Turn the seat heater off. The indicator light turns off.

A CAUTION

Burns

- Use caution when seating the following persons in a seat with the seat heater on to avoid the possibility of burns:
 - Babies, small children, the elderly, the sick and the disabled
 - · Persons with sensitive skin
 - · Persons who are fatigued
 - Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Do not cover the seat with anything when using the seat heater.
 Using the seat heater with a blanket or cushion increases the temperature of the seat and may lead to overheating.

*: If equipped

↑ NOTICE

■ To prevent seat heater damage

Do not put unevenly weighted objects on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.


■ To prevent 12-volt battery discharge

Turn the switches off when the hybrid system is not operating.

3-7. Other interior features

Floor mat

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.



Fix the floor mat in place using the retaining hooks (clips) provided.

The shape of the retaining hooks (clips) and the fixing procedure of the floor mat for your vehicle may differ from those shown in the illustration. For details, refer to the floor mat retention clip installation instructions supplied with the clips.

A CAUTION


Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle, leading to a serious accident.

When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Toyota Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

Before driving




- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the hybrid system stopped and the P position illuminated on the shift position indicator, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.


3

3-7. Other interior features Luggage compartment features


■ Luggage undertray (type A)



■ Luggage undertray (type B)



■ Removing the luggage cover (if equipped)



- 1 Unhook the cords.
- 2 Remove the cover from the anchors.

The cover can be removed by pulling it in the direction of the arrow labeled "A".

If this does not work, pull the cover in the direction labeled "B".

↑ NOTICE

Luggage mat

To avoid deformation of the luggage mat, observe the following:

- Do not place small, heavy objects (more than 5 kg [11 lb.]) on the luggage mat. Put them in the undertray.
- When loading large objects, make sure to balance the weight of the objects evenly over the luggage undertray separators.
- Do not press hard against the luggage mat.

4 **Maintenance and care** 4-1. Maintenance and care Cleaning and protecting the vehicle exterior 356 Cleaning and protecting the vehicle interior 360 4-2. Maintenance Maintenance requirements...... 363 4-3. Do-it-yourself maintenance Do-it-yourself service precautions......366 Hood 369 Positioning a floor jack..... 371 Engine compartment...... 373 12-volt battery 381 Tire inflation pressure 390 Wheels...... 392 Air conditioning filter 394 Key battery..... 397 Checking and replacing fuses...... 400 Light bulbs 411 355

4-1. Maintenance and care

Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

■ Automatic car washes

- Before washing the vehicle, do the following:
 - · Fold the mirrors back.
 - · Remove the antenna.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

■ High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before car wash, check that the fuel filler door on your vehicle is closed properly.

■ Aluminum wheels

 Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners.

Use the same mild detergent and wax as used on the paint.


- Do not use detergent on the wheels when they are hot, for example after driving for long distance in the hot weather.
- Wash detergent from the wheels immediately after use.

■ Bumpers

Do not scrub with abrasive cleaners.

A CAUTION

When cleaning the windshield (vehicles with rain-sensing windshield wiper)



Set the wiper switch to off.

If the wiper switch is in "AUTO", the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.

- When the upper part of the windshield where the raindrop sensor is located is touched by hand
- When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor

Caution about the exhaust pipe

Exhaust gasses cause the exhaust pipe to become quite hot.

When washing the vehicle, be careful not to touch the pipe until it has cooled sufficiently, as touching a hot exhaust pipe can cause burns.

⚠ NOTICE

To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- Wash the vehicle immediately in the following cases:
 - · After driving near the sea coast
 - · After driving on salted roads
 - If you see coal tar or tree sap on the paint surface
 - If you see dead insects, insect droppings or bird droppings on the paint
 - After driving in an area contaminated with soot, oily smoke, mine dust, iron powder or chemical substances
 - · If the vehicle becomes heavily soiled in dust or mud
 - If liquids such as benzene and gasoline are spilled on the paint surface
- If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.

Cleaning the exterior lights

- Wash carefully. Do not use organic substances or scrub with a hard brush.
 This may damage the surfaces of the lights.
- Do not apply wax to the surfaces of the lights.
 Wax may cause damage to the lenses.

Antenna installation and removal precautions

- Before driving, ensure that the antenna is installed.
- When the antenna is removed, such as before entering an automatic car wash, make sure to store it in a suitable place so as not to lose it. Also, before driving, make sure to reinstall the antenna in its original position.

A I

NOTICE

When using an automatic car wash (vehicles with rain-sensing windshield wipers)

Set the wiper switch to off.

If the wiper switch is in "AUTO", the wipers may operate and the wiper blades may be damaged.

To prevent damage to the windshield wiper arms

When lifting the wiper arms away from the windshield, pull the driver side wiper arm upward first, and repeat for the passenger side. When returning the wipers to their original position, do so from the passenger side first.

High pressure car washes (vehicles with rear view monitor system)

When washing the vehicle, do not apply intensive bursts of water to the camera or camera area. Doing so may result in the camera malfunctioning.

4-1. Maintenance and care

Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

■ Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

■ Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded ventilated area.

■ Cleaning the synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a mild soap solution to the synthetic leather using a sponge or soft cloth.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

■ Caring for leather areas

Toyota recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

■ Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not apply water. Excellent results are obtained by keeping the carpet as dry as possible.

■ Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

A CAUTION

Water in the vehicle

- Do not splash or spill liquid in the vehicle, such as on the floor, in the hybrid battery (traction battery) air vents, and in the luggage compartment.
 Doing so may cause the hybrid battery, electrical components, etc. to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet.
 (→P. 130)

An electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or severe injury.

Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

<u>^</u>

NOTICE

Cleaning detergents

- Do not use organic substances such as benzene or gasoline, acidic or alkaline solutions, dye, bleach or other detergent. Doing so may discolor the vehicle interior or cause streaks or damage to painted surfaces.
- Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged.

Preventing damage to leather surfaces

Observe the following precautions to avoid damage to and deterioration of leather surfaces:

- Remove any dust or dirt from leather surfaces immediately.
- Do not expose the vehicle to direct sunlight for extended periods of time.
 Park the vehicle in the shade, especially during summer.
- Do not place items made of vinyl, plastic, or that contain wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly.

Water on the floor

Do not wash the vehicle floor with water.

Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components under the floor of the vehicle, and may also cause the body to rust.

Cleaning the inside of the rear window

- Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires.
- Be careful not to scratch or damage the heater wires.

4-2. Maintenance

Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance is essential. Toyota recommends the following maintenance:

■ Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For full details of your maintenance schedule, read the "Toyota Service Booklet" or "Toyota Warranty Booklet".

■ Do-it-yourself maintenance

What about do-it-yourself maintenance?

Many maintenance items are easy to do yourself if you have a little mechanical ability and a few basic automotive tools.

Note, however, that some maintenance tasks require special tools and skills. These are best performed by qualified technicians. Even if you're an experienced do-it-yourself mechanic, we recommend that repairs and maintenance be conducted by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional. Any authorized Toyota dealer or repairer will keep a record of maintenance, which could be useful should you ever require Warranty Service. Should you choose to select a qualified and equipped professional other than an authorized Toyota repairer to service or maintain your vehicle, we recommend that you request that a record of maintenance be kept.

■ Where to go for service?

In order to maintain your vehicle in the highest possible condition, Toyota recommends that all repairs and service operations be carried out by authorized Toyota dealers or repairers or other duly qualified and equipped professionals. For repairs and services covered by your warranty, please visit an authorized Toyota dealer or repairer, who will use genuine Toyota parts in repairing any difficulties you may encounter. There can also be advantages in utilizing authorized Toyota dealers or repairers for non-warranty repairs and services, as members of the Toyota network will be able to expertly assist you with any difficulties you may encounter.

Your Toyota dealer or repairer, or another duly qualified and equipped professional service department will perform all of the scheduled maintenance on your vehicle-reliably and economically due to their experience with Toyota vehicles.

■ Does your vehicle need repair?

Be on the alert for changes in performance and sounds, and visual tip-offs that indicate service is needed. Some important clues are:

- Engine missing, stumbling, or pinging
- Appreciable loss of power
- Strange engine noises
- A fluid leak under the vehicle (However, water dripping from the air conditioning after use is normal.)
- Change in exhaust sound (This may indicate a dangerous carbon monoxide leak. Drive with the windows open and have the exhaust system checked immediately.)
- Flat-looking tires, excessive tire squeal when cornering, uneven tire wear
- Vehicle pulls to one side when driving straight on a level road
- Strange noises related to suspension movement
- Loss of brake effectiveness, spongy feeling brake pedal, pedal almost touches the floor, vehicle pulls to one side when braking
- Engine coolant temperature continually higher than normal

If you notice any of these clues, take your vehicle to any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible. Your vehicle may need adjustment or repair.

A CAUTION

■ If your vehicle is not properly maintained

It could result in serious damage to the vehicle and possible serious injury or death.

■ Warning in handling of the 12-volt battery

12-volt battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (\rightarrow P. 381)

4-3. Do-it-yourself maintenance **Do-it-yourself service precautions**

If you perform maintenance yourself, be sure to follow the correct procedures as given in these sections.

Items	Parts and tools	
12-volt battery condition (→P. 381)	Grease Conventional wrench (for terminal clamp bolts)	
Engine/power control unit coolant level (→P. 377)	 Toyota Super Long Life Coolant or similar high quality ethylene glycol based non-silicate, non- amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology. Toyota Super Long Life Coolant is pre- mixed with 50% coolant and 50% deionized water. Funnel (used only for adding cool- ant) 	
Engine oil level (→P. 374)	 Toyota Genuine Motor Oil or equivalent Rag or paper towel Funnel (used only for adding engine oil) 	
Fuses (→P. 400)	Fuse with same amperage rating as original	
Radiator and condenser (→P. 379)	_	
Tire inflation pressure (→P. 390)	Tire pressure gauge Compressed air source	
Washer fluid (→P. 379)	Water or washer fluid containing antifreeze (for winter use) Funnel (used only for adding water or washer fluid)	

A CAUTION

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury observe the following precautions:

When working on the engine compartment

- Keep hands, clothing, and tools away from the moving fan.
- Be careful not to touch the engine, power control unit, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
- Do not leave anything that may burn easily, such as paper or rags, in the engine compartment.
- Do not smoke, cause sparks or expose an open flame to fuel. Fuel fumes are flammable.
- Take care because brake fluid can harm your hands or eyes and damage painted surfaces.
 - If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.

When working near the electric cooling fan or radiator grille

Be sure the "POWER" switch is off.

With the "POWER" switch in ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high. $(\rightarrow P. 379)$

Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in the eyes.

<u>^</u>

NOTICE

If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air. Also a backfire could cause a fire in the engine compartment.


If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, it may indicate a serious problem.


Hood

Release the lock from the inside of the vehicle to open the hood.




Pull the hood release lever.

The hood will pop up slightly.



Push the hood catch to the left and lift the hood.



Hold the hood open by inserting the supporting rod into the slot.

A CAUTION

Pre-driving check

Check that the hood is fully closed and locked.

If the hood is not locked properly, it may open while the vehicle is in motion and cause an accident, which may result in death or serious injury.

■ After installing the support rod into the slot

Make sure the rod supports the hood securely from falling down on to your head or body.

↑ NOTICE


When closing the hood

Be sure to return the support rod to its clip before closing the hood. Closing the hood with the support rod up could cause the hood to bend.


4-3. Do-it-yourself maintenance **Positioning a floor jack**

When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.

■ Front




■ Rear



CAUTION

When raising your vehicle


Make sure to observe the following to reduce the possibility of death or serious injury.



 Lift up the vehicle using a floor jack such as the one shown in the illustra-

- When using a floor jack, follow the instructions of the manual provided with the jack.
- Do not use the jack that was supplied with your vehicle.
- Do not put any part of your body or get underneath the vehicle supported only by the floor jack.
- Always use floor jack and/or automotive jack stands on a solid, flat, level surface.
- Do not start the hybrid system while the vehicle is supported by the floor
- Stop the vehicle on level, firm ground, firmly set the parking brake and push the P position switch.
- Make sure to set the floor jack properly at the jack point. Raising the vehicle with an improperly positioned floor jack will damage the vehicle and may cause the vehicle to fall off the floor jack.
- Do not raise the vehicle while someone is in the vehicle.
- When raising the vehicle, do not place any objects on top of or underneath the floor jack.

4-3. Do-it-yourself maintenance **Engine compartment**



- Engine coolant reservoir
 - (→P. 377)
- 2 Engine oil level dipstick (→P. 374)
- 3 Engine oil filler cap (→P. 375)
- 4 Power control unit coolant (→P. 377) reservoir


- 5 Fuse box
- 6 Radiator (→P. 379)
- **7** Condenser (→P. 379)
- Electric cooling fans
- Washer fluid tank (→P. 379)

Engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.


■ Checking the engine oil

Park the vehicle on level ground. After turning off the hybrid system, wait more than five minutes for the oil to drain back into the bottom of the engine.




Hold a rag under the end and pull the dipstick out.

- STEP 3 Wipe the dipstick clean.
- STEP 4 Reinsert the dipstick fully.
- Holding a rag under the end, pull the dipstick out and check the oil level.
- STEP 6 Wipe the dipstick and reinsert it fully.



■ Adding engine oil



If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.

Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	→P. 495
Oil quantity (Low → Full)	1.5 L (1.6 qt., 1.3 lmp. qt.)
Items	Clean funnel

STEP 1 Remove the oil filler cap.

STEP 2 Add engine oil slowly, checking the dipstick.

STEP 3 Install the oil filler cap by turning it clockwise.

■ Engine oil consumption

- The amount of engine oil consumed depends on the oil viscosity, the quality of the oil and the way the vehicle is driven.
- More oil is consumed under driving conditions such as high speeds and frequent acceleration and deceleration.
- A new engine consumes more oil.
- When judging the amount of oil consumption, keep in mind that the oil may have become diluted, making it difficult to judge the true level accurately.
- Oil consumption: Max. 1.0 L/1000 km (1.1 qt./600 miles, 0.9 lmp. qt./600 miles)
- If your vehicle consume more than 1.0 L (1.1 qt., 0.9 lmp. qt.) every 1000 km (600 miles), contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

A CAUTION

Used engine oil

- Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation or skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.
- Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, service station or auto parts store for information concerning recycling or disposal.
- Do not leave used engine oil within the reach of children.

↑ NOTICE

To prevent serious engine damage

Check the oil level on a regular basis.


When replacing the engine oil

- Be careful not to spill engine oil on the vehicle components.
- Avoid overfilling, as the engine could be damaged.
- Check the oil level on the dipstick every time you refill the vehicle.
- Be sure the engine oil filler cap is properly tightened.

Engine/power control unit coolant

The coolant level is satisfactory if it is between the "FULL" (full) and "LOW" (low) lines on the reservoir when the hybrid system is cold.


► Engine coolant reservoir



- Reservoir cap
- 2 Full
- 3 Low

If the level is on or below the "LOW" line, add coolant up to the "FULL" line.

► Power control unit coolant reservoir



- Reservoir cap
- 2 Full
- 3 Low

If the level is on or below the "L" line, add coolant up to the "F" line.

■ If the coolant level drops within a short time after replenishing

Visually check the radiator, hoses, coolant reservoir caps, drain cock and water pump.

If you cannot find a leak, have any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, test the cap and check for leaks in the cooling system.

■ Coolant selection

Only use "Toyota Super Long Life Coolant" or similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Enabled: -35°C [-31°F])

For more details about coolant, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.



▲ CAUTION

When the hybrid system is hot

Do not remove the coolant reservoir caps.

The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.



NOTICE

When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

If you spill coolant

Be sure to wash it off with water to prevent damage to parts or paint.

Radiator and condenser


Check the radiator and condenser and clear any foreign objects. If any of the above parts are extremely dirty or you are not sure of their condition, have your vehicle checked by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

A CAUTION

■ When the hybrid system is hot

Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.

Washer fluid



If the fluid level is extremely low add washer fluid.

Raise the cap keeping your finger pressed down on the hole in the center and check the fluid level in the tube.

A CAUTION

When refilling the washer fluid

Do not refill the washer fluid when the hybrid system is hot or operating, as the washer fluid contains alcohol and may catch fire if spilled on the hybrid system etc.

<u>^</u>

NOTICE

Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.


Diluting washer fluid

Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.


12-volt battery

■ Location




The 12-volt battery is located in the right-hand side of luggage compartment.


■ Removing the 12-volt battery cover



Remove the luggage mat.




Remove the luggage undertray.



Remove the 12-volt battery cover.

■ 12-volt battery exterior

Make sure that the 12-volt battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.



- 1 Terminals
- 2 Hold-down clamp

■ Caution symbol

The meanings of each caution symbol on the top of the 12-volt battery are as follows:

	No smoking, no naked flames, no sparks	Battery acid
	Shield eyes	Note operating instructions
(A)	Keep away from children	Explosive gas

■ Before recharging

When recharging, the 12-volt battery produces hydrogen gas which is flammable and explosive. Therefore, before recharging:

- If recharging with the 12-volt battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the 12-volt battery.

■ After recharging/reconnecting the 12-volt battery

- Vehicles with a smart entry & start system: Unlocking the doors using the entry function may not be possible immediately after reconnecting the 12-volt battery. If this happens, use the wireless remote control or the mechanical key to lock/unlock the doors.
- Start the hybrid system with the "POWER" switch in ACCESSORY mode.
 The hybrid system may not start with the "POWER" switch turned off.
 However, the hybrid system will operate normally from the second attempt.
- The "POWER" switch mode is recorded by the vehicle. If the 12-volt battery is reconnected, the vehicle will return the "POWER" switch mode to the status it was in before the 12-volt battery was disconnected. Make sure to turn the "POWER" switch off before disconnect the 12-volt battery. Take extra care when connecting the 12-volt battery if the "POWER" switch mode prior to discharge is unknown.
- When the 12-volt battery is reconnected, start the hybrid system, depress the brake pedal, and confirm that it is possible to shift into each shift position.

If the system will not start even after multiple attempts, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

A CAUTION

■ Chemicals in the 12-volt battery

The 12-volt battery contains poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the 12-volt battery:

- Do not cause sparks by touching the 12-volt battery terminals with tools.
- Do not smoke or light a match near the 12-volt battery.
- Avoid contact with eyes, skin and clothes.
- Never inhale or swallow electrolyte.
- Wear protective safety glasses when working near the 12-volt battery.
- Keep children away from the 12-volt battery.

■ Where to safely charge the 12-volt battery

Always charge the 12-volt battery in an open area. Do not charge the 12-volt battery in a garage or closed room where there is not sufficient ventilation.

How to recharge the 12-volt battery

Only perform a slow charge (4.2 A or less). The 12-volt battery may explode if charged at a quicker rate.

CAUTION

Emergency measures regarding electrolyte

- If electrolyte gets in your eyes
 - Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility.
- If electrolyte gets on your skin Wash the affected area thoroughly. If you feel pain or a burning sensation, seek medical attention immediately.
- If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary.
- If you accidentally swallow electrolyte Drink a large quantity of water or milk. Follow with milk of magnesia, beaten raw egg or vegetable oil. Get emergency medical attention immediately.

When replacing the 12-volt battery

Use a 12-volt battery designed for the AURIS HYBRID. Failure to do so may cause gas (hydrogen) to enter the passenger compartment, causing a fire or explosion.

For replacement of the 12-volt battery, contact any authorized Toyota dealer or repairer, or another duly qualified professional.



NOTICE


When recharging the 12-volt battery

Never recharge the 12-volt battery while the hybrid system is operating. Also, be sure all accessories are turned off.

Tires

Replace the tires when the treadwear indicators show.

■ Checking tires




- New tread
- Treadwear indicator
- 3 Worn tread

The location of treadwear indicators is shown by the "TWI" or " \triangle " marks, etc., molded on the sidewall of each tire.

Check spare tire condition and inflation pressure if not rotated.

■ Tire rotation



Rotate the tires in the order shown.

To equalize tire wear and help extend tire life, Toyota recommends that you rotate your tires approximately every 10000 km (6000 miles).

■ When to replace your vehicle's tires

Tires should be replaced if:

- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric or bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage

If you are not sure, consult with any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ Tire life

Any tire over 6 years old must be checked by a qualified technician even if they have seldom or never been used or damage is not obvious.

■ If the tread wears down 4 mm (0.16 in.) or more on snow tires

The effectiveness of snow tires is lost.

■ Low profile tires (17-inch tires)

Generally, low profile tires will wear more rapidly and tire grip performance will be reduced on snowy and/or icy roads when compared to standard tires. Be sure to use snow tires or tire chains on snowy and/or icy roads and drive carefully at a speed appropriate for road and weather conditions.

A CAUTION

When inspecting or replacing tires

Observe the following precautions to prevent accidents.

Failure to do so may cause damage to parts of the drive train, as well as dangerous handling characteristics, which may lead to an accident resulting in death or serious injury.

- Do not mix tires of different makes, models or tread patterns.
 Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Toyota.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle.
 Do not use tires if you do not know how they were used previously.

↑ NOTICE

Driving on rough roads

Take particular care when driving on roads with loose surfaces or pot holes. These conditions may cause losses in tire air pressure, reducing the cushioning ability of the tires. In addition driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

Low profile tires (17-inch tires)

Low profile tires may cause greater damage than usual to the wheel when receiving impact from the road surface. Therefore pay attention to the following:

- Be sure to use proper tire inflation pressure. If tires are under-inflated, they may be damaged more severely.
- Avoid pot holes, uneven pavement, curbs and other road hazards. Failure to do so can lead to severe tire and wheel damage.

If tire inflation pressures become low while driving

Do not continue driving, or your tires and/or wheels may be ruined.

4-3. Do-it-yourself maintenance **Tire inflation pressure**

Make sure to maintain the proper tire inflation pressure. Tire inflation pressure should be checked at least once per month. However, Toyota recommends that tire inflation pressure be checked once every two weeks. $(\rightarrow P. 501)$

■ Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drive train

If a tire needs frequent refilling, have it checked by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold.
 If your vehicle has been parked for at least 3 hours and has not been driven for more than 1.5 km or 1 mile, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge.
 The appearance of the tire can be misleading. In addition, tire inflation pressures that are even just a few pounds off can degrade ride and handling.
- Do not reduce tire inflation pressure after driving. It is normal for the tire inflation pressure to be higher after driving.
- Never exceed the vehicle capacity weight.
 Passengers and luggage weight should be placed so that the vehicle is balanced.

A CAUTION

Proper inflation is critical to save tire performance

Keep your tires properly inflated. Otherwise, the following conditions may occur and result in an accident causing death or serious injury.

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Poor sealing of the tire bead
- Wheel deformation and/or tire separation
- A greater possibility of tire damage from road hazards

↑ NOTICE

■ When inspecting and adjusting tire inflation pressure

Be sure to reinstall the tire valve caps.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps have been lost, replace them as soon as possible.

4-3. Do-it-yourself maintenance Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause loss of handling control.

■ Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width, and inset*.

Replacement wheels are available at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

*: Conventionally referred to as "offset".

Toyota does not recommend using:

- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

Aluminum wheel precautions


- Use only Toyota wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1600 km (1000 miles).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Toyota genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

A CAUTION

When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing serious injury or death.

When installing the wheel nuts




- Be sure to install the wheel nuts with the tapered end facing inward. Installing the nuts with the tapered end facing outward can cause wheel to break and eventually cause a wheel to come off while driving, which could lead to an accident resulting in death or serious injury.
- Never use oil or grease on the wheel bolts or wheel nuts. Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing an accident and resulting in death or serious injury. Remove any oil or grease from the wheel bolts or wheel nuts.

4-3. Do-it-yourself maintenance Air conditioning filter


The air conditioning filter must be cleaned or changed regularly to maintain air conditioning efficiency.

■ Removal method

STEP 1 Turn the "POWER" switch off.




Open the glove box. Slide off the damper.




Lift the glove box to disconnect the claws at the bottom and remove it.

STEP 4 Remove the filter cover.


▶ Left-hand drive vehicles



► Right-hand drive vehicles




■ Replacement method



Remove the air conditioning filter and replace it with a new one.

The "↑UP" marks shown on the filter should be pointing up.

■ Cleaning method



If the filter is dirty, clean by blowing compressed air through the filter from the downward side.

Hold the air gun 5 cm (2 in.) from the filter and blow for approximately 2 minutes at 500 kPa (5.0 kgf/cm² or bar, 72 psi).

If an air gun is not available, have the filter cleaned by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ Checking interval

Inspect, clean and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, more frequent cleaning or early replacement may be required. (For scheduled maintenance information, please refer to the "Toyota Service Booklet" or "Toyota Warranty Booklet".)

■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

<u></u> №

NOTICE

To prevent damage to the system

- When using the air conditioning system, make sure that a filter is always installed.
- When cleaning the filter, do not clean the filter with water.


4-3. Do-it-yourself maintenance **Key battery**

Replace the battery with a new one if it is depleted.


■ You will need the following items:

- Flathead screwdriver (To prevent damage to the key, cover the tip of the screwdriver with a rag.)
- Small Phillips-head screwdriver
- Lithium battery CR1632


■ Replacing the battery



Take out the mechanical key.



Remove the cover.



Remove the depleted battery.

Insert a new battery with the "+" terminal facing up.

■ If the key battery is depleted

The following symptoms may occur.

- The smart entry & start system, push button start and wireless remote control does not function properly.
- The operational range is reduced.

■ Use a CR1632 lithium battery

- Batteries can be purchased at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, jewelers, or camera stores.
- Replace only with the same or equivalent type recommended by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.
- Dispose of used batteries according to the local laws.

A CAUTION

Removed battery and other parts

Keep away from children. These parts are small and if swallowed by a child, they can cause choking. Failure to do so could result in death or serious injury.

■ Certification for the smart entry & start system and push button start RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

↑ NOTICE

For normal operation after replacing the battery

Observe the following precautions to prevent accidents.

- Always work with dry hands.
 Moisture may cause the battery to rust.
- Do not touch or move any other components inside the remote control.
- Do not bend either of the battery terminals.


Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

STEP 1 Turn the "POWER" switch off.


STEP 2 Open the fuse box cover.

► Engine compartment




Push the tab in and lift the lid off.

► Instrument panel (left-hand drive vehicles)




Remove the lid.

▶ Instrument panel (right-hand drive vehicles)



Remove the cover and then remove the lid.


STEP 3 After a system failure, see "Fuse layout and amperage ratings" (→P. 404) for details about which fuse to check.



Remove the fuse with the pullout tool.

STEP 5 Check if the fuse has blown.


► Type A



- Normal fuse
- 2 Blown fuse

Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.


► Type B



- Normal fuse
- 2 Blown fuse


Replace it with one of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

► Type C



- 1 Normal fuse
- 2 Blown fuse


Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.



Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Fuse layout and amperage ratings

■ Engine compartment




Fuse		Ampere	Circuit
1	HTR	50 A	Air conditioning system
2	RDI	30 A	Electric cooling fan
3	CDS	30 A	Electric cooling fan
4	DRL	7.5 A	Daytime running lights
5	ENG W/P	30 A	Cooling system
6	ABS MAIN NO.2	7.5 A	Brake system
7	H-LP CLN	30 A	Headlight cleaner
8	IGCT	30 A	IGCT NO.2, IGCT NO.3, PCU
9	DC/DC-S	5 A	Inverter and converter
10	P CON MAIN	7.5 A	P position control system
11	AM2	7.5 A	Hybrid system
12	ECU-B2	10 A	Air conditioning system, smart entry & start system, push button start, power windows

Fuse		Ampere	Circuit
13	TURN & HAZ	10 A	Turn signal lights
14	ETCS	10 A	Multiport fuel injection system/ sequential multiport fuel injection
15	ABS MAIN NO.1	20 A	Brake system
16	P/I 2	40 A	Horn, left-hand headlight (low beam), right-hand headlight (low beam), back-up lights, "touch screen", auto anti-glare inside rear view mirror, Toyota parking assist- sensor
17	ABS MTR 1	30 A	Brake system
18	ABS MTR 2	30 A	Brake system
19	H-LP HI MAIN	20 A	H-LP LH HI, H-LP RH HI
20	P CON MTR	30 A	P position control system
21	P/I 1	60 A	EFI MAIN, BATT FAN, IG2
22	EPS	60 A	Electric power steering
23	PCU	10 A	Hybrid system
24	IGCT NO.2	10 A	Hybrid system, P position control system, hybrid battery
25	MIR HTR	10 A	Outside rear view mirror defoggers, outside rear view mirrors
26	RAD NO.1	15 A	Audio system, "touch screen"
27	DOME	10 A	Interior light, personal lights, vanity lights, smart entry & start system, luggage compartment light
28	ECU-B	10 A	Gauge and meters, vehicle stability control system, main body ECU
29	H-LP LH HI	10 A	Left-hand headlight (high beam)
30	H-LP RH HI	10 A	Right-hand headlight (high beam)

Fuse		Ampere	Circuit
31	EFI NO.2	10 A	Multiport fuel injection system/ sequential multiport fuel injection
32	IGCT NO.3	10 A	Cooling system
33	SPARE	30 A	Spare fuse
34	SPARE	10 A	Spare fuse
35	SPARE	7.5 A	Spare fuse
36	EFI MAIN	20 A	Multiport fuel injection system/ sequential multiport fuel injection, EFI NO.2, cooling system
37	BATT FAN	10 A	Hybrid battery cooling fan
38	IG2	15 A	Multiport fuel injection system/ sequential multiport fuel injection, starting system, IGN, MET, hybrid system

■ Instrument panel



	Fuse	Ampere	Circuit
1	TAIL	10 A	Front position lights, tail lights, license plate lights, rear fog light, front fog lights, manual headlight leveling dial
2	PANEL	7.5 A	Audio system, "touch screen", cigarette lighter, glove box light, Toyota parking assist-sensor, switch illumination
3	IGN	7.5 A	SRS airbag system, multiport fuel injection system/sequential multiport fuel injection, smart entry & start system, push button start, brake system, hybrid system
4	MET	7.5 A	Gauge and meters
5	WASHER RR	10 A	Rear windshield washer
6	WIP	25 A	Windshield wipers, rain sensor
7	RR WIP	15 A	Rear window wiper
8	WASHER FR	15 A	Windshield washer
9	HTR-IG	10 A	Air conditioning system

Fuse Amper		Ampere	Circuit
10	GAUGE	10 A	Horn, left-hand headlight (low beam), right-hand headlight (low beam), back-up lights, "touch screen", auto anti-glare inside rear view mirror, Toyota parking assist- sensor
11	ECU-IG NO.2	10 A	Air conditioning system, turn signal lights, auto anti-glare inside rear view mirror, rear view monitor system, moon roof, Toyota parking assist-sensor, brake system
12	ECU-IG1 NO.1	10 A	Main body ECU, electric cooling fans, automatic headlight leveling system, electric power steering, rain-sensing windshield wipers, headlight cleaner, vehicle stability control system
13	DOOR RL	20 A	Power windows
14	DOOR RR	20 A	Power windows
15	D FR DOOR	20 A	Power windows
16	S/ROOF	20 A	Moon roof
17	P FR DOOR	20 A	Power windows
18	STOP	10 A	Stop lights, high mounted stop light, brake system, hybrid system
19	RR FOG	7.5 A	Rear fog light
20	OBD	7.5 A	On-board diagnosis system
21	FR FOG	15 A	Front fog lights
22	DBL LOCK	25 A	Multiport fuel injection system/ sequential multiport fuel injection
23	DOOR NO.1	25 A	Power door lock
24	SEAT HTR FL	10 A	Seat heater
25	SEAT HTR FR	10 A	Seat heater

Circuit Outside rear view mirrors, audio

system, "touch screen"

Cigarette lighter, power outlet

Ampere

7.5 A

15 A

Fuse

ECU-ACC

CIG

26

27

4	
~	
a	
=	
₹	
4	
۵	
3	
ဂ္ဂ	
Œ	
a	

■ After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 411)
- If the replaced fuse blows again, have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ If there is an overload in the circuits

The fuses are designed to blow, protecting the wiring harness from damage.

■ When replacing light bulbs

Toyota recommends that you use genuine Toyota products. Because certain bulbs are connected to circuits designed to prevent overload, non-genuine parts may be unusable.

A CAUTION

To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failing to do so may cause damage, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than indicated, or use any other object in place of a fuse.
- Always use a genuine Toyota fuse or equivalent.
 Never replace a fuse with a wire, even as a temporary fix.
 This can cause extensive damage or even a fire.
- Do not modify the fuse or the fuse box.

№ NOTICE

Before replacing fuses


Have the cause of electrical overload determined and repaired by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.


4-3. Do-it-yourself maintenance **Light bulbs**

You may replace the following bulbs yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

For more information about replacing other light bulbs, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.


- Prepare a replacement light bulb.
 Check the wattage of the light bulb being replaced. (→P. 503)
- **■** Front bulb locations






Replacing light bulbs

■ Headlight low beams (halogen bulbs)




Turn the bulb base counterclockwise.




Unplug the connector while depressing the lock release.

■ Headlight high beams




Turn the bulb base counterclockwise.




Unplug the connector while depressing the lock release.


■ Front fog lights




Remove the fender liner bolts and clip.



Remove the fender liner.




Unplug the connector while depressing the lock release.




Turn the bulb base counterclockwise.

■ Front position lights




Turn the bulb base counterclockwise.




Remove the light bulb.

■ Front turn signal lights




Turn the bulb base counterclockwise.




Remove the light bulb.

■ Back-up lights/rear fog light, tail lights, stop lights and rear turn signal lights




Open the back door and remove the cover.




Remove the light bulb.

- Stop light
- Back-up light
- Rear fog light
- 4 Tail light
- 5 Rear turn signal light

Remove the light bulb.




■ License plate lights



Remove the cover.

To prevent damaging the vehicle, wrap the flathead screwdriver with a tape.



Remove the light bulb.

■ Lights other than the above

If any of the lights listed below has burnt out, have it replaced by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

- Headlight low beams (discharge bulb)
- Side turn signal lights
- High mounted stoplight
- Daytime running lights

■ Discharge headlights (if equipped)

If voltage to the discharge bulbs is insufficient, the bulbs may not come on, or may go out temporarily. The discharge bulbs will come on when normal power is restored.

■ LED light bulbs

The high mounted stoplight, side turn signal lights and daytime running lights consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to any authorized Toyota dealer or repairer, or another duly qualified and equipped professional to have the light replaced.

■ Condensation build-up on the inside of the lens


Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, for more information in the following situations. Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction.

- Large drops of water are built up on the inside of the lens.
- Water has built up inside the headlight.

■ When replacing light bulbs

→P. 410

■ Installing the fender liner clip



Install the clip.

A CAUTION

Replacing light bulbs

- Turn off the lights. Do not attempt to replace the bulb immediately after turning off the lights.
 - The bulbs become very hot and may cause burns.
- Do not touch the glass portion of the light bulb with bare hands. Hold the bulb by the plastic or metal portion.
 - If the bulb is scratched or dropped it may blow out or crack.
- Fully install light bulbs and any parts used to secure them. Failing to do so may result in heat damage, fire, or water entering the headlight unit. This may damage the headlights or cause condensation to build up on the lens.

Discharge headlights (if equipped)

- Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, before replacing discharge headlights (including light bulbs).
- Do not touch the high-intensity discharge headlight's high voltage socket when the headlights are turned on.
 - An extremely high voltage of 20000 V will be discharged and could result in serious injury or death by electric shock.
- Do not attempt to take apart or repair the low beam discharge headlight bulbs, connectors, power supply circuits, or related components. Doing so could result in electric shock and serious injury or death.

To prevent damage or fire

Make sure bulbs are fully seated and locked.

When trouble arises


5

5-1. Essential information

5-2. Steps to take in an emergency

5-1. Essential information **Emergency flashers**

Use the emergency flashers if the vehicle malfunctions or is involved in an accident.



Press the switch to flash all the turn signal lights. To turn them off, press the switch once again.

⚠ NOTICE

To prevent 12-volt battery discharge

Do not leave the emergency flashers on longer than necessary when the hybrid system is not operating.

5

5-1. Essential information If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, such as or a commercial towing service, using a lift-type truck or a flat bed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

Before towing


The following may indicate a problem with your transmission. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, before towing.

- The hybrid system is operating, but the vehicle will not move.
- The vehicle makes an abnormal sound.

Emergency towing

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using a cable or chain secured to the emergency towing eyelet. This should only be attempted on hard, surfaced roads for short distances at under 30 km/h (18 mph).

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.



Towing eyelet


If emergency towing cannot be performed

The vehicle cannot be towed by another vehicle in the following situations because the front wheels may be locked by the parking lock. Transport the vehicle with both front wheels or all 4 wheels lifted using a flatbed or wheel-lift type truck.


- There is a malfunction in the smart entry & start system
- · There is a malfunction in the push button start
- The P position control system is malfunctioning. (→P. 437)
- The 12-volt battery is discharged.



Remove the eyelet cover by pushing outside of it.



Insert the towing eyelet into the hole and tighten partially by hand.



Tighten down the towing eyelet securely using a wheel nut wrench.

When trouble arises


Towing with a sling-type truck



Do not tow with a sling-type truck to prevent body damage.


Towing with a wheel lift-type truck

▶ From the front




Release the parking brake.

▶ From the rear



Use a towing dolly under the front wheels.

Using a flat bed truck



When using a chain or strap to tie down the rear of the vehicle, secure it at a 45° angle as shown in the illustration.

Do not overly tighten the tie downs or the vehicle may be damaged.

■ Emergency towing procedure

- Turn the "POWER" switch to ON mode.

 Do not turn the "POWER" switch to ACCESSORY mode.
- STEP 2 Release the parking brake.
- Change the shift position to N.

 When the "POWER" switch is in ACCESSORY mode, the shift position cannot be changed to N.

■ Location of the emergency towing eyelet

→P. 447, 459

5

When trouble arises

A CAUTION

Caution while towing

- Use extreme caution when towing the vehicle. Avoid sudden starts or erratic driving maneuvers which place excessive stress on the emergency towing eyelet and the cables or chains. Always be cautious of the surroundings and other vehicles while towing.
- Do not turn the "POWER" switch off. This may lead to accidents as the parking lock will be engaged.
- If the hybrid system is not operating, the power assist for the brakes and steering will not function, making steering and braking more difficult.

Installing towing eyelet to the vehicle

Make sure that towing eyelet is installed securely. If not securely installed, towing eyelet may come loose during towing. This may lead to accidents that cause death or serious injury.

NOTICE

To prevent causing serious damage to the transmission

Never tow the vehicle from the rear with the front wheels on the ground. This may cause serious damage to the transmission.

To prevent damaging the vehicle when towing using a wheel-lift type

When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

To prevent body damage when towing using a sling-type truck

Do not tow with a sling-type truck, either from the front or rear.

5-1. Essential information If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.

Visible symptoms

- Fluid leaks under the vehicle (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge continually indicates that the temperature is higher than normal

Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the hybrid system

Operational symptoms

- Engine missing, stumbling or running rough
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

5-2. Steps to take in an emergency If a warning light turns on or a warning buzzer sounds...

Calmly perform the following actions if any of the warning lights turn on or flash. If a light turns on or flashes, but then turns off, this does not necessarily indicate a malfunction in the system.

Stop the vehicle immediately. Continuing to drive the vehicle may be dangerous.

The following warning indicates a possible problem in the brake system. Immediately stop the vehicle in a safe place and contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Warning light	Warning light/Details
	Brake system warning light and warning buzzer* (red indicator) • Low brake fluid • Malfunction in the brake system This light also comes on when the parking brake is not released. If the light turns off after the parking brake is fully released the system is operating normally.

*: Brake system warning buzzer:

When there is a possible problem that could affect braking performance, the warning light will come on and a warning buzzer will sound.

Parking brake engaged warning buzzer:

The buzzer sounds to indicate that the parking brake is still engaged (with the vehicle having reached a speed of 5 km/h [3 mph]).

Stop the vehicle immediately.

The following warnings indicate the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Warning light	Warning light/Details
-+	Charging system warning light Indicates a malfunction in the vehicle's charging system.
	High engine coolant temperature warning light Indicates that the engine is almost overheating. (→P. 481)

Have the vehicle inspected immediately.

Failing to investigate the cause of the following warnings may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, immediately.

Warning light	Warning light/Details
Ϋ́	Malfunction indicator lamp Indicates a malfunction in: • The hybrid system; • The electronic engine control system; • The electronic throttle control system; • The hybrid transmission control system.
*	SRS warning light Indicates a malfunction in: • The SRS airbag system; or • The seat belt pretensioner system.
(ABS)	ABS warning light Indicates a malfunction in: • The ABS; or • The brake assist system.
@!	Electric power steering system warning light (warning buzzer) Indicates a malfunction in the EPS system.
	Slip indicator light Indicates a malfunction in the VSC system, TRC system or hill-start assist control system.
(Flashes)	Cruise control indicator light (if equipped) Indicates a malfunction in the cruise control system.
	Automatic headlight leveling system warning light (if equipped) Indicates a malfunction in the automatic headlight leveling system.

Warning light	Warning light/Details
	Brake system warning light (yellow indicator) Malfunction in the electronically controlled brake system.

Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Warning light	Warning light/Details	Correction procedure
1/1	Low fuel level warning light Indicates that the amount of fuel is as follows: • Flashes 6.8 L (1.8 gal., 1.5 lmp. gal.) or less • Flashes more rapidly 4.5 L (1.2 gal., 1.0 lmp. gal.) or less	Refuel the vehicle.
(On the instrument cluster)	Driver's seat belt reminder light (warning buzzer)* Warns the driver to fasten his/her seat belt.	Fasten the seat belt.
(On the center panel)	Front passenger's seat belt reminder light (warning buzzer)* Warns the front passenger to fasten his or her seat belt.	Fasten the seat belt.

Warning light	Warning light/Details	Correction procedure
\triangle	Master warning light A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunction.	→P. 436

*: Driver's and front passenger's seat belt reminders:

The driver's and front passenger's seat belt buzzer sounds to alert the driver and front passenger that his or her seat belt is not fastened. The buzzer sounds for 30 seconds after the vehicle has reached a speed of at least 20 km/h (12 mph). Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 90 more seconds.

■ If the malfunction indicator lamp comes on while driving

The malfunction indicator lamp will come on if the fuel tank becomes completely empty. If the fuel tank is empty, refuel the vehicle immediately. The malfunction indicator lamp will go off after several trips.

If the malfunction indicator lamp does not go off, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.

■ Front passenger detection sensor and passenger seat belt reminder

- If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash, even if a passenger is not sitting in the seat.
- If a cushion is placed on the seat, the sensor may not detect a passenger, and the warning light may not operate properly.

■ Electric power steering system warning light (warning buzzer)

When the 12-volt battery charge becomes insufficient or the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.

■ When the electric power steering system warning light comes on


The steering wheel may become extremely heavy.

If the steering wheel becomes heavier than usual when operating, firmly hold and operate it using more force than usual.

When trouble arises

5-2. Steps to take in an emergency If a warning message is displayed

If a warning is shown on the multi-information display, stay calm and perform the following actions:



Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

Multi-information display

If any of the warning lights turns on again after performing the following actions, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Stop the vehicle immediately.

The following warnings indicate the possibility of damage to the vehicle that may lead to an accident. Immediately stop the vehicle in a safe place and contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Warning message	Details	
LOW OIL PRESSURE	Indicates an abnormal engine oil pressure. A buzzer also sounds. The warning light may turn on if the engine oil pressure is too low.	
CHECK HYBRID SYSTEM	Indicates a malfunction in the hybrid system. A buzzer also sounds.	

Have the vehicle inspected immediately.

Failing to investigate the cause of the following warning may lead to the system operating abnormally and possibly cause an accident. Have the vehicle inspected by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, immediately.

Warning message	Details
PLOCK MALFUNCTION WHEN PAPKING, PAPK IN FLAT PLACE AND APPLY PARKING BRAKE SECURELY	Indicates a malfunction in the P position control system. A buzzer also sounds. In this situation, there is a possibility that the parking lock mechanism will not work. When parking, park the vehicle on a flat surface and apply the parking brake securely. Also, it may not be possible to turn the "POWER" switch off. If this happens, applying the parking brake will enable the switch to be turned off.

Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Warning message	Details	Correction procedure
	Indicates that one or more of the side doors is not fully closed. The system also indicates which side doors are not fully closed. If the vehicle reaches a speed of 5 km/h (3 mph), flashes and a buzzer sounds to indicate that the side door(s) are not yet fully closed.	Make sure that all the side doors are closed.
←	Indicates that the back door is not fully closed. If the vehicle reaches a speed of 5 km/h (3 mph), flashes and a buzzer sounds to indicate that the back door is not yet fully closed.	Close the back door.
LOW FUEL	Indicates that remaining fuel is about 6.8 L (1.8 gal., 1.5 Imp. gal.) or less.	Refuel the vehicle.

Warning message	Details	Correction procedure
HYBRID SYSTEM OVERHEAT	Indicates that the hybrid system has overheated. A buzzer also sounds.	Stop and check. (→P. 481)
LOW TRACTION BATTERY SHIFT TO P POSITION (Flashing)	Indicates that the hybrid battery (traction battery) is low. The warning buzzer sounds intermittently or continuously.	Stop the vehicle and push the P position switch.
SHIFT TO P POSITION WHEN STARTING (Flashing)	Indicates that the transmission is out of P when attempting to start the hybrid system. A buzzer also sounds.	Push the P position switch before pressing the "POWER" switch.
SHIFT TO P POSITION WHEN PARKED (Flashing)	Indicates that the driver's door is opened when the transmission is out of P with the hybrid system on. A buzzer sounds continuously.	Push the P position switch.

Warning message	Details	Correction procedure
EV MODE CURRENTLY NOT AVAILABLE	Indicates that the EV-Drive Mode is not available.* A buzzer sounds twice. The reason the EV-Drive Mode is not available (the vehicle is idling, hybrid battery [traction battery] charge is low, speed is higher than the EV-Drive Mode operating speed range, accelerator pedal is depressed too much) may be displayed.	Use the EV-Drive Mode when it becomes available.
Indicates that the EV-Drive Mode has been automatically cancelled.* A buzzer sounds twice. The reason the EV-Drive Mode is not available (the hybrid battery [traction battery] charge is low, speed is higher than the EV-Drive Mode speed range, accelerator pedal is depressed too much) may be displayed.		Drive the vehicle for a while.

^{*:} For the EV-Drive Mode operating conditions (\rightarrow P. 180).

Follow the correction procedures.

After taking the specified steps to correct the suspected problem, check that the warning light turns off.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once	_	(Comes on for 8 seconds.) (Flashing)	The electronic key is not detected when attempting to start the hybrid system.	Confirm the location of the electronic key.
Once	3 times	KEY NOT DETECTED	A door other than the driver's door has been opened or closed with the "POWER" switch in any mode other than off and the electronic key outside of the detection area.	Confirm the location of the electronic key.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once	3 times	KEY NOT DETECTED	The driver's door has been opened or closed with the shift position in P, the "POWER" switch in any mode other than off and the electronic key outside of the detection area.	Turn the "POWER" switch off or confirm the location of the electronic key.
Once	Contin- uous	TURN POWER OFF KEY NOT DETECTED O (Displayed alternately) (Flashing)	The electronic key has been taken outside the vehicle and the doors have been locked without first turning the "POWER" switch to off.	Turn the "POWER" switch to off and lock the doors again.
Contin- uous	_	SHIFT TO P POSITION (Flashing)	The driver's door was opened when the shift position was not in P and the "POWER" switch was not turned off.	Push the P position switch.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Contin- uous	Contin- uous	SHIFT TO P POSITION KEY NOT DETECTED 10 (Displayed alternately) (Flashing)	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift position was not in P and the "POWER" switch was not turned off.	 Push the P position switch. Confirm the location of the electronic key.
Once	Contin- uous	KEY DETECTED IN VEHICLE (Flashing)	An attempt to lock the doors has been made using the smart entry & start system while the electronic key is inside the vehicle.	Take the electronic key outside the vehicle, and lock the doors again.
Once	_	LOW KEY BATTERY	The key battery is low.	Replace the battery. (→P. 397)

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once		DEPRESS BRAKE PEDAL, TOUGH POWER SWITCH WITH KEY (Flashes)	When the doors were unlocked with the mechanical key and then the "POWER" switch was pressed, the electronic key could not be detected in the vehicle. The electronic key could not be detected in the vehicle even after the "POWER" switch was pressed two consecutive times.	Touch the electronic key to the "POWER" switch while depressing the brake pedal.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
Once		DEPRESS BRAKE PEDAL PUSH POWER SWITCH TO START (Flashes)	The driver's door was opened and closed with the "POWER" switch turned off and then the "POWER" switch was put in ACCES-SORY mode twice without the hybrid system being started.	Press the "POWER" switch while depressing the brake pedal.
			During a hybrid system starting procedure in the event that the electronic key was not functioning properly (→P. 474), the "POWER" switch was touched with the electronic key.	Press the "POWER" switch within 10 seconds of the buzzer sound- ing.

Interior buzzer	Exterior buzzer	Warning message	Details	Correction procedure
	_	AUTO POWER OFF TO CONSERVE BATTERY	Power was turned off due to the automatic power off function.	Next time when starting the hybrid system, increase the engine speed slightly and maintain that level for approximately 5 minutes to recharge the battery.


When trouble arises


5-2. Steps to take in an emergency If you have a flat tire (vehicles with a spare tire)

Remove the flat tire and replace it with the spare provided.


- Before jacking up the vehicle
 - Stop the vehicle in a safe place on a hard, flat surface.
 - Set the parking brake.
 - Push the P position switch.
 - Stop the hybrid system.
 - Turn on the emergency flashers.
- Location of the spare tire, jack and tools

► Type A






Taking out the spare tire



Remove the luggage mat (type A), luggage undertray and jack spacer (type A) or toolbox (type B).


Loosen the center fastener that secures the spare tire.

Replacing a flat tire




Chock the tires.


Flat	tire	Wheel chock positions
Front	Left- hand side	Behind the rear right-hand side tire
Tiont	Right- hand side	Behind the rear left-hand side tire
Rear	Left- hand side	In front of the front right-hand side tire
	Right- hand side	In front of the front left-hand side tire




Slightly loosen the wheel nuts (one turn).



Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.



Raise the vehicle until the tire is slightly raised off the ground.




Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.

Installing the tire


Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, and the tire may come off the vehicle.




Install the tire and loosely tighten each wheel nut by hand by approximately the same amount.

Tighten the nuts until the tapered portion comes into loose contact with the disc wheel seat.



Lower the vehicle.



Firmly tighten each nut two or three times in the order shown in the illustration.

Tightening torque: 103 N•m (10.5 kgf•m, 76 ft•lbf)

STEP 5 Stow the tools in the locations specified below.


Jack spacer (type A) or toolbox (type B): spare tire well Jack and tool bag: luggage undertray

Flat tire: luggage compartment (on the luggage mat)

These are temporary locations while the compact spare tire is in use.


When stowing the spare tire

▶ Type A



Stow the jack spacer and jack as shown, with the jack laid flat.

▶ Type B



Stow the toolbox and jack as shown, making sure that the jack does not protrude above the top of the toolbox.

■ The compact spare tire

- The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.
 - Use the compact spare tire temporarily only in an emergency.
- Make sure to check the tire inflation pressure of the compact spare tire.
 (→P. 501)

■ If you have a flat front tire on a road covered with snow or ice

Install the compact spare tire on the rear of the vehicle. Perform the following steps and fit tire chains to the front tires.

STEP 1 Replace a rear tire with the compact spare tire.

STEP 2 Replace the flat front tire with the tire removed from the rear of the vehicle.

STEP 3 Fit tire chains to the front tires.

Manufacturer's Declaration of Conformity

Manufacturer:

ARIKAN KRİKO A.Ş Organize Sanayi Bölgesi 2.Cd.26110 ESKİŞEHİR / TURKEY

The EU Directives covered by this Declaration

2006 / 42 / EC Machinery Directive

The product covered by this declaration

JACK SUB-ASSY. PANTOGRAPH

model

0.8 ton , 1.1 ton

The basis on which conformity is being declared

The product identified above complies with the requirements of the Machinery Directive Directive above by meeting following standards

857 - ISO 8720

The technical documentation required to demonstrate that the product meets the requirement the Machinery Directive has been compiled by the signatory below and is available for inspection by the relevant enforcement authorities.

A sample of the product has been tested by the manufacturer

Technical File No :2010-TOYOTA JACK-ISO8720-1

The CE mark was first applied in:2010

Done at Shizuoka, Japan

Ahmet ARIKAN General Manager

Signature:

Date of Issue : 24.08.2010

5

When trouble arises

A CAUTION

Using the tire jack

Improper use of the tire jack may lead to death or serious injuries due to the vehicle suddenly falling off the jack.

- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire. Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Always check that the tire jack is securely set to the jack point.
- Do not put any part of your body under the vehicle supported by a jack.
- Do not start or operate the hybrid system while your vehicle is supported by the jack.
- Do not raise the vehicle while someone is in it.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.

Take particular care when lowering the vehicle to ensure that no one working on or near the vehicle will be injured.

A CAUTION

Replacing a flat tire

Observe the following precautions to reduce the risk of death or serious injury.

- Have the wheel nuts tightened with a torque wrench to 103 N•m (10.5 kgf•m, 76 ft•lbf) as soon as possible after changing wheels.
 Failure to follow these precautions could cause the nuts to loosen and the wheels may fall off, which could lead to an accident causing death or serious injury.
- Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.

When installing the wheel nuts

Be sure to install the wheel nuts with the tapered end facing inward. $(\rightarrow P. 393)$

Tool storage precaution (while the compact spare tire is in use)

Stow the jack and tool bag in the luggage undertray. Do not place them on the luggage mat as they may be thrown about and possibly injure people in the vehicle in the event of sudden braking or in an accident.

When using the compact spare tire

- Remember that your compact spare tire is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle.
- Do not use more than one compact spare tire simultaneously.
- Replace the compact spare tire with a standard tire as soon as possible.
- Avoid sudden acceleration, deceleration and braking, as well as sharp cornering.

■ Speed limit when using the compact spare tire

Do not drive at speeds in excess of 80 km/h (50 mph) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failing to observe this precaution may lead to an accident causing death or serious injury.

A CAUTION

When the spare tire is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS & Brake assist
- VSC
- Navigation system (if equipped)
- TRC
- Cruise control (if equipped)
- Rear view monitor system (if equipped)

NOTICE

Do not drive the vehicle with a flat tire.

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

Tool storage precaution (while the compact spare tire is in use)

Do not stow anything but the soft jack spacer (type A) or toolbox (type B) in the spare tire well. Hard, unsecured objects may damage nearby components.

Be careful when driving over bumps with the compact spare tire installed on the vehicle.

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires. Be careful when driving over uneven road surfaces.

Driving with tire chains and the compact spare tire


Do not fit tire chains to the compact spare tire.

Tire chains may damage the vehicle body and adversely affect driving performance.


5-2. Steps to take in an emergency If you have a flat tire (vehicles with an emergency tire puncture repair kit)

A puncture caused by a nail or screw passing through the tire tread can be repaired temporarily with the emergency tire puncture repair kit.

- Before repairing the vehicle
 - Stop the vehicle in a safe place on a hard, flat surface.
 - Set the parking brake.
 - Push the P position switch.
 - Stop the hybrid system.
 - Turn on the emergency flashers.
- Location of the emergency tire puncture repair kit, jack and tools
- ▶ Type A




*: Use of the jack (→P. 449)



Before putting the sealant into use

Check the degree of the tire damage before making use of the sealant in the emergency tire puncture repair kit.




A tire should only to be repaired if the damage is caused by a nail or screw passing through the tire tread. Perform the repair with the nail or screw that has punctured the tire positioned at the bottom, in contact with the ground.


Emergency repair with the sealant in the kit is not possible in the following cases. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

- When the wheel is damaged
- When two or more tires have been punctured
- When the tire is damaged due to driving without sufficient air pressure
- When the tire is visibly disengaged from the wheel
- When the tire lost air pressure due to a crack or damage in the tire sidewall
- When the cut or damage to the tread is 4 mm (0.16 in.) or more


Emergency repair method



Position the nail or screw that has punctured the tire at the bottom, in contact with the ground. Remove the cap from the valve.




Bring the protruding part of the valve core tool into contact with the valve to discharge air.




Pull out the valve core by turning it counterclockwise using the valve core tool.

STEP 4 Shake the sealant bottle up and down several times.


STEP 5 Remove the cap of the sealant bottle.




Connect the injection hose by screwing onto the sealant. As it is screwed in, the aluminum seal on the bottle will be torn.




Remove the plug from the injection hose.




Connect the injection hose to the valve.




Inject the sealant that is in the bottle. Hold and tilt the bottle, then squeeze sealant out of the bottle as shown.




Attach the sticker as shown.



Remove the injection hose from the valve and screw the valve core in the valve securely by turning it clockwise with the valve core tool.




Connect the air compressor hose by threading it on the valve.




With a power outlet: Connect the compressor power plug to the power outlet.

The "POWER" switch must be in ACCESSORY mode.




With a cigarette lighter: Remove the cigarette lighter and insert the compressor power plug into the hole.

The "POWER" switch must be in ACCESSORY mode.




Left-hand drive vehicles: Check the specified inflation pressure.

The label is placed as shown in the illustration.



Right-hand drive vehicles: Check the specified inflation pressure.

The label is placed as shown in the illustration.




Turn the compressor switch "ON" and fill the tire with air until the specified inflation pressure is reached.


STEP 16 Turn the switch "OFF" when the pressure gauge connected to the hose reads the specified pressure.

If the inflation pressure is not attained within 5 minutes, emergency repair is not possible due to severe damage. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.


- After completely filling the tire with air, disconnect the hose from the valve on the tire.
- Pull the power plug of the compressor out of the power outlet on the vehicle.
- To spread the liquid sealant evenly in the tire, immediately drive for about 5 km (3 miles) or 10 minutes.




With a power outlet: After driving about 5 km (3 miles) or 10 minutes, pull your vehicle over in a safe place and reconnect the compressor.



With a cigarette lighter: After driving about 5 km (3 miles) or 10 minutes, pull your vehicle over in a safe place and reconnect the compressor.




Read the inflation pressure on the pressure gauge.



If the pressure is 130 kPa (1.3 kgf/cm² or bar, 18 psi) or above, fill the tire with air using the compressor until the specified inflation pressure is reached.

If the pressure is less than 130 kPa (1.3 kgf/cm² or bar, 18 psi), the emergency repair that have been performed is not safe for use as damage to the tire is too severe. Do not continue to drive the vehicle. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.



Store the kit and then attach the sticker as shown.

Taking precautions to avoid sudden braking and sharp turns, drive carefully at under 80 km/h (50 mph) to the nearest authorized Toyota dealer, tire dealer or repairer, or another duly qualified and equipped professional for tire repair or replacement.

■ Sealant

- One tire can be repaired using the bottle of sealant stored in the emergency tire puncture repair kit.
- The sealant can be used when the outside temperature is from -30°C (-22°F) to 60°C (140°F).
- The sealant has a limited lifespan. The expiry date is marked on the bottle. The sealant should be replaced before the expiry date. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.
- If the sealant gets on your clothes, it may stain.
- After using the sealant, bring the empty bottle of sealant to any authorized Toyota dealer or repairer, or another duly qualified and equipped professional and purchase a new bottle. Keep the new bottle of sealant in your vehicle.

■ Compressor

- The compressor is a pneumatic filling type for passenger vehicles.
- When the compressor is operating, a loud operating noise will be produced.

This does not indicate a malfunction.

■ The wheel of a tire that has been repaired

If you remove the sealant adhering to the wheel with a rag, you can reuse the wheel.

A CAUTION

Precaution for children

Keep emergency tire puncture repair kit out of the reach of children and store it properly.

Sealant precautions

- The sealant in the emergency tire puncture repair kit is not for human consumption.
 - If the sealant is consumed inadvertently, drink a large quantity of water and get medical attention immediately.
- If sealant gets in your eyes or on your skin, thoroughly wash with a large quantity of water. If necessary, get medical attention.

When fixing the flat tire

- Stop your vehicle in a safe and flat area.
- If force is used to turn the valve core tool while air remains in the tire, special care should be taken because the valve core could fly out.
- Be careful, as sealant may fly out if you shake the bottle with the hose installed.
- If the hose is not securely installed, sealant may leak out when filling.
- Connect the valve and hose securely with the tire installed on the vehicle.
- Be careful handling the compressor, as parts of the compressor get hot during operation. Some parts of the compressor may remain hot after use.

Driving to spread the liquid sealant evenly

Drive your vehicle with due care. Be especially careful when turning and cornering.

Λ

NOTICE

Do not drive the vehicle with a flat tire

Do not continue driving with a flat tire.

Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair.

When performing an emergency repair

Perform the emergency repair without removing the nail or screw that has punctured the tread of the tire. If the object that has punctured the tire is removed, the repair using the sealant in the emergency tire puncture repair kit may fail.

When fixing the flat tire

- Do not put the valve core on dirty ground or in the sand.
 Store it in a clean place.
- Do not remove the inside cap of the sealant bottle.
- Turn the valve core tool with your hand when screwing it in. If you use another tool in conjunction with the valve core tool, damage may occur.
- Do not operate the compressor continuously for more than 7 minutes. The motor may overheat and be damaged. Let the compressor cool before using it again.

Compressor precautions

- The compressor power source should be 12 V DC suitable for vehicle use.
 Do not connect the compressor to 24 V DC or any other power source.
- The compressor is an oil-less type. Do not lubricate with oil.

5-2. Steps to take in an emergency If the hybrid system will not start

If the hybrid system still does not start after following the correct starting procedure (\rightarrow P. 175), confirm the following points.

The hybrid system will not start even if you are carrying the correct key.

One of the following may be the cause of the problem.

- The electronic key may not be functioning properly.*
 (→P. 474)
- There may not be sufficient fuel in the vehicle's tank. Refuel the vehicle.
- The electronic key battery may be discharged. (→P. 474)
- There may be a malfunction in the P position control system.
- The hybrid system may be malfunctioning due to an electrical problem such as an open circuit or a blown fuse. However, depending on the type of malfunction, an interim measure is available to start the hybrid system. (→P. 472)
- There may be a malfunction in the immobilizer system.*
 (→P. 107)
- *: It may not be possible to shift out of P.
- The interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem.

- The 12-volt battery may be discharged. (→P. 476)
- The 12-volt battery terminal connections may be loose or corroded.

The interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem.

- One or both of the 12-volt battery terminals may be disconnected.
- The 12-volt battery may be discharged. (→P. 476)

Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, if the problem cannot be repaired, or if repair procedures are unknown.

Emergency start function

When the hybrid system does not start, the following steps can be used as an interim measure to start the hybrid system if the "POWER" switch is functioning normally.

- STEP 1 Set the parking brake.
- STEP 2 Set the "POWER" switch to the ACCESSORY mode.
- Push and hold the "POWER" switch for about 15 seconds while depressing the brake pedal firmly.

Even if the hybrid system can be started using the above steps, the system may be malfunctioning. Have the vehicle checked by any authorized Toyota dealer or repairer, or another duty qualified and equipped professional.


5-2. Steps to take in an emergency **If you lose your keys**

New genuine Toyota keys can be made by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, using the other key and the key number stamped on your key number plate.

5-2. Steps to take in an emergency If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted (\rightarrow P. 48, 61) or the electronic key cannot be used because the battery is depleted, the smart entry & start system, push button start and wireless remote control cannot be used. In such cases, the doors can be opened or the hybrid system can be started by following the procedure below.

Locking and unlocking the doors




Use the mechanical key (\rightarrow P. 42) in order to perform the following operations from the driver's door:

- Locks all doors
- 2 Unlocks all doors

With an alarm: An alarm will sound if the alarm is set. $(\rightarrow P. 115)$

Changing "POWER" switch modes and starting the hybrid system

STEP 1 Apply the brakes.



Touch the Toyota emblem side of the electronic key to the "POWER" switch.

An alarm will sound to indicate that the start function cannot detect the electronic key that is touched to the "POWER" switch if any of the doors is opened and closed while the key is touched to the switch.

To change "POWER" switch modes: Within 5 seconds of the buzzer sounding, release the brake pedal and press the "POWER" switch. Modes can be changed each time the switch is pressed. (→P. 176)

To start the hybrid system: Press the "POWER" switch within 5 seconds after the buzzer sounds, keeping the brake pedal depressed.

In the event that the "POWER" switch still cannot be operated, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

■ Stopping the hybrid system

Push the P position switch and press the "POWER" switch as you normally do when stopping the hybrid system.

■ Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery depletes. $(\rightarrow P. 397)$

■ Alarm (if equipped)


Using the mechanical key to lock the doors will not set the alarm system. If a door is unlocked using the mechanical key when the alarm system is set, the alarm may be triggered. (\rightarrow P. 115)

5-2. Steps to take in an emergency If the 12-volt battery is discharged


The following procedures may be used to start the hybrid system if the vehicle's 12-volt battery is discharged.

You can call any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.


If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your Toyota following the steps below.



Open the hood and fuse block cover.



Open the exclusive jump starting terminal cover.



Connect the jumper cables.

- 1 Exclusive jump starting terminal on your vehicle
- 2 Positive (+) battery terminal on the second vehicle
- 3 Negative (-) battery terminal on the second vehicle
- Connect the jumper cable to ground on your vehicle as shown in the illustration.
- STEP 4 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the 12-volt battery of your vehicle.
- STEP 5 Maintain the engine speed of the second vehicle and turn the "POWER" switch to ON mode, then start the vehicle's hybrid system.
- Make sure the "READY" indicator comes on. If the indicator does not come on, contact at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

- Once the hybrid system has started, remove the jumper cables in the exact reverse order in which they were connected.
- STEP 8 Close the exclusive jump starting terminal cover and reinstall the fuse box cover.

Once the hybrid system starts, have the vehicle checked at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.

■ Starting the hybrid system when the 12-volt battery is discharged

The hybrid system cannot be started by push-starting.

■ Avoiding a discharged 12-volt battery

- Turn off the headlights and the audio system while the hybrid system is turned off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic, etc.

■ When the 12-volt battery is removed or discharged

- If the 12-volt battery is depleted with the shift position in P, it will not be possible to shift out of P. In this case, the vehicle cannot be towed without lifting both front wheels because the front wheels are locked by the parking lock. (→P. 423)
- The hybrid system may not start. (→P. 384)

■ Charging the 12-volt battery

The electricity stored in the 12-volt battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the 12-volt battery may discharge, and the hybrid system may be unable to start. (The 12-volt battery recharges automatically while the hybrid system is operating.)

A CAUTION

Avoiding 12-volt battery fires or explosions

Observe the following precautions to prevent accidentally igniting the flammable gas that may be emitted from the 12-volt battery:

- Make sure each jumper cable is connected to the correct terminal and that it is not unintentionally in contact with any other than the intended terminal.
- Do not allow the other end of the jumper cable connected to the "+" terminal to come into contact with any other parts or metal surfaces in the area, such as brackets or unpainted metal.
- Do not allow the + and clamps of the jumper cables to come into contact with each other.
- Do not smoke, use matches, cigarette lighters or allow open flame near the 12-volt battery.

12-volt battery precautions

The 12-volt battery contains poisonous and corrosive acidic electrolyte, while related parts contain lead and lead compounds. Observe the following precautions when handling the 12-volt battery.

- When working with the 12-volt battery, always wear safety glasses and take care not to allow any battery fluids (acid) to come into contact with skin, clothing or the vehicle body.
- Do not lean over the 12-volt battery.
- In the event that battery fluid comes into contact with the skin or eyes, immediately wash the affected area with water and seek medical attention.
 Place a wet sponge or cloth over the affected area until medical attention can be received.
- Always wash your hands after handling the battery support, terminals, and other battery-related parts.
- Do not allow children near the 12-volt battery.

A CAUTION

After recharging the 12-volt battery

Have the 12-volt battery inspected at any authorized Toyota dealer or repairer, or another duly qualified and equipped professional as soon as possible.

If the 12-volt battery is deteriorating, continued use may cause the 12-volt battery to emit a malodorous gas, which may be detrimental to the health of passengers.

When replacing the 12-volt battery

→P. 386



NOTICE

When handling jumper cables

Be careful that the jumper cables do not become tangled in the cooling fan or any of the belts when connecting or disconnecting them.

Exclusive jump starting terminal precaution

The exclusive jump starting terminal is to be used when charging the 12-volt battery from another vehicle in an emergency. It cannot be used to jump start another vehicle.

5-2. Steps to take in an emergency If your vehicle overheats

The following may indicate that your vehicle is overheating:

 The top segments of the engine coolant temperature gauge are flashing:

The engine may be overheating.

 "HYBRID SYSTEM OVERHEAT" is shown on the multi-information display:

The power control unit may be overheating.

Follow the correction procedure as described below.

Correction procedures

- If the top segments of the engine coolant temperature gauge are flashing
- Step 1 Stop the vehicle in a safe place and turn off the air conditioning system.
- STEP 2 Check to see if steam is coming out from under the hood.
 - If you see steam:

Stop the hybrid system. Carefully lift the hood after the steam subsides and then restart the hybrid system.

If you do not see steam:

Leave the hybrid system operating and carefully lift the hood.


STEP 3 Check to see if the cooling fans are operating.

If the fans are operating:


Wait until the high engine coolant temperature warning light goes off and then stop the hybrid system.

If the fans are not operating:

Stop the hybrid system immediately and call any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.



After the hybrid system has cooled down sufficiently, check the engine coolant level and inspect the radiator core (radiator) for any leaks.



If necessary, add engine coolant up to the "FULL" line.

Water can be used in an emergency measure if engine coolant is unavailable. (→P. 498)

If "HYBRID SYSTEM OVERHEAT" is shown on the multi-information display

Step 1 Stop the vehicle in a safe place and turn off the air conditioning system.

STEP 2 Leave the hybrid system operating and carefully lift the hood.

STEP 3 Check if the cooling fans are operating.


If the fans are operating:

Wait until "HYBRID SYSTEM OVERHEAT" disappears and then stop the hybrid system.

If the message does not disappear, call any authorized Toyota dealer or repair, or another duly qualified and equipped professional.


If the fans are not operating:

Stop the hybrid system immediately and call any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.



After the hybrid system has cooled down, check the power control unit coolant level and inspect the cooling system for leaks.

5-2. Steps to take in an emergency



If necessary, add power control unit coolant up to the "F" line.

Water can be used in an emergency measure if power control unit coolant is unavailable. $(\rightarrow P. 498)$

Have the vehicle checked at the nearest authorized Toyota dealer or repairer, or another duly qualified and equipped professional, as soon as possible.

Overheating

The following symptoms may occur when your vehicle is overheating:

- Hybrid system output decrease.
- Steam is coming from under the hood.

When trouble arises

A CAUTION

To prevent an accident or injury when inspecting under the hood of your vehicle

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot, causing serious injury such as burns.
- With a hybrid vehicle, there are times when the gasoline engine automatically starts to run or the cooling fans suddenly start to operate. Do not touch or approach the rotating parts of the belt or fans. Doing so may lead to fingers, clothes or tools getting caught, resulting in an accidental injury.
- Do not loosen the coolant reservoir cap while the hybrid system and radiator are hot.
 - Serious injury, such as burns, may result from hot coolant and steam released under pressure.

↑ NOTICE

When adding engine/power control unit coolant

Wait until the hybrid system has cooled down before adding engine/power control unit coolant.

When adding coolant, do so slowly. Adding cool coolant to a hot hybrid system too quickly can cause damage to the hybrid system.

5-2. Steps to take in an emergency If the vehicle becomes stuck

Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt, or snow.

- STEP 1 Set the parking brake, change the shift position to P and stop the hybrid system.
- STEP 2 Remove the mud, snow, or sand from around the stuck tire.
- STEP 3 Place wood, stones or some other material to help provide traction under the tires.
- STEP 4 Restart the hybrid system.
- STEP 5 Make sure to change the shift position to D or R, release the parking brake, and then carefully apply the accelerator to free the vehicle.

■ When changing the shift position

Depress the brake pedal and ensure that the vehicle has stopped completely before changing the shift position. Failure to do so could cause the rejection function to be activated, canceling the shift position change, or causing the shift position to change to N automatically.



CAUTION

When attempting to free a stuck vehicle

If you choose to rock the vehicle back and forth to free it, make sure the surrounding area is clear, to avoid striking other vehicles, objects or persons. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

■ When changing the shift position

Be careful not to change the shift position with the accelerator pedal depressed.

This may lead to unexpected rapid acceleration of the vehicle that may cause an accident and result in death or serious injury.

NOTICE

- To avoid damaging the transmission and other components
- Avoid spinning the wheels.
- If the vehicle remains stuck after trying these procedures, the vehicle may require towing to be freed.

5

When trouble arises

5-2. Steps to take in an emergency If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

STEP 1 Steadily step on the brake pedal with both feet and firmly depress it.

Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.

STEP 2 Change the shift position to N.


▶ If the shift position can be changed to N

After slowing down, stop the vehicle in a safe place by the road.

STEP 4 Stop the hybrid system.

▶ If the shift position cannot be changed to N

STEP 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.




Stop the hybrid system by pressing and holding the "POWER" switch for 3 consecutive seconds or more.

STEP 5 Stop the vehicle in a safe place by the road.

■ If the hybrid system has to be turned off while driving

Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the hybrid system.

When trouble arises



6 **Vehicle specifications** 6-1. Specifications Maintenance data (fuel, oil level, etc.)...... 492 Fuel information...... 504 6-2. Customization Customizable features 506 491

6-1. Specifications Maintenance data (fuel, oil level, etc.)


Dimensions and weight

Overall length		4245 mm (167.1 in.)	
Overall width		1760 mm (69.3 in.)	
Overall height*1		1510 mm (59.4 in.)	
Wheelbase		2600 mm (102.4 in.)	
Tread	Front	1535 mm (60.4 in.)* ² 1515 mm (59.6 in.)* ³	
	Rear	1535 mm (60.4 in.)* ² 1515 mm (59.6 in.)* ³	
Gross vehicle mass		1805 kg (3980 lb.)	
Maximum permissi- ble axle capacity	Front	1020 kg (2250 lb.)	
	Rear	980 kg (2160 lb.)	


^{*1:} Unladen vehicles *2: 195/65R15 tires *3: 215/45R17 tires

■ Vehicle identification number


The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Toyota. It is used in registering the ownership of your vehicle.



This number is stamped under the right-hand front seat.




On right-hand drive vehicles, this number is also stamped on the top left of the instrument panel.



This number is also on the manufacturer's label on the left-hand side center pillar.

Vehicle specifications

■ Engine number



The engine number is stamped on the engine block as shown.

Engine

Model	2ZR-FXE		
Туре	4-cylinder in line, 4-cycle, gasoline		
Bore and stroke	80.5 × 88.3 mm (3.17 × 3.48 in.)		
Displacement	1798 cm ³ (109.7 cu.in.)		
Valve clearance (engine cold)	Automatic adjustment		

Fuel

Fuel type	EU area: Unleaded gasoline conforming to European stan dard EN228 only Except EU area: Unleaded gasoline only	
Research octane number	95 or higher	
Fuel tank capacity (Reference)	45 L (11.9 gal., 9.9 lmp. gal.)	

Electric motor (Traction motor)

Туре	Permanent magnet motor	
Maximum output	60 kW	
Maximum torque	207 N•m (21.1 kgf•m, 153 ft•lbf)	

Hybrid battery (Traction battery)

Туре	Nickel-Metal hydride battery	
Voltage	7.2 V/module	
Capacity	6.5 Ah (3HR)	
Quantity	28 modules	
Overall voltage	201.6 V	

Lubrication system

Oil capacity (Drain and refill — reference)	
With filter Without filter	4.2 L (4.4 qt., 3.7 lmp. qt.) 3.9 L (4.1 qt., 3.4 lmp. qt.)

■ Engine oil selection

"Toyota Genuine Motor Oil" is used in your Toyota vehicle. Toyota recommends the use of approved "Toyota Genuine Motor Oil". Another motor oil of matching quality can also be used.

Oil grade:


0W-20, 5W-20, 5W-30 and 10W-30:

API grade SL "Energy-Conserving", SM "Energy-Conserving" or ILSAC multigrade engine oil

15W-40 and 20W-50:

API grade SL or SM multigrade engine oil

Recommended viscosity (SAE):



ITNOIL059

SAE 0W-20 is filled into your Toyota vehicle at manufacturing, and the best choice for good fuel economy and good starting in cold weather.

If SAE 0W-20 oil is not available, SAE 5W-30 oil may be used. However, it should be replaced with SAE 0W-20 at the next oil change.


If you use SAE 10W-30 or a higher viscosity engine oil in extremely low temperatures, the engine may become difficult to start, so SAE 5W-30 or lower viscosity engine oil is recommended.

The 0W portion of the oil viscosity rating indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.

The 20 in 0W-20 indicates the oil viscosity when the oil is at its operating temperature. An oil with a higher viscosity may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container labels:

Either or both API registered marks are added to some oil containers to help you select the oil you should use.



1 API Service Symbol

Top portion: The oil quality designation by API (American Petroleum Institute) (SM)

Center portion: The SAE viscosity grade (SAE 0W-20)

Lower portion: "Energy-Conserving" means that the oil has fuel-saving capabilities.

ILSAC Certification Mark

The ILSAC (International Lubricant Standardization and Approval Committee) Certification Mark is displayed on the front of the container.

Cooling system

Capacity (reference)	
Gasoline engine With an exhaust heat recovery system	7.2 L (7.6 qt., 6.3 lmp. qt.)
Without an exhaust heat recovery system	6.5 L (6.9 qt., 5.7 lmp. qt.)
Power control unit	2.1 L (2.2 qt., 1.8 lmp. qt.)
Coolant type	Use either of the following. • "Toyota Super Long Life Coolant" • Similar high-quality ethylene glycol-based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology Do not use plain water alone.

Ignition system

Spark plug	
Make	DENSO SC20HR11
Gap	1.1 mm (0.043 in.)

NOTICE

■ Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust spark plug gap.

11.5 — 11.9 V Discharged (Voltage checked 20 minutes after the hybrid system and all the lights are turned off)

4.2 A max.

Transmission

Charging rates

Fluid capacity*	3.4 L (3.6 qt., 3.0 lmp. qt.)
Fluid type	Toyota Genuine ATF WS

The fluid capacity is the quantity of reference.

If replacement is necessary, contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

NOTICE

Transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause ultimately damage the transmission of your vehicle.

Brakes

Pedal clearance *1 Left-hand drive vehicles Right-hand drive vehicles	78 mm (3.07 in.) Min. 82 mm (3.23 in.) Min.	
Pedal free play	1 — 6 mm (0.04 — 0.24 in.)	
Parking brake lever travel *2	4 — 7 clicks	
Fluid type	SAE J1703 or FMVSS No.116 DOT 3 or SAE J1704 or FMVSS No.116 DOT 4	

^{*1:} Minimum pedal clearance when depressed with a force of 196 N (20 kgf, 44 lbf) while the hybrid system is operating

Steering

Free play	Less than 30 mm (1.2 in.)
-----------	---------------------------

 $^{^{\}star2}$: Parking brake lever travel when pulled up with a force of 200 N (20.4 kgf, 45.0 lbf)

Tires and wheels

▶ 17-inch tires

Tire size	215/45R17 87W		
	Vehicle speed	Front wheel kPa (kgf/cm ² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)
Tire inflation pressure (Recommended cold tire inflation pressure)	More than 160 km/h (99 mph)	250 (2.5, 36)	250 (2.5, 36)
	160 km/h (99 mph) or less	230 (2.3, 33)	220 (2.2, 32)
Wheel size	17 × 7 J		
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)		

▶ 15-inch tires

Tire size	195/65R15 91H			
Tire inflation pressure (Recommended cold tire inflation pressure)	Vehicle speed	Front wheel kPa (kgf/cm² or bar, psi)	Rear wheel kPa (kgf/cm ² or bar, psi)	
	More than 160 km/h (99 mph)	250 (2.5, 36)	240 (2.4, 35)	
	160 km/h (99 mph) or less	250 (2.5, 36)	240 (2.4, 35)	
Wheel size	15 × 6 J			
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)			

6-1. Specifications

▶ Compact spare tire

Tire size	T125/70D17 98M
Tire inflation pressure (Recommended cold tire inflation pressure)	420 kPa (4.2 kgf/cm ² or bar, 60 psi)
Wheel size	17 × 4T
Wheel nut torque	103 N•m (10.5 kgf•m, 76 ft•lbf)

	Light Bulbs	W	Туре
Exterior	Headlights High beam Low beam (discharge bulbs) Low beam (halogen bulbs)	60 35 55	A B C
	Front turn signal lights	21	D
	Front position lights	5	E
	Front fog lights	55	С
	Rear turn signal lights	21	F
	Back-up lights	16	E
	Rear fog light	21	E
	Stop lights	16	E
	Tail lights	5	E
	License plate lights	5	E
Interior	Vanity lights	8	E
	Interior light	8	G
	Personal lights	6* ¹ 5* ²	E
	Luggage compartment light	5	G

B: D4S discharge buids
D: Single end bulbs (amber)
F: Wedge base bulbs (amber) A: HB3 halogen bulbs C: H11 halogen bulbs E: Wedge base bulbs (clear)

G: Double end bulbs

Light bulbs

*1: Vehicles without intrusion sensor

*2: Vehicles with intrusion sensor

Vehicle specifications

6-1. Specifications

Fuel information

EU area:

Your vehicle must use only unleaded gasoline conforming to European standard EN228.

For optimum engine performance, select unleaded gasoline with a Research Octane Number of 95 or higher.

Except EU area:

Your vehicle must use only unleaded gasoline.

For optimum engine performance, select unleaded gasoline with a Research Octane Number of 95 or higher.

■ Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your Toyota has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

■ If your engine knocks

- Consult any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

↑ NOTICE

Notice on fuel quality

- Do not use improper fuels. If improper fuels are used the engine will be damaged.
- Do not use leaded gasoline.
 Leaded gasoline will cause the three-way catalytic converter to lose its effectiveness and the emission control system to function improperly.
- EU area: Bioethanol fuel sold under names such as "E50" or "E85" and fuel containing a large amount of ethanol should not be used. The use of these fuels will damage the vehicle's fuel system. In case of any doubt, ask any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.
- Except EU area: Bioethanol fuel sold under names such as "E50" or "E85" and fuel containing a large amount of ethanol should not be used. Your vehicle can use gasoline mixed with 10% max ethanol. The use of fuel with more than 10% ethanol content (E10) will damage the vehicle's fuel system. You must ensure that refueling is carried out only from a source where fuel specification and quality can be guaranteed. In case of any doubt, ask any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

6-2. Customization Customizable features

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and may be performed by any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Some function settings are changed simultaneously with other functions being customized. Contact any authorized Toyota dealer or repairer, or another duly qualified and equipped professional.

Item	Function	Default setting	Customized setting
Smart entry & start sys-	Smart entry & start system	ON	OFF
tem (→P. 44)	Operation signal (Emergency flashers)	ON	OFF
Push button start (→P. 59)	Push button start	ON	OFF
	Wireless remote control	ON	OFF
	Time elapsed before automatic door lock function is activated if	30 seconds	60 seconds
Wireless remote con-	door is not opened after being unlocked		120 seconds
trol (→P. 70)	Operation signal (Emergency flashers)	ON	OFF
	Door lock buzzer	ON	OFF
	Buzzer volume	Level 7	Level 1 to 6
			OFF
Automatic light control system (→P. 206)	Light sensor sensitivity	Level 3	Level 1 to 5

Customized

setting

OFF

Default setting

ON

(→P. 208)			
	Time elapsed before	15 seconds	7.5 seconds
	lights turn off	10 30001103	30 seconds
	Operation when the doors are unlocked	ON	OFF
Illumination (→P. 336)	Operation after the "POWER" switch is turned off	ON	OFF
	Operation when you approach the vehicle with the electronic key on your person (when the interior light main switch is in the door position)	ON	OFF

Function

Daytime running light system

Item

Daytime running light system

6-2. Customization

Multi-information display (→P. 200)

Available languages	English, French, German, Italian, Spanish
Available laliguages	and Portuguese

Index		
	Abbreviation list 510	
	Alphabetical index 511 What to do if 521	
For details of equipment related touch screen, such as the aud screen" Owner's manual".		
		509

Abbreviation list Abbreviation/Acronym list

ABBREVIATIONS	MEANING
A/C	Air Conditioning
ABS	Anti-lock Brake System
ACC	Accessory
CRS	Child Restraint System
DISP	Display
ECO	Economy/Ecology
ECU	Electronic Control Unit
ELR	Emergency Locking Retractor
EPS	Electric Power Steering
GVM	Gross Vehicle Mass
LED	Light Emitting Diode
MPAC	Maximum Permissible Axle Capacity
PWR	Power
SRS	Supplemental Restraint System
TRC	Traction Control
VIN	Vehicle Identification Number
VSC	Vehicle Stability Control
VSC+	Vehicle Stability Control+

Alphabetical index **Alphabetical index**

Δ

A/C	244
ABS	228
Air conditioning filter	394
Air conditioning system	
Air conditioning filter	394
Automatic air conditioning	
system	244
Airbags	
Airbag manual on-off	
system	160
Airbag operating	
conditions	.131
Airbag precautions for	
your child	.135
Airbag warning light	432
Curtain shield airbag	
operating conditions	.131
Curtain shield airbag	
precautions	.135
General airbag precautions	
Locations of airbags	.129
Modification and disposal of	
airbags	.139
Proper driving posture 127,	135
Side airbag operating	
conditions	.131
Side airbag precautions	135
SRS airbags	129

Alarm Antenna Anti-lock brake system Ashtray Audio system	. 260 . 228
Antenna	. 260
Audio input	. 291
AUX port	. 291
CD player	. 262
iPod	. 273
MP3/WMA disc	. 267
Optimal use	. 288
Portable music player	. 291
Radio	
Steering wheel audio	
switch	. 292
Туре	. 252
USB memory	. 280
Automatic air conditioning	
system	. 244
Automatic headlight leveling	
system	. 209
Automatic light control	
system	. 206
Automatic transmission	
Automatic transmission	. 183
AUX port	. 291
Auxiliary box	. 342

В	Back door75	5
	Back-up lights	
	Replacing light bulbs41	1
	Wattage503	3
	Battery	
	Checking38	1
	Hybrid battery	
	(traction battery)38	8
	If the vehicle has a	
	discharged 12-volt	
	battery476	6
	Preparing and checking	
	before winter236	6
	Bluetooth [®] audio29	5
	Bluetooth® phone309	9
	Brake	
	Parking brake19	1
	Brake assist228	
	Break-in tips16	5
	•	
С	Care	
С	Care Exterior 356	ი
С	Exterior356	
С	Exterior	0
С	Exterior	0 1
С	Exterior	0 1 2
С	Exterior	0 1 2
С	Exterior	0 1 2 6
С	Exterior	0 1 2 6
С	Exterior	0 1 2 6
С	Exterior	0 1 2 6
С	Exterior	0 1 2 6
C	Exterior	0 1 2 6 0 0
С	Exterior	0 1 2 6 0 0
С	Exterior	0 1 2 6 0 0 0
С	Exterior	0 1 2 6 0 0 0
C	Exterior	0 1 2 6 0 0 0 3
C	Exterior	0 1 2 6 0 0 0 3
C	Exterior	0 1 2 6 0 0 0 3 4 0

Child safety	
Airbag precautions13	35
Back door	
Child restraint system 14	40
Child-protectors	73
How your child should wear	
the seat belt	39
Installing child restraints 19	50
Moon roof precautions 10)3
Power window lock switch	97
Power window precautions	99
Removed key battery	
precautions39	98
Seat belt precautions	39
Seat heater	
precautions35	50
12-volt battery	
precautions385, 47	79
	_
Child-protectors	
Child-protectors	73
Cigarette lighter34	73 47
Cigarette lighter34	73 47
Cigarette lighter34	73 47 56
Cigarette lighter 34 Cleaning 35 Exterior 35 Interior 36 Seat belts 36	73 47 56 60
Cigarette lighter 34 Cleaning Exterior 35 Interior 36 Seat belts 36 Clock 34	73 47 56 60 61
Cigarette lighter 34 Cleaning 35 Exterior 36 Interior 36 Seat belts 36 Clock 34 Condenser 37	73 47 56 60 61 45
Cigarette lighter 34 Cleaning Exterior 35 Interior 36 Seat belts 36 Clock 34	73 47 56 60 61 45
Cigarette lighter 34 Cleaning 35 Exterior 35 Interior 36 Seat belts 36 Clock 34 Condenser 35 Console box 34 Cooling system	73 47 56 60 61 45 79
Cigarette lighter 34 Cleaning 35 Exterior 35 Interior 36 Seat belts 36 Clock 34 Condenser 37 Console box 34	73 47 56 60 61 45 79
Cigarette lighter 34 Cleaning Exterior 35 Interior 36 Seat belts 36 Clock 34 Condenser 35 Console box 36 Cooling system 49 Hybrid system overheating 48 Cruise control 26	73 47 56 60 61 45 40 31
Cigarette lighter 34 Cleaning 35 Exterior 36 Interior 36 Seat belts 36 Clock 34 Condenser 35 Console box 36 Cooling system 48 Hybrid system overheating 48 Cruise control 26 Cup holder 36	73 47 56 60 61 45 79 40 81
Cigarette lighter 34 Cleaning Exterior 35 Interior 36 Seat belts 36 Clock 34 Condenser 35 Console box 36 Cooling system Hybrid system overheating 46 Cruise control 26 Cup holder 36 Curtain shield airbags 12	73 47 56 60 61 45 79 40 81 19
Cigarette lighter 34 Cleaning 35 Exterior 36 Interior 36 Seat belts 36 Clock 34 Condenser 35 Console box 36 Cooling system 48 Hybrid system overheating 48 Cruise control 26 Cup holder 36	73 47 56 60 61 45 79 40 81 19 41

D	Daytime running light
	system208
	Defogger
	Rear window251
	Side mirror251
	Dimension492
	Display
	Trip information200
	Warning message436
	Do-it-yourself maintenance 366
	Doors
	Door lock44, 70, 72
	Door windows97
	Double locking system113
	Side mirrors94
	Driver's seat belt reminder
	light433
	Driving
	Break-in tips165
	Correct posture127
	Procedures164
	Winter driving tips236

"ECO MODE" switch
If the electronic key does
not operate properly474
Replacing battery397
Emergency flashers
Switch 422
Emergency, in case of
If a warning message is
displayed436
If the electronic key does
not operate properly474
If the hybrid system will
not start471
If the vehicle has a
discharged 12-volt
battery 476
If the warning buzzer
sounds430
If the warning light
turns on430
If you have a flat tire 447, 459
If you lose your keys 473
If you think something is
wrong429
If your vehicle becomes
stuck486
If your vehicle has to be
stopped in an emergency 488
If your vehicle needs to be
towed423
If your vehicle overheats 481
Emergency shut off system 35

Emergency tire puncture	
repair kit	459
Engine	
Compartment	373
Hood	369
How to start the	
hybrid system	175
Identification number	493
If the hybrid system will	
not start	471
Ignition switch	175
Overheating	481
"POWER" switch	175
Engine coolant temperature	
gauge	193
Engine oil	
Capacity	495
Checking	374
Preparing and checking	
before winter	236
Engine/power control unit	
coolant	
Capacity	498
Checking	377
Preparing and checking	
before winter	236
EPS	228
EV-Drive Mode	180

E	l <u></u> .	
F	Floor mat	352
	Fluid	
	Washer	379
	Fog lights	
	Replacing light bulbs	411
	Switch	211
	Wattage	503
	Front fog lights	
	Replacing light bulbs	411
	Switch	211
	Wattage	503
	Front passenger's seat belt	
	reminder light	433
	Front position lights	
	Replacing light bulbs	411
	Switch	206
	Wattage	503
	Front seats	
	Adjustment	80
	Front turn signal lights	
	Replacing light bulbs	411
	Switch	190
	Wattage	503
	Fuel	
	Capacity	494
	Fuel gauge	
	Gas station information	
	Information	504
	Refueling	
	Туре	
	Fuel door	
	Fuel filler door	
	Fuses	

G	Gas station information524 Gauges193 Glove box340
Н	Hands-free phone system
	(for cellular phone)309
	Hazard lights
	Switch422
	Head restraints
	Adjusting84
	Headlight cleaner218
	Headlights
	Discharge headlight
	precautions420
	Replacing light bulbs411
	Switch
	Wattage503
	Heaters
	Seat heaters350
	Side mirror
	Horn
	Hybrid system Emergency shut off system35
	Energy monitor36
	High-voltage components34
	If the hybrid system will not
	start471
	Ignition switch175
	Indicator195
	Overheating481
	"POWER" switch175
	TOVER SWILDIT

1	Identification
	Engine493
	Vehicle493
	Ignition switch175
	Illuminated entry system 336
	Immobilizer system107
	Indicator lights197
	Inside rear view mirror92
	Interior light
	Interior light336
	Switch337
	Wattage 503
	•
J	Jack
	Positioning a floor jack371
	Vehicle-equipped
	jack447, 459
	Jack handle 447. 459
	Jack Hallule447, 439
K	Marilana antini
I.	Keyless entry44
	Keys
	Electronic key
	Engine switch175
	If the electronic key does
	not operate properly474
	If you lose your keys473
	Ignition switch175
	Key number plate42
	Keyless entry44
	Keys42
	Mechanical key42
	"POWER" switch 175
	Wireless remote control key 70

Language	
Multi-information	
display20	00
License plate lights	
Replacing light bulbs4	11
Wattage50)3
Light bulbs	
Replacing4	11
Wattage50)3
Lights	
Emergency flasher switch42	22
Fog light switch2	11
Hazard light switch42	22
Headlights switch20	
Interior light switch33	37
Personal light switch33	38
Replacing light bulbs4	11
Turn signal lever19	90
Vanity lights34	44
Wattage50	03
Luggage undertray35	53

Maintenance	
Do-it-yourself maintenance 36	6
Maintenance data49	2
Maintenance requirements 36	3
Manual headlight leveling	
dial20	7
Meter	
Instrument panel light	
control19	4
Meters19	3
Mirrors	
Inside rear view mirror9	2
Side mirror heater25	1
Side mirrors9	14
Vanity mirrors34	4
Moon roof10	0
MP3 disc26	7
Multi-information	
display 20	'n

M

_		
0	Odometer	194
	Oil	
	Engine oil	374
	Opener	
	Back door	75
	Fuel filler door	104
	Hood	369
	Outside rear view mirrors	
	Adjusting and folding	94
	Outside temperature	
	display	201
	Overheating, Hybrid	
	system	481
Р	P position switch	185
Р	P position switch	
Р	Parking brake	
Р	Parking brake Personal lights	191
P	Parking brake Personal lights Switch	191 338
P	Parking brake Personal lights Switch Wattage	338 503
P	Parking brake	338 503
Р	Parking brake	191 338 503 349 175
P	Parking brake Personal lights Switch Wattage Power outlet "POWER" switch Power windows	338 503 349 175
P	Parking brake Personal lights Switch Wattage Power outlet "POWER" switch Power windows Push button start	338 503 349 175
P	Parking brake Personal lights Switch Wattage Power outlet "POWER" switch Power windows Push button start Push button start	19133850334917597
P	Parking brake Personal lights Switch Wattage Power outlet "POWER" switch Power windows Push button start	19133850334917597

R	Radiator	379
	Radio	257
	RDS (Radio Data System)	258
	Rear fog light	
	Replacing light bulbs	411
	Switch	211
	Wattage	503
	Rear seat	
	Folding down	81
	Rear turn signal lights	
	Replacing light bulbs	411
	Wattage	503
	Rear window defogger	251
	Rear window wiper	217
	Replacing	
	Fuses	400
	Key battery	397
	Light bulbs	411
	Tires	447

7	7	3	
P	è	5	

Seat belts

Adjusting the seat belt	86
Child restraint system	
installation	.150
Cleaning and maintaining	
the seat belts	.361
Emergency Locking	
Retractor (ELR)	88
How to wear your seat belt	86
How your child should wear	
the seat belt	89
Pregnant women,	
proper seat belt use	88
Reminder light	.433
Seat belt pretensioners	87
Seat heaters	.350
Seats	
Adjustment	80
Adjustment precautions	80
Child seats/child restraint	
system installation	.150
Cleaning	.360
Head restraint	84
Properly sitting in the seat	. 127
Rear seat adjustment	81
Rear seat adjustment	
precautions	83
Seat heaters	.350

Service reminder
indicators197
Shift lever
Transmission183
Side airbags129
Side mirror
Adjusting and folding94
Smart entry & start system
Entry function44
Starting the hybrid system 175
Spare tire
Inflation pressure501
Storage location447
Spark plug 498
Specifications492
Speech command switch 315
Speedometer193
Steering wheel
Adjustment91
Audio switches292
Stop lights
Replacing light bulbs411
Wattage503

Storage feature339
Storage precautions235
Stuck
If your vehicle becomes
stuck486
Sun visors343
Sunshade
Roof101
Switch
Airbag manual on-off
switch160
"ECO MODE" switch186
Emergency flasher switch422
Engine switch175
Fog light switch211
Hazard light switch422
Ignition switch175
Light switches206
P position switch185
Power door lock switch72
"POWER" switch175
Power window switch97
"PWR MODE" switch186
Window lock switch97
Wiper and washer212, 217


Tail lights	
Replacing light bulbs	411
Switch	
Wattage	503
Talk switch	
Telephone switch	
Theft deterrent system	
Alarm	115
Double locking system	113
Immobilizer system	107
Tire inflation pressure	390
Tires	
Chains	236
Checking	387
If you have a flat tire 44	7, 459
Inflation pressure	390
Replacing	
Rotating tires	
Size	501
Snow tires	236
Spare tire	447
Tools44	7, 459
Total load capacity	492
Towing	
Emergency towing	424
Toyota parking	
assist-sensor	223
Traction control	228
Transmission	183
TRC	228
Trip information	200
Trip meter	194
Turn signal lights	
Replacing light bulbs	411
Switch	190
Wattage	503

V	Vanity lights 344 Vanity lights 344 Wattage 503 Vanity mirrors 344 Vehicle identification 493 Vehicle stability control 228 Vehicle stability control+ 228 VSC 228 VSC+ 228
W	Warning buzzers Brake system430
	Electric power steering
	system432
	Seat belt reminder433
	Warning lights
	Anti-lock brake system432 Automatic headlight
	leveling system432
	Brake assist system432
	Brake system430
	Charging system431
	Cruise control indicator
	light432
	Electric power steering
	system432
	Electronic engine control
	system432
	Low fuel level433
	Malfunction indicator lamp 432
	Master warning light433
	Pretensioners
	Seat belt reminder light433
	Slip indicator light

Warning messages	
Back door	. 438
Engine oil pressure	. 436
EV-Drive Mode	. 438
Hybrid system	. 436
Hybrid system overheat	. 438
Low fuel level	. 438
Low traction battery	. 438
Open door	. 438
P position control system	. 437
Push button start	. 441
Side doors	. 438
Smart entry & start system	. 441
Washer	
Checking	. 379
Preparing and checking	
before winter	. 236
Switch212	
Washing and waxing	. 356
Weight	. 492
Wheels	
Nindow glasses	
Nindow lock switch	97
Vindows	
Power windows	
Rear window defogger	
Washer212	
Windshield wipers	. 212
Wireless remote control key	
Replacing the battery	
Wireless remote control	
VMA disc	. 267

What to do if... What to do if...

A tire punctures	P. 447 P. 459	If you have a flat tire
	D 474	160-1-1-1-1-1-1-1
The hybrid system does not		If the hybrid system will not start Immobilizer system
start		If the 12-volt battery is discharged
The top segments of the engine coolar temperature gauge are flashing		
	P. 481	If your vehicle overheats
Steam can be seen coming from under the hood		
from under the flood		
The key is leet	D 473	If you lose your keys
The key is lost	1.473	ii you lose your keys
The 12-volt battery runs out	P. 476	If the 12-volt battery is discharged
	D 70	lau i
The doors cannot be locked	P. 72 P. 75	Side doors Back door
The horn begins to sound	P. 115	Alarm
The vehicle is stuck in	P. 486	If the vehicle becomes stuck
mud or sand		
A warning light or indicator light	P. 430	If a warning light turns on or a
comes on	P. 430	warning buzzer sounds



■Warning lights

(Brake system w	0 0	₽	Slip indicator light	
	(red indicator)	P. 430	22		P. 432
	Brake system wa (yellow indicator)	0 0	(3)	Cruise control light*	indicator P. 432
- +	Charging syste	em warn- P. 431	₽ D	Automatic headlight tem warning light	leveling sys- P. 432
	High engine co temperature w light		1/1	Low fuel level	warning P. 433
ť	Malfunction indicator lamp P. 432		Ä	Driver's seat belt reminder light P. 433	
*	SRS warning li	ight P. 432	4	Front passenger reminder light	s seat belt P. 433
(ABS)	ABS warning li	ight P. 432	Â	Master warnin	g light P. 433
@!	Electric power stee tem warning light	0 ,		J	

^{*:} The light flashes to indicate a malfunction.

What to do if...

A warning message is displayed

P. 436 If a warning message is displayed

