

DOMINAR
250
BS VI



THE WORLD'S
FAVOURITE
INDIAN

DOMINAR
250
BS VI

Bajaj Auto Limited

Akurdi, Pune - 411 035, India.

Tel : +91 20 27472851

Fax : +91 20 27407385

Customer Care : +91 7219821111

Website : www.bajajauto.com

CIN L65993PN2007PLC130076

Catálogo de Repuestos



Toda la información contenida en este manual se basa en la información más reciente sobre el producto en el momento de su publicación. Bajaj Auto Limited no acepta ninguna responsabilidad por las imprecisiones u omisiones que pueda contener esta publicación, aunque se han tomado todas las precauciones posibles para que sea lo más completa y precisa posible. Todos los procedimientos y especificaciones están sujetos a cambios sin previo aviso. Se reserva el derecho de realizar dichos cambios en cualquier momento sin previo aviso y sin incurrir en la obligación de realizar dichos cambios en productos fabricados anteriormente. Póngase en contacto con su distribuidor autorizado de Bajaj para obtener la información más reciente sobre las mejoras del producto incorporadas después de la publicación de este manual.

DOC. NO.: 71120159

REV. 07 AUG 22

Derechos de autor: Todos los derechos reservados. Ninguna parte de esta publicación puede reproducirse, almacenarse en un sistema de recuperación ni transmitirse en ninguna forma ni por ningún medio, ya sea electrónico, mecánico, fotocopiado, grabación o de otro modo, sin el permiso previo por escrito de Bajaj Auto LTD.

Prefacio



Tenemos el placer de presentar el Catálogo de Repuestos para la Motocicleta 'Dominar 250 BS VI'. Este catálogo ha sido especialmente diseñado para ayudarle a seleccionar las piezas correctas para su adquisición y mantener una disponibilidad del 100%. Los repuestos Bajaj están sujetos a estrictos estándares de control de calidad para garantizar una mayor vida útil del vehículo. Por lo tanto, es necesario que solo se utilicen Repuestos Bajaj Genuinos. En un esfuerzo continuo por mejorar el Rendimiento y la Eficiencia de los vehículos, las Especificaciones, Diagramas, Ilustraciones y Números de Piezas pueden cambiar sin previo aviso. En consecuencia, la descripción en este Catálogo de Repuestos no puede ser definitiva ni vinculante para nosotros.

Las modificaciones/alteraciones que se realicen después de la emisión de este catálogo se le comunicarán a través de nuestras Circulares de Servicio. Se le solicita que realice las correcciones necesarias en el Catálogo de Repuestos según las circulares para mantener su catálogo actualizado. Esto garantizará la entrega adecuada y rápida de los Repuestos, ya que el pedido realizado tendrá los números de pieza más recientes. En caso de necesitar asistencia técnica póngase en contacto con la Oficina Regional correspondiente o escribanos a la siguiente dirección:

Bajaj Auto Limited
Service Department
Akurdi, Pune 411 035 India

Instrucciones



- Cómo leer el catálogo:** Abra el catálogo y, en el índice de imágenes, localice el grupo en el que se encuentra la pieza que desea encontrar. Vaya al número de página correspondiente (tal como aparece en el índice de imágenes). Ahora busque la figura de la pieza que desea pedir. Anote el número de pieza junto al número de figura en particular en el texto. En caso de que tenga el número de pieza y necesite otros detalles, puede utilizar el índice de piezas. El índice de piezas (al final del catálogo) le proporcionará la figura y el número de página de la pieza que desea pedir.
- Cómo pedir piezas de repuesto:** El número de pieza y la descripción de la pieza requerida deben mencionarse invariablemente en el pedido, tal como se indica en el texto del catálogo. El último número de pieza que se comunique a través de nuestras circulares de servicio solo debe aparecer en el pedido. En caso de pedir componentes pintados, debe mencionarse el tono de color de los componentes. La cantidad que se muestra junto al número de pieza es la cantidad por vehículo para ese grupo, por lo que esa cantidad en particular debe multiplicarse por la cantidad de juegos necesarios.
- Sistema de numeración de piezas:** Hemos utilizado un sistema de 8 dígitos para los números de piezas. El modelo o el elemento de hardware se indica con los dos primeros dígitos o alfanuméricos, los dos o cuatro dígitos siguientes indican el grupo principal y los cuatro o dos últimos dígitos indican el número de serie en el grupo principal o el número de serie o subgrupo del sujetador respectivamente. Por lo tanto, los números de pieza se indicarán mediante el sistema de dígitos 2-2-4 o 2-4-2. Comprender este sistema le permitirá identificar las piezas de repuesto fácilmente.
- Abreviaturas:** En este catálogo se utilizan las siguientes abreviaturas.

Assly	Assembly	V	Volts
N.I.	Not illustrated	W	Watts
C'case	Crankcase	Accl.	Accelerator
Cyl	Cylinder	Comp.	Complete
O/s	Over size	Fr.	Front
Rr.	Rear	Std.	Standard
L	Length	A/t.	Alternate
R.H.	Right hand	L.H.	Left hand
Hex.	Hexagonal	AR	As required

YOMINAR
250

DOMINAR
250

[illegible][illegible]

Index



Plate No.	Description	Page No.
1	Cover Cylinder Head	2
2	Cylinder Head	4
3	Rocker Arm & Camshaft	6 - 10
4	Chain Guide & Tensioner Assembly	12
5	Cylinder & Piston	14
6	Crankshaft Assembly	16
7	Transmission	18
8	Change Drum / Shift Fork	20
9	Gear Change Mechanism	22
10	Engine Assembly / Crankcase RH	24
11	Crankcase LH	26 - 28
12	Balancer Idler Gear & Water Pump	30
13	Oil Pump & Evacuation Pump	32
14	Cooling System	34 - 36
15	Cover Clutch	38
16	Cover Magneto	40
17	Clutch Assembly	42
18	Throttle Body & Sensors	44
19	Air Cleaner Assembly	46
20	Silencer Assembly	48
21	Belly Pan	50
22	Starter Assembly	52
23	Magneto, Regulator & ECU	54
24	H.T. Coils	56
25	Seat Assembly & Seat Lock	58
26	Engine Mountings	60
27	Frame & Frame Fittings	62
28	Swing Arm & Rear Shock Absorber	64
29	Pillion Foot Rest	66 - 68
30	Front Fender	70
31	Side Stand Assembly	72

Index



Plate No.	Description	Page No.
32	Tubeless Tyre & Rim	74
33	Front Hub	76
34	Master Cylinder - Front	78
35	Caliper Assembly - Front	80
36	Anti Brake Lock System	82
37	Rear Disc Brake Assembly	84
38	Rear Hub	86
39	Rear Brake Pedal	88
40	Handle Bar Assembly	90 - 92
41	Front Fork	94 - 96
42	Petrol Tank, Cap Tank & Gauge Fuel	98 - 100
43	EVAP Mechanism	102
44	Fitting - Petrol Tank Cover	104
45	Fitting - Side Covers, Seat Cowls & Under Tray Front	106
46	Speedometer Assembly	108
47	Control Cables & Chain Case	110
48	Head Lamp Assembly & Front Number Plate	112
49	Indicator Light Assembly	114
50	Tail Lamp Assembly & Rear Number Plate	116
51	Electrical Equipments	118 - 120
52	Tool Kit	122
53	Accessories - Mirror, Leg Guards, Grab Handles & Saree Guard	124
54	Painted Parts & Decals	126 - 128
55	Painted Parts & Decals - From Aug. 2021	130 - 134
56	Consumable Parts	136 - 138
	Kit List	139 - 142
	Part Index	145 - 168

Pictorial Index



PLATE NO. : 1 COVER CYLINDER HEAD	PAGE NO. 1
--------------------------------------	---------------

PLATE NO. : 2 CYLINDER HEAD	PAGE NO. 3
--------------------------------	---------------

PLATE NO. : 3 ROCKER ARM & CAMSHAFT	PAGE NO. 5 - 9
--	-------------------

PLATE NO. : 4 CHAIN GUIDE & TENSIONER ASSEMBLY	PAGE NO. 11
---	----------------

Pictorial Index



PLATE NO. : 5 CYLINDER & PISTON	PAGE NO. 13
------------------------------------	----------------

PLATE NO. : 6 CRANKSHAFT ASSEMBLY	PAGE NO. 15
--------------------------------------	----------------

PLATE NO. : 7 TRANSMISSION	PAGE NO. 17
-------------------------------	----------------

PLATE NO. : 8 CHANGE DRUM / SHIFT FORK	PAGE NO. 19
---	----------------

Pictorial Index



PLATE NO. : 9 GEAR CHANGE MECHANISM	PAGE NO. 21
--	----------------

PLATE NO. : 10 ENGINE ASSEMBLY / CRANKCASE RH	PAGE NO. 23
--	----------------

PLATE NO. : 11 CRANKCASE LH	PAGE NO. 25 - 27
--------------------------------	---------------------

PLATE NO. : 12 BALANCER IDLER GEAR & WATER PUMP	PAGE NO. 29
---	----------------

Pictorial Index



PLATE NO. : 13 OIL PUMP & EVACUATION PUMP	PAGE NO. 31
--	----------------

PLATE NO. : 14 COOLING SYSTEM	PAGE NO. 33 - 35
----------------------------------	---------------------

PLATE NO. : 15 COVER CLUTCH	PAGE NO. 37
--------------------------------	----------------

PLATE NO. : 16 COVER MAGNETO	PAGE NO. 39
---------------------------------	----------------

Pictorial Index



PLATE NO. : 17
CLUTCH ASSEMBLY

PAGE NO.
41




PLATE NO. : 19
AIR CLEANER ASSEMBLY

PAGE NO.
45




PLATE NO. : 18
THROTTLE BODY & SENSORS

PAGE NO.
43





PLATE NO. : 20
SILENCER ASSEMBLY

PAGE NO.
47



Pictorial Index



PLATE NO. : 21
BELLY PAN

PAGE NO.
49




PLATE NO. : 23
MAGNETO, REGULATOR & ECU

PAGE NO.
53




PLATE NO. : 22
STARTER ASSEMBLY

PAGE NO.
51





PLATE NO. : 24
H.T. COILS

PAGE NO.
55



Pictorial Index



PLATE NO. : 25
SEAT ASSEMBLY & SEAT LOCK

PAGE NO.
57




PLATE NO. : 27
FRAME & FRAME FITTINGS

PAGE NO.
61




PLATE NO. : 26
ENGINE MOUNTINGS

PAGE NO.
59





PLATE NO. : 28
SWING ARM & REAR SHOCK ABSORBER

PAGE NO.
63



Pictorial Index



PLATE NO. : 29
PILLION FOOT REST

PAGE NO.
65 - 67




PLATE NO. : 31
SIDE STAND ASSEMBLY

PAGE NO.
71




PLATE NO. : 30
FRONT FENDER

PAGE NO.
69





PLATE NO. : 32
TUBELESS TYRE & RIM

PAGE NO.
73



Pictorial Index



PLATE NO. : 33
FRONT HUB

PAGE NO.
75




PLATE NO. : 35
CALIPER ASSEMBLY - FRONT

PAGE NO.
79




PLATE NO. : 34
MASTER CYLINDER - FRONT

PAGE NO.
77





PLATE NO. : 36
ANTI BRAKE LOCK SYSTEM

PAGE NO.
81



Pictorial Index



PLATE NO. : 37
REAR DISC BRAKE ASSEMBLY

PAGE NO.
83




PLATE NO. : 39
REAR BRAKE PEDAL

PAGE NO.
87




PLATE NO. : 38
REAR HUB

PAGE NO.
85





PLATE NO. : 40
HANDLE BAR ASSEMBLY

PAGE NO.
89 - 91



Pictorial Index



PLATE NO. : 41 FRONT FORK	PAGE NO. 93 - 95
------------------------------	---------------------

PLATE NO. : 42 PETROL TANK, CAP TANK & GAUGE FUEL	PAGE NO. 97 - 99
---	---------------------

PLATE NO. : 43 EVAP MECHANISM	PAGE NO. 101
----------------------------------	-----------------

PLATE NO. : 44 FITTING - PETROL TANK COVER	PAGE NO. 103
---	-----------------

Pictorial Index



PLATE NO. : 45 FITTING - SIDE COVERS, SEAT COWLS & UNDER TRAY FRONT	PAGE NO. 105
---	-----------------

PLATE NO. : 46 SPEEDOMETER ASSEMBLY	PAGE NO. 107
--	-----------------

PLATE NO. : 47 CONTROL CABLES & CHAIN CASE	PAGE NO. 109
---	-----------------

PLATE NO. : 48 HEAD LAMP ASSEMBLY & FRONT NUMBER PLATE	PAGE NO. 111
--	-----------------

Pictorial Index

DOMINAR
250

PLATE NO. : 49
INDICATOR LIGHT ASSEMBLY

PAGE NO.
113




PLATE NO. : 50
TAIL LAMP ASSEMBLY &
REAR NUMBER PLATE

PAGE NO.
115




PLATE NO. : 51
ELECTRICAL EQUIPMENTS

PAGE NO.
117 - 119





PLATE NO. : 52
TOOL KIT

PAGE NO.
121



Pictorial Index

DOMINAR
250

PLATE NO. : 53
ACCESSORIES - MIRROR, LEG GUARDS,
GRAB HANDLES & SAREE GUARD

PAGE NO.
123




PLATE NO. : 54
PAINTED PARTS & DECALS

PAGE NO.
125 - 127




PLATE NO. : 55
PAINTED PARTS AND DECALS -
FROM AUG. 2021

PAGE NO.
129




PLATE NO. : 56
CONSUMABLE PARTS

PAGE NO.
131



Pictorial Index



PLATE NO. : 56 CONSUMABLE PARTS			PAGE NO. 133		
13		14		15	
16		17		18	
19		20		21	
22		23		24	

Pictorial Index







Plate No.: 1


Cover Cylinder Head

No.	Part No.	Description	Qty.	Remarks
1	JG 5110 22	Bolt Special	4	
2	JG 5110 21	Washer	4	
3	DT 5110 27	Cylinder Head Cover Assembly	1	
4	JY 5111 28	Gasket Rubber - Head Cover	1	
5	JY 5111 49	Gasket Head Cylinder	1	




Cylinder Head

No.	Part No.	Description	Qty.	Remarks
1	KA ED06 35	Bolt flanged small	4	Refer Kit List
2	KA EQ06 40	Bolt flange small - M6	2	
3	KA EG06 45	Bolt flanged small	2	
4	JY 5110 58	Guide chain top	1	
5	JF 5110 58	Head Cylinder - Holder Camshaft	1	
6	JY 5110 68	Sleeve spark plug	1	
7	LJ A000 01	'O' Ring	2	
8	JY 5110 74	Gasket sleeve spark plug	1	
9	LA C000 32	Bolt socket head M10	4	
10	DK 1012 25	Oil Pressure Switch	1	
11	DK 1013 40	'O' Ring	1	
12	JG 3514 00	Sensor Temperature with 'O' Ring	1	
13	39 2699 20	'O' Ring	1	
14	JF 5814 08	Pipe Intake	1	
15	LB C000 03	Screw	3	
16	JG 5814 07	'O' Ring Pipe Intake	1	
17	JU 5810 06	Clamp	1	
18	JG 5110 46	Stud	2	
19	JP 4022 18	Pigtail oil pressure switch	1	
20	39 1686 06	Hollow Dowel Pin	2	




Rocker arm & Camshaft

No.	Part No.	Description	Qty.	Remarks
1	JY 5112 12	Rocker arm decomp	1	Refer Kit List
2	JU 5112 04	Rocker arm	3	
3	JY 5112 26	Rocker arm shaft	2	
4	JG 5110 16	Plug	2	
5	39 1021 21	Ring - O	2	
6	JF 5112 60	Camshaft assembly exhaust	1	
7	36 JF01 05	Kit Shim 3.20 mm	1	
8	LA C001 44	Bolt socket - M10	2	
9	JF 5112 58	Camshaft Assembly Intake	1	
10	CB 1010 09	Seal Valve Stem	4	
11	JY 5112 48	Valve Intake	2	Refer Kit List
12	JP 5112 28	Valve Exhaust	2	
13	36 JF01 98	Kit Valve Repair	1	
14	CB 1010 22	Cotter Valve	8	
15	36 JY00 29	Kit Shim 2 mm	1	
16	36 JY00 30	Kit Shim 2.04 mm	1	
17	36 JY00 31	Kit Shim 2.08 mm	1	
18	36 JY00 32	Kit Shim 2.12 mm	1	
19	36 JY00 33	Kit Shim 2.16 mm	1	
20	36 JY00 34	Kit Shim 2.20 mm	1	
21	36 JY00 35	Kit Shim 2.24 mm	1	Refer Kit List
22	36 JY00 36	Kit Shim 2.28 mm	1	
23	36 JY00 56	Kit Shim 2.30 mm	1	
24	36 JY00 37	Kit Shim 2.32 mm	1	




Rocker arm & Camshaft

No.	Part No.	Description	Qty.	Remarks
25	36 JY00 57	Kit Shim 2.34 mm	1	
26	36 JY00 38	Kit Shim 2.36 mm	1	
27	36 JY00 58	Kit Shim 2.38 mm	1	
28	36 JY00 39	Kit Shim 2.40 mm	1	
29	36 JY00 59	Kit Shim 2.42 mm	1	
30	36 JY00 40	Kit Shim 2.44 mm	1	
31	36 JY00 60	Kit Shim 2.46 mm	1	
32	36 JY00 41	Kit Shim 2.48 mm	1	
33	36 JY00 61	Kit Shim 2.50 mm	1	
34	36 JY00 42	Kit Shim 2.52 mm	1	
35	36 JY00 62	Kit Shim 2.54 mm	1	
36	36 JY00 43	Kit Shim 2.56 mm	1	
37	36 JY00 63	Kit Shim 2.58 mm	1	
38	36 JY00 44	Kit Shim 2.60 mm	1	
39	36 JY00 64	Kit Shim 2.62 mm	1	
40	36 JY00 45	Kit Shim 2.64 mm	1	
41	36 JY00 46	Kit Shim 2.68 mm	1	
42	36 JF00 89	Kit Shim 2.70 mm	1	
43	36 JY00 47	Kit Shim 2.72 mm	1	
44	36 JF00 90	Kit Shim 2.74 mm	1	
45	36 JY00 48	Kit Shim 2.76 mm	1	
46	36 JF00 91	Kit Shim 2.78 mm	1	
47	36 JY00 49	Kit Shim 2.80 mm	1	




Rocker arm & Camshaft

No.	Part No.	Description	Qty.	Remarks
48	36 JF00 92	Kit Shim 2.82 mm	1	
49	36 JY00 50	Kit Shim 2.84 mm	1	
50	36 JF00 93	Kit Shim 2.86 mm	1	
51	36 JY00 51	Kit Shim 2.88 mm	1	
52	36 JF00 94	Kit Shim 2.90 mm	1	
53	36 JY00 52	Kit Shim 2.92 mm	1	
54	36 JF00 95	Kit Shim 2.94 mm	1	
55	36 JY00 53	Kit Shim 2.96 mm	1	
56	36 JF00 96	Kit Shim 2.98 mm	1	
57	36 JY00 54	Kit Shim 3.00 mm	1	
58	36 JF00 97	Kit Shim 3.02 mm	1	
59	36 JY00 55	Kit Shim 3.04 mm	1	
60	36 JF00 98	Kit Shim 3.06 mm	1	
61	36 JF00 99	Kit Shim 3.08 mm	1	
62	36 JF01 00	Kit Shim 3.10 mm	1	
63	36 JF01 01	Kit Shim 3.12 mm	1	
64	36 JF01 02	Kit Shim 3.14 mm	1	
65	36 JF01 03	Kit Shim 3.16 mm	1	
66	36 JF01 04	Kit Shim 3.18 mm	1	




Chain Guide & Tensioner Assembly

No.	Part No.	Description	Qty.	Remarks
1	36 JF01 97	Kit cam chain guide	1	
2	JY 5112 20	Chain timing	1	
3	JY 5410 09	Bolt Special Pivot Guide Chain	1	
4	CS 1011 28	Gasket	1	
5	JF 5112 49	Tensioner Assembly	1	
6	KA EW06 20	Hex Bolt With Flange	2	
7	39 2669 21	O - Ring	1	
8	JG 5112 70	Bolt flanged - M6	1	




Cylinder & Piston

No.	Part No.	Description	Qty.	Remarks
1	36 JF02 08	Kit Block Piston Assembly	1	Refer Kit List
2	39 2181 06	Hollow Dowel Pin	2	
3	JY 5210 06	Gasket Cylinder Block	1	
4	36 JP00 25	Kit Piston Ring	1	
5	JY 5212 36	Circlip	2	




Crankshaft Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 5310 21	Balancer Drive Gear	1	
2	LD H000 02	Belleville Washer	1	
3	LD B000 33	Plain Washer	1	
4	JG 5310 40	Nut Balancer Drive Lock	1	
5	39 2606 07	Parallel Pin	1	
6	JY 5512 12	Gear Primary Drive	1	
7	LF B000 01	Sunk Key	1	
8	JY 5310 26	Sprocket crankshaft (18T)	1	
9	JY 5310 08	Plain Washer	1	
10	DG 1012 75	Washer	1	
11	LC G000 02	Nut Sprocket Drive Lock	1	
12	JY 5310 60	Assembly Crankshaft	1	
13	36 JF00 54	Kit Primary Drive & Driven	1	Refer Kit List
14	JY 5310 61	Crankshaft Assembly	1	
15	39 2203 07	Parallel Pin	2	
16	JY 5310 45	Connecting Rod Assly	1	
17	JY 5310 05	Bolt-M8X0.75XL33	2	



Transmission

No.	Part No.	Description	Qty.	Remarks
1	JY 5510 22	Shaft Input	1	
2	JY 5512 30	Gear 5th Drive	1	
3	JY 5510 10	Bush 5th Drive	1	
4	JY 5512 14	Circlip	2	
5	JY 5512 29	Gear 3rd - 4th Drive	1	
6	JY 5510 21	Bush 6th Drive	1	
7	JY 5512 31	Gear 6th Drive	1	
8	JY 5512 28	Gear 2nd Drive	1	
9	JY 5512 15	Thrust Washer	1	
10	JY 5510 06	Bush 2nd Driven	1	
11	JY 5512 33	Gear 2nd Driven	1	
12	JY 5510 08	Shaft Output T/M With Plug	1	
13	JY 5512 37	Gear 6th Driven	1	
14	JY 5512 35	Gear 4th Driven	1	
15	JY 5510 05	Thrust Washer 3rd Driven	1	
16	JY 5512 34	Gear 3rd Driven	1	
17	JY 5510 27	Bush 3rd Driven	1	
18	JY 5512 18	Circlip	1	
19	JY 5512 36	Gear 5th Driven	1	
20	JY 5512 05	Bush 1st Driven	1	
21	JY 5512 32	Gear 1st Driven	1	
22	JY 5512 17	Thrust Washer	1	
23	JY 5510 18	'O' RING	1	
24	JY 5510 33	Collar Sprocket	1	
25	36 JF02 09	Sprocket Output	1	
26	JY 5510 30	Plate Drive Sprocket	1	
27	LA E000 17	Bolt Flanged	2	




FWD Front Wheel Direction

Plate No.: 8


Change Drum / Shift Fork

No.	Part No.	Description	Qty.	Remarks
1	JG 5612 22	Guide Gear Shift	1	
2	LA C000 24	Socket Head Bolt	1	
3	JG 5610 10	Spacer	1	
4	39 2606 07	Parallel Pin	1	
5	JF 5610 00	Drum Gear Shift	1	
6	JG 5610 08	Gear Indicator Pin	1	
7	JY 5610 04	Shaft Input Gear Shift Fork	1	
8	JF 5610 01	Shaft Output Fork Shift	1	
9	JG 5612 15	Compression Spring	2	
10	JY 5610 08	Fork Shift Output	2	
11	JY 5610 02	Fork Gear Shift Input	1	
12	EC 5610 23	Spring Gear Switch Indicator	1	




Gear Change Mechanism

No.	Part No.	Description	Qty.	Remarks
1	JY 5612 05	Lever Complete Change Shaft	1	
2	JG 5612 15	Spring Compression	1	
3	JG 5612 17	Bush Torsion Spring	1	
4	JG 5612 18	Torsion Spring	1	
5	JG 5612 16	Plain Washer	1	
7	KA DD06 22	Bolt Flange M6	1	
8	JL 5614 10	Washer Steel	1	
9	LA C001 04	Bolt Socket - M8	1	
10	01 1009 05	'O' Ring	2	
11	JF 5614 10	Lever Change Assembly	1	
12	52 JF00 62	Tie Rod	1	
13	JF 5614 22	Arm Change	1	
14	DT 5612 05	Damper	1	
15	LC B000 03	Nut (LM6 x 1)	1	
16	KC AM06 05	Nut Hex Thick - M6	1	



Engine Assembly / Crankcase RH

No.	Part No.	Description	Qty.	Remarks
1	36 JF00 52	Kit Assembly Crankcase RH	1	Refer Kit List
2	JF 5010 25	Engine assembly	1	
3	39 2185 20	Deep Groove Ball Bearing	1	
4	39 2562 20	Needle Roller Bearing	1	
5	39 2601 20	Ball Bearing	1	
6	39 1864 20	Ball Bearing 20 X 52 X 15	1	
7	KP BF63 04	Ball Bearing	1	
8	JY 5410 47	Stopper I/P Shaft Bearing	3	
9	AA 1014 37	Bolt Flanged	3	
10	JG 6010 07	Special Shaft Seal	1	
11	JL 6010 10	Water Seal Double Lip	1	
12	JG 5612 04	Bolt Stopper Drum	1	
13	DP 1011 91	Bolt Shifter	1	
14	JG 5710 14	Oil Filter	1	
15	JG 5710 16	'O' Ring	1	
16	56 JF1X 36	Cap oil filter Silk matte blue	1	
17	KA EW06 16	Flange Bolt	2	
18	LA E000 01	Bolt Flanged	1	
19	JG 5612 26	Spring Stopper Drum	1	
20	39 2005 11	Washer	1	
21	JG 5610 09	Stopper Drum Complete	1	
22	JG 5612 05	Washer	1	




FWD Front Wheel Direction

Plate No.: 11

Crankcase LH

No.	Part No.	Description	Qty.	Remarks
1	36 JF02 11	Kit Assembly Crankcase LH	1	Refer Kit List
2	LJ A000 02	'O' Ring	2	
3	JY 5710 08	Strainer Evacuation	1	
4	LJA00006	'O' Ring	1	
5	JY 5710 09	Cap Strainer Evacuation	1	
6	39 1043 19	Oil Seal	1	
7	JY 5410 58	Oil Seal	1	
8	KE BA37 15	Circlip Internal	1	
9	JY 5410 31	Chain Guard	1	
10	LB B000 07	Screw Pan Cross	3	
11	JY 5710 30	Mesh Oil Filter Assembly	1	
12	LJ A000 04	'O' Ring	1	
13	JA 5410 48	Strainer Cap with 'O' Ring	1	
13A	59 2100 23	O - Ring	1	
14	JF 3518 05	Sensor Assembly Pick Up	1	
15	JN 1810 33	Bolt flange	2	
16	AA 1014 37	Bolt M5 x 13	5	
17	JY 5410 81	Bracket Harness	1	
18	JY 5410 80	Plate Harness	1	
19	JY 5410 82	Bracket Harness	1	
20	LP B000 03	Bearing Ball	1	
21	LP B000 02	Bearing Ball	1	




FWD Front Wheel Direction

Plate No.: 11


Crankcase LH

No.	Part No.	Description	Qty.	Remarks
22	39 2562 20	Needle Roller Bearing	1	
23	JF 5410 17	Bracket	1	
24	LB B000 12	Screw pan cross - M6	1	
25	39 2181 06	Hollow Dowel Pin	4	
26	KA EW06 35	Bolt Flange Small	15	
27	LA E000 02	Bolt Flanged	5	
28	JY 5710 29	Oil Rail	1	
29	LJ A000 02	O Ring	1	
30	JF 5410 16	Nozzle	1	
31	LA E000 10	Bolt flange - M5	2	




Balancer Idler Gear & Water Pump

No.	Part No.	Description	Qty.	Remarks
1	JF 5312 14	Assembly balancer	1	
2	KP BF63 04	Ball Bearing	2	
3	36 JL00 39	Rotor Water Pump	1	
4	JG 5312 15	Washer	1	
5	JG 6010 05	Domed Nut	1	
6	JG 6010 12	'O' Ring	1	
7	39 2606 07	Parallel Pin	2	
8	JL 6010 08	Cover Water Pump	1	
9	39 1665 11	Washer	1	
10	LA E000 48	Bolt	1	
11	KA EW06 22	Bolt flange small M6	5	
12	DS 1011 54	Key	1	
13	LD B000 51	Washer	1	
14	LA C000 86	Bolt Socket	1	
15	JF 5312 13	Scissor Gear Assembly	1	
16	JL 5312 03	Sleeve Balancer Driven	1	
17	JG 5312 29	'O' Ring Balancer Driven	1	




Oil Pump & Evacuation Pump

No.	Part No.	Description	Qty.	Remarks
1	JY 5710 15	Evacuation Oil Pump Assly.	1	
2	LH D000 01	Pin Parallel	3	
3	39 0999 06	Pin Dowel	4	
4	LA E000 18	Bolt Flanged M6 Pre Coated	6	
5	JY 5710 24	Shaft Oil Pump	1	
6	JY 5710 12	Oil Pump Assembly Complete	1	
7	JY 5710 23	Gear Oil Pump Drive	1	
8	LD A000 17	Washer Plain	1	
9	KE AB10 10	Circlip External	1	




Cooling System

No.	Part No.	Description	Qty.	Remarks
1	JF 6012 15	Radiator	1	
2	JY 6012 48	Bracket Fan Mounting	2	
3	JY 6012 49	Bracket Fan Mounting	1	
4	JG 6012 35	Pressure Cap Radiator	1	
5	JY 6012 41	Flange Nut	3	
6	JG 6012 09	Clamp DIA 24	2	
7	JF 6012 03	Hose Thermostat To Radiator	1	
8	JG 6012 10	Clamp DIA 28	3	
9	JF 6012 10	Pipe Thermostat - Joint T	1	
10	JG 6010 16	Clamp DIA 26	2	
11	JY 6012 15	Hose Engine To Thermostat	1	
12	JF 6012 13	Pipe Connector - Radiator	1	
13	JF 6012 11	Joint Assembly T	1	
14	JP 6012 35	Fan Radiator	1	
15	JL 6012 16	Rubber Damper	4	
16	LJ A000 05	Pipe coolant "T" O - ring	1	
17	JG 6012 34	Clamp DIA 23	1	
18	JG 6010 14	Thermostat Assembly	1	
19	JF 1812 57	Shroud Centre	1	
20	JL 6012 35	Tank Expansion	1	
21	JG 6012 11	Cap Expansion Tank	1	
21A	JG 6012 30	Expansion tank O Ring	1	




Cooling System

No.	Part No.	Description	Qty.	Remarks
22	56 JF24 6B	Shroud LH Silver	1	
	56 JF24 4X	Shroud LH Black	1	
23	56 JF25 6B	Shroud RH Silver	1	
	56 JF25 4X	Shroud RH Black	1	
24	JL 6012 13	Hose Expansion Tank	1	
25	JG 6012 13	Tube Drain - Expansion Tank	1	
26	JG 1710 29	Spring Band Clip 10 MM	3	
27	JF 1812 62	Shroud Mounting Bracket RH	1	
28	JL 6012 15	Clamp - Expansion Tank	1	
29	LB U000 53	Screw Button Head	4	
30	JY 1812 84	Washer Nylon	4	
31	LA E000 55	Bolt Flange Small	2	
32	JG 1812 59	Rivet Snap	4	
33	DJ 1810 65	Clip Nut M6	4	
34	LD B000 75	Washer	4	
35	LC G000 29	Nut Flange - M6 X 1P	4	
36	LA E000 49	Bolt Flange	2	
37	JF 1138 48	Bracket radiator LH	1	
38	JF 1138 49	Bracket radiator RH	1	




Cover Clutch

No.	Part No.	Description	Qty.	Remarks
1	36 JF02 02	Assembly Clutch Cover with Nozel	1	Refer Kit List
2	39 1990 20	Needle Bearing	1	
3	39 1041 19	Seal Oil	1	
4	LD B000 20	Washer	1	
5	JF 5412 10	Spring Lever Clutch	1	
6	JF 5412 08	Clutch Release Shaft Assembly	1	
7	KJ AA14 24	'O' Ring	1	
8	JG 5412 30	Cap Oil Filling	1	
9	JF 2332 45	Decal Cover Clutch	1	
10	JL 5412 27	Window Oil Gauge	1	
11	DS 1012 15	Wire Circlip	1	
12	39 2016 19	Seal Oil	1	
13	JY 5412 20	Plate Position	1	
14	AA 1014 37	Bolt Flanged Small	2	
15	JY 5412 25	Gasket Clutch Cover	1	
16	JF 5412 04	Bracket Clutch Cable	1	
17	KA EW06 35	Blot Flanged	12	




Cover Magneto

No.	Part No.	Description	Qty.	Remarks
1	52 JF12 25	Magneto Cover Assembly	1	Refer Kit List
2	JF 2332 18	Decal cover magneto	1	
3	30 1011 95	'O' Ring	1	
4	JL 5412 45	Cap TDC Finder	1	
5	JY 5412 14	Gasket Cover Magneto	1	
6	KA EW06 35	Bolt Flange	12	
7	DT 5412 02	Cover LH RR	1	
8	KA EW06 50	Bolt Flange	3	
9	JF 2330 36	Label Gear Shift 6 Speed	1	
10	39 0999 06	Pin - Hollow Dowel	2	
11	JY 5410 34	Bush Starter Shaft	2	




Clutch Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 5514 22	Clutch Assembly	1	Refer Kit List
2	36 JF00 54	Kit Primary Drive & Driven	1	
3	JY 5514 03	Washer Clutch	1	
4	JY 5514 35	Clutch Center	1	
5	JY 5514 42	Spring Seat Judder	1	
6	JY 5514 41	Spring Judder	1	
7	YJ F260 11	Kit Friction Plate	1	
8	JY 5514 36	Pressure Plate - A	5	
9	JY 5514 37	Pressure Plate - B	1	
10	JY 5514 01	Bush Collared	1	
11	LC G000 09	Nut Hex Flanged - M16 x 1.5	1	
12	LP A000 04	Thrust Bearing	1	
13	JY 5514 38	Plate Clutch Pressure	1	
14	JY 5514 04	Rod Pull	1	
15	JY 5514 40	Seat spring	3	
16	JY 5514 43	Plate Stopper	1	
17	LA D001 66	Bolt Flanged - M6 x 35	3	
18	JY 5510 19	Washer Plain	1	
19	DG 1012 75	Washer Special	1	




Throttle Body & Sensors

No.	Part No.	Description	Qty.	Remarks
1	JF 6112 06	Body Throttle Assembly	1	
2	JG 6110 07	Fuel Injector	1	
3	JF 6112 07	Cap Injector & Connector Quick	1	
4	JG 5814 24	Fixing Screw M5 x 12	5	
5	JG 6112 06	Motor Stepper	1	
6	JG 3518 05	Sensor TMAP	1	
7	JG 5814 23	Fixing Screw M4 x 13	2	
8	JG 5814 19	Bracket throttle cable	1	
9	JG 5814 37	Fixing screw - M6 x 14	1	
10	JG 6110 06	Injector Clip	1	
11	DT 3518 03	Sensor Throttle Position	1	




Air Cleaner Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 5810 35	Filter Assembly Air	1	
2	JU 5810 06	Clamp	1	
3	JF 5810 22	Entry Duct	1	
4	DT 5810 28	Seal Top Cover	2	
5	KB UA06 30	Screw Truss	4	
6	JF 5810 31	Tube Breather	1	
7	JY 5810 16	Clamp	1	
8	JG 5810 56	Clamp (breather tube)	1	
9	DT 5810 62	Air Filter Element	1	
10	JY 5810 28	Clamp (Breather Tube)	1	
11	JP 5810 18	Assembly Tube Drain	1	
12	JY 5810 28	Clamp	2	
13	DT 5810 74	Assly Breather Oil Return Tube	1	
14	DT 1138 56	Bracket Filter Mounting	1	
15	JG 1812 65	Washer	4	
16	KA CF06 12	Bolt Socket	4	




Silencer Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 5913 39	Pipe Assembly	1	
2	JF 5910 99	Assembly muffler	1	
3	JF 5912 22	Shield muffler	1	
4	KA CH06 14	Bolt socket M6	3	
5	KA CH06 10	Bolt socket M6	1	
6	JF 5911 82	Muffler assembly W/O shield	1	
7	JP 5910 12	Clamp	1	
8	JG 5910 70	Gasket	1	
9	JP 5910 42	Gasket muffler primary	1	
10	LC G000 24	Nut hex flanged - M8	2	
11	KA DW10 50	Bolt flanged - M10	1	
12	JF 1510 47	Washer cup	2	
13	DH 1611 55	Damper silencer	1	
14	DH 1611 57	Tube silencer mounting	1	
15	DD 1610 71	U - Nut M10	1	
16	LA C000 99	Bolt socket - M6	1	
17	LD B000 68	Washer plain	2	
18	JY 5913 03	Grommet shield muffler	2	
19	KA DA06 12	Bolt flanged	1	
20	KA DD08 40	Bolt flanged	1	
21	JF 5913 34	Collar	1	
22	JG 5911 00	Damper silencer mtg. lower	1	
23	JF 5912 11	Cap End Chamber	1	
24	JP 5910 65	Sensor Oxygen	1	
25	JF 5910 53	Cap	1	




Belly Pan

No.	Part No.	Description	Qty.	Remarks
1	JF 1813 51	Belly pan center in satin blk	1	From Aug.2021
2	JF 1813 55	Bracket Belly Pan Rear	1	
3	LA C000 08	Screw Button Head	2	
4	JF 1813 54	Bracket Assly. Belly Pan Front	1	
	JF 1817 83	Bracket Assembly Belly Pan Front	1	
5	KA EW06 35	Bolt Flange Small	2	
6	KA EW06 55	Bolt Flange Small	1	
7	LD B000 19	Plain Washer	4	
8	LB U000 55	Screw Button Head	2	
9	KA CF06 16	Bolt Socket - M6	2	
10	LD B000 19	Washer plain	2	
11	JY 1812 55	Washer End Cap	4	
12	LB U000 68	Screw Truss - M5	4	
13	JF 1813 29	Foam Belly Pan	2	
14	JG 1710 31	Clip Nut M5	4	
15	52 JF13 51	Belly pan LH satin black + decal glamour green	1	
	52 JF13 45	Belly pan LH satin black + decal graphite matt black	1	
16	52 JF13 52	Belly pan RH satin black + decal glamour green	1	
	52 JF13 46	Belly pan RH satin black + decal graphite matt black	1	



Starter Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 3516 00	Starter Motor	1	
2	KA DQ06 25	Bolt Flanged	2	
3	JY 5512 25	Gear Starter Counter 2	1	
4	JY 5512 26	Gear Starter Counter 1 Assy.	1	
5	31 1011 73	Key Woodruff	1	
6	JY 6214 11	Assembly Gear Starter Clutch	1	
7	JY 5410 40	Retainer Gear Starter	1	
8	LA E000 42	Bolt Flanged	1	




Front Wheel Direction

Plate No.: 23

Magneto, Regulator & ECU

No.	Part No.	Description	Qty.	Remarks
1	JY 3510 25	Rotor Without Clutch & BSC	1	
2	JF 3510 22	Stator Assembly	1	
3	DK 1012 84	Hex Socket Head Screw	3	
4	JF 4020 04	Regulator Assembly	1	
5	KA ED06 30	Bolt - Flanged - Small	2	
6	JF 1812 82	Bracket ECU lower	1	
7	JP 3514 39	ECU	1	
8	JY 1138 64	Bracket ECU mtg top C smple	1	
9	KC GD06 06	Nut hex flanged	4	
10	JF 4022 34	Magneto Pigtail to RR	1	
11	LD B000 41	Plain Washer	1	
12	LA D001 24	Bolt Flange	1	
13	JY 5412 22	Plate Harness	1	
14	JY 5412 08	Bracket Harness Magneto	1	
15	LA E000 16	Bolt	3	
16	LD F000 01	Washer toothed	4	
17	DH 1013 89	Bolt Socket - M6 x 1 x L20	4	
18	JG 3510 19	Body clutch starter	1	
19	JY 5514 02	Clutch One Way Assly	1	
20	JY 1138 77	Damper ECU Locator	1	
21	JY 1138 74	Damper ECU C smple mtg top	1	
22	JY 1710 07	Pad rubber new ECU My16	2	
23	JY 1138 72	Pad resting ECU C sample LH	1	
24	JY 1138 73	Pad resting ECU C sample RH	1	




FWD Front Wheel Direction

Plate No.: 24


H.T. Coils

No.	Part No.	Description	Qty.	Remarks
1	JF 3512 13	Coil Ignition With Cable	1	
2	KA DD06 20	Bolt Flanged	4	
3	DD 1110 12	Grommet For H. T. Cable	2	
4	JD 3512 07	Spark Plug Cap	1	
5	DD 1110 11	Grommet - Spark Plug Cap	1	
6	DK 1110 28	Spark Plug RG6HCC	1	
7	DT 3512 02	Coil HT1 with cap	1	
8	JY 3512 03	Grommet spark plug cap	1	
9	JY 3512 00	Cap spark plug	1	
10	JF 3512 06	Grommet Spark Plug	1	
11	JL 3512 18	Plug Spark Central	1	
12	DT 1138 55	Clamp HT coils	1	
13	AN 1013 48	Clip - hose - rotatable	1	




Seat Assembly & Seat Lock

No.	Part No.	Description	Qty.	Remarks
1	JF 1910 09	Seat Assembly Front - K10	1	
2	JG 1910 08	Collar - Seat	2	
3	JF 1910 16	Rider Seat Rear Mtg Grommet	2	
4	JF 1910 18	Rider Seat Resting Damper	4	
5	JK 1910 05	Damper Seat	2	
6	JF 1910 17	Rider Seat Front Grommet	1	
7	LA D001 13	Bolt flanged - M6	2	
8	JF 1910 12	Seat Assembly Rear - K10	1	
9	JD 1910 06	Damper Round	2	
10	JL 1910 17	Seat Rear Damper Front	2	
11	KA DF06 25	Bolt Flange	2	
12	DT 2326 05	Seat Lock	1	
13	JG 2326 02	Side Lock	1	
14	JL 2326 04	Cover Seat Lock	1	
15	JF 1138 17	Bracket Seat Lock	1	
16	JG 2326 03	Bracket seat lock barrel	1	
17	JF 2314 13	Strap front LH	1	
18	JF 2314 14	Strap front RH	1	
19	LD B000 15	Washer plain	2	
20	JG 1910 11	Plate seat lock	1	
21	JG 2326 06	Seat Lock Cable	1	




Engine Mountings

No.	Part No.	Description	Qty.	Remarks
1	56 DT02 33	Stay hanger LH matt black	1	
2	56 DT03 33	Stay hanger RH matt black	1	
3	KA ED08 20	Bolt flanged small	4	
4	JL 1812 60	Foam strip - 18 x 15 x 5	2	
5	LA J000 20	Bolt stud - M10 X L153	1	
6	KD DB10 18	Washer spring thin	1	
7	KD AA10 18	Washer Plain	1	
8	LA A000 51	Bolt - M8 (For LH & RH)	2	
9	LA D000 06	Bolt Flange	2	
10	LC L000 01	Nut Hex Flange - M10	2	
11	DT 1138 27	Cover Sheath Heat	1	
12	JF 1134 24	Bracket engine middle rear	1	
13	KA DT08 14	Bolt flange - M8	2	
14	JF 1813 48	Cap	1	
15	JF 1813 46	Cover frame front	1	
16	LA E000 54	Bolt flange - M6	1	
17	LA D001 91	Bolt flanged - M8	1	
18	DT 1813 23	Plug 2	2	



Frame and Frame Fittings

No.	Part No.	Description	Qty.	Remarks
1	JF 1112 80	Frame Assembly	1	Refer Kit List
2	36 DV00 11	Kit Steering Cone	1	
3	DK 1810 50	Cage Bearing Steering Top	1	
4	DK 1810 51	Cage Bearing Steering Bottom	1	
5	JG 1510 24	Washer	1	
6	DG 1810 04	Seal Oil	1	
7	JL 1138 09	Grommet Air Filter Resting	1	
8	DS 2110 04	Damper seat I	2	
9	JL 1810 27	Clip Nut	4	
10	DJ 1612 90	Chassis no. protection tape	1	
11	JF 1138 21	Bracket Canister Mounting	1	
12	KA EA06 10	Bolt Flanged	2	
13	JZ 1710 55	Strap Canister	2	
14	JF 1134 22	Spacer	1	
15	DK 1810 76	Cup steering	1	
15A	DK 1810 75	Steering Nut	1	
16	DS 1611 66	Frame tape II	3	
17	JF 1138 71	Insulator Frame	1	




FWD Front Wheel Direction

Plate No.: 28


Swing Arm & Rear Shock Absorber

No.	Part No.	Description	Qty.	Remarks
1	56 JF28 Y9	Arm Assembly Swing	1	
2	JF 1221 20	Shock absorber rear	1	
3	LA C001 05	Bolt Socket M10 x 1.25 x L55	2	
4	DK 1710 06	Sleeve for swing arm	2	
5	DG 1710 18	Bearing - Needle	2	
6	DG 1710 19	Seal - Oil	4	
7	JF 1221 15	Adjuster Chain	2	
8	JF 1221 04	Cap Tube Arm Swing	2	
9	KC GC08 08	Nut Hex Flanged	2	
10	KC BC08 05	Nut Hex Thin	2	
11	LA D001 08	Axle - M14	1	
12	DG 1710 17	Nut	1	
13	DT 1138 48	Cap Swing Arm Pivot	2	
14	JF 1134 23	Washer	1	
15	JF 1221 05	Slider Chain	1	
16	JG 1220 37	Sleeve	2	
17	KA ED06 16	Bolt Flanged Small	2	



Pillion Foot Rest


No.	Part No.	Description	Qty.	Remarks
1	56 JF3X Y9	Step holder LH Sprt Matt blk	1	
2	56 DT3S Y9	Step rider LH sprint matte blk	1	
3	LH E000 03	Pin Clevis With Hole	4	
4	JF 1130 12	Spring Torsion	2	
5	KD AA08 16	Washer Plain Small	4	
6	KH AA25 20	Pin Cotter	4	
7	JL 1130 14	Step Pillion Assy Complete LH	1	
	56 JF18 1Y	Step Pillion LH Slate Grey	1	
	56 DT4J Y9	Step pill assly LH Spr matt blk	1	
8	JL 1130 36	Rubber Pillion Step	2	
9	DT 1130 14	Lock Plate LH	1	
10	30 1410 31	Ring O	2	
11	56 JF3Y Y9	Step Holder RH sprt Matt blk	1	
12	56 DT3T Y9	Step Rider RH sprint matte blk	1	
13	JL 1130 16	Step Pillion Assy Complete RH	1	
	56 JF19 1Y	Step Pillion RH Slate Grey	1	
	56 DT4K Y9	Step pill. asly RH Spr matt blk	1	
14	DT 1130 15	Lock Plate RH	1	
15	LA C000 78	Bolt Socket - M8x1.25xL20	4	
16	LA C000 79	Bolt Socket - M8x1.25xL35	2	
17	DH 1611 55	Damper Silencer	1	
18	DH 1611 57	Tube Silencer	1	
19	JF 1130 36	Bracket reservoir	1	
20	LA D000 85	Bolt M6 x 1	1	




Pillion Foot Rest

No.	Part No.	Description	Qty.	Remarks
21	GF 1611 43	Spring Pillion Footrest	2	
22	KM AA08 00	Ball Steel	2	
23	KA DD06 20	Bolt flanged	1	
24	KC AD06 05	Nut hex thick	1	
25	JL 1130 35	Bolt - M6	2	
26	LD A000 13	Washer plain Dia 6.4	2	
27	DV 1610 50	Stopper step	2	

Front Fender




No.	Part No.	Description	Qty.	Remarks
1	LB B000 15	Screw Pan Cross	3	
2	KD AE05 10	Washer Plain Small	6	
3	JF 1814 80	Flap fender front	1	
4	39 0326 15	Nut Nyloc	3	
5	JF 1814 73	Collar	6	
6	LA C000 71	Bolt socket - M6	6	



Side Stand Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 1132 12	Stand assembly side	1	
2	LA D002 31	Bolt flange - M10	1	
3	LC H000 01	Nut Nyloc M10	1	
4	JF 1132 09	Bracket stand side	1	
5	JF 1132 08	Bracket holder magnet	1	
6	KC BA06 04	Nut hex thin - M6	1	
7	AH 4014 08	Holder magnet	1	
8	LA D001 84	Bolt Flanged	1	
9	LA D002 00	Bolt Flanged	1	
10	JF 1132 05	Bush side stand mtg	1	
11	JF 4014 15	Side Stand Switch	1	
12	KA DS05 16	Bolt Flanged M5 x 0.8 x L16	1	
13	JD 4022 15	Band	3	
14	JF 1138 55	Bkt. cover switch stand side	1	
15	KA DD06 12	Bolt flanged	1	
16	JF 1132 10	Spring with cover	1	
17	JF 1132 11	Spring Tension	1	
18	JD 1610 06	Sleeve brake return spring	1	
19	KB BA05 10	Screw Pan Cross	1	




FWD Front Wheel Direction

Plate No.: 32


Tubeless Tyre & Rim

No.	Part No.	Description	Qty.	Remarks
1	DT 1310 18	Tyre Front 100/80-17	1	
2	DK 1510 26	Valve Tubeless Tyre	2	
3	56 JF9N 33	Wheel Front Mt 2.50x17 Black Colour	1	
	56 JF9N 7D	Wheel Front Mt 2.50x17 Silver Colour	1	
4	56 JF8U 33	Wheel Rear Mt 3.00x17 Black Colour	1	
	56 JF8U 7D	Wheel Rear Mt 3.00x17 Silver Colour	1	
5	DT 1312 22	Tyre Rear 130/70-17	1	




Front Hub

No.	Part No.	Description	Qty.	Remarks
1	JG 1310 07	Flange bolt M8	1	
2	JG 1310 20	Collar CH 0.7_0.9	2	
3	JG 1318 02	Disc mounting bolt	6	
4	DT 1318 67	Sensor Disc Front	1	
5	JP 1318 61	Disc Brake Dia 300	1	
6	DG 1510 05	Seal Oil	2	
7	KP BC62 02	Bearing Ball C3 Clearance	2	
8	JG 1310 01	Spacer Assembly Front Wheel	1	
9	JG 1310 03	Front Axle	1	
10	DT 4024 04	Sensor speed wheel	1	
11	JF 1210 49	Spacer Speed Sensor	1	
12	LA E000 55	Bolt Flange Small	1	M6 x 1 x L16
13	KE BA35 15	Circlip Internal	1	




Master Cylinder - Front

No.	Part No.	Description	Qty.	Remarks
1	JF 1318 89	Cylinder master assly. front	1	
2	DJ 1910 29	Bolt Front Bracket I	1	
3	DJ 1910 30	Nut	1	
4	36 DH19 02	Oil Window Kit	1	
5	DJ 1910 31	Screw	2	
6	DE 1910 29	Cover - Reservoir	1	
7	DE 1910 28	Diaphragm	1	
8	JG 1610 10	Lever Front Brake	1	
9	DJ 2011 09	Switch brake	1	
10	DE 1910 10	Washer - Copper	8	
11	DK 1510 69	Bolt - Banjo	4	
12	36 JF00 80	Kit Hose Front Caliper	—	
13	LA D000 37	Bolt Flanged M8 x 1 x 50	2	
14	36 DT00 34	Major Kit M Cylinder	1	
15	36 PD00 38	Minor Kit M Cylinder	1	
16	36 JF01 85	Kit front clamp	1	
17	36 JF00 82	Kit Push Rod	1	




Caliper Assembly - Front

No.	Part No.	Description	Qty.	Remarks
1	JG 1318 04	Caliper assy brake front	1	
2	JG 1318 11	Bleeder screw	1	
3	DE 1510 47	Bleeder Cap	1	
4	36 JG00 17	Disc pad	1	
5	JU 1318 16	Minor kit	1	
6	JU 1318 15	Major Kit	1	
7	LA D000 79	Bolt flanged	2	
8	59 0400 48	Bolt front brake pad	1	
9	JG 1318 13	Spring clip	1	



Anti Brake Lock System

No.	Part No.	Description	Qty.	Remarks
1	JF 1319 12	Unit ABS	1	
2	36 JF01 79	Kit hose cyl master front unit ABS	1	Refer Kit List
3	36 JF01 80	Kit hose unit ABS caliper front	1	Refer Kit List
4	36 JF01 81	Kit hose cyl master rear unit ABS	1	Refer Kit List
5	36 JF01 82	Kit hose unit ABS caliper rear	1	Refer Kit List
6	JF 1138 52	Bracket unit ABS with bush	1	
7	DH 1013 85	Bolt flanged - M6	2	
8	39 1309 11	Plain washer	2	
9	DT 1318 75	Clamp For ABS Hose	1	
10	JF 1612 07	Bracket Cable Clutch	1	
11	LA E000 57	Bolt Flange Small - M6x1xL25	1	
12	DE 1910 10	Copper Washer	8	
13	DK 1510 69	Benjo Bolt	4	
14	DT 1318 78	Clamp W	4	
15	KA DF06 08	Bolt flanged	1	




FWD Front Wheel Direction

Plate No.: 37


Rear Disc Brake Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 1318 58	Assembly Caliper	1	
2	JF 1318 88	Assembly Master Cyl. Rear	1	
3	36 JF01 86	Rear reservoir tube kit	1	
4	DE 1510 47	Cap Bleeder Screw	1	
5	DE 1510 46	Bleeder Screw	1	
6	YJ L040 05	Kit Major Caliper	1	
7	YJ L040 06	Kit Minor Caliper	1	
8	DK 1510 85	Set Disc Pad	1	
9	30 1910 38	Pin	1	
10	KD BA06 13	Washer	1	
11	KH AA20 15	Split Pin	1	
12	36 JF00 85	Kit Push Rod	1	
13	36 JF00 85	Kit Major Rear Master Cyl.	1	N.I.
14	36 DT00 40	Kit Minor Rear Master Cyl.	1	N.I.
	DK 1510 74	Kit Minor Rear Master Cyl.	1	N.I.
15	LA D000 77	Bolt Flange - M6 x 1 x L16	1	
16	KA DD06 14	Bolt Flanged	1	
17	36 JF01 84	Rear reservoir kit	1	
18	36 DT00 52	Bracket caliper mounting rear	1	



Rear Hub

No.	Part No.	Description	Qty.	Remarks
1	DT 4024 04	Sensor speed wheel	1	
2	JL 1312 03	Axle Rear	1	
3	LD B000 57	Washer Plain	2	
4	KE BA42 17	Circlip Internal	1	
5	JL 1312 11	Spacer For Coupling	1	
6	36 JF02 09	Kit Chain Sprocket	1	Refer Kit List
7	DT 1312 13	Coupling	1	
8	DT 1312 10	Sleeve	1	
9	JU 1312 22	Damper 6 Rubber	6	
10	KP BC62 02	Bearing Ball - C3 Clearance	1	
11	JL 1312 16	Collar Bearing Assembly	1	
12	KP BC63 02	Bearing Ball - C3 Clearance	1	
13	30 1510 82	Seal Oil	1	
14	JF 1318 61	Disc Rear	1	
15	DH 1510 40	Bolt socket - M6	6	
16	JU 1318 02	Sensor Disc Rear	1	
17	JG 1312 20	Screw For ABS	3	
18	DK 1510 82	Spacer II	1	
19	DK 1510 81	Spacer I	1	
20	LC J000 05	Nut U	1	M14 x 1.5 x HT12.5
21	KP AC62 05	Coupling Bearing	1	
22	JG 1312 28	Bolt D	6	
23	LC L000 04	Nut	6	
24	DT 1312 14	Seal oil 52 DIA	1	



Rear Brake Pedal

No.	Part No.	Description	Qty.	Remarks
1	JF 1610 06	Brake Pedal	1	
2	LD B000 56	Washer Pivot Bolt	1	
3	39 1998 19	Seal - Oil	2	
4	JC 1910 09	Bolt Brake Pedal	1	
5	JF 1610 04	Brake Return Spring	1	
6	JL 4014 06	Brake Switch Rear	1	
7	JM 1910 14	Spring Brake Switch Rear	1	
8	JF 1610 07	Damper Brake Pedal	1	
9	JZ 1318 75	Pin	1	
10	KH AA20 15	Pin Snap	1	
11	JF 1130 37	Bracket switch brake rear	1	
12	LA D000 85	Bolt M6 x 1	1	
13	DP 1610 94	Bolt - stepped - M6	1	





Plate No.: 40

Handle Bar Assembly

No.	Part No.	Description	Qty.	Remarks
1	56 JF9J 9L	Handle Bar Matte Black	1	
2	JF 1610 13	Assembly lever - holder LH	1	
3	JG 1610 08	Clutch Lever	1	
4	JF 4014 13	Switch Control LH	1	
5	DH 1910 67	Handle Grip LH	1	
6	DH 1810 22	Handlebar Weight	2	
7	KA CJ06 55	Bolt Socket	2	
8	JF 4014 14	Switch Control RH	1	
9	JG 1510 22	Throttle Pipe	1	
10	JF 1510 51	Grip Assembly RH	1	
11	LA C001 11	Bolt Socket M8 x 1.25 x L29	4	
12	56 JF5A W4	Handle holder upper	1	(Glossy black)
13	LA C001 48	Bolt socket - M10	2	
14	56 JF5B W4	Handle holder lower	1	(Glossy black)
15	JF 1510 47	Washer Cup	4	
16	JF 1510 54	Damper	2	
17	JF 1510 55	Spacer	2	
18	56 JFA8 33	Bracket upper	1	(Matt black)
19	JY 1210 11	Bolt Socket M8 x 1.25 x L30	2	
20	LC H000 01	Nut - Nyloc	2	



Handle Bar Assembly

No.	Part No.	Description	Qty.	Remarks
21	DT 4014 05	Ignition Switch	1	Refer Kit List
22	LA D002 44	Bolt flanged - M6	2	
23	JF 2326 16	Set lock	1	
24	JY 4014 04	Clutch Switch	1	
25	JF 1610 14	Holder lever LH	1	
26	LA D002 13	Bolt flange	1	
27	LB B000 16	Screw pan cross - M5	1	
28	LC H000 05	Nut nyloc - M5	1	





Plate No.: 41

Front Fork

No.	Part No.	Description	Qty.	Remarks
1	JF 1210 68	Fork front	1	
2	DK 1810 17	Guide Bush	2	
3	DK 1810 11	Slide Bush	2	
4	YJ F260 01	LH Pipe Inner with Axle Clamp	1	
5	YJ F260 02	RH Pipe Inner with Axle Clamp	1	
6	YJ F260 09	Fork top bolt	2	
7	YJ F260 08	Fork outer tube only	2	
8	DK 1810 18	Washer plain	2	
9	JF 1814 81	Protector fork LH	1	
10	DK 1810 20	Oil Seal Stopper (Circlip)	2	
11	JF 1814 82	Protector fork RH	1	
12	JF 1210 63	Outer Dust Cap	2	
13	LA C000 10	Bolt socket - M6	2	
14	JG 1138 32	Sleeve for abs hose clamp	2	
15	YJ F260 05	Main Spring & Spacer Assly.	2	
16	JF 1210 69	Bracket Assembly Under	1	
17	JY 1210 11	Bolt socket - M8	6	
18	DJ 1710 39	Oil Seal	2	
19	YJ F260 06	Rubber damper	2	
20	YJ F260 04	Screw cap inner pipe	2	




FWD Front Wheel Direction

Plate No.: 41


Front Fork

No.	Part No.	Description	Qty.	Remarks
21	YJ F260 03	Piston rod assembly	2	
22	YJ F260 07	Lock Nut	2	
23	JF 1210 75	Clamp hose	1	
24	DK 1810 21	Dust Seal	2	



Petrol Tank, Cap Tank & Gauge Fuel

No.	Part No.	Description	Qty.	Remarks
1	JF 1710 72	Tank assembly fuel	1	
2	JF 1716 26	Cap Tank	1	Will be supplied in lock set
3	KA CD05 16	Screw Allen	6	
4	JF 1718 11	Fuel Pump Module - Pump	1	
5	LA D001 54	Bolt Flange	6	M6 x 1 x L12.8
6	DT 1718 39	Plate Pressure Fuel Pump Mtg	1	
7	JF 6112 07	Cap Injector - Connection Quick	1	
8	DT 1710 89	Assy Tube Filter To Regulator	1	
9	DT 1710 87	Tube Pump to Filter	1	
10	DT 1718 14	Inline Fuel Filter	1	
11	JF 1710 67	Sleeve Tank Mtg Rear	2	
12	DT 1710 61	Tube drain	1	
13	JG 1710 30	Clamp	1	
14	KA DF08 25	Bolt Flange	2	
15	JF 1710 55	Sleeve Tank Mtg Front	1	
16	JF 1710 68	Grommet Tank Mtg Front	1	
17	JF 1710 69	Grommet Tank Mtg Rear	2	
18	JF 1710 23	Tank Damper Top Front LH	1	
19	JF 1710 24	Tank Damper Top Front RH	1	
20	JF 1710 25	Tank Damper Top Central LH	1	




Front Wheel Direction

Plate No.: 42


Petrol Tank, Cap Tank & Gauge Fuel

No.	Part No.	Description	Qty.	Remarks
21	JF 1710 26	Tank Damper Top Central RH	1	Refer Kit List
22	JF 2326 16	Set Lock	1	
23	JY 4022 35	Pig Tail Fuel Pump	1	
24	JF 1710 56	Foam	2	
25	JF 1813 46	Cover Frame Front	1	
26	LA E000 54	Step Bolt	1	
27	JL 1710 38	Beading tank LH	1	
28	JD 1710 59	Damper	1	
29	JF 1710 83	Bracket cover tank rear	1	
30	KA DD06 10	Bolt flanged	2	

EVAP Mechanism



No.	Part No.	Description	Qty.	Remarks
1	JF 1138 21	Bracket Canister Mtg.	1	
2	KA EA06 10	Bolt Flanged Small	3	
3	DT 1138 49	Strap ECU Canister	2	
4	JY 1710 77	Canister	1	
5	JF 1716 13	Tube Canister Drain	1	
6	JF 1716 23	Pipe Canister - Connector	1	
7	JF 1716 24	Pipe Connector - Valve purge	1	
8	JF 1138 53	Bracket Valve Purge	1	
9	JU 1716 06	Valve Purge	1	
10	KC EA06 05	Nut Dome Cap	1	
11	JF 1716 25	Pipe Valve Purge - Connector	1	
12	JG 1710 86	Connector Tube EVAP	2	
13	DT 1718 47	Tube Connector To Throttle Body	1	
14	JF 1716 04	Tube Y Connector to Canister	1	
15	JY 1138 42	Connector Y Shape	1	
16	JF 1716 07	Tube Y Connector To Plug	1	
17	JY 1718 25	Plug Fuel Drain	1	
18	JY 1710 69	Spring Band Clamp 15 x 10	1	
19	JL 1711 01	Clamp Band Spring 9.5 x 8.4	5	
20	JL 1711 02	Clamp Band Spring 12.5 x 8	4	
21	JG 1710 29	Spring Band 11.5 x 8.4	6	
22	JF 1716 03	Tube Tank To Y Connector	1	
23	DT 1718 21	Clamp Pump End Permanent	2	




FWD Front Wheel Direction

Plate No.: 44


Fitting - Petrol Tank Cover

No.	Part No.	Description	Qty.	Remarks
1	JF 1710 35	Bracket Tank Side Cover LH	1	
2	JF 1710 36	Bracket Tank Side Cover RH	1	
3	KA DA05 10	Bolt Flanged	6	
4	39 1839 11	Washer plain	2	
5	JF 4024 07	Speedometer Tank Assembly	1	
6	JF 1710 43	Bracket speedometer	1	
7	LB R000 10	Screw Tapping Pan Cross	17	
8	JF 1710 22	Tank Central Cover	1	
9	39 1907 01	Mushroom Head Screw	8	
10	JF 1710 28	Bracket Tank Cover Rear	1	
11	LB U000 65	Screw Truss - M5 x 0.8 x L14	2	
12	JF 1710 66	Collar Cover Tank	6	
13	JF 1710 29	Beading Fuel Tank	1	
14	JF 1710 65	Grommet Cover Tank	6	
15	JG 1812 59	Plug Push Pull	1	
16	LA C001 33	Bolt Socket	6	
17	JF 1710 94	Decal dome tank charcoal	1	
18	JF 1710 58	Anti Abrasive Tape	1	
19	JB 4010 12	Foam	2	
20	JG 1710 31	Clip Nut M5	12	
21	JF 1710 54	Damper cover - tank - side	2	
22	KB UH05 14	Screw truss - M5 x 0.8 x L	2	
23	KB RD42 13	Screw tapping pan cross	2	
24	JF 1710 19	Cover Cap Tank	1	




Fitting - Side Covers, Seat Cowls & Under Tray Front

No.	Part No.	Description	Qty.	Remarks
1	LB U000 69	Screw Truss	4	
2	LD B000 72	Plain washer	4	
3	LB U000 65	Screw Truss	8	
4	JG 1710 31	Clip Nut M5	10	
5	JZ 1812 71	Damper Side Cover	2	
6	JH 1812 55	Washer Retaining	2	
7	LA D002 02	Bolt Flanged	4	
8	DT 1810 07	Under Tray Front	1	
9	JF 1138 18	Bracket Rear Fender Mounting	1	
10	DS 1410 12	Grommet side cover FR	4	
11	LD B000 14	Washer Plain	2	




Speedometer Assembly

No.	Part No.	Description	Qty.	Remarks
1	JF 4024 18	Speedometer	1	
2	JZ 1813 65	Grommet Dashboard	3	
3	LD B000 07	Washer Plain	3	
4	KC AA05 04	Nut Hex Thick	3	
5	JF 1812 65	Speedo Flap	1	
6	JF 1812 69	Bracket Speedo Mounting Upper	1	
7	KD BA05 12	Washer Plain	2	
8	KB UF05 08	Screw Truss	2	
9	JF 1812 70	Bracket Mask Carrier Lower	1	
10	LA D001 02	Bolt Step	2	
11	YJ F040 01	Top cover & ring-Main speedo	1	
12	YJ F040 02	Top cover & ring-Tank speedo	1	
13	JG 1812 58	Rubber strap for molex cupler	1	
14	PF 1812 11	Grommet - cowling mounting	3	
15	LB U000 67	Screw Truss - M6	4	




Control Cables & Chain Case

No.	Part No.	Description	Qty.	Remarks
1	JF 1612 05	Cable Throttle	1	
2	JF 1612 04	Cable Clutch	1	
3	JF 1612 07	Bracket Clutch Cable	1	
4	JF 1612 08	Bush T Clutch Cable	1	
5	JF 1813 77	Cover Assembly Chain	1	
6	JF 1813 16	Collar - Cover Chain Mounting	5	
7	LA C000 54	Screw Button Head	5	M6 x 1 x L16 x BRT5
8	LA E000 57	Bolt flange - M6	1	




Head Lamp Assembly & Front Number Plate

No.	Part No.	Description	Qty.	Remarks
1	JU 2328 00	Front Number Plate	1	
2	LB U000 65	Screw Truss M5 x 0.8 x L14	2	
3	LD B000 74	Washer Plain	2	
4	JF 2328 06	Bracket plate number front	1	
5	LB U000 66	Screw truss	4	
6	39 2141 24	Washer Plain Small	4	
7	DT 1813 06	Windshield	1	
8	JZ 2328 14	Pad Rubber Number Plate Bkt	2	
9	JF 1812 68	Side Mask LH	1	
10	JF 1812 67	Side Mask RH	1	
11	LD B000 74	Plain Washer	4	
12	LB U000 65	Screw Truss	4	
13	JF 1812 66	Mask Carrier	1	
14	KB UA06 14	Screw Truss	7	
15	LD B000 72	Plain Washer	4	
16	LB U000 55	Screw Button Head	2	M6 x 1 x L15
17	JF 1812 75	Decal Mask LH	1	
18	JF 1812 76	Decal Mask RH	1	
19	DT 4010 20	Head Lamp Assembly	1	
20	KD BA06 13	Washer Plain	3	
21	JF 1812 77	Well Nut	4	
22	DT 1810 30	Tape anti abrasive 3M - K8	8	
23	JD 1812 30	Foam	2	
24	JF 1813 61	Foam	2	
25	JF 1813 62	Foam	2	




Indicator Light Assembly

No.	Part No.	Description	Qty.	Remarks
1	DT 4010 02	Indicator Assembly Front LH	1	
2	DT 4010 03	Indicator Assembly Front RH	1	
3	KD AA10 18	Washer Plain Small	4	
4	KD FB10 18	Washer Toothed	4	
5	KC AD10 08	Nut Hex Thick	2	
6	JY 4010 24	Indicator Assembly RR LH	1	
7	JY 4010 25	Indicator Assembly RR RH	1	
8	KC GA10 10	Nut Hex Flanged	2	



Tail Lamp Assembly & Rear Number Plate

No.	Part No.	Description	Qty.	Remarks
1	JF 4010 22	Lamp tail	1	
2	JF 1814 20	Fender Rear	1	
3	KB UA05 14	Screw truss	5	
4	JF 1814 21	Under Tray Fender Rear	1	
5	LD B000 23	Washer plain	2	
6	KA DD06 12	Bolt flanged	2	
7	JF 1814 22	Reinforcement Rear Fender	1	
8	JG 4010 06	No. Plate Illumination Lamp	1	
9	LB R000 03	Screw CR Pan Head Tap	1	4 x 1.59
10	JF 1814 24	Flap Rear Fender	1	
11	LC G000 30	Nut Flange	2	
12	JF 2328 07	Bracket plate number rear	1	
13	JG 4010 36	Reflector - Reflex	1	
14	KC GA05 05	Nut Hex Flanged	1	
15	JZ 2328 05	Foam Rear Number Plate	1	
16	DJ 2011 73	Grommet For Cables	2	Rear Fender
17	DP 1611 45	Number Plate Rear	1	
18	KA DD06 10	Bolt flanged	5	
19	LA D001 95	Bolt flange - M6	2	
20	JF 4010 30	Reflex reflector LH	1	
21	JF 4010 31	Reflex reflector RH	1	
22	KC HA05 07	Nut Nylock	4	




FWD Front Wheel Direction

Plate No.: 51


Electrical Equipments

No.	Part No.	Description	Qty.	Remarks
1	JF 4022 64	Harness wiring	1	Refer Kit List
2	JL 4030 00	Relay	4	
3	36 DT00 04	Kit Band Wiring Harness	1	
4	JG 4020 02	DC Flasher	1	
5	JP 4022 03	Cable Relay To Motor	1	
6	JF 4022 11	Cable Earth	1	
6A	LD F000 01	Washer toothed - cable earth	3	
7	JL 4032 00	Termination Unit	1	
8	JF 4016 01	Horn	1	
9	LD B000 73	Washer - Plain	1	
10	LC L000 07	Nut U Flanged - M8	1	
11	JP 4030 00	Relay Starter	1	
12A	DT 4022 26	Fuse - 7.5A	5	
12B	JG 4022 29	Fuse 15A	7	
12C	JG 4022 30	Fuse 30A	2	
13	JG 4022 28	Fuse 10A	2	
14	DT 1138 51	Bracket Fuse Box Mtg Loose	1	
15	JY 4036 04	Roll Over Sensor	1	
16	JF 1138 42	Bracket Roll Over Sensor	1	
17	KA CF06 12	Bolt Socket	2	M6 x 1 x L12
18	LA C000 08	Screw Truss	2	M6 x 1 x L25
19	LD B000 72	Plain Washer	2	
20	KC HA06 08	Nut nyloc	2	




Electrical Equipments

No.	Part No.	Description	Qty.	Remarks
21	JG 4018 00	12V 8Ah VRLA Battery	1	
22	JF 1812 72	Assembly Battery Case	1	
23	JF 1813 08	Rubber Battery Case	1	
24	KA ED06 22	Bolt Flanged Small Length	2	
25	KA ED06 25	Bolt Flanged Long Length	2	
26	JL 1138 25	Band Battery Case Vertical	1	
27	DT 1810 22	Band Battery Case	1	
28	JF 1138 61	Bracket horn	1	
29	JF 1710 64	Band cable	2	
30	DT 1813 16	Sleeve battery case	4	
31	DT 1813 17	Grommet battery case	4	
32	JK 4018 01	Foam battery band	6	
33	PA 4022 04	Band (Length 110MM)	10	
34	JD 4022 17	Tie band (L 150)	11	
35	JF 1138 57	Bracket Relay Starter	1	
36	KA CA06 10	Bolt Master KAC	2	



1




1	22221016	Bag Polyethylene	1
2	JF231002	Bag Tool	1
3	JF231003	Bar Tool	1
4	JF231004	Tool Wrench 10 X 14	1
5	JF231005	Tool Wrench 13 X 17	1
6	JF231006	Tool Wrench 22 AF	1
7	JF231007	Screw Driver	1
8	JF231008	Tool Wrench 14 X 16	1
9	JF231009	Key Allen – 5mm	1
10	JF231001	Spanner Flat - 12 X 8	1
11	JL231003	Tool Kit – Band	2
12	JF231012	Key Allen 10mm	1
13	JF231013	Key Allen 6mm	1




Tool Kit

No.	Part No.	Description	Qty.	Remarks
1	JF 2310 10	Tool kit	1	Not Serviceable
2	JL 2310 03	Tool kit band	2	




No.	Part No.	Description	Qty.	Remarks
1	56 DT5U 36	Grab handle LH silk matt blk	1	
	56 DT5U 36	Grab Handle LH-Silk Matte Black	1	
2	56 DT5V 36	Grab handle RH silk matt blk	1	
	56 DT5V 36	Grab Handle RH - Silk Matte Black	1	
3	LA C001 19	Bolt Master KAC	4	
4	JF 2312 26	Guard Sari	1	
5	KA CC06 18	Bolt Socket	1	
6	KA CA08 18	Bolt Master KAC	2	
7	JL 2312 09	Plug Saree Guard	1	
8	JF 2312 11	Plug Saree Guard	2	
9	JF 2316 08	Mirror LH	1	
10	JF 2316 09	Mirror RH	1	
11	JF 2312 39	Guard Leg LH	1	
12	JF 2312 40	Guard leg RH	1	
13	KD AB08 16	Washer Plain Small	2	
14	LA C001 65	Bolt Socket - M8 x 1.25	2	
15	LD B000 84	Washer	2	
16	LC L000 07	Nut U flanged - M8	2	
17	LA A000 51	Bolt - M8 x 1.25 x L14	2	
18	LD H000 16	Washer conical	2	
19	KD AA08 16	Washer plain small	2	
20	LA C001 41	Bolt socket - M8	2	
21	JF 2314 15	Strap rear	2	
22	LB U000 55	Screw button head - M6	2	

Painted Parts and Decals




No.	Part No.	Description	Qty.	Remarks
1	56 JF14 4X	Side mask LH in satin black	1	
2	56 JF15 4X	Side mask RH in satin black	1	
3	56 JF8C 9A	Tank cover LH glamour green	1	
	56 JF8C 6D	Tank cover LH charcoal black	1	
	56 JF20 8X	Tank cover LH Canyon Red	1	
4	56 JF8D 9A	Tank cover RH glamour green	1	
	56 JF8D 6D	Tank cover RH charcoal black	1	
	56 JF21 8X	Tank cover RH Canyon Red	1	
5	56 JF22 9A	Tank cover top glamour green	1	
	56 JF22 6D	Tank cover top charcoal black	1	
	56 JF22 8X	Tank cover top Canyon Red	1	
6	52 JF13 51	Belly pan LH satin black + decal glamour green	1	
	52 JF13 45	Belly pan LH satin black + decal graphite matt black	1	
	52 JF17 68	Belly pan LH satin black + decal canyon red	1	
7	52 JF13 52	Belly pan RH satin black + decal glamour green	1	
	52 JF13 46	Belly pan RH satin black + decal graphite matt black	1	
	52 JF17 69	Belly pan RH satin black + decal canyon red	1	
8	52 JF13 53	Seat cowl LH glamour green	1	
	52 JF12 79	Seat cowl LH charcoal black	1	
	52 JF17 74	Seat cowl LH Canyon Red	1	
9	52 JF13 54	Seat cowl RH glamour green	1	
	52 JF12 80	Seat cowl RH charcoal blk+dcl	1	
	52 JF17 76	Seat cowl RH Canyon Red	1	

Painted Parts and Decals




No.	Part No.	Description	Qty.	Remarks
10	52 JF13 55	Front Fender Black + Glamour Green	1	
	52 JF13 49	Front Fender Black + Charcoal black	1	
	52 JF17 70	Front Fender Black + Canyon Red	1	
11	JF 2331 98	Decal 3D	2	
12	JF 2332 44	Decal 3D Cowl Seat	2	
13	JF 2332 45	Decal Cover Clutch	1	
14	JF 5412 12	Label Bajaj	1	
15	JF 2332 34	Decal ring cover magneto	1	
16	JF 2332 35	Decal ring cover clutch	1	
17	56 JF8L 9A	Mask headlamp glam green	1	
	56 JF8L 6D	Head lamp mask Charcoal blk	1	
	56 JF8L 8X	Head lamp mask Canyon Red	1	
18	JF 1813 51	Belly pan center in satin blk	1	
19	56 JF13 4X	Cover side RH satin black	1	
20	56 JF12 4X	Cover side LH satin black	1	
21	JF 2332 22	Decal belly pan LH glam green	1	
	JF 2332 37	Decal belly pan LH charcoal	1	
	JF 2332 56	Decal belly pan LH Canyon Red	1	
22	JF 2332 23	Dcl belly pan RH glam green	1	
	JF 2332 38	Decal belly pan RH charcoal	1	
	JF 2332 57	Decal belly pan RH Canyon Red	1	
23	JF 2332 30	Decal cowl seat upper LH blk	1	
24	JF 2332 31	Decal cowl seat upper RH blk	1	
25	JF 1710 93	Decal dome tank	1	
26	JF 1711 05	Decal dome tank Canyon red	1	

Painted Parts and Decals - From Aug. 2021




No.	Part No.	Description	Qty.	Remarks
1	56 JF22 8X	Tank Cover Top Canyon Red	1	
	52 JF23 36	Tank Cover Top Citrus Rush+ Decal	1	
	52 JF23 15	Tank Cover Top Spark Black + Decal	1	
2	52 JF23 29	Seat Cowl LH Citrus Rush+ Decal	1	
	52 JF22 07	Seat Cowl LH R Red Black + Decal N C&G	1	
	52JF2307	Seat Cowl Lh Abs Spar Black	1	
	52 JF22 09	Seat Cowl RH R Red Black + Decal N C&G	1	
	52 JF23 31	Seat Cowl RH Citrus Rush+ Decal	1	
	52JF2309	Seat Cowl Rh Abs Spar Black	1	
3	52 JF23 26	Tank Cover LH Platinum Silver Matt+ Racing Red Decal	1	
	52 JF23 34	Tank Cover LH Platinum Silver +citrus Decal	1	
	52 JF23 13	Tank Cover Lh Plat Silver+spark Black Decal	1	
	52 JF23 35	Tank Cover RH Platinum Silver +citrus Decal	1	
	52 JF23 27	Tank Cover RH Platinum Silver Matt+ Racing Red Decal	1	
	52 JF23 14	Tank Cover Rh Plat Silver+spark Black Decal	1	
4	56 JF13 6E	Cover Side RH Sparkling Black+platinum Silver	1	
	56 JF12 6E	Cover Side LH Sparkling Black+platinum Silver	1	
5	52 JF22 38	Side Mask LH Racing Red+ Decal	1	
	52 JF23 42	Side Mask LH Citrus Rush + Decal.	1	
	52 JF23 23	Side Mask LH In Satin Black	1	
	52 JF23 24	Side Mask RH In Satin Black	1	
	52 JF22 39	Side Mask RH Racing Red+ Decal	1	
	52 JF23 43	Side Mask RH Citrus Rush + Decal	1	
6	52 JF23 32	Assembly Front Fender Citrus Rush	1	
	52 JF17 70	Assembly Front Fender Canyon Red	1	
	52JF2311	Assembly Front Fender Satin Black	1	
7	52 JF23 40	Belly Pan LH Satin Black+citrus Decal	1	
	52 JF22 28	Belly Pan LH Sparkling Black + Decal	1	
	52 JF22 31	Belly Pan LH Sparkling Black + Red Decal	1	
	52 JF23 41	Belly Pan RH Satin Black+citrus Decal	1	
	52 JF22 27	Belly Pan RH Sparkling Black+ Decal	1	
	52 JF22 30	Belly Pan RH Sparkling Black+Red Decal	1	
	52JF2320	Belly Pan LH+RH Satin Black	1	
8	56 JF24 4X	Shroud LH Satin Black	1	
	56 JF25 4X	Shroud RH Satin Black	1	
9	56 JF8L 4X	Lamp Mask Sparkling Black	1	
10	JF 1817 84	Belly Pan Middle	1	

Painted Parts and Decals - From Aug. 2021



No.	Part No.	Description	Qty.	Remarks
11	JF 2334 73	Decal Dome Tank Sparkling Black	1	
	JF 2334 94	Decal Dome Tank Citrus Rush -Platinum Silver	1	
12	JF 2334 71	Decal Wheel Sparkling Black LH	2	
	JF 2334 72	Decal Wheel Sparkling Black RH	2	
	JF 2334 92	Decal Wheel Racing Red -Platinum Silver LH	2	
	JF 2334 84	Decal Wheel Citrus Rush - Platinum Silver LH	2	
	JF 2334 93	Decal Wheel Racing Red -Platinum Silver RH	2	
	JF 2334 85	Decal Wheel Citrus Rush - Platinum Silver RH	2	
	JF233496	Decal Wheel C R Matte Black Lh	2	From Dec 21
	JF233497	Decal Wheel C R Matte Black Rh	2	From Dec 21
	JF233498	Decal Wheel Sprint Black Matte Lh	2	From Dec 21
	JF233499	Decal Wheel Sprint Black Matte Rh	2	From Dec 21
	JF233500	Decal Wheel Racing Red Matte Black Lh	2	From Dec 21
	JF233501	Decal Wheel Racing Red Matte Black Rh	2	From Dec 21
13	JF 2334 18	Decal Belly Pan Racing Red LH	1	
	JF 2334 19	Decal Belly Pan Racing Red RH	1	
	JF 2334 74	Decal Belly Pan Citrus Rush -platinum Silver LH	1	
	JF 2334 75	Decal Belly Pan Citrus Rush -platinum Silver RH	1	
	JF 2334 61	Decal Belly Pan Sparkling Black LH	1	
	JF 2334 62	Decal Belly Pan Sparkling Black RH	1	
14	JF 2334 32	Decal Fairing Racing Red LH	1	
	JF 2334 33	Decal Fairing Racing Red RH	1	
	JF 2334 69	Decal Fairing Sparkling Black LH	1	
	JF 2334 70	Decal Fairing Sparkling Black RH	1	
	JF 2334 82	Decal Fairing Citrus Rush - Platinum Silver LH	1	
	JF 2334 83	Decal Fairing Citrus Rush - Platinum Silver RH	1	
15	JF 2334 63	Decal Cowl Seat Sparkling Black Silver LH	1	
	JF 2334 86	Decal Cowl Seat Racing Red -Platinum Silver LH	1	
	JF 2334 76	Decal Cowl Seat Citrus Rush -Platinum Silver LH	1	
	JF 2334 77	Decal Cowl Seat Citrus Rush - Platinum Silver RH	1	
	JF 2334 64	Decal Cowl Seat Sparkling Black Silver RH	1	
	JF 2334 87	Decal Cowl Seat Racing Red -Platinum Silver RH	1	

Painted Parts and Decals - From Aug. 2021



No.	Part No.	Description	Qty.	Remarks
16	JF 2334 67	Decal Cover Tank Sparkling Black LH	1	
	JF 2334 68	Decal Cover Tank Sparkling Black RH	1	
	JF 2334 90	Decal Cover Tank Racing Red -Platinum Silver LH	1	
	JF 2334 80	Decal Cover Tank Citrus Rush - Platinum Silver LH	1	
	JF 2334 81	Decal Cover Tank Citrus Rush - Platinum Silver RH	1	
	JF 2334 91	Decal Cover Tank Racing Red -Platinum Silver RH	1	
17	JF 2334 88	Decal Cover Tank Upper Racing Red -Platinum Silver LH	1	
	JF 2334 78	Decal Cover Tank Upper Citrus Rush -Platinum Silver LH	1	
	JF 2334 89	Decal Cover Tank Upper Racing Red -Platinum Silver RH	1	
	JF 2334 79	Decal Cover Tank Upper Citrus Rush -Platinum Silver RH	1	
	JF 2334 65	Decal Cover Tank Upper S Silver LH	1	
	JF 2334 66	Decal Cover Tank Upper S Silver RH	1	
18	JF 2332 30	Decal Seat Cowl Black LH	1	
	JF 2332 31	Decal Seat Cowl Black RH	1	

1		2		3	
4		5		6	
7		8		9	
10		11		12	



Consumable Parts

No.	Part No.	Description	Supply Unit	Application
1	83 0205 76 83 0205 78 83 0205 77	Oil Bajaj DTS-i 10W50 BS VI Oil Bajaj DTS-i 10W50 BS VI Oil Bajaj DTS-i 10W50 BS VI	1.2 Ltr. 1 Ltr. 100 ML.	Top Up
2	36 0010 58	Bajaj Coolant Koolux*	1 Ltr.	Coolant Top-up/Replace
3	36 DH40 61	Brake Fluid DOT4	100 ml	Disc Brake Top-up/Replace
4	36 DH40 52	Silicon grease	3 gm	Caliper Pin
5	83 0204 73 36 DK00 45	Grease Petamo GHY 441 Grease Molycoat	3 gm 200 gm	Water Pump Seals For Starter Clutch Lubrication
6	36 JL01 81	Limaplex HTX 3 Grease	10 gm	Steering Race
7	83 0201 73	Multi Purpose Grease* (Local Purchase)	--	Lubrication of Clutch Lever, Brake Lever, Brake Pedal & Side Stand
8	36 0010 55	Chain Lubricant HP Make	1 kg	Non - Sealed Chain Lubrication
9	36 0010 62	Liquid gasket L5910	50 ml	Crankcase Joining
10	36 3140 04 36 JG00 87	Fork oil Fork oil 480 ml (Dominar UG)	160 ml 480 ml	Front Fork Top-up/Replace\ Front Fork Top-up/Replace\
11	36 DH40 29	Kit Spray Chain Lub	100 ml	Sealed Drive Chain
12	36 DH40 71	Wonderfill Chain Spray	100 ml	Sealed Drive Chain

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

13		14		15	
16		17		18	
19		20		21	
22		23		24	



Front Wheel Direction

Plate No.: 56

Consumable Parts

No.	Part No.	Description	Supply Unit	Application
13	36 DH40 72	Rust Remover Spray Make - Zorric 88 & Wonder fill easiner	100 ml	For Removing Rust from Components
14	76 0109 36	Loctite Thread locker 243*	50 ml	For Screws & Bolts
15	76 0109 37	Loctite retaining compound 638*	50 ml	For Screws & Bolts
16	37 0043 52	Touch up paint slate grey*	440 ml	Touch up of Frame, Swing Arm & Step Holder
17	37 0043 53	Touch up paint Matte Silk black*	440 ml	Touch up of Grab Handle, Handle Bar & Handle Holder
18	36 0010 60	Kibatsu touch up paint*	400 cc	Touch up of Cylinder head, Block & Alloy Wheels
19	37 2240 18	Paint Bottle Schwartz Black*	--	P-200NS Frame Touch-up
20	75 6802 36 NA	Petroleum Jelly (Local Purchase) Distilled Water (Local Purchase)	-- 1 Ltr.	For Battery Terminals For Battery Level Top-up
21	NA	SAE 90 oil (Local Purchase)	-	
22	62 3050 84	WD40 Spray (Local Purchase)	400 ml	Electrical Contact Cleaning Spray
23	36 0010 56	Carburetor Cleaning Spray*		For Cleaning Carburetor/ Throttle Body
24	37 2540 39	Corrosion Protection Spray* Proto quick LTP902	--	For Preventing vehicle parts from rusting

* Marked items to be arrange from vendor or local market. Not applicable against chassis number.

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
1	JF511058	Head Cylinder - Holder Camshaft	JF511059	Head Cylinder	1
			JY511106	Holder Assembly Camshaft	1
			JY511058	Guide Chain Top	1
			39168606	Pin - Hollow Dowel	2
			KAED0635	Bolt-Flange-Kae St-D Dia-06 L-35	4
			KAEG0645	Bolt-Flanged-Small	2
			KAEQ0640	Bolt Flange Small-M6x1xl40xdacro	2
2	36JF0211	Assembly crankcase LH	JF541026	Crankcase Assembly Lh	1
			LPB00002	Bearing Ball-15x35x11-C3-1RS-HN3	1
			LPB00003	Bearing Ball-22x56x16-C3-1RS-HN3	1
			JY541058	Oil Seal Output Shaft	1
			KEBA3715	Circlip Internal	1
			JY541034	Bush Starter Shaft	2
			JY541024	Jet Evacuation Oil	1
			39256220	Bearing - Needle Roller :- 13 x 19 x 12	1
			39104319	Seal - Oil	1
			JG541074	Oil Nozzle	1
			JY541038	Bush	1
			JY541052	Jet Trans	1
3	36JF0052	Assembly crankcase RH	JF541013	Crankcase RH sub assembly	1
			JY541023	Bush crankshaft	1
			39256220	Needle roller bearing	1
			JY541038	Bush	1
			JY541018	Bush insert	1
			JG601007	Special shaft seal ring (oil)	2
			LEB00001	Circlip internal	1
4	36JF0053	Assly clutch cover With nozel	DT541204	Clutch cover with plug	1
			39199020	Bearing - needle	1
			JG541021	Oil nozzle	2

Kit List



Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit
5	36JF0054	Primary drive & driven	JY551212	Gear primary drive	1
			JF551412	Clutch outer complete	1
6	36JF0197	Kit cam chain guide	JY511227	Guide chain slack side	1
			JY511229	Guide chain tight side	1
7	36JF0198	Kit valve repair	JF511257	Seat spring valve	4
			PD511246	Spring valve	4
			PD511208	Retainer spring valve	4
			CB101022	Cotter valve	8
			CB101009	Seal valve stem	4
8	36JF0209	Chain sprocket kit	JG141002	Sprocket 46 T	1
			JY551240	Sprocket Drive	1
			JF141004	Chain	1
9	36JF0208	Block Piston assly	JF521013	Block Cylinder	1
			JY521226	Piston Assembly	1
10	36JF0061	Steering cone	JY521228	Ring Piston Top	1
			JY521229	Ring Piston Second	1
			JY521230	Ring Piston Oil	1
			DG181047	Bearing Race Lower	1
11	36JF0179	Kit hose cyl master fr unit ABS	JF131883	Hose Cylinder Master Front Unit Abs	1
12	36JF0180	Kit hose unit ABS caliper front	JF131884	Hose Unit ABS - Caliper Front	1
13	36JF0181	Kit hose cyl master rr unit ABS	JF131886	Hose Cylinder Master Rear - Unit Abs	1
14	36JF0182	Kit hose unit ABS caliper rear	JF131887	Hose Unit ABS - Caliper Rear	1

141

DOMINAR
250

142

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit

DOMINAR
250

Sr No	Kit Part No.	Kit Description	Consisting of Following Parts		
			Part No.	Description	Qty/Kit

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
01 1009 05	10	22	36 JF00 54	13	16
30 1011 95	3	40	36 JF00 54	2	42
30 1410 31	10	66	36 JF00 80	12	78
30 1510 82	13	86	36 JF00 82	17	78
30 1910 38	9	84	36 JF00 85	12	84
31 1011 73	5	52	36 JF00 85	13	84
36 0010 55	8	136	36 JF00 89	42	8
36 0010 56	23	138	36 JF00 90	44	8
36 0010 58	2	136	36 JF00 91	46	8
36 0010 60	18	138	36 JF00 92	48	10
36 0010 62	9	136	36 JF00 93	50	10
36 3140 04	10	136	36 JF00 94	52	10
36 DH19 02	4	78	36 JF00 95	54	10
36 DH40 29	11	136	36 JF00 96	56	10
36 DH40 52	4	136	36 JF00 97	58	10
36 DH40 61	3	136	36 JF00 98	60	10
36 DH40 71	12	136	36 JF00 99	61	10
36 DH40 72	13	138	36 JF01 00	62	10
36 DK00 45	5	136	36 JF01 01	63	10
36 DT00 04	3	118	36 JF01 02	64	10
36 DT00 34	14	78	36 JF01 03	65	10
36 DT00 40	14	84	36 JF01 04	66	10
36 DV00 11	2	62	36 JF01 05	7	6
36 JF00 52	1	24	36 JF01 79	2	82

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 JF01 80	3	82	36 JY00 35	21	6
36 JF01 81	4	82	36 JY00 36	22	6
36 JF01 82	5	82	36 JY00 37	24	6
36 JF01 84	17	84	36 JY00 38	26	8
36 JF01 85	16	78	36 JY00 39	28	8
36 JF01 86	3	84	36 JY00 40	30	8
36 JF01 97	1	12	36 JY00 41	32	8
36 JF01 98	13	6	36 JY00 42	34	8
36 JF02 02	1	38	36 JY00 43	36	8
36 JF02 08	1	14	36 JY00 44	38	8
36 JF02 09	25	18	36 JY00 45	40	8
36 JF02 09	6	86	36 JY00 46	41	8
36 JF02 11	1	26	36 JY00 47	43	8
36 JG00 17	4	80	36 JY00 48	45	8
36 JG00 87	10	136	36 JY00 49	47	8
36 JL00 39	3	30	36 JY00 50	49	10
36 JL01 81	6	136	36 JY00 51	51	10
36 JP00 25	4	14	36 JY00 52	53	10
36 JY00 29	15	6	36 JY00 53	55	10
36 JY00 30	16	6	36 JY00 54	57	10
36 JY00 31	17	6	36 JY00 55	59	10
36 JY00 32	18	6	36 JY00 56	23	6
36 JY00 33	19	6	36 JY00 57	25	8
36 JY00 34	20	6	36 JY00 58	27	8

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
36 JY00 59	29	8	39 1998 19	3	88
36 JY00 60	31	8	39 2005 11	20	24
36 JY00 61	33	8	39 2016 19	12	38
36 JY00 62	35	8	39 2141 24	6	112
36 JY00 63	37	8	39 2181 06	2	14
36 JY00 64	39	8	39 2181 06	25	28
36 PD00 38	15	78	39 2185 20	3	24
37 0043 52	16	138	39 2203 07	15	16
37 0043 53	17	138	39 2562 20	4	24
37 2240 18	19	138	39 2562 20	22	28
37 2540 39	24	138	39 2601 20	5	24
39 0326 15	4	70	39 2606 07	5	16
39 0999 06	3	32	39 2606 07	4	20
39 0999 06	10	40	39 2606 07	7	30
39 1021 21	5	6	39 2669 21	7	12
39 1041 19	3	38	39 2699 20	13	4
39 1043 19	6	26	52 JF00 62	12	22
39 1309 11	8	82	52 JF12 25	1	40
39 1665 11	9	30	52 JF12 79	8	126
39 1686 06	20	4	52 JF12 80	9	126
39 1839 11	4	104	52 JF13 45	15	50
39 1864 20	6	24	52 JF13 45	6	126
39 1907 01	9	104	52 JF13 46	16	50
39 1990 20	2	38	52 JF13 46	7	126

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
52 JF13 49	10	128	52 JF23 29	2	130
52 JF13 51	15	50	52 JF23 31	2	130
52 JF13 51	6	126	52 JF23 32	6	130
52 JF13 52	16	50	52 JF23 34	3	130
52 JF13 52	7	126	52 JF23 35	3	130
52 JF13 53	8	126	52 JF23 36	1	130
52 JF13 54	9	126	52 JF23 40	7	130
52 JF13 55	10	128	52 JF23 41	7	130
52 JF17 68	6	126	52 JF23 42	5	130
52 JF17 69	7	126	52 JF23 43	5	130
52 JF17 70	10	128	56 DT02 33	1	60
52 JF17 70	6	130	56 DT03 33	2	60
52 JF17 74	8	126	56 DT3S Y9	2	66
52 JF17 76	9	126	56 DT3T Y9	12	66
52 JF22 07	2	130	56 DT4J Y9	7	66
52 JF22 09	2	130	56 DT4K Y9		66
52 JF22 27	7	130	56 DT5U 36	1	124
52 JF22 28	7	130	56 DT5U 36	1	124
52 JF22 30	7	130	56 DT5V 36	2	124
52 JF22 31	7	130	56 DT5V 36	2	124
52 JF22 38	5	130	56 JF12 4X	20	128
52 JF22 39	5	130	56 JF12 6E	4	130
52 JF23 26	3	130	56 JF13 4X	19	128
52 JF23 27	3	130	56 JF13 6E	4	130

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
56 JF14 4X	1	126	56 JF8C 6D	3	126
56 JF14 4X	5	130	56 JF8C 9A	3	126
56 JF15 4X	2	126	56 JF8D 6D	4	126
56 JF15 4X	5	130	56 JF8D 9A	4	126
56 JF18 1Y	7	66	56 JF8L 4X	9	130
56 JF19 1Y	13	66	56 JF8L 6D	17	128
56 JF1X 36	16	24	56 JF8L 8X	17	128
56 JF20 8X	3	126	56 JF8L 9A	17	128
56 JF21 8X	4	126	56 JF8U 33	4	74
56 JF22 6D	5	126	56 JF8U 7D	4	74
56 JF22 8X	5	126	56 JF9J 9L	1	90
56 JF22 8X	1	130	56 JF9N 33	3	74
56 JF22 9A	5	126	56 JF9N 7D	3	74
56 JF24 4X	8	130	56 JFA8 33	18	90
56 JF24 4X	22	36	59 0400 48	8	80
56 JF24 6B	22	36	59 2100 23	13A	26
56 JF25 4X	23	36	62 3050 84	22	138
56 JF25 4X	8	130	75 6802 36	20	138
56 JF25 6B	23	36	76 0109 36	14	138
56 JF28 Y9	1	64	76 0109 37	15	138
56 JF3X Y9	1	66	83 0201 73	7	136
56 JF3Y Y9	11	66	83 0204 73	5	136
56 JF5A W4	12	90	83 0205 76	1	136
56 JF5B W4	14	90	83 0205 77	1	136

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
83 0205 78	1	136	DG 1710 19	6	64
AA 1014 37	9	24	DG 1810 04	6	62
AA 1014 37	16	26	DH 1013 85	7	82
AA 1014 37	14	38	DH 1013 89	17	54
AH 4014 08	7	72	DH 1510 40	15	86
AN 1013 48	13	56	DH 1611 55	13	48
CB 1010 09	10	6	DH 1611 55	17	66
CB 1010 22	14	6	DH 1611 57	14	48
CS 1011 28	4	12	DH 1611 57	18	66
DD 1110 11	5	56	DH 1810 22	6	90
DD 1110 12	3	56	DH 1910 67	5	90
DD 1610 71	15	48	DJ 1612 90	10	62
DE 1510 46	5	84	DJ 1710 39	18	94
DE 1510 47	3	80	DJ 1810 65	33	36
DE 1510 47	4	84	DJ 1910 29	2	78
DE 1910 10	10	78	DJ 1910 30	3	78
DE 1910 10	12	82	DJ 1910 31	5	78
DE 1910 28	7	78	DJ 2011 09	9	78
DE 1910 29	6	78	DJ 2011 73	16	116
DG 1012 75	10	16	DK 1012 25	10	4
DG 1012 75	19	42	DK 1012 84	3	54
DG 1510 05	6	76	DK 1013 40	11	4
DG 1710 17	12	64	DK 1110 28	6	56
DG 1710 18	5	64	DK 1510 26	2	74

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DK 1510 69	11	78	DT 1130 14	9	66
DK 1510 69	13	82	DT 1130 15	14	66
DK 1510 74	14	84	DT 1138 27	11	60
DK 1510 81	19	86	DT 1138 48	13	64
DK 1510 82	18	86	DT 1138 49	3	102
DK 1510 85	8	84	DT 1138 51	14	118
DK 1710 06	4	64	DT 1138 55	12	56
DK 1810 11	3	94	DT 1138 56	14	46
DK 1810 17	2	94	DT 1310 18	1	74
DK 1810 18	8	94	DT 1312 10	8	86
DK 1810 20	10	94	DT 1312 13	7	86
DK 1810 21	24	96	DT 1312 14	24	86
DK 1810 50	3	62	DT 1312 22	5	74
DK 1810 51	4	62	DT 1318 67	4	76
DK 1810 75	15A	62	DT 1318 75	9	82
DK 1810 76	15	62	DT 1318 78	14	82
DP 1011 91	13	24	DT 1710 61	12	98
DP 1610 94	13	88	DT 1710 87	9	98
DP 1611 45	17	116	DT 1710 89	8	98
DS 1011 54	12	30	DT 1718 14	10	98
DS 1012 15	11	38	DT 1718 21	23	102
DS 1410 12	10	106	DT 1718 39	6	98
DS 1611 66	16	62	DT 1718 47	13	102
DS 2110 04	8	62	DT 1810 07	8	106

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
DT 1810 22	27	120	GF 1611 43	21	68
DT 1810 30	22	112	JA 5410 48	13	26
DT 1813 06	7	112	JB 4010 12	19	104
DT 1813 16	30	120	JC 1910 09	4	88
DT 1813 17	31	120	JD 1610 06	18	72
DT 1813 23	18	60	JD 1710 59	28	100
DT 2326 05	12	58	JD 1812 30	23	112
DT 3512 02	7	56	JD 1910 06	9	58
DT 3518 03	11	44	JD 3512 07	4	56
DT 4010 02	1	114	JD 4022 15	13	72
DT 4010 03	2	114	JD 4022 17	34	120
DT 4010 20	19	112	JF 1112 80	1	62
DT 4014 05	21	92	JF 1130 12	4	66
DT 4022 26	12A	118	JF 1130 36	19	66
DT 4024 04	10	76	JF 1130 37	11	88
DT 4024 04	1	86	JF 1132 05	10	72
DT 5110 27	3	2	JF 1132 08	5	72
DT 5412 02	7	40	JF 1132 09	4	72
DT 5612 05	14	22	JF 1132 10	16	72
DT 5810 28	4	46	JF 1132 11	17	72
DT 5810 62	9	46	JF 1132 12	1	72
DT 5810 74	13	46	JF 1134 22	14	62
DV 1610 50	27	68	JF 1134 23	14	64
EC 5610 23	12	20	JF 1134 24	12	60

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 1138 17	15	58	JF 1318 88	2	84
JF 1138 18	9	106	JF 1318 89	1	78
JF 1138 21	11	62	JF 1319 12	1	82
JF 1138 21	1	102	JF 1510 47	12	48
JF 1138 42	16	118	JF 1510 47	15	90
JF 1138 48	37	36	JF 1510 51	10	90
JF 1138 49	38	36	JF 1510 54	16	90
JF 1138 52	6	82	JF 1510 55	17	90
JF 1138 53	8	102	JF 1610 04	5	88
JF 1138 55	14	72	JF 1610 06	1	88
JF 1138 57	35	120	JF 1610 07	8	88
JF 1138 61	28	120	JF 1610 13	2	90
JF 1138 71	17	62	JF 1610 14	25	92
JF 1210 49	11	76	JF 1612 04	2	110
JF 1210 63	12	94	JF 1612 05	1	110
JF 1210 68	1	94	JF 1612 07	10	82
JF 1210 69	16	94	JF 1612 07	3	110
JF 1210 75	23	96	JF 1612 08	4	110
JF 1221 04	8	64	JF 1710 22	8	104
JF 1221 05	15	64	JF 1710 23	18	98
JF 1221 15	7	64	JF 1710 24	19	98
JF 1221 20	2	64	JF 1710 25	20	98
JF 1318 58	1	84	JF 1710 26	21	100
JF 1318 61	14	86	JF 1710 28	10	104

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 1710 29	13	104	JF 1716 24	7	102
JF 1710 35	1	104	JF 1716 25	11	102
JF 1710 36	2	104	JF 1716 26	2	98
JF 1710 43	6	104	JF 1718 02	4	98
JF 1710 54	21	104	JF 1718 11	4	98
JF 1710 55	15	98	JF 1812 57	19	34
JF 1710 56	24	100	JF 1812 62	27	36
JF 1710 58	18	104	JF 1812 65	5	108
JF 1710 64	29	120	JF 1812 66	13	112
JF 1710 65	14	104	JF 1812 67	10	112
JF 1710 66	12	104	JF 1812 68	9	112
JF 1710 67	11	98	JF 1812 69	6	108
JF 1710 68	16	98	JF 1812 70	9	108
JF 1710 69	17	98	JF 1812 72	22	120
JF 1710 72	1	98	JF 1812 75	17	112
JF 1710 83	29	100	JF 1812 76	18	112
JF 1710 93	25	128	JF 1812 77	21	112
JF 1710 94	17	104	JF 1812 82	6	54
JF 1711 05	26	128	JF 1813 08	23	120
JF 1716 03	22	102	JF 1813 16	6	110
JF 1716 04	14	102	JF 1813 29	13	50
JF 1716 07	16	102	JF 1813 46	15	60
JF 1716 13	5	102	JF 1813 46	25	100
JF 1716 23	6	102	JF 1813 48	14	60

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 1813 51	1	50	JF 2312 26	4	124
JF 1813 51	18	128	JF 2312 39	11	124
JF 1813 54	4	50	JF 2312 40	12	124
JF 1813 55	2	50	JF 2314 13	17	58
JF 1813 61	24	112	JF 2314 14	18	58
JF 1813 62	25	112	JF 2314 15	21	124
JF 1813 77	5	110	JF 2316 08	9	124
JF 1814 20	2	116	JF 2316 09	10	124
JF 1814 21	4	116	JF 2326 16	23	92
JF 1814 22	7	116	JF 2326 16	22	100
JF 1814 24	10	116	JF 2328 06	4	112
JF 1814 73	5	70	JF 2328 07	12	116
JF 1814 80	3	70	JF 2330 36	9	40
JF 1814 81	9	94	JF 2331 98	11	128
JF 1814 82	11	94	JF 2332 18	2	40
JF 1817 83	4	50	JF 2332 22	21	128
JF 1817 84	10	130	JF 2332 23	22	128
JF 1910 09	1	58	JF 2332 30	23	128
JF 1910 12	8	58	JF 2332 30	18	141
JF 1910 16	3	58	JF 2332 31	24	128
JF 1910 17	6	58	JF 2332 31	18	142
JF 1910 18	4	58	JF 2332 34	15	128
JF 2310 10	1	122	JF 2332 35	16	128
JF 2312 11	8	124	JF 2332 37	21	128

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 2332 38	22	128	JF 2334 75	13	132
JF 2332 44	12	128	JF 2334 76	15	132
JF 2332 45	9	38	JF 2334 77	15	132
JF 2332 45	13	128	JF 2334 78	17	135
JF 2332 56	21	128	JF 2334 79	17	137
JF 2332 57	22	128	JF 2334 80	16	132
JF 2334 18	13	132	JF 2334 81	16	132
JF 2334 19	13	132	JF 2334 82	14	132
JF 2334 32	14	132	JF 2334 83	14	132
JF 2334 33	14	132	JF 2334 84	12	132
JF 2334 61	13	132	JF 2334 85	12	132
JF 2334 62	13	132	JF 2334 86	15	132
JF 2334 63	15	132	JF 2334 87	15	132
JF 2334 64	15	132	JF 2334 88	17	134
JF 2334 65	17	138	JF 2334 89	17	136
JF 2334 66	17	139	JF 2334 90	16	132
JF 2334 67	16	132	JF 2334 91	16	132
JF 2334 68	16	132	JF 2334 92	12	132
JF 2334 69	14	132	JF 2334 93	12	132
JF 2334 70	14	132	JF 2334 94	11	132
JF 2334 71	12	132	JF 3510 22	2	54
JF 2334 72	12	132	JF 3512 06	10	56
JF 2334 73	11	132	JF 3512 16	1	56
JF 2334 74	13	132	JF 3516 00	1	52

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 3518 05	14	26	JF 5412 04	16	38
JF 4010 22	1	116	JF 5412 08	6	38
JF 4010 30	20	116	JF 5412 10	5	38
JF 4010 31	21	116	JF 5412 12	14	128
JF 4014 13	4	90	JF 5514 22	1	42
JF 4014 14	8	90	JF 5610 00	5	20
JF 4014 15	11	72	JF 5610 01	8	20
JF 4016 01	8	118	JF 5614 10	11	22
JF 4020 04	4	54	JF 5614 22	13	22
JF 4022 11	6	118	JF 5810 22	3	46
JF 4022 34	10	54	JF 5810 31	6	46
JF 4022 64	1	118	JF 5810 35	1	46
JF 4024 07	5	104	JF 5814 08	14	4
JF 4024 18	1	108	JF 5910 53	25	48
JF 5010 25	2	24	JF 5910 99	2	48
JF 5110 58	5	4	JF 5911 82	6	48
JF 5112 49	5	12	JF 5912 11	23	48
JF 5112 58	9	6	JF 5912 22	3	48
JF 5112 60	6	6	JF 5913 34	21	48
JF 5310 21	1	16	JF 5913 39	1	48
JF 5312 13	15	30	JF 6012 03	7	34
JF 5312 14	1	30	JF 6012 10	9	34
JF 5410 16	30	28	JF 6012 11	13	34
JF 5410 17	23	28	JF 6012 13	12	34

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JF 6012 15	1	34	JG 1710 31	20	104
JF 6112 06	1	44	JG 1710 31	4	106
JF 6112 07	3	44	JG 1710 86	12	102
JF 6112 07	7	98	JG 1812 58	13	108
JG 1138 32	14	94	JG 1812 59	32	36
JG 1220 37	16	64	JG 1812 59	15	104
JG 1310 01	8	76	JG 1812 65	15	46
JG 1310 03	9	76	JG 1910 08	2	58
JG 1310 07	1	76	JG 1910 11	20	58
JG 1310 20	2	76	JG 2326 02	13	58
JG 1312 20	17	86	JG 2326 03	16	58
JG 1312 28	22	86	JG 2326 06	21	58
JG 1318 02	3	76	JG 3510 19	18	54
JG 1318 04	1	80	JG 3514 00	12	4
JG 1318 11	2	80	JG 3518 05	6	44
JG 1318 13	9	80	JG 4010 06	8	116
JG 1510 22	9	90	JG 4010 36	13	116
JG 1510 24	5	62	JG 4018 00	21	120
JG 1610 08	3	90	JG 4020 02	4	118
JG 1610 10	8	78	JG 4022 28	13	118
JG 1710 29	26	36	JG 4022 29	12B	118
JG 1710 29	21	102	JG 4022 30	12C	118
JG 1710 30	13	98	JG 5110 16	4	6
JG 1710 31	14	50	JG 5110 21	2	2

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JG 5110 22	1	2	JG 5814 23	7	44
JG 5110 46	18	4	JG 5814 24	4	44
JG 5112 70	8	12	JG 5814 37	9	44
JG 5310 40	4	16	JG 5910 70	8	48
JG 5312 15	4	30	JG 5911 00	22	48
JG 5312 29	17	30	JG 6010 05	5	30
JG 5412 30	8	38	JG 6010 07	10	24
JG 5610 08	6	20	JG 6010 12	6	30
JG 5610 09	21	24	JG 6010 14	18	34
JG 5610 10	3	20	JG 6010 16	10	34
JG 5612 04	12	24	JG 6012 09	6	34
JG 5612 05	22	24	JG 6012 10	8	34
JG 5612 15	9	20	JG 6012 11	21	34
JG 5612 15	2	22	JG 6012 13	25	36
JG 5612 16	5	22	JG 6012 30	21A	34
JG 5612 17	3	22	JG 6012 34	17	34
JG 5612 18	4	22	JG 6012 35	4	34
JG 5612 22	1	20	JG 6110 06	10	44
JG 5612 26	19	24	JG 6110 07	2	44
JG 5710 14	14	24	JG 6112 06	5	44
JG 5710 16	15	24	JH 1812 55	6	106
JG 5810 56	8	46	JK 1910 05	5	58
JG 5814 07	16	4	JK 4018 01	32	120
JG 5814 19	8	44	JL 1130 14	7	66

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JL 1130 16	13	66	JL 5614 10	8	22
JL 1130 35	25	68	JL 6010 08	8	30
JL 1130 36	8	66	JL 6010 10	11	24
JL 1138 09	7	62	JL 6012 13	24	36
JL 1138 25	26	120	JL 6012 15	28	36
JL 1312 03	2	86	JL 6012 16	15	34
JL 1312 11	5	86	JL 6012 35	20	34
JL 1312 16	11	86	JM 1910 14	7	88
JL 1710 38	27	100	JN 1810 33	15	26
JL 1711 01	19	102	JP 1318 61	5	76
JL 1711 02	20	102	JP 3514 39	7	54
JL 1810 27	9	62	JP 4022 03	5	118
JL 1812 60	4	60	JP 4022 18	19	4
JL 1910 17	10	58	JP 4030 00	11	118
JL 2310 03	2	122	JP 5112 28	12	6
JL 2312 09	7	124	JP 5810 18	11	46
JL 2326 04	14	58	JP 5910 12	7	48
JL 3512 18	11	56	JP 5910 42	9	48
JL 4014 06	6	88	JP 5910 65	24	48
JL 4030 00	2	118	JP 6012 35	14	34
JL 4032 00	7	118	JU 1312 22	9	86
JL 5312 03	16	30	JU 1318 02	16	86
JL 5412 27	10	38	JU 1318 15	6	80
JL 5412 45	4	40	JU 1318 16	5	80

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JU 1716 06	9	102	JY 4014 04	24	92
JU 2328 00	1	112	JY 4022 35	23	100
JU 5112 04	2	6	JY 4036 04	15	118
JU 5810 06	17	4	JY 5110 58	4	4
JU 5810 06	2	46	JY 5110 68	6	4
JY 1138 42	15	102	JY 5110 74	8	4
JY 1138 64	8	54	JY 5111 28	4	2
JY 1138 72	23	54	JY 5111 49	5	2
JY 1138 73	24	54	JY 5112 12	1	6
JY 1138 74	21	54	JY 5112 20	2	12
JY 1138 77	20	54	JY 5112 26	3	6
JY 1210 11	19	90	JY 5112 48	11	6
JY 1210 11	17	94	JY 5210 06	3	14
JY 1710 07	22	54	JY 5212 36	5	14
JY 1710 69	18	102	JY 5310 05	17	16
JY 1710 77	4	102	JY 5310 08	9	16
JY 1718 25	17	102	JY 5310 26	8	16
JY 1812 55	11	50	JY 5310 45	16	16
JY 1812 84	30	36	JY 5310 60	12	16
JY 3510 25	1	54	JY 5310 61	14	16
JY 3512 00	9	56	JY 5410 09	3	12
JY 3512 03	8	56	JY 5410 31	9	26
JY 4010 24	6	114	JY 5410 34	11	40
JY 4010 25	7	114	JY 5410 40	7	52

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JY 5410 47	8	24	JY 5512 15	9	18
JY 5410 58	7	26	JY 5512 17	22	18
JY 5410 80	18	26	JY 5512 18	18	18
JY 5410 81	17	26	JY 5512 25	3	52
JY 5410 82	19	26	JY 5512 26	4	52
JY 5412 08	14	54	JY 5512 28	8	18
JY 5412 14	5	40	JY 5512 29	5	18
JY 5412 20	13	38	JY 5512 30	2	18
JY 5412 22	13	54	JY 5512 31	7	18
JY 5412 25	15	38	JY 5512 32	21	18
JY 5510 05	15	18	JY 5512 33	11	18
JY 5510 06	10	18	JY 5512 34	16	18
JY 5510 08	12	18	JY 5512 35	14	18
JY 5510 10	3	18	JY 5512 36	19	18
JY 5510 18	23	18	JY 5512 37	13	18
JY 5510 19	18	42	JY 5514 01	10	42
JY 5510 21	6	18	JY 5514 02	19	54
JY 5510 22	1	18	JY 5514 03	3	42
JY 5510 27	17	18	JY 5514 04	14	42
JY 5510 30	26	18	JY 5514 35	4	42
JY 5510 33	24	18	JY 5514 36	8	42
JY 5512 05	20	18	JY 5514 37	9	42
JY 5512 12	6	16	JY 5514 38	13	42
JY 5512 14	4	18	JY 5514 40	15	42

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
JY 5514 41	6	42	JZ 1318 75	9	88
JY 5514 42	5	42	JZ 1710 55	13	62
JY 5514 43	16	42	JZ 1812 71	5	106
JY 5610 02	11	20	JZ 1813 65	2	108
JY 5610 04	7	20	JZ 2328 05	15	116
JY 5610 08	10	20	JZ 2328 14	8	112
JY 5612 05	1	22	KA CA06 10	36	120
JY 5710 08	3	26	KA CA08 18	6	124
JY 5710 09	5	26	KA CC06 18	5	124
JY 5710 12	6	32	KA CD05 16	3	98
JY 5710 15	1	32	KA CF06 12	16	46
JY 5710 23	7	32	KA CF06 12	17	118
JY 5710 24	5	32	KA CF06 16	9	50
JY 5710 29	28	28	KA CH06 10	5	48
JY 5710 30	11	26	KA CH06 14	4	48
JY 5810 16	7	46	KA CJ06 55	7	90
JY 5810 28	10	46	KA DA05 10	3	104
JY 5810 28	12	46	KA DA06 12	19	48
JY 5913 03	18	48	KA DD06 10	30	100
JY 6012 15	11	34	KA DD06 10	18	116
JY 6012 41	5	34	KA DD06 12	15	72
JY 6012 48	2	34	KA DD06 12	6	116
JY 6012 49	3	34	KA DD06 14	16	84
JY 6214 11	6	52	KA DD06 20	2	56

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KA DD06 20	23	68	KA EW06 35	17	38
KA DD06 22	7	22	KA EW06 35	6	40
KA DD08 40	20	48	KA EW06 35	5	50
KA DF06 08	15	82	KA EW06 50	8	40
KA DF06 25	11	58	KA EW06 55	6	50
KA DF08 25	14	98	KB BA05 10	19	72
KA DQ06 25	2	52	KB RD42 13	23	104
KA DS05 16	12	72	KB UA05 14	3	116
KA DT08 14	13	60	KB UA06 14	14	112
KA DW10 50	11	48	KB UA06 30	5	46
KA EA06 10	12	62	KB UF05 08	8	108
KA EA06 10	2	102	KB UH05 14	22	104
KA ED06 16	17	64	KC AA05 04	4	108
KA ED06 22	24	120	KC AD06 05	24	68
KA ED06 25	25	120	KC AD10 08	5	114
KA ED06 30	5	54	KC AM06 05	16	22
KA ED06 35	1	4	KC BA06 04	6	72
KA ED08 20	3	60	KC BC08 05	10	64
KA EG06 45	3	4	KC EA06 05	10	102
KA EQ06 40	2	4	KC GA05 05	14	116
KA EW06 16	17	24	KC GA10 10	8	114
KA EW06 20	6	12	KC GC08 08	9	64
KA EW06 22	11	30	KC GD06 06	9	54
KA EW06 35	26	28	KC HA05 07	22	116

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
KC HA06 08	20	118	KP BC63 02	12	86
KD AA08 16	5	66	KP BF63 04	7	24
KD AA08 16	19	124	KP BF63 04	2	30
KD AA10 18	7	60	LA A000 51	8	60
KD AA10 18	3	114	LA A000 51	17	124
KD AB08 16	13	124	LA C000 08	3	50
KD AE05 10	2	70	LA C000 08	18	118
KD BA05 12	7	108	LA C000 10	13	94
KD BA06 13	10	84	LA C000 24	2	20
KD BA06 13	20	112	LA C000 32	9	4
KD DB10 18	6	60	LA C000 54	7	110
KD FB10 18	4	114	LA C000 71	6	70
KE AB10 10	9	32	LA C000 78	15	66
KE BA35 15	13	76	LA C000 79	16	66
KE BA37 15	8	26	LA C000 86	14	30
KE BA42 17	4	86	LA C000 99	16	48
KH AA20 15	11	84	LA C001 04	9	22
KH AA20 15	10	88	LA C001 05	3	64
KH AA25 20	6	66	LA C001 11	11	90
KJ AA14 24	7	38	LA C001 19	3	124
KM AA08 00	22	68	LA C001 33	16	104
KP AC62 05	21	86	LA C001 41	20	124
KP BC62 02	7	76	LA C001 44	8	6
KP BC62 02	10	86	LA C001 48	13	90

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LA C001 65	14	124	LA E000 16	15	54
LA D000 06	9	60	LA E000 17	27	18
LA D000 37	13	78	LA E000 18	4	32
LA D000 77	15	84	LA E000 42	8	52
LA D000 79	7	80	LA E000 48	10	30
LA D000 85	20	66	LA E000 49	36	36
LA D000 85	12	88	LA E000 54	16	60
LA D001 02	10	108	LA E000 54	26	100
LA D001 08	11	64	LA E000 55	31	36
LA D001 13	7	58	LA E000 55	12	76
LA D001 24	12	54	LA E000 57	11	82
LA D001 54	5	98	LA E000 57	8	110
LA D001 66	17	42	LA J000 20	5	60
LA D001 84	8	72	LB B000 07	10	26
LA D001 91	17	60	LB B000 12	24	28
LA D001 95	19	116	LB B000 15	1	70
LA D002 00	9	72	LB B000 16	27	92
LA D002 02	7	106	LB C000 03	15	4
LA D002 13	26	92	LB R000 03	9	116
LA D002 31	2	72	LB R000 10	7	104
LA D002 44	22	92	LB U000 53	29	36
LA E000 01	18	24	LB U000 55	8	50
LA E000 02	27	28	LB U000 55	16	112
LA E000 10	31	28	LB U000 55	22	124

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LB U000 65	11	104	LD B000 07	3	108
LB U000 65	3	106	LD B000 14	11	106
LB U000 65	2	112	LD B000 15	19	58
LB U000 65	12	112	LD B000 19	7	50
LB U000 66	5	112	LD B000 19	10	50
LB U000 67	15	108	LD B000 20	4	38
LB U000 68	12	50	LD B000 23	5	116
LB U000 69	1	106	LD B000 33	3	16
LC B000 03	15	22	LD B000 41	11	54
LC G000 02	11	16	LD B000 51	13	30
LC G000 09	11	42	LD B000 56	2	88
LC G000 24	10	48	LD B000 57	3	86
LC G000 29	35	36	LD B000 68	17	48
LC G000 30	11	116	LD B000 72	2	106
LC H000 01	3	72	LD B000 72	15	112
LC H000 01	20	90	LD B000 72	19	118
LC H000 05	28	92	LD B000 73	9	118
LC J000 05	20	86	LD B000 74	3	112
LC L000 01	10	60	LD B000 74	11	112
LC L000 04	23	86	LD B000 75	34	36
LC L000 07	10	118	LD B000 84	15	124
LC L000 07	16	124	LD F000 01	16	54
LD A000 13	26	68	LD F000 01	6A	118
LD A000 17	8	32	LD H000 02	2	16

Part Index



Part Number	Figure No.	Page No.	Part Number	Figure No.	Page No.
LD H000 16	18	124	YJ F260 08	7	94
LF B000 01	7	16	YJ F260 09	6	94
LH D000 01	2	32	YJ F260 11	7	42
LH E000 03	3	66	YJ L040 05	6	84
LJ A000 01	7	4	YJ L040 06	7	84
LJ A000 02	2	26			
LJ A000 02	29	28			
LJ A000 04	12	26			
LJ A000 05	16	34			
LJA00006	4	26			
LP A000 04	12	42			
LP B000 02	21	26			
LP B000 03	20	26			
PA 4022 04	33	120			
PF 1812 11	14	108			
YJ F040 01	11	108			
YJ F040 02	12	108			
YJ F260 01	4	94			
YJ F260 02	5	94			
YJ F260 03	21	96			
YJ F260 04	20	94			
YJ F260 05	15	94			
YJ F260 06	19	94			
YJ F260 07	22	96			