

BAJAJ
pulsar 200
OIL/COOLED



www.auteco.com.co/repuestosauteco

CATÁLOGO DE PARTES



AVISO IMPORTANTE

- *Recuerde hacer los cambios de aceite de motor (1150 cc de Shell Advance 20W50 API SJ + JASO MA) según la TABLA DE MANTENIMIENTO PERIÓDICO (Máximo cada 2.000 Kms. de recorrido) .**
- *No lave la moto con agua a presión, ni con vapor, ni con el motor caliente. Estos procedimientos pueden ocasionar daños en sus componentes eléctricos.**
- *La motocicleta Pulsar 200 OIL/COOLED incorpora sistemas electrónicos muy especializados. Absténgase de hacer modificaciones o instalaciones adicionales a las originales, ya que podría causar daños en dichos sistemas.**

PREFACIO

Es nuestro placer presentarles a ustedes el Catálogo de Partes.

Este Catálogo ha sido especialmente diseñado para ayudarle en la selección de las partes correctas con el fin de mantener el vehículo en las mejores condiciones.

Los repuestos originales están sujetos a un exigente estándar de control de calidad, por lo tanto es necesario que usted sólo use repuestos originales.

En nuestro constante esfuerzo para mejorar la eficiencia y desempeño de su vehículo, las especificaciones, diagramas y número de partes pueden cambiar sin previo aviso. Consecuentemente las descripciones de los repuestos en este Catálogo pueden no ser las finales y definitivas.

Las alteraciones y modificaciones que ocurren en la impresión de este Catálogo, serán informadas a nuestra red, a través de circulares de Servicio o en nuestra página web: www.auteco.com.co accediendo al link repuestos/accesorios. Es requisito que usted actualice su Catálogo y haga las correcciones necesarias, una vez reciba dichas circulares. Lo anterior le asegurará un rápido y adecuado despacho de sus partes, pues las órdenes están siendo diligenciadas con las referencias más actualizadas.

En caso de necesitar asistencia técnica, comunicarse con el Distribuidor Autorizado o llamar al Departamento de Servicios Auteco-Kawasaki.

Todos los derechos reservados, No se permite la reproducción total o parcial de este libro, en ninguna forma o por ningún medio, ya sea electrónico o mecánico, incluido fotocopiado, sin permiso escrito de Autotecnica Colombiana S.A. "AUTECO S.A."



DIRECTORIO TELEFÓNICO - DIVISIÓN REPUESTOS

NOMBRE	CARGO	CELULAR	TELÉFONOS DIRECTOS	CORREO ELECTRÓNICO
ALVARO VÉLEZ V.	JEFE LINEAS ESPECIALES	03310-3739023	306 84 58	
JOSÉ IGNACIO ROJAS L.	JEFE LINEAS ORIGINALES	03313-7677836	306 84 59	
CARLOS TORO	PROMOTOR VENTAS ORIGINALES	03314-8110409	306 84 74	ctoro@auteco.com.co
JORGE GIL	PROMOTOR VENTAS ORIGINALES	03313-6727353	306 84 71	jgil@auteco.com.co
JORGE MARIO MAYA V.	PROMOTOR VENTAS ORIGINALES	03312-2589384	306 84 75	jmaya@auteco.com.co
ALEJANDRO POSADA	PROMOTOR VENTAS ORIGINALES	03313-7677843	306 84 67	aposada@auteco.com.co
ALEXÁNDER GRAJALES	PROMOTOR VENTAS	03310-3739019	306 84 73	agrajales@auteco.com.co
CARLOS H. TOBÓN R.	PROMOTOR VENTAS	03310-4473611	306 84 63	ctobon@auteco.com.co
CARLOS MARIO SALAZAR	PROMOTOR VENTAS	03310-4148845	306 84 65	csalazar@auteco.com.co
ELKIN GALLEGO R.	PROMOTOR VENTAS	03310-4362598	306 84 64	egallego@auteco.com.co
GONZALO A. SILDARRIAGA S.	PROMOTOR VENTAS	03310-4068874	306 84 60	gsaldarriaga@auteco.com.co
HÉCTOR A. VALENCIA R.	PROMOTOR VENTAS	03310-4473652	306 84 61	hvalencia@auteco.com.co
HÉCTOR JAIRO LÓPEZ C.	PROMOTOR VENTAS	03312-2576791	306 84 70	hlopez@auteco.com.co
JOHN JAIRO LÓPEZ CH.	PROMOTOR VENTAS	03310-4442215	306 84 62	jlopez@auteco.com.co
MAURICIO MEJÍA	PROMOTOR VENTAS	03312-2576175	306 84 72	mmejia@auteco.com.co
NESTOR R. ADARVE	PROMOTOR VENTAS	03310-4362689	306 84 68	nadarve@auteco.com.co
UBERNEY ORTIZ V.	PROMOTOR VENTAS	03313-6727337	306 84 66	uortiz@auteco.com.co
WILLIAM GUTIÉRREZ H.	PROMOTOR VENTAS	03310-4074072	306 84 69	wgutierrez@auteco.com.co
ADRIANA VALENCIA	PROMOTOR LINEA AGROINDUSTRIAL	03314-8126167	306 81 92	avalencia@auteco.com.co
BERNARDO MURIEL G.	PROMOTOR LINEA AGROINDUSTRIAL	03310-4362742	306 84 67	bmuriel@auteco.com.co
JOAQUÍN VALDERRAMA	PROMOTOR LINEA AGROINDUSTRIAL	03315-6184912	03315-6184912	jvalderrama@auteco.com.co

DIAGONAL 38 A N° 34-56 B. SAN JOSÉ ITAGÜÍ • FAX BODEGA: 373 83 94 • FAX OFICINAS: 373 03 75

RICARDO CUARTAS	SERVICIO AL CLIENTE	306 84 78
DORIS CARMONA		306 84 77
LEONARDO GARCÍA	FACTURACIÓN	306 84 76

ENVÍE SUS SOLICITUDES DE RECLAMOS AL NUEVO FAX DE DEVOLUCIONES RECLAMOS 306 84 86

ALEX URREA	DEVOLUCIONES RECLAMOS	TEL.: 306 84 79
		FAX: 306 84 86
JUAN GUILLERMO GARCÍA	MOTOS VARADAS	306 84 80

LINEA GRATUITA SERVICIO AL CLIENTE - ACLARA

01 8000 52 00 90

ÍNDICE

FIGURA No.	DESCRIPCIÓN	PÁG. No.	FIGURA No.	DESCRIPCIÓN	PÁG. No.
1	CULATA	1	27	REPOSAPIE CONDUCTOR	27
2	MÚLTIPLE ADMISIÓN	2	28	REPOSAPIE PASAJERO	28
3	VÁLVULAS	3	29	GUARDABARRO TRASERO	29
4	EJE LEVAS / TENSOR CADENILLA	4	30	GATO CENTRAL- GATO LATERAL	30
5	CILINDRO / PISTÓN	5	31	LLANTAS / RINES	31
6	CIGÜEÑAL	6	32	CAMPANA DELANTERA	32
7	EJE BALANCEADOR	7	33	BOMBA FRENO DELANTERO	33
8	TRANSMISIÓN	8	34	FRENO DISCO DELANTERO	34
9	SELECTOR DE CAMBIOS	9	35	CAMPANA TRASERA	35-36
10	EJE DE CAMBIOS	10	36	PEDAL FRENO	37
11	CARCASA DERECHA	11	37	MANUBRIO	38
12	CARCASA IZQUIERDA	12	38	SUSPENSIÓN DELANTERA	39-40
13	CUBIERTA CLUTCH	13	39	TANQUE GASOLINA / TAPAS LATERALES	41
14	CUBIERTA VOLANTE / CUBIERTA CADENA	14	40	GRIFO DE GASOLINA	42
15	CLUTCH	15	41	ANTIVIBRANTES TANQUE GASOLINA Y TAPAS LATERALES	43
16	RADIADOR	16	42	VELOCÍMETRO	44
17	CARBURADOR	17	43	CABLES / GUARDA CADENA	45
18	FILTRO DE AIRE	18	44	FAROLA	46
19	SILENCIADOR	19	45	DIRECCIONALES	47
20	SILLÍN	20	46	STOP / PORTA PLACA	48
21	BOMBA DE ACEITE	21	47	EQUIPO ETÉCTRICO	49
22	MAGNETO / C.D.I. / BOBINA DE ALTA	22	48	ACCESORIOS / HERRAMIENTAS	50
23	MOTOR DE ARRANQUE	23		LISTA DE KITS	51 - 52
24	PARTES DEL CHASIS	24		INDICE DE REFERENCIAS	53 - 57
25	CHASIS	25			
26	AMORTIGUADOR TRAS. / BRAZO OSCILANTE	26			

Esta publicación contiene las referencias para los vehículos ensamblados a partir del **MOTOR No. JCGBRC17185 (CHASÍS No. MD2JCB1Z09VC00894).**

ÍNDICE DE GRÁFICOS




FIGURA N° 1 : CULATA

PÁG. No.
1




FIGURA N° 2 : MÚLTIPLE ADMISIÓN

PÁG. No.
2




FIGURA N° 3 : VÁLVULAS

PÁG. No.
3




FIGURA N° 4 : EJE LEVAS / TENSOR CADENILLA

PÁG. No.
4




FIGURA N° 5 : CILINDRO / PISTÓN

PÁG. No.
5










FIGURA N° 6 : CIGÜEÑAL

PÁG. No.
6

ÍNDICE DE GRÁFICOS

					
FIGURA N° 7 : EJE BALANCEADOR		PÁG. No. 7		FIGURA N° 8 : TRANSMISIÓN	
		PÁG. No. 8		PÁG. No. 9	
					
FIGURA N° 10 : EJE DE CAMBIOS		PÁG. No. 10		FIGURA N° 11 : CARCASA DERECHA	
		PÁG. No. 11		FIGURA N° 12 : CARCASA IZQUIERDA	
				PÁG. No. 12	

ÍNDICE DE GRÁFICOS




FIGURA N° 13 : CUBIERTA CLUTCH

PÁG. No.
13



FIGURA N° 14 : CUBIERTA VOLANTE /
CUBIERTA CADENA

PÁG. No.
14




FIGURA N° 15 : CLUTCH

PÁG. No.
15




FIGURA N° 16 : RADIADOR

PÁG. No.
16




FIGURA N° 17 : CARBURADOR

PÁG. No.
17










FIGURA N° 18 : FILTRO DE AIRE

PÁG. No.
18

ÍNDICE DE GRÁFICOS

	FIGURA N° 19 : SILENCIADOR PÁG. No. 19		FIGURA N° 20 : SILLÍN PÁG. No. 20		FIGURA N° 21 : BOMBA DE ACEITE PÁG. No. 21
	FIGURA N° 22 : MAGNETO / C.D.I. / BOBINA DE ALTA PÁG. No. 22		FIGURA N° 23 : MOTOR DE ARRANQUE PÁG. No. 23		FIGURA N° 24 : PARTES DEL CHASIS PÁG. No. 24

ÍNDICE DE GRÁFICOS




FIGURA N° 25 : CHASIS

PÁG. No.
25




FIGURA N° 26 : AMORTIGUADOR TRASERO /
BRAZO OSCILANTE

PÁG. No.
26




FIGURA N° 27 : REPOSAPIE CONDUCTOR

PÁG. No.
27




FIGURA N° 28 : REPOSAPIE PASAJERO

PÁG. No.
28




FIGURA N° 29 : GUARDABARRO TRASERO

PÁG. No.
29









FIGURA N° 30 : GATO CENTRAL- GATO
LATERAL

PÁG. No.
30

ÍNDICE DE GRÁFICOS

					
FIGURA N° 31 : LLANTAS / RINES		PÁG. No. 31		FIGURA N° 32 : CAMPANA DELANTERA	
		PÁG. No. 32		FIGURA N° 33 : BOMBA FRENO DELANTERO	
		PÁG. No. 33			
					
FIGURA N° 34 : FRENO DISCO DELANTERO		PÁG. No. 34		FIGURA N° 35 : CAMPANA TRASERA	
		PÁG. No. 35 - 36		FIGURA N° 36 : PEDAL FRENO	
		PÁG. No. 37			

ÍNDICE DE GRÁFICOS




FIGURA N° 37: MANUBRIO

PÁG. No.
38




FIGURA N° 38: SUSPENSIÓN DELANTERA

PÁG. No.
39-40



FIGURA N° 39: TANQUE GASOLINA /
TAPAS LATERALES

PÁG. No.
41




FIGURA N° 40: GRIFO DE GASOLINA

PÁG. No.
42




FIGURA N° 41: ANTIVIBRANTES TANQUE
GASOLINA Y TAPAS LATERALES

PÁG. No.
43








FIGURA N° 42: VELOCÍMETRO

PÁG. No.
44

ÍNDICE DE GRÁFICOS

	FIGURA N° 43: CABLES / GUARDACADENA PÁG. No. 45		FIGURA N° 44 : FAROLA PÁG. No. 46		FIGURA N° 45 : DIRECCIONALES PÁG. No. 47
	FIGURA N° 46 : STOP / PORTA PLACA PÁG. No. 48		FIGURA N° 47 : EQUIPO ELÉCTRICO PÁG. No. 49		FIGURA N° 48 : ACCESORIOS / HERRAMIENTAS PÁG. No. 50

This diagram illustrates the exploded view of a carburetor assembly. The main body of the carburetor is labeled 1. Various components are shown in their relative positions, with lines indicating their assembly points. The numbered parts are:

- 1: Main carburetor body
- 2: Two O-rings for the float bowl
- 3: Two O-rings for the jet needle
- 4: Jet needle
- 5: Jet needle seat
- 6: Jet needle pin
- 7: Jet needle pin O-ring
- 8: Jet needle pin screw
- 9: Jet needle pin nut
- 10: Two screws for the float bowl
- 11: Two washers for the float bowl

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

6

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor housing. The parts are numbered 1 through 11. The assembly is shown in two main sections, each enclosed in a dashed rectangular box. The top section (1) contains a large cylindrical component (1), a bearing (2), a washer (3), and a gear (4). The bottom section (5) contains a gear (5), a washer (6), a bearing (7), a gear (8), a shaft (9), a gear (10), a washer (11), and a bolt (12). The diagram shows the relative positions and assembly sequence of these parts, with dashed lines indicating the alignment of the components.

BAJAJ
pulsar₂₀₀ OIL/COOLED

FIGURA N° 8 : TRANSMISIÓN




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	DK-1011-25	Eje Clutch	1	
2	39-2158-11	Arandela Eje Caja	2	
3	DK-1011-03	Piñón de 4a	1	
4	DH-1010-79	Arandela Caja	3	
5	DH-1012-35	Pin Piñones Caja	4	
6	DK-1011-02	Piñón de 3a	1	
7	DK-1011-04	Piñón de 5a	1	
8	DH-1010-84	Piñón de 2a	1	
9	39-2160-11	Arandela Caja	1	
10	DK-1011-44	Eje Piñón Salida	1	
11	DH-1013-36	Arandela Caja	2	
12	DK-1011-05	Piñón de 3a	1	
13	DH-1010-79	Arandela Caja	2	
14	DK-1011-06	Piñón de 4a	1	
15	DH-1011-11	Buje Piñón Caja	1	
16	DK-1011-18	Piñón de 1a	1	
17	DK-1011-07	Piñón de 5a	1	
18	DH-1013-19	Buje Piñón Caja	1	
19	DH-1013-33	Piñón de 2a	1	
20	DK-1012-45	Buje Eje Piñón Salida	1	
21	30-1010-61	Anillo Retenedor	1	
22	DV-1010-48	Piñón de Salida	1	
23	DJ-1010-63	Arandela Seguridad Piñón Salida	1	
24	39-1062-04	Tornillo	2	

This diagram shows the exploded view of a mechanical assembly. The components are numbered as follows:

- 1**: A small bracket or support arm.
- 2**: A large, complex bracket or support arm.
- 3**: A long, hollow cylindrical tube.
- 4**: A long, hollow cylindrical tube with a flange at one end.
- 5**: A central cylindrical component with a complex, multi-faceted top surface.
- 6**: A small, threaded bolt or screw.
- 7**: A small, flat washer or spacer.
- 8**: A small, circular component, possibly a seal or gasket.
- 9**: A small, circular component, possibly a seal or gasket.
- 10**: A small, cylindrical component, possibly a pin or bush.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This diagram shows an exploded view of a mechanical assembly. The main component is a housing (2) with two vertical shafts (3) passing through it. A large, irregular gasket (5) is shown to the left. Various fasteners and seals are indicated by dashed lines and numbered: 4 (a small pin), 6 (a circular seal), 7 (another circular seal), 8 (a bolt), 9 (a nut), and 10 (a washer or spacer). The diagram illustrates the relative positions and assembly sequence of these components.

BAJAJ
pulsar₂₀₀ OIL/COOLED

FIGURA N° 12 : CARCASA IZQUIERDA




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JC-1010-16	Carcasa Izquierda	1	
2	59-0500-08	Espárragos Cilindro	2	
3	DK-1010-94	Platina Motor Arranque	1	
4	39-2188-19	Retén Cigüeñal (22-35-7)	1	
5	59-2100-06	Anillo Retén	1	
6	DK-1010-97	Antivibrante	1	
7	39-0752-01	Tornillo	3	
8	39-2603-20	Balinera Clutch (6202Z)	1	
9	59-2000-06	Balinera Eje Salida (6204)	1	
10	39-2185-20	Balinera Izquierda Balanceador	1	(6303)
11	30-1010-14	Retén Eje Salida	1	
12	39-2190-19	Retén Eje Cambios (12-22-9)	1	
13	DH-1012-03	Conducto Aire	1	
14	DH-1016-61	Tapón Drenaje Aceite	1	
15	31-1011-06	Arandela Tapón Drenaje	1	
16	31-2010-81	Swiche Neutro	1	
17	DH-1017-84	Junta Swiche Neutro	1	
18	39-1677-04	Tornillo 6x45	8	
19	39-2305-04	Tornillo	1	
20	DJ-2010-21	Cable Bateria	1	
21	39-2448-11	Arandela Tapón Drenaje	1	
22	39-2180-06	Pin Guía Carcasa	2	
23	39-2181-06	Pin Guía Carcasa	2	
24	DK-1011-24	Sensor Térmico Con Empaque	1	

FIGURA N° 13 : CUBIERTA CLUTCH




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JC-1010-30	Cubierta Clutch	1	
2	DH-1011-97	Antivibrante Carcasa	1	
3	39-1041-19	Retén Eje Leva De Clutch	1	
4	DH-1011-41	Empujador Clutch	1	
5	DH-1011-42	Eje Clutch	1	
6	DK-1012-51	Pin Eje Clutch	1	
7	DG-1014-18	Visor Nivel Aceite	1	
8	DS-1012-15	Pin Seguridad	1	
9	DS-1013-53	Tornillo	10	
10	39-0999-06	Pin Guía Carcasa	2	
11	DK-1012-52	Soporte Cable Clutch	1	
12	DH-1011-54	Junta Cubierta Clutch	1	
13	DH-1210-15	Tapón Aceite	1	
14	DH-1210-11	Platina Tapón Aceite	1	
15	DH-1210-12	Resorte	1	
16	DH-1015-44	Resorte Eje Clutch	1	
17	39-2443-11	Arandela	1	
18	DH-1015-10	Antivibrante	1	
19	DH-1013-88	Tornillo	8	
20	JC-1010-40	Calcomanía Carcasa Clutch	1	
21	39-1990-20	Balinera	2	
22	DH-1014-82	Platina	1	
23	DK-1011-22	Resorte	1	
24	30-1012-36	Balín	1	
25	DK-1011-23	Válvula Presión	1	
26	39-2547-17	Pin Seguridad	1	
27	DS-1012-63	Tapón Aceite	1	

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

FIGURA N° 15 : CLUTCH




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	DK-1010-73	Clutch Completo	1	
2	DK-1011-26	Espaciador Clutch	1	
3	DK-1010-75	Clutch Completo Sin Corona	1	
4	DK-1011-63	Base Prensa Clutch	1	
5	DK-1010-01	Corona Interna Clutch	1	
6	DK-1013-56	Kit Discos Clutch	1	Items: 6A, 6B y 6C
6A	DK-1011-49	Disco Clutch "A" de 36 Corchos	4	
6B	DK-1011-50	Disco Clutch "B" de 40 Corchos	1	
6C	DK-1012-55	Disco Clutch "C" de 48 Corchos	1	
7	DK-1011-51	Separador Clutch	5	Alt. DH-1017-43
8	DK-1011-52	Resortes Clutch	4	
9	DK-1010-78	Empujador Clutch	1	
10	DK-1011-53	Arandela Anti-brinco Plana	1	
11	DK-1011-55	Arandela Anti-brinco Concava	1	
12	DK-1011-54	Tornillo	4	
13	39-2200-11	Arandela Especial	1	
14	DH-1016-48	Tuerca Izquierda	1	
15	39-1880-20	Balinera Clutch (6002)	1	
16	DK-1010-72	Empujador	1	
17	DH-1012-75	Tuerca Eje Clutch	1	
18	DH-1011-80	Leva Clutch	1	
19	39-1674-04	Tornillo Leva Clutch	1	
20	36-DK00-29	Kit Corona y Piñón Primario	1	

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This diagram illustrates the exploded view of a mechanical assembly, likely a pump or motor component. The parts are numbered 1 through 18. The assembly is shown in a disassembled state, with dashed lines indicating the alignment and assembly sequence of the components. Key parts include a central shaft assembly (1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 13, 14, 15, 16, 17, 18), a housing (1), and various fasteners (screws, bolts, nuts, washers, and springs). The diagram is enclosed in a dashed rectangular border.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This exploded view diagram illustrates the components for a boat's transom assembly. The parts are labeled as follows:

- 1**: A large, curved transom plate.
- 2**: A small rectangular plate with a circular hole.
- 3/5**: A rectangular mounting bracket with two circular holes and a cable entry point.
- 4**: A long, narrow transom plate with a curved end.
- 6**: A small rectangular plate with a circular hole.

The diagram shows the relative positions of these components, with dashed lines indicating the assembly path for the mounting bracket (3/5) and the small plate (6) onto the transom plate (4).

BAJAJ
pulsar₂₀₀ OIL/COOLED

This diagram illustrates the assembly of the rear of a bicycle helmet. The components are numbered as follows:

- 1**: Points to the entire rear assembly area.
- 2**: A bolt used to secure the rear of the helmet shell.
- 3**: The rear portion of the helmet's outer shell.
- 4**: A small circular gasket or spacer.
- 5**: A chin strap with a buckle.
- 6**: A circular liner or padding piece.

The diagram shows the shell (3) being attached to the main helmet body using bolt (2) and gasket (4). The liner (6) is positioned between the shell and the main body. The chin strap (5) is shown separately, indicating its attachment point.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or motor. The parts are numbered 1 through 18. The main assembly (11) features a central shaft with a gear (9) and a large gear (3). A cover (13) is shown with a pin (14) and a screw (12). A flange (2) and a ring (1) are also shown. A large gear (3) is shown with a pin (10) and a screw (4). A spring (15) and a pin (16) are shown. A pin (17) and a screw (18) are shown. A pin (6) and a screw (7) are shown. A pin (8) and a screw (5) are shown. A pin (1) and a screw (10) are shown. A pin (2) and a screw (16) are shown. A pin (3) and a screw (17) are shown. A pin (4) and a screw (18) are shown. A pin (5) and a screw (15) are shown. A pin (6) and a screw (14) are shown. A pin (7) and a screw (12) are shown. A pin (8) and a screw (13) are shown. A pin (9) and a screw (11) are shown. A pin (10) and a screw (1) are shown. A pin (11) and a screw (2) are shown. A pin (12) and a screw (3) are shown. A pin (13) and a screw (4) are shown. A pin (14) and a screw (5) are shown. A pin (15) and a screw (6) are shown. A pin (16) and a screw (7) are shown. A pin (17) and a screw (8) are shown. A pin (18) and a screw (9) are shown.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This diagram shows an exploded view of a mechanical assembly. The main component is a large, curved metal frame (1). At the top, there is a pivot point with a pin (3) and a washer (4). A bracket (5) is attached to the top of the frame. A cable or hose (6/10) is connected to the top of the frame. A small component (7) is attached to the side of the frame. A bracket (8/9) is attached to the bottom of the frame. At the bottom, there is a complex assembly of components, including a motor or actuator (2) and various mounting brackets and pins.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

The diagram shows an exploded view of a mechanical assembly. It consists of two main sub-assemblies, labeled 1 and 2, which are enclosed in dashed-line boxes. Sub-assembly 1 (bottom left) includes a long cylindrical component (3), a small wedge-shaped part (8), a circular ring (7), and a small bolt (5) with a washer (6) and a nut (4). Sub-assembly 2 (top right) includes a similar long cylindrical component (3), a wedge-shaped part (8), a circular ring (7), and a bolt (5) with a washer (6) and a nut (4). The components are numbered 1 through 8, with lines indicating their relative positions and assembly sequence.

BAJAJ
pulsar₂₀₀ OIL/COOLED

This exploded view diagram illustrates the assembly of a mechanical component. The main body is labeled 1. A bracket-like part, labeled 2, is shown being attached to the main body at points 6 and 7. A separate view shows the bracket (2) being secured to a larger component (3) using a pin (4), a washer (5), and a nut (9). A bolt (8) is shown being inserted into the main body (1). The diagram uses dashed lines to indicate the alignment and assembly sequence of the parts.

BAJAJ
pulsar₂₀₀ OIL/COOLED

This exploded view diagram illustrates the assembly of a mechanical component. The parts are numbered as follows:

- 1**: A bracket or housing component with mounting holes.
- 2**: A curved, flexible part, possibly a gasket or seal, shown with dashed lines indicating its placement.
- 3**: A large, flat, rectangular plate or cover with a central cutout and mounting tabs.
- 4**: A small circular washer or spacer.
- 5**: A long screw or bolt used for fastening.
- 6**: A bracket or support arm that fits into the main assembly.
- 7**: A small, angled plate or gasket.
- 8**: A small circular component, likely a pin or a small washer.
- 9**: A small, curved component, possibly a clip or a small bracket.

The diagram shows the relative positions and assembly sequence of these parts, with dashed lines indicating the path of assembly.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED


[illegible]

Diagram illustrating the components of a wheel assembly:

- 1: Wheel rim and hub assembly.
- 2: Tire.
- 3: Wheel rim and hub assembly (shown from a different perspective).
- 4: Tire.
- 5: A small component, likely a nut or bolt, used for securing the tire to the rim.

BAJAJ
Pulsar *200* OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This exploded view diagram illustrates the assembly of a mechanical component, likely a door latch or actuator. The main body is labeled 1. Key sub-assemblies and parts include:

- Part 2:** A curved cable or hose assembly with multiple fittings.
- Part 3:** A curved metal arm or lever.
- Part 4:** A small cylindrical component, possibly a pin or bush.
- Part 5:** A series of small circular components, likely O-rings or spacers.
- Part 6:** A small bracket or mounting plate.
- Part 7:** Two small screws or bolts.
- Part 8:** A small pin or screw.
- Part 9:** A small circular component, possibly a washer or spacer.
- Part 10:** Two small pins or screws.
- Part 11:** A small cylindrical component, possibly a pin or bush.
- Part 12:** A small rectangular component, possibly a switch or sensor.
- Part 13:** A small rectangular component, possibly a switch or sensor.
- Part 14:** A small rectangular component, possibly a switch or sensor.
- Part 15:** A small circular component, possibly a washer or spacer.

The diagram shows the relative positions and assembly sequence of these parts, with lines indicating the path of assembly.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED


[illegible]

FIGURA N° 35 : CAMPANA TRASERA (1/ 2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	39-2242-20	Balinera Campana Trasera	1	(6202Z)
2	DK-1510-22	Buje Campana Trasera	1	
3	DJ-1510-88	Antivibrante Campana	1	
4	39-2241-20	Balinera Campana Trasera	1	(6302Z)
5	30-1510-69	Resorte Bandas Freno	2	
6	30-1510-68	Banda de Freno Trasero	1	
7	JC-1510-05	Leva Freno Trasero	1	
8	JC-1510-02	Plato Porta Bandas Tras. (Solo)	1	
9	DK-1510-09	Eje Rueda Trasera	1	
10	JC-1510-11	Buje	1	
11	JC-1510-07	Leva Freno Trasero	1	
12	39-2447-04	Tornillo Leva Freno	1	
13	39-0798-15	Tuerca de 6mm.	1	
14	JC-1510-06	Indicador Desgaste Bandas	1	
15	30-1510-38	Anillo Retenedor	1	
16	DH-1710-19	Tuerca Pasador Brazo Oscilante	1	
17	39-1997-15	Tuerca Porta Sproket	2	
18	39-1224-11	Arandela Porta Sprocket	2	
19	DK-1510-14	Buje Porta Sprocket	1	
20	DS-1510-74	Arandela Tornillo Sprocket	3	
21	DK-1510-12	Retén Porta Sproket	1	
22	DK-1510-13	Balinera Porta Sprocket	1	
23	DK-1510-05	Porta Sprocket	1	
24	DS-1510-73	Tornillos Sprocket	6	
25	DK-1510-15	Buje	1	

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

37

FIGURA N° 37: MANUBRIO




FIG. No.	PORTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JC-1810-05	Manubrio	1	
2	DH-1810-53	Abrazadera Manubrio	1	
3	39-1714-04	Tornillo	4	
4	DH-2010-48	Comando Luces Izquierdo	1	
5	DH-2010-49	Comando Luces Derecho	1	
6	DJ-1910-53	Soporte Leva Clutch	1	
7	DJ-1910-54	Soporte Izquierdo	1	
8	DJ-1910-55	Leva Clutch	1	
9	DD-1910-85	Tornillo Leva Clutch	1	
10	39-1184-15	Tuerca Comando Izquierdo	1	
11	36-DK00-19	Juego Tornillos Leva Freno	1	Ref. Pag. No.52
12	DH-1910-07	Manillar Izquierdo	1	
13	DH-1910-14	Carretel Acelerador	1	
	DH-1910-17	Tubo Interno Manillar Acelerador	1	
	DH-1910-08	Caucho Manillar Acelerador (Solo)	1	
14	DH-1910-19	Guardapolvo	1	
15	DJ-1810-11	Bujes Manubrio	2	
16	DH-1810-40	Tornillo	2	Alt. 39 2427 04
17	DJ-1810-39	Emblema Manubrio	1	
18	DJ-2210-03	Espejo Retrovisor Izquierdo	1	
19	DJ-2210-04	Espejo Retrovisor Derecho	1	
20	DS-1810-22	Switch Encendido	1	
21	39-1943-04	Tornillos	2	
22	DJ-2010-35	Swiche Clutch	1	
23	DJ-2011-80	Sensor De Direccionales	1	
24	DJ-2011-81	Imán Autocancelación Direccionales	1	

FIGURA N° 38: SUSPENSIÓN DELANTERA (1/2)




FIG. No.	PARTE No.	DESCRIPCIÓN	CANT. VEH.	OBSERVACIÓN
1	JC-1810-01	Suspensión Delantera Completa	1	
2	DG-1810-21	Guardapolvo Telescópico	1	
3	DG-1810-23	Retén Tubo Telescópico	2	
4	DG-1810-13	Buje Guía Tubo Telescópico	2	
5	DG-1810-22	Pin De Seguridad	1	
6	JC-1810-11	Camisa Tubo Telescópico Izquierda	1	
7	JC-1810-12	Camisa Tubo Telescópico Derecha	1	
8	30-1810-26	Junta Tornillo	2	
9	30-1810-25	Tornillo Camisa Telescópico	2	
10	DS-1810-77	Cilindro Interno Tubo Telescópico	2	
11	JC-1810-21	Tubo Telescópico	2	
12	DG-1810-11	Buje Guía Tubo Telescópico	2	
13	DJ-1811-04	Resorte Tubo Telescópico	2	
14	DH-1810-09	Caucho Tapón Suspensión	2	
15	DH-1810-15	Tornillo Telescópico	2	
16	30-1810-29	Anillo Retén	2	
17	30-1810-28	Arandela Resorte Suspensión	2	
18	DS-1810-85	Buje Separador Cabeza Espiga	2	
19	DG-1810-03	Arandela	2	
20	DG-1810-25	Tornillo Espiga	1	
21	JC-1810-02	Cabeza Espiga	1	
22	DG-1810-08	Tornillo Soporte Guardafango Del.	2	
23	JC-1810-07	Caucho Espiga	2	
24	JC-1810-06	Cubierta Caucho Espiga	4	
25	52-JC00-19	Soporte Farola	1	

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This exploded view diagram illustrates the assembly of a bicycle seat. The components are numbered as follows:

- 1**: The main seat body, shown in a dashed outline.
- 2**: A small rectangular plate or insert.
- 3**: A long, narrow saddle pad or insert.
- 4**: A set of three screws used to secure the saddle pad (3) to the seat body (1).
- 5**: A square base plate.
- 6**: A curved, dark-colored saddle cover or fender.
- 7**: A long bolt.
- 8**: A small circular washer or spacer.
- 9**: A decorative cap or plug.

Dashed lines indicate the assembly path and alignment of the parts. The seat body (1) is the central component, with the saddle pad (3) and cover (6) being attached to its top surface. The base plate (5) and various fasteners (7, 8, 9) are shown being attached to the underside of the seat body.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

This diagram shows the exploded view of a motorcycle headlight assembly. The components are labeled with callouts:

- 1/2**: Points to the main headlight assembly, which includes the lens, reflector, and internal wiring harness.
- 3/4**: Points to a mounting bracket or nut that secures the headlight to the motorcycle frame.
- 5**: Points to a small cylindrical component, likely a fuse or a relay, which is part of the electrical system.

BAJAJ
pulsar₂₀₀ OIL/COOLED

This exploded view diagram illustrates the assembly of a car stereo unit. The components are numbered as follows:

- 1:** The main car stereo unit, shown in a dashed box at the top right.
- 2:** A small screw used to secure the unit to the dashboard.
- 3:** A small plastic spacer or bush.
- 4:** A larger screw for mounting the unit.
- 5:** A screw for the antenna cable connection.
- 6:** A screw for the faceplate.
- 7:** A rectangular speaker or tweeter with a cable.
- 8:** A metal bracket or plate for the speaker.
- 9:** A rectangular metal plate.
- 10:** A screw for the metal plate.
- 11:** A control panel or faceplate with various buttons and knobs.
- 12:** A series of small screws and spacers used to mount the control panel.

BAJAJ
pulsar₂₀₀ OIL/COOLED

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

BAJAJ
pulsar₂₀₀ OIL/COOLED

[illegible]

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
1	36-DH10-06	Kit Antivibrantes Tapa Volante	DH-1012-82	Antivibrante Tapa Volante	1
			DH-1012-92	Antivibrante "A" Izquierdo	1
			DH-1012-94	Antivibrante "B" Izquierdo	1
2	36-DH10-07	Kit Arandelas Tapa Volante	DH-1012-83	Antivibrante Platina Plato Bobinas	1
			DH-1012-93	Antivibrante Platina Tapa Volante	1
3	36-DK00-07	Kit Filtro Centrifugo	39-2200-11	Arandela	1
			DH-1012-34	Junta Filtro Centrifugo	1
			39-2267-01	Tornillo Estrella	1
			DH-1010-66	Conducto Aceite	1
			DH-1010-67	Resorte Conducto Aceite	1
			39-2199-08	Pin	1
4	36-DK00-11	Kit Tornillos Soportes de Motor	39-2312-04	Tornillo	4
			39-1970-15	Tuerca	8
			39-2413-04	Tornillo	1
			DH-1612-45	Tuerca	3
5	36-DK00-12	Kit Bujes Amortiguador	39-0714-11	Arandela	8
			39-0712-15	Tuerca	2
			39-0737-12	Wasa	2
6	36-DK00-13	Kit Pines Reposapié Pasajero	DJ-1611-86	Platina	2
			DH-1610-61	Pin	2
			30-1410-31	Anillo Retenedor	2
			39-1040-11	Arandela	2
			39-0784-08	Pin	2
7	36-DK00-17	Kit Varilla Freno	30-1910-38	Pin	1
			39-0219-11	Arandela 6 mm	1
			39-0808-08	Pin	1
			30-1910-35	Resorte Varilla Freno	1
			15-1910-26	Pin Pasador Varilla Freno	1
			30-1910-36	Tuerca	1

LISTA DE KITS

Item	Referencia	Descripción	Contenido del Kit		
			Referencia	Descripción	Cant.
8	36-DK00-19	Kit Soporte Leva Clutch	30-1910-24	Tornillo Ajuste	1
			30-1910-17	Tuerca	1
			39-0219-11	Arandela	1
			39-0725-04	Tornillo	1
9	36-DK00-21	Kit Bujes Soporte Carenaje	DJ-1810-29	Buje Carenaje	1
			DJ-1810-64	Antivibrante	1
			39-0211-11	Arandela	1
			39-1553-04	Tornillo	1
10	36-DS10-01	Kit Anillos Reten Culata	39-2391-21	Anillo Retenedor	2
			39-1283-21	Anillo Retenedor	2
11	36-DV00-03	Kit Cunas de Dirección	DG-1810-45	Cuna Chasis	1
			DG-1810-46	Cuna Dirección	1
			DG-1810-47	Cuna Superior	1
12	36-JC00-01	Kit Calcomanías	JC-1410-18	Calcomanía "Oil Cooler" Izquierda	1
			JC-1410-19	Calcomanía "Oil Cooler" Derecha	1
			JC-1610-19	Calcomanía Cubierta Sillín Izquierda	1
			JC-1610-20	Calcomanía Cubierta Sillín Derecha	1
			DJ-1410-44	Calcomanía Tanque Izquierda	1
			DJ-1410-45	Calcomanía Tanque Derecha	1
13	36-JC00-02	Kit Sprocket y Cadena	DV-1010-48	Empate Cadena	1
			JC-1510-14	Sprocket 35T	1
			DK-1510-10	Cadena 110 con O´ring	1
14	DK-1013-26	Kit Resortes Válvula	DK-1012-47	Arandela Resorte Válvula	2
			DK-1011-08	Resorte Interno Válvula	2
			DK-1011-10	Resorte Externo Válvula	2
			DK-1012-46	Arandela Resorte Válvula	2
15	DK-1013-27	Kit Válvulas	DK-1010-52	Válvula de Admisión	1
			DK-1010-11	Válvula de Escape	1
16	DK-1611-85	Kit Antivibrantes Tapas Laterales	DH-1611-58	Antivibrante Tapa Lateral Delantero	2
			DH-1611-33	Antivibrante Tapa Lateral Trasero	2
17	JC-1010-38	Kit Guías Cadenilla	DH-1010-17	Guía Cadenilla	1
			DK-1010-59	Guía Cadenilla	1

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
15-1910-26	7	51
30-1010-14	11	12
30-1010-61	21	8
30-1012-36	24	13
30-1012-36	6	25
30-1410-28	10	42
30-1410-31	6	51
30-1410-32	11	42
30-1410-39	6	42
30-1510-38	15	35
30-1510-68	6	35
30-1510-69	5	35
30-1510-95	10	37
30-1611-57	2	30
30-1810-25	9	39
30-1810-26	8	39
30-1810-28	17	39
30-1810-29	16	39
30-1910-17	8	52
30-1910-24	8	52
30-1910-35	7	51
30-1910-36	7	51
30-1910-38	7	51
30-2010-85	14	49
30-2011-04	13	49
31-1011-06	11	1
31-1011-06	15	12
31-1011-73	4	6
31-2010-81	16	12
35-1710-33	14	26
36-DH10-06	6	14

PARTE No.	FIG. No.	PAG. No.
36-DH10-06	1	51
36-DH10-07	8	14
36-DH10-07	2	51
36-DH19-02	15	33
36-DK00-07	13	6
36-DK00-07	3	51
36-DK00-11	21	24
36-DK00-11	4	51
36-DK00-12	3	26
36-DK00-12	5	51
36-DK00-13	5	28
36-DK00-13	6	51
36-DK00-15	9	18
36-DK00-17	7	37
36-DK00-17	7	51
36-DK00-18	15	37
36-DK00-19	11	38
36-DK00-19	8	52
36-DK00-21	11	46
36-DK00-21	9	52
36-DK00-26	16	41
36-DK00-29	9	6
36-DK00-29	20	15
36-DS10-01	3	1
36-DS10-01	11	2
36-DS10-01	10	52
36-DV00-03	5	25
36-DV00-03	11	52
36-JC00-01	15	41
36-JC00-01	12	52
36-JC00-02	28	36

PARTE No.	FIG. No.	PAG. No.
36-JC00-02	13	52
39-0007-01	5	18
39-0211-11	9	52
39-0219-11	7	51
39-0219-11	8	52
39-0292-15	7	28
39-0422-15	10	30
39-0694-15	12	37
39-0705-01	5	48
39-0711-11	4	29
39-0712-15	5	51
39-0714-11	5	51
39-0716-01	13	46
39-0725-04	8	52
39-0737-12	5	51
39-0740-11	15	26
39-0740-11	8	42
39-0746-01	7	22
39-0752-01	7	12
39-0761-01	5	22
39-0784-08	6	51
39-0787-08	3	30
39-0787-08	1	32
39-0789-12	11	37
39-0789-12	28	40
39-0794-15	26	36
39-0798-15	13	35
39-0807-08	13	37
39-0808-08	7	51
39-0840-01	2	42
39-0897-04	5	27

PARTE No.	FIG. No.	PAG. No.
39-0999-06	10	13
39-0999-06	4	14
39-1040-11	6	51
39-1041-19	3	13
39-1062-04	24	8
39-1069-01	6	28
39-1075-04	9	1
39-1184-15	10	38
39-1224-11	16	26
39-1224-11	18	35
39-1282-15	4	27
39-1283-21	5	2
39-1283-21	10	52
39-1507-11	3	49
39-1524-01	14	46
39-1540-11	14	37
39-1553-04	9	52
39-1556-04	7	43
39-1620-11	9	7
39-1660-05	2	2
39-1661-21	3	16
39-1672-04	3	7
39-1672-04	5	16
39-1673-04	13	4
39-1674-04	8	2
39-1674-04	14	2
39-1674-04	11	7
39-1674-04	19	15
39-1674-04	2	21
39-1674-04	4	22
39-1677-04	18	12

PARTE No.	FIG. No.	PAG. No.
39-1680-04	7	25
39-1680-04	5	29
39-1680-04	10	48
39-1680-04	11	49
39-1686-06	8	7
39-1686-06	4	21
39-1714-04	3	38
39-1741-04	8	28
39-1765-11	4	18
39-1769-04	2	34
39-1773-04	12	48
39-1778-02	2	44
39-1780-01	12	17
39-1813-04	29	40
39-1880-20	4	4
39-1880-20	15	15
39-1902-04	6	20
39-1902-04	15	22
39-1907-01	8	46
39-1943-04	21	38
39-1944-04	17	22
39-1956-04	4	49
39-1967-04	12	24
39-1970-15	5	24
39-1970-15	6	47
39-1970-15	4	51
39-1972-15	6	48
39-1990-20	21	13
39-1997-15	17	35
39-1998-19	11	10
39-2017-19	5	3

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
39-2132-17	5	5
39-2141-24	5	46
39-2152-20	5	7
39-2153-20	6	6
39-2157-04	8	24
39-2158-11	2	8
39-2160-11	9	8
39-2165-11	3	6
39-2180-06	8	11
39-2180-06	22	12
39-2181-06	2	5
39-2181-06	23	12
39-2183-04	2	6
39-2183-04	3	14
39-2185-20	10	12
39-2188-19	4	12
39-2190-19	12	12
39-2194-21	6	21
39-2199-08	3	51
39-2200-11	13	15
39-2200-11	3	51
39-2203-07	8	6
39-2241-20	4	35
39-2242-20	1	35
39-2267-01	3	51
39-2305-04	19	12
39-2310-04	16	24
39-2310-04	2	50
39-2310-04	5	50
39-2311-04	17	24
39-2312-04	4	24

PARTE No.	FIG. No.	PAG. No.
39-2312-04	4	51
39-2362-20	2	32
39-2381-04	3	42
39-2383-15	18	49
39-2391-21	10	52
39-2412-04	9	24
39-2413-04	10	24
39-2413-04	4	51
39-2414-04	13	24
39-2424-11	8	43
39-2437-04	6	9
39-2443-11	17	13
39-2447-04	12	35
39-2448-11	21	12
39-2452-21	12	14
39-2453-04	6	10
39-2457-11	18	24
39-2532-04	8	1
39-2542-20	3	4
39-2547-17	26	13
39-2557-17	7	7
39-2583-20	6	11
39-2601-20	7	11
39-2603-20	8	12
39-2606-07	7	9
39-2608-01	10	2
39-2637-04	8	16
39-2647-15	6	1
39-2669-21	1	4
52-DH01-77	10	7
52-DK00-13	5	41

PARTE No.	FIG. No.	PAG. No.
52-DK00-27	4	41
52-DK55-06	2	41
52-DK55-07	3	41
52-JC00-01	8	41
52-JC00-02	9	41
52-JC00-19	25	39
59-0100-13	4	48
59-0200-01	12	41
59-0400-31	9	4
59-0400-40	2	29
59-0500-08	3	11
59-0500-08	2	12
59-1000-02	1	22
59-1100-02	9	3
59-2000-06	9	12
59-2000-07	9	23
59-2000-27	9	11
59-2100-06	5	12
59-2100-08	13	2
AP-1010-43	10	14
BA-1220-03	13	42
CB-1210-14	7	18
CS-1011-28	14	4
DD-1010-62	15	4
DD-1110-12	14	22
DD-1410-22	7	42
DD-1910-85	9	38
DE-1510-08	6	32
DE-1510-12	5	32
DE-1510-15	1	33
DE-1910-10	5	33

PARTE No.	FIG. No.	PAG. No.
DE-1910-11	4	33
DF-1611-02	9	30
DF-1810-98	4	46
DG-1010-29	4	3
DG-1014-18	7	13
DG-1110-08	8	22
DG-1410-28	15	42
DG-1510-05	4	32
DG-1510-07	12	32
DG-1510-08	9	32
DG-1510-49	10	32
DG-1510-89	1	34
DG-1611-21	3	43
DG-1710-18	5	26
DG-1710-19	7	26
DG-1710-20	12	26
DG-1710-21	11	26
DG-1710-22	13	26
DG-1710-34	10	26
DG-1710-38	2	26
DG-1810-03	19	39
DG-1810-08	22	39
DG-1810-11	12	39
DG-1810-13	4	39
DG-1810-21	2	39
DG-1810-22	5	39
DG-1810-23	3	39
DG-1810-25	20	39
DG-1810-42	4	25
DG-1810-45	26	40
DG-1810-45	11	52

PARTE No.	FIG. No.	PAG. No.
DG-1810-46	11	52
DG-1810-47	11	52
DG-1810-48	3	25
DH-1010-06	5	11
DH-1010-17	17	52
DH-1010-48	8	4
DH-1010-64	10	6
DH-1010-65	12	6
DH-1010-66	3	51
DH-1010-67	3	51
DH-1010-72	2	7
DH-1010-79	4	8
DH-1010-79	13	8
DH-1010-84	8	8
DH-1011-11	15	8
DH-1011-41	4	13
DH-1011-42	5	13
DH-1011-44	3	10
DH-1011-46	3	9
DH-1011-54	12	13
DH-1011-57	11	14
DH-1011-63	17	23
DH-1011-64	15	23
DH-1011-72	7	23
DH-1011-80	18	15
DH-1011-88	8	23
DH-1011-95	11	6
DH-1011-97	2	13
DH-1011-99	6	22
DH-1012-03	13	12
DH-1012-34	3	51

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
DH-1012-35	5	8
DH-1012-72	10	1
DH-1012-75	17	15
DH-1012-82	1	51
DH-1012-83	2	51
DH-1012-92	1	51
DH-1012-93	2	51
DH-1012-94	1	51
DH-1013-19	18	8
DH-1013-23	13	14
DH-1013-33	19	8
DH-1013-36	11	8
DH-1013-82	10	23
DH-1013-83	4	11
DH-1013-85	5	23
DH-1013-88	19	13
DH-1013-88	7	14
DH-1013-89	14	23
DH-1013-92	11	4
DH-1013-93	7	10
DH-1013-94	10	10
DH-1014-12	7	4
DH-1014-14	10	5
DH-1014-82	22	13
DH-1014-87	10	11
DH-1014-93	4	9
DH-1014-96	9	9
DH-1015-03	8	10
DH-1015-08	4	2
DH-1015-09	5	10
DH-1015-10	18	13

PARTE No.	FIG. No.	PAG. No.
DH-1015-25	7	19
DH-1015-33	18	23
DH-1015-44	16	13
DH-1015-81	4	23
DH-1016-07	3	19
DH-1016-48	14	15
DH-1016-58	3	23
DH-1016-61	14	12
DH-1017-05	1	10
DH-1017-14	2	10
DH-1017-81	2	23
DH-1017-82	1	23
DH-1017-84	17	12
DH-1018-05	6	19
DH-1110-12	9	2
DH-1110-13	9	22
DH-1110-15	13	22
DH-1110-16	18	22
DH-1210-01	1	21
DH-1210-10	3	21
DH-1210-11	14	13
DH-1210-12	15	13
DH-1210-15	13	13
DH-1210-20	3	18
DH-1210-35	5	21
DH-1210-38	7	2
DH-1211-01	10	17
DH-1211-02	11	17
DH-1410-20	6	41
DH-1410-23	5	43
DH-1410-24	14	42

PARTE No.	FIG. No.	PAG. No.
DH-1410-31	2	43
DH-1410-48	5	42
DH-1410-50	1	42
DH-1510-29	9	37
DH-1610-46	3	20
DH-1610-53	3	27
DH-1610-56	7	27
DH-1610-61	6	51
DH-1610-66	7	30
DH-1611-00	6	27
DH-1611-12	2	25
DH-1611-21	4	30
DH-1611-33	16	52
DH-1611-45	5	30
DH-1611-46	8	30
DH-1611-58	16	52
DH-1611-89	2	24
DH-1611-90	3	24
DH-1612-45	15	24
DH-1612-45	4	51
DH-1612-73	11	24
DH-1612-83	4	45
DH-1612-92	11	48
DH-1612-93	2	48
DH-1612-93	13	48
DH-1710-19	8	26
DH-1710-19	8	32
DH-1710-19	16	35
DH-1810-09	14	39
DH-1810-15	15	39
DH-1810-40	16	38

PARTE No.	FIG. No.	PAG. No.
DH-1810-52	10	46
DH-1810-53	2	38
DH-1910-07	12	38
DH-1910-08	13	38
DH-1910-12	9	49
DH-1910-14	13	38
DH-1910-17	13	38
DH-1910-19	14	38
DH-2010-11	1	49
DH-2010-14	2	49
DH-2010-19	10	49
DH-2010-48	4	38
DH-2010-49	5	38
DH-2010-64	11	30
DH-2010-65	12	30
DH-2110-05	9	50
DH-2210-04	8	50
DJ-1010-22	1	7
DJ-1010-63	23	8
DJ-1010-64	4	19
DJ-1011-09	16	23
DJ-1011-33	6	7
DJ-1011-34	4	7
DJ-1012-09	1	14
DJ-1012-17	2	1
DJ-1012-78	13	23
DJ-1110-23	19	22
DJ-1110-59	2	22
DJ-1110-61	3	22
DJ-1110-62	20	22
DJ-1210-51	2	17

PARTE No.	FIG. No.	PAG. No.
DJ-1210-52	3	17
DJ-1210-53	5	17
DJ-1210-54	6	17
DJ-1210-55	7	17
DJ-1210-57	18	17
DJ-1210-58	14	17
DJ-1210-59	15	17
DJ-1410-06	12	42
DJ-1410-07	4	42
DJ-1410-08	6	43
DJ-1410-44	12	52
DJ-1410-45	12	52
DJ-1510-68	3	34
DJ-1510-69	4	34
DJ-1510-70	5	34
DJ-1510-71	6	34
DJ-1510-72	7	34
DJ-1510-73	8	34
DJ-1510-74	9	34
DJ-1510-75	10	34
DJ-1510-76	2	33
DJ-1510-88	3	35
DJ-1511-05	11	34
DJ-1511-06	12	34
DJ-1610-12	9	14
DJ-1610-67	16	22
DJ-1610-69	9	29
DJ-1610-72	8	48
DJ-1610-79	6	50
DJ-1610-80	7	50
DJ-1610-90	8	27

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
DJ-1611-26	1	27
DJ-1611-27	2	27
DJ-1611-28	3	28
DJ-1611-29	4	28
DJ-1611-32	8	25
DJ-1611-33	9	25
DJ-1611-86	6	51
DJ-1611-88	17	17
DJ-1612-47	6	49
DJ-1810-11	15	38
DJ-1810-29	9	52
DJ-1810-33	3	46
DJ-1810-37	7	46
DJ-1810-39	17	38
DJ-1810-64	9	52
DJ-1810-65	12	46
DJ-1810-69	9	46
DJ-1810-90	7	41
DJ-1811-04	13	39
DJ-1811-19	3	44
DJ-1811-20	2	46
DJ-1910-27	6	33
DJ-1910-28	7	33
DJ-1910-29	8	33
DJ-1910-30	9	33
DJ-1910-31	10	33
DJ-1910-32	11	33
DJ-1910-34	13	33
DJ-1910-35	14	33
DJ-1910-53	6	38
DJ-1910-54	7	38

PARTE No.	FIG. No.	PAG. No.
DJ-1910-55	8	38
DJ-1910-57	3	33
DJ-1910-61	1	45
DJ-2010-20	16	49
DJ-2010-21	20	12
DJ-2010-35	22	38
DJ-2011-00	12	33
DJ-2011-26	5	49
DJ-2011-40	15	49
DJ-2011-46	3	47
DJ-2011-47	4	47
DJ-2011-48	1	47
DJ-2011-49	2	47
DJ-2011-59	4	44
DJ-2011-63	5	44
DJ-2011-64	10	22
DJ-2011-65	17	49
DJ-2011-80	23	38
DJ-2011-81	24	38
DJ-2011-90	7	44
DJ-2210-03	18	38
DJ-2210-04	19	38
DK-1010-01	5	15
DK-1010-03	3	2
DK-1010-11	15	52
DK-1010-52	15	52
DK-1010-59	17	52
DK-1010-63	1	5
DK-1010-72	16	15
DK-1010-73	1	15
DK-1010-75	3	15

PARTE No.	FIG. No.	PAG. No.
DK-1010-78	9	15
DK-1010-94	3	12
DK-1010-97	6	12
DK-1011-02	6	8
DK-1011-03	3	8
DK-1011-04	7	8
DK-1011-05	12	8
DK-1011-06	14	8
DK-1011-07	17	8
DK-1011-08	14	52
DK-1011-10	14	52
DK-1011-12	1	16
DK-1011-18	16	8
DK-1011-22	23	13
DK-1011-23	25	13
DK-1011-24	24	12
DK-1011-25	1	8
DK-1011-26	2	15
DK-1011-35	10	9
DK-1011-44	10	8
DK-1011-49	6A	15
DK-1011-50	6B	15
DK-1011-51	7	15
DK-1011-52	8	15
DK-1011-53	10	15
DK-1011-54	12	15
DK-1011-55	11	15
DK-1011-57	5	9
DK-1011-59	1	9
DK-1011-60	2	9
DK-1011-63	4	15

PARTE No.	FIG. No.	PAG. No.
DK-1011-76	6	23
DK-1011-77	16	10
DK-1011-80	13	10
DK-1011-82	4	10
DK-1011-85	14	10
DK-1011-85	3	37
DK-1011-86	15	10
DK-1011-86	2	37
DK-1011-87	12	10
DK-1011-87	4	37
DK-1012-25	2	16
DK-1012-36	8	5
DK-1012-36	9	16
DK-1012-37	9	5
DK-1012-37	10	16
DK-1012-38	7	5
DK-1012-38	4	16
DK-1012-45	20	8
DK-1012-46	14	52
DK-1012-47	14	52
DK-1012-48	7	6
DK-1012-51	6	13
DK-1012-52	11	13
DK-1012-53	9	10
DK-1012-55	6C	15
DK-1012-75	6	16
DK-1012-76	7	16
DK-1012-89	11	16
DK-1013-05	5	19
DK-1013-26	6	3
DK-1013-26	14	52

PARTE No.	FIG. No.	PAG. No.
DK-1013-27	7	3
DK-1013-27	15	52
DK-1013-28	4	5
DK-1013-56	6	15
DK-1013-61	8	9
DK-1014-75	8	19
DK-1110-10	8	18
DK-1210-09	2	18
DK-1410-15	9	43
DK-1510-05	23	35
DK-1510-06	2	31
DK-1510-07	4	31
DK-1510-08	13	32
DK-1510-09	9	35
DK-1510-10	30	36
DK-1510-10	13	52
DK-1510-12	21	35
DK-1510-13	22	35
DK-1510-14	19	35
DK-1510-15	25	35
DK-1510-22	2	35
DK-1510-26	5	31
DK-1510-27	7	32
DK-1510-28	3	32
DK-1510-36	27	36
DK-1610-85	6	29
DK-1610-86	3	29
DK-1610-96	1	24
DK-1610-98	1	29
DK-1611-22	1	30
DK-1611-23	10	41

ÍNDICE DE REFERENCIAS

PARTE No.	FIG. No.	PAG. No.
DK-1611-24	11	41
DK-1611-27	19	24
DK-1611-28	20	24
DK-1611-37	1	28
DK-1611-47	3	50
DK-1611-48	4	50
DK-1611-53	3	48
DK-1611-59	6	24
DK-1611-60	7	24
DK-1611-61	14	24
DK-1611-64	14	48
DK-1611-85	1	43
DK-1611-85	16	52
DK-1611-98	7	29
DK-1611-99	3	45
DK-1710-03	9	26
DK-1710-06	6	26
DK-1810-34	4	43
DK-1810-50	6	25
DK-1810-51	10	25
DK-1910-11	2	45
DK-1910-13	5	37
DK-2010-03	1	48
DK-2010-24	7	48
DK-2010-44	16	46
DK-2010-52	6	44
DK-2010-65	9	42
DK-2010-77	14	32
DK-2010-78	12	49
DK-2110-01	1	20
DK-2110-04	4	20

PARTE No.	FIG. No.	PAG. No.
DK-2110-08	5	20
DK-2210-05	1	50
DK-2210-06	1	50
DL-1810-10	6	46
DP-1611-45	9	48
DS-1010-84	7	1
DS-1010-96	5	1
DS-1011-54	5	6
DS-1011-66	4	1
DS-1012-15	8	13
DS-1012-63	27	13
DS-1012-76	6	4
DS-1013-33	3	3
DS-1013-35	1	3
DS-1013-36	2	3
DS-1013-53	9	13
DS-1013-53	12	23
DS-1013-66	8	3
DS-1510-73	24	35
DS-1510-74	20	35
DS-1611-25	8	29
DS-1810-22	20	38
DS-1810-77	10	39
DS-1810-85	18	39
DS-2110-05	2	20
DV-1010-42	2	14
DV-1010-48	22	8
DV-1010-48	13	52
GH-2010-12	5	47
JC-1010-01	1	6
JC-1010-12	3	5

PARTE No.	FIG. No.	PAG. No.
JC-1010-14	1	19
JC-1010-16	1	12
JC-1010-18	1	11
JC-1010-22	2	4
JC-1010-29	2	11
JC-1010-30	1	13
JC-1010-33	5	14
JC-1010-34	12	4
JC-1010-35	10	4
JC-1010-36	1	1
JC-1010-36	1	2
JC-1010-37	6	5
JC-1010-38	5	4
JC-1010-38	17	52
JC-1010-40	20	13
JC-1010-46	1	19
JC-1010-85	4	4
JC-1010-86	3	4
JC-1110-03	11	22
JC-1110-04	12	22
JC-1110-07	11	23
JC-1200-01	12	2
JC-1200-02	6	18
JC-1200-03	6	2
JC-1200-04	1	18
JC-1200-05	1	17
JC-1200-06	9	17
JC-1200-07	16	17
JC-1200-09	4	17
JC-1200-10	13	17
JC-1200-11	8	17

PARTE No.	FIG. No.	PAG. No.
JC-1410-15	13	41
JC-1410-17	14	41
JC-1410-18	18	41
JC-1410-18	12	52
JC-1410-19	12	52
JC-1510-02	8	35
JC-1510-05	7	35
JC-1510-06	14	35
JC-1510-07	11	35
JC-1510-08	8	37
JC-1510-10	3	31
JC-1510-11	10	35
JC-1510-13	1	31
JC-1510-14	29	36
JC-1510-14	13	52
JC-1610-02	2	28
JC-1610-17	6	30
JC-1610-19	17	41
JC-1610-19	12	52
JC-1610-20	12	52
JC-1610-22	1	25
JC-1710-02	4	26
JC-1710-03	1	26
JC-1810-01	1	39
JC-1810-02	21	39
JC-1810-03	27	40
JC-1810-05	1	38
JC-1810-06	24	39
JC-1810-07	23	39
JC-1810-11	6	39
JC-1810-12	7	39

[illegible]