

TRIPLE S *Customs*

HYUNDAI ACCENT 1995-2005 VEHICLE WIRING

WIRING INFORMATION 1995 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK/BLUE	Ignition harness
12V IGNITION WIRE	BLACK/WHITE	Ignition harness
12V ACCESSORY WIRE	BLUE/RED	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	White Connector To The Left Of The Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLACK/RED	Blue Connector To The Left Of The Steering Column
TRUNK TRIGGER (-)	BROWN/RED	At Light In Trunk
TACHOMETER WIRE	BROWN/RED or BLUE/YELLOW	At Ignition Coil
BRAKE WIRE (+)	GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or BLACK/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1996 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK/BLUE	Ignition harness
12V IGNITION WIRE	BLACK/WHITE	Ignition harness
12V ACCESSORY WIRE	BLUE/RED	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	White Connector To The Left Of The Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLACK/RED	Blue Connector To The Left Of The Steering Column
TRUNK TRIGGER (-)	BROWN/RED	At Light In Trunk
TACHOMETER WIRE	BROWN/RED or BLUE/YELLOW	At Ignition Coil
BRAKE WIRE (+)	GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	GREEN/RED or BLACK/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1997 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK/BLUE	Ignition harness
12V IGNITION WIRE	BLACK/WHITE	Ignition harness
12V ACCESSORY WIRE	BLUE/WHITE	Ignition harness
SECOND ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	White Connector To The Left Of The Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLACK/RED	Blue Connector To The Left Of The Steering Column
TRUNK TRIGGER (-)	BROWN/RED	At Light In Trunk
TACHOMETER WIRE	BROWN/RED or BLUE/YELLOW	At Ignition Coil
BRAKE WIRE (+)	GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1998 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK/BLUE	Ignition harness
12V IGNITION WIRE	BLACK/WHITE	Ignition harness
12V ACCESSORY WIRE	BLUE/WHITE	Ignition harness
SECOND ACCESSORY WIRE	BLUE/RED	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	White Connector To The Left Of The Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	BLACK/RED	Blue Connector To The Left Of The Steering Column
TRUNK TRIGGER (-)	BROWN/RED	At Light In Trunk
TACHOMETER WIRE	BROWN/RED or BLUE/YELLOW	At Ignition Coil
BRAKE WIRE (+)	GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 1999 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED or BLACK/BLUE	Ignition harness
12V IGNITION WIRE	BLACK/WHITE	Ignition harness
12V ACCESSORY WIRE	BLUE/WHITE	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	BLACK/YELLOW	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	White Connector To The Left Of The Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	PURPLE	Blue Connector To The Left Of The Steering Column
TRUNK TRIGGER (-)	BROWN/BLACK	At Light In Trunk
TACHOMETER WIRE	BROWN/RED or BLUE/YELLOW	At Ignition Coil
BRAKE WIRE (+)	GREEN	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLACK/WHITE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLACK/YELLOW	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/WHITE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2000 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN or ORANGE	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE	Ignition harness
PARKING LIGHTS (+)	GREEN/WHITE	Harness In Driver's Kick Panel
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/WHITE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BROWN or BLUE	At Ignition Coil
BRAKE WIRE (+)	RED	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/WHITE or BLUE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2001Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE	Ignition harness
POWER DOOR LOCK (-)	BLACK/ORANGE	At Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW	At Module Under Dash To The Left Of The Steering Column
<ul style="list-style-type: none"> Power door lock wires only exist on models equipped with factory keyless entry. 		
PARKING LIGHTS (+)	GREEN/ORANGE AND GREEN/BLACK	Harness In Driver's Kick Panel
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BROWN or BLUE	At Ignition Coil
BRAKE WIRE (+)	PINK/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2002 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE	Ignition harness
POWER DOOR LOCK (-)	BLACK/ORANGE	At Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	YELLOW	At Module Under Dash To The Left Of The Steering Column
<ul style="list-style-type: none"> Power door lock wires only exist on models equipped with factory keyless entry. 		
PARKING LIGHTS (+)	GREEN/ORANGE AND GREEN/BLACK	Harness In Driver's Kick Panel
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BROWN or BLUE	At Ignition Coil
BRAKE WIRE (+)	PINK/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BROWN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2003 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	BLUE	At Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	GREEN/ORANGE AND GREEN/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	GREEN	Harness At Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	BROWN or BLUE	At Ignition Coil
BRAKE WIRE (+)	PINK/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2004 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	BLUE	At Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	GREEN/ORANGE AND GREEN/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	GREEN or RED/BLACK	Harness At Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	GRAY	At Engine Control Module Under Driver Side Dash Near Firewall
BRAKE WIRE (+)	PINK/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

WIRING INFORMATION 2005 Hyundai Accent

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	RED	Ignition harness
12V IGNITION WIRE	GREEN	Ignition harness
12V ACCESSORY WIRE	YELLOW	Ignition harness
SECOND ACCESSORY WIRE	BLUE	Ignition harness
STARTER WIRE	WHITE	Ignition harness
POWER DOOR LOCK (-)	YELLOW	At Module Under Dash To The Left Of The Steering Column
POWER DOOR UNLOCK (-)	BLUE	At Module Under Dash To The Left Of The Steering Column
PARKING LIGHTS (+)	GREEN/ORANGE AND GREEN/BLACK	Harness In Driver's Kick Panel
PARKING LIGHTS (-)	GREEN or RED/BLACK	Harness At Steering Column
DOOR TRIGGER/ DOMELIGHT SUPERVISION (-)	GREEN	Harness In Driver's Kick Panel
TRUNK TRIGGER (-)	GREEN/ORANGE	Harness In Driver's Kick Panel
TACHOMETER WIRE	GRAY	At Engine Control Module Under Driver Side Dash Near Firewall
BRAKE WIRE (+)	PINK/BLACK	Harness At Brake Pedal Switch
HORN TRIGGER (-)	BLUE/ORANGE	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	GREEN	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	GRAY	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	ORANGE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLACK	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door