

SUZUKI

PARTS CATALOGUE



DR-150

P09



2020-1

1TH EDITION

PREFACE

This catalogue lists the spare parts used for the following model. Please do refer to the parts catalogue and indicate the parts number and the name listed in this catalogue correctly when you need to replace the spare parts.

Design Code	Factory Reference No. (Abbr. form in the catalogue)	Engine Reference No.	Engine Cad No.
DR150	FA403JC100-XXE09	EG3JC10-E09	10091H3J012H000

一、How to place an order for spare parts?

1. Required document:

The number must be provided as follow when order the spare parts:

- (a) The Engine parts: parts number and the Engine number
- (b) The Body parts: parts number and the Frame number

2. Revision

The Revised Version would be published at a suitable time when the parts Catalogue needed to be revised or renewed. In this case, the edition number would be marked on the cover. The parts would have some difference because our products are improved continuously and the modified parts no. will not be informed before the new edition published.

二、How to use the parts catalogue?

1. Size

The unit of the parts' size indicated in the catalogue is 'mm', for example:

Parts name	Description
Bolt 6×12	Diameter 6mm, Length 12mm

0 Ring D: 3.0, ID: 29.5	Section diameter 3mm, inner diameter 29.5mm
Bearing 35×72×17	Inner diameter 35mm, Outer diameter 72mm, Thickness 17mm

2. Abbr.

The meaning of the Abbreviations in the catalogue are as the followings:

D: Section diameter NT: Number of Teeth L: Length ID: Inner diameter W: Width

OPT: Optional T: Thickness OD: Outer diameter OS: Over size

STD: Standard US: Under size LH: Left hand side RH: Right hand side

3. Assy and the inner parts

The part number with a hyphen '-' in the front means this part could be supplied with the Assy (or the comp.), also could be supplied separately.

For example:

Item 1 CYCLINDER HEAD ASSY

Item1-1 PIN,CAMSHAFT COVER

That means Item1-1 can be supplied with Item 1 and aslo can be supplied separately.

4. The illustrations in the catalogue are just for the purpose to distinguish the parts. There might be some discrepancies between the illustrations and the real parts.. Furthermore, the illustrations can not be used for the assembling purpose. When assembling, pls use the Service Manual of the relative models.

5. The instruction for the color parts


The catalogue lists are being supervised by color code.

For example: Assy,Fuel Tank 44100H22000HF01 F01 is the colour code and means "RED".

When place an order for the color parts, please use the correct parts number (with the color code), based on the compound color sheet of the models.


**This catalogue is edited according to the datas
before 2018-9-22. The modification after that time should
refer to the latest SPS(Spare Parts Modification notice).**

FIG.1 CYLINDER HEAD & CYLINDER HEAD COVER




DR150_P09_001
CYLINDER HEAD & CYLINDER HEAD COVER

FIG.2 CYLINDER




DR150_P09_002
CYLINDER

FIG.3 CRANKCASE




DR150_P09_003
CRANKCASE

FIG.4 CRANKCASE COVER




DR150_P09_004
CRANKCASE COVER

FIG.5 CRANKSHAFT




DR150_P09_005
CRANKSHAFT

FIG.6 STARTER CLUTCH




DR150_P09_006
STARTER CLUTCH

FIG.7 CRAMSHAFT - VALVE




DR150_P09_007
CAMSHAFT-VALVE

FIG.8 CAM CHAIN




DR150_P09_008
CAM CHAIN

FIG.9 CARBURETOR




DR150_P09_009
CARBURETOR

FIG.10 AIR CLEANER




DR150_P09_010
AIR CLEANER

FIG.11 MUFFLER




DR150_P09_011
MUFFLER

FIG.12 2ND AIR VALVE




DR150_P09_012
2ND AIR VALVE

FIG.13 OIL PUMP




DR150_P09_013
OIL PUMP

FIG.14 CLUTCH




DR150_P09_014
CLUTCH

FIG.15 TRANSMISSION




DR150_P09_015
TRANSMISSION

FIG.16 GEAR SHIFTING




DR150_P09_016
GEAR SHIFTING

FIG.17 KICK STARTER




DR150_P09_017
KICK STARTER

FIG.18 STARTING MOTOR




DR150_P09_018
STARTING MOTOR

FIG.19 MAGNETO




DR150_P09_019
MAGNETO

FIG.20 BATTERY




DR150_P09_020
BATTERY

FIG.21 ELECTRICAL




DR150_P09_021
ELECTRICAL

FIG.22 SPEEDOMETER




DR150_P09_022
SPEEDOMETER

FIG.23 HEADLAMP




DR150_P09_023
HEADLAMP

FIG.24 TURN SIGNAL LAMP




DR150_P09_024
TURN SIGNAL LAMP

FIG.25 REAR COMBINATION LAMP




DR150_P09_025
REAR COMBINATION LAMP

FIG.26 WIRING HARNESS




DR150_P09_026
WIRING HARNESS

FIG.27 FRAME




DR150_P09_027
FRAME

FIG.28 STAND




DR150_P09_028
STAND

FIG.29 FOOTREST




DR150_P09_029
FOOTREST

FIG.30 FUEL TANK




DR150_P09_030
FUEL TANK

FIG.31 FUEL COCK




DR150_P09_031
FUEL COCK

FIG.32 FRAME COVER




DR150_P09_032
FRAME COVER

FIG.33 FRONT FENDER




DR150_P09_033
FRONT FENDER

FIG.34 HANDLEBAR




DR150_P09_034
HANDLEBAR

FIG.35 HANDLE SWITCH




DR150_P09_035
HANDLE SWITCH

FIG.36 REAR FENDER




DR150_P09_036
REAR FENDER

FIG.37 COWLING




DR150_P09_037
COWLING

FIG.38 LABEL




DR150_P09_038
LABEL

FIG.39 SEAT




DR150_P09_039
SEAT

FIG.40 COVER, SEAT TAIL



DR150_P09_040
COVER, SEAT TAIL

FIG.49 CARRIER



DR150_P09_049
CARRIER

FIG.1




FIG.1 (1-B-2) CYLINDER HEAD&CYLINDER HEAD COVER (P12-S010-0005)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	11110-01X3J-090	HEAD COMP,CYLINDER	1	
2	11141-01X00	GASKET,CYLINDER HEAD	1	
3	09206-01X10-006	PIN	3	
4	11151-01X00	NUT,CYLINDER HEAD	4	
5	08322-01087	WASHER	4	
6	01550-06257	BOLT	2	
7	11171-01X2J-020	COVER,CYLINDER HEAD	1	
8	11173-01X3J-010	GASKET,CYL HEAD COVER	1	
9	01547-0630A	BOLT	4	
10	01547-0612A	BOLT	1	
11	09168-06018	GASKET	1	
12	11121-01X00	COVER,CYLINDER HEAD,L	1	
13	01547-0512A	BOLT	2	
14	09160-01X00	WASHER	1	
15	09482-00621	PLUG,SPARK(CPR7EA-9)	1	
16	13110-01X00	PIPE COMP,INTAKE	1	
17	09280-34004	O-RING	1	
18	01547-0620A	BOLT	2	
19	13129-01X00	PLATE,CARB HEAT GUARD	1	
20	13119-01X00	GASKET,CARB HEAT GUARD PL	1	
21	09108-01X06-009	STUD BOLT	2	
22	08310-00068	NUT	2	

FIG.2




FIG.2 (1-B-3) CYLINDER (P12-S020-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11210-01X3J-060	CYLINDER COMP	1	
2	11241-01X00	GASKET,CYLINDER	1	
3	09206-01X10-007	PIN,KNOCK	2	
4	09108-01X08-021	STUD BOLT	4	

FIG.3




FIG.3 (1-B-4) CRANKCASE (P12-S030-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11300-01X00	CRANKCASE SET	1	
2	09206-01X10-007	PIN,KNOCK	2	
3	01547-0640A	BOLT	7	
4	01547-0645A	BOLT	1	
5	01547-0670A	BOLT	7	
6	12547-01X00	RETAINER,CSHAFT BRG,L	3	
7	01547-0616A	BOLT	4	
8	12543-01X00	PIN,BRG PUSH	1	
9	12544-01X00	SPRING,BRG PUSH	1	
10	12545-01X00	PLATE,BRG PUSH PIN SPRING	1	
11	09247-01X12-105	PLUG	1	
12	09168-12002	GASKET,TDC PLUG	1	
13	16520-09410	STRAINER COMP,ENGINE OIL	1	
14	09103-100V0	BOLT	2	
15	08319-3110A	NUT	2	
16	09103-08530	BOLT	1	
17	09103-01X10	BOLT	1	
18	08319-3108A	NUT	2	
19	24741-01X00	RETAINER,CNTR SHAFT BEARING	2	
20	01550-0616A	BOLT	2	
21	08211-06141	WASHER,GEAR SHIFT CAM STOPPER	3	

FIG.4




FIG.4 (1-B-5) CRANKCASE COVER (P12-S040-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	11340-01X00	COVER COMP,CLUTCH	1	
2	11482-01X00	GASKET,CLUTCH COVER	1	
3	09206-01X08-004	PIN,KNOCK	4	
4	01547-0640A	BOLT	7	
5	01547-0630A	BOLT	5	
6	58634-01X00	BRACKET,CLUTCH CABLE	1	
7	11351-01X00	COVER,MAGNETO	1	
8	11483-01X00	GASKET,MAGNETO COVER	1	
9	01547-0645A	BOLT	2	
10	01547-0635A	BOLT	9	
11	09259-01X32-002	PLUG	1	
12	09280-01X32-006	O-RING,INTAKE PIPE	1	
13	09247-01X00	PLUG,TIMING OBSERVATION HOLE	1	
14	09280-01X13-010	O-RING	1	
15	11361-01X00	COVER,ENG SPROCKET	1	
16	09206-01X08-002	PIN,KNOCK	2	
17	27640-01X00	PLATE,CHAIN	1	
18	11971-01X00	GAUGE SET,OIL LEVEL	1	
19	09280-18002	O-RING	1	
20	23270-01X00	SHAFT COMP,CLUTCH RELEASE	1	
21	09448-01X15-001	SPRING,TORSION	1	
22	09205-03037	PIN,SPRING	1	
23	09282-01X00	SEAL,OIL	1	

FIG.5




FIG.5 (1-B-6) CRANKSHAFT (P12-S050-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12111-01X00-0A0	PISTON	1	
2	12140-01X00	RING SET,PISTON	1	
3	12151-01X00	PIN,PISTON	1	
4	09381-01X14-001	CIRCLIP	2	
5	12200-01X00	CRANKSHAFT ASSY	1	
6	09420-04002	KEY	1	
7	09264-30001	BEARING,ROLLER	1	
8	12661-01X00	GEAR,CRANK BALANCER DRIVE	1	
9	09164-01X00	WASHER	1	
10	21112-01X00	GEAR,PRIMARY DRIVE NO.2	1	
11	21114-01X00	SPRING,PRIMARY DRIVE GEAR	3	
12	21111-01X00	GEAR,PRIMARY DRIVE	1	
13	09421-04001	KEY	1	
14	09420-04005	KEY,WOODRUFF	2	
15	16520-01X00	FILTER SET,ENGINE OIL	1	
16	16510-01X00	FILTER ROTOR,ENG OIL	1	
17	16540-01X00	COVER ASSY,ENGINE OIL FILTER	1	
18	09440-01X00	SPRING	1	
19	16541-01X00	COVER,ENGINE OIL FILTER	1	
20	09385-01X00	PIN,COTTER	1	
21	16545-01X00	TUBE,OIL PASSING	1	
22	16543-01X00	GASKET,ROTOR COVER	1	
23	02122-0512A	SCREW	3	
24	09140-01X00	NUT,LOCK	1	
25	09160-16005	WASHER	1	
26	12666-01X00	GEAR COMP,CRANK BAL DRIVEN	1	
27	12669-01X00	RACE,CRK BAL DRIVEN GEAR	1	
28	12686-01X00	DAMPER,CRANK BALANCER GEAR	2	
29	09440-01X07-004	SPRING,COMPRESSION	2	
30	09181-01X28-001	WASHER	1	
31	12662-01X00	DISC SPRING	1	
32	09181-01X28-004	WASHER	1	
33	08331-31289	CIRCLIP	1	
34	08211-01X00	WASHER	1	
35	09159-01X14-001	NUT	1	
36	12651-01X00	BALANCER,CRANK	1	
37	09262-01X15-018	BEARING	2	
38	09180-01X15-015	SPACER	1	

FIG.6




FIG.6 (1-B-8) STARTER CLUTCH (P12-S060-0001)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12620-01X00	GEAR COMP,STARTER CLUTCH	1	
2	12611-01X00	GEAR,STARTER IDLE	1	
3	09180-01X10-002	SPACER	1	
4	09206-01X00	SHAFT,GEAR 1ST	1	

FIG.7




FIG.7 (1-B-9) CAMSHAFT-VALVE (P12-S070-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12710-01X00	CAMSHAFT COMP	1	
2	09262-01X12-014	BEARING	1	
3	12741-01X00	SPROCKET,CAMSHAFT	1	
4	09103-01X05-001	BOLT	4	
5	24741-20A10	RETAINER,CAMSHAFT COMP	1	
6	01547-0614A	BOLT	1	
7	12840-01X3J-001	ARM COMP,VALVE ROCKER	2	
8	12842-01X00	SCREW,TAPPET ADJUSTING	1	
9	12843-01X00	NUT	1	
10	12861-01X00	SHAFT,VALVE ROCKER ARM	2	
11	12911-01X00	VALVE,INTAKE	1	
12	12912-01X00	VALVE,EXHAUST	1	
13	12931-01X00	RETAINER VALVE SPRING	2	
14	12932-01X00	COTTER VALVE	4	
15	12921-01X00	SPRING,VALVE INNER	2	
16	12922-01X00	SPRING,VALVE OUTER	2	
17	09289-01X05-004	SEAL,OIL	2	
18	09181-01X16-001	SEAT VALVE SPRING	2	
19	09160-01X12-021	WASHER	2	
20	09164-01X10-001	WASHER	2	

FIG.8




FIG.8 (1-B-10) CAM CHAIN (P12-S080-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	12760-01X00	CHAIN COMP,CAMSHAFT DRIVE	1	
2	12811-01X00	TENSIONER,CAM CHAIN	1	
3	12771-01X00	GUIDE,CAM CHAIN	1	
4	12791-01X10	STOPPER,CHAIN	1	
5	12791-01X00	PLATE	1	
6	01547-0625A	BOLT	1	
7	12830-01X00	ADJUSTER ASSY,TENSIONER	1	
8	12837-01X00	GASKET,TENSIONER ADJUSTER	1	
9	01547-0620A	BOLT	2	
10	09125-01X06-002	SCREW	1	
11	09280-01X09-011	O-RING	1	



FIG.9




FIG.9 (1-B-11) CARBURETOR (P12-S090-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13200-01X00	CARBURETOR ASSY	1	
2	13551-01X40-010	VALVE,PISTON	1	
3	13383-01X40-010	JET NEEDLE	1	
4	13389-01X12-600	CAP,JET NEEDLE	1	
5	13573-01X12-600	COMPRESSION SPRING	1	
6	13241-01X12-600	NEEDLE JET	1	
7	13385-01X12-600	JET HOLDER	1	
8	09491-01X20-040	JET,MAIN 100	1	
8-1	09491H21040H000	JET,MAIN 105	1	OPT
9	09492-01X38-040	PILOT JET	1	
10	13279-01X40-010	ADJUSTER	1	
11	13268-01X12-600	COMPRESSION SPRING	1	
12	13382-01X12-600	WASHER	1	
13	13295-01X12-600	O-RING	1	
14	13250-01X12-600	FLOAT ASSY	1	
15	13254-01X12-600	FLOAT PIN	1	
16	13251-01X12-600	GASKET	1	
17	13247-01X12-600	SCREW,DRAIN	1	
18	13389-01X12-610	O-RING,DRAIN	1	
19	13413-01X40-010	LEVER ASSY	1	
20	13253-01X12-600	O-RING	1	
21	13388-01X12-600	COMPRESSION SPRING	1	
22	13346-01X40-010	CAP,MAIN JET	1	
23	13261-01X12-600	MIXING CAP	1	
24	13370-01X40-010	NEEDLE VALVE ASSY	1	
25	13267-01X40-010	ADJUSTER	1	
26	09401-08414	CLIP	1	
27	09401-01X10-410	CLIP,VACUUM HOSE	3	
28	09401-06101	CLIP	1	
29	13286-01X00	4-WAY PIPE	1	
30	13687-01X00	HOSE,OVERFLOW	1	
31	13688-01X00	HOSE,BREATHER	1	
32	13683-01X00	HOSE,DRAIN	1	

FIG.10




FIG.10 (1-B-12) AIR CLEANER (P12-S100-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	13700-01X00	CLEANER ASSY,AIR	1	
2	13761-01X00	HELMHOLTZ RESONATOR	1	
3	09401-20405	CLIP	1	
4	13170-01X00	CLAMP,OUTLET TUBE	1	
5	13877-01X00	TUBE,DRAIN	1	
6	09401-14301	CLIP	1	
7	02142-0516A	SCREW	4	
8	02142-0512A	SCREW	4	
9	13781-01X00	FILTER,AIR CLNR	1	
10	13891-01X00	TUBE,INLET	1	
11	13781-01X10	SPONGE,FILTER	1	
12	13746-01X00	GASKET,FILTER	1	
13	13782-01X00	TRAP COMP,FLAME	1	
14	13746-01X10	GASKET,AIR CLNR CAP	1	
15	13741-01X00	CAP,AIR CLNR	1	
16	35157-01X00	NUT	6	
17	01550-0616A	BOLT	4	
18	09111-01X06-061	SCREW	2	
19	13787-01X00	GUARD,WATER	1	
20	13851-01X00	TUBE,BREATHER	1	
21	09401-01X15-202	CLIP	2	
22	13920-01X00	COVER,WATER PROOF,NO.2	1	
23	03541-0516A	SCREW	2	

FIG.11




FIG.11 (1-B-13) MUFFLER (P12-S110-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	14181-01X00	CUSHION	1	
2	07130-0825A	BOLT	2	
3	14310-01X00	BODY SET,MUF	1	
4	14791-01X00	COVER,MUF BODY	1	
5	09139-01X06-006	SCREW	3	
6	09160-06164	WASHER	3	
7	09180-01X06-336	SPACER	3	
8	09320-01X10-023	CUSHION	3	
9	09168-06004	GASKET	3	
10	14784-01X00	HEAT-SHIELDED FLAKE,MUF COVER	1	
11	14150-01X00	PIPE SET,EXHAUST	1	
12	14781-01X00	COVER,MUF,FR	1	
13	09139-06027	BOLT	2	
14	09160-06163	WASHER	2	
15	09161-01X06-004	WASHER	2	
16	09168-06004	GASKET	2	
17	01550-0845A	BOLT	1	
18	09180-01X00	SPACER	1	
19	09320-01X00	CUSHION	1	
20	08319-3108A	NUT	1	
21	01550-0830A	BOLT	1	
22	09160-01X08-017	WASHER	1	
23	09320-01X12-005	CUSHION	1	
24	09180-01X08-015	SPACER	1	
25	14771-01X00	CONNECTOR,MUF	1	
26	14459-01X00	CLAMP,MUFFLER CONNECTOR	1	
27	01550-0840A	BOLT	1	
28	09321-01X02	CUSHION	2	

FIG.12




FIG.12 (1-B-14) 2ND AIR VAVLE (P12-S120-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	01547-0616A	BOLT	2	
2	09280-10012	O-RING	1	
3	18410-01X00	PIPE COMP,2ND AIR	1	
4	18463-01X00	HOSE,2ND AIR VALVE VACUUM	1	
5	09401-01X07-201	CLIP	2	
6	18450-01X00	VALVE ASSY,2ND AIR	1	
7	18610-01X00	BRACKET COMP,2ND AIR VALVE	1	
8	09401-15404	CLIP,FUEL HOSE	1	
9	09401-17401	CLIP	1	
10	18461-01X00	HOSE,2ND AIR VALVE	1	
11	01547-0625A	BOLT	2	
12	08316-1006A	NUT	2	
13	09160-01X06	WASHER	2	
14	09320-01X08-051	CUSHION,MUF COVER	2	
15	09180-01X06-034	SPACER	2	
16	44330-01X00	CLEANER COMP,AIR	1	
17	44463-01X00	RUBBER,2ND AIR CLNR	1	
18	09401-01X13-002	CLIP	2	
19	18712-01X00	HOSE,2ND AIR CLNR	1	
20	09401-01X15-202	CLIP	1	
21	09401-01X12-302	CLIP	1	
22	18711-01X00	HOSE,2ND AIR CLNR	1	
23	01547-0612A	BOLT	2	



FIG.13

FIG.13 (2-C-1) OIL PUMP (P12-S130-0001)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	16400-01X00	PUMP ASSY,ENG OIL	1	
2	01547-0630A	BOLT	2	
3	16330-01X00	GEAR COMP,OIL PUMP DRIVEN	1	
4	09383-05001	E-RING	1	
5	09261-02001	PIN,OIL PUMP DRIVEN GEAR	1	
6	16422-20E00	WASHER,OIL PUMP DRIVEN	1	




FIG.14




FIG.14 (2-C-2) CLUTCH (P12-S140-0004)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	21200-01X00	GEAR ASSY,PRIMARY DRIVEN	1	
2	21410-01X00	HUB ASSY,CLUTCH SLEEVE	1	
3	01550-0622A	BOLT	4	
4	21465-01X00	PLATE,CLUTCH PUSH ROD	1	
5	21413-01X00	SPRING,CLUTCH	4	
6	21462-01X00	DISC,CLUTCH PRESSURE	1	
7	21441-01X00	PLATE,CLUTCH DRIVE	3	
8	21441-01X10	PLATE,CLUTCH DRIVE	2	
9	21451-01X00	PLATE,CLUTCH DRIVEN	4	
10	21411-01X00	HUB,CLUTCH SLEEVE	1	
11	09180-01X17-005	SPACER	1	
12	21251-01X00	SPACER,PRIMARY DRIVEN GEAR	1	
13	08211-01X10	WASHER,CLUTCH SLEEVE HUB	1	
14	08211-01X00	WASHER	1	
15	09140-01X00	NUT	1	
16	08163-62030	BEARING,CLUTCH	1	
17	23121-01X00	POLE,CLUTCH PUSH	1	

FIG.15




FIG.15 (2-C-3) TRANSMISSION (P12-S150-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	24120-01X00	SHAFT ASSY,COUNTER	1	
2	24121-01X00	SHAFT,COUNTER	1	
3	24125-01X00	NOZZLE,CNTR SHAFT OIL	1	
4	24221-01X00	GEAR,2ND DRIVE	1	
5	24231-01X00	GEAR,3RD DRIVE	1	
6	24241-01X00	GEAR,4TH DRIVE	1	
7	24242-01X00	BUSH,4TH DRIVE GEAR	1	
8	24251-01X00	GEAR,5TH DRIVE	1	
9	24252-01X00	BUSH,5TH DRIVE GEAR	1	
10	09167-01X00	WASHER	1	
11	09160-01X20-001	WASHER	1	
12	09160-01X12-014	WASHER	1	
13	08211-17241	WASHER	1	
14	09380-01X18-002	CIRCLIP	1	
15	09262-01X12-009	BEARING	1	
16	09262-17023	BEARING	1	
17	09283-01X20-013	SEAL,OIL	1	
18	24130-01X00	SHAFT ASSY,DRIVE	1	
19	24131-01X00	SHAFT,DRIVE	1	
20	24311-01X00	GEAR,1ST DRIVEN	1	
21	24312-01X00	BUSH,1ST DRIVEN GEAR	1	
22	24321-01X00	GEAR,2ND DRIVEN	1	
23	24322-01X00	BUSH,2ND DRIVEN GEAR	1	
24	24331-01X00	GEAR,3RD DRIVEN	1	
25	24332-01X00	BUSH,3RD DRIVEN GEAR	1	
26	24341-01X00	GEAR,4TH DRIVEN	1	
27	24351-01X00	GEAR,5TH DRIVEN	1	
28	09167-01X00	WASHER	1	
29	09160-01X20-001	WASHER	3	
30	09380-01X18-002	CIRCLIP	1	
31	08211-17241	WASHER	2	
32	09241-01X08-001	PLUG,OIL	1	

FIG.15




FIG.15 (2-C-3) TRANSMISSION (P12-S150-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
33	09262-20069	BEARING,DRIVE SHAFT	1	
34	09262-01X17-007	BEARING	1	
35	27511-01X00	SPROCKET,ENGINE	1	
36	27512-01X00	WASHER	1	
37	07130-0610A	SCREW	2	
38	27600-01X00-130	CHAIN ASSY,DRIVE	1	
39	26261-01X00	GEAR,KICK STARTER IDLE	1	
40	24312-01X00	BUSH,1ST DRIVEN GEAR	1	
41	08211-17282	WASHER	2	
42	09380-01X16-001	RING,SNAP	1	

FIG.16




FIG.16 (2-C-5) GEAR SHIFTING (P12-S160-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	25211-01X00	FORK,GEAR SHIFT NO.1	2	
2	25231-01X00	FORK,GEAR SHIFT,MIDDLE	1	
3	25411-01X00	SHAFT,GEAR SHIFT FORK NO.1	1	
4	25421-01X00	SHAFT,GEAR SHIFT FORK,NO.2	1	
5	25311-01X00	CAM,GEAR SHIFT	1	
6	09440-01X04-030	SPRING,COMPRESSION	1	
7	04221-01X00	PIN,CAM SHIFT	1	
8	25380-01X00	PLATE COMP,GEAR SHIFT CAM	1	
9	09261-01X00	PIN,GEAR SHIFT FIVE-STAR WHEEL	2	
10	09117-06037-XC0	BOLT	1	
11	25350-01X00	STOPPER COMP,GEAR SHIFT CAM	1	
12	25355-01X00	SPRING,GEAR SHIFT CAM STOPPER	1	
13	09117-06037-XC0	BOLT	1	
14	25500-01X00	SHAFT ASSY,GEAR SHIFT	1	
15	25518-01X00	SPRING,SHIFT SHAFT RETURN	1	
16	08331-3114A	CIRCLIP	1	
17	09181-01X14-004	WASHER	1	
18	25671-01X00	STOPPER,GEAR SHIFT ARM	1	
19	09283-01X14-003	SEAL,OIL	1	
20	25600-01X00	LEVER ASSY,GEAR SHIFT	1	
21	25652-20C00	RUBBER,GEAR SHIFT PEDAL,FR	1	
22	01500-0820A	BOLT	1	
23	37720-01X00	BASE ASSY,GEAR SHIFT TERM	1	
24	37725-01X00	PLATE,GEAR SHIFT PRESSURE	1	
25	09280-01X19-001	O-RING	1	
26	02112-0418A	SCREW	2	

FIG.17




FIG.17 (2-C-6) KICK STARTER (P12-S165-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	26210-01X00	SHAFT COMP,KICK STARTER	1	
2	26211-01X00	SHAFT,KICK STARTER	1	
3	09160-01X14-006	WASHER	1	
4	09440-01X10	SPRING,RELEASE	1	
5	26231-01X00	RATCHET WHEEL	1	
6	09160-01X16-001	WASHER	2	
7	26241-01X00	GEAR,KICK STARTER DRIVE	1	
8	09380-01X15-002	RING,SNAP	1	
9	26212-01X00	SPRING,KICK STARTER SHAFT	1	
10	26221-01X00	GUIDE,KICK STARTER SHAFT SPRIN	1	
11	09283-01X16-001	OIL SEAL	1	
12	26232-01X00	GUIDE,KICK STARTER	1	
13	01550-0616A	BOLT	2	
14	26300-01X00	LEVER ASSY,KICK STARTER	1	
15	26352-01000	RUBBER,KICK STARTER LEVER	1	
16	01500-0825A	BOLT	1	

FIG.18




FIG.18 (2-C-7) STARTING MOTOR (P12-S170-0003)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	31100-01X21	MOTOR ASSY,STARTING	1	
2	31175-01X01	FRAME ASSY	1	
3	31133-01X00	BRUSH,STARTER MOTOR,MINUS	2	
4	31135-05530	SPRING	4	
5	33810-01X20	WIRE,STARTER MOTOR	1	
6	31153-01X00	OIL SEAL,STARTER MOTOR	1	
7	09280-24003	O RING(D:3,ID:24.5)	1	
8	31264-05530	O RING	2	
9	31281-01X00	BOLT	2	
10	31156-05530	O-RING	2	
11	01547-0630A	BOLT	2	

FIG.19




FIG.19 (2-C-8) MAGNETO (P12-S180-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	32100-01X00	MAGNETO ASSY	1	
2	32101-01X00	STATOR ASSY	1	
3	32102-01X00	ROTOR ASSY	1	
4	09100-01X05-005	BOLT	3	
5	07130-0625A	BOLT	3	
6	08316-1014A	NUT	1	
7	32115-01X10	PLATE,WIRE PRESSURE	1	

FIG.19




FIG.19 (1-C-8) BATTERY

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	33610-15D20	BATTERY ASSY (YTX7L-BS,12V,6AH)	1	
1-2	33610C41K00H000	BATTERY AGM YTX7L BS	1	OPTIONAL
2	33652-28C00	PROTECTOR (40X85X3)	1	
3	33652-36000	PROTECTOR (30X50X3)	5	
4	09462-00093	BAND	1	
5	33860-44A00	WIRE, BATTERY MINUS	1	



FIG.21




FIG.21 (2-C-10) ELECTRICAL (P12-S200-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	31800-01X73-101	RELAY ASSY,STARTING MOTOR	1	
2	08361-3506A	NUT	2	
3	32800-01X00	RECTIFIER ASSY	1	
4	01550-0616A	BOLT	4	
5	32831-01X00	BRACKET,RECT FTG	1	
6	32900-01X00	CDI UNIT	1	
7	35157-01X00	NUT	2	
8	33410-01X00	COIL ASSY,IGNITION	1	
9	33510-01X00	CAP ASSY,SPARK PLUG	1	
10	33541-38210	SEAL,SPARK PLUG	1	
11	33542-01X00	SEAL,HIGH TENSION CORD	1	
12	02112-1520A	SCREW	1	
13	33414-01X00	BRACKET,IGNITION COIL	1	
14	09136-01X06-003	SCREW	1	

FIG.22




FIG.22 (2-C-11) SPEEDOMETER (P12-S210-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	34100-01X00	SPEEDOMETER ASSY	1	
2	34150-01X00	HOOD,SPEEDOMETER	1	
3	34111-01X00	CASE,SPEEDOMETER,LOWER	1	
4	34124-01X00	KNOB,SPEEDOMETER	2	
5	03541-0416A	SCREW	6	
6	35151-21J00	SCREW,HEADLAMP	3	
7	34990-01X00	SENSOR COMP,SPEED	1	
8	07130-0512A	SCREW	2	
9	34997-01X00	CLAMP,SPEED SENSOR	1	
10	03541-0516A	SCREW	1	
11	34981-26H00	ROTOR,SPEED	1	
12	07130-0825A	BOLT	1	

FIG.23




FIG.23 (2-C-12) HEADLAMP (P12-S220-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35100-01X00	HEADLAMP ASSY	1	
2	34121-01X00	UNIT,HEADLAMP	1	
3	35174-01X00	BOOT,HEADLAMP HOUSING	1	
4	34171-01X00	CORD,HEADLAMP	1	
5	09471-01X12-001	BULB(12V,35/35W)	1	HS1 12V 35/35W
6	09471-12216	BULB,POSITION LAMP	1	12V W5W
7	35151-01X00	SCREW,HEADLAMP	1	
8	35154-01X00	SPRING,HEADLAMP ADJUST	1	
9	35194-01X00	CLAMP,HEAD LAMP	2	
10	03541-0412A	SCREW	4	

FIG.24




FIG.24 (2-C-13) TURN SIGNAL LAMP (P12-S230-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35601-01X00	LAMP ASSY,FRONT TURNSIGNAL,R	1	
2	35610-01X00	UNIT,FRONT TURNSIGNAL,R	1	
3	09471-01X12-019	BULB(12V, 10W)	1	12V RY10W
4	35602-01X00	LAMP ASSY,FRONT TURNSIGNAL,L	1	
5	35630-01X00	UNIT,FRONT TURNSIGNAL,L	1	
6	09471-01X12-019	BULB(12V, 10W)	1	12V RY10W
7	08310-0010A	NUT	4	
8	35616-01X00	PLATE,TURNSIGNAL	2	
9	35603-01X00	LAMP ASSY,REAR TURNSIGNAL,R	1	
10	35630-01X00	UNIT,FRONT TURNSIGNAL,L	1	
11	09471-01X12-019	BULB(12V, 10W)	1	12V RY10W
12	35604-01X00	LAMP ASSY,REAR TURNSIGNAL,L	1	
13	35610-01X00	UNIT,FRONT TURNSIGNAL,R	1	
14	09471-01X12-019	BULB(12V, 10W)	1	12V RY10W
15	35616-01X10	PLATE,TURNSIGNAL	2	
16	38610-01X00	RELAY ASSY,TURNSIGNAL	1	

FIG.25

FIG.25 (2-C-14) REAR COMBINATION LAMP (P12-S240-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	35710-01X00	LAMP ASSY,REAR COMB	1	
2	35720-01X00	UNIT,REAR COMB	1	
3	35718-01X00	CORD COMP,REAR COMB	1	
4	09471-12128	BULB (12V, 21/5W)	1	12V P21/5W
5	92125-33GC0	SCREW,LID INNER COVER	6	
6	35910-01X00	LAMP ASSY,LICENSE	1	
7	35970-01X00	REFLEX REFLECTOR ASSY,REAR	1	
8	35950H05300H000	REFLEX REFLECTOR, SIDE.	1	




FIG.26




FIG.26 (3-D-2) WIRING HARNESS (P12-S250-0006)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	36610-01X00	HARNESS WIRING	1	
2	36990-01X32-G20	CLAMP,WIRING HARNESS	1	
3	36990-01X32-G10	CLAMP,WIRING HARNESS	2	
4	09407-12402	CLAMP,WIRING HARNESS	2	
5	36651-26H50	CLAMP,WIRING HARNESS	1	
6	09404-06433	CLAMP	2	
7	03541-0416A	SCREW	4	
8	01550-0610A	BOLT	1	
9	09404-06429	CLAMP,CARB OVFL HOSE	2	
10	36651-12F10	CLAMP	1	
11	36618-01X00	BOOT,WIRING HARNESS	2	
12	36618-01X10	PROTECTOR,WIRING HARNESS	1	
13	36651-26H10	CLAMP,WIRING HARNESS	1	
14	09407-10404	CLAMP,WIRING HARNESS	1	
15	36618-01X30	BOOT,WIRING HARNESS	1	
16	36611-01X00	PROTECTOR,WIRING HARNESS	1	
17	36990-01X32-G30	CLAMP,WIRING HARNESS	1	
18	37100-01X00	LOCK ASSY,STEERING	1	
19	09139-06048	BOLT	2	
20	37740-01X00	SWITCH ASSY,STOP LAMP	1	
21	38500-01X00	HORN ASSY	1	
22	01550-0612A	BOLT	1	
23	37101-01X00	.LOCK SET	1	
24	36990-01X39-J00	CLAMP,SEAT LOCK CABLE	1	
25	36720-01X00	FUSE ASSY	2	NOT ILLUSTRATER

FIG.27




FIG.27 (3-D-3) FRAME (P12-S260-0006)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	41100-01X00	FRAME COMP	1	
2	41762-01X00	PROTECTOR	1	
3	41970-01X00	PLATE COMP,ENG MTG UPPER,R	1	
4	41980-01X00	PLATE COMP,ENG MTG UPPER,L	1	
5	01550-0875A	BOLT	2	
6	08319-3108A	NUT	5	
7	09103-01X10	BOLT	2	
8	41992-01X00	BRACKET,ENG MTG LOWER,R	2	
9	41941-01X10	PLATE,ENG MTG RR,L	2	
10	01550-0816A	BOLT	4	
11	41540-01X00	BOX ASSY,BATTERY	1	
12	41540-01X10	HOLDER ASSY,BATTERY	1	
13	01550-0612A	BOLT	5	
14	68311-01X10	PLATE,LICENSE	1	
15	09229-01X01	RIVET,BLIND	2	
16	09103-01X12	BOLT	1	
17	09180-01X26	SPACER	4	
18	47430-01X00	BOX ASSY,TOOL	1	
19	01550-0616A	BOLT	2	
20	09180-01X07	BUSH	1	
21	95700-01X10	LOCK ASSY,SEAT NO.1	1	
22	95729-053G0	SCREW,HELMET LOCK	2	

FIG.28




FIG.28 (3-D-4) STAND (P12-S270-0003)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	42310-01X00	STAND COMP,PROP	1	
2	42241-01X00	SPRING,PROP STAND	1	
3	09111-01X09	BOLT	1	
4	08319-3110A	NUT	1	
5	43110-01X00	PEDAL COMP,BRAKE	1	
6	09443-01X04	SPRING,TENSION	1	
7	43142-01X02	HOSE,RUBBER	1	
8	09443-01X01	SPRING,TENSION	1	
9	43116-01X00	SEAL,BRAKE PEDAL	2	
10	43159-45F00	BOLT,BRAKE PEDAL ADJUSTER	1	
11	08310-00068	NUT	1	
12	09160-01X01	WASHER	1	
13	04111-2525A	COTTER PIN	1	
14	42336-01X00	RUBBER,PROP STAND	1	
15	01550-0625A	BOLT	1	
16	09180-01X35	SPACER	1	

FIG.29




FIG.29 (3-D-5) FOOTREST (P12-S280-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	43501-01X00	FOOTREST ASSY,FRONT,RH	1	
2	43510-01X00	BRACKET COMP,FR FOOTREST,RH	1	
3	43551-01X00	RUBBER,FRONT FOOTREST	1	
4	43581-01X00	PLATE,FOOTREST	1	
5	09180-01X10	SPACER	1	
6	01547-0614A	BOLT	1	
7	43502-01X00	FOOTREST ASSY,FRONT,LH	1	
8	43520-01X00	BRACKET COMP,FR FOOTREST,LH	1	
9	43551-01X00	RUBBER,FRONT FOOTREST	1	
10	43581-01X00	PLATE,FOOTREST	1	
11	09180-01X10	SPACER	1	
12	01547-0614A	BOLT	1	
13	09448-01X05	SPRING,TORSION	2	
14	09200-01X04	PIN WITH HOLE	2	
15	09160-08153	WASHER	2	
16	04111-2020A	COTTER PIN	2	
17	43600-01X00	FOOTREST ASSY,PILLION,RH	1	
18	43620-01X00	HOLDER COMP,PILLION FOOTREST,RH	1	
19	43610-01X00	BAR COMP,PILLION FOOTREST,RH	1	
20	43612-01X00	RUBBER,PILLION FOOTREST,RH	1	
21	09200-08002	PIN,FR FOOTREST	1	
22	09160-08153	WASHER	1	
23	04111-2020A	COTTER PIN	1	
24	43631-01X40-100	WASHER,PILLION FOOTREST RUBBER	1	
25	43700-01X00	FOOTREST ASSY,PILLION,LH	1	
26	43720-01X00	HOLDER COMP,PILLION FOOTREST,LH	1	
27	43710-01X00	BAR COMP,PILLION FOOTREST,LH	1	
28	43712-01X00	RUBBER,PILLION FOOTREST,LH	1	
29	09200-08002	PIN,FR FOOTREST	1	
30	09160-08153	WASHER	1	
31	04111-2020A	COTTER PIN	1	
32	43631-01X40-100	WASHER,PILLION FOOTREST RUBBER	1	
33	01550-0825A	BOLT	4	

FIG.30




FIG.30 (3-D-7) FUEL TANK (P12-S290-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44110-01X00-541	TANK COMP,FUEL(BLACK)	1	
2	44200-01X00	CAP ASSY,FUEL TANK FILLER	1	
3	44162-01X00	CUSHION,FRONT COVER,R	1	
4	44262-01X00	CUSHION,FRONT COVER,L	1	
5-1	44017-01X00-135	COVER SET,FUEL TANK,R(RED)	1	
5-2	44017-01X00-521	COVER SET,FUEL TANK,R(BLACK)	1	
5-3	44017-01X00-913	COVER SET,FUEL TANK,R(WHITE)	1	
6	44173-01X00	SHIELD,FUEL TANK,R	1	
7	44256-01X00	SEPARATOR	6	
8-1	44018-01X00-135	COVER SET,FUEL TANK,L(RED)	1	
8-2	44018-01X00-521	COVER SET,FUEL TANK,L(BLACK)	1	
8-3	44018-01X00-913	COVER SET,FUEL TANK,L(WHITE)	1	
9	44183-01X00	SHIELD,FUEL TANK,L	1	
10	44256-01X00	SEPARATOR	6	
11	44271-01X00	COVER,FUEL TANK FRONT,R	1	
12	44281-01X10	COVER,FUEL TANK FRONT L	1	
13	44130-01X00	BRACKET COMP,FUEL TANK FRONT	1	
14	92125-33GC0	SCREW,LID INNER COVER	6	
15	01550-0612A	BOLT	2	
16	44256-01X00	SEPARATOR	2	
17	47312-01X00	RUBBER CUSHION	2	
18	09320-01X85	CUSHION	2	
19	09320-09016	CUSHION,CYL COWLING	2	
20	09180-06263	SPACER,CYL COWLING(L9)	2	
21	09116-06167	BOLT	2	
22	09111-06106	BOLT	2	
23	02142-0514B	SCREW	4	
24	44281-01X00	CUSHION,FUEL TANK	2	
25	44542-01X00	CUSHION,FUEL TANK REAR LOWER	2	

FIG.30




FIG.30 (3-D-7) FUEL TANK (P12-S290-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
26	09111-01X16	BOLT	1	
27	08316-1006A	NUT	1	
28	09160-06088	WASHER	1	
29	44423-01X00	HOSE,FUEL TANK WATER DRAIN	1	
30	44283-01X00	PROTECTOR,FUEL TANK NO.1	1	
31	44284-01X00	PROTECTOR,FUEL TANK NO.2	1	
32	44285-01X00	PROTECTOR,FUEL TANK NO.3	1	
33	44286-01X00	PROTECTOR,FUEL TANK NO.4	2	
34-1	68226-01X30-S51	TAPE,FUEL TANK L COV,NO.1(S51)	1	
34-2	68226-01X30-S52	TAPE,FUEL TANK L COV,NO.1(S52)	1	
34-3	68226-01X30-S53	TAPE,FUEL TANK L COV,NO.1(S53)	1	
35-1	68126-01X10-S51	TAPE,FUEL TANK L COV,NO.2(S51)	1	
35-2	68126-01X10-S52	TAPE,FUEL TANK L COV,NO.2(S52)	1	
35-3	68126-01X10-S53	TAPE,FUEL TANK L COV,NO.2(S53)	1	
36-1	68225-01X30-S51	TAPE,FUEL TANK R COV,NO.1(S51)	1	
36-2	68225-01X30-S52	TAPE,FUEL TANK R COV,NO.1(S52)	1	
36-3	68225-01X30-S53	TAPE,FUEL TANK R COV,NO.1(S53)	1	
37-1	68125-01X10-S51	TAPE,FUEL TANK R COV,NO.2(S51)	1	
37-2	68125-01X10-S52	TAPE,FUEL TANK R COV,NO.2(S52)	1	
37-3	68125-01X10-S53	TAPE,FUEL TANK R COV,NO.2(S53)	1	
38	44259-01X40-100	SEPARATOR	2	

FIG.31




FIG.31 (3-D-10) FUEL COCK (P12-S300-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	44300-01X00	COCK ASSY,FUEL	1	
2	44421-01X00	HOSE,FUEL	1	
3	09401-01X82	CLAMP	1	
4	09401-09101	CLAMP	1	
5	09128-06006	BOLT	2	
6	09168-01X26	GASKET,FUEL COCK	2	
7	34810-01X00	GAUGE ASSY,FUEL LEVEL SENDER	1	
8	08316-1006A	NUT	4	

FIG.32




FIG.32 (3-D-11) FRAME COVER (P12-S310-0006)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	47211-01X00-521	COVER,FRAME,L(BLACK)	1	
2-1	47212-01X00-913	LID,FRAME COVER,L(WHITE)	1	
2-2	47212-01X00-521	LID,FRAME COVER,L(BLACK)	1	
3	47111-01X00-521	COVER,FRAME,R(BLACK)	1	
4-1	47112-01X00-913	LID,FRAME COVER,R(WHITE)	1	
4-2	47112-01X00-521	LID,FRAME COVER,R(BLACK)	1	
5	92125-33GC0	SCREW,LID INNER COVER	6	
6	03241-0516B	SCREW	2	
7	47312-01X00	RUBBER CUSHION	8	
8	47846-01X00	CUSHION	2	
9-1	68165-01X00-S51	TAPE,TAIL COVER,R(S51)	1	
9-2	68165-01X00-S52	TAPE,TAIL COVER,R(S52)	1	
10-1	68167-01X00-S51	TAPE,TAIL COVER,L(S51)	1	
10-2	68167-01X00-S52	TAPE,TAIL COVER,L(S52)	1	
11-1	68131-01X00-BLA	EMBLEM,SUZUKI(BLA)	1	
11-2	68131-01X00-SIL	EMBLEM,SUZUKI(SIL)	1	

FIG.33




FIG.33 (3-D-12) FRONT FENDER (P12-S320-0002)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1-1	53111-01X00-135	FENDER,FRONT(RED)	1	
1-2	53111-01X00-521	FENDER,FRONT(BLACK)	1	
1-3	53111-01X00-913	FENDER,FRONT(WHITE)	1	
2	09180-01X33	SPACER	4	
3	09116-06167	BOLT	4	



FIG.34




FIG.34 (3-D-13) HANDLEBAR (P12-S330-0006)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	56110-01X00	HANDLEBAR COMP	1	
2	56500-01X30	MIRROR ASSY,REAR VIEW,R	1	
3	56600-01X30	MIRROR ASSY,REAR VIEW,L	1	
4	58200-01X00	CABLE ASSY,CLUTCH	1	
5	58300-01X00	CABLE ASSY,THROTTLE	1	
6	58620-01X00	GUIDE COMP,CABLE	1	
7	58620-01X10	GUIDE COMP,CABLE	1	
8	01550-0610A	BOLT	1	
9	01550-0612A	BOLT	1	
10	44256-01X10	SEPARATOR	1	



FIG.35





FIG.35 (3-D-14) HANDLE SWITCH (P12-S340-0008)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	37200-01X00	SWITCH ASSY,HANDLE,R	1	
2	37400-01X00	SWITCH ASSY,HANDLE,L	1	
3	57211-01X00	GRIP,L	1	
4	57110-01X00	GRIP COMP,THROTTLE	1	
5	57500-01X00	.LEVER ASSY,CLUTCH & SWITCH	1	
6	57621-01X00	.LEVER,CLUTCH	1	
7	57511-01X00	.HOLDER,LEVER	1	
8	37441-01X00	.ADJUSTER,WIRE	1	
9	57442-45C00	.NUT,CABLE ADJUSTER	1	
10	57431-45C01	.BOLT,LEVER	1	
11	08319-2106B	.U-NUT	1	
12	01547-0628B	.BOLT	2	
13	57560-28G11	.SWITCH ASSY,CLUTCH	1	
14	02112-0410B	.SCREW	1	
15	59671-01X00	.HOLDER	1	
16	57661-01X00	COVER,CLUTCH LEVER	1	

FIG.36




FIG.36 (4-E-2) REAR FENDER (P12-S350-0004)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	63111-01X00	FENDER,REAR	1	
2	09320-01X02	CUSHION	2	
3	01550-0625A	BOLT	2	
4	09160-01X06	WASHER	2	
5	09180-01X08	SPACER	2	
6	09320-01X85	CUSHION	2	
7	63112-01X00	BODY,REAR FENDER,FRONT	1	
8	09148-05077	NUT	6	
9	03241-0512B	SCREW	4	
10	35157-01X00	NUT	4	
11	01550-0616A	BOLT	2	
12	63121-01X00	COVER,REAR FENDER	1	
13	09111-01X06-061	SCREW	2	
14	63113-01X00	MUDGUARD,REAR FENDER	1	
15	03241-0516A	SCREW	2	
16	09160-05501	WASHER	2	
17	09800-01X25	TOOL ASSY	1	
18	35927-01X00	BRACKET,LICENSE PLATE	1	
19	01550-0612A	BOLT	2	
20	08316-1006A	NUT	2	
21	63125-01X40	SHIELD,REAR FENDER	1	
22	09111-01X06-061	SCREW	2	

FIG.37

FIG.37 (4-E-3) COWLING (P12-S360-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	94414-01X00-521	PANEL,COWLING(BLACK)	1	
2	09148-05077	NUT	4	
3	94411-01X00	BODY,COWLING	1	
4	09136-01X43	SCREW	7	
5	56321-01X00	COVER,HANDLE REAR	1	
6	35382-48H00	CUSHION,HEADLAMP	1	
7	09320-01X01	CUSHION	2	
8	51544-01X00	SPACER	2	
9	01550-0625A	BOLT	2	
10	09160-01X06-027	WASHER	2	
11	51589-01X00	RUBBER	2	
12	03241-0516B	SCREW	4	
13	09321-01X02	CUSHION	2	
14	68281-01X00-SIL	EMBLEM,SUZUKI(SIL)	1	




FIG.38




FIG.38 (4-E-4) LABEL (P12-S370-0006)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	68319-01X10	LABEL,GENERAL WARNING	1	
2	99011-01X50-029	MANUAL,OWNER'S	1	
3	68332-01X20	LABEL,TIRE INFORMATION	1	
4	68391-01X00	LABEL,LOADING CAPACITY	1	

FIG.39




FIG.39 (4-E-5) SEAT (P12-S380-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	45100-01X00	SEAT ASSY	1	
2	09329-10001	CUSHION	4	
3	45148-01X00	CUSHION,SEAT MOUNT	6	
4	45149-01X00	CUSHION,SEAT MOUNT CTR	4	
5	45160-01X00	COVER COMP,SEAT	1	
6	45315-01X00	PLATE,SEAT STOPPER,RR	1	
7	08319-3106A	U-NUT	2	
8	45219-29J00	SPACER,SEAT	2	
9	01550-0820A	BOLT	2	

FIG.40

FIG.40 (4-E-6) COVER,SEAT TAIL (P12-S390-0003)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1-1	45511-01X00-913	COVER,SEAT TAIL,R(WHITE)	1	
1-2	45511-01X00-521	COVER,SEAT TAIL,R(BLACK)	1	
2-1	45512-01X00-913	COVER,SEAT TAIL,L(WHITE)	1	
2-2	45512-01X00-521	COVER,SEAT TAIL,L(BLACK)	1	
3	92125-33GC0	SCREW,LID INNER COVER	4	
4	09148-05077	NUT	2	




FIG.41




FIG.41 (4-E-7) STEERING STEM (P12-S400-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	51103-01X20	DAMPER ASSY,FRONT FORK,RH	1	
2	51104-01X10	DAMPER ASSY,FRONT FORK,LH	1	
3	51311-01X00	BRACKET,UPPER	1	
4	51410-01X00	BRACKET COMP,UNDER	1	
5	56211-01X00	HOLDER,HANDLE UPPER	2	
6	09103-01X21	BOLT	6	
7	01550-0835A	BOLT	4	
8	51353-01X00	NUT	1	
9	09160-01X02	WASHER	1	
10	51631-28000	NUT,STEERING STEM	1	
11	51643-40502	SEAL,STEERING UPPER DUST	1	
12	09265-01X02	BEARING,ROLLER	1	
13	09267-01X25-L01	BEARING	1	
14	51153-26F00	OIL SEAL	1	
15	51155-01X12-710	GLISTEN CAKE	1	
16	51173-48H00	SEAL, DUST	1	
17	51156-20K00	SNAP, RING	1	
18	51175H40110H000	SEAL, DUST	2	
19	51153H40100H000	SEAL, OIL	2	

FIG.42




FIG.42 (4-E-8) FRONT WHEEL (P12-S410-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	54111-01X00	HUB,FRONT WHEEL	1	
2	55311-01X00	RIM,FR WHEEL	1	1.85X19
3	55322-01X00	SPOKE,FRONT WHEEL OUTER	18	
4	55321-01X00	SPOKE,FRONT WHEEL INNER	18	
5	55326-11200	NIPPLE,WHEEL SPOKE	36	
6	54731-01X00	SPACER,FRONT HUB BEARING	1	
7	08133-63017	BEARING,FRONT HUB	2	
8-1	55100-01X00-PIR	TIRE SET,FR (90/90-19 TT)	1	PIRELLI
8-2	55100-01X00-CEA	TIRE SET,FR (90/90-19)	1	CEAT
9	55200C01X00H000	TUBE ASSY,WHEEL INNER	1	
10	55261-01X00	PROTECTOR,WHEEL INNER TUBE	1	
11	54711-01X00	AXLE,FRONT	1	
12	54741-01X00	SPACER,FRONT AXLE	2	
13	54742-01X00	SEAL,FRONT WHEEL BEARING	2	
14	08319-3112A	U-NUT	1	
15	59211-01X00	DISC,FRONT BRAKE	1	
16	59421-01X00	BOLT,FRONT BRAKE DISC	6	

FIG.43




FIG.43 (4-E-9) FRONT CALIPER (P12-S420-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59300-01X00	CALIPER ASSY,FRONT	1	
2	55156-26F10	CAP,BLEEDER	1	
3	59121-26F10	BLEEDER	1	
4	59300-01X10	PAD COMP	1	
5	01550-0840A	BOLT	2	



FIG.44




FIG.44 (4-E-10) FRONT BRAKE CYLINDER (P12-S430-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59064-01X1A	CYLINDER SET,FRONT MASTER	1	
2	59600-01X10	.CYLINDER ASSY,FRONT MASTER	1	
3	59667-053B0	..DIAPHRAGM	1	
4	59669-01X30	..CAP,RESERVOIR TANK	1	
5	59689-01X10	..SCREW	2	
6	59671-01X00	..HOLDER	1	
7	59675-01X00	..BOLT	2	
8	59600-01X10	..PISTON/CUP SET	1	
9	-59666-44300	..BOOT	1	
10	57421-01X00	.LEVER,BRAKE,R	1	
11	57321-45F20	.SCREW,BRAKE PIVOT	1	
12	57433-09F00	.NUT,BRAKE LEVER PIVOT	1	
13	57460-14J01	.SWITCH ASSY,STOP	1	

FIG.45




FIG.45 (4-E-11) HOSE,FRONT BRAKE (P12-S435-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	59480-01X00	HOSE COMP,FRONT BRAKE	1	
2	59246-01X00	CLAMP,BRAKE HOSE	1	
3	59268-01X10	CLAMP,BRAKE HOSE	1	
4	09360-10061	BOLT,BRAKE FLUID	2	
5	09161-10009	WASHER	4	
6	01550-0612A	BOLT	2	
7	09407-12402	CLAMP,WIRING HARNESS	1	

FIG.46

FIG.46 (4-E-12) REAR SWINGING ARM (P12-S440-0003)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61100-01X00	SWINGINGARM COMP,REAR	1	
2	09263-20041	BEARING RR SWGARM PIVOT	2	
3	09283-20031	SEAL	2	
4	61211-01X00	SHAFT,RR SWG ARM PIVOT	1	
5	61282-01X00	SPACER,RR SWGARM PIVOT CENTER	1	
6	61262-05300	COVER,RR SWGARM PIVOT	2	
7	08211-14321	WASHER	2	
8	61273-01X00	BUFFER,CHAIN TOUCH DEFENSE	1	
9	61275-01X00	WASHER	1	
10	02112-0612A	SCREW	1	
11	08319-3114A	U-NUT	1	




FIG.47




FIG.47 (4-E-13) REARSHOCK ABSORBER (P12-S450-0005)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	61311-01X00	CASE,CHAIN	1	
2	01550-0612A	BOLT	3	
3	61315-45F00	WASHER,CHAIN CASE	3	
4	61149-01X00	GUARD,CHAIN	1	
5	09111-01X10	BOLT	2	
6	01550-0635A	BOLT	1	
7	09180-01X05	SPACER	1	
8	09320-01X04	RUBBER BUSH	1	
9	62313-01X00	BOLT,RR SHOCK ABS LOWER	2	
10	62100-01X10	ABSORBER ASSY,REAR SHOCK	1	
11	08319-3110A	NUT	2	

FIG.48




FIG.48 (4-E-14) REAR WHEEL (P12-S460-0004)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	64110-01X00	HUB COMP,REAR WHEEL	1	
2	65311-01X00	RIM,RR WHEEL	1	2.15X17
3	65322-01X00	SPOKE,REAR WHEEL OUTER	9	
4	65321-01X00	SPOKE,WHEEL INNER	9	
5	65328-01X00	SPOKE,REAR WHEEL OUTER No.2	9	
6	65327-01X00	SPOKE,REAR WHEEL INNER No.2	9	
7	55326-11200	NIPPLE,WHEEL SPOKE	36	
8	64731-01X00	SPACER,REAR HUB BEARING	1	
9	08134-63027	BALL BEARING	1	
10	08133-62027	BALL BEARING	1	
11-1	65100-01X00-PIR	TIRE SET,RR (110/90-17 TT)	1	PIRELLI
11-2	65100-01X00-CEA	TIRE SET,RR (110/90-17)	1	CEAT
12	65200C01X00H000	TUBE ASSY,WHEEL INNER	1	
13	65261-01X00	PROTECTOR,WHEEL INNER TUBE	1	
14	64711-01X00	AXLE,REAR	1	
15	64751-01X00	SPACER,REAR AXLE,L	1	
16	64741-01X00	SPACER,REAR AXLE,R	1	
17	09283-25111	SEAL,OIL	1	
18	08319-3114A	U-NUT	1	
19	64410-01X00	SHOE COMP,BRAKE	1	
20	55421-01X00	SPRING,BRAKE SHOE	1	
21	55421-01X10	SPRING,BRAKE SHOE	1	
22	54441-01X10	CAM,BRAKE	1	
23	64210-01X00	PANEL COMP,REAR BRAKE	1	
24	64451-01X00	LEVER,REAR BRAKE CAM	1	
25	54492-01X00	PLATE,FR BK LINING INDICATOR	1	
26	54443-01X00	SEAL,BRAKE CAM DUST	2	
27	01550-0635A	BOLT	1	
28	08316-1006A	NUT	1	
29	64511-01X40-100	SPROCKET,REAR	1	

FIG.48




FIG.48 (4-E-14) REAR WHEEL (P12-S460-0004)

REF NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
30	08319-3108A	NUT	6	
31	64613-01X00	BOLT, SPROCKET, REAR	6	
32	61410-01X00	ADJUSTER COMP, CHAIN	2	
33	61421-01X00	PLATE, CHAIN ADJUSTER GUIDE	2	
34	08319-3108A	NUT	2	
35	64712-01X00	WASHER, CHAIN ADJUSTER	2	
36	43310-01X00	ROD COMP, REAR BRAKE	1	
37	09150-06010	NUT	1	
38	43321-01X00	PIN	1	
39	09440-01X07	SPRING, COMPRESSION	1	
40	04111-2015A	COTTER PIN	1	
41	08322-0106A	WASHER	2	

FIG.49




FIG.49 (5-F-3) CARRIER (P12-S480-0004)

REF NO.	PART NO.	DESCRIPTION	QTY	REMARKS
1	46310-01X00-841	CARRIER COMP,REAR(MATTE GRAY)	1	
2	46212-01X00	COLLAR NO.1	2	
3	14413-01X00	SPACER	4	
4	03541-0512A	SCREW	4	
5	46313-01X00	CUSHION,RR CARRIER,R	1	
6	46314-01X00	CUSHION,RR CARRIER,L	1	
7	01550-0825A	BOLT	4	
8	46212-01X00	COLLAR NO.1	2	

PARTS NUMBER INDEX

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
10000		12912-01X00	7-12	14181-01X00	11-1
		12921-01X00	7-15	14310-01X00	11-3
		12922-01X00	7-16	14413-01X00	49-1-2
		12931-01X00	7-13	14459-01X00	11-26
		12932-01X00	7-14	14771-01X00	11-21
	11110-01X3J-090	13110-01X00	1-16	14781-01X00	11-12
	11121-01X00	13119-01X00	1-20	14784-01X00	11-10
	11141-01X00	13129-01X00	1-19	14791-01X00	11-4
	11151-01X00	13170-01X00	10-4	16330-01X00	13-3
	11171-01X2J-020	13200-01X00	9-1	16400-01X00	13-1
11173-01X3J-010	1-8	13241-01X12-600	9-6	16422-20E00	13-6
11210-01X3J-060	2-1	13247-01X12-600	9-17	16510-01X00	5-15
11241-01X00	2-2	13250-01X12-600	9-14	16520-01X00	5-14
11300-01X00	3-1	13251-01X12-600	9-16	16520-09410	3-13
11340-01X00	4-1	13253-01X12-600	9-20	16540-01X00	5-17
11351-01X00	4-7	13254-01X12-600	9-15	16541-01X00	5-19
11361-01X00	4-15	13261-01X12-600	9-23	16543-01X00	5-22
11482-01X00	4-2	13267-01X40-010	9-26	16545-01X00	5-21
11483-01X00	4-8	13268-01X12-600	9-11	18410-01X00	12-3
11971-01X00	4-18	13279-01X40-010	9-10	18450-01X00	12-6
12111-01X00-0A0	5-1	13286-01X00	9-29	18461-01X00	12-10
12140-01X00	5-2	13295-01X12-600	9-13	18463-01X00	12-4
12151-01X00	5-3	13346-01X40-010	9-22	18610-01X00	12-7
12200-01X00	5-5	13370-01X40-010	9-24	18711-01X00	12-22
12543-01X00	3-8	13382-01X12-600	9-12	18712-01X00	12-19
12544-01X00	3-9	13383-01X40-010	9-3	20000	
12545-01X00	3-10	13385-01X12-600	9-7		
12547-01X00	3-6	13388-01X12-600	9-21		
12611-01X00	6-2	13389-01X12-600	9-4		
12620-01X00	6-1	13389-01X12-610	9-18		
12651-01X00	5-36	13413-01X40-010	9-19		21111-01X00 5-12
12661-01X00	5-8	13551-01X40-010	9-2		21112-01X00 5-10
12662-01X00	5-31	13573-01X12-600	9-5		21114-01X00 5-11
12666-01X00	5-26	13683-01X00	9-32		21200-01X00 14-1
12669-01X00	5-27	13687-01X00	9-30		21251-01X00 14-9
12686-01X00	5-28	13688-01X00	9-31		21410-01X00 14-2
12710-01X00	7-1	13700-01X00	10-1		21411-01X00 14-10
12741-01X00	7-3	13741-01X00	10-15		21413-01X00 14-5
12760-01X00	8-1	13746-01X00	10-14		21441-01X00 14-7
12771-01X00	8-3	13746-01X10	10-12		21441-01X10 14-8
12791-01X00	8-5	13761-01X00	10-2		21451-01X00 14-9
12791-01X10	8-4	13781-01X00	10-9		21462-01X00 14-6
12811-01X00	8-2	13781-01X10	10-11		21465-01X00 14-4
12830-01X00	8-7	13782-01X00	10-13		23121-01X00 14-17
12837-01X00	8-8	13787-01X00	10-19		23270-01X00 4-19
12840-01X00	7-7	13851-01X00	10-20		24120-01X00 15-1
12842-01X00	7-8	13877-01X00	10-5		24121-01X00 15-2
12843-01X00	7-9	13891-01X00	10-10		24125-01X00 15-3
12861-01X00	7-10	13920-01X00	10-22		24130-01X00 15-18
12911-01X00	7-11	14150-01X00	11-11		24131-01X00 15-19

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
24221-01X00	15-4	31100-01X21	18-1	35610-01X00	24-13
24231-01X00	15-5	31133-01X00	18-2	35616-01X00	24-8
24241-01X00	15-6	31135-05530	18-3	35616-01X10	24-15
24242-01X00	15-7	31153-01X00	18-6	35630-01X00	24-5
24251-01X00	15-8	31156-05530	18-7	35630-01X00	24-10
24252-01X00	15-9	31175-01X01	18-2	35710-01X00	25-1
24311-01X00	15-20	31264-05530	18-8	35718-01X00	25-3
24312-01X00	15-21	31281-01X00	18-9	35720-01X00	25-2
24312-01X00	15-21	31800-01X73-101	21-1	35910-01X00	25-6
24321-01X00	15-22	32100-01X00	19-1	35927-01X00	36-18
24322-01X00	15-23	32101-01X00	19-2	35950-01X00	25-8
24331-01X00	15-24	32102-01X00	19-3	35970-01X00	25-7
24332-01X00	15-25	32115-01X10	19-7	36610-01X00	26-1-1
24341-01X00	15-26	32800-01X00	21-3	36611-01X00	26-16
24351-01X00	15-27	32831-01X00	21-5	36618-01X00	26-11
24741-01X00	3-19	32900-01X00	21-6	36618-01X10	26-12
24741-20A10	7-5	33410-01X00	21-8	36618-01X30	26-15
25211-01X00	16-1	33414-01X00	21-13	36651-12F10	26-10
25231-01X00	16-2	33510-01X00	21-9	36651-26H10	26-13
25311-01X00	16-5	33541-38210	21-10	36651-26H50	26-5
25350-01X00	16-11	33542-01X00	21-11	36720-01X00	26-1-2
25355-01X00	16-12	33610-15D20	20-1	36990-01X32-G10	26-3
25380-01X00	16-8	33612-01X10	20-2	36990-01X32-G20	26-2
25411-01X00	16-3	33810-01X20	18-5	36990-01X32-G30	26-17
25421-01X00	16-4	33860-01X00	20-3	36990-01X39-J00	26-24
25500-01X00	16-14	34100-01X00	22-1	37100-01X00	26-18
25518-01X00	16-15	34111-01X00	22-3	37101-01X00	26-23
25600-01X00	16-17	34121-01X00	23-3	37200-01X00	35-1
25652-20C00	16-21	34124-01X00	22-4	37400-01X00	35-2
25671-01X00	16-18	34150-01X00	22-2	37441-01X00	35-5-3
26210-01X00	17-1	34171-01X00	23-4	37720-01X00	16-23
26211-01X00	17-2	34810-01X00	31-7	37725-01X00	16-24
26212-01X00	17-9	34981-26H00	22-11	37740-01X00	26-20
26221-01X00	17-10	34990-01X00	22-7	38500-01X00	26-21
26231-01X00	17-5	34997-01X00	22-9	38610-01X00	24-8
26232-01X00	17-12	35100-01X00	23-1	40000	
26241-01X00	17-7	35151-01X00	23-7		
26261-01X00	15-39	35151-21J00	22-6		
26300-01X00	17-14	35154-01X00	23-8		
26352-01000	17-15	35157-01X00	10-2		
27511-01X00	15-35	35157-01X00	21-7		41100-01X00 27-1
27512-01X00	15-36	35157-01X00	36-10		41540-01X00 27-11
27600-01X00-130	15-38	35174-01X00	23-3		41540-01X10 27-12
27640-01X00	4-17	35194-01X00	23-4		41762-01X00 27-2
		35382-48H00	37-6		41941-01X10 27-9
30000		35601-01X00	24-1		41970-01X00 27-3
		35602-01X00	24-4		41980-01X00 27-4
		35603-01X00	24-9		41992-01X00 27-8
		35604-01X00	24-12		42241-01X00 28-2
		35610-01X00	24-2		42310-01X00 28-1

PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.	PART NO.	FIG.NO.-REF.NO.
01550-0825A	49-7	08310-0010A	24-7	09139-01X06-006	11-5	09180-01X10	29-2-4	09283-01X20-013	15-4	09440-01X07-004	5-29
01550-0830A	11-21	08316-1006A	12-12	09139-06027	11-13	09180-01X10-002	6-3	09283-20031	46-3	09440-01X10	17-4
01550-0835A	41-7	08316-1006A	30-27	09139-06048	26-19	09180-01X15-015	5-38	09283-25111	48-17	09443-01X01	28-8
01550-0840A	11-27	08316-1006A	31-8	09140-01X00	5-24	09180-01X17-005	14-3	09289-01X05-004	7-17	09443-01X04	28-6
01550-0840A	43-5	08316-1006A	36-20	09140-01X00	14-15	09180-01X26	27-17	09320-01X00	11-19	09448-01X05	29-3
01550-0845A	11-17	08316-1006A	48-28	09148-05077	36-8	09180-01X33	33-2	09320-01X01	37-7	09448-01X15-001	4-21
01550-0875A	27-5	08316-1014A	19-4	09148-05077	37-2	09180-01X35	28-16	09320-01X02	36-2	09471-01X12-001	23-5
02112-0410B	35-14	08319-2106B	35-5-6	09148-05077	40-4	09180-06263	30-20	09320-01X04	47-8	09471-01X12-019	24-3
02112-0418A	16-22	08319-3106A	39-3	09150-06010	48-37	09181-01X14-004	16-17	09320-01X08-051	12-14	09471-01X12-019	24-11
02112-0612A	46-10	08319-3108A	3-18	09159-01X14-001	5-35	09181-01X16-001	7-18	09320-01X10-023	11-8	09471-01X12-019	24-14
02112-1520A	21-12	08319-3108A	11-8	09160-01X00	1-14	09181-01X28-001	5-30	09320-01X12-005	11-23	09471-01X12-019	24-14
02122-0512A	5-23	08319-3108A	27-6	09160-01X01	28-12	09181-01X28-004	5-32	09320-01X85	30-19	09471-12128	25-4
02142-0512A	10-1-7	08319-3108A	48-30	09160-01X02	41-9	09200-01X04	29-4	09320-01X85	36-6	09471-12216	23-6
02142-0514B	30-23	08319-3108A	48-34	09160-01X06	12-13	09200-08002	29-7-4	09320-09016	30-19	09482-00621	1-15
02142-0516A	10-1-6	08319-3110A	3-15	09160-01X06	36-4	09200-08002	29-8-4	09321-01X02	11-28	09491-01X20-040	9-1-7
03241-0512B	36-9	08319-3110A	28-4	09160-01X06-027	37-10	09205-03037	4-21	09321-01X02	37-13	09492-01X38-040	9-1-8
03241-0516A	36-15	08319-3110A	47-11	09160-01X08-017	11-10	09206-01X00	6-4	09329-10001	39-2	09800-01X25	36-17
03241-0516B	32-6	08319-3112A	42-14	09160-01X12-014	15-1-11	09206-01X08-002	4-16	09360-10061	45-4		
03241-0516B	37-12	08319-3114A	46-11	09160-01X12-021	7-19	09206-01X08-004	4-3	09380-01X15-002	17-8		
03541-0412A	23-5	08319-3114A	48-18	09160-01X14-006	17-1-2	09206-01X10-006	1-3	09380-01X16-001	15-42		
03541-0416A	22-5	08322-0106A	48-39	09160-01X16-001	17-1-5	09206-01X10-007	2-3	09380-01X18-002	15-14		
03541-0416A	26-7	08322-01087	1-5	09160-01X20-001	15-11	09206-01X10-007	3-2	09380-01X18-002	15-30		
03541-0512A	49-4	08331-3114A	16-16	09160-01X20-001	15-11	09229-01X01	27-15	09381-01X14-001	5-4		
03541-0516A	10-9	08331-31289	5-33	09160-05501	36-16	09241-01X08-001	15-32	09383-05001	13-4		
03541-0516A	22-6	08361-3506A	21-2	09160-06088	30-28	09247-01X00	4-13	09385-01X00	5-14-2-		
04111-2015A	48-38	09100-01X05-005	19-2	09160-06163	11-14	09247-01X12-105	3-11	09401-01X07-201	12-5		
04111-2020A	29-16	09103-01X05-001	7-4	09160-06164	11-6	09259-01X32-002	4-11	09401-01X10-410	9-3		
04111-2020A	29-23	09103-01X10	3-17	09160-08153	29-15	09261-01X00	16-9	09401-01X12-302	12-21		
04111-2020A	29-31	09103-01X10	27-7	09160-08153	29-22	09261-02001	13-5	09401-01X13-002	12-18		
04111-2525A	28-13	09103-01X12	27-16	09160-08153	29-30	09262-01X12-009	15-15	09401-01X15-202	10-7		
04221-01X00	16-7	09103-01X21	41-6	09160-16005	5-24	09262-01X12-014	7-2	09401-01X15-202	12-20		
07130-0512A	22-8	09103-08530	3-16	09161-01X06-004	11-15	09262-01X15-018	5-37	09401-01X82	31-3		
07130-0610A	15-37	09103-100V0	3-14	09161-10009	45-5	09262-01X17-007	15-34	09401-06101	9-4		
07130-0625A	19-3	09108-01X06-009	1-21	09164-01X00	5-9	09262-17023	15-16	09401-08414	9-2		
07130-0825A	11-2	09108-01X08-021	2-4	09164-01X10-001	7-20	09262-20069	15-33	09401-09101	31-4		
07130-0825A	22-12	09111-01X06-061	10-4	09167-01X00	15-10	09263-20041	46-2	09401-14301	10-1-5		
08133-62027	48-10	09111-01X06-061	36-13	09167-01X00	15-28	09264-30001	5-7	09401-15404	12-8		
08133-63017	42-7	09111-01X06-061	36-22	09168-01X26	31-6	09265-01X02	41-12	09401-17401	12-9		
08134-63027	48-9	09111-01X09	28-3	09168-06004	11-9	09267-01X25-L01	41-13	09401-20405	10-1-2		
08163-62030	14-8	09111-01X10	47-5	09168-06004	11-9	09280-01X09-011	8-11	09404-06429	26-9		
08211-01X00	5-34	09111-01X16	30-26	09168-06018	1-11	09280-01X13-010	4-14	09404-06433	26-6		
08211-01X00	14-6	09111-06106	30-22	09168-12002	3-12	09280-01X19-001	16-21	09407-10404	26-14		
08211-01X10	14-5	09116-06167	30-21	09180-01X00	11-6	09280-01X32-006	4-12	09407-12402	26-4		
08211-06141	3-21	09116-06167	33-3	09180-01X05	47-7	09280-10012	12-2	09407-12402	45-7		
08211-14321	46-7	09117-06037-XC0	16-10	09180-01X06-034	12-15	09280-18002	4-19	09420-04002	5-6		
08211-17241	15-13	09117-06037-XC0	16-13	09180-01X06-336	11-3-4	09280-24003	18-1-4	09420-04005	5-14		
08211-17241	15-13	09125-01X06-002	8-10	09180-01X07	27-20	09280-34004	1-17	09421-04001	5-13		
08211-17282	15-41	09128-06006	31-5	09180-01X08	36-5	09282-01X00	4-23	09440-01X00	5-18		
08310-00068	1-22	09136-01X06-003	21-14	09180-01X08-015	11-12	09283-01X14-003	16-19	09440-01X04-030	16-6		
08310-00068	28-11	09136-01X43	37-4	09180-01X10	29-5	09283-01X16-001	17-2	09440-01X07	48-39		

SUZUKI MOTOR DE COLOMBIA S.A