




Parts Manual

T35100(S)L Telescopic

S/N A8HD11001 & Above
S/N A8GW11001 & Above
S/N A8GT11001 & Above



GENERAL INFORMATION

Before ordering parts, ALWAYS provide dealer with your product model number and complete serial number information. Before ordering parts, verify correct part numbers and/or serial numbers with your dealer. When using the machine serial number, use the complete number.

Some serial number breaks are not available at time of printing. These are listed as & Bel or & Abv or - (thru)

The number shown in the quantity column in this manual is the number of parts needed for the illustration on the page. For some parts an “x” will be shown in the quantity column. This “x” indicates that the quantity to be used is “As Needed”.

When references L.H. (Left Hand) and R.H. (Right Hand) are used in this manual, it is done from the operator’s seat in the forward operating position.

When “See Illustration....” appears in the remarks column, refer to the contents page for the illustration title to find page number location.

Some of the illustrations and information found in this parts manual were supplied to Bobcat by machine component companies.

For additional information on the Bobcat website visit www.bobcat.com

ABBREVIATIONS

SALES = Order from Gwinner Sales Department	P/M = Parts Manual
NSS = Not Serviced Separately	S/L = Service Letter
NAP = Not Available as Parts	W/ = With
BTI = Bobcat Technical Information Bulletin	W/O= Without
O/M = Operation & Maintenance Manual	I.D. = Inside Diameter
S/M = Service Manual	O.D.= Outside Diameter
AHC = Advanced Hand Controls	“ = Inches
ACS = Advanced Control System	‘ = Feet
SJC = Selectable Joystick Controls	mm = Millimeters

TRANSLATION KITS & DECAL KITS

AR = Argentina (Spanish) BR = Brazil (Portugese) JP = Japanese
(Translation Kit includes Safety Manual, Operators Manual & Decal Kit)

DISPOSITION

(Found in the Remarks Column)

[A]	=	Use Up
[B]	=	Use Up on Other Applications
[C]	=	File PDR Report with Bobcat Parts Sales
[D]	=	Part Number Error

NOTE D'INFORMATION

Pour toute référence au numéro de série de l'engin, toujours donner le numéro complet.

Le chiffré apparaissant dans la colonne des quantités de ce manuel représentent le nombre de pièces nécessaires pour l'illustration reprise sur la page. Dans certains cas, on lira un "x" dans la colonne des quantités. Cet "x" indique que la quantité nécessaire est "selon besoin".

Pour toute référence vers la GAUCHE ou la DROITE dans ce manuel, considérer que la personne se trouve assise dans le siège de l'opérateur, en position de fonctionnement en marche avant.

Certaines illustrations et informations reprises dans ce manuel de pièces de rechange ont été fournies à Bobcat/Ingersoll-Rand par des fabricants de composants.

ABREVIATIONS & SYMBOLES

SALES	= Commander au Service Ventes à Bruxelles
NSS	= Pas vendu séparément
NAP	= Non disponible comme pièce de rechange
*	= Chapitre, page ou numéro de pièce modifié ou supplémentaire
BTI	= Bobcat Technical Information Bulletin : voir à la fin de la microfiche du modèle concerné ou la microfiche générale reprenant l'ensemble des "BTI".
was 6535403	= était avant 6535403
adj. (adjustment)	= réglage
Assembly	= ensemble
available W/Ref.	= disponible avec réf.
bulk/sold per foot	= en vrac/vendu par pied
does not include	= ne comprend pas
included with	= compris dans
I.D.	= D.I. (diamètre intérieur)
O.D.	= D.E. (diamètre extérieur)
not in kit	= pas en kit
W/ - WO/	= inclus/ - non inclus/
Qty	= quantité requise
see page/ref.	= voir page/réf.
used with ref/	= utilisé avec réf.
0,05 inch thickness	= 0,05 pouce d'épaisseur (un pouce = 25.4 mm)
weld on	= à souder

ALLGEMEINE INFORMATIONEN

Bei Angabe der Maschinen-Seriennummer stets die komplette Nummer angeben.

Bei der in der Mengenspalte (Anzahl) in diesem Handbuch angegebenen Zahl handelt es sich um die Anzahl von Teilen, die für die Abbildung auf der betreffenden Seite benötigt werden. Bei manchen Teilen in der Mengenspalte ist ein "x" angegeben. Dieses "x" weist darauf hin, dass sich die Anzahl der verwendeten Teile auf den "Bedarf" bezieht.

Bei Verwendung der Seitenangaben links und rechts in diesem Handbuch gelten diese für die Blickrichtung vom Fahrersitz aus, und zwar in Vorwärts-Betriebsrichtung.

Einige der in diesem Ersatzteilhandbuch aufgeführten Abbildungen und Informationen wurden der Bobcat/Ingersoll-Rand von den Herstellern von Maschinenbauteilen zur Verfügung gestellt.

ABKÜRZUNGEN UND SYMBOLE

SALES	= Bestellung bei der Verkaufsabteilung in Brüssel
NSS	= Nicht einzeln erhältlich
NAP	= Nicht als Ersatzteil erhältlich
*	= Geänderte oder hinzugefügte Abschnitte, Seiten oder Teilenummern
BTI	= Bobcat Technical Information Bulletin : Siehe am Ende der Mikrokarte des jeweiligen Modells oder der allgemeinen Mikrokarte der BTI.
was 6535403	= War 6535403
adj.	= Einstellung
Assembly	= Baugruppe
available W/Ref.	= erhältlich mit der Referenz
bulk/sold per foot	= Mengenabnahme / Verkauf pro Fuss
does not include	= beinhaltet nicht
included with	= enthalten in
I.D.	= Innendurchmesser
O.D.	= Aussendurchmesser
not in kit	= nicht in Bausatz
W/ - WO/	= mit/ - ohne/
Qty	= Anzahl
see page/ref.	= Siehe Seite / Referenz
used with ref.	= verwendet mit Referenz
0.05 inch thickness	= Dicke : 0.05 Zoll (ein Zoll = 25.4 mm)
weld on	= anschweißen

INFORMAZIONI GENERALI

Quando si usa il numero di serie della macchina usare il numero completo.

Il numero mostrato nella colonna della quantità di questo manuale corrisponde al numero di componenti necessari per l'illustrazione della pagina. Per alcuni componenti appare "X" nella colonna delle quantità. Questa "X" indica che la quantità da usare è "come necessario".

See in questo manuale si fa riferimento alla parte destra o sinistra, si intende dal sedile dell'operatore nella posizione in avanti di funzionamento.

Alcune delle illustrazioni e informazioni trovate in questo manuale di componenti sono state fornite alla Bobcat/Ingersoll-Rand da società di componenti di macchine.

SIMBOLI E ABBREVIAZIONI

SALES	= Ordinare al servizio vendite di Bruxelles
NSS	= Non vendute separatamente
NAP	= Non disponibile come componente
*	= Sezioni, pagine o numeri di componente cambiati o aggiunti
BTI	= (Bobcat Technical information) Ved. al termine del microfiche del modello relativo oppure microfiche generale
was 6535403	= era 6535403
adj. (adjustment)	= regol. (regolazione)
Assembly	= Complessivo
available W/Ref.	= disponibile con rif.
bulk/sold per foot	= alla rinfusa/venduto al piede
does not include	= non comprende
Included with	= compreso con
I.D.	= d. i.
O.D.	= d. e.
not in kit	= non fa parte del kit
W/ - WO/	= con - senza
Qty	= Qtà
see page/ref	= ved. pagina/rif.
used with ref.	= usato con il rif.
0,05 inch thickness	= spessore 0,05 pollici (un pollice = 25,4 mm)
weld on	= a saldare

INFORMACION GENERAL

Al utilizar el número de serie de la máquina, debe emplearse el número completo.

El número que figura en la columna de “Unidades” en este manual es el número de piezas que se necesitan para la ilustración que consta en la página. En algunas piezas aparece una “x” en la columna de “Unidades”. Esta “x” indica que las unidades a utilizar son “según sea necesario”.

Cuando se empleen las referencias izq. y dcha., éstas se entienden mirando desde el asiento del conductor, en posición de marcha adelante.

Algunas de las ilustraciones y la información que figuran en este manual de piezas han sido facilitadas a Bobcat/Ingersoll-Rand por empresas de componentes de máquinas.

ABREVIATURAS Y SIMBOLOS

VENTAS	= Pedido al Departamento de Ventas de Bruselas
NSS	= No se vende por separado
NAP	= No disponible como pieza de repuesto
*	= Secciones, páginas o referencias modificadas o añadidas
BTI	= (Bobcat Technical Information) Ver al final de la microficha del modelo afectado o en la microficha general “Boletín de Información Técnica Bobcat”.
was 6535403	= era anteriormente el 6535403
adj. (adjustment)	= ajuste
assembly	= conjunto
available W/Ref.	= disponible con la ref.
bulk/sold per foot	= a granel/vendido por pies
does not include	= no incluye
included with	= incluido en
I.D.	= diámetro interior
O.D.	= diámetro exterior
not in kit	= no en el kit
W/ - WO/	= con/ - sin
Qty	= Unidades
see page /ref.	= ver página/ref.
used with ref.	= empleado con la ref.
0,05 inch thickness	= 0,05 pulgadas de espesor (1 pulgada = 25,4 mm)
weld on	= debe ser soldado

ALGEMENE INFORMATIE

Als u het serienummer van de machine gebruikt, geef dan het gehele serienummer.

Het cijfer dat voorkomt in de kolom "Aantal", in deze handleiding, is het aantal onderdelen dat nodig is van de illustratie op de pagina. Voor sommige onderdelen staat er een "x" in de kolom "Aantal". Deze "x" betekent dat er een aantal "zoals nodig" vereist is.


Wanneer er in deze handleiding naar "links" en naar "rechts" gerefereerd wordt, moet dit verstaan worden voor een bestuurder die in de bestuurdersstoel zit in de voorwaartse bedrijfsstand.

Sommige van de illustraties en informatie in deze onderdelen-handleiding werden door firma's van machine-componenten geleverd aan Bobcat/Ingersoll-Rand.

AFKORTINGEN EN SYMBOLEN

SALES	= Bestellen bij de Verkoopafdeling te Brussel
NSS	= Niet afzonderlijk te verkrijgen
NAP	= Niet beschikbaar als onderdeel
*	= Gewijzigde of toegevoegde paragrafen, pagina's of onderdeelnummers
BTI	= Bobcat Technical Information Bulletin : Zie einde van de microfiche van het desbetreffende model of einde van de algemene microfiche die het geheel van alle "BTI" herneemt.
was 6535403	= was vroeger 6535403
adj. (adjustment)	= afstelling
Assembly	= geheel
available W/Ref.	= beschikbaar met ref.
bulk/sold per foot	= bulk/aan de meter verkocht
does not include	= bevat niet
includes with	= is bevat in
I.D.	= ϕ inw. (inwendige diameter)
O.D.	= ϕ uitw. (uitwendige diameter)
not in kit	= niet in de kit
W/ - WO/	= met/ - zonder/
Qty	= vereiste aantal
see page/ref.	= zie pagina/ref.
used with ref/	= gebruikt met ref.
0,05 inch thickness	= 0.05 inch dik (een inch = 25.4 mm)
weld on	= te lassen

**Use only Bobcat belts and hoses
to maintain maximum service life.**



Available from Bobcat Parts.



CONTENTS

MAIN FRAME

CHASSIS	3
BALLAST	7
FUEL TANK INSTALLATION	9
ENGINE COVER	11
ENGINE BASKET	13
CAB & FIXATIONS	15
CAB ASSY	17
CAB ASSY II	21
SEAT & SUSPENSION	25
HEATING/ VENTILATION INSTALLATION	27
HEATING/VENTILATION FAN ASSY	29
PEDALS INSTALLATION	31
STEERING COLUMN INSTALLATION	33
COWLING INSTALLATION	35
CONTROL PANEL SWITCHES	37
DOOR ASSY	41
REAR WINDOW INSTALLATION	47
WIPER INSTALLATION	49
PARKING BRAKE LEVER	51
FIXED BOOM ASSY - T35100, T35100L	53
FIXED BOOM ASSY - T35100SL	57
INTERMEDIATE BOOM - T35100, T35100L	61
INTERMEDIATE BOOM - T35100SL	63
END BOOM ASSY - T35100, T35100L	65
END BOOM ASSY - T35100SL	69
MANUAL QUICK ATTACH LOCK	73

DRIVE SYSTEM

AXLE INSTALLATION	75
CARDAN SHAFT	77
HUB REDUCTION - FRONT AXLE	79
REDUCER BOX - FRONT AXLE	81
HOUSING - FRONT AXLE	85
DIFFERENTIAL - FRONT AXLE	87
STEERING - FRONT AXLE	89
BRAKES - FRONT AXLE	93
HUB REDUCTION - REAR AXLE	95
HOUSING - REAR AXLE	97
DIFFERENTIAL - REAR AXLE	99
STEERING - REAR AXLE	103

HYDRAULIC SYSTEM

BOOM HYDRAULIC SUPPLY FROM CONTROL VALVE	107
BOOM HYDRAULIC SUPPLY	111
LIFT & COMPENSATION CYLINDER INSTALLATION	113
TELESCOPE CYLINDER INSTALLATION	115
STEERING HOSES & FITTINGS (WITHOUT DAMPER)	117
STEERING HOSES & FITTINGS (WITH DAMPER)	119
JOYSTICK INSTALLATION (WITH AMA)	121

AMA - INSTALLATION	123
SERVICE BRAKE HYDRAULIC INSTALLATION	125
PARKING BRAKE HYDRAULIC INSTALLATION	129
PARKING BRAKE HYDRAULIC INSTALLATION (ACCUMULATOR)	131
QUICK ATTACH INSTALLATION	133
HYDRAULIC TANK INSTALLATION	135
FRAME LEVEL INSTALLATION	139
STABILIZERS INSTALLATION	141
STABILIZER SELECTOR VALVES	143
LIFT CYLINDER	145
COMPENSATION CYLINDER	147
TELESCOPE CYLINDER	149
TILT CYLINDER	151
QUICK ATTACH CYLINDER	153
FRAME LEVEL CYLINDER	155
STABILIZER CYLINDER	157
HYDRAULIC MOTOR	159
HYDRAULIC PUMP INSTALLATION	161
HYDRAULIC PUMP ASSY	163
HYDRAULIC CONTROL VALVE FIXATION	165
HYDRAULIC CONTROL VALVE INSTALLATION	167
HYDRAULIC CONTROL VALVE:IN- AND OUTLET	173
HYDRAULIC CONTROL VALVE LIFT SECTION	175
HYDRAULIC CONTROL VALVE TILT SECTION	177
HYDRAULIC CONTROL VALVE TELESCOPE SECTION	179
HYDRAULIC CONTROL VALVE AUXILIARY HYDRAULICS SECTION	181
HYDROSTATIC SYSTEM	
HYDROSTATIC HOSES AND FITTINGS	183
HYDROSTATIC PUMP ASSY	185
HYDROSTATIC MOTOR ASSY	191
ELECTRICAL SYSTEM	
ELECTRICAL CIRCUIT CHASSIS	195
ELECTRICAL CIRCUIT CAB - S/N 11001-12000	199
ELECTRICAL CIRCUIT CAB - S/N 12001 & Above	201
ELECTRICAL CIRCUIT ENGINE	203
VENTILATION REVERSE ELECTRICAL	207
JOYSTICK	209
JOYSTICK/SUSMIC INSTALLATION - S/N 11001 - 12000	211
JOYSTICK / SUSMIC INSTALLATION - S/N 12001 & Above	213
ELECTRIC CIRCUIT SECURITY	215
SECURITY OPTION STABILIZERS/TELESCOPING	217
STABILIZERS 25° LOCKING OPTION	219
ELECTRICAL CIRCUIT ARM	221
ELECTRICAL BOX AV	223
POWER UNIT	
ENGINE INSTALLATION	225
EXHAUST SYSTEM	229
COOLING SYSTEM INSTALLATION	231
RADIATOR	235
COOLING FAN CIRCUIT - (W/O Optional Reverse - W/O Frame Leveling)	237
COOLING FAN CIRCUIT - (W/O Optional Reverse - W/ Frame Leveling)	239
COOLING FAN CIRCUIT - (W/ Optional Reverse - W/O Frame Leveling)	241
COOLING FAN CIRCUIT - (W/ Optional Reverse - W/ Frame Leveling)	243

CYLINDER BLOCK	245
CRANKSHAFT - PISTONS	247
FLYWHEEL AND DRIVE PULLEY	249
CYLINDER HEAD INSTALLATION	251
CYLINDER HEAD ASSY	253
ROCKER SHAFT	255
TIMING GEAR	257
OIL SUMP - OIL PUMP	259
FUEL INJECTION EQUIPMENT	261
FUEL FEEDING	265
CYLINDER HEAD COVER	267
OIL COOLER AND FILTER	269
WATER PUMP AND THERMOSTAT	271
TURBOCHARGER	273
ALTERNATOR	275
FLYWHEEL HOUSING AND STARTER	277
ENGINE GASKET SETS	279

ACCESSORIES & OPTIONS

ACCELERATOR PEDAL STOP KIT	281
ADJUSTABLE HOOK	283
AIR CONDITIONING INSTALLATION	285
AIR PRE-CLEANER OPTION 1	291
AIR PRE-CLEANER OPTION 2	293
AIR SUSPENDED SEAT	295
AUSTRALIAN VERSION	297
BACKUP ALARM	299
BALES PIKES AND PALLET FORK FRAME	301
BOBCAT DECALS - W/ Stabilizer	303
BOBCAT DECALS - W/O Stabilizer	305
BOOM SUPPORT KIT	307
BUCKET 1500L REINFORCEMENT KIT	309
BUCKET 2000L REINFORCEMENT KIT	311
BUCKET 2500L REINFORCEMENT KIT	313
CONCRETE BUCKET	315
DAMPER KIT	317
DUNLOP 400/70-R20 150B WHEELS	319
DUNLOP 400/80-R24 156B WHEELS	321
DUNLOP 405/70-R20 SPT9 WHEELS	323
ELECTRIC KIT FOR BROOM	325
FLOATING PALLET FORKS	327
FUEL PRE-FILTER KIT	329
HOOK	331
HYDRAULIC TANK FILLING KIT	333
JIG + HOOK	335
LIFT CYLINDER ACCUMULATOR KIT	337
LOUDSPEAKER PREDISPOSAL OPTION	339
MATRICULATION PLATE OPTION	341
MUDGUARD 20"	343
MUDGUARD 24"	345
REAR HYDRAULIC FUNCTION	347
REAR HYDRAULIC HOOK	351
REAR VIEW MIRROR	355
RIGID FORKS HOLDER - W/ Back	357
RIGID FORKS HOLDER - W/O Back	359

TITAN 400/70-R20 WHEELS	361
TOOL ADAPTOR KIT	363
TOOTHED BUCKET	365
TOOTHLESS BUCKETS	367
TOW HITCH	369
TOW VALVE INSTALLATION	371
TRAILER BRAKE	373
TRAILER BRAKE ITALY VERSION	375
TRAILER PLUG	377
ULPYO HOOK	379
VALVE BRAKING SWITCH OPTION	381
WHEEL WEDGE OPTION	383
WINDSHIELD PROTECTION GRILL	385
WORKING LIGHT	389
2ND HYDRAULIC FUNCTION ON BOOM	391


T35100(S)(L) Telescopic Handlers

S/N A8HD11001 & Above

S/N A8GW11001 & Above

S/N A8GT11001 & Above

CHASSIS




SPC001107

CHASSIS

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6917761	CHASSIS			1
2	77380.4	BOOM PIVOT BUSHING	Was 6909027 -		2
3	01775.6	NIPPLE, GREASE	straight		2
4	70811.5	BUSH			2
5	6909439	BUSH			2
6	77261.6	BUSH			2
7	90281.7	BUSH			1
8	80919.4	SEAL			10
9	79123.6	PLATE			1
10	79129.3	SEAL			1
11	13415.5	WASHER			2
12	79124.4	NUT			2
13	010338-02X	SCREW			2
14	6909712	PLUG			2
15	6908248	PLATE			1
16	01719.4	WASHER			2
17	01604.8	SCREW			2
18	57702.3	PLUG			2
19	79288.7	RUBBER MOUNTING			2
20		PLATE, SERIAL NO.	NAP		1
21	6916450	PIN			4
22	6915265	SUPPORT			1
23	01607.1	SCREW			6
24	000350-21R	WASHER			2
25	100345-09A	NUT			6
26	6915264	SUPPORT			1
27	6922760	REAR VIEW MIRROR	Was 100432-51C -		1
28	65397.2	SCREW			1
29	100345-09A	NUT			1
30	6909147	SPINDLE			1
31	6915406	HORIZONTALITY INDICATOR			1

CHASSIS

Recurrence of previous drawing




SPC001107

CHASSIS

[illegible]

BALLAST




SPC001144

BALLAST

[illegible]


FUEL TANK INSTALLATION



SPC001206

[illegible]

ENGINE COVER




SPC001178

ENGINE COVER

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	000324-65N	SCREW			8
2	000350-02V	WASHER			6
3	000350-03W	WASHER			4
4	000350-20Q	WASHER			2
5	01596.6	SCREW			2
6	01597.4	SCREW			6
7	01681.6	NUT			1
8	01682.4	NUT			4
9	01718.6	WASHER			4
10	51851.4	NUT			7
11	71825.4	SCREW			1
12	83757.5	CYLINDER			1
13	89516.9	WASHER			4
14	98053.2	PLATE, FRONT	ENGINE BASKET		1
15	100345-09A	NUT			4
16	6908165	PLATE, REAR	ENGINE BASKET		1
17	6909020	PLATE			2
18	6909609	LOCK, ENGINE COVER			1
19	6911249	PLATE			1
20	6911253	SILL PLATE			1
21	6912269	INSULATION			2
22	6912485	HINGE			2
23	6913028	COVER, ENGINE			1
24	6914748	SEAL			2
25	6915513	SUPPORT			1
26	6916609	COVER			1
27	6917964	SEAL	Was 6914678 -		1

ENGINE BASKET




SPC001176

ENGINE BASKET

*

CAB & FIXATIONS




SPC001187

CAB & FIXATIONS

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1		CAB			1
2	6925003	LIGHT, BEACON ROTATING	Option ; Was 78817.4 -		1
3	6917690	WASHER			1
4	01606.3	SCREW			4
5	79872.8	SPACER			1
6	78867.9	SUPPORT			1
7	01701.2	WASHER			1
8	78856.2	PLATE			1
9	100345-16H	NUT			4
10	01547.9	SCREW			2
11	100338-07M	SCREW			1
12	78021.3	SHOCK ABSORBER			3
13	10944.7	SCREW			4
14	79868.6	SHIM			1
15	100345-09A	NUT			12
16	90245.2	SCREW			2
17	6917690	WASHER			2
18	78863.8	SUPPORT			1
19		INDEX CARD			1
20	79864.5	SCREW			2
21	92303.7	BRACKET	T35100(S)L		1
22	94574.1	WASHER	T35100(S)L		3
23	15354.4	SCREW	T35100(S)L		2
24	100416-32S	INCLINOMETER	T35100(S)L		1
25	01657.6	SCREW	T35100(S)L		3
26	100345-04U	NUT	T35100(S)L		5
27	01549.5	SCREW			2
28	100345-15G	NUT			1
29	13778.6	WASHER			2
30	01607.1	SCREW			4
31	000350-06A	WASHER			2

CAB ASSY




SPC001208

CAB ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6963094	FRAME			1
2	6908788	WINDOW, PANEL	Right side		1
3	6908786	WINDOW, ROOF			1
4	6910908	INSULATION			1
5	6971665	SUPPORT			2
6	01696.4	WASHER			4
7	01590.9	SCREW			4
8	63332.1	CAP			4
9	6910542	STOP, RUBBER			2
10	6910932	NUT			2
11	96074.0	COVER			1
12	29272.2	WASHER			3
13	01590.9	SCREW			3
14		CONNECTION	NSS - Order Ref. 15		1
15	79903.1	MIRROR	W/Ref. 14		1
16	6909997	SCREW			2
17	6915508	NON-SKID	Was 6564833 -		3
18	63349.5	HANDLE			2
19	01591.7	SCREW			4
20	94574.1	WASHER			4
21	6908790	WINDSHIELD			1
22		SEAL	NAP - 143.70" (3650 mm) long - Order Ref. 37		1
23	6915519	FLOORMAT, INSULATION	Was 97089.7 -		1
24	97088.9	FLOORMAT, UPPER			1
25	78818.2	CONNECTION			1
26	78819.0	PLUG, GYROLIGHT			1
27	6910931	PLUG			1
28	6809599	PLATE			1
29	6909959	RIVET			2
30	6910930	GUIDE			1
31	6910933	SPACER			1

CAB ASSY

Recurrence of previous drawing




SPC001208

CAB ASSY

*

CAB ASSY II




SPC001010

CAB ASSY II

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6910908	INSULATION			1
2	000350-21R	WASHER			5
3	6914788	SEAL, LOWER PART			1
4	6910503	BOX, FILTER			1
5	01696.4	WASHER			4
6	01590.9	SCREW			4
7	63332.1	CAP			4
* 8	6910504	SEAL	39.37" (1000 mm) long - sold per foot		x
9	6910502	FILTER, CAB			2
10	6910929	GRILLE, INTERNAL			2
11	6910505	SCREW			4
12	61378.6	WASHER			4
13	01664.2	NUT			4
14	6914787	SEAL, UPPER PART			1
15	86167.4	NUT			1
16	6908789	WINDOW, LH			1
17	63332.1	CAP			4
18	01666.7	NUT			4
19	01717.8	WASHER			4
20	6910552	LOCK			1
21	79902.3	SUNSHADE			1
22	6910697	SCREW			1
23	6910948	FIXATION, CATCH			1
24	6910949	WASHER			1
25	6910947	PROTECTOR, CATCH			1
26	6910946	CATCH			1
27	97964.1	RIVET			2
28	6909961	PLATE			1
29	6910999	SCREW			4
30	78816.6	WORKLIGHT, REAR	Was 6909970 -		1
31	78815.8	WORKLIGHT, FRONT	Was 6909971 -		2

CAB ASSY II

Recurrence of previous drawing




SPC001010

CAB ASSY II	
-------------	--

[illegible]

SEAT & SUSPENSION




SPC001011

SEAT & SUSPENSION

[illegible]


HEATING/ VENTILATION INSTALLATION



SPC001012

[illegible]

HEATING/VENTILATION FAN ASSY




SPC001013

HEATING/VENTILATION FAN ASSY

[illegible]

PEDALS INSTALLATION




SPC001198

PEDALS INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	01124.7	SPRING			1
2	01596.6	SCREW			8
3	01597.4	SCREW			1
4	01605.5	SCREW			6
5	01608.9	SCREW			1
6	01669.1	NUT			1
7	01697.2	WASHER			8
8	01739.2	PIN			1
9	01754.1	PIN			1
10	51851.4	NUT			2
11	59893.8	PAD, PEDAL			1
12	62185.4	SCREW			1
13	77919.9	BRACKET			2
14	98240.5	CABLE, THROTTLE			1
15	100345-09A	NUT			7
16	6908478	PEDAL, BRAKE	Was 6917795 -		1
17	6908479	SHAFT, PEDAL			1
18	6909977	PLATE			1
19	6910649	ABUTMENT, PEDAL			1
20	6914781	WIRE			1
21	6917140	WASHER			1
22	6917796	PEDAL, THROTTLE			1
23	6924734	SUPPORT, PEDAL	Was 6917799 -		1
24	6917802	BEARING			2
25	6909383	SWITCH, INCHING (DETECTOR)			1
26	6918227	SWITCH, SERVICE BRAKE			1
27	100345-05V	NUT			2
28	6910952	WASHER			2
29	01478.7	SCREW			2

STEERING COLUMN INSTALLATION




SPC001015

STEERING COLUMN INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	94018.9	CAP, STEERING WHEEL			1
2	6908477	STEERING WHEEL			1
3	6909993	SCREW			2
4	98241.3	LEVER ASSY	Travel direction		1
5	98242.9	LEVER ASSY	Direction signal		1
6	6908476	STEERING COLUMN			1
7	97502.9	KNOB	Steering column adjustment		1
8	63359.4	SCREW			4
9	51851.4	NUT			4
10	97210.9	PIN			2
11	51851.4	NUT			2
12	6915747	SUPPORT	Was 97503.7 -		1
13	6909935	SEAL			1
14	01697.2	WASHER			2
15	01596.6	SCREW			2
16	01596.6	SCREW			4
17	01697.2	WASHER			4
18	6909977	PLATE			1
19	01596.6	SCREW			4
20	01697.2	WASHER			4
21	01697.2	WASHER			4
22	97501.1	HANDLE	Steering column adjustment		1
23	01597.4	SCREW			2
24	01697.2	WASHER			2
25	6910649	ABUTMENT, PEDAL			1
26	6909993	SCREW			2

COWLING INSTALLATION





SPC001016


COWLING INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6910882	COWLING, INSTRUMENT PANEL			1
2	79864.5	SCREW			3
3	6909903	CLIP			10
4	6909930	SEAL			1
5	6910883	COWLING, STEERING COLUMN			1
6	6909903	CLIP			9
7	6910505	SCREW			9
8	6909973	BELLOW, STEERING COLUMN			1
9	6909903	CLIP			2
10	6909995	SCREW			2
11	6914561	SUPPORT, LOWER	Was 6909974 -		1
12	05698.6	WASHER			2
13	01590.9	SCREW			2
14	6912458	COWLING, JOYSTICK			1
15	6909931	SEAL			1
16	6909933	SEAL			1
17	6909903	CLIP			5
18	6909904	COVER			1
19	100331-01U	SCREW			1
20	6917000	COWLING, SIDE FUSE PANEL	Was 6910881 -		1
21	6909932	SEAL			1
22	6910505	SCREW			2
23	6909934	SEAL			1
24	6918139	COWLING, TOP FUSE PANEL	Was 6910879 -		1
25	97098.8	PUSH BUTTON	Was 6909910 -		2
26	6916963	ADHESIVE			1
27	97096.2	LIGHTER, CIGARETTE			1
28	6914086	NUT			1

CONTROL PANEL SWITCHES



WITHOUT FRAME LEVELING





SPC001212

CONTROL PANEL SWITCHES


Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	96080.7	PLATE, CONTROL PANEL L.H.			1
2	6914170	PLATE, CONTROL PANEL R.H.			1
3	6910505	SCREW			10
4	6915871	INSTRUMENT PANEL			1
5	80220.7	BEZEL	W/Ref. 6-7		2
6	96591.3	SWITCH, BEACON LIGHT			1
7	96590.5	SWITCH, HAZARD LIGHTS			1
8	6926588	VALVE, HEATING CONTROL	Was 96609.3 -		1
9	96608.5	SWITCH, FAN SPEED			1
10	80220.7	BEZEL	W/Ref. 12, 15-16, 19-20, 22, 25, 28		10
11	80221.5	BEZEL	W/Ref. 13-14, 17-19, 21, 23-24, 26-28		10
12	96595.4	INDICATOR, TRAILER TURN			1
13	96594.7	INDICATOR, STEERING MODE			1
14	96593.9	SWITCH, STEERING MODE			1
15	96592.1	SWITCH, LEVER			1
16	96600.2	SWITCH, HEAD LAMP			1
17	6913243	SWITCH, BLUE LIGHTS	Was 96601.0 -		1
18	96597.0	SWITCH, REAR FOG LIGHT			1
19	65784.1	PLUG			5
20	96602.8	SWITCH, REAR WIPER/WASHER			1
21	96603.6	SWITCH, ROOF WIPER	Option		1
22	97519.3	SWITCH, TRANSMISSION MODE			1
23	6911728	SWITCH, LOCKING			1
24	6910895	SWITCH, AUX. HYDR.			1
25	6910560	LEFT STABILIZER SWITCH			1
25	65784.1	PLUG	T35100(L)		1
26	6910558	LOCKING STABILIZER SWITCH			1
26	65784.1	PLUG	T35100(L)		1
27	6910561	RIGHT STABILIZER SWITCH			1
27	65784.1	PLUG	T35100(L)		1
28	55438.6	SWITCH, IGNITION	W/Ref. 28-29		1

CONTROL PANEL SWITCHES

Recurrence of previous drawing




WITHOUT FRAME LEVELING



SPC001212

[illegible]

DOOR ASSY





SPC001204

DOOR ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6910733	UPPER DOOR ASSY	W/Ref. 2-20 ; Was 6909925 -		1
2	6910735	UPPER DOOR AND WINDOW	W/Ref. 3-4		1
3	6910734	DOOR, UPPER	Was 6910509 -		1
4	6908792	WINDOW, UPPER PART DOOR			1
5	6910989	SPACER			2
6	01606.3	SCREW			2
7	6910991	WASHER			2
8	63334.7	NUT, CAP			2
9	6910990	WASHER			2
10	6910547	HOOK			1
11	6910984	SPACER			1
12	6910539	HANDLE			1
13	32397.2	SCREW			2
14	01595.8	SCREW			1
15	01718.6	WASHER			1
16	6910988	WASHER			1
17	79297.8	CAP			1
18	6917353	HINGE ASSY	W/Ref. 19-20 ; Was 6910554 - A		2
19		WASHER	NAP		2
20		NIPPLE, GREASE	NAP		2
21	6910736	LOWER DOOR ASSY	W/Ref. 22-58 ; Was 6909923 -		1
22	6910738	LOWER DOOR AND WINDOW	W/Ref. 23-24		1
23	6910737	DOOR, LOWER	Was 6910510 -		1
24	6908791	WINDOW, LOWER PART DOOR			1
25	6911000	SEAL			1
26	6911001	SEAL			1
27	01606.3	SCREW			2
28	6910991	WASHER			2
29	6910990	WASHER			2
30	6910989	SPACER			2
* 30	6914786	SPACER			2

DOOR ASSY

Recurrence of previous drawing




SPC001204

DOOR ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
31	63334.7	NUT, CAP			2
32	6918340	HANDLE			1
33	01719.4	WASHER			2
34	01603.0	SCREW			2
35	97360.2	STRAP, DOOR			1
36	01579.2	SCREW			2
37	51851.4	NUT			2
38	63333.9	NUT, CAP			4
39	6910994	LOCK, COVER			1
40	29272.2	WASHER			3
41	6910996	SCREW			3
42	6914789	SEAL			1
43	6914942	STOP, CABLE			1
44	6918341	LOCK			1
45	6910997	SCREW			2
46	01697.2	WASHER			2
47	01668.3	NUT			2
48	6918342	CABLE			1
49	6918343	HANDLE, WITH KEY			1
50	01696.4	WASHER			4
51	01575.0	SCREW			4
52	6910993	HOOK			1
53	01717.8	WASHER			2
54	01590.9	SCREW			2
55	63332.1	CAP	Was 6910992 - B,D		1
56	01666.7	NUT			1
57	01590.9	SCREW			1
58	6917353	HINGE ASSY	W/Ref. 59-60 ; Was 6910554 - A		2
59		HOSE	NAP		2
60		NIPPLE, GREASE	NAP		2
61	64509.3	GLUE			1

DOOR ASSY

Recurrence of previous drawing




SPC001204

DOOR ASSY

[illegible]


REAR WINDOW INSTALLATION



SPC001109

[illegible]

WIPER INSTALLATION




SPC001020

WIPER INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	97196.0	RESERVOIR, WINDSHIELD	W/Ref. 2		1
* 2	6925355	CAP			1
3	6910505	SCREW			2
4	01717.8	WASHER			2
5	6909903	CLIP			2
6	75926.6	ADAPTER			3
7	75898.7	ARM, WIPER WINDSHIELD			1
8	75895.3	BLADE, FRONT WIPER			1
9	6916061	MOTOR, WINDSHIELD WIPER	Was 75920.9 -		1
10	97212.5	HOSE			1
11	63848.6	UNION, T			1
12	6910982	WASHER, PIPE			2
13	6910983	TUBELINE			1
14	97217.4	JET			1
15	6915535	MOTOR, ROOF WIPER	Option ; Was 63856.9 -		1
16	75896.1	BLADE, WIPER	Option ; Was 6911713 -		1
17	6911006	ROOF WIPER ARM	Option ; Was 6911712 -		1
18	63332.1	CAP			2
19	01596.6	SCREW	Without roof windscreen wiper		3
20	6910976	WASHER	Without roof windscreen wiper		2
21	6909964	WASHER	Without roof windscreen wiper		2
22	000350-20Q	WASHER	Without roof windscreen wiper		2
23	6909963	WASHER	Without roof windscreen wiper		2
24	01668.3	NUT	Without roof windscreen wiper		3
25	63333.9	NUT, CAP	Without roof windscreen wiper		6
26	6910981	TUBELINE			1

PARKING BRAKE LEVER




SPC001127

PARKING BRAKE LEVER

[illegible]

FIXED BOOM ASSY

T35100, T35100L



SPC001137

FIXED BOOM ASSY


T35100, T35100L

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6917248	OUTER BOOM			1
2	01775.6	NIPPLE, GREASE	straight		2
3	77380.4	BOOM PIVOT BUSHING			2
4	89328.9	LOCATING PIN			1
5	77430.7	WASHER			2
6	44001.6	SCREW			2
7	72883.2	BUSH			2
8	6909153	SPINDLE			1
9	000329-42G	SCREW	Was 13399.1 -		1
10	6909150	SPINDLE			1
11	77261.6	BUSH			2
12	70287.8	WASHER			2
13	70288.6	CLIP			2
14	01775.6	NIPPLE, GREASE	straight		2
15	6909222	SHOE			2
16	01634.5	SCREW			4
17	01595.8	SCREW			8
18	01697.2	WASHER			8
19	98344.5	SHOE	Thickness 11mm - 11mm		2
19	98343.7	SHOE	Thickness 12mm - 12mm		2
19	98342.9	SHOE	Thickness 13mm - 13mm		4
19	98341.1	SHOE	Thickness 14mm - 14mm		2
19	98340.3	SHOE	Thickness 15mm - 15mm		2
20	01595.8	SCREW			6
21	01697.2	WASHER			6
22	95501.3	SHOE			2
23	01775.6	NIPPLE, GREASE	straight		2
24	6909225	CHAIN			1
25	95555.9	RETAINING			1
26	95613.6	SPINDLE			1
27	38632.6	PIN			2

FIXED BOOM ASSY

T35100, T35100L

Recurrence of previous drawing




SPC001137

[illegible]

FIXED BOOM ASSY

T35100SL



SPC001038

FIXED BOOM ASSY


T35100SL

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6908903	OUTER BOOM			1
2	01775.6	NIPPLE, GREASE	straight		2
3	77380.4	BOOM PIVOT BUSHING			2
4	89328.9	LOCATING PIN			1
5	77430.7	WASHER			2
6	44001.6	SCREW			2
7	72883.2	BUSH			2
8	6909153	SPINDLE			1
9	000329-42G	SCREW	Was 13399.1 -		1
10	6909150	SPINDLE			1
11	77261.6	BUSH			2
12	70287.8	WASHER			2
13	70288.6	CLIP			2
14	01775.6	NIPPLE, GREASE	straight		2
15	6909222	SHOE			2
16	01634.5	SCREW			4
17	01595.8	SCREW			8
18	01697.2	WASHER			8
19	98344.5	SHOE	Thickness 11mm - 11mm		2
19	98343.7	SHOE	Thickness 12mm - 12mm		2
19	98342.9	SHOE	Thickness 13mm - 13mm		4
19	98341.1	SHOE	Thickness 14mm - 14mm		2
19	98340.3	SHOE	Thickness 15mm - 15mm		2
20	01595.8	SCREW			6
21	01697.2	WASHER			6
22	95501.3	SHOE			2
23	01775.6	NIPPLE, GREASE	straight		2
24	6909225	CHAIN			1
25	95555.9	RETAINING			1
26	95613.6	SPINDLE			1
27	38632.6	PIN			2

FIXED BOOM ASSY

T35100SL

Recurrence of previous drawing




SPC001038

[illegible]

INTERMEDIATE BOOM

T35100, T35100L




SPC001092

[illegible]

INTERMEDIATE BOOM

T35100SL



SPC001138


INTERMEDIATE BOOM

T35100SL

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6915224	INTERMEDIATE BOOM			1
2	98300.7	SHIM	Thickness 1mm - 1mm		4
2	98301.5	SHIM	Thickness 2mm - 2mm		4
2	98302.3	SHIM	Thickness 3mm - 3mm		4
3	95501.3	SHOE			8
4	01775.6	NIPPLE, GREASE	straight		2
6	98344.5	SHOE	Thickness 11mm - 11mm		3
6	98343.7	SHOE	Thickness 12mm - 12mm		3
6	98342.9	SHOE	Thickness 13mm - 13mm		6
6	98341.1	SHOE	Thickness 14mm - 14mm		3
6	98340.3	SHOE	Thickness 15mm - 15mm		3
7	01595.8	SCREW			12
8	01697.2	WASHER			16
9	01596.6	SCREW			4
10	01604.8	SCREW			4
11	6915193	PLATE			2
12	6915214	SPINDLE			1
13	95541.9	BUSH			2
14	6915195	PULLEY (DOUBLE)			1
15	95502.1	SCREW			12
16	98303.1	SCREW			4
17	6915215	SPINDLE			1
18	95539.3	PULLEY			1
19	95541.9	BUSH			2

END BOOM ASSY

T35100, T35100L



SPC001040

END BOOM ASSY


T35100, T35100L

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6917252	INNER BOOM			1
2	74863.2	BUSH			2
3	95533.6	SPINDLE			1
4	009456-02D	WASHER			2
5	31825.3	CLIP			2
6	01775.6	NIPPLE, GREASE	straight		2
7	77380.4	BOOM PIVOT BUSHING			2
8	80400.5	PIN, CARRIAGE			1
9	65397.2	SCREW			1
10	100345-09A	NUT			1
11	01779.8	NIPPLE, GREASE			2
12	6909097	CARRIAGE			1
13	77421.6	PIN			1
14	82459.9	SCREW			1
15	100345-09A	NUT			1
16	95558.3	RETAINING			1
17	95502.1	SCREW			2
18	6917254	CHAIN			2
19	95614.4	SPINDLE			1
20	38632.6	PIN			2
21	98300.7	SHIM	Thickness 1mm - 1mm		2
21	98301.5	SHIM	Thickness 2mm - 2mm		2
21	98302.3	SHIM	Thickness 3mm - 3mm		2
22	95501.3	SHOE			2
23	01775.6	NIPPLE, GREASE	straight		2
24	95502.1	SCREW			6
25	95501.3	SHOE			2
26	01775.6	NIPPLE, GREASE	straight		2
27	95502.1	SCREW			6
28	98344.5	SHOE	Thickness 11mm - 11mm		1
28	98343.7	SHOE	Thickness 12mm - 12mm		1

END BOOM ASSY

T35100, T35100L

Recurrence of previous drawing




SPC001040

END BOOM ASSY
T35100, T35100L

[illegible]

END BOOM ASSY T35100SL



SPC001139


END BOOM ASSY

T35100SL

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6909091	INNER BOOM			1
2	74863.2	BUSH			2
3	95533.6	SPINDLE			1
4	009456-02D	WASHER			2
5	31825.3	CLIP			2
6	01775.6	NIPPLE, GREASE	straight		2
7	77380.4	BOOM PIVOT BUSHING			2
8	77421.6	PIN			1
9	82459.9	SCREW			1
10	100345-09A	NUT			1
11	01779.8	NIPPLE, GREASE			2
12	6909097	CARRIAGE			1
13	80400.5	PIN, CARRIAGE			1
14	65397.2	SCREW			1
15	100345-09A	NUT			1
16	95558.3	RETAINING			1
17	95502.1	SCREW			2
18	6909224	CHAIN			2
19	95614.4	SPINDLE			1
20	38632.6	PIN			2
21	98300.7	SHIM	Thickness 1mm - 1mm		2
21	98301.5	SHIM	Thickness 2mm - 2mm		2
21	98302.3	SHIM	Thickness 3mm - 3mm		2
22	95501.3	SHOE			2
23	01775.6	NIPPLE, GREASE	straight		2
24	95502.1	SCREW			6
25	95501.3	SHOE			2
26	01775.6	NIPPLE, GREASE	straight		2
27	95502.1	SCREW			6
28	98344.5	SHOE	Thickness 11mm - 11mm		1
28	98343.7	SHOE	Thickness 12mm - 12mm		1

END BOOM ASSY T35100SL

Recurrence of previous drawing




SPC001139

END BOOM ASSY

T35100SL

[illegible]

MANUAL QUICK ATTACH LOCK




SPC001043

MANUAL QUICK ATTACH LOCK

[illegible]

AXLE INSTALLATION




SPC002044

AXLE INSTALLATION

[illegible]

CARDAN SHAFT




SPC002051

CARDAN SHAFT

[illegible]


HUB REDUCTION - FRONT AXLE



SPC002045

[illegible]

REDUCER BOX - FRONT AXLE




SPC002071

REDUCER BOX - FRONT AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912814	COVER			1
2	6912722	GEAR			1
3	6912664	RING, SNAP			1
4	6912740	BEARING, BALL			1
5	6912653	RING, SNAP			1
6	6912811	BEVEL GEAR SET			1
7	6912873	TAPER ROLLER BEARING			2
8	6912791	SHIM			1
8	6912792	SHIM			1
8	6912793	SHIM			1
8	6912794	SHIM			1
9	6912795	SHIM			1
9	6912796	SHIM			1
9	6912797	SHIM			1
9	6912798	SHIM			1
10	6912836	SPACER			1
11	6912833	RING NUT			1
12	6912702	SEAL			1
13	6912741	BEARING, BALL			1
14	6912723	GEAR			1
15	6912654	RING, SNAP			1
16	6912742	BEARING, BALL			1
17	6912704	SEAL			1
18	6912625	PLUG			1
19	6912735	WASHER, SPRING			8
*	20	7009648	BOLT, HEX	Was 6912762 - A	8
	21	6912787	PLUG, MAGNET		1
	22	6912724	DOWEL		1
	23	6912786	PLUG		1
	24	6912789	FLANGE		1
	25	6912852	O-RING		1

REDUCER BOX - FRONT AXLE

Recurrence of previous drawing




SPC002071

REDUCER BOX - FRONT AXLE

[illegible]

HOUSING - FRONT AXLE




SPC002072

HOUSING - FRONT AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912715	O-RING			3
2	6912813	INTERMEDIATE COVER			1
3	6912732	PLUG, BREATHER			1
4	6912916	BUSHING, THRUST			2
5	6912625	PLUG			1
6	7JM90	RING, SNAP	Was 6912656 - A		1
7	6912626	CAP			1
8	6912787	PLUG, MAGNET			1
9	6912917	HOUSING			1
10	6912918	HOUSING ASSY	W/Ref. 4, 9		1
11	6912851	O-RING			2
12	6912700	FITTING, GREASE			2
* 13	7011162	CASE, AXLE	W/Ref. 14 ; Was 6912923 - A		1
* 14	6912937	BUSHING, THRUST			2
15	6912868	WASHER			10
16	6912894	BOLT			22
17	6912892	BOLT			2
18	6912828	NUT			2
19	6912685	NUT			4
20	6912773	BOLT			4
21	6912829	NUT			10
22	6912787	PLUG, MAGNET			2
* 23	6912938	BOLT			2
* 24		O-RING	NSS - Order Ref. 22		2
25	6912625	PLUG			4
26	6912840	STUD			8
27	6912919	AXLE CASE			1
* 28	6912774	STEERING ADJUSTMENT ASSY	W/Ref. 19-20		4

DIFFERENTIAL - FRONT AXLE




SPC002047

DIFFERENTIAL - FRONT AXLE

[illegible]

STEERING - FRONT AXLE




SPC002073

STEERING - FRONT AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912808	RING, SNAP			2
2	7JM90	RING, SNAP	Was 6912656 - A		2
3	6912871	BEARING, BALL			2
4	6912848	SEAL			2
* 5		REDUCTION BUSHING	NAP - Order Ref. 7		2
6	6912853	O-RING			2
7	6912825	REDUCTION BUSHING ASSY			2
8	6912847	SEAL			2
9	6912826	THRUST BUSHING			2
10	6912920	JOINT			2
11	6912818	SENSOR, OPTICAL			1
12	6912925	STEERING CASE	W/Ref. 9, 28		1
13	6912784	STEERING CASE	W/Ref. 9, 29 ; Was 6912924 - B		1
14	6912946	CYLINDER	Was 6912887 -		1
15	6912816	COVER			2
16	6912890	BOLT, CYLINDER			4
17		PIVOT	NAP - Order Ref. 19		2
18	6912700	FITTING, GREASE			4
19	6912941	PIVOT PIN ASSY	W/Ref. 17-18		2
20	6912629	PLUG			4
21	6912802	SHIM			2
21	6912803	SHIM			2
21	6912804	SHIM			2
22	6912845	SEAL			2
* 23	6921515	BUSHING	Was 6912680 - A		2
24	6912684	NUT			8
* 25	7003688	ARTICULATED TIE ROD	Was 6912927 - A		1
26	6912736	WASHER			8
* 27	7010888	STUD	Was 6912696 - A		8
28	6912922	STEERING CASE			1
29	6912921	STEERING CASE			1

STEERING - FRONT AXLE

Recurrence of previous drawing




SPC002073

STEERING - FRONT AXLE

[illegible]

BRAKES - FRONT AXLE




SPC002039

BRAKES - FRONT AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912838	SPACER			2
2	6912866	SPRING			4
3	6912857	PISTON			2
4	6912854	O-RING			2
5	6912849	O-RING			4
6	6912780	RING, BACK-UP			4
7	6912629	PLUG			4
8	6912775	BOLT, BLEEDING			4
9	6912768	BOLT			4
10	6912705	SEAL, WASHER			4
11	6912815	COVER			2
12	6912850	O-RING			2
13	6912781	RING, BACK-UP			2
14	6912858	PISTON			2
15	6912824	INTERMEDIATE BRAKE DISC			2
16	6912864	SPRING			6
* 17	6921027	BOLT, ADJUSTING	Was 6912896 - A		6
18	6912897	BOLT, ADJUSTING			6
19	6912865	SPRING			6
20	6912898	BOLT			4
21	6912831	NUT			4
22	6912867	WASHER, LOCK			4
23	6912799	SHIM			2
* 23	6912800	SHIM			2
23	6912801	SHIM			2
24	6912837	SPACER			2
25	6912915	INTERMEDIATE BRAKE DISC			8
26	6912823	DISC, BRAKE			8

HUB REDUCTION - REAR AXLE




SPC002069

HUB REDUCTION - REAR AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912846	SEAL			2
2	6912746	BEARING			4
3	6912841	STUD, WHEEL			16
4	6912856	HUB, WHEEL			2
5	6912715	O-RING			2
6	6912660	RING, SNAP			2
7	6912667	GEAR, RING			2
8	6912875	RING GEAR SUPPORT			2
* 9	7008049	PLATE, LOCKING	Was 6912615 - B, D		2
10	6912663	RING, SNAP			8
11	6912749	PLANET GEAR			8
12	6912748	BEARING			8
13	6912686	NUT			16
14	6912625	PLUG			2
15	6912767	BOLT, COUNTERSUNK			4
16	6912943	PLANET GEAR CARRIER			2
17	6912830	NUT			16
* 18	7010889	STUD	Was 6912839 - A		16
19	7008050	SPACER	Was 6912615 - C		2
20	6912657	RING, SNAP			2
21	6912737	WASHER			2
* 22	7009503	RING GEAR SUPPORT ASSY	W/Ref. 6-8		2
* 23	7009502	PLANET GEAR CARRIER	W/Ref. 10-12, 16, 21		2
* 24	7010276	KIT, LOCKING PLATE	W/Ref. 5, 9, 19-20		2
* 25	6912930	DOUBLE UNIVERSAL JOINT	For details, see page 103		2
* 26	7010277	KIT, PLANET GEAR CARRIER AND JOINT	W/Ref. 22-23, 25		2
* 27	6912944	KIT, PLANET GEAR CARRIER AND RING GEAR SUPPORT	W/Ref. 22-23		2


HOUSING - REAR AXLE



SPC002049

[illegible]

DIFFERENTIAL - REAR AXLE




SPC002041

DIFFERENTIAL - REAR AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912889	CYLINDER BOLT			4
2	6912635	SHIM			2
2	6912636	SHIM			2
2	6912637	SHIM			2
2	6912790	SHIM			2
2	6912642	SHIM			2
3	6912872	TAPER ROLLER BEARING			2
4	6912771	BOLT			12
5	6912812	BEVEL GEAR SET			1
6	6912810	RING, SNAP			4
7	6912870	FRICTION WASHER			4
8	6912809	RING, SNAP			4
9	6912779	PIN			4
10		PINION, DIFFERENTIAL	NAP - Order Ref. 23 ; Was 6912874 - A		4
11	6912869	WASHER			2
12		GEAR, DIFFERENTIAL SIDE	NAP - Order Ref. 23 ; Was 6912861 - A		2
13	6912805	DIFFERENTIAL CARRIER			1
14	6912819	DIFFERENTIAL	W/Ref. 6-13		1
15	6912855	O-RING			1
16	6912834	NUT			1
17	6912873	TAPER ROLLER BEARING			2
18	6912795	SHIM			1
18	6912796	SHIM			1
18	6912797	SHIM			1
18	6912798	SHIM			1
19	6912791	SHIM			1
19	6912792	SHIM			1
19	6912793	SHIM			1
19	6912794	SHIM			1
20	6912836	SPACER			1
21	6912835	RING NUT			1

DIFFERENTIAL - REAR AXLE

Recurrence of previous drawing




SPC002041

DIFFERENTIAL - REAR AXLE

[illegible]

STEERING - REAR AXLE




SPC002050

STEERING - REAR AXLE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912826	THRUST BUSHING			4
2	6912847	SEAL			4
3	6912930	DOUBLE UNIVERSAL JOINT			2
4	6912816	COVER			2
* 5		PIVOT PIN	NAP - Order Ref. 20		2
6		PIVOT PIN	NAP - Order Ref. 8		2
7	6912700	FITTING, GREASE			4
8	6912941	PIVOT PIN ASSY	W/Ref. 6-7		2
9	6912629	PLUG			4
10	6912802	SHIM			2
10	6912803	SHIM			2
10	6912804	SHIM			2
11	6912845	SEAL			2
* 12	6921515	BUSHING	Was 6912680 - A		2
13	6912684	NUT			8
* 14	7003688	ARTICULATED TIE ROD	Was 6912927 - A		1
15	6912736	WASHER			8
* 16	7010888	STUD	Was 6912696 - A		8
17	6912922	STEERING CASE			1
18	6912921	STEERING CASE			1
19	6912778	ARTICULATION			2
20	6912859	PIVOT PIN ASSY	W/Ref. 5, 11, 19		2
21	6912893	BOLT			12
* 22	7003689	ARTICULATED TIE ROD	Was 6912926 - A		1
23	6912818	SENSOR, OPTICAL			1
24	6912773	BOLT			4
25	6912685	NUT			4
26	6912888	CYLINDER			1
27	6912890	BOLT, CYLINDER			4
28	6912774	STEERING ADJUSTMENT ASSY	W/Ref. 24-25		4
29	6912925	STEERING CASE	W/Ref. 1, 17		1

STEERING - REAR AXLE

Recurrence of previous drawing




SPC002050

STEERING - REAR AXLE

[illegible]

BOOM HYDRAULIC SUPPLY FROM CONTROL VALVE




SPC003185

BOOM HYDRAULIC SUPPLY FROM CONTROL VALVE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6917284	CHANNEL	Without stabilizer		1
1	6910842	CHANNEL	With stabilizer		1
2	6910307	SHOE			1
3	95502.1	SCREW			2
4	6915701	SHOE			1
5	88540.0	SCREW			2
6	6910278	PLATE			1
7	01605.5	SCREW			2
8	100345-09A	NUT			2
9	100345-05V	NUT			4
10	33786.5	SCREW			4
11	6917290	CHAIN	Without stabilizer - W/Ref. 12-14		1
11	6909226	CHAIN	With stabilizer - W/Ref. 12-14		1
12	95571.6	LINK	T35100SL		131
12	95571.6	LINK	T35100(L)		117
13	95572.4	LINK			1
14	95088.1	CHAIN SPACER	T35100SL		32
14	95088.1	CHAIN SPACER	T35100(L)		28
15	6913865	HOSE	Without stabilizer		4
15	6910210	HOSE	With stabilizer		4
16	010370-57L	ELBOW			4
17	6917287	PIPE ASSY	Without stabilizer		1
17	6909214	PIPE ASSY	With stabilizer		1
18	01718.6	WASHER			3
19	01597.4	SCREW			3
20	76401.9	HOSE			2
21	80407.0	HOSE			2
22	6919315	WIRE HARNESS	T35100(L)		1
22	6911737	WIRE HARNESS	T35100SL		1
23	6909681	PLATE			1
24	6919314	WIRE HARNESS	T35100(L)		1

BOOM HYDRAULIC SUPPLY FROM CONTROL VALVE

Recurrence of previous drawing




SPC003185

BOOM HYDRAULIC SUPPLY FROM CONTROL VALVE

[illegible]

BOOM HYDRAULIC SUPPLY




SPC003074

BOOM HYDRAULIC SUPPLY

[illegible]


LIFT & COMPENSATION CYLINDER INSTALLATION



SPC003071

[illegible]

TELESCOPE CYLINDER INSTALLATION



SPC003072

[illegible]

This technical diagram illustrates the assembly of a hydraulic system, showing various components and their interconnections. The components are numbered as follows:

- 1**: Hydraulic pump/motor unit.
- 2**: Hose connecting the pump to the first valve.
- 3**: Hose connecting the first valve to the second valve.
- 4**: Hydraulic valve (3-position).
- 5**: Hose connecting the second valve to the third valve.
- 6**: Bundle of hoses connecting the third valve to the actuators.
- 7**: Hose connecting the pump to the first valve.
- 8**: Hose connecting the pump to the first valve.
- 9**: Hose connecting the pump to the first valve.
- 10**: Hydraulic valve (3-position).
- 11**: Hose connecting the pump to the first valve.
- 12**: Hydraulic valve (3-position).
- 13**: Hydraulic valve (3-position).
- 14**: Hose connecting the pump to the first valve.
- 15**: Hose connecting the pump to the first valve.
- 16**: Hose connecting the pump to the first valve.
- 17**: Hose connecting the pump to the first valve.
- 18**: Hose connecting the pump to the first valve.
- 19**: Hose connecting the pump to the first valve.
- 20**: Hose connecting the pump to the first valve.
- 21**: Hose connecting the pump to the first valve.
- 22**: Hose connecting the pump to the first valve.
- 23**: Hose connecting the pump to the first valve.
- 24**: Hose connecting the pump to the first valve.
- 25**: Hose connecting the pump to the first valve.
- 26**: Hose connecting the pump to the first valve.


The diagram shows the pump/motor unit (1) connected to a series of valves (4, 10, 12, 13) via hoses (2, 3, 5, 6, 7, 8, 9, 11, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26). The valves are connected to actuators (cylinders) via hoses (10, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26). The actuators are shown in various positions, indicating the system's range of motion.

T35100(S)(L) Telescopic Handlers HYDRAULIC SYSTEM

STEERING HOSES & FITTINGS (WITHOUT DAMPER)

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6909447	HYDRAULIC PUMP ASSY	For details, see page 161		1
2	100375-38S	ADAPTER			1
3	101319-27P	HOSE			1
4	015370-11P	ELBOW			1
5	79148.3	HOSE			1
6	79147.5	HOSE			1
7	96763.8	HOSE			1
8	100375-56M	ADAPTER			2
9	6910836	HOSE			1
10	010370-94B	FITTING	Elbow		3
11	98348.6	SUPPORT			1
12	10167.5	SCREW			4
13	98349.4	VALVE, STEERING SELECTOR			1
14	79160.8	SCREW			4
15	6913653	HOSE			1
16	100370-06P	ELBOW			1
17	74467.2	HOSE			1
* 18	6910836	HOSE			1
19	96664.8	PIPE, HYDRAULIC			1
20	001369-22D	COLLAR			4
21	48829.6	SCREW			1
22	100369-18T	CLAMP, SPLIT			4
23	100212-53R	PLATE			2
24	100345-06W	NUT			2
* 25	100375-38S	ADAPTER			1
* 26	100370-06P	ELBOW			1

STEERING HOSES & FITTINGS (WITH DAMPER)




SPC003265

STEERING HOSES & FITTINGS (WITH DAMPER)

Item	Part Number	Denomination	Remarks	Serial Number	Qty
* 1	6909447	HYDRAULIC PUMP ASSY			1
* 2	100375-38S	ADAPTER			1
* 3	79147.5	HOSE			1
* 4	015370-11P	ELBOW			1
* 5	79148.3	HOSE			1
* 6	79147.5	HOSE			1
* 7	96763.8	HOSE			1
* 8	100375-56M	ADAPTER			2
* 9	6910836	HOSE			1
* 10	010370-94B	FITTING	Elbow		3
* 11	98348.6	SUPPORT			1
* 12	10167.5	SCREW			4
* 13	98349.4	VALVE, STEERING SELECTOR			1
* 14	79160.8	SCREW			4
* 15	6913653	HOSE			1
* 16	100370-06P	ELBOW			1
* 17	74467.2	HOSE			1
* 18	6910836	HOSE			1
* 19	96664.8	PIPE, HYDRAULIC			1
* 20	001369-22D	COLLAR			4
* 21	48829.6	SCREW			4
* 22	100369-18T	CLAMP, SPLIT			4
* 23	100212-53R	PLATE			2
* 24	100345-06W	NUT			2
* 25	6914316	DAMPER			1
* 26	74467.2	HOSE			1
* 27	51851.4	NUT			2
* 28	01697.2	WASHER			4
* 29	01597.4	SCREW			2
* 30	100375-38S	ADAPTER			1
* 31	100370-06P	ELBOW			1

JOYSTICK INSTALLATION (WITH AMA)




SPC003045

JOYSTICK INSTALLATION (WITH AMA)

[illegible]

AMA - INSTALLATION




SPC003053

AMA - INSTALLATION

[illegible]

SERVICE BRAKE HYDRAULIC INSTALLATION




SPC003148

SERVICE BRAKE HYDRAULIC INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6916227	VALVE, BRAKE			1
2	78927.1	PLUG			1
3	000350-01U	WASHER			2
4	15354.4	SCREW			2
5	51851.4	NUT			4
6	96061.7	SPACER			4
7	96054.2	SPACER			1
8	01578.4	SCREW			4
9	6917139	WASHER			1
10	96656.4	SPRING			1
11	6916595	CLIP			1
12	90289.0	FITTING			3
13	6908595	HOSE			1
14	008372-02C	FITTING	t-union		1
15	010370-87T	FITTING	Elbow		1
16	6916626	HOSE			1
17	100370-40B	FITTING, ELBOW			2
18	6916627	HOSE			1
19	6915430	HOSE			1
20	100370-29P	FITTING	elbow		2
21	6915424	TUBE			1
22	6915425	TUBE			1
23	100372-23A	TEE			2
24	100375-17U	FITTING			4
25	100370-06P	ELBOW			2
26	6916630	ADAPTER			1
27	37872.9	SCREW			2
28	6910771	WASHER			2
29	100345-06W	NUT			2
30	65715.5	HOSE	Was 6916629 -		1
31	6916628	HOSE			1

SERVICE BRAKE HYDRAULIC INSTALLATION




SPC003148

SERVICE BRAKE HYDRAULIC INSTALLATION

[illegible]

PARKING BRAKE HYDRAULIC INSTALLATION




SPC003149

PARKING BRAKE HYDRAULIC INSTALLATION

[illegible]

PARKING BRAKE HYDRAULIC INSTALLATION (ACCUMULATOR)




SPC003150

PARKING BRAKE HYDRAULIC INSTALLATION (ACCUMULATOR)

[illegible]

QUICK ATTACH INSTALLATION




SPC003052

QUICK ATTACH INSTALLATION

[illegible]

HYDRAULIC TANK INSTALLATION




SPC003054

HYDRAULIC TANK INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6913526	TANK	Was 6911094 -		1
2	78743.2	PLUG, DRAIN			1
3	38025.3	WASHER			2
4	01718.6	WASHER			2
5	01597.4	SCREW			2
6	54194.6	GAUGE			1
7	6913570	STRAINER			1
8	6913569	SEAL	Was 98583.8 -		1
9	6917778	BREATHER	Was 37148.4 -		1
10	6911140	HYDRAULIC FILTER	W/Ref. 11-13, 43-44		1
11	6913059	ELEMENT, HYDRAULIC FILTER			1
12	6912548	SET OF SEALS			1
13	6912572	CAP			1
14	01639.4	SCREW			4
15	6909739	UNION			1
16	6923433	PIPE	Was 6910972 -		1
17	01597.4	SCREW			1
18	000350-02V	WASHER			2
19	51851.4	NUT			1
20	011374-62W	PLUG			2
21	6913649	HOSE			1
22	68609.7	FITTING	Was 6910603 -		1
23	6912484	HYDR. CONTROL VALVE ASSY			1
24	69274.9	ELBOW			1
25	85170.9	UNION			1
26	6910602	HOSE			1
27	6919333	CLAMP	Was 89522.7 -		1
28	6908091	FLANGE			1
29	10167.5	SCREW			4
30	93049.5	O-RING			1
31	6909447	HYDRAULIC PUMP ASSY			1

HYDRAULIC TANK INSTALLATION

Recurrence of previous drawing




SPC003054

HYDRAULIC TANK INSTALLATION

[illegible]

FRAME LEVEL INSTALLATION




SPC003155

FRAME LEVEL INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6926839	CYLINDER ASSY, FRAME LEVEL	Was 6915288 - ; For details, see page 155		1
2	67166.9	SPINDLE			1
3	58880.6	WASHER			2
4	06734.8	RING, RETAINING			2
5	27052.0	BUSH			2
6	68656.8	MOUNTING BLOCK			2
7	94990.9	SCREW			4
8	100345-16H	NUT			4
9	77013.1	ADAPTER			2
10	92126.2	HOSE			2
11	100370-40B	FITTING, ELBOW			2
12	67198.2	HOSE			2
13	6918652	FITTING	elbow ; Was 77075.0 -		2
14	6911082	VALVE, HYDRAULIC			1
15	6912537	COIL	speed		2
16	15798.2	SCREW			2
17	51851.4	NUT			2
18	6911081	FRAME LEVEL SELECTOR VALVE			1
19	6912536	COIL	up/down		2
20	022375-04U	ADAPTER			2
21	65715.5	HOSE			1
22	77912.4	ADAPTER			1
23	100370-29P	FITTING	elbow		1
24	67198.2	HOSE			1
25	77013.1	ADAPTER			1
26	6910822	COLLECTOR			1

STABILIZERS INSTALLATION




SPC003248

STABILIZERS INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6909143	SHOE			2
2	84237.7	SPINDLE			2
3	100454-05T	WASHER			4
4	10882.9	SCREW			4
5	6909142	ARM			2
6	01782.2	NIPPLE, GREASE			2
7	88597.0	SPINDLE			4
8	12597.1	SCREW			4
9	100345-09A	NUT			4
10	6909127	FRONT SUPPORT			1
11	6909675	SCREW			2
12	6909675	SCREW			2
13	6909128	WASHER			4
14	001345-66S	NUT			4
15	6914550	CYLINDER			2
16	022375-04U	ADAPTER			4
17	70862.8	HOSE			4
17	66748.5	HOSE			4
18	74466.4	HOSE			2
19		STABILIZER SELECTOR VALVE			1
20	6913651	HOSE	Was 6910781 -		1
21	6911054	HOSE			1
22	022375-28V	ADAPTER			1
23	6910786	HOSE			1
24	72294.2	ELBOW, UNION			1


STABILIZER SELECTOR VALVES



SPC003081

[illegible]

LIFT CYLINDER




SPC003075

LIFT CYLINDER

[illegible]


COMPENSATION CYLINDER



SPC003092

[illegible]

TELESCOPE CYLINDER




SPC003186

TELESCOPE CYLINDER

[illegible]

TILT CYLINDER




SPC003093

TILT CYLINDER

[illegible]

QUICK ATTACH CYLINDER




SPC003178

QUICK ATTACH CYLINDER

[illegible]

FRAME LEVEL CYLINDER




SPC003156

FRAME LEVEL CYLINDER

[illegible]

STABILIZER CYLINDER




SPC003027

STABILIZER CYLINDER

[illegible]

HYDRAULIC MOTOR




SPC003181

HYDRAULIC MOTOR

[illegible]


HYDRAULIC PUMP INSTALLATION



SPC003062

[illegible]

HYDRAULIC PUMP ASSY




SPC003029

HYDRAULIC PUMP ASSY

[illegible]


HYDRAULIC CONTROL VALVE FIXATION



SPC003232

[illegible]

HYDRAULIC CONTROL VALVE INSTALLATION




SPC003184

HYDRAULIC CONTROL VALVE INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6924092	HYDR. CONTROL VALVE ASSY	Was 6912484 -		1
2	01608.9	SCREW			3
3	000350-21R	WASHER			3
4	100345-09A	NUT			3
5	100370-18C	FITTING	elbow		2
6	54367.8	SWITCH, PRESSURE			1
7	100370-18C	FITTING	elbow		2
8	100372-06G	FITTING	T-union		2
9	85283.0	HOSE			1
10	022375-31Z	ADAPTER			1
11	6911845	VALVE			2
12	6912530	BLOCK			1
13	6912531	VALVE			1
14	6912547	KIT, SEALS			1
15	6912528	COIL			1
16	6912529	NUT			1
17	48829.6	SCREW			2
18	000350-01U	WASHER			2
19	100345-06W	NUT			2
20	022375-31Z	ADAPTER			1
21	6911143	HOSE			1
22	77013.1	ADAPTER	T35100(S)L		6
22	77013.1	ADAPTER	T35100		5
23	6910822	COLLECTOR			1
24	10947.0	SCREW			2
25	51851.4	NUT			2
26	69187.3	PLUG			1
27	88946.9	SCREW			1
28	65614.0	UNION			1
29	6911817	HOSE			1
30	022375-31Z	ADAPTER			2

HYDRAULIC CONTROL VALVE INSTALLATION

Recurrence of previous drawing




SPC003184

HYDRAULIC CONTROL VALVE INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
31	6910208	VALVE			1
32	6912526	BLOCK			1
33	6912527	VALVE			1
34	6912546	KIT, SEALS			1
35	6912528	COIL			1
36	6912529	NUT			1
37	000326-25M	SCREW			2
38	94574.1	WASHER			2
39	100370-18C	FITTING	elbow		1
40	100372-06G	FITTING	T-union		2
41	6913655	HOSE			1
42	100370-29P	FITTING	elbow		3
43	82181.9	FITTING			1
44	85955.3	FITTING	ELBOW		1
45	6913658	HOSE			1
46	6911817	HOSE			1
47	100370-18C	FITTING	elbow		1
48	68609.7	FITTING			1
49	100375-40U	ADAPTER			1
50	6910390	HOSE			1
51	014375-02C	FITTING			8
52	008372-28F	FITTING	t-union		4
55	6918017	TUBE			1
56	77013.1	ADAPTER			5
57	6912467	HOSE			1
58	6918017	TUBE			1
59	6918652	FITTING	elbow		1
60	100370-18C	FITTING	elbow		1
61	89519.3	WASHER			2
62	01508.1	SCREW			2
63	54367.8	SWITCH, PRESSURE			1

HYDRAULIC CONTROL VALVE INSTALLATION


Recurrence of previous drawing



SPC003184

[illegible]


HYDRAULIC CONTROL VALVE:IN- AND OUTLET



SPC003066

[illegible]

HYDRAULIC CONTROL VALVE LIFT SECTION




SPC003067

HYDRAULIC CONTROL VALVE LIFT SECTION

[illegible]

HYDRAULIC CONTROL VALVE TILT SECTION




SPC003068

HYDRAULIC CONTROL VALVE TILT SECTION

[illegible]


HYDRAULIC CONTROL VALVE TELESCOPE SECTION



SPC003069

[illegible]

HYDRAULIC CONTROL VALVE AUXILIARY HYDRAULICS SECTION




SPC003070

HYDRAULIC CONTROL VALVE AUXILIARY HYDRAULICS SECTION

[illegible]

HYDROSTATIC HOSES AND FITTINGS




SPC004011

HYDROSTATIC HOSES AND FITTINGS

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6913565	PUMP, HYDROSTATIC	For details, see page 185		1
2	100454-17G	WASHER			4
3	89517.7	WASHER			4
4	01613.9	SCREW			4
5	67046.3	ADAPTER			3
6	014375-33L	ADAPTER			2
7	6909780	TUBELINE			1
8	100375-40U	ADAPTER			2
9	97880.9	VALVE, CHECK			1
10	78705.1	ADAPTER			1
11	6913204	HOSE			1
12	6910599	HOSE			1
13	008372-34M	FITTING	t-union		1
14	6910161	HOSE			1
15	003304-21D	O-RING			4
16	92210.4	WASHER			16
17	28689.8	SCREW			16
18	6915391	HOSE			1
19	78256.5	MOTOR ASSY, HYDROSTATIC			1
20	89518.5	WASHER			4
21	28439.8	SCREW			4
22	67046.3	ADAPTER			2
23	014375-96E	CONNECTOR			2
24	96795.0	HOSE			1
25	6914746	HOSE			1
26	96755.4	HOSE			1
27	96756.2	HOSE			1
28	6915392	HOSE			1
29	100375-15S	REDUCER			1
30	100345-34C	NUT			1
31	72065.6	SWITCH, PRESSURE			1

HYDROSTATIC PUMP ASSY




SPC004003

HYDROSTATIC PUMP ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	75037.2	KIT, SEALS HYDRAULIC PUMP	Including all seals		1
2	6912058	HOUSING			1
3	6912059	BEARING			1
4	71599.5	DOWEL			2
5	71674.6	PLUG			1
6	71674.6	PLUG			1
7	71675.3	PLUG ASSY			1
8	71636.5	PLUG			1
9	6912533	VALVE			1
10	71690.2	PISTON			9
11	71691.0	RETAINER			1
12	71692.8	GUIDE			2
13	71693.6	SPACER			4
14	98653.9	SCREW			4
15	6912554	VALVE PLATE			1
16	6912060	LEVER			1
17	6912061	SUPPORT			1
18	6912062	SCREW			1
19	71681.1	WASHER			1
20	71682.9	PIN			1
21	71679.5	PIN			1
22	6912063	PIN			1
23	71636.5	PLUG			1
24	71684.5	SPRING			1
25	6912558	COVER ASSY			1
26	6912559	SPRING GUIDE	Including 2 springs		1
27	6912560	WASHER			2
28	6912561	GUIDE BOLT			2
29	71715.7	NUT, LOCK			2
30	6912562	O-RING			1
31	6912563	SCREW			6

HYDROSTATIC PUMP ASSY

Recurrence of previous drawing




SPC004003

HYDROSTATIC PUMP ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
32	71675.3	PLUG ASSY			1
33	71711.6	SPRING			2
34	71736.3	HOUSING			1
35	6912564	SCREW			3
36	6912064	SEAL			2
37	71737.1	NUT, LOCK			1
38	71685.2	NUT, SLIDE			1
39	71734.8	HOUSING			1
40	71735.5	SCREW			3
41	71733.0	SEAL			2
42	71732.2	SEAL			2
43	6912065	HOUSING			1
44	71674.6	PLUG			1
45	98695.0	GASKET			1
46	6912066	PLUG			1
47	71674.6	PLUG			1
48	71674.6	PLUG			1
49	71753.8	SCREW			1
50	81424.4	SCREW			1
51	81425.1	SCREW			1
52	71757.9	CHARGE PUMP ASSY			1
53	71762.9	FLANGE	W/Ref. 69		1
54	81427.7	VALVE			1
55	71585.4	BEARING			1
56	71701.7	SHAFT			1
57	71702.5	RING, SNAP			1
58	81421.0	KIT, AXLE SEALS			1
59	6912567	PLATE			1
60	6912067	SCREW			3
61	6912068	SCREW			4
62	97400.6	VALVE			2

HYDROSTATIC PUMP ASSY

Recurrence of previous drawing




SPC004003

HYDROSTATIC PUMP ASSY

[illegible]

HYDROSTATIC MOTOR ASSY




SPC004013

HYDROSTATIC MOTOR ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	78256.5	MOTOR ASSY, HYDROSTATIC	W/Ref. 2-61		1
2	71599.5	DOWEL			2
3	71605.0	SCREW			4
4	71610.0	NUT			1
5	71611.8	COVER, HYDR MOTOR			1
6	71785.0	PLUG			2
7	71629.0	CONE			1
8	71630.8	SPRING			1
9	71631.6	SCREW			1
10	71632.4	O-RING			1
11	71633.2	NUT			1
12	71643.1	SEAL			1
13	71636.5	PLUG			1
14	71646.4	SCREW			4
15	71626.6	SEAL			1
16	71602.7	SCREW			1
17	71603.5	SCREW			1
18	71674.6	PLUG			3
19	71638.1	NOZZLE			1
20	71636.5	PLUG			1
21	71635.7	NOZZLE			1
22	71638.1	NOZZLE			1
23	71674.6	PLUG			1
24	71636.5	PLUG			1
25	71636.5	PLUG			1
26	71674.6	PLUG			2
27	81460.8	SPRING			1
28	71621.7	WASHER			1
29	71622.5	NOZZLE			2
30	81455.8	CONTROL	Was 95424.8 -		1
31	71624.1	SEAL			2

HYDROSTATIC MOTOR ASSY

Recurrence of previous drawing




SPC004013

HYDROSTATIC MOTOR ASSY

Item	Part Number	Denomination	Remarks	Serial Number	Qty
32	71644.9	SEAL			3
33	71643.1	SEAL			3
34	71643.1	SEAL			1
35	71644.9	SEAL			3
36	92614.7	HOUSING			1
37	71636.5	PLUG			1
38	71674.6	PLUG			1
39	71674.6	PLUG			1
40	75594.2	SOLENOID, HYDRAULIC MOTOR			1
41	81450.9	SEAL			1
42	41282.5	SOLENOID			1
43	101472-20M	DIODE			1
44	81463.2	KIT, HYDROSTATIC MOTOR SEAL			1
45	81458.2	SPINDLE			1
46	97258.8	PISTON			1
47	81448.3	COVER			1
48	97357.8	SPRING			2
49	81435.0	SHAFT			1
50	81434.3	CYLINDER BLOCK			1
51	81436.8	BEARING PLATE			1
52	81433.5	VALVE SEGMENT			1
53	81445.9	PISTON			1
54	81437.6	SEAL			1
55	81444.2	O-RING			1
56	81443.4	SCREW			1
57	81450.9	SEAL			1
58	81451.7	PLUG			2
59	6912948	O-RING			1
60	81457.4	PIN			1
61	6912159	SPRING RETAINER			1

ELECTRICAL CIRCUIT CHASSIS




SPC005073

ELECTRICAL CIRCUIT CHASSIS

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	000350-01U	WASHER			2
2	000350-02V	WASHER			1
3	6910892	WIRE HARNESS	SL version		1
4	01591.7	SCREW			2
5	01595.8	SCREW			2
6	01596.6	SCREW			4
7	01598.2	SCREW			1
8	6913674	WIRE HARNESS			1
9	01697.2	WASHER			1
10	01718.6	WASHER			6
11	10947.0	SCREW			1
12	13415.5	WASHER			5
13	51851.4	NUT			3
14	65764.3	CIRCUIT BREAKER			1
15	77136.0	BRACKET			1
16	78869.5	BATTERY CABLE, NEGATIVE			1
17	79533.6	FRONT LIGHT ASSY	Right		1
18	79534.4	FRONT LIGHT ASSY	Left		1
19	79539.3	HARNESS, FRONT LIGHT	Left		1
20	79861.1	CABLE, BATTERY	positive		1
21	79862.9	HARNESS, STARTER			1
22	82265.0	LIGHT, REAR	RH red / amber / clear		1
*	22	97260.4	LENS		1
*	22	27089.2	BULB	21W	2
*	22	6909955	BULB	21/5W	1
	23	82266.8	LIGHT, REAR	LH red/amber	1
*	23	97261.2	LENS		1
*	23	27089.2	BULB	21W	2
*	23	6909955	BULB	21/5W	1
	24	85837.3	NUT, COVER		2
	25	96421.3	PLATE		1

ELECTRICAL CIRCUIT CHASSIS

Recurrence of previous drawing




SPC005073

ELECTRICAL CIRCUIT CHASSIS

[illegible]

ELECTRICAL CIRCUIT CAB

S/N 11001-12000



- | | | | | | | | | | |
|----|----|----|----|-----|-------|------|------|------|-------|
| 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 |
| | | | | | | | | | |
| | | | | 3 A | 7,5 A | 10 A | 15 A | 20 A | DIODE |

SPC005101

ELECTRICAL CIRCUIT CAB

S/N 11001-12000

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6916967	FUSE BOX	W/Ref. 13-22		1
2	6923909	WIRE HARNESS, CAB			1
3	97236.4	HARNESS, WIRE			1
4	78816.6	WORKLIGHT, REAR			1
4	58446.6	BULB			1
5	78815.8	WORKLIGHT, FRONT			2
5	58446.6	BULB			2
6	6918227	SWITCH, SERVICE BRAKE	Was 6909324 -		1
7	6909383	SWITCH, INCHING (DETECTOR)			1
8	6911325	TRANSMISSION BOX			1
10	6915268	JOYSTICK	Was 6910314 -		1
11	6919190	BOX, CONTROL	Was 6911363 -		1
12	6924060	INDICATOR, STABILITY	Was 6913764 -		1
13	96623.4	TURN SIGNAL RELAY			1
14	6910955	RELAY, MICRO			20
15	79930.4	RELAY			1
16	100411-05U	RELAY			2
17	64120.9	FUSE	3A - 3A		1
18	57792.4	FUSE	7.5A - 7.5A		15
19	57752.8	FUSE	10A - 10A		8
20	57793.2	FUSE	15A - 15A		6
21	57753.6	FUSE	20A - 20A		2
22	80226.4	DIODE			2
23	100345-05V	NUT			2
24	6910952	WASHER			2
25	100345-05V	NUT			2
26	6901596	GREASE			1

S/N 12001 & Above




ELECTRICAL CIRCUIT CAB

S/N 12001 & Above

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6911733	FUSE BOX	W/Ref. 13-22		1
2	6923909	WIRE HARNESS, CAB			1
3	97236.4	HARNESS, WIRE			1
4	78816.6	WORKLIGHT, REAR			1
4	58446.6	BULB			1
5	78815.8	WORKLIGHT, FRONT			2
5	58446.6	BULB			2
6	6901596	GREASE			1
7	6909383	SWITCH, INCHING (DETECTOR)			1
8	6924507	BOX, TRANSMISSION			1
10	6915268	JOYSTICK	Was 6910314 -		1
11	6922919	BOX, CONTROL			1
12	6924060	INDICATOR, STABILITY	Was 6913764 -		1
13	96623.4	TURN SIGNAL RELAY			1
14	6910955	RELAY, MICRO			20
15	79930.4	RELAY			1
16	100411-05U	RELAY			2
17	64120.9	FUSE	3A - 3A		1
18	57792.4	FUSE	7.5A - 7.5A		15
19	57752.8	FUSE	10A - 10A		8
20	57793.2	FUSE	15A - 15A		6
21	57753.6	FUSE	20A - 20A		2
22	80226.4	DIODE			2
23	100345-05V	NUT			2
24	6910952	WASHER			2
25	100345-05V	NUT			2

ELECTRICAL CIRCUIT ENGINE




SPC005079

ELECTRICAL CIRCUIT ENGINE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6923681	HARNESS, ENGINE	Was 6915845 -		1
* 2	6917185	TEMPERATURE SENDER, HYDR. OIL			1
3	6912549	INDICATOR, FILTER PLUGGING			1
4	26278.2	OIL PRESSURE SWITCH			1
5	97175.4	SOLENOID			1
6	6911895	THERMOSTAT			1
7	6911911	SWITCH, WATER TEMP			1
8	6911400	SWITCH, WATER TEMP			1
9	6911377	ALTERNATOR			1
10	79926.2	TERMINAL			1
11	13415.5	WASHER			2
12	01665.9	NUT			2
13	96613.5	SPACER			1
14	13416.3	WASHER			3
15	01666.7	NUT			1
16	6911913	MOTOR, STARTER			1
17	018472-83R	CABLE, GROUND			2
18	79930.4	RELAY			2
19	6909767	FUSE	70A		1
20	79947.8	FUSE	50A		1
21	79946.0	FUSE	40A		1
22	79945.2	SUPPORT			2
23	79951.0	SUPPORT, SAFETY			1
24	79931.2	SUPPORT, RELAY			1
25	6916979	PROTECTOR			1
26	01596.6	SCREW			1
27	51851.4	NUT			1
28	01275.7	TIE, CABLE			5
29	01605.5	SCREW			1
30	79927.0	WASHER			1
31	100345-09A	NUT			5

ELECTRICAL CIRCUIT ENGINE

Recurrence of previous drawing




SPC005079

ELECTRICAL CIRCUIT ENGINE

[illegible]

VENTILATION REVERSE ELECTRICAL




SPC005006

VENTILATION REVERSE ELECTRICAL

[illegible]

JOYSTICK




SPC005019

JOYSTICK

[illegible]

JOYSTICK/SUSMIC INSTALLATION

S/N 11001 - 12000



SPC005015




JOYSTICK/SUSMIC INSTALLATION

S/N 11001 - 12000

[illegible]

JOYSTICK / SUSMIC INSTALLATION

S/N 12001 & Above




SPC005116

JOYSTICK / SUSMIC INSTALLATION

S/N 12001 & Above

[illegible]


ELECTRIC CIRCUIT SECURITY



SPC005037

[illegible]

SECURITY OPTION STABILIZERS/TELESCOPING





SPC005022

SECURITY OPTION STABILIZERS/TELESCOPING

[illegible]

STABILIZERS 25° LOCKING OPTION




SPC005021

STABILIZERS 25° LOCKING OPTION

[illegible]

ELECTRICAL CIRCUIT ARM




SPC005096

ELECTRICAL CIRCUIT ARM

[illegible]


ELECTRICAL BOX AV



SPC005107

[illegible]

ENGINE INSTALLATION




SPC006112

ENGINE INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	000345-96E	NUT			4
2	00350-03W	RONDELLE			4
3	000350-04X	WASHER			4
4	01528.9	SCREW			2
5	01595.8	SCREW			2
6	01596.6	SCREW			4
7	01605.5	SCREW			4
8	01608.9	SCREW			6
9	01640.2	SCREW			2
10	01718.6	WASHER			2
11	011374-44C	PLUG			1
12	13399.1	SCREW			4
13	14039.2	SCREW			5
14	28439.8	SCREW			2
15	38441.2	UNION			2
16	54009.6	SCREW			3
17	89516.9	WASHER			6
18	89517.7	WASHER			2
19	89518.5	WASHER			2
20	89519.3	WASHER			4
21	96461.9	ADAPTER			1
22	96462.7	HOSE, DRAIN			1
23	97878.3	HOUSING			1
24	98272.8	SPRING			1
25	100345-09A	NUT			12
26	6908071	SUPPORT			1
27	6908663	PLATE			2
28	6910326	SUPPORT			1
29	6919219	COUPLING			1
30	6919322	ENGINE	See following pages for details		1
31	6921134	FLANGE			1

ENGINE INSTALLATION

Recurrence of previous drawing




SPC006112

ENGINE INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
32	6921192	SHOCK ABSORBER			2
33	6922321	SHOCK ABSORBER			2
34	6923517	GASKET			1
35	01591.7	SCREW			3
36	100345-06W	NUT			5
37	6910322	SUPPORT			1
38	6910328	PIN			2
39	01697.2	WASHER			2
40	007330-29V	SCREW			2
41	29713.5	CLAMP			1
42	35949.7	CLAMP			2
43	38683.9	CLAMP			1
44	51851.4	NUT			2
45	97746.2	FILTER, AIR			1
46	97747.0	CLAMP			1
47	6908363	CAP, RAIN-PROOF			1
48	6911276	INDICATOR FILING			1
49	6916705	HOSE			1
50	6916706	HOSE			1
51	6910724	AIR FILTER COVER			1
52	6910725	FILTER, AIR OUTER			1
53	6910726	FILTER, AIR INNER	secondary		1
54	6910727	RING			1
55	6913087	TACHOMETER			1
56	98132.4	WASHER			3

EXHAUST SYSTEM




SPC006049

EXHAUST SYSTEM

[illegible]

COOLING SYSTEM INSTALLATION




SPC006119

COOLING SYSTEM INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	000350-02V	WASHER			1
2	01275.7	TIE, CABLE			1
3	01590.9	SCREW			2
4	01596.6	SCREW			1
5	01597.4	SCREW			1
6	01598.2	SCREW			1
7	01668.3	NUT			2
8	01697.2	WASHER			1
9	01717.8	WASHER			2
10	008372-34M	FITTING	t-union		1
11	11734.1	CLAMP			2
12	014375-97F	ADAPTER			1
13	51851.4	NUT			4
14	62231.6	CLAMP			3
15	68609.7	FITTING			2
16	78688.9	TANK, EXPANSION			1
17	78745.7	ADAPTER			1
18	84729.3	CLAMP			1
19	88394.2	INSULATION			1
20	88395.9	INSULATION			1
21	89519.3	WASHER			3
22	90490.4	PLATE			1
23	100369-55H	CLAMP			5
24	100369-80K	CLAMP			5
25	100374-14H	PLUG			1
26	6908901	HOSE, EXPANSION TANK			1
27	6908902	HOSE			1
28	6908975	CAP, FILLER			1
29	6910264	HOSE			1
30	6910966	SUPPORT			3
31	6910970	HOSE, LOWER RADIATOR			1

COOLING SYSTEM INSTALLATION


Recurrence of previous drawing



SPC006119

[illegible]

RADIATOR




SPC006123

RADIATOR

[illegible]


COOLING FAN CIRCUIT (W/O Optional Reverse - W/O Frame Leveling)



SPC006130

[illegible]

COOLING FAN CIRCUIT (W/O Optional Reverse - W/ Frame Leveling)




SPC006028

COOLING FAN CIRCUIT
(W/O Optional Reverse - W/ Frame Leveling)

[illegible]


COOLING FAN CIRCUIT (W/ Optional Reverse - W/O Frame Leveling)



SPC006126

[illegible]


COOLING FAN CIRCUIT (W/ Optional Reverse - W/ Frame Leveling)



SPC006127

[illegible]

CYLINDER BLOCK




SPC006073

CYLINDER BLOCK

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6924941	KIT, CYLINDER BLOCK	W/Ref. 2-24		1
2		CYLINDER BLOCK	NAP - Order Ref. 1		1
3		CAP, BEARING	NAP - Order Ref. 1		1
4		CAP, BEARING	NAP - Order Ref. 1		2
5		CAP, BEARING	NAP - Order Ref. 1		1
6		CAP, BEARING	NAP - Order Ref. 1		1
7	64627.3	BUSHING			10
8	64628.1	SCREW			10
9	6911915	BUSHING			1
10	6911936	PLUG			2
11	6911937	PLUG			1
12	6911858	PLUG			1
13	6911859	PLUG			1
14	6911932	PLUG			2
15	6911928	PLUG			1
16	93379.6	DOWEL			2
17	71402.2	SCREW			1
18	6924949	WASHER			1
19	6924913	SWITCH, OIL PRESSURE			1
20	6924924	JET, PISTON COOLING			4
21	71564.9	SCREW			4
22	6911964	PLATE			1
23	6911983	GASKET			1
24	71516.9	SCREW			4
25	6911887	SEAL, OIL HOUSING			1
26	6912051	SCREW			10
27	6911893	PLUG			1
28	64988.9	STUD			8
29	6924910	NUT			8

CRANKSHAFT - PISTONS




SPC006074

CRANKSHAFT - PISTONS

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912029	KIT, CRANKSHAFT	W/Ref. 2-7		1
2		CRANKSHAFT	NAP - Order Ref. 1		1
3	6912021	KIT, MAIN BEARING			1
3	6912034	KIT, MAIN BEARING	+ 0.01" - + 0.01"		1
3	6912035	KIT, MAIN BEARING	+ 0.02" - + 0.02"		1
3	6912036	KIT, MAIN BEARING	+ 0.03" - + 0.03"		1
4	6924326	KIT, BIG END BEARING			1
4	6912031	KIT, BIG END BEARING	+ 0.25mm - + 0.25mm		1
4	6912032	KIT, BIG END BEARING	+ 0.50mm - + 0.50mm		1
4	6912033	KIT, BIG END BEARING	+ 0.75mm - + 0.75mm		1
5	46893.4	WASHER, THRUST			2
5	6912054	WASHER, THRUST	+ 0.007" - + 0.007"		2
6	46854.6	WASHER, THRUST	Was 46854.2 - D		2
6	6912055	WASHER, THRUST	+ 0.007" - + 0.007"		2
7	6911854	KEY, WOODRUFF			1
8	6912046	GEAR, CRANKSHAFT			1
9	6924923	KIT, PISTON AND RING	W/Ref. 10-13		4
10		PISTON	NAP - Order Ref. 9		1
11		PIN, GUDGEON	NAP - Order Ref. 9		4
12	6924925	KIT, PISTON RING			4
13	93158.4	RING, RETAINER			8
14	6911897	KIT, CONROD	Grade F (red) - Grade F (red)		4
14	6912040	KIT, CONROD	Grade G (orange) - Grade G (orange)		4
14	6912041	KIT, CONROD	Grade H (white) - Grade H (white)		4
14	6912042	KIT, CONROD	Grade J (green) - Grade J (green)		4
14	6912043	KIT, CONROD	Grade K (violet) - Grade K (violet)		4
14	6912044	KIT, CONROD	Grade L (blue) - Grade L (blue)		4
15		CONROD	NAP - Order Ref. 14		4
16		CAP, CONROD	NAP - Order Ref. 14		4
17	6911914	BUSHING			4
18	6911929	SCREW	Do not re-use once removed - Do not re-use once removed		8

FLYWHEEL AND DRIVE PULLEY




SPC006078

FLYWHEEL AND DRIVE PULLEY

[illegible]


CYLINDER HEAD INSTALLATION



SPC006087

[illegible]

CYLINDER HEAD ASSY




SPC006079

CYLINDER HEAD ASSY	
--------------------	--

[illegible]


ROCKER SHAFT



SPC006088

[illegible]

TIMING GEAR




SPC006103

TIMING GEAR	
-------------	--

[illegible]


OIL SUMP - OIL PUMP



SPC006094

[illegible]

FUEL INJECTION EQUIPMENT




SPC006091

FUEL INJECTION EQUIPMENT

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6924349	FUEL INJECTION PUMP ASSY	W/Ref. 2-6		1
2		PUMP, FUEL INJECTION	NAP - Order Ref. 1		1
3	93191.5	SEAL			1
4	97175.4	SOLENOID			1
5	81046.5	NUT			1
6	81405.3	WASHER	Was 81405.7 - D		1
7	6911918	GEAR	Was 9611918 - D		1
8	71338.8	SCREW			3
9	6911877	WASHER			3
10	6911966	BRACKET			1
11	64878.2	SCREW			1
12	71329.1	NUT			1
13	71348.7	SCREW			1
14	6924916	PIPE, INJECTION	Cyl. 1 - Cyl. 1		1
15	6924917	PIPE, INJECTION	Cyl. 2 - Cyl. 2		1
16	6924918	PIPE, INJECTION	Cyl. 3 - Cyl. 3		1
17	6924919	PIPE, INJECTION	Cyl. 4 - Cyl. 4		1
18	6924339	CLIP			2
19	6924340	CLIP			1
20	71418.8	CLAMP			1
21	6911904	HOSE			3
22	6912038	CAP			1
23	6924907	INJECTOR	W/Ref. 24-27		4
24		HOLDER, INJECTOR NOZZLE	NAP - Order Ref. 23		4
25		NOZZLE, INJECTOR	NAP - Order Ref. 23		4
26	6924936	SEAL			4
27	93207.9	WASHER			4
28	6911989	CLAMP			4
29	6911874	SCREW			4
30	6924914	PIPE ASSY	W/Ref. 31-33		1
31		PIPE	NAP - Order Ref. 30		1

FUEL INJECTION EQUIPMENT

Recurrence of previous drawing




SPC006091

FUEL INJECTION EQUIPMENT

[illegible]


FUEL FEEDING



SPC006108

[illegible]


CYLINDER HEAD COVER



SPC006095

[illegible]


OIL COOLER AND FILTER



SPC006104

[illegible]


WATER PUMP AND THERMOSTAT



SPC006106

[illegible]

TURBOCHARGER




SPC006107

TURBOCHARGER

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6911993	MANIFOLD			1
2	6911973	GASKET			1
3	93408.3	SCREW			8
4	6924944	TURBOCHARGER			1
4	6924945	TURBOCHARGER, EXCHANGE	remanufactured		1
5	6911978	GASKET			1
6	6911868	STUD			4
7	71490.7	NUT			4
8	6911957	PIPE			1
9	6911979	GASKET			1
10	6911980	GASKET			1
11	93321.8	SCREW			2
12	64878.2	SCREW			2
13	6911992	ELBOW, EXHAUST			1
14	6924333	BRACKET			1
15	6924324	ADAPTOR			1
16	71346.1	SCREW			3
17	71286.9	SCREW			2
18	6911868	STUD			3
19	71490.7	NUT			3
20	6924903	GASKET			1
21	6912008	PIPE ASSY	W/Ref. 22-24		1
22		PIPE	NAP - Order Ref. 21		1
23	6911935	BOLT, BANJO			2
24	6911862	WASHER			4

ALTERNATOR





SPC006122

ALTERNATOR

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6911377	ALTERNATOR			1
2	6911382	CLAMP			1
3	57506.8	SCREW	Was 6911871 -		1
4	01698.0	WASHER	Was 93433.1 -		2
5	51851.4	NUT	Was 92642.8 -		1
6	6911383	BRACKET, ALTERNATOR			1
7	01597.4	SCREW			1
8	01522.2	SCREW			1
9	6911384	SPACER			1
10	100345-09A	NUT			1
11	10944.7	SCREW	Was 6911869 -		2
12	6679034	BRACKET			1
13	01275.7	TIE, CABLE			1
14	6910771	WASHER			1
15	79527.8	BELT, ENGINE DRIVE			1
16	6919502	PROTECTOR, BELT			1
17	01605.5	SCREW			3
18	000350-03W	WASHER			3
19	6915334	SPACER			1
20	000350-20Q	WASHER			1
21	01602.2	SCREW			1
22	97610.0	WASHER			1
23	01697.2	WASHER			1
24	01578.4	SCREW			1

FLYWHEEL HOUSING AND STARTER



SPC006105

FLYWHEEL HOUSING AND STARTER

[illegible]

ENGINE GASKET SETS

1

Top Service Kit

2


Bottom Joints & Gasket Kit

SPC006017

ENGINE GASKET SETS

[illegible]

ACCELERATOR PEDAL STOP KIT




SPC007390

ACCELERATOR PEDAL STOP KIT

[illegible]

ADJUSTABLE HOOK




SPC007304

ADJUSTABLE HOOK

[illegible]

AIR CONDITIONING INSTALLATION




SPC007317

AIR CONDITIONING INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6915517	BELT PROTECTOR	Was 6914411 -		1
2	01578.4	SCREW			2
3	01697.2	WASHER			2
4	97610.0	WASHER			2
5	6908181	SPINDLE			1
6	90531.5	ROLLER			1
7	6914328	SPACER			1
8	6908180	SUPPORT			1
8	6919954	SUPPORT			1
9	000345-96E	NUT			1
10	01522.2	SCREW			1
11	000350-20Q	WASHER			1
12	100345-09A	NUT			1
13	90545.5	BELT, ALTERNATOR			1
14	01605.5	SCREW			3
15	000350-03W	WASHER			3
16	74335.1	PLUG			1
17	89644.9	COMPRESSOR			1
18	54009.6	SCREW			4
19	100345-09A	NUT			4
20	6909391	SUPPORT			1
21	89647.2	HOSE			1
22	81439.2	CONDENSER			1
23	88844.6	HOSE			1
24	6922536	SUPPORT	Was 6911207 -		2
25	66679.2	RIVET			6
26	85171.7	SCREW, THUMB			2
27	6924074	SUPPORT	Was 6911209 -		1
28	6924076	SUPPORT	Was 6911210 -		1
29	6913148	SPONGE, ADHESIVE			1
30	6925115	BAR, PROTECTION			1

AIR CONDITIONING INSTALLATION

Recurrence of previous drawing




SPC007317

AIR CONDITIONING INSTALLATION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
31	89643.1	FILTER, DRYER			1
32	89642.3	SWITCH			1
33	89641.5	BRACKET			1
34	01478.7	SCREW			2
35	01695.6	WASHER			4
36	100345-05V	NUT			2
37	89649.8	HOSE			1
38	89648.0	HOSE			1
39	15354.4	SCREW			1
40	13416.3	WASHER			1
41	88826.3	PLATE			1
42	88827.1	PROTECTOR			1
43	6910951	SCREW			3
44	98071.4	O-RING			1
45	98068.0	O-RING			1
46	97358.6	VALVE			1
47	98070.6	O-RING			1
48	98069.8	O-RING			1
49	97359.4	PLATE			1
50	96082.3	EVAPORATOR			1
51	97265.3	GRILL			2
52	97432.9	THERMOSTAT			1
53	41821.0	SCREW			2
54	01696.4	WASHER			2
55	71921.1	NUT			2
56	88830.5	PLATE			1
57	66679.2	RIVET			2
58	01591.7	SCREW			1
59	01696.4	WASHER			1
60	100345-06W	NUT			1
61	88848.7	HOSE			1

AIR CONDITIONING INSTALLATION

Recurrence of previous drawing




SPC007317

AIR CONDITIONING INSTALLATION

[illegible]

AIR PRE-CLEANER OPTION 1




SPC007299

AIR PRE-CLEANER OPTION 1

[illegible]

AIR PRE-CLEANER OPTION 2




SPC007298

AIR PRE-CLEANER OPTION 2

[illegible]

AIR SUSPENDED SEAT




SPC007379

AIR SUSPENDED SEAT

[illegible]

AUSTRALIAN VERSION




SPC007419

AUSTRALIAN VERSION

[illegible]

BACKUP ALARM




SPC007077

BACKUP ALARM

[illegible]

BALES PIKES AND PALLET FORK FRAME




SPC007413

[illegible]

BOBCAT DECALS

W/ Stabilizer




SPC007330

BOBCAT DECALS W/ Stabilizer

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	79523.7	DECAL	Do not ride forks		2
2	79524.5	DECAL	Do not stand under forks		2
3	79645.8	DECAL	Do not incline load		2
4	79525.2	DECAL	Safety distance		4
5	6925843	DECAL	Logo cab		2
6	76324.3	DECAL	Sound signal		1
7	6918709	LOAD CHART			1
8	6918710	DECAL, JOYSTICK			1
9	6565990	DECAL	hydraulic fill		1
10	96749.7	DECAL	106 dB		1
11	6925851	DECAL, ARM T35100	T35100 ; Was 6918708 -		1
11	6925852	DECAL, ARM T35100L	T35100L ; Was 6918707 -		1
11	6925853	DECAL, ARM T35100SL	T35100SL ; Was 6918706 -		1
12	6925950	DECAL, ARM T35100	T35100 ; Was 6918708 -		1
12	6925951	DECAL, ARM T35100L	T35100L ; Was 6918707 -		1
12	6925952	DECAL, ARM T35100SL	T35100SL ; Was 6918706 -		1
13		PLATE, SERIAL NO.	NAP		1
14	92762.4	DECAL	Engine		1
15	6925840	DECAL	Logo engine basket		1
16	79526.0	DECAL	Starting		1
17	6916450	PIN			4
18	6910594	DECAL	Oil level		1
19	6909446	DECAL	Sliding points		8
20		SLEEVE, SHRINK	Was 96928.7 -		1
20	6925959	DECAL, ARM BOBCAT	Was 96928.7 -		1
21		SLEEVE, SHRINK	Was 96928.7 -		1
21	6925946	DECAL, ARM BOBCAT	Was 96928.7 -		1

BOBCAT DECALS


W/O Stabilizer



SPC007331

[illegible]


BOOM SUPPORT KIT



SPC007240

[illegible]


BUCKET 1500L REINFORCEMENT KIT



SPC007236

[illegible]


BUCKET 2000L REINFORCEMENT KIT



SPC007237

[illegible]


BUCKET 2500L REINFORCEMENT KIT



SPC007238

[illegible]

CONCRETE BUCKET




SPC007032

CONCRETE BUCKET

[illegible]

DAMPER KIT




SPC007030

DAMPER KIT

[illegible]

DUNLOP 400/70-R20 150B WHEELS




SPC007115

DUNLOP 400/70-R20 150B WHEELS

[illegible]

DUNLOP 400/80-R24 156B WHEELS




SPC007155

DUNLOP 400/80-R24 156B WHEELS

[illegible]

DUNLOP 405/70-R20 SPT9 WHEELS




SPC007071

DUNLOP 405/70-R20 SPT9 WHEELS

[illegible]

ELECTRIC KIT FOR BROOM




SPC007403

ELECTRIC KIT FOR BROOM

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6925520	KIT, ELECTRIC, BOOM	W/Ref. 2-25		2
2	01590.9	SCREW			2
3	01603.0	SCREW			2
4	01696.4	WASHER			2
5	01698.0	WASHER			2
6	79531.0	CONNECTOR, FEMALE			1
7	79532.8	CONNECTOR			1
8	79541.9	CONNECTOR			1
9	79542.7	BLOCK, MALE			1
10	79551.8	CONNECTOR, MALE 6 POLES			1
11	79552.6	BLOCK			1
12	79555.9	CONNECTOR, MALE 12 POLE			1
13	79556.7	BLOCK			1
14	79557.5	CONNECTOR			2
15	84726.9	SHRINK SLEEVE			2
16	96604.4	SWITCH, AUX HYD			1
17	96627.5	CABLE PLUG			1
18	97546.6	PLUG			6
19	6908244	SUPPORT			1
20	6908258	BOX	For details, see page 223		1
21	6910955	RELAY, MICRO			1
22	6913433	WIRE HARNESS			1
23	6913913	WIRE HARNESS			1
24	6913916	SLEEVE, PROTECTION			1
25	6913917	SHRINK SLEEVE			1


FLOATING PALLET FORKS



SPC007033

[illegible]

FUEL PRE-FILTER KIT




SPC007028

FUEL PRE-FILTER KIT

[illegible]

HOOK




SPC007099

HOOK

[illegible]

HYDRAULIC TANK FILLING KIT




SPC007029

HYDRAULIC TANK FILLING KIT

[illegible]

JIG + HOOK




SPC007093

JIG + HOOK

[illegible]

LIFT CYLINDER ACCUMULATOR KIT

FOR 10 METER BOOM:




SPC007246

LIFT CYLINDER ACCUMULATOR KIT

[illegible]

LOUDSPEAKER PREDISPOSAL OPTION




SPC007199

LOUDSPEAKER PREDISPOSAL OPTION

[illegible]

MATRICULATION PLATE OPTION




SPC007336

MATRICULATION PLATE OPTION

[illegible]

MUDGUARD 20"




SPC007065

MUDGUARD 20"

[illegible]

MUDGUARD 24"




SPC007262

MUDGUARD 24"

[illegible]

REAR HYDRAULIC FUNCTION




SPC007347

REAR HYDRAULIC FUNCTION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6911079	HYDRAULIC BLOCK			1
2	6912535	SET OF PLUGS			1
3	68566.9	SCREW			2
4	98360.1	VALVE, CONTROL ELECTRIC			1
5	98353.6	PLATE			1
6	78743.2	PLUG, DRAIN			2
7	56029.2	PLUG			2
8	014375-30H	ADAPTER			1
9	6913675	HOSE			2
10	008372-21X	T-UNION			2
11	65614.0	UNION			1
12	65285.9	ELBOW			1
13	65784.1	PLUG			1
14	022375-28V	ADAPTER			2
15	100375-39T	UNION			2
* 16	6922004	HYDRAULIC TUBE			1
* 17	6922003	HYDRAULIC TUBE			1
18	100375-52H	ADAPTER			2
19	6910523	SUPPORT			1
20	29649.1	SCREW			2
21	89519.3	WASHER			2
22	022375-06W	ADAPTER			2
23	95994.0	COUPLER			1
24	96513.7	CAP			1
25	95993.2	COUPLER, FEMALE			1
26	96514.5	CAP			1
27	6910517	PROTECTION			1
28	100345-09A	NUT			2
29	6913675	HOSE			1
30	010370-90W	ELBOW			1
31	96599.6	SWITCH, REAR OPTION			1

REAR HYDRAULIC FUNCTION

Recurrence of previous drawing




SPC007347

REAR HYDRAULIC FUNCTION

[illegible]

REAR HYDRAULIC HOOK




SPC007368

REAR HYDRAULIC HOOK

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	000350-01U	WASHER			2
2	000350-08C	WASHER			4
3	008372-14Q	UNION, ELBOW			1
4	008372-21X	T-UNION			2
5	008372-34M	FITTING	t-union		1
6	010370-90W	ELBOW			1
7	014375-30H	ADAPTER			1
8	015370-11P	ELBOW			1
9	022375-28V	ADAPTER			2
10	39584.8	SCREW			4
11	43824.2	RIVET			4
12	48829.6	SCREW	T35100		2
12	80643.0	SCREW	T35100(S)L		2
13	56029.2	PLUG			3
14	65285.9	ELBOW			1
15	65614.0	UNION			1
16	6912535	SET OF PLUGS			1
17	65784.1	PLUG			1
18	68566.9	SCREW			2
19	78743.2	PLUG, DRAIN			2
20	96589.7	HARNESS, WIRE			1
21	96598.8	SWITCH			1
22		PLATE	NAP		1
23	98353.6	PLATE			1
24	98360.1	VALVE, CONTROL ELECTRIC			1
25	100345-06W	NUT			2
26	100345-20M	NUT			4
27	6911079	HYDRAULIC BLOCK			1
28	6911845	VALVE			1
29	6912226	HOSE			1
30	6913675	HOSE			1

REAR HYDRAULIC HOOK


Recurrence of previous drawing



SPC007368

[illegible]

REAR VIEW MIRROR





SPC007014

REAR VIEW MIRROR

[illegible]

RIGID FORKS HOLDER
W/ Back





SPC007035

RIGID FORKS HOLDER

W/ Back

[illegible]

RIGID FORKS HOLDER
W/O Back




SPC007417

RIGID FORKS HOLDER

W/O Back

[illegible]

TITAN 400/70-R20 WHEELS




SPC007070

TITAN 400/70-R20 WHEELS

[illegible]

TOOL ADAPTOR KIT







SPC007098

TOOL ADAPTOR KIT

[illegible]


TOOTHED BUCKET



SPC007039

[illegible]

TOOTHLESS BUCKETS




SPC007244

TOOTHLESS BUCKETS

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	80914.5	BUCKET	800L - W/Ref. 1-5		1
2	98167.0	PLATE			1
3	43824.2	RIVET			4
4	64012.8	BLADE			1
5	64010.2	WEDGE			2
6	80907.9	BUCKET	900L - W/Ref. 6-10		1
7	98167.0	PLATE			1
8	43824.2	RIVET			4
9	64011.0	BLADE			1
10	64010.2	WEDGE			2
11	6917410	BUCKET	1500L - W/Ref. 12-22		1
12	98167.0	PLATE,CE			1
13	43824.2	RIVET			4
14	78429.8	BLADE			1
15	84536.2	WEDGE			2
19	100215-01L	RIGHT PLATE			1
20	100215-02M	LEFT PLATE			1
22	72554.9	BLADE			1
23	6916616	BUCKET	2000L - W/Ref. 24-34		1
23	6917382	BUCKET	2500L - W/Ref. 24-34		1
24	98167.0	PLATE,CE			1
25	78429.8	BLADE			1
27	84536.2	WEDGE			1
28	43824.2	RIVET			4
29	72554.9	BLADE			1
30	100215-01L	RIGHT PLATE			1
31	100215-02M	LEFT PLATE			1
35	92790.5	PROTECTION FOR TOOTHLESS BUCKETS			1

TOW HITCH




SPC007062

TOW HITCH

[illegible]

TOW VALVE INSTALLATION




SPC007058

TOW VALVE INSTALLATION

[illegible]

TRAILER BRAKE




SPC007245

TRAILER BRAKE

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6913021	SUPPORT			1
2	000350-21R	WASHER			2
3	89516.9	WASHER			2
4	01605.5	SCREW			2
5	6915262	VALVE			1
6	89519.3	WASHER			2
7	10947.0	SCREW			2
8	96568.1	UNION			2
9	6913684	HOSE			1
10	010370-90W	ELBOW			1
11	6917394	HOSE	T35100(S)L ; Was 6911056 -		1
11	6913684	HOSE	T35100		1
12	100370-06P	ELBOW			1
13	6917437	TUBE			1
14	79170.7	COUPLING			1
15	6913650	HOSE			1
16	100375-38S	ADAPTER			1
17	96580.6	UNION			1
18	6916961	HOSE			1
19	100372-06G	FITTING	t-union		1
20	72294.2	ELBOW, UNION	T35100SL		1
21	022375-28V	ADAPTER	T35100SL		1
21	56028.4	PLUG	T35100(L)		1
22	100375-56M	ADAPTER			1
23	100375-56M	ADAPTER			

TRAILER BRAKE ITALY VERSION




SPC007410

TRAILER BRAKE ITALY VERSION

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	008372-28F	FITTING	t-union		1
2	010370-93A	ELBOW			1
3	014375-30H	ADAPTER			1
4	022375-04U	ADAPTER			2
5	65784.1	PLUG			2
6	79170.7	COUPLING			1
7	88271.2	SCREW			2
8	89519.3	WASHER			2
9	100372-06G	FITTING	T-union		3
10	6622655	VALVE			1
11	6913684	HOSE			1
12	6913684	HOSE			1
13	6916745	ADAPTER			2
14	6922966	VALVE, SUPPORT			1
15	6923062	HOSE			1
16	6923136	SWITCH, PRESSURE	232 PSI (16 bar)		1
17	6923401	SWITCH, PRESSURE	1450 PSI (100 bar)		1
18	6923537	HOSE			1
19	6923576	WIRE HARNESS			1
20	000350-01U	WASHER	T35100(S)L		4
21	48829.6	SCREW	T35100(S)L		2
22	6916641	HOSE	T35100(S)L		1
23	100345-06W	NUT	T35100(S)L		2
24	72294.2	ELBOW, UNION	T35100(S)L		1
25	022375-28V	ADAPTER	T35100(S)L		1
26	56028.4	PLUG	T35100L		1
27	6913684	HOSE	T35100		1

TRAILER PLUG




SPC007091

TRAILER PLUG

[illegible]

ULPYO HOOK




SPC007305

ULPYO HOOK

[illegible]

VALVE BRAKING SWITCH OPTION




SPC007151

VALVE BRAKING SWITCH OPTION

[illegible]

WHEEL WEDGE OPTION




SPC007169

WHEEL WEDGE OPTION

[illegible]

WINDSHIELD PROTECTION GRILL




SPC007253

WINDSHIELD PROTECTION GRILL

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	6912988	KIT, WINDOW FRONT GUARD	W/Ref. 2-34		
2	29272.2	WASHER			4
3	01591.7	SCREW			4
4	63332.1	CAP			4
5	63332.1	CAP			2
6	100345-06W	NUT			2
7	29272.2	WASHER			2
8	100520-18G	ABUTMENT, MALE	W/Ref. 8, 12		2
9	01593.3	SCREW			2
10	01591.7	SCREW			2
11	29272.2	WASHER			2
12	100520-19H	ABUTMENT, FEMALE	W/Ref. 8, 12		2
13	29272.2	WASHER			2
14	100345-06W	NUT			2
15	63332.1	CAP			2
16	6924352	GRILL	Was 6914657 -		1
17	63332.1	CAP			2
18	100345-06W	NUT			2
19	29272.2	WASHER			2
20	100520-19H	ABUTMENT, FEMALE	W/Ref. 20, 24		2
21	29272.2	WASHER			2
22	01591.7	SCREW			2
23	01593.3	SCREW			2
24	100520-18G	ABUTMENT, MALE	W/Ref. 20, 24		2
25	6914652	SUPPORT, LOWER	RH		1
26	6914651	SUPPORT, LOWER	LH		1
27	29272.2	WASHER			2
28	100345-06W	NUT			2
29	63332.1	CAP			2
30	63332.1	CAP			4
31	01591.7	SCREW			4

WINDSHIELD PROTECTION GRILL

Recurrence of previous drawing




SPC007253

WINDSHIELD PROTECTION GRILL

[illegible]

WORKING LIGHT




SPC007361

WORKING LIGHT

[illegible]

2ND HYDRAULIC FUNCTION ON BOOM




SPC007402

2ND HYDRAULIC FUNCTION ON BOOM

Item	Part Number	Denomination	Remarks	Serial Number	Qty
1	01511.5	SCREW			2
2	01605.5	SCREW			2
3	01698.0	WASHER			4
4	014375-30H	ADAPTER			4
5	022375-06W	ADAPTER			4
6	51851.4	NUT			2
7	79531.0	CONNECTOR, FEMALE			1
8	79532.8	CONNECTOR			1
9	92131.2	VALVE, SELECTOR			1
10	95791.0	PLATE			1
11	95993.2	COUPLER, FEMALE			2
12	95994.0	COUPLER			2
13	96513.7	CAP			2
14	96514.5	CAP			2
15	96604.4	SWITCH, AUX HYD			1
16	96627.5	CABLE PLUG			1
17	97721.5	CABLE			1
18	100371-06X	ELBOW			4
19	100375-52H	ADAPTER			2
20	6910955	RELAY, MICRO			1
21	6914645	PIPE			1
22	6914646	PIPE			1
23	6925741	HOUSING			1
24	01590.9	SCREW			2
25	01603.0	SCREW			2
26	01696.4	WASHER			2
27	79551.8	CONNECTOR, MALE 6 POLES			1
28	79552.6	BLOCK			1
29	79555.9	CONNECTOR, MALE 12 POLE			1
30	79556.7	BLOCK			1
31	97546.6	PLUG			6

2ND HYDRAULIC FUNCTION ON BOOM

Recurrence of previous drawing



SPC007402

2ND HYDRAULIC FUNCTION ON BOOM

[illegible]

Intentionally left blank

NUMERICAL INDEX

Part Number	Denomination	WAS	Page	Subgroup
			11	ENGINE COVER
000326-10V	SCREW		341	MATRICULATION PLATE OPTION
000326-25M	SCREW		165	HYDRAULIC CONTROL VALVE FIXATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
000329-42G	SCREW	13399.1	53	FIXED BOOM ASSY
		13399.1	57	FIXED BOOM ASSY
000338-54X	SCREW		9	FUEL TANK INSTALLATION
000341-05V	NUT		223	ELECTRICAL BOX AV
000345-96E	NUT		13	ENGINE BASKET
			115	TELESCOPE CYLINDER INSTALLATION
			225	ENGINE INSTALLATION
			285	AIR CONDITIONING INSTALLATION
			301	BALES PIKES AND PALLET FORK FRAME
			327	FLOATING PALLET FORKS
			357	RIGID FORKS HOLDER
			359	RIGID FORKS HOLDER
000348-12P	WASHER		47	REAR WINDOW INSTALLATION
000350-01U	WASHER		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			165	HYDRAULIC CONTROL VALVE FIXATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			195	ELECTRICAL CIRCUIT CHASSIS
			215	ELECTRIC CIRCUIT SECURITY
			347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
			375	TRAILER BRAKE ITALY VERSION
000350-02V	WASHER		11	ENGINE COVER
			135	HYDRAULIC TANK INSTALLATION
			195	ELECTRICAL CIRCUIT CHASSIS
			231	COOLING SYSTEM INSTALLATION
			299	BACKUP ALARM
000350-03W	WASHER		11	ENGINE COVER
			275	ALTERNATOR
			285	AIR CONDITIONING INSTALLATION
000350-04X	WASHER		225	ENGINE INSTALLATION
000350-06A	WASHER		15	CAB & FIXATIONS
000350-08C	WASHER		351	REAR HYDRAULIC HOOK
			369	TOW HITCH
000350-20Q	WASHER		11	ENGINE COVER
			49	WIPER INSTALLATION
			143	STABILIZER SELECTOR VALVES
			275	ALTERNATOR
			285	AIR CONDITIONING INSTALLATION
000350-21R	WASHER		3	CHASSIS
			21	CAB ASSY II
			165	HYDRAULIC CONTROL VALVE FIXATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			373	TRAILER BRAKE
000405-62P	BULB		195	ELECTRICAL CIRCUIT CHASSIS
001345-66S	NUT		141	STABILIZERS INSTALLATION
001350-04T	WASHER		345	MUDGUARD 24"
001369-22D	COLLAR		111	BOOM HYDRAULIC SUPPLY
			117	STEERING HOSES & FITTINGS (WITHOUT D

Part Number	Denomination	WAS	Page	Subgroup
003304-21D	O-RING		183	HYDROSTATIC HOSES AND FITTINGS
00350-03W	RONDELLE		225	ENGINE INSTALLATION
007330-29V	SCREW		225	ENGINE INSTALLATION
007346-02F	WASHER		21	CAB ASSY II
			211	JOYSTICK/SUSMIC INSTALLATION
			213	JOYSTICK / SUSMIC INSTALLATION
			341	MATRICATION PLATE OPTION
008338-06L	SCREW		379	ULPYO HOOK
008372-01B	ELBOW		237	COOLING FAN CIRCUIT
			239	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
008372-02C	FITTING		121	JOYSTICK INSTALLATION (WITH AMA)
			125	SERVICE BRAKE HYDRAULIC INSTALLATIO
008372-14Q	UNION, ELBOW		135	HYDRAULIC TANK INSTALLATION
			347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
008372-21X	T-UNION		347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
008372-28F	FITTING		113	LIFT & COMPENSATION CYLINDER INSTALL
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			375	TRAILER BRAKE ITALY VERSION
008372-34M	FITTING		135	HYDRAULIC TANK INSTALLATION
			183	HYDROSTATIC HOSES AND FITTINGS
			231	COOLING SYSTEM INSTALLATION
			351	REAR HYDRAULIC HOOK
009456-02D	WASHER		65	END BOOM ASSY
			69	END BOOM ASSY
010329-24T	SCREW		3	CHASSIS
010338-02X	SCREW		3	CHASSIS
010370-57L	ELBOW		65	END BOOM ASSY
			69	END BOOM ASSY
			107	BOOM HYDRAULIC SUPPLY FROM CONTRO
010370-87T	FITTING		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			143	STABILIZER SELECTOR VALVES
010370-90W	ELBOW		65	END BOOM ASSY
			69	END BOOM ASSY
			113	LIFT & COMPENSATION CYLINDER INSTALL
			347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
			373	TRAILER BRAKE
010370-93A	ELBOW		237	COOLING FAN CIRCUIT
			239	COOLING FAN CIRCUIT
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
			375	TRAILER BRAKE ITALY VERSION
010370-94B	FITTING		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			129	PARKING BRAKE HYDRAULIC INSTALLATIO
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
			143	STABILIZER SELECTOR VALVES
			161	HYDRAULIC PUMP INSTALLATION
01124.7	SPRING		31	PEDALS INSTALLATION
011374-44C	PLUG		225	ENGINE INSTALLATION
011374-62W	PLUG		135	HYDRAULIC TANK INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
01149.4	PIN		327	FLOATING PALLET FORKS
01275.7	TIE, CABLE		203 231 275	ELECTRICAL CIRCUIT ENGINE COOLING SYSTEM INSTALLATION ALTERNATOR
014345-12C	NUT		121	JOYSTICK INSTALLATION (WITH AMA)
014375-02C	FITTING		113 167	LIFT & COMPENSATION CYLINDER INSTALL HYDRAULIC CONTROL VALVE INSTALLATIO
014375-30H	ADAPTER		115 143 347 351 375 391	TELESCOPE CYLINDER INSTALLATION STABILIZER SELECTOR VALVES REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK TRAILER BRAKE ITALY VERSION 2ND HYDRAULIC FUNCTION ON BOOM
014375-33L	ADAPTER		183	HYDROSTATIC HOSES AND FITTINGS
014375-96E	CONNECTOR		183	HYDROSTATIC HOSES AND FITTINGS
014375-97F	ADAPTER		231	COOLING SYSTEM INSTALLATION
01443.1	BULB		21	CAB ASSY II
01478.7	SCREW		31 285	PEDALS INSTALLATION AIR CONDITIONING INSTALLATION
01508.1	SCREW		165 167	HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO
01511.5	SCREW		391	2ND HYDRAULIC FUNCTION ON BOOM
01519.8	SCREW		371	TOW VALVE INSTALLATION
01522.2	SCREW		275 285 301	ALTERNATOR AIR CONDITIONING INSTALLATION BALES PIKES AND PALLET FORK FRAME
01528.9	SCREW		225	ENGINE INSTALLATION
01534.7	SCREW		327	FLOATING PALLET FORKS
015370-11P	ELBOW		117 119 161 347 351	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP HYDRAULIC PUMP INSTALLATION REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
01547.9	SCREW		7 15	BALLAST CAB & FIXATIONS
01549.5	SCREW		7 15	BALLAST CAB & FIXATIONS
01575.0	SCREW		41	DOOR ASSY
01578.4	SCREW		125 143 275 285	SERVICE BRAKE HYDRAULIC INSTALLATIO STABILIZER SELECTOR VALVES ALTERNATOR AIR CONDITIONING INSTALLATION
01579.2	SCREW		41	DOOR ASSY
01590.9	SCREW		17 21 27 35 41 211 213 231 325 391	CAB ASSY CAB ASSY II HEATING/ VENTILATION INSTALLATION COWLING INSTALLATION DOOR ASSY JOYSTICK/SUSMIC INSTALLATION JOYSTICK / SUSMIC INSTALLATION COOLING SYSTEM INSTALLATION ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM

Part Number	Denomination	WAS	Page	Subgroup
			21	CAB ASSY II
			195	ELECTRICAL CIRCUIT CHASSIS
			225	ENGINE INSTALLATION
			285	AIR CONDITIONING INSTALLATION
			385	WINDSHIELD PROTECTION GRILL
01593.3	SCREW		121	JOYSTICK INSTALLATION (WITH AMA)
			385	WINDSHIELD PROTECTION GRILL
01594.1	SCREW	01595.8	299	BACKUP ALARM
01595.8	SCREW		41	DOOR ASSY
			53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			195	ELECTRICAL CIRCUIT CHASSIS
			225	ENGINE INSTALLATION
			237	COOLING FAN CIRCUIT
			239	COOLING FAN CIRCUIT
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
01596.6	SCREW		11	ENGINE COVER
			21	CAB ASSY II
			31	PEDALS INSTALLATION
			33	STEERING COLUMN INSTALLATION
			49	WIPER INSTALLATION
			53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
			195	ELECTRICAL CIRCUIT CHASSIS
			203	ELECTRICAL CIRCUIT ENGINE
			225	ENGINE INSTALLATION
			231	COOLING SYSTEM INSTALLATION
01597.4	SCREW		11	ENGINE COVER
			31	PEDALS INSTALLATION
			33	STEERING COLUMN INSTALLATION
			107	BOOM HYDRAULIC SUPPLY FROM CONTRO
			119	STEERING HOSES & FITTINGS (WITH DAMP
			135	HYDRAULIC TANK INSTALLATION
			217	SECURITY OPTION STABILIZERS/TELESCOP
			231	COOLING SYSTEM INSTALLATION
			275	ALTERNATOR
			281	ACCELERATOR PEDAL STOP KIT
			297	AUSTRALIAN VERSION
			307	BOOM SUPPORT KIT
			317	DAMPER KIT
01598.2	SCREW		195	ELECTRICAL CIRCUIT CHASSIS
			231	COOLING SYSTEM INSTALLATION
			377	TRAILER PLUG
01599.0	SCREW		337	LIFT CYLINDER ACCUMULATOR KIT
01602.2	SCREW		275	ALTERNATOR
			301	BALES PIKES AND PALLET FORK FRAME
01603.0	SCREW		41	DOOR ASSY
			325	ELECTRIC KIT FOR BROOM
			331	HOOK
			391	2ND HYDRAULIC FUNCTION ON BOOM
01604.8	SCREW		3	CHASSIS
			61	INTERMEDIATE BOOM

Part Number	Denomination	WAS	Page	Subgroup
			213	JOYSTICK / SUSMIC INSTALLATION
01605.5	SCREW		31	PEDALS INSTALLATION
			107	BOOM HYDRAULIC SUPPLY FROM CONTRO
			203	ELECTRICAL CIRCUIT ENGINE
			225	ENGINE INSTALLATION
			229	EXHAUST SYSTEM
			275	ALTERNATOR
			285	AIR CONDITIONING INSTALLATION
			373	TRAILER BRAKE
			389	WORKING LIGHT
			391	2ND HYDRAULIC FUNCTION ON BOOM
01606.3	SCREW		15	CAB & FIXATIONS
			41	DOOR ASSY
			229	EXHAUST SYSTEM
			329	FUEL PRE-FILTER KIT
01607.1	SCREW		3	CHASSIS
			15	CAB & FIXATIONS
		01606.3	215	ELECTRIC CIRCUIT SECURITY
01608.9	SCREW		31	PEDALS INSTALLATION
			165	HYDRAULIC CONTROL VALVE FIXATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			225	ENGINE INSTALLATION
01610.5	SCREW		3	CHASSIS
01613.9	SCREW		115	TELESCOPE CYLINDER INSTALLATION
			183	HYDROSTATIC HOSES AND FITTINGS
			301	BALES PIKES AND PALLET FORK FRAME
			357	RIGID FORKS HOLDER
			359	RIGID FORKS HOLDER
01614.7	SCREW		75	AXLE INSTALLATION
01615.4	SCREW		115	TELESCOPE CYLINDER INSTALLATION
01620.4	SCREW		301	BALES PIKES AND PALLET FORK FRAME
		96467.6	351	REAR HYDRAULIC HOOK
		96467.6	355	REAR VIEW MIRROR
			357	RIGID FORKS HOLDER
			359	RIGID FORKS HOLDER
01634.5	SCREW		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
01636.0	SCREW		115	TELESCOPE CYLINDER INSTALLATION
01639.4	SCREW		135	HYDRAULIC TANK INSTALLATION
01640.2	SCREW		225	ENGINE INSTALLATION
01657.6	SCREW		15	CAB & FIXATIONS
01664.2	NUT		21	CAB ASSY II
01665.9	NUT		37	CONTROL PANEL SWITCHES
			203	ELECTRICAL CIRCUIT ENGINE
01666.7	NUT		21	CAB ASSY II
			41	DOOR ASSY
			121	JOYSTICK INSTALLATION (WITH AMA)
			203	ELECTRICAL CIRCUIT ENGINE
			211	JOYSTICK/SUSMIC INSTALLATION
			213	JOYSTICK / SUSMIC INSTALLATION
			215	ELECTRIC CIRCUIT SECURITY
01668.3	NUT		41	DOOR ASSY
			49	WIPER INSTALLATION
			231	COOLING SYSTEM INSTALLATION
01669.1	NUT		31	PEDALS INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
01670.9	NUT		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
01672.5	NUT		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			301	BALES PIKES AND PALLET FORK FRAME
01681.6	NUT		11	ENGINE COVER
			47	REAR WINDOW INSTALLATION
01682.4	NUT		11	ENGINE COVER
01683.2	NUT		165	HYDRAULIC CONTROL VALVE FIXATION
01695.6	WASHER		285	AIR CONDITIONING INSTALLATION
01696.4	WASHER		17	CAB ASSY
			21	CAB ASSY II
			41	DOOR ASSY
			121	JOYSTICK INSTALLATION (WITH AMA)
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
			285	AIR CONDITIONING INSTALLATION
			325	ELECTRIC KIT FOR BROOM
01697.2	WASHER		391	2ND HYDRAULIC FUNCTION ON BOOM
			31	PEDALS INSTALLATION
			33	STEERING COLUMN INSTALLATION
			41	DOOR ASSY
			53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			119	STEERING HOSES & FITTINGS (WITH DAMP
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
			195	ELECTRICAL CIRCUIT CHASSIS
			211	JOYSTICK/SUSMIC INSTALLATION
			225	ENGINE INSTALLATION
			231	COOLING SYSTEM INSTALLATION
			275	ALTERNATOR
			281	ACCELERATOR PEDAL STOP KIT
			285	AIR CONDITIONING INSTALLATION
			307	BOOM SUPPORT KIT
			317	DAMPER KIT
01698.0	WASHER	93433.1	229	EXHAUST SYSTEM
			275	ALTERNATOR
			325	ELECTRIC KIT FOR BROOM
			391	2ND HYDRAULIC FUNCTION ON BOOM
01699.8	WASHER		75	AXLE INSTALLATION
01701.2	WASHER		9	FUEL TANK INSTALLATION
			15	CAB & FIXATIONS
01717.8	WASHER		21	CAB ASSY II
			27	HEATING/ VENTILATION INSTALLATION
			41	DOOR ASSY
			49	WIPER INSTALLATION
			211	JOYSTICK/SUSMIC INSTALLATION
			213	JOYSTICK / SUSMIC INSTALLATION
01718.6	WASHER		231	COOLING SYSTEM INSTALLATION
			11	ENGINE COVER
			41	DOOR ASSY
			107	BOOM HYDRAULIC SUPPLY FROM CONTRO
			135	HYDRAULIC TANK INSTALLATION
			195	ELECTRICAL CIRCUIT CHASSIS
			225	ENGINE INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
01719.4	WASHER		3 41	CHASSIS DOOR ASSY
01720.2	WASHER		213	JOYSTICK / SUSMIC INSTALLATION
01735.0	PIN, ROLL		133	QUICK ATTACH INSTALLATION
01739.2	PIN		31	PEDALS INSTALLATION
01744.2	PIN, ROLL		133	QUICK ATTACH INSTALLATION
01745.9	PIN, ROLL		133	QUICK ATTACH INSTALLATION
01754.1	PIN		31	PEDALS INSTALLATION
01763.2	PIN		335	JIG + HOOK
01775.6	NIPPLE, GREASE		3 53 57 61 63 65 69 113	CHASSIS FIXED BOOM ASSY FIXED BOOM ASSY INTERMEDIATE BOOM INTERMEDIATE BOOM END BOOM ASSY END BOOM ASSY LIFT & COMPENSATION CYLINDER INSTALL
01779.8	NIPPLE, GREASE		65 69	END BOOM ASSY END BOOM ASSY
01782.2	NIPPLE, GREASE		141	STABILIZERS INSTALLATION
018472-83R	CABLE, GROUND		203	ELECTRICAL CIRCUIT ENGINE
022375-04U	ADAPTER	014375-30H	139 141 161 241 243 375	FRAME LEVEL INSTALLATION STABILIZERS INSTALLATION HYDRAULIC PUMP INSTALLATION COOLING FAN CIRCUIT COOLING FAN CIRCUIT TRAILER BRAKE ITALY VERSION
022375-06W	ADAPTER		65 69 113 347 391	END BOOM ASSY END BOOM ASSY LIFT & COMPENSATION CYLINDER INSTALL REAR HYDRAULIC FUNCTION 2ND HYDRAULIC FUNCTION ON BOOM
022375-27U	ADAPTER		133	QUICK ATTACH INSTALLATION
022375-28V	ADAPTER		133 141 167 347 351 373 375	QUICK ATTACH INSTALLATION STABILIZERS INSTALLATION HYDRAULIC CONTROL VALVE INSTALLATIO REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK TRAILER BRAKE TRAILER BRAKE ITALY VERSION
022375-30X	ADAPTER		167	HYDRAULIC CONTROL VALVE INSTALLATIO
022375-31Z	ADAPTER		121 167	JOYSTICK INSTALLATION (WITH AMA) HYDRAULIC CONTROL VALVE INSTALLATIO
05698.6	WASHER		35	COWLING INSTALLATION
06734.8	RING, RETAINING		139	FRAME LEVEL INSTALLATION
100074-53R	MANUAL CONCRETE SKIP		315	CONCRETE BUCKET
100083-13B	FORK		327	FLOATING PALLET FORKS
100212-53R	PLATE		117 119	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP
100215-01L	RIGHT PLATE		367	TOOTHLESS BUCKETS
100215-02M	LEFT PLATE		367	TOOTHLESS BUCKETS
100228-57K	COVER		351	REAR HYDRAULIC HOOK

Part Number	Denomination	WAS	Page	Subgroup
100288-01V	BUSH		327	FLOATING PALLET FORKS
100328-05X	SCREW		145	LIFT CYLINDER
100329-01C	SCREW		195	ELECTRICAL CIRCUIT CHASSIS
100329-07J	SCREW		115	TELESCOPE CYLINDER INSTALLATION
100329-22A	SCREW		123	AMA - INSTALLATION
100331-01U	SCREW		35	COWLING INSTALLATION
100338-07M	SCREW		15	CAB & FIXATIONS
100338-15V	SCREW		75	AXLE INSTALLATION
100338-23F	SCREW		21 351 355	CAB ASSY II REAR HYDRAULIC HOOK REAR VIEW MIRROR
100345-04U	NUT		15 21 211 213 215 217 297 341	CAB & FIXATIONS CAB ASSY II JOYSTICK/SUSMIC INSTALLATION JOYSTICK / SUSMIC INSTALLATION ELECTRIC CIRCUIT SECURITY SECURITY OPTION STABILIZERS/TELESCOP AUSTRALIAN VERSION MATRICULATION PLATE OPTION
100345-05V	NUT		31 107 143 199 201 241 243 285 377	PEDALS INSTALLATION BOOM HYDRAULIC SUPPLY FROM CONTRO STABILIZER SELECTOR VALVES ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB COOLING FAN CIRCUIT COOLING FAN CIRCUIT AIR CONDITIONING INSTALLATION TRAILER PLUG
100345-06W	NUT		117 119 125 129 131 165 167 195 225 285 347 351 375 385	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP SERVICE BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO ELECTRICAL CIRCUIT CHASSIS ENGINE INSTALLATION AIR CONDITIONING INSTALLATION REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK TRAILER BRAKE ITALY VERSION WINDSHIELD PROTECTION GRILL
100345-09A	NUT		3 11 15 31 65 69 107 141 165 167 203 215 225 229 275	CHASSIS ENGINE COVER CAB & FIXATIONS PEDALS INSTALLATION END BOOM ASSY END BOOM ASSY BOOM HYDRAULIC SUPPLY FROM CONTRO STABILIZERS INSTALLATION HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO ELECTRICAL CIRCUIT ENGINE ELECTRIC CIRCUIT SECURITY ENGINE INSTALLATION EXHAUST SYSTEM ALTERNATOR

Part Number	Denomination	WAS	Page	Subgroup
			301	BALES PIKES AND PALLET FORK FRAME
			329	FUEL PRE-FILTER KIT
			347	REAR HYDRAULIC FUNCTION
			371	TOW VALVE INSTALLATION
			389	WORKING LIGHT
100345-11C	NUT		75	AXLE INSTALLATION
100345-15G	NUT		15	CAB & FIXATIONS
100345-16H	NUT		9	FUEL TANK INSTALLATION
			13	ENGINE BASKET
			15	CAB & FIXATIONS
			139	FRAME LEVEL INSTALLATION
100345-20M	NUT		283	ADJUSTABLE HOOK
			331	HOOK
			351	REAR HYDRAULIC HOOK
			369	TOW HITCH
			379	ULPYO HOOK
100345-34C	NUT		183	HYDROSTATIC HOSES AND FITTINGS
100369-18T	CLAMP, SPLIT		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
100369-39Q	CLAMP		27	HEATING/ VENTILATION INSTALLATION
100369-55H	CLAMP		231	COOLING SYSTEM INSTALLATION
100369-80K	CLAMP		27	HEATING/ VENTILATION INSTALLATION
			231	COOLING SYSTEM INSTALLATION
100370-05N	ELBOW		241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
100370-06P	ELBOW		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			373	TRAILER BRAKE
100370-18C	FITTING		123	AMA - INSTALLATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			337	LIFT CYLINDER ACCUMULATOR KIT
100370-29P	FITTING		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			139	FRAME LEVEL INSTALLATION
			143	STABILIZER SELECTOR VALVES
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
100370-31R	ELBOW UNION		161	HYDRAULIC PUMP INSTALLATION
100370-40B	FITTING, ELBOW		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			139	FRAME LEVEL INSTALLATION
100371-06X	ELBOW		391	2ND HYDRAULIC FUNCTION ON BOOM
100372-06G	FITTING		131	PARKING BRAKE HYDRAULIC INSTALLATIO
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			373	TRAILER BRAKE
			375	TRAILER BRAKE ITALY VERSION
			381	VALVE BRAKING SWITCH OPTION
100372-08J	T-UNION		113	LIFT & COMPENSATION CYLINDER INSTALL
100372-23A	TEE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
100374-14H	PLUG		9	FUEL TANK INSTALLATION
			231	COOLING SYSTEM INSTALLATION
100375-06H	ADAPTER		121	JOYSTICK INSTALLATION (WITH AMA)
100375-15S	REDUCER		183	HYDROSTATIC HOSES AND FITTINGS
100375-17U	FITTING		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
100375-36Q	UNION		331	HOOK

Part Number	Denomination	WAS	Page	Subgroup
100375-38S	ADAPTER		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			143	STABILIZER SELECTOR VALVES
			161	HYDRAULIC PUMP INSTALLATION
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
100375-39T	UNION		373	TRAILER BRAKE
100375-39T	UNION		113	LIFT & COMPENSATION CYLINDER INSTALL
			347	REAR HYDRAULIC FUNCTION
100375-40U	ADAPTER		167	HYDRAULIC CONTROL VALVE INSTALLATIO
			183	HYDROSTATIC HOSES AND FITTINGS
			237	COOLING FAN CIRCUIT
			239	COOLING FAN CIRCUIT
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
100375-42W	ADAPTER		143	STABILIZER SELECTOR VALVES
100375-52H	ADAPTER		347	REAR HYDRAULIC FUNCTION
			391	2ND HYDRAULIC FUNCTION ON BOOM
100375-56M	ADAPTER		75	AXLE INSTALLATION
			117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			373	TRAILER BRAKE
100375-59Q	UNION		237	COOLING FAN CIRCUIT
			239	COOLING FAN CIRCUIT
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
100378-03F	VALVE, SHUTOFF		371	TOW VALVE INSTALLATION
100405-05S	LIGHT BULB		341	MATRICULATION PLATE OPTION
100411-05U	RELAY		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
100416-32S	INCLINOMETER		15	CAB & FIXATIONS
100417-11D	HORN		195	ELECTRICAL CIRCUIT CHASSIS
100425-12Z	TYRE		319	DUNLOP 400/70-R20 150B WHEELS
100426-06B	VALVE, AIR		319	DUNLOP 400/70-R20 150B WHEELS
			321	DUNLOP 400/80-R24 156B WHEELS
			323	DUNLOP 405/70-R20 SPT9 WHEELS
			361	TITAN 400/70-R20 WHEELS
100454-05T	WASHER		13	ENGINE BASKET
			141	STABILIZERS INSTALLATION
100454-17G	WASHER		183	HYDROSTATIC HOSES AND FITTINGS
100520-18G	ABUTMENT, MALE		385	WINDSHIELD PROTECTION GRILL
100520-19H	ABUTMENT, FEMALE		385	WINDSHIELD PROTECTION GRILL
101319-27P	HOSE		117	STEERING HOSES & FITTINGS (WITHOUT D
101438-93V	LIGHT, DOME		21	CAB ASSY II
101472-20M	DIODE		191	HYDROSTATIC MOTOR ASSY
10167.5	SCREW		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			129	PARKING BRAKE HYDRAULIC INSTALLATIO
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
			135	HYDRAULIC TANK INSTALLATION
			161	HYDRAULIC PUMP INSTALLATION
10662.5	SCREW		135	HYDRAULIC TANK INSTALLATION
			161	HYDRAULIC PUMP INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
			13	ENGINE BASKET
			141	STABILIZERS INSTALLATION
			165	HYDRAULIC CONTROL VALVE FIXATION
10897.7	WASHER		335	JIG + HOOK
10942.1	SCREW		301	BALES PIKES AND PALLET FORK FRAME
10944.7	SCREW	6911869	15	CAB & FIXATIONS
			275	ALTERNATOR
10947.0	SCREW		167	HYDRAULIC CONTROL VALVE INSTALLATIO
			195	ELECTRICAL CIRCUIT CHASSIS
			373	TRAILER BRAKE
11464.5	WASHER		379	ULPYO HOOK
11689.7	WASHER		115	TELESCOPE CYLINDER INSTALLATION
11734.1	CLAMP		231	COOLING SYSTEM INSTALLATION
12597.1	SCREW		141	STABILIZERS INSTALLATION
12940.3	CLIP		389	WORKING LIGHT
12K8	SWIVEL		231	COOLING SYSTEM INSTALLATION
13399.1	SCREW		113	LIFT & COMPENSATION CYLINDER INSTALL
			225	ENGINE INSTALLATION
13415.5	WASHER		3	CHASSIS
			37	CONTROL PANEL SWITCHES
			195	ELECTRICAL CIRCUIT CHASSIS
			203	ELECTRICAL CIRCUIT ENGINE
13416.3	WASHER		129	PARKING BRAKE HYDRAULIC INSTALLATIO
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
			203	ELECTRICAL CIRCUIT ENGINE
			285	AIR CONDITIONING INSTALLATION
13778.6	WASHER		15	CAB & FIXATIONS
14039.2	SCREW		225	ENGINE INSTALLATION
14507.8	WASHER		389	WORKING LIGHT
15323.9	WASHER		75	AXLE INSTALLATION
			283	ADJUSTABLE HOOK
			301	BALES PIKES AND PALLET FORK FRAME
			351	REAR HYDRAULIC HOOK
			355	REAR VIEW MIRROR
			357	RIGID FORKS HOLDER
			359	RIGID FORKS HOLDER
			379	ULPYO HOOK
15354.4	SCREW		15	CAB & FIXATIONS
			125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			285	AIR CONDITIONING INSTALLATION
15798.2	SCREW		139	FRAME LEVEL INSTALLATION
26160.2	SCREW		161	HYDRAULIC PUMP INSTALLATION
26261.8	CLIP		341	MATRICULATION PLATE OPTION
26267.5	SLEEVE		341	MATRICULATION PLATE OPTION
26278.2	OIL PRESSURE SWITCH		203	ELECTRICAL CIRCUIT ENGINE
27052.0	BUSH		139	FRAME LEVEL INSTALLATION
27089.2	BULB		195	ELECTRICAL CIRCUIT CHASSIS
27362.3	BULB		195	ELECTRICAL CIRCUIT CHASSIS
28439.8	SCREW	10882.9	183	HYDROSTATIC HOSES AND FITTINGS
			215	ELECTRIC CIRCUIT SECURITY
			225	ENGINE INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
29272.2	WASHER		17	CAB ASSY
			21	CAB ASSY II
			41	DOOR ASSY
			211	JOYSTICK/SUSMIC INSTALLATION
			213	JOYSTICK / SUSMIC INSTALLATION
			385	WINDSHIELD PROTECTION GRILL
29649.1	SCREW		73	MANUAL QUICK ATTACH LOCK
			133	QUICK ATTACH INSTALLATION
			295	AIR SUSPENDED SEAT
			347	REAR HYDRAULIC FUNCTION
29713.5	CLAMP		225	ENGINE INSTALLATION
31825.3	CLIP		65	END BOOM ASSY
			69	END BOOM ASSY
32397.2	SCREW		41	DOOR ASSY
			47	REAR WINDOW INSTALLATION
			295	AIR SUSPENDED SEAT
33219.7	PLUG		251	CYLINDER HEAD INSTALLATION
			253	CYLINDER HEAD ASSY
			257	TIMING GEAR
33786.5	SCREW		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
34765.8	RING, COPPER		231	COOLING SYSTEM INSTALLATION
35497.7	SCREW		365	TOOTHED BUCKET
35949.7	CLAMP		225	ENGINE INSTALLATION
			291	AIR PRE-CLEANER OPTION 1
36925.6	ELEMENT, OIL FILTER		269	OIL COOLER AND FILTER
37469.4	SCREW		47	REAR WINDOW INSTALLATION
37872.9	SCREW		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
38025.3	WASHER		135	HYDRAULIC TANK INSTALLATION
38441.2	UNION		225	ENGINE INSTALLATION
38632.6	PIN		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			65	END BOOM ASSY
			69	END BOOM ASSY
38683.9	CLAMP		225	ENGINE INSTALLATION
			293	AIR PRE-CLEANER OPTION 2
39079.9	SCREW		377	TRAILER PLUG
39584.8	SCREW		331	HOOK
			351	REAR HYDRAULIC HOOK
			369	TOW HITCH
40968.0	PLUG		253	CYLINDER HEAD ASSY
41282.5	SOLENOID		191	HYDROSTATIC MOTOR ASSY
41821.0	SCREW		285	AIR CONDITIONING INSTALLATION
43088.4	CLIP		327	FLOATING PALLET FORKS
43824.2	RIVET		301	BALES PIKES AND PALLET FORK FRAME
			327	FLOATING PALLET FORKS
			335	JIG + HOOK
			351	REAR HYDRAULIC HOOK
			357	RIGID FORKS HOLDER
			359	RIGID FORKS HOLDER
			365	TOOTHED BUCKET
			367	TOOTHLESS BUCKETS
44001.6	SCREW		53	FIXED BOOM ASSY

Part Number	Denomination	WAS	Page	Subgroup
44334.1	NUT		13	ENGINE BASKET
45515.4	SCREW		223	ELECTRICAL BOX AV
46854.6	WASHER, THRUST	46854.2	247	CRANKSHAFT - PISTONS
46893.4	WASHER, THRUST		247	CRANKSHAFT - PISTONS
48792.6	CHAIN, BULK		73 307	MANUAL QUICK ATTACH LOCK BOOM SUPPORT KIT
48829.6	SCREW		117 119 165 167 347 351 375	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK TRAILER BRAKE ITALY VERSION
50917.4	COLLAR		217 297	SECURITY OPTION STABILIZERS/TELESCOP AUSTRALIAN VERSION
51851.4	NUT		11 31 33 41 119 125 131 135 139 143 167 195 203 211 217 225 231 275 281 297 307 317 337 377 391	ENGINE COVER PEDALS INSTALLATION STEERING COLUMN INSTALLATION DOOR ASSY STEERING HOSES & FITTINGS (WITH DAMP SERVICE BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO HYDRAULIC TANK INSTALLATION FRAME LEVEL INSTALLATION STABILIZER SELECTOR VALVES HYDRAULIC CONTROL VALVE INSTALLATIO ELECTRICAL CIRCUIT CHASSIS ELECTRICAL CIRCUIT ENGINE JOYSTICK/SUSMIC INSTALLATION SECURITY OPTION STABILIZERS/TELESCOP ENGINE INSTALLATION COOLING SYSTEM INSTALLATION ALTERNATOR ACCELERATOR PEDAL STOP KIT AUSTRALIAN VERSION BOOM SUPPORT KIT DAMPER KIT LIFT CYLINDER ACCUMULATOR KIT TRAILER PLUG 2ND HYDRAULIC FUNCTION ON BOOM
53100.4	SCREW	92642.8	215 217 297	ELECTRIC CIRCUIT SECURITY SECURITY OPTION STABILIZERS/TELESCOP AUSTRALIAN VERSION
54009.6	SCREW		225 285	ENGINE INSTALLATION AIR CONDITIONING INSTALLATION
54090.6	VALVE, PRESSURE RELIEF		175 177 179	HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO HYDRAULIC CONTROL VALVE TELESCOPE
54194.6	GAUGE		135	HYDRAULIC TANK INSTALLATION
54367.8	SWITCH, PRESSURE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
55438.6	SWITCH, IGNITION		37	CONTROL PANEL SWITCHES
55698.5	GEAR		249	FLYWHEEL AND DRIVE PULLEY
56028.4	PLUG		167 373 375	HYDRAULIC CONTROL VALVE INSTALLATIO TRAILER BRAKE TRAILER BRAKE ITALY VERSION

Part Number	Denomination	WAS	Page	Subgroup
			347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
56726.3	WASHER		7	BALLAST
57189.3	SET OF KEYS (IGNITION)		9	FUEL TANK INSTALLATION
			37	CONTROL PANEL SWITCHES
			41	DOOR ASSY
57506.8	SCREW	6911871	275	ALTERNATOR
57702.3	PLUG		3	CHASSIS
57752.8	FUSE		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
57753.6	FUSE		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
57792.4	FUSE		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
			285	AIR CONDITIONING INSTALLATION
57793.2	FUSE		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
			207	VENTILATION REVERSE ELECTRICAL
57796.5	SEAL		17	CAB ASSY
			47	REAR WINDOW INSTALLATION
58158.7	RING		73	MANUAL QUICK ATTACH LOCK
			307	BOOM SUPPORT KIT
58446.6	BULB		21	CAB ASSY II
			199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
58880.6	WASHER		139	FRAME LEVEL INSTALLATION
59736.9	REFLECTOR		7	BALLAST
59893.8	PAD, PEDAL		31	PEDALS INSTALLATION
60794.5	TOOTH SUPPORT		365	TOOTHED BUCKET
60795.2	LOCK		365	TOOTHED BUCKET
61358.8	COLLAR		351	REAR HYDRAULIC HOOK
			355	REAR VIEW MIRROR
61378.6	WASHER		21	CAB ASSY II
			215	ELECTRIC CIRCUIT SECURITY
61416.4	SCREW		211	JOYSTICK/SUSMIC INSTALLATION
			213	JOYSTICK / SUSMIC INSTALLATION
61677.1	SEAL		223	ELECTRICAL BOX AV
62185.4	SCREW		31	PEDALS INSTALLATION
62231.6	CLAMP		9	FUEL TANK INSTALLATION
			231	COOLING SYSTEM INSTALLATION
			329	FUEL PRE-FILTER KIT
62925.3	FRAME, PALLET FORK HOLD		301	BALES PIKES AND PALLET FORK FRAME
			357	RIGID FORKS HOLDER
			359	RIGID FORKS HOLDER
62926.1	PLATE, SPLASH		301	BALES PIKES AND PALLET FORK FRAME
			357	RIGID FORKS HOLDER
62932.9	PROTECTION		365	TOOTHED BUCKET
62948.5	PROTECTION		365	TOOTHED BUCKET
63332.1	CAP		17	CAB ASSY
			21	CAB ASSY II
			41	DOOR ASSY
			49	WIPER INSTALLATION
		6910992		

Part Number	Denomination	WAS	Page	Subgroup
63333.9	NUT, CAP		41 49	DOOR ASSY WIPER INSTALLATION
63334.7	NUT, CAP		41	DOOR ASSY
63349.5	HANDLE		17	CAB ASSY
63359.4	SCREW		33	STEERING COLUMN INSTALLATION
63848.6	UNION, T		49	WIPER INSTALLATION
63860.1	MIRROR		351 355	REAR HYDRAULIC HOOK REAR VIEW MIRROR
64010.2	WEDGE		365 367	TOOTHED BUCKET TOOTHLESS BUCKETS
64011.0	BLADE		367	TOOTHLESS BUCKETS
64012.8	BLADE		367	TOOTHLESS BUCKETS
64120.9	FUSE		199 201	ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB
64509.3	GLUE		17 41	CAB ASSY DOOR ASSY
64624.0	OLIVE		261	FUEL INJECTION EQUIPMENT
64627.3	BUSHING		245	CYLINDER BLOCK
64628.1	SCREW		245	CYLINDER BLOCK
64648.9	SEAL		277	FLYWHEEL HOUSING AND STARTER
64752.9	O-RING, ENGINE OIL DRAIN		259	OIL SUMP - OIL PUMP
64753.7	PLUG, ENGINE OIL DRAIN	66753.7	259	OIL SUMP - OIL PUMP
64878.2	SCREW		257 259 261 271 273	TIMING GEAR OIL SUMP - OIL PUMP FUEL INJECTION EQUIPMENT WATER PUMP AND THERMOSTAT TURBOCHARGER
64960.8	SCREW		257 269	TIMING GEAR OIL COOLER AND FILTER
64988.9	STUD		245	CYLINDER BLOCK
65226.3	PIN		369	TOW HITCH
65285.9	ELBOW		65 69 113 347 351	END BOOM ASSY END BOOM ASSY LIFT & COMPENSATION CYLINDER INSTALL REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
65397.2	SCREW		3 65 69	CHASSIS END BOOM ASSY END BOOM ASSY
65438.4	HOSE		133	QUICK ATTACH INSTALLATION
65614.0	UNION		113 167 347 351	LIFT & COMPENSATION CYLINDER INSTALL HYDRAULIC CONTROL VALVE INSTALLATIO REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
65641.3	ADAPTER		113	LIFT & COMPENSATION CYLINDER INSTALL
6565990	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
65715.5	HOSE	6916629	125 139 241	SERVICE BRAKE HYDRAULIC INSTALLATIO FRAME LEVEL INSTALLATION COOLING FAN CIRCUIT
65718.9	HOSE	6913611	237	COOLING FAN CIRCUIT

Part Number	Denomination	WAS	Page	Subgroup
65723.9	UNION		331	HOOK
65764.3	CIRCUIT BREAKER		195	ELECTRICAL CIRCUIT CHASSIS
65784.1	PLUG		37 347 351 375	CONTROL PANEL SWITCHES REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK TRAILER BRAKE ITALY VERSION
6587458	SET OF KEYS (FUEL CAP)		9	FUEL TANK INSTALLATION
6622655	VALVE		375	TRAILER BRAKE ITALY VERSION
6625575	FUSE		285	AIR CONDITIONING INSTALLATION
66341.9	SEAL		229	EXHAUST SYSTEM
66362.5	KIT, SEAL		153	QUICK ATTACH CYLINDER
66392.2	NUT		153	QUICK ATTACH CYLINDER
66419.3	KIT, SEAL		157	STABILIZER CYLINDER
66425.0	SCREW		75	AXLE INSTALLATION
6661114	CAP, FUEL		9	FUEL TANK INSTALLATION
6661696	CAP, FUEL (WITH LOCK)		9	FUEL TANK INSTALLATION
66679.2	RIVET		285	AIR CONDITIONING INSTALLATION
66748.5	HOSE		141	STABILIZERS INSTALLATION
6679034	BRACKET		275	ALTERNATOR
6684424	BLOWER		29	HEATING/VENTILATION FAN ASSY
6684425	CASE		29	HEATING/VENTILATION FAN ASSY
6684426	GRILLE		29	HEATING/VENTILATION FAN ASSY
6684427	RADIATOR		29	HEATING/VENTILATION FAN ASSY
6684428	MOUNT		29	HEATING/VENTILATION FAN ASSY
6684429	ROD		29	HEATING/VENTILATION FAN ASSY
6684430	LEVER		29	HEATING/VENTILATION FAN ASSY
6684431	CLIP		29	HEATING/VENTILATION FAN ASSY
67046.3	ADAPTER		183 371	HYDROSTATIC HOSES AND FITTINGS TOW VALVE INSTALLATION
67166.9	SPINDLE		139	FRAME LEVEL INSTALLATION
67198.2	HOSE		139	FRAME LEVEL INSTALLATION
67368.1	PLUG		17	CAB ASSY
6809599	PLATE		17	CAB ASSY
6809625	DECAL, DOOR LOGO		305	BOBCAT DECALS
6809627	DECAL, BOTOM SIDE ENGIN		305	BOBCAT DECALS
68509.9	SCREW		9	FUEL TANK INSTALLATION
68566.9	SCREW		37 347 351	CONTROL PANEL SWITCHES REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
68609.7	FITTING	6910603	135 167 231	HYDRAULIC TANK INSTALLATION HYDRAULIC CONTROL VALVE INSTALLATIO COOLING SYSTEM INSTALLATION
68656.8	MOUNTING BLOCK		139	FRAME LEVEL INSTALLATION
6901596	GREASE		195 199 201 203 207	ELECTRICAL CIRCUIT CHASSIS ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT ENGINE VENTILATION REVERSE ELECTRICAL

Part Number	Denomination	WAS	Page	Subgroup
			211	JOYSTICK/SUSMIC INSTALLATION
			213	JOYSTICK / SUSMIC INSTALLATION
			215	ELECTRIC CIRCUIT SECURITY
			217	SECURITY OPTION STABILIZERS/TELESCOP
			219	STABILIZERS 25° LOCKING OPTION
			221	ELECTRICAL CIRCUIT ARM
6908071	SUPPORT		225	ENGINE INSTALLATION
6908091	FLANGE		135	HYDRAULIC TANK INSTALLATION
			161	HYDRAULIC PUMP INSTALLATION
6908165	PLATE, REAR		11	ENGINE COVER
6908170	PIN		13	ENGINE BASKET
6908180	SUPPORT		285	AIR CONDITIONING INSTALLATION
6908181	SPINDLE		285	AIR CONDITIONING INSTALLATION
6908244	SUPPORT		325	ELECTRIC KIT FOR BROOM
			391	2ND HYDRAULIC FUNCTION ON BOOM
6908248	PLATE		3	CHASSIS
6908252	BRACKET, WHEEL WEDGE		383	WHEEL WEDGE OPTION
6908253	BOX		223	ELECTRICAL BOX AV
6908258	BOX		223	ELECTRICAL BOX AV
			325	ELECTRIC KIT FOR BROOM
			391	2ND HYDRAULIC FUNCTION ON BOOM
6908280	CABLE, 7 WIRE		223	ELECTRICAL BOX AV
6908281	CABLE, 5 WIRE		223	ELECTRICAL BOX AV
6908363	CAP, RAIN-PROOF		225	ENGINE INSTALLATION
6908476	STEERING COLUMN		33	STEERING COLUMN INSTALLATION
6908477	STEERING WHEEL		33	STEERING COLUMN INSTALLATION
6908478	PEDAL, BRAKE	6917795	31	PEDALS INSTALLATION
6908479	SHAFT, PEDAL		31	PEDALS INSTALLATION
6908594	HOSE		121	JOYSTICK INSTALLATION (WITH AMA)
6908595	HOSE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6908633	FORKS LOCK		327	FLOATING PALLET FORKS
6908638	STOP		327	FLOATING PALLET FORKS
6908656	DRIFT		327	FLOATING PALLET FORKS
6908659	FORKS SUPPORT		327	FLOATING PALLET FORKS
6908663	PLATE		225	ENGINE INSTALLATION
6908672	HOSE		121	JOYSTICK INSTALLATION (WITH AMA)
6908786	WINDOW, ROOF		17	CAB ASSY
6908787	WINDOW, REAR CAB		47	REAR WINDOW INSTALLATION
6908788	WINDOW, PANEL		17	CAB ASSY
6908789	WINDOW, LH		21	CAB ASSY II
6908790	WINDSHIELD		17	CAB ASSY
6908791	WINDOW, LOWER PART DO		41	DOOR ASSY
6908792	WINDOW, UPPER PART DOO		41	DOOR ASSY
6908847	SEAL		13	ENGINE BASKET
6908901	HOSE, EXPANSION TANK		231	COOLING SYSTEM INSTALLATION
6908902	HOSE		231	COOLING SYSTEM INSTALLATION
6908903	OUTER BOOM		57	FIXED BOOM ASSY

Part Number	Denomination	WAS	Page	Subgroup
6908976	SPINDLE	96341.3	307	BOOM SUPPORT KIT
6909020	PLATE		11	ENGINE COVER
6909072	SHOE		115	TELESCOPE CYLINDER INSTALLATION
6909091	INNER BOOM		69	END BOOM ASSY
6909097	CARRIAGE		65 69	END BOOM ASSY END BOOM ASSY
6909105	CYLINDER ASSY		113 145	LIFT & COMPENSATION CYLINDER INSTALL LIFT CYLINDER
6909127	FRONT SUPPORT		141	STABILIZERS INSTALLATION
6909128	WASHER		141	STABILIZERS INSTALLATION
6909142	ARM		141	STABILIZERS INSTALLATION
6909143	SHOE		141	STABILIZERS INSTALLATION
6909147	SPINDLE		3	CHASSIS
6909150	SPINDLE		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
6909153	SPINDLE		53 57 113	FIXED BOOM ASSY FIXED BOOM ASSY LIFT & COMPENSATION CYLINDER INSTALL
6909154	PIVOT PIN		113	LIFT & COMPENSATION CYLINDER INSTALL
6909156	PIPE		143	STABILIZER SELECTOR VALVES
6909205	SPACER		211 213	JOYSTICK/SUSMIC INSTALLATION JOYSTICK / SUSMIC INSTALLATION
6909206	SUPPORT		211	JOYSTICK/SUSMIC INSTALLATION
6909214	PIPE ASSY		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6909220	SUPPORT		115	TELESCOPE CYLINDER INSTALLATION
6909222	SHOE		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
6909224	CHAIN		69	END BOOM ASSY
6909225	CHAIN		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
6909226	CHAIN		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6909253	HOSE		113	LIFT & COMPENSATION CYLINDER INSTALL
6909321	TYRE		361	TITAN 400/70-R20 WHEELS
6909362	ACCUMULATOR		337	LIFT CYLINDER ACCUMULATOR KIT
6909363	VALVE, LIFT CYLINDER		113	LIFT & COMPENSATION CYLINDER INSTALL
6909383	SWITCH, INCHING (DETECT		31 199 201	PEDALS INSTALLATION ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB
6909391	SUPPORT		285	AIR CONDITIONING INSTALLATION
6909412	VALVE		115	TELESCOPE CYLINDER INSTALLATION
6909434	HOSE		131	PARKING BRAKE HYDRAULIC INSTALLATIO
6909439	BUSH		3	CHASSIS
6909446	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
6909447	HYDRAULIC PUMP ASSY		117 119 135 161 163	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP HYDRAULIC TANK INSTALLATION HYDRAULIC PUMP INSTALLATION HYDRAULIC PUMP ASSY

Part Number	Denomination	WAS	Page	Subgroup
6909611	LOCK ASSY		9	FUEL TANK INSTALLATION
6909675	SCREW		141	STABILIZERS INSTALLATION
6909681	PLATE		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6909711	PLUG, ELECTRIC		377	TRAILER PLUG
6909712	PLUG		3	CHASSIS
6909730	SUPPORT		377	TRAILER PLUG
6909739	UNION		135	HYDRAULIC TANK INSTALLATION
6909767	FUSE		203	ELECTRICAL CIRCUIT ENGINE
6909780	TUBELINE		183	HYDROSTATIC HOSES AND FITTINGS
6909872	TRAILER FITTING OPTION		369	TOW HITCH
6909903	CLIP		35 49	COWLING INSTALLATION WIPER INSTALLATION
6909904	COVER		35	COWLING INSTALLATION
6909930	SEAL		35	COWLING INSTALLATION
6909931	SEAL		35	COWLING INSTALLATION
6909932	SEAL		35	COWLING INSTALLATION
6909933	SEAL		35	COWLING INSTALLATION
6909934	SEAL		35	COWLING INSTALLATION
6909935	SEAL		33	STEERING COLUMN INSTALLATION
6909955	BULB		195	ELECTRICAL CIRCUIT CHASSIS
6909959	RIVET		17	CAB ASSY
6909961	PLATE		21	CAB ASSY II
6909963	WASHER		49	WIPER INSTALLATION
6909964	WASHER		49	WIPER INSTALLATION
6909973	BELLOW, STEERING COLU		35	COWLING INSTALLATION
6909977	PLATE		31 33	PEDALS INSTALLATION STEERING COLUMN INSTALLATION
6909993	SCREW		33	STEERING COLUMN INSTALLATION
6909995	SCREW		35	COWLING INSTALLATION
6909997	SCREW		17	CAB ASSY
6910150	SCREW		13	ENGINE BASKET
6910161	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
6910206	VALVE, AMA		123	AMA - INSTALLATION
6910208	VALVE		165 167	HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO
6910210	HOSE		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6910213	DOOR, BATTERY		9	FUEL TANK INSTALLATION
6910264	HOSE		231	COOLING SYSTEM INSTALLATION
6910272	SEAL		13	ENGINE BASKET
6910278	PLATE		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6910307	SHOE		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6910313	PLATE		37	CONTROL PANEL SWITCHES
6910322	SUPPORT		225	ENGINE INSTALLATION
6910326	SUPPORT		225	ENGINE INSTALLATION
6910328	PIN		225	ENGINE INSTALLATION
6910390	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO

Part Number	Denomination	WAS	Page	Subgroup
6910496	TUBE		7	BALLAST
6910502	FILTER, CAB		21	CAB ASSY II
6910503	BOX, FILTER		21	CAB ASSY II
6910504	SEAL		21	CAB ASSY II
6910505	SCREW		21 35 37 49	CAB ASSY II COWLING INSTALLATION CONTROL PANEL SWITCHES WIPER INSTALLATION
6910517	PROTECTION		347	REAR HYDRAULIC FUNCTION
6910523	SUPPORT		347	REAR HYDRAULIC FUNCTION
6910539	HANDLE		41	DOOR ASSY
6910542	STOP, RUBBER		17	CAB ASSY
6910547	HOOK		41	DOOR ASSY
6910552	LOCK		21	CAB ASSY II
6910558	LOCKING STABILIZER SWIT		37	CONTROL PANEL SWITCHES
6910560	LEFT STABILIZER SWITCH		37	CONTROL PANEL SWITCHES
6910561	RIGHT STABILIZER SWITCH		37	CONTROL PANEL SWITCHES
6910573	HOSE		135	HYDRAULIC TANK INSTALLATION
6910594	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
6910599	HOSE		135 183	HYDRAULIC TANK INSTALLATION HYDROSTATIC HOSES AND FITTINGS
6910602	HOSE		135	HYDRAULIC TANK INSTALLATION
6910622	HOSE		237 239 241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6910649	ABUTMENT, PEDAL		31 33	PEDALS INSTALLATION STEERING COLUMN INSTALLATION
6910697	SCREW		21 211 213	CAB ASSY II JOYSTICK/SUSMIC INSTALLATION JOYSTICK / SUSMIC INSTALLATION
6910699	PIPE	97207.5	27	HEATING/ VENTILATION INSTALLATION
6910702	PLATE		209	JOYSTICK
6910703	BELLOWS		209	JOYSTICK
6910704	KIT, REGULATION		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910705	REGULATOR		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910706	ELEMENT, OUTLET		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910707	KIT, TIE ROD		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910708	SET OF SEALS		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910709	PLUG, PIPE THREAD		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910710	SET OF SEALS		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910712	HYDRAULIC OPERATION		175 177	HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO
6910713	SET OF SEALS		175 177 179	HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO HYDRAULIC CONTROL VALVE TELESCOPE
6910714	SPOOL RETURN		179 181	HYDRAULIC CONTROL VALVE TELESCOPE HYDRAULIC CONTROL VALVE AUXILIARY H

Part Number	Denomination	WAS	Page	Subgroup
			181	HYDRAULIC CONTROL VALVE AUXILIARY H
6910717	SET OF SEALS		179	HYDRAULIC CONTROL VALVE TELESCOPE
			181	HYDRAULIC CONTROL VALVE AUXILIARY H
6910718	ELECTROHYDRO. ACTUATIO		181	HYDRAULIC CONTROL VALVE AUXILIARY H
6910719	FILTER		181	HYDRAULIC CONTROL VALVE AUXILIARY H
6910724	AIR FILTER COVER		225	ENGINE INSTALLATION
6910725	FILTER, AIR OUTER		225	ENGINE INSTALLATION
6910726	FILTER, AIR INNER		225	ENGINE INSTALLATION
6910727	RING		225	ENGINE INSTALLATION
6910728	LEVER ASSY		209	JOYSTICK
6910733	UPPER DOOR ASSY	6909925	41	DOOR ASSY
6910734	DOOR, UPPER	6910509	41	DOOR ASSY
6910735	UPPER DOOR AND WINDOW		41	DOOR ASSY
6910736	LOWER DOOR ASSY	6909923	41	DOOR ASSY
6910737	DOOR, LOWER	6910510	41	DOOR ASSY
6910738	LOWER DOOR AND WINDO		41	DOOR ASSY
6910741	PLUG		135	HYDRAULIC TANK INSTALLATION
6910742	ELEMENT, INLET		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910743	ELEMENT, EQUIPMENT		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910745	ELEMENT, TELESCOPE		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910748	ELEMENT, TILTING		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910749	ELEMENT, LIFTING		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
6910769	PIPE		115	TELESCOPE CYLINDER INSTALLATION
6910771	WASHER		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			275	ALTERNATOR
6910786	HOSE		141	STABILIZERS INSTALLATION
6910798	HOSE		371	TOW VALVE INSTALLATION
6910822	COLLECTOR		139	FRAME LEVEL INSTALLATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
6910836	HOSE		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
6910842	CHANNEL		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6910878	ROOF, COWLING		21	CAB ASSY II
6910882	COWLING, INSTRUMENT PA		35	COWLING INSTALLATION
6910883	COWLING, STEERING COLU		35	COWLING INSTALLATION
6910891	WIRE HARNESS		195	ELECTRICAL CIRCUIT CHASSIS
6910892	WIRE HARNESS		195	ELECTRICAL CIRCUIT CHASSIS
6910895	SWITCH, AUX. HYDR.		37	CONTROL PANEL SWITCHES
6910908	INSULATION		17	CAB ASSY
			21	CAB ASSY II
6910909	INSULATION		7	BALLAST
6910929	GRILLE, INTERNAL		21	CAB ASSY II
6910930	GUIDE		17	CAB ASSY
6910931	PLUG		17	CAB ASSY
6910932	NUT		17	CAB ASSY
6910933	SPACER		17	CAB ASSY

Part Number	Denomination	WAS	Page	Subgroup
6910935	SCREW		17	CAB ASSY
6910946	CATCH		21	CAB ASSY II
6910947	PROTECTOR, CATCH		21	CAB ASSY II
6910948	FIXATION, CATCH		21	CAB ASSY II
6910949	WASHER		21	CAB ASSY II
6910951	SCREW		37 285	CONTROL PANEL SWITCHES AIR CONDITIONING INSTALLATION
6910952	WASHER		31 199 201	PEDALS INSTALLATION ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB
6910953	SPACER	98473.2	37 121	CONTROL PANEL SWITCHES JOYSTICK INSTALLATION (WITH AMA)
6910955	RELAY, MICRO		199 201 219 325 391	ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB STABILIZERS 25° LOCKING OPTION ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
6910966	SUPPORT		231	COOLING SYSTEM INSTALLATION
6910970	HOSE, LOWER RADIATOR		231	COOLING SYSTEM INSTALLATION
6910975	SPACER		47	REAR WINDOW INSTALLATION
6910976	WASHER		47 49	REAR WINDOW INSTALLATION WIPER INSTALLATION
6910977	WASHER		47	REAR WINDOW INSTALLATION
6910978	GUIDE		47	REAR WINDOW INSTALLATION
6910979	GUIDE		47	REAR WINDOW INSTALLATION
6910981	TUBELINE		49	WIPER INSTALLATION
6910982	WASHER, PIPE		49	WIPER INSTALLATION
6910983	TUBELINE		49	WIPER INSTALLATION
6910984	SPACER		41	DOOR ASSY
6910988	WASHER		41	DOOR ASSY
6910989	SPACER		41	DOOR ASSY
6910990	WASHER		41	DOOR ASSY
6910991	WASHER		41	DOOR ASSY
6910993	HOOK		41	DOOR ASSY
6910994	LOCK, COVER		41	DOOR ASSY
6910996	SCREW		41	DOOR ASSY
6910997	SCREW		41	DOOR ASSY
6910999	SCREW		21	CAB ASSY II
6911000	SEAL		41	DOOR ASSY
6911001	SEAL		41	DOOR ASSY
6911006	ROOF WIPER ARM	6911712	49	WIPER INSTALLATION
6911011	DECAL		319	DUNLOP 400/70-R20 150B WHEELS
6911013	DECAL		361	TITAN 400/70-R20 WHEELS
6911019	DECAL		323	DUNLOP 405/70-R20 SPT9 WHEELS
6911028	HOSE		241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6911054	HOSE		141	STABILIZERS INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
6911079	HYDRAULIC BLOCK		143 347 351	STABILIZER SELECTOR VALVES REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
6911081	FRAME LEVEL SELECTOR V		139	FRAME LEVEL INSTALLATION
6911082	VALVE, HYDRAULIC		139	FRAME LEVEL INSTALLATION
6911140	HYDRAULIC FILTER		135	HYDRAULIC TANK INSTALLATION
6911143	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6911235	KEY		115	TELESCOPE CYLINDER INSTALLATION
6911249	PLATE		11	ENGINE COVER
6911253	SILL PLATE		11	ENGINE COVER
6911276	INDICATOR FILING		225	ENGINE INSTALLATION
6911325	TRANSMISSION BOX		199 211	ELECTRICAL CIRCUIT CAB JOYSTICK/SUSMIC INSTALLATION
6911357	WIRE, HARNESS		195	ELECTRICAL CIRCUIT CHASSIS
6911377	ALTERNATOR		203 275	ELECTRICAL CIRCUIT ENGINE ALTERNATOR
6911382	CLAMP		275	ALTERNATOR
6911383	BRACKET, ALTERNATOR		275	ALTERNATOR
6911384	SPACER		275	ALTERNATOR
6911400	SWITCH, WATER TEMP		203	ELECTRICAL CIRCUIT ENGINE
6911476	SEAL		13	ENGINE BASKET
6911486	ACCUMULATOR		131	PARKING BRAKE HYDRAULIC INSTALLATIO
6911728	SWITCH, LOCKING		37	CONTROL PANEL SWITCHES
6911733	FUSE BOX		201	ELECTRICAL CIRCUIT CAB
6911735	WIRE HARNESS		389	WORKING LIGHT
6911736	WIRE HARNESS		107 221	BOOM HYDRAULIC SUPPLY FROM CONTRO ELECTRICAL CIRCUIT ARM
6911737	WIRE HARNESS		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6911738	SWITCH		215	ELECTRIC CIRCUIT SECURITY
6911746	SEAL		231	COOLING SYSTEM INSTALLATION
6911759	PLUG		231	COOLING SYSTEM INSTALLATION
6911767	FLANGE		135 161	HYDRAULIC TANK INSTALLATION HYDRAULIC PUMP INSTALLATION
6911769	SEAT ASSY		21 25	CAB ASSY II SEAT & SUSPENSION
6911798	HUB		237 239 241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6911812	COLLAR		131	PARKING BRAKE HYDRAULIC INSTALLATIO
6911817	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6911845	VALVE		165 167 347 351	HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
6911846	SCREW		27	HEATING/ VENTILATION INSTALLATION
6911851	SCREW		249	FLYWHEEL AND DRIVE PULLEY
6911853	CLIP		259 261	OIL SUMP - OIL PUMP FUEL INJECTION EQUIPMENT

Part Number	Denomination	WAS	Page	Subgroup
6911854	KEY, WOODRUFF		247 255	CRANKSHAFT - PISTONS ROCKER SHAFT
6911856	OLIVE		261	FUEL INJECTION EQUIPMENT
6911857	NUT		261	FUEL INJECTION EQUIPMENT
6911858	PLUG		245 253	CYLINDER BLOCK CYLINDER HEAD ASSY
6911859	PLUG		245	CYLINDER BLOCK
6911862	WASHER		273	TURBOCHARGER
6911863	WASHER		265	FUEL FEEDING
6911864	WASHER		255	ROCKER SHAFT
6911865	SCREW		267	CYLINDER HEAD COVER
6911868	STUD		273	TURBOCHARGER
6911873	SCREW		271	WATER PUMP AND THERMOSTAT
6911874	SCREW		261	FUEL INJECTION EQUIPMENT
6911875	SCREW		255	ROCKER SHAFT
6911876	SCREW		255	ROCKER SHAFT
6911877	WASHER		261	FUEL INJECTION EQUIPMENT
6911878	O-RING		267	CYLINDER HEAD COVER
6911879	O-RING		267	CYLINDER HEAD COVER
6911880	O-RING		269	OIL COOLER AND FILTER
6911881	O-RING		253	CYLINDER HEAD ASSY
6911883	O-RING, OIL FILTER		265 269	FUEL FEEDING OIL COOLER AND FILTER
6911885	O-RING		271	WATER PUMP AND THERMOSTAT
6911886	O-RING		271	WATER PUMP AND THERMOSTAT
6911887	SEAL, OIL HOUSING		245	CYLINDER BLOCK
6911890	CLIP		251 265	CYLINDER HEAD INSTALLATION FUEL FEEDING
6911891	PLUG		255	ROCKER SHAFT
6911893	PLUG		245	CYLINDER BLOCK
6911894	PLUG		257	TIMING GEAR
6911895	THERMOSTAT		203	ELECTRICAL CIRCUIT ENGINE
6911896	COOLER		269	OIL COOLER AND FILTER
6911897	KIT, CONROD		247	CRANKSHAFT - PISTONS
6911902	PIPE, FEEDING		265	FUEL FEEDING
6911904	HOSE		261	FUEL INJECTION EQUIPMENT
6911907	FILTER ASSY, FUEL		265	FUEL FEEDING
6911908	PLUG, GLOW		261	FUEL INJECTION EQUIPMENT
6911910	RING, SNAP		255	ROCKER SHAFT
6911911	SWITCH, WATER TEMP		203 251	ELECTRICAL CIRCUIT ENGINE CYLINDER HEAD INSTALLATION
6911912	HEAD, FILTER		269	OIL COOLER AND FILTER
6911913	MOTOR, STARTER		203 277	ELECTRICAL CIRCUIT ENGINE FLYWHEEL HOUSING AND STARTER
6911914	BUSHING		247	CRANKSHAFT - PISTONS
6911915	BUSHING		245	CYLINDER BLOCK

Part Number	Denomination	WAS	Page	Subgroup
6911918	GEAR	9611918	261	FUEL INJECTION EQUIPMENT
6911919	GEAR		257	TIMING GEAR
6911924	SPRING		255	ROCKER SHAFT
6911926	SPRING		267	CYLINDER HEAD COVER
6911927	DIPSTICK		259	OIL SUMP - OIL PUMP
6911928	PLUG		245	CYLINDER BLOCK
6911929	SCREW		247	CRANKSHAFT - PISTONS
6911932	PLUG		245	CYLINDER BLOCK
6911933	SCREW	6911033	251	CYLINDER HEAD INSTALLATION
6911934	SCREW		251	CYLINDER HEAD INSTALLATION
6911935	BOLT, BANJO		273	TURBOCHARGER
6911936	PLUG		245	CYLINDER BLOCK
6911937	PLUG		245	CYLINDER BLOCK
6911938	PLUG		269	OIL COOLER AND FILTER
6911939	PLUG		253	CYLINDER HEAD ASSY
6911940	PLUG, OIL FILTER		269	OIL COOLER AND FILTER
6911942	SPACER		259	OIL SUMP - OIL PUMP
6911950	HOSE		267	CYLINDER HEAD COVER
6911956	PIPE		259	OIL SUMP - OIL PUMP
6911957	PIPE		273	TURBOCHARGER
6911960	PLATE		267	CYLINDER HEAD COVER
6911961	PLATE, LIFTING		251	CYLINDER HEAD INSTALLATION
6911964	PLATE		245	CYLINDER BLOCK
6911965	BRIDGE PIECE		259	OIL SUMP - OIL PUMP
6911966	BRACKET		261	FUEL INJECTION EQUIPMENT
6911967	PLATE, LIFTING		251	CYLINDER HEAD INSTALLATION
6911968	SEAL		267	CYLINDER HEAD COVER
6911970	GASKET		259	OIL SUMP - OIL PUMP
6911971	GASKET		257	TIMING GEAR
6911973	GASKET		273	TURBOCHARGER
6911974	GASKET		271	WATER PUMP AND THERMOSTAT
6911975	GASKET		251	CYLINDER HEAD INSTALLATION
6911977	GASKET, OIL COOLER		269	OIL COOLER AND FILTER
6911978	GASKET		273	TURBOCHARGER
6911979	GASKET		273	TURBOCHARGER
6911980	GASKET		273	TURBOCHARGER
6911983	GASKET		245 269	CYLINDER BLOCK OIL COOLER AND FILTER
6911986	PAN, OIL		259	OIL SUMP - OIL PUMP
6911989	CLAMP		261	FUEL INJECTION EQUIPMENT
6911991	CONNECTION		265	FUEL FEEDING
6911992	ELBOW, EXHAUST		273	TURBOCHARGER
6911993	MANIFOLD		273	TURBOCHARGER
6911994	CAP		267	CYLINDER HEAD COVER
6911995	CAP		267	CYLINDER HEAD COVER

Part Number	Denomination	WAS	Page	Subgroup
6911997	DIAPHRAGM		267	CYLINDER HEAD COVER
6912005	SPINDLE ASSY		255	ROCKER SHAFT
6912007	DIPSTICK TUBE ASSY		259	OIL SUMP - OIL PUMP
6912008	PIPE ASSY		273	TURBOCHARGER
6912010	PUMP, OIL		259	OIL SUMP - OIL PUMP
6912011	PIPE ASSY		271	WATER PUMP AND THERMOSTAT
6912012	WATER INLET ASSY		271	WATER PUMP AND THERMOSTAT
6912019	KIT, JOINT AND GASKET		279	ENGINE GASKET SETS
6912020	KIT, JOINT AND GASKET		279	ENGINE GASKET SETS
6912021	KIT, MAIN BEARING		247	CRANKSHAFT - PISTONS
6912029	KIT, CRANKSHAFT		247	CRANKSHAFT - PISTONS
6912031	KIT, BIG END BEARING		247	CRANKSHAFT - PISTONS
6912032	KIT, BIG END BEARING		247	CRANKSHAFT - PISTONS
6912033	KIT, BIG END BEARING		247	CRANKSHAFT - PISTONS
6912034	KIT, MAIN BEARING		247	CRANKSHAFT - PISTONS
6912035	KIT, MAIN BEARING		247	CRANKSHAFT - PISTONS
6912036	KIT, MAIN BEARING		247	CRANKSHAFT - PISTONS
6912038	CAP		261	FUEL INJECTION EQUIPMENT
6912039	CONNECTOR		265	FUEL FEEDING
6912040	KIT, CONROD		247	CRANKSHAFT - PISTONS
6912041	KIT, CONROD		247	CRANKSHAFT - PISTONS
6912042	KIT, CONROD		247	CRANKSHAFT - PISTONS
6912043	KIT, CONROD		247	CRANKSHAFT - PISTONS
6912044	KIT, CONROD		247	CRANKSHAFT - PISTONS
6912046	GEAR, CRANKSHAFT		247	CRANKSHAFT - PISTONS
6912047	PLUG		257	TIMING GEAR
6912051	SCREW		245	CYLINDER BLOCK
6912054	WASHER, THRUST		247	CRANKSHAFT - PISTONS
6912055	WASHER, THRUST		247	CRANKSHAFT - PISTONS
6912056	SCREW		259 277	OIL SUMP - OIL PUMP FLYWHEEL HOUSING AND STARTER
6912057	SCREW		267	CYLINDER HEAD COVER
6912058	HOUSING		185	HYDROSTATIC PUMP ASSY
6912059	BEARING		185	HYDROSTATIC PUMP ASSY
6912060	LEVER		185	HYDROSTATIC PUMP ASSY
6912061	SUPPORT		185	HYDROSTATIC PUMP ASSY
6912062	SCREW		185	HYDROSTATIC PUMP ASSY
6912063	PIN		185	HYDROSTATIC PUMP ASSY
6912064	SEAL		185	HYDROSTATIC PUMP ASSY
6912065	HOUSING		185	HYDROSTATIC PUMP ASSY
6912066	PLUG		185	HYDROSTATIC PUMP ASSY
6912067	SCREW		185	HYDROSTATIC PUMP ASSY
6912068	SCREW		185	HYDROSTATIC PUMP ASSY
6912069	VALVE		185	HYDROSTATIC PUMP ASSY
6912070	ADAPTOR		185	HYDROSTATIC PUMP ASSY

Part Number	Denomination	WAS	Page	Subgroup
6912073	INNER RING		157	STABILIZER CYLINDER
6912074	CYLINDER		157	STABILIZER CYLINDER
6912075	GREASE NIPPLE		157	STABILIZER CYLINDER
6912076	VALVE		157	STABILIZER CYLINDER
6912082	INNER RING		151	TILT CYLINDER
6912084	CYLINDER BODY		151	TILT CYLINDER
6912085	PISTON		147 151	COMPENSATION CYLINDER TILT CYLINDER
6912091	CYLINDER BODY		147	COMPENSATION CYLINDER
6912094	CAP, DUST		77	CARDAN SHAFT
6912095	U-JOINT		77	CARDAN SHAFT
6912097	NIPPLE, GREASE		77	CARDAN SHAFT
6912098	WASHER		77	CARDAN SHAFT
6912099	WASHER, CORK		77	CARDAN SHAFT
6912110	CYLINDER		153	QUICK ATTACH CYLINDER
6912111	SPINDLE		153	QUICK ATTACH CYLINDER
6912118	KIT, SEAL		155	FRAME LEVEL CYLINDER
6912119	ROD		155	FRAME LEVEL CYLINDER
6912120	O-RING		155	FRAME LEVEL CYLINDER
6912126	ELECTROHYDRAULIC ACTU		179	HYDRAULIC CONTROL VALVE TELESCOPE
6912157	SEAL, KIT		159	HYDRAULIC MOTOR
6912158	LIFT PUMP ASSY		265	FUEL FEEDING
6912159	SPRING RETAINER		191	HYDROSTATIC MOTOR ASSY
6912160	VALVE		51	PARKING BRAKE LEVER
6912161	COPPER SEAL		51	PARKING BRAKE LEVER
6912162	MANOCONTACT		51	PARKING BRAKE LEVER
6912163	LEVER		51	PARKING BRAKE LEVER
6912164	AXLE		51	PARKING BRAKE LEVER
6912165	WASHER STARLOCK		51	PARKING BRAKE LEVER
6912226	HOSE		347 351	REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
6912269	INSULATION		11	ENGINE COVER
6912354	BOOM SUPPORT ASSY		307	BOOM SUPPORT KIT
6912354P	PACKING LIST		307	BOOM SUPPORT KIT
6912426	WORKING LIGHT KIT		389	WORKING LIGHT
6912428	SUPPORT		143	STABILIZER SELECTOR VALVES
6912458	COWLING, JOYSTICK		35	COWLING INSTALLATION
6912467	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912484	HYDR. CONTROL VALVE AS		135 173 175 177 179 181	HYDRAULIC TANK INSTALLATION HYDRAULIC CONTROL VALVE:IN- AND OUTL HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO HYDRAULIC CONTROL VALVE TELESCOPE HYDRAULIC CONTROL VALVE AUXILIARY H
6912485	HINGE		11	ENGINE COVER
6912493	HOSE		121 123	JOYSTICK INSTALLATION (WITH AMA) AMA - INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
6912500	SET OF SEALS		147	COMPENSATION CYLINDER
6912501	SPACER		145	LIFT CYLINDER
6912502	CYLINDER HEAD		147	COMPENSATION CYLINDER
6912503	BUSH		147	COMPENSATION CYLINDER
6912504	CAP GREASE NIPPLE		147 151 157	COMPENSATION CYLINDER TILT CYLINDER STABILIZER CYLINDER
6912506	ROD		147	COMPENSATION CYLINDER
6912507	ROD		145	LIFT CYLINDER
6912508	BUSHING		145	LIFT CYLINDER
6912509	HEAD, CYLINDER		145	LIFT CYLINDER
6912510	ROD		151	TILT CYLINDER
6912511	CYLINDER HEAD		151	TILT CYLINDER
6912514	PISTON		149	TELESCOPE CYLINDER
6912515	STOP		149	TELESCOPE CYLINDER
6912516	RING		149	TELESCOPE CYLINDER
6912518	CYLINDER HEAD		149	TELESCOPE CYLINDER
6912519	KIT, SEAL		149	TELESCOPE CYLINDER
6912520	SET OF SEALS		151	TILT CYLINDER
6912521	KIT, SEAL		145	LIFT CYLINDER
6912522	VALVE		163	HYDRAULIC PUMP ASSY
6912523	SET OF SEALS FOR VALVE		163	HYDRAULIC PUMP ASSY
6912524	SET OF SEALS		163	HYDRAULIC PUMP ASSY
6912525	SET OF SEALS		163	HYDRAULIC PUMP ASSY
6912526	BLOCK		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912527	VALVE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912528	COIL	6912573	123 167	AMA - INSTALLATION HYDRAULIC CONTROL VALVE INSTALLATIO
6912529	NUT		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912530	BLOCK		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912531	VALVE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912532	COLLECTOR		123	AMA - INSTALLATION
6912533	VALVE		123 185	AMA - INSTALLATION HYDROSTATIC PUMP ASSY
6912534	COIL		123	AMA - INSTALLATION
6912535	SET OF PLUGS		143 347 351	STABILIZER SELECTOR VALVES REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
6912536	COIL		139	FRAME LEVEL INSTALLATION
6912537	COIL		139	FRAME LEVEL INSTALLATION
6912539	VALVE		159	HYDRAULIC MOTOR
6912544	GRATE, FAN	7008130	235	RADIATOR
6912546	KIT, SEALS		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912547	KIT, SEALS		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6912548	SET OF SEALS		135	HYDRAULIC TANK INSTALLATION
6912549	INDICATOR, FILTER PLUGGI	6913238	135 203	HYDRAULIC TANK INSTALLATION ELECTRICAL CIRCUIT ENGINE

Part Number	Denomination	WAS	Page	Subgroup
6912554	VALVE PLATE		185	HYDROSTATIC PUMP ASSY
6912558	COVER ASSY		185	HYDROSTATIC PUMP ASSY
6912559	SPRING GUIDE		185	HYDROSTATIC PUMP ASSY
6912560	WASHER		185	HYDROSTATIC PUMP ASSY
6912561	GUIDE BOLT		185	HYDROSTATIC PUMP ASSY
6912562	O-RING		185	HYDROSTATIC PUMP ASSY
6912563	SCREW		185	HYDROSTATIC PUMP ASSY
6912564	SCREW		185	HYDROSTATIC PUMP ASSY
6912567	PLATE		185	HYDROSTATIC PUMP ASSY
6912568	PLUG		185	HYDROSTATIC PUMP ASSY
6912572	CAP		135	HYDRAULIC TANK INSTALLATION
6912606	INNER RING		147	COMPENSATION CYLINDER
6912625	PLUG		79 81 85 95 97	HUB REDUCTION - FRONT AXLE REDUCER BOX - FRONT AXLE HOUSING - FRONT AXLE HUB REDUCTION - REAR AXLE HOUSING - REAR AXLE
6912626	CAP		85 97	HOUSING - FRONT AXLE HOUSING - REAR AXLE
6912629	PLUG		89 93 97 103	STEERING - FRONT AXLE BRAKES - FRONT AXLE HOUSING - REAR AXLE STEERING - REAR AXLE
6912635	SHIM		99	DIFFERENTIAL - REAR AXLE
6912636	SHIM		99	DIFFERENTIAL - REAR AXLE
6912637	SHIM		99	DIFFERENTIAL - REAR AXLE
6912642	SHIM		99	DIFFERENTIAL - REAR AXLE
6912653	RING, SNAP		81	REDUCER BOX - FRONT AXLE
6912654	RING, SNAP		81	REDUCER BOX - FRONT AXLE
6912657	RING, SNAP		95	HUB REDUCTION - REAR AXLE
6912660	RING, SNAP		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912663	RING, SNAP		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912664	RING, SNAP		81	REDUCER BOX - FRONT AXLE
6912667	GEAR, RING		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912681	BUSHING, REDUCTION		97	HOUSING - REAR AXLE
6912684	NUT		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912685	NUT		85 89 103	HOUSING - FRONT AXLE STEERING - FRONT AXLE STEERING - REAR AXLE
6912686	NUT		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912700	FITTING, GREASE		85 89 97 103	HOUSING - FRONT AXLE STEERING - FRONT AXLE HOUSING - REAR AXLE STEERING - REAR AXLE
6912702	SEAL		81	REDUCER BOX - FRONT AXLE

Part Number	Denomination	WAS	Page	Subgroup
6912703	SEAL		99	DIFFERENTIAL - REAR AXLE
6912704	SEAL		81	REDUCER BOX - FRONT AXLE
6912705	SEAL, WASHER		93	BRAKES - FRONT AXLE
6912715	O-RING		79	HUB REDUCTION - FRONT AXLE
			85	HOUSING - FRONT AXLE
			95	HUB REDUCTION - REAR AXLE
		6912851	97	HOUSING - REAR AXLE
6912722	GEAR		81	REDUCER BOX - FRONT AXLE
6912723	GEAR		81	REDUCER BOX - FRONT AXLE
6912724	DOWEL		81	REDUCER BOX - FRONT AXLE
6912732	PLUG, BREATHER		85	HOUSING - FRONT AXLE
6912735	WASHER, SPRING		81	REDUCER BOX - FRONT AXLE
6912736	WASHER		89	STEERING - FRONT AXLE
			103	STEERING - REAR AXLE
6912737	WASHER		95	HUB REDUCTION - REAR AXLE
6912740	BEARING, BALL		81	REDUCER BOX - FRONT AXLE
6912741	BEARING, BALL		81	REDUCER BOX - FRONT AXLE
6912742	BEARING, BALL		81	REDUCER BOX - FRONT AXLE
6912746	BEARING		79	HUB REDUCTION - FRONT AXLE
			95	HUB REDUCTION - REAR AXLE
6912748	BEARING		79	HUB REDUCTION - FRONT AXLE
			95	HUB REDUCTION - REAR AXLE
6912749	PLANET GEAR		79	HUB REDUCTION - FRONT AXLE
			95	HUB REDUCTION - REAR AXLE
6912765	BOLT, CYLINDER		81	REDUCER BOX - FRONT AXLE
6912767	BOLT, COUNTERSUNK		79	HUB REDUCTION - FRONT AXLE
			95	HUB REDUCTION - REAR AXLE
6912768	BOLT		93	BRAKES - FRONT AXLE
6912771	BOLT		87	DIFFERENTIAL - FRONT AXLE
			99	DIFFERENTIAL - REAR AXLE
6912773	BOLT		85	HOUSING - FRONT AXLE
			89	STEERING - FRONT AXLE
			103	STEERING - REAR AXLE
6912774	STEERING ADJUSTMENT AS		85	HOUSING - FRONT AXLE
			89	STEERING - FRONT AXLE
			103	STEERING - REAR AXLE
6912775	BOLT, BLEEDING		93	BRAKES - FRONT AXLE
6912778	ARTICULATION		89	STEERING - FRONT AXLE
			103	STEERING - REAR AXLE
6912779	PIN		87	DIFFERENTIAL - FRONT AXLE
			99	DIFFERENTIAL - REAR AXLE
6912780	RING, BACK-UP		93	BRAKES - FRONT AXLE
6912781	RING, BACK-UP		93	BRAKES - FRONT AXLE
6912784	STEERING CASE	6912924	89	STEERING - FRONT AXLE
		6912924	103	STEERING - REAR AXLE
6912786	PLUG		81	REDUCER BOX - FRONT AXLE
6912787	PLUG, MAGNET		81	REDUCER BOX - FRONT AXLE
			85	HOUSING - FRONT AXLE
			97	HOUSING - REAR AXLE
6912789	FLANGE		81	REDUCER BOX - FRONT AXLE

Part Number	Denomination	WAS	Page	Subgroup
6912790	SHIM		99	DIFFERENTIAL - REAR AXLE
6912791	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912792	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912793	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912794	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912795	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912796	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912797	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912798	SHIM		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912799	SHIM		93	BRAKES - FRONT AXLE
6912800	SHIM		93	BRAKES - FRONT AXLE
6912801	SHIM		93	BRAKES - FRONT AXLE
6912802	SHIM		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912803	SHIM		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912804	SHIM		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912805	DIFFERENTIAL CARRIER		99	DIFFERENTIAL - REAR AXLE
6912806	DIFFERENTIAL CARRIER		87	DIFFERENTIAL - FRONT AXLE
6912808	RING, SNAP		89	STEERING - FRONT AXLE
6912809	RING, SNAP		87 99	DIFFERENTIAL - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912810	RING, SNAP		87 99	DIFFERENTIAL - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912811	BEVEL GEAR SET		81 87	REDUCER BOX - FRONT AXLE DIFFERENTIAL - FRONT AXLE
6912812	BEVEL GEAR SET		99	DIFFERENTIAL - REAR AXLE
6912813	INTERMEDIATE COVER		85	HOUSING - FRONT AXLE
6912814	COVER		81	REDUCER BOX - FRONT AXLE
6912815	COVER		93	BRAKES - FRONT AXLE
6912816	COVER		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912817	COVERPLATE		99	DIFFERENTIAL - REAR AXLE
6912818	SENSOR, OPTICAL		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912819	DIFFERENTIAL		99	DIFFERENTIAL - REAR AXLE
6912820	KIT, LIMITED SLIP DIFFEREN		87	DIFFERENTIAL - FRONT AXLE
6912821	KIT, DISC		87	DIFFERENTIAL - FRONT AXLE
6912823	DISC, BRAKE		93	BRAKES - FRONT AXLE
6912824	INTERMEDIATE BRAKE DISC		93	BRAKES - FRONT AXLE

Part Number	Denomination	WAS	Page	Subgroup
6912826	THRUST BUSHING		89 97 103	STEERING - FRONT AXLE HOUSING - REAR AXLE STEERING - REAR AXLE
6912827	THRUST BUSHING		97	HOUSING - REAR AXLE
6912828	NUT		85	HOUSING - FRONT AXLE
6912829	NUT		85	HOUSING - FRONT AXLE
6912830	NUT		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912831	NUT		93	BRAKES - FRONT AXLE
6912832	RING NUT		87	DIFFERENTIAL - FRONT AXLE
6912833	RING NUT		81	REDUCER BOX - FRONT AXLE
6912834	NUT		99	DIFFERENTIAL - REAR AXLE
6912835	RING NUT		99	DIFFERENTIAL - REAR AXLE
6912836	SPACER		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912837	SPACER		93	BRAKES - FRONT AXLE
6912838	SPACER		93	BRAKES - FRONT AXLE
6912840	STUD		85	HOUSING - FRONT AXLE
6912841	STUD, WHEEL		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912845	SEAL		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912846	SEAL		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912847	SEAL		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912848	SEAL		89	STEERING - FRONT AXLE
6912849	O-RING		93	BRAKES - FRONT AXLE
6912850	O-RING		93	BRAKES - FRONT AXLE
6912851	O-RING		85 97	HOUSING - FRONT AXLE HOUSING - REAR AXLE
6912852	O-RING		81	REDUCER BOX - FRONT AXLE
6912853	O-RING		89	STEERING - FRONT AXLE
6912854	O-RING		93	BRAKES - FRONT AXLE
6912855	O-RING		99	DIFFERENTIAL - REAR AXLE
6912856	HUB, WHEEL		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912857	PISTON		93	BRAKES - FRONT AXLE
6912858	PISTON		93	BRAKES - FRONT AXLE
6912859	PIVOT PIN ASSY		103	STEERING - REAR AXLE
6912862	DIFFERENTIAL SIDE GEAR		87	DIFFERENTIAL - FRONT AXLE
6912863	BREATHER, AXLE		97	HOUSING - REAR AXLE
6912864	SPRING		93	BRAKES - FRONT AXLE
6912865	SPRING		93	BRAKES - FRONT AXLE
6912866	SPRING		93	BRAKES - FRONT AXLE
6912867	WASHER, LOCK		93	BRAKES - FRONT AXLE
6912868	WASHER		85	HOUSING - FRONT AXLE

Part Number	Denomination	WAS	Page	Subgroup
6912870	FRICTION WASHER		87 99	DIFFERENTIAL - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912871	BEARING, BALL		89	STEERING - FRONT AXLE
6912872	TAPER ROLLER BEARING		87 99	DIFFERENTIAL - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912873	TAPER ROLLER BEARING		81 99	REDUCER BOX - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912875	RING GEAR SUPPORT		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912879	SUPPORT		97	HOUSING - REAR AXLE
6912880	SUPPORT ASSY		97	HOUSING - REAR AXLE
6912888	CYLINDER		103	STEERING - REAR AXLE
6912889	CYLINDER BOLT		87 99	DIFFERENTIAL - FRONT AXLE DIFFERENTIAL - REAR AXLE
6912890	BOLT, CYLINDER		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912891	CYLINDER BOLT		87	DIFFERENTIAL - FRONT AXLE
6912892	BOLT		85	HOUSING - FRONT AXLE
6912893	BOLT		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912894	BOLT		85	HOUSING - FRONT AXLE
6912895	BOLT, HEX		97	HOUSING - REAR AXLE
6912897	BOLT, ADJUSTING		93	BRAKES - FRONT AXLE
6912898	BOLT		93	BRAKES - FRONT AXLE
6912915	INTERMEDIATE BRAKE DISC		93	BRAKES - FRONT AXLE
6912916	BUSHING, THRUST		85	HOUSING - FRONT AXLE
6912917	HOUSING		85	HOUSING - FRONT AXLE
6912918	HOUSING ASSY		85	HOUSING - FRONT AXLE
6912919	AXLE CASE		85	HOUSING - FRONT AXLE
6912920	JOINT		89	STEERING - FRONT AXLE
6912921	STEERING CASE		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912922	STEERING CASE		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912925	STEERING CASE		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912930	DOUBLE UNIVERSAL JOINT		95 103	HUB REDUCTION - REAR AXLE STEERING - REAR AXLE
6912937	BUSHING, THRUST		85	HOUSING - FRONT AXLE
6912938	BOLT		85	HOUSING - FRONT AXLE
6912941	PIVOT PIN ASSY		89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6912943	PLANET GEAR CARRIER		79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
6912944	KIT, PLANET GEAR CARRIER		95	HUB REDUCTION - REAR AXLE
6912945	KIT, PLANET GEAR CARRIER		79	HUB REDUCTION - FRONT AXLE
6912946	CYLINDER	6912887	89	STEERING - FRONT AXLE
6912948	O-RING		191	HYDROSTATIC MOTOR ASSY

Part Number	Denomination	WAS	Page	Subgroup
			103	STEERING - REAR AXLE
6912978	CYLINDER BODY		149	TELESCOPE CYLINDER
6912979	ROD		149	TELESCOPE CYLINDER
6912987	INSTALLATION INSTRUCTIO		385	WINDSHIELD PROTECTION GRILL
6912988	KIT, WINDOW FRONT GUAR		385	WINDSHIELD PROTECTION GRILL
6913021	SUPPORT		373	TRAILER BRAKE
6913027	PIPE		143	STABILIZER SELECTOR VALVES
6913028	COVER, ENGINE		11	ENGINE COVER
6913059	ELEMENT, HYDRAULIC FILT		135	HYDRAULIC TANK INSTALLATION
6913087	TACHOMETER		225	ENGINE INSTALLATION
6913148	SPONGE, ADHESIVE		285	AIR CONDITIONING INSTALLATION
6913204	HOSE		135 183	HYDRAULIC TANK INSTALLATION HYDROSTATIC HOSES AND FITTINGS
6913225	TUBE		333	HYDRAULIC TANK FILLING KIT
6913238	CAP		333	HYDRAULIC TANK FILLING KIT
6913243	SWITCH, BLUE LIGHTS	96601.0	37	CONTROL PANEL SWITCHES
6913433	WIRE HARNESS		325	ELECTRIC KIT FOR BROOM
6913526	TANK	6911094	135	HYDRAULIC TANK INSTALLATION
6913565	PUMP, HYDROSTATIC		135 183	HYDRAULIC TANK INSTALLATION HYDROSTATIC HOSES AND FITTINGS
6913569	SEAL	98583.8	135	HYDRAULIC TANK INSTALLATION
6913570	STRAINER		135	HYDRAULIC TANK INSTALLATION
6913649	HOSE		135	HYDRAULIC TANK INSTALLATION
6913650	HOSE		373	TRAILER BRAKE
6913651	HOSE	6910781	141	STABILIZERS INSTALLATION
6913653	HOSE		117 119	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP
6913654	HOSE		237 239 241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT
		85130.3		
6913655	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6913656	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6913658	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6913674	WIRE HARNESS		195	ELECTRICAL CIRCUIT CHASSIS
6913675	HOSE		347 351	REAR HYDRAULIC FUNCTION REAR HYDRAULIC HOOK
6913684	HOSE		373 375	TRAILER BRAKE TRAILER BRAKE ITALY VERSION
6913764	STABILITY INDICATOR AND		37	CONTROL PANEL SWITCHES
6913865	HOSE		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6913913	WIRE HARNESS		325	ELECTRIC KIT FOR BROOM
6913916	SLEEVE, PROTECTION		325	ELECTRIC KIT FOR BROOM
6913917	SHRINK SLEEVE		325	ELECTRIC KIT FOR BROOM
6913936	TUBELINE		27	HEATING/ VENTILATION INSTALLATION
6914033	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6914082	INSULATION		27	HEATING/ VENTILATION INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
6914109	CAPTOR		215	ELECTRIC CIRCUIT SECURITY
6914170	PLATE, CONTROL PANEL R.		37	CONTROL PANEL SWITCHES
6914219	SEAL		231	COOLING SYSTEM INSTALLATION
6914220	ARM ABUTMENT		3	CHASSIS
6914316	DAMPER		119 317	STEERING HOSES & FITTINGS (WITH DAMP DAMPER KIT
6914328	SPACER		285	AIR CONDITIONING INSTALLATION
6914403	SUPPORT		217 297	SECURITY OPTION STABILIZERS/TELESCOP AUSTRALIAN VERSION
6914407	SPACER		17	CAB ASSY
6914472	AXLE, FRONT		75	AXLE INSTALLATION
6914473	AXLE, REAR		75	AXLE INSTALLATION
6914480	SECURITY SHUNT STAB/TEL		217 297	SECURITY OPTION STABILIZERS/TELESCOP AUSTRALIAN VERSION
6914550	CYLINDER		141 157	STABILIZERS INSTALLATION STABILIZER CYLINDER
6914553	CYLINDER		65 69 151	END BOOM ASSY END BOOM ASSY TILT CYLINDER
6914554	CYLINDER		113 147	LIFT & COMPENSATION CYLINDER INSTALL COMPENSATION CYLINDER
6914561	SUPPORT, LOWER	6909974	35	COWLING INSTALLATION
6914586	SUPPORT FOR FRAME LEVE		37	CONTROL PANEL SWITCHES
6914640	HOSE		237 239	COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6914643	SUPPORT, UPPER		385	WINDSHIELD PROTECTION GRILL
6914645	PIPE		391	2ND HYDRAULIC FUNCTION ON BOOM
6914646	PIPE		391	2ND HYDRAULIC FUNCTION ON BOOM
6914651	SUPPORT, LOWER		385	WINDSHIELD PROTECTION GRILL
6914652	SUPPORT, LOWER		385	WINDSHIELD PROTECTION GRILL
6914691	VALVE, NO RETURN	6911080	143	STABILIZER SELECTOR VALVES
6914720	SWITCH		215	ELECTRIC CIRCUIT SECURITY
6914736	TANK, FUEL		9	FUEL TANK INSTALLATION
6914746	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
6914748	SEAL		11	ENGINE COVER
6914781	WIRE		31	PEDALS INSTALLATION
6914786	SPACER		41	DOOR ASSY
6914787	SEAL, UPPER PART		21	CAB ASSY II
6914788	SEAL, LOWER PART		21	CAB ASSY II
6914789	SEAL		41	DOOR ASSY
6914807	TUBE		337	LIFT CYLINDER ACCUMULATOR KIT
6914808	CLAMP/SUPPORT		337	LIFT CYLINDER ACCUMULATOR KIT
6914894	RIM		319	DUNLOP 400/70-R20 150B WHEELS
6914895	RIM		361	TITAN 400/70-R20 WHEELS
6914896	RIM		321 323	DUNLOP 400/80-R24 156B WHEELS DUNLOP 405/70-R20 SPT9 WHEELS
6914907	BATTERY		195	ELECTRICAL CIRCUIT CHASSIS

Part Number	Denomination	WAS	Page	Subgroup
6914975	SHIELDS (4,25B)		321	DUNLOP 400/80-R24 156B WHEELS
6915069	SCREW		75	AXLE INSTALLATION
6915089	HOSE		111	BOOM HYDRAULIC SUPPLY
6915177	KIT, DAMPER		317	DAMPER KIT
6915178	INSTALLATION INSTRUCTIO		317	DAMPER KIT
6915193	PLATE		61 63	INTERMEDIATE BOOM INTERMEDIATE BOOM
6915195	PULLEY (DOUBLE)		61 63	INTERMEDIATE BOOM INTERMEDIATE BOOM
6915214	SPINDLE		61 63	INTERMEDIATE BOOM INTERMEDIATE BOOM
6915215	SPINDLE		61 63	INTERMEDIATE BOOM INTERMEDIATE BOOM
6915224	INTERMEDIATE BOOM		63	INTERMEDIATE BOOM
6915235	WASHER		9	FUEL TANK INSTALLATION
6915262	VALVE		373	TRAILER BRAKE
6915264	SUPPORT		3	CHASSIS
6915265	SUPPORT		3	CHASSIS
6915268	JOYSTICK	6910314 6910314 6910314 6910314	121 199 201 209 211 213	JOYSTICK INSTALLATION (WITH AMA) ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB JOYSTICK JOYSTICK/SUSMIC INSTALLATION JOYSTICK / SUSMIC INSTALLATION
6915274	SECURITY SHUNT STABILIZ		219	STABILIZERS 25° LOCKING OPTION
6915283	SHAFT, CARDAN		75	AXLE INSTALLATION
6915290	BRACKET, THREADED		75	AXLE INSTALLATION
6915301	KIT, LIFT CYLINDER ACCUM		337	LIFT CYLINDER ACCUMULATOR KIT
6915302	INSTALLATION INSTRUCTIO		337	LIFT CYLINDER ACCUMULATOR KIT
6915305	SPACER		351	REAR HYDRAULIC HOOK
6915334	SPACER		275	ALTERNATOR
6915372	HYDRAULIC BLOCK		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6915391	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
6915392	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
6915406	HORIZONTALITY INDICATOR		3	CHASSIS
6915424	TUBE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6915425	TUBE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6915428.2	HOSE		129 131	PARKING BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO
6915430	HOSE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6915438	MUDGUARD SUPPORT		345	MUDGUARD 24"
6915508	NON-SKID	6564833	17	CAB ASSY
6915513	SUPPORT		11	ENGINE COVER
6915517	BELT PROTECTOR	6914411	285	AIR CONDITIONING INSTALLATION
6915519	FLOORMAT, INSULATION	97089.7	17	CAB ASSY
6915523	KIT, HYDRAULIC TANK FILLI		333	HYDRAULIC TANK FILLING KIT
6915534	MOTOR, REAR WIPER		47	REAR WINDOW INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
6915584	ACCUMULATOR		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6915701	SHOE		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6915747	SUPPORT	97503.7	33	STEERING COLUMN INSTALLATION
6915837	SUPPORT		165	HYDRAULIC CONTROL VALVE FIXATION
6915839	COUNTERWEIGHT		7	BALLAST
6915869	KIT, FUEL PRE-FILTER		329	FUEL PRE-FILTER KIT
6915871	INSTRUMENT PANEL		37	CONTROL PANEL SWITCHES
6915873	HOSE, FUEL FEED		329	FUEL PRE-FILTER KIT
6915874	HOSE, FUEL FEED		329	FUEL PRE-FILTER KIT
6915875	PRE-FILTER, FUEL		329	FUEL PRE-FILTER KIT
6915876	TUBE		329	FUEL PRE-FILTER KIT
6915892	L.H. WHEEL ASSY		361	TITAN 400/70-R20 WHEELS
6915893	R.H. WHEEL ASSY		361	TITAN 400/70-R20 WHEELS
6915894	L.H. WHEEL ASSY		321	DUNLOP 400/80-R24 156B WHEELS
6915895	R.H. WHEEL ASSY		321	DUNLOP 400/80-R24 156B WHEELS
6915904	WHEEL ASSY		323	DUNLOP 405/70-R20 SPT9 WHEELS
6915908	SEAL		13	ENGINE BASKET
6915911	R.H. WHEEL ASSY		319	DUNLOP 400/70-R20 150B WHEELS
6915912	L.H. WHEEL ASSY		319	DUNLOP 400/70-R20 150B WHEELS
6915979	PRE-FILTER, AIR		293	AIR PRE-CLEANER OPTION 2
6916058	DECAL		305	BOBCAT DECALS
6916061	MOTOR, WINDSHIELD WIPE	75920.9	49	WIPER INSTALLATION
6916070	HOSE, FIXATION		293	AIR PRE-CLEANER OPTION 2
6916071	PLATE		75	AXLE INSTALLATION
6916079	HOSE		351	REAR HYDRAULIC HOOK
6916108	PRE-FILTER, AIR		291	AIR PRE-CLEANER OPTION 1
6916168	MUDGUARD 24"		345	MUDGUARD 24"
6916186	REINFORCEMENT PLATE		311	BUCKET 2000L REINFORCEMENT KIT
6916187	REINFORCEMENT PLATE		309 311 313	BUCKET 1500L REINFORCEMENT KIT BUCKET 2000L REINFORCEMENT KIT BUCKET 2500L REINFORCEMENT KIT
6916225	CYLINDER, QUICK ATTACH		133 153	QUICK ATTACH INSTALLATION QUICK ATTACH CYLINDER
6916227	VALVE, BRAKE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6916229	SWITCH		381	VALVE BRAKING SWITCH OPTION
6916299	LOUDSPEAKER		339	LOUDSPEAKER PREDISPOSAL OPTION
6916302	COWLING, ROOF		339	LOUDSPEAKER PREDISPOSAL OPTION
6916371	ANTENNA		339	LOUDSPEAKER PREDISPOSAL OPTION
6916450	PIN		3 303 305	CHASSIS BOBCAT DECALS BOBCAT DECALS
6916488	TUBELINE		229	EXHAUST SYSTEM
6916551	MUFFLER, EXHAUST		229	EXHAUST SYSTEM
6916582	CAP, PROTECTION		215	ELECTRIC CIRCUIT SECURITY
6916590	SCREW		215	ELECTRIC CIRCUIT SECURITY
6916591	SCREW		215	ELECTRIC CIRCUIT SECURITY

Part Number	Denomination	WAS	Page	Subgroup
6916605	ENGINE BASKET		13	ENGINE BASKET
6916609	COVER		11	ENGINE COVER
6916616	BUCKET		367	TOOTHLESS BUCKETS
6916619	SUPPORT		229	EXHAUST SYSTEM
6916626	HOSE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6916627	HOSE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6916628	HOSE		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6916630	ADAPTER		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6916641	HOSE		375	TRAILER BRAKE ITALY VERSION
6916705	HOSE		225	ENGINE INSTALLATION
6916706	HOSE		225	ENGINE INSTALLATION
6916728	MUDGUARD SUPPORT		343	MUDGUARD 20"
6916745	ADAPTER		375 381	TRAILER BRAKE ITALY VERSION VALVE BRAKING SWITCH OPTION
6916931	LEVER ASSY		51 129 131	PARKING BRAKE LEVER PARKING BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO
6916961	HOSE		373	TRAILER BRAKE
6916963	ADHESIVE		35 211	COWLING INSTALLATION JOYSTICK/SUSMIC INSTALLATION
6916967	FUSE BOX		199 211	ELECTRICAL CIRCUIT CAB JOYSTICK/SUSMIC INSTALLATION
6916978	MOTOR, HYDRAULIC FAN		159 237 239 241 243	HYDRAULIC MOTOR COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6916979	PROTECTOR		203	ELECTRICAL CIRCUIT ENGINE
6917000	COWLING, SIDE FUSE PANE	6910881	35	COWLING INSTALLATION
6917129	SEAT		295	AIR SUSPENDED SEAT
6917139	WASHER		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
6917140	WASHER		31	PEDALS INSTALLATION
6917185	TEMPERATURE SENDER, HY		203	ELECTRICAL CIRCUIT ENGINE
6917196	HOSE	101319-25M	123	AMA - INSTALLATION
6917197	HOSE	6914033	123	AMA - INSTALLATION
6917248	OUTER BOOM		53	FIXED BOOM ASSY
6917250	INTERMEDIATE BOOM		61	INTERMEDIATE BOOM
6917252	INNER BOOM		65	END BOOM ASSY
6917254	CHAIN		65	END BOOM ASSY
6917284	CHANNEL		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6917287	PIPE ASSY		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6917290	CHAIN		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6917353	HINGE ASSY	6910554	41	DOOR ASSY
6917366	HYDRAULIC HOOK DROMON	82425.0	351	REAR HYDRAULIC HOOK
6917382	BUCKET		367	TOOTHLESS BUCKETS
6917394	HOSE	6911056	373	TRAILER BRAKE
6917410	BUCKET		367	TOOTHLESS BUCKETS

Part Number	Denomination	WAS	Page	Subgroup
6917690	WASHER		15	CAB & FIXATIONS
6917692	HYDRAULIC BLOCK		165	HYDRAULIC CONTROL VALVE FIXATION
6917718	PRESSURE SWITCH		241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6917761	CHASSIS		3	CHASSIS
6917778	BREATHER	37148.4	135	HYDRAULIC TANK INSTALLATION
6917779	SUPPORT, BREATHER	6913567	135	HYDRAULIC TANK INSTALLATION
6917796	PEDAL, THROTTLE		31	PEDALS INSTALLATION
6917802	BEARING		31	PEDALS INSTALLATION
6917889	HARNESS, LIGHT AND HORN		195	ELECTRICAL CIRCUIT CHASSIS
6917906	KIT, BUCKET 2500L REINFO		313	BUCKET 2500L REINFORCEMENT KIT
6917906P	PACKING LIST		313	BUCKET 2500L REINFORCEMENT KIT
6917907	KIT, BUCKET 2000L REINFO		311	BUCKET 2000L REINFORCEMENT KIT
6917907P	PACKING LIST		311	BUCKET 2000L REINFORCEMENT KIT
6917908	KIT, BUCKET 1500L REINFO		309	BUCKET 1500L REINFORCEMENT KIT
6917908P	PACKING LIST		309	BUCKET 1500L REINFORCEMENT KIT
6917909	REINFORCEMENT PLATE		313	BUCKET 2500L REINFORCEMENT KIT
6917910	REINFORCEMENT PLATE		309	BUCKET 1500L REINFORCEMENT KIT
6917955	SEAL		13	ENGINE BASKET
6917964	SEAL	6914678	11	ENGINE COVER
6918017	TUBE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6918103	HARNESS, WIRE		295	AIR SUSPENDED SEAT
6918139	COWLING, TOP FUSE PANEL	6910879	35	COWLING INSTALLATION
6918227	SWITCH, SERVICE BRAKE	6909324	31 199	PEDALS INSTALLATION ELECTRICAL CIRCUIT CAB
6918271	SCREW		195	ELECTRICAL CIRCUIT CHASSIS
6918308	FUEL LEVEL SENSOR		195	ELECTRICAL CIRCUIT CHASSIS
6918310	SCREW	6911771 6911771	53 57	FIXED BOOM ASSY FIXED BOOM ASSY
6918314	HOSE		241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT
6918340	HANDLE		41	DOOR ASSY
6918341	LOCK		41	DOOR ASSY
6918342	CABLE		41	DOOR ASSY
6918343	HANDLE, WITH KEY		41	DOOR ASSY
6918652	FITTING	77075.0 77075.0	139 167 371	FRAME LEVEL INSTALLATION HYDRAULIC CONTROL VALVE INSTALLATIO TOW VALVE INSTALLATION
6918667	BAR, SLIDE		295	AIR SUSPENDED SEAT
6918679	PLUG		17	CAB ASSY
6918690	ABACUS CARD		319	DUNLOP 400/70-R20 150B WHEELS
6918691	ABACUS CARD		319	DUNLOP 400/70-R20 150B WHEELS
6918692	ABACUS CARD		361	TITAN 400/70-R20 WHEELS
6918693	ABACUS CARD		361	TITAN 400/70-R20 WHEELS
6918694	ABACUS CARD		321	DUNLOP 400/80-R24 156B WHEELS
6918695	ABACUS CARD		321	DUNLOP 400/80-R24 156B WHEELS

Part Number	Denomination	WAS	Page	Subgroup
6918697	ABACUS CARD		323	DUNLOP 405/70-R20 SPT9 WHEELS
6918698	ABACUS CARD		319	DUNLOP 400/70-R20 150B WHEELS
6918699	ABACUS CARD		361	TITAN 400/70-R20 WHEELS
69187.3	PLUG		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6918700	ABACUS CARD		321	DUNLOP 400/80-R24 156B WHEELS
6918701	ABACUS CARD		323	DUNLOP 405/70-R20 SPT9 WHEELS
6918702	ABACUS CARD		319	DUNLOP 400/70-R20 150B WHEELS
6918703	ABACUS CARD		361	TITAN 400/70-R20 WHEELS
6918704	ABACUS CARD		321	DUNLOP 400/80-R24 156B WHEELS
6918705	ABACUS CARD		323	DUNLOP 405/70-R20 SPT9 WHEELS
6918707	DECAL, ARM T35100L		305	BOBCAT DECALS
6918708	DECAL, ARM T35100		305	BOBCAT DECALS
6918709	LOAD CHART		303	BOBCAT DECALS
6918710	DECAL, JOYSTICK		303	BOBCAT DECALS
6918711	LOAD CHART		305	BOBCAT DECALS
6918712	DECAL JOYSTICK		305	BOBCAT DECALS
6918713	LOAD CHART		305	BOBCAT DECALS
6918714	DECAL, JOYSTICK		305	BOBCAT DECALS
6918738	CYLINDER		115 149	TELESCOPE CYLINDER INSTALLATION TELESCOPE CYLINDER
6918742	PLATE	6911477	215	ELECTRIC CIRCUIT SECURITY
6918896	TUBE	6915872	329	FUEL PRE-FILTER KIT
6919190	BOX, CONTROL	6911363 6911363	199 211	ELECTRICAL CIRCUIT CAB JOYSTICK/SUSMIC INSTALLATION
6919218	SPACER		215	ELECTRIC CIRCUIT SECURITY
6919219	COUPLING		225	ENGINE INSTALLATION
6919314	WIRE HARNESS		107 221	BOOM HYDRAULIC SUPPLY FROM CONTRO ELECTRICAL CIRCUIT ARM
6919315	WIRE HARNESS		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
6919322	ENGINE		225	ENGINE INSTALLATION
6919328	MUDGUARD	78568.3	343	MUDGUARD 20"
6919329	MUDGUARD		345	MUDGUARD 24"
6919333	CLAMP	89522.7	135	HYDRAULIC TANK INSTALLATION
6919502	PROTECTOR, BELT		275	ALTERNATOR
6919773	ADAPTER	100375-38S	351	REAR HYDRAULIC HOOK
6919913	FILTER		167	HYDRAULIC CONTROL VALVE INSTALLATIO
6919939	HOSE		231	COOLING SYSTEM INSTALLATION
6919954	SUPPORT		285	AIR CONDITIONING INSTALLATION
6921027	BOLT, ADJUSTING	6912896	93	BRAKES - FRONT AXLE
6921038	SCREW		267	CYLINDER HEAD COVER
6921108	HOSE		231	COOLING SYSTEM INSTALLATION
6921134	FLANGE		225	ENGINE INSTALLATION
6921188	PLATE		231	COOLING SYSTEM INSTALLATION
6921191	BRACKET		231	COOLING SYSTEM INSTALLATION
6921192	SHOCK ABSORBER		225	ENGINE INSTALLATION
6921241	PLATE		231	COOLING SYSTEM INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
6921416	SLEEVE, CABLE		285	AIR CONDITIONING INSTALLATION
6921479	TIEPIECE		195	ELECTRICAL CIRCUIT CHASSIS
6921515	BUSHING	6912680 6912680	89 103	STEERING - FRONT AXLE STEERING - REAR AXLE
6922003	HYDRAULIC TUBE		347	REAR HYDRAULIC FUNCTION
6922004	HYDRAULIC TUBE		347	REAR HYDRAULIC FUNCTION
6922316	PLATE		301 359	BALES PIKES AND PALLET FORK FRAME RIGID FORKS HOLDER
6922321	SHOCK ABSORBER		225	ENGINE INSTALLATION
6922472	HOOK ASSY		379	ULPYO HOOK
6922476	PLATE		379	ULPYO HOOK
6922478	REAR CAPOT	6919717	351	REAR HYDRAULIC HOOK
6922514	ADJUSTABLE HOOK ASSY		283	ADJUSTABLE HOOK
6922536	SUPPORT	6911207	285	AIR CONDITIONING INSTALLATION
6922760	REAR VIEW MIRROR	100432-51C	3	CHASSIS
6922919	BOX, CONTROL		201 213	ELECTRICAL CIRCUIT CAB JOYSTICK / SUSMIC INSTALLATION
6922966	VALVE, SUPPORT		375	TRAILER BRAKE ITALY VERSION
6923062	HOSE		375	TRAILER BRAKE ITALY VERSION
6923136	SWITCH, PRESSURE		375	TRAILER BRAKE ITALY VERSION
6923401	SWITCH, PRESSURE		375	TRAILER BRAKE ITALY VERSION
6923433	PIPE	6910972	135	HYDRAULIC TANK INSTALLATION
6923517	GASKET		225	ENGINE INSTALLATION
6923537	HOSE		375	TRAILER BRAKE ITALY VERSION
6923576	WIRE HARNESS		375	TRAILER BRAKE ITALY VERSION
6923638	SUPPORT		213	JOYSTICK / SUSMIC INSTALLATION
6923681	HARNESS, ENGINE	6915845	203	ELECTRICAL CIRCUIT ENGINE
6923765	INCLINOMETER ASSY	6914946	215	ELECTRIC CIRCUIT SECURITY
6923799	SCREW		215	ELECTRIC CIRCUIT SECURITY
6923909	WIRE HARNESS, CAB		199 201 213	ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB JOYSTICK / SUSMIC INSTALLATION
6923912	WIRE HARNESS		195	ELECTRICAL CIRCUIT CHASSIS
6923915	WIRE HARNESS		195	ELECTRICAL CIRCUIT CHASSIS
6923939	HOSE		231	COOLING SYSTEM INSTALLATION
6924060	INDICATOR, STABILITY	6913764 6913764	199 201	ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB
6924074	SUPPORT	6911209	285	AIR CONDITIONING INSTALLATION
6924076	SUPPORT	6911210	285	AIR CONDITIONING INSTALLATION
6924079	STOP, PEDAL		281	ACCELERATOR PEDAL STOP KIT
6924092	HYDR. CONTROL VALVE AS	6912484 6912484	165 167	HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO
6924096	SLEEVE, REDUCING		231	COOLING SYSTEM INSTALLATION
6924097	SLEEVE, REDUCING		231	COOLING SYSTEM INSTALLATION
6924324	ADAPTOR		273	TURBOCHARGER
6924325	BAR		261	FUEL INJECTION EQUIPMENT
6924326	KIT, BIG END BEARING		247	CRANKSHAFT - PISTONS

Part Number	Denomination	WAS	Page	Subgroup
6924330	BOWL		265	FUEL FEEDING
6924331	BRACKET		251	CYLINDER HEAD INSTALLATION
6924332	BRACKET		265	FUEL FEEDING
6924333	BRACKET		273	TURBOCHARGER
6924334	BRACKET		259	OIL SUMP - OIL PUMP
6924335	CABLE		251	CYLINDER HEAD INSTALLATION
6924336	CAMSHAFT ASSY		255	ROCKER SHAFT
6924337	CAP		253	CYLINDER HEAD ASSY
6924338	CLIP		265	FUEL FEEDING
6924339	CLIP		261	FUEL INJECTION EQUIPMENT
6924340	CLIP		261	FUEL INJECTION EQUIPMENT
6924341	CONNECTOR		265	FUEL FEEDING
6924343	CYLINDER HEAD COVER AS		267	CYLINDER HEAD COVER
6924344	DOWEL		277	FLYWHEEL HOUSING AND STARTER
6924345	PLUG, DRAIN		265	FUEL FEEDING
6924346	VALVE, EXHAUST		253	CYLINDER HEAD ASSY
6924347	KIT, FRONT COVER		257	TIMING GEAR
6924348	SEAL		257	TIMING GEAR
6924349	FUEL INJECTION PUMP ASS		261	FUEL INJECTION EQUIPMENT
6924352	GRILL	6914657	385	WINDSHIELD PROTECTION GRILL
6924354	VENT	97201.8	27	HEATING/ VENTILATION INSTALLATION
6924369	KIT, PEDAL ACCELERATOR		281	ACCELERATOR PEDAL STOP KIT
6924387	RADIATOR		231 235	COOLING SYSTEM INSTALLATION RADIATOR
6924507	BOX, TRANSMISSION		201 213	ELECTRICAL CIRCUIT CAB JOYSTICK / SUSMIC INSTALLATION
6924734	SUPPORT, PEDAL	6917799	31	PEDALS INSTALLATION
6924900	GASKET, CYLINDER HEAD		251	CYLINDER HEAD INSTALLATION
6924901	GASKET		269	OIL COOLER AND FILTER
6924902	GASKET		257	TIMING GEAR
6924903	GASKET		273	TURBOCHARGER
6924904	GASKET		271	WATER PUMP AND THERMOSTAT
6924905	HUB		257	TIMING GEAR
6924906	GEAR ASSY		257	TIMING GEAR
6924907	INJECTOR		261	FUEL INJECTION EQUIPMENT
6924908	VALVE, INTAKE		253	CYLINDER HEAD ASSY
6924909	KIT, MOUNTING		265	FUEL FEEDING
6924910	NUT		245	CYLINDER BLOCK
6924911	NUT		255	ROCKER SHAFT
6924912	OIL COOLER ASSY		269	OIL COOLER AND FILTER
6924913	SWITCH, OIL PRESSURE		245	CYLINDER BLOCK
6924914	PIPE ASSY		261	FUEL INJECTION EQUIPMENT
6924915	PIPE BREATHER ASSY		267	CYLINDER HEAD COVER
6924916	PIPE, INJECTION		261	FUEL INJECTION EQUIPMENT
6924917	PIPE, INJECTION		261	FUEL INJECTION EQUIPMENT

Part Number	Denomination	WAS	Page	Subgroup
6924919	PIPE, INJECTION		261	FUEL INJECTION EQUIPMENT
6924920	PIPE ASSY		265	FUEL FEEDING
6924921	CLIP		265	FUEL FEEDING
6924922	CLIP		265	FUEL FEEDING
6924923	KIT, PISTON AND RING		247	CRANKSHAFT - PISTONS
6924924	JET, PISTON COOLING		245	CYLINDER BLOCK
6924925	KIT, PISTON RING		247	CRANKSHAFT - PISTONS
6924926	PLATE		257	TIMING GEAR
6924927	PLUG		265	FUEL FEEDING
6924928	PLUG		271	WATER PUMP AND THERMOSTAT
6924929	PUSHROD		255	ROCKER SHAFT
6924930	ROCKER LEVER ASSY		255	ROCKER SHAFT
6924931	ROCKER LEVER ASSY		255	ROCKER SHAFT
6924932	ROCKER SHAFT ASSY		255	ROCKER SHAFT
6924933	SCREW		259	OIL SUMP - OIL PUMP
6924934	SCREW		265	FUEL FEEDING
6924935	SCREW		255	ROCKER SHAFT
6924936	SEAL		261	FUEL INJECTION EQUIPMENT
6924937	O-RING		271	WATER PUMP AND THERMOSTAT
6924938	SEAL		253	CYLINDER HEAD ASSY
6924939	SEAL		253	CYLINDER HEAD ASSY
6924940	SEAL		271	WATER PUMP AND THERMOSTAT
6924941	KIT, CYLINDER BLOCK		245	CYLINDER BLOCK
6924942	TAPPET		255	ROCKER SHAFT
6924943	CASE		257	TIMING GEAR
6924944	TURBOCHARGER		273	TURBOCHARGER
6924945	TURBOCHARGER, EXCHAN		273	TURBOCHARGER
6924946	COLLET, VALVE		253	CYLINDER HEAD ASSY
6924947	GUIDE, VALVE		253	CYLINDER HEAD ASSY
6924948	SPRING		253	CYLINDER HEAD ASSY
6924949	WASHER		245	CYLINDER BLOCK
6924950	KIT, WATER PUMP		271	WATER PUMP AND THERMOSTAT
6925003	LIGHT, BEACON ROTATING	78817.4	15	CAB & FIXATIONS
6925059	SEAL		231	COOLING SYSTEM INSTALLATION
6925115	BAR, PROTECTION		285	AIR CONDITIONING INSTALLATION
6925231	SHUNT		221	ELECTRICAL CIRCUIT ARM
6925355	CAP		49	WIPER INSTALLATION
6925520	KIT, ELECTRIC, BOOM		325	ELECTRIC KIT FOR BROOM
6925741	HOUSING		391	2ND HYDRAULIC FUNCTION ON BOOM
6925840	DECAL		303	BOBCAT DECALS
6925843	DECAL		303	BOBCAT DECALS
6925851	DECAL, ARM T35100	6918708	303	BOBCAT DECALS
6925852	DECAL, ARM T35100L	6918707	303	BOBCAT DECALS
6925853	DECAL, ARM T35100SL	6918706	303	BOBCAT DECALS
6925927	HOSE		351	REAR HYDRAULIC HOOK

Part Number	Denomination	WAS	Page	Subgroup
6925946	DECAL, ARM BOBCAT	96928.7	303	BOBCAT DECALS
6925950	DECAL, ARM T35100	6918708	303	BOBCAT DECALS
6925951	DECAL, ARM T35100L	6918707	303	BOBCAT DECALS
6925952	DECAL, ARM T35100SL	6918706	303	BOBCAT DECALS
6925959	DECAL, ARM BOBCAT	96928.7	303	BOBCAT DECALS
6926228	DECAL, FUSE BOX	6916963	213	JOYSTICK / SUSMIC INSTALLATION
6926342	LETTERS A, B, C, D		297	AUSTRALIAN VERSION
6926588	VALVE, HEATING CONTROL	96609.3	37	CONTROL PANEL SWITCHES
6926755	KIT, DOC T35100 AUST.		297	AUSTRALIAN VERSION
6926839	CYLINDER ASSY, FRAME LE	6915288	139	FRAME LEVEL INSTALLATION
		6915288	155	FRAME LEVEL CYLINDER
6926987	HARNESS, WIRE	96588.9	207	VENTILATION REVERSE ELECTRICAL
6927124	HARNESS, WIRE		297	AUSTRALIAN VERSION
6927132	SWITCH		297	AUSTRALIAN VERSION
69274.9	ELBOW		135	HYDRAULIC TANK INSTALLATION
69485.1	T-UNION		351	REAR HYDRAULIC HOOK
6963094	FRAME		17	CAB ASSY
6971665	SUPPORT		17	CAB ASSY
69791.2	TOOTH		365	TOOTHED BUCKET
69866.2	JIG		335	JIG + HOOK
69868.8	SPINDLE		335	JIG + HOOK
70011.2	HOOK		335	JIG + HOOK
70012.0	SHACKLE		335	JIG + HOOK
7003688	ARTICULATED TIE ROD	6912927	89	STEERING - FRONT AXLE
		6912927	103	STEERING - REAR AXLE
7003689	ARTICULATED TIE ROD	6912926	89	STEERING - FRONT AXLE
		6912926	103	STEERING - REAR AXLE
7008049	PLATE, LOCKING	6912882	79	HUB REDUCTION - FRONT AXLE
		6912615	95	HUB REDUCTION - REAR AXLE
7008050	SPACER	6912615	95	HUB REDUCTION - REAR AXLE
7008125	COOLER, WATER-OIL		235	RADIATOR
7008126	INTERCOOLER		235	RADIATOR
7008127	COVER		235	RADIATOR
7008128	PLATE		235	RADIATOR
7008129	PLATE ASSY		235	RADIATOR
7008310	FITTING		235	RADIATOR
7008801	VALVE	6912121	155	FRAME LEVEL CYLINDER
7009502	PLANET GEAR CARRIER		95	HUB REDUCTION - REAR AXLE
7009503	RING GEAR SUPPORT ASSY		79	HUB REDUCTION - FRONT AXLE
			95	HUB REDUCTION - REAR AXLE
7009648	BOLT, HEX	6912762	81	REDUCER BOX - FRONT AXLE
7010276	KIT, LOCKING PLATE		95	HUB REDUCTION - REAR AXLE
7010277	KIT, PLANET GEAR CARRIER		95	HUB REDUCTION - REAR AXLE
7010583	CYLINDER HEAD ASSY		251	CYLINDER HEAD INSTALLATION
			253	CYLINDER HEAD ASSY
7010888	STUD	6912696	89	STEERING - FRONT AXLE
		6912696	103	STEERING - REAR AXLE

Part Number	Denomination	WAS	Page	Subgroup
7010889	STUD	6912839 6912839	79 95	HUB REDUCTION - FRONT AXLE HUB REDUCTION - REAR AXLE
7010891	GEAR ASSY		99	DIFFERENTIAL - REAR AXLE
7010892	PINION, DIFFERENTIAL	6912874	87	DIFFERENTIAL - FRONT AXLE
7010968	PLANET GEAR CARRIER	6912945	79	HUB REDUCTION - FRONT AXLE
7011162	CASE, AXLE	6912923	85	HOUSING - FRONT AXLE
7011165	FLANGE	6912935	99	DIFFERENTIAL - REAR AXLE
7011166	CASE, AXLE	6912928	97	HOUSING - REAR AXLE
7011167	CASE, AXLE	6912929	97	HOUSING - REAR AXLE
70287.8	WASHER		53 57 113	FIXED BOOM ASSY FIXED BOOM ASSY LIFT & COMPENSATION CYLINDER INSTALL
70288.6	CLIP		53 57 113	FIXED BOOM ASSY FIXED BOOM ASSY LIFT & COMPENSATION CYLINDER INSTALL
70811.5	BUSH		3	CHASSIS
70862.8	HOSE		141	STABILIZERS INSTALLATION
70865.1	HOSE		129 131	PARKING BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO
71162.2	HANDLE, REAR WINDOW		47	REAR WINDOW INSTALLATION
71269.5	SCREW		269	OIL COOLER AND FILTER
71272.9	SCREW		251	CYLINDER HEAD INSTALLATION
71275.2	SCREW	71275.9	259	OIL SUMP - OIL PUMP
71278.6	PIN, DOWEL		257	TIMING GEAR
71286.9	SCREW		273	TURBOCHARGER
71307.3	WASHER		249	FLYWHEEL AND DRIVE PULLEY
71329.1	NUT		261	FUEL INJECTION EQUIPMENT
71338.8	SCREW		259 261 269 271	OIL SUMP - OIL PUMP FUEL INJECTION EQUIPMENT OIL COOLER AND FILTER WATER PUMP AND THERMOSTAT
71343.8	SCREW		269	OIL COOLER AND FILTER
71346.1	SCREW		273	TURBOCHARGER
71348.7	SCREW		251 261	CYLINDER HEAD INSTALLATION FUEL INJECTION EQUIPMENT
71366.9	BRACKET		267	CYLINDER HEAD COVER
71381.8	SCREW		257 269	TIMING GEAR OIL COOLER AND FILTER
71386.7	WASHER		257	TIMING GEAR
71402.2	SCREW		245	CYLINDER BLOCK
71418.8	CLAMP		261	FUEL INJECTION EQUIPMENT
71439.4	SCREW		271	WATER PUMP AND THERMOSTAT
71451.9	SCREW		257	TIMING GEAR
71456.8	SCREW		251 257 259	CYLINDER HEAD INSTALLATION TIMING GEAR OIL SUMP - OIL PUMP
71465.9	NUT		259	OIL SUMP - OIL PUMP
71466.7	OLIVE		259	OIL SUMP - OIL PUMP

Part Number	Denomination	WAS	Page	Subgroup
71490.7	NUT		273	TURBOCHARGER
71495.6	NUT		277	FLYWHEEL HOUSING AND STARTER
71507.8	SCREW		259	OIL SUMP - OIL PUMP
71516.9	SCREW		245	CYLINDER BLOCK
71564.9	SCREW		245	CYLINDER BLOCK
71585.4	BEARING		185	HYDROSTATIC PUMP ASSY
71599.5	DOWEL		185 191	HYDROSTATIC PUMP ASSY HYDROSTATIC MOTOR ASSY
71602.7	SCREW		191	HYDROSTATIC MOTOR ASSY
71603.5	SCREW		191	HYDROSTATIC MOTOR ASSY
71605.0	SCREW		191	HYDROSTATIC MOTOR ASSY
71610.0	NUT		191	HYDROSTATIC MOTOR ASSY
71611.8	COVER, HYDR MOTOR		191	HYDROSTATIC MOTOR ASSY
71621.7	WASHER		191	HYDROSTATIC MOTOR ASSY
71622.5	NOZZLE		191	HYDROSTATIC MOTOR ASSY
71624.1	SEAL		191	HYDROSTATIC MOTOR ASSY
71626.6	SEAL		191	HYDROSTATIC MOTOR ASSY
71629.0	CONE		191	HYDROSTATIC MOTOR ASSY
71630.8	SPRING		191	HYDROSTATIC MOTOR ASSY
71631.6	SCREW		191	HYDROSTATIC MOTOR ASSY
71632.4	O-RING		191	HYDROSTATIC MOTOR ASSY
71633.2	NUT		191	HYDROSTATIC MOTOR ASSY
71635.7	NOZZLE		191	HYDROSTATIC MOTOR ASSY
71636.5	PLUG		185 191	HYDROSTATIC PUMP ASSY HYDROSTATIC MOTOR ASSY
71638.1	NOZZLE		191	HYDROSTATIC MOTOR ASSY
71643.1	SEAL		191	HYDROSTATIC MOTOR ASSY
71644.9	SEAL		191	HYDROSTATIC MOTOR ASSY
71646.4	SCREW		191	HYDROSTATIC MOTOR ASSY
71674.6	PLUG		185 191	HYDROSTATIC PUMP ASSY HYDROSTATIC MOTOR ASSY
71675.3	PLUG ASSY		185	HYDROSTATIC PUMP ASSY
71679.5	PIN		185	HYDROSTATIC PUMP ASSY
71681.1	WASHER		185	HYDROSTATIC PUMP ASSY
71682.9	PIN		185	HYDROSTATIC PUMP ASSY
71684.5	SPRING		185	HYDROSTATIC PUMP ASSY
71685.2	NUT, SLIDE		185	HYDROSTATIC PUMP ASSY
71690.2	PISTON		185	HYDROSTATIC PUMP ASSY
71691.0	RETAINER		185	HYDROSTATIC PUMP ASSY
71692.8	GUIDE		185	HYDROSTATIC PUMP ASSY
71693.6	SPACER		185	HYDROSTATIC PUMP ASSY
71701.7	SHAFT		185	HYDROSTATIC PUMP ASSY
71702.5	RING, SNAP		185	HYDROSTATIC PUMP ASSY
71711.6	SPRING		185	HYDROSTATIC PUMP ASSY
71715.7	NUT, LOCK		185	HYDROSTATIC PUMP ASSY
71732.2	SEAL		185	HYDROSTATIC PUMP ASSY

Part Number	Denomination	WAS	Page	Subgroup
71733.0	SEAL		185	HYDROSTATIC PUMP ASSY
71734.8	HOUSING		185	HYDROSTATIC PUMP ASSY
71735.5	SCREW		185	HYDROSTATIC PUMP ASSY
71736.3	HOUSING		185	HYDROSTATIC PUMP ASSY
71737.1	NUT, LOCK		185	HYDROSTATIC PUMP ASSY
71748.8	PLUG ASSY		185	HYDROSTATIC PUMP ASSY
71753.8	SCREW		185	HYDROSTATIC PUMP ASSY
71757.9	CHARGE PUMP ASSY		185	HYDROSTATIC PUMP ASSY
71760.3	COVER ASSY		185	HYDROSTATIC PUMP ASSY
71762.9	FLANGE		185	HYDROSTATIC PUMP ASSY
71785.0	PLUG		191	HYDROSTATIC MOTOR ASSY
71825.4	SCREW		11	ENGINE COVER
71827.0	SCREW	71827.7	277	FLYWHEEL HOUSING AND STARTER
71879.1	SCREW		339	LOUDSPEAKER PREDISPOSAL OPTION
71921.1	NUT		285	AIR CONDITIONING INSTALLATION
72065.6	SWITCH, PRESSURE		183	HYDROSTATIC HOSES AND FITTINGS
72186.0	SCREW		21	CAB ASSY II
72294.2	ELBOW, UNION		133 141 167 373 375	QUICK ATTACH INSTALLATION STABILIZERS INSTALLATION HYDRAULIC CONTROL VALVE INSTALLATIO TRAILER BRAKE TRAILER BRAKE ITALY VERSION
72554.9	BLADE		367	TOOTHLESS BUCKETS
72883.2	BUSH		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
74335.1	PLUG		285	AIR CONDITIONING INSTALLATION
74425.0	FORKS HOLDER ASSY		327	FLOATING PALLET FORKS
74466.4	HOSE		141 143	STABILIZERS INSTALLATION STABILIZER SELECTOR VALVES
74467.2	HOSE		117 119 317	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP DAMPER KIT
74863.2	BUSH		65 69	END BOOM ASSY END BOOM ASSY
75037.2	KIT, SEALS HYDRAULIC PUM		185	HYDROSTATIC PUMP ASSY
75165.1	SCREW		147 151	COMPENSATION CYLINDER TILT CYLINDER
75168.5	BUSH		157	STABILIZER CYLINDER
75181.8	BUSHING		155	FRAME LEVEL CYLINDER
75182.6	TOOTH		301	BALES PIKES AND PALLET FORK FRAME
75221.2	VALVE		157	STABILIZER CYLINDER
75254.3	PULLEY		249	FLYWHEEL AND DRIVE PULLEY
75594.2	SOLENOID, HYDRAULIC MOT		191	HYDROSTATIC MOTOR ASSY
75618.9	BUSHING		151	TILT CYLINDER
75633.8	SCREW		157	STABILIZER CYLINDER
75883.9	BACK		21	CAB ASSY II
75895.3	BLADE, FRONT WIPER		49	WIPER INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
		6911713	49	WIPER INSTALLATION
75898.7	ARM, WIPER WINDSHIELD		49	WIPER INSTALLATION
75900.1	ARM, REAR WIPER		47	REAR WINDOW INSTALLATION
75903.5	HINGE		47	REAR WINDOW INSTALLATION
75926.6	ADAPTER		49	WIPER INSTALLATION
75935.7	PIN, PIVOT		47	REAR WINDOW INSTALLATION
75940.7	CYLINDER		47	REAR WINDOW INSTALLATION
75985.2	SET OF PUSH ROD		209	JOYSTICK
76324.3	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
76401.9	HOSE		65 69 107	END BOOM ASSY END BOOM ASSY BOOM HYDRAULIC SUPPLY FROM CONTRO
76740.0	BALES PIKES, ASSY		301	BALES PIKES AND PALLET FORK FRAME
76742.6	BRACKET		301	BALES PIKES AND PALLET FORK FRAME
76837.4	ROUND PIN, ASSY		301	BALES PIKES AND PALLET FORK FRAME
77013.1	ADAPTER		123 129 131 139 143 167	AMA - INSTALLATION PARKING BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO FRAME LEVEL INSTALLATION STABILIZER SELECTOR VALVES HYDRAULIC CONTROL VALVE INSTALLATIO
77014.9	PLATE		371	TOW VALVE INSTALLATION
77136.0	BRACKET		195	ELECTRICAL CIRCUIT CHASSIS
77261.6	BUSH		3 53 57	CHASSIS FIXED BOOM ASSY FIXED BOOM ASSY
77297.0	TYRE		323	DUNLOP 405/70-R20 SPT9 WHEELS
77380.4	BOOM PIVOT BUSHING	6909027	3 53 57 65 69	CHASSIS FIXED BOOM ASSY FIXED BOOM ASSY END BOOM ASSY END BOOM ASSY
77421.6	PIN		65 69	END BOOM ASSY END BOOM ASSY
77430.7	WASHER		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
77912.4	ADAPTER		131 139 337	PARKING BRAKE HYDRAULIC INSTALLATIO FRAME LEVEL INSTALLATION LIFT CYLINDER ACCUMULATOR KIT
77919.9	BRACKET		31	PEDALS INSTALLATION
78021.3	SHOCK ABSORBER		15	CAB & FIXATIONS
78256.5	MOTOR ASSY, HYDROSTATI		183 191	HYDROSTATIC HOSES AND FITTINGS HYDROSTATIC MOTOR ASSY
78429.8	BLADE		367	TOOTHLESS BUCKETS
78575.8	CYLINDER		331	HOOK
78579.0	SLIDE		331	HOOK
78688.9	TANK, EXPANSION		231	COOLING SYSTEM INSTALLATION
78705.1	ADAPTER		135 183	HYDRAULIC TANK INSTALLATION HYDROSTATIC HOSES AND FITTINGS

Part Number	Denomination	WAS	Page	Subgroup
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
			347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
78745.7	ADAPTER		231	COOLING SYSTEM INSTALLATION
78815.8	WORKLIGHT, FRONT	6909971	21	CAB ASSY II
			199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
78816.6	WORKLIGHT, REAR	6909970	21	CAB ASSY II
			199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
78818.2	CONNECTION		17	CAB ASSY
78819.0	PLUG, GYROLIGHT		17	CAB ASSY
78856.2	PLATE		15	CAB & FIXATIONS
78863.8	SUPPORT		15	CAB & FIXATIONS
78867.9	SUPPORT		15	CAB & FIXATIONS
78869.5	BATTERY CABLE, NEGATIVE		195	ELECTRICAL CIRCUIT CHASSIS
78927.1	PLUG		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
79123.6	PLATE		3	CHASSIS
79124.4	NUT		3	CHASSIS
79129.3	SEAL		3	CHASSIS
79136.8	WASHER		379	ULPYO HOOK
79147.5	HOSE		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			317	DAMPER KIT
79148.3	HOSE		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
79160.8	SCREW		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
79170.7	COUPLING		373	TRAILER BRAKE
			375	TRAILER BRAKE ITALY VERSION
79255.6	HOOK		331	HOOK
79259.8	PIN		331	HOOK
79260.6	PIN		331	HOOK
79287.9	WASHER		331	HOOK
79288.7	RUBBER MOUNTING		3	CHASSIS
79293.7	SCREW		343	MUDGUARD 20"
			345	MUDGUARD 24"
79294.5	SCREW		343	MUDGUARD 20"
			345	MUDGUARD 24"
79297.8	CAP		41	DOOR ASSY
			343	MUDGUARD 20"
			345	MUDGUARD 24"
79300.0	PIPE		351	REAR HYDRAULIC HOOK
			355	REAR VIEW MIRROR
79334.9	LIGHT		341	MATRICULATION PLATE OPTION
79365.3	BUSHING		133	QUICK ATTACH INSTALLATION
79379.4	BEARING		73	MANUAL QUICK ATTACH LOCK

Part Number	Denomination	WAS	Page	Subgroup
79523.7	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
79524.5	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
79525.2	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
79526.0	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
79527.8	BELT, ENGINE DRIVE		275	ALTERNATOR
79531.0	CONNECTOR, FEMALE		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
79532.8	CONNECTOR		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
79533.6	FRONT LIGHT ASSY		195	ELECTRICAL CIRCUIT CHASSIS
79534.4	FRONT LIGHT ASSY		195	ELECTRICAL CIRCUIT CHASSIS
79539.3	HARNESS, FRONT LIGHT		195	ELECTRICAL CIRCUIT CHASSIS
79541.9	CONNECTOR		223 325	ELECTRICAL BOX AV ELECTRIC KIT FOR BROOM
79542.7	BLOCK, MALE		223 325	ELECTRICAL BOX AV ELECTRIC KIT FOR BROOM
79547.6	CONNECTOR		223	ELECTRICAL BOX AV
79548.4	BLOCK, MALE		223	ELECTRICAL BOX AV
79549.2	CONNECTOR, FEMALE 6 PO		221	ELECTRICAL CIRCUIT ARM
79550.0	BLOCK		221	ELECTRICAL CIRCUIT ARM
79551.8	CONNECTOR, MALE 6 POLE		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
79552.6	BLOCK		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
79553.4	CONNECTOR, FEMALE 12 P		221	ELECTRICAL CIRCUIT ARM
79554.2	BLOCK		221	ELECTRICAL CIRCUIT ARM
79555.9	CONNECTOR, MALE 12 POL		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
79556.7	BLOCK		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
79557.5	CONNECTOR		223 325	ELECTRICAL BOX AV ELECTRIC KIT FOR BROOM
79581.5	COVER		21	CAB ASSY II
79645.8	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
79861.1	CABLE, BATTERY		195	ELECTRICAL CIRCUIT CHASSIS
79862.9	HARNESS, STARTER		195	ELECTRICAL CIRCUIT CHASSIS
79864.5	SCREW		15 35	CAB & FIXATIONS COWLING INSTALLATION
79868.6	SHIM		15	CAB & FIXATIONS
79872.8	SPACER		15	CAB & FIXATIONS
79902.3	SUNSHADE		21	CAB ASSY II
79903.1	MIRROR		17	CAB ASSY
79906.4	CONNECTOR		389	WORKING LIGHT
79908.0	LIGHT		389	WORKING LIGHT

Part Number	Denomination	WAS	Page	Subgroup
79927.0	WASHER		203	ELECTRICAL CIRCUIT ENGINE
79930.4	RELAY		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
			203	ELECTRICAL CIRCUIT ENGINE
79931.2	SUPPORT, RELAY		203	ELECTRICAL CIRCUIT ENGINE
79945.2	SUPPORT		203	ELECTRICAL CIRCUIT ENGINE
79946.0	FUSE		203	ELECTRICAL CIRCUIT ENGINE
79947.8	FUSE		203	ELECTRICAL CIRCUIT ENGINE
79951.0	SUPPORT, SAFETY		203	ELECTRICAL CIRCUIT ENGINE
7JM90	RING, SNAP	6912656	85	HOUSING - FRONT AXLE
		6912656	89	STEERING - FRONT AXLE
		6912656	97	HOUSING - REAR AXLE
80220.7	BEZEL		37	CONTROL PANEL SWITCHES
80221.5	BEZEL		37	CONTROL PANEL SWITCHES
80224.9	RELAY		285	AIR CONDITIONING INSTALLATION
80226.4	DIODE		199	ELECTRICAL CIRCUIT CAB
			201	ELECTRICAL CIRCUIT CAB
80235.5	SLEEVE, SHRINK		217	SECURITY OPTION STABILIZERS/TELESCOP
			297	AUSTRALIAN VERSION
80240.5	NUT		223	ELECTRICAL BOX AV
80250.4	SLEEVE, SHRINK		297	AUSTRALIAN VERSION
80400.5	PIN, CARRIAGE		65	END BOOM ASSY
			69	END BOOM ASSY
80407.0	HOSE		65	END BOOM ASSY
			69	END BOOM ASSY
			107	BOOM HYDRAULIC SUPPLY FROM CONTRO
80583.8	FITTING, TRAILER		369	TOW HITCH
80643.0	SCREW		351	REAR HYDRAULIC HOOK
80732.1	ADAPTER		161	HYDRAULIC PUMP INSTALLATION
80906.1	BUCKET		365	TOOTHED BUCKET
80907.9	BUCKET		367	TOOTHLESS BUCKETS
80908.7	FORKS HOLDER		359	RIGID FORKS HOLDER
80909.5	FORKS HOLDER		357	RIGID FORKS HOLDER
80910.3	BUCKET		365	TOOTHED BUCKET
80914.5	BUCKET		367	TOOTHLESS BUCKETS
80917.8	BACK ASSY		301	BALES PIKES AND PALLET FORK FRAME
			357	RIGID FORKS HOLDER
80919.4	SEAL		3	CHASSIS
			13	ENGINE BASKET
80942.6	FORKS HOLDER, ASSY		301	BALES PIKES AND PALLET FORK FRAME
			359	RIGID FORKS HOLDER
80943.4	FORKS HOLDER		357	RIGID FORKS HOLDER
80945.9	BALES PIKES, ASSY		301	BALES PIKES AND PALLET FORK FRAME
81019.2	SCREW		257	TIMING GEAR
81026.7	PLUG		267	CYLINDER HEAD COVER
81036.6	SCREW		249	FLYWHEEL AND DRIVE PULLEY
81037.4	WASHER		249	FLYWHEEL AND DRIVE PULLEY
81038.2	FLYWHEEL ASSY		249	FLYWHEEL AND DRIVE PULLEY

Part Number	Denomination	WAS	Page	Subgroup
81041.6	HOUSING		277	FLYWHEEL HOUSING AND STARTER
81046.5	NUT		261	FUEL INJECTION EQUIPMENT
81063.0	SEAL		259	OIL SUMP - OIL PUMP
81284.2	BALL JOINT		47	REAR WINDOW INSTALLATION
81296.6	VALVE		185	HYDROSTATIC PUMP ASSY
81405.3	WASHER	81405.7	261	FUEL INJECTION EQUIPMENT
81421.0	KIT, AXLE SEALS		185	HYDROSTATIC PUMP ASSY
81424.4	SCREW		185	HYDROSTATIC PUMP ASSY
81425.1	SCREW		185	HYDROSTATIC PUMP ASSY
81427.7	VALVE		185	HYDROSTATIC PUMP ASSY
81433.5	VALVE SEGMENT		191	HYDROSTATIC MOTOR ASSY
81434.3	CYLINDER BLOCK		191	HYDROSTATIC MOTOR ASSY
81435.0	SHAFT		191	HYDROSTATIC MOTOR ASSY
81436.8	BEARING PLATE		191	HYDROSTATIC MOTOR ASSY
81437.6	SEAL		191	HYDROSTATIC MOTOR ASSY
81439.2	CONDENSER		285	AIR CONDITIONING INSTALLATION
81443.4	SCREW		191	HYDROSTATIC MOTOR ASSY
81444.2	O-RING		191	HYDROSTATIC MOTOR ASSY
81445.9	PISTON		191	HYDROSTATIC MOTOR ASSY
81448.3	COVER		191	HYDROSTATIC MOTOR ASSY
81450.9	SEAL		191	HYDROSTATIC MOTOR ASSY
81451.7	PLUG		191	HYDROSTATIC MOTOR ASSY
81455.8	CONTROL	95424.8	191	HYDROSTATIC MOTOR ASSY
81457.4	PIN		191	HYDROSTATIC MOTOR ASSY
81458.2	SPINDLE		191	HYDROSTATIC MOTOR ASSY
81460.8	SPRING		191	HYDROSTATIC MOTOR ASSY
81463.2	KIT, HYDROSTATIC MOTOR		191	HYDROSTATIC MOTOR ASSY
81473.1	CYLINDER HEAD		157	STABILIZER CYLINDER
81573.8	NIPPLE, GREASE		145	LIFT CYLINDER
			147	COMPENSATION CYLINDER
			151	TILT CYLINDER
			157	STABILIZER CYLINDER
81578.7	KIT, SEAL		331	HOOK
81632.2	BELLOW		25	SEAT & SUSPENSION
82088.6	SLEEVE, BULK		389	WORKING LIGHT
82181.9	FITTING		167	HYDRAULIC CONTROL VALVE INSTALLATIO
82265.0	LIGHT, REAR		195	ELECTRICAL CIRCUIT CHASSIS
82266.8	LIGHT, REAR		195	ELECTRICAL CIRCUIT CHASSIS
82426.8	SUPPORT		331	HOOK
82459.9	SCREW		65	END BOOM ASSY
			69	END BOOM ASSY
83757.5	CYLINDER		11	ENGINE COVER
83933.2	HOSE		113	LIFT & COMPENSATION CYLINDER INSTALL
84078.5	BUSH		61	INTERMEDIATE BOOM
84237.7	SPINDLE		141	STABILIZERS INSTALLATION
84450.6	KIT, ADAPTER		363	TOOL ADAPTOR KIT

Part Number	Denomination	WAS	Page	Subgroup
84625.3	SCREW		9	FUEL TANK INSTALLATION
84648.5	PLATE		351 355	REAR HYDRAULIC HOOK REAR VIEW MIRROR
8465.3	WIRE HARNESS		341	MATRICULATION PLATE OPTION
84675.8	BRACKET		389	WORKING LIGHT
84726.9	SHRINK SLEEVE		223 325	ELECTRICAL BOX AV ELECTRIC KIT FOR BROOM
84729.3	CLAMP		231	COOLING SYSTEM INSTALLATION
84748.3	BASE, MALE		223	ELECTRICAL BOX AV
84749.1	BASE, MALE		223	ELECTRICAL BOX AV
84997.6	SCREW		13	ENGINE BASKET
85170.9	UNION		135	HYDRAULIC TANK INSTALLATION
85171.7	SCREW, THUMB		285	AIR CONDITIONING INSTALLATION
85283.0	HOSE		167	HYDRAULIC CONTROL VALVE INSTALLATIO
85481.0	PIN, ROLL		133	QUICK ATTACH INSTALLATION
85837.3	NUT, COVER		195	ELECTRICAL CIRCUIT CHASSIS
85955.3	FITTING		167	HYDRAULIC CONTROL VALVE INSTALLATIO
86167.4	NUT		21	CAB ASSY II
88236.5	WASHER		13	ENGINE BASKET
88271.2	SCREW		375	TRAILER BRAKE ITALY VERSION
88299.3	SCREW		113	LIFT & COMPENSATION CYLINDER INSTALL
88394.2	INSULATION		231	COOLING SYSTEM INSTALLATION
88395.9	INSULATION		231	COOLING SYSTEM INSTALLATION
88497.3	SCREW		379	ULPYO HOOK
88540.0	SCREW		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
88597.0	SPINDLE		141	STABILIZERS INSTALLATION
88825.5	SWITCH		285	AIR CONDITIONING INSTALLATION
88826.3	PLATE		285	AIR CONDITIONING INSTALLATION
88827.1	PROTECTOR		285	AIR CONDITIONING INSTALLATION
88830.5	PLATE		285	AIR CONDITIONING INSTALLATION
88844.6	HOSE		285	AIR CONDITIONING INSTALLATION
88848.7	HOSE		285	AIR CONDITIONING INSTALLATION
88946.9	SCREW		165 167	HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO
89034.3	FORK		357 359	RIGID FORKS HOLDER RIGID FORKS HOLDER
89055.8	PLUG		223	ELECTRICAL BOX AV
89056.6	CAP		223	ELECTRICAL BOX AV
89328.9	LOCATING PIN		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
89332.1	WASHER		343	MUDGUARD 20"
89516.9	WASHER		11 115 225 229 373	ENGINE COVER TELESCOPE CYLINDER INSTALLATION ENGINE INSTALLATION EXHAUST SYSTEM TRAILER BRAKE
89517.7	WASHER		3	CHASSIS

Part Number	Denomination	WAS	Page	Subgroup
			183	HYDROSTATIC HOSES AND FITTINGS
			225	ENGINE INSTALLATION
89518.5	WASHER		13	ENGINE BASKET
			115	TELESCOPE CYLINDER INSTALLATION
			165	HYDRAULIC CONTROL VALVE FIXATION
			183	HYDROSTATIC HOSES AND FITTINGS
			215	ELECTRIC CIRCUIT SECURITY
			225	ENGINE INSTALLATION
89519.3	WASHER		21	CAB ASSY II
			123	AMA - INSTALLATION
			165	HYDRAULIC CONTROL VALVE FIXATION
			167	HYDRAULIC CONTROL VALVE INSTALLATIO
			225	ENGINE INSTALLATION
			231	COOLING SYSTEM INSTALLATION
			237	COOLING FAN CIRCUIT
			239	COOLING FAN CIRCUIT
			241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
			347	REAR HYDRAULIC FUNCTION
			373	TRAILER BRAKE
			375	TRAILER BRAKE ITALY VERSION
89523.5	CLAMP		135	HYDRAULIC TANK INSTALLATION
89577.1	WEDGE		383	WHEEL WEDGE OPTION
89641.5	BRACKET		285	AIR CONDITIONING INSTALLATION
89642.3	SWITCH		285	AIR CONDITIONING INSTALLATION
89643.1	FILTER, DRYER		285	AIR CONDITIONING INSTALLATION
89644.9	COMPRESSOR		285	AIR CONDITIONING INSTALLATION
89647.2	HOSE		285	AIR CONDITIONING INSTALLATION
89648.0	HOSE		285	AIR CONDITIONING INSTALLATION
89649.8	HOSE		285	AIR CONDITIONING INSTALLATION
89758.7	DECAL		131	PARKING BRAKE HYDRAULIC INSTALLATIO
90245.2	SCREW		15	CAB & FIXATIONS
90281.7	BUSH		3	CHASSIS
90288.2	HOOK		379	ULPYO HOOK
90289.0	FITTING		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			129	PARKING BRAKE HYDRAULIC INSTALLATIO
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
90490.4	PLATE		231	COOLING SYSTEM INSTALLATION
90531.5	ROLLER		285	AIR CONDITIONING INSTALLATION
90545.5	BELT, ALTERNATOR		285	AIR CONDITIONING INSTALLATION
90841.8	COUNTERWEIGHT RH		7	BALLAST
90842.6	COUNTERWEIGHT LH		7	BALLAST
90913.5	BUZZER		215	ELECTRIC CIRCUIT SECURITY
90924.2	CONNECTION		123	AMA - INSTALLATION
92126.2	HOSE		139	FRAME LEVEL INSTALLATION
92131.2	VALVE, SELECTOR		391	2ND HYDRAULIC FUNCTION ON BOOM
92210.4	WASHER		183	HYDROSTATIC HOSES AND FITTINGS
92218.7	PIN		133	QUICK ATTACH INSTALLATION
92220.3	TUBE		133	QUICK ATTACH INSTALLATION
92299.7	PLUG		297	AUSTRALIAN VERSION

Part Number	Denomination	WAS	Page	Subgroup
92398.7	SPRING		133	QUICK ATTACH INSTALLATION
92588.3	WASHER		133	QUICK ATTACH INSTALLATION
92614.7	HOUSING		191	HYDROSTATIC MOTOR ASSY
92637.8	O-RING		135 161	HYDRAULIC TANK INSTALLATION HYDRAULIC PUMP INSTALLATION
92718.6	DECAL		379	ULPYO HOOK
92762.4	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
92783.0	DECAL		365	TOOTHED BUCKET
92790.5	PROTECTION FOR TOOTHLE		367	TOOTHLESS BUCKETS
92803.6	DECAL		365	TOOTHED BUCKET
92805.1	DECAL		365	TOOTHED BUCKET
92808.5	DECAL		365	TOOTHED BUCKET
92809.3	PROTECTION		365	TOOTHED BUCKET
92971.1	SWITCH		217	SECURITY OPTION STABILIZERS/TELESCOP
92993.5	SCREW		283	ADJUSTABLE HOOK
93049.5	O-RING		135 161	HYDRAULIC TANK INSTALLATION HYDRAULIC PUMP INSTALLATION
93158.4	RING, RETAINER		247	CRANKSHAFT - PISTONS
93191.5	SEAL		261	FUEL INJECTION EQUIPMENT
93207.9	WASHER		261	FUEL INJECTION EQUIPMENT
93237.6	STOP		25	SEAT & SUSPENSION
93238.4	BELT, SEAT		25	SEAT & SUSPENSION
93239.2	BAR, SLIDE		25	SEAT & SUSPENSION
93240.0	LEVER		25	SEAT & SUSPENSION
93241.8	LEVER		25	SEAT & SUSPENSION
93242.6	LEVER		25	SEAT & SUSPENSION
93243.4	FOAM, RUBBER		25	SEAT & SUSPENSION
93244.2	FOAM, RUBBER		25	SEAT & SUSPENSION
93245.9	COVER, BACK		25	SEAT & SUSPENSION
93246.7	COVER, SEAT		25	SEAT & SUSPENSION
93247.5	BRACKET		25	SEAT & SUSPENSION
93248.3	SUSPENSION		25	SEAT & SUSPENSION
93249.1	CYLINDER		25	SEAT & SUSPENSION
93273.1	COLLAR		267	CYLINDER HEAD COVER
93274.9	SPRING		267	CYLINDER HEAD COVER
93280.6	SCREW		257 271	TIMING GEAR WATER PUMP AND THERMOSTAT
93321.8	SCREW		273	TURBOCHARGER
93379.6	DOWEL		245	CYLINDER BLOCK
93404.2	PLATE		251	CYLINDER HEAD INSTALLATION
93408.3	SCREW		273	TURBOCHARGER
93651.8	PISTON		151	TILT CYLINDER
93682.3	SCREW		155	FRAME LEVEL CYLINDER
93683.1	GREASE NIPPLE		155	FRAME LEVEL CYLINDER
93982.7	CYLINDER BARREL	6912122	155	FRAME LEVEL CYLINDER

Part Number	Denomination	WAS	Page	Subgroup
93985.0	PISTON		155	FRAME LEVEL CYLINDER
93986.8	SPACE		155	FRAME LEVEL CYLINDER
94018.9	CAP, STEERING WHEEL		33	STEERING COLUMN INSTALLATION
94050.2	SUPPORT, ADJUSTABLE		283	ADJUSTABLE HOOK
94074.2	PIN		327	FLOATING PALLET FORKS
94165.8	HOOK, AUTOMATIC		283	ADJUSTABLE HOOK
94548.5	CAP, PLASTIC		7	BALLAST
94574.1	WASHER		15 17 165 167 211 213 295	CAB & FIXATIONS CAB ASSY HYDRAULIC CONTROL VALVE FIXATION HYDRAULIC CONTROL VALVE INSTALLATIO JOYSTICK/SUSMIC INSTALLATION JOYSTICK / SUSMIC INSTALLATION AIR SUSPENDED SEAT
94990.9	SCREW		139	FRAME LEVEL INSTALLATION
94992.5	HOSE		239 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT
95061.8	SEAL		9	FUEL TANK INSTALLATION
95068.3	TRAP DOOR		9	FUEL TANK INSTALLATION
95088.1	CHAIN SPACER		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
95218.4	PIN		307	BOOM SUPPORT KIT
95428.9	PIN		73	MANUAL QUICK ATTACH LOCK
95501.3	SHOE		53 57 61 63 65 69	FIXED BOOM ASSY FIXED BOOM ASSY INTERMEDIATE BOOM INTERMEDIATE BOOM END BOOM ASSY END BOOM ASSY
95502.1	SCREW		47 61 63 65 69 107	REAR WINDOW INSTALLATION INTERMEDIATE BOOM INTERMEDIATE BOOM END BOOM ASSY END BOOM ASSY BOOM HYDRAULIC SUPPLY FROM CONTRO
95533.6	SPINDLE		65 69	END BOOM ASSY END BOOM ASSY
95539.3	PULLEY		61 63	INTERMEDIATE BOOM INTERMEDIATE BOOM
95541.9	BUSH		61 63	INTERMEDIATE BOOM INTERMEDIATE BOOM
95553.4	PULL ROD		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
95555.9	RETAINING		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
95557.5	SCREW		53 57	FIXED BOOM ASSY FIXED BOOM ASSY
95558.3	RETAINING		65 69	END BOOM ASSY END BOOM ASSY
95564.1	RETAINING		65 69	END BOOM ASSY END BOOM ASSY
95571.6	LINK		107	BOOM HYDRAULIC SUPPLY FROM CONTRO
95572.4	LINK		107	BOOM HYDRAULIC SUPPLY FROM CONTRO

Part Number	Denomination	WAS	Page	Subgroup
95613.6	SPINDLE		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			65	END BOOM ASSY
			69	END BOOM ASSY
95614.4	SPINDLE		65	END BOOM ASSY
			69	END BOOM ASSY
95791.0	PLATE		391	2ND HYDRAULIC FUNCTION ON BOOM
95993.2	COUPLER, FEMALE		65	END BOOM ASSY
			69	END BOOM ASSY
			133	QUICK ATTACH INSTALLATION
			347	REAR HYDRAULIC FUNCTION
			391	2ND HYDRAULIC FUNCTION ON BOOM
95994.0	COUPLING, MALE		65	END BOOM ASSY
			69	END BOOM ASSY
			133	QUICK ATTACH INSTALLATION
			347	REAR HYDRAULIC FUNCTION
			391	2ND HYDRAULIC FUNCTION ON BOOM
96054.2	SPACER		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
96061.7	SPACER		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
96074.0	COVER		17	CAB ASSY
96080.7	PLATE, CONTROL PANEL L.		37	CONTROL PANEL SWITCHES
96082.3	EVAPORATOR		285	AIR CONDITIONING INSTALLATION
96083.1	WIRING		285	AIR CONDITIONING INSTALLATION
96332.2	TYRE		321	DUNLOP 400/80-R24 156B WHEELS
96338.9	SUPPORT		307	BOOM SUPPORT KIT
96344.7	BRACKET		307	BOOM SUPPORT KIT
96352.0	INDICATOR, BOOM ANGLE		297	AUSTRALIAN VERSION
96421.3	PLATE		195	ELECTRICAL CIRCUIT CHASSIS
96461.9	ADAPTER		225	ENGINE INSTALLATION
96462.7	HOSE, DRAIN		225	ENGINE INSTALLATION
96513.7	CAP		65	END BOOM ASSY
			69	END BOOM ASSY
			133	QUICK ATTACH INSTALLATION
			347	REAR HYDRAULIC FUNCTION
			391	2ND HYDRAULIC FUNCTION ON BOOM
96514.5	CAP		65	END BOOM ASSY
			69	END BOOM ASSY
			133	QUICK ATTACH INSTALLATION
			347	REAR HYDRAULIC FUNCTION
			391	2ND HYDRAULIC FUNCTION ON BOOM
96524.4	HYDRAULIC CONCRETE SKI		315	CONCRETE BUCKET
96541.8	RIVET		383	WHEEL WEDGE OPTION
96554.1	WASHER		327	FLOATING PALLET FORKS
			383	WHEEL WEDGE OPTION
96567.3	UNION		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
			129	PARKING BRAKE HYDRAULIC INSTALLATIO
			131	PARKING BRAKE HYDRAULIC INSTALLATIO
96568.1	UNION		373	TRAILER BRAKE
96580.6	UNION		373	TRAILER BRAKE
96589.7	HARNESS, WIRE		351	REAR HYDRAULIC HOOK
96590.5	SWITCH, HAZARD LIGHTS		37	CONTROL PANEL SWITCHES

Part Number	Denomination	WAS	Page	Subgroup
96592.1	SWITCH, LEVER		37	CONTROL PANEL SWITCHES
96593.9	SWITCH, STEERING MODE		37	CONTROL PANEL SWITCHES
96594.7	INDICATOR, STEERING MOD		37	CONTROL PANEL SWITCHES
96595.4	INDICATOR, TRAILER TURN		37	CONTROL PANEL SWITCHES
96596.2	SWITCH, FAN		207	VENTILATION REVERSE ELECTRICAL
96597.0	SWITCH, REAR FOG LIGHT		37	CONTROL PANEL SWITCHES
96598.8	SWITCH		37 351	CONTROL PANEL SWITCHES REAR HYDRAULIC HOOK
96599.6	SWITCH, REAR OPTION		347	REAR HYDRAULIC FUNCTION
96600.2	SWITCH, HEAD LAMP		37	CONTROL PANEL SWITCHES
96602.8	SWITCH, REAR WIPER/WAS		37	CONTROL PANEL SWITCHES
96603.6	SWITCH, ROOF WIPER		37	CONTROL PANEL SWITCHES
96604.4	SWITCH, AUX HYD		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
96608.5	SWITCH, FAN SPEED		37	CONTROL PANEL SWITCHES
96613.5	SPACER		203	ELECTRICAL CIRCUIT ENGINE
96623.4	TURN SIGNAL RELAY		199 201	ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB
96627.5	CABLE PLUG		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
96628.3	CAP		223	ELECTRICAL BOX AV
96629.1	PLUG		223	ELECTRICAL BOX AV
96656.4	SPRING		125	SERVICE BRAKE HYDRAULIC INSTALLATIO
96664.8	PIPE, HYDRAULIC		117 119	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP
96749.7	DECAL		303 305	BOBCAT DECALS BOBCAT DECALS
96755.4	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
96756.2	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
96763.8	HOSE		117 119	STEERING HOSES & FITTINGS (WITHOUT D STEERING HOSES & FITTINGS (WITH DAMP
96776.0	HOSE		129 131	PARKING BRAKE HYDRAULIC INSTALLATIO PARKING BRAKE HYDRAULIC INSTALLATIO
96779.4	HOSE		111 115	BOOM HYDRAULIC SUPPLY TELESCOPE CYLINDER INSTALLATION
96780.2	HOSE		113	LIFT & COMPENSATION CYLINDER INSTALL
96795.0	HOSE		183	HYDROSTATIC HOSES AND FITTINGS
96928.7	DECAL, ARM BOBCAT RH		305	BOBCAT DECALS
96932.9	DECAL, ARM BOBCAT LH		305	BOBCAT DECALS
97008.7	SCREW		149	TELESCOPE CYLINDER
97013.7	PLUG		145 149	LIFT CYLINDER TELESCOPE CYLINDER
97033.5	PISTON		157	STABILIZER CYLINDER
97054.1	SET OF KEYS		37	CONTROL PANEL SWITCHES
97088.9	FLOORMAT, UPPER		17	CAB ASSY
97096.2	LIGHTER, CIGARETTE		35	COWLING INSTALLATION
97098.8	PUSH BUTTON	6909910	35	COWLING INSTALLATION

Part Number	Denomination	WAS	Page	Subgroup
97175.4	SOLENOID		203 261	ELECTRICAL CIRCUIT ENGINE FUEL INJECTION EQUIPMENT
97196.0	RESERVOIR, WINDSHIELD		49	WIPER INSTALLATION
97204.2	TUBELINE		27	HEATING/ VENTILATION INSTALLATION
97205.9	HEATER		27 29	HEATING/ VENTILATION INSTALLATION HEATING/VENTILATION FAN ASSY
97206.7	TUBELINE		27	HEATING/ VENTILATION INSTALLATION
97208.3	NOZZLE, VENT		27	HEATING/ VENTILATION INSTALLATION
97210.9	PIN		33	STEERING COLUMN INSTALLATION
97212.5	HOSE		49	WIPER INSTALLATION
97217.4	JET		49	WIPER INSTALLATION
97236.4	HARNESS, WIRE		199 201	ELECTRICAL CIRCUIT CAB ELECTRICAL CIRCUIT CAB
97258.8	PISTON		191	HYDROSTATIC MOTOR ASSY
97260.4	LENS		195	ELECTRICAL CIRCUIT CHASSIS
97261.2	LENS		195	ELECTRICAL CIRCUIT CHASSIS
97265.3	GRILL		285	AIR CONDITIONING INSTALLATION
97295.0	SET OF SEALS		173 175 177 179 181	HYDRAULIC CONTROL VALVE:IN- AND OUTL HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO HYDRAULIC CONTROL VALVE TELESCOPE HYDRAULIC CONTROL VALVE AUXILIARY H
97297.6	FILTER		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
97300.8	VALVE, PRESSURE RELIEF		173	HYDRAULIC CONTROL VALVE:IN- AND OUTL
97302.4	KIT, PRESSURE COMPENSA		175 177 179 181	HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO HYDRAULIC CONTROL VALVE TELESCOPE HYDRAULIC CONTROL VALVE AUXILIARY H
97303.2	KIT, NO RETURN VALVE		175 177 179 181	HYDRAULIC CONTROL VALVE LIFT SECTIO HYDRAULIC CONTROL VALVE TILT SECTIO HYDRAULIC CONTROL VALVE TELESCOPE HYDRAULIC CONTROL VALVE AUXILIARY H
97350.3	CONTROL VALVE		29	HEATING/VENTILATION FAN ASSY
97357.8	SPRING		191	HYDROSTATIC MOTOR ASSY
97358.6	VALVE		285	AIR CONDITIONING INSTALLATION
97359.4	PLATE		285	AIR CONDITIONING INSTALLATION
97360.2	STRAP, DOOR		41	DOOR ASSY
97400.6	VALVE		185	HYDROSTATIC PUMP ASSY
97420.4	FLANGE		77	CARDAN SHAFT
97432.9	THERMOSTAT		285	AIR CONDITIONING INSTALLATION
97440.2	PLUG		149	TELESCOPE CYLINDER
97448.5	BUSH		145 147	LIFT CYLINDER COMPENSATION CYLINDER
97453.5	PISTON		145	LIFT CYLINDER
97501.1	HANDLE		33	STEERING COLUMN INSTALLATION
97502.9	KNOB		33	STEERING COLUMN INSTALLATION
97504.5	BRACKET		21	CAB ASSY II
97515.1	HORN, REAR		299	BACKUP ALARM
97519.3	SWITCH, TRANSMISSION M		37	CONTROL PANEL SWITCHES

Part Number	Denomination	WAS	Page	Subgroup
97546.6	PLUG		325 391	ELECTRIC KIT FOR BROOM 2ND HYDRAULIC FUNCTION ON BOOM
97610.0	WASHER		275 285	ALTERNATOR AIR CONDITIONING INSTALLATION
97634.0	WIRE HARNESS		217 297	SECURITY OPTION STABILIZERS/TELESCOP AUSTRALIAN VERSION
97721.5	CABLE		391	2ND HYDRAULIC FUNCTION ON BOOM
97746.2	FILTER, AIR		225	ENGINE INSTALLATION
97747.0	CLAMP		225	ENGINE INSTALLATION
97851.0	SCREW		115	TELESCOPE CYLINDER INSTALLATION
97878.3	HOUSING		225	ENGINE INSTALLATION
97880.9	VALVE, CHECK		183	HYDROSTATIC HOSES AND FITTINGS
97885.8	KNOB, BLOCK		37	CONTROL PANEL SWITCHES
97886.6	KNOB, HEAD		37	CONTROL PANEL SWITCHES
97904.7	GLUE		9	FUEL TANK INSTALLATION
97915.3	FAN		237 239 241 243	COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT COOLING FAN CIRCUIT
97964.1	RIVET		21	CAB ASSY II
98053.2	PLATE, FRONT		11	ENGINE COVER
98068.0	O-RING		285	AIR CONDITIONING INSTALLATION
98069.8	O-RING		285	AIR CONDITIONING INSTALLATION
98070.6	O-RING		285	AIR CONDITIONING INSTALLATION
98071.4	O-RING		285	AIR CONDITIONING INSTALLATION
98132.4	WASHER		225	ENGINE INSTALLATION
98167.0	PLATE	95634.2 95634.2	301 327 335 357 359 365 367	BALES PIKES AND PALLET FORK FRAME FLOATING PALLET FORKS JIG + HOOK RIGID FORKS HOLDER RIGID FORKS HOLDER TOOTHED BUCKET TOOTHLESS BUCKETS
98180.3	WASHER		143	STABILIZER SELECTOR VALVES
98235.5	VALVE		113	LIFT & COMPENSATION CYLINDER INSTALL
98240.5	CABLE, THROTTLE		31	PEDALS INSTALLATION
98241.3	LEVER ASSY		33	STEERING COLUMN INSTALLATION
98242.9	LEVER ASSY		33	STEERING COLUMN INSTALLATION
98272.8	SPRING		225	ENGINE INSTALLATION
98300.7	SHIM		53 57 61 63 65 69	FIXED BOOM ASSY FIXED BOOM ASSY INTERMEDIATE BOOM INTERMEDIATE BOOM END BOOM ASSY END BOOM ASSY
98301.5	SHIM		53 57 61 63 65 69	FIXED BOOM ASSY FIXED BOOM ASSY INTERMEDIATE BOOM INTERMEDIATE BOOM END BOOM ASSY END BOOM ASSY

Part Number	Denomination	WAS	Page	Subgroup
98302.3	SHIM		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98303.1	SCREW		61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98340.3	SHOE		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98341.1	SHOE		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98342.9	SHOE		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98343.7	SHOE		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98344.5	SHOE		53	FIXED BOOM ASSY
			57	FIXED BOOM ASSY
			61	INTERMEDIATE BOOM
			63	INTERMEDIATE BOOM
			65	END BOOM ASSY
			69	END BOOM ASSY
98348.6	SUPPORT		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
98349.4	VALVE, STEERING SELECTO		117	STEERING HOSES & FITTINGS (WITHOUT D
			119	STEERING HOSES & FITTINGS (WITH DAMP
98353.6	PLATE		347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
98355.1	DISTRIBUTOR, ELECTRO		241	COOLING FAN CIRCUIT
			243	COOLING FAN CIRCUIT
98360.1	VALVE, CONTROL ELECTRIC		347	REAR HYDRAULIC FUNCTION
			351	REAR HYDRAULIC HOOK
98375.9	CONTROL VALVE		143	STABILIZER SELECTOR VALVES
98583.8	O-RING		333	HYDRAULIC TANK FILLING KIT
98653.9	SCREW		185	HYDROSTATIC PUMP ASSY
98695.0	GASKET		185	HYDROSTATIC PUMP ASSY
98897.2	SCREW	68566.9	143	STABILIZER SELECTOR VALVES

Part Number	Denomination	WAS	Page	Subgroup
			243	COOLING FAN CIRCUIT
P02645	RIVET		327	FLOATING PALLET FORKS