


## **2010 Toyota Prius**

## SYSTEM WIRING DIAGRAMS


**Fig. 20: 1.8L, Engine Controls Circuit (1 of 4)**



**2010 Toyota Prius**

## SYSTEM WIRING DIAGRAMS


**Fig. 21: 1.8L, Engine Controls Circuit (2 of 4)**



# 2010 Toyota Prius

## SYSTEM WIRING DIAGRAMS


Fig. 22: 1.8L, Engine Controls Circuit (3 of 4)



## 2010 Toyota Prius

## SYSTEM WIRING DIAGRAMS


**Fig. 23: 1.8L, Engine Controls Circuit (4 of 4)**



## **2010 Toyota Prius**

## SYSTEM WIRING DIAGRAMS


**Fig. 24: 1.8L, Hybrid System Circuit (1 of 6)**



## **2010 Toyota Prius**


## SYSTEM WIRING DIAGRAMS

**Fig. 25: 1.8L, Hybrid System Circuit (2 of 6)**



## 2010 Toyota Prius


## SYSTEM WIRING DIAGRAMS



## **2010 Toyota Prius**

## SYSTEM WIRING DIAGRAMS


**Fig. 27: 1.8L, Hybrid System Circuit (4 of 6)**



## **2010 Toyota Prius**

## SYSTEM WIRING DIAGRAMS

**Fig. 28: 1.8L, Hybrid System Circuit (5 of 6)**



## **2010 Toyota Prius**

## SYSTEM WIRING DIAGRAMS

**Fig. 29: 1.8L, Hybrid System Circuit (6 of 6)**

