


I. GENERAL VIEW



4-DOOR NOTCH BACK



3-DOOR HATCH BACK



5-DOOR HATCH BACK

II. MODEL & OPTION

1. MODEL

ENGINE	T/A	BODY	LEVEL
Y / 6	M / A	4N / 3H / 5H	S / SE / SX

■ ENGINE TYPE

- Y : 1.5L SOHC
- 6 : 1.6L DOHC
- . : Common

■ T/A(TRANSAXLE)TYPE

- M : Manual T/A
- A : Automatic T/A
- . : Common

■ BODY TYPE

- 4N : 4 Door Notchback
- 3H : 3 Door Hatchback
- 5H : 5 Door Hatchback

NOTE : Please be sure to read "the EXPLANATION OF CATALOG COMPOSITION" to find out the details on "the MODEL COLUMN".

2. OPTION

CODE	DESCRIPTION	BODY			LEVEL		
		4 N	3 H	5 H	S	S E	S X
A31	Window-power,front&rear	B	.	B	.	O	O
A32	Window-power,front	B	B	B	O	O	B
ABF	Air bag-dual	B	B	B	.	O	O
AJ3	Air bag-driver side only	B	B	B	.	O	O
AU3	Central door lock	B	B	B	O	O	B
C59	Uncompleted Air conditioner	B	B	B	O	O	O
C60	Air conditioner	B	B	B	O	O	O
CF6	Sun roof,power	B	B	B	O	O	O
JL9	Antilock brake system	B	B	B	.	O	O
ML4	4 speed automatic T/A	B	B	B	O	O	O
N40	Power steering	B	B	B	O	O	B
PG4	Alloy wheel,5.5JX14	B	B	B	.	.	O
T45	Rear spoiler	.	B	B	.	.	O
U83	Speaker-coaxial 2 way	B	B	B	.	O	O
UNA	Cassette(mech), 7wX2ch(AKF-4331)	B	B	B	O	O	O
UN1	Cassette(mech),25wX2ch(AKF-4036)	B	B	B	O	O	O
UN6	Cassette(logic) ,25wX4ch(AKF-0816)	B	B	B	.	O	O
W8V	CD player	B	B	B	.	O	O

- O : OPTION
- B : BASE
- . : NOT APPLICABLE

III. COLOR CODE TABLE

When order the color parts, the color code should be quoted.

EXTERIOR COLOR		INTERIOR COLOR
CODE	DESCRIPTION	
11U	GALAXY WHITE	GREY
21U	AZURITE BLUE	GREY
27U	VIOLET BLUE	GREY
42U	DEEP BLUISH GREEN	GREY
43U	LIGHT EVERGREEN	GREY
73L	SUPER RED	GREY
74U	SPINEL RED	GREY
81U	STREAMLINE GREY	GREY
83L	GRANADA BLACK	GREY
92U	POLY SILVER	GREY

⑧ MODEL

This column indicates Engine type, Transaxle type, Body type, Trim level.

■ ENG(ENGINE) TYPE

- Y : 1.5L SOHC
- 6 : 1.6L DOHC
- . : COMMON

■ T/A(TRANSAXLE)TYPE

- M : Manual T/A
- A : Automatic T/A
- . : Common

■ BODY TYPE

- 4N : 4 Door Notchback
- 3H : 3 Door Hatchback
- 5H : 5 Door Hatchback

"BODY" column indicates the expression of applicable body type.
B : Applicable
. : Not applicable


■ TRIM LEVEL

- S
- SE
- SX

"LEVEL" column indicates the expression of applicable trim level.
S : Standard equipment.
O : Option equipment.
A : Available equipment for the special package according to the area regulation

⑨ OPTION

This column indicates option code.
Refer to "VI.OPTION CODE TABLE"
ex) OOOO



⑩ L/R

This column indicates the mounting position of a part.
LH : Left hand side
RH : Right hand side

⑪ Q'TY

This column indicates the quantity required per sub-group.
The quantity is normally shown by number or symbol as below.
A : As required quantity.

⑫ EFFECTIVE DATE

This column indicates effective " date in production".
It is shown by the year,month and date or start of production(S.O.P).

⑬ REMARKS

Supplementary or reference information is given in this column.
(examples)
Specification,Use,Type,Applicable country etc.

⑭ PART IDENTIFICATION CODE

This column Indicates part identification code that is marked with two characters.
Part identification code will help you in discriminating a part easily.
But, all parts will not always carry the part identification code.

V. CONSTRUCTION OF VEHICLE IDENTIFICATION NUMBER

K L A T F 69 Y E V B 123456

- Nation of Origin
  K:Korea
- Manufacturer
  L:Daewoo motor co.,Ltd.
- Vehicle Type
  A:Passenger Car
- Car Line
  T:Lanos
- Drive System&T/M Type
  F:Front Wheel Drive
  Manual T/M
  A:Front Wheel Drive
  Automatic T/M
- Body Type
  08: 3 Door Hatchback, 4 windows
  48: 5 Door Hatchback, 4 windows
  69: 4 Door Notchback, 4 windows
- Engine Type
  C:1.4L SOHC Mpfi Fam I
  Y:1.5L SOHC Mpfi Fam I
  6: 1.6L DOHC Mpfi Fam I
- Vehicle Use
  E:Export
- Model Year
  V:1997 W:1998
- Assembly Plant
  B:Bupyeong plant
  K:Kunsan plant
- Serial No.


LOCATION OF VEHICLE INDENTIFICATION NUMBER

DAEWOO MOTOR CO.,LTD

VIN APPROVAL NO.


K L A T F 69 Y E V B 123456

CROSS VEHICLE WEIGHT	kg
CROSS COMBINATION VEHICLE WEIGHT	kg
MAXIMUM PERMISSIBLE AXLE FRONT	kg
MAXIMUM PERMISSIBLE AXLE REAR	kg



1 ENGINE


1110 ENGINE UNIT(SOHC)
1111 ENGINE UNIT(DOHC)
1120 SHORT ENGINE
1130 BELT SYSTEM
1140 REPAIR KIT(SOHC)
1141 REPAIR KIT(DOHC)
1210 ENGINE BLOCK
1220 CRANKSHAFT&PISTON
1230 OIL PAN&PUMP
1240 ENGINE OIL VENTILATION
1310 CYLINDER HEAD(SOHC)
1311 CYLINDER HEAD(DOHC)
1320 CAM SUPPORT&SHAFT(SOHC)
1321 CAM SUPPORT&SHAFT(DOHC)
1330 TIMING COVER(SOHC)
1331 TIMING COVER(DOHC)
1610 RADIATOR
1630 COOLING FAN
1650 RADIATOR HOSE&PIPE(SOHC)
1651 RADIATOR HOSE&PIPE(DOHC)
1680 THERMOSTAT(SOHC)
1681 THERMOSTAT(DOHC)
1690 OIL COOLER PIPE(A/T)
1710 IGNITION CABLE(SOHC)
1711 IGNITION CABLE(DOHC)
1740 ALTERNATOR UNIT(12V,85A)
1741 ALTERNATOR UNIT(12V,95A)
1750 ALTERNATOR MOUNT(SOHC)
1751 ALTERNATOR MOUNT(DOHC)
1760 STARTER(0.8KW)
1761 STARTER(1.4KW)
1910 ENGINE MOUNT



2

KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)ENGINE A *(D)MOTOR*										*(F)MOTEUR (S)MOTOR*					
	96184293	Y	M	B	B	B	S	S	S	&NN4-XCA		1				HF
	96352333	Y	M	B	B	B	A	A	A	&NN4&XCA		1				H2
	96184301	Y	M	B	B	B	A	A	A	&NN6-XCA		1				HB
	96352331	Y	M	B	B	B	A	A	A	&NN6&XCA		1				H8
	96350294	Y	M	B	B	B	A	A	A	&NN7-XCA		1				HJ
	96352335	Y	M	B	B	B	A	A	A	&NN7&XCA		1				H6
	96184297	Y	A	B	B	B	O	O	O	&NN4-XCA		1				HH
	96352334	Y	A	B	B	B	A	A	A	&NN4&XCA		1				H3
	96184305	Y	A	B	B	B	A	A	A	&NN6-XCA		1				HD
	96352332	Y	A	B	B	B	A	A	A	&NN6&XCA		1				H9
	96350292	Y	A	B	B	B	A	A	A	&NN7-XCA		1				HL
	96352336	Y	A	B	B	B	A	A	A	&NN7&XCA		1				H7
[02]	(E)SHACKLE-ENGINE TRANSPORT *(D)HALTER,MOTOR TRANSPORT*										*(F)BRIDES-TRANSPORT (S)GRILLETE-TRANSPORTE*					
	90076951	Y	.	B	B	B	S	S	S			2				
[05]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON (S)PERNO*					
	02865535	Y	.	B	B	B	S	S	S			1			M8X22	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)ENGINE A *(D)MOTOR*										*(F)MOTEUR* *(S)MOTOR*					
96350534	6	M	B	B	B	.	.	O	&NN4-XHA		1					UB
96352343	6	M	B	B	B	.	.	A	&NN4&XHA		1					U2
96352351														NOT APPLIED		
96352339														NOT APPLIED		
96184154	6	M	B	B	B	.	.	A	&NN7-XHA		1					UJ
96352347	6	M	B	B	B	.	.	A	&NN7&XHA		1					U6
96352477														NOT APPLIED		
96352761	6	M	B	B	B	.	.	A	&KL9		1			FOR BRAZIL		G2
96350538	6	A	B	B	B	.	.	O	&NN4-XHA		1					UF
96352345	6	A	B	B	B	.	.	A	&NN4&XHA		1					U3
96352353														NOT APPLIED		
96352341														NOT APPLIED		
96184157	6	A	B	B	B	.	.	A	&NN7-XHA		1					UN
96352349	6	A	B	B	B	.	.	A	&NN7&XHA		1					U7
96352479														NOT APPLIED		
96352763	6	A	B	B	B	.	.	A	&KL9		1			FOR BRAZIL		G3
[02]	(E)SHACKLE-ENGINE TRANSPORT *(D)HALTER,MOTOR TRANSPORT*										*(F)BRIDES-TRANSPORT* *(S)GRILLETE-TRANSPORTE*					
5094021004	6	.	B	B	B	.	.	O			1					
[03]	(E)SHACKLE-ENGINE TRANSPORT *(D)HALTER,MOTOR TRANSPORT*										*(F)BRIDES-TRANSPORT* *(S)GRILLETE-TRANSPORTE*					
96130851	6	.	B	B	B	.	.	O			1					
[05]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

11 ENGINE UNIT(DOHC)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09117-08011	6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)SHORT BLOCK A (D)KURZ BLOCK									(F)BLOC COURT (S)BLOQUE CORTO					
	A96184803Y	Y	M	B	B	B	S	S	S			1				
	A96184804Y	Y	A	B	B	B	O	O	O			1				
	A96184805W	6	M	B	B	B	.	.	O			1				
	A96184806W	6	A	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)V BELT (D)V GURT										(F)COURROIE EN V (S)CORREA V				
	96350467	.	.	B	B	B	O	O	O	&C60		1			840mm	
	[02]	(E)V BELT (D)V GURT										(F)COURROIE EN V (S)CORREA V				
	96144933	Y	.	B	B	B	O	O	S	&N40-XHA		1			970mm	
	96352454	Y	.	B	B	B	A	A	A	&N40&XHA		1				
	96144934	6	.	B	B	B	.	.	O	&N40-XHA		1			1008mm	
	96352455	6	.	B	B	B	.	.	A	&N40&XHA		1				
	[03]	(E)V BELT (D)V GURT										(F)COURROIE EN V (S)CORREA V				
	96144932	.	.	B	B	B	S	S	.	&N51-XHA		1			925mm	
	96352456	.	.	B	B	B	A	A	.	&N51&XHA		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.		PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)GASKET KIT-ENG OVERHAUL *(D)DICHTUNGS-SATZ,ÜBERHOLUNG*									*(F)JEU DE JOINTS* *(S)JUEGO DE JUNTA*					
	S1140005	Y	.	B	B	B	S	S	S			1				
												1			REFER TO BELOW	
										- CONSIST OF -						
										ⓐ : GASKET-THROTTLE BODY		1			2210-02	
										ⓑ : GASKET-INTAKE MANIFOLD		1			2430-02	
										ⓒ : SEAL-BAYONET CAP		1			1320-02	
										ⓓ : GASKET-CAMSHAFT SUPT CVR		1			1320-05	
										ⓔ : RING-CAMSHAFT SEAL		1			1320-11	
										ⓕ : RING-THER. HOUSING SEAL		1			1680-02	
										ⓖ : GASKET-CYLINDER HEAD		1			1310-22	
										ⓗ : GASKET-EXH. MANIFOLD		1			2440-02	
										ⓘ : RING-CYL. BLOCK SEAL		1			1330-02	
										ⓚ : GASKET-OIL PUMP BODY		1			1230-11	
										ⓛ : RING-OIL PUMP SEAL		1			1230-05	
										ⓜ : RING-CRANKSHAFT SEAL		1			1230-02	
										ⓝ : WASHER-PLAIN		1			1230-15	
										ⓞ : RING-SEAL		1			1230-20	
										ⓟ : RING-CRANKSHAFT SEAL		1			1220-09	
										ⓠ : GASKET-OIL PAN		1			9120-13	

GROUP NO / KEY NO


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]	S1141024	(E)GASKET KIT-ENG OVERHAUL *(D)DICHTUNGS-SATZ,ÜBERHOLUNG*								*(F)JEU DE JOINTS* *(S)JUEGO DE JUNTA*						
		6	.	B	B	B	.	.	O			1				
												1			REFER TO BELOW	
		- CONSIST OF -														
										ⓐ : GASKET-THROTTLE BODY		1			2211-02	
										ⓑ : GASKET-INTAKE MANIFOLD		1			2431-02	
										ⓒ : SEAL-BAYONET CAP		1			1321-02	
										ⓓ : GASKET-CAMSHAFT SUPT CVR		1			1321-09	
										ⓔ : RING-CAMSHAFT SEAL		2			1321-11	
										ⓕ : RING-THER. COVER SEAL		1			1681-01	
										ⓖ : RING-THER. HOUSING SEAL		1			1681-04	
										ⓗ : GASKET-CYLINDER HEAD		1			1311-25	
										ⓘ : GASKET-EXH. MANIFOLD		1			2441-02	
										ⓙ : RING-CYL. BLOCK SEAL		1			1331-02	
										ⓚ : GASKET-OIL PUMP BODY		1			1230-11	
										ⓛ : RING-OIL PUMP SEAL		1			1230-05	
										ⓜ : RING-CRANKSHAFT SEAL		1			1230-02	
										ⓝ : WASHER-PLAIN		1			1230-15	
										ⓞ : RING-SEAL		1			1230-20	
										ⓟ : RING-CRANKSHAFT SEAL		1			1220-09	
										ⓠ : GASKET-OIL PAN		1			9120-13	


9120-13: GROUP NO / KEY NO

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)BLOCK A-CYLINDER (D)BLOCK,ZYLINDER									(F)BLOC-CYLINDRE (S)BLOQUE-CILINDRO					
A96184803		Y	M	B	B	B	S	S	S			1				
A96184804		Y	A	B	B	B	O	O	O			1				
A96184805		6	M	B	B	B	.	.	O			1				
A96184806		6	A	B	B	B	.	.	O			1				
[02]		(E)CAP (D)DECKEL									(F)CHAPEAU (S)TAPA					
96180730		.	.	B	B	B	S	S	S			6			34-STD	
11070803		.	.	B	B	B	S	S	S			6			36-OIS	
[03]		(E)PLUG-IGNITION TIMING (D)STÖPSEL									(F)BOUCHON (S)TAPON-TIEMPO DE IGNICION					
90091048		.	.	B	B	B	S	S	S			1	971001			
[04]		(E)BUSHING-IGNITION TIMING (D)LAGERFUTTER									(F)MANCHON (S)BUJE-TIEMPO DE IGNICION					
90091049		.	.	B	B	B	S	S	S			1				
[05]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
09100-10008		.	.	B	B	B	S	S	S			10				
[06]		(E)NECK-WATER INLET (D)HALS,WASSERLEITUNG									(F)COU-ENTREE EAU (S)CUELLO-ENTRADA DE AGUA					
96351207		.	.	B	B	B	S	S	S			1				
[07]		(E)SLEEVE (D)HÜLSE,KUPPLUNG GEHÄUSE									(F)CHEMISE (S)MANGA-CARTER DE EMBRAGUE					
90108591		.	.	B	B	B	S	S	S			2				
[08]		(E)STICK A-OIL LEVEL GAUGE (D)MEßSTAB,ÖL PEGEL									(F)JAUGE (S)VARILLA-MEDIDOR					
96352131		.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96352132	.	A	B	B	B	O	O	O			1				
	[09]	(E)TUBE-GAUGE STICK (D)ROHRLEITUNG,MEßSTAB														
	96352134	.	.	B	B	B	S	S	S			1				
	[10]	(E)VALVE A-BYPASS (D)VENTIL,ÜBERGANG														
	90136113	.	.	B	B	B	S	S	S			1				
	[11]	(E)SLEEVE (D)HÜLSE														
	90091779	.	.	B	B	B	S	S	S			2				
	[12]	(E)PLUG (D)STÖPSEL														
	09246-14001	.	.	B	B	B	S	S	S			2				
	[13]	(E)SENSOR-KNOCK (D)SENSOR														
	10456240	6	.	B	B	B	.	.	O			1				
	[14]	(E)BOLT (D)SCHRAUBE														
	09111-08002	6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)PISTON (D)KOLBEN									(F)PISTON (S)PISTON					
	96350120	Y	.	B	B	B	S	S	S			4			STD	
	S1220008	Y	.	B	B	B	S	S	S			4			O/S 0.25	
	S1220009	Y	.	B	B	B	S	S	S			4			O/S 0.5	
	96182846	6	.	B	B	B	.	.	O			4			STD	
	S1220019	6	.	B	B	B	.	.	O			4			O/S 0.25	
	S1220020	6	.	B	B	B	.	.	O			4			O/S 0.5	
	[02]	(E)PIN-PISTON (D)STIFT,KOLBEN									(F)BROCHE-PISTON (S)PASADOR-PISTON					
	96110730	Y	.	B	B	B	S	S	S			4				
	96350355	6	.	B	B	B	.	.	O			4				
	[03]	(E)RING SET-PISTON (D)RING SATZ,KOLBEN									(F)JEU DE SEGMENTS-PISTON (S)JUEGO DE ANILLOS-PISTON					
	NP960	Y	.	B	B	B	S	S	S			1			STD	
	NP1015	Y	.	B	B	B	S	S	S			1			O/S 0.25	
	NP1016	Y	.	B	B	B	S	S	S			1			O/S 0.5	
	S1220014	6	.	B	B	B	.	.	O			1			STD	
	S1220015	6	.	B	B	B	.	.	O			1			O/S 0.25	
	S1220016	6	.	B	B	B	.	.	O			1			O/S 0.5	
	[04]	(E)ROD A- CONNECTING (D)STAB,VERBINDUNGS									(F)BIELLE-BIELLE (S)VARILLA-CONECTANDO					
	A90281724	.	.	B	B	B	S	S	S			4				
	[05]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09100-08004	.	.	B	B	B	S	S	S			8				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[06]		(E)BEARING SET-CONNECTING ROD (D)KUGELLAGER									(F)ROULEMENT-BIELLE (S)COJINETE-VARA DE CONEXION					
96351662S		.	.	B	B	B	S	S	S			1				
96351663S		.	.	B	B	B	S	S	S			1				
[07]		(E)CRANKSHAFT A (D)KURBELWELLE									(F)VILEBREQUIN (S)CIGUEÑAL					
A96350171		.	.	B	B	B	S	S	S			1				
[08]		(E)BEARING SET-CRANKSHAFT (D)KUGELLAGER STELLUNG									(F)JEU DE ROULEMENT (S)JUEGO DE COJINETE					
S1220012		.	.	B	B	B	S	S	S			1			STD	
S1220013		.	.	B	B	B	S	S	S			1			U/S 0.25	
[09]		(E)RING-SHAFT SEAL (D)RING,STAB DICHTUNG									(F)ANNEAU-JOINT D'ARBRE (S)ANILLO-BROCHE DE EJE					
96101489		.	.	B	B	B	S	S	S			1			80X98X10	
[10]		(E)FLYWHEEL A (D)SCHWUNGRAD									(F)VOLANT D'ENTRAINEMENT (S)VOLANTE					
96184979		Y	M	B	B	B	S	S	S			1				
96184353		6	M	B	B	B	.	.	O			1			POT	
[11]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
09100-09001		Y	M	B	B	B	S	S	S			6				
09100-09003		6	M	B	B	B	.	.	O			6				
[12]		(E)PLATE A-FLEXIBLE (D)PLATTE,FLEXIBEL									(F)PLAQUE-FLEXIBLE (S)PLACA-FLEXIBLE					
90236309		.	A	B	B	B	O	O	O			1				
[13]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
09100-09004		.	A	B	B	B	O	O	O			6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)PUMP A-OIL (D)PUMPE,ÖL													(F)POMPE-HUILE (S)BOMBA-ACEITE	
	96350159	.	.	B	B	B	S	S	S			1				
[02]		(E)RING-SHAFT SEAL (D)RING,KURBELWELLE DICHTUNG													(F)ANNEAU-JOINT VILEBREQUIN (S)ANILLO-SELLO DE CIGUEÑAL	
	96350161	.	.	B	B	B	S	S	S			1			30X42X8	
[03]		(E)PLUNGER-PRESS VALVE (D)TAUCHER													(F)PISTON PLONGEUR (S)EMBOLO	
	03448846	.	.	B	B	B	S	S	S			1				
[04]		(E)SPRING (D)FEDERUNG													(F)RESSORT (S)RESORTE	
	03448847	.	.	B	B	B	S	S	S			1				
[05]		(E)RING-SEAL (D)RING,ÖLPUMPE DICHTUNG													(F)ANNEAU (S)ANILLO-SELLO	
	11093042	.	.	B	B	B	S	S	S			1				
[06]		(E)PLUG-SCREW (D)STÖPSEL,SCHRAUBEN													(F)BOUCHON-VIS (S)TAPON-TORNILLO	
	03448834	.	.	B	B	B	S	S	S			1			M20X1.5	
[07]		(E)ROTOR-OIL PUMP OUTER (D)DREHTEIL													(F)ROTOR (S)ROTOR	
	96350165	.	.	B	B	B	S	S	S			1				
[08]		(E)ROTOR-OIL PUMP INNER (D)DREHTEIL													(F)ROTOR (S)ROTOR	
	96350164	.	.	B	B	B	S	S	S			1				
[09]		(E)COVER-OIL PUMP (D)DECKEL,ÖLPUMPE													(F)CARTER-POMPE A HUILE (S)CUBIERTA-BOMBA DE ACEITE	
	96350166	.	.	B	B	B	S	S	S			1				
[10]		(E)SCREW (D)SCHRAUBE													(F)VIS (S)TORNILLO	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	11085861	.	.	B	B	B	S	S	S			5			M6X14	
	[11]	(E)GASKET-OIL PUMP BODY (D)DICHTUNG,ÖL-PUMPE-KÖRPER										(F)JOINT-CORPS POMPE A HUILE (S)JUNTA-CUERPO DE BOMBA				
	96181208	.	.	B	B	B	S	S	S	&NN4		1				
	96100599	.	.	B	B	B	A	A	A	&NN5		1				
	90353564	.	.	B	B	B	A	A	A	&NN7		1		970608		
Y	96181208	.	.	B	B	B	A	A	A	&NN7		1	970608			
	[12]	(E)SLEEVE-OIL PUMP (D)HÜLSE,ÖLPUMPE										(F)CHEMISE-POMPE A HUILE (S)MANGA-BOMBA DE ACEITE				
	90096047	.	.	B	B	B	S	S	S			2				
	[13]	(E)PLUG-SCREW (D)STÖPSEL,SCHRAUBEN										(F)BOUCHON-VIS (S)TAPON-TORNILLO				
	09246-18002	.	.	B	B	B	S	S	S			1				
	[14]	(E)BOLT-HEXAGON (D)SCHRAUBE										(F)BOULON (S)PERNO				
	01130-06253														NOT APPLIED	
	09117-06008	.	.	B	B	B	S	S	S			6				
	[15]	(E)WASHER-PLAIN (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	09160-14003	.	.	B	B	B	S	S	S			1				
	[16]	(E)SWITCH A-OIL PRESSURE (D)SCHALTER,ÖL DRUCK										(F)COMMUTATEUR (S)INTERRUPTOR				
	90336039	.	.	B	B	B	S	S	S			1				
	[18]	(E)PIPE A-OIL SUCTION (D)ROHR,ÖL SAUG										(F)TUYAU-ASPIRATION HUILE (S)TUBERIA-SUCCION DE ACEITE				
	90410981	.	.	B	B	B	S	S	S			1				
	[19]	(E)BRACKET-OIL SUCTION PIPE (D)TRÄGER,ÖLLEITUNGSROHR										(F)SUPPORT (S)SOPORTE				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	90076916	.	.	B	B	B	S	S	S			1				
	[20]	(E)RING-SEAL *(D)RING,DICHTUNG*										*(F)ANNEAU-JOINT* *(S)ANILLO-SELLO*				
	90190637	.	.	B	B	B	S	S	S			1				
	[21]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09117-06001	.	.	B	B	B	S	S	S			2				
	[22]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	01130-06129	.	.	B	B	B	S	S	S			1				
	[23]	(E)PAN A-OIL *(D)PFANNE,ÖL*										*(F)CARTER-HUILE* *(S)RECIPIENTE-ACEITE*				
	96351480	.	.	B	B	B	S	S	S	-NN7		1		971001	STEEL	
	96350495	.	M	B	B	B	A	A	A	&NN7		1		970617	ALUMINUM	
O	96351600	.	M	B	B	B	A	A	A	&NN7		1	970617	971001	ALUMINUM	
	96351480	.	A	B	B	B	A	A	A	&NN7		1		971001	STEEL	
	96351480	Y	M	B	B	B	S	S	S	-NN4&XCA		1	971001		STEEL	
	96351480	Y	M	B	B	B	S	S	S	-NN7		1	971001		STEEL	
	96351600	Y	M	B	B	B	A	A	A	&NN4&XCA		1	971001		ALUMINUM	
	96351600	Y	M	B	B	B	A	A	A	&NN7		1	971001		ALUMINUM	
	96351480	Y	A	B	B	B	O	O	O			1	971001		STEEL	
	96351480	6	.	B	B	B	.	.	O	-NN7		1	971001		STEEL	
	96351600	6	M	B	B	B	.	.	A	&NN7		1	971001		ALUMINUM	
	96351480	6	A	B	B	B	.	.	A	&NN7		1	971001		STEEL	
	[24]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09100-14005	.	.	B	B	B	S	S	S			1				
	[25]	(E)RING-THREADED (D)RING,SCHRAUBENGEWINDE										(F)ANNEAU-FILETE (S)ANILLO-CON ROSCA				
	96351497	.	.	B	B	B	S	S	S			1				
	[26]	(E)WASHER-PLAIN (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	09160-14003	.	.	B	B	B	S	S	S			1				
	[29]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	09117-06005	.	.	B	B	B	S	S	S	-NN7		15		970701		
Y	09103-06007	.	.	B	B	B	S	S	S	-NN7		15	970701	971001		
	09117-06006	.	M	B	B	B	A	A	A	&NN7		15		970701		
Y	09103-06006	.	M	B	B	B	A	A	A	&NN7		15	970701	971001		
	09117-06005	.	A	B	B	B	A	A	A	&NN7		15		970701		
Y	09103-06007	.	A	B	B	B	A	A	A	&NN7		15	970701	971001		
	09103-06007	.	.	B	B	B	S	S	S			15	971001		FOR STEEL OIL PAN	
	09103-06006	.	.	B	B	B	S	S	S			15	971001		FOR ALUMINUM OIL PAN	
	[30]	(E)FILTER A-OIL (D)FILTER,ÖL										(F)FILTRE-HUILE (S)FILTRO-ACEITE				
	94797406	.	.	B	B	B	S	S	S			1				
	[31]	(E)PIECE-CONNECTING (D)TEIL,VERBINDUNGS										(F)PIECE-DE CONNEXION (S)PIEZA-CONEXION				
	90144360	.	.	B	B	B	S	S	S			1				
	[32]	(E)GASKET-OIL PAN (D)DICHTUNG,ÖL-PFANNE										(F)JOINT-CARTER D'HUILE (S)JUNTA				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		REFER GROUP 9120 KEY NO. 13										1			SEALING	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1240 ENGINE OIL VENTILATION




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)GASKET-OIL SEPARATOR (D)DICHTUNG,ÖL TRENNUNG									(F)JOINT-SEPARATEUR D'HUILE (S)JUNTA-SEPARADOR DE ACEITE					
[01]																
96181209		.	.	B	B	B	S	S	S			1				
		(E)BOLT-HEX PILOT (D)SCHRAUBE									(F)BOULON (S)PERNO					
[02]																
02647-06165		.	.	B	B	B	S	S	S			2				
		(E)PIPE A-ENGINE VENTILATION (D)ROHR,MOTOR BELÜFTUNG									(F)TUYAU-VENTILATION MOTEUR (S)TUBERIA-VENTILACION					
[03]																
96143870		Y	.	B	B	B	S	S	S			1				
96130215		6	.	B	B	B	.	.	O			1				
		(E)CLAMP-SPRING (D)KLAMMER									(F)PINCE (S)ABRAZADERA					
[04]																
09401-27403		Y	.	B	B	B	S	S	S			2				
11085952		6	.	B	B	B	.	.	O			2			20-32	
		(E)HOSE-ENGINE VENTILATION (D)SCHLAUCH,MOTOR BELÜFTUNG									(F)TUYAU-VENTILATION MOTEUR (S)MANGUERA-VENTILACION					
[05]																
90409191		Y	.	B	B	B	S	S	S			1				
5094405002		6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]										(E)HEAD A-CYLINDER *(D)ZYLINDERKOPF* *(F)CULASSE-CYLINDRE* *(S)CABEZA-CILINDRO*						
	A96182931	Y	.	B	B	B	S	S	S				1				
	[02]										(E)GUIDE-VALVE *(D)FÜHRING,VENTIL* *(F)GUIDE-SOUPAPE* *(S)GUIA-VALVULA*						
	90108699	Y	.	B	B	B	S	S	S				4		970819	INTAKE,STD	
	90108700	Y	.	B	B	B	S	S	S				4		970819	INTAKE,O/S	
	96350912	Y	.	B	B	B	S	S	S				4		970819	EXHAUST,STD	
	96350913	Y	.	B	B	B	S	S	S				4		970819	EXHAUST,O/S	
	96350912	Y	.	B	B	B	S	S	S				B	970819		STD	
	96350913	Y	.	B	B	B	S	S	S				B	970819		O/S	
	[03]										(E)ADAPTER *(D)ADAPTER* *(F)ADAPTATEUR* *(S)ADAPTADOR*						
	90299068	Y	.	B	B	B	S	S	S				1				
	[04]										(E)CAP-OIL DUCT *(D)DECKEL,ÖL-LEITUNG* *(F)CHAPEAU-CONDUIT HUILE* *(S)TAPA-CONDUCTO DE ACEITE*						
	96180732	Y	.	B	B	B	S	S	S				1			Φ 20	
	[05]										(E)CAP-OIL DUCT *(D)DECKEL,ÖL-LEITUNG* *(F)CHAPEAU-CONDUIT HUILE* *(S)TAPA-CONDUCTO DE ACEITE*						
	11062401	Y	.	B	B	B	S	S	S				1			Φ 18	
	[06]										(E)SLEEVE *(D)HÜLSE* *(F)CHEMISE* *(S)MANGA*						
	90108642	Y	.	B	B	B	S	S	S				1				
	[07]										(E)SENSOR-TEMPERATURE *(D)SENSOR,TEMPERATUR* *(F)DETECTEUR-TEMPERATURE* *(S)SENSOR-TEMPERATURA*						
	96181508	Y	.	B	B	B	S	S	S				1				
	[08]										(E)VALVE-EXHAUST *(D)VENTIL,ABGAS* *(F)SOUPAPE-ECHAPPEMENT* *(S)VALVULA-ESCAPE*						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	96182933	Y	.	B	B	B	S	S	S			4				
	[09]	(E)VALVE-INTAKE *(D)VENTIL,EINLAß*										*(F)SOUPAPE-ADMISSION* *(S)VALVULA-ENTRADA*				
	96182934	Y	.	B	B	B	S	S	S			4				
	[10]	(E)SEAT-INTAKE VALVE SPRING *(D)SITZ,EINLAßVENTIL*										*(F)SIEGE* *(S)ASIENTO-RESORTE*				
	90128720	Y	.	B	B	B	S	S	S			4				
	[11]	(E)CAP-EXHAUST VALVE ROTARY *(D)DECKEL,ABGASVENTIL DREHTE*										*(F)CHAPEAU* *(S)TAPA-ROTATORIO*				
	90106266	Y	.	B	B	B	S	S	S			4				
	[12]	(E)SEAL-VALVE STEM *(D)DICHTUNG,VENTIL STIEL*										*(F)JOINT-TIGE DE SOUPAPE* *(S)SELLO-TALLO DE VALVULA*				
	90215296	Y	.	B	B	B	S	S	S			8				
	[13]	(E)SPRING-VALVE *(D)FEDERUNG,VENTIL*										*(F)RESSORT-SOUPAPE* *(S)RESORTE-VALVULA*				
	90180310	Y	.	B	B	B	S	S	S			8				
	[14]	(E)PLATE-VALVE SPRING *(D)PLATTE*										*(F)PLAQUE- RESSORT DE SOUPAP* *(S)PLACA-RESORTE DE VALVUL*				
	90280894	Y	.	B	B	B	S	S	S			8				
	[15]	(E)KEY-VALVE *(D)SCHLÜßEL,VENTIL*										*(F)CLE-SOUPAPE* *(S)LLAVE-VALVULA*				
	90076732	Y	.	B	B	B	S	S	S			16				
	[16]	(E)PIECE-VALVE THRUST *(D)TEIL,SCHUB*										*(F)PIECE-BUTEE DE SOUPAPE* *(S)PIEZA-EMPUJE VALVULA*				
	96144735	Y	.	B	B	B	S	S	S			8				
	[17]	(E)FOLLOWER-CAM *(D)ANHÄNGER,NOCKE*										*(F)SATELLITE-CAME* *(S)SEGUIDOR-LEVA*				
	96351051	Y	.	B	B	B	S	S	S			8				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[18]		(E)LIFTER A-CAM FOLLOWER *(D)HEBER,NOCKEN ANHÄNGER*										*(F)LEVIER-SATELLITE DE CAME* *(S)LEVANTADOR*			
05233315		Y	.	B	B	B	S	S	S			8				
[19]		(E)BOLT-STUD *(D)STIFTSCHRAUBE*										*(F)BOULON-TETON* *(S)PERNO-ESPIGA*				
09108-08002		Y	.	B	B	B	S	S	S			13				
[20]		(E)BOLT-STUD *(D)STIFTSCHRAUBE*										*(F)BOULON-TETON* *(S)PERNO-ESPIGA*				
09108-08003		Y	.	B	B	B	S	S	S			4				
[22]		(E)GASKET-CYLINDER HEAD *(D)DICHTUNG,ZYLINERKOPF*										*(F)JOINT-CULASSE CYLINDRE* *(S)JUNTA*				
96181216		Y	.	B	B	B	S	S	S			1				
[23]		(E)PLUG-SCREW *(D)STÖPSEL,SCHRAUBEN*										*(F)BOUCHON-VIS* *(S)TAPON-TORNILLO*				
09246-10001		Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)HEAD A-CYLINDER (D)ZYLINDERKOPF									(F)CULASSE-CYLINDRE (S)CABEZA-CILINDRO					
	A96350007	6	.	B	B	B	.	.	O			1				
[02]		(E)GUIDE-VALVE (D)FÜHRING,VENTIL									(F)GUIDE-SOUPAPE (S)GUIA-VALVULA					
	96103034	6	.	B	B	B	.	.	O			16			STD	
	96103035	6	.	B	B	B	.	.	O			16			O/S	
[03]		(E)CAP-CAMSHAFT, FRONT (D)DECKEL,NOCKENWELLE,VORNE									(F)CHAPEAU (S)TAPA-CIGUEÑAL,DELANTERO					
	96143123	6	.	B	B	B	.	.	O			2				
[06]		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09103-06004	6	.	B	B	B	.	.	O			20				
[07]		(E)CAP-WATER CHAMBER (D)DECKEL,WASSER-KAMMER									(F)CHAPEAU-CHAMBRE A EAU (S)TAPA-CAMARA DE AGUA					
	11044142	6	.	B	B	B	.	.	O			1			26	
[08]		(E)CAP-OIL DUCT (D)DECKEL,ÖL-LEITUNG									(F)CHAPEAU-CONDUIT HUILE (S)TAPA-CONDUCTO DE ACEITE					
	96180732	6	.	B	B	B	.	.	O			3			20	
[09]		(E)PLUG-SCREW (D)STÖPSEL,SCHRAUBEN									(F)BOUCHON-VIS (S)TAPON-TORNILLO					
	09246-24001	6	.	B	B	B	.	.	O			2				
[10]		(E)PLUG-SCREW (D)STÖPSEL,SCHRAUBEN									(F)BOUCHON-VIS (S)TAPON-TORNILLO					
	09246-12001	6	.	B	B	B	.	.	O			5				
[11]		(E)VALVE-INTAKE (D)VENTIL,EINLAß									(F)SOUPAPE-ADMISSION (S)VALVULA-ENTRADA					
	96182806	6	.	B	B	B	.	.	O			8				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
[12]		(E)VALVE-EXHAUST *(D)VENTIL,ABGAS*													*(F)SOUPAPE-ECHAPPEMENT* *(S)VALVULA-ESCAPE*	
96182805		6	.	B	B	B	.	.	O			8				
[13]		(E)SEAL-VALVE STEM *(D)DICHTUNG,VENTIL STIEL*													*(F)JOINT-TIGE DE SOUPAPE* *(S)SELLO-TALLO DE VALVULA*	
96103095		6	.	B	B	B	.	.	O			16				
[14]		(E)SPRING-VALVE *(D)FEDERUNG,VENTIL*													*(F)RESSORT-SOUPAPE* *(S)RESORTE-VALVULA*	
96352140																NOT APPLIED
96352139		6	.	B	B	B	.	.	O			16				
[15]		(E)RETAINER-VALVE SPRING *(D)HALTER,VENTIL FEDERUNG*													*(F)ARRETOIR* *(S)RETENEDOR*	
5094005026		6	.	B	B	B	.	.	O			16				
[16]		(E)KEY-VALVE *(D)SCHLÜßEL,VENTIL*													*(F)CLE-SOUPAPE* *(S)LLAVE--VLVULA*	
5094005601		6	.	B	B	B	.	.	O			32				
[17]		(E)TAPPET-HYDRAULIC *(D)NOCKE,HYDRAULIK*													*(F)POUSSOIR-HYDRAULIQUE* *(S)GRIFO-HIDRAULICO*	
96134997		6	.	B	B	B	.	.	O			16				
[18]		(E)BOLT-STUD *(D)STIFTSCHRAUBE*													*(F)BOULON-TETON* *(S)PERNO-ESPIGA*	
09108-08005		6	.	B	B	B	.	.	O			10				
[19]		(E)BOLT-STUD *(D)STIFTSCHRAUBE*													*(F)BOULON-TETON* *(S)PERNO-ESPIGA*	
09108-08004		6	.	B	B	B	.	.	O			2				
[20]		(E)SENSOR A-TEMPERATURE *(D)SENSOR,TEMPERATUR*													*(F)DETECTEUR-TEMPERATURE* *(S)SENSOR-TEMPERATURA*	
96177604		6	.	B	B	B	.	.	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[21]	96181508	6	.	B	B	B	.	.	O	(E)SENSOR A-TEMPERATURE (D)SENSOR,TEMPERATUR		1			(F)DETECTEUR-TEMPERATURE (S)SENSOR-TEMPERATURA	
[22]	96144431	6	.	B	B	B	.	.	O	(E)BOLT-STUD (D)STIFTSCHRAUBE		11			(F)BOULON-TETON (S)PERNO-ESPIGA	
[23]	09103-10056	6	.	B	B	B	.	.	O	(E)BOLT-CYLINDER HEAD (D)SCHRAUBE,ZYLINDERKOPF		10			(F)BOULON-CULASSE (S)PERNO-TAPA DE CILINDRO	
[24]	09160-10007	6	.	B	B	B	.	.	O	(E)WASHER-CYLINDER HEAD (D)DICHTUNGSRING,ZYLINERKOPF		10			(F)RONDELLE-CULASSE CYLINDRE (S)ARANDELA	
[25]	96103003	6	.	B	B	B	.	.	O	(E)GASKET-CYLINDER HEAD (D)DICHTUNG,ZYLINERKOPF		1			(F)JOINT-CULASSE CYLINDRE (S)JUNTA	
[26]	96182808	6	.	B	B	B	.	.	O	(E)PIPE-HEATER TAKE OFF (D)ROHR		1			(F)TUYAU (S)TUBERIA	
[30]	96103076	6	.	B	B	B	.	.	O	(E)GASKET-EGR ADAPTER (D)DICHTUNG		1			(F)JOINT (S)JUNTA	
[31]	96103111	6	.	B	B	B	.	.	O	(E)ADAPTER-EGR VALVE (D)ADAPTER		1			(F)ADAPTATEUR (S)ADAPTADOR	
[32]	09103-08020	6	.	B	B	B	.	.	O	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE		1			(F)BOULON (S)PERNO	
[33]										(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE					(F)BOULON (S)PERNO	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1311 CYLINDER HEAD(DOHC)




KEY NO.	PART NAME														
I-TC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	09103-08021	6	.	B	B	B	.	.	O			1				
	[34]	(E)GASKET-EGR VALVE (D)DICHTUNG										(F)JOINT (S)JUNTA				
	96103075	6	.	B	B	B	.	.	O			1				
	[35]	(E)VALVE A-EGR (D)VENTIL										(F)SOUPAPE (S)VALVULA				
	17092164	6	.	B	B	B	.	.	O			1				
	[36]	(E)BOLT-HEXAGON (D)SCHRAUBE										(F)BOULON (S)PERNO				
	11048333	6	.	B	B	B	.	.	O			2				
	[37]	(E)PIPE A-VACUUM (D)ROHR,VAKUUM										(F)TUYAU-DEPRESSION (S)TUBERIA-VACIO				
	96248445	6	.	B	B	B	.	.	O	-KL9		1				
	96239364	6	.	B	B	B	.	.	A	&KL9		1				
	[38]	(E)PLATE-EGR CLOSING (D)PLATTE										(F)PLAQUE (S)PLACA				
	96181530														NOT APPLIED	
	[39]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE										(F)BOULON (S)PERNO				
	09103-08019														NOT APPLIED	
	[40]	(E)VALVE-SOLENOID (D)VENTIL										(F)SOUPAPE (S)VALVULA				
	96350594	6	.	B	B	B	.	.	O	-KL9		1				
	[41]	(E)PIPE A-VACUUM (D)ROHR,VAKUUM										(F)TUYAU-DEPRESSION (S)TUBERIA-VACIO				
	96242230	6	.	B	B	B	.	.	O	-KL9		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]									(E)CAP A-BAYONET JOINT *(D)DECKEL,BAYONETTEN-GLIED*					*(F)CHAPEAU-JOINT BAYONETTE* *(S)TAPA-UNION DE BAYONETA*	
	96351602	Y	.	B	B	B	S	S	S			1				
	[02]									(E)SEAL-BAYONET CAP *(D)DICHTUNG,BAYONNETTE KAPPE*					*(F)JOINT-CHAPEAU BAYONETTE* *(S)SELLO-TAPA DE BAYONETA*	
	N/S(1)											1				
	[03]									(E)COVER A-CAMSHAFT SUPPORT *(D)DECKEL,NOCKENWELLE-TRÄGER*					*(F)CARTER* *(S)CUBIERTA*	
	96181319	Y	.	B	B	B	S	S	S			1				INCL #1,2,5
	[04]									(E)BOLT-HEXAGON *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*	
	09117-06007	Y	.	B	B	B	S	S	S			8		971001		W/WASHER TYPE
O	09103-06008	Y	.	B	B	B	S	S	S			8	971001			FLANGE TYPE
	[05]									(E)GASKET-CAMSHAFT SUPT CVR *(D)DICHTUNG*					*(F)JOINT-CARTER SUPPORT* *(S)JUNTA*	
	96181318	Y	.	B	B	B	S	S	S			1				
	[06]									(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*	
	09103-10024	Y	.	B	B	B	S	S	S			10				
	[07]									(E)WASHER *(D)DICHTUNGSRING*					*(F)RONDELLE* *(S)ARANDELA*	
	96180642	Y	.	B	B	B	S	S	S			10				
	[08]									(E)TUBE *(D)ROHRLEITUNG*					*(F)TUYAU OU TUBE* *(S)TUBO*	
	90220615	Y	.	B	B	B	S	S	S			1				
	[09]									(E)SUPPORT A-CAMSHAFT *(D)TRÄGER,NOCKENWELLE*					*(F)SUPPORT-ARBRE A CAMES* *(S)SOPORTE-ARBOL DE LEVA*	
	A96182962	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME													
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	[10]	(E)CAMSHAFT A (D)NOCKENWELLE								(F)ARBRE A CAMES (S)CIGUEÑAL					
	A96182964	Y	.	B	B	B	S	S	S		1				
	[11]	(E)RING-SHAFT SEAL (D)RING,STAB DICHTUNG								(F)ANNEAU-JOINT D'ARBRE (S)ANILLO-BROCHE DE EJE					
	90122609	Y	.	B	B	B	S	S	S		1		971001	35X48X 7	
Y	90280463	Y	.	B	B	B	S	S	S		1	971001		35X48X 7	
	[12]	(E)PLATE-CAMSHAFT PRESSURE (D)PLATTE,KURBELWELLE DRUCK								(F)PLAQUE (S)PLACA					
	90233647	Y	.	B	B	B	S	S	S		1				
	[13]	(E)BOLT-HEXAGON SOCKET TYPE (D)SCHRAUBE								(F)BOULON (S)PERNO					
	07130-06169	Y	.	B	B	B	S	S	S		2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	96351472	6	.	B	B	B	.	.	O	(E)CAP A-BAYONET JOINT (D)DECKEL,BAYONETTEN-GLIED		1			(F)CHAPEAU-JOINT BAYONETTE (S)TAPA-UNION DE BAYONETA	
[02]	96181851	6	.	B	B	B	.	.	O	(E)SEAL-BAYONET CAP (D)DICHTUNG,BAYONNETTE KAPPE		1			(F)JOINT-CHAPEAU BAYONETTE (S)SELLO-TAPA DE BAYONETA	
[03]	96351473	6	.	B	B	B	.	.	O	(E)COVER A-CAMSHAFT,UPPER (D)DECKEL		1			(F)CARTER (S)CUBIERTA	
[04]	07130-06125	6	.	B	B	B	.	.	O	(E)BOLT-HEXAGON SOCKET TYPE (D)SCHRAUBE		4			(F)BOULON (S)PERNO	
[05]	96144569	6	.	B	B	B	.	.	O	(E)WASHER-SEALING (D)RING,DICHTUNG		11	970625		(F)RONDELLE-ETANCHEITE (S)ARANDELA-SELLANTE	
O	96352732	6	.	B	B	B	.	.	O			11	970625			
[06]	09145-06004	6	.	B	B	B	.	.	O	(E)NUT-FLANGE CAP (D)MUTTER,GEFLANSCHTE KAPPE		11			(F)ECROU-CHAPEAU A FLASQUES (S)TUERCA-TAPO CON PESTAÑA	
[07]	96351548	6	.	B	B	B	.	.	O	(E)COVER A-CAMSHAFT (D)DECKEL,NOCKENWELLE		1			(F)CARTER-ARBRE A CAMES (S)CUBIERTA-CIGUEÑAL	
[08]	96351213	6	.	B	B	B	.	.	O	(E)GASKET-CAMSHAFT COVER (D)DICHTUNG		1			(F)JOINT-CARTER (S)JUNTA	
[09]	96144621	6	.	B	B	B	.	.	O	(E)SEAL-'D' (D)DICHTUNG		2			(F)JOINT D'ETANCHEITE (S)SELLO	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1321 CAM SUPPORT&SHAFT(DOHC)



KEY NO.		PART NAME													
		MODEL										EFFECTIVE DATE			
ITC	PART NO	ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	FROM	TO	REMARKS	P/CODE
	[10]	(E)CAMSHAFT A (D)NOCKENWELLE									(F)ARBRE A CAMES (S)CIGUEÑAL					
	A96182606	6	.	B	B	B	.	.	O			2				
	[11]	(E)SEAL-CAMSHAFT,FRONT (D)DICHTUNG,NOCKENWELLE									(F)JOINT-ARBRE A CAMES,AVANT (S)SELLO-ARBOL DE LEVA					
	5094005604	6	.	B	B	B	.	.	O			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1330 TIMING COVER(SOHC)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	96350799	Y	.	B	B	B	S	S	S	(E)PUMP A-WATER (D)PUMPE,WASSER		1			(F)POMPE-EAU (S)BOMBA-AGUA	
[02]	90076127	Y	.	B	B	B	S	S	S	(E)RING-SEAL (D)RING,DICHTUNG		1			(F)ANNEAU (S)ANILLO-SELLO	
[03]	09106-06001	Y	.	B	B	B	S	S	S	(E)BOLT (D)SCHRAUBE		3			(F)BOULON (S)PERNO	
[04]	96182950	Y	.	B	B	B	S	S	S	(E)HOOD-TIMING BELT,REAR (D)HAUBE,ZUNDFOLGEGURT		1			(F)CAPOT (S)TAPA-CORREA DISTRIBUCION	
[05]	09116-06016	Y	.	B	B	B	S	S	S	(E)BOLT (D)SCHRAUBE		4			(F)BOULON (S)PERNO	
[06]	90231882	Y	.	B	B	B	S	S	S	(E)GEAR-CAMSHAFT (D)GETRIEBE,NOCKENWELLE		1			(F)ENGRENAGE-ARBRE A CAMES (S)ENGRANAJE-ARBOL DE LEVAS	
[07]	96180642	Y	.	B	B	B	S	S	S	(E)WASHER (D)DICHTUNGSRING		1			(F)RONDELLE (S)ARANDELA	
[08]	09100-10007	Y	.	B	B	B	S	S	S	(E)BOLT-HEXAGON (D)SCHRAUBE		1			(F)BOULON (S)PERNO	
[09]	90499401	Y	.	B	B	B	S	S	S	(E)TENSIONER A-TIMING BELT (D)SPANNUNG		1			(F)TENDEUR (S)TENSOR	
[10]										(E)BOLT-HEXAGON (D)SCHRAUBE		1			(F)BOULON (S)PERNO	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	09100-08007	Y	.	B	B	B	S	S	S			1				
	[11]	(E)GEAR A-CRANKSHAFT *(D)GETRIEBE,KURBELWELLE*										*(F)ENGRENAGE-VILEBREQUIN* *(S)ENGRANAJE-CIGÜEÑAL*				
	96144520	Y	.	B	B	B	S	S	S			1				
	[12]	(E)PLATE-PRESSURE *(D)PLATTE,DRUCK*										*(F)PLAQUE-PRESSION* *(S)PLACA-PRESION*				
	90409703	Y	.	B	B	B	S	S	S			1				
	[13]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09103-12032	Y	.	B	B	B	S	S	S			1				
	[14]	(E)BELT-TIMING *(D)GURT,ZÜNDFOLGESTEUERUNG*										*(F)COURROIE* *(S)CORREA-DISTRIBUCION*				
	96183353														NOT APPLIED	
	96352407	Y	.	B	B	B	S	S	S			1				
	[15]	(E)HOOD-FRONT,UPPER *(D)HAUBE,VORNE,OBEN*										*(F)CAPOT-AVANT,HAUT* *(S)TAPA-FRENTE SUPERIOR*				
	96182952	Y	.	B	B	B	S	S	S			1				
	[16]	(E)HOOD-FRONT,LOWER *(D)HAUBE,VORNE,UNTEN*										*(F)CAPOT-AVANT, BAS* *(S)TAPA-FRENTE,BAJO*				
	96182951	Y	.	B	B	B	S	S	S			1				
	[17]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	01517-06123	Y	.	B	B	B	S	S	S			7				
	[19]	(E)PULLEY-CRANKSHAFT *(D)ROLLE,KURBELWELLE*										*(F)POULIE-VILEBREQUIN* *(S)POLEA-CIGUEÑAL*				
	96351111	Y	.	B	B	B	S	S	S			1				
	[22]	(E)BRACKET A-CPS *(D)TRÄGER*										*(F)SUPPORT* *(S)SOPORTE*				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96351257	Y	.	B	B	B	S	S	S			1				
	[23]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE										(F)BOULON (S)PERNO				
	01517-06353	Y	.	B	B	B	S	S	S			1				
	[24]	(E)SENSOR-CRANKSHAFT POSITION (D)SENSOR										(F)DETECTEUR (S)SENSOR				
	96183235	Y	.	B	B	B	S	S	S			1				
	[25]	(E)BOLT-HEXAGON SOCKET TYPE (D)SCHRAUBE										(F)BOULON (S)PERNO				
	07130-06165	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]	96351284	6	.	B	B	B	.	.	O	(E)PUMP A-WATER *(D)PUMPE,WASSER*		1			*(F)POMPE-EAU* *(S)BOMBA-AGUA*	
[02]	90076127	6	.	B	B	B	.	.	O	(E)RING-SEAL *(D)RING,DICHTUNG*		1			*(F)ANNEAU* *(S)ANILLO-SELLO*	
[03]	09106-06001	6	.	B	B	B	.	.	O	(E)BOLT *(D)SCHRAUBE*		3			*(F)BOULON* *(S)PERNO*	
[04]	96184800	6	.	B	B	B	.	.	O	(E)PLATE A-TIMING BELT BACK *(D)HINTERE TAFEL*		1			*(F)CONTRE-PLAQUE* *(S)PLACA TRASERA*	
[06]	96184861	6	.	B	B	B	.	.	O	(E)BRACKET-STEPPED MOUNTING *(D)TRÄGER,STUFEN-MONTAGE*		1			*(F)SUPPORT-MONTAGE ETAGE* *(S)SOPORTE*	
[07]	09100-08019	6	.	B	B	B	.	.	O	(E)BOLT-HEXAGON *(D)SCHRAUBE*		1			*(F)BOULON* *(S)PERNO*	
[08]	09160-08011	6	.	B	B	B	.	.	O	(E)WASHER *(D)DICHTUNGSRING*		1			*(F)RONDELLE* *(S)ARANDELA*	
[09]	96182888	6	.	B	B	B	.	.	O	(E)GEAR-CAMSHAFT *(D)GETRIEBE,NOCKENWELLE*		1			*(F)ENGRENAGE-ARBRE A CAMES* *(S)ENGRANAJE-ARBOL DE LEVAS*	INTAKE
	96184322	6	.	B	B	B	.	.	O			1				EXHAUST
[10]	09100-10018	6	.	B	B	B	.	.	O	(E)BOLT-CAMSHAFT GEAR *(D)SCHRAUBE*		2			*(F)BOULON* *(S)PERNO*	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1331 TIMING COVER(DOHC)

3K07



KEY NO.	PART NAME													
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[11]									(E)WASHER-CAMSHAFT GEAR (D)DICHTUNGSRING					(F)RONDELLE (S)ARANDELA	
	5094008002	6	.	B	B	B	.	.	O			2				
	[12]									(E)TENSIONER A-TIMING BELT (D)SPANNUNG					(F)TENDEUR (S)TENSOR	
	96350550	6	.	B	B	B	.	.	O			1				
	[13]									(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE					(F)BOULON (S)PERNO	
	09117-08010	6	.	B	B	B	.	.	O			3				
	[14]									(E)PULLEY-IDLER (D)ROLLE,LEERLAUF					(F)POULIE-LIBRE (S)POLEA-OCIOSA	
	96350526	6	.	B	B	B	.	.	O			1				
	[17]									(E)GEAR A-CRANKSHAFT (D)GETRIEBE,KURBELWELLE					(F)ENGRENAGE-VILEBREQUIN (S)ENGRANAJE-CIGÜEÑAL	
	96143232	6	.	B	B	B	.	.	O			1				
	[20]									(E)BELT-TIMING (D)GURT,ZÜNDFOLGESTEUERUNG					(F)COURROIE (S)CORREA-DISTRIBUCION	
	96183352	6	.	B	B	B	.	.	O			1				
	[21]									(E)COVER A-TIMING BELT,UPPER (D)DECKEL,ZÜNDFOLGE-GURT					(F)CARTER (S)CUBIERTA-CORREA DISTRIBUC	
	96351626	6	.	B	B	B	.	.	O			1				
	[22]									(E)COVER A-TIMING BELT,LOWER (D)DECKEL,ZÜNDFOLGE-GURT					(F)CARTER (S)CUBIERTA-CORREA DISTRIBUC	
	96351627	6	.	B	B	B	.	.	O			1				
	[23]									(E)SEAL-TIMING COVER,UPPER (D)DICHTUNG,VORDER-DECKEL					(F)JOINT-CARTER AVANT (S)SELLO-CUBIERTA DEL FRENTE	
	96351628	6	.	B	B	B	.	.	O			1				
	[24]									(E)SEAL-TIMING COVER,LOWER (D)DICHTUNG,VORDER-DECKEL					(F)JOINT-CARTER AVANT (S)SELLO-CUBIERTA DEL FRENTE	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96351629	6	.	B	B	B	.	.	O			1				
	[25]	(E)SEAL-TIMING COVER,LOWER (D)DICHTUNG,VORDER-DECKEL														
	96351630	6	.	B	B	B	.	.	O			1				
	[26]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														
	01517-06453	6	.	B	B	B	.	.	O			3				
	[27]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														
	01517-06103	6	.	B	B	B	.	.	O			6				
	[28]	(E)BRACKET-HOSE (D)TRÄGER,SCHLAUCH														
	96180354	6	.	B	B	B	.	.	O			1				
	[29]	(E)PULLEY-CRANKSHAFT (D)ROLLE,KURBELWELLE														
	96351111	6	.	B	B	B	.	.	O			1				
	[30]	(E)PLATE-PRESSURE (D)PLATTE,DRUCK														
	90409703	6	.	B	B	B	.	.	O			1				
	[31]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														
	09103-12031	6	.	B	B	B	.	.	O			1		970804		
O	09103-12045	6	.	B	B	B	.	.	O			1	970804			
	[32]	(E)BRACKET A-CPS (D)TRÄGER														
	96351255	6	.	B	B	B	.	.	O			1				
	[33]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1331 TIMING COVER(DOHC)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	01517-06353	6	.	B	B	B	.	.	O			1				
	[34]	(E)SENSOR-CR/SHAFT POSITION (D)SENSOR										(F)DETECTEUR (S)SENSOR				
	96183235	6	.	B	B	B	.	.	O			1				
	[35]	(E)BOLT-HEXAGON SOCKET TYPE (D)SCHRAUBE										(F)BOULON (S)PERNO				
	07130-06165	6	.	B	B	B	.	.	O			1				
	[36]	(E)SEAL (D)DICHTUNG										(F)JOINT (S)SELLO				
	96350088	6	.	B	B	B	.	.	O			1				
	[38]	(E)WASHER (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	9091607060	6	.	B	B	B	.	.	O			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)RADIATOR A *(D)KÜHLER*									*(F)RADIATEUR* *(S)RADIADOR*					
	96351263	.	M	B	B	B	S	S	S	&C46		1				RF
	96182261	.	M	B	B	B	O	O	O	&C59/C60		1				RB
	96182281														NOT APPLIED	
	96351262	.	A	B	B	B	O	O	O	&C46		1				RE
	96182260	.	A	B	B	B	O	O	O	&C59/C60		1				RA
	96182280														NOT APPLIED	
[02]		(E)CORE *(D)GEHÄUSE KÜHLER*									*(F)NOYAU-RADIATEUR* *(S)NUCLEO-RADIADOR*					
	620730	.	.	B	B	B	S	S	S	&C46		1			500X382.4X16	
	620741	.	.	B	B	B	O	O	O	&C59/C60		1			635X382.4X16	
	620742														NOT APPLIED	
[03]		(E)BRACKET-SHROUD MOUNT,UPPER *(D)TRÄGER,HÜLLE-MONTAGE,OBEN*									*(F)SUPPORT* *(S)SOPORTE-MONTAJE DE TAPADO*					
	620580	.	.	B	B	B	S	S	S			1				
[04]		(E)CLIP-SHROUD MOUNT *(D)KLEMME*									*(F)ATTACHE* *(S)GRAPA*					
	620579	.	.	B	B	B	S	S	S			1				
[05]		(E)BRACKET-SHROUD MOUNT,LOWER *(D)TRÄGER,HÜLLE-MONTAGE*									*(F)SUPPORT* *(S)SOPORTE-MONTAJE DE TAPADO*					
	620581	.	.	B	B	B	S	S	S			1				
[06]		(E)SEAL-GASKET *(D)DICHTUNG*									*(F)JOINT* *(S)SELLO*					
	620586	.	.	B	B	B	S	S	S			2				
[07]		(E)TANK A-OUTLET *(D)GEHÄUSE AUSFUHR TANK*									*(F)ENVELOPPE* *(S)CAPARAZON-TANQUE*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME																
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
620834		.	M	B	B	B	S	S	S			1				
[08]	(E)TANK A-OUTLET (D)GEHÄUSE AUSFUHR TANK											(F)ENVELOPPE (S)CAPARAZON-TANQUE				
620832		.	A	B	B	B	O	O	O			1				
[11]	(E)COCK -DRAIN (D)ABFLUßHAHN											(F)ROBINET-VIDANGE (S)GRIFO-DRENAJE				
620728		.	.	B	B	B	S	S	S			2				
[12]	(E)TANK A-INLET (D)GEHÄUSE EINFUHR TANK											(F)ENVELOPPE (S)CAPARAZON-TANQUE				
620827		.	.	B	B	B	S	S	S			4				
[13]	(E)NUT-FAN MOUNTING (D)MUTTER											(F)ECROU (S)TUERCA				
620006		.	.	B	B	B	S	S	S			3				
[14]	(E)HOLDER-PIPE OUTLET (D)BEHÄLTER											(F)MONTURE (S)RETNEDOR				
620584		.	A	B	B	B	O	O	O			1				
[15]	(E)PIPE A-OUTLET (D)ROHR											(F)TUYAU (S)TUBERIA				
620727		.	A	B	B	B	O	O	O			1				
[16]	(E)BOLT (D)SCHRAUBE											(F)BOULON (S)PERNO				
620585		.	A	B	B	B	O	O	O			1				
[17]	(E)NUT-OUTLET (D)MUTTER											(F)ECROU (S)TUERCA				
620589		.	A	B	B	B	O	O	O			2				
[18]	(E)WASHER (D)DICHTUNGSRING											(F)RONDELLE (S)ARANDELA				
620588		.	A	B	B	B	O	O	O			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[19]	(E)WASHER (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	620590	.	A	B	B	B	O	O	O			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
																	(E)BRACKET A-RADIATOR (D)TRÄGER,KÜHLER (F)SUPPORT-RADIATEUR (S)SOPORTE-RADIADOR
[01]	96351477	.	.	B	B	B	S	S	S			2					
[02]																	(E)BUMPER-RADIATOR,UPPER (D)STOßSTANGE (F)PARE-CHOC (S)PARACHOQUES
	96351101	.	.	B	B	B	S	S	S			2					
[03]																	(E)BOLT-HEX FLANGE PILOT (D)SCHRAUBE (F)BOULON (S)PERNO
	02647-06165	.	.	B	B	B	S	S	S			2					
[04]																	(E)BUMPER-RADIATOR,LOWER (D)STOßSTANGE (F)PARE-CHOC (S)PARACHOQUES
	96184140	.	.	B	B	B	S	S	S			2					
[05]																	(E)BLOWER A-RADIATOR (D)BLÄSER,KÜHLER (F)VENTILATEUR-RADIATEUR (S)VENTILADOR-RADIADOR
	96183756	.	.	B	B	B	S	S	S	-XHA		1					
	96183756	.	.	B	B	B	S	S	S	&C46&XHA		1					
	96352580	.	.	B	B	B	O	O	O	&C59/C60&XHA		1					
[06]																	(E)SHROUD (D)MANTEL,KÜHLER (F)BOUCLIER-RADIATEUR (S)CUBIERTA-RADIADOR
	EU03050																NOT APPLIED
	EU03005	.	.	B	B	B	S	S	S			1					
[07]																	(E)BLOWER (D)BLÄSER,KÜHLER (F)VENTILATEUR-RADIATEUR (S)VENTILADOR-RADIADOR
	EU50002																NOT APPLIED
	EU50001	.	.	B	B	B	S	S	S	-XHA		1					
	EU50001	.	.	B	B	B	S	S	S	&C46&XHA		1					
	GI50001	.	.	B	B	B	O	O	O	&C59/C60&XHA		1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
		(E)SCREW									(F)VIS					
[08]		(D)SCHRAUBE									(S)TORNILLO					
	EU01036														NOT APPLIED	
	EU10036	.	.	B	B	B	S	S	S			3				
		(E)BLOWER A-AUXILIARY									(F)VENTILATEUR-AUXILIAIRE					
[09]		(D)BLÄSER,ZUSATZ									(S)VENTILADOR-AUXILIAR					
	96182264	.	.	B	B	B	O	O	O	&C60		1				
		(E)SHROUD									(F)BOUCLIER					
[10]		(D)MANTEL									(S)CUBIERTA					
	DA03050	.	.	B	B	B	O	O	O	&C60		1				
		(E)BLOWER-AUXILIARY									(F)VENTILATEUR-AUXILIAIRE					
[11]		(D)BLÄSER,ZUSATZ									(S)VENTILADOR-AUXILIAR					
	DA50002	.	.	B	B	B	O	O	O	&C60		1				
		(E)BOLT									(F)BOULON					
[12]		(D)SCHRAUBE									(S)PERNO					
	MC01017	.	.	B	B	B	O	O	O	&C60		3				
		(E)BOLT									(F)BOULON					
[13]		(D)SCHRAUBE									(S)PERNO					
	09116-06025	.	.	B	B	B	S	S	S			3				
		(E)BOLT									(F)BOULON					
[14]		(D)SCHRAUBE									(S)PERNO					
	09116-06025	.	.	B	B	B	O	O	O	&C60		3				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1650 RADIATOR HOSE&PIPE(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)HOSE-RADIATOR,UPPER (D)SCHLAUCH,BOGEN,OBEN													(F)TUYAU-COUDE,HAUT (S)MANGUERA-CODO,SUPERIOR	
	96351259	Y	.	B	B	B	S	S	S	&C46		1				UC
	96182268	Y	.	B	B	B	O	O	O	&C59/C60		1				UA
	[02]	(E)HOSE-RADIATOR,LOWER (D)SCHLAUCH,BOGEN,UNTEN													(F)TUYAU-COUDE,BAS (S)MANGUERA-CODO,INFERIOR	
	96350692	Y	.	B	B	B	S	S	S			1				
	[03]	(E)PIPE-RADIATOR & ENGINE (D)ROHR,KÜHLER&MOTOR													(F)TUYAU-RADIATEUR&MOTEUR (S)TUBERIA-RADIADOR Y MOTOR	
	96180035	Y	.	B	B	B	S	S	S			1				
	[04]	(E)BOLT-HEXAGON (D)SCHRAUBE													(F)BOULON (S)PERNO	
	01137-08165	Y	.	B	B	B	S	S	S			2				
	[05]	(E)HOSE-PIPE & WATER PUMP (D)SCHLAUCH,ROHR&WASSERPUMPE													(F)TUYAU-TUYAU&POMPE A EAU (S)MANGUERA	
	96180071	Y	.	B	B	B	S	S	S			1				
	[06]	(E)HOSE-SURGE TANK & PIPE (D)SCHLAUCH,ÜBERFLUßTANK													(F)TUYAU (S)MANGUERA	
	96351748	Y	.	B	B	B	S	S	S			1				
	[07]	(E)HOSE-RADIATOR &SURGE TANK (D)SCHLAUCH													(F)TUYAU (S)MANGUERA	
	96351848	Y	.	B	B	B	S	S	S			1				
	[08]	(E)TANK-SURGE (D)TANK,ÜBERFLUß													(F)RESERVOIR-TROP-PLEIN (S)TANQUE-SOBRE CARGA	
	96182279	Y	.	B	B	B	S	S	S			1				
	[09]	(E)CAP-SURGE TANK (D)DECKEL,ÜBERFLUßTANK													(F)CHAPEAU (S)TAPA-TANQUE DE ARRANQUE	
	96351578	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1650 RADIATOR HOSE&PIPE(SOHC)



KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
[10]	(E)NUT *(D)MUTTER*											(F)ECROU (S)TUERCA				
	09159-06011	Y	.	B	B	B	S	S	S			2				
[11]	(E)HOSE-HEATER FEEDING *(D)SCHLAUCH,HEIZUNG ZUFUHR*											(F)TUYAU (S)MANGUERA-CALENTADOR				
	96304312	Y	.	B	B	B	S	S	S			1				
[12]	(E)HOSE-HEATER RETURN *(D)RÜCK-SCHLAUCH HEIZUNG*											(F)TUYAU-RETOUR CHAUFFAGE (S)MANGUERA-CALENTADOR				
	96304316	Y	M	B	B	B	S	S	S			1				
	96304475	Y	A	B	B	B	O	O	O			1				
[13]	(E)HOSE-THROTTLE BODY FEED'G *(D)SCHLAUCH,DROSSEL KÖRPER*											(F)TUYAU (S)MANGUERA				
	96351770	Y	.	B	B	B	S	S	S			1				
[14]	(E)HOSE-MANIFOLD & DISTRIBUTOR *(D)SCHLAUCH*											(F)TUYAU (S)MANGUERA				
	96351772	Y	.	B	B	B	S	S	S			1				
[15]	(E)HOSE-THROTTLE BODY RETURN *(D)SCHLAUCH,DROSSEL KÖRPER*											(F)TUYAU (S)MANGUERA				
	96351822	Y	.	B	B	B	S	S	S			1				SH
[16]	(E)DISTRIBUTOR-WATER *(D)VERTEILER,WASSER*											(F)DISTRIBUTEUR-EAU (S)DISTRIBUIDOR-AGUA				
	96143583	Y	.	B	B	B	S	S	S			1				
[17]	(E)BOLT-HEXAGON *(D)SCHRAUBE*											(F)BOULON (S)PERNO				
	01510-08503	Y	.	B	B	B	S	S	S			2				
[18]	(E)SUPPORT-INTAKE MANIFOLD *(D)TRÄGER,SAMMELLEITUNG*											(F)SUPPORT (S)SOPORTE				
	96143951	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1650 RADIATOR HOSE&PIPE(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[19]	(E)BOLT (D)SCHRAUBE														(F)BOULON (S)PERNO	
09116-10001		Y	.	B	B	B	S	S	S			1				
[20]	(E)SUPPORT-HEATER HOSE (D)TRÄGER														(F)SUPPORT (S)SOPORTE	
96304320		Y	M	B	B	B	S	S	S			1				
[21]	(E)BOLT-HEXAGON (D)SCHRAUBE														(F)BOULON (S)PERNO	
09100-10004		Y	M	B	B	B	S	S	S			1				
[22]	(E)CLIP (D)KLEMME														(F)ATTACHE (S)GRAPA	
09401-15401		Y	.	B	B	B	S	S	S			6				
[23]	(E)CLIP (D)KLEMME														(F)ATTACHE (S)GRAPA	
09401-22401		Y	.	B	B	B	S	S	S			4				
[24]	(E)CLIP (D)KLEMME														(F)ATTACHE (S)GRAPA	
09401-23402		Y	.	B	B	B	S	S	S			4				
[27]	(E)CLIP (D)KLEMME														(F)ATTACHE (S)GRAPA	
09401-35401		Y	.	B	B	B	S	S	S			1				
[28]	(E)CLIP (D)KLEMME														(F)ATTACHE (S)GRAPA	
09401-38401		Y	.	B	B	B	S	S	S			5				
[29]	(E)CLIP (D)KLEMME														(F)ATTACHE (S)GRAPA	
09408-00074		Y	.	B	B	B	S	S	S			1				
[30]	(E)STRAP-MOUNTING (D)BAND,MONTAGE														(F)BRETELLE-MONTAGE (S)BRIDA-MONTAJE	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1650 RADIATOR HOSE&PIPE(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09286974	Y	.	B	B	B	S	S	S			2				
	[31]	(E)BRACKET-ENG. CONTROL (D)TRÄGER										(F)SUPPORT (S)SOPORTE				
	96234615	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1651 RADIATOR HOSE&PIPE(DOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)HOSE-RADIATOR,UPPER (D)SCHLAUCH,BOGEN,OBEN													(F)TUYAU-COUDE,HAUT (S)MANGUERA-CODO,SUPERIOR	
	96184393	6	.	B	B	B	.	.	O	&C46		1				UD
	96182269	6	.	B	B	B	.	.	O	&C59/C60		1				UB
[02]		(E)HOSE-RADIATOR,LOWER (D)SCHLAUCH,BOGEN,UNTEN													(F)TUYAU-COUDE,BAS (S)MANGUERA-CODO,INFERIOR	
	96350692	6	.	B	B	B	.	.	O			1				
[03]		(E)PIPE-RADIATOR & ENGINE (D)ROHR,KÜHLER&MOTOR													(F)TUYAU-RADIATEUR&MOTEUR (S)TUBERIA-RADIADOR Y MOTOR	
	96180035	6	.	B	B	B	.	.	O			1				
[04]		(E)BOLT-HEXAGON (D)SCHRAUBE													(F)BOULON (S)PERNO	
	01137-08165	6	.	B	B	B	.	.	O			2				
[05]		(E)HOSE-PIPE & WATER PUMP (D)SCHLAUCH,ROHR&WASSERPUMPE													(F)TUYAU-TUYAU&POMPE A EAU (S)MANGUERA	
	96180071	6	.	B	B	B	.	.	O			1				
[06]		(E)HOSE-SURGE TANK & PIPE (D)SCHLAUCH,ÜBERFLUßTANK													(F)TUYAU (S)MANGUERA	
	96351748	6	.	B	B	B	.	.	O			1				
[07]		(E)HOSE-RADIATOR & SURGE TANK (D)SCHLAUCH													(F)TUYAU (S)MANGUERA	
	96351848	6	.	B	B	B	.	.	O			1				
[08]		(E)TANK-SURGE (D)TANK,ÜBERFLUß													(F)RESERVOIR-TROP-PLEIN (S)TANQUE-SOBRE CARGA	
	96182279	6	.	B	B	B	.	.	O			1				
[09]		(E)CAP-SURGE TANK (D)DECKEL,ÜBERFLUßTANK													(F)CHAPEAU (S)TAPA-TANQUE DE ARRANQUE	
	96351578	6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1651 RADIATOR HOSE&PIPE(DOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[10]	(E)NUT *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	09159-06011	6	.	B	B	B	.	.	O			2				
	[11]	(E)HOSE-HEATER FEEDING *(D)SCHLAUCH,HEIZUNG ZUFUHR*										*(F)TUYAU* *(S)MANGUERA-CALENTADOR*				
	96214619	6	.	B	B	B	.	.	O			1				
	[12]	(E)HOSE-HEATER RETURN *(D)RÜCK-SCHLAUCH HEIZUNG*										*(F)TUYAU-RETOUR CHAUFFAGE* *(S)MANGUERA-CALENTADOR*				
	96304316	6	M	B	B	B	.	.	O			1				
	96304475	6	A	B	B	B	.	.	O			1				
	[13]	(E)HOSE-THROTTLE BODY FEED'G *(D)SCHLAUCH,DROSSEL KÖRPER*										*(F)TUYAU* *(S)MANGUERA*				
	96184864	6	.	B	B	B	.	.	O			1				
	[15]	(E)HOSE-THROTTLE BODY RETURN *(D)SCHLAUCH,DROSSEL KÖRPER*										*(F)TUYAU* *(S)MANGUERA*				
	96351823	6	.	B	B	B	.	.	O			1				DH
	[20]	(E)SUPPORT-HEATER HOSE *(D)TRÄGER*										*(F)SUPPORT* *(S)SOPORTE*				
	96304320	6	M	B	B	B	.	.	O			1				
	[21]	(E)BOLT-HEXAGON *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09100-10004	6	M	B	B	B	.	.	O			1				
	[22]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	09401-15401	6	.	B	B	B	.	.	O			6				
	[23]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	09401-22401	6	.	B	B	B	.	.	O			4				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1651 RADIATOR HOSE&PIPE(DOHC)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[24]		(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
09401-23402		6	.	B	B	B	.	.	O			2				
[27]		(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
09401-35401		6	.	B	B	B	.	.	O			1				
[28]		(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
09401-38401		6	.	B	B	B	.	.	O			5				
[29]		(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
09408-00074		6	.	B	B	B	.	.	O			1				
[30]		(E)STRAP-MOUNTING (D)BAND,MONTAGE										(F)BRETELLE-MONTAGE (S)BRIDA-MONTAJE				
09286974		6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)HOUSING-THERMOSTAT *(D)GEHÄUSE THERMOSTAT*									*(F)LOGEMENT-THERMOSTAT* *(S)CARCASA-TERMOSTATO*					
	96180324	Y	.	B	B	B	S	S	S			1				
	[02]	(E)RING-THERMO.HOUSING SEAL *(D)RING,DICHTUNG*									*(F)ANNEAU* *(S)ANILLO-SELLO*					
	90096383	Y	.	B	B	B	S	S	S			1				
	[03]	(E)THERMOSTAT A *(D)THERMOSTAT*									*(F)THERMOSTAT* *(S)TERMOSTATO*					
	96143939	Y	.	B	B	B	S	S	S			1				
	[04]	(E)BOLT *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
	09117-08009	Y	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	96143112	6	.	B	B	B	.	.	O	(E)RING-THERMO COVER SEAL (D)RING,DICHTUNG		1			(F)ANNEAU (S)ANILLO-SELLO	
[02]	96180615	6	.	B	B	B	.	.	O	(E)ADAPTER-THERMOSTAT (D)ADAPTER,THERMOSTAT		1			(F)ADAPTATEUR-THERMOSTAT (S)ADAPTADOR-TERMOSTATO	
[03]	96143939	6	.	B	B	B	.	.	O	(E)THERMOSTAT A (D)THERMOSTAT		1			(F)THERMOSTAT (S)TERMOSTATO	
[04]	90096383	6	.	B	B	B	.	.	O	(E)RING-THERMO HOUSING SEAL (D)RING,DICHTUNG		1			(F)ANNEAU (S)ANILLO-SELLO	
[05]	96130992	6	.	B	B	B	.	.	O	(E)COVER-THERMOSTAT (D)DECKEL,THERMOSTAT		1			(F)COUVERCLE-THERMOSTAT (S)CUBIERTA-TERMOSTATO	
[06]	09117-08009	6	.	B	B	B	.	.	O	(E)BOLT (D)SCHRAUBE		2			(F)BOULON (S)PERNO	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)HOSE-OIL COOLER,OUTLET (D)SCHLAUCH								(F)TUYAU (S)MANGUERA						
	96246287	.	A	B	B	B	O	O	O			1			260mm	
[02]		(E)HOSE-OIL COOLER,INLET (D)SCHLAUCH								(F)TUYAU (S)MANGUERA						
	96246293	.	A	B	B	B	O	O	O			1			200mm	
[03]		(E)CLAMP (D)KLAMMER								(F)PINCE (S)ABRAZADERA						
	09402-16503														NOT APPLIED	
	09402-16502	.	A	B	B	B	O	O	O			4				
[04]		(E)BLOCK-OIL COOLER,REAR (D)BLOCK								(F)BLOC (S)BLOQUE						
	96245950	.	A	B	B	B	O	O	O			1				
[05]		(E)BOLT-HEXAGON (D)SCHRAUBE								(F)BOULON (S)PERNO						
	01117-06203	.	A	B	B	B	O	O	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK

1710 IGNITION CABLE(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)COIL-DIS *(D)WICKLUNG,ZÜNDUNG* *(F)BOBINE-ALLUMAGE* *(S)BOBINA-ARRANQUE*															
96350585		Y	.	B	B	B	S	S	S			1				
[02]	(E)NUT-HEXAGON FLANGE *(D)MUTTER* *(F)ECROU* *(S)TUERCA*															
08316-25063		Y	.	B	B	B	S	S	S			3				
[03]	(E)BRACKET A-DIS *(D)TRÄGER* *(F)SUPPORT* *(S)SOPORTE*															
96351644		Y	.	B	B	B	S	S	S			1				
[04]	(E)O RING *(D)O RING* *(F)JOINT TORIQUE* *(S)ANILLO EN O*															
96351738		Y	.	B	B	B	S	S	S			1				
[05]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*															
01517-06203		Y	.	B	B	B	S	S	S			3	970804			
O 01517-06163		Y	.	B	B	B	S	S	S			3	970804			
[06]	(E)PLUG-SPARK *(D)ZÜNDKERZE* *(F)BOUGIE* *(S)TAPON-BUJIA*															
96110493		Y	.	B	B	B	S	S	S			4				
[07]	(E)CABLE SET- HIGH TENSION *(D)VERDRAHTUNG,HOCHSPANNUNG* *(F)TROUSSE CABLES* *(S)JUEGO DE ALAMBRE*															
96305387		Y	.	B	B	B	S	S	S			1				SW
[08]	(E)CABLE- HIGH TENSION,#1 *(D)VERDRAHTUNG* *(F)CABLES* *(S)ALAMBRE*															
96233409		Y	.	B	B	B	S	S	S			1			NO. 1	
[09]	(E)CABLE- HIGH TENSION,#2 *(D)VERDRAHTUNG* *(F)CABLES* *(S)ALAMBRE*															
96233410		Y	.	B	B	B	S	S	S			1			NO. 2	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[10]																	(E)CABLE- HIGH TENSION,#3 (D)VERDRAHTUNG
	96233411	Y	.	B	B	B	S	S	S			1			NO. 3		
[11]																	(E)CABLE- HIGH TENSION,#4 (D)VERDRAHTUNG
	96233412	Y	.	B	B	B	S	S	S			1			NO. 4		
[12]																	(E)CLIP-CABLE (D)KLEMME
	90320345	Y	.	B	B	B	S	S	S			1					
[13]																	(E)BRACKET-CABLE (D)TRÄGER
	90320342	Y	.	B	B	B	S	S	S			2					
[14]																	(E)CLIP-CABLE (D)KLEMME,ANLASSER-KBEL
	09408-00076	Y	.	B	B	B	S	S	S			1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1711 IGNITION CABLE(DOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)COIL-DIS (D)WICKLUNG,ZÜNDUNG													(F)BOBINE-ALLUMAGE (S)BOBINA-ARRANQUE	
96350585		6	.	B	B	B	.	.	O			1				
[02]		(E)NUT-HEXAGON FLANGE (D)MUTTER													(F)ECROU (S)TUERCA	
08316-25063		6	.	B	B	B	.	.	O			3				
[03]		(E)BRACKET A-DIS (D)TRÄGER													(F)SUPPORT (S)SOPORTE	
96351676		6	.	B	B	B	.	.	O			1				
[05]		(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE													(F)BOULON (S)PERNO	
01517-06303		6	.	B	B	B	.	.	O			3				
[06]		(E)PLUG-SPARK (D)ZÜNDKERZE													(F)BOUGIE (S)TAPON-BUJIA	
96130723		6	.	B	B	B	.	.	O			4				
[07]		(E)CABLE SET- HIGH TENSION (D)VERDRAHTUNG,HOCHSPANNUNG													(F)TROUSSE CABLES (S)JUEGO DE ALAMBRE	
96211948		6	.	B	B	B	.	.	O			1				DW
[08]		(E)CABLE- HIGH TENSION,#1 (D)VERDRAHTUNG													(F)CABLES (S)ALAMBRE	
96242624		6	.	B	B	B	.	.	O			1			NO. 1	
[09]		(E)CABLE- HIGH TENSION,#2 (D)VERDRAHTUNG													(F)CABLES (S)ALAMBRE	
96233414		6	.	B	B	B	.	.	O			1			NO. 2	
[10]		(E)CABLE- HIGH TENSION,#3 (D)VERDRAHTUNG													(F)CABLES (S)ALAMBRE	
96233415		6	.	B	B	B	.	.	O			1			NO. 3	
[11]		(E)CABLE- HIGH TENSION,#4 (D)VERDRAHTUNG													(F)CABLES (S)ALAMBRE	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1711 IGNITION CABLE(DOHC)



KEY NO.		PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	96233416	6	.	B	B	B	.	.	O			1			NO. 4	
	[12]	(E)CLIP-STAR (D)KLEMME										(F)ATTACHE (S)GRAPA				
	12065767	6	.	B	B	B	.	.	O			1				
	[13]	(E)BRACKET-CABLE (D)TRÄGER										(F)SUPPORT-CABLE (S)SOPORTE-ALAMERE				
	96132971	6	.	B	B	B	.	.	O			1				
	[14]	(E)BOLT-HEXAGON (D)SCHRAUBE										(F)BOULON (S)PERNO				
	01107-06803	6	.	B	B	B	.	.	O			1				
	[15]	(E)BRACKET-OXYGEN SENSOR (D)TRÄGER										(F)SUPPORT (S)SOPORTE				
	96239380	6	.	B	B	B	.	.	A	&NN6/NN7		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1740 ALTERNATOR UNIT(12V,85A)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)ALTERNATOR A (D)WECHSELSTROMGENERATOR									(F)ALTERNATEUR (S)ALTERNADOR					
	96303556	.	.	B	B	B	S	S	S	-XHA		1			12V,85A	AW
[02]		(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	01911324	.	.	B	B	B	S	S	S	-XHA		1				
[03]		(E)PULLEY (D)ROLLE									(F)POULIE (S)POLEA					
	210811	.	.	B	B	B	S	S	S	-XHA		1				
[04]		(E)COLLAR (D)KRAGEN(GROß)									(F)COLLIER (GRAND) (S)CASQUILLO(GRANDE)					
	210629	.	.	B	B	B	S	S	S	-XHA		1				
[05]		(E)FAN (D)BLÄSER									(F)VENTILATEUR (S)VENTILADOR					
	210020	.	.	B	B	B	S	S	S	-XHA		1				
[06]		(E)COLLAR (D)KRAGEN(KLEIN)									(F)COLLIER (PETIT) (S)CASQUILLO(PEQUEÑA)					
	210629	.	.	B	B	B	S	S	S	-XHA		1				
[07]		(E)FRAME&BEARING (D)RAHMEN&LAGER,ANTRIEB ENDE									(F)CADRE&ROULEMENT (S)ARMADURA Y COJINETE					
	210667	.	.	B	B	B	S	S	S	-XHA		1				
[08]		(E)ROTOR (D)DREHTEIL									(F)ROTOR (S)ROTOR					
	210933	.	.	B	B	B	S	S	S	-XHA		1				
[09]		(E)STATOR (D)STATOR									(F)STATOR (S)ESTATOR					
	210934	.	.	B	B	B	S	S	S	-XHA		1				
[10]		(E)BAFFLE (D)DÄMPFER									(F)DEFLECTEUR (S)DEFLECTOR					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1740 ALTERNATOR UNIT(12V,85A)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	210931	.	.	B	B	B	S	S	S	-XHA		1					
[11]																	(E)BRUSH SET *(F)BALAI* *(D)BÜRSTE* *(S)ESCOBILLA*
	210679	.	.	B	B	B	S	S	S	-XHA		1					
[12]																	(E)SCREW *(F)VIS* *(D)SCHRAUBE* *(S)TORNILLO*
	01989650	.	.	B	B	B	S	S	S	-XHA		1					
[13]																	(E)REGULATOR *(F)REGULATEUR* *(D)REGULATOR* *(S)REGULADOR*
	276010	.	.	B	B	B	S	S	S	-XHA		1					
[14]																	(E)NUT *(F)ECROU* *(D)MUTTER* *(S)TUERCA*
	01989649	.	.	B	B	B	S	S	S	-XHA		1					
[15]																	(E)RECTIFIER *(F)RECTIFICATEUR* *(D)RICHTER* *(S)RECTIFICADOR*
	267100	.	.	B	B	B	S	S	S	-XHA		1		970813			
O	267300	.	.	B	B	B	S	S	S	-XHA		1	970813				
[16]																	(E)SCREW *(F)VIS* *(D)SCHRAUBE* *(S)TORNILLO*
	01981681	.	.	B	B	B	S	S	S	-XHA		3					
[17]																	(E)BEARING-BALL *(F)ROULEMENT-BILLE* *(D)KUGELLAGER* *(S)COJINETE DE BOLAS*
	01989646	.	.	B	B	B	S	S	S	-XHA		2					
[18]																	(E)FRAME-SLIP RING END *(F)CADRE* *(D)RAHMEN,SCHLEIFRAD-ENDE* *(S)ARMADURA*
	210930	.	.	B	B	B	S	S	S	-XHA		1					
[19]																	(E)BUSHING *(F)MANCHON* *(D)LAGERFUTTER* *(S)BUJE DE BOQUILLA*

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1740 ALTERNATOR UNIT(12V,85A)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	10495216	.	.	B	B	B	S	S	S	-XHA		1				
	[20]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	10473999	.	.	B	B	B	S	S	S	-XHA		3				
	[21]	(E)STUD (D)STEG										(F)TOURILLON (S)TRAVESAÑO				
	211075	.	.	B	B	B	S	S	S	-XHA		1				
	[22]	(E)COVER (D)DECKEL										(F)CARTER (S)CUBIERTA				
	210932	.	.	B	B	B	S	S	S	-XHA		1				
	[23]	(E)COVER (D)DECKEL										(F)CARTER (S)CUBIERTA				
	10476121	.	.	B	B	B	S	S	S	-XHA		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1741 ALTERNATOR UNIT(12V,95A)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)ALTERNATOR A (D)WECHSELSTROMGENERATOR													(F)ALTERNATEUR (S)ALTERNADOR	
	96239894	. .	B	B	B	A	A	A	&XHA		1				12V,95A	AH
	[02]	(E)NUT (D)MUTTER													(F)ECROU (S)TUERCA	
	01911324	. .	B	B	B	A	A	A	&XHA		1					
	[03]	(E)PULLEY (D)ROLLE													(F)POULIE (S)POLEA	
	211081	. .	B	B	B	A	A	A	&XHA		1					
	[04]	(E)COLLAR (D)KRAGEN(GROß)													(F)COLLIER (GRAND) (S)CASQUILLO(GRANDE)	
	210937	. .	B	B	B	A	A	A	&XHA		1				LARGE	
	[05]	(E)FAN (D)BLÄSER													(F)VENTILATEUR (S)VENTILADOR	
	211103	. .	B	B	B	A	A	A	&XHA		1					
	[06]	(E)COLLAR (D)KRAGEN(KLEIN)													(F)COLLIER (PETIT) (S)CASQUILLO(PEQUEÑA)	
	210768	. .	B	B	B	A	A	A	&XHA		1				SMALL	
	[07]	(E)FRAME&STATOR A (D)RAHMEN & STATOR													(F)CADRE&STATOR (S)ARMADURA Y ESTATOR	
	211147	. .	B	B	B	A	A	A	&XHA		1					
	[08]	(E)ROTOR (D)DREHTEIL													(F)ROTOR (S)ROTOR	
	210755	. .	B	B	B	A	A	A	&XHA		1					
	[09]	(E)INSULATOR (D)ISOLATOR													(F)ISOLATEUR (S)AISLADOR	
	210921	. .	B	B	B	A	A	A	&XHA		3					
	[10]	(E)BEARING-BALL (D)KUGELLAGER													(F)ROULEMENT-BILLE (S)COJINETE DE BOLAS	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1741 ALTERNATOR UNIT(12V,95A)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	210938	.	.	B	B	B	A	A	A	&XHA		1					(E)FRAME A (F)CADRE (D)RAHMEN (S)ARMADURA
	[11]																
	211083	.	.	B	B	B	A	A	A	&XHA		1					(E)BUSHING (F)MANCHON (D)LAGERFUTTER (S)BUJE DE BOQUILLA
	[12]																
	10495216	.	.	B	B	B	A	A	A	&XHA		1					(E)RECTIFIER (F)RECTIFICATEUR (D)RICHTER (S)RECTIFICADOR
	[13]																
	268500	.	.	B	B	B	A	A	A	&XHA		1					(E)COVER (F)CARTER (D)DECKEL (S)CUBIERTA
	[14]																
	210990	.	.	B	B	B	A	A	A	&XHA		1					(E)SCREW (F)VIS (D)SCHRAUBE (S)TORNILLO
	[15]																
	210788	.	.	B	B	B	A	A	A	&XHA		3					(E)SCREW (F)VIS (D)SCHRAUBE (S)TORNILLO
	[16]																
	01989650	.	.	B	B	B	A	A	A	&XHA		1					(E)REGULATOR (F)REGULATEUR (D)REGULATOR (S)REGULADOR
	[17]																
	271520	.	.	B	B	B	A	A	A	&XHA		1					(E)BRUSH A (F)BALAI (D)BÜRSTE (S)ESCOBILLA
	[18]																
	210748	.	.	B	B	B	A	A	A	&XHA		1					(E)SCREW (F)VIS (D)SCHRAUBE (S)TORNILLO
	[19]																
	01989681	.	.	B	B	B	A	A	A	&XHA		1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1741 ALTERNATOR UNIT(12V,95A)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[20]	10473999	.	.	B	B	B	A	A	A	&XHA		4			(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1750 ALTERNATOR MOUNT(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)BRACKET-ALTERNATOR (D)TRÄGER									(F)SUPPORT-ALTERNATEUR (S)SOPORTE-ALTERNADOR					
	96184726	Y	M	B	B	B	S	S	S			1	970423			
O	96352550	Y	M	B	B	B	S	S	S			1	970423			
	96184817	Y	A	B	B	B	O	O	O			1	970510			
O	96352551	Y	A	B	B	B	O	O	O			1	970510			
	[02]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01513-08453	Y	.	B	B	B	S	S	S			1				
	[03]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09103-10041	Y	.	B	B	B	S	S	S			2				
	[04]	(E)SHACKLE-ALTERNATOR (D)SCHIENE									(F)SUPPORT-ALTERNATEUR (S)REFUERZO-ALTERNADOR					
	96350678	Y	.	B	B	B	S	S	S			1	970510			
O	96352146	Y	.	B	B	B	S	S	S			1	970510			
-	[05]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01513-08553	Y	.	B	B	B	S	S	S			1				
	[07]	(E)NUT-HEXAGON LOCK (D)MUTTER									(F)ECROU (S)TUERCA					
	08311-38083	Y	.	B	B	B	S	S	S			2				
	[08]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09103-10054	Y	M	B	B	B	S	S	S			1				
	09103-10042	Y	A	B	B	B	O	O	O			1				
	[10]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1750 ALTERNATOR MOUNT(SOHC)




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	01517-08253	Y	.	B	B	B	S	S	S			1					(E)BOLT-HEXAGON FLANGE (F)BOULON (D)SCHRAUBE (S)PERNO
[12]																	
	09103-08019	Y	.	B	B	B	S	S	S			1					(E)WASHER-SPRING (F)RONDELLE (D)DICHTUNGSRING (S)ARANDELA
[14]																	
	08321-21083	Y	.	B	B	B	S	S	S			1					(E)NUT-HEXAGON (F)ECROU (D)MUTTER (S)TUERCA
[15]																	
	08310-11083	Y	.	B	B	B	S	S	S			1					(E)BRACKET-PWM & WIRING (F)SUPPORT (D)TRÄGER (S)SOPORTE
[16]																	
	96242506	Y	.	B	B	B	S	S	S			1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1751 ALTERNATOR MOUNT(DOHC)

3D10



| KEY NO. | PART NAME | | |


1751 ALTERNATOR MOUNT(DOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[10]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE								(F)BOULON (S)PERNO						
	01517-08253	6	.	B	B	B	.	.	O			1				
	[12]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE								(F)BOULON (S)PERNO						
	01517-08353	6	.	B	B	B	.	.	O			1				
	[13]	(E)BUSHING (D)LAGERFUTTER								(F)MANCHON (S)BUJE DE BOQUILLA						
	90280842	6	.	B	B	B	.	.	O			2				
	[14]	(E)WASHER-SPRING (D)DICHTUNGSRING								(F)RONDELLE (S)ARANDELA						
	08321-21083	6	.	B	B	B	.	.	O			1				
	[15]	(E)NUT-HEXAGON (D)MUTTER								(F)ECROU (S)TUERCA						
	08310-11083	6	.	B	B	B	.	.	O			1				
	[16]	(E)BRACKET-C.P.S CONNECTOR (D)TRÄGER								(F)SUPPORT (S)SOPORTE						
	96242507	6	.	B	B	B	.	.	O			1				
	[17]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE								(F)BOULON (S)PERNO						
	01517-08303	6	A	B	B	B	.	.	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1760 STARTER(0.8KW)




KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)STATER A (D)ANLASSER													(F)DEMARREUR (S)ARRANQUE	
	96208781	Y	M	B	B	B	S	S	S	&NN4/NN6		1			0.8KW	SQ
[02]		(E)HOUSING (D)GEHÄUSE													(F)LOGEMENT (S)CARCASA	
	10476114	Y	M	B	B	B	S	S	S			1				
[03]		(E)BUSHING (D)LAGERFUTTER													(F)MANCHON (S)BUJE DE BOQUILLA	
	110526	Y	M	B	B	B	S	S	S			1				
[04]		(E)LEVER (D)HEBEL													(F)LEVIER (S)PALANCA	
	10475062	Y	M	B	B	B	S	S	S			1				
[05]		(E)PLATE (D)PLATTE													(F)PLAQUE (S)PLACA	
	10475061	Y	M	B	B	B	S	S	S			1				
[06]		(E)PLUG (D)STOPSEL													(F)BOUCHON (S)TAPON	
	110725	Y	M	B	B	B	S	S	S			1				
[07]		(E)GASKET (D)DICHTUNG													(F)JOINT (S)JUNTA	
	110645	Y	M	B	B	B	S	S	S			1				
[08]		(E)PLUNGER (D)TAUCHER													(F)PISTON PLONGEUR (S)EMBOLO	
	110974	Y	M	B	B	B	S	S	S			1				
[09]		(E)SPRING (D)FEDERUNG													(F)RESSORT (S)RESORTE	
	100976	Y	M	B	B	B	S	S	S			1				
[10]		(E)SOLENOID (D)SOLENOID													(F)SOLENOIDE (S)SELENOIDE	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
	111350	Y	M	B	B	B	S	S	S			1				
	[11]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	10475056	Y	M	B	B	B	S	S	S			3				
	[12]	(E)ARMATURE (D)ARMATUR										(F)ARMATURE (S)ARMADURA				
	10475100	Y	M	B	B	B	S	S	S			1				
	[13]	(E)COLLAR (D)KRAGEN										(F)COLLIER (S)CASQUILLO				
	10477310	Y	M	B	B	B	S	S	S			1				
	[14]	(E)RING (D)RING										(F)ANNEAU (S)ANILLO				
	01927848	Y	M	B	B	B	S	S	S			1				
	[15]	(E)PINION STOP (D)RITZEL,STOPP										(F)PIGNON-ARRET (S)PIÑON-TOPE				
	01927849	Y	M	B	B	B	S	S	S			1				
	[16]	(E)DRIVE (D)ANTRIEB										(F)ENTRAINEMENT (S)IMPULSADOR				
	10475074	Y	M	B	B	B	S	S	S			1				
	[17]	(E)FRAME-FIELD (D)RAHMEN,FELD										(F)CADRE-CHAMP (S)ARMADURA-CAMPO				
	10475094	Y	M	B	B	B	S	S	S			1				
	[18]	(E)HOLDER-BRUSH (D)BEHÄLTER,BÜRSTE										(F)MONTURE-BALAI (S)RETENEDOR-CEPILLO				
	10475107	Y	M	B	B	B	S	S	S			1				
	[19]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	110720	Y	M	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[20]											(E)WASHER (D)DICHTUNGSRING						
	10475058	Y	M	B	B	B	S	S	S		(F)RONDELLE (S)ARANDELA		1				
[21]											(E)FRAME-COMMUTATOR (D)RAHMEN,KOMMUTATOR ENDE						
	111361	Y	M	B	B	B	S	S	S		(F)CADRE (S)ARMADURA		1				
[22]											(E)BUSHING (D)LAGERFUTTER						
	110295	Y	M	B	B	B	S	S	S		(F)MANCHON (S)BUJE DE BOQUILLA		1				
[23]											(E)SCREW (D)SCHRAUBE						
	10497256	Y	M	B	B	B	S	S	S		(F)VIS (S)TORNILLO		2				
[24]											(E)BOLT (D)SCHRAUBE						
	10475057	Y	M	B	B	B	S	S	S		(F)BOULON (S)PERNO		2				
[25]											(E)NUT (D)MUTTER						
	110720	Y	M	B	B	B	S	S	S		(F)ECROU (S)TUERCA		1				
[29]											(E)SCREW (D)SCHRAUBE						
	08956812	Y	M	B	B	B	S	S	S		(F)VIS (S)TORNILLO		2			M8X1.25X25	
[30]											(E)WASHER (D)DICHTUNGSRING						
	08321-21083	Y	M	B	B	B	S	S	S		(F)RONDELLE (S)ARANDELA		1				
[31]											(E)NUT (D)MUTTER						
	08310-11083	Y	M	B	B	B	S	S	S		(F)ECROU (S)TUERCA		1				
[32]											(E)WASHER (D)DICHTUNGSRING						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1760 STARTER(0.8KW)



KEY NO,	PART NAME													
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	08321-21063	Y	M	B	B	B	S	S	S		1				
	[33]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA				
	08310-21063	Y	M	B	B	B	S	S	S		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1761 STARTER(1.4KW)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)STATER A *(D)ANLASSER*									*(F)DEMARREUR* *(S)ARRANQUE*					
96208782		Y	A	B	B	B	O	O	O	&NN6/NN4		1			1.4KW	SU
96208782		Y	.	B	B	B	A	A	A	&NN7/XCA		1			1.4KW	SU
96208782		6	.	B	B	B	.	.	O			1			1.4KW	SU
[02]		(E)HOUSING *(D)GEHÄUSE*									*(F)LOGEMENT* *(S)CARCASA*					
10476430		.	.	B	B	B	O	O	O			1				
[03]		(E)BUSHING *(D)LAGERFUTTER*									*(F)MANCHON* *(S)BUJE DE BOQUILLA*					
110526		.	.	B	B	B	O	O	O			1				
[04]		(E)LEVER *(D)HEBEL*									*(F)LEVIER* *(S)PALANCA*					
10476003		.	.	B	B	B	O	O	O			1				
[05]		(E)PLATE *(D)PLATTE*									*(F)PLAQUE* *(S)PLACA*					
10475061		.	.	B	B	B	O	O	O			1				
[06]		(E)PLUG *(D)STÖPSEL*									*(F)BOUCHON* *(S)TAPON*					
10475995		.	.	B	B	B	O	O	O			1				
[07]		(E)GASKET *(D)DICHTUNG*									*(F)JOINT* *(S)JUNTA*					
110645		.	.	B	B	B	O	O	O			1				
[08]		(E)PLUNGER *(D)TAUCHER*									*(F)PISTON PLONGEUR* *(S)EMBOLO*					
110974		.	.	B	B	B	O	O	O			1				
[09]		(E)SPRING *(D)FEDERUNG*									*(F)RESSORT* *(S)RESORTE*					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	110976	.	.	B	B	B	O	O	O			1				
	[10]	(E)SOLENOID (D)SOLENOID										(F)SOLENOIDE (S)SELENOIDE				
	110977	.	.	B	B	B	O	O	O			1				
	[11]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	10475056	.	.	B	B	B	O	O	O			3				
	[12]	(E)COLLAR (D)KRAGEN										(F)COLLIER (S)CASQUILLO				
	10477310	.	.	B	B	B	O	O	O			1				
	[13]	(E)DRIVE&SHAFT A (D)ANTRIEB&SPINDEL										(F)ENTRAINEMENT&ARBRE (S)IMPULSADOR&EJE				
	10475969	.	.	B	B	B	O	O	O			1				
	[14]	(E)RING (D)RING										(F)ANNEAU (S)ANILLO				
	01927848	.	.	B	B	B	O	O	O			1				
	[15]	(E)PINION-STOP (D)RITZEL,STOPP										(F)PIGNON-ARRET (S)PIÑON-TOPE				
	111058	.	.	B	B	B	O	O	O			1				
	[16]	(E)DRIVE (D)ANTRIEB										(F)ENTRAINEMENT (S)IMPULSADOR				
	10475974	.	.	B	B	B	O	O	O			1				
	[17]	(E)GEAR (D)GETRIEBE										(F)ENGRENAGE (S)ENGRANAJE				
	10475976	.	.	B	B	B	O	O	O			1				
	[18]	(E)BUSHING (D)LAGERFUTTER										(F)MANCHON (S)BUJE DE BOQUILLA				
	10475977	.	.	B	B	B	O	O	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1761 STARTER(1.4KW)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[19]		(E)SHAFT (D)SPINDEL													(F)ARBRE (S)EJE	
	10475970	. .	B	B	B	O	O	O				1				
[20]		(E)WASHER (D)DICHTUNGSRING													(F)RONDELLE (S)ARANDELA	
	01989917	. .	B	B	B	O	O	O				1				
[21]		(E)BUSHING (D)LAGERFUTTER													(F)MANCHON (S)BUJE DE BOQUILLA	
	10475972	. .	B	B	B	O	O	O				1				
[22]		(E)GEAR (D)GETRIEBE													(F)ENGRENAGE (S)ENGRANAJE	
	10475979	. .	B	B	B	O	O	O				3				
[23]		(E)CUSHION (D)POLSTER													(F)COUSSIN (S)COJIN	
	10476005	. .	B	B	B	O	O	O				1				
[24]		(E)SHIELD (D)KUGELLAGER													(F)ROULEMENT-BILLE (S)COJINETE DE BOLAS	
	10476001	. .	B	B	B	O	O	O				1				
[25]		(E)FRAME-FIELD (D)RAHMEN,FELD													(F)CADRE-CHAMP (S)ARMADURA-CAMPO	
	10476433	. .	B	B	B	O	O	O				1				
[26]		(E)ARMATURE (D)ARMATUR													(F)ARMATURE (S)ARMADURA	
	10475990	. .	B	B	B	O	O	O				1				
[27]		(E)HOLDER BRUSH (D)BEHÄLTER,BÜRSTE													(F)MONTURE-BALAI (S)RETENEDOR-CEPILLO	
	10476006	. .	B	B	B	O	O	O				1				
[28]		(E)BEARING-BALL (D)KUGELLAGER													(F)ROULEMENT-BILLE (S)COJINETE DE BOLAS	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09440924	.	.	B	B	B	O	O	O			1				
	[29]	(E)FRAME-COMMUTATOR END (D)RAHMEN,KOMMUTATOR ENDE										(F)CADRE (S)ARMADURA				
	10468555	.	.	B	B	B	O	O	O			1				
	[30]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	10497256	.	.	B	B	B	O	O	O			2				
	[31]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	10476002	.	.	B	B	B	O	O	O			1				
	[32]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	110720	.	.	B	B	B	O	O	O			1				
	[33]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	08956812	.	.	B	B	B	O	O	O			2			M8X1.25X25	
	[34]	(E)WASHER-SPRING (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	08321-21083	.	.	B	B	B	O	O	O			1				
	[35]	(E)NUT-HEXAGON (D)MUTTER										(F)ECROU (S)TUERCA				
	08310-11083	.	.	B	B	B	O	O	O			1				
	[36]	(E)WASHER-SPRING (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	08321-21063	.	.	B	B	B	O	O	O			1				
	[37]	(E)NUT-HEXAGON (D)MUTTER										(F)ECROU (S)TUERCA				
	08310-21063	.	.	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)BRACKET A-POWER UNIT MT,RR (D)TRÄGER									(F)SUPPORT (S)SOPORTE-MONTAJE					
96221086		.	M	B	B	B	S	S	S			1				MR
[02]		(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
09103-10033		.	.	B	B	B	S	S	S			1				
[03]		(E)BLOCK-PWR UNIT DAMPING,RR (D)BLOCK-DÄMPFUNG									(F)BLOC-AMORTISSEUR (S)BLOQUE					
90372462		.	M	B	B	B	S	S	S			1				TE
96227422		.	A	B	B	B	O	O	O			1				XA
[04]		(E)WASHER-PLAIN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
09160-10001		.	.	B	B	B	S	S	S			1				
[05]		(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
09159-10004		.	.	B	B	B	S	S	S			1				
[06]		(E)WASHER-PLAIN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
09160-10004		Y	.	B	B	B	S	S	S			6				
09160-10004		6	.	B	B	B	.	.	O			4				
[07]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
09100-10012		.	.	B	B	B	S	S	S			4				
[08]		(E)BLOCK-PWR UNIT DAMPING,FRT (D)BLOCK-DÄMPFUNG									(F)BLOC-AMORTISSEUR (S)BLOQUE					
90250437		.	M	B	B	B	S	S	S			LH 1				
[09]		(E)BRACKET A-POWER UNIT MT,FRT (D)TRÄGER									(F)SUPPORT (S)SOPORTE-MONTAJE					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
I T C	PART NO	MODEL							OPTION	L / R	Q T Y	EFFECTIVE DATE		REMARKS	P / C O D E
		E N G	T / A	BODY 4 N	BODY 3 H	BODY 5 H	LEVEL S	LEVEL S E	LEVEL S X				FROM	TO	
	96181254	.	M	B	B	B	S	S	S		LH 1				M5
	[10]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*				
	09103-10032	.	M	B	B	B	S	S	S		LH 3				
	[11]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*				
	09103-10009	.	.	B	B	B	S	S	S		3				
	[12]	(E)BRACKET-POWER UNIT MOUNT, *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE-MONTAJE*				
	96078088	.	M	B	B	B	S	S	S		RH 1				FC
	96181134	.	A	B	B	B	O	O	O		RH 1				A4
	[13]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*				
	09103-10011	.	.	B	B	B	S	S	S		RH 3				
	[14]	(E)BLOCK-PWR UNIT DAMPING,FRT *(D)BLOCK-DÄMPFUNG*									*(F)BLOC-AMORTISSEUR* *(S)BLOQUE*				
	90250348	.	M	B	B	B	S	S	S		RH 1				
	96227425	.	A	B	B	B	O	O	O		RH 1				XB
	[15]	(E)NUT *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*				
	09140-10001	Y	.	B	B	B	S	S	S		2				
	09159-10006	6	.	B	B	B	.	.	O		2				
	[16]	(E)BOLT-HEXAGON *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*				
	09100-12004	.	M	B	B	B	S	S	S		3				
	[17]	(E)PLATE-LOCKING *(D)PLATTE,VERRIEGELUNG*									*(F)PLAQUE-VERROUILLAGE* *(S)PLACA-CIERRE*				
	96243426	.	M	B	B	B	S	S	S		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[18]	09103-10011	.	A	B	B	B	O	O	O			3					(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE (F)BOULON (S)PERNO
[19]	96181137	.	A	B	B	B	O	O	O			1				LA	(E)BRACKET A-POWER UNIT MT,RR (D)TRÄGER (F)SUPPORT (S)SOPORTE-MONTAJE
[20]	96251681	.	.	B	B	B	S	S	S			1					(E)DEFLECTOR-WATER (D)WASSERSCHUTZ-FLÜGEL (F)DEFLECTEUR-EAU (S)DEFLECTOR-AGUA
[21]	09116-06011	.	.	B	B	B	S	S	S			2					(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO
[22]	08361-25063	.	.	B	B	B	S	S	S			2					(E)NUT-HEXAGON (D)MUTTER (F)ECROU (S)TUERCA
[25]	96214804	.	A	B	B	B	O	O	O		LH	1				G4	(E)BRACKET A-POWER UNIT MOUNT (D)TRÄGER (F)SUPPORT (S)SOPORTE
[26]	96181132	.	A	B	B	B	O	O	O		LH	1					(E)BRACKET-POWER UNIT MT,FRT (D)TRÄGER (F)SUPPORT (S)SOPORTE
[27]	96181129	.	A	B	B	B	O	O	O		LH	1					(E)SUPPORT A-POWER UNIT MT,FRT (D)TRÄGER (F)SUPPORT (S)SOPORTE
[28]	09103-10034	.	A	B	B	B	O	O	O		LH	1					(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE (F)BOULON (S)PERNO
[29]																	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

1910 ENGINE MOUNT




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09103-12018	.	A	B	B	B	O	O	O		LH	3				
	[30]	(E)WASHER-PLAIN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	09160-10004	.	A	B	B	B	O	O	O		LH	2				
	[31]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09100-10012	.	A	B	B	B	O	O	O		LH	2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


2 FUEL&ENGINE CONTROL

2110 FUEL TANK
2120 FUEL LINE
2130 CANISTER&FUEL VACUUM
2210 FUEL INJECTION(SOHC)
2211 FUEL INJECTION(DOHC)
2212 FUEL INJECTION(ALCOHOL)
2220 ACCELERATOR CONTROL
2410 AIR INTAKE SYSTEM
2430 INTAKE MANIFOLD(SOHC)
2431 INTAKE MANIFOLD(DOHC)
2440 EXHAUST MANIFOLD(SOHC)
2441 EXHAUST MANIFOLD(DOHC)
2450 VACUUM HOSE(SOHC)
2451 VACUUM HOSE(DOHC)
2460 EXHAUST PIPE LINE
2510 EMISSION CONTROL
2520 EMISSION MODULE MOUNT




ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
	[01]	(E)TANK A-FUEL (D)TANK,BENZIN									(F)RESERVOIR-CARBURANT (S)TANQUE-COMBUSTIBLE					
	S2110003	.	.	B	B	B	S	S	S	-KL9		1				
	S2110006	6	.	B	B	B	.	.	A	&KL9		1				
	[02]	(E)MODULE A-FUEL PUMP (D)PUMPE,BENZIN									(F)POMPE-CARBURANT (S)BOMBA-COMBUSTIBLE					
	96350588	.	.	B	B	B	S	S	S	-KL9		1				TA
	96352018	6	.	B	B	B	.	.	A	&KL9		1				TC
	[03]	(E)O RING-FUEL PUMP (D)O RING									(F)JOINT TORIQUE (S)ANILLO EN O					
	96183170	.	.	B	B	B	S	S	S			1				
	[04]	(E)RING-FUEL PUMP LOCKING (D)RING,DICHTUNG									(F)ANNEAU-JOINT (S)ANILLO-SELLO					
	96183169	.	.	B	B	B	S	S	S			1				
	[07]	(E)BOLT-W/WASHER (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09116-08001	.	.	B	B	B	S	S	S			4				
	[08]	(E)TUBE A-FUEL FILLER (D)ROHRLEITUNG,BENZIN TANKEN									(F)TUYAU (S)TUBO-LLENAR COMBUSTIBLE					
	96351641	.	.	B	B	B	S	S	S	&NN4		1				
	96351342	.	.	B	B	B	A	A	A	&NN6/NN7		1				
	[09]	(E)BRACKET-FUEL FILLER (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96351522	.	.	B	B	B	S	S	S			1				
	[10]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01127-08163	.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME L/R	PART NAME QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[11]									(E)CLAMP-FUEL FILLER *(D)KLAMMER*		*(F)PINCE* *(S)ABRAZADERA*				
	96313240	.	.	B	B	B	S	S	S			1				
	[12]									(E)SHIELD-FUEL FILLER *(D)SCHILD*		*(F)BOUCLIER* *(S)ESCUDO*				
	96351534	.	.	B	B	B	S	S	S			1				
	[13]									(E)NUT *(D)MUTTER*		*(F)ECROU* *(S)TUERCA*				
	09159-06003	.	.	B	B	B	S	S	S			4				
	[14]									(E)SEAL-FUEL FILLER TUBE *(D)DICHTUNG,BENZIN TANK ROHR*		*(F)JOINT* *(S)SELLO*				
	96184683	.	.	B	B	B	S	S	S			1				
	[15]									(E)SCREW-TAPPING *(D)SCHRAUBE*		*(F)VIS* *(S)TORNILLO*				
	03152-48192	.	.	B	B	B	S	S	S			3				
	[16]									(E)CLAMP *(D)KLAMMER*		*(F)PINCE* *(S)ABRAZADERA*				
	09402-25501	.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)TUBE A-FUEL FEEDING,REAR *(D)ROHRLEITUNG*									*(F)TUYAU OU TUBE* *(S)TUBO*					
[01]	96352095														NOT APPLIED	
	96184396	.	.	B	B	B	S	S	S			1			INCL. #17,19	
		(E)TUBE A-FUEL RETURN,REAR *(D)ROHRLEITUNG*									*(F)TUYAU OU TUBE* *(S)TUBO*					
[02]	96352096														NOT APPLIED	
	96184397	.	.	B	B	B	S	S	S			1			INCL. #18,19	
		(E)PIPE-FUEL FEEDING,CENTER *(D)ROHR*									*(F)TUYAU* *(S)TUBERIA*					
[03]	96250326	.	.	B	B	B	S	S	S	-KL9		1				
	96352019	6	.	B	B	B	.	.	A	&KL9		1				
		(E)PIPE-FUEL RETURN,CENTER *(D)ROHR*									*(F)TUYAU* *(S)TUBERIA*					
[04]	96182304	.	.	B	B	B	S	S	S	-KL9		1				
	96352020	6	.	B	B	B	.	.	A	&KL9		1				
		(E)TUBE A-FUEL FILTER,REAR *(D)ROHRLEITUNG*									*(F)TUYAU OU TUBE* *(S)TUBO*				-	
[05]	96352099	.	.	B	B	B	S	S	S			1			INCL. #19	
		(E)TUBE A-FUEL RETURN,FRONT *(D)ROHRLEITUNG*									*(F)TUYAU OU TUBE* *(S)TUBO*					
[06]	96352100	Y	.	B	B	B	S	S	S			1			INCL. #19	
	96352101	6	.	B	B	B	.	.	O	-KL9		1			INCL. #19	
	96352022	6	.	B	B	B	.	.	A	&KL9		1			HOSE TYPE	
		(E)TUBE A-FUEL FILTER,FRT *(D)ROHRLEITUNG*									*(F)TUYAU OU TUBE* *(S)TUBO*					
[07]	96352102	Y	.	B	B	B	S	S	S			1			INCL. #19	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96350574	6	.	B	B	B	.	.	O			1			INCL. #19	
	[08]	(E)FILTER-FUEL *(D)FILTER,BENZIN*										*(F)FILTRE-CARBURANT* *(S)FILTRO-COMBUSTIBLE*				
	25121074	.	.	B	B	B	S	S	S			1				
	[09]	(E)BRACKET-FUEL FILTER *(D)TRÄGER,BENZINFILTER*										*(F)SUPPORT* *(S)SOPORTE*				
	96351817	.	.	B	B	B	S	S	S			1				
	[10]	(E)BOLT-HEXAGON *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	01114-06125	.	.	B	B	B	S	S	S			1				
	[13]	(E)CLIP-FUEL RETURN TUBE *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	96352125	Y	.	B	B	B	S	S	S			1				
	[14]	(E)BOLT-HEXAGON *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	03151-63163	Y	.	B	B	B	S	S	S			1				
	[16]	(E)COVER A-FLANGE *(D)DECKEL*										*(F)COUVERTURE* *(S)CUBIERTA*				
	96352078	.	.	B	B	B	S	S	S			1				
	[17]	(E)RETAINER *(D)HALTER*										*(F)ARRETOIR* *(S)RETENEDOR*				
	HP-9P-86019	.	.	B	B	B	S	S	S			1			Φ 9.5mm	
	[18]	(E)RETAINER *(D)HALTER*										*(F)ARRETOIR* *(S)RETENEDOR*				
	HP-9P-87012	.	.	B	B	B	S	S	S			1			Φ 6.5mm	
	[19]	(E)RETAINER *(D)HALTER*										*(F)ARRETOIR* *(S)RETENEDOR*				
	HP-9P-86020	Y	.	B	B	B	S	S	S			6			Φ 8mm	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME													
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	HP-9P-86020	6	.	B	B	B	.	.	O		5			φ 8mm	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




| KEY NO. | PART NAME | | |



KEY NO.	PART NAME													
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	96184842	.	.	B	B	B	A	A	A	&NN6/NN7		1		INCL. #16	
	96184842	6	.	B	B	B	.	.	A	&KL9		1		INCL. #16	
	[08]	(E)CLAMP *(D)KLAMMER*										*(F)PINCE* *(S)ABRAZADERA*			
	09407-25401	.	.	B	B	B	A	A	A	&NN4&VB4		1			
	09407-25401	.	.	B	B	B	A	A	A	&NN6/NN7		1			
	09407-25401	6	.	B	B	B	.	.	A	&KL9		1			
	[09]	(E)PIPE-PURGE,CENTER *(D)ROHR*										*(F)TUYAU* *(S)TUBERIA*			
	96182327	.	.	B	B	B	A	A	A	&NN4&VB4		1			
	96182327	.	.	B	B	B	A	A	A	&NN6/NN7		1			
	96182327	6	.	B	B	B	.	.	A	&KL9		1			
	[10]	(E)TUBE A-PURGE,FRONT *(D)ROHRLEITUNG*										*(F)TUYAU OU TUBE* *(S)TUBO*			
	96351536	Y	.	B	B	B	A	A	A	&NN4&VB4		1		INCL. #16	
	96351536	Y	.	B	B	B	A	A	A	&NN6/NN7		1		INCL. #16	
	96351537	6	.	B	B	B	.	.	A	&NN4&VB4		1		INCL. #16	
	96351537	6	.	B	B	B	.	.	A	&NN6/NN7		1		INCL. #16	
	96351537	6	.	B	B	B	.	.	A	&KL9		1		INCL. #16	
	[11]	(E)VALVE-PCV *(D)VENTIL*										*(F)SOUPAPE* *(S)VALVULA*			
	96311368	Y	.	B	B	B	A	A	A	&NN4&VB4		1			
	96311368	Y	.	B	B	B	A	A	A	&NN6/NN7		1			
	1997210	6	.	B	B	B	.	.	A	&NN4&VB4		1			
	1997210	6	.	B	B	B	.	.	A	&NN6/NN7		1			
	96311368	6	.	B	B	B	.	.	A	&KL9		1			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
I-TC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	[14]	(E)BRACKET A-CANISTER *(D)TRÄGER,KANISTER*									*(F)SUPPORT-BOITE METALLIQUE* *(S)SOPORTE-BOTE*					
	96216728	.	.	B	B	B	S	S	S		1					
	[15]	(E)TUBE A-PURGE,ENGINE *(D)ROHRLEITUNG*									*(F)TUYAU OU TUBE* *(S)TUBO*					
	96351540	Y	.	B	B	B	A	A	A	&NN4&VB4	1					
	96351540	Y	.	B	B	B	A	A	A	&NN6/NN7	1					
	96351889	6	.	B	B	B	.	.	A	&NN4&VB4	1					
	96351889	6	.	B	B	B	.	.	A	&NN6/NN7	1					
	96351889	6	.	B	B	B	.	.	A	&KL9	1					
	[16]	(E)RETAINER *(D)HALTER*									*(F)ARRETOIR* *(S)RETENEDOR*					
	HP-9P-86020	.	.	B	B	B	A	A	A	&NN4&VB4	5				Φ 8mm	
	HP-9P-86020	.	.	B	B	B	A	A	A	&NN6/NN7	5				Φ 8mm	
	HP-9P-86020	6	.	B	B	B	.	.	A	&KL9	5				Φ 8mm	
	[19]	(E)CANISTER *(D)KANISTER,BENZIN-DAMPF*									*(F)BOITE-VAPEURS CARBURANT* *(S)BOTE-COMBUSTIBLE Y VAPOR*					
	96181415	.	.	B	B	B	A	A	A	&NN4&VB4	1					
	96181415	.	.	B	B	B	A	A	A	&NN6/NN7	1					
	96181415	6	.	B	B	B	.	.	A	&KL9	1					
	[20]	(E)SHIELD-CANISTER *(D)SCHILD*									*(F)BOUCLIER* *(S)ESCUDO*					
	96351820	.	.	B	B	B	A	A	A	&NN4&VB4	1					
	96351820	.	.	B	B	B	A	A	A	&NN6/NN7	1					
	96351820	6	.	B	B	B	.	.	A	&KL9	1					
	[21]	(E)CLIP *(D)KLEMME*									*(F)ATTACHE* *(S)GRAPA*					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

2130 CANISTER&FUEL VACUUM




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09401-15403	.	.	B	B	B	A	A	A	&NN4&VB4		1				
	09401-15403	.	.	B	B	B	A	A	A	&NN6/NN7		1				
	09401-15403	6	.	B	B	B	.	.	A	&KL9		1				
[22]	(E)HOSE-AIR VENT,CANISTER (D)SCHLAUCH											(F)TUYAU (S)MANGUERA				
	96351958	.	.	B	B	B	A	A	A	&NN4&VB4		1				
	96351958	.	.	B	B	B	A	A	A	&NN6/NN7		1				
	96351958	6	.	B	B	B	.	.	A	&KL9		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]										(E)BODY A -THROTTLE (D)KAROSSERIE,GASHEBEL					(F)CORPS-COMMANDE DES GAZ (S)CARROCERIA-ESTRANGULADOR	
	96184569	Y	.	B	B	B	S	S	S				1				
	[02]										(E)GASKET-THROTTLE BODY (D)DICHTUNG,DROSSEL KÖRPER					(F)JOINT (S)JUNTA	
	96352111	Y	.	B	B	B	S	S	S				1				
	[03]										(E)BOLT (D)SCHRAUBE					(F)BOULON (S)PERNO	
	09117-08010	Y	.	B	B	B	S	S	S				2				
	[04]										(E)SENSOR A-THROTTLE PSTN (D)SENSOR,DROSSEL STELLUNG					(F)DETECTEUR (S)SENSOR	
	17106681	Y	.	B	B	B	S	S	S				1				
	[05]										(E)VALVE-IDLING CONTROL (D)VENTIL					(F)SOUPAPE (S)VALVULA	
	17059602	Y	.	B	B	B	S	S	S				1				
	[06]										(E)RAIL A-FUEL (D)SCHIENE,BENZIN					(F)RAIL-CARBURANT (S)RIEL-COMBUSTIBLE	
	96184729	Y	.	B	B	B	S	S	S				1				
	[07]										(E)BOLT-HEXAGON (D)SCHRAUBE					(F)BOULON (S)PERNO	
	01127-08353	Y	.	B	B	B	S	S	S				2				
	[08]										(E)REGULATOR A-FUEL PRESSURE (D)REGULATOR,BENZIN DRUCK					(F)REGULATEUR (S)REGULADOR	
	96184228	Y	.	B	B	B	S	S	S				1				
	[09]										(E)SCREW-PAN (D)SCHRAUBE					(F)VIS (S)TORNILLO	
	9034906100	Y	.	B	B	B	S	S	S				1				
	[10]										(E)HOSE-VACUUM (D)SCHLAUCH,VAKUUM					(F)TUYAU-DEPRESSION (S)MANGUERA-VACIO	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96351089	Y	.	B	B	B	S	S	S	(E)INJECTOR A-FUEL *(D)EINSPRITZE,BENZIN*		1			195mm	
	[11]									*(F)INJECTEUR-CARBURANT* *(S)INYECTOR-COMBUSTIBLE*						
	25171743	Y	.	B	B	B	S	S	S			4				
	[13]									(E)RING-INJECTOR,UPPER *(D)O RING,EINSPRITZER* *(F)JOINT TORIQUE-INJECTEUR* *(S)ANILLO EN O-INYECTOR*						
	05235032	Y	.	B	B	B	S	S	S			4				
	[14]									(E)RING-INJECTOR,LOWER *(D)O RING,EINSPRITZER* *(F)JOINT TORIQUE-INJECTEUR* *(S)ANILLO EN O-INYECTOR*						
	17108225	Y	.	B	B	B	S	S	S			4				
	[15]									(E)WASHER-SEAL *(D)DICHTUNGSRING* *(F)RONDELLE* *(S)ARANDELA*						
	96143641	Y	.	B	B	B	S	S	S			1				
	[16]									(E)CONNECTOR-FUEL RAIL *(D)VERBINDUNG* *(F)CONNECTEUR* *(S)CONECTOR*						
	96184471	Y	.	B	B	B	S	S	S			1				
	[17]									(E)RING-SEAL *(D)RING,DICHTUNG* *(F)ANNEAU-JOINT* *(S)ANILLO-SELLO*						
	17081434	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1 5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)BODY A -THROTTLE (D)KAROSSERIE,GASHEBEL									(F)CORPS-COMMANDE DES GAZ (S)CARROCERIA-ESTRANGULADOR					
96184572		6	.	B	B	B	.	.	O			1				
[02]		(E)GASKET-THROTTLE BODY (D)DICHTUNG,DROSSEL KÖRPER									(F)JOINT (S)JUNTA					
96352111		6	.	B	B	B	.	.	O			1				
[03]		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
09117-08010		6	.	B	B	B	.	.	O			2				
[04]		(E)SENSOR A-THROTTLE PSTN (D)SENSOR,DROSSEL STELLUNG									(F)DETECTEUR (S)SENSOR					
17106681		6	.	B	B	B	.	.	O			1				
[05]		(E)VALVE-IDLING CONTROL (D)VENTIL									(F)SOUPAPE (S)VALVULA					
17059602		6	.	B	B	B	.	.	O			1				
[06]		(E)RAIL A-FUEL (D)SCHIENE,BENZIN									(F)RAIL-CARBURANT (S)RIEL-COMBUSTIBLE					
96183232		6	.	B	B	B	.	.	O			1				
[07]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
01137-08163		6	.	B	B	B	.	.	O			2				
[08]		(E)REGULATOR A-FUEL PRESSURE (D)REGULATOR,BENZIN DRUCK									(F)REGULATEUR (S)REGULADOR					
96184759		6	.	B	B	B	.	.	O			1				
[09]		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
09360-16001															NOT APPLIED	
96143390		6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME													
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[10]									(E)HOSE-VACUUM (D)SCHLAUCH,VAKUUM					(F)TUYAU-DEPRESSION (S)MANGUERA-VACIO	
	96351089	6	.	B	B	B	.	.	O			1	970401		195mm	
Y	96248446	6	.	B	B	B	.	.	O			1	970401		165mm	
	[11]									(E)INJECTOR A-FUEL (D)EINSPRITZE,BENZIN					(F)INJECTEUR-CARBURANT (S)INYECTOR-COMBUSTIBLE	
	25174024	6	.	B	B	B	.	.	O			4				
	[12]									(E)RING-INJECTOR,UPPER (D)O RING,EINSPRITZER					(F)JOINT TORIQUE-INJECTEUR (S)ANILLO EN O-INYECTOR	
	05235032	6	.	B	B	B	.	.	O			4				
	[13]									(E)CONNECTOR-FUEL RAIL (D)VERBINDUNG					(F)CONNECTEUR (S)CONECTOR	
	96183364	6	.	B	B	B	.	.	O			1				
	[14]									(E)BOLT-UNION (D)SCHRAUBE					(F)BOULON (S)PERNO	
	09360-16001	6	.	B	B	B	.	.	O			1				
	[15]									(E)GASKET-CONNECTOR (D)DICHTUNG					(F)JOINT (S)JUNTA	
	96183365	6	.	B	B	B	.	.	O			2				
	[17]									(E)PIPE A-ADAPTOR RETURN (D)ROHR					(F)TUYAU (S)TUBERIA	
	96183068	6	.	B	B	B	.	.	O			1				
	[18]									(E)O RING (D)O RING					(F)JOINT TORIQUE (S)ANILLO EN O	
	96114707	6	.	B	B	B	.	.	O			1				
	[19]									(E)BRACKET-PIPE ADAPTOR RTN (D)TRÄGER					(F)SUPPORT (S)SOPORTE	
	96183070	6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[20]		(E)RING-SEAL (D)RING,DICHTUNG									(F)ANNEAU-JOINT (S)ANILLO-SELLO					
17081434		6	.	B	B	B	.	.	O		1					
[21]		(E)RING-INJECTOR,LOWER (D)O RING,EINSPRITZER									(F)JOINT TORIQUE-INJECTEUR (S)ANILLO EN O-INYECTOR					
17108225		6	.	B	B	B	.	.	O		4					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)BODY A -THROTTLE (D)KAROSSERIE,GASHEBEL								(F)CORPS-COMMANDE DES GAZ (S)CARROCERIA-ESTRANGULADOR						
	96184572	6	.	B	B	B	.	.	A	&KL9		1				
	[02]	(E)GASKET-THROTTLE BODY (D)DICHTUNG,DROSSEL KÖRPER								(F)JOINT (S)JUNTA						
	96352111	6	.	B	B	B	.	.	A	&KL9		1				
	[03]	(E)BOLT (D)SCHRAUBE								(F)BOULON (S)PERNO						
	09117-08010	6	.	B	B	B	.	.	A	&KL9		2				
	[04]	(E)SENSOR A-THROTTLE PSTN (D)SENSOR,DROSSEL STELLUNG								(F)DETECTEUR (S)SENSOR						
	17106681	6	.	B	B	B	.	.	A	&KL9		1				
	[05]	(E)VALVE-IDLING CONTROL (D)VENTIL								(F)SOUPAPE (S)VALVULA						
	17059602	6	.	B	B	B	.	.	A	&KL9		1				
	[06]	(E)RAIL A-FUEL (D)SCHIENE,BENZIN								(F)RAIL-CARBURANT (S)RIEL-COMBUSTIBLE						
	96242764	6	.	B	B	B	.	.	A	&KL9		1				
	[07]	(E)BOLT-HEXAGON (D)SCHRAUBE								(F)BOULON (S)PERNO						
	01137-08163	6	.	B	B	B	.	.	A	&KL9		2				
	[08]	(E)REGULATOR A-FUEL PRESSURE (D)REGULATOR,BENZIN DRUCK								(F)REGULATEUR (S)REGULADOR						
	0280150716	6	.	B	B	B	.	.	A	&KL9		1				
	[10]	(E)HOSE-VACUUM (D)SCHLAUCH,VAKUUM								(F)TUYAU-DEPRESSION (S)MANGUERA-VACIO						
	96242772	6	.	B	B	B	.	.	A	&KL9		1				
	[11]	(E)INJECTOR A-FUEL (D)EINSPRITZE,BENZIN								(F)INJECTEUR-CARBURANT (S)INYECTOR-COMBUSTIBLE						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	0280150983	6	.	B	B	B	.	.	A	&KL9		4				
[13]	(E)CONNECTOR-FUEL FEEDING *(D)VERBINDUNG* *(F)CONNECTEUR* *(S)CONECTOR*															
	96242769	6	.	B	B	B	.	.	A	&KL9		1				
[14]	(E)BOLT-UNION *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*															
	09360-16002	6	.	B	B	B	.	.	A	&KL9		2				
[15]	(E)GASKET-CONNECTOR *(D)DICHTUNG* *(F)JOINT* *(S)JUNTA*															
	96183365	6	.	B	B	B	.	.	A	&KL9		4				
[16]	(E)CONNECTOR-FUEL RETURN *(D)VERBINDUNG* *(F)CONNECTEUR* *(S)CONECTOR*															
	96242767	6	.	B	B	B	.	.	A	&KL9		1				
[17]	(E)HOSE-FUEL RETURN *(D)SCHLAUCH* *(F)TUYAU* *(S)MANGUERA*															
	96242771	6	.	B	B	B	.	.	A	&KL9		1				
[18]	(E)CLAMP *(D)KLAMMER* *(F)PINCE* *(S)ABRAZADERA*															
	09402-16503	6	.	B	B	B	.	.	A	&KL9		3				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)CABLE A-ACCEL. CONT. BOWDEN (D)KABEL,GAS-STEUERUNG										(F)CABLE- ACCELERATEUR (S)CABLE				
	96351836	Y	.	B	B	B	S	S	S			1				ML
	96182338	6	.	B	B	B	.	.	O			1				DL
	[02]	(E)GROMMET (D)ÖSE										(F)VIROLE (S)AISLANTE				
	09308-17002	.	.	B	B	B	S	S	S			1				
	[03]	(E)RING-RETAINING E TYPE (D)RING,HALTER										(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR				
	08332-21089	.	.	B	B	B	S	S	S			1				
	[04]	(E)LEVER A-ACCELERATOR PEDAL (D)HEBEL,GASPEDAL										(F)LEVIER (S)PALANCA				
	96182335	.	.	B	B	B	S	S	S			1				AL
	[05]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	09159-08003	.	.	B	B	B	S	S	S			2				
-	[06]	(E)LEVER-ACCELERATOR PEDAL (D)HEBEL,GASPEDAL										(F)LEVIER (S)PALANCA				
	96184217	.	.	B	B	B	S	S	S			1				
	[07]	(E)PAD-ACCELERATOR PEDAL (D)UNTERLAGE,GASPEDAL										(F)PATIN (S)COJIN-PEDAL				
	96184690	.	.	B	B	B	S	S	S			1				
	[08]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	02116-06309	.	.	B	B	B	S	S	S			1				
	[09]	(E)SPRING (D)FEDERUNG										(F)RESSORT (S)RESORTE				
	09440-09003	.	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[10]									(E)BUMPER-ADJUSTING SCREW *(D)STOßSCHEIBE*					*(F)PARE-CHOC-VIS DE REGLAGE* *(S)PARACHOQUES-TORNILLO*	
	09292075	.	.	B	B	B	S	S	S			1				
	[11]									(E)SPRING-LEG *(D)FEDERUNG,BEIN*					*(F)RESSORT-JAMBE* *(S)RESORTE-PIERNA*	
	90183525	.	.	B	B	B	S	S	S			1				
	[12]									(E)BUSHING *(D)LAGERFUTTER*					*(F)MANCHON* *(S)BUJE DE BOQUILLA*	
	09306-10005	.	.	B	B	B	S	S	S			2				
	[13]									(E)RING-RETAINING E TYPE *(D)RING,HALTER*					*(F)ANNEAU-DE RETENTION* *(S)ANILLO-RETENEDOR*	
	08332-11089	.	.	B	B	B	S	S	S			2				
	[14]									(E)WASHER-PLAIN *(D)DICHTUNGSRING*					*(F)RONDELLE* *(S)ARANDELA*	
	09160-18003	.	.	B	B	B	S	S	S			2				
	[15]									(E)WASHER-SPRING *(D)DICHTUNGSRING*					*(F)RONDELLE* *(S)ARANDELA*	
	09162-10001	.	.	B	B	B	S	S	S			1				
	[16]									(E)WASHER-PLAIN *(D)DICHTUNGSRING*					*(F)RONDELLE* *(S)ARANDELA*	
	09160-10003	.	.	B	B	B	S	S	S			1				
	[17]									(E)BRACKET-ACCEL.CONTROL *(D)TRÄGER,GASPEDAL*					*(F)SUPPORT-ACCELERATEUR* *(S)SOPORTE*	
	96184602	Y	.	B	B	B	S	S	S			1				
	96351517	6	.	B	B	B	.	.	O			1				
	[18]									(E)BOLT-HEXAGON *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*	
	01107-06123	.	.	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

2410 AIR INTAKE SYSTEM



KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)AIR CLEANER A *(D)LUFTREINIGUNG*													*(F)PURIFICATEUR D'AIR* *(S)FILTRO DEL AIRE*	
	96182219	.	.	B	B	B	S	S	S			1				
[02]		(E)AIR CLEANER-UPPER *(D)LUFTREINIGUNG,OBER*													*(F)PURIFICATEUR D'AIR,HAUT* *(S)FILTRO DEL AIRE,SUPERIOR*	
	96182231	.	.	B	B	B	S	S	S			1				
[03]		(E)AIR CLEANER-LOWER *(D)LUFTREINIGUNG,UNTEN*													*(F)PURIFICATEUR D'AIR,BAS* *(S)FILTRO DEL AIRE,BAJO*	
	96182232	.	.	B	B	B	S	S	S			1				
[04]		(E)CLIP-AIR CLEANER *(D)KLEMME*													*(F)ATTACHE* *(S)GRAPA*	
	96300903	.	.	B	B	B	S	S	S			4				
[05]		(E)SPACER-ISOLATOR *(D)DISTANZSTÜCK,ISOLATOR*													*(F)ENTRETOISE-ISOLATEUR* *(S)ESPACIADOR-AISLADOR*	
	96300905	.	.	B	B	B	S	S	S			3				
[06]		(E)ISOLATOR-AIR CLEANER *(D)ISOLATOR,LUFTREINIGUNG*													*(F)ISOLATEUR-FILTRE A AIR* *(S)AISLADOR-FILTRO DEL AIRE*	
	96303067	.	.	B	B	B	S	S	S			1				
[07]		(E)ELEMENT A-AIR CLEANER *(D)ELEMENT,LUFTREINIGUNG*													*(F)ELEMENT-FILTRE A AIR* *(S)ELEMENTO-FILTRO DEL AIRE*	
	96182220	.	.	B	B	B	S	S	S			1				
[08]		(E)BOLT *(D)SCHRAUBE*													*(F)BOULON* *(S)PERNO*	
	09116-06014	.	.	B	B	B	S	S	S			2				
[09]		(E)NUT-HEXAGON *(D)MUTTER*													*(F)ECROU* *(S)TUERCA*	
	08361-25063	.	.	B	B	B	S	S	S			1				
[10]		(E)TUBE-AIR CLEANER CONNECT *(D)ROHRLEITUNG*													*(F)TUYAU OU TUBE* *(S)TUBO*	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	96182223	.	.	B	B	B	S	S	S			1					(E)RESONATOR A *(F)RESONATEUR* *(D)RESONATOR* *(S)RESONADOR*
	[11]																
	96352224	.	.	B	B	B	S	S	S			1	970520				
N	96352243	.	.	B	B	B	S	S	S			1	970520				(E)RESONATOR *(F)RESONATEUR* *(D)RESONATOR* *(S)RESONADOR*
	[12]																
	96352026	.	.	B	B	B	S	S	S			1					(E)DUCT-AIR INLET *(F)CONDUIT-ENTREE D'AIR* *(D)SCHACHT LUFTEINLAß* *(S)CONDUCTO-ENTRADA DE AIRE*
	[13]																
	96182233	.	.	B	B	B	S	S	S			1					(E)SEAL-RESONATOR *(F)JOINT D'ETANCHEITE* *(D)DICHTUNG* *(S)SELLO*
	[14]																
	96181265	.	.	B	B	B	S	S	S			1					(E)SPACER-ISOLATOR *(F)ENTRETOISE-ISOLATEUR* *(D)DISTANZSTÜCK,ISOLATOR* *(S)ESPACIADOR-AISLADOR*
	[15]																
	96300905	.	.	B	B	B	S	S	S			1					(E)ISOLATOR-AIR CLEANER *(F)ISOLATEUR-FILTRE A AIR* *(D)ISOLATOR,LUFTREINIGUNG* *(S)AISLADOR-FILTRO DEL AIRE*
	[16]																
	96300904	.	.	B	B	B	S	S	S			1					(E)ISOLATOR-INTAKE *(F)ISOLATEUR* *(D)ISOLATOR* *(S)AISLADOR*
	[17]																
	96351744	.	.	B	B	B	S	S	S			1					(E)BOLT *(F)BOULON* *(D)SCHRAUBE* *(S)PERNO*
	[18]																
	09116-06014	.	.	B	B	B	S	S	S			1					(E)HOSE A-AIR INLET *(F)TUYAU-ENTREE D'AIR* *(D)SCHACHT LUFTEINLAß* *(S)MANGUERA-ENTRADA DE AIRE*
	[19]																


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

2410 AIR INTAKE SYSTEM



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96352183	.	.	B	B	B	S	S	S			1	970520			
N	96352225	.	.	B	B	B	S	S	S			1	970520			
	[21]	(E)HOSE A-AIR OUTLET *(D)SCHLAUCH*										*(F)TUYAU* *(S)MANGUERA*				
	96182227	Y	.	B	B	B	S	S	S			1				
	96182228	6	.	B	B	B	.	.	O			1				
	[22]	(E)HOSE-ENGINE VENTILATION *(D)SCHLAUCH,VENTILATOR*										*(F)TUYAU-VENTILATION* *(S)MANGUERA-VENTILACION*				
	96351640	Y	.	B	B	B	S	S	S			1				
	96351636	6	.	B	B	B	.	.	O			1				
	[23]	(E)CONNECTOR-P.C.V HOSE *(D)VERBINDUNG*										*(F)CONNECTEUR* *(S)CONECTOR*				
	96184450	Y	.	B	B	B	S	S	S			1				
	96351115	6	.	B	B	B	.	.	O			1				
	[24]	(E)SENSOR A-AIR TEMPERATURE *(D)SENSOR,TEMPERATUR*										*(F)DETECTEUR-TEMPERATURE* *(S)SENSOR-TEMPERATURA*				
	96183228	.	.	B	B	B	S	S	S			1				
	[25]	(E)CLAMP *(D)KLAMMER*										*(F)PINCE* *(S)ABRAZADERA*				
	09402-80501	.	.	B	B	B	S	S	S			1				
	[26]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	09401-20401	Y	.	B	B	B	S	S	S			1				
	09401-22401	6	.	B	B	B	.	.	O			1				
	[27]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	09401-27403	Y	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09401-22401	6	.	B	B	B	.	.	O			1				
	[28]	(E)CLAMP (D)KLAMMER										(F)PINCE (S)ABRAZADERA				
	09402-70501	.	.	B	B	B	S	S	S			1				
	[29]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	09159-06001	.	.	B	B	B	S	S	S			1	970901			
O	09159-06011	.	.	B	B	B	S	S	S			1	970901			
	[30]	(E)BUMPER (D)STOßSTANGE										(F)PARE-CHOC (S)PARACHOQUES				
	96144011	.	.	B	B	B	S	S	S			1				
	[31]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	09159-06001	.	.	B	B	B	S	S	S			1	970901			
O	09159-06011	.	.	B	B	B	S	S	S			1	970901			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

2430 INTAKE MANIFOLD(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
											(E)MANIFOLD-INTAKE (D)SAMMELLEITUNG,EINLAß (F)COLLECTEUR-ADMISSION (S)COLECTOR-ENTRADA						
[01]	96184771	Y	M	B	B	B	S	S	S	&NN4/NN6			1				
	96182953	Y	A	B	B	B	O	O	O	&NN4/NN6			1				
	96182953	Y	.	B	B	B	A	A	A	&NN7			1				
[02]											(E)GASKET-INTAKE MANIFOLD (D)DICHTUNG,SAMMELLEITUNG (F)JOINT (S)JUNTA-COLECTOR DE ENTRADA						
	96183118	Y	.	B	B	B	S	S	S				1				
[04]											(E)NUT-HEXAGON LOCK (D)MUTTER (F)ECROU (S)TUERCA						
	08311-38083	Y	.	B	B	B	S	S	S				9				
[05]											(E)SENSOR A-TEMPERATURE (D)SENSOR,TEMPERATUR (F)DETECTEUR-TEMPERATURE (S)SENSOR-TEMPERATURA						
	96177604	Y	.	B	B	B	S	S	S				1				
[06]											(E)VALVE-EGR (D)VENTIL (F)SOUPAPE (S)VALVULA						
	17089050	Y	A	B	B	B	O	O	O	&NN4/NN6			1				
	17089050	Y	.	B	B	B	A	A	A	&NN7			1				
[07]											(E)GASKET-EGR (D)DICHTUNG (F)JOINT (S)JUNTA						
	96184987	Y	A	B	B	B	O	O	O	&NN4/NN6			1				
	96184987	Y	.	B	B	B	A	A	A	&NN7			1				
[08]											(E)PIPE A-VACUUM (D)ROHR,VAKUUM (F)TUYAU-DEPRESSION (S)TUBERIA-VACIO						
	96242226	Y	A	B	B	B	O	O	O	&NN4/NN6			1				
	96242228	Y	.	B	B	B	A	A	A	&NN7			1				
[09]											(E)BOLT-HEXAGON (D)SCHRAUBE (F)BOULON (S)PERNO						


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	11048333	Y	A	B	B	B	O	O	O	&NN4/NN6		2				
	11048333	Y	.	B	B	B	A	A	A	&NN7		2				
	[10]	(E)BRACKET-ENGINE (D)TRÄGER								CONT.HARNESS		(F)SUPPORT (S)SOPORTE				
	96234616	Y	.	B	B	B	S	S	S			1				
	[11]	(E)BRACKET-ENGINE (D)TRÄGER								CONT.HARNESS		(F)SUPPORT (S)SOPORTE				
	96234617	Y	.	B	B	B	S	S	S			1				
	[12]	(E)VALVE-SOLENOID (D)VENTIL										(F)SOUPAPE (S)VALVULA				
	96350594	Y	.	B	B	B	A	A	A	&NN7		1				
	[13]	(E)BRACKET-EGR (D)TRÄGER										(F)SUPPORT (S)SOPORTE				
	96350602	Y	.	B	B	B	A	A	A	&NN7		1				
	[14]	(E)PIPE A-VACUUM (D)ROHR,VAKUUM										(F)TUYAU-DEPRESSION (S)TUBERIA-VACIO				
	96242229	Y	.	B	B	B	A	A	A	&NN7		1				
	[15]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09408-00030	Y	.	B	B	B	A	A	A	&NN7		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

2431 INTAKE MANIFOLD(DOHC)




KEY NO.	PART NAME														
ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)MANIFOLD A-INTAKE,VGIS (D)SAMMELLEITUNG,EINLAß									(F)COLLECTEUR-ADMISSION (S)COLECTOR-ENTRADA					
	96182872	6	.	B	B	B	.	.	O	&NN4/NN7		1	970522			
	96351815	6	M	B	B	B	.	.	A	&NN6		1	970522			
	96182872	6	A	B	B	B	.	.	A	&NN6		1	970522			
	96182872	6	.	B	B	B	.	.	O	-KL9		1	970522			
	96352535	6	.	B	B	B	.	.	A	&KL9		1			FOR BRAZIL	
	[02]	(E)GASKET-INTAKE MANIFOLD (D)DICHTUNG,SAMMELLEITUNG									(F)JOINT (S)JUNTA-COLECTOR DE ENTRADA					
	5094207001	6	.	B	B	B	.	.	O			1				
	[03]	(E)BOLT-STUD (D)STIFTSCHRAUBE									(F)BOULON-TETON (S)PERNO-ESPIGA					
	01420-08253	6	.	B	B	B	.	.	O			2				
	[04]	(E)NUT-HEXAGON (D)MUTTER									(F)ECROU (S)TUERCA					
	08310-12083	6	.	B	B	B	.	.	O			2				
	[05]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01512-08253	6	.	B	B	B	.	.	O			4				
	[06]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01120-08753	6	.	B	B	B	.	.	O			1				
	[07]	(E)ACTUATOR A-VGIS (D)BETÄTIGUNG									(F)ACTIONNEUR (S)ACTUADOR					
	96184029	6	.	B	B	B	.	.	O			1				
	[08]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01110-06163	6	.	B	B	B	.	.	O	&NN4/NN7		6	970522			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	01110-06163	6	M	B	B	B	.	.	A	&NN6		2	970522			
	01110-06163	6	A	B	B	B	.	.	A	&NN6		6	970522			
	01110-06163	6	.	B	B	B	.	.	O			8	970522			
[09]	(E)RING-RETAINING E TYPE *(D)RING,HALTER*											*(F)ANNEAU-DE RETENTION* *(S)ANILLO-RETENEDOR*				
	08332-11033	6	.	B	B	B	.	.	O			1				
[10]	(E)PIPE-EGR PASSAGE,VGIS *(D)ROHR*											*(F)TUYAU* *(S)TUBERIA*				
	96184030	6	.	B	B	B	.	.	O	&NN4/NN7		1	970522			
	96184030	6	A	B	B	B	.	.	A	&NN6		1	970522			
	96184030	6	.	B	B	B	.	.	O			1	970522			
[11]	(E)BRACKET-EGR,VGIS *(D)TRÄGER*											*(F)SUPPORT* *(S)SOPORTE*				
	96184111	6	.	B	B	B	.	.	O	&NN4/NN7		1	970522			
	96184111	6	A	B	B	B	.	.	A	&NN6		1	970522			
	96184111	6	.	B	B	B	.	.	O			1	970522			
[12]	(E)BOLT-HEXAGON *(D)SCHRAUBE*											*(F)BOULON* *(S)PERNO*				
	01117-06123	6	.	B	B	B	.	.	O	&NN4/NN7		1	970522			
	01117-06123	6	A	B	B	B	.	.	A	&NN6		1	970522			
	01117-06123	6	.	B	B	B	.	.	O			1	970522			
[15]	(E)BOLT-HEXAGON *(D)SCHRAUBE*											*(F)BOULON* *(S)PERNO*				
	01130-08353	6	.	B	B	B	.	.	O			7				
[16]	(E)NUT-HEXAGON LOCK *(D)MUTTER*											*(F)ECROU* *(S)TUERCA*				
	08311-38083	6	.	B	B	B	.	.	O			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[17]	(E)GASKET-MANIFOLD,VGIS (D)DICHTUNG									(F)JOINT (S)JUNTA					
	96184699	6	.	B	B	B	.	.	O			1				
	[18]	(E)GASKET-EGR PIPE,VGIS (D)DICHTUNG									(F)JOINT (S)JUNTA					
	96351344	6	.	B	B	B	.	.	O	&NN4/NN7		2		970522		
	96351344	6	A	B	B	B	.	.	A	&NN6		2		970522		
	96351344	6	.	B	B	B	.	.	O			2	970522			
	[19]	(E)BRACKET-MANIFOLD,VGIS (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96352245	6	.	B	B	B	.	.	O			1				
	[20]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01120-08163	6	.	B	B	B	.	.	O			2				
	[21]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09116-10001	6	.	B	B	B	.	.	O			2				
	[22]	(E)BRACKET-REGULATOR (D)TRÄGER									(F)SUPPORT (S)SOPORTE				-	
	96242770	6	.	B	B	B	.	.	A	&KL9		1			FOR BRAZIL	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.		PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)MANIFOLD-EXHAUST *(D)SAMMELLEITUNG,ABGAS*														
	96184642	Y	.	B	B	B	S	S	S			1				
	[02]	(E)GASKET-EXHAUST MANIFOLD *(D)DICHTUNG,SAMMELLEITUNG*														
	96181207	Y	.	B	B	B	S	S	S			1				
	[03]	(E)SHIELD-EXH MANIFOLD HEAT *(D)HEIZSCHUTZTEIL*														
	96182236	Y	.	B	B	B	S	S	S			1				MS
	[04]	(E)BOLT-HEXAGON *(D)SCHRAUBE*														
	01180-08162	Y	.	B	B	B	S	S	S			3				
	[05]	(E)NUT *(D)MUTTER*														
	09159-08012	Y	.	B	B	B	S	S	S			8				
	[06]	(E)SENSOR A-EXHAUST GAS *(D)SENSOR,ABGAS BELÜFTUNG*														
	25162753	Y	.	B	B	B	A	A	A	&NN6/NN7		1				
	[07]	(E)BOLT *(D)SCHRAUBE*														
	96100183	Y	.	B	B	B	S	S	S	&NN4		1		971001		
O	09247-18001	Y	.	B	B	B	S	S	S	&NN4		1		971001		

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


2441 EXHAUST MANIFOLD(DOHC)



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)MANIFOLD-EXHAUST (D)SAMMELLEITUNG,ABGAS													(F)COLLECTEUR-ECHAPPEMENT (S)COLECTOR,ESCAPE	
96350544		6	.	B	B	B	.	.	O			1				
[02]		(E)GASKET-EXHAUST MANIFOLD (D)DICHTUNG,SAMMELLEITUNG													(F)JOINT (S)JUNTA-COLECTOR DE ESCAPE	
509402100\		6	.	B	B	B	.	.	O			1		970507		
Y 96350469		6	.	B	B	B	.	.	O			1	970507			
[03]		(E)NUT (D)MUTTER													(F)ECROU (S)TUERCA	
09159-08012		6	.	B	B	B	.	.	O			10				
[04]		(E)WASHER (D)DICHTUNGSRING													(F)RONDELLE (S)ARANDELA	
96143555		6	.	B	B	B	.	.	O			3				
[05]		(E)BOLT-HEXAGON (D)SCHRAUBE													(F)BOULON (S)PERNO	
01180-08162		6	.	B	B	B	.	.	O			3				
[06]		(E)SHIELD-EXH MANIFOLD HEAT (D)HEIZSCHUTZTEIL													(F)BOUCLIER THERMIQUE (S)ESCUDO REFRACTARIO	
96350821		6	.	B	B	B	.	.	O			1				MD
[07]		(E)SENSOR A-EXHAUST GAS (D)SENSOR,ABGAS BELÜFTUNG													(F)DETECTEUR (S)SENSOR-OXIGENO DEL ESCAPE	
25162753		6	.	B	B	B	.	.	A	&NN6/NN7		1				
[08]		(E)CLAMP (D)KLAMMER													(F)PINCE (S)ABRAZADERA	
09407-16401		6	.	B	B	B	.	.	O			1				
[09]		(E)BOLT (D)SCHRAUBE													(F)BOULON (S)PERNO	
96100183		6	.	B	B	B	.	.	O	&NN4		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


2450 VACUUM HOSE(SOHC)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)HOSE-VACUUM *(D)SCHLAUCH,VAKUUM*													*(F)TUYAU-DEPRESSION* *(S)MANGUERA-VACIO*	
		REFER GROUP 2210 KEY NO. 10														
[02]		(E)PIPE A-VACUUM *(D)ROHR,VAKUUM*													*(F)TUYAU-DEPRESSION* *(S)TUBERIA-VACIO*	
96239375		Y	.	B	B	B	S	S	S			1				
[03]		(E)TUBE A-PURGE,ENGINE *(D)ROHRLEITUNG*													*(F)TUYAU OU TUBE* *(S)TUBO*	
		REFER GROUP 2130 KEY NO. 15														
[04]		(E)HOSE-ENGINE VENTILATION *(D)SCHLAUCH,VENTILATOR*													*(F)TUYAU-VENTILATION* *(S)MANGUERA-VENTILACION*	
		REFER GROUP 2410 KEY NO. 22														
[05]		(E)HOSE-VACUUM *(D)SCHLAUCH,VAKUUM*													*(F)TUYAU-DEPRESSION* *(S)MANGUERA-VACIO*	
96304432		Y	.	B	B	B	S	S	S			1				
[06]		(E)VALVE-CHECK *(D)VENTIL,PRÜF*													*(F)SOUPAPE-SECURITE* *(S)VALVULA-PARADA*	
90193282		Y	.	B	B	B	S	S	S			1				
[07]		(E)CLIP *(D)KLEMME*													*(F)ATTACHE* *(S)GRAPA*	
09401-17402		Y	.	B	B	B	S	S	S			2				
[08]		(E)CLIP *(D)KLEMME*													*(F)ATTACHE* *(S)GRAPA*	
09401-15402		Y	.	B	B	B	S	S	S			2				
[09]		(E)PIPE A-VACUUM *(D)ROHR,VAKUUM*													*(F)TUYAU-DEPRESSION* *(S)TUBERIA-VACIO*	
		REFER GROUP 2430 KEY NO. 08														
[10]		(E)CAP *(D)DECKEL*													*(F)CHAPEAU* *(S)TAPA*	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

2450 VACUUM HOSE(SOHC)




KEY NO.	PART NAME													
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	08981899	Y	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]									(E)HOSE-VACUUM *(D)SCHLAUCH,VAKUUM*					*(F)TUYAU-DEPRESSION* *(S)MANGUERA-VACIO*	
										REFER GROUP 2211 KEY NO. 10						
	[02]									(E)PIPE A-VACUUM *(D)ROHR,VAKUUM*					*(F)TUYAU-DEPRESSION* *(S)TUBERIA-VACIO*	
	96239374	6	.	B	B	B	.	.	O			1				
	[03]									(E)TUBE-PURGE,ENGINE *(D)ROHRLEITUNG*					*(F)TUYAU OU TUBE* *(S)TUBO*	
										REFER GROUP 2130 KEY NO. 15						
	[04]									(E)HOSE-INTAKE,BREATHER *(D)SCHLAUCH*					*(F)TUYAU* *(S)MANGUERA*	
	96184788	6	.	B	B	B	.	.	O			1				
	[05]									(E)HOSE A-VACUUM *(D)SCHLAUCH,VAKUUM*					*(F)TUYAU-DEPRESSION* *(S)MANGUERA-VACIO*	
	96306170	6	.	B	B	B	.	.	O			1		971001		
	96306170	6	.	B	B	B	.	.	O	-KL9		1	971001			
O	96257689	6	.	B	B	B	.	.	O	&KL9		1	971001			
	[06]									(E)VALVE-CHECK *(D)VENTIL,PRÜF*					*(F)SOUPAPE-SECURITE* *(S)VALVULA-PARADA*	
	90193282	6	.	B	B	B	.	.	O			1				
	[07]									(E)CLIP *(D)KLEMME*					*(F)ATTACHE* *(S)GRAPA*	
	09401-17402	6	.	B	B	B	.	.	O			2				
	[08]									(E)CLIP *(D)KLEMME*					*(F)ATTACHE* *(S)GRAPA*	
	09401-15402	6	.	B	B	B	.	.	O			2				
	[09]									(E)SOLENOID A-VGIS *(D)SOLENOID*					*(F)SOLENOIDE* *(S)SELENOIDE*	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96184584	6	.	B	B	B	.	.	O		1 (F)SOUPAPE (S)VALVULA						
	[10]										(E)VALVE-SOLENOID (D)VENTIL						
	96350594	6	.	B	B	B	.	.	O		1 (F)RESERVOIR-DEPRESSION (S)TANQUE-VACIO						
	[11]										(E)TANK-VACUUM,VGIS (D)TANK,VAKUUM						
	96350595	6	.	B	B	B	.	.	O		1 (F)SUPPORT (S)SOPORTE						
	[12]										(E)BRACKET-VGIS (D)TRÄGER						
	96350597	6	.	B	B	B	.	.	O		1 (F)TUYAU-DEPRESSION (S)TUBERIA-VACIO						
	[13]										(E)PIPE A-VACUUM (D)ROHR,VAKUUM						
	96244912	6	.	B	B	B	.	.	O		1 (F)ECROU (S)TUERCA						
	[14]										(E)NUT-HEXAGON FLANGE (D)MUTTER						
	08316-25063	6	.	B	B	B	.	.	O		2 (F)TUYAU-DEPRESSION (S)TUBERIA-VACIO						
	[15]										(E)PIPE A-VACUUM (D)ROHR,VAKUUM						
	96239379	6	.	B	B	B	.	.	O		1 (F)ATTACHE (S)GRAPA						
	[16]										(E)CLIP (D)KLEMME						
	09408-00030	6	.	B	B	B	.	.	O		1 (F)ATTACHE (S)GRAPA						
	[17]										(E)CLIP (D)KLEMME						
	09408-00081	6	.	B	B	B	.	.	O		2 (F)CHAPEAU (S)TAPA						
	[18]										(E)CAP (D)DECKEL						
	90190478	6	.	B	B	B	.	.	O		1						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)GASKET-FRT EXHAUST PIPE (D)DICHTUNG									(F)JOINT (S)JUNTA-TUBERIA DE ESCAPE					
96184040		.	.	B	B	B	S	S	S			1				
[02]		(E)BOLT-STUD (D)STIFTSCHRAUBE									(F)BOULON-TETON (S)PERNO-ESPIGA					
09108-10003		.	.	B	B	B	S	S	S			3				
[03]		(E)NUT-HEXAGON LOCK (D)MUTTER									(F)ECROU (S)TUERCA					
08311-38102		.	.	B	B	B	S	S	S			13				
[04]		(E)BRACKET A-UPPER (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
96351913		.	.	B	B	B	S	S	S			1				
[05]		(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
09103-10050		.	.	B	B	B	S	S	S			2				
[06]		(E)BRACKET-LOWER (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
96351914	-	.	.	B	B	B	S	S	S			1				
[08]		(E)PIPE A-EXHAUST,FRONT (D)ROHR									(F)TUYAU (S)TUBERIA					
96182250		Y	M	B	B	B	S	S	S			1				TF
96352186		Y	A	B	B	B	O	O	O			1				TE
96352213		6	M	B	B	B	.	.	O			1				TG
96352215		6	A	B	B	B	.	.	O			1				TK
[09]		(E)CONVERTER A-CATALYTIC (D)KATALYSATOR									(F)CONVERTISSEUR-CATALYTIQUE (S)CONVERTIDOR-CATALITICO					
96350081		Y	.	B	B	B	A	A	A	&NN6		1				KO
96351364		6	.	B	B	B	.	.	A	&NN6		1				KH

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96350080	.	.	B	B	B	A	A	A	&NN7		1				EO
	[10]	(E)GASKET-CATALYTIC CONVERTER (D)DICHTUNG														
	96350814	.	..	B	B	B	S	S	S			2				
	[11]	(E)MUFFLER A-EXHAUST,FRONT (D)AUSPUFFTOPF,VORNE														
	96350723	.	.	B	B	B	S	S	S			1				TV
	[12]	(E)MUFFLER A-EXHAUST,REAR (D)AUSPUFFTOPF,HINTEN														
	96350734	.	.	B	.	.	S	S	S			1				TX
	96350703	.	.	.	B	B	S	.	S			1				TW
	[13]	(E)GASKET-REAR MUFFLER (D)DICHTUNG														
	96181581	.	.	B	B	B	S	S	S			1				
	[15]	(E)RUBBER-HANGER (D)GUMMI														
	96351529	.	.	B	B	B	S	S	S			2			NO. 1,3	
	[16]	(E)SHIELD-CATALYTIC CONV.PRO (D)SCHILD,KATALYSATOR														
	96184956	.	.	B	B	B	S	S	S			1				GC
	[17]	(E)NUT-LOCK (D)MUTTER														
	96351831	.	.	B	B	B	S	S	S			4				
	[18]	(E)SHIELD-FRT MUFFLER PROTV. (D)SCHILD,SCHALLDÄMPFER														
	96184957	.	.	B	B	B	S	S	S			1				GF
	[19]	(E)NUT-LOCK (D)MUTTER														

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96351831	.	.	B	B	B	S	S	S			4				
	[20]	(E)SHIELD-RR MUFFLER PROTV. (D)SCHILD,SCHALLDÄMPFER										(F)BOUCLIER-PROTECTION (S)ESCUDO-PROTECTOR				
	96350492	.	.	B	B	B	S	S	S			1				GR
	[21]	(E)NUT-LOCK (D)MUTTER										(F)ECROU (S)TUERCA				
	96351831	.	.	B	B	B	S	S	S			4				
	[22]	(E)RING-TRIM,EXHAUST (D)RING,AUSPUFF-VERZIERUNG										(F)ANNEAU (S)ANILLO-ADORNO				
	96180147	.	.	B	B	B	S	S	S			1				
	[23]	(E)RUBBER-HANGER (D)GUMMI										(F)CAOUTCHOUC (S)GOMA				
	96351183	.	.	B	B	B	S	S	S			2			NO. 2	
	[24]	(E)PIPE A-EXHAUST,CONNECTOR (D)ROHR										(F)TUYAU (S)TUBERIA				
	96351601	.	.	B	B	B	S	S	S	&NN4		1				
	[25]	(E)RUBBER-HANGER (D)GUMMI										(F)CAOUTCHOUC (S)GOMA				
	96181437	.	.	B	B	B	S	S	S			2			NO. 4,5	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1-GENERAL AREA @2-HIGH ALITUDE AREA
@3-LOW VOLATILITY AREA
@4-HOT AREA @5-COLD AREA

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)MODULE-ENGINE CONTROL (D)STEUERUNGS-EINHEIT									(F)UNITE DE CONTROLE (S)UNIDAD DE CONTROL					
	16245849	Y	M	B	B	B	S	S	S	&NN4-UM1		1			@1	JJ
	16249619	Y	M	B	B	B	A	A	A	&NN4&UM1		1			@1	JX
	16240269	Y	M	B	B	B	A	A	A	&NN6-UM1		1			@1	BB
	16269529	Y	M	B	B	B	A	A	A	&NN6&UM1		1			@1	PP
	16247139	Y	M	B	B	B	A	A	A	&NN7-UM1		1			@1	GC
	16247149	Y	M	B	B	B	A	A	A	&NN7&UM1		1			@1	CA
	16245859	Y	A	B	B	B	O	O	O	&NN4-UM1		1			@1	JL
	16249639	Y	A	B	B	B	A	A	A	&NN4&UM1		1			@1	JY
	16240279	Y	A	B	B	B	A	A	A	&NN6-UM1		1			@1	BD
	16269539	Y	A	B	B	B	A	A	A	&NN6&UM1		1			@1	PV
	16247159	Y	A	B	B	B	A	A	A	&NN7-UM1		1			@1	GD
	16247169	Y	A	B	B	B	A	A	A	&NN7&UM1		1			@1	CN
	16247079	Y	M	B	B	B	A	A	A	&NN4-UM1/VB4		1			@2	KD
	96257285	Y	M	B	B	B	A	A	A	&NN4&VB4-UM1		1			@2	GA
	16247089	Y	M	B	B	B	A	A	A	&NN4&UM1		1			@2	KL
	16245839	Y	M	B	B	B	A	A	A	&NN6-UM1		1			@2	HJ
	16247099	Y	A	B	B	B	A	A	A	&NN4-UM1/VB4		1			@2	KF
	96257286	Y	A	B	B	B	A	A	A	&NN4&VB4-UM1		1			@2	GB
	16247109	Y	A	B	B	B	A	A	A	&NN4&UM1		1			@2	KM
	16246579	Y	A	B	B	B	A	A	A	&NN6-UM1		1			@2	HN
	16245869	Y	M	B	B	B	A	A	A	&NN6-UM1		1			@3	HY
	16245879	Y	A	B	B	B	A	A	A	&NN6-UM1		1			@3	HZ


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1-GENERAL AREA @2-HIGH ALITUDE AREA
@3-LOW VOLATILITY AREA
@4-HOT AREA @5-COLD AREA

KEY NO.		PART NAME												
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO	
	16247119	Y	M	B	B	B	A	A	A	&NN4-UM1/VB4		1			@4	KV
	96257287	Y	M	B	B	B	A	A	A	&NN4&VB4-UM1		1			@4	GG
	16247179	Y	M	B	B	B	A	A	A	&NN7-UM1		1			@4	JC
	16269499	Y	M	B	B	B	A	A	A	&NN7&EC2&UM1		1			@4	PW
	16247129	Y	A	B	B	B	A	A	A	&NN4-UM1/VB4		1			@4	KW
	96257288	Y	A	B	B	B	A	A	A	&NN4&VB4-UM1		1			@4	GH
	16247199	Y	A	B	B	B	A	A	A	&NN7-UM1		1			@4	JD
	16269509	Y	A	B	B	B	A	A	A	&NN7&EC2&UM1		1			@4	PX
	16247059	Y	M	B	B	B	A	A	A	&NN4-UM1		1			@5	JZ
	16247069	Y	A	B	B	B	A	A	A	&NN4-UM1		1			@5	KC
	16246179	6	M	B	B	B	.	.	O	&NN4-UM1		1			@1	MV
	16249689	6	M	B	B	B	.	.	A	&NN4&UM1		1			@1	MX
	16246159	6	M	B	B	B	.	.	A	&NN6-UM1		1			@1	GF
	16246159	6	M	B	B	B	.	.	A	&NN7-UM1		1			@1	GF
	16246939	6	M	B	B	B	.	.	A	&NN7&UM1		1			@1	CQ
	16246189	6	A	B	B	B	.	.	O	&NN4-UM1		1			@1	MW
	16249699	6	A	B	B	B	.	.	A	&NN4&UM1		1			@1	MY
	16246169	6	A	B	B	B	.	.	A	&NN6-UM1		1			@1	GJ
	16246169	6	A	B	B	B	.	.	A	&NN7-UM1		1			@1	GJ
	16246899	6	A	B	B	B	.	.	A	&NN7&UM1		1			@1	CS
	16249729	6	M	B	B	B	.	.	A	&NN4-UM1/VB4		1			@2	NH
	16269989	6	M	B	B	B	.	.	A	&NN4VB4-UM1		1			@2	GM
	16249749	6	M	B	B	B	.	.	A	&NN4&UM1		1			@2	NZ
	16249649	6	M	B	B	B	.	.	A	&NN7-UM1		1			@2	KX


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1-GENERAL AREA @2-HIGH ALITUDE AREA
@3-LOW VOLATILITY AREA
@4-HOT AREA @5-COLD AREA

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	16249739	6	A	B	B	B	.	.	A	&NN4-UM1/VB4		1			@2	NN
	16269999	6	A	B	B	B	.	.	A	&NN4VB4-UM1		1			@2	GP
	16249759	6	A	B	B	B	.	.	A	&NN4&UM1		1			@2	PC
	16249659	6	A	B	B	B	.	.	A	&NN7-UM1		1			@2	KY
	16249669	6	M	B	B	B	.	.	A	&NN7-UM1		1			@3	KZ
	16249679	6	A	B	B	B	.	.	A	&NN7-UM1		1			@3	MM
	16249769	6	M	B	B	B	.	.	A	&NN4-UM1/VB4		1			@4	PD
	09350009	6	M	B	B	B	.	.	A	&NN4&VB4-UM1		1			@4	GQ
	16269549	6	M	B	B	B	.	.	A	&NN4&UM1		1			@4	QA
	16246199	6	M	B	B	B	.	.	A	&NN7-UM1		1			@4	MN
	16269599	6	M	B	B	B	.	.	A	&NN7&EC2&UM1		1			@4	PY
	16249779	6	A	B	B	B	.	.	A	&NN4-UM1/VB4		1			@4	PE
	09350019	6	A	B	B	B	.	.	A	&NN4&VB4-UM1		1			@4	GR
	16269559	6	A	B	B	B	.	.	A	&NN4&UM1		1			@4	QD
	16246209	6	A	B	B	B	.	.	A	&NN7-UM1		1			@4	MR
	16269609	6	A	B	B	B	.	.	A	&NN7&EC2&UM1		1			@4	PZ
	16249709	6	M	B	B	B	.	.	A	&NN4-UM1		1			@5	MZ
	16249719	6	A	B	B	B	.	.	A	&NN4-UM1		1			@5	NF
	16269579	6	M	B	B	B	.	.	A	&KL9		1			FOR BRAZIL	MS
	16269589	6	A	B	B	B	.	.	A	&KL9		1			FOR BRAZIL	MT
[02]		(E)MODULE-TRANSAXLE CONTROL *(D)MODUL*										*(F)MODULE* *(S)MODULO*				
	16245799	Y	A	B	B	B	O	O	O			1	970714			WK
O	16265669	Y	A	B	B	B	O	O	O			1	970714			XY


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1-GENERAL AREA @2-HIGH ALITUDE AREA
@3-LOW VOLATILITY AREA
@4-HOT AREA @5-COLD AREA

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	16245779	6	A	B	B	B	.	.	O			1				WM
	[13]	(E)SENSOR A-M.A.P. (D)SENSOR,VAKUUM														
	1613/039	.	.	B	B	B	S	S	S			1				
	[04]	(E)BRACKET-M.A.P. SENSOR (D)TRÄGER,VAKUUM														
	96351294	.	.	B	B	B	S	S	S			1				
	[05]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														
	01517-06305	.	.	B	B	B	S	S	S			2				
	[06]	(E)NUT-HEXAGON FLANGE (D)MUTTER														
	08316-25065	.	.	B	B	B	S	S	S			2				
	[07]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														
	01114-06125	.	.	B	B	B	S	S	S			1				
	[08]	(E)SENSOR A-DISTANCE (D)SENSOR,ENTFERNUNG														
	96190708	.	M	B	B	B	S	S	S			1				T6
	[09]	(E)CONTROL UNIT-IMMOBILIZER (D)STEUERUNGS-EINHEIT														
	96303500	.	.	B	B	B	A	A	A	&UM1		1				
	[10]	(E)POTENTIOMETER-CO (D)POTENTIOMETER														
	90306761	.	.	B	B	B	S	S	S	&NN4		1				
	[11]	(E)CAP-ANTI TAMPER (D)DECKEL														
	90243777	.	.	B	B	B	S	S	S	&NN4		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




NOTE : @1-GENERAL AREA @2-HIGH ALITUDE AREA
@3-LOW VOLATILITY AREA
@4-HOT AREA @5-COLD AREA

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[12]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03152-63163	.	.	B	B	B	S	S	S	&NN4		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)BRACKET-ENG&T.M CONT. (D)TRÄGER,STEUERUNGSEINHEIT									(F)SUPPORT-UNITE DE CONTROLE (S)SOPORTE-UNIDA DE CONTROL					
	96231066	.	M	B	B	B	S	S	S		1					BA
	[02]	(E)COVER-ECM&TCM (D)DECKEL									(F)CARTER (S)CUBIERTA					
	96242607	.	M	B	B	B	S	S	S		1					CE
	[03]	(E)BRACKET-ENGINE CONT.MODULE (D)TRÄGER,STEUERUNGSEINHEIT									(F)SUPPORT-UNITE DE CONTROLE (S)SOPORTE-UNIDA DE CONTROL					
	96232067	.	A	B	B	B	O	O	O		1					BB
	[04]	(E)BRACKET-TCM (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96304683	.	A	B	B	B	O	O	O		1					BM
	[05]	(E)COVER-TCM (D)DECKEL									(F)CARTER (S)CUBIERTA					
	96242608	.	A	B	B	B	O	O	O		1					CT
	[06]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-06002	.	.	B	B	B	S	S	S		4					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

3 CLUTCH&TRANSAXLE


3110 CLUTCH COVER&DISK
3120 HYDRAULIC CLUTCH
3130 CLUTCH PEDAL
3210 MANUAL TRANSAXLE
3220 TRANSAXLE RELATED PARTS
3230 TRANSAXLE GEAR
3240 REVERSE&COUNTER GEAR
3250 BEARING PLATE
3260 GEAR SHIFT COVER&FORK
3270 DIFFERENTIAL GEAR
3510 AUTOMATIC TRANSAXLE
3520 CASE AND RELATED PARTS
3521 INTERNAL POWER TRAIN PARTS
3530 REVERSE INPUT CLUTCH ASSEMBLY
3531 DIRECT AND COAST CLUTCH ASSEMBLIES
3533 FORWARD CLUTCH ASSEMBLY
3535 FORWARD CLUTCH SUPPORT ASSEMBLY
3550 DRIVEN SPROCKET SUPPORT ASSEMBLY
3570 PARK LOCK AND DETENT LEVER
3910 SHIFT CONTROL(M/T)
3920 SHIFT CONTROL(A/T)



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)DISK-CLUTCH *(D)SCHEIBE,KUPPLUNG*										*(F)DISQUE-EMBRAYAGE* *(S)DISCO-EMBRAGUE*				
	96232994	Y	M	B	B	B	S	S	S			1				F1
	96232995	6	M	B	B	B	.	.	O			1				
	[02]	(E)COVER-CLUTCH *(D)DECKEL,KUPPLUNG*										*(F)CARTER-EMBRAYAGE* *(S)CUBIERTA-EMBRAGUE*				
	96183980	Y	M	B	B	B	S	S	S			1				CL
	96184505	6	M	B	B	B	.	.	O			1			POT	
	[03]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09100-07001	.	M	B	B	B	S	S	S			6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

BRAKE RESERVOIR




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]										(E)HOSE A-RESERVOIR TANK (D)SCHLAUCH,BEHÄLTER						
	96184064	.	M	B	B	B	S	S	S				1			INCL #2	
	[02]										(E)CLIP (D)KLEMME						
	09401-13401	.	M	B	B	B	S	S	S				2				
	[03]										(E)CYLINDER A-CLUTCH MASTER (D)ZYLINDER,HAUPT						
	96184062	.	M	B	B	B	S	S	S				1				
	[04]										(E)NUT-HEXAGON LOCK (D)MUTTER						
	08311-18083	.	M	B	B	B	S	S	S				2				
	[05]										(E)GASKET (D)DICHTUNG						
	96184061	.	M	B	B	B	S	S	S				1				
	[06]										(E)PIPE A-CLUTCH MASTER CYL (D)ROHR,HYDRAULIK KUPPLUNG						
	96233023	.	M	B	B	B	S	S	S				1				
	[07]										(E)CLIP (D)KLEMME						
	96180752	.	M	B	B	B	S	S	S				1				
	[08]										(E)CLIP (D)KLEMME						
	96144733	.	M	B	B	B	S	S	S				1				
	[09]										(E)HOSE A-HYDRAULIC CLUTCH (D)SCHLAUCH						
	96184536	.	M	B	B	B	S	S	S				1				
	[10]										(E)BOLT-UNION (D)SCHRAUBE						

(F)TUYAU-RESERVOIR
(S)MANGUERA-RESERVA
(F)ATTACHE
(S)GRAPA
(F)CYLINDRE-MAITRE
(S)CILINDRO-MAESTRO
(F)ECROU
(S)TUERCA
(F)JOINT
(S)JUNTA
(F)TUYAU
(S)TUBERIA
(F)ATTACHE
(S)GRAPA
(F)ATTACHE
(S)GRAPA
(F)TUYAU
(S)MANGUERA
(F)BOULON
(S)PERNO

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


BRAKE RESERVOIR



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09360-10001	.	M	B	B	B	S	S	S			1				
	[11]	(E)CYLINDER A-CLUTCH RELEASE *(D)ZYLINDER LÖSUNG*										*(F)CYLINDRE-RELACHE* *(S)CILINDRO-LIBERAR*				
	96159109	.	M	B	B	B	S	S	S			1	970701			
Y	96104047	.	M	B	B	B	S	S	S			1	970701			
	[12]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09106-08001	.	M	B	B	B	S	S	S			2				
	[13]	(E)BRACKET-RELEASE CYLINDER *(D)TRÄGER*										*(F)SUPPORT* *(S)SOPORTE*				
	96243477	.	M	B	B	B	S	S	S			1				
	[15]	(E)BOLT-HEXAGON *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09100-12001	.	M	B	B	B	S	S	S			1				
	[16]	(E)WASHER-SPRING *(D)DICHTUNGSRING*										*(F)RONDELLE* *(S)ARANDELA*				
	08321-31123	.	M	B	B	B	S	S	S			1				
	[17]	(E)WASHER-PLAIN *(D)DICHTUNGSRING*										*(F)RONDELLE* *(S)ARANDELA*				
	08322-11123	.	M	B	B	B	S	S	S			1				
	[18]	(E)NUT-HEXAGON LOCK *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	08311-18123	.	M	B	B	B	S	S	S			1				
	[19]	(E)WASHER-PLAIN *(D)DICHTUNGSRING*										*(F)RONDELLE* *(S)ARANDELA*				
	09160-10002	.	M	B	B	B	S	S	S			2				
	[20]	(E)CLAMP-CLUTCH HOSE *(D)KLAMMER*										*(F)PINCE* *(S)ABRAZADERA*				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


BRAKE RESERVOIR



ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	9618454	.	M	B	B	B	S	S	S			1				
	[21]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	01514-06123	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


3130 CLUTCH PEDAL



KEY NO.	PART NAME														
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PEDAL A-CLUTCH (D)PEDAL,KUPPLUNG													(F)PEDALE-EMBRAYAGE (S)PEDAL-EMBRAGUE	
	96183919	.	M	B	B	B	S	S	S			1				
	[02]	(E)COVER-PEDAL PLATE (D)UNTERLAGE													(F)PATIN (S)COJIN	
	90105172	.	M	B	B	B	S	S	S			1				
	[03]	(E)SHAFT-CLUTCH PEDAL (D)SPINDEL,PEDAL MONTAGE													(F)ARBRE-MONTAGE PEDALE (S)EJE-MONTAJE DE PEDAL	
	96183932	.	M	B	B	B	S	S	S			1				
	[04]	(E)BUSHING (D)LAGERFUTTER													(F)MANCHON (S)BUJE-PEDAL DEL EMBRAGUE	
	09306-14001	.	M	B	B	B	S	S	S			2				
	[05]	(E)NUT (D)MUTTER													(F)ECROU (S)TUERCA	
	09159-10002	.	M	B	B	B	S	S	S			1				
	[06]	(E)WASHER-SPRING (D)DICHTUNGSRING													(F)RONDELLE (S)ARANDELA	
	08321-31103	.	M	B	B	B	S	S	S			1				
	[07]	(E)NUT-HEXAGON LOCK (D)MUTTER													(F)ECROU (S)TUERCA	
	09159-08003	.	M	B	B	B	S	S	S			5				
	[08]	(E)BUFFER-CLUTCH PEDAL (D)STOßSCHEIBE													(F)TAMPON-PEDALE D'EMBRAYAGE (S)AMORTIGUADOR	
	96157634	.	M	B	B	B	S	S	S			2				
	[09]	(E)NUT-HEXAGON (D)MUTTER													(F)ECROU (S)TUERCA	
	08310-22083	.	M	B	B	B	S	S	S			1				
	[10]	(E)BOLT-HEXAGON (D)SCHRAUBE													(F)BOULON (S)PERNO	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

3130 CLUTCH PEDAL




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	01107-08303	.	M	B	B	B	S	S	S			1				
	[11]	(E)SPRING-TURN OVER (D)FEDERUNG,RÜCK													(F)RESSORT-RETOUR (S)RESORTE-REGRESO	
	96184060	.	M	B	B	B	S	S	S			1				
	96305924														NOT APPLIED	
	[12]	(E)BUSHING (D)LAGERFUTTER													(F)MANCHON (S)BUJE-PEDAL DEL EMBRAGUE	
	09306-10003	.	M	B	B	B	S	S	S			1				
	[13]	(E)RING-RETAINING,E TYPE (D)RING,HALTER													(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR	
	08332-21089	.	M	B	B	B	S	S	S			1				
	[14]	(E)PIN (D)STIFT													(F)BROCHE (S)PASADOR	
	09208-10001	.	M	B	B	B	S	S	S			1				
	[15]	(E)BRACE A-CLUTCH PEDAL (D)SCHIENE,KUPPLUNGSPEDAL													(F)SUPPORT-MONTAGE PEDALE (S)REFUERZO	
	96183927	.	M	B	B	B	S	S	S			1				
	[16]	(E)BRACKET-CLUTCH PEDAL BRACE (D)TRÄGER													(F)SUPPORT (S)SOPORTE	
	96183935	.	M	B	B	B	S	S	S			1				
	[17]	(E)NUT-HEXAGON LOCK (D)MUTTER													(F)ECROU (S)TUERCA	
	08311-18083	.	M	B	B	B	S	S	S			1				
	[18]	(E)WASHER-PLAIN (D)DICHTUNGSRING													(F)RONDELLE (S)ARANDELA	
	09160-08004	.	M	B	B	B	S	S	S			1				
	[19]	(E)BUSHING (D)LAGERFUTTER													(F)MANCHON (S)BUJE DE BOQUILLA	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	96184537	.	M	B	B	B	S	S	S			2				
	[20]	(E)BUSHING (D)LAGERFUTTER										(F)MANCHON (S)BUJE DE BOQUILLA				
	96184050	.	M	B	B	B	S	S	S			1				
	[21]	(E)PEDAL UNIT-CLUTCH (D)PEDAL,KUPPLUNG										(F)UNITE PEDALE-EMBRAYAGE (S)PEDAL UNIDAD -EMBRAGUE				
	96184054	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)TRANSAXLE A-GEARSHIFT (D)ANTRIEB,GANGSCHALTUNG									(F)TRANSMISSION (S)EJE TRANSVERSAL					
[01]	96243097	Y	M	B	B	B	S	S	S	&M85		1			RATIO : 4.176	MA
	96225023	6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1			RATIO : 3.722	BS
	96243097	6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				MA
[02]		(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	09100-12002	.	M	B	B	B	S	S	S			6				
[03]		(E)BRACKET-ENGINE CONT.HARNESS (D)TRÄGER										(F)SUPPORT (S)SOPORTE				
	96234614	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
																	(E)CASE A-TRANSAXLE (D)KASTEN,ANTRIEB (F)CARTER-TRANSMISSION (S)CAJA-EJE TRANSVERSAL
[01]	A96216453	.	M	B	B	B	S	S	S			1					
[02]	90147339	.	M	B	B	B	S	S	S			1					(E)PIN-DOWEL (D)STIFT,DÜBEL (F)BROCHE-GOUJON (S)PASADOR-CLAVIJA
[03]	90065583	.	M	B	B	B	S	S	S			2					(E)SLEEVE-MAINSHAFT OIL DUCT (D)HÜLSE (F)CHEMISE (S)MANGA
[04]	90121130	.	M	B	B	B	S	S	S			1					(E)BUSHING-CLUTCH SHAFT (D)LAGERFUTTER (F)MANCHON-ARBRE D'EMBRAYAGE (S)BUJE-EJE DEL EMBRAGUE
[05]	90305912	.	M	B	B	B	S	S	S			2					(E)COVER-DIFFERENTIAL GEAR (D)DECKEL (F)CARTER (S)CUBIERTA
[08]	90305635	.	M	B	B	B	S	S	S			1					(E)GASKET-DIFF GEAR COVER (D)DICHTUNG (F)JOINT (S)JUNTA
[09]	96179241	.	M	B	B	B	S	S	S			1					(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO
[10]	09103-08028	.	M	B	B	B	S	S	S			10					(E)COVER-TRANSMISSION CASE (D)DECKEL (F)CARTER (S)CUBIERTA
[11]	96224697	.	M	B	B	B	S	S	S	&NN4/NN6		1		970701			
O	96242579	.	M	B	B	B	S	S	S	&NN4/NN6		1	970701		FOR STEEL OIL PAN		

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[12]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09103-10046	.	M	B	B	B	S	S	S	&NN4/NN6		3			FOR STEEL OIL PAN	
	[13]	(E)RING-SHAFT SEAL (D)RING,STAB DICHTUNG									(F)ANNEAU-JOINT D'ARBRE (S)ANILLO-BROCHE DE EJE					
	90182168	.	M	B	B	B	S	S	S			1			23X35X8	
	[14]	(E)O RING (D)O RING									(F)JOINT TORIQUE (S)ANILLO EN O					
	90112258	.	M	B	B	B	S	S	S			1			50.5X2.2	
	[15]	(E)GUIDE-THRUST BEARING (D)FÜHRING,STOß LAGER									(F)GUIDE-ROULEMENT DE BUTEE (S)GUIA-COJINETE DE EMPUJE					
	90112325	.	M	B	B	B	S	S	S			1				
	[16]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09100-06004	.	M	B	B	B	S	S	S			3				
	[17]	(E)BEARING-CLUTCH THRUST (D)KUGELLAGER,KUPPLUNG SCHUB									(F)ROULEMENT (S)COJINETE-EMPUJAR EMBRAGUE					
	90251210	.	M	B	B	B	S	S	S			1				
	[18]	(E)FORK-CLUTCH RELEASE (D)GABEL,KUPPLUNG LÖSUNG									(F)FOURCHETTE (S)HORQUILLA-LIBERACION					
	90372766	.	M	B	B	B	S	S	S			1				
	[19]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09100-08020	.	M	B	B	B	S	S	S			1				
	[20]	(E)LEVER-RELEASE (D)HEBEL,LÖSUNG									(F)LEVIER-RELACHE (S)PALANCA-SOLTAR (LIBERAR)					
	96144874	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[22]	(E)PLUG-SCREW (D)STÖPSEL,SCHRAUBEN									(F)BOUCHON-VIS (S)TAPON-TORNILLO					
	09246-18003	.	M	B	B	B	S	S	S			1				
	[23]	(E)MAGNET (D)MAGNET									(F)AIMANT (S)IMAN					
	03449250	.	M	B	B	B	S	S	S			1				
	[24]	(E)GEAR A-DRIVEN WORM (D)GETRIEBE									(F)ENGRENAGE (S)ENGRANAJE-SINFIN					
	90375764	.	M	B	B	B	S	S	S			1				
	[25]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09100-06003	.	M	B	B	B	S	S	S			1				
	[26]	(E)O RING (D)O RING									(F)JOINT TORIQUE (S)ANILLO EN O					
	09280-17001	.	M	B	B	B	S	S	S			1				
	[27]	(E)SWITCH A-BACK UP LIGHT (D)SCHALTER,RÜCKGANGS-LAMPE									(F)COMMUTATEUR (S)INTERRUPTOR					
	96192077	.	M	B	B	B	S	S	S			1				
	[28]	(E)WASHER-PLAIN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	09160-12003	.	M	B	B	B	S	S	S			1				
	[29]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09103-10009	.	M	B	B	B	A	A	A	&NN7		3				
	[30]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09103-10032	.	M	B	B	B	A	A	A	&NN7		1				
	[31]	(E)GROMMET-OIL PAN,BOLT (D)ÖSE									(F)VIROLE (S)AISLANTE					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)BEARING-ROLLER (D)ROLLENLAGER									(F)ROULEMENT-ROULEAU (S)COJINETE-RUEDECILLA					
90373802		.	M	B	B	B	S	S	S			1			42X72X18	
[02]		(E)SHAFT A-TRANSAXLE MAIN (D)SPINDEL,HAUPT,ANTRIEB									(F)ARBRE-PRINCIPAL (S)EJE-PRINCIPAL					
A96242687		Y	M	B	B	B	S	S	S	&M85		1			RATIO : 4.176	
A90373002		6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1			RATIO : 3.722	
A96242687		6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				
[03]		(E)WASHER-MAIN SHAFT THRUST (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
90199104		.	M	B	B	B	S	S	S			2				
[04]		(E)RING-WASHER RETAINING (D)RING,DICHTUNG HALTER									(F)ANNEAU (S)ANILLO					
90112228		.	M	B	B	B	S	S	S			1				
[05]		(E)GEAR A-4TH SPEED (D)GETRIEBE,4.GANG									(F)ENGRENAGE-4EME VITESSE (S)ENGRANAJE-4TA VELOCIDAD					
A96237744		Y	M	B	B-	B	S	S	S	&M85		1				
A96180759		6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1				
A96237744		6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				
[06]		(E)CAGE-NEEDLE (D)KÄFIG NADEL									(F)CAGE-AIGUILLE (S)JAULA-AGUJA					
90147685		.	M	B	B	B	S	S	S			2			38X42X24	
[07]		(E)RING-SYNCHRONIZING (D)RING,SYNCHRONISIERUNGS									(F)ANNEAU-SYNCHRONISATION (S)ANILLO-SINCRONIZADOR					
90304685		.	M	B	B	B	S	S	S			2				
[08]		(E)SLEEVE A-SHIFT (D)HÜLSE,5.GANG-SCHALTUNG									(F)CHEMISE-CHANGEMENT (S)MANGA-CAMBIO					
A90236634		.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[09]	(E)GEAR-CLUTCH *(D)GETRIEBE,KUPPLUNG*													*(F)ENGRENAGE-EMBRAYAGE* *(S)ENGRANAJE-EMBRAGUE*	
N/S(8)																
	[10]	(E)RING-RETAINING *(D)RING,HALTER*													*(F)ANNEAU-DE RETENTION* *(S)ANILLO-RETENEDOR*	
N/S(8)																
	[11]	(E)KEY-SYNCHRONIZER *(D)SCHLÜßEL,SYNCHRONISATOR*													*(F)CLE-SYNCHRONISATEUR* *(S)LLAVE-SINCRONIZADOR*	
90199973		.	M	B	B	B	S	S	S			3				
	[12]	(E)SPRING-3&4TH SYNCHRONIZER *(D)FEDERUNG,SYNCHRONISATOR*													*(F)RESSORT* *(S)RESORTE-SINCRONIZADOR 3/4*	
90250023		.	M	B	B	B	S	S	S			2				
	[13]	(E)WASHER-PLAIN *(D)DICHTUNGSRING*													*(F)RONDELLE* *(S)ARANDELA*	
09160-38001		.	M	B	B	B	S	S	S			1				
	[14]	(E)CIRCLIP *(D)RUND-KLEMME*													*(F)CIRCLIP* *(S)GRAPA CIRCULAR*	
90373021		.	M	B	B	B	S	S	S			1				
	[16]	(E)GEAR A-3RD SPEED *(D)GETRIEBE,3.GANG*													*(F)ENGRENAGE-3EME VITESSE* *(S)ENGRANAJE-3RA VELOCIDAD*	
A96237742		Y	M	B	B	B	S	S	S	&M85		1				
A96180757		6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1				
A96237742		6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				
	[17]	(E)WASHER-MAIN SHAFT THRUST *(D)DICHTUNGSRING*													*(F)RONDELLE* *(S)ARANDELA*	
90199644		.	M	B	B	B	S	S	S			2				
	[18]	(E)RING-WASHER RETAINING *(D)RING,DICHTUNG HALTER*													*(F)ANNEAU* *(S)ANILLO*	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	90112228	.	M	B	B	B	S	S	S			1				
	[19]	(E)GEAR A-2ND SPEED *(D)GETRIEBE,2.GANG*										*(F)ENGRENAGE-2EME VITESSE* *(S)ENGRANAJE-2DA VELOCIDAD*				
	A96237740	Y	M	B	B	B	S	S	S	&M85		1				
	A90236632	6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1				
	A96237740	6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				
	[20]	(E)CAGE-NEEDLE *(D)KÄFIG NADEL*										*(F)CAGE-AIGUILLE* *(S)JAULA-AGUJA*				
	90373750	.	M	B	B	B	S	S	S			1			38X42X28	
	[21]	(E)RING-INSIDE SYNCHRONIZER *(D)RING,3 KEGEL ZWSCHEN*										*(F)ANNEAU* *(S)ANILLO-INTERMEDIO*				
	90305938	.	M	B	B	B	S	S	S			2				
	[22]	(E)RING-3 CONE INTERMEDIATE *(D)RING,3 KEGEL ZWSCHEN*										*(F)ANNEAU* *(S)ANILLO-INTERMEDIO*				
	90250034	.	M	B	B	B	S	S	S			2				
	[23]	(E)RING-OUTSIDE SYNCHRONIZER *(D)RING,SYNCHRONISATOR*										*(F)ANNEAU* *(S)ANILLO-SINCRONIZADOR*				
	90305939	.	M	B	B	B	S	S	S			2				
	[24]	(E)GEAR A-SLIDING *(D)GETRIEBE*										*(F)ENGRENAGE-GLISSANT* *(S)ENGRANAJE-DESLIZADO*				
	A90236633	.	M	B	B	B	S	S	S			1				
	[25]	(E)PIECE-GUIDE 1ST&2ND SPEED *(D)TEIL,FÜHRUNGS*										*(F)PIECE-GUIDE* *(S)PIEZA-GUIA*				
	N/S(24)															
	[26]	(E)GEAR-SLIDING TO REVERSE *(D)GLEITGETRIEBE,RÜCKWÄRTS*										*(F)ENGRENAGE* *(S)ENGRANAJE*				
	N/S(24)															

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME														
ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[27]	(E)KEY-1ST&2ND SYNCHRONIZER (D)SCHLÜßEL,SYNCHRONISATOR											(F)CLE-SYNCHRONISATEUR (S)LLAVE-SINCRONIZADOR			
	90199019	.	M	B	B	B	S	S	S			3				
	[28]	(E)SPRING-1ST&2ND SYNCHRON (D)FEDERUNG,SYNCHRONISATOR											(F)RESSORT (S)RESORTE			
	90250029	.	M	B	B	B	S	S	S			2				
	[29]	(E)WASHER-PLAIN (D)DICHTUNGSRING											(F)RONDELLE (S)ARANDELA			
	09160-33007	.	M	B	B	B	S	S	S			1				
	[30]	(E)CIRCLIP (D)RUND-KLEMME											(F)CIRCLIP (S)GRAPA CIRCULAR			
	90142582	.	M	B	B	B	S	S	S			1				
	[31]	(E)GEAR A-1ST SPEED (D)GETRIEBE,1.GANG											(F)ENGRENAGE-1ERE VITESSE (S)ENGRANAJE-1RA VELOCIDAD			
	90334381	.	M	B	B	B	S	S	S			1				
	[32]	(E)CAGE-NEEDLE (D)KÄFIG NADEL											(F)CAGE-AIGUILLE (S)JAULA-AGUJA			
	90373752	.	M	B	B	B	S	S	S			1			33X37X26	
	[33]	(E)CAGE-NEEDLE (D)KÄFIG NADEL											(F)CAGE-AIGUILLE (S)JAULA-AGUJA			
	90373751	.	M	B	B	B	S	S	S			1			33X52X2	
	[34]	(E)DISK-MAINSHAFT (D)SCHEIBE,HAUPTSTANGE											(F)DISQUE (S)DISCO-EJE PRINCIPAL			
	90142561	.	M	B	B	B	S	S	S			1				
	[35]	(E)RING-RETAINING (D)RING,HALTER											(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR			
	90373019	.	M	B	B	B	S	S	S			1				
	[36]	(E)BEARING-GROOVE BALL (D)KUGELLAGER											(F)ROULEMENT-BILLE A SILLONS (S)COJINETE-BOLA DE RANURA			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME																	
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	96108006	.	M	B	B	B	S	S	S			1				
	[37]	(E)WASHER-MAIN SHAFT THRUST (D)DICHTUNGSRING														
	90223614	.	M	B	B	B	S	S	S			2				
	[38]	(E)RING-RETAINING (D)RING,HALTER														
	90142139	.	M	B	B	B	S	S	S			1				
	[39]	(E)GEAR A-5TH SPD TRANSAXLE (D)GETRIEBE,5.GANG ANTRIEB														
	A96237746	Y	M	B	B	B	S	S	S	&M85		1				
	90334395	6	M	B	B	B	.	.	O	&MG4		1		970303		
Y	A90334396	6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1	970303			
	A96237746	6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				
	[40]	(E)CAGE-NEEDLE (D)KÄFIG NADEL														
	90373748	.	M	B	B	B	S	S	S			1				
	[41]	(E)RING-SYNCHRONIZING (D)RING,SYNCHRONISIERUNGS														
	90304686	.	M	B	B	B	S	S	S			1				
	[42]	(E)SLEEVE A-5TH SPEED SHIFT (D)HÜLSE														
	A90142140	.	M	B	B	B	S	S	S			1				
	[43]	(E)SLEEVE-SHIFT (D)HÜLSE														
	N/S(42)															
	[45]	(E)KEY-5TH SPD SYNCHRONIZER (D)SCHLÜßEL,SYNCHRONISATOR														
	90142143	.	M	B	B	B	S	S	S			3				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[46]		(E)SPRING-5TH SPD SYNCHRONIZ *(D)FEDERUNG,5.GANG SYNCHRO*													*(F)RESSORT-5EME VIT SYNCHRO* *(S)RESORTE*	
90157546		.	M	B	B	B	S	S	S			1				
[47]		(E)RING-RETAINING *(D)RING,HALTER*													*(F)ANNEAU-DE RETENTION* *(S)ANILLO-RETENEDOR*	
90373017		.	M	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4J05




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[09]		(E)RING-RETAINING (D)RING,HALTER													(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR	
	90373018	.	M	B	B	B	S	S	S			1				
[10]		(E)WASHER-PLAIN (D)DICHTUNGSRING													(F)RONDELLE (S)ARANDELA	
	09160-16002	.	M	B	B	B	S	S	S			1				
[11]		(E)GEAR A-REVERSE IDLER (D)GETRIEBE,LEERLAUF													(F)ENGRENAGE (S)ENGRANAJE-OCIOSO	
	A96161880	.	M	B	B	B	S	S	S			1				
[12]		(E)SHAFT-REVERSE GEAR (D)SPINDEL													(F)ARBRE (S)EJE	
	90182850	.	M	B	B	B	S	S	S			1				
[13]		(E)BALL (D)KUGEL													(F)BOULE (S)BOLA	
	06111-05004	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)BRIDGE-STRAIN BOLT (D)BRÜCKEN-SPANNUNGSSCHRAUBE													(F)PONT-BOULON DE TAMIS (S)PUENTE-PERNO DE TENSION	
	90147084	.	M	B	B	B	S	S	S			1				
[02]		(E)BOLT (D)SCHRAUBE													(F)BOULON (S)PERNO	
	09106-06003	.	M	B	B	B	S	S	S			2				
[03]		(E)BOLT (D)SCHRAUBE													(F)BOULON (S)PERNO	
	09106-06004	.	M	B	B	B	S	S	S			2				
[04]		(E)BOLT-GEARSHIFT STRAIN ROD (D)SCHRAUBE													(F)BOULON (S)PERNO	
	90086156	.	M	B	B	B	S	S	S			1				
[05]		(E)PLATE-BEARING (D)PLATTE,LAGER													(F)PLAQUE-ROULEMENT (S)PLACA-COJINETE	
	96180859	.	M	B	B	B	S	S	S			1				
[06]		(E)BOLT-GEARSHIFT STRAIN ROD (D)SCHRAUBE													(F)BOULON (S)PERNO	
	90032052	.	M	B	B	B	S	S	S			1				
[07]		(E)PIN-DOWEL (D)STIFT,DÜBEL													(F)BROCHE-GOUJON (S)PASADOR-CLAVIJA	
	11053109	.	M	B	B	B	S	S	S			2				
[08]		(E)PIN-BLOCKING (D)STIFT,BLOCKIER													(F)BROCHE-DE BLOCAGE (S)PASADOR-BLOQUEADOR	
	90189977	.	M	B	B	B	S	S	S			1				
[09]		(E)SPRING-COMPRESSION (D)FEDERUNG,VERDICHTUNG													(F)RESSORT-COMPRESSION (S)RESORTE-COMPRESION	
	90125326	.	M	B	B	B	S	S	S			1				
[10]		(E)PLUG (D)STÖPSEL													(F)BOUCHON (S)TAPON	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	90092564	.	M	B	B	B	S	S	S			1				
	[11]	(E)FORK A-GEARSHIFT SLIDING *(D)GABEL,GANGSCHALTUNG,GLEIT*										*(F)FOURCHETTE* *(S)HORQUILLA-DESLIZADOR*				
	90342057	.	M	B	B	B	S	S	S			1				
	[12]	(E)SHOE-GEARSHIFT *(D)SCHUH,GANGSCHALTUNG*										*(F)SABOT-CHANGEMENT* *(S)ZAPATA-PALANCA DE CAMBIOS*				
	96305524	.	M	B	B	B	S	S	S			2				
	[13]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09106-08004	.	M	B	B	B	S	S	S			2				
	[16]	(E)COVER-TRANSEAXLE *(D)DECKEL,ANTRIEB*										*(F)CARTER-TRANSMISSION* *(S)CUBIERTA-EJE TRANSVERSAL*				
	96175844	.	M	B	B	B	S	S	S			1				
	[17]	(E)GASKET-TRANSAXLE COVER *(D)DICHTUNG,ANTRIEB DECKEL*										*(F)JOINT* *(S)JUNTA*				
	96179238	.	M	B	B	B	S	S	S			1				
	[18]	(E)MAGNET *(D)MAGNET*										*(F)AIMANT* *(S)IMAN*				
	08957605	.	M	B	B	B	S	S	S			1				
	[19]	(E)GASKET-BEARING PLATE *(D)DICHTUNG,LAGER PLATTE*										*(F)JOINT-PLAQUE DE ROULEMENT* *(S)JUNTA-PLACA DE COJINETE*				
	96179244	.	M	B	B	B	S	S	S			1				
	[20]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09100-08016	.	M	B	B	B	S	S	S			5				
	[21]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09100-08018	.	M	B	B	B	S	S	S			5				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[22]									(E)BOLT (D)SCHRAUBE					(F)BOULON (S)PERNO	
	09100-07002	.	M	B	B	B	S	S	S			5				
	[23]									(E)SCREW (D)SCHRAUBE					(F)VIS (S)TORNILLO	
	90168610	.	M	B	B	B	S	S	S			1				
	[24]									(E)SLEEVE-DETENT (D)HÜLSE,RÜCK-HALTER					(F)CHEMISE-DETENTE (S)MANGA-SEGURO	
	90375062	.	M	B	B	B	S	S	S			3				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

3260 GEAR SHIFT COVER&FORK




ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		KEY NO.								PART NAME						
[01]	90344077	.	M	B	B	B	S	S	S	(E)FORK-1ST&2ND GEARSHIFT (D)GABEL,1.&2.GANGSCHALTUNG		1			(F)FOURCHETTE (S)HORQUILLA-CAMBIOS	
[02]	90375059	.	M	B	B	B	S	S	S	(E)ROD-1ST&2ND GEARSHIFT (D)STAB,1.&2.GANGSCHALTUNG		1			(F)TRINGLE (S)VARILLA-PALANCA DE CAMBIO	
[03]	11054212	.	M	B	B	B	S	S	S	(E)PIN-COILED (D)STIFT,GEWICKELT		1			(F)BROCHE-BOUDIN (S)PASADOR-ENROSCADO	
[04]	90184831	.	M	B	B	B	S	S	S	(E)FORK-3RD&4TH GEARSHIFT (D)GABEL,3.&4.GANGSCHALTUNG		1			(F)FOURCHETTE (S)HORQUILLA-CAMBIOS	
[05]	90375060	.	M	B	B	B	S	S	S	(E)ROAD-3RD&4TH GEARSHIFT (D)STRAßE,3.&4.GANGSCHALTUNG		1			(F)ROUTE (S)VIA-PALANCA DE CAMBIOS	
[06]	11054212	.	M	B	B	B	S	S	S	(E)PIN-COILED (D)STIFT,GEWICKELT		1			(F)BROCHE-BOUDIN (S)PASADOR-ENROSCADO	
[07]	90375041	.	M	B	B	B	S	S	S	(E)PIECE-5TH SPEED ENGAGING (D)TEIL,BETATIGUNGS		1			(F)PIECE-ENGAGEMENT (S)PIEZA-ENGRANAR	
[08]	90142154	.	M	B	B	B	S	S	S	(E)PAWL-GEARSHIFT ROD (D)SPERRHACKEN		1			(F)CLIQUET (S)RETEN	
[09]	90199518	.	M	B	B	B	S	S	S	(E)FORK-GEARSHIFT REVERSE (D)GABEL		1			(F)FOURCHETTE-MARCHE ARRIERE (S)HORQUILLA-CAMBIO	
[10]										(E)ROD-REVERSE GEARSHIFT (D)STAB					(F)TRINGLE (S)VARILLA-PALANCA DE CAMBIO	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	90334195	.	M	B	B	B	S	S	S			1				
	[11]	(E)PIN-COILED (D)STIFT,GEWICKELT													(F)BROCHE-BOUDIN (S)PASADOR-ENROSCADO	
	11054212	.	M	B	B	B	S	S	S			1				
	[12]	(E)COVER A-GEARSHIFT (D)DECKEL,GANGSCHALTUNG													(F)CARTER (S)CUBIERTA	
	90374229	.	M	B	B	B	S	S	S			1				
	[13]	(E)ROD A-GEARSHIFT (D)STAB,GANGSCHALTUNG													(F)TRINGLE (S)VARILLA-PALANCA DE CAMBIO	
	90147931	.	M	B	B	B	S	S	S			1				
	[14]	(E)FINGER-SHIFT (D)FINGER,SCHALTUNG													(F)DOIGT-CHANGEMENT (S)DEDO-CAMBIOS	
	90157060	.	M	B	B	B	S	S	S			1				
	[15]	(E)PIN-COILED (D)STIFT,GEWICKELT													(F)BROCHE-BOUDIN (S)PASADOR-ENROSCADO	
	11054212	.	M	B	B	B	S	S	S			1				
	[16]	(E)LEVER-GEARSHIFT INTER (D)HEBEL,GANGSCHALTUNG													(F)LEVIER (S)PALANCA	
	96179218	.	M	B	B	B	S	S	S			1				
	[17]	(E)PLATE-GUARD (D)PLATTE,SCHUTZ													(F)PLAQUE-GARDE (S)PLACA-GUARDIA	
	90142132	.	M	B	B	B	S	S	S			1				
	[18]	(E)SPRING-COMPRESSION (D)FEDERUNG,VERDICHTUNG													(F)RESSORT-COMPRESSION (S)RESORTE-COMPRESION	
	90170121	.	M	B	B	B	S	S	S			1				
	[19]	(E)BUSHING-GEARSHIFT COVER (D)LAGERFUTTER													(F)MANCHON (S)BUJE	
	90223591	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[20]	(E)RING-RETAINING (D)RING,HALTER													(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR	
	90223590	.	M	B	B	B	S	S	S			1				
	[21]	(E)GASKET-GEARSHIFT COVER (D)DICHTUNG													(F)JOINT (S)JUNTA	
	96179248	.	M	B	B	B	S	S	S			1				
	[22]	(E)BOLT (D)SCHRAUBE													(F)BOULON (S)PERNO	
	09100-07003	.	M	B	B	B	S	S	S			4				
	[23]	(E)PLUG-GEARSHIFT COVER (D)STÖPSEL													(F)BOUCHON (S)TAPON	
	90105651	.	M	B	B	B	S	S	S			1				
	[24]	(E)PLUG-OIL FILLER (D)STÖPSEL,ÖL ZUFUHR													(F)BOUCHON (S)TAPON-LLENAR ACEITE	
	90086885	.	M	B	B	B	S	S	S			1				
	[25]	(E)BRACKET-ENGINE (D)TRÄGER								CONT.HARNESS					(F)SUPPORT (S)SOPORTE	
	96234618	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)HOUSING-DIFFERENTIAL GEAR *(D)GEHÄUSE*									*(F)LOGEMENT* *(S)CARCASA*					
90372052		.	M	B	B	B	S	S	S			1				
[02]		(E)GEAR-HELICAL DIFFERENTIAL *(D)AUSGLEICHSGETRIEBE*									*(F)ENGRENAGE-HELICOIDAL* *(S)ENGRANAJE*					
96242700		Y	M	B	B	B	S	S	S	&M85		1			RATIO : 4.176	
90279879		6	M	B	B	B	.	.	O	&MG4-KL9/EC1		1			RATIO : 3.722	
96242700		6	M	B	B	B	.	.	A	&M85&KL9/EC1		1				
[03]		(E)GEAR-DRIVEN WORM *(D)GETRIEBE*									*(F)ENGRENAGE* *(S)ENGRANAJE*					
90125064		.	M	B	B	B	S	S	S			1				
[04]		(E)WASHER-SIDE GEAR THRUST *(D)DICHTUNGSRING*									*(F)RONDELLE* *(S)ARANDELA*					
14040531		.	M	B	B	B	S	S	S			2				
[05]		(E)GEAR-AXLE SHAFT BEVEL *(D)GETRIEBE,ABSCHRÄGUNG*									*(F)ENGRENAGE* *(S)ENGRANAJE-BISEL*					
96183738		.	M	B	B	B	S	S	S			2				
[06]		(E)GEAR-BEVEL DIFFERENTIAL *(D)GETRIEBE*									*(F)ENGRENAGE* *(S)ENGRANAJE*					
96183739		.	M	B	B	B	S	S	S			2				
[07]		(E)DISK-BEVEL GEAR *(D)SCHEIBE,KEGELRADGETRIEBE*									*(F)DISQUE-ENGRENAGE BISEAUTE* *(S)DISCO-ENGRANAJE BISEL*					
00463061		.	M	B	B	B	S	S	S			2				
[08]		(E)SHAFT-DIFFERENTIAL GEAR *(D)SPINDEL,AUSGLEICHSGETRIEB*									*(F)ARBRE* *(S)EJE-ENGRANAJE DIFERENCIAL*					
90372053		.	M	B	B	B	S	S	S			1				
[09]		(E)PIN-DIFFERENTIAL SPRING *(D)STIFT,AUSGLEICHSGETRIEBE*									*(F)BROCHE* *(S)PASADOR*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	96169094	.	M	B	B	B	S	S	S			1					(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO
[10]																	
	09103-10057	.	M	B	B	B	S	S	S			10					(E)BEARING-TAPERED ROLLER (D)ROLLENLAGER,ZUGESPITZT (F)ROULEMENT-ROULEAU FUSELE (S)COJINETE-RODILLO REDUCIDO
[11]																	
	96108125	.	M	B	B	B	S	S	S			2					(E)RING-DIFFERENTIAL BEARING (D)RING,AUSGLEICHS-LAGER (F)ANNEAU (S)ANILLO
[12]																	
	90121689	.	M	B	B	B	S	S	S			1					(E)RING-SHAFT SEAL (D)RING,STAB DICHTUNG (F)ANNEAU-JOINT D'ARBRE (S)ANILLO-BROCHE DE EJE
[13]																	
	90182166	.	M	B	B	B	S	S	S			2					(E)O RING-DIFFERENTIAL (D)O RING,AUSGLEICHSGETRIEBE (F)JOINT TORIQUE (S)ANILLO EN O-DIFERENCIAL
[14]																	
	90111402	.	M	B	B	B	S	S	S			1					(E)FLANGE-DIFF GEAR BEARING (D)FLANSCH (F)FLASQUE (S)PESTAÑA
[15]																	
	90121695	.	M	B	B	B	S	S	S			1					(E)O RING (D)O RING (F)JOINT TORIQUE (S)ANILLO EN O
[16]																	
	90129521	.	M	B	B	B	S	S	S			1					(E)PLATE-LOCKING (D)PLATTE,VERRIEGELUNG (F)PLAQUE-VERROUILLAGE (S)PLACA-CIERRE
[17]																	
	90079853	.	M	B	B	B	S	S	S			1					(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO
[18]																	
	09116-06029	.	M	B	B	B	S	S	S			1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[19] 09103-08026	(E)BOLT (D)SCHRAUBE .	M	B	B	B	S	S	S		(F)BOULON (S)PERNO	6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)TRANSAXLE A-AUTOMATIC *(D)ANTRIEB,AUTOMATISCH*									*(F)TRANSMISSION-AUTOMATIQUE* *(S)EJE TRANSVERSAL*					
[01]	24210487	Y	A	B	B	B	O	O	O			1				7X
	24210488	6	A	B	B	B	.	.	O			1				7Y
		(E)HOSE-VENTING *(D)SCHLAUCH,BELÜFTUNG*									*(F)TUYAU-VENTILATION* *(S)MANGUERA-VENTILACION*					
[02]	96183828	.	A	B	B	B	O	O	O			1			900mm	
		(E)SUPPORT-TRANSMISSION *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
[03]	96179228	.	A	B	B	B	O	O	O			1				
		(E)BOLT-HEXAGON *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
[04]	09103-10009	.	A	B	B	B	O	O	O			3				
		(E)BRACKET-SHIELD *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
[05]	96236245	.	A	B	B	B	O	O	O			1	970901			
		(E)NUT *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
[06]	08316-25063	.	A	B	B	B	O	O	O			1	970901			
		(E)COVER-CONVERTER *(D)DECKEL*									*(F)CARTER* *(S)CUBIERTA*					
[07]	96245952	.	A	B	B	B	O	O	O			1				
		(E)SCREW-TAPPING *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
[08]	03252-63168	.	A	B	B	B	O	O	O			3				
		(E)BOLT-HEXAGON *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
[09]	09100-12006	.	A	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
		MODEL										EFFECTIVE DATE			
1 TC	PART NO	ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	FROM	TO	REMARKS	P/CODE
[10]	(E)BOLT-HEXAGON *(D)SCHRAUBE*														*(F)BOULON* *(S)PERNO*	
09100-10006		.	A	B	B	B	O	O	O			3				
[11]	(E)BOLT-HEXAGON *(D)SCHRAUBE*														*(F)BOULON* *(S)PERNO*	
09100-12002		.	A	B	B	B	O	O	O			5				
[12]	(E)BRACKET-ENG CONT HARNESS *(D)TRÄGER*														*(F)SUPPORT* *(S)SOPORTE*	
96234606		.	A	B	B	B	O	O	O			1				
[A0]	(E)OVERHAUL KIT *(D)WARTUNG SATZ*														*(F)TROUSSE DE REPARATIONS* *(S)JUEGO DE REPARACION*	
24209093		.	A	B	B	B	O	O	O			1				
	- CONSIST OF -															
	FIG. NO 3520 #2,5,6,14,16,17,18,28,29,34,35 39,40,42															
	FIG. NO 3521 #7,12,14,19,22,25,32,33,53															
	FIG. NO 3530 #2,8,9,14															
	FIG. NO 3531 #1,5,10,19,23,34,															
	FIG. NO 3533 #3,10															
	FIG. NO 3535 #5															
	FIG. NO 3550 #5,6															
	FIG. NO 3570 #10,12															
[A1]	(E)GASKET KIT *(D)DICHTUNG SATZ*														*(F)TROUSSE DE JOINT* *(S)JUEGO DE JUNTA*	
24210577		.	A	B	B	B	O	O	O			1				
	- CONSIST OF -															

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME													
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4 N	3 H	5 H	S	S E	S X						
		FIG. NO 3520 #6,14,17,18													
		FIG. NO 3521 #12,14,19,33													
		FIG. NO 3570 #10													

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)COVER-SIDE (D)DECKEL,SEITE									(F)CARTER-COTE (S)CUBIERTA-LADO					
	24209574	.	A	B	B	B	O	O	O			1			INCL.#2,5,6,41	
[02]		(E)SEAL-OIL (D)DICHTUNG,ACHSE ÖL									(F)JOINT-HUILE DE PONT (S)SELLO-ACEITE DE EJE					
	24201936	.	A	B	B	B	O	O	O			1				
[03]		(E)BOLT-SIDE COVER (D)SCHRAUBE,SEITENDECKEL									(F)BOULON-COUVERCLE COTE (S)PERNO-CUBIERTA DE LADO					
	24203912	.	A	B	B	B	O	O	O			1			M8X1.25X23mm	
[04]		(E)STUD-SIDE COVER (D)STEG,SEITEN-DECKEL									(F)TOURILLON (S)TRAVESAÑO					
	24208309	.	A	B	B	B	O	O	O			1			M8X1.25X20mm	
[05]		(E)GASKET-SIDE COVER (D)DICHTUNG									(F)JOINT-CARTER DE COTE (S)JUNTA-CUBIERTA LATERAL					
	24200478	.	A	B	B	B	O	O	O			1				
[06]		(E)GASKET-SIDE CVR OIL LEVER (D)DICHTUNG									(F)JOINT (S)JUNTA					
	08685154	.	A	B	B	B	O	O	O			1				
[08]		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	24200205	.	A	B	B	B	O	O	O			12			M6X1.0X86mm	
[09]		(E)SWITCH-PRESSURE (D)SCHALTER,DRUCK									(F)COMMUTATEUR-PRESSION (S)INTERRUPTOR-PRESION					
	24200495	.	A	B	B	B	O	O	O			1				
[12]		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	24200207	.	A	B	B	B	O	O	O			2			M6X1.0X24mm	
[13]		(E)PLUG-LINE PRESS (D)STÖPSEL									(F)BOUCHON (S)TAPON					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	08654382	.	A	B	B	B	O	O	O			1				
	[14]	(E)SEALS-COOLER LINE (D)DICHTUNG										(F)JOINT (S)SELLO				
	24200326	.	A	B	B	B	O	O	O			2				
	[15]	(E)CAP-VENTILATION (D)DECKEL										(F)CHAPEAU (S)TAPA				
	24200354	.	A	B	B	B	O	O	O			1				
	[16]	(E)SEAL-TORQUE CONVERTER (D)DICHTUNG										(F)JOINT (S)SELLO				
	08685515	.	A	B	B	B	O	O	O			1				
	[17]	(E)SLEEVE-OUTPUT/STUB SHAFT (D)HÜLSE										(F)CHEMISE (S)MANGA				
	08684482	.	A	B	B	B	O	O	O			1				
	[18]	(E)RING-OUTPUT/STUB SHAFT (D)RING										(F)ANNEAU (S)ANILLO				
	07829495	.	A	B	B	B	O	O	O			2				
	[19]	(E)SHAFT-STUB (D)SPINDEL										(F)ARBRE (S)EJE				
	24200734	.	A	B	B	B	O	O	O			1				
	[20]	(E)STUD-OUTPUT SPD SENSOR (D)STEG										(F)TOURILLON (S)TRAVESAÑO				
	24200091	.	A	B	B	B	O	O	O			1			M6X1.0X11mm	
	[21]	(E)SENSOR-OUTPUT SPEED (D)SENSOR,GESCHWINDIGKEIT										(F)DETECTEUR (S)SENSOR-VELOCIDAD				
	24207507	.	A	B	B	B	O	O	O			1				
	[22]	(E)PLUG-LINE PRESS (D)STÖPSEL										(F)BOUCHON (S)TAPON				
	08654382	.	A	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[23]	08684393	.	A	B	B	B	O	O	O	(E)SPRING-SERVO RETURN (D)FEDERUNG,SERVO RÜCK (F)RESSORT-SERVO RETOUR (S)RESORTE-RETORNO DE SERVO		1				
[24]	08684395	.	A	B	B	B	O	O	O	(E)PIN-SERVO APPLY (D)STIFT,SERVO ANWENDUNG (F)BROCHE-APPLICATION SERVO (S)PASADOR-APPLY SERVO		1				
[25]	24203610	.	A	B	B	B	O	O	O	(E)SPRING-SERVO CUSHION (D)FEDERUNG,SERVO POLSTER (F)RESSORT-SERVO COUSSIN (S)RESORTE-COJIN DE SERVO		2				
[26]	24201884	.	A	B	B	B	O	O	O	(E)PISTON-SERVO (D)KOLBEN,SERVO (F)PISTON-SERVO (S)PISTON-SERVO		1				
[27]	11505767	.	A	B	B	B	O	O	O	(E)RING-SERVO SNAP (D)RING,SERVO DRUCK (F)ANNEAU-SERVO PRESSION (S)ANILLO-BROCHE DE SERVO		2				
[28]	08684674	.	A	B	B	B	O	O	O	(E)SEAL-SERVO PISTON (D)DICHTUNG,SERVO KOLBEN (F)JOINT-SERVO PISTON (S)SELLO-PISTON DE SERVO		1				
[29]	08684394	.	A	B	B	B	O	O	O	(E)SEAL-SERVO COVER (D)DICHTUNG,SERVO DECKEL (F)JOINT-SERVO COUVERCLE (S)SELLO-CUBIERTA DE SERVO		1				
[30]	24201882	.	A	B	B	B	O	O	O	(E)COVER-SERVO(LO/REVERSE) (D)DECKEL (F)COUVERTURE (S)CUBIERTA		1				
[31]	08684350	.	A	B	B	B	O	O	O	(E)SPRING-SERVO RETURN (D)FEDERUNG,SERVO RÜCK (F)RESSORT-SERVO RETOUR (S)RESORTE-RETORNO DE SERVO		1				
[32]										(E)PIN-SERVO APPLY (D)STIFT,SERVO ANWENDUNG (F)BROCHE-APPLICATION SERVO (S)PASADOR-APPLY SERVO						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	08684404	.	A	B	B	B	O	O	O			1				
	[33]	(E)PISTON-SERVO (D)KOLBEN,SERVO										(F)PISTON-SERVO (S)PISTON-SERVO				
	N/S(60)	.	A	B	B	B	O	O	O			1				
	[34]	(E)SEAL-SERVO PISTON (D)DICHTUNG,SERVO KOLBEN										(F)JOINT-SERVO PISTON (S)SELLO-PISTON DE SERVO				
	08684673	.	A	B	B	B	O	O	O			1				
	[35]	(E)SEAL-SERVO COVER (D)DICHTUNG,SERVO DECKEL										(F)JOINT-SERVO COUVERCLE (S)SELLO-CUBIERTA DE SERVO				
	08678473	.	A	B	B	B	O	O	O			1				
	[36]	(E)COVER-SERVO (D)DECKEL,SERVO										(F)CARTER-SERVO (S)CUBIERTA-SERVO				
	24201880	.	A	B	B	B	O	O	O			1				
	[37]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	24200092	.	A	B	B	B	O	O	O			4			M6X1.0X15mm	
	[38]	(E)TUBE A-OIL FEED (D)ROHRLEITUNG,ÖL-ZUFUHR										(F)TUYAU-ALIMENTATION HUILE (S)TUBO-ALIMENTACION				
	24202349	.	A	B	B	B	O	O	O			1				
	[39]	(E)SEAL-OIL FILTER (D)DICHTUNG										(F)JOINT (S)SELLO				
	08684467	.	A	B	B	B	O	O	O			1				
	[40]	(E)FILTER A-OIL (D)FILTER										(F)FILTRE (S)FILTRO				
	08685185	.	A	B	B	B	O	O	O			1				
	Y 24203770	.	A	B	B	B	O	O	O			1				
	[41]	(E)VALVE-FILTER CONTROL (D)VENTIL										(F)SOUPAPE (S)VALVULA				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	24207185	.	A	B	B	B	O	O	O			1				
	[42]	(E)GASKET-BOTTOM OIL PAN (D)DICHTUNG										(F)JOINT (S)JUNTA				
	24203590	.	A	B	B	B	O	O	O			1				
	[43]	(E)PAN KIT-OIL (D)PFANNE,OL										(F)CARTER-HUILE (S)RECIPIENTE-ACEITE				
	24203769	.	A	B	B	B	O	O	O			1			INCL.#42	
	[45]	(E)RETAINER (D)KLEMME,HALTERUNG										(F)ATTACHE-ARRETOIR (S)GRAPA-RETENEDOR				
	08685781	.	A	B	B	B	O	O	O			11				
	[46]	(E)SOLENOID-SHIFT(A & B) (D)SOLENOID										(F)SOLENOIDE (S)SELENOIDE				
	24207236	.	A	B	B	B	O	O	O			2				
	[47]	(E)SOLENOID-PRESSURE CONTROL (D)SOLENOID,DRUCK STEUERUNG										(F)SOLENOIDE (S)SELENOIDE				
	10478117	.	A	B	B	B	O	O	O			1				
	[48]	(E)SOLENOID-TCC CONTROL (D)SOLENOID										(F)SOLENOIDE (S)SELENOIDE-CONTROL TCC				
	24207054	.	A	B	B	B	O	O	O			1				
	[49]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	24203911	.	A	B	B	B	O	O	O			10				
	24210147	.	A	B	B	B	O	O	O			2				
	[50]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	08685658	.	A	B	B	B	O	O	O			6			M8X1.25X16mm	
	[51]	(E)CONVERTER-TORQUE (D)KATALYSATOR										(F)CONVERTISSEUR (S)CONVERTIDOR-CATALITICO				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	24203821	Y	A	B	B	B	O	O	O			1				
	24210147														NOT APPLIED	
	24211286	6	A	B	B	B	.	.	O			1				
[52]	(E)BUSHING-CASE TO FINAL DRV (D)LAGERFUTTER									(F)MANCHON (S)BUJE						
	08631119	.	A	B	B	B	O	O	O			1				
[53]	(E)SEAL-OUTPUT SPD SENSOR (D)DICHTUNG									(F)JOINT (S)SELLO						
	10475299	.	A	B	B	B	O	O	O			1				
[54]	(E)PIN-BAND ANCHOR,LO/REVERS (D)STIFT									(F)BROCHE (S)PASADOR						
	24202694	.	A	B	B	B	O	O	O			1				
[56]	(E)COVER A-REV BAND SERVO (D)DECKEL									(F)CARTER (S)CUBIERTA						
	24203623	.	A	B	B	B	O	O	O			1				
[60]	(E)COVER KIT-4TH BAND SERVO (D)DECKEL,SERVO									(F)CARTER-SERVO (S)CUBIERTA-SERVO						
	24203608	.	A	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)PUMP-OIL									(F)POMPE-HUILE					
[01]		(D)PUMPE,ÖL									(S)BOMBA-ACEITE					
24208987		.	A	B	B	B	O	O	O			1				
		(E)BOLT									(F)BOULON					
[02]		(D)SCHRAUBE									(S)PERNO					
24200209		.	A	B	B	B	O	O	O			4			M8X1.25X58mm	
		(E)BOLT									(F)BOULON					
[03]		(D)SCHRAUBE									(S)PERNO					
24200208		.	A	B	B	B	O	O	O			3			M6X1.0X99mm	
		(E)WIRING									(F)CABLAGE					
[04]		(D)VERDRAHTUNG									(S)INSTALACION ELECTRICA					
15302843		.	A	B	B	B	O	O	O			1				
		(E)BOLT									(F)BOULON					
[05]		(D)SCHRAUBE									(S)PERNO					
24200093		.	A	B	B	B	O	O	O			2			M8X1.0X11mm	
		(E)BOLT									(F)BOULON					
[06]		(D)SCHRAUBE									(S)PERNO					
24200206		.	A	B	B	B	O	O	O			9			M6X1.0X47mm	
		(E)FILTER A-OIL									(F)FILTRE					
[07]		(D)FILTER									(S)FILTRO					
08683769		.	A	B	B	B	O	O	O			1				
		(E)BODY A-CONTROL VALVE									(F)CORPS-SOUPAPE					
[08]		(D)KAROSSERIE									(S)CARROCERIA-VALVULA					
24209128		.	A	B	B	B	O	O	O			1				
		(E)SHAFT-OIL PUMP DRIVE									(F)ARBRE					
[09]		(D)SPINDEL									(S)EJE					
08684255		.	A	B	B	B	O	O	O			1				
		(E)BOLT									(F)BOULON					
[10]		(D)SCHRAUBE									(S)PERNO					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	24200214	.	A	B	B	B	O	O	O			2			M6X1.0X64mm	
[11]	(E)SUPPORT-SPACER PLATE (D)TRÄGER											(F)SUPPORT (S)SOPORTE				
	08685213	.	A	B	B	B	O	O	O			1				
[12]	(E)GASKET-VALVE BODY (D)DICHTUNG											(F)JOINT (S)JUNTA				
	24207387	.	A	B	B	B	O	O	O			1				
[13]	(E)PLATE-VALVE BODY SPACER (D)PLATTE											(F)PLAQUE (S)PLACA				
	24205050	.	A	B	B	B	O	O	O			1				
[14]	(E)GASKET-VALVE BODY (D)DICHTUNG											(F)JOINT (S)JUNTA				
	24207386	.	A	B	B	B	O	O	O			1				
[15]	(E)BOLT (D)SCHRAUBE											(F)BOULON (S)PERNO				
	24200207	.	A	B	B	B	O	O	O			14			M6X1.0X24mm	
[16]	(E)WASHER-DRIVEN SPROC.THRU. (D)DICHTUNGSRING											(F)RONDELLE (S)ARANDELA				
	08684379	.	A	B	B	B	O	O	O			1				
[17]	(E)BALL-CHECK (D)KUGEL											(F)BOULE (S)BOLA				
	00147485	.	A	B	B	B	O	O	O			7				
[18]	(E)PLATE-CHNNEL (D)PLATTE											(F)PLAQUE (S)PLACA				
	24208110	.	A	B	B	B	O	O	O			1				
[19]	(E)GASKET-CHNNEL PLATE (D)DICHTUNG											(F)JOINT (S)JUNTA				
	24201096	.	A	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[20]	24210506	.	A	B	B	B	O	O	O	(E)PISTON-ACCUMULATOR *(D)KOLBEN* *(F)PISTON* *(S)PISTON*		3				
[21]	24206623	.	A	B	B	B	O	O	O	(E)SEAL-ACCUM PISTON *(D)DICHTUNG* *(F)JOINT* *(S)SELLO*		3				
[22]	08685241	.	A	B	B	B	O	O	O	(E)SPRING *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*		1				
[23]	08685240	.	A	B	B	B	O	O	O	(E)SPRING *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*		2				
[24]	24203557	.	A	B	B	B	O	O	O	(E)SPRING *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*		2				
[25]	08643068	.	A	B	B	B	O	O	O	(E)SEAL *(D)DICHTUNG* *(F)JOINT* *(S)SELLO*		2				
[26]	08652868	.	A	B	B	B	O	O	O	(E)WASHER-THRUST *(D)DICHTUNGSRING* *(F)RONDELLE* *(S)ARANDELA*		1				
[27]	08631210	.	A	B	B	B	O	O	O	(E)RING-SNAP *(D)RING* *(F)ANNEAU* *(S)ANILLO*		1				
[28]	24200738	.	A	B	B	B	O	O	O	(E)LINK A-DRIVE *(D)KETTE* *(F)CHAINE* *(S)CADENA*		1				
[29]										(E)SPROCKET-DRIVE *(D)ZAHNKETTENRAD* *(F)ENGRENAGE* *(S)RUEDA DE ESPIGAS*						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	24204709	.	A	B	B	B	O	O	O			1				
[30]	(E)WASHER-THRUST (D)DICHTUNGSRING (F)RONDELLE (S)ARANDELA															
	08652841	.	A	B	B	B	O	O	O			1				
[31]	(E)SHAFT-TURBINE (D)SPINDEL (F)ARBRE (S)EJE															
	08652382	.	A	B	B	B	O	O	O			1				
[32]	(E)SEAL-TURBINE SHAFT (D)DICHTUNG (F)JOINT (S)SELLO															
	08637170	.	A	B	B	B	O	O	O			1				
[33]	(E)SEAL-TURBINE SHAFT (D)DICHTUNG (F)JOINT (S)SELLO															
	08677453	.	A	B	B	B	O	O	O			1				
[34]	(E)BEARING (D)KUGELLAGER (F)ROULEMENT (S)COJINET															
	24205179	.	A	B	B	B	O	O	O			1				
[36]	(E)SUPPORT A-DRIVEN SPROCKET (D)TRÄGER (F)SUPPORT (S)SOPORTE															
	08685660	.	A	B	B	B	O	O	O			1				
[37]	(E)BUSHING (D)LAGERFUTTER (F)MANCHON (S)BUJE															
	08628047	.	A	B	B	B	O	O	O			1				
[38]	(E)PIN-DOWEL (D)STIFT (F)BROCHE (S)PASADOR															
	08685132	.	A	B	B	B	O	O	O			4				
[39]	(E)SENSOR-INPUT SPEED (D)SENSOR (F)DETECTEUR (S)SENSOR															
	10456545	.	A	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[44]										(E)SLEEVE-OUTPUT/STUB SHAFT *(D)HÜLSE*						
	08684482	.	A	B	B	B	O	O	O				1				
	[45]										(E)RING-OUTPUT/STUB SHAFT *(D)RING*						
	07829495	.	A	B	B	B	O	O	O				2				
	[47]										(E)SPROCKET-DRIVEN *(D)ZAHNKETTENRAD*						
	24204714	.	A	B	B	B	O	O	O				1				
	[48]										(E)WASHER-THRUST *(D)DICHTUNGSRING*						
	08637227	.	A	B	B	B	O	O	O				1				
	[49]										(E)SHAFT-OUTPUT *(D)SPINDEL*						
	24200733	.	A	B	B	B	O	O	O				1				
	[50]										REFER GROUP #3550						
	[51]										(E)PLATE-DISC CLUTCH *(D)PLATTE,SCHEIBEN-KUPPLUNG*						
	24200298	.	A	B	B	B	O	O	O				1				
	[52]										(E)PLATE-DISC CLUTCH *(D)PLATTE,SCHEIBEN-KUPPLUNG*						
	24200790	.	A	B	B	B	O	O	O				3				
	[53]										(E)PLATE-DISC CLUTCH *(D)PLATTE,SCHEIBEN-KUPPLUNG*						
	08684322	.	A	B	B	B	O	O	O				3				
	[54]										(E)PLATE-DISC CLUTCH *(D)PLATTE,SCHEIBEN-KUPPLUNG*						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	08684324	.	A	B	B	B	O	O	O			1				
	[55]	(E)BAND-INTERMEDIATE/4TH *(D)BAND*										*(F)BANDE* *(S)BRIDA*				
	08684403	.	A	B	B	B	O	O	O			1				
	[56]	(E)WASHER-THRUST *(D)DICHTUNGSRING*										*(F)RONDELLE* *(S)ARANDELA*				
	08684259	.	A	B	B	B	O	O	O			1				
	[57]	REFER GROUP #3530														
	[58]	(E)BEARING-THRUST *(D)KUGELLAGER*										*(F)ROULEMENT* *(S)COJINET*				
	24200249	.	A	B	B	B	O	O	O			1				
	[59]	(E)WASHER-THRUST *(D)DICHTUNGSRING*								(SELECTIVE)		*(F)RONDELLE* *(S)ARANDELA*				
	08684469	.	A	B	B	B	O	O	O			1			BROWN	
		.	A	B	B	B	O	O	O						(SIZE1.50-1.60)	
	08684470	.	A	B	B	B	O	O	O			1			GRAY	
		.	A	B	B	B	O	O	O						(SIZE1.79-1.89)	
	08684471	.	A	B	B	B	O	O	O			1			NATURAL	
		.	A	B	B	B	O	O	O						(SIZE2.09-2.19)	
	08684472	.	A	B	B	B	O	O	O			1			BLACK	
		.	A	B	B	B	O	O	O						(SIZE2.39-2.49)	
	08684473	.	A	B	B	B	O	O	O			1			ORANGE	
		.	A	B	B	B	O	O	O						(SIZE2.68-2.78)	
	08684474	.	A	B	B	B	O	O	O			1			VIOLET	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		.	A	B	B	B	O	O	O						(SIZE2.98-3.08)	
	08684475	.	A	B	B	B	O	O	O			1			YELLOW	
		.	A	B	B	B	O	O	O						(SIZE2.98-3.08)	
	08684476	.	A	B	B	B	O	O	O			1			RED	
		.	A	B	B	B	O	O	O						(SIZE3.57-3.67)	
	08684477	.	A	B	B	B	O	O	O			1			GREEN	
		.	A	B	B	B	O	O	O						(SIZE3.87-3.97)	
[60]																
		REFER GROUP #3531														
[61]		(E)CARRIER-INPUT(W/REACTION) *(D)GETRIEBE*										*(F)ENGRENAGE (S)ENGRANAJE*				
	24207008	.	A	B	B	B	O	O	O			1				
[62]		(E)BEARING-THRUST *(D)KUGELLAGER*										*(F)ROULEMENT (S)COJINET*				
	08644206	.	A	B	B	B	O	O	O			1				
[63]		(E)FLANGE-INPUT CARR *(D)FLANSCH*										*(F)FLASQUE (S)PESTAÑA*				
	24202220														NOT APPLIED	
	24202221	.	A	B	B	B	O	O	O			1				
[64]		(E)WASHER-THRUST *(D)DICHTUNGSRING*										*(F)RONDELLE (S)ARANDELA*				
	08685039	.	A	B	B	B	O	O	O			1				
[65]																
		REFER GROUP #3533														

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	[66]									(E)BAND-FORWARD CLUTCH (D)BAND						
	08651614	.	A	B	B	B	O	O	O			1				
	[67]									(E)RING-FWD CLUTCH SUPT (D)RING						
	24201607	.	A	B	B	B	O	O	O			1				
	[68]									(E)BEARING-THRUST (D)KUGELLAGER						
	24200250	.	A	B	B	B	O	O	O			1				
	[69]															
		REFER GROUP #3535														
	[70]									(E)GEAR-FRT DIFF CARR SUN (D)GETRIEBE						
	08684311	.	A	B	B	B	O	O	O			1				
	[71]									(E)FINAL DRIVE & DIFFERENTIA (D)GETRIEBE						
	24203709	.	A	B	B	B	O	O	O			1				
	[72]									(E)BEARING-THRUST (D)KUGELLAGER						
	08646254	.	A	B	B	B	O	O	O			1				
	[73]									(E)RING (D)RING						
	11501326	.	A	B	B	B	O	O	O			1				
	[75]									(E)BEARING-THRUST (D)KUGELLAGER						
	08631362	.	A	B	B	B	O	O	O			1				
	[76]									(E)GEAR-FINAL DRIVE INTERNAL (D)GETRIEBE						


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
I-T-C	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM / TO		
	24201608	.	A	B	B	B	O	O	O			1			
	[77]	(E)RING-FRETTING (D)RING										(F)ANNEAU (S)ANILLO			
	24201612	.	A	B	B	B	O	O	O			1			
	[78]	(E)GEAR-INPUT (D)GETRIEBE										(F)ENGRENAGE (S)ENGRANAJE			
	08684574	.	A	B	B	B	O	O	O			1			
	[79]	(E)RING-INPUT (D)RING										(F)ANNEAU (S)ANILLO			
	24203619	.	A	B	B	B	O	O	O			1			
	[80]	(E)CASE-TRANSAXLE (D)KASTEN										(F)CARTER (S)CAJA			
	24208101	.	A	B	B	B	O	O	O			1			
O	24210088	.	A	B	B	B	O	O	O			1			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


3530 REVERSE INPUT CLUTCH ASSEMBLY



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[02]										(E)RETAINER-2ND ROLLER CLUTC *(D)KLEMME,HALTERUNG* *(F)ATTACHE-ARRETOIR* *(S)GRAPA-RETENEDOR*						
	24207224	.	A	B	B	B	O	O	O				1				
	[03]										(E)CAM-2ND ROLLER CLUTCH *(D)NOCKE* *(F)CAME* *(S)LEVA*						
	08684671	.	A	B	B	B	O	O	O				1				
	[04]										(E)CLUTCH-2ND ROLLER *(D)KUPPLUNG* *(F)EMBRAYAGE* *(S)EMBRAGUE*						
	00930695	.	A	B	B	B	O	O	O				1				
	[05]										(E)BUSHING-REVERSE CLUTCH *(D)LAGERFUTTER* *(F)MANCHON* *(S)BUJE*						
	08684268	.	A	B	B	B	O	O	O				1				
	[06]										(E)HOUSING-REVERSE CLUTCH *(D)GEHÄUSE* *(F)LOGEMENT* *(S)CARCASA*						
	24207313															NOT APPLIED	
	24204545	.	A	B	B	B	O	O	O				1				
	[07]										(E)BUSHING-REVERSE CLUTCH *(D)LAGERFUTTER* *(F)MANCHON* *(S)BUJE*						
	08684269	.	A	B	B	B	O	O	O				1				
	[08]										(E)SEAL *(D)DICHTUNG* *(F)JOINT* *(S)SELLO*						
	24205041	.	A	B	B	B	O	O	O				1				
	[09]										(E)PISTON A-REVERSE CLUTCH *(D)KOLBEN* *(F)PISTON* *(S)PISTON*						
	24205040	.	A	B	B	B	O	O	O				1				
	[10]										(E)SPRING & RETAINER *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*						
	24200758	.	A	B	B	B	O	O	O				1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK


3530 REVERSE INPUT CLUTCH ASSEMBLY



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[11]		(E)RING-SNAP (D)RING									(F)ANNEAU (S)ANILLO					
	08684283	.	A	B	B	B	O	O	O			1				
[12]		(E)PLATE-REVERSE CLUTCH(WAVE (D)PLATTE,SCHEIBEN-KUPPLUNG									(F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO					
	24200466	.	A	B	B	B	O	O	O			1				
[13]		(E)PLATE-REV.CLUTCH (STEEL) (D)PLATTE,SCHEIBEN-KUPPLUNG									(F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO					
	24207081	.	A	B	B	B	O	O	O			3				
[14]		(E)PLATE-REV.CLUTCH (FIBER) (D)PLATTE,SCHEIBEN-KUPPLUNG									(F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO					
	08684266	.	A	B	B	B	O	O	O			3				
[15]		(E)PLATE-REV.CLUTCH(BACK'G,A (D)PLATTE,SCHEIBEN-KUPPLUNG									(F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO					
	24200950	.	A	B	B	B	O	O	O			1			SELECTIVE	
	24200756	.	A	B	B	B	O	O	O			1			SELECTIVE	
	24200951	.	A	B	B	B	O	O	O			1			SELECTIVE	
[16]		(E)RING-SNAP (D)RING									(F)ANNEAU (S)ANILLO					
	24200754	.	A	B	B	B	O	O	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHRACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK

3531 DIRECT AND COAST CLUTCH ASSEMBLIES




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[01]																	(E)RING-SEAL (D)RING,DICHTUNG (F)ANNEAU-JOINT (S)ANILLO-SELLO
	08684272	.	A	B	B	B	O	O	O			4					
[03]																	(E)HOUSING-DIRECT&COAST CLUT (D)GEHÄUSE (F)LOGEMENT (S)CARCASA
	24209113	.	A	B	B	B	O	O	O			1					
[05]																	(E)PISTON-COAST CLUTCH (D)KOLBEN (F)PISTON (S)PISTON
	24205043	.	A	B	B	B	O	O	O			1					
[06]																	(E)SPRING (D)FEDERUNG (F)RESSORT (S)RESORTE
	24204448	.	A	B	B	B	O	O	O			1					
[07]																	(E)RETAINER (D)KLEMME,HALTERUNG (F)ATTACHE-ARRETOIR (S)GRAPA-RETENEDOR
	08684277	.	A	B	B	B	O	O	O			1					
[08]																	(E)RING-COAST CLUTCH SPRING (D)RING (F)ANNEAU (S)ANILLO
	08684278	.	A	B	B	B	O	O	O			1					
[09]																	(E)PLATE-COAST CLUTCH (STEEL (D)PLATTE,SCHEIBEN-KUPPLUNG (F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO
	08685874	.	A	B	B	B	O	O	O			4					
[10]																	(E)PLATE-COAST CLUTCH (FIBER (D)PLATTE,SCHEIBEN-KUPPLUNG (F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO
	08684282	.	A	B	B	B	O	O	O			4					
[11]																	(E)BEARING-THRUST (D)KUGELLAGER (F)ROULEMENT (S)COJINET
	24200249	.	A	B	B	B	O	O	O			1					
[12]																	(E)SHAFT A-INPUT SUN GEAR (D)SPINDEL (F)ARBRE (S)EJE

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[13]	24203613	.	A	B	B	B	O	O	O	(E)RACE A-OTR(INPUT SPRAG) *(D)GLEITBAHN*		1			*(F)CAGE* *(S)CARRERA*	
[14]	24203616	.	A	B	B	B	O	O	O	(E)RACE-OTR(INPUT SPRAG) *(D)GLEITBAHN*		1			*(F)CAGE* *(S)CARRERA*	
[16]	24200497	.	A	B	B	B	O	O	O	(E)SPRAG-INPUT CLUTCH *(D)KUPPLUNG,EINWEG*		1			*(F)EMBRAYAGE-SENS UNIQUE* *(S)EMBRAGUE-1 DIRECCION*	
[17]	24203617	.	A	B	B	B	O	O	O	(E)RING-SNAP *(D)RING*		1			*(F)ANNEAU* *(S)ANILLO*	
[18]	08658889	.	A	B	B	B	O	O	O	(E)RING-SNAP *(D)RING*		1			*(F)ANNEAU* *(S)ANILLO*	
[19]	08685878	.	A	B	B	B	O	O	O	(E)PISTON A-DIRECT CLUTCH *(D)KOLBEN*		1			*(F)PISTON* *(S)PISTON*	
[20]	24205044	.	A	B	B	B	O	O	O	(E)SPRING A-DIRECT CLUTCH *(D)FEDERUNG*		1			*(F)RESSORT* *(S)RESORTE*	
[21]	08684610	.	A	B	B	B	O	O	O	(E)RING-DIRECT CLUTCH SPRING *(D)RING*		1			*(F)ANNEAU* *(S)ANILLO*	
[22]	08684280	.	A	B	B	B	O	O	O	(E)PLATE-DIRECT CLUTCH(STEEL *(D)PLATTE,SCHEIBEN-KUPPLUNG*		1			*(F)PLAQUE-EMBRAYAGE A DISQUE* *(S)PLACA-EMBRAGUE DISCO*	
	08685879	.	A	B	B	B	O	O	O			8				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[23]	08684415	.	A	B	B	B	O	O	O			4					(E)PLATE-DIRECT CLUTCH(FIBER (D)PLATTE,SCHEIBEN-KUPPLUNG (F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO
[24]	08685875	.	A	B	B	B	O	O	O			1					(E)PLATE-DIRECT CLUTCH(BACK' (D)PLATTE,SCHEIBEN-KUPPLUNG (F)PLAQUE-EMBRAYAGE A DISQUE (S)PLACA-EMBRAGUE DISCO
[25]	24200248	.	A	B	B	B	O	O	O			1					(E)BEARING-THRUST (D)KUGELLAGER (F)ROULEMENT (S)COJINET
[26]	08684589	.	A	B	B	B	O	O	O			1					(E)BUSHING-REACTION CARR.SHF (D)LAGERFUTTER (F)MANCHON (S)BUJE
[27]	24202267	.	A	B	B	B	O	O	O			1					(E)SHELL-REACTION CARR.SHAFT (D)GEHÄUSE (F)ENVELOPPE (S)CAPARAZON
[28]	24200251	.	A	B	B	B	O	O	O			1					(E)BEARING-THRUST (D)KUGELLAGER (F)ROULEMENT (S)COJINET
[29]	08684586	.	A	B	B	B	O	O	O			1					(E)BUSHING-REACTION SUN GEAR (D)LAGERFUTTER (F)MANCHON (S)BUJE
[30]	24202271	.	A	B	B	B	O	O	O			1					(E)SHELL-REACTION SUN GEAR (D)GEHÄUSE (F)ENVELOPPE (S)CAPARAZON
[31]	24208584	.	A	B	B	B	O	O	O			1					(E)CARRIER A-REACTION (D)GETRIEBE (F)ENGRENAGE (S)ENGRANAJE
[32]																	(E)BEARING-THRUST (D)KUGELLAGER (F)ROULEMENT (S)COJINET

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	24200252	.	A	B	B	B	O	O	O			1				
	[33]	(E)GEAR-INPUT SUN (D)GETRIEBE										(F)ENGRENAGE (S)ENGRANAJE				
	08684581	.	A	B	B	B	O	O	O			1				
	[34]	(E)RING-SNAP (D)RING										(F)ANNEAU (S)ANILLO				
	08684580	.	A	B	B	B	O	O	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]										(E)RING-SNAP *(D)RING* *(F)ANNEAU* *(S)ANILLO*						
	08684893	.	A	B	B	B	O	O	O				1				
	[02]										(E)PLATE-FWD CLUTCH(BACK'G) *(D)PLATTE,SCHEIBEN-KUPPLUNG* *(F)PLAQUE-EMBRAYAGE A DISQUE* *(S)PLACA-EMBRAGUE DISCO*						
	24200595	.	A	B	B	B	O	O	O				1				
	[03]										(E)PLATE-FWD CLUTCH(FIBER) *(D)PLATTE,SCHEIBEN-KUPPLUNG* *(F)PLAQUE-EMBRAYAGE A DISQUE* *(S)PLACA-EMBRAGUE DISCO*						
	08684445	.	A	B	B	B	O	O	O				7				
	[04]										(E)PLATE-FWD CLUTCH(STEEL) *(D)PLATTE,SCHEIBEN-KUPPLUNG* *(F)PLAQUE-EMBRAYAGE A DISQUE* *(S)PLACA-EMBRAGUE DISCO*						
	08684444	.	A	B	B	B	O	O	O				7				
	[05]										(E)PLATE-FWD CLUTCH(WAVED) *(D)PLATTE,SCHEIBEN-KUPPLUNG* *(F)PLAQUE-EMBRAYAGE A DISQUE* *(S)PLACA-EMBRAGUE DISCO*						
	24200467	.	A	B	B	B	O	O	O				1				
	[06]										(E)RING-SNAP *(D)RING* *(F)ANNEAU* *(S)ANILLO*						
	08684443	.	A	B	B	B	O	O	O				1				
	[07]										(E)SPRING *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*						
	08684712	.	A	B	B	B	O	O	O				1				
Y	24208652	.	A	B	B	B	O	O	O				1				
	[08]										(E)PISTON A-FWD CLUTCH *(D)KOLBEN* *(F)PISTON* *(S)PISTON*						
	24208641	.	A	B	B	B	O	O	O				1				
	[10]										(E)SEAL & SLEEVE A *(D)DICHTUNG* *(F)JOINT* *(S)SELLO*						
	24208642	.	A	B	B	B	O	O	O				1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


3533 FORWARD CLUTCH ASSEMBLY



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[11]		(E)HOUSING-FWD CLUTCH *(D)GEHÄUSE*										*(F)LOGEMENT* *(S)CARCASA*				
24208640		.	A	B	B	B	O	O	O			1				
[12]		(E)BUSHING *(D)LAGERFUTTER*										*(F)MANCHON* *(S)BUJE*				
08684390		.	A	B	B	B	O	O	O			1				
[13]		(E)BUSHING *(D)LAGERFUTTER*										*(F)MANCHON* *(S)BUJE*				
08684389		.	A	B	B	B	O	O	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


3535 FORWARD CLUTCH SUPPORT ASSEMBLY



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
											(E)SUPPORT A-FORWARD CLUTCH (D)TRÄGER (F)SUPPORT (S)SOPORTE						
[01]	24204222															NOT APPLIED	
	24204810	.	A	B	B	B	O	O	O				1				
[03]											(E)SHAFT-FINAL DRIVE SUN (D)SPINDEL (F)ARBRE (S)EJE						
	24201609	.	A	B	B	B	O	O	O				1				
[04]											(E)ROLLER-FWD CLUTCH (D)ROLLE (F)ROULEAU (S)RODILLO						
	00930694	.	A	B	B	B	O	O	O				1				
[05]											(E)RING-OIL SEAL (D)RING (F)ANNEAU (S)ANILLO						
	24204223	.	A	B	B	B	O	O	O				2				
[06]											(E)BEARING-THRUST (D)KUGELLAGER (F)ROULEMENT (S)COJINET						
	24200246	.	A	B	B	B	O	O	O				1				
[07]											(E)GEAR-PARK LOCK (D)GETRIEBE (F)ENGRENAGE (S)ENGRANAJE						
	24204708	.	A	B	B	B	O	O	O				1				
[08]											(E)RING-SNAP (D)RING (F)ANNEAU (S)ANILLO						
	08684580	.	A	B	B	B	O	O	O				1				
[10]											(E)SPRING-PARK PAWL (D)FEDERUNG (F)RESSORT (S)RESORTE						
	24200129	.	A	B	B	B	O	O	O				1				
[11]											(E)PAWL-PARK (D)SPERRHACKEN (F)CLIQUET (S)RETEN						
	24200797	.	A	B	B	B	O	O	O				1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


3550 DRIVEN SPROCKET SUPPORT ASSEMBLY



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	[01]																(E)SUPPORT A-DRIVEN SPROCKET *(D)TRÄGER* *(F)SUPPORT* *(S)SOPORTE*
	24207143	.	A	B	B	B	O	O	O			1					
	[03]																(E)BEARING-THRUST *(D)KUGELLAGER* *(F)ROULEMENT* *(S)COJINET*
	08631190	.	A	B	B	B	O	O	O			1					
	[04]																(E)BUSHING-DRVN SPROCKET SUP *(D)LAGERFUTTER* *(F)MANCHON* *(S)BUJE*
	08684330	.	A	B	B	B	O	O	O			1					
	[05]																(E)SEAL *(D)DICHTUNG* *(F)JOINT* *(S)SELLO*
	24201613	.	A	B	B	B	O	O	O			2					
	[06]																(E)PISTON-2ND CLUTCH *(D)KOLBEN* *(F)PISTON* *(S)PISTON*
	24205042	.	A	B	B	B	O	O	O			1					
	[07]																(E)SPRING-2ND CLUTCH *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*
	08684327	.	A	B	B	B	O	O	O			1					
	[08]																(E)RING-2ND CLUTCH SPRING RE *(D)RING* *(F)ANNEAU* *(S)ANILLO*
	08684325	.	A	B	B	B	O	O	O			1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


3570 PARK LOCK AND DETENT LEVER



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[01]																	(E)VALVE-MAIN *(D)VENTIL* *(F)SOUPAPE* *(S)VALVULA*
	24201006	.	A	B	B	B	O	O	O			1					
[02]																	(E)RETAINER *(D)KLEMME,HALTERUNG* *(F)ATTACHE-ARRETOIR* *(S)GRAPA-RETENEDOR*
	24207209	.	A	B	B	B	O	O	O			1					
[03]																	(E)LINK-MANUAL VALVE *(D)VERBINDUNG* *(F)ACOUPLEMENT* *(S)ENLACE*
	08685147	.	A	B	B	B	O	O	O			1					
[04]																	(E)PIN-MANUAL SHAFT *(D)STIFT* *(F)BROCHE* *(S)PASADOR*
	08685700	.	A	B	B	B	O	O	O			1					
[05]																	(E)DETENT-MANUAL SHAFT *(D)SPERRHACKEN* *(F)CLIQUET* *(S)RETEN*
	24204221	.	A	B	B	B	O	O	O			1					
[06]																	(E)BOLT *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*
	24200092	.	A	B	B	B	O	O	O			1			M6X1.0X15mm		
[07]																	(E)LEVER&SHAFT A *(D)HEBEL* *(F)LEVIER* *(S)PALANCA*
	24203588	.	A	B	B	B	O	O	O			1					
[08]																	(E)ACTUATOR-PARKING LOCK *(D)BETÄTIGUNG* *(F)ACTIONNEUR* *(S)ACTUADOR*
	24202424	.	A	B	B	B	O	O	O			1					
[10]																	(E)SEAL-MANUAL SHAFT *(D)DICHTUNG* *(F)JOINT* *(S)SELLO*
	08644709	.	A	B	B	B	O	O	O			1					
[11]																	(E)PIN-ACTUATOR GUIDE SPRING *(D)STIFT* *(F)BROCHE* *(S)PASADOR*


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

3570 PARK LOCK AND DETENT LEVER




KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO	
	09427406	.	A	B	B	B	O	O	O		1				
	[12]	(E)SEAL-ACTUATOR GUIDE (D)DICHTUNG									(F)JOINT (S)SELLO				
	08675086	.	A	B	B	B	O	O	O		1				
	[13]	(E)GUIDE A-PARK'G LOCK (D)FÜHRING									(F)GUIDE (S)GUIA				
	08675325	.	A	B	B	B	O	O	O		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[01]																	(E)CONTROL A-GEARSHIFT (D)STEUERUNG,GANGSCHALTUNG
	96244989	.	M	B	B	B	S	S	S			1					
[02]																	(E)BOOT A-CONSOLE (D)KOFFERRAUM,KONSOLE
	96303182	.	M	B	B	B	S	S	S			1					
[04]																	(E)BOLT (D)SCHRAUBE
	09119-06002	.	M	B	B	B	S	S	S			4					
[05]																	(E)BELLOWS A-GEARSHIFT TUBE (D)GEBLÄSE
	96133781	.	M	B	B	B	S	S	S			1					
[06]																	(E)CLAMP (D)KLAMMER
	90217840	.	M	B	B	B	S	S	S			1					
[08]																	(E)BOLT (D)SCHRAUBE
	09117-08001	.	M	B	B	B	S	S	S			1					
[09]																	(E)ROD-GEARSHIFT CONTROL (D)STAB
	90250156	.	M	B	B	B	S	S	S			1					
[10]																	(E)CONTROL A-GEARSHIFT GUIDE (D)STEUERUNG,GANGSCHALTUNGS
	90342949	.	M	B	B	B	S	S	S			1					
[11]																	(E)PIN (D)STIFT
	09208-08001	.	M	B	B	B	S	S	S			1					
[12]																	(E)CLIP-RETAINING (D)KLEMME

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	08335-11069	.	M	B	B	B	S	S	S			1				
		(E)BOLT														
	[13]	(D)SCHRAUBE														
		(F)BOULON														
		(S)PERNO														
	96182212	.	M	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
											(E)CONTROL A-SELECTOR *(D)STEUERUNG,WÄHLER* *(F)CONTROLE-SELECTEUR* *(S)CONTROL-SELECTOR*						
[01]	96228515	.	A	B	B	B	O	O	O				1				
[02]	96242557	.	A	B	B	B	O	O	O		(E)HANDLE A-SELECTOR CONTROL *(D)HENKEL* *(F)POIGNEE* *(S)MANIJA*		1				
[03]	96228514	.	A	B	B	B	O	O	O		(E)BUTTON A-SELECTOR CONTROL *(D)KNOPF* *(F)BOUTON* *(S)BOTON*		1				
[04]	09440-12001	.	A	B	B	B	O	O	O		(E)SPRING *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*		1				
[05]	09127-04003	.	A	B	B	B	O	O	O		(E)SCREW *(D)SCHRAUBE* *(F)VIS* *(S)TORNILLO*		2				
[06]	96228503	.	A	B	B	B	O	O	O		(E)PIECE *(D)TEIL* *(F)PIECE* *(S)PIEZA*		1				
[07]	09306-10004	.	A	B	B	B	O	O	O		(E)BUSHING *(D)LAGERFUTTER* *(F)MANCHON* *(S)BUJE DE BOQUILLA*		2				
[08]	08321-31083	.	A	B	B	B	O	O	O		(E)WASHER-SPRING *(D)DICHTUNGSRING* *(F)RONDELLE* *(S)ARANDELA*		1				
[09]	08310-22083	.	A	B	B	B	O	O	O		(E)NUT-HEXAGON *(D)MUTTER* *(F)ECROU* *(S)TUERCA*		1				
[10]											(E)SPRING *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09440-07001	.	A	B	B	B	O	O	O			1				
	[11]	(E)BALL-STEEL (D)KUGEL										(F)BOULE (S)BOLA				
	06112-10004	.	A	B	B	B	O	O	O			1				
	[12]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	02114-14108	.	A	B	B	B	O	O	O			4				
	[13]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	09119-06002	.	A	B	B	B	O	O	O			4				
	[14]	(E)CAP A-FRONT CONSOLE (D)DECKEL,KONSOLE,AUTOM.										(F)CHAPEAU-CONSOLE,AUTO (S)TAPA-CONSOLA,AUTO				
	96236784	.	A	B	B	B	O	O	O			1				
	[15]	(E)CAP-CONSOLE,UPPER (D)DECKEL,KONSOLE,AUTOM.										(F)CHAPEAU-CONSOLE,AUTO (S)TAPA-CONSOLA,AUTO				
	96236787	.	A	B	B	B	O	O	O			1				
	[16]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03140-42095	.	A	B	B	B	O	O	O			4				
	[17]	(E)SCALE-CONSOLE (D)MAß,KONSOLE										(F)BALANCE-CONSOLE (S)ESCALA-CONSOLA				
	96218104	.	A	B	B	B	O	O	O			1				
	[18]	(E)CAP-CONSOLE,LOWER (D)DECKEL,KONSOLE,AUTOM.										(F)CHAPEAU-CONSOLE,AUTO (S)TAPA-CONSOLA,AUTO				
	96236790	.	A	B	B	B	O	O	O			1				
	[19]	(E)LAMP A-SCALE CONSOLE AUTO (D)LAMPE,VORDERE KONSOLE										(F)LAMPE-CONSOLE AVANT (S)LAMPARA				
	96169967	.	A	B	B	B	O	O	O			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
																	(E)SLIDER-CONSOLE (D)GLEIT,KONSOLE (F)GLISSIERE-CONSOLE (S)FRENILLO-CONSOLA
[20]	96218105	.	A	B	B	B	O	O	O			1					
[21]	96155676	.	A	B	B	B	O	O	O			1					(E)PIECE-SELECTOR CONT GUIDE (D)TEIL,FÜHRUNGS (F)PIECE-GUIDE (S)PIEZA-GUIA
[22]	09164-08001	.	A	B	B	B	O	O	O			1					(E)WASHER-CONICAL SPRING (D)DICHTUNGSRING (F)RONDELLE (S)ARANDELA
[23]	09160-08006	.	A	B	B	B	O	O	O			1					(E)WASHER-PLAIN (D)DICHTUNGSRING (F)RONDELLE (S)ARANDELA
[24]	09383-06002	.	A	B	B	B	O	O	O			1					(E)E RING (D)RING (F)ANNEAU (S)ANILLO
[25]	90121099	.	A	B	B	B	O	O	O			1					(E)PIECE-CLAMPING (D)TEIL (F)PIECE (S)PIEZA
[26]	08316-28063	.	A	B	B	B	O	O	O			1					(E)NUT-HEXAGON FLANGE (D)MUTTER (F)ECROU (S)TUERCA
[27]	09383-19005	.	A	B	B	B	O	O	O			1					(E)E RING (D)RING (F)ANNEAU (S)ANILLO
[28]	09383-06001	.	A	B	B	B	O	O	O			1					(E)E RING (D)RING (F)ANNEAU (S)ANILLO
[29]																	(E)FASTENER-SELECTOR CABLE (D)BEFESTIGUNG,KABEL WAHL (F)ATTACHE-CABLE SELECT (S)GRAPA


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4F09



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96226013	.	A	B	B	B	O	O	O			1				
	[30]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	01130-08203	.	A	B	B	B	O	O	O			1				
	[31]	(E)SWITCH A-NSBU (D)SCHALTER										(F)COMMUTATEUR (S)INTERRUPTOR-NSBU SELLADO				
	11516166	.	A	B	B	B	O	O	O			1	970602			
Y	12450161	.	A	B	B	B	O	O	O			1	970602			
	[32]	(E)BOLT-HEXAGON (D)SCHRAUBE										(F)BOULON (S)PERNO				
	01130-08203	.	A	B	B	B	O	O	O			1				
	[33]	(E)LEVER A-TRANSMISSION (D)HEBEL,TRIEBWELLE										(F)LEVIER-TRANSMISSION (S)PALANCA-TRANSMISION				
	96182099	.	A	B	B	B	O	O	O			1				
	[34]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	09159-10003	.	A	B	B	B	O	O	O			1				
	[35]	(E)CABLE A-SELECTOR CONTROL (D)KABEL,WÄHLER										(F)CABLE-CONTROLE SELECTEUR (S)CABLE-CONTROL DE SELECTOR				
	96242556	.	A	B	B	B	O	O	O			1				TG
	[36]	(E)PLATE A-BASE (D)PLATTE,BODEN										(F)PLAQUE-BASE (S)PLACA-BASE				
	96228658	.	A	B	B	B	O	O	O			1				
	[37]	(E)WASHER-PLAIN (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	09160-08004	.	A	B	B	B	O	O	O			1				
	[38]	(E)PLUG-NSBU SWITCH (D)STÖPSEL										(F)BOUCHON (S)TAPON				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME													
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	96245741	.	A	B	B	B	O	O	O		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4 CHASSIS


4110 AXLE SHAFT UNIT
4120 AXLE SHAFT PARTS(M/T)
4121 AXLE SHAFT PARTS(A/T)
4130 KNUCKLE&HUB
4140 FRONT SHOCK ABSORBER
4150 CONTROL ARM
4310 REAR AXLE
4320 REAR SHOCK ABSORBER
4510 FRONT BRAKE
4520 REAR BRAKE
4530 PARKING BRAKE
4610 MASTER BRAKE UNIT
4620 MASTER CYLINDER&BOOSTER
4630 MASTER BRAKE MOUNT
4640 BRAKE PEDAL(LHD)
4650 BRAKE PIPE(NON ABS)
4651 BRAKE PIPE(ABS)
4710 ANTI LOCK BRAKE SYSTEM
4720 HYDRAULIC MODULATOR
4810 STEERING WHEEL
4820 STEERING COLUMN COVER
4830 NON TILT STEERING COLUMN
4831 TILTABLE STEERING COLUMN
4910 STEERING GEAR UNIT
4920 MANUAL STEERING GEAR PARTS(LHD)
4930 POWER STEERING GEAR PARTS
4940 TIE ROD
4950 POWER STEERING PIPE LINE



KEY NO.		PART NAME																
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)SHAFT A-FRT AXLE (D)SPINDEL,VORDER-ACHSE									(F)ARBRE-PONT AVANT (S)EJE-FRENTE					
	96229091	Y	M	B	B	B	S	S	S	-JL9	LH	1		970422		SM
Y	96251135	Y	M	B	B	B	S	S	S	-JL9	LH	1	970422			BR
	96183016	Y	M	B	B	B	.	O	O	&JL9	LH	1		970422		UM
Y	96251184	Y	M	B	B	B	.	O	O	&JL9	LH	1	970422			AV
	96238233	Y	A	B	B	B	O	O	O	-JL9	LH	1				LC
	96225969	Y	A	B	B	B	.	O	O	&JL9	LH	1				LQ
	96229093	6	M	B	B	B	.	.	O	-JL9	LH	1		970422		WM
Y	96251183	6	M	B	B	B	.	.	O	-JL9	LH	1	970422			AU
	96229095	6	M	B	B	B	.	.	O	&JL9	LH	1		970422		YM
Y	96241975	6	M	B	B	B	.	.	O	&JL9	LH	1	970422			GP
	96238235	6	A	B	B	B	.	.	O	-JL9	LH	1				CA
	96238237	6	A	B	B	B	.	.	O	&JL9	LH	1				CB
	[02]	(E)SHAFT A-FRT AXLE (D)SPINDEL,VORDER-ACHSE									(F)ARBRE-PONT AVANT (S)EJE-FRENTE					
	96229092	Y	M	B	B	B	S	S	S	-JL9	RH	1		970422		TM
Y	96251136	Y	M	B	B	B	S	S	S	-JL9	RH	1	970422			CR
	96183017	Y	M	B	B	B	.	O	O	&JL9	RH	1		970422		VM
Y	96251185	Y	M	B	B	B	.	O	O	&JL9	RH	1	970422			AW
	96238234	Y	A	B	B	B	O	O	O	-JL9	RH	1				RC
	96225970	Y	A	B	B	B	.	O	O	&JL9	RH	1				RQ
	96229094	6	M	B	B	B	.	.	O	-JL9	RH	1		970422		XM
Y	96241974	6	M	B	B	B	.	.	O	-JL9	RH	1	970422			FP
	96229096	6	M	B	B	B	.	.	O	&JL9	RH	1		970422		ZM


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4110 AXLE SHAFT UNIT



KEY NO. ITG	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
Y	96241977	6	M	B	B	B	.	.	O	&JL9	RH	1	970422			AQ
	96238236	6	A	B	B	B	.	.	O	&JL9	RH	1				RX
	96238238	6	A	B	B	B	.	.	O	&JL9	RH	1				RY


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)JOINT A-SEAL&C/V (D)GLIED,ABDICHTUNG									(F)JOINT-JOINT D'ETANCHEITE (S)UNION-SELLO Y C/V					
	96243569	Y	M	B	B	B	S	S	S	-JL9	LH	1		970422		
Y	96257804	Y	M	B	B	B	S	S	S	-JL9	LH	1	970422			
	96243571	Y	M	B	B	B	.	O	O	&JL9	LH	1		970422		
Y	96237803	Y	M	B	B	B	.	O	O	&JL9	LH	1	970422			
	96243573	6	M	B	B	B	.	.	O	-JL9	LH	1		970422		
Y	96257802	6	M	B	B	B	.	.	O	-JL9	LH	1	970422			
	96243575	6	M	B	B	B	.	.	O	&JL9	LH	1		970422		
Y	96257801	6	M	B	B	B	.	.	O	&JL9	LH	1	970422			
	[02]	(E)JOINT A-SEAL&C/V (D)GLIED,ABDICHTUNG									(F)JOINT-JOINT D'ETANCHEITE (S)UNION-SELLO Y C/V					
	96243569	Y	M	B	B	B	S	S	S	-JL9	RH	1		970422		
Y	96257804	Y	M	B	B	B	S	S	S	-JL9	RH	1	970422			
	96243571	Y	M	B	B	B	.	O	O	&JL9	RH	1		970422		
Y	96257803	Y	M	B	B	B	.	O	O	&JL9	RH	1	970422			
	96243573	6	M	B	B	B	.	.	O	-JL9	RH	1		970422		
Y	96257802	6	M	B	B	B	.	.	O	-JL9	RH	1	970422			
	96243575	6	M	B	B	B	.	.	O	&JL9	RH	1		970422		
Y	96257801	6	M	B	B	B	.	.	O	&JL9	RH	1	970422			
	[03]	(E)JOINT A-SEAL&C/G (D)GLIED,ABDICHTUNG									(F)JOINT-JOINT D'ETANCHEITE (S)UNION-SELLO Y C/V					
	96243576	.	M	B	B	B	S	S	S		LH	1				
	[04]	(E)JOINT A-SEAL&C/G (D)GLIED,ABDICHTUNG									(F)JOINT-JOINT D'ETANCHEITE (S)UNION-SELLO Y C/V					
	96243576	.	M	B	B	B	S	S	S		RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[05]																	(E)SEAL KIT-C/V JOINT (D)DICHTUNGS-SATZ,GLIED
	96243578	.	M	B	B	B	S	S	S			2					
[06]																	(E)SEAL KIT-C/G JOINT (D)DICHTUNGS-SATZ,GLIED
	96243579	.	M	B	B	B	S	S	S		LH	1					
[07]																	(E)SEAL KIT-C/G JOINT (D)DICHTUNGS-SATZ,GLIED
	96243579	.	M	B	B	B	S	S	S		RH	1					
[08]																	(E)SHAFT-AXLE (D)SPINDEL,ACHSE
	510842	.	M	B	B	B	S	S	S		LH	1					
[09]																	(E)SHAFT-AXLE (D)SPINDEL,ACHSE
	510843	.	M	B	B	B	S	S	S		RH	1					
[10]																	(E)SEAL-C/V JOINT (D)DICHTUNG
	510346	.	M	B	B	B	S	S	S			2					
[11]																	(E)SEAL-C/G JOINT (D)DICHTUNG,QUERRILLE GLIED
	510469	.	M	B	B	B	S	S	S			2					
[14]																	(E)CLAMP (D)KLAMMER
	510429	.	M	B	B	B	S	S	S			2			C/V JOINT		
[15]																	(E)CLAMP (D)KLAMMER
	510464	.	M	B	B	B	S	S	S			2			C/G JOINT		
[16]																	(E)CLAMP (D)KLAMMER

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4120 AXLE SHAFT PARTS(M/T)





ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	510430	.	M	B	B	B	S	S	S			2			C/V JOINT	
	[17]	(E)CLAMP (D)KLAMMER										(F)PINCE (S)ABRAZADERA				
	510466	.	M	B	B	B	S	S	S			2				
	[19]	(E)RING-JOINT RETAINING (D)RING,HALTER										(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR				
	510470	.	M	B	B	B	S	S	S			2				
	[20]	(E)RING-DEFLECTING (D)RING										(F)ANNEAU (S)ANILLO				
	510449	.	M	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



#2,4,5,6, IS SERVICED ONLY SET


KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)BOOT SET-INNER (D)KOFFERRAUM-SATZ									(F)TROUSSE DE GAINE (S)JUEGO DE BOTA					
96220401		.	A	B	B	B	O	O	O			2			INCL. #2	
[03]		(E)BOOT SET-OUTER (D)KOFFERRAUM-SATZ									(F)TROUSSE DE GAINE (S)JUEGO DE BOTA					
96220402		.	A	B	B	B	O	O	O			2			INCL. #2,4,5,6	
[07]		(E)JOINT SET-INNER (D)GLIED SATZ									(F)JEU DE JOINTS (S)JUEGO DE UNION					
96220403		.	A	B	B	B	O	O	O			2			INCL. #2,4,5	
[08]		(E)JOINT SET-OUTER (D)GLIED SATZ									(F)JEU DE JOINTS (S)JUEGO DE UNION					
96250527		Y	A	B	B	B	O	O	O	-JL9	LH	1			INCL. #2,4,5,6	
96250528		Y	A	B	B	B	O	O	O	-JL9	RH	1			INCL. #2,4,5,6	
96250525		Y	A	B	B	B	.	O	O	&JL9	LH	1			INCL. #2,4,5,6	
96250526		Y	A	B	B	B	.	O	O	&JL9	RH	1			INCL. #2,4,5,6	
96250521		6	A	B	B	B	.	.	O	-JL9	LH	1			INCL. #2,4,5,6	
96250522		6	A	B	B	B	.	.	O	-JL9	RH	1			INCL. #2,4,5,6	
96250523		6	A	B	B	B	.	.	O	&JL9	LH	1			INCL. #2,4,5,6	
96250524		6	A	B	B	B	.	.	O	&JL9	RH	1			INCL. #2,4,5,6	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)KNUCKLE A-STEERING (D)KNUCKLE,LENKUNG										(F)ARTICULATION-DIRECTION (S)NUDILLO-VOLANTE					
96219508	Y	.	B	B	B	S	S	S	-JL9	LH	1					
96219509	Y	.	B	B	B	S	S	S	-JL9	RH	1					
96219506	Y	.	B	B	B	.	O	O	&JL9	LH	1					
96219507	Y	.	B	B	B	.	O	O	&JL9	RH	1					
96219512	6	.	B	B	B	.	.	O	-JL9	LH	1					
96219513	6	.	B	B	B	.	.	O	-JL9	RH	1					
96219510	6	.	B	B	B	.	.	O	&JL9	LH	1					
96219511	6	.	B	B	B	.	.	O	&JL9	RH	1					
[02]	(E)COVER-SHEET (D)DECKEL,LENKUNG NUCKLE										(F)COUVERCLE (S)CUBIERTA-LAMINA					
96304481	Y	.	B	B	B	S	S	S	&JB3		2					
96176932	6	.	B	B	B	.	.	O	&JB4		2					
[03]	(E)RING-RETAINING (D)RING,HALTER										(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR					
09381-67001	Y	.	B	B	B	S	S	S	&JB3		4					
09381-75001	6	.	B	B	B	.	.	O	&JB4		4					
[04]	(E)BEARING (D)KUGELLAGER										(F)ROULEMENT-BILLE INCLINEE (S)COJINETE-BOLA INCLINADA					
09267-34001	Y	.	B	B	B	S	S	S	&JB3		2		970701			
Y 09267-34002	Y	.	B	B	B	S	S	S	&JB3		2		970701			
09267-39001	6	.	B	B	B	.	.	O	&JB4		2		970701			
Y 09267-39005	6	.	B	B	B	.	.	O	&JB4		2		970701			
[05]	(E)HUB-BRAKE DISK,FRONT (D)NABE,SCHEIBENBREMSE										(F)MOYEU-DISQUE DE FREIN (S)CUBO-FRENO DE DISCOS					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96176252	Y	.	B	B	B	S	S	S	&JB3		2				
	96162249	6	.	B	B	B	.	.	O	&JB4		2				
[06]	(E)DISK-VENTILATED BRAKE *(D)SCHEIBENBREMSE*											*(F)DISQUE-FREIN* *(S)DISCO-FRENO*				
	90121445	Y	.	B	B	B	S	S	S	&JB3		2				DV
	96179110	6	.	B	B	B	.	.	O	&JB4		2				DQ
[07]	(E)WASHER-PLAIN *(D)DICHTUNGSRING*											*(F)RONDELLE* *(S)ARANDELA*				
	09160-20001	.	.	B	B	B	S	S	S			2				
[08]	(E)NUT *(D)MUTTER*											*(F)ECROU* *(S)TUERCA*				
	09159-20004	.	.	B	B	B	S	S	S			2				
[10]	(E)SCREW *(D)SCHRAUBE*											*(F)VIS* *(S)TORNILLO*				
	02126-06103	.	.	B	B	B	S	S	S			2		970404		
Y	02126-06123	.	.	B	B	B	S	S	S			2	970404			
[11]	(E)SCREW *(D)SCHRAUBE*											*(F)VIS* *(S)TORNILLO*				
	02116-36103	.	.	B	B	B	S	S	S			6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]										(E)CAP-STRUT MOUNT (D)DECKEL,SPREIZE-MONTAGE					(F)CHAPEAU-MONTAGE TENDEUR (S)TAPA-MONTAJE DE PUNTAL	
90079044		.	.	B	B	B	S	S	S			2				
[02]										(E)NUT (D)MUTTER					(F)ECROU (S)TUERCA	
09159-12003		.	.	B	B	B	S	S	S			2				
[03]										(E)WASHER-PLAIN (D)DICHTUNGSRING					(F)RONDELLE (S)ARANDELA	
09160-12002		.	.	B	B	B	S	S	S			2				
[04]										(E)NUT-HEXAGON LOCK (D)MUTTER					(F)ECROU (S)TUERCA	
08311-38082		.	.	B	B	B	S	S	S			2				
[06]										(E)STRUT-SHOCK ABSOR MOUNT (D)STÜTZE					(F)TENDEUR (S)BRIDA-MONTAJE	
96225638		.	.	B	B	B	S	S	S			2				
[07]										(E)PLATE-BALL BEARING (D)PLATTE,KUGELLAGER					(F)PLAQUE-ROULEMENT A BILLES (S)PLACA-COJINETE DE BOLA	
90079042		.	.	B	B	B	S	S	S			2				
[08]										(E)SEAT A-SPRING,UPPER (D)SITZ,FEDERUNG,OBERE					(F)SIEGE-RESSORT,HAUT (S)ASIENTO-RESORTE,SUPERIOR	
96133096		.	.	B	B	B	S	S	S			2				
[09]										(E)SEAT A-SPRING,UPPER (D)SITZ,FEDERUNG,OBERE					(F)SIEGE-RESSORT,HAUT (S)ASIENTO-RESORTE,SUPERIOR	
96133097		.	.	B	B	B	S	S	S			2				
[10]										(E)LOCATOR-FRONT SPRING (D)FINDER,VORDERE FEDERUNG					(F)LOCALISATEUR (S)LOCALIZADOR	
90305062		.	.	B	B	B	S	S	S			2				
[11]										(E)RING-FR SPRING INSULATOR (D)RING					(F)ANNEAU (S)ANILLO-AISLADOR	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	90216299	.	.	B	B	B	S	S	S			2				
	[12]	(E)SPRING-FRONT *(D)FEDERUNG,VORDERE*										*(F)RESSORT-AVANT* *(S)RESORTE-FRENTE*				
	96223500	Y	M	B	B	B	S	S	S	&C46&F39		2				
	96223501	Y	M	B	B	B	A	A	A	&C46&F40		2				
	96232695	Y	M	B	B	B	O	O	O	&C59/C60&F39		2				
	96223502	Y	M	B	B	B	A	A	A	&C59/C60&F40		2				
	96223501	Y	A	B	B	B	O	O	O	&C46&F39		2				
	96223508	Y	A	B	B	B	A	A	A	&C46&F40		2				
	96223502	Y	A	B	B	B	O	O	O	&C59/C60&F39		2				
	96246623	Y	A	B	B	B	A	A	A	&C59/C60&F40		2				
	96223501	6	M	B	B	B	.	.	O	&C46&F39		2				
	96223508	6	M	B	B	B	.	.	A	&C46&F40		2				
	96223502	6	M	B	B	B	.	.	O	&C59/C60&F39		2				
	96246623	6	M	B	B	B	.	.	A	&C59/C60&F40		2				
	96223502	6	A	B	B	B	.	.	O	&C46&F39		2				
	96246623	6	A	B	B	B	.	.	A	&C46&F40		2				
	96223508	6	A	B	B	B	.	.	O	&C59/C60&F39		2				
	96246624	6	A	B	B	B	.	.	A	&C59/C60&F40		2				
	[13]	(E)BUMPER-HOLLOW *(D)STOßSTANGE,HOHL*										*(F)PARE-CHOC-EXCAVATION* *(S)TOPE-HUECO*				
	90142884	Y	.	B	B	B	S	S	S			2				
	90125889	6	.	B	B	B	.	.	O			2				
	[14]	(E)RING-THREADED *(D)RING,SCHRAUBENGEWINDE*										*(F)ANNEAU-FILETE* *(S)ANILLO-CON ROSCA*				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4140 FRONT SHOCK ABSORBER




KEY NO.	PART NAME																	
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	90063897	.	.	B	B	B	S	S	S			2				
		(E)CARTRIDGE-SHOCK ABSORBER										(F)CARTOUCHE-AMORTISSEUR				
	[15]	(D)KASSETTE,STOßDÄMPFER										(S)CARTUCHO-AMORTIGUADOR				
	96226992	.	.	B	B	B	S	S	S			2				
		(E)WASHER-PLAIN										(F)RONDELLE				
	[16]	(D)DICHTUNGSRING										(S)ARANDELA				
	09160-14005	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)ARM A-CONTROL (D)ARM,STEUERUNG									(F)BRAS-CONTROLE (S)BRAZO-CONTROL					
	96218397	.	.	B	B	B	S	S	S	&F39	LH	1				
	96218398	.	.	B	B	B	S	S	S	&F39	RH	1				
	96218399	.	.	B	B	B	A	A	A	&F40	LH	1				
	96218400	.	.	B	B	B	A	A	A	&F40	RH	1				
	[02]	(E)JOINT SET-CONTROL ARM BAL (D)GLIED SATZ,KONSTANT ARM									(F)JEU DE JOINTS (S)JUEGO DE UNION					
	94788122	.	.	B	B	B	S	S	S			2				
	[03]	(E)BUSHING-RR CONT ARM DAMPING (D)LAGERFUTTER									(F)COUSSINET (S)BUJE-AMORTIGUADOR					
	90235040	.	.	B	B	B	S	S	S			2				
	[04]	(E)BUSHING-FRT CONT ARM DAMPING (D)LAGERFUTTER									(F)MANCHON (S)BUJE-AMORTIGUADOR,FRENTE					
	96185973	.	.	B	B	B	S	S	S			2				
	[05]	(E)WASHER-PLAIN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	09160-14007	.	.	B	B	B	S	S	S			2				
	[06]	(E)NUT-HEXAGON LOCK (D)MUTTER									(F)ECROU (S)TUERCA					
	08311-28143	.	.	B	B	B	S	S	S			2				
	[07]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09100-14004	.	.	B	B	B	S	S	S			2				
	[08]	(E)PLATE (D)PLATTE									(F)PLAQUE (S)PLACA					
	90105063	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[09]	09100-08001	.	.	B	B	B	S	S	S	(E)BOLT-HEXAGON (D)SCHRAUBE		2			(F)BOULON (S)PERNO	
[10]	90209277	.	.	B	B	B	S	S	S	(E)PLATE-BUMPER (D)PLATTE,STOßSTANGE		8			(F)PLAQUE-PARE-CHOC (S)PLACA-PARACHOQUES	
[11]	02875013	.	.	B	B	B	S	S	S	(E)BUMPER-STABILIZER (D)STOßSTANGE,STABILISATOR		8			(F)PARE-CHOC-STABILISATEUR (S)TOPE-ESTABILIZADOR	
[12]	11087513	.	.	B	B	B	S	S	S	(E)TUBE (D)ROHRLEITUNG		2			(F)TUYAU OU TUBE (S)TUBO	
[13]	96226986	.	.	B	B	B	S	S	S	(E)STABILIZER-FRONT (D)STABILISATOR,VORNE		1			(F)STABILISATEUR-AVANT (S)ESTABLIZADOR-FRENTE	
[14]	09141-12001	.	.	B	B	B	S	S	S	(E)NUT (D)MUTTER		2			(F)ECROU (S)TUERCA	
[15]	90095298	.	.	B	B	B	S	S	S	(E)SPRING-RETAINING (D)FEDERUNG,HALTER		2			(F)RESSORT-D'ARRET (S)RESORTE-RETENIENDO	
[16]	90344190	.	.	B	B	B	S	S	S	(E)CAP-DAMPING BUSHING (D)DECKEL,DÄMPFUNGS-FUTTER		2			(F)CHAPEAU (S)TAPA-BUJE DE AMORTIGUADOR	
[17]	09103-10010	.	.	B	B	B	S	S	S	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE		4			(F)BOULON (S)PERNO	
[18]										(E)CLAMP-STABILIZER BUSHING (D)KLAMMER					(F)PINCE (S)ABRAZADERA-BUJE	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	96230714	.	.	B	B	B	S	S	S		2				
	[19]	(E)BOLT-HEXAGON									(F)BOULON				
		(D)SCHRAUBE									(S)PERNO				
	09100-10003	.	.	B	B	B	S	S	S		4				
	[20]	(E)BUSHING-STABILIZER BAR									(F)MANCHON-STABILISATEUR				
		(D)LAGERFUTTER,STABILISATOR									(S)BUJE-ESTABILIZADOR				
	96227420	.	.	B	B	B	S	S	S		2	970701			
O	96246674	.	.	B	B	B	S	S	S		2	970701			
	[21]	(E)NUT-HEXAGON LOCK									(F)ECROU				
		(D)MUTTER									(S)TUERCA				
	08311-28082	.	.	B	B	B	S	S	S		2				
	[22]	(E)BOLT-HEXAGON									(F)BOULON				
		(D)SCHRAUBE									(S)PERNO				
	09100-10020	.	.	B	B	B	S	S	S		3				
	[23]	(E)NUT-HEXAGON LOCK									(F)ECROU				
		(D)MUTTER									(S)TUERCA				
	09159-10016	.	.	B	B	B	S	S	S		3				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)AXLE A-REAR (D)ACHSE,HINTEN									(F)PONT-ARRIERE (S)EJE-TRASERO					
[01]	96219577	.	.	B	B	B	S	S	S			1				
[02]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
[02]	09100-12015	.	.	B	B	B	S	S	S			2				
[03]		(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
[03]	09159-12011	.	.	B	B	B	S	S	S			2				
[04]		(E)STABILIZER-REAR (D)STABILISATOR,HINTEN									(F)STABILISATEUR-ARRIERE (S)ESTABILIZADOR-TRASERO					
[04]	96208559	.	.	B	B	B	S	S	S			1				EE
[05]		(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
[05]	09100-10015	.	.	B	B	B	S	S	S			2				
[06]		(E)WASHER-SPRING (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
[06]	09162-10002	.	.	B	B	B	S	S	S			2				
[07]		(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
[07]	09159-10008	.	.	B	B	B	S	S	S			2				
[08]		(E)BUSHING-REAR AXLE DAMPING (D)LAGERFUTTER									(F)COUSSINET (S)BUJE-AMORTIGUADOR					
[08]	90189050	.	.	B	B	B	S	S	S			2				
[09]		(E)SPINDLE A-WHEEL BEARING (D)SPINDEL									(F)ROULEMENT PALIER (S)EJE					
[09]	96115666	.	.	B	B	B	S	S	S	-JL9		2				
[10]		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09119-10007	.	.	B	B	B	S	S	S	-JL9		8				
[11]	(E)NUT (D)MUTTER											(F)ECROU (S)TUERCA				
	09159-10010	.	.	B	B	B	S	S	S	-JL9		8				
[12]	(E)DAMPER-STABILIZER (D)DÄMPFER,STABILISATOR											(F)AMORTISSEUR-STABILISATEUR (S)AMORTIGUADOR				
	96208560	.	.	B	B	B	S	S	S			1				
[13]	(E)SEAL (D)DICHTUNG											(F)JOINT D'ETANCHEITE (S)SELLO				
	09283-40001	.	.	B	B	B	S	S	S	-JL9		2				
[14]	(E)BEARING (D)KUGELLAGER											(F)ROULEMENT (S)COJINETE				
	09265-29001	.	.	B	B	B	S	S	S	-JL9		2				
[15]	(E)BEARING-OUTER (D)KUGELLAGER,AUßEN											(F)ROULEMENT,EXTERIEUR (S)COJINETE,EXTERIOR				
	09265-17201	.	.	B	B	B	S	S	S	-JL9		2				
[16]	(E)WASHER (D)DICHTUNGSRING											(F)RONDELLE (S)ARANDELA				
	09166-16001	.	.	B	B	B	S	S	S	-JL9		2				
[17]	(E)NUT (D)MUTTER											(F)ECROU (S)TUERCA				
	09141-16001	.	.	B	B	B	S	S	S	-JL9		2				
[18]	(E)PIN-COTTER (D)STIFT											(F)BROCHE (S)PASADOR				
	09204-03001	.	.	B	B	B	S	S	S	-JL9		2				
[19]	(E)CAP-HUB (D)DECKEL,HÜLSE											(F)CHAPEAU-MOYEU (S)TAPA-CUBO				
	06696899	.	.	B	B	B	S	S	S	-JL9		2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO	
	[20]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA			
	09408-00068	. .	B	B	B	.	O	O	&JL9			3			
	[21]	(E)BEARING-INNER (D)KUGELLAGER,INNEN										(F)ROULEMENT,INTERNE (S)COJINETE-INTERNO			
	09265-17101	. .	B	B	B	S	S	S	-JL9			2			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)CAP-COVER *(D)DECKEL*										*(F)CHAPEAU* *(S)TAPA- AMORTIGUADOR*				
	96249401	.	.	.	B	B	S	.	S			2				
[02]		(E)NUT *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	09159-10003	.	.	B	B	B	S	S	S			2				
[03]		(E)PLATE-BUMPER,UPPER&LOWER *(D)PLATTE,STOßSTANGE*										*(F)PLAQUE* *(S)PLACA-PARACHOQUES*				
	90343956	.	.	B	B	B	S	S	S			4				
[04]		(E)BUMPER-SHOCK ABS,UPPER *(D)STOßSCHEIBE*										*(F)PARE-CHOC* *(S)TOPE-AMORTIGUADOR,INF*				
	96231921	.	.	B	B	B	S	S	S			2				
[05]		(E)BUMPER-SHOCK ABS,LOWER *(D)STOßSCHEIBE*										*(F)PARE-CHOC-AMORTISSEUR,BAS* *(S)TOPE-AMORTIGUADOR,SUP*				
	96231922	.	.	B	B	B	S	S	S			2	970807			
O	96246673	.	.	B	B	B	S	S	S			2	970807			
[06]		(E)SPACER *(D)DISTANZSTÜCK*										*(F)ENTRETOISE* *(S)ESPACIADOR*				
	96231920	.	.	B	B	B	S	S	S			2				
[07]		(E)ABSORBER A-SHOCK *(D)STOßDÄMPFER*										*(F)AMORTISSEUR* *(S)AMORTIGUADOR CHOQUE*				
	96226990	.	.	B	B	B	S	S	S	&F39		2				XA
	96246626	.	.	B	B	B	A	A	A	&F40		2				XB
[08]		(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09111-10003	.	.	B	B	B	S	S	S			2				
[09]		(E)BUMPER-REAR AXLE *(D)STOßSTANGE,HINTERE ACHSE*										*(F)PARE-CHOC-PONT ARRIERE* *(S)TOPE-EJE TRASERO*				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4320 REAR SHOCK ABSORBER



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96179844	.	.	B	B	B	S	S	S			2				
	[10]	(E)SPRING-REAR (D)FEDERUNG,HINTEN													(F)RESSORT-ARRIERE (S)RESORTE-TRASERO	
	96226988	.	.	B	B	B	S	S	S	&F39		2				GG
	96099946	.	.	B	B	B	A	A	A	&F40		2				BO
	[11]	(E)RING-RR SPRING INSULATING (D)RING, ISOLIERUNG													(F)ANNEAU (S)ANILLO-AISLAMIENTO	
	90305263	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4510 FRONT BRAKE



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)CALIPER A-BRAKE SLIDING (D)TASTER,BREMS-GLEIT									(F)CALIBRE-FREIN COULISSANT (S)CALIBRADOR-DESLIZADOR					
[01]																
	96234339	Y	.	B	B	B	S	S	S	&JB3	LH	1			13INCH,VENT	VL
	96234340	Y	.	B	B	B	S	S	S	&JB3	RH	1			13INCH,VENT	VR
	96304482	6	.	B	B	B	.	.	O	&JB4	LH	1			14INCH,VENT	LD
	96304433	6	.	B	B	B	.	.	O	&JB4	RH	1			14INCH,VENT	RD
		(E)PROTECTOR-BLEEDER SCREW (D)SCHUTZTEIL									(F)PROTECTION (S)PROTECTOR					
[03]																
	410350	.	.	B	B	B	S	S	S			2				
		(E)SCREW-BLEEDER (D)SCHRAUBE									(F)VIS (S)TORNILLO					
[04]																
	2007023	.	.	B	B	B	S	S	S			2				
		(E)PIN KIT (D)STIFT									(F)BROCHE (S)PASADOR					
[05]																
	S4511003	.	.	B	B	B	S	S	S			1				
		(E)BOOT-PIN (D)KOFFERRAUM									(F)GAINE (S)CAPUCHON					
[06]																
	410410	.	.	B	B	B	S	S	S			4				
		(E)BOLT-PIN (D)SCHRAUBE									(F)BOULON (S)PERNO					
[07]																
	2006010	.	.	B	B	B	S	S	S			4				
		(E)SPRING-PAD (D)FEDERUNG									(F)RESSORT (S)RESORTE					
[13]																
	410515	Y	.	B	B	B	S	S	S	&JB3		4				
	410415	6	.	B	B	B	.	.	O	&JB4		4				
		(E)SEAL KIT-PISTON (D)DICHTUNG									(F)JOINT D'ETANCHEITE (S)SELLO					
[14]																
	S4510008	Y	.	B	B	B	S	S	S	&JB3		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4510 FRONT BRAKE





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	S4511005	6	.	B	B	B	.	.	O	&JB4		1				
[17]	(E)PISTON (D)KOLBEN											(F)PISTON (S)PISTON				
	410507	Y	.	B	B	B	S	S	S	&JB3		2				
	410807	6	.	B	B	B	.	.	O	&JB4		2				
[18]	(E)PAD SET-BRAKE (D)UNTERLAGE-SATZ											(F)JEU DE PATINS-FREIN AVANT (S)JUEGO DE COJIN-FRENOS				
	S4510004	Y	.	B	B	B	S	S	S	&JB3		1				
	S4510005	6	.	B	B	B	.	.	O	&JB4		1				
[19]	(E)SHIM-ANTI NOISE (D)AUSGLEICHSSCHEIBE											(F)CALE DE SUPPORT (S)CUÑA				
	410513	Y	.	B	B	B	S	S	S	&JB3		4				
	410413	6	.	B	B	B	.	.	O	&JB4		4				
[20]	(E)COVER-SHIM (D)DECKEL											(F)CARTER (S)CUBIERTA				
	410517	Y	.	B	B	B	S	S	S	&JB3		2				
	410417	6	.	B	B	B	.	.	O	&JB4		2				
[22]	(E)BOLT (D)SCHRAUBE											(F)BOULON (S)PERNO				
	09106-12002	.	.	B	B	B	S	S	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4520 REAR BRAKE








KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX						
												FROM	TO		
	[01]	(E)BRAKE A-REAR *(D)BREMSE,HINTEN*								*(F)FREIN-ARRIERE* *(S)FRENO-TRASERO*					
	96304439	Y	.	B	B	B	S	S	S		LH	1		Φ 17.46	ML
	96304440	Y	.	B	B	B	S	S	S		RH	1		Φ 17.46	MR
	96304443	6	.	B	B	B	.	.	O		LH	1		Φ 19.05	DL
	96304444	6	.	B	B	B	.	.	O		RH	1		Φ 19.05	DR
	[02]	(E)PLATE-BRAKE BACKING *(D)PLATTE,BREMS RÜCKEN*								*(F)PLAQUE-FOND DE FREIN* *(S)PLACA-FRENO DE REVERSA*					
	96233628	.	.	B	B	B	S	S	S		LH	1			
	96233629	.	.	B	B	B	S	S	S		RH	1			
	[03]	(E)CYLINDER-BRAKE WHEEL *(D)ZYLINDER,BREMSRAD*								*(F)CYLINDRE-FREIN ROUE* *(S)CILINDRO-RUEDA FRENO*					
	90235420	Y	.	B	B	B	S	S	S			2			
	90235422	6	.	B	B	B	.	.	O			2			
	[04]	(E)DUST CAP *(D)STAUBDECKEL*								*(F)CHAPEAU-POUSSIERE* *(S)TAPA-POLVO*					
	06620325	.	.	B	B	B	S	S	S			2			
	[05]	(E)JET *(D)DUESE*								*(F)JET* *(S)SURTIDOR*					
	09493-02001	.	.	B	B	B	S	S	S			2			
	[06]	(E)CAP-BRAKE WHEEL CYLINDER *(D)DECKEL,BREMS-RAD-ZYLINDER*								*(F)CHAPEAU* *(S)TAPA-CILINDRO DE RUEDA*					
	96179002	Y	.	B	B	B	S	S	S			4			
	96179003	6	.	B	B	B	.	.	O			4			
	[07]	(E)PISTON-WHEEL CYLINDER *(D)KOLBEN,RAD ZYLINDER*								*(F)PISTON* *(S)PISTON-CILINDRO DE FRENO*					
	90168036	Y	.	B	B	B	S	S	S			4			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	90168037	6	.	B	B	B	.	.	O			4				
	[08]	(E)CUFF-WHEEL CYLINDER (D)HÜLSEN. BREMSTROMMEL													(F)MANCHETTE (S)PUÑO-CILINDRO DE RUEDA	
	90168030	Y	.	B	B	B	S	S	S			4				
	90168031	6	.	B	B	B	.	.	O			4				
	[09]	(E)BODY-CYLINDER (D)ZYLINDER,KÖRPER													(F)CYLINDRE-CORPS (S)CILINDRO-CUERPO	
	N/S(3)															
	[10]	(E)SPRING-COMPRESSION (D)FEDERUNG,VERDICHTUNG													(F)RESSORT-COMPRESSION (S)RESORTE-COMPRESION	
	90189461	Y	.	B	B	B	S	S	S			2				
	90189462	6	.	B	B	B	.	.	O			2				
	[12]	(E)PLUG (D)STÖPSEL													(F)BOUCHON (S)TAPON	
	90063579	.	.	B	B	B	S	S	S			4				
	[14]	(E)SCREW (D)SCHRAUBE													(F)VIS (S)TORNILLO	
	11046532	.	.	B	B	B	S	S	S			2				
	[15]	(E)READJUSTING UNIT (D)NEU-EINSTELLUNG EINHEIT													(F)UNITE DE REAJUSTEMENT (S)UNIDAD DE REAJUSTE	
	90199718	.	.	B	B	B	S	S	S			LH 1				
	90199719	.	.	B	B	B	S	S	S			RH 1				
	[16]	(E)SPRING-EXTENSION (D)FEDERUNG,VERLÄNGERUNG													(F)RESSORT-EXTENSION (S)RESORTE-EXTENSION	
	96179133	.	.	B	B	B	S	S	S			2				
	[18]	(E)SHOE A-BRAKE,FRONT (D)SCHUH,BREMS-VORNE													(F)SABOT-FREIN,AVANT (S)ZAPATA-FRENO,DELANTERO	
	96241681	Y	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4520 REAR BRAKE








KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96226105	6	.	B	B	B	.	.	O			2				
	[19]	(E)SHOE A-BRAKE,REAR (D)SCHUH,BREMS-HINTEN										(F)SABOT-FREIN,ARRIERE (S)ZAPATA-FRENO,TRASERO				
	96241679	Y	.	B	B	B	S	S	S		LH	1				
	96241680	Y	.	B	B	B	S	S	S		RH	1				
	96226101	6	.	B	B	B	.	.	O		LH	1				
	96226103	6	.	B	B	B	.	.	O		RH	1				
	[20]	(E)PIN-RETAINING SPRING (D)STIFT,HALTER-FEDERUNG										(F)BROCHE (S)PASADOR-RESORTE RETENEDOR				
	06638956	.	.	B	B	B	S	S	S			4				
	[21]	(E)SPRING-COMPRESSION (D)FEDERUNG,VERDICHTUNG										(F)RESSORT-COMPRESSION (S)RESORTE-COMPRESION				
	06681527	.	.	B	B	B	S	S	S			4				
	[22]	(E)PLATE-SECURING SPRING (D)PLATTE										(F)PLAQUE-RESSORT D'ATTACHE (S)PLACA-RESORTE DE ASEGURAR				
	06663706	.	.	B	B	B	S	S	S			4				
	[23]	(E)SHOE SET-BRAKE,REAR (D)SCHUH SATZ,BREMS-,HINTEN										(F)JEU DE SABOTS-FREIN (S)JUEGO DE ZAPATO-FRENO				
	S4520003	Y	.	B	B	B	S	S	S			1				
	96226110	6	.	B	B	B	.	.	O			1				
	[24]	(E)DRUM-BRAKE (D)BREMSTROMMEL										(F)TAMBOUR-FREIN (S)TAMBOR-TORNILLO				
	96193771	.	.	B	B	B	S	S	S	-JL9		2			W/HUB	
	96175281	.	.	B	B	B	.	O	O	&JL9		2			WO/HUB	
	[25]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	02126-06123	.	.	B	B	B	.	O	O	&JL9		2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



9	10	11
		

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	[01]									(E)LEVER A-PARKING BRAKE *(D)HEBEL,HANDBREMSE*					*(F)LEVIER-FREIN DE SECOURS* *(S)PALANCA*		
	96304484	.	.	B	B	B	S	S	S			1					
	[02]									(E)CABLE A-PARKING LEVER *(D)KABEL*					*(F)CABLE* *(S)CABLE*		
	96232674	.	.	B	B	B	S	S	S			1					
	[03]									(E)NUT *(D)MUTTER*					*(F)ECROU* *(S)TUERCA*		
	09159-06010	.	.	B	B	B	S	S	S			1					
	[04]									(E)SWITCH A-P/BRAKE WARNING *(D)SCHALTER*					*(F)COMMUTATEUR* *(S)INTERRUPTOR*		
	90087504	.	.	B	B	B	S	S	S			1					
	[05]									(E)BOLT-HEXAGON *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*		
	01137-05102	.	.	B	B	B	S	S	S			1					
	[06]									(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*		
	01517-08163	.	.	B	B	B	S	S	S			2					
	[07]									(E)CABLE A-PARKING BRAKE *(D)KABEL,HANDBREMSE*					*(F)FREIN DE SECOURS* *(S)CABLE*		
	96230545	.	.	B	B	B	S	S	S		LH	1					
	[08]									(E)CABLE A-PARKING BRAKE *(D)KABEL,HANDBREMSE*					*(F)FREIN DE SECOURS* *(S)CABLE*		
	96245829	.	.	B	B	B	S	S	S		RH	1					
	[09]									(E)CLAMP-PRESSURE HOSE *(D)KLAMMER*					*(F)PINCE* *(S)ABRAZADERA*		
	90111423	.	.	B	B	B	S	S	S			1					
	[10]									(E)NUT-HEXAGON *(D)MUTTER*					*(F)ECROU* *(S)TUERCA*		


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



9	10	11
		


KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	08361-25063	.	.	B	B	B	S	S	S			7				
	[11]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	96308272	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME													
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)CYLINDER A-BRAKE MASTER (D)ZYLINDER,HAUPT									(F)CYLINDRE-MAITRE (S)CILINDRO-MAESTRO					
	96306181	Y	M	B	B	B	S	S	S	-JL9		1			Φ 20.64	TA
	96306182	Y	M	B	B	B	.	O	O	&JL9		1			Φ 20.64	TC
	96228915	Y	A	B	B	B	O	O	O	-JL9		1			Φ 20.64	TB
	96228918	Y	A	B	B	B	.	O	O	&JL9		1			Φ 20.64	TD
	96306184	6	M	B	B	B	.	.	O	-JL9		1			Φ 22.22	TE
	96306183	6	M	B	B	B	.	.	O	&JL9		1			Φ 22.22	TG
	96228924	6	A	B	B	B	.	.	O	-JL9		1			Φ 22.22	TF
	96228921	6	A	B	B	B	.	.	O	&JL9		1			Φ 22.22	TH

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)CYLINDER A - MASTER *(D)ZYLINDER,HAUPT*										*(F)CYLINDRE-MAITRE* *(S)CILINDRO-MAESTRO*				
	426505	Y	M	B	B	B	S	S	S	-JL9		1				
	426503	Y	M	B	B	B	.	O	O	&JL9		1				
	426506	Y	A	B	B	B	O	O	O	-JL9		1				
	426504	Y	A	B	B	B	.	O	O	&JL9		1				
	426570	6	M	B	B	B	.	.	O	-JL9		1				
	426507	6	M	B	B	B	.	.	O	&JL9		1				
	426571	6	A	B	B	B	.	.	O	-JL9		1				
	426508	6	A	B	B	B	.	.	O	&JL9		1				
	[02]	(E)CAP-RESERVOIR *(D)DECKEL,BEHÄLTER*										*(F)CHAPEAU-RESERVOIR* *(S)TAPA-RESERVA*				
	426495	.	.	B	B	B	S	S	S			1				
	[03]	(E)BODY-RESERVOIR *(D)KAROSSERIE,BEHÄLTER*										*(F)CORPS-RESERVOIR* *(S)CARROCERIA-EMBALSE*				
	426475	.	M	B	B	B	S	S	S			1				
	426499	.	A	B	B	B	O	O	O			1				
	[04]	(E)SEAL-RESERVOIR *(D)DICHTUNG,BEHÄLTER*										*(F)JOINT-RESERVOIR* *(S)SELLO-RESERVA*				
	3492377	.	.	B	B	B	S	S	S			2				
	[05]	(E)BODY-MASTER CYLINDER *(D)KAROSSERIE,HAUPTZYLINDER*										*(F)CORPS-CYLINDRE PRINCIPAL* *(S)CARROCERIA-CILINDRO*				
N/S(9)																
	[06]	(E)PISTON&SEAL KIT *(D)KOLBEN&VERDICHTUNGS-SATZ*										*(F)PISTON&TROUSSE DE JOINT* *(S)JUEGO DE PISTON Y SELLO*				
	3492436	Y	.	B	B	B	S	S	S			1				
	3492355	6	.	B	B	B	.	.	O			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[07]	(E)PROPORTIONER-BRAKE (D)PROPORTIONIERUNG,BREMSE									(F)DOSEUR-FREIN (S)PROPORCIONADOR-FRENO					
	3488967	Y	.	B	B	B	S	S	S	-JL9		2				
	426120	6	.	B	B	B	.	.	O	-JL9		2				
	[09]	(E)CYLINDER SUB A-MASTER (D)UNTER-ZYLINDER HAUPT									(F)CYLINDRE SUB-MAITRE (S)CILINDRO SUB-MAESTRO					
	426382	Y	.	B	B	B	S	S	S	-JL9		1				
	426383	Y	.	B	B	B	.	O	O	&JL9		1				
	426253	6	.	B	B	B	.	.	O	-JL9		1				
	426299	6	.	B	B	B	.	.	O	&JL9		1				
	[10]	(E)BOOSTER-BRAKE (D)BREMSVERSTÄRKER									(F)SURPRESSEUR-FREIN (S)SERVO-FRENO					
	426589	.	.	B	B	B	S	S	S			1				
	[11]	(E)BOOT-BRAKE BOOSTER (D)KOFFERRAUM									(F)GAINE (S)CAPUCHON-SERVO DE FRENO					
	3492912A	.	.	B	B	B	S	S	S			1				
	[12]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	09159-10002	.	.	B	B	B	S	S	S			1				
	[13]	(E)SPRING-RETAINING (D)FEDERUNG,HALTER									(F)RESSORT-D'ARRET (S)RESORTE-RETENIENDO					
	90184913	.	.	B	B	B	S	S	S			1				
	[14]	(E)ADJUSTER (D)EINSTELLVORRICHTUNG									(F)AJUSTEUR (S)AJUSTADOR					
	90184914	.	.	B	B	B	S	S	S			1				
	[15]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	2909253	.	.	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[16]	(E)SEAL-FRONT HOUSING (D)DICHTUNG,VORDER-GEHÄUSE								(F)JOINT-LOGEMENT AVANT (S)SELLO-CARTER DEL FRENTE						
	03488577	.	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4630 MASTER BRAKE MOUNT



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)BRACE-MASTER BRAKE UNIT *(D)SCHIENE,HAUPTBREMSE*								*(F)SUPPORT* *(S)REFUERZO*						
90184911		.	.	B	B	B	S	S	S			1				
[02]		(E)BRACE-MASTER BRAKE UNIT *(D)SCHIENE,HAUPTBREMSE*								*(F)SUPPORT* *(S)REFUERZO*						
90184912		.	.	B	B	B	S	S	S			1				
[03]		(E)STRUT-TENSION *(D)STÜTZE,SPANNUNG*								*(F)TENDEUR-TENSION* *(S)BRIDA-TENSION*						
96243317		.	.	B	B	B	S	S	S			1				
[04]		(E)WASHER-PLAIN *(D)DICHTUNGSRING*								*(F)RONDELLE* *(S)ARANDELA*						
08322-11083		.	.	B	B	B	S	S	S			3				
[05]		(E)NUT-HEXAGON *(D)MUTTER*								*(F)ECROU* *(S)TUERCA*						
08310-11083		.	.	B	B	B	S	S	S			4				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)PEDAL A-BRAKE *(D)PEDAL,BREMSE*									*(F)PEDALE-FREIN* *(S)PEDAL-FRENO*					
96306187		.	M	B	B	B	S	S	S	-EC1		1				PA
96250892		.	M	B	B	B	A	A	A	&EC1		1				PE
96306149		.	A	B	B	B	O	O	O	-EC1		1				PB
96250893		.	A	B	B	B	A	A	A	&EC1		1				PF
[02]		(E)DISK-INSULATION *(D)SCHEIBE,ISOLIERUNG*									*(F)DISQUE-ISOLATION* *(S)DISCO-AISLAMIENTO*					
96156393		.	.	B	B	B	S	S	S			3				
[03]		(E)NUT *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
09159-08003		.	.	B	B	B	S	S	S			5				
[04]		(E)BRACE A-BRAKE PEDAL *(D)SCHIENE,BREMSPEDAL*									*(F)SUPPORT-MONTAGE PEDALE* *(S)REFUERZO*					
96306185		.	.	B	B	B	S	S	S			1				
[05]		(E)NUT *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
09159-10007		.	.	B	B	B	S	S	S			1				
[07]		(E)SHAFT-PEDAL MOUNTING *(D)SPINDEL,PEDAL MONTAGE*									*(F)ARBRE-MONTAGE PEDALE* *(S)EJE-MONTAJE DE PEDAL*					
96215326		.	.	B	B	B	S	S	S			1				
[08]		(E)SPRING *(D)FEDERUNG,PEDAL MONTAGE*									*(F)RESSORT* *(S)RESORTE*					
09448-24001		.	.	B	B	B	S	S	S			1				
[09]		(E)PEDAL-BRAKE *(D)PEDAL,BREMSE*									*(F)PEDALE-FREIN* *(S)PEDAL-FRENO*					
96192176															NOT APPLIED	
96193094		.	M	B	B	B	S	S	S	-EC1		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4640 BRAKE PEDAL(LHD)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96289190	.	M	B	B	B	A	A	A	&EC1		1				
	96192177														NOT APPLIED	
	96193095	.	A	B	B	B	O	O	O	-EC1		1				
	96289191	.	A	B	B	B	A	A	A	&EC1		1				
[10]	(E)COVER-PEDAL PLATE (D)UNTERLAGE,BERMSPEDAL														(F)PATIN-PEDALE DE FREIN (S)COJIN-PEDAL DE FRENO	
	90105172	.	M	B	B	B	S	S	S			1				
	90135701	.	A	B	B	B	O	O	O			1				
[11]	(E)BRACKET-BRAKE PEDAL BRACE (D)TRÄGER														(F)SUPPORT (S)SOPORTE	
	96306186	.	.	B	B	B	S	S	S			1				
[12]	(E)WASHER-PLAIN (D)DICHTUNGSRING														(F)RONDELLE (S)ARANDELA	
	09160-08002	.	.	B	B	B	S	S	S			1				
[13]	(E)NUT-HEXAGON LOCK (D)MUTTER														(F)ECROU (S)TUERCA	
	08311-18083	.	.	B	B	B	S	S	S			1				
[14]	(E)SWITCH A-STOP LAMP (D)SCHALTER,STOP-LAMPE														(F)COMMUTATEUR-LAMPE D'ARRET (S)INTERRUPTOR	
	96212027	.	.	B	B	B	S	S	S			1				
[15]	(E)ROD A-PISTON (D)KOLBENSTANGE														(F)TRINGLE-PISTON (S)VARILLA-PISTON	
	90289187	.	.	B	B	B	S	S	S			1				
[16]	(E)PIN (D)STIFT														(F)BROCHE (S)PASADOR	
	09208-10001	.	.	B	B	B	S	S	S			1				
[17]	(E)RING-RETAINING E TYPE (D)RING,HALTER														(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4640 BRAKE PEDAL(LHD)



KEY NO.		PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	08332-21089	.	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	PICODE
[01]		(E)PIPE A-BRAKE,FRONT *(D)ROHR,BREMSE,VORDERE*													*(F)TUYAU-FREIN,AVANT* *(S)TUBERIA-FRENO,DELANTERO*	
	96306678	.	.	B	B	B	S	S	S	-JL9	LH	1				NF
[02]		(E)PIPE A-BRAKE,FRONT *(D)ROHR,BREMSE,VORDERE*													*(F)TUYAU-FREIN,AVANT* *(S)TUBERIA-FRENO,DELANTERO*	
	96248672	.	.	B	B	B	S	S	S	-JL9	RH	1				
[03]		(E)PIPE A-BRAKE, REAR,1ST *(D)ROHR,BREMSE,HINTERE*													*(F)TUYAU-FREIN,ARRIERE* *(S)TUBERIA-FRENO,TRASERO*	
	96248673	.	.	B	B	B	S	S	S	-JL9	LH	1				
[04]		(E)PIPE A-BRAKE, REAR,1ST *(D)ROHR,BREMSE,HINTERE*													*(F)TUYAU-FREIN,ARRIERE* *(S)TUBERIA-FRENO,TRASERO*	
	96248674	.	.	B	B	B	S	S	S	-JL9	RH	1	970609			
N	96256672	.	.	B	B	B	S	S	S	-JL9	RH	1	970609			
[05]		(E)PIPE A-BRAKE, REAR,2ND *(D)ROHR,BREMSE,HINTERE*													*(F)TUYAU-FREIN,ARRIERE* *(S)TUBERIA-FRENO,TRASERO*	
	96304479	.	.	B	B	B	S	S	S	-JL9	LH	1				NU
[06]		(E)PIPE A-BRAKE, REAR,2ND *(D)ROHR,BREMSE,HINTERE*													*(F)TUYAU-FREIN,ARRIERE* *(S)TUBERIA-FRENO,TRASERO*	
	96306168	.	.	B	B	B	S	S	S	-JL9	RH	1	970609			NW
N	96256676	.	.	B	B	B	S	S	S	-JL9	RH	1	970609			
[07]		(E)PIPE A-BRAKE,REAR,3RD *(D)ROHR,BREMSE,HINTERE*													*(F)TUYAU-FREIN,ARRIERE* *(S)TUBERIA-FRENO,TRASERO*	
	96237761	.	.	B	B	B	S	S	S	-JL9	LH	1				NV
[08]		(E)HOSE A-BRAKE,REAR *(D)SCHLAUCH,BREMSE,HINTEN*													*(F)TUYAU-FREIN,ARRIERE* *(S)MANGUERA-FRENO,TRASERO*	
	96215570	.	.	B	B	B	S	S	S	-JL9		2				
[09]		(E)PIPE A-BRAKE,REAR *(D)ROHR,BREMSE,HINTERE*													*(F)TUYAU-FREIN,ARRIERE* *(S)TUBERIA-FRENO,TRASERO*	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4650 BRAKE PIPE(NON ABS)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96306664	.	.	B	B	B	S	S	S	JL9	LH	1				
	96306666	.	.	B	B	B	S	S	S	JL9	RH	1				
[11]	(E)E RING (D)RING											(F)ANNEAU (S)ANILLO				
	09383-12003	.	.	B	B	B	S	S	S	JL9		4				
[12]	(E)E RING (D)RING											(F)ANNEAU (S)ANILLO				
	09383-12003	.	.	B	B	B	S	S	S	JL9		2				
[13]	(E)BOLT-HEXAGON (D)SCHRAUBE											(F)BOULON (S)PERNO				
	02714-06163	.	.	B	B	B	S	S	S	JL9		3				
[14]	(E)HOSE A-BRAKE,FRONT (D)SCHLAUCH,BREMSE,VORNE											(F)TUYAU-FREIN,AVANT (S)MANGUERA-FRENO,FRENTE				
	96212323	.	.	B	B	B	S	S	S	JL9		2				
[15]	(E)WASHER-PLAIN (D)DICHTUNGSRING											(F)RONDELLE (S)ARANDELA				
	09160-10002	.	.	B	B	B	S	S	S	JL9		4				
[16]	(E)BOLT-UNION (D)SCHRAUBE											(F)BOULON (S)PERNO				
	09360-10002	.	.	B	B	B	S	S	S	JL9		2				
[20]	(E)CLIP (D)KLEMME											(F)ATTACHE (S)GRAPA				
	09409-07328	.	.	B	B	B	S	S	S	JL9		2				
[21]	(E)CLIP (D)KLEMME											(F)ATTACHE (S)GRAPA				
	09408-00082	.	.	B	B	B	S	S	S	JL9		5				
[22]	(E)CLIP (D)KLEMME											(F)ATTACHE (S)GRAPA				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	09408-00006	.	.	B	B	B	S	S	S	-JL9		4				
	[23]	(E)CLIP A (D)KLEMME										(F)ATTACHE (S)GRAPA				
	96304429	.	.	B	B	B	S	S	S	-JL9		3				
	[26]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09408-00007	.	.	B	B	B	S	S	S	-JL9		2				
	[27]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09408-00008	.	.	B	B	B	S	S	S	-JL9		1				
	[28]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09408-00009	.	.	B	B	B	S	S	S	-JL9		1				
	[31]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09408-00079	.	.	B	B	B	S	S	S	-JL9		1				
	[32]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09408-00080	.	.	B	B	B	S	S	S	-JL9		1				
	[33]	(E)SHIELD A-BRAKE PROTV (D)SCHILD										(F)BOUCLIER (S)ESCUDO				
	96243676	.	.	B	B	B	S	S	S	-JL9		1				
	[34]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	09118-06010	.	.	B	B	B	S	S	S	-JL9		1				
	[A0]	(E)PIPE A-BRAKE,FUEL (D)ROHR,BREMSE										(F)TUYAU-FREIN (S)TUBERIA-FRENO				
	96256674	.	.	B	B	B	S	S	S	&NN4-VB4/JL9/KL9		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96218173	.	.	B	B	B	A	A	A	&NN4&VB4-JL9/KL9		1		970609		NT
N	96256673	.	.	B	B	B	A	A	A	&NN4&VB4-JL9/KL9		1	970609			
	96218173	.	.	B	B	B	A	A	A	&NN6/NN7-JL9/KL9		1		970609		NT
N	96256673	.	.	B	B	B	A	A	A	&NN6/NN7-JL9/KL9		1	970609			
	96252759														NOT APPLIED	
	96256675	6	.	B	B	B	.	.	A	&KL9-JL9		1				
															REFER TO BELOW	
		- CONSIST OF -														
		PIPE-FUEL FEEDING,CENTER													2120-03	
		PIPE-FUEL RETURN,CENTER													2120-04	
		PIPE-PURGE,CENTER													2130-09	
		PIPE A-BRAKE REAR,2ND(LH)													4650-05	
		PIPE A-BRAKE REAR,2ND(RH)													4650-06	
		SHIELD A-PROTV,BRAKE,FUEL													4650-33	

GROUP NO — KEY NO


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]									(E)PIPE A-BRAKE,FRONT,1ST (D)ROHR,BREMSE,VORDERE					(F)TUYAU-FREIN,AVANT (S)TUBERIA-FRENO,DELANTERO	
	96304457	.	.	B	B	B	.	O	O	&JL9	LH	1				
	[02]									(E)PIPE A-BRAKE,FRONT,1ST (D)ROHR,BREMSE,VORDERE					(F)TUYAU-FREIN,AVANT (S)TUBERIA-FRENO,DELANTERO	
	96304458	.	.	B	B	B	.	O	O	&JL9	RH	1				
	[03]									(E)PIPE A-BRAKE, REAR,1ST (D)ROHR,BREMSE,HINTERE					(F)TUYAU-FREIN,ARRIERE (S)TUBERIA-FRENO,TRASERO	
	96304459	.	.	B	B	B	.	O	O	&JL9	LH	1				
	[04]									(E)PIPE A-BRAKE, REAR,1ST (D)ROHR,BREMSE,HINTERE					(F)TUYAU-FREIN,ARRIERE (S)TUBERIA-FRENO,TRASERO	
	96304460	.	.	B	B	B	.	O	O	&JL9	RH	1	970609			
N	96256677	.	.	B	B	B	.	O	O	&JL9	RH	1	970609			
	[05]									(E)PIPE A-BRAKE, REAR,2ND (D)ROHR,BREMSE,HINTERE					(F)TUYAU-FREIN,ARRIERE (S)TUBERIA-FRENO,TRASERO	
	96304479	.	.	B	B	B	.	O	O	&JL9	LH	1				NU
	[06]									(E)PIPE A-BRAKE, REAR,2ND (D)ROHR,BREMSE,HINTERE					(F)TUYAU-FREIN,ARRIERE (S)TUBERIA-FRENO,TRASERO	
	96306168	.	.	B	B	B	.	O	O	&JL9	RH	1	970609			NW
N	96256676	.	.	B	B	B	.	O	O	&JL9	RH	1	970609			
	[07]									(E)PIPE A-BRAKE,REAR,3RD (D)ROHR,BREMSE,HINTERE					(F)TUYAU-FREIN,ARRIERE (S)TUBERIA-FRENO,TRASERO	
	96237761	.	.	B	B	B	.	O	O	&JL9	LH	1				NV
	[08]									(E)HOSE A-BRAKE,REAR (D)SCHLAUCH,BREMSE,HINTEN					(F)TUYAU-FREIN,ARRIERE (S)MANGUERA-FRENO,TRASERO	
	96215570	.	.	B	B	B	.	O	O	&JL9		2				
	[09]									(E)PIPE A-BRAKE,REAR (D)ROHR,BREMSE,HINTERE					(F)TUYAU-FREIN,ARRIERE (S)TUBERIA-FRENO,TRASERO	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4651 BRAKE PIPE(ABS)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96306664	.	.	B	B	B	.	O	O	&JL9	LH	1				
	96306666	.	.	B	B	B	.	O	O	&JL9	RH	1				
[11]	(E)E RING *(D)RING* *(F)ANNEAU* *(S)ANILLO*															
	09383-12003	.	.	B	B	B	.	O	O	&JL9		4				
[12]	(E)E RING *(D)RING* *(F)ANNEAU* *(S)ANILLO*															
	09383-12003	.	.	B	B	B	.	O	O	&JL9		2				
[13]	(E)BOLT-HEXAGON *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*															
	02714-06163	.	.	B	B	B	.	O	O	&JL9		3				
[14]	(E)HOSE A-BRAKE,FRONT *(D)SCHLAUCH,BREMSE,VORNE* *(F)TUYAU-FREIN,AVANT* *(S)MANGUERA-FRENO,FRENTE*															
	96212323	.	.	B	B	B	.	O	O	&JL9		2				
[15]	(E)WASHER-PLAIN *(D)DICHTUNGSRING* *(F)RONDELLE* *(S)ARANDELA*															
	09160-10002	.	.	B	B	B	.	O	O	&JL9		4				
[16]	(E)BOLT-UNION *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*															
	09360-10002	.	.	B	B	B	.	O	O	&JL9		2				
[17]	(E)PIPE A-BRAKE,PRIMARY *(D)ROHR-BREMSE,HAUPT* *(F)TUYAU-FREIN,PRIMAIRE* *(S)TUBERIA-FRENO,PRIMARIA*															
	96304462	.	.	B	B	B	.	O	O	&JL9		1				
[18]	(E)PIPE A-BRAKE,SECONDARY *(D)ROHR,BREMSE,2.* *(F)TUYAU-FREIN,SECONDAIRE* *(S)TUBERIA-FRENO,SECUNDARIO*															
	96304461	.	.	B	B	B	.	O	O	&JL9		1				
[19]	(E)PIPE A-BRAKE,FRONT,2ND *(D)ROHR,BREMSE,VORDERE* *(F)TUYAU-FREIN,AVANT* *(S)TUBERIA-FRENO,DELANTERO*															

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96248675	.	.	B	B	B	.	O	O	&JL9	LH	1				
[20]	(E)PIPE A-BRAKE,FRONT,2ND *(D)ROHR,BREMSE,VORDERE*										*(F)TUYAU-FREIN,AVANT* *(S)TUBERIA-FRENO,DELANTERO*					
	96304423	.	.	B	B	B	.	O	O	&JL9	RH	1				
[21]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00082	.	.	B	B	B	.	O	O	&JL9		3				
[22]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00006	.	.	B	B	B	.	O	O	&JL9		4				
[23]	(E)CLIP A *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	96304429	.	.	B	B	B	.	O	O	&JL9		3				
[26]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00007	.	.	B	B	B	.	O	O	&JL9		2				
[27]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00008	.	.	B	B	B	.	O	O	&JL9		1				
[28]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00009	.	.	B	B	B	.	O	O	&JL9		1				
[29]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00004	.	.	B	B	B	.	O	O	&JL9		2				
[30]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*					
	09408-00038	.	.	B	B	B	.	O	O	&JL9		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	PICODE
	[31]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09408-00079	.	.	B	B	B	.	O	O	&JL9		1				
	[32]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09408-00080	.	.	B	B	B	.	O	O	&JL9		1				
	[33]	(E)SHIELD A-BRAKE PROTV (D)SCHILD									(F)BOUCLIER (S)ESCUDO					
	96243676	.	.	B	B	B	.	O	O	&JL9		1				
	[34]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09118-06010	.	.	B	B	B	.	O	O	&JL9		1				
	[A0]	(E)PIPE A-BRAKE,FUEL (D)ROHR,BREMSE									(F)TUYAU-FREIN (S)TUBERIA-FRENO					
	96256674	.	.	B	B	B	.	O	O	&NN4&JL9-VB4/KL9		1				
	96218173	.	.	B	B	B	.	A	A	&NN4&VB4&JL9-KL9		1		970609		NT
N	96256673	.	.	B	B	B	.	A	A	&NN4&VB4&JL9-KL9		1	970609			
	96218173	.	.	B	B	B	.	A	A	&NN6/NN7&JL9-KL9		1		970609		NT
N	96256673	.	.	B	B	B	.	A	A	&NN6/NN7&JL9-KL9		1	970609			
	96252759														NOT APPLIED	
	96256675	6	.	B	B	B	.	.	A	&JL9&KL9		1				
															REFER TO BELOW	
		- CONSIST OF -														
		PIPE-FUEL FEEDING,CENTER													2120-03	
		PIPE-FUEL RETURN,CENTER													2120-04	
		PIPE-PURGE,CENTER													2130-09	
		PIPE A-BRAKE REAR,2ND(LH)													4651-05	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4651 BRAKE PIPE(ABS)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
										PIPE A-BRAKE REAR,2ND(RH)					4651-06	
										SHIELD A-PROTV,BRAKE,FUEL					4651-33	

(4651-33: GROUP NO — KEY NO)


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)HYDRAULIC UNIT-BRAKE *(D)HYDRAULIK EINHEIT,BREMSE*										*(F)UNITE HYDRAULIQUE-FREIN* *(S)UNIDAD HIDRAULICA-FRENO*					
96304464		Y	.	B	B	B	.	O	O	&JL9		1				MA
96306147		6	.	B	B	B	.	.	O	&JL9		1				MB
[02]	(E)BRACKET A-HYDRAULIC UNIT *(D)TRÄGER,STEUERUNGSEINHEIT*										*(F)SUPPORT-UNITE DE CONTROLE* *(S)SOPORTE-UNIDA DE CONTROL*					
96304465		.	.	B	B	B	.	O	O	&JL9		1				
[03]	(E)NUT-HEXAGON FLANGE *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*					
08316-28063		.	.	B	B	B	.	O	O	&JL9		3				
[04]	(E)BOLT-HEXAGON *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*					
01137-08165		.	.	B	B	B	.	O	O	&JL9		3				
[05]	(E)NUT-HEXAGON FLANGE *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*					
08316-18083		.	.	B	B	B	.	O	O	&JL9		1				
[06]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*					
07130-06165		.	.	B	B	B	.	O	O	&JL9		2				
[07]	(E)SENSOR-WHEEL SPEED *(D)SENSOR,GESCHWINDIGKEIT*										*(F)DETECTEUR-VITESSE DE ROUE* *(S)SENSOR-VELOCIDAD DE RUEDA*					
10456154		.	.	B	B	B	.	O	O	&JL9	LH	1		970617		
Y 10456266		.	.	B	B	B	.	O	O	&JL9	LH	1	970617			
[08]	(E)SENSOR-WHEEL SPEED *(D)SENSOR,GESCHWINDIGKEIT*										*(F)DETECTEUR-VITESSE DE ROUE* *(S)SENSOR-VELOCIDAD DE RUEDA*					
10456155		.	.	B	B	B	.	O	O	&JL9	RH	1		970617		
Y 10456267		.	.	B	B	B	.	O	O	&JL9	RH	1	970617			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4710 ANTI LOCK BRAKE SYSTEM



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	PICODE
											(E)BRACKET A-SPEED SENSOR (D)TRÄGER (F)SUPPORT (S)SOPORTE-SENSOR						
[09]	96146791	.	.	B	B	B	.	O	O	&JL9		LH	1				
[10]	96146792	.	.	B	B	B	.	O	O	&JL9	(E)BRACKET A-SPEED SENSOR (D)TRÄGER (F)SUPPORT (S)SOPORTE-SENSOR	RH	1				
[11]	09106-06005	.	.	B	B	B	.	O	O	&JL9	(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO		2				
[12]	96306175	.	.	B	B	B	.	O	O	&JL9	(E)CONTROL UNIT-ABS (D)STEUERUNGS-EINHEIT,ABS (F)UNITE DE CONTROLE ABS (S)UNIDAD DE CONTROL-ABS		1				TB
[13]	03160-48195	.	.	B	B	B	.	O	O	&JL9	(E)SCREW-TAPPING (D)SCHRAUBE (F)VIS (S)TORNILLO		3				
[14]	96306212	.	.	B	B	B	.	O	O	&JL9	(E)BRACKET-CONTROL UNIT (D)TRÄGER,STEUERUNGSEINHEIT (F)SUPPORT-UNITE DE CONTROLE (S)SOPORTE-UNIDA DE CONTROL		1	970521			
N	96250304	.	.	B	B	B	.	O	O	&JL9			1	970521			
[15]	07466975	.	.	B	B	B	.	O	O	&JL9	(E)BEARING A-WHEEL (D)KUGELLAGER,RAD (F)ROULEMENT-ROUE (S)COJINETE-RUEDA		2				
[16]	09159-10010	.	.	B	B	B	.	O	O	&JL9	(E)NUT (D)MUTTER (F)ECROU (S)TUERCA		8				
[17]	09160-06002	.	.	B	B	B	.	O	O	&JL9	(E)WASHER-PLAIN (D)DICHTUNGSRING (F)RONDELLE (S)ARANDELA		2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[18]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-06327	.	.	B	B	B	.	O	O	&JL9		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4720 HYDRAULIC MODULATOR




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)MODULATOR A-ABS *(D)MODULATOR,ABS*													*(F)MODULATEUR-ABS* *(S)MODULADOR-ABS*	
18025679		Y	.	B	B	B	.	O	O	&JL9		1				
18024772		6	.	B	B	B	.	.	O	&JL9		1				
[02]		(E)VALVE A-PROPORTIONER *(D)VENTIL,PROPORTIONS*													*(F)SOUPAPE-PROPORTION* *(S)VALVULA-PROPORCIONAL*	
18029786		.	.	B	B	B	.	O	O	&JL9		1				
		- CONSIST OF -														
		PISTON(1)														
		SEAL(1)														
		CAP A(1)														
[03]		(E)PACK A-MOTOR *(D)PACKET,MOTOR*													*(F)PAQUET-MOTEUR* *(S)PAQUETE-MOTOR*	
18029785		.	.	B	B	B	.	O	O	&JL9		1				
[04]		(E)SOLENOID *(D)SOLENOID*													*(F)SOLENOIDE* *(S)SELENOIDE*	
18029783		.	.	B	B	B	.	O	O	&JL9		1				
[05]		(E)COVER-GEAR *(D)DECKEL*													*(F)CARTER* *(S)CUBIERTA*	
18029891		.	.	B	B	B	.	O	O	&JL9		1				
[06]		(E)HARDWARE KIT *(D)METALLWAREN-SATZ*													*(F)TROUSSE FERRURES* *(S)JUEGO DE FERRETERIA*	
18029784		.	.	B	B	B	.	O	O	&JL9		1				
		- CONSIST OF -														
		SCREW M6X1.0(3)														
		SCREW M4X0.7(6)														
		SCREW M6X1.0(6)														

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME													
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
		SEAL(2)														

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)WHEEL A-STEERING W/O SIR														
[01]		(D)RAD,LENK													(F)VOLANT DE DIRECTION (S)RUEDA-VOLANTE	
96239024		.	.	B	B	B	S	S	S			1				TW
		(E)CAP A-HORN													(F)CHAPEAU-AVERTISSEUR	
[02]		(D)DECKEL,HUPE													(S)TAPA-BOCINA	
96239023		.	.	B	B	B	S	S	S			1				TH
		(E)CONTACT A-SLIDING													(F)CONTACT-GLISSANT	
[03]		(D)KONTAKT,GLEIT													(S)CONTACTO-DESLIZANTE	
96304414		.	.	B	B	B	S	S	S			1				
		(E)CABLE A-GROUND													(F)CABLE	
[04]		(D)KABEL													(S)CABLE	
96304415		.	.	B	B	B	S	S	S			1				
		(E)SWITCH A-SIGNAL													(F)COMMUTATEUR-SIGNAL	
[05]		(D)SCHALTER,SIGNAL													(S)INTERRUPTOR-SEÑAL	
96230794		.	.	B	B	B	S	S	S			1				ZA
96242526		.	.	B	B	B	.	.	A	&T98&T97		1				ZE
		(E)SWITCH A-WIPER													(F)COMMUTATEUR-ESSUIE-GLACE	
[06]		(D)SCHALTER,SCHEIBENWISCHER													(S)INTERRUPTOR-LIMPIADOR	
96230798		.	.	B	.	.	S	S	S	-C25		1				CA
96230800		.	.	.	B	B	S	.	S	&C25		1				CB


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)COVER-STEERING COLUMN,UPR (D)DECKEL,LENKSÄULE,OBERE									(F)COUVERCLE (S)CUBIERTA					
96242958		.	.	B	B	B	S	S	S			1				T1
[02]		(E)COVER-STEERING COLUMN,LWR (D)DECKEL,LENKSÄULE,UNTERE									(F)COUVERCLE (S)CUBIERTA					
96242964		.	.	B	B	B	S	S	S	-N33		1				T5
96242962		.	.	B	B	B	.	.	O	&N33		1				T4
[03]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
03220-42095		.	.	B	B	B	S	S	S			2				
[04]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
03210-48095		.	.	B	B	B	S	S	S			2				
[05]		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
09136-04006		.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


4830 NON TILT STEERING COLUMN



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)COLUMN A-STEERING (D)SÄULE,LENKUNG									(F)COLONNE-DIRECTION (S)COLUMNA-CONDUCIR					
	96304406	.	.	B	B	B	S	S	S	&N55-N33		1				SS
	96214477	.	.	B	B	B	.	O	O	&N58-N33		1				SF
	[02]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	530952	.	.	B	B	B	S	S	S	-AJ3		1			M14X1.5	
	530545	.	.	B	B	B	.	O	O	&AJ3		1			M14X1.5	
	[03]	(E)SPRING (D)FEDERUNG									(F)RESSORT (S)RESORTE					
	530803	.	.	B	B	B	S	S	S			1				
	[04]	(E)WASHER (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	530546	.	.	B	B	B	S	S	S			1				
	[05]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	530590	.	.	B	B	B	S	S	S			2				
	[06]	(E)HOUSING A-SIGNAL SWITCH (D)GEHÄUSE,SIGNAL SCHALTER									(F)LOGEMENT (S)CARCASA					
	530445	.	.	B	B	B	S	S	S	-AJ3		1				
	530923	.	.	B	B	B	.	O	O	&AJ3		1				
	530723	.	.	B	B	B	.	O	O	&AJ3		1				
	[07]	(E)BOLT-SHEAR (D)SCHRAUBE,SCHERE									(F)BOULON-CISAILLE (S)PERNO-CORTAR					
	530549	.	.	B	B	B	S	S	S			2			M6X1.0	
	[08]	(E)BOLT-SUPPORT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	530600	.	.	B	B	B	S	S	S			4			M8X1.25	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK

4830 NON TILT STEERING COLUMN



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[09]		(E)HOUSING A-STEERING COLUMN (D)GEHÄUSE,LENKSÄULE								(F)LOGEMENT (S)CARCASA-COLUMNA DE VOLANT						
530751		. .	B	B	B	S	S	S			1					
[10]		(E)JACKET A-STEERING COLUMN (D)MANTEL,LENKSÄULE								(F)JAQUETTE (S)CUBIERTA						
530485		. .	B	B	B	S	S	S			1					
[11]		(E)NUT (D)MUTTER								(F)ECROU (S)TUERCA						
08361-28083		. .	B	B	B	S	S	S			3					
[13]		(E)SPACER (D)DISTANZSTÜCK								(F)ENTRETOISE (S)ESPACIADOR						
530995		. .	B	B	B	S	S	S			1					
530280		. .	B	B	B	S	S	S			1					
[14]		(E)SHAFT A-STEERING COLUMN (D)SPINDEL,LENKSÄULE								(F)ARBRE (S)EJE-COLUMNA DE VOLANTE						
530486		. .	B	B	B	S	S	S			1					
[15]		(E)HOUSING A-IGNITION SWITCH (D)GEHÄUSE,ZÜNDUNGS-SCHALTER								(F)LOGEMENT (S)CARCASA						
530825		. .	B	B	B	S	S	S			1					
[19]		(E)SWITCH-IGNITION (D)SCHALTER,ZÜNDUNG								(F)COMMUTATEUR-CONTACT (S)INTERRUPTOR-IGNICION						
96238726		. .	B	B	B	S	S	S			1					
[20]		(E)BOLT (D)SCHRAUBE								(F)BOULON (S)PERNO						
001711-4016		. .	B	B	B	S	S	S			1					
[21]		(E)PLATE-LOCKING (D)PLATTE,VERRIEGELUNG								(F)PLAQUE-VERROUILLAGE (S)PLACA-CIERRE						
03451666		. .	B	B	B	.	O	O	&AJ3		1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
[01]		(E)COLUMN A-TILT.STEERING (D)SÄULE,KIPPLENKUNG								(F)COLONNE-DIRECTION (S)COLUMNA-CONDUCIR					
96230715		. .	B	B	B	. .	O		&N33&N55		1				TS
96230716		. .	B	B	B	. .	O		&N33&N58		1				TF
[02]		(E)SHAFT A-RACER&UPPER (D)SPINDEL								(F)ARBRE (S)EJE					
530964		. .	B	B	B	. .	O				1				
[03]		(E)SPHERE-CENTERING (D)KUGEL-CENTRE								(F)SPHÈRE-CENTRE (S)ESFERA					
530625		. .	B	B	B	. .	O				2				
[04]		(E)SPRING (D)FEDERUNG								(F)RESSORT (S)RESORTE					
530626		. .	B	B	B	. .	O				1				
[05]		(E)SHAFT A-LOWER STRG (D)SPINDEL								(F)ARBRE (S)EJE					
530918		. .	B	B	B	. .	O				1				
[06]		(E)HOUSING A-SIGNAL SWITCH (D)GEHÄUSE								(F)LOGEMENT (S)CARCASA					
530445		. .	B	B	B	. .	O		-AJ3		1				
530923		. .	B	B	B	. .	O		&AJ3		1				
530723		. .	B	B	B	. .	O		&AJ3		1				
[07]		(E)NUT (D)MUTTER								(F)ECROU (S)TUERCA					
530952		. .	B	B	B	. .	O		-AJ3		1				M14X1.5
530545		. .	B	B	B	. .	O		&AJ3		1				M14X1.5
[08]		(E)SPRING (D)FEDERUNG								(F)RESSORT (S)RESORTE					
530561		. .	B	B	B	. .	O				1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4831 TILTABLE STEERING COLUMN




KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[09]		(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
530590		.	.	B	B	B	.	.	O			2				
[10]		(E)RING-RETAINING (D)RING,HALTER										(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR				
530503		.	.	B	B	B	.	.	O			1				
[11]		(E)RETAINER-SPRING (D)HALTER										(F)ARRETOIR (S)RETENEDOR				
530553		.	.	B	B	B	.	.	O			1				
[12]		(E)SPRING (D)FEDERUNG										(F)RESSORT (S)RESORTE				
530552		.	.	B	B	B	.	.	O			1				
[13]		(E)SEAT-UPR BEARING INR RACE (D)SITZ,OBERER LAGER										(F)SIEGE (S)ASIENTO				
530524		.	.	B	B	B	.	.	O			1				
[14]		(E)RACE-INNER (D)GLEITBAHN,INNEN										(F)CAGE-INTERNE (S)CARRERA-INTERNA				
530502		.	.	B	B	B	.	.	O			1				
[15]		(E)HOUSING A-STRG COLUMN (D)GEHÄUSE										(F)LOGEMENT (S)CARCASA				
530913		.	.	B	B	B	.	.	O			1				
[16]		(E)PIN-PIVOT (D)STIFT										(F)BROCHE (S)PASADOR				
530515		.	.	B	B	B	.	.	O			2				
[17]		(E)BOLT-SHEAR (D)SCHRAUBE,SCHERE										(F)BOULON-CISAILLE (S)PERNO-CORTAR				
530549		.	.	B	B	B	.	.	O			2			M6X1.0	
[18]		(E)RETAINER-SPRING (D)HALTER										(F)ARRETOIR (S)RETENEDOR				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	530509	.	.	B	B	B	.	.	O			1				
[19]	(E)HANDLE-TILTABLE LEVER (D)HENKEL											(F)POIGNEE (S)MANIJA				
	530953	.	.	B	B	B	.	.	O			1				
[20]	(E)SCREW (D)SCHRAUBE											(F)VIS (S)TORNILLO				
	530848	.	.	B	B	B	.	.	O			1				
[21]	(E)JACKET A-STEERING COLUMN (D)MANTEL,LENKSÄULE											(F)JAQUETTE (S)CUBIERTA				
	530914	.	.	B	B	B	.	.	O			1				
[22]	(E)SUPPORT-STRG COLUMN HSG (D)TRÄGER,LENKSÄULE GEHÄUSE											(F)SUPPORT (S)SOPORTE				
	530494	.	.	B	B	B	.	.	O			1				
[23]	(E)SCREW (D)SCHRAUBE											(F)VIS (S)TORNILLO				
	530600	.	.	B	B	B	.	.	O			4			M8X1.25	
[24]	(E)SPRING (D)FEDERUNG											(F)RESSORT (S)RESORTE				
	530750	.	.	B	B	B	.	.	O			1				
[25]	(E)SPACER (D)DISTANZSTÜCK											(F)ENTRETOISE (S)ESPACIADOR				
	530995	.	.	B	B	B	.	.	O			1				
	530280	.	.	B	B	B	.	.	O			1				
[26]	(E)NUT (D)MUTTER											(F)ECROU (S)TUERCA				
	08361-28083	.	.	B	B	B	.	.	O			3				
[27]	(E)HOUSING A-IGNITION SWITCH (D)GEHÄUSE ZÜNDUNGS-SCHALTER											(F)LOGEMENT (S)CARCASA				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	530825	. .	B	B	B	. .		O				1				
	[28]	(E)SWITCH-IGNITION *(D)SCHALTER,ZÜNDUNG*										*(F)COMMUTATEUR-CONTACT* *(S)INTERRUPTOR-IGNICION*				
	96238726	. .	B	B	B	. .		O				1				
	[29]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	001711-4016	. .	B	B	B	. .		O				1				
	[30]	(E)PLATE-LOCKING *(D)PLATTE,VERRIEGELUNG*										*(F)PLAQUE-VERROUILLAGE* *(S)PLACA-CIERRE*				
	03451666	. .	B	B	B	. .		O		&AJ3		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)GEAR A-STEERING *(D)GETRIEBE,LENKUNG*									*(F)ENGRENAGE-DIRECTION* *(S)ENGRANAJE-VOLANTE*					
96304378		.	.	B	B	B	S	S	.	&N51		1	970716			AP
96304378		.	.	B	B	B	S	S	.	&N51-F40		1	970716			AP
96255507		.	.	B	B	B	A	A	.	&N51&F40		1	970716			MP
[02]		(E)GEAR A-POWER STEERING *(D)GETRIEBE,KRAFTLENKUNG*									*(F)ENGRENAGE* *(S)ENGRANAJE-SERVODIRECCION*					
96216615		.	.	B	B	B	O	O	S	&N40		1	970716			SU
96216615		.	.	B	B	B	O	O	S	&N40-F40		1	970716			SU
96255506		.	.	B	B	B	A	A	A	&N40&F40		1	970716			PA
[03]		(E)BRACKET-STEERING GEAR *(D)TRÄGER,LENKGETRIEBE*									*(F)SUPPORT* *(S)SOPORTE-ENGRANAJE*					
90334562		.	.	B	B	B	S	S	S		LH	1				
[04]		(E)BRACKET-STEERING GEAR *(D)TRÄGER,LENKUNG GETRIEBE*									*(F)SUPPORT* *(S)SOPORTE*					
90121248		.	.	B	B	B	S	S	S		RH	1				
[05]		(E)NUT-HEXAGON LOCK *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
08311-18083		.	.	B	B	B	S	S	S			2				
[06]		(E)BOLT-HEXAGON *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
09100-08009		.	.	B	B	B	S	S	S			2				
[07]		(E)WASHER-PLAIN *(D)DICHTUNGSRING*									*(F)RONDELLE* *(S)ARANDELA*					
09160-08005		.	.	B	B	B	S	S	S			2				
[08]		(E)BOLT *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
09117-08003		.	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)SHORT GEAR A (D)KURZ GETRIEBE													(F)ENGRENAGE COURT (S)ENGRANAJE CORTO	
520558		.	.	B	B	B	S	S	.	&N51		1				
[03]		(E)COUPLING A-FLANGE&STRG (D)KUPPLUNG,FLANSCH&LENKUNG													(F)ACCOUPLEMENT (S)ACOPLAMIENTO	
520689		.	.	B	B	B	S	S	.	&N51		1				
[04]		(E)BOLT (D)SCHRAUBE													(F)BOULON (S)PERNO	
09117-08003		.	.	B	B	B	S	S	.	&N51		1				
[05]		(E)SEAL-DASH RUBBER (D)DICHTUNG													(F)JOINT (S)SELLO-GOMA SALPICADERO	
07848183		.	.	B	B	B	S	S	.	&N51		1				
[06]		(E)SEAL-PINION (D)DICHTUNG,RITZEL													(F)JOINT-PIGNON (S)SELLO-PIÑON	
07819410		.	.	B	B	B	S	S	.	&N51		1				
[07]		(E)RING-RETAINING (D)RING,HALTER													(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR	
05684948		.	.	B	B	B	S	S	.	&N51		1				
[08]		(E)PINION-BEARING (D)RITZEL,LAGER													(F)PIGNON-ROULEMENT (S)PIÑON-COJINETE	
520758		.	.	B	B	B	S	S	.	&N51		1				
[09]		(E)BEARING-ROLLER (D)ROLLENLAGER													(F)ROULEMENT-ROULEAU (S)COJINETE-RUEDECILLA	
07819358		.	.	B	B	B	S	S	.	&N51		1				
[11]		(E)HOUSING-RACK&PINION (D)GEHÄUSE													(F)LOGEMENT (S)CARCASA	
26026617		.	.	B	B	B	S	S	.	&N51		1				
[12]		(E)COVER-HOUSING END (D)DECKEL,GEHÄUSE-ENDE													(F)COUVERCLE (S)CUBIERTA	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


1



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	07849949	.	.	B	B	B	S	S	.	&N51		1					
[13]										(E)GROMMET-MOUNTING (D)ÖSE,MONTAGE							(F)VIROLE-MONTAGE (S)AISLANTE-MONTAJE
	26000626	.	.	B	B	B	S	S	.	&N51		1					
[14]										(E)GROMMET-MOUNTING (D)ÖSE,MONTAGE							(F)VIROLE-MONTAGE (S)AISLANTE-MONTAJE
	07848188	.	.	B	B	B	S	S	.	&N51		1					
[15]										(E)BUSHING-RACK (D)LAGERFUTTER,ZAHNSTANGE							(F)MANCHON-CREMAILLERE (S)BUJE
	07834425	.	.	B	B	B	S	S	.	&N51		1					
[16]										(E)RING-RETAINING (D)RING,HALTER							(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR
	07834429	.	.	B	B	B	S	S	.	&N51		1					
[17]										(E)COVER-HOUSING END (D)DECKEL,GEHÄUSE-ENDE							(F)COUVERCLE (S)CUBIERTA
	07849987	.	.	B	B	B	S	S	.	&N51		1					
[20]										(E)SPRING-ADJUSTER (D)FEDERUNG,RICHTER							(F)RESSORT-AJUSTEUR (S)RESORTE-AJUSTADOR
	07819378	.	.	B	B	B	S	S	.	&N51		1					
[21]										(E)NUT-ADJUSTER PLUG LOCK (D)MUTTER							(F)ECROU (S)TUERCA
	07834434	.	.	B	B	B	S	S	.	&N51		1					
[22]										(E)PLUG-ADJUSTER (D)STOPSEL							(F)BOUCHON (S)TAPON
	07834435	.	.	B	B	B	S	S	.	&N51		1					
[23]										(E)RACK-STEERING (D)GESTELL,LENKUNG							(F)CREMAILLERE-DIRECTION (S)ENGRANAJE DE CREMALLERA
	07849959	.	.	B	B	B	S	S	.	&N51		1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4920 MANUAL STEERING GEAR PARTS(LHD)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[24]		(E)BOOT-RACK&PINION (D)KOFFERRAUM										(F)GAINE (S)CAPUCHON				
26021070		.	.	B	B	B	S	S	.	&N51		1				
[27]		(E)CLAMP-SEAL RETAINING (D)KLAMMER										(F)PINCE (S)ABRAZADERA				
26021589		.	.	B	B	B	S	S	.	&N51		2				
[29]		(E)PLATE-DISTANCE (D)PLATTE,ABSTAND										(F)PLAQUE-DISTANCE (S)PLACA-DISTANCIA				
26001550		.	.	B	B	B	S	S	.	&N51		1				
[31]		(E)PLATE-LOCKING (D)PLATTE,VERRIEGELUNG										(F)PLAQUE-VERROUILLAGE (S)PLACA-CIERRE				
26001761		.	.	B	B	B	S	S	.	&N51		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)SHORT GEAR A (D)KURZ GETRIEBE													(F)ENGRENAGE COURT (S)ENGRANAJE CORTO	
	520533	.	.	B	B	B	O	O	S	&N40		1				
[02]		(E)COUPLING-FLANGE&STEERING (D)KUPPLUNG,FLANSCH&LENKUNG													(F)ACCOUPLEMENT (S)ACOPLAMIENTO	
	520689	.	.	B	B	B	O	O	S	&N40		1				
[03]		(E)BOLT (D)SCHRAUBE													(F)BOULON (S)PERNO	
	09117-08003	.	.	B	B	B	O	O	S	&N40		1				
[04]		(E)SEAL-DASH RUBBER (D)DICHTUNG													(F)JOINT (S)SELLO-GOMA SALPICADERO	
	26013593	.	.	B	B	B	O	O	S	&N40		1				
[05]		(E)LINE KIT-CYLINDER (D)AUSKLEIDUNGS,ZYLINDER													(F)TROUSSE DE LIGNE-CYLINDRE (S)JUEGO DE LINEA-CILINDRO	
	26020486	.	.	B	B	B	O	O	S	&N40		1				
[06]		(E)O RING (D)O RING													(F)JOINT TORIQUE (S)ANILLO EN O	
	26005047	.	.	B	B	B	O	O	S	&N40		2				
[07]		(E)BOOT KIT (D)KOFFERRAUM-SATZ								-					(F)TROUSSE DE GAINE (S)JUEGO DE BOTA	
	26024585	.	.	B	B	B	O	O	S	&N40		1				
[08]		(E)COVER-HOUSING END (D)DECKEL,GEHÄUSE-ENDE													(F)COUVERCLE (S)CUBIERTA	
	07849949	.	.	B	B	B	O	O	S	&N40		1				
[09]		(E)GROMMET-MOUNTING (D)ÖSE,MONTAGE													(F)VIROLE-MONTAGE (S)AISLANTE-MONTAJE	
	26000626	.	.	B	B	B	O	O	S	&N40		LH 1				
	07848187	.	.	B	B	B	O	O	S	&N40		RH 1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[14]	(E)PLATE-DISTANCE *(D)PLATTE,ABSTAND*									*(F)PLAQUE-DISTANCE* *(S)PLACA-DISTANCIA*					
	26001550	. .	B	B	B	O	O	S	&N40		1					
	[15]	(E)PLATE-LOCKING *(D)PLATTE,VERRIEGELUNG*									*(F)PLAQUE-VERROUILLAGE* *(S)PLACA-CIERRE*					
	26001761	. .	B	B	B	O	O	S	&N40		1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)ROD A-TIE (D)VERBINDUNGSSTANGE										(F)TRINGLE-BARRE (S)VARILLA-AMARRE					
07846481		.	.	B	B	B	S	S	.	&N51	LH	1		970716		
07846481		.	.	B	B	B	S	S	.	&N51-F40	LH	1	970716			
96255510		.	.	B	B	B	A	A	.	&N51&F40	LH	1	970716			
07846480		.	.	B	B	B	S	S	.	&N51	RH	1		970716		
07846480		.	.	B	B	B	S	S	.	&N51-F40	RH	1	970716			
96255511		.	.	B	B	B	A	A	.	&N51&F40	RH	1	970716			
96216616		.	.	B	B	B	O	O	S	&N40	LH	1		970716		
96216616		.	.	B	B	B	O	O	S	&N40-F40	LH	1	970716			
96255508		.	.	B	B	B	A	A	A	&N40&F40	LH	1	970716			
96216620		.	.	B	B	B	O	O	S	&N40	RH	1		970716		
96216620		.	.	B	B	B	O	O	S	&N40-F40	RH	1	970716			
96255509		.	.	B	B	B	A	A	A	&N40&F40	RH	1	970716			
[02]	(E)ROD-TIE (D)VERBINDUNGSSTANGE										(F)TRINGLE-BARRE (S)VARILLA-AMARRE					
07848281		.	.	B	B	B	S	S	.	&N51	LH	1				
07848282		.	.	B	B	B	S	S	.	&N51	RH	1				
96216618		.	.	B	B	B	O	O	S	&N40	LH	1				
96216622		.	.	B	B	B	O	O	S	&N40	RH	1				
[03]	(E)HEAD END A-TIE ROD (D)SPURSTANGENKOPF										(F)BIELLETTE DE DIRECTION (S)CABEZA DE RÓTULA					
07846495		.	.	B	B	B	S	S	S		LH	1		970716		
07846495		.	.	B	B	B	S	S	S	-F40	LH	1	970716			
96255512		.	.	B	B	B	A	A	A	&F40	LH	1	970716			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4940 TIE ROD




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	07846485	.	.	B	B	B	S	S	S		RH	1		970716		
	07846485	.	.	B	B	B	S	S	S	-F40	RH	1	970716			
	96255513	.	.	B	B	B	S	S	S	&F40	RH	1	970716			
[04]	(E)BOLT-ADJUSTER *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*	1				
[05]	07846696 (E)BOLT-HEXAGON *(D)SCHRAUBE*	.	.	B	B	B	S	S	S		*(F)BOULON* *(S)PERNO*	4				
[06]	09100-08002 (E)NUT *(D)MUTTER*	.	.	B	B	B	S	S	S		*(F)ECROU* *(S)TUERCA*	2				
	09159-12010	.	.	B	B	B	S	S	S							

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PIPE A-HIGH PRESSURE,PUMP *(D)ROHR*									*(F)TUYAU* *(S)TUBERIA*					
	96304375	Y	.	B	B	B	O	O	S	&N40		1	970616			
O	96246614	Y	.	B	B	B	O	O	S	&N40		1	970616			
	96228670	6	.	B	B	B	.	.	O	&N40		1	970616			
O	96246615	6	.	B	B	B	.	.	O	&N40		1	970616			
	[02]	(E)HOSE A-ELASTIC,GEAR *(D)SCHLAUCH,GUMMI,GETRIEBE*									*(F)TUYAU-ELASTIQUE,ENGRENAGE* *(S)MANGUERA-ELASTICA*					
	96304383	.	.	B	B	B	O	O	S	&N40		1				
	[03]	(E)PIPE A-HIGH PRESSURE,GEAR *(D)ROHR*									*(F)TUYAU* *(S)TUBERIA*					
	96304381	.	.	B	B	B	O	O	S	&N40		1				
	[04]	(E)HOSE A-RETURN FLOW *(D)SCHLAUCH,RÜCK-FLUß*									*(F)TUYAU-RETOUR ECOULEMENT* *(S)MANGUERA-FLUJO DE RETORNO*					
	96304380	.	.	B	B	B	O	O	S	&N40		1				
	[05]	(E)HOSE A-SUCTION,RESERVOIR *(D)SCHLAUCH,ANSAUGUNG*									*(F)TUYAU-ASPIRATION* *(S)MANGUERA-SUCCION*					
	96232170	.	.	B	B	B	O	O	S	&N40		1	970901			
O	96254886	.	.	B	B	B	O	O	S	&N40		1	970901			
	[06]	(E)HOSE A-SUCTION LINE,PUMP *(D)SCHLAUCH,SAUGLEITUNG*									*(F)TUYAU* *(S)MANGUERA-LINEA DE SUCCION*					
	96304372	.	.	B	B	B	O	O	S	&N40		1				
	[07]	(E)RESERVOIR-POWER STRG OIL *(D)BEHÄLTER,ÖL*									*(F)RESERVOIR-HUILE* *(S)RESERVA-ACEITE*					
	96304394	.	.	B	B	B	O	O	S	&N40		1				
	[08]	(E)CAP-OIL RESERVOIR *(D)DECKEL,ÖL-BEHÄLTER*									*(F)CHAPEAU-RESERVOIR D'HUILE* *(S)TAPA-RESERVA DE ACEITE*					
	96304395	.	.	B	B	B	O	O	S	&N40		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.		PART NAME													
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[09]									(E)SHIELD-OIL RESERVOIR (D)SCHILD					(F)BOUCLIER (S)ESCUDO	
	96226875	.	.	B	B	B	O	O	S	&N40		1				
	[11]									(E)SCREW-TAPPING (D)SCHRAUBE					(F)VIS (S)TORNILLO	
	03110-48133	.	.	B	B	B	O	O	S	&N40		2				
	[14]									(E)CLIP (D)KLEMME					(F)ATTACHE (S)GRAPA	
	09401-17401	.	.	B	B	B	O	O	S	&N40		1				
	[15]									(E)SCREW (D)SCHRAUBE					(F)VIS (S)TORNILLO	
	09139-06005	.	.	B	B	B	O	O	S	&N40		2				
	[16]									(E)CLIP (D)KLEMME					(F)ATTACHE (S)GRAPA	
	09401-21401	.	.	B	B	B	O	O	S	&N40		3				
	[17]									(E)CLAMP (D)KLAMMER					(F)PINCE (S)ABRAZADERA	
	90217449	.	.	B	B	B	O	O	S	&N40	.	2		970901		
O	96254889	.	.	B	B	B	O	O	S	&N40		2		970901		
	[18]									(E)GROMMET (D)ÖSE					(F)VIROLE (S)AISLANTE	
	09308-10006	.	.	B	B	B	O	O	S	&N40		3				
	[20]									(E)GROMMET (D)ÖSE					(F)VIROLE (S)AISLANTE	
	09308-16001	.	.	B	B	B	O	O	S	&N40		3				
	[22]									(E)BRACKET (D)TRÄGER					(F)SUPPORT (S)SOPORTE	
	96228671	.	.	B	B	B	O	O	S	&N40		2		970901		


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

4950 POWER STEERING PIPE LINE



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
O	96254887	.	.	B	B	B	O	O	S	&N40		2	970901				(E)NUT-SPEED (F)ECROU (D)MUTTER (S)TUERCA
	[23]																
	09148-06012	.	.	B	B	B	O	O	S	&N40		2					(E)O RING (F)JOINT TORIQUE (D)O RING (S)ANILLO EN O
	[24]																
	09280-07001	.	.	B	B	B	O	O	S	&N40		3					(E)PUMP A-POWER STEERING (F)POMPE-UNITE HYDRAULIQUE (D)PUMPE,HYDRAULIK EINHEIT (S)BOMBA-UNIDAD HIDRAULICA
	[25]																
	96230842	.	.	B	B	B	O	O	S	&N40		1				TR	(E)BOLT-HEXAGON (F)BOULON (D)SCHRAUBE (S)PERNO
	[26]																
	01103-08703	.	.	B	B	B	O	O	S	&N40		2					(E)PULLEY-HYDRAURIC PUMP (F)POULIE-POMPE HYDRAULIQUE (D)ROLLE,HYDRAULIK PUMPE (S)POLEA-BOMBA HIDRAULICA
	[27]																
	90299071	.	.	B	B	B	O	O	S	&N40		1					(E)BOLT-HEXAGON (F)BOULON (D)SCHRAUBE (S)PERNO
	[28]																
	09100-08003	.	.	B	B	B	O	O	S	&N40		3					(E)CLAMP (F)PINCE (D)KLAMMER (S)ABRAZADERA
	[29]																
	96248572	.	.	B	B	B	O	O	S	&N40		1					(E)BOLT (F)BOULON (D)SCHRAUBE (S)PERNO
	[30]																
	09116-08008	.	.	B	B	B	O	O	S	&N40		1					(E)SCREW-TAPPING (F)VIS (D)SCHRAUBE (S)TORNILLO
	[31]																
	03110-48133	.	.	B	B	B	O	O	S	&N40		1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO	
	[32]	(E)CLAMP (D)KLAMMER								(F)PINCE (S)ABRAZADERA					
	09403-26301	.	.	B	B	B	O	O	S	&N40		1			
	[33]	(E)BOLT (D)SCHRAUBE								(F)BOULON (S)PERNO					
	09116-06011	.	.	B	B	B	O	O	S	&N40		2			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5 ELECTRICAL EQUIPMENTS

5110 FRONT LAMP

5140 REAR LAMP(N/B)

5141 REAR LAMP(H/B)

5220 INSTRUMENT CLUSTER

5310 WINDSHIELD WIPER

5320 BACK WINDOW WIPER

5330 WINDSHIELD WASHER

5410 ELECTRICAL PARTS

5420 ANTENNA


5430 AUDIO SYSTEM

5510 AIR BAG SYSTEM

5610 BATTERY

5620 FUSE & RELAY


5710 WIRING HARNESS



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)LAMP A-HEAD (D)LAMPE,SCHEINWERFER (F)LAMPE-PHARE (S)LAMPARA-CABECERA															
	96304606	.	.	B	B	B	S	S	S	-HL4	LH	1				HL
	96304607	.	.	B	B	B	S	S	S	-HL4	RH	1				HM
	96304610	.	.	B	B	B	A	A	A	&HL4	LH	1				HP
	96304611	.	.	B	B	B	A	A	A	&HL4	RH	1				HQ
[02]	(E)BULB-HEAD LAMP (D)BIRNE (F)AMPOULE (S)BOMBILLA															
	05104-60553	.	.	B	B	B	S	S	S			2			60/55W	
[03]	(E)BULB-TURN SIGNAL (D)BIRNE (F)AMPOULE (S)BOMBILLA															
	05201-21004	.	.	B	B	B	S	S	S			2			21W	
[04]	(E)BULB-POSITION (D)BIRNE (F)AMPOULE (S)BOMBILLA															
	05302-05003	.	.	B	B	B	S	S	S			2			5W	
[06]	(E)CLIP (D)KLEMME (F)ATTACHE (S)GRAPA															
	09409-10305	.	.	B	B	B	S	S	S			2				
[07]	(E)NUT (D)MUTTER (F)ECROU (S)TUERCA															
	09159-06011	.	.	B	B	B	S	S	S			2				
[08]	(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO															
	09116-06026	.	.	B	B	B	S	S	S			4			W/WASHER	
[09]	(E)SPACER-HEAD LAMP (D)DISTANZSTÜCK (F)ENTRETOISE (S)ESPACIADOR															
	96304656	.	.	B	B	B	S	S	S		LH	1				
	96304657	.	.	B	B	B	S	S	S		RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5110 FRONT LAMP




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[10]		(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03170-42133	. .	B	B	B	S	S	S				4				
[11]		(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA				
	09148-04004	. .	B	B	B	S	S	S				4				
[12]		(E)LAMP A-FOG,FRONT (D)LAMPE,NEBEL										(F)LAMPE (S)LAMPARA-NEBLINA				
	96303261	. .	B	B	B	.	.	O	&T97		LH	1				
	96303262	. .	B	B	B	.	.	O	&T97		RH	1				
[13]		(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	09159-05005	. .	B	B	B	.	.	O	&T97			4				
[14]		(E)BULB-FOG LAMP (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05103-55003	. .	B	B	B	.	.	O	&T97			2			55W	
[15]		(E)LAMP A-TURN SIGNAL,SIDE (D)LAMPE										(F)LAMPE (S)LAMPARA .				
	96303241	. .	B	B	B	A	A	A	&FL6			2				
[16]		(E)BULB- TURN SIGNAL SIDE (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05302-05003	. .	B	B	B	A	A	A	&FL6			2			5W	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)LAMP A-TAIL (D)LAMPE,HINTERTEIL									(F)LAMPE-EXTREMITE ARRIERE (S)LAMPARA-COLA					
	96304620	.	.	B	.	.	S	S	S		LH	1				RJ
	96304621	.	.	B	.	.	S	S	S		RH	1				RK
	[02]	(E)BULB-TURN SIGNAL (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	05201-21004	.	.	B	.	.	S	S	S			2			21W	
	[03]	(E)BULB-TAIL STOP (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	05202-21053	.	.	B	.	.	S	S	S			2			21/5W	
	[06]	(E)NUT-HEXAGON FLANGE (D)MUTTER									(F)ECROU (S)TUERCA					
	08316-25053	.	.	B	.	.	S	S	S			8				
	[07]	(E)LAMP A-EXTENSION TAIL (D)LAMPE,VERLÄNGERUNG									(F)LAMPE-EXTENSION (S)LAMPARA-EXTENSION					
	96248143	.	.	B	.	.	S	S	S	-T98	LH	1		971001		EL
Y	96239383	.	.	B	.	.	S	S	S	-T98	LH	1	971001			EQ
	96248144	.	.	B	.	.	S	S	S	-T98	RH	1		971001		EM
Y	96239384	.	.	B	.	.	S	S	S	-T98	RH	1	971001			ER
	96304631	.	.	B	.	.	A	A	A	&T98	LH	1				EJ
	96304632	.	.	B	.	.	A	A	A	&T98	RH	1				EK
	[08]	(E)BULB-BACK UP (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	05201-21003	.	.	B	.	.	S	S	S			2			21W	
	[09]	(E)BULB-TAIL STOP (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	05202-21053	.	.	B	.	.	S	S	S	-T98		2		971001	21/5W	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
Y	05232-27081	.	.	B	.	.	S	S	S	-T98		2	971001		27/8W	
	05201-21003	.	.	B	.	.	A	A	A	&T98		2			21W	
	[11]	(E)NUT-CAP (D)MUTTER										(F)ECROU (S)TUERCA				
	09145-05001	.	.	B	.	.	S	S	S			4				
	[12]	(E)NUT-HEXAGON FLANGE (D)MUTTER										(F)ECROU (S)TUERCA				
	08316-25053	.	.	B	.	.	S	S	S			2				
	[13]	(E)LAMP A-LICENSE (D)LAMPE,NUMMERSCHILD										(F)LAMPE (S)LAMPARA-PLACA DE LICENCIA				
	96237708	.	.	B	.	.	S	S	S			2				LE
	[14]	(E)BULB-LICENSE (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05302-05003	.	.	B	.	.	S	S	S			2			5W	
	[17]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03110-42132	.	.	B	.	.	S	S	S			4				
	[18]	(E)LAMP A-HIGH MOUNTED STOP (D)LAMPE										(F)LAMPE (S)LAMPARA				
	96304677	.	.	B	.	.	A	A	A	&T93		1				CB
	[19]	(E)BULB-HIGH MOUNTED STOP (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05201-21003	.	.	B	.	.	A	A	A	&T93		1			21W	
	[20]	(E)NUT-HEXAGON (D)MUTTER										(F)ECROU (S)TUERCA				
	08361-25053	.	.	B	.	.	A	A	A	&T93		2			WWASHER	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)LAMP A-TAIL *(D)LAMPE,HINTERTEIL*										*(F)LAMPE-EXTREMITE ARRIERE* *(S)LAMPARA-COLA*					
96304618		.	.	.	B	B	S	.	S		LH	1				RG
96304619		.	.	.	B	B	S	.	S		RH	1				RH
[03]	(E)BULB-TURN SIGNAL *(D)BIRNE*										*(F)AMPOULE* *(S)BOMBILLA*					
05201-21004		.	.	.	B	B	S	.	S			2			21W	
[04]	(E)BULB-TAIL STOP *(D)BIRNE*										*(F)AMPOULE* *(S)BOMBILLA*					
05202-21053		.	.	.	B	B	S	.	S			2			21/5W	
[06]	(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*					
09132-04013		.	.	.	B	B	S	.	S			4				
[07]	(E)NUT-SPEED *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*					
09148-03006		.	.	.	B	B	S	.	S			4				
[08]	(E)BRACKET A-REAR COMB LAMP *(D)TRÄGER*										*(F)SUPPORT* *(S)SOPORTE*					
96223420		.	.	.	B	B	S	.	S		LH	1				
96224456		.	.	.	B	B	S	.	S		RH	1				
[09]	(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*					
09132-04013		.	.	.	B	B	S	.	S			4				
[10]	(E)LAMP A-EXTENSION TAIL *(D)LAMPE,VERLÄNGERUNG*										*(F)LAMPE-EXTENSION* *(S)LAMPARA-EXTENSION*					
96248145		.	.	.	B	B	S	.	S	-T98	LH	1		971001		EU
Y 96239381		.	.	.	B	B	S	.	S	-T98	LH	1	971001			ES
96248146		.	.	.	B	B	S	.	S	-T98	RH	1		971001		EV


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
Y	96239382	.	.	.	B	B	S	.	S	-T98	RH	1	971001			ET
	96304629	.	.	.	B	B	A	.	A	&T98	LH	1				EG
	96304630	.	.	.	B	B	A	.	A	&T98	RH	1				EH
	[11]	(E)BULB-TAIL STOP *(D)BIRNE*									*(F)AMPOULE* *(S)BOMBILLA*					
	05202-21053	.	.	.	B	B	S	.	S	-T98		2		971001	21/5W	
Y	05232-27081	.	.	.	B	B	S	.	S	-T98		2	971001		27/8W	
	05201-21003	.	.	.	B	B	A	.	A	&T98		2			21W	
	[12]	(E)BULB-BACK UP *(D)BIRNE*									*(F)AMPOULE* *(S)BOMBILLA*					
	05201-21003	.	.	.	B	B	S	.	S			2			21W	
	[14]	(E)NUT-CAP *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
	09145-05001	.	.	.	B	B	S	.	S			4				
	[15]	(E)NUT-HEXAGON FLANGE *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
	08316-25053	.	.	.	B	B	S	.	S			2				
	[16]	(E)LAMP A-LICENSE *(D)LAMPE,NUMMERSCHILD*									*(F)LAMPE* *(S)LAMPARA-PLACA DE LICENCIA*					
	96237708	.	.	.	B	B	S	.	S			2				LE
	[17]	(E)BULB-LICENSE *(D)BIRNE*									*(F)AMPOULE* *(S)BOMBILLA*					
	05302-05003	.	.	.	B	B	S	.	S			2			5W	
	[18]	(E)SCREW-TAPPING *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
	03110-42132	.	.	.	B	B	S	.	S			4				
	[19]	(E)LAMP A-HIGH MOUNTED STOP *(D)LAMPE*									*(F)LAMPE* *(S)LAMPARA*					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5141 REAR LAMP(H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96303244	.	.	.	B	B	A	.	A	&T93		1				CA
	[20]	(E)BULB-HIGH MOUNTED STOP (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05201-21003	.	.	.	B	B	A	.	A	&T93		1			21W	
	[21]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA				
	09409-10305	.	.	.	B	B	A	.	A	&T93		2				
	[22]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA				
	09148-04003	.	.	.	B	B	A	.	A	&T93		2				
	[23]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03160-42165	.	.	.	B	B	A	.	A	&T93		2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1 - KILOMETER TYPE,

KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)CLUSTER-INSTRUMENT (D)INSTRUMENT									(F)TABLEAU DE BORD (S)INSTRUMENTO					
	96304893	.	M	B	B	B	S	.	.	-U44		1			@1, WO/TACHO	RA
	96304900	.	M	B	B	B	.	S	S	-ABF/AJ3/U44		1			@1, W/TACHO	RF
	96304900	.	M	B	B	B	.	S	S	-JL9/T97/U44		1			@1, W/TACHO	RF
	96304717	.	M	B	B	B	.	O	O	&ABF/AJ3-U44		1		970715	@1, W/TACHO	RG
	96304717	.	M	B	B	B	.	O	O	&ABF/AJ3/T98-U44		1	970715		@1, W/TACHO	RG
	96304717	.	M	B	B	B	.	O	O	&JL9/T97-U44		1		970715	@1, W/TACHO	RG
	96304717	.	M	B	B	B	.	O	O	&JL9/T97/T98-U44		1	970715		@1, W/TACHO	RG
	96304894	.	M	B	B	B	A	.	.	&U44-ABF/AJ3		1			@1, WO/TACHO	RB
	96304894	.	M	B	B	B	A	.	.	&U44-JL9/T97		1			@1, WO/TACHO	RB
	96304718	.	M	B	B	B	.	A	A	&U44		1			@1, W/TACHO	RH
	96304896	.	A	B	B	B	O	.	.	-U44		1			@1, WO/TACHO	RD
	96304720	.	A	B	B	B	.	O	O	-U44		1			@1, W/TACHO	RK
	96304895	.	A	B	B	B	A	.	.	&U44		1			@1, WO/TACHO	RC
	96304719	.	A	B	B	B	.	A	A	&U44		1			@1, W/TACHO	RJ
	[02]	(E)LENS-INSTRUMENT (D)OBJEKTIV									(F)LENTILLE (S)LENTE					
	96218671	.	.	B	B	B	S	S	S			1				
	[03]	(E)PLATE-WINDOW (D)PLATTE									(F)PLAQUE (S)PLACA					
	96218670	.	.	B	B	B	S	S	S			1				
	[04]	(E)SPEEDOMETER A (D)GESCHWINDIGKEITSMESSER									(F)COMPTEUR DE VITESSE (S)VELOCIMETRO					
	96214624	.	.	B	B	B	S	S	S	-U44		1			@1	
	96218647	.	.	B	B	B	A	A	A	&U44		1			@1	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1 - KILOMETER TYPE,

KEY NO.		PART NAME																
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
[05]		(E)TACHOMETER A (D)TACHOMETER									(F)TACHYMETRE (S)TACOMETRO					
	96214665	.	M	B	B	B	.	S	S			1			W/TACHO	
	96218649	.	A	B	B	B	.	O	O			1			W/TACHO	
[06]		(E)GAUGE A-FUEL&TEMPERATURE (D)ANZEIGE,BENZIN&TEMPERATUR									(F)JAUGE (S)JUNTA					
	96214629	.	.	B	B	B	.	S	S			1			W/TACHO	
[07]		(E)FILTER A-TELLTALES (D)FILTER									(F)FILTRE (S)FILTRO					
	96236132	.	.	B	B	B	S	S	S			1				
[08]		(E)CASE-INSTRUMENT CLUSTER (D)KASTEN,INSTRUMENT									(F)BOITIER-TABLEAU DE BORD (S)CAJA-INSTRUMENTOS					
	96214669	.	.	B	B	B	S	.	.			1			WO/TACHO	
	96214668	.	.	B	B	B	.	S	S			1			W/TACHO	
[09]		(E)BOARD A-PRINTED CIRCUIT (D)PLATTE,DRUCK KREIS									(F)PLAQUE-CIRCUIT IMPRIME (S)PLACA-CIRCUITO IMPRESO					
	96214667	.	.	B	B	B	S	.	.			1			WO/TACHO	
	96214666	.	.	B	B	B	.	S	S			1			W/TACHO	
[10]		(E)SOCKET (D)FASSUNG BIRNE									(F)CULOT-AMPOULE (S)ENCHUFE-BOMBILLA					
	94797520	.	.	B	B	B	S	S	S	-ABF/AJ3/JL9/T97		9			SMALL	
	94797520	.	.	B	B	B	O	O	O	&ABF/AJ3/JL9/T97		12			SMALL	
[11]		(E)BULB-SMALL (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	09471-12014	.	.	B	B	B	S	S	S	-ABF/AJ3/JL9/T97		9			SMALL	
	09471-12014	.	.	B	B	B	O	O	O	&ABF/AJ3/JL9/T97		12			SMALL	
[12]		(E)SOCKET (D)FASSUNG BIRNE									(F)CULOT-AMPOULE (S)ENCHUFE-BOMBILLA					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



NOTE : @1 - KILOMETER TYPE.

KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	96077679	. .	B B B				S	S	S			1			MEDIUM	
	[13]	(E)BULB-MEDIUM (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	09471-12015	. .	B B B				S	S	S			1			MEDIUM	
	[14]	(E)SOCKET (D)FASSUNG BIRNE										(F)CULOT-AMPOULE (S)ENCHUFE-BOMBILLA				
	94797519	. .	B B B				S	S	S			4			LARGE	
	[15]	(E)BULB-LARGE (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05301-03003	. .	B B B				S	S	S			4			LARGE	
	[16]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03160-48165	. .	B B B				S	S	S			4				
	[17]	(E)GAUGE A-TEMPERATURE (D)ANZEIGE,TEMPERATUR										(F)JAUGE-TEMPÉRATURE (S)JUNTA-TEMPERATURA				
	96214631	. .	B B B				S	.	.			1			W/O TACHO	
	[18]	(E)GAUGE A-FUEL (D)ANZEIGE,BENZIN										(F)JAUGE-CARBURANT (S)JUNTA-COMBUSTIBLE				
	96214627	. .	B B B				S	.	.			1			W/O TACHO	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]										(E)MOTOR A-WINDSHIELD WIPER *(D)MOTOR,SCHEIBENWISCHER*					*(F)ESSUIE-GLACE* *(S)MOTOR-LIMPIAPARABRISAS*	
96303118		.	.	B	B	B	S	S	S			1				LM
[02]										(E)ARM A-WIPER *(D)ARM,SCHEIBENWISCHER*					*(F)BRAS-ESSUIE-GLACE* *(S)BRAZO-LIMPIAPARABRISAS*	
96306672		.	.	B	B	B	S	S	S		LH	1				
96306103		.	.	B	B	B	S	S	S		RH	1				
[03]										(E)BLADE A-WIPER *(D)SCHEIBENWISCHERGUMMI*					*(F)BALAI D'ESSUIE-GLACE* *(S)ESCOBILLA-LIMPIAPARABRISA*	
96132997		.	.	B	B	B	S	S	S			2				
[04]										(E)NUT-CAP *(D)MUTTER*					*(F)ECROU* *(S)TUERCA*	
09145-08001		.	.	B	B	B	S	S	S			2				
[06]										(E)NUT-HEXAGON FLANGE *(D)MUTTER*					*(F)ECROU* *(S)TUERCA*	
08316-25063		.	.	B	B	B	S	S	S			4				
[07]										(E)LINKAGE A-WIPER *(D)VERBINDUNG*					*(F)ACOUPLEMENT* *(S)ENLACE*	
96303360		.	.	B	B	B	S	S	S			1				K5


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5320 BACK WINDOW WIPER




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)MOTOR A-BACK WINDOW WIPER *(D)MOTOR,SCHEIBENWISCHER*										*(F)MOTEUR-ESSUIE* *(S)MOTOR-LIMPIAPARABRISAS*				
96303127		.	.	.	B	B	S	.	S			1				BM
[02]		(E)ARM A-WIPER *(D)ARM,SCHEIBENWISCHER*										*(F)BRAS-ESSUIE-GLACE* *(S)BRAZO-LIMPIAPARABRISAS*				
96303365		.	.	.	B	B	S	.	S			1				
[03]		(E)BLADE A-WIPER *(D)SCHEIBENWISCHERGUMMI*										*(F)BALAI D'ESSUIE-GLACE* *(S)ESCOBILLA-LIMPIAPARABRISA*				
96132997		.	.	.	B	B	S	.	S			1				
[04]		(E)GROMMET-WIPER MOTOR *(D)ÖSE*										*(F)VIROLE* *(S)AISLANTE*				
96221124		.	.	.	B	B	S	.	S			1				
[05]		(E)NUT-HEXAGON FLANGE *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
08316-25063		.	.	.	B	B	S	.	S			1				
[06]		(E)CAP-WIPER ARM *(D)DECKEL,SCHEIBENWISCHER*										*(F)CHAPEAU* *(S)TAPA-LIMPIAPARABRISAS*				
96303372		.	.	.	B	B	S	.	S			1				E2

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)RESERVOIR A-WINDSHIELD *(D)BEHÄLTER*										*(F)RESERVOIR* *(S)RESERVA*					
	96303534			B			S	S	S	-C25		1				RN
	96303535				B	B	S		S	&C25		1		970602		RB
N	96255654				B	B	S		S	&C25		1	970602			
[02]	(E)GROMMET-PUMP *(D)ÖSE*										*(F)VIROLE* *(S)AISLANTE*					
	96233400			B			S	S	S	-C25		1				
	96233400				B	B	S		S	&C25		2				
[03]	(E)PUMP A *(D)PUMPE,ELEKTRISCHE*										*(F)POMPE-LAVEUR ELECTRIQUE* *(S)BOMBA -LIMPIADOR*					
	96190259			B			S	S	S	-C25		1				
	96190259				B	B	S		S	&C25		2				
[04]	(E)HOSE A-RESERVOIR *(D)SCHLAUCH,BEHÄLTER*										*(F)TUYAU-RESERVOIR* *(S)MANGUERA-RESERVA*					
	96233398				B	B	S		S	&C25		1		970602	980mm	
N	T.B.D				B	B	S		S	&C25		1	970602		280mm	
[05]	(E)HOSE A-RESERVOIR *(D)SCHLAUCH,BEHÄLTER*										*(F)TUYAU-RESERVOIR* *(S)MANGUERA-RESERVA*					
	96233397			B	B	B	S	S	S			1				
[06]	(E)CAP-RESERVOIR *(D)DECKEL,BEHÄLTER*										*(F)CHAPEAU-RESERVOIR* *(S)TAPA-RESERVA*					
	96233396			B	B	B	S	S	S			1				
[07]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*					
	09116-06024			B	B	B	S	S	S			1			WNWASHER	
[08]	(E)HOSE A-HOOD *(D)SCHLAUCH,HAUBE*										*(F)TUYAU-CAPOT* *(S)MANGUERA-CAPO*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96304915	.	.	B	B	B	S	S	S			1	970502			
O	96252906	.	.	B	B	B	S	S	S			1	970502			
	[09]	(E)NOZZLE A-WINDSHIELD WASHE *(D)MÜNDUNG,WINDSCHUTZSCHEIBE*										*(F)BEC-LAVE* *(S)BOQUILLA-LIMPIAPARABRISAS*				
	96231860	.	.	B	B	B	S	S	S			2				
	[10]	(E)NUT-HEXAGON *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	08361-25063	.	.	B	B	B	S	S	S			2			W/WASHER	
	[11]	(E)HOSE-REAR WASHER *(D)SCHLAUCH*										*(F)TUYAU* *(S)MANGUERA*				
	96242636	.	.	.	B	.	S	.	S	&C25		1				
	96242637	.	.	.	.	B	S	.	S	&C25		1				
	[12]	(E)NOZZLE A-REAR WASHER *(D)MÜNDUNG,WASCHANLAGE*										*(F)BEC-LAVE-GLACE ARRIERE* *(S)BOQUILLA-LIMPIADOR*				
	96303537	.	.	.	B	B	S	.	S	&C25		1				
	[13]	(E)NUT *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	09159-08011	.	.	.	B	B	S	.	S	&C25		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 6H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)HORN A (D)HUPE									(F)AVERTISSEUR (S)BOCINA					
	96242524	.	.	B	B	B	S	S	S	-2G3/U05		1	970609			FL
	96242619	.	.	B	B	B	A	A	A	&2G3-U05		1	970609			EL
	96242524	.	.	B	B	B	S	S	S			1	970609			FL
	96242525	.	.	B	B	B	A	A	A	&U05		1			NOT APPLIED	FH
	[02]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09118-08003	.	.	B	B	B	S	S	S	-U05		1			W/WASHER	
	09118-08003	.	.	B	B	B	A	A	A	&U05		2			NOT APPLIED	
	[03]	(E)LAMP A-ROOM,CENTER (D)LAMPE,RAUM									(F)LAMPE-INTERIEUR (S)LAMPARA-CABINA					
	96236130	.	.	B	B	B	S	S	S	-CF6		1				
	[04]	(E)LENS-ROOM LAMP (D)OBJEKTIV									(F)LENTILLE (S)LENTE					
	96230743	.	.	B	B	B	S	S	S	-CF6		1				
	[05]	(E)BULB (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	05404-10001	.	.	B	B	B	S	S	S	-CF6		1			10W(34mm)	
	[06]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03170-42138	.	.	B	B	B	S	S	S	-CF6		2				
	[07]	(E)SPEAKER A-FRONT (D)LAUTSPRECHER,VORNE									(F)HAUT-PARLEUR-AVANT (S)ALTAVOZ-FRENTE					
	96303513	.	.	B	B	B	S	S	S			2				
	[08]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	B	B	S	S	S			6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME																
I T C	PART NO	MODEL								OPTION	L / R	Q T Y	EFFECTIVE DATE		REMARKS	P / C O D E
		E N G	T / A	BODY 4 N	BODY 3 H	BODY 5 H	LEVEL S	LEVEL S E	LEVEL S X				FROM	TO		
	[09]	(E)SPEAKER A-REAR (D)LAUTSPRECHER,HINTEN									(F)HAUT-PARLEUR-ARRIERE (S)ALTAVOZ-TRASERO					
	96303515	.	.	B	.	.	O	O	S	&US8		2			STANDARD	ST
	96303516	.	.	B	.	.	.	O	O	&U83		2			DELUXE	DL
	96216123	.	.	.	B	B	O	.	S	&US8		2			STANDARD	HS
	96216124	.	.	.	B	B	.	.	O	&U83		2			DELUXE	HD
	[10]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03110-48095	.	.	B	B	B	O	O	S			8				
	[14]	(E)LAMP A-TRUNK (D)LAMPE									(F)LAMPE (S)LAMPARA					
	08972943	.	.	B	B	B	S	S	S			1		970602		
Y	96247398	.	.	B	B	B	S	S	S			1	970602			
	[15]	(E)BULB (D)BIRNE									(F)AMPOULE (S)BOMBILLA					
	05405-10001	.	.	B	B	B	S	S	S			1			10W(40mm)	
	[16]	(E)RESISTOR (D)WIDERSTAND									(F)RESISTANCE (S)RESISTOR					
	96190362	.	.	B	B	B	S	S	S	&C46		1				
	[17]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01517-06353	.	.	B	B	B	S	S	S	&C46		1				
	[18]	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04005	.	.	B	B	B	S	S	S			6				
	[19]	(E)LAMP A-ROOM,FRONT (D)LAMPE,RAUM,VORNE									(F)LAMPE-INTERIEUR,AVANT (S)LAMPARA-CABINA,DELANTERO					
	96238283	.	.	B	B	B	O	O	O	&CF6		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[20]	(E)LENS-ROOM LAMP,FRONT (D)OBJEKTIV										(F)LENTILLE (S)LENTE				
	96238279	. .	B	B	B	O	O	O	&CF6			1				
	[21]	(E)BULB (D)BIRNE										(F)AMPOULE (S)BOMBILLA				
	05404-10001	. .	B	B	B	O	O	O	&CF6			1			10W(34mm)	
	[22]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03170-42138	. .	B	B	B	O	O	O	&CF6			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)ANTENNA A-AUTOMATIC *(D)ANTENNE AUTOMATISCH*									*(F)ANTENNE-AUTOMATIQUE* *(S)ANTENA-AUTOMATICO*					
	96303522	.	.	B	.	.	.	.	S	&U75		1				AN
	96219197	.	.	.	B	.	.	.	S	&U75		1				AH
	96242523	.	.	.	.	B	.	.	S	&U75		1				A5
	[02]	(E)ANTENNA A-MANUAL *(D)ANTENNE MANUELLE*									*(F)ANTENNE-MANUELLE* *(S)ANTENA-MANUAL*					
	96303521	.	.	B	.	.	S	S	.	&U73		1		970407		MN
O	96255031	.	.	B	.	.	S	S	.	&U73		1	970407			NM
	96219195	.	.	.	B	.	S	.	.	&U73		1		970407		MH
O	96255032	.	.	.	B	.	S	.	.	&U73		1	970407			3M
	96242521	.	.	.	.	B	S	.	.	&U73		1		970407		M5
O	96255033	.	.	.	.	B	S	.	.	&U73		1	970407			5M
	[04]	(E)POLE-ANTENNA *(D)STAB,ANTENNE*									*(F)HAMPE-ANTENNE* *(S)POSTE-ANTENA*					
	S5420004	.	.	B	B	B	.	.	S	&U75		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)CASSETTE *(D)KASSETTE*									*(F)CASSETTE* *(S)CASETE*					
96252563		.	.	B	B	B	O	O	O	&UNA-XLA/2G3		1				BA
96242627		.	.	B	B	B	A	A	A	&UNA&2G3		1				BE
96252737		.	.	B	B	B	A	A	A	&UNA&XLA		1				BL
96248434		.	.	B	B	B	O	O	O	&UN1-XLA/2G3		1				SA
96222377		.	.	B	B	B	A	A	A	&UN1&2G3		1				SE
96222379		.	.	B	B	B	A	A	A	&UN1&XLA		1				SL
96248432		.	.	B	B	B	.	O	O	&UN6-XLA/2G3		1				DD
96312715		.	.	B	B	B	.	A	A	&UN6&2G3		1				WF
96312721		.	.	B	B	B	.	A	A	&UN6&XLA		1				WK
[02]		(E)SCREW *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
02116-05165		.	.	B	B	B	O	O	O	&UN1/UN6		2				
[03]		(E)FRAME-CASSETTE *(D)RAHMEN-KASSETTE*									*(F)CADRE-CASSETTE* *(S)ARMADURA-CASETE*					
96254552		.	.	B	B	B	S	S	S			1			A/S ONLY	
[04]		(E)PLAYER-COMPACT DISK *(D)SPIELER,CD*									*(F)MAGNETOPHONE* *(S)PLACA-CD*					
96252564		.	.	B	B	B	.	O	O	-XLA/2G3		1				CA
96229570		.	.	B	B	B	.	A	A	&2G3		1				CE
96229572		.	.	B	B	B	.	A	A	&XLA		1				CL
[05]		(E)SCREW *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
02116-05165		.	.	B	B	B	.	O	O			4				
[06]		(E)COVER-BLANK,RADIO *(D)DECKEL*									*(F)COUVERCLE* *(S)CUBIERTA*					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	96236135	.	.	B	B	B	S	S	S			1				BR
		(E)SCREW														
	[07]	*(D)SCHRAUBE*										*(F)VIS*				
												(S)TORNILLO				
	02116-05165	.	.	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5510 AIR BAG SYSTEM




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)WHEEL A-STEERING,W/SIR *(D)RAD,LENK*								*(F)VOLANT DE DIRECTION* *(S)RUEDA-VOLANTE*						
	96238765	.	.	B	B	B	.	O	O			1				HP
	[02]	(E)MODULE-AIR BAG DRIVER *(D)MODUL,AIR BAG*								*(F)MODULE-AIR BAG* *(S)MODULO-AIR BAG*						
	96220427	.	.	B	B	B	.	O	O			1				
	[03]	(E)SPRING A-AIR BAG CLOCK *(D)FEDERUNG*								*(F)RESSORT* *(S)RESORTE*						
	96230847	.	.	B	B	B	.	O	O			1				
	[04]	(E)W\RING-AIR BAG *(D)VERDRAHTUNG,AIR BAG*								*(F)CABLAGE* *(S)INSTALACION ELECTRICA*						
	96304225	.	.	B	B	B	.	O	O	&AJ3		1				WE
	96217551	.	.	B	B	B	.	O	O	&ABF		1				WD
	[05]	(E)MODULE-SENSOR&DIAGNOSTIC *(D)MODUL,SENSOR&DIAGNOSTIK*								*(F)MODULE* *(S)MODULO*						
	96220438	.	.	B	B	B	.	O	O	&AJ3		1				
	96220425	.	.	B	B	B	.	O	O	&ABF		1				
	[06]	(E)MODULE-SENSOR&DIAGNOSTIC *(D)MODUL,SENSOR&DIAGNOSTIK*								*(F)MODULE* *(S)MODULO*						
	96220439	.	.	B	B	B	.	O	O	&AJ3		1				
	96217003	.	.	B	B	B	.	O	O	&ABF		1				
	[07]	(E)BRACKET-AIR BAG MODULE *(D)TRÄGER,AIR BAG MODUL*								*(F)SUPPORT* *(S)SOPORTE*						
	96217010	.	.	B	B	B	.	O	O			1				
	[08]	(E)BOLT *(D)SCHRAUBE*								*(F)BOULON* *(S)PERNO*						
	09119-06011	.	.	B	B	B	.	O	O			3				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	PICODE
	PART NAME															
	[09]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09116-06027	. .	B	B	B	.	O	O			4				WWASHER	
	[10]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	96179417	. .	B	B	B	.	O	O			2				MB	
	[11]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03110-48139	. .	B	B	B	.	O	O			4					
	[12]	(E)CAP-STRG WHEEL LWR COVER (D)DECKEL									(F)CHAPEAU (S)TAPA					
	96238766	. .	B	B	B	.	O	O			LH	1				
	96238767	. .	B	B	B	.	O	O			RH	1				
	[13]	(E)MODULE-AIR BAG,PASSENGER (D)MODUL,AIR BAG									(F)MODULE-AIR BAG (S)MODULO-AIR BAG					
	96220430	. .	B	B	B	.	O	O	&ABF-2G3		1					
	96245086	. .	B	B	B	.	A	A	&ABF&2G3		1					
	[14]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09119-06011	. .	B	B	B	.	O	O	&ABF		4					
	[15]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09119-08013	. .	B	B	B	.	O	O	&ABF		2					
	[16]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	09159-08003	. .	B	B	B	.	O	O	&ABF		2					
	[17]	(E)STRAP-MOUNTING (D)BAND,MONTAGE									(F)BRETELLE-MONTAGE (S)BRIDA-MONTAJE					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME																	
ITC	PART NO	MODEL									OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL							FROM	TO		
				4N	3H	5H	S	SE	SX								
	96224564	.	.	B	B	B	.	O	O		&ABF		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)BATTERY A *(D)BATTERIE*									*(F)BATTERIE* *(S)BATERIA*					
	96230966	.	.	B	B	B	S	S	S			1			55A	TB
	96190267	.	.	B	B	B	A	A	A	&XPH		1			45A	TA
	[02]	(E)HOLDER A-BATTERY *(D)BEHÄLTER*									*(F)MONTURE* *(S)RETNEDOR*					
	96190269	.	.	B	B	B	S	S	S			1				MS
	[03]	(E)ROD-HOLDER *(D)STAB,BATTERIE*									*(F)TRINGLE-BATTERIE* *(S)VARILLA-BATERIA*					
	96305846	.	.	B	B	B	S	S	S			2				
	[04]	(E)BAR-HOLDER *(D)STANGE*									*(F)BARRE* *(S)BARRA*					
	96305845	.	.	B	B	B	S	S	S			1				
	[05]	(E)NUT-HEXAGON *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
	08361-25063	.	.	B	B	B	S	S	S			2			W/WASHER	
	[06]	(E)COVER-BATTERY TERMINAL *(D)DECKEL,BATTERIE-PFOSTEN*									*(F)CHAPEAU-POLE DE BATTERIE* *(S)CUBIERTA*					
	96187088	.	.	B	B	B	S	S	S			1			(-) TERMINAL	
	96187087	.	.	B	B	B	S	S	S			1			(+) TERMINAL	
	[07]	(E)CONNECTOR A-BATTERY *(D)VERBINDUNG,BATTERIE*									*(F)CONNECTEUR-BATTERIE* *(S)CONECTOR-BATERIA*					
	96187092	.	.	B	B	B	S	S	S			1			(-) TERMINAL	
	96187093	.	.	B	B	B	S	S	S			1			(+) TERMINAL	
	[08]	(E)CAP-BATTERY *(D)DECKEL,BATTERIE-PFOSTEN*									*(F)CHAPEAU-POLE DE BATTERIE* *(S)TAPA*					
	96239892	.	.	B	B	B	S	S	S			1			(-) TERMINAL	
	96239891	.	.	B	B	B	S	S	S			1			(+) TERMINAL	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5610 BATTERY




KEY NO.		PART NAME														
		MODEL														
				BODY			LEVEL									
T/C	PART NO	ENG	T/A	4N	3H	5H	S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[09]	(E)SHIELD A-HEAT,BATTERY *(D)SCHILD*									*(F)BOUCLIER* *(S)ESCUDO*					
	96303981	.	.	B	B	B	A	A	A	&XHA		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)COVER-FUSE BOX,UPPER *(D)DECKEL*										*(F)CARTER* *(S)CUBIERTA*					
96245532		.	.	B	B	B	S	S	S			1				
[02]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*					
01514-06165		.	.	B	B	B	S	S	S			2				
[03]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*					
01514-06203		.	.	B	B	B	S	S	S			3				
[04]	(E)FUSE-SLOW *(D)SICHERUNG*										*(F)FUSIBLE* *(S)FUSIBLE*					
61009		.	.	B	B	B	S	S	S			1			20A	
61010		.	.	B	B	B	S	S	S			1			30A	
61011		.	.	B	B	B	S	S	S			1			40A	
61001		.	.	B	B	B	S	S	S			1			80A	
[05]	(E)RELAY A *(D)RELAIS*										*(F)RELAI* *(S)RELEVADOR*					
90229206		.	.	B	B	B	S	S	S			1			CLG FAN LOW	
90191753		.	.	B	B	B	S	S	S			1			FUEL PUMP	
90244312		.	.	B	B	B	S	S	S			1			A/C BLOWER	
96312300		.	.	B	B	B	S	S	S			1			INT. WIPER	
90229206		.	.	B	B	B	S	S	S			1			HEAD LAMP	
90229206		.	.	B	B	B	S	S	S			1			TAIL LAMP	
90244312		.	.	B	B	B	S	S	S			1			RR DEFOGGER	
90229206		.	.	B	B	B	S	S	S			1			HORN	
90244312		.	.	B	B	B	O	O	S	&A32/A31		1			PWR WINDOW	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	90229206	.	.	B	B	B	.	.	O	&T97		1			FR FOG LAMP	
	90191753	.	.	B	B	B	O	O	O	&C59/C60		1			CLG FAN	
	90244312	.	.	B	B	B	O	O	O	&C59/C60		1			CLG FAN HIGH	
	90229206	.	.	B	B	B	O	O	O	&C59/C60		1			COMPRESSOR	
	12088595	.	.	B	B	B	.	O	O	&JL9		1			ABS	
	96242630	.	.	B	B	B	A	A	A	&T98		1			RR FOG LAMP	
[06]	(E)BLINKER UNIT *(D)BLINKER*										*(F)UNITE CLIGNOTANTE* *(S)UNIDAD INTERMITENTE*					
	96312545	.	.	B	B	B	S	S	S			1			2/4X21W	
[07]	(E)FUSE-MINI *(D)SICHERUNG*										*(F)FUSIBLE* *(S)FUSIBLE*					
	96234924	.	.	B	B	B	S	S	S			1			10AMP	
	96234923	.	.	B	B	B	S	S	S			1			15AMP	
	96234922	.	.	B	B	B	S	S	S			1			20AMP	
	96234921	.	.	B	B	B	S	S	S			1			25AMP	
[08]	(E)DIODE *(D)DIODE*										*(F)DIODE* *(S)DIODE*					
	96234932	.	.	B	B	B	S	S	S			1				
[09]	(E)MODULE A-CHIME BELL *(D)MODUL,GLOCKE*										*(F)MODULE-CARILLON* *(S)MODULO-CAMPANA DE REPIQUE*					
	96219056	.	.	B	B	B	S	S	S	-U44		1				CN
	96223528	.	.	B	B	B	A	A	A	&U44		1				CY
[10]	(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*					
	03112-42133	.	.	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)WIRING-INSTRUMENT PANEL (D)VERDRAHTUNG,INSTRUMENTENB								(F)CABLAGE-TABLEAU DE BORD (S)INSTALACION ELECTRICA						
	96254088	.	.	B	B	B	S	S	S	&D39		1		970907		NM
N	96258719	.	.	B	B	B	S	S	S	&D39		1	970901			FU
	96254084	.	.	B	B	B	A	A	A	&D39&T98-HL4/UM1		1		970901		NH
N	96258715	.	.	B	B	B	A	A	A	&D39&T98-HL4/UM1		1	970901			FQ
	96254081	.	.	B	B	B	A	A	A	&D39		1		970901	FOR LITHUANIA, POLAND	NE
N	96258712	.	.	B	B	B	A	A	A	&D39		1	970901		FOR LITHUANIA, POLAND	FM
	96254082	.	.	B	B	B	A	A	A	&D39		1		970901	FOR ISRAEL	NF
N	96258713	.	.	B	B	B	A	A	A	&D39		1	970901		FOR ISRAEL	FN
	96254083	.	.	B	B	B	A	A	A	&D39&HL4&T98-UM1		1		970901		NG
N	96258714	.	.	B	B	B	A	A	A	&D39&HL4&T98-UM1		1	970901			FP
	96254086	.	.	B	B	B	A	A	A	&D39&UM1-HL4/T98		1		970901		NK
N	96258717	.	.	B	B	B	A	A	A	&D39&UM1-HL4/T98		1	970901			FS
	96254078	.	.	B	B	B	.	.	A	&DD4&UM1-HL4/T98		1				NB
	96254080	.	.	B	B	B	.	.	O	&DD4		1				ND
	96252219	.	.	B	B	B	.	.	A	&DD4&T98-HL4/UM1		1				JJ
	96252216	.	.	B	B	B	.	.	A	&DD4		1			FOR LITHUANIA, POLAND	JF
	96252217	.	.	B	B	B	.	.	A	&DD4		1			FOR ISRAEL	JG
	96252218	.	.	B	B	B	.	.	A	&DD4&HL4&T98-UM1		1				JH
	96254087	.	.	B	B	B	A	A	A	&D39&HL4-UM1/T98		1		970901	NOT APPLIED	NL
N	96258718	.	.	B	B	B	A	A	A	&D39&HL4-UM1/T98		1	970901		NOT APPLIED	FT


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96254077	.	.	B	B	B	.	.	A	&DD4&HL4&UM1-T98		1			NOT APPLIED	NA
	96254079	.	.	B	B	B	.	.	A	&DD4&HL4-T98/UM1		1			NOT APPLIED	NC
[02]	(E)WIRING-FRONT (D)VERDRAHTUNG,VORNE										(F)CABLAGE-AVANT (S)INSTALACION ELECTRICA					
	96252265	.	.	B	B	B	S	S	S	&C46-JL9/T97		1			SINGLE HORN	XR
	96252257	.	.	B	B	B	.	O	O	&C46&JL9-T97		1			SINGLE HORN	XH
	96252263	.	.	B	B	B	.	.	O	&C46&T97-JL9		1			SINGLE HORN	XP
	96252255	.	.	B	B	B	.	.	O	&C46&JL9&T97		1			SINGLE HORN	XF
	96252261	.	.	B	B	B	O	O	O	&C59/C60-JL9/T97		1			SINGLE HORN	XM
	96252253	.	.	B	B	B	.	O	O	&C59/C60&JL9-T97		1			SINGLE HORN	XD
	96252259	.	.	B	B	B	.	.	O	&C59/C60&T97-JL9		1			SINGLE HORN	XK
	96252251	.	.	B	B	B	.	.	O	&C59/C60&JL9&T97		1			SINGLE HORN	XB
	96255192	.	.	B	B	B	.	.	A	&C46-JL9/T97		1			FOR BRAZIL	K9
	96255187	.	.	B	B	B	.	.	A	&C46&JL9&T97		1			FOR BRAZIL	J7
	96255188	.	.	B	B	B	.	.	A	&C46&JL9-T97		1			FOR BRAZIL	J9
	96255191	.	.	B	B	B	.	.	A	&C46&T97-JL9		1			FOR BRAZIL	K7
	96255190	.	.	B	B	B	.	.	A	&C59/C60-JL9/T97		1			FOR BRAZIL	K5
	96255185	.	.	B	B	B	.	.	A	&C59/C60&JL9&T97		1			FOR BRAZIL	J3
	96255186	.	.	B	B	B	.	.	A	&C59/C60&JL9-T97		1			FOR BRAZIL	J5
	96255189	.	.	B	B	B	.	.	A	&C59/C60&T97-JL9		1			FOR BRAZIL	K3
	96252264	.	.	B	B	B	A	A	A	&C46-JL9/T97		1			NOT APPLIED	XQ
	96252256	.	.	B	B	B	.	A	A	&C46&JL9-T97		1			NOT APPLIED	XG
	96252262	.	.	B	B	B	.	.	A	&C46&T97-JL9		1			NOT APPLIED	XN
	96252254	.	.	B	B	B	.	.	A	&C46&JL9&T97		1			NOT APPLIED	XE

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96252260	.	.	B	B	B	A	A	A	&C59/C60-JL9/T97		1			NOT APPLIED	XL
	96252252	.	.	B	B	B	.	A	A	&C59/C60&JL9-T97		1			NOT APPLIED	XC
	96252258	.	.	B	B	B	.	.	A	&C59/C60&T97-JL9		1			NOT APPLIED	XJ
	96252250	.	.	B	B	B	.	.	A	&C59/C60&JL9&T97		1			NOT APPLIED	XA
	[03]	(E)WIRING-ENGINE (D)VERDRAHTUNG,MOTOR									(F)CABLAGE-MOTEUR (S)INSTALACION ELECTRICA					
	96254117	Y	M	B	B	B	S	S	S	&NN4-VB4		1				MG
	96235335	Y	M	B	B	B	A	A	A	&NN7		1				HN
	96243365	Y	M	B	B	B	A	A	A	&NN4&VB4		1				9D
	96306006	Y	M	B	B	B	A	A	A	&NN6		1				HA
	96254118	Y	A	B	B	B	O	O	O	&NN4-VB4		1				MH
	96235336	Y	A	B	B	B	A	A	A	&NN7		1				HP
	96243366	Y	A	B	B	B	A	A	A	&NN4&VB4		1				9E
	96306007	Y	A	B	B	B	A	A	A	&NN6		1				HB
	96254119	6	M	B	B	B	.	.	S			1		970610		MJ
N	96255171	6	M	B	B	B	.	.	S	&NN4-VB4		1	970610			DP
	96216498	6	M	B	B	B	.	.	A	&NN7		1				HF
	96243367	6	M	B	B	B	.	.	A	&NN4&VB4		1				9F
	96306008	6	M	B	B	B	.	.	A	&NN6		1				HC
	96254120	6	A	B	B	B	.	.	O			1		970610		MK
N	96255172	6	A	B	B	B	.	.	O	&NN4-VB4		1	970610			DQ
	96216499	6	A	B	B	B	.	.	A	&NN7		1				HG
	96243368	6	A	B	B	B	.	.	A	&NN4&VB4		1				9G
	96306009	6	A	B	B	B	.	.	A	&NN6		1				HD

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5710 WIRING HARNESS







For ground
20

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[04]	(E)W/RING-FUEL INJECTION (D)VERDRAHTUNG,EINSPRITZ									(F)CABLAGE-INJECTION (S)INSTALACION ELECTRICA					
	96239890	6	.	B	B	B	.	.	O			1				WE
	[05]	(E)W/RING-FRONT DOOR (D)VERDRAHTUNG,VORDERTÜR									(F)CABLAGE-PORTE AVANT (S)INSTALACION ELECTRICA					
	96306030	.	.	B	.	B	S	S	.	&A30&D39-AU3		2				TS
	96306027	.	.	B	.	B	O	O	S	&AU3	LH	1				TN
	96306032	.	.	B	.	B	O	O	S	&AU3&D39	RH	1				5B
	96306029	.	.	B	.	B	O	O	.	&AU3&A30&D39	LH	1				TR
	96306033	.	.	B	.	B	O	O	.	&AU3&A30&D39	RH	1				5C
	96306031	.	.	B	.	B	.	.	O	&AU3&DD4	RH	1				5A
	96227435	.	.	.	B	.	S	.	.	&A30&D39		2				5D
	96227438	.	.	.	B	.	O	.	S	&AU3&A32	LH	1				5E
	96227443	.	.	.	B	.	O	.	S	&AU3&A32&D39	RH	1				5F
	96227445	.	.	.	B	.	.	.	O	&AU3&A32&DD4	RH	1				5G
	[06]	(E)W/RING-REAR DOOR (D)VERDRAHTUNG,HINTERTÜR									(F)CABLAGE-PORTE ARRIERE (S)INSTALACION ELECTRICA					
	96304236			B	.	B	O	O	S	&AU3-A31		2				TC
	96250935			B	.	B	.	.	O	&AU3&A31		2				VR
	[07]	(E)W/RING-FLOOR (D)VERDRAHTUNG,BODEN									(F)CABLAGE-PLANCHER (S)INSTALACION ELECTRICA					
	96252306	.	.	B	.	.	S	S	.	&A30-AU3/JL9		1				LS
	96252299	.	.	B	.	.	.	O	.	&AU3&A32&JL9		1				LK
	96252302	.	.	B	.	.	.	O	.	&A30&JL9-AU3		1				LN
	96252303	.	.	B	.	.	.	O	.	&AU3&A32-JL9		1				LP
	96258765	.	.	B	.	.	.	O	.	&AU3&A31&JL9		1				EB

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






For ground

20

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96258766	.	.	B	.	.	.	O	.	&AU3&A31-JL9		1				EC
	96252310	.	.	B	.	.	.	.	S	&AU3&A32-JL9		1				LW
	96252307	.	.	B	.	.	.	.	O	&AU3&A31&JL9		1				LT
	96252308	.	.	B	.	.	.	.	O	&AU3&A32&JL9		1				LU
	96252309	.	.	B	.	.	.	.	O	&AU3&A31-JL9		1				LV
	96255126	.	.	B	.	.	.	.	A	&KL9&A32-JL9		1			FOR BRAZIL	3K
	96255124	.	.	B	.	.	.	.	A	&KL9&A32&JL9		1			FOR BRAZIL	3H
	96255125	.	.	B	.	.	.	.	A	&KL9&A31-JL9		1			FOR BRAZIL	3J
	96255123	.	.	B	.	.	.	.	A	&KL9&A31&JL9		1			FOR BRAZIL	3G
	96252348	.	.	.	B	.	S	.	.	&A30-AU3/JL9		1				4W
	96252350	.	.	.	B	.	O	.	.	&AU3&A32-JL9		1				4Y
	96252351	.	.	.	B	.	.	.	S	&AU3&A32-JL9		1				4Z
	96252353	.	.	.	B	.	.	.	O	&AU3&A32&JL9		1				F2
	96255100	.	.	.	B	.	.	.	A	&KL9&A32-JL9		1			FOR BRAZIL	FD
	96255102	.	.	.	B	.	.	.	A	&KL9&A32&JL9		1			FOR BRAZIL	FF
	96252355	.	.	.	.	B	S	.	.	&A30-AU3/JL9		1				F4
	96252354	.	.	.	.	B	O	.	.	&AU3&A32-JL9		1				F3
	96252357	.	.	.	.	B	.	.	S	&AU3&A32-JL9		1		970602		F6
N	96255092	.	.	.	.	B	.	.	S	&AU3&A32-JL9		1	970602			FY
	96252361	.	.	.	.	B	.	.	O	&AU3&A31&JL9		1		970602		G1
N	96255095	.	.	.	.	B	.	.	O	&AU3&A31&JL9		1	970602			3B
	96252360	.	.	.	.	B	.	.	O	&AU3&A31-JL9		1		970602		F9
N	96255094	.	.	.	.	B	.	.	O	&AU3&A31-JL9		1	970602			3A
	96252359	.	.	.	.	B	.	.	O	&AU3&A32&JL9		1		970602		F8

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


5710 WIRING HARNESS





KEY NO. ITC	PART NO	PART NAME: MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
N	96255093	.	.	.	.	B	.	.	O	&AU3&A32&JL9		1	970602			FZ
	96255106	.	.	.	.	B	.	.	A	&KL9&A32-JL9		1			FOR BRAZIL	FK
	96255108	.	.	.	.	B	.	.	A	&KL9&A32&JL9		1			FOR BRAZIL	FM
	96255109	.	.	.	.	B	.	.	A	&KL9&A31-JL9		1			FOR BRAZIL	FN
	96255110	.	.	.	.	B	.	.	A	&KL9&A31&JL9		1			FOR BRAZIL	FP
	96258767	.	.	B	.	.	O	.		&A31&JL9-AU3		1			NOT APPLIED	ED
	96258768	.	.	B	.	.	O	.		&A31-AU3/JL9		1			NOT APPLIED	EE
	[08]	(E)WIRING-TRUNK (D)VERDRAHTUNG										(F)CABLAGE-COFFRE (S)INSTALACION ELECTRICA				
	96306014	.	.	B	.	.	S	S	S			1				TD
	96243390	.	.	.	B	B	S	.	.	-US8/U83		1				7S
	96242515	.	.	.	B	B	O	.	S	&US8/U83		1				7N
	[09]	(E)WIRING-TRUNK LID&TAILGATE (D)VERDRAHTUNG										(F)CABLAGE (S)INSTALACION ELECTRICA				
	96306016	.	.	B	.	.	S	S	S	-T98		1			FOR TRUNK	TT
	96217030	.	.	B	.	.	A	A	A	&T98		1			FOR TRUNK	TU
	96217032	.	.	.	B	B	S	.	.	-AU3/T93.		1			FOR TAILGATE	7B
	96217034	.	.	.	B	B	A	.	.	&T93-AU3.		1			FOR TAILGATE	7D
	96217035	.	.	.	B	B	A	.	A	&AU3&T93.		1			FOR TAILGATE	7E
	96217036	.	.	.	B	B	O		S	&AU3-T93.		1			FOR TAILGATE	7F
	[11]	(E)WIRING-FRONT BUMPER (D)VERDRAHTUNG										(F)CABLAGE (S)INSTALACION ELECTRICA				
	96236220	.	.	B	B	B	.	.	O	&VT1&T97		1				TK
	96236223	.	.	B	B	B	.	.	O	&VT2&T97		1				TJ
	[12]	(E)WIRING-BATTERY CABLE (D)VERDRAHTUNG										(F)CABLAGE (S)INSTALACION ELECTRICA				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96304994	.	.	B	B	B	S	S	S			1				3X
	[13]	(E)WIRING-BACK WDO HEATED (D)VERDRAHTUNG,HINTERE FENST										(F)CABLE (S)ALAMBRE				
	96306001	.	.	B	B	B	S	S	S			1				
	[14]	(E)WIRING-ROOF (D)VERDRAHTUNG										(F)CABLAGE (S)INSTALACION ELECTRICA				
	96304237	.	.	B	.	.	S	S	S	-C25		1		970602		6H
N	96255145	.	.	B	.	.	S	S	S	-C25		1	970602	971001		2F
N	96258770	.	.	B	B	B	S	S	S			1	971001			5J
	96242513	.	.	.	B	.	S	.	S	&C25		1		970602		7K
N	96255144	.	.	.	B	.	S	.	S	&C25		1	970602	971001		2E
N	96258769	.	.	.	B	.	S	.	S	&C25		1	971001			5H
	96242512	.	.	.	.	B	S	.	S	&C25		1		970602		7F
N	96255146	.	.	.	.	B	S	.	S	&C25		1	970602	971001		2G
N	96258769	.	.	.	.	B	S	.	S	&C25		1	971001			5H
	[15]	(E)WIRING-ECM & ABS (D)VERDRAHTUNG										(F)CABLAGE (S)INSTALACION ELECTRICA				
	96243370	Y	M	B	B	B	S	S	S	&C46&NN4-JL9		1				9H
	96243378	Y	M	B	B	B	O	O	O	&C59/C60&NN4-JL9		1				9S
	96243371	Y	M	B	B	B	.	O	O	&C46&JL9&NN4		1				9J
	96243379	Y	M	B	B	B	.	O	O	&C59/C60&JL9&NN4		1				9T
	96243372	Y	A	B	B	B	O	O	O	&C46&NN4-JL9		1				9K
	96243380	Y	A	B	B	B	O	O	O	&C59/C60&NN4-JL9		1				9U
	96243373	Y	A	B	B	B	.	O	O	&C46&JL9&NN4		1				9L
	96243381	Y	A	B	B	B	.	O	O	&C59/C60&JL9&NN4		1				9V


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96217037	Y	M	B	B	B	A	A	A	&C46&NN6-JL9		1				KA
	96243343	Y	M	B	B	B	A	A	A	&C59/C60&NN6-JL9		1				8E
	96235345	Y	M	B	B	B	A	A	A	&C46&NN7-JL9		1				6C
	96243339	Y	M	B	B	B	A	A	A	&C59/C60&NN7-JL9		1				8A
	96217038	Y	M	B	B	B	.	A	A	&C46&JL9&NN6		1				KB
	96243344	Y	M	B	B	B	.	A	A	&C59/C60&JL9&NN6		1				8F
	96235346	Y	M	B	B	B	.	A	A	&C46&JL9&NN7		1				6D
	96243340	Y	M	B	B	B	.	A	A	&C59/C60&JL9&NN7		1				8B
	96217039	Y	A	B	B	B	A	A	A	&C46&NN6-JL9		1				KC
	96243345	Y	A	B	B	B	A	A	A	&C59/C60&NN6-JL9		1				8G
	96235347	Y	A	B	B	B	A	A	A	&C46&NN7-JL9		1				6E
	96243341	Y	A	B	B	B	A	A	A	&C59/C60&NN7-JL9		1				8C
	96243342	Y	A	B	B	B	.	A	A	&C59/C60&JL9&NN7		1				8D
	96217040	Y	A	B	B	B	.	A	A	&C46&JL9&NN6		1				KD
	96243346	Y	A	B	B	B	.	A	A	&C59/C60&JL9&NN6		1				8H
	96235348	Y	A	B	B	B	.	A	A	&C46&JL9&NN7		1				6F
	96243374	6	M	B	B	B	.	.	O	&C46&NN4-JL9		1				9M
	96243382	6	M	B	B	B	.	.	O	&C59/C60&NN4-JL9		1				9W
	96243375	6	M	B	B	B	.	.	O	&C46&JL9&NN4		1				9N
	96243383	6	M	B	B	B	.	.	O	&C59/C60&JL9&NN4		1				9X
	96243376	6	A	B	B	B	.	.	O	&C46&NN4-JL9		1				9P
	96243384	6	A	B	B	B	.	.	O	&C59/C60&NN4-JL9		1				9Y
	96243377	6	A	B	B	B	.	.	O	&C46&JL9&NN4		1				9R
	96243385	6	A	B	B	B	.	.	O	&C59/C60&JL9&NN4		1				9Z


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96217041	6	M	B	B	B	.	.	A	&C46&NN6-JL9		1				KE
	96243347	6	M	B	B	B	.	.	A	&C59/C60&NN6-JL9		1				8J
	96217049	6	M	B	B	B	.	.	A	&C46&NN7-JL9		1				KM
	96243353	6	M	B	B	B	.	.	A	&C59/C60&NN7-JL9		1				8Q
	96217042	6	M	B	B	B	.	.	A	&C46&JL9&NN6		1				KF
	96243348	6	M	B	B	B	.	.	A	&C59/C60&JL9&NN6		1				8K
	96217050	6	M	B	B	B	.	.	A	&C46&JL9&NN7		1				KN
	96243354	6	M	B	B	B	.	.	A	&C59/C60&JL9&NN7		1				8R
	96217043	6	A	B	B	B	.	.	A	&C46&NN6-JL9		1				KG
	96243349	6	A	B	B	B	.	.	A	&C59/C60&NN6-JL9		1				8L
	96217051	6	A	B	B	B	.	.	A	&C46&NN7-JL9		1				KP
	96243355	6	A	B	B	B	.	.	A	&C59/C60&NN7-JL9		1				8S
	96217044	6	A	B	B	B	.	.	A	&C46&JL9&NN6		1				KH
	96243350	6	A	B	B	B	.	.	A	&C59/C60&JL9&NN6		1				8M
	96217052	6	A	B	B	B	.	.	A	&C46&JL9&NN7		1				KR
	96243356	6	A	B	B	B	.	.	A	&C59/C60&JL9&NN7		1				8T
[16]	(E)WIRING-ABS REAR SENSOR *(D)VERDRAHTUNG*									*(F)CABLAGE* *(S)INSTALACION ELECTRICA*						
96304995		.	.	B	B	B	.	O	O	&JL9		1				
[17]	(E)WIRING-FUEL TANK *(D)VERDRAHTUNG*									*(F)CABLAGE* *(S)INSTALACION ELECTRICA*						
96232850		.	.	B	B	B	S	S	S			1				6A
[18]	(E)WIRE-CIGAR LIGHTER EXTENS *(D)VERDRAHTUNG*									*(F)CABLES* *(S)ALAMBRE*						
96243388		.	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK





ITC	KEY NO. / PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[19]	(E)WIRING-R.O.N. JUMP (D)VERDRAHTUNG									(F)CABLAGE (S)INSTALACION ELECTRICA					
	96232850	. .	B	B	B	S	S	S				1				6A
	[20]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09115-06001	. .	B	B	B	S	S	S				8				
	[22]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01514-06165	. .	B	B	B	S	S	S				3				
	[23]	(E)COVER-CONNECTION BRACKET (D)DECKEL									(F)CARTER (S)CUBIERTA					
	96234604	. .	B	B	B	S	S	S				1				
	[24]	(E)BRACKET-ENGINE CONT.HARNE (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96234603	. .	B	B	B	S	S	S				1				
	[25]	(E)WIRE-EXTN S/TURN SIG LAMP (G)VERDRAHTUNG-VERLÄNGERUN									(F)CABLAGE-RALLONGE LAMPE (S)INSTALACION ELECTRICA					
-	96245540	. .	B	B	B	A	A	A	&FL6		RH	1				
	[26]	(E)WIRING-SUNROOF (D)VERDRAHTUNG									(F)CABLAGE (S)INSTALACION ELECTRICA					
	96242510	. .	B	.	.	O	O	O				1		970602		
N	96255147	. .	B	.	.	O	O	O				1	970602			2H
	96250676	. .	.	B	.	O	.	O				1		970602		PC
N	96255149	. .	.	B	.	O	.	O				1	970602			2K
	96250675	. .	.	.	B	O	.	O				1		970602		PB
N	96255148	. .	.	.	B	O	.	O				1	970602			2J
	[27]	(E)WIRING-EXTENSION T/GATE (D)VERDRAHTUNG-VERLÄNGERUN									(F)CABLAGE-RALLONGE (S)INSTALACION ELECTRICA					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






For ground
20

KEY NO.	PART NAME																
ITC	PART NO	MODEL									OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL							FROM	TO		
				4N	3H	5H	S	SE	SX								
	96246695	.	.	.	B	B	S	.	S				1				RJ
	[28]	(E)WIRING-EXTENSION A/T (D)VERDRAHTUNG-VERLÄNGERUN											(F)CABLAGE-RALLONGE A/T (S)INSTALACION ELECTRICA				
	96250974	.	A	B	B	B	O	O	O				1				PT

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6 BODY & EXTERIOR


6110 HOOD PANEL
6130 FRONT PANEL
6140 FENDER PANEL
6150 DASH PANEL & COWL
6210 FRONT DOOR PANEL
6220 FRONT DOOR LOCKING
6230 FRONT WINDOW LIFTER
6240 FRONT WEATHERSTRIP
6250 ELECTRIC DOOR LOCKING
6310 REAR DOOR PANEL
6320 REAR DOOR LOCKING
6330 REAR WINDOW LIFTER
6340 REAR WEATHERSTRIP
6360 QUATER WINDOW LOCKING
6410 SIDE BODY PANEL(N/B)
6411 SIDE BODY PANEL(5DOOR H/B)
6412 SIDE BODY PANEL(3DOOR H/B)
6420 FUEL FILLER LOCKING
6430 ROOF PANEL
6440 TRUNK LID PANEL
6441 TAILGATE PANEL
6450 TRUNK LID LOCKING
6451 TAILGATE LOCKING
6460 CAR LOCKING
6510 FRONT FLOOR PANEL
6520 REAR FLOOR PANEL
6530 FRAME
6630 OUTSIDE MIRROR
6640 GLASS I
6641 GLASS II
6650 EMBLEM & LETTERING
6660 WHEELS & WHEEL COVER
6670 LABEL & STICKER
6710 GRILLE
6720 FRONT BUMPER
6730 REAR BUMPER
6750 MUD GUARD



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A-HOOD (D)HAUBE,BLECH									(F)PANNEAU DE CAPOT (S)PANEL DEL CAPO					
	A96303303	.	.	B	B	B	S	S	S	&XCK		1	970502			HA
O	A96255481	.	.	B	B	B	S	S	S	&XCK		1	970502			
	A96307013	.	.	B	B	B	A	A	A	&XCP		1	970502			HB
O	A96256482	.	.	B	B	B	A	A	A	&XCP		1	970502			
	[02]	(E)HINGE A-HOOD (D)BESCHLAG,HAUBE									(F)CHARNIERE-CAPOT (S)BISAGRA					
	96303296	.	.	B	B	B	S	S	S		LH	1	970901			
	96255037	.	.	B	B	B	S	S	S	&XCK	LH	1	970901			
	96303296	.	.	B	B	B	A	A	A	&XCP	LH	1	970901			
	96304580	.	.	B	B	B	S	S	S		RH	1	970901			
	96255038	.	.	B	B	B	S	S	S	&XCK	RH	1	970901			
	96304580	.	.	B	B	B	A	A	A	&XCP	RH	1	970901			
	[03]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01127-08203	.	.	B	B	B	S	S	S			4				
	[04]	(E)BOLT-HEXAGON (D)SCHRAUBE									(F)BOULON (S)PERNO					
	01127-08203	.	.	B	B	B	S	S	S			4				
	[05]	(E)LEVER A-HOOD RELEASE (D)HEBEL									(F)LEVIER (S)PALANCA					
	96236189	.	.	B	B	B	S	S	S			1			INCL #7,8	N5
	[06]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03151-48165	.	.	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6110 HOOD PANEL




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
		(E)CABLE A-HOOD RELEASE (D)KABEL,HAUBE BOGEN									(F)CABLE-BOWDEN DE CAPOT (S)CABLE-CAPO BOWDEN					
[07]																
	96303301	.	.	B	B	B	S	S	S			1			INCL #8	
		(E)GROMMET (D)ÖSE									(F)VIROLE (S)AISLANTE					
[08]																
	96222846	.	.	B	B	B	S	S	S			1				
		(E)SEAT-HOOD HOLD OPEN ROD (D)SITZ,ÖFFNUNGS-STANGE									(F)SIEGE (S)ASIENTO					
[09]																
	90149859	.	.	B	B	B	S	S	S			1				
		(E)INSULATION-HOOD (D)ISOLIERUNG									(F)ISOLATION (S)AISLAMIENTO					
[10]																
	96254519	6	.	B	B	B	.	.	O	-2G3		1				TZ
	96252558	6	.	B	B	B	.	.	A	&2G3		1				TV
		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
[11]																
	09409-06328	6	.	B	B	B	.	.	O			17				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]									(E)PANEL A-FRONT,UPPER *(D)VERKLEIDUNG,VORNE*	*(F)PANNEAU-AVANT* *(S)PANEL-FRENTE*					
	96303597	.	.	B	B	B	S	S	S			1				
	[02]									(E)PANEL A-FRONT,SIDE *(D)VERKLEIDUNG,VORNE*	*(F)PANNEAU-AVANT* *(S)PANEL-FRENTE*					
	96216195	.	.	B	B	B	S	S	S		LH	1				
	96216196	.	.	B	B	B	S	S	S		RH	1				
	[03]									(E)SUPPORT A-FRONT PANEL *(D)TRÄGER,VERKLEIDUNGSBLECH*	*(F)SUPPORT* *(S)SOPORTE*					
	96303601	.	.	B	B	B	S	S	S			1				
	[04]									(E)BOLT *(D)SCHRAUBE*	*(F)BOULON* *(S)PERNO*					
	09118-06001	.	.	B	B	B	S	S	S			3			W/WASHER	
	[05]									(E)LATCH A-HOOD *(D)VERSCHLUß,HAUBE-VERSCHLU*	*(F)LOQUET-VERROU DE CAPOT* *(S)PESTILLO*					
	96303295	.	.	B	B	B	S	S	S			1				K7
	[06]									(E)BUMPER-HOOD,FRONT *(D)STOßSTANGE,HAUBE,VORNE*	*(F)PARE-CHOC-CAPOT,AVANT* *(S)TOPE-CAPO,FRENTE*					
	96245706	.	.	B	B	B	S	S	S			2				
	[07]									(E)BUMPER *(D)STOßSTANGE*	*(F)PARE-CHOC* *(S)PARACHOQUES*					
	96169594	.	.	B	B	B	S	S	S			2				
	[08]									(E)PIVOT A-SUPPORT HOOD *(D)DREHTREIL,TRÄGERWELLE*	*(F)PIVOT-TRINGLE DE SUPPORT* *(S)PIVOTE-VARA DE APOYO*					
	96165268	.	.	B	B	B	S	S	S			1				
	[09]									(E)ROD A-HOOD HOLD OPEN *(D)STAB,HAUBE ÖFFNUNGS*	*(F)TRINGLE* *(S)VARILLA*					
	96233432	.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[10]	(E)BRACKET A-HOOD ROD (D)TRÄGER,ÖFFNUNGSSTANGE									(F)SUPPORT (S)SOPORTE-VARA						
96233191		.	.	B	B	B	S	S	S			1				
[11]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO						
09118-06002		.	.	B	B	B	S	S	S			1			W/WASHER	
[12]	(E)AIR DAM-FRONT (D)LUFTSPERRE,VORNE									(F)BARRAGE AIR-AVANT (S)PRESA DE AIRE-FRENTE						
96216960		.	.	B	B	B	S	S	S			1				
[13]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO						
03152-63162		.	.	B	B	B	S	S	S			4				
[14]	(E)REINF A-HOOD ROD BRACKET (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO						
96235371		.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	(E)PANEL A-FENDER (D)VERKLEIDUNG,KOTFLÜGEL										(F)PANNEAU-GARDE-BOUE (S)ALETA DEL.					
A96303294		.	.	B	B	B	S	S	S	&XCK-FL6	LH	1				FA
A96304579		.	.	B	B	B	S	S	S	&XCK-FL6	RH	1				FN
A96220732		.	.	B	B	B	A	A	A	&FL6&XCK	LH	1				FC
A96220733		.	.	B	B	B	A	A	A	&FL6&XCK	RH	1				FQ
A96221072		.	.	B	B	B	A	A	A	&FL6&XCP	LH	1				FD
A96221073		.	.	B	B	B	A	A	A	&FL6&XCP	RH	1				FR
[02]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO					
09139-06006		.	.	B	B	B	S	S	S			8				
[03]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA					
09148-06019		.	.	B	B	B	S	S	S			8				
[04]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO					
09139-06006		.	.	B	B	B	S	S	S			4				
[05]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA					
09148-06019		.	.	B	B	B	S	S	S			4				
[06]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO					
09139-06006		.	.	B	B	B	S	S	S			4				
[07]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA					
09148-06019		.	.	B	B	B	S	S	S			4				
[08]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09139-06006	.	.	B	B	B	S	S	S		(E)NUT *(D)MUTTER*		2				
	[09]										*(F)ECROU* *(S)TUERCA*						
	09159-06006	.	.	B	B	B	S	S	S		(E)LINER-FENDER *(D)AUSKLEIDUNG,KOTFLÜGEL*		2				
	[10]										*(F)GARNITURE-GARDE-BOUE* *(S)REVESTIMIENTO-GUARDAFANGO*						
	96242551	.	.	B	B	B	S	S	S			LH	1				
	96242552	.	.	B	B	B	S	S	S			RH	1				
	[11]										(E)SCREW-TAPPING *(D)SCHRAUBE*						
	09136-04005	.	.	B	B	B	S	S	S				2				
	[13]										(E)CLIP *(D)KLEMME*						
	09409-07303	.	.	B	B	B	S	S	S				8				
	[14]										(E)BRACE-WHEELHOUSE *(D)SCHIENE,RAD-GEHÄUSE*						
	96306384	.	.	B	B	B	S	S	S			LH	1				HB
	96306385	.	.	B	B	B	S	S	S			RH	1				H2
	[15]										(E)WHEELHOUSE A *(D)VERKLEIDUNG,RAD-GEHÄUSE*						
	96304491	.	.	B	B	B	S	S	S			LH	1				WB
	96250659	.	.	B	B	B	S	S	S			RH	1		970604		W2
Y	96252573	.	.	B	B	B	S	S	S			RH	1	970604			W3
	[16]										(E)PLUG *(D)STOPSEL*						
	09250-10001	.	.	B	B	B	S	S	S				2				
	[17]										(E)SUPPORT A-BATTERY TRAY *(D)TRÄGER*						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96226880	.	.	B	B	B	S	S	S			1				
	[18]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE										(F)BOULON (S)PERNO				
	02860-08203	.	.	B	B	B	S	S	S			2		970509		
Y	01517-08163	.	.	B	B	B	S	S	S			2		970509		
	[19]	(E)TRAY-BATTERY (D)PFANNE,BATTERIE										(F)PLATEAU-BATTERIE (S)BANDEJA-BATERIA				
	96242192	.	.	B	B	B	S	S	S			1				
	[20]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE										(F)BOULON (S)PERNO				
	02860-08203	.	.	B	B	B	S	S	S			1		970509		
Y	01517-08163	.	.	B	B	B	S	S	S			1		970509		
	[21]	(E)GUARD-SPLASH (D)KOTFLÜGEL										(F)GARDE (S)PROTECTOR				
	96251301	.	.	B	B	B	S	S	S			1				
	[22]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	09136-04005	.	.	B	B	B	S	S	S			3		970804		
Y	09136-04013	.	.	B	B	B	S	S	S			3		970804		
	[23]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA				
	09148-04010	.	.	B	B	B	S	S	S			3				
	[24]	(E)HOOK (D)HAKEN										(F)CROCHET (S)PERCHA				
	09410-00100	.	.	B	B	B	S	S	S			1				
	[25]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	09136-04005	.	.	B	B	B	S	S	S			4		970804		

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	Y 09136-04013	.	.	B	B	B	S	S	S			4	970804			
	[26]	(E)SEALING-BUTYL (D)DICHTUNG														
	96238376	.	.	B	B	B	S	S	S			2				
	[27]	(E)SEALING-BUTYL (D)DICHTUNG														
	96245279	.	.	B	B	B	S	S	S			2				
	[28]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														
	01517-08162	.	.	B	B	B	S	S	S			3				
	[29]	(E)INSULATION A-AIR INTAKE (D)ISOLIERUNG														
	96247387	.	.	B	B	B	S	S	S			1				
	[30]	(E)BOLT (D)SCHRAUBE														
	09116-06024	.	.	B	B	B	S	S	S			2			W/WASHER	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




ITC	KEY NO. PART NO	ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01] PART NAME	(E)PANEL A-DASH,UPPER (D)VERKLEIDUNG,ARMATUREN BRET									(F)PANNEAU-TABLEAU DE BORD (S)PANEL-SALPICAR					
	96218304	.	.	B	B	B	S	S	S			1				DB
	[02] PART NAME	(E)PANEL A-DASH,LOWER (D)PLATTE									(F)PLAQUE (S)PLACA-GOLPEADOR					
	96246763	.	.	B	B	B	S	S	S			1				D4
	[03] PART NAME	(E)WEATHERSTRIP-HOOD (D)DICHTUNGSLEISTE									(F)ISOLATION EN BANDELETTE (S)BURLETE					
	96303226	.	.	B	B	B	S	S	S			1				
	[04] PART NAME	(E)COWL (D)HAUBE									(F)CHAPEAU (S)CAPUCHA					
	96304672	.	.	B	B	B	S	S	S		LH	1				
	96304673	.	.	B	B	B	S	S	S		RH	1				
	[05] PART NAME	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-06327	.	.	B	B	B	S	S	S			5				
	[06] PART NAME	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42132	.	.	B	B	B	S	S	S			2		970602		
N	09132-05002	.	.	B	B	B	S	S	S			2	970602			
	[07] PART NAME	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-03001	.	.	B	B	B	S	S	S			2				
	[08] PART NAME	(E)SUPPORT A-DASH PANEL (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96233565	.	A	B	B	B	O	O	O			1		970512		
O	96247422	.	A	B	B	B	O	O	O			1	970512			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[09]	(E)NUT (D)MUTTER											(F)ECROU (S)TUERCA				
09159-08003		.	A	B	B	B	O	O	O			5				
[10]	(E)COVER A-DASH,TOP (D)DECKEL											(F)COUVERCLE (S)CUBIERTA				
96242195		.	.	B	B	B	S	S	S			1				
[11]	(E)COVER- FLANGE,DASH TOP (D)DECKEL											(F)COUVERCLE (S)CUBIERTA				
96246176		.	.	B	B	B	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A-FRONT DOOR (D)VERKLEIDUNG,VORDERTÜR									(F)PANNEAU-PORTE AVANT (S)PANEL-PUERTA DEL FRENTE					
	A96307283	.	.	B	.	B	S	S	S	&XCK	LH	1				RA
	A96307284	.	.	B	.	B	S	S	S	&XCK	RH	1				R1
	A96303836	.	.	B	.	B	A	A	A	&XCP	LH	1				RB
	A96303837	.	.	B	.	B	A	A	A	&XCP	RH	1				R2
	A96307281	.	.	.	B	.	S	.	S	&XCK	LH	1				KA
	A96307282	.	.	.	B	.	S	.	S	&XCK	RH	1				K1
	A96303834	.	.	.	B	.	A	.	A	&XCP	LH	1				KB
	A96303835	.	.	.	B	.	A	.	A	&XCP	RH	1				K2
	[02]	(E)PANEL-FRONT DOOR OUTER (D)VERKLEIDUNG									(F)PANNEAU (S)PANEL					
	A96310023	.	.	B	.	B	S	S	S	&XCK	LH	1				
	A96310024	.	.	B	.	B	S	S	S	&XCK	RH	1				
	A96303911	.	.	B	.	B	A	A	A	&XCP	LH	1				
	A96303912	.	.	B	.	B	A	A	A	&XCP	RH	1				
	A96310021	.	.	.	B	.	S	.	S	&XCK	LH	1				
	A96310022	.	.	.	B	.	S	.	S	&XCK	RH	1				
	A96303909	.	.	.	B	.	A	.	A	&XCP	LH	1				
	A96303910	.	.	.	B	.	A	.	A	&XCP	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)LATCH A-FRONT DOOR (D)VERSCHLUß,VORDERTÜR									(F)LOQUET-PORTE AVANT (S)PESTILLO-PUERTA					
	96306416	. .	B	B	B	S	S	.	-AU3	LH	1					
	96306418	. .	B	B	B	S	S	.	-AU3	RH	1					
	96306409	. .	B	B	B	O	O	S	&AU3	LH	1					
	96306412	. .	B	B	B	O	O	S	&AU3	RH	1					
	[02]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09125-06002	. .	B	B	B	S	S	S			6					
	[03]	(E)ROD-FRONT DOOR LOCKING (D)STAB									(F)TRINGLE (S)VARILLA					
	96304033	. .	B	.	B	S	S	S		LH	1					
	96304034	. .	B	.	B	S	S	S		RH	1					
	96304756	. .	.	B	.	S	.	S		LH	1					
	96304757	. .	.	B	.	S	.	S		RH	1					
	[04]	(E)ROD-FRT DOOR INSIDE HANDL (D)STAB									(F)TRINGLE (S)VARILLA					
	96304031	. .	B	.	B	S	S	S		LH	1					
	96304032	. .	B	.	B	S	S	S		RH	1					
	96304754	. .	.	B	.	S	.	S		LH	1					
	96304755	. .	.	B	.	S	.	S		RH	1					
	[05]	(E)ROD-FRT DOOR KEY CYLINDER (D)STAB									(F)TRINGLE (S)VARILLA					
	96304000	. .	B	.	B	S	S	S		LH	1					
	96304001	. .	B	.	B	S	S	S		RH	1					
	96304752	. .	.	B	.	S	.	S		LH	1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96304753	.	.	.	B	.	S	.	S		RH	1				
[06]	(E)CLIP (D)KLEMME										(F)ATTACHE (S)GRAPA					
	09408-00021	.	.	B	B	B	S	S	S			2				
[07]	(E)HANDLE A-FRT DOOR OUTSIDE (D)HENKEL,TÜR,AUßEN										(F)POIGNEE-EXTERIEURE PORTE (S)MANIJA-EXTERNA PUERTA					
	96226249	.	.	B	.	B	S	S	S		LH	1				NA
	96226250	.	.	B	.	B	S	S	S		RH	1				NB
	96226251	.	.	.	B	.	S	.	S		LH	1				NC
	96226252	.	.	.	B	.	S	.	S		RH	1				ND
[08]	(E)CLAMP (D)KLAMMER										(F)PINCE (S)ABRAZADERA					
	09403-04301	.	.	B	B	B	S	S	S			2				
[09]	(E)ROD-OUTSIDE HANDLE (D)STAB,AUßEN-GRIFF										(F)TRINGLE (S)VARILLA-MANIJA EXTERNA					
	96304016	.	.	B	.	B	S	S	S			2				
	96306632	.	.	.	B	.	S	.	S			2				
[10]	(E)BOLT-HEXAGON (D)SCHRAUBE										(F)BOULON (S)PERNO					
	01114-06103	.	.	B	B	B	S	S	S			4				
[11]	(E)CHECK A-FRONT DOOR (D)TÜR-PRÜF										(F)ARRET-PORTE (S)PUERTA DE VERIFICAR					
	96303990	.	.	B	B	B	S	S	S		LH	1				
	96303991	.	.	B	B	B	S	S	S		RH	1				
[12]	(E)BOLT-HEXAGON (D)SCHRAUBE										(F)BOULON (S)PERNO					
	01117-06162	.	.	B	B	B	S	S	S			4				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6220 FRONT DOOR LOCKING




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[13]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09118-08003	.	.	B	B	B	S	S	S			2	970512		W/WASHER	
Y	09118-08009	.	.	B	B	B	S	S	S			2	970512		W/WASHER	
	[14]	(E)HINGE A-FRONT DOOR (D)BESCHLAG,VORDERTÜR									(F)CHARNIERE-PORTE AVANT (S)BISAGRA-PUERTA					
	96224310	.	.	B	B	B	S	S	S		LH	1			UPPER	EA
	96224311	.	.	B	B	B	S	S	S		LH	1			LOWER	EB
	96224311	.	.	B	B	B	S	S	S		RH	1			UPPER	EB
	96224310	.	.	B	B	B	S	S	S		RH	1			LOWER	EA
	[15]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09118-08008	.	.	B	B	B	S	S	S			8			W/WASHER	
	[16]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09103-08018	.	.	B	B	B	S	S	S			8				
	[17]	(E)SWITCH A-DOOR CONTACT (D)SCHALTER,TÜR KONTAKT									(F)COMMUTATEUR-CONTACT PORTE (S)INTERRUPTOR					
	96235956	.	.	B	B	B	S	S	S			2				
	[18]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03170-42095	.	.	B	B	B	S	S	S			2				
	[19]	(E)STRIKER A-DOOR (D)SCHLÄGER									(F)MARTEAU (S)HUELGUISTA					
	96301668	.	.	B	B	B	S	S	S			2				
	[20]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09119-08026	.	.	B	B	B	S	S	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	[21]									(E)WASHER-DISTANCE (D)DICHTUNGSRING,DISTANZ						
	[21]									(F)RONDELLE-DISTANCE (S)ARANDELA-DISTANCIA						
	96216377	.	.	B	B	B	S	S	S			2				
	[22]									(E)BUMPER-TRUNK LID,LWR (D)STOßSTANGE						
	[22]									(F)PARE-CHOC (S)PARACHOQUES						
	96240768	.	.	B	.	B	S	S	S			2				
	96169620	.	.	.	B	.	S	.	S			2				
	[23]									(E)STRIP-INSULATING (D)AUSZIEHEN						
	[23]									(F)BANDE (S)FLEJE						
	96249231	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)MOLDING A-FRT DOOR OTR CH (D)MOLDURA-PUERTA DELANTE									(F)MOULURE-PORTE AVANT (S)PREßTEIL,VORDERTÜR					
	96304086	.	.	B	.	B	S	S	S		LH	1				
	96304087	.	.	B	.	B	S	S	S		RH	1				
	96304084	.	.	.	B	.	S	.	S		LH	1				
	96304085	.	.	.	B	.	S	.	S		RH	1				
	[02]	(E)GLASS RUN-FRONT DOOR (D)RILLE,SCHEIBE,ABLAUF									(F)RAINURE-CHEMIN DE GLACE (S)CANAL-CORRIDA DE VIDRIO					
	96304082	.	.	B	.	B	S	S	S		LH	1				
	96304083	.	.	B	.	B	S	S	S		RH	1				
	96304080	.	.	.	B	.	S	.	S		LH	1				
	96304081	.	.	.	B	.	S	.	S		RH	1				
	[03]	(E)RAIL A-FRT DOOR GUIDE,RR (D)SCHIENE,FÜHRUNG									(F)RAIL-GUIDE (S)RIEL-GUIA					
	96246242	.	.	B	.	B	S	S	S		LH	1		970901		
O	96257724	.	.	B	.	B	S	S	S		LH	1	970901			
	96246243	.	.	B	.	B	S	S	S		RH	1		970901		
O	96257725	.	.	B	.	B	S	S	S		RH	1	970901			
	96303993	.	.	.	B	.	S	.	S		LH	1		970901		
O	96257722	.	.	.	B	.	S	.	S		LH	1	970901			
	96303994	.	.	.	B	.	S	.	S		RH	1		970901		
O	96257723	.	.	.	B	.	S	.	S		RH	1	970901			
	[04]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09116-06034	.	.	B	B	B	S	S	S			4			W/WASHER	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[06]	(E)GARNISH-FRONT DOOR CENTER *(D)VERZIERUNG*										*(F)GARNITURE* *(S)ORNAMENTO*					
96304715		.	.	B	.	B	S	S	S		LH	1				
96304716		.	.	B	.	B	S	S	S		RH	1				
96304713		.	.	.	B	.	S	.	S		LH	1				
96304714		.	.	.	B	.	S	.	S		RH	1				
[06]	(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*					
03111-42132		.	.	B	.	B	S	S	S			6				
09132-04009		.	.	.	B	.	S	.	S			2		970701		
N 09136-04011		.	.	.	B	.	S	.	S			2	970701			
[07]	(E)COVER A-WINDOW FRAME INR *(D)DECKEL,FENSTERRAHMEN*										*(F)COUVERTURE* *(S)CUBIERTA-MARCO DE VENTANA*					
96304172		.	.	B	B	B	S	S	S	&D33	LH	1				
96304173		.	.	B	B	B	S	S	S	&D39	RH	1				
96304175		.	.	B	B	B	.	.	O	&DD4	RH	1				
[08]	(E)LIFTER-FRT DOOR WINDOW *(D)HEBER,FENSTERSCHEIBE*										*(F)LEVIER-FENETRE,AVANT* *(S)LEVANTADOR-VENTANA*					
96304038		.	.	B	.	B	S	S	.	&A30	LH	1				W1
96304040		.	.	B	.	B	S	S	.	&A30	RH	1				W2
96225383		.	.	B	.	B	O	O	S	&A32/A31	LH	1				
96225384		.	.	B	.	B	O	O	S	&A32/A31	RH	1				
96304039		.	.	.	B	.	S	.	.	&A30	LH	1				W3
96304041		.	.	.	B	.	S	.	.	&A30	RH	1				W4
96233470		.	.	.	B	.	O	.	S	&A32	LH	1				
96233471		.	.	.	B	.	O	.	S	&A32	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	PART NAME															
	[09]	(E)NUT-HEXAGON FLANGE (D)MUTTER									(F)ECROU (S)TUERCA					
	08316-25063	.	.	B	B	B	S	S	.	&A30		12				
	08316-25063	.	.	B	B	B	O	O	S	&A32/A31		14				
	[10]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	96227795	.	.	B	B	B	O	O	S	&A32/A31		6				
	[11]	(E)MOTOR A-POWER WINDOW (D)MOTOR,FENSTERSCHEIBE									(F)MOTEUR (S)MOTOR-VENTANA ELECTRICA					
	96190207	.	.	B	B	B	O	O	S	&A32/A31	LH	1				TC
	96190208	.	.	B	B	B	O	O	S	&A32/A31	RH	1				TD

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6240 FRONT WEATHERSTRIP

5H09




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]										(E)COVER-FRT DOOR OPEN FLANG *(D)DECKEL*		*(F)CARTER* *(S)CUBIERTA*				
96238367		.	.	B	.	B	S	S	S			2				
96238366		.	.	.	B	.	S	.	S			2				
[02]										(E)WEATHERSTRIP A FRONT DOOR *(D)DICHTUNGSLEISTE*		*(F)ISOLATION EN BANDELETTE* *(S)BURLETE*				
96304074		.	.	B	.	B	S	S	S		LH	1				
96304075		.	.	B	.	B	S	S	S		RH	1				
96304072		.	.	.	B	.	S	.	S		LH	1				
96304073		.	.	.	B	.	S	.	S		RH	1				
[03]										(E)WEATHERSTRIP-FR DOOR,2ND *(D)DICHTUNGSLEISTE*		*(F)ISOLATION EN BANDELETTE* *(S)BURLETE*				
96304078		.	.	B	.	B	S	S	S		LH	1				
96304079		.	.	B	.	B	S	S	S		RH	1				
96304076		.	.	.	B	.	S	.	S		LH	1				
96304077		.	.	.	B	.	S	.	S		RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)ACTUATOR A-DOOR (D)BETÄTIGUNG									(F)ACTIONNEUR (S)ACTUADOR					
[02]	96229552	. .	B	B	B	O	O	S	&AU3		1			CO DRIVE		
		(E)RELAY A-CENTRAL DOOR LOCK (D)RELAIS									(F)RELAI (S)RELEVADOR					
[03]	96216279	. .	B	B	B	O	O	S	&AU3		1					
		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
[04]	01517-06123	. .	B	B	B	O	O	S	&AU3		1					
		(E)ACTUATOR A-DOOR (D)BETÄTIGUNG									(F)ACTIONNEUR (S)ACTUADOR					
[05]	96229551	. .	B	.	B	O	O	S	&AU3		LH	1				
	96229552	. .	B	.	B	O	O	S	&AU3		RH	1				
		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
[06]	07-2012-0011	. .	B	B	B	O	O	S	&AU3		1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A-REAR DOOR (D)VERKLEIDUNG,HINTERTÜR									(F)PANNEAU-PORTE ARRIERE (S)PANEL-PUERTA TRASERA					
	A96310031	.	.	B	.	B	S	S	S	&XCK	LH	1				RA
	A96310032	.	.	B	.	B	S	S	S	&XCK	RH	1				R1
	A96303928	.	.	B	.	B	A	A	A	&XCP	LH	1				RB
	A96303929	.	.	B	.	B	A	A	A	&XCP	RH	1				R2
	[02]	(E)PANEL-REAR DOOR OUTER (D)VERKLEIDUNG									(F)PANNEAU (S)PANEL					
	A96310058	.	.	B	.	B	S	S	S	&XCK	LH	1				
	A96310059	.	.	B	.	B	S	S	S	&XCK	RH	1				
	A96303970	.	.	B	.	B	A	A	A	&XCP	LH	1				
	A96303971	.	.	B	.	B	A	A	A	&XCP	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)LATCH A-REAR DOOR (D)VERSCHLUß,HINTERTÜR									(F)LOQUET-PORTE ARRIERE (S)PESTILLO-PUERTA TRASERA					
	96305419	.	.	B	.	B	S	S	.	-AU3	LH	1				
	96305420	.	.	B	.	B	S	S	.	-AU3	RH	1				
	96305413	.	.	B	.	B	O	O	S	&AU3	LH	1				
	96305414	.	.	B	.	B	O	O	S	&AU3	RH	1				
	[02]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09125-06002	.	.	B	.	B	S	S	S			6				
	[03]	(E)ROD-REAR DOOR LOCKING (D)STAB									(F)TRINGLE (S)VARILLA-CON CIERRE DE PUE					
	96304127	.	.	B	.	B	S	S	S		LH	1				
	96304128	.	.	B	.	B	S	S	S		RH	1				
	[04]	(E)ROD-RR DOOR INSIDE HANDLE (D)STAB									(F)TRINGLE (S)VARILLA					
	96304125	.	.	B	.	B	S	S	S		LH	1				
	96304126	.	.	B	.	B	S	S	S		RH	1				
	[06]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09408-00021	.	.	B	.	B	S	S	S			2				
	[07]	(E)HANDLE A-RR DOOR OUTSIDE (D)HENKEL,TÜR,AUßEN									(F)POIGNEE-EXTERIEURE PORTE (S)MANIJA-EXTERNA PUERTA					
	96226329	.	.	B	.	B	S	S	S		LH	1				NE
	96226330	.	.	B	.	B	S	S	S		RH	1				NF
	[08]	(E)CLAMP (D)KLAMMER									(F)PINCE (S)ABRAZADERA					
	09403-04301	.	.	B	.	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[09]										(E)ROD-RR DOOR OUTSIDE HANDL *(D)STAB,AUßEN-GRIFF*	*(F)TRINGLE* *(S)VARILLA-MANIJA EXTERNA*					
	96304110	.	.	B	.	B	S	S	S			2				
[10]										(E)BOLT-HEXAGON *(D)SCHRAUBE*	*(F)BOULON* *(S)PERNO*					
	01114-06103	.	.	B	.	B	S	S	S			4				
[11]										(E)CHECK A-REAR DOOR *(D)TÜR-PRÜF*	*(F)ARRET-PORTE* *(S)PUERTA DE VERIFICAR*					
	96304088	.	.	B	.	B	S	S	S		LH	1				
	96304089	.	.	B	.	B	S	S	S		RH	1				
[12]										(E)BOLT-HEXAGON *(D)SCHRAUBE*	*(F)BOULON* *(S)PERNO*					
	01117-06162	.	.	B	.	B	S	S	S			4				
[13]										(E)BOLT *(D)SCHRAUBE*	*(F)BOULON* *(S)PERNO*					
	09118-08003	.	.	B	.	B	S	S	S			2		970512	W/WASHER	
Y	09118-08009	.	.	B	.	B	S	S	S			2	970512		W/WASHER	
[14]										(E)HINGE A-REAR DOOR *(D)BESCHLAG,HINTERTÜR*	*(F)CHARNIERE-PORTE ARRIERE* *(S)BISAGRA-PUERTA*					
	96224312	.	.	B	.	B	S	S	S		LH	1			UPPER	HA
	96224313	.	.	B	.	B	S	S	S		LH	1			LOWER	HB
	96224313	.	.	B	.	B	S	S	S		RH	1			UPPER	HB
	96224312	.	.	B	.	B	S	S	S		RH	1			LOWER	HA
[15]										(E)BOLT *(D)SCHRAUBE*	*(F)BOULON* *(S)PERNO*					
	09118-08008	.	.	B	.	B	S	S	S			8			W/WASHER	
[16]										(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*	*(F)BOULON* *(S)PERNO*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09103-08018	.	.	B	.	B	S	S	S			8				
	[17]	(E)SWITCH A-DOOR CONTACT *(D)SCHALTER,TÜR KONTAKT*													*(F)COMMUTATEUR-CONTACT PORTE* *(S)INTERRUPTOR*	
	96235956	.	.	B	.	B	S	S	S			2				
	[18]	(E)SCREW-TAPPING *(D)SCHRAUBE*													*(F)VIS* *(S)TORNILLO*	
	03170-42095	.	.	B	.	B	S	S	S			2				
	[19]	(E)STRIKER A-DOOR *(D)SCHLÄGER*													*(F)MARTEAU* *(S)HUELGUISTA*	
	96301668	.	.	B	.	B	S	S	S			2				
	[20]	(E)BOLT *(D)SCHRAUBE*													*(F)BOULON* *(S)PERNO*	
	09119-08026	.	.	B	.	B	S	S	S			4				
	[21]	(E)WASHER-DISTANCE *(D)DICHTUNGSRING,DISTANZ*													*(F)RONDELLE-DISTANCE* *(S)ARANDELA-DISTANCIA*	
	96216377	.	.	B	.	B	S	S	S			2				
	[22]	(E)BUMPER-TRUNK LID,LWR *(D)STOßSTANGE*													*(F)PARE-CHOC* *(S)PARACHOQUES*	
	96169620	.	.	B	.	B	S	S	S	*		2				
	[23]	(E)PLUG-REAR DOOR *(D)STÖPSEL*													*(F)BOUCHON* *(S)TAPON*	
	96236225	.	.	B	.	B	S	S	.	-AU3		2				
	[24]	(E)STRIP-INSULATING *(D)AUSZIEHEN*													*(F)BANDE* *(S)FLEJE*	
	96249231	.	.	B	.	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)MOLDING-RR DR OTR CHANNEL *(D)MOLDURA-PUERTA TRASERA*									*(F)MOULURE-PORTE ARRIERE* *(S)PREßTEIL,HINTERTÜR*					
	96304162	.	.	B	.	B	S	S	S		LH	1				
	96304163	.	.	B	.	B	S	S	S		RH	1				
	[02]	(E)GLASS RUN-REAR DOOR *(D)RILLE,SCHEIBE,ABLAUF*									*(F)RAINURE-CHEMIN DE GLACE* *(S)CANAL-CORRIDA DE VIDRIO*					
	96304158	.	.	B	.	B	S	S	S		LH	1				
	96304159	.	.	B	.	B	S	S	S		RH	1				
	[03]	(E)RAIL A-REAR DOOR GUIDE,RR *(D)SCHIENE,FÜHRUNG*									*(F)RAIL-GUIDE* *(S)RIEL-GUIA*					
	96247142	.	.	B	.	B	S	S	S		LH	1				
	96247143	.	.	B	.	B	S	S	S		RH	1				
	[04]	(E)BOLT *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
	09116-06034	.	.	B	.	B	S	S	S			4			W/WASHER	
	[06]	(E)GARNISH A-RR DOOR, CENTER *(D)VERZIERUNG*									*(F)GARNITURE* *(S)ORNAMENTO*					
	96304726	.	.	B	.	B	S	S	S		LH	1				
	96304727	.	.	B	.	B	S	S	S		RH	1				
	[07]	(E)SCREW-TAPPING *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
	03111-42132	.	.	B	.	B	S	S	S			6				
	[08]	(E)COVER-WINDOW FRAME INNER *(D)DECKEL,FENSTERRAHMEN*									*(F)COUVERTURE* *(S)CUBIERTA-MARCO DE VENTANA*					
	96238369	.	.	B	.	B	S	S	S		LH	1		971001		
O	96256348	.	.	B	.	B	S	S	S		LH	1	971001			
	96238370	.	.	B	.	B	S	S	S		RH	1		971001		


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6330 REAR WINDOW LIFTER




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
O	96256349	.	.	B	.	B	S	S	S		RH	1	971001			
	[09]	(E)GARNISH A-REAR DOOR, REAR (D)VERZIERUNG									(F)GARNITURE (S)ORNAMENTO					
	96304733	.	.	B	.	B	S	S	S		LH	1				
	96304734	.	.	B	.	B	S	S	S		RH	1				
	[10]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03140-42135	.	.	B	.	B	S	S	S			6				
	[11]	(E)REGULATOR A-RR DOOR WDO (D)REGULATOR									(F)REGULATEUR (S)REGULADOR					
	96304132	.	.	B	.	B	S	S	S	&A30/A32	LH	1				A1
	96304134	.	.	B	.	B	S	S	S	&A30/A32	RH	1				A2
	96245711	.	.	B	.	B	.	O	O	&A31	LH	1				
	96245712	.	.	B	.	B	.	O	O	&A31	RH	1				
	[12]	(E)NUT-HEXAGON FLANGE (D)MUTTER									(F)ECROU (S)TUERCA					
	08316-25063	.	.	B	.	B	S	S	S	&A30/A32		12				
	08316-25063	.	.	B	.	B	.	O	O	&A31		14				
	[13]	(E)MOTOR A-POWER WINDOW (D)MOTOR,FENSTERSCHEIBE									(F)MOTEUR (S)MOTOR-VENTANA ELECTRICA					
	96190207	.	.	B	.	B	.	O	O	&A31	LH	1				TC
	96190208	.	.	B	.	B	.	O	O	&A31	RH	1				TD

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME																
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)COVER-RR DOOR OPEN'G FLAN (D)DECKEL									(F)CARTER (S)CUBIERTA					
	96238367	.	.	B	.	.	S	S	.	&AM6		2				
	96238366	.	.	B	.	.	.	.	S	&AM9		2				
	96238366	.	.	B	.	.	A	A	A	&AMB		2				
	96238366	.	.	.	.	B	S	.	S	&AMB/AM9		2				
	[02]	(E)WEATHERSTRIP A-REAR DOOR (D)DICHTUNGSLEISTE									(F)ISOLATION EN BANDELETTE (S)BURLETE					
	96304154	.	.	B	.	B	S	S	S		LH	1				
	96304155	.	.	B	.	B	S	S	S		RH	1				
	[03]	(E)WEATHERSTRIP-RR DOOR,2ND (D)DICHTUNGSLEISTE									(F)ISOLATION EN BANDELETTE (S)BURLETE					
	96304156	.	.	B	.	B	S	S	S		LH	1				
	96304157	.	.	B	.	B	S	S	S		RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]									(E)LOCK A-HINGED WINDOW *(D)SCHLOß*					*(F)VERROU* *(S)CERRADURA-VENTANABISAGRA*	
	96307266	.	.	.	B	.	S	.	S			2				
	[02]									(E)PIN-HINGED WINDOW LOCK *(D)STIFT,FENSTERVERSCHLUß*					*(F)BROCHE* *(S)PASADOR*	
	03437757	.	.	.	B	.	S	.	S			2		970325		
O	96251236	.	.	.	B	.	S	.	S			2	970325			
	[03]									(E)GROMMET *(D)ÖSE*					*(F)VIROLE* *(S)AISLANTE*	
	96222232	.	.	.	B	.	S	.	S			4				
	[04]									(E)NUT A-HINGED WINDOW *(D)MUTTER*					*(F)ECROU* *(S)TUERCA*	
	90047124	.	.	.	B	.	S	.	S			2				
	[05]									(E)SUPPORT-HINGED WDO PIVOT *(D)TRÄGER*					*(F)SUPPORT* *(S)SOPORTE*	
	03466314	.	.	.	B	.	S	.	S			2				
	[06]									(E)SCREW-CR MACHINE *(D)SCHRAUBE*					*(F)VIS* *(S)TORNILLO*	
	02116-05083	.	.	.	B	.	S	.	S			2				
	[07]									(E)WASHER-TOOTHED LOCK *(D)DICHTUNGSRING*					*(F)RONDELLE-VERROU DE DENT* *(S)ARANDELA-CIERRE DE DIENTE*	
	09163-05002	.	.	.	B	.	S	.	S			2				
	[08]									(E)SCREW-TAPPING *(D)SCHRAUBE*					*(F)VIS* *(S)TORNILLO*	
	03140-42135	.	.	.	B	.	S	.	S			6				
	[09]									(E)GARNISH-HINGED WINDOW *(D)VERZIERUNG*					*(F)GARNITURE* *(S)ORNAMENTO*	
	96251191	.	.	.	B	.	S	.	S			LH 1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME L/R	PART NAME QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	PICODE
	96251192	.	.	.	B	.	S	.	S		RH	1				
	[10]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42135	.	.	.	B	.	S	.	S			6				
	[11]	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-03001	.	.	.	B	.	S	.	S			4				
	[12]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42132	.	.	.	B	.	S	.	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A1-SIDE (D)VERKLEIDUNG A1,SEITE,AUßEN									(F)PANNEAU A1-COTE EXTERNE (S)PANEL A1-LADO EXTERNO					
	A96226341	.	.	B	.		S	S	.	&AM6-CF6	LH	1				S6
	A96226342	.	.	B	.		S	S	.	&AM6-CF6	RH	1				SF
	A96248519	.	.	B	.		O	O	.	&AM6&CF6	LH	1				G3
	A96248520	.	.	B	.		O	O	.	&AM6&CF6	RH	1				SM
	A96306503	.	.	B	.		.	.	S	&AM9-CF6	LH	1				S8
	A96306503	.	.	B	.		A	A	A	&AMB-CF6	LH	1				S8
	A96306504	.	.	B	.		.	.	S	&AM9-CF6	RH	1				SH
	A96306504	.	.	B	.		A	A	A	&AMB-CF6	RH	1				SH
	A96248523	.	.	B	.		.	.	O	&AM9&CF6	LH	1				G5
	A96248524	.	.	B	.		.	.	O	&AM9&CF6	RH	1				SP
	[03]	(E)PANEL-SIDE OUTER (D)VERKLEIDUNG,SEITE,AUßEN									(F)PANNEAU-COTE EXTERNE (S)PANEL-LADO EXTERNO					
	A96306511	.	.	B	.		S	S	S		LH	1				S6
	A96306512	.	.	B	.		S	S	S		RH	1	970623			SF
N	A96255371	.	.	B	.		S	S	S		RH	1	970623			D6
	[04]	(E)REINF A-CENTER PILLAR (D)VERSTÄRKUNG,ZENTRAL-SÄULE									(F)RENFORCEMENT (S)REFUERZO-PILAR DEL CENTRO					
	96244271	.	.	B	.		S	S	S		LH	1				
	96244272	.	.	B	.		S	S	S		RH	1				
	[05]	(E)PANEL-SIDE INNER (D)VERKLEIDUNG,SEITE,INNEN									(F)PANNEAU-COTE INTERNE (S)PANEL-LADO INTERNO					
	96306560	.	.	B	.		S	S	S		LH	1				
	96306561	.	.	B	.		S	S	S		RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[06]	(E)WHEELHOUSE A-INNER (D)VERKLEIDUNG,RAD-GEHÄUSE									(F)PANNEAU-IMONERIE (S)PANEL-VOLANTE INTERNO					
	96307026	.	.	B	.	.	S	S	.	&AM6	LH	1				WB
	96307027	.	.	B	.	.	S	S	.	&AM6	RH	1				W2
	96226337	.	.	B	.	.	.	.	S	&AM9	LH	1				WD
	96226337	.	.	B	.	.	A	A	A	&AMB	LH	1				WD
	96226338	.	.	B	.	.	.	.	S	&AM9	RH	1				W4
	96226338	.	.	B	.	.	A	A	A	&AMB	RH	1				W4
	[07]	(E)PILLAR A-FRONT (D)SÄULE,VORDER-KAROSSERIE									(F)PILIER-CORPS AVANT (S)PILAR-FRENTE DE CUERPO					
	96303787	.	.	B	.	.	S	S	S		LH	1				LA
	96303788	.	.	B	.	.	S	S	S		RH	1				L1
	[08]	(E)PATCH-FRONT PILLAR (D)TEIL,VORDER-SÄULE									(F)PIECE-PILIER,AVANT (S)PIEZA-FRENTE DE PILAR					
	96233763	.	.	B	.	.	S	S	S		LH	1				
	96233764	.	.	B	.	.	S	S	S		RH	1				
	[09]	(E)PILLAR A-FRONT,INNER (D)SÄULE,VORDER-KAROSSERIE									(F)PILIER-CORPS AVANT (S)PILAR-FRENTE DE CUERPO					
	96307046	.	.	B	.	.	S	S	S		LH	1				
	96307047	.	.	B	.	.	S	S	S		RH	1				
	[10]	(E)REINF A-FRONT PILLAR,LWR (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO-BISAGRA					
	96306612	.	.	B	.	.	S	S	S		LH	1				NA
	96306613	.	.	B	.	.	S	S	S		RH	1				N1
	[11]	(E)REINFORCEMENT-ROCKER (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO					
	96242967	.	.	B	.	.	S	S	S		LH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96242968	.	.	B	.	.	S	S	S		RH	1				
	[12]	(E)REINF-RR DOOR STRIKER *(D)VERSTÄRKUNG*									*(F)RENFORCEMENT* *(S)REFUERZO*					
	96303715	.	.	B	.	.	S	S	S		LH	1				RA
	96303716	.	.	B	.	.	S	S	S		RH	1				R1
	[13]	(E)GUSSET-SIDE PANEL OUTER *(D)ECKBLECH*									*(F)GOUSSET-PANNEAU DE COTE* *(S)ANGULAR-PANEL DEL LADO*					
	96306513	.	.	B	.	.	S	S	S		LH	1				
	96306514	.	.	B	.	.	S	S	S		RH	1				
	[14]	(E)PATCH-TAIL LAMP HOUSING *(D)TEIL-GEHÄUSE*									*(F)PIECE-LOGEMENT* *(S)PIEZA-CARCASA*					
	96306522	.	.	B	.	.	S	S	S		LH	1				
	96306523	.	.	B	.	.	S	S	S		RH	1				
	[15]	(E)EXTENSION-SIDE PANEL OTR *(D)VERLÄNGERUNG,SEITE,AUßEN*									*(F)EXTENSION-COTE,EXTERIEUR* *(S)EXTENSION-LADO EXTERIOR*					
	96306538	.	.	B	.	.	S	S	S		LH	1				ED
	96306539	.	.	B	.	.	S	S	S		RH	1				E4
	[16]	(E)SPACER A-SIDE BODY,REAR *(D)DISTANZSTÜCK*									*(F)ENTRETOISE* *(S)ESPACIADOR*					
	96306484	.	.	B	.	.	S	S	S		LH	1				AD
	96306485	.	.	B	.	.	S	S	S		RH	1				A4
	[17]	(E)INSERT A-VENTILATION *(D)EINSATZ,VENTILATOR*									*(F)INSERTION-VENTILATION* *(S)REFUERZO-VENTILACION*					
	96242978	.	.	B	.	.	S	S	S			2				
	[18]	(E)PANEL-QUATER *(D)VERKLEIDUNG,VIERTEL*									*(F)PANNEAU-QUART* *(S)PANEL-CUADRANTE*					
	A96250421	.	.	B	.	.	S	S	S		LH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	PICODE
	A96250422	.	.	B	.		S	S	S		RH	1				
[19]	(E)PANEL-ROOF SIDE (D)VERKLEIDUNG,SEITE,AUßEN										(F)PANNEAU-COTE EXTERNE (S)PANEL-LADO EXTERNO ,TECHO					
	A96248534	.	.	B	.		S	S	S		LH	1				
	A96248535	.	.	B	.		S	S	S		RH	1				
[20]	(E)PANEL-HINHE PILLAR,CTR (D)VERKLEIDUNG,BESCHLAG,SÄUL										(F)PANNEAU (S)PANEL-PILAR BISAGAR					
	A96248536	.	.	B	.		S	S	S		LH	1				
	A96248537	.	.	B	.		S	S	S		RH	1				
[21]	(E)PANEL-ROCKER (D)VERKLEIDUNG,SCHWENKUNG										(F)PANNEAU-CULBUTEUR (S)PANEL-ARCO EXTERNO					
	A96248538	.	.	B	.		S	S	S		LH	1				
	A96248539	.	.	B	.		S	S	S		RH	1				
[22]	(E)PANEL-HINHE PILLAR,FRONT (D)VERKLEIDUNG,BESCHLAG,SÄUL										(F)PANNEAU (S)PANEL-PILAR BISAGRA					
	A96248540	.	.	B	.		S	S	S		LH	1				
	A96248541	.	.	B	.		S	S	S		RH	1				
[23]	(E)REINF A-LOCK PILLAR (D)VERSTÄRKUNG										(F)RENFORCEMENT (S)REFUERZO					
	96303747	.	.	B	.	.	S	S	S		LH	1				
	96303748	.	.	B	.	.	S	S	S		RH	1				
[24]	(E)REINF A-REAR ASSIST GRIP (D)VERSTÄRKUNG										(F)RENFORCEMENT (S)REFUERZO					
	96307023	.	.	B	.	.	S	S	S	-CF6		2				
	96240749	.	.	B	.	.	O	O	O	&CF6	LH	1				
	96240750	.	.	B	.	.	O	O	O	&CF6	RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A1-SIDE (D)VERKLEIDUNG A1,SEITE,AUßEN									(F)PANNEAU A1-COTE EXTERNE (S)PANEL A1-LADO EXTERNO					
	A96233181	.	.	.	B	S	.	S	-CF6		LH	1				S4
	A96233182	.	.	.	B	S	.	S	-CF6		RH	1				SD
	A96250400	.	.	.	B	O	.	O	&CF6		LH	1				G7
	A96250401	.	.	.	B	O	.	O	&CF6		RH	1				SR
	[03]	(E)PANEL-SIDE OUTER (D)VERKLEIDUNG,SEITE,AUßEN									(F)PANNEAU-COTE EXTERNE (S)PANEL-LADO EXTERNO					
	A96307223	.	.	.	B	S	.	S			LH	1				S4
	A96307224	.	.	.	B	S	.	S			RH	1	970630			SD
N	A96255367	.	.	.	B	S	.	S			RH	1	970630			D4
	[04]	(E)REINF A-CENTER PILLAR (D)VERSTÄRKUNG,ZENTRAL-SÄULE									(F)RENFORCEMENT (S)REFUERZO-PILAR DEL CENTRO					
	96244271	.	.	.	B	S	.	S			LH	1				
	96244272	.	.	.	B	S	.	S			RH	1				
	[05]	(E)PANEL-SIDE INNER (D)VERKLEIDUNG,SEITE,INNEN									(F)PANNEAU-COTE INTERNE (S)PANEL-LADO INTERNO					
	96307239	.	.	.	B	S	.	S			LH	1				
	96307240	.	.	.	B	S	.	S			RH	1				
	[06]	(E)WHEELHOUSE A-INNER (D)VERKLEIDUNG,RAD-GEHÄUSE									(F)PANNEAU-IMONERIE (S)PANEL-VOLANTE INTERNO					
	96307032	.	.	.	B	S	.	S			LH	1				WF
	96307033	.	.	.	B	S	.	S			RH	1				W6
	[07]	(E)PILLAR A-FRONT (D)SÄULE,VORDER-KAROSSERIE									(F)PILIER-CORPS AVANT (S)PILAR-FRENTE DE CUERPO					
	96303787	.	.	.	B	S	.	S			LH	1				LA
	96303788	.	.	.	B	S	.	S			RH	1				L1


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6411 SIDE BODY PANEL(5DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[08]	(E)PATCH-FRONT PILLAR *(D)TEIL,VORDER-SÄULE*								*(F)PIECE-PILIER,AVANT* *(S)PIEZA-FRENTE DE PILAR*						
	96233763	.	.	.	B	S	.	S			LH	1				
	96233764	.	.	.	B	S	.	S			RH	1				
	[09]	(E)PILLAR A-FRONT,INNER *(D)SÄULE,VORDER-KAROSSERIE*								*(F)PILIER-CORPS AVANT* *(S)PILAR-FRENTE DE CUERPO*						
	96307046	.	.	.	B	S	.	S			LH	1				
	96307047	.	.	.	B	S	.	S			RH	1				
	[10]	(E)REINF A-FRONT PILLAR,LWR *(D)VERSTÄRKUNG*								*(F)RENFORCEMENT* *(S)REFUERZO-BISAGRA*						
	96306612	.	.	.	B	S	.	S			LH	1				NA
	96306613	.	.	.	B	S	.	S			RH	1				N1
	[11]	(E)REINFORCEMENT-ROCKER *(D)VERSTÄRKUNG*								*(F)RENFORCEMENT* *(S)REFUERZO*						
	96242967	.	.	.	B	S	.	S			LH	1				
	96242968	.	.	.	B	S	.	S			RH	1				
	[12]	(E)REINF A-STRIKER,REAR DOOR *(D)VERSTÄRKUNG*								*(F)RENFORCEMENT* *(S)REFUERZO*						
	96303715	.	.	.	B	S	.	S			LH	1				RA
	96303716	.	.	.	B	S	.	S			RH	1				R1
	[13]	(E)PIECE-SIDE PANEL OTR CONN *(D)TEIL,VERBINDUNGS*								*(F)PIECE* *(S)PIEZA*						
	96306524	.	.	.	B	S	.	S			LH	1				CB
	96306525	.	.	.	B	S	.	S			RH	1				C2
	[14]	(E)PATCH A-TAIL LAMP HOUSING *(D)TEIL-GEHÄUSE*								*(F)PIECE-LOGEMENT* *(S)PIEZA-CARCASA*						
	96310159	.	.	.	B	S	.	S			LH	1				LB


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96310160	.	.	.	.	B	S	.	S		RH	1				L2
[15]										(E)EXTENSION-SIDE PANEL,OTR *(D)VERLÄNGERUNG,SEITE,AUßEN*					*(F)EXTENSION-COTE,EXTERIEUR* *(S)EXTENSION-LADO EXTERIOR*	
	96306534	.	.	.	.	B	S	.	S		LH	1				EB
	96306535	.	.	.	.	B	S	.	S		RH	1				E2
[16]										(E)SPACER A-SIDE BODY,REAR *(D)DISTANZSTÜCK*					*(F)ENTRETOISE* *(S)ESPACIADOR*	
	96307247	.	.	.	.	B	S	.	S		LH	1				AB
	96307248	.	.	.	.	B	S	.	S		RH	1				A2
[17]										(E)INSERT A-VENTILATION *(D)EINSATZ,VENTILATOR*					*(F)INSERTION-VENTILATION* *(S)REFUERZO-VENTILACION*	
	96242978	.	.	.	.	B	S	.	S			2				
[18]										(E)PANEL-QUATER *(D)VERKLEIDUNG,VIERTEL*					*(F)PANNEAU-QUART* *(S)PANEL-CUADRANTE*	
	A96248552	.	.	.	.	B	S	.	S		LH	1				
	A96248553	.	.	.	.	B	S	.	S		RH	1				
[19]										(E)PANEL-ROOF SIDE *(D)VERKLEIDUNG,SEITE,AUßEN*					*(F)PANNEAU-COTE EXTERNE* *(S)PANEL-LADO EXTERNO,TECHO*	
	A96248550	.	.	.	.	B	S	.	S		LH	1				
	A96248551	.	.	.	.	B	S	.	S		RH	1				
[20]										(E)PANEL-HINHE PILLAR,CTR *(D)VERKLEIDUNG,BESCHLAG,SÄUL*					*(F)PANNEAU* *(S)PANEL-PILAR BISAGAR*	
	A96248554	.	.	.	.	B	S	.	S		LH	1				
	A96248555	.	.	.	.	B	S	.	S		RH	1				
[21]										(E)PANEL-ROCKER *(D)VERKLEIDUNG,SCHWENKUNG*					*(F)PANNEAU-CULBUTEUR* *(S)PANEL-ARCO EXTERNO*	
	A96248556	.	.	.	.	B	S	.	S		LH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6411 SIDE BODY PANEL(5DOOR H/B)



KEY NO.	PART NAME														
I-C	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	A96248557	.	.	.	B	S	.	S			RH	1				
	[22]	(E)PANEL-HINHE PILLAR,FRONT (D)VERKLEIDUNG,BESCHLAG,SÄUL									(F)PANNEAU (S)PANEL-PILAR BISAGRA					
	A96248558	.	.	.	B	S	.	S			LH	1				
	A96248559	.	.	.	B	S	.	S			RH	1				
	[23]	(E)REINF A-LOCK PILLAR (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO					
	96307241	.	.	.	B	S	.	S			LH	1				
	96307242	.	.	.	B	S	.	S			RH	1				
	[24]	(E)REINF A-REAR ASSIST GRIP (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO					
	96307023	.	.	.	B	S	.	S	-CF6			2				
	96240749	.	.	.	B	O	.	O	&CF6		LH	1				
	96240750	.	.	.	B	O	.	O	&CF6		RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A1-SIDE (D)VERKLEIDUNG A1,SEITE,AUßEN									(F)PANNEAU A1-COTE EXTERNE (S)PANEL A1-LADO EXTERNO					
	A96306501	.	.	.	B		S	.	S	-CF6	LH	1				
	A96306502	.	.	.	B		S	.	S	-CF6	RH	1				
	A96251001	.	.	.	B		O	.	O	&CF6	LH	1				
	A96251002	.	.	.	B		O	.	O	&CF6	RH	1				
	[03]	(E)PANEL-SIDE,OUTER (D)VERKLEIDUNG,SEITE,AUßEN									(F)PANNEAU-COTE EXTERNE (S)PANEL-LADO EXTERNO					
	A96251006	.	.	.	B	.	S	.	S		LH	1				
	A96251007	.	.	.	B	.	S	.	S		RH	1		970616		
N	A96255363	.	.	.	B	.	S	.	S		RH	1	970616			
	[04]	(E)REINF A-CENTER PILLAR (D)VERSTÄRKUNG,ZENTRAL-SÄULE									(F)RENFORCEMENT (S)REFUERZO-PILAR DEL CENTRO					
	96303686	.	.	.	B	.	S	.	S		LH	1				PA
	96303687	.	.	.	B	.	S	.	S		RH	1				P1
	[05]	(E)PANEL A-SIDE INNER (D)VERKLEIDUNG,SEITE,INNEN									(F)PANNEAU-COTE INTERNE (S)PANEL-LADO INTERNO					
	96306558	.	.	.	B	.	S	.	S		LH	1				
	96306559	.	.	.	B	.	S	.	S		RH	1				
	[06]	(E)WHEELHOUSE A-INNER (D)VERKLEIDUNG,RAD-GEHÄUSE									(F)PANNEAU-IMONERIE (S)PANEL-VOLANTE INTERNO					
	96307032	.	.	.	B	.	S	.	S		LH	1				WF
	96307033	.	.	.	B	.	S	.	S		RH	1				W6
	[07]	(E)PILLAR A-FRONT (D)SÄULE,VORDER-KAROSSERIE									(F)PILIER-CORPS AVANT (S)PILAR-FRENTE DE CUERPO					
	96303787	.	.	.	B	.	S	.	S		LH	1				LA
	96303788	.	.	.	B	.	S	.	S		RH	1				L1

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6412 SIDE BODY PANEL(3DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[08]		(E)PATCH-FRONT PILLAR (D)TEIL,VORDER-SÄULE									(F)PIECE-PILIER,AVANT (S)PIEZA-FRENTE DE PILAR					
	96233763	.	.	.	B	.	S	.	S		LH	1				
	96233764	.	.	.	B	.	S	.	S		RH	1				
[09]		(E)PILLAR A-FRONT,INNER (D)SÄULE,VORDER-KAROSSERIE									(F)PILIER-CORPS AVANT (S)PILAR-FRENTE DE CUERPO					
	96307046	.	.	.	B	.	S	.	S		LH	1				
	96307047	.	.	.	B	.	S	.	S		RH	1				
[10]		(E)REINF A-FRONT PILLAR,LWR (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO-BISAGRA					
	96306612	.	.	.	B	.	S	.	S		LH	1				NA
	96306613	.	.	.	B	.	S	.	S		RH	1				N1
[11]		(E)REINFORCEMENT-ROCKER (D)VERSTÄRKUNG									(F)RENFORCEMENT (S)REFUERZO					
	96242806	.	.	.	B	.	S	.	S		LH	1				
	96242807	.	.	.	B	.	S	.	S		RH	1				
[13]		(E)PIECE-SIDE PANEL OTR CONN (D)TEIL,VERBINDUNGS									(F)PIECE (S)PIEZA					
	96306524	.	.	.	B	.	S	.	S		LH	1				CB
	96306525	.	.	.	B	.	S	.	S		RH	1				C2
[14]		(E)PATCH A-TAIL LAMP HOUSING (D)TEIL-GEHÄUSE									(F)PIECE-LOGEMENT (S)PIEZA-CARCASA					
	96310159	.	.	.	B	.	S	.	S		LH	1				LB
	96310160	.	.	.	B	.	S	.	S		RH	1				L2
[15]		(E)EXTENSION-SIDE PANEL,OTR (D)VERLÄNGERUNG,SEITE,AUßEN									(F)EXTENSION-COTE,EXTERIEUR (S)EXTENSION-LADO EXTERIOR					
	96306534	.	.	.	B	.	S	.	S		LH	1				EB


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6412 SIDE BODY PANEL(3DOOR H/B)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96306535	.	.	B	.	S	.	S			RH	1				E2
[16]	(E)SPACER A-SIDE BODY,REAR (D)DISTANZSTÜCK										(F)ENTRETOISE (S)ESPACIADOR					
	96307247	.	.	B	.	S	.	S			LH	1				AB
	96307248	.	.	B	.	S	.	S			RH	1				A2
[17]	(E)INSERT A-VENTILATION (D)EINSATZ,VENTILATOR										(F)INSERTION-VENTILATION (S)REFUERZO-VENTILACION					
	96242978	.	.	B	.	S	.	S				2				
[18]	(E)PANEL- QUATER (D)VERKLEIDUNG,VIERTEL										(F)PANNEAU-QUART (S)PANEL-CUADRANTE					
	A96248544	.	.	B		S	.	S			LH	1				
	A96248545	.	.	B		S	.	S			RH	1				
[19]	(E)PANEL-ROOF SIDE (D)VERKLEIDUNG,SEITE,AUßEN										(F)PANNEAU-COTE EXTERNE (S)PANEL-LADO EXTERNO,TECHO					
	A96248542	.	.	B		S	.	S			LH	1				
	A96248543	.	.	B		S	.	S			RH	1				
[20]	(E)PANEL-ROCKER (D)VERKLEIDUNG,SCHWENKUNG										(F)PANNEAU-CULBUTEUR (S)PANEL-ARCO EXTERNO					
	A96248546	.	.	B		S	.	S			LH	1				
	A96248547	.	.	B		S	.	S			RH	1				
[21]	(E)PANEL-HINHE PILLAR,FRONT (D)VERKLEIDUNG,BESCHLAG,SÄUL										(F)PANNEAU (S)PANEL-PILAR BISAGRA					
	A96248548	.	.	B		S	.	S			LH	1				
	A96248549	.	.	B		S	.	S			RH	1				
[22]	(E)REINF A-LOCK PILLAR (D)VERSTÄRKUNG										(F)RENFORCEMENT (S)REFUERZO					
	96303749	.	.	B	.	S	.	S			LH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96303750	.	.	.	B	.	S	.	S		RH	1				
[23]	(E)REINF A-SUNROOF BRACKET *(D)VERSTÄRKUNG*										*(F)RENFORCEMENT* *(S)REFUERZO*					
	96240740	.	.	.	B	.	O	.	O	&CF6	LH	1				
	96240741	.	.	.	B	.	O	.	O	&CF6	RH	1				
[24]	(E)REINFORCEMENT A-COAT HOOK *(D)VERSTÄRKUNG*										*(F)RENFORCEMENT* *(S)REFUERZO*					
	96307022	.	.	.	B	.	S	.	S	-CF6	LH	1				
	96310175	.	.	.	B	.	S	.	S	-CF6	RH	1				
[25]	(E)RAIL-SIDE PANEL, INNER *(D)SCHIENE,SEITE,INNEN*										*(F)RAIL-COTE INTERNE* *(S)RIEL-LADO INTERNO*					
	96307123	.	.	.	B	.	S	.	S		LH	1				
	96307124	.	.	.	B	.	S	.	S		RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.		PART NAME												
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX						
												FROM	TO		
	[01]	(E)CAP-FUEL FILLER (D)DECKEL,BENZINTANK								(F)CHAPEAU (S)TAPA-TOMA DE GASOLINA					
	96306516	.	.	B	B	B	S	S	S		1				FB
	[02]	(E)DOOR A-FUEL FILLER (D)TÜR,BENZINTANK								(F)PORTE-REMPLISSAGE (S)PUERTA-ECHAR COMBUSTIBLE					
	96303245	.	.	B	.	.	S	S	S		1			INCL. #3	
	96303238	.	.	.	B	.	S	.	S		1			INCL. #3	
	96307261	.	.	.	.	B	S	.	S		1			INCL. #3	
	[03]	(E)BUMPER-FUEL FILLER DOOR (D)STOßSTANGE								(F)PARE-CHOC (S)PARACHOQUES					
	96246535	.	.	B	B	B	S	S	S		2				
	[04]	(E)SCREW-TAPPING (D)SCHRAUBE								(F)VIS (S)TORNILLO					
	03160-42132	.	.	B	B	B	S	S	S		3				
	[05]	(E)LOCK A-FUEL FILLER DOOR (D)SCHLOß								(F)VERROU (S)CERRADURA					
	96248525	.	.	B	B	B	S	S	S		1		970616		
N	96250424	.	.	B	B	B	S	S	S		1	970616			
	[06]	(E)CAP-FUEL SCREW (D)SCHRAUBEDECKEL,BENZINTANK								(F)CHAPEAU (S)TAPA-TORNILLO					
	22591475	.	.	B	B	B	S	S	S		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
										(E)RAIL-WINDSHIELD HEADER (D)SCHIENE						
	[02]															
	96303820	.	.	B	B	B	S	S	S			1				
										(E)SUPPORT A-ROOF,CENTER (D)TRÄGER,DACH						
	[03]															
	96307051	.	.	B	B	B	S	S	S	-CF6		1				
										(E)FRAME-ROOF,REAR (D)RAHMEN,HINTERES DACH						
	[04]															
	96303823	.	.	B	.	.	S	S	S			1				
	96303824	.	.	.	B	B	S	.	S			1				
										(E)MOLDING A-ROOF (D)PREßTEIL,DACH						
	[05]															
	96303484	.	.	B	.	.	S	S	S		LH	1				
	96306107	.	.	B	.	.	S	S	S		RH	1				
	96306233	.	.	.	B	B	S	.	S		LH	1				
	96306234	.	.	.	B	B	S	.	S		RH	1				
										(E)CLIP-ROOF MOLDING (D)KLEMME						
	[06]															
	96233387	.	.	B	B	B	S	S	S			8				
										(E)PANEL A-ROOF (D)VERKLEIDUNG,DACH						
	[07]															
	A96303816	.	.	B	.	.	S	S	S	-CF6		1			INCL.#2~4	
	96232378	.	.	B	.	.	O	O	O	&CF6		1			INCL.#2,4,8	
	A96303817	.	.	.	B	.	S	.	S	-CF6		1			INCL.#2~4	
	96232379	.	.	.	B	.	O	.	O	&CF6		1			INCL.#2,4,8	
	A96230852	.	.	.	.	B	S	.	S	-CF6		1			INCL.#2~4	
	96232380	.	.	.	.	B	O	.	O	&CF6		1			INCL.#2,4,8	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[08]	(E)FRAME A-SUN ROOF *(D)RAHMEN*									*(F)CADRE* *(S)ARMADURA*					
	96240722	. .	B	.	B	O	O	O	&CF6		1					
	96240723	. .	.	B	.	O	.	O	&CF6		1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6440 TRUNK LID PANEL

5K11




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)PANEL A-TRUNK LID (D)VERKLEIDUNG,KOFFERRAUM									(F)PANNEAU-CAPOT DE COFFRE (S)TAPA DEL PORTAEQUIPAJE					
[01]																
A96228756		. .	B	. .			S	S	S	&XCK-XBR		1				LB
A96303333		. .	B	. .			.	.	A	&XCK&XBR		1				LA
A96228757		. .	B	. .			A	A	A	&XCP		1				LD
		(E)BUMPER-TRUNK LID LOWER (D)STOßSCHEIBE									(F)PARE-CHOC (S)TOPE-TAPA DE PORTAEQUIPAJ					
[02]																
96240768		. .	B	. .			S	S	S			2				
		(E)BUMPER (D)STOßSTANGE									(F)PARE-CHOC (S)PARACHOQUES					
[03]																
96169594		. .	B	. .			S	S	S			2				
		(E)WEATHERSTRIP A-TRUNK LID (D)DICHTUNGSLEISTE									(F)ISOLATION EN BANDELETTE (S)BURLETE					
[04]																
96303249		. .	B	. .			S	S	S			1	970901			
N 96250354		. .	B	. .			S	S	S			1	970901			
		(E)HINGE A-TRUNK LID (D)BESCHLAG,KOFFERRAUM									(F)CHARNIERE-CAPOT DE COFFRE (S)BISAGRA					
[05]																
96303325		. .	B	. .			S	S	S		LH	1				GA
96306119		. .	B	. .			S	S	S		RH	1				G1
		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
[06]																
09118-06004		. .	B	. .			S	S	S			4			W/WASHER	
		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
[07]																
09118-06003		. .	B	. .			S	S	S			6			W/WASHER	
		(E)BUMPER-TRUNK LID HINGE AR (D)STOßSCHEIBE									(F)PARE-CHOC-CAPOT DE COFFRE (S)TOPE					
[08]																
96185310		. .	B	. .			S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[09]		(E)PANEL A-BACK,UPPER *(D)VERKLEIDUNG,HINTEN,OBEN*									*(F)PANNEAU-ARRIERE HAUT* *(S)PANEL-RESPALDO SUPERIOR*					
96226339		.	.	B	.	.	S	S	.	&AM6		1				BB
96303806		.	.	B	.	.	.	.	S	&AM9		1				BD
96303806		.	.	B	.	.	A	A	A	&AMB		1				BD
[10]		(E)BAR-TRUNK LID TORSION *(D)STANGE*									*(F)BARRE* *(S)BARRA*					
96304597		.	.	B	.	.	S	S	S		LH	1				
96304598		.	.	B	.	.	S	S	S		RH	1				
[11]		(E)HOSE-SPRING *(D)SCHLAUCH*									*(F)TUYAU* *(S)MANGUERA*					
94825352		.	.	B	.	.	S	S	S			1				
[12]		(E)HANDLE A-TRUNK LID *(D)HENKEL*									*(F)POIGNEE* *(S)MANIJA*					
96303267		.	.	B	.	.	S	S	S			1				
[13]		(E)NUT-HEXAGON FLANGE *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
08316-25053		.	.	B	.	.	S	S	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A-TAILGATE *(D)VERKLEIDUNG,HINTERTEIL*									*(F)PANNEAU-HAYON* *(S)PANEL-COMPUERTA DE COLA*					
	A96224442	.	.	.	B	B	S	.	S	&XCK-XBR		1				TB
	A96303345	.	.	.	B	B	.	.	A	&XCK&XBR		1				TA
	A96224443	.	.	.	B	B	A	.	A	&XCP		1				TD
	[02]	(E)BUMPER *(D)STOßSTANGE*									*(F)PARE-CHOC* *(S)PARACHOQUES*					
	96307168	.	.	.	B	B	S	.	S			2				
	[03]	(E)BUMPER *(D)STOßSTANGE*									*(F)PARE-CHOC* *(S)PARACHOQUES*					
	96169594	.	.	.	B	B	S	.	S			2				
	[04]	(E)WEATHERSTRIP A-TAIL GATE *(D)DICHTUNGSLEISTE*									*(F)ISOLATION EN BANDELETTE* *(S)BURLETE*					
	96250362	.	.	.	B	B	S	.	S			1				
	[05]	(E)HINGE A-TAILGATE *(D)BESCHLAG*									*(F)CHARNIERE* *(S)BISAGRA*					
	96306236	.	.	.	B	B	S	.	S		LH	1				GA
	96232686	.	.	.	B	B	S	.	S		RH	1				G1
	[06]	(E)NUT-HEXAGON FLANGE *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
	08316-28083	.	.	.	B	B	S	.	S			4				
	[07]	(E)BOLT-GP HEXAGON FLANGE *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
	01800-08163	.	.	.	B	B	S	.	S			4				
	[08]	(E)BUMPER-T/GATE SLIDING,LWR *(D)STOßSTANGE*									*(F)PARE-CHOC* *(S)PARACHOQUES*					
	96307169	.	.	.	B	B	S	.	S		LH	1				
	96224445	.	.	.	B	B	S	.	S		RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME															
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
[10]	(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*															
	01517-06165	.	.	.	B	B	S	.	S			8				
[12]	(E)HANDLE A-TAILGATE *(D)HENKEL* *(F)POIGNEE* *(S)MANIJA*															
	96234770	.	.	.	B	B	S	.	S			1				
[13]	(E)NUT-HEXAGON FLANGE *(D)MUTTER* *(F)ECROU* *(S)TUERCA*															
	08316-25053	.	.	.	B	B	S	.	S			4				
[14]	(E)JOINT A-BALL *(D)GLIED,KUGEL* *(F)JOINT-BOULE* *(S)UNION-BOLA*															
	96228420	.	.	.	B	B	S	.	S			4				
[15]	(E)SPRING-TAILGATE GAS *(D)FEDERUNG* *(F)RESSORT* *(S)RESORTE*															
	96306157	.	.	.	B	B	S	.	S			2				H5
[16]	(E)FASTENER *(D)BEFESTIGUNG* *(F)ATTACHE* *(S)GRAPA*															
	96303215	.	.	.	B	B	S	.	S			2	970615			
[17]	(E)COVER-TAILGATE GLASS *(D)DECKEL* *(F)CARTER* *(S)CUBIERTA*															
	96237573	.	.	.	B	B	S	.	S			1				
[18]	(E)TRIM A-TAILGATE *(D)VERKLEIDUNG,HINTERTEIL* *(F)GARNITURE-HAYON* *(S)ADORNO-COMPUERTA DE COLA*															
	96236114	.	.	.	B	B	S	.	S			1				
[19]	(E)COVER A-TAILGATE,UPR *(D)DECKEL* *(F)CARTER* *(S)CUBIERTA*															
	96236116	.	.	.	B	B	S	.	S			1				
[20]	(E)CLIP *(D)KLEMME* *(F)ATTACHE* *(S)GRAPA*															

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	09409-07326	.	.	.	B	B	S	.	S			7				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO	
[01]	(E)LATCH A-TRUNK LID (D)VERSCHLUß,KOFFERRAUM														
96214300		.	.	B	.	.	S	S	S			1			
[02]	(E)BOLT (D)SCHRAUBE														
09119-06023		.	.	B	.	.	S	S	S			2			
[03]	(E)ROD-LATCH PULLING (D)STAB,SCHOß-ÖFFNUNG														
96304759		.	.	B	.	.	S	S	S			1			
[04]	(E)CLAMP (D)KLAMMER														
09403-03302		.	.	B	.	.	S	S	S			1			
[06]	(E)STRIKER A-LATCH (D)SCHLÄGER														
96303364		.	.	B	.	.	S	S	S			1			
[07]	(E)BOLT (D)SCHRAUBE														
09118-06003		.	.	B	.	.	S	S	S			2		W/WASHER	
[08]	(E)LEVER A-T/LID & F/FILLER (D)HEBEL														
96220202		.	.	B	.	.	S	S	S			1		INCL #10,11	H1
[09]	(E)BOLT (D)SCHRAUBE														
09118-06003		.	.	B	.	.	S	S	S			1		W/WASHER	
[10]	(E)CABLE A-TRUNK LID (D)KABEL														
96216134		.	.	B	.	.	S	S	S			1			
[11]	(E)CABLE A-FUEL FILLER DOOR (D)KABEL														

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96216135	.	.	B	.	.	S	S	S			1				
	[12]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE (S)GRAPA*				
	09408-00018	.	.	B	.	.	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



ITC	KEY NO. PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]									(E)LATCH A-TAILGATE (D)VERSCHLUß,HINTERTEIL						
	96232493	.	.	.	B	B	S	.	S			1				
	[02]									(E)SCREW-MACHINE (D)SCHRAUBE						
	09137-06001	.	.	.	B	B	S	.	S			3				
	[03]									(E)ROD-LATCH PULLING (D)STAB,SCHOß-ÖFFNUNG						
	96234313	.	.	.	B	B	S	.	S			1				
	[04]									(E)CLAMP (D)KLAMMER						
	09403-04301	.	.	.	B	B	S	.	S			1				
	[06]									(E)STRIKER A-TAILGATE (D)SCHLÄGER						
	96232494	.	.	.	B	B	S	.	S			1				
	[07]									(E)BOLT (D)SCHRAUBE						
.	09119-08026	.	.	.	B	B	S	.	S			2				
	[08]									(E)LEVER A-FUEL FILLER DOOR (D)HEBEL						
	96310090	.	.	.	B	B	S	.	S			1			INCL #11	H3
	[09]									(E)BOLT (D)SCHRAUBE						
	09118-06003	.	.	.	B	B	S	.	S			1			W/WASHER	
	[10]									(E)ROD-KEY CYLINDER (D)STAB						
	96234309	.	.	.	B	B	S	.	S			1				
	[11]									(E)CABLE A-FUEL FILLER DOOR (D)KABEL						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


5F12



ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96232709	.	.	.	B	B	S	.	S			1				
	[12]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	09408-00018	.	.	.	B	B	S	.	S			1				
	[13]	(E)ACTUATOR A-TAILGATE *(D)BETÄTIGUNG*										*(F)ACTIONNEUR* *(S)ACTUADOR*				
	96237555	.	.	.	B	B	O	.	S	&AU3		1				KH
	[14]	(E)ROD-TAILGATE ACTUATOR *(D)STAB*										*(F)TRINGLE* *(S)VARILLA*				
	96234312	.	.	.	B	B	O	.	S	&AU3		1				
	[15]	(E)CLAMP *(D)KLAMMER*										*(F)PINCE* *(S)ABRAZADERA*				
	09403-03302	.	.	.	B	B	O	.	S	&AU3		1				
	[16]	(E)BUSHING *(D)LAGERFUTTER*										*(F)MANCHON* *(S)BUJE DE BOQUILLA*				
	09320-07001	.	.	.	B	B	O	.	S	&AU3		2				
	[17]	(E)BUSHING *(D)LAGERFUTTER*										*(F)MANCHON* *(S)BUJE DE BOQUILLA*				
	09306-04001	.	.	.	B	B	O	.	S	&AU3		2				
	[18]	(E)NUT *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	09159-04004	.	.	.	B	B	O	.	S	&AU3		2				
	[20]	(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
	09408-00077	.	.	.	B	B	S	.	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


5G12



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)LOCK SET-CAR *(D)SCHLOß-SATZ,AUTOMOBIL*									*(F)JEU VERROU-VOITURE* *(S)JUEGO DE CERRADURA-CABINA*					
	96213542	.	.	B	.	.	S	S	S	-UM1		1				T2
	96304764	.	.	B	.	.	A	A	A	&UM1		1				T1
	96236253	.	.	.	B	B	S	.	S	-UM1		1				T3
	96236254	.	.	.	B	B	A	.	A	&UM1		1				T4
	[02]	(E)LOCK SET-STEERING *(D)SCHLOß-SATZ,LENKUNG*									*(F)JEU VERROU-DIRECTION* *(S)JUEGO DE CERRADURA*					
	S6460020	.	.	B	B	B	S	S	S	-UM1		1				
	S6460037	.	.	B	B	B	A	A	A	&UM1		1				
	[03]	(E)LOCK SET-DOOR *(D)SCHLOß-SATZ,TÜR*									*(F)JEU VERROU-PORTE* *(S)JUEGO DE CERRADURA-PUERTA*					
	S6460021	.	.	B	B	B	S	S	S		LH	1				
	S6460022	.	.	B	B	B	S	S	S		RH	1				
	[04]	(E)LOCK SET-TRUNK *(D)SCHLOß-SATZ,KOFFERRAUM*									*(F)JEU VERROU-COFFRE* *(S)JUEGO DE CERRADURA*					
	S6460023	.	.	B	.	.	S	S	S			1			TRUNK LID	
	S6460043	.	.	.	B	B	S	.	S			1			TAILGATE	
	[05]	(E)KEY-BLANK *(D)SCHLÜßEL,UNBEARBEITET*									*(F)CLE-BLANC* *(S)LLAVE-EN BLANCO*					
	S6460019	.	.	B	B	B	S	S	S	-UM1		1				
	S6460042	.	.	B	B	B	A	A	A	&UM1		1				
	[06]	(E)CAP *(D)DECKEL*									*(F)CHAPEAU* *(S)TAPA*					
	96225803	.	.	B	B	B	S	S	S	-UM1		1				
	96303503	.	.	B	B	B	A	A	A	&UM1		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6510 FRONT FLOOR PANEL



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)PANEL A-FLOOR,FRONT *(D)VERKLEIDUNG,BODEN,VORNE*									*(F)PANNEAU-PLANCHER,AVANT* *(S)PANEL-PISO,FRENTE*					
	A96306304	.	.	B	B	B	S	S	S			1				FD
[02]		(E)CROSSMEMBER A-FRONT SEAT *(D)QUERTRÄGER,VORDERSITZ*									*(F)BARRE DE TRAVERSE* *(S)TRANSVERSAL-ASIENTO*					
	96303380	.	.	B	B	B	S	S	S		LH	1				CA
	96306121	.	.	B	B	B	S	S	S		RH	1				CB
[03]		(E)SUPPORT A-FRONT SEAT,OTR *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
	96303382	.	.	B	B	B	S	S	S		LH	1		970624		SA
O	96251599	.	.	B	B	B	S	S	S		LH	1	970624			SA
	96306123	.	.	B	B	B	S	S	S		RH	1		970624		S1
O	96251600	.	.	B	B	B	S	S	S		RH	1	970624			S1
[04]		(E)SUPPORT A-FRONT SEAT,INR *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
	96303383	.	.	B	B	B	S	S	S		LH	1				NA
	96306124	.	.	B	B	B	S	S	S		RH	1				N1
[05]		(E)BRACKET A-ECM *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
	96215606	.	.	B	B	B	S	S	S			1				
[06]		(E)BRACKET A-CONNECTING PIEC *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
	96303384	.	.	B	B	B	S	S	S			1				
[07]		(E)BRACKET-CONSOLE *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
	96215387	.	.	B	B	B	S	S	S			1				
[08]		(E)REINFORCEMENT A-TUNNEL *(D)VERSTÄRKUNG*									*(F)RENFORCEMENT-TUNNEL AVANT* *(S)REFUERZO-TUNEL DEL FRENTE*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6510 FRONT FLOOR PANEL



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96250466	.	.	B	B	B	S	S	S			1				
[09]	(E)SIDE MEMBER A-FLOOR *(D)RAHMEN,SEITE*											*(F)CADRE-COTE* *(S)ARMADURA-LADO*				
	96306348	.	.	B	B	B	S	S	S		LH	1				BB
	96306314	.	.	B	B	B	S	S	S		RH	1				B2
[10]	(E)CROSSMEMBER-FRT FLOOR,LWR *(D)QUERTRÄGER*											*(F)BARRE DE TRAVERSE* *(S)TRANSVERSAL*				
	96227504	.	.	B	B	B	S	S	S			2				LB
[11]	(E)PANEL A-FLOOR SIDE *(D)VERKLEIDUNG,BODEN,SEITE*											*(F)PANNEAU-PLANCHER,COTE* *(S)PANEL-PISO,LADO*				
	96306318	.	.	B	.	B	S	S	S		LH	1				SD
	96306320	.	.	B	.	B	S	S	S		RH	1				S4
	96306317	.	.	.	B	.	S	.	S		LH	1				SB
	96306319	.	.	.	B	.	S	.	S		RH	1				S2
[12]	(E)BRACKET A-FIRE EXTINGUISHER *(D)TRÄGER*											*(F)SUPPORT* *(S)SOPORTE*				
	96248577	.	.	B	B	B	A	A	A			1			FOR LEBANON,LIBYA	
	96248583	.	.	B	B	B	A	A	A			1			FOR BRAZIL,POLAND	
[13]	(E)SCREW-TAPPING *(D)SCHRAUBE*											*(F)VIS* *(S)TORNILLO*				
	09132-04004	.	.	B	B	B	A	A	A			2		971001	FOR LEBANON,LIBYA	
O	09132-04013	.	.	B	B	B	A	A	A			2	971001		FOR LEBANON,LIBYA	
	09132-04004	.	.	B	B	B	A	A	A			2		971001	FOR BRAZIL,POLAND	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6510 FRONT FLOOR PANEL



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
O	09132-04013	.	.	B	B	B	A	A	A			2	971001		FOR BRAZIL,POLAND	
	[14]	(E)PANEL A-FLOOR,FRONT *(D)VERKLEIDUNG,BODEN,VORNE* *(F)PANNEAU-PLANCHER,AVANT* *(S)PANEL-PISO,FRENTE*														
	A96306303	.	.	B	B		S	S	S			1				FB


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)PANEL A-FLOOR,REAR *(D)VERKLEIDUNG,BODEN,HINTEN*													*(F)PANNEAU-PLANCHER* *(S)PANEL-PISO,ATRAS*	
	A96306407	.	.	B	.	.	S	S	S			1				
	A96306408	.	.	.	B	B	S	.	S			1				
	[02]	(E)EXTENSION-FLOOR PANEL,RR *(D)VERLÄNGERUNG*													*(F)RALLONGE* *(S)EXTENSION-PANEL DEL PISO*	
	A96306409	.	.	B	.	.	S	S	S			1				EB
	[03]	(E)BRACKET A-RR SEAT BACK,CT *(D)TRÄGER*													*(F)SUPPORT* *(S)SOPORTE*	
	96250617	.	.	B	B	B	S	.	S	&AM9		1				
	96250617	.	.	B	B	B	A	A	A	&AMB		1				
	[04]	(E)BRACKET A-JACK NO.1 *(D)TRÄGER*													*(F)SUPPORT* *(S)SOPORTE*	
	96216610	.	.	B	.	.	S	S	S			1				
	[05]	(E)STAND A-SPARE WHEEL *(D)STÄNDER,ERSATZRAD*													*(F)SUPPORT-ROUE DE SECOURS* *(S)PIE-RUEDA DE REPUESTO*	
	96303404	.	.	B	B	B	S	S	S			1				
	[06]	(E)REINFORCEMENT A-RR BUMPER *(D)VERSTÄRKUNG*													*(F)RENFORCEMENT* *(S)REFUERZO*	
	96303405	.	.	B	B	B	S	S	S			2				
	[07]	(E)PANEL A-BACK,LOWER *(D)VERKLEIDUNG,HINTEN,UNTEN*													*(F)PANNEAU-ARRIERE BAS* *(S)PANEL-RESPALDO BAJA*	
	96306372	.	.	B	.	.	S	S	S			1				BD
	96306370	.	.	.	B	B	S	.	S			1				BB
	[08]	(E)BRACKET-JACK,NO.2 *(D)TRÄGER*													*(F)SUPPORT* *(S)SOPORTE*	
	96216613	.	.	B	.	.	S	S	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)CAP-FUEL TANK SERVICE (D)DECKEL										(F)CHAPEAU (S)TAPA				
[09]	96221241	.	.	B	B	B	S	S	S			1				
		(E)PLUG (D)STÖPSEL										(F)BOUCHON (S)TAPON				
[10]	09241-40001	.	.	B	B	B	S	S	S			12				
		(E)PLUG (D)STÖPSEL										(F)BOUCHON (S)TAPON				
[11]	09241-21001	.	.	B	B	B	S	S	S			9				
		(E)PLUG (D)STÖPSEL										(F)BOUCHON (S)TAPON				
[12]	09241-30003	.	.	B	B	B	S	S	S			6				
		(E)PLUG (D)STÖPSEL										(F)BOUCHON (S)TAPON				
[13]	09241-40002	.	.	B	B	B	S	S	S			1				
		(E)BRACKET-JACK,LOWER (D)TRÄGER										(F)SUPPORT (S)SOPORTE				
[14]	96225158	.	.	.	B	B	S	.	S			1				
		(E)PANEL A1-FLOOR,REAR (D)VERKLEIDUNG,BODEN,HINTEN										(F)PANNEAU-PLANCHER (S)PANEL-PISO,ATRAS				
[15]	A96306389	.	.	B	.		S	S	.	&AM6		1				
	A96304541	.	.	B	.		.	.	S	&AM9		1				
	A96304541	.	.	B	.		A	A	A	&AMB		1				
	A96306394	.	.	.	B	B	S	.	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)FRAMEWORK A-FRONT (D)AUSSTATTUNG GESTELL									(F)TRAVAIL-CADRE AVANT (S)TRABAJO-ARMADURA					
	A96306256	M	B	B	B	S	S	S				1				MD
	A96306255	A	B	B	B	O	O	O				1				MB
	[02]	(E)CROSSMEMBER A-RADIATOR (D)QUERTRÄGER,KÜHLER									(F)BARRE DE TRAVERSE (S)TRANSVERSAL-RADIADOR					
	96306685	.	.	B	B	B	S	S	S			1	970407			CB
N	96251570	.	.	B	B	B	S	S	S			1	970407			U2
	[03]	(E)LONGITUDINAL A-FRONT (D)LÄNGENTEIL,VORNE									(F)LONGITUDINAL-AVANT (S)LONGITUDINAL-FRENTE					
	96248574	.	M	B	B	B	S	S	S			LH 1				M4
	96248576	.	A	B	B	B	O	O	O			LH 1				M2
	[04]	(E)LONGITUDINAL A-FRONT (D)LÄNGENTEIL,VORNE									(F)LONGITUDINAL-AVANT (S)LONGITUDINAL-FRENTE					
	96306280	.	.	B	B	B	S	S	S			RH 1				L2
	[05]	(E)CROSSMEMBER A-FLR PNL,FRT (D)QUERTRÄGER									(F)BARRE DE TRAVERSE (S)TRANSVERSAL					
	96303374	.	.	B	B	B	S	S	S			1				PB
	[07]	(E)LONGITUDINAL A-REAR (D)LÄNGENTEIL,HINTEN									(F)LONGITUDINAL-ARRIERE (S)LONGITUDINAL-TRASERO					
	96250474	.	.	B	.	.	S	S	S			LH 1				H4
	96250476	.	.	.	B	B	S	.	S			LH 1				H2
	[08]	(E)LONGITUDINAL A-REAR (D)LÄNGENTEIL,HINTEN									(F)LONGITUDINAL-ARRIERE (S)LONGITUDINAL-TRASERO					
	96306437	.	.	B	.	.	S	S	S			RH 1				L4
	96306438	.	.	.	B	B	S	.	S			RH 1				L2
	[09]	(E)C/MBR A-RR FLOOR,PNL,FRT (D)QUERTRÄGER									(F)BARRE DE TRAVERSE (S)TRANSVERSAL					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC.	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96306466	.	.	B	B	B	S	S	S			1				RB
[10]	(E)C/MBR A-RR FLOOR PNL,CTR *(D)QUERTRÄGER*														*(F)BARRE DE TRAVERSE* *(S)TRANSVERSAL*	
	96306472	.	.	B	B	B	S	S	S			1				RB


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)MIRROR A-OUTSIDE (D)SPIEGEL,AUßEN									(F)RETROVISEUR-EXTERIEUR (S)ESPEJO-EXTERNO					
	96304167	.	.	B	B	B	S	S	S	&D33	LH	1				CA
	96227724	.	.	B	B	B	S	S	S	&D39	RH	1				CE
	96227725	.	.	B	B	B	.	.	O	&DD4	RH	1				EE
	[02]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09138-06027	.	.	B	B	B	S	S	S			6				
	[03]	(E)GLASS-MIRROR (D)GLAS									(F)GLACE (S)VIDRIO					
	S6630006	.	.	B	B	B	S	S	S		LH	1				
	S6630007	.	.	B	B	B	S	S	S		RH	1				
	[04]	(E)BOOT-KNOB (D)KOFFERRAUM									(F)GAINE (S)CAPUCHON					
	31121708	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[01]																	(E)GLASS A-WINDSHIELD *(D)GLAS,WINDSCHUTZSCHEIBE*
	96303213	.	.	B	.	.	S	.	.	&A22		1	970526				
O	96256902	.	.	B	.	.	S	.	.	&A22		1	970526				
	96306108	.	.	B	.	.	O	S	S	&A01		1					
[03]																	(E)PLATE-CARRIER *(D)PLATTE*
	90126071	.	.	B	.	.	S	S	S			1					
[04]																	(E)MOLDING-WINDSHIELD *(D)PREßTEIL,WINDSCHUTZSCHEIB*
	96240757	.	.	B	.	.	S	S	S			1					
[05]																	(E)GLASS A-BACK WINDOW *(D)GLAS*
	96306110	.	.	B	.	.	S	.	.	&A22		1					
	96306112	.	.	B	.	.	O	S	S	&A01		1					
[06]																	(E)STOPPER-GLASS,UPPER *(D)STÖPSEL*
	96216138	.	.	B	.	.	S	S	S			2					
[07]																	(E)MOLDING-BACK WINDOW *(D)PREßTEIL,FENSTERSCHEIBE*
	96240758	.	.	B	.	.	S	S	S			1					
[08]																	(E)GLASS-FRT DOOR WINDOW *(D)GLAS*
	96304048	.	.	B	.	.	S	.	.	&A22		LH 1					
	96304050	.	.	B	.	.	S	.	.	&A22		RH 1					
	96304052	.	.	B	.	.	O	S	S	&A01		LH 1					
	96304054	.	.	B	.	.	O	S	S	&A01		RH 1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
		PART NAME														
[09]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-06002	.	.	B	.	.	S	S	S			4				
[10]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03140-63163	.	.	B	.	.	S	S	S			4				
[11]		(E)GLASS-RR DOOR WINDOW (D)GLAS									(F)GLACE-FENETRE ARRIERE (S)VIDRIO-VENTANA TRASERA					
	96304138	.	.	B	.	.	S	.	.	&A22	LH	1				
	96304140	.	.	B	.	.	S	.	.	&A22	RH	1				
	96304142	.	.	B	.	.	O	S	S	&A01	LH	1				
	96304144	.	.	B	.	.	O	S	S	&A01	RH	1				
[12]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-06002	.	.	B	.	.	S	S	S			4				
[13]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03140-63163	.	.	B	.	.	S	S	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	[01]	(E)GLASS A-WINDSHIELD (D)GLAS,WINDSCHUTZSCHEIBE									(F)GLACE-PARE-BRISE (S)VIDRIO-PARABRISAS					
	96303213	.	.	.	B	B	S	.	.	&A22		1	970526			
O	96256902	.	.	.	B	B	S	.	.	&A22		1	970526			
	96306108	.	.	.	B	B	O	.	S	&A01		1				
	[03]	(E)PLATE-CARRIER (D)PLATTE									(F)PLAQUE (S)PLACA					
	90126071	.	.	.	B	B	S	.	S			1				
	[04]	(E)MOLDING-WINDSHIELD (D)PREßTEIL,WINDSCHUTZSCHEIB									(F)MOULURE-PARE-BRISE (S)MOLOURA-PARABRISAS					
	96240757	.	.	.	B	B	S	.	S			1				
	[05]	(E)GLASS A-TAILGATE (D)GLAS,HINTERTEIL									(F)GLACE-HAYON (S)VIDRIO-COMPUERTA DE COLA					
	96306141	.	.	.	B	B	S	.	.	&A22-T45		1				K1
	96306144	.	.	.	B	B	O	.	S	&A01-T45		1				K4
	96224320	.	.	.	B	B	.	.	O	&A01&T45		1				K8
	[06]	(E)STOPPER-GLASS,UPPER (D)STÖPSEL									(F)ARRETOIR OU BOUCHON (S)TAPON					
	96216138	.	.	.	B	B	S	.	S			2				
	[07]	(E)MOLDING-TAILGATE GLASS (D)PREßTEIL,GLAS,HINTERTEIL									(F)MOULURE-GLACE,HAYON (S)MOLOURA-VIDRIO					
	96233056	.	.	.	B	B	S	.	S			1				
	[08]	(E)GLASS-FRT DOOR WINDOW (D)GLAS									(F)GLACE-FENETRE AVANT (S)VIDRIO-VENTANA DELANTERA					
	96304049	.	.	.	B	.	S	.	.	&A22		LH 1				
	96304051	.	.	.	B	.	S	.	.	&A22		RH 1				
	96304053	.	.	.	B	.	O	.	S	&A01		LH 1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96304055	.	.	.	B	.	O	.	S	&A01	RH	1				
	96304048	.	.	.	.	B	S	.	.	&A22	LH	1				
	96304050	.	.	.	.	B	S	.	.	&A22	RH	1				
	96304052	.	.	.	.	B	O	.	S	&A01	LH	1				
	96304054	.	.	.	.	B	O	.	S	&A01	RH	1				
[09]	(E)NUT-SPEED (D)MUTTER (F)ECROU (S)TUERCA															
	09148-06002	.	.	.	B	B	S	.	S			4				
[10]	(E)SCREW-TAPPING (D)SCHRAUBE (F)VIS (S)TORNILLO															
	03140-63163	.	.	.	B	B	S	.	S			4				
[11]	(E)GLASS-RR DOOR WINDOW (D)GLAS (F)GLACE-FENETRE ARRIERE (S)VIDRIO-VENTANA TRASERA															
	96304138	.	.	.	.	B	S	.	.	&A22	LH	1				
	96304140	.	.	.	.	B	S	.	.	&A22	RH	1				
	96304142	.	.	.	.	B	O	.	S	&A01	LH	1				
	96304144	.	.	.	.	B	O	.	S	&A01	RH	1				
[12]	(E)NUT-SPEED (D)MUTTER (F)ECROU (S)TUERCA															
	09148-06002	.	.	.	.	B	S	.	S			4				
[13]	(E)SCREW-TAPPING (D)SCHRAUBE (F)VIS (S)TORNILLO															
	03140-63163	.	.	.	.	B	S	.	S			4				
[14]	(E)GLASS A-HINGED WINDOW (D)GLAS,KIPPFENSTER (F)GLACE-FENETRE (S)VIDRIO-VENTANA BISAGRA															
	96234660	.	.	.	B	.	S	.	.	&A22	LH	1				
	96234661	.	.	.	B	.	S	.	.	&A22	RH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96234662	.	.	.	B	.	O	.	S	&A01	LH	1			•	
	96234663	.	.	.	B	.	O	.	S	&A01	RH	1				
[15]	(E)WEATHERSTRIP-HINGED WDO (D)DICHTUNGSLEISTE										(F)ISOLATION EN BANDELETTE (S)BURLETE					
	96303243	.	.	.	B	.	S	.	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


5J13



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)EMBLEM-HOOD *(D)ETIKETT*									*(F)EMBLEME* *(S)EMBLEMA*				•	
96303492		.	.	B	B	B	S	S	S			1				
[02]		(E)EMBLEM A *(D)ETIKETT*									*(F)EMBLEME* *(S)EMBLEMA*					
96303493		.	.	B	.	.	S	S	S			1			TRUNK LID	
96243520		.	.	.	B	B	S	.	S			1			TAILGATE	
[03]		(E)LETTERING A-LANOS *(D)BESCHRIFTUNG-'LANOS'*									*(F)LETTRES-'LANOS'* *(S)LETRAS-'LANOS'*					
96226350		.	.	B	.	.	S	S	S			1			TRUNK LID	
96245521		.	.	.	B	B	S	.	S			1			TAILGATE	
[06]		(E)LETTERING A-SE *(D)BESCHRIFTUNG-'SE'*									*(F)LETTRES-'SE'* *(S)LETRAS-'SE'*					
96250233		.	.	B	.	.	.	S	.			2				
[07]		(E)LETTERING A-SX *(D)BESCHRIFTUNG-'SX'*									*(F)LETTRES-'SX'* *(S)LETRAS-'SX'*					
96250234		.	.	B	B	B	.	.	S			2				
[08]		(E)LETTERING A-DAEWOO *(D)BESCHRIFTUNG-'DAEWOO'*									*(F)LETTRES-'DAEWOO'* *(S)LETRAS-'DAEWOO'*					
96303494		.	.	B	.	.	S	S	S			1				
96249417		.	.	.	B	B	S	.	S			1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6660 WHEELS & WHEEL COVER




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)WHEEL A (D)RAD									(F)ROUE (S)RUEDA					
	96162637	.	.	B	B	B	S	.	.	&N76&W9U		5			5 JX13	WH
	96162636	.	.	B	B	B	O	S	S	&N76&W9M		5			5 JX13	HF
	90304218	.	.	B	B	B	.	.	O	&PX8		5			5 1/2JX14	HY
	96303778	.	.	B	B	B	.	.	O	&PG4		5			5 1/2JX14	AL
	[02]	(E)WEIGHT-BALANCE (D)GEWICHT AUSGLEICH									(F)POIDS-EQUILIBRAGE (S)PESO-BALANCE					
	96209681	.	.	B	B	B	S	S	S	&N76/PX8		1			5G	
	96209715	.	.	B	B	B	S	S	S	&N76/PX8		1			10G	
	96209716	.	.	B	B	B	S	S	S	&N76/PX8		1			15G	
	96209717	.	.	B	B	B	S	S	S	&N76/PX8		1			20G	
	96209718	.	.	B	B	B	S	S	S	&N76/PX8		1			25G	
	96209719	.	.	B	B	B	S	S	S	&N76/PX8		1			30G	
	96209720	.	.	B	B	B	S	S	S	&N76/PX8		1			35G	
	96209721	.	.	B	B	B	S	S	S	&N76/PX8		1			40G	
	96209722	.	.	B	B	B	S	S	S	&N76/PX8		1			45G	
	96209723	.	.	B	B	B	S	S	S	&N76/PX8		1			50G	
	96209724	.	.	B	B	B	S	S	S	&N76/PX8		1			55G	
	96209725	.	.	B	B	B	S	S	S	&N76/PX8		1			60G	
	96209679	.	.	B	B	B	.	.	O	&PG4		1			5G	
	96209680	.	.	B	B	B	.	.	O	&PG4		1			10G	
	96209682	.	.	B	B	B	.	.	O	&PG4		1			15G	
	96209683	.	.	B	B	B	.	.	O	&PG4		1			20G	
	96209684	.	.	B	B	B	.	.	O	&PG4		1			25G	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96209685	.	.	B	B	B	.	.	O	&PG4		1			30G	
	96209686	.	.	B	B	B	.	.	O	&PG4		1			35G	
	96209687	.	.	B	B	B	.	.	O	&PG4		1			40G	
	96209688	.	.	B	B	B	.	.	O	&PG4		1			45G	
	96209689	.	.	B	B	B	.	.	O	&PG4		1			50G	
	96209690	.	.	B	B	B	.	.	O	&PG4		1			55G	
	96209691	.	.	B	B	B	.	.	O	&PG4		1			60G	
[03]	(E)VALVE-TIRE (D)VENTIL,REIFEN											(F)SOUPAPE-PNEU (S)VALVULA-LLANTA				
	90223915	.	.	B	B	B	O	S	S	&W9M		5				
[04]	(E)VALVE-RUBBER (D)VENTIL,GUMMI											(F)SOUPAPE-CAOUTCHOUC (S)VALVULA-LLANTA				
	11049239	.	.	B	B	B	S	.	O	&W9U/PG4		5				
[05]	(E)COVER A-WHEEL (D)DECKEL,RAD											(F)CARTER-ROUE (S)CUBIERTA-RUEDA				
	96304348	.	.	B	B	B	O	S	S	&P13		4		13 Inch		T3
	96306210	.	.	B	B	B	.	.	O	&P11		4		14 Inch		T4
[06]	(E)CAP-WHEEL HUB (D)DECKEL,RADNABE											(F)CHAPEAU-MOYEU DE ROUE (S)TAPA-CUBO DE RUEDA				
	96304347	.	.	B	B	B	.	.	O	&PG4		4				
[07]	(E)BOLT (D)SCHRAUBE											(F)BOULON (S)PERNO				
	09119-12001	.	.	B	B	B	S	S	S			16				
[08]	(E)BOLT A-SPARE WHEEL WING (D)SCHRAUBE											(F)BOULON (S)PERNO				
	96167631	.	.	B	B	B	S	S	S	&N76		1				
	96167632	.	.	B	B	B	.	.	O	&PX8/PG4		1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[09]	(E)CAP-HUB (D)DECKEL									(F)CHAPEAU (S)TAPA					
	96304346	.	.	B	B	B	S	.	.	&PA5		4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5N13






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)STICKER-ABS *(D)ETIKETT-'ABS'*													*(F)VIGNETTE-'ABS'* *(S)ETIQUETA-'ABS'*	
	96245663	.	.	B	B	B	.	O	O	&JL9		1				
	[02]	(E)STICKER-AIR BAG *(D)ETIKETT-'AIR BAG'*													*(F)VIGNETTE-'AIR BAG'* *(S)ETIQUETA-'AIR BAG'*	
	96245664	.	.	B	B	B	.	O	O	&AJ3		1				
	[03]	(E)STICKER-ABS & AIR BAG *(D)ETIKETT-'ABS & AIR BAG'*													*(F)VIGNETTE-'ABS & AIR BAG'* *(S)ETIQUETA-'ABS & AIR BAG'*	
	96245665	.	.	B	B	B	.	O	O	&JL9&AJ3		1				
	[04]	(E)STICKER-DUAL AIR BAG *(D)ETIKETT-'DUAL AIR BAG'*													*(F)VIGNETTE-'DUAL AIR BAG'* *(S)ETIQUETA-'DUAL AIR BAG'*	
	96245666	.	.	B	B	B	.	O	O	&ABF		1				
	[05]	(E)STICKER-ABS&DUAL AIR BAG *(D)ETIKETT-'ABS&DUAL AIR BAG*													*(F)VIGNETTE-'ABS&DUAL AIR BA* *(S)ETIQUETA-'ABS&DUAL AIR BA*	
	96245667	.	.	B	B	B	.	O	O	&JL9&ABF		1				
	[07]	(E)STICKER-TIRE PRESSURE *(D)ETIKETT*													*(F)VIGNETTE* *(S)ETIQUETA*	
	96304349	.	.	B	B	B	S	S	.	&QTF		1				
	96304466	.	.	B	B	B	O	O	S	&QTJ/QUS		1				
	[08]	(E)STICKER-AIR CONDITIONING *(D)ETIKETT*													*(F)VIGNETTE* *(S)ETIQUETA*	
	96242973	.	.	B	B	B	O	O	O	&C60		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


6710 GRILLE

5B14




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
[01]		(E)GRILLE A-RADIATOR (D)GITTER,KÜHLER									(F)GRILLE-RADIATEUR (S)REJA-RADIADOR					
[01]	96303229	.	.	B	B	B	S	S	S			1				
[02]		(E)COVER-RADIATOR GRILLE (D)DECKEL									(F)CARTER (S)CUBIERTA					
[02]	96215293	.	.	B	B	B	S	S	S			1				
[03]		(E)HOUSING A-RADIATOR GRILLE (D)GEHÄUSE									(F)LOGEMENT (S)CARCASA					
[03]	96215294	.	.	B	B	B	S	S	S			1				
[04]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
[04]	09132-03001	.	.	B	B	B	S	S	S			13				
[05]		(E)NUT-HEXAGON FLANGE (D)MUTTER									(F)ECROU (S)TUERCA					
[05]	08316-25042	.	.	B	B	B	S	S	S			6				
[06]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
[06]	03151-42132	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME																
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	[01]	(E)BUMPER A-FRONT (D)STOßSTANGE,VORNE									(F)PARE-CHOC-AVANT (S)PARACHOQUES-FRENTE					
	S6720006	.	.	B	B	B	S	S	S	&VT2		1				
	S6720007	.	.	B	B	B	.	O	O	&VT3		1				
	[02]	(E)FASCIA A-BUMPER,FRONT (D)SCHILD,VORDERE STOßSTANGE									(F)BANDELETTES (S)PARACHOQUES					
	96226164	.	.	B	B	B	S	S	S			1				
	[03]	(E)ABSORBER-FRT BUMPER ENERG (D)VORDERE STOßSTANGE									(F)AMORTISSEUR (S)AMORTIGUADOR					
	96303216	.	.	B	B	B	S	S	S	&VT2		1				
	96214018	.	.	B	B	B	.	O	O	&VT3		1				
	[04]	(E)BEAM A-FRONT BUMPER IMPAC (D)STANGE,VORDERE STOßSTANGE									(F)BARRE (S)BARRA-IMPACTO					
	96303218	.	.	B	B	B	S	S	S	&VT2		1				
	96214019	.	.	B	B	B	.	O	O	&VT3		1				
	[05]	(E)GRILLE A-FRONT FOG LAMP (D)GITTER,VORDERE NEBELLAMPE									(F)GRILLE (S)REJA-LAMPARA DE NEBLINA					
	96303479	.	.	B	B	B	S	S	S	-T97	LH	1				
	96306248	.	.	B	B	B	S	S	S	-T97	RH	1				
	[06]	(E)BRACKET A-LICENSE PLATE (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96215626	.	.	B	B	B	A	A	A	&T12		1				
	[07]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03112-48222	.	.	B	B	B	A	A	A	&T12		1				
	[08]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09119-06017	.	.	B	B	B	A	A	A	&T12		2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




| KEY NO. | PART NAME | | |




ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09148-04003	.	.	B	B	B	S	S	S			2				
		(E)SCREW-TAPPING														
	[18]	*(D)SCHRAUBE*										*(F)VIS*				
												(S)TORNILLO				
	09136-04005	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)BUMPER A-REAR (D)STOßSTANGE,HINTEN									(F)PARE-CHOC-ARRIERE (S)PARACHOQUES-TRASERO					
	96303222	.	.	B	.	.	S	S	S			1				
	96232611	.	.	.	B	B	S	.	S			1				
	[02]	(E)FASCIA A-BUMPER,REAR (D)SCHILD,HINTERE STOßSTANGE									(F)BANDELETTES (S)PARACHOQUES TRASERO					
	96226178	.	.	B	.	.	S	S	S			1				
	96226180	.	.	.	B	B	S	.	S			1				
	[03]	(E)BRACKET A-RR BUMPER SIDE (D)TRÄGER,HINTERE STOßSTANGE									(F)SUPPORT (S)SOPORTE-LADO					
	96303482	.	.	B	.	.	S	S	S			LH 1				
	96215644	.	.	B	.	.	S	S	S			RH 1				
	96215645	.	.	.	B	B	S	.	S			LH 1				
	96215646	.	.	.	B	B	S	.	S			RH 1				
	[05]	(E)ABSORBER-RR BUMPER ENERGY (D)HINTERE STOßSTANGE									(F)AMORTISSEUR (S)AMORTIGUADOR					
	96303225	.	.	B	.	.	S	S	S			1				
	96215632	.	.	.	B	B	S	.	S			1				
	[06]	(E)BEAM A-REAR BUMPER IMPACT (D)STANGE,HINTERE STOßSTANGE									(F)BARRE (S)BARRA-IMPACTO					
	96303227	.	.	B	B	B	S	S	S			1				
	[07]	(E)SUPPORT-REAR FASCIA,LOWER (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96216493	.	.	B	.	.	S	S	S			4				
	96217114	.	.	.	B	B	S	.	S			LH 1				
	96217115	.	.	.	B	B	S	.	S			RH 1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
	[08]	(E)SUPPORT-REAR FASCIA,UPPER (D)TRÄGER									(F)SUPPORT (S)SOPORTE				-	
	96215642	.	.	.	B	B	S	.	S		LH	1				
	96226268	.	.	.	B	B	S	.	S		RH	1				
	[10]	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-01001	.	.	B	B	B	S	S	S			2				
	[11]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09119-06020	.	.	B	B	B	S	S	S			2		970908		
Y	09119-06039	.	.	B	B	B	S	S	S			2	970908			
	[12]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	09119-06017	.	.	B	B	B	S	S	S			2		970804		
Y	09116-06039	.	.	B	B	B	S	S	S			2	970804			
	[13]	(E)RIVET (D)NIETE									(F)RIVET (S)ROBLON (REMACHE)					
	09229-04002	.	.	B	B	B	S	S	S			4				
	[14]	(E)RIVET (D)NIETE									(F)RIVET (S)ROBLON (REMACHE)					
	09229-04002	.	.	B	B	B	S	S	S			8				
	[15]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-09302	.	.	B	B	B	S	S	S			4				
	[16]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-09302	.	.	B	B	B	S	S	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[17]	(E)WASHER-PLAIN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	09161-07001	.	.	B	B	B	S	S	S			4	970804			
Y	09161-09001	.	.	B	B	B	S	S	S			4	970804			
	[18]	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-03006	.	.	B	B	B	S	S	S			3				
	[19]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42132	.	.	B	B	B	S	S	S			3				
	[20]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	09159-08010	.	.	B	B	B	S	S	S			6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
	[01]	(E)GUARD A-MUD,FRONT (D)KOTFLÜGEL									(F)GARDE-GARDE-BOUE (S)PROTECTOR-GUARDAFANGO					
	96303235	. .	B	B	B	A	A	A			LH	1				
	96306140	. .	B	B	B	A	A	A			RH	1				
	[02]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-04005	. .	B	B	B	A	A	A				4		970804		
Y	09136-04013	. .	B	B	B	A	A	A				4	970804			
	[03]	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04003	. .	B	B	B	A	A	A				4				
	[04]	(E)GUARD-MUD,REAR (D)KOTFLÜGEL,SCHLAMM									(F)GARDE-BOUE (S)PROTECTOR-LODO					
	96303233	. .	B	.	.	A	A	A			LH	1				
	96306249	. .	B	.	.	A	A	A			RH	1				
	96303239	. .	.	B	B	A	.	A			LH	1				
	96306250	. .	.	B	B	A	.	A			RH	1				
	[05]	(E)GUARD-WHEEL,REAR (D)KOTFLÜGEL,SCHLAMM									(F)GARDE-BOUE (S)PROTECTOR-LODO					
	96306231	. .	B	.	.	S	S	S			LH	1				
	96306232	. .	B	.	.	S	S	S			RH	1				
	96304674	. .	.	B	B	S	.	S			LH	1				
	96304675	. .	.	B	B	S	.	S			RH	1				
	[06]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-04005	. .	B	B	B	A	A	A				4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[07]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04010	. .	B	B	B	A	A	A				4				
[08]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-04005	. .	B	B	B	A	A	A				2				
[09]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04003	. .	B	B	B	A	A	A				2				
[10]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-04005	. .	B	B	B	A	A	A				2				
[11]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04003	. .	B	B	B	A	A	A				2				
[12]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-04005	. .	B	B	B	A	A	A				2				
[13]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04010	. .	B	B	B	A	A	A				2				
[14]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09136-04005	. .	B	B	B	A	A	A				2				
[15]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04003	. .	B	B	B	A	A	A				2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7 INTERIOR

7110 INSTRUMENT PANEL
7120 MOLDING & SWITCH
7130 INSTRUMENT CENTER PARTS
7140 CONSOLE
7210 FRONT DOOR TRIM
7220 REAR DOOR TRIM
7310 HEADLINING
7320 SHELF BACK PANEL
7321 COVER-CENTER,LOAD COMPT
7330 FRONT PILLAR TRIM (4DOOR N/B)
7331 FRONT PILLAR TRIM (5DOOR H/B)
7332 FRONT PILLAR TRIM (3DOOR H/B)
7340 REAR PILLAR TRIM (N/B)
7341 REAR PILLAR TRIM (H/B)
7350 SUNSHADE & INSIDE MIRROR
7510 FRONT SEAT
7520 FRONT SEAT PARTS
7530 SEAT GUIDE RAIL
7540 REAR SEAT I
7541 REAR SEAT II
7550 FRONT SEAT BELT
7560 REAR SEAT BELT
7610 FRONT FLOOR CARPET
7620 REAR FLOOR CARPET
7630 DEADENER




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)PANEL-INSTRUMENT (D)VERKLEIDUNG,INSTRUMENT									(F)PANNEAU-TABLEAU DE BORD (S)PANEL-INSTRUMENTO					
96235802		.	.	B	B	B	S	S	S	-ABF		1				
96235804		.	.	B	B	B	.	O	O	&ABF		1				
[02]		(E)COVER-INST PANEL,SIDE (D)DECKEL									(F)CARTER (S)CUBIERTA					
96246806		.	.	B	B	B	S	S	S		LH	1				R3
96246808		.	.	B	B	B	S	S	S		RH	1				R4
[03]		(E)BOX A-GLOVE (D)HANDSCHUHFACH									(F)BOITE-GANTS (S)CAJA-GUANTERA					
96235825		.	.	B	B	B	S	S	S	-ABF		1			INCL. #4~6,8	R7
96235823		.	.	B	B	B	.	O	O	&ABF		1			INCL. #4~6,8	R5
[04]		(E)LOCK A-GLOVE BOX (D)SCHLOß,HANDSCHUHFACH									(F)VERROU-BOITE A GANTS (S)CERRADURA					
96235836		.	.	B	B	B	S	S	S			1				
[05]		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
02124-04123		.	.	B	B	B	S	S	S			2				
[06]		(E)HINGE-GLOVE BOX (D)BESCHLAG,HANDSCHUHFACH									(F)CHARNIERE-BOITE A GANTS (S)BISAGRA					
96221351		.	.	B	B	B	S	S	S			2				
[07]		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
02146-15205		.	.	B	B	B	S	S	S			2				
[08]		(E)PIN-GLOVE BOX (D)STIFT,HANDSCHUHFACH									(F)BROCHE-BOITE A GANTS (S)PASADOR-GUANTERA					
96221307		.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7110 INSTRUMENT PANEL


5C15



KEY NO.	PART NAME													
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[09]									(E)STRIKER A-GLOVE BOX (D)SCHLÄGER			(F)MARTEAU (S)HUELGUISTA			
	96221301	.	.	B	B	B	S	S	S			1				
	[10]									(E)SCREW (D)SCHRAUBE			(F)VIS (S)TORNILLO			
	02146-15165	.	.	B	B	B	S	S	S			2				
	[11]									(E)COVER-INST PANEL,LOWER (D)DECKEL			(F)CARTER (S)CUBIERTA			
	96235788	.	.	B	B	B	S	S	S			1				R3
	[12]									(E)SCREW-TAPPING (D)SCHRAUBE			(F)VIS (S)TORNILLO			
	03160-48165	.	.	B	B	B	S	S	S			4				
	[13]									(E)BRACKET A-INST PANEL,SIDE (D)TRÄGER			(F)SUPPORT (S)SOPORTE			
	96307185	.	.	B	B	B	S	S	S			2				
	[14]									(E)BOLT-HEXAGON (D)SCHRAUBE			(F)BOULON (S)PERNO			
	01107-06123	.	.	B	B	B	S	S	S			2				
	[15]									(E)SCREW (D)SCHRAUBE			(F)VIS (S)TORNILLO			
	02146-15165	.	.	B	B	B	S	S	S			2				
	[16]									(E)BOLT (D)SCHRAUBE			(F)BOULON (S)PERNO			
	09116-08008	.	.	B	B	B	S	S	S			6			W/WASHER	
	[17]									(E)PIECE A-CONNECTING (D)TEIL,VERBINDUNGS			(F)PIECE-DE CONNEXION (S)PIEZA-CONEXION			
	96214161	.	.	B	B	B	S	S	S			LH 1				
	96214201	.	.	B	B	B	S	S	S			RH 1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

5D15




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[18]									(E)BOLT-HEXAGON (D)SCHRAUBE (F)BOULON (S)PERNO						
	01117-06123	.	.	B	B	B	S	S	S			4				
	[19]									(E)NUT-HEXAGON FLANGE (D)MUTTER (F)ECROU (S)TUERCA						
	08316-15063	.	.	B	B	B	S	S	S			4				
	[20]									(E)NUT-HEXAGON (D)MUTTER (F)ECROU (S)TUERCA						
	08316-28083	.	.	B	B	B	S	S	S			2				
	[21]									(E)NOZZLE A-VENT.,DRIVER (D)ABFLUß,LUFT (F)SORTIE-AIR (S)SALIDA-AIRE						
	96241655	.	.	B	B	B	S	S	S		LH	1				
	[22]									(E)NOZZLE A-VENT.,CENTER (D)ABFLUß,LUFT (F)SORTIE-AIR (S)SALIDA-AIRE						
	96241653	.	.	B	B	B	S	S	S			1				
	[23]									(E)NOZZLE A-VENT.,ASSIST. (D)ABFLUß,LUFT (F)SORTIE-AIR (S)SALIDA-AIRE						
	96235809	.	.	B	B	B	S	S	S		RH	1				
	[24]									(E)SCREW-TAPPING (D)SCHRAUBE (F)VIS (S)TORNILLO						
	03140-48165			B	B	B									NOT APPLED	
	03160-48165	.	.	B	B	B	S	S	S			4				
	[25]									(E)SCREW-TAPPING (D)SCHRAUBE (F)VIS (S)TORNILLO						
	03240-42165	.	.	B	B	B	S	S	S			6				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)HOUSING-INSTRUMENT CLUSTE *(D)GEHÄUSE ARMATURENBRETT*										*(F)LOGEMENT-GRAPPE* *(S)CARCASA-TABLERO DE INSTRU*			
96240807		.	.	B	B	B	S	S	S			1	970602			B3
96255623		.	.	B	B	B	S	S	S	-N33		1	970602			B5
96240807		.	.	B	B	B	.	.	O	&N33		1	970602			B3
96240807		.	.	B	B	B	.	O	O	&N33		1			POLAND ONLY	B3
[02]		(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
03160-48165		.	.	B	B	B	S	S	S			6				
[03]		(E)CLOCK A-DIGITAL *(D)UHR,DIGITAL*										*(F)HORLOGE-DIGITALE* *(S)RELOJ-DIGITAL*				
96236122		.	.	B	B	B	O	S	S	-UM1		1				CA
96236123		.	.	B	B	B	A	A	A	&UM1		1				CB
[04]		(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
03110-42135		.	.	B	B	B	S	S	S			2				
[05]		(E)SWITCH A-HAZARD LIGHT *(D)SCHALTER,WARNBLINKER*										*(F)COMMUTATEUR* *(S)INTERRUPTOR*				
96231858		.	.	B	B	B	S	S	S			1				HY
[06]		(E)SWITCH A-HOUSING *(D)SCHALTER*										*(F)COMMUTATEUR* *(S)INTERRUPTOR*				
96230809		.	.	B	B	B	.	.	O	&DD4-HL4		1				ME
96230807		.	.	B	B	B	.	.	A	&DD4&HL4		1				MB
96230811		.	.	B	B	B	A	A	A	&HL4-DD4		1				MH
[07]		(E)COVER-BLANK, F/LAMP S/W *(D)DECKEL*										*(F)COUVERCLE* *(S)CUBIERTA*				
96230804		.	.	B	B	B	S	S	S	-T97/T98		1				DC

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[08]	(E)SWITCH A-MIRROR ADJUST (D)SCHALTER									(F)COMMUTATEUR (S)INTERRUPTOR					
	96230818	. .	B	B	B	. .	O			&DD4		1				KP
	[09]	(E)BOX A-DEPOSIT, CARD (D)KASTEN									(F)BOITE-DEPOT (S)CAJA DE DEPOSITOS					
	96242595	. .	B	B	B	S	S	S				1				
	[10]	(E)COVER-BLANK,CLOCK (D)DECKEL									(F)COUVERCLE (S)CUBIERTA					
	96236126	. .	B	B	B	S	. .			-UM1		1				CC
	96236127	. .	B	B	B	A	. .			&UM1		1				CD
	[11]	(E)SWITCH A-FOG LAMP (D)SCHALTER									(F)COMMUTATEUR (S)INTERRUPTOR					
	96230802	. .	B	B	B	.	O	O		&T97-T98		1				DA
	[12]	(E)SWITCH A-FOG LAMP,REAR (D)SCHALTER									(F)COMMUTATEUR (S)INTERRUPTOR					
	96242528	. .	B	B	B	A	A	A		&T98		1				DE

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)ASHTRAY A-INSTRUMENT PNL (D)ASCHENBECHER								(F)CENDRIER-TABLEAU DE BORD (S)CENICERO						
96235808		. .	B	B	B	S	S	S				1				
[03]		(E)HOLDER A-CUP (D)BEHÄLTER								(F)MONTURE (S)RETNEDOR						
96242957		. .	B	B	B	S	S	S				1				
[04]		(E)SCREW-TAPPING (D)SCHRAUBE								(F)VIS (S)TORNILLO						
03160-42165		. .	B	B	B	S	S	S				2				
[05]		(E)BOX-I/P CENTER DEPOSIT (D)ZENTRAL-FACH								(F)BOITE-DEPOT CENTRAL (S)CAJA-DEPOSITO						
96304289		. .	B	B	B	S	S	S				1				B1
[06]		(E)SCREW (D)SCHRAUBE								(F)VIS (S)TORNILLO						
02116-05165		. .	B	B	B	S	S	S				2				
[11]		(E)BEZEL A-AUDIO (D)KASTEN								(F)BISEAU (S)BISEL						
96303173		. .	B	B	B	S	S	S				1				B2
[12]		(E)SOCKET (D)FASSUNG BIRNE								(F)CULOT-AMPOULE (S)ENCHUFE-BOMBILLA						
11067612		. .	B	B	B	S	S	S				1				
[13]		(E)BULB (D)BIRNE								(F)AMPOULE (S)BOMBILLA						
11062449		. .	B	B	B	S	S	S				1				
Y 09471-12012		. .	B	B	B	S	S	S				1				
[16]		(E)FRAME-CASSETTE (D)RAHMEN-KASSETTE								(F)CADRE-CASSETTE (S)ARMADURA-CASETE						
96254552		. .	B	B	B	S	S	S				1			A/S ONLY	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[17]	96232340	(E)CLIP-SPRING (D)RAHMEN-KASSETTE		.	.	B	B	B	S	S	S	(F)ATTACHE (S)GRAPA		2			
[18]	96221359	(E)CLIP-SPRING (D)RAHMEN-KASSETTE		.	.	B	B	B	S	S	S	(F)ATTACHE (S)GRAPA		2			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)CONSOLE-FRONT (D)KONSOLE VORNE									(F)CONSOLE-AVANT (S)CONSOLA-FRENTE					
	96236781	.	.	B	B	B	S	S	S			1	970701			LH
N	96252617	.	.	B	B	B	S	S	S			1	970701			
[02]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	B	B	S	S	S			2				
[03]		(E)PLUG-CONSOLE (D)STÖPSEL									(F)BOUCHON (S)TAPON					
	96236795	.	.	B	B	B	S	S	S			1				
[04]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	B	B	S	S	S			1				
[05]		(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04013	.	.	B	B	B	S	S	S			1				
[06]		(E)LIGHTER A-CIGAR (D)ANZÜNDER,ZIGARETTEN									(F)ALLUME-CIGARETTE (S)ENCENDEDOR					
	96160018	.	.	B	B	B	S	S	S			1	970701			
N	96242635	.	.	B	B	B	S	S	S			1	970701			
[08]		(E)RING A-LIGHT (D)RING,ZIGARETTEN-ANZÜNDER									(F)ANNEAU-ALLUME-CIGARETTE (S)ANILLO-LUZ DE CIGARRILLO					
	96242616	.	.	B	B	B	S	S	S			1	970701			
N	96233408	.	.	B	B	B	S	S	S			1	970701			
[09]		(E)CONSOLE A-REAR (D)KONSOLE HINTEN									(F)CONSOLE-ARRIERE (S)CONSOLA-TRASERO					
	96239363	.	.	B	B	B	S	S	S			1	970807			
O	96252621	.	.	B	B	B	S	S	S			1	970807			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7140 CONSOLE

5K15




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[10]	(E)PLUG-CONSOLE (D)STÖPSEL									(F)BOUCHON (S)TAPON					
	96236795	.	.	B	B	B	S	S	S			2	970807			
	[11]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03240-48165	.	.	B	B	B	S	S	S			2				
Y	03160-48165	.	.	B	B	B	S	S	S			2				
	[12]	(E)ASHTRAY A-CONSOLE,REAR (D)ASCHENBECHER									(F)CENDRIER (S)CENICERO					
	96236792	.	.	B	B	B	.	.	S			1	970901			
	96236792	.	.	B	B	B	S	S	S			1	970901			
	[13]	(E)COVER-REAR CONSOLE (D)DECKEL									(F)COUVERCLE (S)CUBIERTA					
	96239325	.	.	B	B	B	S	S	.			1	970901			
	[14]	(E)COVER-BLANK,WDO LIFTER SW (D)DECKEL									(F)COUVERCLE (S)CUBIERTA					
	96233407	.	.	B	B	B	S	S	.	&A30		1				KB
	[15]	(E)SWITCH A-WINDOW LIFTER (D)SCHALTER									(F)COMMUTATEUR (S)INTERRUPTOR					
	96233406	.	.	B	B	B	O	O	S	&A32		1				KA
	96242532	.	.	B	.	B	.	.	O	&A31		1				KA

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)TRIM A-FRONT DOOR (D)VERKLEIDUNG,VORDERTÜR									(F)GARNITURE-PORTE AVANT (S)ADORNO-PUERTA DELANTERA					
	96236137	.	.	B	.	B	S	.	.	&A30&TD1	LH	1				A1
	96236138	.	.	B	.	B	S	.	.	&A30&TD1	RH	1				A2
	96247276	.	.	B	.	B	O	S	.	&A30&TD2	LH	1				J5
	96247277	.	.	B	.	B	O	S	.	&A30&TD2	RH	1				J6
	96236141	.	.	B	.	B	O	O	S	&A31/A32&TD2	LH	1				A5
	96236142	.	.	B	.	B	O	O	S	&A31/A32&TD2	RH	1				A6
	96236145	.	.	.	B	.	S	.	.	&A30&TD1	LH	1				G1
	96236146	.	.	.	B	.	S	.	.	&A30&TD1	RH	1				G2
	96247284	.	.	.	B	.	O	.	.	&A30&TD2	LH	1				M3
	96247285	.	.	.	B	.	O	.	.	&A30&TD2	RH	1				M4
	96236149	.	.	.	B	.	O	.	S	&A32&TD2	LH	1				G5
	96236150	.	.	.	B	.	O	.	S	&A32&TD2	RH	1				G6
[02]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	B	B	S	S	S			6				
[03]		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-08301	.	.	B	.	B	S	S	S			10				
	09409-08301	.	.	.	B	.	S	.	S			12				
[04]		(E)HANDLE-DOOR POCKET (D)HENKEL									(F)POIGNEE (S)MANIJA					
	96236165	.	.	B	B	B	S	.	.	&TD1		2				
	96236166	.	.	B	B	B	O	S	S	&TD2		2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[05]	(E)BRACKET-DOOR POCKET HANDL (D)TRÄGER										(F)SUPPORT (S)SOPORTE					
96304828		.	.	B	B	B	S	S	S			2				
[06]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO					
03160-48165		.	.	B	B	B	S	S	S			2				
[07]	(E)HANDLE A-DOOR INSIDE (D)HENKEL										(F)POIGNEE (S)MANIJA					
96238351		.	.	B	B	B	S	S	S		LH	1				
96238352		.	.	B	B	B	S	S	S		RH	1				
[08]	(E)ESCUTCHEON-INSIDE HANDLE (D)ESCHTCHEON										(F)ECUSSON (S)EMBELLECEDOR					
96238359		.	.	B	B	B	S	S	S		LH	1				
96238360		.	.	B	B	B	S	S	S		RH	1				
[09]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO					
03160-48165		.	.	B	B	B	S	S	S			2				
[10]	(E)CRANK A-WINDOW LIFTER (D)KURBEL,FENSTER HEBER										(F)MANIVELLE-SOULEVEUR (S)MANIVELA-LEVANTADOR					
96238361		.	.	B	B	B	S	S	.	&A30		2				
[11]	(E)RING (D)RING										(F)ANNEAU (S)ANILLO					
09388-00001		.	.	B	B	B	S	S	.	&A30		2				
[12]	(E)WASHER-WINDOW LIFTER CRAN (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA					
96238365		.	.	B	B	B	S	S	.	&A30		2				
[13]	(E)SEAL-FRONT DOOR TRIM (D)DICHTUNG										(F)JOINT (S)SELLO					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK

7210 FRONT DOOR TRIM




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96304070	.	.	B	.	B	S	S	S		LH	1				
	96304071	.	.	B	.	B	S	S	S		RH	1				
	96304068	.	.	.	B	.	S	.	S		LH	1				
	96304069	.	.	.	B	.	S	.	S		RH	1				
[14]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	B	B	S	S	S			4				
[15]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA					
	09148-04005	.	.	B	B	B	S	S	S			4				
[16]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA					
	09148-04005	.	.	B	B	B	S	S	S			6				
[17]	(E)NUT-SPEED (D)MUTTER										(F)ECROU (S)TUERCA					
	09148-04005	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
	[01]	(E)TRIM A-REAR DOOR (D)VERKLEIDUNG,HINTERTÜR									(F)GARNITURE-PORTE ARRIERE (S)ADORNO-PUERTA TRASERA					
	96236171	.	.	B	.	B	S	.	.	&TD1&A30/A32	LH	1				D1
	96236172	.	.	B	.	B	S	.	.	&TD1&A30/A32	RH	1				D2
	96236175	.	.	B	.	B	O	S	S	&TD2&A30/A32	LH	1				D5
	96236176	.	.	B	.	B	O	S	S	&TD2&A30/A32	RH	1				D6
	96246592	.	.	B	.	B	.	O	O	&TD2&A31	LH	1				Q1
	96246593	.	.	B	.	B	.	O	O	&TD2&A31	RH	1				Q2
	[02]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	.	B	S	S	S		4					
	[03]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-08301	.	.	B	.	B	S	S	S		12					
	[04]	(E)HANDLE-DOOR POCKET (D)HENKEL									(F)POIGNEE (S)MANIJA					
	96236165	.	.	B	.	B	S	.	.	&TD1	2					
	96236166	.	.	B	.	B	O	S	S	&TD2	2					
	[05]	(E)BRACKET-DOOR POCKET HANDL (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96304828	.	.	B	.	B	S	S	S		2					
	[06]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	.	B	S	S	S		2					
	[07]	(E)HANDLE A-DOOR INSIDE (D)HENKEL									(F)POIGNEE (S)MANIJA					
	96238351	.	.	B	.	B	S	S	S		LH	1				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME																	
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL						FROM	TO		
				4N	3H	5H	S	SE	SX							
	96238352	.	.	B	.	B	S	S	S		RH	1				
	[08]	(E)ESCUTCHEON-INSIDE HANDLE (D)ESCHTCHEON									(F)ECUSSON (S)EMBELLECEDOR					
	96238359	.	.	B	.	B	S	S	S		LH	1				
	96238360	.	.	B	.	B	S	S	S		RH	1				
	[09]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	.	B	S	S	S			2				
	[10]	(E)CRANK A-WINDOW LIFTER (D)KURBEL,FENSTER HEBER									(F)MANIVELLE-SOULEVEUR (S)MANIVELA-LEVANTADOR					
	96238361	.	.	B	.	B	S	S	S	&A30/A32		2				
	[11]	(E)RING (D)RING									(F)ANNEAU (S)ANILLO					
	09388-00001	.	.	B	.	B	S	S	S	&A30/A32		2				
	[12]	(E)WASHER-WINDOW LIFTER CRAN (D)DICHTUNGSRING									(F)RONDELLE (S)ARANDELA					
	96238365	.	.	B	.	B	S	S	S	&A30/A32		2				
	[13]	(E)SEAL-REAR DOOR TRIM (D)DICHTUNG									(F)JOINT (S)SELLO-ADORNO					
	96306640	.	.	B	.	B	S	S	S		LH	1				
	96304151	.	.	B	.	B	S	S	S		RH	1				
	[14]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-48165	.	.	B	.	B	S	S	S			4				
	[15]	(E)NUT-SPEED (D)MUTTER									(F)ECROU (S)TUERCA					
	09148-04005	.	.	B	.	B	S	S	S			4				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7220 REAR DOOR TRIM




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[16]										(E)NUT-SPEED *(D)MUTTER* *(F)ECROU* *(S)TUERCA*						
	09148-04005	.	.	B	.	B	S	S	S				4				
	[17]										(E)NUT-SPEED *(D)MUTTER* *(F)ECROU* *(S)TUERCA*						
	09148-04005	.	.	B	.	B	S	S	S				2				
	[18]										(E)SWITCH A-POWER WDO *(D)SCHALTER* *(F)COMMUTATEUR* *(S)INTERRUPTOR*						
	96242533	.	.	B	.	B	.	.	O			LH	1				
	96242534	.	.	B	.	B	.	.	O			RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)HEADLINING (D)KOPF AUSKLEIDUNG									(F)GARNITURE (S)FORRO DE CABECERA					
	96236011	.	.	B	.	.	S	S	S	-CF6		1		970901		D2
O	96257410	.	.	B	.	.	S	S	S	-CF6		1	970901			E7
	96243596	.	.	B	.	.	O	O	O	&CF6		1		970901		D5
O	96257412	.	.	B	.	.	O	O	O	&CF6		1	970901			F7
	96236010	.	.	.	B	.	S	.	S	-CF6		1		970901		D1
O	96257406	.	.	.	B	.	S	.	S	-CF6		1	970901			C7
	96243595	.	.	.	B	.	O	.	O	&CF6		1		970901		D4
O	96257408	.	.	.	B	.	O	.	O	&CF6		1	970901			D7
	96236012	.	.	.	.	B	S	.	S	-CF6		1		970901		D3
O	96257414	.	.	.	.	B	S	.	S	-CF6		1	970901			H7
	96243597	.	.	.	.	B	O	.	O	&CF6		1		970901		D6
O	96257416	.	.	.	.	B	O	.	O	&CF6		1	970901			J7
	[02]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07316	.	.	B	B	B	S	S	S			3				
	[03]	(E)HANDLE A (D)HENKEL									(F)POIGNEE (S)MANIJA					
	96238629	.	.	B	.	B	S	S	S			2		970901		
Y	96238629	.	.	B	.	B	S	S	S			3	970901			
	96238629	.	.	.	B	.	S	.	S			1				
	[04]	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	09125-06004	.	.	B	.	B	S	S	S			5		970901		
Y	09125-06004	.	.	B	.	B	S	S	S			6	970901			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09125-06004	.	.	.	B	.	S	.	S			3				
	[05]	(E)HOOK-COAT (D)HAKEN										(F)CROCHET (S)PERCHA				
	96236801	.	.	B	.	B	S	S	S			1				
	96236801	.	.	.	B	.	S	.	S			1				
	[06]	(E)COVER-HANDLE (D)DECKEL										(F)COUVERCLE (S)CUBIERTA				
	96240529	.	.	B	B	B	S	S	S			3	970901			
Y	96240529	.	.	.	B	.	S	.	S			3	970901			
Y	96240529	.	.	B	.	B	S	S	S			2	970901			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK

7320 SHELF BACK PANEL



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)SHELF A-BACK PANEL,UPPER *(D)REGAL,HINTERE VERKLEIDUNG*										*(F)ETAGERE-PANNEAU ARRIERE* *(S)ESTANTE-PANEL TRASERO*				
[01]																
96236082		.	.	B	.	.	S	S	.	-T93		1			WO/SPEAKER	E1
96236083		.	.	B	.	.	O	O	S	-T93		1			W/SPEAKER	E2
96236084		.	.	B	.	.	A	A	.	&T93		1			WO/SPEAKER	E3
96236085		.	.	B	.	.	A	A	A	&T93		1			W/SPEAKER	E4
		(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
[02]																
09409-08315		.	.	B	.	.	S	S	S			3				
		(E)GRILLE A-SPEAKER,REAR *(D)GITTER,LAUTSPRECHER*										*(F)GRILLE-HAUT-PARLEUR* *(S)REJA-ALTAVOZ*				
[03]																
96236136		.	.	B	.	.	O	O	S			2				
		(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
[04]																
03111-29065		.	.	B	.	.	O	O	S			8				
		(E)CLIP *(D)KLEMME*										*(F)ATTACHE* *(S)GRAPA*				
[05]																
09409-12003		.	.	B	.	.	S	S	S			3				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)COVER A-LOAD COMPT.CENTER (D)DECKEL									(F)COUVERCLE (S)CUBIERTA					
	96236032	.	.	B	B	S	.	S		-T93		1			INCL. #2	F1
	96236033	.	.	B	B	A	.	A		&T93		1			INCL. #2	F2
	[02]	(E)STRAP-LOAD COMPART.COVER (D)BAND									(F)BRETELLE (S)BRIDA					
	90244194	.	.	B	B	S	.	S				2				
	[03]	(E)BUTTON-FIXING (D)KNOPF									(F)BOUTON (S)BOTON					
	90248700	.	.	B	B	S	.	S				2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7330 FRONT PILLAR TRIM (4DOOR N/B)



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	3H	5H	LEVEL S	SE	SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	TO	REMARKS	P/CODE
	[01]	(E)TRIM A-SHROUD SIDE *(D)VERKLEIDUNG,MANTEL SEITE*									*(F)GARNITURE* *(S)ADORNO-LADO DE CUBIERTA*					
	96235985	.	.	B	.	.	S	S	S		RH	1				
	[02]	(E)TRIM A-SHROUD SIDE *(D)VERKLEIDUNG,MANTEL SEITE*									*(F)GARNITURE* *(S)ADORNO-LADO DE CUBIERTA*					
	96235983	.	.	B	.	.	S	S	S		LH	1				
	[03]	(E)COVER-SHROUD SIDE TRIM *(D)DECKEL*									*(F)COUVERCLE* *(S)CUBIERTA*					
	96235988	.	.	B	.	.	S	S	S			1				
	[04]	(E)CLIP *(D)KLEMME*									*(F)ATTACHE* *(S)GRAPA*					
	09409-05311	.	.	B	.	.	S	S	S			2				
	[05]	(E)COVER A-ROCKER PANEL,FRON *(D)DECKEL*									*(F)COUVERCLE* *(S)CUBIERTA*					
	96235963	.	.	B	.	.	S	S	S		LH	1				
	96235964	.	.	B	.	.	S	S	S		RH	1				
	[06]	(E)TRIM-B PILLAR,LOWER *(D)VERKLEIDUNG,B SÄULE,UNTEN*									*(F)GARNITURE-B PILIER,BAS* *(S)ADORNO-PILAR B,BAJO*					
	96236029	.	.	B	.	.	S	S	S		LH	1				
	96236030	.	.	B	.	.	S	S	S		RH	1				
	[07]	(E)COVER A-ROCKER PANEL,REAR *(D)DECKEL*									*(F)COUVERCLE* *(S)CUBIERTA*					
	96235967	.	.	B	.	.	S	S	.	&AM6	LH	1				
	96235968	.	.	B	.	.	S	S	.	&AM6	RH	1				
	96235969	.	.	B	.	.	.	.	S	&AM9	LH	1				
	96235969	.	.	B	.	.	A	.	A		LH	1	970709		FOR POLAND	
	96235970	.	.	B	.	.	.	.	S	&AM9	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7330 FRONT PILLAR TRIM (4DOOR N/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96235970	.	.	B	.	.	A	.	A		RH	1	970709		FOR POLAND	
	[08]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42135	.	.	B	.	.	S	S	.	&AM6		4				
	03160-42135	.	.	B	.	.	.	.	S	&AM9		2				
	03160-42135	.	.	B	.	.	A	.	A			2	970709		FOR POLAND	
	[09]	(E)TRIM A-A PILLAR (D)VERKLEIDUNG,A SÄULE									(F)GARNITURE-A PILIER (S)ADORNO-PILAR					
	96235979	.	.	B	.	.	S	S	S		LH	1				
	96235980	.	.	B	.	.	S	S	S		RH	1				
	[10]	(E)TRIM A-B PILLAR,UPPER (D)VERKLEIDUNG,B SÄULE,OBEN									(F)GARNITURE-B PILIER,HAUT (S)ADORNO-PILAR B,ALTO					
	96236015	.	.	B	.	.	S	.	.	-AAC	LH	1				B3
	96236016	.	.	B	.	.	S	.	.	-AAC	RH	1				B4
	96236019	.	.	B	.	.	.	S	S	&AAC	LH	1				B7
	96236020	.	.	B	.	.	.	S	S	&AAC	RH	1				B8
	[11]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42163	.	.	B	.	.	S	S	S			4				
	[12]	(E)TRIM A-QUARTER WINDOW (D)VERKLEIDUNG									(F)GARNITURE (S)ADORNO-VENTANA CUADRANTE					
	96236096	.	.	B	.	.	S	S	.	&AM6	LH	1				
	96236097	.	.	B	.	.	S	S	.	&AM6	RH	1				
	96236098	.	.	B	.	.	.	.	S	&AM9	LH	1				
	96236098	.	.	B	.	.	A	.	A		LH	1	970709		FOR POLAND	
	96236099	.	.	B	.	.	.	.	S	&AM9	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7330 FRONT PILLAR TRIM (4DOOR N/B)



KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	96236099	.	.	B	.	.	A	.	A	RH	1	970709		FOR POLAND	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7331 FRONT PILLAR TRIM (5DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]										(E)TRIM A-SHROUD SIDE (D)VERKLEIDUNG,MANTEL SEITE						
	96235985	.	.	.	B	S	.	S				RH	1				
	[02]										(E)TRIM A-SHROUD SIDE (D)VERKLEIDUNG,MANTEL SEITE						
	96235983	.	.	.	B	S	.	S				LH	1				
	[03]										(E)COVER-SHROUD SIDE TRIM (D)DECKEL						
	96235988	.	.	.	B	S	.	S					1				
	[04]										(E)CLIP (D)KLEMME						
	09409-05311	.	.	.	B	S	.	S					2				
	[05]										(E)COVER A-ROCKER PANEL FRON (D)DECKEL						
	96235963	.	.	.	B	S	.	S				LH	1				
	96235964	.	.	.	B	S	.	S				RH	1				
	[06]										(E)TRIM-B PILLAR,LOWER (D)VERKLEIDUNG,B SÄULE,UNTEN						
	96236029	.	.	.	B	S	.	S				LH	1				
	96236030	.	.	.	B	S	.	S				RH	1				
	[07]										(E)COVER A-ROCKER PANEL REAR (D)DECKEL						
	96235969	.	.	.	B	S	.	S				LH	1				
	96235969	.	.	.	B	A	.	A				LH	1	970709		FOR POLAND	
	96235970	.	.	.	B	S	.	S				RH	1				
	96235970	.	.	.	B	A	.	A				RH	1	970709		FOR POLAND	
	[08]										(E)SCREW-TAPPING (D)SCHRAUBE						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7331 FRONT PILLAR TRIM (5DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	03160-42135	.	.	.	B	S	.	S			2					
	[09]	(E)TRIM A-A PILLAR (D)VERKLEIDUNG,A SÄULE									(F)GARNITURE-A PILIER (S)ADORNO-PILAR					
	96235979	.	.	.	B	S	.	S			LH	1				
	96235980	.	.	.	B	S	.	S			RH	1				
	[10]	(E)TRIM A-B PILLAR,UPPER (D)VERKLEIDUNG,B SÄULE,OBEN									(F)GARNITURE-B PILIER,HAUT (S)ADORNO-PILAR B,ALTO					
	96236015	.	.	.	B	S	.	.		-AAC	LH	1				B3
	96236016	.	.	.	B	S	.	.		-AAC	RH	1				B4
	96236019	.	.	.	B	.	.	S		&AAC	LH	1				B7
	96236020	.	.	.	B	.	.	S		&AAC	RH	1				B8
	[11]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42163	.	.	.	B	S	.	S				4				
	[12]	(E)TRIM A-QUARTER WINDOW (D)VERKLEIDUNG									(F)GARNITURE (S)ADORNO-VENTANA CUADRANTE					
	96236108	.	.	.	B	S	.	S			LH	1				
	96236109	.	.	.	B	S	.	S			RH	1				
	[13]	(E)COVER A-LOAD COMPART.SIDE (D)DECKEL,LADEFACH,SEITE									(F)COUVERCLE (S)CUBIERTA					
	96236110	.	.	.	B	S	.	S			LH	1				
	96236111	.	.	.	B	S	.	S			RH	1				
	[14]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42135	.	.	.	B										NOT APPLIED	
	09136-04007	.	.	.	B	S	.	S				4		970701		
O	09136-04012	.	.	.	B	S	.	S				4		970701		

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7331 FRONT PILLAR TRIM (5DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL ※	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)TRIM A-FRONT,WHEELHOUSE (D)VERKLEIDUNG,RADGEHÄUSE									(F)GARNITURE-TIMONERIE,AVANT (S)ADORNO-ENGRANAJE,FR					
[15]																
	96236038	.	.	.	.	B		S	.	S	LH	1				
	96236039	.	.	.	.	B		S	.	S	RH	1				
[16]		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07325	.	.	.	.	B		S	.	S		4			NOT APPLIED	
[17]		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07325	.	.	.	.	B		S	.	S		4				
	09409-07325	.	.	.	.	B		A	.	A		4	970709		FOR POLAND	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7332 FRONT PILLAR TRIM (3DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)TRIM A-SHROUD SIDE *(D)VERKLEIDUNG,MANTEL SEITE*								*(F)GARNITURE* *(S)ADORNO-LADO DE CUBIERTA*						
	96235985	.	.	.	B	.	S	.	S		RH	1				
	[02]	(E)TRIM A-SHROUD SIDE *(D)VERKLEIDUNG,MANTEL SEITE*								*(F)GARNITURE* *(S)ADORNO-LADO DE CUBIERTA*						
	96235983	.	.	.	B	.	S	.	S		LH	1				
	[03]	(E)COVER-UHROUD SIDE TRIM *(D)DECKEL*								*(F)COUVERCLE* *(S)CUBIERTA*						
	96235988	.	.	.	B	.	S	.	S			1				
	[04]	(E)CLIP *(D)KLEMME*								*(F)ATTACHE* *(S)GRAPA*						
	09409-05311	.	.	.	B	.	S	.	S			2				
	[05]	(E)COVER A-ROCKER PANEL *(D)DECKEL*								*(F)COUVERCLE* *(S)CUBIERTA*						
	96235975	.	.	.	B	.	S	.	S		LH	1				
	96235976	.	.	.	B	.	S	.	S		RH	1				
	[06]	(E)TRIM A-FRONT SIDE PANEL *(D)VERKLEIDUNG*								*(F)GARNITURE* *(S)ADORNO*						
	96236067	.	.	.	B	.	S	.	.	&TD1	LH	1				K7
	96236068	.	.	.	B	.	S	.	.	&TD1	RH	1				K8
	96236057	.	.	.	B	.	O	.	S	&TD2	LH	1				K1
	96236058	.	.	.	B	.	O	.	S	&TD2	RH	1				K2
	[10]	(E)TRIM A-B PILLAR,UPPER *(D)VERKLEIDUNG,B SÄULE,OBEN*								*(F)GARNITURE-B PILIER,HAUT* *(S)ADORNO-PILAR B,ALTO*						
	96236013	.	.	.	B	.	S	.	S		LH	1				B1
	96236014	.	.	.	B	.	S	.	S		RH	1				B2
	[12]	(E)TRIM A-QUARTER WINDOW *(D)VERKLEIDUNG*								*(F)GARNITURE* *(S)ADORNO-VENTANA CUADRANTE*						

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7332 FRONT PILLAR TRIM (3DOOR H/B)



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96236094	.	.	.	B	.	S	.	S		LH	1				
	96236095	.	.	.	B	.	S	.	S		RH	1				
	[13]	(E)COVER A-LOAD COMPART.SIDE (D)DECKEL,LADEFACH,SEITE									(F)COUVERCLE (S)CUBIERTA					
	96236110	.	.	.	B	.	S	.	S		LH	1				
	96236111	.	.	.	B	.	S	.	S		RH	1				
	[14]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03160-42135	.	.	.	B	.									NOT APPLIED	
	09136-04007	.	.	.	B	.	S	.	S			6		970701		
O	09136-04012	.	.	.	B	.	S	.	S			6		970701		
	[15]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07325	.	.	.	B	.									NOT APPLIED	
	[16]	(E)TRIM A-FRONT,WHEELHOUSE (D)VERKLEIDUNG,RADGEHÄUSE									(F)GARNITURE-TIMONERIE,AVANT (S)ADORNO-ENGRANAJE,FR					
	96236040	.	.	.	B	.	S	.	S		LH	1				
	96236041	.	.	.	B	.	S	.	S		RH	1				
	[17]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07325	.	.	.	B	.	S	.	S			4				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7340 REAR PILLAR TRIM (N/B)




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)TRIM A-WHEELHOUSE REAR (D)VERKLEIDUNG,RADGEHÄUSE									(F)GARNITURE (S)ADORNO-ENGRANAJE,RR					
[01]																
96236047		. .	B	. .			S	S	S		LH	1				
96238285		. .	B	. .			S	S	S		RH	1				
		(E)COVER-SHOCK ABSORBER,REAR (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
[02]																
96237855		. .	B	. .			S	S	S			2				
		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
[03]																
09409-07326		. .	B	. .			S	S	S			4				
		(E)TRIM A-REAR SIDE PANEL (D)VERKLEIDUNG									(F)GARNITURE (S)ADORNO					
[04]																
96236073		. .	B	. .			S	S	S		LH	1				
96236074		. .	B	. .			S	S	S		RH	1				
		(E)COVER-TAIL LAMP (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
[05]																
96236079		. .	B	. .			S	S	S		LH	1				
96236080		. .	B	. .			S	S	S		RH	1				
		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
[06]																
09409-07326		. .	B	. .			S	S	S			8				
		(E)COVER-BACK PANEL,LOWER (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
[07]																
96236056		. .	B	. .			S	S	S			1				L2
		(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
[08]																
09409-07326		. .	B	. .			S	S	S			6	970509			
09409-07326		. .	B	. .			S	S	S			7	970509			

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[09]	(E)COVER A-BACK PANEL,UPPER (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
	96236053			.	.	B	.	.	S			1				
	96236053			.	.	B	.	A	A			1	970709		FOR POLAND	
	[10]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07325			.	.	B	.	.	S			2				
	09409-07325			.	.	B	.	A	A			2	970709		FOR POLAND	
	[11]	(E)TRIM A-FRONT,WHEELHOUSE (D)VERKLEIDUNG,RADGEHÄUSE									(F)GARNITURE-TIMONERIE,AVANT (S)ADORNO-ENGRANAJE,FR					
	96252543			.	.	B	.	.	S		LH	1				
	96252543			.	.	B	.	A	A		LH	1	970709		FOR POLAND	
	96252545			.	.	B	.	.	S	&AM9	RH	1				
	96252545			.	.	B	.	A	A		RH	1	970709		FOR POLAND	
	[12]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-07325			.	.	B	.	S	S	.		4				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)TRIM A-REAR SIDE PANEL *(D)VERKLEIDUNG*									*(F)GARNITURE* *(S)ADORNO*					
96236071		.	.	.	B	B	S	.	S		LH	1			INCL #2.3	
[02]		(E)COVER-SHOCK ABSORBER,REAR *(D)DECKEL*									*(F)COUVERTURE* *(S)CUBIERTA*					
96237855		.	.	.	B	B	S	.	S			2				
[03]		(E)COVER-TRUNK JACK *(D)DECKEL*									*(F)COUVERTURE* *(S)CUBIERTA*					
96236081		.	.	.	B	B	S	.	S			1				
[04]		(E)TRIM A-REAR SIDE PANEL *(D)VERKLEIDUNG*									*(F)GARNITURE* *(S)ADORNO*					
96236072		.	.	.	B	B	S	.	S		RH	1				
[05]		(E)COVER-BACK PANEL,LOWER *(D)DECKEL*									*(F)COUVERTURE* *(S)CUBIERTA*					
96236055		.	.	.	B	B	S	.	S			1				L1
[06]		(E)CLIP *(D)KLEMME*									*(F)ATTACHE* *(S)GRAPA*					
09409-07326		.	.	.	B	B	S	.	S			6		970509		
09409-07326		.	.	.	B	B	S	.	S			7	970509			


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7350 SUNSHADE & INSIDE MIRROR



KEY NO.	PART NAME																	
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)MIRROR A-INSIDE,TILTABLE *(D)SPIEGEL,VERSTELLBAR*									*(F)RETROVISEUR* *(S)ESPEJO-INCLINABLE*					
	96226345	.	.	B	B	B	S	S	S			1				
	[02]	(E)SUNSHADE A *(D)SONNENBLENDE*									*(F)PARE-SOLEIL* *(S)PARASOL*					
	96235989	.	.	B	B	B	S	S	S	-ABF/AJ3		1			WO/MIRROR	M1
	96235995	.	.	B	B	B	.	O	O	&ABF/AJ3-VB4	LH	1		970508	WO/MIRROR	M3
N	96256547	.	.	B	B	B	.	O	O	&ABF/AJ3-VB4	LH	1	970508		WO/MIRROR	S2
	96235997	.	.	B	B	B	.	A	A	&ABF/AJ3&VB4	LH	1			WO/MIRROR	M4
	96235990	.	.	B	.	.	S	.	.	-ABF/AJ3	RH	1			WO/MIRROR	N1
	96235992	.	.	B	B	B	.	S	S	-ABF/AJ3	RH	1			W/MIRROR	N6
	96236004	.	.	B	B	B	.	O	O	&ABF-VB4	RH	1		970508	W/MIRROR	N8
N	96256551	.	.	B	B	B	.	O	O	&ABF-VB4	RH	1	970508		W/MIRROR	T2
	96236006	.	.	B	B	B	.	A	A	&ABF&VB4	RH	1			W/MIRROR	N9
	[03]	(E)SCREW-TAPPING *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
	03130-35198	.	.	B	B	B	S	S	S			4				
	[04]	(E)BRACKET-SUNSHADE *(D)TRÄGER*									*(F)SUPPORT* *(S)SOPORTE*					
	96236009	.	.	B	B	B	S	S	S			2				
	[05]	(E)SCREW-TAPPING *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					
	03130-35198	.	.	B	B	B	S	S	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



1

KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)SEAT A-FRONT (D)SITZ,VORDER									(F)SIEGE-AVANT (S)ASIENTO-FRENTE					
	96239283	.	.	B	.	B	S	.	.		LH	1				B6
	96239284	.	.	B	.	B	S	.	.		RH	1				B7
	96239281	.	.	B	.	B	O	S	S		LH	1				B4
	96239282	.	.	B	.	B	O	S	S		RH	1				B5
	96239279	.	.	.	B	.	S	.	.		LH	1				B2
	96239280	.	.	.	B	.	S	.	.		RH	1				B3
	96239277	.	.	.	B	.	O	.	S		LH	1				A9
	96239278	.	.	.	B	.	O	.	S		RH	1				B1
	96254867	.	.	B	.	B	A	A	A		LH	1	970709		FOR POLAND	
	96254868	.	.	B	.	B	A	A	A		RH	1	970709		FOR POLAND	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)COVERING-FRONT SEAT BACK (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
[01]	96239314	.	.	B	B	B	S	.	.	&W6K		2				
	96239313	.	.	B	B	B	O	S	S	&W6E		2				
		(E)PAD-FRONT SEAT BACK (D)UNTERLAG									(F)PATIN (S)COJIN					
[02]	96227651	.	.	B	B	B	S	S	S			2				
		(E)FRAME-FRONT SEAT BACK (D)RAHMEN									(F)CADRE (S)ARMADURA					
[03]	96227653	.	.	B	.	B	S	S	S		LH	1				
	96227654	.	.	B	.	B	S	S	S		RH	1				
	96228641	.	.	.	B	.	S	.	S		LH	1				
	96228642	.	.	.	B	.	S	.	S		RH	1				
		(E)COVERING-FRT SEAT CUSHION (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
[04]	96239316	.	.	B	B	B	S	.	.	&W6K		2				
	96239315	.	.	B	B	B	O	S	S	&W6E		2				
		(E)PAD-FRONT SEAT CUSHION (D)UNTERLAG									(F)PATIN (S)COJIN					
[05]	96227652	.	.	B	B	B	S	S	S			2				
		(E)FRAME-FRONT SEAT CUSHION (D)RAHMEN									(F)CADRE (S)ARMADURA					
[06]	96234775	.	.	B	B	B	S	S	S		LH	1				
	96234776	.	.	B	B	B	S	S	S		RH	1				
		(E)HEADREST A-FRONT SEAT (D)KOPFPOLSTER									(F)APPUI-TETE (S)APOYABRAZOS					
[07]	96227633	.	.	B	B	B	S	.	.	&W6K		2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK

7520 FRONT SEAT PARTS




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96227632	.	.	B	B	B	O	S	S	&W6E		2				
	[08]	(E)SLEEVE-HEADREST (D)HÜLSE,KOPFPOLSTER										(F)CHEMISE-APPUI-TETE (S)MANGA				
	96238404	.	.	B	B	B	S	S	S			2			W/LOCK	
	96238405	.	.	B	B	B	S	S	S			2			WO/LOCK	
	[09]	(E)COVER-FRONT SEAT OTR,LWR (D)DECKEL										(F)COUVERTURE (S)CUBIERTA				
	96238397	.	.	B	B	B	S	S	S			LH 1				
	96238398	.	.	B	B	B	S	S	S			RH 1				
	[10]	(E)SCREW-TAPPING (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	03140-42229	.	.	B	B	B	S	S	S			4				
	[11]	(E)COVER-FRONT SEAT OTR,UPR (D)DECKEL										(F)COUVERTURE (S)CUBIERTA				
	96238399	.	.	B	B	B	S	S	S			LH 1				
	96238400	.	.	B	B	B	S	S	S			RH 1				
	[12]	(E)REGULATOR A-FRONT SEAT (D)REGULATOR										(F)REGULATEUR (S)REGULADOR				
	96238401	.	.	B	B	B	S	S	S			2				
	[14]	(E)COVER-FRONT SEAT OTR,UPR (D)SCHRAUBE										(F)COUVERTURE (S)TORNILLO				
	96238395	.	.	B	B	B	S	S	S			LH 1				
	96238396	.	.	B	B	B	S	S	S			RH 1				
	[15]	(E)COVER-SEAT BACK STOP (D)DECKEL										(F)CARTER (S)CUBIERTA				
	96238403	.	.	.	B	.	S	S	S			2				
	[16]	(E)KNOB-LEVER,SEAT BACK STOP (D)KNOPF										(F)BOUTON (S)PERILLA				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY			LEVEL					FROM	TO		
				4N	3H	5H	S	SE	SX						
	96238402	.	.	.	B	.	S	S	S		2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[01]	(E)RAIL A-GUIDE OUTER *(D)SCHIENE,AUßEN FÜHRUNG*									*(F)RAIL-GUIDE EXTERNE* *(S)RIEL-GUIA EXTERNA*					
	96227634	.	.	B	B	B	S	S	S		LH	1				
	96227635	.	.	B	B	B	S	S	S		RH	1				
	[02]	(E)WIRE-SEAT ADJUSTER *(D)VERDRAHTUNG,EINSTELLUNG*									*(F)CABLE-AJUSTEUR SIEGE* *(S)ALAMBRE*					
	96227657	.	.	B	B	B	S	S	S			2				
	[03]	(E)RAIL A-GUIDE INNER *(D)SCHIENE,INNEN FÜHRUNG*									*(F)RAIL-GUIDE INTERNE* *(S)RIEL-GUIA INTERNA*					
	96227636	.	.	B	B	B	S	S	S		LH	1				
	96227637	.	.	B	B	B	S	S	S		RH	1				
	[04]	(E)BOLT *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
	09116-08001	.	.	B	B	B	S	S	S			8			W/WASHER	
	[05]	(E)END PIECE-FRONT SEAT,REAR *(D)TEIL,END*									*(F)PIECE* *(S)PIEZA*					
	96238406	.	.	B	B	B	S	S	S			4				
	[06]	(E)BOLT *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
	01127-08259	.	.	B	B	B	S	S	S			4				
	[07]	(E)BOLT *(D)SCHRAUBE*									*(F)BOULON* *(S)PERNO*					
	01107-10259	.	.	B	.	B	S	S	S			4				
	[08]	(E)NUT-SPEED *(D)MUTTER*									*(F)ECROU* *(S)TUERCA*					
	09148-10001	.	.	B	B	B	S	S	S			4				
	[09]	(E)PIN-LOCKING FRONT SEAT *(D)STIFT*									*(F)BROCHE* *(S)PASADOR*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME												
I/C	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96228645	.	.	B	B	B	S	S	S			4				
	[10]	(E)BOLT-LOCKING FRONT SEAT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	96228646	.	.	.	B	.	S	.	S			4				
	[11]	(E)ROLLER-FRONT SEAT *(D)LAUFROLLE*										*(F)ROULEAU* *(S)RODILLO*				
	96228647	.	.	.	B	.	S	.	S			4				
	[12]	(E)WASHER-PLAIN *(D)DICHTUNGSRING*										*(F)RONDELLE* *(S)ARANDELA*				
	09160-10006	.	.	.	B	.	S	.	S			4				
	[13]	(E)NUT-HEXAGON *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	08310-21089	.	.	.	B	.	S	.	S			4				
	[14]	(E)KNOB-ADJUSTER *(D)KNOPF*										*(F)BOUTON* *(S)PERILLA*				
	9401705	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]		(E)BACK-REAR SEAT (D)SITZ									(F)SIEGE (S)ASIENTO					
96239299		.	.	B	.	.	S	.	.	&W6K		1				Q1
96239300		.	.	B	.	.	O	S	.	&W6E		1				Q2
[02]		(E)COVERING A-REAR SEAT BACK (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
96239307		.	.	B	.	.	S	.	.	&W6K		1				
96239308		.	.	B	.	.	O	S	.	&W6E		1				
[03]		(E)PAD A-REAR SEAT BACK (D)UNTERLAG									(F)PATIN (S)COJIN					
96226019		.	.	B	.	.	S	S	.			1				
[05]		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
09116-08001		.	.	B	.	.	S	S	.			3			W/WASHER	
[06]		(E)CUSHION-REAR SEAT (D)POLSTER,SITZ,HINTER									(F)COUSSIN-SIEGE,ARRIERE (S)COJIN-ASIENTO,TRASERO					
96239297		.	.	B	.	.	S	.	.	&W6K		1				P1
96239298		.	.	B	.	.	O	S	.	&W6E		1				P2
[07]		(E)COVERING A-RR SEAT CUSHIO (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
96239306		.	.	B	.	.	S	.	.	&W6K		1				
96239305		.	.	B	.	.	O	S	.	&W6E		1				
[08]		(E)PAD A-REAR SEAT CUSHION (D)UNTERLAG									(F)PATIN (S)COJIN					
96226016		.	.	B	.	.	S	S	.			1				
[10]		(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
09116-08001		.	.	B	.	.	S	S	.			1			W/WASHER	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
	[11]	(E)COVER-REAR SEAT BACK (D)DECKEL,SITZRÜCKEN								(F)COUVERTURE (S)CUBIERTA						
	96236052	.	.	B	.	.	S	S	.			1				
	[12]	(E)CLIP (D)KLEMME								(F)ATTACHE (S)GRAPA						
	09409-07330	.	.	B	.	.	S	S	.			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)BACK-REAR SEAT (D)SITZ									(F)SIEGE (S)ASIENTO					
	96239301	.	.	B	.	.	.	.	S	&W6E	LH	1				R1
	96239303	.	.	.	B	B	S	.	.	&W6K	LH	1				R3
	96239301	.	.	.	B	B	O	.	S	&W6E	LH	1				R1
	[02]	(E)COVERING A-REAR SEAT BACK (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
	96239311	.	.	B	.	.	O	.	S	&W6E	LH	1				
	96239309	.	.	.	B	B	S	.	.	&W6K	LH	1				
	96239311	.	.	.	B	B	O	.	S	&W6E	LH	1				
	[03]	(E)PAD A-REAR SEAT BACK (D)UNTERLAG									(F)PATIN (S)COJIN					
	96226024	.	.	B	.	.	.	.	S		LH	1				
	96226024	.	.	.	B	B	S	.	S		LH	1				
	[04]	(E)FRAME A-REAR SEAT BACK (D)RAHMEN									(F)CADRE (S)ARMADURA					
	96226030	.	.	B	.	.	.	.	S		LH	1				
	96226030	.	.	.	B	B	S	.	S		LH	1				
	[05]	(E)BACK-REAR SEAT (D)SITZ									(F)SIEGE (S)ASIENTO					
	96239302	.	.	B	.	.	.	.	S	&W6E	RH	1				R2
	96239304	.	.	.	B	B	S	.	.	&W6K	RH	1				R4
	96239302	.	.	.	B	B	O	.	S	&W6E	RH	1				R2
	[06]	(E)COVERING A-REAR SEAT BACK (D)DECKEL									(F)COUVERTURE (S)CUBIERTA					
	96239312	.	.	B	.	.	.	.	S	&W6E	RH	1				
	96239310	.	.	.	B	B	S	.	.	&W6K	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME													
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96239312	.	.	.	B	B	O	.	S	&W6E	RH	1				
	[07]	(E)PAD A-REAR SEAT BACK *(D)UNTERLAG*									*(F)PATIN* *(S)COJIN*					
	96226025	.	.	B	.	.	.	.	S		RH	1				
	96226025	.	.	.	B	B	S	.	S		RH	1				
	[08]	(E)FRAME A-REAR SEAT BACK *(D)RAHMEN*									*(F)CADRE* *(S)ARMADURA*					
	96226031	.	.	B	.	.	.	.	S		RH	1				
	96226031	.	.	.	B	B	S	.	S		RH	1				
	[09]	(E)CUSHION-REAR SEAT *(D)POLSTER,SITZ,HINTER*									*(F)COUSSIN-SIEGE,ARRIERE* *(S)COJIN-ASIENTO,TRASERO*					
	96239298	.	.	B	.	.	.	.	S	&W6E		1				P2
	96239297	.	.	.	B	B	S	.	.	&W6K		1				P1
	96239298	.	.	.	B	B	O	.	S	&W6E		1				P2
	96254874	.	.	.	.	B	O	.	S	&W6E		1	970709		FOR POLAND	P2
	[10]	(E)COVERING A-RR SEAT CUSHIO *(D)DECKEL*									*(F)COUVERTURE* *(S)CUBIERTA*					
	96239305	.	.	B	.	.	.	.	S	&W6E		1				
	96239306	.	.	.	B	B	S	.	.	&W6K		1				
	96239305	.	.	.	B	B	O	.	S	&W6E		1				
	[11]	(E)PAD A-REAR SEAT CUSHION *(D)UNTERLAG*									*(F)PATIN* *(S)COJIN*					
	96226016	.	.	B	.	.	.	.	S			1				
	96226016	.	.	.	B	B	S	.	S			1				
	[12]	(E)BUSHING *(D)LAGERFUTTER*									*(F)MANCHON* *(S)BUJE DE BOQUILLA*					
	96216145	.	.	B	.	.	.	.	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96216145	.	B	.	.	A	.	A				2	970709		FOR POLAND	
	96216145	.	.	.	B	B	S	.	S			2				
	[13]	(E)STRIKER A *(D)SCHLÄGER*										*(F)MARTEAU* *(S)HUELGUISTA*				
	96303088	.	.	B	.	.	.	.	S			2				
	96303088	.	.	B	.	.	A	.	A			2	970709		FOR POLAND	
	96303088	.	.	.	.	B	A	.	A			2	970709		FOR POLAND	
	96303088	.	.	.	B	B	S	.	S			2				
	[14]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09116-08001	.	.	B	.	.	.	.	S			4			W/WASHER	
	09116-08001	.	.	B	.	.	A	.	A			4	970709		FOR POLAND	
	09116-08001	.	.	.	B	B	S	.	S			4			W/WASHER	
	[15]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09116-08001	.	.	B	.	.	.	.	S			4			W/WASHER	
	09116-08001	.	.	B	.	.	A	.	A			4	970709		FOR POLAND	
	09116-08001	.	.	.	B	B	S	.	S			4			W/WASHER	
	[16]	(E)BOLT *(D)SCHRAUBE*										*(F)BOULON* *(S)PERNO*				
	09116-08001	.	.	B	.	.	.	.	S			1			W/WASHER	
	09116-08001	.	.	B	.	.	A	A	A			1	970709		FOR POLAND	
	09116-08001	.	.	.	B	B	S	.	S			1			W/WASHER	
	[17]	(E)KNOB-REAR,SEAT BACK *(D)KNOPF*										*(F)BOUTON* *(S)PERILLA*				
	96238407	.	.	B	.	.	.	.	S			2				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.	PART NAME																
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	96238407	.	.	.	B	B	S	.	S			2				
	[18]	(E)SLEEVE-REAR,SEAT BACK (D)HÜLSE										(F)CHEMISE (S)MANGA				
	96238408	.	.	B	.	.	.	.	S			2				
	96238408	.	.	.	B	B	S	.	S			2				
	[19]	(E)LATCH A-REAR,SEAT BACK (D)VERSCHLUß										(F)LOQUET (S)PESTILLO				
	96226034	.	.	B	.	.	.	.	S			LH 1				
	96226035	.	.	.	B	B	S	.	S			RH 1				
	96226034	.	.	B	.	.	.	.	S			LH 1				
	96226035	.	.	.	B	B	S	.	S			RH 1				
	[20]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	02116-76165	.	.	B	.	.	.	.	S			4				
	02116-76165	.	.	.	B	B	S	.	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7550 FRONT SEAT BELT



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)BELT A-FRONT SEAT (D)SICHERHEITSGURT									(F)CEINTURE-SIEGE AVANT (S)CINTURON-ASIENTO					
	96243252	. .	B .	B			S	.	.	-SGS/ABF/AJ3	LH	1				4L
	96244251	. .	B .	B			S	.	.	-SGS/ABF	RH	1				4M
	96248299	. .	B .	B			.	S	S	-SGS/ABF/AJ3	LH	1				5A
	96248300	. .	B .	B			.	S	S	-SGS/AJ3	RH	1				5B
	96243253	. .	B .	B			.	O	O	&ABF/AJ3-SGS	LH	1			NOT APPLIED	4N
	96240897	. .	B .	B			.	O	O	&ABF/AJ3-SGS	LH	1				2A
	96243254	. .	B .	B			.	O	O	&ABF-SGS	RH	1			NOT APPLIED	4O
	96240898	. .	B .	B			.	O	O	&ABF-SGS	RH	1				1J
	96240890	. .	B .	B			A	.	.	&SGS	LH	1				1A
	96240891	. .	B .	B			A	.	.	&SGS	RH	1				1B
	96254475	. .	B .	B			.	A	A	&SGS	LH	1				7A
	96254476	. .	B .	B			.	A	A	&SGS	RH	1				7B
	96243258	. .	.	B	.		S	.	.	-SGS	LH	1				4T
	96243259	. .	.	B	.		S	.	.	-SGS	RH	1				4U
	96248297	. .	.	B	.		.	.	S	-SGS /ABF/AJ3	LH	1				5C
	96248298	. .	.	B	.		.	.	S	-SGS /ABF	RH	1				5D
	96240878	. .	.	B	.		.	.	O	&ABF/AJ3-SGS	LH	1				1M
	96240879	. .	.	B	.		.	.	O	&ABF-SGS	RH	1				1N
	96240886	. .	.	B	.		A	.	.	&SGS	LH	1				1S
	96240887	. .	.	B	.		A	.	.	&SGS	RH	1				1T
	96254469	. .	.	B	.		.	.	A	&SGS	LH	1				7G
	96254470	. .	.	B	.		.	.	A	&SGS	RH	1				7H

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7550 FRONT SEAT BELT



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[02]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	CPZ01580	.	.	B	.	B	S	S	S			2			L=42	
	CPZ03380	.	.	.	B	.	S	.	S			2			L=20	
	[03]	(E)CAP-FRONT SEAT BELT BOLT (D)DECKEL									(F)CHAPEAU (S)TAPA					
	96236550	.	.	B	B	B	S	S	S			2				
	[04]	(E)SPACER (D)DISTANZSTÜCK									(F)ENTRETOISE (S)ESPACIADOR					
	CPZ46090	.	.	B	.	B	S	S	S			2			Φ 20,L=10	
	[05]	(E)SPACER (D)DISTANZSTÜCK									(F)ENTRETOISE (S)ESPACIADOR					
	CPZ46040	.	.	B	.	B	S	S	S			2			Φ 20,L=5	
	[06]	(E)WASHER-TOOTH (D)DICHTUNGSRING									(F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE					
	CPZ42010	.	.	B	B	B	S	S	S			2				
	[07]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	CPZ01420	.	.	B	B	B	S	.	.	-AAC		2			L=60	
	CPZ01470	.	.	B	B	B	.	S	S	&AAC		2			L=40	
	[08]	(E)SPACER (D)DISTANZSTÜCK									(F)ENTRETOISE (S)ESPACIADOR					
	CPZ46020	.	.	B	B	B	S	.	.	-AAC		2			Φ 20,L=20	
	CPZ46030	.	.	B	B	B	.	S	S	&AAC		2			Φ 20,L=16	
	[09]	(E)SPACER (D)DISTANZSTÜCK									(F)ENTRETOISE (S)ESPACIADOR					
	CPZ46350	.	.	B	B	B	S	.	.	-AAC		2			Φ 20,L=13	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


7550 FRONT SEAT BELT



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
																	(E)WASHER-TOOTH (D)DICHTUNGSRING
[10]	CPZ42010	.	.	B	B	B	S	S	S			2					(F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE
																	(E)BUCKLE A-FRONT SEAT BELT (D)SCHNALLE,SICHERHEITSGURT
[11]	96236531	.	.	B	B	B	S	S	S		LH	1					(F)BOUCLE-CEINTURE SIEGE (S)HEBILLA-CINTURON
	96236532	.	.	B	B	B	S	S	S		RH	1					
																	(E)BOLT (D)SCHRAUBE
[12]	96190876	.	.	B	B	B	S	S	S			2			7/16X22		(F)BOULON (S)PERNO
																	(E)WASHER-SPRING (D)DICHTUNGSRING
[13]	09162-17001	.	.	B	B	B	S	S	S			2					(F)RONDELLE (S)ARANDELA
																	(E)COVER-PILLAR (D)DECKEL
[14]	CPF12130	.	.	B	B	B	S	.	.	-AAC		2					(F)COUVERTURE (S)CUBIERTA
	CPF12120	.	.	B	B	B	.	S	S	&AAC		2					
																	(E)BOLT (D)SCHRAUBE
[15]	09119-06023	.	.	B	B	B	S	S	S			2		970901			(F)BOULON (S)PERNO
O	09119-06028	.	.	B	B	B	S	S	S			2	970901				
																	(E)ADJUSTER-SEAT BELT HEIGHT (D)EINSTELLVORRICHTUNG
[16]	96190873	.	.	B	B	B	A	S	S	&AAC		2					(F)AJUSTEUR-HAUTEUR (S)AJUSTADOR
																	(E)BAR-FRT SEAT BELT SLIDING (D)STANGE,SICHERHEITSGURT
[17]	96226306	.	.	.	B	.	S	.	S		LH	1					(F)BARRE (S)BARRA-DESLIZADOR
	96226307	.	.	.	B	.	S	.	S		RH	1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7550 FRONT SEAT BELT



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME L/R	PART NAME QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[18]	(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO															
	96238619	.	.	.	B	.	S	.	S			2			7/16	
[19]	(E)SPACER (D)DISTANZSTÜCK (F)ENTRETOISE (S)ESPACIADOR															
	96238620	.	.	.	B	.	S	.	S			2			Φ 20,L=14	
[20]	(E)SPACER (D)DISTANZSTÜCK (F)ENTRETOISE (S)ESPACIADOR															
	96238621	.	.	.	B	.	S	.	S			2			Φ 34,L=3.4	
[21]	(E)SPACER (D)DISTANZSTÜCK (F)ENTRETOISE (S)ESPACIADOR															
	96238622	.	.	.	B	.	S	.	S			2			Φ 20,L=4	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




ITC	KEY NO. PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)BELT A-REAR SEAT (D)SICHERHEITSGURT									(F)CEINTURE-SIEGE ARRIERE (S)CINTURON-ASIENTO TRASERO					
	96240913	.	.	B	.	.	S	S	S	-SGS	LH	1				3C
	96240914	.	.	B	.	.	S	S	S	-SGS	RH	1				3D
	96240919	.	.	B	.	.	A	A	A	&SGS	LH	1				3E
	96240920	.	.	B	.	.	A	A	A	&SGS	RH	1				3E
	96240903	.	.	.	B	.	S	.	S	-SGS	LH	1				3M
	96240904	.	.	.	B	.	S	.	S	-SGS	RH	1				3N
	96240905	.	.	.	B	.	A	.	A	&SGS	LH	1				3O
	96240906	.	.	.	B	.	A	.	A	&SGS	RH	1				3P
	96242346	.	.	.	.	B	S	.	S	-SGS	LH	1				4C
	96242348	.	.	.	.	B	S	.	S	-SGS	RH	1				4D
	96242350	.	.	.	.	B	A	.	A	&SGS	LH	1				4E
	96242352	.	.	.	.	B	A	.	A	&SGS	RH	1				4F
	[02]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	CPZ01480	.	.	B	B	B	S	S	S			2		L=30		
	[03]	(E)SPACER (D)DISTANZSTÜCK									(F)ENTRETOISE (S)ESPACIADOR					
	CPZ46040	.	.	B	B	B	S	S	S			2		ϕ20,L=5		
	[04]	(E)WASHER-TOOTH (D)DICHTUNGSRING									(F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE					
	CPZ42010	.	.	B	B	B	S	S	S			2				
	[05]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	CPZ03380	.	.	B	B	B	S	S	S			2		L=20		

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7560 REAR SEAT BELT

6B07




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[06]	(E)WASHER-SPRING (D)DICHTUNGSRING										(F)RONDELLE (S)ARANDELA				
	CPZ41010	.	.	B	B	B	S	S	S			2				
	[07]	(E)WASHER-TOOTH (D)DICHTUNGSRING										(F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE				
	CPZ42010	.	.	B	B	B	S	S	S			2				
	[08]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	CPZ01650	.	.	B	B	B	S	S	S			2			L=32	
	[09]	(E)SPACER (D)DISTANZSTÜCK										(F)ENTRETOISE (S)ESPACIADOR				
	CPZ46040	.	.	B	B	.	S	S	S			2			Φ20,L=5	
	CPZ46090	.	.	.	.	B	.	S	S			2			Φ20,L=10	
	[10]	(E)SPACER (D)DISTANZSTÜCK										(F)ENTRETOISE (S)ESPACIADOR				
	CPZ43240	.	.	B	.	.	.	S	S			2			Φ33,L=2	
	CPZ43220	.	.	.	.	B	S	S	S			2			Φ26,L=3	
	[11]	(E)WASHER-TOOTH (D)DICHTUNGSRING										(F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE				
	CPZ42010	.	.	B	B	B	S	S	S			2				
	[12]	(E)BELT A-RR SEAT,CTR PELVIS (D)SICHERHEITSGURT,MITTE										(F)CEINTURE-PELVIS CENTRE (S)CINTURON-CENTRO PELVIS				
	96240916	.	.	B	B	B	S	S	S	-SGS		1				3V
	96240918	.	.	B	B	B	A	A	A	&SGS		1				3X
	[13]	(E)BOLT (D)SCHRAUBE										(F)BOULON (S)PERNO				
	CPZ03440	.	.	B	B	B	S	S	S			1			L=25	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7560 REAR SEAT BELT


6C07




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)SPACER (D)DISTANZSTÜCK (F)ENTRETOISE (S)ESPACIADOR														
[14]	CPZ43220	. .	B	B	B	S	S	S			1				Φ 26,L=3	
[15]	CPZ42010	(E)WASHER-TOOTH (D)DICHTUNGSRING (F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE . .	B	B	B	S	S	S			1					
[16]	96240908	(E)BUCKLE A-REAR SEAT BELT (D)SCHNALLE,SICHERHEITSGURT (F)BOUCLE-CEINTURE SIEGE (S)HEBILLA-CINTURON . .	B	B	B	S	S	S			1					3T
[17]	CPZ03440	(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO . .	B	B	B	S	S	S			1				L=25	
[18]	CPZ43220	(E)SPACER (D)DISTANZSTÜCK (F)ENTRETOISE (S)ESPACIADOR . .	B	B	B	S	S	S			1				Φ 26,L=3	
[19]	CPZ42010	(E)WASHER-TOOTH (D)DICHTUNGSRING (F)RONDELLE-VERROU DE DENT (S)ARANDELA-CIERRE DE DIENTE . .	B	B	B	S	S	S			1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7610 FRONT FLOOR CARPET







KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)LINING-FLOOR PANEL (D)AUSKLEIDUNG									(F)GARNITURE (S)FORRO-PANEL DEL PISO					
	96243418	.	.	B	.	B	S	S	S	-C35/V86		1				TR
	96252208	.	.	B	.	B	A	A	A	&V86-C35		1				TW
	96252204	.	.	B	.	B	A	A	A	&C35		1				TX
	96258916	.	.	B	.	B	A	A	A			1	970709		FOR POLAND	TQ
	96238378	.	.	.	B	.	S	.	S	-C35/V86		1				TM
	96252209	.	.	.	B	.	A	.	A	&V86-C35		1				TZ
	96252205	.	.	.	B	.	A	.	A	&C35		1				TY
	[02]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-06325	.	.	B	B	B	S	S	S			1				
	[03]	(E)INSULATION-DASH PANEL INR (D)ISOLIERUNG									(F)ISOLATION (S)AISLAMIENTO					
	96124011	.	.	B	B	B	S	S	S			1		970701		TQ
	96124011	Y	.	B	B	B	S	S	.			1	970701	970901		TQ
	96252017	6	.	B	B	B	.	.	S			1	970701	970901		TQ
Y	96252017	.	.	B	B	B	S	S	S			1	970901			TQ
	[04]	(E)CLIP (D)KLEMME									(F)ATTACHE (S)GRAPA					
	09409-05311	.	.	B	B	B	S	S	S			11				
	[05]	(E)INSULATION-FLOOR PNL,FRT (D)ISOLIERUNG									(F)ISOLATION (S)AISLAMIENTO					
	96124012	.	.	B	B	B	S	S	S	-C35		1				TS
	96245052	.	.	B	B	B	A	A	A	&C35		1				TW
	[07]	(E)INSULATION-FRT PILLAR,LWR (D)ISOLIERUNG									(F)ISOLATION (S)AISLAMIENTO					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7610 FRONT FLOOR CARPET







ITC	KEY NO. PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96246330	.	.	B	B	B	S	S	S		LH	1				
	96246331	.	.	B	B	B	S	S	S		RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6F07







KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)MAT A-FLOOR PANEL,TRUNK (D)AUSKLEIDUNG									(F)GARNITURE (S)FORRO					
	96237863	.	.	B	.	.	S	.	.			1		970509	INCL #2	G8
O	96255259	.	.	B	.	.	S	.	.			1	970509	970901	INCL #2	R4
	96237867	.	.	B	.	.	O	S	.			1		970509	INCL #2	H5
O	96255265	.	.	B	.	.	O	S	.			1	970509	970901	INCL #2	S5
	96255265	.	.	B	.	.	S	S	.			1	970901		INCL #2	S5
	96237866	.	.	B	.	.	.	.	S			1		970509	INCL #2	H4
O	96255263	.	.	B	.	.	.	.	S			1	970509		INCL #2	S4
	96255263	.	.	B	.	.	A	.	A			1	970709		FOR POLAND	S4
	96237862	.	.	.	B	B	S	.	.			1		970509	INCL #2	G7
O	96255257	.	.	.	B	B	S	.	.			1	970509	970901	INCL #2	R3
	96237865	.	.	.	B	B	O	.	S			1		970509	INCL #2	H3
O	96255262	.	.	.	B	B	O	.	S			1	970509	970901	INCL #2	S3
	96255262	.	.	.	B	B	S	.	S			1	970901		INCL #2	S3
	[02]	(E)BOARD-FLOOR PANEL,TRUNK (D)BODENVERKLEIDUNG									(F)GARNITURE (S)TABLON DE MALETERO					
	96303140	.	.	B	.	.	S	S	S			1		970509		
O	96255266	.	.	B	.	.	S	S	S			1	970509			
	96303005	.	.	.	B	B	S	.	S			1		970509		
	96255267	.	.	.	B	B	S	.	S			1	970509			
	[03]	(E)PLUG (D)STÖPSEL									(F)BOUCHON (S)TAPON					
	09241-30003	.	.	B	B	B									NOT APPLIED	
	09409-07326	.	.	B	.	.	.	.	S	&AM9		5				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7620 REAR FLOOR CARPET







KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	09409-07326	.	.	B	.	.	A	.	A			5			FOR POLAND	
	09409-07326	.	.	.	B	B	S	.	S	&AM9		5				
	09409-07326	.	.	.	.	B	A	.	A			5			FOR POLAND	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

630 DEADENER







KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		(E)DEADENER-FLOOR PANEL,FRT *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[01]	96303091	. .	B	B	B	S	S	S			LH	1				
	96303092	. .	B	B	B	S	S	S			RH	1				
		(E)DEADENER-FLOOR,FRT TUNNEL *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[02]	96303089	. .	B	B	B	S	S	S				1				
		(E)DEADENER-FLOOR PANEL,REAR *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[03]	96303093	. .	B	B	B	S	S	S			LH	1				
	96303094	. .	B	B	B	S	S	S			RH	1				
		(E)DEADENER-FLOOR,RR TUNNEL *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[04]	96303090	. .	B	B	B	S	S	S				1				
		(E)DEADENER-FRT PILLAR UPPER *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[05]	96226902	. .	B	B	B	S	S	S				2				
		(E)DEADENER-FRT PILLAR,LOWER *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[06]	96226915	. .	B	B	B	S	S	S				2				
		(E)DEADENER-ROOF PANEL *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[07]	96229803	. .	B	B	B	S	S	S				1				
		(E)DEADENER-SIDE PANEL,TRUNK *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[08]	96243410	. .	B	.	.	S	S	S				1				
		(E)DEADENER-RR FLR TRUNK SID *(D)ENDSTÜCK*									*(F)ASSOURDISSEUR* *(S)AMORTIGUADOR*					
[09]																

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

7630 DEADENER






KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96252517	.	.	B	.	.	S	S	S			1				
	96252749	.	.	.	B	B	S	.	S			1				
	[10]	(E)DEADENER-FRT WHEEL HOUSIN (D)ENDSTÜCK										(F)ASSOURDISSEUR (S)AMORTIGUADOR				
	96238894	.	.	B	B	B	S	S	S		LH	2				
	96238896	.	.	B	B	B	S	S	S		RH	2				
	[11]	(E)DEADENER-FRT PILLAR,SIDE (D)ENDSTÜCK										(F)ASSOURDISSEUR (S)AMORTIGUADOR				
	96226915	.	.	B	B	B	S	S	S			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


8 HEATER & AIR CONDITIONER

8110 AIR DISTRIBUTION
8210 MODULE-AIR CONDITIONER
8220 BLOWER
8230 EVAPORATOR
8310 CONDENSER A
8320 COMPRESSOR
8330 COMPRESSOR MOUNT
8340 AIR CONDITIONER HOSE & PIPE LINE(LHD)
8350 AIR CONDITIONER CONTROL SWITCH




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)DUCT A-INST PANEL UPR AIR (D)SCHACHT LUFTEINLAß									(F)CONDUIT-ENTREE D'AIR (S)CONDUCTO-ENTRADA DE AIRE					
96252010		.	.	B	B	B	S	S	S			1				
[02]		(E)HOSE A-SIDE DEFROSTER (D)SCHLAUCH,ENTFROSTER									(F)TUYAU-DEGIVREUR (S)MANGUERA-DESCONGELADOR					
96217063		.	.	B	B	B	S	S	S		LH	1				
[03]		(E)HOSE A-SIDE DEFROSTER (D)SCHLAUCH,ENTFROSTER									(F)TUYAU-DEGIVREUR (S)MANGUERA-DESCONGELADOR					
96217064		.	.	B	B	B	S	S	S		RH	1				
[04]		(E)HOSE A-VENTILATION (D)SCHLAUCH,VENTILATOR									(F)TUYAU-VENTILATION (S)MANGUERA-VENTILACION					
96304300		.	.	B	B	B	S	S	S			1				
[05]		(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
03240-48165		.	.	B	B	B	S	S	S			9		970401		
Y 03160-48165		.	.	B	B	B	S	S	S			9	970401			
[06]		(E)DUCT A-LEG ROOM,REAR (D)SCHACHT									(F)CONDUIT (S)CONDUCTO					
96235400		.	.	B	B	B	A	A	A	&C35	LH	1				
96235401		.	.	B	B	B	A	A	A	&C35	RH	1				
[07]		(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
03151-55133		.	.	B	B	B	A	A	A	&C35		2				
[08]		(E)CONNECTOR A-AIR DISRIBUTOR (D)VERBINDUNG									(F)CONNECTEUR (S)CONECTOR					
96251041		.	.	B	B	B	A	A	A	&C35	LH	1				
96243680		.	.	B	B	B	A	A	A	&C35	RH	1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)MODULE-AIR CONDITIONER (D)KLIMAANLAGE									(F)CLIMATISEUR (S)ACONDICIONADOR DE AIRE					
96251693		.	.	B	B	B	S	S	S	&C46-C35		1				NS
96237889		.	.	B	B	B	A	A	A	&C46&C35		1				NC
96241129		.	.	B	B	B	O	O	O	&C59/C60-C35		1				NE
96241130		.	.	B	B	B	A	A	A	&C59/C60&C35		1				NF
[02]		(E)CASE A-DEFROSTER (D)KASTEN									(F)CARTER (S)CAJA					
612418		.	.	B	B	B	S	S	S			1			INCL.#3	
[03]		(E)VALVE A-MODE (D)VENTIL									(F)SOUPAPE (S)VALVULA					
611722		.	.	B	B	B	S	S	S			1				
[04]		(E)VALVE A-TEMPERATURE (D)VENTIL,TEMPERATUR									(F)SOUPAPE-TEMPERATURE (S)VALVULA-TEMPERATURA					
612022		.	.	B	B	B	S	S	S			1				
[05]		(E)VALVE A-HEATER/DEFROSTER (D)VENTIL									(F)SOUPAPE (S)VALVULA					
611723		.	.	B	B	B	S	S	S			1				
[06]		(E)CLIP-TEMP VALVE (D)KLEMME									(F)ATTACHE (S)GRAPA					
611998		.	.	B	B	B	S	S	S			1				
[07]		(E)CASE A-UPPER (D)KASTEN									(F)CARTER (S)CAJA					
612962		.	.	B	B	B	S	S	S	&C46		1				
612098		.	.	B	B	B	O	O	O	&C59/C60		1				
[08]		(E)CASE-DISTRIBUTOR (D)KASTEN									(F)CARTER (S)CAJA					
612115		.	.	B	B	B	S	S	S	-C35		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
	612112	.	.	B	B	B	A	A	A	&C35		1					(E)CASE- COVER (D)KASTEN (F)CARTER (S)CAJA
[09]																	
	612071	.	.	B	B	B	S	S	S			1					(E)CLIP-RETAINING (D)KLEMME (F)ATTACHE (S)GRAPA
[10]																	
	611984	.	.	B	B	B	S	S	S			2					(E)SEAL-HEATER PIPE (D)DICHTUNG (F)JOINT D'ETANCHEITE (S)SELLO
[11]																	
	612127	.	.	B	B	B	S	S	S			1					(E)CLIP-TANK MOUNTING (D)KLEMME (F)ATTACHE (S)GRAPA
[12]																	
	611977	.	.	B	B	B	S	S	S			1					(E)CORE-HEATER (D)GEHÄUSE HEIZUNG (F)NOYAU-CHAUFFAGE (S)NUCLEO-CALENTADOR
[13]																	
	96231949	.	.	B	B	B	S	S	S			1					(E)BRACKET-PIPE MOUNTING (D)TRÄGER (F)SUPPORT (S)SOPORTE
[14]																	
	611980	.	.	B	B	B	S	S	S			1					(E)CASE A-SHROUD (D)KASTEN (F)CARTER (S)CAJA
[15]																	
	612159	.	.	B	B	B	S	S	S			1					(E)SEAL-DASH MOUNTING RING (D)DICHTUNG (F)JOINT D'ETANCHEITE (S)SELLO
[16]																	
	612961	.	.	B	B	B	S	S	S			1					(E)LEVER-MAIN (D)HEBEL (F)LEVIER (S)PALANCA
[17]																	
	612108	.	.	B	B	B	S	S	S			1					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	612124	.	.	B	B	B	S	S	S			1				
	[28]	(E)INLET-AIR *(D)LUFTEINLAß*										*(F)ENTREE D'AIR* *(S)ENTRADA DE AIRE*				
	612104	.	.	B	B	B	O	O	O	&C59/C60		1				
	[29]	(E)SCREW *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
	611979	.	.	B	B	B	S	S	S			45				
	[30]	(E)SCREW-TAPPING *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
	03160-48165	.	.	B	B	B	S	S	S			2				
	[31]	(E)NUT-SPEED *(D)MUTTER*										*(F)ECROU* *(S)TUERCA*				
	03511-48042	.	.	B	B	B	S	S	S			2				
	[32]	(E)SCREW *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
	09139-06003	.	.	B	B	B	S	S	S			5				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
		PART NAME														
[01]		(E)CASE A -LOWER (D)KASTEN										(F)CARTER (S)CAJA				
612982		.	.	B	B	B	S	S	S	&C46		1				
612980		.	.	B	B	B	O	O	O	&C59/C60		1				
[02]		(E)MOTOR-BLOWER (D)MOTOR										(F)MOTEUR (S)MOTOR				
96190671		.	.	B	B	B	S	S	S			1				
[03]		(E)RESISTOR (D)WIDERSTAND										(F)RESISTANCE (S)RESISTOR				
96247452		.	.	B	B	B	S	S	S			1				
[04]		(E)TUBE-COOLING (D)ROHRLEITUNG										(F)TUYAU OU TUBE (S)TUBO				
612030		.	.	B	B	B	S	S	S			1				
[06]		(E)BRACKET-LOWER (D)TRÄGER										(F)SUPPORT (S)SOPORTE				
612207		.	.	B	B	B	S	S	S			1				
[06]		(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
611979		.	.	B	B	B	S	S	S			5				
[07]		(E)CLIP-LEAD WIRE (D)KLEMME										(F)ATTACHE (S)GRAPA				
610452		.	.	B	B	B	S	S	S			1				
[08]		(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
02146-06123		.	,	B	B	B	S	S	S			1				
[09]		(E)COVER-MOTOR (D)DECKEL										(F)CARTER (S)CUBIERTA				
612971		.	.	B	B	B	S	S	S			1			NOT APPLIED	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO.		PART NAME													
ITC	PART NO	MODEL								OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	P/CODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[10] 611983	(E)SCREW (D)SCHRAUBE									(F)VIS (S)TORNILLO					
		.	.	B	B	B	S	S	S			3				


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[01]																	(E)EVAPORATER A (D)VERDAMPFER (F)EVAPORATEUR (S)EVAPORADOR
612122		.	.	B	B	B	O	O	O	&C59/C60		1					
[02]																	(E)CORE A-EVAPORATOR (D)GEHÄUSE VERDAMPFER (F)NOYAU-EVAPORATEUR (S)NUCLEO-EVAPORADOR
612220		.	.	B	B	B	O	O	O	&C59/C60		1					
[03]																	(E)O RING-EVAPORATOR OUTLET (D)O RING (F)JOINT TORIQUE (S)ANILLO EN O
3094215		.	.	B	B	B	O	O	O	&C59/C60		1					
[04]																	(E)O RING-EVAPORATOR INLET (D)O RING (F)JOINT TORIQUE (S)ANILLO EN O
3094214		.	.	B	B	B	O	O	O	&C59/C60		1					
[05]																	(E)VALVE-THERMOSTATIC EXPANS (D)VENTIL (F)SOUPAPE (S)VALVULA
96190670		.	.	B	B	B	O	O	O	&C59/C60		1					
[06]																	(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO
600098		.	.	B	B	B	O	O	O	&C59/C60		1					
[07]																	(E)O RING-DASH INLET (D)O RING (F)JOINT TORIQUE (S)ANILLO EN O
3093509		.	.	B	B	B	O	O	O	&C59/C60		1					
[08]																	(E)O RING-DASH OUTLET (D)O RING (F)JOINT TORIQUE (S)ANILLO EN O
3094215		.	.	B	B	B	O	O	O	&C59/C60		1					
[09]																	(E)FITTING&PIPE A-IN/OUT (D)BEFESTIGUNG (F)MONTAGE (S)TUBERIA ENTRADA-SALIDA
612210		.	.	B	B	B	O	O	O	&C59/C60		1					
[10]																	(E)SEAL-EVAPORATOR (D)DICHTUNG (F)JOINT (S)SELLO


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

6K08




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	612054	.	.	B	B	B	O	O	O	&C59/C60		1				
[11]	(E)SEAL-BLOCK *(D)DICHTUNG*											*(F)JOINT* *(S)SELLO*				
	612463	.	.	B	B	B	O	O	O	&C59/C60		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO.		PART NAME														
ITC	PART NO	MODEL							OPTION	L/R	QTY	EFFECTIVE DATE		REMARKS	PICODE
		ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX				FROM	TO		
	[01]	(E)CONDENSER A (D)KONDENSATOR									(F)CONDENSATEUR (S)CONDENSADOR					
	96303204	.	.	B	B	B	O	O	O	&C60		1				K1
	[02]	(E)NUT (D)MUTTER									(F)ECROU (S)TUERCA					
	09159-06011	.	.	B	B	B	O	O	O	&C60		2				
	[03]	(E)NUT-HEXAGON (D)MUTTER									(F)ECROU (S)TUERCA					
	08310-12083	.	.	B	B	B	O	O	O	&C60		1				
	[04]	(E)DRYER-RECEIVER (D)FILTERTROCKNER									(F)RECEVEUR SEC (S)BOTELLA SECADORA					
	96225633	.	.	B	B	B	O	O	O	&C60		1				
	[05]	(E)GROMMET (D)ÖSE									(F)VIROLE (S)AISLANTE					
	09308-06006	.	.	B	B	B	O	O	O	&C60		2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)COMPRESSOR A (D)KOMPRESSOR										(F)COMPRESSEUR (S)COMPRESOR				
	96245943	.	.	B	B	B	O	O	O	&C60		1	970715			KA
N	96255980	.	.	B	B	B	O	O	O	&C60		1	970715			KC
	[02]	(E)CLUTCH&PULLEY KIT (D)KUPPLUNG&ROLLE SATZ										(F)TROUSSE EMBRAYAGE&POULIE (S)EMBRAGUE-& POLEA,JUEGO				
	NP1072	.	.	B	B	B	O	O	O	&C60		1				
	[03]	(E)NUT (D)MUTTER										(F)ECROU (S)TUERCA				
	6557414	.	.	B	B	B	O	O	O	&C60		1				
	[04]	(E)DRIVE A-CLUTCH (D)ANTRIEB,KUPPLUNG										(F)ENTRAINEMENT-EMBRAYAGE (S)IMPULSADOR-EMBRAGUE				
	713402	.	.	B	B	B	O	O	O	&C60		1				
	[05]	(E)RING-RETAINING (D)RING,HALTER										(F)ANNEAU-DE RETENTION (S)ANILLO-RETENEDOR				
	6557617	.	.	B	B	B	O	O	O	&C60		1				
	[06]	(E)PULLEY&BEARING A (D)ROLLE&LAGER										(F)POULIE&ROULEMENT (S)POLEA Y COJINETE				
	713833	.	.	B	B	B	O	O	O	&C60		1				
	[07]	(E)COIL&HOUSING A (D)WICKLUNG&LAGER										(F)BOBINE&ROULEMENT (S)BOBINA Y COJINETE				
	714142	.	.	B	B	B	O	O	O	&C60		1				
	[08]	(E)LOCK&SLEEVE KIT (D)SCHLOß&HÜLSE SATZ										(F)TROUSSE VERROU&MANCHON (S)CERRADURA Y MANGA				
	713650	.	.	B	B	B	O	O	O	&C60		1				
	[09]	(E)COMPRESSOR SUB A (D)KOMPRESSOR UNTER										(F)COMPRESSEUR SUB (S)COMPRESOR SUB				
	714144	.	.	B	B	B	O	O	O	&C60		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. LTC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[10]	713247	.	.	B	B	B	O	O	O	&C60		6			(E)BOLT (D)SCHRAUBE (F)BOULON (S)PERNO	
[11]	N/S(9)	.	.	B	B	B	O	O	O	&C60		2			(E)HEAD-FRONT (D)KOPF,VORNE (F)CULASSE-AVANT (S)CABEZA-FRENTE	
[12]	6557662	.	.	B	B	B	O	O	O	&C60		2			(E)O RING-FRT HEAD CYLINDER (D)O RING,VORDERER KOPF (F)JOINT TORIQUE (S)ANILLO EN O	
[13]	N/S(9)	.	.	B	B	B	O	O	O	&C60		1			(E)CYLINDER-SHAFT&GUIDE PIN (D)ZYLINDER (F)CYLINDRE-AXE&BROCHE GUIDE (S)CILINDRO	
[14]	6559801	.	.	B	B	B	O	O	O	&C60		1			(E)REED-SUCTION (D)ROHR ANSAUGUNG (F)ANCHE D'ASPIRATION (S)CAÑA-SUCCION	
[15]	6553562	.	.	B	B	B	O	O	O	&C60		1			(E)PLATE-VALVE (D)PLATTE,VENTIL (F)PLAQUE-SOUPAPE (S)PLACA-VALVULA	
[16]	6559755	.	.	B	B	B	O	O	O	&C60		1			(E)GASKET-HEAD (D)DICHTUNG,KOPF (F)JOINT-CULASSE (S)JUNTA-CABEZA	
[17]	N/S(9)						O	O	O						(E)HEAD-REAR (D)KOPF,HINTER (F)CULASSE-ARRIERE (S)CABEZA-TRASERA	
[18]	5110156	.	.	B	B	B	O	O	O	&C60		1			(E)VALVE KIT-CONTROL (D)VENTIL SATZ,STEUERUNG (F)TROUSSE DE SOUPAPE (S)JUEGO DE VALVULA-CONTROL	
[19]															(E)VALVE-HIGH PRESSURE RELIF (D)VENTIL,HOCHDRUCK LÖSUNG (F)SOUPAPE (S)VALVULA	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	6552743	.	.	B	B	B	O	O	O	&C60		1				
	[20]	(E)BOLT-STUD (D)STIFTSCHRAUBE														
	6558459	.	.	B	B	B	O	O	O	&C60		1				
	[21]	(E)BRACKET (D)TRÄGER														
	96241910	.	.	B	B	B	O	O	O	&C60		1		970715		
N	96255631	.	.	B	B	B	O	O	O	&C60		1	970715			
	[22]	(E)BOLT (D)SCHRAUBE														
	713847	.	.	B	B	B	O	O	O	&C60		3				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
											(E)BRACKET-COMPRESSOR MAIN *(D)TRÄGER,KOMPRESSOR*					*(F)SUPPORT-COMPRESSEUR* *(S)SOPORTE-COMPRESOR*	
	[01]																
	96352039	1	.	B	B	B	O	O	O	&C60			1		970715		
N	96352642	1	.	B	B	B	O	O	O	&C60			1	970715			
	96352038	6	.	B	B	B	.	.	O	&C60			1		970715		
N	96352641	6	.	B	B	B	.	.	O	&C60			1	970715			
	[02]										(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*	
	09103-10040	.	.	B	B	B	O	O	O	&C60			4		970715		
	09103-10040	.	.	B	B	B	O	O	O	&C60			3	970715			
	[03]										(E)PIECE-SLIDING *(D)GLEIT-TEIL*					*(F)PIECE COULISSANTE* *(S)PIEZA DE DESLICE*	
	96193361	.	.	B	B	B	O	O	O	&C60			1				
	[04]										(E)BOLT-HEXAGON *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*	
	09117-08013	.	.	B	B	B	O	O	O	&C60			1		970901		
O	09100-08008	.	.	B	B	B	O	O	O	&C60			1	970901			
	[05]										(E)SPACER *(D)DISTANZSTÜCK*					*(F)ENTRETOISE* *(S)ESPACIADOR*	
	96209433	.	.	B	B	B	O	O	O	&C60			1				
	[06]										(E)PULLEY A *(D)ROLLE*					*(F)POULIE* *(S)POLEA*	
	96208428	.	.	B	B	B	O	O	O	&C60			1				
	[07]										(E)NUT *(D)MUTTER*					*(F)ECROU* *(S)TUERCA*	
	09159-10001	.	.	B	B	B	O	O	O	&C60			1				
	[08]										(E)BOLT-HEXAGON FLANGE *(D)SCHRAUBE*					*(F)BOULON* *(S)PERNO*	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	01517-08853	.	.	B	B	B	O	O	O	&C60		2				
[09]	(E)COVER-DUST (D)STAUBDECKEL														(F)COUVERTURE-POUSSIERE (S)CUBIERTA-POLVO	
	96187507	.	.	B	B	B	O	O	O	&C60		1				
[10]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														(F)BOULON (S)PERNO	
	09103-08032	.	.	B	B	B	O	O	O	&C60		2				
[11]	(E)BOLT-HEXAGON FLANGE (D)SCHRAUBE														(F)BOULON (S)PERNO	
	09103-10061	.	.	B	B	B	O	O	O	&C60		1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

8350 AIR CONDITIONER CONTROL SWITCH


6G09



KEY NO.	PART NAME														
ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)SWITCH A-HEATER CONTROL (D)SCHALTER														
	96242969	.	.	B	B	B	S	S	S	&C46		1				NJ
	96242970	.	.	B	B	B	O	O	O	&C59/C60		1				NK
	[02]	(E)PANEL A -FRONT (D)VERKLEIDUNG,VORNE														
	759189	.	.	B	B	B	S	S	S			1				
	[03]	(E)KNOB-TEMP.CONTROL (D)KNOPF														
	759237	.	.	B	B	B	S	S	S			2				
	[04]	(E)COVER-BLANK (D)DECKEL														
	159264	.	.	B	B	B	S	S	S	&C46		1				
	[05]	(E)KNOB-RECIRCULATION (D)KNOPF														
	759203	.	.	B	B	B	S	S	S			1				
	[06]	(E)BUTTON A (D)KNOPF														
	759198	.	.	B	B	B	O	O	O	&C59/C60		1				
	[07]	(E)BUTTON-DEFROSTER (D)KNOPF														
	759199	.	.	B	B	B	S	S	S			1				
	[08]	(E)BALL-DETENT (D)KUGEL														
	159102	.	.	B	B	B	S	S	S			1				
	[09]	(E)SPRING-BALL (D)FEDERUNG														
	159245	.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

8350 AIR CONDITIONER CONTROL SWITCH




KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[10]		(E)KNOB-BLOWER CONTROL *(D)KNOPF*									*(F)BOUTON* *(S)PERILLA*					
	759192	.	.	B	B	B	S	S	S			1				
[11]		(E)GUIDE-LIGHT *(D)FÜHRING*									*(F)GUIDE* *(S)GUIA*					
	159241	.	.	B	B	B	S	S	S			1				
[12]		(E)BODY A-MAIN *(D)KAROSSERIE*									*(F)CORPS* *(S)CARROCERIA*					
	759190	.	.	B	B	B	S	S	S			1				
[13]		(E)BULB A *(D)BIRNE*									*(F)AMPOULE* *(S)BOMBILLA*					
	759191	.	.	B	B	B	S	S	S			2				
[14]		(E)COVER-FRONT *(D)DECKEL*									*(F)CARTER* *(S)CUBIERTA*					
	159239	.	.	B	B	B	S	S	S			1				
[15]		(E)E-WASHER *(D)DICHTUNGSRING*									*(F)RONDELLE* *(S)ARANDELA*					
	159114	.	.	B	B	B	S	S	S			1				
[16]		(E)SPRING-CONICAL *(D)FEDERUNG*									*(F)RESSORT* *(S)RESORTE*					
	159105	.	.	B	B	B	S	S	S			1				
[17]		(E)CONTACTOR-MOVING *(D)KONTAKTSTÜCK*									*(F)CONTACTEUR* *(S)CONTACTO*					
	159106	.	.	B	B	B	S	S	S			1				
[18]		(E)BOARD A-CIRCUIT *(D)PALTINE*									*(F)PLATINE* *(S)TABLA DE CIRCUITO*					
	759194	.	.	B	B	B	S	S	S			1				
[19]		(E)SCREW *(D)SCHRAUBE*									*(F)VIS* *(S)TORNILLO*					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

8350 AIR CONDITIONER CONTROL SWITCH

6J09




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	155447	.	.	B	B	B	S	S	S			1				
	[20]	(E)COVER-REAR *(D)DECKEL*										*(F)CARTER* *(S)CUBIERTA*				
	159233	.	.	B	B	B	S	S	S			1				
	[21]	(E)SCREW-MOUNT'G *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
	159230	.	.	B	B	B	S	S	S			4				
	[22]	(E)SPRING-BALL *(D)FEDERUNG*										*(F)RESSORT* *(S)RESORTE*				
	159245	.	.	B	B	B	S	S	S			2				
	[23]	(E)BALL-DETENT *(D)KUGEL*										*(F)BOULE* *(S)BOLA*				
	159102	.	.	B	B	B	S	S	S			2				
	[24]	(E)MODE-PINION *(D)MODE,RITZEL*										*(F)PIGNON MODE* *(S)PINON*				
	159246	.	.	B	B	B	S	S	S			1				
	[25]	(E)RACK A- MODE *(D)GESTELL*										*(F)CONTROLE MODE* *(S)REJILLA*				
	759195	.	.	B	B	B	S	S	S			1				
	[26]	(E)PINION-TEMPERATURE *(D)RITZEL*										*(F)PIGNON* *(S)PIÑON*				
	159103	.	.	B	B	B	S	S	S			1				
	[27]	(E)RACK A -TEMPERATURE *(D)GESTELL*										*(F)CONTROLE TEMPERATURE* *(S)REJILLA TEMPERATURA*				
	759238	.	.	B	B	B	S	S	S			1				
	[28]	(E)SCREW *(D)SCHRAUBE*										*(F)VIS* *(S)TORNILLO*				
	155424	.	.	B	B	B	S	S	S			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

8350 AIR CONDITIONER CONTROL SWITCH

6K09




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[29]	(E)CABLE A-MODE (D)KABEL									(F)CABLE (S)CABLE					
	759205	.	.	B	B	B	S	S	S			1				
	[30]	(E)CABLE A-TEMPERATURE (D)KABEL									(F)CABLE (S)CABLE					
	759204	.	.	B	B	B	S	S	S			1				
	[31]	(E)CABLE A-RECIRCULATION (D)KABEL									(F)CABLE (S)CABLE					
	759206	.	.	B	B	B	S	S	S			1				
	[32]	(E)SWITCH A -RECIRCULATION (D)SCHALTER									(F)COMMUTATEUR (S)INTERRUPTOR					
	759202	.	.	B	B	B	S	S	S			1				
	[33]	(E)SWITCH A-PUSH (D)SCHALTER									(F)COMMUTATEUR (S)INTERRUPTOR					
	759254	.	.	B	B	B	S	S	S	&C46		1				
	759196A	.	.	B	B	B	O	O	O	&C59/C60		1				
	[34]	(E)GRIP- WIRE (D)GRIFF									(F)POIGNEE (S)ASIDERO					
	159261	.	.	B	B	B	S	S	S			1				
	[35]	(E)SCREW-TAPPING (D)SCHRAUBE									(F)VIS (S)TORNILLO					
	03110-48165	.	.	B	B	B	S	S	S			2				
	[36]	(E)PLATE-SYMBOL (D)PLATTE									(F)PLAQUE (S)PLACA					
	159238	.	.	B	B	B	S	S	S			1				
	[37]	(E)PLATE-RECIRCULAT. SYMBOL (D)PLATTE									(F)PLAQUE (S)PLACA					
	159240	.	.	B	B	B	S	S	S			1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK


9 O.V.M & ACCESSORY

9110 TOOL
9120 OIL & PAINT
9210 REAR SPOILER
9250 SUN ROOF
9260 SUN ROOF MOUNT




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
											(E)BAG-TOOL (D)WERKZEUGKASTEN						
[01]	09811-00001	.	.	B	B	B	S	S	S		(F)TROUSSE A OUTILS (S)CAJA-DEPOSITO		1				
[02]	09816-19002	.	.	B	B	B	S	S	S		(E)WRENCH-WHEEL NUT (D)SCHRAUBENSCHLÜßEL,RAD		1				
[03]	09814-12001	.	.	B	B	B	S	S	S		(E)DRIVER-SCREW (D)SCHRAUBENZIEHER		1				
[04]	90278524	.	.	B	B	B	S	S	S		(E)JACK A (D)STECKER		1				
[05]	96219681	.	.	B	B	B	S	S	S		(E)BOLT A-JACK WING (D)SCHRAUBE		1				
[06]	09813-08001	.	.	B	B	B	S	S	S		(E)SPANNER (D)SCHRAUBENSCHLÜßEL		1				
[07]	09812-42001	.	.	B	B	B	S	S	S		(E)PLIER (D)ZANGE		1		970328		

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)OIL-ENGINE (D)ÖL,MOTOR										(F)HUILE-MOTEUR (S)ACEITE-MOTOR				
	M-8045-1L	Y	.	B	B	B	S	S	S	-XCA		1			1L,10W30,SJ	
	M-8045-4L	Y	.	B	B	B	S	S	S	-XCA		1			4L,10W30,SJ	
	M-8044-1L	Y	.	B	B	B	A	A	A	&XCA		1			1L,5W30,SJ	
	M-8044-4L	Y	.	B	B	B	A	A	A	&XCA		1			4L,5W30,SJ	
	M-8044-1L	6	.	B	B	B	.	.	O	-XHA		1			1L,5W30,SJ	
	M-8044-4L	6	.	B	B	B	.	.	O	-XHA		1			4L,5W30,SJ	
	M-8045-1L	6	.	B	B	B	.	.	A	&XHA		1			1L,10W30,SJ	
	M-8045-4L	6	.	B	B	B	.	.	A	&XHA		1			4L,10W30,SJ	
	M-8045-1L	6	.	B	B	B	.	.	A	&KL9		1			1L,10W30,SJ	
	M-8045-4L	6	.	B	B	B	.	.	A	&KL9		1			4L,10W30,SJ	
	[02]	(E)OIL-MANUAL TRANSAXLE (D)ÖL,MANUELLE GANGSCHALTUNG										(F)HUILE-TRANS MANUELLE (S)ACEITE-EJE TRANSVERSAL				
	M-8027-1L	.	.	B	B	B	S	S	S			1			1L	
	[03]	(E)OIL-AUTOMATIC TRANSAXLE (D)ÖL,GANGSCHALTUNG										(F)HUILE-TRANS AUTOMATIQUE (S)ACEITE-EJE TRANSVERSAL				
	M-8039-1L	.	.	B	B	B	S	S	S			1			1L	
	M-8039-4L	.	.	B	B	B	S	S	S			1			4L	
	[04]	(E)OIL-POWER STEERING (D)ÖL,KRAFTLENKUNG										(F)HUILE-DIRECTION ASSISTEE (S)ACEITE-SERVODIRECCION				
	M-8036-1L	.	.	B	B	B	S	S	S			1			1L	
	[05]	(E)FLUID-BRAKE (D)FLÜSSIGKEIT,BREMSE										(F)LIQUIDE-FREIN (S)FLUIDO-FRENOS				
	05KGM4653M	.	.	B	B	B	S	S	S			1			0.5L	
	1KGM4653M	.	.	B	B	B	S	S	S			1			1L	

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[06]	(E)FLUID-WINDOW CLEANER (D)FLÜSSIGKEIT									(F)LIQUIDE-LAVE-GLACE (S)FLUIDO-LIMPIA PARABRISAS					
	M-8206-1L	.	.	B	B	B	S	S	S	-XCA		1				
	M-8209-1L	.	.	B	B	B	A	A	A	&XCA		1				
	[07]	(E)GREASE (D)SCHMIERMITTEL									(F)GRAISSE (S)GRASA					
	B0400625A	.	.	B	B	B	S	S	S			1			0.5 KG	
	[08]	(E)GREASE (D)SCHMIERMITTEL									(F)GRAISSE (S)GRASA					
	B0400625B	.	.	B	B	B	S	S	S			1			3 KG	
	[09]	(E)ANTIFREEZE (D)GEFRIERSCHUTZMITTEL									(F)ANTIGEL (S)ANTICONGELANTE					
	B0400240-4	.	.	B	B	B	S	S	S			1			4L	
	[10]	(E)PAINT-TOUTCH UP (D)LACK,NACHLACKIEREN									(F)PEINTURE-RETOUCHES (S)PINTURA-RETOQUE					
	A/L-11U-0.5L	.	.	B	B	B	S	S	S			1			0.5L	
	A/L-21U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-27U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-42U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-43U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-73L-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-74U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-81U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-83L-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	A/L-92U-0.5L	.	.	B	B	B	O	O	O			1			0.5L	
	[11]	(E)PAINT (D)LACK									(F)PEINTURE (S)PINTURA					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	U/T-11U-4L	.	.	B	B	B	S	S	S			1			4L	
	B/C-21U-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-27U-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-42U-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-43U-4L	.	.	B	B	B	O	O	O			1			4L	
	U/T-73L-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-74U-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-81U-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-83L-4L	.	.	B	B	B	O	O	O			1			4L	
	B/C-92U-4L	.	.	B	B	B	O	O	O			1			4L	
[12]		(E)CLEAR -VARNISH *(D)LACK*										*(F)PEINTURE* *(S)PINTURA*				
	U/T-CLR-4L	.	.	B	B	B	S	S	S			1			4L	
[13]		(E)GASKET *(D)DICHTUNG*										*(F)JOINT* *(S)JUNTA*				
	S9120016	.	.	B	B	B	S	S	S			1			50ml	


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

9210 REAR SPOILER




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]	96303489	(E)SPOILER A-REAR (D)SPOILER		.	.	.	B	B	O	.	O	(F)SPOILER (S)SPOILER 1			INCL #2	
[02]	09308-05001	(E)GROMMET (D)ÖSE		.	.	.	B	B	O	.	O	(F)VIROLE (S)AISLANTE 4				
[04]	09159-06101	(E)NUT (D)MUTTER		.	.	.	B	B	O	.	O	(F)ECROU (S)TUERCA 4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK




KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
[01]										(E)ROOF A-SUN *(D)DACH,SONNEN*					*(F)TOIT-OUVRANT* *(S)TECHO-SOLAR*	
96240744		.	.	B	B	B	O	O	O			1				
[02]										(E)FRAME A *(D)RAHMEN*					*(F)CADRE* *(S)ARMADURA*	
44044480		.	.	B	B	B	O	O	O			1				
[03]										(E)PANEL A-GLASS *(D)VERKLEIDUNG,GLAS*					*(F)PANNEAU-GLACE* *(S)PANEL-VIDRIO*	
44044460		.	.	B	B	B	O	O	O			1				
[04]										(E)DEFLECTOR-WIND *(D)WINDSCHUTZ-FLÜGEL*					*(F)DEFLECTEUR-VENT* *(S)DEFLECTOR-VIENTO*	
44044450		.	.	B	B	B	O	O	O			1				
[05]										(E)MECHANISM *(D)MECHANISMUS*					*(F)MECANISME* *(S)MECANISMO*	
44044150		.	.	B	B	B	O	O	O		LH	1				
44044140		.	.	B	B	B	O	O	O		RH	1				
[06]										(E)CHANNEL-DRAIN *(D)RILLE*					*(F)RAINURE* *(S)CANAL*	
40109330		.	.	B	B	B	O	O	O			1				
[07]										(E)SCREW *(D)SCHRAUBE*					*(F)VIS* *(S)TORNILLO*	
26158906		.	.	B	B	B	O	O	O			2				
[08]										(E)SPRING-SLIDE BLOCK *(D)FEDERUNG*					*(F)RESSORT* *(S)RESORTE*	
40329190		.	.	B	B	B	O	O	O			4				
[09]										(E)BLOCK-SLIDE *(D)BLOCK*					*(F)BLOC* *(S)BLOQUE*	
42309630		.	.	B	B	B	O	O	O			4				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC	M = MANUAL T/A	4 N = 4 DOOR NOTCHBACK
6 = 1.6DOHC	A = AUTOMATIC T/A	3 H = 3 DOOR HATCHBACK
. = COMMON	. = COMMON	5 H = 5 DOOR HATCHBACK




KEY NO.	PART NAME															
ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[10]	(E)SEAL-GLASS PANEL (D)DICHTUNG										(F)JOINT (S)SELLO				
	42309750	.	.	B	B	B	O	O	O			1				
	[11]	(E)COVER-SIDE,INNER (D)DECKEL								1		(F)CARTER (S)CUBIERTA				
	42409250	.	.	B	B	B	O	O	O			LH 1				
	42409240	.	.	B	B	B	O	O	O			RH 1				
	[12]	(E)COVER-SIDE,OUTER (D)DECKEL										(F)CARTER (S)CUBIERTA				
	42409230	.	.	B	B	B	O	O	O			LH 1				
	42409220	.	.	B	B	B	O	O	O			RH 1				
	[13]	(E)MOTER & DRIVE GEAR A (D)MOTOR-SATZ										(F)ENSEMBLE MOTEUR (S)JUEGO DE MOTOR				
	44249122	.	.	B	B	B	O	O	O			1				
	[14]	(E)SCREW (D)SCHRAUBE										(F)VIS (S)TORNILLO				
	22715316	.	.	B	B	B	O	O	O			3				
	[15]	(E)BOX A-RELAY (D)RELAISKASTEN										(F)BOITE-RELAI (S)CAJA-RELEVADOR				
	44249340	.	.	B	B	B	O	O	O			1				
	[16]	(E)TUBE-CABLE GUIDE (D)ROHRLEITUNG										(F)TUYAU OU TUBE (S)TUBO				
	42009662	.	.	B	B	B	O	O	O			2				
	[17]	(E)TUBE-DRIVE (D)ROHRLEITUNG										(F)TUYAU OU TUBE (S)TUBO				
	40419390	.	.	B	B	B	O	O	O			LH 1				
	40419380	.	.	B	B	B	O	O	O			RH 1				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	T/A	BODY 4N	BODY 3H	BODY 5H	LEVEL S	LEVEL SE	LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE	PART NAME
[19]																	(E)PLUG-GUIDE,RR *(D)STÖPSEL* *(F)BOUCHON* *(S)TAPON*
42109830		.	.	B	B	B	O	O	O		LH	1					
42109840		.	.	B	B	B	O	O	O		RH	1					
[20]																	(E)ARRETOIR OU BOUCHON *(D)TAPON* *(F)STÖPSEL* *(S)TAPON*
42309710		.	.	B	B	B	O	O	O			2					
[21]																	(E)DRAINAGE PIECE-RR *(D)DRANÄGE HINTERE* *(F)DRAINAGE-ARRIERE* *(S)DRENAJE-TRASERO*
42409670		.	.	B	B	B	O	O	O		LH	1					
42409680		.	.	B	B	B	O	O	O		RH	1					
[22]																	(E)BRACKET *(D)TRÄGER* *(F)SUPPORT* *(S)SOPORTE*
41109880		.	.	B	B	B	O	O	O			1					
[23]																	(E)SUNSHADE A *(D)SONNENBLENDE* *(F)PARE-SOLEIL* *(S)PARASOL*
44044470		.	.	B	B	B	O	O	O			1					
[24]																	(E)BOLT *(D)SCHRAUBE* *(F)BOULON* *(S)PERNO*
40429881		.	.	B	B	B	O	O	O			4					
[25]																	(E)FINISHER-HEADLINER *(D)FERTIGGESENK* *(F)FINITION CARNITURE* *(S)COBERTOR*
96245679		.	.	B	B	B	O	O	O			1					


ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	PART NAME L/R	PART NAME QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	[01]	(E)TUBE-DRAIN (D)ROHRLEITUNG									(F)TUYAU OU TUBE (S)TUBO					
	96240751	.	.	B	B	B	O	O	O			2				
	[02]	(E)TUBE-DRAIN (D)ROHRLEITUNG									(F)TUYAU OU TUBE (S)TUBO					
	96240752	.	.	B	.	.	O	O	O			2				
	96240753	.	.	.	B	B	O	.	O		LH	1				
	96252576	.	.	.	B	B	O	.	O		RH	1				
	[03]	(E)BRACKET A-SUN ROOF (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96240728	.	.	B	.	B	O	O	O		LH	1				
	96240732	.	.	.	B	.	O	.	O		LH	1				
	[04]	(E)BRACKET A-SUN ROOF (D)TRÄGER									(F)SUPPORT (S)SOPORTE					
	96240729	.	.	B	.	B	O	O	O		RH	1				
	96240733	.	.	.	B	.	O	.	O		RH	1				
	[05]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	02717-06163	.	.	B	B	B	O	O	O			9		970403		
Y	09118-06012	.	.	B	B	B	O	O	O			9		970403		
	[06]	(E)BOLT (D)SCHRAUBE									(F)BOULON (S)PERNO					
	02717-06163	.	.	B	B	B	O	O	O			4				
	[07]	(E)GROMMET-DRAIN TUBE,FRONT (D)ÖSE									(F)VIROLE (S)AISLANTE					
	96245671	.	.	B	B	B	O	O	O			2				
	[08]	(E)GROMMET-DRAIN TUBE (D)ÖSE									(F)VIROLE (S)AISLANTE					

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK

9260 SUN ROOF MOUNT



KEY NO. ITC	PART NO	MODEL ENG	MODEL T/A	MODEL BODY 4N	MODEL BODY 3H	MODEL BODY 5H	MODEL LEVEL S	MODEL LEVEL SE	MODEL LEVEL SX	OPTION	L/R	QTY	EFFECTIVE DATE FROM	EFFECTIVE DATE TO	REMARKS	P/CODE
	96239613	.	.	B	B	B	O	O	O			2				

ENG(ENGINE)	T/A(TRANSAXLE)	BODY TYPE
Y = 1.5SOHC 6 = 1.6DOHC . = COMMON	M = MANUAL T/A A = AUTOMATIC T/A . = COMMON	4 N = 4 DOOR NOTCHBACK 3 H = 3 DOOR HATCHBACK 5 H = 5 DOOR HATCHBACK