



Mitsubishi F4A21, F4A22 & F4A23

"N" Range – Neutral




Mitsubishi F4A21, F4A22 & F4A23

"P" Range – Park



Mitsubishi F4A21, F4A22 & F4A23

"D" Range – Stopped At Idle




PRESSURES

Red	Line	Yellow	Torque Converter and Lubrication	Blue	Reducing
Pink	Moderated Line	Green	Damper Clutch Control Solenoid Valve	Grey	Pump Suction
Orange	Damper Clutch	Cyan	Control		

Mitsubishi F4A21, F4A22 & F4A23


"D" Range – 1st Gear



PRESSURES


Line	Torque Converter and Lubrication	Reducing
Moderated Line	Damper Clutch Control Solenoid Valve	Pump Suction
Damper Clutch	Control	

"D" Range – 2nd Gear




Mitsubishi F4A21, F4A22 & F4A23

"D" Range – 3rd Gear




Mitsubishi F4A21, F4A22 & F4A23



Mitsubishi F4A21, F4A22 & F4A23

"L" Range – 1st Gear



"R" Range – Reverse

