


PARTS LIST

SQ125

CERRADURA BAUL
DESCR1 125
SASN-30010.



DAELIM MOTOR CO.,LTD.

INDEX

INTRODUCTION FOR USE OF PARTS LIST

ENGINE GROUP

FRAME GROUP

PART NUMBER INDEX

PART NAME INDEX

Introduction for use of parts list

THIS PARTS LIST GIVES YOU ALL INFORMATION ABOUT SQ125 PARTS TO BE REPLACED FOR ANY PURPOSE. WHEN YOU WANT TO ORDER ANY PARTS, YOU CAN REFER TO PART NO., PART NAME, ETC., WHICH SHOULD BE REQUIRED FOR US TO SUPPLY YOU EXACT PARTS.

I. How to order parts

1. Information required

Please specify parts numbers and parts names when ordering replacement parts as the shapes and serial numbers of the parts may have changed. Please check for availability prior to ordering parts because not all the required parts can be supplied.

"-RB00", "-RC00", "-RE00", "-RJ00" AND "-EU" at the end of parts No. mean they are parts for export spec. only

2. Revisions

When modifications or additions to this parts list are made, a revised edition will be issued at an appropriate time, with successively progressing revision numbers. When you order parts, refer to the latest parts list. To check whether a parts list revision has been issued, please contact your DAELIM distributor.

II. How to read this parts list

1. Make-up of parts number

- * No. FOR FUNCTIONAL GROUP — 00000 — 000 — 0000 — 00
- * MODEL No. _____
- * MODIFICATION _____
- * SUPPLY MARKING (Color, maker, etc.,) _____

2. Color code

The last of parts number represents the right color painted for these parts. On the placement of parts order you should name the color additionally after color code and parts name.

Ex) 64301-SA4-0000-TR COVER, FR. (O/RED)

3. Abbreviations

The following abbreviations are used in this parts list.

ASS'Y	— — — —	Assamby	T(22T)	— — — —	Tooth(22Teeth)
COMP.	— — — —	Complete	L(100L)	— — — —	Link(100Links)
RH.	— — — —	Right	A.C	— — — —	Alternating current
LH.	— — — —	Left	D.C	— — — —	Direct Current
STD	— — — —	Standard	IN.	— — — —	Inlet
mm	— — — —	Millimeter	EX.	— — — —	Exhaust
g	— — — —	Gram	FR.	— — — —	Front
A	— — — —	Ampere	RR.	— — — —	Rear
V	— — — —	Volt	HEX.	— — — —	Hexagonal
W	— — — —	Watt			

4. Dimensions

All dimensions are given in millimeters (mm) except in the case of steel balls, tires and tire tubes.

Parts	Example	Interpretation	
Bolt (Screw)	6 x 12	6mm diameter,	12mm length
Pin	8 x 14	8mm diameter,	14mm length
O-Ring	9.5 x 1.6	9.5mm inside diameter,	1.6mm thickness
Oil Seal	14x25x5	14mm inside diameter,	25mm outside diameter, 5mm thickness
Tube	5x130	5mm inside diameter,	130mm length

5. Assemblies

Sections framed with broken lines in the exploded view drawings are available as complete assembled (their individual parts can also be obtained)

6. Required Quantity

The number in the Do column represents the quantity of the part needed for domestic specification and the number in the Ex column represents the quantity of the part needed for export specification.

7. A/S Part

The part with "Y" in the A/S column can be supplied as A/S part and the part with "N" in the A/S column can't.

8. Exchangeability

"Y" in the Exch column means the part can be replaced with new part and "N" means the part can't be replaced with new part.

9. Start date and End date

Start date shows the date of initial application of the part and "blank" means the part has been applied from the time of initial production. End date shows the date of end time of part's application and "blank" means the part is still applying.


10. Model and related serial number

MODEL	SERIAL No. of ENGINE	SERIAL No. of FRAME	REMARK
SQ125	SQ125E3000001~	KMYSA4BLS4C000001~	EUR02

11. Illustration

The part illustration in the part list is only used help explanation and may have minor difference with the actual appearance of the part.

12. Location of stamped serial number



III. How to use the flat rate time (F.R.T)

This F.R.T (Flat Rate Time) is used to determine the standard labor time allowed for replacement of parts covered by the warranty during the period the warranty is in effect. The F.R.T for those parts which are not listed here should be determined from the operation closely related to the replacement of that part.

1. The F.R.T is based on the following servicing conditions

- A liberal allowance is added to the net servicing time
- Standard times specified are based on the condition that the necessary servicing tools listed in the service manual (motorcycle) which describes the DAELIM service policy are available close at hand and the work performed by a mechanic with normal skill.
- Time required for inspection and operational test following the servicing is included in the F.R.T

2. Method of computing

The job times are listed in tenth of an hour to simplify computation.

Ex) 0.3 = 18 minutes

5.6 = 5 hours and 36 minutes

CONVERSION CHART			
HOURS	MINUTES	HOURS	MINUTES
0.1	6	0.6	36
0.2	12	0.7	42
0.3	18	0.8	48
0.4	24	0.9	54
0.5	30	1.0	60

3. Computing the F.R.T

When several jobs are performed at the same time, make the calculation in the following manner.

a. Jobs of non-duplicated nature

The F.R.T for the job is obtained by totalling the F.R.T for each part replaced.

Ex) Replacement of cylinder and oil pump body

SERVICE ITEM	F.R.T
Cylinder	*3.0
Oil pump body	0.9

The F.R.T for job is : $3.0 + 0.9 = 3.9$

b. Jobs of duplicated nature

Take the F.R.T for the last part to be replaced

Ex) Replacement of piston and cylinder head gasket

SERVICE ITEM	F.R.T
Cylinder head gasket	*3.0
Piston	*3.0

The F.R.T for job is = 3.0

c. Jobs of partially related nature

Total up the F.R.T for all of the parts replaced and then subtract the F.R.T for the duplicated operation

Ex) Replacement of oil pump and starter oneway clutch

SERVICE ITEM	F.R.T
Oil pump	0.9
Starter oneway clutch	1.1
Rh crank case cover disassembly	0.9

The F.R.T for job is : $(0.9 + 1.1) - 0.9 = 1.1$

Crank case disassembly is the duplicated operations.

The F.R.T shown with(*) includes engine removal time and installation time

4. Operations other than replacing parts

1) Removal and installation

No.	SERVICE ITEM	F.R.T
1	Engine	1.7
2	Cylinder head	2.7
3	Carburetor	0.5

2) Adjustment, Measurement and cleaning.

① Engine

No.	SERVICE ITEM	F.R.T
1	Engine oil inspection	0.1
2	Oil filter screen cleaning	0.2
3	Compression pressure measurement	0.1
4	Spark plug adjustment and cleaning	0.1
5	Ignition timing inspection	0.2
6	Valve clearance adjustment	0.5
7	Throttle operation adjustment	0.1
8	Carburetor idle adjustment	0.1
9	Carburetor float level measurement	0.5
10	Clutch adjustment	0.1

② Frame

No.	SERVICE ITEM	F.R.T
1	Front brake adjustment	0.3
2	Rear brake adjustment	0.3
3	Brake operation test	0.1
4	Headlight aimings	0.3

3) Overhaul disassembly, inspection, cleaning and assembly

No.	SERVICE ITEM	F.R.T
1	Carburetor	0.7

엔진 그룹 ENGINE GROUP

E-1 FAN COVER / SHROUD 11	E-2 CYLINDER HEAD COVER 12	E-3 CYLINDER HEAD / VALVE 13
E-4 CAM SHAFT 15	E-5 CAM CHAIN / TENSIONER 16	E-6 CYLINDER 17

엔진 그룹 ENGINE GROUP


E-10 STARTER MOTOR 21	E-11 LEFT CRANK CASE COVER 22	E-12 DRIVE FACE 23
E-13 DRIVEN FACE 24	E-14 TRANSMISSION 26	E-15 RADIATOR / RADIATOR HOSE 27
E-16 RIGHT CRANK CASE 28	E-17 LEFT CRANK CASE 29	E-18 CRANK SHAFT / PISTON 30

엔진 그룹 ENGINE GROUP

E-19

CARBURETOR










31



후레임 그룹 FRAMEGROUP

F-1 HEAD LIGHT 33	F-2 SPEEDOMETER 34	F-3 HANDLE GRIP / SWITCH / CABLE 35
F-4 MASTER CYLINDER 36	F-5 STEERING HANDLE / HANDLE COVER 38	F-6 FRONT COVER / INNER COVER 40
F-7 FRONT FENDER 42	F-8 STEERING STEM 43	F-9 FRONT FORK 44

후레임 그룹 FRAMEGROUP


F-10 BRAKE CALIPER 45	F-11 FRONT WHEEL 47	F-12 REAR WHEEL 48
		
F-13 SEAT 49	F-14 FLOOR SIDE COVER / UNDER COVER 50	F-15 FUEL TANK 51
		
F-16 BATTERY 53	F-17 LUGGAGE BOX 54	F-18 CENTER COVER / BODY COVER 56
		

후레임 그룹 FRAMEGROUP

F-19 AIR CLEANER 59	F-20 EXHAUST MUFFLER 61	F-21 STAND 62
F-22 REAR CUSHION 63	F-23 FRONT WINKER 64	F-24 REAR COMBINATION LIGHT / REAR FENDER 65
F-25 WIRE HARNESS / IGNITION COIL 67	F-26 FRAME BODY 69	F-27 TOOL 71

E-01

FAN COVER / SHROUD




FR.

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
SHROUD COMP., RH. (ADD 0.2 FOR EACH)	0.5	1	19615-SA2-0000	COVER ASS'Y, FAN	1	Y	20040817		KMYSA4BLS4C000001	
		2	19620-SA4-0000	SHROUD COMP., RH.	1	Y	20040817		KMYSA4BLS4C000001	
		3	19625-SA4-0000	SEAL, SHROUD	1	Y	20040817		KMYSA4BLS4C000001	
COVER ASS'Y, FAN	0.2	4	19630-SA4-0000	SHROUD COMP., LH	1	Y	20040817		KMYSA4BLS4C000001	
		5	19633-SA0-0000	GROMMET, SHROUD B	1	Y	20040817		KMYSA4BLS4C000001	
		6	90001-SA1-0000	SCREW, WASHER 5x12	3	Y	20040817		KMYSA4BLS4C000001	
		7	90108-BA5-9001	SCREW 6x18	1	Y	20040817		KMYSA4BLS4C000001	
		8	S3903-34380	SCREW, TAPPING 4x12	2	N	20040817		KMYSA4BLS4C000001	
		9	S3904-35380	SCREW, TAPPING 5x16	4	Y	20040817		KMYSA4BLS4C000001	
		10	S6001-06020-07	BOLT, FLANGE SH.6x20	4	Y	20040817		KMYSA4BLS4C000001	

E-02


CYLINDER HEAD COVER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
COVER COMP., CYLINDER HEAD	0.4	1	12300-SA2-RB00	COVER ASS'Y, CYLINDER HEAD	1	Y		20040817		KMYSA4BLS4C000001	
		2	12301-SA2-RB02	COVER, CYLINDER HEAD	1	N		20040817		KMYSA4BLS4C000001	
GASKET, CYLINDER HEAD COVER	0.4	3	12313-SA1-0000	GASKET, CYLINDER HEAD COVER	1	Y		20040817		KMYSA4BLS4C000001	
		4	12330-SA2-RB02	COVER COMP., CYLINDER HEAD SIDE	1	Y		20040817		KMYSA4BLS4C000001	
		5	12391-SA2-RB01	GASKET, CYLINDER HEAD SIDE COVER	1	Y		20040817		KMYSA4BLS4C000001	
		6	12392-SA2-RB01	ELEMENT A, SIDE COVER	1	Y		20040817		KMYSA4BLS4C000001	
		7	12393-SA2-RB01	ELEMENT B, SIDE COVER	1	Y		20040817		KMYSA4BLS4C000001	
		8	15650-SA1-0000	CAP ASS'Y, OIL FILLER	1	Y		20040817		KMYSA4BLS4C000001	
		9	9000A-8E5-7501	BOLT ASS'Y, SPECIAL 6x28	4	Y		20040817		KMYSA4BLS4C000001	
		10	S6001-06020-00	BOLT, FLANGE SH.6x20	4	Y		20040817		KMYSA4BLS4C000001	

E-03


CYLINDER HEAD / VALVE



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
HEAD COMP., CYLINDER	*3.5	1	1220A-SA4-0000	HEAD ASS'Y, CYLINDER	1	Y		20040817		KMYSA4BLS4C000001	
		2	1220A-SA4-0000	HEAD COMP., CYLINDER	1	N		20040817		KMYSA4BLS4C000001	
GASKET, CYLINDER HEAD	*3.0	3	12209-BA6-0050	SEAL, VALVE STEM	4	Y		20040817		KMYSA4BLS4C000001	
		4	12251-SA1-0000	GASKET, CYLINDER HEAD	1	Y		20040817		KMYSA4BLS4C000001	
BOLT, STUD 6x20 (ADD 0.1 FOR EACH)		5	14291-SA2-RZ00	GASKET, SAI PIPE	2	Y		20040817		KMYSA4BLS4C000001	
		6	14320-SA2-RZ00	PIPE COMP., SAI	1	Y		20040817		KMYSA4BLS4C000001	
INSULATOR ASS'Y, CARBURETOR	0.5	7	14711-SA1-0000	VALVE, INLET - <i>ADMISSION</i>	2	Y		20040817		KMYSA4BLS4C000001	
		8	14721-SA1-0000	VALVE, EXHAUST - <i>EXHAUST</i>	2	Y		20040817		KMYSA4BLS4C000001	
PLUG, SPARK C8EH-9	0.1	9	14751-SA1-0100	SPRING, VALVE	4	Y		20040817		KMYSA4BLS4C000001	
VALVE	*3.2	10	14771-BA6-9601	RETAINER, VALVE SPRING	4	Y		20040817		KMYSA4BLS4C000001	
(ADD 0.2 FOR EACH)		11	14775-SA1-0100	SEAT, VALVE SPRING	4	Y		20040817		KMYSA4BLS4C000001	
		12	14781-BA6-0000	COTTER, VALVE	8	Y		20040817		KMYSA4BLS4C000001	
SPRING, VALVE	*3.0	13	1621A-SA4-RZ00	INSULATOR ASS'Y, CARBURETOR	1	Y		20040817		KMYSA4BLS4C000001	
(ADD 0.1 FOR EACH)		14	1621Q-SA4-RZ00	INSULATOR COMP., CARBURETOR	1	Y		20040817		KMYSA4BLS4C000001	
		15	17256-SA4-0000	BAND 47, CARBURETOR INSULATOR	1	Y		20040817		KMYSA4BLS4C000001	
		16	91303-SA1-0001	O-RING 29.5x3	1	Y		20040817		KMYSA4BLS4C000001	
		17	S2900-06020-0B	BOLT, STUD 6x20	2	Y		20040817		KMYSA4BLS4C000001	
		18	S4301-10160	PIN, DOWEL 10x16	2	Y		20040817		KMYSA4BLS4C000001	
		19	S6001-06014-00	BOLT, FLANGE SH.6x14	2	Y		20040817		KMYSA4BLS4C000001	
		20	S6001-06018-00	BOLT, FLANGE SH.6x18	2	Y		20040817		KMYSA4BLS4C000001	

E-03


CYLINDER HEAD / VALVE



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		21	S6001-06032-00	BOLT, FLANGE SH.6x32	2	Y		20040817		KMYSA4BLS4C000001	
		22	S6001-06145-00	BOLT, FLANGE SH.6x145	2	Y		20040817		KMYSA4BLS4C000001	
		23	S8059-58916-00	PLUG, SPARK CRBEH-9	1	Y		20040817		KMYSA4BLS4C000001	

E-04

CAM SHAFT




FR.

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
SHAFT COMP., CAM ARM, VALVE ROCKER (ADD 0.3 FOR EACH)	1.2	1	12211-SA1-0100	HOLDER, CAM SHAFT	1	Y		20040817		KMYSA4BLS4C000001	
		2	14100-SA1-0100	SHAFT COMP., CAM	1	Y		20040817		KMYSA4BLS4C000001	
		3	1443A-SA1-0101	ARM ASS'Y, INLET VALVE ROCKER	1	Y		20040817		KMYSA4BLS4C000001	
		4	14431-SA1-0100	ARM, INLET VALVE ROCKER	1	N		20040817		KMYSA4BLS4C000001	
		5	1444A-SA1-0101	ARM ASS'Y, EXHAUST VALVE ROCKER	1	Y		20040817		KMYSA4BLS4C000001	
HOLDER, CAM SHAFT	1.4	6	14441-SA1-0100	ARM, EXHAUST VALVE ROCKER	1	N		20040817		KMYSA4BLS4C000001	
		7	14451-SA1-0000	SHAFT, INLET ROCKER ARM	1	Y		20040817		KMYSA4BLS4C000001	
		8	14452-SA1-0000	SHAFT, EXHAUST ROCKER ARM	1	Y		20040817		KMYSA4BLS4C000001	
		9	90012-CB2-0004	SCREW, TAPPET ADJUSTING	4	Y		20040817		KMYSA4BLS4C000001	
		10	90206-CB2-0007	NUT, TAPPET ADJUSTING	4	Y		20040817		KMYSA4BLS4C000001	
		11	S4050-08080	NUT, FLANGE 8mm	4	Y		20040817		KMYSA4BLS4C000001	

E-05


CAM CHAIN / TENSIONER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
CHAIN, CAM	3.5	1	14401-SA0-0010-M1	CHAIN, CAM	1	Y	20040817		KMYSA4BLS4C000001	
		2	14500-SA1-0001	TENSIONER, CAM CHAIN	1	Y	20040817		KMYSA4BLS4C000001	
TENSIONER, CAM CHAIN	0.9	3	14520-BA1-0000	LIFTER ASS'Y, TENSIONER	1	Y	20040817		KMYSA4BLS4C000001	
		4	14523-BA7-0000-EU	GASKET, TENSIONER LIFTER	1	Y	20040817		KMYSA4BLS4C000001	
LIFTER ASS'Y, TENSIONER	0.4	5	1453A-SA1-0000	PIVOT ASS'Y, CAM CHAIN TENSIONER	1	Y	20040817		KMYSA4BLS4C000001	
		6	14531-SA1-0001	PIVOT, CAM CHAIN TENSIONER	1	N	20040817		KMYSA4BLS4C000001	
GUIDE, CAM CHAIN	*2.8	7	14550-SA1-0000	GUIDE, CAM CHAIN	1	Y	20040817		KMYSA4BLS4C000001	
		8	90005-BA7-9000	SCREW, PAN 6x6	1	Y	20040817		KMYSA4BLS4C000001	
		9	90091-BA7-0000	BOLT, FLANGE 6x16	2	Y	20040817		KMYSA4BLS4C000001	
		10	91302-SA0-0000	O-RING 15.2x1.5	1	N	20040817		KMYSA4BLS4C000001	
		11	91306-BA6-6900	O-RING 1.5x9.5	1	Y	20040817		KMYSA4BLS4C000001	

E-06


CYLINDER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
CYLINDER COMP.	*3.0	1	12100-SA1-0010	CYLINDER COMP.	1	Y		20040817		KMYSA4BLS4C000001	
		2	12191-SA1-0000-EU	GASKET, CYLINDER	1	Y		20040817		KMYSA4BLS4C000001	
GASKET, CYLINDER	*3.0	3	S4301-10160	PIN, DOWEL 10x16	2	Y		20040817		KMYSA4BLS4C000001	

E-07


RIGHT CRANK CASE COVER



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
COVER COMP., RH. CRANK CASE GASKET, RH. COVER	0.9	1	11330-SA2-RZ00	COVER COMP., RH. CRANK CASE	1	Y		20040817		KMYSA4BLS4C000001	
		2	11394-SA1-0000-EU	GASKET, RH. COVER	1	Y		20040817		KMYSA4BLS4C000001	
		3	14200-SA1-RZ01	VALVE ASS'Y, SAI REED	1	Y		20040817		KMYSA4BLS4C000001	
		4	28117-SA1-0000	PLATE, START DRIVEN GEAR SETTING	1	Y		20040817		KMYSA4BLS4C000001	
		5	32964-SC1-0201	CLAMP, CORD	1	Y		20040817		KMYSA4BLS4C000001	
		6	90701-CB2-0002	PIN, SPECIAL DOWEL 8x14	2	Y		20040817		KMYSA4BLS4C000001	
		7	91201-SA1-0000	SEAL, OIL 20x30x6	1	Y		20040817		KMYSA4BLS4C000001	
		8	S6001-06012-00	BOLT, FLANGE SH.6x12	1	Y		20040817		KMYSA4BLS4C000001	
		9	S6001-06018-00	BOLT, FLANGE SH.6x18	1	Y		20040817		KMYSA4BLS4C000001	
		10	S6001-06022-00	BOLT, FLANGE SH.6x22	6	Y		20040817		KMYSA4BLS4C000001	
		11	S6001-06032-00	BOLT, FLANGE SH.6x32	1	Y		20040817		KMYSA4BLS4C000001	
		12	S6001-06035-00	BOLT, FLANGE SH.6x35	1	Y		20040817		KMYSA4BLS4C000001	
		13	S6001-06045-00	BOLT, FLANGE SH.6x45	1	Y		20040817		KMYSA4BLS4C000001	

E-08


GENERATOR



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
FAN COMP., COOLING	0.5	1	19510-SA1-0000	FAN COMP., COOLING	1	Y		20040817		KMYSA4BLS4C000001	
AC.GENERATOR ASS'Y	0.7	2	31100-SA2-RZ00	AC.GENERATOR ASS'Y	1	Y		20040817		KMYSA4BLS4C000001	
		3	31110-SA2-RZ00	FLYWHEEL COMP.	1	Y		20040817		KMYSA4BLS4C000001	
		4	31120-SA2-0000	STATOR COMP.	1	Y		20040817		KMYSA4BLS4C000001	
STATOR COMP.		5	S3500-SA1-0000-W1	SCREW, SPECIAL PAN 5x32	3	Y		20040817		KMYSA4BLS4C000001	
FLYWHEEL COMP.	0.5	6	S3500-05012-OH	SCREW, PAN 5x12	2	Y		20040817		KMYSA4BLS4C000001	
		7	S4050-12080	NUT, FLANGE 12mm	1	Y		20040817		KMYSA4BLS4C000001	
		8	S6001-06012-00	BOLT, FLANGE SH.6x12	3	Y		20040817		KMYSA4BLS4C000001	

E-09


OIL PUMP



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
BODY, OIL PUMP (INCLUDE RELATIVE PARTS)	0.9	1	15100-SA1-0100	PUMP ASS'Y, OIL	1	Y		20040817		KMYSA4BLS4C000001	
		2	15111-SA1-0000	BODY, OIL PUMP	1	N		20040817		KMYSA4BLS4C000001	
		3	15113-SA1-0000	PLATE, OIL PUMP	1	N		20040817		KMYSA4BLS4C000001	
		4	15131-SA1-0200	GEAR, OIL PUMP DRIVEN	1	Y		20040817		KMYSA4BLS4C000001	
		5	15136-SA1-0000	SHAFT, OIL PUMP	1	Y		20040817		KMYSA4BLS4C000001	
		6	1533A-SA1-0000	ROTOR ASS'Y, OIL PUMP	1	Y		20040817		KMYSA4BLS4C000001	
		7	15331-SA1-0000	ROTOR, OIL PUMP INNER	1	N		20040817		KMYSA4BLS4C000001	
		8	15332-SA1-0000	ROTOR, OIL PUMP OUTER	1	N		20040817		KMYSA4BLS4C000001	
		9	90301-BA6-0032	NUT, U 6mm	1	N		20040817		KMYSA4BLS4C000001	
		10	90417-CB2-0002	WASHER, SHIFT DRUM SIDE	1	N		20040817		KMYSA4BLS4C000001	
		11	S3500-04010-0A	SCREW, PAN 4x10	1	N		20040817		KMYSA4BLS4C000001	
		12	S3600-06032-1A	SCREW, FLAT 6x32	3	Y		20040817		KMYSA4BLS4C000001	
		13	S6220-25118	ROLLER 2.5x11.8	2	Y		20040817		KMYSA4BLS4C000001	

E-10


STARTER MOTOR



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
GEAR COMP., STARTER DRIVEN	0.9	1	28101-SA2-0001	GEAR, STARTER REDUCTION	1	Y	20040817		KMYSA4BLS4C000001	
		2	28102-SA1-0000	SHAFT, REDUCTION GEAR	1	Y	20040817		KMYSA4BLS4C000001	
GEAR, STARTER REDUCTION		3	28110-SA2-0000	GEAR COMP., STARTER DRIVEN	1	Y	20040817		KMYSA4BLS4C000001	
		4	2812A-SA1-0031	ONEWAY CLUTCH SET, STARTER(I.S)	1	Y	20040817		KMYSA4BLS4C000001	
MOTOR UNIT, STARTER	0.4	5	28120-SA1-0131	ONEWAY CLUTCH ASS'Y, START(I.S)	1	N	20040817		KMYSA4BLS4C000001	
		6	28128-SA1-0130	FLANGE, STARTING CLUTCH(I.S)	1	N	20040817		KMYSA4BLS4C000001	
CABLE, STARTER MOTOR	0.5	7	31200-SA4-0000	MOTOR ASS'Y, STARTER	1	Y	20040817		KMYSA4BLS4C000001	
ONEWAY CLUTCH SET, STARTER (INCLUDE RELATIVE PARTS)	1.1	8	31210-SA2-0000	MOTOR UNIT, STARTER	1	Y	20040817		KMYSA4BLS4C000001	
		9	32410-SA4-0000	CABLE, STARTER MOTOR	1	Y	20040817		KMYSA4BLS4C000001	
		10	90201-SA0-0001	NUT, LOCK 22mm	1	Y	20040817		KMYSA4BLS4C000001	
		11	90403-SA0-0100	WASHER, THRUST 22.0x31x2	1	Y	20040817		KMYSA4BLS4C000001	
		12	91104-SA0-0001-M1	BEARING, NEEDLE K28x32x17SV1	1	Y	20040817		KMYSA4BLS4C000001	
		13	91309-BA6-0030	O-RING 24.4x3.1	1	Y	20040817		KMYSA4BLS4C000001	
		14	S4002-06080-0S	NUT, HEX 6mm(Y)	1	Y	20040817		KMYSA4BLS4C000001	
		15	S6001-06055-00	BOLT, FLANGE SH.6x55	2	Y	20040817		KMYSA4BLS4C000001	

E-11

LEFT CRANK CASE COVER




Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
COVER ASS'Y, LH. CRANK CASE	0.5	1	11332-BA7-9000	CLAMPER, BREATHER TUBE	1	Y		20040817		KMYS4BLS4C000001	
		2	11340-SA2-0000	COVER ASS'Y, LH. CRANK CASE	1	Y		20040817		KMYS4BLS4C000001	
GASKET, LH. COVER	0.6	3	11342-SA1-0000	SCREEN, AIR FILTER	1	Y		20040817		KMYS4BLS4C000001	
		4	11396-SA1-0100-EU	GASKET, LH. COVER	1	Y		20040817		KMYS4BLS4C000001	
		5	17208-SA4-0000	STAY COMP., AIR CLEANER A	1	Y		20040817		KMYS4BLS4C000001	
		6	90701-CB2-0002	PIN, SPECIAL DOWEL 8x14	2	Y		20040817		KMYS4BLS4C000001	
		7	S3903-34120	SCREW, TAPPING 4x8	2	Y		20040817		KMYS4BLS4C000001	
		8	S6001-06040-00	BOLT, FLANGE SH.6x40	8	Y		20040817		KMYS4BLS4C000001	
		9	S6001-06045-00	BOLT, FLANGE SH.6x45	2	Y		20040817		KMYS4BLS4C000001	
		10	S6001-06050-00	BOLT, FLANGE SH.6x50	2	Y		20040817		KMYS4BLS4C000001	

E-12


DRIVE FACE

Redillo fino 22121SA1PA00.
 Sine fino - 22132SA10000
 Redillo - 22121SA10102EU



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
FACE, DRIVE	0.5	1	2210A-SA4-0000	FACE ASS'Y, MOVABLE DRIVE	1	Y	20040817		KMYSA4BLS4C000001	
		2	22102-SA1-0000	FACE, DRIVE	1	Y	20040817		KMYSA4BLS4C000001	
FACE COMP., MOVABLE DRIVE	0.9	3	22105-SA4-0000	BOSS, DRIVE FACE	1	N	20040817		KMYSA4BLS4C000001	
		4	22110-SA1-0200	FACE COMP., MOVABLE DRIVE	1	N	20040817		KMYSA4BLS4C000001	
ROLLER COMP., WEIGHT (ONE OR ALL)	0.8	5	22121-SA1-0102-EU 22121SA10100EU	ROLLER COMP., WEIGHT 12g	6	Y	20040817		KMYSA4BLS4C000001	
(INCLUDE RELATIVE PARTS)		6	22131-SA1-0200	PLATE, RAMP	1	Y	20040817		KMYSA4BLS4C000001	
		7	22132-SA1-0200	PIECE, SLIDE	3	Y	20040817		KMYSA4BLS4C000001	
		8	28211-SA1-0001	RATCHET, KICK STARTER	1	Y	20040817		KMYSA4BLS4C000001	
		9	91212-SA1-0000	SEAL, OIL 24x31x3	2	Y	20040817		KMYSA4BLS4C000001	
		10	S4050-12080	NUT, FLANGE 12mm	1	Y	20040817		KMYSA4BLS4C000001	


DRIVEN FACE



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
OUTER, CLUTCH	0.5	1	22100-SA2-0000	OUTER, CLUTCH	1	Y		20040817		KMYSA4BLS4C000001	
		2	2230A-SA2-0000	PLATE UNIT, DRIVE	1	Y		20040817		KMYSA4BLS4C000001	
WEIGHT SET, CLUTCH	0.9	3	22300-SA2-0000	PLATE ASS'Y, DRIVE	1	Y		20040817		KMYSA4BLS4C000001	
(INCLUDE RELATIVE PARTS)		4	22350-SA1-0001	PLATE COMP., DRIVE	1	N		20040817		KMYSA4BLS4C000001	
		5	22401-SA1-0000	SPRING, CLUTCH	3	N		20040817		KMYSA4BLS4C000001	
FACE COMP., MOVABLE DRIVEN											
(INCLUDE RELATIVE PARTS)		6	22530-SA1-0001-EU	WEIGHT, CLUTCH	3	N		20040817		KMYSA4BLS4C000001	
		7	22804-SC1-0000	RUBBER, CLUTCH DAMPER	3	N		20040817		KMYSA4BLS4C000001	
BELT, DRIVE	0.6	8	2301A-SA2-0030	PULLEY SUB ASS'Y, DRIVEN	1	Y		20040817		KMYSA4BLS4C000001	
		9	23010-SA2-0030	PULLEY ASS'Y, DRIVEN	1	Y		20040817		KMYSA4BLS4C000001	
FACE ASS'Y, DRIVEN	0.8	10	23100-SA1-0000	BELT, DRIVE	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6902U		11	23200-SA2-0010	FACE ASS'Y, DRIVEN	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, NEEDLE 22x19x18		12	23210-SA2-0010	FACE COMP., DRIVEN	1	N		20040817		KMYSA4BLS4C000001	
		13	23220-SA2-0000	FACE COMP., MOVABLE DRIVEN	1	N		20040817		KMYSA4BLS4C000001	
SUB ASS'Y, DRIVEN PULLEY	0.5	14	23225-SA2-0000	PIN, ROLLER GUIDE	3	N		20040817		KMYSA4BLS4C000001	
		15	23226-SC1-0000	ROLLER, GUIDE	3	Y		20040817		KMYSA4BLS4C000001	
		16	23233-SA2-0000	SPRING, DRIVEN FACE	1	Y		20040817		KMYSA4BLS4C000001	
		17	23237-SA0-0000	COLLAR, SEAL	1	N		20040817		KMYSA4BLS4C000001	
		18	23238-SA2-0000	COLLAR, SPRING	1	N		20040817		KMYSA4BLS4C000001	
		19	90202-SE5-0001	NUT, SPECIAL 28mm	1	Y		20040817		KMYSA4BLS4C000001	
		20	90442-CB2-9100	WASHER, THRUST 8mm	3	N		20040817		KMYSA4BLS4C000001	

E-13


DRIVEN FACE



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		21	90605-SA0-0001	CIR CLIP 9mm	3	N		20040817		KMYSA4BLS4C000001	
		22	91001-SA1-0000	BEARING, NEEDLE	1	N		20040817		KMYSA4BLS4C000001	
		23	91004-SA0-0020-M1	BEARING, RADIAL BALL 6902U	1	N		20040817		KMYSA4BLS4C000001	
		24	91211-SE5-0130	SEAL, OIL 34x39x3	2	Y		20040817		KMYSA4BLS4C000001	
		25	91351-SE5-1000	O-RING 38.5x2	2	Y		20040817		KMYSA4BLS4C000001	
		26	S4050-12080	NUT, FLANGE 12mm	1	Y		20040817		KMYSA4BLS4C000001	
		27	S4520-28000	CIR CLIP, INTERNAL 28mm	1	N		20040817		KMYSA4BLS4C000001	

E-14


TRANSMISSION



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
COVER, TRANSMISSION	0.8	1	11204-SA1-0000	BUSH, RR.CUSHION UNDER RUBBER	1	Y		20040817		KMYSA4BLS4C000001	
		2	21301-SA1-0100	COVER, TRANSMISSION	1	Y		20040817		KMYSA4BLS4C000001	
SEAL, MISSION COVER	0.8	3	21395-SA1-0000	SEAL, MISSION COVER	1	Y		20040817		KMYSA4BLS4C000001	
		4	21396-SA1-0000	GUIDE RUBBER, MISSION COVER	2	Y		20040817		KMYSA4BLS4C000001	
SEAL, OIL 22x39x7		5	23411-SA1-0100	SHAFT, DRIVE(13T)	1	Y		20040817		KMYSA4BLS4C000001	
SHAFT, DRIVE	0.9	6	23420-SA1-0000-EU	SHAFT COMP., COUNTER(14T)	1	Y		20040817		KMYSA4BLS4C000001	
		7	23430-SA2-0010	SHAFT COMP., FINAL	1	Y		20040817		KMYSA4BLS4C000001	
SHAFT COMP., COUNTER		8	90103-SAO-0000	BOLT, SPECIAL 8mm	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6302		9	90451-BA6-0002	WASHER, THRUST 15mm	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 63/22		10	90474-SAO-0000	WASHER, DRAIN PLUG 8.2x16.2	2	Y		20040817		KMYSA4BLS4C000001	
SHAFT COMP., FINAL	0.9	11	90701-CB2-0002	PIN, SPECIAL DOWEL 8x14	2	Y		20040817		KMYSA4BLS4C000001	
		12	91002-SA1-0000	BEARING, NEEDLE 15x25x12	1	Y		20040817		KMYSA4BLS4C000001	
		13	91003-SA1-0100	BEARING, RADIAL BALL 63/22 TMB	1	Y		20040817		KMYSA4BLS4C000001	
		14	91203-SA1-0000	SEAL, OIL 22x39x7	1	Y		20040817		KMYSA4BLS4C000001	
		15	S5701-08016-08	BOLT, FLANGE 8x16	1	Y		20040817		KMYSA4BLS4C000001	
		16	S6001-06028-00	BOLT, FLANGE SH.6x28	5	Y		20040817		KMYSA4BLS4C000001	
		17	S6001-06035-00	BOLT, FLANGE SH.6x35	2	Y		20040817		KMYSA4BLS4C000001	
		18	S6001-06045-00	BOLT, FLANGE SH.6x45	2	Y		20040817		KMYSA4BLS4C000001	
		19	S6100-63020-00	BEARING, BALL 6302	1	Y		20040817		KMYSA4BLS4C000001	

E-15


RADIATOR / RADIATOR HOSE



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
RADIATOR ASS'Y, OIL	0.6	1	1901A-SA1-0101	RADIATOR ASS'Y, OIL	1	Y	20040817		KMYSA4BLS4C000001	
		2	19010-SA1-0102	RADIATOR COMP., OIL	1	N	20040817		KMYSA4BLS4C000001	
HOSE ASS'Y, RADIATOR RH.	1.0	3	19011-SA1-0000	COLLAR, RADIATOR	3	Y	20040817		KMYSA4BLS4C000001	
		4	19012-SA1-0100	RUBBER, RADIATOR	3	Y	20040817		KMYSA4BLS4C000001	
HOSE ASS'Y, RADIATOR LH.	1.0	5	19100-SA2-0000	HOSE ASS'Y, RADIATOR RH.	1	Y	20040817		KMYSA4BLS4C000001	
		6	19200-SA4-0000-M2	HOSE ASS'Y, RADIATOR LH.	1	Y	20040817		KMYSA4BLS4C000001	
		7	90145-SA1-0002	BOLT, OIL THROUGH 12mm	4	Y	20040817		KMYSA4BLS4C000001	
		8	90407-BA6-0002	PACKING, DRAIN COCK 12.5x20	8	Y	20040817		KMYSA4BLS4C000001	
		9	S5701-06018-08	BOLT, FLANGE 6x18	3	Y	20040817		KMYSA4BLS4C000001	

E-16


RIGHT CRANK CASE



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
CASE COMP., RH. CRANK	*4.0	1	11100-SA2-0000	CASE COMP., RH. CRANK	1	Y		20040817		KMYSA4BLS4C000001	
		2	11333-SA1-0101	COVER COMP., OIL FILTER	1	Y		20040817		KMYSA4BLS4C000001	
COVER COMP., OIL FILTER	0.5	3	11335-SA1-0000	SEAL, OIL FILTER	1	Y		20040817		KMYSA4BLS4C000001	
		4	12361-SA1-0000 12361-035-0000	CAP, TAPPET ADJUSTING HOLE	1	Y		20040817		KMYSA4BLS4C000001	
• ELEMENT, OIL FILTER		5	15412-SA1-0000	ELEMENT, OIL FILTER	1	Y		20040817		KMYSA4BLS4C000001	
• SEAL, OIL FILTER		6	15414-BA6-9600	SPRING, OIL FILTER	1	Y		20040817		KMYSA4BLS4C000001	
SCREEN, OIL FILTER	0.2	7	15415-SA1-0001	VALVE, RELIEF	1	Y		20040817		KMYSA4BLS4C000001	
(INCLUDE RELATIVE PARTS)		8	15416-SA1-0000	SPRING, RELIEF VALVE	1	Y		20040817		KMYSA4BLS4C000001	
		9	15421-BA6-0001	SCREEN, OIL FILTER	1	Y		20040817		KMYSA4BLS4C000001	
		10	15426-SA1-0000	SPRING, OIL FILTER SCREEN	1	Y		20040817		KMYSA4BLS4C000001	
		11	15652-SA1-0001	COLLAR, OIL PICK UP	1	Y		20040817		KMYSA4BLS4C000001	
		12	90009-SA1-0001	BOLT, SOCKET 12mm	1	Y		20040817		KMYSA4BLS4C000001	
		13	90031-SA1-0101	BOLT, CYLINDER STUD	2	Y		20040817		KMYSA4BLS4C000001	
		14	90443-SA1-0001	WASHER, SELING 12mm	1	Y		20040817		KMYSA4BLS4C000001	
		15	91004-X10-0000	BEARING, RADIAL BALL 6305	1	Y		20040817		KMYSA4BLS4C000001	
		16	91302-CB2-0205	O-RING 30.8mm	1	Y		20040817		KMYSA4BLS4C000001	
		17	S6001-06022-00	BOLT, FLANGE SH.6x22	3	Y		20040817		KMYSA4BLS4C000001	
		18	S6001-06040-00	BOLT, FLANGE SH.6x40	1	Y		20040817		KMYSA4BLS4C000001	
		19	S6001-06065-00	BOLT, FLANGE SH.6x65	2	Y		20040817		KMYSA4BLS4C000001	

E-17



LEFT CRANK CASE



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
CASE COMP., LH. CRANK	*4.5	1	11191-SA1-0000-EU	GASKET, CRANK CASE	1	Y		20040817		KMYSA4BLS4C000001	
		2	11200-SA2-0000	CASE COMP., LH. CRANK	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6004UU	*4.5	3	11210-SA1-0000	GLASS COMP., OIL SIGHT	1	Y		20040817		KMYSA4BLS4C000001	
		4	1122A-SA4-0000	TUBE ASS'Y, BREATHER	1	Y		20040817		KMYSA4BLS4C000001	
• SEAL, OIL 25x42x7		5	90031-SA1-0101	BOLT, CYLINDER STUD	2	Y		20040817		KMYSA4BLS4C000001	
• SEAL, OIL 30x42x7											
		6	90084-CB2-8300	CAP, AC. GENERATOR	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6201 TMB	*4.5	7	90407-BA6-0002	PACKING, DRAIN COCK 12.5x20	1	Y		20040817		KMYSA4BLS4C000001	
		8	91003-SA0-0001	BEARING, RADIAL BALL 6301 TMB	1	Y		20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6303 TMB	*4.5	9	91004-SC1-7010-M1	BEARING, RADIAL BALL 6203 TMB	1	Y		20040817		KMYSA4BLS4C000001	
		10	91009-SC1-0030	BEARING, RADIAL BALL 6004UU	1	Y		20040817		KMYSA4BLS4C000001	
		11	91202-SA1-0100	SEAL, OIL 25x42x7	1	Y		20040817		KMYSA4BLS4C000001	
		12	91204-SA1-0000	SEAL, OIL 30x42x7	1	Y		20040817		KMYSA4BLS4C000001	
		13	91303-CB2-1000	O-RING 13.8x2.5	1	Y		20040817		KMYSA4BLS4C000001	
		14	S2800-12000	BOLT, DRAIN PLUG 12mm	1	Y		20040817		KMYSA4BLS4C000001	
		15	S4301-10160	PIN, DOWEL 10x16	2	Y		20040817		KMYSA4BLS4C000001	
		16	S5002-02100	CLIP, B10 TUBE	1	N		20040817		KMYSA4BLS4C000001	
		17	S6001-06065-00	BOLT, FLANGE SH.6x65	6	Y		20040817		KMYSA4BLS4C000001	
		18	S6001-06070-00	BOLT, FLANGE SH.6x70	1	Y		20040817		KMYSA4BLS4C000001	

E-18


CRANK SHAFT / PISTON



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
SHAFT COMP., CRANK	*4.0	1	13000-SA4-0000	SHAFT COMP., CRANK	1	Y	20040817		KMYSA4BLS4C000001	
		2	13101-SA1-0100	PISTON	1	Y	20040817		KMYSA4BLS4C000001	
SHAFT, CRANK		3	13111-BA6-9300	PIN, PISTON	1	Y	20040817		KMYSA4BLS4C000001	
		4	13121-SA1-0000	RING, PISTON TOP	1	Y	20040817		KMYSA4BLS4C000001	
RING SET, PISTON	*3.0	5	13131-SA1-0000	RING, PISTON 2ND	1	Y	20040817		KMYSA4BLS4C000001	
PISTON		6	13141-SA1-0000	RING, PISTON OIL	1	Y	20040817		KMYSA4BLS4C000001	
PIN, PISTON		7	13201-SA1-0003-H1	ROD, CONNECTING	1	N	20040817		KMYSA4BLS4C000001	
ROD, CONNECTING		8	13310-SA1-0100-H1	SHAFT COMP., RH. CRANK	1	N	20040817		KMYSA4BLS4C000001	
(INCLUDE RELATIVE PARTS)		9	13321-SA1-0201-H1	SHAFT, LH. CRANK	1	N	20040817		KMYSA4BLS4C000001	
		10	13381-SA1-0100-H1	PIN, CRANK	1	N	20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6305	*4.5	11	14311-SA4-0000-H1	SPROCKET, TIMMING	1	Y	20040817		KMYSA4BLS4C000001	
		12	15133-SA1-0102	GEAR, OIL PUMP DRIVE	1	Y	20040817		KMYSA4BLS4C000001	
		13	90741-BA6-9600	KEY, WOODRUFF 25x14x4	2	Y	20040817		KMYSA4BLS4C000001	
		14	91102-BA6-0030	ROLLER 4x14.8A	18	N	20040817		KMYSA4BLS4C000001	
		15	91105-BA6-0031	RETAINER, CONROD LARGE END	1	N	20040817		KMYSA4BLS4C000001	
		16	S4601-15000	CLIP, PISTON PIN 15mm	2	Y	20040817		KMYSA4BLS4C000001	
		17	S6100-63050-00	BEARING, RADIAL BALL 6305	1	Y	20040817		KMYSA4BLS4C000001	

E-19


CARBURETOR



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
JET, NEEDLE	0.7	1	16007-SA4-0000	CAP, HOLDER	1	N		20040817		KMYSA4BLS4C000001	
		2	16008-SA4-0000	TOP SET	1	N		20040817		KMYSA4BLS4C000001	
• PLANGER ASS'Y		3	16009-SA4-0000	SPRING, COMPRESSION	1	N		20040817		KMYSA4BLS4C000001	
• CARBURETOR ASS'Y		4	16015-SA4-0000	CHAMBER SET, FLOAT	1	N		20040817		KMYSA4BLS4C000001	
		5	16016-SA4-0000	SCREW SET	1	N		20040817		KMYSA4BLS4C000001	
FLOAT ASS'Y	0.6	6	16022-SA4-0000	NEEDLE COMP., JET	1	Y		20040817		KMYSA4BLS4C000001	
• JET, MAIN	0.5	7	16024-SA4-0000	PISTON COMP., VACUUM	1	Y		20040817		KMYSA4BLS4C000001	
		8	16028-SA4-0000	VALVE SET, FLOAT	1	Y		20040817		KMYSA4BLS4C000001	
		9	16031-SA4-0000	PIN, ARM	1	N		20040817		KMYSA4BLS4C000001	
		10	16033-SA4-0000	SPRING, COMPRESSION	1	N		20040817		KMYSA4BLS4C000001	
		11	16033-SA4-9000	SPRING, COMPRESSION	1	N		20040817		KMYSA4BLS4C000001	
		12	16034-SA4-0000	CAP, SEALING	1	N		20040817		KMYSA4BLS4C000001	
		13	16035-SA4-0000	PLATE SET, STAY	1	N		20040817		KMYSA4BLS4C000001	
		14	16037-SA4-0000	SCREW SET	1	N		20040817		KMYSA4BLS4C000001	
		15	16042-SA4-0000	PLATE, STAY	1	N		20040817		KMYSA4BLS4C000001	
		16	16050-SA4-0000	FLOAT COMP.	1	Y		20040817		KMYSA4BLS4C000001	
		17	16070-SA4-0000	COVER	1	N		20040817		KMYSA4BLS4C000001	
		18	16070-SA4-9000	COVER	1	N		20040817		KMYSA4BLS4C000001	
		19	16080-SA4-0000	DIAPHRAGM COMP.	1	N		20040817		KMYSA4BLS4C000001	
		20	16080-SA4-9000	DIAPHRAGM COMP.	1	N		20040817		KMYSA4BLS4C000001	

E-19


CARBURETOR



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		21	16091-SA4-0000	TUBE SET	1	N		20040817		KMYSA4BLS4C000001	
		22	16100-SA4-0000	CARBURETOR ASS'Y	1	Y		20040817		KMYSA4BLS4C000001	
		23	16101-SA4-0000	HOLDER, NEEDLE JET	1	N		20040817		KMYSA4BLS4C000001	
		24	16102-SA4-0000	JET, NEEDLE	1	Y		20040817		KMYSA4BLS4C000001	
		25	16114-SA4-0000	PLATE SET, VALVE	1	N		20040817		KMYSA4BLS4C000001	
		26	16150-SA4-0000	BYSTARTER SET, AUTO	1	Y		20040817		KMYSA4BLS4C000001	
		27	16182-SA4-0000	U-RING	2	Y		20040817		KMYSA4BLS4C000001	
		28	16199-SA4-0000	TUBE SET	1	N		20040817		KMYSA4BLS4C000001	
		29	90001-SA4-0000	SCREW, SPECIAL PAN	2	Y		20040817		KMYSA4BLS4C000001	
		30	90011-SA4-0000	SCREW, PAN 5x8	1	N		20040817		KMYSA4BLS4C000001	
		31	90011-SA4-9000	SCREW, PAN 5x14	1	N		20040817		KMYSA4BLS4C000001	
		32	S3500-04008-1H	SCREW, PAN 4x8	3	N		20040817		KMYSA4BLS4C000001	
		33	S3500-04010-1H	SCREW, PAN 4x10	2	N		20040817		KMYSA4BLS4C000001	
		34	S3500-04012-1H	SCREW, PAN 4x12	3	N		20040817		KMYSA4BLS4C000001	
		35	S3892-04008-18	SCREW, WASHER 4x8	1	N		20040817		KMYSA4BLS4C000001	
		36	S9101-SA4-0000	JET, MAIN #102	1	Y		20040817		KMYSA4BLS4C000001	
		37	S9103-SA4-0000	JET, SLOW	1	Y		20040817		KMYSA4BLS4C000001	

F-01


HEAD LIGHT



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM.No	End FRM.No
LIGHT ASS'Y, HEAD	0.6	1	33100-SZ1-0000-M1	LIGHT ASS'Y, HEAD	1	Y		20040817		KMYSA4BLS4C000001	
		2	33110-SZ1-0000	UNIT, HEAD LIGHT	1	N		20040817		KMYSA4BLS4C000001	
		3	33116-SZ1-0000	COVER, DUST	2	N		20040817		KMYSA4BLS4C000001	
		4	33130-SZ1-0000-M1	SOCKET COMP., HEAD LIGHT	1	N		20040817		KMYSA4BLS4C000001	
SOCKET COMP., HEAD LIGHT	0.5	5	34901-SZ1-0000	BULB, HEAD LIGHT(12V 55W) H7	2	Y		20040817		KMYSA4BLS4C000001	
		6	34902-SA1-RB00	BULB, WEDGE BASE(12V 5W)	1	Y		20040817		KMYSA4BLS4C000001	
		7	90111-SE5-1000	BOLT, FLANGE Gmm	5	Y		20040817		KMYSA4BLS4C000001	

F-02


SPEEDOMETER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
METER ASS'Y, COMBINATION	0.6	1	34908-BA7-9000	BULB, WEDGE BASE	3	Y		20040817		KMYSA4BLS4C000001	
		2	34908-SA2-8710-M1	BULB, WEDGE BASE(12V 1.7W)	2	Y		20040817		KMYSA4BLS4C000001	
METER, METER	0.7	3	37100-SA4-0000	METER ASS'Y, COMBINATION	1	Y		20040817		KMYSA4BLS4C000001	
		4	37202-SZ1-0000	LENS, METER	1	N		20040817		KMYSA4BLS4C000001	
METER, METER	0.6	5	37210-SA4-0000 37100 SA4 0000	BODY ASS'Y, SPEEDOMETER	1	N		20040817		KMYSA4BLS4C000001	
SOCKET COMP.	0.8	6	37211-SZ1-0000	CASE, METER	1	N		20040817		KMYSA4BLS4C000001	
		7	37212-SZ1-0000	PLATE, REFLECTING	1	N		20040817		KMYSA4BLS4C000001	
BULB, WEDGE BASE(12V 3W)		8	37215-SZ1-0000	CLAMP, CORD	1	N		20040817		KMYSA4BLS4C000001	
BULB, WEDGE BASE(12V 1.7W)		9	37223-SA4-0000	SOCKET COMP.	1	N		20040817		KMYSA4BLS4C000001	
		10	37305-BA6-0080	SCREW, WASHER 3x22	3	N		20040817		KMYSA4BLS4C000001	
CABLE COMP., SPEEDOMETER	0.4	11	44830-SZ1-0000	CABLE COMP., SPEEDOMETER	1	Y		20040817		KMYSA4BLS4C000001	
		12	S3700-05016-06	SCREW, OVAL 5x16	1	Y		20040817		KMYSA4BLS4C000001	
		13	S3892-04008-10	SCREW, WASHER 4x8	2	N		20040817		KMYSA4BLS4C000001	
		14	S3903-25380	SCREW, TAPPING 5x16	5	Y		20040817		KMYSA4BLS4C000001	
		15	S3903-34120	SCREW, TAPPING 4x8	1	N		20040817		KMYSA4BLS4C000001	

F-03


HANDLE GRIP / SWITCH / CABLE



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
CABLE COMP., THROTTLE	1.0	1	17910-SA4-0000	CABLE COMP., THROTTLE	1	Y		20040817		KMYSA4BLS4C000001	
		2	35150-SZ1-RB00-M1	SWITCH ASS'Y, LIGHTING START	1	Y		20040817		KMYSA4BLS4C000001	
SWITCH ASS'Y, LIGHTING START	0.4	3	35200-SZ1-0000	SWITCH ASS'Y, WINKER	1	Y		20040817		KMYSA4BLS4C000001	
		4	53140-SZ1-0000	GRIP COMP., RH.	1	Y		20040817		KMYSA4BLS4C000001	
SWITCH ASS'Y, WINKER	0.4	5	53141-SZ1-0000	PIPE, THROTTLE GRIP	1	N		20040817		KMYSA4BLS4C000001	
GRIP COMP., RH.	0.4	6	53166-BA4-0000	GRIP, LH.HANDLE	1	Y		20040817		KMYSA4BLS4C000001	
		7	88110-SZ1-0000	MIRROR ASS'Y, RH.BACK	1	Y		20040817		KMYSA4BLS4C000001	
GRIP, LH.HANDLE	0.3	8	88120-SZ1-0000	MIRROR ASS'Y, LH.BACK	1	Y		20040817		KMYSA4BLS4C000001	
		9	90107-BA5-1000	BOLT, SPECIAL FLANGE 8x35	2	N		20040817		KMYSA4BLS4C000001	
MIRROR, BACK	0.2	10	S3892-05028-08	SCREW, WASHER 5x28	3	Y		20040817		KMYSA4BLS4C000001	
		11	S3892-05045-08	SCREW, WASHER 5x45	1	Y		20040817		KMYSA4BLS4C000001	
		12	S4111-08000	WASHER, SPRING 8mm	4	N		20040817		KMYSA4BLS4C000001	

F-04


MASTER CYLINDER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
SWITCH ASS'Y, FR.STOP	0.4	1	35340-SA2-0000	SWITCH ASS'Y, RR.STOP	1	Y		20040817		KMYSA4BLS4C000001	
		2	35340-SC1-6710-M1	SWITCH ASS'Y, FR.STOP	1	Y		20040817		KMYSA4BLS4C000001	
DIAPHRAGM		3	45126-SZ1-0000	HOSE COMP., FR.BRAKE	1	Y		20040817		KMYSA4BLS4C000001	
LEVER, RH.STEERING HANDLE		4	45146-SZ1-0000	HOSE PIPE, RR.BRAKE	1	Y		20040817		KMYSA4BLS4C000001	
		5	45147-SZ1-0000	HOSE A ASS'Y, RR.BRAKE	1	Y		20040817		KMYSA4BLS4C000001	
HOSE COMP., FR.BRAKE	0.7										
		6	45148-SA4-0000-M1	HOSE B ASS'Y, RR.BRAKE	1	Y		20040817		KMYSA4BLS4C000001	
CYLINDER ASS'Y, FR.MASTER	0.6	7	45151-SA2-0000	CLAMP, BRAKE HOSE	2	Y		20040817		KMYSA4BLS4C000001	
		8	45500-SZ1-0000	CYLINDER ASS'Y, FR.MASTER	1	Y		20040817		KMYSA4BLS4C000001	
CYLINDER SET, MASTER	0.6	9	45501-SZ1-0002	BODY, FR.MASTER CYLINDER	1	N		20040817		KMYSA4BLS4C000001	
		10	45512-BA6-0062-M1	PROTECTOR(DC)	2	N		20040817		KMYSA4BLS4C000001	
SWITCH ASS'Y, RR.STOP	0.4										
		11	45513-SZ1-0000	CAP, OIL CUP	2	N		20040817		KMYSA4BLS4C000001	
HOSE A ASS'Y, RR.BRAKE	0.7	12	45517-SZ1-0000	HOLDER, MASTER CYLINDER	2	N		20040817		KMYSA4BLS4C000001	
		13	45518-BA4-0000-M1	BOLT, MASTER CYLINDER HOLDER	4	N		20040817		KMYSA4BLS4C000001	
HOSE B ASS'Y, RR.BRAKE	0.4	14	45520-SC1-0060	DIAPHRAGM	2	Y		20040817		KMYSA4BLS4C000001	
		15	45521-SC1-0061	PLATE, DIAPHRAGM	2	N		20040817		KMYSA4BLS4C000001	
HOSE PIPE, RR.BRAKE	0.4										
		16	45530-SZ1-0000	CYLINDER SET, MASTER	2	Y		20040817		KMYSA4BLS4C000001	
CYLINDER ASS'Y, RR.MASTER	0.6	17	45600-SZ1-0000	CYLINDER ASS'Y, RR.MASTER	1	Y		20040817		KMYSA4BLS4C000001	
		18	45601-SZ1-0002	BODY, RR.MASTER CYLINDER	1	N		20040817		KMYSA4BLS4C000001	
		19	53175-SZ1-0000	LEVER, RH.STEERING HANDLE	1	N		20040817		KMYSA4BLS4C000001	
		20	53178-SZ1-0000	LEVER, LH.STEERING HANDLE	1	N		20040817		KMYSA4BLS4C000001	

F-04


MASTER CYLINDER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
		21	90114-BA6-0000	BOLT, HANDLE LEVER	2	N	20040817		KMYSA4BLS4C000001	
		22	90145-SE5-0000	BOLT, OIL 10x22	4	Y	20040817		KMYSA4BLS4C000001	
		23	90545-BA6-0000	WASHER, OIL BOLT	8	Y	20040817		KMYSA4BLS4C000001	
		24	S3600-04012-1G	SCREW, FLAT 4x12	4	N	20040817		KMYSA4BLS4C000001	
		25	S3893-04012-18	SCREW, WASHER 4x12	2	N	20040817		KMYSA4BLS4C000001	
		26	S4050-06000	NUT, FLANGE 6mm	1	Y	20040817		KMYSA4BLS4C000001	
		27	S4050-06080	NUT, FLANGE 6mm	1	Y	20040817		KMYSA4BLS4C000001	
		28	S5701-06012-08*	BOLT, FLANGE 6x12	1	Y	20040817		KMYSA4BLS4C000001	

F-05


STEERING HANDLE / HANDLE COVER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
HANDLE COMP., STEERING	1.0	1	53100-SZ1-0000	HANDLE COMP., STEERING	1	Y	20040817		KMYSA4BLS4C000001	
		2	53106-SZ1-0000	WEIGHT CAP, HANDLE	2	Y	20040817		KMYSA4BLS4C000001	
COVER, RH.UNDER HANDLE	0.1	3	53125-CB2-9001	COLLAR, HANDLE SETTING	1	Y	20040817		KMYSA4BLS4C000001	
		4	53205-SZ1-0000	COVER, UPPER HANDLE	1	Y	20040817		KMYSA4BLS4C000001	
COVER, LH.UNDER HANDLE	0.1	5	53206-SZ1-0000	COVER, RH.UNDER HANDLE	1	Y	20040817		KMYSA4BLS4C000001	
		6	53207-SZ1-0000	COVER, LH.UNDER HANDLE	1	Y	20040817		KMYSA4BLS4C000001	
COVER, UPPER HANDLE	0.2	7	5321A-SZ1-0000	SCREEN ASS'Y, WIND	1	Y	20040817		KMYSA4BLS4C000001	
SCREEN, WIND	0.1	8	5321A-SZ1-0000	SCREEN, WIND	1	N	20040817		KMYSA4BLS4C000001	
		9	53214-SZ1-0000	RUBBER, WIND SCREEN MOUNT	4	Y	20040817		KMYSA4BLS4C000001	
		10	87150-SZ1-0000	MARK, HANDLE COVER	1	Y	20040817		KMYSA4BLS4C000001	
		11	87560-SA1-MA00	MARK, DRIVE CAUTION(ENGLISH)	1	Y	20040817		KMYSA4BLS4C000001	
			87560-SA1-RB00	MARK, DRIVE CAUTION(GERMAN)	1	Y	20040817		KMYSA4BLS4C000001	
			87560-SA1-RC00	MARK, DRIVE CAUTION(ITALIAN)	1	Y	20040817		KMYSA4BLS4C000001	
			87560-SA1-RE00	MARK, DRIVE CAUTION(FRENCH)	1	Y	20040817		KMYSA4BLS4C000001	
			87560-SA1-RJ00	MARK, DRIVE CAUTION(SPANISH)	1	Y	20040817		KMYSA4BLS4C000001	
		12	90106-CB2-9000	BOLT, FLANGE 10x50	1	Y	20040817		KMYSA4BLS4C000001	
		13	90192-SE3-0000	SCREW, SPECIAL 5x14	2	Y	20040817		KMYSA4BLS4C000001	
		14	90302-SE5-2001	BOLT, WASHER 5x16	4	Y	20040817		KMYSA4BLS4C000001	
		15	90304-SE6-0000	NUT, U 10mm	1	Y	20040817		KMYSA4BLS4C000001	
		16	S3891-05014-07	SCREW, WASHER 5x14	1	Y	20040817		KMYSA4BLS4C000001	

F-05


STEERING HANDLE / HANDLE COVER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		17	S3903-25280	SCREW, TAPPING 5x12	2	Y		20040817		KMYSA4BLS4C000001	
		18	S3903-34380	SCREW, TAPPING 4x12	2	Y		20040817		KMYSA4BLS4C000001	
		19	S6700-08035-00	BOLT, SOCKET 8x35	2	Y		20040817		KMYSA4BLS4C000001	

F-06

FRONT COVER / INNER COVER




AZUL 2006 = DB

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
COVER, FR.	0.1	1	1751B-SZ1-0000	NECK ASS'Y, FUEL CAP	1	Y		20040817		KMYSA4BLS4C000001	
		2	53215-SZ1-0000	RUBBER, WIND SCREEN SEALING	1	Y		20040817		KMYSA4BLS4C000001	
COVER, METER	0.3	3	61200-SZ1-0000-SL	COVER B, FR.UNDER(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			61200-SZ1-0000-TR	COVER B, FR.UNDER(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
COVER ASS'Y, INNER	0.8		61200-SZ1-0000-XB	COVER B, FR.UNDER(G/BBLUE)	1	Y		20040817		KMYSA4BLS4C000001	
		4	61310-SZ1-0000	COVER, METER	1	Y		20040817		KMYSA4BLS4C000001	
HOLDER COMP., BAG	0.1	5	64301-SZ1-0000-SL	COVER, FR.(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			64301-SZ1-0000-TR	COVER, FR.(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, ENGINE COOLANT	0.1		64301-SZ1-0000-XB	COVER, FR.(G/BBLUE)	1	Y		20040817		KMYSA4BLS4C000001	
COVER B, FR.UNDER	0.6	6	6440A-SZ1-0000-SL	COVER A ASS'Y, FR.UNDER(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			6440A-SZ1-0000-TR	COVER A ASS'Y, FR.UNDER(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
NECK ASS'Y, FUEL CAP	0.1		6440A-SZ1-0000-XB	COVER A ASS'Y, FR.UNDER(G/BBLUE)	1	Y		20040817		KMYSA4BLS4C000001	
		7	64400-SZ1-0000-SL	COVER A, FR.UNDER(SILVER)	1	N		20040817		KMYSA4BLS4C000001	
DUCT, AIR	0.6		64400-SZ1-0000-TR	COVER A, FR.UNDER(O/RED)	1	N		20040817		KMYSA4BLS4C000001	
			64400-SZ1-0000-XB	COVER A, FR.UNDER(G/BBLUE)	1	N		20040817		KMYSA4BLS4C000001	
COVER A ASS'Y, FR.UNDER	0.4	8	64409-SZ1-0000	RUBBER, CUSHION	3	N		20040817		KMYSA4BLS4C000001	
		9	81100-SA1-0101	HOLDER COMP., BAG	1	Y		20040817		KMYSA4BLS4C000001	
		10	8113A-SZ1-0000	COVER ASS'Y, INNER	1	Y		20040817		KMYSA4BLS4C000001	
		11	8113A-SZ1-0000	COVER, INNER	1	N		20040817		KMYSA4BLS4C000001	
		12	81132-SA2-0000	CAP, NUMBERING	1	N		20040817		KMYSA4BLS4C000001	

8113A-SZ1-0000

F-06


FRONT COVER / INNER COVER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		13	81137-SZ1-000	GRILLE, RH. INNER COVER	1	Y		20040817		KMYSA4BLS4C000001	
		14	81147-SZ1-000	GRILLE, LH. INNER COVER	1	Y		20040817		KMYSA4BLS4C000001	
		15	81161-SZ1-000	COVER, ENGINE COOLANT	1	Y		20040817		KMYSA4BLS4C000001	
		16	87124-SZ1-0000	MARK, FR. COVER	1	Y		20040817		KMYSA4BLS4C000001	
		17	90111-SE5-1000	BOLT, FLANGE 6mm	2	Y		20040817		KMYSA4BLS4C000001	
		18	90190-SC1-0000	SCREW, SPECIAL 6x10	1	Y		20040817		KMYSA4BLS4C000001	
		19	90192-SE3-0000	SCREW, SPECIAL 5x14	4	Y		20040817		KMYSA4BLS4C000001	
		20	90302-SA4-0032	NUT, SPRING 4mm	3	Y		20040817		KMYSA4BLS4C000001	
		21	90302-SE5-2001	BOLT, WASHER 5x16	2	Y		20040817		KMYSA4BLS4C000001	
		22	90305-SE5-1001	NUT, CLIP 6mm	5	Y		20040817		KMYSA4BLS4C000001	
		23	90677-SE5-0030	NUT, CLIP 5mm	4	Y		20040817		KMYSA4BLS4C000001	
		24	S3500-05028-0H	SCREW, PAN 5x28	2	Y		20040817		KMYSA4BLS4C000001	
		25	S3903-25280	SCREW, TAPPING 5x12	19	Y		20040817		KMYSA4BLS4C000001	
		26	S3903-34380	SCREW, TAPPING 4x12	3	Y		20040817		KMYSA4BLS4C000001	

F-07

FRONT FENDER




AZUL 2006 = DB



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
FENDER, FR.	0.2	1	45451-BA6-9700	GROMMET, WIRE	1	Y		20040817		KMYSA4BLS4C000001	
		2	61100-SZ1-0000-SL	FENDER, FR. (SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			61100-SZ1-0000-TR	FENDER, FR. (O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
			61100-SZ1-0000-XB	FENDER, FR. (G/BLUE)	1	Y		20040817		KMYSA4BLS4C000001	
		3	90110-SE5-0001	SCREW, SPECIAL 6x14	4	Y		20040817		KMYSA4BLS4C000001	

F-08

STEERING STEM




- 3 50306 GS4 0000
- 10 53220 GS4 0000
- 6 53211 GNS 9002
- 5 53210 CB3 7500
- 15801 GNS 9002
- 2 50302 CB2 9002
- 11 53220-CB3-7500
- 7 53212 GNS 9002
- 8 53214 GNS 9001
- 9 53215 GS4 0000

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
RACE, STEERING TOP BALL	1.2	1	50301-CB2-9002	RACE, STEERING TOP BALL	1	Y		20040817		KMYSA4BLS4C000001	
		2	50302-CB2-9002	RACE, STEERING BOTTOM BALL	1	Y		20040817		KMYSA4BLS4C000001	
RACE, STEERING BOTTOM CONE	1.2	3	50306-CB3-0000	NUT, STEERING STEM LOCK	1	Y		20040817		KMYSA4BLS4C000001	
		4	53200-SZ1-0000	STEM COMP., STEERING → 116-518	1	Y		20040817		KMYSA4BLS4C000001	
THREAD COMP., TOP	1.0	5	53210-CB3-7500	BALL ASS'Y, STEERING UPPER	1	Y		20040817		KMYSA4BLS4C000001	
STEM COMP., STEERING	1.2	6	53211-CB2-9002	RACE, STEERING TOP CONE	1	Y		20040817		KMYSA4BLS4C000001	
		7	53212-CB2-9002	RACE, STEERING BOTTOM CONE	1	Y		20040817		KMYSA4BLS4C000001	
		8	53214-CB2-9001	SEAL, STEERING DUST	1	Y		20040817		KMYSA4BLS4C000001	
		9	53215-CB3-0000	WASHER, STEERING HEAD DUST SEAL	1	Y		20040817		KMYSA4BLS4C000001	
		10	53220-CB3-0000	THREAD COMP., TOP	1	Y		20040817		KMYSA4BLS4C000001	
		11	53220-CB3-7500	BALL ASS'Y, STEERING UNDER	1	Y		20040817		KMYSA4BLS4C000001	
		12	S5801-10045-08	BOLT, FLANGE 10x45	4	Y		20040817		KMYSA4BLS4C000001	

F-09



FRONT FORK



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
FORK ASS'Y, FR. (ADD 0.1 FOR EACH)	0.7	1	51400-SZ1-0001	FORK ASS'Y, RH.FR.	1	Y		20040817		KMYSA4BLS4C000001	
		2	51401-SZ1-0000	SPRING, FR.FORK	2	N		20040817		KMYSA4BLS4C000001	
		3	51410-SZ1-0000	PIPE COMP., FORK	2	N		20040817		KMYSA4BLS4C000001	
PIPE COMP., FORK (ADD 0.4 FOR EACH)	0.9	4	51412-BA5-9000	SPRING, REBOUND	4	N		20040817		KMYSA4BLS4C000001	
		5	51420-SZ1-0000	CASE, RH.BOTTOM	1	N		20040817		KMYSA4BLS4C000001	
• SPRING, FR.FORK		6	51425-BA5-9000	SEAL, DUST	2	Y		20040817		KMYSA4BLS4C000001	
• SPRING, REBOUND		7	51427-BA5-9000	BUSH, GUIDE	2	N		20040817		KMYSA4BLS4C000001	
• PIPE, SEAT		8	51432-BA5-9000	PIECE, OIL LOCK	2	N		20040817		KMYSA4BLS4C000001	
		9	51437-BA5-9000	RING, PISTON	2	N		20040817		KMYSA4BLS4C000001	
CASE, BOTTOM (ADD 0.5 FOR EACH)	1.0	10	51440-SZ1-0000	PIPE, SEAT	2	N		20040817		KMYSA4BLS4C000001	
		11	51441-BA5-9000	RING, BACK UP	2	N		20040817		KMYSA4BLS4C000001	
		12	51500-SZ1-0001	FORK ASS'Y, LH.FR.	1	Y		20040817		KMYSA4BLS4C000001	
		13	51520-SZ1-0000	CASE, LH.BOTTOM	1	N		20040817		KMYSA4BLS4C000001	
		14	90116-BA6-7210-M1	BOLT, SOCKET 8mm	2	Y		20040817		KMYSA4BLS4C000001	
		15	90123-BA5-9000	BOLT, FR.FORK	2	Y		20040817		KMYSA4BLS4C000001	
		16	90544-H02-0002	WASHER, SPECIAL 8mm	2	Y		20040817		KMYSA4BLS4C000001	
		17	90601-BA5-9000	RING, OIL SEAL STOP	2	N		20040817		KMYSA4BLS4C000001	
		18	91255-BA5-9000	SEAL, OIL	2	Y		20040817		KMYSA4BLS4C000001	
		19	91356-BA5-9000	O-RING	2	Y		20040817		KMYSA4BLS4C000001	

F-10

BRAKE CALIPER




45105KCK0000EU

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
CALIPER ASS'Y, LH.FR	0.4	1	43352-BA5-9000-M1	BLEEDER(DC)	1	N		20040817		KMYSA4BLS4C000001	
		2	43352-SE6-9800	SCREW, BLEEDER	1	N		20040817		KMYSA4BLS4C000001	
PAD COMP.	0.2	3	43353-BA5-9000-M1	CAP, BLEEDER(DC)	1	N		20040817		KMYSA4BLS4C000001	
		4	43353-SE6-9800	CAP, BLEEDER	1	N		20040817		KMYSA4BLS4C000001	
BRACKET, CALIPER(FR.)	0.3	5	45100-BA5-RB00	CALIPER ASS'Y, LH.FR.	1	Y		20040817		KMYSA4BLS4C000001	
PISTON(FR.)	0.5	6	45101-BA5-9000-M1	BODY, CALIPER(DC)	1	N		20040817		KMYSA4BLS4C000001	
(ADD 0.1 FOR EACH)		7	45105-BA5-RB10-M1	PAD COMP. A(DC)	1	Y		20040817		KMYSA4BLS4C000001	
		8	45105-BA7-0001-EU	PAD COMP.	2	Y		20040817		KMYSA4BLS4C000001	
CALIPER ASS'Y, RR.BRAKE	0.5	9	45106-BA5-RB10-M1	PAD COMP. B(DC)	1	Y		20040817		KMYSA4BLS4C000001	
		10	45107-BA5-9000-M1	PISTON(DC)	2	N		20040817		KMYSA4BLS4C000001	
PAD COMP., OUTER	0.3	11	45107-BA6-0000	PISTON	1	N		20040817		KMYSA4BLS4C000001	
PAD COMP., INNER	0.3	12	45108-BA5-9000-M1	SPRING, PAD(DC)	1	N		20040817		KMYSA4BLS4C000001	
		13	45108-SE6-9800	SPRING, PAD	1	N		20040817		KMYSA4BLS4C000001	
BRACKET, CALIPER(RR.)	0.4	14	45109-BA5-9000-M1	SEAL, DUST(DC)	2	Y		20040817		KMYSA4BLS4C000001	
		15	45109-BA6-0000	SEAL, DUST	1	Y		20040817		KMYSA4BLS4C000001	
PISTON(RR.)	0.6		45110 KE2 9000 M1								
(ADD 0.1 FOR EACH)		16	45110-BA5-9000-M1	BRACKET, CALIPER(DC)	1	N		20040817		KMYSA4BLS4C000001	
		17	45112-BA5-9000-M1	RETAINER(DC)	1	N		20040817		KMYSA4BLS4C000001	
		18	45115-SE6-9800	PIN, SLIDE(DC)	1	N		20040817		KMYSA4BLS4C000001	
		19	45116-BA6-0000	SHIM, RH.(DC)	1	N		20040817		KMYSA4BLS4C000001	
		20	45131-BA5-9000-M1	BOLT, PIN(DC)	1	N		20040817		KMYSA4BLS4C000001	

F-10


BRAKE CALIPER



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM.No	End FRM.No
		21	45131-SE6-9800	BOLT, PIN	1	N		20040817		KMYSA4BLS4C000001	
		22	45132-BA5-9000-M1	BOOT, PIN BUSH(DC)	1	N		20040817		KMYSA4BLS4C000001	
		23	45132-SE6-9800	BUSH, PIN	1	N		20040817		KMYSA4BLS4C000001	
		24	45133-BA5-9000-M1	BOOT, PIN(DC)	1	N		20040817		KMYSA4BLS4C000001	
		25	45133-SE6-9800	BOOT, PIN	1	N		20040817		KMYSA4BLS4C000001	
		26	45134-SE6-9800	PLUG, DUST	1	N		20040817		KMYSA4BLS4C000001	
		27	45135-BA5-9000-M1	BOLT, PIN A(DC)	1	N		20040817		KMYSA4BLS4C000001	
		28	45201-SA1-0000	BODY, CALIPER	1	N		20040817		KMYSA4BLS4C000001	
		29	45203-BA5-9000-M1	PLUG, PIN(DC)	1	N		20040817		KMYSA4BLS4C000001	
		30	45209-BA5-9000-M1	SEAL, PISTON(DC)	2	Y		20040817		KMYSA4BLS4C000001	
		31	45209-BA6-0000	SEAL, PISTON	1	Y		20040817		KMYSA4BLS4C000001	
		32	45215-BA5-9000-M1	PIN, HANGER(DC)	1	N		20040817		KMYSA4BLS4C000001	
		33	45215-BA6-0000	PIN, HANGER	2	N		20040817		KMYSA4BLS4C000001	
		34	45216-SE6-9800	WASHER, WAVE	1	N		20040817		KMYSA4BLS4C000001	
		35	45217-BA6-0000	WASHER, TONGUED	1	N		20040817		KMYSA4BLS4C000001	
		36	45218-SE6-9800	WASHER, CONICAL SPRING	1	N		20040817		KMYSA4BLS4C000001	
		37	46200-SA2-RB00	CALIPER ASS'Y, RR.	1	Y		20040817		KMYSA4BLS4C000001	
		38	46210-SA2-0000	BRACKET, RR.CALIPER	1	N		20040817		KMYSA4BLS4C000001	
		39	90101-BA5-0000	BOLT, SPECIAL FLANGE 8x32	2	Y		20040817		KMYSA4BLS4C000001	
		40	S5801-08025-08	BOLT, FLANGE 8x25	2	Y		20040817		KMYSA4BLS4C000001	

F-11


FRONT WHEEL



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM.No	End FRM.No
WHEEL ASS'Y, FR.	0.5	1	42753-BA7-0000	VALVE, RIM TR 413	1	Y	20040817		KMYSA4BLS4C000001	
		2	44301-SZ1-0000	AXLE, FR.WHEEL	1	Y	20040817		KMYSA4BLS4C000001	
AXLE, FR.WHEEL	0.2	3	44311-SZ1-0000	COLLAR, FR.WHEEL SIDE	1	Y	20040817		KMYSA4BLS4C000001	
		4	44600-SZ1-0001	WHEEL ASS'Y, FR.	1	Y	20040817		KMYSA4BLS4C000001	
WHEEL, FR.CASTING	0.7	5	44601-SZ1-0000	WHEEL, FR.CASTING	1	Y	20040817		KMYSA4BLS4C000001	
COLLAR, FR.DISTANCE	0.6	6	44620-SA2-0000	COLLAR, FR.DISTANCE	1	N	20040817		KMYSA4BLS4C000001	
		7	44680-BA6-0100	RETAINER, GEAR BOX	1	N	20040817		KMYSA4BLS4C000001	
BEARING, RADIAL BALL 6301U		8	44711-SZ1-0000-M1	TIRE, FR.	1	Y	20040817		KMYSA4BLS4C000001	
		9	44800-SZ1-0000	BOX ASS'Y, SPEEDOMETER GEAR	1	Y	20040817		KMYSA4BLS4C000001	
BOX ASS'Y, SPEEDOMETER GEAR	0.3	10	44805-SZ1-0000	PINION, SPEEDOMETER	1	N	20040817		KMYSA4BLS4C000001	
TIRE, FR.	0.6	11	44806-SZ1-0000	GEAR, SPEEDOMETER	1	N	20040817		KMYSA4BLS4C000001	
		12	44808-BA6-7010-Y1	WASHER, GEAR	2	N	20040817		KMYSA4BLS4C000001	
DISK, FR.BRAKE	0.4	13	45121-SZ1-0000	DISK, FR.BRAKE	1	Y	20040817		KMYSA4BLS4C000001	
		14	90106-SC1-0000	BOLT, FR.DISK 8x57	3	Y	20040817		KMYSA4BLS4C000001	
		15	90306-CB3-0000	NUT, FLANGE 12mm	1	Y	20040817		KMYSA4BLS4C000001	
		16	91252-BA6-0030	SEAL, OIL 23x37x7	1	Y	20040817		KMYSA4BLS4C000001	
		17	91258-BA6-0061	SEAL, DUST 40x50x5	1	Y	20040817		KMYSA4BLS4C000001	
		18	S6140-63010-10	BEARING, RADIAL BALL 6301U	2	Y	20040817		KMYSA4BLS4C000001	

F-12

REAR WHEEL




Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
ARM, ASS'Y, RR. SWING	0.4	1	11204-SA1-0000	BUSH, RR. CUSHION UNDER RUBBER	1	Y		20040817		KMYSA4BLS4C000001	
		2	4230A-SA4-0000	ARM ASS'Y, RR. SWING	1	Y		20040817		KMYSA4BLS4C000001	
BUSH, RR. CUSHION UNDER RUBBER	0.6	3	42301-SA2-0001	ARM, RR. SWING	1	N		20040817		KMYSA4BLS4C000001	
		4	42304-SA2-0000	COLLAR, RR. WHEEL INSIDE	1	Y		20040817		KMYSA4BLS4C000001	
WHEEL ASS'Y, RR.	0.6	5	42305-SA2-0000	COLLAR, RR. WHEEL OUTSIDE	1	Y		20040817		KMYSA4BLS4C000001	
WHEEL, RR. CASTING	0.8	6	42600-SA4-0000	WHEEL ASS'Y, RR.	1	Y		20040817		KMYSA4BLS4C000001	
		7	42601-SA2-0000-M3	WHEEL COMP., RR. CASTING (W.F.)	1	Y		20040817		KMYSA4BLS4C000001	
TIRE, RR.	0.7	8	42711-SA4-0000-M1	TIRE, RR. 130/70-12	1	Y		20040817		KMYSA4BLS4C000001	
		9	42753-BA7-0000	VALVE, RIM TR 413	1	Y		20040817		KMYSA4BLS4C000001	
DISK, BRAKE	0.5	10	45351-SA2-0010-M1	DISK, RR. BRAKE	1	Y		20040817		KMYSA4BLS4C000001	
		11	90106-BA5-0001	BOLT, FR. DISK 8x24	3	Y		20040817		KMYSA4BLS4C000001	
		12	90158-SZ1-0000	BOLT, SPECIAL FLANGE 8x45	2	Y		20040817		KMYSA4BLS4C000001	
		13	90305-SE5-0000	NUT, U 14mm	1	Y		20040817		KMYSA4BLS4C000001	
		14	91257-BA6-0031	SEAL, OIL 28x42x7	1	Y		20040817		KMYSA4BLS4C000001	
		15	S6150-63020-10	BEARING, RADIAL BALL 6302UU	1	Y		20040817		KMYSA4BLS4C000001	

F-13

SEAT

ASIDEROS GRIS MODERNO
77305 SZ 10020 DERECHO
77306 SZ 10020 IZQ.




Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
SEAT ASS'Y	0.1	1	77101-SZ1-0000	COLLAR, SEAT MOUNT	1	N		20040817		KMYSA4BLS4C000001	
		2	77103-SZ1-0000	HINGE B, SEAT	1	N		20040817		KMYSA4BLS4C000001	
CATCH COMP., SEAT	0.2	3	77106-SZ1-0000	BOLT, PILLION SEAT	2	Y		20040817		KMYSA4BLS4C000001	
		4	7720A-SZ1-0000	SET, SEAT	1	Y		20040817		KMYSA4BLS4C000001	
CABLE, SEAT LOCK	0.8	5	77200-SZ1-0001	SEAT ASS'Y	1	N		20040817		KMYSA4BLS4C000001	
SEAT COMP., PILLION	0.1	6	77235-SZ1-0000	CATCH COMP., SEAT	2	Y		20040817		KMYSA4BLS4C000001	
		7	77240-SZ1-0009	CABLE, SEAT LOCK	1	Y		20040817		KMYSA4BLS4C000001	
GRIP, RH.RR.	0.1	8	77300-SZ1-0000	SEAT COMP., PILLION	1	Y		20040817		KMYSA4BLS4C000001	
		9	77330-SZ1-0000	GRIP, RH.RR. <i>negro</i>	1	Y		20040817		KMYSA4BLS4C000001	
GRIP, LH.RR.	0.1	10	77331-SZ1-0000	CAP, RH.RR.GRIP FR.	1	Y		20040817		KMYSA4BLS4C000001	
		11	77332-SZ1-0000	CAP, RH.RR.GRIP RR.	1	Y		20040817		KMYSA4BLS4C000001	
		12	77340-SZ1-0000	GRIP, LH.RR. <i>negro</i>	1	Y		20040817		KMYSA4BLS4C000001	
		13	77341-SZ1-0000	CAP, LH.RR.GRIP FR.	1	Y		20040817		KMYSA4BLS4C000001	
		14	77342-SZ1-0000	CAP, LH.RR.GRIP RR.	1	Y		20040817		KMYSA4BLS4C000001	
		15	90102-CB4-0000	BOLT, SEAT HINGE	1	N		20040817		KMYSA4BLS4C000001	
		16	90103-BA5-0000	SCREW, TORUS 6x12	4	Y		20040817		KMYSA4BLS4C000001	
		17	90106-SE1-0000	BOLT, SPECIAL 8x24	4	Y		20040817		KMYSA4BLS4C000001	
		18	S4050-06080	NUT, FLANGE 6mm	5	N		20040817		KMYSA4BLS4C000001	
		19	S4111-06800	WASHER, SPRING 6mm	2	Y		20040817		KMYSA4BLS4C000001	

F-14

FLOOR SIDE COVER / UNDER COVER

Reparan: Utes. S2 125 07.
 70602 SZ10000
 70601 SZ10000


AZUL 2006 = DB



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM.No	End FRM.No
COVER, RH.FLOOR SIDE	0.2	1	50613-SZ1-0000-SL	COVER, RH.FLOOR SIDE(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			50613-SZ1-0000-TR	COVER, RH.FLOOR SIDE(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, LH.FLOOR SIDE	0.2		50613-SZ1-0000-XB	COVER, RH.FLOOR SIDE(G/BUE)	1	Y		20040817		KMYSA4BLS4C000001	
		2	50614-SZ1-0000-SL	COVER, LH.FLOOR SIDE(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			50614-SZ1-0000-TR	COVER, LH.FLOOR SIDE(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, UNDER	0.3		50614-SZ1-0000-XB	COVER, LH.FLOOR SIDE(G/BUE)	1	Y		20040817		KMYSA4BLS4C000001	
		3	50621-SZ1-0000	COVER, UNDER	1	Y		20040817		KMYSA4BLS4C000001	
PANEL SET, FLOOR	0.6	4	6431A-SZ1-0000	SET, FLOOR PANEL	1	Y		20040817		KMYSA4BLS4C000001	
		5	6431A-SZ1-0000	PANEL, FLOOR	1	N		20040817		KMYSA4BLS4C000001	
		6	64311-SE1-RB00	CAP A, FLOOR PANEL	2	Y		20040817		KMYSA4BLS4C000001	
		7	64320-SZ1-0000	MAT, FLOOR	1	Y		20040817		KMYSA4BLS4C000001	
		8	90192-SB1-0000	SCREW, SPECIAL 5x12	8	Y		20040817		KMYSA4BLS4C000001	
		9	90677-SE5-0030	NUT, CLIP 5mm	7	Y		20040817		KMYSA4BLS4C000001	
		10	90683-SE5-0030	CLIP, BODY COVER	6	Y		20040817		KMYSA4BLS4C000001	
		11	S3404-06020-08	BOLT, WASHER 6x20	6	Y		20040817		KMYSA4BLS4C000001	
		12	S3891-05014-08	SCREW, WASHER 5x14	4	Y		20040817		KMYSA4BLS4C000001	
		13	S3903-25380	SCREW, TAPPING 5x16	2	Y		20040817		KMYSA4BLS4C000001	

F-15


FUEL TANK



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
BODY ASS'Y, FUEL PUMP	0.5	1	1670A-SA4-0000	PUMP SET, FUEL	1	Y		20040817		KMYSA4BLS4C000001	
		2	16700-SZ1-0000-M1	BODY ASS'Y, FUEL PUMP	1	Y		20040817		KMYSA4BLS4C000001	
STRAINER ASS'Y, FUEL	0.2	3	1691A-SZ1-0000	STRAINER ASS'Y, FUEL	1	Y		20040817		KMYSA4BLS4C000001	
		4	16910-CB2-9110-M1	STRAINER COMP., FUEL	1	Y		20040817		KMYSA4BLS4C000001	
TANK COMP., FUEL	0.8	5	16915-CB2-0000	SUSPENSION, STRAINER	1	Y		20040817		KMYSA4BLS4C000001	
UNIT, FUEL	0.6	6	1751A-SZ1-0000	TANK ASS'Y, FUEL	1	Y		20040817		KMYSA4BLS4C000001	
		7	17510-SZ1-0002	TANK COMP., FUEL	1	N		20040817		KMYSA4BLS4C000001	
		8	17514-SC1-9510-M1	CAP COMP., UNIT SET	1	Y		20040817		KMYSA4BLS4C000001	
		9	17610-SZ1-0000	TUBE, FUEL SUPPLY	1	Y		20040817		KMYSA4BLS4C000001	
		10	17612-SZ1-0000	CLIP, TUBE	2	Y		20040817		KMYSA4BLS4C000001	
		11	17615-SZ1-0000	TUBE, BREATHER 5.3x540	1	Y		20040817		KMYSA4BLS4C000001	
		12	1768B-SZ1-0000	TUBE B ASS'Y, FUEL 5.3x290	1	Y		20040817		KMYSA4BLS4C000001	
		13	1768C-SZ1-0000	TUBE C ASS'Y, FUEL 5.3x320	1	Y		20040817		KMYSA4BLS4C000001	
		14	17681-SA4-0000	TUBE ASS'Y, PULSE	1	Y		20040817		KMYSA4BLS4C000001	
		15	17683-SA4-0000	TUBE ASS'Y, FUEL 4.5x650	1	Y		20040817		KMYSA4BLS4C000001	
		16	37800-SZ1-0000	UNIT, FUEL	1	Y		20040817		KMYSA4BLS4C000001	
		17	37801-SE5-7000	PACKING, BASE	1	Y		20040817		KMYSA4BLS4C000001	
		18	90502-SA1-0000	SPECIAL CLIP, TUBE	1	N		20040817		KMYSA4BLS4C000001	
		19	S4050-06080	NUT, FLANGE 6mm	4	Y		20040817		KMYSA4BLS4C000001	
		20	S5002-02080	CLIP, B8 TUBE	1	N		20040817		KMYSA4BLS4C000001	

F-15


FUEL TANK



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		21	S5002-02100	CLIP, B10 TUBE	8	N		20040817		KMYSA4BLS4C000001	
		22	S5701-06016-08	BOLT, FLANGE 6x16	2	Y		20040817		KMYSA4BLS4C000001	

F-16


BATTERY



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
BATTERY ASS'Y 12V 10A(MF)	0.5	1	31500-BA4-0000-M1	BATTERY 12V 10A(MF) YTX12-13s	1	Y		20040817		KMYSA4BLS4C000001	
		2	32601-SA4-0000	CABLE, BATTERY EARTH	1	Y		20040817		KMYSA4BLS4C000001	
RELAY ASS'Y, AUDIBLE PILOT WINKER	0.2	3	35856-SE4-0000	RUBBER, WINKER RELAY SHOCK	1	N		20040817		KMYSA4BLS4C000001	
		4	3830A-SE4-0001	RELAY ASS'Y, AUDIBLE PILOT WINKER	1	Y		20040817		KMYSA4BLS4C000001	
RELAY ASS'Y, LIGHT	0.2	5	38301-BA6-0300-P	RELAY COMP., AUDIBLE PILOT WINKER	1	N		20040817		KMYSA4BLS4C000001	
		6	38500-BA4-0000	RELAY ASS'Y, LIGHT	1	Y		20040817		KMYSA4BLS4C000001	
		7	38501-SE6-9800	RELAY COMP., START	1	N		20040817		KMYSA4BLS4C000001	
		8	38506-BA4-0000	SUSPENSION, LIGHT RELAY	1	N		20040817		KMYSA4BLS4C000001	
		9	50320-SA4-0000	BOX ASS'Y, BATTERY	1	Y		20040817		KMYSA4BLS4C000001	
		10	90192-SE3-0000	SCREW, SPECIAL 5x14	1	Y		20040817		KMYSA4BLS4C000001	
		11	S3404-06012-08	BOLT, WASHER 6x12	2	Y		20040817		KMYSA4BLS4C000001	
		12	S8200-31500	FUSE, BLADE 15A	1	Y		20040817		KMYSA4BLS4C000001	

F-17


LUGGAGE BOX



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
LAMP, TRUNK	0.2	1	33900-SA1-0102-M1	LAMP, TRUNK	1	Y	20040817		KMYSA4BLS4C000001	
		2	50326-SZ1-0000	COVER, BATTERY	1	Y	20040817		KMYSA4BLS4C000001	
BOX, LUGGAGE	0.3	3	81218-SE5-3000-B1	LABEL, LUGGAGE BOX CAUTION(ENGLISH)	1	Y	20040817		KMYSA4BLS4C000001	
			81218-SA1-RB00	LABEL, LUGGAGE BOX CAUTION(GERMAN)	1	Y	20040817		KMYSA4BLS4C000001	
TOP COVER, LUGGAGE BOX	0.1		81218-SE5-RC00	LABEL, LUGGAGE BOX CAUTION(ITALIAN)	1	Y	20040817		KMYSA4BLS4C000001	
			81218-SE5-RE00	LABEL, LUGGAGE BOX CAUTION(FRENCH)	1	Y	20040817		KMYSA4BLS4C000001	
			81218-SE5-RJ00	LABEL, LUGGAGE BOX CAUTION(SPANISH)	1	Y	20040817		KMYSA4BLS4C000001	
		4	8125A-SA4-MA00	BOX ASS'Y, LUGGAGE(ENGLISH)	1	Y	20040817		KMYSA4BLS4C000001	
			8125A-SA4-RB00	BOX ASS'Y, LUGGAGE(GERMAN)	1	Y	20040817		KMYSA4BLS4C000001	
			8125A-SA4-RC00	BOX ASS'Y, LUGGAGE(ITALIAN)	1	Y	20040817		KMYSA4BLS4C000001	
			8125A-SA4-RE00	BOX ASS'Y, LUGGAGE(FRENCH)	1	Y	20040817		KMYSA4BLS4C000001	
			8125A-SA4-RJ00	BOX ASS'Y, LUGGAGE(SPANISH)	1	Y	20040817		KMYSA4BLS4C000001	
		5	81250-SZ1-0001	BOX, LUGGAGE	1	N	20040817		KMYSA4BLS4C000001	
		6	81251-SZ1-0000	COVER, CARBURETOR MAINTENANCE	1	Y	20040817		KMYSA4BLS4C000001	
		7	81255-SZ1-0000	TOP COVER, LUGGAGE BOX	1	Y	20040817		KMYSA4BLS4C000001	
		8	87565-SA4-RB00	CONTROL LABEL, ANTI-TAMPERING	1	N	20040817		KMYSA4BLS4C000001	
		9	90124-CB4-0010	SCREW, SPECIAL 6x16	1	N	20040817		KMYSA4BLS4C000001	
		10	90301-SB1-0000	NUT, OPEN STAY 6mm	2	Y	20040817		KMYSA4BLS4C000001	
		11	90305-SE5-1001	NUT, CLIP 6mm	1	Y	20040817		KMYSA4BLS4C000001	
		12	S3404-06016-08	BOLT, WASHER 6x16	2	Y	20040817		KMYSA4BLS4C000001	

F-17


LUGGAGE BOX



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		13	S3903-25380	SCREW, TAPPING 5x16	5	Y		20040817		KMYSA4BLS4C000001	
		14	S3903-45320	SCREW, TAPPING 5x16	1	Y		20040817		KMYSA4BLS4C000001	

F-18

CENTER COVER / BODY COVER




Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
MUDGUARD, RR.WHEEL	0.2	1	61120-SA1-RB12-BK	MUDGUARD, RR.WHEEL (BLACK)	1	Y		20040817		KMYSA4BLS4C000001	
		2	80104-SA1-0000	PLATE, SPLASH GUARD	1	Y		20040817		KMYSA4BLS4C000001	
COVER, CENTER	0.2	3	8015A-SA4-MA00	COVER ASS'Y, CENTER(ENGLISH)	1	Y		20040817		KMYSA4BLS4C000001	
			8015A-SA4-RB00	COVER ASS'Y, CENTER(GERMAN)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, RH.BODY SIDE	0.3		8015A-SA4-RC00	COVER ASS'Y, CENTER(ITALIAN)	1	Y		20040817		KMYSA4BLS4C000001	
			8015A-SA4-RE00	COVER ASS'Y, CENTER(FRENCH)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, RH.BODY	0.5		8015A-SA4-RJ00	COVER ASS'Y, CENTER(SPANISH)	1	Y		20040817		KMYSA4BLS4C000001	
		4	80151-SZ1-0001	COVER, CENTER	1	N		20040817		KMYSA4BLS4C000001	
COVER, LH.BODY SIDE	0.3	5	8350A-SZ1-0000-SL	COVER ASS'Y, RR.UPPER(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			8350A-SZ1-0000-TR	COVER ASS'Y, RR.UPPER(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, LH.BODY	0.5		8350A-SZ1-0000-XB	COVER ASS'Y, RR.UPPER(G/BLUE)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, RR.UNDER		6	83500-SZ1-0000-SL	COVER, RH.BODY(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
COVER, RR.UPPER			83500-SZ1-0000-TR	COVER, RH.BODY(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
			83500-SZ1-0000-XB	COVER, RH.BODY(G/BLUE)	1	Y		20040817		KMYSA4BLS4C000001	
		7	83502-SZ1-0000-SL	COVER, RR.UPPER(SILVER)	1	N		20040817		KMYSA4BLS4C000001	
			83502-SZ1-0000-TR	COVER, RR.UPPER(O/RED)	1	N		20040817		KMYSA4BLS4C000001	
			83502-SZ1-0000-XB	COVER, RR.UPPER(G/BLUE)	1	N		20040817		KMYSA4BLS4C000001	
		8	83503-SZ1-0000-SL	COVER, RR.UNDER(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			83503-SZ1-0000-TR	COVER, RR.UNDER(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
			83503-SZ1-0000-XB	COVER, RR.UNDER(G/BLUE)	1	Y		20040817		KMYSA4BLS4C000001	
		9	83506-SZ1-0000	COVER, RH.BODY SIDE	1	Y		20040817		KMYSA4BLS4C000001	
		10	83509-SZ1-0000	RUBBER, RR.UPPER COVER CUSHION	1	Y		20040817		KMYSA4BLS4C000001	

F-18

CENTER COVER / BODY COVER


AZUL 2006 = DB



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		11	83600-SZ1-0000-SL	COVER, LH.BODY(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			83600-SZ1-0000-TR	COVER, LH.BODY(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
			83600-SZ1-0000-XB	COVER, LH.BODY(G/BUE)	1	Y		20040817		KMYSA4BLS4C000001	
		12	83606-SZ1-0000	COVER, LH.BODY SIDE	1	Y		20040817		KMYSA4BLS4C000001	
		13	87121-SA4-RB00	MARK, BODY COVER	2	Y		20040817		KMYSA4BLS4C000001	
		14	87123-SZ1-0001-SL	MARK, RR.UNDER COVER(SILVER)	1	Y		20040817		KMYSA4BLS4C000001	
			87123-SZ1-0001-TR	MARK, RR.UNDER COVER(O/RED)	1	Y		20040817		KMYSA4BLS4C000001	
			87123-SZ1-0001-XB	MARK, RR.UNDER COVER(G/BUE)	1	Y		20040817		KMYSA4BLS4C000001	
		15	87505-SA4-MA00	LABEL, TIRE(ENGLISH)	1	Y		20040817		KMYSA4BLS4C000001	
			87505-SA4-RB00	LABEL, TIRE(GERMAN)	1	Y		20040817		KMYSA4BLS4C000001	
			87505-SA4-RC00	LABEL, TIRE(ITALIAN)	1	Y		20040817		KMYSA4BLS4C000001	
			87505-SA4-RE00	LABEL, TIRE(FRENCH)	1	Y		20040817		KMYSA4BLS4C000001	
			87505-SA4-RJ00	LABEL, TIRE(SPANISH)	1	Y		20040817		KMYSA4BLS4C000001	
		16	90110-SE5-0001	SCREW, SPECIAL 6x14	1	Y		20040817		KMYSA4BLS4C000001	
		17	90192-SB1-0000	SCREW, SPECIAL 5x12	3	Y		20040817		KMYSA4BLS4C000001	
		18	90192-SE3-0000	SCREW, SPECIAL 5x14	2	Y		20040817		KMYSA4BLS4C000001	
		19	90677-SE5-0030	NUT, CLIP 5mm	6	Y		20040817		KMYSA4BLS4C000001	
		20	90683-SE5-0030	CLIP, BODY COVER	2	Y		20040817		KMYSA4BLS4C000001	
		21	91411-BA6-9600	CLIP 2x90	1	Y		20040817		KMYSA4BLS4C000001	
		22	S3404-06016-08	BOLT, WASHER 6x16	2	Y		20040817		KMYSA4BLS4C000001	

F-18


CENTER COVER / BODY COVER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		23	S3891-05014-08	SCREW, WASHER 5x14	2	Y		20040817		KMYSA4BLS4C000001	
		24	S3903-24220	SCREW, TAPPING 4x10	3	Y		20040817		KMYSA4BLS4C000001	
		25	S3903-25280	SCREW, TAPPING 5x12	4	Y		20040817		KMYSA4BLS4C000001	

F-19


AIR CLEANER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
CLEANER ASS'Y, AIR	0.5	1	1122B-SA4-0000	TUBE B ASS'Y, BREATHER	1	Y	20040817		KMYSA4BLS4C000001	
		2	15772-BA7-0101	CLIP, BREATHER TUBE	2	N	20040817		KMYSA4BLS4C000001	
· DUCT A, AIR CLEANER INLET		3	17200-SA4-0000	CLEANER ASS'Y, AIR	1	Y	20040817		KMYSA4BLS4C000001	
· DUCT B, AIR CLEANER INLET		4	17209-SA4-0000	STAY COMP., AIR CLEANER B	1	Y	20040817		KMYSA4BLS4C000001	
· DUCT C, AIR CLEANER INLET		5	17211-SZ1-0000	ELEMENT COMP., AIR CLEANER	1	Y	20040817		KMYSA4BLS4C000001	
ELEMENT COMP., AIR CLEANER	0.3	6	17213-SZ1-0000	SEAL, AIR CLEANER COVER	1	N	20040817		KMYSA4BLS4C000001	
		7	17214-SZ1-0000	SEAL, ELEMENT	1	N	20040817		KMYSA4BLS4C000001	
COVER ASS'Y, AIR CLEANER	0.2	8	17230-SZ1-0000	COVER ASS'Y, AIR CLEANER	1	Y	20040817		KMYSA4BLS4C000001	
		9	17240-SZ1-0000	DUCT ASS'Y, AIR CLEANER INLET	1	Y	20040817		KMYSA4BLS4C000001	
		10	17241-SZ1-0000	DUCT A, AIR CLEANER INLET	1	Y	20040817		KMYSA4BLS4C000001	
		11	17242-SZ1-0000	DUCT B, AIR CLEANER INLET	1	Y	20040817		KMYSA4BLS4C000001	
		12	17243-SZ1-0000	DUCT C, AIR CLEANER INLET	1	Y	20040817		KMYSA4BLS4C000001	
		13	17358-BA7-0000	TUBE, DRAIN	1	N	20040817		KMYSA4BLS4C000001	
		14	1737A-SZ1-0000	TUBE ASS'Y, DRAIN	1	Y	20040817		KMYSA4BLS4C000001	
		15	17612-SZ1-0000	CLIP, TUBE	1	Y	20040817		KMYSA4BLS4C000001	
		16	17891-SZ1-0000	SCREW, SPECIAL 5x16	12	N	20040817		KMYSA4BLS4C000001	
		17	83807-SZ1-0000	COVER, AIR DUCT	1	Y	20040817		KMYSA4BLS4C000001	
		18	90853-SA4-0000	BAND B 47.5, AIR CLEANER CONNECTING TUBE	1	Y	20040817		KMYSA4BLS4C000001	
		19	S3404-06032-08	BOLT, WASHER 6x32	2	Y	20040817		KMYSA4BLS4C000001	

F-19


AIR CLEANER



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		20	S3903-24220	SCREW, TAPPING 4x10	3	Y		20040817		KMYSA4BLS4C000001	
		21	S5701-06012-08	BOLT, FLANGE 6x12	2	Y		20040817		KMYSA4BLS4C000001	

F-20


EXHAUST MUFFLER



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
MUFFLER COMP.	0.3	1	18200-SA4-RZ00	MUFFLER ASS'Y, EXHAUST	1	Y	20040817		KMYSA4BLS4C000001	
		2	18201-SA1-0000	COLLAR, MUFFLER PROTECTOR	5	Y	20040817		KMYSA4BLS4C000001	
PROTECTOR, MUFFLER	0.1	3	18202-SA1-0000	RUBBER, PROTECTOR	5	Y	20040817		KMYSA4BLS4C000001	
		4	18203-SA1-0000	COLLAR, MUFFLER MOUNT	3	Y	20040817		KMYSA4BLS4C000001	
PIPE COMP., EXHAUST	0.5	5	18204-SA1-0000	WASHER, MUFFLER MOUNT	3	Y	20040817		KMYSA4BLS4C000001	
		6	18205-SA1-0000	RUBBER, MUFFLER MOUNT	3	Y	20040817		KMYSA4BLS4C000001	
GASKET, EXHAUST PIPE		7	18210-SA4-RZ00	SUB ASS'Y, MUFFLER	1	Y	20040817		KMYSA4BLS4C000001	
		8	18240-SA4-0000	PROTECTOR, MUFFLER	1	N	20040817		KMYSA4BLS4C000001	
		9	18291-SE5-5000-EU	GASKET, EXHAUST PIPE	1	Y	20040817		KMYSA4BLS4C000001	
		10	18292-SA4-0000	GASKET, EXHAUST PIPE FLANGE	1	Y	20040817		KMYSA4BLS4C000001	
		11	18310-SA4-RZ01	MUFFLER COMP.	1	N	20040817		KMYSA4BLS4C000001	
		12	18320-SA4-0000	PIPE COMP., EXHAUST	1	Y	20040817		KMYSA4BLS4C000001	
		13	90002-SA1-0000	WASHER, TORUS SCREW 6x13	5	N	20040817		KMYSA4BLS4C000001	
		14	90304-BA7-0002	NUT, HEX CAP 6mm	3	Y	20040817		KMYSA4BLS4C000001	
		15	S4050-06080	NUT, FLANGE 6mm	2	Y	20040817		KMYSA4BLS4C000001	
		16	S5801-08035-08	BOLT, FLANGE 8x35	2	Y	20040817		KMYSA4BLS4C000001	
		17	S5801-08055-08	BOLT, FLANGE 8x55	1	Y	20040817		KMYSA4BLS4C000001	

F-21


STAND



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
STAND ASS'Y, MAIN	0.4	1	5050A-SA1-0100	STAND ASS'Y, MAIN	1	Y	20040817		KMYSA4BLS4C000001	
		2	50500-SA1-0101	STAND COMP., MAIN	1	N	20040817		KMYSA4BLS4C000001	
• SPRING SET, MAIN STAND		3	50504-SA1-0000	COLLAR, MAIN STAND	2	Y	20040817		KMYSA4BLS4C000001	
• STOPPER RUBBER, MAIN STAND		4	50505-SC1-0101	STOPPER RUBBER, STAND	1	Y	20040817		KMYSA4BLS4C000001	
• STAND COMP., MAIN		5	5052A-SE5-5000-EU	SPRING SET, MAIN STAND	1	Y	20040817		KMYSA4BLS4C000001	
BAR COMP., SIDE STAND	0.2	6	50520-SE5-5000-EU	SPRING, MAIN STAND OUTER	1	N	20040817		KMYSA4BLS4C000001	
		7	50521-SE5-5000-EU	SPRING, MAIN STAND INNER	1	N	20040817		KMYSA4BLS4C000001	
• SPRING SET, SIDE STAND		8	5053A-SE1-RB00	SPRING SET, SIDE STAND	1	Y	20040817		KMYSA4BLS4C000001	
		9	50530-SZ1-0000	BAR COMP., SIDE STAND	1	Y	20040817		KMYSA4BLS4C000001	
		10	50532-SE1-RB00	SPRING, SIDE STAND INNER	1	N	20040817		KMYSA4BLS4C000001	
		11	50533-SE1-RB00	SPRING, SIDE STAND OUTER	1	N	20040817		KMYSA4BLS4C000001	
		12	90108-SE5-0000	SCREW, SIDE STAND PIVOT	1	Y	20040817		KMYSA4BLS4C000001	
		13	S4001-10080-OS	NUT, HEX 10mm	1	Y	20040817		KMYSA4BLS4C000001	
		14	S4101-10800	WASHER, PLAIN 10mm	2	Y	20040817		KMYSA4BLS4C000001	
		15	S5801-10035-08	BOLT, FLANGE 10x35	2	Y	20040817		KMYSA4BLS4C000001	

F-22

REAR CUSHION




854-
70000@10-0000000000
COLL
QPR 125
CS400

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM.No	End FRM.No
CUSHION ASS'Y, RR. (ADD 0.2 FOR EACH)	0.4	1	52400-SA4-0000	CUSHION ASS'Y, RR.	2	Y		20040817		KMYSA4BLS4C000001	
		2	52401-SZ1-0000	SPRING, RR.CUSHION	1	N		20040817		KMYSA4BLS4C000001	
		3	52403-BA7-0000	METAL, UPPER	1	N		20040817		KMYSA4BLS4C000001	
DAMPER COMP., RR.	0.6	4	52410-SA4-0000	DAMPER COMP., RR.	1	N		20040817		KMYSA4BLS4C000001	
		5	52422-BA6-0032	ADJUSTER, SPRING	1	N		20040817		KMYSA4BLS4C000001	
		6	52485-SE5-0011-M1	BUSH, RR.CUSHION RUBBER	1	N		20040817		KMYSA4BLS4C000001	
		7	52486-SE5-0031	COLLAR, RUBBER BUSH	1	N		20040817		KMYSA4BLS4C000001	
		8	52517-BA6-0030	RUBBER, STOPPER	1	N		20040817		KMYSA4BLS4C000001	
		9	90108-CB3-0000	BOLT, RR.CUSHION UNDER	2	Y		20040817		KMYSA4BLS4C000001	
		10	S4002-10000-0S	NUT, HEX 10mm	1	N		20040817		KMYSA4BLS4C000001	

F-23


FRONT WINKER



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
WINKER ASS'Y, FR. (ADD 0.1 FOR EACH)	0.4	1	33400-SZ1-0000-M1	WINKER ASS'Y, RH.FR.	1	Y	20040817		KMYSA4BLS4C000001	
		2	33401-SZ1-0000	LENS, WINKER	1	Y	20040817		KMYSA4BLS4C000001	
		3	33402-SZ1-0000	REFLECTOR, WINKER	1	N	20040817		KMYSA4BLS4C000001	
LENS, WINKER(FOR EACH)	0.1	4	33410-SZ1-0000	SOCKET COMP., RH.WINKER	1	N	20040817		KMYSA4BLS4C000001	
SOCKET COMP., WINKER (ADD 0.1 FOR EACH)	0.4	5	33450-SZ1-0000-M1	WINKER ASS'Y, LH.FR.	1	Y	20040817		KMYSA4BLS4C000001	
		6	33451-SZ1-0000	LENS, WINKER	1	Y	20040817		KMYSA4BLS4C000001	
		7	33452-SZ1-0000	REFLECTOR, WINKER	1	N	20040817		KMYSA4BLS4C000001	
BULB, WINKER(12V 10W) (FOR EACH)	0.1	8	33460-SZ1-0000	SOCKET COMP., LH.WINKER	1	N	20040817		KMYSA4BLS4C000001	
		9	34905-SE4-0000	BULB, WINKER(12V 10W)	2	Y	20040817		KMYSA4BLS4C000001	
		10	S3903-34380	SCREW, TAPPING 4x12	6	N	20040817		KMYSA4BLS4C000001	
		11	S3903-44220	SCREW, TAPPING 4x10	4	N	20040817		KMYSA4BLS4C000001	

F-24


REAR COMBINATION LIGHT / REAR FENDER



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
LENS, RR. WINKER	0.1	1	33602-SZ1-0000	LENS, RH. RR. WINKER	1	Y	20040817		KMYSA4BLS4C000001	
		2	33652-SZ1-0000	LENS, LH. RR. WINKER	1	Y	20040817		KMYSA4BLS4C000001	
LENS, TAIL LIGHT	0.1	3	33700-SZ1-0000-M1	LIGHT ASS'Y, RR. COMBINATION	1	Y	20040817		KMYSA4BLS4C000001	
		4	33702-SZ1-0000	LENS, TAIL LIGHT	1	Y	20040817		KMYSA4BLS4C000001	
SOCKET COMP., RR. COMINATION	0.2	5	33703-SZ1-0000	SOCKET COMP., RR. COMBINATION	1	N	20040817		KMYSA4BLS4C000001	
LIGHT ASS'Y, RR. COMBINATION	0.5	6	33704-SZ1-0000	BASE, RR. COMBINATION	1	N	20040817		KMYSA4BLS4C000001	
		7	33710-SZ1-0000	PLATE ASS'Y, LICENSE	1	Y	20040817		KMYSA4BLS4C000001	
BLUB, WINKER(12V 10W)	0.1	8	33711-SE1-RB00	BASE, LICENSE LAMP	1	N	20040817		KMYSA4BLS4C000001	
		9	33712-SE1-RB00	LENS, LICENSE LAMP	1	N	20040817		KMYSA4BLS4C000001	
BLUB, TAIL & STOP(12V 21W/5W)	0.1	10	33715-SZ1-0000	SOCKET COMP., LICENSE LAMP	1	N	20040817		KMYSA4BLS4C000001	
SOCKET COMP., LICENSE LAMP	0.2	11	33741-SE5-RB00-M1	REFLECTOR, REFLEX	1	Y	20040817		KMYSA4BLS4C000001	
		12	34902-BA7-RB00	BULB, MARKER LIGHT(12V 4W)	1	Y	20040817		KMYSA4BLS4C000001	
BLUB, MARKER LIGHT(12V 4W)	0.1	13	34905-SE4-0000	BULB, WINKER(12V 10W)	2	Y	20040817		KMYSA4BLS4C000001	
		14	34906-BA7-RB00	BULB, TAIL & STOP(12V 21W/5W)	1	Y	20040817		KMYSA4BLS4C000001	
FENDER, RR.	0.5	15	8010A-SZ1-0000	FENDER ASS'Y, RR.	1	Y	20040817		KMYSA4BLS4C000001	
		16	80101-BA1-0001	RUBBER, LICENSE PLATE	1	Y	20040817		KMYSA4BLS4C000001	
		17	80105-SZ1-0001	FENDER, RR.	1	N	20040817		KMYSA4BLS4C000001	
		18	90677-SE5-0030	NUT, CLIP 5mm	4	Y	20040817		KMYSA4BLS4C000001	
		19	S3404-06012-08	BOLT, WASHER 6x12	4	Y	20040817		KMYSA4BLS4C000001	
		20	S3891-05010-18	SCREW, WASHER 5x10	2	Y	20040817		KMYSA4BLS4C000001	

F-24


REAR COMBINATION LIGHT / REAR FENDER



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
		21	S3891-05014-08	SCREW, WASHER 5x14	4	Y	20040817		KMYSA4BLS4C000001	
		22	S3901-24580	SCREW, TAPPING 4x20	2	N	20040817		KMYSA4BLS4C000001	
		23	S3903-34310	SCREW, TAPPING 4x12	2	N	20040817		KMYSA4BLS4C000001	
		24	S4050-06080	NUT, FLANGE 6mm	1	Y	20040817		KMYSA4BLS4C000001	

F-25


WIRE HARNESS / IGNITION COIL



Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM, No	End FRM, No
UNIT, CDI	0.3	1	17300-SA4-0000	AIR FILTER ASS'Y, SECONDARY	1	Y	20040817		KMYSA4BLS4C000001	
COIL ASS'Y, IGNITION	0.4	2	17620-BA4-0000-M1	CAP COMP., FUEL FILLER	1	N	20040817		KMYSA4BLS4C000001	
		3	30400-SA4-0000	UNIT ASS'Y, CDI	1	Y	20040817		KMYSA4BLS4C000001	
		4	30510-SA4-0000	COIL COMP., IGNITION	1	Y	20040817		KMYSA4BLS4C000001	
RECTIFIER COMP., REGULATOR	0.5	5	30700-BA7-9002	CAP ASS'Y, NOISE SUPPRESSOR	1	Y	20040817		KMYSA4BLS4C000001	
HARNESS, WIRE	1.6	6	31600-BA7-0000 31600SA40000AS	RECTIFIER ASS'Y, REGULATOR	1	Y	20040817		KMYSA4BLS4C000001	
SET, KEY	1.0	7	32100-SA4-0000	HARNESS, WIRE	1	Y	20040817		KMYSA4BLS4C000001	
		8	32401-SZ1-0000	CABLE, START MAGNETIC BATTERY(+)	1	Y	20040817		KMYSA4BLS4C000001	
		9	35010-SZ1-0000	SET, KEY	1	Y	20040817		KMYSA4BLS4C000001	
RESISTOR COMP., C	0.5	10	35100-SZ1-0000-M1	SWITCH ASS'Y, COMBINATION & LOCK	1	N	20040817		KMYSA4BLS4C000001	
SWITCH SET, START MAGNETIC	0.3	11	35111-SZ1-0000-M1	KEY COMP.	1	N	20040817		KMYSA4BLS4C000001	
		12	35121-SZ1-0000	KEY, BLANK	1	Y	20040817		KMYSA4BLS4C000001	
CABLE, START MAGNETIC BATTERY	0.2	13	3585A-SA4-0000	SWITCH SET, START MAGNETIC	1	Y	20040817		KMYSA4BLS4C000001	
		14	35850-SA1-0000	SWITCH ASS'Y, START MAGNETIC	1	Y	20040817		KMYSA4BLS4C000001	
HORN COMP.	0.5	15	35856-SA1-0001	RUBBER, MAGNETIC SHOCK	1	Y	20040817		KMYSA4BLS4C000001	
AIR FILTER ASS'Y, SECONDARY	0.5	16	38110-SZ1-0000	HORN COMP.	1	Y	20040817		KMYSA4BLS4C000001	
		17	90112-BA7-0000	BOLT, FLANGE 5X22	1	Y	20040817		KMYSA4BLS4C000001	
		18	90152-BA4-0000	BOLT, SOCKET 5x25	4	Y	20040817		KMYSA4BLS4C000001	
		19	S4002-06080-0S	NUT, HEX 6mm(Y)	2	Y	20040817		KMYSA4BLS4C000001	
		20	S4050-06080	NUT, FLANGE 6mm	3	Y	20040817		KMYSA4BLS4C000001	

F-25

WIRE HARNESS / IGNITION COIL




FR

Service Item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	End Date	Start FRM.No	End FRM.No
		21	S4101-06800	WASHER, PLAIN 6mm	1	Y	20040817		KWYSA4BLS4C000001	
		22	S4111-06800	WASHER, SPRING 6mm	1	Y	20040817		KWYSA4BLS4C000001	
		23	S6001-06020-00	BOLT, FLANGE SH. 6x20	3	Y	20040817		KWYSA4BLS4C000001	
		24	S8200-31500	FUSE, BLADE 15A	1	Y	20040817		KWYSA4BLS4C000001	

F-26

FRAME BODY




INTERCEPTOR CARTRIDGE LATERAL

Service item	FRT	Ref No.	Part No.	Description	QTY	A/S Exch	Start Date	En. Date	Start FRM, No	End FRM, No
SWITCH ASS'Y, SIDE STAND	0.3	1	17517-SZ1-0000	PLATE, TANK SUPPORT	1	Y	20040817		KMYSA4BLS4C000001	
		2	18323-BA7-RE00	RIVET, BLIND 3.2x8.5	2	N	20040817		KMYSA4BLS4C000001	
BODY COMP., FRAME	4.8	3	35700-BA6-0000-M2	SWITCH ASS'Y, SIDE STAND	1	Y	20040817		KMYSA4BLS4C000001	
		4	50100-SA4-0000	BODY COMP., FRAME	1	Y	20040817		KMYSA4BLS4C000001	
PIPE COMP., FR.TOP	0.6	5	50170-SA1-0000	PLATE COMP., ENGINE HANGER	1	N	20040817		KMYSA4BLS4C000001	
LINK ASS'Y, ENGINE HANGER	1.0	6	50180-SZ1-0000	STAY, TANK UNDER SUPPORT	1	Y	20040817		KMYSA4BLS4C000001	
		7	50350-SA1-0000	HANGER ASS'Y, ENGINE	1	Y	20040817		KMYSA4BLS4C000001	
PLATE, TANK SUPPORT	0.8	8	50351-SA1-0000	LINK, ENGINE HANGER	1	N	20040817		KMYSA4BLS4C000001	
		9	50352-SA1-0000	RUBBER, LINK STOPPER	2	Y	20040817		KMYSA4BLS4C000001	
STAY, TANK UNDER SUPPORT	0.8	10	50353-CB2-0000	BUSH, ENGINE HANGER RUBBER	2	Y	20040817		KMYSA4BLS4C000001	
		11	50354-SC1-0002	COLLAR, ENGINE HANGER	1	N	20040817		KMYSA4BLS4C000001	
		12	50355-SA1-0000	METAL, OIL LESS	2	Y	20040817		KMYSA4BLS4C000001	
		13	50356-SA1-0000	COLLAR, ENGINE HANGER PIVOT	1	N	20040817		KMYSA4BLS4C000001	
		14	50357-SA1-0000	BUSH A, ENGINE HANGER RUBBER	2	Y	20040817		KMYSA4BLS4C000001	
		15	64315-SA4-0000	PIPE COMP., FR.TOP	1	Y	20040817		KMYSA4BLS4C000001	
		16	87509-SA4-RB00	PLATE, MANUFACTURER'S DATA	1	N	20040817		KMYSA4BLS4C000001	
		17	90105-SB1-0000	BOLT, FLANGE 10x212	1	Y	20040817		KMYSA4BLS4C000001	
		18	90107-SA1-0001	BOLT, FLANGE 10x200	1	Y	20040817		KMYSA4BLS4C000001	
		19	90304-SE6-0000	NUT, U 10mm	2	Y	20040817		KMYSA4BLS4C000001	
		20	90441-SA1-0000	WASHER, THRU	4	N	20040817		KMYSA4BLS4C000001	

F-26


FRAME BODY



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM.No	End FRM.No
		21	91301-SA1-0000	O-RING 16.8x1.6	4	Y		20040817		KMYSA4BLS4C000001	
		22	S3892-05016-08	SCREW, WASHER 5x16	2	Y		20040817		KMYSA4BLS4C000001	
		23	S4050-06080	NUT, FLANGE 6mm	2	Y		20040817		KMYSA4BLS4C000001	
		24	S4510-17000	CIR CLIP, EXTERNAL 17mm	4	N		20040817		KMYSA4BLS4C000001	
		25	S5701-06012-08	BOLT, FLANGE 6x12	4	Y		20040817		KMYSA4BLS4C000001	
		26	S5701-08050-08	BOLT, FLANGE 8x50	2	Y		20040817		KMYSA4BLS4C000001	
		27	S5801-10035-08	BOLT, FLANGE 10x35	4	Y		20040817		KMYSA4BLS4C000001	

F-27

TOOL



Service item	FRT	Ref No.	Part No.	Description	QTY	A/S	Exch	Start Date	End Date	Start FRM, No	End FRM, No
		1	89010-SA2-RB00	TOOL SET	1	Y		20040817		KMYSA4BLS4C000001	

PART NO. APPLIED COUNTRY INDEX

EURO 2
RZ

Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country
[11000]				13321-SA1-0201-H1	E-18	9	RZ	15652-SA1-0001	E-16	11	RZ	17214-SZ1-0000	F-19	7	RZ
				13381-SA1-0100-H1	E-18	10	RZ	15772-BA7-0101	F-19	2	RZ	17230-SZ1-0000	F-19	8	RZ
11100-SA2-0000	E-16	1	RZ	[14000]				[16000]				17240-SZ1-0000	F-19	9	RZ
11191-SA1-0000-EU	E-17	1	RZ	14100-SA1-0100	E-04	2	RZ	16007-SA4-0000	E-19	1	RZ	17241-SZ1-0000	F-19	10	RZ
11200-SA2-0000	E-17	2	RZ	14200-SA1-RZ01	E-07	3	RZ	16008-SA4-0000	E-19	2	RZ	17242-SZ1-0000	F-19	11	RZ
11204-SA1-0000	E-14	1	RZ	14291-SA2-RZ00	E-03	5	RZ	16009-SA4-0000	E-19	3	RZ	17243-SZ1-0000	F-19	12	RZ
11204-SA1-0000	F-12	1	RZ	14311-SA4-0000-H1	E-18	11	RZ	16015-SA4-0000	E-19	4	RZ	17256-SA4-0000	E-03	15	RZ
11210-SA1-0000	E-17	3	RZ	14320-SA2-RZ00	E-03	6	RZ	16016-SA4-0000	E-19	5	RZ	17300-SA4-0000	F-25	1	RZ
1122A-SA4-0000	E-17	4	RZ	14401-SA0-0010-M1	E-05	1	RZ	16022-SA4-0000	E-19	6	RZ	17358-BA7-0000	F-19	13	RZ
1122B-SA4-0000	F-19	1	RZ	14431-SA1-0100	E-04	4	RZ	16024-SA4-0000	E-19	7	RZ	1737A-SZ1-0000	F-19	14	RZ
11330-SA2-RZ00	E-07	1	RZ	1443A-SA1-0101	E-04	3	RZ	16028-SA4-0000	E-19	8	RZ	17510-SZ1-0002	F-15	7	RZ
11332-BA7-9000	E-11	1	RZ	14441-SA1-0100	E-04	6	RZ	16031-SA4-0000	E-19	9	RZ	17514-SC1-9510-M1	F-15	8	RZ
11333-SA1-0101	E-16	2	RZ	1444A-SA1-0101	E-04	5	RZ	16033-SA4-0000	E-19	10	RZ	17517-SZ1-0000	F-26	1	RZ
11335-SA1-0000	E-16	3	RZ	14451-SA1-0000	E-04	7	RZ	16033-SA4-9000	E-19	11	RZ	1751A-SZ1-0000	F-15	6	RZ
11340-SA2-0000	E-11	2	RZ	14452-SA1-0000	E-04	8	RZ	16034-SA4-0000	E-19	12	RZ	1751B-SZ1-0000	F-06	1	RZ
11342-SA1-0000	E-11	3	RZ	14500-SA1-0001	E-05	2	RZ	16035-SA4-0000	E-19	13	RZ	17610-SZ1-0000	F-15	9	RZ
11394-SA1-0000-EU	E-07	2	RZ	14520-BA1-0000	E-05	3	RZ	16037-SA4-0000	E-19	14	RZ	17612-SZ1-0000	F-15	10	RZ
11396-SA1-0100-EU	E-11	4	RZ	14523-BA7-0000-EU	E-05	4	RZ	16042-SA4-0000	E-19	15	RZ	17612-SZ1-0000	F-19	15	RZ
[12000]				14531-SA1-0001	E-05	6	RZ	16050-SA4-0000	E-19	16	RZ	17615-SZ1-0000	F-15	11	RZ
12100-SA1-0010	E-06	1	RZ	1453A-SA1-0000	E-05	5	RZ	16070-SA4-0000	E-19	17	RZ	17620-BA4-0000-M1	F-25	2	RZ
12191-SA1-0000-EU	E-06	2	RZ	14550-SA1-0000	E-05	7	RZ	16070-SA4-9000	E-19	18	RZ	17681-SA4-0000	F-15	14	RZ
12200-SA4-0000	E-03	2	RZ	14711-SA1-0000	E-03	7	RZ	16080-SA4-0000	E-19	19	RZ	17683-SA4-0000	F-15	15	RZ
12209-BA6-0050	E-03	3	RZ	14721-SA1-0000	E-03	8	RZ	16080-SA4-9000	E-19	20	RZ	1768B-SZ1-0000	F-15	12	RZ
1220A-SA4-0000	E-03	1	RZ	14751-SA1-0100	E-03	9	RZ	16091-SA4-0000	E-19	21	RZ	1768C-SZ1-0000	F-15	13	RZ
12211-SA1-0100	E-04	1	RZ	14771-BA6-9601	E-03	10	RZ	16100-SA4-0000	E-19	22	RZ	17891-SZ1-0000	F-19	16	RZ
12251-SA1-0000	E-03	4	RZ	14775-SA1-0100	E-03	11	RZ	16101-SA4-0000	E-19	23	RZ	17910-SA4-0000	F-03	1	RZ
12300-SA2-RB00	E-02	1	RZ	14781-BA6-0000	E-03	12	RZ	16102-SA4-0000	E-19	24	RZ	[18000]			
12301-SA2-RB02	E-02	2	RZ	[15000]				16114-SA4-0000	E-19	25	RZ	18200-SA4-RZ00	F-20	1	RZ
12313-SA1-0000	E-02	3	RZ	15100-SA1-0100	E-09	1	RZ	16150-SA4-0000	E-19	26	RZ	18201-SA1-0000	F-20	2	RZ
12330-SA2-RB02	E-02	4	RZ	15111-SA1-0000	E-09	2	RZ	16182-SA4-0000	E-19	27	RZ	18202-SA1-0000	F-20	3	RZ
12361-SA0-0000	E-16	4	RZ	15113-SA1-0000	E-09	3	RZ	16199-SA4-0000	E-19	28	RZ	18203-SA1-0000	F-20	4	RZ
12391-SA2-RB01	E-02	5	RZ	15131-SA1-0200	E-09	4	RZ	16210-SA4-RZ00	E-03	14	RZ	18204-SA1-0000	F-20	5	RZ
12392-SA2-RB01	E-02	6	RZ	15133-SA1-0102	E-18	12	RZ	1621A-SA4-RZ00	E-03	13	RZ	18205-SA1-0000	F-20	6	RZ
12393-SA2-RB01	E-02	7	RZ	15136-SA1-0000	E-09	5	RZ	16700-SZ1-0000-M1	F-15	2	RZ	18210-SA4-RZ00	F-20	7	RZ
[13000]				15331-SA1-0000	E-09	7	RZ	1670A-SA4-0000	F-15	1	RZ	18240-SA4-0000	F-20	8	RZ
13000-SA4-0000	E-18	1	RZ	15332-SA1-0000	E-09	8	RZ	16910-CB2-9110-M1	F-15	4	RZ	18291-SE5-5000-EU	F-20	9	RZ
13101-SA1-0100	E-18	2	RZ	1533A-SA1-0000	E-09	6	RZ	16915-CB2-0000	F-15	5	RZ	18292-SA4-0000	F-20	10	RZ
13111-BA6-9300	E-18	3	RZ	15412-SA1-0001	E-16	5	RZ	1691A-SZ1-0000	F-15	3	RZ	18310-SA4-RZ00	F-20	11	RZ
13121-SA1-0000	E-18	4	RZ	15414-BA6-9600	E-16	6	RZ	[17000]				18320-SA4-0000	F-20	12	RZ
13131-SA1-0000	E-18	5	RZ	15415-SA1-0001	E-16	7	RZ	17200-SA4-0000	F-19	3	RZ	18323-BA7-RE00	F-26	2	RZ
13141-SA1-0000	E-18	6	RZ	15416-SA1-0000	E-16	8	RZ	17208-SA4-0000	E-11	5	RZ	[19000]			
13201-SA1-0100-H1	E-18	7	RZ	15421-BA6-0001	E-16	9	RZ	17209-SA4-0000	F-19	4	RZ	19010-SA1-0102	E-15	2	RZ
13310-SA1-0100-H1	E-18	8	RZ	15426-SA1-0000	E-16	10	RZ	17211-SZ1-0000	F-19	5	RZ	19011-SA1-0000	E-15	3	RZ
				15650-SA1-0000	E-02	8	RZ	17213-SZ1-0000	F-19	6	RZ	19012-SA1-0100	E-15	4	RZ

PART NO. APPLIED COUNTRY INDEX

Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country
1901A-SA1-0101	E-15	1	RZ	23430-SA2-0010	E-14	7	RZ	33451-SZ1-0000	F-23	6	RZ	37211-SZ1-0000	F-02	6	RZ
19100-SA2-0000	E-15	5	RZ	[28000]				33452-SZ1-0000	F-23	7	RZ	37212-SZ1-0000	F-02	7	RZ
19200-SA4-0000-M2	E-15	6	RZ	28101-SA2-0001	E-10	1	RZ	33460-SZ1-0000	F-23	8	RZ	37215-SZ1-0000	F-02	8	RZ
19510-SA1-0000	E-08	1	RZ	28102-SA1-0000	E-10	2	RZ	33602-SZ1-0000	F-24	1	RZ	37223-SA4-0000	F-02	9	RZ
19615-SA2-0001	E-01	1	RZ	28110-SA2-0000	E-10	3	RZ	33652-SZ1-0000	F-24	2	RZ	37305-BA6-0080	F-02	10	RZ
19620-SA4-0000	E-01	2	RZ	28117-SA1-0000	E-07	4	RZ	33700-SZ1-0000-M1	F-24	3	RZ	37800-SZ1-0001	F-15	16	RZ
19625-SA4-0000	E-01	3	RZ	28120-SA1-0131	E-10	5	RZ	33702-SZ1-0000	F-24	4	RZ	37801-SE5-7001	F-15	17	RZ
19630-SA4-0000	E-01	4	RZ	28128-SA1-0130	E-10	6	RZ	33703-SZ1-0000	F-24	5	RZ	[38000]			
19633-SA0-0000	E-01	5	RZ	2812A-SA1-0031	E-10	4	RZ	33704-SZ1-0000	F-24	6	RZ	38110-SZ1-0000	F-25	16	RZ
[21000]				28211-SA1-0001	E-12	8	RZ	33711-SE1-RB00	F-24	8	RZ	38301-BA6-0301-P	F-16	5	RZ
21301-SA1-0100	E-14	2	RZ	[30000]				33712-SE1-RB00	F-24	9	RZ	3830A-SE4-0001	F-16	4	RZ
21395-SA1-0000	E-14	3	RZ	30400-SA4-0000	F-25	3	RZ	33715-SZ1-0000	F-24	10	RZ	38500-BA4-0000	F-16	6	RZ
21396-SA1-0000	E-14	4	RZ	30510-SA4-0000	F-25	4	RZ	33741-SE5-RB00-M1	F-24	11	RZ	38501-SE6-9800	F-16	7	RZ
[22000]				30700-BA7-9002	F-25	5	RZ	33900-SA1-0102-M1	F-17	1	RZ	38506-BA4-0000	F-16	8	RZ
22100-SA2-0000	E-13	1	RZ	[31000]				[34000]				[42000]			
22102-SA1-0000	E-12	2	RZ	31100-SA2-RZ00	E-08	2	RZ	34901-SZ1-0000	F-01	5	RZ	42301-SA2-0001	F-12	3	RZ
22105-SA4-0000	E-12	3	RZ	31110-SA2-RZ00	E-08	3	RZ	34902-BA7-RB00	F-24	12	RZ	42304-SA2-0000	F-12	4	RZ
2210A-SA4-0000	E-12	1	RZ	31120-SA2-0000	E-08	4	RZ	34902-SA1-RB00	F-01	6	RZ	42305-SA2-0000	F-12	5	RZ
22110-SA1-0200	E-12	4	RZ	31200-SA4-0000	E-10	7	RZ	34905-SE4-0000	F-23	9	RZ	4230A-SA4-0000	F-12	2	RZ
22121-SA1-0102-EU	E-12	5	RZ	31210-SA2-0000	E-10	8	RZ	34905-SE4-0000	F-24	13	RZ	42600-SA4-0000	F-12	6	RZ
22131-SA1-0200	E-12	6	RZ	31500-BA4-0000-M1	F-16	1	RZ	34906-BA7-RB00	F-24	14	RZ	42601-SA2-0000-M3	F-12	7	RZ
22132-SA1-0200	E-12	7	RZ	31600-BA6-0001	F-25	6	RZ	34908-BA7-9000	F-02	1	RZ	42711-SA4-0000-M1	F-12	8	RZ
22300-SA2-0000	E-13	3	RZ	[32000]				34908-SA2-8710-M1	F-02	2	RZ	42753-BA7-0000	F-11	1	RZ
2230A-SA2-0000	E-13	2	RZ	32100-SA4-0000	F-25	7	RZ	[35000]				42753-BA7-0000	F-12	9	RZ
22350-SA1-0001	E-13	4	RZ	32401-SZ1-0000	F-25	8	RZ	35010-SZ1-0000	F-25	9	RZ	[43000]			
22401-SA1-0000	E-13	5	RZ	32410-SA4-0000	E-10	9	RZ	35100-SZ1-0000-M1	F-25	10	RZ	43352-BA5-9000-M1	F-10	1	RZ
22530-SA1-0001-EU	E-13	6	RZ	32601-SA4-0000	F-16	2	RZ	35111-SZ1-0000-M1	F-25	11	RZ	43352-SE6-9800	F-10	2	RZ
22804-SC1-0000	E-13	7	RZ	32964-SC1-0201	E-07	5	RZ	35121-SZ1-0000	F-25	12	RZ	43353-BA5-9000-M1	F-10	3	RZ
[23000]				[33000]				35150-SZ1-RB00-M1	F-03	2	RZ	43353-SE6-9800	F-10	4	RZ
23010-SA2-0030	E-13	9	RZ	33100-SZ1-0000-M1	F-01	1	RZ	35200-SZ1-0000	F-03	3	RZ	[44000]			
2301A-SA2-0030	E-13	8	RZ	33110-SZ1-0000	F-01	2	RZ	35340-SA2-0000	F-04	1	RZ	44301-SZ1-0000	F-11	2	RZ
23100-SA1-0000	E-13	10	RZ	33116-SZ1-0000	F-01	3	RZ	35340-SC1-6710-M1	F-04	2	RZ	44311-SZ1-0000	F-11	3	RZ
23200-SA2-0010	E-13	11	RZ	33130-SZ1-0000-M1	F-01	4	RZ	35700-BA6-0000-M1	F-26	3	RZ	44600-SZ1-0001	F-11	4	RZ
23210-SA2-0010	E-13	12	RZ	33400-SZ1-0000-M1	F-23	1	RZ	35850-SA1-0000	F-25	14	RZ	44601-SZ1-0000	F-11	5	RZ
23220-SA2-0010	E-13	13	RZ	33401-SZ1-0000	F-23	2	RZ	35856-SA1-0001	F-25	15	RZ	44620-SA2-0000	F-11	6	RZ
23225-SA2-0000	E-13	14	RZ	33402-SZ1-0000	F-23	3	RZ	35856-SE4-0000	F-16	3	RZ	44680-BA6-0100	F-11	7	RZ
23226-SC1-0000	E-13	15	RZ	33410-SZ1-0000	F-23	4	RZ	3585A-SA4-0000	F-25	13	RZ	44711-SZ1-0000-M1	F-11	8	RZ
23233-SA2-0000	E-13	16	RZ	33450-SZ1-0000-M1	F-23	5	RZ	[37000]				44800-SZ1-0000	F-11	9	RZ
23237-SA0-0000	E-13	17	RZ					37100-SA4-0000	F-02	3	RZ	44805-SZ1-0000	F-11	10	RZ
23238-SA2-0000	E-13	18	RZ					37202-SZ1-0000	F-02	4	RZ	44806-SZ1-0000	F-11	11	RZ
23411-SA1-0101	E-14	5	RZ					37210-SZ1-0000	F-02	5	RZ				
23420-SA1-0000-EU	E-14	6	RZ												

PART NO. APPLIED COUNTRY INDEX

Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country
44808-BA6-7010-Y1	F-11	12	RZ	45513-SZ1-0000	F-04	11	RZ	50614-SZ1-0000-XB	F-14	2	RZ	53214-CB2-9001	F-08	8	RZ
44830-SZ1-0000	F-02	11	RZ	45517-SZ1-0000	F-04	12	RZ	50621-SZ1-0001	F-14	3	RZ	53214-SZ1-0000	F-05	9	RZ
[45000]				45518-BA4-0000-M1	F-04	13	RZ	[51000]				53215-CB3-0000	F-08	9	RZ
				45520-SC1-0060	F-04	14	RZ					53215-SZ1-0000	F-06	2	RZ
45100-BA5-RB00	F-10	5	RZ	45521-SC1-0061	F-04	15	RZ	51400-SZ1-0001	F-09	1	RZ	5321A-SZ1-0000	F-05	7	RZ
45101-BA5-9000-M1	F-10	6	RZ	45530-SZ1-0000	F-04	16	RZ	51401-SZ1-0000	F-09	2	RZ	53220-CB3-0000	F-08	10	RZ
45105-BA5-RB10-M1	F-10	7	RZ	45600-SZ1-0000	F-04	17	RZ	51410-SZ1-0000	F-09	3	RZ	53220-CB3-7500	F-08	11	RZ
45105-BA7-0001-EU	F-10	8	RZ	45601-SZ1-0002	F-04	18	RZ	51412-BA5-9000	F-09	4	RZ	[61000]			
45106-BA5-RB10-M1	F-10	9	RZ	[46000]				51420-SZ1-0000	F-09	5	RZ				
45107-BA5-9000-M1	F-10	10	RZ					51425-BA5-9000	F-09	6	RZ	61100-SZ1-0000-SL	F-07	2	RZ
45107-BA6-0000	F-10	11	RZ	46200-SA2-RB00	F-10	37	RZ	51427-BA5-9000	F-09	7	RZ	61100-SZ1-0000-TR	F-07	2	RZ
45108-BA5-9000-M1	F-10	12	RZ	46210-SA2-0000	F-10	38	RZ	51432-BA5-9000	F-09	8	RZ	61100-SZ1-0000-XB	F-07	2	RZ
45108-SE6-9800	F-10	13	RZ	[50000]				51437-BA5-9000	F-09	9	RZ	61120-SA1-RB12-BK	F-18	1	RZ
45109-BA5-9000-M1	F-10	14	RZ					51440-SZ1-0000	F-09	10	RZ	61200-SZ1-0000-SL	F-06	3	RZ
45109-BA6-0000	F-10	15	RZ	50100-SA4-0000	F-26	4	RZ	51441-BA5-9000	F-09	11	RZ	61200-SZ1-0000-TR	F-06	3	RZ
45110-BA5-9000-M1	F-10	16	RZ	50170-SA1-0001	F-26	5	RZ	51500-SZ1-0001	F-09	12	RZ	61200-SZ1-0000-XB	F-06	3	RZ
45112-BA5-9000-M1	F-10	17	RZ	50180-SZ1-0000	F-26	6	RZ	51520-SZ1-0000	F-09	13	RZ	61310-SZ1-0001	F-06	4	RZ
45115-SE6-9800	F-10	18	RZ	50301-CB2-9002	F-08	1	RZ	[52000]				[64000]			
45116-BA6-0000	F-10	19	RZ	50302-CB2-9002	F-08	2	RZ								
45121-SZ1-0000	F-11	13	RZ	50306-CB3-0000	F-08	3	RZ	52400-SA4-0000	F-22	1	RZ	64301-SZ1-0000-SL	F-06	5	RZ
45126-SZ1-0000	F-04	3	RZ	50320-SA4-0000	F-16	9	RZ	52401-SZ1-0000	F-22	2	RZ	64301-SZ1-0000-TR	F-06	5	RZ
45131-BA5-9000-M1	F-10	20	RZ	50326-SZ1-0000	F-17	2	RZ	52403-BA7-9000	F-22	3	RZ	64301-SZ1-0000-XB	F-06	5	RZ
45131-SE6-9800	F-10	21	RZ	50350-SA1-0000	F-26	7	RZ	52410-SA4-0000	F-22	4	RZ	64310-SZ1-0001	F-14	5	RZ
45132-BA5-9000-M1	F-10	22	RZ	50351-SA1-0000	F-26	8	RZ	52422-BA6-0032	F-22	5	RZ	64311-SE1-RB00	F-14	6	RZ
45132-SE6-9800	F-10	23	RZ	50352-SA1-0000	F-26	9	RZ	52485-SE5-9011-M1	F-22	6	RZ	64315-SA4-0000	F-26	15	RZ
45133-BA5-9000-M1	F-10	24	RZ	50353-CB2-0000	F-26	10	RZ	52486-SE5-0031	F-22	7	RZ	6431A-SZ1-0000	F-14	4	RZ
45133-SE6-9800	F-10	25	RZ	50354-SC1-0002	F-26	11	RZ	52517-BA6-0030	F-22	8	RZ	64320-SZ1-0000	F-14	7	RZ
45134-SE6-9800	F-10	26	RZ	50355-SA1-0000	F-26	12	RZ	[53000]				64400-SZ1-0000-SL	F-06	7	RZ
45135-BA5-9000-M1	F-10	27	RZ	50356-SA1-0000	F-26	13	RZ					64400-SZ1-0000-TR	F-06	7	RZ
45146-SZ1-0001	F-04	4	RZ	50357-SA1-0000	F-26	14	RZ	53100-SZ1-0000	F-05	1	RZ	64400-SZ1-0000-XB	F-06	7	RZ
45147-SZ1-0000	F-04	5	RZ	50500-SA1-0101	F-21	2	RZ	53106-SZ1-0000	F-05	2	RZ	64409-SZ1-0000	F-06	8	RZ
45148-SA4-0000-M1	F-04	6	RZ	50504-SA1-0000	F-21	3	RZ	53125-CB2-9001	F-05	3	RZ	6440A-SZ1-0000-SL	F-06	6	RZ
45151-SA2-0000	F-04	7	RZ	50505-SC1-0101	F-21	4	RZ	53140-SZ1-0000	F-03	4	RZ	6440A-SZ1-0000-TR	F-06	6	RZ
45201-SA1-0000	F-10	28	RZ	5050A-SA1-0100	F-21	1	RZ	53141-SZ1-0000	F-03	5	RZ	6440A-SZ1-0000-XB	F-06	6	RZ
45203-BA5-9000-M1	F-10	29	RZ	50520-SE5-5000-EU	F-21	6	RZ	53166-BA4-0000	F-03	6	RZ	[77000]			
45209-BA5-9000-M1	F-10	30	RZ	50521-SE5-5000-EU	F-21	7	RZ	53175-SZ1-0000	F-04	19	RZ				
45209-BA6-0000	F-10	31	RZ	5052A-SE5-5000-EU	F-21	5	RZ	53178-SZ1-0000	F-04	20	RZ	77101-SZ1-0000	F-13	1	RZ
45215-BA5-9000-M1	F-10	32	RZ	50530-SZ1-0000	F-21	9	RZ	53200-SZ1-0001	F-08	4	RZ	77103-SZ1-0000	F-13	2	RZ
45215-BA6-0000	F-10	33	RZ	50532-SE1-RB00	F-21	10	RZ	53205-SZ1-0001	F-05	4	RZ	77106-SZ1-0000	F-13	3	RZ
45216-SE6-9800	F-10	34	RZ	50533-SE1-RB00	F-21	11	RZ	53206-SZ1-0001	F-05	5	RZ	77200-SZ1-0001	F-13	5	RZ
45217-BA6-0000	F-10	35	RZ	5053A-SE1-RB00	F-21	8	RZ	53207-SZ1-0002	F-05	6	RZ	7720A-SZ1-0000	F-13	4	RZ
45218-SE6-9800	F-10	36	RZ	50613-SZ1-0000-SL	F-14	1	RZ	53210-CB3-7500	F-08	5	RZ	77235-SZ1-0000	F-13	6	RZ
45351-SA2-0010-M1	F-12	10	RZ	50613-SZ1-0000-XB	F-14	1	RZ	53211-CB2-9002	F-08	6	RZ	77240-SZ1-0001	F-13	7	RZ
45451-BA6-9700	F-07	1	RZ	50614-SZ1-0000-SL	F-14	2	RZ	53212-CB2-9002	F-08	7	RZ	77300-SZ1-0000	F-13	8	RZ
45500-SZ1-0000	F-04	8	RZ	50614-SZ1-0000-XB	F-14	2	RZ	53213-SZ1-0000	F-05	8	RZ	77330-SZ1-0000	F-13	9	RZ
45501-SZ1-0002	F-04	9	RZ	50614-SZ1-0000-SL	F-14	2	RZ								
45512-BA6-0062-M1	F-04	10	RZ	50614-SZ1-0000-TR	F-14	2	RZ								

PART NO. APPLIED COUNTRY INDEX

Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country		
77331-SZ1-0000	F-13	10	RZ	83502-SZ1-0000-TR	F-18	7	RZ	[90000]				90192-SE3-0000	F-16	10	RZ		
77332-SZ1-0000	F-13	11	RZ	83502-SZ1-0000-XB	F-18	7	RZ					90192-SE3-0000	F-18	18	RZ		
77340-SZ1-0000	F-13	12	RZ	83503-SZ1-0000-SL	F-18	8	RZ					90201-SAO-0002	E-10	10	RZ		
77341-SZ1-0000	F-13	13	RZ	83503-SZ1-0000-TR	F-18	8	RZ		90001-SA1-0000	E-01	6	RZ	90202-SE5-0001	E-13	19	RZ	
77342-SZ1-0000	F-13	14	RZ	83503-SZ1-0000-XB	F-18	8	RZ		90001-SA4-0000	E-19	29	RZ	90206-CB2-0007	E-04	10	RZ	
[80000]				83506-SZ1-0001	F-18	9	RZ		90002-SA1-0000	F-20	13	RZ	90301-BA6-0032	E-09	9	RZ	
				83509-SZ1-0000	F-18	10	RZ		90005-BA7-9000	E-05	8	RZ	90301-SB1-0000	F-17	10	RZ	
				8350A-SZ1-0000-SL	F-18	5	RZ		90009-SA1-0001	E-16	12	RZ	90302-SA4-0032	F-06	20	RZ	
				8350A-SZ1-0000-TR	F-18	5	RZ		9000A-SE5-7501	E-02	9	RZ	90302-SE5-2001	F-05	14	RZ	
				8350A-SZ1-0000-XB	F-18	5	RZ		90011-SA4-0000	E-19	30	RZ	90302-SE5-2001	F-06	21	RZ	
				83600-SZ1-0000-SL	F-18	11	RZ		90011-SA4-9000	E-19	31	RZ	90304-BA7-0002	F-20	14	RZ	
				83600-SZ1-0000-TR	F-18	11	RZ		90012-CB2-0004	E-04	9	RZ	90304-SE6-0000	F-05	15	RZ	
				83600-SZ1-0000-XB	F-18	11	RZ		90031-SA1-0101	E-16	13	RZ	90304-SE6-0000	F-26	19	RZ	
				83606-SZ1-0001	F-18	12	RZ		90031-SA1-0101	E-17	5	RZ	90305-SE5-0000	F-12	13	RZ	
				83607-SZ1-0000	F-19	17	RZ		90084-CB2-8300	E-17	6	RZ	90305-SE5-1001	F-06	22	RZ	
							90091-BA7-0000	E-05	9	RZ	90305-SE5-1001	F-17	11	RZ			
[81000]				[87000]				90101-BA5-0000	F-10	39	RZ	90306-CB3-0000	F-11	15	RZ		
								90102-CB4-0000	F-13	15	RZ	90403-SAO-0100	E-10	11	RZ		
								90103-BA5-0000	F-13	16	RZ	90407-BA6-0002	E-15	8	RZ		
								90103-SAO-0000	E-14	8	RZ	90407-BA6-0002	E-17	7	RZ		
								90105-SB1-0000	F-26	17	RZ	90417-CB2-0002	E-09	10	RZ		
								90106-BA5-0001	F-12	11	RZ	90441-SA1-0000	F-26	20	RZ		
								90106-CB2-9000	F-05	12	RZ	90442-CB2-9100	E-13	20	RZ		
								90106-SC1-0000	F-11	14	RZ	90443-SA1-0001	E-16	14	RZ		
								90106-SE1-0000	F-13	17	RZ	90451-BA6-0002	E-14	9	RZ		
								90107-BA5-1000	F-03	9	RZ	90474-SAO-0000	E-14	10	RZ		
81100-SA1-0101	F-06	9	RZ					90107-SA1-0001	F-26	18	RZ	90502-SA1-0000	F-15	18	RZ		
81131-SZ1-0001	F-06	11	RZ	87121-SA4-RB00	F-18	13	RZ	90108-BA5-9001	E-01	7	RZ	90544-HD2-0002	F-09	16	RZ		
81132-SA2-0001	F-06	12	RZ	87123-SZ1-0001-SL	F-18	14	RZ	90108-CB3-0000	F-22	9	RZ	90545-BA6-0000	F-04	23	RZ		
81137-SZ1-0001	F-06	13	RZ	87123-SZ1-0001-TR	F-18	14	RZ	90108-SE5-0000	F-21	12	RZ	90601-BA5-9000	F-09	17	RZ		
8113A-SZ1-0000	F-06	10	RZ	87123-SZ1-0001-XB	F-18	14	RZ	90110-SE5-0001	F-07	3	RZ	90605-SAO-0001	E-13	21	RZ		
81147-SZ1-0001	F-06	14	RZ	87124-SZ1-0000	F-06	16	RZ	90110-SE5-0001	F-18	16	RZ	90653-SA4-0000	F-19	18	RZ		
81161-SZ1-0002	F-06	15	RZ	87150-SZ1-0000	F-05	10	RZ	90111-SE5-1000	F-01	7	RZ	90677-SE5-0030	F-06	23	RZ		
81218-SA1-RB00	F-17	3	RZ	87505-SA4-MA00	F-18	15	RZ	90111-SE5-1000	F-06	17	RZ	90677-SE5-0030	F-14	9	RZ		
81218-SE5-3000-B1	F-17	3	RZ	87505-SA4-RB00	F-18	15	RZ	90112-BA7-0000	F-25	17	RZ	90677-SE5-0030	F-18	19	RZ		
81218-SE5-RC00	F-17	3	RZ	87505-SA4-RC00	F-18	15	RZ	90114-BA6-0000	F-04	21	RZ	90677-SE5-0030	F-24	18	RZ		
81218-SE5-RE00	F-17	3	RZ	87505-SA4-RE00	F-18	15	RZ	90118-BA6-7210-M1	F-09	14	RZ	90683-SE5-0030	F-14	10	RZ		
81218-SE5-RJ00	F-17	3	RZ	87505-SA4-RJ00	F-18	15	RZ	90123-BA5-9000	F-09	15	RZ	90683-SE5-0030	F-18	20	RZ		
81250-SZ1-0001	F-17	5	RZ	87509-SA4-RB00	F-26	16	RZ	90124-CB4-0010	F-17	9	RZ	90701-CB2-0002	E-07	6	RZ		
81251-SZ1-0000	F-17	6	RZ	87560-SA1-MA00	F-05	11	RZ	90145-SA1-0002	E-15	7	RZ	90701-CB2-0002	E-11	6	RZ		
81255-SZ1-0000	F-17	7	RZ	87560-SA1-RC00	F-05	11	RZ	90145-SE5-0000	F-04	22	RZ	90701-CB2-0002	E-14	11	RZ		
8125A-SA4-MA00	F-17	4	RZ	87560-SA1-RE00	F-05	11	RZ	90152-BA4-0000	F-25	18	RZ	90741-BA6-9600	E-18	13	RZ		
8125A-SA4-RB00	F-17	4	RZ	87560-SA1-RJ00	F-05	11	RZ	90158-SZ1-0000	F-12	12	RZ	[91000]					
8125A-SA4-RC00	F-17	4	RZ	87565-SA4-RB00	F-17	8	RZ	90190-SC1-0000	F-06	18	RZ						
8125A-SA4-RE00	F-17	4	RZ	[88000]				90192-SB1-0000	F-14	8	RZ						
8125A-SA4-RJ00	F-17	4	RZ						90192-SB1-0000	F-18	17		RZ				
[83000]									90192-SE3-0000	F-05	13		RZ				
									90192-SE3-0000	F-06	19		RZ				
83500-SZ1-0000-SL	F-18	6	RZ		[89000]								91001-SA1-0000	E-13	22	RZ	
83500-SZ1-0000-TR	F-18	6	RZ									91002-SA1-0000	E-14	12	RZ		
83500-SZ1-0000-XB	F-18	6	RZ									91003-SAO-0001	E-17	8	RZ		
83502-SZ1-0000-SL	F-18	7	RZ														
				88110-SZ1-0002	F-03	7	RZ										
				88120-SZ1-0002	F-03	8	RZ										
				89010-SA2-RB00	F-27	1	RZ										

PART NO. APPLIED COUNTRY INDEX

Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country	Part No.	Block No.	Ref. No.	Applied country
91003-SA1-0100	E-14	13	RZ	S3500-SA1-0000-W1	E-08	5	RZ	S4050-06080	F-26	23	RZ	S6001-06028-00	E-14	16	RZ
91004-SAO-0020-M1	E-13	23	RZ	S3600-04012-1G	F-04	24	RZ	S4050-08080	E-04	11	RZ	S6001-06032-00	E-03	21	RZ
91004-SC1-7010-M1	E-17	9	RZ	S3600-06032-1A	E-09	12	RZ	S4050-12080	E-08	7	RZ	S6001-06032-00	E-07	11	RZ
91004-X10-0000	E-16	15	RZ	S3700-05016-0G	F-02	12	RZ	S4050-12080	E-12	10	RZ	S6001-06035-00	E-07	12	RZ
91009-SC1-0030	E-17	10	RZ	S3891-05010-18	F-24	20	RZ	S4050-12080	E-13	26	RZ	S6001-06035-00	E-14	17	RZ
91102-BA6-0030	E-18	14	RZ	S3891-05014-07	F-05	16	RZ	S4101-06800	F-25	21	RZ	S6001-06040-00	E-11	8	RZ
91104-SAO-0001-M1	E-10	12	RZ	S3891-05014-08	F-14	12	RZ	S4101-10800	F-21	14	RZ	S6001-06040-00	E-16	18	RZ
91105-BA6-0031	E-18	15	RZ	S3891-05014-08	F-18	23	RZ	S4111-06800	F-13	19	RZ	S6001-06045-00	E-07	13	RZ
91201-SA1-0000	E-07	7	RZ	S3891-05014-08	F-24	21	RZ	S4111-06800	F-25	22	RZ	S6001-06045-00	E-11	9	RZ
91202-SA1-0100	E-17	11	RZ	S3892-04008-10	F-02	13	RZ	S4111-08000	F-03	12	RZ	S6001-06045-00	E-14	18	RZ
91203-SA1-0000	E-14	14	RZ	S3892-04008-18	E-19	35	RZ	S4301-10160	E-03	18	RZ	S6001-06050-00	E-11	10	RZ
91204-SA1-0000	E-17	12	RZ	S3892-05016-08	F-26	22	RZ	S4301-10160	E-06	3	RZ	S6001-06055-00	E-10	15	RZ
91211-SE5-0130	E-13	24	RZ	S3892-05028-08	F-03	10	RZ	S4301-10160	E-17	15	RZ	S6001-06065-00	E-16	19	RZ
91212-SA1-0000	E-12	9	RZ	S3892-05045-08	F-03	11	RZ	S4510-17000	F-26	24	RZ	S6001-06065-00	E-17	17	RZ
91252-BA6-0030	F-11	16	RZ	S3893-04012-18	F-04	25	RZ	S4520-28000	E-13	27	RZ	S6001-06070-00	E-17	18	RZ
91255-BA5-9000	F-09	18	RZ	S3901-24580	F-24	22	RZ	S4601-15000	E-18	16	RZ	S6001-06145-00	E-03	22	RZ
91257-BA6-0031	F-12	14	RZ	S3903-24220	F-18	24	RZ	[S5000]				S6100-63020-00	E-14	19	RZ
91258-BA6-0061	F-11	17	RZ	S3903-24220	F-19	20	RZ	S5002-02080	F-15	20	RZ	S6100-63050-00	E-18	17	RZ
91301-SA1-0000	F-26	21	RZ	S3903-25280	F-05	17	RZ	S5002-02100	E-17	16	RZ	S6140-63010-10	F-11	18	RZ
91302-CB2-0205	E-16	16	RZ	S3903-25280	F-06	25	RZ	S5002-02100	F-15	21	RZ	S6150-63020-10	F-12	15	RZ
91302-SAO-0000	E-05	10	RZ	S3903-25280	F-18	25	RZ	S5002-02100	F-15	21	RZ	S6220-25118	E-09	13	RZ
91303-CB2-1000	E-17	13	RZ	S3903-25380	F-02	14	RZ	S5701-06012-08	F-04	28	RZ	S6700-08035-00	F-05	19	RZ
91303-SA1-0001	E-03	16	RZ	S3903-25380	F-14	13	RZ	S5701-06012-08	F-19	21	RZ	[S8000]			
91306-BA6-6900	E-05	11	RZ	S3903-25380	F-17	13	RZ	S5701-06016-08	F-15	22	RZ	S8059-58916-00	E-03	23	RZ
91309-BA6-0030	E-10	13	RZ	S3903-34120	E-11	7	RZ	S5701-06018-08	E-15	9	RZ	S8200-31500	F-16	12	RZ
91351-SE5-1000	E-13	25	RZ	S3903-34120	F-02	15	RZ	S5701-08016-08	E-14	15	RZ	S8200-31500	F-25	24	RZ
91356-BA5-9000	F-09	19	RZ	S3903-34310	F-24	23	RZ	S5701-08050-08	F-26	26	RZ	[S9000]			
91411-BA6-9600	F-18	21	RZ	S3903-34380	E-01	8	RZ	S5801-08025-08	F-10	40	RZ	S9101-SA4-0000	E-19	36	RZ
[S2000]				S3903-34380	F-05	18	RZ	S5801-08035-08	F-20	16	RZ	S9103-SA4-0000	E-19	37	RZ
S2800-12000	E-17	14	RZ	S3903-34380	F-06	26	RZ	S5801-08055-08	F-20	17	RZ				
S2900-06020-08	E-03	17	RZ	S3903-34380	F-23	10	RZ	S5801-10035-08	F-21	15	RZ				
[S3000]				S3903-44220	F-23	11	RZ	S5801-10035-08	F-26	27	RZ				
S3404-06012-08	F-16	11	RZ	S3903-45320	F-17	14	RZ	S5801-10045-08	F-08	12	RZ				
S3404-06012-08	F-24	19	RZ	S3904-35380	E-01	9	RZ	[S6000]				S6001-06012-00	E-07	8	RZ
S3404-06016-08	F-17	12	RZ	[S4000]				S6001-06012-00	E-08	8	RZ	S6001-06014-00	E-03	19	RZ
S3404-06016-08	F-18	22	RZ	S4001-10080-0S	F-21	13	RZ	S6001-06018-00	E-03	20	RZ	S6001-06018-00	E-07	9	RZ
S3404-06020-08	F-14	11	RZ	S4002-06080-0S	E-10	14	RZ	S6001-06020-00	E-02	10	RZ	S6001-06020-00	F-25	23	RZ
S3404-06032-08	F-19	19	RZ	S4002-06080-0S	F-25	19	RZ	S6001-06020-07	E-01	10	RZ	S6001-06022-00	E-07	10	RZ
S3500-04008-1H	E-19	32	RZ	S4002-10000-0S	F-22	10	RZ	S6001-06022-00	E-16	17	RZ				
S3500-04010-0A	E-09	11	RZ	S4050-06000	F-04	26	RZ								
S3500-04010-1H	E-19	33	RZ	S4050-06080	F-04	27	RZ								
S3500-04012-1H	E-19	34	RZ	S4050-06080	F-13	18	RZ								
S3500-05012-0H	E-08	6	RZ	S4050-06080	F-15	19	RZ								
S3500-05028-0H	F-06	24	RZ	S4050-06080	F-20	15	RZ								
				S4050-06080	F-24	24	RZ								
				S4050-06080	F-25	20	RZ								

PARTS NAME INDEX

Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.
[A]			BOLT, CYLINDER STUD	E-17	5	BOLT, FR.DISK 8x57	F-11	14	BULB, WEDGE BASE(12V 5W)	F-01	6
			BOLT, DRAIN PLUG 12mm	E-17	14	BOLT, FR.FORK	F-09	15	BULB, WINKER(12V 10W)	F-23	9
			BOLT, FLANGE 10x200	F-26	18	BOLT, HANDLE LEVER	F-04	21	BULB, WINKER(12V 10W)	F-24	13
			BOLT, FLANGE 10x212	F-26	17	BOLT, MASTER CYLINDER HOLDER	F-04	13	BUSH A, ENGINE HANGER RUBBER	F-26	14
			BOLT, FLANGE 10x35	F-21	15	BOLT, OIL 10x22	F-04	22	BUSH, ENGINE HANGER RUBBER	F-26	10
			BOLT, FLANGE 10x35	F-26	27	BOLT, OIL THROUGH 12mm	E-15	7	BUSH, GUIDE	F-09	7
			BOLT, FLANGE 10x45	F-08	12	BOLT, PILLION SEAT	F-13	3	BUSH, PIN	F-10	23
			BOLT, FLANGE 10x50	F-05	12	BOLT, PIN	F-10	21	BUSH, RR.CUSHION RUBBER	F-22	6
			BOLT, FLANGE 5X22	F-25	17	BOLT, PIN A(DC)	F-10	27	BUSH, RR.CUSHION UNDER RUBBER	E-14	1
			BOLT, FLANGE 6mm	F-01	7	BOLT, PIN(DC)	F-10	20	BUSH, RR.CUSHION UNDER RUBBER	F-12	1
			BOLT, FLANGE 6mm	F-06	17	BOLT, RR.CUSHION UNDER	F-22	9	BYSTARTER SET, AUTO	E-19	26
			BOLT, FLANGE 6x12	F-04	28	BOLT, SEAT HINGE	F-13	15	[C]		
			BOLT, FLANGE 6x12	F-19	21	BOLT, SOCKET 12mm	E-16	12			
			BOLT, FLANGE 6x12	F-26	25	BOLT, SOCKET 5x25	F-25	18			
			BOLT, FLANGE 6x16	E-05	9	BOLT, SOCKET 8mm	F-09	14	CABLE COMP., SPEEDOMETER	F-02	11
			BOLT, FLANGE 6x16	F-15	22	BOLT, SOCKET 8x35	F-05	19	CABLE COMP., THROTTLE	F-03	1
			BOLT, FLANGE 6x18	E-15	9	BOLT, SPECIAL 8mm	E-14	8	CABLE, BATTERY EARTH	F-16	2
			BOLT, FLANGE 8x16	E-14	15	BOLT, SPECIAL 8x24	F-13	17	CABLE, SEAT LOCK	F-13	7
			BOLT, FLANGE 8x25	F-10	40	BOLT, SPECIAL FLANGE 8x32	F-10	39	CABLE, START MAGNETIC BATTERY(+)	F-25	8
			BOLT, FLANGE 8x35	F-20	16	BOLT, SPECIAL FLANGE 8x35	F-03	9	CABLE, STARTER MOTOR	E-10	9
			BOLT, FLANGE 8x50	F-26	26	BOLT, SPECIAL FLANGE 8x45	F-12	12	CALIPER ASS'Y, LH.FR.	F-10	5
			BOLT, FLANGE 8x55	F-20	17	BOLT, STUD 6x20	E-03	17	CALIPER ASS'Y, RR.	F-10	37
			BOLT, FLANGE SH.6x12	E-07	8	BOLT, WASHER 5x16	F-05	14	CAP A, FLOOR PANEL	F-14	6
			BOLT, FLANGE SH.6x12	E-08	8	BOLT, WASHER 5x16	F-06	21	CAP ASS'Y, NOISE SUPPRESSOR	F-25	5
			BOLT, FLANGE SH.6x14	E-03	19	BOLT, WASHER 6x12	F-16	11	CAP ASS'Y, OIL FILLER	E-02	8
			BOLT, FLANGE SH.6x145	E-03	22	BOLT, WASHER 6x12	F-24	19	CAP COMP., FUEL FILLER	F-25	2
			BOLT, FLANGE SH.6x18	E-03	20	BOLT, WASHER 6x16	F-17	12	CAP COMP., UNIT SET	F-15	8
			BOLT, FLANGE SH.6x18	E-07	9	BOLT, WASHER 6x16	F-18	22	CAP, AC.GENERATOR	E-17	6
			BOLT, FLANGE SH.6x20	E-01	10	BOLT, WASHER 6x20	F-14	11	CAP, BLEEDER	F-10	4
			BOLT, FLANGE SH.6x20	E-02	10	BOLT, WASHER 6x32	F-19	19	CAP, BLEEDER(DC)	F-10	3
			BOLT, FLANGE SH.6x20	F-25	23	BOOT, PIN	F-10	25	CAP, HOLDER	E-19	1
			BOLT, FLANGE SH.6x22	E-07	10	BOOT, PIN BUSH(DC)	F-10	22	CAP, LH.RR.GRIP FR.	F-13	13
			BOLT, FLANGE SH.6x28	E-16	17	BOOT, PIN(DC)	F-10	24	CAP, LH.RR.GRIP RR.	F-13	14
			BOLT, FLANGE SH.6x32	E-14	16	BOSS, DRIVE FACE	E-12	3	CAP, NUMBERING	F-06	12
			BOLT, FLANGE SH.6x32	E-03	21	BOX ASS'Y, BATTERY	F-16	9	CAP, OIL CUP	F-04	11
			BOLT, FLANGE SH.6x32	E-07	11	BOX ASS'Y, LUGGAGE(ENGLISH)	F-17	4	CAP, RH.RR.GRIP FR.	F-13	10
			BOLT, FLANGE SH.6x35	E-07	12	BOX ASS'Y, LUGGAGE(FRENCH)	F-17	4	CAP, RH.RR.GRIP RR.	F-13	11
			BOLT, FLANGE SH.6x35	E-14	17	BOX ASS'Y, LUGGAGE(GERMAN)	F-17	4	CAP, SEALING	E-19	12
			BOLT, FLANGE SH.6x40	E-11	8	BOX ASS'Y, LUGGAGE(ITALIAN)	F-17	4	CAP, TAPPET ADJUSTING HOLE	E-16	4
			BOLT, FLANGE SH.6x40	E-16	18	BOX ASS'Y, LUGGAGE(SPANISH)	F-17	4	CARBURETOR ASS'Y	E-19	22
			BOLT, FLANGE SH.6x45	E-07	13	BOX ASS'Y, SPEEDOMETER GEAR	F-11	9	CASE COMP., LH.CRANK	E-17	2
			BOLT, FLANGE SH.6x45	E-11	9	BOX, LUGGAGE	F-17	5	CASE COMP., RH.CRANK	E-16	1
			BOLT, FLANGE SH.6x45	E-14	18	BRACKET, CALIPER(DC)	F-10	16	CASE, LH.BOTTOM	F-09	13
			BOLT, FLANGE SH.6x50	E-11	10	BRACKET, RR.CALIPER	F-10	38	CASE, METER	F-02	6
			BOLT, FLANGE SH.6x55	E-10	15	BULB, HEAD LIGHT(12V 55W)	F-01	5	CASE, RH.BOTTOM	F-09	5
			BOLT, FLANGE SH.6x65	E-16	19	BULB, MARKER LIGHT(12V 4W)	F-24	12	CATCH COMP., SEAT	F-13	6
			BOLT, FLANGE SH.6x65	E-17	17	BULB, TAIL & STOP(12V 21W/5W)	F-24	14	CHAIN, CAM	E-05	1
			BOLT, FLANGE SH.6x70	E-17	18	BULB, WEDGE BASE	F-02	1	CHAMBER SET, FLOAT	E-19	4
			BOLT, FR.DISK 8x24	F-12	11	BULB, WEDGE BASE(12V 1.7W)	F-02	2	CIR CLIP 9mm	E-13	21
[B]											
BALL ASS'Y, STEERING UNDER	F-08	11									
BALL ASS'Y, STEERING UPPER	F-08	5									
BAND 47, CARBURETOR INSULATOR	E-03	15									
BAND B 47.5, AIR CLEANER CONNECTING	F-19	18									
BAR COMP., SIDE STAND	F-21	9									
BASE, LICENSE LAMP	F-24	8									
BASE, RR.COMBINATION	F-24	6									
BATTERY 12V 10A(MF)	F-16	1									
BEARING, BALL 6302	E-14	19									
BEARING, NEEDLE	E-13	22									
BEARING, NEEDLE 15x25x12	E-14	12									
BEARING, NEEDLE K28x32x17SV1	E-10	12									
BEARING, RADIAL BALL 6004UU	E-17	10									
BEARING, RADIAL BALL 6203 TMB	E-17	9									
BEARING, RADIAL BALL 63/22 TMB	E-14	13									
BEARING, RADIAL BALL 6301 TMB	E-17	8									
BEARING, RADIAL BALL 6301U	F-11	18									
BEARING, RADIAL BALL 6302UU	F-12	15									
BEARING, RADIAL BALL 6305	E-16	15									
BEARING, RADIAL BALL 6305	E-18	17									
BEARING, RADIAL BALL 6902U	E-13	23									
BELT, DRIVE	E-13	10									
BLEEDER(DC)	F-10	1									
BODY ASS'Y, FUEL PUMP	F-15	2									
BODY ASS'Y, SPEEDOMETER	F-02	5									
BODY COMP., FRAME	F-26	4									
BODY, CALIPER	F-10	28									
BODY, CALIPER(DC)	F-10	6									
BODY, FR.MASTER CYLINDER	F-04	9									
BODY, OIL PUMP	E-09	2									
BODY, RR.MASTER CYLINDER	F-04	18									
BOLT ASS'Y, SPECIAL 6x28	E-02	9									
BOLT, CYLINDER STUD	E-16	13									

PARTS NAME INDEX

Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.
CIR CLIP, EXTERNAL 17mm	F-26	24	COVER ASS'Y, CENTER(SPANISH)	F-18	3	COVER, UNDER	F-14	3	[G]		
CIR CLIP, INTERNAL 28mm	E-13	27	COVER ASS'Y, CYLINDER HEAD	E-02	1	COVER, UPPER HANDLE	F-05	4			
CLAMP, BRAKE HOSE	F-04	7	COVER ASS'Y, FAN	E-01	1	CUSHION ASS'Y, RR.	F-22	1			
CLAMP, CORD	E-07	5	COVER ASS'Y, INNER	F-06	10	CYLINDER ASS'Y, FR.MASTER	F-04	8		GASKET, CRANK CASE	E-17 1
CLAMP, CORD	F-02	8	COVER ASS'Y, LH.CRANK CASE	E-11	2	CYLINDER ASS'Y, RR.MASTER	F-04	17		GASKET, CYLINDER	E-06 2
CLAMPER, BREATHER TUBE	E-11	1	COVER ASS'Y, RR.UPPER(G/BLUE)	F-18	5	CYLINDER COMP.	E-06	1		GASKET, CYLINDER HEAD	E-03 4
CLEANER ASS'Y, AIR	F-19	3	COVER ASS'Y, RR.UPPER(O/RED)	F-18	5	CYLINDER SET, MASTER	F-04	16		GASKET, CYLINDER HEAD COVER	E-02 3
CLIP 2x90	F-18	21	COVER ASS'Y, RR.UPPER(SILVER)	F-18	5					GASKET, CYLINDER HEAD SIDE COVER	E-02 5
CLIP, B10 TUBE	E-17	16	COVER B, FR.UNDER(G/BLUE)	F-06	3	[D]				GASKET, EXHAUST PIPE	F-20 9
CLIP, B10 TUBE	F-15	21	COVER B, FR.UNDER(O/RED)	F-06	3					GASKET, EXHAUST PIPE FLANGE	F-20 10
CLIP, B8 TUBE	F-15	20	COVER B, FR.UNDER(SILVER)	F-06	3	DAMPER COMP., RR.	F-22	4		GASKET, LH.COVER	E-11 4
CLIP, BODY COVER	F-14	10	COVER COMP., CYLINDER HEAD SIDE	E-02	4	DIAPHRAGM	F-04	14		GASKET, RH.COVER	E-07 2
CLIP, BODY COVER	F-18	20	COVER COMP., OIL FILTER	E-16	2	DIAPHRAGM COMP.	E-19	19		GASKET, SAI PIPE	E-03 5
CLIP, BREATHER TUBE	F-19	2	COVER COMP., RH.CRANK CASE	E-07	1	DIAPHRAGM COMP.	E-19	20		GASKET, TENSIONER LIFTER	E-05 4
CLIP, PISTON PIN 15mm	E-18	16	COVER, AIR DUCT	F-19	17	DISK, FR.BRAKE	F-11	13		GEAR COMP., STARTER DRIVEN	E-10 3
CLIP, TUBE	F-15	10	COVER, BATTERY	F-17	2	DISK, RR.BRAKE	F-12	10		GEAR, OIL PUMP DRIVE	E-18 12
CLIP, TUBE	F-19	15	COVER, CARBURETOR MAINTENANCE	F-17	6	DUCT A, AIR CLEANER INLET	F-19	10		GEAR, OIL PUMP DRIVEN	E-09 4
COIL COMP., IGNITION	F-25	4	COVER, CENTER	F-18	4	DUCT ASS'Y, AIR CLEANER INLET	F-19	9		GEAR, SPEEDOMETER	F-11 11
COLLAR, ENGINE HANGER	F-26	11	COVER, CYLINDER HEAD	E-02	2	DUCT B, AIR CLEANER INLET	F-19	11		GEAR, STARTER REDUCTION	E-10 1
COLLAR, ENGINE HANGER PIVOT	F-26	13	COVER, DUST	F-01	3	DUCT C, AIR CLEANER INLET	F-19	12		GLASS COMP., OIL SIGHT	E-17 3
COLLAR, FR.DISTANCE	F-11	6	COVER, ENGINE COOLANT	F-06	15				[E]	GRILLE, LH.INNER COVER	F-06 14
COLLAR, FR.WHEEL SIDE	F-11	3	COVER, FR.(G/BLUE)	F-06	5					GRILLE, RH.INNER COVER	F-06 13
COLLAR, HANDLE SETTING	F-05	3	COVER, FR.(O/RED)	F-06	5					GRIP COMP., RH.	F-03 4
COLLAR, MAIN STAND	F-21	3	COVER, FR.(SILVER)	F-06	5	ELEMENT A, SIDE COVER	E-02	6		GRIP, LH.HANDLE	F-03 6
COLLAR, MUFFLER MOUNT	F-20	4	COVER, INNER	F-06	11	ELEMENT B, SIDE COVER	E-02	7		GRIP, LH.RR.	F-13 12
COLLAR, MUFFLER PROTECTOR	F-20	2	COVER, LH.BODY SIDE	F-18	12	ELEMENT COMP., AIR CLEANER	F-19	5		GRIP, RH.RR.	F-13 9
COLLAR, OIL PICK UP	E-16	11	COVER, LH.BODY(G/BLUE)	F-18	11	ELEMENT, OIL FILTER	E-16	5		GROMMET, SHROUD B	E-01 5
COLLAR, RADIATOR	E-15	3	COVER, LH.BODY(O/RED)	F-18	11					GROMMET, WIRE	F-07 1
COLLAR, RR.WHEEL INSIDE	F-12	4	COVER, LH.BODY(SILVER)	F-18	11					GUIDE RUBBER, MISSION COVER	E-14 4
COLLAR, RR.WHEEL OUTSIDE	F-12	5	COVER, LH.FLOOR SIDE(G/BLUE)	F-14	2					GUIDE, CAM CHAIN	E-05 7
COLLAR, RUBBER BUSH	F-22	7	COVER, LH.FLOOR SIDE(O/RED)	F-14	2				[F]		
COLLAR, SEAL	E-13	17	COVER, LH.FLOOR SIDE(SILVER)	F-14	2	FACE ASS'Y, DRIVEN	E-13	11			
COLLAR, SEAT MOUNT	F-13	1	COVER, LH.UNDER HANDLE	F-05	6	FACE ASS'Y, MOVABLE DRIVE	E-12	1			
COLLAR, SPRING	E-13	18	COVER, LH.UNDER HANDLE	F-05	6	FACE COMP., DRIVEN	E-13	12			
CONTROL LABEL, ANTI-TAMPERING	F-17	8	COVER, METER	F-06	4	FACE COMP., MOVABLE DRIVE	E-12	4		HANDLE COMP., STEERING	F-05 1
COTTER, VALVE	E-03	12	COVER, RH.BODY SIDE	F-18	9	FACE COMP., MOVABLE DRIVEN	E-13	13		HANGER ASS'Y, ENGINE	F-26 7
COVER	E-19	17	COVER, RH.BODY(G/BLUE)	F-18	6	FACE, DRIVE	E-12	2		HARNES, WIRE	F-25 7
COVER	E-19	18	COVER, RH.BODY(O/RED)	F-18	6	FAN COMP., COOLING	E-08	1		HEAD ASS'Y, CYLINDER	E-03 1
COVER	E-19	18	COVER, RH.BODY(SILVER)	F-18	6	FENDER ASS'Y, RR.	F-24	15		HEAD COMP., CYLINDER	E-03 2
COVER A ASS'Y, FR.UNDER(G/BLUE)	F-06	6	COVER, RH.FLOOR SIDE(G/BLUE)	F-14	1	FENDER, FR.(G/BLUE)	F-07	2		HINGE B, SEAT	F-13 2
COVER A ASS'Y, FR.UNDER(O/RED)	F-06	6	COVER, RH.FLOOR SIDE(O/RED)	F-14	1	FENDER, FR.(O/RED)	F-07	2		HOLDER COMP., BAG	F-06 9
COVER A ASS'Y, FR.UNDER(SILVER)	F-06	6	COVER, RH.FLOOR SIDE(SILVER)	F-14	1	FENDER, FR.(SILVER)	F-07	2		HOLDER, CAM SHAFT	E-04 1
COVER A, FR.UNDER(G/BLUE)	F-06	7	COVER, RH.UNDER HANDLE	F-05	5	FENDER, RR.	F-24	17		HOLDER, MASTER CYLINDER	F-04 12
COVER A, FR.UNDER(O/RED)	F-06	7	COVER, RR.UNDER(G/BLUE)	F-18	8	FLANGE, STARTING CLUTCH(I.S)	E-10	6		HOLDER, NEEDLE JET	E-19 23
COVER A, FR.UNDER(SILVER)	F-06	7	COVER, RR.UNDER(O/RED)	F-18	8	FLOAT COMP.	E-19	16		HORN COMP.	F-25 16
COVER ASS'Y, AIR CLEANER	F-19	8	COVER, RR.UNDER(SILVER)	F-18	8	FLYWHEEL COMP.	E-08	3		HOSE A ASS'Y, RR.BRAKE	F-04 5
COVER ASS'Y, CENTER(ENGLISH)	F-18	3	COVER, RR.UPPER(G/BLUE)	F-18	7	FORK ASS'Y, LH.FR.	F-09	12		HOSE ASS'Y, RADIATOR LH.	E-15 6
COVER ASS'Y, CENTER(FRENCH)	F-18	3	COVER, RR.UPPER(O/RED)	F-18	7	FORK ASS'Y, RH.FR.	F-09	1		HOSE ASS'Y, RADIATOR RH.	E-15 5
COVER ASS'Y, CENTER(GERMAN)	F-18	3	COVER, RR.UPPER(SILVER)	F-18	7	FUSE, BLADE 15A	F-16	12		HOSE B ASS'Y, RR.BRAKE	F-04 6
COVER ASS'Y, CENTER(ITALIAN)	F-18	3	COVER, TRANSMISSION	E-14	2	FUSE, BLADE 15A	F-25	24		HOSE COMP., FR.BRAKE	F-04 3

PARTS NAME INDEX

Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.
HOSE PIPE, RR.BRAKE	F-04	4	MARK, DRIVE CAUTION(ENGLISH)	F-05	11	NUT, HEX CAP 6mm	F-20	14	PIN, SPECIAL DOWEL 8x14	E-11	6
[I]			MARK, DRIVE CAUTION(FRENCH)	F-05	11	NUT, LOCK 22mm	E-10	10	PIN, SPECIAL DOWEL 8x14	E-14	11
INSULATOR ASS'Y, CARBURETOR	E-03	13	MARK, DRIVE CAUTION(GERMAN)	F-05	11	NUT, OPEN STAY 6mm	F-17	10	PINION, SPEEDOMETER	F-11	10
INSURATOR COMP., CARBURETOR	E-03	14	MARK, DRIVE CAUTION(ITALIAN)	F-05	11	NUT, SPECIAL 28mm	E-13	19	PIPE COMP., EXHAUST	F-20	12
[J]			MARK, DRIVE CAUTION(SPANISH)	F-05	11	NUT, SPRING 4mm	F-06	20	PIPE COMP., FORK	F-09	3
JET, MAIN #102	E-19	36	MARK, FR.COVER	F-06	16	NUT, STEERING STEM LOCK	F-08	3	PIPE COMP., FR.TOP	F-26	15
JET, NEEDLE	E-19	24	MARK, HANDLE COVER	F-05	10	NUT, TAPPET ADJUSTING	E-04	10	PIPE COMP., SAI	E-03	6
JET, SLOW	E-19	37	MARK, RR.UNDER COVER(G/BUE)	F-18	14	NUT, U 10mm	F-05	15	PIPE, SEAT	F-09	10
[K]			MARK, RR.UNDER COVER(O/RED)	F-18	14	NUT, U 10mm	F-26	19	PIPE, THROTTLE GRIP	F-03	5
KEY COMP.	F-25	11	MARK, RR.UNDER COVER(SILVER)	F-18	14	NUT, U 14mm	F-12	13	PISTON	E-18	2
KEY, BLANK	F-25	12	MAT, FLOOR	F-14	7	NUT, U 6mm	E-09	9	PISTON	F-10	11
KEY, WOODRUFF 25x14x4	E-18	13	METAL, OIL LESS	F-26	12	[O]			PISTON COMP., VACUUM	E-19	7
[L]			METAL, UPPER	F-22	3	ONEWAY CLUTCH ASS'Y, START(I.S)	E-10	5	PISTON(DC)	F-10	10
LABEL, LUGGAGE BOX CAUTION(ENGLISH)	F-17	3	METER ASS'Y, COMBINATION	F-02	3	ONEWAY CLUTCH SET, STARTER(I.S)	E-10	4	PIVOT ASS'Y, CAM CHAIN TENSIONER	E-05	5
LABEL, LUGGAGE BOX CAUTION(FRENCH)	F-17	3	MIRROR ASS'Y, LH.BACK	F-03	8	O-RING	F-09	19	PIVOT, CAM CHAIN TENSIONER	E-05	6
LABEL, LUGGAGE BOX CAUTION(GERMAN)	F-17	3	MIRROR ASS'Y, RH.BACK	F-03	7	O-RING 1.5x9.5	E-05	11	PLATE ASS'Y, DRIVE	E-13	3
LABEL, LUGGAGE BOX CAUTION(ITALIAN)	F-17	3	MOTOR ASS'Y, STARTER	E-10	7	O-RING 13.8x2.5	E-17	13	PLATE ASS'Y, LICENSE	F-24	7
LABEL, LUGGAGE BOX CAUTION(SPANISH)	F-17	3	MOTOR UNIT, STARTER	E-10	8	O-RING 15.2x1.5	E-05	10	PLATE COMP., DRIVE	E-13	4
LABEL, TIRE(ENGLISH)	F-18	15	MUDGUARD, RR.WHEEL(BLACK)	F-18	1	O-RING 16.8x1.6	F-26	21	PLATE COMP., ENGINE HANGER	F-26	5
LABEL, TIRE(FRENCH)	F-18	15	MUFFLER ASS'Y, EXHAUST	F-20	1	O-RING 24.4x3.1	E-10	13	PLATE SET, STAY	E-19	13
LABEL, TIRE(GERMAN)	F-18	15	MUFFLER COMP.	F-20	11	O-RING 29.5x3	E-03	16	PLATE SET, VALVE	E-19	25
LABEL, TIRE(ITALIAN)	F-18	15	[N]			O-RING 30.8mm	E-16	16	PLATE UNIT, DRIVE	E-13	2
LABEL, TIRE(SPANISH)	F-18	15	NECK ASS'Y, FUEL CAP	F-06	1	O-RING 38.5x2	E-13	25	PLATE, DIAPHRAGM	F-04	15
LAMP, TRUNK	F-17	1	NEEDLE COMP., JET	E-19	6	OUTER, CLUTCH	E-13	1	PLATE, MANUFACTURER'S DATA	F-26	16
LENS, LH.RR.WINKER	F-24	2	NUT, CLIP 5mm	F-06	23	[P]			PLATE, OIL PUMP	E-09	3
LENS, LICENSE LAMP	F-24	9	NUT, CLIP 5mm	F-14	9	PACKING, BASE	F-15	17	PLATE, RAMP	E-12	6
LENS, METER	F-02	4	NUT, CLIP 5mm	F-18	19	PACKING, DRAIN COCK 12.5x20	E-15	8	PLATE, REFLECTING	F-02	7
LENS, RH.RR.WINKER	F-24	1	NUT, CLIP 6mm	F-24	18	PACKING, DRAIN COCK 12.5x20	E-17	7	PLATE, SPLASH GUARD	F-18	2
LENS, TAIL LIGHT	F-24	4	NUT, CLIP 6mm	F-06	22	PAD COMP.	F-10	8	PLATE, START DRIVEN GEAR SETTING	E-07	4
LENS, WINKER	F-23	2	NUT, FLANGE 12mm	F-17	11	PAD COMP. A(DC)	F-10	7	PLATE, STAY	E-19	15
LENS, WINKER	F-23	6	NUT, FLANGE 12mm	E-08	7	PAD COMP. B(DC)	F-10	9	PLATE, TANK SUPPORT	F-26	1
LEVER, LH.STEERING HANDLE	F-04	20	NUT, FLANGE 12mm	F-11	15	PANEL, FLOOR	F-14	5	PLUG, DUST	F-10	26
LEVER, RH.STEERING HANDLE	F-04	19	NUT, FLANGE 6mm	F-04	26	PIECE, OIL LOCK	F-09	8	PLUG, PIN(DC)	F-10	29
LIFTER ASS'Y, TENSIONER	E-05	3	NUT, FLANGE 6mm	F-04	27	PIECE, SLIDE	E-12	7	PLUG, SPARK CRBEH-9	E-03	23
LIGHT ASS'Y, HEAD	F-01	1	NUT, FLANGE 6mm	F-13	18	PIN, ARM	E-19	9	PROTECTOR(DC)	F-04	10
LIGHT ASS'Y, RR.COMBINATION	F-24	3	NUT, FLANGE 6mm	F-15	19	PIN, CRANK	E-18	10	PROTECTOR, MUFFLER	F-20	8
LINK, ENGINE HANGER	F-26	8	NUT, FLANGE 6mm	F-20	15	PIN, DOWEL 10x16	E-03	18	PULLEY ASS'Y, DRIVEN	E-13	9
[M]			NUT, FLANGE 6mm	F-24	24	PIN, DOWEL 10x16	E-06	3	PULLEY SUB ASS'Y, DRIVEN	E-13	8
MARK, BODY COVER	F-18	13	NUT, FLANGE 6mm	F-25	20	PIN, HANGER	F-10	33	PUMP ASS'Y, OIL	E-09	1
			NUT, HEX 10mm	F-26	23	PIN, HANGER(DC)	F-10	32	PUMP SET, FUEL	F-15	1
			NUT, HEX 10mm	E-04	11	PIN, PISTON	E-18	3	[R]		
			NUT, HEX 6mm(Y)	F-22	10	PIN, ROLLER GUIDE	E-13	14	RACE, STEERING BOTTOM BALL	F-08	2
			NUT, HEX 6mm(Y)	E-10	14	PIN, SLIDE(DC)	F-10	18	RACE, STEERING BOTTOM CONE	F-08	7
			NUT, HEX 6mm(Y)	F-25	19	PIN, SPECIAL DOWEL 8x14	E-07	6	RACE, STEERING TOP BALL	F-08	1
									RACE, STEERING TOP CONE	F-08	6
									RADIATOR ASS'Y, OIL	E-15	1
									RADIATOR COMP., OIL	E-15	2

PARTS NAME INDEX

Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.
RATCHET, KICK STARTER	E-12	8	SCREW SET	E-19	5	SCREW, TORUS 6x12	F-13	16	SHAFT, INLET ROCKER ARM	E-04	7
RECTIFIER ASS'Y, REGULATOR	F-25	6	SCREW SET	E-19	14	SCREW, WASHER 3x22	F-02	10	SHAFT, LH. CRANK	E-18	9
REFLECTOR, REFLEX	F-24	11	SCREW, BLEEDER	F-10	2	SCREW, WASHER 4x12	F-04	25	SHAFT, OIL PUMP	E-09	5
REFLECTOR, WINKER	F-23	3	SCREW, FLAT 4x12	F-04	24	SCREW, WASHER 4x8	E-19	35	SHAFT, REDUCTION GEAR	E-10	2
REFLECTOR, WINKER	F-23	7	SCREW, FLAT 6x32	E-09	12	SCREW, WASHER 4x8	F-02	13	SHIM, RH. (DC)	F-10	19
RELAY ASS'Y, AUDIBLE PILOT WINKER	F-16	4	SCREW, OVAL 5x16	F-02	12	SCREW, WASHER 5x10	F-24	20	SHROUD COMP., LH	E-01	4
RELAY ASS'Y, LIGHT	F-16	6	SCREW, PAN 4x10	E-09	11	SCREW, WASHER 5x12	E-01	6	SHROUD COMP., RH.	E-01	2
RELAY COMP., AUDIBLE PILOT WINKER	F-16	5	SCREW, PAN 4x10	E-19	33	SCREW, WASHER 5x14	F-05	16	SOCKET COMP.	F-02	9
RELAY COMP., START	F-16	7	SCREW, PAN 4x12	E-19	34	SCREW, WASHER 5x14	F-14	12	SOCKET COMP., HEAD LIGHT	F-01	4
RETAINER(DC)	F-10	17	SCREW, PAN 4x8	E-19	32	SCREW, WASHER 5x14	F-18	23	SOCKET COMP., LH. WINKER	F-23	8
RETAINER, CONROD LARGE END	E-18	15	SCREW, PAN 5x12	E-08	6	SCREW, WASHER 5x14	F-24	21	SOCKET COMP., LICENSE LAMP	F-24	10
RETAINER, GEAR BOX	F-11	7	SCREW, PAN 5x14	E-19	31	SCREW, WASHER 5x16	F-26	22	SOCKET COMP., RH. WINKER	F-23	4
RETAINER, VALVE SPRING	E-03	10	SCREW, PAN 5x28	F-06	24	SCREW, WASHER 5x28	F-03	10	SOCKET COMP., RR. COMBINATION	F-24	5
RING, BACK UP	F-09	11	SCREW, PAN 5x8	E-19	30	SCREW, WASHER 5x45	F-03	11	SPECIAL CLIP, TUBE	F-15	18
RING, OIL SEAL STOP	F-09	17	SCREW, PAN 6x6	E-05	8	SEAL, AIR CLEANER COVER	F-19	6	SPRING SET, MAIN STAND	F-21	5
RING, PISTON	F-09	9	SCREW, SIDE STAND PIVOT	F-21	12	SEAL, DUST	F-09	6	SPRING SET, SIDE STAND	F-21	8
RING, PISTON 2ND	E-18	5	SCREW, SPECIAL 5x12	F-14	8	SEAL, DUST	F-10	15	SPRING, CLUTCH	E-13	5
RING, PISTON OIL	E-18	6	SCREW, SPECIAL 5x12	F-18	17	SEAL, DUST 40x50x5	F-11	17	SPRING, COMPRESSION	E-19	3
RING, PISTON TOP	E-18	4	SCREW, SPECIAL 5x14	F-05	13	SEAL, DUST(DC)	F-10	14	SPRING, COMPRESSION	E-19	10
RIVET, BLIND 3.2x8.5	F-26	2	SCREW, SPECIAL 5x14	F-06	19	SEAL, ELEMENT	F-19	7	SPRING, COMPRESSION	E-19	11
ROD, CONNECTING	E-18	7	SCREW, SPECIAL 5x14	F-16	10	SEAL, MISSION COVER	E-14	3	SPRING, DRIVEN FACE	E-13	16
ROLLER 2.5x11.8	E-09	13	SCREW, SPECIAL 5x14	F-18	18	SEAL, OIL	F-09	18	SPRING, FR. FORK	F-09	2
ROLLER 4x14.8A	E-18	14	SCREW, SPECIAL 5x16	F-19	16	SEAL, OIL 20x30x6	E-07	7	SPRING, MAIN STAND INNER	F-21	7
ROLLER COMP., WEIGHT 12g	E-12	5	SCREW, SPECIAL 6x10	F-06	18	SEAL, OIL 22x39x7	E-14	14	SPRING, MAIN STAND OUTER	F-21	6
ROLLER, GUIDE	E-13	15	SCREW, SPECIAL 6x14	F-11	16	SEAL, OIL 23x37x7	F-11	16	SPRING, OIL FILTER	E-16	6
ROTOR ASS'Y, OIL PUMP	E-09	6	SCREW, SPECIAL 6x14	F-18	16	SEAL, OIL 24x31x3	E-12	9	SPRING, OIL FILTER SCREEN	E-16	10
ROTOR, OIL PUMP INNER	E-09	7	SCREW, SPECIAL 6x16	F-17	9	SEAL, OIL 25x42x7	E-17	11	SPRING, PAD	F-10	13
ROTOR, OIL PUMP OUTER	E-09	8	SCREW, SPECIAL PAN	E-19	29	SEAL, OIL 28x42x7	F-12	14	SPRING, PAD(DC)	F-10	12
RUBBER, CLUTCH DAMPER	E-13	7	SCREW, SPECIAL PAN 5x32	E-08	5	SEAL, OIL 30x42x7	E-17	12	SPRING, REBOUND	F-09	4
RUBBER, CUSHION	F-06	8	SCREW, TAPPET ADJUSTING	E-04	9	SEAL, OIL 34x39x3	E-13	24	SPRING, RELIEF VALVE	E-16	8
RUBBER, LICENSE PLATE	F-24	16	SCREW, TAPPING 4x10	F-18	24	SEAL, OIL FILTER	E-16	3	SPRING, RR. CUSHION	F-22	2
RUBBER, LINK STOPPER	F-26	9	SCREW, TAPPING 4x10	F-19	20	SEAL, PISTON	F-10	31	SPRING, SIDE STAND INNER	F-21	10
RUBBER, MAGNETIC SHOCK	F-25	15	SCREW, TAPPING 4x10	F-23	11	SEAL, PISTON(DC)	F-10	30	SPRING, SIDE STAND OUTER	F-21	11
RUBBER, MUFFLER MOUNT	F-20	6	SCREW, TAPPING 4x12	E-01	8	SEAL, SHROUD	E-01	3	SPRING, VALVE	E-03	9
RUBBER, PROTECTOR	F-20	3	SCREW, TAPPING 4x12	F-05	18	SEAL, STEERING DUST	F-08	8	SPROCKET, TIMMING	E-18	11
RUBBER, RADIATOR	E-15	4	SCREW, TAPPING 4x12	F-06	26	SEAL, VALVE STEM	E-03	3	STAND ASS'Y, MAIN	F-21	1
RUBBER, RR. UPPER COVER CUSHION	F-18	10	SCREW, TAPPING 4x12	F-23	10	SEAT ASS'Y	F-13	5	STAND COMP., MAIN	F-21	2
RUBBER, STOPPER	F-22	8	SCREW, TAPPING 4x12	F-24	23	SEAT COMP., PILLION	F-13	8	STATOR COMP.	E-08	4
RUBBER, WIND SCREEN MOUNT	F-05	9	SCREW, TAPPING 4x20	F-24	22	SEAT, VALVE SPRING	E-03	11	STAY COMP., AIR CLEANER A	E-11	5
RUBBER, WIND SCREEN SEALING	F-06	2	SCREW, TAPPING 4x8	E-11	7	SET, FLOOR PANEL	F-14	4	STAY COMP., AIR CLEANER B	F-19	4
RUBBER, WINKER RELAY SHOCK	F-16	3	SCREW, TAPPING 4x8	F-02	15	SET, KEY	F-25	9	STAY, TANK UNDER SUPPORT	F-26	6
			SCREW, TAPPING 5x12	F-05	17	SET, SEAT	F-13	4	STEM COMP., STEERING	F-08	4
			SCREW, TAPPING 5x12	F-06	25	SHAFT COMP., CAM	E-04	2	STOPPER RUBBER, STAND	F-21	4
			SCREW, TAPPING 5x12	F-18	25	SHAFT COMP., COUNTER(14T)	E-14	6	STRAINER ASS'Y, FUEL	F-15	3
SCREEN ASS'Y, WIND	F-05	7	SCREW, TAPPING 5x16	E-01	9	SHAFT COMP., CRANK	E-18	1	STRAINER COMP., FUEL	F-15	4
SCREEN, AIR FILTER	E-11	3	SCREW, TAPPING 5x16	F-02	14	SHAFT COMP., FINAL	E-14	7	SUB ASS'Y, MUFFLER	F-20	7
SCREEN, OIL FILTER	E-16	9	SCREW, TAPPING 5x16	F-14	13	SHAFT COMP., RH. CRANK	E-18	8	SUSPENSION, LIGHT RELAY	F-16	8
SCREEN, WIND	F-05	8	SCREW, TAPPING 5x16	F-17	13	SHAFT, DRIVE(13T)	E-14	5	SUSPENSION, STRAINER	F-15	5
SCREW 6x18	E-01	7	SCREW, TAPPING 5x16	F-17	14	SHAFT, EXHAUST ROCKER ARM	E-04	8	SWITCH ASS'Y, COMBINATION & LOCK	F-25	10

[S]

PARTS NAME INDEX

Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.	Description	Block No.	Ref. No.
SWITCH ASS'Y, FR.STOP	F-04	2	[W]								
SWITCH ASS'Y, LIGHTING START	F-03	2									
SWITCH ASS'Y, RR.STOP	F-04	1									
SWITCH ASS'Y, SIDE STAND	F-26	3									
SWITCH ASS'Y, START MAGNETIC	F-25	14									
SWITCH ASS'Y, WINKER	F-03	3									
SWITCH SET, START MAGNETIC	F-25	13									
[T]											
TANK ASS'Y, FUEL	F-15	6									
TANK COMP., FUEL	F-15	7									
TENSIONER, CAM CHAIN	E-05	2									
THREAD COMP., TOP	F-08	10									
TIRE, FR.	F-11	8									
TIRE, RR.	F-12	8									
TOOL SET	F-27	1									
TOP COVER, LUGGAGE BOX	F-17	7									
TOP SET	E-19	2									
TUBE ASS'Y, BREATHER	E-17	4									
TUBE ASS'Y, DRAIN	F-19	14									
TUBE ASS'Y, FUEL 4.5x650	F-15	15									
TUBE ASS'Y, PULSE	F-15	14									
TUBE B ASS'Y, BREATHER	F-19	1									
TUBE B ASS'Y, FUEL 5.3x290	F-15	12									
TUBE C ASS'Y, FUEL 5.3x320	F-15	13									
TUBE SET	E-19	21									
TUBE SET	E-19	28									
TUBE, BREATHER 5.3x540	F-15	11									
TUBE, DRAIN	F-19	13									
TUBE, FUEL SUPPLY	F-15	9									
[U]											
UNIT ASS'Y, CDI	F-25	3									
UNIT, FUEL	F-15	16									
UNIT, HEAD LIGHT	F-01	2									
U-RING	E-19	27									
[V]											
VALVE ASS'Y, SAI REED	E-07	3									
VALVE SET, FLOAT	E-19	8									
VALVE, EXHAUST	E-03	8									
VALVE, INLET	E-03	7									
VALVE, RELIEF	E-16	7									
VALVE, RIM TR 413	F-11	1									
VALVE, RIM TR 413	F-12	9									

DAELIM

SQ 125
SZ 125
PARTS LIST



 **DAELIM MOTOR**

<http://www.dmc.co.kr>

SQ.125

PARTS LIST

2004. 08. PRINTED
2004. 08. PUBLICATION

NO COPY



DAELIM MOTOR CO.,LTD.



■ HEAD OFFICE (FACTORY)

#58, SUNG SAN-DONG, CHANG WON, KYUNGNAM, KOREA
TEL:(82-55)239-7000 FAX:(82-55)263-9761

■ OVERSEAS SALES OFFICE

#13-5, SUNG SOO 2 DONG 1GA, SUNG DONG GU, SEOEL, KOREA
TEL:(82-2) 497-3109 / FAX:(82-2) 467-9997