

PARTS CATALOGUE

MODEL YEAR 1993

DUAL PURPOSE

XT225E (4BE4) U49

XT225EC (4BE5) CALIFORNIA

STARTING VIN (4BE4):	JYA4BEE0*PA014101
STARTING VIN (4BE5):	JYA4BEC0*PA020101

Color Code	Color Name	Abbreviation
206	PURPLISH WHITE SOLID 1	PWS1

OWNERS LIT-11626-08-48

ASSEMBLY LIT-11666-07-99

SERVICE LIT-11616-XT-25

FOREWORD

-INTRODUCTION- To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the XT225E/EC. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

[]	Inactive, no longer available
U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD,SO,SW	"SD", "SO", or "SW" type oil seal
E,R	"E" or "R" type circlip
F/No.	Frame No. (Applicable Machine No.)
L.M.	Locally made
O.L.	Obtain locally
AP	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	123-45678-00-00	CYLINDER (111-12345-00-00)	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-12345-00	CYLINDER (111-12345-00-00)	1
	234-56789-00-00	• HEAD, CYLINDER	1
	345-67890-00-00	• GASKET, CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl)	Inside Diameter - Length
O-Ring	Section Area - Inside Diameter
Washer, Shim, Collar	Inside Diameter - Outside Diameter Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indentation of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.

EXAMPLE:


Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No.



(2) Frame Serial No.




FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4DU-00000-00-00 identifies the XJ600SE.
3FA-00000-00-00 identifies the YFA1E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These "Middle Five Digits" indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The "Major Classification" indicates the section to which the parts belong, i.e., engine, electrical etc. The "Intermediate" and "Minor Classifications" indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

4BR-11610-0 0-00 Standard Piston Ring Set for XJ600SE
4BR-11610-2 0-00 Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: YFZ350E

2GU-11610-0 0-00 PISTON RING SET, STD. - ORIGINAL
2GU-11610-0 1-00 PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number "9" followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.

FOREWORD

Example:

- 9 0 000-00000-00 "0" designates various types.
- 9 1 000-00000-00 "1" designates bolts, cotter pins, etc.
- 9 2 000-00000-00 "2" designates screw, nuts, etc.
- 9 3 000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
- 9 4 000-00000-00 "4" designates spark plugs.
- 9 5 000-00000-00 "5" designates bolts and nuts.
- 9 7 000-00000-00 "7" designates ISO bolts.
- 9 8 000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.

BOLT EXAMPLE:

91311 - 06 018 - 00
6mm outside diameter 18mm in length

EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.

NUT AND WASHER EXAMPLE:

95301 - 08600 - 00 NUT
8mm inside diameter

90201 - 25290 - 00 WASHER
25mm inside diameter

-MODEL LABEL-

A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross-reference the "model code - production code No." in the catalogue to the "model code - production code No." indicated on the Model Label affixed onto the product concerned.

"MODEL LABEL" INDICATION

1
xxxx - xxx
3
x

2

1 Model Type Code


2 Production Code Nol

3 Coloring Type

○ 4TW1-010

● A


MODEL LABEL AFFIXING LOCATION



MODEL CODE - PRODUCTION CODE NUMBER OF MODEL LISTED IN THIS PARTS CATALOG

Model Code	Production Code No.	Country (destination)
4BE4	010	U49
4BE5	010	CALIFORNIA


CYLINDER HEAD



Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-11101-01-00	CYLINDER HEAD ASSEMBLY .	1	
2	5H0-11133-10-00	. GDE, INTK VLV 1 O/S	2	
3	93440-10085-00	. CIRCLIP	2	
4	90153-06045-00	SCREW, HEXAGON	1	
5	90430-06014-00	GASKET	1	
6	90385-12039-00	BUSH	1	
7	59V-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
8	99530-14016-00	PIN, DOWEL	2	
9	91810-08016-00	PIN, DOWEL	1	
10	90430-12186-00	GASKET	1	
11	90105-08195-00	BOLT, WASHER BASED	4	
12	90201-080L7-00	WASHER, PLATE	4	
13	91311-08045-00	BOLT	2	
14	3RW-11185-00-00	COVER, CYLINDER HEAD SIDE 1	1	
15	93211-05471-00	O-RING	1	
16	98580-06020-00	SCREW, PAN HEAD	2	
17	3RW-11186-00-00	COVER, CYLINDER HEAD SIDE 2	1	
18	3RW-11187-00-00	COVER, CYLINDER HEAD SIDE 3	1	
19	93210-57634-00	O-RING	2	
20	91311-06018-00	BOLT	5	
21	5H0-1111F-00-00	PLATE	1	
22	97013-06012-00	BOLT	2	
23	90215-06184-00	WASHER, LOCK	1	
24	NGK-DR8ES-L0-00	NGK DR8ES-L 10PK	1	UR


CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-11310-00-00	CYLINDER	1	
2	93210-71470-00	O-RING (93210-72529-00)	1	
3	4BE-11351-00-00	GASKET, CYLINDER	1	
4	93210-13361-00	O-RING	1	
5	99530-14016-00	PIN, DOWEL	2	
6	91311-06030-00	BOLT, SOCKET HEAD	2	
7	15A-11162-00-00	ABSORBER 2	2	
8	5H0-11161-00-00	ABSORBER 1	2	
9	15A-11162-00-00	ABSORBER 2	1	
10	1KH-15441-00-00	HOLDER, CABLE	1	



1KH010-6020

CRANKSHAFT - PISTON





Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-11400-00-00	CRANKSHAFT ASSEMBLY ...	1	
2	5H0-11681-00-00	. PIN, CRANK 1	1	
3	93310-530J3-00	. BEARING	1	
4	29U-11651-00-00	. ROD, CONNECTING	1	
5	93306-30615-00	BEARING (B6306)	1	
6	1KH-11631-01-A0	PISTON (STD)	1	
	1KH-11636-01-00	PISTON (0.50MM O/S)	1	AP
	1KH-11638-01-00	PISTON (1.00MM O/S)	1	AP
7	29U-11610-00-00	PISTON RING SET (STD)	1	
	29U-11610-20-00	PISTON RING SET (0.50MM O/S)	1	AP
	29U-11610-40-00	PISTON RING SET (1.00MM O/S)	1	AP
8	58L-11633-00-00	PIN, PISTON	1	
9	93450-17044-00	CIRCLIP	2	
10	90201-201E4-00	WASHER, PLATE	1	
11	5H0-11496-00-00	BOSS, BUFFER	1	
12	90501-21133-00	SPRING, COMPRESSION	6	
13	93605-10090-00	PIN, DOWEL	3	
14	5H0-11536-00-00	GEAR, DRIVE (38T)	1	
15	90214-20023-00	WASHER, CLAW	1	
16	90240-07083-00	PIN, CLEVIS	1	
17	90501-07629-00	SPRING, COMPRESSION	1	
18	93602-13177-00	PIN, DOWEL	1	
19	2LN-11530-00-00	BALANCER WEIGHT GEAR COMP.	1	
20	1KH-11454-00-00	WEIGHT 1	1	
21	93306-20529-00	BEARING (B6205C4)	1	
22	93306-30427-00	BEARING	1	
23	90282-05013-00	KEY, STRAIGHT	1	

CONTINUED ON NEXT FRAME ➤

CRANKSHAFT - PISTON


Ref. No.	Part Number	Description	Qty	Remarks
24	90215-14205-00	WASHER, LOCK	1	
25	90170-14284-00	NUT	1	
26	90280-16053-00	KEY, WOODRUFF (90280-05048-00)	1	
27	90201-102J5-00	WASHER, PLATE	1	
28	92901-10100-00	WASHER, SPRING	1	
29	90101-10188-00	BOLT	1	
30	1KH-11145-00-00	PLATE, BREATHER 2	1	
31	93101-25106-00	OIL SEAL	1	





CAMSHAFT - CHAIN


Ref. No.	Part Number	Description	Qty	Remarks
1	1KH-12171-00-00	CAMSHAFT 1	1	
2	2LN-12176-00-00	SPROCKET, CAM CHAIN (40T)	1	
3	93604-10011-00	PIN, DOWEL	1	
4	90101-10303-00	BOLT	1	
5	90201-10774-00	WASHER, PLATE	1	
6	90387-255F3-00	COLLAR	1	
7	94580-41104-00	CHAIN	1	
8	5H0-12231-00-00	GUIDE, STOPPER 1	1	
9	5N0-12241-00-00	GUIDE, STOPPER 2	1	
10	2HT-12210-10-00	TENSIONER ASSEMBLY, CAM CHAIN	1	
11	4BE-12213-00-00	GASKET, TENSIONER CASE ..	1	
12	91311-06025-00	BOLT, SOCKET HEAD	2	
13	97011-06016-00	BOLT	2	
14	92901-06600-00	WASHER	2	



VALVE

Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-12111-00-00	VALVE, INTAKE	1	
2	5H0-12121-00-00	VALVE, EXHAUST	1	
3	4G0-12116-01-00	SEAT, VALVE SPRING	2	
4	11H-12113-00-00	SPRING, VALVE INNER	2	
5	11H-12114-00-00	SPRING, VALVE OUTER	2	
6	5H0-12119-00-00	SEAL, VALVE STEM	2	
7	4G0-12117-00-00	RETAINER, VALVE SPRING ..	2	
8	4G0-12118-00-00	COTTER, VALVE	4	
9	29U-12151-00-00	ARM, VALVE ROCKER	2	
10	5H0-12156-00-00	SHAFT, ROCKER 2	1	
11	5H0-12146-00-00	SHAFT, ROCKER	1	
12	93210-09350-00	O-RING	1	
13	3Y1-12159-00-00	SCREW, VALVE ADJUSTING ..	2	
14	90170-06128-00	NUT	2	

IKHO10-6040




OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-13300-00-00	OIL PUMP ASSEMBLY	1	
2	5H0-13326-00-00	. GEAR, PUMP DRIVEN 2 (45T)	1	
3	93603-12030-00	. PIN, DOWEL	1	
4	4BE-13329-00-00	GASKET, PUMP COVER	1	
5	98701-06030-00	SCREW, FLAT HEAD	3	
6	5H0-13327-00-00	COVER, PUMP GEAR	1	
7	51Y-13411-00-00	STRAINER, OIL	1	
8	90501-18576-00	SPRING, COMPRESSION	1	
9	5H0-15351-00-00	PLUG, DRAIN	1	
10	93210-35389-00	O-RING	1	
11	5H0-13440-00-00	ELEMENT ASSEMBLY, OIL CLEANER	1	
12	3AW-13447-00-00	COVER, OIL ELEMENT	1	
13	93210-54175-00	O-RING	1	
14	90109-06419-00	BOLT	1	
15	93210-07135-00	O-RING	1	
16	98506-06025-00	SCREW, PAN HEAD	1	
17	98506-06075-00	SCREW, PAN HEAD	1	



JKH010-6060



3RW1010-0070


AIR FILTER

Ref. No.	Part Number	Description	Qty	Remarks
1	2LN-13586-01-00	JOINT, CARBURETOR 1	1	
2	93210-35537-00	O-RING	1	
3	92016-06020-00	SCREW	2	
4	92906-06600-00	WASHER	1	
5	90450-49020-00	HOSE CLAMP ASSEMBLY	1	
6	3RW-14411-00-00	CASE, AIR CLEANER 1	1	
7	3RW-14453-01-00	JOINT, AIR CLEANER 1	1	
8	1KH-14437-01-00	DUCT	1	
9	1KH-14458-00-00	GUIDE	1	
10	1KH-14451-00-00	ELEMENT, AIR CLEANER	1	
11	1KH-14412-00-00	CAP, CLEANER CASE 1	1	
12	51Y-14462-00-00	SEAL	1	
13	97706-50520-00	SCREW, TAPPING	6	
14	1KH-14472-00-00	PLATE, ELEMENT	1	
15	3RW-14422-00-00	CAP, CLEANER CASE 2	1	
16	5T0-14457-00-00	SEAL	1	
17	90154-05013-00	SCREW, BINDING	3	
18	34X-1443E-00-00	PIPE, DRAIN	1	
19	90467-11102-00	CLIP, SCISSOR	1	
20	4U8-14462-00-00	SEAL	1	
21	90460-56105-00	CLAMP, HOSE	1	
22	90159-06016-00	SCREW, WITH WASHER	1	
23	90119-06172-00	BOLT, WITH WASHER	2	
24	90387-07789-00	COLLAR	1	
25	16G-13569-00-00	PLUG, BLIND	1	
26	90467-10039-00	CLIP	1	

CARBURETOR


Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-14901-00-00	CARBURETOR ASSEMBLY 1	1	UR CA ONLY
	4BE-14901-10-00	CARBURETOR ASSEMBLY 1	1	UR NON-CA
2	2A2-14997-00-00	. SEAL	2	
3	812-14137-00-00	. CLIP	1	
4	22F-14126-00-00	. GASKET	1	
5	36X-14169-00-00	. CAP	1	
6	3LD-1490H-00-00	. DIAPHRAGM SET, 5 (26H-1490H-00-00)	1	
7	2A2-14172-12-00	. PILOT JET, AIR (1.2)	1	
8	22F-14139-00-00	. CLIP, PIPE	1	
9	137-14153-00-00	. WASHER, MAIN JET	1	
10	537-14186-00-00	. PIN, FLOAT	1	
11	98511-04012-00	. SCREW, PAN HEAD	4	
12	12R-14191-00-00	. PLUG, DRAIN	1	
13	558-14147-00-00	. O-RING	1	
14	93210-04121-00	. O-RING	2	
15	3RW-14197-00-00	. PIPE	1	UR
	90445-084E3-00	. HOSE	1	UR CA ONLY
16	98580-04008-00	. SCREW, PAN HEAD	3	
17	92901-04100-00	. WASHER, SPRING	3	
18	2LN-14933-00-00	. SPRING, DIAPHRAGM	1	
19	98506-04008-00	. SCREW, PAN HEAD	4	
20	92906-04100-00	. WASHER, SPRING	4	
21	2LN-14197-00-00	. PIPE	1	UR
	4BE-14196-00-00	. PIPE	1	UR CA ONLY
22	2LN-14197-00-00	. PIPE	1	
23	4BE-1490J-00-00	. NEEDLE SET	1	
24	4BE-14141-31-00	. NOZZLE, MAIN	1	
25	2LN-14940-00-00	. DIAPHRAGM ASSEMBLY	1	


CONTINUED ON NEXT FRAME ►



CARBURETOR


Ref. No.	Part Number	Description	Qty	Remarks
26	3RW-1410A-00-00	. STARTER SET	1	
27	90445-084E3-00	. HOSE	1	NON CA
28	4G0-14142-40-00	. JET, PILOT (40)	1	
29	620-14231-26-A0	. JET, MAIN (#130.0)	1	
30	2LN-14185-00-00	. FLOAT	1	
31	1UY-14107-20-00	. NEEDLE VALVE SET	1	
32	2LN-14147-00-00	. O-RING	1	
33	2LN-14103-00-00	. THROTTLE SCREW SET	1	
34	4BE-14105-00-00	. PILOT SCREW SET	1	
35	3F9-14118-00-00	. CAP	1	CA ONLY
36	90467-09006-00	. CLIP	1	CA ONLY
37	90445-103F5-00	. HOSE	1	CA ONLY
38	4BE-14193-00-00	PIPE	1	CA ONLY
39	90445-07671-00	HOSE	1	CA ONLY





CRANKCASE


Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-15100-00-00	CRANKCASE ASSEMBLY	1	
2	99510-12016-00	. PIN, DOWEL	2	
3	90387-125F1-00	COLLAR	1	
4	90387-125F1-00	COLLAR	1	
5	98580-06030-00	SCREW PAN HEAD	7	
6	98506-06040-00	SCREW, PAN HEAD	2	
7	98506-06090-00	SCREW, PAN HEAD	2	
8	98506-06085-00	SCREW, PAN HEAD	1	
9	1KH-11166-01-00	PIPE, BREATHER 1	1	
10	90467-14015-00	CLIP	2	
11	90465-08200-00	CLAMP	1	
12	90462-08193-00	CLAMP	1	



3RW1010-0110

CRANKCASE COVER 1

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-15411-00-00	COVER, CRANKCASE 1	1	
2	4BE-15451-00-00	GASKET, CRCS COVERCOVER 1	1	
3	99510-12016-00	PIN, DOWEL	2	
4	98506-06025-00	SCREW, PAN HEAD	6	
5	98506-06035-00	SCREW, PAN HEAD	2	
6	90340-14128-00	PLUG, STRAIGHT SCREW	1	
7	93210-14369-00	O-RING	1	
8	90340-32123-00	PLUG, STRAIGHT SCREW	1	
9	93210-32172-00	O-RING	1	
10	90465-08300-00	CLAMP	1	
11	98580-06010-00	SCREW, PAN HEAD	1	
12	90462-16096-00	CLAMP	1	
13	3RW-15420-00-00	CRANKCASE COVER ASSEMBLY 2	1	
14	98506-06025-00	SCREW, PAN HEAD	2	
15	3RW-15431-01-00	COVER, CRANKCASE 3	1	
16	4BE-15462-00-00	GASKET, CRANKCASE COVER 3	1	
17	99510-12016-00	PIN, DOWEL	2	
18	98506-06025-00	SCREW, PAN HEAD	5	
19	98506-06035-00	SCREW, PAN HEAD	3	
20	98506-06045-00	SCREW, PAN HEAD	2	
21	1RG-15363-00-00	PLUG, OIL	1	
22	93210-19123-00	O-RING	1	
23	3Y1-15361-00-00	GAUGE, LEVEL	1	
24	90462-08194-00	CLAMP	2	
25	55X-15167-00-00	PLUG, BLIND 1	1	




GENERATOR


Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-81410-00-00	STATOR ASSEMBLY	1	
2	3RW-85580-00-00	COIL, PULSER	1	
3	2YG-85550-M0-00	ROTOR ASSEMBLY	1	
4	98501-05030-00	SCREW, PAN HEAD	3	
5	92990-05100-00	WASHER, SPRING	3	
6	98580-06020-00	SCREW, PAN HEAD	2	

STARTING MOTOR

Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-81800-01-00	STARTING MOTOR ASSEMBLY	1	
2	50M-81801-M0-00	. BRUSH SET	1	
3	93210-55669-00	. O-RING	1	
4	59V-81828-M0-00	. SCREW SET	1	
5	3RW-8183G-00-00	. CORD COMP.	1	
6	93210-25711-00	. O-RING	1	



3RW1010-033I




3RW1010-0120

STARTER CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	2HT-15512-00-00	GEAR, IDLER 1	1	
2	5H0-15521-00-00	SHAFT 1	1	
3	90387-125Y0-00	COLLAR	1	
4	5H0-15517-00-00	GEAR, IDLER 2 (56T)	1	
5	90201-256K6-00	WASHER, PLATE (0.9T)	1	
6	4H7-15580-10-00	STARTER CLUTCH OUTER ASSEMBLY	1	
7	90501-04596-00	. SPRING, COMPRESSION	3	
8	341-15583-05-00	. CAP, STR CLUTCH SPR -CLUTCH SPRING	3	
9	93615-12088-00	. PIN, DOWEL	3	
10	91316-08016-00	BOLT, SOCKET HEAD	3	
11	90560-17368-00	SPACER	1	
12	99009-17400-00	CIRCLIP	2	

CLUTCH





Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-16111-00-00	GEAR, PRIMARY DRIVE (22T)	1	
2	90282-05043-00	KEY, STRAIGHT	1	
3	90215-14205-00	WASHER, LOCK	1	
4	90170-14284-00	NUT	1	
5	1KH-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
6	2LN-16154-00-00	PLATE, THRUST 1	1	
7	2LN-16371-00-00	BOSS, CLUTCH	1	
8	537-16321-00-00	PLATE, FRICTION	5	
9	137-16324-00-00	PLATE, CLUTCH 1	5	
10	5H0-16351-00-00	PLATE, PRESSURE 1	1	
11	90501-23700-00	SPRING, COMPRESSION	4	
12	90159-05011-00	SCREW, WITH WASHER	4	
13	30X-16358-00-00	PLATE, PUSH	1	
14	1HX-16356-00-00	ROD, PUSH 1	1	
15	93210-48364-00	O-RING	1	
16	92990-06200-00	WASHER, PLAIN	1	
17	95380-06600-00	NUT, HEXAGON	1	
18	36X-16321-00-00	PLATE, FRICTION	1	
19	1KH-16383-00-00	SPRING, CLUTCH BOSS	1	
20	90215-14224-00	WASHER, LOCK	1	
21	90170-14284-00	NUT	1	
22	1KH-16380-01-00	PUSH LEVER ASSEMBLY	1	
23	90201-08087-00	WASHER, PLATE	1	
24	90149-08067-00	SCREW	1	
25	90508-16708-00	SPRING, TORSION	1	
26	5H0-16357-00-00	ROD, PUSH 2	1	
27	93505-16006-00	BALL	1	
28	93315-31428-00	BEARING	1	

CONTINUED ON NEXT FRAME ►

CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
29	93102-14209-00	OIL SEAL	1	
30	93420-28055-00	CIRCLIP	1	





1KH010-6140


TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	2LN-17411-00-00	AXLE, MAIN	1	
2	5H0-17141-02-00	GEAR, 4TH PINION (29T)	1	
3	90209-17285-00	WASHER	1	
4	93410-20038-00	CIRCLIP	1	
5	1KH-17131-01-00	GEAR, 3RD PINION (24T)	1	
6	1KH-17151-00-00	GEAR, 5TH PINION (27T)	1	
7	1KH-17121-00-00	GEAR, 2ND PINION (15T)	1	
8	90201-164K2-00	WASHER, PLATE	1	
9	93306-20421-00	BEARING (B6204)	1	
10	93101-15101-00	OIL SEAL	1	
11	93306-20211-00	BEARING (6202SH2-C3)	1	
12	17T-17402-00-00	DRIVE AXLE ASSEMBLY	1	
13	1KH-17221-00-00	GEAR, 2ND WHEEL (30T)	1	
14	17T-17251-02-00	GEAR, 5TH WHEEL (25T)	1	
15	1KH-17231-00-00	GEAR, 3RD WHEEL (30T)	1	
16	17T-17241-02-00	GEAR, 4TH WHEEL (27T)	1	
17	90209-18208-00	WASHER	1	
18	93410-22039-00	CIRCLIP	1	
19	1EV-17251-00-00	GEAR, 5TH WHEEL (23T)	1	
20	1KH-17211-00-00	GEAR, 1ST WHEEL (34T)	1	
21	90201-17257-00	WASHER, PLATE	1	
22	99009-17400-00	CIRCLIP	1	
23	90201-203E7-00	WASHER, PLATE	1	
24	93306-30424-00	BEARING (B6304A3)	1	
25	93102-20242-00	OIL SEAL	1	
26	93306-20332-00	BEARING	1	
27	1KH-17460-00-00	SPROCKET, DRIVE 15T (1KH1746150)	1	
28	5H0-17456-00-00	HOLDER, SPROCKET	1	


CONTINUED ON NEXT FRAME ➤

TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
29	97011-06010-00	BOLT (97002-06010)	 2	




IKH010-6140



25A310-3160

SHIFT CAM - FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	17T-18540-01-00	SHIFT CAM ASSEMBLY	1	
2	136-18542-00-00	. POINT, NEUTRAL	1	
3	93315-23612-00	BEARING	1	
4	1RH-18185-00-00	SEGMENT	1	
5	93604-16092-00	PIN, DOWEL	4	
6	93604-20156-00	PIN, DOWEL	1	
7	90151-06013-00	SCREW, COUNTERSUNK	1	
8	1RH-18140-00-00	STOPPER LEVER ASSEMBLY .	1	
9	90508-26539-00	SPRING, TORSION	1	
10	5N0-18513-00-00	FORK, SHIFT 3	1	
11	5H0-18511-00-00	FORK, SHIFT 1	1	
12	5H0-18512-00-00	FORK, SHIFT 2	1	
13	5H0-18531-00-00	BAR, SHIF FRK GDE 1	1	
14	30X-18535-00-00	BAR, SHIF FRK GDE 2	1	




SHIFT SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
1	5H0-18120-02-00	SHIFT LEVER ASSEMBLY	1	
2	90506-08227-00	. SPRING, TENSION	1	
3	90508-26705-00	SPRING, TORSION	1	
4	99006-10600-00	CIRCLIP	1	
5	90387-124F4-00	COLLAR	1	
6	90201-12588-00	WASHER, PLATE	2	
7	93608-50158-00	PIN, DOWEL	1	
8	93102-12321-00	OIL SEAL, SD-TYPE	1	
9	1KH-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
10	1W6-18113-00-00	. COVER, SHIFT PEDAL	1	
11	97016-06020-00	BOLT	1	
12	95316-06700-00	NUT 54G	1	
13	16G-18115-00-00	ROD, SHIFT	1	
14	90170-06228-00	NUT (COUNTER CLOCKWISE)	1	
15	1KH-18112-00-00	ARM, SHIFT	1	
16	2H9-18154-00-00	COVER, DUST	1	




IKH010-6160



FRAME

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-21110-00-UJ	FRAME COMP. 1	1	UR RADICAL WHITECA ONLY
	4FD-21110-00-UJ	FRAME COMP.	1	UR RADICAL WHITENON-CA
2	95811-08065-00	BOLT, FLANGE	4	
3	4BE-21316-00-UJ	STAY, ENGINE	1	RADICAL WHITE
4	95601-08200-00	NUT, SELF LOCKING	4	
5	1KH-21315-00-00	STAY, ENGINE 2	1	
6	95811-08050-00	BOLT, FLANGE (95823-08050)	1	
7	95601-08200-00	NUT, SELF LOCKING	1	
8	90201-094G1-00	WASHER, PLATE	1	
9	90105-08408-00	BOLT, WASHER BASED	2	
10	90105-08024-00	BOLT, WASHER BASED	1	
11	95601-08200-00	NUT, SELF LOCKING	1	
12	90201-094G1-00	WASHER, PLATE	1	
13	92901-08800-00	WASHER	1	
14	3RW-21471-00-00	PROTECTOR, ENGINE	1	
15	1KH-21485-00-00	DAMPER, RUBBER 1	1	
16	36X-21485-00-00	DAMPER, RUBBER 1	2	
17	34L-21485-00-00	DAMPER, RUBBER 1	2	
18	90480-14023-00	GROMMET	1	
19	90387-07391-00	COLLAR	1	
20	97011-06025-00	BOLT (97001-06025)	1	
21	30X-22178-00-00	TENSIONER	1	
22	4V4-22184-00-00	BUSH	1	
23	90109-08705-00	BOLT	1	
24	90201-13409-00	WASHER, PLATE	1	
25	90201-08753-00	WASHER, PLATE	1	
26	90387-085E1-00	COLLAR	1	

CONTINUED ON NEXT FRAME ►




4BE4100-3170

FRAME

Ref. No.	Part Number	Description	Qty	Remarks
27	55E-21308-00-00	HELMET HANGER ASSEMBLY	1	
28	90151-06025-00	SCREW, COUNTERSUNK	1	
29	4BE-21165-10-00	HANDLE, STANDING	1	
30	4BE-21275-10-00	STAY, REAR	1	
31	95811-08016-00	BOLT, FLANGE	4	
32	2J5-21732-00-00	SEAL 1	1	
33	3RW-Y217W-A0-00	SCOOP COMP, 1 PURPL	1	UR
34	90480-14448-00	. GROMMET	1	
35	3RW-24246-71-00	. GRAPHIC, FUEL TAN 3	1	UR
36	3RW-2139U-00-00	. DAMPER 2	1	
37	4BE-Y217X-10-00	SCOOP COMP, AIR 2	1	UR
38	90480-14448-00	. GROMMET	1	
39	3RW-24247-71-00	. GRAPHIC	1	UR
40	3RW-2139X-00-00	. DAMPER	1	
41	4BE-24170-00-00	CANISTER ASSEMBLY	1	CA ONLY
42	90480-15342-00	GROMMET	2	CA ONLY
43	90387-063G3-00	COLLAR	2	CA ONLY
44	97011-06025-00	BOLT (97001-06025)	2	CA ONLY
45	92906-06100-00	WASHER, SPRING	1	CA ONLY
46	20K-24180-00-00	ROLL OVER VALVE ASSEMBLY	1	CA ONLY
47	93210-10166-00	O-RING	1	CA ONLY
48	90445-10638-00	HOSE	1	CA ONLY
49	90445-110F5-00	HOSE	1	CA ONLY
50	90467-09006-00	CLIP	3	CA ONLY
51	90467-11102-00	CLIP, SCISSOR	1	CA ONLY
52	80L-26397-00-00	BAND	1	
53	90480-16185-00	GROMMET	2	
54	4BE-2139T-00-00	BRACKET, COVER	1	


CONTINUED ON NEXT FRAME ►



4BE4100-3170

FRAME


Ref. No.	Part Number	Description	Qty	Remarks
55	90119-06043-00	BOLT, WITH WASHER	1	
56	90267-40075-00	RIVET, BLIND	2	
57	90201-040P8-00	WASHER, PLATE	2	
58	90338-15202-00	PLUG	1	
59	90338-24177-00	PLUG	2	



4BE4100-3180

FENDER


Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-21511-00-00	FENDER, FRONT	1	
2	3RW-21570-50-00	GRPHC SET, FRT FNDRFRONT FENDER	1	
3	90387-06681-00	COLLAR	4	
4	90119-06063-00	BOLT, WITH WASHER	4	
5	3RW-21611-10-00	FENDER, REAR	1	
6	90119-06056-00	BOLT, WITH WASHER	2	
7	34X-21691-00-00	FLAP	1	
8	3LT-24786-11-00	EMBLEM	1	
9	4BE-84551-00-00	BRACKET, LICENCE	1	
10	4BE-84527-00-00	DAMPER	1	
11	42U-21639-00-00	DAMPER 2	1	
12	97011-06025-00	BOLT (97001-06025)	2	
13	90387-07391-00	COLLAR	2	
14	95811-06016-00	BOLT, FLANGE (95801-06016) .	2	
15	4BE-21637-00-00	CLAMP, WIRE	1	
16	95380-06600-00	NUT, HEXAGON	2	
17	90387-06681-00	COLLAR	2	
18	3RW-21639-00-00	DAMPER 2	1	
19	3RW-2165A-10-00	GRAPHIC SET REAR F	1	



4BE4100-3190

SIDE COVER

Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-21711-10-00	COVER, SIDE 1	1	
2	3RW-2173L-12-00	GRAPHIC SET 1	1	
3	90480-01401-00	GROMMET	1	
4	90149-06223-00	SCREW	1	
5	90387-064J1-00	COLLAR	1	
6	90480-01401-00	GROMMET	1	
7	4U5-2176E-00-00	PLATE	1	
8	3RW-21721-10-00	COVER, SIDE 2	1	
9	3RW-2174L-10-00	GRAPHIC SET 2	1	
10	90149-06223-00	SCREW	1	
11	90387-064J1-00	COLLAR	1	
12	4U5-2176E-00-00	PLATE	1	
13	90480-11224-00	GROMMET	1	
14	90480-01401-00	GROMMET	1	
15	3RW-2177A-01-00	BOX	1	
16	3RW-2173M-00-00	SEAL 3	1	
17	95811-06016-00	BOLT, FLANGE (95801-06016) .	1	
18	90387-06500-00	COLLAR	1	
19	90119-06042-00	BOLT, WITH WASHER	1	
20	3RW-2177F-00-00	COVER	1	
21	4BE-2179N-10-00	PLATE, EPA CAL	1	CA ONLY NON CA
	4BE-2179V-10-00	PLATE, EPA U 9	1	
22	3RW-28100-01-00	TOOL KIT	1	
23	55V-28173-00-00	BOX, TOOL	1	
24	55V-28185-00-00	LID	1	
25	3RW-28267-00-00	DAMPER 5	1	
26	90119-06108-00	BOLT, WITH WASHER	2	




4BE1110-2200

SWING ARM

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-22110-00-P0	REAR ARM	1	GRAY METALLIC
2	90386-18146-00	BUSH	2	
3	90380-18139-00	BUSH, SOLID	2	
4	401-22127-00-00	SHIM	1	
5	401-22128-01-00	SEAL, GUARD	2	
6	93109-18020-00	OIL SEAL	2	
7	90387-121N2-00	COLLAR	1	
8	90387-127F2-00	COLLAR	1	
9	1KH-22141-00-00	SHAFT, PIVOT	1	
10	90185-12134-00	NUT, SELF-LOCKING	1	
11	90201-126A7-00	WASHER, PLATE	1	
12	93700-06005-00	NIPPLE, GREASE	2	
13	1KH-22151-00-00	SEAL, GUARD	1	
14	34L-22117-00-00	CAP	1	
15	38V-22199-00-00	SUPPORT, CHAIN	1	
16	90387-06737-00	COLLAR	2	
17	91001-06020-00	BOLT, FLANGE	2	
18	34X-22311-00-00	CASE, CHAIN	1	
19	90119-05062-00	BOLT, WITH WASHER	2	
20	3RW-2217A-00-00	ARM, RELAY	1	
21	90386-20120-00	BUSH	2	
22	90387-140J9-00	COLLAR	1	
23	34L-22128-00-00	COVER, THRUST 1	2	
24	90105-12668-00	BOLT, WASHER BASED	1	
25	90201-122H1-00	WASHER, PLATE	1	
26	95611-12100-00	NUT, U	1	
27	93700-06M03-00	NIPPLE, GREASE	1	
28	90386-18115-00	BUSH	2	
29	93109-18020-00	OIL SEAL	2	

CONTINUED ON NEXT FRAME ➤




4BE1110-2200

SWING ARM


Ref. No.	Part Number	Description	Qty	Remarks
30	90387-126J8-00	COLLAR	1	
31	90109-10752-00	BOLT	1	
32	90201-100E9-00	WASHER, PLATE	1	
33	90185-10120-00	NUT, SELF-LOCKING	1	
34	93700-06005-00	NIPPLE, GREASE	1	
35	90380-16109-00	BUSH, SOLID	2	
36	22W-22124-00-00	BUSH 2	1	
37	90387-106G0-00	COLLAR	1	
38	90109-10689-00	BOLT	1	
39	90201-100E9-00	WASHER, PLATE	1	
40	90185-10120-00	NUT, SELF-LOCKING	1	
41	22W-22129-00-00	COVER, THRUST 2	2	
42	22W-22189-00-00	BOOT, RUBBER	1	
43	3RW-22189-00-00	BOOT, RUBBER	1	
44	1KH-2217F-00-00	ROD, CONNECTING 1	1	
45	90386-18115-00	BUSH	2	
46	93109-18020-00	OIL SEAL	2	
47	90387-121L6-00	COLLAR	1	
48	90109-10752-00	BOLT	1	
49	90201-100E9-00	WASHER, PLATE	1	
50	90185-10120-00	NUT, SELF-LOCKING	1	
51	93700-06M03-00	NIPPLE, GREASE	1	

REAR SHOCKS

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-22210-10-26	SHK/ABS ASSEMBLY, REARREAR	1	COMPETITION YELLOW
2	1YW-22216-00-00	. BUSH, REAR SHOCK ABSORBER	1	
3	90105-10250-00	BOLT, WASHER BASED	1	
4	95601-10100-00	NUT, U (95602-10100-00)	1	
5	90201-100E9-00	WASHER, PLATE	1	




IKH010-6210



FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-23102-00-00	FRONT FORK ASSEMBLY (L.H)	1	
2	34X-23126-00-38	. TUBE, OUTER (LEFT)	1	CLEAR(WBUFF)
3	2A6-23119-00-00	. . PLUG, DRAIN	1	W/WASHER
4	3RW-23110-00-00	. INNER TUBE COMP 1	1	
5	3RW-23351-00-00	. SPRING	1	
6	3RW-23171-00-00	. PISTON, FRONT FORK	1	
7	1KH-23144-00-00	. SEAL, DUST	1	
8	1KH-23145-00-00	. OIL SEAL	1	
9	34X-23156-00-00	. CLIP, OIL SEAL	1	
10	1KH-23147-00-00	. SEAL, SPACER	1	
11	34X-23125-00-00	. METAL, SLIDE 1	1	
12	34X-23157-00-00	. RING, PISTON	1	
13	34X-23151-00-00	. SPRING, REBOUND	1	
14	34X-23135-00-00	. METAL, SLIDE 2	1	
15	1KH-23166-00-00	. SPACER, OIL LOCK	1	
16	3M7-23181-00-00	. BOLT, HEXAGON SOCKET HEAD	1	W/ WASHER
17	1KH-23168-00-00	. CAP, FRONT FORK	1	
18	35E-23183-00-00	. CIRCLIP	1	
19	1KH-23111-00-00	. BOLT, CAP	1	
20	35E-23114-00-00	. GASKET	1	
21	5K7-23190-00-00	. AIR VALVE	1	
22	3H3-23147-00-00	. O-RING	1	
23	3RW-23103-00-00	FRONT FORK ASSEMBLY (R.H)	1	
24	34X-23136-00-38	. TUBE, OUTER (RIGHT)	1	CLEAR(WBUFF)
25	2A6-23119-00-00	. . PLUG, DRAIN	1	W/WASHER
26	3RW-23110-00-00	. INNER TUBE COMP 1	1	
27	3RW-23351-00-00	. SPRING	1	
28	3RW-23171-00-00	. PISTON, FRONT FORK	1	

CONTINUED ON NEXT FRAME ►





FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
29	1KH-23144-00-00	. SEAL, DUST	1	
30	1KH-23145-00-00	. OIL SEAL	1	
31	34X-23156-00-00	. CLIP, OIL SEAL	1	
32	1KH-23147-00-00	. SEAL, SPACER	1	
33	34X-23125-00-00	. METAL, SLIDE 1	1	
34	34X-23157-00-00	. RING, PISTON	1	
35	34X-23151-00-00	. SPRING, REBOUND	1	
36	34X-23135-00-00	. METAL, SLIDE 2	1	
37	1KH-23166-00-00	. SPACER, OIL LOCK	1	
38	3M7-23181-00-00	. BOLT, HEXAGON SOCKET HEAD	1	W/ WASHER
39	1KH-23168-00-00	. CAP, FRONT FORK	1	
40	35E-23183-00-00	. CIRCLIP	1	
41	1KH-23111-00-00	. BOLT, CAP	1	
42	35E-23114-00-00	. GASKET	1	
43	5K7-23190-00-00	. AIR VALVE	1	
44	3H3-23147-00-00	. O-RING	1	
45	3RW-23192-00-00	BAND	2	
46	3RW-23191-00-00	BOOT	2	
47	34X-23192-00-00	BAND	2	
48	10V-2331E-02-00	GUIDE, CABLE	1	
49	1KH-23340-00-00	UNDER BRACKET COMP	1	
50	5X2-23181-L0-00	BOLT, HEX SCKT HEAD	4	
51	92906-06100-00	WASHER, SPRING	1	
52	98516-06012-00	SCREW, PAN HEAD	1	

STEERING


Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00008-00	BEARING	1	
2	22F-23411-01-00	RACE, BALL 1	1	
3	22F-23412-01-00	RACE, BALL 2	1	
4	93503-16010-00	BALL 3/ 6	22	
5	10V-23416-01-00	COVER, BALL RACE 2	1	
6	90179-25033-00	NUT	1	
7	4BE-23435-10-00	CROWN, HANDLE	1	
8	90105-14329-00	BOLT, WASHER BASED	1	
9	95026-08040-00	BOLT, FLANGE	4	
10	1E6-23441-10-35	HOLDER, HANDLE UPPER ...	2	SILVER
11	95811-08035-00	BOLT, FLANGE	4	
12	34X-23317-00-00	HOLDER, CABLE	1	
13	98501-05018-00	SCREW, PAN HEAD	1	
14	92901-05600-00	WASHER, PLATE	1	
15	95380-05600-00	NUT	1	





FUEL TANK


Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-24110-00-08	FUEL TANK	1	UR NON-CA
	4BE-24110-00-03	FUEL TANK	1	UR CA ONLY
2	3RW-24240-70-00	. GRAPHIC SET	1	UR
3	3RW-24250-70-00	. GRAPHIC SET	1	UR
4	3RW-24500-00-00	FUEL COCK ASSEMBLY 1 ...	1	
5	4X8-24512-00-00	. O-RING	1	
6	3AJ-24534-00-00	. SEAL, COCK	1	
7	98580-03008-00	. SCREW, PAN HEAD (98501-03008-00)	2	
8	90149-06011-00	SCREW	2	
9	4FD-24524-00-00	LEVER, COCK	1	
10	98506-03008-00	SCREW, PAN HEAD (90157-03122-00)	1	
11	90202-05187-00	WASHER, PLATE	2	
12	90445-10007-00	HOSE	1	
13	90467-09006-00	CLIP	2	
14	11H-24602-03-00	CAP ASSEMBLY	1	UR NON-CA
	51K-24602-01-00	CAP ASSEMBLY	1	UR CA ONLY
15	1KH-24187-00-00	WASHER, SPECIAL	1	
16	1KH-24182-00-00	DAMPER, LOCATING 2	1	
17	30X-24183-01-00	DAMPER, LOCATING 3	1	
18	30X-24186-01-00	WASHER, SPECIAL	1	
19	97013-06012-00	BOLT	1	
20	92995-06100-00	WASHER, SPRING	1	
21	4H7-24181-00-00	DAMPER, LOCATING 1	2	
22	3RW-2414H-00-00	DAMPER, PLATE 1	1	
23	3RW-2414J-00-00	DAMPER, PLATE 2	1	



PW2010-1250

SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	3RW-24730-20-00	DOUBLE SEAT ASSEMBLY ...	1	
2	3RW-24731-20-00	. COVER, DOUBLE SEAT	1	
3	3RW-24738-00-00	. BRACKET, SEAT	1	
4	3RW-24748-00-00	. BRACKET, SEAT	1	
5	3RW-24734-20-00	. BAND, SEAT	1	
6	95811-06016-00	. BOLT, FLANGE (95801-06016)	4	
7	90201-06M02-00	. WASHER, PLATE	4	
8	1KH-2475M-00-00	. SEAL	1	
9	90119-06043-00	BOLT, WITH WASHER	2	




FRONT WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	34X-25111-02-35	HUB, FRONT	1	SILVER
2	93306-20209-00	BEARING	2	
3	90560-15290-00	SPACER	1	
4	93102-20281-00	OIL SEAL (SD 20-35-5)	1	
5	94416-21427-00	RIM (1.60-21)	1	
6	1KH-25104-00-00	SPOKE SET, FRONT	1	
7	94127-212X0-00	TIRE (2.75-21 45P/TW27)	1	UR BRIDGESTONE
8	94227-21123-00	TUBE (80/100-21 TR4 BTL) ...	1	UR BRIDGESTONE
9	94330-21084-00	BAND, RIM (70-80/100-21)	1	UR BRIDGESTONE
10	90480-10068-00	GROMMET	1	
11	90387-15600-00	COLLAR	1	
12	322-25118-00-00	COVER, HUB DUST	1	
13	90201-163H8-00	WASHER, PLATE	1	
14	90201-15785-00	WASHER, PLATE	1	
15	34X-25181-00-00	AXLE, WHEEL	1	
16	90171-14020-00	NUT, CASTLE	1	
17	91401-30030-00	PIN, COTTER	1	
18	34X-25190-01-00	GEAR UNIT ASSEMBLY	1	





IKH010-6260



FRONT BRAKE CALIPER

Ref. No.	Part Number	Description	Qty	Remarks
1	34X-25831-00-00	DISC, BRAKE (RIGHT)	1	
2	90109-06757-00	BOLT	6	
3	1RH-2580T-00-00	CALIPER ASSEMBLY L (LEFT)	1	
4	34X-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
5	34X-W0047-00-00	. . CALIPER SEAL KIT	1	
6	5R2-25937-00-00	. BOOT 2	1	
7	34X-25937-00-00	. BOOT 2	1	
8	51L-W0048-00-00	. BLEED SCREW KIT	1	
9	34X-W0046-02-00	. BRAKE PAD KIT	1	
10	34X-25919-00-00	. SUPPORT, PAD	2	
11	2GV-25926-00-00	. BOLT	1	
12	34X-25845-00-00	. CAP, INDICATOR	1	
13	90105-10638-00	BOLT, WASHER BASED	2	
14	(1RH-25715-30-00)	COVER 1	1	
15	90149-06194-00	SCREW	2	






REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
1	15A-25311-00-35	HUB, REAR	1	SILVER
2	90560-15313-00	SPACER	1	
3	146-25116-00-00	FLANGE, SPACER 2	1	
4	93306-20226-00	BEARING	1	
5	93306-20209-00	BEARING	2	
6	93104-22018-00	OIL SEAL	1	
7	90116-08218-00	BOLT, STUD	6	
8	15A-25321-03-35	PLATE, BRAKE SHOE	1	SILVER
9	4BE-W2536-00-00	BRAKE SHOE SET	1	
10	90506-15260-00	SPRING, TENSION	2	
11	3Y6-25351-00-00	CAMSHAFT	1	
12	5R0-25355-00-00	LEVER, CAMSHAFT	1	
13	90101-06278-00	BOLT	1	
14	95380-06600-00	NUT, HEXAGON	1	
15	4H7-2533A-02-00	PLATE, INDICATOR	1	
16	94421-18426-00	RIM (2.15-18)	1	
17	23J-25304-00-00	SPOKE SET, REAR	1	
18	94112-182X1-00	TIRE (120/80-18 62P TW30)	1	UR BRIDGESTONE
19	94241-18153-00	TUBE (4.10-18)	1	UR BRIDGESTONE
20	94340-18086-00	BAND, RIM (4.00-18)	1	UR BRIDGESTONE
21	3Y1-25394-00-00	SPACER, BEAD	1	
22	1KH-25445-00-00	SPROCKET, DRIVEN (45T)	1	
23	90215-08160-00	WASHER, LOCK	3	
24	90170-08258-00	NUT	6	
25	5H0-25388-00-00	PULLER, CHAIN 1	1	
26	5H0-25389-00-00	PULLER, CHAIN 2	1	
27	90387-151R1-00	COLLAR	1	
28	1KH-25383-01-00	COLLAR, WHEEL	1	
29	31G-25381-00-00	AXLE, WHEEL	1	

CONTINUED ON NEXT FRAME ➤


IKH010-6281

REAR WHEEL



Ref. No.	Part Number	Description	Qty	Remarks
30	90171-14031-00	NUT, CASTLE	1	
31	91401-30030-00	PIN, COTTER	1	
32	94581-33120-00	CAHIN (D.I.D.428V2-120L)	1	
33	94681-33011-00	. JOINT, CHAIN (D.I.D.428V2-FJ)	1	


IKH010-6281



3RW4010-2290

HANDLE - CABLE

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-26111-00-00	HANDLEBAR	1	
2	1LX-26242-01-00	GRIP (RIGHT)	1	
3	434-26243-12-00	TUBE, THROTTLE GUIDE	1	
4	1M1-26249-01-00	RING, LEAF	1	
5	1LX-26241-01-00	GRIP (LEFT)	1	
6	3RW-26311-01-00	CABLE, THROTTLE 1	1	
7	3RW-26335-00-00	CABLE, CLUTCH	1	
8	1E6-26342-00-00	BOOT, CABLE	1	
9	1T5-26372-00-00	COVER, HANDLE LEVER 1 ...	1	
10	3Y1-26290-00-00	BACK MIRROR ASSEMBLY (R.H)	1	
11	5Y1-26290-10-00	BACK MIRROR ASSEMBLY (L.H)	1	
12	90387-22660-00	COLLAR	1	
13	1VJ-26331-01-00	CABLE, STARTER 1	1	
14	1YU-26329-00-00	. CAP, RUBBER	1	
15	1AE-26325-00-00	. KNOB, CHOKE	1	
16	90149-03132-00	. SCREW, SPECIAL SHAPE ...	1	
17	1VJ-26333-00-00	NUT	1	
18	3RW-26334-00-00	CABLE, STARTER 2	1	
19	53L-26261-01-00	CONNECTOR, CABLE	1	
20	38V-26281-00-98	CAP, GRIP UPPER	1	LOW GLOSS BLACK
21	493-26282-00-98	CAP, GRIP LOWER	1	LOW GLOSS BLACK
22	38V-2628H-00-00	CAP, WIRE	1	
23	98706-04012-00	SCREW, FLAT HEAD	2	
24	98586-05016-00	SCREW, PAN HEAD	2	
25	4BE-2637G-00-00	HOLDER, WIRE	1	
26	90465-13169-00	CALMP	1	




STAND - FOOTREST

Ref. No.	Part Number	Description	Qty	Remarks
1	1KH-27200-00-00	PEDAL, BRAKE	1	
2	55V-27242-00-00	. PEDAL, BRAKE	1	
3	90508-14352-00	. SPRING, TORSION	1	
4	91701-06022-00	. PIN, CLEVIS	1	
5	92901-06600-00	. WASHER	1	
6	91490-20020-00	. PIN, COTTER (91401-20020-00)	1	
7	1KH-27212-00-00	SHAFT, BRAKE PEDAL	1	
8	90201-12541-00	WASHER, PLATE	1	
9	93430-09038-00	CIRCLIP	1	
10	97011-06020-00	BOLT	1	
11	95380-06700-00	NUT	1	
12	90506-18305-00	SPRING, TENSION	1	
13	1KH-27231-00-00	ROD, BRAKE	1	
14	90240-06006-00	PIN, CLEVIS	1	
15	92990-06200-00	WASHER, PLAIN	1	
16	91401-25020-00	PIN, COTTER	1	
17	90501-10245-00	SPRING, COMPRESSION	1	
18	90249-12008-00	PIN	1	
19	90179-06411-00	NUT, SPECIAL SHAPE	1	
20	4BE-27311-00-R4	STAND, SIDE	1	BLACK
21	90506-29276-00	SPRING, TENSION	1	
22	42U-27315-01-00	LINK, SIDE STAND	1	
23	90109-10474-00	BOLT	1	
24	90185-10037-00	NUT, SELF-LOCKING	1	
25	22W-27411-01-90	FOOTREST 1	1	UNI-CHROME BLACK CHROMATE
26	90508-20023-00	SPRING, TORSION	1	
27	91701-08038-00	PIN, CLEVIS	1	
28	91401-25020-00	PIN, COTTER	1	

CONTINUED ON NEXT FRAME ➤


48E1110-2310



48E1110-2310

STAND - FOOTREST


Ref. No.	Part Number	Description	Qty	Remarks
29	1KH-27412-00-00	BRACKET, FOOTREST 1	1	
30	95806-10016-00	BOLT, FLANGE	2	
31	1KH-27421-00-90	FOOTREST 2	1	UNI-CHROME BLACK CHROMATE
32	90508-20155-00	SPRING, TORSION	1	
33	91701-08038-00	PIN, CLEVIS	1	
34	91401-25020-00	PIN, COTTER	1	
35	1KH-27422-00-00	BRACKET, FOOTREST 2	1	
36	91316-10020-00	BOLT	2	
37	120-27433-00-00	COVER, REAR FOOTREST	2	
38	90201-20279-00	WASHER, PLATE	2	
39	120-27431-00-00	FOOTREST, REAR 1	2	
40	90240-06009-00	PIN, CLEVIS	2	
41	91490-16020-00	PIN, COTTER (91402-16015)	2	
42	4BP-27434-00-00	BOLT	1	
43	90201-120K4-00	WASHER, PLATE	1	
44	90201-08784-00	WASHER, PLATE	1	
45	3RW-27432-00-00	BRACKET 1	1	
46	3RW-27442-00-00	BRACKET 2	1	
47	92016-08020-00	SCREW	4	



4BE4100-3320

COWLING 1


Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-W2834-20-00	BODY, COWLING	1	
2	4BE-28368-10-00	. EMBLEM	1	
3	23V-85110-00-00	REFLECTOR ASSEMBLY	2	
4	95701-05500-00	NUT, FLANGE	2	
5	90480-12053-00	GROMMET	2	
6	90149-06263-00	SCREW	1	



4FD1710-3360


METER

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-83580-00-00	SPEEDOMETER ASSEMBLY ..	1	
2	4BE-8355A-00-00	BRACKET, METER	1	
3	1M1-83526-00-00	DAMPER 2	2	
4	90201-05033-00	WASHER, PLATE	2	
5	90468-10050-00	CLIP	2	
6	3TB-83536-00-00	SOCKET, METER	1	
7	3YP-83520-00-00	SOCKET CORD ASSEMBLY ..	1	
8	5Y1-83513-00-00	DAMPER	1	
9	4G1-84744-00-00	BULB (12V-3.4W T-10)	4	
10	4BE-8352K-00-00	PLUG, BLIND	1	
11	1RH-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	



HEADLIGHT

Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-84320-00-00	LENS ASSEMBLY	1	HALOGEN
2	1ML-84314-00-XX	WIRE, STARTER (D:5MM, 1.7M)	1	
3	2F9-84397-01-00	COVER, SOCKET	1	
4	3TB-84325-00-00	SCREW, RIM FITTING	2	
5	341-84332-60-00	SPRING, SCREW	2	
6	198-84334-60-00	NUT, ADJUSTING	2	
7	3TB-8431R-00-00	STAY, SETTING	1	
8	4BE-84311-00-00	BODY, HEADLIGHT	1	
9	3TB-84372-01-00	BOLT, LAMP STAY	1	
10	3TB-84329-00-00	BOLT, WING 1	2	
11	90202-06013-00	WASHER, PLATE	2	
12	90468-12120-00	CLIP	2	
13	3TB-84137-00-00	BOLT, SPECIAL	2	
14	97016-06025-00	BOLT	1	
15	90201-06059-00	WASHER, PLATE	1	
16	90387-06388-00	COLLAR	1	
17	90387-07391-00	COLLAR	2	
18	90480-14023-00	GROMMET	3	




48E1110-2360

TAILLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	1W9-84710-60-00	TAILLIGHT UNIT ASSEMBLY ..	1	
2	1M1-84523-60-00	. GASKET, LENS	1	
3	1M8-84521-40-00	. LENS, TAILLIGHT	1	
4	1M1-84524-60-00	. SCREW, LENS FITTING	2	
5	31L-84714-00-00	. BULB, TAILLIGHT (12V-21/5W)	1	
6	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	1	
7	95701-05500-00	NUT, FLANGE	1	
8	4BE-84717-00-00	CORD, TAILLIGHT	1	

TURN SIGNAL

Ref. No.	Part Number	Description	Qty	Remarks
1	1UF-83310-00-00	FRONT FLASHER LIGHT ASSEMBLY 1	1	
2	51L-83332-01-00	. LENS, FLASHER	1	
3	306-83311-40-00	. BULB, FLASHER (12V-21W)	1	
4	97706-40620-00	. SCREW, TAPPING	1	
5	95311-12700-00	NUT	1	
6	18G-83365-00-00	CAP	1	
7	1UF-83320-00-00	FRONT FLASHER LIGHT ASSEMBLY 2	1	
8	51L-83342-01-00	. LENS, FLASHER 2	1	
9	306-83311-40-00	. BULB, FLASHER (12V-21W)	1	
10	97706-40620-00	. SCREW, TAPPING	1	
11	95311-12700-00	NUT	1	
12	18G-83365-00-00	CAP	1	
13	4BE-83330-00-00	REAR FLASHER LIGHT ASSEMBLY 1	1	
14	256-83311-70-XX	. BULB (12V-27W)	1	
15	51L-83332-01-00	. LENS, FLASHER	1	
16	97706-40520-00	. SCREW, TAPPING	1	
17	4BE-83368-00-00	STAY, FLASHER 1	1	
18	95311-12700-00	NUT	1	
19	10V-83365-00-00	CAP	1	
20	4BE-83340-00-00	FLASHER LIGHT ASSEMBLY 2	1	
21	256-83311-70-XX	. BULB (12V-27W)	1	
22	51L-83342-01-00	. LENS, FLASHER 2	1	
23	97706-40520-00	. SCREW, TAPPING	1	
24	4BE-83369-00-00	STAY, FLASHER 2	1	
25	95311-12700-00	NUT	1	
26	10V-83365-00-00	CAP	1	



4BE1110-2350




ELECTRICAL 1


Ref. No.	Part Number	Description	Qty	Remarks
1	4BE-85540-00-00	C.D.I. UNIT ASSEMBLY	1	
2	3RW-85546-00-00	BAND	1	
3	4BE-82310-00-00	IGNITION COIL ASSEMBLY ...	1	
4	98502-06016-00	SCREW, PAN HEAD (98501-06014-00)	2	
5	3NS-82370-00-00	PLUG CAP ASSEMBLY	1	
6	2H7-82540-00-00	NEUTRAL SWITCH ASSY	1	
7	90430-10171-00	GASKET	1	
8	47X-81960-A2-00	RECTIFIER & REGULATOR ASSEMBLY	1	
9	98511-06012-00	SCREW, PAN HEAD	2	
10	BTY-YTX7L-BS-00	BATTERY ASSEMBLY	1	
11	3RW-82115-00-00	WIRE, PLUS LEAD	1	
12	3RW-82116-00-00	WIRE, MINUS LEAD	1	
13	2TV-82150-01-00	FUSE HOLDER ASSEMBLY ...	1	
14	4X7-82151-00-00	. FUSE (15A)	1	
15	22F-82131-00-00	BAND, BATTERY	1	
16	2HV-82501-00-00	MAIN SWITCH STEERING LOCK	1	
17	90149-06228-00	SCREW	2	
18	4BE-82530-01-00	STOP SWITCH ASSEMBLY ...	1	
19	4BE-82590-00-00	WIRE HARNESS ASSEMBLY ..	1	
20	25G-83936-01-00	BAND, SWITCH CORD	1	
21	25G-83936-01-00	BAND, SWITCH CORD	2	
22	437-83936-11-00	BAND, SWITCH CORD	1	
23	12R-82591-00-00	BAND	1	
24	437-83936-11-00	BAND, SWITCH CORD	1	
25	4BE-83350-00-00	FLASHER RELAY ASSEMBLY .	1	
26	3RW-83371-00-00	HORN	1	
27	95811-06010-00	BOLT, FLANGE	1	

CONTINUED ON NEXT FRAME ➤

ELECTRICAL 1



Ref. No.	Part Number	Description	Qty	Remarks
28	3RW-81950-00-00	RELAY ASSEMBLY	1	
29	3AY-81940-00-00	STARTER RELAY ASSEMBLY .	1	
30	95701-06500-00	NUT, FLANGE	2	
31	3LD-82566-00-00	SWITCH, SIDE STAND	1	
32	98586-05016-00	SCREW, PAN HEAD	2	
33	29U-81950-93-00	RELAY ASSY	1	
34	12R-82591-00-00	BAND	1	



HANDLE SWITCH - LEVER

Ref. No.	Part Number	Description	Qty	Remarks
1	437-83936-01-00	BAND, SWITCH CORD	2	
2	1LN-82911-00-00	HOLDER, LEVER 1	1	
3	33G-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	
4	1NV-83912-00-00	LEVER 1	1	
5	90109-06799-00	BOLT	1	
6	95616-06100-00	NUT, U	1	
7	98506-05020-00	SCREW, PAN HEAD	2	
8	92906-05100-00	WASHER, SPRING	2	
9	3Y6-82917-00-00	SWITCH	1	
10	90123-08046-00	BOLT	1	
11	90179-08148-00	NUT	1	
12	1E6-26372-00-00	COVER, HANDLE LEVER 1 ...	1	
13	3YR-83922-00-00	LEVER 2	1	
14	90109-06577-00	BOLT	1	
15	95616-06100-00	NUT, U	1	
16	90149-06153-00	SCREW, SPEC'L SHAPE	1	
17	90170-06010-00	NUT	1	
18	90501-10312-00	SPRING, COMPRESSION	1	
19	34X-83980-01-00	FRONT STOP SWITCH ASSEMBLY	1	
20	4DW-83975-00-00	SWITCH, HANDLE 2	1	
21	98506-05018-00	. SCREW, PAN HEAD	2	
22	3RW-83973-00-00	SWITCH HANDLE 3	1	
23	98516-06030-00	. SCREW, PAN HEAD	2	