
COMPONENT LOCATIONS


CONTROL HARNESS	CL-18
DOOR HARNESS	CL-23
ENGINE HARNESS	CL-9
FRAME HARNESS	CL-8
GROUNDS	CL-29
INSTRUMENT HARNESS	CL-16
MAIN HARNESS	CL-2
REAR HARNESS	CL-24




-10

MAIN HARNESS

MAIN HARNESS(1)




M01,M02,M03,M04,M05,M06 M07, M08, M09, M10, M11, M13



M20-1,M20-2,M20-3,M20-4


E3HC001D




M14-1,M14-2,M14-3,M15,M16

M21 E3HC001B

E3HC001E



M17,M18-3,M18-4,M18-5,M18-6





E3HC001C


E3HC001F


E3HC001A

Facia panel removed



MAIN HARNESS(2)







M25,M27,M28,M29

E3HC001G

M32,M33,M36

E3HC001K







M26

E3HC001H

E3HC001L







M31

M37,M38 E3HC001J

E3HC001M

MAIN HARNESS(3)







M40

E3HC001N M44,M44-1,M48

E3HC001R







M42

E3HC001P

E3HC001S






M51, M53, M56, M58-1, M58-2 E3HC001Q


E3HC001T

M43

M45,M46,M47,M49

MAIN HARNESS(4)







M59

E3HC001U

E3HC001X






M60,M64

E3HC001V

E3HC001Y



M66 PASSENGEF AIR BAG Glove box removed


M62

M66 E3HC001W

E3HC001Z

M82 DRIVER

MAIN HARNESS(5)






E3HC0A1A


M82

E3HC0A1D




M68,MD01,MD02

E3HCOA1B



MC05,MC06,MC07,MC08,MC09,MC10 E3HC0A1E



M69,MF01,MF02,MF03

``-...

E3HC0A1C

MD03,MD04

Right lower crash pad removed

E3HC0A1F

Right


door


3

MD03(8P) MD04(10P)




3VAN






MR01,MR02,MR03,MR11,MR12

E3HC0A1K



MI01,MI02,MM01

E3HC0A1H



MR05,MR06

VAN


E3HCOA1L

Left lower quarter trim removed

MR09(6P)

MR10(1P)

MR08(10P)






E3HC0A1J

MR08,MR09,MR10

E3HCOA1M

FRAME HARNESS

FRAME HARNESS(1)






F01


E3HCOAIN F07

E3HCOA1R




F02,F03,F04,F05

E3HC0A1P



• **F09**

E3HC0A1S





F06

E3HC0A1Q

ENGINE HARNESS


ENGINE HARNESS(1)






E08,E11

E3HC002D







E03

E01,E02,E07

E3HC002B

E3HC002E





E13,E14,E15,E16,E17,E18,E19 E3HC002C

E3HC002F

E05




CL-9

E3HC002A


E09

ENGINE HARNESS(2)




E20,E21,E23,E24


E3HC002G







ЕЗНСОО2Н







E29







E3HC002M

E3HC002L

E26,E27

ENGINE HARNESS(3)







E32

E3HC002N

E3HC002R






E34

E38,E39 E3HC002P

E3HC002S









E40,E41

E3HC002T

E35


ENGINE HARNESS(4)






E42

E3HC002X







E43,E44

E49,E51 E3HC002V

E3HC002Y






E3HC002W


E3HC002Z

E46

E48 E3HC002U

ENGINE HARNESS(5)







E52,E54

E3HC0A2A

E60,E61

E3HC0A2D






E55

ЕЗНСОА2В

E66,E68,E72

E3HC0A2E



E57,E58


E3HC0A2C



E70,E70-1,E70-2,E71-1 E71-2,E71-3,E71-4


E3HC0A2F

ENGINE HARNESS(6)




E73, E74, E77


E3HC0A2G



E79

E3HC0A2K






E75,E80

E3HC0A2H

Antoning Front exhaust pipe E78(DIESEL) E81(MPI) TRANSAXLE RANGE SWITCH Transmission case (Bottom view) 181




E3HC0A2M

E78,E81


E3HC0A2J

EC05,EC06




EC07,EC08

E3HC0A2N




EE01,EE02,EE03 EE04,EE05,EE09

E3HC0A2Q





E3HC0A2P





EM01,EM02,EM03,EM04 EM05,EM06,EM07

E3HC0A2R

INSTRUMENT HARNESS

INSTRUMENT HARNESS(1)







I12 MULTIMETER

ЕЗНСООЗА 107,111

E3HC003D






103,104,110

101,102,106

E3HC003B




105,113


ЕЗНСООЗС


c **109**

I14 HAZARD SWITCH I16 4WD SWITCH I08,112,114,115,116 BHC003E



E3HC003F






117,118

E3HC003G


124,125,1102

E3HC003K






E3HC003H




E3HC003L






127 E3HC003J



E3HC003M


CONTROL HARNESS

CONTROL HARNESS(1)




C01,C05,C06,C08,C09

E3HC004A




C02

E3HC004B




C03



C12,C13,C14,C15-1,C15-2 C15-3,C15-4

E3HC004D




C16

MPI C23 POWER STEERING PRESSURE SWITCH Battery




E3HC004F

CONTROL HARNESS(2)




C25,C26,C28-1,C28-2,C28-3,C28-4 E3HC004G



C33,C35-1,C35-2

E3HC004K









C36 E3HC004H

E3HC004L






C32,C34

E3HC004J

E3HC004M

CONTROL HARNESS(3)






C38

E3HC004N

C42

E3HC004R




C40-1,C40-2,C40-3,C40-4

E3HC004P

C43

E3HC004S




C/RAIL Right fender C44 GLOW RELAY Air cleaner C44 E3HC004T





- E3HC004Q

CL-20



CONTROL HARNESS(4)






C46

E3HC004U

E3HC004X



C60-1,C60-2,C60-3,C60-4


C66,C68 E3HC004V

COVEC-F

C66 GLOW PLUG


E3HC004Y

C68 WATER TEMPERATURE SENSOR & SENDER




C61,C62,C65


C67,C69 E3HC004W



E3HC004Z

CONTROL HARNESS(5)







C70

CL-22

C74 E3HC0A4A

E3HC0A4D







C71,C73

CC01 E3HCOA4B

E3HC0A4E






C72

E3HC0A4C

E3HC0A4F


DOOR HARNESS

DOOR HARNESS(1)




D01,D06,D11,D16


E3HC005A



D15

E3HC005D






D02,D05


E3HC005B

в **D07,D17**

E3HC005E



D03,D04,D08,D13,D14,D18



· · ...




E3HC005F

REAR HARNESS


REAR HARNESS(1)





R05

E3HC006D





R02

E3HC006B

в **R06**

E3HC006E







R06 HIGH-MOUNTED STOP LAMP



E3HC006F

REAR HARNESS(2)







R09,R10

E3HC006G


E3HC006K






R12

E3HC006H







E3HC006J R16



E3HC006M

REAR HARNESS(3)







R17, R19, R33

E3HC006N


E3HC006R





R18, R25


E3HC006P



R21,R22,R23,R26,R29,R34,R35



1







E3HC006Q



REAR HARNESS(4)





R45


E3HC006U

E3HC006X




R46


E3HC006V



R66, R67, R68, R70, R71, R72

E3HC006Y






RR01, RR02, RR03 E3HC006W

E3HC006Z

R47


REAR HARNESS(5)






RR14, RR15

E3HC0A6D







RR06

E3HCOA6B

E3HC0A6E







E3HC0A6F


RR07


·~ ...

GROUNDS

GROUNDS

GROUNDS(1)







G01

G05 E3HC007A

E3HC007D






G02,G03


G06,G07 E3HC007B

E3HC007E







E3HC007C



E3HC007F

GROUNDS(2)





Rela

box


G11

E3HC007G

ういた

G19


E3HC007K




G12,G13,G16,G17

G19 E3HC007H

E3HC007L





G23,G24 E3HC007J

E3HC007M

G14