

# **TRIPLE S** *Customs*

## **SUBARU LEGACY 1991-2004 VEHICLE WIRING**

# WIRING INFORMATION 1991 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	Wagon: RED/GREEN Sedan: YELLOW/BLUE	Wagon: Harness In Driver's Kick Panel Sedan: Light In Trunk
TACHOMETER	BLACK/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1992 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	Wagon: RED/GREEN Sedan: YELLOW/BLUE	Wagon: Harness In Driver's Kick Panel Sedan: Light In Trunk
TACHOMETER	BLACK/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1993 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	Wagon: RED/GREEN Sedan: YELLOW/BLUE	Wagon: Harness In Driver's Kick Panel Sedan: Light In Trunk
TACHOMETER	BLACK/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1994 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	Wagon: RED/GREEN Sedan: YELLOW/BLUE	Wagon: Harness In Driver's Kick Panel Sedan: Light In Trunk
TACHOMETER	BLACK/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	GREEN/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1995 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	LT.GREEN/YELLOW	Light In Trunk
TACHOMETER	BLACK/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1996 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
PARKING LIGHTS (+)	RED	Harness In Driver's Kick Panel
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	LT.GREEN/YELLOW	Light In Trunk
TACHOMETER	BLACK/BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1997 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	At Module Under Dash Left Of Column
POWER DOOR UNLOCK (-)	WHITE	At Module Under Dash Left Of Column
PARKING LIGHTS (+) -test with ignition on-	RED	In Gray Connector Above Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	LT.GREEN/YELLOW	Light In Trunk
FACTORY ALARM ARM (-)	GREEN/YELLOW	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	GREEN/LT.BLUE	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER	BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1998 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	At Module Under Dash Left Of Column
POWER DOOR UNLOCK (-)	WHITE	At Module Under Dash Left Of Column
PARKING LIGHTS (+) -test with ignition on-	RED	In Gray Connector Above Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	LT.GREEN/YELLOW	Light In Trunk
FACTORY ALARM ARM (-)	GREEN/YELLOW	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	GREEN/LT.BLUE	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER	BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 1999 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	BLACK/YELLOW	Ignition Harness
12V IGNITION WIRE	RED	Ignition Harness
12V ACCESSORY WIRE	RED/YELLOW	Ignition Harness
STARTER WIRE	BLUE/RED	Ignition Harness
POWER DOOR LOCK (-)	WHITE/RED	At Module Under Dash Left Of Column
POWER DOOR UNLOCK (-)	WHITE	At Module Under Dash Left Of Column
PARKING LIGHTS (+) -test with ignition on-	RED	In Gray Connector Above Fuse Box
DOOR TRIGGER (-)	RED/WHITE	In Black Connector Above Hood Release
TRUNK TRIGGER (-)	LT.GREEN/YELLOW	Light In Trunk
FACTORY ALARM ARM (-)	GREEN/YELLOW	In Harness Coming Into Vehicle From Driver's Door
FACTORY ALARM DISARM (-)	GREEN/LT.BLUE	In Harness Coming Into Vehicle From Driver's Door
TACHOMETER	BLUE	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	RED/BLUE	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLACK/BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	GREEN/YELLOW	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	GREEN/BLACK	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/WHITE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	GREEN/WHITE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 2000 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 2001 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 2002 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 2003 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door

# WIRING INFORMATION 2004 Subaru Legacy

WIRE	WIRE COLOR	LOCATION
12V CONSTANT WIRE	WHITE	Ignition Harness
12V IGNITION WIRE	GREEN	Ignition Harness
12V ACCESSORY WIRE	YELLOW	Ignition Harness
STARTER WIRE	WHITE/BLACK	Ignition Harness
POWER DOOR LOCK (-)	WHITE	Harness In Driver's Kick Panel
POWER DOOR UNLOCK (-)	GREEN/RED	Harness In Driver's Kick Panel
PARKING LIGHTS (+)	ORANGE	At Light Switch
DOOR TRIGGER (-)	PINK/BLACK	In White Connector Behind Fuse Box
TRUNK TRIGGER (-)	YELLOW/BLUE	In White Connector Behind Fuse Box
TRUNK RELEASE (5-wire)	LT.GREEN/YELLOW	At Motor In Tail Gate
FACTORY ALARM ARM (-)	Factory remote only	
FACTORY ALARM DISARM (-)	Factory remote only	
TACHOMETER	YELLOW/GREEN	At Ignition Coil
BRAKE WIRE (+)	WHITE/BLACK	At Brake Pedal Switch
HORN TRIGGER (-)	RED/GREEN	Harness At Steering Column
LEFT FRONT WINDOW UP	BLUE/RED	At Driver Window Motor Inside Door
LEFT FRONT WINDOW DOWN	BLUE	At Driver Window Motor Inside Door
RIGHT FRONT WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT FRONT WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
LEFT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW UP	BLUE/RED	Harness In Driver's Kick From Driver Door
RIGHT REAR WINDOW DOWN	BLUE	Harness In Driver's Kick From Driver Door